



VistaMAX OBR3650HP Outdoor Base Station Transceiver

Installation and Operation Guide



Document: **OBR3650HP_ml_r01_sd**
Approved: **C.W.**

Proprietary to Vecima Networks Inc.

(C) Vecima Networks Inc., 2009

Permission to Reproduce

Except as otherwise specifically noted, the information in this publication may be reproduced, in part or in whole and by any means, without charge or further permission from Vecima Networks Inc., provided that due diligence is exercised in ensuring the accuracy of the information reproduced; that Vecima Networks Inc. is identified as the source; and that the reproduction is not represented as an official version of the information reproduced.

This publication is also available electronically on the World Wide Web at the following address:
www.vecima.com

Vecima Networks Inc. reserves the right to revise this publication and to make changes in content from time to time without obligation on the part of Vecima Networks Inc. to provide notification of such revision or change.

Vecima Networks Inc. provides this guide without warranty of any kind, either implied or expressed, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Vecima Networks Inc. may make improvements or changes in the product(s) described in this manual at any time.

Specifications subject to change without notice.

Contents

Preface.....	i
Warnings and Advisories.....	i
Regulatory Notices.....	ii
Getting Support.....	iii
Finding Related Documentation	iii
Technical Support	v
Warranty and Service Policies	vi
1.0 Introduction.....	1-1
1.1 OBR3650HP Overview	1-1
1.2 Specifications.....	1-2
2.0 Installation.....	2-1
2.1 Unpacking the Unit	2-1
2.2 Mounting the OBR3650HP	2-1
2.2.1 Water Proof the Connection.....	2-6
2.3 Installing the Grounding Apparatus	2-7
2.3.1 Lightning Protection	2-7
2.3.2 Power Surge Protection.....	2-9
2.3.3 Grounding the Base Station	2-10
3.0 Getting Started with OBR3650HP	3-1
3.1 Before You Begin.....	3-1
3.2 Overview of Configuration.....	3-2
3.3 Using the Web Based Interface.....	3-2
3.4 Configuring the Network	3-3
3.5 Configuring the Radio.....	3-6
3.5.1 Setting the VistaMAX OBR3650HP Transmit Power for FCC Limits	3-7
3.6 Establishing a Link.....	3-14
3.7 Other Administrative Tasks.....	3-15
3.7.1 Upgrading the Base Station	3-15
3.7.2 Adding a Virtual IP Address.....	3-16
3.7.3 Rebooting the system.....	3-17
3.7.4 Applying Configuration	3-17
3.7.6 Checking Base Station Logs.....	3-17
3.7.7 Setting Service Flow Information	3-18
3.7.8 SNMP Configuration	3-22
3.7.9 Subscriber Station Modulation Table	3-22

3.7.10 Checking Base Station Status.....	3-22
3.7.11 SS Table	3-23
3.7.12 PKM AUTH Table	3-23
3.7.13 PKM TEK Table.....	3-23
A1 Molex® Backshell Installation	A-1
A1.1 Molex® Backshell Components	A-2
A1.2 Initial Placement of the Backshell.....	A-3
A1.3 Attaching the RJ45 Connector.....	A-4
A1.4 Completing the Backshell Installation.....	A-7
B1 Installing the Antenna - Points to Consider	B-1
B1.1 Planning the Installation.....	B-1
B1.2 Safety Considerations.....	B-1
B1.3 Evaluating the Mounting Location.....	B-1

Preface

Warnings and Advisories



CAUTION

Before installing and operating this equipment, read all safety, installation and operating sections. Retain this manual for future reference. Follow all instructions - failure to do so may result in damage to the unit or severe personal injury.



CAUTION

Servicing should not be attempted by the user. There are no user serviceable parts inside. Refer all servicing to factory qualified personnel.

Regulatory Notices

FCC Compliance

This equipment has been tested and found to comply with the limits for Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (EIRP) is not more than that required for successful communication.

For safety reasons, people should not work in a situation where RF exposure limits could be exceeded. To prevent this situation, the users should consider the following rules:

- Install the antenna so that there is a minimum of 25 cm of distance between the antenna and people.
- Do not turn on power to the device while installing the antenna.
- Do not connect the antenna while the device is in operation.
- Do not collocate or operate the antenna used with the device in conjunction with any other antenna or transmitter.
- In order to ensure compliance with local regulations, the installer MUST enter the antenna gain at the time of installation.

Any changes or modifications not expressly approved by Vecima Networks Ltd. could void the user's warranty.

The Vecima OBR3650HP base station unit must be installed by a trained professional, value added reseller, or systems integrator who is familiar with regulatory EIRP limits, RF cell planning issues and the regulatory limits defined by the FCC.



WARNING

See "3.5.1 Setting the VistaMAX OBR3650HP Transmit Power for FCC Limits" on page 3-7 for professional installation instructions regarding safe EIRP limits.

Industry Canada Compliance

Operation of this device is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

The users should not modify or change this device without written approval from Vecima Networks. Modification will void warranty and authority to use the device.

Getting Support

Finding Related Documentation

The user manuals for the VistaMAX series of products may be downloaded from our FTP site as follows:


- Step 1

Using a web browser, visit <https://files.vecima.com>
- Step 2

Select 103 from the 'Jump to Download Area' drop menu and click on 'Go!'



Private Download Area



- Step 3

Enter the Username as **vistamax** and the Password as **vistamax**

Index of /private_dl/103

Name	Last modified	Size	Description
Parent Directory		-	
Document full names ..>	18-Jun-2008 11:08	456	
nms8000_ml_01_sd.pdf	16-Feb-2007 13:14	13M	
obr3500_ml_02_sd.pdf	27-Jun-2008 14:58	8.0M	
obr3650_ml_01_sd.pdf	27-Jun-2008 14:30	8.6M	
opc3500_ml_01_sd.pdf	29-Jun-2007 09:28	9.0M	
osr3500_ml_02_sd.pdf	06-Jul-2007 16:11	7.0M	
wes800_ml_04_sd.pdf	17-Dec-2007 11:47	2.5M	

Apache/2.0.54 (Ubuntu) mod_python/3.1.3 Python/2.4.2 PHP/4.4.0-3ubuntu2 proxy_html/2.4 mod_ssl/2.0.54 OpenSSL/0.9.7g Server at postoffice Port 443

- Step 4

Download the required file(s)

Document Conventions

This manual uses the following special formats to emphasize key information. Be aware of all warnings and cautions before you begin to install the OBR3650HP.



WARNING

Whenever you see this icon and heading, the associated text addresses or discusses a critical safety or regulatory issue.



CAUTION

Whenever you see this icon and heading, the associated text discusses an issue, which, if not followed, could result in damage to, or improper use of, the equipment or software.



NOTE

Whenever you see this icon and heading, the associated text provides some important information not directly related to the topic.



TIP

Whenever you see this icon and heading, the associated text provides a tip for facilitating the installation, testing, or operation of the equipment or software

Technical Support

Visit the Vecima Networks Web page at www.vecima.com.

- Get the latest announcements from Vecima Networks.
- Download product related software, manuals, application notes, or other information about Vecima products.

For technical support:

Contact technical support by telephone or email.

- Email: support@vecima.com
- Telephone: +1 306 955 7075, press "2" for technical support.

Be prepared to provide your model number and phone number.

Warranty and Service Policies

Warranty Statement

Vecima Networks warrants its products to be free from defects in workmanship or materials for a period of two years. The warranty begins on the date of the original shipment from Vecima Networks to its customer. No claim may be allowed for expenses incurred in installation or use. No other expressed or implied warranties shall apply to the goods sold. Vecima Networks is not responsible for delayed shipments, other loss beyond Vecima Networks' control, or consequential damages of any kind arising in connection with the use of its products. This warranty is a return-to-factory warranty only. During the warranty period Vecima Networks will at its option, replace, repair or refund the price paid for any item which is returned for service. This warranty does not apply to units that have been misused physically or used in an inappropriate environment.

Service Policies

Return Material Authorization

Before returning any item for service, you must obtain a Returned Material Authorization (RMA) number from Vecima Networks. Vecima Networks will assign a unique RMA number for each item returned.

How to Return an Item for Service

- Step 1** Contact Vecima Networks to obtain an RMA number. Before contacting Vecima Networks, record the model number, Vecima serial number, original invoice number, purchase order number, and a description of the fault. Vecima will request this information before providing an RMA.



Email: support@vecima.com

Telephone: +1 306 955 7075, press "2" for technical support.

- Step 2** Refer to the RMA number in all correspondence and clearly mark all applicable RMA numbers on the outside of each package returned.
- Step 3** The repair center will provide you with shipping instructions when they send the RMA number to you.
- Step 4** Ship each product to Vecima Networks in its original shipping container (or equivalent) via prepaid carrier, with appropriate insurance and customs documentation (where required). Vecima Networks will not accept collect shipments, damaged shipments or shipments unaccompanied by an RMA number.
- Step 5** Vecima Networks will replace or repair items and return them to you as follows:

For items still under warranty—Vecima Networks Inc. will return items via prepaid ground carrier. The customer is responsible for any additional costs incurred, including customs clearance and duties. The customer will be responsible for any additional charges incurred from alternative shipping methods.

For items no longer under warranty—Vecima Networks will return items via prepaid ground carrier at the customer's expense. The customer is responsible for any additional costs incurred, including customs clearance and duties. The customer will be responsible for any additional charges incurred from alternative shipping methods.

Repair Charges and Warranty Exemptions

Items returned beyond the warranty period or items that do not qualify for warranty service are subject to additional out-of-warranty repair charges. Descriptions of these charges and warranty exemptions are listed below:

- (1) Repair turnaround time is typically 5-14 business days after receipt of the item at Vecima Networks. A flat rate repair charge will apply to all out-of-warranty items. Flat rate repair charges are subject to change without notice.
- (2) Any faults due to customer error (i.e. - incorrect set-up or configuration settings) are subject to the current test fee and will be exempt from warranty.
- (3) Items returned with inadequate fault descriptions are subject to the current test fee and are exempt from warranty.
- (4) In the event that no fault is found, the item is subject to the current test fee and will be exempt from warranty.
- (5) Any product exhibiting external damage (either from shipping, improper handling or use) will be subject to inspection. If said damages are determined to be the cause of failure, the item will be exempt from warranty. All repairs to correct the external damage are subject to time & materials charges (parts and labor at current rates).
- (6) Items with damage caused by unauthorized repairs or by external devices are subject to current out-of-warranty flat rate repair charges and are exempt from warranty.
- (7) All products returned for factory optioning are subject to the applicable current option charge plus test fee. Factory-optioned products carry the balance of the original warranty or a 90 day warranty, whichever is greater.



NOTE

The customer must approve all out-of-warranty repairs in writing. Vecima will not start any repairs until they receive the customer's purchase order or out-of-warranty repair authorization.

This page intentionally left blank

1.0 Introduction

1.1 OBR3650HP Overview

The VistaMAX Outdoor Base Station 3650 (OBR3650HP) is a WiMAX compliant low power transceiver contained in a weatherproof sealed housing. The OBR3650HP offers a single out-of-box solution for WiMAX applications – the only equipment required inside the base station premises is Power over Ethernet switch. The OBR3650HP is part of the WiMAX compliant VistaMAX family of base stations, subscriber units, and network equipment available from Vecima Networks.

The OBR3650HP operates in the 3650 to 3675 MHz band. It requires an additional indoor Power over Ethernet switch such as the VPN100002. The WiMAX Ethernet Switch 800 (WES800) can also serve as the Ethernet switch to provide power to sectors using the units and serve as the network connection point.



Figure 1-1 VistaMAX OBR3650HP

1.2 Specifications

RF

Item	Specification
RF Frequency	3650 to 3675 MHz
RF Frequency Step Size	250 KHz
Duplexing Mode	TDD
Channel Bandwidth	3.5 MHz or 7 MHz (software selectable)
Modulation Types	IEEE 802.16-2004, OFDM256, burst by burst adaptive BPSK-1/2 QPSK-1/2, QPSK-3/4 16QAM-1/2, 16QAM-3/4 64QAM-2/3, 64QAM-3/4
Maximum Rated Power	+27dBm at the external antenna connector
Output Power	+17 dBm to +27 dBm
Output Power Control Range	FCC Part 90
Spectral Mask Compliance	-94 dBm
Minimum Sensitivity	-91 dBm
Integrated Antenna Options	N female

Network

Item	Specification
LAN Interface	10/100BaseT 802.3 Ethernet
Management/Monitoring Interfaces	SNMP (WiMAX Forum MIBs + Vecima Networks extensions) Built-in HTTPS web server Telnet/SSH CLI Syslog

Operation Parameters

Item	Specification
Lightning Protection	Multi-strike protection built-in
Power Supply	36 to 56 VDC Power over Ethernet
Power Consumption	45 W maximum

Mechanical

Item	Specification
Operating Temperature	-45°C to +55°C
Physical	20" x 8" x 5" (50.8cm x 20cm x 12.7cm) maximum
Mounting	Pole mount (2.5" to 4.5" diameter pole)
Weight	20 lbs. (9 kg) maximum
Weatherproofing	NEMA 4X/IP66

2.0 Installation

2.1 Unpacking the Unit

Carefully remove the equipment from the packing material and set it on a solid surface, such as a table or desk. If it appears damaged in any way, notify the carrier and keep all packing materials for inspection by the carrier's agent.

2.2 Mounting the OBR3650HP

The following hardware is included in the box for mounting the OBR3650HP to the pole:

- Qty. 1 x Chassis Bracket
- Qty. 1 x Elevation Adjustment Bracket
- Qty. 1 x Pole Catch Bracket
- Qty. 4 x 6 inch Carriage Bolts
- Qty. 8 x Nuts
- Qty. 4 x Split Lock Washer
- Qty. 4 x Bolts
- Qty. 4 x Flat Washer
- Qty. 4 x Nylon Washer

The Chassis Bracket and Elevation Adjustment Bracket come pre-installed on the OBR3650HP chassis.





Figure 2-1 OBR3650HP Pole Mounting Hardware

Figure 2-2 & 2-3 describe the steps necessary to prepare the OBR3650HP for pole mounting.

- 1 Remove the Elevation Adjustment Bracket from the Chassis Bracket by removing the four screws (2 on each side) .



- 2 Attach the Chassis Bracket to the OBR3650 using four bolts and assorted washers as shown below. Take care to place the nylon washers between the Chassis Bracket and the OBR3650 to prevent damage to the paint.






Figure 2-2 Preparing the OBR3650HP for Pole Mounting (Part 1)


3 Insert the four carriage bolts into the four square holes in the Elevation Adjustment bracket as shown

To prevent the square collar near the head of the carriage bolts from slipping back through the square holes, fasten a nut onto each carriage bolt as shown -- **NOTE:** do not use any washers; the nuts will not fasten flush to the surface. The nuts will prevent the square collars on the carriage bolts from slipping out of the notches when fastened down.


Square collar on carriage bolt



Elevation Adjustment bracket
with Carriage bolts installed
(viewed from the side)



Elevation Adjustment bracket
with Carriage bolts installed
(viewed from the "face" that
will mount against the pole)



Elevation Adjustment bracket
with Carriage bolts installed
(viewed from the "face" that
will mount towards the OBR3650)

4 After inserting the carriage bolt into the Elevation Adjustment bracket, re-attach the bracket to the OBR3650 by replacing the four screws (2 on each side) as shown.

The OBR3650 is now ready to be mounted to a pole.






Figure 2-3 Preparing the OBR3650HP for Pole Mounting (Part 2)

After preparing the OBR3650HP for pole mounting, hold the OBR3650HP against the pole at the desired height then place the Pole Catch Bracket onto the opposite side as shown in Figure 2-4. Fasten a lock washer and nut onto all four carriage bolts and tighten until the OBR3650HP is suitably secured in place.



Pole Mounting - Side View




Pole Mounting - Top View

Figure 2-4 Attaching the OBR3650HP to the Pole

Once the OBR3650HP is mounted to the pole, the Elevation Angle may be adjusted as necessary and the unit may be connected to the network via a CAT5E cable with a standard RJ45 connector on one end and a special Molex® backshell with RJ45 connector on the other end.

NOTE

If not using a pre-made cable assembly (such as a CAT5CABLE/OD/25, CAT5CABLE/OD/50, CAT5CABLE/OD/75 or CAT5CABLE/OD/10 from Vecima Networks), then a cable assembly will have to be made using the Molex® backshell included with the OBR3650HP. Please see Appendix 1 for details on how to install the Molex® backshell.



Connect the other end of the Ethernet cable into the network via surge suppressor

Figure 2-5 Connecting the OBR3650HP to the Network

2.2.1 Water Proof the Connection

Wrapping the antenna connection with sealing tape keeps the connection tight and protects against moisture.

To water proof the connection follow these steps:

- Step 1** Use a section of rubber sealing tape. Starting at the OBR3650HP end, stretch the tape and wrap it around the connector as close as possible to the body of the OBR3650HP. Overlap the tape by approximately one-half of its width so that it can form a seal with itself. Extend the wrapping to approximately one-inch past the end of the connector.



Figure 2-6 Apply Rubber Sealing Tape

- Step 2** Cover the sealing tape with electrical tape. Start approximately one inch further down the cable, and stretch the tape, overlapping by one-half. Wrap to the OBR3650HP end, then without breaking the tape, wrap back down to the cable end.



Figure 2-7 Water Proofed Connection

2.3 Installing the Grounding Apparatus

Install the grounding apparatus to protect the OBR3650HP from lightning strikes and power surges. Ground the base station to the earth ground to protect from lightning strikes. Use the surge suppressor to shunt to ground any over-voltage [>60 V] transients that may be induced on the CAT5E cablefeed via lightning or other high voltages.

2.3.1 Lightning Protection

The OBR3650HP has a built in lightning surge suppression mechanism to protect it against damage from lightning strikes.

Assembling the OBR3650HP Base Station Grounding

Attach the earth ground to the grounding lug located on the base station.

Provided parts:

- 1 x 5/8 inch washer
- 1 x 1/4 inch grounding lug

Required parts:

- 1 x #6 AWG grounding wire assembly of sufficient length to connect the OBR to the tower's earth ground bus
- 1 Size 11 Wrench (11mm or 7/16 inch)

To assemble and attach the ground lug:

1. Locate the grounding point on the OBR3650HP. This is at the bottom of the OBR, to the right of the Vecima sticker.
2. On the grounding lug, assemble the grounding combination in the following order:
Lug > Washer > Grounding Assembly > Washer.
3. Screw the combination into the OBR at the grounding point.
4. Attach the assembly to the lightning grid or the antenna.




Figure 2-8 Assembled Ground Lug

Grounding the Base Station

Vecima Networks requires that the OBR3650HP be connected to the tower grounding system as shown in Figure 2-11.




Figure 2-9 Grounding the OBR3650HP



CAUTION

Vecima Networks requires that the CAT5E cable to the OBR3650HP is connected to a lightning surge protector at the entrance to the building, prior to connection to the WES800 Ethernet Switch as shown in [Figure 2-10](#).

2.3.2 Power Surge Protection

Use the surge suppressor to protect your equipment and secure your data from power surges.

To connect the Cablefeed Shield to the Surge Suppressor Ground Lug

1. Remove the suppressor unit cover.
2. Thread the Ethernet cable through the right side opening to the suppressor.
3. Measure five (5) inches from the end of the cable that you threaded through the right side opening.
4. Lightly score the cable at the five inch mark.
5. Carefully slice the edge of the insulation.

Note: Do NOT cut the metal shield that surrounds the wires.

6. Slowly snip or slice the insulation down to the five (5) inch scoring.
7. Remove the insulation from the cable.
8. Gently twist the metal shield to form metal ground strip.
9. Make a straight-through cable with the wires.
- Remember:** be careful not to damage the metal ground strip.
10. Undo the grounding bolt on the right side of the suppressor.
11. Wrap the grounding strip onto the grounding bolt.
12. Screw the grounding bolt back into the side of the suppressor.
13. Thread the cable that connects to the Power over Ethernet through the left opening on the suppressor.
14. Strip the wires and make it a straight-through cable.
15. Connect the cables to their perspective ports.
16. Replace the cover of the suppressor.
17. Finish connecting the network. See [“2.3.3 Grounding the Base Station”](#)




Figure 2-10 Assembled Surge Suppressor

2.3.3 Grounding the Base Station

Vecima recommends grounding the base station using one of the following procedures depending on your configuration. If you are unsure which procedure to use, use procedure B.

Procedure A: Grounding the base station so that the building and the tower share the same earth ground:

1. Connect the chassis of the OBR3650HP to the tower via the grounding lug on the back of the unit. See “2.3.3 Grounding the Base Station”.
2. Use a shielded CAT5 cablefeed to connect the OBR base station to the surge suppressor.
3. Use an inline surge suppressor for all OBR3650HP cablefeed installations. Connect the shield of the cablefeed to the ground lug of the surge suppressor. The purpose of the surge suppressor is to shunt to ground any over voltage [>60] transients that may be induced on the CAT5E cablefeed via lightning or other high voltages.

Base Station Grounding

Option A: Building ground = Tower/Earth ground




Figure 2-11 Base Station Grounding - building ground is same as tower ground

Procedure B: Grounding the base station so that the building and the tower use different earth grounds:

1. Connect the chassis of the OBR3650HP to the tower via the grounding lug on the back of the unit. See “2.3.3 Grounding the Base Station”.
2. Use a shielded CAT5 cablefeed to connect the OBR base station to the surge suppressor.
3. Use two inline surge suppressors, one for all OBR3650HP cablefeed installations at the base of the tower and another for the first surge suppressor and the WES800. Connect the shield of the cablefeed to the ground lug of the surge suppressor. The purpose of the surge suppressor is to shunt to ground any over voltage [>60 V] transients that may be induced on the CAT5E cablefeed via lightning or other high voltages.




Figure 2-12 Base Station Grounding - building ground different than tower ground

This page intentionally left blank

3.0 Getting Started with OBR3650HP

3.1 Before You Begin

The OBR3650HP provides the base station component of the Vecima VistaMAX system. To set up and configure the base station, you require the following:

- One VistaMAX OBR3650HP base station with a stand-alone Power over Ethernet (PoE) or WES800 Ethernet Switch
- One VistaMAX outdoor subscriber station or indoor subscriber station such as the OSR3500C or ISR3510.
- One of the following components to provide the DHCP and TFTP server:
 - Vecima's Network Management 8000
 - A third-party DHCP and TFTP server as per the WiMAX standard. This setup is not covered in this manual.

Setting up the system using NMS8000

Using the NMS8000 as the provisioning tool for all OSR subscriber stations and hosts on the VistaMAX system is the most common scenario. The platinum, gold, silver, or bronze VistaMAX starter kits available from Vecima Networks includes an NMS8000.



NOTE

If you wish to connect Internet-accessible hosts to the VistaMAX system, you will need to provide a router with a public IP address and a valid DNS server. When you are connecting to Internet-accessible host and using the NMS8000, Vecima recommends connecting one of the NMS8000 Ethernet interfaces on a public routeable IP address.




Figure 3-1 Using NMS8000 to Provision VistaMAX System

3.2 Overview of Configuration

The following steps outline the process for configuring a VistaMAX system. This process assumes that you are using an NMS8000.

- Step 1** Use CAT5 straight-through Ethernet cables to connect the physical components as shown in **Using NMS8000 to Provision VistaMAX System**.
- Step 2** Use the Web-based interface to configure the IP addresses for the base station and subscriber station(s). If necessary, configure the IP addresses for the NMS8000.
- Step 3** Use the Web-based interface to configure the radio parameters for the base station and subscriber station(s).
- Step 4** If necessary, use the Web-based interface for the NMS8000 to add the subscriber stations on the NMS8000.
- Step 5** Establish the link between the base stations and subscriber stations and verify that the subscriber stations are online.

The steps that pertain to the base station are described in more detail below. For more information, refer to the *NMS8000 & NMS8000/SSP Network Management Server Installation and Operation Guide* or related information listed under [Finding Related Documentation](#) on page iii.

3.3 Using the Web Based Interface

The Web interface of the OBR3650HP system may be viewed with a standard web browser such as Mozilla™ or Internet Explorer™, no additional add-ins are required.



NOTE

If your Web certificate is invalid or expired, you will be prompted to continue without the certificate or add an exemption to the certificate.

The following are the default log on settings for the Base station Web-based interface:

- Web-based interface access — `https://192.168.101.2`
- subnetwork mask — `255.255.255.0`
- username — `root`
- password — `vistamax`

To log on to the Web-based interface:

- Step 1** Open a Web browser and open the Web-based interface by typing `https://192.168.101.2` in the address bar. The Network Password page opens:






NOTE

192.168.101.2 is the default IP address that comes preconfigured from Vecima, but your IP address might be different. If you are not using the default address, contact your system administrator for the IP address.

Step 2 Type the username `root` and the password `vistamax` to access the web GUI. The log on screen displays:



3.4 Configuring the Network

You will need to configure your network to establish communication between the network elements. Figure 3-2 shows an example of a properly configured network. The example shows a network configuration using default values. If you purchased a WiMAX starter kit, these value will already be set.

The VistaMAX Base Station is shipped with a default IP address. However, depending upon your network configuration, you may want to change the IP address of your Base Station.




Figure 3-2 Network Diagram

As per the WiMAX standard, the subscriber station requires an IP address and TFTP offered to it during network entry. To fulfill this requirement, both a DHCP and TFTP server must be present. It is possible to use a third-party customer-supplied DHCP and TFTP server, but Vecima recommends using the Network Management Server 8000 (NMS8000). Most Vecima starter kits come with an NMS as part of the solution.



NOTE

Customers who purchased the basic starter kit or who do not have an NMS must use the WiMAX-out-of-the-box (WOOTB) procedure. For more information about WOOTB, contact the Application Engineering Support at Vecima Networks.

To configure a network using NMS8000:

- Step 1** Open the base station graphical user interface (GUI) and click **Configuration > Network Configuration**. The Current Interfaces screen opens displaying the name, IP address, and netmask of the base station's primary interface. The default value is 192.168.101.2. To modify this value, click **br0** to open the BR0 configuration screen and type the new value in the appropriate field. See "To change the base station IP address" below for a detailed description of this Step.
- Step 2** Using the NMS GUI, set up and enable DHCP on the NMS, then configure the subscriber stations and host computers as required.




NOTE

For more information see the *NMS8000 & NMS8000/SSP Network Management Server Installation and Operation Guide*.

To change the base station IP address:

- Step 1** Log on to the Web-based interface and click **Configuration > Network Configuration**. The Current Interfaces table displays showing the primary (**br0**) IP address and virtual addresses (**br0:1 br0:2**, etc.) for your base station.

VistaMAX - OBR3650HP+ - v5.1.456


- Base Station
- Apply Configuration
- Show Logs
- Configuration
 - Initial Setup
 - Network Configuration**
 - Radio Configuration
 - SNMP Configuration
 - Max CPE Configuration
- Service Flows
 - Allowed MAC Addresses
 - VLAN Configuration
- Status
- System Tools

Current Interfaces

Name	IP Address	Netmask
br0	192.168.229.191	255.255.0.0
lo	127.0.0.1	255.0.0.0


Add Virtual Interface
Edit Default Gateway

Warning! Editing Interfaces will take effect immediately on change. This will likely result in Subscriber Station disconnection.

From this page, you can set the following parameters:

Parameter	Description	Default
br0 and Virtual Interfaces	<p>This is where the primary interface (br0) and any virtual interfaces (br0:1, br0:2, etc.) will be configured for remote access.</p> <p>The primary interface is the IP address for the Base Station.</p>	Dependent on your network design.
Gateway	This is where the default gateway will be specified for the br0 .	Dependent on your network design.

Step 2 Click the **br0** link under Name field in the Current Interfaces table. The window will change to this.



- In the **Primary IP Address** field, enter the new IP for the Base Station: 192.168.101.138
- In the **Primary IP Subnet Mask** field, enter the subnet mask for the Base Station. 255.255.255.0
- In the **Primary IP Gateway** field, enter the gateway address for your network 192.168.101.3

Step 3 Click the **Submit** button. The following message appears:

```
Network saving in progress ....
Network will now be reset.
You should now change your network on your computer so that you will be able to connect to 192.168.101.138.
After the network has been readjusted, You can cancel the reboot by clicking here to make changes permanent.
Otherwise Reverting Changes in 2 minutes.
```

Step 4 Click the [here](#) link to make the change permanent.



NOTE

At this point, you may need to change the IP configuration of the computer which you are using to access the base station. If you have completely changed the domain for the Base Station (was 192.168.101.1, now 172.200.26.1), please ensure the IP of the computer is capable of communicating with the new IP address of the BS. If not, adjust the network configuration of the computer accordingly before moving on to the next step.

The following information displays on the page to indicate the changed IP address:

```
Reboot Cancelled Successfully.
Permanent IP Config Set
Permanent IP Gateway set
Network Configuration Saved.
Network Saved.

Save Completed.
```

The address on the browser also changes to reflect the new IP address:

`https://192.168.101.138/cgi-bin/index.cgi`



NOTE

If you were not able to reconnect and click the [here](#) link to confirm the IP address of the Base Station within 2 minutes, the Base Station will revert to the old IP address and reboot automatically. Please restart the IP address change process by going back to step 1.


Step 5 Once you have made the correct configuration settings, click the **Submit** button at the bottom of the window.

Step 6 To apply the Radio Configuration, click **Apply Configuration** from the menu options. The configuration area displays a list of changes made. Click **Yes** to apply the changes.

3.5 Configuring the Radio

To configure the radio

Step 1 Log on to the Web-based interface and click **Configuration > Radio Configuration**. The following page displays:



VistaMAX - OBR3650HP+ - v5.1.456


General Radio Configuration

GPS Status:	Disabled	<input type="button" value="v"/>
Fixed Downlink Allocation:	50 % / 50 %	<input type="button" value="v"/>
Downlink/Uplink Center Frequency:	3550000 kHz	<input type="text"/>
Frame Duration:	10 ms	<input type="button" value="v"/>
Cyclic Prefix:	1/4	<input type="button" value="v"/>
Channel Bandwidth:	3500 kHz	<input type="button" value="v"/>
Transmit Power:	20.5 dBm	<input type="text"/>
Transmit Antenna Gain:	5 dBi	<input type="text"/>
Transmit Feed Loss:	0 dB	<input type="text"/>
Uplink Target Receive Level:	0 dB	<input type="button" value="v"/>
Pilot Fix:	True	<input type="button" value="v"/>
Data Encryption:	OFF	<input type="button" value="v"/>

You can set the following parameters for the base station radio from this page:

Parameter	Description	Procedure	Default
Downlink/Uplink center frequency	This is the channel center frequency in KHz	Enter the value into the blank field.	Customer specific
Transmit power	The output power level of the Downlink in dBm	Enter the value into the blank field	28.0 dBm
Channel Bandwidth	The available options are 3500 and 7500 kHz	Click the drop-down menu arrow and select the bandwidth	7000000 kHz
Frame Duration	The combined Downlink and Uplink frame length in milliseconds	Click the drop-down menu arrow and select the duration	10.0 ms
Cyclic Prefix	The redundant symbol percentage used to counteract inter-symbol interference	Click the drop-down menu arrow and select the prefix	1/4
Uplink Target Receive Level	This is the Uplink Rx level which all Subscriber Stations will strive to meet in dB	Enter the value into the blank field	0 dB
Downlink Allocation	This is the percentage of the TDD frame that is dedicated to Downlink data	Click the drop down arrow for the Fixed Downlink Allocation and select the value for the location	50%
Downlink/Uplink Modulation	This is the modulation scheme used for the DL and UL	Click the drop-down arrow and select the value for the modulation	Adaptive
RF Output Enable	This enables or disables the transmitter	Click the drop-down arrow and select the output	Enabled

- Step 2** Once you have made the correct configuration settings, click the **Submit** button at the bottom of the window.
- Step 3** To apply the Radio Configuration, click **Apply Configuration** from the menu options. The configuration area displays a list of changes made. Click **Yes** to apply the changes.
- Step 4** To save configuration changes to the radio, click **Reboot** from the menu options. The configuration screen displays the following:



VistaMAX - OBR3650HP+ - v5.1.456

Are you sure you want to apply the New Configuration listed below?

Apply Configuration

	Current Configuration:	New Configuration:
* Cyclic Prefix	1/4	1/8
* Channel Bandwidth:	3500 kHz	7000 kHz
TX PWR:	20.0 dBm	-10.0 dBm
* GPS Status:	Disabled	Enabled
* Indicates Setting Requires Reboot		

Click Yes to apply the New Configuration, or No to not apply them.

Click **Yes** to confirm the reboot.

3.5.1 Setting the VistaMAX OBR3650HP Transmit Power for FCC Limits



CAUTION

The VistaMAX OBR3650 radio and antenna should be installed only by experienced installation professionals who are familiar with FCC EIRP limits, local building and safety codes and, wherever applicable, are licensed by the appropriate government regulatory authorities. Failure to do so may void Vecima's product warranty and may expose the end user or the service provider to legal and financial liabilities. Vecima and its resellers or distributors are not liable for injury, damage or violation of regulations associated with the installation of outdoor units or antennas.



CAUTION

The device cannot be sold as a retail item to the general public or by mail order. It must only be sold to dealers.

FCC EIRP Limits

- The allowed EIRP for 3.5MHz bandwidth is 3.5watts or 35.44dBm
- The allowed EIRP for 7.0MHz bandwidth is 7.0watts or 38.45dBm



NOTE

Vecima has provided head room in the OBR transmitter to allow the professional installer to use different RF cable types and lengths.

Installation Scenarios

The following procedures describe how an installer would set the transmit power level for a 3.65 MHz OBR base station using either a 12 dBi 120-deg Sector or an 11dBi Omni antenna.

Required equipment for installation:

- One VistaMax 3.65 OBR base station, mounting accessories, and PoE surge suppressors
- One 5-ft Huber + Suhner - Sucofeed 1/2" cable or equivalent.
- Five OSR3500C subscriber stations
- One 12dBi 120-deg Sector or 11dBi Omni antenna – optional at time of purchase.

Setting Transmit Power When Using a 12dBi 120-deg Sector Antenna




Figure 3-3 Gains and losses in the RF chain for the calculated EIRP of 38.0dBm





Figure 3-4 Gains and losses in the RF chain for the calculated EIRP of 35.0dBm

To adjust the power for 7.0MHz bandwidth:

1. Enter the new power setting in the field to the right of **Transmit Power**. In this scenario, 26.5dBm will result in the correct transmit power.

Note: The transmit power can be adjusted by 0.5dB increments.

VistaMAX - OBR3650HP+ - v5.1.456




General Radio Configuration		
GPS Status:	Disabled	
Fixed Downlink Allocation:	50 % / 50 %	
Downlink/Uplink Center Frequency:	3650000 kHz	
Frame Duration:	5 ms	
Cyclic Prefix:	1/8	
Channel Bandwidth:	7000 kHz	
Transmit Power:	27.0 dBm	26.5
Transmit Antenna Gain:	12 dBi	
Transmit Feed Loss:	0 dB	
Uplink Target Receive Level:	-5 dB	
Pilot Fix:	True	
Data Encryption:	OFF	

Submit

2. Click **Submit**. The main menu changes to indicate that a new configuration is ready to be applied.
3. Click **Apply Configuration** and click **Yes** to apply the changes to the configuration. The window changes to offer a reboot option.

VistaMAX - OBR3650HP+ - v5.1.456



Are you sure you want to apply the New Configuration listed below?


Apply Configuration	
Current Configuration:	New Configuration:
TX PWR: 27.0 dBm	26.5 dBm
* Indicates Setting Requires Reboot	

Click Yes to apply the New Configuration, or No to not apply them.

Yes No

4. Click **Reboot**. The OBR3650 will reboot and restart with the new configuration.
5. Confirm the new transmit power by clicking **Configuration>Initial Setup>Radio Configuration**.

VistaMAX - OBR3650HP+ - v5.1.456



General Radio Configuration		
GPS Status:	Disabled	
Fixed Downlink Allocation:	50 % / 50 %	
Downlink/Uplink Center Frequency:	3650000 kHz	
Frame Duration:	5 ms	
Cyclic Prefix:	1/8	
Channel Bandwidth:	7000 kHz	
Transmit Power:	26.5 dBm	
Transmit Antenna Gain:	12 dBi	
Transmit Feed Loss:	0 dB	
Uplink Target Receive Level:	-5 dB	
Pilot Fix:	True	
Data Encryption:	OFF	


Submit

To adjust the power for 3.5MHz bandwidth:

1. Enter the new power setting in the field to the right of **Transmit Power**. In this scenario, 23.5dBm will result in the correct transmit power.


Note: The transmit power can be adjusted by 0.5dB increments.

2. Click **Submit**. The main menu changes to indicate that a new configuration is ready to be applied.



General Radio Configuration		
GPS Status:	Disabled	<input type="button" value="v"/>
Fixed Downlink Allocation:	50 % / 50 %	<input type="button" value="v"/>
Downlink/Uplink Center Frequency:	3650000 kHz	<input type="text"/>
Frame Duration:	5 ms	<input type="button" value="v"/>
Cyclic Prefix:	1/8	<input type="button" value="v"/>
Channel Bandwidth:	3500 kHz	<input type="button" value="v"/>
Transmit Power:	27.0 dBm	<input type="text" value="23.5"/>
Transmit Antenna Gain:	12 dBi	<input type="text"/>
Transmit Feed Loss:	0 dB	<input type="text"/>
Uplink Target Receive Level:	-5 dB	<input type="button" value="v"/>
Pilot Fix:	True	<input type="button" value="v"/>
Data Encryption:	OFF	<input type="button" value="v"/>

3. Click **Apply Configuration** and click **Yes** to apply the changes to the configuration. The window changes to offer a reboot option.




Are you sure you want to apply the New Configuration listed below?

Apply Configuration	
	Current Configuration:
TX PWR:	27.0 dBm
* Indicates Setting Requires Reboot	

Click Yes to apply the New Configuration, or No to not apply them.

4. Click **Reboot**. The OBR3650 will reboot and restart with the new configuration.
5. Confirm the new transmit power by clicking **Configuration>Initial Setup>Radio Configuration**.



General Radio Configuration		
GPS Status:	Disabled	<input type="button" value="v"/>
Fixed Downlink Allocation:	50 % / 50 %	<input type="button" value="v"/>
Downlink/Uplink Center Frequency:	3650000 kHz	<input type="text"/>
Frame Duration:	5 ms	<input type="button" value="v"/>
Cyclic Prefix:	1/8	<input type="button" value="v"/>
Channel Bandwidth:	3500 kHz	<input type="button" value="v"/>
Transmit Power:	23.5 dBm	<input type="text"/>
Transmit Antenna Gain:	12 dBi	<input type="text"/>
Transmit Feed Loss:	0 dB	<input type="text"/>
Uplink Target Receive Level:	-5 dB	<input type="button" value="v"/>
Pilot Fix:	True	<input type="button" value="v"/>
Data Encryption:	OFF	<input type="button" value="v"/>

Setting Transmit Power When Using an 11dBi Omni Antenna:

Since the Omni antenna is 1dB lower in gain, the transmit power of the OBR can be increased by 1dB.

The maximum transmit power of the OBR can be used when using the 11dBi Omni antenna. If a shorter RF cable is used, then the transmit power will need to be adjusted down.




Figure 3-5 Gains and losses in the RF chain for the calculated EIRP of 37.5dBm





Figure 3-6 Gains and losses in the RF chain for the calculated EIRP of 34.5dBm

To adjust the power for 7.0MHz bandwidth:

1. Enter the new power setting in the field to the right of **Transmit Power**. In this scenario, 27dBm will result in the correct transmit power.

Note: The transmit power can be adjusted by 0.5dB increments.



VistaMAX - OBR3650HP+ - v5.1.456

Base Station
 Apply Configuration
 Show Logs
 Configuration
 Initial Setup
 Network Configuration
 Initial Configuration
 Radio Configuration
 SNMP Configuration
 Max CPE Configuration
 Service Flows
 Allowed MAC Addresses
 VLAN Configuration
 Status
 System Tools


© 2009 Vecima Networks Inc.

General Radio Configuration

GPS Status:	Disabled	
Fixed Downlink Allocation:	50 % / 50 %	
Downlink/Uplink Center Frequency:	3650000 kHz	
Frame Duration:	5 ms	
Cyclic Prefix:	1/8	
Channel Bandwidth:	7000 kHz	
Transmit Power:	23.0 dBm	27
Transmit Antenna Gain:	11 dBi	
Transmit Feed Loss:	0 dB	
Uplink Target Receive Level:	-5 dB	
Pilot Fix:	True	
Data Encryption:	OFF	

Submit

2. Click **Submit**. The main menu changes to indicate that a new configuration is ready to be applied.
3. Click **Apply Configuration** and click **Yes** to apply the changes to the configuration. The window changes to offer a reboot option.



VistaMAX - OBR3650HP+ - v5.1.456

Base Station
 Apply Configuration **New!**
 Show Logs
 Configuration
 Initial Setup
 Network Configuration
 Initial Configuration
 Radio Configuration
 SNMP Configuration
 Max CPE Configuration
 Service Flows
 Allowed MAC Addresses
 VLAN Configuration
 Status
 System Tools

© 2009 Vecima Networks Inc.

Are you sure you want to apply the New Configuration listed below?

Apply Configuration


	Current Configuration:	New Configuration:
TX PWR:	24.5 dBm	27.0 dBm

* Indicates Setting Requires Reboot

Click Yes to apply the New Configuration, or No to not apply them.

Yes No

4. Click **Reboot**. The OBR3650 will reboot and restart with the new configuration.
5. Confirm the new transmit power by clicking **Configuration>Initial Setup>Radio Configuration**.



VistaMAX - OBR3650HP+ - v5.1.456

Base Station
 Apply Configuration
 Show Logs
 Configuration
 Initial Setup
 Network Configuration
 Initial Configuration
 Radio Configuration
 SNMP Configuration
 Max CPE Configuration
 Service Flows
 Allowed MAC Addresses
 VLAN Configuration
 Status
 System Tools

© 2009 Vecima Networks Inc.

General Radio Configuration

GPS Status:	Disabled	
Fixed Downlink Allocation:	50 % / 50 %	
Downlink/Uplink Center Frequency:	3650000 kHz	
Frame Duration:	5 ms	
Cyclic Prefix:	1/8	
Channel Bandwidth:	7000 kHz	
Transmit Power:	23.0 dBm	27.0 dBm
Transmit Antenna Gain:	11 dBi	
Transmit Feed Loss:	0 dB	
Uplink Target Receive Level:	-5 dB	
Pilot Fix:	True	
Data Encryption:	OFF	


Submit

To adjust the power for 3.5MHz bandwidth:

1. Enter the new power setting in the field to the right of **Transmit Power**. In this scenario, 24dBm will result in the correct transmit power.

Note: The transmit power can be adjusted by 0.5dB increments.

VistaMAX - OBR3650HP+ - v5.1.456




General Radio Configuration		
GPS Status:	Disabled	
Fixed Downlink Allocation:	50 % / 50 %	
Downlink/Uplink Center Frequency:	3650000 kHz	
Frame Duration:	5 ms	
Cyclic Prefix:	1/8	
Channel Bandwidth:	7000 kHz	
Transmit Power:	26.5 dBm	24
Transmit Antenna Gain:	12 dBi	
Transmit Feed Loss:	0 dB	
Uplink Target Receive Level:	-5 dB	
Pilot Fix:	True	
Data Encryption:	OFF	

Submit

2. Click **Submit**. The main menu changes to indicate that a new configuration is ready to be applied.
3. Click **Apply Configuration** and click **Yes** to apply the changes to the configuration. The window changes to offer a reboot option.

VistaMAX - OBR3500 - v4.2.16RC3



Are you sure you want to apply the New Configuration listed below?

Apply Configuration	
	Current Configuration:
TX PWR:	26.5 dBm
	24.0 dBm


* Indicates Setting Requires Reboot

Click Yes to apply the New Configuration, or No to not apply them.

Yes No

4. Click **Reboot**. The OBR3650 will reboot and restart with the new configuration.
5. Confirm the new transmit power by clicking **Configuration>Initial Setup>Radio Configuration**.

VistaMAX - OBR3650HP+ - v5.1.456



General Radio Configuration		
GPS Status:	Disabled	
Fixed Downlink Allocation:	50 % / 50 %	
Downlink/Uplink Center Frequency:	3650000 kHz	
Frame Duration:	5 ms	
Cyclic Prefix:	1/8	
Channel Bandwidth:	7000 kHz	
Transmit Power:	26.5 dBm	24
Transmit Antenna Gain:	12 dBi	
Transmit Feed Loss:	0 dB	
Uplink Target Receive Level:	-5 dB	
Pilot Fix:	True	
Data Encryption:	OFF	

Submit

3.6 Establishing a Link

Before you can establish the link between the base station and the subscriber station(s), ensure that the equipment is set up as follows.

- The NMS, base station, subscriber station, and one or more host computers are physically connected and powered up as shown in [Figure 3-1](#).
- If you are using an outdoor base station with an integrated antenna, ensure that the base station is vertically aligned in comparison to its mounting. If you are using a non-integrated antenna, connect an external antenna.
- The base station network and radio have been configured as described in this manual.
- The subscriber station is powered up and connected to the host computers and the Downlink/Uplink frequency is set to the same frequency as the base station transmit frequency.
- Host computers should be assigned static IP addresses.



NOTE

For more information about how to set up and configure VistaMAX components, see the [Finding Related Documentation](#) on page iii section in the Preface. Documentation is available for download from the FTP site or by contacting Vecima Networks.

To establish the link between the base station and subscriber station:

-
- Step 1** Set up and configure your VistaMAX system.
- Step 2** Power up all the units.
- Step 3** The subscriber station should complete network entry and establish a link to the base station in 1-2 minutes.
-


3.7 Other Administrative Tasks

3.7.1 Upgrading the Base Station

In order to make sure that the Base Station is able to function properly, upgrades may need to be made to the system.

To upgrade the base station through the Web GUI:

Step 1 From the **System Tools** menu, click **Upgrade BS Software**. The following page displays:



VistaMAX - OBR3650HP+ - v5.1.456

Web Upgrade


Examples - tftp://ip_address/path/release.tgz
http://ip_address/path/release.tgz

File Transfer Method: Enter a path to the file:
(no spaces please)

Upgrade

Note: after clicking on 'Submit', it may take a few minutes to upload the file to the unit. A new page will open when the upload is complete and the upgrade is ready to begin...

Step 2 Choose one of the following methods to upgrade your base station.

If	Then
The upgrade file is located on a web server	<ol style="list-style-type: none"> 1) Enter the address of the web server plus the path to the file in the upgrade line. 1) Click Upgrade.
The upgrade file is located on the tftp server in the tftpboot folder.	<ol style="list-style-type: none"> 1) Type the URL and path for the certificate. For example: tftp://<ip of NMS>/<version>/<file> 2) Click Upgrade.
The upgrade file has been downloaded to your computer	<ol style="list-style-type: none"> 1) Click the Browse button at the end of the Enter Path Select the file that will be used for the upgrade.  <ol style="list-style-type: none"> 3) Click the Open button. 4) Click Upgrade.




NOTE

The Base Station upgrade might take about five minutes to complete.

To verify the upgrade:

Step 1 Click **Status > General Status**. The General Status page opens:



VistaMAX - OBR3650HP+ - v5.1.456

Uptime: 01:06:57 up 1:06, load average: 0.09, 0.13, 0.09

General Status	
Mac Address Radio Interface:	00:18:48:00:0b:4d
Mac Address Physical Interface:	00:18:48:00:0b:4c
Current Date and Time:	2011-01-25 19:06:57
MAC Uptime:	0 Days 1 Hours 6 Minutes 8 Seconds
PLL Control Voltage:	0
Current Temperature:	36 °C
PLL Status:	PLL Locked
Power Status:	0
Temperature Status:	Normal
Output RF Power Status:	Normal

Version/Serial Number Information	
Hardware Revision:	Not Available
Software Revision:	5.1.456
Board Serial Number:	867562
Radio Serial Number:	898653


Step 2 Read the **Versions/Serial Number Information** to ensure the proper version is running.

3.7.2 Adding a Virtual IP Address

The ability to define virtual addresses on the Base Station will allow you to access the Base Station from more than one domain. Set up a virtual address by adding a new IP addresses into the Base Station through the Network Configuration menu.

To add a Virtual IP Address:

Step 1 Log on to the Web-based interface and click **Configuration > Network Configuration**. The Current Interfaces table displays showing the primary (**br0**) IP address and virtual addresses (**br0:1 br0:2**, etc.) for your base station.



VistaMAX - OBR3650HP+ - v5.1.456

Current Interfaces		
Name	IP Address	Netmask
br0	192.168.229.191	255.255.0.0
lo	127.0.0.1	255.0.0.0

Add Virtual Interface Edit Default Gateway

Warning! Editing Interfaces will take effect immediately on change. This will likely result in Subscriber Station disconnection.

Step 2 Click **Add Virtual Interface**. The Add Virtual Interface page appears.


Step 3 Type the name for the new virtual interface in the **Virtual Interface Name** field. Enter an IP address for the new domain that you wish to add in the **IP Address** field and the subnet address in the **Subnet Mask** field.

Step 4 Click **Add**.

Step 5 Repeat steps 2 to 4 until you have added all the virtual addresses that you need.


3.7.3 Rebooting the system

Select **Reboot** and click **Yes** to restart the system. If you have made configuration changes, they will be in use after the system restarts.




3.7.4 Applying Configuration

Select **Apply Configuration** and click **Yes** to confirm the configuration changes.



3.7.6 Checking Base Station Logs

Select **Show Log** to display the log activity for the base station.



3.7.7 Setting Service Flow Information

The service flow is part of the Quality of Service (QoS) feature of the base station. Service flows provide the following functions:

- Service flows specify a multitude of QoS parameters including: traffic priority, sustained and reserved data rates, jitter, maximum latency, and specify security profiles.
- Service flows are setup individually for both uplink and downlink data flows.
- Service flows classify traffic based on Layer 2, 3 or 4 (Ethernet, IP, TCP/UDP/RTP) header information including items such as source and destination addresses, port numbers, 802.1Q VLAN IDs, and Ethernet or IP traffic priority levels.


Before each frame, OBR3650HP examines all of the incoming requests and grants a time to transmit for the subscriber station based on all of the active service flow parameters to guarantee QoS where required. Individual subscriber stations receive aggregate bandwidth grants from the OBR3650HP and must individually manage their own uplink bandwidth usage.

Setting up a Quality of Service framework:

- Step 1** Define a service class and set up its parameters.
- Step 2** Define a classifier template and set up its rules.
- Step 3** Create service flows and associate them with service classes and classifier templates.
- Step 4** Provision subscriber stations with service flows.

To define a service class and set up its parameters:

- 1) Click **Configuration > Service Flows > Service Class Table** to open the Service Class Table page. This page lists all the default and user defined Service Classes and shows the parameters for each one.

VistaMAX - OBR3650HP+ - v5.1.456


- Base Station
- Apply Configuration
- Show Logs
- Configuration
 - Initial Setup
 - Service Flows
 - Service Classes**
 - Classifier Templates
 - Service Flows
 - Allowed MAC Addresses
 - VLAN Configuration
- Status
- System Tools


Service Class Table

Service Class name	Schedule Type	Maximum Sustained Traffic Rate	Minimum Reserved Traffic Rate	Max Latency	Max Traffic Burst	Tolerated Jitter	Segmented Data Unit Size	Minimum Tolerated Traffic Rate	Fixed / Variable Schedule
<input type="checkbox"/> 40001 - BE: 40001	Best Effort	18000000	0	0	0	0	0	0	Variable
<input type="checkbox"/> 40002 - BE: 40002	Best Effort	10000000	0	0	0	0	0	0	Variable

Add
Delete Selected

© Apr 29 2009 Vecima Networks Inc.

2) Click **Add** to open a page displaying the Service Class (QoS). Use this page to define the service class parameters.



VistaMAX - OBR3650HP+ - v5.1.456

Switch to Advanced Mode

Set

Service Class (QOS) (Check Show SNMP Log for error messages.)

Index	40003
Service Class Name	BE: 40001
Scheduling Type	Best Effort
Maximum Sustained Traffic Rate (MSTR)	18000000 bits/second
Requested Transmission Policy	Broadcast Bandwidth Request Support Multicast Bandwidth Request Support Piggy back Request Support Fragment Data Support Payload Header Suppression (PHS) Support Segmented Data Unit (SDU) Packing Support Cyclic Redundancy Check (CRC) Support
Automatic Repeat Request (ARQ) Enabled	Disabled


© Apr 29 2009 Vecima Networks Inc.

3) Enter values in the fields and click **Set** to save the changes and return to the Service Class Table page.

Required fields:

- Index
- Service Class Name
- Maximum Sustained Traffic Rate

4) Click **Switch to Advanced Mode** to open another page where you can set more parameters.



VistaMAX - OBR3650HP+ - v5.1.456

Switch to Simple Mode

Set


Service Class (QOS) (Check Show SNMP Log for error messages.)

Index	40003
Service Class Name	BE: 40001
Scheduling Type	Best Effort
Maximum Sustained Traffic Rate (MSTR)	18000000 bits/second
Minimum Reserved Traffic Rate (MRTR)	0 bits/second
Maximum Latency	0 ms
Maximum Traffic Burst	0 bytes
Tolerated Jitter	0 ms
Fixed Length Segmented Data Unit (SDU)	Variable
Segmented Data Unit (SDU) Size	0 bytes
Minimum Reserved Tolerable Rate	0 bits/second
Requested Transmission Policy	Broadcast Bandwidth Request Support Multicast Bandwidth Request Support Piggy back Request Support Fragment Data Support Payload Header Suppression (PHS) Support Segmented Data Unit (SDU) Packing Support Cyclic Redundancy Check (CRC) Support
Automatic Repeat Request (ARQ) Enabled	Disabled

© Apr 29 2009 Vecima Networks Inc.

To define a classifier template and set up its rules.

- 1) Click **Configuration > Service Flows > Classifier Templates** to open the Classifier Template Table page. Use this page to define the classifier templates.




VistaMAX - OBR3650HP+ - v5.1.456

Classifier Template Table

Name	Priority	Description
Undefined	10	

Add Delete Selected

- 2) Click **Add** to open the Classifier Rule Entry page and set up classifier templates for later use.



VistaMAX - OBR3650HP+ - v5.1.456

Classifier Rule Entry

Name	
Priority	10
IP Type of Service (TOS) Low	
IP Type of Service (TOS) High	
IP Type of Service (TOS) Mask	
IP Protocol	
IP Source Address	
IP Source Mask	
IP Destination Address	
IP Destination Mask	
Source Port Start	
Source Port End	
Destination Port Start	
Destination Port End	
Source MAC Address	
Source MAC Mask	
Destination MAC Address	
Destination MAC Mask	
Ethernet Protocol Type	
Ethernet Protocol	
User Priority Low	
User Priority High	


- 3) Enter values in the fields and click **Set** to save the changes.

Required fields:

- Priority
- Destination Port Start
- Destination Port End

To create service flows and associate them with service classes and classifier templates.

- 1) Click **Configuration > Service Flows > Service Flows** to open a page displaying the predefined service flows. Use this page to provision subscriber stations with service flows according to their MAC addresses.



VistaMAX - OBR3650HP+ - v5.1.456

Service Flow Table: 4 (Check Show SNMP Log for error messages.)

SFID	Service Class	Classifier	Direction	Convergence SubLayer Specification
<input type="checkbox"/> 100002	40001 - BE: 40001	Undefined 65535	Downstream	802.3 Over IPV4
<input type="checkbox"/> 100003	40001 - BE: 40001		Upstream	802.3 Over IPV4
<input type="checkbox"/> 100004	40002 - BE: 40002		Upstream	802.3 Over IPV4
<input type="checkbox"/> 100005	40002 - BE: 40002		Downstream	802.3 Over IPV4

☒ New
 ☐ Existing MAC

: : : : :

View SFID:
 View MAC:

Provisioned Service Flows: 4

	MAC Address	SFID	Service Class	Classifier	Direction	Convergence SubLayer Specification
<input type="checkbox"/>	00:18:48:00:19:b4	100002	40001 - BE: 40001	100002	Downstream	802.3 Over IPV4
<input type="checkbox"/>	00:18:48:00:19:b4	100003	40001 - BE: 40001	100003	Upstream	802.3 Over IPV4
<input type="checkbox"/>	00:18:48:00:8e:7e	100004	40002 - BE: 40002	100004	Upstream	802.3 Over IPV4
<input type="checkbox"/>	00:18:48:00:8e:7e	100005	40002 - BE: 40002	100005	Downstream	802.3 Over IPV4

- 2) Click **Add**. A new page opens displaying the Add Service Flow table. Use this page to set up the service flow parameters.
- 3) Type a number in the **SFID** field to identify the service flow.
- 4) Select **UpStream** or **DownStream** from the **Direction** drop list to indicate the direction of the data to which the service flow will apply.
- 5) Select a specification from the **Convergence SubLayer Specification** drop list to indicate the protocol that the service flow uses. The default is IPv4 over Ethernet.
- 6) Select the State of the service flow: **Authorized**, **Admitted**, or **Active**.
- 7) Select a service class to include with the service flow.
- 8) Select a classifier template to include with the service flow.
- 9) Click **Add**. This saves the service flow and returns you to the Service Flow Table page where the new service flow is displayed. You can then use this service flow to provision subscriber stations.

To provision a subscriber station:


- 1) Type a MAC address in the field provided or select one from the list of that appears when you select **Existing MAC**.
- 2) Choose the service flows that you want to assign to the selected MAC address by clicking the **SFID** check boxes that correspond to the predefined service flows.
- 3) Click **Provision Selected**. The new MAC address appears in the Provisioned Service Flows table with the associated service flow.

To remove the service flow from a subscriber station:

- 1) Select a MAC Address from the Provisioned Service Flows table by selecting the corresponding check box.
- 2) Click **UnProvision Selected** to remove the provisioned service flow from the subscriber station.

3.7.8 SNMP Configuration

Select **SNMP Configurations** to define the SNMP community strings. Currently, setting the SNMP is the only way that the base station can communicate.

VistaMAX - OBR3650HP+ - v5.1.456


- Base Station
- Apply Configuration
- Show Logs
- Configuration
 - Initial Setup
 - Network Configuration
 - Initial Configuration
 - Radio Configuration
 - SNMP Configuration**
 - Max CPE Configuration
- Service Flows
- Allowed MAC Addresses
- VLAN Configuration
- Status
- System Tools


SNMP Configuration

Read Only Community:	public	
Read Write Community:	private	

© Apr 29 2009 Vecima Networks Inc.

3.7.9 Subscriber Station Modulation Table

Select **SS Modulation Table** to show the current downlink and uplink modulations for all registered SS.

VistaMAX - OBR3650HP+ - v5.1.456


- Base Station
- Apply Configuration
- Show Logs
- Configuration
 - Initial Setup
 - Service Flows
 - Allowed MAC Addresses
 - VLAN Configuration
- Status
 - BS Statistics
 - General Status
 - General Configuration
 - SS Modulation Table**
 - SS Table
 - PKM AUTH Table
 - PKM TEK Table
- System Tools


Modulation Table

MAC	DL Modulation	UL Modulation	DL RSSI Mean	DL RSSI Standard Deviation	DL CINR Mean	DL CINR Standard Deviation	UL RSSI Mean	UL RSSI Standard Deviation	UL CINR Mean	UL CINR Standard Deviation
00:18:48:00:8e:7e	64QAM 3/4	64QAM 3/4	-66 dBm	-123 dBm	27 dB	-10 dB	-73 dBm	-9 dBm	24 dB	0 dB
00:18:48:00:19:b4	64QAM 3/4	64QAM 3/4	-66 dBm	0 dBm	25 dB	0 dB	-73 dBm	-9 dBm	27 dB	1 dB

© Apr 29 2009 Vecima Networks Inc.

3.7.10 Checking Base Station Status

Select **General Status** to display the statistics of a base station.

VistaMAX - OBR3650HP+ - v5.1.456


- Base Station
- Apply Configuration
- Show Logs
- Configuration
 - Initial Setup
 - Service Flows
 - Allowed MAC Addresses
 - VLAN Configuration
- Status
 - BS Statistics
 - General Status**
 - General Configuration
 - SS Modulation Table
 - SS Table
 - PKM AUTH Table
 - PKM TEK Table
- System Tools

Uptime: 01:06:57 up 1:06, load average: 0.09, 0.13, 0.09

General Status

Mac Address Radio Interface:	00:18:48:00:0b:4d
Mac Address Physical Interface:	00:18:48:00:0b:4c
Current Date and Time:	2011-01-25 19:06:57
MAC Uptime:	0 Days 1 Hours 6 Minutes 8 Seconds
PLL Control Voltage:	0
Current Temperature:	36 °C
PLL Status:	PLL Locked
Power Status:	0
Temperature Status:	Normal
Output RF Power Status:	Normal


Version/Serial Number Information

Hardware Revision:	Not Available
Software Revision:	5.1.456
Board Serial Number:	867562
Radio Serial Number:	898653

© Apr 29 2009 Vecima Networks Inc.

3.7.11 SS Table

Select **SS Table** to display the status of subscriber stations that are connected to the base station.

VistaMAX - OBR3650HP+ - v5.1.456


- Base Station
 - Apply Configuration
 - Show Logs
 - Configuration
 - Initial Setup
 - Service Flows
 - Allowed MAC Addresses
 - VLAN Configuration
 - Status
 - BS Statistics
 - General Status
 - General Configuration
 - SS Modulation Table
 - SS Table**
 - PKM AUTH Table
 - PKM TEK Table
 - System Tools

Subscriber Station Table


Status	MAC Address	CID			IP Managed	Managed Sub- scriber Mode	ARQ	Vendor ID
		Basic	Prim- ary	Sec- ondary				
Conn- ected	00:18:48:00:8e:7e	1	257	513	Managed	UnManagedNo	No VIDs currently	
Conn- ected	00:18:48:00:19:b4	2	258	514	Managed	Managed	No	No VIDs currently

ARQ - Automatic Repeat Request Support

© Apr 29 2009 Vecima Networks Inc.

3.7.12 PKM AUTH Table

Select **PKM AUTH Table** to display Privacy and Key Management (PKM) and authentication information.

VistaMAX - OBR3650HP+ - v5.1.456


- Base Station
 - Apply Configuration
 - Show Logs
 - Configuration
 - Initial Setup
 - Service Flows
 - Allowed MAC Addresses
 - VLAN Configuration
 - Status
 - BS Statistics
 - General Status
 - General Configuration
 - SS Modulation Table
 - SS Table
 - PKM AUTH Table**
 - PKM TEK Table
 - System Tools

PKM Authentication Entry Table


More	SAID	MAC Address	Key	Old Key Expires	New Key Expires	Auth Life	Auth Info Count	Auth Req Count	Auth Resp Count	Auth Rej Error Count	Auth Invalid Count
More	1	00:18:48:00:8e:7e	1	2011-02-01 18:01:02	2011-02-08 18:01:02	13 Days, 22 Hours, 52 Minutes, 25 Seconds	1	1	0	0	0
More	2	00:18:48:00:19:b4	0	2011-02-01 18:02:00	1969-12-31 18:00:00	6 Days, 22 Hours, 53 Minutes, 23 Seconds	1	1	0	0	0

© Apr 29 2009 Vecima Networks Inc.

This page shows the Security Association ID (SAID) number for MAC Addresses and displays Private Key information for those MAC addresses.

3.7.13 PKM TEK Table

Select **PKM TEK Table** to display information about the traffic-encryption keys (TEK).

VistaMAX - OBR3650HP+ - v5.1.456


- Base Station
 - Apply Configuration
 - Show Logs
 - Configuration
 - Initial Setup
 - Service Flows
 - Allowed MAC Addresses
 - VLAN Configuration
 - Status
 - BS Statistics
 - General Status
 - General Configuration
 - SS Modulation Table
 - SS Table
 - PKM AUTH Table
 - PKM TEK Table**
 - System Tools

PKM TEK Table

More	SAID	Tek SA Type	Tek LifeTime	Key Requests	Key Replies	Key Rejects	Tek Invalids	Tek Key Sequence Number
More	1	Primary	0 Days, 12 Hours, 0 Minutes, 0 Seconds	3	0	0	0	1
More	2	Primary	0 Days, 12 Hours, 0 Minutes, 0 Seconds	2	0	0	0	1

© Apr 29 2009 Vecima Networks Inc.

This page shows the Security Association ID (SAID) number and the traffic-encryption keys (TEK) information.

This page intentionally left blank.

A1 Molex® Backshell Installation

A defect was detected with the Ethernet terminating end of the Molex®backshell packaged with the OBR3650HP. The terminating modular plug allowed the shielding wire to be improperly grounded, thus making the cable susceptible to radiated interference. Without proper grounding, the presence of interfering radiation can cause the loss of data packets between the OBR base station and the WES800.

To fix this problem, Vecima recommends reworking the termination of the Ethernet cable using the JMRJ45S-15 modular plug and properly grounding the cablefeed. The cable termination can be repaired in the field at the tower site. Once the Ethernet cable termination is repaired, the cable feed will no longer be susceptible to interfering radiation and the data will be secured.




Figure A-1 JMRJ45S-15 Modular Plug



NOTE

Other than the risk of data loss due to interfering radiation, there is no safety issues concerning the connector that came with the OBR3650HP. Where loss of data due to the radiating interference is not a concern, reworking the terminating end with the JMRJ45S-15 is only necessary as a precaution.

If using a pre-made cable assembly (such as a CAT5CABLE/OD/25, CAT5CABLE/OD/50, CAT5CABLE/OD/75 or CAT5CABLE/OD/100 from Vecima Networks), then the process described in this document is not necessary



CAUTION

Before attaching the backshell, it is highly recommended that the user read through this entire appendix to become familiar with all of the steps involved to ensure that none are missed.

A1.1 Molex® Backshell Components

Figure A-2 shows the items that make up the Molex® backshell included with the OBR3650HP. The Ethernet modular plug shown is the JMRJ45S-15 that must be substituted for the plug that comes with the package.



Figure A-2 Molex® Backshell Elements

Molex® backshell component parts:

1. Coupling ring
2. Cable seal assembly – might already be threaded to into part 3
3. Plug holder
4. Basket seal
5. JMRJ45S-15 modular plug
6. Loading sleeve
7. Retainer wedge




NOTE

The CAT5E cable is not included with the OBR3650HP. Vecima Networks strongly recommends using CAT5E, outdoor rated cable with stranded conductors (Example: CommScope ICAT5E 2002).

A1.2 Initial Placement of the Backshell


shows the steps necessary to initially place the backshell on the cable.



Step 1:


Separate the Cable Seal Assembly from the Coupling Ring (if they came threaded together in the package)

NOTE: Loosen the back end of the Cable Seal Assembly to allow cable to slide through



Step 2:

Place the Cable Seal Assembly, Coupling Ring and Plug Holder onto the cable as shown. ***It is vital that the items are placed on the cable in the correct order.***



Step 3:

After placing the Cable Seal Assembly, Coupling Ring and Plug Holder onto the cable, insert the Retainer Wedge into the Plug Holder and then slide the Basket Seal onto the Plug Holder.

Figure A-3 Placing the Molex Backshell on

A1.3 Attaching the RJ45 Connector

Assembling the JMRM45S-15 Ethernet Terminating End

Step 1 Carefully cut about 1.5 inches (approximately 4 cm) of the jacket. Be careful not to cut the foil that encases the wires. Vecima recommends that you use an exacta knife to score the length of jacket that you are removing, then use your needle-nose pliers to carefully split the jacket. If you happen to take off all the foil, simply remove more of the jacket. When complete, 0.65 inches (or 1.7 cm) of intact foil should be exposed and the wires should extend another 0.85 inches (or 2.2 cm) beyond that. See Figure Figure A-4.




Figure A-4 Stripped jacket

Step 2 Untwist the wire pairs and separate them. Fold the stranded wire back over the foil. See Figure A-5 below for a picture of wires prepared for insertion into the connector sleeve.




Figure A-5 Preparing the wires for insertion in connector sleeve

Step 3 Insert each wire through the loading sleeve in the precise order shown in Figure A-6. Ensure that the foil is closed around the wires and that the loading sleeve is pushed as far back on the cable as possible so that it is close to the foil. Be sure to insert the wires into the open end of the loading sleeve. Trim the wires so that they extend from the foil by 0.4 inches (1 cm). Figure Figure A-7 shows the completed assembly before crimping.




Figure A-6 Inserting wires in loading sleeve




Figure A-7 Cable ready for crimping

Step 4 Before installing into the connector bend back the metal strain relief along the cable length. The metal strain relief should fit just after the jacket and cover the foil.

Check the following before crimping:

- 1) The wires are in the correct order. See Figure A-6
- 2) You can see the copper ends of the wires. If the wires are not snug against the connector end, the connection will be intermittent.

After ensuring that the cable is prepared correctly, crimp the cable using a WT1144 or WT1145 crimping tool as shown in Figure A-8. The crimped cable is shown in Figure A-9.



NOTE

If no crimping tool is available, use a pair of pliers to crimp the shield to the cable. Ensure that the shield is securely attached to the cable.




Figure A-8 Crimping the cable



Figure A-9 Assembled cable terminating end



Step 5 After crimping the cable, cut a two inch piece of ZTHS.50-01 heat-shrunk protective sheath and place it over the connector and a leading piece of cable. See Figure A-10.



Figure A-10 Connector wrapped in ZTHS.50-01 sheath

A1.4 Completing the Backshell Installation

Figure A-11 shows the steps necessary to complete the installation of the backshell on the cable.



This prevents the RJ45 connector tab from locking since there is no access to push down the tab once it is inside the Coupling Ring. The Coupling Ring takes care of locking the RJ45 connector in place via its bayonet locking mechanism.




Figure A-11 Attaching the RJ45 Connector

This page intentionally left blank

B1 Installing the Antenna - Points to Consider

Improperly installed antennas will add cost, time, and frustration to your operation. Taking some time to plan a proper installation will have long term benefits.

B1.1 Planning the Installation

Consider the following points when planning an installation:

- The antenna should support proper grounding and lightning protection.

It is usually far easier to bring the coax into the building where the AC power enters the building; because this is the easiest and cheapest way to properly bond the cable entrance to the AC ground (coax is easier and cheaper to work with than #6 AWG copper). Any lightning energy coming in on the coax will be also shared and spread over to the AC ground system, and there will be no voltage differential between the two ground systems.

- The antenna should be able to send and receive a strong signal.

The simplest method is to presurvey the proposed location with an antenna and transceiver that are connected via a temporary string of coaxial cable to a power inserter. The assembly can be mounted to any pole and hand-held to determine the presence of signal using the integrated beeper.

- The antenna should support your plan for cableruns.

Cableruns that are too long might decrease the efficiency of signal transmission. Cableruns should be able to support proper grounding and surge protection. Make sure that you have determined the entire wiring route & needs before drilling holes in the structure and attaching mounting hardware.



CAUTION

To comply with RF exposure requirements, the integrated antenna or any external antenna which is connected to an OBR3650HP requires a minimum distance of 1.5 meters between it and all persons.

B1.2 Safety Considerations

Before you begin your installation, read all critical safety warnings.

- Do not put the antenna under a power line. The power line can cause interference, and also exposes the Installation to unnecessary site hazards.
- All Installations must meet building and electrical codes. Note that some municipalities have restrictions or community covenants regarding towers and antenna structures. Check first.
- Do not install the antenna in high winds or in stormy weather, particularly if lightning is present.
- Remember to assemble the antenna hardware at a safe location before climbing up to the antenna mount.
- Depending on your location, you may need two or more people to install the antenna and mount.

B1.3 Evaluating the Mounting Location

You can mount the antenna to a variety of surfaces.

- The antenna should have a clear line-of-sight to the subscriber station. Do not put the antenna where it will be blocked by people, animals or vehicles.

Consider how time and the season will affect the line-of-sight. For example, will foliage from growing trees interfere with the line-of-sight? Will wind or ice add strain to the mounting assembly?

- The simple arm supplied with the integrated antenna assembly can be mounted to the side of the house if you can locate the structural studding.

The simple arm can also be attached to brick or cinder blocks. If mounting to brick, be sure to put the anchors in the brick only, as anchors will not hold in joint mortar. If mounting to cinder blocks, use toggle bolts that go into the hollow space in the block.

- The rooftop will often be another spot to fasten to. This usually is the best location for obstruction clearance. Locating underlying truss structure can be done with stud finders, looking for nail fasteners through the fascia board, standard sounding techniques, or from the underside of the roof. To prevent the roof from leaking, you should caulk the holes with silicone sealant around the holes and at the bottom of the antenna foot where it contacts the surface. Apply the sealant before you bolt the foot down tight. Be sure to caulk all holes to prevent leaks.
- An independent radio tower can also be used, but the Installation of these towers is beyond the scope of this document, usually involving professional structural engineering. Metal towers can provide some of the best lightning protection since the large metallic structural elements will best carry lightning energy straight to ground.
- Wooden poles are NOT recommended, because the insulating properties of the wooden pole mean that a large percentage of a lightning stroke will follow the coax towards the terminal end, even when substantial grounding conductors are used. Also, wooden poles will sway in the wind putting the antenna beam in and out of alignment in high wind conditions. By the time the pole is re-guyed to minimize the sway; a properly engineered metal tower could have been installed.
- Wind considerations. The integrated antenna has been engineered to operate in 160 Km (100MPH) winds, and survive in 220 Km (135 MPH) winds, but these forces will generate several hundred Kg. of load to the supporting mast. At this point, the mounting structure needs to be very secure.
- The Installation should be accessible year round. Ice might build up in the winter or early spring time.

**TIP**

When the primary coaxial cable is placed, leave approximately 24" of coaxial cable with a 4" to 6" diameter loop where the antenna will be installed. This will allow for the required flexibility for adjustment and future servicing.