

Go to [www.vtechphones.com](http://www.vtechphones.com) to register your product for enhanced warranty support and latest VTech product news.

TR1-2013  
TR16-2013  
TR17-2013  
TR2-2013  
TR26-2013  
TR27-2013

DECT 6.0 cordless telephone



**vtech**

Abridged user's manual

## Congratulations

on purchasing your new VTech product. Before using this product, please read **important safety instructions**.

This abridged user's manual provides you with basic installation and use instructions. A limited set of features are described in abbreviated form.

Please refer to the online Complete user's manual for a full set of installation and operation instructions at [www.vtechphones.com](http://www.vtechphones.com).

Compatible with Hearing Aid T-Coil




Telephones identified with this logo have reduced noise and interference when used with most T-coil equipped hearing aids and cochlear implants. The TIA-1083 Compliant Logo is a trademark of the Telecommunications Industry Association. Used under license.




The ENERGY STAR program ([www.energystar.gov](http://www.energystar.gov)) recognizes and encourages the use of products that save energy and help protect our environment. We are proud to mark this product with the ENERGY STAR label indicating it meets the latest energy efficiency guidelines.

## What's in the box

Your product package contains the following items. Save your sales receipt and original packaging in the event warranty service is necessary.




1 set for TR1-2013/TR16-2013  
2 sets for TR2-2013/TR26-2013/TR27-2013



1 set for TR2-2013/TR26-2013/TR27-2013



## Handset overview



- Handset earpiece
- LCD display
- MENU/SELECT
  - Show the menu.
  - While in a menu, press to select an item, or save an entry or setting.
- OFF/CANCEL
  - Hang up a call.
  - Silence the ringer temporarily while the handset is ringing.
  - Press and hold to erase the missed call indicator while the phone is not in use.
  - Press to return to the previous menu; or press and hold to return to idle mode, without making changes.
- ONE#
  - Press repeatedly to show other dialing options when reviewing a caller ID log entry.
- INT
  - Press to start an intercom conversation or transfer a call (for multi-handset models only).

## 7 - Microphone

### 8 - MUTE/DELETE

- Mute the microphone during a call.
- Delete digits or characters while using the dialing keys.
- Silence the ringer temporarily while the handset is ringing.

### 9 -

- Make or answer a call using the handset speakerphone.
- During a call, press to switch between the speakerphone and the handset.

### 10 - TONE

- While you have set the dial mode to pulse and on a call, press to switch to tone dialing temporarily.

### 11 - OPEN

- Press to add a space when entering names.

### 12 - 1

- Press repeatedly to add or remove 1 in front of the caller ID log entry before dialing or saving it to the directory.
- Press and hold to set or dial your voicemail number.

### 13 - TALK/FLASH

- Make or answer a home call.
- Answer an incoming home call when you hear a call waiting alert.

### 14 - REDIAL/PAUSE

- Review the directory when the phone is not in use.
- Increase the listening volume during a call.
- Scroll up while in a menu, or in the directory, caller ID log, or redial list.
- Move the cursor to the right when entering numbers or names.


### 15 - VOLUME/VOL

- Review the caller ID log when the phone is not in use.
- Decrease the listening volume during a call.
- Scroll down while in a menu, or in the directory, caller ID log, or redial list.
- Move the cursor to the left when entering numbers or names.

### 16 - CHARGE light

- On when the handset is charging.

## Telephone base overview



### 1 - IN USE light

- Flashes when there is an incoming call, or another telephone sharing the same line is in use.
- Flashes when handsets are being deregistered.
- On when the handset is in use or being registered.
- On when the answering system is answering a call.

### 2 - FIND HANDSET

- Press to page all system handsets.

### 3 - REPEAT

- Press to repeat the playing message.
- Press twice to play the previous message.

### 4 - Charging pole

- Press to turn the answering system on or off.

### 6 - PLAY/STOP

- Press to play messages.
- Press to stop message

### 7 - VOL-

- Press to decrease the volume during message playback.
- When the phone is not in use, press to decrease the telephone base ringer volume.

### 8 - SKIP

- Press to skip to the next message.

### 9 - Message window

- Shows the number of messages, and other information of the answering system or telephone base.


### 10 - VOL+

- Press to increase the volume during message playback.
- When the phone is not in use, press to increase the telephone base ringer volume.

### 11 - DELETE

- Press to delete the playing message.
- When the phone is not in use, press twice to delete all previously reviewed messages.

## Charger overview



1 - Charging pole

## Display icons overview

	The battery icon flashes when the battery is low and needs charging.
	The battery icon animates when the battery is charging.
	The battery icon becomes solid when the battery is fully charged.
	The handset ringer is off.
	There are new voicemail received from your telephone service provider.
	The message number currently playing and total number of new/old messages recorded.
<b>ANS ON</b>	The answering system is turned on.
<b>ECO</b>	The ECO mode activates automatically to reduce power consumption when the handset is within range from the telephone base.
<b>NEW</b>	There are new caller ID log entries.

## Handset lights overview

	On when the handset speakerphone is in use.
<b>CHARGE</b>	On when the handset is charging in the telephone base or charger.

## Telephone base lights overview

<b>IN USE</b>	On when the telephone line is in use. On when the answering system is answering a call. On when you are registering a handset. Flashes quickly when there is an incoming call. Flashes when another telephone sharing the same line is in use. Flashes when you are deregistering all handsets.
<b>ANS ON/OFF</b>	On when the answering system is turned on.

## Connect


You can choose to connect the telephone base for desktop usage or wall mounting.

### NOTE


- Use only the adapters provided.
- Make sure the electrical outlets are not controlled by wall switches.
- The adapters are intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.

### TIP


- If you subscribe to digital subscriber line (DSL) high-speed Internet service through your telephone line, make sure you install a **DSL filter** (not included) between the telephone line cord and telephone wall jack. Contact your DSL service provider for more information.



## Connect the telephone base



## Connect the charger




## Mount the telephone base

The telephone comes ready for tabletop use. If you have already installed the telephone for tabletop use, unplug the telephone line cord from the telephone wall jack, and unplug the telephone base power adapter from the wall outlet before mounting your telephone on a wall. Follow the steps below to mount your telephone on a wall.


- Route the telephone line cord through the rectangular hole on the wall mount bracket. Then plug the two ends of the telephone line cord into the telephone base and the wall outlet as shown.



- Align the holes on the bracket with the standard wall plate and slide the bracket down until it clicks securely in place.



- Connect the power adapter to the telephone base and an electrical outlet not controlled by a wall switch.



## Charge the battery

Place the handset in the telephone base or the charger to charge.



Once you have installed the battery, the handset LCD display indicates the battery status (see the table below).

### NOTES

- For best performance, keep the handset in the telephone base or charger when not in use.
- The battery is fully charged after 12 hours of continuous charging.


Battery indicators	Battery status	Action
The screen is blank, or shows Put in charger and flashes.	The battery has no charge or very little charge. The handset cannot be used.	Charge without interruption (at least 30 minutes).
The screen shows Low battery and flashes.	The battery has enough charge to be used for a short time.	Charge without interruption (at least 30 minutes).
The screen shows HANDSET X.	The battery is charged.	To keep the battery charged, place it in the telephone base or charger when not in use.

## Install and charge the battery

Install the battery as shown below.

### NOTES

- Use only the adapters provided.
- If the handset will not be used for a long time, disconnect and remove the battery to prevent possible leakage.



## Before use

After you install your telephone or power returns following a power outage, the handset or telephone will prompt you to set the date and time.

### Set date and time

- Use the dialing keys (0-9) to enter the month (MM), date (DD) and year (YY). Then press **SELECT**.
- Use the dialing keys (0-9) to enter the hour (HH) and minute (MM). Then press **▼** or **▲** to choose AM or PM.
- Press **SELECT** to save.

### Check for dial tone:

Press **TALK**. If you hear a dial tone, the installation is successful.

### If you do not hear a dial tone:

- Make sure the installation procedures described above are properly done.
- It may be a wiring problem. If you have changed your telephone service to digital service from a cable company or a VoIP service provider, the telephone line may need to be rewired to allow all existing telephone jacks to work. Contact your cable/VoIP service provider for more information.

### Operating range

This cordless telephone operates with the maximum power allowed by the Federal Communications Commission (FCC). Even so, this handset and telephone base can communicate over only a certain distance which can vary with the locations of the telephone base and handset, the weather, and the layout of your home or office.

When the handset is out of range, the handset displays **Out of range or no pwr at base**.

If there is a call while the handset is out of range, it may not ring, or if it does ring, the call may not connect well when you press **TALK**. Move closer to the telephone base, and then press **TALK** to answer the call. If the handset moves out of range during a telephone conversation, there may be interference. To improve reception, move closer to the telephone base.

## Using the handset menu

- Press **MENU** when the phone is not in use.
- Press **▼** or **▲** until the screen displays the desired feature menu.
- Press **SELECT** to enter that menu.
- To return to the previous menu, press **CANCEL**.
- To return to idle mode, press and hold **CANCEL**.

## Configure your telephone

### Set language

The LCD language is preset to English. You can select English, French or Spanish to be used in all screen displays.

- Press **MENU** when the handset is not in use.
- Scroll to **Settings**, and then press **SELECT** twice.
- Scroll to choose **English**, **Français** or **Español**, and then press **SELECT**.
- Press **SELECT** again to save.

### Set date and time

- Press **MENU** when the handset is not in use.
- Scroll to **Set date/time**, and then press **SELECT**.
- Use the dialing keys (0-9) to enter the month (MM), date (DD) and year (YY). Then press **SELECT**.
- Use the dialing keys (0-9) to enter the hour (HH) and minute (MM). Then press **▼** or **▲** to choose AM or PM.
- Press **SELECT** to save.


### Temporary tone dialing

If you have pulse (rotary) service only, you can switch from pulse to tone dialing temporarily during a call.

- During a call, press **TONE**.
- Use the dialing keys to enter the relevant number. The telephone sends touch-tone signals. It automatically returns to pulse dialing mode after you end the call.

## Telephone operation

Handset control key panel:



## Make a call

- Press **TALK** or **▲**, and then dial the telephone number.

## Answer a call

- Press **TALK**, **▲**, or any dialing key.

## End a call

- Press **OFF** on the handset, or put the handset to the base or charger.

## Speakerphone

- During a call, press **▲** on the handset to switch between speakerphone and normal handset use.

## Volume

- During a call, press **▼/VOLUME/▲** on the handset to adjust the listening volume.

### NOTE

The handset earpiece volume setting and speakerphone volume setting are independent.

## Mute

The mute function allows you to hear the other party but the other party cannot hear you.

- During a call, press **MUTE** on the handset or telephone base. The screen displays **Muted**.
- Press **MUTE** again to resume the conversation. The screen displays **Microphone ON**.

## Call waiting

When you subscribe to call waiting service from your telephone service provider, you hear an alert tone if there is an incoming call while you are on another call.

- Press **FLASH** to put the current call on hold and take the new call.
- Press **FLASH** to switch back and forth between calls.

## Find handset

Use this feature to find all system handsets.

### To start paging:

- Press **FIND HANDSET** on the telephone base. All idle handsets ring and display **\*\* Paging \*\***.

### To end paging:

- Press **FIND HANDSET** again on the telephone base.

## -OR-

- Press **TALK**, **▲**, **OFF**, or any dialing key on the handset.

## -OR-

- Place the handset in the telephone base or charger.

### NOTE

Do not press and hold **FIND HANDSET** for more than four seconds. It may lead to handset deregistration.

## Join a call in progress

You can use up to two system handsets at a time on a home line call. You can buy additional expansion handsets (TROY-2013) for this telephone base. You can register up to five handsets to the telephone base.

- When a handset is on a home call, press **TALK** or **▲** on another handset to join the call.
- Press **OFF** to exit the call. The call continues until all handsets hang up.

## Transfer a call

While on an outside call, you can transfer the call from one handset to another.

- Press **MENU** on your handset during a call.
- Scroll to **Transfer**, and then press **SELECT**.
- Use the dialing keys to enter a destination handset number.
- To answer the intercom call, press **TALK**, **▲**, or any dialing key on the destination handset.

## Intercom

Use the intercom features for conversations between two devices.

- Press **INT** on your handset when not in use.
- Use the dialing keys to enter a destination handset number.
- To answer the intercom call, press **TALK**, **▲**, or any dialing key on the destination handset.
- To end the intercom call, press **OFF** or place the handset back in the telephone base or charger.

## Transfer a call using intercom

While on an outside call, you can use the intercom feature to transfer the call from one handset to another.

- Press **INT** on your handset during a call.
- The current call is put on hold. Use the dialing keys to enter a destination handset number.

## 3.

To answer the intercom call, press **TALK**, **▲**, or any dialing key on the destination handset. You can now have a private conversation before transferring the call.

- From this intercom call, you have the following options:

- You can let the destination handset join you on the outside call in a three-way conversation. Press and hold **INT** on the originating handset.
- You can transfer the call. Press **OFF**, or place your handset back in the telephone base or charger. Your handset displays **Transferred**. The destination handset is then connected to the outside call.
- You can press **INT** to switch between the outside call (**Outside call** displays) and the intercom call (**Intercom** displays).
- The destination handset can end the intercom call by pressing **OFF**, or by placing the handset back in the telephone base or charger. The outside call continues with the original system handset.

## Answer an incoming call during an intercom call

If you receive an incoming call during an intercom call, there is an alert tone.

- To answer a call, press **TALK**. The intercom call ends automatically.
- To end the intercom call without answering the outside call, press **OFF**. The intercom call ends and the telephone continues to ring.

## Redial list

Each handset stores the last 10 telephone numbers dialed. When there are already 10 entries, the oldest entry is deleted to make room for the new entry.

## Review the redial list

- Press **REDIAL** when the handset is not in use.
- Press **▼**, **▲**, or **REDIAL** repeatedly until the desired entry displays.

## Dial a redial list entry

- Press **TALK** or **▲** to

- Press **SELECT** twice. The screen displays **Reassign SD**.
- Press **SELECT**. The screen displays **Copy from DIR...** and then the first entry of the directory.
- Scroll to browse to the desired entry.
  - OR-**Use the alphabetical search to find the desired entry.
- Press **SELECT** to save. You hear a confirmation. The name (up to 12 characters) appears in the selected speed dial location.

#### Dial a speed dial number

- Press and hold a dialing key (0 or 2-9) to dial the number stored in the corresponding speed dial location.

When the speed dial location is empty, the screen displays the speed dial list. See **Assign a speed dial entry** to add a new entry.

#### Delete a speed dial entry

- Press **MENU** when the phone is not in use.
- Scroll to **Directory**, then press **SELECT**.
- Scroll to **Speed dial**, then press **SELECT**.
- Press ▼ or ▲, or use the dialing keys to choose the desired speed dial location, then press **DELETE**. The screen displays **Clear SD #X?**
- Press **SELECT** to confirm. You hear a confirmation tone.

NOTE

Deleting the speed dial entries does not affect the entries in the directory.

### Caller ID

If you subscribe to caller ID service, information about each caller appears after the first or second ring. If you answer a call before the caller information appears on the screen, it will not be saved in the caller ID log.

The caller ID log stores up to 50 entries. Each entry has up to 24 digits for the phone number and 15 characters for the name.

If the telephone number has more than 15 digits, only the last 15 digits appear. If the name has more than 15 characters, only the first 15 characters are shown and saved in the caller ID log.

#### Review a caller ID log entry

- Press **CID** when the phone is not in use.
- Scroll to browse through the caller ID log. When the desired entry appears:
  - Press **#** repeatedly to show different dialing options.
  - Press **1** repeatedly if you need to add or remove 1 in front of the phone number.
  - Press ↶ or ↷ to dial the displayed number.

#### Dial a caller ID log entry

- When the desired entry appears, press ↶ or ↷ to dial.

#### Save a caller ID log entry to the directory

- When the desired caller ID log entry displays, press **SELECT**.
- Scroll to **To Directory** then press **SELECT**.
- Use the dialing keys to modify the number, and then press **SELECT**.
- Use the dialing keys to modify the name, and then press **SELECT** to save.

#### Delete a caller ID log entry

- When the desired caller ID log entry displays, press **DELETE**.

#### Delete all caller ID log entries

- Press **MENU** when the phone is not in use. Scroll to **Caller ID log** and then press **SELECT**. Scroll to **Del all calls** and then press **SELECT** twice.

### Sound settings

#### Key tone

You can choose from different ringer tones.

- Press **MENU** when the handset is not in use.
- Scroll to **Settings**, and then press **SELECT**.
- Scroll to choose **Key tone**, and then press **SELECT**.
- Scroll to choose **On** or **Off**, and then press **SELECT** to save.

#### Ringer tone

You can choose from different ringer tones.

- Press **MENU** when the handset is not in use.
- Scroll to **Ringers**, and then press **SELECT**.
- Scroll to choose **Ringer tone**, and then press **SELECT**.
- Scroll to sample each ringer tone, and then press **SELECT** to save.

NOTE

If you turn off the ringer volume, you will not hear ringer tone samples.

#### Ringer volume

You can adjust the ringer volume level, or turn the ringer off.

- Press **MENU** when the handset is not in use.
- Scroll to **Ringers**, and then press **SELECT**.
- Scroll to choose **Ringer volume** or **Cell volume**, and then press **SELECT**.
- Scroll to adjust the volume, and then press **SELECT** to save.

NOTE

If the handset ringer volume is set to off, that handset is silenced for all incoming calls except paging tone.

#### Ringer volume (telephone base)

You can adjust the telephone base volume level by pressing ▼**VOL-** or ▲**VOL+** on the top of the telephone base when idle.

#### Temporary ringer silencing

When the telephone is ringing, you can temporarily silence the ringer of the handset without disconnecting the call. The next call rings normally at the preset volume.

- Press **OFF** or **MUTE** on the handset. The handset displays ⏸ and **Ringer muted** briefly.

#### Quiet mode

You can turn on the quiet mode for a period of time. During this period, all tones (except paging tone) and call screening are muted. When you turn on the quiet mode, the answering system turns on automatically.


- Press and hold ⏏ **#** on the handset or telephone base when idle.
- Use the dialing keys (0-9) to enter the duration, and then press **SELECT** to save.
- To turn off the quiet mode, press and hold ⏏ **#** on the handset or telephone base when idle.

### About answering system and voicemail service

For message recording, your telephone has a built-in answering system, and it also support voicemail service offered by your telephone service provider (subscription is required, and fee may apply).

The main differences between them are as follows:

Category	Built-in answering system	Voicemail from telephone service
Storage	Messages are stored in the telephone base.	Messages are stored in a server or system provided by your telephone service.
	Your messages will not be deleted automatically. You have to delete your messages manually.	Your messages may be automatically deleted after a period of time. Contact your telephone service provider for more details.
Method to retrieve messages	When you received new messages, handset displays <b>XX new messages</b> and the message window on the telephone base flashes.	When you received new messages, the handset displays <span>✉</span> and <b>New voicemail</b> .
	To retrieve messages, usually there are two ways: <ul style="list-style-type: none"><li>Press a button on the telephone base; or</li> <li>Access remotely with an access code.</li></ul>	To retrieve messages, you need an access number and/or a password provided by your telephone service provider.



### Set your built-in answering system

Your answering system has various features, read below for the basic settings.

The answering system can record and store up to 99 messages. Each message can be up to three minutes in length. The total storage capacity for the announcement, messages and memos is approximately 14 minutes. The actual recording time depends on individual message characteristics.

Your answering system allows you to set your announcement, to save and delete messages, activate call screening, to set number of rings before pick up, to access remotely, and to control the recording time.

#### Turn the answering system on or off

The answering system must be turned on to answer and record messages.

#### To turn on or off with the telephone base:

- Press ⏏**ANS ON** on the telephone base to turn the built-in answering system on or off.

#### To turn on or off with the handset:

- Press **MENU** when the phone is not in use.
- Scroll to highlight **Answering sys**, and then press **SELECT**.
- Scroll to highlight **Answer on/off**, and then press **SELECT**.
- Scroll to highlight **Answer: On** or **Answer: Off**, and then press **SELECT** to save. You hear a confirmation tone.

#### Default announcement

The telephone is preset with a greeting that answers calls with "Hello, please leave a message after the tone." You can use this preset announcement, or replace it with your own.

#### Record your own announcement

The announcement can be up to 90 seconds in length.

- Press **MENU** when the phone is not in use.
- Scroll to **Answering sys** and then press **SELECT** twice.
- The handset displays **Play [2] Del [3] Rec [7]**, and it announces, *"To play, press 2. To record, press 7."*
- Press **7** to record. The handset announces, *"Record after the tone. Press STOP when you are done."* After the tone, speak towards the handset microphone. Then, press 5 when done.

#### Play the announcement

- Press **MENU** when the phone is not in use.
- Scroll to **Answering sys** and then press **SELECT** twice.
- The handset displays **Play [2] Del [3] Rec [7]**, and it announces, *"To play, press 2. To record, press 7."*
- Press **2** to record. The handset announces, *"Record after the tone. Press STOP when you are done."* Then, press 2 to play the announcement.

#### Delete the announcement

- Press **MENU** when the phone is not in use.
- Scroll to **Answering sys** and then press **SELECT** twice.
- The handset displays **Play [2] Del [3] Rec [7]**, and it announces, *"To play, press 2. To record, press 7."*
- Press **3** to delete your own recorded announcement.

#### Set number of rings

You can set the answering system to answer an incoming call after 2, 3, 4, 5 or 6 rings; or toll saver. If you choose toll saver, the answering system answers a call after 2 rings when you have new messages, or after 4 rings when you have no new messages.

- Press **MENU** when the phone is not in use.
- Scroll to **Answering sys** then press **SELECT**.
- Scroll to **Ans sys setup** then press **SELECT**.
- Scroll to **# of rings** then press **SELECT**.
- Scroll to choose **2**, **3**, **4**, **5**, **6** or **Toll saver**.
- Press **SELECT** to save and you hear a confirmation tone.

#### Message alert tone

When the message alert tone is set to on, and there is at least one new message, the telephone base beeps every 10 seconds. The message alert tone is preset to off.

- Press **MENU** when the phone is not in use.
- Scroll to **Answering sys** then press **SELECT**.
- Scroll to **Ans sys setup** then press **SELECT**.
- Scroll to **Msg alert tone** then press **SELECT**.
- Scroll to choose **Tone: On** or **Tone: Off**.
- Press **SELECT** to save and you hear a confirmation tone.

#### Recording time

You can set the recording time limit for each incoming message.

- Press **MENU** when the phone is not in use.
- Scroll to **Answering sys** then press **SELECT**.
- Scroll to **Ans sys setup** then press **SELECT**.
- Scroll to **Recording time** then press **SELECT**.
- Scroll to choose **3 minutes**, **2 minutes** or **1 minute**.
- Press **SELECT** to save and you hear a confirmation tone.

### Use your built-in answering system

#### New message indication

When there are new answering system messages, The handset displays **XX new messages** and the message window on the telephone base flashes.

#### Message playback

- To playback messages at the telephone base:**
  - Press ▶/**▶****PLAY** when the phone is not in use.

#### Options during playback:

- Press ▼**VOL-** or ▲**VOL+** to adjust the speaker volume.
- Press ⏏/**SKIP** to skip to the next message.
- Press ⏏/**REPEAT** to repeat the message currently playing. Press ⏏/**REPEAT** twice to listen to the previous message.
- Press **X/DELETE** to delete the playing message. The system advances to the next message.
- Press ▶/**▶**/**STOP** to stop.

#### To playback messages at the handset:

- Press **MENU** to choose **Play messages**. Press **SELECT**.

#### Options during playback:

- Press ▶/**VOLUME/▲** to adjust the message playback volume.
- Press ⏏ to skip to the next message.
- Press 6 to skip to the next message. Press 4 during the time and day announcement to hear the previous message.
- Press 3 to delete the playing message.
- Press **OFF** to stop the playback.
- Press ⏏ to switch between speakerphone mode and handset mode.

#### Delete all old messages at the telephone base

**To delete all old messages at the telephone base:**

Press **X/DELETE** twice when the phone is not in use.

#### To delete all old messages on a handset:

- Press **MENU** when the phone is not in use.
- Scroll to **Answering sys**, and then press **SELECT**.
- Scroll to **Delete all old**, and then press **SELECT** twice. You hear a confirmation tone.

#### Remote access

A two-digit security code is required to access the answering system remotely from any touch-tone telephone. The preset code is **19**. You can use this preset code, or set your own.

- Dial your telephone number from any touch-tone telephone.
- When the system plays your announcement, enter the two-digit security code.
- You can enter one of the following remote commands.

Command	Description
<b>1</b>	Play all messages.
<b>2</b>	Play new messages.
<b>3</b>	Delete the current message (during playback).
<b>33</b>	Delete all old messages.
<b>4</b>	Repeat the current message (during playback).
<b>5</b>	Stop.
<b>*5</b>	Hear a list of remote commands.
<b>6</b>	Skip to the next message (during playback).
<b>*7</b>	Record a new announcement.
<b>8</b>	End the call.
<b>0</b>	Turn the answering system on or off.

- Hang up or press **8** to end the call.

#### Remote access code

A two-digit security code is required to access the answering system remotely from any touch-tone telephone. The preset code is **19**. You can set the code from **00** to **99**.

- Press **MENU** when the phone is not in use.
- Scroll to **Answering sys** then press **SELECT**.
- Scroll to **Ans sys setup** then press **SELECT**.
- Scroll to **Remote code**, and then press **SELECT**.
- Use the dialing keys to enter a two-digit number.
  - OR-**Scroll to a desired two-digit number.
- Press **SELECT** to save and you hear a confirmation tone.

### Use the built-in answering system and voicemail service

You can use your answering system and voicemail service together by setting your answering system to answer before voicemail service answers as described below. To learn how to program your voicemail settings, contact your telephone service provider.

If you are on a call, or if the answering system is busy recording a message and you receive another call, the second caller can leave a voicemail message.

Set your answering system to answer calls at least two rings earlier than your voicemail service is set to answer. For example, if your voicemail service answers after six rings, set your answering system to answer after four rings. Some voicemail service providers may program the delay before answering calls in seconds instead of rings. In this case, allow six seconds per ring when determining the appropriate setting.

When first purchased and properly charged, each expansion handset shows **To register HS...** and **...see manual** alternately. Charge the handset before registering it to the telephone base.

#### To register a handset:

- Place the new or non-registered handset in the telephone base. After about 10 seconds, the handset shows **Registering...**



Do not place the handset in the charger.

The handset shows **Registered** and you hear a beep when the registration process completes. The registration process takes about 90 seconds to complete.

#### Deregister all devices

To replace a handset or reassign the designated handset number of a registered handset, you must deregister all handsets and then individually register each handset.

#### To deregister all handsets:

- Press and hold ⏏/**FIND HANDESET** on the telephone base for about 10 seconds until the **IN USE** light on the telephone base flashes.
- Immediately press ⏏/**FIND HANDESET** again.

All handsets show **To register HS...** and **...see manual** alternately when the deregistration process completes. The deregistration process takes about 10 seconds to complete.

### ECO mode

This power conserving technology reduces power consumption for optimal battery performance. The ECO mode activates automatically whenever the handset is synchronized with the telephone base.

### General product care

#### Taking care of your telephone

Your cordless telephone contains sophisticated electronic parts, so it must be treated with care.

#### Avoid rough treatment

Place the handset down gently. Save the original packing materials to protect your telephone if you ever need to ship it.

#### Avoid water

Your telephone can be damaged if it gets wet. Do not use the handset outdoors in the rain, or handle it with wet hands. Do not install the telephone base near a sink, bathtub or shower.

#### Electrical storms

Electrical storms can sometimes cause power surges harmful to electronic equipment. For your own safety, take caution when using electrical appliances during storms.

#### Cleaning your telephone

Your telephone has a durable plastic casing that should retain its luster for many years. Clean it only with a dry non-abrasive cloth. Do not use dampened cloth or cleaning solvents of any kind.

## Frequently asked questions

Below are the questions most frequently asked about the cordless telephone. If you cannot find the answer to your question, visit our website at **www.vtechphones.com** or call **1 (800) 595-9511** for customer service. In Canada, go to **www.vtechcanada.com** or call **1 (800) 267-7377**.

My telephone does not work at all.	Make sure the telephone base is installed properly, and battery is installed and charged correctly. For optimum daily performance, return the handset to the telephone base after use.
The display shows <b>No line</b> . I cannot hear the dial tone.	Disconnect the telephone line cord from your telephone and connect it to another telephone. If there is no dial tone on that other telephone either, then the telephone line cord may be defective. Try installing a new telephone line cord. If changing telephone line cord does not help, the wall jack (or the wiring to this wall jack) may be defective. Contact your telephone service provider.
You may be using a new cable or VoIP service, the existing telephone jacks in your home may no longer work. Contact your service provider for solutions.	
The answering system does not record messages.	Make sure the answering system is on. When the answering system is on, <b>ANS ON</b> should display on the handset and the telephone base.
	When the answering machine memory is full, it does not record new messages until some old messages are deleted.
	If you subscribe to voicemail service, change the number of rings so that your answering system answers before your voicemail service answers. To determine how many rings activate your voicemail service, contact your telephone service provider.

The answering system does not announce the correct day of the week for recorded messages time stamp.	Make sure you have set the date and time. See <b>Configure your telephone</b> section.
The messages on the answering system are incomplete.	If a caller leaves a very long message, part of it may be lost when the answering system disconnects the call after the preset recording time. <p>If the memory on the answering system becomes full during a message, the answering system stops recording and disconnects the call.</p>
I accidentally set my LCD language to Spanish or French, and I don't know how to change it back to English.	While the handset is not in use, press <b>MENU</b> and then enter <b>*364#</b> to change the handset LCD language back to English.

### Limited warranty

#### What does this limited warranty cover?

The manufacturer of this VTech Product warrants to the holder of a valid proof of purchase ("Consumer" or "you") that the Product and all accessories provided in the sales package ("Product") are free from defects in material and workmanship, pursuant to the following terms and conditions, when installed and used normally and in accordance with the Product operating instructions. This limited warranty extends only to the Consumer for Products purchased and used in the United States of America and Canada.

**What will VTech do if the Product is not free from defects in materials and workmanship during the limited warranty period ("Materially Defective Product")?**

During the limited warranty period, VTech's authorized service representative will repair or replace at VTech's option, without charge, a Materially Defective Product. If we repair the Product, we may use new or refurbished replacement parts. If we choose to replace the Product, we may replace it with a new or refurbished Product of the same or similar design. We will retain defective parts, modules, or equipment. Repair or replacement of the Product, at VTech's option, is your exclusive remedy. VTech will return the repaired or replacement Products to you in working condition. You should expect the repair or replacement to take approximately 30 days.

#### What must you return with the Product to get warranty service?

- Return the entire original package and contents including the Product to the VTech service location along with a description of the malfunction or difficulty; and
- Include a "valid proof of purchase" (sales receipt) identifying the Product purchased (Product model) and the date of purchase or receipt; and
- Provide your name, complete and correct mailing address, and telephone number.

#### Other limitations

This warranty is the complete and exclusive agreement between you and VTech. It supersedes all other written or oral communications related to this Product. VTech provides no other warranties for this Product. The warranty exclusively describes all of VTech's responsibilities regarding the Product. There are no other express warranties. No one is authorized to make modifications to this limited warranty and you should not rely on any such modification. State/Provincial Law Rights: This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state or province to province. Limitations: Implied warranties, including those of fitness for a particular purpose and merchantability (an unwritten warranty that the Product is fit for ordinary use) are limited to one year from the date of purchase. Some states/provinces do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. In no event shall VTech be liable for any indirect, special, incidental, consequential, or similar damages (including, but not limited to lost profits or revenue, inability to use the Product or other associated equipment, the cost of substitute equipment, and claims by third parties) resulting from the use of this Product. Some states/provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

**Please retain your original sales receipt as proof of purchase.**

