

YAMAHA

PORTATONE

PSR-180

PSR-76

OWNER'S MANUAL

Contents

Getting Started.....	2
Playing Your New PortaTone	3
Voice Mode	5
Style Mode	6
Song Mode	9
Sound Effect and Drum Pads (PSR-180)	10
Sound Effect and Drum List	10
Troubleshooting	11
Percussion Assign List (Voices 40 and 00)	11
Jam Track Chord Progression List	12
One Touch Setting List	12
Song Scores	13
Specifications	24

Congratulations on your purchase of the Yamaha PortaTone

You now own a portable keyboard that packs advanced functions and great sound in a highly compact size. Its outstanding features also make it an exceptionally expressive and versatile instrument. Read this Owner's Manual carefully while playing your new PortaTone in order to take full advantage of its various features.

Main Features

The PortaTone is a sophisticated musical instrument with the following features and functions:

- Exceptionally realistic sounds with 100 AWM (Advanced Wave Memory) Voices, utilizing digital recordings of actual instruments.
- Dynamic, versatile rhythms and accompaniment with 100 music Styles.
- 20 Songs, for listening enjoyment or for playing along with when using the Minus One function.
- 20 Jam Track patterns, providing specially programmed rhythms and chord progressions for playing along with.
- (On the PSR-180) a set of four Pads that allow you to play drum and percussion sounds as well as special sound effects.
- One Touch Setting, for automatically calling up an appropriate Voice for playing with the Style, Song or Jam Track you select.
- High-quality amplifier/speaker system (stereo for the PSR-180).

Precautions — Taking Care of Your PortaTone

Your new PortaTone is a fine musical instrument — and should be treated as such. Handle it with care and common sense, and it will give you years of enjoyment.

Location

- Avoid exposure to direct sunlight or other sources of heat. Never leave it inside a car where it can get very hot. Also avoid highly humid or dusty places.

Interference From Electromagnetic Fields

- Do not use your PortaTone close to television sets, radios or similar equipment since this may cause interference noise in the other appliance.

Handling

- Protect your PortaTone from strong impact. Be careful not to drop it or place heavy objects on it. Avoid applying excessive force to the controls and keys.

When Not Using the PortaTone

- After use, always turn off the POWER switch. When not using your PortaTone for long periods, be sure to remove the batteries to avoid damage through battery leakage.

Cleaning

- Clean the exterior with a soft, dry cloth. To remove stubborn stains, use a slightly moistened cloth.
- Never use alcohol, thinner, or other chemical solvents, since they will damage the finish. Also, do not leave vinyl chloride material on the PortaTone for a long time, since it may adhere to the exterior.



NOTE

Yamaha is not responsible for damage caused by improper usage.

Getting Started

Power Requirements

Your PortaTone can run either on batteries (sold separately) or on normal household current by using the optional Yamaha PA-3/4/40 Power Adaptor.


Using an AC Power Adaptor

To connect your PortaTone to a wall socket, you will need the optionally available Yamaha PA-3/4/40 Power Adaptor. Use of other AC adaptors could result in damage to the instrument, so be sure to ask for the right kind. Plug the adaptor into a convenient wall outlet and its connector into the DC 10-12V IN jack on the back of your PortaTone.

Using Batteries

Inserting Batteries

Turn the instrument upside-down and remove the battery compartment lid. Insert six 1.5-volt size "D" batteries as shown in the illustration, making sure that the positive and negative terminals are properly aligned. Replace the lid.



When the Batteries Run Down

When the batteries run low and the battery voltage drops below a certain level, the PortaTone may not sound or function properly. As soon as this happens, replace them with a complete set of six new batteries. Never mix old and new or different types of batteries (e.g., alkaline and manganese).

Auto Power OFF


The PSR-180/76 features an Auto Power OFF function that automatically turns the power OFF if the instrument is not used for approximately 30 minutes. This functions whether batteries or the AC power adaptor is used.

Accessory Jacks


Using Headphones

For private practicing and playing without disturbing others, connect a set of stereo headphones to the rear panel HEADPHONES/AUX OUT jack. Sound from the built-in speaker system is automatically cut off when you insert a headphone plug into this jack.

PSR-180



PSR-76



Connecting a Keyboard Amplifier or Stereo System


After making sure the PortaTone and any external devices are turned off, connect one end of a stereo audio cable to the LINE IN or AUX. IN jack(s) of the other device and the other end to the HEADPHONES/AUX OUT jack of the PortaTone.

The Music Stand

Insert the bottom edge of the music stand into the slot located at the top rear of the PSR-180/76 control panel.

Playing Your New PortaTone

This section briefly shows you how to use the various controls on the panel of the PortaTone.



Turning on the Power

Press the POWER ON/OFF button **1** to turn on the power of the PortaTone. Whenever the power is turned on, Voice 01 (PIANO) is automatically selected.

Selecting a Mode

Your PortaTone has three different operating modes: Voice, Style and Song — each selected from the corresponding panel buttons. VOICE **2** lets you select and play a Voice. STYLE **3** lets you select and play a setting that includes a rhythm/accompaniment pattern. SONG **4** lets you select and play either a Song or a Jam Track pattern.

To select one of the modes:

Press the button corresponding to the desired mode. For now, press SONG **4** to select the Song mode.

Playing a Song in the Song Mode

A variety of Songs and special Jam Tracks have been recorded to your PortaTone to give you a taste of what you can do with the instrument, and to provide music and patterns for you to play along with.

To select and play one of the Songs:

1. With the Song mode selected, use the Numeric Keypad **5** to enter the desired Song or Jam Track number. Be sure to enter a two-digit number, as is printed next to each song on the panel. For example, to select Song 09, first press "0" on the Numeric Keypad, then "9." You can also use the +/- buttons on the Numeric Keypad to step up or down through the preset numbers; holding down the appropriate button continuously changes the number. Note that the +/- buttons have a "wrap around" feature. For example, pressing the + button from the last number returns to Song 01. (Song 01 is also automatically selected when you turn the power on.)

2. To play the selected Song, press the START/STOP button **7**.

Note that the dots in the MULTI DISPLAY **11** flash in time with the music. The left dot flashes at the first beat of every measure, and the right dot flashes at the other beats, (For more information on the MULTI DISPLAY, see box at right.)

3. Adjust the volume of the Song by using the VOLUME control **12**.

4. Although the Song is automatically set to play at a default tempo, you can change the speed of the Song by using the TEMPO buttons **9**. Press TEMPO + to increase the speed and TEMPO - to decrease it; holding down the appropriate button continuously increases/decreases the speed. (Note that the tempo value is briefly shown in the MULTI DISPLAY.)

If you want to set the tempo back to its original default setting, press both TEMPO buttons simultaneously. (For more information on the Tempo functions, see box at right.)

5. To stop the Song, press the START/STOP button **7** again.


NOTE

You should enter numbers on the Numeric Keypad relatively quickly. If you do not enter the second digit of a number within about ten seconds after entering the first digit, the first digit will be cancelled. Entry of a first digit is also automatically cancelled if any other button on the panel (except for those on the Numeric Keypad) is pressed before entering the second digit. Also, keep in mind that entry of numbers higher than 40 in the Song mode are ignored.


About the MULTI DISPLAY

As mentioned above, the dots in the MULTI DISPLAY flash in time with the rhythm, and the indication is used when a Song or Style plays back. This flashing provides a visual indication of both the tempo and the time signature of the rhythm.

For Songs and Styles in 4/4 time, the dots flash like this:



For Songs and Styles in 3/4 time, the dots flash like this:



About the Tempo Functions

Tempo Values

As mentioned above, the tempo value is shown briefly in the MULTI DISPLAY when one of the TEMPO buttons is pressed. The displayed tempo range is from 10 to 60; in actual tempo values, the range is from 40 to 240 beats per minute. (Each step in the tempo adjustment corresponds to 4 beats per minute.)

Default Tempos

Each Song and Style has been given a default or standard tempo. If you change the tempo, you can set it back to the original default setting, by pressing both TEMPO buttons simultaneously. Also, the tempo of a Song or Style returns to the default setting when selecting a different Song or Style. (The set tempo remains, however, when switching Styles during playback.) When you turn on the power of 'the PortaTone, the tempo is automatically set to the default setting of Style 01.

Voice Mode


The Voice mode features 100 authentic Voices. Many of these Voices have special preset characteristics or embellishments. The Voices are divided into various categories depending on their characteristics or the effects used.

Dual Voices (#41 - #56) feature two Voices mixed together in a layer for rich ensemble sounds. Split Voices (#57 - #67) also have two Voices, but rather than being layered, each is played from a different range of the keyboard. Sustain Voices (#68 - #72) extend the sound by adding a natural, slow release. Harmony Voices (#73 - #85) have an additional one-, two- or three-note harmony added to the original monophonic Voice. Finally, Echo Voices (#86 - #00) have an echo effect that adds delayed repeats to the original Voice.

Included in the Voices are special PERCUSSION Voices (#40 and #00) that lets you play various drum and percussion sounds from the keyboard. (Refer to the Percussion Assign List page 11.)


Selecting a Voice

1. Press the VOICE button to select the Voice mode.



2. Use the Numeric Keypad to select the desired Voice number.

Each Voice is automatically called up with the most suitable octave range setting. Thus, playing middle C with one Voice may sound higher or lower than another Voice at the same key.



3. Play the newly selected Voice. To change to another Voice, repeat step 2 above.

You can also play rhythm Styles in the Voice mode by simply pressing the START/STOP button. The Style last selected from the Style mode will be played.

About the Harmony Voices

Since Harmony Voices are designed to automatically play two or more notes with the notes you play on the keyboard, only one note can be played on the keyboard at a time. If several notes are played together, only the last note or highest note played will be heard.

The type of harmony used depends on the Voice that is selected. When a Style or Song/Jam Track is not being played back, the basic key for the harmony is always C. When a Style is played or the Stopped Accompaniment function is active, the harmony changes according to the chord played with the left hand. When a Song is played back, the harmony changes according to the chord progression of the Song or Jam Track.

NOTE

The PortaTone is polyphonic up to a maximum of 12 notes. (Depending on the Voice selected, fewer notes may be available.) This includes not only the Voices played from the keyboard, but also the notes in a Style pattern, and so on. Thus, if you play too many notes at one time, some may not sound and/or others may be cancelled.


Style Mode

The Style mode provides dynamic rhythm/accompaniment patterns — as well as Voice settings appropriate for each pattern— for various popular music styles, as listed on the panel. A total of 100 different Styles are available, and are divided into ten different categories. Each rhythm pattern also has a specially created companion Fill In pattern, which can be played by using the SYNC START/FILL IN button.


Auto Accompaniment features built into the rhythms add the excitement of instrumental backing to your performance, letting you control the accompaniment by the chords you play. Auto Accompaniment effectively splits the keyboard into two sections: The upper is used for playing a melody line, and the lower (labeled "AUTO ACCOMP. SECTION" on the keyboard, including keys C1 through F2) is for the Auto Accompaniment function.

Selecting a Style

1. Press the STYLE button to select the Style mode.



2. Use the Numeric Keypad to select the desired Style number.



3. You can start the selected rhythm by pressing the START/STOP button.

The PortaTone also has a Synchro Start function that allows you to start the rhythm by simply pressing a key on the keyboard. To use Synchro Start, first press the SYNC-START/FILL IN button, then press one of the keys in the AUTO ACCOMP. SECTION.

NOTE

Synchro Start is automatically set to stand-by when you select the Style mode. (The dots in the MULTI DISPLAY flash to indicate stand-by status.)

4. With the rhythm running, you're ready to try out the Auto Accompaniment feature. Try playing a few single notes with your left hand, and notice how the bass and chord accompaniment change with each key you play. (Refer to the boxed sections on pages 7 and 8 for more information on how to use Auto Accompaniment.)
5. Use the TEMPO buttons to change the tempo of the Style as it's playing (For more information on the Tempo functions, see page 4.)
6. While the Style is playing, you can add variation to the rhythm by playing special Fill In patterns. To play a Fill In pattern, press the SYNC START! FILL IN button.

NOTE

The Fill In pattern may not play precisely when you press the SYNC START/FILL IN button, but instead starts on the beat immediately following your press of the button. Also, depending on when you press the button, only a portion of the Fill In might be played. Both of these situations are normal and are done to ensure that the Fill In pattern complements the basic rhythm, rather than disrupting it.

7. To stop the rhythm, press the START/STOP button again,

Pressing the START/STOP button while the rhythm is playing produces a simple ending phrase. This also applies to playing Jam Track patterns in the Song mode.

Using the Auto Accompaniment Function/Multi Fingering

The Auto Accompaniment function automatically generates bass and chord accompaniment for you to play along with, by using Multi Fingering operation. You can change the chords of the accompaniment by playing keys in the AUTO ACCOMP. SECTION of the keyboard using either the "Single Finger" or "Fingered" method. With Single Finger you can simply play a one-, two- or three-finger chord indication (see Single Finger Chords below). The Fingered technique is that of conventionally playing all the notes of the chord. Whichever method you use, the PortaTone "understands" what chord you indicate and then automatically generates the accompaniment,

NOTE

Chords played in the AUTO ACCOMP. SECTION of the keyboard are also detected and played when the accompaniment is stopped (Stopped Accompaniment function). In this condition, the Voices used for the bass and chords are automatically selected.

NOTE

To use the Minus One function with one of the Styles, press the MINUS ONE button. (The LED next to the button lights.) Minus One cancels all chord accompaniment, leaving only the bass and basic rhythm of the Style.

Setting Auto Accompaniment to Single Finger or Fingered

Though detection of the Single Finger and Fingered methods is automatic, you can set Auto Accompaniment to function exclusively in either the Single Finger or Fingered mode.

To Set Auto Accompaniment to Single Finger, turn the power off, then hold down the "-" button on the Numeric Keypad and simultaneously turn the power on. "SF" (Single Finger) briefly appears in the MULTI DISPLAY.

NOTE

In Single Finger, the AUTO ACCOMP. SECTION is set between the C1 key (the lowest key) and the C#2 key.


To set Auto Accompaniment to Fingered, follow the same steps, holding down the "+" button instead.

"F" (Fingered) briefly appears in the MULTI DISPLAY.

To switch back to Multi Fingering operation, simply turn the power off and on again.

Single Finger Chords

Chords that can be produced in Single Finger operation are major, minor, seventh and minor seventh. The illustration below shows how to produce the four chord types. (The key of C is used here as an example; other keys follow the same rules. For example, B^b7 is played as B^b and A.)



Press the root note of the chord.



Press the root note together with any white key to the left of it.



Press the root note together with any black key to the left of it.




Press the root note together with any white and black key to the left of it (three keys altogether).

Fingered Chords

Using the key of C as an example, the chart below shows the types of chords that can be recognized in the Fingered mode.

Fingered Chords in the Key of C



Notes enclosed in parentheses are optional; the chords will be recognized without them.

NOTE


- If the chord is inverted (ie., C-E-G is played as G-C-E), the PortaTone will still recognize it as a C chord.
- Minor 6th chords are recognized only in root position, however; all other inversions are interpreted as minor 7th/flatted 5th.
- If augmented and diminished 7th chords are inverted, the lowest note will be recognized as the root.
- 7th flatted 5th chords may be played with the lowest note as the root or the 7th.
- 9th chords are recognized only in root position; all other inversions are interpreted as suspended 4th.
- Augmented 7th and diminished 7th chords are interpreted as simple augmented and diminished.
- The PortaTone also has a Chord Cancel function to stop the chord accompaniment but allow the rhythm pattern to continue playing. To use Chord Cancel, simultaneously press any three consecutive notes in the AUTO ACCOMP. SECTION; for example, C, C[#] and D.

One Touch Setting in the Style Mode

The One Touch Setting function automatically selects an appropriate Voice for playing with the Style you select. In other words, when One Touch Setting is on, the Voice automatically changes when you change the Style.

To turn on the One Touch Setting function, press the ONE TOUCH SETTING button. (The LED next to the button lights.)

To turn the function off, press the button again.



NOTE

When the One Touch Setting is on, selecting another Style will automatically reset the tempo to the default of the selected Style.


Song Mode

The Song mode features special Songs and Jam Track patterns that have been created using the rich sounds and sophisticated accompaniment functions of the PortaTone.


The Songs are generally for your listening enjoyment; however, you can also play along with them on the keyboard. Also, by using the Minus One function, you can “mute” the original melody and play it manually on the keyboard yourself. The Jam Track patterns in this mode let you “jam” or play along with a variety of dynamic rhythm styles and chord changes.

Selecting and Playing a Song or Jam Track Pattern

1. Press the SONG button to select the Song mode.



2. Use the Numeric Keypad to select the desired Song or Jam Track number.



3. Start the selected Song or Jam Track by pressing the START/STOP button.

You can also start the selected Song, or Jam Track pattern with the Synchro Start function (as in the Style mode) by simply pressing any key of the keyboard.

4. If you want to change to another Song or Jam Track pattern, repeat step 2 above.
5. To stop the Song or pattern, press the START/STOP button again.

If playback is not stopped, all Songs play back repeatedly in succession, indefinitely. (However, if Minus One is on, only the selected Song repeatedly plays back.) If a Jam Track pattern is selected, only the selected pattern repeats indefinitely.

About the Minus One Function


Minus One, as its name implies, takes away the melody part of the Song, allowing you to play that part yourself. You can turn Minus One on before starting a Song, or do it even while a Song is playing. To help you play the “missing” melody, scores for all Songs have been provided; see pages 13-22.

To use the Minus One function with the selected Song, press the MINUS ONE button (either before starting the Song or while it is playing). (The LED next to the button lights.)

One Touch Setting in the Song Mode

The One Touch Setting function works with the Minus One function and automatically selects an appropriate Voice for playing the melody along with the Song you select. Though the Minus One function is not used with the Jam Track patterns, One Touch Setting works the same way with JamTrack, automatically selecting an appropriate Voice.

To turn on the One Touch Setting function, press the ONE TOUCH SETTING button. (The LED next to the button lights.)




To turn the function off, press the button again.


NOTE

Keep in mind that even with the One Touch Setting function on, there are some Songs and Jam Track patterns which change the selected Voice in the middle of the Song or pattern.

Sound Effect and Drum Pads (PSR-180)



Use the button corresponding to the desired set of sounds to change the bank. Press the button repeatedly to step through the banks. The selected bank number briefly appears in the MULTI DISPLAY. For example, to select bank 3, press the button next to SOUND EFFECT repeatedly until "3" appears in the MULTI DISPLAY.



The Sound Effect and Drum Pads let you play selected drum and percussion sounds, as well as special sound effects, from the four Pads directly above the right side of the keyboard.

The Pads can be played in any of the modes. You can play them alone (for example, to try out your own rhythms), or play them along with the Styles, Songs and Jam Track patterns. Eight banks of sounds (four in each bank) are available. There are 16 Sound Effect sounds and 16 Drum sounds, and each sound is shown graphically on the panel.



NOTE

Unlike the "one-shot" Drum sounds, the Sound Effect sounds are complex sequences of sounds and once triggered, play through to their end.




NOTE

Up to two Pads ten be played simultaneously. Three or more Pads can be played successively; however, the limit on total simultaneous notes may result in cancellation of some sounds or notes played in the Voice, Style or Song mode. (Refer to the note regarding polyphony on page 5.)

When the power is turned on, bank 1 of the Sound Effect sounds is automatically selected.

Sound Effect and Drum List



Sound Effect

1. Safari	Percussion	Elephant	Lion	Monkey
2. Forest	Stream	Bird 1	Bird 2	Bird 3
3. Train	Whistle	Locomotive	Crossing Signal	Train Passing
4. Ocean	Seashore	Gull	Boat	Marine Horn


Drum

5. AccDrum1	Bass Drum 1	Snare Drum 1	Hi-hat Close	Hi-hat Open
6. AccDrum2	Crash Cymbal	Tom Low	Tom Mid	Tom High
7. SynDrum1	Synth Bass Drum	Synth Snare Drum	Synth Hi-hat Close	Synth Hi-hat Open
8. SynDrum2	Splash Cymbal	Synth Tom Low	Synth Tom Mid	Synth Tom High

Troubleshooting

Problem	Possible Cause and Solution
When the PortaTone is turned on or off, a buzzing sound is temporarily produced.	This is normal and indicates that power is flowing into the PortaTone.
The sound of the voices or rhythms seems unusual or strange.	The battery power is too low. Replace the batteries.
Not all notes are heard when playing a number of notes simultaneously.	Too many keys are pressed at the same time. The PortaTone is polyphonic up to a maximum of 12 notes. (See the note on page 5.)
The sound of the Voice changes from note to note.	The AWM tone generation method uses multiple recordings (samples) of an instrument across the range of the keyboard; thus, the actual sound of the Voice may be slightly different from note to note.
The power cannot be turned on.	Quick, successive pressing of the POWER ON/OFF button may fail to turn the power on. When using the POWER ON/OFF button, wait a short time between successive presses.

Percussion Assign List (Voices 40 and 00)



Jam Track Chord Progression List

21 DANCE	J=120
Am7 / Em7 /	
Dm7 / Am7 /	
22 RAP	J=116
Am7 / / /	
Am7 / / /	
23 FUNK	J=92
C7 F7 C7 F7	
24 SOUL BALLAD	J=104
C / / /	
Am / / /	
Dm7 / / /	
G7 / Gaug /	
25 MINOR BLUES	J=144
Am / / /	
Dm / Am /	
E / Am /	
26 HEAVY METAL	J=120
C / B ^b C	
27 BOOGIE WOOGIE	J=136
C / / /	
F / C /	
G F C G	

28 ROCK'N'ROLL	J=144
C Am F G	
29 R&B	J=136
C7 F7 G7 F7 C7	
30 SLOW ROCK	J=88
C Am7 F G7	
31 JAZZ BLUES	J=160
O7 F7 C7 /	
F7 / C7 A7	
Dm7 G7 C7 A7 Dm7 G7	
32 JAZZ WALTZ	J=192
C7 / / /	
C7 / / /	
F7 / / /	
C7 / / /	
G7 / G#7 G7	
C7 / / /	
33 FUSION	J=128
Dm7 / G7 /	
34 BOSSA NOVA	J=160
Em7 E ^b 7 Dm7 D ^b 7	
35 SAMBA	J=112
C F G / / /	

36 TANGO	J=124
E7 / Am /	
37 SKA	J=160
Am / Dm /	
38 COUNTRY	J=120
C F C G7	
C F C G7 C	
39 MARCH	J=116
C / G7 C	
40 NEW AGE	J=84
C / C# C	

One Touch Setting List

Turning on the One Touch Setting function, the following voice and tempo is automatically selected.

Jam Track List

NO.	VOICE	TEMPO
21	48 PIANO PAD	120
22	18 ORCHESTRA HIT	116
23	49 PIANO & VIBES	92
24	29 TENOR SAX	104
25	01 PIANO	144
26	13 DIST GUITAR	120
27	01 PIANO	136
28	05 E ORGAN	144
29	54 BRASS ENS	136
30	50 E PIANO PAD	88
31	66 PNO/VIBES	160
32	29 TENOR SAX	192
33	42 CHORUS E PNO	128
34	26 FLUTE	160
35	82 TRUMPET DUET	112
36	07 ACCORDION	124
37	22 TROMBONE	160
38	78 VIOLIN CNTRY	120
39	21 TRUMPET	116
40	50 E PIANO PAD	84

Style List

NO.	VOICE	TEMPO	NO.	VOICE	TEMPO	NO.	VOICE	TEMPO	NO.	VOICE	TEMPO
01	32 SY BRASS	152	26	31 HARMONICA	96	51	09 JAZZ GTR	160	76	33 SY LEAD	120
02	33 SY LEAD	188	27	22 TROMBONE	120	52	31 HARMONICA	140	77	49 PIANO&VIBES	100
03	42 CHORUS E PNO	104	28	42 CHORUS E PNO	88	53	19 VIBRAPHONE	120	78	50 E PIANO PAD	192
04	56 FANTASY2	200	29	19 VIBRAPHONE	84	54	22 TROMBONE	148	79	31 HARMONICA	120
05	50 E PIANO PAD	120	30	05 E ORGAN	104	55	26 FLUTE	128	80	07 ACCORDION	112
06	52 FOLK GTR PAD	92	31	05 E ORGAN	104	56	07 ACCORDION	124	81	74 PIANO CNTRY	120
07	01 PIANO	92	32	29 TENOR SAX	92	57	82 TRUMPET DUET	104	82	05 E ORGAN	132
08	26 FLUTE	92	33	73 PIANO BLOCK	152	58	22 TROMBONE	88	83	78 VIOLIN CNTRY	120
09	19 VIBRAPHONE	80	34	05 E ORGAN	144	59	81 MARIMBA TRIO	68	84	31 HARMONICA	76
10	05 E ORGAN	68	35	44 12STR GUITAR	140	60	22 TROMBONE	160	85	80 VIBES BLOCK	88
11	50 E PIANO PAD	112	36	13 DIST GUITAR	120	61	05 E ORGAN	124	86	09 J GUITAR	204
12	53 JAZZ GUITAR PAD	116	37	52 FOLK GTR PAD	116	62	24 BRASS ENS	136	87	11 E GUITAR	176
13	53 FANTASY 1	112	38	30 PANFLUTE	128	63	20 MARIMBA	112	88	27 CLARINET	116
14	51 E PNO & VIBES	112	39	42 CHORUS E PNO	120	64	82 TRUMPET DUET	200	89	14 VIOLIN	132
15	52 FOLK GTR PAD	112	40	68 PIANO SUSTAIN	120	65	22 TROMBONE	116	90	17 STRINGS	200
16	49 PIANO & VIBES	96	41	05 E ORGAN	88	66	81 MARIMBA TRIO	152	91	73 PIANO BLOCK	144
17	24 BRASS ENS	104	42	29 TENOR SAX	176	67	72 VIBRAPHONE SUSTAIN	84	92	29 TENOR SAX	120
18	18 ORCHESTRA HIT	116	43	41 HONKY-TONK	136	68	26 FLUTE	96	93	82 TRUMPET DUET	112
19	04 CLAVI	112	44	77 E ORGAN TRIO	156	69	72 VIBRAPHONE SUSTAIN	152	94	25 PICCOLO	124
20	30 PANFLUTE	108	45	24 BRASS ENS	136	70	21 TRUMPET	104	95	07 ACCORDION	120
21	50 E PIANO PAD	140	46	22 TROMBONE	88	71	29 TENOR SAX	208	96	27 CLARINET	128
22	32 SY BRASS	120	47	21 TRUMPET	148	72	80 VIBES BLOCK	140	97	83 HORN DUET	72
23	54 BRASS ENS DUAL	120	48	19 VIBRAPHONE	108	73	26 FLUTE	140	98	53 FANTASY 1	180
24	50 E PIANO PAD	128	49	54 BRASS ENS DUAL	152	74	33 SY LEAD	128	99	17 STRINGS	148
25	82 TRUMPET DUET	120	50	22 TROMBONE	176	75	84 FLUTE DUET	112	100	48 PIANO PAD	84

Keep in mind that even with the One Touch Setting function on, there are some Jam Track patterns which change the selected voice in the middle of the pattern.

Song Scores

V=Voice Number

01 ORIGINAL SONG 1

$\text{♩} = 108$ $\text{♩} = \text{♩}^3$

Am7 D7 Am7 8va D7 Am7
 V18 V54 V37 V54 V01
 D7 Am7 D7 Am7 D7 Am7
 V24 V01 V24 V01
 D7 D7 E7 D7 E7 D7
 V24
 E7 D7 E7 A7 sus4 D7 sus4 A7 sus4 D7 sus4
 V79
 Am7 D7 Am7 D7 Am7
 V29 V18 V29
 D7 Am7 D7
 Coda Am7
 D.S.

02 ORIGINAL SONG 2

Bm7 E7 Am7 Bm7 E7
 V01
 Dm7 G7 C F Bm⁵ B7 E7sus4 E7 Bm⁵ E7 to C Am E7
 V48
 8va Am7 Bm7 E7 Am7
 V30
 Bm7 E7 Dm7 G7 Cm7 Fm7 Bm⁵ B7 E7
 Coda Am Bm⁵ E7 Am Bm⁵ E7 Am
 V48 D.S.

03 ORIGINAL SONG 3

$\text{♩} = 136$

Musical score for 'ORIGINAL SONG 3' in 4/4 time, tempo 136. The score consists of seven staves of music. The key signature has one sharp (F#). The chord progression is as follows:

- Staff 1: Dm7, G7, C, A7, Dm7, G7
- Staff 2: Em7, E^b7, Dm7, G7, Cm7, Am7, Dm7, G7, Cm7
- Staff 3: Am7, Bm7, E7, Fm7, B^b7, Em7, A7
- Staff 4: F[#]m7⁵, B7, Em7, E^b7, Dm7, G7, Cm7, Am7, Dm7
- Staff 5: G7, Cm7, Am7, Gm7, C7, Fm7, B^b7
- Staff 6: Em7, A7, Dm7, to C, G7, C, Dm7, G7, Cm7
- Staff 7: Am7, Dm7, G7, Cm7, Am7, Dm7, G7

Additional markings include V73, V26, and V73. The piece concludes with a Coda section: G7, Em7⁵, A7, Dm7, G7, D^bm7, Cm7.

04 HOUSE OF THE RISING SUN

American Folk Song

$\text{♩} = 124$

Musical score for 'HOUSE OF THE RISING SUN' in 4/4 time, tempo 124. The key signature has one sharp (F#). The score consists of five staves of music. The chord progression is as follows:

- Staff 1: FM7, Em7, Am, E7, Am, C, D, F
- Staff 2: Am, C, Esus4, E7, Am, C, D, E, F
- Staff 3: Am, E7, Am, E7, Am, C, D, F
- Staff 4: Am, C, Esus4, E7, Am, C, D, F
- Staff 5: Am, E7, Am, FM7, Em7, Am

Additional markings include V48 and V7. The piece concludes with a triplet of eighth notes on the final staff.

05 THE LAST ROSE OF SUMMER

T. Moore

$\text{♩} = 80$

Musical score for 'The Last Rose of Summer' in 3/4 time, key of B-flat major. The score consists of six staves of music. The first staff begins with a tempo marking of quarter note = 80. Chord symbols are placed above the notes: F, B^b, F, B^b, F, B^b. A first ending bracket labeled 'V27' spans the final two measures of the first staff. The second staff continues with chords F, C7, F, B^b, F. The third staff has chords F, C7, F, B^b, F, Dm, A7, Dm. The fourth staff has chords Dm, F, B^b, F, C7, with a first ending bracket labeled '1' and 'F' above it. The fifth staff has chords Dm, A7, Dm, A7, Dm, C7, with a first ending bracket labeled 'V31' below it. The sixth staff has chords F, B^b, F, B^b, F, B^b, with a first ending bracket labeled '2' and 'F' above it.

06 SUR LE PONT D'AVIGNON

French Folk Song

$\text{♩} = 108$

Musical score for 'Sur le Pont d'Avignon' in 2/4 time, key of C major. The score consists of three staves of music. The first staff begins with a tempo marking of quarter note = 108. Chord symbols are placed above the notes: C, G7, C, C, G7. A first ending bracket labeled 'V27' spans the final two measures of the first staff. The second staff has chords C, G7, C, G7, C, G7, C, with a first ending bracket labeled '1.2.3.4.' above it. The third staff has chords C, G7, C, C, A^b7, Dm, G7, C, with a first ending bracket labeled '5.' above it.

07 WALTZ OF THE FLOWERS

Tchaikovsky

J=144

8va bassa

8va

V75

V30

(D.S. time repeat)

V75

V26

V79

V48

D.S.

Coda

08 AIR ON THE G STRING

J. S. Bach

J=76

V26

09 BEAUTIFUL DREAMER

S. C. Foster

J=172

Chords: F, Gm, C7, F, Gm, C7, F, G7, C7, C7, F, C7, F, A7, Dm, B^b, F, C7, F, Gm, C7, F.

Tempo: **J=172**

Time Signature: 3/4

Key Signature: B^b

Staff 1: Treble clef, B^b key signature.

Staff 2: Repeat sign, first ending.

Staff 3: Second ending.

Staff 4: D.S.

Staff 5: Coda.

Staff 6: Continuation of the piece.

10 LONDONDERRY AIR

Irish Folk Song

J=160

Chords: CM7, Dm7, Em7, Dm7, CM7, Dm7, Em7, Dm7, CM7, C7, FM7, Fm, CM7, Am7, Dm7, G7, CM7, G7, CM7, FM7, CM7, G, Am7, D7, Dm7, G7, CM7, FM7, CM7, G, CM7, Am7, Dm7, G7, CM7, Dm7, Em7, Dm7, CM7.

Tempo: **J=160**

Time Signature: 4/4

Key Signature: C

Staff 1: Treble clef, C key signature.

Staff 2: Repeat sign, first ending.

Staff 3: Second ending.

Staff 4: First ending.

Staff 5: Second ending.

Staff 6: Continuation of the piece.

11 SYMPHONY NO. 40

Mozart

$\text{♩} = 68$

Chords: Gm, EbM7, Cm7, D7, Gm, Cm, D7, Gm, Cdim, Gm, Cdim, Gm, Em7⁵, Eb7, D7, C[#]dim, D7, C[#]dim, D7, C[#]dim, D, D, Gm, Eb, Cm, F7, B^b, F7, Eb, B^b, Cm, B^b, C7, D^b7, C7, D^b7, C7, D^b7, C7, F, B^bdim, C7, F, B^bdim, C7, F, D7, Gm, EbM7, Cm7, D7, Gm.

12 DECK THE HALLS

Sacred Song

$\text{♩} = 112$

Chords: CM7, Am7, Fm7, Dm, G7, CM7, Am7, Dm7, G7, C, CM7, Am7, Dm7, G7, C, G7, C, Am7, D7, G, G7, CM7, Am7, Dm7, G7, C, A^bM7, B^bM7, CM7.

13 AULD LANG SYNE

Scottish Folk Song

J=92

Chord progression for 'Auld Lang Syne':
 F, Dm7, Gm7, C7, Dm7, G7, Gm7, C7, 2nd time (F, Dm7)
 C7, Gm7, C7, F, (F7), B^b, F, (F), V48 (2nd time), C7, Gm7, C7
 B^b, C7, F, B^b, (F), Dm7, C7, Gm7, C7, F, (F7)
 B^b, (Bdim), F, Dm7, C7, Gm7, C7, B^b, C7, F
 F, F, Dm7, Gm7, C7, B^b, B^bm, F

14 SILENT NIGHT

F. Gruber

J=84

Chord progression for 'Silent Night':
 C, C7, F, Fm, C, G7
 C, C, V50, V51 (2nd time), C7, F, C
 C, C7, F, C, G7, E7
 Am, F[#]m⁵, C, G7, C, A^b
 A^b, E^b, B^b7, E^b, G7
 C, F, Fm, C

15 TANNENBAUM

German Folk Song

J=84
C

Chord symbols: C, G7, C, C, G7, C, V17, G7, C, A7, Dm, G7, C, Em⁻⁵, A7, Dm7, G7, C, G7, C.

16 LA CUCARACHA

Mexican Folk Song

J=108
C

Chord symbols: C, G7, C, G7, C, G7, V21, V20, V80 (2nd time), V21, V82 (2nd time), C, V20, V80 (2nd time), V21, V82 (2nd time), C, V20, V24, C, V84, V24, V84, V54, C, V81, V54, V81, V82, V79, C, G7, C.

17 OH! SUSANNA

S. C. Foster

$\text{♩} = 116$

18 SONG OF JOY

Beethoven

$\text{♩} = 120$

19 O, VRENELI

Swiss Folk Song

J=120

Musical score for 'O, VRENELI' in C major, 2/4 time. The score consists of six staves of music. The tempo is marked as J=120. The key signature has one sharp (F#). The score includes various chords such as C, F, G7, and V07. There are repeat signs and first/second endings. A section labeled 'V48 (2nd time)' is indicated. The piece concludes with a final chord of C.

20 TROIKA

Russian Folk Song

J=120

Musical score for 'TROIKA' in A minor, 2/4 time. The tempo is marked as J=120. The key signature has no sharps or flats. The score consists of five staves of music. The chords are primarily minor and dominant seventh chords, including Am, Em7, Fm7, Dm, Bm7, and E7. There are repeat signs and first/second endings. A section labeled 'V49' is indicated. The piece concludes with a Coda section marked 'D.S.' and a final chord of Am.

SPECIAL MESSAGE SECTION

This product utilizes batteries or an external power supply (adapter). DO NOT connect this product to any power supply or adapter other than one described in the manual, on the name plate, or specifically recommended by Yamaha.

This product should be used only with the components supplied or; a cart, rack, or stand that is recommended by Yamaha. If a cart, etc., is used, please observe all safety markings and instructions that accompany the accessory product.

SPECIFICATIONS SUBJECT TO CHANGE:

The information contained in this manual is believed to be correct at the time of printing. However, Yamaha reserves the right to change or modify any of the specifications without notice or obligation to update existing units.

This product, either alone or in combination with an amplifier and headphones or speaker/s, may be capable of producing sound levels that could cause permanent hearing loss. DO NOT operate for long periods of time at a high volume level or at a level that is uncomfortable. If you experience any hearing loss or ringing in the ears, you should consult an audiologist.

IMPORTANT: The louder the sound, the shorter the time period before damage occurs.

NOTICE:

Service charges incurred due to a lack of knowledge relating to how a function or effect works (when the unit is operating as designed) are not covered by the manufacturer's warranty, and are therefore the owners responsibility. Please study this manual carefully and consult your dealer before requesting service.

ENVIRONMENTAL ISSUES:

Yamaha strives to produce products that are both user safe and environmentally friendly. We sincerely believe that our products and the production methods used to produce them, meet these goals. In keeping with both the letter and the spirit of the law, we want you to be aware of the following:

Battery Notice:

This product MAY contain a small non-rechargeable battery which (if applicable) is soldered in place. The average life span of this type of battery is

approximately five years. When replacement becomes necessary, contact a qualified service representative to perform the replacement.

This product may also use "household" type batteries. Some of these may be rechargeable. Make sure that the battery being charged is a rechargeable type and that the charger is intended for the battery being charged.

When installing batteries, do not mix batteries with new, or with batteries of a different type. Batteries MUST be installed correctly. Mismatches or incorrect installation may result in overheating and battery case rupture.

Warning:

Do not attempt to disassemble, or incinerate any battery. Keep all batteries away from children. Dispose of used batteries promptly and as regulated by the laws in your area. Note: Check with any retailer of household type batteries in your area for battery disposal information.

Disposal Notice: Should this product become damaged beyond repair, or for some reason its useful life is considered to be at an end, please observe all local, state, and federal regulations that relate to the disposal of products that contain lead, batteries, plastics, etc. If your dealer is unable to assist you, please contact Yamaha directly.

NAME PLATE LOCATION:

The name plate is located on the bottom of the product. The model number, serial number, power requirements, etc., are located on this plate. You should record the model number, serial number, and the date of purchase in the spaces provided below and retain this manual as a permanent record of your purchase.

Model

Serial No.

Purchase Date

PLEASE KEEP THIS MANUAL

FCC INFORMATION (U.S.A.)

IMPORTANT NOTICE: DO NOT MODIFY THIS UNIT!

This product, when installed as indicated in the instructions contained in this manual, meets FCC requirements. Modifications not expressly approved by Yamaha may void your authority, granted by the FCC, to use the product.

IMPORTANT:

When connecting this product to accessories and/or another product use only high quality shielded cables. Cable/s supplied with this product MUST be used. Follow all installation instructions. Failure to follow instructions could void your FCC authorization to use this product in the USA.

NOTE:

This product has been tested and found to comply with the requirements listed in FCC Regulations, Part 15 for Class "B" digital devices. Compliance with these requirements provides a reasonable level of assurance that your use of this product in a residential environment will not result in harmful interference with other electronic devices. This equipment generates/uses radio frequencies and, if not installed and used according to the instructions found in the users manual, may cause interference harmful to the operation of other electronic de-

vices. Compliance with FCC regulations does not guarantee that interference will not occur in all installations. If this product is found to be the source of interference, which can be determined by turning the unit "OFF" and "ON", please try to eliminate the problem by using one of the following measures:

- Relocate either this product or the device that is being affected by the interference.
- Utilize power outlets that are on different branch(circuit breaker or fuse) circuits or install AC line filter/s.
- In the case of radio or TV interference, relocate/reorient the antenna. If the antenna lead-in is 300 ohm ribbon lead, change the lead-in to co-axial type cable.

If these corrective measures do not produce satisfactory results, please contact the local retailer authorized to distribute this type of product. If you can not locate the appropriate retailer, please contact Yamaha Corporation of America, Electronic Service Division, 6600 Orangethorpe Ave, Buena Park, CA90620

- This applies only to products distributed by Yamaha Corporation of America.

Specifications

		PSR-180	PSR-76
KEYBOARD	Number of Keys	61	49
	Key Size		Regular
	Register	C1-C6	C1-Cs
VOICE	Tone Generation		AWM
	Number of Voices		100
	Polyphony (Maximum)		12 notes
STYLE	Number of Styles		100
	Auto Accompaniment		Yes
	Chord Detection		Multi (Single Finger, Fingered)
SONG/JAM TRACK	Songs		20
	Jam Track Patterns		20
	Minus One		Yes
	One Touch Setting		Yes
	PADS	4	--
	Drum	16 (4x4)	--
	Sound Effect	16 (4x4)	--
CONTROLS		POWER ON/OFF, VOICE, STYLE, SONG, Numeric Keypad, MINUS ONE, START/STOP, ONE TOUCH SETTING, TEMPO, SYNC-START/FILL IN, MULTI DISPLAY, VOLUME	
OTHER TERMINALS, FITTINGS		DC IN, HEADPHONES/AUX OUT, Music Stand	
AMPLIFIER(S)		using Power Adaptor: 4.5 W + 4.5 W using batteries: 8 W + 8 W	using Power Adaptor: 3.8 W using batteries: 3.8 W
SPEAKERS		10 cm x 2, 4Ω	
POWER CONSUMPTION		8.3 w (using Power Adaptor PA-3)	8.0 w (using Power Adaptor PA-3)
RATED POWER SUPPLY		DC 10-12 V; 6 "D" size/R-20/SUM-1 (1.5 V) batteries, or PA-3/4/10 Power Adaptor	
DIMENSIONS (W x D x H)		931 x 347 x 137mm (36-5/8" x 13-5/8" x 5-3/8")	964 x 287 x 113mm (38" x 11-1/4" x 4-1/2")
WEIGHT		4.3 kg (9 lbs., 8 oz.)	3.6 kg (7 lbs., 15 oz.)
CASING		Polystyrene	
OPTIONAL ACCESSORIES		HPE-3/150 Headphones, PA-3/4/10 Power Adaptors (PA-40 for use in U.S. only), L-2C Keyboard Stand	

Specifications are subject to change without notice.

Limited Warranty

90 DAYS LABOR

1 YEAR PARTS

Yamaha Corporation of America, hereafter referred to as Yamaha, warrants to the original consumer of a product included in the categories listed below that the product will be free of defects in materials and/or workmanship for the periods indicated. This warranty is applicable to all models included in the following series of products:

PSR SERIES OF PORTASOUND ELECTRONIC KEYBOARDS

If during the first 90 days that immediately follows the purchase date, your new Yamaha product covered by this warranty is found to have a defect in material and/or workmanship, Yamaha and/or its authorized representative will repair such defect without charge for parts or labor.

If parts should be required after this 90 day period but within the one year period that immediately follows the purchase date, Yamaha will, subject to the terms of this warranty, supply these parts without charge. However, charges for labor, and/or any miscellaneous expenses incurred are the consumers responsibility. Yamaha reserves the right to utilize reconditioned parts in repairing these products and/or to use reconditioned units as warranty replacements.

THIS WARRANTY IS THE ONLY EXPRESS WARRANTY WHICH YAMAHA MAKES IN CONNECTION WITH THESE PRODUCTS. ANY IMPLIED WARRANTY APPLICABLE TO THE PRODUCT, INCLUDING THE WARRANTY OF MERCHANTABILITY IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY. YAMAHA EXCLUDES AND SHALL NOT BE LIABLE IN ANY EVENT FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Some states do not allow limitations that relate to implied warranties and/or the exclusion of incidental or consequential damages. Therefore, these limitations and exclusions may not apply to you.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

CONSUMERS RESPONSIBILITIES

If warranty service should be required, it is necessary that the consumer assume certain responsibilities:

- Contact the Customer Service Department of the retailer selling the product, or any retail outlet authorized by Yamaha to sell the product for assistance. You may also contact Yamaha directly at the address provided below.
- Deliver the unit to be serviced under warranty to: the retailer selling the product, an authorized service center, or to Yamaha with an explanation of the problem. Please be prepared to provide proof purchase date (sales receipt, credit card copy, etc.) when requesting service and/or parts under warranty.
- Shipping and/or insurance costs are the consumers responsibility.* Units shipped for service should be packed securely.

*Repaired units will be returned PREPAID if warranty service is required within the first 90 days.

IMPORTANT: Do NOT ship anything to ANY location without prior authorization. A Return Authorization (RA) will be issued that has a tracking number assigned that will expedite the servicing of your unit and provide a tracking system if needed.

- Your owners manual contains important safety and operating instructions. It is your responsibility to be aware of the contents of this manual and to follow all safety precautions.

EXCLUSIONS

This warranty does not apply to units whose trade name, trademark, and/or ID numbers have been altered, defaced, exchanged removed, or to failures and/or damages that may occur as a result of:

- Neglect, abuse, abnormal strain, modification or exposure to extremes in temperature or humidity
- Improper repair or maintenance by any person who is not a service representative of a retail outlet authorized by Yamaha to sell the product, an authorized service center, or an authorized service representative of Yamaha
- This warranty is applicable only to units sold by retailers authorized by Yamaha to sell these products in the U.S.A., the District of Columbia, and Puerto Rico. This warranty is not applicable in other possessions or territories of the U.S.A. or in any other country.

Please record the model and serial number of the product you have purchased in the spaces provided below.

Model _____ Serial # _____ Sales Slip # _____

Purchased from _____ (Retailer) Date _____

YAMAHA CORPORATION OF AMERICA
Electronic Service Division
6600 Orangethorpe Avenue
Buena Park, CA 90620

KEEP THIS DOCUMENT FOR YOUR RECORDS. DO NOT MAIL!

For details of products, please contact your nearest Yamaha or the authorized distributor listed below.

Die Einzelheiten zu Produkten sind bei Ihrer unten aufgeführten Niederlassung und bei Yamaha Vertragshändlern in den jeweiligen Bestimmungsländern erhältlich.

Pour plus de détails sur les produits, veuillez-vous adresser à Yamaha ou au distributeur le plus proche de vous figurant dans la liste suivante.

Para detalles sobre productos, contacte su tienda Yamaha más cercana o el distribuidor autorizado que se lista debajo.

NORTH AMERICA

CANADA

Yamaha Canada Music Ltd.
135 Milner Avenue, Scarborough, Ontario,
M1S 3R1, Canada
Tel: 416-298-1311

U.S.A.

Yamaha Corporation of America
6600 Orangethorpe Ave., Buena Park, Calif. 90620,
U.S.A.
Tel: 714-522-9011

MIDDLE & SOUTH AMERICA

MEXICO

**Yamaha De Mexico S.A. De C.V.,
Departamento de ventas**
Javier Rojo Gomez No.1149, Col. Gpe Del
Moral, Deleg. Iztapalapa, 09300 Mexico, D.F.
Tel: 686-00-33

BRASIL

Yamaha Musical Do Brasil LTDA.
Ave. Reboucas 2636, São Paulo, Brasil
Tel: 55-11 853-1377

PANAMA

Yamaha De Panama S.A.
Edificio Interseco, Calle Elvira Mendez no.10, Piso
3, Oficina # 105, Ciudad de Panama, Panama
Tel: 507-69-5311

OTHER LATIN AMERICAN COUNTRIES AND CARIBBEAN COUNTRIES

Yamaha Music Latin America Corp.
6101 Blue Lagoon Drive, Miami, Florida 33126,
U.S.A.
Tel: 305-261-4111

EUROPE

THE UNITED KINGDOM

Yamaha-Kemble Music(U.K.) Ltd.
Sherbourne Drive, Tilbrook, Milton Keynes,
MK7 8BL England
Tel: 0908-366700

IRELAND

Danfay Ltd.
61D, Sallynoggin Road, Dun Laoghaire, Co. Dublin
Tel: 01-2859177

GERMANY/SWITZERLAND

Yamaha Europa GmbH.
Siemensstraße 22-34, D-2084 Rellingen, F.R. of
Germany
Tel: 04101-3030

AUSTRIA/HUNGARY/SLOVENIA/ ROMANIA/BULGARIA

Yamaha Music Austria GmbH.
Schleiergasse 20, A-1100 Wien Austria
Tel: 0222-60203900

THE NETHERLANDS

**Yamaha Music Benelux B.V.,
Verkoop Administratie**
Kanaalweg 18G, 3526 KL Utrecht, The Netherlands
Tel: 030-828411

BELGIUM/LUXEMBOURG

**Yamaha Music Benelux B.V.,
Brussels-office**
Keiberg Imperiastraat 8, 1930 Zaventem, Belgium
Tel: 02-7258220

FRANCE

**Yamaha Musique France, Division
Instruments Electroniques et de Scène**
BP 70-77312 Marne-la-Valée Cedex 2, France
Tel: 01-64-61-4000

ITALY

**Yamaha Musica Italia S.P.A.,
Home Keyboard Division**
Viale Italia 88, 20020 Lainate(Milano), Italy
Tel: 02-935-771

SPAIN

Yamaha-Hazen Electronica Musical, S.A.
Jorge Juan 30, 28001, Madrid, Spain
Tel: 91-577-7270

PORTUGAL

Valentim de Carvalho CI SA
Estrada de Porto Salvo, Paço de Arcos 2780 Oeiras,
Portugal
Tel: 01-443-3398/4030/1823

GREECE

Philippe Nakas S.A.
Navarinou Street 13, P.Code 10680, Athens, Greece
Tel: 01-364-7111

SWEDEN

Yamaha Scandinavia AB
J. A. Wettergrens gata 1, Box 30053, 400 43
Göteborg, Sweden
Tel: 031-496090

DENMARK

YS Copenhagen Liaison Office
Finsensvej 86, DK-2000 Frederiksberg, Denmark
Tel: 31-87 30 88

FINLAND

Fazer Music Inc.
Aleksanterinkatu 11, SF 00100 Helsinki, Finland
Tel: 0435 011

NORWAY

Narud Yamaha AS
Østerndalen 29, 1345 Østerås
Tel: 02-24 47 90

ICELAND

Páll H. Pálsson
P.O. Box 85, 121 Reykjavik, Iceland
Tel: 01-19440

OTHER EUROPEAN COUNTRIES

Yamaha Europa GmbH.
Siemensstraße 22-34, D-2084 Rellingen, F.R. of
Germany
Tel: 04101-3030

AFRICA

**Yamaha Corporation,
International Marketing Division**
Nakazawa-cho 10-1, Hamamatsu, Japan 430
Tel: 053-460-2311

MIDDLE EAST

TURKEY/CYPRUS

Yamaha Musique France, Division Export
BP70-77312 Marne-la-Valée Cedex 2, France
Tel: 01-64-61-4000

OTHER COUNTRIES

**Yamaha Corporation,
International Marketing Division**
Nakazawa-cho 10-1, Hamamatsu, Japan 430
Tel: 053-460-2311

ASIA

HONG KONG

Tom Lee Music Co., Ltd.
11/F., Silvercord Tower 1, 30 Canton Road,
Tsimshatsui, Kowloon, Hong Kong
Tel: 730-1098

INDONESIA

**PT. Yamaha Music Indonesia (Distributor)
PT. Nusantik**
Gedung Yamaha Music Center, Jalan Jend. Gatot
Subroto Kav. 4, Jakarta 12930, Indonesia
Tel: 21-520-2577

KOREA

Cosmos Corporation
#131-31, Neung-Dong, Sungdong-Ku, Seoul
Korea
Tel: 02-466-0021-5

MALAYSIA

Yamaha Music Malaysia Sdn., Bhd.
16-28, Jalan SS 2/72, Petaling Jaya, Selangor,
Malaysia
Tel: 3-717-8977

PHILIPPINES

Yupango Music Corporation
339 Gil J. Puyat Avenue, P.O. Box 885 MCPO,
Makati, Metro Manila, Philippines
Tel: 819-7551

SINGAPORE

Yamaha Music Asia Pte., Ltd.
Blk 17A Toa Payoh #01-190 Lorong 7
Singapore 1231
Tel: 354-0133

TAIWAN

Kung Hsue She Trading Co., Ltd.
No. 322, Section 1, Fu Hsing S. Road,
Taipei 106, Taiwan. R.O.C.
Tel: 02-709-1266

THAILAND

Siam Music Yamaha Co., Ltd.
865 Phornprapha Building, Rama I Road,
Patumwan, Bangkok 10330, Thailand
Tel: 2-215-3443

THE PEOPLE'S REPUBLIC OF CHINA AND OTHER ASIAN COUNTRIES

**Yamaha Corporation,
International Marketing Division**
Nakazawa-cho 10-1, Hamamatsu, Japan 430
Tel: 053-460-2311

OCEANIA

AUSTRALIA

Yamaha Music Australia Pty. Ltd.
17-33 Market Street, South Melbourne, Vic. 3205,
Australia
Tel: 3-699-2388

NEW ZEALAND

Music Houses of N.Z. Ltd.
146/148 Captain Springs Road, Te Papapa,
Auckland, New Zealand
Tel: 9-634-0099

COUNTRIES AND TRUST TERRITORIES IN PACIFIC OCEAN

**Yamaha Corporation,
International Marketing Division**
Nakazawa-cho 10-1, Hamamatsu, Japan 430
Tel: 053-460-2311

HEAD OFFICE Yamaha Corporation, Electronic Musical Instrument Division
Nakazawa-cho 10-1, Hamamatsu, Japan 430
Tel: 053-460-3273

YAMAHA
YAMAHA CORPORATION