



YAMAHA R-V905



CAT

R-V905

Natural Sound AV Receiver


Récepteur audiovisuel

**OWNER'S MANUAL
MODE D'EMPLOI**


YAMAHA ELECTRONICS CORPORATION, USA 6660 ORANGETHORPE AVE., BUENA PARK, CALIF. 90620, U.S.A.
YAMAHA CANADA MUSIC LTD. 135 MILNER AVE., SCARBOROUGH, ONTARIO M1S 3R1, CANADA
YAMAHA ELECTRONIK EUROPA G.m.b.H. SIEMENSSTR. 22-34, 25462 RELINGEN BEI HAMBURG, F.R. OF GERMANY
YAMAHA ELECTRONIQUE FRANCE S.A. RUE AMBROISE CROIZAT BP70 CROISSY-BEAUBOURG 77312 MARNE-LA-VALLEE CEDEX02, FRANCE
YAMAHA ELECTRONICS (UK) LTD. YAMAHA HOUSE, 200 RICKMANSWORTH ROAD WATFORD, HERTS WD1 7JS, ENGLAND
YAMAHA SCANDINAVIA A.B. J A WETTERGRENS GATA 1, BOX 30053, 400 43 VÄSTRA FRÖLUNDA, SWEDEN
YAMAHA MUSIC AUSTRALIA PTY, LTD. 17-33 MARKET ST., SOUTH MELBOURNE, 3205 VIC., AUSTRALIA

YAMAHA CORPORATION
Printed in Malaysia ID V275370

SAFETY INSTRUCTIONS



- Explanation of Graphical Symbols



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert you to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert you to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.


- 1 Read Instructions – All the safety and operating instructions should be read before the unit is operated.
- 2 Retain Instructions – The safety and operating instructions should be retained for future reference.
- 3 Heed Warnings – All warnings on the unit and in the operating instructions should be adhered to.
- 4 Follow Instructions – All operating and other instructions should be followed.
- 5 Water and Moisture – The unit should not be used near water – for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool, etc.
- 6 Carts and Stands – The unit should be used only with a cart or stand that is recommended by the manufacturer.
- 6A A unit and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the unit and cart combination to overturn.
- 7 Wall or Ceiling Mounting – The unit should be mounted to a wall or ceiling only as recommended by the manufacturer.
- 8 Ventilation – The unit should be situated so that its location or position does not interfere with its proper ventilation. For example, the unit should not be situated on a bed, sofa, rug, or similar surface, that may block the ventilation openings; or placed in a built-in installation, such as a bookcase or cabinet that may impede the flow of air through the ventilation openings.
- 9 Heat – The unit should be situated away from heat sources such as radiators, stoves, or other appliances that produce heat.
- 10 Power Sources – The unit should be connected to a power supply only of the type described in the operating instructions or as marked on the unit.
- 11 Power-Cord Protection – Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the unit.
- 12 Cleaning – The unit should be cleaned only as recommended by the manufacturer.
- 13 Nonuse Periods – The power cord of the unit should be unplugged from the outlet when left unused for a long period of time.
- 14 Object and Liquid Entry – Care should be taken so that objects do not fall into and liquids are not spilled into the inside of the unit.
- 15 Damage Requiring Service – The unit should be serviced by qualified service personnel when:
 - A. The power-supply cord or the plug has been damaged; or
 - B. Objects have fallen, or liquid has been spilled into the unit; or
 - C. The unit has been exposed to rain; or
 - D. The unit does not appear to operate normally or exhibits a marked change in performance; or
 - E. The unit has been dropped, or the cabinet damaged.
- 16 Servicing – The user should not attempt to service the unit beyond those means described in the operating instructions. All other servicing should be referred to qualified service personnel.
- 17 Power Lines – An outdoor antenna should be located away from power lines.
- 18 Grounding or Polarization – Precautions should be taken so that the grounding or polarization is not defeated.

19 For US customers only:

Outdoor Antenna Grounding – If an outside antenna is connected to this unit, be sure the antenna system is grounded so as to provide some protection against voltage surges and built-up static charges. Article 810 of the National Electrical Code, ANSI/NFPA 70, provides information with regard to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

Note to CATV system installer:

This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

**FCC INFORMATION (for US customers only)****1. IMPORTANT NOTICE : DO NOT MODIFY THIS UNIT!**

This product, when installed as indicated in the instructions contained in this manual, meets FCC requirements. Modifications not expressly approved by Yamaha may void your authority, granted by the FCC, to use the product.

2. IMPORTANT : When connecting this product to accessories and/or another product use only high quality shielded cables. Cable/s supplied with this product **MUST** be used. Follow all installation instructions. Failure to follow instructions could void your FCC authorization to use this product in the USA.**3. NOTE :** This product has been tested and found to comply with the requirements listed in FCC Regulations, Part 15 for Class "B" digital devices. Compliance with these requirements provides a reasonable level of assurance that your use of this product in a residential environment will not result in harmful interference with other electronic devices.

This equipment generates/uses radio frequencies and, if not installed and used according to the instructions found in the users manual, may cause interference harmful to the operation of other electronic devices.

Compliance with FCC regulations does not guarantee that interference will not occur in all installations. If this product is found to be the source of interference, which can be determined by turning the unit "OFF" and "ON", please try to eliminate the problem by using one of the following measures:

Relocate either this product or the device that is being affected by the interference.

Utilize power outlets that are on different branch (circuit breaker or fuse) circuits or install AC line filter/s.

In the case of radio or TV interference, relocate/reorient the antenna. If the antenna lead-in is 300 ohm ribbon lead, change the lead-in to coaxial type cable.

If these corrective measures do not produce satisfactory results, please contact the local retailer authorized to distribute this type of product. If you can not locate the appropriate retailer, please contact Yamaha Electronics Corp., U.S.A. 6660 Orangethorpe Ave, Buena Park, CA 90620.

The above statements apply **ONLY** to those products distributed by Yamaha Corporation of America or its subsidiaries.

We Want You Listening For A Lifetime





YAMAHA and the Electronic Industries Association's Consumer Electronics Group want you to get the most out of your equipment by playing it at a safe level. One that lets the sound come through loud and clear without annoying blaring or distortion – and, most importantly, without affecting your sensitive hearing.

Since hearing damage from loud sounds is often undetectable until it is too late, YAMAHA and the Electronic Industries Association's Consumer Electronics Group recommend you to avoid prolonged exposure from excessive volume levels.




SUPPLIED ACCESSORIES
ACCESSOIRES FOURNIS

- After unpacking, check that the following parts are included.
- Après le déballage, vérifier que les pièces suivantes sont incluses.

| | |
|---|---|
| <ul style="list-style-type: none"> • Indoor FM Antenna • Antenne FM intérieure |  |
| <ul style="list-style-type: none"> • AM Loop Antenna • Cadre-antenne AM |  |
| <ul style="list-style-type: none"> • Antenna adapter (U.S.A. and Canada models only) • Adaptateur d'antenne (Modèle pour les Etats-Unis et le Canada seulement) |  |
| <ul style="list-style-type: none"> • Batteries (size AA, R6, UM-3) • Piles (taille AA, R6, UM-3) |  |

- Remote control transmitter
- Télécommande



The remote control transmitter features the following controls and buttons:

- POWER** (I) and **STANDBY** (⏻)
- AMP/TUN** (Volume knob)
- DIGITAL / PRO LOGIC** (CD)
- ENHANCED TUNER** (1)
- MOVIE THEATER TAPE/MD** (3)
- MONO MOVIE DVD/LD** (4)
- TV SPORTS TV/DBS** (5)
- DISCO VCR** (6)
- ROCK PHONO** (7)
- HALL V-AUX** (8)
- TEST +100** (9)
- EXT. DEC.** (0)
- +10** (ENTER)
- TEST +100 CLEAR** (CLEAR)
- DSP** (A/B/C/D/E)
- DISC SKIP PRESET** (EFCT ON/OFF)
- CH** (Left/Right) and **TV** (Up/Down)
- CODE SET** (MUTE)
- VOLUME** (Up/Down)
- SLEEP** (TV)
- POWER** (TV)
- VCR REC** (TV INPUT A/B)
- INDEX** (DISP)
- SELECT** (Left/Right/Up/Down)
- SET UP** (SUBTITLE ON/OFF)
- RETURN** (ANGLE AUDIO MENU)
- TITLE** (TIME/LEVEL)
- SET MENU**

YAMAHA

FEATURES

- **5 Speaker Configuration**
<Canada model>
Main: 70 W + 70 W (8Ω) RMS Output
Power, 0.04% THD, 20 Hz – 20 kHz
Center: 70 W (8Ω) RMS Output
Power, 0.04% THD, 20 Hz – 20 kHz
Rear: 70 W + 70 W (8Ω) RMS Output
Power, 0.04% THD, 20 Hz – 20 kHz
<Australia and China models>
Main: 65 W + 65 W (8Ω) RMS Output
Power, 0.04% THD, 20 Hz – 20 kHz
Center: 65 W (8Ω) RMS Output
Power, 0.04% THD, 20 Hz – 20 kHz
Rear: 65 W + 65 W (8Ω) RMS Output
Power, 0.04% THD, 20 Hz – 20 kHz
- **Digital Sound Field Processor**
- **Dolby Digital Decoder**
- **Dolby Pro Logic Surround Decoder**
- **CINEMA DSP: Theater-like Sound Experience by the Combination of Dolby Surround and YAMAHA DSP Technology**
- **6-Channel External Decoder Input for DTS and other future formats**
- **Automatic Input Balance Control for Dolby Pro Logic Surround**
- **Test Tone Generator for Easier Speaker Balance Adjustment**
- **Speaker Output Mode Changing Capability**
- **40-Station Random Access Preset Tuning**
- **Automatic Preset Tuning**
- **Preset Station Shifting Capability (Preset Editing)**
- **Video Signal Input/Output Capability**
- **SLEEP Timer**
- **Universal Remote Control Transmitter with Preset Manufacturer Codes**

CONTENTS

| | | | |
|------------------------------------|----|-------------------------------------|-----|
| SUPPLIED ACCESSORIES | 4 | ● Information about DSP | |
| FEATURES | 5 | USING DIGITAL SOUND FIELD | |
| CAUTION | 6 | PROCESSOR (DSP) | 37 |
| ● Introduction | | ● Advanced Information | |
| FEATURES ON SOUND EFFECT | 7 | ADJUSTMENTS | |
| CONTROLS AND THEIR FUNCTIONS | 9 | IN THE "SET MENU" MODE | 43 |
| ● Preparation | | ● Remote Control Transmitter | |
| SPEAKER SETUP | 12 | REMOTE CONTROL TRANSMITTER | 45 |
| CONNECTIONS | 14 | SETUP CODES | 50 |
| ADJUSTMENTS | | NOTES ABOUT THE REMOTE CONTROL | |
| BEFORE USING THIS UNIT | 22 | TRANSMITTER | 51 |
| ● Basic Operation | | TROUBLESHOOTING | 52 |
| BASIC OPERATIONS | 27 | SPECIFICATIONS | 54 |
| TUNING OPERATIONS | 31 | LIST OF MANUFACTURER'S CODES | 108 |
| SETTING THE SLEEP TIMER | 36 | | |

CAUTION : READ THIS BEFORE OPERATING YOUR UNIT.

1. To assure the finest performance, please read this manual carefully. Keep it in a safe place for future reference.
2. Install this unit in a cool, dry, clean place – away from windows, heat sources, sources of excessive vibration, dust, moisture and cold. Avoid sources of humming (transformers, motors). To prevent fire or electrical shock, do not expose the unit to rain or water.
3. Never open the cabinet. If something drops into the set, contact your dealer.
4. Do not use force on switches, controls or connection wires. When moving the unit, first disconnect the power plug and the wires connected to other equipment. Never pull the wires themselves.
5. The openings on the unit cover assure proper ventilation of the unit. If these openings are obstructed, the temperature inside the unit will rise rapidly. Therefore, avoid placing objects against these openings, and install the unit in a well-ventilated area to prevent fire and damage.
6. The voltage used must be the same as that specified on this unit. Using this unit with a higher voltage than specified is dangerous and may result in fire or other accidents. YAMAHA will not be held responsible for any damage resulting from use of this unit with a voltage other than specified.
7. Digital signals generated by this unit may interfere with other equipment such as tuners, receivers or TVs. Move this unit farther away from such equipment if interference is observed.
8. Always set the VOLUME control to “∞” before starting the audio source play. Increase the volume gradually to an appropriate level after playback has been started.
9. Do not attempt to clean the unit with chemical solvents; this might damage the finish. Use a clean, dry cloth.
10. Be sure to read the “TROUBLESHOOTING” section regarding common operating errors before concluding that the unit is faulty.
11. When not planning to use this unit for long periods of time (ie., vacation, etc.), disconnect the AC power plug from the wall outlet.
12. To prevent lightning damage, disconnect the AC power plug and disconnect the antenna cable when there is an electrical storm.
13. Grounding or polarization – Precautions should be taken so that the grounding or polarization of an appliance is not defeated.
14. AC outlet
Do not connect audio equipment to the AC outlet on the rear panel if that equipment requires more power than the outlet is rated to provide.
15. **Voltage Selector (China and General Models only)**
The voltage selector on the rear panel of this unit must be set for your local main voltage BEFORE plugging into the AC main supply.
Voltages are 110/120/220/240 V AC, 50/60 Hz.

This unit is not disconnected from the AC power source as long as it is connected to the wall outlet, even if this unit itself is turned off. This state is called the standby mode. In this state, this unit is designed to consume a very small quantity of power.

FREQUENCY STEP switch (China and General Models only)

Because the interstation frequency spacing differs in different areas, set the FREQUENCY STEP switch (located at the rear) according to the frequency spacing in your area. Before setting this switch, disconnect the AC power plug of this unit from the AC outlet.

IMPORTANT

Please record the serial number of this unit in the space below.

Serial No.:

The serial number is located on the rear of the unit. Retain this Owner's Manual in a safe place for future reference.

WARNING

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.

FOR CANADIAN CUSTOMERS

TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT AND FULLY INSERT.

THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.

FEATURES ON SOUND EFFECT

This unit incorporates a sophisticated, multi-program digital sound field processor. The processor allows you to electronically expand and change the shape of the audio sound field from both audio and video sources, creating a theater-like experience in your listening room. This unit has a total of 8 digital sound field processor (DSP) modes. You can create an excellent audio sound field by selecting a suitable sound field (this will, of course, depend on what you will be listening to), and adding desired adjustments.

Digital Sound Field Processing

What is it that makes live music so good? Today's advanced sound reproduction technology lets you get extremely close to the sound of a live performance, but chances are you'll still notice something missing, the acoustic environment of the live concert hall. Extensive research into the exact nature of the sonic reflections that create the ambience of a large hall has made it possible for YAMAHA engineers to bring you this same sound in your listening room, so you'll feel all the sound of a live concert.

Dolby Pro Logic Surround

This unit employs a Dolby Pro Logic Surround decoder similar to professional Dolby Stereo decoders used in many movie theaters. By using the Dolby Pro Logic Surround decoder, you can experience the dramatic realism and impact of Dolby Surround movie theater sound in your own home. Dolby Pro Logic employs a four channel five speaker system. The Pro Logic Surround system divides the input signal into four levels: the left and right main channels, the center channel (used for dialog), and the rear surround sound channels (used for sound effects, background noise, and other ambient noises). The center channel allows listeners seated in even less-than-ideal positions to hear the dialog originating from the action on the screen while experiencing good stereo imaging.

Dolby Digital

The built-in Dolby Digital decoder leads you into a totally new sound experiences.

Dolby Digital is a new generation of multi-channel digital audio technology, or the newest spatial sound processing format developed for 35 mm film-movies by employing a new kind of low bit-rate audio coding.

Dolby Digital is a digital surround sound system that provides completely independent multi-channel audio to consumers. In multi-channel form, Dolby Digital provides five full range channels in what is sometimes referred to as a "3/2" configuration: three front channels (left, center and right), plus two surround channels. A sixth bass-only effect channel is also provided for output of LFE (low frequency effect), or low bass effects that are independent of other channels. This channel is counted as 0.1, thus giving rise to the term 5.1 channels in total.

In addition, this unit incorporates a Dolby Pro Logic Surround decoder and Dolby Digital decoder for multi-channel sound reproduction of Dolby Surround encoded video sources. The operation of the Dolby Pro Logic Surround or Dolby Digital decoder can be controlled by selecting a corresponding DSP program including combined operations of the YAMAHA DSP and the Dolby Pro Logic Surround or Dolby Digital decoder.

Furthermore, our technicians, armed with sophisticated measuring equipment, have even made it possible to capture the acoustics of a variety of actual concert halls, theaters, etc. from around the world, to allow you to accurately re-create any one of these live performance environments, all in your home.

Dolby Surround is encoded on the sound track of pre-recorded video tapes, laser discs, and some TV/cable broadcasts. When you play a source encoded with Dolby Surround on this unit, the Dolby Pro Logic Surround decoder decodes the signal and distributes the surround-sound effects.

This Dolby Pro Logic Surround decoder employs a digital signal processing system. This system improves the stability of sound at each channel and crosstalk between channels, so that positioning of sounds around the room is more accurate compared with conventional analog signal processing systems.

In addition, this unit features a built-in automatic input balance control. This always assures you the best performance without manual adjustment.

Compared to Dolby Pro Logic that is referred to a "3/1" system (left front, center, right front and just one surround channel), Dolby Digital features two surround channels, called stereo or split surrounds, each offering the same full range fidelity as the three front channels.

Sound of wide dynamic range reproduced by the five full range channels presents listeners much excitement that has never been experienced before. Precise sound orientation by the discrete digital sound processing expands realism that the original movie possesses.

LD and DVD are home audio formats that could benefit from Dolby Digital. In the near future, Dolby Digital will also be applied to DBS, CATV and HDTV. The ongoing release of Dolby Stereo Digital theatrical films now underway will provide an immediate source of Dolby Digital encoded video software.



Manufactured under license from Dolby Laboratories Licensing Corporation. "Dolby", "Pro Logic", and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation. Copyright 1992 Dolby Laboratories, Inc. All rights reserved.

The following original functions make the surround-sound effect of Dolby Digital become the most suitable for your audio system and the listening conditions.

- Dynamic range (sound scale) of source can be changed so that it will be suitable for the listening conditions.
- Output of low bass from any channel can be assigned to either the **MAIN SPEAKERS** terminals or **SUBWOOFER** terminal to maximize system performance.
- Output of LFE can be assigned to either the **MAIN SPEAKERS** terminals or **SUBWOOFER** terminal to maximize system performance.

Dolby Surround + DSP (CINEMA DSP)

Dolby Surround sound system shows its full ability in a large movie theater, because movie sounds are originally designed to be reproduced in a large movie theater using many speakers. It is difficult to create a sound environment similar to that of a movie theater in your listening room, because the room size, materials of inside walls, the number of speakers, etc. of your listening room is much different from those of a movie theater.

YAMAHA DSP technology made it possible to present you with nearly the same sound experience as that of a large movie theater in your listening room by compensating for lack of presence and dynamics in your listening room with its original digital sound fields combined with Dolby Surround sound field.


CINEMA DSP

The YAMAHA "CINEMA DSP" logo indicates those programs are created by the combination of Dolby Surround and YAMAHA DSP technology.

Dolby Pro Logic + 2 Digital Sound Fields

Digital sound fields are created on the presence side and the rear surround side of the Dolby Pro Logic Surround-decoded sound field respectively. They create a wide acoustic environment and emphasize surround-effect in the room, letting you feel much presence as if you are watching a movie in a popular Dolby Stereo theater.


This combination is available when the sound field program **DOLBY PRO LOGIC ENHANCED/DOLBY DIGITAL ENHANCED, 70 mm MOVIE THEATER/DIGITAL MOVIE THEATER** or **TV SPORTS** is selected, and the input signal of source is analog, PCM audio or encoded with the Dolby Digital in 2-channel.



Dolby Digital + 3 Digital Sound Fields


Digital sound fields are created on the presence side and the independent left and right surround sides of the Dolby Digital-decoded sound field respectively. They create a wide acoustic environment and much surround effect in the room without losing high channel separation. With wide dynamic range of Dolby Digital sound, this sound field combination lets you feel as if you are watching a movie in the newest Dolby Stereo Digital theater. This will be the most ideal home theater sound at the present time.

This combination is available when the sound field program **DOLBY PRO LOGIC ENHANCED/DOLBY DIGITAL ENHANCED, 70 mm MOVIE THEATER/DIGITAL MOVIE THEATER** or **TV SPORTS** is selected, and the input signal of source is encoded with the Dolby Digital (except in 2-channel).



CONTROLS AND THEIR FUNCTIONS

FRONT PANEL



1 STANDBY/ON

Press this switch to turn the power of this unit on. Press it again to turn this unit into the standby mode.

Standby mode

In this state, this unit consumes a very small quantity of power to receive infrared-signals from the remote control transmitter.

2 Remote control sensor

Receives signals from the remote control transmitter.

3 Display

Shows various information. (For details, refer to page 11.)

4 MEMORY (MAN'L/AUTO FM)

Press this button to store the broadcasting stations. When this button is pressed and held for more than three seconds, the automatic preset tuning begins.

5 EDIT

This button is used to exchange the places of two preset stations with each other.

6 TUNING MODE (AUTO/MAN'L MONO)

Press this button to switch the tuning mode to automatic or manual. To select the automatic tuning mode, press this button so that the "AUTO TUNING" indicator lights up on the display. To select the manual tuning mode, press this button so that the "AUTO TUNING" indicator goes off.

7 FM/AM

Press this button to switch the reception band to FM or AM.

8 TUNING UP/DOWN

This button is used for tuning. Press the UP side to tune in to higher frequencies, and press the DOWN side to tune in to lower frequencies.

9 TAPE/MD MON / EXT. DECODER

Press this button to play a tape or an MD. The "TAPE/MD MON" indicator lights up on the display. When you press the button next, the "TAPE/MD MON" indicator goes off and "EXT. DECDR" appears on the display and you can play the signal connected to the **EXTERNAL DECODER INPUT** terminals.

10 INPUT

Turn this selector to select the program source (VCR, VIDEO AUX, TV/DBS, DVD/LD, CD, TUNER, PHONO) to listen to or watch.

The name of the selected program source appears on the display.

11 INPUT MODE

Switches the DVD/LD and TV/DBS input signal mode (AUTO/ANALOG).


12 VOLUME

This control is used to raise or lower the volume level.

13 PHONES jack

When you use headphones, connect the headphones to the **PHONES** jack. You can listen to the sound to be output from the main speakers through headphones.

When using headphones only, set both **SPEAKERS A** and **B** to the OFF position and switch off the digital sound field processor (so that no DSP program name appears on the display) by pressing **EFFECT**.



14 SPEAKERS

Set **A** or **B** (or both **A** and **B**) to the ON position for the main speaker system (connected to this unit) you will use. Set it (or them) for the main speaker system you will not use to the OFF position.

15 A/B/C/D/E

Press this button to select a group (A to E) of preset stations.

16 Preset station number selector

Select a preset station number (1 to 8).

17 Tone controls

These controls are effective only for the sound from the main speakers.

BASS

Used to increase or decrease the low frequency response. The "0" position produces flat response.

TREBLE

Used to increase or decrease the high frequency response. The "0" position produces flat response.

18 BALANCE

This control is effective only for the sound from the main speakers.

Adjusts the balance of the output volume to the left and right speakers to compensate for sound imbalance caused by speaker location or listening room conditions.

19 TIME/LEVEL

Press this button to select the setting of delay time or speaker output levels in the TIME/LEVEL mode.

20 +/-

These buttons are used to adjust settings of the SET MENU mode and the TIME/LEVEL mode. In the TIME LEVEL mode, press **+** to increase delay time or speaker output levels. Press **-** to decrease delay time or speaker output levels.

21 SET MENU

Press this button to select functions in the SET MENU mode.

22 PROGRAM selector

Press **<** or **>** to select the DSP program.

The name of the selected program appears on the display.

23 EFFECT


Switches on and off the output from the center and rear speakers so that the sound becomes normal 2-channel.

* Even if the output from the center and rear speakers is off, when the Dolby Digital is decoded, the signals at all channels are distributed to the main channels and output from the main speakers.

24 VIDEO AUX terminals

Connect an auxiliary video or audio input source unit such as a camcorder to these terminals. The source connected to these terminals can be selected by **INPUT**.

DISPLAY PANEL



1 Multi-information display

Displays various information, for example station frequency, preset station number and name of selected input source.

2 MEMORY indicator

When **MEMORY** is pressed, this indicator flashes for about five seconds. During this period, the displayed station can be stored to the memory.

3 AUTO TUNING indicator

Lights up when this unit is in the automatic tuning mode.

4 TAPE/MD MON indicator

Lights up when the tape deck (or MD recorder etc.) is selected as the input source by pressing **TAPE/MD MON / EXT. DECODER** on the front panel or **TAPE/MD** on the remote control transmitter.

5 STEREO indicator

Lights up when an FM stereo broadcast with sufficient signal strength is received.

6 Signal-level meter

Indicates the signal level of the received station. If multipath interference is detected, the indication decreases.

7 DIGITAL, DSP and PRO LOGIC indicators

“**DIGITAL**” lights up when the built-in Dolby Digital decoder is on and the signals of selected source encoded with the Dolby Digital is not in 2-channel. “**DSP**” lights up when the built-in digital sound field processor is on, and “**PRO LOGIC**” lights up when the built-in Dolby Pro Logic Surround decoder is on. Depending on the selected DSP program, both “**DIGITAL**” and “**DSP**”, or both “**DSP**” and “**PRO LOGIC**” will light up.

8 SLEEP indicator

Lights up while the built-in SLEEP timer is functioning.

SPEAKER SETUP

SPEAKERS TO BE USED

This unit is designed to provide the best sound-field quality with a 5-speaker configuration, using main speakers, rear speakers and a center speaker.

The main speakers are used for the main source sound plus the effect sounds. They will probably be the speakers from your present stereo system. The rear speakers are used for the effect and surround sounds, and the center speaker is for the center sounds (dialog, vocals, etc.). If for some reason it is not practical to use a center speaker, you can do without it. Best results, however, are obtained with the full system.

The main speakers should be high performance models and have enough power handling capacity to accept the maximum output of your audio system.

Other speakers do not have to be equal to the main speakers. For precise sound localization, however, it is ideal to use high performance models that can reproduce sounds in the full range for the center speaker and the rear speakers.

Use of a subwoofer expands your sound field

It is also possible to further expand your system with the addition of a subwoofer and amplifier. The use of a subwoofer is effective not only for reinforcing bass frequencies from any or all channels, but also for reproducing the LFE (low frequency effect) sound with high fidelity when playing back a source with the Dolby Digital decoded. You may wish to choose the convenience of a YAMAHA Active Servo Processing Subwoofer System, which has its own built-in power amplifier.

SPEAKER CONFIGURATION

5-Speaker Configuration



This configuration is the most effective and recommended one. When playing back a source using the DSP program, **DOLBY PRO LOGIC/DOLBY DIGITAL, DOLBY PRO LOGIC ENHANCED/DOLBY DIGITAL ENHANCED, 70 mm MOVIE THEATER/DIGITAL MOVIE THEATER, MONO MOVIE** or **TV SPORTS**, or when playing back a source which contains center-channel signals (dialog, vocals, etc.) using any DSP program with the Dolby Digital decoded, conversations will be output from the center speaker and the ambience will be excellent.

Note: Set the CNTR (CENTER SPEAKER) mode to the "LARGE" or "SMALL" position. (For details, see page 22.)

4-Speaker Configuration


The center speaker is not used in this configuration. When playing back a source using the DSP program, **DOLBY PRO LOGIC/DOLBY DIGITAL, DOLBY PRO LOGIC ENHANCED/DOLBY DIGITAL ENHANCED, 70 mm MOVIE THEATER/DIGITAL MOVIE THEATER, MONO MOVIE** or **TV SPORTS**, or when playing back a source which contains center-channel signals (dialog, vocals, etc.) using any DSP program with the Dolby Digital decoded, the center sound is output from the left and the right main speakers. However, the sound effect of other programs will be the same as that of the 5-speaker configuration.

Note: Be sure to set the CNTR (CENTER SPEAKER) mode to the "NONE" position. (For details, see page 22.)



SPEAKER PLACEMENT

When you place the speakers, refer to the following diagram:



- Main:** The position of your present stereo speaker system.
- Rear:** Behind your listening position, facing slightly inward. Nearly 1.8 m (approx. 6 feet) up from the floor.
- Center:** Precisely between the main speakers. (To avoid interference with TV sets, use a magnetically shielded speaker.)
- Subwoofer:** The position of the subwoofer is not so critical because low bass tones are not highly directional.


CONNECTIONS

Never plug in this unit and other components until all connections are completed.

CONNECTIONS WITH OTHER COMPONENTS

When making connections between this unit and other components, be sure all connections are made correctly, that is to say L (left) to L, R (right) to R, "+" to "+" and "-" to "-". Also, refer to the owner's manual for each component to be connected to this unit.

* If you have YAMAHA components numbered as 1, 3, 4, etc. on the rear panel, connections can be made easily by making sure to connect the output (or input) terminals of each component to the same-numbered terminals of this unit.



*¹, *² : See the next page.

★¹

SWITCHED AC OUTLET(S)

(U.S.A., Canada, Singapore, China and General models)
 2 SWITCHED OUTLETS
 (Australia model) 1 SWITCHED OUTLET

Use these to connect the power cords from your components to this unit.

The power to the **SWITCHED** outlets is controlled by this unit's **STANDBY/ON** or the provided remote control transmitter's **POWER** and **STANDBY**. These outlets will supply power to any component whenever this unit is turned on.

The maximum power (total power consumption of components) that can be connected to the **SWITCHED AC OUTLET(S)** is 100 watts.


★²

GND terminal (For turntable use)

Connecting the ground wire of the turntable to the **GND** terminal will normally minimize hum, but in some cases better results may be obtained with the ground wire disconnected.

CONNECTING TO AN EXTERNAL DECODER

When using the DTS or other decoder with 6-channel discrete outputs, connect the **6CH DISCRETE OUTPUT** terminals of the decoder to the **EXTERNAL DECODER INPUT** terminals of this unit.



CONNECTING TO DIGITAL (COAXIAL AND/OR OPTICAL) TERMINALS


If your DVD (LD) player, TV/DBS tuner, etc. are equipped with coaxial or optical digital audio signal output terminals, they can be connected to this unit's **COAXIAL** and/or **OPTICAL** digital signal input terminals.

To make a connection between optical digital audio signal terminals, remove the cover from each terminal, and then connect them by using a commercially available optical fiber cable that conforms to EIAJ standards. Other cables might not function correctly.

Even if you connect an audio/video unit to the **COAXIAL** (or **OPTICAL**) terminal of this unit, you must keep the unit connected with the same named analog audio signal terminals of this unit, because digital signal cannot be recorded by a tape deck or VCR connected to this unit. You can switch the selection of input signals between "digital" and "analog" easily. (See page 29 for details.)


Notes

- When connecting an audio/video unit to both of the digital and analog terminals of this unit, make sure to connect to both terminals of the same name.
- Be sure to attach the covers when the **OPTICAL** terminals are not being used, in order to protect the terminals from dust.
- The input signal from the DVD/LD input terminals is selected in the following order of priority.
(input mode: AUTO position)
 - 1 **COAXIAL** terminal
 - 2 **OPTICAL** terminal
 - 3 ANALOG terminal
- All digital audio signal input terminals are applicable to the sampling frequency of 32 kHz, 44.1 kHz and 48 kHz.




CONNECTING TO VIDEO AUX TERMINALS (ON THE FRONT PANEL)

These terminals are used to connect any video input source, such as a camcorder, to this unit.



CONNECTING SPEAKERS



Note
Use speakers with the specified impedance shown on the rear panel of this unit.

Note on main speaker connections:
One or two speaker systems can be connected to this unit. If you use only one speaker system, connect it to either the **SPEAKERS A** or **B** terminals.

Note on a subwoofer connection:
You may wish to add a subwoofer to reinforce low frequencies or to output low bass sound from the subwoofer channel. If you have a subwoofer with built-in amplifier, including the YAMAHA Active Servo Processing Subwoofer System, connect the **SUBWOOFER OUTPUT** terminal of this unit to the input terminal of the subwoofer system. If you have an amplifier and a subwoofer, connect the **SUBWOOFER OUTPUT** terminal of this unit to the input terminal of the subwoofer amplifier, and then connect the speaker terminals of the subwoofer amplifier to the subwoofer. When the input signals to this unit are in normal 2-channel stereo, this terminal outputs only frequencies below 90 Hz from the main and center channels. When discrete signals are input to this unit and are selected as the input source, this terminal outputs signals from the subwoofer channel.

Note on center speaker connection:
Center speaker can be connected to this unit. Place it on or under the TV.

How to connect


Connect the **SPEAKERS** terminals to your speakers with wire of the proper gauge, cut as short as possible. If the connections are faulty, no sound will be heard from the speakers. Make sure that the polarity of the speaker wires is correct, that is the + and – markings are observed. If these wires are reversed, the sound will be unnatural and lack bass.

Caution

Do not let the bare speaker wires touch each other and do not let them touch any metal part of this unit. This could damage this unit and/or speakers.

For connecting to the MAIN SPEAKERS terminals


Red: positive (+)
Black: negative (–)



- ① Unscrew the knob.
- ② Insert the bare wire.
[Remove approx. 5 mm (1/4") insulation from the speaker wires.]
- ③ Tighten the knob and secure the wire.


For connecting to the REAR and CENTER SPEAKERS terminals

Red: positive (+)
Black: negative (–)



- ① Press the tab.
- ② Insert the bare wire.
[Remove approx. 5 mm (1/4") insulation from the speaker wires.]
- ③ Release the tab and secure the wire.

Banana plug connections are also possible (except for Singapore model). Simply insert the banana plug connector into the corresponding terminal.




IMPEDANCE SELECTOR SWITCH


WARNING

Do not change the **IMPEDANCE SELECTOR** switch setting while the power of this unit is on, otherwise this unit may be damaged.

IF THIS UNIT FAILS TO TURN ON WHEN THE STANDBY/ON SWITCH IS PRESSED, the **IMPEDANCE SELECTOR** switch may not be fully set to either end. If so, set the switch to either end fully.




Select the position whose requirements your speaker system meets.

 (Upper position)

Main: If you use one pair of main speakers, the impedance of each speaker must be 4Ω or higher.
If you use two pairs of main speakers, the impedance of each speaker must be 8Ω or higher.

Center: The impedance of the speaker must be 6Ω or higher.

Rear: The impedance of each speaker must be 6Ω or higher.

 (Lower position)


Main: If you use one pair of main speakers, the impedance of each speaker must be 8Ω or higher.
If you use two pairs of main speakers, the impedance of each speaker must be 16Ω or higher.

Center: The impedance of the speaker must be 8Ω or higher.

Rear: The impedance of each speaker must be 8Ω or higher.

ANTENNA CONNECTIONS

Each antenna should be correctly connected to the designated terminals, referring to the following diagram. Both AM and FM indoor antennas are included with this unit. In general, these antennas will probably provide sufficient signal strength. Nevertheless, a properly installed outdoor antenna will give clearer reception than an indoor one. If you experience poor reception quality, an outdoor antenna may result in improvement.



Connecting the AM loop antenna

- 1 1
- 2 2
- 3 3

Orient so that the best reception is obtained.


- * The AM loop antenna should be placed away from this unit. The antenna may be hung on a wall.
- * The AM loop antenna always should be connected, even if an outdoor AM antenna is connected to this unit.

GND TERMINAL

For maximum safety and minimum interference, connect the **GND** terminal to a good earth ground. A good earth ground is a metal stake driven into moist earth.

Notes

- When connecting the indoor FM antenna, insert its connector into the **FM ANT** terminal firmly.
- If you need an outdoor FM antenna to improve FM reception quality, either 300-ohm feeder or coaxial cable may be used. In locations troubled by electrical interference, coaxial cable is preferable.



ADJUSTMENTS BEFORE USING THIS UNIT

SELECTING THE OUTPUT MODES

This unit provides you the following five functions to determine the method of distributing output signals to speakers suitable for your audio system. When speaker connections are all completed, select a proper position on each function to make the best use of your speaker system. (See "ADJUSTMENTS IN THE 'SET MENU' MODE" on page 43.)

- | | | |
|---------------------------------|-------------------------------|-------------------------------|
| 1. CNTR (CENTER SPEAKER) | 2. REAR (REAR SPEAKER) | 3. MAIN (MAIN SPEAKER) |
| 4. BASS (LFE/BASS OUT) | 5. M.LVL (MAIN LEVEL) | |

DESCRIPTION OF EACH FUNCTION

1. CNTR (CENTER SPEAKER)

Choices: **LARGE/SMALL/NONE**
Preset position: **LARGE**

- LARGE:** Select this position when your center speaker is approximately the same size as the main speakers.
- SMALL:** Select this position when you use a center speaker that is smaller than the main speakers.
In this position, low bass signals (below 90 Hz) at the center channel are output from the main speakers (or the **SUBWOOFER OUTPUT** terminal if the **SMALL** position is selected on "3. MAIN" and the SW position is selected on "4. BASS").
- NONE:** Select this position when you do not have a center speaker. The center channel sound will be output from the left and right main speakers.

2. REAR (REAR SPEAKER)

Choices: **LARGE/SMALL**
Preset position: **LARGE**

- LARGE:** Select this position if your rear speakers have a high ability for bass reproduction, or a subwoofer is connected to the rear speaker in parallel.
In this position, full range signals are output from the rear speakers.
- SMALL:** Select this position if your rear speakers do not have a high ability for bass reproduction.
In this position, low bass signals (below 90 Hz) at the rear channels are output from the **SUBWOOFER OUTPUT** terminal (or the main speakers if the **MAIN** position is selected on "4. BASS").

3. MAIN (MAIN SPEAKER)

Choices: **LARGE/SMALL**
Preset position: **LARGE**

- LARGE:** Select this position if your main speakers have a high ability for bass reproduction.
In this position, full range signals present at the main channels are output from the main speakers.
- SMALL:** Select this position if your main speakers do not have a high ability for bass reproduction. However, if your system does not include a subwoofer, do not select this position.
In this position, low bass signals (below 90 Hz) at the main channels are output from the **SUBWOOFER OUTPUT** terminal if the SW or BOTH position is selected on "4. BASS".

4. BASS (LFE/BASS OUT)

Choices: **SW/MAIN/BOTH**
Preset position: **SW**

- MAIN:** Select this position if your system does not include a subwoofer.
In this position, full range signals present at the main channels, signals from the LFE channel and other low bass signals that are selected on "1. CNTR" to "3. MAIN" to be distributed from other channels are output from the main speakers.
- SW/BOTH:** Select either the SW or BOTH position if your system includes a subwoofer.
In either position, signals at LFE channel and other low bass signals that are selected on "1. CNTR" to "3. MAIN" to be distributed from other channels are output from the **SUBWOOFER OUTPUT** terminal. When the **LARGE** position is selected on "3. MAIN", in the SW position, no signal is distributed from the main channels to the **SUBWOOFER OUTPUT** terminal, however in the **BOTH** position, low bass signals from the main channels are output to both of the main speakers and the **SUBWOOFER OUTPUT** terminal.



5. M.LVL (MAIN LEVEL)

Choices: **NORMAL (NRML)/-10 dB**
Preset position: **NORMAL (NRML)**


- NORMAL (NRML):** Normally select this position.
- 10 dB:** Select this position if the sound output from the main speakers is too loud and cannot be balanced with the sound output from the center and rear speakers. In this position, the sound output from the main speakers is attenuated.

ADJUSTING METHOD


Operations should be made while watching the information on this unit's display.




If you are using the remote control transmitter, set the **SELECTOR DIAL** to the AMP/TUN or DSP position on the remote control transmitter.




1 Turn the power on.





2 Press **SET MENU** once or more to select the title "1. CNTR" (so that "CNTR" appears on the display).



* After pressing **SET MENU** once on the remote control transmitter, you can also select the title by pressing ∇. (Pressing ∆ goes back one selection.)



3 Press + or – once or more to select the position you want.




4 Repeat steps 2 and 3 to change selections on "2. REAR", "3. MAIN", "4. BASS" and/or "5. M.LVL" in the same way.

SPEAKER BALANCE ADJUSTMENT

This procedure lets you adjust the sound output level balance between the main, center and rear speakers using the built-in test tone generator. When this adjustment is performed, the sound output level heard at the listening position will be the same from each speaker. This is important for the best performance of the digital sound field processor, the Dolby Digital decoder and the Dolby Pro Logic Surround decoder.

The adjustment of each speaker output level should be done at your listening position with the remote control transmitter. After completing the adjustment of the output level for each speaker, use VOLUME (^ v) on the remote control transmitter at your listening position to check if the adjustments are satisfactory.



Set the **SELECTOR DIAL** to the AMP/TUN or DSP position on the remote control transmitter.

2 Turn the power on.

Front panel **Remote control**

1 Set **VOLUME** to the "∞" position.


Front panel

3 Select the main speakers to be used.

Front panel


* If you use two main speaker systems, press both **A** and **B**.

4 Set **BASS**, **TREBLE** and **BALANCE** to the “0” position.



5 Press **TEST** (so that “TEST LEFT” appears on the display).


Remote control




Appears.

6 Turn up the volume.

Remote control



You will hear a test tone (like pink noise) from the left main speaker, then the center speaker, then the right main speaker, then the right rear speaker, and then the left rear speaker, for about two seconds each. The display changes as shown below.



* If the function “1. CNTR” in the SET MENU mode is set to the NONE position, you will hear the center channel test tone from the left and right main speakers.

7 Adjust **BALANCE** so that the sound output level of the left main speaker and the right main speaker is the same.

Front panel




- 8** Adjust the sound output levels of the center speaker and the rear speakers so that they become almost as same as that of the main speakers.

Remote control




- a) Press Δ or ∇ once or more so that "CENTER", "R SUR." or "L SUR." appears on the display.
 * Select "CENTER" to adjust the output level of the center speaker and select "R SUR." or "L SUR." to adjust the output level of the rear speakers.

Remote control



- b) Adjust the level.
 * Pressing \triangleright raises and \triangleleft lowers the level.
 * While adjusting, the test tone is fixed on the selected speaker.

Remote control



- 9** Press **TEST** once more to cancel the test tone.

Remote control




"TEST" disappears.

Notes

- Once you have completed these adjustments, you can adjust the overall sound level on your audio system by using **VOLUME** (or **VOLUME** (\wedge \vee) on the remote control transmitter) only.
- If you use external power amplifiers, you may also use their volume controls to achieve the proper balance.
- If the function "1. CNTR" in the SET MENU mode is set to the NONE position, the sound output level of the center speaker cannot be adjusted in step 8. The center sound is automatically output from the left and right main speakers.
- If there is insufficient sound output from the center and rear speakers, you may decrease the main speaker output level by setting "5. M.LVL" to "-10 dB".

BASIC OPERATIONS

TO PLAY A SOURCE



Notes

- Set the **SELECTOR DIAL** to the AMP/TUN position on the remote control transmitter.
- To operate the CD player, DVD/LD player, tape deck, MD recorder, or other components using this remote control transmitter, set the **SELECTOR DIAL** to the component to be used. (See "SETUP CODES" on page 50.)

1 Set **VOLUME** to the "∞" position.

Front panel

2 Turn the power on.

Front panel

Remote control

or

3 Select the desired input source by using **INPUT**.
(For video sources, turn the TV/monitor ON.)
See page 29 if you are using an external decoder or playing a tape or an MD.


Front panel

Remote control


or

The name of the selected input source will appear on the display.

4 For the DVD/LD or TV/DBS source, the current input mode is also shown.
 * To change the input mode for the DVD/LD or TV/DBS source, press **INPUT MODE** (or the button that you have pressed to select the input source in step 3 on the remote control transmitter) once or more until the desired input mode (AUTO or ANALOG) is shown on the display. (See page 29 for details on switching the input mode.)




5 Select the main speakers to be used.



* If you use two main speaker systems, press both **A** and **B**.

6 Play the source. (For detailed information on tuning, see page 31.)


7 Adjust the volume to the desired output level.



8 If desired, adjust **BASS**, **TREBLE**, **BALANCE**, etc. (see below) and use the digital sound field processor. (see page 37.)

Selecting the SPEAKER system

Because one or two speaker systems (as main speakers) can be connected to this unit, **SPEAKERS** allow you to select speaker system **A** or **B**, or both at once.



Adjusting the BALANCE control

Adjust the balance of the output volume from the left and right speakers to compensate for sound imbalances caused by speaker location or listening room conditions.




Note

This control is effective only for the sound from the main speakers.

Adjusting the BASS and TREBLE controls

BASS: Turn this clockwise to increase (or counter-clockwise to decrease) the low frequency response.

TREBLE: Turn this clockwise to increase (or counter-clockwise to decrease) the high frequency response.




Note

These controls are effective only for the sound from the main speakers.

To play a tape or an MD


Press **TAPE/MD MON / EXT. DECODER** so that the "TAPE/MD MON" indicator lights up on the display, then play the tape or MD.



To stop playing the tape or MD, press **TAPE/MD MON / EXT. DECODER** twice so that the "TAPE/MD MON" indicator and "EXT. DECDR" disappear from the display and the play stops (or press **TAPE/MD** once on the remote control transmitter).

To use a decoder connected to the EXTERNAL DECODER INPUT terminals

Press **TAPE/MD MON / EXT. DECODER** once or more so that the "EXT. DECDR" appears on the display. Start the play by operating the DTS or other external decoder, DVD player or LD player.



To stop playing, press **TAPE/MD MON / EXT. DECODER** once so that "EXT. DECDR" disappears from the display and the play stops (or press **EXT. DEC.** on the remote control transmitter).

When you finish using this unit

Press **STANDBY/ON** on the front panel again or **STANDBY** on the remote control transmitter to turn this unit into the standby mode.

Notes on using INPUT

- By using **INPUT**, you can select the program sources connected to the input terminals on the rear panel.
- To play a video source connected to the **VIDEO AUX** terminals on the front panel, set **INPUT** to the VIDEO AUX position.
- The audio source selected by **INPUT** will not be played if the "TAPE/MD MON" indicator lights up or if "EXT. DECDR" is displayed.
- If you select **INPUT** for a video source without canceling the selection of **TAPE/MD MON / EXT. DECODER** on the front panel (or, **TAPE/MD** or **EXT. DEC.** on the remote control transmitter), the playback result will be the video image from the video source and the sound from the input source selected by **TAPE/MD MON / EXT. DECODER** on the front panel (or, **TAPE/MD** or **EXT. DEC.** on the remote control transmitter).

- Once you play a video source, its video image will not be interrupted even if **INPUT** for an audio source is selected.
- When you select an input source by using **INPUT**, the DSP program (or no DSP program) that was used when the same input source was selected the last time, will be automatically recalled.

Switching the input mode (for DVD/LD and TV/DBS)

This unit allows you to switch the input mode only for sources connected to the DVD/LD and TV/DBS input terminals (on the rear panel of this unit) that input two or three types of signals.

The following two input modes are provided.

AUTO: For the source connected to the DVD/LD input terminals:

This mode is automatically selected when you turn the power of this unit on. In this mode, input signal is automatically selected in the following order of priority.

1. Digital input signal from the **COAXIAL** terminal
2. Digital input signal from the **OPTICAL** terminal
3. Analog input signal

For the source connected to the TV/DBS input terminals:

This mode is selected when you turn the power of this unit on if the AUTO position is selected on "10. INPUT" in the SET MENU mode. (For details, see page 44.) In this mode, input signal is automatically selected in the following order of priority.

1. Digital input signal from the **OPTICAL** terminal
2. Analog input signal


ANALOG:

In this mode, only analog input signal is selected even if a digital signal is input at the same time. Select this mode when you want to use the analog input signal instead of the digital input signal.

Notes on input mode selection

- To playback a source with the Dolby Digital-decoded, set the input mode to AUTO.
- For the TV/DBS source only, the input mode selected on the function "10. INPUT" in the SET MENU mode is effective when you turn the power of this unit on.
- When you want to enjoy a source which has normal 2-channel signals with a Dolby Pro Logic Surround program, select the ANALOG mode.
- In the AUTO mode, there may be a case depending on some LD players or DVD players that when you make a search on a source encoded with the Dolby Digital during the play and then the play is restored, sound output is interrupted for a moment because the digital input signal is selected again.

TO RECORD A SOURCE TO TAPE OR MD



1 Select the source to be recorded.

Front panel
 INPUT
 VCR • V-AUX • TV/DBS • DVD/LD • CD • TUNER • PHONO

Remote control

4 When the tape deck or MD recorder is used for recording, you can monitor the sounds being recorded by pressing **TAPE/MD MON / EXT. DECODER** so that the “TAPE/MD MON” indicator lights up on the display.

Front panel
 TAPE/MD MON / EXT. DECODER

Remote control
 MOVIE THEATER TAPE/MD

2 Play the source and then turn **VOLUME** up to confirm the input source. (For detailed information on tuning, see page 31.)

Front panel
 VOLUME

Remote control

3 Begin recording on the tape deck, MD recorder or VCR connected to this unit.


Notes

- The settings of DSP and **VOLUME**, **BASS**, **TREBLE** and **BALANCE** have no effect on the material being recorded.
- A source that is connected to this unit through digital terminals only cannot be recorded by a tape deck or VCR connected to this unit.
- Please check the copyright laws in your country to record from records, compact discs, radio, etc. Recording of copyright material may infringe copyright laws.

If you watch a video software that uses scrambled or encoded signals to prevent it from being dubbed, there may be a case that the picture itself will be affected by those signals.

TUNING OPERATIONS

Set the **SELECTOR DIAL** to the AMP/TUN position on the remote control transmitter and select the tuner by using **INPUT**. Normally, if station signals are strong and there is no interference, quick automatic-search tuning (AUTOMATIC TUNING) is possible. However, if the signal from the station you want to select is weak, you must tune in to it manually (MANUAL TUNING).



AUTOMATIC TUNING

- 1** Select the reception band (FM or AM) confirming it on the display.

Front panel
- 2** Press **TUNING MODE** (so that the "AUTO TUNING" indicator lights up on the display).

Front panel
- 3** To tune in to a higher frequency, press the UP side of **TUNING** once.
To tune in to a lower frequency, press the DOWN side of **TUNING** once.

Front panel

* If the station where the tuning search stops is not the desired one, press once more.
* If the tuning search does not stop at the desired station (because the signal from the station is weak), operate the manual tuning procedure.

MANUAL TUNING

- 1** Select the reception band (FM or AM) confirming it on the display.

Front panel
- 2** Press **TUNING MODE**.

Front panel
- 3** Tune in to the desired station manually.

Front panel



* To continue the tuning search, press and hold the button.

Note

- If you tune in to an FM station manually, it is received in monaural mode automatically to increase the signal quality.

MANUAL PRESET TUNING

This unit can store station frequencies selected by tuning. With this function, you can recall any desired station simply by selecting the preset station number with which it was stored. Up to 40 stations (8 stations x 5 groups) can be stored.




To store stations


1 Tune in to the desired station.
(See the previous page for tuning procedure.)

2 Press **A/B/C/D/E** once or more to select the desired group (A to E) of preset stations confirming it on the display.


Front panel



Remote control




or



3 Press **MEMORY** (so that the "MEMORY" indicator flashes for about five seconds).



Front panel



Flashes.

4 Select the preset station number with which you want to store the station before the "MEMORY" indicator goes off from the display.

Front panel




The displayed station has been stored to A1.

- * In the same way, store other stations to A2, A3 ... A8.
- * You can store more stations to preset station numbers in other groups in the same way by selecting other groups in step 2.

To recall a preset station

(See the illustration on previous page.)



Notes


- A new setting can be stored in place of the former one.
- For presets, the setting of the reception mode (stereo or monaural) is stored along with the station frequency.

Memory back-up

The memory back-up circuit prevents the stored data from being lost even if this unit is turned into the standby mode, or the power plug is disconnected from the AC outlet, or the power is cut due to temporary power failure. If, however, the power is cut for more than one week, the memory may be erased. If so, it can be re-stored by simply following the preset tuning procedures.

AUTOMATIC PRESET TUNING (For FM stations only)

You can also make use of an automatic preset tuning function for FM stations only. Using this function, this unit performs automatic tuning and sequentially stores FM stations with strong signals. Up to 40 stations are stored automatically in the same way as in the manual preset tuning method on page 32. Note that a new setting can be stored in place of the former one.



To store stations



- 1** Select the FM.

Front panel




- 2** Press **TUNING MODE** (so that the “AUTO TUNING” indicator lights up on the display).

Front panel




- 3** Press **MEMORY** and hold for about three seconds.

Front panel



- 4** To tune in to higher frequencies, press the UP side of **TUNING** once.
To tune in to lower frequencies, press the DOWN side of **TUNING** once.

Front panel



- * If **TUNING** is not pressed, in a while, the automatic preset tuning begins automatically toward higher frequencies.

The automatic preset tuning begins from the frequency currently displayed. Received stations are stored to A1, A2 ... A8 sequentially.

- * If more than 8 stations are received, they are also stored to the preset station numbers in other groups (B, C, D and E) in that order.

If you want to store the first station received by the automatic preset tuning to a desired preset station number.

For example, if you want to store the first received station to C5, select “C5” while “A1”, the “MEMORY” indicator and the “AUTO TUNING” indicator flash after pressing **MEMORY** in step 3. Then press **TUNING**. The first received station is stored to C5, and next stations to C6, C7 ... sequentially.

If stations are stored up to E8, automatic preset tuning stops automatically.

When automatic preset tuning is finished


The display shows the frequency of the last preset station. Check the contents and the number of preset stations by following the procedures in the section “To recall a preset station” on page 33.

Notes

- You can replace a preset station with another FM or AM station manually by simply following the procedures in the section “To store stations” on page 32.
- Even if the number of received stations is not enough to be stored up to E8, the search is finished automatically after searching all frequencies.
- With this function, only FM stations with sufficient signal strength are stored automatically. If the station you want to store is weak in signal strength, tune in to it in monaural manually and store it by following the procedures in the section “To store stations” on page 32.

EXCHANGING PRESET STATIONS

You can exchange the places of two preset stations with each other as shown below.



Example

If you want to shift the preset station on E1 to A5, and vice versa.

1 Recall the preset station on E1 (by following the procedures in the section “To recall a preset station” on page 33).

2 Press **EDIT**.

Front Panel

Flashes.

3 Next, recall the preset station on A5 by following the same procedures as in step 1.

Flashes.

4 Press **EDIT** once more.

Front Panel


Shows the exchange of stations is completed.

SETTING THE SLEEP TIMER

If you use the SLEEP timer of this unit, you can make this unit automatically switch to the standby mode. When you are going to sleep while enjoying a broadcast or other desired input source, this timer function is useful. The SLEEP timer can be controlled only with the remote control transmitter.

Notes

- To set the SLEEP timer for this unit, set the **SELECTOR DIAL** to a position other than the TV position. To set the SLEEP timer for your TV, set the **SELECTOR DIAL** to the TV position.
- The components on which the SLEEP timer is effective are the sources connected to the **SWITCHED AC OUTLET(S)** on the rear panel of this unit.




To set the SLEEP time

- 1 Press **SLEEP** once or more to select the desired SLEEP time.

Remote control




Indicates the SLEEP time.



Flashes.

Whenever **SLEEP** is pressed, the SLEEP time will change as follows.

(Minutes)



After a while, the "SLEEP" indicator lights up and the display returns to the indication before the SLEEP timer was set.

- 2 The unit will be switched to the standby mode automatically at the selected SLEEP time.

To cancel the selected SLEEP time

Remote control



Press **SLEEP** once or more so that "SLEEP OFF" appears on the display. (It will soon disappear and the "SLEEP" indicator will go off from the display.)

Note

The SLEEP timer setting can also be canceled by tuning this unit into the standby mode with **STANDBY/ON** on the front panel (or **STANDBY** on the remote control transmitter) or disconnecting the power plug of this unit from the AC outlet.

USING DIGITAL SOUND FIELD PROCESSOR (DSP)

This unit incorporates a sophisticated, multi-program digital sound field processor. The processor allows you to electronically expand and change the shape of the audio sound field from both audio and video sources, creating a theater-like experience in your listening room. You can create an excellent audio sound field by selecting a suitable sound field program (this will, of course, depend on what you are listening to), and adding any desired adjustments.

The following list gives you a brief description of the sound fields produced by each of the DSP programs. Keep in mind that most of these are precise digital recreations of actual acoustic environments. The data for these sound fields was recorded at actual locations using sophisticated sound field measurement equipment.

Note

The channel level balance between the left and right rear speakers may vary depending on the sound field you are listening to. This is due to the fact that most of these sound field are re-creation of actual acoustic environments.



BRIEF OVERVIEW OF DIGITAL SOUND FIELD PROGRAMS

| No. | PROGRAM | FEATURE |
|-----|---|---|
| 1 | <p>DOLBY PRO LOGIC (<input type="checkbox"/> PRO LOGIC)</p> <p>Functions when the input signal is analog or PCM audio, or encoded with the Dolby Digital in 2-channel. Speaker output: main, center, rear</p> <p>DOLBY DIGITAL (<input checked="" type="checkbox"/> DIGITAL)</p> <p>Functions when the input signal is encoded with the Dolby Digital (not in 2-channel). Speaker output: main, center, rear</p> | <p>Reproduces video discs, video tapes and similar sources which are Dolby Surround encoded and bear the "DOLBY SURROUND" logo.</p> <p>The built-in Dolby Pro Logic Surround decoder or Dolby Digital decoder precisely reproduces sounds and sound effects of a source encoded with Dolby Surround. The realization of a highly efficient decoding process improves crosstalk and channel separation and makes sound positioning smoother and more precise.</p> |
| 2 | <p>DOLBY PRO LOGIC ENHANCED (<input checked="" type="checkbox"/> DSP <input checked="" type="checkbox"/> PRO LOGIC)</p> <p>Functions when the input signal is analog or PCM audio, or encoded with the Dolby Digital in 2-channel. Speaker output: main, center, rear</p> <p>DOLBY DIGITAL ENHANCED (<input checked="" type="checkbox"/> DIGITAL <input checked="" type="checkbox"/> DSP)</p> <p>Functions when the input signal is encoded with the Dolby Digital (not in 2-channel). Speaker output: main, center, rear</p> | <p>Reproduces video discs, video tapes and similar sources which are Dolby Surround encoded and bear the "DOLBY SURROUND" logo.</p> <p>This program ideally simulates the multi-surround speaker systems of the 35 mm film theater. The Dolby Surround decoding and the digital sound field processing is precisely performed without altering the original sound orientation. The surround effects produced by this sound field folds around the viewer naturally from the rear to the left and right and toward the screen.</p> <p>Note: If the main channel sound is considerably altered by overadjustment of BASS or TREBLE, the relationship with the rear channels may produce an unnatural effect.</p> |
| 3 | <p>70 mm MOVIE THEATER (<input checked="" type="checkbox"/> DSP <input checked="" type="checkbox"/> PRO LOGIC)</p> <p>Functions when the input signal is analog or PCM audio, or encoded with the Dolby Digital in 2-channel. Speaker output: main, center, rear</p> <p>DIGITAL MOVIE THEATER (<input checked="" type="checkbox"/> DIGITAL <input checked="" type="checkbox"/> DSP)</p> <p>Functions when the input signal is encoded with the Dolby Digital (not in 2-channel). Speaker output: main, center, rear</p> | <p>Ideal for reproducing video discs, video tapes and similar sources which are Dolby Surround encoded and bear the "DOLBY SURROUND" logo.</p> <p>This program is ideal for precisely reproducing the sound design of the newest 70 mm/Dolby Digital multi-track films. The sound field is made to be similar to that of the newest movie theaters, so the reverberations of the sound field itself are restrained as much as possible. The three dimensional feeling of the sound field is emphasized, and dialog is precisely oriented on the screen. You can enjoy watching Sci-Fi, adventure movies, etc. with considerable presence.</p> |

| No. | PROGRAM | FEATURE |
|-----|---|--|
| 4 | <p>MONO MOVIE (DSP) Functions when the input signal is analog or PCM audio, or encoded with the Dolby Digital in 2-channel. Speaker output: main, center, rear</p> <p>(DIGITAL DSP) Functions when the input signal is encoded with the Dolby Digital (not in 2-channel). Speaker output: main, center, rear</p> | <p>This program is designed specifically to enhance mono source programs. Compared to a strictly mono setting, the sound image created in this mode is wider and slightly forward of the speaker pair, lending an immediacy to the overall sound. It is particularly effective when used with old mono movies, news broadcasting and dialog.</p> |
| 5 | <p>TV SPORTS (DSP) Functions when the input signal is analog or PCM audio, or encoded with the Dolby Digital in 2-channel. Speaker output: main, center, rear</p> <p>(DIGITAL DSP) Functions when the input signal is encoded with the Dolby Digital (not in 2-channel). Speaker output: main, center, rear</p> | <p>This program is furnished with a tight sound field in which the sound will not spread excessively on the front side, but the rear surround side produces a dynamic sound expansion. This program is the most suitable for sports programs.</p> |
| 6 | <p>DISCO (DSP) Functions when the input signal is analog or PCM audio, or encoded with the Dolby Digital in 2-channel. Speaker output: main, rear</p> <p>(DIGITAL DSP) Functions when the input signal is encoded with the Dolby Digital (not in 2-channel). Speaker output: main, center, rear</p> | <p>This program recreates the acoustic environment of a lively disco in the heart of a very lively city. The sound is dense and highly concentrated. It is also characterized by a high-energy, "immediate" sound.</p> |
| 7 | <p>ROCK CONCERT (DSP) Functions when the input signal is analog or PCM audio, or encoded with the Dolby Digital in 2-channel. Speaker output: main, rear</p> <p>(DIGITAL DSP) Functions when the input signal is encoded with the Dolby Digital (not in 2-channel). Speaker output: main, center, rear</p> | <p>This program is ideally suited for rock music. You will experience a very dynamic and lively sound field.</p> |
| 8 | <p>CONCERT HALL (DSP) Functions when the input signal is analog or PCM audio, or encoded with the Dolby Digital in 2-channel. Speaker output: main, rear</p> <p>(DIGITAL DSP) Functions when the input signal is encoded with the Dolby Digital (not in 2-channel). Speaker output: main, center, rear</p> | <p>In this program, the center will appear to be deep behind the main speakers, creating an expansive, large hall ambience. Orchestra and opera music are suited to this sound field.</p> |

Note: When the NONE position is selected on "1. CNTR" in the SET MENU mode, no sound is output from the center speaker(s).

PLAYING A SOURCE WITH THE DIGITAL SOUND FIELD PROCESSOR (DSP) EFFECT





1 Follow steps 1 to 7 shown in “BASIC OPERATIONS” on pages 27 to 28.


2 Select the desired DSP program that is suitable for the source.

Front panel

Remote control



or



Press DSP. While the indicator lights up for about three seconds, select a DSP program using the numeric buttons (1 to 8).

* If the **SELECTOR DIAL** is set to the DSP position, you can also select a DSP program using the numeric buttons (1 to 8).



The name of selected program appears on the display.

3 If desired, adjust the delay time and the output level of each speaker. (For details, see pages 41 and 42.)

Notes


- You can select the program for each of the input sources. Once you select a program, it is linked with the input source selected at that time. So, when you select the input source next time, the same program is automatically called.
- If you prefer to cancel the DSP, press **EFFECT** or **EFCT ON/OFF**. The sound will be the normal 2-channel stereo without surround sound effect.
- When a monaural sound source is played with **DOLBY PRO LOGIC** or **DOLBY PRO LOGIC ENHANCED**, no sound is heard from the main speakers and the rear speakers. Sound is heard only from the center speaker. However, if the NONE position is selected on “1. CNTR” in the SET MENU mode, the main speakers output the sound of the center channel.
- If the main-source sound is considerably altered by overadjustment of **BASS** or **TREBLE** when this unit’s Dolby Pro Logic Surround decoder or Dolby Digital decoder is used, the relationship between the center and rear channels may produce an unnatural effect.

This unit incorporates a Dolby Digital decoder and a Dolby Pro Logic Surround decoder for multi-channel sound reproduction of sources encoded with Dolby Surround. The operation of these decoders can be controlled by selecting a corresponding DSP program including the combined operation of YAMAHA DSP and Dolby Digital or Dolby Pro Logic Surround.

To enjoy a video source with the Dolby Pro Logic Surround or Dolby Digital decoded

When you select the program **DOLBY PRO LOGIC/DOLBY DIGITAL**, **DOLBY PRO LOGIC ENHANCED/DOLBY DIGITAL ENHANCED** or **70 mm MOVIE THEATER/DIGITAL MOVIE THEATER**, and the input signal of the source is 2-channel stereo, Dolby Pro Logic Surround is decoded. When some program is selected and the input signal of the source is encoded with Dolby Digital, Dolby Digital is automatically decoded.

* The following indicators on the display show you what sound processing is being made.



* In addition, for the program **DOLBY PRO LOGIC/DOLBY DIGITAL**, **DOLBY PRO LOGIC ENHANCED/DOLBY DIGITAL ENHANCED** or **70 mm MOVIE THEATER/DIGITAL MOVIE THEATER**, the name of the program on the display will change according to the type of decoding. (For details, see page 37.)

Note


If the input signals of the source are encoded with Dolby Digital in 2-channel only, the sound processing for them is similar to that for analog or PCM audio signals.

To cancel the effect sound

EFFECT on the front panel and **EFCT ON/OFF** on the remote control transmitter make it simple to compare the normal stereo sound with the fully processed effect sound.

To cancel the effect sound and monitor only the main sound, press **EFFECT** or **EFCT ON/OFF**. Press **EFFECT** or **EFCT ON/OFF** once more to turn effect sounds on.

Front panel



or

Remote control




Notes

- If the effect sound is canceled when signals encoded with Dolby Digital are input to this unit, signals of all channels are mixed and are output from the main speakers.
- If **EFFECT** or **EFCT ON/OFF** is pressed to turn effect sounds off when the Dolby Digital is decoded, it may happen that the sound is output faintly or not output normally depending on the source. In that case, press **EFFECT** or **EFCT ON/OFF** to turn effect sounds on, or use input signals not encoded with Dolby Digital.


ADJUSTING DELAY TIME AND SPEAKER OUTPUT LEVELS

When using the digital sound field processor including the Dolby Pro Logic Surround decoder or the Dolby Digital decoder, you can adjust the delay time between the main sound and effect sound, and each speaker's output level as you prefer.




Adjusting method

If you are using the remote control transmitter, set the **SELECTOR DIAL** to the AMP/TUN or DSP position on the remote control transmitter.




2 Press **+** or **-** to adjust the settings for delay time or speaker output levels.

Front panel **Remote control**




3 Repeat steps 1 to 3 to adjust settings on any other item.

1 Press **TIME/LEVEL** once or more until the name of item which you want to adjust appears on the display.



* After pressing **TIME/LEVEL** once on the remote control transmitter, you can also select the name of item by pressing ∇ .

When pressed, the selection changes as follows:



* Pressing Δ on the remote control transmitter changes the selection in the reverse order.

* Depending on the mode of this unit, you cannot select all items.

Adjusting delay time

You can adjust the time difference between the beginning of the sound from the main speakers and the beginning of the effect sound from the rear speakers.

The larger the value, the later the effect sound is generated.

This adjustment can be made to all programs individually.

Notes

- Adding too much delay will cause an unnatural effect with some sources.
- When + or – is pressed, the sound is momentarily interrupted.

| Program | Control range (ms) | Preset value |
|-----------------------------|--------------------|--------------|
| 1. DOLBY PRO LOGIC | 15 to 30 | 20 |
| DOLBY DIGITAL | 0 to 15 | 5 |
| 2. DOLBY PRO LOGIC ENHANCED | 15 to 30 | 20 |
| DOLBY DIGITAL ENHANCED | 0 to 15 | 5 |
| 3. 70 mm MOVIE THEATER | 15 to 30 | 20 |
| DIGITAL MOVIE THEATER | 1 to 99 | 16 |
| 4. MONO MOVIE | 1 to 99 | 49 |
| 5. TV SPORTS | 1 to 99 | 9 |
| 6. DISCO | 1 to 99 | 40 |
| 7. ROCK CONCERT | 1 to 99 | 16 |
| 8. CONCERT HALL | 1 to 99 | 44 |

Adjusting output level of the center, right rear and left rear speakers, and subwoofer

If desired, you can adjust the sound output level of each speaker even if the output level is already set in "SPEAKER BALANCE ADJUSTMENT" on pages 24 to 26.

Notes

- Output level of the center speaker cannot be adjusted when the program **DISCO**, **ROCK CONCERT** or **CONCERT HALL** is selected, and the input signal is analog, PCM audio, or encoded with Dolby Digital in 2-channel.

- If the function "1. CNTR" in the SET MENU mode is set to the NONE position, the sound output level of the center speaker cannot be adjusted. This is because, in this mode, the center sound is automatically output from the left and right main speakers.
- Once the output level is adjusted, the level will be the same for all digital sound field programs.

| Speakers | Control range (dB) | Preset value |
|-----------------------|--------------------|--------------|
| CENTER | MIN, -20 to +10 | 0 |
| RIGHT SURROUND (Rear) | MIN, -20 to +10 | 0 |
| LEFT SURROUND (Rear) | MIN, -20 to +10 | 0 |
| SUBWOOFER | MIN, -20 to 0 | 0 |

Note

The values of the delay time, center/rear/subwoofer output level you set the last time will remain memorized even when this unit is in the standby mode. However, if the power cord is kept disconnected for more than one week, these values will automatically change back to the original factory settings.

ADJUSTMENTS IN THE “SET MENU” MODE

The following ten types of functions maximize the performance of your system and expand your enjoyment for audio listening and video watching.

1. **CNTR (CENTER SPEAKER)**
2. **REAR (REAR SPEAKER)**
3. **MAIN (MAIN SPEAKER)**
4. **BASS (LFE/BASS OUT)**
5. **M.LVL (MAIN LEVEL)**
6. **LFE (LFE LEVEL)**
7. **D.RNG (DYNAMIC RANGE)**
8. **C.DELAY (CENTER DELAY)**
9. **GUARD (MEMORY GUARD)**
10. **INPUT (INPUT MODE)**

For details on “1. CNTR”, “2. REAR”, “3. MAIN”, “4. BASS” and “5. M.LVL”, see page 22. (Once you have selected the appropriate modes, you do not have to change settings unless any alteration is made in your speaker system.)

6. LFE [Adjusting the output level of the LFE (low frequency effect) channel]

Control range: -20 dB to 0 dB (in 1 dB step)
Preset value: 0 dB

* This adjustment is effective only when the Dolby Digital is decoded and the signals of selected source encoded with the Dolby Digital contain LFE signals.

Adjusts the output level of the LFE (low frequency effect) channel. If the LFE signals are mixed with signals of other channels to output them from the same speakers, the ratio of LFE signal level to the level of other signals are adjusted. (See page 7 for details about the LFE channel.)

7. D.RNG (Adjusting dynamic range)

Choices: MAX/STD/MIN
Preset position: MAX

* This adjustment is effective only when the Dolby Digital is decoded.

MAX: “Dynamic range” is the difference between the maximum level and the minimum level of sounds. Sounds on a movie originally designed for movie theaters feature very wide dynamic range. Dolby Digital technology can bring the original sound track into a home audio format with this wide dynamic range unchanged. In this position, a source encoded with the Dolby Digital is reproduced in the original sound track’s wide dynamic range providing you with powerful sounds just like in a movie theater. Selecting this position will be even better if you can listen to a source in a high output level in a room specially soundproofed for audio/video enjoyment.

STD (Standard):

Powerful sounds of extremely wide dynamic range are not always suitable for home use. Depending upon the condition of your listening environment, it may not be possible to increase the sound output level as high as a movie theater. However, in a level suitable for listening to in your room, the low level parts of source sound often cannot be heard so well because they will be lost among noises in your environment. Dolby Digital technology also made it possible to reduce an original sound track’s dynamic range for a home audio format by “compressing” the data of sound.

In this position, a source encoded with the Dolby Digital is reproduced in the “compressed” dynamic range of the source suitable for low level listening.

MIN: In this position, dynamic range is more reduced than in the STD position. Selecting this position will be effective when you must listen to a source at lower level.

8. C.DELAY [Adjusting the delay of center sounds (dialog etc.)]

Control range: 0 ms to 5 ms (in 1 ms step)
Preset value: 0 ms

- * This adjustment is effective only when the Dolby Digital is decoded and the signals of selected source encoded with the Dolby Digital contain center-channel signals.

Adjusts the delay between the main sounds (at the main channels) and dialog etc. (at the center channel).
 The larger the value, the later the dialog etc. is generated.

This is for making sounds from the left main, center and right main speakers reach your listening position at the same time. This is achieved by delaying the sound from the center speaker if the distance from the center speaker to your listening position is shorter than the distance from the left or right main speaker to your listening position.

9. GUARD

Choices: ON/OFF
Preset position: OFF

If you wish to prevent accidental alteration to SET MENU and other adjustments on this unit, select ON. The following functions on this unit can be locked by this operation.

- Functions in the SET MENU mode
- Functions in the TIME/LEVEL mode
- Functions when using TEST

10. INPUT (Selecting the initial input mode of the sources connected to the TV/DBS input terminals)

For the sources connected to the TV/DBS input terminals of this unit only, you can designate the input mode that is automatically selected when the power of this unit is switched on.


- AUTO:** In this position, the AUTO input mode is always selected when the power of this unit is switched on.
- LAST:** In this position, the input mode you selected last time is memorized and will not be changed even if the power of this unit is switched on.

- * See page 29 for details on switching the input mode.


Adjusting method

Operations should be made while watching the information on this unit's display.

If you are using the remote control transmitter, set the **SELECTOR DIAL** to the AMP/TUN or DSP position on the remote control transmitter.




Press **SET MENU** once or more so that the title of function which you want to change appears on the display.



- * After pressing **SET MENU** once on the remote control transmitter, you can also select the title by pressing ▽. (Pressing Δ goes back one selection.)

Press + or – to select any desired position or edit parameters on the function.




Repeat these steps to change and adjust settings on any other function.

REMOTE CONTROL TRANSMITTER

You can use this remote control transmitter to control not only this unit but also other components connected to it. This is factory set to control this unit and most YAMAHA audio components. To control other brands of components, you must preset the remote control transmitter with the manufacturer's codes listed from page 108.

Components which can be controlled

There are nine positions that you can select to control connected components with this remote control transmitter. When turning the **SELECTOR DIAL**, the position changes as follows:




Notes

- The shaded positions in the diagram above indicate that you can preset the code for the manufacturer of your component. Note that you can preset only one code for one position. For details, see "SETUP CODES" on page 50.
- The DVD/LD and DVD MENU positions
 - Be sure that the **SELECTOR DIAL** is set to the DVD/LD position when presetting the code for a DVD or an LD player. The code that you preset to the DVD/LD position is also preset to the DVD MENU position simultaneously. You cannot preset the code for a DVD player when the **SELECTOR DIAL** is set to the DVD MENU position.
 - DVD MENU operations cannot be performed for some DVD players.
- When using a second (and third) VCR (For details, see "To use a second (and third) VCR" on page 50.)
 - If you are not using a CBL/DBS (cable TV or DBS tuner), the second (or third) VCR can be preset using the CBL/DBS position.
 - If you are not using a DVD player, the second (or third) VCR can be preset using the DVD MENU position. Note that in this case you must preset a code for an LD player to the DVD/LD position even if an LD player is not used.


Basic Operations

- Select the component that you want to control by turning the **SELECTOR DIAL**.
Note: Turn the **SELECTOR DIAL** until it stops with a click.



The component name is displayed in this window.

- Press the desired operation button.
Note: Press the button with the remote control transmitter aimed at the front panel.




Indicator
The indicator will flash when the button is pressed.

Faintly colored buttons do not function.

AMP/TUN

Note: TV POWER and TV VOLUME function if you have preset the code for your TV.



1 POWER

This button turns this unit on.

2 INPUT

Press these buttons to select the program source.

3 EXT. DEC.

Press this button when using an external decoder.

4 A/B/C/D/E

Press this button to select a group of preset stations.

5 DSP selector

Press this button. While the indicator lights up for about three seconds, select a DSP program using the number buttons (1 to 8). No DSP program can be selected after the indicator goes off.

6 PRESET (+/-)

Press these buttons to select the preset station number.

7 VOLUME (^ v)

Press these buttons to adjust the volume level.

8 MUTE

Press this button to mute the sound. To cancel mute, press this button once more, or press the operation buttons of this unit.

9 SLEEP

Press this button to set the SLEEP timer.

11 < (LEFT)

This button is used to adjust the settings of the SET MENU mode and the TIME/LEVEL mode.

14 TIME/LEVEL

Press this button to select the item in the TIME/LEVEL mode.

15 STANDBY

Press this button to turn this unit into Standby mode.

16 TEST

Press this button to output a test tone for adjusting the output level of the speakers.

17 EFCT (EFFECT) ON/OFF

Press this button to switch the DSP program on or off.

20 Δ (BACK)

Press this button to go back one selection in the SET MENU mode and TIME/LEVEL mode.

21 ▷ (RIGHT)

This button is used to adjust the settings of the SET MENU mode and the TIME/LEVEL mode.


22 ▽ (NEXT)

Press this button to advance one selection in the SET MENU mode and TIME/LEVEL mode.

24 SET MENU

Press this button to select functions in the SET MENU mode.

DSP




2 DSP program

Press these buttons to select the DSP program (1 to 8). When you select the input source, set the SELECTOR DIAL to the AMP/TUN position.

Note: The function of all buttons other than DSP program is the same as with the AMP/TUN position.

Faintly colored buttons do not function. For the buttons which are not described here, see "AMP/TUN" on page 46. For details, please refer to the owner's manual for each component.

■ TAPE/MD



Notes:

- **TV POWER** and **TV VOLUME** function if you have preset the code for your TV.
- Be sure to preset the proper code for your MD recorder.

TAPE

1 POWER

This button turns this unit on under the default settings. (The code for a YAMAHA tape deck is preset as the default code.) If other codes are preset, only those preset tape decks having a remote controller with a POWER button will be turned on.

10 ○/⏸ (REC/PAUSE)

Press this button to pause recording on a tape deck.

11 ◀ DIR A

Press this button to select the playing direction of deck A.

12 ▷ (PLAY)

Press this button to play a tape.

13 ◀◀ (REWIND)

Press this button to rewind a tape.

19 DECK A/B

Press this button to select double cassette tape deck A or B.

21 ▷ DIR B

Press this button to select the playing direction of deck B.

22 ◻ (STOP)

Press this button to stop operation of a tape.

23 ▷▷ (FAST FORWARD)

Press this button to fast forward a tape.

MD

1 POWER

This button turns this unit on if you have preset the code for the YAMAHA MD recorder. If other codes are preset, only those preset MD recorders having a remote controller with a POWER button will be turned on.

10 ○/⏸ (REC/PAUSE)

11 ◀◀ (SKIP)

12 ▷ (PLAY)

13 ◀◀ (BACKWARD)

18 DISPLAY


20 ◻◻ (PAUSE)

21 ▷▷ (SKIP)

22 ◻ (STOP)

23 ▷▷ (FAST FORWARD)

■ CD



Note: **TV POWER**, **TV VOLUME** and **TV INPUT** function if you have preset the code for your TV.

1 POWER

This button turns this unit on under the default settings. (The code for a YAMAHA CD player is preset as the default code.) If other codes are preset, only those preset CD players having a remote controller with a POWER button will be turned on.

6 DISC SKIP (+/-)

Press this button to skip to the next or previous CD.

11 ▷▷, ◀◀ (SKIP)

Press ▷▷ to skip to the next track. Press ◀◀ to skip to the previous track.

12 ▷ (PLAY)

Press this button to play a CD.

13 ◀◀ (BACKWARD)

Press this button to backward the track that is playing.

20 ◻◻ (PAUSE)

Press this button to pause operation. This button functions as **PAUSE/STOP** for operating YAMAHA CD players under default settings.

22 ◻ (STOP)

Press this button to stop operation. This button functions as **PAUSE/STOP** for operating YAMAHA CD players under default settings.

23 ▷▷ (FAST FORWARD)

Press this button to fast forward the track that is playing.

Faintly colored buttons do not function. For the buttons which are not described here, see "AMP/TUN" on page 46. For details, please refer to the owner's manual for each component.


DVD/LD

POWER

(DVD) This button turns this unit on under the default settings. (The code for a YAMAHA DVD player is preset as the default code.) If other codes are preset, only those preset DVD players having a remote controller with a POWER button will be turned on.

(LD) This button turns this unit on if you have preset the code for the YAMAHA LD player. If other codes are preset, only those preset LD players having a remote controller with a POWER button will be turned on.

Note: TV POWER, TV VOLUME and TV INPUT function if you have preset the code for your TV.




DVD MENU

POWER

(DVD) This button turns this unit on under the default settings. (The code for a YAMAHA DVD player is preset as the default code.) If other codes are preset, only those preset DVD players having a remote controller with a POWER button will be turned on.


Note: TV POWER, TV VOLUME and TV INPUT function if you have preset the code for your TV.



Faintly colored buttons do not function. For the buttons which are not described here, see "AMP/TUN" on page 46. For details, please refer to the owner's manual for each component.


VCR

Note: TV POWER, TV VOLUME and TV INPUT function if you have preset the code for your TV.




TV

Note: You can control your VCR if you have preset the code for it.



CBL/DBS

Note: TV POWER, TV VOLUME and TV INPUT function if you have preset the code for your TV.



SETUP CODES


Presetting the remote control transmitter

Perform the presetting procedure for each component you want to control with this remote control transmitter.


Note: If your component does not respond to any of the codes listed for the manufacturer, use the original remote control that came with the component.

To control your components (MD recorder, DVD player, TV etc.)


1. Turn on the component to be used.
2. Set the **SELECTOR DIAL** to the desired component (TAPE/MD, DVD/LD, TV etc.).



3. Press both **VOLUME** buttons (^) at the same time until the indicator flashes twice.



4. Use the numeric buttons to enter the four-digit manufacturer's code for the component to be used. Make sure that the indicator flashes twice. If the indicator does not flash, repeat step 3 and re-enter the code.




5. Press **POWER** (or any other button) on the remote control transmitter to check if you have preset the code correctly. If the component cannot be controlled using the remote control transmitter, try entering another code for the same manufacturer.

To use a second (and third) VCR


You can use the CBL/DBS and/or DVD MENU positions to control a second VCR (and/or third) if a CBL (or DBS) or DVD player is not used.

If you are using the DVD MENU position for a second (or third) VCR, you must preset a code for an LD player to the DVD/LD position.


1. Turn on the VCR to be used.
2. Set the **SELECTOR DIAL** to the CBL/DBS or DVD MENU position.




3. Press both **VOLUME** buttons (^) at the same time until the indicator flashes twice.



4. Press **MUTE**.



5. Use the numeric buttons to enter the four-digit code for a second (or third) VCR. Make sure that the indicator flashes twice. If the indicator does not flash, repeat step 3 and 4, and re-enter the code.



6. Press **POWER** (or any other button) on the remote control transmitter to check if you have preset the code correctly. If the VCR cannot be controlled using the remote control transmitter, try entering another code for the same manufacturer.

Returning to the default code

To return all components to the default code, follow these steps.

1. Press both **VOLUME** buttons (^) at the same time until the indicator flashes twice.
2. Enter the code number "9987".
3. Make sure that the indicator flashes twice.

To return each component to the default code, follow these steps.

1. Set the **SELECTOR DIAL** to the component to be return to the default code.
2. Press both **VOLUME** buttons (^) at the same time until the indicator flashes twice.
3. Enter the code number "9999".
4. Make sure that the indicator flashes twice.

The following codes are preset as the default code.

Default codes

| POSITION | Component | Code ¹ | Code ² |
|----------|------------|-------------------|-------------------|
| TV | TV | 0047 | 0037 |
| CBL/DBS | DBS tuner | 2566 | 2455 |
| VCR | VCR | 3060 | 3072 |
| DVD/LD | DVD player | 4545 | YAMAHA |
| CD | CD player | 6187 | YAMAHA |
| TAPE/MD | Tape deck | 8524 | YAMAHA |


*1: Canada and China models

*2: Australia model

We recommend that you write all code numbers you have preset on the "Quick Reference Card".

NOTES ABOUT THE REMOTE CONTROL TRANSMITTER

Battery installation



Battery replacement


If the remote control transmitter operates only when it is closed to this unit, the batteries are weak. Replace both batteries with new ones.

Be sure to replace batteries within about two minutes. If it takes longer than two minutes, the codes preset for the remote control transmitter will return to the default codes.

Notes

- Use only AA, R6, UM-3 batteries for replacement.
- Be sure the polarities are correct. (See the illustration inside the battery compartment.)
- Remove the batteries if the remote control transmitter will not be used for an extended period of time.
- If batteries leak, dispose of them immediately. Avoid touching the leaked material or letting it come in contact with clothing, etc. Clean the battery compartment thoroughly before installing new batteries.

Remote control transmitter operation range



Notes

- There should be no large obstacles between the remote control transmitter and this unit.
- If the remote control sensor is directly illuminated by strong lighting (especially an inverter type of fluorescent lamp etc.), it might cause the remote control transmitter not to work correctly. In this case, reposition this unit to avoid direct lighting.

TROUBLESHOOTING

If the unit fails to operate normally, check the following points to determine whether the fault can be corrected by the simple measures suggested. If it cannot be corrected, or if the fault is not listed in the SYMPTOM column, disconnect the power cord and contact your authorized YAMAHA dealer or service center for help.

| | SYMPTOM | CAUSE | REMEDY |
|--|---|---|--|
| Amplifier | The unit fails to turn on when STANDBY/ON is pressed, or turns into the standby mode suddenly soon after the power is turned on. | Power cord is not plugged in or is not completely inserted. | Firmly plug in the power cord. |
| | | The IMPEDANCE SELECTOR switch on the rear panel is not fully set to the upper or lower end. | Set the switch fully to the upper or lower end. |
| | The unit does not work normally. | There is an influence of strong external noise (lightning, excessive static electricity, etc.) or a misoperation while using this unit. | Turn this unit into the standby mode and disconnect the AC power cord from the AC outlet. After about 30 seconds have passed, connect the power and operate this unit again. |
| | No sound or no picture. | Incorrect output cord connections. | Connect the cords properly. If the problem persists, the cords may be defective. |
| | | Appropriate input source is not selected. | Select an appropriate input source with INPUT . |
| | | SPEAKERS are not set properly. | Set SPEAKERS corresponding to the speakers in use to the ON position. |
| | | Speaker connections are not secure. | Secure the connections. |
| | The sound suddenly goes off. | The protection circuit has been activated because of short circuit etc. | Turning the unit into the standby mode and then on again will reset the protection circuit. |
| | | The SLEEP timer has functioned. | Cancel the SLEEP timer function. |
| | Only one side speaker outputs sound. | Incorrect setting of BALANCE . | Adjust it to the appropriate position. |
| | | Incorrect cord connections. | Connect the cords properly. If the problem persists, the cords may be defective. |
| | A "humming" sound can be heard. | Incorrect cord connections. | Firmly connect the audio plugs. If the problem persists, the cords may be defective. |
| | | No connection from the turntable to the GND terminal. | Make the GND connection between the turntable and this unit. |
| | The volume level is low while playing a record. | The record is being played on a turntable with an MC cartridge. | The turntable should be connected to the unit through the MC head amplifier. |
| | The volume level cannot be increased, or the sound is distorted. | The component connected to the REC OUT terminals of this unit is in the standby mode. | Turn the power to the component on. |
| | No sound from the rear speakers. | The sound output level of the rear speakers is set to minimum. | Raise the sound output level of the rear speakers. |
| | | A monaural sound source is being played in DOLBY PRO LOGIC or DOLBY PRO LOGIC ENHANCED mode. | Select another sound field program suitable for the monaural sound source. |
| | No sound from the center speaker. | The sound output level of the center speaker is set to minimum. | Raise the sound output level of the center speaker. |
| The center channel mode is in NONE mode. | | Select LARGE or SMALL. | |
| Incorrect sound field program selection. | | Select the appropriate program. | |

| | SYMPTOM | CAUSE | REMEDY |
|----------------------------|--|--|---|
| FM | FM stereo reception is noisy. | Because of the characteristics of FM stereo broadcasts, this is limited to cases where the transmitter is too far away or the antenna input is poor. | Check the antenna connections. Try using a high quality directional FM antenna. Set TUNING MODE to the manual tuning mode. |
| | There is distortion and clear reception cannot be obtained even with a good FM antenna. | There is multipath interference. | Adjust antenna placement to eliminate multipath interference. |
| | The desired station cannot be tuned in with the automatic tuning method. | The station is too weak. | Use the manual tuning method. Use a high quality directional FM antenna. |
| | Previously preset stations can no longer be tuned in. | This unit has been unplugged for a long period. | Repeat the presetting procedure. |
| AM | The desired station cannot be tuned in with the automatic tuning method. | Weak signal or loose antenna connections. | Tighten the AM loop antenna connections and rotate it for best reception. Use the manual tuning method. |
| | There are continuous crackling and hissing noises. | Noises will result from lightning, fluorescent lamps, motors, thermostats and other electrical equipment. | Use an outdoor antenna and a ground wire. This will help somewhat but it is difficult to eliminate all noise. |
| | There are buzzing and whining noises (especially in the evening). | A television set is being used nearby. | Relocate this unit away from the TV. |
| Remote control transmitter | The remote control transmitter does not work. | Direct sunlight or lighting (of an inverter type of fluorescent lamp etc.) is striking the remote control sensor of the main unit. | Change the position of the main unit. |
| | | The manufacturer's code is not set properly. | Set the code again. |
| | | The proper manufacturer's code for the component to be controlled is not set. | Try entering another code for the same manufacturer. |
| | | The component to be controlled is not selected. | Set the SELECTOR DIAL to the proper position. |
| Others | The sound is degraded when listening with headphones to a CD player or tape deck that is connected to this unit. | This unit is in the standby mode. | Turn the power of the unit on. |

SPECIFICATIONS

AUDIO SECTION

Minimum RMS Output Power

8 ohms, 20 Hz to 20 kHz, 0.04% THD

[U.S.A. and Canada models]

MAIN L/R 70 W + 70 W

CENTER 70 W

REAR L/R 70 W + 70 W

[Australia, China, Singapore and General models]

MAIN L/R 65 W + 65 W

CENTER 65 W

REAR L/R 65 W + 65 W

8 ohms, 1 kHz, 0.07% THD

[U.S.A. and Canada models]

MAIN L/R 85 W + 85 W

CENTER 85 W

REAR L/R 85 W + 85 W

[Australia, China, Singapore and General models]

MAIN L/R 80 W + 80 W

CENTER 80 W

REAR L/R 80 W + 80 W

Maximum Power

[China and General models only]

8 ohms, 1 kHz, 10% THD

MAIN L/R 105 W + 105 W

CENTER 105 W

REAR L/R 105 W + 105 W

Dynamic Power per Channel

(by IHF Dynamic Headroom measuring method)

[U.S.A. and Canada models]

8/6/4/2 ohms 100/120/145/170 W

[Australia, China, Singapore and General models]

8/6/4/2 ohms 90/110/135/160 W

Dynamic Headroom (8 ohms)

[U.S.A. and Canada models only] 1.55 dB

Power Band Width

8 ohms, 35 W, 0.1% THD ... 10 Hz to 50 kHz

Damping Factor (SPEAKERS A)

8 ohms, 20 Hz to 20 kHz 60 or more

Input Sensitivity/Impedance

PHONO MM 2.5 mV/47 k-ohms

CD/TAPE-MD/DVD-LD/TV-DBS/VCR/

VIDEO AUX 150 mV/47 k-ohms

EXT. DECODER

MAIN L/R 150 mV/47 k-ohms

CENTER/SURROUND L/R/SUBWOOFER

..... 150 mV/40 k-ohms

Maximum Input Signal

PHONO MM

1 kHz, 0.1% THD 100 mV or more

CD/TAPE-MD/DVD-LD/TV-DBS/VCR/

VIDEO AUX (EFFECT ON)

1 kHz, 0.5% THD 2.2V or more

Output Level/Impedance

REC OUT 150 mV/1.2 k-ohms

SUBWOOFER

(MAIN SP: SMALL) 4.0 V/1.2 k-ohms

Headphones Jack Rated Output/Impedance

CD/TAPE-MD/DVD-LD/TV-DBS/VCR/

VIDEO AUX input,

1 kHz, 150mV, 8 ohms 0.5 V/390 ohms

Frequency Response (20 Hz to 20 kHz)

CD/TAPE-MD/DVD-LD/TV-DBS/VCR/

VIDEO AUX to MAIN L/R SP OUT

..... 0±0.5 dB

RIAA Equalization Deviation

PHONO MM 0±0.5 dB

Total Harmonic Distortion (20 Hz to 20 kHz)

PHONO MM to REC OUT

1 V 0.02% or less

Signal-to-Noise Ratio (IHF-A Network)

PHONO MM to REC OUT

[U.S.A., Canada, China and General

models]

(5 mV, Input Shorted) 86 dB or more

[Australia and Singapore models]

(5mV, Input Shorted) 81 dB or more

CD/TAPE-MD/DVD-LD/TV-DBS/VCR/

VIDEO AUX to SP OUT (EFFECT OFF)

(150 mV, Input Shorted) 96 dB or more

Residual Noise (IHF-A Network)

MAIN L/R SP OUT 150 µV or less

Channel Separation

(Vol. -30 dB, EFFECT OFF)

PHONO MM

(Input Shorted, 1 kHz/10 kHz)

..... 60 dB or more/55 dB or more

CD/TAPE-MD/DVD-LD/TV-DBS/VCR/

VIDEO AUX

(Input 5.1 k-ohms Terminated, 1 kHz/10 kHz)

..... 60 dB or more/45 dB or more

Tone Control Characteristics

BASS: Boost/cut ±10 dB (50 Hz)

Turnover Frequency 350 Hz

TREBLE: Boost/cut ±10 dB (20 kHz)

Turnover Frequency 3.5 kHz

Filter Characteristics

MAIN L/R, REAR L/R (SPEAKER: SMALL)

(H.P.F.) fc = 90 Hz, 12 dB/oct.

SUBWOOFER

(L.P.F.) fc = 90 Hz, 18 dB/oct.

VIDEO SECTION

Video Signal Type

[U.S.A. and Canada models] NTSC

[Australia and Singapore models] PAL

[China and General models] NTSC/PAL

Video Signal Level 1 Vp-p/75 ohms

Maximum Input Level 1.5 Vp-p or more

Signal-to-Noise Ratio 50 dB or more

Monitor Out Frequency Response

..... 5 Hz to 10 MHz, -3 dB

FM SECTION

Tuning Range

[U.S.A. and Canada models]

..... 87.5 to 107.9 MHz

[Australia and Singapore models]

..... 87.5 to 108.0 MHz

[China and General models]

100 kHz step 87.5 to 108.0 MHz

50 kHz step 87.50 to 108.00 MHz

50 dB Quieting Sensitivity (IHF)

(100% mod., 1 kHz)

Mono 1.6 µV (15.3 dBf)

Stereo 23 µV (38.5 dBf)

| | |
|---|---------------------|
| Usable Sensitivity (DIN) | |
| [Australia and Singapore models] | |
| Mono (S/N 26 dB) | 0.9 μ V |
| Stereo (S/N 46 dB) | 28 μ V |
| Alternate Channel Selectivity (\pm 400 kHz) | |
| [U.S.A., Canada, China and General models only] | 75 dB |
| Selectivity (two signals, 40 kHz Dev. \pm 300 kHz) | |
| [Australia and Singapore models only] | 55 dB |
| Signal-to-Noise Ratio | |
| (IHF) Mono/Stereo | |
| [U.S.A., Canada, China and General models] | 81 dB/75 dB |
| (DIN-Weighted, 40 kHz Dev.) Mono/Stereo | |
| [Australia and Singapore models] | 75 dB/69 dB |
| Harmonic Distortion (1 kHz) | |
| Mono/Stereo | 0.1/0.2% |
| Stereo Separation (1 kHz) | 48 dB |
| Frequency Response | |
| 20 Hz to 15 kHz | 0 \pm 1 dB |
| Antenna Input | 75 ohms, Unbalanced |
| Output Level | |
| [U.S.A., Canada, China and General models] | |
| (100% mod., 1 kHz) | 550 mV |
| [Australia and Singapore models] | |
| (40 kHz Dev., 1 kHz) | 550 mV |

AM SECTION

| | |
|----------------------------------|------------------|
| Tuning Range | |
| [U.S.A. and Canada models] | |
| | 530 to 1,710 kHz |
| [Australia and Singapore models] | |
| | 531 to 1,611 kHz |
| [China and General models] | |
| 10 kHz step | 530 to 1,710 kHz |
| 9 kHz step | 531 to 1,611 kHz |
| Usable Sensitivity | 300 μ V/m |
| Signal-to-Noise Ratio | 52 dB |
| Antenna | Loop antenna |
| Output Level | |
| (30% mod., 1 kHz) | 150 mV |

GENERAL

| | |
|---|---------------------------------|
| Power Supply | |
| [U.S.A. and Canada models] | |
| | AC 120 V, 60 Hz |
| [Australia model] | AC 240 V, 50 Hz |
| [General model] | |
| | AC 110/120/220/240 V, 50/60 Hz |
| [China model] | AC 220 V, 50 Hz |
| [Singapore model] | AC 230 V, 50 Hz |
| Power Consumption | |
| [U.S.A. model] | 280 W |
| [Canada model] | 310 W/410 VA |
| [Australia and Singapore models] | 300 W |
| [China and General models] | 310 W |
| Maximum Power Consumption | |
| 5 ch, 10% THD | |
| [General model only] | 650 W |
| AC Outlets | |
| 2 SWITCHED OUTLETS | |
| [U.S.A., Canada, Singapore, China and General models] | 100 W max. total |
| 1 SWITCHED OUTLET | |
| [Australia model] | 100 W max. total |
| Dimensions (W x H x D) | |
| | 435 x 151 x 391 mm |
| | (17-1/8" x 5-15/16" x 15-3/8") |
| Weight | 12.5 kg (27 lbs. 8 oz.) |
| Accessories | AM loop antenna |
| | Indoor FM antenna |
| | Remote control transmitter |
| | Batteries |
| | Antenna adapter |
| | (U.S.A. and Canada models only) |

Specifications are subject to change without notice.

LIST OF MANUFACTURER'S CODES (Canada and China models)
LISTE DES CODES FABRICANTS (Modèles pour le Canada et la Chine)

TV

Manufacturer Code

| | |
|----------------|--|
| A-Mark | 0003 |
| AOC | 0030, 0019, 0003, 0052, 0185 |
| Abex | 0032 |
| Acura | 0009 |
| Admiral | 0093 |
| Adventura | 0046 |
| Adyson | 0032 |
| Aiko | 0092 |
| Akai | 0030, 0208 |
| Akura | 0264 |
| Alaron | 0179, 0216 |
| Alba | 0009, 0037 |
| Ambassador | 0177 |
| Amstrad | 0009, 0171, 0177 |
| Anam | 0180, 0004, 0009, 0068 |
| Anam National | 0161 |
| Anitech | 0009, 0068 |
| Arcam | 0216 |
| Archer | 0003 |
| Audinac | 0391 |
| Audiosonic | 0037, 0109 |
| Audiovox | 0451, 0180, 0003, 0092 |
| BPL | 0282 |
| Basic Line | 0009 |
| Baur | 0037, 0512, 0535, 0554 |
| Baysonic | 0180 |
| Belcor | 0019 |
| Bell & Howell | 0154, 0016 |
| Beon | 0037 |
| Blaupunkt | 0535, 0554 |
| Blue Star | 0282 |
| Bradford | 0180 |
| Brandt | 0109 |
| Britannia | 0216 |
| Brockwood | 0019 |
| Broksonic | 0236, 0463, 0003, 0426 |
| Bush | 0282, 0009, 0037 |
| CCE | 0037 |
| CS Electronics | 0216 |
| CXC | 0180 |
| Candle | 0030, 0056, 0046, 0186 |
| Carnivale | 0030 |
| Carver | 0054, 0170 |
| Cascade | 0009 |
| Cathay | 0037 |
| Celebrity | 0000 |
| Centurion | 0037 |
| Cimline | 0009 |
| Cineral | 0451, 0092 |
| Citizen | 0060, 0030, 0056, 0039, 0046, 0092, 0186, 0280 |
| Clairtone | 0185 |
| Clarivox | 0037 |

| | |
|-----------------|--|
| Concerto | 0056 |
| Contec | 0180, 0009, 0185, 0216 |
| Craig | 0180, 0161 |
| Crosley | 0054 |
| Crown | 0180, 0039, 0009, 0037, 0418 |
| Curtis Mathes | 0047, 0054, 0154, 0051, 0451, 0093, 0060, 0030, 0145, 0056, 0016, 0039, 0166 |
| Daewoo | 0451, 0019, 0039, 0009, 0037, 0066, 0092 |
| Dansai | 0037 |
| Dayton | 0009 |
| Daytron | 0019 |
| De Graaf | 0208 |
| Decca | 0037 |
| Denon | 0145 |
| Dixi | 0004, 0009, 0037 |
| Dumont | 0017, 0019 |
| Ectec | 0391 |
| Electroband | 0000, 0185 |
| Elin | 0037 |
| Elta | 0009 |
| Emerson | 0154, 0236, 0463, 0180, 0282, 0178, 0019, 0179, 0039, 0177, 0185, 0280 |
| Envision | 0030 |
| Erres | 0037 |
| Ferguson | 0037, 0109, 0287, 0560 |
| Fidelity | 0216 |
| Finlandia | 0208 |
| Finlux | 0179, 0037 |
| Firstline | 0009, 0216 |
| Fisher | 0154, 0159, 0208 |
| Formenti | 0037 |
| Frontech | 0264 |
| Fujitsu | 0179 |
| Funai | 0180, 0179, 0171, 0264 |
| Futuretech | 0180 |
| GE | 0047, 0051, 0451, 0093, 0282, 0178, 0021, 0135 |
| GEC | 0037 |
| Geloso | 0009 |
| Gibraltar | 0017, 0030, 0019 |
| GoldStar | 0030, 0178, 0019, 0056, 0001, 0002, 0032, 0037, 0109 |
| Goodmans | 0179, 0037 |
| Gradiente | 0053, 0056, 0170 |
| Granada | 0037, 0208, 0339, 0502 |
| Grandin | 0282 |
| Grundig | 0037, 0535, 0554 |
| Grunpy | 0180, 0179 |
| HCM | 0282, 0009 |
| Hallmark | 0178 |
| Hanseatic | 0037 |
| Harley Davidson | 0179 |
| Harvard | 0180, 0068 |
| Hinari | 0179, 0009, 0037, 0283 |

| | |
|----------------|--|
| Hisawa | 0282 |
| Hitachi | 0145, 0056, 0032, 0109, 0151, 0576 |
| Huanyu | 0216 |
| Hypson | 0282, 0037, 0264 |
| ICE | 0264 |
| ITT | 0283 |
| Imperial | 0418 |
| Indiana | 0037 |
| Infinity | 0054 |
| Inteq | 0017 |
| Interbuy | 0068 |
| Interfunk | 0037, 0512 |
| Intervision | 0037, 0068, 0264 |
| JBL | 0054 |
| JCB | 0000 |
| JEC | 0502 |
| JVC | 0053, 0069, 0160 |
| Janeil | 0046 |
| KEC | 0180 |
| KTV | 0180, 0030, 0039, 0185, 0280 |
| Kaisui | 0282, 0009, 0216 |
| Kamp | 0216 |
| Kawasho | 0216 |
| Kaypani | 0052 |
| Kendo | 0037 |
| Kenwood | 0030, 0019 |
| Kingsley | 0216 |
| Kloss | 0046 |
| Korpel | 0037 |
| Koyoda | 0009 |
| LG | 0056 |
| LXI | 0047, 0054, 0154, 0156, 0178 |
| Leyco | 0037, 0264 |
| Liesenk & Tter | 0037 |
| Lloytron | 0032 |
| Loewe | 0512 |
| Logik | 0016, 0001 |
| Luxman | 0056 |
| M Electronic | 0009, 0037, 0068, 0109, 0287 |
| MEI | 0185 |
| MGA | 0150, 0030, 0178, 0019 |
| MTC | 0060, 0030, 0019, 0056, 0185, 0216, 0512 |
| Magnavox | 0054, 0030, 0179, 0186, 0187 |
| Majestic | 0016 |
| Manesth | 0264 |
| Marantz | 0054, 0030, 0037 |
| Mark | 0037 |
| Matsui | 0009, 0035, 0037, 0177, 0208 |
| Matsushita | 0250 |
| Mediator | 0037 |
| Megatron | 0178, 0145, 0003 |
| Memorex | 0154, 0250, 0150, 0178, 0056, 0016, 0009 |

| | | | | | |
|--------------|--|-------------|--|--------------------|--|
| Metz | 0535 | Rex | 0264 | Teletch | 0009 |
| Midland | 0047, 0017, 0051, 0039, 0032, 0135 | Rhapsody | 0185, 0216 | Teleton | 0186 |
| Minerva | 0535, 0554 | Roadstar | 0009, 0264, 0418 | Texet | 0216 |
| Minutz | 0021 | Runco | 0017, 0030 | Thomson | 0109, 0287 |
| Mitsubishi | 0093, 0150, 0178, 0019, 0512, 0535 | SBR | 0037 | Thorn | 0035, 0037, 0512, 0535 |
| Mivar | 0216 | SEG | 0264 | Tomashi | 0282 |
| Motorola | 0093 | SEI | 0177 | Toshiba | 0154, 0156, 0060, 0035, 0149, 0502 |
| Multitech | 0180, 0009, 0216 | SSS | 0180, 0019 | Tosonic | 0185 |
| NAD | 0156, 0178, 0166 | Saba | 0109, 0287 | Totevision | 0039 |
| NEC | 0030, 0019, 0056, 0170 | Saisho | 0009, 0177, 0264 | Triumph | 0177 |
| NEI | 0037 | Sampo | 0030, 0039, 0032, 0052 | Ultra | 0391 |
| NTC | 0092 | Samsung | 0060, 0030, 0178, 0019, 0056, 0039, 0009, 0032, 0037, 0090, 0264, 0427 | Universum | 0037, 0264, 0535 |
| Neckermann | 0037, 0554 | Samsux | 0039 | Vector Research | 0030 |
| Nesco | 0179 | Sandra | 0216 | Vestel | 0037 |
| Nikkai | 0032, 0035, 0037, 0216, 0264 | Sansei | 0451 | Victor | 0053 |
| Nikko | 0030, 0178, 0092 | Sansui | 0463 | Vidikron | 0054 |
| Nisato | 0391 | Sanyo | 0154, 0159, 0208, 0339 | Vidtech | 0178, 0019 |
| Nordmende | 0109, 0287, 0560 | Schneider | 0037 | Viking | 0046 |
| Noshi | 0018 | Scimitsu | 0019 | Wards | 0054, 0165, 0030, 0178, 0021, 0019, 0179, 0056, 0016, 0080 |
| Onwa | 0180 | Scotch | 0178 | Watson | 0037 |
| Optimus | 0154, 0250, 0166 | Scott | 0236, 0180, 0178, 0019, 0179 | White Westinghouse | 0037, 0216 |
| Optonica | 0093, 0165 | Sears | 0047, 0054, 0154, 0156, 0178, 0179, 0056, 0149, 0159, 0171 | Yamaha | 0030, 0019 |
| Orion | 0236, 0463, 0179, 0037, 0177 | Semivox | 0180 | Yoko | 0037, 0264 |
| Osaki | 0032, 0264 | Semp | 0156 | Zenith | 0017, 0016, 0092 |
| Osume | 0032 | Sentra | 0035, 0283 | Zonda | 0003 |
| Otto Versand | 0037, 0512, 0535, 0554 | Sharp | 0093, 0165, 0039 | | |
| Palladium | 0418 | Shogun | 0019 | | |
| Panama | 0264 | Siemens | 0037, 0535, 0554 | | |
| Panasonic | 0051, 0250, 0226 | Signature | 0016 | | |
| Pathe Cinema | 0216 | Simpson | 0186, 0187 | | |
| Pausa | 0009 | Sinudyne | 0177 | | |
| Penney | 0047, 0156, 0051, 0060, 0030, 0178, 0021, 0019, 0018, 0056, 0039, 0002, 0003, 0032, 0135, 0149 | Solavox | 0032 | | |
| Phase | 0032 | Sonitron | 0208 | | |
| Philco | 0054, 0463, 0030, 0145, 0019 | Sonoko | 0009, 0037 | | |
| Philips | 0054, 0037, 0554 | Sonolor | 0208 | | |
| Phonola | 0037 | Sontec | 0037 | | |
| Pilot | 0030, 0019, 0039 | Sony | 0000, 0080 | | |
| Pioneer | 0109, 0166, 0287 | Soundesign | 0180, 0178, 0179, 0186 | | |
| Portland | 0019, 0039, 0092 | Soundwave | 0037, 0418 | | |
| Prism | 0051 | Spectricon | 0003 | | |
| Profex | 0009 | Squareview | 0171 | | |
| Proscan | 0047 | Standard | 0009 | | |
| Protech | 0009, 0037, 0264, 0418 | Starlite | 0180 | | |
| Proton | 0178, 0003, 0052 | Supra | 0056 | | |
| Pulsar | 0017, 0019 | Supre-Macy | 0046 | | |
| Quasar | 0051, 0250, 0165 | Supreme | 0000 | | |
| Quelle | 0037, 0252, 0512, 0535, 0554 | Sylvania | 0054, 0030 | | |
| R-Line | 0037 | Symphonic | 0171 | | |
| RCA | 0047, 0051, 0093, 0019, 0018, 0090, 0135 | Sysline | 0037 | | |
| Radio Shack | 0047, 0154, 0165, 0180, 0030, 0178, 0019, 0056, 0039, 0032 | TMK | 0178, 0056, 0177 | | |
| Radiola | 0037 | Tandy | 0093 | | |
| Realistic | 0154, 0165, 0180, 0030, 0178, 0019, 0056, 0039, 0032 | Tatung | 0003, 0037 | | |
| Revox | 0037 | Technics | 0051, 0250 | | |
| | | Technol Ace | 0179 | | |
| | | Techwood | 0051, 0056, 0003 | | |
| | | Teknika | 0054, 0180, 0150, 0060, 0019, 0179, 0056, 0016, 0039, 0092, 0186 | | |
| | | Telefunken | 0056, 0109, 0252 | | |

CABLE

| Manufacturer | Code |
|--------------------|--|
| ABC | 1003, 1008, 1014, 1011 |
| Allegro | 1315 |
| Archer | 1797 |
| BBT | 1267 |
| Belcor | 1056 |
| British Telecom | 1003 |
| Cable Star | 1056 |
| Citizen | 1315 |
| Colour Voice | 1031 |
| Comtronics | 1040 |
| Contec | 1019 |
| Emerson | 1797 |
| Everquest | 1015, 1040 |
| Focus | 1400 |
| GC Electronics | 1056 |
| Gemini | 1015 |
| General Instrument | 1476, 1011 |
| GoldStar | 1144, 1040 |
| Goodmind | 1797 |
| Hamlin | 1020, 1259, 1009, 1034 |
| Hitachi | 1011 |
| Jasco | 1315 |
| Jerrold | 1003, 1012, 1476, 1014, 1015, 1011, 1024 |
| MNet | 1019 |
| Magnavox | 1027 |
| Memorex | 1000 |
| Movie Time | 1063 |

| | |
|--------------------------|------------------------|
| NSC | 1063 |
| Novaplex | 1618 |
| Oak | 1019 |
| Optimus | 1021 |
| PVP Stereo Visual Matrix | 1003 |
| Panasonic | 1000, 1107, 1021 |
| Paragon | 1000 |
| Philips | 1027, 1031 |
| Pioneer | 1144, 1533 |
| Popular Mechanics | 1400 |
| Prelude | 1770 |
| Pulsar | 1000 |
| RCA | 1021 |
| Radio Shack | 1015, 1315 |
| Recoton | 1400 |
| Regal | 1020, 1259 |
| Rembrandt | 1011 |
| Runco | 1000 |
| SL Marx | 1040 |
| Samsung | 1144, 1040 |
| Scientific Atlanta | 1008, 1477 |
| Signal | 1015, 1040 |
| Signature | 1011 |
| Sprucer | 1021 |
| StarSight | 1422 |
| Starcom | 1003, 1015 |
| Stargate | 1015, 1040, 1770, 1797 |
| Starquest | 1015 |
| TV86 | 1063 |
| TeleCaption | 1221 |
| Televue | 1040 |
| Timeless | 1418 |
| Tocom | 1012 |
| Toshiba | 1000 |
| Tusa | 1015 |
| United Cable | 1003 |
| Universal | 1056, 1191 |
| Viewstar | 1063, 1027 |
| Zenith | 1000, 1054, 1525 |
| Zentek | 1400 |

DBS TUNER

| Manufacturer | Code |
|--------------------|------------|
| AST | 2321 |
| Audio Ton | 2364 |
| Avalon | 2396 |
| Chaparral | 2053, 2209 |
| Connexions | 2396 |
| DNT | 2396 |
| Echostar | 2396 |
| Elta | 2364 |
| Expressvu | 2775 |
| Fuba | 2396 |
| Galaxis | 2364 |
| Galaxisat | 2321 |
| General Instrument | 2361 |
| Huth | 2364 |

| | |
|------------|------------|
| JSR | 2364 |
| JVC | 2775 |
| Jerrold | 2361 |
| Lemon | 2692 |
| NEC | 2507 |
| Neusat | 2692 |
| Next-Wave | 2732 |
| Primestar | 2361 |
| Radix | 2396 |
| SAT | 2321 |
| SatPartner | 2692 |
| Seemann | 2396 |
| Triad | 2321 |
| Wisi | 2321, 2396 |
| Zehnder | 2321 |

(DSS)

| | |
|-----------------------|------|
| AlphaStar | 2772 |
| Echostar | 2775 |
| General Instrument | 2869 |
| HTS | 2775 |
| Hitachi | 2819 |
| Hughes Network System | 2749 |
| Jerrold | 2627 |
| Magnavox | 2724 |
| Memorex | 2724 |
| Panasonic | 2701 |
| Philips | 2724 |
| Primestar | 2627 |
| RCA | 2566 |
| Sony | 2639 |
| Star Choice | 2869 |
| Toshiba | 2790 |
| Uniden | 2724 |

VCR

| Manufacturer | Code |
|---------------|------------------------------|
| ASA | 3037, 3081 |
| Admiral | 3048 |
| Adventura | 3000 |
| Aiko | 3278 |
| Aiwa | 3037, 3000 |
| Akai | 3041, 3061, 3281, 3288 |
| Akiba | 3072 |
| Akura | 3271 |
| Alba | 3209, 3072, 3278, 3020, 3295 |
| Ambassador | 3020 |
| American High | 3035 |
| Amstrad | 3000, 3278 |
| Anitech | 3072 |
| Asha | 3240 |
| Asuka | 3037 |
| Audiovox | 3037 |
| Baird | 3000, 3104, 3041 |
| Basic Line | 3072, 3278, 3020 |
| Beaumont | 3240 |
| Bell & Howell | 3104 |

| | |
|-------------------|--|
| Blaupunkt | 3162, 3034, 3195, 3226, 3227 |
| Brandt | 3187, 3320 |
| Brandt Electronic | 3041 |
| Broksonic | 3184, 3121, 3209, 3002, 3295, 3361, 3479 |
| Bush | 3209, 3072, 3278 |
| CCE | 3072, 3278 |
| CGE | 3000 |
| Calix | 3037 |
| Canon | 3035 |
| Capehart | 3020 |
| Carver | 3081 |
| Catron | 3020 |
| Cimline | 3072 |
| Cineral | 3278 |
| Citizen | 3037, 3278 |
| Clatronic | 3020 |
| Colt | 3072 |
| Condor | 3020 |
| Craig | 3037, 3047, 3240, 3072, 3271 |
| Crown | 3072, 3278, 3020 |
| Curtis Mathes | 3060, 3035, 3041, 3162 |
| Cybernex | 3240 |
| Cyrus | 3081 |
| Daewoo | 3045, 3278, 3020 |
| Dansai | 3072 |
| Daytron | 3020 |
| De Graaf | 3042, 3166 |
| Decca | 3081, 3000 |
| Denon | 3042 |
| Dual | 3041 |
| Dumont | 3081, 3000, 3104 |
| Dynatech | 3000 |
| ESC | 3240, 3278 |
| Elbe | 3038 |
| Elcotech | 3072 |
| Electrohome | 3037 |
| Electroponic | 3037 |
| Emerex | 3032 |
| Emerson | 3037, 3184, 3000, 3121, 3043, 3209, 3002, 3278, 3036, 3061, 3068, 3208, 3212, 3295, 3361, 3479 |
| Ferguson | 3041, 3320 |
| Fidelity | 3000 |
| Finlandia | 3081, 3104 |
| Finlux | 3081, 3000, 3042, 3104 |
| Firstline | 3037, 3045, 3043, 3209, 3072 |
| Fisher | 3047, 3104, 3046, 3054, 3066 |
| Frontech | 3020 |
| Fuji | 3035, 3033 |
| Funai | 3000 |
| GE | 3060, 3035, 3048, 3240, 3202 |
| GEC | 3081 |
| Garrard | 3000 |
| General | 3020 |
| GoldHand | 3072 |
| GoldStar | 3037, 3038, 3225, 3471 |
| Goodmans | 3037, 3000, 3072, 3278, 3062, 3020 |
| Gradiente | 3000, 3008 |

| | | | | | |
|-----------------|--|---------------|--|--------------------|--|
| Graetz | 3240, 3104, 3041 | Nesco | 3072 | Schaub Lorenz | 3000, 3104, 3041 |
| Granada | 3081, 3104, 3046 | Nikko | 3037 | Schneider | 3081, 3000, 3072 |
| Grandin | 3037, 3000, 3072 | Nikon | 3034 | Scott | 3184, 3045, 3121, 3043, 3212 |
| Grundig | 3081, 3072, 3195, 3226 | Noblex | 3240 | Sears | 3035, 3037, 3047, 3000, 3042, 3104, 3046, 3054, 3066 |
| HCM | 3072 | Nokia | 3240, 3104, 3041, 3046 | Seleco | 3041 |
| HI-Q | 3047 | Nordmende | 3041, 3320, 3384 | Semp | 3045 |
| Hanseatic | 3037 | Oceanic | 3000, 3041 | Sentra | 3020 |
| Harley Davidson | 3000 | Olympus | 3035, 3226 | Sharp | 3048, 3062 |
| Harman/Kardon | 3038 | Optimus | 3037, 3048, 3104, 3162 | Shintom | 3104, 3072 |
| Harwood | 3072, 3068 | Optonica | 3062 | Shogun | 3240 |
| Headquarter | 3046 | Orion | 3184, 3121, 3209, 3002, 3036, 3208, 3295, 3479 | Siemens | 3037, 3081, 3104, 3054, 3195 |
| Hinari | 3240, 3072, 3208 | Osaki | 3037, 3000, 3072 | Silva | 3037 |
| Hitachi | 3240, 3000, 3042, 3041, 3166, 3235 | Otto Versand | 3081 | Singer | 3045, 3072 |
| Hypson | 3072 | Palladium | 3037, 3041, 3072 | Sinudyne | 3081 |
| ITT | 3240, 3104, 3041, 3046, 3384 | Panasonic | 3035, 3162, 3225, 3226, 3227 | Solavox | 3020 |
| ITV | 3037, 3278 | Pathe Cinema | 3036 | Sonolor | 3046 |
| Imperial | 3000 | Pathe Marconi | 3041 | Sontec | 3037 |
| Interfunk | 3081 | Penney | 3035, 3037, 3240, 3042, 3038, 3040, 3054 | Sony | 3035, 3032, 3000, 3033, 3034 |
| JVC | 3067, 3041, 3008, 3384 | Pentax | 3042 | Sunstar | 3000 |
| Jensen | 3041 | Perdio | 3000 | Suntronic | 3000 |
| KEC | 3037, 3278 | Philco | 3035, 3209, 3038, 3479 | Sylvania | 3035, 3081, 3000, 3043 |
| KLH | 3072 | Philips | 3035, 3081, 3062, 3384 | Symphonic | 3000 |
| Kaisui | 3072 | Phonola | 3081 | TMK | 3240, 3036, 3208 |
| Kendo | 3209 | Pilot | 3037 | Tashiko | 3000 |
| Kenwood | 3067, 3041, 3038, 3384 | Pioneer | 3081, 3067, 3162, 3235 | Tatung | 3081, 3000, 3041 |
| Kodak | 3035, 3037 | Portland | 3020 | Teac | 3000, 3041 |
| Korpel | 3072 | Profitronic | 3240 | Tec | 3020 |
| LXI | 3037 | Proline | 3000 | Technics | 3035, 3162, 3226 |
| Lenco | 3278 | Proscan | 3060, 3202 | Teknika | 3035, 3037, 3000 |
| Leyco | 3072 | Protec | 3072 | Teleavia | 3041 |
| Lloyd's | 3000, 3208 | Pulsar | 3039 | Telefunken | 3041, 3187, 3320, 3384 |
| Loewe | 3037, 3081 | Pye | 3081 | Tenosal | 3072 |
| Logik | 3240, 3072 | Quarter | 3046 | Tensai | 3000 |
| Luxor | 3048, 3104, 3043, 3062, 3046 | Quartz | 3046 | Thomas | 3000 |
| M Electronic | 3000 | Quasar | 3035, 3162 | Thomson | 3041, 3320, 3384 |
| MEI | 3035 | Quelle | 3081 | Thorn | 3104, 3041, 3036 |
| MGA | 3240, 3043, 3061 | RCA | 3060, 3035, 3048, 3240, 3042, 3202 | Toshiba | 3081, 3045, 3043, 3041, 3066, 3212, 3366, 3384 |
| MGN Technology | 3240 | Radio Shack | 3037, 3000 | Totevision | 3037, 3240 |
| MTC | 3240, 3000 | Radiola | 3081 | Triumph | 3208 |
| Magnasonic | 3278 | Radix | 3037 | Uher | 3240 |
| Magnavox | 3035, 3039, 3081, 3000 | Randex | 3037 | Unitech | 3240 |
| Magnin | 3240 | Realistic | 3035, 3037, 3048, 3047, 3000, 3104, 3062, 3046, 3066 | Universum | 3037, 3081, 3240, 3000, 3195 |
| Manesth | 3045, 3072 | Rex | 3041, 3384 | Vector | 3045 |
| Marantz | 3035, 3081, 3062, 3295 | Ricoh | 3034 | Vector Research | 3038, 3040 |
| Marta | 3037 | Roadstar | 3037, 3240, 3072, 3278 | Video Concepts | 3045, 3040, 3061 |
| Matsui | 3209, 3036, 3208, 3295 | Runco | 3039 | Videosonic | 3240 |
| Matsushita | 3035, 3162 | SBR | 3081 | Wards | 3060, 3035, 3048, 3047, 3081, 3240, 3000, 3042, 3072, 3062, 3212 |
| Memorex | 3035, 3037, 3048, 3039, 3047, 3240, 3000, 3104, 3162, 3046 | SEG | 3240 | White Westinghouse | 3278 |
| Memphis | 3072 | SEI | 3081 | XR-1000 | 3035, 3000, 3072 |
| Metz | 3162, 3195, 3227 | STS | 3042 | Yamaha | 3038 |
| Minerva | 3195 | Saba | 3041, 3320, 3384 | Yamishi | 3072 |
| Minolta | 3042 | Saisho | 3209, 3036, 3208 | Yokan | 3072 |
| Mitsubishi | 3048, 3081, 3067, 3043, 3061, 3173, 3196 | Salora | 3043, 3046 | Yoko | 3240, 3020 |
| Motorola | 3035, 3048 | Samsung | 3240, 3045 | Zenith | 3039, 3000, 3033, 3034 |
| Multitech | 3000, 3072 | Sanky | 3048, 3039 | | |
| Murphy | 3000 | Sansui | 3000, 3067, 3041, 3271, 3479 | | |
| NEC | 3104, 3067, 3041, 3038, 3040 | Sanyo | 3047, 3240, 3104, 3046 | | |
| Neckermann | 3081 | | | | |

DVD PLAYER

| Manufacturer | Code |
|---------------------|-------------|
| JVC | 4558 |
| Kenwood | 4534 |
| Magnavox | 4503 |
| Mitsubishi | 4521 |
| Onkyo | 4503 |
| Panasonic | 4490 |
| Philips | 4503, 4539 |
| Pioneer | 4525 |
| Proscan | 4522 |
| RCA | 4522 |
| Sony | 4533 |
| Technics | 4490 |
| Toshiba | 4503 |
| Yamaha | 4490, 4545 |
| Zenith | 4503 |

LD PLAYER

| Manufacturer | Code |
|---------------------|------------------|
| Aiwa | 5203 |
| Carver | 5064, 5194, 5323 |
| Denon | 5059, 5172 |
| Disco Vision | 5023 |
| Funai | 5203 |
| Hitachi | 5023 |
| Magnavox | 5194, 5217 |
| Marantz | 5064, 5194 |
| Mitsubishi | 5059 |
| NAD | 5059 |
| Panasonic | 5204 |
| Philips | 5064, 5194 |
| Pioneer | 5059, 5023 |
| Quasar | 5204 |
| Realistic | 5203 |
| Salora | 5064 |
| Samsung | 5323 |
| Sega | 5023 |
| Sony | 5193, 5201 |
| Technics | 5204 |
| Telefunken | 5059 |
| Theta Digital | 5194 |
| Yamaha | 5217 |

CD PLAYER

| Manufacturer | Code |
|----------------------|------------------------------|
| ADC | 6018 |
| Acoustic Research | 6420 |
| Adcom | 6155 |
| Aiwa | 6157, 6012, 6124 |
| Akai | 6156 |
| Arcam | 6157 |
| Audio Pro | 6437 |
| Audio Research | 6157 |
| Audio-Technica | 6170 |
| Audio Ton | 6157 |
| Audiolab | 6157 |
| Audiomeca | 6157 |
| BSR | 6245 |
| Bestar | 6164 |
| Burmester | 6420 |
| Bush | 6245 |
| California Audio Lab | 6029 |
| Carver | 6157, 6179, 6437 |
| Condor | 6164 |
| Crown | 6122 |
| Cyrus | 6157 |
| DAK | 6245 |
| DKK | 6000 |
| Denon | 6003, 6034 |
| Elektra | 6393, 6437 |
| Emerson | 6305, 6155, 6164 |
| Fisher | 6179, 6048, 6088, 6342 |
| Garrard | 6420, 6393, 6245, 6280, 6425 |
| Genexxa | 6032, 6305, 6164, 6426 |
| Goodmans | 6305, 6245, 6280 |
| Grundig | 6157 |
| Harman/Kardon | 6426 |
| Hitachi | 6032, 6155 |
| JVC | 6072 |
| Kenwood | 6028, 6037, 6190, 6048 |
| Kodak | 6287 |
| Krell | 6157 |
| Kyocera | 6018 |
| LXI | 6305 |
| Linn | 6157 |
| Luxman | 6093 |
| MCS | 6029, 6043 |
| MTC | 6420 |
| Magnavox | 6157, 6305 |
| Marantz | 6029, 6157, 6180 |
| Matsui | 6157 |
| McIntosh | 6287 |
| Memorex | 6032, 6305, 6155, 6164, 6180 |
| Meridian | 6157 |
| Micromega | 6157 |
| Mission | 6157 |

| | |
|------------|--|
| Mitsubishi | 6156 |
| NAD | 6000 |
| NEC | 6043 |
| NSM | 6157 |
| Nagaoka | 6018 |
| Naim | 6157 |
| Nakamichi | 6147 |
| Nikko | 6164, 6170 |
| Onkyo | 6101 |
| Optimus | 6000, 6032, 6179, 6305, 6037, 6420, 6048, 6145, 6468, 6087, 6280, 6342, 6426, 6437 |
| Panasonic | 6029, 6303 |
| Parasound | 6420 |
| Philips | 6157, 6287 |
| Pioneer | 6032, 6305, 6468, 6244 |
| Poppy | 6164 |
| Proton | 6157 |
| QED | 6157 |
| Quad | 6157 |
| Quasar | 6029 |
| RCA | 6179, 6305, 6053, 6155 |
| Realistic | 6179, 6420, 6155, 6164, 6180 |
| Revox | 6157 |
| Roadstar | 6461 |
| Rotel | 6157, 6420 |
| Royal | 6420 |
| SAE | 6157 |
| STS | 6018 |
| Sansui | 6157, 6305, 6202 |
| Sanyo | 6179, 6048, 6087, 6342 |
| Scott | 6305, 6155, 6164 |
| Sears | 6305 |
| Sharp | 6037, 6180, 6261 |
| Sherwood | 6114, 6180, 6426 |
| Shure | 6043 |
| Sony | 6000, 6185 |
| Soundesign | 6145, 6425 |
| Tascam | 6420 |
| Teac | 6420, 6393, 6180 |
| Technics | 6029, 6303 |
| Universum | 6157, 6437 |
| Victor | 6072 |
| Wards | 6157, 6053 |
| Yamaha | 6036, 6187, 6261, 6082, 6712 |
| Yorx | 6461 |

MD RECORDER

| Manufacturer | Code |
|---------------------|-------------|
| Kenwood | 7826 |
| Sony | 7490 |
| Yamaha | 7888, 7490 |

TAPE DECK

| Manufacturer | Code |
|---------------------|------------------------------|
| ADC | 8171 |
| Aiwa | 8029, 8197 |
| Akai | 8283 |
| Arcam | 8076 |
| Carver | 8029 |
| Denon | 8076 |
| Fisher | 8074 |
| Garrard | 8308, 8309, 8375 |
| GoldStar | 8375 |
| Grundig | 8029, 8375 |
| JVC | 8244, 8274, 8303, 8304, 8310 |
| Kenwood | 8071, 8092, 8233, 8234 |
| Kyocera | 8171 |
| Magnavox | 8029 |
| Marantz | 8029, 8009 |
| Memorex | 8099 |
| Mitsubishi | 8283 |
| Onkyo | 8136, 8282 |
| Optimus | 8027, 8220, 8337 |
| Panasonic | 8229 |
| Philips | 8029 |
| Phonotrend | 8337 |
| Pioneer | 8027, 8220, 8099 |
| Revox | 8029, 8190 |
| Sansui | 8029, 8009 |
| Sanyo | 8074 |
| Sharp | 8231 |
| Sherwood | 8337 |
| Sonic | 8375 |
| Sony | 8243, 8170, 8291 |
| Teac | 8280, 8289, 8308, 8309 |
| Technics | 8229 |
| Universum | 8375 |
| Victor | 8274 |
| Wards | 8027 |
| Yamaha | 8097, 8094, 8478, 8524 |

LIST OF MANUFACTURER'S CODES (Australia model)
LISTE DES CODES FABRICANTS (Modèle pour l'Australie)

TV

| Manufacturer | Code | | | | |
|---------------------|--|--------------------|--|-----------------|--|
| Abex | 0032 | Condor | 0370, 0320 | Hanseatic | 0037, 0320, 0361 |
| Acura | 0009 | Contec | 0216, 0009, 0036, 0157 | Harley Davidson | 0043 |
| Admiral | 0093, 0163, 0213 | Continental Edison | 0196, 0198, 0205, 0333 | Harvard | 0068 |
| Adyson | 0217, 0032 | Crosley | 0074, 0076, 0084, 0213 | Hinari | 0037, 0218, 0009, 0036 |
| Akai | 0208, 0361 | Crown | 0037, 0370, 0418, 0009, 0076 | Hisawa | 0282, 0455 |
| Akura | 0218, 0264, 0369 | Crystal | 0431 | Hitachi | 0217, 0036, 0109, 0032, 0043, 0044, 0105, 0163, 0196, 0198, 0225, 0306, 0349 |
| Alaron | 0216 | Curtis Mathes | 0093 | Huanyu | 0216, 0374 |
| Alba | 0037, 0218, 0371, 0009, 0036, 0235 | Cybertron | 0218 | Hypson | 0037, 0282, 0264 |
| Allorgan | 0294 | Daewoo | 0037, 0374, 0009 | ICE | 0217, 0371, 0264 |
| Amplivision | 0217 | Dainichi | 0218, 0215 | ICeS | 0218 |
| Amstrad | 0371, 0009, 0362, 0369 | Dansai | 0037 | ITS | 0371 |
| Anam | 0009, 0068 | Dayton | 0009 | ITT | 0163, 0361 |
| Anitech | 0009, 0068, 0076 | De Graaf | 0208 | Imperial | 0370, 0418, 0074, 0076, 0084, 0247 |
| Arcam | 0216, 0217 | Decca | 0037, 0072 | Indiana | 0037 |
| Asberg | 0076 | Dixi | 0037, 0009 | Ingelen | 0163 |
| Asuka | 0218 | Dual | 0336, 0352 | Inno Hit | 0072 |
| Atlantic | 0206 | Dual Tec | 0217 | Interbuy | 0068 |
| Audiosonic | 0037, 0109 | Dumont | 0070 | Interfunk | 0037, 0163, 0247, 0361 |
| Autovox | 0206, 0076, 0336 | Elbe | 0259 | Intervision | 0037, 0217, 0264, 0102, 0068 |
| BPL | 0282 | Elin | 0037 | Isukai | 0218 |
| BSR | 0294 | Elite | 0218, 0320 | JVC | 0371, 0036, 0053, 0190, 0192 |
| BTC | 0218 | Elta | 0009 | KTV | 0217 |
| Baird | 0343 | Emerson | 0282, 0213, 0361 | Kaisui | 0216, 0217, 0218, 0009, 0282 |
| Basic Line | 0218, 0009 | Erres | 0037, 0012 | Kamp | 0216 |
| Baur | 0037, 0010, 0554, 0349, 0361 | Expert | 0206 | Kapsch | 0206, 0163 |
| Beko | 0370 | Ferguson | 0037, 0109, 0005, 0073, 0190, 0238, 0287, 0335, 0343 | Kawasho | 0216 |
| Beon | 0037 | Fidelity | 0216, 0361 | Kendo | 0037, 0235, 0362 |
| Binatone | 0217 | Finlandia | 0208, 0346, 0359 | Kingsley | 0216 |
| Blaupunkt | 0554, 0191, 0195, 0200, 0213, 0327, 0328 | Finlux | 0037, 0072, 0070, 0105, 0346 | Kneissel | 0259 |
| Blue Sky | 0218 | Firstline | 0216, 0217, 0294, 0009, 0321, 0247 | Korpel | 0037 |
| Blue Star | 0282 | Fisher | 0370, 0217, 0208, 0303 | Koyoda | 0009 |
| Bondstec | 0247 | Flint | 0455 | Leyco | 0037, 0294, 0072, 0264 |
| Boots | 0217 | Formenti | 0037, 0320, 0213 | Liesenk & Tter | 0037 |
| Brandt | 0109, 0196, 0198, 0205, 0333, 0335 | Frontech | 0264, 0431, 0163, 0247 | Lloytron | 0032 |
| Brionvega | 0362 | Fujitsu | 0072, 0206 | Loewe | 0075 |
| Britannia | 0216 | Funai | 0294, 0264, 0303 | Luma | 0206 |
| Bush | 0037, 0218, 0374, 0371, 0294, 0009, 0282, 0036, 0349 | GE | 0282, 0093 | Luxor | 0349, 0361 |
| CCE | 0037, 0217 | GEC | 0037, 0217, 0072, 0043, 0205 | M Electronic | 0037, 0217, 0374, 0009, 0109, 0068, 0105, 0163, 0287, 0346 |
| CGE | 0074, 0076, 0084, 0247, 0306 | GPM | 0218 | MGA | 0150 |
| CS Electronics | 0216 | Geloso | 0009, 0213 | MTC | 0216, 0349 |
| CTC | 0247 | Genexxa | 0218, 0163 | Magnadyne | 0102, 0247 |
| Carrefour | 0036 | GoldStar | 0037, 0217, 0109, 0032, 0290 | Magnafon | 0102, 0076, 0213 |
| Cascade | 0009 | Goodmans | 0037, 0217, 0374, 0371, 0072, 0036, 0235, 0317, 0343 | Magnavox | 0036 |
| Cathay | 0037 | Gorenje | 0370 | Manesth | 0217, 0320, 0264, 0235 |
| Centurion | 0037 | Gradiente | 0053 | Marantz | 0037 |
| Century | 0213 | Graetz | 0163, 0361 | Mark | 0037 |
| Cimline | 0009 | Granada | 0037, 0217, 0072, 0146, 0208, 0339, 0359 | Matsui | 0037, 0217, 0371, 0294, 0009, 0072, 0036, 0035, 0011, 0208, 0235 |
| Clarivox | 0037 | Grandin | 0282 | Matsushita | 0250 |
| Clatronic | 0370, 0076, 0247 | Grundig | 0037, 0554, 0070, 0191, 0195, 0205 | McMichael | 0043 |
| | | HCM | 0009, 0282 | | |

| | | | | | |
|---------------|--|---------------|--|--------------------|--|
| Mediator | 0037, 0012 | Radio Shack | 0032 | Teletech | 0009 |
| Memorex | 0009, 0250, 0150 | Radiola | 0037, 0012, 0323 | Teleton | 0217, 0206, 0349 |
| Memphis | 0337 | Rank Arena | 0036 | Tensai | 0218, 0294, 0320, 0317 |
| Metz | 0213, 0367 | Realistic | 0032 | Texet | 0216, 0218 |
| Midland | 0032 | Rediffusion | 0361 | Thomson | 0109, 0196, 0198, 0205, 0287, 0333, 0343, 0349 |
| Minerva | 0554, 0070 | Revox | 0037 | Thorn | 0037, 0072, 0035, 0074, 0084, 0190, 0192, 0361 |
| Minoka | 0369 | Rex | 0206, 0264, 0163, 0259 | Thorn-Ferguson | 0343 |
| Mitsubishi | 0036, 0093, 0108, 0150 | Rhapsody | 0216 | Tomashi | 0282 |
| Mivar | 0216, 0290, 0291, 0292 | Roadstar | 0218, 0418, 0009, 0264 | Toshiba | 0036, 0035, 0070, 0243 |
| Motion | 0076 | SBR | 0037, 0012, 0043 | Trical | 0157 |
| Motorola | 0093 | SEG | 0217, 0264, 0036, 0076 | Triumph | 0243 |
| Multitech | 0216, 0217, 0009, 0102, 0076 | SEI | 0294, 0102, 0213 | Uher | 0206, 0320, 0303 |
| NEC | 0455, 0036 | Saba | 0109, 0075, 0163, 0196, 0198, 0205, 0213, 0287, 0335, 0343 | Ultra | 0192 |
| NEI | 0037, 0431, 0337 | Sacccs | 0238 | Ultravox | 0102 |
| Neckermann | 0037, 0554, 0191, 0213, 0349 | Saisho | 0009, 0264, 0431, 0011, 0235 | Universum | 0037, 0370, 0264, 0105, 0346 |
| Nikkai | 0037, 0216, 0218, 0072, 0264, 0035, 0032, 0337 | Salora | 0163, 0349, 0359, 0361 | Vestel | 0037 |
| Nikko | 0317 | Sambers | 0102, 0076, 0213 | Victor | 0053 |
| Nobliko | 0102, 0076 | Sampo | 0032 | Videosat | 0247 |
| Nokia | 0361 | Samsung | 0037, 0370, 0217, 0009, 0264, 0032, 0090, 0290 | Videotechnic | 0217 |
| Nordmende | 0109, 0196, 0198, 0213, 0287, 0343 | Sandra | 0216 | Vidtech | 0036 |
| Oceanic | 0163, 0215, 0361 | Sanyo | 0072, 0036, 0011, 0146, 0157, 0208, 0213, 0339 | Vision | 0320 |
| Optimus | 0250 | Schaub Lorenz | 0361 | Voxson | 0163 |
| Optonica | 0093 | Schneider | 0037, 0218, 0371, 0247, 0303, 0323, 0336, 0352 | Waltham | 0217 |
| Orion | 0037, 0294, 0320, 0321, 0235 | Sears | 0146 | Watson | 0037, 0320 |
| Osaki | 0217, 0218, 0072, 0264, 0032 | Sei-Sinudyne | 0010 | Watt Radio | 0102 |
| Oso | 0218 | Seleco | 0206, 0163, 0259, 0362 | Wega | 0036 |
| Osume | 0072, 0032, 0157 | Sentra | 0035 | White Westinghouse | 0037, 0216, 0320 |
| Otake | 0317 | Sharp | 0036, 0093, 0157 | Yoko | 0037, 0217, 0264, 0431 |
| Otto Versand | 0037, 0217, 0320, 0036, 0010, 0554, 0191, 0213, 0343, 0349 | Shorai | 0294 | Zanussi | 0206 |
| Palladium | 0370, 0418 | Siarem | 0102, 0213 | | |
| Panama | 0217, 0264 | Siemens | 0037, 0554, 0157, 0191, 0195, 0200, 0213, 0327, 0328 | | |
| Panasonic | 0250, 0163, 0213, 0214, 0226, 0367 | Silver | 0036 | | |
| Pathe Cinema | 0216, 0320, 0213, 0238 | Sinudyne | 0294, 0102, 0213, 0235 | | |
| Pathe Marconi | 0196, 0198, 0205, 0333 | Solavox | 0032, 0163 | | |
| Pausa | 0009 | Sonitron | 0208 | | |
| Penney | 0032 | Sonoko | 0037, 0009 | | |
| Perdio | 0320 | Sonolor | 0163, 0208, 0215 | | |
| Phase | 0032 | Sontec | 0037 | | |
| Philco | 0074, 0076, 0084, 0213, 0247 | Sony | 0036, 0010, 0011 | | |
| Philips | 0037, 0374, 0554, 0012, 0043, 0323 | Soundwave | 0037, 0418 | | |
| Phonola | 0037, 0012 | Standard | 0217, 0218, 0009 | | |
| Pioneer | 0109, 0163, 0287 | Stern | 0206, 0163, 0259 | | |
| Profex | 0009, 0076, 0361 | Sunkai | 0294, 0321 | | |
| Proline | 0321 | Susumu | 0218 | | |
| Protech | 0037, 0217, 0418, 0009, 0264, 0102, 0431, 0247, 0337 | Sysline | 0037 | | |
| Pye | 0012 | Tandy | 0217, 0218, 0072, 0093, 0163 | | |
| Quasar | 0250 | Tashiko | 0217, 0036, 0043, 0359 | | |
| Quelle | 0037, 0010, 0554, 0011, 0070, 0074, 0084, 0200, 0213, 0306, 0327, 0328, 0361 | Tatung | 0037, 0217, 0072 | | |
| Questa | 0036 | Tec | 0217, 0247 | | |
| R-Line | 0037 | Technema | 0320 | | |
| RBM | 0070 | Technics | 0250 | | |
| RCA | 0090, 0093 | Teknika | 0150 | | |
| | | Teleavia | 0205, 0333, 0343 | | |
| | | Telefunken | 0109, 0005, 0074, 0084, 0101, 0213, 0262, 0306, 0335, 0343 | | |
| | | Telemeister | 0320 | | |

CABLE

| Manufacturer | Code |
|---------------------------------|------------------------|
| ABC | 1003, 1008, 1014, 1017 |
| Birmingham Cable Communications | 1276 |
| British Telecom | 1003, 1105 |
| Cabletime | 1161, 1271, 1377 |
| Clyde | 1086 |
| Contec | 1019 |
| Decsat | 1423 |
| Filmnet | 1443 |
| France Telecom | 1451 |
| GEC | 1086 |
| General Instrument | 1276 |
| GoldStar | 1144 |
| Jerrold | 1003, 1276, 1014 |
| MNet | 1443, 1019 |
| Magnavox | 1032 |
| Memorex | 1000 |
| Movie Time | 1156 |
| NSC | 1156 |
| Oak | 1019 |
| PVP Stereo Visual Matrix | 1003 |
| Panasonic | 1000 |
| Paragon | 1000 |

| | | | | | |
|--------------------|------------------|---------------------|------------------------------------|------------|------------------------------------|
| Pioneer | 1144, 1260 | Emanon | 2421 | Pace | 2455, 2183, 2067, 2328, 2336, 2791 |
| Pulsar | 1000 | FTE | 2331 | Palcom | 2297 |
| Runco | 1000 | Ferguson | 2183, 2067, 2189, 2336 | Palladium | 2571 |
| STS | 1156 | Fidelity | 2252 | Palsat | 2501 |
| Salora | 1382 | Finlux | 2455, 2108, 2344, 2397 | Panda | 2455 |
| Samsung | 1144 | Fracarro | 2871 | Philips | 2455, 2571, 2200, 2292, 2328 |
| Satbox | 1375 | Freecom | 2421, 2335 | Phonotrend | 2288, 2592 |
| Scientific Atlanta | 1008, 1277, 1017 | Fuba | 2421, 2369, 2396, 2217, 2297, 2417 | Planet | 2871 |
| Starcom | 1003 | G-Sat | 2183 | Plasmatic | 2442 |
| Tele+1 | 1443 | Galaxis | 2288, 2834, 2863 | Polytron | 2394 |
| Teleservice | 1281 | Galaxisat | 2321 | Promax | 2455 |
| Toshiba | 1000 | GoldStar | 2335 | Prosat | 2288 |
| Tudi | 1286 | Gooding | 2571 | Quadral | 2362, 2519 |
| United Cable | 1003 | Goodmans | 2189 | RFT | 2288, 2220, 2200 |
| Videoway | 1250 | Grothusen | 2335 | Radiola | 2200 |
| Westminster | 1105 | Grundig | 2571, 2173, 2189, 2328 | Radix | 2396, 2882 |
| Zenith | 1000 | Harting und Helling | 2333 | SAT | 2321, 2351, 2461 |

DBS TUNER

Manufacturer Code

| | |
|----------------|------------------------------|
| AST | 2321, 2351 |
| Alba | 2455, 2421, 2362, 2613 |
| Aldes | 2288 |
| Allantide | 2333 |
| Amstrad | 2080, 2252, 2345, 2461, 2501 |
| Ankaro | 2369, 2288, 2220, 2519, 2217 |
| Anttron | 2421, 2183 |
| Arcon | 2368 |
| Armstrong | 2243 |
| Astra | 2108, 2539 |
| Astro | 2520, 2173, 2358, 2501 |
| Avalon | 2396 |
| Axis | 2369, 2530 |
| BT | 2668 |
| Barcom | 2217 |
| Beko | 2189 |
| Best | 2369, 2217 |
| Blaupunkt | 2173 |
| Boca | 2243, 2513 |
| Brain Wave | 2332 |
| Bush | 2067 |
| CNT | 2520 |
| Cambridge | 2344 |
| Channel Master | 2362 |
| Chaparral | 2053, 2209 |
| CityCom | 2394 |
| Commlink | 2288 |
| Connexions | 2396 |
| Crown | 2243 |
| Cyrus | 2200 |
| D-box | 2723 |
| DDC | 2362 |
| DNT | 2396, 2200 |
| Diskxpress | 2217 |
| Drake | 2268 |
| EIF | 2417 |
| Echostar | 2396, 2871 |

| | | | |
|------------------|--|-----------------|--|
| Hitachi | 2455 | Saba | 2520, 2336 |
| Houston | 2668 | Sabre | 2455 |
| Huth | 2243, 2288, 2220, 2346 | Sagem | 2820 |
| ITT | 2108 | Salora | 2108 |
| InVideo | 2871 | Samsung | 2287 |
| Intervision | 2592 | SatPartner | 2421, 2332, 2520, 2502, 2335, 2692 |
| JVC | 2571 | Satcom | 2605, 2346 |
| Johansson | 2332 | Satec | 2183, 2328 |
| Kathrein | 2173, 2200, 2092, 2331, 2358, 2394, 2442, 2480, 2504 | Satmaster | 2346 |
| Kosmos | 2331, 2335 | Schwaiger | 2183, 2394, 2504 |
| Kreiselmeier | 2173 | Seemann | 2396, 2530 |
| Kyostar | 2421 | Siemens | 2173 |
| La Sat | 2520, 2513, 2464 | Skymaster | 2288, 2605, 2519 |
| Lemon | 2692 | Star Trak | 2421 |
| Lenco | 2421, 2335 | Strong | 2421 |
| Lennox | 2592 | Sunstar | 2513 |
| Lupus | 2369 | TPS | 2820 |
| Luxor | 2573, 2108 | Tantec | 2455, 2297, 2336 |
| Manhattan | 2455, 2592, 2520 | TechniSat | 2262, 2501 |
| Marantz | 2200 | Techniland | 2346 |
| Maspro | 2092, 2328, 2336 | Telefunken | 2421 |
| Matsui | 2571, 2344 | Teleka | 2243, 2613 |
| Mediamarkt | 2243 | Telesat | 2605 |
| Micro Technology | 2333, 2539 | Thomson | 2455 |
| Minerva | 2571 | Tonna | 2668, 2346 |
| Morgan's | 2243, 2513 | Triad | 2321, 2333, 2335, 2351 |
| Multistar | 2331, 2464 | Triasat | 2501 |
| Muratto | 2335 | Unitor | 2332, 2217 |
| Navex | 2332 | Universum | 2571, 2173 |
| Neuhaus | 2501 | Vector | 2333 |
| Neusat | 2692, 2834 | Ventana | 2200 |
| Newhaus | 2220 | Vortec | 2421 |
| Nikko | 2360 | Vtech | 2351 |
| Nokia | 2455, 2573, 2108, 2328, 2397, 2873 | Wevasat | 2333 |
| Nordmende | 2362 | Winersat | 2332 |
| Orbitech | 2501 | Wisi | 2455, 2396, 2173, 2321, 2351, 2372, 2406, 2407 |
| Oxford | 2344 | XSat | 2889 |
| | | Xcom Multimedia | 2889 |
| | | Zehnder | 2520, 2321, 2331 |

VCR

Manufacturer

Code

ASA 3037, 3081
 Admiral 3048
 Adventura 3000
 Aiko 3278
 Aiwa 3000, 3037, 3307, 3348, 3352
 Akai 3315, 3106, 3041, 3053
 Akiba 3072
 Alba 3072, 3020, 3278, 3209, 3315, 3352
 Ambassador 3020
 Amstrad 3000, 3278, 3325, 3332
 Anitech 3072
 Asha 3240
 Asuka 3037
 Audiovox 3037
 Baird 3000, 3041, 3104, 3107
 Basic Line 3072, 3020, 3278
 Beaumark 3240
 Bell & Howell 3104
 Blaupunkt 3034, 3226, 3195, 3003, 3006, 3154, 3162, 3227, 3403
 Brandt 3320, 3187, 3321
 Brandt Electronic 3041
 Broksonic 3209
 Bush 3072, 3278, 3209, 3352
 CCE 3072, 3278
 CGE 3000
 Calix 3037
 Capehart 3020
 Carver 3081
 Catron 3020
 Cimline 3072
 Cinal 3278
 Citizen 3037, 3278
 Clatronic 3020
 Colt 3072
 Combitech 3352
 Condor 3020
 Craig 3072, 3037, 3047, 3240
 Crown 3072, 3020, 3278
 Curtis Mathes 3041, 3162
 Cybernex 3240
 Cyrus 3081
 Daewoo 3020, 3278, 3045
 Dansai 3072
 Daytron 3020
 De Graaf 3042, 3166
 Decca 3000, 3081
 Denon 3042
 Dual 3041
 Dumont 3000, 3081, 3104
 Dynatech 3000
 ESC 3278, 3240
 Elbe 3038
 Elcatech 3072
 Electrohome 3037

Electrophonic 3037
 Emerex 3032
 Emerson 3000, 3037, 3278, 3209, 3036, 3043, 3088
 Ferguson 3320, 3041, 3107, 3321
 Fidelity 3000
 Finlandia 3081, 3104
 Finlux 3000, 3081, 3042, 3104
 Firstline 3072, 3037, 3209, 3045, 3043
 Fisher 3046, 3047, 3054, 3104
 Frontech 3020
 Fuji 3033
 Funai 3000
 GE 3048, 3240
 GEC 3081
 Garrard 3000
 General 3020
 Go Video 3432
 GoldHand 3072
 GoldStar 3037, 3038, 3225
 Goodmans 3072, 3000, 3020, 3037, 3278, 3403
 Gradiente 3000, 3008
 Graetz 3005, 3041, 3104, 3240
 Granada 3081, 3046, 3104
 Grandin 3072, 3000, 3037
 Grundig 3072, 3081, 3347, 3226, 3195, 3003, 3006, 3007, 3207, 3349, 3403
 HCM 3072
 HI-Q 3047
 Hanseatic 3037
 Harley Davidson 3000
 Harman/Kardon 3038
 Harwood 3072
 Headquarter 3046
 Hinari 3072, 3004, 3240, 3352
 Hitachi 3000, 3004, 3042, 3041, 3166, 3235, 3240
 Hypson 3072
 ITT 3106, 3046, 3384, 3005, 3041, 3104, 3240
 ITV 3037, 3278
 Imperial 3000
 Ingersol 3004
 Interfunk 3081
 JVC 3067, 3384, 3008, 3041, 3206, 3207, 3486
 Jensen 3041
 KEC 3037, 3278
 KLH 3072
 Kaisui 3072
 Kendo 3209, 3106
 Kenwood 3067, 3384, 3038, 3041
 Kodak 3037
 Korpel 3072
 LXI 3037
 Lenco 3278
 Leyco 3072
 Lloyd's 3000
 Loewe 3037, 3004, 3081, 3006

Logik 3072, 3004, 3240
 Luxor 3106, 3048, 3046, 3043, 3104
 M Electronic 3000
 MGA 3043, 3240
 MGN Technology 3240
 MTC 3000, 3240
 Magnasonic 3278
 Magnavox 3000, 3081
 Magnin 3240
 Manesth 3072, 3045
 Marantz 3081, 3003, 3006
 Marta 3037
 Matsui 3209, 3004, 3036, 3088, 3348, 3352
 Matsushita 3162
 Memorex 3000, 3037, 3048, 3046, 3047, 3104, 3162, 3240, 3307
 Memphis 3072
 Metz 3347, 3195, 3003, 3006, 3162, 3227
 Minerva 3195, 3006
 Minolta 3042
 Mitsubishi 3081, 3067, 3048, 3043
 Motorola 3048
 Multitech 3072, 3000
 Murphy 3000
 NEC 3067, 3038, 3041, 3104
 Neckermann 3081
 Nesco 3072
 Nikko 3037
 Nikon 3034
 Noblex 3240
 Nokia 3106, 3046, 3041, 3104, 3240
 Nordmende 3320, 3384, 3041, 3297, 3321
 Oceanic 3000, 3041
 Okano 3315, 3348
 Olympus 3226
 Optimus 3037, 3432, 3048, 3104, 3162
 Orion 3209, 3004, 3036, 3088, 3348, 3352
 Osaki 3072, 3000, 3037
 Otto Versand 3081
 Palladium 3072, 3037, 3006, 3041
 Panasonic 3226, 3162, 3225, 3227
 Pathe Cinema 3036
 Pathe Marconi 3041
 Penney 3037, 3042, 3038, 3054, 3240
 Pentax 3042
 Perdio 3000
 Philco 3209, 3038
 Philips 3081, 3384, 3403
 Phonola 3081
 Pilot 3037
 Pioneer 3081, 3067, 3162, 3235
 Portland 3020
 Profex 3322
 Profitronic 3240
 Proline 3000
 Protec 3072
 Pye 3081

Quarter 3046
 Quartz 3046
 Quasar 3162
 Quelle 3081
 RCA 3106, 3042, 3048, 3240
 RFT 3403
 Radio Shack 3000, 3037
 Radiola 3081
 Radix 3037
 Randex 3037
 Realistic 3000, 3037, 3048, 3046, 3047, 3104
 Rex 3384, 3041
 Ricoh 3034
 Roadstar 3072, 3037, 3278, 3240
 SBR 3081
 SEG 3322, 3240
 SEI 3004, 3081
 STS 3042
 Saba 3320, 3384, 3041, 3206, 3207, 3297, 3321
 Saisho 3209, 3004, 3036, 3088
 Salora 3106, 3046, 3043
 Samsung 3432, 3045, 3053, 3240
 Sanky 3048
 Sansui 3000, 3067, 3041
 Sanyo 3046, 3047, 3104, 3240
 Saville 3352
 Schaub Lorenz 3000, 3005, 3041, 3104
 Schneider 3072, 3000, 3081
 Scott 3045, 3043
 Sears 3000, 3037, 3042, 3046, 3047, 3054, 3104
 Seleco 3041
 Semp 3045
 Sentra 3020
 Sharp 3048
 Shintom 3072, 3104
 Shogun 3240
 Shorai 3004
 Siemens 3037, 3081, 3195, 3003, 3006, 3054, 3104
 Silva 3037
 Singer 3072, 3045
 Sinudyne 3004, 3081
 Solavox 3020
 Sonolor 3046
 Sontec 3037
 Sony 3000, 3032, 3033, 3034, 3011
 Sunkai 3348
 Sunstar 3000
 Suntronic 3000
 Sylvania 3000, 3081, 3043
 Symphonic 3000
 TMK 3036, 3240
 Tashiko 3000
 Tatung 3000, 3081, 3041
 Teac 3000, 3041
 Tec 3020
 Technics 3226, 3162
 Teknika 3000, 3037

Teleavia 3041
 Telefunken 3320, 3384, 3041, 3187, 3321
 Tenosal 3072
 Tensai 3322, 3000
 Thomas 3000
 Thomson 3320, 3384, 3041
 Thorn 3036, 3041, 3104
 Toshiba 3081, 3045, 3384, 3041, 3043
 Totevision 3037, 3240
 Towada 3322
 Uher 3240
 Unitech 3240
 Universum 3000, 3037, 3081, 3106, 3195, 3006, 3240, 3325
 Vector 3045
 Vector Research 3038
 Video Concepts 3045
 Videosonic 3240
 Wards 3072, 3000, 3081, 3042, 3048, 3047, 3240
 White Westinghouse 3278
 XR-1000 3072, 3000
 Yamaha 3038
 Yamishi 3072
 Yokan 3072
 Yoko 3020, 3240
 Zenith 3000, 3033, 3034

Mitsubishi 5059
 NAD 5059
 Panasonic 5204, 5496
 Philips 5064, 5388, 5194
 Pioneer 5023, 5059
 Quasar 5204
 Radiola 5388
 Realistic 5203
 Salora 5064
 Sega 5023
 Sharp 5001
 Sony 5193, 5201
 Technics 5204, 5496
 Telefunken 5059
 Theta Digital 5194
 Thorn 5014
 Yamaha 5217

CD PLAYER

| Manufacturer | Code |
|----------------------|------------------------------|
| Aiwa | 6124, 6157, 6419 |
| Akai | 6108, 6156, 6199 |
| Alba | 6536, 6288, 6334 |
| Arcam | 6157 |
| Audio Research | 6157 |
| Audio Ton | 6157 |
| Audiolab | 6157 |
| Audiomeca | 6157 |
| BSR | 6134 |
| Bestar | 6164 |
| Binatone | 6452 |
| California Audio Lab | 6029 |
| Carver | 6157, 6179 |
| Condor | 6134, 6164 |
| Cyrus | 6157 |
| DKK | 6000 |
| Denon | 6003, 6034 |
| Dual | 6196 |
| Emerson | 6164 |
| Fisher | 6048, 6179, 6342 |
| GE | 6334 |
| Genexxa | 6032, 6164 |
| GoldStar | 6525, 6383 |
| Goodmans | 6536 |
| Grundig | 6157 |
| Harman/Kardon | 6108, 6173 |
| Hitachi | 6032, 6291 |
| JVC | 6072 |
| Kenwood | 6037, 6523, 6028, 6048, 6190 |
| Kodak | 6287 |
| Krell | 6157 |
| Linn | 6157 |
| Luxman | 6328 |
| M Electronic | 6525 |
| MCS | 6029 |
| Magnavox | 6157, 6038, 6129 |

DVD PLAYER

| Manufacturer | Code |
|--------------|------------|
| Kenwood | 4534 |
| Magnavox | 4503 |
| Onkyo | 4503 |
| Panasonic | 4490 |
| Philips | 4539, 4503 |
| Pioneer | 4525 |
| Sony | 4533 |
| Technics | 4490 |
| Thomson | 4551 |
| Toshiba | 4503 |
| Yamaha | 4490, 4545 |
| Zenith | 4503 |

LD PLAYER

| Manufacturer | Code |
|--------------|------------|
| Aiwa | 5203 |
| Carver | 5064, 5194 |
| Cyrus | 5388 |
| Denon | 5059, 5172 |
| Disco Vision | 5023 |
| Funai | 5203 |
| Hitachi | 5023 |
| Magnavox | 5194, 5217 |
| Marantz | 5064, 5194 |

| | |
|------------|---|
| Marantz | 6157, 6029, 6038, 6129 |
| Matsui | 6157, 6288, 6307 |
| McIntosh | 6287 |
| Memorex | 6032, 6164 |
| Meridian | 6157 |
| Micromega | 6157 |
| Mission | 6157 |
| Mitsubishi | 6108, 6156 |
| NAD | 6000 |
| NSM | 6157 |
| Naim | 6157 |
| Nikko | 6525, 6164 |
| Onkyo | 6101, 6102 |
| Optimus | 6000, 6032, 6037, 6536, 6048, 6179, 6196, 6342 |
| Panasonic | 6303, 6029, 6367 |
| Philips | 6157, 6274, 6287 |
| Pioneer | 6032 |
| Poppy | 6164 |
| Proton | 6157 |
| QED | 6157 |
| Quad | 6157 |
| Quasar | 6029 |
| RCA | 6179 |
| Realistic | 6164, 6179 |
| Revox | 6157, 6113 |
| Roadstar | 6461, 6525, 6527 |
| Rotel | 6157 |
| SAE | 6157 |
| Sansui | 6157, 6202, 6513 |
| Sanyo | 6048, 6179, 6342 |
| Schneider | 6134 |
| Scott | 6164 |
| Sharp | 6037, 6262, 6265 |
| Sherwood | 6114, 6196 |
| Siemens | 6516 |
| Signature | 6108 |
| Sony | 6000, 6490 |
| Teac | 6378 |
| Technics | 6207, 6303, 6029 |
| Toshiba | 6481 |
| Universum | 6157 |
| Victor | 6072 |
| Wards | 6157, 6108 |
| Yamaha | 6036, 6082, 6187, 6712 |
| Yorx | 6461 |

MD RECORDER

| Manufacturer | Code |
|--------------|------------|
| Kenwood | 7826 |
| Sony | 7490 |
| Yamaha | 7888, 7490 |

TAPE DECK

| Manufacturer | Code |
|---------------|---------------------------------------|
| Aiwa | 8029, 8197, 8200 |
| Akai | 8188, 8189 |
| Arcam | 8076 |
| Carver | 8029 |
| Denon | 8076, 8412 |
| Fisher | 8074 |
| Grundig | 8029 |
| Harman/Kardon | 8182 |
| JVC | 8244, 8273, 8274 |
| Kenwood | 8070, 8071, 8092, 8205, 8233, 8234 |
| Magnavox | 8029 |
| Marantz | 8029, 8009 |
| Memorex | 8099, 8101 |
| Mitsubishi | 8189 |
| Onkyo | 8136, 8135 |
| Optimus | 8027, 8220 |
| Panasonic | 8229 |
| Philips | 8029 |
| Pioneer | 8027, 8099, 8101, 8220 |
| Revox | 8029 |
| Sansui | 8029, 8009 |
| Sanyo | 8074 |
| Sharp | 8205 |
| Sony | 8170, 8243 |
| Technics | 8229 |
| Victor | 8273, 8274 |
| Wards | 8027 |
| Yamaha | 8094, 8097, 8205, 8478, 8524 |

Quick Reference Card

