



⚠ Read this manual carefully before operating this vehicle.

OWNER'S MANUAL

**VITEV**

***XC125E***

**4P7-F8199-E2**

DIC183



 **Read this manual carefully before operating this vehicle. This manual should stay with this vehicle if it is sold.**

## INTRODUCTION

---

EAU10113

Welcome to the Yamaha world of motorcycling!

As the owner of the XC125E, you are benefiting from Yamaha's vast experience and newest technology regarding the design and manufacture of high-quality products, which have earned Yamaha a reputation for dependability.

Please take the time to read this manual thoroughly, so as to enjoy all advantages of your XC125E. The Owner's Manual does not only instruct you in how to operate, inspect and maintain your scooter, but also in how to safeguard yourself and others from trouble and injury.

In addition, the many tips given in this manual will help keep your scooter in the best possible condition. If you have any further questions, do not hesitate to contact your Yamaha dealer.

The Yamaha team wishes you many safe and pleasant rides. So, remember to put safety first!

Yamaha continually seeks advancements in product design and quality. Therefore, while this manual contains the most current product information available at the time of printing, there may be minor discrepancies between your scooter and this manual. If there is any question concerning this manual, please consult a Yamaha dealer.

EWA12411

### **WARNING**

---





**Please read this manual carefully and completely before operating this scooter.**

---

## IMPORTANT MANUAL INFORMATION

---

Particularly important information is distinguished in this manual by the following notations:

	<b>This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.</b>
	<b>A WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.</b>
	<b>A NOTICE indicates special precautions that must be taken to avoid damage to the vehicle or other property.</b>
	<b>A TIP provides key information to make procedures easier or clearer.</b>

## **IMPORTANT MANUAL INFORMATION**

---

EAU37230

**XC125E  
OWNER'S MANUAL  
©2009 by Yamaha Motor Co., Ltd.  
1st edition, July 2009  
All rights reserved.  
Any reprinting or unauthorized use  
without the written permission of  
Yamaha Motor Co., Ltd.  
is expressly prohibited.  
Printed in China.**

## TABLE OF CONTENTS

<b>SAFETY INFORMATION</b> .....	1-1	<b>FOR YOUR SAFETY –</b>		
Further safe-riding points .....	1-5	<b>PRE-OPERATION CHECKS</b> .....	4-1	
<b>DESCRIPTION</b> .....	2-1	<b>OPERATION AND IMPORTANT</b>		
Left view .....	2-1	<b>RIDING POINTS</b> .....	5-1	
Right view .....	2-2	Starting the engine .....	5-1	
Controls and instruments.....	2-3	Starting off .....	5-2	
<b>INSTRUMENT AND CONTROL</b>		Acceleration and deceleration .....	5-2	
<b>FUNCTIONS</b> .....	3-1	Braking .....	5-3	
Main switch/steering lock .....	3-1	Tips for reducing fuel		
Keyhole cover .....	3-2	consumption .....	5-3	
Indicator, indicator lights and		Engine break-in .....	5-4	
warning light .....	3-2	Parking .....	5-4	
Speedometer unit .....	3-3	<b>PERIODIC MAINTENANCE AND</b>		
Self-diagnosis device .....	3-4	<b>ADJUSTMENT</b> .....	6-1	
Fuel gauge .....	3-4	Periodic maintenance chart for		
Anti-theft alarm (optional) .....	3-4	the emission control system .....	6-2	
Handlebar switches .....	3-5	General maintenance and		
Front brake lever .....	3-5	lubrication chart .....	6-3	
Rear brake lever .....	3-6	Removing and installing cowlings		
Fuel tank cap .....	3-6	and panels .....	6-6	
Fuel .....	3-7	Checking the spark plug .....	6-8	
Catalytic converters .....	3-8	Engine oil .....	6-9	
Seat .....	3-8	Final transmission oil .....	6-11	
Helmet holders .....	3-9	Air filter and V-belt case air filter		
Storage compartments .....	3-10	elements .....	6-12	
Carrier .....	3-11	Checking the throttle cable free		
Luggage hook .....	3-11	play .....	6-14	
Sidestand .....	3-11	Valve clearance .....	6-15	
Ignition circuit cut-off system .....	3-12	Tires .....	6-15	
		Cast wheels .....	6-17	
		Checking the front brake lever		
		free play .....	6-17	
		Adjusting the rear brake lever		
		free play .....	6-17	
		Checking the front brake pads		
		and rear brake shoes .....	6-18	
		Checking the front brake fluid		
		level .....	6-19	
		Changing the brake fluid .....	6-20	
		Checking and lubricating		
		the cables .....	6-20	
		Checking and lubricating		
		the throttle grip and cable .....	6-20	
		Lubricating the front and rear		
		brake levers .....	6-21	
		Checking and lubricating the		
		centerstand and sidestand .....	6-21	
		Checking the front fork .....	6-22	
		Checking the steering .....	6-23	
		Checking the wheel bearings .....	6-23	
		Battery .....	6-23	
		Replacing the fuse .....	6-25	
		Replacing the headlight bulb .....	6-25	
		Replacing a front turn signal light		
		bulb .....	6-26	
		Rear turn signal light and tail/brake		
		light .....	6-27	
		Replacing the auxiliary light		
		bulb .....	6-27	
		Troubleshooting .....	6-28	

## **TABLE OF CONTENTS**

---

Troubleshooting chart .....	6-29
<b>SCOOTER CARE AND STORAGE ...</b>	<b>7-1</b>
Matte color caution .....	7-1
Care .....	7-1
Storage .....	7-3
<b>SPECIFICATIONS .....</b>	<b>8-1</b>
<b>CONSUMER INFORMATION.....</b>	<b>9-1</b>
Identification numbers .....	9-1

## SAFETY INFORMATION

EAU10264

### 1 Be a Responsible Owner

As the vehicle's owner, you are responsible for the safe and proper operation of your scooter.

Scooters are single-track vehicles.

Their safe use and operation are dependent upon the use of proper riding techniques as well as the expertise of the operator. Every operator should know the following requirements before riding this scooter.

He or she should:

- Obtain thorough instructions from a competent source on all aspects of scooter operation.
- Observe the warnings and maintenance requirements in this Owner's Manual.
- Obtain qualified training in safe and proper riding techniques.
- Obtain professional technical service as indicated in this Owner's Manual and/or when made necessary by mechanical conditions.

### Safe Riding

Perform the pre-operation checks each time you use the vehicle to make sure it is in safe operating condition. Failure to inspect or maintain the vehicle properly increases the possibility of an accident or equipment damage. See page 4-1 for a list of pre-operation checks.

- This scooter is designed to carry the operator and a passenger.
- The failure of motorists to detect and recognize scooters in traffic is the predominating cause of automobile/scooter accidents. Many accidents have been caused by an automobile driver who did not see the scooter. Making yourself conspicuous appears to be very effective in reducing the chance of this type of accident.

#### Therefore:

- Wear a brightly colored jacket.
- Use extra caution when you are approaching and passing through intersections, since intersections are the most likely places for scooter accidents to occur.

- Ride where other motorists can see you. Avoid riding in another motorist's blind spot.
- Many accidents involve inexperienced operators. In fact, many operators who have been involved in accidents do not even have a current driver's license.
- Make sure that you are qualified and that you only lend your scooter to other qualified operators.
- Know your skills and limits. Staying within your limits may help you to avoid an accident.
- We recommend that you practice riding your scooter where there is no traffic until you have become thoroughly familiar with the scooter and all of its controls.
- Many accidents have been caused by error of the scooter operator. A typical error made by the operator is veering wide on a turn due to ex-



## SAFETY INFORMATION

cessive speed or undercornering (insufficient lean angle for the speed).

- Always obey the speed limit and never travel faster than warranted by road and traffic conditions.
- Always signal before turning or changing lanes. Make sure that other motorists can see you.
- The posture of the operator and passenger is important for proper control.
  - The operator should keep both hands on the handlebar and both feet on the operator footrests during operation to maintain control of the scooter.
  - The passenger should always hold onto the operator, the seat strap or grab bar, if equipped, with both hands and keep both feet on the passenger footrests. Never carry a passenger unless he or she can firmly place both feet on the passenger footrests.
- Never ride under the influence of alcohol or other drugs.

- This scooter is designed for on-road use only. It is not suitable for off-road use.

### Protective apparel

The majority of fatalities from scooter accidents are the result of head injuries. The use of a safety helmet is the single most critical factor in the prevention or reduction of head injuries.

- Always wear an approved helmet.
- Wear a face shield or goggles. Wind in your unprotected eyes could contribute to an impairment of vision that could delay seeing a hazard.
- The use of a jacket, substantial shoes, trousers, gloves, etc., is effective in preventing or reducing abrasions or lacerations.
- Never wear loose-fitting clothes, otherwise they could catch on the control levers or wheels and cause injury or an accident.
- Always wear protective clothing that covers your legs, ankles, and feet. The engine or exhaust system become very hot during or after operation and can cause burns.

- A passenger should also observe the above precautions.

### Avoid Carbon Monoxide Poisoning

All engine exhaust contains carbon monoxide, a deadly gas. Breathing carbon monoxide can cause headaches, dizziness, drowsiness, nausea, confusion, and eventually death.

Carbon Monoxide is a colorless, odorless, tasteless gas which may be present even if you do not see or smell any engine exhaust. Deadly levels of carbon monoxide can collect rapidly and you can quickly be overcome and unable to save yourself. Also, deadly levels of carbon monoxide can linger for hours or days in enclosed or poorly ventilated areas. If you experience any symptoms of carbon monoxide poisoning, leave the area immediately, get fresh air, and SEEK MEDICAL TREATMENT.

- Do not run engine indoors. Even if you try to ventilate engine exhaust with fans or open windows and doors, carbon monoxide can rapidly reach dangerous levels.

## SAFETY INFORMATION

- Do not run engine in poorly ventilated or partially enclosed areas such as barns, garages, or carports.
- Do not run engine outdoors where engine exhaust can be drawn into a building through openings such as windows and doors.

### Loading

Adding accessories or cargo to your scooter can adversely affect stability and handling if the weight distribution of the scooter is changed. To avoid the possibility of an accident, use extreme caution when adding cargo or accessories to your scooter. Use extra care when riding a scooter that has added cargo or accessories. Here, along with the information about accessories below, are some general guidelines to follow if loading cargo to your scooter:

The total weight of the operator, passenger, accessories and cargo must not exceed the maximum load limit.

**Operation of an overloaded vehicle could cause an accident.**

**Maximum load:**  
167 kg (368 lb)

When loading within this weight limit, keep the following in mind:

- Cargo and accessory weight should be kept as low and close to the scooter as possible. Securely pack your heaviest items as close to the center of the vehicle as possible and make sure to distribute the weight as evenly as possible on both sides of the scooter to minimize imbalance or instability.
- Shifting weights can create a sudden imbalance. Make sure that accessories and cargo are securely attached to the scooter before riding. Check accessory mounts and cargo restraints frequently.
- Properly adjust the suspension for your load (suspension-adjustable models only), and check the condition and pressure of your tires.

- Never attach any large or heavy items to the handlebar, front fork, or front fender. Such items can create unstable handling or a slow steering response.

- **This vehicle is not designed to pull a trailer or to be attached to a sidecar.**

### Genuine Yamaha Accessories

Choosing accessories for your vehicle is an important decision. Genuine Yamaha accessories, which are available only from a Yamaha dealer, have been designed, tested, and approved by Yamaha for use on your vehicle.

Many companies with no connection to Yamaha manufacture parts and accessories or offer other modifications for Yamaha vehicles. Yamaha is not in a position to test the products that these aftermarket companies produce. Therefore, Yamaha can neither endorse nor recommend the use of accessories not sold by Yamaha or modifications not specifically recommended by Yamaha, even if sold and installed by a Yamaha dealer.

 **SAFETY INFORMATION****Aftermarket Parts, Accessories, and Modifications**

While you may find aftermarket products similar in design and quality to genuine Yamaha accessories, recognize that some aftermarket accessories or modifications are not suitable because of potential safety hazards to you or others. Installing aftermarket products or having other modifications performed to your vehicle that change any of the vehicle's design or operation characteristics can put you and others at greater risk of serious injury or death. You are responsible for injuries related to changes in the vehicle.

Keep the following guidelines in mind, as well as those provided under "Loading" when mounting accessories.

- Never install accessories or carry cargo that would impair the performance of your scooter. Carefully inspect the accessory before using it to make sure that it does not in any way reduce ground clearance or cornering clearance, limit sus-

pension travel, steering travel or control operation, or obscure lights or reflectors.

- Accessories fitted to the handlebar or the front fork area can create instability due to improper weight distribution or aerodynamic changes. If accessories are added to the handlebar or front fork area, they must be as lightweight as possible and should be kept to a minimum.
- Bulky or large accessories may seriously affect the stability of the scooter due to aerodynamic effects. Wind may attempt to lift the scooter, or the scooter may become unstable in cross winds. These accessories may also cause instability when passing or being passed by large vehicles.
- Certain accessories can displace the operator from his or her normal riding position. This improper position limits the freedom of movement of the opera-

tor and may limit control ability, therefore, such accessories are not recommended.

- Use caution when adding electrical accessories. If electrical accessories exceed the capacity of the scooter's electrical system, an electric failure could result, which could cause a dangerous loss of lights or engine power.

**Aftermarket Tires and Rims**


The tires and rims that came with your scooter were designed to match the performance capabilities and to provide the best combination of handling, braking, and comfort. Other tires, rims, sizes, and combinations may not be appropriate. Refer to page 6-15 for tire specifications and more information on replacing your tires.

## SAFETY INFORMATION


### Further safe-riding points EAU45371

- Make sure to signal clearly when making turns.

#### Left turn



#### Right turn




- Braking can be extremely difficult on a wet road. Avoid hard braking, because the scooter could slide. Apply the brakes slowly when stopping on a wet surface.
- Slow down as you approach a corner or turn. Once you have completed a turn, accelerate slowly.
- Be careful when passing parked cars. A driver might not see you and open a door in your path.
- Railroad crossings, streetcar rails, iron plates on road construction sites, and manhole covers become extremely slippery when wet. Slow down and cross them with caution. Keep the scooter upright, otherwise it could slide out from under you.
- The brake pads and linings could get wet when you wash the scooter. After washing the scooter, check the brakes before riding.
- Always wear a helmet, gloves, trousers (tapered around the cuff and ankle so they do not flap), and a bright colored jacket.
- Do not carry too much luggage on the scooter. An overloaded scooter is unstable. Use a strong cord to secure any luggage to the carriers. A loose load will affect the stability of the scooter and could divert your attention from the road. (See page 1-3.)

## DESCRIPTION

EAU10410

### Left view




1. Battery (page 6-23)
2. Fuse (page 6-25)
3. V-belt case air filter element (page 6-12)
4. Air filter element (page 6-12)
5. Final transmission oil filler cap (page 6-11)
6. Final transmission oil drain bolt (page 6-11)
7. Engine oil drain bolt (page 6-9)
8. Centerstand (page 6-21)

9. Sidestand (page 3-11)

## DESCRIPTION

EAU10420

### Right view




1. Carrier (page 3-11)
2. Grab bar (page 5-2)
3. Fuel tank cap (page 3-6)
4. Rear storage compartment (page 3-10)
5. Helmet holder (page 3-9)
6. Front storage compartment (page 3-10)
7. Luggage hook (page 3-11)
8. Spark plug (page 6-8)

9. Engine oil filler cap (page 6-9)

## DESCRIPTION

EAU10430

### Controls and instruments




- 1. Rear brake lever (page 3-6)
- 2. Left handlebar switches (page 3-5)
- 3. Speedometer unit (page 3-3)
- 4. Fuel gauge (page 3-4)
- 5. Right handlebar switch (page 3-5)
- 6. Throttle grip (page 6-14)
- 7. Front brake lever (page 3-5)
- 8. Main switch/steering lock and keyhole cover (pages 3-1 and 3-2)

- 9. Oil change indicator reset switch (page 3-2)

## INSTRUMENT AND CONTROL FUNCTIONS

### Main switch/steering lock EAU45440



3

The main switch/steering lock controls the ignition and lighting systems, and is used to lock the steering. The various positions are described below.

**TIP** \_\_\_\_\_  
The main switch/steering lock is equipped with a keyhole cover. (See page 3-2.)

**ON** EAU45430  
All electrical circuits are supplied with power; the meter lighting, taillight, and auxiliary light come on, and the engine can be started. The key cannot be removed.


**TIP** \_\_\_\_\_  
The headlight comes on automatically when the engine is started and stays on until the key is turned to "OFF" or the sidestand is moved down.

**OFF** EAU10661  
All electrical systems are off. The key can be removed.

**⚠ WARNING** \_\_\_\_\_  
**Never turn the key to "OFF" or "LOCK" while the vehicle is moving. Otherwise the electrical systems will be switched off, which may result in loss of control or an accident.**

**LOCK** EAU49001  
The steering and the centerstand are locked, and all electrical systems are off. The key can be removed.

### To lock the steering and the centerstand




1. Push.
  2. Turn.
1. Put the scooter on the centerstand.
  2. Turn the handlebars all the way to the left.
  3. Push the key in from the "OFF" position, and then turn it to "LOCK" while still pushing it.
  4. Remove the key.

**TIP** \_\_\_\_\_  
When the steering is locked, the centerstand is locked, and the scooter cannot be taken off it.



## INSTRUMENT AND CONTROL FUNCTIONS

To unlock the steering and the center-stand




1. Push.
2. Turn.

Push the key in, and then turn it to "OFF" while still pushing it.

### Keyhole cover

EAUT2121



#### To close the keyhole cover


Insert the key bow into the keyhole cover receptacle as shown, and then turn the key to "SHUT" to close the cover.

#### To open the keyhole cover

Insert the key bow into the keyhole cover receptacle as shown, and then turn the key to "OPEN" to open the cover.

### Indicator, indicator lights and warning light

EAU45380



1. Engine trouble warning light "⚠"
2. High beam indicator light "≡"
3. Turn signal indicator light "↔"
4. Oil change indicator

#### Turn signal indicator light "↔"

EAU11020

This indicator light flashes when the turn signal switch is pushed to the left or right.

#### High beam indicator light "≡"

EAU11080


This indicator light comes on when the high beam of the headlight is switched on.

## INSTRUMENT AND CONTROL FUNCTIONS

### Oil change indicator

EAU45401

This indicator changes from green to red every 2000 km (1200 mi) to indicate that the engine oil should be changed. After changing the engine oil, push the oil change indicator reset switch in with the main switch key.



1. Oil change indicator
2. Oil change indicator reset switch

If the engine oil is changed before the 2000 km (1200 mi) interval, the indicator must be reset after the oil change for the next periodic oil change to be indicated at the correct time. **NOTICE: After 1000 km (600 mi) of operation, the engine oil must be changed.** [ECA10281]

### TIP

After resetting the oil change indicator reset switch, the indicator changes from red to green.

### Engine trouble warning light “”


EAUT1934

This warning light flashes or stays on if an electrical circuit monitoring the engine is not working correctly. If this occurs, have a Yamaha dealer check the self-diagnosis system.

The electrical circuit of the warning light can be checked by turning the key to “ON”. The warning light should come on for a few seconds, and then go off. If the warning light does not come on initially when the key is turned to “ON”, or if the warning light remains on, have a Yamaha dealer check the electrical circuit.

### Speedometer unit

EAUT1821



1. Speedometer
2. Odometer

The speedometer unit is equipped with a speedometer and an odometer. The speedometer shows the riding speed. The odometer shows the total distance traveled.

## INSTRUMENT AND CONTROL FUNCTIONS

### Self-diagnosis device

EAU12092

This model is equipped with a self-diagnosis device for various electrical circuits.

If a problem is detected in any of those circuits, the engine trouble warning light will come on or flash. If this occurs, have a Yamaha dealer check the vehicle.


ECA11170

#### **NOTICE**

**To prevent engine damage, be sure to consult a Yamaha dealer as soon as possible if this occurs.**

### Fuel gauge

EAU45630



1. Fuel gauge
2. Red line

The fuel gauge indicates the amount of fuel in the fuel tank. The needle moves towards "E" (Empty) as the fuel level decreases. When the needle reaches the red line, refuel as soon as possible.

#### **TIP**

Turning the key to "OFF" cancels the fuel gauge reading.

### Anti-theft alarm (optional)

EAU12331


This model can be equipped with an optional anti-theft alarm by a Yamaha dealer. Contact a Yamaha dealer for more information.

## INSTRUMENT AND CONTROL FUNCTIONS

### Handlebar switches


EAU12348

#### Left



1. Dimmer switch “/”
2. Turn signal switch “/”
3. Horn switch “”

#### Right



1. Start switch “”

### Dimmer switch “/”

EAU12400

Set this switch to “” for the high beam and to “” for the low beam.

### Turn signal switch “/”

EAU12460

To signal a right-hand turn, push this switch to “”. To signal a left-hand turn, push this switch to “”. When released, the switch returns to the center position. To cancel the turn signal lights, push the switch in after it has returned to the center position.

### Horn switch “”

EAU12500

Press this switch to sound the horn.


### Start switch “”

EAU12721

With the sidestand up, push this switch while applying the front or rear brake to crank the engine with the starter. See page 5-1 for starting instructions prior to starting the engine.

### Front brake lever

EAU12900




1. Front brake lever

The front brake lever is located on the right handlebar grip. To apply the front brake, pull this lever toward the handlebar grip.

## INSTRUMENT AND CONTROL FUNCTIONS

### Rear brake lever

EAU12950




1. Rear brake lever

The rear brake lever is located on the left handlebar grip. To apply the rear brake, pull this lever toward the handlebar grip.

### Fuel tank cap

EAU45391



1. Fuel tank cap lid
2. Fuel tank cap

#### To remove the fuel tank cap

1. Open the seat. (See page 3-8.)
2. Open the fuel tank cap lid.
3. Turn the fuel tank cap counter-clockwise and pull it off.

#### To install the fuel tank cap

1. Insert the fuel tank cap into the tank opening and turn it clockwise until the “△” marks on the cap and tank are aligned.
2. Close the fuel tank cap lid.
3. Close the seat.

### **! WARNING**

Make sure that the fuel tank cap is properly closed after filling fuel. Leaking fuel is a fire hazard.

## INSTRUMENT AND CONTROL FUNCTIONS

### Fuel

EAU13221


Make sure there is sufficient gasoline in the tank.

EWA10881

#### **WARNING**

**Gasoline and gasoline vapors are extremely flammable. To avoid fires and explosions and to reduce the risk of injury when refueling, follow these instructions.**

1. Before refueling, turn off the engine and be sure that no one is sitting on the vehicle. Never refuel while smoking, or while in the vicinity of sparks, open flames, or other sources of ignition such as the pilot lights of water heaters and clothes dryers.
2. Do not overfill the fuel tank. When refueling, be sure to insert the pump nozzle into the fuel tank filler hole. Stop filling when the fuel reaches the bottom of the filler tube. Because fuel expands when it heats up, heat from the engine or the sun can cause fuel to spill out of the fuel tank.



1. Fuel tank filler tube
2. Maximum fuel level

3. Wipe up any spilled fuel immediately. **NOTICE: Immediately wipe off spilled fuel with a clean, dry, soft cloth, since fuel may deteriorate painted surfaces or plastic parts.** [ECA10071]
4. Be sure to securely close the fuel tank cap.

EWA15151

#### **WARNING**

**Gasoline is poisonous and can cause injury or death. Handle gasoline with care. Never siphon gasoline by mouth. If you should swallow some gasoline or inhale a lot of gasoline vapor, or get some gasoline in your eyes, see your doctor immedi-**

**ately. If gasoline spills on your skin, wash with soap and water. If gasoline spills on your clothing, change your clothes.**

EAU33520

**Recommended fuel:**  
REGULAR UNLEADED GASOLINE ONLY  
**Fuel tank capacity:**  
5.5 L (1.45 US gal, 1.21 Imp.gal)

ECA11400

#### **NOTICE**

**Use only unleaded gasoline. The use of leaded gasoline will cause severe damage to internal engine parts, such as the valves and piston rings, as well as to the exhaust system.**

Your Yamaha engine has been designed to use regular unleaded gasoline with a research octane number of 91 or higher. If knocking (or pinging) occurs, use a gasoline of a different brand or premium unleaded fuel. Use of unleaded fuel will extend spark plug life and reduce maintenance costs.

## INSTRUMENT AND CONTROL FUNCTIONS

### Catalytic converters

EAU13445

This vehicle is equipped with catalytic converters in the exhaust system.

#### **WARNING**

EWA10862

The exhaust system is hot after operation. To prevent a fire hazard or burns:

- Do not park the vehicle near possible fire hazards such as grass or other materials that easily burn.
- Park the vehicle in a place where pedestrians or children are not likely to touch the hot exhaust system.
- Make sure that the exhaust system has cooled down before doing any maintenance work.
- Do not allow the engine to idle more than a few minutes. Long idling can cause a build-up of heat.

#### **NOTICE**

ECA10701


Use only unleaded gasoline. The use of leaded gasoline will cause unreparable damage to the catalytic converter.

### Seat

EAUT1503

#### To open the seat

1. Place the scooter on the center-stand.
2. Insert the key into the main switch, and then turn it counterclockwise to the first "OPEN" position. If the main switch is in the "LOCK" position, turn the key counterclockwise to the second "OPEN" position.



1. Seat open position

#### **TIP**

Do not push inward when turning the key from "OFF" to "OPEN" or from "LOCK" to "OPEN".

3. Fold the seat up.

## INSTRUMENT AND CONTROL FUNCTIONS

### To close the seat

1. Fold the seat down, and then push it down to lock it in place.
2. Remove the key from the main switch if the scooter will be left unattended.


### TIP

3

Make sure that the seat is properly secured before riding.

### Helmet holders

EAU37481



1. Helmet holder

The helmet holders are located under the seat.

### To secure a helmet to a helmet holder

1. Open the seat. (See page 3-8.)
2. Attach a helmet to a helmet holder, and then securely close the seat.

**WARNING! Never ride with a helmet attached to the helmet holder, since the helmet may hit objects, causing loss of control and possibly an accident.** [EWA10161]


### To release a helmet from a helmet holder

Open the seat, remove the helmet from the helmet holder, and then close the seat.



## Storage compartments

### Front storage compartment




1. Front storage compartment

#### **WARNING**

- Do not exceed the load limit of 1.5 kg (3.3 lb) for the front storage compartment.
- Do not exceed the maximum load of 167 kg (368 lb) for the vehicle.

EAUT1712

### Rear storage compartment



1. Rear storage compartment

The rear storage compartment is located under the seat. (See page 3-8.)

ECAT1030

#### **NOTICE**

Keep the following points in mind when using the storage compartment.

- Since the storage compartment accumulates heat when exposed to the sun, do not store anything susceptible to heat inside it.
- To avoid humidity from spreading through the storage compartment, wrap wet articles in a plastic bag before storing them in the compartment.

- Since the storage compartment may get wet while the scooter is being washed, wrap any articles stored in the compartment in a plastic bag.
- Do not keep anything valuable or breakable in the storage compartment.

EWAT1051

#### **WARNING**

- Do not exceed the load limit of 5 kg (11 lb) for the rear storage compartment.
- Do not exceed the maximum load of 167 kg (368 lb) for the vehicle.

## INSTRUMENT AND CONTROL FUNCTIONS


### Carrier

EAU15112

EWA10171

#### **WARNING**

- Do not exceed the load limit of 5 kg (11 lb) for the carrier.
- Do not exceed the maximum load of 167 kg (368 lb) for the vehicle.



1. Carrier


### Luggage hook

EAUT1072

EWAT1031

#### **WARNING**


- Do not exceed the load limit of 1.0 kg (2.2 lb) for the luggage hook.
- Do not exceed the maximum load of 167 kg (368 lb) for the vehicle.



1. Luggage hook

### Sidestand

EAU15303



1. Sidestand

The sidestand is located on the left side of the frame. Raise the sidestand or lower it with your foot while holding the vehicle upright.

#### **TIP**

The built-in sidestand switch is part of the ignition circuit cut-off system, which cuts the ignition in certain situations. (See page 3-12 for an explanation of the ignition circuit cut-off system.)

#### **WARNING**

The vehicle must not be ridden with the sidestand down, or if the sidestand cannot be properly moved up

EWA10240

## INSTRUMENT AND CONTROL FUNCTIONS


(or does not stay up), otherwise the sidestand could contact the ground and distract the operator, resulting in a possible loss of control. Yamaha's ignition circuit cut-off system has been designed to assist the operator in fulfilling the responsibility of raising the sidestand before starting off. Therefore, check this system regularly as described below and have a Yamaha dealer repair it if it does not function properly.

**Ignition circuit cut-off system**<sup>EAUT1095</sup>  
Check the operation of the sidestand switch according to the following procedure.

## INSTRUMENT AND CONTROL FUNCTIONS

---

3



### **WARNING**

- The vehicle must be placed on the center-stand during this inspection.
- If a malfunction is noted, have a Yamaha dealer check the system before riding.

## FOR YOUR SAFETY – PRE-OPERATION CHECKS

Inspect your vehicle each time you use it to make sure the vehicle is in safe operating condition. Always follow the inspection and maintenance procedures and schedules described in the Owner's Manual.

**⚠ WARNING**

**Failure to inspect or maintain the vehicle properly increases the possibility of an accident or equipment damage. Do not operate the vehicle if you find any problem. If a problem cannot be corrected by the procedures provided in this manual, have the vehicle inspected by a Yamaha dealer.**

Before using this vehicle, check the following points:

ITEM	CHECKS	PAGE
<b>Fuel</b>	<ul style="list-style-type: none"> <li>• Check fuel level in fuel tank.</li> <li>• Refuel if necessary.</li> <li>• Check fuel line for leakage.</li> </ul>	3-7
<b>Engine oil</b>	<ul style="list-style-type: none"> <li>• Check oil level in engine.</li> <li>• If necessary, add recommended oil to specified level.</li> <li>• Check vehicle for oil leakage.</li> </ul>	6-9
<b>Final transmission oil</b>	<ul style="list-style-type: none"> <li>• Check vehicle for oil leakage.</li> </ul>	6-11
<b>Front brake</b>	<ul style="list-style-type: none"> <li>• Check operation.</li> <li>• If soft or spongy, have Yamaha dealer bleed hydraulic system.</li> <li>• Check brake pads for wear.</li> <li>• Replace if necessary.</li> <li>• Check fluid level in reservoir.</li> <li>• If necessary, add recommended brake fluid to specified level.</li> <li>• Check hydraulic system for leakage.</li> </ul>	6-18, 6-19
<b>Rear brake</b>	<ul style="list-style-type: none"> <li>• Check operation.</li> <li>• Lubricate cable if necessary.</li> <li>• Check lever free play.</li> <li>• Adjust if necessary.</li> </ul>	6-17, 6-18

## FOR YOUR SAFETY – PRE-OPERATION CHECKS

ITEM	CHECKS	PAGE
<b>Throttle grip</b>	<ul style="list-style-type: none"> <li>• Make sure that operation is smooth.</li> <li>• Check cable free play.</li> <li>• If necessary, have Yamaha dealer adjust cable free play and lubricate cable and grip housing.</li> </ul>	6-14, 6-20
<b>Control cables</b>	<ul style="list-style-type: none"> <li>• Make sure that operation is smooth.</li> <li>• Lubricate if necessary.</li> </ul>	6-20
<b>Wheels and tires</b>	<ul style="list-style-type: none"> <li>• Check for damage.</li> <li>• Check tire condition and tread depth.</li> <li>• Check air pressure.</li> <li>• Correct if necessary.</li> </ul>	6-15, 6-17
<b>Brake levers</b>	<ul style="list-style-type: none"> <li>• Make sure that operation is smooth.</li> <li>• Lubricate lever pivoting points if necessary.</li> </ul>	6-21
<b>Centerstand, sidestand</b>	<ul style="list-style-type: none"> <li>• Make sure that operation is smooth.</li> <li>• Lubricate pivots if necessary.</li> </ul>	6-21
<b>Chassis fasteners</b>	<ul style="list-style-type: none"> <li>• Make sure that all nuts, bolts and screws are properly tightened.</li> <li>• Tighten if necessary.</li> </ul>	—
<b>Instruments, lights, signals and switches</b>	<ul style="list-style-type: none"> <li>• Check operation.</li> <li>• Correct if necessary.</li> </ul>	—
<b>Sidestand switch</b>	<ul style="list-style-type: none"> <li>• Check operation of ignition circuit cut-off system.</li> <li>• If system is not working correctly, have Yamaha dealer check vehicle.</li> </ul>	3-11

## OPERATION AND IMPORTANT RIDING POINTS

EAU15951

Read the Owner's Manual carefully to become familiar with all controls. If there is a control or function you do not understand, ask your Yamaha dealer.

EWA10271

### **WARNING**

**Failure to familiarize yourself with the controls can lead to loss of control, which could cause an accident or injury.**

### **TIP**

This model is equipped with a lean angle sensor to stop the engine in case of a turnover. To start the engine after a turnover, be sure to turn the main switch to "OFF" and then to "ON". Failing to do so will prevent the engine from starting even though the engine will crank when pushing the start switch.

EAU45310

### Starting the engine

EAU45422

ECA10250

### **NOTICE**

**See page 5-4 for engine break-in instructions prior to operating the vehicle for the first time.**


In order for the ignition circuit cut-off system to enable starting, the side-stand must be up.

See page 3-12 for more information.

1. Turn the key to "ON".
2. Close the throttle completely.
3. Start the engine by pushing the start switch while applying the front or rear brake. **NOTICE: For maximum engine life, never accelerate hard when the engine is cold!** [ECA11041]

If the engine fails to start, release the start switch, wait a few seconds, and then try again. Each starting attempt should be as short as possible to preserve the battery. Do not crank the engine more than 5 seconds on any one attempt.

## OPERATION AND IMPORTANT RIDING POINTS




1. Rear brake lever
2. Start switch
3. Front brake lever

### Starting off

EAU45091

1. While pulling the rear brake lever with your left hand and holding the grab bar with your right hand, push the scooter off the centerstand.




1. Grab bar

2. Sit astride the seat, and then adjust the rear view mirrors.
3. Switch the turn signals on.
4. Check for oncoming traffic, and then slowly turn the throttle grip (on the right) in order to take off.
5. Switch the turn signals off.

### Acceleration and deceleration

EAU16780



The speed can be adjusted by opening and closing the throttle. To increase the speed, turn the throttle grip in direction (a). To reduce the speed, turn the throttle grip in direction (b).

ZALUM0199



## OPERATION AND IMPORTANT RIDING POINTS

### Braking


EAU16793

EWA10300

#### **! WARNING**

- Avoid braking hard or suddenly (especially when leaning over to one side), otherwise the scooter may skid or overturn.
- Railroad crossings, streetcar rails, iron plates on road construction sites, and manhole covers become extremely slippery when wet. Therefore, slow down when approaching such areas and cross them with caution.
- Keep in mind that braking on a wet road is much more difficult.
- Ride slowly down a hill, as braking downhill can be very difficult.

1. Close the throttle completely.
2. Apply both front and rear brakes simultaneously while gradually increasing the pressure.



### Tips for reducing fuel consumption

EAU16820

Fuel consumption depends largely on your riding style. Consider the following tips to reduce fuel consumption:

- Avoid high engine speeds during acceleration.
- Avoid high engine speeds with no load on the engine.
- Turn the engine off instead of letting it idle for an extended length of time (e.g., in traffic jams, at traffic lights or at railroad crossings).

## OPERATION AND IMPORTANT RIDING POINTS

### Engine break-in

EAU16830

There is never a more important period in the life of your engine than the period between 0 and 1000 km (600 mi). For this reason, you should read the following material carefully.

Since the engine is brand new, do not put an excessive load on it for the first 1000 km (600 mi). The various parts in the engine wear and polish themselves to the correct operating clearances. During this period, prolonged full-throttle operation or any condition that might result in engine overheating must be avoided.

EAU45581

#### 0–150 km (0–90 mi)

Avoid prolonged operation above 1/3 throttle.

#### 150–500 km (90–300 mi)

Avoid prolonged operation above 1/2 throttle.

#### 500–1000 km (300–600 mi)

Avoid prolonged operation above 3/4 throttle. **NOTICE:** After 1000 km (600 mi) of operation, be sure to change

the engine oil and final transmission oil, and to clean the oil strainer.

[ECA16501]

#### 1000 km (600 mi) and beyond

The vehicle can now be operated normally.

ECA10270

### **NOTICE**

If any engine trouble should occur during the engine break-in period, immediately have a Yamaha dealer check the vehicle.

### Parking

EAU17213

When parking, stop the engine, and then remove the key from the main switch.

EWA10311

### **WARNING**

- Since the engine and exhaust system can become very hot, park in a place where pedestrians or children are not likely to touch them and be burned.
- Do not park on a slope or on soft ground, otherwise the vehicle may overturn, increasing the risk of a fuel leak and fire.
- Do not park near grass or other flammable materials which might catch fire.

## PERIODIC MAINTENANCE AND ADJUSTMENT

EAU17241

Periodic inspection, adjustment, and lubrication will keep your vehicle in the safest and most efficient condition possible. Safety is an obligation of the vehicle owner/operator. The most important points of vehicle inspection, adjustment, and lubrication are explained on the following pages.

The intervals given in the periodic maintenance and lubrication chart should be simply considered as a general guide under normal riding conditions. However, depending on the weather, terrain, geographical location, and individual use, the maintenance intervals may need to be shortened.

EWA10321

### **WARNING**

**Failure to properly maintain the vehicle or performing maintenance activities incorrectly may increase your risk of injury or death during service or while using the vehicle. If you are not familiar with vehicle service, have a Yamaha dealer perform service.**

EWA15121

### **WARNING**

**Turn off the engine when performing maintenance unless otherwise specified.**

- **A running engine has moving parts that can catch on body parts or clothing and electrical parts that can cause shocks or fires.**
- **Running the engine while servicing can lead to eye injury, burns, fire, or carbon monoxide poisoning – possibly leading to death. See page 1-1 for more information about carbon monoxide.**

## PERIODIC MAINTENANCE AND ADJUSTMENT

EAU46871

### TIP

- The annual checks must be performed every year, except if a kilometer-based maintenance, or for the UK, a mileage-based maintenance, is performed instead.
- From 30000 km (17500 mi), repeat the maintenance intervals starting from 6000 km (3500 mi).
- Items marked with an asterisk should be performed by a Yamaha dealer as they require special tools, data and technical skills.

### Periodic maintenance chart for the emission control system

EAU46920

NO.	ITEM	CHECK OR MAINTENANCE JOB	ODOMETER READING					ANNUAL CHECK
			1000 km (600 mi)	6000 km (3500 mi)	12000 km (7000 mi)	18000 km (10500 mi)	24000 km (14000 mi)	
1	* Fuel line	• Check fuel hoses for cracks or damage.		√	√	√	√	√
2	Spark plug	• Check condition. • Clean and regap.		√		√		
		• Replace.			√		√	
3	* Valves	• Check valve clearance. • Adjust.		√	√	√	√	
4	* Fuel injection	• Check engine idle speed.	√	√	√	√	√	√
5	* Air induction system	• Check the air cut-off valve, reed valve, and hose for damage. • Replace any damaged parts if necessary.		√	√	√	√	√

## PERIODIC MAINTENANCE AND ADJUSTMENT

EAU17717

### General maintenance and lubrication chart

NO.	ITEM	CHECK OR MAINTENANCE JOB	ODOMETER READING					ANNUAL CHECK
			1000 km (600 mi)	6000 km (3500 mi)	12000 km (7000 mi)	18000 km (10500 mi)	24000 km (14000 mi)	
1	* Air filter element	• Replace.			√		√	
2	* V-belt case air filter element	• Clean.		√	√	√	√	
3	* Front brake	• Check operation, fluid level and vehicle for fluid leakage.	√	√	√	√	√	√
		• Replace brake pads.	Whenever worn to the limit					
4	* Rear brake	• Check operation and adjust brake lever free play.	√	√	√	√	√	√
		• Replace brake shoes.	Whenever worn to the limit					
5	* Brake hose	• Check for cracks or damage.		√	√	√	√	√
		• Replace.	Every 4 years					
6	* Wheels	• Check runout and for damage.		√	√	√	√	
7	* Tires	• Check tread depth and for damage. • Replace if necessary. • Check air pressure. • Correct if necessary.		√	√	√	√	√
8	* Wheel bearings	• Check bearing for looseness or damage.		√	√	√	√	
9	* Steering bearings	• Check bearing play and steering for roughness.	√	√	√	√	√	
		• Lubricate with lithium-soap-based grease.	Every 24000 km (14000 mi)					

## PERIODIC MAINTENANCE AND ADJUSTMENT

NO.	ITEM	CHECK OR MAINTENANCE JOB	ODOMETER READING					ANNUAL CHECK
			1000 km (600 mi)	6000 km (3500 mi)	12000 km (7000 mi)	18000 km (10500 mi)	24000 km (14000 mi)	
10	* Chassis fasteners	• Make sure that all nuts, bolts and screws are properly tightened.		√	√	√	√	√
11	Front brake lever pivot shaft	• Lubricate with silicone grease.		√	√	√	√	√
12	Rear brake lever pivot shaft	• Lubricate with lithium-soap-based grease.		√	√	√	√	√
13	Sidestand, center-stand	• Check operation. • Lubricate with lithium-soap-based grease.		√	√	√	√	√
14	* Sidestand switch	• Check operation.	√	√	√	√	√	√
15	* Front fork	• Check operation and for oil leakage.		√	√	√	√	
16	* Shock absorber assembly	• Check operation and shock absorber for oil leakage.		√	√	√	√	
17	Engine oil	• Change. (See page 6-9.) • Check oil level and vehicle for oil leakage.	√	Every 2000 km (1200 mi)				
18	* Engine oil strainer	• Clean.	√					
19	Final transmission oil	• Check vehicle for oil leakage.	√	√	√	√	√	
		• Change.	√		√		√	
20	* V-belt	• Replace.	Every 12000 km (7000 mi)					
21	* Front and rear brake switches	• Check operation.	√	√	√	√	√	√
22	Moving parts and cables	• Lubricate.		√	√	√	√	√

## PERIODIC MAINTENANCE AND ADJUSTMENT

NO.	ITEM	CHECK OR MAINTENANCE JOB	ODOMETER READING					ANNUAL CHECK
			1000 km (600 mi)	6000 km (3500 mi)	12000 km (7000 mi)	18000 km (10500 mi)	24000 km (14000 mi)	
23	* Throttle grip housing and cable	<ul style="list-style-type: none"> <li>• Check operation and free play.</li> <li>• Adjust the throttle cable free play if necessary.</li> <li>• Lubricate the throttle grip housing and cable.</li> </ul>		√	√	√	√	√
24	* Lights, signals and switches	<ul style="list-style-type: none"> <li>• Check operation.</li> <li>• Adjust headlight beam.</li> </ul>	√	√	√	√	√	√

EAU45610


### TIP

- Air filter
  - This model's air filter is equipped with a disposable oil-coated paper element, which must not be cleaned with compressed air to avoid damaging it.
  - The air filter element needs to be replaced more frequently when riding in unusually wet or dusty areas.
- V-belt case air filter
  - The air filter needs more frequent service if you are riding in unusually wet or dusty areas.
- Hydraulic brake service
  - Regularly check and, if necessary, correct the brake fluid level.
  - Every two years replace the internal components of the brake master cylinder and caliper, and change the brake fluid.
  - Replace the brake hose every four years and if cracked or damaged.

## PERIODIC MAINTENANCE AND ADJUSTMENT

### Removing and installing cowlings and panels EAU18712

The cowlings and panels shown need to be removed to perform some of the maintenance jobs described in this chapter. Refer to this section each time a cowling or panel needs to be removed and installed.




1. Cowling A
2. Cowling B
3. Panel A
4. Panel B

#### Cowling A EAU18852

##### To remove the cowling

Remove the screws, and then pull the cowling off as shown.



1. Screw


##### To install the cowling

Place the cowling in the original position, and then install the screws.


#### Cowling B EAU45470

##### To remove the cowling

1. Remove the screws, and then pull the cowling off as shown.



1. Screw




1. Screw

2. Disconnect the headlight coupler, and the auxiliary light lead coupler.



## PERIODIC MAINTENANCE AND ADJUSTMENT



1. Headlight coupler
2. Auxiliary light lead coupler

### To install the cowling


1. Connect the headlight coupler, and the auxiliary light lead coupler.
2. Place the cowling in the original position, and then install the screws.

### **Panel A**

EAU19281

### To remove the panel

Remove the screw, and then pull the panel off as shown.



1. Screw

### To install the panel


Place the panel in the original position, and then install the screw.

### **Panel B**

EAU45450


### To remove the panel

1. Pull up the floorboard mat.



1. Floorboard mat

2. Remove the screws, and then pull the panel off as shown.



1. Screw

### To install the panel

1. Place the panel in the original position, and then install the screws.
2. Place the floorboard mat in the original position.

## PERIODIC MAINTENANCE AND ADJUSTMENT


### Checking the spark plug

EAU45590


The spark plug is an important engine component, which is easy to check. Since heat and deposits will cause any spark plug to slowly erode, the spark plug should be removed and checked in accordance with the periodic maintenance and lubrication chart. In addition, the condition of the spark plug can reveal the condition of the engine.

### To remove the spark plug

1. Place the vehicle on the center-stand.
2. Remove panel A. (See page 6-6.)
3. Remove the spark plug cap.
4. Remove the spark plug as shown, using the spark plug wrench, which is located in the rear storage compartment. (See page 3-10.)



1. Spark plug wrench



1. Spark plug wrench

### To check the spark plug

1. Check that the porcelain insulator around the center electrode of the spark plug is a medium-to-light tan (the ideal color when the vehicle is ridden normally).

### TIP

If the spark plug shows a distinctly different color, the engine could be operating improperly. Do not attempt to diagnose such problems yourself. Instead, have a Yamaha dealer check the vehicle.

2. Check the spark plug for electrode erosion and excessive carbon or other deposits, and replace it if necessary.


**Specified spark plug:**  
NGK/CR7E

### To install the spark plug

1. Measure the spark plug gap with a wire thickness gauge and, if necessary, adjust the gap to specification.

## PERIODIC MAINTENANCE AND ADJUSTMENT

EAU45482



1. Spark plug gap

### Spark plug gap:

0.7–0.8 mm (0.028–0.031 in)

2. Clean the surface of the spark plug gasket and its mating surface, and then wipe off any grime from the spark plug threads.
3. Install the spark plug with the spark plug wrench, and then tighten it to the specified torque.

### Tightening torque:

Spark plug:  
13 Nm (1.3 m·kgf, 9.4 ft·lbf)

### TIP

If a torque wrench is not available when installing a spark plug, a good estimate of the correct torque is 1/4–1/2 turn past finger tight. However, the spark plug should be tightened to the specified torque as soon as possible.

4. Install the spark plug cap.
5. Install the panel.

### Engine oil

The engine oil level should be checked before each ride. In addition, the oil must be changed at the intervals specified in the periodic maintenance and lubrication chart.

The engine oil must also be changed at the initial 1000 km (600 mi) and when the oil change indicator color changes from green to red. The oil change indicator must be reset after the initial 1000 km (600 mi). (See page 3-2 for reset procedures.)


### To check the engine oil level

1. Place the vehicle on the centerstand. A slight tilt to the side can result in a false reading.
2. Start the engine, warm it up for several minutes, and then turn it off.
3. Wait a few minutes until the oil settles, remove the oil filler cap, wipe the engine oil dipstick clean, insert it back into the oil filler hole (without screwing it in), and then remove it again to check the oil level.

## PERIODIC MAINTENANCE AND ADJUSTMENT

### TIP

The engine oil should be between the tip of the dipstick and maximum level mark.




1. Engine oil filler cap
2. Engine oil dipstick
3. Maximum level mark
4. Tip of the engine oil dipstick

4. If the engine oil is not between the tip of the dipstick and the maximum level mark, add sufficient oil of the recommended type to raise it to the correct level.
5. Insert the engine oil dipstick into the oil filler hole, and then tighten the oil filler cap.

### To change the engine oil

1. Place the vehicle on the center-stand.
2. Start the engine, warm it up for several minutes, and then turn it off.
3. Place an oil pan under the engine to collect the used oil.
4. Remove the engine oil filler cap, and then remove the engine oil drain bolt and its gasket to drain the oil from the crankcase.



1. Engine oil drain bolt
2. Gasket

5. Install the engine oil drain bolt and its new gasket, and then tighten the bolt to the specified torque.

### Tightening torque:

Engine oil drain bolt  
20 Nm (2.0 m·kgf, 14 ft·lbf)

6. Refill with the specified amount of the recommended engine oil, and then install and tighten the engine oil filler cap.

### Recommended engine oil:

See page 8-1.

### Oil quantity:

1.00 L (1.06 US qt, 0.88 Imp.qt)

ECA11670

### NOTICE

- Do not use oils with a diesel specification of "CD" or oils of a higher quality than specified. In addition, do not use oils labeled "ENERGY CONSERVING II" or higher.
- Be sure no foreign material enters the crankcase.

7. Start the engine, and then let it idle for several minutes while checking it for oil leakage. If oil is leaking, immediately turn the engine off and check for the cause.

## PERIODIC MAINTENANCE AND ADJUSTMENT

8. Turn the engine off, and then check the oil level and correct it if necessary.
9. Reset the oil change indicator. (See page 3-2 for reset procedures.)

### TIP


If the engine oil is changed before the oil change indicator color changes from green to red (i.e. before the periodic oil change interval has been reached), the oil change indicator must be reset after the oil change for the next periodic oil change to be indicated at the correct time.

### Final transmission oil

EAU20065


The final transmission case must be checked for oil leakage before each ride. If any leakage is found, have a Yamaha dealer check and repair the scooter. In addition, the final transmission oil must be changed as follows at the intervals specified in the periodic maintenance and lubrication chart.

1. Start the engine, warm up the final transmission oil by riding the scooter for several minutes, and then stop the engine.
2. Place the scooter on the center-stand.
3. Place an oil pan under the final transmission case to collect the used oil.
4. Remove the final transmission oil filler cap and its O-ring from the final transmission case.
5. Remove the final transmission oil drain bolt and its gasket to drain the oil from the final transmission case.



1. Final transmission oil filler cap
2. O-ring

6. Install the final transmission oil drain bolt and its new gasket, and then tighten the bolt to the specified torque.



1. Final transmission oil drain bolt
2. Gasket

## PERIODIC MAINTENANCE AND ADJUSTMENT

### Tightening torque:

Final transmission oil drain bolt:  
23 Nm (2.3 m·kgf, 17 ft·lbf)

7. Refill with the specified amount of the recommended final transmission oil. **WARNING! Make sure that no foreign material enters the final transmission case. Make sure that no oil gets on the tire or wheel.** [EWA11311]

### Recommended final transmission oil:

See page 8-1.

### Oil quantity:

0.13 L (0.14 US qt, 0.11 Imp.qt)


8. Install the final transmission oil filler cap and its new O-ring, and then tighten the oil filler cap.
9. Check the final transmission case for oil leakage. If oil is leaking, check for the cause.

### Air filter and V-belt case air filter elements EAU45492

The air filter element should be replaced and the V-belt case air filter element should be cleaned at the intervals specified in the periodic maintenance and lubrication chart. Service the air filter elements more frequently if you are riding in unusually wet or dusty areas. The air filter check hoses must be frequently checked and cleaned if necessary.


### Replacing the air filter element

1. Place the scooter on the center-stand.
2. Remove the air filter case cover by removing the screws.



1. Air filter case cover
2. Screw

3. Pull the air filter element out.



1. Air filter element

4. Insert a new air filter element into the air filter case. **NOTICE: Make sure that the air filter element is properly seated in the air filter case. The engine should never**


## PERIODIC MAINTENANCE AND ADJUSTMENT

be operated without the air filter element installed, otherwise the piston(s) and/or cylinder(s) may become excessively worn.

[ECA10481]

5. Install the air filter case cover by installing the screws.

### Cleaning the air filter check hoses




1. Air filter check hose
2. Clamp
3. Air filter check hose plug

1. Check the hoses on the rear side of the air filter case for accumulated dirt or water.
2. If dirt or water is visible in the air filter check hoses, remove the clamps from them, and then remove the plugs to drain the hoses.


### Cleaning the V-belt case air filter element

1. Place the scooter on the center-stand.
2. Remove the screws, and then pull the V-belt case air filter element cover outward and away from V-belt case.



1. V-belt case air filter element cover
2. Screw



3. Remove the V-belt case air filter element holder by removing the screw.



1. V-belt case air filter element holder
2. Screw

4. Pull the V-belt case air filter element out, and then clean it with solvent. After cleaning, remove the remaining solvent by squeezing the element. **WARNING! Use only a dedicated parts cleaning solvent. To avoid the risk of fire or explosion, do not use gasoline or solvents with a low flash point.** [EWA10431] **NOTICE: To avoid damaging the air filter element, handle it gently and carefully, and do not twist it.** [ECA10521]

## PERIODIC MAINTENANCE AND ADJUSTMENT



1. V-belt case air filter element

5. Apply oil of the recommended type to the entire surface of the sponge material, and then squeeze the excess oil out.

### TIP


The air filter element should be wet but not dripping.

**Recommended oil:**  
Yamaha foam air filter oil or other quality foam air filter oil

6. Insert the element into the V-belt case.
7. Install the air filter element holder by installing the screw.
8. Install the air filter element cover by installing the screws.

### Checking the throttle cable free play

EAU21382



ZAUM0051

1. Throttle cable free play

The throttle cable free play should measure 3.0–5.0 mm (0.12–0.20 in) at the throttle grip. Periodically check the throttle cable free play and, if necessary, have a Yamaha dealer adjust it.



## PERIODIC MAINTENANCE AND ADJUSTMENT

### Valve clearance

EAU21401

The valve clearance changes with use, resulting in improper air-fuel mixture and/or engine noise. To prevent this from occurring, the valve clearance must be adjusted by a Yamaha dealer at the intervals specified in the periodic maintenance and lubrication chart.

### Tires

EAU33601

To maximize the performance, durability, and safe operation of your vehicle, note the following points regarding the specified tires.

#### Tire air pressure

The tire air pressure should be checked and, if necessary, adjusted before each ride.

EWA10501

#### **WARNING**

**Operation of this vehicle with improper tire pressure may cause severe injury or death from loss of control.**

- The tire air pressure must be checked and adjusted on cold tires (i.e., when the temperature of the tires equals the ambient temperature).
- The tire air pressure must be adjusted in accordance with the riding speed and with the total weight of rider, passenger, cargo, and accessories approved for this model.

#### Tire air pressure (measured on cold tires):

##### 0–83 kg (0–183 lb):

Front:

175 kPa (1.75 kgf/cm<sup>2</sup>, 25 psi)

Rear:

200 kPa (2.00 kgf/cm<sup>2</sup>, 29 psi)

##### 83–167 kg (183–368 lb):

Front:

175 kPa (1.75 kgf/cm<sup>2</sup>, 25 psi)

Rear:

250 kPa (2.50 kgf/cm<sup>2</sup>, 36 psi)

#### Maximum load\*:

167 kg (368 lb)

\* Total weight of rider, passenger, cargo and accessories


EWA10511

#### **WARNING**

**Never overload your vehicle. Operation of an overloaded vehicle could cause an accident.**

## PERIODIC MAINTENANCE AND ADJUSTMENT

### Tire inspection



1. Tire sidewall
2. Tire tread depth

The tires must be checked before each ride. If the center tread depth reaches the specified limit, if the tire has a nail or glass fragments in it, or if the sidewall is cracked, have a Yamaha dealer replace the tire immediately.

**Minimum tire tread depth (front and rear):**  
1.6 mm (0.06 in)

**TIP** \_\_\_\_\_  
The tire tread depth limits may differ from country to country. Always comply with the local regulations.

### Tire information

This model is equipped with tubeless tires.

After extensive tests, only the tires listed below have been approved for this model by Yamaha Motor Co., Ltd.

<b>Front tire:</b>
Size: 100/90-10 56J
Manufacturer/model: CHENG SHIN/C-922
<b>Rear tire:</b>
Size: 100/90-10 56J
Manufacturer/model: CHENG SHIN/C-940

EWA10470

### **WARNING**

- **Have a Yamaha dealer replace excessively worn tires. Besides being illegal, operating the vehicle with excessively worn tires decreases riding stability and can lead to loss of control.**
- **The replacement of all wheel and brake related parts, including the tires, should be left to a**

**Yamaha dealer, who has the necessary professional knowledge and experience.**

## PERIODIC MAINTENANCE AND ADJUSTMENT

### Cast wheels


EAU21960

To maximize the performance, durability, and safe operation of your vehicle, note the following points regarding the specified wheels.

- The wheel rims should be checked for cracks, bends or warpage before each ride. If any damage is found, have a Yamaha dealer replace the wheel. Do not attempt even the smallest repair to the wheel. A deformed or cracked wheel must be replaced.
- The wheel should be balanced whenever either the tire or wheel has been changed or replaced. An unbalanced wheel can result in poor performance, adverse handling characteristics, and a shortened tire life.
- Ride at moderate speeds after changing a tire since the tire surface must first be “broken in” for it to develop its optimal characteristics.

### Checking the front brake lever free play

EAUT1221



1. Front brake lever free play

The brake lever free play should measure 2.0–5.0 mm (0.08–0.20 in) as shown. Periodically check the brake lever free play and, if necessary, have a Yamaha dealer check the brake system.


#### **⚠ WARNING**

**An incorrect brake lever free play indicates a hazardous condition in the brake system. Do not operate the vehicle until the brake system has been checked or repaired by a Yamaha dealer.**

EWA10641

### Adjusting the rear brake lever free play

EAU22170




1. Rear brake lever free play

The brake lever free play should measure 10.0–20.0 mm (0.39–0.79 in) as shown. Periodically check the brake lever free play and, if necessary, adjust it as follows.

To increase the brake lever free play, turn the adjusting nut at the brake shoe plate in direction (a). To decrease the brake lever free play, turn the adjusting nut in direction (b).

## PERIODIC MAINTENANCE AND ADJUSTMENT



1. Adjusting nut

### **WARNING**

If proper adjustment cannot be obtained as described, have a Yamaha dealer make this adjustment.

EWA10650


### Checking the front brake pads and rear brake shoes

EAU22380

The front brake pads and the rear brake shoes must be checked for wear at the intervals specified in the periodic maintenance and lubrication chart.

#### Front brake pads

EAU22430




1. Brake pad wear indicator groove

Each front brake pad is provided with wear indicator grooves, which allow you to check the brake pad wear without having to disassemble the brake. To check the brake pad wear, check the wear indicator grooves. If a brake pad has worn to the point that the wear

indicator grooves have almost disappeared, have a Yamaha dealer replace the brake pads as a set.

#### Rear brake shoes

EAU22540




1. Brake shoe wear indicator  
2. Brake shoe wear limit line

The rear brake is provided with a wear indicator, which allows you to check the brake shoe wear without having to disassemble the brake. To check the brake shoe wear, check the position of the wear indicator while applying the brake. If a brake shoe has worn to the point that the wear indicator reaches the wear limit line, have a Yamaha dealer replace the brake shoes as a set.

## Checking the front brake fluid level

EAU37001



1. Minimum level mark

Insufficient brake fluid may allow air to enter the brake system, possibly causing it to become ineffective.

Before riding, check that the brake fluid is above the minimum level mark and replenish if necessary. A low brake fluid level may indicate worn brake pads and/or brake system leakage. If the brake fluid level is low, be sure to check the brake pads for wear and the brake system for leakage.

Observe these precautions:

## PERIODIC MAINTENANCE AND ADJUSTMENT

- When checking the fluid level, make sure that the top of the master cylinder is level by turning the handlebars.
- Use only the recommended quality brake fluid, otherwise the rubber seals may deteriorate, causing leakage and poor braking performance.
- Brake fluid may deteriorate painted surfaces or plastic parts. Always clean up spilled fluid immediately.
- As the brake pads wear, it is normal for the brake fluid level to gradually go down. However, if the brake fluid level goes down suddenly, have a Yamaha dealer check the cause.

**Recommended brake fluid:**  
DOT 4

### TIP

If DOT 4 is not available, DOT 3 can be used.

- Refill with the same type of brake fluid. Mixing fluids may result in a harmful chemical reaction and lead to poor braking performance.
- Be careful that water does not enter the master cylinder when refilling. Water will significantly lower the boiling point of the fluid and may result in vapor lock.

## PERIODIC MAINTENANCE AND ADJUSTMENT

### Changing the brake fluid EAU22721

Have a Yamaha dealer change the brake fluid at the intervals specified in the TIP after the periodic maintenance and lubrication chart. In addition, have the oil seals of the brake master cylinder and caliper as well as the brake hose replaced at the intervals listed below or whenever they are damaged or leaking.

- Oil seals: Replace every two years.
- Brake hose: Replace every four years.

### Checking and lubricating the cables EAU23101

The operation of all control cables and the condition of the cables should be checked before each ride, and the cables and cable ends should be lubricated if necessary. If a cable is damaged or does not move smoothly, have a Yamaha dealer check or replace it.

**WARNING! Damage to the outer sheath may interfere with proper cable operation and will cause the inner cable to rust. Replace a damaged cable as soon as possible to prevent unsafe conditions.** [EWA10721]

**Recommended lubricant:**  
Engine oil


### Checking and lubricating the throttle grip and cable EAU23112

The operation of the throttle grip should be checked before each ride. In addition, the cable should be lubricated by a Yamaha dealer at the intervals specified in the periodic maintenance chart.


## PERIODIC MAINTENANCE AND ADJUSTMENT

### Lubricating the front and rear brake levers EAU43641

#### Front brake lever



#### Rear brake lever




The pivoting points of the front and rear brake levers must be lubricated at the intervals specified in the periodic maintenance and lubrication chart.

#### Recommended lubricants:

- Front brake lever:
  - Silicone grease
- Rear brake lever:
  - Lithium-soap-based grease

### Checking and lubricating the centerstand and sidestand EAU23213



The operation of the centerstand and sidestand should be checked before each ride, and the pivots and metal-to-metal contact surfaces should be lubricated if necessary.

#### **WARNING**

If the centerstand or sidestand does not move up and down smoothly, have a Yamaha dealer check or repair it. Otherwise, the centerstand or sidestand could contact the ground and distract the operator, resulting in a possible loss of control.

EWA10741

## PERIODIC MAINTENANCE AND ADJUSTMENT

**Recommended lubricant:**  
Lithium-soap-based grease

EAU23272

### Checking the front fork


The condition and operation of the front fork must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.

#### To check the condition

Check the inner tubes for scratches, damage and excessive oil leakage.

#### To check the operation

1. Place the vehicle on a level surface and hold it in an upright position. **WARNING! To avoid injury, securely support the vehicle so there is no danger of it falling over.** [EWA10751]
2. While applying the front brake, push down hard on the handlebars several times to check if the front fork compresses and rebounds smoothly.



ECA10590

#### **NOTICE**

**If any damage is found or the front fork does not operate smoothly, have a Yamaha dealer check or repair it.**




## PERIODIC MAINTENANCE AND ADJUSTMENT

### Checking the steering

EAU45511

Worn or loose steering bearings may cause danger. Therefore, the operation of the steering must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.

1. Place the vehicle on the center-stand. **WARNING! To avoid injury, securely support the vehicle so there is no danger of it falling over.** [EWA10751]
2. Hold the lower ends of the front fork legs and try to move them forward and backward. If any free play can be felt, have a Yamaha dealer check or repair the steering.



### Checking the wheel bearings


EAU23291



The front and rear wheel bearings must be checked at the intervals specified in the periodic maintenance and lubrication chart. If there is play in the wheel hub or if the wheel does not turn smoothly, have a Yamaha dealer check the wheel bearings.

### Battery

EAUT1857



1. Battery
2. Positive battery lead (red)
3. Negative battery lead (black)

This model is equipped with a VRLA (Valve Regulated Lead Acid) battery. There is no need to check the electrolyte or to add distilled water. However, the battery lead connections need to be checked and, if necessary, tightened.

#### TIP

The battery is located behind panel B. (See page 6-6.)

## PERIODIC MAINTENANCE AND ADJUSTMENT

### WARNING

EWA10760

- Electrolyte is poisonous and dangerous since it contains sulfuric acid, which causes severe burns. Avoid any contact with skin, eyes or clothing and always shield your eyes when working near batteries. In case of contact, administer the following FIRST AID.
  - EXTERNAL: Flush with plenty of water.
  - INTERNAL: Drink large quantities of water or milk and immediately call a physician.
  - EYES: Flush with water for 15 minutes and seek prompt medical attention.
- Batteries produce explosive hydrogen gas. Therefore, keep sparks, flames, cigarettes, etc., away from the battery and provide sufficient ventilation when charging it in an enclosed space.

- KEEP THIS AND ALL BATTERIES OUT OF THE REACH OF CHILDREN.

### To charge the battery

Have a Yamaha dealer charge the battery as soon as possible if it seems to have discharged. Keep in mind that the battery tends to discharge more quickly if the vehicle is equipped with optional electrical accessories.

ECA16520

### NOTICE

To charge a VRLA (Valve Regulated Lead Acid) battery, a special (constant-voltage) battery charger is required. Using a conventional battery charger will damage the battery. If you do not have access to a constant-voltage battery charger, have a Yamaha dealer charge your battery.

### To store the battery

1. If the vehicle will not be used for more than one month, remove the battery, fully charge it, and then place it in a cool, dry place.  
**NOTICE:** When removing the

battery, be sure the key is turned to "OFF", then disconnect the negative lead before disconnecting the positive lead.

[ECA16302]

2. If the battery will be stored for more than two months, check it at least once a month and fully charge it if necessary.
3. Fully charge the battery before installation.
4. Before installation, make sure that the battery leads are properly connected to the battery terminals.

ECAT1053


### NOTICE

- Always keep the battery charged. Storing a discharged battery can cause permanent battery damage.
- After installing the battery, be sure to turn the main switch from "ON" to "OFF" three times in 3 seconds intervals to initialize the idle speed control system.

## PERIODIC MAINTENANCE AND ADJUSTMENT

### Replacing the fuse

EAUT2023



1. Fuse
2. Spare fuse

The fuse holder is located beside the battery. Remove panel B to access the fuse. (See page 6-6.)

If the fuse is blown, replace it as follows.

1. Turn the key to "OFF" and turn off all electrical circuits.
2. Remove the blown fuse, and then install a new fuse of the specified amperage. **WARNING! Do not use a fuse of a higher amperage rating than recommended to avoid causing extensive damage to the electrical system and possibly a fire.** [EWA15131] **NOTICE:**

After removing and installing the main fuse, be sure to turn the main switch from "ON" to "OFF" three times in 3 seconds intervals to initialize the idle speed control system. [ECAT1062]

**Specified fuse:**  
15.0 A

3. Turn the key to "ON" and turn on the electrical circuits to check if the devices operate.
4. If the fuse immediately blows again, have a Yamaha dealer check the electrical system.

### Replacing the headlight bulb


EAU45503

This model is equipped with a quartz bulb headlight. If the headlight bulb burns out, replace it as follows.

ECA10660

#### **NOTICE**

**Do not touch the glass part of the headlight bulb to keep it free from oil, otherwise the transparency of the glass, the luminosity of the bulb, and the bulb life will be adversely affected. Thoroughly clean off any dirt and fingerprints on the headlight bulb using a cloth moistened with alcohol or thinner.**




1. Do not touch the glass part of the bulb.

1. Place the vehicle on the center-stand.

## PERIODIC MAINTENANCE AND ADJUSTMENT


2. Remove cowling B. (See page 6-6.)
3. Remove the headlight bulb cover.
4. Remove the headlight bulb holder by turning it counterclockwise, and then remove the burnt-out bulb from the headlight unit.
5. Place a new headlight bulb into position, and then install the bulb holder by turning the holder clockwise.
6. Install the headlight bulb cover.
7. Install the cowling.
8. Have a Yamaha dealer adjust the headlight beam if necessary.



1. Headlight bulb cover

6

1. Headlight bulb holder
2. Headlight bulb



1. Headlight bulb holder  
2. Headlight bulb

### Replacing a front turn signal light bulb


EAUT1262

ECA10670

#### NOTICE

It is advisable to have a Yamaha dealer perform this job.

1. Place the scooter on the center-stand.
2. Remove cowling A. (See page 6-6.)
3. Remove the socket (together with the bulb) by turning it counterclockwise.



1. Turn signal light bulb socket

4. Remove the burnt-out bulb by pushing it in and turning it counterclockwise.

## PERIODIC MAINTENANCE AND ADJUSTMENT

5. Insert a new bulb into the socket, push it in, and then turn it clockwise until it stops.
6. Install the socket (together with the bulb) by turning it clockwise.
7. Install the cowling.

### Rear turn signal light and tail/brake light

EAU37741


If a rear turn signal light or the tail/brake light does not come on, have a Yamaha dealer check its electrical circuit or replace the bulb.

### Replacing the auxiliary light bulb

EAU45462

If the auxiliary light bulb burns out, replace it as follows.

1. Place the vehicle on the center-stand.
2. Remove cowling A. (See page 6-6.)
3. Remove the auxiliary light socket (together with the bulb) by pulling it out.



1. Auxiliary light bulb
2. Auxiliary light bulb socket

4. Remove the burnt-out bulb by pulling it out.
5. Insert a new bulb into the socket.

## PERIODIC MAINTENANCE AND ADJUSTMENT

---

6. Install the auxiliary light socket (together with the bulb) by pushing it in.
7. Install the cowling.

### Troubleshooting

EAU25861

Although Yamaha scooters receive a thorough inspection before shipment from the factory, trouble may occur during operation. Any problem in the fuel, compression, or ignition systems, for example, can cause poor starting and loss of power.

The following troubleshooting chart represents a quick and easy procedure for checking these vital systems yourself. However, should your scooter require any repair, take it to a Yamaha dealer, whose skilled technicians have the necessary tools, experience, and know-how to service the scooter properly.

Use only genuine Yamaha replacement parts. Imitation parts may look like Yamaha parts, but they are often inferior, have a shorter service life and can lead to expensive repair bills.

EWA15141



**When checking the fuel system, do not smoke, and make sure there are no open flames or sparks in the area, including pilot lights from water**


**heaters or furnaces. Gasoline or gasoline vapors can ignite or explode, causing severe injury or property damage.**

---

# PERIODIC MAINTENANCE AND ADJUSTMENT

EAUT1981

## Troubleshooting chart



## SCOOTER CARE AND STORAGE

### Matte color caution

EAU37833

#### NOTICE

Some models are equipped with matte colored finished parts. Be sure to consult a Yamaha dealer for advice on what products to use before cleaning the vehicle. Using a brush, harsh chemical products or cleaning compounds when cleaning these parts will scratch or damage their surface. Wax also should not be applied to any matte colored finished parts.

ECA15192

### Care

EAU26094

While the open design of a scooter reveals the attractiveness of the technology, it also makes it more vulnerable. Rust and corrosion can develop even if high-quality components are used. A rusty exhaust pipe may go unnoticed on a car, however, it detracts from the overall appearance of a scooter. Frequent and proper care does not only comply with the terms of the warranty, but it will also keep your scooter looking good, extend its life and optimize its performance.

#### Before cleaning

1. Cover the muffler outlet with a plastic bag after the engine has cooled down.
2. Make sure that all caps and covers as well as all electrical couplers and connectors, including the spark plug cap, are tightly installed.
3. Remove extremely stubborn dirt, like oil burnt onto the crankcase, with a degreasing agent and a brush, but never apply such prod-

ucts onto seals, gaskets and wheel axles. Always rinse the dirt and degreaser off with water.

#### Cleaning

ECA10783

#### NOTICE

- Avoid using strong acidic wheel cleaners, especially on spoked wheels. If such products are used on hard-to-remove dirt, do not leave the cleaner on the affected area any longer than instructed. Also, thoroughly rinse the area off with water, immediately dry it, and then apply a corrosion protection spray.
- Improper cleaning can damage plastic parts (such as cowlings, panels, windshields, headlight lenses, meter lenses, etc.) and the mufflers. Use only a soft, clean cloth or sponge with water to clean plastic. However, if the plastic parts cannot be thoroughly cleaned with water, diluted mild detergent with water may be used. Be sure to rinse



## SCOOTER CARE AND STORAGE

off any detergent residue using plenty of water, as it is harmful to plastic parts.

- Do not use any harsh chemical products on plastic parts. Be sure to avoid using cloths or sponges which have been in contact with strong or abrasive cleaning products, solvent or thinner, fuel (gasoline), rust removers or inhibitors, brake fluid, antifreeze or electrolyte.
- Do not use high-pressure washers or steam-jet cleaners since they cause water seepage and deterioration in the following areas: seals (of wheel and swing-arm bearings, fork and brakes), electric components (couplers, connectors, instruments, switches and lights), breather hoses and vents.
- For scooters equipped with a windshield: Do not use strong cleaners or hard sponges as they will cause dulling or scratching. Some cleaning compounds for plastic may leave scratches on the windshield.

Test the product on a small hidden part of the windshield to make sure that it does not leave any marks. If the windshield is scratched, use a quality plastic polishing compound after washing.

### After normal use

Remove dirt with warm water, a mild detergent, and a soft, clean sponge, and then rinse thoroughly with clean water. Use a toothbrush or bottlebrush for hard-to-reach areas. Stubborn dirt and insects will come off more easily if the area is covered with a wet cloth for a few minutes before cleaning.

### After riding in the rain, near the sea or on salt-sprayed roads

Since sea salt or salt sprayed on the roads during winter are extremely corrosive in combination with water, carry out the following steps after each ride in the rain, near the sea or on salt-sprayed roads.

### TIP

Salt sprayed on roads in the winter may remain well into spring.

1. Clean the scooter with cold water and a mild detergent after the engine has cooled down. **NOTICE: Do not use warm water since it increases the corrosive action of the salt.** [ECA10791]
2. Apply a corrosion protection spray on all metal, including chrome- and nickel-plated, surfaces to prevent corrosion.

### After cleaning

1. Dry the scooter with a chamois or an absorbing cloth.
2. Use a chrome polish to shine chrome, aluminum and stainless-steel parts, including the exhaust system. (Even the thermally induced discoloring of stainless-steel exhaust systems can be removed through polishing.)

## SCOOTER CARE AND STORAGE

3. To prevent corrosion, it is recommended to apply a corrosion protection spray on all metal, including chrome- and nickel-plated, surfaces.
4. Use spray oil as a universal cleaner to remove any remaining dirt.
5. Touch up minor paint damage caused by stones, etc.
6. Wax all painted surfaces.
7. Let the scooter dry completely before storing or covering it.

EWA10942

### WARNING

**Contaminants on the brakes or tires can cause loss of control.**

- **Make sure that there is no oil or wax on the brakes or tires. If necessary, clean the brake discs and brake linings with a regular brake disc cleaner or acetone, and wash the tires with warm water and a mild detergent.**
- **Before operating the scooter test its braking performance and cornering behavior.**

### NOTICE

ECA10800

- **Apply spray oil and wax sparingly and make sure to wipe off any excess.**
- **Never apply oil or wax to any rubber and plastic parts, but treat them with a suitable care product.**
- **Avoid using abrasive polishing compounds as they will wear away the paint.**

### TIP

- Consult a Yamaha dealer for advice on what products to use.
- Washing, rainy weather or humid climates can cause the headlight lens to fog. Turning the headlight on for a short period of time will help remove the moisture from the lens.

## Storage

EAU36561

### Short-term

Always store your scooter in a cool, dry place and, if necessary, protect it against dust with a porous cover.

ECA10820

### NOTICE

- **Storing the scooter in a poorly ventilated room or covering it with a tarp, while it is still wet, will allow water and humidity to seep in and cause rust.**
- **To prevent corrosion, avoid damp cellars, stables (because of the presence of ammonia) and areas where strong chemicals are stored.**

### Long-term

Before storing your scooter for several months:

1. Follow all the instructions in the "Care" section of this chapter.
2. Fill up the fuel tank and add fuel stabilizer (if available) to prevent the fuel tank from rusting and the fuel from deteriorating.

## SCOOTER CARE AND STORAGE

3. Perform the following steps to protect the cylinder, piston rings, etc. from corrosion.
  - a. Remove the spark plug cap and spark plug.
  - b. Pour a teaspoonful of engine oil into the spark plug bore.
  - c. Install the spark plug cap onto the spark plug, and then place the spark plug on the cylinder head so that the electrodes are grounded. (This will limit sparking during the next step.)
  - d. Turn the engine over several times with the starter. (This will coat the cylinder wall with oil.)
  - e. Remove the spark plug cap from the spark plug, and then install the spark plug and the spark plug cap. **WARNING! To prevent damage or injury from sparking, make sure to ground the spark plug electrodes while turning the engine over.** [EWA10951]
4. Lubricate all control cables and the pivoting points of all levers and pedals as well as of the side-stand/centerstand.
5. Check and, if necessary, correct the tire air pressure, and then lift the scooter so that both of its wheels are off the ground. Alternatively, turn the wheels a little every month in order to prevent the tires from becoming degraded in one spot.
6. Cover the muffler outlet with a plastic bag to prevent moisture from entering it.
7. Remove the battery and fully charge it. Store it in a cool, dry place and charge it once a month. Do not store the battery in an excessively cold or warm place [less than 0 °C (30 °F) or more than 30 °C (90 °F)]. For more information on storing the battery, see page 6-23.

### TIP

Make any necessary repairs before storing the scooter.

## SPECIFICATIONS

### Dimensions:

Overall length:  
1860 mm (73.2 in)  
Overall width:  
670 mm (26.4 in)  
Overall height:  
1045 mm (41.1 in)  
Seat height:  
730 mm (28.7 in)  
Wheelbase:  
1250 mm (49.2 in)  
Ground clearance:  
95 mm (3.74 in)  
Minimum turning radius:  
1900 mm (74.8 in)

### Weight:


With oil and fuel:  
110.0 kg (243 lb)

### Engine:

Engine type:  
Air cooled 4-stroke, SOHC  
Cylinder arrangement:  
Forward-inclined single cylinder  
Displacement:  
125 cm<sup>3</sup>  
Bore × stroke:  
51.5 × 60.0 mm (2.03 × 2.36 in)  
Compression ratio:  
9.50 :1  
Starting system:  
Electric starter  
Lubrication system:  
Wet sump

### Engine oil:

Recommended brand:  
YAMALUBE  
Type:  
SAE 10W-30, 10W-40, 10W-50, 15W-40,  
20W-40 or 20W-50



Recommended engine oil grade:  
API service SG type or higher, JASO  
standard MA  
Engine oil quantity:  
Periodic oil change:  
1.00 L (1.06 US qt, 0.88 Imp.qt)

### Final transmission oil:

Type:  
SAE 85W-140(GL5)  
Quantity:  
0.13 L (0.14 US qt, 0.11 Imp.qt)

### Air filter:

Air filter element:  
Oil-coated paper element

### Fuel:

Recommended fuel:  
Regular unleaded gasoline only  
Fuel tank capacity:  
5.5 L (1.45 US gal, 1.21 Imp.gal)

### Fuel injection:

Throttle body:  
ID mark:  
4P72 00

### Spark plug (s):

Manufacturer/model:  
NGK/CR7E  
Spark plug gap:  
0.7–0.8 mm (0.028–0.031 in)

### Clutch:

Clutch type:  
Dry, centrifugal automatic

### Transmission:

Primary reduction system:  
Helical gear  
Primary reduction ratio:  
40/15 (2.667)  
Secondary reduction system:  
Spur gear  
Secondary reduction ratio:  
38/13 (2.923)  
Transmission type:  
V-belt automatic  
Operation:  
Centrifugal automatic type

### Chassis:

Frame type:  
Steel tube backbone

## SPECIFICATIONS

Caster angle:  
27.00 °

Trail:  
75.0 mm (2.95 in)

**Front tire:**

Type:  
Tubeless

Size:  
100/90-10 56J

Manufacturer/model:  
CHENG SHIN/C-922

**Rear tire:**

Type:  
Tubeless

Size:  
100/90-10 56J

Manufacturer/model:  
CHENG SHIN/C-940

**Loading:**

Maximum load:  
167 kg (368 lb)  
(Total weight of rider, passenger, cargo and accessories)

**Tire air pressure (measured on cold tires):**

Loading condition:  
0–83 kg (0–183 lb)

Front:  
175 kPa (1.75 kgf/cm<sup>2</sup>, 25 psi)

Rear:  
200 kPa (2.00 kgf/cm<sup>2</sup>, 29 psi)

Loading condition:  
83–167 kg (183–368 lb)

Front:  
175 kPa (1.75 kgf/cm<sup>2</sup>, 25 psi)

Rear:  
250 kPa (2.50 kgf/cm<sup>2</sup>, 36 psi)

**Front wheel:**

Wheel type:  
Cast wheel

Rim size:  
J10 x 2.15

**Rear wheel:**

Wheel type:  
Cast wheel

Rim size:  
J10 x MT2.50

**Front brake:**

Type:  
Single disc brake

Operation:  
Right hand operation

Recommended fluid:  
DOT 3 or 4

**Rear brake:**

Type:  
Drum brake

Operation:  
Left hand operation

**Front suspension:**

Type:  
Telescopic fork

Spring/shock absorber type:  
Coil spring/oil damper

Wheel travel:  
80.0 mm (3.15 in)

**Rear suspension:**

Type:  
Unit swing

Spring/shock absorber type:  
Coil spring/oil damper

Wheel travel:  
65.0 mm (2.56 in)

**Electrical system:**

Ignition system:  
TCI (digital)

Charging system:  
AC magneto

**Battery:**

Model:  
GTX7A-BS/YTX7A-BS

Voltage, capacity:  
12 V, 6.0 Ah

**Headlight:**

Bulb type:  
Halogen bulb

**Bulb voltage, wattage × quantity:**

Headlight:  
12 V, 35 W/35 W × 1

Tail/brake light:  
12 V, 5.0 W/21.0 W × 1

Front turn signal light:  
12 V, 10.0 W × 2

Rear turn signal light:  
12 V, 16.0 W × 2

Meter lighting:  
12 V, 3.4 W × 2

High beam indicator light:  
12 V, 1.7 W × 1

## SPECIFICATIONS

---

Turn signal indicator light:

12 V, 1.7 W × 1

Engine trouble warning light:

12 V, 1.7 W × 1

**Fuses:**

Main fuse:

15.0 A

## CONSUMER INFORMATION

### Identification numbers

EAU48610

Record the vehicle identification number and model label information in the spaces provided below for assistance when ordering spare parts from a Yamaha dealer or for reference in case the vehicle is stolen.


VEHICLE IDENTIFICATION NUMBER:

MODEL LABEL INFORMATION:

○  
●

### Vehicle identification number

EAU26410




1. Vehicle identification number

The vehicle identification number is stamped into the frame.

**TIP** \_\_\_\_\_  
The vehicle identification number is used to identify your vehicle and may be used to register it with the licensing authority in your area.

### Model label

EAU26500



1. Model label

The model label is affixed to the inside of the rear storage compartment. (See page 3-10.) Record the information on this label in the space provided. This information will be needed when ordering spare parts from a Yamaha dealer.

## INDEX

- A**
- Acceleration and deceleration..... 5-2
  - Air filter and V-belt case air filter elements ..... 6-12
  - Anti-theft alarm (optional)..... 3-4
  - Auxiliary light bulb, replacing ..... 6-27
- B**
- Battery..... 6-23
  - Brake fluid, changing ..... 6-20
  - Brake fluid level, checking ..... 6-19
  - Brake lever, front..... 3-5
  - Brake lever, rear ..... 3-6
  - Brake levers, lubricating..... 6-21
  - Brake pads and shoes, checking ..... 6-18
  - Braking..... 5-3
- C**
- Cables, checking and lubricating ..... 6-20
  - Care ..... 7-1
  - Carrier..... 3-11
  - Catalytic converters ..... 3-8
  - Centerstand and sidestand, checking and lubricating ..... 6-21
  - Cowlings and panels, removing and installing..... 6-6
- D**
- Dimmer switch ..... 3-5
- E**
- Engine break-in..... 5-4
  - Engine oil ..... 6-9
  - Engine trouble warning light..... 3-3
- F**
- Final transmission oil ..... 6-11
  - Front brake lever free play, checking.... 6-17
  - Front fork, checking ..... 6-22
  - Fuel..... 3-7
  - Fuel consumption, tips for reducing..... 5-3
  - Fuel gauge..... 3-4
  - Fuel tank cap ..... 3-6
  - Fuse, replacing ..... 6-25
- H**
- Handlebar switches ..... 3-5
  - Headlight bulb, replacing ..... 6-25
  - Helmet holders ..... 3-9
  - High beam indicator light ..... 3-2
  - Horn switch..... 3-5
- I**
- Identification numbers ..... 9-1
  - Ignition circuit cut-off system ..... 3-12
  - Indicator, indicator lights and warning light ..... 3-2
- K**
- Keyhole cover..... 3-2
- L**
- Luggage hook..... 3-11
- M**
- Main switch/steering lock..... 3-1
  - Maintenance and lubrication, periodic ... 6-3
  - Maintenance, emission control system... 6-2
  - Matte color, caution ..... 7-1
  - Model label ..... 9-1
- P**
- Parking ..... 5-4
  - Part locations..... 2-1
- R**
- Rear brake lever free play, adjusting.... 6-17
  - Rear turn signal light and tail/brake light..... 6-27
- S**
- Safe-riding points ..... 1-5
  - Safety information ..... 1-1
  - Seat..... 3-8
  - Self-diagnosis device ..... 3-4
  - Sidestand ..... 3-11
  - Spark plug, checking ..... 6-8
  - Specifications ..... 8-1
  - Speedometer unit..... 3-3
  - Starting off..... 5-2
  - Starting the engine ..... 5-1
  - Start switch..... 3-5
  - Steering, checking..... 6-23
  - Storage..... 7-3
  - Storage compartments..... 3-10
- T**
- Throttle cable free play, checking ..... 6-14
  - Throttle grip and cable, checking and lubricating ..... 6-20
  - Tires ..... 6-15
  - Troubleshooting ..... 6-28
  - Troubleshooting chart ..... 6-29
  - Turn signal indicator light ..... 3-2
  - Turn signal light bulb (front), replacing ..... 6-26
  - Turn signal switch ..... 3-5
- V**
- Valve clearance..... 6-15
  - Vehicle identification number ..... 9-1
- W**
- Wheel bearings, checking ..... 6-23
  - Wheels ..... 6-17







PRINTED IN CHINA  
2009.08-0.3x2 CR  
(E)



DIC183