




Quick Installation Guide

AC1200 Wireless Dual Band Gigabit Router

Model: A3002RU

Copyrights © TOTOLINK. All Rights Reserved. <http://www.totolink.net>
Information in this document is subject to change without prior notice.

1 Hardware Installation




Default Wi-Fi Name:
TOTOLINK_A3002RU
TOTOLINK_A3002RU_5G

LEDs	Status	Description
System	Off	System is not running or didn't boot.
	On	System is booting.
2.4G/5G	Blinking	System is running normally.
	Off	2.4G/5G Wi-Fi was turned off.
WAN / LAN 1-4	On	2.4G/5G Wi-Fi is working normally.
	Off	Corresponding port disconnected.
USB	On	Corresponding port connected.
	Blinking	Corresponding port is transmitting data.
USB	Off	USB port disconnected
	On	USB port connected

Ports and Buttons	Description
DC In	Connect to the Power Source.
Power Button	Control the power supply to the router.
WAN Port	Connect to the Internet.
LAN1-LAN4 Ports	Connect to the computers.
USB Port	Connect to the USB storage or other USB devices.
RST/WPS Button	WPS: Press and hold for 1-3 seconds to activate the WPS function. Reset: Press and hold the button(for more than 5 seconds) until the System indicator becomes quick blinking light to reset the router.


2 Configure the router on Phone

- Connect the Wi-Fi of the router with your Phone. Find "TOTOLINK_A3002RU" or "TOTOLINK_A3002RU_5G" from the WLAN list on your Phone, and choose one of them to connect.



2 Configure the router on Phone

- Input **admin** for both User Name and Password on the coming page, then click Login.



- Click **Quick Setup** on the coming page.



- Internet Setting. Choose a suitable WAN Connection type from the list, and fill in the information required.

WAN Setting

PPPoE Dynamic IP Static IP

Please enter User Name and Password provided by your ISP.

User Name
ISP

Password


Back Next

WAN Connection Type	Description
Static IP	Input the IP address, Subnet Mask, Default Gateway, DNS from your ISP.
DHCP	No information required. Please confirm with your ISP if DHCP is supported.
PPPoE	Input User Name and Password from your ISP.

3 FAQs

(Frequently Asked Questions)

- Wireless Setting. Create a password for the 2.4G Wi-Fi and 5G Wi-Fi. (Here users could also revise the default Wi-Fi name.) And then click "Finish" to save all the settings. It may take 1 minute to save the settings and restart. This time your phone will be disconnected from the Wi-Fi of the router.



- After the Wi-Fi is set up, choose the one you set just now and enter the correct password. Now, you could enjoy the Wi-Fi.

- Unable to open the router's login page on the browser?**
Please check if your Phone has connected to the router and make sure you have entered the correct default gateway <http://totolink.net>
- How to reset the router to factory default settings?**
Keep the router powered on, then press and hold the WPS/RST button(for more than 5 seconds) until the System indicator becomes quick blinking light.
- How to do if forgetting the router's Login User Name and Password?**
Reset the router to the factory default settings. The User Name and Password would be resumed to **admin**.
- How to do if forgetting the password of the Wi-Fi?**
Please connect any LAN port of the router to the computer with RJ45 cable and then open any web browser to log in the router to check the Wi-Fi password in the **2.4G Wireless—Basic Settings** or **5G Wireless—Basic Settings** (Please ensure your computer has been set to "Obtain an IP address automatically" in advance.)

FCC warning:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
RF Radiation Exposure Statement
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Manufacturer: ZIONCOM ELECTRONICS (SHENZHEN) LTD.
Address: Room 702, Unit D, 4 Building Shenzhen Software Industry Base, Xuefu Road, Nanshan District, Shenzhen, Guangdong, China