

ZTE CORPORATION

ZTE A611+

GSM Dual-band GPRS Digital Mobile Phone

User Manual

Copyright © 2008 by ZTE Corporation

All rights reserved.

No part of this publication may be excerpted, reproduced, translated or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation.

ZTE operates a policy of continuous development. We reserve the right to update the technical specifications in this document at any time without prior notice.

Release V1.0

Manual number

MM DD, 2008

FCC COMPLIANCE STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Warning

Changes or modifications made to this equipment not expressly approved by ZTE for compliance could void the user's authority to operate the equipment.

Health and safety information

The phone with internal antenna has been tested for compliance with FCC RF Exposure (SAR) limits and is complied with FCC RF exposure compliance requirements.

Exposure to radio frequency energy

Radio wave exposure and Specific Absorption Rate (SAR) information The handset is designed to comply with safety requirements for exposure to radio waves. This requirement is based on scientific guidelines that include safety margins designed to assure the safety of all persons, regardless of age and health.

The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate, or SAR. Tests for SAR are conducted using a standardized method with the phone transmitting at its highest certified power level in all used frequency bands. While there may be differences between the SAR levels of various ZTE phone models, they are all designed to meet the relevant guidelines for exposure to radio waves.

The SAR limit recommended is 1.6W/kg averaged over one (1) gram of tissue. The highest SAR value for this device when tested at the ear was 0.768 W/kg, and when tested at the body it was 0.864 W/kg SAR compliance for bodyworn operations is restricted to belt-clips, holsters, or similar accessories that have no metallic component in the assembly and which provide at least 1.5 cm separation between the device, including its antenna, and the users body.

Contents

GENERAL INFORMATION	5
WELCOME	5
SECURITY	5
SAFETY PRECAUTIONS	5
GETTING STARTED	8
KEY DEFINITION	8
DISPLAY INDICATORS	8
TECHNICAL PARAMETERS	9
BATTERY	9
Removing & Installing the Battery	9
Charging the Battery	9
CONNECTING TO THE NETWORK	9
SIM Card	9
Inserting & Removing SIM Card	10
Switching on/off Your Phone	10
Connecting to the Network	10
BASIC OPERATIONS.....	10
MAKING AND ANSWERING A CALL	10
CALL MENU	10
FUNCTION MENU.....	11
USAGE AND STRUCTURE OF FUNCTION MENU	11
CALL HISTORY	11
Missed Calls/ Dialed Calls/ Received Calls	11
Delete Call Log	11
Call Time	11
Call Cost	11
USER PROFILES	11
FILE MANAGER	11
SETTINGS	11
Phone Setup	11
Call Setup	12
Network Setup	12
Security Setup	12
Restore Factory Settings	12
MESSAGES	12
SMS	13
MMS	13

Voice Mail Server	14
Broadcast Message	14
PHONE BOOK	14
TOOLKIT.....	14
FM Radio	14
Alarm	14
Stopwatch	14
Calendar	14
World Clock	14
Calculator	14
Currency Converter	15
SERVICES	15
STK	15
WAP	15
Data Account	15
GAMES.....	15
TEXT INPUT	15
OVERVIEW	15
ABC AND abc MODE.....	15
123 MODE.....	16
EzI EN AND eZi en MODE	16
CHARACTER CHART	16
TROUBLESHOOTING	16

General Information

Welcome

Thank you for using ZTE A611+ GSM digital mobile phone.

To guarantee the mobile phone always in its best condition, please read this manual carefully and keep it for further use.

The pictures, symbols and contents in this manual are just for your reference. They might not be completely identical with your mobile phone.

Security

- To protect your mobile phone from illegal use, take the security measures as follows:
 - Set PIN codes of the SIM card.
 - Set handset lock code.
 - Set call restrictions.

Safety Precautions

This section includes some important information on safe and efficient operation. Please read this information before using the phone.

Operational Precautions

- Please use your phone properly. When making or receiving a call, please hold your phone as holding a wireline telephone. Make sure that the phone is at least one inch (two point five centimeters) from your body when transmitting.

- Do not touch the antenna when the phone is in use. Touching the antenna area affects call quality and may cause the phone to operate at a higher power level than needed.
- Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when watching television or playing video games. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your doctor before playing video games on your phone or enabling a flashing-light feature on your phone. (The flashing-light feature is not available on all products.)
- Keep the phone out of the reach of small children. The phone may cause injury if used as a toy.

Precautions While Driving

- Please pay attention to the traffic safety. Check the laws and regulations on the use of your phone in the area where you drive. Always obey them.
- Use hands-free function of the phone, if available.
- Pull off the road and park before making or answering a call if conditions require.

Precautions for Medical Devices and Facilities

- When using your phone near pacemakers, please always keep the phone more than eight inches (twenty centimeters) from the pacemaker when the phone is switched on. Do not carry the phone in the breast pocket. Use the ear opposite the pacemaker to minimize the potential for interference. Switch off the phone immediately if necessary.
- Some phones may interfere with some hearing aids. In the event of such interference, you may consult your hearing aids manufacturer to discuss alternatives.
- If you use any other personal medical device, please consult the manufacturer of your device to determine if it is adequately shielded from RF energy.
- In those facilities with special demand, such as hospital or health care facilities, please pay attention to the restriction on the use of mobile phone. Switch off your phone if required.

Mobile Phone

- Please use original accessories or accessories approved by the phone manufacturer. Using any unauthorized accessories may affect your mobile phone's performance, damage your phone or even cause danger to your body and violate related local regulations about telecom terminals.
- Turn off your phone before you clean it. Use a damp or anti-static cloth to clean the phone. Do not use a dry cloth or electrostatically charged cloth. Do not use chemical or abrasive cleaners as these could damage the phone.
- As your mobile phone can produce electromagnetic field, do not place it near magnetic items such as computer disks.
- Using the phone near electrical appliances such as TV, telephone, radio and personal computer can cause interference.
- Do not expose your mobile phone to direct sunlight or store it in hot areas. High temperatures can shorten the life of electronic devices.
- Keep your phone dry. Any liquid may damage your phone.
- Do not drop, knock or harshly treat the phone. Rough handling can break internal circuit boards.
- Do not connect the phone with any incompatible enhancement.
- Do not attempt to disassemble the mobile phone or battery.
- Do not store the phone with flammable or explosive articles.
- Do not charge the mobile phone without battery.

Precautions for Potentially Explosive Atmospheres

- Switch off your phone prior to entering any area with potentially explosive atmospheres, such as fueling areas, fuel or chemical transfer or storage facilities.

- Do not remove, install, or charge batteries in such areas. Spark in a potentially explosive atmosphere can cause an explosion or fire resulting in bodily injury or even death.
- To avoid possible interference with blasting operations, switch off your phone when you are near electrical blasting caps, in a blasting area, or in areas posted "Turn off electronic devices." Obey all signs and instructions.

Precautions for Electronic Devices

- Some electronic devices are susceptible to electromagnetic interference sent by mobile phone if inadequately shielded, such as electronic system of vehicles. Please consult the manufacturer of the device before using the phone if necessary.

Safety and General Use in Vehicles

- Safety airbag, brake, speed control system and oil eject system shouldn't be affected by wireless transmission. If you do meet problems above, please contact your automobile provider. Do not place your phone in the area over an airbag or in the airbag deployment area. Airbags inflate with great force. If a phone is placed in the airbag deployment area and the airbag inflates, the phone may be propelled with great force and cause serious injury to occupants of the vehicle.
- Please turn off your mobile phone at a refueling point, and the same to the place where the use of two-way radio is prohibited.

Aircraft Safety

- Please turn off your mobile phone before the airplane takes off. In order to protect airplane's communication system from interference, it is forbidden to use mobile phone in flight. Safety regulations require you to have permission from a crew member to use your phone while the plane is on the ground.
- If the mobile phone has the function of automatic timing power-on, please check your alarm setting to make sure that your phone will not be automatically turned on during flight.

Battery Use

- Do not short-circuit the battery, as this can cause the unit to overheat or ignite.
- Do not store battery in hot areas or throw it into fire. Otherwise, it will cause explosion.
- Do not disassemble or refit the battery. Otherwise, it will cause liquid leakage, overheating, explosion and ignition of the battery.
- Please store the battery in a cool dry place if you don't use it for a long period.
- The battery can be recharged for hundreds of times, but it will eventually wear out. When the operating time (talk time and standby time) is noticeably shorter than normal, it is time to replace it with a new one.
- Please stop using the charger and battery when they are damaged or show evidence of aging.
- Return the worn-out battery to the provider or dispose of it in accordance with environment regulations. Do not dispose of it in household rubbish.
- Only use the original batteries. Using any unauthorized battery may affect your handset performance or may cause danger of explosion, etc.

Warning: If the battery is damaged, do not discharge it. If the leakage does come into contact with the eyes or skin, wash thoroughly in clean water and consult a doctor.







Getting Started





Key Definition



Note: In this manual **press a key** means you press a key and then release it; **hold a key** means you press a key and hold on for two seconds or more.

Display Indicators

-  Signal strength
-  GPRS online
-  Missed call
-  Divert All Voice Calls
-  Alarm clock
-  Keypad lock

-  Mute
-  Vibration
-  New message; no space for messages when blinking
-  Battery charge level

Technical Parameters

Handset

Type	ZTE A611+
Dimensions (L×W×H)	93 mm×47.8 mm×15.9 mm
Weight	Approx. 80 g (with battery)

Battery

Continuous standby time	Approx. 120 hours - 150 hours (subject to network status)
Continuous talk time	Approx. 2 hours – 3 hours (subject to network status)

For other parameters about battery and charger, refer to their labels.

Battery

The accessory lithium battery of the handset can be immediately used after unpacking. A new battery will have the best performance after full charge/discharge cycles for the first three times.

Removing & Installing the Battery

- Remove: Switch off your phone, slide down the cover and then lift the battery from the compartment to remove it.
- Install: Insert the battery by aligning the metal contacts on the battery with the metal contacts in the battery compartment on the phone. Push down the battery until it clicks into place and then install the battery cover.

Charging the Battery

- Plug the charger connector into the charge port on the left side of the phone. (Note: Put upward the side with arrow.) Then plug the other end of the charger in an appropriate electrical outlet.
- Now, a charge indicator displays in the upper right corner of the screen. If the battery is charged in power-off condition, the indicator bar will scroll. If the phone is over-used in shortage of battery or not used for a long time, it will take a few minutes for the indicator bar to show.
- When the battery is fully charged, the bar stops scrolling. Generally the whole charge process needs two to three hours (charge the battery for six to eight hours for the first three times). Normally, during the charge process, your phone, battery and charger may become hot.
- Disconnect the charger with the phone and the power outlet when charge finished.

Warning:

- Put the phone at a ventilated place with temperature between + 5°C - + 40°C. Use only the supplied or approved chargers. Using unauthorized charger may cause danger and violate the authorization and warranty rules of the phone.
- Charge the battery in time when your phone automatically powers off or displays a warning "Battery low".
- The conversation time and standby time of the phone lie on ideal working environments. In practice, the battery working time varies with different network conditions, working environments and modes.

Connecting to the Network

SIM Card

Do not touch the metal contact area of the SIM card (Subscriber Identity Module card). Doing so may cause information in the card lost or destroyed. Keep the card away from electricity and magnetism.

Inserting & Removing SIM Card

- Switch off your phone, disconnect the outer power source and remove the battery.
Warning: It is forbidden to insert or remove the SIM card when it is on or connected to an outer power source.
- Insert the SIM card into the SIM card slot or pull it out from the slot.

Switching on/off Your Phone

Hold the End key to power on/off the phone.

The mobile phone will automatically test whether the SIM card is plugged in and valid after power on, then the following messages will be displayed on the screen sequentially.:

Enter Phone Lock—if a phone lock code has been set.

Enter PIN —if a SIM card password has been set.

Searching —search for the right network.

Connecting to the Network

After the phone and the SIM card are unlocked, the mobile phone will automatically search for the network. After a few seconds, your phone will be registered on the network. Now your phone is in the standby mode. Besides receiving and sending calls, you can do the following things:

- Press the Left soft key to enter the function menu.
- Press the Right soft key to enter the Name [Phone Book].
- Press the Up/Down/Left/Right key to enter Audio Player/Alarm/User Profiles/Tone Setup, respectively.

Note: If “Emergency” is shown on the screen, you can only make emergency calls.

Basic Operations

Making and Answering a Call

You can make or answer calls in the standby mode. The bar at the upper left corner of the screen shows the network signal strength.

- Dial a number: Input the number with the number keys and then press the Dial key. You can hold the * key until it displays a waiting indicator “p” to insert it between the telephone exchange and the extension.
- Dial the number in the List:
 - View Call Logs by pressing the Dial key.
 - View Name by pressing the Right soft key.
 - All the numbers in the lists can be directly dialed by pressing the Dial key.
- Press the Dial key to answer an incoming call. For other answer modes please refer to **User Profiles-Option-Customize-Answer Mode**. If you won't answer the call, press the End key or press **Reject** to send busy tones to the caller.

Call Menu

In the in-call mode, you can enter the call menu by pressing **Option**. Press **H-Free** to switch to the hand-free mode. Call menu can be seen only in the process of communication. The functions such as Call waiting, Call keeping, Multiparty require the network support.

- **Hold/Retrieve:** Hold or Retrieve the current call.
- **End:** End the call.
- **New Call:** Connect a third party.
- **Phone Book:** Enter the phone book.
- **Message:** Enter the message interface.
- **Mute:** Set On/Off to stop sending the local voice or resume.

- **DTMF:** Set On/Off to send or stop send DTMF.

Note: Some options can only appear in special cases. Options such as **Swap** will appear only when the ongoing call and the hang-on call coexist.

Function Menu

Usage and Structure of Function Menu

- Scrolling search function: Enter the function main menu by pressing Menu or the OK key in the standby mode. Press the Up/Down/Left/Right keys to select in menu.
- In the function menu, you can select or quit some menus by pressing the Left soft key or Right soft key according to the prompt displayed on the screen.

Call History

Missed Calls/ Dialed Calls/ Received Calls

You can view the missed calls, dialed calls, and received calls.

Delete Call Log

You can delete the call logs.

Call Time

You can view the call time.

Call Cost

The call cost depends on the **Price Per Unit**, which you have to enter the PIN2 to set first. For the exact cost please refer to the service provider.

User Profiles

You can select the profile in this menu. The profile options are: **General**, **Meeting**, **Outdoor** and **Silent**. The default settings for each individual profile are preset by the manufactory. You can change them in **Option-Customize** menu.

- **Tone Setup:** Set the tone for various conditions.
- **Volume:** Set ring tone, key tone, and speech volumes.
- **Alert Type:** Choose among four modes based on ring and vibration.
- **Ring Type:** Choose among Single, Repeat and Ascending.
- **Extra Tone:** Let the phone ring when Warning or Error occurs.
- **Answer Mode:** Any Key means to answer by pressing any key except the End key and the Right soft key.

Note: The Silent mode has no Customize menu.

File Manager

You can check all the folders in the phone, create new ones or rename, delete, or sort, etc. The pictures you take, the sounds or videos you record, and the files you download from the internet will be stored in these folders.

Note: When you select **Format**, the data will be lost, so please be careful with this function.

Settings

Phone Setup

- **Time and Date:** Date can be set from January 1st, 2000 to December 31st, 2030. Time can be set from 00:00 to 23:59. Set the time and date displayed format.
- **Schedule Power On/Off:** Enable or disable this function to automatically power on/off the phone at the set time.

- **Language:** Select the language for the display texts.
- **Display Characteristic:** Set a series of display Characteristics.
- **Speed Dial:** Set the speed dial keys and enable or disable this function.
- **Flight Mode:** Set the mode for a flight.
- **LCD Backlight:** Set the parameter for the backlight.
- **KeyBacklight:** Activate or deactivate the key backlight.

Call Setup

- **Call Waiting:** When enabled, the network will notify you of a new call if a new incoming call takes place during an ongoing conversation. Please contact the network service provider for detailed usage.
- **Call Divert:** This service enables you to divert some incoming calls to other preset numbers. Contact your service provider for details. You can set diverts in different conditions.
- **Call Barring:** Set to bar the outgoing calls or incoming calls.
- **Call Time Reminder:** This function enables a reminder several seconds after connected or every several seconds during a call, or you can select "Off" instead to turn it off.
- **Call Time Display:** Select On/Off to display the call time or not.
- **Auto Redial:** Select whether or not to auto redial when call failed.
- **IP Number:** You can edit three IP numbers and activate one. When you call a number, select IP call to automatically add the activated IP number before the phone number.

Network Setup

In this menu, you can select **Automatic/Manual** to select the network service provider according to requests. If you have selected a service provider manually, you have to manually select again or return to the Automatic option to select the service provider when you switch to the SIM card of another network. You can set preferred networks and add new ones or change priority.

The GPRS Connection can be set to **When Needed** or **Always**.

Security Setup

- **SIM Lock:** The SIM password (PIN code) can prevent your SIM card from illegal use. Select **On/Off** to enable or disable the SIM password protection.

Note: Three consecutive incorrect PIN code entries will lock the SIM card. Then, the PUK code is needed to unlock the SIM card. The PIN code and the PUK code may be provided to you together with the SIM card. If not, please contact with your network service provider. Please change it with your own private password as soon as possible.
- **Phone Lock:** Phone lock can prevent your mobile phone from unauthorized use. Select **On/Off** to enable or disable the handset lock protection.

Note: The default Phone lock code is 1122.
- **Fixed Dial:** You can enable or disable fix dialing to specified phone numbers only. You must enter your PIN2 code for authentication.
- **Change Password:** You can change PIN code, PIN2 code and Phone Lock Password.

Restore Factory Settings

Enter password to restore to the factory settings.

Messages

If the network supports and you have subscribed this service, you can use this function. Please contact your service provider for details.

SMS

Set a message service center number in **Message Settings-Profile Setting** before sending messages.

- **Write Message:** Create new SMS.
- **Inbox:** You can read the received messages. In the Message Body interface, you can press **Option** to make more operations.
- **Outbox:** If you select **Save and Send**, the successfully sent out SMS will be saved in Outbox. In the Message Body interface, you can press **Option** to make more operations.
- **Message Settings:** You can set some parameters according to the display.
 - ✧ **Profile Setting:** You can set up to 2 profiles. Set profile name, SMS center number, and valid period.
 - ✧ **Common Setting:** Set whether or not to activate delivery report. This needs network support. If it is set On, you can receive a report when your sent-out message is received by the opposite party. If Reply Path is set On, you have to pay for the messages sending and receiving.
 - ✧ **Memory Status:** View the memory status.
 - ✧ **Preferred Storage:** Select SIM or Phone.

Note: The SMS centers of some countries and regions do not support messages longer than one hundred and sixty English characters.

MMS

- **Write Message:** Create new MMS.
- **Inbox:** View the received MMS.
- **Outbox:** View the sent MMS.
- **Draft:** View the draft MMS.
- **Message Settings**
 - ✧ **Compose**
 - **Creation Mode:** If you select Restricted, the files you add to the MMS will be checked (whether the format is supported by the network, etc.) before sent out. If you select Free, they would not be checked.
 - **Auto Signature:** Select to automatically add the signature to your MMS. The content of signature could be edited in the line below.
 - ✧ **Send**
 - **Validity period:** Set the MMS validity period. The sent MMS will be stored in the network server for the receiver to retrieve in the validity period. When time is out or it has been retrieved, the MMS will be deleted from the server.
 - **Delivery report:** Set whether or not to receive a report when the MMS you sent is received by the opposite part (need network support).
 - **Read report:** Set whether or not to receive a report when the opposite part has read the MMS you sent (need network support).
 - **Priority:** Set the priority.
 - **Slide Timing:** Set the slide time. When there is more than one slide, it will automatically turn to the next slide when the previous slide has been displayed for the set slide time. When there is only one slide, the display will be stopped after the set time.
 - **Delivery time:** Set the delivery time.
 - ✧ **Retrieve**
 - **Home network:** Set to download the MMS automatically, manually, or reject to download when in home network.
 - **Roaming:** Set to download the MMS as in home network manually, or reject to download.

- **Read Report:** Select whether or not to send a read report.
- **Delivery Report:** Select whether or not to send a delivery report.
- ◇ **Server Profile**
You can set up to 10 profiles. For the content to fill in, please consult the network service provider.
- ◇ **Memory Status**
View the memory status.

Voice Mail Server

You can edit a server. Select **Connect** to check the voicemail box and listen to the voice message.

Broadcast Message

Set Receive Mode, Languages and Channel. Press **Read Message** to read the broadcast message.

Phone Book

The **Phone Book** menu is structured as follows:

- **Quick Search:** The list shown will be changed as you input each letter to match the input. Quick Search is only available for the first word of a name.
- **Search Entry:** Input a part of the name and then search. Remember to start with the first letter. The result is in alphabetical order. To get a more precise result, please input as complete as possible.
- **Add New Entry:** Add a new entry to the SIM card or the Phone.
- **Copy All:** Copy all the records from the SIM card to the Phone or from the Phone to the SIM card.
- **Delete:** Delete the records from SIM/Phone or one by one.
- **Caller Group:** There are five default groups which you could add members to. The groups could be renamed, and each group could have a respective ring tone. Only the names stored in the phone can be grouped.
- **Owner Number:** Set owner number.
- **Settings:** Check the memory status and set the preferred storage.

Toolkit

FM Radio

Listen to the FM radio. You have to plug in the earphone first.

Alarm

Your phone can be set up to five alarm clocks at the same time. Press **Edit** to edit an alarm. The Alarm can work in both Power On/Off modes.

Stopwatch

You can measure time and take split times or lap times, for example, in different sports.

Calendar

You can view the Calendar and press **Option** to add tasks to each day. The date can go from January 1, 1970 to December 31, 2030.

World Clock

The World Clock function provides time information on major worldwide cities.

Calculator

Press 0-9 Number keys to input numbers, and press the # key to input the decimal point.

Press the Up/Down/Left/Right keys to switch among different operations.

Press the Right soft key to clear last digit or results. Press the End key to exit the calculator. Press the Left soft

key [OK] or the OK key to get results.

Note: This calculator has limited accuracy and rounding errors may occur especially in long division.

Currency Converter

Input the Rate, press OK and input a figure, and then press OK to get the result.

Services

STK

This service needs the network service provider to provide. If neither SIM card nor the network service provider supports this service, this service will not be available. For more information, please consult the network service provider.

WAP

- **Homepage:** Press to go into your homepage.
- **Bookmarks:** Display the list of saved page.
- **Recent Pages:** Display the list of pages you recently visited.
- **Offline Pages:** Display the stored pages, which you could read offline.
- **Enter Address:** Go to a page by directly inputting the address.
- **Service Inbox:** Inbox of the service messages.
- **Settings:** Do the settings. For some of the settings, consult the network service provider.
 - ◇ **Edit Profile:** You can set up to 10 profiles. For the content to fill in, please consult the network service provider.
 - ◇ **Browser Options:**
 - **Timeout:** You can set timeout. If the timeout period elapsed prior to completion of the operation or the server is not responding, it will show "Connection Failed". During the timeout period, it will keep trying to connect until expired.
 - **Show Images:** Set whether or not to show the images.
 - ◇ **Enable Push:** You can set whether or not to receive the push messages.
 - ◇ **Clear Cache:** You can select Yes to clear cache.
 - ◇ **Clear Cookies:** You can select Yes to clear cookies.

Data Account

- **GSM Data:** Set GSM data account.
- **GPRS:** Set GPRS data account.

Games

There are two games: **Riches** and **Copter**. You can set the sound effect and vibration in **Game Setting**.

Text Input

Overview

Your mobile phone provides the following input methods: upper and lower case input, numeric input and predictive text input, punctuation mark or special characters input.

When you are in a field that allows characters to be input, you will notice the text input mode indicator in the upper left corner of the screen. Press the # key to switch among different input modes.

ABC and abc Mode

- Use the number keys from 2 to 9 to input your text.

- Press the key labeled with the required letter
 - Once for the first letter
 - Twice for the second letter
 - And so on
- To insert a space, press the 0 key once. To delete letters, press the Right soft key.
- Press the * key to open a list of special characters, use the Scroll keys to move through the list, and press the OK key to select a character.

123 Mode

- The 123 mode enables you to input numbers in a text message.
- Press the keys corresponding to the required digits.

eZi EN and eZi en Mode

- It is a predictive text input mode. You can input any letter with a single key press. The predictive text input is based on a built-in dictionary.
- To write a desired word, press the keys 2 to 9. Press each key only once for one letter. For example, to write “book”, press 2 for B, 6 for O twice, 5 for K.
- When you finish writing the word and it is correct, press the Right key or OK key to input in the screen. If the word is not correct, press the Up/Down keys to view other matching words found in the dictionary.

Note: In eZi EN and eZi en Mode, pressing the key 1 can only input a full stop.

Character Chart

Refer to the table below for more information on the characters available using the keys.

key	Corresponding Characters
1	1 and some common symbols
2	ABCabc2
3	DEFdef3
4	GHIghi4
5	JKLjkl5
6	MNOmno6
7	PQRSpqrs7
8	TUVtuv8
9	WXYZwxyz9
0	Space 0
* key	Press the * key to bring out symbols.
# key	Switch among different input modes.
Up/Down key	Roll the cursor up/down.
Left/Right key	Roll the cursor left/right.
Left soft key	Select
Right soft key	Clear the previous character. Hold the Clear key to clear all the characters.
End key	Exit

Troubleshooting

This section describes how to troubleshoot some problems when they occur to your phone. If you cannot deal with them, contact your local dealer.

1. “Enter PIN” is shown when the phone is switched on.

Input the PIN or input the new PIN if you have changed the code. The code can be set "off" if you do not want to input.

2. "Insert SIM" is shown when the phone is switched on.

Turn off your phone and make sure that you have inserted a valid SIM card.

3. "Enter Phone Lock" is shown when the phone is switched on.

Enter the handset lock code.

4. No key tone volume when pressing keys.

Check the keypad tone in User Profiles-Customize.

5. No incoming ring tone.

Check the ring tone and ring volume settings in User Profiles-Customize.

6. No alarm tone when the reminder time reaches.

Check the profile setting and the alarm ring setting in User Profiles-Customize.

7. A phone number cannot be dialed.

Check whether a call restriction is set to the number.

8. A phone call cannot be answered.

Check whether a call restriction is set to the number

9. Short message cannot be sent.

Check the SC Address in the Message Settings-Profile Setting.

10. Some menus related to voice setting cannot be used.

Check the User Profiles settings.