

ZTE BLADE 520

User Manual

LEGAL INFORMATION

Thank you for choosing this ZTE mobile device. In order to keep your device in its best condition, please read this manual and keep it for future reference.

Copyright

Copyright © 2016 ZTE CORPORATION

All rights reserved.

No part of this publication may be quoted, reproduced, translated or used in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation.

Notice

ZTE Corporation reserves the right to make modifications on print errors or update specifications in this guide without prior notice. This manual has been designed with the utmost care to ensure the accuracy of its content. However, all statements, information and recommendations contained therein do not constitute a warranty of any kind, either expressed or implied. We offer self-service for our smartphone users. Please visit the ZTE official website (at www.ztedevice.com) for more information on self-service and supported product models. Information on the website takes precedence.

Disclaimer

ZTE Corporation expressly disclaims any liability for faults

and damages caused by unauthorized modifications of the software.


Images and screenshots used in this manual may differ from the actual product. Content in this manual may differ from the actual product or software.

Trademarks

ZTE and the ZTE logos are trademarks of ZTE Corporation.

Google and Android are trademarks of Google, Inc.

The *Bluetooth*[®] trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such trademarks by ZTE Corporation is under license.

 microSDXC Logo is a trademark of SD-3C, LLC.

Other trademarks and trade names are the property of their respective owners

Version No.: R1.0

Edition Time: December 16, 2016

Contents

For Your Safety	8
General Safety	8
Distraction	9
Product Handling	10
Electrical Safety	13
Interference	14
Explosive Environments	16
Getting Started	17
Overview	17
Keys Explained.....	19
Starting up	20
Powering On/Off	26
Getting Around Your Phone	27
Phone Calls	30
Making Calls	30
Receiving Calls.....	31
Call settings	32
Contacts	33
Creating a Contact	34
Searching for a Contact.....	34
Messaging	35
Opening the Messaging Screen	35
Sending a Message.....	35













Message Settings	36
Connecting to Networks and Devices.....	37
Set Access Point Names	37
Turn Wi-Fi On and Connect to a Wi-Fi Network	37
Bluetooth.....	38
Tethering & portable hotspot	39
Browser	41
Opening the Browser	41
Using Multiple Browser Tabs	41
Downloading Files	42
Changing Browser Settings	42
Using Multimedia Apps	42
Taking Pictures with Your Camera	42
Recording Videos with Your Camcorder.....	43
Listening to Your FM Radio	44
Playing Your Music	44
Opening Your Gallery	44
Making Voice Memos	45
Using Your Google Applications.....	45
Gmail.....	46
Google Play™ Store	46
Other Applications.....	46
Clock.....	46
Mi-Moment.....	47







FileManager	47
Settings.....	47
Wi-Fi	48
Bluetooth	48
Wi-Fi hotspot	48
Airplane Mode	48
Enable 4G	49
Data Usage	49
VPN	49
USB Tethering.....	50
Bluetooth Tethering.....	50
Hotspot & Tethering Settings	50
ZTE Locker.....	50
Themes & Wallpapers	50
Display.....	51
Sound	51
Notifications	51
Navigation keys	51
Apps	52
Default Apps.....	52
Power Manager	52
Security	52
Accounts.....	53
Languages & Input	53
Date & Time	53
Backup and Reset.....	53

Memory	54
Storage	54
Connect to PC.....	54
Scheduled Power On/Off	55
Location	55
Google	56
Accessibility	56
Printing.....	56
System Update	56
About Phone	57

For Your Safety

General Safety

	Don't make or receive handheld calls while driving. And never text while driving.		Don't use at petrol stations.
	Keep your phone at least 10 mm away from your body while making calls.		Your phone may produce a bright or flashing light.
	Small parts may cause a choking.		Don't dispose of your phone in fire.
	Your phone can produce a loud sound.		Avoid contacting with anything magnetic.
	Keep away from pacemakers and other electronic medical devices.		To prevent possible hearing damage, do not listen at high volume levels for long periods.
	Avoid extreme temperatures.		Switch off when asked to in hospitals and medical facilities.

	Avoid contacting with liquids. Keep your phone dry.		Switch off when told to in aircrafts and airports.
	Don't take your phone apart.		Switch off when near explosive materials or liquids.
	Only use approved accessories.		Don't rely on your phone for emergency communications.

Distraction

Driving

Full attention must be given to driving at all times in order to reduce the risk of an accident. Using a phone while driving (even with a hands free kit) can cause distraction and lead to an accident. You must comply with local laws and regulations restricting the use of wireless devices while driving.

Operating Machinery

Full attention must be given to operating the machinery in order to reduce the risk of an accident.

Product Handling

General Statement on Handling and Use

You alone are responsible for how you use your phone and any consequences of its use.

You must always switch off your phone wherever the use of a phone is prohibited. Use of your phone is subject to safety measures designed to protect users and their environment.

- Always treat your phone and its accessories with care and keep it in a clean and dust-free place.
- Do not expose your phone or its accessories to open flames or lit tobacco products.
- Do not expose your phone or its accessories to liquid, moisture or high humidity.
- Do not drop, throw or try to bend your phone or its accessories.
- Do not use harsh chemicals, cleaning solvents, or aerosols to clean the device or its accessories.
- Do not paint your phone or its accessories.
- Do not attempt to disassemble your phone or its accessories, only authorized personnel can do so.
- Do not expose your phone or its accessories to extreme temperatures, minimum - [20] and maximum + [60] degrees Celsius.

- The phone's normal operating temperature is 0°C ~ 45°C .In order to ensure the normal phone functions, do not use this phone outside the temperature range.
- Please check local regulations for disposal of electronic products.
- Do not carry your phone in your back pocket as it could break when you sit down.
- Use careful with the earphone maybe possible excessive sound pressure from earphones and headphones can cause hearing loss.

Small Children

Do not leave your phone and its accessories within the reach of small children or allow them to play with it.

They could hurt themselves or others, or could accidentally damage the phone.

Your phone contains small parts with sharp edges that may cause an injury or may become detached and create a choking hazard.

Demagnetization

To avoid the risk of demagnetization, do not allow electronic devices or magnetic media close to your phone for a long time.

Electrostatic Discharge (ESD)

Do not touch the nano-SIM card's metal connectors.

Antenna

Do not touch the antenna unnecessarily.

Normal Use Position

When placing or receiving a phone call, hold your phone to your ear, with the bottom towards your mouth.

Air Bags

Do not place a phone in the area over an air bag or in the air bag deployment area.

Store the phone safely before driving your vehicle.

Seizures/ Blackouts

The phone can produce a bright or flashing light.

Repetitive Motion Injuries

To minimize the risk of RSI when texting or playing games with your phone:

- Do not grip the phone too tightly.
- Press the buttons lightly.
- Use the special features which are designed to minimize the times of pressing buttons, such as Message

Templates and Predictive Text.

- Take lots of breaks to stretch and relax.

Emergency Calls

This phone, like any wireless phone, operates using radio signals, which cannot guarantee connection in all conditions. Therefore, you must never rely solely on any wireless phone for emergency communications.

Loud Noise

This phone is capable of producing loud noises, which may damage your hearing. Turn down the volume before using headphones, Bluetooth stereo headsets or other audio devices.

Phone Heating

Your phone may become warm during charging and during normal use.

Electrical Safety

Accessories

Use only approved accessories.

Do not connect with incompatible products or accessories.

Take care not to touch or allow metal objects, such as coins or key rings, to contact or short-circuit in the battery

terminals.

Connection to a Car

Seek professional advice when connecting a phone interface to the vehicle electrical system.

Faulty and Damaged Products

Do not attempt to disassemble the phone or its accessory.

Only qualified personnel can service or repair the phone or its accessory.

If your phone or its accessory has been submerged in water, punctured, or subjected to a severe fall, do not use it until you have taken it to be checked at an authorized service centre.

Interference

General Statement on Interface

Care must be taken when using the phone in close proximity to personal medical devices, such as pacemakers and hearing aids.

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 15 cm be maintained between a mobile phone and a pacemaker to avoid potential interference with the

pacemaker. To achieve this, use the phone on the opposite ear to your pacemaker and do not carry it in a breast pocket.

Hearing Aids

People with hearing aids or other cochlear implants may experience interfering noises when using wireless devices or when one is nearby.

The level of interference will depend on the type of hearing device and the distance from the interference source, increasing the separation between them may reduce the interference. You may also consult your hearing aid manufacturer to discuss alternatives.

Medical Devices

Please consult your doctor and the device manufacturer to determine if operation of your phone may interfere with the operation of your medical device.

Hospitals

Switch off your wireless device when requested to do so in hospitals, clinics or health care facilities. These requests are designed to prevent possible interference with sensitive medical equipment.

Aircraft

Switch off your wireless device whenever you are instructed to do so by airport or airline staff.

Consult the airline staff about the use of wireless devices on board the aircraft. If your device offers a 'flight mode', this must be enabled prior to boarding an aircraft.

Interference in Cars

Please note that because of possible interference to electronic equipment, some vehicle manufacturers forbid the use of mobile phones in their vehicles unless a hands-free kit with an external antenna is included in the installation.

Explosive Environments

Petrol Stations and Explosive Atmospheres

In locations with potentially explosive atmospheres, obey all posted signs to turn off wireless devices such as your phone or other radio equipment.


Areas with potentially explosive atmospheres include fuelling areas, below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust, or metal powders.


Blasting Caps and Areas

Power off your mobile phone or wireless device when in a blasting area or in areas posted power off "two-way radios" or "electronic devices" to avoid interfering with blasting operations.

Getting Started


Overview





Keys Explained

Key	Function
Power Key	<ul style="list-style-type: none">• Press and hold to turn on or off airplane mode, restart, select phone modes, or power off.• Press to turn off or on the screen display.
Home Key	<ul style="list-style-type: none">• Touch to return to the home screen from any application or screen.• Touch and hold to use Google Search.
Back Key	Touch to go to the previous screen.
Recent apps Key	Touch to see recently used apps.
Volume Key	Press or hold either end of the key to turn the volume up or down.

 **NOTE:**

The positions of the **Recent apps** key and the **Back** key are interchangeable through **Settings > Featured > Navigation keys**.

Starting up

Installing the nano-SIM Card and the microSDXC™ Card


The nano-SIM card can be installed or removed while the phone is turned on. Power off your phone before removing or replacing the battery.

The microSDXC card (optional, not included) can be installed or removed while the phone is turned on. You need to unmount the microSDXC card before removing it.


WARNING!

To avoid damage to the phone, do not use any other kind of SIM cards, or any non-standard nano-SIM card cut from a SIM card. You can get a standard nano-SIM card from your service provider.


1. Place your finger in the slot at the bottom of the back cover to lift and remove the cover.




2. Hold the nano-SIM card with their cut corner oriented as shown and slip it into the card holder.




3. Hold your microSDXC card with the metal contacts facing down and slide it into the microSDXC card slot.



4. Insert the battery by aligning the golden contacts on the battery and those in the battery compartment. Gently push down on the battery until it clicks into place.



5. Replace the back cover.
 - ① Align the back cover with the bottom of the phone.
 - ② Press the cover back into place.



Charging the Battery


Your phone's battery should have enough power for the phone to turn on, find a signal, and make a few calls. You should fully charge the battery as soon as possible.



If the battery is low, there will be a pop-up message on the screen. As you charge your phone, the lock screen will show you the exact battery level on the status bar.

WARNING!

Use only ZTE-approved chargers and cables. The use of unapproved accessories could damage your phone or cause the battery to explode.

1. Connect the adapter to the charging jack. Ensure that the adapter is inserted with the correct orientation. Do not force the connector into the charging jack.



2. Connect the charger to a standard AC power outlet. If the phone is on, you'll see a charging icon, such as  or , appear on the status bar.
3. Disconnect the charger when the battery is fully charged.

 **NOTE:**

If the battery is extremely low, you may be unable to power on the phone even when it is being charged. In this case, try again after charging the phone for at least 20 minutes.

Contact the customer service if you still cannot power on the phone after prolonged charging.

Powering On/Off


- Press and hold the **Power** key to turn on your phone.
- To switch it off, hold **Power** key to open the options menu and touch **Shut down**.

Setting Up for the First Time


When you first power on your phone after you purchase it or reset it to factory settings, you need to do some settings before using it.


Touch the language field to select the language you want to use and then touch **GET SATRTED**. Then follow the prompts to set up Wi-Fi, Google services, add fingerprint and other options.

Waking Up Your Phone

1. Press the **Power** key to turn the screen on.
2. Drag  towards .

- or -

You can drag  towards any direction to access the application shortcuts.

 **NOTES:**

- You can pull out the starts on the left for a quick view or action when the screen is turned on.
- If you have set an unlock pattern, PIN or complex password for your phone, you'll need to draw the pattern or enter the PIN/password to unlock your screen.

Getting Around Your Phone

Touch Control

You can use finger gestures to control your phone. The controls on your touch-screen change dynamically depending on the tasks you're performing.

- Touch the buttons, icons, or applications to select items or to open applications.
- Flick the screen to scroll up, down, left or right.
- Hold and drag to move particular items across the screen.
- Double-tap the screen to zoom in/out an image. Pinch on with two fingers to zoom in/out a web page.

Home Screen

The home screen is the starting point for your phone's applications, functions, and menus. You can customize your home screen by adding folders, widgets, and more.

Extended Home Screen

Your home screen is extendable, providing more space for

shortcuts, folders, widgets, and more. Simply swipe left or right on the screen to see the extended panels.

Choosing Your Wallpaper

You can set the wallpaper for the home screen and lock screen.


1. Touch the **Home** key and slide on the screen to select **Settings > Themes & wallpapers > Wallpapers**.
2. Touch **Home screen wallpaper** or **Lock screen wallpaper** and select a built-in static wallpaper, or touch **Gallery** to select a picture, crop it, and use it as the wallpaper.

NOTE:

Other way to set the home screen wallpaper and the lock screen wallpaper:

Touch and hold an empty area of the home screen and select **Customize launcher > Wallpaper** tab. Then select a built-in image or an image from your gallery. You can also touch **Camera** to take a photo as the wallpaper.

Removing Items from Your Home Screen















1. Touch and hold the item you want to delete.
2. Drag it to  to delete it.
3. If the item is an application, touch **OK** to uninstall it.

NOTE:

Some preinstalled apps cannot be uninstalled.

Status and Notification Icons

Your phone will tell you exactly what's going on by showing you simple icons. Here's what they mean.

	USB tethering on		Missed call
	Airplane mode		Bluetooth icon
	New Wi-Fi network detected		New message
	Battery charge		Connected to a Wi-Fi® network
	Song playing		Portable Wi-Fi hotspot is on
	Alarm set		Vibration on
	Signal strength		No signal

Open/Close the Notification Panel

Notifications report the arrival of new messages, calendar events, and alarms, as well as ongoing events, such as when you've configured your phone as a Wi-Fi hotspot. You can open the notification panel to view the details of notifications.




- To open the notification panel, swipe your finger down from the top of the screen.
- To close the notification panel, swipe your finger up on the screen or touch the **Back** key.

Phone Calls

Making Calls

You can place calls from the Phone app, the People app, or other apps or widgets that display contact information. Wherever you see a phone number, you can usually touch it to dial.


Calling from the Phone

1. Touch the **Home** key > .
2. Enter the phone number with the dialpad. Touch  to delete incorrect digits.
3. Touch  below the keypad to dial.


NOTE:

To make an international call, touch and hold the 0 key to enter the plus (+) symbol. Next, enter the country code, followed by the city/area code and then the phone number.

Calling from Your Contacts

1. Touch the **Home** key and slide on the screen to select **Contacts**.
2. Touch  next to a contact to place the call.

Calling from Your Call History


1. Touch the **Home** key >  > **Phone**.
2. Touch a listing to call back.

NOTE:

You can touch **All calls**, **Incoming calls**, **Outgoing calls**, **Missed calls**, or **Rejected calls** to filter the records by call type.


Calling from a Text Message

If a text message contains a phone number that you want to call, you can make the call while viewing the text message.


1. Touch the **Home** key > .
2. Touch the conversation and then find the message that contains the phone number you need.
3. Touch the number and touch **Call**.

Receiving Calls

Answering a Call



When you receive a phone call, slide  down to answer the call.

Rejecting a Call



When you receive a phone call, slide  up to reject the call.

Muting a Call

During a call, you can mute your microphone so that the person you are speaking to cannot hear you, but you can still hear them.

Touch  to turn your microphone off. To turn your microphone back on, touch  again.

Turning the Speakerphone On/Off

Touch  during a call to turn the speakerphone on. Touch  again to turn off the speakerphone.

Ending a Call

Touch  to finish a call.

Call settings


Touch the **Home** key >  >  > **Call settings**.

- **Speed Dials:** Touch and hold the 1 ~ 9 keys from the dialer to call the corresponding speed dial number.
- **Auto-Answer:** Configure your phone to answer calls automatically when you are not in a call.



- **Voicemail:** Touch to configure voicemail settings.
- **Call Barring Settings:** Call barring feature allows you to forbid certain types of calls from your phone.
- **Fixed Dialing Numbers:** Fixed Dialing Numbers (FDN) allows you to restrict outgoing calls to a limited set of phone numbers.
- **Call forwarding:** Call forwarding feature allows you to forward your incoming calls to another phone number.
- **Additional settings:** Touch **Caller ID** to choose whether your number is displayed when someone receives your outgoing call. Or check **Call waiting** to get notified of incoming calls during a call.
- **Set operations for a call not answered:** Enable operations for a call not answered to send a message or call another number after the call ends.
- **Block calls that ring just once:** Configure your phone to block calls that ring just once.

Contacts


You can add contacts on your phone and synchronize them with the contacts in your Google account or other accounts that support contact syncing.

To see your contacts, touch the **Home** key and slide on the screen to select .

Creating a Contact

1. Press the **Home** key and slide on the screen to select .
2. Touch  to add a new contact.
3. Touch the account field near the top of the screen to choose where to save the contact. You can save the contact on the phone, a nano-SIM card, or a web account you have added on the phone.
4. Enter the contact name, phone numbers, email addresses, and other information.
5. Touch **Save**.

Searching for a Contact

1. Press the **Home** key and slide on the screen to select .
2. Enter the contact name or any information the contact has to search for it at the top.
The contacts matched will be listed.




Messaging

You can use Messaging to exchange text messages (SMS) and multimedia messages (MMS).


Opening the Messaging Screen




Touch the **Home** key > .

The Messaging screen opens, where you can create a new message, search for messages, delete messages, or open an ongoing message thread.

- Touch  to write a new text or multimedia message.
- Touch  to search for a message using keywords.
- Touch  to select message threads for deletion.
- Touch an existing message thread to open the conversation you've had with a certain number.

Sending a Message

1. On the **Messages** screen, touch  at the bottom.
2. Add recipients by one of the following ways.
 - ▶ Touch the **To** field and manually enter the recipient's number or the contact name. If the phone presents a few suggestions, touch the one you want to add.

- ▶ Select recipients from your contacts or call log by touching .
- 3. Touch the **Enter a message** field and enter the message text.
- 4. If you want to send a multimedia message, touch  to add a subject or attach a file to the message.
- 5. Touch .



NOTE:


You can also include email addresses as recipients for a multimedia message.



NOTE:

Do not add a message subject or any attachment if you want to send a text message. Otherwise you may be charged for a multimedia message.



Message Settings

Touch  > **Settings** in the Messages screen to change the messaging settings.


Connecting to Networks and Devices

Set Access Point Names

To connect to the Internet you can use the default Access Point Names (APN). And if you want to add a new APN, please contact the service provider to get the necessary information.

1. Touch the **Home** key and slide on the screen to select **Settings > Mobile networks**.
2. Touch **Access Point Names >** .
3. Touch each item to enter the information you get from your service provider.
4. Touch  **> Save** to complete.

 **NOTE:**

To set the APN to default settings, touch  **> Reset to default**.

Turn Wi-Fi On and Connect to a Wi-Fi Network

1. Touch the **Home** key and slide on the screen to select **Settings > Wi-Fi**.

2. Slide the switch next to **Wi-Fi** to turn on Wi-Fi.
3. Touch a network name to connect to it.
4. If the network is secured, enter the password and touch **Connect**.


 **NOTE:**

Your phone automatically connects to previously used Wi-Fi networks when they are in range.

Bluetooth

Bluetooth® is a short-range wireless communication technology. Phones or other devices with Bluetooth capabilities can exchange information wirelessly within a distance of about 10 meters (32.8 feet). The Bluetooth devices must be paired before the communication is performed.

1. Touch the **Home** key and slide on the screen to select **Settings > Bluetooth**.
2. Slide the switch next to **Bluetooth** to turn on or off Bluetooth.

When Bluetooth is on, the  icon appears in the status bar.

Tethering & portable hotspot

You can share your phone's data capabilities through tethering or by activating the mobile hotspot feature to create a portable Wi-Fi hotspot.

Share Your Mobile Data Connection via USB

You cannot transfer files between your phone and your computer via USB while the phone is USB tethered.

1. Connect your phone to your computer with a USB cable.
2. Touch the **Home** key slide on the screen to select **Settings > More**.
3. Switch on **USB tethering**. A new network connection will be created on your computer.

NOTE:

To stop sharing your data connection, switch off **USB tethering** or disconnect the USB cable.

Share Your Mobile Data Connection via Bluetooth

1. Pair your phone with your computer via Bluetooth.
2. Configure your computer to obtain its network connection via Bluetooth. For more information, please see your computer's documents.
3. Touch the **Home** key slide on the screen to select **Settings > More**.
4. Switch on **Bluetooth tethering**. Your computer is now

sharing your phone's data connection.

 **NOTE:**

To stop sharing your data connection, switch off **Bluetooth tethering**.

Share Your Mobile Data Connection as a Wi-Fi Hotspot

When the portable Wi-Fi hotspot feature is enabled, you cannot use your phone's Wi-Fi capability to access the Internet. You still remain connected to the Internet via your mobile data network.

1. Touch the **Home** key slide on the screen to select **Settings > Wi-Fi hotspot**.
2. Switch on **Wi-Fi hotspot**.
After a moment, the phone starts broadcasting its Wi-Fi network name (SSID).
3. On another device, locate your phone via Wi-Fi and connect with it to start using the phone's mobile data.

 **NOTE:**

To stop sharing your data connection, switch off **Wi-Fi hotspot**.


Browser

Use **Browser** to view web pages and search for information.

Opening the Browser

Touch the **Home** key >  to launch the web browser.


You can also open the browser by touching a web link - for example, in an email or a text message.

1. Open the **Browser** app.
2. Touch the address box.
3. Enter the address (URL) of a web page or enter terms you want to search for.
4. Touch a URL or search suggestion or touch  on the keyboard to open the web page or search results.


Using Multiple Browser Tabs

You can open several web pages at the same time (one page in each tab) and switch between them freely.


To open a new browser tab:

Touch  > **New window**. A new browser tab opens.

To switch between tabs:

1. Touch . Titles of opened tabs appear as a list.
2. Touch the title you want to open.

 **NOTE:**


Swipe a title horizontally or touch its  to close the tab.

Downloading Files

1. Touch and hold an image or a link to a file or to another web page.
 2. In the menu that opens, touch **Save image** or **Save link**.
- The downloaded files are saved to your phone. You can view or open them in the **Downloads** app.


Changing Browser Settings


You can configure a number of settings to customize the way you browse the web, including several that you can use to control your privacy.

To open the browser settings screen, touch  > **Settings**.


Using Multimedia Apps

Taking Pictures with Your Camera



1. Touch the **Home** key and slide on the screen to touch .
2. Aim the camera at the subject and make any necessary adjustment.

 **NOTE:**

You can spread or pinch on the screen to zoom in or out before taking pictures.


3. Touch the area where you want the camera to focus, or leave the camera to autofocus on the center of the image.
4. Lightly touch . The **Volume** key can also be used to take a photo

Recording Videos with Your Camcorder

1. Touch the **Home** key and slide on the screen to touch .
2. Touch .
3. Aim the camera at the subject. You can touch any area on the screen that you want the camcorder to focus on before and during recording.

 **NOTE:**

You can spread or pinch on the screen to zoom in or out before and during recording.

4. Touch  to start recording a video.

 **NOTE:**



While the recording is in progress, touch  to pause the recording, or touch  to save the frame as a separate

photo.

5. Touch  to stop recording.

Listening to Your FM Radio

With the FM Radio, you can search for radio channels, listen to them, and collect them to your phone. Note that the quality of the radio broadcast depends on the coverage of the radio station in your area. The wired headset works as an antenna, so always connect the headset when using the radio.

1. Plug your headset into your phone.
2. Touch the **Home** key and slide on the screen to select **FM Radio**.

Playing Your Music

Music supports a wide variety of audio formats, so it can play music you purchase from online stores, music you copy from your CD collection, and so on.






1. Touch the **Home** key and slide on the screen to touch **Music > All songs** to see the music library.
2. Touch a song in any list.

Opening Your Gallery

Touch the **Home** key and slide on the screen to select **Gallery** to view albums of your pictures and videos.

Making Voice Memos

Recorder enables you to record voice memos and listen to them whenever you like.

1. Press the **Home** key and slide on the screen to select **Recorder**.
2. Touch  to select audio format.
3. Touch  to start recording. During recording, you can do the following:
 - ▶ Touch  /  to pause or continue the recording.
 - ▶ Touch  to add time tags to the recording.
4. Touch **Save** to stop recording.
5. Edit the file name and touch **OK** to save the recording.

If you don't want to save the memo after recording it, touch **Cancel** to delete it.

Using Your Google Applications


Signing in to your Google Account lets you synchronize Gmail, Calendar, and Contacts between your phone and the web. And if you don't have an account, you can easily create one.

Gmail

Gmail is a web-based email service that's configured when you sign in to your Google account. Depending on your synchronization settings, the Gmail on your phone can be automatically synchronized with your Gmail account on the web. This is how to enter Gmail:

To open **Gmail** by touching the **Home** key > **Google**> **Gmail**.

Google Play™ Store

Touch the **Home** key > . You can buy or rent music, books, movies, apps, and download them to your phone.

NOTE:

The content you can access in Google Play Store depends on your region and your service provider.

Other Applications




Clock

Touch the **Home** key and slide on the screen to select **Clock**.

The **Clock** app allows you to check local time in places around the world, set alarms, and use timers.

Mi-Moment

Touch the **Home** key and slide on the screen to select **Mi-Moment** to save and view your text notes.

- Touch  to create a new note. Then enter your text and touch **SAVE**.
- Touch a note to view its entire contents. Touch  or  to edit, delete, share, export, lock, move it to folder, or view its details.

FileManager

Quickly access all of your images, videos, audio clips, and other types of files on your phone storage.

Touch the **Home** key and slide on the screen to select **FileManager**. You can touch a file category to find the file you need, or touch **Phone**, **SD Card**, or **External devices** to browse folders and files on the phone storage, the microSDXC card, or the connected OTG device.

Settings

The **Settings** app contains most of the tools for customizing and configuring your phone.

Wi-Fi

Touch the **Home** key and slide on the screen to select **Settings > Wi-Fi**. You can turn Wi-Fi on or off and configure your Wi-Fi connections.

Bluetooth

Touch the **Home** key and slide on the screen to select **Settings > Bluetooth**. You can turn Bluetooth on or off and configure your Bluetooth connections.

Wi-Fi hotspot

Touch the **Home** key and slide on the screen to select **Settings > Wi-Fi hotspot** to share your phone's mobile data connection with PCs or other devices via Wi-Fi.

Airplane Mode

Touch the **Home** key and slide on the screen to select **Settings > More**, and then slide the switch beside **Airplane mode** to turn airplane mode on or off. All the phone's radios that transmit voice or data are turned off when airplane mode is on.

Enable 4G

Touch the **Home** key and slide on the screen to select **Setting > More**, and then slide the switch beside **Enable 4G** to connect to 4G LTE network.

Data Usage

Touch the **Home** key and slide on the screen to select **Settings > More > Data usage** to manage mobile data use. Touch the **Cellular data** switch to turn on or off mobile data.

Touch **Cellular data usage** to check how much data has been used during the time cycle you set, set mobile data limit and warning, see what apps have been using mobile data, or restrict background data for individual apps.

NOTE:

The data usage is measured by your phone, and your carrier's data usage accounting may differ.

VPN

Touch the **Home** key and slide on the screen to select **Settings > More > VPN** to set up and connect to virtual private networks.

USB Tethering

Touch the **Home** key and slide on the screen to select **Settings > More > USB Tethering** to share your phone's mobile data connection with PCs or other devices via USB.

Bluetooth Tethering

Touch the **Home** key and slide on the screen to select **Settings > More > Bluetooth Tethering** to share your phone's mobile data connection with PCs or other devices via Bluetooth.

Hotspot & Tethering Settings

Touch the **Home** key and slide on the screen to select **Settings > More > Hotspot & tethering settings** to configure hotspot and tethering settings.

ZTE Locker

Touch the **Home** key and slide on the screen to select **Settings > ZTE Locker**. You can turn on or off ZTE locker and configure the options for lock screen settings.

Themes & Wallpapers

Touch the **Home** key and slide on the screen to select **Settings > Themes & wallpapers**. You can select a different

theme for the phone display, or change the home/lock screen wallpaper.

Display

Touch the **Home** key and slide on the screen to select **Settings > Display** to configure the display options.

Sound

Touch the **Home** key and slide on the screen to select **Settings > Sound**. You can adjust different types of volume, toggle sound, vibration and mute, set up ringtone and notification sound, or select touch sounds.

Notifications

Touch the **Home** key and slide on the screen to select **Settings > Notifications** to control the display of notifications.

Navigation keys

Touch the **Home** key and slide on the screen to select **Settings > Featured > Navigation keys**. You can exchange the location of the **Recent apps** key and the **Back** key.

Apps

Touch the **Home** key and slide on the screen to select **Settings > Apps** to see apps installed on your phone and manage them.

Default Apps

Touch the **Home** key and slide on the screen to select **Settings > Default apps** to set the default application for certain operation. For example, you can set Email or Gmail as the default email app. Touch **⋮ > Restore defaults** to return to the default settings.

Power Manager

Touch the **Home** key and slide on the screen to select **Settings > Power manager** to view the battery level, check what has been using the battery, and enable different battery saving modes.

Security

Touch the **Home** key and slide on the screen to select **Settings > Security** to configure options that help keep your phone and data safe.

Accounts

Touch the **Home** key and slide on the screen to select **Settings > Accounts** to manage your web accounts and synchronization. Touch **Add account** to sign in to or create accounts on your phone.

Touch an account type to see that type of accounts you have added and adjust the accounts settings.

Languages & Input

Touch the **Home** key and slide on the screen to select **Settings > Advanced settings > Languages & input** to configure options related to system language, input methods, speech input and output as well as mouse/trackpad input.

Date & Time

Touch the **Home** key and slide on the screen to select **Settings > Advanced settings > Date & time** to set date, time, time zone, time format and more.

Backup and Reset

Press the **Home** key, slide on the screen and touch **Settings > Advanced settings > Backup & reset** to manage data backup and restoration options, and to reset the network setting or the phone to factory status.

Memory

Touch the **Home** key and slide on the screen to select **Settings > Advanced settings > Memory** to monitor the average memory use and performance of your phone. You can also check which apps use the most memory.

Storage

Touch the **Home** key and slide on the screen to select **Settings > Advanced settings > Storage** to view the memory information of the internal phone storage and the microSDXC card.

Touch **Phone memory** to get a detailed breakdown of space usage by type. Touch a data type to see more information or delete the files you do not need.

Connect to PC

Touch the **Home** key and slide on the screen to select **Settings > Advanced settings > Connect to PC** to select your USB connection type between your phone and PC.

Scheduled Power On/Off

Touch the **Home** key and slide on the screen to select **Settings > Advanced settings > Scheduled power on/off** to set the day and time when the phone automatically powers on or off. You can also touch the switches on the right to turn the features on or off.

Location

Touch the **Home** key and slide on the screen to select **Settings > Advanced settings > Location** to manage location services, which help your phone and apps determine your location. To use location-related applications, such as finding your location on Google Maps, you must have location services turned on on your phone.

1. Slide the switch at the top to turn location services on or off.
2. When location is enabled, touch **Mode** to select location sources you want to use.

In the **Location** menu, touch **Google Location History** to configure Google location options.

Google

Touch the **Home** key and slide on the screen to select **Settings > Advanced settings > Google** to easily manage settings for Google apps and features. You can set the options for Google account and services.

Accessibility

Touch the **Home** key and slide on the screen to select **Settings > Advanced settings > Accessibility** to configure accessibility plug-ins and services on your phone, such as using **Color inversion** or **High contrast text** for users with sight problems.

Printing

Touch the **Home** key and slide on the screen to select **Settings > Advanced settings > Printing** to manage Google Cloud Print service or other printer plug-ins installed from the Google Play Store or your printer manufacturer.

System Update

Touch the **Home** key and slide on the screen to select **Settings > System Update** to check, download and install system updates.

About Phone

Touch the **Home** key and slide on the screen to select **Settings > About phone** to view important phone information and legal information. You can also touch **My phone name** to give your phone a name for easy identification when others want to connect to your phone via Bluetooth or Wi-Fi hotspot.

FCC RF Exposure Information (SAR)

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the United States.

During SAR testing, this device was set to transmit at its highest certified power level in all tested frequency bands, and placed in positions that simulate RF exposure in usage against the head with no separation, and near the body with the separation of 10 mm. Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach

the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

The exposure standard for wireless devices employing a unit of measurement is known as the Specific Absorption Rate, or SAR.

The SAR limit set by the FCC is 1.6W/kg. This device is complied with SAR for general population /uncontrolled exposure limits in ANSI/IEEE C95.1-1992 and had been tested in accordance with the measurement methods and procedures specified in IEEE1528.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching on

FCC ID:SRQ-BLADEA520

For this device, the highest reported SAR value for usage against the head is 0.65 W/kg, for usage near the body is 1.18 W/kg.

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirements.

SAR compliance for body-worn operation is based on a separation distance of 10 mm between the unit and the human body. Carry this device at least 10 mm away from your body to ensure RF exposure level compliant or lower to the reported level. To support bodyworn operation, choose the belt clips or holsters, which do not contain metallic components, to maintain a separation of 10 mm between this device and your body.

RF exposure compliance with any body-worn accessory, which contains metal, was not tested and certified, and use such body-worn accessory should be avoided.

FCC Regulations

This mobile phone complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This mobile phone has been tested and found to comply with

the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.