

APPENDIX C FTP FIRMWARE UPGRADE

Introduction

This appendix provides reader firmware update information on using the web-based **Administrator Console**. The following methods are available to update the firmware on the FX7500 reader.

- Update using a USB drive.
- File-based update that allows uploading the firmware files from the PC (or a network location) to the reader and running the update.
- FTP / FTPS / SCP server-based update.

Use this procedure to update the following software components:

- uboot
- OS
- Reader Server Application (includes Radio API and Radio firmware)

Prerequisites

The following items are required to perform the update:

- Reader with power supply or POE connection
- Laptop (or other host computer)
- An Ethernet cable
- An FTP server
- Current firmware file examples:
 - OSUpdate.elf
 - response.txt
 - u-boot_X.X.X.X.bin (uBoot, X.X.X.X is a filename version)
 - ulmage_ X.X.X.X (OS, X.X.X.X is a filename variable)

- `rootfs_ X.X.X.X.jffs2` (Root FileSystem, `X.X.X.X` is a filename variable)
- `platform_ X.X.X.X.tar.gz` (Platform partition, `X.X.X.X` is a filename variable)

Refer to the release notes to determine which files were updated; not all of the files are updated in every release.

Failsafe Update

FX7500 provides true failsafe firmware update. Each partition (such as OS and platform) has an active and backup partition.

The firmware update process always writes the new images to the backup partition. This ensures that any power or network outages in the middle of firmware update does not prevent the reader from being operational. In the case of a firmware update failure, the power LED on the reader lights red.

Update Phases

The firmware update takes place in three phases:

- **Phase 1** - The reader application retrieves the **response.txt** and **OSUpdate.elf** files from the ftp server.
- **Phase 2** - The reader application shuts down and the **OSUpdate** starts. The files referenced in the **response.txt** file are retrieved from the FTP server and written to flash.
- **Phase 3** - The reader resets after all partitions update successfully. It may also update the RFID firmware if it detects a different version in the platform partition.

A typical entry in the **Response.txt** is:

```
;platform partition  
-t5 -fplatform_1.1.15.0.tar.gz -s8004561 -u8130879
```

✓ **NOTE** The Application Server, Radio API, and Radio firmware code all reside in the **Platform** partition.

The **-t** parameter is the file type, **-f** is the name of the file, and **-s** the size. Ensure the file size is correct. ";" comments out the rest of the line.

Updating FX7500 Reader Software

Verifying Firmware Version

To verify that the FX7500 reader firmware is outdated:

1. Log into the reader. In the **User Login** window, enter **admin** in the **User Name:** field and enter **change** in the **Password:** field.




Figure C-1 User Login Window

2. Select **Firmware** on the left side panel to verify that the current version of reader software is outdated, e.g., 1.1.43.




Figure C-2 Firmware Version Window

Updating Methods

Download the reader update files from <http://www.motorolasolutions.com/support>, then use one of three methods to update the reader software to a later version, e.g., 1.1.45.0 or higher:

- *Update Using a USB Drive (Recommended)*
- *File-Based Update on page C-6*
- *FTP-Based Update on page C-8*

Update Using a USB Drive (Recommended)

1. Copy all reader update files into the root folder of the USB drive.





Figure C-3 USB Drive Root Folder

2. Insert the USB drive into the USB host port of the FX7500 RFID reader.



New Pic with USB Host Port to Come

Figure C-4 USB Host Port Window

The reader starts the update process in 5-7 seconds, and indicates progress as follows:

- The reader continuously blinks the Power LED red.
- The reader blinks all 4 LEDs orange once.
- The reader Power LED remains steady orange.
- The reader Power LED settles to a steady green to indicate that the update is complete.




Figure C-5 *Reader LEDs*

New Pic with LED Labels to Come

File-Based Update

1. Copy all reader update files into any folder on a host computer.




Figure C-6 Host Computer Folder

2. Log into the reader and navigate to the **Firmware Update** page.




Figure C-7 Firmware Update Window

3. Select **File based Upload**.

- Click on **Browse** and navigate to the folder that contains the firmware update files.





Figure C-8 *Browsing Update Files*

- Select **response.txt** and click **Open**.
- Click **Start Update**. The reader starts the update process and displays the update status as follows:
 - The reader continuously blinks the Power LED red.
 - The reader blinks all 4 LEDs orange once.
 - The reader Power LED remains steady orange.
 - The reader Power LED settles to a steady green to indicate that the update is complete.



New Pic with LED Labels to Come

Figure C-9 *Reader LEDs*

When the update completes, the reader reboots and returns to the FX7500 login screen.

FTP-Based Update

Copy all the update files into an appropriate FTP location.

1. Log into the reader and navigate to the **Firmware Update** page.




Figure C-10 Firmware Update Window

2. Select **FTP/FTPS Server**.
3. Enter the FTP location where the files are located.
4. Enter the **User Name** and **Password** for the FTP server login.
5. Click **Start Update**. The reader starts the update process and displays the update status as follows:
 - The reader continuously blinks the Power LED red.
 - The reader blinks all 4 LEDs orange once.
 - The reader Power LED remains steady orange.
 - The reader Power LED settles to a steady green to indicate that the update is complete.




Figure C-11 Reader LEDs

New Pic with LED Labels to Come

When the update completes, the reader reboots and returns to the FX7500 login screen.

Verifying Firmware Version

To verify reader update success:

1. Log into the reader. In the **User Login** window, enter **admin** in the **User Name:** field and enter **change** in the **Password:** field.




Figure C-12 User Login Window

2. Select **Firmware** on the left side panel to verify that the current version of reader software is the new version number, e.g., 1.1.45, which indicates that the update was successful.



Figure C-13 Firmware Version Window

APPENDIX D STATIC IP CONFIGURATION

Introduction

This appendix describes three methods of setting the static IP address on an FX7500 RFID Reader.

Reader IP Address or Host Name is Known - Set the Static IP Using the Web Console

1. Browse the device using the host name, e.g., FX7500CD3B1E.
2. Log onto the device.




Figure D-1 Reader Administration Console Login Window

3. Click **Communication**.

- Set **Obtain IP Address via DHCP** to **Off** and enter all required information.




Figure D-2 Reader Communication Parameters Window

- Click **Set Properties**. You can set a static IP that doesn't belong to this DHCP network.
- Click **Commit/Discard**, then click the **Commit** button.




Figure D-3 Commit/Discard Window

- The message **Reader IP Address config has changed. Needs reader reboot to take effect** appears. Reset the device and use the reader with the static IP network.

Reader IP is Not Known (DHCP Network Not Available) - Set the Static IP Using the Web Console

1. Connect the device and a PC running Windows XP to the same network that doesn't have a DHCP server, or connect the device directly to the PC.
2. Ensure both the device and PC Ethernet jack use at least one LED to indicate network connection detect.
3. If the PC uses an assigned static IP, update it to use DHCP. The PC obtains an IP that starts with **169**.

```
C:\>ipconfig

Windows IP Configuration

Ethernet adapter Local Area Connection:

    Connection-specific DNS Suffix  . : 
    Autoconfiguration IP Address. . . : 169.254.136.115
    Subnet Mask . . . . . : 255.255.0.0
    Default Gateway . . . . . : 

Ethernet adapter Network Connect Adapter:

    Media State . . . . . : Media disconnected

C:\>_
```

Figure D-4 Obtain IP Address

4. When possible, ping the host name of the device.

```
C:\>ping fx7400cd3b20

Pinging fx7400cd3b20 [169.254.62.74] with 32 bytes of data:

Reply from 169.254.62.74: bytes=32 time=3ms TTL=128
Reply from 169.254.62.74: bytes=32 time=2ms TTL=128
Reply from 169.254.62.74: bytes=32 time=3ms TTL=128
Reply from 169.254.62.74: bytes=32 time=3ms TTL=128

Ping statistics for 169.254.62.74:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 2ms, Maximum = 3ms, Average = 2ms

C:\>_
```

Figure D-5 Ping the Host Name

5. Use a browser to connect to the device with the host name, e.g., FX7500CD3B1E, or use the IP address obtained from ping replies (e.g. 169.254.62.74).
6. Log onto the device.
7. Click **Communication**.

8. Set **Obtain IP Address via DHCP** to **Off** and enter all required information.




Figure D-6 Reader Communication Parameters Window

9. Click **Set Properties**.
10. Click **Commit/Discard**, then click the **Commit** button.




Figure D-7 Commit/Discard Window

11. The message **Reader IP Address config has changed. Needs reader reboot to take effect** appears. Reset the device and use the reader with the static IP network.

APPENDIX E RF AIR LINK CONFIGURATION

Introduction

This appendix lists the different air link configurations supported. The air link configuration is available through LLRP and RFID3 API interfaces.

Radio Modes

The supported modes are exposed as a list of individual **UHFC1G2RfModeTableEntry** parameters in regulatory capabilities as shown in [Table E-1](#) and [Table E-2](#). The **Mode Index** column refers to the index used to walk the **C1G2UHFModeTable**. Refer to the EPCglobal *Low Level Reader Protocol (LLRP) Standard*.

Table E-1 Radio Modes for FCC Readers

RFMode Index	Divide Ratio	BDR Value	M Value M2=2, FM0=1, M4=4, M8=8	FLM Value	PIE Value	Min Tari	Max Tari	Step Tari	Spectral Mask Indicator	EPC HAG T&C Conformance
1	64/3	640000	1	PR_ASK	1500	6250	6250	0	Single	false
2	64/3	640000	1	PR_ASK	2000	6250	6250	0	Single	false
3	64/3	120000	2	PR_ASK	1500	25000	25000	0	Single	false
4	64/3	120000	2	PR_ASK	1500	12500	23000	2100	Single	false
5	64/3	120000	2	PR_ASK	2000	25000	25000	0	Single	false
6	64/3	120000	2	PR_ASK	2000	12500	23000	2100	Single	false
7	64/3	128000	2	PR_ASK	1500	25000	25000	0	Single	false
8	64/3	128000	2	PR_ASK	1500	12500	23000	2100	Single	false
9	64/3	128000	2	PR_ASK	2000	25000	25000	0	Single	false

*RF Mode 13 is the default air link profile.
**RF Mode 23 is the automac air link profile.

Table E-1 Radio Modes for FCC Readers (Continued)

RF Mode Index	Divide Ratio	BDR Value	M Value M2=2, FM0=1, M4=4, M8=8	FLM Value	PIE Value	Min Tari	Max Tari	Step Tari	Spectral Mask Indicator	EPC HAG T&C Conformance
10	64/3	128000	2	PR_ASK	2000	12500	23000	2100	Single	false
11	64/3	160000	2	PR_ASK	1500	12500	18800	2100	Single	false
12	64/3	160000	2	PR_ASK	2000	12500	18800	2100	Single	false
*13	64/3	60000	4	PR_ASK	1500	25000	25000	0	Dense	false
14	64/3	60000	4	PR_ASK	1500	12500	23000	2100	Dense	false
15	64/3	60000	4	PR_ASK	2000	25000	25000	0	Dense	false
16	64/3	60000	4	PR_ASK	2000	12500	23000	2100	Dense	false
17	64/3	64000	4	PR_ASK	1500	25000	25000	0	Dense	false
18	64/3	64000	4	PR_ASK	1500	12500	23000	2100	Dense	false
19	64/3	64000	4	PR_ASK	2000	25000	25000	0	Dense	false
20	64/3	64000	4	PR_ASK	2000	12500	23000	2100	Dense	false
21	64/3	80000	4	PR_ASK	1500	12500	18800	2100	Dense	false
22	64/3	80000	4	PR_ASK	2000	12500	18800	2100	Dense	false
**23	64/3	variable	variable	PR_ASK	variable	6250	25000	variable	variable	false
24	64/3	320000	1	PR_ASK	1500	12500	18800	2100	Single	false
25	64/3	320000	1	PR_ASK	2000	12500	18800	2100	Single	false
26	64/3	30000	8	PR_ASK	1500	25000	25000	0	Dense	false
27	64/3	30000	8	PR_ASK	1500	12500	23000	2100	Dense	false
28	64/3	30000	8	PR_ASK	2000	25000	25000	0	Dense	false
29	64/3	30000	8	PR_ASK	2000	12500	23000	2100	Dense	false
30	64/3	32000	8	PR_ASK	1500	25000	25000	0	Dense	false
31	64/3	32000	8	PR_ASK	1500	12500	23000	2100	Dense	false
32	64/3	32000	8	PR_ASK	2000	25000	25000	0	Dense	false
33	64/3	32000	8	PR_ASK	2000	12500	23000	2100	Dense	false
34	64/3	40000	8	PR_ASK	1500	12500	18800	2100	Dense	false
35	64/3	40000	8	PR_ASK	2000	12500	18800	2100	Dense	false

*RF Mode 13 is the default air link profile.

**RF Mode 23 is the automac air link profile.

Table E-2 Radio Modes for ETSI Readers

RF Mode Index	Divide Ratio	BDR Value	M Value M2=2, FM0=1, M4=4, M8=8	FLM Value	PIE Value	Min Tari	Max Tari	Step Tari	Spectral Mask Indicator	EPC HAG T&C Conformance
1	64/3	120000	2	PR_ASK	1500	25000	25000	0	Single	false
2	64/3	120000	2	PR_ASK	1500	12500	23000	2100	Single	false
3	64/3	120000	2	PR_ASK	2000	25000	25000	0	Single	false
4	64/3	120000	2	PR_ASK	2000	12500	23000	2100	Single	false
5	64/3	128000	2	PR_ASK	1500	25000	25000	0	Single	false
6	64/3	128000	2	PR_ASK	1500	12500	23000	2100	Single	false
7	64/3	128000	2	PR_ASK	2000	25000	25000	0	Single	false
8	64/3	128000	2	PR_ASK	2000	12500	23000	2100	Single	false
9	64/3	160000	2	PR_ASK	1500	12500	18800	2100	Single	false
10	64/3	160000	2	PR_ASK	2000	12500	18800	2100	Single	false
*11	64/3	60000	4	PR_ASK	1500	25000	25000	0	Dense	false
12	64/3	60000	4	PR_ASK	1500	12500	23000	2100	Dense	false
13	64/3	60000	4	PR_ASK	2000	25000	25000	0	Dense	false
14	64/3	60000	4	PR_ASK	2000	12500	23000	2100	Dense	false
15	64/3	64000	4	PR_ASK	1500	25000	25000	0	Dense	false
16	64/3	64000	4	PR_ASK	1500	12500	23000	2100	Dense	false
17	64/3	64000	4	PR_ASK	2000	25000	25000	0	Dense	false
18	64/3	64000	4	PR_ASK	2000	12500	23000	2100	Dense	false
19	64/3	80000	4	PR_ASK	1500	12500	18800	2100	Dense	false
20	64/3	80000	4	PR_ASK	2000	12500	18800	2100	Dense	false
**21	64/3	variable	variable	PR_ASK	variable	12500	25000	variable	variable	false
22	64/3	320000	1	PR_ASK	1500	12500	18800	2100	Single	false
23	64/3	320000	1	PR_ASK	2000	12500	18800	2100	Single	false
24	64/3	30000	8	PR_ASK	1500	25000	25000	0	Dense	false
25	64/3	30000	8	PR_ASK	1500	12500	23000	2100	Dense	false
26	64/3	30000	8	PR_ASK	2000	25000	25000	0	Dense	false
27	64/3	30000	8	PR_ASK	2000	12500	23000	2100	Dense	false

*RF Mode 11 is the default air link profile.
**RF Mode 21 is the automac air link profile.

Table E-2 Radio Modes for ETSI Readers (Continued)

RF Mode Index	Divide Ratio	BDR Value	M Value M2=2, FM0=1, M4=4, M8=8	FLM Value	PIE Value	Min Tari	Max Tari	Step Tari	Spectral Mask Indicator	EPC HAG T&C Conformance
28	64/3	32000	8	PR_ASK	1500	25000	25000	0	Dense	false
29	64/3	32000	8	PR_ASK	1500	12500	23000	2100	Dense	false
30	64/3	32000	8	PR_ASK	2000	25000	25000	0	Dense	false
31	64/3	32000	8	PR_ASK	2000	12500	23000	2100	Dense	false
32	64/3	40000	8	PR_ASK	1500	12500	18800	2100	Dense	false
33	64/3	40000	8	PR_ASK	2000	12500	18800	2100	Dense	false

***RF Mode 11 is the default air link profile.**

****RF Mode 21 is the automac air link profile.**

APPENDIX F CONNECTING WI-FI AND BLUETOOTH DONGLES

Introduction

This appendix describes how to connect to a wireless network using a USB Wi-Fi dongle on the FX7500, and how to connect to a peer device over Bluetooth using a USB Bluetooth dongle.

Connecting to a Wireless Network Using a Wi-Fi Dongle

To connect to a wireless network using a USB Wi-Fi dongle on the FX7500:

1. Plug the supported wireless dongle into the USB host port on the FX7500. Supported dongles are:
 - Wi-Fi over USB adapters with Realtek chipset RTL 8187
 - The following devices were tested:
 - Alfa AWUS036H, visit <http://www.alfa.com.tw/in/front/bin/ptlist.phtml?Category=10541>
 - CCrane Versa Wifi USB Adapter II, visit <http://www.ccrane.com/antennas/wifi-antennas/versa-wifi-usb-adapter-II.aspx>




Figure F-1 USB Host Port Location for Dongle

- To confirm that the Wi-Fi dongle is detected properly, log in to the reader Administrator Console. On the Home page ensure the **USB Port Status** displays **Device Connected**. Hover the mouse pointer over this link to display the WiFi dongle information shown in *Figure F-2*.




Figure F-2 Wi-Fi Dongle Connected

- Select **Communication > Wireless**.




Figure F-3 Wireless Settings

The WiFi dongle can connect to the wireless network in one of two ways:

- Manually entering the ESSID (if known).
- Scanning the current list of APs and choosing the correct one to connect to.

- Once the APs are scanned, enter the appropriate passkey and enable **Connect Automatically** (if required to connect to the AP automatically if the connection is lost).




Figure F-4 Entering Connect Information

- Select **Connect**. When the connection to the AP succeeds, an IP is assigned and appears in the **IP Address** field.




Figure F-5 Assigned IP Address

The reader is now accessible using the wireless IP shown in the **IP Address** field (157.235.207.24 in this case). The WiFi interface supports dynamic addressing mechanisms for both IPV4 and IPV6. There is no provision to set a static IP address.

For wireless IP address details, select **Communication > Wi-Fi** tab.




Figure F-6 Wi-Fi Tab - IPV4

The reader can also be accessed via Wi-Fi using an IPV6 address if supported by the network to which the API is connected.




Figure F-7 Wi-Fi Tab - IPV6

Connecting to a Peer Device over Bluetooth Using a Bluetooth Dongle

To connect to a peer device over Bluetooth using a USB Bluetooth dongle on the FX7500:

1. Plug the supported Bluetooth dongle into the USB host port on the FX7500. The following Bluetooth dongles are supported on the FX7500:
 - Asus Mini Bluetooth Dongle USB-BT211.
 - MediaLink Bluetooth Dongle MUA-BA3.




Figure F-8 USB Host Port Location for Dongle

2. To confirm that the Bluetooth dongle is detected properly, log in to the reader Administrator Console. On the **Home** page ensure the **USB Port Status** displays **Device Connected**. Hover the mouse pointer over this link to display the Bluetooth dongle information.

Reader Administration Console

Welcome to the FX Series (2 port) Reader Administration Console.

Reader Software Version :	1.1.46
Reader Host Name :	FX7500060C17
Reader Network IP Address :	157.235.208.232
Reader Serial Number :	13219010500509
USB Port Status :	Device Connected

Connected USB Devices Information

Bluetooth Adapter	
Model :	3002
Vendor :	0cf3
SerialNumber :	0cf3_3002

© Copyright 2013 Motorola Solutions Inc. All Rights Reserved

Figure F-9 Bluetooth Dongle Connected

3. Select **Communication > Bluetooth**.

4. Change the **Discoverable** and **Pairable** properties to **On**.




Figure F-10 Changing Discoverable and Pairable Properties

5. Optionally select **Use Passkey** and enter a passkey to validate the Bluetooth connection. The default passkey for the FX7500 is **0000**.
6. Discover the reader from a Bluetooth-enabled device (such as a laptop). Use the host name to identify the reader among the discovered devices (e.g., **FX7500060C17**).
7. After a successful connection, right-click the reader icon (e.g., **FX7500060C17**) in the list of Bluetooth devices and select **Connect using > Ad hoc network**. This establishes the network connection for later.




Figure F-11 Connecting to the Reader

8. The IP address assigned to the Bluetooth interface is 192.168.XX.XX. The last 2 octets are the last 2 octets of the Bluetooth MAC address (found in the **Properties** window on the PC once the Bluetooth connection is established). Also find this in the **Communication > Bluetooth** page. Both IPV4 and IPV6 based IP address are supported for adhoc Bluetooth connection between the reader and the client.

The screenshot shows the Motorola FX7500 web interface. The main content area is titled "Reader Communication Parameters" and "Configure Network Settings". It features three tabs: "Ethernet", "Wi-Fi", and "Bluetooth". The "Bluetooth" tab is selected, displaying the following configuration options:

- Current IPv4 address: 192.168.67.21
- IPv4 Subnet Mask: 255.255.0.0
- MAC Address: 00:02:72:38:43:15
- Discoverable: On
- Pairable: On
- Use PassKey:
- PassKey:
- DHCP start address: 192.168.0.2
- DHCP end address: 192.168.0.3

A "Set Properties" button is located at the bottom right of the configuration form. To the right of the main configuration area is a "Communication Settings" sidebar. Under the "Bluetooth" section, it provides explanatory text and a list of settings:

- Discoverable**: Whether the reader will be seen by other bluetooth enabled devices on a discovery.
- Pairable**: Whether any bluetooth enabled device will be allowed to pair with reader.
- Use Passkey**: This option when enabled mandates the connecting device to supply a predetermined passkey which will be used for authentication while pairing.
- Passkey**: Passkey that will be used for authentication.
- DHCP start address**: The starting address of the DHCP IP range out of which an IP will be assigned to the connecting device.
- DHCP end address**: The end address of the DHCP IP range out of which an IP will be assigned to the connecting device.

A note at the bottom of the sidebar states: "Note: The DHCP IP range specified using the DHCP start address and DHCP end address options will also determine the IP of the bluetooth interface of the reader. The First two octets of the IP address of the reader bluetooth interface will be taken from the IP range specified and the last two octets formed using the reader BD address."

Figure F-12 Communication Bluetooth Tab

9. Open the web page or sample application to connect to the Bluetooth IP (192.168.67.21 in [Figure F-12](#)) and read tags.

INDEX

Numerics

10/100BaseT Ethernet	1-2, 2-5
2-port reader	2-4
4-port reader	2-4

A

administrator console	4-1
applications	4-36
committing changes	4-41
communication settings	4-23
configure network services	4-30
configure network settings	4-23, 4-25, 4-26
configuring system log	4-43
discarding changes	4-41
firmware version	4-39, 4-40
GPIO	4-35
IPV6 sec	4-32
login	4-6
main screen	4-9
managing login	4-34
reader diagnostics	4-44
reader profiles	4-37
scan control	1-6, 4-21
set password	4-33
setting date and time	4-31
shutting down	4-45
status	4-10
system log	4-42
air link	E-1
antennas	2-2
configuring	4-18
installing	3-4
ports	1-2, 2-5
applications	4-36

B

backup	2-7
bluetooth	F-5
connecting	F-5

C

cable pinouts	A-4
ethernet	A-4
GPIO	A-6
USB	A-5
USB client	A-5
USB host	A-5
chapter descriptions	x
client applications	2-7
commit region change	1-5
committing changes	4-41
communication	2-5
ethernet, wired	3-5
communication settings	4-23
configurations	ix
configure	
administrator console	2-7
antenna	4-18
LLRP	4-27
read points	4-17, 4-19
reader	4-16
region	4-20
SNMP	4-28
static IP	D-1
static IP via web console	D-1, D-3
wireless	4-29
configuring network	
bluetooth	4-26
ethernet	4-23
services	4-30

- wi-fi 4-25
- connecting
 - to reader 4-3
 - via bluetooth F-5
 - via host name 4-3
 - via IP address 4-4
 - via wi-fi F-1
- connection 2-7
 - antennas 3-4
 - communication 3-5
 - port diagram 2-5
 - ports 2-4
 - powering 3-10
 - wired ethernet 3-5
- conventions
 - notational x
- country list 1-5, 4-7

D

- date 4-31
- deployments 4-2
- discarding changes 4-41

E

- ethernet
 - Bias-T port connection 3-6
 - pinouts A-4
 - POE 3-5
 - port 2-5
 - setup 3-5
 - wired 3-5
- event management, tags 2-7
- event statistics 4-14

F

- filtering, tags 2-7
- firmware
 - updating 2-7
 - version 4-39, 4-40
- firmware update 4-39, 4-40, C-1, C-3
 - prerequisites C-1
- first time login 1-3, 4-6

G

- GPIO 1-2, 2-5
 - pinouts A-6
 - port 2-5
- GPIO control 4-35

H

- host communication
 - ethernet, wired 3-5
- host name connect 1-2

I

- information, service xi
- initiating reads 1-6, 4-21
- installation
 - antennas 3-4
 - communication connection 3-5
 - mounting 3-2
 - powering 3-10
- IP address 4-5
- IP ping 4-5

K

- kill tag 2-7
- kits 2-4, A-1

L

- LEDs 2-6
- LLRP 2-7
 - configure 4-27
 - extensions B-1
 - radio modes E-1, E-3
- lock tag 2-7
- log 4-42
 - configuring 4-43
- logging 2-7
- login 4-6
 - first time 4-6
 - managing 4-34

M

- mono-static 2-4
- mounting 3-2
- mounting plate 3-2
- multiple reader deployments 4-2

N

- NXP
 - statistics 4-13, 4-15

O

- obtain reader IP address 4-5

P

Password 1-3, C-3, C-9
 password 1-3, 4-6, C-3, C-9
 changing 4-33
 pinouts A-4
 ethernet A-4
 GPIO A-6
 USB A-5
 USB client A-5
 USB host A-5
 POE 1-2, 2-5, 3-5, 3-10, A-4
 ports 2-4
 descriptions 2-5
 ethernet 3-5
 power 1-2, 2-5
 AC power supply 3-10
 applying 3-10
 options 3-10
 POE 3-5, 3-10
 port 2-5
 profiles 4-37

R

read points 4-17, 4-19
 reader
 configuration 4-16
 configurations ix
 connecting 4-3
 description 2-2
 GEN2 statistics 4-12
 kits 2-4, A-1
 profiles 4-37
 statistics 4-11
 event 4-14
 NXP 4-13, 4-15
 status 4-10
 versions 2-4
 reading tags 2-7, 3-12
 initiating 1-6, 4-21
 rear panel 1-2, 2-5
 reboot 4-2
 recovery 2-7
 region 4-7
 region configuration 4-20
 region control 4-7
 region setting 1-4
 region settings 1-4
 reset 1-2, 2-5
 RFID
 FX reader 2-3
 overview 2-1
 RFID components 2-2

 antennas 2-2
 readers 2-2
 tags 2-2
 RJ45 2-5
 RM
 extensions B-1

S

service information xi
 set region 1-4, 4-7
 setting date 4-31
 setting time 4-31
 setup
 POE 3-10
 power supply 3-10
 wired ethernet 3-5
 wired ethernet AC outlet 3-5
 wired ethernet, power-over 3-5
 shutdown 4-45
 SNMP 2-7
 configure 4-28
 software update C-3
 specifications A-2
 start-up 1-3
 static IP configuration D-1
 via web console D-1, D-3
 Statistics 4-14
 statistics 4-11
 event 4-14
 GEN2 4-12
 NXP 4-13, 4-15
 status 4-10
 system log 4-42
 configuring 4-43
 system time 4-31

T

tags 2-2
 management 2-7
 reading 3-12, 4-21
 technical specifications A-2
 time 4-31
 troubleshooting 5-1

U

unpacking 3-1
 updating firmware 2-7, 4-39, 4-40, C-1, C-3
 prerequisites C-1
 updating software C-3
 USB 1-2, 2-5
 client pinouts A-5

host pinouts	A-5
pinouts	A-5
user ID	4-6
user name	1-3, C-3, C-9
user password	4-6

V

version control	4-39, 4-40
-----------------------	------------

W

wi-fi	F-1
connecting	F-1
wired ethernet	3-5
wireless	
configure	4-29
write tag	2-7

Z

zero-configuration networking	4-5
-------------------------------------	-----



Motorola Solutions, Inc.
One Motorola Plaza
Holtsville, New York 11742, USA
1-800-927-9626
<http://www.motorolasolutions.com>

MOTOROLA, MOTO, MOTOROLA SOLUTIONS and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are the property of their respective owners.

© 2013 Motorola Solutions, Inc. All Rights Reserved.



MN000026A01 Revision .5 - November 2013

