

**Honeywell**

# **TB3026B Configuration Wizard Guide - N4**

**CONFIGURATION GUIDE**

**JUNE 2018**



31-00121-02





# Table of Contents

<b>INTRODUCTION</b> .....	<b>5</b>
WEBStation-N4™ .....	5
Features .....	5
TB3026B Configuration Wizard .....	5
TB3026B Configuration Requirement .....	6
Organization of the Manual .....	6
<b>CONFIGURATION OF TB3026B AND TB3026B-W CONTROLLERS</b> .....	<b>7</b>
Installation .....	7
Installation of WEBStation-N4™ Tool .....	7
Getting Started.....	8
Digital Signature .....	8
TB3026B Configuration Wizard Initial Setup .....	12
Connecting to Platform.....	12
Adding New Station.....	12
Starting New Station .....	14
Adding BACnet Network to Niagara Network.....	16
Adding TB3026B Controller to the BACnet Network .....	18
TB3026B Configuration Wizard .....	19
Field Description for TB3026B Configuration Wizard .....	20
<b>APPLICATIONS</b> .....	<b>21</b>
Equipment Type.....	21
AHU.....	22
General Display.....	23
Schedule Options.....	25
Zone Setpoints.....	27
Control Settings.....	30
Fan / Humidity.....	32
Economizer .....	34
I/O Configurations .....	35
Air Source Heat Pump.....	37
General Display.....	38
Schedule Options.....	40
Zone Setpoints.....	42
Control Settings.....	45
Fan / Humidity.....	47
Economizer .....	49
I/O Configurations .....	50
Water Source Heat Pump.....	52
General Display.....	53
Schedule Options.....	55
Zone Setpoints.....	57
Control Settings.....	60
Fan / Humidity.....	62
Economizer .....	64
I/O Configurations .....	65
Two Pipe Fan Coil Unit.....	67
General Display.....	69
Schedule Options.....	71

Zone Setpoints.....	73
Control Settings.....	76
Fan / Humidity.....	80
I/O Configurations.....	82
Four Pipe Fan Coil Unit.....	85
General Display.....	87
Schedule Options.....	89
Zone Setpoints.....	91
Control Settings.....	94
Fan / Humidity.....	97
Economizer.....	100
I/O Configurations.....	101
<b>ONLINE OPERATIONS.....</b>	<b>106</b>
Download.....	106
Upload.....	106
Write Device Instance.....	106
Sensor Calibration.....	107
Diagnostics.....	108
Modulating Output Diagnostics.....	109
Binary Output Diagnostics.....	109
Refresh.....	109
Alarms.....	110
Error.....	110
Error Details.....	110
Value Limits.....	110
Current Value.....	110
Refresh alarm list.....	110
Auto Refresh / Update auto refresh rate.....	110
Time Sync.....	111
Batch Operations.....	112
Download.....	113
Upload.....	113
Set Outputs to Auto.....	113
<b>HONEYWELL SOFTWARE END USER LICENSE AGREEMENT.....</b>	<b>114</b>

## List of Figures

Figure 1: Installing WEBStation-N4™ .....	7
Figure 2: Installing WEBStation-N4™ (selecting installation location) .....	7
Figure 3: Installing Platform Daemon .....	9
Figure 4: WEBStation-N4™ – Getting Started.....	10
Figure 5: Open Platform .....	12
Figure 6: Connect Platform .....	12
Figure 7: Authentication during connecting Platform .....	12
Figure 8: Identity Verification during Connecting to Platform.....	12
Figure 9: Adding New Station.....	13
Figure 10: New Station Wizard Window .....	13
Figure 11: Entering Admin Password for New Station.....	13
Figure 12: Location of New Station (BACnetFF) .....	13
Figure 13: Application Director .....	14
Figure 14: Selecting the Station to Start.....	14
Figure 15: Starting the Station.....	14
Figure 16: Started Station .....	14
Figure 17: Newly added Station .....	15
Figure 18: Adding BACnet Network.....	16
Figure 19: Selecting BACnet Network to add .....	16
Figure 20: Adding Specification to add BACnet Network .....	17
Figure 21: Newly added BACnet Network .....	17
Figure 22: Adding Palette .....	18
Figure 23: Opening Palette .....	18
Figure 24: Adding 'honeywellTB3026BWizard' to BACnet Network .....	18
Figure 25: BACnetFF in Palette TAB.....	18
Figure 26: Drag and drop BACnetFF on BacnetNetwork .....	18
Figure 27: Naming Controller .....	19
Figure 28: Location of Controller .....	19
Figure 29: Opening TB3026B Configuration Wizard Screen .....	20
Figure 30: Field description for TB3026B Configuration Wizard Screen .....	20
Figure 31: Application Screen .....	21
Figure 32: Equipment Type .....	21
Figure 33: AHU window.....	22
Figure 34: General Display Screen (AHU) .....	23
Figure 35: Schedule Options Screen (AHU).....	25
Figure 36: Zone Setpoints Screen (Occupancy Mode).....	27
Figure 37: Zone Setpoint Screen (Setpoint Mode).....	29
Figure 38: Control Settings Screen (AHU) .....	30
Figure 39: Fan/Humidity Screen (AHU).....	32
Figure 40: Economizer Screen (AHU).....	34
Figure 41: I/O Configurations Screen (AHU) .....	35
Figure 42: Terminal Assignment View (AHU).....	36
Figure 43: Air Source Heat Pump Window.....	37
Figure 44: General Display Screen (Air Source Heat Pump) .....	38
Figure 45: Schedule Options Screen (Air Source Heat Pump).....	40
Figure 46: Zone Setpoints Screen (Occupancy Mode).....	42
Figure 47: Zone Setpoint Screen (Setpoint Mode) .....	44
Figure 48: Control Settings Screen (Air Source Heat Pump) .....	45
Figure 49: Fan/Humidity Screen (Air Source Heat Pump).....	47
Figure 50: Economizer Screen (Air Source Heat Pump).....	49
Figure 51: I/O Configurations Screen (Air Source Heat Pump).....	50

Figure 52: Terminal Assignment View (Air Source Heat Pump).....	50
Figure 53: Water Source Heat Pump Window .....	52
Figure 54: General Display Screen (Water Source Heat Pump).....	53
Figure 55: Schedule Options Screen (Water Source Heat Pump).....	55
Figure 56: Zone Setpoints Screen (Occupancy Mode) .....	57
Figure 57: Zone Setpoint Screen (Setpoint Mode).....	59
Figure 58: Control Settings Screen (Water Source Heat Pump).....	60
Figure 59: Fan/Humidity Screen (Water Source Heat Pump) .....	62
Figure 60: Economizer Screen (Water Source Heat Pump).....	64
Figure 61: I/O Configurations Screen (Water Source Heat Pump).....	65
Figure 62: Terminal Assignment View (Water Source Heat Pump) .....	66
Figure 63: Two Pipe Fan Coil Unit Window.....	67
Figure 64: General Display Screen (Two Pipe Fan Coil Unit) .....	69
Figure 65: Schedule Options Screen (Two Pipe Fan Coil Unit) .....	71
Figure 66: Zone Setpoints Screen (Occupancy Mode) .....	73
Figure 67: Zone Setpoint Screen (Setpoint Mode).....	75
Figure 68: Control Settings Screen (Two Pipe Fan Coil Unit).....	76
Figure 69: Fan/Humidity Screen (Two Pipe Fan Coil Unit) .....	80
Figure 70: I/O Configurations Screen (Two Pipe Fan Coil Unit).....	82
Figure 71: Terminal Assignment View (Single Speed Fan).....	82
Figure 72: Four Pipe Fan Coil Unit window.....	85
Figure 73: General Display Screen (Four Pipe Fan Coil Unit).....	87
Figure 74: Schedule Options Screen (Four Pipe Fan Coil Unit).....	89
Figure 75: Zone Setpoints Screen (Occupancy Mode) .....	91
Figure 76: Zone Setpoint Wizard Screen (Setpoint Mode).....	93
Figure 77: Control Settings Screen (Four Pipe Fan Coil Unit).....	94
Figure 78: Fan/Humidity Screen (Four Pipe Fan Coil Unit).....	97
Figure 79: Economizer Screen (Four Pipe Fan Coil Unit).....	100
Figure 80: I/O Configurations Screen (Four Pipe Fan Coil Unit).....	101
Figure 81: Terminal Assignment View (Three Speed Fan) .....	101
Figure 82: Selecting 'Download'.....	106
Figure 83: Selecting 'Upload' .....	106
Figure 84: Write Device Instance .....	106
Figure 85: Online Operations View .....	106
Figure 86: Sensor Calibration .....	107
Figure 87: Outputs Overridden Mode/Diagnostics .....	108
Figure 88: Viewing Alarms .....	110
Figure 89: Selecting 'Honeywell Time Sync' .....	111
Figure 90: Time Sync View .....	111
Figure 91: Selecting 'BACnet FF Batch Operations' .....	112
Figure 92: BACnet FF Batch Operations' view.....	112
Figure 93: BACnet FF Batch Operations' view while loading the Mode Status.....	113

## INTRODUCTION

The BACnet Fixed Function (TB3026B) is a communicating sensor/fixed application controller with a built-in humidity sensor. The TB3026B-W is the wireless version with an onboard wireless receiver for wireless occupancy control.

It supports the following equipment types:

1. AHU
2. Air Source Heat Pump
3. Water Source Heat Pump
4. Two Pipe Fan Coil Unit
5. Four Pipe Fan Coil Unit

Each equipment type has other various configurable settings, which provide multiple options and flexibility to the user. Configuration of the TB3026B and TB3026B-W controllers involves selection of the appropriate settings from available options as per the application requirement.

It can be configured using the 'TB3026B Configuration Wizard'. This configuration wizard is developed under WEBStation-N4™ software tool which uses the Niagara N4 Framework® software. It utilizes BACnet® network communication technology (MS/TP).

## WEBStation-N4™

The WEBStation-N4™, powered by the Niagara N4 Framework® is a flexible network server for all connected WEBs-N4 controllers.

WEBStation-N4™ creates a powerful network environment with comprehensive database management, alarm management and messaging services.

WEBStation-N4™ hosts an application called 'TB3026B Configuration Wizard', which provides an engineering environment for configuration of TB3026B and TB3026B-W controllers.

## Features

- Provisioning of multi-controller systems (tools for updating and installation of software modules).
- Central database storage for attached controllers.
- Archive destination/repository for log and alarm data.
- Central server of graphics and aggregated data (single point of access to the system – one IP address).
- Platform for optional enterprise applications.

WEBStation-N4™ acts as a network server or a 'Supervisor' for all connected WEBs-N4™ Controllers. It creates a network environment for the management of these controllers, alarms and messaging services.

## TB3026B Configuration Wizard

It is a special application developed in the WEBStation-N4 to configure the TB3026B and TB3026B-W controllers. All configurable network variables of the TB3026B and TB3026B-W controllers are accessible through this application for configuration.

TB3026B Configuration Wizard provides a means to select settings for all equipment types, control strategy and parameters as per the application requirement.

The following operations can be performed using this wizard:

1. Add a TB3026B controller on the BACnet network.
2. Configure and set the parameters as per the application requirements.
3. Download and upload the configuration into the selected TB3026B controller (Online Operation).
4. Set the time and date.

## TB3026B Configuration Requirement

TB3026B controller is configured using following:

### 1. With WEBStation- N4 Software Tool

In the WEBStation-N4™ software tool, the TB3026B Configuration Wizard application is integrated for TB3026B and TB3026B-W controllers' configuration.

- **Configuration through PC**

TB3026B controllers can be accessed with a personnel computer with WEBStation-N4™ software tool installed. Via BACnet converter, which connects a PC, TB3026B controller can be accessed for configuring, uploading, downloading operations.

- **Configuration through WEBs Controller**

If the TB3026B controller is on the BACnet network of WEBs controller, it can be accessed through WEBs controller using a PC with WEBStation-N4™ tool installed.

When WEBs controller is already commissioned, then it can be accessed through an IP address via Browser. All required operations on the TB3026B controller can be performed by accessing WEBs controller.

### 2. Through TB3026B touch screen

Configurable network parameters are also accessible through the TB3026B touch screen. Access to the configurable parameters is password protected with a default password of 0000. For details refer to, 'BACnet Fixed Function System Engineering Guide, 31-00098.'

## Organization of the Manual

This manual is divided into two basic parts: Introduction and Configuration.

The Introduction provides information for the TB3026B configurable controllers, WEBStation-N4™ Software tool, "TB3026B Configuration Wizard", control application, and abbreviations.

Configuration provides information for the engineering about configurable TB3026B and TB3026B-W controllers' different application types through "TB3026B Configuration Wizard" using its various settings options.



# CONFIGURATION OF TB3026B AND TB3026B-W CONTROLLERS

## Installation

Before proceeding to the “TB3026B Configuration Wizard”, WEBStation-N4™ should be installed as it hosts the configuration wizard.

### Installation of WEBStation-N4™ Tool

WEBStation-N4™ software is distributed via the web or a DVD, and has the following minimum hardware requirements:

**Processor:** Intel Pentium® IV, 2 GHz or higher

**Operating System:**

32-bit: Microsoft Windows XP Professional, Windows 2003 or 2008 Server (if Microsoft IIS is disabled), Vista Business or Windows 7

64-bit: Windows XP Professional, Windows 7

**Browser:** Microsoft IE versions 7, 8, 9, Google Chrome version 15, and Mozilla Firefox version 8, 10, 12

**Memory:** 1 GB minimum, 2 GB or more recommended for large systems, 8 GB or more recommended for the windows 64-bit version

**Hard Drive:** 1 GB minimum, 5 GB for applications that need more archiving capacity

**Display:** Video card and monitor capable of displaying 1024 x 768 pixel resolution or greater

**Network Support:** Ethernet adapter (10/100 Mb with RJ-45 connector)

**Modem:** 56 KB minimum, full time high speed ISP connection 1111 recommended for remote site access (i.e. T1, ADSL, cable modem).

These requirements can vary for the different versions of WEBStation-N4™ as support for newer operating systems is added. For the latest product data, visit <http://customer.honeywell.com>

After selecting the setup for installation, proceed by clicking ‘Next’ to accept the license agreement.



Figure 1: Installing WEBStation-N4™

Select the installation location, (It will create a path in ‘C’ drive under ‘Honeywell’ folder by default)



Figure 2: Installing WEBStation-N4™ (selecting installation location)

Click ‘Next’ button to proceed after selecting appropriate options. Wait until the installation gets finished.

**Note:**

*It is recommended to secure the WEBStation-N4 system in order to make it resistant to the attacks. Refer to the security documents available within WEBStation-N4 software build to make WEBStation-N4 system secure.*

# Getting Started

## Digital Signature

### IMPORTANT

All the Honeywell WEBs software tools are now signed. Users can verify the signature using any OpenSSL tool. Below are the steps to verify signature using OpenSSL community distribution.

### Prerequisites:

- Download the Honeywell public key BuildingsCommonSupervisor.crt from location- same location as the software release location
- Download the batch file “VerifyWEBsToolsSignature.bat” from location- same location as the software release location. This file has the commands to verify the module signature using the public key specified in Step 1
- Download OPENSLL from this link- <https://www.openssl.org/source/openssl-1.0.2o.tar.gz>
- Extract the file using any ZIP utility to get the folder “openssl-1.0.2o”
- In the extracted folder find the file “openssl.cnf”
- Set Windows environment variable OPENSLL\_CONF=<PATH TO openssl.cnf>, for example  
OPENSLL\_CONF=C:\openssl-1.0.2o\apps\openssl.cnf

### Steps to verify the signature:


1. Place the files BuildingsCommonSupervisor.crt, VerifyWEBsToolsSignature.bat, WEBs tools modules and signature file in the same location. For example: Following files are in one place
  - a. BuildingsCommonSupervisor.crt
  - b. VerifyWEBsToolsSignature.bat
  - c. honeywellSpyderTool.jar
  - d. honeywellSpyderTool.jar.sig
2. Open the command prompt and navigate to the location of the above files.
3. Execute the batch file VerifyWEBsToolsSignature.bat against a module for verifying its signature, for example  
- C:\Spyder\_RELEASE\ > VerifyWEBsToolsSignature.bat honeywellSpyderTool.jar
4. OpenSSL will verify this module’s signature and printout the below verification details:


```
C:\Development\SpyderTool\Releases\Spyder_RELEASE_4.4.73.7.2.13\WEBs\Obfuscated\PC\Code Signed Modules>echo OFF
Signature Verification - Process started for honeywellSpyderTool.jar
-a. Extracting Public Key
-b. Verifying Signature for honeywellSpyderTool.jar
-----
Verified OK
Signature verification process finished
C:\Development\SpyderTool\Releases\Spyder_RELEASE_4.4.73.7.2.13\WEBs\Obfuscated\PC\Code Signed Modules>
```

5. If the Niagara module is compromised then user will get the below log, where verification has failed:


```
C:\Development\SpyderTool\Releases\Spyder_RELEASE_4.4.73.7.2.13\WEBs\Obfuscated\PC\Code Signed Modules>VerifyWEBsToolsSignature.bat honeywellSpyderTool.jar
C:\Development\SpyderTool\Releases\Spyder_RELEASE_4.4.73.7.2.13\WEBs\Obfuscated\PC\Code Signed Modules>echo OFF
Signature Verification - Process started for honeywellSpyderTool.jar
-a. Extracting Public Key
-b. Verifying Signature for honeywellSpyderTool.jar
-----
Verification Failure
Signature verification process finished
C:\Development\SpyderTool\Releases\Spyder_RELEASE_4.4.73.7.2.13\WEBs\Obfuscated\PC\Code Signed Modules>
C:\Development\SpyderTool\Releases\Spyder_RELEASE_4.4.73.7.2.13\WEBs\Obfuscated\PC\Code Signed Modules>
C:\Development\SpyderTool\Releases\Spyder_RELEASE_4.4.73.7.2.13\WEBs\Obfuscated\PC\Code Signed Modules>
C:\Development\SpyderTool\Releases\Spyder_RELEASE_4.4.73.7.2.13\WEBs\Obfuscated\PC\Code Signed Modules>VerifyWEBsToolsSignature.bat honeywellSpyderTool.jar
```

TB3026B Configuration Wizard is a user interface where a user can set and adjust various types of parameters.

	<b>Important</b>
<p><b>Hash Value:</b> Honeywell publishes the Hash Value with the TB3026B Configuration Wizard module. It is available as "honeywellTB3026BWizard_HashValue.txt" with the released module.</p> <p>The Hash Value generated at user's end should match the Hash Value published with the TB3026B Configuration Wizard module. It is recommended to perform this check in order to ensure the authenticity of the TB3026B Configuration Wizard module.</p>	



	<b>Note:</b>
<ul style="list-style-type: none"> <li>If more than one version of WEBStation-N4 is installed on the same PC, It is mandatory to install Platform Daemon when switching from one version of WEBStation-N4 to other. It is not required to install Platform Daemon if the same version of WEBStation-N4 needs to open consecutively.</li> <li>If only single version of WEBStation-N4 is installed, then it may not be required to install Platform Daemon every time while opening WEBStation-N4.</li> </ul>	


To start working with the configuration wizard, go to 'Start' menu, select 'All Programs', navigate to 'WEBStation-N4 4.2.36.34' folder and click on it. Click 'Install Platform Daemon' as shown in [Figure 3](#).



**Figure 3: Installing Platform Daemon**

After installing Platform Daemon completely, go to 'Start' menu again and select 'All Programs', navigate to 'WEBStation-N4 4.2.36.34' folder and click on it. Click 'WEBStation.' It will open 'WEBStation-N4' window. Refer to [Figure 4](#).

	<b>Note:</b>
	
<p>'WEBStation-N4' can also be open by clicking an icon named 'WEBStation-N4 Workbench' on the desktop</p>	



**Figure 4: WEBStation-N4™ – Getting Started**

The field description for [Figure 4](#) is as follows:

**1. Title Bar:**



Top of the WEBStation interface is the Title bar. It displays the title of the screen.

**2. Controls**



An application can be minimized, maximized and closed with these controls.

**3. Menu Bar**



It displays heading for drop-down menus.

According to function, commands are group in to the menu tabs. These are File, Edit, Search, Bookmarks, Tools, Window, and Help.

- I. **File:** A user can open, close and save the file, directory, query, new tab, new window using File tab.
- II. **Edit:** Cut, copy, paste, duplicate delete options are available.
- III. **Search:** A file can be searched and navigate from one file to other file.
- IV. **Bookmarks:** A user can add or manage bookmarks.
- V. **Tools:** A user can maintain certificates, license, migration and credential details.
- VI. **Window:** A user can add/ hide Side Bar, Console window, check Active Plug-in.
- VII. **Help:** A user can get assist by clicking F1 or help tab.

#### 4. Standard Tool Bar



Various functions can be accessed using this tool bar. It provides a quick shortcut to frequently used functions.

#### 5. Ribbon




It includes menu bar and standard toolbar.

#### 6. Path Bar




A path of a particular function can be tracked using this.

#### 7. View Tab



It is used to switch between various views, such as, Html View, Text File Editor, Text File Viewer, and Hex File Editor.

#### 8. Left pane



Nav tree details can be viewed over here.

#### 9. Right Pane



Details about Version, License and Certificate are found over here.

## TB3026B Configuration Wizard Initial Setup

The TB3026B Configuration Wizard's user interface window is obtained by following these steps:

1. Connecting to platform
2. Adding new station
3. Starting/Running new station
4. Adding a BACnet network
5. Adding TB3026B device to the BACnet network

### Connecting to Platform

To perform various operations, it is necessary to connect to the Platform initially.

To connect Platform, follow the process:

Navigate to 'My Host: ...' in the Left pane, by right clicking on it, select 'Open Platform'. Refer to [Figure 5](#).




Figure 5: Open Platform

A window will pop up to connect to the Host's secure platform daemon. Click 'OK' to proceed.



Figure 6: Connect Platform

An Identity Verification window may pop up during the first time configuration. Click 'Accept' to verify. (Refer to [Figure 8](#))

Enter Username and Password and click 'OK'



Figure 7: Authentication during connecting Platform




Figure 8: Identity Verification during Connecting to Platform

### Adding New Station

The next stage is to add a new station under platform. Different controllers can be added to the respective network assigned to the station.

To add a new station:

- Navigate to the Platform by clicking sign of Host in the left pane.
- Click 'Tools' tab on menu bar.
- Navigate to 'New station' and click on it.




Figure 9: Adding New Station

- After clicking 'New Station', it opens 'New Station Wizard' window. (Refer to Figure 10)
- Enter name in Station Name field. For example, 'BACnetFF' is added here. Station Directory displays a path by default.
- Click 'Next'



Figure 10: New Station Wizard Window

- Enter a password in the 'Admin Password' field. Enter the same password in 'Confirm Admin Password' field.

	<b>Important:</b>
<b>Password must contain:</b>	
<ul style="list-style-type: none"> <li>– at least 10 character(s)</li> <li>– at least 1 digit(s)</li> <li>– at least 1 lower case character(s)</li> <li>– at least 1 upper case character(s)</li> </ul>	



Figure 11: Entering Admin Password for New Station

- Click 'Finish' to complete action. It creates a station at 'My Host > My File System > User Home > Stations > (created station)'. Refer to Figure 12.




Figure 12: Location of New Station (BACnetFF)

## Starting New Station

To start configuration of controller, it is necessary to start the station. The following is the process to start a newly added station:

Double click on 'Platform', it opens a screen as shown in Figure 13.

Double click on 'Application Director' at the right pane. (Refer to Figure 13).

Select the newly created station ('BACnetFF' in this case) by just clicking on it. Status for this station will be Idle at this stage.

Click 'Start' button as shown in Figure 14. After clicking 'Start', the 'Status' of this station will change to 'Starting' as shown in Figure 15.




Figure 13: Application Director




Figure 14: Selecting the Station to Start




Figure 15: Starting the Station




Figure 16: Started Station




Once the station is started, its status will change to 'Running' (Refer to [Figure 16](#)).

Double click on the started station, a 'verification window will pop up as shown in [Figure 8](#). Click 'Accept' to proceed.

It opens an authentication window. Enter username and password. Click 'OK' to proceed.

	<b>Note:</b>
<p><i>Check 'Remember these credentials' box to remember the username and passwords so that it will not be required to enter it every time during opening the station.</i></p>	

Check newly added station as shown in [Figure 17](#).



**Figure 17: Newly added Station**

## Adding BACnet Network to Niagara Network

TB3026B controller works with BACnet network.

To add a BACnet network (Refer to [Figure 18](#)):

- Navigate to Drivers and double click on it.
- Click on 'New' tab




Figure 18: Adding BACnet Network

- A window will pop out as shown in [Figure 19](#), asking 'Type to Add'.
- Select 'Bacnet Network' from the drop down list.

Required number of networks can be added in 'Number to Add' field. (In this guide since only one network is shown, Number is added as '1')





Figure 19: Selecting BACnet Network to add

- Click 'OK' to proceed.
- Next, a new window will appear, showing 'Name', 'Type' and 'Enabled'(keep its value to 'True'). Refer to [Figure 20](#).
- Click 'OK'.

- A newly added 'BacnetNetwork' can be seen under 'Device manager' on the right pane highlighted in Amber color as shown in [Figure 21](#)  
(An amber colored background highlight appears, as BacnetNetwork is offline. Background will turn white when it is online.)



**Figure 20: Adding Specification to add BACnet Network**



**Figure 21: Newly added BACnet Network**

## Adding TB3026B Controller to the BACnet Network

- After adding a Bacnet Network to the Drivers, the next step is to add a TB3026B controller to the Bacnet Network.
- Click on the 'Window' option in Menu bar; navigate to 'Palette' through sub menu of 'Side Bars'. (Refer to [Figure 22](#)).




Figure 22: Adding Palette

- This will add a 'Palette' tab in the left pane. (Refer to [Figure 23](#)). Click 'Open Palette' option.




Figure 23: Opening Palette

- An 'Open Palette' window will open. Find a module named 'honeywellTB3026BWizard' as shown in [Figure 24](#), Select it and click 'OK' button to add into the Palette.



Figure 24: Adding 'honeywellTB3026BWizard' to BACnet Network

- After adding 'honeywellTB3026BWizard', it reflects in the 'Palette' tab as 'BACnetFF' as seen in [Figure 25](#).




Figure 25: BACnetFF in Palette TAB

- Drag 'BACnetFF' and Drop it on 'BacnetNetwork' added under created station. Refer to [Figure 26](#).





Figure 26: Drag and drop BACnetFF on BacnetNetwork

A window will pop up as 'BACnetFF' is dropped on BacnetNetwork to name the controller. Enter the name accordingly. In this guide, it is named as 'BACnetFF' as shown in [Figure 27](#).



**Figure 27: Naming Controller**

A newly added TB3026B controller can be seen by clicking  sign as shown in [Figure 28](#).



**Figure 28: Location of Controller**

## TB3026B Configuration Wizard

To start working with the TB3026B wizard, navigate to Bacnet Network (Refer to [Figure 28](#)). Double click on added controller (here, 'BACnetFF'). It will open the TB3026B Configuration Wizard window. .




Figure 29: Opening TB3026B Configuration Wizard Screen

## Field Description for TB3026B Configuration Wizard




Figure 30: Field description for TB3026B Configuration Wizard Screen

**1. Title Bar**

It displays the name 'TB3026B Configuration View'.

**2. Configuration Parameters**

It displays the list of setting buttons for various groups of configuration parameters.

**3. Configuration Settings**


It displays Configuration settings as per the selected group of parameters.

**4. Action Buttons**


It displays following buttons:



It is used to save the configuration settings.




It is used to reset actions to its default value.



It is used to generate proxy points under TB3026B controller "points" folder for the selected configuration.

# APPLICATIONS

Application  is the first tab of the Configuration Wizard. The Application screen allows a user to select the required Equipment Type.




Figure 31: Application Screen

## Equipment Type

A user can select the required equipment type through this option. This is a fundamental setting in a configuration as selection of various other parameters from the different settings depend on the Equipment Type.

A required Equipment Type can be selected from the following:

1. AHU
2. Air Source Heat Pump
3. Water Source Heat Pump
4. Two Pipe Fan Coil Unit
5. Four Pipe Fan Coil Unit

### Equipment Type




Figure 32: Equipment Type

# AHU





Figure 33: AHU window

## Output Stages

Equipment Type 'AHU' consists of two types of 'Output Stages'

1. One Stage Heat/One Stage Cool
2. Two Stage Heat/Two Stage Cool

## Output Stages



**One Stage Heat/One Stage Cool:** Select this option if One stage of cooling and one stage of Heating is required in the application.

**Two Stage Heat/Two Stage Cool:** Select this option if Two stages of cooling and two stages of Heating are required in the application.



## General Display

Click 'General Display'  to view the general display settings. The following parameters are used to configure the controller's display settings.

1. Engineering Units
2. Time Functions
3. Display
4. Contractor Access Codes




Figure 34: General Display Screen (AHU)

## Engineering Units

### Engineering Units

**Application Unit**  English  Metric

**Application Unit:** The application units contain two options to change the controller's units. By default, the controller's application units are set to 'English'. Application Units can be changed to 'English' or 'Metric'.

## Time Function

### Time Time Issues



**Clock Format:** A user can select a clock format as 12-hour format or 24-hour format.

**Daylight Savings Time:** This feature enables to select the Daylight Savings Time settings. By default, Daylight Savings Time is set to 'Disabled'. Daylight Savings Time can be changed to 'Pre-2007' or 'Post-2007'.

## Display

This feature allows a user to select the Display settings.

### Display



**Outside Air Temp:** A user has an option to hide/show an outside air temperature.

**Clock Adjustment:** This option allows a user to enable/disable the clock adjustment on the controller display.

**Keypad Lockout:** This option allows a user to lock/unlock the clock adjustment. When an option, 'Temperature Settings Only' is selected, a user can only set the temperature through keypad.

**Backlight:** A user can keep the backlight always on or set to delayed off through this option.

## Contractor Access Codes

### Contractor Access Codes




An access to the controller can be restricted with the help of Access Codes.

Field Service Pin and Installer Service Pin can be set. These codes should be enabled to restrict an access to the controller.

	<b>Note:</b>
<p>A user can set only numerical PIN code for 'Field Service Pin' and 'Installer Service Pin'. PIN codes should be set within 0000 – 9999. The following Error Window pops up if this field is left blank after selecting.</p>	
<p><b>Note:</b> When error message pops up, it displays the text field twice in the error window.</p>	

## Schedule Options

'Schedule'  tab displays Schedule options. The following parameters are used to configure the schedule options (i.e. Occupancy Configuration and Bypass and Standby).




Figure 35: Schedule Options Screen (AHU)

### Occupancy Configuration


**Schedule Model:** A user can set the device's schedule model as;

1. Setpoint Mode or
2. Occupancy Mode

**Setpoint Mode:** In setpoint mode, the controller logically emulates residential thermostats. The space temperature is controlled to "SP Mode Cooling SP" and "SP Mode Heating SP". Each schedule period consists of a start time, a heating setpoint, and a cooling setpoint.

**If a user selects 'Setpoint Mode' from the available 'Schedule Model', the fields for 'Comm Fails Occupied' and 'System Block' settings become disabled.**

#### Occupancy Configuration



**Occupancy Mode:** By default, 'Schedule Model' is in 'Occupancy Mode'. The system will be switched to 'Occupied Mode' when the occupancy sensor detects occupancy. Occupied Mode allows a user to configure 'Comm Fails Occupied', 'System Block' & 'Internal Schedule' settings.

### Occupancy Configuration

**Schedule Model**  Setpoint Mode  Occupancy Mode  
**Comm Fails Occupied**  Disable  Enable  
**System Block**  Hide  Show Unoccupied  Show Unoccupied and Off  
**Internal Schedule**  Disable  Two Periods  Four Periods

**Comm Fails Occupied:** It allows a user to switch the system in Occupied Mode in case of MS/TP communication failure. If the MS/TP communication fails, the system enters into Occupied Mode when this option is selected as 'Enable', otherwise the system remains in its current state when this option is selected as 'Disable'.

**System Block:** The System Block is hidden when the schedule model is in 'Setpoint Mode'. When the schedule model is in 'Occupancy Mode', it allows a user to switch between the available options. Selecting "Show Unoccupied/Off" places the controller in unoccupied state.

**Internal schedule:** It can be configured in both Occupancy Mode & Setpoint Mode. By default, 'Internal Schedule' is 'Disable'.

If the internal schedule is 'Disable', a user can adjust the setpoint (within setpoint limits).

### Display Settings

When a user selects, 'Two Periods' or 'Four Periods' options an additional 'Display Settings' appears as follows:

#### Display Settings

**Schedule Access**  None  View  Edit  
**Vacation Hold**  Allow  Deny  
**Permanent Hold**  Allow  Deny

**Schedule Access:** When a user selects 'Edit', it allows a user to view and edit the schedule and when a user selects 'View', it allows a user to view the schedule. When a user selects 'None', it will not allow a user to view or edit the schedule.

**Vacation Hold:** It allows/denies a user to override the scheduled setpoint from TB3026B display to "Vacation Hold".

**Permanent Hold:** It allows/denies a user to override the scheduled setpoint from TB3026B display to "Permanent Hold".

### Bypass and Standby


#### Bypass and Standby

**Bypass Time**  hr (0.2-9.5)  
**Standby Delay**  s (0-3600)

**Bypass Time:** In the Unoccupied state, it forces the controller into the occupied state for up to 4 hours (default value). The override time limit is adjustable from a minimum of 0.2 hours to a maximum of 9.5 hours.

**Standby Delay:** In Occupied Mode, if any window or door is opened and closed with no motion detected after the time mentioned for the Standby Delay, the room status switches to Standby state. The default value is 180 seconds.

## Zone Setpoints

Zone Setpoints , allows a user to set the following parameters as per the requirement:

1. Temperature Setpoints
2. Setpoint Limits
3. Standby Settings
4. Display Options



Figure 36: Zone Setpoints Screen (Occupancy Mode)

### Temperature Setpoints

#### Temperature Setpoints

Occupied Setpoint	<input type="text" value="70.0"/> °F [45.0-99.0]
Cooling Offset	<input type="text" value="2.0"/> Δ°F [0.0-12.1]
Heating Offset	<input type="text" value="3.0"/> Δ°F [0.0-12.1]
Unoccupied Heating Setpoint	<input type="text" value="55.0"/> °F [45.0-99.0]
Unoccupied Cooling Setpoint	<input type="text" value="55.0"/> °F [45.0-99.0]

**Occupied Setpoint:** It is a setpoint in Occupied Mode. Enter the value within the range of 45 °F to 99 °F. The default value is 70°F.

**Cooling Offset:** In the Occupied state, the cooling setpoint is calculated as cooling offset plus occupied setpoint. Enter

the value within the range of 0Δ°F to 12.1Δ°F. The default value is 2 Δ°F.

**Heating Offset:** In the Occupied state, the heating setpoint is calculated as heating offset minus occupied setpoint. Enter the value within the range of 0Δ°F to 12.1Δ°F. The default value is 1 Δ°F.

**Unoccupied Heating Setpoint:** It is a setpoint for Heating in Unoccupied mode. Enter the value within the range of 45 °F to 99 °F. The default value is 55 °F.

**Unoccupied Cooling Setpoint:** It is a setpoint for Cooling in Unoccupied mode. Enter the value within the range of 45 °F to 99 °F. The default value is 55 °F.

## Setpoint Limits




### Setpoint Limits

Setpoint High Limit  [45.0-99.0]

Setpoint Low Limit  [45.0-99.0]

**Setpoint High Limit:** A user can enter a Setpoint High Limit in Occupied Mode within the range of 45 °F to 99 °F. The default value is 78 °F.

**Setpoint Low Limit:** A user can enter a Setpoint Low Limit in Occupied Mode within the range of 45 °F to 99 °F. The default value is 62 °F.

	<b>Note:</b>
<p>1. <i>Unoccupied Cooling Setpoint should always be set GREATER than Unoccupied Heating Setpoint.</i></p> <p><i>Following Error window appears if Unoccupied Cooling Setpoint is set lower than Unoccupied Heating Setpoint.</i></p> 	
<p>2. <i>Setpoint High Limit should always be set GREATER than Setpoint Low Limit.</i></p> <p><i>Following Error window appears if Setpoint High Limit is set lower than Setpoint low Limit.</i></p> 	

## Standby Settings

### Standby Settings

Standby Offset  [0.0-12.1]

Reverse Standby Input  Normal (NO)  Reverse (NC)

Standby state is a power-saving function of Occupancy mode. It occurs when the space is scheduled as Occupied, but sensors detect (When the Standby input is active) there are no humans in the space.

**Standby Offset:** In this case, the Standby Offset relaxes the occupied setpoints. The value of the Standby Offset [SO] can be set between a minimum of 0Δ°F and a maximum of 12.1Δ°F degrees. The default value is 4 Δ°F.

**Reverse Standby Input:** It allows a user to configure two types of inputs, 'Normally Open (NO)' and 'Normally Close (NC)'.

**Display Options**

**Unoccupied Setpoints:** It allows a user to either 'Hide' or 'Show' the unoccupied setpoint.

**Display Options**


Unoccupied Setpoints  Hide  Show

When a user selects Schedule Mode under the 'Schedule Options' tab to 'Setpoint Mode', the 'Zone Setpoints' configuration window appears as follows:



**Figure 37: Zone Setpoint Screen (Setpoint Mode)**

## Control Settings

'Control Settings'  allows a user to configure following settings:

1. Cooling PI Control
2. Heating PI Control
3. Compressor Settings



**TH3026B Configuration View**

Application | General Display | Schedule Options | Zone Setpoints | **Control Settings** | Fan/Humidity | Economizer | I/O Configuration

**Cooling PI Control**

Proportional Constant Kp: 21.00 [10.00-40.00]  
 Integral Constant Ki: 1.00 [0.30-3.00]  
 DAT Lockout Setpoint: 55.0 °F [45.0-65.0]

**Heating PI Control**

Proportional Constant Kp: 21.00 [10.00-40.00]  
 Integral Constant Ki: 1.00 [0.30-3.00]  
 DAT Lockout Setpoint: 62.0 °F [45.0-80.0]

**Compressor Settings**

Cycle Time: 20 min [8-30]  
 Minimum On/Off Time: 3 min [3-15]

Figure 38: Control Settings Screen (AHU)



## Cooling PI Control

### Cooling PI Control

**Proportional Constant  $K_p$**   [10.00 - 40.00]  
**Integral Constant  $K_i$**   [0.50 - 2.00]  
**OAT Lockout Setpoint**  °F [45.0 - 99.0]

**Proportional Constant  $K_p$ :** A user can enter a value for  $K_p$  within the range of 10 to 40. The default value is 20.

**Integral Constant  $K_i$ :** A user can enter a value for  $K_i$  within the range of 0.50 to 2. The default value is 1.

**OAT Lockout Setpoint:** Cooling PI control will lockout when outside Temperature decreases below OAT (Cooling) Lockout Setpoint. The default value is 55 °F.

## Heating PI Control

### Heating PI Control

**Proportional Constant  $K_p$**   [10.00 - 40.00]  
**Integral Constant  $K_i$**   [0.50 - 2.00]  
**OAT Lockout Setpoint**  °F [45.0 - 99.0]

**Proportional Constant  $K_p$ :** A user can enter a value for  $K_p$  within the range of 10 to 40. The default value is 20.

**Integral Constant  $K_i$ :** A user can enter a value for  $K_i$  within the range of 0.50 to 2. The default value is 1.

**OAT Lockout Setpoint:** Heating PI control will lockout when outside Temperature increases above OAT (Heating) Lockout Setpoint. The default value is 62 °F.

## Compressor Settings


### Compressor Settings

**Cycle Time**  min [8 - 30]  
**Minimum On/Off Time**  min [0 - 15]

**Cycle Time:** The Compressor Cycle Time is adjustable, it ranges from minimum of 8 minutes, and a maximum of 30 minutes. The default value is 20 minutes.

**Minimum On/Off Time:** It is a minimum time for the compressor to stay On/Off. The default value is 3 minutes.

## Fan / Humidity

'Fan / Humidity'  allows a user to configure the following settings:

1. Fan Operation
2. Humidity Control
3. Filter Alarm




Figure 39: Fan/Humidity Screen (AHU)

### Fan Operation

**Fan Mode Control:** During Setpoint Mode and Occupancy Mode, the fan can be configured to operate based on the selected Fan Mode Control as describe below:

#### Fan Operation

**Fan Mode Control**  Auto  On  On Cool/Auto Heat

**Auto:** When this option is selected, Fan cycles ON when:

1. Cooling or heating is selected or
2. During Unoccupied mode only when called to run by cooling or heating demand.

**On:** When this option is selected the fan runs continuously for ventilation.

**On Cool/Auto Heat:** When this option is selected the fan runs continuously in cooling mode. In heating mode the fan cycles on only when the heating signal calls for the fan to run.

## Humidity Control

### Humidity Control

Fan Circulation Cycle  Enable  Disable

Trigger Setpoint  %RH [0-100]

Reset Deadband  % [0-100]

Fan On Cycle Time  s [10-3000]

Fan Off Cycle Time  s [10-3000]

**Fan Circulation Cycle:** When a user selects the ‘Enable’ option from Fan Circulation Cycle, it allows a user to edit the Trigger Setpoint, Reset Deadband, and Fan On/Off Cycle Time.

**Trigger Setpoint & Reset Deadband:** When sensed humidity equals or exceeds humidity trigger setpoint, the fan cycles ON/OFF at low speed until sensed humidity drops below the trigger setpoint minus the reset deadband.

**Fan On Cycle Time:** This field allows a user to enter a time for fan ON cycle when stratification and humidity control is active. The default value is 300 seconds.

**Fan Off Cycle Time:** This field allows a user to enter a time for fan OFF cycle when stratification and humidity control is active. The default value is 1800 seconds.

## Filter Alarm

### Filter Alarm

Runtime Hours  [0-3000]

**Runtime Hours:** A filter alarm activates after the Runtime Hours mentioned in this field. The default value is 3000 hours.

## Economizer


Select Economizer  from Configuration parameters. It is used to configure the economizer settings in TB3026B controller.



Figure 40: Economizer Screen (AHU)


### Configuration

**Minimum Position:** When either the occupied command or the After-hours Timer is ON, the current minimum position is set to the specified Economizer Minimum Position; otherwise, it is zero. The default minimum position is 20%.

**Outside Air Lockout:** The economizer is forced to Minimum position when Outside Air Temperature goes above the Outside Air Lockout setpoint. The default value is 68° F.

**Supply Air Low Limit:** The economizer is forced to Minimum position when Supply Temperature goes below the Supply Air Low Limit. The default value is 45° F.

## I/O Configurations

Select I/O Configurations  from Configuration parameters. This configuration is mainly used for Terminal Assignment & Output Configuration.




Figure 41:I/O Configurations Screen (AHU)

### Terminal Assignment

After completing the AHU configuration, selected inputs and outputs get automatically assigned to the TB3026B controller's input and output terminals. However, a user can assign the outputs as 'Economizer Open' & 'Economizer Close' to BO-4 & BO-5 and inputs as 'BMS Sensor' or 'Remote Space Temp' or 'Outdoor Air Temp' to AI/BI0 respectively.




Figure 42: Terminal Assignment View (AHU)

### Output Configuration

#### Output Configuration

Economizer Damper Stroke Time  s [ 300 ]

When a user assigns the outputs, 'Economizer Open' and 'Economizer Close' to BO-4 and BO-5 respectively, 'Economizer Damper Stroke Time' can be mentioned in the field 'Output Configuration'. The default value is 3 seconds.

When 'Output Stage' is selected as 'Two Stages Heat/Two Stages Cool', the 'Terminal Assignment' view changes as follows:

The screenshot shows the 'Terminal Assignment' view for the TB3026B controller. The interface includes a navigation bar with tabs for Application, General Display, Schedule Options, Zone Setpoints, Control Settings, Fan/Humidity, Economizer, and I/O Configuration. The 'Terminal Assignment' table is as follows:

Terminal	BO	Relay	AI/BI	Output
Unused	BO-5	24VAC Hot	1	24VAC Hot
Heat Stage 2	BO-4	Relay 24VAC	2	Relay 24VAC
Heat Stage 1	BO-3	BO-0	3	Fan
Cool Stage 2	BO-2	BO-1	4	Cool Stage 1
GND	GND	GND	5	GND
Economizer	AO-0	AI/BI0	6	BMS Sensor
COM	COM	COM	7	COM
Fan Speed	AO-1	AI/BI1	8	Standby
MSTP+	MSTP+	COM	9	COM
MSTP-	MSTP-	AI/BI2	10	SA Temp or Alarm

## Air Source Heat Pump




Figure 43: Air Source Heat Pump Window

### Output Stages

Equipment Type 'Air Source Heat Pump' consists of two types of 'Output Stages'. Required type of output stages can be selected from the following available options:

#### Output Stages



#### One Compressor Stage and One Aux Heat Stage:

Select this option if One stage of compressor and one stage of Auxiliary Heating is required in the application

#### One Compressor Stage and Two Aux Heat Stage:


Select this option if Two stages of Compressors and Two stages of Auxiliary Heating are required in the application

### Fan Speeds

A user can select Two types of 'Fan Speeds' when the output stage is configured as 'One Compressor Stage and One Aux Heat Stage'.

1. Single Speed Fan
2. Three Speed Fan

#### Fan Speeds



## General Display

Click 'General Display'  to view the general display settings. The following parameters are used to configure the controller's display settings.

1. Engineering Units
2. Time Functions
3. Display
4. Contractor Access Codes




Figure 44: General Display Screen (Air Source Heat Pump)

## Engineering Units

### Engineering Units



**Application Unit:** The application units contain two options to change the controller's units. By default, the controller's application units are set to 'English'. Application units can be changed to 'English' or 'Metric'.



## Time Function



**Clock Format:** A user can select a clock format as 12-hour format or 24-hour format.

**Daylight Savings Time:** This feature enables to select the Daylight Savings Time settings. By default, Daylight Savings Time is set to 'Disabled'. Daylight Savings Time can be changed to 'Pre-2007' or 'Post-2007'.

## Display

This feature allows a user to select the Display settings.



**Outside Air Temp:** A user has an option to hide/show an outside air temperature.

## Contractor Access Codes

**Clock Adjustment:** This option allows a user to enable/disable the clock adjustment on the controller display.



**Keypad Lockout:** This option allows a user to lock/unlock the clock adjustment. When an option, 'Temperature Settings Only' is selected, a user can only set the temperature through keypad.

An access to the controller can be restricted with the help of Access Codes. Field Service Pin and Installer Service Pin can be set. These codes should be enabled to restrict an access to the controller.

**Backlight:** A user can keep the backlight always on or set to delayed off through this option.

**Note:**

A user can set only numerical PIN code for 'Field Service Pin' and 'Installer Service Pin'. PIN codes should be set within 0000 – 9999. The following Error Window pops up if this field is left blank after selecting.

## Schedule Options

'Schedule'  tab displays Schedule options.

The following parameters are used to configure the schedule options (i.e. Occupancy Configuration and Bypass and Standby)



Figure 45: Schedule Options Screen (Air Source Heat Pump)

### Occupancy Configuration

**Schedule Model:** A user can set the device's schedule model as;

1. Setpoint Mode or
2. Occupancy Mode

**Setpoint Mode:** In setpoint mode, the controller logically emulates residential thermostats. The space temperature is controlled to "SP Mode Cooling SP" and "SP Mode Heating SP". Each schedule period consists of a start time, a heating setpoint, and a cooling setpoint.

**If a user selects 'Setpoint Mode' from the available 'Schedule Model', the fields for 'Comm Fails Occupied' and 'System Block' settings become disabled.**

#### Occupancy Configuration



**Occupancy Mode:** By default, 'Schedule Model' is in 'Occupancy Mode'. The system will be switched to 'Occupied Mode' when the occupancy sensor detects occupancy. Occupied Mode allows a user to configure 'Comm Fails Occupied', 'System Block' & 'Internal Schedule' settings.

#### Occupancy Configuration



**Comm Fails Occupied:** It allows a user to switch the system in Occupied Mode in case of MS/TP communication failure. If the MS/TP communication fails, the system enters into Occupied Mode when this option is selected as 'Enable', otherwise the system remains in its current state when this option is selected as 'Disable'.

'Enable', and remains in its current state when this option is selected as 'Disable'.

**System Block:** The System Block is hidden when the schedule model is in 'Setpoint Mode'. When the schedule model is in 'Occupancy Mode', it allows a user to switch between the available options. Selecting "Show Unoccupied/Off" places the controller in unoccupied state.

**Internal schedule:** It can be configured in both Occupancy Mode & Setpoint Mode. By default, 'Internal Schedule' is 'Disable'.

If the internal schedule is 'Disable', a user can adjust the setpoint (within setpoint limits).

### Display Settings

When a user selects, 'Two Periods' or 'Four Periods' options an additional 'Display Settings' appears as follows:

#### Display Settings



**Schedule Access:** When a user selects 'Edit', it allows a user to view and edit the schedule and when a user selects 'View', it allows a user to view the schedule. When a user selects 'None', it will not allow a user to view or edit the schedule.

**Vacation Hold:** It allows/denies a user to override the scheduled setpoint from TB3026B display to "Vacation Hold".

**Permanent Hold:** It allows/denies a user to override the scheduled setpoint from TB3026B display to "Permanent Hold".

### Bypass and Standby


#### Bypass and Standby



**Bypass Time:** In the Unoccupied state, it forces the controller into the occupied state for up to 4 hours (default value). The override time limit is adjustable from a minimum of 0.2 hours to a maximum of 9.5 hours.

**Standby Delay:** In Occupied Mode, if any window or door is opened and closed with no motion detected after the time mentioned for the Standby Delay, the room status switches to Standby state. The default value is 180 seconds.

## Zone Setpoints

Zone Setpoints  , allows a user to set the following parameters as per the requirement:

1. Temperature Setpoints
2. Setpoint Limits
3. Standby Settings
4. Display Options



Figure 46: Zone Setpoints Screen (Occupancy Mode)

### Temperature Setpoints

#### Temperature Setpoints

<b>Occupied Setpoint</b>	<input type="text" value="70.0"/> °F [45.0-99.0]
<b>Cooling Offset</b>	<input type="text" value="2.0"/> Δ°F [0.0-12.1]
<b>Heating Offset</b>	<input type="text" value="1.0"/> Δ°F [0.0-12.1]
<b>Unoccupied Heating Setpoint</b>	<input type="text" value="55.0"/> °F [45.0-99.0]
<b>Unoccupied Cooling Setpoint</b>	<input type="text" value="85.0"/> °F [45.0-99.0]

**Occupied Setpoint:** It is a setpoint in Occupied Mode. Enter the value within the range of 45 °F to 99 °F. The default value is 70°F.

**Cooling Offset:** In the Occupied state, the cooling setpoint is calculated as cooling offset plus occupied setpoint. Enter

the value within the range of 0Δ°F to 12.1Δ°F. The default value is 2 Δ°F.

**Heating Offset:** In the Occupied state, the heating setpoint is calculated as heating offset minus occupied setpoint. Enter the value within the range of 0Δ°F to 12.1Δ°F. The default value is 1 Δ°F.

**Unoccupied Heating Setpoint:** It is a setpoint for Heating in Unoccupied mode. Enter the value within the range of 45 °F to 99 °F. The default value is 55 °F.

**Unoccupied Cooling Setpoint:** It is a setpoint for Cooling in Unoccupied mode. Enter the value within the range of 45°F to 99°F. The default value is 85 °F.

## Setpoint Limits




### Setpoint Limits

Setpoint High Limit 78.0 [45.0-99.0]

Setpoint Low Limit 62.0 [45.0-99.0]

**Setpoint High Limit:** A user can enter a Setpoint High Limit in Occupied Mode within the range of 45 °F to 99 °F. The default value is 78°F.

**Setpoint Low Limit:** A user can enter a Setpoint Low Limit in Occupied Mode within the range of 45 °F to 99 °F. The default value is 62°F.

	<b>Note:</b>
<p>1. <i>Unoccupied Cooling Setpoint should always be set GREATER than Unoccupied Heating Setpoint.</i></p> <p><i>Following Error window appears if Unoccupied Cooling Setpoint is set lower than Unoccupied Heating Setpoint.</i></p> 	
<p>2. <i>Setpoint High Limit should always be set GREATER than Setpoint Low Limit.</i></p> <p><i>Following Error window appears if Setpoint High Limit is set lower than Setpoint low Limit.</i></p> 	

## Standby Settings

### Standby Settings

Standby Offset 4.0 [0.0-12.1]

Reverse Standby Input  Normal (NO)  Reverse (NC)

Standby state is a power-saving function of Occupancy mode. It occurs when the space is scheduled as Occupied, but sensors detect (When the Standby input is active) there are no humans in the space.

**Standby Offset:** In this case, the Standby Offset relaxes the occupied setpoints. The value of the Standby Offset [SO] can be set between a minimum of 0Δ°F and a maximum of 12.1Δ°F degrees. The default value is 4 Δ°F.

**Reverse Standby Input:** It allows a user to configure two types of inputs, 'Normally Open (NO)' and 'Normally Close (NC)'.

## Display Options

### Display Options

Unoccupied Setpoints  Hide  Show


**Unoccupied Setpoints:** It allows a user to either 'Hide' or 'Show' the unoccupied setpoint.

When a user selects Schedule Model under the 'Schedule Options' tab to 'Setpoint Mode', the 'Zone Setpoints' configuration window appears as follows:




Figure 47: Zone Setpoint Screen (Setpoint Mode)

## Control Settings

'Control Settings'  allows a user to configure following settings:

1. Cooling PI Control.
2. Heating PI Control.
3. Aux Staged Heating
4. Compressor Settings.



**TR1026B Configuration View**

Application | General Display | Schedule Options | Zone Setpoints | **Control Settings** | Fan/Humidity | Economizer | I/O Configuration

**Cooling PI Control**

Proportional Constant Kp: 20.00 [10.00-40.00]

Integral Constant Ki: 1.00 [0.50-2.00]

ΔT Lockout Setpoint: 55.0 °F [45.0-65.0]

**Heating PI Control**

Proportional Constant Kp: 20.00 [10.00-40.00]

Integral Constant Ki: 1.00 [0.50-2.00]

ΔT Lockout Setpoint: 62.0 °F [45.0-99.0]

**Aux Staged Heating**

Cycle Time: 5 min [0-30]

Minimum On/Off Time: 3 min [0-15]

**Compressor Settings**

Cycle Time: 20 min [0-30]

Minimum On/Off Time: 8 min [0-15]

Reversing Valve:  Energized on Heating  Energized on Cooling

Figure 48: Control Settings Screen (Air Source Heat Pump)

## Cooling PI Control

### Cooling PI Control

Proportional Constant  $K_p$   [10.00-40.00]  
 Integral Constant  $K_i$   [0.50-2.00]  
 OAT Lockout Setpoint  °F [45.0-65.0]

**Proportional Constant  $K_p$ :** A user can enter a value for  $K_p$  within the range of 10 to 40. The default value is 20.

**Integral Constant  $K_i$ :** A user can enter a value for  $K_i$  within the range of 0.50 to 2. The default value is 1.

**OAT Lockout Setpoint:** Cooling PI control will lockout when outside Temperature increases above OAT (Cooling) Lockout Setpoint. The default value is 55 °F.

## Aux Staged Heating

### Aux Staged Heating

Cycle Time  min [8-30]  
 Minimum On/Off Time  min [0-15]

**Cycle Time:** The Cycle Time ranges from minimum of 8 minutes, and a maximum of 30 minutes. The default value is 15 minutes.

**Minimum On/Off Time:** It is a minimum On/Off time for the Auxiliary Heating. The default value is 3 minutes.

## Heating PI Control

### Heating PI Control

Proportional Constant  $K_p$   [10.00-40.00]  
 Integral Constant  $K_i$   [0.50-2.00]  
 OAT Lockout Setpoint  °F [45.0-65.0]

**Proportional Constant  $K_p$ :** A user can enter a value for  $K_p$  within the range of 10 to 40. The default value is 20.

**Integral Constant  $K_i$ :** A user can enter a value for  $K_i$  within the range of 0.50 to 2. The default value is 1.

**OAT Lockout Setpoint:** Heating PI control will lockout when outside Temperature decreases below OAT (Heating) Lockout Setpoint. The default value is 62 °F.

## Compressor Settings

### Compressor Settings

Cycle Time  min [5-30]  
 Minimum On/Off Time  min [0-15]  
 Reversing Valve:  energized on Heating  energized on Cooling


**Cycle Time:** The Compressor Cycle Time is adjustable; it ranges from minimum of 8 minutes, and a maximum of 30 minutes. The default value is 20 minutes.

**Minimum On/Off Time:** It is a minimum time for the compressor to stay On/Off. The default value is 3 minutes.

**Reversing Valve:** Depending upon heating/cooling demand, a user can energize the Reversing Valve on Heating or Cooling.



## Fan / Humidity

'Fan / Humidity'  allows a user to configure the following settings:

1. Fan Operation
2. Humidity Control
3. Filter Alarm




Figure 49: Fan/Humidity Screen (Air Source Heat Pump)

### Fan Operation

**Fan Mode Control:** During Setpoint Mode and Occupancy Mode, the fan can be configured to operate based on the selected Fan Mode Control as describe below:

#### Fan Operation

**Fan Mode Control**  Auto  On  On Cool/Auto Heat

**Auto:** When this option is selected, Fan cycles ON when:

1. Cooling or heating is selected or
2. During Unoccupied mode only when called to run by cooling or heating demand.

**On:** When this option is selected the fan runs continuously for ventilation.

**On Cool/Auto Heat:** When this option is selected the fan runs continuously in cooling mode. In heating mode the fan cycles on only when the heating signal calls for the fan to run.

## Humidity Control

### Humidity Control

Fan Circulation Cycle	<input checked="" type="radio"/> Enable	<input type="radio"/> Disable
Trigger Setpoint	<input type="text" value="100"/>	%RH [0-100]
Reset Deadband	<input type="text" value="5"/>	% [0-100]
Fan On Cycle Time	<input type="text" value="300"/>	s [300-3000]
Fan Off Cycle Time	<input type="text" value="1800"/>	s [300-3000]

**Fan Circulation Cycle:** When a user selects the 'Enable' option from Fan Circulation Cycle, it allows a user to edit the Trigger Setpoint, Reset Deadband, and Fan On/Off Cycle Time.

**Trigger Setpoint & Reset Deadband:** When sensed humidity equals or exceeds humidity trigger setpoint, the fan cycles ON/OFF at low speed until sensed humidity drops below the trigger setpoint minus the reset deadband.

**Fan On Cycle Time:** This field allows a user to enter a time for fan ON cycle when stratification and humidity control is active. The default value is 300 seconds.

**Fan Off Cycle Time:** This field allows a user to enter a time for fan OFF cycle when stratification and humidity control is active. The default value is 1800 seconds.

## Filter Alarm

### Filter Alarm

Runtime Hours	<input type="text" value="3000"/>	h [0-3000]
---------------	-----------------------------------	------------

**Runtime Hours:** A filter alarm activates after the Runtime Hours mentioned in this field. The default value is 3000 hours.

## Economizer


Select Economizer  from Configuration parameters. It is used to configure the economizer settings in TB3026B controller



Figure 50: Economizer Screen (Air Source Heat Pump)

### Configuration

**Minimum Position:** When either the occupied command or the After-hours Timer is ON, the current minimum position is set to the specified Economizer Minimum Position; otherwise, it is zero. The default minimum position is 20%.

**Outside Air Lockout:** The economizer is forced to Minimum position when Outside Air Temperature goes above the Outside Air Lockout setpoint. The default value is 68° F.

**Supply Air Low Limit:** The economizer is forced to Minimum position when Supply Temperature goes below the Supply Air Low Limit. The default value is 45° F.

## I/O Configurations

Select I/O Configurations  from Configuration parameters. This configuration is used for Terminal Assignment & Output Configuration.




Figure 51: I/O Configurations Screen (Air Source Heat Pump)

### Terminal Assignment

After completing the 'Air Source Heat Pump' configuration, selected inputs and outputs get automatically assigned to the TB3026B controller's input and output terminals. However, a user can assign the outputs as 'Economizer Open' & 'Economizer Close' to BO-4 & BO-5 and inputs as 'BMS Sensor' or 'Remote Space Temp' or 'Outdoor Air Temp' to AI/B10 respectively.




Figure 52: Terminal Assignment View (Air Source Heat Pump)

## Output Configuration

### Output Configuration

Economizer Damper Stroke Time  s (0-300)

When a user assigns the outputs, 'Economizer Open' and 'Economizer Close' to BO-4 and BO-5 respectively, 'Economizer Damper Stroke Time' can be mentioned in the field 'Output Configuration'. The default value is 3 seconds.

When 'Fan Speed' is selected as 'Three Speed Fan', the 'Terminal Assignment' view changes as follows:

**TB3026B Configuration View**

Application | General Display | Schedule Options | Zone Setpoints | Control Settings | Fan/Humidity | Economizer | I/O Configuration

**Terminal Assignment**

Aux Heat	20	BO-5	24VAC Hot	1	24VAC Hot
Reversing Valve	19	BO-4	Relay 24VAC	2	Relay 24VAC
HP Compressor	18	BO-3	BO-0	3	Fan Low
Fan High	17	BO-2	BO-1	4	Fan Medium
GND	16	GND	GND	5	GND
Economizer	15	AO-0	AU/BI0	6	BMS Sensor
COM	14	COM	COM	7	COM
Fan Speed	13	AO-1	AU/BI1	8	Standby
MSTP +	12	MSTP +	COM	9	COM
MSTP -	11	MSTP -	AU/BI2	10	SA Temp or Alarm

When 'Output Stage' is selected as 'One Compressor Stage/Two Aux Stages', the 'Terminal Assignment' view changes as follows:

**TB3026B Configuration View**

Application | General Display | Schedule Options | Zone Setpoints | Control Settings | Fan/Humidity | Economizer | I/O Configuration

**Terminal Assignment**

Unused	20	BO-5	24VAC Hot	1	24VAC Hot
Heat Stage 2	19	BO-4	Relay 24VAC	2	Relay 24VAC
Heat Stage 1	18	BO-3	BO-0	3	Fan
Reversing Valve	17	BO-2	BO-1	4	HP Compressor
GND	16	GND	GND	5	GND
Economizer	15	AO-0	AU/BI0	6	BMS Sensor
COM	14	COM	COM	7	COM
Fan Speed	13	AO-1	AU/BI1	8	Standby
MSTP +	12	MSTP +	COM	9	COM
MSTP -	11	MSTP -	AU/BI2	10	SA Temp or Alarm

## Water Source Heat Pump




Figure 53: Water Source Heat Pump Window

### Output Stages

Equipment Type 'Water Source Heat Pump' consists of two types of 'Output Stages'

1. One Compressor Stage/One Aux Heat Stage
2. One Compressor Stage/Two Aux Heat Stages

### Output Stages

One Compressor Stage and One Aux Heat Stage

One Compressor Stage and One Aux Heat Stage

One Compressor Stage and Two Aux Heat Stages

### One Compressor Stage and One Aux Heat Stage:

Select this option if One stage of compressor and one stage of Auxiliary Heating is required in the application

### One Compressor Stage and Two Aux Heat Stage:

Select this option if Two stages of Compressors and Two stages of Auxiliary Heating are required in the application

## General Display

Click 'General Display'  to view the general display settings. The following parameters are used to configure the controller's display settings.

1. Engineering Units
2. Time Functions
3. Display
4. Contractor Access Codes




Figure 54: General Display Screen (Water Source Heat Pump)

## Engineering Units

### Engineering Units

Application Unit  English  Metric

**Application Unit:** The application units contain two options to change the controller's units. By default, the controller's application units are set to 'English'. Application Unit can be changed to 'English' or 'Metric'.

## Time Function

### Time Time Issues

**Clock Format**  12 Hour  24 Hour  
**Daylight Savings Time**  Disabled  Pre-2007  Post-2007

**Clock Format:** A user can select a clock format as 12-hour format or 24-hour format.

**Daylight Savings Time:** This feature enables to select the Daylight Savings Time settings. By default, Daylight Savings Time is set to 'Disabled'. Daylight Savings Time can be changed to 'Pre-2007' or 'Post-2007'.

## Display

This feature allows a user to select the Display settings.

### Display

**Outside Air Temp**  Show  Hide  
**Clock Adjustment**  Allow  Deny  
**Keypad Lockout**  Unlocked  Locked  Temperature Settings Only  
**Backlight**  Delayed Off  Always On

**Outside Air Temp:** A user has an option to hide/show an outside air temperature.

**Clock Adjustment:** This option allows a user to enable/disable the clock adjustment on the controller display.

**Keypad Lockout:** This option allows a user to lock/unlock the clock adjustment. When an option, 'Temperature Settings Only' is selected, a user can only set the temperature through keypad.

**Backlight:** A user can keep the backlight always on or set to delayed off through this option.



## Contractor Access Codes

### Contractor Access Codes

**Field Service Pin**   Require PIN Code  
**Installer Service Pin**   Require PIN Code

An access to the controller can be restricted with the help of Access Codes.

Field Service Pin and Installer Service Pin can be set. These codes should be enabled to restrict an access to the controller.

	<b>Note:</b>
<p>A user can set only numerical PIN code for 'Field Service Pin' and 'Installer Service Pin'. PIN codes should be set within 0000 – 9999. The following Error Window pops up if this field is left blank after selecting.</p>	
	



## Schedule Options


'Schedule Options'  tab displays Schedule options. The following parameters are used to configure the schedule options (i.e. Occupancy Configuration and Bypass and Standby).



Figure 55: Schedule Options Screen (Water Source Heat Pump)

### Occupancy Configuration

**Schedule Model:** A user can set the device's schedule model as;

1. Setpoint Mode or
2. Occupancy Mode

**Setpoint Mode:** In setpoint mode, the controller logically emulates residential thermostats. The space temperature is controlled to "SP Mode Cooling SP" and "SP Mode Heating SP". Each schedule period consists of a start time, a heating setpoint, and a cooling setpoint.

**If a user selects 'Setpoint Mode' from the available 'Schedule Model', the fields for 'Comm Fails Occupied' and 'System Block' settings become disabled.**

#### Occupancy Configuration



**Occupancy Mode:** By default, 'Schedule Model' is in 'Occupancy Mode'. The system will be switched to 'Occupied Mode' when the occupancy sensor detects occupancy. Occupied Mode allows a user to configure 'Comm Fails Occupied', 'System Block' & 'Internal Schedule' settings.

### Occupancy Configuration

**Schedule Model**  Setpoint Mode  Occupancy Mode  
**Comm Fails Occupied**  Disable  Enable  
**System Block**  Hide  Show Unoccupied  Show Unoccupied and Off  
**Internal Schedule**  Disable  Two Periods  Four Periods

**Comm Fails Occupied:** It allows a user to switch the system in Occupied Mode in case of MS/TP communication failure. If the MS/TP communication fails, the system enters into Occupied Mode when this option is selected as 'Enable', otherwise the system remains in its current state when this option is selected as 'Disable'.

**System Block:** The System Block is hidden when the schedule model is in 'Setpoint Mode'. When the schedule model is in 'Occupancy Mode', it allows a user to switch between the available options. Selecting "Show Unoccupied/Off" places the controller in unoccupied state.

**Internal schedule:** It can be configured in both Occupancy Mode & Setpoint Mode. By default, 'Internal Schedule' is 'Disable'.

If the internal schedule is 'Disable', a user can adjust the setpoint (within setpoint limits).

### Display Settings

When a user selects, 'Two Periods' or 'Four Periods' options an additional 'Display Settings' appears as follows:

#### Display Settings

**Schedule Access**  None  View  Edit  
**Vacation Hold**  Allow  Deny  
**Permanent Hold**  Allow  Deny

**Schedule Access:** When a user selects 'Edit', it allows a user to view and edit the schedule and when a user selects 'View', it allows a user to view the schedule. When a user selects 'None', it will not allow a user to view or edit the schedule.

**Vacation Hold:** It allows/denies a user to override the scheduled setpoint from TB3026B display to "Vacation Hold".

**Permanent Hold:** It allows/denies a user to override the scheduled setpoint from TB3026B display to "Permanent Hold".

### Bypass and Standby


#### Bypass and Standby

**Bypass Time**  hr (0.2-9.5)  
**Standby Delay**  s (0-3600)

**Bypass Time:** In the Unoccupied state, it forces the controller into the occupied state for up to 4 hours (default value). The override time limit is adjustable from a minimum of 0.2hours to a maximum of 9.5 hours.

**Standby Delay:** In Occupied Mode, if any window or door is opened and closed with no motion detected after the time mentioned for the Standby Delay, the room status switches to Standby state. The default value is 180 seconds.

## Zone Setpoints

Zone Setpoints  , allows a user to set the following parameters as per the requirement:

1. Temperature Setpoints
2. Setpoint Limits
3. Standby Settings
4. Display Options



Figure 56: Zone Setpoints Screen (Occupancy Mode)

### Temperature Setpoints

#### Temperature Setpoints

Occupied Setpoint	<input type="text" value="70.0"/> °F [45.0-99.0]
Cooling Offset	<input type="text" value="2.0"/> Δ°F [0.0-12.1]
Heating Offset	<input type="text" value="1.0"/> Δ°F [0.0-12.1]
Unoccupied Heating Setpoint	<input type="text" value="55.0"/> °F [45.0-99.0]
Unoccupied Cooling Setpoint	<input type="text" value="55.0"/> °F [45.0-99.0]

**Occupied Setpoint:** It is a setpoint in Occupied Mode. Enter the value within the range of 45 °F to 99 °F. The default value is 70 °F.

**Cooling Offset:** In the Occupied state, the cooling setpoint is calculated as cooling offset plus occupied setpoint. Enter

the value within the range of 0Δ°F to 12.1Δ°F. The default value is 2 Δ°F.

**Heating Offset:** In the Occupied state, the heating setpoint is calculated as heating offset minus occupied setpoint. Enter the value within the range of 0Δ°F to 12.1Δ°F. The default value is 1 Δ°F.

**Unoccupied Heating Setpoint:** It is a setpoint for Heating in Unoccupied mode. Enter the value within the range of 45 °F to 99 °F. The default value is 55 °F.

**Unoccupied Cooling Setpoint:** It is a setpoint for Cooling in Unoccupied mode. Enter the value within the range of 45 °F to 99 °F. The default value is 55 °F.

## Setpoint Limits



### Setpoint Limits

Setpoint High Limit  [45.0-99.0]

Setpoint Low Limit  [45.0-99.0]

**Setpoint High Limit:** A user can enter a Setpoint High Limit in Occupied Mode within the range of 45 °F to 99 °F. The default value is 78 °F.

**Setpoint Low Limit:** A user can enter a Setpoint Low Limit in Occupied Mode within the range of 45 °F to 99 °F. The default value is 62 °F.

☰	Note:
<p>1. <i>Unoccupied Cooling Setpoint should always be set GREATER than Unoccupied Heating Setpoint.</i></p> <p><i>Following Error window appears if Unoccupied Cooling Setpoint is set lower than Unoccupied Heating Setpoint.</i></p>  <p>2. <i>Setpoint High Limit should always be set GREATER than Setpoint Low Limit.</i></p> <p><i>Following Error window appears if Setpoint High Limit is set lower than Setpoint low Limit.</i></p> 	

## Standby Settings

### Standby Settings

Standby Offset  [0.0-12.1]

Reverse Standby Input  Normal [NO]  Reverse [NC]

Standby state is a power-saving function of Occupancy mode. It occurs when the space is scheduled as Occupied, but sensors detect (When the Standby input is active) there are no humans in the space.

**Standby Offset:** In this case, the Standby Offset relaxes the occupied setpoints. The value of the Standby Offset [SO] can be set between a minimum of 0Δ°F and a maximum of 12.1Δ°F degrees. The default value is 4 Δ°F.

**Reverse Standby Input:** It allows a user to configure two types of inputs, 'Normally Open (NO)' and 'Normally Close (NC)'.

## Display Options

### Display Options

Unoccupied Setpoints  Hide  Show


**Unoccupied Setpoints:** It allows a user to either 'Hide' or 'Show' the unoccupied setpoint.

When a user selects Schedule Model under the 'Schedule Options' tab to 'Setpoint Mode', the 'Zone Setpoints' configuration window appears as follows:



Figure 57: Zone Setpoint Screen (Setpoint Mode)

## Control Settings

'Control Settings'  allows a user to configure following settings:

1. Cooling PI Control.
2. Heating PI Control.
3. Aux Staged Heating
4. Compressor Settings.




Figure 58: Control Settings Screen (Water Source Heat Pump)

### Cooling PI Control

#### Cooling PI Control

Proportional Constant  $K_p$   (10.00-40.00)  
 Integral Constant  $K_i$   (0.50-2.00)  
 OAT Lockout Setpoint  (°F 45.0-99.0)

**Proportional Constant  $K_p$ :** A user can enter a value for  $K_p$  within the range of 10 to 40. The default value is 20.

**Integral Constant  $K_i$ :** A user can enter a value for  $K_i$  within the range of 0.50 to 2. The default value is 1.

**OAT Lockout Setpoint:** Cooling PI control will lockout when outside Temperature increases above OAT (Cooling) Lockout Setpoint. The default value is 55 °F.

### Aux Staged Heating

#### Aux Staged Heating

Cycle Time  min (8-30)  
 Minimum On/Off Time  min (0-15)

**Cycle Time:** The Cycle Time ranges from minimum of 8 minutes, and a maximum of 30 minutes. The default value is 15 minutes.

**Minimum On/Off Time:** It is a minimum On/Off time for the Auxiliary Heating. The default value is 3 minutes.

### Heating PI Control

#### Heating PI Control

Proportional Constant  $K_p$   (10.00-40.00)  
 Integral Constant  $K_i$   (0.50-2.00)  
 OAT Lockout Setpoint  (°F 45.0-99.0)

**Proportional Constant  $K_p$ :** A user can enter a value for  $K_p$  within the range of 10 to 40. The default value is 20.

**Integral Constant  $K_i$ :** A user can enter a value for  $K_i$  within the range of 0.50 to 2. The default value is 1.

**OAT Lockout Setpoint:** Heating PI control will lockout when outside Temperature decreases below OAT (Heating) Lockout Setpoint. The default value is 62 °F.

### Compressor Settings

#### Compressor Settings


Cycle Time  min (8-30)  
 Minimum On/Off Time  min (0-15)  
 Reversing Valve  Energized on Heating  Energized on Cooling

**Cycle Time:** The Compressor Cycle Time is adjustable; it ranges from minimum of 8 minutes, and a maximum of 30 minutes. The default value is 20 minutes.

**Minimum On/Off Time:** It is a minimum time for the compressor to stay On/Off. The default value is 3 minutes.

**Reversing Valve:** Depending upon heating/cooling demand, a user can Energize the Reversing Valve on Heating or Cooling.

## Fan / Humidity

'Fan / Humidity'  allows a user to configure the following settings:

1. Fan Operation
2. Humidity Control
3. Filter Alarm




Figure 59: Fan/Humidity Screen (Water Source Heat Pump)

### Fan Operation

**Fan Mode Control:** During Setpoint Mode and Occupancy Mode, the fan can be configured to operate based on the selected Fan Mode Control as describe below;

#### Fan Operation

**Fan Mode Control**  Auto  On  On Cool/Auto Heat

**Auto:** When this option is selected, Fan cycles ON when:

1. Cooling or heating is selected or
2. During Unoccupied mode only when called to run by cooling or heating demand.

**On:** When this option is selected the fan runs continuously for ventilation.

**On Cool/Auto Heat:** When this option is selected the fan runs continuously in cooling mode. In heating mode the fan cycles on only when the heating signal calls for the fan to run.



## Humidity Control

### Humidity Control

Fan Circulation Cycle  Enable  Disable

Trigger Setpoint  %RH [0-100]

Reset Deadband  % [0-100]

Fan On Cycle Time  s [10-3000]

Fan Off Cycle Time  s [10-3000]

**Fan Circulation Cycle:** When a user selects the ‘Enable’ option from Fan Circulation Cycle, it allows a user to edit the Trigger Setpoint, Reset Deadband, and Fan On/Off Cycle Time.

**Trigger Setpoint & Reset Deadband:** When sensed humidity equals or exceeds humidity trigger setpoint, the fan cycles ON/OFF at low speed until sensed humidity drops below the trigger setpoint minus the reset deadband.

**Fan On Cycle Time:** This field allows a user to enter a time for fan ON cycle when stratification and humidity control is active. The default value is 300 seconds.

**Fan Off Cycle Time:** This field allows a user to enter a time for fan OFF cycle when stratification and humidity control is active. The default value is 1800 seconds.

## Filter Alarm

### Filter Alarm

Runtime Hours  [10-3000]

**Runtime Hours:** A filter alarm activates after the Runtime Hours mentioned in this field. The default value is 3000 hours.

## Economizer


Select Economizer  from Configuration parameters. It is used to configure the economizer settings in TB3026B controller



Figure 60: Economizer Screen (Water Source Heat Pump)

### Configuration

**Minimum Position:** When either the occupied command or the After-hours Timer is ON, the current minimum position is set to the specified Economizer Minimum Position; otherwise, it is zero. The default minimum position is 20%.

**Outside Air Lockout:** The economizer is forced to Minimum position when Outside Air Temperature goes above the Outside Air Lockout setpoint. The default value is 68° F.

**Supply Air Low Limit:** The economizer is forced to Minimum position when Supply Temperature goes below the Supply Air Low Limit. The default value is 45° F.

## I/O Configurations

Select I/O Configurations  from Configuration parameters. This configuration is used for Terminal Assignment & Output Configuration.




Figure 61: I/O Configurations Screen (Water Source Heat Pump)

### Terminal Assignment

After completing the 'Water Source Heat Pump' configuration, selected inputs and outputs get automatically assigned to the TB3026B controller's input and output terminals. However, a user can assign the outputs as 'Economizer Open' & 'Economizer Close' to BO-4 & BO-5 and inputs as 'BMS Sensor' or 'Remote Space Temp' or 'Outdoor Air Temp' to AI/BI0 respectively.




Figure 62: Terminal Assignment View (Water Source Heat Pump)

## Output Configuration

### Output Configuration

**Economizer Damper Stroke Time**  s [0 - 300]

When a user assigns the outputs, 'Economizer Open' and 'Economizer Close' to BO-4 and BO-5 respectively, 'Economizer Damper Stroke Time' can be mentioned in the field 'Output Configuration'. The default value is 3 seconds.

When 'Output Stage' is selected as 'One Compressor Stage/Two Aux Heat Stages', the 'Terminal Assignment' view changes as follows:

**TB3026B Configuration View**

Application | General Display | Schedule Options | Zone Setpoints | Control Settings | Fan/Humidity | Economizer | I/O Configuration

**Terminal Assignment**

Unused	20	BO-5	24VAC Hot	1	24VAC Hot
Heat Stage 2	19	BO-4	Relay 24VAC	2	Relay 24VAC
Heat Stage 1	18	BO-3	BO-4	3	Fan
Reversing Valve	17	BO-2	BO-1	4	HP Compressor
GND	16	GND	GND	5	GND
Economizer	15	AD-0	AU/BI0	6	RMS Sensor
COM	14	COM	COM	7	COM
Fan Speed	13	AD-1	AU/BI1	8	Standby
MSTP +	12	MSTP +	COM	9	COM
MSTP -	11	MSTP -	AU/BI2	10	SA Temp or Alarm

## Two Pipe Fan Coil Unit





Figure 63: Two Pipe Fan Coil Unit Window

### Fan Speeds

A user can select Two types of 'Fan Speeds' when the output stage is configured as 'One Compressor Stage and One Aux Heat Stage'.

1. Single Speed Fan
2. Three Speed Fan


#### Fan Speeds



## Auxiliary Heat

A user can select heating stages from the following options:


### Auxiliary Heat



A screenshot of a dropdown menu titled "Auxiliary Heat". The menu is open, showing three options: "Single Stage Aux Heat" (top), "No Staged Aux Heat" (middle), and "Single Stage Aux Heat" (bottom, highlighted with a dark background).


**No Stage Aux Heat:** If auxiliary heating is not required in the system, select this option.

**Single Stage Aux Heat:** For single auxiliary heating stage, select this option.

	<b>Note:</b>
<p><i>The Auxilliary heat can be selected as 'No Stage Aux Heat' or 'Single Stage Aux Heat' only when Three Speed Fan is configured.</i></p>	


## Valve Actuator

### Valve Actuator




A screenshot of a dropdown menu titled "Valve Actuator". The menu is open, showing three options: "Floating / Analog" (top), "Two-Position" (middle), and "Floating / Analog" (bottom, highlighted with a dark background).

Valve actuator can be configured as 'Two-Position' or 'Floating/Analog' based on application.

	<b>Note:</b>
<p><i>The valve actuator can be selected as 'Two-Position' or 'Floating/Analog' only when 'Three Speed Fan' is configured.</i></p>	

## Input Configuration

### Input Configuration



A screenshot of a dropdown menu titled "Input Configuration". The menu is open, showing four options: "Water Temperature Sensor" (top), "Remote Space Temp Sensor" (second), "Door Switch" (third), and "Water Temperature Sensor" (bottom, highlighted with a dark background).

Input Configuration can be configured as 'Remote Space Temp Sensor' or 'Door Switch' or 'Water Temperature Sensor' based on application.

## General Display

Click 'General Display'  to view the general display settings. The following parameters are used to configure the controller's display settings.

1. Engineering Units
2. Time Functions
3. Display
4. Contractor Access Codes



Figure 64: General Display Screen (Two Pipe Fan Coil Unit)

## Engineering Units

### Engineering Units

**Application Unit**  English  Metric

**Application Unit:** The application units contain two options to change the controller's units. By default, the controller's application units are set to 'English'. Application Unit can be changed to 'English' or 'Metric'.

## Time Function

### Time Time Issues

**Clock Format**  12 Hour  24 Hour  
**Daylight Savings Time**  Disabled  Pre-2007  Post-2007

**Clock Format:** A user can select a clock format as 12-hour format or 24-hour format.

**Daylight Savings Time:** This feature enables to select the Daylight Savings Time settings. By default, Daylight Savings Time is set to 'Disabled'. Daylight Savings Time can be changed to 'Pre-2007' or 'Post-2007'.

## Display

This feature allows a user to select the Display settings.

### Display

**Outside Air Temp**  Show  Hide  
**Clock Adjustment**  Allow  Deny  
**Keypad Lockout**  Unlocked  Locked  Temperature Settings Only  
**Backlight**  Delayed Off  Always On

**Outside Air Temp:** A user has an option to hide/show an outside air temperature.

**Clock Adjustment:** This option allows a user to enable/disable the clock adjustment on the controller display.

**Keypad Lockout:** This option allows a user to lock/unlock the clock adjustment. When an option, 'Temperature Settings Only' is selected, a user can only set the temperature through keypad.

**Backlight:** A user can keep the backlight always on or set to delayed off through this option.



## Contractor Access Codes

### Contractor Access Codes

**Field Service Pin**   Require PIN Code  
**Installer Service Pin**   Require PIN Code

An access to the controller can be restricted with the help of Access Codes.

Field Service Pin and Installer Service Pin can be set. These codes should be enabled to restrict an access to the controller.

	<b>Note:</b>
<p>A user can set only numerical PIN code for 'Field Service Pin' and 'Installer Service Pin'. PIN codes should be set within 0000 – 9999. The following Error Window pops up if this field is left blank after selecting.</p>	
	



## Schedule Options

'Schedule'  tab displays Schedule options.

The following parameters are used to configure the schedule options (i.e. Occupancy Configuration and Bypass and Standby)




Figure 65: Schedule Options Screen (Two Pipe Fan Coil Unit)

### Occupancy Configuration

**Schedule Model:** A user can set the device's schedule model as;

1. Setpoint Mode or
2. Occupancy Mode

**Setpoint Mode:** In setpoint mode, the controller logically emulates residential thermostats. The space temperature is controlled to "SP Mode Cooling SP" and "SP Mode Heating SP". Each schedule period consists of a start time, a heating setpoint, and a cooling setpoint.

**If a user selects 'Setpoint Mode' from the available 'Schedule Model', the fields for 'Comm Fails Occupied' and 'System Block' settings become disabled.**

#### Occupancy Configuration



**Occupancy Mode:** By default, 'Schedule Model' is in 'Occupancy Mode'. The system will be switched to 'Occupied Mode' when the occupancy sensor detects occupancy. Occupied Mode allows a user to configure 'Comm Fails Occupied', 'System Block' & 'Internal Schedule' settings.

### Occupancy Configuration

Schedule Model     Setpoint Mode     Occupancy Mode  
 Comm Fails Occupied     Disable     Enable  
 System Block     Hide     Show Unoccupied     Show Unoccupied and Off  
 Internal Schedule     Disable     Two Periods     Four Periods

**Comm Fails Occupied:** It allows a user to switch the system in Occupied Mode in case of MS/TP communication failure. If the MS/TP communication fails, the system enters into Occupied Mode when this option is selected as 'Enable', otherwise the system remains in its current state when this option is selected as 'Disable'.

**System Block:** The System Block is hidden when the schedule model is in 'Setpoint Mode'. When the schedule model is in 'Occupancy Mode', it allows a user to switch between the available options. Selecting "Show Unoccupied/Off" places the controller in unoccupied state.

**Internal schedule:** It can be configured in both Occupancy Mode & Setpoint Mode. By default, 'Internal Schedule' is 'Disable'.  
 If the internal schedule is 'Disable', a user can adjust the setpoint (within setpoint limits).

### Display Settings

When a user selects, 'Two Periods' or 'Four Periods' options an additional 'Display Settings' appears as follows:

#### Display Settings

Schedule Access     None     View     Edit  
 Vacation Hold     Allow     Deny  
 Permanent Hold     Allow     Deny

**Schedule Access:** When a user selects 'Edit', it allows a user to view and edit the schedule and when a user selects 'View', it allows a user to view the schedule. When a user selects 'None', it will not allow a user to view or edit the schedule.

**Vacation Hold:** It allows/denies a user to override the scheduled setpoint from TB3026B display to "Vacation Hold".

**Permanent Hold:** It allows/denies a user to override the scheduled setpoint from TB3026B display to "Permanent Hold".

### Bypass and Standby


#### Bypass and Standby

Bypass Time     hr (0.2-9.5)  
 Standby Delay     s (0-3600)

**Bypass Time:** In the Unoccupied state, it forces the controller into the occupied state for up to 4 hours (default value). The override time limit is adjustable from a minimum of 0.2 hours to a maximum of 9.5 hours.

**Standby Delay:** In Occupied Mode, if any window or door is opened and closed with no motion detected after the time mentioned for the Standby Delay, the room status switches to Standby state. The default value is 180 seconds.

## Zone Setpoints


Zone Setpoints  , allows a user to set the following parameters as per the requirement:

1. Temperature Setpoints
2. Setpoint Limits
3. Standby Settings
4. Display Options



Figure 66: Zone Setpoints Screen (Occupancy Mode)

### Temperature Setpoints



**Occupied Setpoint:** It is a setpoint in Occupied Mode. Enter the value within the range of 45 °F to 99 °F. The default value is 70°F.

**Cooling Offset:** In the Occupied state, the cooling setpoint is calculated as cooling offset plus occupied setpoint. Enter the value within the range of 0Δ°F to 12.1Δ°F. The default value is 2 Δ°F.

**Heating Offset:** In the Occupied state, the heating setpoint is calculated as heating offset minus occupied setpoint. Enter the value within the range of 0Δ°F to 12.1Δ°F. The default value is 1 Δ°F.

**Unoccupied Heating Setpoint:** It is a setpoint for Heating in Unoccupied mode. Enter the value within the range of 45 °F to 99 °F. The default value is 55 °F.

**Unoccupied Cooling Setpoint:** It is a setpoint for Cooling in Unoccupied mode. Enter the value within the range of 45 °F to 99 °F. The default value is 85 °F.

## Setpoint Limits




### Setpoint Limits

Setpoint High Limit  °F [45.0 - 99.0]

Setpoint Low Limit  °F [45.0 - 99.0]

**Setpoint High Limit:** A user can enter a Setpoint High Limit in Occupied Mode within the range of 45 °F to 99 °F. The default value is 78°F.

**Setpoint Low Limit:** A user can enter a Setpoint Low Limit in Occupied Mode within the range of 45 °F to 99 °F. The default value is 62°F.

	<b>Note:</b>
<p>1. <i>Unoccupied Cooling Setpoint should always be set GREATER than Unoccupied Heating Setpoint.</i></p> <p><i>Following Error window appears if Unoccupied Cooling Setpoint is set lower than Unoccupied Heating Setpoint.</i></p> 	
<p>2. <i>Setpoint High Limit should always be set GREATER than Setpoint Low Limit.</i></p> <p><i>Following Error window appears if Setpoint High Limit is set lower than Setpoint low Limit.</i></p> 	

## Standby Settings

### Standby Settings

Standby Offset  °F [0.0 - 12.1]

Reverse Standby Input  Normal [NO]  Reverse [NC]

Standby state is a power-saving function of Occupancy mode. It occurs when the space is scheduled as Occupied, but sensors detect (When the Standby input is active) there are no humans in the space.

**Standby Offset:** In this case, the Standby Offset relaxes the occupied setpoints. The value of the Standby Offset [SO] can be set between a minimum of 0 Δ°F and a maximum of 12.1 Δ°F degrees. The default value is 4 Δ°F.

**Reverse Standby Input:** It allows a user to configure two types of inputs, 'Normally Open (NO)' and 'Normally Close (NC)'.

## Display Options

### Display Options

Unoccupied Setpoints  Hide  Show


**Unoccupied Setpoints:** It allows a user to either 'Hide' or 'Show' the unoccupied setpoint.

When a user selects Schedule Model under the 'Schedule Options' tab to 'Setpoint Mode', the 'Zone Setpoints' configuration window appears as follows:



Figure 67: Zone Setpoint Screen (Setpoint Mode)

## Control Settings

'Control Settings'  allows a user to configure following settings:

1. Cooling PI Control
2. Heating PI Control
3. Aux Staged Heating
4. Two-Position Valves
5. FCU Configuration




Figure 68: Control Settings Screen (Two Pipe Fan Coil Unit)

### Cooling PI Control

#### Cooling PI Control

Proportional Constant  $K_p$  20.00 [10.00 - 40.00]  
 Integral Constant  $K_i$  1.00 [0.50 - 2.00]  
 OAT Lockout Setpoint 55.0 °F [45.0 - 65.0]

**Proportional Constant  $K_p$ :** A user can enter a value for  $K_p$  within the range of 10 to 40. The default value is 20.

**Integral Constant  $K_i$ :** A user can enter a value for  $K_i$  within the range of 0.50 to 2. The default value is 1.

**OAT Lockout Setpoint:** Cooling PI control will lockout when outside Temperature decreases below OAT (Cooling) Lockout Setpoint. The default value is 55 °F.

## Heating PI Control

### Heating PI Control

Proportional Constant  $K_p$   [10.00-40.00]

Integral Constant  $K_i$   [0.50-2.00]

OAT Lockout Setpoint  [40-80]

**Proportional Constant  $K_p$ :** A user can enter a value for  $K_p$  within the range of 10 to 40. The default value is 20.

**Integral Constant  $K_i$ :** A user can enter a value for  $K_i$  within the range of 0.50 to 2. The default value is 1.

**OAT Lockout Setpoint:** Heating PI control will lockout when outside Temperature increases above OAT (Heating) Lockout Setpoint. The default value is 62 °F.

### Aux Staged Heating

A user can configure the Cycle Time & Minimum On/Off Time when a 'Single Stage Auxiliary Heat' is selected in the application.

### Aux Staged Heating

Cycle Time  min [3-30]

Minimum On/Off Time  min [0-15]

**Cycle Time:** The Cycle Time ranges from minimum of 8 minutes, and a maximum of 30 minutes. The default value is 15 minutes.

**Minimum On/Off Time:** It is a minimum On/Off time for the Auxiliary Heating. The default value is 3 minutes.

## Two-Position Valves

### Two-Position Valves

Cycle Time  min [3-30]

Minimum On Time  s [0-300]

Minimum Off Time  s [0-300]

Heating/Cooling Valve Control 

- On Off
- Analog To Binary
- Thermal Valve

**Cycle Time:** Two-Position Valve cycle time ranges from minimum of 3 minutes, and a maximum of 30 minutes. The default value is 15 minutes.

**Minimum On Time:** It is a minimum time for the compressor to stay On.

**Minimum Off Time:** It is a minimum time for the compressor to stay Off.

**Heating/Cooling Valve Control:** Physical heating/cooling valve control has three options

**On Off:** This option selects the opening and closing of heating valve.

**Analog To Binary:** In this mode the valve is remains open for Cycle Time.

**Thermal valve:** This option allows a user to select a Thermal valve for Heating/Cooling Valve Control.

## FCU Configuration

A user can configure the Water Temperature when 'Floating/Analog' valve actuator is selected in the application.

### FCU Configuration

Water Temperature  Local  Remote

**Water Temperature:** The water temperature can be monitored either by local or by remote entity (default inactive, 'Local Mode').

When 'Fan Speeds' is selected as 'Three Speed Fan', the 'Control Settings' view changes as follows:

The screenshot shows the 'Control Settings' tab for a TB3026B unit. The 'Cooling PI Control' section has a Proportional Constant Kp of 20.00, Integral Constant Ki of 1.00, and DAT Lockout Setpoint of 55.0 °F. The 'Heating PI Control' section has a Proportional Constant Kp of 20.00, Integral Constant Ki of 1.00, and DAT Lockout Setpoint of 62.0 °F. The 'Aux Staged Heating' section has a Cycle Time of 15 min and a Minimum On/Off Time of 3 min. The 'FCU Configuration' section has 'Water Temperature' set to 'Local'.

Section	Parameter	Value	Range
Cooling PI Control	Proportional Constant Kp	20.00	[10.00 - 40.00]
	Integral Constant Ki	1.00	[0.50 - 2.00]
	DAT Lockout Setpoint	55.0 °F	[45.0 - 99.0]
Heating PI Control	Proportional Constant Kp	20.00	[10.00 - 40.00]
	Integral Constant Ki	1.00	[0.50 - 2.00]
	DAT Lockout Setpoint	62.0 °F	[45.0 - 99.0]
Aux Staged Heating	Cycle Time	15 min	[3 - 30]
	Minimum On/Off Time	3 min	[0 - 15]
FCU Configuration	Water Temperature	Local	Remote

When 'Auxiliary Heat' is selected as 'No Stage Aux heat', the 'Control Settings' view changes as follows:

The screenshot shows the 'Control Settings' tab for a TB3026B unit. The 'Cooling PI Control' section has a Proportional Constant Kp of 20.00, Integral Constant Ki of 1.00, and DAT Lockout Setpoint of 55.0 °F. The 'Heating PI Control' section has a Proportional Constant Kp of 20.00, Integral Constant Ki of 1.00, and DAT Lockout Setpoint of 62.0 °F. The 'FCU Configuration' section has 'Water Temperature' set to 'Local'.

Section	Parameter	Value	Range
Cooling PI Control	Proportional Constant Kp	20.00	[10.00 - 40.00]
	Integral Constant Ki	1.00	[0.50 - 2.00]
	DAT Lockout Setpoint	55.0 °F	[45.0 - 99.0]
Heating PI Control	Proportional Constant Kp	20.00	[10.00 - 40.00]
	Integral Constant Ki	1.00	[0.50 - 2.00]
	DAT Lockout Setpoint	62.0 °F	[45.0 - 99.0]
FCU Configuration	Water Temperature	Local	Remote




When 'Valve Actuator' is selected as 'Two-Position', the 'Control Settings' view changes as follows:

The screenshot displays the 'Control Settings' view for a TB3026B controller. The interface includes a navigation bar with tabs for Application, General Display, Schedule Options, Zone Setpoints, Control Settings (selected), Fan/Humidity, and I/O Configuration. The main content area is divided into several sections:

- Cooling PI Control:**
  - Proportional Constant Kp: 20.00 [10.00-40.00]
  - Integral Constant Ki: 1.00 [0.50-2.00]
  - DAT Lockout Setpoint: 55.0 °F [45.0-65.0]
- Heating PI Control:**
  - Proportional Constant Kp: 20.00 [10.00-40.00]
  - Integral Constant Ki: 1.00 [0.50-2.00]
  - DAT Lockout Setpoint: 42.0 °F [45.0-55.0]
- Aux Staged Heating:**
  - Cycle Time: 15 min [3-30]
  - Minimum On/Off Time: 3 min [0-15]
- Two-Position Valves:**
  - Cycle Time: 15 min [3-30]
  - Minimum On Time: 60 s [0-300]
  - Minimum Off Time: 0 s [0-300]
- Heating/Cooling Valve Control:** On/Off

## Fan / Humidity

'Fan / Humidity'  allows a user to configure the following settings:

1. Fan Operation
2. Humidity Control
3. Filter Alarm




Figure 69: Fan/Humidity Screen (Two Pipe Fan Coil Unit)

### Fan Operation

**Fan Mode Control:** During occupancy & Setpoint mode, the fan operates based on the selected fan control modes.

#### Fan Operation

**Fan Mode Control**  Auto  On  On Cool/Auto Heat

**Auto:** When this option is selected, Fan cycles ON when:

1. Cooling or heating is selected or
2. During Unoccupied mode only when called to run by cooling or heating demand.

**On:** When this option is selected the fan runs continuously for ventilation.

When a user selects ‘Three Speed Fan’ in the application, the ‘Fan Operation’ parameter appears as follows:

**Fan Operation**

Fan Mode Control  Auto  On  On Cool/Auto Heat

Fan Off Selection  High Fan Off  Low Fan Off

Local User Fan Control  Enable  Disable

Low Speed Heat/Cool Demand  % [0-100]

Medium Speed Heat/Cool Demand  % [0-100]

High Speed Heat/Cool Demand  % [0-100]

**Auto:** When this option is selected, Fan cycles ON when:

1. Cooling or heating is selected or
2. During Unoccupied mode only when called to run by cooling or heating demand.

**On:** When this option is selected the fan runs continuously for ventilation.

**On Cool/Auto Heat:** When this option is selected the fan runs continuously in cooling mode. In heating mode the fan cycles on only when the heating signal calls for the fan to run.

**Local User Fan Control:** This selection allows a user to enable/disable the fan Control to local user.

**Low Speed Heat/Cool Demand:** This field allows a user to set the Heating/Cooling demand limits for the Low Speed Fan.

**Medium Speed Heat/Cool Demand:** This field allows a user to set the Heating/Cooling demand limits for the Medium Speed Fan.

**High Speed Heat/Cool Demand:** This field allows a user to set the Heating/Cooling demand limits for the High Speed Fan.

### Humidity Control

#### Humidity Control

Fan Circulation Cycle  Enable  Disable

Trigger Setpoint  %RH [0-100]

Reset Deadband  % [0-100]

Fan On Cycle Time  s [300-3600]

Fan Off Cycle Time  s [300-3600]

**Fan Circulation Cycle:** When a user selects the ‘Enable’ option from Fan Circulation Cycle, it allows a user to edit the Trigger Setpoint, Reset Deadband, and Fan On/Off Cycle Time.

**Trigger Setpoint & Reset Deadband:** When sensed humidity equals or exceeds humidity trigger setpoint, the fan cycles ON/OFF at low speed until sensed humidity drops below the trigger setpoint minus the reset deadband.

**Fan On Cycle Time:** This field allows a user to enter a time for fan ON cycle when stratification and humidity control is active. The default value is 300 seconds.

**Fan Off Cycle Time:** This field allows a user to enter a time for fan OFF cycle when stratification and humidity control is active. The default value is 1800 seconds.

### Filter Alarm


#### Filter Alarm

Runtime Hours  hr [0-9999]

**Runtime Hours:** A filter alarm activates after the Runtime Hours mentioned in this field. The default value is 3000 hours.

## I/O Configurations

Select I/O Configurations  from Configuration parameters. This configuration is used for Terminal Assignment & Output Configuration.



**Terminal Assignment**

Aux Heat	(20) BO-5	24VAC Hot	(1)	24VAC Hot
H/C Valve Close	(19) BO-4	Relay 24VAC	(2)	Relay 24VAC
H/C Valve Open	(18) BO-3	BO-0	(3)	Fan
Cool/Heat Valve	(17) BO-2	BO-1	(4)	Unused
GND	(16) GND	GND	(5)	GND
Cool/Heat Valve	(15) AD-0	AI/BI0	(6)	Supply Air Temp
COM	(14) COM	COM	(7)	COM
Fan Speed	(13) AD-1	AI/BI1	(8)	Standby
MSTP +	(12) MSTP +	COM	(9)	COM
MSTP -	(11) MSTP -	AI/BI2	(10)	Water Temp Sensor


**Output Configuration**

H/C Valve Stroke Time: 90 s [6-300]

Figure 70: I/O Configurations Screen (Two Pipe Fan Coil Unit)

### Terminal Assignment

After completing the 'Two Pipe Fan Coil Unit' configuration, selected inputs and outputs get automatically assigned to the TB3026B controller's input and output terminals. A user can assign the outputs as 'Heating/Cooling Valve Close' & 'Heating/Cooling Valve Open' to BO-4 & BO-3 respectively.



**Terminal Assignment**

Aux Heat	(20) BO-5	24VAC Hot	(1)	24VAC Hot
H/C Valve Close	(19) BO-4	Relay 24VAC	(2)	Relay 24VAC
H/C Valve Open	(18) BO-3	BO-0	(3)	Fan
Cool/Heat Valve	(17) BO-2	BO-1	(4)	Unused
GND	(16) GND	GND	(5)	GND
Cool/Heat Valve	(15) AD-0	AI/BI0	(6)	Supply Air Temp
COM	(14) COM	COM	(7)	COM
Fan Speed	(13) AD-1	AI/BI1	(8)	Standby
MSTP +	(12) MSTP +	COM	(9)	COM
MSTP -	(11) MSTP -	AI/BI2	(10)	Water Temp Sensor

Figure 71: Terminal Assignment View (Single Speed Fan)


## Output Configuration

### Output Configuration


H/C Valve Stroke Time 40 [8-500]

**H/C Valve Stroke Time:** This setting is available to configure, when 'Floating/ Analog' Valve Actuator is selected.

When 'Three Speed Fan' is configured with 'Single Stage Aux Heat', the 'Terminal Assignment' view changes as follows:



When 'No Stage Aux Heat' is configured with 'Floating/Analog' valve actuator, 'Three Speed Fan' and 'Door Switch', the 'Terminal Assignment' view changes as follows:



When 'No Stage Aux Heat' is configured with 'Two-Position' valve actuator, 'Three Speed Fan' and 'Water Temperature Sensor', the 'Terminal Assignment' view changes as follows:

**TB3026B Configuration View**

Application General Display Schedule Options Zone Setpoints Control Settings Fan/Humidity I/O Configuration

**Terminal Assignment**

Unused	20	BO-5	24VAC Hot	1	24VAC Hot
Unused	19	BO-4	Relay 24VAC	2	Relay 24VAC
Cool/Heat Valve	18	BO-3	BO-0	3	Fan Low
Fan High	17	BO-2	BO-1	4	Fan Medium
GND	16	GND	GND	5	GND
Cool/Heat Valve	15	AO-0	AI/BI0	6	Motion Sensor
COM	14	COM	COM	7	COM
Fan Speed	13	AO-1	AI/BI1	8	Door/Window Switch
MSTP +	12	MSTP +	COM	9	COM
MSTP -	11	MSTP -	AI/BI2	10	Water Temp Sensor

*Note: In the original image, a dropdown menu for terminal 6 is open, showing 'Motion Sensor' selected, with 'BMS Sensor' and another 'Motion Sensor' option visible.*

When 'Input Configuration is selected as 'Remote Space Temp Sensor' with 'No Stage Aux Heat', 'Floating/Analog' valve actuator and 'Three Speed Fan', the 'Terminal Assignment' view changes as follows:

**TB3026B Configuration View**

Application General Display Schedule Options Zone Setpoints Control Settings Fan/Humidity I/O Configuration

**Terminal Assignment**

Unused	20	BO-5	24VAC Hot	1	24VAC Hot
Unused	19	BO-4	Relay 24VAC	2	Relay 24VAC
Cool/Heat Valve	18	BO-3	BO-0	3	Fan Low
Fan High	17	BO-2	BO-1	4	Fan Medium
GND	16	GND	GND	5	GND
Cool/Heat Valve	15	AO-0	AI/BI0	6	Motion Sensor
COM	14	COM	COM	7	COM
Fan Speed	13	AO-1	AI/BI1	8	Door/Window Switch
MSTP +	12	MSTP +	COM	9	COM
MSTP -	11	MSTP -	AI/BI2	10	Remote Space Temp

*Note: In the original image, dropdown menus are open for terminals 15 and 6. Terminal 15 is set to 'B/C Valve Close' and terminal 6 is set to 'Motion Sensor'. A dropdown for terminal 10 is also open, showing 'Remote Space Temp' selected.*

## Four Pipe Fan Coil Unit





Figure 72: Four Pipe Fan Coil Unit window

### Fan Speeds

A user can select Two types of 'Fan Speeds' when the output stage is configured as 'One Compressor Stage and One Aux Heat Stage'.

1. Single Speed Fan
2. Three Speed Fan


#### Fan Speeds



### Auxiliary Heat


A user can select heating stages from the following options:

#### Auxiliary Heat




## Valve Actuator

### Valve Actuator




Valve actuator can be configured as 'Two-Position' or 'Floating', or 'Analog' based on application.

	<b>Note:</b> <i>The valve actuator can be selected as 'Two-Position' or 'Analog' only when 'Three Speed Fan' is configured. Floating valve actuator can be configured only when Single Speed Fan is configured.</i>
---	--

## Input Configuration


### Input Configuration




Input Configuration can be configured as 'Motion Sensor' or 'Remote Space Temp Sensor' based on application.

## Economizer Output

### Economizer Output



Out of the two types of parameters, select 'Analog Output' if Floating valve actuator is used. Select 'Floating Output' when analog valve actuator is used.

	<b>Note:</b> <i>Analog Type Economizer Output can be configured when Single Speed Fan is configured'. Floating Type Economizer Output can only be configured if Three Speed Fan is configured'.</i>
---	--



## General Display

Click 'General Display'  to view the general display settings. The following parameters are used to configure the controller's display settings.

1. Engineering Units
2. Time Functions
3. Display
4. Contractor Access Codes




Figure 73: General Display Screen (Four Pipe Fan Coil Unit)

## Engineering Units

### Engineering Units

Application Unit  English  Metric

**Application Unit:** The application units contain two options to change the controller's units. By default, the controller's application units are set to 'English'. Application Unit can be changed to 'English' or 'Metric'.

## Time Function

### Time Time Issues

**Clock Format**  12 Hour  24 Hour  
**Daylight Savings Time**  Disabled  Pre-2007  Post-2007

**Clock Format:** A user can select a clock format as 12-hour format or 24-hour format.

**Daylight Savings Time:** This feature enables to select the Daylight Savings Time settings. By default, Daylight Savings Time is set to 'Disabled'. Daylight Savings Time can be changed to 'Pre-2007' or 'Post-2007'.

## Display

This feature allows a user to select the Display settings.

### Display

**Outside Air Temp**  Show  Hide  
**Clock Adjustment**  Allow  Deny  
**Keypad Lockout**  Unlocked  Locked  Temperature Settings Only  
**Backlight**  Delayed Off  Always On

**Outside Air Temp:** A user has an option to hide/show an outside air temperature.

**Clock Adjustment:** This option allows a user to enable/disable the clock adjustment on the controller display.

**Keypad Lockout:** This option allows a user to lock/unlock the clock adjustment. When an option, 'Temperature Settings Only' is selected, a user can only set the temperature through keypad.

**Backlight:** A user can keep the backlight always on or set to delayed off through this option.



## Contractor Access Codes

### Contractor Access Codes


**Field Service Pin**   Require PIN Code  
**Installer Service Pin**   Require PIN Code

An access to the controller can be restricted with the help of Access Codes.

Field Service Pin and Installer Service Pin can be set. These codes should be enabled to restrict an access to the controller.

	<b>Note:</b>
<p>A user can set only numerical PIN code for 'Field Service Pin' and 'Installer Service Pin'. PIN codes should be set within 0000 – 9999. The following Error Window pops up if this field is left blank after selecting.</p>	
	

## Schedule Options

'Schedule'  tab displays Schedule options. The following parameters are used to configure the schedule options (i.e. Occupancy Configuration and Bypass and Standby)




Figure 74: Schedule Options Screen (Four Pipe Fan Coil Unit)

### Occupancy Configuration

**Schedule Model:** A user can set the device's schedule model as;

1. Setpoint Mode or
2. Occupancy Mode

**Setpoint Mode:** In setpoint mode, the controller logically emulates residential thermostats. The space temperature is controlled to "SP Mode Cooling SP" and "SP Mode Heating SP". Each schedule period consists of a start time, a heating setpoint, and a cooling setpoint.

**If a user selects 'Setpoint Mode' from the available 'Schedule Model', the fields for 'Comm Fails Occupied' and 'System Block' settings become disabled.**

#### Occupancy Configuration



**Occupancy Mode:** By default, 'Schedule Model' is in 'Occupancy Mode'. The system will be switched to 'Occupied Mode' when the occupancy sensor detects occupancy. Occupied Mode allows a user to configure 'Comm Fails Occupied', 'System Block' & 'Internal Schedule' settings.

### Occupancy Configuration

<b>Schedule Model</b>	<input type="radio"/> Setpoint Mode	<input checked="" type="radio"/> Occupancy Mode	
<b>Comm Fails Occupied</b>	<input checked="" type="radio"/> Disable	<input type="radio"/> Enable	
<b>System Block</b>	<input checked="" type="radio"/> Hide	<input type="radio"/> Show Unoccupied	<input type="radio"/> Show Unoccupied and Off
<b>Internal Schedule</b>	<input checked="" type="radio"/> Disable	<input type="radio"/> Two Periods	<input type="radio"/> Four Periods

**Comm Fails Occupied:** It allows a user to switch the system in Occupied Mode in case of MS/TP communication failure. If the MS/TP communication fails, the system enters into Occupied Mode when this option is selected as 'Enable', otherwise the system remains in its current state when this option is selected as 'Disable'.

**Vacation Hold:** It allows/denies a user to override the scheduled setpoint from TB3026B display to "Vacation Hold".

**Permanent Hold:** It allows/denies a user to override the scheduled setpoint from TB3026B display to "Permanent Hold".

**Note:**  
When Application 8 or 9 is selected, the 'Comm Fails Occupied' will be selected as 'Enable' by default and does not allow user to edit this field.

**System Block:** The System Block is hidden when the schedule model is in 'Setpoint Mode'. When the schedule model is in 'Occupancy Mode', it allows a user to switch between the available options. Selecting "Show Unoccupied/Off" places the controller in unoccupied state.

**Internal schedule:** It can be configured in both Occupancy Mode & Setpoint Mode. By default, 'Internal Schedule' is 'Disable'.

If the internal schedule is 'Disable', a user can adjust the setpoint (within setpoint limits).

### Bypass and Standby

#### Occupancy and Standby

<b>Bypass Time</b>	<input type="text" value="4.0"/>	hr(0.2-9.5)
<b>Standby Delay</b>	<input type="text" value="180"/>	s(10-3000)

**Bypass Time:** In the Unoccupied state, it forces the controller into the occupied state for up to 4 hours (default value). The override time limit is adjustable from a minimum of 0.2 hours to a maximum of 9.5 hours.

**Standby Delay:** In Occupied Mode, if any window or door is opened and closed with no motion detected after the time mentioned for the Standby Delay, the room status switches to Standby state. The default value is 180 seconds.

### Display Settings


When a user selects, 'Two Periods' or 'Four Periods' options an additional 'Display Settings' appears as follows:

#### Display Settings

<b>Schedule Access</b>	<input type="radio"/> None	<input type="radio"/> View	<input checked="" type="radio"/> Edit
<b>Vacation Hold</b>	<input checked="" type="radio"/> Allow	<input type="radio"/> Deny	
<b>Permanent Hold</b>	<input checked="" type="radio"/> Allow	<input type="radio"/> Deny	

**Schedule Access:** When a user selects 'Edit', it allows a user to view and edit the schedule and when a user selects 'View', it allows a user to view the schedule. When a user selects 'None', it will not allow a user to view or edit the schedule.

## Zone Setpoints

Zone Setpoints , allows a user to set the following parameters as per the requirement:

1. Temperature Setpoints
2. Setpoint Limits
3. Standby Settings
4. Display Options



Figure 75: Zone Setpoints Screen (Occupancy Mode)

### Temperature Setpoints

#### Temperature Setpoints

Occupied Setpoint	70.0	°F [45.0-99.0]
Cooling Offset	2.0	Δ°F [0.0-12.1]
Heating Offset	1.0	Δ°F [0.0-12.1]
Unoccupied Heating Setpoint	55.0	°F [45.0-99.0]
Unoccupied Cooling Setpoint	85.0	°F [45.0-99.0]

**Occupied Setpoint:** It is a setpoint in Occupied Mode. Enter the value within the range of 45 °F to 99 °F. The default value is 70°F.

**Cooling Offset:** In the Occupied state, the cooling setpoint is calculated as cooling offset plus occupied setpoint. Enter

the value within the range of 0Δ°F to 12.1Δ°F. The default value is 2 Δ°F.

**Heating Offset:** In the Occupied state, the heating setpoint is calculated as heating offset minus occupied setpoint. Enter the value within the range of 0Δ°F to 12.1Δ°F. The default value is 1 Δ°F.

**Unoccupied Heating Setpoint:** It is a setpoint for Heating in Unoccupied mode. Enter the value within the range of 45 °F to 99 °F. The default value is 55 °F.

**Unoccupied Cooling Setpoint:** It is a setpoint for Cooling in Unoccupied mode. Enter the value within the range of 45 °F to 99 °F. The default value is 85 °F.

## Setpoint Limits




### Setpoint Limits

Setpoint High Limit  °F [45.0 99.0]

Setpoint Low Limit  °F [45.0 99.0]

**Setpoint High Limit:** A user can enter a Setpoint High Limit in Occupied Mode within the range of 45 °F to 99 °F. The default value is 78°F.

**Setpoint Low Limit:** A user can enter a Setpoint Low Limit in Occupied Mode within the range of 45 °F to 99 °F. The default value is 62°F.

	<b>Note:</b>
<p>1. <i>Unoccupied Cooling Setpoint should always be set GREATER than Unoccupied Heating Setpoint.</i></p> <p><i>Following Error window appears if Unoccupied Cooling Setpoint is set lower than Unoccupied Heating Setpoint.</i></p> 	
<p>2. <i>Setpoint High Limit should always be set GREATER than Setpoint Low Limit.</i></p> <p><i>Following Error window appears if Setpoint High Limit is set lower than Setpoint low Limit.</i></p> 	

## Standby Settings

### Standby Settings

Standby Offset  Δ°F [0.0 12.0]

Reverse Standby Input  Normal (NO)  Reverse (NC)

Standby state is a power-saving function of Occupancy mode. It occurs when the space is scheduled as Occupied, but sensors detect (When the Standby input is active) there are no humans in the space.

**Standby Offset:** In this case, the Standby Offset relaxes the occupied setpoints. The value of the Standby Offset [SO] can be set between a minimum of 0Δ°F and a maximum of 12.1Δ°F degrees. The default value is 4 Δ°F.

**Reverse Standby Input:** It allows a user to configure two types of inputs, 'Normally Open (NO)' and 'Normally Close (NC)'.

## Display Options

### Display Options

Unoccupied Setpoints  Hide  Show


**Unoccupied Setpoints:** It allows a user to either 'Hide' or 'Show' the unoccupied setpoint.

When a user selects Schedule Model under the 'Schedule Options' tab to 'Setpoint Mode', the 'Zone Setpoints' configuration window appears as follows:



Figure 76: Zone Setpoint Wizard Screen (Setpoint Mode)

## Control Settings

'Control Settings'  allows a user to configure following settings:

1. Cooling PI Control
2. Heating PI Control
3. Two-Position Valves



Figure 77: Control Settings Screen (Four Pipe Fan Coil Unit)

### Cooling PI Control

#### Cooling PI Control

Proportional Constant  $K_p$  20.00 (10.00-40.00)  
 Integral Constant  $K_i$  1.00 (0.50-2.00)  
 OAT Lockout Setpoint 55.0 °F (45.0-99.0)

**Proportional Constant  $K_p$ :** A user can enter a value for  $K_p$  within the range of 10 to 40. The default value is 20.

**Integral Constant  $K_i$ :** A user can enter a value for  $K_i$  within the range of 0.50 to 2. The default value is 1.

**OAT Lockout Setpoint:** Cooling PI control will lockout when outside Temperature decreases below OAT (Cooling) Lockout Setpoint. The default value is 55 °F.

### Heating PI Control

#### Heating PI Control

Proportional Constant  $K_p$  20.00 (10.00-40.00)  
 Integral Constant  $K_i$  1.00 (0.50-2.00)  
 OAT Lockout Setpoint 62.0 °F (45.0-99.0)

**Proportional Constant  $K_p$ :** A user can enter a value for  $K_p$  within the range of 10 to 40. The default value is 20.

**Integral Constant  $K_i$ :** A user can enter a value for  $K_i$  within the range of 0.50 to 2. The default value is 1.

**OAT Lockout Setpoint:** Heating PI control will lockout when outside Temperature increases above OAT (Heating) Lockout Setpoint. The default value is 62 °F.



## Two-Position Valves

### Two-Position Valves

Cycle time: 15 min [3-30]

Minimum On time: 60 s [0-300]

Minimum Off time: 0 s [0-300]

Heating/Cooling Valve Control: On Off

- On Off
- Analog To Binary
- Thermal Valve

**Cycle Time:** Two-Position Valve cycle time ranges from minimum of 3 minutes, and a maximum of 30 minutes. The default value is 15 minutes.

**Minimum On Time:** It is a minimum time for the compressor to stay On.

**Minimum Off Time:** It is a minimum time for the compressor to stay Off.


**Heating/Cooling Valve Control:** Physical heating/cooling valve control has three options

**On Off:** This option selects the opening and closing of Heating valve.

**Analog To Binary:** In this mode the valve is remains open for Cycle Time.

**Thermal valve:** This option allows a user to select a Thermal valve for Heating/Cooling Valve Control.

When 'Auxiliary heat' is configured as 'Single Stage Aux Heat', the 'Control Settings' view changes as follows:



### Aux Staged Heating

A user can configure the Cycle Time & Minimum On/Off Time when a 'Single Stage Auxiliary Heat' is selected in the application.


#### Aux Staged Heating

Cycle Time	<input type="text" value="15"/>	min [8-30]
Minimum On/Off Time	<input type="text" value="3"/>	min [0-15]


**Cycle Time:** The Cycle Time ranges from minimum of 8 minutes, and a maximum of 30 minutes. The default value is 15 minutes.

**Minimum On/Off Time:** It is a minimum On/Off time for the Auxiliary Heating. The default value is 3 minutes.


When 'Analog/Floating' valve actuator is configured, the 'Control Settings' view changes as follows:



## Fan / Humidity

'Fan / Humidity'  allows a user to configure the following settings:

1. Fan Operation
2. Humidity Control
3. Filter Alarm



**TB30268 Configuration View**

Application | General Display | Schedule Options | Zone Setpoints | Control Settings | **Fan/Humidity** | Economizer | I/O Configuration

**Fan Operation**

Fan Mode Control:  Auto  On  On Cool/Auto Heat

Fan OFF Selection:  Hide fan OFF  Show fan OFF

Local User Fan Control:  Disable  Enable

Low Speed Heat/Cool Demand:  % [0-100]

Medium Speed Heat/Cool Demand:  % [0-100]

High Speed Heat/Cool Demand:  % [0-100]

**Humidity Control**

Fan Circulation Cycle:  Disable  Enable

Trigger Setpoint:  %RH [0-100]

Reset Deadband:  % [0-100]

Fan On Cycle Time:  s [210-3600]

Fan Off Cycle Time:  s [120-3600]

**Filter Alarm**

Runtime Hours:  h [0-30000]

Figure 78: Fan/Humidity Screen (Four Pipe Fan Coil Unit)

## Fan Operation

**Fan Mode Control:** During occupancy & Setpoint mode, the fan operates based on the selected fan control modes.

**Fan Operation**

**Fan Mode Control**  Auto  On  On Cool/Auto Heat

**Fan OFF Selection**  Unoccupied OFF  Scheduled OFF

**Local User Fan Control**  Enable  Disable

**Low Speed Heat/Cool Demand**  % (0-100)

**Medium Speed Heat/Cool Demand**  % (0-100)

**High Speed Heat/Cool Demand**  % (0-100)

**Auto:** When this option is selected, Fan cycles ON when:

1. Cooling or heating is selected or
2. During Unoccupied mode only when called to run by cooling or heating demand.

**On:** When this option is selected the fan runs continuously for ventilation.

**On Cool/Auto Heat:** When this option is selected the fan runs continuously in cooling mode. In heating mode the fan cycles on only when the heating signal calls for the fan to run.

**Fan OFF Selection:** This selection allows a user to enable/disable the selection to OFF the fan on the LCD of the controller.

**Local User Fan Control:** This selection allows a user to enable/disable the fan Control to local user.

**Low Speed Heat/Cool Demand:** This field allows a user to set the Heating/Cooling demand limits for the Low Speed Fan.

**Medium Speed Heat/Cool Demand:** This field allows a user to set the Heating/Cooling demand limits for the Medium Speed Fan.

**High Speed Heat/Cool Demand:** This field allows a user to set the Heating/Cooling demand limits for the High Speed Fan.

**When a user selects ‘Single Speed Fan’ in the application, the ‘Fan Operation’ parameter appears as follows:**

**Fan Operation**

**Fan Mode Control**  Auto  On  On Cool/Auto Heat

**Auto:** When this option is selected, Fan cycles ON when:

1. Cooling or heating is selected or
2. During Unoccupied mode only when called to run by cooling or heating demand.

**On:** When this option is selected the fan runs continuously for ventilation.

**On Cool/Auto Heat:** When this option is selected the fan runs continuously in cooling mode. In heating mode the fan cycles on only when the heating signal calls for the fan to run.

## Humidity Control

### Humidity Control

Fan Circulation Cycle  **None**  **Enable**

Trigger Setpoint  Range: 0-100

Reset Deadband  Range: 0-100

Fan On Cycle Time  Range: 0-3600

Fan Off Cycle Time  Range: 0-3600

**Fan Circulation Cycle:** When a user selects the ‘Enable’ option from Fan Circulation Cycle, it allows a user to edit the Trigger Setpoint, Reset Deadband, and Fan On/Off Cycle Time.

**Trigger Setpoint & Reset Deadband:** When sensed humidity equals or exceeds humidity trigger setpoint, the fan cycles ON/OFF at low speed until sensed humidity drops below the trigger setpoint minus the reset deadband.

**Fan On Cycle Time:** This field allows a user to enter a time for fan ON cycle when stratification and humidity control is active. The default value is 300 seconds.

**Fan Off Cycle Time:** This field allows a user to enter a time for fan OFF cycle when stratification and humidity control is active. The default value is 1800 seconds.

## Filter Alarm

### Filter Alarm

Runtime Hours  Range: 0-8888

**Runtime Hours:** A filter alarm activates after the Runtime Hours mentioned in this field. The default value is 3000 hours.

## Economizer


Select Economizer  from Configuration parameters. It is used to configure the economizer settings in TB3026B controller.



Figure 79: Economizer Screen (Four Pipe Fan Coil Unit)

### Configuration

**Minimum Position:** When either the occupied command or the After-hours Timer is ON, the current minimum position is set to the specified Economizer Minimum Position; otherwise, it is zero. The default minimum position is 20%.

**Outside Air Lockout:** The economizer is forced to Minimum position when Outside Air Temperature goes above the Outside Air Lockout setpoint. The default value is 68° F.

**Supply Air Low Limit:** The economizer is forced to Minimum position when Supply Temperature goes below the Supply Air Low Limit. The default value is 45° F.

## I/O Configurations

Select I/O Configurations  from Configuration parameters. This configuration is used for Terminal Assignment & Output Configuration.




Figure 80: I/O Configurations Screen (Four Pipe Fan Coil Unit)

### Terminal Assignment

After completing the 'Four Pipe Fan Coil Unit' configuration, selected inputs and outputs get automatically assigned to the TB3026B controller's input and output terminals.

A user can assign the Input as 'Main Door' or 'Supply Air Temp' to AI/BI2.




Figure 81: Terminal Assignment View (Three Speed Fan)

When AI/BI2 is configured as 'Supply Air Temp' in (Application 8), AI/BI1 gets displayed as 'Standby' and AI/BI0 gets displayed as 'BMS Sensor' as follows:

**Terminal Assignment**

Unused	(20)	BO-5	24VAC Hot	(1)	24VAC Hot
Heating Valve	(19)	BO-4	Relay 24VAC	(2)	Relay 24VAC
Cooling Valve	(18)	BO-3	BO-0	(3)	Fan Low
Fan High	(17)	BO-2	BO-1	(4)	Fan Medium
GND	(16)	GND	GND	(5)	GND
Economizer	(15)	AD-0	AI/BI0	(6)	BMS Sensor
COM	(14)	COM	COM	(7)	COM
Fan Speed	(13)	AD-1	AI/BI1	(8)	Standby
MSTP +	(12)	MSTP +	COM	(9)	COM
MSTP -	(11)	MSTP -	AI/BI2	(10)	Supply Air Temp

When 'Fan Speed' is selected as 'Single Speed Fan', the 'Terminal Assignment' view changes as follows:

**Terminal Assignment**

Unused	(20)	BO-5	24VAC Hot	(1)	24VAC Hot
Heat Close	(19)	BO-4	Relay 24VAC	(2)	Relay 24VAC
Heat Open	(18)	BO-3	BO-0	(3)	Fan
Cool Close	(17)	BO-2	BO-1	(4)	Cool Open
Unused	(16)	GND	GND	(5)	GND
Economizer	(15)	AD-0	AI/BI0	(6)	Motion Sensor
COM	(14)	COM	COM	(7)	COM
Fan Speed	(13)	AD-1	AI/BI1	(8)	Door/Window Switch
MSTP +	(12)	MSTP +	COM	(9)	COM
MSTP -	(11)	MSTP -	AI/BI2	(10)	Main Door

**Output Configuration**

Heating Valve Stroke Time: 90 (1-300)

Cooling Valve Stroke Time: 90 (1-300)

**Output Configuration**

**Output Configuration**

Heating Valve Stroke Time: 90 (1-300)

Cooling Valve Stroke Time: 90 (1-300)

**Heating Valve Stroke Time:** This setting is available to configure, when 'Floating' Valve Actuator is selected and BO-3 and BO-4 are configured to 'Heat Open' and 'Heat Close' respectively. The default value is 90 seconds.

**Cooling Valve Stroke Time:** This setting is available to configure, when 'Floating' Valve Actuator is selected BO-1 and BO-2 are configured to 'Cool Open' and 'Cool Close' respectively. The default value is 90 seconds.



When AI/B12 is configured as 'Supply Air Temp' in (Application 7), AI/B11 gets displayed as 'Unused' and AI/B10 gets displayed as 'BMS Sensor' as follows:

**Terminal Assignment**

Unused	20	BO-5	24VAC Hot	1	24VAC Hot
Heat Close	19	BO-4	Relay 24VAC	2	Relay 24VAC
Heat Open	18	BO-3	BO-0	3	Fan
Cool Close	17	BO-2	BO-1	4	Cool Open
GND	16	GND	GND	5	GND
Economizer	15	AO-0	AU/B10	6	BMS Sensor
COM	14	COM	COM	7	COM
Fan Speed	13	AO-1	AU/B11	8	Unused
MSTP +	12	MSTP +	COM	9	COM
MSTP -	11	MSTP -	AU/B12	10	Supply Air Temp

Supply Air Temp dropdown menu options: Supply Air Temp, Main Door, Supply Air Temp.


When 'Single Stage Aux Heat' is configured, the 'Terminal Assignment' view changes as follows:

**Terminal Assignment**


Aux Heat	20	BO-5	24VAC Hot	1	24VAC Hot
Heating Valve	19	BO-4	Relay 24VAC	2	Relay 24VAC
Cooling Valve	18	BO-3	BO-0	3	Fan Low
Fan High	17	BO-2	BO-1	4	Fan Medium
GND	16	GND	GND	5	GND
Economizer	15	AO-0	AU/B10	6	Motion Sensor
COM	14	COM	COM	7	COM
Fan Speed	13	AO-1	AU/B11	8	Door/Window Switch
MSTP +	12	MSTP +	COM	9	COM
MSTP -	11	MSTP -	AU/B12	10	Main Door

Main Door dropdown menu options: Main Door, Main Door, Supply Air Temp.

When AI/BI2 is configured as 'Supply Air Temp' in (Application 9), AI/BI1 gets displayed as 'Unused' and AI/BI0 gets displayed as 'BMS Sensor' as follows:



When 'Analog' valve actuator is configured, the 'Terminal Assignment' view changes as follows:



## Output Configuration

### Output Configuration

Economizer Damper Stroke Time  s [0-300]

**Economizer Damper Stroke Time:** This setting is available to configure, when 'Analog' 'Valve Actuator' is selected. The default value is 3 seconds.

When 'Analog Input 2' is selected as 'Remote Space Temp Sensor', the 'Terminal Assignment' view changes as follows:



## Output Configuration

### Output Configuration

Heating Valve Stroke Time: 90 s [0-300]

Cooling Valve Stroke Time: 90 s [0-300]

**Heating Valve Stroke Time:** This setting is available to configure, when 'Floating' 'Valve Actuator is selected and BO-3 and BO-4 are configured to 'Heat Open' and 'Heat Close' respectively. The default value is 90 seconds.

**Cooling Valve Stroke Time:** This setting is available to configure, when 'Floating' 'Valve Actuator is selected BO-1 and BO-2 are configured to 'Cool Open' and 'Cool Close' respectively. The default value is 90 seconds.

# ONLINE OPERATIONS

TB3026B controllers can be connected online as described in [Configuration through WEBS Controller](#) or [Configuration through PC](#).

Following Online Operations can be performed when it is connected online.

## Download

Select the Controller from the left pane. Right click on it and select 'Download' as shown in [Figure 82](#).




Figure 82: Selecting 'Download'

It is used to download the configuration from tool to controller.

	<b>Note:</b>
<p>When a Download operation is performed;</p> <ol style="list-style-type: none"> <li>Overridden outputs (if any) will be set to Auto.</li> <li>The values written to the controller will appear as the values configured in the application unit in the wizard.</li> </ol>	

## Upload

Select the Controller from the left pane. Right click on it and select 'Upload' as shown in [Figure 83](#).



Figure 83: Selecting 'Upload'

Invoke this option to read configuration data from the controller and update the same in the tool database.

## Write Device Instance

A user can set the device instance number for a device so that each device in the network has a unique device instance number.

Select the Controller from the left pane. Right click on it and select Actions > 'Write Device Instance' as shown in [Figure 84](#).



Figure 84: Write Device Instance

A user can view the job progress for Write Device Instance in a Job Side Bar from the workbench.

To perform online operations, right click on the controller > select Views as shown in [Figure 85](#).




Figure 85: Online Operations View

## Sensor Calibration

It is used to calibrate the sensors that are connected to the device. Using Sensor Calibration feature, a user can correct the input values to the controller. This action can be performed with the device in online mode only. The controller must be in a downloaded state.

While performing Sensor Calibration, the device should not be used by another application. Only analog inputs to the controllers can be calibrated.

Select 'BACnet FF Calibration View' option as shown in [Figure 85](#).

A window will pop up as shown in [Figure 86](#).



Sensor Name	Actual Value	Calibrated Value	Offset Value
Temperature sensor	73.8 °F	73.8 °F	1.6 Δ°F [-4.0 - 4.0]
Humidity sensor	62.3 %	62.3 %	1.0 % [-5.0 - 5.0]

**Figure 86: Sensor Calibration**

This shows the list of total analog inputs configured to the controller.

**Sensor name:** Displays the names of the sensors configured based on the configured applications.

**Actual Value:** shows the current value of the sensor as read by controller.

**Calibrated Value:** shows the calibrated value to be entered.

**Offset value:** Click the  button to calculate the offset value. Offset value is a difference between Actual value and Calibrated value. It can be a positive or negative value.

Click  button to updated the Actual Value and Offset Value.



**Note:**

*The Offset value is always calculated in Fahrenheit irrespective of the Engineering Units (English Units or Metric Units) configured in the system. Hence if the values are selected as °C, a user should convert that value to equivalent °F while calculating the offset value.*

*For example, a user has configured the engineering unit to °C and the sensor value reported is 25 °C and user wants the value to be reported is 27 °C, so the offset should be written as 3.6.*

$$25\text{ }^{\circ}\text{C} = 77\text{ }^{\circ}\text{F}$$

$$27\text{ }^{\circ}\text{C} = 80.6\text{ }^{\circ}\text{F}$$

$$\text{so offset should be } (80.6 - 77 = 3.6)$$

*Similarly, if user wants the calibrated value as 28 °C, then it is not possible to get it, because, 28 °C is equal to 82.4 °F and in this case original value reported by the controller is 77 °F (25 °C), so the offset is 5.4 which is greater than sensor offset limit. [-4.0 – 4.0] °F*

## Diagnostics

**Honeywell**

**Diagnostics for BACnetFF1**

**Modulating Output Diagnostics**

Name	Current Value	Edit Value
Economizer	0.0 %	0.0 %
Fan Speed	0.0 %	0.0 %

**Binary Output Diagnostics**

Name	Current Value	Edit Value
Fan	OFF	OFF
Staged Heat	OFF	OFF
Cool Stage 1	OFF	OFF

Current Mode:


**Figure 87: Outputs Overridden Mode/Diagnostics**

It is used to test the outputs of the BACnet FF Stat device in Outputs overridden mode.

This action can only be performed with the device in online mode. The device must be in downloaded state.

The Diagnostics screen displays:

- All configured Digital Outputs to command ON/OFF.
- All configured Analog Outputs to command the values within 0 % to 100%.
- The values that are sensed (currently) at the outputs.

 **Note:**

*The 'Current mode' changes to 'Outputs Overridden' from 'Auto' when the Outputs are overridden in the Diagnostics view.*


Current Mode:

## Modulating Output Diagnostics

The number of Modulating Outputs depend on the outputs configured in the application.

**Current Value:** it displays the value of the modulating output as read from the controller  
This field is non-editable.

**Edit Value:** Enter the value that is required to command the output.  
The range is 0 % to 100 %.


When the value is entered, click  button to feed the value to the selected output.

## Binary Output Diagnostics


The number of Binary Outputs depends on the outputs are configured in the application.


**Current Value:** It displays the value of the Digital or Binary output as read from the controller.  
This field is non-editable.



**Edit Value:** Select the value as ON or OFF to command the output.

When the value is entered, click  button to feed the value to the selected output.

## Refresh

Click the  button to refresh the output values. This button is enabled only when the device is in Outputs overridden mode. The values set in the 'Edit Value' column get reflected in the 'Current Value' column when user clicks 'Refresh' button.

	<b>Note:</b>
<i>When the outputs are overridden, if a user invokes a Download operation, it puts the outputs into 'Auto' from 'Outputs Overridden'.</i>	

	<b>Note:</b>
<i>If a user tries to exit the diagnostics view when the outputs are Overridden, a confirmation window pops up asking a user whether user wants to put outputs to auto.</i>	
	

# Alarms



Figure 88: Viewing Alarms

Alarm window shows errors logged by the BACnet FF T-Stat device. This action can be performed only when the device is in the online mode.

The controller must be in a downloaded state.

	<b>Note:</b>
<p><i>The controller is capable of tracking and reporting several types of errors.</i></p>	

Groups of errors of the same type are also reported as an alarm by the controller. This means, the several different errors of the same type will be reported as a single alarm.

For Example, multiple sensors connected to the controller may read invalid values and the controller will log individual errors for each sensor. However, a single 'Bad Sensor Alarm' alarm will be reported.

As shown in [Figure 88](#), this screen displays all the errors that are currently active and reported by the controller.

## Error

This column displays the name of the errors. Errors can be one of the following types:

- Bad Sensor Alarm
- Filter Alarm
- Low Limit Alarm
- Cooling Locked Out / Low-Supply-Temperature Alarm
- Space Too Warm Alarm
- Space Too Cold Alarm
- Bad Water Sensor Alarm

## Error Details

It shows the description for the error occurred.

## Value Limits

It displays the value or range of values for a parameter, beyond which an alarm will be generated.

## Current Value

It displays the value of the as read from the controller

## Refresh alarm list

Click the button to refresh the error list manually and see the current errors.

## Auto Refresh / Update auto refresh rate



**Auto Refresh:** If this option is selected, the alarms view/data refreshes automatically for the time mentioned in 'Auto refresh rate' field.

For example, if Auto refresh rate is set to 30 sec, the alarm data refreshes automatically after every 30 seconds to show the current errors.




## Time Sync

It is used to set the time as per the time zone in the devices connected over BACnet network.

Features like scheduling and day light savings will not work correctly if the device does not have a valid date and time set. This action can only be performed with the device in online mode.


Right click on the 'Bacnetnetwork' > Views > select 'Honeywell Time Sync' as shown in [Figure 89](#).



**Figure 89: Selecting 'Honeywell Time Sync'**

Select the required device and click 'UTC Time Sync'

**UTC Time Sync** option as shown in [Figure 90](#). The time will be updated for the selected device.



**Figure 90: Time Sync View**

## Batch Operations

In BACnet FF Batch Operations view, batch operations can be invoked on selected BACnet FF devices.

Following batch operations can be performed with the BACnet Batch Operations view

1. Download
2. Upload
3. Set Outputs To Auto

To perform BACnet FF Batch Operations, right click on the 'Bacnetnetwork' > Views > select 'BACnet FF Batch Operations' as shown in [Figure 91](#).




Figure 91: Selecting 'BACnet FF Batch Operations'

In the 'BACnet FF Batch Operations' view, the device download status and the device mode status can be viewed in a tabular format. Refer to [Figure 92](#).




Figure 92: BACnet FF Batch Operations' view

**Device:** Displays the list of devices added in the network.

**Download Status:** Displays the download status for the added devices.

**Mode Status:** Displays the three types of mode status for the added devices:

- **Auto:** BACnet FF controller derives the outputs automatically.
- **Outputs Overridden:** When user manually overrides the output values using Diagnostics option.

- **Unknown:** When the output status is unknown because of connection error or if the device is offline or the device is not downloaded state.

## Set Outputs to Auto

Selecting **Set Outputs to Auto** will put the overridden outputs back to “Auto” mode.

## Download

Click **Download** to perform the batch download.

## Upload

Click **Upload** to perform the batch upload.




Figure 93: BACnet FF Batch Operations’ view while loading the Mode Status

When the ‘Download Status’ and ‘Mode Status’ are in loading for the devices in Batch Operation, the ‘Batch Commands’ get disabled till the loading is completed for all the devices. Refer to [Figure 93](#)

# HONEYWELL SOFTWARE END USER LICENSE AGREEMENT

HONEYWELL IS WILLING TO PROVIDE A LIMITED LICENSE OF THE SOFTWARE TO YOU ONLY ON THE CONDITION THAT YOU ACCEPT ALL OF THE TERMS IN THIS AGREEMENT. PLEASE READ THE TERMS AND CONDITIONS OF THIS AGREEMENT CAREFULLY BEFORE USING THIS PRODUCT. BY DOWNLOADING THE SOFTWARE, YOU ACKNOWLEDGE THAT YOU HAVE READ THIS AGREEMENT AND AGREE TO BE BOUND BY ITS TERMS AND CONDITIONS. BY INSTALLING, COPYING, DOWNLOADING, ACCESSING, OR OTHERWISE USING THE SOFTWARE YOU REPRESENT THAT YOU ARE ACTING ON BEHALF OF YOUR EMPLOYER AND/OR THE END USER OF THIS SOFTWARE (SUCH PARTY HEREINAFTER REFERRED TO AS "YOU" OR THE "LICENSEE"), AND ARE AUTHORIZED TO, AND DO, ACCEPT THESE TERMS ON ITS BEHALF. THE ACCEPTANCE OF THIS AGREEMENT IS REQUIRED FOR USE OF THE LICENSED SOFTWARE. IF YOU DO NOT AGREE TO THE TERMS OF THIS AGREEMENT: (A) DO NOT INSTALL, COPY, DOWNLOAD, ACCESS, OR OTHERWISE USE THE SOFTWARE; AND (B) RETURN THE COMPLETE UNUSED SOFTWARE AND ALL ACCOMPANYING ITEMS AND PACKING WITHIN 30 DAYS OF PURCHASE FOR A FULL REFUND OF ANY AMOUNT PAID FOR THE RETURNED SOFTWARE.

This End User License Agreement ("Agreement") is a legal contract between Honeywell International Inc., acting through its Environmental and Energy Solutions business, having an office at 1985 Douglas Drive North, Golden Valley MN 55422 ("Honeywell"), and You. The right to use the Software is granted only on the condition that You agree to the following terms:

## 1. LICENSE GRANT

- a. Subject to the terms and conditions herein, Honeywell grants, and You accept, a nonexclusive, non-transferable, limited license to install, execute, and use the Software with the Designated System. All such use of the Software shall be for your internal business purposes, at and for the benefit of the Designated Facility only.
- b. The license granted in Section (a) above does not include the right to make copies of the Software.

## 2. PROPERTY RIGHTS

The Software is highly confidential and proprietary to Honeywell or Honeywell's Software vendor(s) and title thereto remains with Honeywell or Honeywell's Software vendor(s). All applicable rights in patents, copyrights, trademarks and trade secrets in the Software are and will remain with Honeywell or Honeywell's Software vendor(s). You shall not sell, lease, transfer, publicly disclose or display or otherwise make available the Software or copies thereof to others. You agree to secure and protect the Software in a manner consistent with the maintenance of Honeywell's or Honeywell's Software vendor's rights therein. You shall not, and will not permit others, to modify, adapt, translate, reverse engineer, decompile, disassemble or otherwise attempt to create derivative works or alter the Software or discover its source code. The terms of this Section will survive termination or expiration of this Agreement. You understand that violation of this provision may cause irreparable harm to Honeywell.

## 3. TERM AND TERMINATION

- a. This Agreement is effective upon first installation, downloading, access, or other use of the Software and shall remain in effect until terminated.
- b. Honeywell may terminate this Agreement immediately if you fail to comply with any of the terms and conditions of this Agreement including, but not limited to, failing to pay any fees or charges when due. Termination of this Agreement by Honeywell shall, among other things, constitute termination of all licenses granted hereunder.
- c. Within 5 days after the termination of this Agreement, unless the requirement is waived by Honeywell, you will return to Honeywell the Software in the form provided by Honeywell and all copies thereof.

## 4. TRANSFER

You understand that reproduction of copies of the Software and/or transfer of the Software or any copy thereof may be a serious crime, as well as may subject You to damages and attorneys' fees. You may not transfer the original or any copy of the Software to another person except with Honeywell's prior written approval. Honeywell has the right to terminate the License, to trace serial numbers, and to take legal action if these conditions are violated. This License Agreement may not be assigned by You.

**5. DISCLAIMER OF WARRANTY**

THE SOFTWARE IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND. FURTHER, HONEYWELL DOES NOT WARRANT, GUARANTEE, OR MAKE ANY REPRESENTATIONS REGARDING THE USE, OR THE RESULTS OF THE USE OF THE SOFTWARE IN TERMS OF CORRECTNESS, ACCURACY, RELIABILITY OR OTHERWISE. THE ENTIRE RISK AS TO THE RESULTS AND PERFORMANCE OF THE SOFTWARE IS ASSUMED BY YOU. IF THE SOFTWARE IS DEFECTIVE, YOU AND NOT HONEYWELL ASSUMES THE ENTIRE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION. HONEYWELL AND ITS SOFTWARE VENDORS EXCLUDE ALL WARRANTIES INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

**6. LIMITATION OF LIABILITY AND INDEMNIFICATION**

- a. Neither Honeywell nor anyone else who has been involved in the creation, production or delivery of the Software shall be liable for any direct, indirect, consequential, or incidental damages (including damages for loss of business profits, business interruption, loss of business information and the like) arising out of training on the Software, nor the use of or inability to use such Software even if Honeywell has been advised of the possibility of such damages. In no event shall Honeywell be liable for any amount in excess of the amounts paid by You for the Software.
- b. You hereby release Honeywell from any and all liability relating directly or indirectly, to Honeywell providing training on the Software, your entry of data using the Software, your error in writing or modifying software programs using the Software, or any other act relating to or arising out use of the Software. Further, You agree to indemnify and hold Honeywell harmless from and against any claim, loss of damage, arising directly or indirectly out of your use of the Software or the use of the Software by anyone while the Software is licensed to You. In the event the cause of any damage cannot be determined, the damage will be presumed to be caused by your use of the Software and this paragraph shall apply with respect to such damage.

**7. GENERAL**

- a. Honeywell shall have the right, upon reasonable notice during business hours, to audit your use of the Software for purposes of evaluating your compliance with this Agreement
- b. This License Agreement may be amended only by an instrument in writing executed by You and Honeywell.
- c. You agree that no copy of the Software, nor any of its associated documentation, nor any other information regarding such Software shall be transmitted into any country other than the country in which the designated installation is located without the express written consent of Honeywell. Such written consent must specify both the country from which the Software is to be moved and the country into which the Software is to be moved.
- d. Software, including technical data, is subject to U.S. export control laws, including the U.S. Export Administration Act and its associated regulations, and may be subject to export or import regulations in other countries. You agree to comply strictly with all such regulations and acknowledge that you have the responsibility to obtain such licenses to export, re-export, or import the Software. The Software may not be used, sold, resold, sublicensed, diverted, transferred, reshipped, or otherwise exported or re-exported:
  - (i) in, into or through any country designated as a terrorist supporting country by the U.S. government or any of its agencies;
  - (ii) in, into or through any country for which the U.S. has an embargo or with which the U.S. or any of its agencies maintains comprehensive trade controls;
  - (iii) to or by a national or resident of the countries described in (i) or (ii);
  - or (iv) to or by any party included in the United States Department of Commerce's Denied Persons List, Entity List or Unverified List; or the United States Department of the Treasury's Specially Designated Nationals, Specially Designated Global Terrorists, Specially Designated Narcotics Traffickers, or Specially Designated Terrorists List; or the United States Department of State's Designated Foreign Terrorist Organizations or Debarred Persons List; or is otherwise designated by the U.S. government, or any of its agencies, as a party with which it is unlawful to do business

- e. The Software is provided with restricted rights. With respect to any acquisition of the Software by or for any unit or agency of the U.S. Government ("Government"), the Software shall be classified as "Commercial Computer Software," as that term is defined in the applicable provisions of the Federal Acquisition Regulation ("FAR") and supplements thereto, including the Department of Defense ("DoD") FAR Supplement ("DFARS"). If the Software is supplied for use by DoD, the Software is delivered subject to the terms of this Agreement and either (i) in accordance with DFARS 252.227-7202-1(a) and 227.7202-3(a), or (ii) with restricted rights in accordance with DFARS 252.227 7013(c)(1)(ii), as applicable. If the Software is supplied for use by a federal agency other than DoD, the Software is restricted computer software delivered subject to the terms of this Agreement and (i) FAR 12.212(a); (ii) FAR 52.227-19; or (iii) FAR 52.227-14 (ALT III), as applicable .
- f. The failure of either party to enforce at any time any of the provisions of this Agreement shall not be construed to be a continuing waiver of any provisions hereunder nor shall any such failure prejudice the right of such party to take any action in the future to enforce any provisions hereunder.
- g. In the event any provision of this Agreement is determined to be illegal, invalid, or unenforceable, the validity and enforceability of the remaining provisions of this Agreement will not be affected and, in lieu of such illegal, invalid, or unenforceable provision, there will be added as part of this Agreement one or more provisions as similar in terms as may be legal, valid and enforceable under applicable law.
- h. You acknowledge that any breach of your obligations hereunder with respect to the Software or the confidential information of Honeywell will cause Honeywell irreparable injury for which it has no adequate remedy at law. You further agree that Honeywell will be entitled to seek and obtain equitable relief, including preliminary injunctions and temporary restraining orders, to prevent any unauthorized use of the Software and confidential information, without posting of bond or other security, in addition to all other remedies available to it under this Agreement or other applicable law.
- i. This Agreement will be governed by and interpreted in accordance with the laws of the State of Minnesota without reference to conflict of laws principles. If for any reason a court of competent jurisdiction finds any provision of the Agreement to be unenforceable, that provision will be enforced to the maximum extent possible to effectuate the intent of the parties, and the remainder of the Agreement will continue in full force and effect. This Agreement shall not be governed by the United Nations Convention on Contracts for the International Sale of Goods, or by the Uniform Computer Information Transactions Act (UCITA). The parties agree that exclusive jurisdiction for any

dispute arising out of or relating to this Agreement lies within courts located in the State of Minnesota. Notwithstanding the foregoing, any judgment may be enforced in any United States or foreign court.

## 8. DEFINITIONS

- a. "Designated Facility" means the particular building(s) owned or operated by you or authorized Honeywell customers at the locations authorized by Honeywell for use with the Software.
- b. "Designated System" means the equipment and/or computer hardware authorized by Honeywell for use with the Software.
- c. "Software" means the computer software in machine-readable, object code form only, owned and distributed by Honeywell via CD ROM, the Internet, or other distribution mechanism, including any Updates to such Software that may be provided by Honeywell to this Agreement.
- d. "Updates" means any enhancement, upgrade, or modification to the Software that may be provided by Honeywell under this Agreement but excluding any items licensed, marketed or distributed by Honeywell as a separately-priced product.



By using this Honeywell literature, you agree that Honeywell will have no liability for any damages arising out of your use or modification to, the literature. You will defend and indemnify Honeywell, its affiliates and subsidiaries, from and against any liability, cost, or damages, including attorneys' fees, arising out of, or resulting from, any modification to the literature by you.

**Home and Building Technologies**

In the U.S.:

Honeywell

715 Peachtree Street NE

Atlanta, GA 30308

[customer.honeywell.com](http://customer.honeywell.com)

® U.S. Registered Trademark  
© 2018 Honeywell International Inc.  
31-00121-02 M.S. Rev. 06-18  
Printed in United States

**Honeywell**