

On-Machine ArmorStart Accelerator Toolkit

Catalog Numbers 280D, 281D, 283D, 284D



Important User Information

Solid-state equipment has operational characteristics differing from those of electromechanical equipment. Safety Guidelines for the Application, Installation and Maintenance of Solid State Controls (publication [SGI-1.1](#) available from your local Rockwell Automation sales office or online at <http://www.rockwellautomation.com/literature/>) describes some important differences between solid-state equipment and hard-wired electromechanical devices. Because of this difference, and also because of the wide variety of uses for solid-state equipment, all persons responsible for applying this equipment must satisfy themselves that each intended application of this equipment is acceptable.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.






Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.

	WARNING: Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.
	ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence.
	SHOCK HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.
	BURN HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.
IMPORTANT	Identifies information that is critical for successful application and understanding of the product.

Rockwell Software, ArmorStart, RSLinx Classic, RSLinx Enterprise, RSNetworx, FactoryTalk View ME, FactoryTalk View SE, FactoryTalk View, Integrated Architecture, ControlFlash, FactoryTalk View Studio, FactoryTalk Services, RSNetworx for DeviceNet, DeviceLogix, On-Machine, ArmorConnect, Logix5000, ControlLogix, CompactLogix, RSLinx, RSLogix, Logix, Allen-Bradley, Rockwell Automation, and TechConnect are trademarks of Rockwell Automation, Inc.

Trademarks not belonging to Rockwell Automation are property of their respective companies.



Notes:

Preface

About This Publication	9
Required Software	10
Conventions	10
Additional Resources	11

Chapter 1

Hardware Selection

Before You Begin	13
What You Need	13
Follow These Steps	14
Select an ArmorConnect Power Media System	15
Adding a Three-phase Power Network and a Branch	18
Add a Three-phase Power Network	18
Add Device to a Branch (Three-phase Power Network)	20
Configure the Device Added to Branch	20
Configure Device Accessories	22
View and Configure Network	29
Add a Control Power Network	30
Add a DeviceNet Network	32
Export the IAB Configuration to ProposalWorks	34
Add Additional Equipment and Generate a Complete BOM	37

Chapter 2

System Layout and Wiring

Before You Begin	39
What You Need	39
Follow These Steps	40
Planning Your ArmorStart Panel Layout and Wiring	41
Use CAD Drawings from the Toolkit CD	41
Panel Layout Diagrams	42
ArmorStart Distributed Motor Controllers Wiring Diagrams	44
Wiring Your ArmorStart Controllers	46
General Precautions	46
Additional Precautions for the Bulletin 284 Devices	46
ArmorStart Device Wiring	47
Connecting the DeviceNet ArmorConnect to Your ArmorStart Device	50
AC Supply Considerations for Bulletin 284 Units	53
Ungrounded and High-resistive Distribution Systems	53
Disconnect MOVs	53
Group Motor Installations For North American and Canadian Markets	54
Cabling and Installation Guidelines	54
DeviceNet Network Installation	55

	Electromagnetic Compatibility	56
	General Notes for Bulletin 284 Devices	56
	Ground the ArmorStart Controller	56
ArmorStart DeviceNet Configuration	Chapter 3	
	Before You Begin	57
	What You Need	57
	Follow These Steps	58
	Open an Existing Project in RSLogix 5000 Software	59
	Configure the DeviceNet Network by Using RSNetWorx Software	60
	Add a Scanner Module to Your ControlLogix Project	65
	Generate ArmorStart Tags by Using the Tag Generator Tool	67
	Download Controller File and Test ArmorStart Tags	69
	Verify Tags	69
	Set Project Path and Download to Controller	70
	Device Tag Test Setup	72
	Test Procedure	73
ArmorStart Local Control Configuration	Chapter 4	
	Before You Begin	75
	What You Need	75
	Follow These Steps	76
	Create a DeviceLogix Program on an ArmorStart Device	77
	Build Your Logic Program	78
	Download Program to ArmorStart	82
	Standalone Device	83
	DeviceLogix Programming Example	84
Faceplate Logix Integration	Chapter 5	
	Before You Begin	89
	What You Need	89
	Follow These Steps	90
	Import the ArmorStart Add-On Instructions	91
	Reassign Add-On Instruction Input and Output Parameter Data Types	92
	Modify ArmorStart Add-On Instruction for Equipment Status Faceplate	95
	Integrate ArmorStart AOI into Your Application Program Routines	96
	Integrate Your ArmorStart Device Application	101
	Understanding Operator Control and Program Control Transfer Logic	102
	Enabling Operator Control of Drive	102
	Add-On Instruction Program Tag Listing and Function	104
	Common Application Logic Examples	106

	Add Alarm Logic for Alarm History Faceplate	109
	Download the Project	111
FactoryTalk View Integration	Chapter 6	
	Before You Begin.	113
	What You Need	113
	Follow These Steps	114
	Add ArmorStart Device Faceplates.	115
	Configuration Steps for Using Pre-configured Goto Buttons. . .	120
	Set Initial Application Graphic	123
	Add Equipment Status Faceplate	124
	Add the Equipment Status Faceplate Display	126
	Add the ME_Equipment_Parameter File.	127
	Configure the Goto buttons on the Equipment Status Faceplate.	129
	Configure Additional Device Value Columns	131
	Create a Goto Display Button to Launch the Equipment Faceplate.	132
	Add Alarm History Faceplate	133
	Test the Project	139
	Download the Project to a Terminal.	140
	Run the Project on a Terminal	142
ArmorStart System Application Guide	Chapter 7	
	Before You Begin.	145
	What You Need	145
	ArmorStart System Overview Display	146
	ArmorStart Device Faceplate Overview	147
	ArmorStart Device Faceplate - Fault Indication View.	148
	Last Fault, Fault Description, and Fault Action	149
	ArmorStart Device Faceplate - Configuration Status View	150
	ArmorStart Device Faceplate - Trending View	151
	ArmorStart Device Faceplate - Online Help Options	152
Logix Communication and Controller Configuration	Appendix A	
	Configuring PC Communication.	155
	Set the IP Address	155
	Verify Your IP Address.	156
	Configure the EtherNet/IP Driver.	157
	Load the Controller Firmware Serially	158
	Assign IP Addresses.	160
	Using BOOTP/DHCP	160
	Using DHC	162
	Ethernet Module Firmware Update Using ControlFLASH Utility . .	163
	Browse the EtherNet/IP Network Devices	168

Load the Controller Firmware.....	168
Create a New Project File in RSLogix 5000 Software	170
Configure Your Ethernet Module.....	171

FactoryTalk View Application Configuration

Appendix B

Create New FactoryTalk View Application	173
Create Design (local) and Runtime (target) Shortcuts	174
Configure Design (local) Communication	175
Configure Runtime (Target) Communication.....	176

ArmorStart Configuration Using 193-DNCT Device

Appendix C

Before You Begin.....	177
What You Need	177
Follow These Steps	178
Connect to the ArmorStart Controller	179
Applying Power to the 193-DNCT Terminal.....	180
Hand-held Terminal Keys	181
Browse through the Network to Select Your ArmorStart Controller	182
Select and Monitor Parameters	183
Select a Parameter	183
Monitor a Parameter	184
Change Parameters.....	185
Change a Bit Numeric Parameter	185
Change a Numeric Parameter	186
Change an Enumerated Parameter	186

About This Publication

This quick start provides step-by-step instructions for using the ArmorStart Accelerator Toolkit to help you easily design, install, operate, and maintain an on-machine system. Included are pre-configured files, selection tools, and examples of using a Logix controller to connect to multiple devices (ArmorStart distributed motor controllers and HMI terminal) over the EtherNet/IP and DeviceNet network to provide Intelligent Motor Control for your application requirements.

The ArmorStart Accelerator Toolkit CD, publication [IASIMP-SP015](#), provides ArmorStart selection tools; CAD drawings for panel layout and wiring; basic status, control, and diagnostic logic; FactoryTalk View ME and FactoryTalk View SE faceplates, and more. For a copy of the CD, contact your local Rockwell Automation distributor or sales representative. With these tools and the built-in best-practices design, the system designer is free to focus on the design of their machine control and not on design overhead tasks.

You can also download these same supporting files from the Rockwell Automation Integrated Architecture Tools website, <http://www.ab.com/go/iatools> on the Beyond Getting Started tab.

IMPORTANT

Before using this quick start and the contents of the ArmorStart Accelerator Toolkit CD, read the Terms and Conditions provided on the CD or website.

The beginning of each chapter contains the following information. Read these sections carefully before beginning work in each chapter:

- **Before You Begin** - This section lists the steps that must be completed and decisions that must be made before starting that chapter. The chapters in this quick start do not have to be completed in the order in which they appear, but this section defines the minimum amount of preparation required before completing the current chapter.
- **What You Need** - This section lists the tools that are required to complete the steps in the current chapter. This includes, but is not limited to, hardware and software.
- **Follow These Steps** - This illustrates the steps in the current chapter and identifies which steps are required to complete the examples by using specific networks.

Required Software

To complete this quick start, the following software is required.

Rockwell Automation Software	Cat. No.	Version	Required for
RSLogix 5000 - ControlFlash - BOOTP/DHCP utility (EtherNet/IP) - RSLinx Classic	9324-RLD300RNE	17 or later	All EtherNet/IP and ControlLogix processors
FactoryTalk View Studio for Machine Edition - FactoryTalk Services - RSLinx Enterprise - RSLinx Classic	9701-VWSTMENE	5.00 or later	PanelView Plus terminals
RSNetWorx for DeviceNet	9357-DNETL3	9.00 or later	Communication from 1756-DNB ControlLogix to ArmorStart controllers
ArmorStart Accelerator Toolkit CD	IASIMP-SP015	N/A	CAD files, wiring diagrams, application files, and other support information

Conventions

This manual uses the following conventions.

Convention	Meaning	Example
Click	Click the left mouse button once to initiate an action. (Assumes cursor is positioned on object or selection.)	Click Browse.
Double-click	Click the left mouse button twice in quick succession to initiate an action, while the cursor is positioned on object or selection.	Double-click the application icon.
Right-click	Click the right mouse button once while the cursor is positioned on object or selection.	Right-click the Fieldbus Networks icon.
Drag and drop	Click and hold the left mouse button on an object, move the cursor to where you want to move the object, and release the mouse button.	Drag and drop the desired block into the Strategy window.
Select	Click to highlight a specific option.	Select New Module.
Check or uncheck	Click to activate or deactivate a checkbox.	Check the Disable Keying checkbox.
>	Shows nested menu selections as menu name followed by menu selection.	Click File>New>Preferences.
Expand	Click the + to the left of a given item /folder to show its contents.	Expand the Main Task.

Additional Resources

The following documents contain additional information concerning related Rockwell Automation products.

Resource	Description
ArmorStart Distributed Motor Controller User Manual, publication 280-UM002 .	Provides mounting and wiring instructions for the 280, 281, 283, and 284 ArmorStart controllers. It also provides information on how to set parameters and troubleshoot the AmorStart controller.
DeviceLogix System User Manual, publication RA-UM003 .	Provides details on how to configure, create, and run DeviceLogix software.
On-Machine Connectivity, publication M116-CA001 .	Provides selection of On-Machine components.
ArmorStart Distributed Motor Controller and ArmorConnect Power Media Selection Guide, publication 280-SG001 .	Provides information on ArmorStart controllers, and associated communication and power media.
RSNetWorx for DeviceNet Getting Results Guide, publication, DNET-GR001 .	Provides information on how to install and navigate the RSNetWorx for DeviceNet software.
EtherNet/IP Modules in Logix5000 Control Systems User Manual, publication ENET-UM001 .	Describes how you can use EtherNet/IP modules with your Logix 5000 controller and communicate with various devices on the Ethernet network.
ControlLogix DeviceNet Interface Module Release Notes, publication 1756-RN567 .	Provides information on this module, version 7.003 and earlier.
Logix5000 Controllers Common Procedures, publication 1756-PM001 .	Provides information on how to develop projects for Logix5000 controllers.
Logix5000 Controllers General Instructions Reference Manual, publication 1756-RM003 .	Provides information on how to program the controller for sequential applications.
Logix5000 Controllers Process Control and Drives Instructions Reference Manual, publication 1756-RM006 .	Provides information on how to program the controller for process or drives applications.
DeviceNet Media Design and Installation Guide, publication DNET-UM072 .	Provides information on how to plan and install a DeviceNet network.
DeviceNet Modules in Logix5000 Control Systems User Manual, publication DNET-UM004 .	Provides information on how to program, configure, use, and troubleshoot DeviceNet modules.
Industrial Automation Wiring and Grounding Guidelines Application Data, publication 1770-4.1 .	Provides information on how to ground and wire programmable controllers.
EDS files at http://www.rockwellautomation.com/resources/eds .	Provides text files used by network configuration tools to help you identify products and commission them on a network.
National Electrical Code - Published by the National Fire protection Association of Boston, MA.	Provides information on wire sizes and types for grounding electrical equipment.

You can view or download publications at <http://literature.rockwellautomation.com>. To order paper copies of technical documentation, contact your local Rockwell Automation distributor or sales representative.

Notes:

Hardware Selection

In this chapter, you will select six ArmorStart controllers including peripherals by using the Rockwell Automation Integrated Architecture Builder (IAB) software. This graphical software tool is used to configure Logix-based automation systems. IAB helps you select hardware and generate a bill of material (BOM) for applications that include I/O, networks, ArmorStart controllers, On-Machine cabling, wiring, and other devices. Outputs include BOM and reports with graphics. You can install IAB and ProposalWorks from the Configuration and Selection Tools page which pops up after registering the CD.

Before You Begin

Collect specific application data, that may include the following:


- Control and line power
- Networks used
- Transmission type
- Motor data if specified and available
- Cable lengths

What You Need

- ArmorStart Accelerator Toolkit CD, publication [IASIMP-SP015](#). For a copy of the CD, contact your local Rockwell Automation distributor or sales representative.
- Personal computer with Internet access for downloading software.
- ArmorStart Distributed Motor Controller and ArmorConnect Power Media Selection Guide, publication [280-SG001](#).
- Integrated Architecture Builder and ProposalWorks software can be downloaded from <http://www.ab.com/e-tools>. For a copy of the Product Selection Toolbox CD, you can also contact your local Rockwell Automation distributor or sales representative.

Follow These Steps


Complete the following steps to select your system hardware.




Select an ArmorConnect Power Media System

Follow these steps to select an ArmorConnect power media system by using Integrated Architecture Builder (IAB) software.


1. Open the Integrated Architecture Builder software.
2. Click 'I want to create a New project.' and click OK.



3. Click Integrated Architecture Workspace.
4. Enter a Workspace Name.
5. Click OK.



6. Select ControlLogix Subsystem.
7. Click OK.




The ControlLogix Chassis Preference dialog box appears.

8. Select the appropriate settings.

For this example, 4 is the preferred size.


9. Click Next until the Networks dialog box appears.



10. Enter the number of EtherNet/IP and DeviceNet networks.

For this example, enter 1 for EtherNet/IP and 1 for DeviceNet.


11. Click Next.




12. Check 'Click here to manually choose Logix processor(s)'.

13. Select 1756-L63 as the processor.

14. Click Finish.



15. When finished configuring the chassis, click the Hardware tab to view the configured chassis.



Adding a Three-phase Power Network and a Branch


You will now add a three-phase power network and a branch, add devices to a branch, configure the devices and accessories for the device.

Add a Three-phase Power Network


1. Click the new network icon on the toolbar at the top of the screen.



2. Select 3PhasePwr and click OK.




3. Enter a new network name.
4. Click OK.




5. From the Line Voltage pull-down menu, choose 480V 60Hz.

Line voltage is the three-phase voltage distributed by the three-phase network. You can choose from three line voltages; 240V 60 Hz, 480V 60 Hz, and 600V 60 Hz.




6. From the Control Voltage pull-down menu, choose 24VDC.


This will be the default control voltage for ArmorStart motor controllers connected to the network. Other options are 120V AC and 240V AC. Control voltage might be distributed by a Control Power network, which you can also configure in the IAB software.



A new three-phase power network is created with a single branch and displayed in the network view. Notice the tab added to the network view and the display of the network voltage. The gray box at the left end of the network represents the power distribution panel.



You can change the three-phase power network voltage if needed by right-clicking the distribution panel (the box at the left end of the network) and choosing Change Network Voltage.




Add Device to a Branch (Three-phase Power Network)

Follow these steps to add a device to a branch of a three-phase power network.

1. Click the 3 Phase tab.
2. Under Motor Controller, select Distributed Starters.
A list of ArmorStart motor controllers appear.
3. Select the desired ArmorStart device and drag it over the Branch_0 line.

In this example, select the 283D ArmorStart.

When the plus sign appears, release the left mouse button.




Once a device is placed on the branch, the RAISE configurator will launch.

Configure the Device Added to Branch

You will now need to configure each ArmorStart device by using the RAISE configurator tool.

4. Select the entries that list NO SELECTION or NO VALUE.



For example, when you select Horsepower, the horsepower options appear on the right.

- Choose the appropriate horsepower amount.

Product Configuration Assistant
283A/283D ArmorStart Distributed Motor Controller

Enter the order code for the desired 283A/283D ArmorStart Distributed Motor Controller...

283D?????

OR, make the selections for the product that you need using the interactive selection chart.

SYSTEM DATA

Supply Voltage	480V 60Hz
Horsepower	- NO SELECTION
Motor Current	- NO VALUE

MODULE DATA

Communications	DeviceNet
Enclosure Type	- NO SELECTION
Input Voltage	- NO SELECTION
Current Range	- NO SELECTION
Control Voltage	24V DC
Line/Motor Connections	- NO SELECTION

OPTIONS DATA

Option 1 - Hand-Off-Auto	- NO SELECTION
Source Brake Contactor Option	- NO SELECTION
Safety Monitor Option	- NO SELECTION

I/O DATA

Total Current Draw of Sensors	200 mA
Total Current Draw of Outputs	2000 mA

ACCESSORIES

Extended Motor Cables	- NO SELECTION
Output Cable Port #1	- NO SELECTION
Input Cable Port #1	- NO SELECTION
Sealing Caps	- NO SELECTION

Horsepower (You must choose one of these selections...)

- 1/8 HP
- 1/4 HP
- 1/2 HP
- 3/4 HP
- 1 HP
- 1.5 HP
- 2 HP
- 3 HP
- 5 HP
- 7.5 HP
- 10 HP

Buttons: Accept, Validate, Cancel, Reset, Undo, Redo

- Choose other options as appropriate.

After choosing all of your appropriate options, the dialog box should look similar to this.

Product Configuration Assistant
283A/283D ArmorStart Distributed Motor Controller

Enter the order code for the desired 283A/283D ArmorStart Distributed Motor Controller...

283D-FB3Z-10A-CR-3

OR, make the selections for the product that you need using the interactive selection chart.

SYSTEM DATA

Supply Voltage	480V 60Hz
Horsepower	1 HP
Motor Current	2.1 A
Motor Current Information	Please Note: The motor current is the default value taken from NEC Table 430-150. A different motor current may require another starter size. You may overwrite motor current with the exact value if available.

MODULE DATA

Communications	DeviceNet
Enclosure Type	NEMA Type 4 Watertight Enclosure - IP 67
Input Voltage	200...480V AC, 3-Phase 50/60 Hz
Current Range	1.1...3.0 A
Control Voltage	24V DC
Line/Motor Connections	Conduit Entrance with Motor Cable with 3 m (9.8 ft) unshielded male cordset

OPTIONS DATA

Option 1 - Hand-Off-Auto	Hand-Off-Auto Selector Keypad with Jog Function
Source Brake Contactor Option	- NO SELECTION
Safety Monitor Option	- NO SELECTION

I/O DATA

Total Current Draw of Sensors	200 mA
Total Current Draw of Outputs	2000 mA

ACCESSORIES

Extended Motor Cables	- NO SELECTION
Output Cable Port #1	- NO SELECTION
Input Cable Port #1	- NO SELECTION
Sealing Caps	- NO SELECTION

Select an attribute to the left to start making selections...

Buttons: Accept, Validate, Cancel, Reset, Undo, Redo

Configure Device Accessories


Follow these steps to configure the device accessories.

You will need to add one input and two output cables for the photoelectric sensor and stack lights respectively that will be added later to the BOM in ProposalWorks.


1. Click Output Cable Port #1.

ACCESSORIES	
Output Cable Port #1	Configure Port Cables <i>Output Port #1 - (Point 0)</i>
Output Cable Port #2	- NO SELECTION
Input Cable Port #1	- NO SELECTION
Sealing Caps	- NO SELECTION

2. Make the following selections.
 - a. Select Cable Type under the First Cable Type Selection
 - b. Under Cable Type, choose 'Cordset-Male'.



3. Configure the 'Cordset-Male' as shown by clicking the '?' next to 'Cable Configuration Port 1'.



4. Click Accept in the upper left when you are finished selecting the cordset.
5. Continue to click Accept until you are at the ArmorStart configuration assistant to complete the accessories configuration.

Product Configurator -- Powered by RAISE...

**889 Cordsets and Patchcords
Product Configuration Assistant**

Enter the order code for the desired 889 Cordsets and Patchcords...

889R-E3AE-A-2

Click on the selections for the product that you need using the interactive selection chart.

Accept **Validate** **Cancel** **Reset** **Undo** **Redo**

SENSOR END DATA - FEMALE

Female End Termination	Cable
Number of Pins	Same as Male End
Female Connector Style	No Connector

I/O END DATA - MALE

Male End Termination	AC Micro (Dual Key)
Number of Pins	3-Pin
Male Connector Style	Male, Right Angle

CORD DATA

Cable Type	PVC Cable, Yellow, Unshielded
Wire Size	18AWG
Cable Color Code	Automotive Color Code

SPECIAL CHARACTERISTICS

Hardware Material	Epoxy coated Zinc
Special Characteristics	Standard

CORD LENGTH DATA

Units	Meters
Standard or Build-to-Order Cable Length	2 meters (6.56 feet)

NOTES

Pin Layout (Female End)	Flying Lead Color Codes: 1 Green (GND) 2 Red/Black Tr 3 Red/White Tr
Pin Layout (Male End)	Pinout:

MESSAGES

6. Copy the configuration from Port #1 to Output Cable Port #2 as shown.
7. Select NO SELECTION for Output Cable Port #2.

Product Configurator -- Powered by RAISE...

283A/283D ArmorStart Distributed Motor Controller Product Configuration Assistant

Enter the order code for the desired 283A/283D ArmorStart Distributed Motor Controller...

283D-FB3Z-10A-CR-3

OR, make the selections for the product that you need using the interactive selection chart.

Accept Validate Cancel Reset Undo Redo

Representative Photo Only

Information

The motor current is the default value taken from NEC Table 430-150. A different motor current may require another starter size. You may overwrite motor current with the exact value if available.

MODULE DATA

Communications	DeviceNet
Enclosure Type	NEMA Type 4 Watertight Enclosure - IP 67
Input Voltage	200...460V AC, 3-Phase 50/60 Hz
Current Range	1.1...3.0 A
Control Voltage	24V DC
Line/Motor Connections	Conduit Entrance with Motor Cable with 3 m (9.8 ft) unshielded male cordset

OPTIONS DATA

Option 1 - Hand-Off-Auto	Hand-Off-Auto Selector Keypad with Jog Function
Source Brake Contactor Option	- NO SELECTION
Safety Monitor Option	- NO SELECTION

I/O DATA

Total Current Draw of Sensors	200 mA
Total Current Draw of Outputs	2000 mA

ACCESSORIES

Output Cable Port #1	Configure Port Cables Output Port #1 - (Point 0)
Output Cable Port #2	- NO SELECTION
Input Cable Port #1	- NO SELECTION
Sealing Caps	- NO SELECTION

MESSAGES

8. Click Accept.

Accept Validate Cancel Reset Undo Redo

FIRST CABLE TYPE SELECTION

Cable Type	Cordset - Male
------------	----------------

FIRST CABLE CONFIGURATION

Cable Configuration Part 1	✓ Cordset - Male 889R-E3AEA-2
Cable Configuration Part 2	Flying Leads

USER SPECIFIED DEVICE TAGS

Device Tag - I/O Point #0	"I/O Device Tag"
Device Tag - RSLogix Point #0	"I/O Device Tag"


9. Once the output cables have been configured, click Input Cable Port #1 to configure the port cable.

ACCESSORIES


Output Cable Port #1	✓ Configure Port Cables Output Port #1 - (Point 0)
Output Cable Port #2	✓ Configure Port Cables Output Port #2 - (Point 1)
Input Cable Port #1	? Configure Port Cables Input Port #1 - (Points 0 & 1)

10. Click Cable Type, then Patchcord.

11. Click the '?' next to Patchcord.




12. Make the following selections as shown.




13. Select NO SELECTION under the second cable type.

14. Select No Cable on the right.




15. Click Accept until you have exited the RAISE configurator and are back in the network view.

16. Double-click the Starter.



17. Change the name and click OK.




The dialog box titled "3-Phase Power Network Properties" contains the following fields and sections:

- Device Name:** A text field with "200" entered.
- Position:** A text field with "0.00" and a unit dropdown set to "meter(s)".
- Start Sequence:** A dropdown menu set to "1".
- Motor Current:** A checkbox for "Force" and a text field with "2.10" and a unit dropdown set to "A".
- Network Connection:**
 - Trunk Tap:** A dropdown menu.
 - ☐ End of the Network Drop Cable (no Tap)
 - Drop Cable:**
 - Drop Length to Device: A text field and a unit dropdown set to "meter(s)".
- Device Information:**
 - Catalog #: "280D-F12Z-10B-CR-3"
 - Description: "Combination Starter - DeviceNet"
- Device Receptacle:**
 - Type: "OPEN-STYLE"
 - Gender: "FEMALE"
- Current Associated Catalog#:** A table with columns "Catalog #" and "Description".

Buttons at the bottom: OK, Cancel, Help.

The completed configuration for the 283D ArmorStart will look like this.



The "Product Configuration Assistant" window shows the configuration for the "280A/280D/281A/281D ArmorStart Distributed Motor Controller".

Order Code: 280D-F12Z-10B-CR-3

Buttons: Accept, Validate, Cancel, Reset, Undo, Redo

SYSTEM DATA

Supply Voltage	480V 60Hz
Horsepower	1 HP
Motor Current	2.1 A
Motor Current Information	Please Note: The motor current is the default value taken from NEC Table 430-150. A different motor current may require another starter size. You may overwrite motor current with the exact value if available.

MODULE DATA

Bulletin Number	280 Full Voltage Starter
Communications	DeviceNet
Enclosure Type	NEMA Type 4 Watertight Enclosure - IP 67
Current Range	Current Range 0.5...2.5 A
Control Voltage	24V DC
Line/Motor Connections	Conduit Entrance with Motor Cable with 3 m (9.8 ft) unshielded male cordset

OPTIONS DATA

Option 1 - Hand-Off-Auto	Hand-Off-Auto Selector Keypad
Safety Monitor Option	- NO SELECTION

I/O DATA

Total Current Draw of Sensors	200 mA
Total Current Draw of Outputs	2000 mA

MESSAGES

On the right side, there is a section titled "Select an attribute to the left to start making selections..." with a list of attributes.

Repeat the procedures starting on page 20 to add additional devices to the branch, configure the devices, and select accessories.

The completed configuration for the 281D should look similar to this.

Product Configurator -- Powered by RAISE...

280A/280D/281A/281D ArmorStart Distributed Motor Controller Product Configuration Assistant

Enter the order code for the desired 280A/280D/281A/281D ArmorStart Distributed Motor Controller...

281D-F12Z-10B-CR-3FR

OR, make the selections for the product that you need using the interactive selection chart.

Accept Validate Cancel Reset Undo Redo

Representative Photo Only

SYSTEM DATA

Supply Voltage: 480V 60Hz

Horsepower: 1 HP

Motor Current: 2.1 A

Motor Current Information: Please Note:
The motor current is the default value taken from NEC Table 430-150. A different motor current may require another starter size. You may overwrite motor current with the exact value if available.

MODULE DATA

Bulletin Number: 281 Reversing Starter

Communications: DeviceNet

Enclosure Type: NEMA Type 4 Watertight Enclosure - IP 67

Current Range: Current Range 0.5...2.5 A

Control Voltage: 24V DC

Line/Motor Connections: Conduit Entrance with Motor Cable with 3 m (9.8 ft) unshielded male cordset

OPTIONS DATA

Option 1 - Hand-Off-Auto: Hand-Off-Auto Selector Keypad with Forward/Reverse

Safety Monitor Option: -NO SELECTION

I/O DATA

Total Current Draw of Sensors: 200 mA

Total Current Draw of Outputs: 2000 mA

Select an attribute to the left to start making selections...

MESSAGES

The completed configuration for the 284D ArmorStart should look similar to this.

Product Configurator -- Powered by RAISE...

284A/284D ArmorStart Distributed Motor Controller Product Configuration Assistant

Enter the order code for the desired 284A/284D ArmorStart Distributed Motor Controller...

284D-FVD2P3Z-10-CR-3

OR, make the selections for the product that you need using the interactive selection chart.

Accept Validate Cancel Reset Undo Redo

Representative Photo Only

SYSTEM DATA

Supply Voltage: 480V 60Hz

MODULE DATA

Communications: DeviceNet

Enclosure Type: NEMA Type 4 Watertight Enclosure - IP 67

Torque Performance Mode: Sensorless Vector Control and Volts per Hertz

Input Voltage: 380...480V 50/60 Hz 3-Phase

Output Current: 2.3A, 0.75kW, 1.0 Hp

Control Voltage: 24V DC

Line/Motor Connections: Conduit Entrance with Motor Cable with 3 Meter Unshielded Single Ended Cordset male 90

OPTIONS DATA

Option 1 - Hand-Off-Auto: Hand-Off-Auto Selector Keypad with Jog Function

Option 2: -NO SELECTION

Option 3: -NO SELECTION

I/O DATA

Total Current Draw of Sensors: 200 mA


Total Current Draw of Outputs: 2000 mA

Select an attribute to the left to start making selections...


MESSAGES

View and Configure Network

After completing the configuration sequence, the network view appears.



1. Click Run Wizard.
2. From the various pull-down menus and fields, choose the appropriate values.
3. Click OK.




The "3-Phase Power Network Wizard" dialog box contains the following sections and parameters:

- Facility Substation Parameters:**
 - Transformer Size (KVA): 112.5
 - Percent Impedance of Transformer: 5.75
 - Distribution Wire Size: 6 AWG
 - Distance from Facility Power Source to Power Distribution Panel (meters): 35
- Power Distribution Parameters:**
 - Branch Fuse Type: CC (Non-Time Delay)
 - Voltage Drop Allowance (%):
 - Starting: 10
 - Running: 5
 - Operating Conditions:
 - Ambient Temperature: 30°C
 - Environment: Dry
- Network Parameters:**
 - Network Name: 3 Phase Power Armorstart
 - Tap Interval (Meters): 3.0 (highlighted with a red circle)
 - Drop Length (Meters): 1.0
 - Default Tap: M35, 3-Phase Power Tee Reducing Drop M22, 4-pole (280-RT35)
 - Default Trunk Cable: ArmorConnect Power Media - Trunk Cable, Straight Female to Straight Male Patchcord, 3m (9.8ft) (280-PwRM35A-M3)
 - Default Drop Cable: ArmorConnect Power Media - Drop Cable, Straight Female to Straight Male Patchcord, 1m (3.3ft) (280-PwRM22A-M1)
 - ☒ Keep User Defined Settings


Buttons at the bottom: OK, Cancel, Help.

4. Click the arrow.
5. Check the appropriate parameters for your application.




Add a Control Power Network


1. Click the New Network icon.
2. Select the ControlPwr network.
3. Click OK.




4. Enter your network name then click OK.



The IAB creates a new control power network and displays the network voltage under the power distribution panel at the left end of the network. Notice the tab added to the network view for the Lab control Power network.




5. Add the current ArmorStart devices on the three-phase network to the control network.
 - a. Click the hardware tab.
 - b. Click the first ArmorStart device and right-click the icon of the ArmorStart device.
 - c. Choose 'Connect channel...to Network1:' Control power Armorstart''.




The names of the ArmorStart devices may be different.


6. Repeat step 5 for all of the ArmorStart devices listed under the hardware tab.
7. Click the network tab.
8. Select the Network view.



The network is displayed.



9. Click Run Wizard.




10. From the various pull-down menus and fields, choose the appropriate values.

11. Click OK.

12. Click the arrow.

13. Check the appropriate parameters for your application.




Add a DeviceNet Network

Follow these steps to add a DeviceNet network.


1. Click the New Network icon.




2. Click OK.




3. Enter the network name.
4. Select the power supply.
5. Click OK.



6. Repeat the process to add the ArmorStart devices to the control power network, but instead select 'Connect channel' to Network1:'DeviceNet ArmorStart'.




7. Click the arrow.
8. Check the appropriate parameters for your application.




Export the IAB Configuration to ProposalWorks

Follow these steps to export the IAB configuration to ProposalWorks.


1. From the File menu, choose Export to ProposalWorks File.



2. Enter a file name for the exports.
3. From the Files of Type pull-down menu, choose ProposalWorks Files (*.prp).
4. Click Open.



5. Click Yes or No to export the IAB project to ProposalWorks and add components to the BOM.



Refer to the table for details on how your selection affects the configuration files.

If You Select	Then
Yes	The IAB configuration is exported to ProposalWorks. This option maintains a link between the IAB and ProposalWorks files so that they always represent the same configuration.
No	The IAB configuration is exported to ProposalWorks. In this case, you can modify the configuration in ProposalWorks or IAB. This option breaks the link between the IAB and ProposalWorks files so that either can change without affecting the other.


The IAB exports the projects into a ProposalWorks file in the format you selected. You can monitor progress at the bottom left corner of the IAB dialog box.




Once the validation process has completed, the following dialog box appears.

6. Click OK.


The ProposalWorks file created (ArmorStart BOM) is now on the respective directory.



7. Open Proposal Works.
8. From the File menu, choose Open.




9. Select ArmorStart BOM, then click Open.




10. Click Yes.

Your project is saved. If you click No, the project is not saved.



11. Enter a file name, then click Save.

The default is the name selected in step 2.



12. Open the ArmorStart BOM and review the bill of material generated by the IAB.

Printed Report Detail
Title: Equipment List
Do not print in Word

Wt: kg Pricing: List/Mult/Net Apply Agreement Refresh View: Sell Grand Total

Item / DevID	Qty	Typical Delivery	Wt (kg/lbs)	DS	PGC	Net Only	List Ea	Sell	Each	Ext Net (US)
1	1	Integrated Architecture Builder								
1.1	1	1756-A4 4 Slot ControlLogix Chassis								
1.2	1	1756-ENBT DeviceNet Bridge/Scanner Module								
1.3	1	1756-ENBT CLX EtherNet/IP 10/100 Bridge Module - Twisted Pr								
1.4	1	1756-L63 Logix5563 Processor With 8Mbyte Memory								
1.5	1	1756-N2 Slot Filler								
1.6	1	1756-PA72 85-265 VAC Power Supply (5V @ 10 Amp)								
1.7	1	283D-FB32-18A-CR-3 Bulletin 283 ArmorStart Solid-State Motor Control(DeviceNet, 24V DC, 10 A Rated Device, 1.1...3.0 A, Conduit Entrance with Motor Cable, Hand-Off-Auto Selector Keypad with Jog Function								
1.8	12	889R-E3AEA-2 Cordset, AC Micro (Dual Key), Male, R-Ana (Ext.Threads), 3-Pin, PVC Cable, Yellow, Unshielded, 1.8MM, Automotive Color Coded,No Connector, 2 meter (6.56 feet)								
Add:										
										Tot Wt: 17.028 kg Total (US): \$ 28,583.00

Equipment List

Add Additional Equipment and Generate a Complete BOM

1. Verify that the Integrated Architecture Builder is open in ProposalWorks.

TIP

Please note, this is an example of optional parts. Add or remove items as needed. Prices listed are subject to change.

2. Add the following items that will complete the BOM for this application.

Item / DevID	Qty	Typical Delivery	Wt (kg/lbs)	DS	PGC	Net Only	List Ea	Sell	Each	Ext Net (US)
2										
42EF-S1MPA-F4										
PHOTOSWITCH Photoelectric Sensor, RightSight, Sharp Cutoff Diffuse, Infrd, DC - 2 Complementary LO/DO Outputs, Source (PNP), 4-pin D.C. Micro QD on 152mm (6in) pigtail										
6	Stocked	N/A	E7	622			\$ 60.00	1.0000	\$ 60.00	\$ 360.00
2.1										
60-2696										
Bracket, Mounting, Right Angle										
6	Stocked	N/A	E7	622			\$ 10.00	1.0000	\$ 10.00	\$ 60.00
3										
Parts for: 855E Pre-Assembled 50mm Control Towers (Modular)										
6										
3.1										
855E-BVM										
Control Tower Stack Light Mounting Base, Vertical Mount, Black Housing, No Cap										
6	Stocked	N/A	B5	222			\$ 41.70	1.0000	\$ 41.70	\$ 250.20
3.2										
855E-24TL3										
Control Tower Stack Light, 24V AC/DC Full Voltage, Green Steady LED (socket mount)										
6	Stocked	N/A	B5	222			\$ 113.40	1.0000	\$ 113.40	\$ 680.40
3.3										
855E-24TL4										
Control Tower Stack Light, 24V AC/DC Full Voltage, Red Steady LED (socket mount)										
6	Stocked	N/A	B5	222			\$ 113.40	1.0000	\$ 113.40	\$ 680.40
3.4										
855E-ABCAP										
Black Cap										
6	Stocked	N/A	B5	222			\$ 4.50	1.0000	\$ 4.50	\$ 27.00
4										
Accessories for 193 E1 Overload Relay										
1										
4.1										
193-DNCT										
193-DNCT, DeviceNet Configuration Terminal										
1	Stocked	N/A	B3	126			\$ 269.00	1.0000	\$ 269.00	\$ 269.00
4.2										
193-CM1										
193-CM1, 1 m DNCT Communication Cable with Microconnector (male)										
1	Stocked	N/A	B3	126			\$ 38.00	1.0000	\$ 38.00	\$ 38.00
5										
1485P-P1R5-MIN5										
DeviceNet T-Port, Mini Male/Mini Female Trunk Connection, Female Micro, 1 Port, Standard										
1	Stocked	N/A	E9	648			\$ 50.00	1.0000	\$ 50.00	\$ 50.00
6										
800C-P0212										
800C 2 Hole Enclosure Pendant Station										


The BOM is complete. It can be reviewed in ProposalWorks, converted to a spreadsheet, or made into a proposal in a Microsoft Word document.

3. Select the Microsoft Word icon to generate the complete equipment list or the BOM for this accelerator as shown.



Using the provided BOM with this accelerator DVD, you can also use ProposalWorks to customize the list to suit your needs.

For assistance on ProposalWorks, please see the user guide under the help file.



This example is a partial equipment list. The prices listed are subject to change.

Equipment List

Item	Product ID Description								
Device ID	Qty	Delivery	Ship Wt	DS	PGC	List Price	Multiplier	Each	Extended Net
1	Integrated Architecture Builder								
	1								
1.1	1756-A4 4 Slot ControlLogix Chassis								
	1	Stocked	N/A	D6	539	\$ 296.00	1.0000	\$ 296.00	\$ 296.00
1.2	1756-DNB DeviceNet Bridge/Scanner Module								
	1	Stocked	N/A	D6	539	\$ 1,058.00	1.0000	\$ 1,058.00	\$ 1,058.00
1.3	1756-ENBT CLXEtherNet/IP 10/100 Bridge Module - Twisted Pr								
	1	Stocked	N/A	D6	539	\$ 1,769.00	1.0000	\$ 1,769.00	\$ 1,769.00
1.4	1756-L63 Logix5563 Processor With 8Mbyte Memory								
	1	Stocked	N/A	D5	530	\$ 10,226.00	1.0000	\$ 10,226.00	\$ 10,226.00
1.5	1756-N2 Slot Filler								
	1	Stocked	N/A	D6	539	\$ 25.00	1.0000	\$ 25.00	\$ 25.00
1.6	1756-P A72 85-265 VAC Power Supply (5V @ 10 Amp)								
	1	Stocked	N/A	D6	539	\$ 817.00	1.0000	\$ 817.00	\$ 817.00
1.7	263D-FB3Z-10A-CR-3 Bulletin 283 ArmorStart Solid-State Motor Control DeviceNet, 24V DC, 10 A Rated Device, 1.1...3.0 A, Conduit Entrance with Motor Cable, Hand-Off-Auto Selector Keypad with Jog Function								
	1	Non-Stocked	N/A	B4	171	\$ 1,553.00	1.0000	\$ 1,553.00	\$ 1,553.00
1.8	269R-E3AEA-2 Cordset: AC Micro (Dual Key), Male, R-Ang (Ext. Threads), 3-Pin, PVC Cable, Yellow, Unshielded, 18AWG, Automotive Color Coded No Connector, 2 meter (6.56 feet)								
	12	Non-Stocked	N/A	E9	645	\$ 26.00	1.0000	\$ 26.00	\$ 312.00
1.9	269D-F4ACDE-1 Patchcord: DC Micro (M12), Female, Straight, 4-Pin, PVC Cable, Yellow, Unshielded, 22AWG, IEC Color Coded, DC Mic, Male, R-Ang, 1 meter (3.28 feet)								
	12	Stocked	N/A	E9	645	\$ 25.00	1.0000	\$ 25.00	\$ 300.00
1.10	260D-F12Z-10B-CR-3 280 Full Voltage Starter, DeviceNet, 24V DC, 10 A Rated Device, Current Range 0.5...2.5 A, Conduit Entrance with Motor Cable, Hand-Off-Auto Selector Keypad								
	2	Non-Stocked	N/A	B4	177	\$ 1,233.00	1.0000	\$ 1,233.00	\$ 2,466.00
1.11	261D-F12Z-10B-CR-3R 281 Reversing Starter, DeviceNet, 24V DC, 10 A Rated Device, Current Range 0.5...2.5 A, Conduit Entrance with Motor Cable, Hand-Off-Auto Selector Keypad with Forward/Reverse								
	1	Stocked	N/A	B4	177	\$ 1,298.00	1.0000	\$ 1,298.00	\$ 1,298.00
1.12	264D-FVD2P3Z-10-CR-3 Bulletin 284 ArmorStart W/Variable Frequency A/C Drive DeviceNet, 2.3A, 0.75kW, 1.0 Hp, 10 A Rated Device, Conduit Entrance with Motor Cable, Hand-Off-Auto Selector Keypad with Jog Function								
	2		N/A	B4	174	\$ 2,018.00	1.0000	\$ 2,018.00	\$ 4,036.00

System Layout and Wiring

In this chapter, you plan the panel layout and wiring for your ArmorStart system. You can use the AutoCAD Electrical drawings supplied on the ArmorStart Accelerator Toolkit CD to add or remove components to and from your ArmorStart system.

Before You Begin

Complete your system hardware selection (refer to [Chapter 1](#)).

What You Need

- ArmorStart Accelerator Toolkit CD, publication [IASIMP-SP015](#).
- AutoCAD Electrical software to open the DWG files or Adobe Reader software to open PDF files.

TIP


Use AutoCAD Electrical software to take advantage of advanced features of the project provided.

- System Design for Control of Electrical Noise Reference Manual, publication [GMC-RM001](#).
- System Design for Control of Electrical Noise Video, publication GMC-SP004.
- The user manual for your ArmorStart controllers. Refer to [Additional Resources](#) for publication numbers.
- The documentation that came with your other Allen-Bradley products.

Refer to the Literature Library (<http://literature.rockwellautomation.com>) for access to publications.

Follow These Steps

Complete the following steps to plan your system layout and wiring.



Planning Your ArmorStart Panel Layout and Wiring

The toolkit includes AutoCAD Electrical DWG project files that include panel layout and wiring diagrams that you can easily modify for your specific application. Individual DXF, and PDF files are also available for use in standard AutoCAD and non-AutoCAD drawing and image software packages. The diagrams include power and control wiring examples. The ArmorStart controllers are connected with ArmorStart media.


TIP

If you do not have CAD software, use the PDF files to build your system drawing.

Use CAD Drawings from the Toolkit CD

Refer to your bill of materials and follow these steps to access the AutoCAD drawings.

1. Browse to the System Layout and Wiring Diagrams directories on the toolkit CD.
2. Navigate to the desired (DWG, DXF, or PDF) file type directories.



3. Select ArmorStart Files.
4. Add the required files to your project or copy them to your project folder.


The drawings were created using AutoCAD Electrical. The project files are included in the DWG directory. The path references in the project file are the default AutoCAD Electrical installation path.

Panel Layout Diagrams

The AutoCAD Electrical project includes several panel-layout diagrams (with BOM) based on the ArmorStart distributed motor controllers. Choose an appropriate diagram as a starting point. Add or remove components as needed.

The example shows a control panel with a ControlLogix controller, PanelView display, and stack lights as well as control power components. The ArmorStart controllers are typically on the machine such as a conveyor and are connected by using ArmorConnect media.

Sample ArmorStart Panel Layout



Sample Bill of Material


ITEM	QTY	DESCRIPTION	MFG	CATALOG
01	1	NEMA1 ENCLOSURE 30"x24"x10"	HOF	CSD302410
02	1	PANEL FOR ENCLOSURE 21"x22.5"	HOF	CP3024
03	1	FUSED DISCONNECT 30A CLASS J 3 POLE	AB	194R-J30-1753
04	1	DISCONNECT OPERATOR HANDLE TYPE 4/4X RED/YELLOW	AB	194R-HS4E
05	1	DISCONNECT OPERATING SHAFT HANDLE KIT	AB	194R-NHR1
06	1	FUSE HOLDER 3 POLE CLASS C LED BLOWN FUSE INDICATOR	AB	1492-FB3C30-L
07	2	SAFETY CONTACTOR 30A 24VDC COIL W/DIODE	AB	100S-C30DJ14C
08	1	MSR126T SAFETY RELAY	AB	440R-N23117
09	2	CIRCUIT BREAKER 6A 1 POLE	AB	1489-A1C060
10	1	CIRCUIT BREAKER 5A 1 POLE	AB	1489-A1C050
11	1	CIRCUIT BREAKER 4A 1 POLE	AB	1489-A1C040
12	1	CIRCUIT BREAKER 10A 2 POLE	AB	1489-A2C100
13	1	TRANSFORMER 500VA 240/480V PRIMARY 120V SECONDARY	AB	1497-G-BASX-3-N
14	1	POWER SUPPLY 24VDC 240W	AB	1606-XLS240E
15	1	POWER SUPPLY 24VDC 91W DEVICENET	AB	1606-XLSDNET4
16	1	CONTROLLOGIX 4 SLOT CHASSIS	AB	1756-A4
17	1	CONTROLLOGIX POWER SUPPLY 85-265VAC	AB	1756-PA72
18	1	CONTROLLOGIX L63 PROCESSOR	AB	1756-L63
19	1	CONTROLLOGIX DEVICENET BRIDGE/SCANNER MODULE	AB	1756-DNB
20	1	CONTROLLOGIX ETHERNET/IP BRIDGE MODULE	AB	1756-ENBT
21	1	CONTROLLOGIX SLOT FILLER	AB	1756-N2
22	1	STRATIX 2000 SWITCH UNMANAGED 5 PORTS	AB	1783-US05T
23	1	PANELVIEW PLUS 600 COLOR TOUCHSCREEN	AB	2711P-T6C20D
24	1	STACK LIGHT, VERTICAL MOUNT 1RED,1GREEN STEADY, 24VDC	AB	855EY-B24YL34
25	1	MUSHROOM HEAD OPERATOR TWIST TO RELEASE 30mm	AB	800FP-MT34
26	1	LEGEND PLATE 60mm ROUND YELLOW EMERGENCY STOP	AB	800F-15YSE112
27	1	PHOTO ELECTRIC SENSOR, RIGHTSIGHT, (PNP) 4PIN DC MICRO	AB	42EF-S1MPA-F4
28	1	RIGHT ANGLE BRACKET FOR PHOTO SENSOR	AB	60-2696
29	-	DIN RAIL 35mm x 7.5mm	AB	199-DR1
30	10	TERMINAL BLOCK FEED THRU GRAY	AB	1492-J3
31	4	TERMINAL BLOCK CENTER JUMPER 2 POLE	AB	1492-CJJ5-2
32	9	TERMINAL BLOCK END RETAINER	AB	1492-EAJ35
33	3	TERMINAL BLOCK END BARRIER	AB	1492-EBJ3
34	1	TERMINAL BLOCK SNAP-IN MARKER CARD	AB	1492-MSX15
35	-	PANDUIT WIRE DUCT, 1"x4" GRAY	PANDUIT	F1X4LG6
36	-	PANDUIT WIRE DUCT COVER, 1" GRAY	PANDUIT	C1LG6
37	-	PANDUIT WIRE DUCT, 1" x4" WHITE	PANDUIT	F1X4WH6
38	-	PANDUIT WIRE DUCT COVER, 1" WHITE	PANDUIT	C1WH6
39	1	FAN KIT 115V WITH FILTER	HOFFMAN	TFP41
40	1	EXHAUST GRILL WITH FILTER	HOFFMAN	TEP4

ArmorStart Distributed Motor Controllers Wiring Diagrams

The AutoCAD Electrical project includes a variety of ArmorStart wiring diagrams. The drawing titles indicate ArmorStart controller types. Add or remove components and drawings as needed.

This example shows power wiring for an ArmorStart 284D device and other power components.

Sample CAD Wiring Diagram



Access Other Allen-Bradley CAD Drawings

Follow these steps to download other Allen-Bradley product CAD drawings.

1. Open your browser and go to <http://ab.com/e-tools>.

The Configuration and Selection Tools web page opens.

Configuration & Selection Tools

- > Product Selection
 - Overview
 - + Get the Product Selection Toolbox
- System Configuration
- Product Drawings
- Integrated Architecture Tools
- + Get Support Now

Resources

- Product Directory
- Product Certification
- Product Cross Reference
- Literature Library

CONFIGURATION & SELECTION TOOLS

Rockwell Automation offers a powerful range of product selection and system configuration tools to assist you to choose and apply our products. There are tools available on-line and for you to install on your personal computer so that you can quickly access information on our products while in the office or on the go.

Product Selection | System Configuration | Product Drawings

- **Build/Validate A Catalog Number** – Build, Verify and Get Information and CAD Drawings for Products
To verify a catalog number, acquire drawings and product information enter the complete number (including dashes) below.
Catalog Number:
You can also browse our [product directory](#) for additional product information or to configure a part.
NOTE: You must be [logged in](#) to correctly view US or Canadian dollar results.

TIP

If you know the complete catalog number of your Allen-Bradley product, you can enter it here and click Submit. However, you need a complete catalog number string to get the configuration results.

2. If you don't know the complete catalog number, click product directory to browse the configured Rockwell Automation products.
3. Click Rockwell Automation and follow the prompts.

If you know the complete catalog number of your Allen-Bradley product, enter it here and click Submit. You need the complete catalog number to receive the configuration results.

Select and Configure Products

[Back](#)

Rockwell Automation/Allen-Bradley Product Catalog

- [Rockwell Automation](#)
- [Services](#)
- [Encompass Partner Library](#)

Wiring Your ArmorStart Controllers

This section provides information pertaining to wiring your ArmorStart distributive motor controller.

General Precautions

ATTENTION

The controller contains electrostatic discharge (ESD) sensitive parts and assemblies. Static control precautions are required when installing, testing, servicing, or repairing the assembly. Component damage may result if the ESD control procedures are not followed. If you are not familiar with static control procedures, refer to Guarding Against Electrostatic Discharge, publication [8000-SB001](#), or any other ESD protection documents.

ATTENTION

An incorrectly applied or installed controller can damage components or reduce product life. Wiring or application errors, such as an undersized motor, incorrect or inadequate AC supply, or excessive ambient temperatures, may result in malfunction of the system.

ATTENTION

Only personnel familiar with the controller and associated machinery should plan or implement the installation, startup, and subsequent maintenance of the system. Failure to do so may result in personal injury and equipment damage.

Additional Precautions for the Bulletin 284 Devices

ATTENTION

The ArmorStart device contains high-voltage capacitors which take time to discharge after removal of mains supply. Before working on an ArmorStart device, help ensure isolation of mains supply from line inputs [R, S, T (L1, L2, and L3)]. Wait at least three minutes for the capacitors to discharge to a safe voltage level. Failure to do so may result in personal injury or death. Darkened display indicators are not an indication that the capacitors have discharged to safe levels.

Only qualified personnel familiar with ArmorStart devices and associated machinery should plan or implement the installation, startup, and subsequent maintenance of the system. Failure to do so may result in personal injury and equipment damage.

ArmorStart Device Wiring

Wiring in an industrial control application can be divided into three groups; power, control, and signal. Follow these recommendations for physical separation between these to reduce the coupling effect:

- Minimum spacing between different wire groups in the same tray should be 16 cm (6 in.).
- Run wire outside an enclosure conduit or have shielding or armor with equivalent attenuation.
- Run different wire groups in separate conduits.
- Minimum spacing between conduits containing different groups should be 8 cm (3 in.).


The table provides power, control, ground wire capacity, and tightening torque requirements. The power, control, ground, and safety monitor terminals accept a maximum of two-wire per terminal.

Power, Control, Safety Monitor Inputs, Ground Wire Size, and Torque Specifications


Terminal Type	Wire Size	Torque	Wire Strip Length
Power and Ground	Primary/secondary terminal 1.5...4.0 mm ² (16...10 AWG)	Primary terminal - 1.2 N•m (10.8 lb•in.) Secondary terminal - 0.5 N•m (4.5 lb•in.)	9 mm (0.35 in)
Control and Safety Monitor Inputs	1.0...4.0 mm ² (18...10 AWG)	0.7 N•m (6.2 lb•in.)	9 mm (0.35 in.)

The following illustrations and table provide various terminal designations.


Bulletin 280/281 ArmorStart Power and Control Terminals



Bulletin 283 ArmorStart Power and Control Terminals



Bulletin 284 ArmorStart Power and Control Terminals



Power, Control, Safety Monitor, and Ground Terminal Designations


Terminal Designation	Description
SM11	Safety monitor input
SM2 ¹	Safety monitor input
A1(+)	Control power input
A2(-)	Control power common
PE	Ground
1/L1	Line power phase A
3/L2	Line power phase B
5/L3	Line power phase C

¹ Only available with the Safety Monitor option.

Connecting the DeviceNet ArmorConnect to Your ArmorStart Device

The ArmorConnect power media offers both three-phase and control power cable system of cord sets, patch cords, receptacles, tees, reducers, and accessories for use with the ArmorStart distributed motor controller. These cable system components allow quick connection of ArmorStart distributed motor controllers, reducing installation time. They provide for repeatable, reliable connection of the three-phase and control power to the ArmorStart distributed motor controller and motor by providing a plug-and-play environment that also avoids system miss wiring. When specifying power media for the ArmorStart distributed motor controllers (Bulletin 280/281, 283, and 284), use only the Bulletin 280 ArmorConnect power media.


Three-phase Power System Overview



ID	Cat. No.	Description
1	280-PWR35A-Mx ¹	Three-phase power trunk—Patchcord cable with integral female or male connector on each end.
2	280-PWR22A-Mx ¹	Three-phase drop cable—Patchcord cable with integral female or male connector on each end.
3	280-T35	Three-Phase power tees and reducer—Tee connects to a single drop line to trunk with quick change connectors.
	280-RT35	Reducing tee connects to a single drop line (mini) to trunk (quick change) connector.
	280-RA35	Reducer connects from quick change male connector to mini female connector.
4	280-M35F-M1	Three-phase power receptacles—Female receptacles are a panel mount connector with flying leads

¹ "x" represents number needed for cable length. See the three-phase power media section of the ArmorStart Distributed MotorController and ArmorConnect Power Media Selection Guide, publication [280-SG001](#), for available lengths.


Control Power Media System Overview




ID	Cat. No.	Description
6	889N-F65GFNM-x ¹	Control power media patchcords - Patchcord cable with integral female or male connector on each end.
7	898N-653ST-NKF	The E-stop in tee used to connect to the Bulletin 800F On-Machine E-Stop station by using a control power media patchcord.
	898N-653ES-NKF	The E-stop out tee is used with cordset or patchcord to connect to the ArmorStart distributed motor controller.
8	888N-D65AF1-x ¹	Control power receptacles - Female receptacles are a panel mount connector with flying leads.

¹ "x" represents number needed for desired cable length, which is 2 (2 meters/6.5 feet), 5 (5 m/16.4 ft), or 10 (10 m/32.8 ft).


ArmorStart Device with ArmorConnect Connectivity



Cord Grips for ArmorStart Devices with 10 A Short-circuit Protection Rating



Cord Grips for ArmorStart Devices with 25 A Short-circuit Protection Rating



Connector



Terminal Designations

Terminal Designation	Description	Color Code
A1(+)	Control power input	Blue
A2(-)	Control power common	Black
PE	Ground	Green/Yellow
1/L1	Line power phase A	Black
3/L3	Line power phase B	White
5/L5	Line power phase C	Red

AC Supply Considerations for Bulletin 284 Units

This section describes AC supply considerations for Bulletin 284 units.

Ungrounded and High-resistive Distribution Systems

ATTENTION




The Bulletin 284 device contains protective metal oxide variables (MOVs) that are referenced to ground. These devices should be disconnected if the Bulletin 284 device is installed on an ungrounded and high-resistive distribution system.

Disconnect MOVs

To prevent device damage, the MOVs connected to ground must be disconnected if the device is installed on an ungrounded and high resistive distribution system where the line-to-ground voltages on any phase could exceed 125% of the nominal line-to-line voltage. To disconnect the MOVs, follow this procedure to remove the jumper.

1. Loosen the four mounting screws before installing the Bulletin 284 device.
2. Unplug the started module from the base unit by pulling forward.



ATTENTION



Do not remove this jumper if the unit is equipped with an EMI filter installed.

The EMI Filter option is required if the Bulletin 284 ArmorStart Distributed Motor Controller must be CE-compliant. If the EMI Filter is selected, a 3 meter shielded 4-conductor cordset is provided as standard. This option is only available with sensorless vector control.

Group Motor Installations For North American and Canadian Markets

The ArmorStart distributed motor controllers are listed for use with each other in group installations per NFPA 79, Electrical Standard for Industrial Machinery. When applied according to the group motor installation requirements, two or more motors, of any rating or controller type, are permitted on a single branch circuit. Group motor installation has been successfully used for many years in North America and Canada.

Cabling and Installation Guidelines

In addition to conduit and seal-tight raceway, it is acceptable to use cable that is dual rated Tray Cable, Type TC-ER and Cord, STOOW, for power and control wiring on ArmorStart installations. In North America and Canada installations, the following guidelines are outlined by the NEC and NFPA 79.

In industrial environments where the conditions of maintenance and supervision ensure that only qualified personnel service the installation, and where the exposed cable is continuously supported and protected against physical damage by using mechanical protection, such as struts, angles, or channels, Type TC tray cable that complies with the crush and impact requirements of type metal clad (MC) cable and is identified for such use with the marking type TC-ER (Exposed Run) shall be permitted between a cable tray and the use equipment or device as open wiring. The cable shall be secured at intervals not exceeding 1.8 m (6 ft) and installed in a 'good workman-like' manner. Equipment grounding for the use equipment shall be provided by an equipment grounding conductor within the cable.

Cables meeting these crush and impact requirements were designated and marked 'Open Wiring'. Cable marked this way is equivalent to the present Type TC-ER and can be used.

Refer to the following when installing the ArmorStart device in factory floor environments of industrial applications.

ATTENTION



Cables, including those for control voltage including 24V DC and communication, are not to be exposed to an operator or building traffic on a continuous basis. Locate the ArmorStart device to minimize exposure to continual traffic is recommended. If the location to minimize traffic flow is unavoidable, other barriers to minimize inadvertent exposure to the cabling should be considered. Routing cables should be done in such a manner to minimize inadvertent exposure and/or damage.

Additionally, if conduit or other raceways are not used, we recommend that strain relief fittings be used when installing the cables for the control and power wiring through the conduit openings.

The working space around the ArmorStart device may be minimized as the ArmorStart device does not require examination, adjustment, servicing, or maintenance while energized. In lieu of this service, the ArmorStart device is meant to be unplugged and replaced after proper lockout and tag-out procedures have been employed.

Since the ArmorStart device is available with a factory installed HOA keypad option, this may require the ArmorStart device to be selected and installed as follows. If the application requires frequent use of the hand-operated interface by the equipment operator:

- they should not be less than 0.6 m (2 ft) above the servicing level and are within easy reach of the normal working position of the operator.
- the operator is not placed in a hazardous situation when operating them.
- the possibility of inadvertent operation is minimized.

If the operated interface is used in industrial environments where the conditions of maintenance and supervision ensure that only qualified persons operate and service the ArmorStart operator interface, and the installation is located so that inadvertent operation is minimized, then other installation locations with acceptable access can be provided.

DeviceNet Network Installation

The ArmorStart distributed motor controller contains the equivalent of 0.76 m (30 in) of DeviceNet drop cable's electrical characteristics and therefore 0.76 m (30 in) of drop cable must be included in the DeviceNet drop cable budget for each ArmorStart controller in addition to actual drop cable required for the installation.

The separation of the control power and DeviceNet power is recommended as a good design practice. This minimizes the load on the DeviceNet supply, and prevents transients which may be present on the control power system from influencing the communication controls.

Electromagnetic Compatibility

The following guidelines are provided for EMC installation compliance.

General Notes for Bulletin 284 Devices

- The motor cable should be kept as short as possible to avoid electromagnetic emission as well as capacitive currents
- Conformity of the device with CE EMC requirements does not guarantee an entire machine installation complies with CE EMC requirements. Many factors can influence total machine and installation compliance.
- Using an EMI filter with any ArmorStart device rating, may result in relatively high-ground leakage currents. Therefore, the filter must only be used in installations and solidly grounded (bonded) to the building power distribution ground. Grounding must not rely on flexible cables and should not include any form of plug or socket that would permit inadvertent disconnection. Some local codes may require redundant ground connections. The integrity of all connections should be periodically checked.

Ground the ArmorStart Controller

Connect a grounding conductor to the terminal provided as standard on each ArmorStart Distributed Motor Controller.

ArmorStart DeviceNet Configuration

In this chapter, you will configure your ArmorStart device by using RSNetWorx for DeviceNet software, RSLogix 5000 software, and the DeviceNet Tag Generator Tool. This significantly simplifies ArmorStart device configuration.

[Appendix A](#) on [page 155](#), includes the setup procedures for your personal computer and Logix communication. These procedures apply only if you are creating a new project file in RSLogix 5000 software.

Before You Begin


- Complete your system hardware selection (refer to [Chapter 1](#)).
- Complete your system layout and wiring (refer to [Chapter 2](#)).

What You Need

- ArmorStart Accelerator Toolkit CD, publication [IASIMP-SP015](#).
- RSLogix 5000 software, version 17.0 or later.
- RSLinx Classic software, version 2.50 or later.
- RSNetWorx for DeviceNet software, version 9.0 or later.
- The user manual for your ArmorStart controller. Refer to [Additional Resources](#) on [page 11](#) for publication numbers.

Follow These Steps

Complete the following steps to configure your ArmorStart device.



Open an Existing Project in RSLogix 5000 Software

IMPORTANT

If you are creating a new project and have not configured your personal computer communication or controller hardware, refer to [Appendix A](#) on [page 155](#).


1. Launch RSLogix 5000 software.



2. Select Open Project.

The Open/Import Project dialog box opens.

3. Browse to your controller file.
4. Click Open.




Configure the DeviceNet Network by Using RSNetWorx Software

1. Refer to [Chapter 2](#) for wiring the ArmorStart devices and the DeviceNet scanner module on the DeviceNet network.


Make sure that the devices are powered.

2. Launch RSNetWorx for DeviceNet software.




3. From the File menu, choose New.

4. Click the Online icon.




The network browser dialog box appears. This is where you select the Ethernet driver where the controller resides.

5. Select the appropriate controller, then expand the list to select the DeviceNet scanner in the controller.




6. Select the DeviceNet network.

7. Click OK.




Online devices on the selected DeviceNet network for the specific node address are displayed.




TIP

An electronic data sheet (EDS) file for each device should be loaded for each device type on the network. If there is a red question mark on the device, or the following message appears, you can download it from the Rockwell Automation website <http://www.ab.com/networks/eds>.




8. Double-click the ArmorStart device on a specific node address.
 - a. Upload the devices properties if they have not been yet.
 - b. Click Parameters on the device properties tab.
 - c. For the ArmorStart 280D and 281D device, make sure the consumed IO Assy is 160 and the Produce IO Assy is 161.




- d. Change any other parameter as needed for your specific application.
- e. For the ArmorStart 284D device, make sure the Consumed IO Assy is 164 and the Produced IO Assy is 165.

Change any other parameter as needed for your specific application.




9. If the Consumed IO Assy or any other parameter needs to be changed:
 - a. Click the current value.
 - b. Type in the appropriate value.
 - c. Click Apply.




Some parameters have predefined values you can select versus typing in a value.

- d. Click OK.


The  icon signifies a read-only parameter that cannot be configured.



10. Once you have browsed all of the nodes (63 total nodes on the DeviceNet network), right-click the scanner icon (the 1756-DNB icon), and choose Upload from Device.




11. Double-click the scanner icon.
 - a. Enter a new name for the scanner or accept the default name.
 - b. Make sure that the node address corresponds to the node on which the scanner is commissioned.
 - c. Click OK.




12. Click the Scanlist tab.
 - a. Select all of the devices that you want to scan from the Available Devices list and move them to the Scanlist window.

For example, the dialog box shows three ArmorStart devices configured in the scanlist.
 - b. Once the scanlist is populated, click Download to Scanner.



13. Click Apply then OK.


14. Save the .dnt file.




Add a Scanner Module to Your ControlLogix Project

Follow these steps to add and configure a DeviceNet scanner module to the controller.


1. In the RSLogix software, right-click I/O Configuration on the Controller Organizer window and select New Module. The Select Module dialog box appears.




2. Expand the Communications tree and select 1756-DNB.
3. Click OK.



4. In the New Modules dialog, enter the module name.
5. Choose the node number and slot number of where the DeviceNet module resides in the controller backplane.
6. Click OK twice.



A DeviceNet I/O module is added to the I/O configuration tree.




Generate ArmorStart Tags by Using the Tag Generator Tool

Follow these steps to generate ArmorStart device tags.


TIP

Make sure RSNetWorx software is closed before starting the DeviceNet Tag Generator Tool.


1. Launch the DeviceNet Tag Generator tool.




2. Select the RSLogix 5000 Project where tags need to be added.




3. Click Select Scanner and select the DeviceNet scanner module that was added in the previous section.




4. Click Select RSNetWorx and select the .dnt file that was saved from [page 65](#).



5. Click Select Scanner Node and then select the appropriate scanner node.



6. Click Generate Tags on the right side of the dialog box and then click the Generate Tags tab.



7. Close the Tag Generator tool after the tags are generated.

Download Controller File and Test ArmorStart Tags

Verify Tags

1. Go to the RSLogix 5000 editor and double-click Controller tags from the Controller Organizer window.

You'll see generated input and output tags for all of the devices that were added to the scanlist.

For example, the tag name `Dnet_ArmorStart_Module_N04_POL_I` is for input tags for an ArmorStart device located at node address 4. The tag name `Dnet_ArmorStart_Module_N04_POL_O` is for output tags for an ArmorStart device located at node address 4.

Name	Alias For	Base Tag	Data Type	Style
Dnet_ArmorStart_Module_N02_POL_I			AB_280D_F122_10B_I_C79A3567	
Dnet_ArmorStart_Module_N02_POL_O			AB_280D_F122_10B_O_01434119	
Dnet_ArmorStart_Module_N03_POL_I			AB_281D_F122_10A_I_A94E889C	
Dnet_ArmorStart_Module_N03_POL_O			AB_281D_F122_10A_O_DDF3D0DE	
Dnet_ArmorStart_Module_N04_POL_I			AB_284D_FHB2P3x_10_I_85284898	
Dnet_ArmorStart_Module_N04_POL_O			AB_284D_FHB2P3x_10_O_7B19C168	
FaultStatus			MESSAGE	
FaultTag			DINT	Decimal
forward_cmd_280			BOOL	Decimal
forward_cmd_281			BOOL	Decimal
forward_cmd_284			BOOL	Decimal
Local1:I			AB:1756_DNB_500Bytes:I:0	
Local1:O			AB:1756_DNB_496Bytes:O:0	
Local1:S			AB:1756_DNB_Status_128Bytes:S:0	
Motor_Fault_Msg_280			MESSAGE	
Motor_Fault_Msg_281			MESSAGE	
Motor_Fault_Msg_284			MESSAGE	
Motor_With_280			ArmorStart_280_AOI	
Motor_With_281			ArmorStart_281_AOI	
Motor_With_284			ArmorStart_284_AOI	
reset_trip_cmd_280			BOOL	Decimal
reset_trip_cmd_281			BOOL	Decimal

These are the tags that correspond to the parameters from the Produced IO instance for the corresponding ArmorStart device.

Dnet_ArmorStart_Module_N04_POL_I		AB_284D_FHB2P3x_10_I_85284898
Dnet_ArmorStart_Module_N04_POL_I.Tripped		BOOL
Dnet_ArmorStart_Module_N04_POL_I.Warning		BOOL
Dnet_ArmorStart_Module_N04_POL_I.RunningFwd		BOOL
Dnet_ArmorStart_Module_N04_POL_I.RunningRev		BOOL
Dnet_ArmorStart_Module_N04_POL_I.Ready		BOOL
Dnet_ArmorStart_Module_N04_POL_I.NetCtlStatus		BOOL
Dnet_ArmorStart_Module_N04_POL_I.NetRefStatus		BOOL
Dnet_ArmorStart_Module_N04_POL_I.AReference		BOOL
Dnet_ArmorStart_Module_N04_POL_I.Input0		BOOL
Dnet_ArmorStart_Module_N04_POL_I.Input1		BOOL
Dnet_ArmorStart_Module_N04_POL_I.Input2		BOOL
Dnet_ArmorStart_Module_N04_POL_I.Input3		BOOL
Dnet_ArmorStart_Module_N04_POL_I.HQASStatus		BOOL
Dnet_ArmorStart_Module_N04_POL_I_140MOn		BOOL
Dnet_ArmorStart_Module_N04_POL_I.Contactor1		BOOL
Dnet_ArmorStart_Module_N04_POL_I.Contactor2		BOOL
Dnet_ArmorStart_Module_N04_POL_I.OutputFrequency		INT

These are the tags that correspond to the parameters from the Consumed IO instance for the corresponding ArmorStart device.

Dnet_ArmorStart_Module_N04_POL_0	AB_284D_FHB2P3x_T0_0_7B19C168
Dnet_ArmorStart_Module_N04_POL_0.RunFwd	BOOL
Dnet_ArmorStart_Module_N04_POL_0.RunRev	BOOL
Dnet_ArmorStart_Module_N04_POL_0.FaultReset	BOOL
Dnet_ArmorStart_Module_N04_POL_0.JogFwd	BOOL
Dnet_ArmorStart_Module_N04_POL_0.JogRev	BOOL
Dnet_ArmorStart_Module_N04_POL_0.UndefinedData	BOOL
Dnet_ArmorStart_Module_N04_POL_0.UserOutA	BOOL
Dnet_ArmorStart_Module_N04_POL_0.UserOutB	BOOL
Dnet_ArmorStart_Module_N04_POL_0.Accel1En	BOOL
Dnet_ArmorStart_Module_N04_POL_0.Accel2En	BOOL
Dnet_ArmorStart_Module_N04_POL_0.Decel1En	BOOL
Dnet_ArmorStart_Module_N04_POL_0.Decel2En	BOOL
Dnet_ArmorStart_Module_N04_POL_0.DrvIn1	BOOL
Dnet_ArmorStart_Module_N04_POL_0.DrvIn2	BOOL
Dnet_ArmorStart_Module_N04_POL_0.DrvIn3	BOOL
Dnet_ArmorStart_Module_N04_POL_0.DrvIn4	BOOL
Dnet_ArmorStart_Module_N04_POL_0.CommFreqCmd	INT

Set Project Path and Download to Controller

1. Save your changes.



2. Move the keyswitch on controller to Program.




3. Click the Who Active button.




2. Expand the network tree.
3. Select your controller and click Set Project Path.

If using serial communications, verify that the 1756-CP3 cable is connected between the computer and the controller.


4. Click Download.



5. Click Download.



The project Path updates.



6. Move the keyswitch on controller to Run.

Device Tag Test Setup


The tags used in this test procedure apply to the ArmorStart 284D device. The tags for the other ArmorStart devices are different.

IMPORTANT


Before you begin the test, make sure the DeviceNet Scanner Module (DNBT) on the controller is set to Run.

Follow these steps to make sure the scanner is in Run mode.

1. Double-click Controller Tags, then click Show in the Controller Tag dialog box on the right.




2. In the Define Tag Filter dialog box clear all Data Types except Module-Defined.




3. Click OK.
DNBT Scanner module (DeviceNet) tags for input, output and status, are listed.

- Make sure the controller tags are in 'Monitor Tags' mode and not 'Edit Tags' mode by checking the tab field at the bottom.



- Expand the Local:1:0 (output tags) and within it, expand the Local:1:0.CommandRegister tag as shown.
- Locate the Local:1:0.CommandRegister.Run value and if set to 0, change value to 1.



- Check the DeviceNet scanner module on the controller and it should read 'Run' on it.

Test Procedure

- Place the keyswitch in the Run position.
- Double-click Controller Tags.



3. From the Monitor Tags tab, locate and expand the ArmorStart 284D output tags.

Follow this procedure if you need to change the value of a tag in RSLogix software.

Dnet_ArmorStart_Module_N04_POL_0		AB_284D_FHB2P3x_10_0_7B19C16B
-Dnet_ArmorStart_Module_N04_POL_0.RunFwd		BOOL
-Dnet_ArmorStart_Module_N04_POL_0.RunRev		BOOL
-Dnet_ArmorStart_Module_N04_POL_0.FaultReset		BOOL
-Dnet_ArmorStart_Module_N04_POL_0.JogFwd		BOOL
-Dnet_ArmorStart_Module_N04_POL_0.JogRev		BOOL
-Dnet_ArmorStart_Module_N04_POL_0.UndefinedData		BOOL
-Dnet_ArmorStart_Module_N04_POL_0.UserOutA		BOOL
-Dnet_ArmorStart_Module_N04_POL_0.UserOutB		BOOL
-Dnet_ArmorStart_Module_N04_POL_0.Accel1En		BOOL
-Dnet_ArmorStart_Module_N04_POL_0.Accel2En		BOOL
-Dnet_ArmorStart_Module_N04_POL_0.Decel1En		BOOL
-Dnet_ArmorStart_Module_N04_POL_0.Decel2En		BOOL
-Dnet_ArmorStart_Module_N04_POL_0.DrvIn1		BOOL
-Dnet_ArmorStart_Module_N04_POL_0.DrvIn2		BOOL
-Dnet_ArmorStart_Module_N04_POL_0.DrvIn3		BOOL
-Dnet_ArmorStart_Module_N04_POL_0.DrvIn4		BOOL
-Dnet_ArmorStart_Module_N04_POL_0.CommFreqCmd		INT

- Select the tag value.
- Enter or select the desired value.
- Press Enter.

4. Change the FaultReset tag to 1 and press Enter to clear any initial faults.

Dnet_ArmorStart_Module_N04_POL_0.FaultReset	1
---	---

5. Change FaultReset back to 0 and press enter.

Dnet_ArmorStart_Module_N04_POL_0.FaultReset	0
---	---

6. Verify that the I.Status_ready tag value is 1, indicating that the device is ready.

Dnet_ArmorStart_Module_N04_POL_I.Ready	1
--	---

7. Change the O.CommandFreq tag to 600 engineering units and press Enter.

+Dnet_ArmorStart_Module_N04_POL_0.CommFreqCmd	600
---	-----

This is 60.0 Hz.

ATTENTION



If there is a motor attached to your device, completing the next step will cause it to turn.

8. Change the RunFwd tag to 1 and press Enter.

Dnet_ArmorStart_Module_N04_POL_0.RunFwd	1
---	---

The display on the device registers the speed increase in Hz until the value entered at the reference tag is reached.

9. Change the RunFwd tag back to 0.

The display on the ArmorStart device will show the speed decreasing until it reaches 0.00 Hz.

By starting and stopping the device, you verified that the:

- Logix controller is communicating correctly with the device.
- A armorStart device can receive simple commands.

ArmorStart Local Control Configuration

In this chapter, you will configure your ArmorStart device for standalone or device level control. DeviceLogix devices have built-in processing capabilities that include controlled shutdowns in the event of network loss, or a controlled continuation of the process. It reduces the sense-to-actuation time, resulting in higher performance and simpler programming.

Before You Begin


- Complete your system hardware selection (refer to [Chapter 1](#)).
- Complete your system layout and wiring (refer to [Chapter 2](#)).
- Configure your ArmorStart device (refer to [Chapter 3](#)).

What You Need

- RSNetWorx for DeviceNet software, version 9.0 or later.
- The manual for how to program the DeviceLogix device. Refer to [Additional Resources](#) on [page 11](#) for publication numbers.

Follow These Steps

Complete the following steps to configure your ArmorStart devices for stand-alone DeviceLogix applications.



Create a DeviceLogix Program on an ArmorStart Device

Configuring DeviceLogix smart components for local control can be accomplished with RSNetWorx for DeviceNet software. With this software, you can set up DeviceNet components for system installation or field maintenance through the use of pull-down menus and dialog boxes. DeviceLogix enabled products can also be created and monitored using the 193-DNCT device. There are also two ways of creating the program; Ladder editor and Function Block Editor. This accelerator will demonstrate the use of the Function Block editor in RSNetWorx for DeviceNet.

The Function Block editor provides a graphical interface for configuring function blocks to provide local control within DeviceLogix-capable devices, such as the ArmorStart controllers. Refer to the DeviceLogix user manual for instructions on programming using the Ladder editor.

Follow these steps to create a DeviceLogix program on an existing network.

1. Open RSNetWorx for DeviceNet software.




2. Go online with the DeviceNet network.


3. Double-click the ArmorStart icon.
The actual ArmorStart device and node address may be different from the one shown.




4. Click the DeviceLogix tab.




5. Click Upload if you are prompted.



- Click Start Logix Editor.



- If the DeviceLogix Editor Style dialog box appears, select function Block Editor.




- Click OK.

You are now ready to begin building your logic program.


Build Your Logic Program

Follow these steps to build your logic program.


- In the Logic editor, click the edit icon to enter the Edit mode.




- Click Yes to enter Edit mode.




When in Edit mode, the following buttons appear for use in creating the logic program.




3. Drag the Bit Input icon  from the Timer/Counter or Move/Logical tab to the grid.




4. Double-click the tag and then click the down arrow.
5. Click the '+' next to Network Boolean.



6. Double-click Net Input 0.




7. Repeat steps 3 and 4 then click the '+' next to Hardware Boolean Input.
8. From the Hardware Boolean Input, select Input0.




9. Click the Move/Logical tab.

10. Drag the BAND tag to the grid.




11. Drag the Net Input0 connection point to the In1 connection point.


12. Click In1 again to make the connection.
The line will remain indicating that the connection is made.



13. Repeat steps 10 to 12 connect the IO Input0 tab to the In2 connection point.




14. Click and hold the Bit Output tab  on the toolbar.




15. Drag the BAND function block to the left.

16. Double-click the '?' in the Bit Output tab.




17. Click the down arrow.


18. Click the '+' next to Hardware Boolean.



19. Double-click Run Fwd.




20. Connect the BAND block to the Run Fwd tag.



21. From the Edit pull-down menu, choose Recovery Mode.


22. Click Enabled.

23. Click OK.



24. Click the Logic Verify  icon on the toolbar to determine if the program is valid and error-free.

If the logic is valid and passed certification, the following dialog box appears.




25. Click OK.

26. Click the Edit mode icon  to exit the editor.

If the logic fails verification, the following dialog box appears.


27. Click OK.

You will return to the logic editor where you can make the necessary changes and revalidate the program.




Download Program to ArmorStart

1. Download the program to the ArmorStart device by choosing Download from the communication pull-down menu.



2. Click OK if the download is successful.




3. From the Communications menu, choose Logic Enable On.


This will enable logic in the ArmorStart device.



4. From the File menu choose File>Close.



5. Click Apply, then OK.



If the master scanner is currently scanning the ArmorStart device to which you are downloading, you must first access the DeviceNet's scanner's scanlist to remove the device from the scanlist. If this new logic results in different connection sizes, adjust the master scanner as follows:


- a. Put the master in Idle mode.
This may mean turning a processor's key switch to PROG.
- b. Access the ArmorStart parameter's to change the size of the connections (parameters 11 and 12, Consumed and Produced IO Assy).
- c. Download the device to the scanlist.
- d. Click the Edit I/O Parameters button and verify the Rx and Tx size corresponds to the new connection size.
- e. Put the master in RUN mode for normal operation.

See [Chapter 3](#) for examples of moving the ArmorStart device to the scanlist.

Standalone Device

Set the comms parameters if the ArmorStart is a standalone device.


1. Select the parameters tab.
2. Set parameter 8 and 9 to Enabled.



DeviceLogix Programming Example


This example is a combination of different modes that can be used together in an application for the 284D ArmorStart device. A logic controller ladder logic program is controlling the ArmorStart device (auto control). In the event of an I/O connection fault, the external push buttons (manual control) will be allowed to control the ArmorStart and local I/O. A tripped condition, whether in manual or auto control, will provide a status indication of a trip using a stack light (controlled by output A). An IO Connection fault is also indicated on the same stack light. In an IO Connection fault, the stack light will be steady state. If both happen, the stack light will remain solid. In addition to the fault or tripped indication on the stack light, a second stack light is used to indicate the ArmorStart device is given a run command either from the PLC processor or the push buttons. Drive input 1 is used to command the preset speed of the drive in manual control.

DeviceLogix Example




The automatic (PLC processor) controlled portion of the DeviceLogix example shows the network input 0 and IO Connection fault negated to provide an output. The Boolean OR gate is in place for a second input that is used later in the example. If there is an IO Connection fault, the PLC processor will not be able to control the DeviceNetLogix device.

Network Input 0 Logic




If there is an IO Connection fault, manual operation from a pendant station or other push buttons will be allowed. In this example, input 1 of the Boolean OR gate is used for the PLC control. In manual control, input 0 could be from a sensor on a conveyor belt in which after manually starting the conveyor using a pendant station, the product will pass the sensor. After a user selected count, the conveyor motor will stop until another start command is given. Multiple sensors can be used along with logic to start and stop the motor.

Input 1 Logic




The program also shows one of the ways in which a fault or trip can be programmed via the DeviceLogix program. For example, a flashing stack light can be an indication of a fault or trip.

Flashing Stack Light Logic



The DeviceLogix program can also be created to prevent unwanted automatic restarts after clearing a fault.

Unwanted Automatic Restart Logic



Here is a list of hardware inputs and status inputs that can be used in the DeviceLogix program with the ArmorStart device.

Hardware and Status Inputs

Name	DataType
Hardware Boolean...	
Input 0	BOOLEAN
Input 1	BOOLEAN
Input 2	BOOLEAN
Input 3	BOOLEAN
Status Input	
Tripped	BOOLEAN
Warning	BOOLEAN
Running Fwd	BOOLEAN
Running Rev	BOOLEAN
Ready	BOOLEAN
Net Ctl Status	BOOLEAN
Net Ref Status	BOOLEAN
At Reference	BOOLEAN
Keypad Jog	BOOLEAN
Keypad Hand	BOOLEAN
HOA Status	BOOLEAN
140M On	BOOLEAN
Contactor 1	BOOLEAN
Contactor 2	BOOLEAN
Exp Cnxn	BOOLEAN
IO Cnxn	BOOLEAN
Exp Flt	BOOLEAN
IO Cnxn Flt	BOOLEAN
IO Cnxn Idle	BOOLEAN
Hand Direction	BOOLEAN
ZIP1 Cnxn	BOOLEAN
ZIP1 Flt	BOOLEAN
ZIP2 Cnxn	BOOLEAN
ZIP2 Flt	BOOLEAN
ZIP3 Cnxn	BOOLEAN
ZIP3 Flt	BOOLEAN
ZIP4 Cnxn	BOOLEAN
ZIP4 Flt	BOOLEAN
Fault Input	
Network Boolean ...	

Fault Inputs

Name	DataType
Hardware Boolean...	
Status Input	
Fault Input	
Short Circuit	BOOLEAN
Overload	BOOLEAN
Phase Short	BOOLEAN
Ground Fault	BOOLEAN
Stall	BOOLEAN
Control Power	BOOLEAN
IO Fault	BOOLEAN
Over Temp	BOOLEAN
Over-Current	BOOLEAN
DNet Power ...	BOOLEAN
Internal Comm	BOOLEAN
DC Bus Faults	BOOLEAN
EEProm	BOOLEAN
HW Flt	BOOLEAN
Retries	BOOLEAN
Misc. Fault	BOOLEAN
CP Warning	BOOLEAN
IO Warning	BOOLEAN
DN Warning	BOOLEAN
HW Warning	BOOLEAN
Network Boolean ...	

Network Inputs

Name	DataType
Network Boolean ...	
Net Input 0	BOOLEAN
Net Input 1	BOOLEAN
Net Input 2	BOOLEAN
Net Input 3	BOOLEAN
Net Input 4	BOOLEAN
Net Input 5	BOOLEAN
Net Input 6	BOOLEAN
Net Input 7	BOOLEAN
Net Input 8	BOOLEAN
Net Input 9	BOOLEAN
Net Input 10	BOOLEAN
Net Input 11	BOOLEAN
Net Input 12	BOOLEAN
Net Input 13	BOOLEAN
Net Input 14	BOOLEAN
Net Input 15	BOOLEAN
ZIP 0	BOOLEAN
ZIP 1	BOOLEAN
ZIP 2	BOOLEAN
ZIP 3	BOOLEAN
ZIP 4	BOOLEAN
ZIP 5	BOOLEAN
ZIP 6	BOOLEAN
ZIP 7	BOOLEAN
ZIP 8	BOOLEAN
ZIP 9	BOOLEAN
ZIP 10	BOOLEAN
ZIP 11	BOOLEAN
ZIP 12	BOOLEAN
ZIP 13	BOOLEAN
ZIP 14	BOOLEAN
ZIP 15	BOOLEAN
ZIP 16	BOOLEAN
ZIP 17	BOOLEAN
ZIP 18	BOOLEAN
ZIP 19	BOOLEAN
ZIP 20	BOOLEAN
ZIP 21	BOOLEAN

Notes:

Faceplate Logix Integration

In this chapter you import pre-configured logic, referred to as an Add-On Instruction (AOI), into your RSLogix 5000 application that integrates your ArmorStart device configuration with the ArmorStart faceplate. This chapter also provides instructions on how to configure the Add-On Instruction to work with the Equipment Status and ME Alarm History faceplates and how to integrate the Add-On Instructions into your specific application logic.

Before You Begin


- Complete your system hardware selection (refer to [Chapter 1](#)).
- Complete your system layout and wiring (refer to [Chapter 2](#)).
- Configure your ArmorStart device (refer to [Chapter 3](#)).

What You Need

- ArmorStart Accelerator Toolkit CD, publication [IASIMP-SP015](#).
- ArmorStart device.
- RSLogix 5000 software, version 17.0 or later.
- RSLinx Classic software, version 2.50 or later.
- RSLogix 5000 Start Page Resource Center for related Logix controller hardware and software manuals.
- The user manual for your ArmorStart device. Refer to [Additional Resources](#) on [page 11](#) for publication numbers.

Follow These Steps

Complete the following steps to add the necessary logic to your RSLogix 5000 application for use with the ArmorStart faceplates.






Import the ArmorStart Add-On Instructions

The pre-configured ArmorStart Add-On Instructions provide the logic for the pre-configured FactoryTalk View Machine Edition ArmorStart faceplates. These pre-configured faceplates let you monitor, control, and diagnose your ArmorStart device from a PanelView Plus terminal or Industrial Computer.

The ArmorStart 284 illustration to the right is a pre-configured FactoryTalk View Machine Edition Goto Display button that will launch the on-top display just below it. This is the initial display that provides operator monitoring and control. The toolbar buttons on that display let you navigate through the additional status, configuration, and diagnostic displays provided in this faceplate.

Follow these steps to import the pre-configured ArmorStart Add-On Instruction into your RSLogix 5000 software application.


1. Open your RSLogix 5000 software application.
2. Right-click the Add-On Instructions folder and select Import Add-On Instruction.
3. Browse to the ArmorStart Faceplate files on the toolkit CD.
4. Open the Controller Program Files folder if you are using FactoryTalk View Machine Edition software for your HMI software.



5. Select the ArmorStart Add-On Instruction faceplate file appropriate for your ArmorStart service class.

In this example, the ArmorStart_284_AOI file is chosen.

6. Click Import.




Reassign Add-On Instruction Input and Output Parameter Data Types

If your application requires additional data from the device that is not included within the imported Add-On Instruction for the faceplate, then refer to [Chapter 3](#) on [page 57](#) where ArmorStart specific tags were generated by using the DeviceNet Tag Generator tool.

Follow these steps to reassign the input and output parameter data types for your device.

1. In the project file Explorer window, expand the Add-On Instructions folder.
 2. Select the appropriate ArmorStart Add-On Instruction file you are using and double-click Parameters and Local Tags.
- A armorStart_284_AOI was selected in this example.




3. Scroll to and select the Inp_ArmorStart_xxx AOI tag and click  next to the Data Type field.

The Select Data Type dialog box opens.

4. Browse to the Input Data Type that matches the ArmorStart type, DeviceNet node, and data type that was created when you generated tags for the device, by using the DeviceNet tag generator tool in [Chapter 3](#).

It should have a name similar to the device you configured, for example, AB_284D_FHB2P3X10_I_85284B98.

If you have multiple ArmorStart devices configured in RSLogix 5000 software, you also need to create unique Add-On Instruction files for those ArmorStart devices as well.



5. Click OK.

The Data Type field updates. This example shows a ArmorStart 284 input tag's data type.


Controller_Trigger	Output	BOOL	Decimal
DeviceNet_Node	Input	DINT	Decimal
EnableIn	Input	BOOL	Decimal
EnableOut	Output	BOOL	Decimal
Fault_Msg	InOut	MESSAGE	
Fault_Msg_Code	Output	DINT	Decimal
Inp_ArmorStart_284	InOut	AB_284D_FHB2P3x_10_I_85284B98	
Inp_Scaled_Speed_At_240Hz	Input	REAL	Float
OperONS	Local	BOOL	Decimal
Out_ArmorStart_284	InOut	AB_284D_FHB2P3x_10_O_7B19C16B	
RunningFwd	Output	BOOL	Decimal

6. Select the Out_ArmorStart_xx AOI tag and click  next to the data type field.

The Select Data Type dialog box opens.


7. Browse to the output data type that matches the Data Type that was created when you configured the device in [Chapter 3](#).

It should have a name similar to the device you configured, for example, AB_284D-FHB2P3x_10_O_7B19C16B.



8. Click OK.

The Data Type field updates. This example shows an ArmorStart 284 output tag's data type.




9. Select the Sts_DeviceNet_Scanner tag and click the browse button to display the data type field.

The Select Data Type dialog box appears.

10. Browse to the status data type that matches the DNB scanner module data type that was created when you configured the scanner in [Chapter 3](#).

11. Click OK.



The Data Type field updates. This example shows a DeviceNet Scanner status tags' data type.

Set_Value4Units	Local	STRING	
storage_bit2	Local	BOOL	D
Sts_ArmorStartAlarmTrigger	Output	DINT	D
Sts_CommFault	Input	BOOL	D
Sts_DeviceNet_Scanner	InOut	AB:1756_DNB_Status_128Bytes:S:0	D
Sts_DeviceState	Output	DINT	D
Sts_DriveStatus	Output	DINT	D

12. Close Parameters and Local tags when finished.

Modify ArmorStart Add-On Instruction for Equipment Status Faceplate

TIP

This is an optional step and necessary only if you intend to use the Equipment Status Faceplate. To skip this step, go to [Integrate ArmorStart AOI into Your Application Program Routines](#) on [page 96](#).

IMPORTANT

To incorporate Equipment Status Faceplate into your application, make sure the PanelView Plus terminal supports 800x600 window size.

The ME Equipment Status Faceplate files let you quickly load and configure a summary display of pre-configured status and diagnostic displays or faceplates for FactoryTalk View Machine Edition software. The Equipment Status Faceplate works in conjunction with individual device faceplates and provides a single summary display of all the faceplates that may be configured for an application. You can configure up to nine device faceplates to run with the Equipment Status faceplate and you can launch each device faceplate directly from it.

This example shows the Equipment Status Faceplate that you can add to your specific hardware system display. This faceplate is configured for three rows or three devices and provides overall status of the device, up to four additional status values to be monitored, and can launch the individual device faceplates for more detailed information.

Example of Equipment Status Display Configured with Three Device Faceplates

You can launch these faceplates from the Goto buttons.


Equipment Status					
Device	State	Value 1	Value 2	Value 3	Value 4
ArmorStart 284D	ENABLED	0.000 SPEED	0.000 units	0.000 units	0.000 units
ArmorStart 280D	DISABLED	0.000 units	0.000 units	0.000 units	0.000 units
ArmorStart 281D	DISABLED	0.000 units	0.000 units	0.000 units	0.000 units

Follow these steps to modify your ArmorStart Add-On Instruction by using the Equipment Status Faceplate and the ArmorStart device you just configured.

1. Determine how many of the nine available rows you will use on the Equipment Status faceplate and which device faceplate you will assign to each row.

2. Set the tag Inp_NumRowsVis for your ArmorStart Add-On Instruction to the number of rows that you will use on the Equipment Status Faceplate.

- a. Under the Add-On Instructions folder in the system tree, double-click the ArmorStart Add-On Instruction that you will use for the device in row 1.
- b. Under the Parameters tab, find the Inp_NumRowsVis tag and check the Vis box to make the tag visible on the AOI.



This tag only needs to be set for the Add-On Instruction used in row 1 of the faceplate.


The default number of rows, 'Inp_NumRowsVis' is set to 9. You can change the number of rows displayed here by changing the default, or edit the field directly on the Add-On Instruction when creating your ladder rungs.

Sts_Value4	0.0	Float	☐	☐
* Inp_NumRowsVis	9	Decimal	☐	☒
Set_EquipFaceplateAnimation	0	Decimal	☐	☐

Integrate ArmorStart AOI into Your Application Program Routines

Follow these steps to add ArmorStart Add-On Instruction into your application program routines for each of your ArmorStart devices that you have configured.

1. Open the intended program routine.
2. Create a rung.
3. Click the Add-On Instruction tab.




4. Select the ArmorStart Add-On Instruction.

In this example, the ArmorStart_284_AOI file is selected.


5. Assign an ArmorStart Data Type tag to the main AOI tag with the same name of the module you want to control and monitor.

In this example the tag name is Motor_with_284.


6. Right-click the tag and associate Motor_with_284 tag with the ArmorStart_284_AOI Data Type.



7. Right click the Inp_ArmorStart_284 tag and select the module Input tag for the Add-On Instruction file you configured previously.



8. Right-click the Out_ArmorStart_284 tag and select the module Output tag for the Add-On Instruction file you configured previously.




TIP


Be sure to save your application file after additions are made.

9. Enter the Inp_Scaled_Speed_At_XXXX value.

The Add-On Instruction scales the drive input and output speed values based on the value entered.



To access the fault codes for the ArmorStart device, you need to get an explicit message. Fault_Msg parameter is of the data type message. It needs to be connected to the Explicit Message tag already in the Add-On Instruction as shown in the example.




10. Click next to the Motor_Fault_Msg tag.


The Message Configuration -Motor_Fault_Msg_284 dialog box appears.

11. From the pull-down menus and fields, choose the appropriate settings as follows:

- Message Type = CIP Generic
- Service Type = Get Attribute Single
- Class = 29
- Attribute = 9c
- Instance = 1




12. From the Destination pull-down menu, choose Motor_With_284.Fault_Msg_code.



13. Click the Communication tab.

The communication properties are displayed.

Notice that the Path has not been identified.





14. Click Browse to enter the path.

- Select the previous module followed by a comma.
- Enter 2 for the port of the scanner module.
- Enter the DeviceNet node address of the ArmorStart device that is communicated with, to get the fault codes. For this example, the Armorstart node address is 4.

Make sure all three entries are separated by commas:


Dnet_ArmorStart_Module, 2, 4



15. Click OK.

16. Click the Tag tab.


17. Verify that the name in the name field is Motor_Fault_Msg_xxx which is the tag in AOI.



18. Right click on Sts_DeviceNet_Scanner tag and select the Local:1:S tag from the list.


It is the module defined tag and displays the status of the DNBt scanner.

19. Click OK.



20. Enter the DeviceNet_Node value that corresponds to the node address of the device that it is connected to.

For this example, the node of the ArmorStart 284 device is 4.



Integrate Your ArmorStart Device Application

The individual Add-On Instructions include the interface logic and tags from both the faceplate (operator control) and application program (program control) to monitor and control the ArmorStart device.


IMPORTANT

Do not write directly to the Corresponding ArmorStart Device Tags that are listed in the ArmorStart Command and Set Value Tags tables in [Add-On Instruction Program Tag Listing and Function](#), on [page 104](#).

Understanding Operator Control and Program Control Transfer Logic

The first three rungs of each Add-On Instruction file handle the transfer of control from the Logix program (program control) to the faceplate (operator control). It is important that you understand how the two operator control rungs (shown below) operate so you achieve the program-to-operator and operator-to-program control transfers.

Two Operator Rungs



In this example, the rungs enable operator control of the intended ArmorStart device. You can initiate Command requests (Cmd) from either the Logix Programs (ProgOperReq) or FactoryTalk View ME ArmorStart Faceplate (OperOperReq).

Enabling Operator Control of Drive

To enable operator control for an ArmorStart associated with Motor_with_284 AOI instance, you could add a rung to the Logix MainRoutine with specific input conditions driving an output instruction with the tag name Motor_with_284.Cmd_ProgOperReq. Likewise, you could add a push button within a FactoryTalk View ME/SE Faceplate with a value tag name of #1.Cmd_OperOperReq with the #1 parameter for that faceplate display associated with Motor_with_284.

A Motor_with_284.Cmd_ProgToOperPermissive tag must also be included in the Logix program to control whether program-to-operator control transfer requests are allowed or acted upon. A tag value of 1 permits

the associated control transfer requests. A value of 0 prevents the associated control transfer requests.

ATTENTION

If an `Xxxx.Cmd_ProgToOperPermissive` tag is set to 1, the associated Add-On Instruction is programmed to allow a transfer from Program Control to Operator Control regardless of the current direction, speed, or active status of the ArmorStart device. In addition, the AOI is programmed to transfer the current Program Speed value `Xxxx.Set_SpeedProg` to the associated Operator Speed tag, `Xxxx.Set_SpeedOper`, creating a bumpless transfer when a transfer from Program Control to Operator Control is executed.

Therefore, if the ArmorStart device is running at the time of a program-to-operator control transition, the ArmorStart device continues to run at the most recent commanded Program Speed. If a different program-to-operator control transition is desired, then the status of the ArmorStart device and the operator command requests must be monitored and the appropriate program commands must be issued before the `Xxxx.Cmd_ProgToOperPermissive` is allowed. Therefore, it is very important that the status of the ArmorStart device is monitored and appropriate program commands, for the specific application, are issued before the `Xxxx.Cmd_ProgToOperPermissive` tag is set. This makes sure that a safe program-to-operator control transfer is executed.

ATTENTION

If an `Xxxx.Cmd_OperToProgramPermissive` tag is set to 1, the associated AOI is programmed to allow a transfer from Operator Control to Program Control regardless of the current direction, speed, or active status of the ArmorStart device.

In addition, there is no logic within the Add-On Instruction that sets the `Set_SpeedProg` upon transfer to Program mode, so the ArmorStart device assumes the last commanded `Set_SpeedProg` speed value unless logic is programmed outside of the Add-On Instruction to set it to a different value. Therefore, it is very important that the status of the ArmorStart device is monitored and appropriate Program commands, for the specific application, are issued before the `Xxxx.Cmd_OperToProgramPermissive` tag is set. This makes sure that a safe operator-to-program control transfer is executed.

ATTENTION

There is no logic within the AOI that controls the minimum or maximum ArmorStart Commanded Speed values sent to the specific drive.

It is important to understand the limitations of the motor connected to the specific drive and set the appropriate ArmorStart device parameters and add additional Program logic if necessary.

ATTENTION

If the ArmorStart device is started in Operator Mode and the FactoryTalk View ME ArmorStart Faceplate is closed while the ArmorStart device is running, the ArmorStart device will continue running at the current `Set_SpeedOper` tag value.

It is critical to understand how this operation affects the specific application and appropriate actions and safeguards are implemented.

Add-On Instruction Program Tag Listing and Function

This table provides the interface tag names and functions that are within the Add-On Instructions. You can read from and write to these tags from your specific application logic. This provides control and monitoring of your configured devices.

ArmorStart Command Tags

Tag Names	Function	Corresponding ArmorStart Device Tag
Cmd_JogFwdProg	Commands to Jog Forward	Out_ArmorStart_xxxJogFwd
Cmd_JogRevProg	Commands to Jog Reverse	Out_ArmorStart_xxxJogRev
Cmd_RunFwdProg	Commands to Run Forward	Out_ArmorStart_xxxRunFwd
Cmd_RunRevProg	Commands to Run Reverse	Out_ArmorStart_xxxRunRev
Cmd_ResetProg	Initiates device Clear Fault	Out_ArmorStart_xxxFaultReset
Cmd_OperProgReq	Initiates Operator Control	N/A
Cmd_ProgOperReq	Initiates Program Control	
Cmd_ProgProgReq	Initiates Program Control	
Cmd_ProgToOperPermissive	Allows Program to Operator Control Transfer	
Cmd_OperToProgPermissive	Allows Operator to Program Control Transfer	

ArmorStart Set Value Tag

Tag Names	Function	Corresponding ArmorStart DeviceTag
Set_SpeedProg	Sets Commanded Frequency	Out_ArmorStart_xxx.CommandedFreq

ArmorStart Status Tags

Tag Names	Function	Corresponding ArmorStart Device Tag
Sts_DriveStatus_AtReference	Provides Status of Corresponding ArmorStart device Tag	Inp_ArmorStart_xxx.AtReference
Sts_DriveStatus_Input0		Inp_ArmorStart_xxx.Input0
Sts_DriveStatus_Input1		Inp_ArmorStart_xxx.Input1
Sts_DriveStatus_Input2		Inp_ArmorStart_xxx.Input2
Sts_DriveStatus_Input3		Inp_ArmorStart_xxx.Input3
Sts_DriveStatus_Mon		Inp_ArmorStart_xxx._140Mon
Sts_DriveStatus_Ready		Inp_ArmorStart_xxx.Ready
Sts_DriveStatus_RunningFwd		Inp_ArmorStart_xxx.RunningFwd
Sts_DriveStatus_RunningRev		Inp_ArmorStart_xxx.RunningRev
Sts_DriveStatus_Tripped		Inp_ArmorStart_xxx.Tripped
Sts_DriveStatus_Warning		Inp_ArmorStart_xxx.Warning
Sts_OperatorModeEnabled	Indicates Operator Control is Active	N/A
Sts_ProgramModeEnabled	Indicates Program Control is Active	
Val_OutputFreq	Provides Status of Corresponding ArmorStart device Tag	Inp_ArmorStart_xxx.OutputFrequency


Common Application Logic Examples

You have the option to programmatically control the ArmorStart device via Logix software. Example rungs are shown in `AarmorStart_AOI_Example_Code.acd` included in the toolkit CD.

- `Device_xxx_RunForward_Command`
- `Device_xxx_RunReverse_Command`
- `Device_xxx_Reset_Command`

Follow these steps to add application logic to your routine.


1. Extract the `AarmorStart_AOI_Example_Code.acd` from the accelerator toolkit CD and save it.
2. Open RSLogix 5000 software.
3. From the File menu, choose Open.
4. Browse to the directory where the `AarmorStart_AOI_Example_Code.acd` file is located.




Rungs 15, 16, and 17 are programmatically commanded.

5. Select the rung you want to export and right-click the rung.

6. Choose Export Rungs.




7. Save the rung as .LSX.



8. Open your application logic file in RSLogix 5000 software.


9. Select the rung where you want to import the saved rung and right-click

10. Choose Import Rungs.




11. Select
Rung15_from_MainRoutine.L5x.

12. Click Import.



13. Click OK from the Import
Configuration dialog box.

The rung is copied into the desired
location.



14. Change the tag names to what you need.

15. Select a tag and right-click.

16. Click OK.

Add Alarm Logic for Alarm History Faceplate

TIP


This is an optional step and necessary only if you intend to use the Alarm History Faceplate. To skip this step, go to [Download the Project](#) on [page 111](#).

TIP

To incorporate Alarm History Faceplate into your application, the PanelView Plus terminal must support 800x600 window size.

The ME Alarm History Faceplate files let you quickly load and configure a pre-configured Alarm History display or faceplate for FactoryTalk View Machine Edition software. The Alarm History Faceplate works in conjunction with the individual ME_ArmorStart_Faceplates/AOIs, and provides an Alarm History of all of the device alarms and warnings that are configured to its alarm triggers. The Alarm History Faceplate files include pre-configured alarm triggers and messages for the ArmorStart devices.


In this example, an Alarm History Faceplate is displaying alarms and faults from ArmorStart devices (Motor 1 and Motor 2). The pre-configured alarm messages include an embedded string tag that is updated by the individual ArmorStart faceplate Add-On Instruction files when their specific alarms are triggered.



Follow these steps to add Alarm History logic to your routine.


1. Add the following rung to your program for each individual device Add-On Instruction.

The three tags pointed to were created already by your Add-On Instruction and exist in the tag database. You will need to edit the tag name prefixes to adjust for the name given to your Add-On Instruction. This example uses an Add-On Instruction named `Motor_With_284`.




2. Create the following controller scope tags (which will be used to pass data to the alarm summary in FT ME) for the different device trigger types.

- For the Move instruction, the destination tag must be created as one of the controller scoped tags.



- For the copy instruction, the source and destination tags must be created as a controller scoped tag, type STRING.

`Motor_With_284` is the device Add-On Instruction name used for the specific device in your program. The tag type must be STRING.



3. In the controller tag database, enter the names you need your devices to appear with in the Alarm History faceplate, into the source string tag you created in the COP instruction.
4. Add the following rung to clear your Alarm Trigger tag when a fault reset has been commanded.




The `ArmorStart Trigger` tag is being cleared by this rung. You will need to edit the tag name prefixes to adjust for the name given to your Add-On Instruction. This example uses `ArmorStart_With_284`.

Download the Project

1. If you have not already done so, move the keyswitch on your controller to Program.




2. Click the Controller Status icon and select Download.



3. Click Download.

The project downloads to the controller.



Notes:

FactoryTalk View Integration

In this chapter you add the pre-configured ArmorStart faceplates to your FactoryTalk View ME application file. This provides status, control, and diagnostics for each of your ArmorStart devices within your control system.

Before You Begin


- Complete your system hardware selection (refer to [Chapter 1](#)).
- Complete your system layout and wiring (refer to [Chapter 2](#)).
- Configure your ArmorStart device (refer to [Chapter 3](#)).
- Complete your Faceplate Logix Integration (refer to [Chapter 5](#)).

What You Need

- ArmorStart Accelerator Toolkit CD, publication [IASIMP-SP015](#).
- FactoryTalk View Studio software, version 5.00 or later.
- RSLinx Enterprise software, version 5.0 or later.
- FactoryTalk View Machine Edition User Manual Volume 1, publication [VIEWME-UM004](#).
- FactoryTalk View Machine Edition User Manual Volume 2, publication [VIEWME-UM005](#).

Follow These Steps

Complete the following steps to add the ArmorStart faceplates to your FactoryTalk View ME application.



Add ArmorStart Device Faceplates

TIP

If you are creating a new FactoryTalk View Studio application, refer to [FactoryTalk View Application Configuration](#), beginning on [page 175](#), before proceeding with this section.

The ME ArmorStart Faceplate files let you quickly load, configure, and use pre-configured status, control, and diagnostic displays or faceplates for the ArmorStart family of devices using FactoryTalk View Machine Edition.

This example shows a ArmorStart device object that may be added to your specific hardware system display. The object is a pre-configured Goto display button that can launch the on-top display or faceplate for the particular ArmorStart device it represents. The faceplate includes status, control, and diagnostic views controlled by its own toolbar buttons.

Goto Button Display Launching a ArmorStart Faceplate


Goto Display Button



Status and Control



Speed Trending




Diagnostic Info




Diagnostic Info



1. Open your existing FactoryTalk View ME application to which you want to add the ArmorStart faceplates.
2. Add the desired ArmorStart_xxx_Faceplate.gif to your display.
 - a. Right-click Displays and choose Add Component Into Application.




- b. Browse to the HMI Application Files folder on the toolkit CD and select the faceplate GFX file you want to use.
 - c. Click OK.



3. Add the faceplate parameter file for ME_ArmorStart_Parameter.par to your FactoryTalk ViewME application.


- a. Right-click Parameters, and choose Add Component Into Application.



- b. Browse to the HMI Application Files folder on the toolkit CD and select the ArmorStart_Parameter.xxx.par file.

- c. Click Open.

Typically you rename the parameter with a name that associates it with the intended ArmorStart device you wish to monitor and control.




4. Open the parameter that you just added and edit the parameter tagname to match your application.

The parameter tag name needs to include the RSLinx Enterprise device shortcut name of your systems controller and the module name of the intended ArmorStart device you wish to monitor and control.

- a. Double-click the faceplate parameter file and edit the Device Shortcut name to match the Logix controller that was previously configured in your RSLinx Enterprise Communication Setup.


In this example, the controller is the CLX-L63.



- b. Enter the desired Module/AOI Name of the intended ArmorStart device you want to monitor and control.

In this example, the module name is Motor_with_284. This name was configured in [step 5](#) on [page 118](#).

- c. Save your changes and close this parameter.




5. Repeat step 3 to add parameter files for additional ArmorStart devices you intend to monitor and control.
6. Create a unique parameter name and assign the associated Device Shortcut and Module Name to the parameter tagname.

7. Create the display navigation to open the ArmorStart Faceplate at runtime.


To use the pre-configured ArmorStart Goto buttons, refer to [Configuration Steps for Using Pre-configured Goto Buttons](#) on [page 120](#).

- On a desired graphic display, create a new transparent Goto display navigation button over the graphic object that represents the motor/drive you intend to monitor and control.
- Double-click the Goto button to configure its Display settings.

- Click the browse button  along side of the Display field and assign the ArmorStart faceplate display.
- Click  next to the Parameter file and assign the ArmorStart parameter file you created earlier for this intended device.
- Click OK.



- Repeat [step 7](#) for the Goto Display navigation buttons for each of your devices and skip to Set Initial Application Graphic on [page 123](#).




Configuration Steps for Using Pre-configured Goto Buttons

Follow these steps to add a Goto Display button with a graphic image representing the ArmorStart device, as shown.




1. Right-click the Image folder in the system tree and choose Add Component into Application.


The ArmorStart bitmap images are added to your FactoryTalk View application.



2. Choose HMI Application Files on the toolkit CD.
3. Select all the Bitmap images and click Open.




4. Right-click the Display folder in the system tree and choose Add Component Into Application.



5. Choose HMI Application Files on the toolkit CD and select the Goto_ArmorStart.gfx file.
6. Click Open.


7. Verify that the Goto_ArmorStart display appears under Displays in your system tree.
8. Create a new display or open your own system display where you want the Goto Buttons.
9. Open the Goto_ArmorStart displays and copy (or drag and drop) the desired graphic objects onto your system display.
10. Repeat the previous step until all the objects needed have been copied onto the display.
11. Open each module Goto Display button by double-clicking on the object.
Be sure to click near the top of the object to open the Goto Buttons properties and not the text object properties.




12. Click the General tab.

13. Assign the ArmorStart Faceplate and parameter file to create the associate with the Goto button.

- a. Click the browse button along side of the Display field and select the ArmorStart Faceplate display from the Component Browser dialog box.
- b. Click OK.



- c. Click the browse button along side of the Parameter file field and assign the ArmorStart parameter file.
- d. Click OK.
- e. Click OK on the Goto Display Button Properties dialog box to save your configuration.



14. Resize multiple objects.

Group all the objects by drawing a box around them with mouse to select all of the objects and then, from the Arrange menu, choose Group.

15. Once all desired ArmorStart objects have been copied into the application, you can delete the display from the application.


- a. In the system tree, right-click the Goto display under Displays and choose delete.
- b. Click Yes to the prompt to Remove file from the application and delete it from disk.

Set Initial Application Graphic

1. From the System folder, double-click Startup.



2. Check Initial Graphic.



3. Save and create a runtime file to test your display.

Add Equipment Status Faceplate

TIP

This section is optional and necessary only if you intend to use the Equipment Status Faceplate. To skip this section, go to [Add Alarm History Faceplate](#) on [page 133](#).

IMPORTANT


In order to use the Equipment Status faceplate into your application, you must have PanelView Plus terminal that supports 800x600 window size.

The ME Equipment Status Faceplate files let you quickly load and configure a summary display of preconfigured status and diagnostic displays or faceplates for FactoryTalk View Machine Edition. The Equipment Status Faceplate works in conjunction with individual device faceplates and provides a single summary display of all the faceplates that may be configured for an application. You can configure up to nine device faceplates to run with the Equipment Status faceplate and you can launch each device faceplate directly from it.

This example shows the Equipment Status Faceplate that you can add to your specific hardware system display. This faceplate is configured for three rows or three devices and provides overall status of the device, up to four additional status values to be monitored, and can launch the individual device faceplates for more detailed information.



You can launch these faceplates from the Goto buttons.

Example of Equipment Status Display Configured with Three Device Faceplates






Add the Equipment Status Faceplate Display

1. Right-click Displays and choose Add Component Into Application.
2. Browse to the HMI Application Files folder on the toolkit CD and select the Equipment_Status_Faceplate.gfx file.
3. Click Open.
4. Verify the Equipment_Status_Faceplate Display appears under Displays.



Add the ME_Equipment_Parameter File

1. Right-click Parameters and select Add Component Into Application.
2. Browse to the HMI Application Files folder on the toolkit CD and select the ME_Equipment_Parameter file.
3. Verify that the ME_Equipment_Parameter file appears under Parameters.



4. Open and configure the parameter file.

There is one parameter field that must be defined.

5. Save the file once changes are made.

```

#9=::[CLX-L63]My_E3_Plus_Motor_3      (This will represent the device monitored in row 9 of the Equipment Fa
**NOTE: YOU MUST CONFIGURE ALL 9 Parameter numbers representing each of the 9 rows, respectively
      for the Equipment Status Faceplate. If you are not planning on using 9 devices for the Equipment Status
      Faceplate, fill in the remaining parameters with the last device used, ie. In the example above, only
      4 devices      are configured for the Equipment Faceplate, therefore the remaining rows 5-9 is config
      same as the last device in row 4.
**NOTE: Configure parameter #1 with the name of the AOI that has the "Inp_NumRowsVis" configured
      in the AOI to represent the actual number of rows to appear on the Equipment Status Faceplate.
#1 in any expression of a graphic object would be replaced by the tag ::[CLX-L63]My_PowerFlex_Motor_1
#2 in any expression of a graphic object would be replaced by the tag ::[CLX-L63]My_PowerFlex_Motor_2
#3 in any expression of a graphic object would be replaced by the tag ::[CLX-L63]My_Kinetix_Axis_1
#4 in any expression of a graphic object would be replaced by the tag ::[CLX-L63]My_E3_Plus_Motor_3
etc.

Assign the "tagname" of the device AOI (Add On Instruction) you intend to monitor.
The "tagname" includes the "Device Shortcut" of your system's Logix Controller and the
"Module Name" of the device that was configured in your Logix application file.

For Example:
[CLX-63] represents the "Device Shortcut" name of Logix controller you configured in
RSLogix Enterprise Communication Setup that is connected to the intended device you want to monitor.

My_PowerFlex_Motor_1 represents the AOI name the device that was configured in your Logix application file.
=====

#1=::[CLX-L63]Motor_1
#2=::[CLX-L63]Motor_2
#3=::[CLX-L63]Motor_3
#4=::[CLX-L63]Motor_4
#5=::[CLX-L63]Motor_5
#6=::[CLX-L63]Motor_6
#7=::[CLX-L63]Motor_7
#8=::[CLX-L63]Motor_8
#9=::[CLX-L63]Motor_9

```

Each Parameter (1...9) corresponds to the device AOI tag name of each Equipment Status Faceplate row (1...9). You must assign the 1 parameter to a Pre-configured Device Faceplate AOI that includes the Inp_NumRowsVis assignment that was configured in [Chapter 5](#).

The remaining Parameters (2...9) must be assigned to valid Pre-configured Device Faceplate AOI tag names for the Equipment Status Faceplate to operate without errors, even if corresponding Equipment Status Faceplate Rows are not being used or assigned to non-preconfigured devices. We recommend you fill in the non-used parameters with the last valid AOI tag name.

In this example, we are only using one row, therefore, parameters #1...3 are assigned to the corresponding device AOI tags that we wish to display in rows #1...3. The remaining parameters #4...9 are assigned to the #3 row device AOI tag name Motor_With_281 as a placeholder for those faceplate objects in the non-visible rows #4...9.

```

**NOTE: YOU MUST CONFIGURE ALL 9 Parameter numbers representing each of the 9 rows, respectively
      for the Equipment Status Faceplate. If you are not planning on using 9 devices for the Equipment
      Faceplate, fill in the remaining parameters with the last device used, ie. In the example above, c
      4 devices      are configured for the Equipment Faceplate, therefore the remaining rows 5-9
      same as the last device in row 4.
**NOTE: Configure parameter #1 with the name of the AOI that has the "Inp_NumRowsVis" configured
      in the AOI to represent the actual number of rows to appear on the Equipment Status Faceplate.
#1 in any expression of a graphic object would be replaced by the tag ::[CLX-L63]My_PowerFlex_Motor_1
#2 in any expression of a graphic object would be replaced by the tag ::[CLX-L63]My_PowerFlex_Motor_2
#3 in any expression of a graphic object would be replaced by the tag ::[CLX-L63]My_Kinetix_Axis_1
#4 in any expression of a graphic object would be replaced by the tag ::[CLX-L63]My_E3_Plus_Motor_3
etc.

Assign the "tagname" of the device AOI (Add On Instruction) you intend to monitor.
The "tagname" includes the "Device Shortcut" of your system's Logix Controller and the
"Module Name" of the device that was configured in your Logix application file.

For Example:
[CLX-63] represents the "Device Shortcut" name of Logix controller you configured in
RSLogix Enterprise Communication Setup that is connected to the intended device you want to monitor.


My_PowerFlex_Motor_1 represents the AOI name the device that was configured in your Logix application
=====

#1=::[CLX-L63]Motor_With_281
#2=::[CLX-L63]Motor_With_280
#3=::[CLX-L63]Motor_With_281
#4=::[CLX-L63]Motor_With_281
#5=::[CLX-L63]Motor_With_281
#6=::[CLX-L63]Motor_With_281
#7=::[CLX-L63]Motor_With_281
#8=::[CLX-L63]Motor_With_281
#9=::[CLX-L63]Motor_With_281

```


Configure the Goto buttons on the Equipment Status Faceplate

1. Open the Equipment Faceplate display.
2. Right-click the display and choose Object Explorer.




The Object Explorer dialog box opens.


3. For each row to be displayed on the Equipment Faceplate, find the GotoDisplayButton object for that row and double-click to open its properties.



4. Set the Display to the corresponding device's faceplate, to be launched from that row's GotoDisplayButton object.




5. Set the Parameter file to the corresponding device faceplate Parameter file to be displayed for that row.
6. Repeat steps 1...5 for all Goto Display Buttons that you will use to launch corresponding device faceplates.



Configure Additional Device Value Columns


Not all device faceplates used with the Equipment Status Faceplate are configured to display four value fields. If unused value fields are needed then additional logic will need to be added to the existing device AOI to move the additional AOI tag values to the corresponding Sts_Valuexx tags.

In this example, pre-configured logic within the ArmorStart Faceplate AOI is used to write values to Values 1 and 2. Simply add additional MOV instructions to move other values to Values 3 and 4 if desired.



Create a Goto Display Button to Launch the Equipment Faceplate

1. Add a Goto Display button on one of your existing ME displays.
2. Double-click the button to open its Properties.
3. Under Display Settings, set the Display to Equipment_Status_Faceplate and the Parameter file to ME_Equipment_Parameter.



4. Save and test your application by creating a runtime application.

TIP

To add devices that do not have pre-configured faceplates and add views to the Equipment Status Faceplate, refer [Add Equipment Status Faceplate](#) beginning on [page 124](#).

Add Alarm History Faceplate

TIP

This is an optional step and necessary only if intend to use the Alarm History Faceplate. To skip this step, go to [Test the Project](#) on [page 139](#).


IMPORTANT

In order to use the Alarm History faceplate into your application, you must have PanelView Plus terminal that supports 800x600 window size.


The ME Alarm History Faceplate files let you quickly load and configure a pre-configured Alarm History display or faceplate for FactoryTalk View Machine Edition software. The Alarm History Faceplate works in conjunction with the individual ME_ArmorStart_Faceplates, ME_PowerFlex_Faceplates/AOIs, ME_Kinetix_Faceplates/AOIs, and ME_E3 Plus_Faceplates/AOIs, and provides an Alarm History of all of the device alarms and warnings that are configured to its alarm triggers. The Alarm History Faceplate files include pre-configured alarm triggers and messages for the ArmorStart devices, Kinetix Motion Axis, and E3 Plus Overload Relay family of devices.

In this example, an Alarm History Faceplate is displaying alarms/faults from ArmorStart devices (Motor 1 and Motor 2). The pre-configured alarm messages include an embedded string tag that is updated by the individual ArmorStart faceplate AOI files when their specific alarms are triggered.




Example of Alarm History Status Faceplate



Add the Alarm_History_Faceplate.gfx to your application.





1. Right-click Displays and choose Add Component Into Application.
2. Browse to HMI Application Files folder and select Alarm_History.gfx.
3. Verify the Alarm_History Display appears under Displays.



4. Import the Alarm Setup.


- a. Select Alarm Setup under the Alarms folder.
- b. Right-click Alarm Setup and choose Import and Export.
- c. Click Import alarm configuration into application.
- d. Click Next.




IMPORTANT

When importing the alarm configuration, your existing alarm configuration is lost. When prompted to back up your existing alarm configuration, you can choose to save it as an XML file.

- e. Click Yes or No and click Next.




- f. Browse to the HMI Application Files folder to import the Alarms xml file to your project.
- g. Click Open.
- h. Click Finish.




5. Open the Alarm Setup that you imported.

6. Observe the Trigger tags that were pre-configured.



7. Click the Messages tab.

8. Observe that the pre-configured alarm messages have been configured for the ArmorStart controller.




IMPORTANT

Upon startup, FactoryTalk View software will give application error warnings that unused Trigger tags have not been activated. When this happens, clear the errors.

9. Configure the Alarm Trigger tags in the FactoryTalk View tag database.

- a. Under the system tree, double-click Tags to open the tag database.


For each ArmorStart that you are using, you need to create two FactoryTalk View memory tags for each.



- b. Create the FactoryTalk View device tags.

- xxxAlarmTrigger – Analog tag (set max to 200 for each) where xxx is replaced with ArmorStart.
- xxxAlarmName – String tag where xxx is replaced with ArmorStart.
- Assign each FactoryTalk View tag to the appropriate controller tag you configured in the RSLogix 5000 application.

Example of an ArmorStartAlarmTrigger tag assigned to a tag named ArmorStartAlarmTrigger in the controller identified by the Device Shortcut L63.




A Summary of all possible FactoryTalk View tags that may need to be created. Only the tags for the devices actually used in Alarm History faceplate need to be created.

	Tag Name	Type	Description
1	ArmorStartAlarmName	String	
2	ArmorStartAlarmTrigger	Analog	
3			



10. Add additional Alarm Trigger tags and Alarm Messages for Devices without Pre-configured Device Faceplates to your Alarm History display.

- Open the Alarm Setup.
- Click Add.

A Trigger tag is added.



- Using the Tag browser, select the tag in your controller you will want to use to trigger an alarm message.
- Click OK.
- Click the Message tab.




- f. Scroll to the bottom of the listing to add your Trigger Tag, the trigger value, and the message you want displayed.

110	E3AlarmTrigger	20	/*S:0 E3AlarmName*/ Overload Warnin
111	{[L43]Furnace Alarm trigger		
112	<Unassigned>		


- g. To insert a String into the message, right click in the message choose Edit String, then enter the text.
- h. To insert a variable, click Insert Variable, then choose Numeric, String, or Time/Date.

A String, Numeric or Time/Date will be added to your message.



11. Configure a Goto Display button to launch the Alarm History Faceplate.

- a. Create a Goto Display button on the display from which you want to launch the Alarm History faceplate.
- b. Double-click to open its Properties.
- c. Click the browse button  along side of the Display field and choose Alarm History.
- d. Click OK.



Test the Project

FactoryTalk View Studio software lets you create and test individual displays or the entire project, so that you can navigate and test all the functionality before downloading your project to a terminal.

IMPORTANT

To test run the project, all communication must be configured first.

Follow these steps to test your FactoryTalk View Studio project.


1. From the Application menu, choose Test Application.



2. If prompted to save changes, click Yes.



The FactoryTalk View Studio software compiles the project and runs it as if it were executing on the desired terminal.



3. Test the functionality of the project and fix errors as necessary.

Disregard the following errors and warnings. The Datalog feature is looking for the logging path to Storage Card2 on the PanelView Plus terminal.




4. Press Close [F3] to close this dialog box.
5. Press x on the keyboard to end testing and shut down the application.

Download the Project to a Terminal


Follow these steps to download your FactoryTalk View Studio project.

1. From the Application menu, choose Create Runtime Application.




The Create Runtime Application dialog box opens.

2. Select Runtime x.x Application (*.mer) based on terminal firmware version for the Save as type field.
3. Enter a File name for the application.
ArmorStart.mer is used in this example.
4. Click Save.




5. Click the File Transfer Utility button from the tool bar.




The Transfer Utility dialog box opens.

6. Click the browse button  to search for the runtime file.



7. Select ArmorStart.mer.
8. Select your PanelView Plus terminal.
9. Click Download.

The file is transferred to the PanelView Plus terminal.



The following dialog box appears.

10. Click OK.
11. Click Exit.
12. Click Close from the file menu.

The application closes.




Run the Project on a Terminal

Follow these steps to run your project on the PanelView Plus terminal.

1. Apply power to the PanelView Plus terminal.
2. Connect your motion system communication network cable to your PanelView Plus terminal and personal computer.

The FactoryTalk View ME Station window opens.

3. Press Load Application [F1].




The Load Application window opens.

4. Scroll through the list of application files by using the up/down arrows and select the .mer file you intend to run.

ArmorStart.mer is used in this example.


5. Press Load [F2].



The Replace Communications window appears.


6. Press Yes [F7].

If you press No [F8], the communication settings from the project run previously will be used instead.



The FactoryTalk View ME Station window appears.

7. Verify that the ArmorStart.mer file appears in the current application field.
8. Press Run Application [F2].
9. Verify the functionality of the application.
10. Refer to [Chapter 7](#) for a basic understanding of how to run and operate the FactoryTalk View application.



Notes:

ArmorStart System Application Guide

This chapter guides you through a pre-configured FactoryTalk View ME application. The application interfaces with a pre-configured Logix program that controls the ArmorStart devices. This chapter helps you to navigate around the faceplates and provides an understanding of the status, control, and diagnostic features.

Before You Begin

- Configure your ArmorStart controller (refer to [Chapter 3](#)).
- Complete your Faceplate Logix integration (refer to [Chapter 5](#)).
- Complete your FactoryTalk View integration (refer to [Chapter 6](#)).

What You Need

- ArmorStart Accelerator Toolkit CD, publication. For a copy of the CD, contact your local Rockwell Automation distributor or sales representative.
- Hardware installation and wiring complete with power applied.
- Logix application file downloaded to the ControlLogix or CompactLogix controller. Controller set to run.
- FactoryTalk View ME runtime application file downloaded to the PanelView Plus terminal. Run Application activated on terminal.

AarmorStart System Overview Display

The AarmorStart System Overview display serves as a system map to identify which devices are located in which parts of the system. You can modify the FactoryTalk View ME pre-configured Goto Display buttons to fit your particular device application by using the GFX files provided on the toolkit CD. They can then be placed in appropriate locations.

In this example, there are six Goto Display buttons configured. There is one Goto Display button for each of the three motors, the Configuration Display, the Equipment Status Display, and the Alarm History Display. Pressing any of the Goto Display buttons launches the associated display.



ArmorStart Device Faceplate Overview

Pressing any of the Goto display buttons opens the corresponding faceplate screen. In this example the ArmorStart 284D device faceplate screen is shown.



Faceplate Function Buttons


Function Button	Icons	Description
Alarm		The Alarm button indicates a device fault condition and activates fault diagnostic views. A grey bell indicates normal status, with no faults. A red flashing bell indicates a fault condition.
Configuration		The Configuration button lets you edit the ArmorStart faceplate name or name of the device.
Trending		The Trending button shows you the speed trend.
Help		The Help button provides information for the existing view.
Close		Click the Close button to close the faceplate.
Program/Operator	Operator Program	The Program/Operator command button executes a switch between program control and operator control of the ArmorStart device. The button indicator text shows what has control.
Numeric Display		Click the Numeric Display button to access numeric entry keypad.

The overview faceplate places the logic program in control by default. For you to take control, press the Program/Operator button. The text on the button changes to Operator and the ArmorStart command buttons are enabled.

RunFwd, RunRev, JogFwd, JogRev, and Stop command buttons let the operator perform the normal ArmorStart functions as the names suggest. You can also enter a speed reference for operator control by pressing the numeric display.

ArmorStart Device Faceplate - Fault Indication View

The Alarm button indicates a ArmorStart device fault condition and activates the fault diagnostic views.



Fault Indication View

Toolbar Button	Color Indicator	Description	Action
Alarm	Grey	Normal state	None
	Flashing red	Fault	Follow fault action screen

To access the detailed fault information and action displays, press the alarm button on the toolbar.

Last Fault, Fault Description, and Fault Action

1. Press the Alarm button on the toolbar.

The Last Fault view is displayed. The specific error being reported by the module is indicated.

2. Press the Help button on the toolbar to access the detailed fault description view.



3. Press the black arrow key at the bottom of the view to access Fault Action information and for further diagnostic help.



This diagnostic information is triggered by the reported module error code. The input and output error code information provided is in accordance with the fault descriptions found in the ArmorStart user manual, publication [280-UM002](#).

4. Press the black arrow key again to return to the Last Fault view.




AarmorStart Device Faceplate - Configuration Status View

You can use the Configuration button to edit the faceplate name or device descriptions.

1. Press the Configuration button on the toolbar.

The Configuration button becomes highlighted.



2. Press the Device Name, or Speed Units field you need to modify.



A popup keyboard opens.

3. Type the desired text.
4. Press Enter.



ArmorStart Device Faceplate - Trending View


1. Click the Trending toolbar button to access the trending faceplate view.

The trending views let you monitor the speed value over time.



2. Press the speed trend navigation buttons to scroll through the saved value over a selected period of time.
3. Click the trend configuration toolbar button to access the minimum and maximum speed trend settings.


The trend scale configuration screen opens.



4. Press the value fields to modify.


A popup keyboard opens for value entry.

5. Press Enter when the entry is complete.



ArmorStart Device Faceplate - Online Help Options


Press Help on any view to access the online help information.



Equipment Status Display Overview

The ME Equipment Status Faceplate files let you quickly load and configure a summary display of preconfigured status and diagnostic displays or faceplates for FactoryTalk View Machine Edition software. The Equipment Status Faceplate works in conjunction with individual device faceplates and provides a single summary display of all the faceplates that may be configured for an application. You can configure up to nine device faceplates to run with the Equipment Status faceplate and you can launch each Device faceplate directly from it.

This example shows the ArmorStart devices added to the Equipment Status display. You can click the device button to open the associated device faceplate.




Alarm History Display Overview

The ME Alarm History Faceplate files let you quickly load and configure a pre-configured Alarm History display or faceplate for FactoryTalk View Machine Edition software. The Alarm History Faceplate works in conjunction with the individual ME_ArmorStart_Faceplates, ME_PowerFlex_Faceplates/AOIs, ME_Kinetix_Faceplates/AOIs, ME_PowerFlex_Faceplates/AOIs, and ME_E3 Plus_Faceplates/AOIs, and provides an Alarm History of all of the device alarms and warnings that are configured to its alarm triggers. The Alarm History Faceplate files include pre-configured alarm triggers and messages for the ArmorStart devices, Kinetix Motion Axis, and E3 Plus Overload Relay family of devices.

In this example, an Alarm History Faceplate is displaying alarms/faults from ArmorStart 284D. The pre-configured alarm messages include an embedded string tag that is updated by the individual ArmorStart faceplate AOI files when their specific alarms are triggered.

Refer to the FactoryTalk View Machine Edition User's Guide, publication [VIEWME-UM004](#), for alarm history button operation and configuration.



Notes:

Logix Communication and Controller Configuration


In this appendix you configure your personal computer and controller communication, configure your controller, and create a new project by using RSLogix 5000 software.

Configuring PC Communication


This section provides information on how to set and verify your IP address.

Set the IP Address


1. On your desktop, right-click My Network Places and choose Properties.




2. Double-click Local Area Connection.
3. From the General tab, Choose Properties.
Verify Internet Protocol (TCP/IP) is checked and selected.



4. Click Properties.



5. Click Use the following IP address.
6. Enter the IP address and Subnet mask as shown or enter your address.
7. Click OK.
8. Close all network windows.




Verify Your IP Address

1. From the Start menu, choose Run.

The Run dialog box opens.

2. From the Open pull-down menu, choose cmd.
3. Click OK.




The Windows IP Configuration dialog box opens.

4. Enter ipconfig at the prompt.
5. Press Enter.
6. Verify that the IP address and Subnet Mask match what you entered.



If these numbers do not match what you entered, contact your network administrator.

7. Close the cmd.exe window.




Configure the EtherNet/IP Driver


1. Click the RSLinx icon in the system tool tray to start the RSLinx Classic software.
2. From the Communications menu, choose Configure drivers.



3. Select EtherNet/IP Driver from the pull-down menu and click Add New.




4. Click OK to accept the default name.




5. Click Browse Local Subnet.
6. Highlight the IP address you just selected. Click Apply, then click OK.

The EtherNet/IP driver is added to the Configured drivers list.



7. Verify that the status of the driver is Running.
8. Click Close.




Load the Controller Firmware Serially

This procedure describes how to load firmware in the controller by using a serial connection.

1. Apply input power to the ControlLogix controller power supply.
2. Launch the ControlFlash software from the RSLogix 5000 tools menu.
3. Click Next.



4. Select your controller catalog number.
- In this example, 1756-L63 is controller catalog number. The steps to download other Logix controller firmware is similar.



6. Under AB_DF1-1, select the 1756-L63 controller.
7. Click OK.

8. Move the controller keyswitch to PROG.



9. Compare the current firmware revision to the latest revision listed.


If the current revision matches the newest revision listed, then your controller has the latest firmware and an update is not needed.

- a. Click cancel.

The firmware upgrade is cancelled.


- b. Go to Assign IP Addresses on [page 160](#).

- c. If the current revision does not match the latest revision listed, click Next.



If you are unsure of which revision to use, select the latest version.

10. Click Finish.



11. Click Start.

The firmware update begins.

When the controller is updated, the status dialog box displays update complete.

12. Click OK.

13. Click Cancel.

14. Click Yes.


The ControlFlash software closes.

Assign IP Addresses

Using BOOTP/DHCP


The BOOTP/DHCP Server utility is used to assign IP addresses to most devices in this quick start, except the PanelView Plus terminal. The BOOTP/DHCP utility is installed during the RSLogix 5000 software installation.

1. Launch the BOOTP/DHCP Server utility.




If you are running this utility for the first time, the Network Setup Error dialog box opens.

- a. Click OK.
- b. Enter the subnet mask from [step 6](#) on [page 155](#).




If you are not running this utility for the first time, from the Tools menu, choose Network Settings.



2. Click OK.

The Request History field displays all devices in your network that need IP addresses.

The EtherNet/IP (MAC) addresses correspond to the pre-loaded addresses and typically are marked on the device labels.




- Double-click a request from one of the devices.

- Enter a unique IP address for each device.

- Click OK.

If you are not on an isolated network, obtain the IP addresses from your network administrator.

- Repeat steps [3...5](#) for each device, except for the PanelView Plus terminal.

**IMPORTANT**

If you cycle power, the device will not retain its IP address unless you disable BOOTP/DHCP.


- Select the first device in the Relation List field.

- Click Disable BOOTP/DHCP.

- Repeat steps [7...8](#) for all devices except for the PanelView Plus terminal.



- Close the BOOTP/DHCP utility.

If prompted to save changes, click No.



Using DHCP

1. Open RSLinx Classic software.
2. From the Communications menu, choose RSWho.
3. Open the tree and select the 1756-ENBT/A module or your specific module.
4. Right-click the Ethernet module.
5. Click Module Configuration.




6. Select Dynamic and use DHCP to obtain the network configuration.

If Use DHCP to obtain network configuration is grayed out, you may need to use ControlFlash software to upgrade the latest firmware in the Ethernet module. Refer to [Ethernet Module Firmware Update Using ControlFLASH Utility](#) on [page 163](#) to get the latest updates.

7. Click Apply.
8. Click OK.


You can now exit RSLinx Classic software.




Ethernet Module Firmware Update Using ControlFLASH Utility

Follow these steps to update firmware in the Ethernet module by using the ControlFLASH utility.

1. Make sure the network is connected.
2. Select the ControlFLASH utility from the Tools menu or launch from Programs in your PC Start menu.






3. Click Next.




4. Select the module you would like to update and click Next.




RSLinx software starts.

5. Click OK.


**ATTENTION**

Be sure that the update you are about to make is the correct one for your device. If it is not, unpredictable system operation may result.


6. In the left pane, navigate to the Ethernet module you want to upgrade and click OK.




7. Highlight the revision you want to upgrade to and click Next.




8. Click Finish.



9. Click Yes to update.




10. When the update is complete, verify that the module resets and the front-panel status indicator displays the correct revision and click OK.




The screen in [step 4](#) will reappear.

11. Click Cancel.



12. Click Yes if there are no more modules to upgrade.




Browse the EtherNet/IP Network Devices

Follow these steps to verify that all of your network devices are present in RSLinx Classic software.

1. Click  to view the EtherNet/IP driver and devices on the network.
2. Verify that all of your network devices are detected.


In this example, there are five network devices. The network configuration for your specific application will be different.



Load the Controller Firmware

This procedure describes how to load firmware in the controller from RSLogix 5000 software by using an Ethernet connection.


1. Apply input power to the ControlLogix controller and have the Ethernet cable connected to the Ethernet card.
2. From the Communications menu, choose Who Active.




3. Select the logix controller if different than the previous path.

The Update Firmware button will illuminate.

4. Click Update Firmware.




5. Verify firmware revision and click Update.




Create a New Project File in RSLogix 5000 Software

1. Launch RSLogix 5000 software.



2. Click New Project.

The New Controller dialog box opens.




3. From the Type pull-down menu, choose the controller.
4. From the Revision pull-down menu, choose the software revision.

In this example, the CompactLogix 1768-L63 is the controller Type. The steps to configure other Logix controller types are similar.

5. Enter a unique controller Name.

If you are using a ControlLogix controller, you will also need to choose the Chassis Type and Slot number.

6. Click OK.




Configure Your Ethernet Module

1. Expand I/O Configuration in the system tree.

This example features the CompactLogix 1768-ENBT ethernet module. The steps to configure other Logix ethernet modules are similar.


For instructions on configuring other ethernet modules, refer to the Start Pages within RSLogix 5000 software.




2. Right-click 1756 Backplane and choose New Module.

3. Expand Communications and select 1768-ENBT/A or another 1756 Ethernet module.

4. Click OK.



5. From the Major Revision pull-down menu, choose the latest revision and click OK.



6. Enter a Name for the module.
7. Enter the IP Address of your Logix controller network module.

Refer to [Browse the EtherNet/IP Network Devices](#) on [page 168](#) for the IP address.
8. From the Electronic Keying pull-down menu, choose Disable Keying.

If you are using a ControlLogix controller, you will also need to choose the module revision.
9. Clear Open Module Properties.
10. Click OK.

New Module

Type: 1756-ENBT/A 1756 10/100 Mbps Ethernet Bridge, Twisted-Pair Media Change Type...

Vendor: Allen-Bradley

Parent: Local

Name: EtherNet_Bridge

Description:

Slot: 1

Revision: 4

Address / Host Name

☒ IP Address: 192 . 168 . 1 . 107

☐ Host Name:

Electronic Keying: **Disable Keying**

☒ Open Module Properties OK Cancel Help

FactoryTalk View Application Configuration


In this appendix you will create a new FactoryTalk View application and configure communication.

Create New FactoryTalk View Application

1. Launch FactoryTalk View software.



2. Click the New tab.
3. Enter the application name.
4. From the Language pull-down menu, choose English (United States), en-US.
5. Click Create.
6. Click Cancel when prompted to Add Process Faceplates.




Create Design (local) and Runtime (target) Shortcuts

FactoryTalk View Studio software lets you configure independent communication methods for application Design (local) and for Runtime (target) deployment. This functionality lets you test applications on the development machine before it is deployed on a terminal. This saves a significant amount of time testing and developing the application.


In this example, we use RSLinx Enterprise software with an L63 CompactLogix controller.

Follow these steps to create a New RSLinx Enterprise Configuration.

1. Expand RSLinx Enterprise and double-click Communication Setup.



2. Click Create a new configuration.
3. Click Finish.




Configure Design (local) Communication


The local tab in Communication Setup reflects the view of the topology from the RSLinx Enterprise server on the development computer. For this example, the development computer is communicating with the L63 ControlLogix controller via Ethernet network.

Follow these steps to setup the Design Time path.

1. Expand Ethernet, Ethernet.
2. Expand the Ethernet bridge assigned to you.
3. Expand CompactLogix System.
4. Select 0, 1756-L63.




5. Click Add.
A new device shortcut appears.



6. Name the shortcut CLX-L63.
7. Select the L63 shortcut and the controller.

8. Click Apply.

A verification dialog box appears showing that the shortcut was assigned to the design path.



9. Close the verification dialog box.


The Apply button is dimmed indicating the shortcut is attached to the path.

Configure Runtime (Target) Communication


The target tab displays the offline configuration from the perspective of the device that will be running the application and comprises the topology that will be loaded into a PanelView Plus or PanelView Plus CE terminal.

Follow these steps to copy the configuration from Design time to Runtime.

1. Click Copy from Design to Runtime.




2. Click Yes.



3. Click Verify to make sure communication is setup correctly.

The Shortcut Verifier dialog box appears.

4. Verify that the path to the Design device and the Runtime device are assigned.



5. Click Close.
6. Click OK.

ArmorStart Configuration Using 193-DNCT Device

In this chapter you will learn how to configure your ArmorStart device by using the 193-DNCT hand-held device. Some of the things that you can use the 193-DNCT device for include:

- commissioning the ArmorStart distributed motor controller.
- configuring the device parameters.
- programming the motor controller.
- monitoring other devices on a DeviceNet network.
- uploading, storing, and downloading complete device configurations for DeviceNet devices via the network.
- displaying DeviceNet physical layer diagnostics and network bandwidth statistics.

Refer to Bulletin 193 DeviceNet Configuration Terminal User Manual, publication [193-UM009](#), for more information.

Before You Begin


- Complete your system hardware selection (refer to [Chapter 1](#)).
- Complete your system layout and wiring (refer to [Chapter 2](#)).
- Configure your DeviceNet Scanner and ArmorStart devices (refer to [Chapter 3](#)).

What You Need

- 193-DNCT device.
- ArmorStart Accelerator Toolkit CD, publication [IASIMP-SP015](#).
- The manual for how to use the 193-DNCT hand-held device.

Follow These Steps

Complete the following steps to configure your ArmorStart device by using the 193-DNCT hand-held device.




Connect to the ArmorStart Controller

Follow this procedure to connect the 193-DNCT terminal to the ArmorStart controller.

1. Mount the 1485P-P1R5-MN5R1 mini-mini-micro tee port to the DeviceNet connection on one of the ArmorStart controllers in your application.

It does not matter which ArmorStart controller you connect to on the network.

If necessary, remove the DeviceNet cable from the ArmorStart device if the cable is already connected to the unit. The selection of the ArmorStart device in the network does not matter as the node address is not dictated by its physical location.



2. Reconnect the DeviceNet cable that was removed from the network to the mini connector on the 1485P-P1R5-MN5R1 mini-mini-micro tee port.
3. Attach the DeviceNet male micro-connector end of the 193-CM1 cable to the 1485P-P1R5-MN5R1 mini-mini-micro tee port.

4. Attach the other end (plug connection) of the 193-CM1 cable to the 193-DNCT device.

The 193-CM1 cable can be connected to other female micro-connectors on the network, not just the 1485P-P1R5-MN5R1 mini-mini-micro tee port.


193-DNCT Device



Applying Power to the 193-DNCT Terminal

The DeviceNet configuration terminal (catalog number 193-DNCT) is shipped so that when it is placed on the network for the first time, it will automatically set its baud rate to that of the traffic on the network, and then assign itself an unused network address. When power is applied, the following screen is displayed. The 193-DNCT obtains its power from the DeviceNet network in this example.

Initial Screen



There is a 10 second power-up delay programmed at the factory. The above screen will appear for at least 10 seconds on initial powerup. The power-up delay can be modified in the Terminal Setup screen described in the following section. Once the communication rate is determined and a network address has been set, the terminal will display the Network Who screen, which displays a list of all devices on the network.

IMPORTANT

If the terminal fails to enter the Network Who screen after approximately 20 seconds, it is because it could not determine the network baud rate due to lack of traffic on the network. Pressing the ESC key will allow you to enter the Terminal Setup screen so that a fixed baud rate and network address can be set for the terminal.

To go directly to the Terminal Setup screen, press and hold the ESC key while applying power.

Hand-held Terminal Keys

The table provides descriptions of the hand-held terminal keypad.

Key	Description
	Escape Key. Exit a menu or cancel a change.
	Select key. Select a value, digit, or screen choice.
	Increment key. Scroll through options, increase a value, or toggle a bit.
	Decrement key. Scroll through options, decrease a value, or toggle a bit.
	Enter key. Enter a menu, enter a mode, or enter a value.
 	Scroll left or right keys. Scroll left or right through a value.
	Shift key. Small values (yellow text) on top of keys are entered when pressed after the shift key.
 ... 	Used to enter numbers.
	Used to enter a decimal place for a number.
	Used to negate a numeric value. Used to add a sign character when editing a value.
   	Programmable function keys.
	Programmable Reset key.


The following table describes the alternate functionality of each key when it is pressed after the Shift key.

Alternate Functionality

Key Sequence	Description
	The letter A. Used to enter values in hexadecimal.
	The letter B. Used to enter values in hexadecimal.
	The letter C. Used to enter values in hexadecimal.
	The letter D. Used to enter values in hexadecimal.
	The letter E. Used to enter values in hexadecimal.
	The letter F. Used to enter values in hexadecimal.
	Copy function. Used to copy Class, Instance, and/or Attribute data to the clipboard. Available on screens displaying a small 'C' in the upper right corner.
	Exponential function. Used to enter values in exponential notation.
	Paste function. Used to paste Class, Instance, and/or Attribute data from the clipboard. Available on screens displaying a small 'P' in the upper right corner.
	Help function. Invoke help information for the current screen.

Browse through the Network to Select Your ArmorStart Controller

The terminal searches for all devices on the network and reports the devices it has found on the Network Who display.



- Press  or  to scroll through devices until you find the ArmorStart controller you need.
- Press .

The following Device Choices menu appears.



Button	Description
Version	Displays Version information for the selected device.
Params	Provides access to configuration and status parameters for the selected device. Allows the operator to search for parameters that are not at factory defaults.
Copy Cat	Upload and store complete device configurations, including DeviceLogix programs to the programming terminal's memory. Download stored device configurations from the programming terminal memory to the selected device.
Tools	Provides access to Node Commissioning functions, the Class Instance Attribute editor, and the real time graphing function.
Advanced	Provides access to the DeviceLogix editor, DeviceNet IO message timing information, ZIP configuration, and local input and output status display.
Scanner	If the selected device is a DeviceNet scanner, provides access to simple scanner configuration values and access to the scan list.

Select and Monitor Parameters

The parameter menu allows the operator to select, monitor, and change parameters.

Select a Parameter

To select a parameter follow these steps.

1. From the Device Choices menu, press  to go to .
2. Press .
3. Go to  and press .


You can also narrow down the amount of parameters by using the Groups Key under .

4. Use the numeric keypad to enter your parameter number, or use the up  and down  to scroll to the desired parameter.

Monitor a Parameter

To monitor a parameter, select the desired parameter by completing steps [1...4](#) in [Select a Parameter](#).

The parameter screen displays all information for a single parameter. Parameter values are continuously updated.



Note: If the parameter is a monitor parameter, the HIM stores the HI and LO values for the parameter during monitoring. The HI/LO: values are displayed on the same line as the Min, Max, Def and Help string.

Change Parameters

The parameter screens have slightly different formats for each parameter data type. The three different parameter screen types are bit enumerated Boolean, numeric, and value enumerated.

Change a Bit Numeric Parameter


To change a bit numeric parameter follow these steps.

1. Select the desired parameter by completing steps [1...4](#) in [Select a Parameter](#).

2. Press .

The following display appears.


Parameter Number



3. Press .

4. Press   until you reach the designated bit.

The description of the bit is listed below the highlighted bit.



Bit Description

5. Use the numeric keypad to enter 1 to enable the bit or 0 to disable the bit.

You can also use the up  and down  to change the status of the bit.

6. Press .

Change a Numeric Parameter


To change a numeric parameter, follow these steps.

1. Select the desired parameter by completing steps [1...4](#) in [Select a Parameter](#).

2. Press  in the given parameter.



3. Use the up  and down  or numeric keys to change the value.




4. Press  to accept the value.

This will highlight the parameter number again.

Change an Enumerated Parameter

To change an enumerated parameter value, follow these steps.

1. Select the desired parameter by completing steps [1...4](#) in [Select a Parameter](#).



2. Press up  and down  to change to the appropriate value.
3. To edit any remaining parameters repeat steps [1...4](#) in [Select a Parameter](#) and use the appropriate method for the data type to change them.
4. When finished, push  until you go back to the Who Screen or you may choose to move to a parameter to monitor the status.

Rockwell Automation Support

Rockwell Automation provides technical information on the Web to assist you in using its products.

At <http://www.rockwellautomation.com/support/>, you can find technical manuals, a knowledge base of FAQs, technical and application notes, sample code and links to software service packs, and a MySupport feature that you can customize to make the best use of these tools.

For an additional level of technical phone support for installation, configuration, and troubleshooting, we offer TechConnect support programs. For more information, contact your local distributor or Rockwell Automation representative, or visit <http://www.rockwellautomation.com/support/>.

Installation Assistance

If you experience a problem within the first 24 hours of installation, review the information that is contained in this manual. You can contact Customer Support for initial help in getting your product up and running.

United States or Canada	1.440.646.3434
Outside United States or Canada	Use the Worldwide Locator at http://www.rockwellautomation.com/support/americas/phone_en.html , or contact your local Rockwell Automation representative.

New Product Satisfaction Return

Rockwell Automation tests all of its products to ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning and needs to be returned, follow these procedures.

United States	Contact your distributor. You must provide a Customer Support case number (call the phone number above to obtain one) to your distributor to complete the return process.
Outside United States	Please contact your local Rockwell Automation representative for the return procedure.

Documentation Feedback

Your comments will help us serve your documentation needs better. If you have any suggestions on how to improve this document, complete this form, publication [RA-DU002](#), available at <http://www.rockwellautomation.com/literature/>.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat:6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication IASIMP-QS015C-EN-P - August 2011

Supersedes Publication IASIMP-QS015B-EN-P - March 2010

Copyright © 2011 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.