



Service and Repair Manual

Serial Number Range

Z[®]-45 XC
Z[®]-45 HF

from Z4525XCF-101
from Z4525XCM-101

This manual includes:
Repair procedures
Fault Codes
Electrical and
Hydraulic Schematics

For detailed maintenance
procedures, refer to the
appropriate Maintenance
Manual for your machine.

Part No. 1268197GT
Rev E
November 2020

Introduction

Important

Read, understand and obey the safety rules and operating instructions in the appropriate Operator's Manual on your machine before attempting any procedure.

This manual provides troubleshooting and repair procedures for qualified service professionals.

Basic mechanical, hydraulic and electrical skills are required to perform most procedures. However, several procedures require specialized skills, tools, lifting equipment and a suitable workshop. In these instances, we strongly recommend that maintenance and repair be performed at an authorized Genie dealer service center.

Compliance

Machine Classification

Group B/Type 3 as defined by ISO 16368

Machine Design Life

Unrestricted with proper operation, inspection and scheduled maintenance.

Technical Publications

Genie has endeavored to deliver the highest degree of accuracy possible. However, continuous improvement of our products is a Genie policy. Therefore, product specifications are subject to change without notice.

Readers are encouraged to notify Genie of errors and send in suggestions for improvement. All communications will be carefully considered for future printings of this and all other manuals.

Contact Us:

Internet: www.genielift.com

E-mail: awp.techpub@terex.com

Find a Manual for this Model

Go to <http://www.genielift.com>

Use the links to locate Service Manuals, Maintenance Manuals, Service and Repair Manuals, Parts Manuals and Operator's Manuals.

Copyright © 2017 by Terex Corporation

1268197GT Rev E, November 2020

First Edition, Fifth Printing

Genie and "Z" are registered trademarks of Terex South Dakota, Inc. in the U.S.A. and many other countries.

"XC" is a trademark of Terex South Dakota, Inc.

Introduction

Revision History

| Revision | Date | Section | Procedure / Page / Description |
|--|---------|----------------|---|
| A | 5/2017 | | Initial Release |
| A1 | 8/2017 | Fault Codes | Control System Fault Codes |
| | | Specifications | Hydraulic Component Specifications |
| | | Repair | Function Manifold Components |
| | | Schematics | Hydraulic Schematic, |
| A2 | 9/2017 | Repair | Procedure 2-3, 2-4 |
| | | Fault Codes | Introduction, Control System and Platform Overload Fault Codes |
| | | Schematics | Hour Meter Pin Legend |
| B | 9/2017 | Schematics | Add wiring diagrams |
| B1 | 11/2017 | Specifications | Machine Specifications |
| B2 | 6/2018 | Schematics | GCON Terminal Strip Wiring Diagram |
| C | 1/2019 | Specifications | Added ANSI / CSA engines |
| | | Schematics | Added ANSI / CSA Schematics |
| D | 10/2019 | Specifications | Machine Specifications |
| | | Repair | Procedure 2-3 |
| E | 11/2020 | All Sections | Add Deutz TD 2.2 L3 engine |
| | | | |
| Reference Examples: | | | Electronic Version Click on any content or procedure in the Table of Contents to view the update. |
| Section – Repair Procedure, 4-2 | | | |
| Section – Fault Codes, All charts | | | |
| Section – Schematics, Legends and schematics | | | |

Safety Rules



Danger

Failure to obey the instructions and safety rules in this manual and the appropriate Operator's Manual on your machine will result in death or serious injury.

Many of the hazards identified in the operator's manual are also safety hazards when maintenance and repair procedures are performed.

Do Not Perform Maintenance Unless:

- ☒ You are trained and qualified to perform maintenance on this machine.
- ☒ You read, understand and obey:
 - manufacturer's instructions and safety rules
 - employer's safety rules and worksite regulations
 - applicable governmental regulations
- ☒ You have the appropriate tools, lifting equipment and a suitable workshop.

Safety Rules

Personal Safety

Any person working on or around a machine must be aware of all known safety hazards. Personal safety and the continued safe operation of the machine should be your top priority.



Read each procedure thoroughly. This manual and the decals on the machine, use signal words to identify the following:



Safety alert symbol—used to alert personnel to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



Indicates a imminently hazardous situation which, if not avoided, will result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, may cause minor or moderate injury.



Indicates a potentially hazardous situation which, if not avoided, may result in property damage.



Be sure to wear protective eye wear and other protective clothing if the situation warrants it.



Be aware of potential crushing hazards such as moving parts, free swinging or unsecured components when lifting or placing loads. Always wear approved steel-toed shoes.

Workplace Safety

Any person working on or around a machine must be aware of all known safety hazards. Personal safety and the continued safe operation of the machine should be your top priority.



Be sure to keep sparks, flames and lighted tobacco away from flammable and combustible materials like battery gases and engine fuels. Always have an approved fire extinguisher within easy reach.



Be sure that all tools and working areas are properly maintained and ready for use. Keep work surfaces clean and free of debris that could get into machine components and cause damage.



Be sure any forklift, overhead crane or other lifting or supporting device is fully capable of supporting and stabilizing the weight to be lifted. Use only chains or straps that are in good condition and of ample capacity.



Be sure that fasteners intended for one time use (i.e., cotter pins and self-locking nuts) are not reused. These components may fail if they are used a second time.



Be sure to properly dispose of old oil or other fluids. Use an approved container. Please be environmentally safe.



Be sure that your workshop or work area is properly ventilated and well lit.

Table of Contents

| | | |
|---------------------|--|-----------|
| Introduction | Introduction | ii |
| | Important Information | ii |
| | Find a Manual for this Model..... | ii |
| | Revision History | iii |
| Section 1 | Safety Rules..... | iv |
| | General Safety Rules | iv |
| Section 2 | Specifications | 1 |
| | Machine Specifications | 1 |
| | Performance Specifications | 2 |
| | Hydraulic Oil Specifications | 2 |
| | Hydraulic Component Specifications | 5 |
| | Deutz D 2.9 L4 Engine Specifications | 7 |
| | Deutz TD 2.2 L3 Engine Specifications | 8 |
| | Deutz D2011 L03i Engine Specifications..... | 9 |
| | Perkins 404D-22 Engine Specifications..... | 10 |
| | Perkins 404F-E22T Engine Specifications | 11 |
| | Ford MSG-425 EFI Engine Specifications | 12 |
| | Machine Torque Specifications | 13 |
| | Hydraulic Hose and Fitting Torque Specifications | 13 |
| | Torque Procedure | 15 |

Table of Contents

| | | |
|------------------|--|-----------|
| Section 3 | Repair Procedures | 17 |
| | Introduction..... | 17 |
| | Platform Controls | 19 |
| | 1-1 ALC-500 Circuit Board | 19 |
| | 1-2 Joysticks..... | 20 |
| | How to Adjust the Joystick Max-out Setting..... | 20 |
| | How to Adjust the Joystick Ramp Rate Setting | 21 |
| | How to Adjust the Joystick Threshold Setting..... | 23 |
| | Platform Components..... | 24 |
| | 2-1 Platform Leveling Slave Cylinder | 24 |
| | How to Bleed the Slave Cylinder | 25 |
| | 2-2 Platform Rotator | 25 |
| | 2-3 Platform Overload System | 26 |
| | How to Replace the Platform Overload Load Cell | 29 |
| | 2-4 Platform Overload Recovery Fault..... | 29 |
| | Jib Boom Components | 30 |
| | 3-1 Jib Boom | 30 |
| | 3-2 Jib Boom Lift Cylinder | 31 |
| | Primary Boom Components..... | 33 |
| | 4-1 Cable Track..... | 33 |
| | How to Remove the Cable Track | 33 |
| | How to Repair the Primary Boom Cable Track | 35 |
| | 4-2 Primary Boom | 35 |
| | How to Disassemble the Primary Boom | 37 |
| | 4-3 Primary Boom Lift Cylinder | 38 |
| | 4-4 Primary Boom Extension Cylinder | 39 |
| | 4-5 Platform Leveling Master Cylinder | 40 |
| | Secondary Boom Components..... | 41 |
| | 5-1 Secondary Boom..... | 42 |
| | 5-2 Secondary Boom Lift Cylinders..... | 46 |

Table of Contents

| | |
|--|-----------|
| Engines | 47 |
| 6-1 RPM Adjustment - Deutz D2011L03i Models | 47 |
| 6-2 RPM Adjustment - Perkins 404D-22 Models | 47 |
| 6-3 Flex Plate | 47 |
| How to Install the Flex Plate | 49 |
| How to install the Pump and Bell Housing Assembly | 50 |
| 5-4 Engine Fault Codes | 51 |
| 6-7 Diesel Particle Filter Regeneration - Deutz TD 2.2 L3 | 52 |
| Hydraulic Pumps..... | 53 |
| 7-1 Lift/Steer Pump | 53 |
| 7-2 Drive Pump | 54 |
| How to Prime the Pump | 55 |
| Manifolds | 56 |
| 8-1 Function Manifold Components - CE (to Z4525XCM-1500)..... | 56 |
| 8-1.1 Function Manifold Components - ANSI / CSA / CE (from Z4525XCF-101, Z4525XCM-1501) | 59 |
| 8-2 Valve Adjustments - Function Manifold | 64 |
| How to Adjust the System Relief Valve | 64 |
| How to Adjust the Secondary Boom Down Relief Valve | 64 |
| 8-3 Jib Boom / Platform Rotate Manifold Components..... | 65 |
| 8-4 Turntable Rotation Manifold Components | 66 |
| 8-5 Directional Valve Manifold Components..... | 67 |
| How to Set Up the Directional Valve Linkage | 68 |
| 8-6 Traction Manifold Components, 4WD | 70 |
| 8-7 Valve Adjustments, 4WD Traction Manifold | 72 |
| 8-8 Hydraulic Generator Manifold Components, 2.2kW | 73 |
| 8-8.1 Generator Manifold Components | 74 |
| 8-9 Valve Coils | 75 |
| How to Test a Coil Diode | 75 |
| Turntable Rotation Components | 77 |
| 9-1 Turntable Rotation Assembly..... | 77 |
| Axle Components..... | 78 |
| 10-1 Oscillating Axle Cylinders | 78 |

Table of Contents

| | | |
|------------------|---|------------|
| Section 4 | Fault Codes | 79 |
| | Introduction | 79 |
| | Control System Fault Codes | 80 |
| | How to Retrieve Control System Fault Codes | 80 |
| | Control System Fault Codes | 81 |
| | How to Retrieve Platform Overload System Fault Codes - Deutz D2011L03i, Perkins 404D-22 and Ford MSG-425 Models | 84 |
| | Platform Overload System Fault Codes | 85 |
| | Fault Code Display - Deutz and Perkins Models | 87 |
| | How to Retrieve Active Engine Fault Codes - Deutz D 2.9 L4 and Perkins 404F-E22T Models | 87 |
| | How to Retrieve Active Engine Fault Codes - Deutz TD 2.2 L3 Models | 88 |
| | Fault Code Display - Flashing and Solid LED's - Deutz D 2.9 L4 and Perkins 404F-E22T Models | 89 |
| | Soft Key Functions and Icons - Deutz D 2.9 L4 and Perkins 404F-E22T Models | 90 |
| | Soft Key Functions and Icons - Deutz TD 2.2 L3 Models | 91 |
| | Main Menu Structure - Deutz D 2.9 L4 Models | 92 |
| | Main Menu Structure - Deutz TD 2.2 L3 Models | 93 |
| | Main Menu Structure - Perkins 404F-E22T Models | 94 |
| | Deutz TD 2.2 L3 Engine Fault Codes | 95 |
| | Deutz D 2.9 L4 Engine Fault Codes | 105 |
| | Perkins 404F-E22T Engine Fault Codes | 116 |
| | Ford MSG-425 Engine Fault Codes | 118 |
| | How to Retrieve Ford MSG-425 Engine Fault Codes | 118 |

Table of Contents

| | | |
|------------------|---|------------|
| Section 5 | Schematics | 123 |
| | Introduction | 123 |
| | Electrical Symbol Legend | 124 |
| | Hydraulic Symbols Legend | 125 |
| | Limit Switch Location Legend | 126 |
| | Electrical Component and Wire Color Legends | 127 |
| | Hour Meter Legend | 130 |
| | Electrical Schematics | 131 |
| | Electrical Schematic, Ford MSG425 | 132 |
| | Electrical Schematic, Deutz D2011L03i and Perkins 404D-22 | 133 |
| | Electrical Schematic, Deutz D 2.9 L4 | 136 |
| | Engine Wire Harness, Deutz D 2.9 L4 | 137 |
| | Electrical Schematic, Deutz TD 2.2 L3 | 140 |
| | Engine Wire Harness, Deutz TD 2.2 L3 - Page 1 | 141 |
| | Engine Wire Harness, Deutz TD 2.2 L3 - Page 2 | 143 |
| | Electrical Schematic, Perkins 404F-22T | 146 |
| | Perkins 404F-E22T Engine Wire Harness | 147 |
| | Electrical Schematic, Function Controls - ANSI / CSA | 150 |
| | Electrical Schematic, Function Controls - CE | 151 |
| | Electrical Schematic, Platform Overload | 154 |
| | Electrical Schematic, Options Wiring Diagram | 155 |

Table of Contents

| | |
|--|------------|
| Ground Control Box Switch Panel Wiring Diagram, Deutz D2011L03i and Perkins 404D-22 - ANSI / CSA..... | 158 |
| Ground Control Box Terminal Strip Wiring Diagram, Deutz D2011L03i and Perkins 404D-22 - ANSI / CSA..... | 159 |
| Ground Control Box Switch Panel Wiring Diagram, Deutz D 2.9 L4 and Perkins 404F-E22T - ANSI / CSA | 162 |
| Ground Control Box Terminal Strip Wiring Diagram, Deutz D 2.9 L4 and Perkins 404F-E22T - ANSI / CSA | 163 |
| Ground Control Box Switch Panel Wiring Diagram, Ford MSG425 - ANSI / CSA | 166 |
| Ground Control Box Terminal Strip Wiring Diagram, Ford MSG425 - ANSI / CSA | 167 |
| Ground Control Box Switch Panel Wiring Diagram - CE | 170 |
| Ground Control Box Terminal Strip Wiring Diagram - CE | 171 |
| Platform Control Box Switch Panel Wiring Diagram | 174 |
| Platform Control Box Terminal Strip Wiring Diagram..... | 175 |
| Platform Control Box Relay Wiring Diagram - ANSI / CSA | 178 |
| Platform Control Box Relay Wiring Diagram- CE..... | 179 |
| Hydraulic Schematics | 181 |
| Hydraulic Schematic - CE (to Z4525XCM-1500) | 182 |
| Hydraulic Schematic - ANSI / CSA / CE (from Z4525XCF-101, Z4525XCM-1501) | 183 |

This page intentionally left blank.



Specifications

Machine Specifications

| Tires and wheels | rough terrain |
|--|------------------------|
| Tire size | 315/55 D20 |
| Tire ply rating | 12 |
| Tire weight, new foam filled (minimum) | 290 lbs 131,5 kg |
| Overall tire diameter | 32.5 in 82,5 cm |
| Wheel diameter | 20 in 50,8 cm |
| Wheel width | 11 in 27,9 cm |
| | high flotation |
| Tire size | 33/16LL 500 |
| Tire ply rating | 10 |
| Tire weight | 145 lbs 66 kg |
| Overall tire diameter | 33 in 88,8 cm |
| Wheel diameter | 19.5 in 49,5 |
| Wheel width | 14 in 35,5 |
| Tire pressure | 38 psi 2,62 bar |
| Wheel lugs | 9 @ 5/8 -18 |
| Lug nut torque, lubricated | 94 ft-lbs 127,4 Nm |
| Lug nut torque, dry | 125 ft-lbs 169,5 Nm |

Fuel capacities

| | |
|-----------------------------------|----------------------------|
| LPG tank | 33.5 pounds 15,2 kg |
| Fuel tank | 17 gallons 64,4 liters |
| Hydraulic tank | 22 gallons 83 liters |
| Hydraulic system (including tank) | 30 gallons 113,6 liters |
| Drive hubs | 24 fl oz 710 cc |
| Turntable rotation drive hub | 25.5 fl oz 750 cc |

Drive hub oil type: SAE 90 multipurpose hypoid gear oil
API service classification GL5

For operational specifications, refer to the Operator's Manual.

Specifications

Performance Specifications

| | |
|---|--|
| Drive speed, maximum | |
| Stowed position | 4.5 mph 7,2 km/h 40 ft / 6.1 sec 12,2 m / 6,1 sec |
| Raised or extended | 0.33 mph 0,5 km/h 40 ft / 90 sec 12,2 m / 90 sec |
| Gradeability | See Operator's Manual |
| Braking distance, maximum | |
| High range on paved surface | 3 to 6 ft 0,9 to 1,8 m |
| Joystick function speeds, maximum from platform controls | |
| Primary boom up | 26 to 30 seconds |
| Primary boom down | 26 to 30 seconds |
| Primary boom extend | 14 to 18 seconds |
| Primary boom retract | 14 to 18 seconds |
| Secondary boom up | 26 to 30 seconds |
| Secondary boom down | 26 to 30 seconds |
| Turntable rotate, 355° | 67 to 73 seconds |
| For operational specifications, refer to the Operator's Manual. | |

Hydraulic Oil Specifications

Hydraulic Fluid Specifications

Genie specifications require hydraulic oils which are designed to give maximum protection to hydraulic systems, have the ability to perform over a wide temperature range, and the viscosity index should exceed 140. They should provide excellent antiwear, oxidation prevention, corrosion inhibition, seal conditioning, and foam and aeration suppression properties.

| | |
|----------------------------|-----------|
| Cleanliness level, minimum | ISO 15/13 |
| Water content, maximum | 250 ppm |

Recommended Hydraulic Fluid

| | |
|--------------------|--------------------------|
| Hydraulic oil type | Chevron Rando HD Premium |
| Viscosity grade | 32 |
| Viscosity index | 200 |

Optional Hydraulic Fluids

| | |
|----------------|---|
| Mineral based | Shell Tellus S2 V 32 Shell Tellus S2 V 46 Shell Tellus S4 VX 32 Shell Donax TG (Dexron III) Chevron 5606A |
| Biodegradable | Petro Canada Environ MV 46 |
| Fire resistant | UCON Hydrolube HP-5046 |

Note: Genie specifications require additional equipment and special installation instructions for the approved optional fluids. Consult Genie Product Support before use.

NOTICE

Optional fluids may not have the same hydraulic lifespan and may result in component damage.

Note: Extended machine operation can cause the hydraulic fluid temperature to increase beyond its maximum allowable range. If the hydraulic fluid temperature consistently exceeds 200°F / 90°C an optional oil cooler may be required.


Specifications

NOTICE

Do not top off with incompatible hydraulic fluids. Hydraulic fluids may be incompatible due to the differences in base additive chemistry. When incompatible fluids are mixed, insoluble materials may form and deposit in the hydraulic system, plugging hydraulic lines, filters, control valves and may result in component damage.

Note: Do not operate the machine when the ambient air temperature is consistently above 120°F / 49°C.

Hydraulic Fluid Temperature Range



Ambient air temperature

- 1 Chevron hydraulic oil 5606A
- 2 Petro-Canada Environ MV 46
- 3 UCON Hydrolube HP-5046D
- 4 Chevron Rando HD premium oil MV

Chevron Rando HD Premium Oil MV Fluid Properties

| | |
|--|---------------|
| ISO Grade | 32 |
| Viscosity index | 200 |
| Kinematic Viscosity | |
| cSt @ 200°F / 100°C | 7.5 |
| cSt @ 104°F / 40°C | 33.5 |
| Brookfield Viscosity | |
| cP @ -4°F / -20°C | 1040 |
| cP @ -22°F / -30°C | 3310 |
| Flash point | 375°F / 190°C |
| Pour point | -58°F / -50°C |
| Maximum continuous operating temperature | 171°F / 77°C |

Note: A hydraulic oil heating system is recommended when the ambient temperature is consistently below 0°F / -18°C.

Note: Do not operate the machine when the ambient temperature is below -20°F / -29°C with Rando HD Premium MV.

Specifications

Chevron 5606A Hydraulic Oil Fluid Properties

| | |
|--|---------------|
| ISO Grade | 15 |
| Viscosity index | 300 |
| Kinematic Viscosity | |
| cSt @ 200°F / 100°C | 5.5 |
| cSt @ 104°F / 40°C | 15.0 |
| cSt @ -40°F / -40°C | 510 |
| Flash point | 180°F / 82°C |
| Pour point | -81°F / -63°C |
| Maximum continuous operating temperature | 124°F / 51°C |

Note: Use of Chevron 5606A hydraulic fluid, or equivalent, is required when ambient temperatures are consistently below 0°F / -17°C unless an oil heating system is used.

NOTICE

Continued use of Chevron 5606A hydraulic fluid, or equivalent, when ambient temperatures are consistently above 32°F / 0°C may result in component damage

Petro-Canada Environ MV 46 Fluid Properties

| | |
|--|---------------|
| ISO Grade | 46 |
| Viscosity index | 154 |
| Kinematic Viscosity | |
| cSt @ 200°F / 100°C | 8.0 |
| cSt @ 104°F / 40°C | 44.4 |
| Flash point | 482°F / 250°C |
| Pour point | -49°F / -45°C |
| Maximum continuous operating temperature | 180°F / 82°C |

Shell Tellus S4 VX Fluid Properties

| | |
|--|---------------|
| ISO Grade | 32 |
| Viscosity index | 300 |
| Kinematic Viscosity | |
| cSt @ 200°F / 100°C | 9 |
| cSt @ 104°F / 40°C | 33.8 |
| Brookfield Viscosity | |
| cSt @ -4°F / -20°C | 481 |
| cSt @ -13°F / -25°C | 702.4 |
| cSt @ -40°F / -40°C | 2624 |
| Flash point | >100 |
| Pour point | -76°F / -60°C |
| Maximum continuous operating temperature | 103°F / 75°C |

Specifications

UCON Hydrolube HP-5046 Fluid Properties

| | |
|--|---------------|
| ISO Grade | 46 |
| Viscosity index | 192 |
| Kinematic Viscosity | |
| cSt @ 149°F / 65°C | 22 |
| cSt @ 104°F / 40°C | 46 |
| cSt @ 0°F / -18°C | 1300 |
| Flash point | None |
| Pour point | -81°F / -63°C |
| Maximum continuous operating temperature | 189°F / 87°C |

Hydraulic Component Specifications

Drive Pump

Type: bi-directional variable displacement piston pump

| | |
|--------------------------------|---------------------|
| Flow rate @ 2500 psi / 172 bar | 32 gpm 121 L/min |
|--------------------------------|---------------------|

| | |
|-------------------------|---------------------|
| Drive pressure, maximum | 3500 psi 241 bar |
|-------------------------|---------------------|

Charge Pump

| | |
|------|------|
| Type | gear |
|------|------|

| | |
|-----------------------------|------------------------|
| Displacement per revolution | 0.84 cu in 13,76 cc |
|-----------------------------|------------------------|

| | |
|--------------------------------|-----------------------|
| Flow rate @ 2500 psi / 172 bar | 9.1 gpm 34,4 L/min |
|--------------------------------|-----------------------|

| | |
|----------------------------|---------------------|
| Charge pressure @ 2500 rpm | 315 psi 21,7 bar |
|----------------------------|---------------------|

Function Pump

| | |
|------|------|
| Type | gear |
|------|------|

| | |
|-----------------------------|---------------------|
| Displacement per revolution | 0.67 cu in 11 cc |
|-----------------------------|---------------------|

| | |
|--------------------------------|------------------------|
| Flow rate @ 2500 psi / 172 bar | 7.25 gpm 27,4 L/min |
|--------------------------------|------------------------|

Auxiliary Pump

| | |
|------|--------------------------|
| Type | gear, fixed displacement |
|------|--------------------------|

| | |
|-----------------------------|-----------------------|
| Displacement per revolution | 0.067 cu in 1,1 cc |
|-----------------------------|-----------------------|

| | |
|--------------------------------|-----------------------|
| Auxiliary pump relief pressure | 3200 psi 220,6 bar |
|--------------------------------|-----------------------|

Specifications

Function manifold

| | |
|---|-----------------------|
| System relief valve pressure, maximum | 3200 psi 220,6 bar |
| Secondary boom down relief valve pressure | 2100 psi 145 bar |
| Platform level relief valve pressure | 3000 psi 207 bar |
| Steer flow regulator | 2.0 gpm 7,6 L/min |
| Boom extend flow regulator | 2 gpm 7,6 L/min |
| Jib boom / platform rotate flow regulator | 0.8 gpm 3 L/min |

Traction Manifold

| | |
|-------------------------|---------------------|
| Hot oil relief pressure | 250 psi 17,2 bar |
|-------------------------|---------------------|

Steer end drive motors

| | |
|--------------------------------------|-------------------------------------|
| Displacement per revolution variable | 0.54 to 1.53 cu in 8,77 to 25 cc |
|--------------------------------------|-------------------------------------|

Non-steer end drive motors

| | |
|--|---------------------------------------|
| Displacement per revolution variable (2 speed motor) | 0.54 to 1.53 cu in 8,85 to 25,1 cc |
|--|---------------------------------------|

Hydraulic Filters

| | |
|--|--|
| High pressure filter: | Beta 3 ^ 200 |
| High pressure filter bypass pressure | 102 psi 7 bar |
| Medium pressure filter | Beta 3 ^ 200 |
| Medium pressure filter bypass pressure | 51 psi 3,5 bar |
| Hydraulic tank return filter | 10 micron with 25 psi / 1,7 bar bypass |

Manifold Component Specifications

Plug torque

| | |
|------------|-------------------|
| SAE No. 2 | 36 in-lbs / 4 Nm |
| SAE No. 4 | 10 ft-lbs / 13 Nm |
| SAE No. 6 | 14 ft-lbs / 19 Nm |
| SAE No. 8 | 38 ft-lbs / 51 Nm |
| SAE No. 10 | 41 ft-lbs / 55 Nm |
| SAE No. 12 | 56 ft-lbs / 76 Nm |

Specifications

Deutz D2.9 L4 Engine

| | |
|---|-------------------------------------|
| Displacement | 177 cu in 2,9 liters |
| Number of cylinders | 4 |
| Bore and Stroke | 3.6 x 4.3 inches 92 x 110 mm |
| Horsepower | 48.8 @ 2600 rpm 37 kW @ 2600 rpm |
| Firing order | 1 - 3 - 4 - 2 |
| Low idle | 1500 rpm 313 Hz |
| High idle | 2500 rpm 521,7 Hz |
| Compression ratio | 18.4:1 |
| Compression pressure | 362 to 435 psi 25 to 30 bar |
| Governor | electronic |
| Lubrication system | |
| Oil pressure (@ 2000 rpm) | 40 to 60 psi 1,4 to 3 bar |
| Oil capacity (including filter) | 9.4 quarts 9 liters |
| Oil viscosity requirements | Low ash oil required |
| -22° F to 86° F / -30° C to 30° C | 5W-30 (synthetic) |
| -4° F to 90° F / -20° C to 32° C | 10W-40 |
| Above 23° F / -5° C | 20W-50 |
| Unit ships with 15W-40. Extreme operating temperatures may require the use of alternative engine oils. For oil requirements, refer to the Engine Operator Manual for your engine. | |
| Oil temperature switch | |
| Temperature switch point | 257°F 125°C |
| Oil Pressure switch | |
| Oil pressure switch point | 20 psi 1,4 bar |

Engine coolant

| | |
|----------|-------------------------|
| Capacity | 10 quarts 9,4 liters |
|----------|-------------------------|

Fuel injection system

| | |
|----------------------------------|-----------------------|
| Injection pump make | Bosch |
| Injection pump pressure, maximum | 15000 psi 1034 bar |
| Injector opening pressure | 3046 psi 210 bar |

Fuel requirement

For fuel requirements, refer to the engine Operator Manual for your engine.

Starter motor

| | |
|---------------------------|--------------|
| Cranking speed | 150-250 RPM |
| Current draw, normal load | 250A to 400A |
| Output | 3.2kW |

Battery

| | |
|-----------------------------|-------------|
| Type | 12V DC |
| Quantity | 1 |
| Cold cranking ampere | 1000A |
| Reserve capacity @ 25A rate | 200 minutes |

| | |
|--------------------------|--------------|
| Alternator output | 95A @ 14V DC |
|--------------------------|--------------|

| | |
|----------------------------|-------------------------------|
| Fan belt deflection | 3/8 to 1/2 inch 9 to 12 mm |
|----------------------------|-------------------------------|

Specifications

Deutz TD 2.2 L3 Engine

| | |
|---|---------------------------------|
| Displacement | 134 cu. in 2,2 liters |
| Number of cylinders | 3 |
| Bore and Stroke | 3.6 x 4.3 inches 92 x 110 mm |
| Horsepower net intermittent @ 2600 rpm | 49 hp 36 kW |
| Induction system | turbocharged |
| Firing order | 1 - 2 - 3 |
| Low idle, standby | 1000 rpm |
| Low idle, function enable | 1500 rpm |
| High idle | 2400 rpm |
| Governor | electronic |
| Lubrication system | Low ash oil required |
| Oil pressure, hot (@ 2000 rpm) | 40 to 60 psi 2,8 to 4,1 bar |
| Oil capacity (including filter) | 8 quarts 7,6 liters |
| Oil viscosity requirements | |
| -22°F to 86°F / -30°C to 30°C | 5W-30 (synthetic) |
| -4°F to 104°F / -20°C to 40°C | 10W-40 |
| Above 5°F / -15°C | 15W-40 |
| Unit ships with 15W-40. Extreme operating temperatures may require the use of alternative engine oils. For oil requirements, refer to the Engine Operator Manual for your engine. | |

Oil temperature switch

| | |
|--------------------------|-----------------------------|
| Installation torque | 8 - 18 ft-lbs 11 - 24 Nm |
| Temperature switch point | 257°F 125°C |

Oil Pressure switch

| | |
|-----------------------|-----------------------------|
| Installation torque | 8 - 18 ft-lbs 11 - 24 Nm |
| Pressure switch point | 17.4 psi 1,2 bar |

Fuel requirement

For fuel requirements, refer to the engine Operator Manual for your engine.

| | |
|--------------------------------|---------------------------|
| Engine coolant capacity | 2.2 gallons 8,3 liters |
|--------------------------------|---------------------------|

Unit ships with Ethylene Glycol engine coolant. Consult your local supplier for compatibility before mixing alternative engine coolants.

Starter motor

| | |
|---------------------------|---------------|
| Current draw, normal load | 140 - 200A |
| Cranking speed | 250 - 350 rpm |

Battery – Engine starting and control system

| | |
|-----------------------------|------------------|
| Type | 12V DC, Group 31 |
| Quantity | 1 |
| Battery capacity, maximum | 1000A |
| Reserve capacity @ 25A rate | 200 Minutes |
| Alternator output | 95A @ 14V DC |

Specifications

Deutz D2011 L03i Engine

| | |
|------------------------------------|-----------------------------------|
| Displacement | 142 cu in 2,33 liters |
| Number of cylinders | 3 |
| Bore and Stroke | 3.7 x 4.4 inches 94 x 112 mm |
| Horsepower | 48 @ 2800 rpm 36 kW @ 2800 rpm |
| Firing order | 1 - 2 - 3 |
| Low idle | 1500 rpm 313 Hz |
| High idle | 2500 rpm 521,7 Hz |
| Compression ratio | 19:01 |
| Compression pressure | 362 to 435 psi 25 to 30 bar |
| Governor | centrifugal mechanical |
| Valve clearance, cold | |
| Intake | 0.012 in 0.3 mm |
| Exhaust | 0.020 in 0,5 mm |
| Lubrication system | |
| Oil pressure | 20 to 44 psi 1,4 to 3 bar |
| Oil capacity (including filter) | 9.5 quarts 9 liters |
| Oil viscosity requirements | |
| -22° F to 86° F / -30° C to 30° C | 5W-30 (synthetic) |
| -4° F to 90° F / -20° C to 32° C | 10W-40 |
| Above 23° F / -5° C | 20W-50 |

Unit ships with 15W-40. Extreme operating temperatures may require the use of alternative engine oils. For oil requirements, refer to the Engine Operator Manual for your engine.

Oil temperature switch

| | |
|--------------------------|----------------|
| Temperature switch point | 300°F 149°C |
|--------------------------|----------------|

Oil Pressure switch

| | |
|---------------------------|-------------------|
| Oil pressure switch point | 22 psi 1,5 bar |
|---------------------------|-------------------|

Fuel injection system

| | |
|----------------------------------|-----------------------|
| Injection pump make | Bosch |
| Injection pump pressure, maximum | 15000 psi 1034 bar |
| Injector opening pressure | 3046 psi 210 bar |

Fuel requirement

For fuel requirements, refer to the engine Operator Manual for your engine.

Starter motor

| | |
|-----------------------|--------------------|
| Current draw, no load | 90A |
| Brush length, new | 0.72 in 18,5 mm |
| Brush length, minimum | 0.27 in 7 mm |

Battery

| | |
|-----------------------------|---------------------|
| Type | 12V DC, Group 34/78 |
| Quantity | 1 |
| Cold cranking ampere | 900A |
| Reserve capacity @ 25A rate | 200 minutes |

Alternator output 60A @ 14V DC

| | |
|----------------------------|-------------------------------|
| Fan belt deflection | 3/8 to 1/2 inch 9 to 12 mm |
|----------------------------|-------------------------------|

Specifications

Perkins 404D-22 Engine

| | |
|--|-----------------------------------|
| Displacement | 134 cu in 2,2 liters |
| Number of cylinders | 4 |
| Bore and Stroke | 3.31 x 3.94 inches 84 x 100 mm |
| Horsepower | 51 @ 2500 rpm 38 kW @ 2500 rpm |
| Firing order | 1 - 3 - 4 - 2 |
| Low idle | 1300 rpm 229,7 Hz |
| High idle | 2500 rpm 441,7 Hz |
| Compression ratio | 23.3:1 |
| Compression pressure | 426 psi 29,4 bar |
| Pressure (psi) of lowest cylinder must be within 50 psi / 3.45 bar of highest cylinder | |
| Governor | centrifugal mechanical |
| Valve clearance, cold | |
| Intake | 0.008 in 0,2 mm |
| Exhaust | 0.008 in 0,2 mm |
| Lubrication system | |
| Oil pressure, cold (at 2500 rpm) | 60 psi 4,1 bar |
| Oil capacity (including filter) | 9.3 quarts 8,8 liters |
| Oil viscosity requirements | |
| Below 86°F / 30°C | 5W-20 |
| -4°F to 104°F / -20°C to 40°C | 10W-30 |
| Above 14°F / -10°C | 15W-40 |

Unit ships with 15W-40. Extreme operating temperatures may require the use of alternative engine oils. For oil requirements, refer to the Engine Operator Manual for your engine.

| | |
|---|--------------------------|
| Oil pressure sending unit | |
| Oil pressure switch point | 14.2 psi 1 bar |
| Fuel injection system | |
| Injection pump make | Zexel |
| Injection pressure | 2133 psi 147 bar |
| Fuel requirement | |
| For fuel requirements, refer to the engine Operator Manual for your engine. | |
| Alternator output | 55A @ 12V DC |
| Fan belt deflection | 3/8 in 10 mm |
| Starter motor | |
| Current draw, no load | 140-200A |
| Brush length, new | 0.7480 in 19 mm |
| Brush length, minimum | 0.5 in 12,7 mm |
| Battery | |
| Type | 12V DC, Group 34/78 |
| Quantity | 1 |
| Cold cranking ampere | 900A |
| Reserve capacity @ 25A rate | 200 minutes |
| Engine coolant | |
| Capacity | 7.7 quarts 7,3 liters |
| Coolant temperature switch | |
| Temperature switch point | 221° F 105° C |

Specifications

Perkins 404F-E22T Engine

| | |
|---|--|
| Displacement | 134 cu in 2,2 liters |
| Number of cylinders | 4 |
| Bore and Stroke | 3.31 x 3.94 inches 84 x 100 mm |
| Horsepower | 48 @ 2800 rpm 38 kW @ 2500 rpm |
| Firing order | 1 - 3 - 4 - 2 |
| Low idle | 1500 rpm 313 Hz |
| High idle | 2500 rpm 441,7 Hz |
| Compression ratio | 18:1 |
| Compression pressure | 426 psi 29,4 bar |
| Pressure (psi) of lowest cylinder must be within 50 psi / 3.45 bar of highest cylinder | |
| Governor | electronic |
| Valve clearance, cold | |
| Intake | 0.008 in 0,2 mm |
| Exhaust | 0.008 in 0,2 mm |
| Lubrication system | |
| Oil pressure (@ 2000 rpm) | 40 to 60 psi 1,4 to 3 bar |
| Oil capacity (including filter) | 9.4 - 11.2 quarts 8,9 - 10,6 liters |
| Oil viscosity requirements | |
| Below 86°F / 30°C | 5W-20 |
| -4°F to 104°F / -20°C to 40°C | 10W-30 |
| Above 14°F / -10°C | 15W-40 |
| Unit ships with 15W-40. Extreme operating temperatures may require the use of alternative engine oils. For oil requirements, refer to the Engine Operator Manual for your engine. | |
| Oil pressure sending unit | |
| Oil pressure switch point | 14.2 psi 1 bar |

Fuel injection system

| | |
|---------------------|---------------------|
| Injection pump make | Zexel |
| Injection pressure | 2133 psi 147 bar |

Fuel requirement

For fuel requirements, refer to the engine Operator Manual for your engine.

| | |
|--------------------------|--------------|
| Alternator output | 85A @ 12V DC |
|--------------------------|--------------|

| | |
|----------------------------|-----------------|
| Fan belt deflection | 3/8 in 10 mm |
|----------------------------|-----------------|

Starter motor

| | |
|-----------------------|--------------------|
| Current draw, no load | 140A - 200A |
| Brush length, new | 0.7480 in 19 mm |
| Brush length, minimum | 0.5 in 12,7 mm |

Battery

| | |
|-----------------------------|-------------|
| Type | 12V DC |
| Quantity | 1 |
| Cold cranking ampere | 1000A |
| Reserve capacity @ 25A rate | 200 minutes |

Engine coolant

| | |
|----------|--------------------------|
| Capacity | 7.7 quarts 7,3 liters |
|----------|--------------------------|

Coolant temperature switch

| | |
|--------------------------|------------------|
| Temperature switch point | 221° F 105° C |
|--------------------------|------------------|

Specifications

Ford MSG-425 EFI Engine

| | |
|---|-----------------------------------|
| Displacement | 153 cu in 2,5 liters |
| Number of cylinders | 4 |
| Bore and Stroke | 3.5 x 3.9 inches 89 x 100 mm |
| Horsepower | 60 @ 2500 rpm 45 kW @ 2500 rpm |
| Firing order | 1 - 3 - 4 - 2 |
| Low idle, standby | 1000 rpm 33,3 Hz |
| Low idle, function enable | 1600 rpm 53,3 Hz |
| High idle | 2500 rpm 83,3 Hz |
| Compression ratio | 9.7:1 |
| Compression pressure (approx.) | |
| Pressure (psi or bar) of lowest cylinder must be at least 75% of highest cylinder | |
| Lubrication system | |
| Oil pressure (operating temperature @ 2000 rpm) | 29 to 39 psi 2,75 to 4,1 bar |
| Oil capacity (including filter) | 6.7 quarts 6,4 liters |
| Oil Pressure switch | |
| Oil pressure switch point | 7.5 psi 0,51 bar |
| Oil viscosity requirements | |
| Extreme operating temperatures may require the use of alternative engine oils. For oil requirements, refer to the Engine Operator Handbook on your machine. | |
| Electronic fuel pump | |
| Fuel pressure, static | 60 psi 4,1 bar |
| Fuel flow rate | 0.58 gpm 2,2 L/min |

Fuel requirement

For fuel requirements, refer to the engine Operator Manual for your engine.

Ignition system

| | |
|-----------------|--|
| Spark plug type | Motorcraft AYFS-32Y-R |
| Spark plug gap | 0.049 to 0.053 inches 1,25 to 1,35 mm |

Engine coolant

| | |
|----------|----------------------------|
| Capacity | 11.5 quarts 10,9 liters |
|----------|----------------------------|

Coolant temperature switch

| | |
|--------------------------|----------------|
| Temperature switch point | 230°F 110°C |
|--------------------------|----------------|

Starter motor

| | |
|------------------------------|----------------|
| Normal engine cranking speed | 200 to 250 rpm |
| Current draw, no load | 140-200A |
| Current draw, maximum load | 800A |

Alternator

| | |
|-------------------|---------------|
| Alternator output | 95A, 13.8V DC |
|-------------------|---------------|

Battery

| | |
|-----------------------------|---------------------|
| Type | 12V DC, Group 34/78 |
| Quantity | 1 |
| Cold cranking ampere @ 0°F | 900A |
| Reserve capacity @ 25A rate | 200 minutes |

Specifications

Machine Torque Specifications

Note: All torque values are shown lubricated unless otherwise noted.

Platform Rotator

| | |
|-----------------------|----------------------|
| 1-8 center bolt, GR 5 | 483 ft-lbs 655 Nm |
| 1/2 -13 bolts, GR 8 | 85 ft-lbs 115 Nm |

Turntable rotate assembly

| | |
|----------------------------------|----------------------|
| Rotate bearing mounting bolts | 159 ft-lbs 215 Nm |
| Drive motor/brake mounting bolts | 93 ft-lbs 126 Nm |

Drive motors and hubs

| | |
|----------------------------|----------------------|
| Drive hub mounting bolts | 179 ft-lbs 242 Nm |
| Drive motor mounting bolts | 52 ft-lbs 70 Nm |

JIC 37° Fittings

(swivel nut or hose connection)

| SAE Dash Size | Thread Size | Flats |
|---------------|-------------|-------|
| -4 | 7/16-20 | 2 |
| -6 | 9/16-18 | 1 1/2 |
| -8 | 3/4-16 | 1 1/2 |
| -10 | 7/8-14 | 1 1/2 |
| -12 | 1 1/16-12 | 1 1/4 |
| -16 | 1 5/16-12 | 1 |
| -20 | 1 5/8-12 | 1 |
| -24 | 1 7/8-12 | 1 |

Hydraulic Hose and Fitting Torque Specifications

Your machine is equipped with Parker Seal-Lok™ ORFS or 37° JIC fittings and hose ends. Genie specifications require that fittings and hose ends be torqued to specification when they are removed and installed or when new hoses or fittings are installed.

Seal-Lok™ Fittings

(hose end - ORFS)


| SAE Dash Size | Torque |
|---------------|---------------------|
| -4 | 18 ft-lbs / 25 Nm |
| -6 | 30 ft-lbs / 41 Nm |
| -8 | 40 ft-lbs / 55 Nm |
| -10 | 60 ft-lbs / 81 Nm |
| -12 | 85 ft-lbs / 115 Nm |
| -16 | 110 ft-lbs / 150 Nm |
| -20 | 150 ft-lbs / 205 Nm |
| -24 | 230 ft-lbs / 315 Nm |

Specifications

SAE O-ring Boss Port


(tube fitting - installed into Aluminum)
(all types)

| SAE Dash Size | Torque |
|---------------|-----------------------|
| -4 | 14 ft-lbs / 19 Nm |
| -6 | 23 ft-lbs / 31,2 Nm |
| -8 | 36 ft-lbs / 49 Nm |
| -10 | 62 ft-lbs / 84 Nm |
| -12 | 84 ft-lbs / 114 Nm |
| -16 | 125 ft-lbs / 169,5 Nm |
| -20 | 151 ft-lbs / 204,7 Nm |
| -24 | 184 ft-lbs / 249,5 Nm |



Adjustable Fitting

1 jam nut



Non-adjustable fitting

SAE O-ring Boss Port

(tube fitting - installed into Steel)

| SAE Dash Size | Torque |
|--------------------------|-----------------------|
| -4 ORFS / 37° (Adj) | 15 ft-lbs / 20,3 Nm |
| ORFS (Non-adj) | 26 ft-lbs / 35,3 Nm |
| 37° (Non-adj) | 22 ft-lbs / 30 Nm |
| -6 ORFS (Adj / Non-adj) | 35 ft-lbs / 47,5 Nm |
| 37° (Adj / Non-adj) | 29 ft-lbs / 39,3 Nm |
| -8 ORFS (Adj / Non-adj) | 60 ft-lbs / 81,3 Nm |
| 37° (Adj / Non-adj) | 52 ft-lbs / 70,5 Nm |
| -10 ORFS (Adj / Non-adj) | 100 ft-lbs / 135,6 Nm |
| 37° (Adj / Non-adj) | 85 ft-lbs / 115,3 Nm |
| -12 (All types) | 135 ft-lbs / 183 Nm |
| -16 (All types) | 200 ft-lbs / 271,2 Nm |
| -20 (All types) | 250 ft-lbs / 339 Nm |
| -24 (All types) | 305 ft-lbs / 413,5 Nm |

Specifications

Torque Procedure

Seal-Lok™ fittings

- 1 Replace the O-ring. The O-ring must be replaced anytime the seal has been broken. The O-ring cannot be re-used if the fitting or hose end has been tightened beyond finger tight.

Note: The O-ring in Parker Seal Lok™ fittings and hose end are custom-size O-rings. They are not standard size O-rings. They are available in the O-ring field service kit (Genie part number 49612GT).

- 2 Lubricate the O-ring before installation.
- 3 Be sure the O-ring face seal is seated and retained properly.
- 4 Position the tube and nut squarely on the face seal end of the fitting and tighten the nut finger tight.
- 5 Tighten the nut or fitting to the appropriate torque. Refer to the appropriate torque chart in this section.
- 6 Operate all machine functions and inspect the hose, fittings and related components to confirm there are no leaks.

Specifications

JIC 37° fittings

- 1 Align the tube flare (hex nut) against the nose of the fitting body (body hex fitting) and tighten the hex nut to the body hex fitting to hand tight, approximately 30 in-lbs / 3.4 Nm.
- 2 Using a permanent ink marker, make a reference mark on one the flats of the hex nut and continue the mark onto the body of the hex fitting. Refer to Illustration 1.




Illustration 1

- 1 hex nut
- 2 reference mark
- 3 body hex fitting

- 3 Working clockwise on the body hex fitting, make a second mark with a permanent ink marker to indicate the proper tightening position. Refer to Illustration 2.

Note: Use the JIC 37° Fitting table in this section to determine the correct number of flats, for the proper tightening position.

Note: The marks indicate the correct tightening positions have been determined. Use the second mark on the body hex fitting to properly tighten the joint after it has been loosened.




Illustration 2

- 1 body hex fitting
- 2 reference mark
- 3 second mark

- 4 Tighten the hex nut until the mark on the hex nut is aligned with the second mark on the body hex fitting.
- 5 Operate all machine functions and inspect the hose, fittings and related components to confirm there are no leaks.

Repair Procedures



Observe and Obey:

- ☑ Repair procedures shall be completed by a person trained and qualified on the repair of this machine.
- ☑ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☑ Repair any machine damage or malfunction before operating the machine.

Before Repairs Start:

- ☑ Read, understand and obey the safety rules and operating instructions in the appropriate operator's manual on your machine.
- ☑ Be sure that all necessary tools and parts are available and ready for use.
- ☑ Use only Genie approved replacement parts.
- ☑ Read each procedure completely and adhere to the instructions. Attempting shortcuts may produce hazardous conditions.

Machine Configuration:

- ☑ Unless otherwise specified, perform each repair procedure with the machine in the following configuration:
 - Machine parked on a firm, level surface
 - Key switch in the off position with the key removed
 - The red Emergency Stop button in the off position at both the ground and platform controls
 - Wheels chocked
 - All external AC power supply disconnected from the machine
 - Boom in the stowed position
 - Turntable secured with the turntable rotation lock

Repair Procedures

About This Section

Most of the procedures in this section should only be performed by trained service professional in a suitably equipped workshop. Select the appropriate repair procedure after troubleshooting the problem.

Perform disassembly procedures to the point where repairs can be completed. Then to re-assemble, perform the disassembly steps in reverse order.

Symbols Legend



Safety alert symbol—used to alert personnel to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



Indicates a imminently hazardous situation which, if not avoided, will result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, may cause minor or moderate injury.



Indicates a potentially hazardous situation which, if not avoided, may result in property damage.


- ⦿ Indicates that a specific result is expected after performing a series of steps.
- ☒ Indicates that an incorrect result has occurred after performing a series of steps.

Platform Controls

Platform Controls

The platform control box contains one printed circuit board. The ALC-500 circuit board inside the platform control box controls all proportional machine functions from the platform. The joystick controllers at the platform controls utilize Hall Effect technology and require no adjustment. The operating parameters of the joysticks are stored in memory at the ECM circuit board at the platform controls. If a joystick error occurs or if a joystick is replaced, it will need to be calibrated before that particular machine function will operate. Refer to Repair Procedure, *How to Calibrate a Joystick*.

Each joystick controller should operate smoothly and provide proportional speed control over its entire range of motion.



- 1 ALC-500 circuit board
- 2 drive/steer joystick controller
- 3 secondary boom up/down joystick controller
- 4 primary boom up/down and turntable rotate left/right joystick controller

1-1

ALC-500 Circuit Board

Note: When the ALC-500 circuit board is replaced, the joystick controllers will need to be calibrated. Refer to Repair Procedure, *How to Calibrate a Joystick*.

How to Remove the ALC-500 Circuit Board

- 1 Push in the red Emergency Stop button to the off position at both the ground and platform controls.
- 2 Remove the platform control box lid retaining fasteners. Open the control box lid.
- 3 Locate the ALC-500 circuit board mounted to the inside of the platform control box.

WARNING

Electrocution/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

- 4 Attach a grounded wrist strap to the ground screw inside the platform control box.

NOTICE

Component damage hazard. Electrostatic discharge (ESD) can damage printed circuit board components. Maintain firm contact with a metal part of the machine that is grounded at all times when handling printed circuit boards OR use a grounded wrist strap.

- 5 Carefully disconnect the wire connectors from the circuit board.
- 6 Remove the ALC-500 circuit board mounting fasteners.
- 7 Carefully remove the ALC-500 circuit board from the platform control box.

Platform Controls

1-2 Joysticks

How to Calibrate a Joystick

The joystick controllers on this machine utilize digital Hall Effect technology for proportional control. If a joystick controller is disconnected or replaced, it must be calibrated before that particular machine function will operate.

Note: The joystick must be calibrated before the threshold, max-out or ramping can be set.

Note: Perform this procedure with the engine off.

- 1 Open the platform control box.
- 2 Pull out the red Emergency Stop button to the on position at both the ground and platform controls.
- 3 Turn the key switch to platform control. Do not start the engine.
- 4 Select a joystick to calibrate.
- 5 Disconnect the wire harness connector from the joystick for approximately 10 seconds or until the alarm sounds. Connect the wire harness connector to the joystick.
- 6 Move the joystick full stroke in either direction and hold for 5 seconds.
- 7 Return the joystick to the neutral position, pause for a moment, then move the joystick full stroke in the opposite direction. Hold for 5 seconds and return the joystick to the neutral position.
- ⦿ **Result:** The alarm should sound indicating successful joystick calibration.
- ✗ **Result:** The alarm does not sound. Check the electrical connections or replace the joystick.
- 8 Repeat this procedure for each joystick controlled machine function including the thumb rocker steer switch.

Note: No machine function should operate while performing the joystick calibration procedure.

How to Adjust the Joystick Max-out Setting

The max-out setting of a joystick controls the maximum speed of a joystick-controlled machine function. Whenever a hydraulic cylinder, drive motor or hydraulic pump is replaced, the max-out setting should be adjusted to maintain optimum performance. The max-out settings on the joystick can be changed to compensate for hydraulic pump wear to maintain peak performance from the machine.

Note: Perform this procedure with the boom in the stowed position.

- 1 Pull out the red Emergency Stop button to the on position at both the ground and platform controls.
- 2 Turn the key switch to platform control. Do not start the engine.
- 3 Push in the platform controls red Emergency Stop button to the off position.
- 4 Do not press down the foot switch.
- 5 Move and hold the drive enable toggle switch in the right position and pull out the red Emergency Stop button to the on position.
- 6 When the alarm sounds, release the drive enable toggle switch.
- 7 Momentarily activate the drive enable toggle switch in the right direction 4 times.
- ⦿ **Result:** There should be a pause and the alarm should sound 4 times indicating that the machine is in max-out calibration mode.
- ✗ **Result:** The alarm does not sound. Repeat steps 3 through 7.

Platform Controls

- 8 Start the engine from the platform controls and press down the foot switch.
- 9 Start a timer and activate the machine function that needs to be adjusted. Record the time it takes for that function to complete a full cycle (ie; boom up).
- 10 Compare the machine function time with the function times listed in Refer to Specifications, *Performance Specifications*. Determine whether the function time needs to increase or decrease.
- 11 While the joystick is activated, adjust the max-out setting to achieve the proper function cycle time. Momentarily move the drive enable toggle switch in the right direction to increase the function speed or momentarily move the drive enable toggle switch in the left direction to decrease the function speed.

Note: Each time the drive enable toggle switch is momentarily moved, the function speed will change in 2% increments from a default of 100%, with a minimum of 60% and a maximum of 120%.

- 12 Repeat steps 9 through 11 for each joystick controlled machine function.
 - 13 Return the joystick to the neutral position and wait for approximately 10 seconds to allow the settings to be saved.
- ⦿ Result: The alarm should sound indicating that the settings have been saved in memory.

Note: Do not operate any machine function during the 10 second waiting time.

How to Adjust the Joystick Ramp Rate Setting

The ramp rate setting of a joystick controls the time at which it takes for the joystick to reach maximum output, when moved out of the neutral position. The ramp rate settings of a joystick can be changed to compensate for hydraulic pump wear to maintain peak performance from the machine.

Note: Perform this procedure with the boom in the stowed position.

- 1 Pull out the red Emergency Stop button to the on position at both the ground and platform controls.
 - 2 Turn the key switch to platform control. Do not start the engine.
 - 3 Push in the platform controls red Emergency Stop button to the off position.
 - 4 Do not press down the foot switch.
 - 5 Move and hold the drive enable toggle switch in the right position and pull out the red Emergency Stop button to the on position.
 - 6 When the alarm sounds, release the drive enable toggle switch.
 - 7 Momentarily activate the drive enable toggle switch in the right direction 6 times.
- ⦿ Result: There should be a pause and the alarm should sound 6 times indicating that the machine is in ramp rate calibration mode.

Platform Controls

- 8 Start the engine from the platform controls and press down the foot switch.
- 9 Start a timer and simultaneously move the joystick in either direction full stroke. Note how long it takes the function to reach maximum speed. This is the ramp rate.
- 10 Compare the function ramp rate time with the table below and determine whether the ramp rate time needs to increase or decrease.
- 11 While the joystick is activated, set the ramp rate. Momentarily move the drive enable toggle switch in the right direction to increase the time or momentarily move the drive enable toggle switch in the left direction to decrease the time.

Note: Each time the drive enable toggle switch is momentarily moved, the time will change in 10% increments.

- 12 Repeat steps 9 through 11 for each joystick controlled machine function.

- 13 Return the joystick to the neutral position and wait for approximately 10 seconds to allow the settings to be saved.

- ⦿ Result: The alarm should sound indicating that the settings have been saved in memory.

Note: Do not operate any machine function during the 10 second waiting time.

Ramp rate (factory settings)

Primary boom up/down

| | |
|------------|------------|
| accelerate | 4 seconds |
| decelerate | 0.5 second |

Secondary boom up/down

| | |
|------------|------------|
| accelerate | 2 seconds |
| decelerate | 0.5 second |

Turntable rotate

| | |
|------------|------------|
| accelerate | 2 seconds |
| decelerate | 0.5 second |

Drive

| | |
|--|-------------|
| accelerate | 3 seconds |
| decelerate to neutral | 0.5 second |
| decelerate, change of direction | 0.5 second |
| decelerate, coasting | 0.75 second |
| decelerate, braking | 1 second |
| decelerate, shift from low to high speed | 1 seconds |
| decelerate, shift from high to low speed | 2 seconds |

Platform Controls

How to Adjust the Joystick Threshold Setting

The threshold setting of a joystick is the minimum output at which a function proportional valve can open and allow the function to operate.

Note: Perform this procedure with the boom in the stowed position.

- 1 Pull out the red Emergency Stop button to the on position at both the ground and platform controls.
- 2 Turn the key switch to platform control. Do not start the engine.
- 3 Push in the platform controls red Emergency Stop button to the off position.
- 4 Do not press down the foot switch.
- 5 Move and hold the drive enable toggle switch in the right position and pull out the red Emergency Stop button to the on position.
- 6 When the alarm sounds, release the drive enable toggle switch.
- 7 Momentarily activate the drive enable toggle switch in the right direction 8 times.
 - ⦿ Result: There should be a pause and the alarm should sound 8 times indicating that the machine is in threshold calibration mode.
 - ✗ Result: The alarm does not sound. Repeat steps 3 through 7.
- 8 Start the engine from the platform controls and press down the foot switch.
- 9 Select a boom function joystick to set the threshold.
- 10 Slowly move the joystick off center in either direction just until the function begins to move.
- 11 Slowly move the joystick back towards the neutral position. Just before the function stops moving, move the drive enable toggle switch to either side to set the threshold.
 - ⦿ Result: The alarm should sound indicating a successful calibration.

Note: For each joystick axis, the threshold must be set for both directions.

- 12 Repeat steps 9 through 11 for each direction of boom joystick controlled machine function (boom up/down, boom extend/retract and turntable rotate left/right).
- 13 Return the joystick to the neutral position and wait for approximately 10 seconds to allow the settings to be saved.
 - ⦿ Result: The alarm should sound indicating that the settings have been saved in memory.

Note: Do not operate any machine function during the 10 second waiting time.

- 14 Cycle the red Emergency Stop button off, then back on.

Platform Components

2-1

Platform Leveling Slave Cylinder

The slave cylinder and the rotator pivot are the two primary supports for the platform. The slave cylinder keeps the platform level through the entire range of boom motion. It operates in a closed-circuit hydraulic loop with the master cylinder. The slave cylinder is equipped with counterbalance valves to prevent movement in the event of a hydraulic line failure.

How to Remove the Platform Leveling Slave Cylinder

Note: Before cylinder removal is considered, bleed the slave cylinder to be sure there is no air in the closed loop.

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or hose end must be replaced. All connections must be torqued to specification during installation. Refer to Specifications, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Extend the primary boom until the slave cylinder barrel-end pivot pin is accessible.
- 2 Raise the primary boom slightly and place blocks under the platform for support.
- 3 Lower the primary boom until the platform is resting on the blocks just enough to support the platform.

Note: Do not rest the entire weight of the boom on the blocks.

- 4 Tag, disconnect and plug the hydraulic hoses from the slave cylinder at the unions and connect them together using a connector. Connect the hoses from the cylinder together using a connector.

⚠ WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 5 Remove the pin retaining fastener from the slave cylinder rod-end pivot pin. Do not remove the pin.
- 6 Remove the external snap rings from the slave cylinder barrel-end pivot pin. Do not remove the pin.
- 7 Place a block under the slave cylinder for support. Protect the cylinder rod from damage.
- 8 Use a soft metal drift to drive the rod-end pivot pin out.

⚠ WARNING

Crushing hazard. The platform could fall when the slave cylinder rod-end pivot pin is removed if not properly supported.

NOTICE

Component damage hazard. The slave cylinder rod may become damaged if it is allowed to fall if not properly supported by the lifting device.


- 9 Use a soft metal drift and drive the barrel-end pin out.
- 10 Carefully pull the cylinder out of the primary boom.

Platform Components


How to Bleed the Slave Cylinder

Note: This procedure will have to be preformed outside.

- 1 Raise the jib to a horizontal position and raise the secondary boom 3 feet.
- 2 Move the function enable toggle switch to either side. Simultaneously activate and hold the primary boom up and platform level up toggle switches until the primary boom is fully raised.
- ⊙ The platform should be facing in an upward position. As shown.



- 3 While still holding the function enable toggle switch, simultaneously activate the primary boom down and platform level down toggle switches until the primary boom is fully lowered.
- ⊙ The platform should be facing in a down position. As shown.



2-2

Platform Rotator

How to Bleed the Platform Rotator

Note: This procedure will require two people. Do not start the engine. Use auxiliary power for this procedure.

- 1 Move the function enable toggle switch to either side and activate the platform rotate toggle switch to the right then the left through two platform rotation cycles, then hold the switch to the right position until the platform is fully rotated to the right.
- 2 Place a suitable container underneath the platform rotator.
- 3 Open the top bleed screw on the rotator, but do not remove it.

⚠ WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 4 Move the function enable toggle switch to either side and hold the platform rotate toggle switch to the left position until the platform is fully rotated to the left. Continue holding the toggle switch until air stops coming out of the bleed screw. Close the bleed screw.

⚠ WARNING

Crushing hazard. Keep clear of the platform during rotation.

- 5 Open the bottom bleed screw on the rotator, but do not remove it.

⚠ WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

Platform Components

- 6 Move the function enable toggle switch to either side and hold the platform rotate toggle switch to the right position until the platform is fully rotated to the right. Continue holding the toggle switch until air stops coming out of the bleed screw. Close the bleed screw.

⚠ WARNING

Crushing hazard. Keep clear of the platform during rotation.

- 7 Clean up any oil that may have spilled. Properly discard the used oil.
- 8 Rotate the platform fully in both directions and inspect the bleed screws for leaks.

2-3

Platform Overload System

Proper calibration of the platform overload system is essential to safe machine operation. Continued use of an improperly calibrated platform overload system could result in the system failing to sense an overloaded platform. The stability of the machine is compromised, and it could tip over.

Note: Perform this procedure with the machine on a firm, level surface.

How to Perform a Zero Load Platform Calibration

Perform this procedure when platform overload is not operating within the calibration parameters. This procedure will re-calibrate the zero load point without affecting a previous full load calibration. In most cases the machine will maintain full load capacity, however, in some situations the platform load capacity may be reduced until a full load calibration has been performed.

- 1 Remove all weight, tools, accessories and equipment from the platform.

⚠ DANGER

Tip-over hazard. Failure to remove all non-integrated factory and non-factory options and accessories could result in the machine tipping over, causing death or serious injury.

- 2 Turn the key switch to ground controls.

Platform Components

- 3 Pull out the red Emergency Stop button and momentarily activate the calibration toggle switch located on the left side of the control box in the up position 3 times to enter calibration mode.

Note: The calibration toggle switch must be activated within 5 seconds.

- Result: The green LED on the SCON located under the ground control box is flashing confirming calibration mode is active.
- 4 Activate and hold the calibration toggle switch in the down position for 2 seconds to store the zero load calibration.

Result: An audible alarm sounds for 1 second. Calibration has been stored.

How to Perform a Full Load Platform Calibration

Perform this procedure if the platform support or load cell sensor has been replaced, or if a zero load platform calibration does not return the machine to full load capacity.

- 1 Remove all weight, tools, accessories and equipment from the platform.

Note: Remove the welder (if equipped).

DANGER

Tip-over hazard. Failure to remove all non-integrated factory and non-factory options and accessories could result in the machine tipping over, causing death or serious injury.

- 2 Turn the key switch to ground controls.
- 3 Pull out the red Emergency Stop button and momentarily activate the calibration toggle switch located on the left side of the control box in the up position 3 times to enter calibration mode.

Note: The calibration toggle switch must be activated within 5 seconds.


- Result: The green LED on the SCON located under the ground control box is flashing confirming calibration mode is active.
- 4 Activate and hold the calibration toggle switch in the down position for 2 seconds to store the zero load calibration.
- Result: An audible alarm sounds for 1 second. Calibration has been stored.

Platform Components


- 5 **XC models:** Add maximum rated load of 1000 lbs / 454 kg to the center of the platform.

HF models: Add maximum rated load of 600 lbs / 272 kg to the center of the platform.

Note: If test weights are not available, you may use an industrial scale to weigh available objects until it equals the platform's maximum capacity.



Note: Alternate method for achieving rated load in the platform is to attach a hanging scale to the bottom of the platform and apply load using a winch or ratchet until the readout displays the appropriate weight.



Platform hidden from illustration for clarity

- 1 platform support
- 2 hanging scale
- 3 winch or ratchet
- 4 anchoring device

- 6 Activate and hold the calibration toggle switch in the up position for 2 seconds to store the rated load calibration.
- Result: An audible alarm sounds for 1 second. Calibration has been stored.
- 7 Push in the red Emergency Stop button to the off position.

Confirm calibration:

- 8 Start the engine from the ground controls.
- 9 Place an additional 50 lbs / 23 kg of weight in the platform.

Result: The alarm sounds. The engine turns off. The platform overload indicator light flashes at the platform controls and *Platform Overload* is displayed on the LCD screen at the ground controls.

Note: There may be a 2 second delay before the overload indicator lights flash and the alarm sounds.

- 10 Test all machine functions from the ground controls.
- Result: Engine does not start. Limited APU functionality. Elevate and extend functions do not operate.
 - Remove the test weight or the rated load from the platform.

Platform Components

How to Replace the Load Cell Sensor

Note: The preload adjustment should only be performed after the load cell sensor has been replaced.

- 1 Remove all equipment or tools from the platform. Remove the welder if equipped.
- 2 At the platform, remove the plastic instruction holder from the document mount plate.
- 3 Tag and disconnect the load cell sensor harness.
- 4 Loosen the jam nut securing the load cell sensor foot and rotate the foot screw clockwise to remove the preload.
- 5 Remove the fasteners securing the load cell sensor and remove the sensor.

Install the new Load Cell Sensor

- 6 Screw the foot with jam nut into the top of the load cell sensor until the foot bolt extends out of the bottom of the sensor. The foot should not contact the flex plate when assembling onto the platform support.
- 7 Assemble the load cell and foot assembly to the platform and securely tighten the two mounting screws. Torque the bolts to 101 ft-lbs / 137 Nm.

Set the Load Cell Sensor Preload

- 8 Rotate the foot screw counter clockwise until the foot just contacts the flex plate (finger tight).
- 9 Using an open end wrench, continue to rotate the foot counter clockwise an additional 1/2 turn (180°). Then, while holding the foot bolt, securely tighten the jam nut. Torque the jam nut to 55 ft-lbs / 75 Nm.
- 10 Attach the load cell sensor harness.
- 11 Install the plastic instruction holder.
- 12 Calibrate the platform overload system. Refer to Repair Procedure *How to Calibrate the Platform Overload System*.


2-4 Platform Overload Recovery Fault

If the ground controls hour meter displays fault code 8221, the emergency lowering system has been used while the platform was overloaded.

How to Clear the Platform Overload Recovery Fault

Note: This message shall be cleared by a person trained and qualified on the troubleshooting and repair of this machine.

- 1 Turn the key switch to ground control and pull out the red Emergency Stop button to the on position.
- 2 Wait 10 seconds and activate the calibration toggle switch in the following sequence (gain)(gain)(gain)(zero).



1 gain
2 zero

- 3 Turn the key switch to the off position.

Jib Boom Components

3-1 Jib Boom

How to Remove the Jib Boom

Note: Perform this procedure with the boom in the stowed position.

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or hose end must be replaced. All connections must be torqued to specification during installation. Refer to Specifications, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Remove the platform.
- 2 Disconnect the electrical connector from the jib boom/platform rotate select valve manifold mounted to the platform support.
- 3 Tag, disconnect and plug all of the hydraulic hoses from the jib boom/platform rotate select valve manifold. Cap the fittings on the manifold and pull the hoses out through the platform rotator.

⚠ WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 4 Remove the platform mounting weldment.
- 5 Attach a lifting strap from an overhead crane to the platform rotator for support.
- 6 Remove the pin retaining fastener from the jib boom lift cylinder rod-end pivot pin. Do not remove the pin.

- 7 Remove the pin retaining fasteners from both platform rotator pivot pins. Do not remove the pins.
- 8 Use a soft metal drift to remove the leveling arm pivot pin and let the leveling arms hang down.
- 9 Slide both of the jib boom leveling arms off of the jib boom cylinder rod-end pivot pin.
- 10 Remove the hose and cable cover from the side of the jib boom. Remove the hose and cable separators.
- 11 Attach a lifting strap from an overhead crane to the jib boom.
- 12 Support the barrel end of the jib boom lift cylinder with a suitable lifting device.
- 13 Tag, disconnect and plug the jib boom lift cylinder hydraulic hoses. Cap the fittings on the cylinder.

⚠ WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 14 Remove the pin retaining fastener from the jib boom lift cylinder barrel-end pivot pin.

Jib Boom Components

- 15 Use a soft metal drift to remove the pin and let the cylinder hang down. Remove the platform rotator from the machine.

⚠ WARNING Crushing hazard. The jib boom could fall when the barrel-end pivot pin is removed if not properly supported by the overhead crane.

- 16 Remove the pin retaining fastener from the jib boom pivot pin. Use a soft metal drift to remove the pin, then remove the jib boom from the bellcrank.

⚠ WARNING Crushing hazard. The jib boom may become unbalanced and fall when it is removed from the machine if it is not properly supported by the overhead crane.

- 17 Attach a lifting strap from an overhead crane to the lug on the rod end of the jib boom lift cylinder.

- 18 Use a soft metal drift to remove the jib boom lift cylinder rod-end pivot pin, then remove the jib boom lift cylinder from the bellcrank.

⚠ WARNING Crushing hazard. The jib boom lift cylinder may become unbalanced and fall when it is removed from the machine if it is not properly supported by the overhead crane.

3-2

Jib Boom Lift Cylinder

How to Remove the Jib Boom Lift Cylinder

Note: Perform this procedure with the boom in the stowed position.

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or hose end must be replaced. All connections must be torqued to specification during installation. Refer to Specifications, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Raise the jib boom slightly and place blocks under the platform mounting weldment. Then lower the jib boom until the platform is resting on the blocks just enough to support the platform.

Note: Do not rest the entire weight of the boom on the blocks.

- 2 Tag, disconnect and plug the jib boom lift cylinder hydraulic hoses. Cap the fittings on the cylinder.

⚠ WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 3 Remove the pin retaining fasteners from the jib boom lift cylinder rod-end pivot pin. Do not remove the pin.

Jib Boom Components

- 4 Use a soft metal drift to tap the jib boom lift cylinder rod-end pivot pin half way out. Then lower one of the leveling arms to the ground. Tap the pin the other direction and lower the opposite leveling arm. Do not remove the pin.
- 5 Support the jib boom lift cylinder with a suitable lifting device.
- 6 Remove the pin retaining fastener from the jib boom lift cylinder barrel-end pivot pin.
- 7 Use a soft metal drift to remove the pin and let the cylinder hang down. Remove the platform rotator from the machine.

⚠ WARNING Crushing hazard. The jib boom may become unbalanced and fall when it is removed from the machine if it is not properly supported by the overhead crane.

- 8 Attach a lifting strap from an overhead crane to the lug on the rod end of the jib boom lift cylinder.
- 9 Use a soft metal drift to remove the jib boom lift cylinder rod-end pin. Remove the jib boom lift cylinder from the machine.

⚠ WARNING Crushing hazard. The jib boom lift cylinder may become unbalanced and fall when it is removed from the machine if it is not properly supported by the overhead crane.

Primary Boom Components

4-1 Cable Track

The primary boom cable track guides the cables and hoses running up the boom. It can be repaired link by link without removing the cables and hoses that run through it. Removing the entire primary boom cable track is only necessary when performing major repairs that involve removing the primary boom.

How to Remove the Cable Track

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or hose end must be replaced. All connections must be torqued to specification during installation. Refer to Specifications, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Locate the cables from the primary boom cable track to the platform control box. Number each cable and its entry location at the platform control box.
- 2 Disconnect the cables from the platform control box.
- 3 Remove the hose and cable cover from the side of the jib boom. Remove the hose and cable separators.
- 4 Remove the hose clamp on the primary boom bellcrank.
- 5 Pull all of the electrical cables out of the plastic cable track. Do not pull out the hydraulic hoses.

- 6 Tag, disconnect and plug the hydraulic hoses from the "V1" and "V2" ports on the counterbalance valve manifold located on the platform rotator. Cap the fittings on the manifold.

⚠ WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 7 Tag and disconnect the hydraulic hoses from the platform leveling slave cylinder at the union and connect them together using a connector. Connect the hoses from the cylinder together using a connector.

⚠ WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 8 Tag, disconnect and plug the hydraulic hoses from the jib boom/platform rotate manifold. Cap the fittings on the manifold.

⚠ WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

Primary Boom Components

- 9 Tag, disconnect and plug the platform rotator hydraulic hoses at the union located above the primary boom lift cylinder. Cap the fittings on the unions.

⚠ WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 10 Tag, disconnect and plug the hydraulic hoses from the platform leveling master cylinder. Cap the fittings on the cylinder.

⚠ WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 11 Raise the boom to a horizontal position.
- 12 Place blocks between the upper and lower cable tracks and secure the upper and lower tracks together.

⚠ WARNING

Crushing hazard. If the upper and lower cable tracks are not properly secured together, the cable track could become unbalanced and fall when removed from the machine.

- 13 Attach a lifting strap from an overhead 5 ton / 5,000 kg capacity crane to the platform end of the primary boom for support. Do not lift it.
- 14 Remove all hose and cable clamps from the underside of the primary boom.
- 15 Support the rod end of the primary boom lift cylinder with a suitable lifting device.

- 16 Remove the pin retaining fasteners from the primary boom lift cylinder rod-end pivot pin. Do not remove the pin.
- 17 Raise the primary boom slightly with the overhead crane to relieve the pressure on the primary boom lift cylinder rod-end pivot pin.
- 18 Use a soft metal drift to remove the primary boom lift cylinder rod-end pivot pin.

⚠ WARNING

Crushing hazard. The primary boom lift cylinder could become unbalanced and fall if not properly supported by the lifting device.

- 19 Lower the rod end of the primary boom lift cylinder approximately 12 inches / 30 cm.
- 20 Pull all of the hoses and cables out and away from the mounting ears for the rod end of the primary boom lift cylinder.
- 21 Raise the rod end of the primary boom lift cylinder back into position and install the rod-end pivot pin. Install the pin retaining fasteners.
- 22 Attach a strap from an overhead crane to the cable track.
- 23 Remove the mounting fasteners from the upper cable track at the platform end of the extension boom.
- 24 Remove the cable track mounting fasteners that attach the lower cable track to the primary boom.
- 25 Remove the cable track from the machine and place it on a structure capable of supporting it.

⚠ WARNING

Crushing hazard. The cable track could become unbalanced and fall if not properly attached to the overhead crane.

NOTICE

Component damage hazard. Cables and hoses can be damaged if they are kinked or pinched.


Primary Boom Components

How to Repair the Primary Boom Cable Track

NOTICE

Component damage hazard.
The boom cable track can be damaged if it is twisted.

Note: A 7 link repair section of cable track is available through the Genie Service Parts Department.



- 1 link separation point
- 2 lower clip

- 1 Use a slotted screwdriver to pry down on the lower clip.
- 2 To remove a single link, open the lower clip and then use a screw driver to pry the link to the side.
- 3 Repeat steps 1 and 2 for each link.

4-2 Primary Boom

How to Remove the Primary Boom

⚠ WARNING

Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is strongly recommended.

Note: Perform this procedure with the boom in the stowed position.

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or hose end must be replaced. All connections must be torqued to specification during installation. Refer to Specifications, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Remove the platform.
- 2 Remove the jib boom. Refer to Repair Procedure, *How to Remove the Jib Boom*.
- 3 Remove the cable track. Refer to Repair Procedure, *How to Remove the Cable Track*.
- 4 Raise the primary boom to a horizontal position.
- 5 Remove the hose and cable cover from the upper pivot.

Primary Boom Components

- 6 Remove the pin retaining fastener from the master cylinder barrel-end pivot pin. Use a soft metal drift to remove the pin. Then lower the cylinder and let it hang down.

NOTICE

Component damage hazard. When lowering the master cylinder down, be sure not to damage the master cylinder hoses or fittings.

- 7 Locate the primary boom drive speed limit switch inside of the upper pivot.
- 8 Remove the primary boom drive speed limit switch mounting fasteners. Do not disconnect the wiring.
- 9 Locate the primary extension boom drive speed limit switch inside of the extension boom.
- 10 Remove the primary extension boom drive speed limit switch mounting fasteners. Do not disconnect the wiring.
- 11 Pull the limit switch and the wiring out of the extension tube and move it out of the way.
- 12 Tag, disconnect and plug the primary boom extension cylinder hydraulic hoses. Cap the fittings on the cylinder.

WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 13 Remove the hose clamp at the pivot end of the boom.

- 14 Attach a 5 ton / 5,000 kg overhead crane to the center point of the primary boom.
- 15 Attach a similar lifting device to the primary boom lift cylinder.
- 16 Place support blocks under the primary boom lift cylinder.
- 17 Remove the pin retaining fasteners from the primary boom lift cylinder rod-end pivot pin. Use a soft metal drift to remove the pin.

WARNING

Crushing hazard. The boom lift cylinder and primary boom will fall if not properly supported.

- 18 Lower the rod end of the primary boom lift cylinder onto support blocks. Protect the cylinder rod from damage.
- 19 Remove the pin retaining fasteners from the primary boom pivot pin.
- 20 Remove the primary boom pivot pin with a soft metal drift, then carefully remove the primary boom from the machine and place it on a structure capable of supporting it.

WARNING

Crushing hazard. The primary boom could become unbalanced and fall when removed from the machine if not properly attached to the overhead crane.

Primary Boom Components

How to Disassemble the Primary Boom

Complete disassembly of the boom is only necessary if the outer or inner boom tube must be replaced. The extension cylinder can be removed without completely disassembling the boom. Refer to Repair Procedure, *How to Remove the Primary Boom Extension Cylinder*.

- 1 Remove the primary boom. Refer to Repair Procedure, *How to Remove the Primary Boom*.
- 2 Place blocks under the barrel end of the primary boom extension cylinder for support.
- 3 Remove the pin retaining fastener from the extension cylinder barrel-end pivot pin at the pivot end of the primary boom. Use a soft metal drift to remove the pin.
- 4 Remove and label the location of the wear pads from the platform end of the primary boom.

Note: Pay careful attention to the location and amount of shims used with each wear pad.

- 5 Support and slide the extension tube and extension cylinder assembly out of the boom tube.

⚠ WARNING

Crushing hazard. The primary boom extension tube could become unbalanced and fall when removed from the primary boom tube if not properly supported.

Note: During removal, the overhead crane strap will need to be carefully adjusted for proper balancing.

- 6 Remove the external snap rings from the extension cylinder rod-end pivot pins at the platform end of the extension tube. Use a soft metal drift to remove the pins.
- 7 Support and slide the extension cylinder out of the base end of the extension tube. Place the extension cylinder on blocks for support.

⚠ WARNING

Crushing hazard. The extension cylinder could become unbalanced and fall when removed from primary boom extension tube if not properly supported.

Note: During removal, the overhead crane strap will need to be carefully adjusted for proper balancing.

Primary Boom Components

4-3

Primary Boom Lift Cylinder

The primary boom lift cylinder raises and lowers the primary boom. The primary boom lift cylinder is equipped with a counterbalance valve to prevent movement in the event of a hydraulic line failure.

How to Remove the Primary Boom Lift Cylinder

⚠ WARNING Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is strongly recommended.

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or hose end must be replaced. All connections must be torqued to specification during installation. Refer to Specifications, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Raise the primary boom to a horizontal position.
- 2 Raise the secondary boom until the primary boom lift cylinder barrel-end pivot pin is above the turntable covers.
- 3 Attach a 5 ton / 5000 kg overhead crane to the primary boom for support.
- 4 Raise the primary boom with the overhead crane slightly to take the pressure off the primary boom lift cylinder pivot pins.
- 5 Support the rod end and the barrel end of the primary boom lift cylinder with a second overhead crane or similar lifting device.

- 6 Tag, disconnect and plug the primary boom lift cylinder hydraulic hoses. Cap the fittings on the cylinder.

⚠ WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 7 Remove the pin retaining fasteners from the primary boom lift cylinder rod-end pivot pin. Use a soft metal drift to remove the pin.

⚠ WARNING Crushing hazard. The primary boom will fall if not properly supported when the primary boom rod-end pivot pin is removed.

- 8 Place a support block across both turntable covers under the primary boom lift cylinder.
- 9 Lower the rod end of the lift cylinder onto the block. Protect the cylinder rod from damage.

⚠ WARNING Crushing hazard. The primary boom lift cylinder could become unbalanced and fall if not properly supported by the lifting device.

- 10 Remove the primary boom lift cylinder barrel-end pivot pin retaining fasteners. Do not remove the pin.
- 11 Use a slide hammer to remove the barrel-end pivot pin. Carefully remove the primary boom lift cylinder from the machine.

⚠ WARNING Crushing hazard. The lift cylinder could become unbalanced and fall if not properly supported and secured to the lifting device.

Primary Boom Components

4-4 Primary Boom Extension Cylinder

The primary boom extension cylinder extends and retracts the primary boom extension tube. The primary boom extension cylinder is equipped with counterbalance valves to prevent movement in the event of a hydraulic line failure.

How to Remove the Primary Boom Extension Cylinder

⚠ WARNING Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is strongly recommended.

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or hose end must be replaced. All connections must be torqued to specification during installation. Refer to Specifications, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Raise the primary boom to a horizontal position.
- 2 Extend the primary boom until the primary boom extension cylinder rod-end pivot pin is accessible in the primary boom extension tube.
- 3 Remove the hose and cable guard from the upper pivot.

- 4 Tag, disconnect and plug the primary boom extension cylinder hydraulic hoses. Cap the fittings on the cylinder.

⚠ WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 5 At the platform end of the boom, remove the external snap rings from the extension cylinder rod-end pivot pins. Use a soft metal drift to remove the pins.
- 6 Remove the barrel-end pivot pin retaining fasteners.
- 7 Place a rod through the barrel-end pivot pin and twist to remove the pin.
- 8 Support and slide the extension cylinder out of the upper pivot.

⚠ WARNING Crushing hazard. The extension cylinder could fall when removed from the extension boom if not properly supported.

NOTICE Component damage hazard. Be careful not to damage the counterbalance valves on the primary boom extension cylinder when removing the cylinder from the primary boom.

NOTICE Component damage hazard. Hoses and cables can be damaged if the primary boom extension cylinder is dragged across them.

Note: Note the length of the cylinder after removal. The cylinder must be at the same length for installation.

Primary Boom Components

4-5 Platform Leveling Master Cylinder

The master cylinder acts as a pump for the slave cylinder. It's part of the closed circuit hydraulic loop that keeps the platform level through the entire range of boom motion. The master cylinder is located at the base of the primary boom.

How to Remove the Platform Leveling Master Cylinder

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or hose end must be replaced. All connections must be torqued to specification during installation. Refer to Specifications, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Raise the primary and secondary booms until both the rod-end and barrel-end pivot pins on the master cylinder are accessible.
- 2 Tag, disconnect and plug the master cylinder hydraulic hoses. Cap the fittings on the cylinder.

⚠ WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.


- 3 Attach overhead crane or similar lifting device to the master cylinder.

- 4 Remove the pin retaining fasteners from the master cylinder barrel-end pivot pin.
- 5 Place a rod through the barrel-end pivot pin and twist to remove the pin.
- 6 Remove the pin retaining fastener from the rod-end pivot pin.
- 7 Place a rod through the rod-end pivot pin and twist to remove the pin.
- 8 Remove the master cylinder from the machine.

⚠ WARNING

Crushing hazard. The master cylinder could become unbalanced and fall if not properly attached to the overhead crane.

Secondary Boom Components



Secondary Boom components

- | | |
|---------------------------------------|---------------------------------------|
| 1 upper secondary boom (number 1 arm) | 5 compression link |
| 2 upper tension link (number 2 arm) | 6 secondary boom lift cylinder (2) |
| 3 lower tension link (number 3 arm) | 7 lower secondary boom (number 4 arm) |
| 4 mid-pivot | 8 upper pivot |

Secondary Boom Components

5-1 Secondary Boom

How to Disassemble the Secondary Boom

⚠ WARNING Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is strongly recommended.

Follow the disassembly steps to the point required to complete the repair. Then re-assemble the secondary boom by following the disassembly steps in reverse order.

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or hose end must be replaced. All connections must be torqued to specification during installation. Refer to Specifications, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Remove the platform.
- 2 Remove the jib boom. Refer to Repair Procedure, *How to Remove the Jib Boom*.
- 3 Remove the primary boom. Refer to Repair Procedure, *How to Remove the Primary Boom*.
- 4 Remove the master cylinder. Refer to Repair Procedure, *How to Remove the Master Cylinder*.
- 5 Attach a lifting strap from an overhead crane to the lug on the rod end of the primary boom lift cylinder. Then raise the primary boom lift cylinder with the crane, to a vertical position.

- 6 Tag, disconnect and plug the hydraulic hoses at the primary boom lift cylinder. Cap the fittings on the cylinder.

⚠ WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 7 Remove the pin retaining fastener from the primary boom lift cylinder barrel-end pivot pin.
- 8 Use a slide hammer to remove the pin. Remove the primary boom lift cylinder from the machine.

⚠ WARNING Crushing hazard. The primary boom lift cylinder could become unbalanced and fall if not properly supported by the lifting device.

- 9 Tag, disconnect and plug the hydraulic hoses on both of the secondary boom lift cylinders. Cap the fittings on the cylinders.

⚠ WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 10 Remove the pin retaining fasteners from both sides of the secondary boom lift cylinder rod-end pivot pin and barrel-end pivot pin. Do not remove the pins.

Secondary Boom Components

- 11 Attach a strap from an overhead crane to the lug on the rod end of one of the secondary boom lift cylinders for support. Do not apply any lifting pressure.
- 12 Use a soft metal drift to drive the barrel-end pivot pin half way out. Lower the barrel end of the secondary boom lift cylinder and let it hang down.
- 13 Use a soft metal drift to drive the rod-end pivot pin half way out.
- 14 Remove the secondary boom lift cylinder from the machine.
- 15 Repeat steps 11 through 14 for the other secondary boom lift cylinder.

⚠ WARNING Crushing hazard. The secondary boom lift cylinder could become unbalanced and fall when removed from the machine if not properly attached to the overhead crane.

NOTICE Component damage hazard. When removing a secondary boom lift cylinder from the machine, be careful not to damage the counterbalance valve at the barrel end of the cylinder.

- 16 Attach a lifting strap from an overhead crane to the upper pivot for support. Do not lift it.
- 17 Attach a lifting strap from a second overhead crane to the number 1 arm at the mid-point between the upper pivot and mid-pivot.
- 18 Remove the pin retaining fasteners from the number 1 arm pivot pins at the mid-pivot and the upper pivot. Do not remove the pins.
- 19 Use a soft metal drift to drive both pins out.

- 20 Remove the number 1 arm from the machine.

⚠ WARNING Crushing hazard. The number 1 arm could become unbalanced and fall when removed from the machine if not properly attached to the overhead crane.

⚠ WARNING Crushing hazard. The upper pivot could fall when the number 1 arm is removed from the machine if not properly supported by the overhead crane.

- 21 Using the overhead crane attached to the upper pivot, raise the secondary boom assembly approximately 30 inches / 76 cm.
- 22 Insert a 4 x 4 x 11 inch / 10 x 10 x 28 cm block between the number 2 arm and the boom rest. Then lower the secondary boom assembly onto the block.

⚠ WARNING Crushing hazard. The secondary boom assembly could fall if not properly supported by the 4 x 4 x 11 inch / 10 x 10 x 28 cm block.

- 23 Pull all of the cables and hoses out through the upper pivot.

NOTICE Component damage hazard. Cables and hoses can be damaged if they are kinked or pinched.

- 24 Remove the hose and cable covers from the top of the number 2 arm.
- 25 Pull all of the hoses and cables out of the upper pivot and out through the mid-pivot. Lay the hoses and cables on the ground.

NOTICE Component damage hazard. Cables and hoses can be damaged if they are kinked or pinched.

- 26 Remove the pin retaining fastener from the number 2 arm pivot pin at the upper pivot. Use a soft metal drift to remove the pin.

Secondary Boom Components

- 27 Remove the upper pivot from the machine.

⚠ WARNING

Crushing hazard. The upper pivot could become unbalanced and fall when removed from the machine if not properly attached to the overhead crane.

- 28 Attach the lifting strap from an overhead crane to the number 2 arm at the upper pivot end.

- 29 Raise the number 2 arm slightly and remove the 4 x 4 x 11 inch / 10 x 10 x 28 cm block.

- 30 Lower the number 2 arm onto the boom rest pad.

- 31 Insert a 4 x 4 x 8 1/2 inch / 10 x 10 x 22 cm block between the number 3 arm and the number 4 arm at the mid-pivot end.

- 32 Attach a lifting strap from the overhead crane to the mid-pivot for support. Do not lift it.

- 33 Remove the pin retaining fasteners from the number 2, 3 and 4 arm pivot pins at the mid-pivot. Do not remove the pins.

- 34 Use a soft metal drift to drive each pin out. Then remove the mid-pivot from the secondary boom assembly.

⚠ WARNING

Crushing hazard. The mid-pivot could become unbalanced and fall when removed from the secondary boom assembly if not properly supported by the overhead crane.

- 35 Attach the lifting strap from an overhead crane to the center point of the number 2 arm for support. Do not lift it.

- 36 Remove the pin retaining fasteners from both compression link pivot pins. Do not remove the pins.

- 37 Use a soft metal drift to remove the lower compression link pivot pin at the number 3 arm.

- 38 Support the compression link with an appropriate lifting device.

- 39 Use a soft metal drift to remove the upper compression link pivot pin from the number 2 arm. Remove the compression link from the machine.

⚠ WARNING

Crushing hazard. The number 2 arm could fall when the compression link is disconnected from the number 2 arm if not properly supported by the overhead crane.

⚠ WARNING

Crushing hazard. The compression link may fall if not properly supported when removed from the secondary boom assembly.

- 40 Remove the number 2 arm from the machine.

⚠ WARNING

Crushing hazard. The number 2 arm could become unbalanced and fall when removed from the secondary boom assembly if not properly supported by the overhead crane.

- 41 Remove the upper and lower hose and cable covers from the number 3 arm.

- 42 Pull all of the cables and hoses from the number 3 arm and lay them over the turntable counterweight.

NOTICE

Component damage hazard. Cables and hoses can be damaged if they are kinked or pinched.

- 43 Open the ground controls side turntable cover.

- 44 Remove the fuel tank filler cap.

Secondary Boom Components

- 45 Using an approved hand-operated pump, drain the fuel tank into a container of suitable capacity. Refer to Specifications, *Machine Specifications*.

⚠ DANGER

Explosion and fire hazard. Engine fuels are combustible. Perform this procedure in an open, well-ventilated area away from heaters, sparks, flames and lighted tobacco. Always have an approved fire extinguisher within easy reach.

⚠ DANGER

Explosion and fire hazard. When transferring fuel, connect a grounding wire between the machine and pump or container.

Note: Be sure to only use a hand-operated pump suitable for use with gasoline and diesel fuel.

- 46 Tag, disconnect and plug the fuel hoses from the fuel tank. Clean up any fuel that may have spilled.
- 47 Remove the fuel tank mounting fasteners. Carefully remove the fuel tank from the machine.

NOTICE

Component damage hazard. The fuel tank is plastic and may become damaged if allowed to fall.

Note: Clean the fuel tank and inspect for cracks and other damage before installing it onto the machine.

- 48 Remove the retaining fastener from the ground control box and function manifold pivot plate.
- 49 Lower the ground control box and function manifold pivot plate to access the number 3 arm pivot pin.
- 50 Attach the lifting strap from the overhead crane to the center point of the number 3 arm for support. Do not lift it.

- 51 Remove the mounting fasteners from the cover located in the boom storage area to access the number 3 and number 4 arm pivot pin retaining fasteners at the turntable riser.

- 52 Remove the pin retaining fasteners from the number 3 arm at the turntable riser. Do not remove the pin.

- 53 Use a slide hammer to remove the number 3 arm pivot pin from the turntable pivot through the access hole behind the ground control box.

- 54 Remove the number 3 arm from the machine.

⚠ WARNING

Crushing hazard. The number 3 arm could become unbalanced and fall when removed from the machine if not properly supported by the overhead crane.

- 55 Remove the upper and lower hose and cable covers from the number 3 arm.

- 56 Remove the secondary boom drive speed limit switch mounting fasteners from the number 4 arm at the mid-pivot end. Do not disconnect the wiring.

- 57 Remove the pin retaining fasteners from the number 4 arm at the turntable riser. Do not remove the pin.

- 58 Attach a lifting strap from the overhead crane to the center point of the number 4 arm. Do not lift it.

- 59 Use a slide hammer to remove the number 4 arm from the turntable riser through the ground controls side bulkhead.

- 60 Remove the number 4 arm from the machine.

⚠ WARNING

Crushing hazard. The number 4 arm could become unbalanced and fall when removed from the machine if not properly supported by the overhead crane.

Secondary Boom Components

5-2

Secondary Boom Lift Cylinder

There are two secondary boom lift cylinders incorporated in the structure of the secondary boom assembly. These cylinders operate in parallel and require hydraulic pressure to extend and retract. Each secondary boom lift cylinder is equipped with a counterbalance valve to prevent movement in the event of a hydraulic line failure.

How to Remove the Secondary Boom Lift Cylinder

⚠ WARNING Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is strongly recommended.

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or hose end must be replaced. All connections must be torqued to specification during installation. Refer to Specifications, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Lower the secondary boom to the stowed position.
- 2 Raise the primary boom so that it is above the secondary boom lift cylinder rod-end pivot pin.

- 3 Tag, disconnect and plug the hydraulic hoses on the secondary boom lift cylinder.

⚠ WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 4 Remove the pin retaining fasteners from the secondary boom lift cylinder rod-end pivot pin and barrel-end pivot pin. Do not remove the pins.
- 5 Attach a strap from an overhead crane to the lug on the rod end of the secondary boom lift cylinder for support. Do not apply any lifting pressure.
- 6 Use a soft metal drift to drive the barrel-end pivot pin half way out. Lower the barrel end of the secondary boom lift cylinder and let it hang down.
- 7 Use a soft metal drift to drive the rod-end pivot pin half way out.
- 8 Remove the secondary boom lift cylinder from the machine.

⚠ WARNING Crushing hazard. The secondary boom lift cylinder could become unbalanced and fall when removed from the machine if not properly attached to the overhead crane.

NOTICE Component damage hazard. When removing a secondary boom lift cylinder from the machine, be careful not to damage the counterbalance valve at the barrel end of the cylinder.

Engines

6-1 RPM Adjustment - Deutz D2011L03i Models

Refer to Maintenance Procedure in the appropriate Service or Maintenance Manual for your machine, *Check and Adjust the Engine RPM.*

6-2 RPM Adjustment - Perkins 404D- 22 Models

Refer to Maintenance Procedure in the appropriate Service or Maintenance Manual for your machine, *Check and Adjust the Engine RPM.*

6-3 Flex Plate

The flex plate acts as a coupler between the engine and the pump. It is bolted to the engine flywheel and has a splined center to drive the pump.

How to Remove the Flex Plate

Perkins models:

- 1 Disconnect the battery cables from the battery.

⚠ WARNING

Electrocution/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

- 2 Disconnect the electrical connectors at the electrical proportional controller, located on the drive pump.
- 3 Remove the engine starter mounting fasteners. Remove the starter from the engine. Do not disconnect the wiring.
- 4 Support the drive pump with an appropriate lifting device. Then remove all of the bell housing to engine mounting bolts. Leave the pump connected to the bell housing.
- 5 Carefully pull the pump and bell housing away from the engine and secure it from moving.

NOTICE

Component damage hazard. Hoses can be damaged if they are kinked or pinched.

- 6 Remove the flex plate mounting fasteners, then remove the flex plate from the engine flywheel.

Engines

Ford models:

- 1 Disconnect the battery cables from the battery.
- ⚠ WARNING** Electrocutation/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.
- 2 Disconnect the electrical connectors at the electrical proportional controller, located on the drive pump.
- 3 Support the drive pump assembly with an overhead crane or other suitable lifting device. Do not apply any lifting pressure.
- 4 Remove the drive pump retaining fasteners.
- 5 Carefully pull the drive pump out until the pump coupler separates from the flex plate.

- NOTICE** Component damage hazard. Hoses can be damaged if they are kinked or pinched.
- 6 Disconnect the electrical connector from the oxygen sensor at the tailpipe. Do not remove the oxygen sensor.
- 7 Support the muffler and bracket assembly with a suitable lifting device.
- 8 Remove the exhaust pipe fasteners at the muffler.
- 9 Remove the muffler bracket mounting fasteners from the bell housing. Carefully remove the muffler and bracket assembly from the engine.

- 10 Support the engine with an overhead crane or other suitable lifting device. Do not lift it.
- 11 Remove the engine mounting plate to bell housing fasteners.
- 12 Raise the engine slightly using the overhead crane and place a block of wood under the oil pan for support.
- 13 Remove all of the engine bell housing retaining fasteners.
- 14 Carefully remove the bell housing from the engine.
- 15 Remove the flex plate mounting fasteners. Remove the flex plate from the flywheel.

Engines


How to Install the Flex Plate

- 1 Install the flex plate onto the engine flywheel with the rubber vibration isolators towards the pump.
- 2 Apply Loctite® removable thread sealant to the flex plate fasteners and loosely install the fasteners.
- 3 **Deutz models:** Torque the flex plate mounting bolts in sequence to 28 ft-lbs / 38 Nm. Then torque the flex plate mounting bolts in sequence to 40 ft-lbs / 54 Nm.


Ford and Perkins models: Torque the flex plate mounting bolts in sequence to 14 ft-lbs / 19 Nm. Then torque the flex plate mounting bolts in sequence to 20 ft-lbs / 27 Nm.
- 4 Apply a high viscosity coupling grease (Genie part number 128025) to the splines of the pump shaft and flex plate.

Grease Specification


Shell Alvania® Grease CG, NLGI 0/1 or equivalent.



Ford Models



Deutz Models



Perkins Models

Engines

How to Install the Pump and Bell Housing Assembly

- 1 Install the pump and bell housing assembly.

Deutz models: Torque the bell housing mounting bolts labeled "C" in sequence to 28 ft-lbs / 38 Nm. Then torque the bell housing mounting bolts labeled "C" in sequence to 40 ft-lbs / 54 Nm.

Ford models: Torque the bell housing mounting bolts labeled "A" and "B" in sequence to 28 ft-lbs / 38 Nm and the mounting bolts labeled "C" to 49 ft-lbs / 66 Nm. Then torque the bell housing mounting bolts labeled "A" and "B" in sequence to 40 ft-lbs / 54 Nm and the mounting bolts labeled "C" to 70 ft-lbs / 95 Nm.


Perkins models: Torque the bell housing mounting bolts labeled "B" in sequence to 28 ft-lbs / 38 Nm and the mounting bolts labeled "A" to 49 ft-lbs / 66 Nm. Then torque the bell housing mounting bolts labeled "B" in sequence to 40 ft-lbs / 54 Nm and the mounting bolts labeled "A" to 70 ft-lbs / 95 Nm.

NOTICE


Component damage hazard. When installing the pump, do not force the pump coupler into the flexplate or damage to the pump shaft seal may occur.

NOTICE


Component damage hazard. Do not force the drive pump during installation or the flex plate teeth may become damaged.



Ford Models



Deutz Models D2011L03i



Deutz Models D 2.9 L4, TD 2.2 L3


Engines

6-4


Engine Fault Codes

The ECM constantly monitors the engine by the use of sensors on the engine. The ECM also uses signals from the sensors to initiate sequential fuel injection and make constant and instantaneous changes to ignition timing, fuel delivery and throttle position to maintain the engine's running condition at its highest efficiency while at the same time keeping exhaust emissions to a minimum. When a sensor fails or returns signals that are outside of set parameters, the ECM will store a fault code in memory that relates to the appropriate sensor.

Refer to Fault Codes Section. Use the Fault Code Charts to aid in identifying the fault.



Perkins Models 404D-22



Perkins Models 404F-E22T

Engines

6-5

Diesel Particle Filter

Regeneration - Deutz TD 2.2 L3 Engine

The combustion of diesel fuel results in soot, which is separated in the diesel particle filter (DPF). This must be regenerated as the contamination with soot increases. There are 3 types of regeneration.

Passive regeneration:

Under normal operating conditions when the exhaust temperature is $>482^{\circ}\text{F}$ / 250°C the particle filter contamination with soot remains in a permissible range. This process is automatically activated by the engine control unit, the operator does not need to perform any actions.

Standstill regeneration:

If passive regeneration does not attain an adequate reduction of the soot contamination, the particle filter will continue to become contaminated with soot and a standstill regeneration will be required by the operator.

To perform standstill regeneration, refer to the Operator's Manual on your machine.

Service regeneration:

If a fault occurs, the system reacts by reducing the engine performance. This can include limited machine functions, torque reduction, reduced engine rpm and replacement of the DPF.

If standstill regeneration is prohibited by the operator. Service regeneration must be performed by a trained technician with the use of the DEUTZ SerDia software tool and DeCom interface cable. Available from Deutz.

If service regeneration is not performed, replacement of the DPF will be required.

Hydraulic Pumps

7-1 Lift/Steer Pump


How to Remove the Lift/Steer Pump

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or hose end must be replaced. All connections must be torqued to specification during installation. Refer to Specifications, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Locate the two hydraulic tank valves at the hydraulic tank through the access hole underneath the turntable. Close the valves.

NOTICE

Component damage hazard. The engine must not be started with the hydraulic tank shut-off valves in the closed position or component damage will occur. If the tank valves are closed, remove the key from the key switch and tag the machine to inform personnel of the condition.



- 2 Tag, disconnect and plug the lift/steer pump hydraulic hoses. Cap the fittings on the pump.

WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 3 Remove the pump mounting bolts. Carefully remove the pump.

NOTICE

Component damage hazard. Be sure to open the two hydraulic tank valves and prime the pump after installing the pump.

Hydraulic Pumps

7-2 Drive Pump

The drive pump is a bi-directional variable displacement piston pump. The pump output is controlled by the electro-proportional controller, located on the pump. The only adjustment that can be made to the pump is the neutral or null adjustment. Any internal service to the pump should only be performed at an authorized Eaton Hydraulics center. Call Genie Service Department to locate your local authorized service center.

How to Remove the Drive Pump

NOTICE Component damage hazard. The work area and surfaces where this procedure will be performed must be clean and free of debris that could get into the hydraulic system and cause severe component damage. Dealer service is recommended.


Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or hose end must be replaced. All connections must be torqued to specification during installation. Refer to Specifications, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Disconnect the electrical connectors at the electrical proportional controller located on the drive pump.

- 2 Locate the two hydraulic tank valves at the hydraulic tank through the access hole underneath the turntable. Close the valves.

NOTICE

Component damage hazard. The engine must not be started with the hydraulic tank shut-off valves in the closed position or component damage will occur. If the tank valves are closed, remove the key from the key switch and tag the machine to inform personnel of the condition.



- 3 Tag and disconnect and plug the hydraulic hoses from the drive and lift/steer pumps. Cap the fittings on the pumps.

WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 4 Support the pump with a lifting device and remove the two drive pump mounting fasteners.

Hydraulic Pumps

- 5 Carefully pull the drive pump out until the pump coupler separates from the flex plate.
- 6 Remove the drive pump from the machine.

NOTICE Component damage hazard. The pump(s) may become unbalanced and fall if not properly supported.

NOTICE Component damage hazard. When installing the pump, do not force the pump coupler into the flexplate or damage to the pump shaft seal may occur.


NOTICE Component damage hazard. Be sure to open the two hydraulic tank valves and prime the pump after installing the pump.

How to Prime the Pump

- 1 Connect a 0 to 600 psi / 0 to 41 bar pressure gauge to the test port on the drive pump.
- 2 Remove the safety pin from the engine pivot plate latch.

Note: The engine pivot plate latch is located under the engine turntable pivot plate at the counterweight end of the machine.

- 3 Open the engine pivot plate latch and swing the engine pivot plate out and away from the machine.
- 4 Hold the manual fuel shutoff valve clockwise to the closed position.



1 manual fuel shutoff valve

- 5 Have another person crank the engine with the starter motor for 15 seconds, wait 15 seconds, then crank the engine an additional 15 seconds or until the pressure reaches 320 psi / 22 bar.
- 6 Release the manual fuel shutoff valve.
- 7 Start the engine from the ground controls and check for hydraulic leaks.


Manifolds

8-1 Function Manifold Components - CE (to Z4525XCM-1500)

The function manifold is located next to the hydraulic tank underneath the ground controls side cover.

| Index No. | Description | Schematic Item | Function | Torque |
|------------------|---|-----------------------|---|-------------------------|
| 1 | Solenoid valve, 3 position 4 way | BM | Platform level up/down | 25 ft-lbs / 34 Nm |
| 2 | Solenoid valve, 3 position 4 way | CG | Platform rotate left/right and jib boom up/down | 25 ft-lbs / 34 Nm |
| 3 | Flow regulator valve, 2 gpm / 7.6 L/min | BZ | Boom extend/retract circuit | 20 ft-lbs / 27 Nm |
| 4 | Solenoid valve, 2 position 3 way | CA | Primary boom extend | 20 ft-lbs / 27 Nm |
| 5 | Proportional directional solenoid valve, 3 position 4 way | BY | Primary boom up/down | 16-20 ft-lbs / 22-27 Nm |
| 6 | Differential sensing valve 160 psi / 11 bar | BG | Meters flow to functions | 25 ft-lbs / 34 Nm |
| 7 | Proportional directional solenoid valve, 3 position 4 way | BP | Turntable rotate left/right | 16-20 ft-lbs / 22-27 Nm |
| 8 | Proportional directional solenoid valve, 3 position 4 way | BU | Secondary boom up/down | 16-20 ft-lbs / 22-27 Nm |
| 9 | Solenoid valve, 3 position 4 way | BF | Steer left/right | 25 ft-lbs / 34 Nm |
| 10 | Relief valve, 2100 psi / 145 bar | BV | Secondary boom down | 20 ft-lbs / 27 Nm |
| 11 | Orifice, 0.046 inch / 1.17 mm | CF | Secondary boom down circuit | |
| 12 | Check valve, 5 psi / 0.3 bar | BT | Differential sensing circuit, secondary boom down | 12-14 ft-lbs / 16-19 Nm |
| 13 | Check valve, 5 psi / 0.3 bar | BW | Secondary boom circuit | 25 ft-lbs / 34 Nm |
| 14 | Check valve, 5 psi / 0.3 bar | BS | Differential sensing circuit, secondary boom up | 12-14 ft-lbs / 16-19 Nm |
| 15 | Priority flow regulator valve, 2.0 gpm / 7.6 L/min | BB | Steer circuit | 25 ft-lbs / 34 Nm |
| 16 | Relief valve, 3200 psi / 221 bar | BA | System relief | 20 ft-lbs / 27 Nm |
| 17 | Shuttle valve | BO | Turntable rotate circuit | 12-14 ft-lbs / 16-19 Nm |

Manifolds




Manifolds

Function Manifold Components - CE, continued

| Index No. | Description | Schematic Item | Function | Torque |
|-----------|---|----------------|---|-------------------------|
| 18 | Check valve, 5 psi / 0.3 bar | BQ | Differential sensing circuit, turntable rotate | 12-14 ft-lbs / 16-19 Nm |
| 19 | Check valve, 5 psi / 0.3 bar | CB | Differential sensing circuit, primary boom retract | 12-14 ft-lbs / 16-19 Nm |
| 20 | Check valve, 5 psi / 0.3 bar | BC | Differential sensing circuit, platform rotate left and jib boom up | 25 ft-lbs / 34 Nm |
| 21 | Check valve, 5 psi / 0.3 bar | BD | Differential sensing circuit, platform rotate right and jib boom down | 25 ft-lbs / 34 Nm |
| 22 | Flow regulator valve, 0.1 gpm / 0.38 L/min | BX | Primary boom load sense circuit | 20 ft-lbs / 27 Nm |
| 23 | Counterbalance valve, 3000 psi / 207 bar | CD | Primary boom down circuit | 30-35 ft-lbs / 45-50 Nm |
| 24 | Pressure compensator valve, 80 psi / 5.5 bar | BR | Turntable rotate circuit | 25 ft-lbs / 34 Nm |
| 25 | Shuttle valve | CE | Differential sensing circuit, primary boom up/down | 12-14 ft-lbs / 16-19 Nm |
| 26 | Flow regulator valve, 0.8 gpm / 3 L/min | BE | Jib boom and platform rotate circuit | 20 ft-lbs / 27 Nm |
| 27 | Needle valve | BN | Platform level flow control | 20 ft-lbs / 27 Nm |
| 28 | Relief valve, 3000 psi / 207 bar | BH | Platform level circuit | 20 ft-lbs / 27 Nm |
| 29 | Check valve, 5 psi / 0.3 bar | BK | Differential sensing circuit, platform level up | 12-14 ft-lbs / 16-19 Nm |
| 30 | Check valve, 5 psi / 0.3 bar | BL | Differential sensing circuit, platform level down | 12-14 ft-lbs / 16-19 Nm |
| 31 | Solenoid valve, 2 position 3 way | CC | Primary boom retract | 20 ft-lbs / 27 Nm |
| 32 | Shuttle valve | BI | Platform level circuit | 12-14 ft-lbs / 16-19 Nm |
| 33 | Check valve, dual pilot operated, 135 psi / 9.3 bar | BJ | Platform level circuit | 20 ft-lbs / 27 Nm |

Manifolds




Manifolds

8-1.1 Function Manifold Components - ANSI / CSA / CE (from Z4525XCF-101, Z4525XCM-1501)

The function manifold is located next to the hydraulic tank underneath the ground controls side cover.

| Index No. | Description | Schematic Item | Function | Torque |
|-----------|--|----------------|---|-------------------------|
| 1 | VALVE, CHECK, #4 SAE, 5 PSI* | BD | Differential sensing circuit, platform rotate right and jib boom down | 25 ft-lbs / 34 Nm |
| 2 | VALVE, CHECK, #4 SAE, 5 PSI* | BC | Differential sensing circuit, platform rotate left and jib boom up | 25 ft-lbs / 34 Nm |
| 3 | VALVE, CHECK, #4 SAE, 5 PSI* | BQ | Differential sensing circuit, turntable rotate | 12-14 ft lbs / 16-19 Nm |
| 4 | VALVE, SHUTTLE | BO | Turntable rotate circuit | 12-14 ft lbs / 16-19 Nm |
| 5 | VALVE, CHECK, CV10-20-0-N-05 | BW | Secondary boom circuit | 25 ft-lbs / 34 Nm |
| 6 | VALVE, CHECK, #4 SAE, 5 PSI* | CB | Differential sensing circuit, primary boom retract | 12-14 ft lbs / 16-19 Nm |
| 7 | VALVE, RELIEF, RV08-22H-0-N-26/21 | BV | Secondary boom down | 20 ft-lbs / 27 Nm |
| 8 | VALVE, SOLENOID, 2POS 3 WAY*** | CA | Primary boom extend | 20 ft-lbs / 27 Nm |
| 9 | VALVE, PROPORTIONAL 3 POS 4 WY | BY | Primary boom up/down | 16-20 ft lbs / 22-27 Nm |
| 10 | VALVE, SPOOL, 4 WAY, 3 POSITION | BP | Turntable rotate left/right | 16-20 ft lbs / 22-27 Nm |
| 11 | VALVE, SPOOL, 4 WAY, 3 POSITION | BU | Secondary boom up/down | 16-20 ft lbs / 22-27 Nm |
| 12 | VALVE, DIRECTIONAL, P-COMP | BG | Meters flow to functions | 25 ft-lbs / 34 Nm |
| 13 | VALVE, 4-WAY, TANDEM CENTER, SV08-47A-0-N-00 | BF | Steer left/right | 25 ft-lbs / 34 Nm |
| 14 | VALVE, SOLENOID, 2POS 2WAY N.O.* | CH | Main function enable | 19-21 ft-lbs / 26-29 Nm |
| 15 | VALVE, PRESSURE COMPENSATOR, EC08-32-0-N-80 | BR | Turntable rotate circuit | 25 ft-lbs / 34 Nm |
| 16 | VALVE, CHECK, #4 SAE, 5 PSI* | BT | Differential sensing circuit, secondary boom down | 12-14 ft lbs / 16-19 Nm |
| 17 | VALVE, CHECK, #4 SAE, 5 PSI* | BS | Differential sensing circuit, secondary boom up | 12-14 ft-lbs / 16-19 Nm |

Manifolds




Manifolds

Function Manifold Components - ANSI / CSA / CE, continued

| Index No. | Description | Schematic Item | Function | Torque |
|-----------|---|----------------|--|-------------------------|
| 18 | VALVE, FLOW REGULATOR, FR10-30F-0-N-2.00 | BB | Steer circuit | 25 ft-lbs / 34 Nm |
| 19 | VALVE, RELIEF, RV08-22H-0-N-26/32 | BA | System relief | 20 ft-lbs / 27 Nm |
| 20 | VALVE, CHECK, -8 | BX | Primary boom load sense circuit | 20 ft-lbs / 27 Nm |
| 21 | VALVE, COUNTERBALANCE, CBBC-LHN@1000*** | CI | Primary boom rod side CB valve | 30-35 ft-lbs / 41-47 Nm |
| 22 | VALVE, SHUTTLE | CE | Differential sensing circuit, primary boom up/down | 12-14 ft lbs / 16-19 Nm |
| 23 | VALVE, FLOW REGULATOR, 0.8 GPM FIXED | BE | Jib boom and platform rotate circuit | 20 ft-lbs / 27 Nm |
| 24 | VALVE, FLOW REGULATOR, 2.0 GPM | BZ | Boom extend/retract circuit | 20 ft-lbs / 27 Nm |
| 25 | VALVE, NEEDLE, ADJUSTABLE*** | BN | Platform level flow control | 20 ft-lbs / 27 Nm |
| 26 | VALVE, PRESSURE REDUCER, PR58-38H-0-N-05/05 | CJ | Oscillate circuit pressure reducing valve | 24-26 ft-lbs / 33-35 Nm |
| 27 | VALVE, RELIEF, RV08-22H-0-N-26/35 | BH | Platform level circuit | 20 ft-lbs / 27 Nm |
| 28 | VALVE, PRESSURE CONTROL, PS10-41H-0-N-22/08.5 | CK | Oscillate circuit pressure control valve | 25 ft-lbs / 34 Nm |
| 29 | VALVE, SOLENOID, 2POS 3 WAY*** | CC | Primary boom retract | 20 ft-lbs / 27 Nm |
| 30 | VALVE, 2-WAY, NC, SV08-20-0-N-00 | CL | Primary boom extend enable valve | 19-21 ft-lbs / 26-29 Nm |
| 31 | VALVE, SHUTTLE | BI | Primary boom retract | 12-14 ft lbs / 16-19 Nm |
| 32 | VALVE, PO CHECK, DC08-40-0-N-135 | BJ | Platform level circuit | 20 ft-lbs / 27 Nm |
| 33 | VALVE, SOLENOID, 3POS 4WAY*** | CG | Platform rotate left/right and jib boom up/down | 25 ft-lbs / 34 Nm |
| 34 | VALVE, SOLENOID, 3POS 4WAY*** | BM | Platform level up/down | 25 ft-lbs / 34 Nm |
| 35 | VALVE, CHECK, 5 PSI* | BL | Differential sensing circuit, platform level down | 12-14 ft lbs / 16-19 Nm |
| 36 | VALVE, CHECK, 5 PSI* | BK | Differential sensing circuit, platform level up | 12-14 ft lbs / 16-19 Nm |

Manifolds



Manifolds

8-2 Valve Adjustments - Function Manifold

How to Adjust the System Relief Valve

Note: Perform this procedure with the boom in the stowed position.

Note: Refer to Function Manifold Component list to locate the system relief valve.

- 1 Connect a 0 to 5000 psi / 0 to 350 bar pressure gauge to the test1 port on the function manifold.
- 2 Start the engine from the ground controls.
- 3 Hold the function enable switch to the high rpm position and activate and hold the primary boom retract switch with the boom fully retracted.
- 4 Observe the pressure reading on the pressure gauge. Refer to Specifications, *Hydraulic Specifications*.
- 5 Turn the engine off. Use a wrench to hold the relief valve and remove the cap.
- 6 Adjust the internal hex socket. Turn it clockwise to increase the pressure or counterclockwise to decrease the pressure. Install the relief valve cap.

⚠ WARNING Tip-over hazard. Do not adjust the relief valve higher than specified.

- 7 Repeat steps 2 through 5 and recheck relief valve pressure.
- 8 Remove the pressure gauge.

How to Adjust the Secondary Boom Down Relief Valve

Note: Perform this procedure with the boom in the stowed position.

Note: Refer to Function Manifold Component list to locate the secondary boom down relief valve.

- 1 Connect a 0 to 5000 psi / 0 to 350 bar pressure gauge to the test1 port on the function manifold.
- 2 Start the engine from the ground controls.
- 3 Hold the function enable switch to the high rpm position and activate and hold the secondary boom down switch with the secondary boom fully lowered.
- 4 Observe the pressure reading on the pressure gauge. Refer to Specifications, *Hydraulic Specifications*.
- 5 Turn the engine off. Use a wrench to hold the relief valve and remove the cap.
- 6 Adjust the internal hex socket. Turn it clockwise to increase the pressure or counterclockwise to decrease the pressure. Install the relief valve cap.

⚠ WARNING Tip-over hazard. Do not adjust the relief valve higher than specified.

- 7 Repeat steps 2 through 5 and recheck relief valve pressure.
- 8 Remove the pressure gauge.


Manifolds

8-3

Jib Boom / Platform Rotate Manifold Components

The jib boom / platform rotate manifold is mounted to the platform support.

| Index No. | Description | Schematic Item | Function | Torque |
|-----------|----------------------------------|----------------|---------------------------------|------------------------|
| 1 | Solenoid valve, 2 position 3 way | G | Platform rotate/jib boom select | 8-10 ft-lbs / 11-14 Nm |




Manifolds

8-4

Turntable Rotation Manifold Components

The turntable rotation manifold is mounted to the turntable rotation motor located in the boom storage compartment.

| Index No. | Description | Schematic Item | Function |
|-----------|----------------------|----------------|------------------------|
| 1 | Counterbalance valve | L | Turntable rotate right |
| 2 | Counterbalance valve | J | Turntable rotate left |




Manifolds

8-5 Directional Valve Manifold Components

The directional valve manifold is mounted inside the drive chassis at the non-steer end.

| Index No. | Description | Schematic Item | Function | Torque |
|-----------|-------------|----------------|---------------------|-------------------------|
| 1 | Cap | | Breather | 20-25 ft-lbs / 27-33 Nm |
| 2 | Spool valve | CH | Directional control | |



Manifolds

How to Set Up the Directional Valve Linkage

Note: Adjustment of the oscillate directional valve linkage is only necessary when the linkage or valve has been replaced.

- 1 Lower the boom to the stowed position.
- 2 Use a "bubble type" level to be sure the floor is completely level.

⚠ WARNING

Tip-over hazard. Failure to perform this procedure on a level floor could compromise the stability of the machine resulting in the machine tipping over.

- 3 Check the tire pressure in all four tires and add air if needed to meet specification.

Note: The tires on some machines are foam-filled and do not need air added to them.

- 4 Remove the drive chassis cover and the non-steer axle covers.
- 5 Place a "bubble type" level across the drive chassis non-steer end. Check to be sure the drive chassis is completely level.
- 6 Remove the ball joint retaining fastener from the bracket.
- 7 To level the drive chassis, start the engine and push up or pull down on the threaded rod until the machine is completely level.
- 8 Verify that the ground and drive chassis are completely level.

- 9 Adjust the ball joint until the hole lines up with the retaining fastener hole in the bracket.
- 10 Install the ball joint to the axle and tighten the jam nut.
- 11 Check to be sure the drive chassis is completely level.
- 12 Measure the distance between the drive chassis and the non-steer axle on both sides (from the inside of the drive chassis).

Note: If the distance is not equal and the adjustment to the linkage was completed with the ground and drive chassis level, repeat steps 6 through 11 OR consult Genie Product Support.

This page intentionally left blank.

Manifolds


8-6

Traction Manifold Components, 4WD

The traction manifold is mounted inside the drive chassis at the non-steer end.

| Index No. | Description | Schematic Item | Function | Torque |
|-----------|----------------------------------|----------------|---|-------------------------|
| 1 | Flow divider/combiner valve | AA | Controls flow to flow divider/combiner valves 2 and 4 | 25-30 ft-lbs / 34-41 Nm |
| 2 | Flow divider/combiner valve | AB | Controls flow to non-steer end drive motors in forward and reverse | 25-30 ft-lbs / 34-41 Nm |
| 3 | Orifice, 0.047 in / 1.2 mm | AC | Drive circuit | |
| 4 | Flow divider/combiner valve | AD | Controls flow to steer end drive motors in forward and reverse | 25-30 ft-lbs / 34-41 Nm |
| 5 | Orifice, 0.040 in / 1.02 mm | AE | Drive circuit | |
| 6 | Check valve | AF | Non-steer end drive motor circuit | 10-12 ft-lbs / 14-16 Nm |
| 7 | Solenoid valve, 2 position 3 way | AG | Braking | 10-12 ft-lbs / 14-16 Nm |
| 8 | Relief valve, 250 psi / 17.2 bar | AH | Charge pressure circuit | 10-12 ft-lbs / 14-16 Nm |
| 9 | Solenoid valve, 2 position 3 way | AI | 2-speed motor shift | 10-12 ft-lbs / 14-16 Nm |
| 10 | Check valve | AJ | Steer end drive motor circuit | 10-12 ft-lbs / 14-16 Nm |
| 11 | Check valve | AK | Steer end drive motor circuit | 10-12 ft-lbs / 14-16 Nm |
| 12 | Check valve | AL | Non-steer end drive motor circuit | 10-12 ft-lbs / 14-16 Nm |
| 13 | Check valve | AM | Non-steer end drive motor circuit | 10-12 ft-lbs / 14-16 Nm |
| 14 | Check valve | AN | 2 speed motor shift circuit | 10-12 ft-lbs / 14-16 Nm |
| 15 | Orifice, 0.030 inch / 0.76 mm | AO | Brake circuit | |
| 16 | Check valve | AP | Steer end drive motor circuit | 10-12 ft-lbs / 14-16 Nm |
| 17 | Shuttle valve, 3 position 3 way | AQ | Charge pressure circuit that directs hot oil out of low pressure side of drive pump and allows low pressure flow path for brake release and 2-speed motor shift | 15-18 ft-lbs / 20-24 Nm |
| 18 | Orifice, 0.040 in / 1.01 mm | AR | Drive circuit | |

Manifolds



Manifolds

8-7

Valve Adjustments, 4WD Traction Manifold

How to Adjust the Charge Pressure Relief Valve

Note: Refer to 4WD Traction Manifold Component list to locate the charge pressure relief valve.

- 1 Connect a 0 to 600 psi / 0 to 50 bar pressure gauge to the test port on the drive pump.
- 2 Hold the charge pressure relief valve and remove the cap.
- 3 Turn the internal hex socket clockwise fully until it stops. Install the cap.
- 4 Start the engine and move and hold the function enable/rpm select toggle switch to the high rpm (rabbit symbol) position. Note the reading on the pressure gauge.
- 5 Turn the engine off.
- 6 Remove the pressure gauge from the drive pump. Connect the gauge to the test port located on the traction manifold.
- 7 Hold the charge pressure relief valve and remove the cap.
- 8 Start the engine and move and hold the function enable/rpm select toggle switch to the high rpm (rabbit symbol) position.
- 9 Adjust the internal hex socket until the pressure reading on the gauge is 40 psi / 2.8 bar less than the pressure reading on the pump. Turn it clockwise to increase the pressure or counterclockwise to decrease the pressure. Install the valve cap.
- 10 Turn the engine off and remove the pressure gauge.


Manifolds

8-8

Hydraulic Generator Manifold Components, 2.2kW

The generator manifold is mounted to the hydraulic generator located in the engine compartment.

| Index No. | Description | Schematic Item | Function | Torque |
|-----------|----------------------------------|----------------|-------------------|-------------------------|
| 1 | Proportional solenoid valve | HH | Generator speed | 33-37 ft-lbs / 45-50 Nm |
| 2 | Relief valve, 3000 psi / 207 bar | GG | Generator circuit | 20-25 ft-lbs / 27-34 Nm |




Manifolds

8-8.1

3 kW Generator Manifold

The generator manifold is mounted below the generator on the control side of the machine.

| Index No. | Description | Schematic Item | Function | Torque |
|-----------|----------------------------|----------------|--|-----------------------------|
| 1 | Relief valve | GA | Generator relief valve | 50 ft-lbs / 67 Nm |
| 2 | Solenoid Valve | GB | Charge pressure circuit | 60-65 ft lbs / 81-88 Nm |
| 3 | Needle valve | GD | Charge pressure circuit | 50 ft-lbs / 67 Nm |
| 4 | Differential sensing valve | GC | Pilot valve to diverter valve | 50 ft-lbs / 67 Nm |
| 5 | Counterbalance valve | GF | Adds backpressure to generator circuit | |
| 6 | Check valve | GE | Prevents oil to generator | 24-26 ft-lbs / 32.5-35.3 Nm |



Manifolds

8-9 Valve Coils

How to Test a Coil

A properly functioning coil provides an electromotive force which operates the solenoid valve. Critical to normal operation is continuity within the coil that provides this force field.

⚠ WARNING Electrocuting/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

- 1 Tag and disconnect the wiring from the coil to be tested.
- 2 Test the coil resistance.
 - ⊙ Result: The resistance should be within specification, plus or minus 30%.
 - ⊙ Result: If the resistance is not within specification, plus or minus 30%, replace the coil.

Valve Coil Resistance Specification

| | |
|--|---------|
| Proportional directional solenoid valve, 10V DC (schematic items BP, BU and BY) | 6 to 8Ω |
| 3 position 4 way directional valve, 10V DC (schematic items BF, BM and CG) | 6 to 8Ω |
| 2 position 3 way solenoid valve, 10V DC (schematic items CA, CC, AF, AG and AI) | 6 to 8Ω |

How to Test a Coil Diode

Properly functioning coil diodes protect the electrical circuit by suppressing voltage spikes. Voltage spikes naturally occur within a function circuit following the interruption of electrical current to a coil. Faulty diodes can fail to protect the electrical system, resulting in a tripped circuit breaker or component damage.

⚠ WARNING Electrocuting/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.


- 1 Test the coil for resistance. Refer to Repair Procedure, *How to Test a Coil*.
- 2 Connect a 10Ω resistor to the negative terminal of a known good 9V DC battery. Connect the other end of the resistor to a terminal on the coil.

Resistor, 10Ω

| | |
|-------------------|-------|
| Genie part number | 27287 |
|-------------------|-------|

Note: The battery should read 9V DC or more when measured across the terminals.

Manifolds



Note: Dotted lines in illustration indicate a reversed connection as specified in step 6.

- 3 Set a multimeter to read DC current.

Note: The multimeter, when set to read DC current, should be capable of reading up to 800 mA.

- 4 Connect the negative lead to the other terminal on the coil.
 - 5 Momentarily connect the positive lead from the multimeter to the positive terminal on the 9V DC battery. Note and record the current reading.
 - 6 At the battery or coil terminals, reverse the connections. Note and record the current reading.
- ⊙ Result: Both current readings are greater than 0 mA and are different by a minimum of 20%. The coil is good.
 - ⊗ Result: If one or both of the current readings are 0 mA, or if the two current readings do not differ by a minimum of 20%, the coil and/or its internal diode are faulty and the coil should be replaced.

Turntable Rotation Components

9-1

Turntable Rotation Assembly


How to Remove the Turntable Rotation Assembly

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or hose end must be replaced. All connections must be torqued to specification during installation. Refer to Specifications, *Hydraulic Hose and Fitting Torque Specifications*.


- 1 Raise the secondary boom until the upper pivot is above the turntable covers. Turn the machine off.
- 2 Secure the turntable from rotating with the turntable rotation lock.

⚠ DANGER

Tip-over hazard. The machine could tip over when the turntable rotation assembly is removed if the turntable rotation lock is not in the locked position.



Unlocked position



Locked position

- 3 Remove the safety pin from the engine pivot plate latch.

Note: The engine pivot plate latch is located under the engine turntable pivot plate at the counterweight end of the machine.

- 4 Remove the center turntable cover retaining fasteners. Remove the center turntable cover from the machine.
- 5 Open the engine pivot plate latch and swing the engine pivot plate out and away from the machine.
- 6 Tag, disconnect and plug the hydraulic hoses from the turntable rotation motor manifold. Cap the fittings on the manifold.

⚠ WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 7 Attach a lifting strap from and overhead crane or other suitable lifting device to the turntable rotator assembly.
- 8 Remove the turntable rotation assembly mounting fasteners.
- 9 Carefully remove the turntable rotation assembly from the machine.

⚠ DANGER

Tip-over hazard. The machine could tip over when the turntable rotation assembly is removed if the turntable rotation lock is not in the locked position.

⚠ WARNING

Crushing hazard. The turntable rotation assembly could become unbalanced and fall when removed from the machine if not properly supported by the overhead crane.

Axle Components

10-1 Oscillating Axle Cylinders

The oscillating axle cylinders extend and retract between the drive chassis and the oscillating axle. The cylinders are equipped with counterbalance valves to prevent movement in the event of a hydraulic line failure. The valves are not adjustable.

How to Remove an Oscillating Axle Cylinder

Note: Perform this procedure on a firm, level surface with the boom in the stowed position.

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or hose end must be replaced. All connections must be torqued to specification during installation. Refer to Specifications, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Tag, disconnect and plug the oscillating axle cylinder hydraulic hoses. Cap the fittings on the oscillate cylinder.

⚠ WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 2 Remove the pin retaining fasteners from the rod-end pivot pin. Use a soft metal drift to remove the pin.

- 3 Attach a lifting strap from an overhead crane to the barrel end of the oscillating cylinder.
- 4 Remove the pin retaining fasteners from the barrel-end pivot pin. Use a soft metal drift to remove the pin.

⚠ CAUTION Crushing hazard. The oscillate cylinder may become unbalanced and fall when removed from the machine if not properly attached to the overhead crane.

- 5 Remove the oscillate cylinder from the machine.

Fault Codes



Observe and Obey:

- ✓ Troubleshooting and repair procedures shall be completed by a person trained and qualified on the repair of this machine
- ✓ Immediately tag and remove from service a damaged or malfunctioning machine.
- ✓ Repair any machine damage or malfunction before operating the machine.
- ✓ Unless otherwise specified, perform each procedure with the machine in the following configuration:
 - Machine parked on a firm, level surface
 - Key switch in the off position with the key removed
 - The red Emergency Stop button in the off position at both the ground and platform controls
 - Wheels chocked
 - All external AC power supply disconnected from the machine
 - Boom in the stowed position
 - Turntable secured with the turntable rotation lock
 - Welder disconnected from the machine (if equipped with the weld cable to platform option)

Before Troubleshooting:

- ✓ Read, understand and obey the safety rules and operating instructions in the appropriate operator's manual on your machine.
- ✓ Be sure that all necessary tools and test equipment are available and ready for use.
- ✓ Read each appropriate fault code thoroughly. Attempting short cuts may produce hazardous conditions.
- ✓ Be aware of the following hazards and follow generally accepted safe workshop practices.

⚠ WARNING

Electrocution/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

Note: Two persons will be required to safely perform some troubleshooting procedures.

About This Section

There are two types of system faults in this section.

Control System Faults: Faults are indicated by the ALC500 operating system with two short beeps every 30 seconds when an abnormal condition or component failure occurs with the machine operating system. This could include machine functions, limit switches, angle sensors and hydraulic valves. Control system faults can be retrieved inside the platform control box.

Platform Overload System Fault Codes: Faults are indicated on the hour meter display, a red LED and with one short beep every second when an abnormal condition or component failure occurs with the platform overload system. Platform overload system fault codes can be retrieved on the hour meter display located at the ground controls.

Control System Fault Codes

Control System

How to Retrieve Control System Fault Codes

At least one fault code is present when the alarm at the platform controls produces two short beeps every 30 seconds for 10 minutes.

Perform this procedure with the engine off, the key switch turned to platform controls and the red Emergency Stop button pulled out to the on position at both the ground and platform controls.

- 1 Open the platform control box lid.

WARNING

Electrocution/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

- 2 Locate the red and yellow fault LEDs on the ALC-500 circuit board inside the platform control box. Do not touch the circuit board.

NOTICE

Component damage hazard. Electrostatic discharge (ESD) can damage printed circuit board components. Maintain firm contact with a metal part of the machine that is grounded at all times when handling printed circuit boards OR use a grounded wrist strap.

- 3 **Determine the error source:** The red LED indicates the error source and will flash two separate codes. The first code will indicate the first digit of the two digit code, flashing once per second. It will then pause for 1.5 seconds and flash the second digit once per 0.5 second.

Note: When the red LED is flashing the code, the yellow LED will be on solid.

- 4 **Determine the error type:** The yellow LED indicates the error type and will flash two separate codes. The first code will indicate the first digit of the two digit code, flashing once per second. It will then pause for 1.5 seconds and flash the second digit once per 0.5 second.

Note: When the yellow LED is flashing the code, the red LED will be on solid.

- 5 Use the fault code table on the following pages to aid in troubleshooting the machine by pinpointing the area or component affected.

Control System Fault Codes

| Error Source | | Error Type | | Condition | Solution |
|--------------|--|------------|-----------------|---|--|
| ID | Name | ID | Name | | |
| 21 | Primary Up / Down Joystick | 11 | Value at 5.0 V | Limited Speed and Direction frozen at zero and neutral, Alarm sounds. | Power up controller with problem corrected. |
| | | 12 | Value too high | | |
| | | 15 | Value too low | | |
| | | 16 | Value at 0 V | | |
| | | 17 | Not Calibrated | Joystick Speed and Direction frozen at zero and neutral. | Calibrate Joystick. |
| | | 18 | Just calibrated | Initiate 1 second beep of Alarm. | Self-clearing (transient) |
| 22 | Primary Up / Down Directional Valves | 21 | Fault | Limited Speed and Direction frozen at zero and neutral, Alarm sounds. | Power up controller with problem corrected. |
| 23 | Primary Up / Down Flow Valve | 12 | Value too high | Limited Speed and Direction frozen at zero and neutral, Alarm sounds. | Power up controller with problem corrected. |
| | | 15 | Value too low | | |
| | | 17 | Not Calibrated | Normal function except threshold for one or both directions is zero. | Calibrate valve threshold. |
| | | 18 | Just calibrated | Initiate 1 second beep of Alarm. | Self-clearing (transient) |
| 24 | Angle sensor | 11 | Value at 5.0 V | Reduced function speed | Retract before lowering required. Dual capacity models. |
| | | 12 | Value too high | | |
| | | 15 | Value too low | | Power up controller with problem corrected. |
| | | 16 | Value at 0 V | | |
| | | 17 | Not Calibrated | | Calibrate angle sensor. |
| | | 31 | Invalid setup | Initiate 1 second beep of Alarm. | Retract before lowering required. Dual capacity models. Calibrate angle sensor. |
| 26 | Angle sensor cross check | 19 | Out of Range | Reduced function speed | Retract before lowering required. Dual capacity models. Power up controller with problem corrected. |
| 31 | Secondary Up / Down. Joystick | 11 | Value at 5.0 V | Limited Speed and Direction frozen at zero and neutral, Alarm sounds. | Power up controller with problem corrected. |
| | | 12 | Value too high | | |
| | | 15 | Value too low | | |
| | | 16 | Value at 0 V | | |
| | | 17 | Not Calibrated | Joystick Speed and Direction frozen at zero and neutral. | Calibrate Joystick. |
| | | 18 | Just calibrated | Initiate 1 second beep of Alarm. | Self-clearing (transient) |

Control System Fault Codes

| Error Source | | Error Type | | Condition | Solution |
|--------------|--|------------|-----------------|--|---|
| ID | Name | ID | Name | | |
| 32 | Secondary Up / Down. Directional Valves | 21 | Fault | Limited Speed and Direction frozen at zero and neutral, Alarm sounds. | Power up controller with problem corrected. |
| 33 | Secondary Up / Down Flow Valve | 12 | Value too high | Limited Speed and Direction frozen at zero and neutral, Alarm sounds. | Power up controller with problem corrected. |
| | | 15 | Value too low | | |
| | | 17 | Not Calibrated | Normal function except threshold for one or both directions is zero. | Calibrate valve threshold. |
| | | 18 | Just calibrated | Initiate 1 second beep of Alarm. | Self-clearing (transient) |
| 34 | primary Boom Extend / Retract Limit Switches | 31 | Invalid setup | Initiate 1 second beep of Alarm. 1000lb. Mode: Required retract into FULLY RETRACTED state before lowering. 500lb. Mode: Operates normally. Dual capacity models. | Fully retract, then lower boom. Check and service ext/ret and fully stowed switches. |
| 41 | Turntable Rotate Joystick | 11 | Value at 5.0 V | Limited Speed and Direction frozen at zero and neutral, Alarm sounds. | Power up controller with problem corrected. |
| | | 12 | Value too high | | |
| | | 15 | Value too low | | |
| | | 16 | Value at 0 V | | |
| | | 17 | Not Calibrated | Initiate 1 second beep of Alarm. | Calibrate Joystick. |
| | | 18 | Just calibrated | Initiate 1 second beep of Alarm. | Self-clearing (transient) |
| 42 | Turntable Rotate Directional Valves | 21 | Fault | Limited Speed and Direction frozen at zero and neutral, Alarm sounds. | Power up controller with problem corrected. |
| 43 | Turntable Rotate Flow Valve | 12 | Value too high | Limited Speed and Direction frozen at zero and neutral, Alarm sounds. | Power up controller with problem corrected. |
| | | 15 | Value too low | | |
| | | 17 | Not Calibrated | Normal function except threshold for one or the other direction is zero. Display message on LCD. | Calibrate valve threshold. |
| | | 18 | Just calibrated | Initiate 1 second beep of Alarm. | Self-clearing (transient) |
| 44 | Drive Enable Override Switch | 21 | Fault | Drive enable override direction is frozen at neutral. | Power up controller with problem corrected. |
| 45 | Platform Level Switch | 21 | Fault | Platform level frozen at neutral. | Power up controller with problem corrected. |
| 46 | Primary Extend / Retract Switch | 21 | Fault | Platform Extend / Retract frozen at neutral. | Power up controller with problem corrected. |

Control System Fault Codes

| Error Source | | Error Type | | Condition | Solution |
|--------------|------------------------------------|------------|-----------------|--|---|
| ID | Name | ID | Name | | |
| 51 | Drive Joystick | 11 | Value at 5.0 V | Limited Speed and Direction frozen at zero and neutral, Alarm sounds. | Power up controller with problem corrected. |
| | | 12 | Value too high | | |
| | | 15 | Value too low | | |
| | | 16 | Value at 0 V | | Calibrate Joystick. |
| | | 17 | Not Calibrated | Joystick Speed and Direction frozen at zero and neutral. | |
| | | 18 | Just calibrated | Initiate 1 second beep of Alarm. | |
| 53 | Drive Flow Valve (EDC) | 12 | Value too high | Limited Speed and Direction frozen at zero and neutral, Alarm sounds. | Power up controller with problem corrected. |
| | | 15 | Value too low | | |
| | | 17 | Not Calibrated | Normal function except threshold for one or both directions is zero. | Calibrate valve threshold. |
| | | 18 | Just calibrated | Initiate 1 second beep of Alarm. | |
| 54 | Propel Brake Valve | 21 | Fault | Limited Speed and Direction frozen at zero and neutral, Alarm sounds. | Power up controller with problem corrected. |
| 55 | Propel High Motor Speed Valve | 21 | Fault | Motor speed frozen in the low state. | Power up controller with problem corrected. |
| 56 | Platform Level Valve | 21 | Fault | Direction frozen at zero and neutral. | Power up controller with problem corrected. |
| 57 | Foot switch / ECU Power Crosscheck | 12 | Value too high | Direction frozen at zero and neutral. | Power up controller with problem corrected. |
| | | 15 | Value too low | | |
| 61 | Steer Joystick | 11 | Value at 5.0 V | Limited Speed and Direction frozen at zero and neutral, Alarm sounds. | Power up controller with problem corrected. |
| | | 12 | Value too high | | |
| | | 15 | Value too low | | |
| | | 16 | Value at 0 V | | Calibrate Joystick. |
| | | 17 | Not Calibrated | Joystick Speed and Direction frozen at zero and neutral. | |
| | | 18 | Just calibrated | Initiate 1 second beep of Alarm. | |
| 62 | Steer Direction Valves | 21 | Fault | Limited Speed and Direction frozen at zero and neutral, Alarm sounds. | Power up controller with problem corrected. |
| 81 | Platform Load Sense Overload | 21 | Fault | Limited Speed and Direction frozen at zero and neutral, Alarm sounds. | Self-clearing (transient) |
| 82 | Load Sense Overload Recovery | 21 | Fault | Limited Primary Up, Secondary Up and Primary extend and 5 seconds timeout. | Self-clearing after timeout. |


Control System Fault Codes

Platform Overload System Fault Codes

How to Retrieve Platform Overload System Fault Codes - Deutz D2011L03i, Perkins 404D-22 and Ford MSG-425 Models

At least one or more fault codes are present when the alarm at the platform and ground controls produces one short beep every second and a solid or flashing red LED is displayed on the hour meter at the ground controls.

The last two digits of the fault code are the *Error Type*. The first two or three digits of the fault code are the *Error Source*.



- 1 LCD display
- 2 red LED - fault indicator
- 3 yellow LED - battery indicator
- 4 green LED - engine hours indicator

- 1 Read and record the fault code(s) shown on the display.
- 2 Refer to the fault code tables on the following pages.

Control System Fault Codes

| Error Source | | Error Type | | Condition | Solution |
|--------------|--------------------------|------------|---|---|--|
| ID | Name | ID | Name | | |
| 34 | Ext. Ret. Limit Switch | 36 | Cross check fault | Alarm sounds indicating a fault. Overload LED is on. Functions disabled, engine shutdown. Auxiliary functions enabled except extend. | Check primary boom retracted operational (LS1) and safety (LS5) limit switches. Boom retracted: 0 volts at C42LS of LS1. 12 volts at C166LS of LS5. |
| 75 | SCON - Safety controller | 34 | Software mismatch Primary and secondary micro-controllers software do not match. | Alarm sounds indicating a fault. Overload LED is on. Functions disabled, engine shutdown. Auxiliary functions enabled except extend. | Install correct software part number and version in secondary micro-controller. |
| 76 | Platform load cell | 12 | Value too high | Platform overloaded. | Reduce weight in platform. |
| | | 13 | No Response | No communication to load cell. | Check CAN bus circuit for open or short. Check for cable damage to load cell. Check for power at load cell. |
| | | 15 | Value too low | Output from load cell lower than expected while primary up is active. | Confirm the platform load cell is properly pre-loaded and is free of obstructions. |
| | | 17 | Not Calibrated | Zero load not calibrated: Alarm sounds indicating a fault. Overload LED is on. Functions disabled, engine shutdown. Auxiliary functions enabled except extend. Zero load calibrated, gain is not: Unit operates with reduced load capacity. | Calibrate the load cell. |
| | | 21 | Internal load cell status | Alarm sounds indicating a fault. Overload LED is on. Functions disabled, engine shutdown. Auxiliary functions enabled except extend. | Inspect load cell for damage. Cycle power off then back on. If fault persist, replace load cell. |
| | | 31 | Invalid setup | | Calibrate load cell with proper load or replace |
| | | 36 | Cross check fault | | Inspect load cell for damage. Cycle power off then back on. If fault persist, replace load cell. |

Control System Fault Codes

| Error Source | | Error Type | | Condition | Solution |
|--------------|--------------------------------|------------|----------------|---|--|
| ID | Name | ID | Name | | |
| 79 | Hour meter | 13 | No Response | Loss of communication to hour meter. Machine functions normal. | Check power and ground to hour meter. Check CAN bus circuit for open or short. Check CAN bus resistance between CAN high and CAN low. 60 ohms. |
| 82 | Overload recovery | 21 | Fault | Platform overloaded and machine operated using auxiliary power. Fault remains active until reset is performed. | Refer to Repair Procedure, <i>Platform Overload Recovery Fault</i> . |
| 102 | Overload function cutout relay | 12 | Value too high | SCON detects 12VDC from CR54 or CR55 terminal 87 when terminals 85 and 86 are not activated. Alarm sounds indicating a fault. Overload LED is on. Functions disabled, engine shutdown. Auxiliary functions enabled except extend. | Check for 12VDC at SCON C41-6. Should be 0VDC. Replace CR54 or CR55. Check for short to 12VDC in harness to SCON C41-6. |
| | | 15 | Value too low | SCON detects 0VDC from CR54 or CR55 terminal 87 when terminals 85 and 86 are activated. Alarm sounds indicating a fault. Overload LED is on. Functions disabled, engine shutdown. Auxiliary functions enabled except extend. | Check for 0VDC at SCON C41-6. Should be 12VDC. Replace CR54 or CR55. Check for open in harness to SCON C41-6. |
| 103 | Overload engine cutout relay | 12 | Value too high | SCON detects input from TB21 when CR56 terminals 85 and 86 are not activated. Alarm sounds indicating a fault. Overload LED is on. Functions disabled, engine shutdown. Auxiliary functions enabled except extend. | Replace CR56. Check for short from TB21 in harness to SCON C42-2. |

Fault Code Display - Deutz and Perkins Models

How to Retrieve Active Engine Fault Codes - Deutz D 2.9 L4 and Perkins 404F-E22T Models

The ECM constantly monitors the engine by the use of sensors on the engine. The ECM also uses signals from the sensors to initiate sequential fuel injection and make constant and instantaneous changes to ignition timing, fuel delivery and throttle position to maintain the engine's running condition at its highest efficiency while at the same time keeping exhaust emissions to a minimum. When a sensor fails or returns signals that are outside of set parameters, the ECM will store a fault code in memory that relates to the appropriate sensor. One or more fault LED's will illuminate on the display located at the ground control box. The active fault code will also be displayed on the LCD screen.

Note: The Perkins 404F-E22T is equipped with an engine fault LED located at the platform control box.

If an engine fault occurs that does not result in an engine shutdown, the engine rpm will go into limp home mode resulting in the loss of high rpm.

When operating from the platform, if the red Emergency Stop button is pushed in, the active fault code(s) will be erased from the display.

Start the engine from the ground control box and operate various boom functions to verify that an active engine fault occurs and is shown on the display.

Note: All faults are stored in the Previous Fault history menu. These faults will not be erased when corrective action has been completed.

With an active fault and the engine running: (preferred method)


- 1 At the ground controls, activate the auxiliary pump toggle switch to shut the engine off.

Note: Do not push in the red Emergency Stop button or turn the key switch to the off position.

- 2 Press any soft key below the display.
- 3 Use the scroll up / down keys to check for multiple engine fault codes.

With the engine not running:

- 1 At the ground controls, turn the key switch to ground controls and pull out the red Emergency Stop button.
- 2 Navigate to the Active Fault Menu and use the scroll up / down keys to check for multiple engine fault codes.



Fault Code Display - Deutz and Perkins Models

How to Retrieve Active Engine Fault Codes - Deutz TD 2.2 L3 Models

The ECM constantly monitors the engine by the use of sensors on the engine. The ECM also uses signals from the sensors to initiate sequential fuel injection and make constant and instantaneous changes to ignition timing, fuel delivery and throttle position to maintain the engine's running condition at its highest efficiency while at the same time keeping exhaust emissions to a minimum. When a sensor fails or returns signals that are outside of set parameters, the ECM will store a fault code in memory that relates to the appropriate sensor. One or more fault LED's will illuminate on the display located at the ground control box. The active fault code will also be displayed on the LCD screen.

If an engine fault occurs that does not result in an engine shutdown, the engine rpm will go into limp home mode resulting in the loss of high rpm.

When operating from the platform, if the red Emergency Stop button is pushed in, the active fault code(s) will be erased from the display.

Start the engine from the ground control box and operate various boom functions to verify that an active engine fault occurs and is shown on the display.

Note: All faults are stored in the Previous Fault history menu. These faults will not be erased when corrective action has been completed.

With an active fault and the engine running: (preferred method)


- 1 At the ground controls, activate the auxiliary pump toggle switch to shut the engine off.

Note: Do not push in the red Emergency Stop button or turn the key switch to the off position.

- 2 Press any soft key below the display.
- 3 Use the scroll up / down keys to check for multiple engine fault codes.


With the engine not running:

- 1 At the ground controls, turn the key switch to ground controls and pull out the red Emergency Stop button.
- 2 Navigate to the Active Fault Menu and use the scroll up / down keys to check for multiple engine fault codes.



Fault Code Display - Deutz and Perkins Models


Flashing and Solid LED's - Deutz D 2.9 L4 and Perkins 404F-E22T Models



- 1 Left green LED:
Flashing, engine fault detected. Contact service.
Solid, fault acknowledged. Contact service.
- 2 Left amber LED: (Perkins models)
Solid,
 - a) Regeneration is inhibited. No service required.
 - b) High exhaust temperature during regeneration mode. No service required.
- 3 Left red LED:
Flashing, engine fault detected. Contact service.
Flashing with right flashing amber LED, engine soot level over 140%. Engine shut down. Contact service.
- 4 Right green LED:
Flashing, engine fault detected. Contact service.
Solid, fault acknowledged. Contact service.
- 5 Right amber LED: (Perkins models)
Solid with left amber LED on solid, regeneration has been inhibited and engine soot level is between 80 - 100%. Regeneration is required.
Flashing with left amber LED on solid, regeneration has been inhibited and soot level is between 100 - 140%. Engine rpm is de-rated. Regeneration is required.
Flashing with left and right red LED's flashing, engine soot level over 140%. Engine shut down. Contact service.
- 6 Right red LED:
Flashing, engine fault detected. Contact service.
Flashing with right flashing amber LED, engine soot level over 140%. Engine shut down. Contact service.

Fault Code Display - Deutz and Perkins Models

Soft Key Functions and Icons - Deutz D 2.9 L4 and Perkins 404F-E22T Models




- 1 Next menu • Exit / Back one screen • Decrease brightness (-)
- 2 Brightness / Contrast • Scroll up • Increase • Increase brightness (+)
- 3 Regeneration forced • Scroll down • Decrease • Decrease contrast (-)
- 4 Regeneration inhibited • Select / Next • Main menu • Increase contrast (+)

| | | | |
|---------------------------|---------------------------------------|--------------------|--------------------|
| | | | |
| Next Menu | Brightness/ Contrast | Initiate Switch | Inhibit Switch |
| | | | |
| Exit / Back One Screen | Scroll Up | Scroll Down | Select |
| | | | |
| Main Menu | Hour Meter | Oil Pressure | Coolant Temp. |
| | | | |
| Engine RPM | Soot Soot Level Percent (%) | Voltage | Pin # Protected |

























Note: Regeneration, initiate, inhibit and soot only apply to the Perkins 404F-E22T models.

Fault Code Display - Deutz and Perkins Models

Soft Key Functions and Icons - Deutz TD 2.2 L3 Models




- 1 Exit / Back one screen
- 2 Scroll up • Increase Time / Date • Decrease brightness
- 3 Scroll down • Decrease Time / Date • Increase brightness
- 4 Main menu • Select

| Main Screen Icons | | | | Engine Warning Icons | | | |
|---|--|---|--|--|---|--|---|
|  Engine RPM |  Voltage |  Oil pressure |  Coolant temperature |  Regen required |  DPF service required |  Replace DPF |  Change oil |
|  Soot load (%) |  Engine torque |  Hour meter |  Time since last regen |  Low coolant |  Fuel/Water separator |  Engine stop |  Engine start |
|  Exit / Back one screen |  Scroll up |  Scroll down |  Select |  Standstill regen active |  Engine failure | | |
|  Main menu |  Pin code required | | | | | | |


Fault Code Display - Deutz and Perkins Models

Main Menu Structure - Deutz D 2.9 L4 Models




Fault Code Display - Deutz and Perkins Models

Main Menu Structure - Deutz TD 2.2 L3 Models



Fault Code Display - Deutz and Perkins Models

Main Menu Structure - Perkins 404F-E22T Models



Deutz TD 2.2 L3 Engine Fault Codes

DTC = Diagnostic Trouble Code

FMI = Failure Mode Identifier

SPN = Suspect Parameter Number

| DTC | SPN | FMI | Description |
|------|-----|-----|---|
| 1000 | 98 | 2 | Engine oil level sensor internal error. Sensor reports error. Open/short transducer. |
| 1001 | 98 | 31 | Engine oil level out of range. Level low, high, foaming. |
| 1002 | 98 | 31 | Oil sensor voltage out of range. <8,5V \pm 0,5V; >16,5V \pm 0,5V. |
| 1003 | 98 | 2 | Oil sensor invalid sensor status. |
| 1004 | 98 | 31 | Oil sensor temperature out of range. |
| 1005 | 98 | 14 | Oil sensor is broken or disconnected. |
| 1021 | 100 | 3 | Oil pressure voltage above normal or shorted to high. |
| 1022 | 100 | 4 | Oil pressure voltage below normal or shorted to low. |
| 1025 | 100 | 1 | Low oil pressure. Warning threshold exceeded. |
| 1026 | 100 | 1 | Low oil pressure. Shut off threshold exceeded. |
| 1043 | 107 | 0 | Air filter differential pressure. Air filter clogged. |
| 1071 | 411 | 2 | Engine exhaust gas recirculation. Pressure does not change between engine operating points. |
| 1072 | 411 | 0 | Engine exhaust gas recirculation. Pressure above normal operational range. |
| 1073 | 411 | 1 | Engine exhaust gas recirculation. Pressure below normal operational range. |
| 1074 | 411 | 2 | Engine exhaust gas recirculation. Negative measured differential pressure. |
| 1075 | 411 | 2 | Engine exhaust gas recirculation. Positive measured differential pressure. |

| DTC | SPN | FMI | Description |
|------|-------|-----|--|
| 1077 | 411 | 3 | Engine exhaust gas recirculation. Signal value above maximum limit. |
| 1078 | 411 | 4 | Engine exhaust gas recirculation. Signal value below maximum limit. |
| 1079 | 108 | 0 | Ambient air pressure sensor above normal operational range. |
| 1080 | 108 | 1 | Ambient air pressure sensor below normal operational range. |
| 1081 | 108 | 15 | Fault check max signal range violated for ambient air pressure sensor. |
| 1082 | 108 | 17 | Fault check min signal range violated for ambient air pressure sensor. |
| 1083 | 108 | 2 | Ambient air pressure sensor error by component self diagnosis. |
| 1084 | 3720 | 0 | DPF ash load above normal operational range. |
| 1086 | 3734 | 0 | DPF soot load exceeded. Remove filter level. |
| 1087 | 4781 | 14 | DPF soot load exceeded shut off level. |
| 1088 | 4781 | 0 | DPF soot load exceeded warning level. |
| 1089 | 4781 | 16 | DPF. Too much standstill time in short time interval. |
| 1090 | 10156 | 0 | DPF. The standstill-regeneration mode time exceeds the short-limit. |
| 1091 | 3735 | 16 | DPF. Standstill required and no successful standstill longer than escalation threshold. Moderately severe. |
| 1092 | 3735 | 0 | DPF. Standstill required and no successful standstill longer than escalation threshold. Most severe. |
| 1093 | 4766 | 1 | DOC. Regeneration temperature in standstill main phase not reached. |
| 1102 | 171 | 2 | Ambient air temperature shows a deviation from expected value at cold start conditions. |

Deutz TD 2.2 L3 Engine Fault Codes

DTC = Diagnostic Trouble Code

FMI = Failure Mode Identifier

SPN = Suspect Parameter Number

| DTC | SPN | FMI | Description |
|------|------|-----|---|
| 111 | 102 | 0 | Engine intake manifold pressure above normal operational range. |
| 1114 | 102 | 1 | Engine intake manifold pressure below normal operational range. |
| 1115 | 102 | 3 | Intake manifold pressure sensor voltage above normal or shorted to high. |
| 1116 | 102 | 4 | Intake manifold pressure sensor voltage below normal or shorted to low. |
| 1118 | 102 | 1 | Intake manifold pressure below normal operational range. |
| 1121 | 102 | 2 | DFC for signal variation check for pressure sensor of the intake manifold. |
| 1122 | 102 | 0 | Intake air pressure valve sensor, warning condition exceeded. |
| 1123 | 102 | 1 | Intake air pressure valve sensor, shutoff condition exceeded. |
| 1124 | 1209 | 2 | Engine exhaust pressure turbine upstream differs from ambient pressure while engine not running. |
| 1125 | 1209 | 15 | Engine exhaust pressure turbine upstream above upper limit. |
| 1126 | 1176 | 1 | Engine turbocharger compressor intake pressure below normal operational range. |
| 1127 | 1209 | 2 | Engine exhaust pressure turbine upstream tuck check failed. Pressure does not change between engine operating points. |
| 1130 | 1209 | 3 | Engine exhaust pressure sensor voltage above normal or shorted to high. |
| 1131 | 1209 | 4 | Engine exhaust pressure sensor voltage below normal or shorted to low. |

| DTC | SPN | FMI | Description |
|------|------|-----|--|
| 1134 | 3251 | 3 | DPF voltage above normal or shorted to high. |
| 1135 | 3251 | 4 | DPF voltage below normal or shorted to low. |
| 1136 | 3251 | 14 | DPF reporting communication error. |
| 1137 | 3251 | 14 | DPF reporting data error. |
| 1138 | 3251 | 14 | DPF reporting fast channel 1 error. |
| 1139 | 3251 | 14 | DPF reporting fast channel 2 signal range error. |
| 1149 | 3251 | 2 | DPF difference pressure value not plausible. |
| 1150 | 3251 | 0 | DPF difference pressure above shut off threshold. |
| 1151 | 3251 | 16 | DPF difference pressure above warning threshold. |
| 1152 | 3251 | 1 | DPF difference pressure below shut off threshold. |
| 1153 | 3251 | 18 | DPF difference pressure below warning threshold. |
| 1161 | 5571 | 16 | Rail fuel pressure relief valve above normal operational range. |
| 1162 | 5571 | 2 | Rail fuel pressure relief valve is forced to open, perform pressure increase. |
| 1163 | 5571 | 2 | Rail fuel pressure relief valve is forced to open. Performed by pressure increase. |
| 1164 | 5571 | 16 | Rail fuel pressure relief valve is forced to open. Shutoff conditions. |
| 1165 | 5571 | 15 | Rail fuel pressure relief valve is forced to open. Warning conditions. |
| 1166 | 5571 | 0 | Open rail fuel pressure relief valve was detected. |
| 1167 | 5571 | 2 | Unexpected opening of the rail fuel pressure relief valve. |
| 1168 | 5571 | 2 | Successful rail fuel pressure relief valve opening cannot be ensured. |
| 1169 | 5571 | 13 | Averaged rail fuel pressure after valve opening is outside the expected tolerance range. |

Deutz TD 2.2 L3 Engine Fault Codes

DTC = Diagnostic Trouble Code

FMI = Failure Mode Identifier

SPN = Suspect Parameter Number

| DTC | SPN | FMI | Description |
|------|------|-----|--|
| 1170 | 5571 | 16 | Open time of rail fuel pressure relief valve for wear out monitoring had exceeded. |
| 1171 | 94 | 1 | Fuel pressure build up during engine start not successful. |
| 1172 | 1347 | 5 | Electrical fuel pump current below normal or open circuit. |
| 1174 | 1347 | 3 | Electrical fuel pump voltage above normal or shorted to high. |
| 1175 | 1347 | 4 | Electrical fuel pump voltage below normal or shorted to low. |
| 119 | 1231 | 14 | CAN Bus 2 off Error for Application CAN. |
| 1190 | 7103 | 13 | Rail fuel pressure below set point, speed-dependent threshold exceeded. |
| 1191 | 7103 | 13 | Rail fuel pressure metering unit. Fuel quantity balance is disrupted. |
| 1194 | 7103 | 13 | Negative rail fuel pressure governor deviation at zero delivery by metering unit. |
| 1195 | 7103 | 1 | Rail fuel pressure value is below minimum rail pressure threshold. |
| 1197 | 7103 | 0 | Maximum rail fuel pressure exceeded. |
| 1198 | 7103 | 2 | Set point of fuel metering unit in overrun mode not plausible. |
| 120 | 639 | 14 | CAN Bus 1 off Error for Power train CAN. |
| 1200 | 5357 | 14 | Shut-off due to undershoot of minimum rail pressure. |
| 1202 | 157 | 0 | Maximum rail pressure exceeded in limp home mode. |
| 1208 | 157 | 3 | Engine fuel injector metering rail pressure voltage above normal or shorted to high. |

| DTC | SPN | FMI | Description |
|------|--------|-----|--|
| 1209 | 157 | 4 | Engine fuel injector metering rail pressure voltage below normal or shorted to low. |
| 121 | 520252 | 2 | Wrong checksum in the CAN message EAT Control. |
| 1212 | 629 | 12 | ECU. Keep alive error during runtime at an external device. |
| 1213 | 629 | 12 | ECU. Keep alive error during initialization phase at an external device. |
| 1215 | 629 | 12 | ECU. Read diagnosis error for non volatile memory. |
| 1216 | 629 | 12 | ECU. Write diagnosis error for non volatile memory. |
| 1218 | 629 | 12 | ECU. Stack memory threshold overrun. |
| 1219 | 629 | 12 | ECU. Observation counter irregular switch off counter triggered by engine running. |
| 122 | 4207 | 2 | TSC1 message checksum fault. |
| 123 | 4207 | 2 | TSC1 message checksum fault. |
| 1233 | 5826 | 15 | Emission control system operator inducement level 1 severity above normal operational range. |
| 1235 | 5826 | 0 | Emission control system operator inducement level 2 severity above normal operational range. |
| 1236 | 5826 | 14 | Emission control system operator pre-trigger inducement level 2 severity. |
| 124 | 4207 | 2 | TSC1 message checksum fault. |
| 125 | 4207 | 2 | TSC1 message checksum fault. |
| 1274 | 91 | 3 | Accelerator pedal sensor position 1 voltage above normal or shorted to high. |
| 1275 | 2623 | 3 | Accelerator pedal 1, channel 2 voltage above normal or shorted to high. |
| 1276 | 29 | 3 | Accelerator pedal 2 voltage above normal or shorted to high. |

Deutz TD 2.2 L3 Engine Fault Codes

DTC = Diagnostic Trouble Code

FMI = Failure Mode Identifier

SPN = Suspect Parameter Number

| DTC | SPN | FMI | Description |
|------|------|-----|---|
| 1277 | 2625 | 3 | Accelerator pedal 2, channel 2 voltage above normal or shorted to high. |
| 1280 | 91 | 4 | Accelerator pedal sensor position 1 voltage below normal or shorted to low. |
| 1281 | 2623 | 4 | Accelerator pedal 1, channel 2 voltage below normal or shorted to low. |
| 1282 | 29 | 4 | Accelerator pedal 2 voltage below normal or shorted to low. |
| 1283 | 2625 | 4 | Accelerator pedal 2, channel 2 voltage below normal or shorted to low. |
| 1289 | 3509 | 14 | Failure of sensor supply voltage 1 from ECU. |
| 1290 | 3509 | 0 | Sensor supply voltage 1 from ECU above normal operational range. |
| 1291 | 3509 | 6 | Sensor supply voltage 1 from ECU current above normal or grounded circuit. |
| 1292 | 3509 | 1 | Sensor supply voltage 1 from ECU below normal operational range. |
| 1293 | 3510 | 14 | Failure of sensor supply voltage 2 from ECU. |
| 1294 | 3510 | 0 | Sensor supply voltage 2 from ECU above normal operational range. |
| 1295 | 3510 | 6 | Sensor supply voltage 2 from ECU current above normal or grounded circuit. |
| 1296 | 3510 | 1 | Sensor supply voltage 2 from ECU below normal operational range. |
| 1306 | 677 | 3 | Engine starter motor relay voltage above normal or shorted to high. |
| 1307 | 677 | 4 | Engine starter motor relay voltage below normal or shorted to low. |

| DTC | SPN | FMI | Description |
|------|------|-----|---|
| 1308 | 677 | 5 | Engine starter motor relay current below normal or shorted to low. |
| 1310 | 677 | 3 | Engine starter motor relay voltage above normal or shorted to high. |
| 1311 | 677 | 4 | Engine starter motor relay voltage below normal or shorted to low. |
| 1323 | 91 | 11 | Accelerator pedal position 1. Possible error between APP1 and APP2 or APP1 and idle switch. |
| 1326 | 29 | 11 | Accelerator Pedal 2 Position. Possible error between APP1 and idle switch. |
| 1346 | 1041 | 14 | Start signal indicator. Terminal 50 was operated too long. |
| 1354 | 105 | 0 | Engine intake manifold 1 temperature data above normal operational range. Warning threshold exceeded. |
| 1355 | 105 | 0 | Engine intake manifold 1 temperature above normal operational range. Shutoff threshold exceeded. |
| 1357 | 1136 | 0 | Engine ECU temperature above normal operational range. Most severe. |
| 1358 | 1136 | 1 | Engine ECU temperature below normal operational range. Most severe. |
| 1359 | 1136 | 15 | Engine ECU temperature above normal operational range. Least severe. |
| 1360 | 1136 | 17 | Engine ECU temperature below normal operational range. Least severe. |
| 1361 | 1136 | 2 | Engine ECU temperature fault check. |
| 1362 | 412 | 15 | Engine exhaust gas recirculation temperature above normal operational range. |

Deutz TD 2.2 L3 Engine Fault Codes

DTC = Diagnostic Trouble Code

FMI = Failure Mode Identifier

SPN = Suspect Parameter Number

| DTC | SPN | FMI | Description |
|------|-----|-----|---|
| 1363 | 412 | 17 | Engine exhaust gas recirculation temperature below normal operational range. |
| 1364 | 412 | 3 | Engine exhaust gas recirculation temperature voltage above normal or shorted to high. |
| 1365 | 412 | 4 | Engine exhaust gas recirculation temperature voltage below normal or shorted to low. |
| 1372 | 51 | 5 | Engine throttle valve 1, position 1 current below normal or open circuit. |
| 1375 | 51 | 3 | Engine throttle valve 1, position 1 voltage above normal or shorted to high. Short circuit to battery 1. |
| 1376 | 51 | 3 | Engine throttle valve 1, position 1 voltage above normal or shorted to high. Short circuit to battery 2. |
| 1377 | 51 | 4 | Engine throttle valve 1, position 1 voltage below normal or shorted to low. Short circuit to ground 1. |
| 1378 | 51 | 4 | Engine throttle valve 1, position 1 voltage below normal or shorted to low. Short circuit to ground 2. |
| 1379 | 51 | 6 | Engine throttle valve 1, position 1 current above normal or grounded circuit. |
| 1382 | 51 | 7 | Engine throttle valve 1 position 1 mechanical system not responding or out of adjustment. Valve stuck closed. |
| 1383 | 51 | 7 | Engine throttle valve 1 position 1 mechanical system not responding or out of adjustment. Valve stuck open. |
| 1391 | 51 | 3 | Engine throttle valve 1, position 1 voltage above normal or shorted to high. |

| DTC | SPN | FMI | Description |
|------|--------|-----|---|
| 1392 | 51 | 4 | Engine throttle valve 1, position 1 voltage below normal or shorted to low. |
| 1397 | 105 | 0 | Engine intake manifold 1 temperature above normal operational range. |
| 1398 | 105 | 1 | Engine intake manifold 1 temperature below normal operational range. |
| 1399 | 4766 | 2 | DOC temperature too high. |
| 1400 | 4766 | 2 | DOC temperature too low. |
| 1401 | 4766 | 15 | DOC outlet temperature above normal operational range. |
| 1402 | 4766 | 3 | DOC outlet temperature voltage above normal or shorted to high. |
| 1403 | 4766 | 4 | DOC outlet temperature voltage below normal or shorted to low. |
| 1404 | 4766 | 2 | DOC intake temperature error. |
| 1405 | 4766 | 15 | DOC Intake temperature above normal operational range. |
| 1406 | 4766 | 3 | DOC intake temperature voltage above normal or shorted to high. |
| 1407 | 4766 | 4 | DOC intake temperature voltage below normal or shorted to low. |
| 1408 | 4766 | 2 | DOC intake temperature does not change. |
| 142 | 520256 | 9 | Timeout of EAT control receive message. CAN message is not received. |
| 144 | 523211 | 9 | Timeout error of CAN receive frame EBC1. |
| 154 | 523212 | 9 | Timeout error of CAN receive frame engine protection. |
| 1540 | 520254 | 8 | The stand still regeneration mode time exceeds the long limit threshold. |
| 1541 | 520255 | 2 | Hoses connected to the dp DPF SENT sensor inverted. Swap hoses. |
| 155 | 523741 | 14 | Engine shutdown request via CAN. |

Deutz TD 2.2 L3 Engine Fault Codes

DTC = Diagnostic Trouble Code

FMI = Failure Mode Identifier

SPN = Suspect Parameter Number

| DTC | SPN | FMI | Description |
|------|--------|-----|--|
| 1587 | 97 | 0 | Water in fuel level prefilter; maximum value exceeded. |
| 188 | 523240 | 9 | Timeout CAN message function mode control. |
| 219 | 520253 | 2 | Rolling counter fault CAN message EAT Control. |
| 220 | 4206 | 2 | Fault check for Rolling Counter of TSC1AE. |
| 221 | 4206 | 2 | Fault check for Rolling Counter of TSC1AR. |
| 222 | 4206 | 2 | Fault check for Rolling Counter of TSC1TE. |
| 223 | 4206 | 2 | Fault check for Rolling Counter of TSC1TR. |
| 349 | 3349 | 0 | Timeout error of CAN receive frame active TSC1AE. |
| 350 | 3349 | 0 | Timeout error of CAN receive frame passive TSC1AE. |
| 351 | 3349 | 0 | Timeout error of CAN receive frame active TSC1AR. |
| 352 | 3349 | 0 | Timeout error of CAN receive frame passive TSC1AR. |
| 353 | 3349 | 0 | Timeout error of CAN receive frame TSC1TE active. |
| 354 | 3349 | 0 | TSC1 receive timeout error. Short circuit to ground error. |
| 355 | 3349 | 0 | Timeout error of CAN receive frame TSC1TR. |
| 356 | 3349 | 0 | Passive timeout error of CAN receive frame TSC1TR. |
| 361 | 3349 | 0 | Timeout error of CAN receive frame TSC1AE. Traction Control. |
| 363 | 3349 | 0 | Timeout error of CAN receive frame TSC1AR. Retarder. |
| 365 | 3349 | 0 | Timeout error of CAN receive frame TSC1TE. Setpoint. |

| DTC | SPN | FMI | Description |
|-----|--------|-----|---|
| 367 | 3349 | 0 | Timeout Error of CAN receive frame TSC1TR; control signal. |
| 38 | 1485 | 3 | ECM main relay voltage above normal or shorted to high. |
| 39 | 1485 | 3 | ECM main relay voltage above normal or shorted to high of actuator relay 2. |
| 40 | 1485 | 3 | ECM main relay voltage above normal or shorted to high of actuator relay 3. |
| 41 | 1485 | 4 | ECM main relay voltage below normal or shorted to low. |
| 42 | 1485 | 4 | ECM main relay voltage below normal or shorted to low of actuator relay 2. |
| 43 | 1485 | 4 | ECM main relay voltage below normal or shorted to low of actuator relay 3. |
| 48 | 168 | 0 | Battery voltage above normal operational range. |
| 49 | 168 | 1 | Battery voltage low normal operational range. |
| 50 | 168 | 3 | Battery voltage above normal or shorted to high. |
| 51 | 168 | 4 | Battery voltage above normal or shorted to low. |
| 516 | 523982 | 0 | Power stage diagnosis disabled. High battery voltage. |
| 517 | 523982 | 1 | Power stage diagnosis disabled. Low battery voltage. |
| 52 | 168 | 0 | High battery voltage. Warning threshold is exceeded. |
| 567 | 27 | 5 | Engine exhaust gas recirculation 1 valve position current below normal or open circuit. |
| 570 | 27 | 3 | Engine exhaust gas recirculation 1 valve position voltage above normal or shorted to battery 1. |
| 571 | 27 | 3 | Engine exhaust gas recirculation 1 valve position voltage above normal or shorted to battery 2. |

Deutz TD 2.2 L3 Engine Fault Codes

DTC = Diagnostic Trouble Code

FMI = Failure Mode Identifier

SPN = Suspect Parameter Number

| DTC | SPN | FMI | Description |
|-----|------|-----|---|
| 572 | 27 | 4 | Engine exhaust gas recirculation 1 valve position voltage below normal or shorted to ground 1. |
| 573 | 27 | 4 | Engine exhaust gas recirculation 1 valve position voltage below normal or shorted to ground 2. |
| 574 | 27 | 6 | Engine exhaust gas recirculation 1 valve position current above normal or grounded circuit. |
| 577 | 27 | 7 | Engine exhaust gas recirculation 1 valve position. Mechanical system not responding or out of adjustment. Valve stuck closed. |
| 578 | 27 | 7 | Engine exhaust gas recirculation 1 valve position. Mechanical system not responding or out of adjustment. Valve stuck open. |
| 582 | 5763 | 3 | Engine exhaust gas recirculation 1, actuator 1 voltage above normal or shorted to high. |
| 583 | 5763 | 4 | Engine exhaust gas recirculation 1, actuator 1 voltage below normal or shorted to low. |
| 586 | 3055 | 14 | Internal software error ECU. Injection cut off. |
| 587 | 190 | 0 | Engine speed above warning threshold. Over speed detection in component engine protection. |
| 588 | 190 | 0 | Engine speed above warning threshold. FOC-Level 1. |
| 589 | 190 | 0 | Engine speed above warning threshold. FOC-Level 2. |
| 590 | 190 | 0 | Engine speed above warning threshold. Overrun Mode. |
| 610 | 171 | 15 | Environment temperature sensor, temperature above upper physical threshold. |

| DTC | SPN | FMI | Description |
|-----|------|-----|--|
| 613 | 171 | 3 | Ambient air temperature sensor voltage above normal or shorted to high. |
| 614 | 171 | 4 | Ambient air temperature sensor voltage below normal or shorted to low. |
| 615 | 723 | 8 | Camshaft speed sensor abnormal frequency or pulse width or period. |
| 616 | 723 | 14 | Camshaft sensor detection. Out of range, signal disrupted, no signal. |
| 617 | 723 | 13 | Offset angle between crank and camshaft sensor is too large. |
| 618 | 4201 | 8 | Crankshaft sensor detection. Out of range, signal disrupted, no signal. |
| 619 | 4201 | 14 | Crankshaft speed sensor. Speed detection, out of range, signal disrupted or no signal. |
| 68 | 1669 | 14 | CAN Bus ID-5. CAN Hardware registers are not updated within the expected time. |
| 70 | 110 | 2 | Engine Coolant Temperature. Data erratic, intermittent or incorrect. |
| 709 | 97 | 3 | Water in fuel indicator 1. Voltage above normal or shorted to high. |
| 710 | 97 | 4 | Water in fuel indicator 1. Voltage below normal or shorted to low. |
| 721 | 94 | 15 | Low fuel pressure system, max. physical range exceeded. |
| 723 | 94 | 3 | Engine fuel pressure sensor voltage above normal or shorted to high. |
| 724 | 94 | 4 | Engine fuel pressure sensor voltage below normal or shorted to low. |
| 725 | 94 | 1 | Low fuel pressure system, warning threshold exceeded. |
| 726 | 94 | 1 | Low fuel pressure, shut off threshold exceeded. |
| 75 | 110 | 3 | Engine coolant temperature voltage above normal or shorted to high. |
| 76 | 110 | 4 | Engine coolant temperature voltage below normal or shorted to low. |

Deutz TD 2.2 L3 Engine Fault Codes

DTC = Diagnostic Trouble Code

FMI = Failure Mode Identifier

SPN = Suspect Parameter Number

| DTC | SPN | FMI | Description |
|-----|------|-----|--|
| 77 | 110 | 0 | High coolant temperature. Warning threshold exceeded. |
| 78 | 110 | 0 | Coolant temperature. System reaction initiated. |
| 797 | 676 | 12 | Engine cold start aid relay error. |
| 798 | 676 | 5 | Engine cold start aid relay current below normal or open circuit. |
| 799 | 676 | 5 | Engine cold start aid relay current below normal or open circuit. |
| 80 | 411 | 2 | Intake air massflow not in expected range. |
| 803 | 676 | 3 | Engine cold start aid relay voltage above normal or shorted to high. |
| 805 | 676 | 4 | Engine cold start aid relay voltage below normal or shorted to low. |
| 807 | 2797 | 14 | Engine fuel 1 injector, Group 1. Number of possible injections limited by the injection valve. |
| 815 | 2797 | 4 | Engine fuel 1 injector, Group 1 voltage below normal or shorted to low. |
| 816 | 5358 | 5 | Engine cylinder 1 fuel injection quantity current below normal or open circuit. |
| 817 | 5359 | 5 | Engine cylinder 2 fuel injection quantity current below normal or open circuit. |
| 818 | 5360 | 5 | Engine cylinder 3 fuel injection quantity current below normal or open circuit. |
| 819 | 5361 | 5 | Engine cylinder 4 fuel injection quantity current below normal or open circuit. |
| 820 | 5362 | 5 | Engine cylinder 5 fuel injection quantity current below normal or open circuit. |

| DTC | SPN | FMI | Description |
|-----|------|-----|--|
| 821 | 5363 | 5 | Engine cylinder 6 fuel injection quantity current below normal or open circuit. |
| 822 | 2797 | 6 | Engine fuel 1 injector, Group 1 current above normal or grounded circuit. |
| 823 | 2798 | 6 | Engine fuel 1 injector, Group 2 current above normal or grounded circuit. |
| 824 | 5358 | 6 | Engine cylinder 1 fuel injection quantity above normal or grounded circuit. Short circuit of the power stage low-side. |
| 825 | 5359 | 6 | Engine cylinder 2 fuel injection quantity above normal or grounded circuit. Short circuit of the power stage low-side. |
| 826 | 5360 | 6 | Engine cylinder 3 fuel injection quantity above normal or grounded circuit. Short circuit of the power stage low-side. |
| 827 | 5361 | 6 | Engine cylinder 4 fuel injection quantity above normal or grounded circuit. Short circuit of the power stage low-side. |
| 828 | 5362 | 6 | Engine cylinder 5 fuel injection quantity above normal or grounded circuit. Short circuit of the power stage low-side. |
| 829 | 5363 | 6 | Engine cylinder 6 fuel injection quantity above normal or grounded circuit. Short circuit of the power stage low-side. |
| 83 | 111 | 1 | Coolant level too low. |
| 830 | 5358 | 6 | Engine cylinder 1 fuel injection quantity above normal or grounded circuit. Short circuit between high-side and low-side of the power stage. |

Deutz TD 2.2 L3 Engine Fault Codes

DTC = Diagnostic Trouble Code

FMI = Failure Mode Identifier

SPN = Suspect Parameter Number

| DTC | SPN | FMI | Description |
|-----|------|-----|--|
| 831 | 5359 | 6 | Engine cylinder 2 fuel injection quantity above normal or grounded circuit. Short circuit between high-side and low-side of the power stage. |
| 832 | 5360 | 6 | Engine cylinder 3 fuel injection quantity above normal or grounded circuit. Short circuit between high-side and low-side of the power stage. |
| 833 | 5361 | 6 | Engine cylinder 4 fuel injection quantity above normal or grounded circuit. Short circuit between high-side and low-side of the power stage. |
| 834 | 5362 | 6 | Engine cylinder 5 fuel injection quantity above normal or grounded circuit. Short circuit between high-side and low-side of the power stage. |
| 835 | 5363 | 6 | Engine cylinder 6 fuel injection quantity above normal or grounded circuit. Short circuit between high-side and low-side of the power stage. |
| 836 | 105 | 3 | Engine intake manifold temperature voltage above normal or shorted to high. |
| 837 | 105 | 4 | Engine intake manifold temperature voltage below normal or shorted to low. |
| 838 | 2797 | 14 | Engine fuel 1 injector, group 1 missing injector adjustment value programming injector 1. |
| 839 | 2798 | 14 | Engine fuel 1 injector, group 2 missing injector adjustment value programming injector 2. |

| DTC | SPN | FMI | Description |
|-----|------|-----|---|
| 840 | 4257 | 14 | Engine fuel 1 injector, group 3 missing injector adjustment value programming injector 3. |
| 854 | 7103 | 5 | Engine fuel metering rail pump current below normal or open circuit. |
| 855 | 7103 | 3 | Engine fuel metering rail pump voltage above normal or shorted to high. Short circuit to battery on the high side power stage. |
| 856 | 7103 | 3 | Engine fuel metering rail pump voltage above normal or shorted to high. Short circuit to battery on the low side power stage. |
| 857 | 7103 | 4 | Engine fuel metering rail pump voltage below normal or shorted to low. Short circuit to battery on the high side power stage. |
| 858 | 7103 | 4 | Engine fuel metering rail pump voltage below normal or shorted to low. Short circuit to battery on the low side power stage. |
| 859 | 7103 | 6 | Engine fuel metering rail pump current above normal or grounded circuit. |
| 868 | 629 | 12 | Function monitoring: fault of ECU ADC. Null load test pulse. |
| 869 | 629 | 12 | Function monitoring: fault of ECU ADC. Test voltage. |
| 870 | 629 | 12 | ECU. DFC to indicate ICO request from MoCSOP module. |
| 871 | 91 | 14 | Function monitoring: Monitoring of accelerator pedal position. |
| 875 | 190 | 2 | Function monitoring: Fault of engine speed check. |
| 876 | 5357 | 2 | Engine fuel injection error for multiple cylinders. Diagnostic fault check error between level 1 energizing time and level 2 information. |

Deutz TD 2.2 L3 Engine Fault Codes

DTC = Diagnostic Trouble Code

FMI = Failure Mode Identifier

SPN = Suspect Parameter Number

| DTC | SPN | FMI | Description |
|-----|--------|-----|---|
| 877 | 5441 | 2 | Engine fuel injection timing error for multiple cylinders. |
| 878 | 5357 | 2 | Engine fuel injection error for multiple cylinders. Diagnostic fault check to report the error due to non plausibility in ZFC. |
| 879 | 523612 | 12 | Internal recovery. Diagnosis fault check to report the error to demand for an ICO due to an error in the Pol2 shut-off. |
| 88 | 598 | 10 | Clutch switch. Abnormal rate of change. |
| 880 | 523612 | 12 | Internal recovery. Diagnosis fault check to report the error to demand for an ICO due to an error in the Pol3 efficiency factor. |
| 881 | 523612 | 12 | Internal recovery. Diagnosis fault check to report the error to demand for an ICO due to an error in change of EOM. |
| 882 | 5357 | 2 | Engine fuel injection error for multiple cylinders. Diagnosis fault check to report the error to demand for an ICO due to an error in total torque relevant quantity. |
| 883 | 5357 | 2 | Engine fuel injection error for multiple cylinders. Diagnostic fault check to report the error due to injection quantity correction. |
| 884 | 5442 | 2 | Engine fuel injection pressure error for multiple cylinders. |
| 885 | 29 | 2 | Accelerator pedal 2 position. |
| 886 | 677 | 2 | Engine starter motor relay. Function monitoring: Fault of ECU power train active. |

| DTC | SPN | FMI | Description |
|-----|--------|-----|---|
| 887 | 513 | 2 | Actual engine percent torque. DFC to report the fault in energizing time comparison. |
| 888 | 513 | 2 | Actual engine percent torque. DFC to report in torque comparison error. |
| 889 | 520250 | 2 | Function monitoring: Error in the post-build selectable monitoring. |
| 890 | 629 | 12 | ECU. Status of the EMM alarm FCCU0 which is read out of the FCCU hardware module. |
| 91 | 1109 | 2 | Engine protection system approaching shutdown. Engine shut off demand ignored. |
| 92 | 1109 | 14 | Engine protection system approaching shutdown. Shut off request from supervisory monitoring function. |
| 996 | 629 | 12 | ECU. Diagnostic fault check to report ABE active state. |
| 997 | 629 | 12 | Function monitoring: Fault of ECU, WDA active by inquiry/response communication. |
| 998 | 629 | 12 | Function monitoring: Fault of ECU, Error Pin active suspicion of HW fault. |
| 999 | 629 | 12 | Function monitoring: Fault of ECU, WDA active by overvoltage detection. |

The following DTC fault code range shares the same description. Replace the ECU.

| DTC | 891 - 945 | Description |
|-----|-----------|---------------------|
| SPN | 629 | Internal ECU error. |
| FMI | 12 | |

Deutz D 2.9 L4 Engine Fault Codes

SPN = Suspect Parameter Number

FMI = Failure Mode Identifier

KWP = Keyword Protocol

| SPN | FMI | KWP | Description |
|-----|-----|------|--|
| 51 | 3 | 1019 | EGR-Valve, short circuit to battery |
| 51 | 3 | 1024 | Position sensor error of actuator EGR-Valve; signal range check high |
| 51 | 3 | 1226 | EGR-Valve; short circuit to battery (A02) |
| 51 | 3 | 1227 | EGR-Valve; short circuit to battery (A67) |
| 51 | 4 | 1020 | EGR-Valve; short circuit to ground |
| 51 | 4 | 1025 | Position sensor error actuator EGR-Valve; signal range check low |
| 51 | 4 | 1228 | EGR-Valve; short circuit to ground (A02) |
| 51 | 4 | 1229 | EGR-Valve; short circuit to ground (A67) |
| 1 | 4 | 1232 | Actuator error EGR-Valve; Voltage below threshold |
| 51 | 5 | 1015 | Actuator error EGR-Valve; signal range check low |
| 51 | 5 | 1017 | Actuator EGR-Valve; open load |
| 51 | 5 | 1023 | Actuator error EGR-Valve; signal range check low |
| 51 | 5 | 1223 | Actuator EGR-Valve; open load |
| 51 | 6 | 1014 | Actuator error EGR-Valve; signal range check high |
| 51 | 6 | 1022 | Actuator error EGR-Valve; signal range check high |
| 51 | 6 | 1224 | Actuator EGR-Valve; over current |
| 51 | 6 | 1230 | Actuator error EGR-Valve; Overload by short-circuit |
| 51 | 7 | 1016 | Actuator position for EGR-Valve not plausible |

| SPN | FMI | KWP | Description |
|-----|-----|------|---|
| 51 | 11 | 1231 | Actuator error EGR-Valve; Power stage over temp due to high current |
| 51 | 12 | 1018 | Actuator EGR-Valve; powerstage over temperature |
| 51 | 12 | 1021 | Mechanical actuator defect EGR-Valve |
| 51 | 12 | 1225 | Actuator EGR-Valve; over temperature |
| 94 | 1 | 474 | Low fuel pressure; warning threshold exceeded |
| 94 | 1 | 475 | Low fuel pressure; shut off threshold exceeded |
| 94 | 3 | 472 | Sensor error low fuel pressure; signal range check high |
| 94 | 4 | 473 | Sensor error low fuel pressure; signal range check low |
| 97 | 3 | 464 | Sensor error water in fuel; signal range check high |
| 97 | 4 | 465 | Sensor error water in fuel; signal range check low |
| 97 | 12 | 1157 | Water in fuel level prefilter; maximum value exceeded |
| 100 | 0 | 734 | High oil pressure; warning threshold exceeded |
| 100 | 0 | 735 | High oil pressure; shut off threshold exceeded |
| 100 | 1 | 736 | Low oil pressure; warning threshold exceeded |
| 100 | 1 | 737 | Low oil pressure; shut off threshold exceeded |
| 100 | 3 | 732 | Sensor error oil pressure; signal range check high |
| 100 | 4 | 733 | Sensor error oil pressure sensor; signal range check low |
| 102 | 2 | 88 | Charged air pressure above warning threshold |
| 102 | 2 | 89 | Charged air pressure above shut off threshold |
| 102 | 4 | 777 | Sensor error charged air press.; signal range check low |

Deutz D 2.9 L4 Engine Fault Codes

SPN = Suspect Parameter Number

FMI = Failure Mode Identifier

KWP = Keyword Protocol

| SPN | FMI | KWP | Description |
|-----|-----|-----|--|
| 105 | 0 | 996 | High charged air cooler temperature; warning threshold exceeded |
| 105 | 0 | 997 | High charged air cooler temperature; shut off threshold exceeded |
| 105 | 3 | 994 | Sensor error charged air temperature; signal range check high |
| 105 | 4 | 995 | Sensor error charged air temperature; signal range check low |
| 108 | 3 | 412 | Sensor error ambient air press.; signal range check high |
| 108 | 4 | 413 | Sensor error ambient air press.; signal range check low |
| 110 | 0 | 98 | High coolant temperature; warning threshold exceeded |
| 110 | 0 | 99 | High coolant temperature; shut off threshold exceeded |
| 110 | 3 | 96 | Sensor error coolant temp.; signal range check high |
| 110 | 4 | 97 | Sensor error coolant temp.; signal range check low |
| 111 | 1 | 101 | Coolant level too low |
| 132 | 11 | 1 | Air flow sensor load correction factor exceeding the maximum drift limit; plausibility error |
| 132 | 11 | 2 | Air flow sensor load correction factor exceeding drift limit; plausibility error |
| 132 | 11 | 3 | Air flow sensor low idle correction factor exceeding the maximum drift limit |
| 132 | 11 | 4 | Air flow sensor load correction factor exceeding the maximum drift limit |
| 157 | 3 | 877 | Sensor error rail pressure; signal range check high |
| 157 | 4 | 878 | Sensor error rail pressure; signal range check low |

| SPN | FMI | KWP | Description |
|-----|-----|------|---|
| 168 | 0 | 1180 | Physical range check high for battery voltage |
| 168 | 1 | 1181 | Physical range check low for battery voltage |
| 168 | 2 | 47 | High battery voltage; warning threshold exceeded |
| 168 | 2 | 48 | Low battery voltage; warning threshold exceeded |
| 168 | 3 | 45 | Sensor error battery voltage; signal range check high |
| 168 | 4 | 46 | Sensor error battery voltage; signal range check low |
| 171 | 3 | 417 | Sensor error environment temperature; signal range check high |
| 171 | 4 | 418 | Sensor error environment temperature; signal range check low |
| 172 | 0 | 1182 | Physical range check high for intake air temperature |
| 172 | 1 | 1183 | Physical range check low for intake air temperature |
| 172 | 2 | 9 | Sensor ambient air temperature; plausibility error |
| 172 | 2 | 983 | Intake air sensor; plausibility error |
| 172 | 3 | 981 | Sensor error intake air; signal range check high |
| 172 | 4 | 982 | Sensor error intake air sensor; signal range check low |
| 174 | 0 | 481 | High low fuel temperature; warning threshold exceeded |
| 174 | 0 | 482 | High Low fuel temperature; shut off threshold exceeded |
| 175 | 0 | 740 | Physical range check high for oil temperature |
| 175 | 0 | 745 | High oil temperature; warning threshold exceeded |
| 175 | 0 | 746 | High oil temperature; shut off threshold exceeded |
| 175 | 1 | 741 | Physical range check low for oil temperature |

Deutz D 2.9 L4 Engine Fault Codes

SPN = Suspect Parameter Number

FMI = Failure Mode Identifier

KWP = Keyword Protocol

| SPN | FMI | KWP | Description |
|-----|-----|------|---|
| 175 | 2 | 738 | Sensor oil temperature; plausibility error |
| 175 | 2 | 739 | Sensor oil temperature; plausibility error oil temperature too high |
| 175 | 3 | 743 | Sensor error oil temperature; signal range check high |
| 175 | 4 | 744 | Sensor error oil temperature; signal range check low |
| 190 | 0 | 389 | Engine speed above warning threshold (FOC-Level 1) |
| 190 | 2 | 421 | Offset angle between crank- and camshaft sensor is too large |
| 190 | 8 | 419 | Sensor camshaft speed; disturbed signal |
| 190 | 8 | 422 | Sensor crankshaft speed; disturbed signal |
| 190 | 11 | 390 | Engine speed above warning threshold (FOC-Level 2) |
| 190 | 12 | 420 | Sensor camshaft speed; no signal |
| 190 | 12 | 423 | Sensor crankshaft speed; no signal |
| 190 | 14 | 391 | Engine speed above warning threshold (Overrun Mode) |
| 190 | 14 | 1222 | Camshaft- and Crankshaft speed sensor signal not available on CAN |
| 411 | 0 | 791 | Physical range check high for differential pressure Venturiunit (EGR) |
| 411 | 1 | 792 | Physical range check low for differential pressure Venturiunit (EGR) |
| 411 | 3 | 795 | Sensor error differential pressure Venturiunit (EGR); signal range check high |
| 411 | 4 | 381 | Physical range check low for EGR differential pressure |
| 411 | 4 | 796 | Sensor error differential pressure Venturiunit (EGR); signal range check low |

| SPN | FMI | KWP | Description |
|-----|-----|------|---|
| 412 | 3 | 1007 | Sensor error EGR cooler downstream temperature; signal range check high |
| 412 | 4 | 1008 | Sensor error EGR cooler downstream temperature; signal range check low |
| 520 | 9 | 306 | Timeout Error of CAN-Receive-Frame TSC1TR; Setpoint |
| 597 | 2 | 49 | Break lever mainswitch and break lever redundancy switch status not plausible |
| 624 | 3 | 971 | SVS lamp; short circuit to batt. |
| 624 | 4 | 972 | SVS lamp; short circuit to grd. |
| 624 | 5 | 969 | SVS lamp; open load |
| 624 | 12 | 970 | SVS lamp; powerstage over temperature |
| 630 | 12 | 376 | Access error EEPROM memory (delete) |
| 630 | 12 | 377 | Access error EEPROM memory (read) |
| 630 | 12 | 378 | Access error EEPROM memory (write) |
| 639 | 14 | 84 | CAN-Bus 0 "BusOff-Status" |
| 651 | 3 | 580 | Injector 1 (in firing order); short circuit |
| 651 | 4 | 586 | High side to low side short circuit in the injector 1 (in firing order) |
| 651 | 5 | 568 | Injector 1 (in firing order); interruption of electric connection |
| 652 | 3 | 581 | Injector 2 (in firing order); short circuit |
| 652 | 4 | 587 | High side to low side short circuit in the injector 2 (in firing order) |
| 652 | 5 | 569 | Injector 2 (in firing order); interruption of electric connection |
| 653 | 3 | 582 | Injector 3 (in firing order); short circuit |
| 653 | 4 | 588 | High side to low side short circuit in the injector 3 (in firing order) |
| 653 | 5 | 570 | Injector 3 (in firing order); interruption of electric connection |

Deutz D 2.9 L4 Engine Fault Codes

SPN = Suspect Parameter Number

FMI = Failure Mode Identifier

KWP = Keyword Protocol

| SPN | FMI | KWP | Description |
|------|-----|-----|---|
| 654 | 3 | 583 | Injector 4 (in firing order); short circuit |
| 654 | 4 | 589 | High side to low side short circuit in the injector 4 (in firing order) |
| 654 | 5 | 571 | Injector 4 (in firing order); interruption of electric connection |
| 676 | 11 | 543 | Cold start aid relay error. |
| 676 | 11 | 544 | Cold start aid relay open load |
| 677 | 3 | 956 | Starter relay high side; short circuit to battery |
| 677 | 3 | 960 | Starter relay low side; short circuit to battery |
| 677 | 4 | 957 | Starter relay high side; short circuit to ground |
| 677 | 4 | 961 | Starter relay low side; short circuit to ground |
| 677 | 5 | 958 | Starter relay; no load error |
| 677 | 12 | 959 | Starter relay; powerstage over temperature |
| 703 | 3 | 426 | Engine running lamp; short circuit to battery |
| 703 | 4 | 427 | Engine running lamp; short circuit to ground |
| 703 | 5 | 424 | Engine running lamp; open load |
| 703 | 12 | 425 | Engine running lamp; powerstage over temperature |
| 729 | 5 | 545 | Cold start aid relay open load |
| 729 | 12 | 547 | Cold start aid relay; over temperature error |
| 898 | 9 | 305 | Timeout Error of CAN-Receive-Frame TSC1TE; Setpoint |
| 1079 | 13 | 946 | Sensor supply voltage monitor 1 error (ECU) |
| 1080 | 13 | 947 | Sensor supply voltage monitor 2 error (ECU) |

| SPN | FMI | KWP | Description |
|------|-----|------|--|
| 1109 | 2 | 121 | Engine shut off demand ignored |
| 1136 | 0 | 1398 | Physikal range check high for ECU temperature |
| 1136 | 1 | 1399 | Physikal range check low for ECU temperature |
| 1136 | 3 | 1400 | Sensor error ECU temperature; signal range check high |
| 1136 | 4 | 1401 | Sensor error ECU temperature; signal range check low |
| 1176 | 3 | 849 | Sensor error pressure sensor upstream turbine; signal range check high |
| 1176 | 4 | 850 | Sensor error pressure sensor downstream turbine; signal range check high |
| 1180 | 0 | 1193 | Physical range check high for exhaust gas temperature upstream turbine |
| 1180 | 0 | 1460 | Turbocharger Wastegate CAN feedback; warning threshold exceeded |
| 1180 | 0 | 1462 | Exhaust gas temperature upstream turbine; warning threshold exceeded |
| 1180 | 1 | 1194 | Physical range check low for exhaust gas temperature upstream turbine |
| 1180 | 1 | 1461 | Turbocharger Wastegate CAN feedback; shut off threshold exceeded |
| 1180 | 1 | 1463 | Exhaust gas temperature upstream turbine; shut off threshold exceeded |
| 1180 | 3 | 1067 | Sensor error exhaust gas temperature upstream turbine; signal range check high |
| 1180 | 11 | 1066 | Sensor exhaust gas temperature upstream turbine; plausibility error |
| 1188 | 2 | 1414 | Wastegate; status message from ECU missing |

Deutz D 2.9 L4 Engine Fault Codes

SPN = Suspect Parameter Number

FMI = Failure Mode Identifier

KWP = Keyword Protocol

| SPN | FMI | KWP | Description |
|------|-----|------|--|
| 1188 | 7 | 1415 | Wastegate actuator; blocked |
| 1188 | 11 | 1411 | Wastegate actuator; internal error |
| 1188 | 11 | 1412 | Wastegate actuator; EOL calibration not performed correctly |
| 1188 | 11 | 1416 | Wastegate actuator; over temperature (> 145°C) |
| 1188 | 11 | 1417 | Wastegate actuator; over temperature (> 135°C) |
| 1188 | 11 | 1418 | Wastegate actuator; operating voltage error |
| 1188 | 13 | 1413 | Wastegate actuator calibration deviation too large, recalibration required |
| 1231 | 14 | 85 | CAN-Bus 1 "BusOff-Status" |
| 1235 | 14 | 86 | CAN-Bus 2 "BusOff-Status" |
| 1237 | 2 | 747 | Override switch; plausibility error |
| 1322 | 12 | 610 | Too many recognized misfires in more than one cylinder |
| 1323 | 12 | 604 | Too many recognized misfires in cylinder 1 (in firing order) |
| 1324 | 12 | 605 | Too many recognized misfires in cylinder 2 (in firing order) |
| 1325 | 12 | 606 | Too many recognized misfires in cylinder 3 (in firing order) |
| 1326 | 12 | 607 | Too many recognized misfires in cylinder 4 (in firing order) |
| 2659 | 0 | 1524 | Physical range check high for EGR exhaust gas mass flow |
| 2659 | 1 | 1525 | Physical range check low for EGR exhaust gas mass flow |
| 2659 | 2 | 1523 | Exhaust gas recirculation AGS sensor; plausibility error |

| SPN | FMI | KWP | Description |
|------|-----|------|--|
| 2659 | 2 | 1527 | AGS sensor temperature exhaust gas mass flow; plausibility error |
| 2659 | 12 | 1526 | Exhaust gas recirculation; AGS sensor has "burn off" not performed |
| 2797 | 4 | 1337 | Injector diagnostics; timeout error of short circuit to ground measurement cyl. Bank 0 |
| 2798 | 4 | 1338 | Injector diagnostics; timeout error of short circuit to ground measurement cyl. Bank 1 |
| 2798 | 4 | 1339 | Injector diagnostics; short circuit to ground monitoring Test in Cyl. Bank 0 |
| 2798 | 4 | 1340 | Injector diagnostics; short circuit to ground monitoring Test in Cyl. Bank 1 |
| 3224 | 2 | 127 | DLC Error of CAN-Receive-Frame AT11G1 NOX Sensor (SCR-system upstream cat; DPF-system downstream cat); length of frame incorrect |
| 3224 | 9 | 128 | Timeout Error of CAN-Receive-Frame AT11G1; NOX sensor upstream |
| 3248 | 4 | 1047 | Sensor error particle filter downstream temperature; signal range check low |
| 3699 | 2 | 1616 | DPF differential pressure sensor and a further sensor or actuator CRT system defective |
| 3699 | 2 | 1617 | Temperature sensor us. and ds. DOC simultaneously defect |
| 3699 | 14 | 1615 | Maximum stand-still-duration reached; oil exchange required |
| 4765 | 0 | 1039 | Physical range check high for exhaust gas temperature upstream (DOC) |
| 4765 | 1 | 1042 | Physical range check low for exhaust gas temperature upstream (DOC) |

Deutz D 2.9 L4 Engine Fault Codes

SPN = Suspect Parameter Number

FMI = Failure Mode Identifier

KWP = Keyword Protocol

| SPN | FMI | KWP | Description |
|--------|-----|------|--|
| 4766 | 0 | 1029 | Physical range check high for exhaust gas temperature downstream (DOC) |
| 4766 | 1 | 1032 | Physical range check low for exhaust gas temperature downstream (DOC) |
| 4768 | 2 | 1036 | Sensor exhaust gas temperature upstream (DOC); plausibility error |
| 4768 | 3 | 1044 | Sensor error exhaust gas temperature upstream (DOC); signal range check high |
| 4768 | 4 | 1045 | Sensor error exhaust gas temperature upstream (DOC) signal range check low |
| 4769 | 2 | 1026 | Sensor exhaust gas temperature downstream (DOC); plausibility error |
| 4769 | 3 | 1034 | Sensor error exhaust gas temperature downstream (DOC); signal range check high |
| 4769 | 4 | 1035 | Sensor error exhaust gas temperature downstream (DOC); signal range check low |
| 523006 | 3 | 34 | Controller mode switch; short circuit to battery |
| 523006 | 4 | 35 | Controller mode switch; short circuit to ground |
| 523008 | 1 | 648 | Manipulation control was triggered |
| 523008 | 2 | 649 | Timeout error in Manipulation control |
| 523009 | 9 | 825 | Pressure Relief Valve (PRV) reached maximum allowed opening count |
| 523009 | 10 | 833 | Pressure relief valve (PRV) reached maximum allowed open time |

| SPN | FMI | KWP | Description |
|--------|-----|-----|--|
| 523212 | 9 | 171 | Timeout Error of CAN-Receive-Frame ComEngPrt; Engine Protection |
| 523216 | 9 | 198 | Timeout Error of CAN-Receive-Frame PrHtEnCmd; pre-heat command, engine command |
| 523240 | 9 | 179 | Timeout CAN-message FunModCtl; Function Mode Control |
| 523350 | 4 | 565 | Injector cylinder-bank 1; short circuit |
| 523352 | 4 | 566 | Injector cylinder-bank 2; short circuit |
| 523354 | 12 | 567 | Injector powerstage output defect |
| 523470 | 2 | 826 | Pressure Relief Valve (PRV) forced to open; performed by pressure increase |
| 523470 | 2 | 827 | Pressure Relief Valve (PRV) forced to open; performed by pressure shock |
| 523470 | 7 | 876 | Maximum rail pressure in limp home mode exceeded (PRV) |
| 523470 | 11 | 831 | The PRV can not be opened at this operating point with a pressure shock |
| 523470 | 11 | 832 | Rail pressure out of tolerance range |
| 523470 | 12 | 828 | Open Pressure Relief Valve (PRV); shut off condition |
| 523470 | 12 | 829 | Open Pressure Relief Valve (PRV); warning condition |
| 523470 | 14 | 830 | Pressure Relief Valve (PRV) is open |
| 523550 | 12 | 980 | T50 start switch active for too long |
| 523601 | 13 | 948 | Sensor supply voltage monitor 3 error (ECU) |
| 523603 | 9 | 126 | Timeout Error of CAN-Receive-Frame AMB; Ambient Temperature Sensor |

Deutz D 2.9 L4 Engine Fault Codes

SPN = Suspect Parameter Number

FMI = Failure Mode Identifier

KWP = Keyword Protocol

| SPN | FMI | KWP | Description |
|--------|-----|-----|---|
| 523605 | 9 | 300 | Timeout Error of CAN-Receive-Frame TSC1AE; Traction Control |
| 523606 | 9 | 301 | Timeout Error of CAN-Receive-Frame TSC1AR; Retarder |
| 523612 | 12 | 387 | Internal software error ECU; injection cut off |
| 523612 | 12 | 612 | Internal ECU monitoring detection reported error |
| 523612 | 12 | 613 | Internal ECU monitoring detection reported error |
| 523612 | 12 | 614 | Internal ECU monitoring detection reported error |
| 523612 | 12 | 615 | Internal ECU monitoring detection reported error |
| 523612 | 12 | 616 | Internal ECU monitoring detection reported error |
| 523612 | 12 | 617 | Internal ECU monitoring detection reported error |
| 523612 | 12 | 618 | Internal ECU monitoring detection reported error |
| 523612 | 12 | 619 | Internal ECU monitoring detection reported error |
| 523612 | 12 | 620 | Internal ECU monitoring detection reported error |
| 523612 | 12 | 621 | Internal ECU monitoring detection reported error |
| 523612 | 12 | 623 | Internal ECU monitoring detection reported error |
| 523612 | 12 | 624 | Internal ECU monitoring detection reported error |
| 523612 | 12 | 625 | Internal ECU monitoring detection reported error |
| 523612 | 12 | 627 | Internal ECU monitoring detection reported error |
| 523612 | 12 | 628 | Internal ECU monitoring detection reported error |

| SPN | FMI | KWP | Description |
|--------|-----|------|---|
| 523612 | 12 | 637 | Internal ECU monitoring detection reported error |
| 523612 | 12 | 1170 | Internal software error ECU |
| 523612 | 14 | 973 | Softwarereset CPU SWReset_0 |
| 523612 | 14 | 974 | Softwarereset CPU SWReset_1 |
| 523612 | 14 | 975 | Softwarereset CPU SWReset_2 |
| 523613 | 0 | 856 | Maximum positive deviation of rail pressure exceeded (RailMeUn0) |
| 523613 | 0 | 857 | Maximum positive deviation of rail pressure in metering unit exceeded (RailMeUn1) |
| 523613 | 0 | 858 | Railsystem leakage detected (RailMeUn10) |
| 523613 | 0 | 859 | Maximum negative deviation of rail pressure in metering unit exceeded (RailMeUn2) |
| 523613 | 0 | 860 | Negative deviation of rail pressure second stage (RailMeUn22) |
| 523613 | 0 | 862 | Maximum rail pressure exceeded (RailMeUn4) |
| 523613 | 1 | 861 | Minimum rail pressure exceeded (RailMeUn3) |
| 523613 | 2 | 864 | Setpoint of metering unit in overrun mode not plausible |
| 523615 | 3 | 594 | Metering unit (Fuel-System); short circuit to battery highside |
| 523615 | 3 | 596 | Metering unit (Fuel-System); short circuit to battery low side |
| 523615 | 4 | 595 | Metering unit (Fuel-System); short circuit to ground high side |
| 523615 | 4 | 597 | Metering Unit (Fuel-System); short circuit to ground low side |
| 523615 | 5 | 592 | Metering unit (Fuel-System); open load |
| 523615 | 12 | 593 | Metering unit (Fuel-System); powerstage over temperature |
| 523619 | 2 | 488 | Physical range check high for exhaust gas temperature upstrem (SCR-CAT) |
| 523698 | 11 | 122 | Shut off request from supervisory monitoring function |

Deutz D 2.9 L4 Engine Fault Codes

SPN = Suspect Parameter Number

FMI = Failure Mode Identifier

KWP = Keyword Protocol

| SPN | FMI | KWP | Description |
|--------|-----|------|--|
| 523717 | 12 | 125 | Timeout Error of CAN-Transmit-Frame AmbCon; Weather environments |
| 523718 | 3 | 1488 | SCR mainrelay; short circuit to battery (only CV56B) |
| 523718 | 4 | 1489 | SCR mainrelay; short circuit to ground (only CV56B) |
| 523718 | 5 | 1486 | SCR mainrelay; open load (only CV56B) |
| 523718 | 12 | 1487 | SCR mainrelay; powerstage over temperature (only CV56B) |
| 523766 | 9 | 281 | Timeout Error of CAN-Receive-Frame Active TSC1AE |
| 523767 | 9 | 282 | Timeout Error of CAN-Receive-Frame Passive TSC1AE |
| 523768 | 9 | 283 | Timeout Error of CAN-Receive-Frame Active TSC1AR |
| 523769 | 9 | 284 | Timeout Error of CAN-Receive-Frame Passive TSC1AR |
| 523770 | 9 | 285 | Timeout Error of CAN-Receive-Frame Passive TSC1DE |
| 523776 | 9 | 291 | Timeout Error of CAN-Receive-Frame TSC1TE - active |
| 523777 | 9 | 292 | Passive Timeout Error of CAN-Receive-Frame TSC1TE; Setpoint |
| 523778 | 9 | 293 | Active Timeout Error of CAN-Receive-Frame TSC1TR |
| 523779 | 9 | 294 | Passive Timeout Error of CAN-Receive-Frame TSC1TR |

| SPN | FMI | SPN | Description |
|--------|-----|------|---|
| 523788 | 12 | 299 | Timeout Error of CAN-Transmit-Frame TrbCH; Status Wastegate |
| 523793 | 9 | 202 | Timeout Error of CAN-Receive-Frame UAA10; AGS sensor service message |
| 523794 | 9 | 203 | Timeout Error of CAN-Receive-Frame UAA11; AGS sensor data |
| 523895 | 13 | 559 | Check of missing injector adjustment value programming (IMA) injector 1 (in firing order) |
| 523896 | 13 | 560 | check of missing injector adjustment value programming (IMA) injector 2 (in firing order) |
| 523897 | 13 | 561 | check of missing injector adjustment value programming (IMA) injector 3 (in firing order) |
| 523898 | 13 | 562 | check of missing injector adjustment value programming (IMA) injector 4 (in firing order) |
| 523910 | 6 | 1261 | Air Pump; over current |
| 523913 | 3 | 74 | Sensor error glow plug control diagnostic line voltage; signal range check high |
| 523913 | 4 | 75 | Sensor error glow plug control diagnostic line voltage; signal range check low |
| 523914 | 3 | 78 | Glow plug control; short circuit to battery |
| 523914 | 4 | 79 | Glow plug control; short circuit to ground |
| 523914 | 5 | 76 | Glow plug control; open load |
| 523914 | 5 | 1216 | Glow plug control release line; short circuit error |
| 523914 | 11 | 1217 | Glow plug control; internal error |
| 523914 | 12 | 77 | Glow plug control; powerstage over temperature |
| 523919 | 2 | 1378 | Sensor air pump airpressure; plausibility error |
| 523920 | 2 | 1379 | Sensor exhaust gas back pressure burner; plausibility error |

Deutz D 2.9 L4 Engine Fault Codes

SPN = Suspect Parameter Number

FMI = Failure Mode Identifier

KWP = Keyword Protocol

| SPN | FMI | KWP | Description |
|--------|-----|------|--|
| 523922 | 7 | 1262 | Burner Shut Off Valve; blocked closed |
| 523922 | 7 | 1264 | Burner Shut Off Valve; blocked closed |
| 523929 | 0 | 109 | Fuel Balance Control integrator injector 1 (in firing order); maximum value exceeded |
| 523929 | 1 | 115 | Fuel Balance Control integrator injector 1 (in firing order); minimum value exceeded |
| 523930 | 0 | 110 | Fuel Balance Control integrator injector 2 (in firing order); maximum value exceeded |
| 523930 | 1 | 116 | Fuel Balance Control integrator injector 2 (in firing order); minimum value exceeded |
| 523931 | 0 | 111 | Fuel Balance Control integrator injector 3 (in firing order); maximum value exceeded |
| 523931 | 1 | 117 | Fuel Balance Control integrator injector 3 (in firing order); minimum value exceeded |
| 523932 | 0 | 112 | Fuel Balance Control integrator injector 4 (in firing order); maximum value exceeded |
| 523932 | 1 | 118 | Fuel Balance Control integrator injector 4 (in firing order); minimum value exceeded |
| 523935 | 12 | 168 | Timeout Error of CAN-Transmit-Frame EEC3VOL1; Engine send messages |
| 523936 | 12 | 169 | Timeout Error of CAN-Transmit-Frame EEC3VOL2; Engine send messages |
| 523946 | 0 | 1158 | Zero fuel calibration injector 1 (in firing order); maximum value exceeded |

| SPN | FMI | KWP | Description |
|--------|-----|------|---|
| 523946 | 1 | 1164 | Zero fuel calibration injector 1 (in firing order); minimum value exceeded |
| 523947 | 0 | 1159 | Zero fuel calibration injector 2 (in firing order); maximum value exceeded |
| 523947 | 1 | 1165 | Zero fuel calibration injector 2 (in firing order); minimum value exceeded |
| 523948 | 0 | 1160 | Zero fuel calibration injector 3 (in firing order); maximum value exceeded |
| 523948 | 1 | 1166 | Zero fuel calibration injector 3 (in firing order); minimum value exceeded |
| 523949 | 0 | 1161 | Zero fuel calibration injector 4 (in firing order); maximum value exceeded |
| 523949 | 1 | 1167 | Zero fuel calibration injector 4 (in firing order); minimum value exceeded |
| 523960 | 0 | 1011 | Physical range check high for EGR cooler downstream temp. |
| 523960 | 0 | 1458 | High exhaust gas temperature EGR cooler downstream; warning threshold exceeded |
| 523960 | 1 | 1012 | Physical range check low for EGR cooler downstream temp. |
| 523960 | 1 | 1459 | High exhaust gas temperature EGR cooler downstream; shut off threshold exceeded |
| 523980 | 14 | 1187 | Bad quality of reduction agent detected |
| 523981 | 11 | 918 | Urea-tank without heating function (heating phase) |
| 523982 | 0 | 360 | Powerstage diagnosis disabled; high battery voltage |
| 523982 | 1 | 361 | Powerstage diagnosis disabled; low battery voltage |

Deutz D 2.9 L4 Engine Fault Codes

SPN = Suspect Parameter Number

FMI = Failure Mode Identifier

KWP = Keyword Protocol

| SPN | FMI | KWP | Description |
|--------|-----|------|---|
| 523988 | 3 | 1245 | Charging lamp; short circuit to battery |
| 523988 | 4 | 1246 | Charging lamp; short circuit to ground |
| 523988 | 5 | 1243 | Charging lamp; open load |
| 523988 | 12 | 1244 | Charging lamp; over temp. |
| 523998 | 4 | 1327 | Injector cylinder bank 2 slave; short circuit |
| 523999 | 12 | 1328 | Injector powerstage output Slave defect |
| 524014 | 1 | 1254 | Air pressure glow plug flush line; below limit |
| 524016 | 2 | 1259 | Amount of air is not plausible to pump speed |
| 524016 | 2 | 1260 | Calculated amount of air is not plausible to HFM reading |
| 524016 | 11 | 1258 | HFM sensor; electrical fault |
| 524021 | 11 | 1263 | Burner fuel line pipe leak behind Shut Off Valve |
| 524024 | 11 | 1302 | Deviation of the exhaust gas temp. setpoint to actual value downstream (DOC) too high |
| 524028 | 2 | 1431 | CAN message PROEGRActr; plausibility error |
| 524029 | 2 | 1432 | Timeout Error of CAN-Receive-Frame ComEGRActr - exhaust gas recirculation positioner |
| 524030 | 7 | 1440 | EGR actuator; internal error |
| 524031 | 13 | 1441 | EGR actuator; calibration error |

| SPN | FMI | KWP | Description |
|--------|-----|------|---|
| 524032 | 2 | 1442 | EGR actuator; status message EGRCust is missing |
| 524033 | 7 | 1443 | EGR actuator; due to overload in Save Mode |
| 524034 | 3 | 1438 | Disc separator; short circuit to battery |
| 524034 | 4 | 1439 | Disc separator; short circuit to ground |
| 524034 | 5 | 1436 | Disc Separator; open load |
| 524034 | 12 | 1437 | Disc Separator; powerstage over temperature |
| 524035 | 12 | 1341 | Injector diagnostics; time out error in the SPI communication |
| 524057 | 2 | 1505 | Electric fuel pump; fuel pressure build up error |
| 524097 | 9 | 1663 | Timeout error of CAN-Transmit-Frame DPFBnAirPmpCtl |
| 524098 | 9 | 1664 | Timeout error of CAN-Transmit-Frame ComDPFBnPT |
| 524099 | 9 | 1665 | Timeout error of CAN-Transmit-Frame ComDPFC1 |
| 524100 | 9 | 1666 | Timeout error of CAN-Transmit-Frame ComDPFHisDat |
| 524101 | 9 | 1667 | Timeout error of CAN-Transmit-Frame ComDPFTstMon |

Deutz D 2.9 L4 Engine Fault Codes

SPN = Suspect Parameter Number

FMI = Failure Mode Identifier

KWP = Keyword Protocol

| SPN | FMI | KWP | Description |
|--------|-----|------|---|
| 524102 | 9 | 1674 | Timeout error of CAN-Receive-Frame ComRxDPFBrnAirPmpCtl |
| 524103 | 9 | 1675 | Timeout error of CAN-Receive-Frame ComRxDPFBrnAirPmp |
| 524104 | 9 | 1676 | Timeout error of CAN-Receive-Frame ComRxDPFCtl |
| 524105 | 9 | 1668 | Timeout error of CAN-Transmit-Frame ComEGRMsFlw |
| 524106 | 9 | 1677 | Timeout error of CAN-Receive-Frame ComRxEGRMsfW1 |
| 524107 | 9 | 1678 | Timeout error of CAN-Receive-Frame ComRxEGRMsfW2 |
| 524108 | 9 | 1669 | Timeout error of CAN-Transmit-Frame ComEGRTVActr |
| 524109 | 9 | 1679 | Timeout error of CAN-Receive-Frame ComRxEGRTVActr |
| 524110 | 9 | 1670 | Timeout error of CAN-Transmit-Frame ComETVActr |
| 524111 | 9 | 1680 | Timeout error of CAN-Receive-Frame ComRxETVActr |
| 524112 | 9 | 1671 | Timeout ComlTVActr |
| 524113 | 9 | 1681 | Timeout error of CAN-Receive-Frame ComRxITVActr |

| SPN | FMI | KWP | Description |
|--------|-----|------|---|
| 524114 | 9 | 1659 | Timeout error of CAN-Transmit-Frame A1DOC |
| 524115 | 9 | 1660 | Timeout error of CAN-Transmit-Frame AT1S |
| 524116 | 9 | 1661 | Timeout error of CAN-Transmit-Frame SCR2 |
| 524117 | 9 | 1662 | Timeout error of CAN-Transmit-Frame SCR3 |
| 524118 | 9 | 1672 | Timeout error of CAN-Receive-Frame ComRxCM1 |
| 524119 | 9 | 1673 | Timeout error of CAN-Receive-Frame ComRxCustSCR3 |
| 524120 | 9 | 1682 | Timeout error of CAN-Receive-Frame ComRxSCRHtDiag |
| 524121 | 9 | 1683 | Timeout error of CAN-Receive-Frame ComRxTrbChActr |
| 524122 | 9 | 1684 | Timeout error of CAN-Receive-Frame ComRxUQSens |
| 524123 | 9 | 1685 | Timeout error of CAN-Receive-Frame ComSCRHtCtl |
| 524124 | 9 | 1686 | Timeout error of CAN-Receive-Frame ComTxAT1IMG |
| 524125 | 9 | 1687 | Timeout error of CAN-Receive-Frame ComTxTrbChActr |

Perkins 404F-E22T Engine Fault Codes

SPN = Suspect Parameter Number

FMI = Failure Mode Identifier

| SPN | FMI | Description |
|-----|-----|--|
| 29 | 3 | Accelerator Pedal Position 2: Voltage Above Normal |
| 29 | 4 | Accelerator Pedal Position 2: Voltage Below Normal |
| 91 | 3 | Accelerator Pedal Position 1: Voltage Above Normal |
| 91 | 4 | Accelerator Pedal Position 1: Voltage Below Normal |
| 100 | 1 | Engine Oil Pressure: Low- most severe (3) |
| 108 | 3 | Barometric Pressure: Voltage Above Normal |
| 108 | 4 | Barometric Pressure: Voltage Below Normal |
| 110 | 3 | Engine Coolant Temperature: Voltage Above Normal |
| 110 | 4 | Engine Coolant Temperature: Voltage Below Normal |
| 110 | 15 | Engine Coolant Temperature: High - least severe (1) |
| 168 | 0 | Battery Potential/ Power Input 1: High- most severe (3) |
| 168 | 3 | Battery Potential/ Power Input 1: Voltage Above Normal |
| 168 | 4 | Battery Potential/ Power Input 1: Voltage Below Normal |
| 172 | 3 | Engine Air Inlet Temperature: Voltage Above Normal |
| 172 | 4 | Engine Air Inlet Temperature: Voltage Below Normal |
| 190 | 0 | Engine Speed: High- most severe (3) |
| 190 | 8 | Engine Speed: Abnormal Frequency, Pulse Width or Period |
| 558 | 3 | Accelerator Pedal1 Low Idle Switch: Voltage Above Normal |
| 558 | 4 | Accelerator Pedal1 Low Idle Switch: Voltage Below Normal |
| 638 | 6 | Engine Fuel Rack Actuator: Current Above Normal |
| 639 | 14 | J1939 Network#1: Special Instruction |

| SPN | FMI | Description |
|------|-----|---|
| 723 | 3 | Engine Speed Sensor #2: Voltage Above Normal |
| 723 | 4 | Engine Speed Sensor #2: Voltage Below Normal |
| 723 | 8 | Engine Speed Sensor#2: Abnormal Frequency, Pulse Width or Period" |
| 723 | 10 | Engine Speed Sensor #2: Abnormal Rate of Change |
| 733 | 3 | Engine Rack Position Sensor: Voltage Above Normal |
| 733 | 4 | Engine Rack Position Sensor: Voltage Below Normal |
| 1485 | 7 | ECU Main Relay: Not Responding Property |
| 2840 | 11 | ECU Instance: Other Failure Mode |
| 2840 | 12 | ECU Instance: Failure |
| 2840 | 13 | ECU Instance: Out of Calibration |
| 2970 | 3 | Accelerator Pedal 2 Low Idle Switch: Voltage Above Normal |
| 2970 | 4 | Accelerator Pedal 2 Low Idle Switch: Voltage Below Normal |
| 3241 | 1 | Exhaust Gas Temperature 1: Low- most severe (3) |
| 3241 | 3 | Exhaust Gas Temperature 1: Voltage Above Normal |
| 241 | 4 | Exhaust Gas Temperature 1: Voltage Below Normal |
| 3241 | 15 | Exhaust Gas Temperature 1: High- least severe (1) |
| 3241 | 16 | Exhaust Gas Temperature 1: High- moderate severity (2) |
| 3242 | 1 | Particulate Trap Intake Gas Temp: Low- most severe (3)" |
| 3242 | 3 | Particulate Trap Intake Gas Temp: Voltage Above Normal" |
| 3242 | 4 | Particulate Trap Intake Gas Temp: Voltage Below Normal" |
| 3242 | 15 | Particulate Trap Intake Gas Temp: High - least severe (1)" |
| 3242 | 16 | Particulate Trap Intake Gas Temp: High-moderate severity (2) |

Perkins 404F-E22T Engine Fault Codes

SPN = Suspect Parameter Number

FMI = Failure Mode Identifier

| SPN | FMI | Description |
|------|-----|--|
| 3251 | 3 | Particulate Trap Differential Pressure: Voltage Above Normal |
| 3251 | 4 | Particulate Trap Differential Pressure: Voltage Below Normal |
| 3473 | 7 | Aftertreatment #1 Failed to Ignite: Not Responding Properly |
| 3473 | 11 | Aftertreatment #1 Failed to Ignite: Other Failure Mode |
| 3484 | 0 | Aftertreatment #1 Ignition: High-most severe (3) |
| 3484 | 3 | Aftertreatment #1 Ignition: Voltage Above Normal |
| 3484 | 4 | Aftertreatment #1 Ignition: Voltage Below Normal |
| 3556 | 6 | Aftertreatment 1 Hydrocarbon Doser 1: Current Above Normal |
| 3610 | 3 | Diesel Particulate Filter Outlet Pressure or 1: Voltage Above Normal" |
| 3610 | 4 | Diesel Particulate Filter Outlet Pressure Sensor 1: Voltage Below Normal |
| 3713 | 7 | DPF Active Regeneration Inhibited Due to System Timeout: Not Responding Properly |
| 3713 | 31 | DPF Active Regeneration Inhibited Due to System Timeout |
| 3719 | 0 | Particulate Trap #1 Soot Load Percent: High- most severe (3) |
| 3719 | 16 | Particulate Trap #1 Soot Load Percent: High-moderate severity (2) |
| 4016 | 6 | High Current Auxiliary Power Relay 1: Current Above Normal |
| 4201 | 3 | Engine Speed Sensor #1: Voltage Above Normal |

| SPN | FMI | Description |
|------|-----|--|
| 4201 | 4 | Engine Speed Sensor #1: Voltage Below Normal |
| 4201 | 8 | Engine Speed Sensor #1: Abnormal Frequency, Pulse Width, or Period |
| 4201 | 10 | Engine Speed Sensor #1: Abnormal Rate of Change |
| 4765 | 1 | Aftertreatment #1 Diesel Oxidation Catalyst Intake Gas Temperature: Low-most severe (3) |
| 4765 | 3 | Aftertreatment #1 Diesel Oxidation Catalyst Intake Gas Temperature: Voltage Above Normal |
| 4765 | 4 | Aftertreatment #1 Diesel Oxidation Catalyst Intake Gas Temperature: Voltage Below Normal |
| 4765 | 15 | Aftertreatment #1 Diesel Oxidation Catalyst Intake Gas Temperature: High-least severe (1) |
| 4765 | 16 | Aftertreatment #1 Diesel Oxidation Catalyst Intake Gas Temperature: High-moderate severity (2) |
| 5487 | 3 | Aftertreatment 1 Burner Unit Combustion Chamber Temperature: Voltage Above Normal |
| 5487 | 4 | Aftertreatment 1 Burner Unit Combustion Chamber Temperature: Voltage Below Normal |
| 6581 | 6 | Aftertreatment 1 Hydrocarbon Doser 2: Current Above Normal |

Fault Codes

How to Retrieve Ford Engine Fault Codes

The ECM constantly monitors the engine by the use of sensors on the engine. The ECM also uses signals from the sensors to initiate sequential fuel injection and make constant and instantaneous changes to ignition timing, fuel delivery and throttle position to maintain the engine's running condition at its highest efficiency while at the same time keeping exhaust emissions to a minimum. When a sensor fails or returns signals that are outside of set parameters, the ECM will store a fault code in memory that relates to the appropriate sensor and will turn on the Check Engine Light.

Note: Perform this procedure with the key switch in the off position.

- 1 Open the ground controls side cover and locate the run/test toggle switch on the side of the ground control box.
- 2 Pull out the red Emergency Stop button to the on position at both the ground and platform controls.
- 3 Move and hold the run/test toggle switch to the test position.
- ⦿ Result: The check engine light should turn on. The check engine light should begin to blink.
- 4 Continue to hold the run/test toggle switch in the test position and count the blinks.

Note: Before the fault codes are displayed, the check engine light will blink a code 1-6-5-4 three times. After the fault codes, the check engine light will blink a code 1-6-5-4 three times again indicating the end of the stored codes.

Note: If any fault codes are present, the ECM will blink a three digit code three times for each code stored in memory. It will blink the first digit of a three digit code, pause, blink the second digit, pause, and then blink the third digit. For example: the check engine light blinks 5 consecutive times, blinks 3 times and then 1 time. That would indicate code 531.

Note: Once a fault code has been retrieved and the repair has been completed, the ECM memory must be reset to clear the fault code from the ECM. Refer to Fault Codes Procedure, *How to Clear Engine Fault Codes from the ECM*.

How to Clear Engine Fault Codes from the ECM

Note: Perform this procedure with the engine off and the key switch in the off position.

- 1 Open the engine side turntable cover and locate the battery.
- 2 Disconnect the negative battery cable from the battery for a minimum of 5 minutes.

⚠ WARNING

Electrocution/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

- 3 Connect the negative battery cable to the battery.

Fault Codes

| Code | Description |
|------|------------------------------------|
| 16 | Never crank synced at start |
| 91 | FP low voltage |
| 92 | FP high voltage |
| 107 | MAP Low Voltage |
| 108 | MAP High Pressure |
| 111 | IAT higher than expected 1 |
| 112 | IAT low voltage |
| 113 | IAT high voltage |
| 116 | ECT higher than expected 1 |
| 117 | ECT/CHT Low Voltage |
| 118 | ECT/CHT High Voltage |
| 121 | TPS1 lower than TPS2 |
| 122 | TPS1 low voltage |
| 123 | TPS1 high voltage |
| 127 | IAT higher than expected 2 |
| 129 | BP low pressure |
| 134 | EGO open/lazy pre-cat 1 |
| 140 | EGO open/lazy post-cat 1 |
| 154 | EGO open/lazy pre-cat 2/post-cat 1 |
| 160 | EGO open/lazy post-cat 2 |
| 171 | AL high gasoline bank1 |
| 172 | AL low gasoline bank1 |
| 174 | AL high gasoline bank2 |
| 175 | AL low gasoline bank2 |
| 182 | FT Gasoline Low Voltage |
| 183 | FT Gasoline High Voltage |
| 187 | FT Gaseous fuel low voltage |
| 188 | FT Gaseous fuel high voltage |
| 217 | ECT higher than expected 2 |
| 219 | Max govern speed override |
| 221 | TPS1 higher than TPS2 |
| 222 | TPS2 low voltage |
| 223 | TPS2 high voltage |
| 236 | TIP Active |

| Code | Description |
|------|---|
| 237 | TIP Low Voltage |
| 238 | TIP High Voltage |
| 261 | Injector Loop Open or Low-side short to Ground |
| 262 | Injector Coil Shorted |
| 264 | Injector Loop Open or Low-side short to Ground |
| 265 | Injector Coil Shorted |
| 267 | Injector Loop Open or Low-side short to Ground |
| 268 | Injector Coil Shorted |
| 270 | Injector Loop Open or Low-side short to Ground |
| 271 | Injector Coil Shorted |
| 273 | Injector Loop Open or Low-side short to Ground |
| 274 | Injector Coil Shorted |
| 276 | Injector Loop Open or Low-side short to Ground |
| 277 | Injector Coil Shorted |
| 279 | Injector Loop Open or Low-side short to Ground |
| 280 | Injector Coil Shorted |
| 282 | Injector Loop Open or Low- side short to Ground |
| 283 | Injector Coil Shorted |
| 285 | Injector Loop Open or Low-side short to Ground |
| 286 | Injector Coil Shorted |
| 288 | Injector Loop Open or Low-side short to Ground |
| 289 | Injector Coil Shorted |

Ford MSG-425 EFI Diagnostic Manual

Genie part number

162067GT

Fault Codes

| Code | Description |
|------|--|
| 301 | Emissions/catalyst damaging misfire |
| 302 | Emissions/catalyst damaging misfire |
| 303 | Emissions/catalyst damaging misfire |
| 304 | Emissions/catalyst damaging misfire |
| 305 | Emissions/catalyst damaging misfire |
| 306 | Emissions/catalyst damaging misfire |
| 307 | Emissions/catalyst damaging misfire |
| 308 | Emissions/catalyst damaging misfire |
| 326 | Knock 1 Excessive Signal |
| 327 | Knock 1 sensor Open |
| 331 | Knock 2 Excessive Signal |
| 332 | Knock 2 sensor Open |
| 336 | Crank sync noise |
| 337 | Crank loss |
| 341 | Cam sync noise |
| 342 | Cam loss |
| 420 | Gasoline cat monitor |
| 430 | Gasoline cat monitor |
| 524 | Oil pressure low |
| 562 | Battery Voltage Low |
| 563 | Battery Voltage High |
| 601 | Flash checksum invalid |
| 604 | RAM failure |
| 606 | COP failure |
| 615 | Start relay coil open |
| 616 | Start relay control ground short |
| 617 | Start relay coil short to power |
| 627 | Fpump relay coil open |
| 628 | FPump motor loop open or high-side shorted to ground |
| 628 | Fpump relay control ground short |
| 629 | FPump motor high-side shorted to power |
| 629 | Fpump relay coil short to power |

| Code | Description |
|------|---|
| 642 | 5VE1 low voltage |
| 643 | 5VE1 high voltage |
| 650 | MIL open |
| 652 | 5VE2 low voltage |
| 653 | 5VE2 high voltage |
| 685 | Relay Coil Open |
| 686 | Relay Control ground short |
| 687 | Relay coil short to power |
| 1111 | Fuel rev limit |
| 1112 | Spark rev limit |
| 1121 | FPP1/2 simultaneous voltages out of range |
| 1122 | FPP1/2 do not match each other or the IVS |
| 1151 | CL high LPG |
| 1152 | CL low LPG |
| 1153 | CL high NG |
| 1154 | CL low NG |
| 1155 | CL high gasoline bank1 |
| 1156 | CL low gasoline bank1 |
| 1157 | CL high gasoline bank2 |
| 1158 | CL low gasoline bank2 |
| 1161 | AL high LPG |
| 1162 | AL low LPG |
| 1163 | AL high NG |
| 1164 | AL low NG |
| 1165 | LPG cat monitor |
| 1166 | NG cat monitor |
| 1171 | Megajector delivery pressure higher than expected |
| 1172 | Megajector delivery pressure lower than expected |

Ford MSG-425 EFI Diagnostic Manual

Genie part number

162067GT



Fault Codes

| Code | Description |
|------|---|
| 1173 | Megajector comm lost |
| 1174 | Megajector voltage supply high |
| 1175 | Megajector voltage supply low |
| 1176 | Megajector internal actuator fault detection |
| 1177 | Megajector internal circuitry fault detection |
| 1178 | Megajector internal comm fault detection |
| 1311 | Misfire detected |
| 1312 | Misfire detected |
| 1313 | Misfire detected |
| 1314 | Misfire detected |
| 1315 | Misfire detected |
| 1316 | Misfire detected |
| 1317 | Misfire detected |
| 1318 | Misfire detected |
| 1511 | AUX analog PU1 high |
| 1512 | AUX analog PU1 low |
| 1513 | AUX analog PU2 high |
| 1514 | AUX analog PU2 low |
| 1515 | AUX analog PD1 high |
| 1516 | AUX analog PD1 low |
| 1517 | AUX analog PU3 high |
| 1518 | AUX analog PU3 low |
| 1521 | CHT higher than expected 1 |
| 1522 | CHT higher than expected 2 |
| 1531 | IVS/Brake/Trans-Park interlock failure |
| 1541 | AUX analog PUD1 high |
| 1542 | AUX analog PUD1 low |
| 1543 | AUX analog PUD2 high |
| 1544 | AUX analog PUD2 low |
| 1545 | AUX analog PUD3 high |

| Code | Description |
|------|-----------------------------------|
| 1551 | AUX DIG1 high |
| 1552 | AUX DIG1 low |
| 1553 | AUX DIG2 high |
| 1554 | AUX DIG2 low |
| 1555 | AUX DIG3 high |
| 1556 | AUX DIG3 low |
| 1561 | AUX analog PD2 high |
| 1562 | AUX analog PD2 low |
| 1563 | AUX analog PD3 high |
| 1564 | AUX analog PD3 low |
| 1611 | 5VE 1/2 simultaneous out of range |
| 1612 | RTI 1 loss |
| 1613 | RTI 2 loss |
| 1614 | RTI 3 loss |
| 1615 | A/D loss |
| 1616 | Invalid interrupt |
| 1621 | Rx Inactive |
| 1622 | Rx Noise |
| 1623 | Invalid Packet Format |
| 1624 | Shutdown Request |
| 1625 | Shutdown Request |
| 1626 | CAN Tx failure |
| 1627 | CAN Rx failure |
| 1628 | CAN addresss conflict failure |

Ford MSG-425 EFI Diagnostic Manual

Genie part number

162067GT

Fault Codes

| Code | Description |
|------|--|
| 1629 | J1939 TSC1 message receipt lost |
| 1630 | J1939 ETC message receipt lost |
| 1631 | PWM1-Gauge1 open / ground short |
| 1632 | PWM1-Gauge1 short to power |
| 1633 | PWM2-Gauge2 open /ground short |
| 1634 | PWM2-Gauge2 short to power |
| 1635 | PWM3-Gauge3 open / ground short |
| 1636 | PWM3-Gauge3 short to power |
| 1641 | Buzzer control ground short |
| 1642 | Buzzer open |
| 1643 | Buzzer control short to power |
| 1644 | MIL control ground short |
| 1645 | MIL control short to power |
| 2111 | Unable to reach lower TPS |
| 2112 | Unable to reach higher TPS |
| 2115 | FPP1 higher than IVS limit |
| 2116 | FPP2 higher than IVS limit |
| 2120 | FPP1 invalid voltage and FPP2 disagrees with IVS |
| 2121 | FPP1 lower than FPP2 |
| 2122 | FPP1 high voltage |
| 2123 | FPP1 low voltage |
| 2125 | FPP2 invalid voltage and FPP1 disagrees with IVS |
| 2126 | FPP1 higher than FPP2 |
| 2127 | FPP2 low voltage |
| 2128 | FPP2 high voltage |

| Code | Description |
|------|---|
| 2130 | IVS stuck at-idle, FPP1/2 match |
| 2131 | IVS stuck off-idle, FPP1/2 match |
| 2135 | TPS1/2 simultaneous voltages out of range |
| 2139 | FPP1 lower than IVS limit |
| 2140 | FPP2 lower than IVS limit |
| 2229 | BP high pressure |
| 2300 | Primary Loop Open or Low-side Short to Ground |
| 2301 | Primary Coil Shorted |
| 2303 | Primary Loop Open or Low-side Short to Ground |
| 2304 | Primary Coil Shorted |
| 2306 | Primary Loop Open or Low-side Short to Ground |
| 2307 | Primary Coil Shorted |
| 2309 | Primary Loop Open or Low-side Short to Ground |
| 2310 | Primary Coil Shorted |
| 2312 | Primary Loop Open or Low-side Short to Ground |
| 2313 | Primary Coil Shorted |
| 2315 | Primary Loop Open or Low-side Short to Ground |
| 2316 | Primary Coil Shorted |
| 2318 | Primary Loop Open or Low-side Short to Ground |
| 2319 | Primary Coil Shorted |
| 2321 | Primary Loop Open or Low-side Short to Ground |
| 2322 | Primary Coil Shorted |
| 2618 | Tach output ground short |
| 2619 | Tach output short to power |

Ford MSG-425 EFI Diagnostic Manual

Genie part number

162067GT



Schematics



Observe and Obey:

- ☑ Troubleshooting and repair procedures shall be completed by a person trained and qualified on the repair of this machine
- ☑ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☑ Repair any machine damage or malfunction before operating the machine.

Before Troubleshooting:

- ☑ Read, understand and obey the safety rules and operating instructions in the appropriate operator's manual on your machine.
- ☑ Be sure that all necessary tools and test equipment are available and ready for use.

About This Section

There are two groups of schematics in this section.

Electrical Schematics

⚠ WARNING




































Electrocution/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

Hydraulic Schematics

























⚠ WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.


Electrical Symbol Legend

| | | | | |
|---|---|---|---|---|
|  |  |  |  |  |
| Battery | Coil, solenoid or relay | Horn or alarm | Flashing beacon | Gauge |
|  |  |  |  |  |
| Diode | Hour meter | LED | Fuse with amperage | Foot switch |
|  |  |  |  |  |
| T-circuits connect | Limit Switch | Power relay | Coil with suppression | Fuel or RPM solenoid |
|  |  |  |  |  |
| Connection - no terminal | T-circuits connect at terminal | Circuits crossing no connection | Quick disconnect terminal | Circuit breaker with amperage |
|  |  |  |  |  |
| Key switch | Toggle Switch DPDT | Toggle Switch SPDT | Pump or Motor | Tilt sensor |
|  |  |  |  |  |
| Horn button - normally open | Emergency Stop button - normally closed | Resistor with ohm value | Battery separator | Gauge sending unit |
|  |  |  |  |  |
| Oil temperature switch normally open | Coolant temperature switch - normally open | Oil pressure switch normally closed | Control relay contact normally open | Diode starting aid, glow plug or flame ignitor |

Hydraulic Symbols Legend

| | | | |
|---|---|--|---|
|  |  |  |  |
| Orifice with size | Check valve | Shut off valve | Brake |
|  |  |  |  |
| Pump, fixed displacement | Pump, bi-directional variable displacement | Motor, bi-directional | Motor, 2 speed bi-directional |
|  |  |  |  |
| Cylinder, double acting | Pump, prime mover (engine or motor) | Shuttle valve, 2 position, 3 way | Differential sensing valve |
|  |  |  |  |
| Filter with bypass relief valve | Relief valve with pressure setting 200 psi 13.8 bar | Priority flow regulator valve | Solenoid operated proportional valve |
|  |  |  |  |
| Directional valve (mechanically activated) | Flow divider/combiner valve | Pilot operated 3 position, 3 way shuttle valve | Solenoid operated 2 position, 3 way directional valve |
|  |  |  |  |
| Counterbalance valve with pressure and pilot ratio 3000 psi 206.8 bar 3:1 | Solenoid operated 3 position 4 way directional valve | Solenoid operated 3 position, 4 way proportional directional valve | Solenoid valve, 2 position 2 way |

Limit Switch Location Legend



- 1 S24
- 2 LS1, LS5
- 3 LS2
- 4 LS4

- 5 S8
- 6 LS3

Limit Switches and Sensors

| | |
|-----|--|
| S24 | Platform overload sensor |
| LS1 | Limit switch boom fully retracted operational, 40pin connector |
| LS5 | Limit switch boom fully retracted safety, 2 pin connector |
| LS2 | Limit switch primary boom angle |
| LS4 | Limit switch secondary boom angle |
| S8 | Turntable tilt sensor |
| LS3 | Limit switch turntable |

Electrical Component and Wire Color Legends

| Item | Description |
|-----------|---|
| B | Battery |
| B1 | Engine Start - 12V DC |
| C | Connector |
| C7 | Power to platform, 12v cable connector |
| C9 | Foot switch input connector |
| C54 | Options connector |
| CB | Circuit Breaker |
| CB1 | Circuit breaker, engine, 15a |
| CB2 | Circuit breaker, controls, 15a |
| CB7 | Circuit breaker, controls, 10a Engine throttle solenoid |
| CR | Control Relay |
| CR1 | Start relay |
| CR2 | Ignition power relay |
| CR4 | High idle relay |
| CR5 | Horn relay |
| CR13 | Jib relay (jib option) |
| CR14 | Jib relay (jib option) |
| CR17 | Hydraulic oil cooling fan (option) |
| CR23 | Drive light enable |
| CR27 | Brake circuit relay (lift/drive option) |
| CR30 | Limit switch relay (lift/drive option) |
| CR76 | Load sense aux recovery (AS models) |
| CR51 | Aircraft package (option) |
| G | Gauge |
| G1 | Battery Charge Indicator |
| G2 | Engine oil pressure |
| G3 | Engine coolant temp. |
| G4 | Engine oil temp. |
| G6 | Hour meter |

| Item | Description |
|-----------|---|
| H | Horn or Alarm |
| H1 | Tilt/load sense alarm |
| H4 | Descent (ground) |
| H6 | Load sense (ground) |
| JC | Joystick |
| JC1 | Boom proportional joystick: secondary boom up/down |
| JC2 | Boom proportional joystick: primary up/down, turntable rotate |
| JC3 | Drive proportional joystick |
| KS | Key switch |
| KS1 | Key switch |
| L | LED or Light |
| L1 | Drive enable led |
| L2 | Check engine led |
| L4 | Platform overload led (ce only) |
| L29 | Drive lights |
| L48 | Tilt alarm led (ansi/csa only) |
| LS | Limit Switch |
| LS1 | Primary boom retracted operational |
| LS5 | Primary boom retracted safety |
| LS2 | Primary boom up |
| LS3 | Drive enable |
| LS4 | Secondary boom up |

Electrical Component and Wire Color Legends

| Item | Description |
|-----------|--|
| M | Motor |
| M2 | Auxiliary pump |
| M3 | Engine starter |
| M4 | Fuel pump |
| P | Button |
| P1 | Red emergency stop button |
| P2 | Emergency stop button |
| P3 | Horn Button |
| P4 | Function enable button |
| PR | Power Relay |
| PR1 | Auxiliary pump (m2) |
| PR2 | Engine starter (m3) |
| PR3 | Starting aid / glow plugs |
| PR4 | Function pump (m5) |
| R | Resistor |
| R4 | Speed limiting variable resistor 20 ohms |
| R14 | Up/down speed resistor 7.5 ohms |
| SW | Switch |
| SW2 | Engine oil pressure |
| SW3 | Engine oil temperature |

| Item | Description |
|-----------|---|
| TS | Toggle Switch |
| TS1 | Auxiliary pump switch |
| TS2 | Start engine switch |
| TS3 | Fuel select switch (ford efi only) |
| TS4 | Hi/low rpm switch |
| TS6 | Glow plug switch |
| TS7 | Platform rotate switch |
| TS8 | Jib rotate switch (jib option) |
| TS9 | Platform level switch |
| TS13 | Primary boom extend/retract switch |
| TS14 | Drive speed switch |
| TS15 | Drive enable switch |
| TS43 | Heater switch (option) |
| TS46 | Proximity kill switch (option) |
| TS47 | Generator switch (option) |
| TS51 | Auxiliary pump toggle switch |
| TS52 | Engine start toggle switch |
| TS53 | Fuel select toggle switch |
| TS54 | Rpm select toggle switch |
| TS56 | Glow plug toggle switch |
| TS57 | Platform rotate toggle switch |
| TS58 | Jib boom up/down toggle switch (option) |
| TS59 | Platform level up/down toggle switch |
| TS60 | Secondary boom up/down toggle switch |
| TS61 | Primary boom up/down toggle switch |
| TS62 | Turntable rotate toggle switch |
| TS63 | Primary boom extend/retract toggle switch |
| TS64 | Run/test toggle switch (Ford) |
| TS74 | Run/test toggle switch (Deutz) |

Electrical Component and Wire Color Legends

| Item | Description |
|----------|-----------------------------------|
| U | Module |
| U1 | Ignition start module |
| U4 | EDC - drive pump |
| U13 | Alc 500 joystick controller card |
| U18 | Control module |
| U33 | Load sense module |
| U34 | Time delay relay - 2 seconds, 10A |
| U35 | Time delay relay |
| U38 | Time delay relay |
| U39 | J1939 Ground Control Box Display |
| X | ALC500 connectors |
| X101 | ALC500 power connector |
| X101 | ALC500 input/out connectors |
| X102 | ALC500 input/out connectors |
| X103 | ALC500 input/out connectors |
| X104 | ALC500 input/out connectors |
| X105 | ALC500 input/out connectors |
| X106 | ALC500 input/out connectors |
| X107 | ALC500 input/out connectors |
| X108 | ALC500 input/out connectors |
| X109 | ALC500 input/out connectors |
| X1-4 | Circuit splice |


| Wire Color Legend | |
|-------------------|--------------|
| Item | Description |
| BL | Blue |
| BK | Black |
| BR | Brown |
| GN | Green |
| OR | Orange |
| PP | Purple |
| RD | Red |
| WH | White |
| YL | Yellow |
| BL/RD | Blue/Red |
| BL/WH | Blue/White |
| BK/RD | Black/Red |
| OR/WH | Orange/White |
| RD/BK | Red/Black |
| RD/WH | Red/White |
| WH/BL | White/Blue |
| WH/BK | White/Black |
| WH/RD | White/Red |
| WH/YL | White/Yellow |
| YL/BK | Yellow/Black |

Hour Meter Legend

The hour meter (HCON) displays the SCON software version upon startup for 5 seconds.

Under normal operation the display will sequence between engine hours and battery voltage every 5 seconds.


Active platform overload fault codes are also displayed.




- 1 LCD display
- 2 red LED - fault indicator
- 3 yellow LED - battery indicator
- 4 green LED - engine hours indicator
- 5 8 pin connector

| 8 Pin Connector | | |
|-----------------|-----------------|------------|
| Pin number | Circuit | Wire color |
| 1 | CAN High | Yellow |
| 2 | CAN Low | Green |
| 3 | 12V (B+) Heater | Red |
| 4 | Not Used | |
| 5 | 12V (B+) | Red |
| 6 | Not Used | |
| 7 | Not Used | |
| 8 | Ground (B-) | Brown |


Electrical Schematic, Ford MSG425




Electrical Schematic, Ford MSG425




Electrical Schematic, Deutz D2011 L03i and Perkins 404D-22



Electrical Schematic, Deutz D2011 L03i and Perkins 404D-22




Electrical Schematic, Deutz D 2.9 L4




The diagram is a complex electrical wiring schematic for a vehicle, organized into a grid with letters A-M across the top and numbers 1-8 down the right side. It shows the following components and connections:

- Power Sources:** A 12V DC battery (B1) and an alternator (ES0590E) are connected to the main power lines.
- Engine and Fuel System:** Includes the engine start relay (CR54), fuel pump relay (CR55), and various sensors like the engine speed sensor (TS4) and footswitch high sensor (D12).
- Lighting and Horn:** Shows connections for the horn (D108), headlights (D109), and various indicator lights (D13, D11, D12).
- Relays and Switches:** Numerous relays are shown, including the engine start relay (CR54), fuel pump relay (CR55), and various control relays (CR56, CR57, CR58, CR59, CR60, CR61, CR62, CR63, CR64, CR65, CR66, CR67, CR68, CR69, CR70, CR71, CR72, CR73, CR74, CR75, CR76, CR77, CR78, CR79, CR80, CR81, CR82, CR83, CR84, CR85, CR86, CR87, CR88, CR89, CR90, CR91, CR92, CR93, CR94, CR95, CR96, CR97, CR98, CR99, CR100).
- Sensors and Actuators:** Includes the engine speed sensor (TS4), footswitch high sensor (D12), and various other sensors and actuators.
- Wiring and Terminals:** The diagram shows a dense network of wires connecting various components, with many terminals labeled (e.g., TB20, TB21, TB22, TB23, TB24, TB25, TB26, TB27, TB28, TB29, TB30, TB31, TB32, TB33, TB34, TB35, TB36, TB37, TB38, TB39, TB40, TB41, TB42, TB43, TB44, TB45, TB46, TB47, TB48, TB49, TB50, TB51, TB52, TB53, TB54, TB55, TB56, TB57, TB58, TB59, TB60, TB61, TB62, TB63, TB64, TB65, TB66, TB67, TB68, TB69, TB70, TB71, TB72, TB73, TB74, TB75, TB76, TB77, TB78, TB79, TB80, TB81, TB82, TB83, TB84, TB85, TB86, TB87, TB88, TB89, TB90, TB91, TB92, TB93, TB94, TB95, TB96, TB97, TB98, TB99, TB100).

Engine Wire Harness, Deutz D 2.9 L4




Engine Wire Harness, Deutz D 2.9 L4




Electrical Schematic, Deutz TD 2.2 L3



Electrical Schematic, Deutz TD 2.2 L3




Engine Wire Harness, Deutz TD 2.2 L3 - Page 1




ES0590E


Engine Wire Harness, Deutz TD 2.2 L3 - Page 1




Engine Wire Harness, Deutz TD 2.2 L3 - Page 2



Engine Wire Harness, Deutz TD 2.2 L3 - Page 2



Electrical Schematic, Perkins 404F-E22T




The diagram is a complex electrical wiring schematic for a vehicle, organized into a grid with letters A-M across the top and numbers 1-8 down the right side. It details the electrical connections for various components, including the battery, alternator, engine, and various sensors and relays.


Key Components and Connections:

- Battery and Power Distribution:** The battery (ES0590E) is connected to the main power rail. The alternator (P20BAT RD) provides charging power. The diagram shows the distribution of power to various components, including the engine, fuel system, and lighting.
- Engine and Fuel System:** The engine (ENGINE START) is connected to the main power rail. The fuel system (P24FS RD/WH) is connected to the engine. The diagram shows the control logic for the engine and fuel system, including the use of relays and sensors.
- Sensors and Relays:** The diagram includes numerous sensors and relays, such as the C21IGN WH (ignition switch), C22TEL BL (telephone line), C23REL BK/WH (relay), C24REL BK/WH (relay), C25REL BK/WH (relay), C26REL BK/WH (relay), C27REL BK/WH (relay), C28REL BK/WH (relay), C29REL BK/WH (relay), C30REL BK/WH (relay), C31REL BK/WH (relay), C32REL BK/WH (relay), C33REL BK/WH (relay), C34REL BK/WH (relay), C35REL BK/WH (relay), C36REL BK/WH (relay), C37REL BK/WH (relay), C38REL BK/WH (relay), C39REL BK/WH (relay), C40REL BK/WH (relay), C41REL BK/WH (relay), C42REL BK/WH (relay), C43REL BK/WH (relay), C44REL BK/WH (relay), C45REL BK/WH (relay), C46REL BK/WH (relay), C47REL BK/WH (relay), C48REL BK/WH (relay), C49REL BK/WH (relay), C50REL BK/WH (relay), C51REL BK/WH (relay), C52REL BK/WH (relay), C53REL BK/WH (relay), C54REL BK/WH (relay), C55REL BK/WH (relay), C56REL BK/WH (relay), C57REL BK/WH (relay), C58REL BK/WH (relay), C59REL BK/WH (relay), C60REL BK/WH (relay), C61REL BK/WH (relay), C62REL BK/WH (relay), C63REL BK/WH (relay), C64REL BK/WH (relay), C65REL BK/WH (relay), C66REL BK/WH (relay), C67REL BK/WH (relay), C68REL BK/WH (relay), C69REL BK/WH (relay), C70REL BK/WH (relay), C71REL BK/WH (relay), C72REL BK/WH (relay), C73REL BK/WH (relay), C74REL BK/WH (relay), C75REL BK/WH (relay), C76REL BK/WH (relay), C77REL BK/WH (relay), C78REL BK/WH (relay), C79REL BK/WH (relay), C80REL BK/WH (relay), C81REL BK/WH (relay), C82REL BK/WH (relay), C83REL BK/WH (relay), C84REL BK/WH (relay), C85REL BK/WH (relay), C86REL BK/WH (relay), C87REL BK/WH (relay), C88REL BK/WH (relay), C89REL BK/WH (relay), C90REL BK/WH (relay), C91REL BK/WH (relay), C92REL BK/WH (relay), C93REL BK/WH (relay), C94REL BK/WH (relay), C95REL BK/WH (relay), C96REL BK/WH (relay), C97REL BK/WH (relay), C98REL BK/WH (relay), C99REL BK/WH (relay), C100REL BK/WH (relay).
- Wiring and Terminals:** The diagram shows the wiring for various terminals, including TB20, TB24, TB25, TB26, TB27, TB28, TB29, TB30, TB31, TB32, TB33, TB34, TB35, TB36, TB37, TB38, TB39, TB40, TB41, TB42, TB43, TB44, TB45, TB46, TB47, TB48, TB49, TB50, TB51, TB52, TB53, TB54, TB55, TB56, TB57, TB58, TB59, TB60, TB61, TB62, TB63, TB64, TB65, TB66, TB67, TB68, TB69, TB70, TB71, TB72, TB73, TB74, TB75, TB76, TB77, TB78, TB79, TB80, TB81, TB82, TB83, TB84, TB85, TB86, TB87, TB88, TB89, TB90, TB91, TB92, TB93, TB94, TB95, TB96, TB97, TB98, TB99, TB100.


Engine Wire Harness, Perkins 404F-E22T



Engine Wire Harness, Perkins 404F-E22T




Electrical Schematic, Function Controls - ANSI / CSA




[illegible]


Electrical Schematic, Function Controls - CE




Electrical Schematic, Function Controls - CE




Electrical Schematic, Platform Overload



Electrical Schematic, Platform Overload




Electrical Schematic, Options Wiring Diagram




ES0590E

Electrical Schematic, Options Wiring Diagram



**Ground Control Box Switch Panel Wiring Diagram,
Deutz D2011L03i and Perkins 404D - ANSI / CSA**




This wiring diagram illustrates the electrical system for a vehicle, organized by column (A-M) and row (1-8). The diagram shows the following components and their interconnections:


- Column A:** CHECK ENGINE LED L2, CIRCUIT BREAKER ENGINE 15A CB1, HOUR METER C61, STOP SWITCH ES0590E P1.
- Column B:** PLATFORM OVERLOAD LED L46, CIRCUIT BREAKER CONTROLS 15A CB2.
- Column C:** GND BR, BK-22D, RD P20PWR U34-2, GR D81CAN- C41-4, YL D81CAN+ C41-3, RD H6, RD P20BAT TB20D, P20BAT RD TB20C, P24BAT RD TB24D, C108ESL WH/BK TB25D, BR TBGND, GR/BK C133PLL C42-4, GR/BK C133PLL C7B-13.
- Column D:** ENABLE SWITCH P4, R14 DALE RH-25 25W 5 ohm, TS63 PRIMARY EXTEND/RETRACT SWITCH, TS61 PRIMARY BOOM UP/DOWN SWITCH.
- Column E:** JIB UP/DOWN TS58, TS59 PLATFORM LEVEL, RD/BK TB129D, BK/WH C8PBR-8D, C7PBE BK-7D, C1PBU RD-TB1D, C2PBD RD/BK-TB2D, C35RPM BK/RD-35D, TS54 ENGINE SPEED ENABLE D13.
- Column F:** C47FE BL/RD CR18-86, C14PLU OR-14D, C15PLD OR/BK-15C, C18JD GR/BK-18D, C18JD GR/BK, C17JU GR, C27AUX RD-27D, WH P174BAT CR55-30, C5TRR WH/BK-5D, C4TRL WH-4D, C11SBD BL/BK-11D, C129DA RD/BK TB129A, C10SBU BL-10D, C33STR BK-33D, RD R174BAT CR55-87, C34SA BK-34D.
- Column G:** BASE BOX HARNESS (TO TERMINAL STRIP), C17JU GR-17D, C19JSV GR/WH C3-U, C18JD GR/BK-18D, C17JU GR, C27AUX RD-27D, WH P174BAT CR55-30, C5TRR WH/BK-5D, C4TRL WH-4D, C11SBD BL/BK-11D, C129DA RD/BK TB129A, C10SBU BL-10D, C33STR BK-33D, RD R174BAT CR55-87, C34SA BK-34D.
- Column H:** TS57 PLATFORM ROTATE, D28, FUNCTION SPEED CONTROL VARIABLE RESISTOR 20 OHM, TURNABLE ROTATE SWITCH TS62.
- Column I:** SECONDARY UP/DOWN SWITCH TS60, TS66 GLOW PLUG, D64.
- Column J:** AUXILIARY SWITCH TS61, D9, D4, OR/RD, RD, WH.

The diagram uses standard electrical symbols for switches, relays, lights, meters, and connectors. Wire colors are indicated by abbreviations (e.g., BK for black, RD for red, GR for green, WH for white, YL for yellow, BL for blue).


Ground Control Box Terminal Strip Wiring Diagram,
Deutz D2011L03i and Perkins 404D-22 - ANSI / CSA




Ground Control Box Terminal Strip Wiring Diagram, Deutz D2011L03i and Perkins 404D-22 - ANSI / CSA




**Ground Control Box Switch Panel Wiring Diagram,
Deutz D 2.9 L4 and Perkins 404F-E22T - ANSI / CSA**




Ground Control Box Switch Panel Wiring Diagram,
Deutz D 2.9 L4 and Perkins 404F-E22T - ANSI / CSA




Ground Control Box Terminal Strip Wiring Diagram,
Deutz D 2.9 L4 and Perkins 404F-E22T - ANSI / CSA




Ground Control Box Terminal Strip Wiring Diagram, Deutz D 2.9 L4 and Perkins 404F-E22T - ANSI / CSA




**Ground Control Box Switch Panel Wiring Diagram,
Ford MSG425 - ANSI / CSA**




Ground Control Box Switch Panel Wiring Diagram,
Ford MSG425 - ANSI / CSA




Ground Control Box Terminal Strip Wiring Diagram, Ford MSG425 - ANSI / CSA




**Ground Control Box Terminal Strip Wiring Diagram,
Ford MSG425 - ANSI / CSA**




Ground Control Box Switch Panel Wiring Diagram, - CE




| A | B | C | D | E | F | G | H | I | J | K | L | M |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
|---|---|---|---|---|---|---|---|---|---|---|---|---|




Ground Control Box Terminal Strip Wiring Diagram, - CE




Ground Control Box Terminal Strip Wiring Diagram, - CE




Platform Control Box Switch Panel Wiring Diagram




Platform Control Box Switch Panel Wiring Diagram




| A | B | C | D | E | F | G | H | I | J | K | L | M |
|---|---|---|---|---|---|---|---|---|---|---|---|---|
|---|---|---|---|---|---|---|---|---|---|---|---|---|




Platform Control Box Terminal Strip Wiring Diagram




Platform Control Box Relay Wiring Diagram - ANSI / CSA




Platform Control Box Relay Wiring Diagram - ANSI / CSA




Platform Control Box Relay Wiring Diagram - CE




Platform Control Box Relay Wiring Diagram - CE




Hydraulic Schematic, - CE
(to Z4525XCM-1500)




Hydraulic Schematic, - CE
(to Z4525XCM-1500)



Hydraulic Schematic, - ANSI / CSA / CE
(from Z4525XCF-101, Z4525XCM-1501)



Hydraulic Schematic, - ANSI / CSA / CE
(from Z4525XCF-101, Z4525XCM-1501)



California Proposition 65



WARNING

Operating, servicing and maintaining this equipment can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. These chemicals can be emitted from or contained in other various parts and systems, fluids and some component wear by-products. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your equipment and vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your equipment or vehicle and after operation. For more information go to www.P65Warnings.ca.gov/passenger-vehicle.

Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.