

Encompass® 4-S

Quick Start Guide

16-0168-001 Rev C 9/2021

TransCore's Encompass® 4-S family of fully integrated wireless radio frequency identification (RFID) readers are designed for use in parking, security access, electronic vehicle registration (EVR), traffic management, and low-speed electronic toll collection applications.

This quick start guide is intended for use by authorized TransCore Encompass series dealers, installers, and service personnel, and provides information for site design, reader placement, testing, installation, and troubleshooting.



Information in this document is subject to change and does not represent a commitment on the part of TransCore, LP.

© 2021 TransCore, LP. All rights reserved. TRANSCORE, AMTECH, EGO, and ENCOMPASS are registered trademarks and are used under license. All other trademarks are the property of their respective owners. Contents are subject to change. Printed in the U.S.A.

For further information, contact:

TransCore

8600 Jefferson Street NE
Albuquerque, New Mexico 87113 USA

Web: www.transcore.com

TransCore Technical Support

Phone: (505) 856-8007

TransCore Sales Support

Phone: (800) 923-4824

WARNING TO USERS IN THE UNITED STATES

**FEDERAL COMMUNICATIONS COMMISSION (FCC)
LOCATION AND MONITORING SERVICE STATEMENT
47 CFR §90.351**

NOTE: The user is required to obtain a Part 90 site license from the Federal Communications Commission (FCC) to operate this radio frequency identification (RFID) device in the United States. The FCC ID number is FIHE4SPT90V45. Access the FCC website at www.fcc.gov to obtain additional information concerning licensing requirements.

NOTE: Users in all countries should check with the appropriate local authorities for licensing requirements.

**FCC RADIO FREQUENCY INTERFERENCE STATEMENT
47 CFR §15.105(A)**

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate RF energy and may cause harmful interference to radio communications if not installed and used in accordance with the instruction manual. Operating this equipment in a residential area is likely to cause harmful interference, in which case, depending on the laws in effect, the user may be required to correct the interference at their own expense.

**NO UNAUTHORIZED MODIFICATIONS
47 CFR §15.21**



CAUTION: This equipment may not be modified, altered, or changed in any way without permission. Unauthorized modification may void the equipment authorization from the FCC and will void the warranty.

**USE OF SHIELDED CABLES AND GROUNDING
47 CFR §15.27(A)**

NOTE: Shielded cables and earth grounding the unit is recommended for this equipment to comply with FCC regulations.

**TRANSCORE, LP
USA**

**AVERTISSEMENT À L'ATTENTION DES
UTILISATEURS AUX ÉTATS-UNIS**

**DÉCLARATION 47 CFR §90.351 (CODE DES
RÈGLEMENTS FÉDÉRAUX) DE LA FEDERAL
COMMUNICATIONS COMMISSION (FCC) SUR LES
SERVICES DE LOCALISATION ET DE CONTRÔLE**

REMARQUE : L'utilisateur est tenu d'obtenir une licence d'utilisation sur site Partie 90 auprès de la Federal Communications Commission (FCC) afin de pouvoir utiliser ce dispositif RFID (radio-identification) aux États-Unis ou au Canada. Le numéro d'identification de la FCC est FIHE4SPT90V45. Pour obtenir de plus amples informations concernant les exigences relatives aux licences, prière de consulter le site web de la FCC à www.fcc.gov.

REMARQUE : Il est recommandé à tous les utilisateurs, quel que soit leur pays, de consulter les autorités locales compétentes sur les exigences de licence.

**DÉCLARATION 47 CFR §15.105(A) DE LA FCC SUR
LES INTERFÉRENCES DES FRÉQUENCES RADIO**

REMARQUE : Cet appareil a été testé et déclaré conforme à la catégorie d'un appareil numérique de classe A en accord avec la partie 15 des directives de la FCC. Ces normes visent à assurer une protection raisonnable contre les interférences nuisibles lorsque l'appareil est utilisé dans un environnement commercial. Cet appareil génère, utilise et peut émettre de l'énergie RF et peut être à l'origine d'interférences nuisibles aux communications radio s'il n'est pas installé et utilisé en suivant les directives du manuel d'instructions. Si cet appareil est utilisé dans une zone résidentielle, il est probable qu'il cause des interférences nuisibles. Dans ce cas, l'utilisateur pourrait être amené à remédier aux interférences à ses propres frais, selon les lois du pays en vigueur.

**AUCUNE MODIFICATION NON AUTORISÉE
47 CFR §15.21**



MISE EN GARDE : Il est interdit de modifier, d'altérer ou d'apporter des changements à cet appareil de quelque manière que ce soit sans autorisation. Toute modification non autorisée peut annuler l'autorisation d'utilisation accordée par la FCC et annulera la garantie.

**UTILISATION DE CÂBLES BLINDÉS ET MISE À LA TERRE
47 CFR §15.27(A)**

REMARQUE : Il est recommandé d'utiliser des câbles blindés et une mise à la terre avec cet appareil afin de répondre aux réglementations de la FCC

**TRANSCORE, LP
ÉTATS-UNIS**

WARNING TO USERS IN CANADA**INDUSTRY CANADA (IC) INDUSTRY CANADA'S RADIO STANDARD SPECIFICATIONS (RSS-137) LOCATION AND MONITORING SERVICE IN THE BAND 902-928 MHZ SECTION 2.1**

NOTE: The user is required to obtain a license from Industry Canada (IC), to operate this radio frequency identification (RFID) device in Canada. The IC ID number is IC: 1584A-E4SPT90V45, access the IC website at www.ic.gc.ca to obtain additional information concerning licensing requirements.

Industry Canada (IC) Industry Canada's Radio Standard Specifications General Requirements (RSS-GEN) for Compliance of Radio Apparatus Statement Section 8.4

This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions:

- 1) This device may not cause interference; and
- 2) This device must accept any interference, including interference that may cause undesired operation of the device.

AVERTISSEMENT AUX UTILISATEURS AU CANADA**INDUSTRIE CANADA (IC) INDUSTRIE CANADA RADIO STANDARD SPECIFICATIONS (CNR-137) EMPLACEMENT ET SERVICE DE SURVEILLANCE DANS LA BANDE 902-928 MHZ, SECTION 2.1**

Remarque : L'utilisateur est tenu d'obtenir une licence d'Industrie Canada (IC), afin d'exploiter ce dispositif d'identification par radiofréquence au Canada. Le numéro d'identification d'IC est IC: 1584A-E4SPT90V45. Pour obtenir de plus amples informations concernant les exigences relatives aux licences, prière de consulter le site web de d'IC à www.ic.gc.ca.

Radio Standard Spécifications exigences générales Industrie Canada (IC) Industrie Canada (CNR-GEN) pour s'acquitter du Radio appareil déclaration article 8.4

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1) l'appareil ne doit pas produire de brouillage, et
- 2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

**RADIO FREQUENCY HEALTH LIMITS FOR ENCOMPASS 4 READER
USING AN EXTERNAL ANTENNA IN FREQUENCY BAND
OF 902.25 TO 903.75 AND 910.00 TO 921.50 MHZ**

Several agencies (OSHA, FCC, IC) have environmental guidelines regulating maximum permissible exposure (MPE) or “safe” exposure levels that this product falls under. To ensure that proper safety guideline for the end users of this product, i.e. Occupational (Controlled) and General Population/ Public (Uncontrolled), the recommended levels for each of the agencies are presented in the next sections with TransCore’s recommendations for safety in the last section.

OSHA (Occupational Safety and Health Administration)

OSHA (an agency of The United States of America) legislates in the Code of Federal Regulations (CFR) Title 29 Part 1910 Subpart G 1910.97 titled “Nonionizing radiation”, a maximum safe exposure limit of 10 milliwatts per square centimeter (mW/cm^2) during any 0.1-hour period (i.e. 6 minutes). Using the frequency (in the middle of the band of operation of this equipment) of 915 MHz and the highest antenna gain that this equipment is certified for use in a final installation, the minimum safe distance was calculated to be 8in (20cm).

FCC (Federal Communication Commission)

FCC (an agency of The United States of America) legislates in the Code of Federal Regulations (CFR) Title 47 Chapter I Subchapter A Part 1 Subpart I Section 1.1310 titled “Radiofrequency radiation exposure limits” that the maximum permissible exposure (MPE) is the following:

Occupational/Controlled Exposure

Power density = frequency (in MHz)/300 mW/cm^2 with an Averaging time of 6 Min

General Population/Uncontrolled Exposure

Power density = frequency (in MHz)/1500 mW/cm^2 with an Averaging time of 30 Min

Using the frequency (in the middle of the band of operation of this equipment) of 915MHz and the highest antenna gain that this equipment is certified for use in a final installation, the minimum safe distance was calculated. The MPE minimum distances are 14in (36cm) for the Occupational/ Controlled environment, and 31.5in (80.5cm) for the General Population/Uncontrolled environment.

Industry Canada (Innovation, Science and Economic Development Canada)

Industry Canada (a Department of the Government of Canada) sets out the requirements in Radio Standards Specification RSS-102, Issue 5 guidelines, recommending a maximum safe power density in W/m^2 . Thus, the maximum permissible exposure for general population/uncontrolled exposure at 915MHz is $2.77 W/m^2$. The average time is 6 minutes. The maximum permissible exposure (MPE) is the following:

Controlled Environment

Power density = $0.6455 \cdot \text{frequency (in MHz)}^{0.5} \text{ W/m}^2$ with a Reference Period time of 6 Min

General Public/Uncontrolled Environment

Power density = $0.02619 \cdot \text{frequency (in MHz)}^{0.6834} \text{ W/m}^2$ with a Reference Period time of 6 Min

Using the frequency (in the middle of the band of operation of this equipment) of 915MHz and the highest antenna gain that this equipment is certified for use in a final installation, the minimum safe distance was calculated. The MPE minimum distances are 18in (45cm) for the Controlled environment and 47in (120cm) for the General Public/Uncontrolled environment.

TransCore Recommendation on MPE (Maximum Permissible Exposure)

The calculated power densities and MPE distance for each of the agencies respective to the environment is shown below.

Occupational/Controlled Environment				
Agency	Power Density (mW/cm ²)	MPE minimum distance		Time (min)
		in	cm	
OSHA	10	7	18	6
FCC	3.05	13	32	6
IC	1.95	16	40	6

General Population/Public/Uncontrolled Environment				
Agency	Power Density (mW/cm ²)	MPE minimum distance		Time (min)
		In	cm	
OSHA	10	7	18	6
FCC	0.61	28	72	30
IC	0.28	42	106	6

With the equipment installed and running at the maximum transmit power of 1.6W (32dBm), 0dB transmit attenuation, using the highest gain antenna that the equipment is certified for, the recommendation for each of the operation environments is as follows:

- 1) The antenna should be installed at least 42in (106cm) from the General Population/ Public i.e. Uncontrolled Environment.
- 2) Maintenance personnel (i.e. Occupational/Controlled Environment) must remain at least 16in (40cm) from the antenna and limit their time in the environment to 6 minutes when the system is operating.

LIMITES D'EXPOSITION AUX RADIOFRÉQUENCES POUR LE LECTEUR ENCOMPASS 4 UTILISANT UNE ANTENNE EXTERNE SUR LA BANDE DE FRÉQUENCES DE 902.25 À 903.75 ET DE 910.00 À 921.50 MHZ

Plusieurs organismes (OSHA, FCC, IC) publient des directives environnementales qui recommandent des limites d'exposition maximale autorisée (normes MPE) ou des niveaux d'exposition « sûrs » auxquels cet appareil se conforme. Pour faire en sorte que chaque utilisateur final ait connaissance des directives de sécurité qui le concerne, que ce soit dans son travail (accès contrôlé) ou pour la population générale/le grand public (accès non contrôlé), TransCore présente les niveaux recommandés par chaque organisme dans ses recommandations sécuritaires détaillées dans la dernière section.

OSHA (Occupational Safety and Health Administration)

Dans le Code des réglementations fédérales (CFR), Titre 29, Partie 1910, Sous-partie G 1910.97, intitulée « Nonionizing radiation » (Rayonnements non ionisants), l'OSHA (organisme américain) recommande un plafond d'exposition maximale de 10 milliwatts par centimètre carré (mW/cm²) pendant une période de 0,1 heure (soit 6 minutes). En utilisant la fréquence de 915 MHz (milieu de la bande de fréquences de cet appareil) et le gain d'antenne maximal pour lequel cet appareil a reçu une certification d'utilisation dans une installation finale, la distance minimale sécuritaire est de 20 cm (8 po).

FCC (Federal Communication Commission)

Dans le Code des réglementations fédérales (CFR), Titre 47, Chapitre I, Sous-chapitre A, Partie 1, Sous-partie I, Section 1.1310 intitulée « Radiofrequency radiation exposure limits » (Limites d'exposition aux rayonnements de radiofréquence), la FCC (organisme américain) établit les limites d'exposition maximale autorisée (normes MPE) comme suit :

Exposition professionnelle/contrôlée

Densité de puissance = fréquence (en MHz)/300 mW/cm² avec une durée moyenne de 6 min.

Exposition de la population générale/non contrôlée

Densité de puissance = fréquence (en MHz)/1500 mW/cm² avec une durée moyenne de 30 min.

En utilisant la fréquence de 915 MHz (milieu de la bande de fréquences de cet appareil) et le gain d'antenne maximal pour lequel cet appareil a reçu une certification d'utilisation dans une installation finale, la distance minimale sécuritaire est la suivante : les distances MPE minimales sont de 36 cm (14 po) pour l'environnement professionnel/contrôlé et de 80,5 cm (31,5 po) pour la population générale/environnement non contrôlé.

Industrie Canada (Innovation, Sciences et Développement économique Canada)

Le Cahier des charges sur les normes radioélectriques 102, 5^e édition, d'Industrie Canada (un ministère du Gouvernement du Canada) établit des recommandations pour une densité de puissance maximale sécuritaire en W/m². Ainsi, l'exposition maximale admissible pour la population générale/non contrôlée à 915 MHz est calculée à 2,77 W/m². La durée moyenne est de 6 minutes. Les limites d'exposition maximale autorisée (normes MPE) sont les suivantes :

Environnement contrôlé

*Densité de puissance = 0,6455*fréquence (en MHz)^{0,5} W/m² avec une durée de référence de 6 min.*

Grand public/environnement non contrôlé

*Densité de puissance = 0,02619*fréquence (en MHz)^{0,6834} W/m² avec une durée de référence de 6 min.*

En utilisant la fréquence de 915 MHz (milieu de la bande de fréquences de cet appareil) et le gain d'antenne maximal pour lequel cet appareil a reçu une certification d'utilisation dans une installation finale, la distance minimale sécuritaire est la suivante : les distances MPE minimales sont de 45 cm (18 po) pour l'environnement professionnel/contrôlé et de 120 cm (47 po) pour le grand public/environnement non contrôlé.

Recommandations de TransCore sur les limites d'exposition maximale autorisée (normes MPE)

Les densités de puissance et la distance MPE calculées par chaque organisme pour un environnement donné sont présentées ci dessous.

Exposition professionnelle/environnement contrôlé				
Organisme	Densité de puissance (mW/cm ²)	Distance MPE minimale		Durée (en min.)
		po	cm	
OSHA	10	7	18	6
FCC	3,05	13	32	6
IC	1,95	16	40	6

Population générale/environnement non contrôlé				
Organisme	Densité de puissance (mW/cm ²)	Distance MPE minimale		Durée (en min.)
		po	cm	
OSHA	10	7	18	6
FCC	0,61	28	72	30
IC	0,28	42	106	6

Avec l'appareil installé et fonctionnant à la puissance de transmission maximale de 1,6W (32dBm), 0dB d'atténuation de transmission, et en utilisant le gain d'antenne maximal pour lequel l'appareil a reçu une certification, les recommandations pour chaque environnement d'exploitation sont les suivantes :

- 1) L'antenne devrait être installée à au moins 106 cm (42 po) de la population générale/du grand public, c'est-à-dire d'un environnement non contrôlé.
- 2) Le personnel d'entretien (c'est-à-dire dans un environnement professionnel/contrôlé) doit rester à au moins 40 cm (16 po) de l'antenne et limiter son temps d'exposition à 6 minutes lorsque l'appareil est en fonctionnement.

Contents

Site Licensing	12
Designing the Site Plan	12
Interface Cable	14
Pre-Installation Testing	15
Installation at the Site	20
Reader Commands	25
Troubleshooting	29

Tables

Table 1 Encompass 4-S Reader Features	12
Table 2 Interface Cable Wire Pair Key	14
Table 3 Power Connections	15
Table 4 RS–232 Interface	16
Table 5 RS–422 Interface	16
Table 6 Wiegand Testing Command Example	17
Table 7 Wiegand Interface	17
Table 8 Return to Factory Default Commands	18
Table 9 Testing Commands	18
Table 10 Reader Frequencies Staggered for 14 Lanes	19
Table 11 Sense Input/Output Cabling Assignments	21
Table 12 Frequently Used Reader Commands	25

Figures

Figure 1 Interface Cable	14
Figure 2 Recommended Reader Grounding	16
Figure 3 Frequency Separation for Four Lanes	19
Figure 4 Correct Orientation of Reader	20
Figure 5 RS–232 Wiring Diagram	23
Figure 6 RS-422 Wiring Diagram	24
Figure 7 Sources of RF Interference	30

Site Licensing

Encompass® 4-S Readers radiate more than 3 milliwatts of RF power, and must be licensed under Federal Communications Commission (FCC) Section 90.239. An FCC license provides the user with the legal authorization to operate the Encompass 4-S Reader on the licensed frequencies at the site specified in the license. The FCC license also provides the user with protection and authorization to maintain the system should any other RFID product be used in the licensed area after the Encompass 4-S Reader equipment is installed.

The site owner must complete and file Form 601, FCC Application for Wireless Telecommunications Bureau Radio Service Authorization. Forms are available online at the FCC Internet site <https://www.fcc.gov/licensing-databases/forms>.

The authorized frequency band for this product in the United States is 911.75 to 919.75 MHz. Only an authorized installer or service technician should set the RF frequency of the Encompass 4-S Reader to the frequency specified in the FCC site license.

Designing the Site Plan

Design the site plan before ordering equipment and installing the Encompass 4-S Reader. If the site configuration differs significantly from the recommendations in this guide, contact TransCore Sales Support.

Determine the Reader and Tag Combination

The Encompass 4-S Reader is capable of reading the following protocols and formats:

- TransCore Super eGo® (SeGo)
- eGo (ISO 18000-6B)
- ATA/AAR/ISO 10374
- IAG (Interagency Group)
- Wiegand

Table 1 lists the Encompass 4-S Reader models and features.

Table 1 Encompass 4-S Reader Features

Reader Model*	Protocol(s)	Wiegand	Internal Antenna	Communication	
				RS-232	RS-422
10-400y-S08	ATA	✓	✓	✓	✓
10-400y-S01	SeGo	✓	✓	✓	✓
10-400y-S19	IAG	✓	✓	✓	✓
10-400y-S02	ATA/SeGo	✓	✓	✓	✓
10-400y-S10	ATA/IAG	✓	✓	✓	✓
10-400y-S04	SeGo/IAG	✓	✓	✓	✓
10-400y-S09	eGo/ATA	✓	✓	✓	✓
10-400y-S03	eGo/SeGo	✓	✓	✓	✓

*y = 2 (RS-232) or y = 4 (RS422)

Reader Placement

Encompass 4-S Readers may be mounted on a pole at the side of the lane (side-fire), or on a gantry or surface extending over the center of the lane (overhead). The reader should be located in a place where it is not likely to be bumped out of alignment. Readers should not directly face each other or be positioned back-to-back.

For a pole mount installation, readers should be installed as high as possible so that the reader can be pointed down to control the read zone and minimize interference in the adjacent lane.

Tag Placement on Vehicle

Most TransCore RFID tags should be mounted in the center of the windshield to the right of the rear-view mirror post. Refer to the installation instructions for your specific tag for more information on tag placement.

Site Layout, Lane Type, and Traffic Flow

Become familiar with the configuration of the site and its proximity to other sites. Determine what the lane types will be, and identify any equipment that will be used, such as ticket machines or proximity readers.

The number of readers that will be required depends on the number of lanes at the site, how they are grouped, and total entry and exit points. Measure lane widths and the distance between adjacent lanes, taking into account any island/barrier width. TransCore recommends a lane width of 12 feet or less, with the distance between the readers at least 12 feet or more.

Interfaces to External Equipment

For effective lane layout and transaction framing, the maximum distance from the entry loop to the reader should be about 8 feet. The distance from the reader to the gate arm should be 3 to 4 feet before the gate. Refer to [“Figure 3 Frequency Separation for Four Lanes” on page 19](#).

The readers are typically configured to be loop-activated (on by presence). Readers may be alternatively set to have RF on continuously. The choice depends on traffic volume and possible interaction with the other in-lane components.

Electrical and Communications Requirements

The Encompass 4-S Reader requires 16-20VAC, 47-63HZ, or 16-28VDC for proper operation. Contact TransCore Sales Support for a list of recommended transformers and cable lengths.

The reader is available in RS-232 or RS-422 models. Maximum distance for RS-232 (3-wire serial) is 50 feet at 9600 baud. Maximum distance for RS-422 (4-wire differential signal) is 4000 feet at 9600 baud. The baud rate can be adjusted to accommodate noisy environments.

Interface Cable

The Encompass 4-S Reader uses a single 26-pin (13 twisted pair) cable to interface with power, I/O, and communications signals. The reader cable can be directly connected to external devices or routed to other components via an external junction box. Refer to [Figure 1](#) to see an example of the interface cable wire pairs and socket.




Figure 1 Interface Cable

[Table 2](#) describes each wire pair color and pin designation.

Table 2 Interface Cable Wire Pair Key

Pair Number	Pin	Color	Description
1	A	Black	TX232, RX422+, IF_ 485-
	B	Red	RX232, RX422-, IF_ 485+
11	C	Yellow	RTS, GND (RS485)
	D	Red	CTS, DEF L (RS485)
10	E	Blue	WIEGAND 0
	F	Red	WIEGAND 1
13	G	Orange	18V
	H	Red	18V RETURN
12	J	Brown	18V
	K	Red	18V RETURN
8	L	White	LOCK
	M	Red	LOCK RETURN
9	N	Green	SENSE 0
	P	Red	SENSE 0 RETURN
4	R	Blue	SENSE 1
	S	Black	SENSE 1 RETURN
6	T	Black	OUT 0 COMMON
	U	Brown	OUT 0 NORMALLY OPEN

Table 2 Interface Cable Wire Pair Key

Pair Number	Pin	Color	Description
7	V	Black	OUT 0 COMMON
	W	Orange	OUT 0 NORMALLY CLOSED
3	X	Black	OUT 1 COMMON
	Y	Green	OUT 1 NORMALLY OPEN
2	Z	Black	OUT 1 COMMON
	a	White	OUT 1 NORMALLY CLOSED
5	b	Yellow	GROUND
	c	Black	GROUND

Pre-Installation Testing

Bench Test the Reader

Bench test the reader using the following equipment:

- Audible circuit tester (buzzer) or volt meter with continuity tester
- Compatible power/communications cable
- PC using a terminal emulation program such as Tera Term or PuTTY.

Connect Hardware

1. For AC powered units, connect the power wires from the cable to the transformer. Select Pair 12 (Brown/Red) and Pair 13 (Orange/Red) using the colors from each wire pair to connect the cable as described in [Table 3](#). Do not apply power to the transformer at this time.

Note: AC transformer must be TransCore’s 76-1670-005 or equivalent.

Input Voltage	Output Voltage	Rated Current	No Load Voltage
120 VAC 60 Hz	AC 18.0 V ± 5%	2700 mA	AC 21.0 V Max

Table 3 Power Connections

Pair Number	Colored Wire Pair	Use These Colors	Connect to Transformer Terminal Strip
12	Brown/Red	Orange and Brown	L1 (16 to 20V AC)
13	Orange/Red	Red and Red	L2 (16 to 20V AC)
Earth Ground	Shielded Drain Wire	Isolated	Separate from any other RF

2. Connect the leads from the audible tester to the red and white pair of wires (Pair #8) from the power/communications cable.
3. For RS-232 units, refer to [Table 4](#) for wiring instructions. For RS-422 units, refer to [Table 5](#).
4. Connect the communications cable to the appropriate terminal on the host computer.

Table 4 RS-232 Interface


Pair Number	Colored Wire Pair	Use This Color	Connect to Host DB9 Pin	Connect to Host DB25 Pin
1	Red/Black	Black	Pin 2 (RXD)	Pin 3 (RXD)
		Red	Pin 3 (TXD)	Pin 2 (TXD)
5	Yellow/Black	Yellow	Pin 5 (GND)	Pin 7 (GND)
		Black	Do not connect	

Table 5 RS-422 Interface

Pair Number	Colored Wire Pair	Use This Color	Connect to Host Signal
11	Yellow/Red	Yellow	Receive (+)
		Red	Receive (-)
1	Red/Black	Black	Transmit (+)
		Red	Transmit (-)
5	Yellow/Black	Yellow	Signal Ground

Correct Reader Grounding

Ground the reader following the recommended grounding shown in [Figure 2](#).



WD-0082B

Figure 2 Recommended Reader Grounding

Set up the Terminal Emulation Application

1. Launch the terminal emulation application.
2. In the dialog boxes choose the com port to which the communications interface is attached and set the properties as follows:
 - Bits per second: 9600 baud
 - Data bits: 8
 - Parity: None
 - Stop bits: 1
 - Flow control: None

Power the Reader

1. Ensure circular connector is connected to the reader. The connector is keyed, and should only be able to be plugged in one way.
2. Once the reader has been powered up, a sign-on message will appear. If startup is successful, the sign-on message appears as follows:

```
Model E4 Series [software version] SNYYYYYY
[Copyright notice]
```

Where YYYYYY is the serial number of the Encompass 4-S Reader unit being used.

Configure for Wiegand Operation

When using a Wiegand interface, configure the reader for Wiegand operation using the commands in [Table 6](#). Connect the Wiegand interface wires including the Black of the Yellow/Black pair for signal ground, as shown in [Table 7](#). If not using Wiegand tags, move to the next step, “[Read Test Tags](#)”.

Table 6 Wiegand Testing Command Example

Enter	Reader Response	What It Does
#01	#Done	Switches reader to command mode
#489	#Done	Sets operational mode to read eATA data from eGo Plus or eGo tags
#451	#Done	Switches reader to Wiegand mode
#6401	#Done	Turns RF ON
#00	#Done	Returns reader to data mode and saves settings to NVM

Table 7 Wiegand Interface

Pair Number	Colored Wire Pair	Use This Color	Connect to Data Wire of Wiegand Controller
10	Blue/Red	Blue	Data0
		Red	Data1
5	Yellow/Black	Black	Ground
		Yellow	Do not connect

For further information, refer to TransCore document 16-0088-001, Wiegand Translator Guide.

Read Test Tags

Hold a tag in front of the reader to determine if the data is read out on the computer screen or on the Wiegand interface.

The commands listed in [Table 8](#) return the reader to factory defaults.

Table 8 Return to Factory Default Commands

Enter	Reader Response	What It Does
#01	#Done	Switches reader to command mode and turns RF OFF
#66F	#Done	Loads all factory default operating parameters except operating frequency
#00	#Done	Returns reader to data mode and turns RF ON, if enabled

[Table 9](#) provides commands that can be used for testing the reader. The #40 command causes the reader to transmit the Tag data continuously and command #6401 will cause the reader to transmit RF continuously.

Table 9 Testing Commands

Enter	Reader Response	What It Does
#01	#Done	Switches reader to command mode and turns RF OFF
#481	#Done	Sets operational mode to read ATA tags
#40	#Done	Transmits all tag IDs without regard for uniqueness
#6401	#Done	Turns RF ON
#00	#Done	Returns reader to data mode and turns RF ON, if enabled

Frequency Plan

The Encompass 4-S Reader FCC-approved frequency band is 911.75 to 919.75 MHz. This relatively narrow frequency band requires careful planning to maintain the desired 2 MHz frequency separation between adjacent readers.

If readers are spread out within a facility (readers ½ mile or so apart) and loops are used, then frequencies may be reused. **Figure 3** shows frequency separation for 4 lanes.




Figure 3 Frequency Separation for Four Lanes

Table 10 shows an example of the frequency settings for up to 14 lanes, along with the two different commands that can be used to set the reader operating frequency. Command #642NN is backward compatible to older readers including the Encompass 2 reader, and provides a 0.5MHz resolution. Command #647XXX provides a 0.25MHz resolution for setting the reader frequency. Either command may be used to set the reader frequency. Note that the response to Command #527 (Display RF Parameters) will include either two or three hexadecimal characters, depending on which command was last used to set the reader frequency.

Table 10 Reader Frequencies Staggered for 14 Lanes

Lane	Reader Frequency	#642	#647	Lane	Reader Frequency	#642	#647
1	912.50	15	0D2	2	915.00	1A	0DC
3	917.50	1F	0E6	4	913.50	17	0D6
5	916.00	1C	0E0	6	918.50	21	0EA
7	914.50	19	0DA	8	917.00	1E	0E4
9	913.00	16	0D4	10	915.50	1B	0DE
11	918.00	20	0E8	12	914.00	18	0D8
13	916.50	1D	0E2	14	919.00	22	0EC

Installation at the Site

Complete pre-installation testing before installing the reader on site.


Before Starting Installation

Confirm the following:

- All construction is complete and electrical and communications cables are of the appropriate length and in place.
- A watertight junction box with terminal strip is present.
- A dedicated power supply of the appropriate voltage is present.
- Placement of the readers follows the site plan.
- The readers are in the correct positions: side-fire or overhead.

The Encompass 4-S reader has a weep hole located on the bottom left side to allow moisture to escape. The reader should always be positioned so that the side with the weep hole is lower than the top. For overhead mounting, the reader angle should be at least 10° (Figure 4).

Typically, readers (or antennas) are installed either on the side of the lane, pointing into the lane (side-fire) or directly over the lane, pointed downward (center-fire or overhead).



HS-0119B

Figure 4 Correct Orientation of Reader

Overhead installations are typically used in parking garages and other areas where an overhead mounting surface already exists. These readers are normally set to 10° down-tilt.

Side-fire installations are commonly used when the lanes are out in the open and the installation of a pole is sufficient to mount a reader.

Mount Reader on Round Pole or Flat Surface

Proper reader angle may require both up-down and right-left adjustment. Ensure that the correct wall-mount or pole-mount bracket is used in the reader installation.



CAUTION:

For reliable reader operation, ensure that the reader is connected to Earth Ground. Also connect the housing, via the mounting bracket, to Earth Ground.

Connect the cable shield of the communications cable to Earth Ground. TransCore strongly recommends following the National Electric Code for lightning protection for the locale where the Encompass 4-S Reader is installed. Refer to “Figure 2 Recommended Reader Grounding” on page 16.

Connect All Wiring

1. Connect all wiring as described in “Pre-Installation Testing” on page 15 using the “RS–232 Wiring Diagram” on page 23 as a guide or the “RS-422 Wiring Diagram” on page 24 as a guide.

NOTE: Use a watertight junction box that meets applicable local and national building codes for connecting power and communications wiring. The junction box houses the transformer, terminal strip for power, and the communications connections. TransCore recommends a NEMA Type-4 junction box with a back mounting panel. The junction box must meet all environmental specs of the housed electronics, including the transformer specs.

2. Connect the sense input and sense output circuits using Table 11 as a guide.
3. Start the terminal emulation application. Refer to “Pre-Installation Testing” on page 15.



CAUTION:

Do not ground the input power supply.


Table 11 Sense Input/Output Cabling Assignments

Pair Number	Pair	Pin	Color	Signal	Description	Typical Function
5	Yellow/Black	b	Yellow	GND	Logic ground	Signal ground used with RS–232, RS–422, and Wiegand
		c	Black	GND	Logic ground	Signal ground used with RS–232, RS–422, and Wiegand
10	Blue/Red	E	Blue	WGND0	Wiegand data0	Parking/access control
		F	Red	WGND1	Wiegand data1	Parking/access control
8	White/Red	L	White	Lock	Tag lock output, active-closed	Testing/maintenance
		M	Red	Lock_RTN	Tag lock return	Testing/maintenance

Table 11 Sense Input/Output Cabling Assignments

Pair Number	Pair	Pin	Color	Signal	Description	Typical Function
9	Green/Red	N	Green	Sense Input0	Sense Input0 (loop)	Loop and presence detection
		P	Red	Sense Input0_RTN	Sense Input0 return; not isolated from signal ground	Loop and presence detection
4	Blue/Black	R	Blue	Sense Input1	Sense Input1	General-purpose sense input, not used for detecting presence
		S	Black	Sense Input1_RTN	Sense Input1 return; not isolated from signal ground	General-purpose sense input, not used for detecting presence
6	Brown/Black	T	Black	Sense Output0_COM	Sense Output0 (tag detect), common terminal	Switched output to control gate
		U	Brown	Sense Output0_NO	Sense Output0 normally open terminal	Switched output to control gate
7	Orange/Black	V	Black	Sense Output0_COM	Sense Output0 (tag detect output), common terminal	Switched sense output for any external control (light, gate, buzzer, etc.)
		W	Orange	Sense Output0_NC	Sense Output0 normally closed terminal	Switched sense output for any external control (light, gate, buzzer, etc.)
3	Green/Black	X	Black	Sense Output1_COM	Sense Output1, common terminal	Switched sense output
		Y	Green	Sense Output1_NO	Sense Output1 normally open terminal	Switched sense output
2	White/Black	Z	Black	Sense Output1_COM	Sense Output1, common terminal	Switched sense output
		a	White	Sense Output1_NC	Sense Output1 normally closed terminal	Switched sense output

Wiring Diagram for an Encompass® 4-S (RS-232) Unit



WD-0113B

Figure 5 RS-232 Wiring Diagram

Wiring Diagram for an Encompass® 4-S (RS-422) Unit




Figure 6 RS-422 Wiring Diagram

Apply Power

Apply power and verify the reader sign-on message appears on the terminal emulator application laptop/ computer.

Reader Set Up

1. Use reader commands to query status and set up the reader.
2. Make sure that each reader is set up to the appropriate settings.
3. Adjust reader angle and power to optimize read zone for each reader.
4. Check for interference from each reader or the environment, using a portable field spectrum analyzer if one is available.

Note: If using Wiegand tags, configure the reader for Wiegand operation and connect the Wiegand interface. Refer to “Configure for Wiegand Operation” on page 17.

5. Disconnect the computer and connect the reader to back end devices. Recheck read zone and for interference between readers.
6. System-test the reader to verify that the gate opens when a valid tag is read.
7. Once all in lane testing is complete, perform a system test using tagged vehicles passing through numerous lanes. The tag reads are sent to the gate controller back end system for validation.

Reader Commands

Table 12 provides the commands frequently used in testing, setting up, and tuning the Encompass 4-S Reader.

NOTE: An #Error response from the reader indicates that the command was entered incorrectly.

Table 12 Frequently Used Reader Commands

Enter	Reader Response	What It Does
#00	#Done	Returns reader to data mode
#01	#Done	Switches to command mode
#40	#Done	Transmits all tag IDs without regard for uniqueness
#450	#Done	Disable Wiegand mode (Default)
#451	#Done	Enable Wiegand mode, Refer to #532
#454	#Done	Disable Multitag Sort (Default)
#455	#Done	Enable multi-tag sort
#46NN	#Done	Set Wiegand retransmit interval in seconds NN = 01–FF Hex (01 Default) Refer to #533

Table 12 Frequently Used Reader Commands

Enter	Reader Response	What It Does
#48N	#Done	Select tag mode N = 0–9 0 = disable ATA 1 = enable ATA 2 = disable eGo 3 = enable eGo 4 = disable SeGo 5 = enable SeGo 6 = disable IAG 7 = enable IAG 8 = disable eATA 9 = enable eATA NOTE: Encompass 4-S Reader will only have tag protocols specific to the model ordered. NOTE: Refer to Commands #838 and #839
#505	#Model [model] Ver [version no.] SN [serial no.]	Display firmware version

Table 12 Frequently Used Reader Commands

Enter	Reader Response	What It Does
#527	<p>#RFST Cx Ox T1 Fxx Rxx Gxx Axx lxx</p> <p>C0 = RF controlled by host, Refer to #6400, #6401</p> <p>C1 = RF-by-input control, Refer to #641</p> <p>O0 = RF off, Refer to #6400</p> <p>O1 = RF on, Refer to #6401</p> <p>T1 = uniqueness timeout of 2 min, Refer to #441</p> <p>Fxx = RF output frequency 00 to 34, (Refer to #642NN, #647XXX</p> <p>Rxx = ATA RF output range, 00 to 1F (Default = 1F = max range), Refer to #643NN</p> <p>Gxx = eATA SeGo/eGo range control, 00 to 1F (Default = 1F = max range) , Refer to #645NN</p> <p>Axx = RF power attenuation, 00 to 0A (Default = 00 = Max Power), Refer to #644NN</p> <p>lxx (IAG Attenuation) = 00-0F (04 Default) 00=Max Power, Refer to #646NN</p>	<p>Display RF status</p>
#532	<p>#TOF <0 to 1>, Refer to #450, #451</p> <p>0 = Wiegand disabled 1 = Wiegand enabled</p>	<p>Display Wiegand mode status</p>
#533	<p>#WTI <01 to FF> seconds (1-255) in hex, Refer to #46NN</p>	<p>Display Wiegand retransmit interval</p>

Table 12 Frequently Used Reader Commands

Enter	Reader Response	What It Does
#570	#ATA:_ eGo:_ SeGo:_ IAG:_ EPC:_SORT:_TMM:_ I = SeGo ID (64 bits) E = enabled F = full transaction D = disabled Refer to commands #480 – #489, 838 and #839	Display reader protocols
#63	#Model [model] Ver [version no.] SN [serial no.] Copyright [date] TransCore	Reset reader equivalent to cycling power. Does not affect operating parameter settings
#6400	#Done	Turn RF off
#6401	#Done	Turn RF on
#641	#Done	Select RF-by-input control (Default)
#642NN (00 – FF)	#Done	Set RF operating frequency, 0.5 MHz resolution: 915MHz = #6421A (Default) . Refer to Table 10 .
#643NN (00-1F)	#Done	Set operating range for ATA protocol (distance): (00 to 1F Hex) 1F = max range (Default)
#644NN (00 – 0A) Hex	#Done	Set RF attenuation in 1.0 dB increments; 0 to 10 dB, 00=max power for max range
#645NN	#Done	Set operating range for eGo and SeGo protocols
#646xx (00 – 0F) Hex	#Done	where xx = 00 to 0F (hex) Set IAG Attenuation. Allows control of the read zone for IAG tags. Does not affect the performance of other tag types. 00=max power for max range (04 Default)
#647xxx	#Done	Set RF operating frequency, 0.25 MHz Resolution, #6470DC = 915MHz (Default) . Refer to Table 10 .
#66F	#Done	Load default operating parameters (does not affect RF operating frequency)

Troubleshooting

Communications problems between the reader and back-end host

These problems may be caused by incorrectly wiring the communications cable, using the wrong cable, having a too-long cable run, or incorrectly setting communications parameters between host and reader.

Cable run for RS–232 exceeds 50 feet in length

Fifty feet exceeds the maximum length for RS–232 interface. The interface should be converted to RS 422, wireless modem, fiber optic, or Wiegand.

RF is not on

The technician must verify that RF is on by presence or by using the command #6401 for RF ON Continuously. Command #527 may be used to verify RF status (O1).

Improper grounding

Cable shielding should be connected to Earth Ground to prevent damage from lightning or power surges.

Mixed tag population

In a mixed tag population, multiple tags in the same vehicle must be separated by at least 2 inches, preferably more.

Reader not programmed correctly

The technician must verify that all parameters are set appropriately for the reader location. Command #527 may be used to verify reader parameters. If using Wiegand, the technician can use commands #532 and #533 to verify Wiegand status.

Readers pointed toward each other

Configure the site plan so that readers are not aimed directly facing one another or in immediate proximity back-to-back. Refer to [Figure 3](#).

Tag presentation

Check the installation instructions for the specific tag to ensure that tags are properly mounted in the location determined by the reader placement.

Tag-to-reader polarization

Tag polarization must match reader polarization. Both tags and readers should be installed horizontally.

When performing a quick test of the Encompass 4-S Reader, the buzz box does not buzz.

Check all the wiring connections, and ensure that the buzz box is functioning. Ensure that the correct red and white wire pair to the leads of the buzzer are connected. Verify that RF is on (#6401). Ensure that the reader is in the correct interface mode for the test tag using Command #570.

When testing the Encompass 4-S Reader, all the wires are connected correctly but the unit does not respond.

Check that the Encompass 4-S Reader communication cable is connected to the correct COM port.

Unusual responses received from the Encompass 4-S Reader when testing with PC or laptop.

Verify the baud rate is correct on the PC or laptop terminal emulator.

Nothing happens when the test tag is passed in front of the Encompass 4-S Reader.

Ensure that the Encompass 4-S Reader is powered on and the reader is in the correct read mode (#48N). Verify that the reader is set to RF ON (#6401) or the red/green pair are shorted.

The Encompass 4-S Reader came from another site and does not work the way the factory defaults indicate that it should.

Different commands were likely used to support the other site. Restore the factory defaults by issuing command #66F. The factory defaults will be restored except for RF operating frequency, which will be retained.

RF Interference or Poor Performance

Permanent structures and transient factors (such as large metal trucks) in the vicinity may affect RF signals. Metal objects, walls, wet pavement, and ice can reflect RF signals, degrading system performance (Figure 7).

Interference from RF and electrical sources can interfere with the optimal operation of the system.

Any RF interference at the site should be shielded, removed, or positioned farther from the Encompass 4-S Reader if possible.




Figure 7 Sources of RF Interference

For more information:

Sales Support
800.923.4824

Technical Support
505.856.8007

transcore.com



TRANSCORE[®]
Trusted Transportation Solutions

©2021 TransCore LP. All rights reserved. TRANSCORE is a registered trademark, and is used under license. All other trademarks listed are the property of their respective owners. Contents subject to change. Printed in the U.S.A.