

# INSTRUCTION MANUAL

---

INSTALLATION – OPERATION - MAINTENANCE

*JKSSS Series*

**Medium Voltage  
Solid State Starter**

*Issued: 3/20  
Firmware Version 7.34*



## Important Notice

The instructions contained in this manual are not intended to cover all details or variations in equipment types nor may it provide for every possible contingency concerning the installation, operations, or maintenance of this equipment. Should additional information be required, contact your Toshiba Customer Support Center.

The contents of this manual shall not become a part of or modify any prior or existing agreement, commitment, or relationship. The sales contract contains the entire obligation of Toshiba International Corporation. The warranty contained in the contract between the parties is the sole warranty of Toshiba International Corporation and any statements contained herein do not create new warranties or modify the existing warranty.

**Any electrical or mechanical modifications to this equipment without the prior written consent of Toshiba International Corporation may void all warranties or other safety certifications. Unauthorized modifications may also result in safety hazard or equipment damage.**

**Misuse of this equipment could result in injury and equipment damage. In no event will Toshiba International Corporation be responsible or liable for direct, indirect, special, or consequential damage or injury that may result from the misuse of this equipment.**

## About This Manual

Every effort has been made to provide accurate and concise information to you, our customer.

At Toshiba International Corporation we are continuously striving for better ways to meet the constantly changing needs of our customers. E-mail your comments, questions, or concerns about this publication to [TIC-Controls@toshiba.com](mailto:TIC-Controls@toshiba.com).

## **Purpose and Scope of Manual**

This manual provides information on how to safely install, operate, maintain, and dispose of your JKSSS solid state starter. The information provided in this manual is applicable to the **JKSSS starter** only.

This manual provides information on the various features and functions of this powerful device, including:

- Installation
- Operation
- Mechanical and electrical specifications

Included is a section on general safety instructions that describe the warning labels and symbols that are used on the device and throughout the manual. Read the manual completely before installing, operating, performing maintenance, or disposing of this equipment.

This manual and the accompanying drawings should be considered a permanent part of the equipment and should be readily available for reference and review. Dimensions shown in the manual are in imperial units and/or the metric equivalent. Connection drawings within this document convey the typical topology of the JKSSS starter.

Because of our commitment to continuous improvement, Toshiba International Corporation reserves the right, without prior notice, to update information, make product changes, or to discontinue any product or service identified in this publication.

**Toshiba International Corporation (TIC) shall not be liable for direct, indirect, special, or consequential damages resulting from the use of the information contained within this manual.**

This manual is copyrighted. No part of this manual may be photocopied or reproduced in any form without the prior written consent of Toshiba International Corporation.

© Copyright 2020 Toshiba International Corporation.

**TOSHIBA®** is a registered trademark of Toshiba Corporation. All other product or trade references appearing in this manual are registered trademarks of their respective owners.

All rights reserved.

Printed in the U.S.A.

## **Contacting TIC's Customer Support Center**

Toshiba International Corporation's Customer Support Center can be contacted to obtain help in resolving any system problem that you may experience or to provide application information.

The center is open from 8 a.m. to 5 p.m. (CST), Monday through Friday. The Support Center's toll free number is US (800) 231-1412/Fax (713) 466-8773 — Canada (800) 527-1204.

You may also contact Toshiba International Corporation by writing to:

**Toshiba International Corporation**

**13131 West Little York Road**

**Houston, Texas 77041-9990**

For further information on Toshiba International Corporation's products and services, please visit our website at [www.toshiba.com/tic/](http://www.toshiba.com/tic/).

## **TOSHIBA INTERNATIONAL CORPORATION**

### **JK Series Solid State Starter**

Complete the following information and retain for your records.

Model Number: \_\_\_\_\_

Serial Number: \_\_\_\_\_

Project Number (if applicable): \_\_\_\_\_

Date of Installation: \_\_\_\_\_

Inspected By: \_\_\_\_\_

Name of Application: \_\_\_\_\_

## General Safety Information

**DO NOT** attempt to install, operate, maintain, or dispose of this equipment until you have read and understood all of the product safety information and directions that are contained in this manual.

### Safety Alert Symbol

The **Safety Alert Symbol** is comprised of an equilateral triangle enclosing an exclamation mark. This indicates that a potential personal injury hazard exists.



### Signal Words

Listed below are the signal words that are used throughout this manual followed by their descriptions and associated symbols. When the words **DANGER**, **WARNING**, and **CAUTION** are used in this manual, they will be followed by important safety information that must be carefully followed.

The word **DANGER** preceded by the safety alert symbol indicates that an imminently hazardous situation exists that, if not avoided or if instructions are not followed precisely, will result in serious injury to personnel or loss of life.



The word **WARNING** preceded by the safety alert symbol indicates that a potentially hazardous situation exists that, if not avoided or if instructions are not followed precisely, could result in serious injury to personnel or loss of life.



The word **CAUTION** preceded by the safety alert symbol indicates that a potentially hazardous situation exists that, if not avoided or if instructions are not followed precisely, may result in minor or moderate injury.



The word **NOTE** provides helpful information.

### NOTE


## Equipment Labels (Safety, Rating, Information)

**DO NOT** attempt to install, operate, perform maintenance, or dispose of this equipment until you have read and understood all of the product labels and user directions that are contained in this manual.

Shown below are examples of safety labels that may be found attached to the equipment. **DO NOT** remove or cover any of the labels. If the labels are damaged or if additional labels are required, contact your Toshiba representative for additional labels.

Labels attached to the equipment are there to provide useful information or to indicate an imminently hazardous situation that may result in serious injury, severe property and equipment damage, or death if the instructions are not followed.

**SAFETY** labels that will be found on the equipment are shown below:



## Qualified Personnel

Installation, operation, and maintenance shall be performed by **Qualified Personnel ONLY**. A Qualified Person is one that has the skills and knowledge relating to the construction, installation, operation, and maintenance of the electrical equipment and has received safety training on the hazards involved (Refer to the latest edition of NFPA 70E for additional safety requirements). Outside the U.S., follow all applicable national and local safety practices.

**Qualified Personnel** shall:

- Have carefully read the entire manual.
- Be familiar with the construction and function of the starter, the equipment being driven, and the hazards involved.
- Be able to recognize and properly address hazards associated with the application of motor-driven equipment.
- Be trained and authorized to safely energize, de-energize, ground, lock-out/tag-out circuits and equipment, and clear faults in accordance with established safety practices.
- Be trained in the proper care and use of protective equipment such as safety shoes, rubber gloves, hard hats, safety glasses, face shields, flash clothing, etc., in accordance with established safety practices.
- Be trained in rendering first aid.

**For further information on workplace safety in the U.S. visit [www.osha.gov](http://www.osha.gov). Outside the U.S., refer to your local existing plant safety regulations.**

## Equipment Inspection

- Upon receipt of the equipment, inspect the packaging and equipment for shipping damage.
- Carefully unpack the equipment and check for parts that may have been damaged during shipping, missing parts, or concealed damage. If any discrepancies are discovered, it should be noted with the carrier prior to accepting the shipment, if possible. File a claim with the carrier if necessary and immediately notify your Toshiba Customer Support Center.
- **DO NOT** install or energize equipment that has been damaged. Damage equipment may fail during operation resulting in further equipment damage or personal injury.
- Check to see that the rated capacity and the model number specified on the nameplate conform to the order specifications.
- Modification of this equipment is dangerous and is to be performed by factory trained personnel **ONLY**. When modifications are required contact your Toshiba representative.
- Inspections may be required after moving the equipment.
- Contact your Toshiba representative for assistance if required.

## Handling and Storage

- Use proper lifting techniques when moving the equipment, including properly sizing up the load, getting assistance, and using a forklift if required.
- Store in a well-ventilated location, preferably in the original packaging, if the equipment will not be used upon receipt.
- Store in a cool, clean, and dry location. Avoid storage locations with extreme temperatures, rapid temperature changes, high humidity, moisture, dust, corrosive gases, or metal particles.
- The storage temperature range of the breaker is 23° to 104° F (-5° to 40° C).
- **DO NOT** store the unit in places that are exposed to outside weather conditions (e.g., wind, rain, snow).
- Store in an upright position as indicated on the shipping carton.
- Include any other product-specific requirement.

## Disposal

Never dispose of electrical components via incineration. Contact your state environmental agency for details on disposal of electrical components and packaging in your area.

## Installation Precautions Location and Ambient Requirements

- Adequate personnel working space and illumination must be provided for adjustment, inspection, and maintenance of the equipment. In the U.S., refer to NEC Article 110-34 for requirements. Outside the U.S., follow applicable local electrical code requirements.
- Avoid installation in areas where vibration, heat, humidity, dust, fibers, steel particles, explosive/corrosive mists or gasses, or sources of electrical noise are present.
- Do not install the starter where it may be exposed to flammable chemicals or gasses, water, solvents, or other fluids.
- The ambient operating temperature shall be between 0° to 40° C (32° and 105° F).
- Allow proper clearance spaces for installation. Do not obstruct the ventilation openings. Refer to the recommended minimum installation dimensions as shown on the enclosure outline drawings.


## Mounting Requirements

- Only **Qualified Personnel** should install this equipment.
- Install the unit in a secure upright position in a well-ventilated area.
- A noncombustible insulating floor or mat should be provided in the area immediately surrounding the electrical system at the place where maintenance operations are to be performed.

- Equipment should be installed according to all applicable national, regional, and industry codes and standards. In the U.S., installation of the equipment should conform to NEC Article 110 Requirements For Electrical Installations and to OSHA requirements.
- In the U.S., installation practices should conform to the latest revision of NFPA 70E Electrical Safety Requirements for Employee Workplaces. Outside the U.S., applicable national and local installation safety practices should be followed. In the EU refer to section 6.5 of HD 637 and its sub clauses.

## Personnel Protection

- Installation, operation, and maintenance shall be performed by **Qualified Personnel Only**.
- A thorough understanding of the starter will be required before installation, operation, or maintenance.



- Rotating machinery and live conductors can be hazardous and shall not come into contact with humans. Personnel should be protected from all rotating machinery and electrical hazards at all times.
- Insulators, machine guards, and electrical safeguards may fail or be defeated by the purposeful or inadvertent actions of workers. Insulators, machine guards and electrical safeguards are to be inspected (and tested where possible) at installation and periodically after installation for potential hazardous conditions.
- Do not allow personnel near rotating machinery. Warning signs to this effect shall be posted at or near the machinery.
- Do not allow personnel near electrical conductors. Human contact with electrical conductors can be fatal. Warning signs to this effect shall be posted at or near the hazard.
- Personal protection equipment shall be provided and used to protect employees from any hazards inherent to the system operation.

## Table of Contents

	PAGE
<b>Chapter 1: Introduction</b> .....	1
<b>1.1 Overview</b> .....	1
<b>1.2 Specifications</b> .....	1-2
<b>1.3 Reference Chart</b> .....	3
<b>1.4 Design Features</b> .....	4-5
<b>1.5 Theory of Operation</b> .....	5-6
<b>1.6 General Protection</b> .....	6-7
<b>1.7 Thermal Overload Protection</b> .....	7
<b>1.8 Firing Circuit</b> .....	8
<b>1.9 Electronics</b> .....	8-9
<i>Fig. 1.9 Keypad Interface</i> .....	8
<b>Chapter 2: Connections</b> .....	10
<b>2.1 Warnings</b> .....	10
<b>2.2 Receiving, Handling/Moving and Unpacking</b> .....	10
<b>2.3 Initial Inspection</b> .....	11
<b>2.4 Location</b> .....	12
<b>2.5 Mounting</b> .....	13
<b>2.6 Additional Cabinet Entries</b> .....	13
<b>2.7 Pre-energization Check</b> .....	14
<b>2.8 Medium Voltage Power Connections</b> .....	16
<b>2.9 Control Connections</b> .....	19
2.9.1 TCB Board .....	19
<i>Fig. 2.9.1 TCB Terminal and Control Board</i> .....	19
2.9.2 Description of Terminal Connections .....	20-22
2.9.3 Description of Jumper Selections and Functions .....	22
2.9.4 Description of Switch Settings and Functions .....	23
2.9.5 Description of LED Indicator Functions .....	23
<b>2.10 Circuit Board Layout Reference Section</b> .....	24-27
<i>Fig. 2.10.1 RTD Board</i> .....	24
<i>Fig. 2.10.2 RS485 / RS422 Communications Board</i> .....	24
<i>Fig. 2.10.3 Main Board</i> .....	25
<i>Fig. 2.10.4 CPU Board</i> .....	26
<b>2.11 Typical Wiring Diagram</b> .....	27
<i>Fig. 2.11 Typical Wiring Diagram</i> .....	27
<b>Chapter 3: Start-Up</b> .....	28
<b>3.1 Introduction</b> .....	28
<b>3.2 Acceleration Adjustments</b> .....	28
<i>Fig. 3.2.3 Current Limit</i> .....	28
<b>3.3 Deceleration Adjustments</b> .....	29-30
<i>Fig. 3.3 Deceleration Control</i> .....	29
<b>3.4 Sequence of Normal Operation</b> .....	30
<b>3.5 Emergency Bypass Operation</b> .....	31
<b>Chapter 4: User Interface and Menu Navigation</b> .....	32
<b>4.1 Keypad/Operator Interface</b> .....	32
<b>4.2 Menu Navigation</b> .....	33
4.2.1 Password Access .....	34
4.2.2 Changing Setpoints .....	34

<b>Chapter 5: Setpoint Programming</b> .....	35
<b>5.1 Setpoints Page List</b> .....	35-41
5.1.1 Basic Configuration (Setpoint Page 1) .....	35
5.1.2 Starter Configuration (Setpoint Page 2) .....	35
5.1.3 Phase and Ground Settings (Setpoint Page 3) .....	36
5.1.4 Relay Assignments (Setpoint Page 4) .....	37
5.1.5 Relay Configuration (Setpoint Page 5) .....	38
5.1.6 User I/O Configuration (Setpoint Page 6) .....	38
5.1.7 Custom Acceleration Curve (Setpoint Page 7) .....	39
5.1.8 Overload Curve Configuration (Setpoint Page 8) .....	39
5.1.9 RTD Configuration (Setpoint Page 9) .....	40
5.1.10 RTD Password Level Configuration (Setpoint Page 10) .....	41
5.1.11 Communication (Setpoint Page 11) .....	41
5.1.12 System (Setpoint Page 12) .....	41
5.1.13 Calibration and Service (Setpoint Page 13) .....	41
<b>5.2 Setpoints Menu and Parameter Explanation</b> .....	42-57
SP.1 Basic Configuration.....	42-43
SP.2 Starter Configuration.....	44-47
<i>Fig. SP2.3 Example of Switching from Jog to Start Ramp #1 Type: Voltage</i> .....	45
<i>Fig. SP2.4 Power Ramp</i> .....	46
SP.3 Phase & Ground Settings .....	48-50
SP.4 Relay Assignment.....	51-53
SP.5 Relay Configuration .....	53
SP.6 User I/O Configuration .....	54-56
SP.7 Custom Acceleration Curve .....	57-59
SP.8 Overload Curve Configuration .....	60-61
SP.9 RTD Configuration .....	62-63
SP.10 Set Password.....	63
SP.11 Communications .....	64
SP.12 System Setpoints .....	65-66
SP.13 Calibration & Service .....	67
<b>Chapter 6: Metering Pages</b> .....	68
<b>6.1 Metering Page List</b> .....	68-69
6.1.1 Metering Menu & Data (Metering Page 1) .....	68
6.1.2 Metering (Metering Page 2) .....	68
6.1.3 RTD Values (Metering Page 3) .....	68
6.1.4 Status (Metering Page 4) .....	69
6.1.5 Event Recorder (Metering Page 5) .....	69
6.1.6 Last Trip (Metering Page 6) .....	69
6.1.7 Statistics (Metering Page 7) .....	69
<b>6.2 Metering Menu and Explanation</b> .....	70-77
MP.1 Metering Data.....	71
MP.2 Metering .....	72
MP.3 RTD Values .....	73
MP.4 Status .....	74
MP.5 Event Recorder – 60 Events .....	75
MP.6 Last Trip .....	76
MP.7 Statistics .....	77

<b>Chapter 7: Maintenance and Troubleshooting</b> .....	78
7.1 Failure Analysis.....	78-80
7.1.1 SCR Testing Procedure.....	80
<b>APPENDIX A: Modbus RTU Communication and Registers</b> .....	81

## Chapter 1 - Introduction

This chapter is an introduction to the Toshiba **JKSSS+** Reduced Voltage Solid State Soft Starter for medium voltage AC motors. It is highly recommended that users read this section thoroughly to become familiar with the basic configuration, operation and features before applying the soft starter.

### 1.1 Overview

The standard **JKSSS+ Series** solid state starter is a complete NEMA Class E-2 motor controller designed for the starting, protection and control of AC medium voltage motors. It contains the motor disconnect switch, motor circuit fuses, control power transformer, a line isolation contactor, SCR stack assembly, bypass contactor, and low voltage controls.

### 1.2 Specifications

#### GENERAL

GENERAL	
Unit Running Overload Capacity (Percent of motor FLA)	125% - Continuous 500% - 60 seconds 1 Cycle: Up to 14x FLA (Internally protected by the programmable short circuit)
Frequency	50 or 60Hz, +2Hz hardware selectable
Power Circuit	6 SCRs, 12 SCRs, 18 SCRs (Model dependent)
SCR Peak Inverse Voltage Ratings	6500V - 19500V (Model dependent see Table 1)
Phase Insensitivity	User selectable phase sequence detection
Transient Voltage Protection	RC snubber dv/dt networks (One per inverse pair of SCRs)
Ambient Condition Design	Enclosed units: 0° to 40°C (32° to 104°F) (optional - 20° to 50° C with heaters) 5 - 95% relative humidity 0 - 3300 ft. (1000m) above sea level without de-rating (Ratings for ambient conditions external to unit)
Control	2 or 3 wire 120VAC (Customer supplied)
Auxiliary Contacts	Multiple: Form C (Contacts), rated 5 Amps, 240VAC max. 8 Relays (4 programmable): Form C contacts Fault Indicator: Form C contacts
BIL Rating	2300V - 7200V 60KV
Approvals	400A model: UL listed, Canadian UL (cUL) listed

#### ADVANCED MOTOR PROTECTION

ADVANCED MOTOR PROTECTION	
Two Stage Electronic Overload Curves	Starting: Programmable for Class 5 through 30 Run: Programmable for Class 5 through 30 when "At-Speed" is detected.
Overload Reset	Manual
Retentive Thermal Memory	Overload circuit retains thermal condition of the motor regardless of control power status. Unit uses real time clock to adjust for off time.
Dynamic Reset Capacity	Overload will not reset until thermal capacity available in the motor is sufficient for a successful restart. Starter learns and retains this information by monitoring previous successful starts.
Phase Current Imbalance Protection	Imbalance Trip Level: 5 - 30% current between any two phases Imbalance Trip Delay: 1 -20 seconds
Over Current Protection (Electronic Shear Pin)	Trip Level: 100 - 300% of motor FLA Trip Delay: 1 - 20 seconds
Load Loss Trip Protection	Under Current Trip Level: 10 -90 % of motor FLA Under Current Trip Delay: 1 - 60 seconds
Coast Down (Back Spin) Lockout Timer	Coast Down Time Range: 1 - 60 minutes
Starts-per-hour Lockout Timer	Range: 1 - 6 successful starts per hour Time between starts: 1 - 60 minutes between start attempts

PROGRAMMABLE OUTPUTS	
Type / Rating	Form C (SPDT), Rated 5A, 240Vac max, (1200 VA)
Run Indication	Programmable
At Speed Indication	Programmable
Acceleration Adjustments	Programmable Ramp Types: Voltage or Current Ramp (VR or CR) Starting Torque: 0 - 100% of line voltage (VR) or 0 - 600% of motor FLA (CR) Ramp Time: 1 to 120 seconds Current Limit: 200 - 500% (VR or CR)
Dual Ramp Settings	4 Options: VR1+VR2; VR1+CR2; CR1+CR2; CR1+VR2 Dual Ramp Control: Ramp 1 = Default Ramp 2 = selectable via dry contact input
Deceleration Adjustments	Begin Decel Level: 0 - 100% of line voltage Stop Level: 0 to 1% less than Begin Decel Level Decel Time: 1 - 60 seconds
Jog Settings	Voltage Jog: 5 - 75%
Kick Start Settings	Kick Voltage: 10 - 100% Kick Time: 0.1 - 2 seconds
Fault Display	Shorted SCR, Phase Loss, Shunt Trip, Phase Imbalance Trip, Overload, Overtemp, Overcurrent, Short Circuit, Load Loss, Undervoltage or Any Trip
Lockout Display	Coast Down Time, Starts Per Hour, Time Between Starts, and Any Lockout

EVENT HISTORY	
Up to 60 Events	Data includes cause of event, time, date, voltage, power factor and current for each phase and ground fault current at time of event

METERING FUNCTIONS	
Motor Load	Percent of FLA
Current Data	A, B, C Phase Current, Avg. Current, Ground Fault (Option)
Thermal Data	Remaining thermal register; thermal capacity to start
Start Data	Avg. Start Time, Avg. Start Current, Measured Capacity to start, time since last start.
RTD Data	Temperature readings from up to 12 RTDs (6 stator RTDs)
Voltage Metering	kW, kVAR, PF, kWh

SERIAL COMMUNICATIONS	
Protocol	Modbus RTU
Signal	RS-485, RS-422 or RS232
Network	Up to 247 devices per mode
Functionality	Full operation, status view, and programming via communications port

OPERATOR INTERFACE	
OLED Readout	Alpha numeric OLED display
Keypad	8 function keys with tactile feedback
Status Indicators	12 LEDs include Power, Run, Alarm, Trip, Aux Relays
Remote Mount Capability	Up to 1000 circuit-feet from chassis (Use twisted, shielded wire & power source)

CLOCK and MEMORY	
Operating Memory	SRAM loaded from EEPROM at initialization
Factory Default Storage	Flash EPROM, field replaceable
Customer Settings and Status	Non-volatile EEPROM, no battery backup necessary
Real Time Clock	Lithium ion battery for clock memory only

1.3 Reference chart

SEC.	Table or Drawing	Page Number
1.2	Specifications	1 - 2
1.4	Unit PIV Ratings	4
1.9 & 4.1	Keypad Operator Interface	8 & 32
2.9	TCB Board Layout and Connections	19
	TB1, TB2 & TB3 Description	20
	TB4, TB5, TB6 & TB7 Description	21
	TB8 Description	22
	Jumper Selections	22
	Switch Settings	23
	LED Indicators	23
2.3	RTD Board	24
	Communications Board Layout & Connections: RS485 and RS422	24
	Power Board & Connections	25
	CPU Board Layout & Connections	26
2.4	Typical Wiring Diagram	27
3.2	Acceleration Adjustments	28
3.3	Deceleration Adjustments	29
3.4	Sequence of Operations	30
4.2	Menu Navigation	32
	Changing Setpoints Example	34
5.1	Setpoints Page List	35 - 41
5.2	Setpoint Menu & Parameter Explanation	42
	Setpoint Page 1 Displays - Basic Configuration	42
	Overload Class Trip Curves	43
	Setpoint Page 2 Displays - Starter Configuration	44
	Jog/Voltage Ramp	45
	Setpoint Page 3 Displays - Phase & Ground Settings	48 - 50
	Overcurrent Trip Delay Graph	48
	Setpoint Page 4 Displays - Relay Assignment	51-53
	Setpoint Page 5 Displays - Relay Configuration	53
	Setpoint Page 6 Displays - User I/O Configuration	54 - 56

SEC.	Table or Drawing	Page Number	
5.2	Setpoint Page 7 Displays - Custom Acceleration Curve	57 - 59	
	Setpoint Page 8 Displays - Overload Curve Configuration	60-61	
	Setpoint Page 9 Displays - RTD Configuration	62-63	
	Setpoint Page 10 Displays - Set Password	63	
	Setpoint Page 11 Displays - Communications	64	
	Setpoint Page 12 Displays - System Setpoints	65-66	
5.2	Setpoint Page 13 Displays - Calibration & Service	67	
	6.1	Metering Page List	68-69
6.2	Metering Menu	70	
	Metering Page 1 Displays - Metering Data	71	
	Metering Page 2 Displays - Metering	72	
	Metering Page 3 Displays - RTD Values	73	
	Metering Page 4 Displays - Status	74	
	Metering Page 5 Displays - Event Recorder	75	
	Metering Page 6 Displays - Last Trip	76	
	Metering Page 7 Displays - Statistics	77	
	7.1	Failure Analysis & Troubleshooting	78 - 80
	7.1	SCR Testing Procedure	80
NOTES-			

### 1.4 Design Features

The standard **JKSSS+** configuration is a complete NEMA Class E-2 motor controller which includes the following features:

- **Isolation Switch:** An isolation switch is provided in the incoming power section of the starter assembly. The maximum voltage is 7200V.

Power is switched on and off to the controller by a fixed-mounted, externally-operated, three-pole isolation switch. When the switch is in the opened position, incoming power is isolated from the controller compartment interior by an automatic shutter. For additional safety, the load terminals of the switch are automatically grounded when the switch is opened. This allows any stored energy in the controller load circuit to be discharged by closing the contactor using test power.

A viewing window in the Main Incoming Power Compartment allows visual inspection of the disconnect blade status with the medium voltage door closed.

The external operating handle for the isolation switch is designed to accept up to three external padlocks in the OFF position.

For additional information on the isolation switch, see instruction manual VF010H01, VF010H02 or VF010H03.

- **Power Fuses:** As a NEMA Class E2 controller, current limiting primary power fuses are provided for each incoming phase.

Typically the fuses are ANSI class “R” for units rated up to 5000V. The fuses are sized according to motor locked rotor current and are coordinated with the solid state overload relay. The fuse and overload coordination is designed to allow the controller and contactor to clear low and medium level faults. This prevents exceeding the contactor interrupt ratings. Fuses interrupt high level faults that exceed the contactor interrupt ratings.

- **SCR Power Modules:** For each phase, the SCRs are arranged in inverse parallel pairs and series strings as indicated in Table 1 below to facilitate sufficient Peak Inverse Voltage ratings for the application.

- **RC Snubber Networks:** Provide Transient Voltage Protection for SCR Power Modules in each phase to avoid dv/dt damage.

- **Firing Circuit:** The SCRs are gated (turned on) using a Sustained Pulse Firing Circuit. This circuitry is isolated from the control voltage by means of fiber optics.

**Table 1 Unit PIV Ratings**

200 & 400 Amps Units			
Voltage	Series Pairs	Total Number of SCRs	PIV Rating
2300 V	0	6	6500 V
3300 / 4160 V	2	12	13000 V
6000 – 6600V	3	18	19500 V

500, 600 & 800 Amps Units			
Voltage	Series Pairs	Total Number of SCRs	PIV Rating
2300 V	2	12	6500 V
3300 / 4160 V	4	24	13000 V
6000 – 6600V	4	36	18000 V

Removable conduit entry plates are provided in the bottom of the enclosures to facilitate drilling and punching of conduit holes without exposing the equipment to contamination from metal debris.

- **Enclosure Finish:** The enclosure is suitable for use in noncorrosive environments. The paint is ANSI 61 gray polyurethane powder over a zinc phosphate pretreatment with a minimum thickness of 2 mil. 11 gauge steel is used in all enclosures. All NEMA 1 & 12 units have bottom entrance plates.
- **Lifting Provisions:** Eyes or angles capable of supporting the maximum weight of each shipping split are provided on the top of the enclosure.
- **Power Bus:** Optional main horizontal phase bus bars can be configured to extend the entire length of the starter lineup. Bus bar material is tin-plated or silver-plated copper. All bus ratings are per UL Standard 347.
- **Bracing:** Bus bars are braced with non-tracking fire resistant non-hygroscopic insulation supports and have a minimum fault current rating of 50,000 Amps.
- **Connections:** All bus connections use 2 bolts minimum, with Belleville spring washers to ensure tightness. Splice kits for each shipping split are included, along with specific installation instructions.
- **Ground Bus:** A continuous ground bus bar with a minimum rating of 400 Amps extends the entire length of the starter near the bottom of each enclosure. A grounding strap connects each vertically adjacent compartment and also ties the grounding arm of the disconnect switch to the main ground bus bar (**see section 2.8**).
- **Seismic Qualifications:** The entire starter assembly, when properly installed, withstands vertical and horizontal accelerations typical of seismic Zones 1 through 4 as defined in the UBC. The assembly will not overturn or show significant lateral movement, but cannot be expected to continue operating during, or after, a seismic event.

## **1.5 Theory of Operation**

The soft starter is CPU controlled, using a microprocessor based protection and control system for the motor and starter assembly. The CPU uses Phase Angle Firing control of the SCRs to apply a reduced voltage to the motor, and then slowly and gently increases torque using voltage and current control until the motor accelerates to full speed. This starting method lowers the starting current of the motor, reducing electrical stresses on the power system and motor. It also reduces peak starting torque stresses on both the motor and load mechanical components, promoting longer service life and less downtime.

### **1.5.1 Acceleration:**

The soft starter comes standard with several methods of accelerating the motor so that it can be programmed to match almost any industrial AC motor application. The factory default setting applies a **Voltage Ramp with Current Limit** as this has been proven to be the most reliable starting method for the vast majority of applications. Using this starting method, the Initial Torque setting applies just enough voltage to the motor to cause the motor shaft to begin to turn. This voltage is then gradually increased over time (Ramp Time setting) until one of three things happen: the motor accelerates to full speed, the Ramp Time expires, or a Current Limit setting is reached. If the motor accelerates to full speed before the ramp time setting has expired, an automatic Anti-oscillation feature will override the remaining ramp time and full voltage will be applied. This will prevent any surging or pulsation in the motor torque, which might otherwise occur due to the load not being fully coupled to the motor when operating at reduced voltage and torque levels. If the motor has not reached full speed at the end of the ramp time setting, the current limit setting will proportionally control the maximum output torque. Feedback sensors provide protection against a stall condition, an overload condition, or excessive acceleration time.

The Current Limit feature is provided to accommodate installations where there is limited power available (for example, on-site generator power or utility lines with limited capacity). The torque is increased until the motor current reaches the pre-set Current Limit point and it is then held at that level. Current Limit overrides the ramp time setting so if the motor has not accelerated to full speed under the Current Limit setting, the current remains limited for as long as it takes the motor to accelerate to full speed. When the motor reaches full speed and the

current drops to running levels, the soft starter detects an At-Speed condition and closes the Bypass Contactor. The Bypass Contactor serves to shunt power around the SCR stack assemblies to prevent heat build-up in the starter enclosure due to the slight voltage drop across the SCRs. At this point, the motor is operating at full voltage, speed and power.

Other starting methods available in the soft starter are:

- **Current Ramp** uses a closed current feedback PID loop to provide a linear torque increase up to a Maximum Current level.
- **Constant Current** is immediately increased to the Current Limit point and held there until the motor reaches full speed.
- **Power (kW) Ramp** uses True RMS kW feedback PID loop to provide a linear increase in True RMS motor power to a maximum set kW value.
- **Custom Curve** gives the user the ability to plot torque and time points on a graph. The soft starter will then accelerate the motor following these points.
- **Tachometer Feedback Ramp** uses a closed loop speed follower method monitoring a tachometer input signal from the motor or load shaft to provide a linear RPM acceleration.

**1.5.2 Deceleration:** the soft starter provides the user with the option of having the load coast to a stop or controlling the deceleration by slowly reducing the voltage to the motor upon initiating a stop command. The Decel feature is the **opposite of DC injection braking** in that the motor will actually take longer to come to a stop than if allowed to coast to a stop. The most common application for the Decel feature is pumping applications where a controlled stop prevents water hammer and mechanical damage to the system.

## **1.6 General Protection**

The soft starter is provided with a built-in motor protection relay that can be programmed for primary protection of the motor / load system. Operation of the soft starter can be divided into 4 modes: Ready, Start, Run and Stop.

**1.6.1. Ready Mode:** In this mode, control and line power are applied and the starter is ready for a start command. Protection during this mode includes the monitoring of current for leakage through multiple shorted SCRs or welded contacts on the Bypass Contactor. Other protection features in effect are:

- Starter Power Pole Temperature
- Shorted SCR
- Blown Fuse Indication
- Phase Reversal (if enabled)
- Line Frequency Trip Window
- External Input Faults
- Undervoltage
- Overvoltage

**Note:** The “Programming Mode” can only be entered from the Ready Mode. Any attempt to enter data while the motor is starting or running will be blocked. During programming, all protection features and start command are disabled.

**1.6.2 Start Mode:** These additional protection functions are enabled when the soft starter receives a valid Start command:

- Phase Reversal (if enabled) – Phase Reversal will still be on and is not a newly active feature when starting.
- Start Curve
- Acceleration Timer
- Phase Imbalance
- Short Circuit / Load Pre-check (Toe-in-the-Water)
- Ground Fault (Optional)
- External Input Faults
- Accumulated Starting FLA Units (I2t Protection)
- Starting Overload Protection Curve Selection
- Thermal Capacity

**Note:** Shorted SCR protection is no longer in effect once the soft starter goes into the Start Mode.

**1.6.3 Run Mode:** The soft starter enters the Run Mode when it reaches full output voltage *and* the motor current drops below the FLA setting (motor nameplate FLA plus service factor) for a pre-determined period of time. During the Run Mode these additional protection features are enabled:

- Running Overload Curve
- Phase Loss
- Under Current / Load Loss
- Over Current / Electronic Shear Pin (Jam Protection)
- External Input Faults

**1.6.4 Stop Mode:** Once a Stop command has been given, the protection features change depending on which Stop Mode is selected.

- Decel Mode: Retains all protection features of the Run Mode. At the end of Decel, the motor will be stopped and the protection features change as indicated below.
- Coast-To-Stop Mode: Power is immediately removed from the motor and the soft starter returns to the Ready Mode.
- Additional protection features activated when the stop command is given include:
  - Coast-Down / Back Spin Timer
  - Starts-per-Hour
  - Time between Starts
  - External Input Faults

## **1.7 Thermal Overload Protection**

The soft starter plays an important role in the protection of your motor in that it monitors the motor for excessive thermal conditions due to starting, running and ambient conditions. The soft starter has a Dynamic Thermal Register system in the CPU that provides a mathematical representation of the thermal state of the motor. This thermal state information is retained in memory and is monitored for excesses in both value and rate of change. Input is derived from current imbalances and RTD measurements making it dynamic to all processes involving the motor. The Soft Starter monitors these conditions separately during the Start and Run modes to provide proper thermal overload protection at all times.

**1.7.1 Start Mode overload protection** is selectable using one of three methods:

- **Basic Protection:** I<sup>2</sup>t data is accumulated and plotted based on an Overload Curve selected in programming. This is programmed per NEMA Class 5-30 standard curves and is based on the Locked Rotor Current (from the motor nameplate) as programmed into the Soft Starter.
- **Measured Start Capacity:** The user enters a measured amount of thermal capacity from a pre-selected successful start as a setpoint to the Thermal Register for the soft starter to follow.
- **Learned Curve Protection:** The user sets the soft starter to the “LEARN” mode and starts the motor under normal starting conditions. The CPU then samples and records 100 data points during the start curve, analyzes them and creates a graphical representation in memory. The soft starter is then switched to Curve Follow protection mode and monitors motor performance against this curve. This feature is especially useful in initial commissioning tests to record a base line performance sample (in this case, it is not necessarily used for motor protection).

**1.7.2 Run Mode overload protection** is initiated when the soft starter determines that the motor is At-Speed. Overload Protection is initiated when the motor RMS current rises above a “pick-up point” (as determined by the motor nameplate FLA and service factor). Run mode protection is provided by the CPU monitoring the Dynamic Thermal Register. Data for the Dynamic Thermal Register is accumulated from I<sup>2</sup>t calculations and cooling rates. A trip occurs when the register reaches 100% as determined by the selected Overload Protection Curve (NEMA Class 5-30 standard curves) and is based on the programmed Locked Rotor Current indicated on the motor nameplate. The Dynamic Thermal Register is altered, or “biased”, by the following conditions:

- **Current Imbalance** will bias the register higher to add protection from additional motor heating during a current imbalance condition.
- **Normal Cooling** is provided when the motor current drops below the pick-up point or the motor is offline. The cooling rate is lower for motors that are off-line (such as after a trip) since cooling fans are also inoperative.
- **RTD Input** will bias the register in either direction based on real-time input of the motor, bearing and even ambient temperature conditions.
- **Dynamic Reset** is another feature that adds reliability and consistency to the performance of the soft starter. If a

motor overload condition occurs and the Overload protection trips, it cannot be reset until sufficient cool down time has elapsed. This cool down time is determined by the “Learned Thermal Capacity” required to start the motor which must be regained before the overload can be reset. This ensures sufficient thermal capacity for a successful restart of motor.

- **Retentive Memory** provides continuous overload protection and true thermal modeling by means of a running back up of the thermal register even if power is lost. Upon restoration of power, the soft starter will read the Real Time Clock, then recalculate and restore the thermal register to what it should be, given the elapsed time and the cool down rate of the motor.
- **Learned Reset Capacity** is a feature that is unique to the soft starter. By sampling the amount of thermal capacity used in the previous three successful starts, the starter will not allow a reset until a sufficient amount of thermal capacity has been regained in the motor. This prevents nuisance tripping and insures that unsuccessful start attempts (which would otherwise use up the starts-per-hour capacity of the motor) are not counted.

### **1.8 Firing Circuit**

The SCR gate firing circuit is critical to the performance and stability of the system. The firing circuit includes several unique features which enhance the ruggedness, noise immunity and flexibility for maximized performance. In most applications, this performance is attained without the need for reactors or field installed devices. These features include:


- **Auto Synchronizing** of the gate timing pulses match each phase firing angle to their respective phases. The soft starter actively tracks minor shifts in the line frequency avoiding nuisance tripping that may happen with conventional gate firing systems. This is especially useful on portable or backup generator supplies, allowing the soft starter to be used confidently in applications that have unstable power.
- **Sustained Pulse** firing keeps the firing signal active for 270 electrical degrees ensuring that the DC gate pulse causes the SCR to fire even if line noise is present. This provides the soft starter with superior noise immunity and protects against misfiring, enhancing the soft starter stability.
- **Closed Loop Firing Control** is a method of balancing the SCR firing pattern. The CPU uses feedback signals from both the output current and voltage providing smooth output and preventing imbalances during ramping which prevents unnecessary motor heating.
- **Transformer Isolation** of SCR firing information and signals prevents interference from line noise and EMI/RFI that may be present. Three phase isolation transformers provide potential measurement, firing board timing while Providing isolation from the line voltage. High isolation Ring Transformers are used to step the 120V control voltage down to 28VAC for the Sustained Pulse firing circuit, providing further isolation for the SCR gates.
- **Fiber Optic Isolation** is provided for all gate drive and current feedback signal interfaces between the Medium Voltage and Low Voltage systems.

## 1.9 Electronics

The Soft Starter electronic systems are divided into two categories: Low Voltage and Medium Voltage, and are based on where they are located in the starter structure.

**1.9.1 Low Voltage** electronics includes the Keypad Operator Interface, the CPU and Main Power PC boards, which are located in an isolated Low Voltage compartment of the enclosure.


- **Keypad Operator Interface** is a 2 line x 20 character OLED display. The display reads out in truncated English and can show multiple data points on each screen. Twelve LED indicators are included, which show the status of Power, RUN, ALARM, TRIP and the 8 AUX RELAYS. The Operator communicates with the CPU board via a serial cable link and can be remotely located up to 1000ft. from the starter. The following **FIG. 1.9** shows the Keypad Operator Interface.



**FIG. 1.9 Keypad Operator Interface.**

- **CPU Board** is where the microprocessor and communications co-processor is located and is attached to the main Power board. The CPU determines operating functions, stores user programming and acts upon feedback signals for faults, metering and historical data. The board communicates with the Keypad Operator Interface via a serial link cable. Analog and Digital I/O are also located on the CPU board (see **FIG. 2.3.4**).
- **Main Power Board** also referred to as the Firing Board, contains the Auxiliary I/O relays and interfaces to the TCB board (see below) for user interface. This board generates all firing signals for the SCR stacks and receives feedback signals which are isolated via fiber optics. The board provides signal conditioning in preparation for analog to digital signal conversion (see **FIG. 2.3.3**).
- **TCB (Terminal and Control Board)** is the user connection interface board. It is located in the Low Voltage section and does not actually connect directly to the medium voltage components other than the contactor coils. This board contains the user terminal blocks, output relays (duplicated), inputs and control power connections. It also contains additional timed relays for interfacing with Power Factor Correction contactors (if used) and other external devices. Please note Power Factor Capacitor warnings in **Section 2.1** (see **FIG. 2.9.1**).

**1.9.2 Control Electronics** are located in the Medium Voltage section of the soft starter. They include the Gate Drive and Temp / CT boards.


 <b>DANGER</b>
<b>HAZARDOUS VOLTAGE</b>  <b>Disconnect all power supplying this equipment prior to working on it.</b>  <b>Failure to follow this instruction will result in death or serious injury.</b>


- **Gate Drive Boards** are located directly on the SCR stacks. These boards communicate to the Main Power board via fiber optic cables. They amplify the gate pulse signals with power from the Ring Transformers to create the Sustained Pulse Firing of the SCRs. There is one Gate Drive board for each pair of SCRs in each stack.
- **Temp / CT Boards** are attached to the Gate Drive boards on the SCR stacks and provide the heat sink Temperature and current signals back to the Main Power Board via fiber optic cables.
- **MOV Boards** are attached to standoffs mounted on the SCR heat sinks and are mounted directly below the Gate Drive boards. The MOV boards are used to protect the gate/cathode section of the SCRs.
- **DV/DT Boards** are also attached to standoffs mounted on the SCR heat sinks and are mounted below the MOV boards. The DV/DT boards are used to reduce voltage transients across the stack assemblies.

## Chapter 2 - Connections

### 2.1 Warnings

- **Do not service this equipment with voltage applied!** The unit can be the source of fatal electric shock! To avoid shock hazard, disconnect main power and control power before working on the unit. Warning labels must be attached to terminals, enclosure and control panel to meet local codes observing Lock Out, Tag Out procedures.
- **Do not connect (PFC) capacitors or surge capacitors to the load side (motor side) of the unit.** This will cause di/dt damage to the SCRs when they are turned on and will void the warranty on this product. Capacitors can only be connected to the load side of the starter through the use of an isolating contactor which is closed after the soft starting sequence has been completed or when di/dt limiting inductors are factory installed.
- **Avoid connecting capacitors to the input side of the unit.** If you cannot avoid using capacitors across the power lines, they must be located as far upstream as possible of the input line contactor. In this situation, an optional power factor correction (PFC) capacitor contactor should be specified. For additional information and specifications or when di/dt limiting inductors are factory installed, please contact the factory.

 <b>DANGER</b>
<b>HAZARDOUS VOLTAGE</b>  <b>Disconnect all power supplying this equipment prior to working on it.</b>  <b>Failure to follow this instruction will result in death or serious injury.</b>

 <b>CAUTION</b>
<b>SCR DAMAGE</b>  <b>Do not connect (PFC) capacitors to the load side of the unit.</b>  <b>Doing so will cause DI/DT damage to the SCRs when energized.</b>

 <b>WARNING</b>
<b>SAFETY HAZARD</b>  <b>Do not bypass electrical or mechanical interlocks.</b>  <b>Failure to follow this instruction will cause severe equipment damage, serious injury or death.</b>

- **Never interchange the input and output power connections on the unit.** This will cause excessive voltage to the control circuit logic.
- **For bus protection, it is strongly recommended to use non-gap MOV Type lightning arrestors in areas where lightning is a significant problem.** The arrestors should be mounted on the nearest utility pole at the Station or optionally included with the unit at the time of order.
- **Medium Voltage cables can have significant capacitance values by design which can elevate Di/Dt thru the SCRs to unsafe levels.** Compensating inductors can limit these values to safe levels. Contact the factory if you need more information on this subject.

For additional information on the equipment, refer to the following additional instruction manuals:

For fixed type input isolation contactor - "JK Series Medium Voltage Controllers - Fixed Type", manual number **VF010H03** or "JK Series 720 Ampere Medium Voltage Controllers", manual number **VF010H02**.

For drawout type input isolation contactor - "JK Series Medium Voltage Controllers", manual number **VF010H01**.

## 2.2 - Receiving, Handling/Moving and Unpacking

Upon receipt of the equipment, do the following:

- All JKSSS+ Series units are shipped in the vertical (upright) position and should be handled accordingly when received. If the controller is not upright upon receipt, notify the carrier of possible damage. Upright the units as soon as possible and immediately notify the nearest Toshiba representative.
- Carefully unpack the unit and make an immediate inspection for any damage which might have occurred during shipment. If damage is found, it should be noted with the carrier prior to accepting the shipment, if possible. Report any damage immediately and file a claim with the freight carrier within 15 days of receipt.
- Carefully unpack the equipment sufficiently to check for concealed damage and to verify that the starter description on your unit matches your purchase order. The starter information is located on stickers in the medium voltage, incoming compartment.
- Keep the equipment upright. It is located on stickers in the medium voltage, incoming compartment.



**Do not install or energize equipment that has been damaged.**



**Do not lay the equipment on its side or upside down.**

### Handling and Moving

Medium voltage motor controllers should be handled with care, to avoid damage to components and to the frame or its finish.

The capability of the moving equipment to handle the weight of the controller shipping section should be confirmed. The equipment should remain secured to the shipping skid to prevent distortion of the frame during moving and to minimize tipping. Extreme care should be exercised during any movement and placement operations to prevent dropping or tipping.



**Do not place any part of your body beneath equipment being lifted.  
Improperly secured equipment can fall or tip over quickly and without notice.**

### Using a Forklift

A forklift truck may offer a more convenient method of handling the controller. A safety strap should be used when handling with a forklift. The ends of the forks should not enter the bottom of an open-bottom enclosure.

### Overhead Lifting

When it is necessary to move the equipment between elevations, overhead hoisting may be required. Lifting angles (for multiple controller sections) are provided on top of the enclosure for this purpose. Spreaders (Fig. 2.2.1) should be used to provide the vertical lift on single controllers to prevent eye-bolt failure.

Always keep the controller upright while lifting. Some controller sections may contain heavy or special equipment that will cause the center of gravity to be off-center. Rigging lengths should be adjusted to maintain the controller in an upright position. The angle between the lifting cables and vertical should not be allowed to exceed 45 degrees (Fig. 2.2.2). Ropes or cables should not pass through the holes in lifting angles or eye-bolts. Slings with safety hooks or shackles of adequate load rating should be used.




Fig. 2.2.1 Use of Spreader Bar – Single Section

### 2.3 - Initial Inspection

- Make a complete visual check of the unit for damage which may have occurred during shipping and handling. Do not attempt to continue installation or start up the unit if it is damaged.
- Check for loose mechanical assemblies or broken wires which may have occurred during transportation or handling. Loose electrical connections will increase resistance and cause the unit to function improperly.
- Prior to beginning the installation, verify that the motor and JKSSS unit are rated for the proper amperage and voltage.

### 2.4 - Location

#### Storage

If the controller is to be stored for any length of time prior to installation, the packing should be restored for protection during that period. Where conditions permit, the packing should be left intact until the controller is at the final installation position. If the packing is removed, the top and openings of the controller should be covered during the construction period to protect it against dust and debris.




Fig. 2.2.2 Lifting Multiple Sections

### Indoor Equipment

Controllers designed for indoor installation (Type 1, 12) and are not to be installed and energized immediately, should be stored in a clean, dry space where a uniform temperature prevents condensation. Preferably, the controller should be stored in a heated building, with adequate air circulation and protected from dirt and water. Equipment should be stored where it is not subject to mechanical damage, especially during building construction. An indoor controller that is to be stored outdoors should be securely covered for protection from weather conditions and dirt. Temporary electrical heating should be installed to prevent condensation. Approximately 150 watts per enclosure is usually adequate.

**NOTE:** All loose packing or flammable materials should be removed before energizing space heaters.

### Outdoor Equipment

An un-energized controller designed for outdoor installation (Type 3R, EPIC building, etc.) should be kept dry internally by installing electrical heating or by energizing self-heaters, if provided. All openings, either used or unused, should be covered or sealed to prevent the entry of rain, vermin, insects, etc.

### Routine Inspection

Routine scheduled inspection should be established if storage for an extended period is anticipated. This is to check for condensation, corrosion, vermin, and adequacy of space heating. Prior to inspection, the equipment should be carefully examined for evidence of physical damage, corrosion, or other deterioration.



**WARNING**

**Do not install equipment found to have damage or deterioration that could affect the unit performance.**

Overhead should be checked for plumbing condensation, sprinklers or similar possible sources of trouble. A clearance of 1/2 inch should be provided between a wall and the rear of the controller for indoor equipment, when rear access is not required. If rear access is required in either environment, a minimum of 30 inches should be provided. A minimum of 48 inches working space should be allowed in front of the controller. This minimum should be increased, if necessary, to accommodate movement around open enclosure doors to comply with applicable codes.

### SERVICE CONDITIONS

Toshiba medium voltage controllers are intended for usual service conditions as defined by NEMA. The equipment should not be exposed to corrosive or explosive fumes, dusts, vapors, dripping or standing water, abnormal vibration, shock, tilting, or other abnormal operation conditions. The temperature of the ambient air surrounding the controller should be between the limits of 0°C (32°F) and +40°C (104°F). The altitude of the equipment installed should not exceed 3300 ft. (1000m).

**NOTE:** Temperature or altitude conditions outside of the usual limits may require derating or other special equipment, such as heating, cooling or ventilation. Contact Toshiba for further information.

If the location for installation is damp, space heaters may be required. If space heaters are furnished inside the controller, they should be connected in accordance with the wiring diagram furnished.



**WARNING**

**Do not install this equipment in areas where unusual service conditions exist, unless the equipment has been specially designed for the particular environment.**

### Installation Site Preparation

It is recommended that site preparation be completed before the controller is unpacked, so that possible problems such as headroom, conduit location, cable tray locations, ventilation, etc. can be solved, assuring a proper installation in compliance with the building plans and codes. The floor on which the controller will be placed must be level so that the enclosure is not distorted when bolted in place. Ensure the equipment adequately clears any underground raceways or cables.

## 2.5 - Mounting

Each shipping section must be leveled and firmly secured to its supporting foundation. Steel shims may be used for final leveling (Fig. 2.5.1), if necessary. When three or more shipping sections are to be arranged in one continuous line-up, the center shipping section should normally be the first located.

Follow the equipment outline drawings to determine the location of the mounting bolt holes and any conduit locations.

Sill channels may or may not be furnished, depending on order specifications. Refer to outline drawings furnished for location of sill channels, if furnished.

Various methods may be used to anchor the enclosure to the foundation, including expandable inserts or "J" bolts embedded in concrete. The recommended size for anchor bolts is 1/2" (Fig. 2.5.2).




Fig. 2.5.1 Leveling Using Shims



**For heavy equipment, enclosure must be securely anchored to prevent tipping over.**

## 2.6 - Additional Cabinet Entries

If conduit entry locations are required in areas other than the removable plates, cover the electrical assemblies to prevent metal filings from becoming lodged in areas which may cause a reduction in the high voltage clearances or a short circuit. After the work is completed, thoroughly clean the area and inspect the unit for foreign material.

## 2.7 - Pre-energization Check

AFTER INSTALLATION, BUT BEFORE ENERGIZING THE CONTROLLER for the first time, follow the procedure below to verify that the equipment is properly installed and functional.

There is a rating data label on the inside of each medium voltage compartment door. Verify that the controller ratings properly match the system data by checking the following:

1. Verify agreement of full load current, locked rotor current and acceleration time with motor nameplate.
2. Verify that system voltage, number of phases and frequency matches controller rating.
3. Verify that available short circuit current of power system is less than rated short circuit capacity of controller.

Check connections - Although the equipment and devices have been completely tested at the factory, a final field check should be made that all electrical wiring and bus bar connections are correct and have not become loose in transportation. Refer to MAINTENANCE Section for electrical joint specification.

All blocks or other temporary braces used for shipment must be removed.




Fig. 2.5.2 Securely Anchor the Controller

Before closing the enclosure, all metal chips, scrap wire and other debris left over from installation must be cleaned out. If there is an appreciable accumulation of dust or dirt, the enclosure should be cleaned by using a brush, vacuum cleaner or clean, lint free brush.

The integrity of all bus bar supports must be checked to confirm they are secured and without damage.

Care should be exercised that when covers are installed and doors closed, no wires are pinched and that all enclosure parts are properly aligned and tightened.

A supply of spare parts, fuses, etc. should be established.

Instruction manuals and diagrams should be collected and filed.

### **WIRING CHECK**

Field wiring should be checked for clearance to live busses where necessary, physically secured to withstand the effects of fault current. All grounding connections should be checked.

Each motor should be connected to its intended controller, and phase rotation should be correct prior to startup.

Changes made to circuit diagrams during installation should be recorded.

### **DEVICE/MECHANISM CHECKS**

All devices should be checked for damage. All necessary repairs or replacements should be made.



**Do not energize damaged equipment that has not been repaired and verified.**

Ensure that safety signs are not covered or obscured by paint.



**Do not remove, cover or destroy any safety signs.**

The setting of any adjustable current and voltage trip mechanisms should be verified to the proper values.

**NOTE:** Damage from faults can be reduced if devices used for short circuit and ground fault protection are chosen and set to operate at values as close to minimum as feasible, while allowing normal transients.

All switches, relays and other operating mechanisms should be manually exercised to make certain that they are properly aligned and operate freely.

Operating mechanisms such as interlocks, key switches, etc. should be checked for function as intended for protection of personnel and equipment.

Overload relay settings should be checked to be sure they are selected and adjusted to the proper settings per the load nameplate data.

Power circuit fuses were selected and installed in accordance with the application requirements. Fuses must be completely inserted in their holders. Instruction on removing and installing the fuses can be found in one of the following manuals: VF010H03 (Fixed Type) or VF010H01 (Drawout Type).

**Electrical Checks**

With incoming power isolated and all loads disconnected electrically, the control circuit and other mechanisms should be exercised to determine that the devices operate properly. An auxiliary source of control power will be necessary to provide power to the electrical operators.



**Electrical shock hazard. Do not touch energized components during a test using auxiliary power.**

The ground fault protection system (if furnished) should be tested in accordance with the instructions furnished with the device.

An electrical insulation test should be performed to ensure that the controller and associated field wiring are free from short circuits and grounds. The preferred method is to perform a dielectric test at 2.25 times the nominal system voltage plus 2000 volts. This should be done phase-to-ground, phase-to-phase and phase-to-neutral (if applicable), with all switches and circuit breakers opened. Disconnect any devices which may have limited dielectric strength and that are not intended for this test.

The light or buzzer, or both, used to indicate breakdown should be calibrated to indicate failure with an output current between 1.5 and 2.0 milliamperes per 1000 volts applied.



**Hazardous voltages are present during dielectric testing that can result in serious injury or death. High potential test should be performed only by qualified personnel. Refer to safety instructions provided with the test equipment.**

All devices must be set to their normal or OFF position before energizing incoming power.

**2.8 - Medium Voltage Power Connections**

Use a properly calibrated torque wrench to tighten all MV connections according to the chart.

**Connections**

Cable and wire bundles that enter the controller enclosure should be routed to avoid interference with moving parts. Minimum bending radius for the type of cable used should be observed.


Power cables should be braced and/or laced to withstand short circuit forces wherever such cables are unsupported. Power cables should be adequately sized to carry the motor full load current in accordance with NEC requirements, and have an adequate voltage rating. Cables should be dressed and terminated as appropriate to the voltage class and cable manufacturer’s recommendations.

Bolt Size	Torque at Full Engagement (ft - lbs)
1/4 - 20	6
3/16 - 18	12
3/8 - 16	18
7/16 - 14	30
1/2 - 13	45
9/16 - 12	68
5/8 - 11	90
3/4 - 10	150
7/8 - 9	240
1.0 - 8	245

*Torque Specs for MV Power Connections*


Main power bus (when provided) and horizontal ground bus are supplied with links to join shipping sections together. These should be installed in accordance with Fig. 2.8.1 through Fig. 2.8.3.

All access covers, barriers, partitions, etc. that are temporarily removed during installation must be replaced.



**Fig. 2.8.1 Main Bus Splice Connections - 1200A Main Bus**

**NOTE:** Covers and braces supplied only for protection during shipment should not be replaced. All debris and tools should be removed from each compartment as cabling is completed.



**Fig. 2.8.2 Main Bus Splice Connections - 2000A Main Bus**

### **Incoming Line**

On the standard JKSSS, incoming power cable connections should be made at the points shown on the wiring diagram furnished with the equipment.

**Note:** Proper phase sequence must be observed when connecting the input power. For example, phase A must lead phase B, which in turn must lead phase C by 120° respectively. If the phase rotation is not correct, a fault light and the OLED display will indicate the problem. The SCR output will be clamped.

### **Load Connections**

The load cables should be routed through the wireways furnished within the enclosure. For load cable termination arrangements, refer to the drawings furnished with the equipment.

### **Ground Connections**

The controller line-up must be grounded in accordance with the requirements of the National Electrical Code. Proper equipment grounding must be established before making any incoming power connection. If a main ground bus is furnished, make the ground connection to this bus. If there is no ground bus, the sections which are shipped separately should be connected in such a way as to ensure a continuous grounding path.

Each section contains a vertical ground bus extending from the main ground bus or ground pad to each controller compartment.

Special attention should be paid to protection for operating personnel, to protection of equipment itself, (e.g. such as ground fault relays) and protection of sensitive transducers or control devices that are electronic in nature.

The following may be used as a general guide with regard to equipment grounding.

#### Controller used as service equipment for a grounded system or as a main section for a separately derived system:

- a. The grounding electrode conductor (ground wire) sized in accordance with NEC 250 should be run from the grounding electrode to the controller ground bus or ground terminal.
- b. Unless already done at the factory, a main bonding jumper should be installed from the incoming grounded connector bus (neutral) to the ground bus or designated grounding point. If a jumper is not furnished, one having a size in accordance with NEC 250 should be selected.
- c. Steps (a) and (b) should effectively connect together the grounding electrode, the controller frame, all outgoing equipment grounding conductors and the grounded neutral bus of the system.
- d. No connection should be made to ground on the load side of any neutral disconnecting line or any sensor used for ground fault protection. No connections should be made between outgoing grounding connectors and the neutral.
- e. Where the controller or system is dual-fed (double-ended) and has ground fault protection, special precautions are necessary to accomplish proper grounding and bonding.

#### Controller used as service equipment for an ungrounded system or as a main section for a separately derived system:


- a. A grounding electrode conductor (ground wire) sized in accordance with NEC 250 should be run from the grounding electrode to the controller ground bus or ground terminal.

- b. If the system is grounded at any point ahead of the controller, the grounded conductor should be run to the controller in accordance with NEC 250 and connected to the ground bus or ground terminal.
- c. Steps (a) and (b) should effectively connect together the grounding electrode, the controller frame, all outgoing equipment grounding connectors and any grounded conductor which runs to the controller.

Controller not used as service equipment or as a main section for a separately derived system, and used on either a grounded or ungrounded system:

- a. The controller frame and any ground bus should be grounded by means of equipment grounding conductors having a size in accordance with NEC 250 and run with the main supply conductors or by bonding to the raceway enclosing the main supply conductors in accordance with NEC 250.
- b. Ground leads should be connected to cable potheads/shields as specified by the manufacturer of these devices.

**Fig. 2.8.3 Ground Bus Splice**



## 2.9 Control Connections - TCB (Terminal and Control Board)

### 2.9.1 TCB Board

The TCB board, FIG. 2.9.1 shown below, provides interconnections between the main power and CPU boards and the customer's control logic connections. It is a 120 VAC control board with several auxiliary dry control contacts, built-in time delay circuits and emergency bypass functions. It also controls the sequence of the inline isolation and bypass contactor and provides provisions for shutdown interlocks (see **Section 2.9.2** for terminal designations and descriptions).




FIG. 2.9.1 TCB Terminal and Control Board

2.9.2 Description of Terminal Connections

TB1 Start / Stop Control		
T	Description	
1	AC	120Vac Control Power (Line)
2 3	NC C	Shutdown Input - Accepts customer N.C dry contact (factory jumper installed)
4 5	NC C	Shutdown Input - Accepts customer N.C dry contact (factory jumper installed)
6 7 8	NC C NO	For terminals 6, 7 & 8: 2-wire control is connected to terminals 6 & 8. For 3 wire control, connect the N.C. STOP button to pins 6 & 7, and the N.O. START button to terminals 7 & 8.
9	AC	120Vac Control Power (Neutral)
10 11 12	C NO NC	Common Normally Open Normally Closed, Form C Relay that changes state on Start and Stop commands


TB2 Emergency Bypass Control		
T	Description	
1 2	NO C	When the N.O. contact closes the unit reverts to an electromechanical starter. When a start command is given the unit will start the motor across the line.
3 4 5	C NO NC	Terminals 3, 4 and 5 are Form C output relay contacts that changes state when the contact at TB2 terminals 1 & 2 are closed.
6 7	NO NC	120Vac @ 200VA Aux Control Power output.
8	-	Not Used.
9 10	N NC	Normally Closed Emergency Stop Dry Contact Input. Open to activate the Emergency Stop Feature.

TB3 Fault Relay Outputs		
T	Description	
1 2 3	C NO NC	(2) Form C relay output that transfer on blown fuse or disconnect open indication.
4 5 6	C NO NC	(2) Form C relay output that transfer on blown fuse or disconnect open indication.
7 8 9	C NO NC	(2) Form C relay output that transfer on <b>any</b> fault indication.
10 11 12	C NO NC	(2) Form C relay output that transfer on <b>any</b> fault indication.

2.9.2. Description of Terminal Connections - Continued

TB4 Optional Relay Outputs		
T	Description	
1 2 3	C NO NC	Two Form C time delay Aux relay output contacts. Time delay starts when the Start command is given.
4 5 6	C NO NC	
7 8 9	C NO NC	Two Form C time delay Aux relay output contacts. Time delay starts when the "At Speed" condition is reached, ideal for controlling a PFC contactor.
10 11 12	C NO NC	

TB5 TCB Power		
T	Description	
1	L	By connecting TB5 of multiple units in parallel, PFC contactors will be inhibited from closing while a unit is soft starting. PFCs that are already on line will remain on line. The lead unit in the parallel string requires TB5 terminals 1 & 3 to be connected to the 120Vac source and neutral respectively.
2	PFC	
3	N	



Example: PFC Automatic inhibit control

2.9.2 Description of Terminal Connections - Continued

TB6 Main and CPU Circuit Board Control Inputs		
T	Description	
1 2	L N	120Vac output to Control Power Input (Main & CPU Circuit)
3 4	- -	Start Input
5 6	- -	Fuse Blown Input
7 8	- -	Dual Ramp Input
9 10	- -	Bypass Status Input (not used)


TB7 Main and CPU Circuit Board Control Outputs		
T	Description	
1 2	Run contacts (AUX3) to the TCB board ( <i>signal is used to hold the main contactor closed during deceleration</i> ).	
3 4	To the TCB board indicating the status of AUX 1.	
5 6	At Speed Contacts (AUX 4) used to signal the bypass contactor to close.	
7	Not Connected / Not Used.	

TB8 Control Inputs and Outputs		
T	Description	
1 2	N.C. dry contact input from external protection relay (required if emergency bypass is used).	
3 4	N.C. dry contact input from an external overload protection device, if decel is required ( <i>factory jumper installed</i> ).	
5 6	N.C. dry contact input from the bypass contactor for at speed indication.	
7 8	Output connected to the bypass contactor and energizes / de-energizes the contactor ( <i>factory wired</i> ).	
9 10	Output connected to the inline isolation contactor and energizes / de-energizes the contactor ( <i>factory wired</i> ).	

2.9.3 Description of Jumper Selections and Functions

Jumper Selection			
Jumper		Time Delay	Function
DLY-C	X1	Seconds /Cycles	<b>Start Delay</b> Jumper selects between seconds or cycles (1/60 <sup>th</sup> of a second) for the Start delay when a Start command is received and when the CPU actually receives the start signal. Default jumper setting is seconds.
AUX-C	X3	Seconds /Cycles	<b>Auxiliary Start Delay</b> Jumper selects between seconds or cycles (1/60 <sup>th</sup> of a second) for the auxiliary start delay when a Start command is received and when the CPU actually receives the star signal. Default jumper setting is seconds.
PFC-C	X5	Seconds /Cycles	<b>PFC Contactor Delay</b> Jumper selects between seconds or cycles (1/60 <sup>th</sup> of a second) for the delay when the Bypass Contactor closes to when the Power Factor Capacitor is activated. Default jumper setting is seconds.
JP1	N/A		<b>Motor Protection Jumper</b> When this jumper is in place, the CPU will be disabled during operation in the Emergency Bypass Mode. <b><i>In this case, insure that there is an external means of overload protection.</i></b> When the jumper is removed, the CPU will be enabled to provide electronic motor protection when operating in the Emergency Bypass Mode.

2.9.4 Description of Switch Settings and Functions

DIP Switches		
Switch	Function	
SW1	ON: Sets Dual Adjustment OFF: Disabled	
SW2	Not Used	
SW3	Sets the Start Delay Value	<p>SW3, SW4 and SW5 are 7 position DIP Switches that use binary coding to set the value of the time delay in Cycles or Seconds as selected via jumpers X1 to X6 (see Jumper Table). The setting range is 0 to 127 (1+2+4+8+16+32+64). The example shown results in a value of 7 (1+2+4)</p> 
SW4	Sets the AUX Start Delay Value	
SW5	Sets the PFC Contactor Delay Value	

2.9.5 Description of LED Indicators Functions

LED Indicators			
Function	Location	Color	Function
Fuse Blown/ Disconnect	D4	Red	ON: When a Fuse is blown and / or a Disconnect is open.
Fault	D16	Red	ON: When any Fault has occurred.
Start	D7	Yellow	ON: When a Start signal has been initiated.
PFC Timed Out	D17	Yellow	ON: When the Power Factor Correction Capacitors Contactor is energized.
Delay Timed Out	D15	Yellow	ON: When the Auxiliary Start Contacts have been energized.
+24V	D28	Green	ON: +24V supply is good.

2.10 CB Layout Section - THIS SECTION IS FOR REFERENCE ONLY. NO FIELD WIRING OR CONNECTIONS ARE REQUIRED.

2.10.1 RTD Board





FIG. 2.10.1 RTD Board

**2.10.2 RS485 / RS422 Communications Board**

**Note:** This Board is mounted on the back of the Keypad Interface



**FIG. 2.10.2 RS485 / RS422 Communications Board**

2.10.3 Main Board




FIG. 2.10.3 Power Board

2.10.4 CPU Board




FIG. 2.10.4 CPU Board

2.11 Typical Wiring Diagram




FIG. 2.11 Typical Wiring Diagram

## Chapter 3 - Start-up

### 3.1 Introduction

It is best to operate the motor at its full load starting condition to achieve the proper time, torque and ramp settings. Initial settings are set to accommodate most motor conditions. **TRY INITIAL SETTINGS FIRST.** See Section 5.1.2 Starter Configuration (Setpoint Page 2) to make any adjustments.

### 3.2 Acceleration Adjustments

The unit is set at the factory with typical starting characteristics that perform well in most applications. When the system is ready to start, try the initial unit settings. If the motor does not come up to speed, increase the current limit setting. If the motor does not start to turn as soon as desired, raise the starting voltage adjustment. Adjustment description and procedures are described as follows. See Section 5.1.2 Starter Configuration (Setpoint Page 2) for additional Accel settings.

#### 3.2.1 Initial Voltage

**Factory Setting = 20% of line voltage**

**Range = 0% - 100% of line voltage**

Initial voltage adjustment changes the initial starting voltage level to the motor.

#### 3.2.2 Ramp Time

**Factory Setting = 10 sec.**

**Range = 0 - 120 sec.**

Ramp time adjustment changes the amount of time it takes to reach the current limit point or full voltage if the current limit point was not reached.

*Note: Refer to your motor manual for the maximum number of starts per hour allowed by the manufacturer and do not exceed the recommended number.*

#### 3.2.3 Current Limit (FIG. 3.2.3 below)

**Factory Setting = 350% of motor FLA**

**Range = 200% - 500% of motor FLA**

The main function of current limit is to limit the maximum current. It may also be used to extend the ramp time if required. The interaction between the voltage ramp and the current limit will allow the soft start to ramp the motor until the maximum current is reached and the current limit will hold the current at that level. The current limit must be set high enough to allow the motor to reach full speed. The factory setting of 350% is a good starting point.

**Do not set the current limit too low on variable starting loads. This could cause the motor to stall and eventually cause the overload protection to trip.**

*Note: If the motor does stall, refer to the motor manufacturer's motor data for the proper cooling time.*




FIG. 3.2.3 Current Limit


### 3.3 Deceleration Adjustments (Pump Control)

Decel control extends the stopping time on loads that would otherwise stop too quickly if allowed to coast to stop. Decel control provides smooth deceleration until the load comes to a stop. Three adjustments optimize the deceleration curve to meet the most demanding requirements. **The unit is shipped from the factory with the Decel control feature disabled.**

#### 3.3.1 Deceleration Applications

Apply power and adjust the soft start before enabling or modifying the deceleration adjustments. Both, acceleration and deceleration adjustments should be made under normal load conditions. The deceleration feature provides a slow decrease in the output voltage, accomplishing a gentle decrease in motor torque during the stopping mode. This is the **OPPOSITE OF BRAKING** in that, it will take **longer** to come to a stop than if the starter were just turned off. The primary use of this function is to reduce the sudden changes in pressure that are associated with “Water Hammer” and slamming of check valves with centrifugal pumps. Decel control in pump applications is often referred to as **Pump Control**. In a pump system, liquid is being pushed uphill. The force exerted by gravity on the column of liquid as it goes up hill is called the “Head Pressure” in the system. The pump is sized to provide enough Output Pressure to overcome the Head Pressure and move the fluid up the pipe. When the pump is turned off, the Output Pressure rapidly drops to zero and the Head Pressure takes over to send the fluid back down the hill. A “Check Valve” is normally used somewhere in the system to prevent this (if necessary) by only allowing the liquid to flow in one direction. The kinetic energy in that moving fluid is suddenly trapped when the check valve slams closed. Since fluids can’t compress, that energy is transformed into a “Shock Wave” that travels through the piping system looking for an outlet in which to dissipate. The sound of that shock wave is referred to as “Water Hammer” and the energy in that shock wave can be extremely damaging to pipes, fittings, flanges, seals and mounting systems.

By using the Soft Stop/Deceleration feature of the soft starter, the pump output torque is gradually and gently reduced, which slowly reduces the pressure in the pipe. When the Output Pressure is just slightly lower than the Head Pressure, the flow slowly reverses and closes the Check Valve. By this time there is very little energy left in the moving fluid and the Shock Wave is avoided. When the output voltage to the motor is low enough to no longer be needed, the soft starter will end the Decel cycle and turn itself off. (See **FIG. 3.3**)



**FIG. 3.3 Deceleration Control**

Another common application for decel control is on material handling conveyors as a means to prevent sudden stops that may cause products to fall over or to bump into one another. In overhead crane applications, soft stopping of the Bridge or Trolley can prevent loads from beginning to over swing on sudden stops.

### 3.3.2 Start Deceleration Voltage

**Factory Setting = 60% of line voltage**

**Range = 0% - 100% of line voltage**

The step down voltage adjustment eliminates the dead band in the deceleration mode that is experienced while the voltage drops to a level where the motor deceleration is responsive to decreased voltage. This feature allows for an instantaneous drop in voltage when deceleration is initiated.

### 3.3.2 Stop Deceleration Voltage

**Factory Setting = 30% of line voltage**

**Range = 0% - 100% of line voltage**

The stop voltage level setpoint is where the deceleration voltage drops to zero.

### 3.3.3 Deceleration Time

**Factory Setting = 5 sec.**

**Range = 0 - 60 sec.**

The deceleration ramp time adjusts the time it takes to reach the stop voltage level setpoint. The unit should be restarted and stopped to verify that the desired deceleration time has been achieved. When calculating the number of starts per hour, a decel curve should be counted as a start curve. For example, recommended number of starts per hour = 6, allowable starts with decel cycle per hour = 3.

**Note:** Do not exceed the motor manufacturer's recommended number of starts per hour.

## 3.4 Sequence of Normal Operation

It is best to operate the motor at its full load starting condition to achieve the proper time, torque and ramp settings. Initial settings are set to accommodate most motor conditions.

**TRY INITIAL SETTINGS FIRST FOR:**

- Initial Voltage
- Current Limit
- Ramp Time

See Section 5.1.2 Setpoint Page 2 to make any adjustments. If the Decel function is enabled, related parameters may also need adjusting to achieve optimal Decel performance

#### Sequence:

- Close the disconnect switch to apply 3 phase power" Verify the power LED on the keypad comes on.

**MOTOR STOPPED  
READY TO START**


- Activate the start command, the motor should start accelerating and the RUN LED will come ON.

**MOTOR STARTING  
00 x FLA**

**OVERLOAD ALARM  
TIME TO TRIP .XXX SECS**

**Check:** If the motor decelerates, or stops, during the acceleration period, **activate the Stop button immediately.** Adjustments to the ramp time and or current limit setting are necessary to provide the motor sufficient energy to reach full speed. If the unit does not follow this operational sequence, please refer to the Troubleshooting Chapter.

If the motor does not enter the run mode in the set time (Acceleration time limit, see SP8.2), a trip will occur. When the Motor Reaches full speed, the At Speed” LED will come on and Aux 4 (At Speed) relay will energize closing the bypass contactor. Phase A, B, C and Ground Fault current is then shown on the keypad during operation.




### 3.5 Emergency Bypass Operation

#### Emergency Bypass

- Remove input power by opening the disconnect switch and lock out.
- Close the emergency Bypass contact located on the TCB board at TB2 (See section 2.2.1 for location).
- Unlock and reclose the disconnect switch.

**Note:** In the emergency bypass mode, there is no overload protection unless a separate (optional or customer supplier) thermal overload relay is installed, or JP-1 (Motor Protection Jumper, Sec. 2.9.3) is removed from the TCB Board.

The unit is operable as a normal across-the-line starter. When power is applied, the bypass contactor is energized, tying the input terminals directly to the output terminals. When the "START" command is given, the main (in-line) contactor is energized and the motor starts. When the "STOP" command is given, the motor is disconnected from the line via the main (in-line) vacuum contactor.

	<b>DANGER</b>
<b>HAZARDOUS OPERATION</b> <b>Do not operate the Bypass Contactor with medium voltage power applied to the unit.</b> <b>Failure to follow this instruction will cause the motor to start unexpectedly.</b>	

## Chapter 4 - User Interface & Menu Navigation


This chapter explains the keypad operator interface, the OLED descriptions and the programming features.

### 4.1 Keypad/Operator Interface

The user keypad/ operator interface consists of:

- 2 row by 20 characters Organic Light-Emitting Diode (OLED)
- 12 LEDs
- 8 pushbuttons

**Note:** The soft starter is menu driven and there are three levels of programming. The programming for two of these levels is password protected. Level two requires a three digit password and level three requires a four digit password.




#### 4.1.1. Keypad Operator designations and functions

ITEM	DESIGNATION	DESCRIPTION
KEY	MENU	Toggle between the menu selection for metering and setpoint pages.
	RESET	Will clear the trip indicator and release the trip relay.
	ENTER	In edit mode, press the ENTER pushbutton so the unit will accept the new programming information. When not in the edit mode, the ENTER pushbutton will toggle through the event indicator list (such as alarms or trips).
	HELP	Provides general help information about a specific setpoint or action.
	UP ARROW	Will scroll up through the setpoint and metering menu page. It will scroll to the top of the setpoint page or a section. In edit mode, it will increase a setpoint in an incremental step or toggle through the available options in the setpoint.
	RIGHT ARROW	In the main menu the RIGHT ARROW button provides access to the setpoint page. For setpoint pages with multiple columns, the RIGHT ARROW will scroll the setpoint page to the right. In edit mode, it will shift one character to the right.
	DOWN ARROW	Will scroll down through the setpoint pages and down through the setpoints. In edit mode, it will decrement through values and toggle available options in the setpoint.
	LEFT ARROW	Will move to the left through setpoint pages with multiple columns. In edit mode, it will become the backspace key and will shift one character to the left.
LED	POWER	Indicates control power is present.
	RUN	Indicates unit/motor is running.
	ALARM	Lights in conjunction with AUX 2 to indicate event or warn of possible critical condition.
	TRIP	Lights in conjunction with AUX 1 to indicate a critical condition has occurred.
	AUX 1- 8	Auxiliary relays

**Note:** The directional arrow buttons require careful operation. In edit mode, if the buttons are held for a long period, the scrolling speed will increase.

### 4.2 Menu Navigation



#### 4.2.1 Password Access

Screens in Level 1 of the setpoint menu can be changed without password access because they list basic motor information. Screens in Levels 2 and 3 require passwords because they provide more in-depth protection and control of the unit. The password in Levels 2 and 3 can be changed by the user.

**Note: Setpoints can only be changed when the motor is in Stop/ Ready Mode! The soft starter will not allow a start if it is still in the Edit Mode. When the unit is in the Edit Mode, an asterisk is displayed in the top right corner screen.**

#### 4.2.2 Changing Setpoints


##### Example 1: Changing Motor FLA from 140 AMPS to 142 AMPS

- A. Press MENU button to display Setpoint Page 1, Basic Configuration.
- B. Press the RIGHT ARROW you will view the screen Motor Full Load Amps.
- C. Press the ENTER button for edit mode. **Note the asterisk (\*) in the top right corner of the**

OLED

**screen that indicates Edit Mode.**

- D. To change the value, select the UP ARROW or DOWN ARROW. In this case push the UP ARROW twice (2x).
- E. To accept the new value, press the ENTER button. The unit will accept the changes and will leave the edit mode. Note the \* is no longer in the top right corner of the OLED Display.



## Chapter 5 - Setpoint Programming

The soft starter has thirteen programmable setpoint pages which define the motor data, ramp curves, protection, I/O configuration and communications. In Section 5.1, the setpoint pages are outlined in chart form. In Section 5.2 the setpoint pages are illustrated and defined for easy navigation and programming. **Note:** *setpoints can only be changed when the starter is in the Ready Mode. The soft start will not start when it is in programming mode.*

### 5.1 Setpoints Page List

These charts list the Setpoint Page, the programmable functions and the section.

#### 5.1.1 Basic Configuration (Setpoint Page 1)

Setpoint Page	Security Level	Description	Factory Setting Default	Range	Section
Page 1 Basic Configuration	Level 1 No Password Required	Motor Full Load Amps (FLA)	Model dependent	50 - 100% of Unit Max Current Rating (Model and Service Factor dependent)	SP1.1
		Service Factor	1.15	1.00 – 1.3	SP1.2
		Overload Class	10	O/L Class 5-30	SP1.3
		NEMA Design	B	A-F	SP1.4
		Insulation Class	B	A, B, C, E, F, H, K, N, S	SP1.5
		Line Voltage	Model dependent	1000 to 7200V	SP1.6
		Line Frequency	60	50 or 60 HZ	SP1.7

#### 5.1.2 Starter Configuration (Setpoint Page 2)

Setpoint Page	Security Level	Description	Factory Setting Default	Range	Section
Page 21 Starter Configuration	Level 1 No Password Required	Start Control Mode	Start Ramp 1	Jog, Start Ramp 1, Start Ramp 2, Custom Accel Curve, Start Disabled, Dual Ramp, Tach Ramp	SP2.1
		Jog Voltage	50%	5-75%, Off	SP2.2
		Start Ramp #1 Type	Voltage	Voltage, Current	SP2.3
		Initial Voltage #1	20%	0-100%	
		Ramp Time #1	10 sec	1-120 sec	
		Current Limit #1	350% FLA	200-500 %	
		Initial Current #1	200% FLA	0-300 %	
		Ramp Time #1	10 sec	1-120 sec	
		Maximum Current #1	350% FLA	200-500 %	SP2.4
		Start Ramp #2 Type	Disabled	Disabled, Voltage, Power	
		Initial Voltage #2	60%	0-100 %	
		Ramp Time #2	10 sec	1-120 sec	
		Current Limit #2	350% FLA	200-500 %	
		Initial Power #2	20%	0-100 %	
		Ramp Time #2	10 sec	1-120 sec	SP2.5
		Maximum Power #2	80%	0 – 300 %	
		Kick Start Type	Disabled	Voltage or Disabled	
		Kick Start Voltage	65%	10-100 %	
		Kick Start Time	0.50 sec	0.10-2.00	SP2.6
		Deceleration	Disabled	Enabled or Disabled	
Start Deceleration Voltage	60%	0-100 %			
Stop Deceleration Voltage	30%	0-59 %			
Deceleration Time	5 sec	1-60 sec			
Timed Output Time	Off	1-1000 sec, Off			
Run Delay Time	1 Sec	1-30 sec, Off	SP2.8		
At-Speed Delay Time	1 Sec	1-30 sec, Off	SP2.9		
Bypass Pull-in Current	100% FLA	90 – 300%	SP2.10		

5.1.3 Phase and Ground Settings (Setpoint Page 3)

Setpoint Page	Security Level	Description	Factory Setting Default	Range	Section
Page 3 Phase and Ground Settings	Level 2 Password Protected	Imbalance Alarm Level	15% FLA	5-30 %, Off	SP3.1
		Imbalance Alarm Delay	1.5 sec	1.0-20.0 sec	
		Imbalance Trip Level	20%	5-30 %, Off	SP3.2
		Imbalance Trip Delay	2.0 sec	1.0-20.0 sec	
		Undercurrent Alarm Level	Off	10-90 %, Off	SP3.3
		Undercurrent Alarm Delay	2.0 sec	1.0-60.0 sec	
		Overcurrent Alarm Level	Off	100-300 %, Off	SP3.4
		Overcurrent Alarm Delay	2.0 sec	1.0-20.0 sec	
		Overcurrent Trip Level	Off	100-300 %, Off	SP3.5
		Overcurrent Trip Delay	2.0 sec	1.0-20.0 sec	
		Phase Loss Trip	Enabled	Enabled or Disabled	SP3.6
		Phase Loss Trip Delay	0.1 sec	0-20.0 sec	
		Phase Rotation Detection	ABC	ABC, ACB or Disabled	SP3.7
		Phase Rotation Trip Delay	1.0 sec	1.0 - 20.0 sec	
		*Ground Fault Alarm Level	Off	5-90 %, Off	SP3.8
		*Ground Fault Alarm Delay	0.1 sec	0.1-20.0 sec	
		*Ground Fault Loset Trip Level	Off	5-90 %, Off	SP3.9
		*Ground Fault Loset Trip Delay	0.5 sec	0.1-20 sec	
		*Ground Fault Hiset Trip Level	Off	5-90 %, Off	SP3.10
		*Ground Fault Hiset Trip Delay	0.008 sec	0.008-0.250 sec	
		Overvoltage Alarm Level	Off	5 -30%, Off	SP3.11
		Overvoltage Alarm Delay	1.0 sec	1.0-30.0 sec	
		Overvoltage Trip Level	10%	5-30%, Off	SP3.12
		Overvoltage Trip Delay	2.0 sec	1.0-30.0 sec	
		Undervoltage Alarm Level	Off	5-30%, Off	SP3.13
		Undervoltage Alarm Delay	1.0 sec	1.0-30.0 sec	
		Undervoltage Trip Level	15%	5-30%, Off	SP3.14
		Undervoltage Trip Delay	2.0 sec	1.0-30.0 sec	
		Line Frequency Trip Window	Disabled	0-6 Hz, Disabled	SP3.15
		Line Frequency Trip Delay	1.0 sec	1.0-20.0 sec	
		P/F Lead P/F Alarm	Off	0.1-1.00, Off	SP3.16
		P/F Lead Alarm Delay	1.0 sec	1-120 sec	
		P/F Lead P/F Trip	Off	.01-1.00, Off	SP3.17
P/F Lead Trip Delay	1.0 sec	1-120 sec			
P/F Lag P/F Alarm	Off	.01-1.00, Off	SP3.18		
P/F Lag Alarm Delay	1.0 sec	1-120 sec			
P/F Lag P/F Trip	Off	.01-1.00, Off	SP3.19		
P/F Lag Trip Delay	1.0 sec	1-120 sec			
Power Demand Period	10 min	1 - 60 min	SP3.20		
KW Demand Alarm Pickup	Off KW	Off, 1-100000			
KVA Demand Alarm Pickup	Off KVA	Off, 1-100000			
KVAR Demand Alarm Pickup	Off KVAR	Off, 1-100000			
Amps Demand Alarm Pickup	Off Amps	Off, 1-100000			

\* Ground fault option must be installed.

5.1.4 Relay Assignments (Setpoint Page 4)

Setpoint Page	Security Level	Description	Factory Setting			Range	Section
			1st	2nd	3rd		
Page 4 Relay Assignments	Level 2 Password Protected	O/L Trip	Trip Only	None	None	None Trip(AUX1) / Trip Only Alarm(AUX2) AUX3 AUX4 AUX5 - 8 Only Available in 8 Relay System  <b>Notes:</b> <b>AUX1 to AUX4 are for Factory use only Do not change!</b> <b>Only AUX 5 - 8 are used in the 2nd &amp; 3rd relay assignments.</b>	SP4.1
		I/B Trip	Trip	None	None		
		S/C Trip	Trip Only	None	None		
		Overcurrent Trip	Trip	None	None		
		Stator RTD Trip	None	None	None		
		Non Stator RTD Trip	None	None	None		
		*G/F Hi Set Trip	Trip	None	None		
		*G/F Lo Set Trip	Trip	None	None		
		Phase Loss Trip	Trip	None	None		
		Accel. Time Trip	Trip Only	None	None		
		Start Curve Trip	Trip Only	None	None		
		Over Frequency Trip	Trip	None	None		
		Under Frequency Trip	Trip	None	None		
		I*I*T Start Curve	Trip	None	None		
		Learned Start Curve	Trip	None	None		
		Phase Reversal	Trip	None	None		
		Overvoltage Trip	Trip	None	None		
		Undervoltage Trip	Trip	None	None		
		Power Factor Trip	None	None	None		
		Tach Accel Trip	None	None	None		
		Inhibits Trip	Alarm	None	None		
		Shunt Trip	Trip Only	None	None		
		Bypass Discrepancy	Trip Only	None	None		
		Low Control Voltage	Trip Only	None	None		
		TCB Fault /ESTOP	Trip	None	None		
		Two Speed	None	None	None		
		Dual Ramp	None	None	None		
		Thermostat	Trip	None	None		
		O/L Warning	Alarm	None	None		
		Overcurrent Alarm	Alarm	None	None		
		SCR Fail Shunt Alarm	None	None	None		
		*Ground Fault Alarm	Alarm	None	None		
		Under Current	None	None	None		
		Motor Running	AUX3	None	None		
		I/B Alarm	Alarm	None	None		
		Stator RTD Alarm	None	None	None		
		Non-Stator RTD Alarm	None	None	None		
		RTD Failure Alarm	None	None	None		
		Self Test Fail	Trip	None	None		
		Thermal Register	Alarm	None	None		
U/V Alarm	Alarm	None	None				
O/V Alarm	Alarm	None	None				
Power Factor Alarm	None	None	None				
KW Demand Alarm	None	None	None				
KVA Demand Alarm	None	None	None				
KVAR Demand Alarm	None	None	None				
Amps Demand Alarm	None	None	None				
Timed Output	None	None	None				
Run Delay Time	None	None	None				
At Speed	AUX4	None	None				

\* Ground fault option must be installed.

5.1.5 Relay Configuration (Setpoint Page 5)

Setpoint Page	Security Level	Description	Factory Setting Default	Range	Section
Page 5 Relay Configuration	Level 2 Password Protected	Trip (AUX1) Fail-Safe	No	Yes or No	SP5.1
		Trip (AUX1) Relay Latched	Yes		SP5.2
		Alarm (AUX2) Fail-Safe	No		SP5.1
		Alarm (AUX2) Relay Latched	No		SP5.2
		AUX3 Relay Fail-Safe	No		SP5.1
		AUX3 Relay Latched	No		SP5.2
		AUX4 Relay Fail-Safe	No		SP5.1
		AUX4 Relay Latched	No		SP5.2
		AUX5 Relay Fail-Safe	No		SP5.1
		AUX5 Relay Latched	No		SP5.2
		AUX6 Relay Fail-Safe	No		SP5.1
		AUX6 Relay Latched	No		SP5.2
		AUX7 Relay Fail-Safe	No		SP5.1
		AUX7 Relay Latched	No		SP5.2
AUX8 Relay Fail-Safe	No	SP5.1			
AUX8 Relay Latched	No	SP5.2			

5.1.6 User I/O Configuration (Setpoint Page 6)

Setpoint Page	Security Level	Description	Factory Setting Default	Range	Section
Page 6 User I/O Configuration	Level 2 Password Protected	Tachometer Scale Selection	Disabled	Enabled or Disabled	SP6.1
		Manual Tach Scale 4.0 mA:	0 RPM	0 - 3600	
		Manual Tach Scale 20.0 mA:	2000 RPM	0 - 3600	
		Tach Accel Trip Mode Select	Disabled	Underspeed, Overspeed or Disabled	SP6.2
		Tach Ramp Time	20 sec	1 - 120	
		Tach Underspeed Trip PT	1650 RPM	0 - 3600	
		Tach Overspeed Trip PT	1850 RPM	0 - 3600	
		Tach Accel Trip Delay	1 sec	1 - 60	
		Analog Output #1	RMS Current	Off, RPM 0-3600, Hottest Non-Stator RTD 0-200°C, Hottest Stator RTD 0 - 200°C, RMS Current 0 - 7500 A, % Motor Load 0 - 600% Kw	SP6.3
		Analog Output #1 4mA:	0	0-65535	
		Analog Output #1 20mA:	250	0-65535	
		Analog Output #2	% Motor Load	Same As Analog Input #1	SP6.4
		Analog Output #2 4mA:	0	0-65535	
		Analog Output #2 20mA:	1000	0-65535	
		User Programmable External Inputs			SP6.5
		TCB Fault	Enabled	User Defined, up to 15 Characters	
		Name Ext. Input #1	TCB Fault	Normally Open or Closed	
		TCB Fault Type	NO	0-60 sec	
		TCB Fault Time Delay	1 sec	Enabled or Disabled	
		External Input #2	Disabled	User Defined, up to 15 Characters	
		Name Ext. Input #2	NO	Normally Open or Closed	
		External Input #2 Type	0 sec	0-60 sec	
		External Input #2 Time Delay	Dual Ramp	Enabled or Disabled or Dual Ramp	
		Dual Ramp	Dual Ramp	User Defined, up to 15 Characters	
Name Ext. Input #3	NO	Normally Open or Closed			
Dual Ramp Type	0 sec	0-60 sec			
Dual Ramp Time Delay	Enabled	Enabled or Disabled			
Thermostat	Thermostat	User Defined, up to 15 Characters			
Name Ext. Input #4	NC	Normally Open or Closed			
Thermostat Type	1 sec	0-60 sec			

5.1.7 Custom Acceleration Curve (Setpoint Page 7)

Setpoint Page	Security Level	Description	Factory Setting Default	Range	Section
Page 7 Custom Acceleration Curve	Level 3 Password Protected	Custom Accel Curve	Disabled	Disabled, Curve A, B, or C	SP7.1
		Custom Curve A			
		Curve A Voltage Level 1	25%	0-100%	
		Curve A Ramp Time 1	2 sec	1-60 sec	
		Curve A Voltage Level 2	30%	0-100%	
		Curve A Ramp Time 2	2 sec	1-60 sec	
		Curve A Voltage Level 3	37%	0-100%	
		Curve A Ramp Time 3	2 sec	1-60 sec	
		Curve A Voltage Level 4	45%	0-100%	
		Curve A Ramp Time 4	2 sec	1-60 sec	
		Curve A Voltage Level 5	55%	0-100%	
		Curve A Ramp Time 5	2 sec	1-60 sec	
		Curve A Voltage Level 6	67%	0-100%	
		Curve A Ramp Time 6	2 sec	1-60 sec	
		Curve A Voltage Level 7	82%	0-100%	
		Curve A Ramp Time 7	2 sec	1-60 sec	
		Curve A Voltage Level 8	100%	0-100%	
		Curve A Ramp Time 8	2 sec	1-60 sec	
		Curve A Current Limit	350% FLA	200-500%	
Custom Curve B		Same Programmable Data Points and Ranges as Custom Curve A			
Custom Curve C		Same Programmable Data Points and Ranges as Custom Curve A			

5.1.8 Overload Curve Configuration (Setpoint Page 8)

Setpoint Page	Security Level	Description	Factory Setting Default	Range	Section
Page 8 Overload Curve Configuration	Level 3 Password Protected	Basic Run Overload Curve			SP8.1
		Run Curve Locked Rotor Time	O/L Class	1-30 sec, O/L Class	
		Run Locked Rotor Current	600% FLA	400-800%	
		Coast Down Timer	Disabled	1-60 Min, Disabled	
		Basic Start Overload Curve			SP8.2
		Start Curve Locked Rotor Time	O/L Class	1-30 sec, O/L Class	
		Start Locked Rotor Current	600% FLA	400-800%	
		Acceleration Time Limit	30 sec	1-300 sec, Disabled	
		Number of Starts Per Hour	Disabled	1-6, Disabled	
		Time Between Starts Time	5 min	1-60 Min, Disabled	SP8.3
		Area Under Curve Protection	Disabled	Enabled or Disabled	
		Max I**T Start	368 FLA	1-2500 FLA*FLA*sec	
		Current Over Curve	Disabled	Disabled, Learn, Enabled	SP8.4
		Learned Start Curve Bias	10%	5-40%	
		Time for Sampling	30 sec	1-300 sec	

5.1.9 RTD Configuration (Setpoint Page 9)

Setpoint Page	Security Level	Description	Factory Setting Default	Range	Section
Page 9 RTD Configuration	Level 3 Password Protected	Use NEMA Temp for RTD Values	Disabled	Enabled or Disabled	SP9.1
		# of RTD Used for Stator	4	0-6	SP9.2
		RTD Voting	Disabled	Enabled or Disabled	SP9.3
		Stator Phase A1 Type	Off	120 OHM NI, 100 OHM NI, 100 OHM PT, 10 OHM CU	SP9.4
		RTD #1 Description	Stator A1	User defined, Up to 15 Characters	
		Stator Phase A1 Alarm Level	Off	0-240C (32-464F), Off	
		Stator Phase A1 Trip Level	Off	0-240C (32-464F), Off	
		Stator Phase A2 Type	Off	Same as Stator Phase A1	
		RTD #2 Description	Stator A2	User defined, Up to 15 Characters	
		Stator Phase A2 Alarm	Off	0-240C (32-464F), Off	
		Stator Phase A2 Trip Level	Off	0-240C (32-464F), Off	
		Stator Phase B1 Type	Off	Same as Stator Phase A1	
		RTD #3 Description	Stator B1	User defined, Up to 15 Characters	
		Stator Phase B1 Alarm Level	Off	0-240C (32-464F), Off	
		Stator Phase B1 Trip Level	Off	0-240C (32-464F), Off	
		Stator Phase B2 Type	Off	Same as Stator Phase A1	
		RTD #4 Description	Stator B2	User defined, Up to 15 Characters	
		Stator Phase B2 Alarm Level	Off	0-240C (32-464F), Off	
		Stator Phase B2 Trip Level	Off	0-240C (32-464F), Off	
		Stator Phase C1 Type	Off	Same as Stator Phase A1	
		RTD #5 Description	Stator C1	User defined, Up to 15 Characters	
		Stator Phase C1 Alarm Level	Off	0-240C (32-464F), Off	
		Stator Phase C1 Trip Level	Off	0-240C (32-464F), Off	
		Stator Phase C2 Type	Off	Same as Stator Phase A1	
		RTD #6 Description	Stator C2	User defined, Up to 15 Characters	
		Stator Phase C2 Alarm Level	Off	0-240C (32-464F), Off	
		Stator Phase C2 Trip Level	Off	0-240C (32-464F), Off	
		End Bearing Type	Off	Same as Stator Phase A1	
		RTD #7 Description	End Bearing	User defined, Up to 15 Characters	
		End Bearing Alarm Level	Off	0-240C (32-464F), Off	
		End Bearing Trip Level	Off	0-240C (32-464F), Off	
		Shaft Bearing Type	Off	Same as Stator Phase A1	
		RTD #8 Description	Shaft Bearing	User defined, Up to 15 Characters	
		Shaft Bearing Alarm Level	Off	0-240C (32-464F), Off	
		Shaft Bearing Trip Level	Off	0-240C (32-464F), Off	
		RTD #9 Type	Off	Same as Stator Phase A1	
RTD #9 Description	User defined	User defined, Up to 15 Characters			
RTD #9 Alarm Level	Off	0-240C (32-464F), Off			
RTD #9 Trip Level	Off	0-240C (32-464F), Off			
RTD #10 Type	Off	Same as Stator Phase A1			
RTD #10 Description	User defined	User defined, Up to 15 Characters			
RTD #10 Alarm Level	Off	0-240C (32-464F), Off			
RTD #10 Trip Level	Off	0-240C (32-464F), Off			
RTD #11 Type	Off	Same as Stator Phase A1			
RTD #11 Description	User defined	User defined, Up to 15 Characters			
RTD #11 Alarm Level	Off	0-240C (32-464F), Off			
RTD #11 Trip Level	Off	0-240C (32-464F), Off			
RTD #12 Type	Off	Same as Stator Phase A1			
RTD #12 Description	User defined	User defined, Up to 15 Characters			
RTD #12 Alarm Level	Off	0-240C (32-464F), Off			
RTD #12 Trip Level	Off	0-240C (32-464F), Off			

5.1.10 RTD Password Level Configuration (Setpoint Page 10)

Setpoint Page	Security Level	Description	Factory Setting Default	Range	Section
Page 10 Password	Level 3 Password	Set Level 2 Password	100	000 – 999 Three Digits	SP10.1
		Set Level 3 Password	1000	0000 – 9999 Four Digits	SP10.2

5.1.11 RTD Communications Configuration (Setpoint Page 11)

Setpoint Page	Security Level	Description	Factory Setting Default	Range	Section
Page 11 Communications	Level 3 Password	Set Front Baud Rate	9.6 KB/sec	2.4, 4.8, 9.6, 19.2, 38.4 KB/sec	SP11.1
		Set Modbus Baud Rate	9.6 KB/sec	2.4, 4.8, 9.6, 19.2, 38.4 KB/sec	SP11.2
		Modbus Address Number	247	1 – 247	SP11.3
		Set Access Code	1	1 – 999	SP11.4
		Set Link Baud Rate	38.4 KB/sec	2.4, 4.8, 9.6, 19.2, 38.4 KB/sec	SP11.5
		Remote Start/Stop	Disabled	Enabled or Disabled	SP11.6

5.1.12 System (Setpoint Page 12)

Setpoint Page	Security Level	Description	Factory Setting Default	Range	Section
Page 12 System Setpoints	Level 3 Password Protected	Default Display Screen			SP12.1
		Metering Data Page #	1	Enter Metering Page (1-4)	
		Metering Data Screen #	1	Enter Metering Screen Page 1(1-10) Page 2 (1-11) Page 3 (1 - 29) Page 4 (1 - 6)	
		Alarms			SP12.2
		RTD Failure Alarm	Disabled	Enabled or Disabled	
		Thermal Register Alarm	90%	Off, 40-95%	
		Thermal Alarm Delay	10 sec	1-20 sec	
		Thermal Register Setup Info			SP12.3
		Cold Stall Time	O/L Class	O/L Class (5-30) or 4-40 second time delay	
		Hot Stall Time	½ O/L Class	½ O/L Class, 4-40 sec	
		Stopped Cool Down Time	30 Min	10-300 Min	
		Running Cool Down Time	15 Min	10-300 Min	
		Relay Measured Cool Rates	Disabled	Enabled or Disabled	
		Thermal Register Minimum	15%	10-50%	
		Motor Design Ambient Temp	40C	10-90C	
		Motor Design Run Temperature	80% Max	50-100% of Motor Stator Max Temp	
		Motor Stator Max Temp	INS CLS	INS CLS, 10-240 C	
		I/B Input to Thermal Register	Enabled	Enabled or Disabled	
		Use Calculated K or Assign	7	1-50, On	
		Press Enter to Clr Thermal Register			


5.1.13 Calibration and Service (Setpoint Page 13)

Setpoint Page	Security Level	Description	Factory Setting Default	Range	Section
Page 12 Calibration & Service	Factory Use Only	Set Date and Time (DDMMYY:HHMM)	FACTORY SET; ## / ## / ## : ##		SP13.1
		Enter Date (DDMMYYYY)	FACTORY SET; ## / ## / #####	D=1-31, M=1-12, Y=1970-2069	
		Enter Time (HH:MM)	FACTORY SET; ## : ##	H=00-23, M=0-59	
		Model # Firmware REV. #	FACTORY SET; #####	Display Only, Cannot be changed	SP13.2
		Press Enter to Access Factory Settings		Available to Qualified Factory Personnel	SP13.3

## 5.2 Setpoints Menu and Parameter Explanation (SP1 – SP13)

### SP.1 Basic Configuration (Setpoint Page 1)


In Setpoint Page 1, is used to setup basic nameplate data of the motor.



**SP1.1 Motor Full Load Amps (FLA):** Allows the user to enter the motor's FLA rating. Range of adjustment is 50 - 100% (less programmed service factor).

**SP1.2 Service Factor:** Sets the pickup point on the overload curve as defined by the programmed motor full load current. Ex: If the motor FLA is 100 and the service factor is 1.15, the overload pickup point will be 115 Amps.

**SP1.3 Overload Class:** Choose the motor protection overload class, range from 5-30. Ex: Overload Class 10 will trip in 10 seconds at six times Motor FLA.



**SP1.4 NEMA design:** The motor design maximum allowed slip (Select from Class A through F).


**SP1.5 Insulation Class:** The motor insulation temperature class (Select A, B, C, E, F, G, H, K, N or S).

**SP1.6 Line Voltage Input:** Applied Voltage.

**SP1.7 Line Frequency:** The user may choose either 50 Hz or 60 Hz.

SP.2 Starter Configuration (Setpoint Page 2)

This provides multiple choices for starting ramps that can be selected for particular loads and applications.



## SP2 Starter Configuration (Setpoint Page 2) Menu Navigation

**SP2.1 Start Control Mode:** Dual Ramp, Custom Accel Curve, Jog Voltage, Start Ramp 1, Start Ramp 2.

- **Dual Ramp:** The dual ramp mode works in conjunction with External Input #3. This allows the user to switch between the two start ramps without having to reconfigure the start mode (for details on configuring External Input #3 for DUAL RAMP, see Setpoint **Page 6**).
- **Custom Accel Curve:** Allows the user to custom design the acceleration start curve to the application (see setpoint **page 7** for configuration setup).


**Note:** If Custom Accel Curve has not been enabled in Setpoint page 7, the soft starter will ignore the start control mode and read this setpoint as disabled.

**SP2.2 Jog Voltage:** The voltage level necessary to cause the motor to slowly rotate.

**SP2.3 Start Ramp 1 Type:** The ramp type can be setup for either Voltage or Current. If Voltage is selected, initial voltage, ramp time and current limit are adjustable. If Current is selected, initial current, ramp time and maximum current are adjustable.

### Start Ramp 1 Type: Voltage

- **Voltage Ramping** is the most reliable starting method, because the starter will eventually reach an output voltage high enough to draw full current and develop full torque. This method is useful for applications where the load conditions change frequently and where different levels of torque are required. Typical applications include material handling conveyors, positive displacement pumps and drum mixers. Voltage is increased from a starting point, (Initial Torque) to full voltage over an adjustable period of time (Ramp Time). To achieve Voltage Ramping, select VOLTAGE for the START RAMP #1 TYPE setpoint and set CURRENT LIMIT #1 setpoint to 500% (the maximum setting). Since this is essentially Locked Rotor Current on most motors, there is little or no Current Limit effect on the Ramp profile.



**FIG. SP2.3 Example of Switching from Jog to Start Ramp #1 Type: Voltage**

- **Voltage Ramping with Current Limit** is the most used curve and is similar to voltage ramping; however, it adds an adjustable maximum current output. Voltage is increased gradually until the setting of the Maximum Current Limit setpoint is reached. The output is held at this level until the motor accelerates to full speed. This may be necessary in applications where the electrical power is limited. Typical applications include portable or emergency generator supplies, utility power near the end of a transmission line and utility starting power demand restrictions.

**Note:** Current Limit will override the Ramp Time setting if necessary, so use this when acceleration time is not critical.

To set Voltage Ramping with Current Limit, select VOLTAGE for the START RAMP #1 setpoint and set CURRENT LIMIT #1 setpoint to a desired lower setting, as determined by your application requirements.

### Start Ramp 1 Type: Current

- **Current Ramping** (Closed Loop Torque Ramping) is used for smooth linear acceleration of output torque. This ramp is only used on some conveyor systems (long haul or downhill). For other applications, use Voltage Ramp or a custom Accel curve. Output voltage is constantly updated to provide the linear current ramp, and therefore the available torque is maximized at any given speed. This is for applications where rapid changes in torque may result in load damage or equipment changes. Typical applications include overland conveyors if belt stretching occurs, fans and mixers if blade warping is a problem, and material handling systems if stacked products fall over or break.

Cont.

This feature can be used with or without the Maximum Current Limit setting. To achieve Current Ramping select CURRENT for START RAMP #1 TYPE setpoint and set the MAXIMUM CURRENT #1 setpoint to the desired level.

- **Current Limit Only (Current Step)** uses the Current Limit feature exclusively. This method of starting eliminates the soft start voltage/current ramp and instead, maximizes the effective application of motor torque within the limits of the motor. In this mode, setpoint RAMP TIME #1 is set to minimum so that the output current jumps to the current limit setting immediately. Typically used with a limited power supply when starting a difficult load such as a centrifuge or a deep well pump, when the motor capacity is barely adequate (stall condition or overloading occurs) or if other starting modes fail. Since ramp times are set to minimum, START RAMP #1 TYPE is set to either VOLTAGE or CURRENT.
- **Initial Torque (Initial Voltage #1 or Initial Current #1)** sets the initial start point of either Voltage Ramp or the Current Ramp. Every load requires some amount of torque to start from a standstill. It is inefficient to begin ramping the motor from zero every time, since between zero and the WK2 break-away torque level, no work is being performed. The initial torque level should be set to provide enough torque to start rotating the motor shaft, enabling a soft start and preventing torque shock damage. Setting this start point too high will not damage the starter, but may reduce or eliminate the soft start effect.
- **Ramp Time #1** sets the maximum allowable time for ramping the initial voltage, current (torque) or power setting to either of the following:
  - The Current Limit setting when the motor is still accelerating.
  - Full output voltage if the Current Limit is set to maximum.
  - KW if Power Ramp is selected.


Increasing the ramp time softens the start process by gradually increasing the voltage, current or power. Ideally, the ramp time should be set for the longest amount of time the application will allow (without stalling the motor). Some applications require a short ramp time due to the mechanics of the system. (i.e., centrifugal pumps, because pump problems can occur due to insufficient torque).

- **Current Limit** sets the maximum motor current the starter will allow during the acceleration. As the motor begins to ramp, the Current Limit feature sets a maximum at which the current draw is held. Current Limit remains in effect until the following occurs:
  - 1) The motor reaches full speed (Detected by the At-Speed detection circuit) or;
  - 2) The Overload Protection trips on Motor Thermal Overload. Once the motor reaches full speed, the Current Limit feature becomes inactive.

In the Voltage Ramp Profile, the voltage output is increased until it reaches the Current Limit. Ramp time is the maximum amount of time it takes for the voltage to increase until the Current Limit setting takes over. With some load conditions, the Current Limit is reached before the Ramp Time expires. The Current Ramp profile varies the output voltage to provide a linear increase in current up to the Maximum Current setpoint value. A closed loop feedback of motor current maintains the Current Ramp profile.

**SP2.4 Start Ramp 2 Type:** Please refer to Ramp 1 settings for Ramp 2 Type: Voltage selection.


**Start Ramp 2: Power**

 <b>CAUTION</b>
Do not use on an unloaded un-coupled motor!
The power ramp should only be used with a loaded motor.

- The **Power Ramp** feature has three programmable setpoints, Initial Power, Ramp Time and Maximum Power.
  - The **Initial Power** setpoint allows the user to define an initial KW (motor power) value that will be applied to the motor when the start sequence is begun. It has a range of 0-100% and a default value of 20%.
  - The **Ramp Time** functions as all other ramp time and allows the user to define a time period during which the applied KW (motor power) will be increased linearly to the Maximum Power value setpoint. The adjustment range is 1-120 seconds. Once the Power Limit value is reached, the system enters a constant power mode that regulates the applied motor power until the motor reaches full speed.
  - The **Maximum Power** setpoint has an adjustment range of 0-300% and a default value of 80%.

Cont.

- **Power Ramp Calculations:** The basic motor power value is derived from the line voltage and motor FLA, using a unity power factor as a default. This allows for approximation of the motor power rating without any other input data. During the Power Ramp process, the RMS line voltage, RMS motor current and power factor are measured on a cycle by cycle basis and applied to the Power Ramp algorithm. The CPU then calculates the True RMS motor power and will control the SCR firing to deliver the programmed power ramp values to the motor.



- **Initial Power:** The Initial power setpoint allows the user to define an initial KW (motor power) value that will be applied to the motor at the beginning of the start sequence.
- **Ramp Time #2:** See Ramp Time #1 for description.
- **Maximum Power:** Sets the maximum motor power the starter will allow during the acceleration. As the motor begins to ramp, the "Maximum Power" sets a limit.

**SP2.5 Kick Start:** Used as an initial energy burst in applications with high friction loads.

- **Kick Start Voltage:** The initial voltage (as a percent of full voltage value) that is needed to start the motor (e.g. Breakaway or Initial Torque).
- **Kick Start Time:** The time the initial torque boost is applied.

**SP2.6 Deceleration:** Allows the motor to gradually come to a soft stop.

- **Start Deceleration Voltage:** Upon receiving a STOP command, the output voltage initially drops to this voltage (represented as a percent of voltage value).
- **Stop Deceleration Voltage:** The drop-off point of the deceleration ramp (percent of voltage value). The point at which the unit output drops to zero to end the deceleration.
- **Deceleration Time:** The time to get to the stop Deceleration Voltage setpoint value.

**SP2.7 Timed Output:** Used with an AUX (5-8) relay. When enabled, and upon a start command, it waits until the programmed time plus the run delayed time has expired. The relay energizes and remains so until a stop command is received. It de-energizes upon receiving a stop command.

**SP2.8 Run Delay Time:** Can be used with an AUX (5-8) relay. The delay timer begins upon receipt of the start command. The relay will then drop out when the time has expired.

**SP2.9 At-Speed Delay Time:** Used with the AUX 4 relay, it energizes when the motor reaches At-Speed and the Programmed delay time has expired. The relay remains energized until a stop command has been received.

**SP2.10 Bypass Pull-in Current:** Level is a % of Motor FLA at which the bypass activates while at speed.

**SP.3 Phase & Ground Settings (Setpoint Page 3)**  
(Security Level 2)

**SP3.1 Imbalance Alarm Level:** This is an advance warning of a phase imbalance problem. The problem may not be a fault in the motor, but merely caused by imbalanced voltages.

- **Imbalance Alarm Delay:** The amount of time the imbalance condition must exist before an alarm occurs.

**SP3.2 Imbalance Trip Level:** This will trip the motor on excessive phase imbalance. The trip level should be programmed to a higher value than the alarm level.

- **Imbalance Trip Delay:** The amount of time the imbalance condition must exist before a trip will occur.

**SP3.3 Undercurrent Alarm Level:** Typically used to warn of possible load loss, a coupling break or other mechanical problems.



- **Undercurrent Alarm Delay:** The amount of time the undercurrent condition must exist before an alarm will occur.

**SP3.4 Overcurrent Alarm Level:** Typically used to indicate when the motor is overloaded. This feature can be used to either stop the feed to the equipment or warn operators of an overload condition.

- **Overcurrent Alarm Delay:** The amount of time the overcurrent condition must exist before an alarm will occur.

**SP3.5 Overcurrent Trip Level:** Typically used to indicate the motor is severely overloaded and at which point a trip occurs.

- **Overcurrent Trip Delay:** The amount of time the overcurrent condition must exist before a trip will occur.



Continued (Next Page)

**SP3.6 Phase Loss Trip:** When enabled, the Soft Starter will trip the motor off-line upon a loss of phase power.

- **Phase Loss Trip Delay:** The amount of time the phase loss condition must exist before a trip will occur.

**SP3.7 Phase Rotation Detection:** The soft starter is continuously monitoring the phase rotation. Upon a start command, a trip will occur if it detects a change in the phase rotation.

- **Phase Rotation:** There are two possible phase rotation options: ABC or ACB. This Setpoint monitors the wiring to ensure that the phase rotation is correct. To view the present phase rotation, go to Metering Page1, screen number 4.

**SP3.8 \*Ground Fault Alarm:** Typically used to warn of low level ground current leakage

- **Ground Fault Alarm Delay:** The amount of time that the ground fault condition must exist before an alarm will occur.

**SP3.9 \*Ground Fault Loset Trip Level:** Typically used to trip the motor on a low level of ground current leakage. This Setpoint is intended to detect high impedance faults.

- **Ground Fault Loset Trip Delay:** The amount of time that the ground fault condition must exist before a trip will occur.

\* **Ground Fault Option must be installed**


**SP3.10 \*Ground Fault Hiset Trip Level:** Used to trip the motor (within milliseconds) upon detecting a high level of ground current leakage. This Setpoint is intended to detect low impedance faults.

- **\*Ground Fault Hiset Trip Delay:** The amount of time that the ground fault condition must exist before a trip will occur.

**SP3.11 Overvoltage Alarm Level:** Typically used to indicate when the line voltage is too high. This is an alarm level.


- **Overvoltage Alarm Delay:** Amount of time the overvoltage condition must exist before an alarm occurs.

Continued (From Previous Page)



- SP3.12 Overvoltage Trip Level:** Typically used to indicate that the line voltage is too high and at which point a trip occurs.
- **Overvoltage Trip Delay:** The amount of time that the overvoltage condition must exist before a trip will occur.
- SP3.13 Undervoltage Alarm Level:** Typically used to indicate when the line voltage is too low. This is an alarm level.
- **Undervoltage Alarm Delay:** The amount of time that the undervoltage condition must exist before an alarm occurs.
- SP3.14 Undervoltage Trip Level:** Typically used to indicate that the line voltage is too low at which point a trip occurs.
- **Undervoltage Trip Delay:** The amount of time that the undervoltage condition must exist before a trip occurs.
- SP3.15 Line Frequency Trip Window:** The acceptable amount of drift above or below the line frequency (Hz) before a trip is generated.
- **Line Frequency Trip Delay:** The amount of time that the frequency drift condition must exist beyond the window before a trip occurs.
- SP3.16 Power Factor Lead Alarm:** Typically used to indicate a leading power factor.
- **Power Factor Lead Alarm Delay:** The amount of time that the power factor lead condition must exist beyond the window before an alarm occurs.
- SP3.17 Power Factor Lead Trip:** The acceptable amount of power factor lead before a trip is generated.
- **Power Factor Lead Delay:** The amount of time that the power factor lead condition must exist beyond the window before a trip will occur.
- SP3.18 Power Factor Lag Alarm:** Typically used to indicate a lagging power factor.
- **Power Factor Lag Alarm Delay:** The amount of time that the power factor lagging condition must exist beyond the window before an alarm occurs.
- SP3.19 Power Factor Lag Trip:** The acceptable amount of power factor lag before a trip is generated.
- **Power Factor Lag Delay:** The amount of time that the power factor lag condition must exist beyond the window before a trip will occur.
- SP3.20 Power Demand Period:** The soft starter monitors the demand of the motor based on several parameters (current, kW, kVAR, kVA). Monitoring the demand of the motor assist in the energy management program where processes can be altered or scheduled to reduce overall demand. Demand is calculated by taking samples of the output current, kW, kVAR and kVA over a period of time, then averaged and stored into memory.

**SP.4 Relay Assignment (Setpoint Page 4)**  
(Security Level 2)



**SP.4 Relay Assignment (Setpoint Page 4) - Continued**  
(Security Level 2)

All of the protective functions of the soft starter are user programmable to an output relay. The factory will ship with all tripping functions assigned to TRIP (AUX1) relay, and all alarm functions to ALARM (AUX2) relay. Note: AUX1 - 4 are factory set and should not be changed.

**SP4.1** The following is a list of all the user programmable functions.

**Note:** The 1st Relay Assignments are factory defaults and should not be changed.

**RELAY ASSIGNMENTS**


**FUNCTIONS**

	<b><u>1st</u></b>	<b><u>2nd</u></b>	<b><u>3rd</u></b>
OVERLOAD TRIP	TRIP ONLY	NONE	NONE
IMBALANCE TRIP	TRIP (AUX1)	NONE	NONE
SHORT CIRCUIT TRIP	TRIP ONLY	NONE	NONE
OVERCURRENT TRIP	TRIP (AUX1)	NONE	NONE
STATOR RTD TRIP	NONE	NONE	NONE
NON-STATOR RTD TRIP	NONE	NONE	NONE
GROUND FAULT HI SET TRIP*	TRIP (AUX1)	NONE	NONE
GROUND FAULT LO SET TRIP*	TRIP (AUX1)	NONE	NONE
PHASE LOSS TRIP	TRIP (AUX1)	NONE	NONE
ACCEL TIME TRIP	TRIP ONLY	NONE	NONE
START CURVE TRIP	TRIP ONLY	NONE	NONE
OVER FREQUENCY TRIP	NONE	NONE	NONE
UNDER FREQUENCY TRIP	TRIP (AUX1)	NONE	NONE
I*T START CURVE	TRIP (AUX1)	NONE	NONE
LEARNED START CURVE	TRIP (AUX1)	NONE	NONE
PHASE REVERSAL	TRIP (AUX1)	NONE	NONE
OVERVOLTAGE TRIP	TRIP (AUX1)	NONE	NONE
UNDERVOLTAGE TRIP	TRIP (AUX1)	NONE	NONE
POWER FACTOR TRIP	NONE	NONE	NONE
TACH ACCEL TRIP	NONE	NONE	NONE
INHIBITS	ALARM (AUX2)	NONE	NONE
SHUNT TRIP	NONE	NONE	NONE
BYPASS DISCREPANCY	TRIP ONLY	NONE	NONE
LOW CONTROL VOLTAGE	TRIP ONLY	NONE	NONE
TCB FAULT / ESTOP	TRIP (AUX1)	NONE	NONE
EXTERNAL INPUT 2	NONE	NONE	NONE
DUAL RAMP	NONE	NONE	NONE
THERMOSTAT	TRIP (AUX1)	NONE	NONE
OVERLOAD WARNING	ALARM (AUX2)	NONE	NONE
OVERCURRENT ALARM	ALARM (AUX2)	NONE	NONE
SCR FAIL SHUNT ALARM	ALARM (AUX2)	NONE	NONE
GROUND FAULT ALARM*	ALARM (AUX2)	NONE	NONE
UNDERCURRENT ALARM	NONE	NONE	NONE
MOTOR RUNNING	AUX3	NONE	NONE
IMBALANCE ALARM	ALARM (AUX2)	NONE	NONE
STATOR RTD ALARM	NONE	NONE	NONE
NON-STATOR RTD ALARM	NONE	NONE	NONE
RTD FAILURE ALARM	NONE	NONE	NONE
SELF TEST FAIL	TRIP (AUX1)	NONE	NONE
THERMAL REGISTER	ALARM (AUX2)	NONE	NONE
U/V ALARM	ALARM (AUX2)	NONE	NONE
O/V ALARM	ALARM (AUX2)	NONE	NONE
POWER FACTOR ALARM	NONE	NONE	NONE
KW DEMAND ALARM	NONE	NONE	NONE
KVA DEMAND ALARM	NONE	NONE	NONE
KVAR DEMAND ALARM	NONE	NONE	NONE
AMPS DEMAND ALARM	NONE	NONE	NONE
TIMED OUTPUT	NONE	NONE	NONE

RUN DELAY TIME	NONE	NONE	NONE
AT-SPEED	AUX4	NONE	NONE
*Ground fault option must be installed.			

**SP.5 Relay Configuration (Setpoint Page 5)  
(Security Level 3)**

In Setpoint Page 5 the user can configure the four output relays as either fail-safe or non fail-safe and latching or non-latching.




**SP5.1** When a relay has been configured as fail-safe and power is applied, the relay will be energized. The relay will then de-energize when an event occurs or if the power fails.

**NOTE:** The relays in the soft starter will not prevent a start sequence unless they are wired in as interlocks. If power is lost, the motor power is also lost. Do not change the programming for AUX 1-4. These are for factory use only. AUX 5-8 are user defined outputs.

**SP5.2** A relay configured as non-latching will reset itself when the cause of the trip event is not continuous. The TRIP (AUX1) relay should always be programmed for latching, because this trip should require a visual inspection of the motor and starter before issuing a manual reset to release the relay after a trip has been stored.

**SP.6 User I/O Configuration (Setpoint Page 6)**  
(Security Level 2)



Continued on Pg. 56

## SP.6 User I/O Configuration (Setpoint Page 6) - Continued (Security Level 2)

The soft starter can be configured to accept a tachometer feedback signal using the 4-20mA input.

**SP6.1** The first screen of Setpoint page 6 is TACHOMETER SCALE SELECTION. When this is set to ENABLED, the user will need to input the tachometer scale of the 4-20mA input range.

- **Manual Tach Scale 4.0 mA:** The unit is looking for an RPM value to assign to the lowest point on the scale. This Value should represent the motor at zero speed.
- **Manual Tach Scale 20.0 mA:** The unit is looking for an RPM value to assign to the highest point on the scale. This value should represent the motor at full speed.

**SP6.2 Tach Accel Trip Mode Select:** When enabled, the underspeed or overspeed must be selected for the Tach Accel Trip. If underspeed is selected, only the Tach Underspeed Trip Point will be used. If overspeed is selected, only the Tach Overspeed Trip Point will be used.

- **Tach Ramp Time:** This is the duration of time before the starter begins sampling the tachometer.
- **Tach Underspeed Trip:** Defines the minimum motor speed using the Tach feedback. When the underspeed trip mode is enabled and the motor speed falls below this level for the time specified by the Tach Accel Trip Delay, an underspeed trip occurs.
- **Tach Overspeed Trip:** Defines the maximum allowed motor speed using the Tach feedback. When the overspeed trip mode is enabled and the motor speed exceeds this level for the time specified by the Tach Accel Trip Delay, an overspeed trip occurs.
- **Tach Accel Trip Delay:** The duration of time that the Tach Accel trip condition must persist before a trip is generated.

**SP6.3** The controller provides two 4-20mA analog outputs. Each analog output is independent of the other and can be assigned to monitor different functions. The available output ranges are RPM, Hottest Non-Stator (Bearing) RTD, Hottest Stator RTD, RMS current, and % of Motor Load.


- **Analog Output #1** – Select a function from the available five options to be transmitted from the 4-20mA output.

*Note: If selecting RPM, the Tachometer feedback input signal must be present in order for the controller to give proper output. If selecting RTD, an RTD input signal must be present for a proper output to be given from the analog output.*

- **Analog Output #1 (4 mA):** Enter a value that the 4mA level will represent for the selected function; typically this value should be 0.
- **Analog Output #1 (20 mA):** Enter a value that the 20mA level will represent for the selected function.

**SP6.4 Analog Output #2** – All of the setpoints and setup screens for Analog Output #2 are the same as those for Analog Output #1.

**SP.6 User I/O Configuration (Setpoint Page 6) - Continued**  
(Security Level 2)



**SP6.5 User Programmable External Inputs:** The controller provides up to 4 digital external inputs which are individually programmable. A description name can be assigned to each individual input for easy identification.

- **TCB FAULT / ESTOP:** Factory programmed for TCB Fault/ESTOP. Input and can be enabled or disabled.
- **TWO SPEED:** Factory programmed for TWO SPEED. Input and can be enabled, disabled or Two Speed.
- **External Input #3:** The setup screens and setpoints for External Input #3 includes the option of being configured for Dual Ramp. In Dual Ramp mode, the initial contact setting is the same as the START RAMP #1. Upon a change in input contact state, the controller will switch over to START RAMP #2 and use that setting for start control mode.

*Note: The start RAMP types should only be switched while the motor is stopped. In Setpoint Page 4 Relay Assignments do not assign any output relay to this function. The controller is programmed with External input #3 programmed for dual ramp. If it is not needed, disable the dual ramp.*

- **External Input #4:** These input screens are for the thermostat input and can be enabled, disabled or thermostat.

*Note: It is recommended that this function remain enabled. If the thermostat indicates an over temperature condition, the controller will trip the motor.*

**External Input #1, #2, #3, #4 Time Delay:** Upon a change in contact setting, the unit will wait the programmed amount of time before generating an output. If no delay is needed, then input 0 seconds. The controller will post an event upon seeing a change in state.

**External Input #1, #2, #3, #4 Type:** The external input can be set as either a normally open or normally closed contact.


**Name Ext. Input #1, #2, #3, #4:** The user can assign a description name to the input. Up to 15 characters including spaces can be used to assign the name.

**SP.7 Custom Acceleration Curve (Setpoint Page 7)  
(Security Level 3)**

**SP7.1** Setpoint Page 7 allows the user to custom design the acceleration curve (start curve) for a specific application. The custom design setup allows for up to three different curves in the Soft Starter. Only one curve can be active (enabled) at any given time. Each of the three curves allow for eight voltage plotting points, with corresponding ramp times and a current limit setting.

**Note:** Each successive voltage level must be programmed to a voltage level equal to or greater than the previous level. All eight voltage levels must be programmed and the eighth level has been preset at 100%.

- If Custom Accel Curve has been set to curve A, B or C on this page, the Soft Starter will override the Start Control Mode selected in Setpoint Page 2, (even if Start Control Mode in Setpoint Page 2 has not been set to Custom Accel Curve).




(Continued on next page)

SP.7 Custom Acceleration Curve (Setpoint Page 7) - Continued

(Security Level 3)


(Continued from Prev. page)



(Continued on next page)

**SP.7 Custom Acceleration Curve (Setpoint Page 7) - Continued**  
(Security Level 3)

(Continued from prev. page)




**SP.8 Overload Curve Configuration (Setpoint Page 8)  
(Security Level 3)**

Configures the unit's start and run protection mode. The unit has independent start and run curve protection and the settings can be based on the OL Class or set by the motor's locked rotor current and time.

**SP8.1 Basic Run Overload Curve**

- **Run Curve Locked Rotor Time:** Set the locked rotor time to the OL Class default chosen in Setpoint Page 1 or set the time in seconds. This is the time the locked rotor condition exists before a trip occurs.
- **Run Locked Rotor Current:** The current the motor draws with full voltage on the windings and no rotor movement (as a percent of motor FLA). Refer to the nameplate data or contact the motor manufacturer.
- **Coast Down Timer:** If enabled, this prevents the motor from restarting for the programmed amount of time, after a stop command is given.



### **SP8.2 Basic Start Overload Curve**

- **Start Curve Locked Rotor Time:** The locked rotor time can be set to the OL Class default chosen in Setpoint Page 1 or to a specific time. The overload condition must exist for the programmed amount of time before a trip occurs.
- **Start Locked Rotor Current:** The current the motor draws with full voltage on the windings and no motor movement (as a percent of motor FLA). Refer to the motor nameplate data or contact the motor manufacturer.
- **Acceleration Time Limit:** If the motor does not enter run mode (reach “At-Speed”) within the pre-set time, the unit trips on acceleration time limit.
- **Number of Starts per hour:** If enabled, this limits the maximum number of starts permitted per hour. This setpoint allows a maximum of 6 starts per hour. Contact the motor manufacturer for further information regarding number of starts per hour.
- **Time Between Starts:** If enabled, the soft starter prevents another start attempt until the programmed time has expired.

**SP8.3 Area Under Curve Protection:** If enabled, this secondary start protection uses both the basic start protection and the area under the curve protection.

- **Max I<sup>2</sup>t Start:** The maximum I<sup>2</sup>t allowed during start. If the I<sup>2</sup>t to start exceeds this number then the soft starter will generate a trip.

**SP8.4 Current Over Curve:** Learns the motor’s starting characteristics and protects the motor based upon the learned curve. It is useful when commissioning a new motor.

- **Learn:** The unit reads the motor’s starting characteristics. Start the motor and allow it to come to full speed. The start feedback enables the motor protection based on the learned start curve.
- **Learned Start Curve Bias:** The maximum allowed deviation above or below the start curve before a trip is generated.
- **Time for sampling:** The time the soft starter continues to sample the start curve characteristic during learn mode.

### SP.9 RTD Configuration (Setpoint Page 9) (Security Level 3)

The soft starter has a card that provides 12 programmable RTDs which are individually programmable for type. Each RTD can be identified with a description name of up to 15 characters (including spacing). Also, each individual RTD has its own alarm and trip level.

**SP9.1 Use NEMA Temp for RTD Value:** When this setpoint is enabled, the soft starter will use the NEMA design insulation class to limit the maximum allowed range of the alarm and trip level. The maximum allowed temperature range is 240° C or (464°F).

**SP9.2 Number Of RTD'S Used for Stator:** Up to six RTDs can be assigned to monitor the stator of the motor.

**SP9.3 RTD Voting:** When this is enabled, the Soft Starter will not post a trip until 2 RTD's have exceeded the trip level. This prevents nuisance RTD tripping.

**SP9.4 Description:** Each of the 12 RTDs is configured in the following manner. The first column is the RTD type, the second column is the RTD description, the third column is the alarm level, and the fourth column is the trip level. The first six RTDs have been pre-programmed with a description name for the STATOR, with two RTDs per phase.

RTDs #1 & #2 have been named STATOR PHASE A1 and A2 respectively. RTDs #3 & 4 are named STATOR PHASE B1 and B2, RTDs #5 & 6 are named STATOR PHASE C1 and C2.

If other description names are required, press the right arrow button from the RTD Type screen to go the RTD description screen. If no alarm or trip level is required these setpoints can be turned off.

#### RTD Available Settings

##### RTD TYPE:

- 120 OHM NICKEL (NI)
- 100 OHM NICKEL (NI)
- 10 OHM COPPER (CU)
- 100 OHM PLATINUM (PT)

**ALARM LEVEL:** OFF or 0 - 240C (32-464F) Example: ### C = ### F, Increments of 1

##### RTD DESCRIPTION:

STATOR A1, STATOR A2, STATOR B1, STATOR B2, STATOR C1, STATOR C2, FRONT BEARING, BACK BEARING, BEARING BOX, AMBIENT, NONE

**RTD ALARM DELAY:** Entry allows the enunciation of the Alarm condition to be delayed by the set time to ensure an alarm condition persists.

**Factory Setting = 5 sec.**

**Range = 1 - 60 sec.**


**RTD TRIP DELAY:** This entry will allow the RTD Trip function to be delayed by the set time.

**Factory Setting = 10 sec.**


**Range = 1 - 60 sec.**

Cont

SP.9 RTD Configuration (Setpoint Page 9)  
(Security Level 3)




SP.9 RTD Configuration (Setpoint Page 9)  
(Security Level 3)



**SP.10 Set Password (Setpoint Page 10)  
(Security Level 3)**

The soft starter has three levels of user programmable setpoint screens. Level one setpoints do not require a password because the data contained in level one is basic nameplate data and starter control. Level two setpoint screens require a three-digit password to configure the protection schemes. Level three setpoint screens require a four-digit password to access the full range of protection and starter schemes.



**SP10.1 Set Level 2 Password:** This level uses a 3-digit password. The default level 2 password is 100.

**SP10.2 Set Level 3 Password:** Level three uses a 4-digit password. The default level 3 password is 1000.

**SP.11 Communications (Setpoint Page 11)  
(Security Level 3)**

**SP11.1 Set Front Baud Rate:** Configures the RS232 communications baud rate.


**SP11.2 Set Modbus Baud Rate:** Configures the Modbus communications baud rate

**SP11.3 Modbus Address Number:** Assigns a Modbus address to the unit.

**SP11.4 Set Access Code:** Assigns an access code to the Modbus addressing. This is typically not used

**SP11.5 Set Link Baud Rate:** Configures the RS422 communications baud rate between the keypad operator and the CPU board (For applications with remote keypad only).

**SP11.6 Remote Start/Stop:** Allows the RS485 Modbus communications to start and stop the motor. Contact factory for details.



## SP.12 System Setpoints (Setpoint Page 12) (Security Level 3)

**SP12.1 Default Display Screen:** This Setpoint group allows the user to choose the default screen the Soft Starter displays while the motor is running. Select the metering page number (1-3), then, select the metering screen number. The range varies depending on the selected page. To display a default screen, program the following two Setpoints:

- **Metering Data Page#:** Range is Page 1 - 3.
- **Metering Data Screen#:** If Page 1 is selected as the default page, then Screens 1- 10 are available. If Page 2 Screens 1-29 are available. If Page 3 is selected then Screens 1-6 are available. (See Metering Menu, MP.1, for screen number assignment.)


**SP12.2 Alarms:** Configures the RTD failure alarm and the thermal register alarm.

- **RTD Failure Alarm:** If enabled, and an RTD shorts or open, an alarm occurs.
- **Thermal Register Alarm:** Sets a level in the thermal register to generate an alarm when the Thermal Register Capacity Used has exceeded this level.
- **Thermal Alarm Delay:** The amount of time that the Thermal Register Used must exceed the Setpoint before an alarm condition will occur.

**SP12.3 Thermal Register Setup Information:** This Setpoint group will configure the thermal register and indicate to the soft starter which inputs to use when thermal modeling.

- **Cold Stall Time:** Enter the time from the motor manufacturer's specification sheet or use the time defined by the OL Class. This Setpoint is used to define the thermal capacity of the motor.
- **Hot Stall Time:** Enter the amount of time specified by the motor manufacturer or use half of the time defined by the OL Class.
- **Stopped Cool Down Time:** The time the motor needs to cool down after it has stopped. Use only the data provided by the motor manufacturer. This Setpoint is used to configure the cooling rate of the thermal register.
- **Running Cool Down Time:** The amount of time the motor needs to cool down while running. Use only the data provided by the motor manufacturer.
- **Relay Measured Cool Rates:** When the RTD option is supplied, the Soft Starter can be configured to use the measured cooling rates from the RTDs instead of the programmed settings. This Setpoint should only be enabled when the RTD option is present.
- **Thermal Register Minimum:** Sets the value in the thermal register which represents a motor running at the nameplate current (with no overheating or negative sequence currents present).
- **Motor Design Ambient Temperature:** Use the data from the motor manufacturer's specifications. When RTD option is supplied, this Setpoint will be the base point for the RTD biasing of the Thermal Register.
- **Motor Design Run Temperature:** Use the data from the motor manufacturer's specifications. This Setpoint defines the operating temperature rise of the motor at full load amps or 100% load.
- **Motor Stator Max Temperature:** This represents the maximum temperature the stator insulation will withstand. The user may choose to use the temperature setting of the insulation class (selected in Setpoint Page 1) or enter a specific maximum temperature. This value should not exceed the stator's insulation temperature. This maximum temperature represents 100% thermal capacity.
- **U/B Input to Thermal Register:** Always enabled. It allows the soft starter to use the line current imbalance information to bias the Thermal Register.

- **User Calculated K or Assign:** When the Setpoint is set to ON, the soft starter will calculate the k constant factor for biasing the thermal register, or the user may choose to assign the k value.
- **SP12.4 Press Enter to CLR Thermal Register:** Allows the level three password user to clear the thermal register for emergency restarts.



### SP.13 Calibration & Service (Setpoint Page 13)

(Security Level 3)


Certain screens are displayed for user information only, such as Current date and time, Model number and Firmware revision number. *Setpoint changes in this page will only be accessible to factory personnel.*

**SP13.1 Set Date and Time:** Displays the date and time.

- **Enter Date (DDMMYYYY):** Allows the factory personnel to program the date for the soft starter in the format shown.
- **Enter Time (HH:MM):** Allows the factory personnel to program the time for the soft starter.

**SP13.2 Model & Firmware #:** Displays the model number and firmware revision in the soft starter.

**SP13.3 Press Enter to Access Factory Settings:** Available to qualified personnel.



## Chapter 6 - Metering Pages

The soft starter offers performance metering which gives the user the ability to view information about the motor and the unit.

### 6.1 Metering Page List

The following charts list each Metering Page and the functions within that page. The applicable section of the manual is referenced.

#### 6.1.1 Metering Menu & Data (Metering Page 1)

Metering Page	Description of Display	Screen
PAGE 1 Metering Menu & Data	Phase A, B, C and Ground Fault (Option)	1
	Average current of the % of imbalance and the motor's RPM (Tach Option)	2
	Motor load as a percentage of motor FLA	3
	Line frequency and present phase sequence	4
	Percentage of remaining Thermal Register	5
	Thermal capacity required to start the motor	6
	Average time required to start	7
	Average current during start	8
	Measured I <sup>2</sup> T required to start the motor	9
	Amount of time required to start the motor during the last successful start	10

#### 6.1.2 Metering (Metering Page 2)

Metering Page	Description of Display	Screen
PAGE 2 Metering	Phase A, B, C currents and Power Factor	1
	Phase A, B, C currents and Ground Fault (Option)	2
	Displays kW and kVA	3
	Displays kVAR and Power Factor	4
	Displays Peak ON and kW Demand	5
	Displays Peak ON and kVA Demand	6
	Displays Peak ON and kVAR Demand	7
	Displays Peak ON and Amps Demand	8
	Clears Demand values	9
	Displays Megawatt hours used	10
	Press enter to clear statistics on MWH values	11

#### 6.1.3 RTD Values (Metering Page 3)

Metering Page	Description of Display	Screen
PAGE 3 RTD Values	Hottest stator RTD (#1 - 6)	1
	Hottest non-stator RTD (#7 - 12)	2
	Temperature of start phase A1 in °C and °F	3
	Maximum temperature for RTD #1	4
	Same as Screens 3 - 4 for RTDs #2 - 12	5 - 26
	Clear the maximum temperature register (Level 3 password required)	27
	Measured running thermal stabilization time of motor (in minutes)	28
	Measured stopped cooling time (to ambient) of motor (in minutes)	29

6.1.4 Status (Metering Page 4)

Metering Page	Description of Display	Screen
PAGE 4 Status	Current status	1
	Amount of time remaining before an overload trip occurs	2
	Amount of time remaining from a thermal inhibit signal	3
	Coast down time remaining	4
	Amount of time remaining before a start command can be given	5
	Excessive number of starts per hour	6

6.1.5 Event Recorder (Metering Page 5)

Metering Page	Description of Display	Screen
PAGE 5 Event Recorder	Displays the event with date and time (Up to 60 events)	1
	Displays Phase A, B, C current values, Ground Fault (Option) at time of trip	1A
	Displays Vab, Vbc, Vca and Power Factor at time of trip	1B

6.1.6 Last Trip (Metering Page 6)


Metering Page	Description of Display	Screen
PAGE 6 Last Trip	Cause of last trip	1
	Measured phase current	2
	Measured voltage and power factor	3
	Imbalance percentage, the frequency and the kW	4
	Hottest stator RTD temperature	5
	Hottest non-stator RTD temperature	6

6.1.7 Statistics (Metering Page 7)

Metering Page	Description of Display	Screen
PAGE 7 Statistics	Total Megawatt Hours	1
	Accumulated Total Running Hours	2
	Clear the Total Running Hour Count	3
	Total Number of Trips / Number of Short Circuit Trips	4
	Number of Start and Run Overload Trips since the last statistical data clearing	5
	Number of frequency and Current Imbalance trips	6
	Number of Over Current Trips	7
	Stator and Non-Stator RTD Trips	8
	Ground Fault Hiset and Loset Trips	9
	Acceleration Time Trips	10
	Start Curve Trips	11
	I <sup>2</sup> T Start Curve Trips	12
	Learned Start Curve Trips	13
	Shunt Trip Trips	14
	Phase Loss Trips	15
	Tach Acceleration Trips	16
	Undervoltage and Overvoltage Trips	17
	Power Factor Trips	18
	Phase Reversal Trips	19
	Low Control Voltage Trips	20
	Ext Input #1 Trips	21
	Ext Input #2 Trips	22
	Ext Input #3 Trips	23
	Ext Input #4 Trips	24
	<b>Press ENTER to Clear Statistics</b>	25


## 6.2 Metering Menu and Explanation

Push MENU key to toggle the screens between Setpoint Menu and Metering Menu and follow the arrow keys to get to different screens.




**MP.1 Metering (Metering Page 1)**

Displays basic current metering data.




**MP.2 Metering (Metering Page 2)**

Displays the soft starter statistical voltage metering information.



**MP.3 Metering (Metering Page 3)**

Displays the RTD information.



**Screen 1:** Displays the hottest stator RTD (#1 – 6 depending upon number of RTDs used for stator).

**Screen 2:** Displays the hottest non-stator RTD (#7-12 if #1-6 is used for stator).

**Screen 3:** Displays the temperature of stator phase A1 in °C and °F.


**Screen 4:** Displays the maximum temperature for RTD #1 since the last command to clear the thermal register.

**Screen 5 - 26:** Same as Screens 3 - 4 for RTDs # 2 - 12.

**Screen 27:** Allows the user to clear the maximum temperature register upon entering the setpoint level 3 password.

**Screen 28:** Displays the measured run cool time in minutes.

**Screen 29:** Displays the measured stopped cool time in minutes.



### MP.4 Metering (Metering Page 4)

Displays the present status of the soft start

**\*Screen 1:** Displays the present state of the unit as follows:

**Screen 2:** Displays the amount of time remaining before an overload trip will occur.

**Screen 3:** Displays the amount of time remaining from a thermal inhibit. The inhibit time comes from the amount of thermal register remaining versus the amount of thermal capacity required to start.

**Screen 4:** Displays the coast down time remaining (Backspin time). The time remaining depends upon the user setting in Setpoint Page 8, Coast Down Time.

**Screen 5:** Displays the amount of time remaining before a start command can be given. The time remaining depends upon the setting in Setpoint page 5.

**Screen 6:** If the number of starts per hour has exceeded the setting in Setpoint page 8.

**\* NOTE: Screen 1 CURRENT STATUS Screens include:**

MOTOR STOPPED  
READY TO START

MOTOR STARTING  
MULT. OF FLA


MOTOR RUNNING  
AT ###.## X FLA

LAST TRIP CAUSE  
NONE (or trip cause)

PROGRAMMING  
SETPOINTS

MOTOR STATUS  
UNKNOWN STATE ###

(Displays relay state upon error)




**MP.5 Metering (Metering Page 5)**

Displays the present status of the soft start

**Screen 1:** Displays the event (i.e., Imbalance Trip) with the date and time it occurred.

**Screen 1a:** Displays the current at Phase A, B, C and the ground fault at the time of the event. (**Note:** Ground fault option must be present)

**Screen 1b:** Displays the Vab, Vbc, Vca and power factor at the time of event.



All events will be viewed from oldest event in buffer to most recent event.

**MP.6 Metering (Metering Page 6)**

Displays the last trip information

**Screen 1:** Displays the cause of the last trip.


**Screen 2:** Displays the measured phase current at the time of the trip.

**Screen 3:** Displays the Vab, Vbc, Vca and power factor at the time of trip.

**Screen 4:** Displays the imbalance percentage, the frequency and the kW at the time of the trip.

**Screen 5:** Displays the hottest stator RTD temperature (when RTD option present) at time of the trip.

**Screen 6:** Displays the hottest non-stator RTD temperature (when RTD option present) at the time of the trip.



**MP.7 Statistics (Metering Page 7)**

Displays the statistical trip information

**Screen 1:** Displays the total of megawatt hours.

**Screen 2:** Displays the accumulated total running hours.

**Screen 3:** Clears the total running hour count.

**Screen 4:** Displays the total number of trips since the last clearing of the statistical data and the total number of short circuit trips.

**Screen 5:** Displays the number of start overload and run overload trips since the last clearing of the statistical data.

**Screen 6:** Displays the number of frequency trips and Imbalance trips.

**Screen 7:** Displays the number of overcurrent trips

**Screen 8:** Displays the number of Stator and non-Stator RTD Trips

**Screen 9:** Displays the number of Ground Fault Hi and Lo Set trips

**Screen 10:** Displays the number of acceleration time trips.

**Screen 11:** Displays the number of start under curve trips

**Screen 12:** Displays the number start over curve trips

**Screen 13:** Displays the number of I2T start curve trips

**Screen 14:** Displays the number of learned start curve trips.

**Screen 15:** Displays the number of fail shunt trips.

**Screen 16:** Displays the number of phase loss trips.

**Screen 17:** Displays the number of tachometer acceleration trips.

**Screen 18:** Displays the number of undervoltage and overvoltage trips.

**Screen 19:** Displays the number of power factor trips.

**Screen 20:** Displays the number of phase reversal trips.

**Screen 21:** Displays the number of low control voltage trips.


**Screen 22:** Displays the number of external input #1 trips.

**Screen 23:** Displays the number of external input #2 trips.

**Screen 24:** Displays the number of external input #3 trips.

**Screen 25:** Displays the number of external input #4 trips.

**Screen 26:** Requires a Security Level 2 password to clear the statistics.



## Chapter 7 - Maintenance and Troubleshooting

The soft starter is designed to be a maintenance-free product; however, as with all electronic equipment, the unit should be checked periodically for build-up of dirt, moisture or industrial contaminants. These can cause high voltage arc-over, carbon tracking or prevent proper cooling of the SCR heat sinks. All bolts should be checked annually for proper tightness using an accurate torque wrench. According to the manufacturer's manual, check the contactor for air gap spacing of the vacuum bottles.

**Note:** If the unit is installed in a contaminated environment and forced air cooling is used, blower filters must be checked and cleaned regularly to insure proper air flow and cooling of the enclosure.

### 7.1 Failure Analysis

When a fault occurs, the OLED will display the fault error while the listed LED and AUX Relay will be lit. Please clear all faults before attempting to restart the unit.

**Note:** If the problem persists after the required programming changes have been made, and all corrective action has been taken, please contact the factory for assistance.

Problem	CPU OLED Display	LED	AUX Relay	Possible Cause	Solutions
External protection relay tripped or TCB board failure.	<b>TCB FAULT TRIP</b>	Trip	AUX1	Fault initiated by an external relay (e.g. emergency bypass protection relay)	Correct trip cause and reset external relay.
Short Circuit Trip	<b>SHORT CIRCUIT TRIP</b>	Trip	AUX1	Short circuit or ground fault in motor/cabling	Locate and remove short or ground.
				Phase Loss	Repair cause of phase loss.
				Branch circuit protection not correctly sized	Verify correct sizing of branch circuit protection.
				Faulty main circuit board	Remove power and replace main circuit board.
Single Phase Trip	<b>SINGLE PHASE TRIP</b>  (Check OLED display for possible fault indicators)	Trip	AUX1	Single phase incoming power	Correct problem with incoming power.
				Faulty SCRs	Remove power and test SCR(s). Refer to Section 7.1.1 for the SCR testing procedure.
Thermostat trips during run	<b>EXTERNAL TRIP ON THERMOSTAT</b>	Trip	AUX1	Heatsink coated with debris	Remove power and clean heatsink with high pressure air (80 - 100 psi max clean and dry air).
				Overcurrent on unit	Verify that running current does not exceed unit rating.
				Environment temp. over 122°F (ambient for chassis units) or over 104°F (ambient for enclosed version)	Place unit in environment temperature less than 122°F for panel version or less than 104°F for enclosed version.
				Bypass failed to close	Check the bypass contactor and wiring.

Cont.

7.1 Failure Analysis - Continued

Problem	CPU OLED Display	LED	AUX Relay	Possible Cause	Solutions
Phase Loss	PHASE LOSS	Trip	AUX1	Loss of 1 or more phases of power from utility or generated power.	Check power source.
				Blown power fuses	Check for short circuits.
Overload	OVERLOAD TRIP	Trip	AUX1	Improper programming	Check motor nameplate versus programmed parameters.
				Possible load damage or jammed load	Check motor currents.
Stall prevention	ACCEL TIME TRIP	Trip	AUX1	Improper setting for motor load condition	Verify current limit setting.
				Damaged load	Check for load failure.
Under Voltage Trip	UNDER VOLTAGE TRIP	Trip	AUX1	Improper programming	Check Setpoint settings.
				Wrong position of disconnected breaker	Check disconnect or open breaker.
				Main contactor failed to close	Check internal connections.
				Transformer too small	Reduce current limit setting, saturation or sagging power supply transformer.
Under Current Trip	UNDER CURRENT TRIP	Trip	AUX1	Improper programming	Check setpoint settings.
				Unloaded motor	Check load.
Self-test Failure	SELF-TEST FAILURE	Trip	AUX1	Failed CPU or Main Firing Board	Contact factory.
				Vibration	Check internal wiring connections.
Line Frequency Trip	OVER OR UNDER FREQUENCY TRIP	Trip	AUX1	Generator Power Problem or grid change	Troubleshoot and repair generator.
					Contact utility company.
					Main board failure.
					Three phase power removed from Main.
Any Ground Fault Trip	GROUND FAULT HI-SET OR LO-SET	Trip	AUX1	Improper programming	Check setpoint settings.
				Any wire going to ground (e.g. stator ground, motor ground, soft start ground)	Check with megger or Hi-pot motor leads and motor.
				High vibration or loose connections	Check internal connections.
Motor stopped during run	Check for fault indication	Trip	AUX1	 <b>WARNING</b> This is a serious fault condition. Ensure that the fault condition is cleared on the load side before attempting to restart the motor.	
				Load shorted	Remove power and repair.
				Faulty main circuit board	Replace the main circuit board.



Cont.

7.1 Failure Analysis - Continued

Problem	CPU OLED Display	LED	AUX Relay	Possible Cause	Solutions
Control circuit fuses blow after control power is applied	None	None	None	Short in Control Circuit	Remove power, locate and remove the short.
				Wrong Control Voltage	Apply the correct voltage to the control circuit.
Motor will not start	Any fault indication message	Trip	AUX1	No Control Voltage applied to Control Board	Apply control voltage to TB1 pins 1 and 6 on the power board.
				Control Power Transformer failure or CPT Fuse failure	Remove power and replace the power transformer or the CPT fuse.
				Start Circuit Wired Incorrectly	Remove power and correct the start circuit wiring.
				No Start Command	Apply the start command.
				No 3-Phase Line Voltage	Apply 3-phase line voltage to the unit.
				Shorted SCR in Starter	Remove power and Test SCR(s). Refer to Sec. 7.1.1 for the testing procedure.
				Faulty Control Logic	Remove power and repair the Control Logic.
Failure of Main Circuit Board	Replace the Main Circuit Board.				
Motor vibrates / Motor growls while starting or extremely unbalanced motor currents run mode	IMBALANCE TRIP	Trip	AUX1	Faulty Motor	Check the Motor and the Motor connections.
				Faulty SCR(s)	Remove Power and perform the SCR device checks.
				Faulty Gate / Cathode on SCR(s)	Remove Power and Test SCR(s). Refer to Sec. 7.1.1 for the testing procedure.
				Faulty Main Circuit Board.	Replace the Main Circuit Board.
	IMBALANCE ALARM	Alarm	AUX2	Faulty Motor / Wiring	Troubleshoot and repair / replace wiring.
				Faulty Main Circuit Board	Replace the Main Circuit Board.

7.1.1 - SCR Testing Procedure

Perform the SCR Heat Sink Ohm test on each Stack Assembly.



Test Points	OHM Meter Reading	Test Results
From Position A to Position B	Greater than 10K Ohm	Pass
	Less than 5K Ohm	Fail
From Position B to Position C	Greater than 10K Ohm	Pass
	Less than 5K Ohm	Fail
Gate (G) to Cathode (K) for each SCR	8 to 100 Ohms	Pass (Typical 8 to 20 Ohms)
	Less than 10 or greater than 100 Ohms	Fail

Notes

- 1 - Allow 15 minutes after shutdown for DV/DT network to discharge.
- 2 - Voltage sharing resistors may need to be disconnected to obtain correct readings for tests between positions A, B & C.





For the latest product information  
visit us at [www.Toshiba.com/tic](http://www.Toshiba.com/tic)