

Operating Instructions

Proline Promag 53

HART

Electromagnetic flowmeter





Table of contents

1	Safety instructions	4	9	Troubleshooting	103
1.1	Designated use	4	9.1	Troubleshooting instructions	103
1.2	Installation, commissioning and operation	4	9.2	System error messages	104
1.3	Operational safety	4	9.3	Process error messages	108
1.4	Return	5	9.4	Process errors without messages	110
1.5	Notes on safety conventions and icons	5	9.5	Response of outputs to errors	111
2	Identification	6	9.6	Spare parts	113
2.1	Device designation	6	9.7	Return	121
2.2	Certificates and approvals	9	9.8	Disposal	121
2.3	Registered trademarks	9	9.9	Software history	121
3	Installation	10	10	Technical data	123
3.1	Incoming acceptance, transport and storage	10	10.1	Application	123
3.2	Installation conditions	12	10.2	Function and system design	123
3.3	Installation	20	10.3	Input	123
3.4	Post-installation check	45	10.4	Output	123
4	Wiring	46	10.5	Power supply	124
4.1	Connecting the remote version	46	10.6	Performance characteristics	125
4.2	Connecting the measuring unit	51	10.7	Installation	125
4.3	Potential equalization	55	10.8	Environment	126
4.4	Degree of protection	57	10.9	Process	127
4.5	Post-connection check	58	10.10	Mechanical construction	132
5	Operation	59	10.11	Human interface	147
5.1	Display and operating elements	59	10.12	Certificates and approvals	148
5.2	Brief Operating Instructions for the function matrix	63	10.13	Ordering information	149
5.3	Error messages	65	10.14	Accessories	149
5.4	Communication	66	10.15	Documentation	149
6	Commissioning	83	Index		150
6.1	Function check	83			
6.2	Switching on the measuring device	83			
6.3	Quick Setup	84			
6.4	Configuration	93			
6.5	Adjustment	97			
6.6	Data storage devices	98			
7	Maintenance	99			
7.1	Exterior cleaning	99			
7.2	Seals	99			
8	Accessories	100			
8.1	Device-specific accessories	100			
8.2	Accessories specific to measuring principle	100			
8.3	Communication-specific accessories	101			
8.4	Service-specific accessories	102			

1 Safety instructions

1.1 Designated use

The measuring device described in this Operating Manual is to be used only for measuring the flow rate of conductive fluids in closed pipes.

A minimum conductivity of 20 $\mu\text{S}/\text{cm}$ is required for measuring demineralized water. Most liquids can be measured as of a minimum conductivity of 5 $\mu\text{S}/\text{cm}$.

Examples:

- Acids, alkalis
- Drinking water, wastewater, sewage sludge
- Milk, beer, wine, mineral water, etc.

Resulting from incorrect use or from use other than that designated the operational safety of the measuring devices can be suspended. The manufacturer accepts no liability for damages being produced from this.

1.2 Installation, commissioning and operation

Note the following points:

- Installation, connection to the electricity supply, commissioning and maintenance of the device must be carried out by trained, qualified specialists authorized to perform such work by the facility's owner-operator. The specialist must have read and understood these Operating Instructions and must follow the instructions they contain.
- The device must be operated only by persons authorized and trained by the system operator. Strict compliance with the instructions in the Operating Instructions is mandatory.
- Endress+Hauser is willing to assist in clarifying the chemical resistance properties of parts wetted by special fluids, including fluids used for cleaning. However, small changes in temperature, concentration or the degree of contamination in the process can result in changes to the chemical resistance properties. For this reason, Endress+Hauser does not accept any responsibility with regard to the corrosion resistance of materials wetted by fluids in a specific application. The user is responsible for the choice of wetted materials with regard to their in-process resistance to corrosion.
- If welding work is performed on the piping system, do not ground the welding appliance through the flowmeter.
- The installer must ensure that the measuring system is correctly wired in accordance with the wiring diagrams. The transmitter must be grounded, except in cases where special protective measures have been taken (e.g. galvanically isolated power supply SELV or PELV).
- Always note the regulations applicable in your country to the operation, maintenance and repair of electrical devices. Special instructions relating to the device can be found in the relevant sections of the documentation.

1.3 Operational safety

Note the following points:

- Measuring systems for use in hazardous environments are accompanied by separate "Ex documentation", which is an integral part of these Operating Instructions. Strict compliance with the installation instructions and ratings as stated in this supplementary documentation is mandatory. Depending on the approval and certification agency, the relevant symbol is depicted on the front page of the supplementary documentation on Ex ratings (e.g.  Europe,  USA,  Canada).
- The measuring device meets the general safety requirements according to EN 61010-1 and the EMC requirements according to IEC/EN 61326 in addition to the NAMUR recommendations NE 21, NE 43 and NE 53.

- Depending on the application, the seals of the process connections of the Promag H sensor require periodic replacement.
- When hot fluid passes through the measuring tube, the surface temperature of the housing increases. In the case of the sensor, in particular, users should expect temperatures that can be close to the fluid temperature. If the temperature of the fluid is high, implement sufficient measures to prevent burning or scalding.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser distributor will supply you with current information and updates to these Operating Instructions.

1.4 Return

The measuring device must be returned if repairs or a factory calibration are required, or if the wrong measuring device has been ordered or delivered. According to legal regulations, Endress+Hauser, as an ISO-certified company, is required to follow certain procedures when handling returned products that are in contact with medium.

To ensure swift, safe and professional device returns, please read the return procedures and conditions on the Endress+Hauser website at www.services.endress.com/return-material

1.5 Notes on safety conventions and icons

The devices are designed and tested to meet state-of-the-art safety requirements, and have left the factory in a condition in which they are safe to operate. The devices comply with the applicable standards and regulations in accordance with EN 61010 - 1 "Protection Measures for Electrical Equipment for Measurement, Control, Regulation and Laboratory Procedures". The devices can, however, be a source of danger if used incorrectly or for other than the designated use.

For this reason, always pay particular attention to the safety instructions indicated in these Operating Instructions by the following icons:



Warning!

"Warning" indicates an action or procedure which, if not performed correctly, can result in personal injury or a safety hazard. Comply strictly with the instructions and proceed with care.



Caution!

"Caution" indicates an action or procedure which, if not performed correctly, can result in incorrect operation or destruction of the device. Comply strictly with the instructions.



Note!

"Note" indicates an action or procedure which, if not performed correctly, can have an indirect effect on operation or trigger an unexpected response on the part of the device.

2 Identification

2.1 Device designation

The flow measuring system consists of the following components:

- Promag 53 transmitter
- Promag E/H/L/P/W sensors

Two versions are available:

- Compact version: transmitter and sensor form a single mechanical unit.
- Remote version: transmitter and sensor are installed separately.

2.1.1 Nameplate of the transmitter




Fig. 1: Nameplate specifications for the "Promag 53" transmitter (example)

- 1 Order code/serial number: See the specifications on the order confirmation for the meanings of the individual letters and digits
- 2 Power supply/frequency/power consumption
- 3 Additional functions and software
 - EPD: with empty pipe detection electrode
 - ECC: with electrode cleaning
- 4 Available outputs:
 - I-OUT (HART): with current output (HART)
 - f-OUT: with pulse/frequency output
 - RELAY: with relay output
 - STATUS-IN: with status input (auxiliary input)
 - I-IN: with current input
- 5 Reserved for additional information on special products
- 6 Please comply with the Operating Instructions
- 7 Reserved for additional information on device version (approvals, certificates)
- 8 Permitted ambient temperature range
- 9 Degree of protection

2.1.2 Nameplate of the sensor




Fig. 2: Nameplate specifications for the "Promag W" sensor (example)

- 1 Order code/serial number: See the specifications on the order confirmation for the meanings of the individual letters and digits
- 2 Calibration factor with zero point
- 3 Nominal diameter/nominal pressure
- 4 Medium temperature range
- 5 Materials: lining/measuring electrode
- 6 Reserved for additional information on special products
- 7 Permitted ambient temperature range
- 8 Please comply with the Operating Instructions
- 9 Reserved for additional information on device version (approvals, certificates)
- 10 Calibration tolerance
- 11 Additional information
 - EPD: with empty pipe detection electrode
 - R/B: with reference electrode
- 12 Degree of protection
- 13 Flow direction

2.1.3 Nameplate for connections




Fig. 3: Nameplate specifications for Proline transmitter connections (example)

- 1 Serial number
- 2 Possible configuration of current output
- 3 Possible configuration of relay contacts
- 4 Terminal assignment, cable for power supply
 - Terminal no. 1:
 - L1 for AC, L+ for DC
 - Terminal no. 2:
 - N for AC, L- for DC
- 5 Signals present at inputs and outputs, possible configurations and terminal assignment
- 6 Version of device software currently installed (incl. language group)
- 7 Type of communication installed
- 8 Information on current communication software (Device Revision, Device Description)
- 9 Date of installation
- 10 Current updates to data specified in points 6 to 9

2.2 Certificates and approvals

The devices are designed and tested to meet state-of-the-art safety requirements in accordance with sound engineering practice. They have left the factory in a condition in which they are safe to operate. The devices comply with the standards EN 61010 -1 "Protection Measures for Electrical Equipment for Measurement, Control, Regulation and Laboratory Procedures" and with the EMC requirements of IEC/EN 61326. The measuring system described in these Operating Instructions therefore complies with the legal requirements of the EU Directives. Endress+Hauser confirms this by affixing the CE mark to it and by issuing the CE Declaration of Conformity. The measuring system is in conformity with the EMC requirements of the "Australian Communications and Media Authority (ACMA)".

2.3 Registered trademarks

HART®

Registered trademark of HART Communication Foundation, Austin, USA

TRI-CLAMP®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

KALREZ® and VITON®

Registered trademarks of E.I. Du Pont de Nemours & Co., Wilmington, USA

HistoROM™, S-DAT®, T-DAT™, F-CHIP®, Field Xpert™, FieldCare®, Fieldcheck®, Applicator®

Registered or registration-pending trademarks of Endress+Hauser Flowtec AG, Reinach, CH

3 Installation

3.1 Incoming acceptance, transport and storage

3.1.1 Incoming acceptance

On receipt of the goods, check the following points:

- Check the packaging and the contents for damage.
- Check the shipment, make sure nothing is missing and that the scope of supply matches your order.

3.1.2 Transport

The following instructions apply to unpacking and to transporting the device to its final location:

- Transport the devices in the containers in which they are delivered.
- Do not remove the protection plates or caps on the process connections until you are ready to install the device. This is particularly important in the case of sensors with PTFE linings.

Special notes on flanged devices



Caution!

- The wooden covers mounted on the flanges before the device leaves the factory protect the linings on the flanges during storage and transportation. Do not remove these protection plates until *immediately before* the device is installed in the pipe.
- Do not lift flanged devices by the transmitter housing or, in the case of the remote version, by the connection housing.


Transporting flanged devices DN ≤ 300 (12")

Use webbing slings slung round the two process connections. Do not use chains, as they could damage the housing.



Warning!

Risk of injury if the measuring device slips. The center of gravity of the assembled measuring device might be higher than the points around which the slings are slung. At all times, therefore, make sure that the device does not unexpectedly turn around its axis or slip.



a0004294

Fig. 4: Transporting sensors with DN ≤ 300 (12")


Transporting flanged devices DN > 300 (12")

Use only the metal eyes on the flanges for transporting the device, lifting it and positioning the sensor in the piping.



Caution!

Do not attempt to lift the sensor with the tines of a fork-lift truck beneath the metal casing. This would buckle the casing and damage the internal magnetic coils.



a0004295

Fig. 5: *Transporting sensors with DN > 300 (12")*

3.1.3 Storage

Note the following points:

- Pack the measuring device in such a way as to protect it reliably against impact for storage (and transportation). The original packaging provides optimum protection.
- The storage temperature corresponds to the operating temperature range of the measuring transmitter and the appropriate measuring sensors → 126.
- The measuring device must be protected against direct sunlight during storage in order to avoid unacceptably high surface temperatures.
- Choose a storage location where moisture does not collect in the measuring device. This will help prevent fungus and bacteria infestation which can damage the lining.
- Do not remove the protection plates or caps on the process connections until you are ready to install the device. This is particularly important in the case of sensors with PTFE linings.

3.2 Installation conditions

3.2.1 Dimensions

The dimensions and installation lengths of the sensor and transmitter can be found in the "Technical Information" for the device in question. This document can be downloaded as a PDF file from www.endress.com. A list of the "Technical Information" documents available is provided in the "Documentation" section on → 149.

3.2.2 Mounting location

The accumulation of air or gas bubbles in the measuring tube could result in an increase in measuring errors.

Avoid the following locations:

- At the highest point of a pipeline. Risk of air accumulating.
- Directly upstream from a free pipe outlet in a vertical pipeline.




Fig. 6: Mounting location

Installing pumps

Do not install the sensor on the intake side of a pump. This precaution is to avoid low pressure and the consequent risk of damage to the lining of the measuring tube. Information on the lining's resistance to partial vacuum → 130.

It might be necessary to install pulse dampers in systems incorporating reciprocating, diaphragm or peristaltic pumps. Information on the measuring system's resistance to vibration and shock → 126.




Fig. 7: Installing pumps


Partially filled pipes

Partially filled pipes with gradients necessitate a drain-type configuration. The Empty Pipe Detection function offers additional protection by detecting empty or partially filled pipes → [97](#).



Caution!

Risk of solids accumulating. Do not install the sensor at the lowest point in the drain. It is advisable to install a cleaning valve.




A0011901

Fig. 8: Installation in partially filled pipe

Down pipes

Install a siphon or a vent valve downstream of the sensor in down pipes longer than 5 m (16,3 ft). This precaution is to avoid low pressure and the consequent risk of damage to the lining of the measuring tube. This measure also prevents the system losing prime, which could cause air inclusions.

Information on the lining's resistance to partial vacuum → [130](#)



A0011902

Fig. 9: Measures for installation in a down pipe

1 Vent valve

2 Siphon

h Length of down pipe ($h \geq 5 \text{ m (16,3 ft)}$)

3.2.3 Orientation


An optimum orientation position helps avoid gas and air accumulations and deposits in the measuring tube. Promag, nevertheless, supplies a range of functions and accessories for correct measuring of problematic fluids:

- Electrode Cleaning Circuitry (ECC) to prevent electrically conductive deposits in the measuring tube, e.g. for fluids causing buildup (see "Description of Device Functions" manual).
- Empty Pipe Detection (EPD) ensures the detection of partially filled measuring tubes or in the case of degassing fluids → 97.

Vertical orientation

A vertical orientation is ideal in the following cases:

- For self-emptying piping systems and when using empty pipe detection.
- For sludge containing sand or stones and where the solids cause sedimentation.



A0011903

Fig. 10: Vertical orientation


Horizontal orientation

The measuring electrode plane should be horizontal. This prevents brief insulation of the two electrodes by entrained air bubbles.



Caution!

Empty Pipe Detection functions correctly with the measuring device installed horizontally only when the transmitter housing is facing upward (see diagram). Otherwise there is no guarantee that Empty Pipe Detection will respond if the measuring tube is only partially filled.



A0011904

Fig. 11: Horizontal orientation

- 1 EPD electrode for empty pipe detection
(not available for "measuring electrode only" option, not in Promag H, DN 2 to 15 / 1/12 to 1/2")
- 2 Measuring electrodes for signal detection
- 3 Reference electrode for potential equalization
(not available for "measuring electrode only" option, not in Promag H)

3.2.4 Inlet and outlet runs

If possible, install the sensor in a location upstream of fittings such as valves, T-pieces, elbows, etc.

Compliance with the following requirements for the inlet and outlet runs is necessary in order to ensure measuring accuracy.

- Inlet run $\geq 5 \times \text{DN}$
- Outlet run $\geq 2 \times \text{DN}$




Fig. 12: Inlet and outlet runs

3.2.5 Vibrations

Secure and fix both the piping and the sensor if the vibrations are severe.



Caution!

It is advisable to install sensor and transmitter separately if vibration is excessively severe. Information on the permitted resistance to vibration and shock → 126.




Fig. 13: Measures to prevent vibration of the measuring device ($L > 10 \text{ m} / 33 \text{ ft}$)

3.2.6 Foundations, supports


If the nominal diameter is $DN \geq 350$ (14"), mount the sensor on a foundation of adequate load-bearing strength.



Caution!

Risk of damage.

Do not support the weight of the sensor on the metal casing: the casing would buckle and damage the internal magnetic coils.



a0003209

Fig. 14: Correct support for large nominal diameters ($DN \geq 350$ / 14")

3.2.7 Adapters

Suitable adapters to DIN EN 545 (double-flange reducers) can be used to install the sensor in larger-diameter pipes. The resultant increase in the rate of flow improves measuring accuracy with very slow-moving fluids.


The nomogram shown here can be used to calculate the pressure loss caused by cross-section reduction.



Note!

The nomogram only applies to liquids of viscosity similar to water.

1. Calculate the ratio of the diameters d/D .
2. From the nomogram, read off the pressure loss as a function of fluid velocity (*downstream* from the reduction) and the d/D ratio.



A0011907

Fig. 15: Pressure loss due to adapters

3.2.8 Nominal diameter and flow rate

The diameter of the pipe and the flow rate determine the nominal diameter of the sensor. The optimum velocity of flow is between 2 and 3 m/s (6.5 to 9.8 ft/s)

The velocity of flow (v), moreover, has to be matched to the physical properties of the fluid:

- $v < 2$ m/s ($v < 6.5$ ft/s): for abrasive fluids
- $v > 2$ m/s ($v > 6.5$ ft/s): for fluids producing buildup



Note!

Flow velocity can be increased, if necessary, by reducing the nominal diameter of the sensor (→ 16).

Recommended flow (SI units)

Nominal diameter [mm]	Promag E/P	Promag H	Promag L	Promag W
	Min./max. full scale value ($v \approx 0.3$ or 10 m/s) in [dm ³ /min]			
2	–	0.06 to 1.8	–	–
4	–	0.25 to 7	–	–
8	–	1 to 30	–	–
15	4 to 100	4 to 100	–	–
25	9 to 300	9 to 300	9 to 300	9 to 300
32	15 to 500	–	15 to 500	15 to 500
40	25 to 700	25 to 700	25 to 700	25 to 700
50	35 to 1100	35 to 1100	35 to 1100	35 to 1100
65	60 to 2000	60 to 2000	60 to 2000	60 to 2000
80	90 to 3000	90 to 3000	90 to 3000	90 to 3000
100	145 to 4700	145 to 4700	145 to 4700	145 to 4700
125	220 to 7500	220 to 7500	220 to 7500	220 to 7500
[mm]	Min./max. full scale value ($v \approx 0.3$ or 10 m/s) in [m ³ /h]			
150	20 to 600	20 to 600	20 to 600	20 to 600
200	35 to 1100	–	35 to 1100	35 to 1100
250	55 to 1700	–	55 to 1700	55 to 1700
300	80 to 2400	–	80 to 2400	80 to 2400
350	110 to 3300	–	110 to 3300	110 to 3300
375	–	–	140 to 4200	140 to 4200
400	140 to 4200	–	140 to 4200	140 to 4200
450	180 to 5400	–	180 to 5400	180 to 5400
500	220 to 6600	–	220 to 6600	220 to 6600
600	310 to 9600	–	310 to 9600	310 to 9600
700	–	–	420 to 13500	420 to 13500
800	–	–	550 to 18000	550 to 18000
900	–	–	690 to 22500	690 to 22500
1000	–	–	850 to 28000	850 to 28000
1200	–	–	1250 to 40000	1250 to 40000
1400	–	–	–	1700 to 55000
1600	–	–	–	2200 to 70000
1800	–	–	–	2800 to 90000
2000	–	–	–	3400 to 110000

Recommended flow (US units)

Nominal diameter [inch]	Promag E/P	Promag H	Promag L	Promag W
	Min./max. full scale value ($v \approx 0.3$ or 10 m/s) in [gal/min]			
1/12"	–	0.015 to 0.5	–	–
1/8"	–	0.07 to 2	–	–
3/8"	–	0.25 to 8	–	–
1/2"	1.0 to 27	1.0 to 27	–	–
1"	2.5 to 80	2.5 to 80	2.5 to 80	2.5 to 80
1 1/4"	4 to 130	–	–	4 to 130
1 1/2"	7 to 190	7 to 190	7 to 190	7 to 190
2"	10 to 300	10 to 300	10 to 300	10 to 300
2 1/2"	16 to 500	16 to 500	16 to 500	16 to 500
3"	24 to 800	24 to 800	24 to 800	24 to 800
4"	40 to 1250	40 to 1250	40 to 1250	40 to 1250
5"	60 to 1950	60 to 1950	60 to 1950	60 to 1950
6"	90 to 2650	90 to 2650	90 to 2650	90 to 2650
8"	155 to 4850	–	155 to 4850	155 to 4850
10"	250 to 7500	–	250 to 7500	250 to 7500
12"	350 to 10600	–	350 to 10600	350 to 10600
14"	500 to 15000	–	500 to 15000	500 to 15000
15"	–	–	600 to 19000	600 to 19000
16"	600 to 19000	–	600 to 19000	600 to 19000
18"	800 to 24000	–	800 to 24000	800 to 24000
20"	1000 to 30000	–	1000 to 30000	1000 to 30000
24"	1400 to 44000	–	1400 to 44000	1400 to 44000
28"	–	–	1900 to 60000	1900 to 60000
30"	–	–	2150 to 67000	2150 to 67000
32"	–	–	2450 to 80000	2450 to 80000
36"	–	–	3100 to 100000	3100 to 100000
40"	–	–	3800 to 125000	3800 to 125000
42"	–	–	4200 to 135000	4200 to 135000
48"	–	–	5500 to 175000	5500 to 175000
[inch]	Min./max. full scale value ($v \approx 0.3$ or 10 m/s) in [Mgal/d]			
54"	–	–	–	9 to 300
60"	–	–	–	12 to 380
66"	–	–	–	14 to 500
72"	–	–	–	16 to 570
78"	–	–	–	18 to 650

3.2.9 Length of connecting cable

In order to ensure measuring accuracy, please comply with the following instructions when installing the remote version:

- Secure the cable run or route the cable in an armored conduit. Movement of the cable can falsify the measuring signal, particularly if the fluid conductivity is low.
- Route the cable well clear of electrical machines and switching elements.
- Ensure potential equalization between sensor and transmitter, if necessary.
- The permissible cable length L_{max} depends on the fluid conductivity (\rightarrow Fig. 16).
- The maximum connecting cable length is 10 m (32.8 ft) when empty pipe detection (EPD \rightarrow 97) is switched on.




Fig. 16: Permitted lengths for connecting cable in remote version, as a function of the conductivity of the fluid

Gray shaded area = permissible range
 L_{max} = length of connecting cable

a0010734

3.3 Installation

3.3.1 Installing the Promag E sensor



Caution!

- The protective covers mounted on the two sensor flanges guard the PTFE lining, which is turned over the flanges. Consequently, do not remove these protection plates **until immediately before** the sensor is installed in the pipe.
- Protection plates must remain in place while the device is in storage.
- Make sure that the lining is not damaged or removed from the flanges.




Note!

Bolts, nuts, seals, etc. are not included in the scope of supply and must be supplied by the customer.

The sensor is designed for installation between the two piping flanges:

- It is essential that you observe the necessary screw tightening torques on → 31.
- If grounding disks are used, follow the mounting instructions which will be enclosed with the shipment.



A0011908

Fig. 17: *Installing the Promag E sensor*

Seals

Comply with the following instructions when installing seals:

- PFA or PTFE lining → seals are **not** required.
- Only use seals that comply with DIN EN 1514-1 for DIN flanges.
- Make sure that the seals do not protrude into the piping cross-section.



Caution!

Risk of short circuit! Do not use electrically conductive sealing compound such as graphite. An electrically conductive layer could form on the inside of the measuring tube and short-circuit the measuring signal.

Ground cable

- If necessary, special ground cables can be ordered as accessories for potential equalization, → 100.
- For information on potential equalization and detailed installation instructions for using ground cables, please refer to → 55.

Screw tightening torques (Promag E)

Note the following points:

- The tightening torques listed below are for lubricated threads only.
- Always tighten the screws uniformly and in diagonally opposite sequence.
- Overtightening the screws will deform the sealing faces or damage the seals.
- The tightening torques listed below apply only to pipes not subjected to tensile stress.

Tightening torques for:

- EN (DIN) → 21
- ASME → 22
- JIS → 22

Promag E tightening torques for EN (DIN)

Nominal diameter [mm]	EN (DIN) Pressure rating [bar]	Threaded fasteners	Max. tightening torque [Nm]
15	PN 40	4 × M 12	11
25	PN 40	4 × M 12	26
32	PN 40	4 × M 16	41
40	PN 40	4 × M 16	52
50	PN 40	4 × M 16	65
65 *	PN 16	8 × M 16	43
80	PN 16	8 × M 16	53
100	PN 16	8 × M 16	57
125	PN 16	8 × M 16	75
150	PN 16	8 × M 20	99
200	PN 10	8 × M 20	141
200	PN 16	12 × M 20	94
250	PN 10	12 × M 20	110
250	PN 16	12 × M 24	131
300	PN 10	12 × M 20	125
300	PN 16	12 × M 24	179
350	PN 6	12 × M 20	200
350	PN 10	16 × M 20	188
350	PN 16	16 × M 24	254
400	PN 6	16 × M 20	166
400	PN 10	16 × M 24	260
400	PN 16	16 × M 27	330
450	PN 6	16 × M 20	202
450	PN 10	20 × M 24	235
450	PN 16	20 × M 27	300
500	PN 6	20 × M 20	176
500	PN 10	20 × M 24	265
500	PN 16	20 × M 30	448
600	PN 6	20 × M 24	242
600	PN 10	20 × M 27	345
600 *	PN 16	20 × M 33	658

* Designed acc. to EN 1092-1 (not to DIN 2501)

Promag E tightening torques for ASME

Nominal diameter [mm]	Nominal diameter [inch]	ASME Pressure rating [lbs]	Threaded fasteners	Max. tightening torque	
				PTFE [Nm]	PTFE [lbf · ft]
15	1/2"	Class 150	4 × 1/2"	6	4
25	1"	Class 150	4 × 1/2"	11	8
40	1 1/2"	Class 150	4 × 1/2"	24	18
50	2"	Class 150	4 × 5/8"	47	35
80	3"	Class 150	4 × 5/8"	79	58
100	4"	Class 150	8 × 5/8"	56	41
150	6"	Class 150	8 × 3/4"	106	78
200	8"	Class 150	8 × 3/4"	143	105
250	10"	Class 150	12 × 7/8"	135	100
300	12"	Class 150	12 × 7/8"	178	131
350	14"	Class 150	12 × 1"	260	192
400	16"	Class 150	16 × 1"	246	181
450	18"	Class 150	16 × 1 1/8"	371	274
500	20"	Class 150	20 × 1 1/8"	341	252
600	24"	Class 150	20 × 1 1/4"	477	352

Promag E tightening torques for JIS

Nominal diameter [mm]	JIS Pressure rating	Threaded fasteners	Max. tightening torque [Nm]	
			PTFE	PTFE
15	20K	4 × M 12	16	
25	20K	4 × M 16	32	
32	20K	4 × M 16	38	
40	20K	4 × M 16	41	
50	10K	4 × M 16	54	
65	10K	4 × M 16	74	
80	10K	8 × M 16	38	
100	10K	8 × M 16	47	
125	10K	8 × M 20	80	
150	10K	8 × M 20	99	
200	10K	12 × M 20	82	
250	10K	12 × M 22	133	
300	10K	16 × M 22	99	

3.3.2 Installing the Promag H sensor

The sensor is supplied, as per your order, with or without installed process connections. Installed process connections are screwed onto the sensor using 4 or 6 hexagonal-headed bolts.



Caution!

Depending on the application and the length of the pipe, the sensor must be supported or more securely mounted if necessary. Particularly when using process connections made of plastic, it is essential that the sensor be mounted securely. A wall mounting kit for this purpose can be ordered separately as an accessory from Endress+Hauser (→ 100).




Fig. 18: Promag H process connections; DN 2 to 25 (1/12 to 1"), DN 40 to 150 (1 1/2 to 6")

A = DN 2 to 25 (1/12 to 1") / Process connections with O-ring

Weld nipple (DIN EN ISO 1127, ODT / SMS), flange (EN (DIN), ASME, JIS), flange made of PVDF (EN (DIN), ASME, JIS), external thread, internal thread, hose connection, PVC adhesive fitting

B = DN 2 to 25 (1/12 to 1") / Process connections with aseptic molded seal

Weld nipple (DIN 11850, ODT/SMS), clamp (ISO 2852, DIN 32676, L14 AM7), coupling (DIN 11851, DIN 11864-1, SMS 1145), flange DIN 11864-2

C = DN 40 to 150 (1 1/2 to 6") / Process connections with aseptic molded seal

Weld nipple (DIN 11850, ODT/SMS, ASME BPE, ISO 2037), clamp (ISO 2852, DIN 32676, L14 AM7), coupling (DIN 11851, DIN 11864-1, ISO 2853, SMS 1145), flange DIN 11864-2

Seals

When mounting the process connections, please ensure that the relevant seals are clean and properly centered.



Caution!

- In the case of metallic process connections, the screws must be fully tightened. The process connection forms a metallic connection with the sensor, which ensures a defined compression of the seal.
- In the case of process connections made of plastic, the maximum screw tightening torques for lubricated threads (7 Nm / 5.2 lbf ft) must be adhered to. In the case of plastic flanges, a seal must always be used between the connection and the counterflange.
- Depending on the application, the seals should be replaced periodically, particularly when molded seals (aseptic version) are used!

The interval between replacements depends on the frequency of the cleaning cycles and on the temperatures of the fluid and the cleaning process. Replacement seals can be ordered as an accessory at a later stage → 100.

Using and installing grounding rings (DN 2 to 25 / 1/12 to 1")

In case the process connections are made of plastic (e.g. flanges or adhesive fittings), the potential between the sensor and the fluid must be equalised using additional ground rings. If the ground rings are not installed this can affect the accuracy of the measurements or cause the destruction of the sensor through the galvanic corrosion of the electrodes.



Caution!

- Depending on the option ordered, plastic rings may be installed at the process connections instead of ground rings. These plastic rings serve only as spacers and have no potential equalization function. In addition, they provide a sealing function at the interface between the sensor and process connection. For this reason, with process connections without ground rings, these plastic rings/seals must not be removed, or must always be installed.
- Ground rings can be ordered separately from Endress+Hauser as accessories → 100. When placing the order, make certain that the ground ring is compatible with the material used for the electrodes. Otherwise, there is a risk that the electrodes may be destroyed by galvanic corrosion! Information about the materials can be found on → 142.
- Ground rings, including the seals, are mounted within the process connections. Therefore, the fitting length is not affected.

1. Loosen the four or six hexagonal headed bolts (1) and remove the process connection from the sensor (4).
2. Remove the plastic ring (3), including the two O-ring seals (2).
3. Place one seal (2) in the groove of the process connection.
4. Place the metal ground ring (3) on the process connection.
5. Now place the second seal (2) in the groove of the ground ring.
6. Finally, mount the process connection on the sensor again. With plastic process connections, note the max. torques for lubricated threads (7 Nm / 5.2 lbf ft).




Fig. 19: Installing grounding rings in the Promag H (DN 2 to 25 / 1/12 to 1")

- 1 = Hexagonal-headed bolts, process connection
- 2 = O-ring seals
- 3 = Grounding ring or plastic ring (spacer)
- 4 = Sensor

Welding the transmitter into the pipe (weld nipple)



Caution!

Risk of electronics being destroyed. Please ensure that the welding system is *not* grounded via the sensor or transmitter.

1. Secure the sensor using several welding points in the piping. A welding jig suitable for this purpose can be ordered separately as an accessory → 100.
2. Loosen the screws at the process connection flange, and remove the sensor incl. seal from the piping.
3. Weld the process connection into the pipe.
4. Mount the sensor back into the pipe. When doing so, make sure that the seal is clean and positioned correctly.



Note!

- If the welding is done properly with thin-walled food pipes, the seal will not be damaged by heat even when mounted. Nonetheless, it is recommended that you dismantle the sensor and seal.
- For dismantling purposes, it must be possible to open the piping a total of approx. 8 mm.

Cleaning using pigs

When cleaning using pigs, please note the internal diameters of the measuring tube and the process connection. All the dimensions and lengths of the sensor and transmitter are provided in the separate documentation "Technical Information" → 149.

3.3.3 Installing the Promag L sensor



Caution!

- The protective covers mounted on the two sensor flanges (DN 25 to 300 / 1 to 12") are used to hold the lap joint flanges in place and to protect the PTFE liner during transportation. Consequently, do not remove these covers until immediately before the sensor is installed in the pipe.
- The covers must remain in place while the device is in storage.
- Make sure that the lining is not damaged or removed from the flanges.



Note!

Bolts, nuts, seals, etc. are not included in the scope of supply and must be supplied by the customer.

The sensor is designed for installation between the two piping flanges.

- Observe in any case the necessary screw tightening torques on → 27
- If grounding disks are used, follow the mounting instructions which will be enclosed with the shipment
- To comply with the device specification, a concentrical installation in the measuring section is required




Fig. 20: *Installing the Promag L sensor*

Seals

Comply with the following instructions when installing seals:

- Hard rubber lining → additional seals are **always** necessary.
- Polyurethane lining → **no** seals are required.
- PTFE lining → **no** seals are required.
- For DIN flanges, use only seals according to EN 1514-1.
- Make sure that the seals do not protrude into the piping cross-section.



Caution!

Risk of short circuit!

Do not use electrically conductive sealing compounds such as graphite! An electrically conductive layer could form on the inside of the measuring tube and short-circuit the measuring signal.

Ground cable

- If necessary, special ground cables for potential equalization can be ordered as an accessory (→ 100).
- Information on potential equalization and detailed mounting instructions for the use of ground cables can be found on → 55.

Screw tightening torques (Promag L)

Please note the following:

- The tightening torques listed below are for lubricated threads only.
- Always tighten the screws uniformly and in diagonally opposite sequence.
- Overtightening the screws will deform the sealing faces or damage the seals.
- The tightening torques listed below apply only to pipes not subjected to tensile stress.

Promag L tightening torques for EN (DIN)

Nominal diameter [mm]	EN (DIN) Pressure rating [bar]	Threaded fas- teners	Max. tightening torque		
			Hard rubber [Nm]	Polyurethane [Nm]	PTFE [Nm]
25	PN 10/16	4 × M 12	-	6	11
32	PN 10/16	4 × M 16	-	16	27
40	PN 10/16	4 × M 16	-	16	29
50	PN 10/16	4 × M 16	-	15	40
65*	PN 10/16	8 × M 16	-	10	22
80	PN 10/16	8 × M 16	-	15	30
100	PN 10/16	8 × M 16	-	20	42
125	PN 10/16	8 × M 16	-	30	55
150	PN 10/16	8 × M 20	-	50	90
200	PN 16	12 × M 20	-	65	87
250	PN 16	12 × M 24	-	126	151
300	PN 16	12 × M 24	-	139	177
350	PN 6	12 × M 20	111	120	-
350	PN 10	16 × M 20	112	118	-
400	PN 6	16 × M 20	90	98	-
400	PN 10	16 × M 24	151	167	-
450	PN 6	16 × M 20	112	126	-
450	PN 10	20 × M 24	153	133	-
500	PN 6	20 × M 20	119	123	-
500	PN 10	20 × M 24	155	171	-
600	PN 6	20 × M 24	139	147	-
600	PN 10	20 × M 27	206	219	-
700	PN 6	24 × M 24	148	139	-
700	PN 10	24 × M 27	246	246	-
800	PN 6	24 × M 27	206	182	-
800	PN 10	24 × M 30	331	316	-
900	PN 6	24 × M 27	230	637	-
900	PN 10	28 × M 30	316	307	-
1000	PN 6	28 × M 27	218	208	-
1000	PN 10	28 × M 33	402	405	-
1200	PN 6	32 × M 30	319	299	-
1200	PN 10	32 × M 36	564	568	-

* Designed acc. to EN 1092-1 (not to DIN 2501)

Promag L tightening torques for ASME

Nominal diameter [mm] [inch]		ASME Pressure rating [lbs]	Threaded fasteners	Max. tightening torque			
				Hard rubber		Polyurethane	
[Nm]	[lbf · ft]	[Nm]	[lbf · ft]	[Nm]	[lbf · ft]	[Nm]	[lbf · ft]
25	1"	Class 150	4 × 5/8"	-	-	5	4
40	1 1/2"	Class 150	8 × 5/8"	-	-	10	17
50	2"	Class 150	4 × 5/8"	-	-	15	11
80	3"	Class 150	4 × 5/8"	-	-	25	18
100	4"	Class 150	8 × 5/8"	-	-	20	15
150	6"	Class 150	8 × 3/4"	-	-	45	33
200	8"	Class 150	8 × 3/4"	-	-	65	48
250	10"	Class 150	12 × 7/8"	-	-	126	93
300	12"	Class 150	12 × 7/8"	-	-	146	108
350	14"	Class 150	12 × 1"	135	100	158	117
400	16"	Class 150	16 × 1"	128	94	150	111
450	18"	Class 150	16 × 1 1/8"	204	150	234	173
500	20"	Class 150	20 × 1 1/8"	183	135	217	160
600	24"	Class 150	20 × 1 1/4"	268	198	307	226

Promag L tightening torques for AWWA

Nominal diameter [mm] [inch]		AWWA Pressure rating	Threaded fasteners	Max. tightening torque			
				Hartgummi		Polyurethane	
[Nm]	[lbf · ft]	[Nm]	[lbf · ft]	[Nm]	[lbf · ft]	[Nm]	[lbf · ft]
700	28"	Class D	28 × 1 1/4"	247	182	292	215
750	30"	Class D	28 × 1 1/4"	287	212	302	223
800	32"	Class D	28 × 1 1/2"	394	291	422	311
900	36"	Class D	32 × 1 1/2"	419	309	430	317
1000	40"	Class D	36 × 1 1/2"	420	310	477	352
1050	42"	Class D	36 × 1 1/2"	528	389	518	382
1200	48"	Class D	44 × 1 1/2"	552	407	531	392

Promag L tightening torques for AS 2129

Nominal diameter [mm]	AS 2129 Pressure rating	Threaded fasteners	Max. tightening torque		
			Hard rubber [Nm]	Polyurethane [Nm]	PTFE [Nm]
350	Table E	12 × M 24	203	-	-
400	Table E	12 × M 24	226	-	-
450	Table E	16 × M 24	226	-	-
500	Table E	16 × M 24	271	-	-
600	Table E	16 × M 30	439	-	-
700	Table E	20 × M 30	355	-	-
750	Table E	20 × M 30	559	-	-
800	Table E	20 × M 30	631	-	-
900	Table E	24 × M 30	627	-	-
1000	Table E	24 × M 30	634	-	-
1200	Table E	32 × M 30	727	-	-

Promag L tightening torques for AS 4087

Nominal dia- meter [mm]	AS 4087 Pressure rating	Threaded fasteners	Max. tightening torque		
			Hard rubber [Nm]	Polyurethane [Nm]	PTFE [Nm]
350	PN 16	12 × M 24	203	-	-
375	PN 16	12 × M 24	137	-	-
400	PN 16	12 × M 24	226	-	-
450	PN 16	12 × M 24	301	-	-
500	PN 16	16 × M 24	271	-	-
600	PN 16	16 × M 27	393	-	-
700	PN 16	20 × M 27	330	-	-
750	PN 16	20 × M 30	529	-	-
800	PN 16	20 × M 33	631	-	-
900	PN 16	24 × M 33	627	-	-
1000	PN 16	24 × M 33	595	-	-
1200	PN 16	32 × M 33	703	-	-

3.3.4 Installing the Promag P sensor



Caution!

- The protective covers mounted on the two sensor flanges guard the PTFE lining, which is turned over the flanges. Consequently, do not remove these protection plates **until immediately before** the sensor is installed in the pipe.
- Protection plates must remain in place while the device is in storage.
- Make sure that the lining is not damaged or removed from the flanges.



Note!

Bolts, nuts, seals, etc. are not included in the scope of supply and must be supplied by the customer.

The sensor is designed for installation between the two piping flanges:

- It is essential that you observe the necessary screw tightening torques on → 31.
- If grounding disks are used, follow the mounting instructions which will be enclosed with the shipment.




Fig. 21: *Installing the Promag P sensor*

Seals

Comply with the following instructions when installing seals:

- PFA or PTFE lining → seals are **not** required.
- Only use seals that comply with DIN EN 1514-1 for DIN flanges.
- Make sure that the seals do not protrude into the piping cross-section.



Caution!

Risk of short circuit! Do not use electrically conductive sealing compound such as graphite. An electrically conductive layer could form on the inside of the measuring tube and short-circuit the measuring signal.

Ground cable

- If necessary, special ground cables can be ordered as accessories for potential equalization, → 100.
- For information on potential equalization and detailed installation instructions for using ground cables, please refer to → 55.

Installing the high-temperature version (with PFA lining)

The high-temperature version has a housing support for the thermal separation of sensor and transmitter. The high-temperature version is always used for applications in which high ambient temperatures are encountered in conjunction with high fluid temperatures. The high-temperature version is obligatory if the fluid temperature exceeds +150 °C (+300 °F).



Note!

You will find information on permissible temperature ranges on → 127.


Insulation

Pipes generally have to be insulated if they carry very hot fluids to avoid energy losses and prevent accidental contact with pipes at temperatures that could cause injury. Guidelines regulating the insulation of pipes have to be taken into account.



Caution!

Risk of electronics overheating. The housing support dissipates heat and its entire surface area must remain uncovered. Make sure that the sensor insulation does not extend past the top of the two sensor half-shells.



a0004300

Fig. 22: Promag P sensor (high-temperature version): insulating the pipe

Screw tightening torques (Promag P)

Note the following points:

- The tightening torques listed below are for lubricated threads only.
- Always tighten the screws uniformly and in diagonally opposite sequence.
- Overtightening the screws will deform the sealing faces or damage the seals.
- The tightening torques listed below apply only to pipes not subjected to tensile stress.

Tightening torques for:

- EN (DIN) → 32
- ASME → 33
- JIS → 33
- AS 2129 → 34
- AS 4087 → 34

Promag P tightening torques for EN (DIN)

Nominal diameter [mm]	EN (DIN) Pressure rating [bar]	Screws	Max. tightening torque [Nm]	
			PTFE	PFA
15	PN 40	4 × M 12	11	-
25	PN 40	4 × M 12	26	20
32	PN 40	4 × M 16	41	35
40	PN 40	4 × M 16	52	47
50	PN 40	4 × M 16	65	59
65 *	PN 16	8 × M 16	43	40
65	PN 40	8 × M 16	43	40
80	PN 16	8 × M 16	53	48
80	PN 40	8 × M 16	53	48
100	PN 16	8 × M 16	57	51
100	PN 40	8 × M 20	78	70
125	PN 16	8 × M 16	75	67
125	PN 40	8 × M 24	111	99
150	PN 16	8 × M 20	99	85
150	PN 40	8 × M 24	136	120
200	PN 10	8 × M 20	141	101
200	PN 16	12 × M 20	94	67
200	PN 25	12 × M 24	138	105
250	PN 10	12 × M 20	110	-
250	PN 16	12 × M 24	131	-
250	PN 25	12 × M 27	200	-
300	PN 10	12 × M 20	125	-
300	PN 16	12 × M 24	179	-
300	PN 25	16 × M 27	204	-
350	PN 10	16 × M 20	188	-
350	PN 16	16 × M 24	254	-
350	PN 25	16 × M 30	380	-
400	PN 10	16 × M 24	260	-
400	PN 16	16 × M 27	330	-
400	PN 25	16 × M 33	488	-
450	PN 10	20 × M 24	235	-
450	PN 16	20 × M 27	300	-
450	PN 25	20 × M 33	385	-
500	PN 10	20 × M 24	265	-
500	PN 16	20 × M 30	448	-
500	PN 25	20 × M 33	533	-
600	PN 10	20 × M 27	345	-
600 *	PN 16	20 × M 33	658	-
600	PN 25	20 × M 36	731	-

* Designed acc. to EN 1092-1 (not to DIN 2501)

Promag P tightening torques for ASME

Nominal diameter [mm]		ASME Pressure rating [lbs]	Screws	Max. tightening torque			
				[Nm]	[lbf · ft]	[Nm]	[lbf · ft]
15	½"	Class 150	4 × ½"	6	4	–	–
15	½"	Class 300	4 × ½"	6	4	–	–
25	1"	Class 150	4 × ½"	11	8	10	7
25	1"	Class 300	4 × 5/8"	14	10	12	9
40	1 ½"	Class 150	4 × ½"	24	18	21	15
40	1 ½"	Class 300	4 × ¾"	34	25	31	23
50	2"	Class 150	4 × 5/8"	47	35	44	32
50	2"	Class 300	8 × 5/8"	23	17	22	16
80	3"	Class 150	4 × 5/8"	79	58	67	49
80	3"	Class 300	8 × ¾"	47	35	42	31
100	4"	Class 150	8 × 5/8"	56	41	50	37
100	4"	Class 300	8 × ¾"	67	49	59	44
150	6"	Class 150	8 × ¾"	106	78	86	63
150	6"	Class 300	12 × ¾"	73	54	67	49
200	8"	Class 150	8 × ¾"	143	105	109	80
250	10"	Class 150	12 × 7/8"	135	100	–	–
300	12"	Class 150	12 × 7/8"	178	131	–	–
350	14"	Class 150	12 × 1"	260	192	–	–
400	16"	Class 150	16 × 1"	246	181	–	–
450	18"	Class 150	16 × 1 1/8"	371	274	–	–
500	20"	Class 150	20 × 1 1/8"	341	252	–	–
600	24"	Class 150	20 × 1 ¼"	477	352	–	–

Promag P tightening torques for JIS

Nominal diameter [mm]	JIS Pressure rating	Screws	Max. tightening torque [Nm]	
			PTFE	PFA
15	10K	4 × M 12	16	–
15	20K	4 × M 12	16	–
25	10K	4 × M 16	32	27
25	20K	4 × M 16	32	27
32	10K	4 × M 16	38	–
32	20K	4 × M 16	38	–
40	10K	4 × M 16	41	37
40	20K	4 × M 16	41	37
50	10K	4 × M 16	54	46
50	20K	8 × M 16	27	23
65	10K	4 × M 16	74	63
65	20K	8 × M 16	37	31
80	10K	8 × M 16	38	32
80	20K	8 × M 20	57	46
100	10K	8 × M 16	47	38
100	20K	8 × M 20	75	58
125	10K	8 × M 20	80	66
125	20K	8 × M 22	121	103

Nominal diameter [mm]	JIS Pressure rating	Screws	Max. tightening torque [Nm]	
			PTFE	PFA
150	10K	8 × M 20	99	81
150	20K	12 × M 22	108	72
200	10K	12 × M 20	82	54
200	20K	12 × M 22	121	88
250	10K	12 × M 22	133	–
250	20K	12 × M 24	212	–
300	10K	16 × M 22	99	–
300	20K	16 × M 24	183	–

Promag P tightening torques for AS 2129

Nominal diameter [mm]	AS 2129 Pressure rating	Screws	Max. tightening torque [Nm] PTFE
25	Table E	4 × M 12	21
50	Table E	4 × M 16	42

Promag P tightening torques for AS 4087

Nominal diameter [mm]	AS 4087 Pressure rating	Screws	Max. tightening torque [Nm] PTFE
50	PN 16	4 × M 16	42

3.3.5 Installing the Promag W sensor



Note!

Bolts, nuts, seals, etc. are not included in the scope of supply and must be supplied by the customer.

The sensor is designed for installation between the two piping flanges:

- It is essential that you observe the necessary screw tightening torques on → [36](#).
- If grounding disks are used, follow the mounting instructions which will be enclosed with the shipment.




Fig. 23: *Installing the Promag W sensor*

Seals

Comply with the following instructions when installing seals:

- Hard rubber lining → additional seals are **always** required.
- Polyurethane lining → seals are **not** required.
- Only use seals that comply with DIN EN 1514-1 for DIN flanges.
- Make sure that the seals do not protrude into the piping cross-section.



Caution!

Risk of short circuit! Do not use electrically conductive sealing compound such as graphite. An electrically conductive layer could form on the inside of the measuring tube and short-circuit the measuring signal.

Ground cable

- If necessary, special ground cables can be ordered as accessories for potential equalization, → [100](#).
- For information on potential equalization and detailed installation instructions for using ground cables, please refer to → [55](#).

Screw tightening torques (Promag W)

Note the following points:

- The tightening torques listed below are for lubricated threads only.
- Always tighten the screws uniformly and in diagonally opposite sequence.
- Overtightening the screws will deform the sealing faces or damage the seals.
- The tightening torques listed below apply only to pipes not subjected to tensile stress.

Tightening torques for:

- EN (DIN) →  36
- JIS →  38
- ASME →  38
- AWWA →  39
- AS 2129 →  39
- AS 4087 →  40

Promag W tightening torques for EN (DIN)

Nominal diameter [mm]	EN (DIN) Pressure rating [bar]	Screws	Max. tightening torque [Nm]	
			Hard rubber	Polyurethane
25	PN 40	4 × M 12	-	15
32	PN 40	4 × M 16	-	24
40	PN 40	4 × M 16	-	31
50	PN 40	4 × M 16	48	40
65*	PN 16	8 × M 16	32	27
65	PN 40	8 × M 16	32	27
80	PN 16	8 × M 16	40	34
80	PN 40	8 × M 16	40	34
100	PN 16	8 × M 16	43	36
100	PN 40	8 × M 20	59	50
125	PN 16	8 × M 16	56	48
125	PN 40	8 × M 24	83	71
150	PN 16	8 × M 20	74	63
150	PN 40	8 × M 24	104	88
200	PN 10	8 × M 20	106	91
200	PN 16	12 × M 20	70	61
200	PN 25	12 × M 24	104	92
250	PN 10	12 × M 20	82	71
250	PN 16	12 × M 24	98	85
250	PN 25	12 × M 27	150	134
300	PN 10	12 × M 20	94	81
300	PN 16	12 × M 24	134	118
300	PN 25	16 × M 27	153	138
350	PN 6	12 × M 20	111	120
350	PN 10	16 × M 20	112	118
350	PN 16	16 × M 24	152	165
350	PN 25	16 × M 30	227	252
400	PN 6	16 × M 20	90	98
400	PN 10	16 × M 24	151	167
400	PN 16	16 × M 27	193	215
400	PN 25	16 × M 33	289	326
450	PN 6	16 × M 20	112	126
450	PN 10	20 × M 24	153	133
450	PN 16	20 × M 27	198	196
450	PN 25	20 × M 33	256	253
500	PN 6	20 × M 20	119	123
500	PN 10	20 × M 24	155	171

Nominal diameter [mm]	EN (DIN) Pressure rating [bar]	Screws	Max. tightening torque [Nm]	
			Hard rubber	Polyurethane
500	PN 16	20 × M 30	275	300
500	PN 25	20 × M 33	317	360
600	PN 6	20 × M 24	139	147
600	PN 10	20 × M 27	206	219
600 *	PN 16	20 × M 33	415	443
600	PN 25	20 × M 36	431	516
700	PN 6	24 × M 24	148	139
700	PN 10	24 × M 27	246	246
700	PN 16	24 × M 33	278	318
700	PN 25	24 × M 39	449	507
800	PN 6	24 × M 27	206	182
800	PN 10	24 × M 30	331	316
800	PN 16	24 × M 36	369	385
800	PN 25	24 × M 45	664	721
900	PN 6	24 × M 27	230	637
900	PN 10	28 × M 30	316	307
900	PN 16	28 × M 36	353	398
900	PN 25	28 × M 45	690	716
1000	PN 6	28 × M 27	218	208
1000	PN 10	28 × M 33	402	405
1000	PN 16	28 × M 39	502	518
1000	PN 25	28 × M 52	970	971
1200	PN 6	32 × M 30	319	299
1200	PN 10	32 × M 36	564	568
1200	PN 16	32 × M 45	701	753
1400	PN 6	36 × M 33	430	398
1400	PN 10	36 × M 39	654	618
1400	PN 16	36 × M 45	729	762
1600	PN 6	40 × M 33	440	417
1600	PN 10	40 × M 45	946	893
1600	PN 16	40 × M 52	1007	1100
1800	PN 6	44 × M 36	547	521
1800	PN 10	44 × M 45	961	895
1800	PN 16	44 × M 52	1108	1003
2000	PN 6	48 × M 39	629	605
2000	PN 10	48 × M 45	1047	1092
2000	PN 16	48 × M 56	1324	1261

* Designed acc. to EN 1092-1 (not to DIN 2501)

Promag W tightening torques for JIS

Sensor Nominal diameter [mm]	JIS Pressure rating	Screws	Max. tightening torque [Nm]	
			Hard rubber	Polyurethane
25	10K	4 × M 16	–	19
25	20K	4 × M 16	–	19
32	10K	4 × M 16	–	22
32	20K	4 × M 16	–	22
40	10K	4 × M 16	–	24
40	20K	4 × M 16	–	24
50	10K	4 × M 16	40	33
50	20K	8 × M 16	20	17
65	10K	4 × M 16	55	45
65	20K	8 × M 16	28	23
80	10K	8 × M 16	29	23
80	20K	8 × M 20	42	35
100	10K	8 × M 16	35	29
100	20K	8 × M 20	56	48
125	10K	8 × M 20	60	51
125	20K	8 × M 22	91	79
150	10K	8 × M 20	75	63
150	20K	12 × M 22	81	72
200	10K	12 × M 20	61	52
200	20K	12 × M 22	91	80
250	10K	12 × M 22	100	87
250	20K	12 × M 24	159	144
300	10K	16 × M 22	74	63
300	20K	16 × M 24	138	124

Promag W tightening torques for ASME

Sensor Nominal diameter [inch]	ASME Pressure rating	Screws	Max. tightening torque [Nm]	
			Hard rubber	Polyurethane
1"	Class 150	4 × 1/2"	–	7
1"	Class 300	4 × 5/8"	–	8
1 1/2"	Class 150	4 × 1/2"	–	10
1 1/2"	Class 300	4 × 3/4"	–	15
2"	Class 150	4 × 5/8"	35	22
2"	Class 300	8 × 5/8"	18	11
3"	Class 150	4 × 5/8"	60	43
3"	Class 300	8 × 3/4"	38	26
4"	Class 150	8 × 5/8"	42	31
4"	Class 300	8 × 3/4"	58	40
6"	Class 150	8 × 3/4"	79	59
6"	Class 300	12 × 3/4"	70	51
8"	Class 150	8 × 3/4"	107	80
10"	Class 150	12 × 7/8"	101	75
12"	Class 150	12 × 7/8"	133	103
14"	Class 150	12 × 1"	135	158

Sensor Nominal diameter [inch]	ASME Pressure rating [lbs]	Screws	Max. tightening torque [Nm]	
			Hard rubber	Polyurethane
16"	Class 150	16 × 1"	128	150
18"	Class 150	16 × 1 1/8"	204	234
20"	Class 150	20 × 1 1/8"	183	217
24"	Class 150	20 × 1 1/4"	268	307

Promag W tightening torques for AWWA

Sensor Nominal diameter [inch]	AWWA Pressure rating	Screws	Max. tightening torque [Nm]	
			Hard rubber	Polyurethane
28"	Class D	28 × 1 1/4"	247	292
30"	Class D	28 × 1 1/4"	287	302
32"	Class D	28 × 1 1/2"	394	422
36"	Class D	32 × 1 1/2"	419	430
40"	Class D	36 × 1 1/2"	420	477
42"	Class D	36 × 1 1/2"	528	518
48"	Class D	44 × 1 1/2"	552	531
54"	Class D	44 × 1 3/4"	730	633
60"	Class D	52 × 1 3/4"	758	832
66"	Class D	52 × 1 3/4"	946	955
72"	Class D	60 × 1 3/4"	975	1087
78"	Class D	64 × 2"	853	786

Promag W tightening torques for AS 2129

Sensor Nominal diameter [mm]	AS 2129 Pressure rating	Screws	Max. tightening torque [Nm]	
			Hard rubber	
50	Table E	4 × M 16	32	
80	Table E	4 × M 16	49	
100	Table E	8 × M 16	38	
150	Table E	8 × M 20	64	
200	Table E	8 × M 20	96	
250	Table E	12 × M 20	98	
300	Table E	12 × M 24	123	
350	Table E	12 × M 24	203	
400	Table E	12 × M 24	226	
500	Table E	16 × M 24	271	
600	Table E	16 × M 30	439	
700	Table E	20 × M 30	355	
750	Table E	20 × M 30	559	
800	Table E	20 × M 30	631	
900	Table E	24 × M 30	627	
1000	Table E	24 × M 30	634	
1200	Table E	32 × M 30	727	

Promag W tightening torques for AS 4087

Sensor Nominal diameter [mm]	AS 4087 Pressure rating	Screws	Max. tightening torque [Nm]
			Hard rubber
50	PN 16	4 × M 16	32
80	PN 16	4 × M 16	49
100 *	PN 16	8 × M 16	38
150	PN 16	8 × M 20	52
200	PN 16	8 × M 20	77
250	PN 16	8 × M 20	147
300	PN 16	12 × M 24	103
350	PN 16	12 × M 24	203
375	PN 16	12 × M 24	137
400	PN 16	12 × M 24	226
500	PN 16	16 × M 24	271
600	PN 16	16 × M 30	393
700	PN 16	20 × M 27	330
750	PN 16	20 × M 30	529
800	PN 16	20 × M 33	631
900	PN 16	24 × M 33	627
1000	PN 16	24 × M 33	595
1200	PN 16	32 × M 33	703

* Designed acc. to AS 2129 (not to AS 4087)

3.3.6 Turning the transmitter housing


Turning the aluminum field housing



Warning!

The rotating mechanism in devices with Ex d/de or FM/CSA Cl. I Div. 1 approval is different to that described here. The relevant procedure is described in the Ex-specific documentation.

1. Loosen the two securing screws.
2. Turn the bayonet catch as far as it will go.
3. Carefully lift the transmitter housing as far as it will go.
4. Turn the transmitter housing to the desired position (max. $2 \times 90^\circ$ in either direction).
5. Lower the housing into position and reengage the bayonet catch.
6. Retighten the two securing screws.




a0004302

Fig. 24: Turning the transmitter housing (aluminum field housing)

Turning the stainless steel field housing

1. Loosen the two securing screws.
2. Carefully lift the transmitter housing as far as it will go.
3. Turn the transmitter housing to the desired position (max. $2 \times 90^\circ$ in either direction).
4. Lower the housing into position once more.
5. Retighten the two securing screws.



a0004303

Fig. 25: Turning the transmitter housing (stainless steel field housing)

3.3.7 Turning the local display

1. Unscrew the electronics compartment cover from the transmitter housing.
2. Press the latches on the side of the display module and pull the module out of the electronics compartment cover.
3. Turn the display to the desired position (max. $4 \times 45^\circ$ in both directions) and position it back on the electronics compartment cover.
4. Screw the cover of the electronics compartment firmly onto the transmitter housing.




Fig. 26: Turning the local display (field housing)

3.3.8 Installing the wall-mount housing

There are various ways of installing the wall-mount housing:

- Mounted directly on the wall
- Panel mounting (with separate mounting kit, accessories) → [Fig. 44](#)
- Pipe mounting (with separate mounting kit, accessories) → [Fig. 44](#)




Caution!

- Make sure that the permitted ambient temperature range is observed (see nameplate or → [Fig. 126](#)). Install the device in a shady location. Avoid direct sunlight.
- Always install the wall-mount housing in such a way that the cable entries are pointing down.

Mounted directly on the wall

1. Drill the holes as illustrated.
2. Remove the cover of the connection compartment (a).
3. Push the two securing screws (b) through the appropriate bores (c) in the housing.
 - Securing screws (M6): max. Ø 6.5 mm (0.24")
 - Screw head: max. Ø 10.5 mm (0.4")
4. Secure the transmitter housing to the wall as indicated.
5. Screw the cover of the connection compartment (a) firmly onto the housing.



Panel mounting

1. Prepare the opening in the panel as illustrated.
2. Slide the housing into the opening in the panel from the front.
3. Screw the fasteners onto the wall-mount housing.
4. Place the threaded rods in the fasteners and screw them down until the housing is seated tightly against the panel wall. Afterwards, tighten the locking nuts.

Additional support is not necessary.




Fig. 28: Panel mounting (wall-mount housing)

Pipe mounting

The assembly should be performed by following the instructions in the following diagram.



Caution!

If the device is mounted to a warm pipe, make sure that the housing temperature does not exceed +60 °C (+140 °F), which is the maximum permissible temperature.




Fig. 29: Pipe mounting (wall-mount housing)

3.4 Post-installation check

Perform the following checks after installing the measuring device in the pipe:

Device condition/specifications	Notes
Is the device damaged (visual inspection)?	–
Does the device correspond to specifications at the measuring point, including process temperature and pressure, ambient temperature, minimum fluid conductivity, measuring range, etc.?	→  123
Installation	Notes
Does the arrow on the sensor nameplate match the direction of flow through the pipe?	–
Is the position of the measuring electrode plane correct?	→  14
Is the position of the empty pipe detection electrode correct?	→  14
Were all screws tightened to the specified tightening torques when the sensor was installed?	→  20
Were the correct seals installed (type, material, installation)?	→  35
Are the measuring point number and labeling correct (visual inspection)?	–
Process environment / process conditions	Notes
Are the inlet and outlet runs respected?	Inlet run $\geq 5 \times \text{DN}$ Outlet run $\geq 2 \times \text{DN}$
Is the measuring device protected against moisture and direct sunlight?	–
Is the sensor adequately protected against vibration (attachment, support)?	Acceleration up to 2 g in accordance with IEC 600 68-2-6 →  126

4 Wiring



Warning!

When connecting Ex-certified devices, please take note of the instructions and wiring diagrams in the Ex-specific supplement to these Operating Instructions. Should you have any questions, please contact your Endress+Hauser sales office for assistance.



Note!

The device does not have an internal circuit breaker. An external switch or circuit breaker must therefore be installed which can be used to disconnect the device from the main power source.

4.1 Connecting the remote version

4.1.1 Connecting the sensor



Warning!

- Risk of electric shock! Switch off the power supply before opening the device. Do **not** install or wire the device while it is connected to the power supply. Failure to comply with this precaution can result in irreparable damage to the electronics.
- Risk of electric shock! Connect the protective conductor to the ground terminal on the housing before the power supply is applied.



Caution!

- Only sensors and transmitters with the same serial number can be connected to one another. Communication problems can occur if the devices are not connected in this way.
- Risk of damaging the coil driver. Always switch off the power supply before connecting or disconnecting the coil cable.

Procedure

1. Transmitter: Remove the cover from the connection compartment (a).
2. Sensor: Remove the cover from the connection housing (b).
3. Feed the signal cable (c) and the coil cable (d) through the appropriate cable entries.
 Caution!
Route the connecting cables securely (see "Connecting cable length" → 19).
4. Terminate the signal and coil current cable as indicated in the table:
Promag E/L/P/W → Refer to the table → 48
Promag H → Refer to the "Cable termination" table → 49
5. Establish the wiring between the sensor and the transmitter.
The electrical wiring diagram that applies to your device can be found:
 - ▶ In the corresponding graphic:
→ 30 (Promag E/L/P/W); → 31 (Promag H)
 - ▶ In the cover of the sensor and transmitter
 Note!
The cable shields of the Promag H sensor are grounded by means of the strain relief terminals (see also the "Cable termination" table → 49)
6. Transmitter: Screw the cover on the connection compartment (a).
7. Sensor: Secure the cover on the connection housing (b).

Promag E/L/P/W




Fig. 30: Connecting the remote version of Promag E/L/P/W

- a Wall-mount housing connection compartment
- b Cover of the sensor connection housing
- c Signal cable
- d Coil current cable
- n.c. Not connected, insulated cable shields

Wire colors/Terminal No.:
5/6 = brown, 7/8 = white, 4 = green, 37/36 = yellow

Promag H




Fig. 31: Connecting the remote version of Promag H

- a Wall-mount housing connection compartment
- b Cover of the sensor connection housing
- c Signal cable
- d Coil current cable
- n.c. Not connected, insulated cable shields


Wire colors/Terminal No.:
5/6 = brown, 7/8 = white, 4 = green, 37/36 = yellow

Cable termination in remote version Promag E/L/P/W

Terminate the signal and coil current cables as shown in the figure below (Detail A).

Fit the fine-wire cores with wire end ferrules (detail B: ① = red ferrules, Ø 1.0 mm; ② = white ferrules, Ø 0.5 mm)

* Stripping for reinforced cables only




Caution!

When fitting the connectors, pay attention to the following points:


- **Signal cable** → Make sure that the wire end ferrules do not touch the wire shields on the sensor side!
Minimum distance = 1 mm (exception "GND" = green cable)
- **Coil current cable** → Insulate one core of the three-core wire at the level of the core reinforcement; you only require two cores for the connection.

TRANSMITTER

Signal cable



Coil current cable




A0002687


A0002688

SENSOR

Signal cable



Coil current cable



A0002646

A0002650

**Cable termination in remote version
Promag H**

Terminate the signal and coil current cables as shown in the figure below (Detail A).



Fit the fine-wire cores with wire end ferrules (detail B: ① = ferrules red, Ø 1.0 mm; ② = ferrule white, Ø 0.5 mm)



Caution!



When fitting the connectors, pay attention to the following points:

- **Signal cable** → Make sure that the wire end ferrules do not touch the wire shields on the sensor side!
Minimum distance = 1 mm (exception "GND" = green cable)
- **Coil current cable** → Insulate one core of the three-core wire at the level of the core reinforcement; you only require two cores for the connection.
- On the sensor side, reverse both cable shields approx. 15 mm over the outer jacket. The strain relief ensures an electrical connection with the connection housing.

TRANSMITTER
Signal cable

Coil current cable


A0002686

A0002684

SENSOR
Signal cable

Coil current cable


A0002647

A0002648

4.1.2 Cable specifications

Signal cable

- 3 × 0.38 mm² PVC cable with common, braided copper shield ($\varnothing \sim 7$ mm) and individually shielded cores
- With Empty Pipe Detection (EPD): 4 × 0.38 mm² PVC cable with common, braided copper shield ($\varnothing \sim 7$ mm) and individually shielded cores
- Conductor resistance: $\leq 50 \Omega \text{ km}$
- Capacitance: core/shield: $\leq 420 \text{ pF/m}$
- Operating temperature: -20 to +80 °C
- Conductor cross-section: max. 2.5 mm²

Coil cable

- 2 × 0.75 mm² PVC cable with common, braided copper shield ($\varnothing \sim 7$ mm)
- Conductor resistance: $\leq 37 \Omega \text{ km}$
- Capacitance: core/core, shield grounded: $\leq 120 \text{ pF/m}$
- Operating temperature: -20 to +80 °C
- Conductor cross-section: max. 2.5 mm²
- Test current for cable insulation: $\geq 1433 \text{ V AC rms 50/60 Hz or } \geq 2026 \text{ V DC}$




Fig. 32: Cable cross-section

a Signal cable
b Coil current cable

1 = Core, 2 = Core insulation, 3 = Core shield, 4 = Core jacket, 5 = Core reinforcement, 6 = Cable shield,
7 = Outer jacket

Reinforced connecting cables

As an option, Endress+Hauser can also deliver reinforced connecting cables with an additional, reinforcing metal braid.

We recommend such cables for the following cases:

- Directly buried cable
- Cables endangered by rodents
- Device operation which should comply with the IP 68 (NEMA 6P) standard of protection

Operation in zones of severe electrical interference

The measuring device complies with the general safety requirements in accordance with EN 61010-1 and the EMC requirements of IEC/EN 61326.



Caution!

Grounding is by means of the ground terminals provided for the purpose inside the connection housing. Keep the stripped and twisted lengths of cable shield to the terminals as short as possible.

4.2 Connecting the measuring unit


4.2.1 Connecting the transmitter



Warning!

- Risk of electric shock! Switch off the power supply before opening the device. Do not install or wire the device while it is energized. Failure to comply with this precaution can result in irreparable damage to the electronics.
- Risk of electric shock! Connect the protective conductor to the ground terminal on the housing before the power supply is applied (not necessary if the power supply is galvanically isolated).
- Compare the specifications on the nameplate with the local voltage supply and frequency. Also comply with national regulations governing the installation of electrical equipment.

1. Remove the cover of the connection compartment (f) from the transmitter housing.
2. Feed the power supply cable (a) and the signal cable (b) through the appropriate cable entries.
3. Perform the wiring:
 - Wiring diagram (aluminum housing) → 33
 - Wiring diagram (stainless steel housing) → 34
 - Wiring diagram (wall-mount housing) → 35
 - Terminal assignment → 53
4. Screw the cover of the connection compartment (f) firmly onto the transmitter housing.



a0004582

Fig. 33: Connecting the transmitter (aluminum field housing). Cable cross-section: max. 2.5 mm²

- a Cable for power supply: 85 to 260 V AC, 20 to 55 V AC, 16 to 62 V DC
Terminal **No. 1**: L1 for AC, L+ for DC
Terminal **No. 2**: N for AC, L- for DC
- b Signal cable: Terminals **Nos. 20–27** → 53
- c Ground terminal for protective ground
- d Ground terminal for signal cable shield
- e Service connector for connecting service interface FXA193 (Fieldcheck, FieldCare)
- f Cover of the connection compartment
- g Securing clamp




Fig. 34: Connecting the transmitter (stainless steel field housing); cable cross-section: max. 2.5 mm^2

- a Cable for power supply: 85 to 260 V AC, 20 to 55 V AC, 16 to 62 V DC
Terminal No. 1: L1 for AC, L+ for DC
Terminal No. 2: N for AC, L- for DC
- b Signal cable: Terminals Nos. 20-27 → 53
- c Ground terminal for protective ground
- d Ground terminal for signal cable shield
- e Service connector for connecting service interface FXA193 (Fieldcheck, FieldCare)
- f Cover of the connection compartment

a0004584




Fig. 35: Connecting the transmitter (wall-mount housing); cable cross-section: max. 2.5 mm^2

- a Cable for power supply: 85 to 260 V AC, 20 to 55 V AC, 16 to 62 V DC
Terminal No. 1: L1 for AC, L+ for DC
Terminal No. 2: N for AC, L- for DC
- b Signal cable: Terminals Nos. 20-27 → 53
- c Ground terminal for protective ground
- d Ground terminal for signal cable shield
- e Service connector for connecting service interface FXA193 (Fieldcheck, FieldCare)
- f Cover of the connection compartment

a0001135

4.2.2 Terminal assignment



Note!

The electrical characteristic quantities are listed in the "Technical data" section → 123.

Order variant	Terminal No. (inputs/outputs)			
	20 (+) / 21 (-)	22 (+) / 23 (-)	24 (+) / 25 (-)	26 (+) / 27 (-)
Fixed communication boards (fixed assignment)				
53**_*****A	–	–	Frequency output	Current output HART
53**_*****B	Relay output 2	Relay output 1	Frequency output	Current output HART
53**_*****S	–	–	Frequency output, Ex i	Current output, Ex i, active, HART
53**_*****T	–	–	Frequency output, Ex i	Current output, Ex i, passive, HART
Flexible communication boards				
53**_*****C	Relay output 2	Relay output 1	Frequency output	Current output HART
53**_*****D	Status input	Relay output	Frequency output	Current output HART
53**_*****L	Status input	Relay output 2	Relay output 1	Current output HART
53**_*****M	Status input	Frequency output	Frequency output	Current output HART
53**_*****2	Relay output	Current output	Frequency output	Current output HART
53**_*****4	Current input	Relay output	Frequency output	Current output HART
53**_*****5	Status input	Current input	Frequency output	Current output HART

Ground terminal → 51

4.2.3 HART connection

Users have the following connection options at their disposal:

- Direct connection to transmitter by means of terminals 26(+) and 27 (-)
- Connection by means of the 4 to 20 mA circuit.



Note!

- The measuring loop's minimum load must be at least $250\ \Omega$.
- After commissioning, make the following settings:
 - CURRENT SPAN function → "4-20 mA HART" or "4-20 mA (25 mA) HART"
 - Switch HART write protection on or off →  82

Connection of the HART handheld communicator

See also the documentation issued by the HART Communication Foundation, and in particular HCF LIT 20: "HART, a technical summary".




Fig. 36: Electrical connection of HART handheld Field Xpert SFX100

1 = HART handheld Field Xpert SFX100, 2 = Auxiliary energy, 3 = Shielding, 4 = Other devices or PLC with passive input

Connection of a PC with an operating software

In order to connect a PC with operating software (e.g. "FieldCare"), a HART modem (e.g. "Commubox FXA195") is needed.




Fig. 37: Electrical connection of a PC with operating software

1 = PC with operating software, 2 = Auxiliary energy, 3 = Shielding, 4 = Other devices or PLC with passive input, 5 = HART modem, e.g. Commubox FXA195

4.3 Potential equalization



Warning!

The measuring system must be included in potential equalization.

Perfect measurement is only ensured when the medium and the sensor have the same electrical potential. Most Promag sensors have a reference electrode installed as standard, which guarantees the required potential equalization.

The following must also be taken into account for potential equalization:

- Company-internal grounding guidelines
- Operating conditions such as material/grounding of piping etc. (see table)

4.3.1 Potential equalization, Promag E/L/P/W

Reference electrode available as standard

4.3.2 Potential equalization, Promag H

No reference electrode available!

There is always one electrical connection to the fluid via the metallic process connection.




Caution!

When using process connections made of plastic, potential equalization must be guaranteed through the use of grounding rings → 24.




The necessary grounding rings may be ordered separately as an accessory from Endress+Hauser (→ 100).

4.3.3 Connection examples for potential equalization

Standard case

Operating conditions	Potential equalization
<p>When using the measuring device in:</p> <ul style="list-style-type: none"> ▪ metallic, grounded piping <p>Potential equalization is carried out via the ground terminal of the transmitter.</p> <p> Note! For installation in metal pipes, it is advisable to connect the ground terminal of the transmitter housing to the piping.</p>	 <p>A0011892</p> <p>Fig. 38: Via the transmitter's ground terminal</p>

Special cases

Operating conditions	Potential equalization
<p>When using the measuring device in:</p> <ul style="list-style-type: none"> ▪ metallic, ungrounded piping <p>This type of connection occurs when:</p> <ul style="list-style-type: none"> ▪ the usual potential equalization cannot be guaranteed ▪ extremely high equalizing currents are expected <p>A ground cable (copper wire, at least 6 mm² (0.0093 in²)) is used to connect both sensor flanges to the respective pipe flange and ground them. Connect the transmitter or sensor connection housing, as applicable, to ground potential by means of the ground terminal provided for the purpose.</p> <p>The installation of the ground cable depends on the nominal diameter:</p> <ul style="list-style-type: none"> ▪ DN ≤ 300 (12"): The ground cable is in direct connection with the conductive flange coating and is secured by the flange screws. ▪ DN ≥ 350 (14"): The ground cable connects directly to the metal transport bracket. <p> Note! The ground cable for flange-to-flange connections can be ordered separately as an accessory from Endress+Hauser.</p>	 <p>DN ≤ 300 DN ≥ 350</p> <p>A0011893</p>
<p>When using the measuring device in:</p> <ul style="list-style-type: none"> ▪ Plastic pipes ▪ Isolating lined pipes <p>This type of connection occurs when:</p> <ul style="list-style-type: none"> ▪ the usual potential equalization cannot be guaranteed ▪ extremely high equalizing currents are expected <p>Potential equalization takes place using additional ground disks, which are connected to the ground terminal via a ground cable (copper wire, min. 6 mm² (0.0093 in²)). When installing the ground disks, please comply with the enclosed Installation Instructions.</p>	 <p>A0011895</p>
<p>When using the measuring device in:</p> <ul style="list-style-type: none"> ▪ pipes with cathodic protection <p>The device is installed in the pipeline in such a way that it is potential-free.</p> <p>Using a ground cable (copper wire, min. 6 mm² (0.0093 in²)), only the two pipe flanges are connected. When doing so, the ground cable is mounted directly on the conductive flange coating using flange screws.</p> <p>Please note the following during installation:</p> <ul style="list-style-type: none"> ▪ The relevant regulations for potential-free installations must be observed. ▪ There must not be an electrically conductive connection between the piping and the device. ▪ The mounting material must be able to withstand the relevant torques. 	 <p>1 2</p> <p>1 Isolation transformer power supply 2 Electrically isolated</p> <p>A0011896</p>

4.4 Degree of protection

The devices fulfill all the requirements for IP 67 (NEMA 4X).

Compliance with the following points is mandatory following installation in the field or servicing, in order to ensure that IP 67 protection (NEMA 4X) is maintained:

- The housing seals must be clean and undamaged when inserted into their grooves. The seals must be dried, cleaned or replaced if necessary.
- All housing screws and screw covers must be firmly tightened.
- The cables used for connection must be of the specified external diameter →  124.
- Tighten cable glands to prevent leakages.
- The cables must loop down before they enter the cable entries ("water trap"). This arrangement prevents moisture penetrating the entry. Always install the measuring device in such a way that the cable entries do not point up.
- Close off unused cable entries using suitable insert plugs.
- Do not remove the grommet from the cable entry.




Fig. 42: Installation instructions, cable entries



Caution!

Do not loosen the screws of the sensor housing as otherwise the degree of protection guaranteed by Endress+Hauser no longer applies.



Note!

The sensor can also be supplied with IP 68 rating (permanent immersion in water to a depth of 3 m (10 ft). In this case the transmitter must be installed remote from the sensor.

4.5 Post-connection check

Perform the following checks after completing electrical installation of the measuring device:


Device condition and specifications	Notes
Are cables or the device damaged (visual inspection)?	–
Electrical connection	Notes
Does the supply voltage match the specifications on the nameplate?	<ul style="list-style-type: none"> ▪ 85 to 250 V AC (50 to 60 Hz) ▪ 20 to 28 V AC (50 to 60 Hz) 11 to 40 V DC
Do the cables used comply with the necessary specifications?	→  50
Do the cables have adequate strain relief?	–
Is the cable type route completely isolated? Without loops and crossovers?	–
Are the power-supply and signal cables correctly connected?	See the wiring diagram inside the cover of the connection compartment
Only remote version: Is the flow sensor connected to the matching transmitter electronics?	Check serial number on nameplates of sensor and connected transmitter
Only remote version: Is the connecting cable between sensor and transmitter connected correctly?	→  46
Are all screw terminals firmly tightened?	–
Have the measures for grounding/potential equalization been correctly implemented?	→  55
Are all cable entries installed, firmly tightened and correctly sealed? Cables looped as "water traps"?	→  57
Are all housing covers installed and firmly tightened?	–

5 Operation

5.1 Display and operating elements

The local display enables you to read important parameters directly at the measuring point or to configure your device using the "Quick Setup" or the function matrix.

The display consists of four lines; this is where measured values and/or status variables (direction of flow, empty pipe, bar graph, etc.) are displayed. You can change the assignment of display lines to variables at will in order to customize the display to suit your needs and preferences (→ see the "Description of Device Functions" manual).



a0001172

Fig. 43: Display and operating elements

- 1 Liquid crystal display
The backlit, four-line liquid crystal display shows measured values, dialog texts, fault messages and notice messages. The display as it appears when normal measuring is in progress is known as the **HOME** position (operating mode display).
- 2 Optical sensors for Touch Control
[/] keys
 - HOME position → Direct access to totalizer values and actual values of inputs/outputs
 - Enter numerical values, select parameters
 - Select different blocks, groups and function groups within the function matrix
 - Press the [/] keys **simultaneously** to trigger the following functions:
 - Exit the function matrix step by step → HOME position
 - Press and hold down the [/] keys for longer than 3 seconds → Return directly to the HOME position
 - Cancel data entry
- 3 [/] keys
 - HOME position → Direct access to totalizer values and actual values of inputs/outputs
 - Enter numerical values, select parameters
 - Select different blocks, groups and function groups within the function matrix
 - Press the [/] keys **simultaneously** to trigger the following functions:
 - Exit the function matrix step by step → HOME position
 - Press and hold down the [/] keys for longer than 3 seconds → Return directly to the HOME position
 - Cancel data entry
- 4 key (Enter key)
 - HOME position → Entry into the function matrix
 - Save the numerical values you input or settings you change

5.1.1 Display (operating mode)

The display area consists of three lines in all; this is where measured values are displayed, and/or status variables (direction of flow, bar graph, etc.). You can change the assignment of display lines to variables at will in order to customize the display to suit your needs and preferences (→ see the "Description of Device Functions" manual).

Multiplex mode:

A maximum of two different display variables can be assigned to each line. Variables multiplexed in this way alternate every 10 seconds on the display.

Error messages:

Display and presentation of system/process errors → 65




Fig. 44: Typical display for normal operating mode (HOME position)

- 1 Main line shows main measured values, e.g. flow
- 2 Supplementary line shows supplementary measured or status variables, e.g. totalizer reading.
- 3 Information line shows additional information on measured or status variables, e.g. bar graph representation of the full scale value attained by the flow rate
- 4 "Info icons" field shows additional information in the form of icons on the measured values displayed. A complete overview of all icons and their meaning can be found on → 61
- 5 "Measured values" field shows the current measured values
- 6 "Engineering unit" field shows the engineering units and time units defined for the current measured values.

5.1.2 Additional display functions

Depending on the order option (F-CHIP → 97), the local display has different display functions.

Device without batching software

From HOME position, use the **[+/-]** keys to open an "Info Menu" containing the following information:

- Totalizer (including overflow)
- Actual values or states of the configured inputs/outputs
- Device TAG number (user-definable)

[+/-] → Scan of individual values within the Info Menu
[Esc] (Esc key) → Back to HOME position

Device with batching software

On measuring instruments with installed batching software (F-Chip → 97) and a suitably configured display line, you can carry out filling processes directly using the local display. You will find a detailed description on → 60.

Icons

The icons which appear in the field on the left make it easier to read and recognize measured variables, device status, and error messages.

Icon	Meaning	Icon	Meaning
S	System error	P	Process error
⚡	Fault message (with effect on outputs)	!	Notice message (without effect on outputs)
1 to n	Current output 1 to n or current input	P 1 to n	Pulse output 1 to n
F 1 to n	Frequency output 1 to n	S 1 to n	Status/relay output 1 to n or status input
 a0001181	Measuring mode: PULSATING FLOW	 a0001182	Measuring mode: SYMMETRY (bidirectional)
 a0001183	Measuring mode: STANDARD	 a0001184	Counting mode totalizer: BALANCE (forward and reverse flow)
 a0001185	Counting mode totalizer: forward	 a0001186	Counting mode totalizer: reverse
 a0001187	Signal input (current or status input)		
 a0001188	Volume flow	 a0001195	Mass flow
 a0001200	Fluid density	 a0001207	Fluid temperature
 a0001201	Batching quantity upwards	 a0001202	Batching quantity downwards
 a0001203	Batching quantity	 a0001204	Batch sum
 a0001205	Batch counter (x times)	 a0001206	Remote configuration Active device operation via: HART, e.g. FieldCare, Field Xpert

5.1.3 Controlling the batching processes using the local display

Filling processes can be controlled directly by means of the local display with the aid of the optional "(Batching)" software package (F-CHIP, accessories → 100). Therefore, the device can be fully deployed in the field as a "batch controller".

Procedure:

1. Configure all the required batching functions and assign the lower display info line (= BATCHING KEYS) using the "Batch" Quick Setup menu (→ 89) or using the function matrix (→ 63).
The following "softkeys" then appear on the bottom line of the local display → 45:
 - START = left display key (⊖)
 - PRESET = middle display key (⊕)
 - MATRIX = right display key (⊖)
2. Press the "PRESET (⊕)" key. Various batching process functions requiring configuration will now appear on the display:

"PRESET" → Initial settings for the batching process		
No.	Function	Configuration
7200	BATCH SELECTOR	⊕ ⊖ → Select the batching liquid (BATCH #1 to 6)
7203	BATCH QUANTITY	If the "ACCESS CUSTOMER" option was selected for the "PRESET batch quantity" prompt in the "Batching" Quick Setup, the batching quantity can be altered via the local display. If the "LOCKED" option was selected, the batching quantity can only be read and cannot be altered until the private code has been entered.
7265	RESET TOTAL BATCH SUM/COUNTER	Resets the batching quantity counter or the total batching quantity to "0".

3. After exiting the PRESET menu, you can now start the batching process by pressing "START (⊖)". New softkeys (STOP / HOLD or GO ON) now appear on the display. You can use these to interrupt, continue or stop the batching process at any time. → 62
STOP (⊖) → Stops batching process
HOLD (⊕) → Interrupts batching process (softkey changes to "GO ON")
GO ON (⊕) → Continues batching process (softkey changes to "HOLD")
 After the batch quantity is reached, the "START" or "PRESET" softkeys reappear on the display.




Fig. 45: Controlling batching processes using the local display (softkeys)

5.2 Brief Operating Instructions for the function matrix



Note!

- See the general notes → 64
- Function descriptions → See the "Description of Device Functions" manual

1. HOME position → **E** → Enter the function matrix
2. **+/[-]** → Select a block (e.g. MEASURED VARIABLES) → **E**
3. **+/[-]** → Select a group (e.g. SYSTEM UNITS) → **E**
4. **+/[-]** → Select a function group (e.g. CONFIGURATION) → **E**
5. Select a function (e.g. UNIT VOLUME FLOW) and change parameters/enter numerical values:
+/[-] → Select or enter release code, parameters, numerical values
E → Save entries
6. Exit the function matrix:
 - Press and hold down Esc key (**Esc**) for longer than 3 seconds → HOME position
 - Repeatedly press Esc key (**Esc**) → Return step by step to HOME position




Fig. 46: Selecting functions and configuring parameters (function matrix)

a0001210

5.2.1 General notes

The Quick Setup menu is adequate for commissioning with the necessary standard settings. Complex measuring operations on the other hand necessitate additional functions that you can configure as necessary and customize to suit your process parameters. The function matrix, therefore, comprises a multiplicity of additional functions which, for the sake of clarity, are arranged on a number of menu levels (blocks, groups, and function groups).

Comply with the following instructions when configuring functions:

- You select functions as described →  63.
Each cell in the function matrix is identified by a numerical or letter code on the display.
- You can switch off certain functions (OFF). If you do so, related functions in other function groups will no longer be displayed.
- Certain functions prompt you to confirm your data entries. Press  to select "SURE | YES |" and press  again to confirm. This saves your setting or starts a function, as applicable.
- Return to the HOME position is automatic if no key is pressed for 5 minutes.
- Programming mode is automatically disabled if you do not press a key within 60 seconds following automatic return to the HOME position.



Caution!

All functions are described in detail, including the function matrix itself, in the "Description of Device Functions" manual, which is a separate part of these Operating Instructions.



Note!

- The transmitter continues to measure while data entry is in progress, i.e. the current measured values are output via the signal outputs in the normal way.
- If the power supply fails, all preset and parameterized values remain safely stored in the EEPROM.

5.2.2 Enabling the programming mode

The function matrix can be disabled. Disabling the function matrix rules out the possibility of inadvertent changes to device functions, numerical values or factory settings. A numerical code (factory setting = 53) has to be entered before settings can be changed.

If you use a code number of your choice, you exclude the possibility of unauthorized persons accessing data (→ "Description of Device Functions" manual).

Comply with the following instructions when entering codes:

- If programming is disabled and the  keys are pressed in any function, a prompt for the code automatically appears on the display.
- If "0" is entered as the customer's code, programming is always enabled.
- The Endress+Hauser service organization can be of assistance if you mislay your personal code.



Caution!

Changing certain parameters such as all sensor characteristics, for example, influences numerous functions of the entire measuring system, particularly measuring accuracy. There is no need to change these parameters under normal circumstances and consequently, they are protected by a special code known only to the Endress+Hauser service organization. Please contact Endress+Hauser first if you have any questions.

5.2.3 Disabling the programming mode

Programming mode is disabled if you do not press a key within 60 seconds following automatic return to the HOME position.

You can also disable programming in the ACCESS CODE function by entering any number (other than the customer's code).

5.3 Error messages

5.3.1 Type of error

Errors which occur during commissioning or measuring operation are displayed immediately. If two or more system or process errors occur, the error with the highest priority is the one shown on the display.

The measuring system distinguishes between two types of error:

- **System errors:** This group comprises all device errors, e.g. communication errors, hardware errors, etc. →  104
- **Process error:** This group includes all application errors e.g. empty pipe, etc. →  108




Fig. 47: Error messages on the display (example)

- 1 Error type: P = process error, S = system error
- 2 Error message type: ⚡ = fault message, ! = notice message
- 3 Error designation
- 4 Error number
- 5 Duration of most recent error occurrence (hours : minutes : seconds)

5.3.2 Error message type

Users have the option of weighting system and process errors differently, by defining them as **Fault messages** or **Notice messages**. You can define messages in this way with the aid of the function matrix (see the "Description of Device Functions" manual).

Serious system errors, e.g. module defects, are always identified and classed as "fault messages" by the measuring device.

Notice message (!)

- Displayed as → Exclamation mark (!), type of error (S: system error, P: process error)
- The error in question has no effect on the current measuring operation and the outputs of the measuring device.

Fault message (⚡)

- Displayed as → Lightning flash (⚡), type of error (S: system error, P: process error)
- The error in question interrupts or stops the current measuring operation and has an immediate effect on the outputs. The response of the outputs (failsafe mode) can be defined by means of functions in the function matrix. →  111



Note!

- Error conditions can be output via the relay outputs.
- If an error message occurs, an upper or lower signal level for the breakdown information according to NAMUR 43 can be output via the current output.

5.3.3 Confirming error messages

For the sake of plant and process safety, the measuring device can be configured in such a way that fault messages displayed (⚡) always have to be rectified and acknowledged locally by pressing . Only then do the error messages disappear from the display. This option can be switched on or off by means of the "ACKNOWLEDGE FAULT MESSAGES" function (see the "Description of Device Functions" manual).



Note!

- Fault messages (⚡) can also be reset and confirmed via the status input.
- Notice messages (!) do not require acknowledgment. Note, however, that they remain visible until the cause of the error has been rectified.

5.4 Communication

In addition to local operation, the measuring device can be configured and measured values can be obtained by means of the HART protocol. Digital communication takes place using the 4-20 mA current output HART →  54.

The HART protocol allows the transfer of measuring and device data between the HART master and the field devices for configuration and diagnostics purposes. The HART master, e.g. a handheld terminal or PC-based operating programs (such as FieldCare), require device description (DD) files which are used to access all the information in a HART device. Information is exclusively transferred using so-called "commands". There are three different command groups:

There are three different command groups:

▪ *Universal commands*

All HART device support and use universal commands. The following functionalities, for example, are linked to them:

- Identify HART devices
- Reading digital measured values (volume flow, totalizer, etc.)

▪ *Common practice commands*:

Common practice commands offer functions which are supported and can be executed by most but not all field devices.

▪ *Device-specific commands*:

These commands allow access to device-specific functions which are not HART standard. Amongst other things, such commands access individual field device information, such as empty-pipe/full-pipe calibration values, low flow cutoff settings, etc.



Note!

The device has access to all three command classes.

List of all "universal commands" and "common practice commands" →  70

5.4.1 Operating options

For the complete operation of the measuring device, including device-specific commands, there are DD files available to the user to provide the following operating aids and programs:



Note!

- In the CURRENT SPAN function (current output 1), the HART protocol demands the setting "4-20 mA HART" or "4-20 mA (25 mA) HART".
- HART write protection can be enabled or disabled by means of a jumper on the I/O board
→ [82](#)

Field Xpert HART Communicator

Selecting device functions with a HART Communicator is a process involving a number of menu levels and a special HART function matrix.

The HART manual in the carrying case of the HART Communicator contains more detailed information on the device.

Operating program "FieldCare"

Fieldcare is Endress+Hauser's FDT-based plant Asset Management Tool and allows the configuration and diagnosis of intelligent field devices. By using status information, you also have a simple but effective tool for monitoring devices. The Proline flow measuring devices are accessed via a service interface or via the service interface FXA193.

Operating program "SIMATIC PDM" (Siemens)

SIMATIC PDM is a standardized, manufacturer-independent tool for the operation, configuration, maintenance and diagnosis of intelligent field devices.

Operating program "AMS" (Emerson Process Management)

AMS (Asset Management Solutions): program for operating and configuring devices

5.4.2 Current device description files

The following table illustrates the suitable device description file for the operating tool in question and then indicates where these can be obtained.

HART protocol:

Order code "Power Supply; Display", option A, B, C, D, E, F, G, H, X, 7, 8 (HART 5)		
Valid for software	2.03.XX	→ "Device software" function (8100)
Device data HART		
Manufacturer ID:	11 _{hex} (ENDRESS+HAUSER)	→ "Manufact ID" function (6040)
Device ID:	42 _{hex}	→ "Device ID" function (6041)
HART version data	Device Revision 6/ DD Revision 1	
Software release	01.2011	

Order code "Power Supply; Display", option P, Q, R, S, T, U, 4, 5 (HART 7)		
Valid for software	2.07.XX	→ "Device software" function (8100)
Device data HART		
Manufacturer ID:	11 _{hex} (ENDRESS+HAUSER)	→ "Manufact ID" function (6040)
Device ID:	42 _{hex}	→ "Device ID" function (6041)
HART version data	Device Revision 9/ DD Revision 1	
Software release	12.2014	

Operating	Sources for obtaining device descriptions
Handheld terminal Field Xpert SFX100	Use update function of handheld terminal
FieldCare / DTM	<ul style="list-style-type: none"> ■ www.endress.com → Download ■ CD-ROM (Endress+Hauser order number 56004088) ■ DVD (Endress+Hauser order number 70100690)
AMS	www.endress.com → Download
SIMATIC PDM	www.endress.com → Download

Tester/simulator	Sources for obtaining device descriptions
Fieldcheck	Update via FieldCare using the Flow Device FXA193/291 DTM in the Fieldflash module

5.4.3 Device and process variables

Device variables:

The following device variables are available using the HART protocol:

Code (decimal)	Device variable
0	OFF (not assigned)
1	Volume flow
2	Mass flow
52	Batch upwards
53	Batch downwards
250	Totalizer 1
251	Totalizer 2
252	Totalizer 3

Process variables:

At the factory, the process variables are assigned to the following device variables:

- Primary process variable (PV) → Volume flow
- Second process variable (SV) → Totalizer 1
- Third process variable (TV) → Mass flow
- Fourth process variable (FV) → not assigned



Note!

You can set or change the assignment of device variables to process variables using Command 51 →  75

5.4.4 Universal/Common practice HART commands

Command No. HART command / Access type		Command data (numeric data in decimal form)	Response data (numeric data in decimal form)
Universal Commands			
0 (HART 5)	Read unique device identifier Access type = read	none	<p>Device identification delivers information on the device and the manufacturer. It cannot be changed.</p> <p>The response consists of a 12 byte device ID:</p> <ul style="list-style-type: none"> - Byte 0: fixed value 254 - Byte 1: Manufacturer ID, 17 = E+H - Byte 2: Device type ID, e.g. 66 = Promag 53 - Byte 3: Number of preambles - Byte 4: Universal commands rev. no. - Byte 5: Device-specific rev. no. Commands - Byte 6: Software revision - Byte 7: Hardware revision - Byte 8: Additional device information - Bytes 9-11: Device identification
0 (HART 7)	Read unique device identifier Access type = read	none	<p>Device identification delivers information on the device and the manufacturer. It cannot be changed.</p> <p>The response consists of a 22 byte device ID:</p> <ul style="list-style-type: none"> - Byte 0: Fixed value 254 - Byte 1: Manufacturer ID, 17 = E+H - Byte 2: Device type ID, e.g. 66 = Promag 53 - Byte 3: Number of preambles - Byte 4: Universal commands rev. no. - Byte 5: Device-specific rev. no. Commands - Byte 6: Software revision - Byte 7: Hardware revision - Byte 8: Additional device information - Bytes 9-11: Device identification - Byte 12: Minimum number of preambles that are sent by the slave to the master with the response message - Byte 13: Maximum number of device variables - Bytes 14-15: Configuration change counter - Byte 16: Extended field device status - Bytes 17-18: Manufacturer ID code
1	Read primary process variable Access type = read	none	<ul style="list-style-type: none"> - Byte 0: HART unit code of the primary process variable - Bytes 1-4: Primary process variable <p><i>Factory setting:</i> Primary process variable = Volume flow</p> <p> Note!</p> <ul style="list-style-type: none"> ■ You can set or change the assignment of device variables to process variables using Command 51. ■ Manufacturer-specific units are represented using the HART unit code "240".
2	Read the primary process variable as current in mA and percentage of the set measuring range Access type = read	none	<ul style="list-style-type: none"> - Bytes 0-3: actual current of the primary process variable in mA - Bytes 4-7: Percentage of the set measuring range <p><i>Factory setting:</i> Primary process variable = Volume flow</p> <p> Note!</p> <p>You can set the assignment of device variables to process variables using Command 51.</p>

Command No. HART command / Access type	Command data (numeric data in decimal form)	Response data (numeric data in decimal form)															
3 Read the primary process variable as current in mA and four (preset using Command 51) dynamic process variables Access type = read	none	<p>24 bytes are sent as a response:</p> <ul style="list-style-type: none"> - Bytes 0-3: primary process variable current in mA - Byte 4: HART unit code of the primary process variable - Bytes 5-8: Primary process variable - Byte 9: HART unit code of the second process variable - Bytes 10-13: Second process variable - Byte 14: HART unit code of the third process variable - Bytes 15-18: Third process variable - Byte 19: HART unit code of the fourth process variable - Bytes 20-23: Fourth process variable <p><i>Factory setting:</i></p> <ul style="list-style-type: none"> ▪ Primary process variable = Volume flow ▪ Second process variable = Totalizer 1 ▪ Third process variable = Mass flow ▪ Fourth process variable = OFF (not assigned) <p> Note!</p> <ul style="list-style-type: none"> ▪ You can set the assignment of device variables to process variables using Command 51. ▪ Manufacturer-specific units are represented using the HART unit code "240". 															
6 (HART 5) Set HART shortform address Access type = write	Byte 0: Desired address (0 to 15) <i>Factory setting:</i> 0  Note! With an address >0 (multidrop mode), the current output of the primary process variable is fixed at 4 mA..	Byte 0: Active address															
6 (HART 7) Set HART address and loop current mode Access type = write	Byte 0: Desired address (0 to 63) <i>Factory setting:</i> 0  Note! With an address >0 (multidrop mode), the current output of the primary process variable is fixed at 4 mA..	Byte 0: Active address Byte 1: Loop current mode															
9 (HART 7) Write long HART tag name Access type = write	none	<p>This command allows a master (PLC) to request the value and status of up to four devices or dynamic variables..</p> <table border="1" data-bbox="1044 1500 1518 1756"> <thead> <tr> <th data-bbox="1044 1500 1202 1585">Number of device variables requested</th><th data-bbox="1202 1500 1361 1585">Number of data bytes requested</th><th data-bbox="1361 1500 1518 1585">Number of data bytes in response</th></tr> </thead> <tbody> <tr> <td data-bbox="1044 1585 1202 1630">1</td><td data-bbox="1202 1585 1361 1630">1</td><td data-bbox="1361 1585 1518 1630">9</td></tr> <tr> <td data-bbox="1044 1630 1202 1675">2</td><td data-bbox="1202 1630 1361 1675">2</td><td data-bbox="1361 1630 1518 1675">17</td></tr> <tr> <td data-bbox="1044 1675 1202 1720">3</td><td data-bbox="1202 1675 1361 1720">3</td><td data-bbox="1361 1675 1518 1720">25</td></tr> <tr> <td data-bbox="1044 1720 1202 1756">4</td><td data-bbox="1202 1720 1361 1756">4</td><td data-bbox="1361 1720 1518 1756">33</td></tr> </tbody> </table>	Number of device variables requested	Number of data bytes requested	Number of data bytes in response	1	1	9	2	2	17	3	3	25	4	4	33
Number of device variables requested	Number of data bytes requested	Number of data bytes in response															
1	1	9															
2	2	17															
3	3	25															
4	4	33															

Command No. HART command / Access type		Command data (numeric data in decimal form)	Response data (numeric data in decimal form)
11	Read unique device identification using the TAG (measuring point designation) Access type = read	Bytes 0-5: TAG	<p>Device identification delivers information on the device and the manufacturer. It cannot be changed.</p> <p>The response consists of a 12 byte device ID if the given TAG agrees with the one saved in the device:</p> <ul style="list-style-type: none"> - Byte 0: fixed value 254 - Byte 1: Manufacturer ID, 17 = E+H - Byte 2: Device type ID, 66 = Promag 53 - Byte 3: Number of preambles - Byte 4: Universal commands rev. no. - Byte 5: Device-specific rev. no. Commands - Byte 6: Software revision - Byte 7: Hardware revision - Byte 8: Additional device information - Bytes 9-11: Device identification
12	Read user message Access type = read	none	<p>Bytes 0-24: User message</p> <p> Note! You can write the user message using Command 17.</p>
13	Read TAG, descriptor and date Access type = read	none	<ul style="list-style-type: none"> - Bytes 0-5: TAG - Bytes 6-17: descriptor - Bytes 18-20: Date <p> Note! You can write the TAG, descriptor and date using Command 18.</p>
14	Read sensor information on primary process variable	none	<ul style="list-style-type: none"> - Bytes 0-2: Sensor serial number - Byte 3: HART unit code of sensor limits and measuring range of the primary process variable - Bytes 4-7: Upper sensor limit - Bytes 8-11: Lower sensor limit - Bytes 12-15: Minimum span <p> Note!</p> <ul style="list-style-type: none"> ■ The data relate to the primary process variable (= volume flow). ■ Manufacturer-specific units are represented using the HART unit code "240".
15	Read output information of primary process variable Access type = read	none	<ul style="list-style-type: none"> - Byte 0: Alarm selection ID - Byte 1: Transfer function ID - Byte 2: HART unit code for the set measuring range of the primary process variable - Bytes 3-6: End of measuring range, value for 20 mA - Bytes 7-10: Start of measuring range, value for 4 mA - Bytes 11-14: Attenuation constant in [s] - Byte 15: Write protection ID - Byte 16: OEM dealer ID, 17 = E+H <p><i>Factory setting:</i> Primary process variable = Volume flow</p> <p> Note!</p> <ul style="list-style-type: none"> ■ You can set the assignment of device variables to process variables using Command 51. ■ Manufacturer-specific units are represented using the HART unit code "240".
16	Read the device production number Access type = read	none	Bytes 0-2: Production number
17	Write user message Access = write	<p>You can save any 32-character long text in the device under this parameter: Bytes 0-23: Desired user message</p>	<p>Displays the current user message in the device: Bytes 0-23: Current user message in the device</p>

Command No. HART command / Access type		Command data (numeric data in decimal form)	Response data (numeric data in decimal form)																																													
18	Write TAG, descriptor and date Access = write	With this parameter, you can store an 8 character TAG, a 16 character descriptor and a date: – Bytes 0-5: TAG – Bytes 6-17: descriptor – Bytes 18-20: Date	Displays the current information in the device: – Bytes 0-5: TAG – Bytes 6-17: descriptor – Bytes 18-20: Date																																													
20 (HART 7)	Read long HART tag name Access type = read	none	The long tag name with the international character set (ISO Latin 1) makes it possible to use longer names as required by many users in industry. The long tag name occupies 16 consecutive buffer memory addresses. 32 characters are saved in ASCII format, the first character in the least significant byte (LSB) of the lowest buffer memory address.																																													
21 (HART 7)	Read unique ID assigned to long HART tag name Access type = read	none	This command can either be issued with the long frame address of the device or the broadcast address No response if the long HART tag name and the device do not match. This comparison is case-sensitive. If the long frame address is used, no response if the address and the long HART tag name of the device do not match																																													
22 (HART 7)	Write long HART tag name Access type = write	Byte 0-31: Long HART tag name response codes	<table border="1"> <thead> <tr> <th colspan="3">Response codes</th> </tr> <tr> <th>Code</th> <th>Class</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Success</td> <td>No command-specific errors</td> </tr> <tr> <td>1-4</td> <td></td> <td>Undefined</td> </tr> <tr> <td>5</td> <td>Error</td> <td>Too few data bytes received</td> </tr> <tr> <td>6</td> <td>Error</td> <td>Device-specific command error</td> </tr> <tr> <td>7</td> <td>Error</td> <td>In write protect mode</td> </tr> <tr> <td>8-15</td> <td></td> <td>Undefined</td> </tr> <tr> <td>16</td> <td>Error</td> <td>Access Restricted</td> </tr> <tr> <td>17-31</td> <td></td> <td>Undefined</td> </tr> <tr> <td>32</td> <td>Error</td> <td>Busy (A DR cannot be started)</td> </tr> <tr> <td>33</td> <td>Error</td> <td>DR Initiated</td> </tr> <tr> <td>34</td> <td>Error</td> <td>DR Running</td> </tr> <tr> <td>35</td> <td>Error</td> <td>DR Dead</td> </tr> <tr> <td>36</td> <td>Error</td> <td>DR Conflict</td> </tr> </tbody> </table>	Response codes			Code	Class	Description	0	Success	No command-specific errors	1-4		Undefined	5	Error	Too few data bytes received	6	Error	Device-specific command error	7	Error	In write protect mode	8-15		Undefined	16	Error	Access Restricted	17-31		Undefined	32	Error	Busy (A DR cannot be started)	33	Error	DR Initiated	34	Error	DR Running	35	Error	DR Dead	36	Error	DR Conflict
Response codes																																																
Code	Class	Description																																														
0	Success	No command-specific errors																																														
1-4		Undefined																																														
5	Error	Too few data bytes received																																														
6	Error	Device-specific command error																																														
7	Error	In write protect mode																																														
8-15		Undefined																																														
16	Error	Access Restricted																																														
17-31		Undefined																																														
32	Error	Busy (A DR cannot be started)																																														
33	Error	DR Initiated																																														
34	Error	DR Running																																														
35	Error	DR Dead																																														
36	Error	DR Conflict																																														

The following table contains all the common practice commands supported by the device.

Command No. HART command / Access type	Command data (numeric data in decimal form)	Response data (numeric data in decimal form)
34 Write damping value for primary process variable Access = write	Bytes 0-3: Damping value of the primary process variable in seconds <i>Factory setting:</i> Primary process variable = Volume flow	Displays the current damping value in the device: Bytes 0-3: Damping value in seconds
35 Write measuring range of primary process variable Access = write	Write the desired measuring range: - Byte 0: HART unit code of the primary process variable - Bytes 1-4: upper range, value for 20 mA - Bytes 5-8: lower range, value for 4 mA <i>Factory setting:</i> Primary process variable = Volume flow  Note! ■ You can set the assignment of device variables to process variables using Command 51. ■ If the HART unit code is not the correct one for the process variable, the device will continue with the last valid unit.	The currently set measuring range is displayed as a response: - Byte 0: HART unit code for the set measuring range of the primary process variable - Bytes 1-4: upper range, value for 20 mA - Bytes 5-8: lower range, value for 4 mA  Note! Manufacturer-specific units are represented using the HART unit code "240".
38 Device status reset (Configuration changed) Access = write	none	none
40 Simulate output current of primary process variable Access = write	Simulation of the desired output current of the primary process variable. An entry value of 0 exits the simulation mode: Bytes 0-3: Output current in mA <i>Factory setting:</i> Primary process variable = Volume flow  Note! You can set the assignment of device variables to process variables using Command 51.	The momentary output current of the primary process variable is displayed as a response: Bytes 0-3: Output current in mA
42 Perform master reset Access = write	none	none
44 Write unit of primary process variable Access = write	Set unit of primary process variable. Only unit which are suitable for the process variable are transferred to the device: Byte 0: HART unit code <i>Factory setting:</i> Primary process variable = Volume flow  Note! ■ If the written HART unit code is not the correct one for the process variable, the device will continue with the last valid unit. ■ If you change the unit of the primary process variable, this has no impact on the system units.	The current unit code of the primary process variable is displayed as a response: Byte 0: HART unit code  Note! Manufacturer-specific units are represented using the HART unit code "240".
48 Read additional device status Access = read	none	The device status is displayed in extended form as the response: Coding: see table →  78

Command No. HART command / Access type	Command data (numeric data in decimal form)	Response data (numeric data in decimal form)
50 Read assignment of the device variables to the four process variables Access = read	none	<p>Display of the current variable assignment of the process variables:</p> <ul style="list-style-type: none"> - Byte 0: Device variable code to the primary process variable - Byte 1: Device variable code to the second process variable - Byte 2: Device variable code to the third process variable - Byte 3: Device variable code to the fourth process variable <p><i>Factory setting:</i></p> <ul style="list-style-type: none"> ▪ Primary process variable: Code 1 for volume flow ▪ Second process variable: Code 250 for totalizer 1 ▪ Third process variable: Code 2 for mass flow ▪ Fourth process variable: Code 0 for OFF (not assigned) <p> Note! You can set the assignment of device variables to process variables using Command 51.</p>
51 Write assignments of the device variables to the four process variables Access = write	<p>Setting of the device variables to the four process variables:</p> <ul style="list-style-type: none"> - Byte 0: Device variable code to the primary process variable - Byte 1: Device variable code to the second process variable - Byte 2: Device variable code to the third process variable - Byte 3: Device variable code to the fourth process variable <p><i>Code of the supported device variables:</i> See information → 68</p> <p><i>Factory setting:</i></p> <ul style="list-style-type: none"> ▪ Primary process variable = Volume flow ▪ Second process variable = Totalizer 1 ▪ Third process variable = Mass flow ▪ Fourth process variable = OFF (not assigned) 	<p>The variable assignment of the process variables is displayed as a response:</p> <ul style="list-style-type: none"> - Byte 0: Device variable code to the primary process variable - Byte 1: Device variable code to the second process variable - Byte 2: Device variable code to the third process variable - Byte 3: Device variable code to the fourth process variable
53 Write device variable unit Access = write	<p>This command set the unit of the given device variables. Only those units which suit the device variable are transferred:</p> <ul style="list-style-type: none"> - Byte 0: Device variable code - Byte 1: HART unit code <p><i>Code of the supported device variables:</i> See information → 68</p> <p> Note!</p> <ul style="list-style-type: none"> ▪ If the written unit is not the correct one for the device variable, the device will continue with the last valid unit. ▪ If you change the unit of the device variable, this has no impact on the system units. 	<p>The current unit of the device variables is displayed in the device as a response:</p> <ul style="list-style-type: none"> - Byte 0: Device variable code - Byte 1: HART unit code <p> Note! Manufacturer-specific units are represented using the HART unit code "240".</p>
59 Write number of preambles in response message Access = write	This parameter sets the number of preambles which are inserted in the response messages: Byte 0: Number of preambles (2 to 20)	As a response, the current number of the preambles is displayed in the response message: Byte 0: Number of preambles
95 (HART 7) Read device communication statistics Access type = read	none	<p>The device communication statistics command provides statistics about device communication</p> <p>6 bytes follow by way of response</p> <ul style="list-style-type: none"> - Byte 0-1: Number of STX messages received by the device - Byte 2-3: Number of ACK messages sent by the device - Byte 4-6: Number of BACK messages sent by the device

Command No. HART command / Access type	Command data (numeric data in decimal form)	Response data (numeric data in decimal form)
523 (HART 7) Read condensed status mapping array Access type = read	<p>Byte 0: Start index of the status map Byte 1: Number of status map entries to be read</p>	<p>This command returns the requested condensed status map entries of the field device. Each entry in the status map corresponds to either a bit of the field device status or a bit of command 48.</p> <p>Two status map codes are packed into a byte. The least significant nibble corresponds to the smaller of the two indices of the status map array.</p> <p>The following is returned by way of response:</p> <ul style="list-style-type: none"> - Byte 0: Current start index of the status map - Byte 1: Number of status map entries to be read - Byte 2.0-2.3: First status map code - Byte 2.4-2.7: Second status map code - Byte 3.0-3.3: Third status map code ... - Byte $(2+(n-2)/2).0-(2+(n-2)/2).3$: (n-1)-th status map code - Byte $(2+(n-2)/2).4-(2+(n-2)/2).7$: n-th status map code
524 (HART 7) Write condensed status mapping Access = write	<p>This command changes the status map of the field device. Each entry in the status map corresponds to either a bit of the field device status or a bit of command 48.</p> <p>Two status map codes are packed into a byte. The least significant nibble corresponds to the smaller of the two indices of the status map array.</p> <p> Note! Modified mapping is active immediately as soon as this command is executed and can therefore cause immediate changes to the condensed status.</p> <p>This command must always write at least two status map entries. This means that the number of entries to be written must always be an even number.</p> <ul style="list-style-type: none"> - Byte 0: Current start index of the status map - Byte 1: Number of status map entries to be written - Byte 2.0-2.3: First status map code - Byte 2.4-2.7: Second status map code - Byte 3.0-3.3: Third status map code ... - Byte $(2+(n-2)/2).0-(2+(n-2)/2).3$: (n-1)-th status map code - Byte $(2+(n-2)/2).4-(2+(n-2)/2).7$: n-th status map code 	<ul style="list-style-type: none"> - Byte 0: Current start index of the status map - Byte 1: Number of status map entries to be written - Byte 2.0-2.3: First status map code - Byte 2.4-2.7: Second status map code - Byte 3.0-3.3: Third status map code ... - Byte $(2+(n-2)/2).0-(2+(n-2)/2).3$: (n-1)-th status map code - Byte $(2+(n-2)/2).4-(2+(n-2)/2).7$: n-th status map code
525 (HART 7) Reset condensed status map Access = write	<p>none</p> <p>This command resets the status map (i.e. the default values for the status map are written to the status map array).</p> <p> Note! The condensed status map reset becomes effective immediately as soon as this command is executed and can result in immediate changes to the condensed status</p>	none

Command No. HART command / Access type	Command data (numeric data in decimal form)	Response data (numeric data in decimal form)
526 (HART 7) Write simulation status mode Access = write	<p>Byte 0: Status simulation mode code This command is used to activate or deactivate status simulation mode.</p> <p>The status simulation mode enables the point-to-point verification of the system response to changes in the device status or command 48 response.</p> <p>If status simulation is enabled:</p> <ul style="list-style-type: none"> - all device-initiated changes to the device status and command 48 response are disabled - the simulation status active bit is set <p>When status simulation is enabled, the device status and command 48 response are influenced by the host application only when command 527 is received.</p> <p>If status simulation is disabled:</p> <ul style="list-style-type: none"> - the simulation status active bit is reset - the current values that apply for the device status and command 48 response are active - Normal internal updating of the device status and command 48 response are resumed <p>The status simulation mode is also disabled if power supply to the device is interrupted or if the device is reset.</p>	<p>The following is returned by way of response: Byte 0: Status simulation mode code</p>
527 (HART 7) Simulation status bit Access = write	<p>Byte 0: Index of the simulated bit Byte 1: Value of the simulated bit</p> <p>When the status simulation mode is enabled, this command allows the device status bits or the bits in the command 48 response to be set or reset individually.</p>	<p>The following is returned by way of response: Byte 0: Index of the simulated bit Byte 1: Value of the simulated bit</p>

5.4.5 Device status/Error messages

You can read the extended device status, in this case, current error messages, via Command "48". The command delivers information which are partly coded in bits (see table below).



Note!

For a detailed explanation of the device status and error messages and their elimination, see → 103

HART 5

Byte-Bit	Error No.	Short description of error → 103
0-0	001	Serious device error
0-1	011	Measuring amplifier has faulty EEPROM
0-2	012	Error when accessing data of the measuring amplifier EEPROM
1-1	031	S-DAT: defective or missing
1-2	032	S-DAT: Error accessing saved values
1-3	041	T-DAT: defective or missing
1-4	042	T-DAT: Error accessing saved values
1-5	051	I/O- board and the amplifier board are not compatible
3-3	111	Totalizer checksum error
3-4	121	I/O board and the amplifier board are not compatible.
3-6	205	T-DAT: Data download unsuccessful
3-7	206	T-DAT: Data upload unsuccessful
4-3	251	Internal communication error on amplifier board
4-4	261	No data reception between amplifier and I/O board
5-0	321	Coil current of the sensor is outside the tolerance.
5-7	339	Flow buffer: The temporarily buffered flow portions (measuring mode for pulsating flow) could not be cleared or output within 60 seconds.
6-0	340	
6-1	341	
6-2	342	
6-3	343	
6-4	344	Frequency buffer: The temporarily buffered flow portions (measuring mode for pulsating flow) could not be cleared or output within 60 seconds.
6-5	345	
6-6	346	
6-7	347	
7-0	348	
7-1	349	Pulse buffer: The temporarily buffered flow portions (measuring mode for pulsating flow) could not be cleared or output within 60 seconds.
7-2	350	
7-3	351	
7-4	352	
7-5	353	
7-6	354	Current output: Actual flow value is out of range.
7-7	355	
8-0	356	
8-1	357	
8-2	358	
8-3	359	Frequency output: Actual flow value is out of range.
8-4	360	
8-5	361	
8-6	362	
10-7	401	Measuring tube partially filled or empty

Byte-Bit	Error No.	Short description of error → 103
11-2	461	EPD adjustment not possible because the fluid's conductivity is either too low or too high.
11-4	463	The EPD adjustment values for empty pipe and full pipe are identical and therefore incorrect.
11-6	471	Max. permitted batching time has been exceeded.
11-7	472	Underbatching: the minimum quantity was not reached. Overbatching: the maximum permitted batching quantity was exceeded.
12-0	473	The predefined batch quantity point was exceeded. End of filling process approaching.
12-1	481	Actual relaxation time has exceeded the limit value.
12-2	482	Electrical potential of electrode 1 has exceeded the limit value.
12-3	483	Electrical potential of electrode 2 has exceeded the limit value.
12-7	501	New amplifier software version is loaded. Currently no other commands are possible.
13-2	571	Batching process in progress (valves are open)
13-3	572	Batching process has been stopped (valves are closed)
14-3	601	Positive zero return active
14-7	611	Simulation current output active
15-0	612	
15-1	613	
15-2	614	
15-3	621	Simulation frequency output active
15-4	622	
15-5	623	
15-6	624	
15-7	631	Simulation pulse output active
16-0	632	
16-1	633	
16-2	634	
16-3	641	Simulation status output active
16-4	642	
16-5	643	
16-6	644	
16-7	651	Simulation relay output active
17-0	652	
17-1	653	
17-2	654	
17-3	661	Simulation current input active
17-7	671	Simulation status input active
18-0	672	
18-1	673	
18-2	674	
18-3	691	Simulation of response to error (outputs) active
18-4	692	Simulation of volume flow is active
22-4	061	F-CHIP is defective or not on I/O board
24-5	363	Current input: Actual current value is out of range.

HART 7

Byte-Bit	Error No.	Short description of error →  103
0-0	001	Critical failure
0-1	011	Measuring amplifier has faulty EEPROM
0-2	012	Error when accessing data of the measuring amplifier EEPROM
0-3	031	S-DAT is missing
0-4	032	S-DAT is defective
0-5	041	T-DAT is defective or missing
0-6	042	T-DAT: Error accessing saved values.
0-7	101	Gain deviation compared to reference gain
1-0	111	Totalizer checksum error
1-1	205	T-DAT: Data download unsuccessful
1-2	206	T-DAT: Data upload unsuccessful
1-3	251	Internal communication error on amplifier board
1-4	261	No data reception between amplifier and I/O board
1-6	321	Coil current of the sensor is outside the tolerance.
1-7	355	Frequency output: Actual flow value is out of range.
2-0	356	
2-1	357	
2-2	358	
2-3	359	Pulse output: The pulse output frequency is outside the permitted range.
2-4	360	
2-5	361	
2-6	362	
2-7	401	Measuring tube partially filled or empty
3-0	461	EPD adjustment not possible because the fluid's conductivity is either too low or too high.
3-1	463	The EPD adjustment values for empty pipe and full pipe are identical and therefore incorrect.
3-2	502	Upload and download of device files. Currently no other commands are possible.
3-3	601	Positive zero return active
3-4	621	Simulation frequency output active
3-5	622	
3-6	623	
3-7	624	
4-0	631	Simulation pulse output active
4-1	632	
4-2	633	
4-3	634	
4-4	641	Simulation status output active
4-5	642	
4-6	643	
4-7	644	
5-0	651	Simulation relay output active.
5-1	652	
5-2	653	
5-3	654	
5-4	661	Simulation current output active.

Byte-Bit	Error No.	Short description of error →  103
10-0	351	
10-1	352	Current output: The actual value for the flow lies outside the set limits.
10-2	353	
13-0	611	
13-1	612	Simulation current output active.
13-2	613	
13-3	614	
14-0	671	
14-1	672	Simulation status input active.
14-2	673	
14-3	674	
14-4	691	Simulation of response to error (outputs) active.
14-5	692	Simulation of volume flow is active.
14-7	471	The maximum permitted batching time was exceeded
15-0	472	Under batching: The minimum quantity was not reached. Over batching: The maximum permitted batching quantity was exceeded.
15-1	473	The predefined batch quantity point was exceeded. End of filling process approaching.
15-2	571	Batching process in progress (valves are open)
15-3	572	Batching process has been stopped (valves are closed)
15-4	339	
15-5	340	Flow buffer: The temporarily buffered flow portions (measuring mode for pulsating flow) could not be cleared or output within 60 seconds.
15-6	341	
15-7	342	
16-0	343	
16-1	344	Frequency buffer: The temporarily buffered flow portions (measuring mode for pulsating flow) could not be cleared or output within 60 seconds.
16-2	345	
16-3	346	
16-4	347	
16-5	348	Pulse buffer: The temporarily buffered flow portions (measuring mode for pulsating flow) could not be cleared or output within 60 seconds.
16-6	349	
16-7	350	
17-0	121	I/O board and the amplifier board are not compatible.
17-1	061	F-CHIP is defective or not on I/O board
17-2	363	Current input: Actual current value is out of range.
17-6	698	The measuring device is being checked on site via the test and simulation device.
17-7	474	Maximum flow value entered is overshot.

5.4.6 Switching HART write protection on and off


A jumper on the I/O board provides the means of activating or deactivating HART write protection.



Warning!

Risk of electric shock. Exposed components carry dangerous voltages. Make sure that the power supply is switched off before you remove the cover of the electronics compartment.

1. Switch off power supply.
2. Remove the I/O board → [Fig. 114](#)
3. Switch HART write protection on or off, as applicable, by means of the jumper (→ [Fig. 48](#)).
4. Installation of the I/O board is the reverse of the removal procedure.



a0001212

Fig. 48: Switching HART write protection on and off

1 Write protection OFF (default), i.e. HART protocol unlocked
2 Write protection ON, i.e. HART protocol locked

6 Commissioning

6.1 Function check


Make sure that all final checks have been completed before you start up your measuring point:

- Checklist for "Post-installation check" → [45](#)
- Checklist for "Post-connection check" → [58](#)

6.2 Switching on the measuring device

Once the connection checks have been successfully completed, it is time to switch on the power supply. The device is now operational.

The measuring device performs a number of post switch-on self-tests. As this procedure progresses the following sequence of messages appears on the local display:



Normal measuring mode commences as soon as startup completes.

Various measured value and/or status variables appear on the display (HOME position).



Note!

If startup fails, an error message indicating the cause is displayed.

6.3 Quick Setup

In the case of measuring devices without a local display, the individual parameters and functions must be configured by means of a configuration program, such as FieldCare from Endress+Hauser.

If the measuring device is equipped with a local display, all the important device parameters for standard operation can be configured quickly and easily by means of the following Quick Setup menus. Additional functions can be configured too.

- "Commissioning" Quick Setup menu → [84](#)
- "Pulsating flow" Quick Setup menu → [86](#)
- "Batching" Quick Setup menu → [86](#)

6.3.1 "Commissioning" Quick Setup menu



Note!

- The display returns to the cell SETUP COMMISSIONING (1002) if you press the ESC key combination during parameter interrogation. The stored parameters remain valid.
- The "Commissioning" Quick Setup must be carried out before any of the other Quick Setups described in this Operating Instructions are run.

① The DELIVERY SETTINGS option sets each selected unit to the factory setting.
The ACT.SETTING option accepts the units previously set by you.

② Only units not yet configured in the current setup are offered for selection in each cycle. The unit for mass and volume is derived from the corresponding flow unit.

③ The "YES" option remains visible until all the units have been configured.
"NO" is the only option displayed when no further units are available.

④ Only the outputs not yet configured in the current setup are offered for selection in each cycle.

⑤ The "YES" option remains visible until all the outputs have been parameterized.
"NO" is the only option displayed when no further outputs are available.

⑥ The "automatic parameterization of the display" option contains the following basic settings/factory settings

YES	Main line = volume flow Additional line = totalizer 1 Information line = operating/system conditions
NO	The existing (selected) settings remain.

⑦ The Quick Setup "Batching" is only available when the optional software package BATCHING is installed.




Fig. 49: Quick Setup for straightforward commissioning

A0005523-en

6.3.2 "Pulsating flow" Quick Setup menu



Note!


The "Pulsating flow" Quick Setup is only available if the device has a current output or a pulse/frequency output.

Certain pumps of a construction which necessitates a pulsating pumping action, such as reciprocating, peristaltic and cam-type pumps, create a flow characterized by severe periodic fluctuations. Negative flows can occur with pumps of these types on account of the closing volume of the valves or valve leaks.



Note!

Before carrying out the "Pulsating Flow" Quick Setup, the "Commissioning" Quick Setup must be executed → 84



a0001213

Fig. 50: Flow characteristics of various types of pump

A with severely pulsating flow
B with slightly pulsating flow

1	1-cylinder cam pump
2	2-cylinder cam pump
3	Magnetic pump
4	Peristaltic pump, flexible connecting hose
5	Multi-cylinder reciprocating pump

Severely pulsating flow

Once several device functions have been configured in the "Pulsating Flow" Quick Setup menu, flow fluctuations can be compensated over the entire flow range and pulsating liquid flows measured correctly. The following describes in detail how to use this Quick Setup menu.



Note!

It is always advisable to work run the "Pulsating Flow" Quick Setup if there is any uncertainty about the exact flow characteristic.

Slightly pulsating flow


If flow fluctuations are no more than minor, as is the case, for example with gear-type, three-cylinder or multi-cylinder pumps, it is **not** absolutely necessary to work through the "Pulsating Flow" menu.

In cases of this nature, however, it is advisable to adapt the functions listed below (see "Description of Device Functions" manual) to suit local process conditions in order to ensure a stable, unvarying output signal. This applies particularly to the current output:

- Measuring system damping: SYSTEM DAMPING function → increase the value
- Current output damping: TIME CONSTANT function → increase the value

Using the "Pulsating Flow" Quick Setup menu

This Quick Setup menu guides you systematically through the setup procedure for all the device functions that have to be configured for measuring pulsating flows. Note that this has no effect on values already configured, such as measuring range, current range or full scale value.



A0005524-en

Fig. 51: Quick Setup for measuring severely pulsating flows. Recommended settings see next page

- ① Only the output not yet configured in the current setup is offered for selection in the second cycle.
- ② The "YES" option remains visible until both outputs have been parameterized. "NO" is the only option displayed when no further outputs are available.
- ③ Only the outputs not yet configured in the current Setup are offered for selection in each cycle.
- ④ The "YES" option remains visible until all the outputs have been configured. "NO" is the only option displayed when no further outputs are available.



Note!

- The display returns to the cell QUICK SETUP PULSATING FLOW (1003) if you press the ESC key (Esc) during parameter interrogation.
- You can call up this setup menu either directly from the Commissioning Quick Setup menu or manually by means of the function QUICK SETUP PULSATING FLOW (1003).

"Pulsating flow" Quick Setup menu		
HOME position → [E] → MEASURED VARIABLE → [+] → QUICK SETUP → [E] → QS PULSATING FLOW (1003)		
Function No.	Function name	Select using [+] [-] Go to next function using [E]
1003	QS-PULS FLOW	YES After [E] is pressed by way of confirmation, the quick setup menu calls up all the subsequent functions in succession.

Basic configuration		
2002	DISPLAY DAMPING	3 s
3002	TOTALIZER MODE (DAA)	BALANCE (Totalizer 1)
3002	TOTALIZER MODE (DAB)	BALANCE (Totalizer 2)
3002	TOTALIZER MODE (DAC)	BALANCE (Totalizer 3)
Signal type for "CURRENT OUTPUT 1 to n"		
4004	MEASURING MODE	PULSATING FLOW
4005	TIME CONSTANT	1 s
Signal type for "PULSE/FREQ. OUTPUT 1 to n" (for FREQUENCY operating mode)		
4206	MEASURING MODE	PULSATING FLOW
4208	TIME CONSTANT	0 s
Signal type for "PULSE/FREQ. OUTPUT 1 to n" (for PULSE operating mode)		
4225	MEASURING MODE	PULSATING FLOW
Other settings		
8005	ALARM DELAY	0 s
6400	ASSIGN LOW FLOW CUT OFF	VOLUME FLOW
6402	ON-VALUE LOW FLOW CUT OFF	Recommended setting: On-value $\approx \frac{\text{max. full scale (per DN)*}}{1000}$ a0004432-en
6403	OFF-VALUE LOW FLOW CUT OFF	50%
6404	PRESSURE SHOCK SUPPRESSION	0 s

6.3.3 "Batching" Quick Setup menu



Note!

This function is only available when the additional "batching" software is installed in the measuring device (order option). You can order this software from Endress+Hauser as an accessory at a later date.

This Quick Setup menu guides you systematically through the setup procedure for all the device functions that have to be parameterized and configured for batching operation. These basic settings allow simple (one step) batching processes.

Additional settings, e.g. for the calculation of after runs or for multi-stage batching procedures, must be made via the function matrix itself (see the "Description of Device Functions" manual).



Caution!

The "Batching" Quick Setup sets certain device parameters for discontinuous measurement operation.

If the measuring instrument is used for continuous flow measurement at a later time, we recommend at you rerun the "Commissioning" and/or "Pulsating Flow" Quick Setup.



Note!

- Before carrying out the Quick Setup "Batching" the Quick Setup "Commissioning" has to be executed. → 84
- You can find detailed information on the batching functions in the separate "Description of Device Functions" manual.
- You can also directly control filling process using the local display. During Quick Setup, an appropriate dialog appears concerning the automatic display configuration. Acknowledge this by clicking "YES".

This assigns special batching functions (START, PRESET, MATRIX) to the bottom line of the display. These can be directly executed onsite using the three operating keys (⊕/⊖/⊖). Therefore, the measuring device can be fully deployed in the field as a "batch controller". → 62




Fig. 52: Quick Setup "Batching". Recommended settings see next page

a0004433-en

Recommended settings

"Batching" Quick Setup menu		
HOME-Position → [E] → MEASURED VARIABLE → [+] → QUICK SETUP → [E] → QUICK SETUP BATCHING (1005)		
Function No.	Function name	Setting to be selected ([+]) (to next function with [E])
1005	QUICK SETUP BATCHING / DOSING	YES After [E] is pressed by way of confirmation, the Quick Setup menu calls up all the subsequent functions in succession.
▼		
 Note! Functions with a gray background are configured automatically (by the measuring system itself)		
6400	ASSIGN LOW FLOW CUTOFF	VOLUME FLOW
6402	ON-VALUE LOW FLOW CUTOFF	Recommended settings see on → 88 in function 6402.
6403	OFF-VALUE LOW FLOW CUTOFF	50%
6603	SYSTEM DAMPING	9  Note! The parameter has to be optimized for highly accurate and short filling processes: to do this, put the setting to "0".
6404	PRESSURE SHOCK SUPPRESSION	0 seconds
7200	BATCH SELECTOR	BATCH #1
7201	BATCH NAME	BATCH #1
7202	ASSIGN BATCH VARIABLE	Volume
7203	BATCH QUANTITY	0
7204	FIX COMPENSATION QUANTITY	0
7205	COMPENSATION MODE	OFF
7208	BATCH STAGES	1
7209	INPUT FORMAT	Value input
4700	ASSIGN RELAY	BATCH VALVE 1
4780	TERMINAL NUMBER	Output (display only)
7220	OPEN VALVE 1	0% or 0 [unit]
7240	MAXIMUM BATCH TIME	0 seconds (= switched off)
7241	MINIMUM BATCH QUANTITY	
7242	MAXIMUM BATCH QUANTITY	
2200	ASSIGN (main line)	BATCH NAME
2220	ASSIGN (Multiplex main line)	OFF
2400	ASSIGN (additional line)	BATCH DOWNWARDS
2420	ASSIGN (Multiplex additional line)	OFF
2600	ASSIGN (information line)	BATCHING KEYS
2620	ASSIGN (Multiplex information line)	OFF
▼		
Back to the HOME position: → Press and hold down Esc key [Esc] for longer than three seconds or → Repeatedly press and release Esc key [Esc] → Exit the function matrix step by step		

6.3.4 Data backup/transmission

Using the T-DAT SAVE/LOAD function, you can transfer data (device parameters and settings) between the T-DAT (exchangeable memory) and the EEPROM (device storage unit).


This is required in the following instances:

- Creating a backup: current data are transferred from an EEPROM to the T-DAT.
- Replacing a transmitter: current data are copied from an EEPROM to the T-DAT and then transferred to the EEPROM of the new transmitter.
- Duplicating data: current data are copied from an EEPROM to the T-DAT and then transferred to EEPROMs of identical measuring points.



Note!

For information on installing and removing the T-DAT → 114



a0001221-en

Fig. 53: Data backup/transmission with T-DAT SAVE/LOAD function

Information on the LOAD and SAVE options available:

LOAD: Data are transferred from the T-DAT to the EEPROM.



Note!

- Any settings already saved on the EEPROM are deleted.
- This option is only available, if the T-DAT contains valid data.
- This option can only be executed if the software version of the T-DAT is the same or newer than that of the EEPROM. Otherwise, the error message "TRANSM. SW-DAT" appears after restarting and the LOAD function is then no longer available.

SAVE:

Data are transferred from the EEPROM to the T-DAT

6.4 Configuration

6.4.1 Current outputs: active/passive

The current outputs can be configured as "active" or "passive" by means of various jumpers on the I/O board or on the current submodule.



Caution!

The configuration of the current outputs as "active" or "passive" is only possible on non-Ex i I/O boards. Ex i I/O boards are permanently wired as "active" or "passive". See Table → 53



Warning!

Risk of electric shock. Exposed components carry dangerous voltages. Make sure that the power supply is switched off before you remove the cover of the electronics compartment.

1. Switch off power supply
2. Remove the I/O board → 114
3. Position jumpers → 54, → 55



Caution!

- Risk of destroying the measuring device. Set the jumpers exactly as shown in the diagrams. Incorrectly set jumpers can cause overcurrents that would destroy either the measuring device or external devices connected to it.
- Note that the position of the current submodule on the I/O board can vary, depending on the version ordered, and that the terminal assignment in the connection compartment of the transmitter varies accordingly → 53.

4. Installation of the I/O board is the reverse of the removal procedure.




Fig. 54: Configuring the current outputs with the aid of jumpers (convertible I/O board)

1	Current output 1 with HART
1.1	Active current output (factory setting)
1.2	Passive current output
2	Current output 2 (optional, plug-in module)
2.1	Active current output (factory setting)
2.2	Passive current output

a0001214




Fig. 55: Configuring the current output with the aid of jumpers (fixed I/O board)

1 Active current output (factory setting)
2 Passive current output

6.4.2 Current input: active/passive


The current input can be configured as "active" or "passive" by means of various jumpers on the current input submodule.



Warning!

Risk of electric shock. Exposed components carry dangerous voltages. Make sure that the power supply is switched off before you remove the cover of the electronics compartment.

1. Switch off power supply
2. Remove the I/O board → [514](#)
3. Position jumpers → [56](#)



Caution!

- Risk of destroying the measuring device. Set the jumpers exactly as shown in the diagram. Incorrectly set jumpers can cause overcurrents that would destroy either the measuring device or external devices connected to it.
- Note that the position of the current input submodule on the I/O board can vary, depending on the version ordered, and that the terminal assignment in the connection compartment of the transmitter varies accordingly → [53](#).

4. Installation of the I/O board is the reverse of the removal procedure.




Fig. 56: Configuring the current input with the aid of jumpers (I/O board)

1	Active current input (factory setting)
2	Passive current input

A0005124

6.4.3 Relay contacts: Normally closed/normally open

The relay contact can be configured as normally open (NO or make) or normally closed (NC or break) contacts by means of two jumpers on the I/O board or on the relay submodule respectively. This configuration can be called up at any time with the ACTUAL STATUS RELAY function (4740).



Warning!

Risk of electric shock. Exposed components carry dangerous voltages. Make sure that the power supply is switched off before you remove the cover of the electronics compartment.

1. Switch off power supply
2. Remove the I/O board → [Fig. 114](#)
3. Position jumpers → [Fig. 57](#), → [Fig. 58](#)

Caution!

- If you change the setting you must always change the positions of **both** jumpers. Set the jumpers exactly as indicated.
- Note that the position of the relay submodule on the I/O board can vary, depending on the version ordered, and that the terminal assignment in the connection compartment of the transmitter varies accordingly → [Fig. 53](#).

4. Installation of the I/O board is the reverse of the removal procedure.




Fig. 57: Configuring relay contacts (NC/NO) for the flexible module board.

1 Configured as NO contact (factory setting, relay 1)
 2 Configured as NC contact (factory setting, relay 2, if installed)




Fig. 58: Configuring relay contacts (NC/NO) for the fixed module board.
 A = relay 1; B = relay 2

1 Configured as NO contact (factory setting, relay 1)
 2 Configured as NC contact (factory setting, relay 2)

6.5 Adjustment

6.5.1 Empty-pipe/Full-pipe adjustment

Flow cannot be measured correctly unless the measuring pipe is completely full. This status can be monitored at all times with the Empty Pipe Detection function:

- EPD = Empty Pipe Detection (with the help of an EPD electrode)
- OED = Open Electrode Detection (Empty Pipe Detection with the help of the measuring electrodes, if the sensor is not equipped with an EPD electrode or the orientation is not suitable for using EPD).



Caution!

A **detailed** description and other helpful hints for the empty-pipe/full-pipe adjustment procedure can be found in the separate "Description of Device Functions" Manual:

- EPD/OED ADJUSTMENT (6481) → Carrying out the adjustment.
- EPD (6420) → Switching on and off EPD/OED.
- EPD RESPONSE TIME (6425) → Input of the response time for EPD/OED.



Note!

- The EPD function is not available unless the sensor is fitted with an EPD electrode.
- The devices are already calibrated at the factory with water (approx. 500 $\mu\text{S}/\text{cm}$). If the liquid conductivity differs from this reference, empty-pipe/full-pipe adjustment has to be performed again on site.
- The default setting for EPD/OED when the devices are delivered is OFF; the function has to be activated if required.
- The EPD/OED process error can be output by means of the configurable relay outputs.

Performing empty-pipe and full-pipe adjustment (EPD/OED)

1. Select the corresponding function in the function matrix:
HOME → **E** → **+** → BASIC FUNCTIONS → **E** → **+** → PROCESS PARAMETERS
→ **E** → **+** → ADJUSTMENT → **E** → EPD/OED ADJUSTMENT
2. Empty the piping. In case of an EPD adjustment, the wall of the measuring tube should be wetted with fluid for the adjustment procedure but this is not the case with an OED adjustment!
3. Start empty-pipe adjustment: Select "EMPTY PIPE ADJUST" or "OED EMPTY ADJUST" and press **E** to confirm.
4. After empty-pipe adjustment, fill the piping with fluid.
5. Start full-pipe adjustment: Select "FULL PIPE ADJUST" or "OED FULL ADJUST" and press **E** to confirm.
6. Having completed the adjustment, select the setting "OFF" and exit the function by pressing **E**.
7. Now select the "EPD" function (6420). Switch on Empty Pipe Detection by selecting the following settings:
 - EPD → Select ON STANDARD or ON SPECIAL and press **E** to confirm.
 - OED → Select OED and confirm with **E**.



Caution!

The adjustment coefficients must be valid before you can activate the EPD/OED function. If adjustment is incorrect the following messages might appear on the display:

- ADJUSTMENT FULL = EMPTY
The adjustment values for empty pipe and full pipe are identical. In such instances, empty-pipe adjustment/full-pipe adjustment **must** be carried out again.
- ADJUSTMENT NOT OK
Adjustment is not possible because the fluid's conductivity is out of range.

6.6 Data storage devices

At Endress+Hauser, the term HistoROM refers to various types of data storage modules on which process and measuring device data are stored. By plugging and unplugging such modules, device configurations can be duplicated onto other measuring devices to cite just one example.

6.6.1 HistoROM/S-DAT (sensor DAT)

The S-DAT is an exchangeable data storage device in which all sensor data are stored, i.e., nominal diameter, serial number, calibration factor, zero point.

6.6.2 HistoROM/T-DAT (transmitter DAT)

The T-DAT is an exchangeable data storage device in which all transmitter parameters and settings are stored.

Storing of specific parameter settings from the device memory (EEPROM) to the T-DAT module and vice versa must be carried out by the user (= manual save function). Detailed instructions regarding this can be found on → 92.

6.6.3 F-CHIP (function chip)

The F-CHIP is a microprocessor component which contains additional software packages which are used to enhance the functionality and therefore the range of application of the transmitter.

If an upgrade is carried out at a later stage, the F-CHIP can be ordered as an accessory and can simply be inserted into the I/O board. After startup, the transmitter can access this software immediately.

Accessories → 100

Inserting into the I/O board → 113



Caution!

To avoid any confusion, once the F-CHIP has been put on the I/O board, it is labeled with the transmitter's serial number i.e. the F-CHIP can then no longer be used for another measuring device.

7 Maintenance

No special maintenance work is required.

7.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

7.2 Seals

The seals in the Promag H sensor should be replaced periodically, particularly when molded seals (aseptic version) are used!

The interval between replacements depends on the frequency of the cleaning cycles and on the temperature of the fluid and of the cleaning process.

Replacement seals (accessory) →  100.

8 Accessories

Various accessories, which can be ordered separately from Endress+Hauser, are available for the transmitter and the sensor. Your Endress+Hauser service organization can provide detailed information on the order code of your choice.

8.1 Device-specific accessories

Accessory	Description	Order code
Transmitter Promag 53	Transmitter for replacement or for stock. Use the order code to define the following specifications: <ul style="list-style-type: none">- Approvals- Degree of protection / version- Cable type for remote version- Cable entries- Display / power supply / operation- Software- Outputs / inputs	53XXX - XXXXX * * * * *
Software packages for Promag 53	Software add-ons on F-CHIP, can be ordered individually: <ul style="list-style-type: none">- Electrode Cleaning Circuitry (ECC)- Batching	DK5SO-*
Conversion kit for outputs/inputs	Conversion kit with appropriate plug-in point modules to change the current input/output configuration to a new version.	DKUI-*

8.2 Accessories specific to measuring principle

Accessory	Description	Order code
Mounting kit for Promag 53 transmitter	Mounting kit for wall-mount housing (remote version). Suitable for: <ul style="list-style-type: none">■ Wall mounting■ Pipe mounting■ Panel mounting Mounting set for aluminum field housing. Suitable for Pipe mounting.	DK5WM - *
Cable for remote version	Coil and signal cables, various lengths. Reinforced cable on request.	DK5CA - **
Ground cable for Promag E/L/P/W	A set consists of two ground cables.	DK5GC - ***
Ground disk for Promag E/L/P/W	Ground disk for potential equalization.	DK5GD - * * * *
Mounting kit for Promag H	Mounting kit for Promag H, consisting of: <ul style="list-style-type: none">■ 2 Process connections■ Screws■ Seals	DKH ** - * * * *
Adapter connection for Promag A/H	Adapter connections for installation of Promag 53 H instead of Promag 30/33 A or Promag 30/33 H/DN 25.	DK5HA - * * * * *
Grounding rings for Promag H	If the process connections are made of PVC or PVDF, ground rings are necessary to ensure that potential is matched. A set comprises 2 ground rings.	DK5HR - ***
Seal set for Promag H	For regular replacement of seals in the Promag H sensor.	DK5HS - ***
Wall mounting kit Promag H	Wall mounting kit for Promag H transmitter.	DK5HM - **
Welding jig for Promag H	Weld nipple as process connection: Welding jig for installation in piping.	DK5HW - ***

8.3 Communication-specific accessories

Accessory	Description	Order code
HART Communicator Field Xpert SFX 100	Handheld terminal for remote configuration and for obtaining measured values via the 4 to 20 mA HART current output. Contact your Endress+Hauser representative for more information.	SFX100 – *****
Fieldgate FXA320	Gateway for remote interrogation of HART sensors and actuators via Web browser: <ul style="list-style-type: none">▪ 2-channel analog input (4 to 20 mA)▪ 4 binary inputs with event counter function and frequency measurement▪ Communication via modem, Ethernet or GSM▪ Visualization via Internet/Intranet in Web browser and/or WAP cellular phone▪ Limit value monitoring with alarm by e-mail or SMS▪ Synchronized time stamping of all measured values.	FXA320 – ****
Fieldgate FXA520	Gateway for remote interrogation of HART sensors and actuators via Web browser: <ul style="list-style-type: none">▪ Web server for remote monitoring of up to 30 measuring points▪ Intrinsically safe version [EEx ia]IIC for applications in hazardous areas▪ Communication via modem, Ethernet or GSM▪ Visualization via Internet/Intranet in Web browser and/or WAP cellular phone▪ Limit value monitoring with alarm by e-mail or SMS▪ Synchronized time stamping of all measured values▪ Remote diagnosis and remote configuration of connected HART devices	FXA520 – ****
FXA195	The Commubox FXA195 connects intrinsically safe Smart transmitters with HART protocol to the USB port of a personal computer. This makes the remote operation of the transmitters possible with the aid of configuration programs (e.g. FieldCare). Power is supplied to the Commubox by means of the USB port	FXA195 – *

8.4 Service-specific accessories

Accessory	Description	Order code
Applicator	Software for selecting and configuring flowmeters. Applicator can be downloaded from the Internet or ordered on CD-ROM for installation on a local PC. Contact your Endress+Hauser representative for more information.	DXA80 - *
Fieldcheck	Tester/simulator for testing flowmeters in the field. When used in conjunction with the "FieldCare" software package, test results can be imported into a database, printed and used for official certification. Contact your Endress+Hauser representative for more information.	50098801
FieldCare	FieldCare is Endress+Hauser's FDT-based plant asset management tool. It can configure all intelligent field devices in your plant and supports you in the administration of these devices. Through the use of status information, it is also an easy but effective means of monitoring the status of these devices.	See product list on the Endress+Hauser website: www.endress.com
FXA193	Service interface of device to the PC for operation via FieldCare.	FXA193 - *
Memograph M graphic display recorder	The Memograph M graphic display recorder provides information on all relevant process variables: Measuring values are recorded reliably, limit values monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on an SD card or USB stick. The PC software package ReadWin® 2000, which is supplied as standard, is used for configuration, visualization and storage of the recorded data.	RSG40-*****

9 Troubleshooting

9.1 Troubleshooting instructions

If faults occur after commissioning or during operation, always start troubleshooting with the checklist below. The routine takes you directly to the cause of the problem and the appropriate remedial measures.



Caution!

In the event of a serious fault, a flowmeter might have to be returned to the manufacturer for repair. The necessary procedures must be carried out before you return the device to Endress+Hauser → 5.

Always enclose a duly completed "Declaration of Contamination" form. You will find a preprinted blank of this form at the back of this manual.

Check the display	
No display visible and no output signals present.	<ol style="list-style-type: none"> 1. Check the supply voltage → terminals 1, 2 2. Check the power line fuse → 118 85 to 260 V AC: 0.8 A slow-blow / 250 V 20 to 55 V AC / 16 to 62 V DC: 2 A slow-blow / 250 V 3. Measuring electronics defective → order spare parts → 113
No display visible, but output signals are present.	<ol style="list-style-type: none"> 1. Check whether the ribbon-cable connector of the display module is correctly plugged into the amplifier board → 113 2. Display module defective → order spare parts → 113 3. Measuring electronics defective → order spare parts → 113
Display texts are in a foreign language.	Switch off power supply. Press and hold down both the OS buttons and switch on the measuring device. The display text will appear in English (default) and is displayed at maximum contrast.
Measured value indicated, but no signal at the current or pulse output.	Electronics board defective → order spare parts → 113



Status signals on display (only HART 7)	
The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).	
The status signals are categorized according to VDI/VDE 2650 and NAMUR Recommendation NE 107: F = Failure, C = Function Check, S = Out of Specification, M = Maintenance Required	
Category F (Failure)	A device error has occurred. The measured value is no longer valid.
Category C (Function check)	The device is in service mode (e.g. during a simulation).
Category S (Out of specification)	The device is operated: <ul style="list-style-type: none"> ▪ Outside its technical specification limits (e.g. outside the process temperature range) ▪ Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA-Value)
Category M (Maintenance required)	Maintenance is required. The measured value remains valid.



Error messages on display	
Errors which occur during commissioning or operation are displayed immediately. Error messages consist of a variety of icons. The meanings of these icons are as follows (example):	
<ul style="list-style-type: none"> - Error type: S = system error, P = process error - Error message type: ! = fault message, ! = notice message - EMPTY PIPE = type of error, e.g. measuring tube is only partly filled or completely empty - 03:00:05 = duration of error occurrence (in hours, minutes and seconds) - #401 = error number 	
 Caution!	
	<ul style="list-style-type: none"> ■ Also observe the information on → 65 ■ The measuring system interprets simulations and positive zero return as system errors, but displays them only as a notice message.
Error number: No. 001 – 399 No. 501 – 699	System error (device error) has occurred → 104
Error number: No. 401 – 499	Process error (application error) has occurred → 108

Other errors (without error message)	
Some other errors have occurred.	Diagnosis and rectification → 110

9.2 System error messages

Serious system errors are **always** recognized by the device as "Fault message", and are shown as a lightning flash (**!**) on the display. Fault messages immediately affect the outputs.



Caution!

In the event of a serious fault, a flowmeter might have to be returned to the manufacturer for repair. The necessary procedures on → 121 must be carried out before you return a flowmeter to Endress+Hauser. Always enclose a duly completed "Declaration of Contamination" form. You will find a master copy of this form at the back of this manual.



Note!

Also observe the information on → 65.

No.	Error message / Type	Status signals (from the factory, only HART 7)	Cause	Remedy (spare part → 113)
-----	----------------------	---	-------	---------------------------

S = System error

! = Fault message (with an effect on the outputs)

! = Notice message (without an effect on the outputs)

No. # 0xx → Hardware error

001	S: CRITICAL FAILURE !: # 001	F	Serious device error	Replace the amplifier board.
011	S: AMP HW EEPROM !: # 011	F	Amplifier: Defective EEPROM	Replace the amplifier board.
012	S: AMP SW EEPROM !: # 012	F	Amplifier: Error accessing EEPROM data	<p>The EEPROM data blocks in which an error has occurred are displayed in the TROUBLESHOOTING function.</p> <p>Press Enter to acknowledge the errors in question; default values are automatically inserted instead of the errored parameter values.</p>



Note!

The measuring device has to be restarted if an error has occurred in a totalizer block (see error No. 111 / CHECKSUM TOTAL).

No.	Error message / Type	Status signals (from the factory, only HART 7)	Cause	Remedy (spare part → 113)
031	S: SENSOR HW DAT !: # 031	F	1. S-DAT is not plugged into the amplifier board correctly (or is missing). 2. S-DAT is defective.	1. Check whether the S-DAT is correctly plugged into the amplifier board. 2. Replace the S-DAT if it is defective. Check that the new replacement DAT is compatible with the measuring electronics. Check the: – Spare part set number – Hardware revision code 3. Replace measuring electronics boards if necessary. 4. Plug the S-DAT into the amplifier board.
032	S: SENSOR SW DAT !: # 032	F		
041	S: TRANSM. HW-DAT !: # 041	F	Transmitter DAT: 1. T DAT is not correctly plugged into the amplifier board (or is missing). 2. T-DAT is defective.	1. Check whether the T-DAT is correctly plugged into the amplifier board. 2. Replace the T-DAT if it is defective. Check that the new replacement DAT is compatible with the measuring electronics. Check the: – Spare part set number – Hardware revision code 3. Replace measuring electronics boards if necessary. 4. Plug the T-DAT into the amplifier board.
042	S: TRANSM. SW-DAT !: # 042	F	Transmitter DAT: Error accessing the calibration values stored in the S-DAT.	
061	S: HW F-CHIP !: # 061	F	Transmitter F-CHIP: 1. F-CHIP is defective. 2. F-CHIP is not plugged into the I/O board or is missing.	1. Replace the F-CHIP. Accessories → 100 2. Plug the F-CHIP into the I/O board → 114
No. # 1xx → Software error				
101	S: GAIN ERROR AMP !: # 101	F	Gain deviation compared to reference gain > 25%.	Replace the amplifier board.
111	S: CHECKSUM TOTAL !: # 111	F	Totalizer checksum error.	1. Restart the measuring device. 2. Replace the amplifier board if necessary.
121	S: A / C COMPATIB. !: # 121	F	Due to different software versions, I/O board and amplifier board are only partially compatible (possibly restricted functionality). Note! – The indication on the display as notice message appears only for 30 seconds (with listing in "Previous system condition" function). – This condition can occur if only one electronics board has been exchanged; the extended software functionality is not available. The previously existing software functionality is still working and the measurement possible.	Module with lower software version has either to be updated by FieldCare with the required software version or the module has to be replaced.
No. # 2xx → Error in DAT / no communication				
205	S: LOAD T-DAT !: # 205	M	Transmitter DAT: Data backup (downloading) to T-DAT failed, or error when accessing (uploading) the calibration values stored in the T-DAT.	1. Check whether the T-DAT is correctly plugged into the amplifier board → 114 2. Replace the T-DAT if it is defective. Before replacing the DAT, check that the new, replacement DAT is compatible with the measuring electronics. Check the: – Spare part set number – Hardware revision code 3. Replace measuring electronics boards if necessary.
206	S: SAVE T-DAT !: # 206	M		

No.	Error message / Type	Status signals (from the factory, only HART 7)	Cause	Remedy (spare part → 113)
251	S: COMMUNICATION I/O !: # 251	F	Internal communication error on amplifier board.	Replace the amplifier board.
261	S: COMMUNICATION I/O !: # 261	F	No data reception between amplifier and I/O board or faulty internal data transfer.	Check the BUS contacts.
No. # 3xx → System limits exceeded				
321	S: TOL. COIL CURR. !: # 321	F	Sensor: Coil current is out of tolerance.	<p> Warning! Switch off power supply before manipulating the coil current cable, coil current cable connector or measuring electronics boards!</p> <p>Remote version:</p> <ol style="list-style-type: none"> 1. Check wiring of terminals 41/42 → 46 2. Check coil current cable connector. <p>Compact and remote version: If the error can not be resolved, please contact your local Endress+Hauser service organization.</p>
339 to 342	S: STACK CUR OUT n !: # 339 to 342	S	The temporarily buffered flow portions (measuring mode for pulsating flow) could not be cleared or output within 60 seconds.	<ol style="list-style-type: none"> 1. Change the upper or lower limit setting, as applicable. 2. Increase or reduce flow, as applicable. <p>Recommendations in the event of fault category = FAULT MESSAGE (!)</p> <ul style="list-style-type: none"> Configure the fault response of the output to "ACTUAL VALUE" so that the temporary buffer can be cleared. Clear the temporary buffer by the measures described under Item 1.
343 to 346	S: STACK FREQ. OUT n !: # 343 to 346	S	The temporarily buffered flow portions (measuring mode for pulsating flow) could not be cleared or output within 60 seconds.	<ol style="list-style-type: none"> 1. Increase the setting for pulse weighting 2. Increase the max. pulse frequency if the totalizer can handle a higher number of pulses. 3. Increase or reduce flow, as applicable. <p>Recommendations in the event of fault category = FAULT MESSAGE (!)</p> <ul style="list-style-type: none"> Configure the fault response of the output to "ACTUAL VALUE" so that the temporary buffer can be cleared. Clear the temporary buffer by the measures described under Item 1.
347 to 350	S: STACK PULSE OUT n !: # 343 to 346	S	The temporarily buffered flow portions (measuring mode for pulsating flow) could not be cleared or output within 60 seconds.	<ol style="list-style-type: none"> 1. Increase the setting for pulse weighting 2. Increase the max. pulse frequency if the totalizer can handle a higher number of pulses. 3. Increase or reduce flow, as applicable. <p>Recommendations in the event of fault category = FAULT MESSAGE (!)</p> <ul style="list-style-type: none"> Configure the fault response of the output to "ACTUAL VALUE" so that the temporary buffer can be cleared. Clear the temporary buffer by the measures described under Item 1.
351 to 354	S: CURRENT RANGE n !: # 351 to 354	S	Current output: flow is out of range.	<ol style="list-style-type: none"> 1. Change the upper or lower limit setting, as applicable. 2. Increase or reduce flow, as applicable.
355 to 358	S: FREQ. RANGE n !: # 355 to 358	S	Frequency output: flow is out of range.	<ol style="list-style-type: none"> 1. Change the upper or lower limit setting, as applicable. 2. Increase or reduce flow, as applicable.

No.	Error message / Type	Status signals (from the factory, only HART 7)	Cause	Remedy (spare part → 113)
359 to 362	S: PULSE RANGE !: # 359 to 362	S	Pulse output: the pulse output frequency is out of range.	<ol style="list-style-type: none"> 1. Increase the setting for pulse weighting 2. When selecting the pulse width, choose a value that can still be processed by a connected counter (e.g. mechanical counter, PLC etc.). <p><i>Determine the pulse width:</i></p> <ul style="list-style-type: none"> - Variant 1: Enter the minimum duration that a pulse must be present at the connected counter to ensure its registration. - Variant 2: Enter the maximum (pulse) frequency as the half "reciprocal value" that a pulse must be present at the connected counter to ensure its registration. <p>Example: The maximum input frequency of the connected counter is 10 Hz. The pulse width to be entered is:</p> $\frac{1}{2 \cdot 10 \text{ Hz}} = 50 \text{ ms}$ <p style="text-align: right;">a0004437</p> <ol style="list-style-type: none"> 3. Reduce flow.
363	S: CUR IN. RANGE !: # 363	S	Current input: The actual value for the current lies outside the set limits.	<ol style="list-style-type: none"> 1. Change set lower-range or upper-range value. 2. Check settings of the external sensor.
No. # 5xx → Application error				
501	S: SW.-UPDATE ACT. !: # 501	-	New amplifier or communication (I/O module) software version is loaded. Currently no other functions are possible.	Wait until the procedure is finished. The device will restart automatically.
502	S: UP-/DOWNLOAD ACT !: # 502	C	Uploading or downloading the device data via operating program. Currently no other functions are possible.	Wait until the procedure is finished.
571	S: BATCH RUNNING !: # 571	-	Batching is started and active (valves are open).	No measures needed (during the batching process some other functions may not be activated).
572	S: BATCH HOLD !: # 572	-	Batching has been interrupted (valves are closed).	<ol style="list-style-type: none"> 1. Continue batching with command "GO ON". 2. Interrupt batching with "STOP" command.
No. # 6xx → Simulation mode active				
601	S: POS. ZERO-RETURN !: # 601	C ¹⁾	Positive zero return active  Caution! This message has the highest display priority!	Switch off positive zero return
611 to 614	S: SIM. CURR. OUT. n !: # 611 to 614	C	Simulation current output active	Switch off simulation
621 to 624	S: SIM. FREQ. OUT. n !: # 621 to 624	C	Simulation frequency output active	Switch off simulation
631 to 634	S: SIM. PULSE n !: # 631 to 634	C	Simulation pulse output active	Switch off simulation
641 to 644	S: SIM. STAT. OUT n !: # 641 to 644	C	Simulation status output active	Switch off simulation
651 to 654	S: SIM. RELAY n !: # 651 to 654	C	Simulation relay output active.	Switch off simulation.

No.	Error message / Type	Status signals (from the factory, only HART 7)	Cause	Remedy (spare part → 113)
661	S: SIM. CURR. IN n !: # 661	C	Simulation current input active.	Switch off simulation.
671 to 674	S: SIM. STATUS IN n !: # 671 to 674	C	Simulation status input active	Switch off simulation
691	S: SIM. FAILSAFE !: # 691	C	Simulation of response to error (outputs) active	Switch off simulation
692	S: SIM. MEASURAND !: # 692	C	Simulation of a measured variable active (e.g. mass flow).	Switch off simulation
698	S: DEV. TEST ACT. !: # 698	C	The measuring device is being checked on site via the test and simulation device.	-
1) Status signal is changeable.				

9.3 Process error messages



Note!

Also observe the information on → 65.

No.	Error message / Type	Status signals (from the factory, only HART 7)	Cause	Remedy (spare part → 113)
P = Process error F = Fault message (with an effect on the outputs) N = Notice message (without an effect on the outputs)				
401 EMPTY PIPE !: # 401				
S ¹⁾ Measuring tube partially filled or empty				
401			1. Check the process conditions of the plant 2. Fill the measuring tube	
461	ADJ. NOT OK !: # 461	S	EPD calibration not possible because the fluid's conductivity is either too low or too high.	The EPD function cannot be used with fluids of this nature.
463	FULL = EMPTY !: # 463	M	The EPD calibration values for empty pipe and full pipe are identical, therefore incorrect.	Repeat calibration, making sure procedure is correct → 97.

No.	Error message / Type	Status signals (from the factory, only HART 7)	Cause	Remedy (spare part → 113)
471	P: > BATCH TIME !: # 471	S	The maximum permitted batching time was exceeded.	<ol style="list-style-type: none"> 1. Increase flow rate. 2. Check valve (opening). 3. Adjust time setting to changed batch quantity. <p> Note! If the errors listed above occur, these are displayed in the Home position flashing continuously.</p> <ul style="list-style-type: none"> ▪ General: These error messages can be reset by configuring any batching parameter. It is sufficient to confirm with the OS key and then the F key. ▪ Batching via status input: The error message can be reset by means of a pulse. Another pulse then restarts the batching. ▪ Batching via operating keys (soft keys) The error message is reset by pressing the START key. Pressing the START key a second time starts the batching process. ▪ Batching via the BATCHING PROCESS function (7260): The error message can be reset by pressing the STOP, START, HOLD or GO ON keys. Pressing the START key a second time starts the batching process.
472	P: >< BATCH QUANTITY !: # 472	S	<ul style="list-style-type: none"> - Underbatching: The minimum quantity was not reached. - Overbatching: The maximum permitted batching quantity was exceeded. 	<p>Underbatching:</p> <ol style="list-style-type: none"> 1. Increase fixed correction quantity. 2. Valve closes too quickly with active after run correction. Enter smaller after run as mean value. 3. If the batching quantity changes, the minimum batching quantity must be adjusted. <p>Overbatching:</p> <ol style="list-style-type: none"> 1. Reduce fixed correction quantity. 2. Valve closes too slowly with active after run correction. Enter larger after run as mean value. 3. If the batching quantity changes, the maximum batching quantity must be adjusted. <p> Note! Please observe Note in error message No. 471</p>
473	P: PROGRESS NOTE !: # 473	-	End of filling process approaching. The running filling process has exceeded the predefined batch quantity point for the display warning message.	No measures required (if necessary prepare to replace container).
474	P: MAX. FLOW !: # 474	S	Maximum flow value entered is overshot.	<p>Reduce the flow value.</p> <p> Note! Please observe Note in error message No. 471</p>
1) Status signal is changeable.				

9.4 Process errors without messages

Symptoms	Rectification
 Note! <p>You may have to change or correct certain settings in functions in the function matrix in order to rectify the fault. The functions outlined below, such as DISPLAY DAMPING, are described in detail in the "Description of Device Functions" manual.</p>	
Flow values are negative, even though the fluid is flowing forwards through the pipe.	<ol style="list-style-type: none"> 1. Remote version: <ul style="list-style-type: none"> – Switch off the power supply and check the wiring → 46 – If necessary, reverse the connections at terminals 41 and 42 2. Change the setting in the "INSTALLATION DIRECTION SENSOR" function accordingly
Measured-value reading fluctuates even though flow is steady.	<ol style="list-style-type: none"> 1. Check grounding and potential equalization → 55 2. The medium is too inhomogeneous. Check the following medium characteristics: <ul style="list-style-type: none"> – Gas bubble percentage too high? – Solids percentage too high? – Conductivity fluctuations too high? 3. SYSTEM DAMPING function → increase value (→ BASIC FUNCTION/SYSTEMPARAMETER/CONFIGURATION) 4. TIME CONSTANT function → increase value (→ OUTPUTS/CURRENT OUTPUT/CONFIGURATION) 5. DISPLAY DAMPING function → increase value (→ USER INTERFACE / CONTROL/BASIC CONFIGURATION)
Measured-value reading or measured-value output pulsates or fluctuates, e.g. because of reciprocating pump, peristaltic pump, diaphragm pump or pump with similar delivery characteristic.	Run the "Pulsating flow" Quick Setup → 86 If the problem persists despite these measures, a pulsation damper will have to be installed between pump and measuring device.
There are differences between the flowmeter's internal totalizer and the external metering device.	This symptom is due primarily to backflow in the piping, because the pulse output cannot subtract in the STANDARD or SYMMETRY measuring modes. There is the following solution: The flow in both directions should be taken into account. Set the MEASURING MODE function to PULSATING FLOW for the pulse output in question.
Measured-value reading shown on display, even though the fluid is at a standstill and the measuring tube is full.	<ol style="list-style-type: none"> 1. Check grounding and potential equalization → 53 2. Check the fluid for presence of gas bubbles. 3. Activate ON-VALUE LOW FLOW CUT OFF function, i.e. enter or increase on value (→ BASIC FUNCTION/PROCESSPARAMETER/CONFIGURATION).
Measured-value reading on display, even though measuring tube is empty.	<ol style="list-style-type: none"> 1. Perform empty-pipe/full-pipe adjustment and then switch on empty pipe detection → 97 2. Remote version: Check the terminals of the EPD cable → 46 3. Fill the measuring tube.
The current output signal is always 4 mA, irrespective of the flow signal at any given time.	<ol style="list-style-type: none"> 1. Select the BUS ADDRESS function and change the setting to "0". 2. Low flow cutoff too high → reduce the relevant value in the ON-VALUE LOW FLOW CUT OFF function.
The fault cannot be rectified or some other fault not described above has arisen. In these instances, please contact your Endress+Hauser service organization.	The following options are available for tackling problems of this nature: <ul style="list-style-type: none"> ▪ Request the services of an Endress+Hauser service technician If you contact our service organization to have a service technician sent out, please be ready to quote the following information: <ul style="list-style-type: none"> – Brief description of the fault – Nameplate specifications (→ 6): order code, serial number ▪ Returning devices to Endress+Hauser The necessary procedures (→ 121) must be carried out before you return a flowmeter requiring repair or calibration to Endress+Hauser. Always enclose a duly completed "Declaration of Conformity" form with the flowmeter. You will find a master copy of this form at the back of this manual. ▪ Replace transmitter electronics Components in the measuring electronics defective → order spare parts → 113

9.5 Response of outputs to errors



Note!

The failsafe mode of current, pulse and frequency outputs can be customized by means of various functions in the function matrix. You will find detailed information on these procedures in the "Description of Device Functions" manual.

You can use positive zero return to reset the signals of the current, pulse and frequency outputs to their fallback value, for example when measuring has to be interrupted while a pipe is being cleaned. This function takes priority over all other device functions: simulations, for example, are suppressed.

Error response mode of outputs		
	System/process error is current	Positive zero return is activated
 Caution! System or process errors defined as "Notice messages" have no effect whatsoever on the inputs and outputs. See the information on → 65		
Current output	MINIMUM VALUE 0-20 mA → 0 mA 4-20 mA → 2 mA 4-20 mA HART → 2 mA 4-20 mA NAMUR → 3.5 mA 4-20 mA HART NAMUR → 3.5 mA 4-20 mA US → 3.75 mA 4-20 mA HART US → 3.75 mA 0-20 mA (25 mA) → 0 mA 4-20 mA (25 mA) → 2 mA 4-20 mA (25 mA) HART → 2 mA MAXIMUM VALUE 0-20 mA → 22 mA 4-20 mA → 22 mA 4-20 mA HART → 22 mA 4-20 mA NAMUR → 22.6 mA 4-20 mA HART NAMUR → 22.6 mA 4-20 mA US → 22.6 mA 4-20 mA HART US → 22.6 mA 0-20 mA (25 mA) → 25 mA 4-20 mA (25 mA) → 25 mA 4-20 mA (25 mA) HART → 25 mA HOLD VALUE Last valid value (preceding occurrence of the fault) is output. ACTUAL VALUE Fault is ignored, i.e. normal measured-value output on the basis of ongoing flow measurement.	Output signal corresponds to "zero flow"
Pulse output	FALBACK VALUE Signal output → no pulses HOLD VALUE Last valid value (preceding occurrence of the fault) is output. ACTUAL VALUE Fault is ignored, i.e. normal measured-value output on the basis of ongoing flow measurement.	Output signal corresponds to "zero flow"

Error response mode of outputs		
	System/process error is current	Positive zero return is activated
Frequency output	<p>FALLBACK VALUE Signal output → 0 Hz</p> <p>FAILSAFE LEVEL Output of the frequency specified in the FAILSAFE VALUE function (4211).</p> <p>HOLD VALUE Last valid value (preceding occurrence of the fault) is output.</p> <p>ACTUAL VALUE Fault is ignored, i.e. normal measured-value output on the basis of ongoing flow measurement.</p>	Output signal corresponds to "zero flow"
Totalizer	<p>STOP The totalizers are paused until the fault is rectified.</p> <p>ACTUAL VALUE The fault is ignored. The totalizers continue to count in accordance with the current flow value.</p> <p>HOLD VALUE The totalizers continue to count the flow in accordance with the last valid flow value (before the error occurred).</p>	Totalizer stops
Relay output	<p>Fault or power supply failure: relay → de-energized</p> <p>In the "Description of Device Functions" manual you will find detailed information on relay switching response for various configurations such as error message, flow direction, EPD, limit value, etc.</p>	No effect on relay output

9.6 Spare parts

You will find detailed troubleshooting instructions in the preceding sections → 103. The measuring device, moreover, provides additional support in the form of continuous self-diagnosis and error messages.

Fault rectification can entail replacing defective components with tested spare parts. The illustration below shows the available scope of spare parts.




Note!

You can order spare parts directly from your Endress+Hauser service organization by providing the serial number printed on the transmitter nameplate → 6.

Spare parts are shipped as sets comprising the following parts:

- Spare part
- Additional parts, small items (screws, etc.)
- Mounting instructions
- Packaging



A0005521

Fig. 59: Spare parts for Promag transmitter (field and wall-mount housing)

1	Power unit board
2	Amplifier board
3	I/O board (COM module), flexible assignment
4	Pluggable input/output submodules; product structure → 100
5	I/O board (COM module), permanent assignment
6	S-DAT (sensor data storage device)
7	T-DAT (transmitter data storage device)
8	F-CHIP (function chip for optional software)
9	Display module

9.6.1 Removing and installing electronics boards

Field housing



Warning!

- Risk of electric shock. Exposed components carry dangerous voltages. Make sure that the power supply is switched off before you remove the cover of the electronics compartment.
- Risk of damaging electronic components (ESD protection). Static electricity can damage electronic components or impair their operability. Use a workplace with a grounded working surface purpose-built for electrostatically sensitive devices!
- If you cannot guarantee that the dielectric strength of the device is maintained in the following steps, then an appropriate inspection must be carried out in accordance with the manufacturer's specifications.



Caution!

Use only original Endress+Hauser parts.

Removing and installing the boards → 60:

1. Unscrew cover of the electronics compartment from the transmitter housing.
2. Remove the local display (1) as follows:
 - Press in the latches (1.1) at the side and remove the display module.
 - Disconnect the ribbon cable (1.2) of the display module from the amplifier board.
3. Remove the screws and remove the cover (2) from the electronics compartment.
4. Removing power unit board (4) and I/O board (6, 7):
Insert a thin pin into the hole provided (3) and pull the board clear of its holder.
5. Removing submodules (6.2, only for devices with flexibly assigned I/O board):
No additional tools are required for removing the submodules (inputs/outputs) from the I/O board or plugging them into it.




Caution!

Only certain combinations of submodules on the I/O board are permissible → 53.
The individual slots are marked and correspond to certain terminals in the connection compartment of the transmitter:

- Slot "INPUT/OUTPUT 2" = Terminals 24/25
- Slot "INPUT/OUTPUT 3" = Terminals 22/23
- Slot "INPUT/OUTPUT 4" = Terminals 20/21

6. Remove amplifier board (5):
 - Disconnect the plug of the electrode signal cable (5.1) including S-DAT (5.3) from the board.
 - Loosen the plug locking of the coil current cable (5.2) and gently disconnect the plug from the board, i.e. without moving it to and fro.
 - Insert a thin pin into the hole provided (3) and pull the board clear of its holder.
7. Installation is the reverse of the removal procedure.



a0002656

Fig. 60: Field housing: removing and installing printed circuit boards

- 1 Local display
- 1.1 Latch
- 1.2 Ribbon cable (display module)
- 2 Screws for electronics compartment cover
- 3 Aperture for installing /removing boards
- 4 Power unit board
- 5 Amplifier board
- 5.1 Electrode signal cable (sensor)
- 5.2 Coil current cable (sensor)
- 5.3 S-DAT (sensor data storage device)
- 5.4 T-DAT (transmitter data storage device)
- 6 I/O board (flexible assignment)
- 6.1 F-CHIP (function chip for optional software)
- 6.2 Pluggable submodules (inputs/outputs)
- 7 I/O boards (permanent assignment)
- 7.1 F-CHIP (function chip for optional software)

Wall-mount housing



Warning!

- Risk of electric shock. Exposed components carry dangerous voltages. Make sure that the power supply is switched off before you remove the cover of the electronics compartment.
- Risk of damaging electronic components (ESD protection). Static electricity can damage electronic components or impair their operability. Use a workplace with a grounded working surface purpose-built for electrostatically sensitive devices!
- If you cannot guarantee that the dielectric strength of the device is maintained in the following steps, then an appropriate inspection must be carried out in accordance with the manufacturer's specifications.



Caution!

Use only original Endress+Hauser parts.

Installing and removing the boards → 117:

1. Remove the screws and open the hinged cover (1) of the housing.
2. Loosen the screws securing the electronics module (2). Then push up electronics module and pull it as far as possible out of the wall-mounted housing.
3. Disconnect the following cable plugs from amplifier board (7):
 - Electrode signal cable plug (7.1) including S-DAT (7.3)
 - Plug of coil current cable (7.2): To do so, loosen the plug locking of the coil current cable (5.2) and carefully disconnect the plug from the board, i.e. without moving it to and fro.
 - Ribbon cable plug (3) of the display module
4. Remove the cover (4) from the electronics compartment by loosening the screws.
5. Removing boards (6, 7, 8):
Insert a thin pin into the hole provided (5) and pull the board clear of its holder.
6. Removing submodules (8.2, only for devices with flexibly assigned I/O board):
No additional tools are required for removing the submodules (inputs/outputs) from the I/O board or plugging them into it.




Caution!

Only certain combinations of submodules on the I/O board are permissible → 53.

The individual slots are marked and correspond to certain terminals in the connection compartment of the transmitter:

- Slot "INPUT/OUTPUT 2" = Terminals 24/25
- Slot "INPUT/OUTPUT 3" = Terminals 22/23
- Slot "INPUT/OUTPUT 4" = Terminals 20/21

7. Installation is the reverse of the removal procedure.



a0005520

Fig. 61: Wall-mounted housing: removing and installing printed circuit boards

- 1 Housing cover
- 2 Electronics module
- 3 Ribbon cable (display module)
- 4 Screws for electronics compartment cover
- 5 Aperture for installing /removing boards
- 6 Power unit board
- 7 Amplifier board
- 7.1 Electrode signal cable (sensor)
- 7.2 Coil current cable (sensor)
- 7.3 S-DAT (sensor data storage device)
- 7.4 T-DAT (transmitter data storage device)
- 8 I/O board (flexible assignment)
- 8.1 F-CHIP (function chip for optional software)
- 8.2 Pluggable submodules (inputs/outputs)
- 9 I/O boards (permanent assignment)
- 9.1 F-CHIP (function chip for optional software)

9.6.2 Replacing the device fuse



Warning!

Risk of electric shock. Exposed components carry dangerous voltages. Make sure that the power supply is switched off before you remove the cover of the electronics compartment.

The main fuse is on the power supply board →  62.


The procedure for replacing the fuse is as follows:

1. Switch off power supply.
2. Remove power unit board →  114.
3. Remove cap (1) and replace the device fuse (2).
Use only the following types of fuses:
 - 85 to 260 V AC: 0.8 A slow-blow / 250 V
 - 20 to 55 V AC and 16 to 62 V DC: 2 A slow-blow / 250 V
 - Ex-rated devices → See the Ex documentation
4. Installation is the reverse of the removal procedure.



Caution!

Use only original Endress+Hauser parts.



a0001148

Fig. 62: Replacing the device fuse on the power supply board

1 Protection cap
2 Device fuse

9.6.3 Replacing the exchangeable electrode

The Promag W sensor (DN 350 to 2000 / 14 to 78") can be supplied with optional exchangeable measuring electrodes. This design allows the measuring electrodes to be exchanged or cleaned under process conditions.




Fig. 63: Device for replacing the exchangeable measuring electrodes

View A = DN 1200 to 2000 (48 to 78")

View B = DN 350 to 1050 (14 to 42")

1	Socket head cap screw
2	Rotary handle
3	Electrode cable
4	Knurled nut (counter nut)
5	Measuring electrode
6	Stop cock (ball valve)
7	Retaining cylinder
8	Locking bolt (rotary handle)
9	Ball valve housing
10	Seal (retaining cylinder)
11	Coil spring

Removing the electrode	Fitting the electrode
1 Release the socket head cap screw (1) and remove the cap.	1 Insert the new electrode (5) from underneath into the retaining cylinder (7). Ensure that the seals at the tip of the electrode are clean.
2 Unscrew the electrode cable (3) secured on the rotary handle (2).	2 Attach the rotary handle (2) to the electrode and secure with the locking bolt (8).  Caution! Ensure that the coil spring (11) is inserted to guarantee perfect electrical contact and thus correct measuring signals.
3 Release the knurled nut (4) by hand. This knurled nut serves as a counter nut.	3 Pull the electrode back until the tip is no longer protruding from the retaining cylinder (7).
4 Unscrew the electrode (5) using the rotary handle (2). It can now be pulled out of the retaining cylinder (7) up to a defined point.  Warning! Risk of injury! The electrode can bounce back to its stop under process conditions (pressure in the pipe). Exert counter pressure against it when releasing.	4 Screw the retaining cylinder (7) onto the ball valve housing (9) and secure tightly by hand. The seal (10) at the retaining cylinder must be fitted and clean.  Note! Ensure that the rubber hoses attached to the retaining cylinder (7) and stop cock (6) are the same color (red or blue).
5 Close the stop cock (6) after you have pulled out the electrode as far as it will go.  Warning! Do not open the stop cock after this to ensure that no fluid comes out.	5 Open the stop cock (6) and screw the electrode as far as it will go into the retaining cylinder using the rotary handle (2).
6 You can now unscrew the entire electrode with the retaining cylinder (7).	6 Now, screw the knurled nut (4) on the retaining cylinder. This secures the electrode in position.
7 Remove the rotary handle (2) from the electrode (5) by pushing out the locking bolt (8). Ensure that you do not lose the coil spring (11).	7 Secure the electrode cable (3) on the rotary handle (2) once more using the socket head cap screw.  Caution! Ensure that the socket head cap screw of the electrode cable is securely tightened. This guarantees perfect electrical contact and thus correct measuring signals.
8 Now replace the old electrode with the new one. You can order replacement electrodes separately from Endress+Hauser	8 Refit the cover and tighten the socket head cap screw (a).

9.7 Return

The measuring device must be returned if repairs or a factory calibration are required, or if the wrong measuring device has been ordered or delivered. According to legal regulations, Endress+Hauser, as an ISO-certified company, is required to follow certain procedures when handling returned products that are in contact with medium.

To ensure swift, safe and professional device returns, please read the return procedures and conditions on the Endress+Hauser website at www.services.endress.com/return-material

9.8 Disposal

Please observe the regulations applicable in your country or region.

9.9 Software history

Date	Software-Version	Changes to software	Documentation
12.2014	2.07.XX	<p>Software expansion:</p> <ul style="list-style-type: none"> ▪ Status signals according VDI/VDE 2650 and NAMUR Recommendation NE 107 ▪ Introduction HART 7 <ul style="list-style-type: none"> - New functionalities - New Universal / Common practice HART commands - Amplifier update 	71271698/14.14
01.2011	2.03.XX	Improved HART communication	71249449/13.14
12.2009	2.02.XX	Introduction of Calf history	71107993/12.09
03.2005	2.00.XX	<p>Software expansion:</p> <ul style="list-style-type: none"> - Language group (contains the language Chinese and English) <p>New functionalities:</p> <ul style="list-style-type: none"> - DEVICE SOFTWARE → Device software displayed (NAMUR-recommendation 53) Unit US Kgal 	50097083/03.05
11.2004	Amplifier: 1.06.01 Communication module: 1.04.00	Software update relevant only for production	50097083/10.03
10.2003	Amplifier: 1.06.00 Communication module: 1.03.00	<p>Software expansion:</p> <ul style="list-style-type: none"> - Language groups - Flow direction pulse output selectable <p>New functionalities:</p> <ul style="list-style-type: none"> - Second Totalizer - Adjustable backlight (display) - Operation hours counter - Simulation function for pulse output - Access code for counter - Reset function (fault history) - Up-/download with FieldTool 	50097083/10.03
08.2003	Communication module: 1.02.01	<p>Software expansion:</p> <ul style="list-style-type: none"> - New / revised functionalities <p>Special documentation:</p> <ul style="list-style-type: none"> - Current span NAMUR NE 43 - Failsafe mode function - Trouble-shooting function - System and process error messages - Response of status output 	50097083/08.03

Date	Software-Version	Changes to software	Documentation
08.2002	Amplifier: 1.04.00	Software expansion: - New / revised functionalities Special documentation: - Current span NAMUR NE 43 - Quick Setup "Batching" - EPD (new mode) - Failsafe mode function - Acknowledge fault function - Trouble-shooting function - Function "T-DAT SAVE/LOAD" - System and process error messages - Response of relay and status output	50097083/08.02
06.2001	Amplifier: 1.02.00 Communication module: 1.02.00	Software expansion: - New functionalities New functionalities: - Device functions in general - "Batching" software function - "OED" software function - "Advanced Diagnostics" software function - "Pulse width" software function	50097083/06.01
09.2000	Amplifier: 1.01.01 Communication module: 1.01.00	Software expansion: - Functional adaptations	none
08.2000	Amplifier: 1.01.00	Software expansion: - Functional adaptations	none
04.2000	Amplifier: 1.00.00 Communication module: 1.00.00	Original software. Compatible with: - FieldTool - Commuwin II (version 2.05.03 and higher) - HART Communicator DXR 375 (from OS 4.6) with Rev. 1, DD 1.	-

10 Technical data

10.1 Application

→  4

10.2 Function and system design

Measuring principle	Electromagnetic flow measurement on the basis of Faraday's Law.
---------------------	---

Measuring system	→  6
------------------	---

10.3 Input

Measured variable	Flow rate (proportional to induced voltage)
-------------------	---

Measuring range	Typical $v = 0.01$ to 10 m/s (0.03 to 33 ft/s) with the specified measuring accuracy
-----------------	--

Operable flow range	Over 1000 : 1
---------------------	---------------

Input signal	Status input (auxiliary input): $U = 3 \dots 30 \text{ V DC}$, $R_i = 5 \text{ k}\Omega$ galvanically isolated Configurable for: totalizer(s) reset, positive zero return, error-message reset
	Current input: active/passive selectable, galvanically isolated, full scale value adjustable, resolution: $3 \text{ }\mu\text{A}$, temperature coefficient: typically $0.005 \text{ \% o.f.s./}^\circ\text{C}$; ($0.003 \text{ \% o.f.s./}^\circ\text{F}$) <ul style="list-style-type: none"> ▪ active: 4 to 20 mA, $R_i \geq 150 \Omega$, $U_{out} = 24 \text{ V DC}$, short-circuit proof ▪ passive: $0/4$ to 20 mA, $R_i \leq 150 \Omega$, $U_{max} = 30 \text{ V DC}$

10.4 Output

Output signal	Current output: active/passive selectable, galvanically isolated, time constant selectable (0.01 to 100 s), full scale value adjustable, temperature coefficient: typically $0.005\% \text{ o.f.s./}^\circ\text{C}$ ($0.003 \text{ \% o.f.s./}^\circ\text{F}$), resolution: $0.5 \text{ }\mu\text{A}$ <ul style="list-style-type: none"> ▪ active: $0/4$ to 20 mA, $R_L < 700 \Omega$ (for HART: $R_L \geq 250 \Omega$) ▪ passive: 4 to 20 mA; supply voltage V_S: 18 to 30 V DC; $R_i \geq 150 \Omega$ Pulse / frequency output: active/passive selectable (Ex i version passive only), galvanically isolated <ul style="list-style-type: none"> ▪ active: 24 V DC, 25 mA (max. 250 mA over 20 ms), $R_L > 100 \Omega$ ▪ passive: open collector, 30 V DC, 250 mA ▪ Frequency output: end frequency 2 to 10000 Hz ($f_{max} = 12500 \text{ Hz}$), on/off ratio $1:1$, pulse width max. 2 s ▪ Pulse output: pulse value and pulse polarity selectable, pulse width configurable (0.05 to 2000 ms)
---------------	---

Signal on alarm	<p><i>Current output:</i> Failsafe mode selectable (e.g. according to NAMUR recommendation NE 43)</p> <p><i>Pulse / frequency output:</i> Failsafe mode selectable</p> <p><i>Relay output:</i> "de-energized" in the event of a fault or power supply failure</p> <p>Details →  111</p>
Load	See "output signal"
Switching output	<p>Relay output:</p> <p>Normally closed (NC or break) or normally open (NO or make) contacts available (default: relay 1 = NO, relay 2 = NC), max. 30 V / 0.5 A AC; 60 V / 0.1 A DC, galvanically isolated. Configurable for: error messages, empty pipe detection (EPD), direction of flow, limit values</p>
Low flow cutoff	Switch points for low flow cut off freely selectable.
Galvanic isolation	All circuits for inputs, outputs, and power supply are galvanically isolated from each other.

10.5 Power supply

Electrical connections	→  46
Supply voltage (power supply)	<ul style="list-style-type: none"> ■ 20 to 55 V AC, 45 to 65 Hz ■ 85 to 260 V AC, 45 to 65 Hz ■ 16 to 62 V DC
Cable entries	<p>Power supply and signal cable (inputs/outputs):</p> <ul style="list-style-type: none"> ■ Cable gland M20 × 1.5 (8 to 12 mm / 0.31 to 0.47 in) ■ Cable gland sensor for armored cables M20 × 1.5 (9.5 to 16 mm / 0.37 to 0.63 in) ■ Cable entries for thread ½" NPT, G ½" <p>Connecting cable for remote version:</p> <ul style="list-style-type: none"> ■ Cable gland M20 × 1.5 (8 to 12 mm / 0.31 to 0.47 in) ■ Cable gland sensor for armored cables M20 × 1.5 (9.5 to 16 mm / 0.37 to 0.63 in) ■ Cable entries for thread ½" NPT, G ½"
Cable specifications remote version	→  46
Power consumption	<p>Power consumption</p> <ul style="list-style-type: none"> ■ AC: <15 VA (including sensor) ■ DC: <15 W (including sensor) <p>Switch-on current</p> <ul style="list-style-type: none"> ■ max. 8.5 A (< 50 ms) for 24 V DC ■ max. 3 A (< 5 ms) for 260 V AC

Power supply failure	Lasting min. 1 power cycle: <ul style="list-style-type: none"> ▪ EEPROM or HistoROM/T-DAT saves measuring system data if power supply fails ▪ HistoROM/S-DAT: exchangeable data storage device which stores sensor characteristic data (nominal diameter, serial number, calibration factor, zero point etc.)
----------------------	--

Potential equalization	→  55
------------------------	--

10.6 Performance characteristics

Reference operating conditions	To DIN EN 29104 and VDI/VDE 2641: <ul style="list-style-type: none"> ▪ Fluid temperature: $+28 \pm 2^\circ\text{C}$ ($+82 \pm 4^\circ\text{F}$) ▪ Ambient temperature: $+22 \pm 2^\circ\text{C}$ ($+72 \pm 4^\circ\text{F}$) ▪ Warm-up period: 30 minutes <p>Installation:</p> <ul style="list-style-type: none"> ▪ Inlet run $> 10 \times \text{DN}$ ▪ Outlet run $> 5 \times \text{DN}$ ▪ Sensor and transmitter grounded. ▪ Sensor centered relative to the pipe.
--------------------------------	--

Maximum measured error	Standard: $\pm 0.2\%$ o.r. $\pm 2 \text{ mm/s}$ (o.r. = of reading)
------------------------	---



Note!

Supply-voltage fluctuations have no effect within the specified range.




Fig. 64: Max. measured error in % of reading

a0004456

Repeatability	Standard: max. $\pm 0.1\%$ o.r. $\pm 0.5 \text{ mm/s}$ (o.r. = of reading)
---------------	--

10.7 Installation

Installation instructions	→  12
---------------------------	--

Inlet and outlet runs	Inlet run: typically $\geq 5 \times \text{DN}$ Outlet run: typically $\geq 2 \times \text{DN}$
-----------------------	---

Length of connecting cable	<ul style="list-style-type: none"> ▪ The permissible cable length L_{\max} for the remote version depends on the conductivity of the medium →  19. ▪ A minimum conductivity of $20 \mu\text{S}/\text{cm}$ is required to measure demineralized water.
----------------------------	--

10.8 Environment

Ambient temperature range

Transmitter:

- Standard: -20 to +60 °C (-4 to +140 °F)
- Optional: -40 to +60 °C (-40 to +140 °F)



Note!

At ambient temperatures below -20 °C (-4 °F), the readability of the display may be impaired.

Sensor:

- Flange material carbon steel: -10 to +60 °C (+14 to +140 °F)
- Flange material stainless steel: -40 to +60 °C (-40 to +140 °F)



Caution!

Do not exceed the min. and max. temperatures for the lining of the measuring tube (→ "Medium temperature range").

Note the following points:

- Install the device at a shady location. Avoid direct sunlight, particularly in warm climatic regions.
- If both fluid and ambient temperatures are high, install the transmitter at a remote location from the sensor (→ "Medium temperature range").

Storage temperature

The storage temperature corresponds to the operating temperature range of the transmitter and sensor.



Caution!

- The measuring device must be protected against direct sunlight during storage in order to avoid unacceptably high surface temperatures.
- Choose a storage location where moisture does not collect in the measuring device. This will help prevent fungus and bacteria infestation which can damage the lining.

Degree of protection

- Standard: IP 67 (NEMA 4X) for transmitter and sensor

- Optional: IP 68 (NEMA 6P) for remote version of Promag P/W sensors

Shock and vibration resistance

Acceleration up to 2 g in accordance with IEC 600 68-2-6
(High-temperature version: no data available)

CIP cleaning



Caution!

The maximum fluid temperature permitted for the measuring device must not be exceeded.

CIP cleaning possible:

Promag E (110 °C / 230 °F), Promag H/P

CIP cleaning not possible:

Promag L/W

SIP cleaning



Caution!

The maximum fluid temperature permitted for the measuring device must not be exceeded.

SIP cleaning possible:

Promag H, Promag P (with PFA lining)

SIP cleaning not possible:

Promag E/L/W

Electromagnetic compatibility (EMC)


- As per IEC/EN 61326 and NAMUR Recommendation NE 21
- Emission: to limit value for industry EN 55011

10.9 Process

Medium temperature range The permitted temperature depends on the lining of the measuring tube:

Promag E

PTFE: -10 to +110 °C (+14 to +230 °F)



A0022937

Abb. 65: Compact and remote version (TA = Ambient temperature, TF = Fluid temperature)

Promag H

Sensor:

- DN 2 to 25 (1/12 to 1"): -20 to +150 °C (-4 to +302 °F)
- DN 40 to 150 (1 1/2 to 6"): -20 to +150 °C (-4 to +302 °F)

Seals:

- EPDM: -20 to +150 °C (-4 to +302 °F)
- Silicone (VMQ): -20 to +150 °C (-4 to +302 °F)
- Viton (FKM): -20 to +150 °C (-4 to +302 °F)
- Kalrez: -20 to +150 °C (-4 to +302 °F)

Promag L

- 0 to +80 °C (+32 to +176 °F) for hard rubber (DN 350 to 2400 / 14 to 90")
- -20 to +50 °C (-4 to +122 °F) for polyurethane (DN 25 to 1200 / 1 to 48")
- -20 to +90 °C (-4 to +194 °F) for PTFE (DN 25 to 300 / 1 to 12")

Promag P

Standard

- -40 to +130 °C (-40 to +266 °F) for PTFE (DN 15 to 600 / 1/2 to 24"),
restrictions → see diagrams below
- -20 to +130 °C (-4 to +266 °F) for PFA/HE (DN 25 to 200 / 1 to 8"),
restrictions → see diagrams below
- -20 to +150 °C (-4 to +302 °F) for PFA (DN 25 to 200 / 1 to 8"),
restrictions → see diagrams below

Optional

High-temperature version (HT): -20 to +180 °C (-4 to +356 °F) for PFA (DN 25 to 200 / 1 to 8")




Fig. 66: Promag P compact version (with PFA or PTFE lining)

T_A = ambient temperature; T_F = fluid temperature; HT = high-temperature version with insulation

① = Light gray area → temperature range from -10 to -40 °C (-14 to -40 °F) applies only to stainless steel flanges

② = Diagonally hatched area → foam lining (HE) + degree of protection IP68 = fluid temperature max. 130°C (266 °F)




Fig. 67: Remote versions (with PFA or PTFE lining)

T_A = ambient temperature; T_F = fluid temperature; HT = high-temperature version with insulation

① = Light gray area → temperature range from -10 to -40 °C (-14 to -40 °F) applies only to stainless steel flanges

② = Diagonally hatched area → foam lining (HE) + degree of protection IP68 = fluid temperature max. 130°C (266 °F)

Promag W

- 0 to +80 °C (+32 to +176 °F) for hard rubber (DN 65 to 2000 / 2 1/2 to 80")
- -20 to +50 °C (-4 to +122 °F) for polyurethane (DN 25 to 1200 / 1 to 48")

Conductivity of the fluid



The minimum conductivity is $\geq 5 \mu\text{S}/\text{cm}$ (for demineralized water $\geq 20 \mu\text{S}/\text{cm}$)

Note!

In the remote version, the required minimum conductivity is also influenced by the length of the connecting cable → 19.

Limiting medium pressure range (nominal pressure)

Promag E

- EN 1092-1 (DIN 2501)
 - PN 10 (DN 200 to 600 / 8 to 24")
 - PN 16 (DN 65 to 600 / 3 to 24")
 - PN 40 (DN 15 to 150 / ½ to 2")
- ASME B 16.5
 - Class 150 (½ to 24")
- JIS B2220
 - 10K (DN 50 to 300 / 2 to 12")
 - 20K (DN 15 to 40 / ½ to 1½")

Promag H

The permissible nominal pressure depends on the process connection, the seal and the nominal diameter.

Details are provided in the separate documentation "Technical Information" →  149.

Promag L

- EN 1092-1 (DIN 2501)
 - PN 6 (DN 350 to 2400 / 14 to 90")
 - PN 10 (DN 200 to 2400 / 8 to 90")
 - PN 16 (DN 25 to 300 / 1 to 12")
- EN 1092-1, lap joint flange, stampel plate
 - PN 10 (DN 25 to 300 / 1 to 12")
- ASME B16.5
 - Class 150 (1 to 24")
- AWWA
 - Class D (28 to 90")
- AS2129
 - Table E (350 to 1200 / 14 to 48")
- AS4087
 - PN 16 (350 to 1200 / 14 to 48")

Promag P

- EN 1092-1 (DIN 2501)
 - PN 10 (DN 200 to 600 / 8 to 24")
 - PN 16 (DN 65 to 600 / 3 to 24")
 - PN 25 (DN 200 to 600 / 8 to 24")
 - PN 40 (DN 25 to 150 / 1 to 6")
- ASME B 16.5
 - Class 150 (1 to 24")
 - Class 300 (1 to 6")
- JIS B2220
 - 10K (DN 50 to 300 / 2 to 12")
 - 20K (DN 25 to 300 / 1 to 12")
- AS 2129
 - Table E (DN 25 / 1"), 50 / 2")
- AS 4087
 - PN 16 (DN 50 / 2")

Promag W

- EN 1092-1 (DIN 2501)
 - PN 6 (DN 350 to 2000 / 14 to 84")
 - PN 10 (DN 200 to 2000 / 8 to 84")
 - PN 16 (DN 65 to 2000 / 3 to 84")
 - PN 25 (DN 200 to 1000 / 8 to 40")
 - PN 40 (DN 25 to 150 / 1 to 6")

- ASME B 16.5
 - Class 150 (1 to 24")
 - Class 300 (1 to 6")
- AWWA
 - Class D (28 to 78")
- JIS B2220
 - 10K (DN 50 to 300 / 2 to 12")
 - 20K (DN 25 to 300 / 1 to 12")
- AS 2129
 - Table E (DN 80 / 3", 100 / 4", 150 to 1200 / 6 to 48")
- AS 4087
 - PN 16 (DN 80 / 3", 100 / 4", 150 to 1200 / 6 to 48")

Pressure tightness
(measuring tube lining)

Promag E (Measuring tube lining: PTFE)

Nominal diameter		Resistance of measuring tube lining to partial vacuum Limit values for abs. pressure [mbar] ([psi]) at various fluid temperatures							
[mm]	[inch]	25 °C		80 °C		100 °C		110 °C	
		[mbar]	[psi]	[mbar]	[psi]	[mbar]	[psi]	[mbar]	[psi]
15	1/2"	0	0	0	0	0	0	100	1.45
25	1"	0	0	0	0	0	0	100	1.45
32	–	0	0	0	0	0	0	100	1.45
40	1 1/2"	0	0	0	0	0	0	100	1.45
50	2"	0	0	0	0	0	0	100	1.45
65	–	0	0	*	*	40	0.58	130	1.89
80	3"	0	0	*	*	40	0.58	130	1.89
100	4"	0	0	*	*	135	1.96	170	2.47
125	–	135	1.96	*	*	240	3.48	385	5.58
150	6"	135	1.96	*	*	240	3.48	385	5.58
200	8"	200	2.90	*	*	290	4.21	410	5.95
250	10"	330	4.79	*	*	400	5.80	530	7.69
300	12"	400	5.80	*	*	500	7.25	630	9.14
350	14"	470	6.82	*	*	600	8.70	730	10.59
400	16"	540	7.83	*	*	670	9.72	800	11.60
450	18"	Partial vacuum is impermissible!							
500	20"	Partial vacuum is impermissible!							
600	24"	Partial vacuum is impermissible!							

* No value can be quoted.

Promag H (measuring tube lining: PFA)

Nominal diameter		Pressure tightness, measuring tube lining: limit values for absolute pressure [mbar] ([psi]) at various fluid temperature					
[mm]	[inch]	25 °C	80 °C	100 °C	130 °C	150 °C	180 °C
		77 °F	176 °F	212 °F	266 °F	302 °F	356 °F
2 to 150	1/12 to 6"	0	0	0	0	0	0

Promag L (Measuring tube lining: Polyurethane, Hard rubber)

Nominal diameter		Measuring tube lining	Resistance of measuring tube lining to partial vacuum Limit values for abs. pressure [mbar] ([psi]) at various fluid temperatures		
[mm]	[inch]		25 °C	50 °C	80 °C
			77 °F	122 °F	176 °F
25 to 1200	1 to 48"	25 to 1200	1 to 48"	0	-
350 to 2400	14 to 90"	Hard rubber	0	0	0

Promag L (Measuring tube lining: PTFE)

Nominal diameter		Resistance of measuring tube lining to partial vacuum Limit values for abs. pressure [mbar] ([psi]) at various fluid temperatures			
[mm]	[inch]	25 °C		90 °C	
		77 °F		194 °F	
		[mbar]	[psi]	[mbar]	[psi]
25	1"	0	0	0	0
32	-	0	0	0	0
40	1 1/2"	0	0	0	0
50	2"	0	0	0	0
65	-	0	0	40	0.58
80	3"	0	0	40	0.58
100	4"	0	0	135	1.96
125	-	135	1.96	240	3.48
150	6"	135	1.96	240	3.48
200	8"	200	2.90	290	4.21
250	10"	330	4.79	400	5.80
300	12"	400	5.80	500	7.25

Promag P (Measuring tube lining: PFA)

Nominal diameter		Resistance of measuring tube lining to partial vacuum: limit values for absolute pressure [mbar] ([psi]) at various fluid temperatures					
[mm]	[inch]	25 °C	80 °C	100 °C	130 °C	150 °C	180 °C
		77 °F	176 °F	212 °F	266 °F	302 °F	356 °F
25	1"	0	0	0	0	0	0
32	-	0	0	0	0	0	0
40	1 1/2"	0	0	0	0	0	0
50	2"	0	0	0	0	0	0
65	-	0	*	0	0	0	0
80	3"	0	*	0	0	0	0
100	4"	0	*	0	0	0	0
125	-	0	*	0	0	0	0
150	6"	0	*	0	0	0	0
200	8"	0	*	0	0	0	0

* No value can be quoted.

Promag P (Measuring tube lining: PTFE)

Nominal diameter		Resistance of measuring tube lining to partial vacuum: limit values for absolute pressure [mbar] ([psi]) at various fluid temperatures									
[mm]	[inch]	25 °C		80 °C		100 °C		130 °C		150 °C	180 °C
		77 °F		176 °F		212 °F		266 °F		302 °F	356 °F
		[mbar]	[psi]	[mbar]	[psi]	[mbar]	[psi]	[mbar]	[psi]		
15	1/2"	0	0	0	0	100	1,45	—	—		
25	1"	0	0	0	0	100	1,45	—	—		
32	—	0	0	0	0	100	1,45	—	—		
40	1 1/2"	0	0	0	0	100	1,45	—	—		
50	2"	0	0	0	0	100	1,45	—	—		
65	—	0	0	*	40	0,58	1,89	—	—		
80	3"	0	0	*	40	0,58	1,89	—	—		
100	4"	0	0	*	135	1,96	170	2,47	—	—	
125	—	135	1,96	*	240	3,48	385	5,58	—	—	
150	6"	135	1,96	*	240	3,48	385	5,58	—	—	
200	8"	200	2,90	*	290	4,21	410	5,95	—	—	
250	10"	330	4,79	*	400	5,80	530	7,69	—	—	
300	12"	400	5,80	*	500	7,25	630	9,14	—	—	
350	14"	470	6,82	*	600	8,70	730	10,59	—	—	
400	16"	540	7,83	*	670	9,72	800	11,60	—	—	
450	18"	Partial vacuum is impermissible									
500	20"	Partial vacuum is impermissible									
600	24"	Partial vacuum is impermissible									

* No value can be quoted.

Promag W

Nominal diameter		Measuring tube lining	Resistance of measuring tube lining to partial vacuum: limit values for absolute pressure [mbar] ([psi]) at various fluid temperatures								
[mm]	[inch]		25 °C	50 °C	80 °C	100 °C	130 °C	150 °C	180 °C		
			77 °F	122 °F	176 °F	212 °F	266 °F	302 °F	356 °F		
25 to 1200	1 to 48"	Polyurethane	0	0	—	—	—	—	—	—	
65 to 2000	3 to 78"	Hard rubber	0	0	0	—	—	—	—	—	

Limiting flow

Further information can be found in the "Nominal diameter and flow rate" → 17 section

Pressure loss

- No pressure loss if the sensor is installed in piping with the same nominal diameter (for Promag H only from DN 8 (3/8")).
- Pressure losses for configurations incorporating adapters according to DIN EN 545 → 16.

10.10 Mechanical construction**Design / dimensions**

The dimensions and face-to-face length of the sensor and transmitter can be found in the separate "Technical Information" documentation for each device which can be downloaded in PDF format from www.endress.com. A list of available "Technical Information" documentation can be found in the "Documentation" → 149 section.

Weight (SI units)

Promag E

Weight data in kg		Compact version				ASME	JIS
Nominal diameter		EN (DIN)				Class 150	10K
[mm]	[inch]	PN 6	PN 10	PN 16	PN 40		
15	1/2"	–	–	–	6.5	6.5	6.5
25	1"	–	–	–	7.3	7.3	7.3
32	–	–	–	–	8.0	–	7.3
40	1 1/2"	–	–	–	9.4	9.4	8.3
50	2"	–	–	–	10.6	10.6	9.3
65	–	–	–	12.0	–	–	11.1
80	3"	–	–	14.0	–	14.0	12.5
100	4"	–	–	16.0	–	16.0	14.7
125	–	–	–	21.5	–	–	21.0
150	6"	–	–	25.5	–	25.5	24.5
200	8"	–	45.0	46.0	–	45.0	41.9
250	10"	–	65.0	70.0	–	75.0	69.4
300	12"	–	70.0	81.0	–	110.0	72.3
350	14"	77.4	88.4	99.4	–	137.4	–
400	16"	89.4	104.4	120.4	–	168.4	–
450	18"	99.4	112.4	133.4	–	191.4	–
500	20"	114.4	132.4	182.4	–	228.4	–
600	24"	155.4	162.4	260.4	–	302.4	–

- Transmitter (compact version): 1.8 kg
- Weight data without packaging material

Weight data in kg		Remote version (without cable)				Transmitter
Nominal diameter		Sensor				
[mm]	[inch]	EN (DIN)			ASME	JIS
		PN 6	PN 10	PN 16	Class 150	10K
15	1/2"	–	–	–	4.5	4.5
25	1"	–	–	–	5.3	5.3
32	–	–	–	–	6.0	–
40	1 1/2"	–	–	–	7.4	7.4
50	2"	–	–	–	8.6	8.6
65	–	–	–	10.0	–	–
80	3"	–	–	12.0	–	12.0
100	4"	–	–	14.0	–	14.0
125	–	–	–	19.5	–	–
150	6"	–	–	23.5	–	23.5
200	8"	–	43.0	44.0	–	43.0
250	10"	–	63.0	68.0	–	73.0
300	12"	–	68.0	79.0	–	108.0
350	14"	73.1	84.1	95.1	–	133.1
400	16"	85.1	100.1	116.1	–	164.1
450	18"	95.1	108.1	129.1	–	187.1
500	20"	110.1	128.1	178.1	–	224.1
600	24"	158.1	158.1	256.1	–	298.1

- Transmitter (remote version): 3.1 kg
- Weight data without packaging material

Promag H**Note!**

The following weights apply to standard pressure ratings and without packaging material.

Nominal diameter DIN [mm]	Compact version (DIN)		Remote version (without cable; DIN)	
	Aluminum field housing [kg]	Stainless steel field housing [kg]	Sensor [kg]	Transmitter (wall-mount housing) [kg]
2	5.2	5.7	2.0	6.0
4	5.2	5.7	2.0	6.0
8	5.3	5.8	2.0	6.0
15	5.4	5.9	1.9	6.0
25	5.5	6.0	2.8	6.0
40	7.1	7.6	4.1	6.0
50	7.6	8.1	4.6	6.0
65	8.4	8.9	5.4	6.0
80	9.0	9.5	6.0	6.0
100	10.3	10.8	7.3	6.0
125	15.7	16.2	12.7	6.0
150	18.1	18.6	15.1	6.0
Transmitter (compact version): 3.4 kg				

Promag L

Weight data in kg		Compact version (including transmitter) ¹⁾						AS	
Nominal diameter [mm] [inch]		EN (DIN)			ASME/ AWWA		AS		Tabelle E
25	1"	—	—	7.3	7.9	—	—	ASME / Class 150	Tabelle E
32	1 1/4"	—	—	8.0	—	—	—		
40	1 1/2"	—	—	9.0	7.5	—	—		
50	2"	—	—	9.4	7.6	—	—		
65	2 1/2"	—	—	10.4	—	—	—		
80	3"	—	—	12.4	12.8	—	—		
100	4"	—	—	14.4	16.1	—	—		
125	5"	—	—	15.9	—	—	—		
150	6"	—	—	23.9	24.4	—	—		
200	8"	—	43.4	44.9	49.6	—	—		
250	10"	—	63.4	70.7	75.1	—	—		
300	12"	—	68.4	85.8	100	—	—		
350	14"	77.4	88.4	103	137	99.4	99.4		
375	15"	—	—	—	—	105	—		
400	16"	89.4	104	124	168	120	120		
450	18"	99.4	112	139	191	133	143		
500	20"	114	132	174	228	182	182		
600	24"	155	162	303	302	260	260		
700	28"	190	240	288	266	367	346		
750	30"	—	—	—	318	445	433		
800	32"	240	315	364	383	503	493		
900	36"	308	393	456	470	702	690		
1000	40"	359	468	579	587	759	761		
1050	42"	—	—	—	670	—	—		
1200	48"	529	717	866	901	—	—		1237
—	54"	—	—	—	1273	—	—		—
1400	—	784	1114	1274	—	—	—		—
—	60"	—	—	—	1594	—	—		—
1600	—	1058	1624	1872	—	—	—		—
1650	66"	—	—	—	2131	—	—		—
1800	72"	1418	2107	2409	2568	—	—		—
2000	78"	1877	2630	2997	3113	—	—		—
—	84"	—	—	—	3755	—	—		—
2200	—	2512	3422	—	—	—	—		—
—	90"	—	—	—	4797	—	—		—
2400	—	2996	4094	—	—	—	—		—

Transmitter Promag (compact version): 3.1 kg
(Weight data valid without packaging material)

1) Lap joint flanges / welded flanges DN > 300 (12")

Weight data in kg		Remote version (sensor plus sensor housing without cable) ¹⁾									
Nominal diameter		EN (DIN)					ASME/ AWWA		AS		
[mm]	[inch]										
25	1"						5.3		5.9		
32	1 1/4"						6.0		-		
40	1 1/2"						7.0		5.5		
50	2"						7.4		5.6		
65	2 1/2"						8.4		-		
80	3"						10.4		10.8		
100	4"						12.4		14.1		
125	5"						13.9		-		
150	6"						21.9		22.4		
200	8"			41.4			42.9		47.6		
250	10"			61.4			68.7		73.1		
300	12"			66.4			83.8		98		
350	14"	75.4		86.4			103		135	97.4	97.4
375	15"	-		102			-		-	103	-
400	16"	87.4		102			124		166	118	118
450	18"	97.4		110			139		189	131	141
500	20"	112		130			174		226	180	180
600	24"	153		160			303		300	258	258
700	28"	188		238			288		264	365	344
750	30"	-		-			-		316	443	431
800	32"	238		313			364		381	501	491
900	36"	306		391			456		468	700	688
1000	40"	357		466			579		585	757	759
1050	42"	-		-			-		668	-	-
1200	48"	527		715			866		899	1271	1235
-	54"	-		-			-		-	-	-
1400	-	782		1112			1274		-	-	-
-	60"	-		-			-		1592	-	-
1600	-	1056		1622			1872		-	-	-
1650	66"	-		-			-		2129	-	-
1800	72"	1416		2105			2409		2566	-	-
2000	78"	1875		2628			2997		3111	-	-
-	84"	-		-			-		3753	-	-
2200	-	2510		3420			-		-	-	-
-	90"	-		-			-		4795	-	-
2400	-	2994		4092			-		-	-	-
Transmitter Promag (remote version): 3.4 kg (Weight data valid without packaging material)											

1) Lap joint flanges / welded flanges DN > 300 (12")

Tabellen E

Weight data in kg		Compact version ¹⁾		Remote version (without cable) ¹⁾	
Nominal diameter [mm]	[inch]	EN (DIN)		Sensor EN (DIN)	Transmitter
25	1"	PN 10	5.8	PN 10	3.8
32	1 1/4"		5.4		4.2
40	1 1/2"		6.3		4.2
50	2"		5.4		4.2
65	2 1/2"		6.2		4.2
80	3"		7.2		4.2
100	4"		9.7		4.2
125	5"		13.2		4.2
150	6"		17.2		4.2
200	8"		35.7		4.2
250	10"		54.2		4.2
300	12"		55.2		4.2

Transmitter Promag (compact version): 1.8 kg
(Weight data valid for standard pressure ratings and without packaging material)

1) Lap joint flanges, stamped plate

Promag P



Note!

The following weights apply to standard pressure ratings and without packaging material.

Nominal diameter [mm]	Weight data in kg					
	Compact version		Remote version (without cable)			
	EN (DIN) / AS*	JIS	EN (DIN) / AS*	Sensor	JIS	Transmitter
15	PN 40	6.5	PN 40	4.5	10K	4.5
25		7.3		5.3		5.3
32		8.0		6.0		5.3
40		9.4		7.4		6.0
50		10.6		8.6		6.0
65		12.0		10.0		9.1
80		14.0		12.0		10.5
100		14.4		14.0		12.7
125		16.0		19.5		19.0
150		21.5		23.5		22.5
200	PN 16	45	PN 16	43	10K	39.9
250		65		63		67.4
300		70		68		70.3
350		115		113		6.0
400		135		133		6.0
450		175		173		6.0
500		175		173		6.0
600		235		233		6.0

Promag transmitter (compact version): 3.4 kg
High-temperature version: +1.5 kg
* Only DN 25 and 50 are available for flanges as per AS

Promag W

Note!

The following weights apply to standard pressure ratings and without packaging material.

Nominal diameter [mm]	Weight data in kg								
	Compact version			Remote version (without cable)					
	EN (DIN) / AS*		JIS	Sensor		JIS	Transmitter		
25	PN 40	7.3	10K	7.3	PN 40	5.3	5.3		
32		8.0		7.3		6.0	5.3		
40		9.4		8.3		7.4	6.3		
50		10.6		9.3		8.6	7.3		
65		12.0		11.1		10.0	9.1		
80		14.0		12.5	PN 16	12.0	10.5		
100		16.0		14.7		14.0	12.7		
125		21.5		21.0		19.5	19.0		
150		25.5		24.5		23.5	22.5		
200		45		41.9		43	39.9		
250	PN 10	65	10K	69.4	PN 10	63	67.4		
300		70		72.3		68	70.3		
350	PN 10	115	10K	PN 10	113		6.0		
	PN 6	105		PN 6	103		6.0		
375	PN 10	134		PN 10	133		6.0		
400	PN 10	135		PN 10	133		6.0		
	PN 6	120		PN 6	118		6.0		
450	PN 10	175		PN 10	173		6.0		
	PN 6	161		PN 6	159		6.0		
500	PN 10	175		PN 10	173		6.0		
	PN 6	156		PN 6	154		6.0		
600	PN 10	235		PN 10	233		6.0		
	PN 6	208		PN 6	206		6.0		
700	PN 10	355		PN 10	353		6.0		
	PN 6	304		PN 6	302		6.0		
800	PN 10	435		PN 10	433		6.0		
	PN 6	357		PN 6	355		6.0		
900	PN 10	575		PN 10	573		6.0		
	PN 6	485		PN 6	589		6.0		
1000	PN 10	700		PN 10	698		6.0		
	PN 6	589		PN 6	587		6.0		
1200	PN 6	850	10K		848		6.0		
1400		1300			1298		6.0		
1600		1700			1698		6.0		
1800		2200			2198		6.0		
2000		2800			2798		6.0		
Promag transmitter (compact version): 3.4 kg									
*Only DN 80, 100, 150 to 400, 500 and 600 are available for flanges as per AS									

Weight (US units)

Promag E (ASME)

Weight data in lbs		Compact version	Remote version (without cable)	Transmitter
Nominal diameter		ASME	Sensor ASME	Transmitter
[mm]	[inch]	Class 150	Class 150	Wall-mount housing
15	1/2"	14.3	9.92	13.2
25	1"	16.1	11.7	
40	1 1/2"	20.7	16.3	
50	2"	23.4	19.0	
80	3"	30.9	26.5	
100	4"	35.3	30.9	
150	6"	56.2	51.8	
200	8"	99.2	94.8	
250	10"	165.4	161.0	
300	12"	242.6	238.1	
350	14"	303.0	293.5	
400	16"	371.3	361.8	
450	18"	422.0	412.6	
500	20"	503.6	494.1	
600	24"	666.8	657.3	

■ Transmitter: 4.0 lbs (compact version); 6.8 lbs (remote version)

■ Weight data without packaging material

Promag H

Note!

The following weights apply to standard pressure ratings and without packaging material.

Nominal diameter DIN [in]	Compact version (DIN)		Remote version (without cable; DIN)	
	Aluminum field housing [lbs]	Stainless steel field housing [lbs]	Sensor [lbs]	Transmitter (wall-mount housing) [lbs]
1/12"	11.5	12.6	4.0	13.0
1/8"	11.5	12.6	4.0	13.0
3/8"	11.7	12.8	4.0	13.0
1/2"	11.9	13.0	4.0	13.0
1"	12.1	13.2	6.0	13.0
1 1/2"	15.7	16.8	4.1	13.0
2"	16.8	17.9	4.6	13.0
3"	19.8	20.9	6.0	13.0
4"	22.7	23.8	7.3	13.0
5"	34.6	35.7	12.7	13.0
6"	39.9	41.0	15.1	13.0

Transmitter (compact version): 7.5 lbs

Promag L (ASME/AWWA)

Weight data in lbs		Compact version ¹⁾ ASME/AWWA	Remote version ¹⁾ ASME/AWWA	
Nominal diameter [mm]	[inch]			
25	1"	ASME / Class 150	17.4	
32	1 1/4"		-	
40	1 1/2"		16.5	
50	2"		16.8	
65	2 1/2"		-	
80	3"		28.2	
100	4"		35.5	
125	5"		-	
150	6"		53.8	
200	8"		109	
250	10"		166	
300	12"		221	
350	14"		302	
375	15"		-	
400	16"		370	
450	18"		421	
500	20"		503	
600	24"		666	
700	28"		587	
750	30"		701	
800	32"		845	
900	36"		1036	
1000	40"		1294	
1050	42"		1477	
1200	48"		1987	
-	54"		2807	
1400	-		-	
-	60"		3515	
1600	-		-	
1650	66"		4699	
1800	72"		5662	
2000	78"		6864	
-	84"		8280	
2200	-		-	
-	90"		10577	
2400	-		-	
Transmitter Promag (compact version): 4.0 lbs				
Transmitter Promag (remote version): 6.8 lbs				
(Weight data valid without packaging material)				

1) Lap joint flanges / welded flanges DN > 300 (12")

Promag P**Note!**

The following weights apply to standard pressure ratings and without packaging material.

Nominal diameter [inch]	Compact version		Weight data in lbs			
	ASME/AWWA		Remote version (without cable)			
	Sensor	Transmitter				
1/2"	Class 150	14	Class 150	10		
1"		16		12		
1 1/2"		21		16		
2"		23		19		
3"		31		26		
4"		35		31		
6"		56		52		
8"		99		95		
10"		165		161		
12"		243		238		
14"		386		381		
16"		452		448		
18"		562		558		
20"		628		624		
24"		893		889		
Promag transmitter (compact version): 7.5 lbs						
High-temperature version: + 3.3 lbs						

Promag W**Note!**

The following weights apply to standard pressure ratings and without packaging material.

Nominal diameter [inch]	Compact version		Weight data in lbs			
	ASME/AWWA		Remote version (without cable)			
	Sensor	Transmitter				
1"	Class 150	16	Class 150	12		
1 1/2"		21		16		
2"		23		19		
3"		31		26		
4"		35		31		
6"		56		52		
8"		99		95		
10"		143		161		
12"		243		238		
14"		386		381		
16"		452		448		
18"		562		558		
20"		628		624		
24"		893		889		
Promag transmitter (compact version): 7.5 lbs						
High-temperature version: + 3.3 lbs						

Nominal diameter [inch]	Weight data in lbs			
	Compact version		Remote version (without cable)	
	ASME/AWWA	ASME/AWWA	Sensor	Transmitter
28"	Class D	882	Class D	878
30"		1014		1010
32"		1213		1208
36"		1764		1760
40"		1985		1980
42"		2426		2421
48"		3087		3083
54"		4851		4847
60"		5954		5949
66"		8159		8154
72"		9041		9036
78"		10143		10139
Promag transmitter (compact version): 7.5 lbs				

Material

Promag E

- Transmitter housing
 - Compact housing: powder-coated die-cast aluminum
 - Wall-mount housing: powder-coated die-cast aluminum
- Sensor housing
 - DN 25 to 300 (1 to 12)": powder-coated die-cast aluminum
 - DN 350 to 600 (14 to 24)": with protective lacquering
- Measuring tube
 - DN ≤ 300 (12)": stainless steel 1.4301 (304) or 1.4306 (304L) (with Al/Zn protective coating)
 - DN ≥ 350 (14)": stainless steel 1.4301 (304) or 1.4306 (304L) (with protective lacquering)
- Electrodes: 1.4435 (316, 316L), Alloy C22, Tantalum
- Flanges (with protective lacquering)
 - EN 1092-1 (DIN2501): RSt37-2 (S235JRG2); Alloy C22; Fe 410W B
 - ANSI: A105
 - JIS: RSt37-2 (S235JRG2); HII
- Seals: to DIN EN 1514-1
- Ground disks: 1.4435 (316, 316L) or Alloy C22

Promag H

- Transmitter housing:
 - Compact housing: powder-coated die-cast aluminum or stainless steel field housing (1.4301 (316L))
 - Wall-mounted housing: powder-coated die-cast aluminum
 - Window material: glass or polycarbonate
- Sensor housing: stainless steel 1.4301 (304)
- Wall mounting kit: stainless steel 1.4301 (304)
- Measuring tube: stainless steel 1.4301 (304)
- Liner: PFA (USP class VI; FDA 21 CFR 177.1550: 3A)
- Electrodes:
 - Standard: 1.4435 (316, 316L)
 - Option: Alloy C22, Tantalum, Platinum

- Flange:
 - All connections stainless-steel 1.4404 (316L)
 - EN (DIN), ASME, JIS made of PVDF
 - Adhesive fitting made of PVC
- Seals
 - DN 2 to 25 (1/12 to 1"): O-ring (EPDM, Viton, Kalrez), gasket seal (EPDM*, Viton, Silicone*)
 - DN 40 to 150 (1½ to 6"): gasket seal (EPDM*, Silicone*)
 - * = USP class VI; FDA 21 CFR 177.2600: 3A
- Ground rings: 1.4435 (316, 316L) (optional: Tantalum, Alloy C22)

Promag L

- Transmitter housing:
 - Compact housing: powder-coated die-cast aluminum
 - Wall-mounted housing: powder-coated die-cast aluminum
- Sensor housing
 - DN 25 to 300 (1 to 12"): powder-coated die-cast aluminum
 - DN 350 to 1200 (14 to 48"): with protective lacquering
- Measuring tube:
 - DN \leq 300 (12"): stainless steel 1.4301 (304) or 1.4306 (304L)
 - DN \geq 350 (14"): stainless steel 202 or 304
- Electrodes: 1.4435 (316, 316L), Alloy C22
- Flange
 - EN 1092-1 (DIN 2501): DN \leq 300: 1.4306; 1.4307; 1.4301 (304); 1.0038 (S235JRG2)
 - EN 1092-1 (DIN 2501): DN \geq 350: A105; 1.0038 (S235JRG2)
 - AWWA: A181/A105; 1.0425 (316L) (P265GH); 1.0044 (S275JR)
 - AS 2129: A105; 1.0345 (P235GH); 1.0425 (316L) (P265GH); 1.0038 (S235JRG2); FE 410 WB
 - AS 4087: A105; 1.0425 (316L) (P265GH); 1.0044 (S275JR)
- Seals: to DIN EN 1514-1
- Ground disks: 1.4435 (316, 316L) or Alloy C22

Promag P

- Transmitter housing:
 - Compact housing: powder-coated die-cast aluminum
 - Wall-mounted housing: powder-coated die-cast aluminum
- Sensor housing
 - DN 15 to 300 (½ to 12"): powder-coated die-cast aluminum
 - DN 350 to 2000 (14 to 84"): with protective lacquering
- Measuring tube
 - DN \leq 300 (12"): stainless steel 1.4301 (304) or 1.4306 (304L); for flanges made of carbon steel with Al/Zn protective coating
 - DN \geq 350 (14"): stainless steel 1.4301 (304) or 1.4306 (304L); for flanges made of carbon steel with Al/Zn protective coating
- Electrodes: 1.4435 (316, 316L), Platinum, Alloy C22, Tantalum, Titanium
- Flange
 - EN 1092-1 (DIN2501): 1.4571 (316L); RSt37-2 (S235JRG2); Alloy C22; FE 410W B (DN \leq 300 (12") with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - ASME: A105; F316L (DN \leq 300 (12") with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - AWWA: 1.0425

- JIS: RSt37-2 (S235JRG2); HII; 1.0425 (316L)
(DN \leq 300 (12") with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
- AS 2129
 - DN 25 (1"): A105 or RSt37-2 (S235JRG2)
 - DN 40 (1½"): A105 or St44-2 (S275JR)
 - AS 4087: A105 or St44-2 (S275JR)
- Seals: to DIN EN 1514-1
- Ground disks: 1.4435 (316, 316L) or Alloy C22

Promag W

- Transmitter housing:
 - Compact housing: powder-coated die-cast aluminum
 - Wall-mounted housing: powder-coated die-cast aluminum
- Sensor housing
 - DN 25 to 300 (1 to 12"): powder-coated die-cast aluminum
 - DN 350 to 2000 (14 to 84"): with protective lacquering
- Measuring tube
 - DN \leq 300 (12"): stainless steel 1.4301 (304) or 1.4306 (304L)
(for flanges made of carbon steel with Al/Zn protective coating)
 - DN \geq 350 (14"): stainless steel 1.4301 (304) or 1.4306 (304)
(for flanges made of carbon steel with protective lacquering)
- Electrodes: 1.4435 (316, 316L) or Alloy C22, Tantalum
- Flange
 - EN 1092-1 (DIN2501): 1.4571 (316L); RSt37-2 (S235JRG2); Alloy C22; FE 410 WB
(DN \leq 300 (12") with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - ASME: A105; F316L
(DN \leq 300 (12") with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - AWWA: 1.0425
 - JIS: RSt37-2 (S235JRG2); HII; 1.0425 (316L)
(DN \leq 300 (12") with Al/Zn protective coating; DN \geq 350 (14") with protective lacquering)
 - AS 2129
 - DN 150 to 300 (6 to 12"), DN 600 (24"): A105 or RSt37-2 (S235JRG2)
 - DN 80 to 100 (3 to 4"), 350 to 500 (14 to 20"): A105 or St44-2 (S275JR)
 - AS 4087: A105 or St44-2 (S275JR)
- Seals: to DIN EN 1514-1
- Ground disks: 1.4435 (316, 316L), Alloy C22, Titanium, Tantalum

Pressure-temperature ratings

The material load diagrams (pressure-temperature diagrams) for the process connections can be found in the separate "Technical Information" documentation, which you can download in PDF format from www.endress.com.

A list of available "Technical Information" documentation can be found in the "Documentation" →  149 section.

Fitted electrodes

Promag E/L

- 2 measuring electrodes for signal detection
- 1 EPD electrode for empty pipe detection
- 1 reference electrode for potential equalization

Promag H

- 2 measuring electrodes for signal detection
- 1 EPD electrode for empty pipe detection, not for DN 2 to 15 (1/12 to 1/2")

Promag P

Available as standard:

- 2 measuring electrodes for signal detection
- 1 EPD electrode for empty pipe detection
- 1 Reference electrode for potential equalization

Optionally available:

- Platinum measuring electrodes only

Promag W

Available as standard:

- 2 measuring electrodes for signal detection
- 1 EPD electrode for empty pipe detection
- 1 Reference electrode for potential equalization

Optionally available:

- Exchangeable measuring electrodes for DN 350 to 2000 (14 to 78")

Process connection

Promag E

Flange connections:

- EN 1092-1 (DIN 2501)
 - DN ≤ 300 (12") = form A
 - DN ≥ 350 (14") = flat face
 - DN 65 PN 16 and DN 600 PN 16 only as per EN 1092-1
- ASME
- JIS

Promag H

With O-ring:

- Weld nipple DIN (EN), ISO 1127, ODT/SMS
- Flange EN (DIN), ASME, JIS
- Flange made of PVDF EN (DIN), ASME, JIS
- External thread
- Internal thread
- Hose connection
- PVC adhesive fitting

With molded seal:

- Weld nipple DIN 11850, ODT/SMS, ASME BPE, ISO 2037
- Clamp ISO 2852, DIN 32676, L14 AM7
- Coupling DIN 11851, DIN 11864-1, ISO 2853, SMS 1145
- Flange DIN 11864-2

Promag L

Flange connection:

- EN 1092-1 (DIN 2501)
 - DN \leq 300 (12") = form A
 - DN \geq 350 (14") = form B
- ASME B16.5
- AWWA C207
- AS

Promag P/W

Flange connections:

- EN 1092-1 (DIN 2501)
 - DN \leq 300 (12") = form A
 - DN \geq 350 (14") = flat face
 - DN 65 PN 16 and DN 600 PN 16 exclusively according to EN 1092-1
- ASME
- AWWA (Promag W only)
- JIS
- AS

Surface roughness

All data relate to parts in contact with fluid.

- Liner \rightarrow PFA: $\leq 0.4 \mu\text{m}$ (15 μin)
- Electrodes: 0.3 to 0.5 μm (12 to 20 μin)
- Process connection made of stainless-steel (Promag H):
 - with O-ring seal: $\leq 1.6 \mu\text{m}$ (63 μin)
 - with aseptic gasket seal: $\leq 0.8 \mu\text{m}$ (31.5 μin)
 - optional: $\leq 0.38 \mu\text{m}$ (15 μin)

10.11 Human interface

Display elements	<ul style="list-style-type: none"> ■ Liquid crystal display: illuminated, four lines with 16 characters per line ■ Custom configurations for presenting different measured values and status variables ■ 3 totalizers ■ At ambient temperatures below -20°C (-4°F), the readability of the display may be impaired.
------------------	---

Operating elements	<ul style="list-style-type: none"> ■ Onsite operation with three optical sensor keys ($[-]/[+]/[E]$) ■ Application-specific Quick Setup menus for straightforward commissioning
--------------------	--

Language group	Language groups available for operation in different countries:
----------------	---

Valid until software version 2.03.XX			
Order code	Option		Contents
Power Supply; Display	WEA	Western Europe and America	English, German, Spanish, Italian, French, Dutch and Portuguese
	EES	Eastern Europe and Scandinavia	English, Russian, Polish, Norwegian, Finnish, Swedish and Czech
	SEA	South and East Asia	English, Japanese, Indonesian
	CN	China	English, Chinese

Valid as of software version 2.07.XX		
Order code	Option	Contents
Power Supply; Display	P, Q	English, German, Spanish, Italian, French
	R, S	English, Russian, Portuguese, Dutch, Czech
	T, U	English, Japanese, Swedish, Norwegian, Finnish
	4, 5	English, Chinese, Indonesian, Polish

You can change the language group via the operating program "FieldCare".

Remote operation	Operation by means of HART protocol
------------------	-------------------------------------

10.12 Certificates and approvals

CE mark	The measuring system complies with the legal requirements of the EU directives. Endress+Hauser confirms that the device has been tested successfully by affixing the CE mark to it.
C-tick mark	The measuring system is in conformity with the EMC requirements of the "Australian Communications and Media Authority (ACMA)".
Ex approval	Information about currently available Ex versions (ATEX, FM, CSA, TIIS, IECEx, NEPSI etc.) can be supplied by your Endress+Hauser Sales Center on request. All explosion protection data are given in a separate documentation which is available upon request.
HART certification	The flowmeter has successfully passed all the test procedures carried out and is certified and registered by the HCF (Hart Communication Foundation). The device thus meets all the requirements of the following specifications: <ul style="list-style-type: none"> ■ Certified in accordance with HART Revisions 5 and 7 (device certification number: available on request) ■ The measuring device can also be operated with certified devices of other manufacturers (interoperability).
Sanitary compatibility	<p><i>Promag H</i></p> <ul style="list-style-type: none"> ■ 3A-approval and EHEDG-certified ■ Seals: FDA-compliant (except for Kalrez seals) <p><i>Promag E/L/P/W</i></p> <p>No applicable approvals or certification</p>
Drinking water approval	<p><i>Promag P</i></p> <ul style="list-style-type: none"> ■ ACS <p><i>Promag W</i></p> <ul style="list-style-type: none"> ■ WRAS BS 6920 ■ ACS ■ NSF 61 ■ KTW/W270
Pressure Equipment Directive	The devices can be ordered with or without a PED approval. If a device with a PED approval is required, this must be explicitly stated in the order. For devices with nominal diameters less than or equal to DN 25 (1"), this is neither possible nor necessary. <ul style="list-style-type: none"> ■ With the PED/G1/x (x = category) marking on the sensor nameplate, Endress+Hauser confirms compliance with the "Essential Safety Requirements" specified in Annex I of the Pressure Equipment Directive 97/23/EC. ■ Devices bearing this marking (PED) are suitable for the following types of medium: Media in Group 1 and 2 with a vapor pressure greater than, or smaller and equal to 0.5 bar (7.3 psi) ■ Devices not bearing this marking (PED) are designed and manufactured according to good engineering practice. They meet the requirements of Art.3 Section 3 of the Pressure Equipment Directive 97/23/EC. The range of application is indicated in tables 6 to 9 in Annex II of the Pressure Equipment Directive.
Other standards and guidelines	<ul style="list-style-type: none"> ■ EN 60529: Degrees of protection by housing (IP code) ■ EN 61010-1 Protection measures for electrical equipment for measurement, control, regulation and laboratory procedures

- IEC/EN 61326
"Emission in accordance with requirements for class A".
Electromagnetic compatibility (EMC requirements).
- ASME/ISA-S82.01
Safety Standard for Electrical and Electronic Test, Measuring, Controlling and related Equipment - General Requirements. Pollution degree 2, Installation Category II.
- CAN/CSA-C22.2 (No. 1010.1-92)
Safety requirements for Electrical Equipment for Measurement and Control and Laboratory Use. Pollution degree 2, Installation Category I.
- NAMUR NE 21
Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment.
- NAMUR NE 43
Standardization of the signal level for the breakdown information of digital transmitters with analog output signal.
- NAMUR NE 53
Software of field devices and signal-processing devices with digital electronics.

10.13 Ordering information

Detailed ordering information is available from the following sources:

- In the Product Configurator on the Endress+Hauser website: www.endress.com → Select country → Instruments → Select device → Product page function: Configure this product
- From your Endress+Hauser Sales Center: www.endress.com/worldwide



Note!

Product Configurator - the tool for individual product configuration

- Up-to-the-minute configuration data
- Depending on the device: Direct input of measuring point-specific information such as measuring range or operating language
- Automatic verification of exclusion criteria
- Automatic creation of the order code and its breakdown in PDF or Excel output format
- Ability to order directly in the Endress+Hauser Online Shop

10.14 Accessories

Various accessories are available for the transmitter and the sensor. These can be ordered separately from Endress+Hauser → 100.



Note!

For detailed information on specific order codes, please contact the Endress+Hauser service organization.

10.15 Documentation

- Flow Measurement (FA00005D/06)
- Promag 53E Technical Information (TI01164D/06)
- Promag 53H Technical Information (TI00048D/06)
- Promag 53P Technical Information (TI00047D/06)
- Promag 53W Technical Information (TI00046D/06)
- Promag 53 Description of Device Functions (BA00048D/06)
- Supplementary documentation on Ex-ratings: ATEX, FM, CSA

Index

A

Accessories	100
Adapters (installation of sensors)	16
Ambient temperature range	126
Applicator (selection and configuration software)	102
Approvals	9
Auxiliary input	
See Status input	

B

Batching	62
Quick Setup	89
Boards	
See Printed circuit boards	

C

Cable entries	
Degree of protection	57
Technical data	124
Cable length (remote version)	19
Cable specifications	50
Cable specifications (remote version)	
Cable length, conductivity	19
Calibration factor	7
CE mark	148
CE mark (Declaration of Conformity)	9
Certificates	9
Change parameter / enter numerical values	63
CIP cleaning	126
Cleaning (exterior cleaning)	99
Cleaning using pigs, Promag H	25
Code entry (function matrix)	64
Commissioning	

"Commissioning" Quick Setup menu	85
"Pulsating flow" Quick Setup menu	86
Configuring current input (active/passive)	95
Configuring current outputs (active/passive)	93
Configuring relay contacts (NC/NO)	96
Empty-pipe/Full-pipe adjustment	97

Commubox FXA 195 (electrical connection)	54, 101
Communication	66
Conductivity of fluid	128
Conductivity of the fluid	

Length of connecting cable (remote version)	19
---	----

Connection	
HART	54
Remote version	46
See Electrical connection	

Control	
Device description files	68
Field Xpert HART Communicator	67
FieldCare	67
C-tick mark	9, 148

Current input	
Active/passive configuration	95
Technical data	123

Current output

Active/passive configuration	93
Technical data	123

D

Data back-up (of device data with T-DAT)	92
Declaration of Conformity (CE mark)	9
Degree of protection	57, 126
Device description files	68
Device designation	6

Device functions

See the "Description of Device Functions" manual	
--	--

Display

Display	60
Display and operating elements	59
Local display	59
See Display	
Turning the display	42
Disposal	121
Documentation, supplementary	149
Down pipes	13
Drinking water approval	148
Druckgerätezulassung	148

E

Electrical connection

Commubox FXA 191	54
Degree of protection	57
HART handheld terminal	54
Post-connection check (checklist)	58
Potential equalization	55
Terminal assignment, transmitter	53

Electrode cleaning circuitry

See the "Description of Device Functions" manual ..	14
---	----

Electrodes

Electrode Cleaning Circuitry (ECC)	14
EPD electrode	14
Measuring electrode plane	14
Reference electrode (potential equalization)	14

Electronics boards

See Printed circuit boards	
----------------------------	--

EMC (Electromagnetic compatibility)

EMC (electromagnetic compatibility)	126
---	-----

Empty pipe detection (EPD)

EPD electrode	14
---------------------	----

Empty-pipe/Full-pipe adjustment

97

Environment

126

Error limits

See Performance characteristics	
---------------------------------	--

Error messages

Confirming error messages	65
Process error (application error)	108
System errors (device errors)	104

Error types (system and process errors)

65

Europäische Druckgeräterichtlinie

148

Ex approval

148

Exterior cleaning

99

F	Foundations (DN > 300)	16
Failsafe mode inputs/outputs	111	
F-Chip	98	
Field Xpert SFX100	54	
FieldCare	67	
Fieldcheck (tester and simulator)	102	
Fitted electrodes	145	
Flow rate/limits	17	
Frequency output		
Technical data	123	
Function check	83	
Function descriptions		
See the "Description of Device Functions" manual		
Function matrix (operation)	63	
Fuse, replacing	118	
FXA193	102	
FXA195	101	
G		
Galvanic isolation	124	
Ground cable		
Promag E	20	
Promag L	26	
Promag P	30	
Promag W	35	
Grounding rings		
Promag H	24	
H		
HART		
Command groups	66	
Command No	70, 74	
Error messages	70	
Field Xpert HART Communicator	67	
Write protection, switching on and off	82	
High-temperature version		
Installation	31	
Temperature ranges	31	
HOME position (operating mode display)	59	
I		
Incoming acceptance	10	
Inlet run	15	
Input	123	
Input signal	123	
Installation	125	
Promag L	26	
Wall-mount housing	43	
Installation conditions		
Down pipes	13	
Foundations, supports	16	
Inlet and outlet runs	15	
Installing pumps	12	
Mounting location	12	
Orientation (vertical, horizontal)	14	
Partially filled pipes	13	
Vibrations	15	
Installing the sensor		
Adapters	16	
L		
Languages	147	
Length of connecting cable (remote version)	125	
Load (output signal)	124	
Local display		
See Display		
Low flow cutoff	124	
M		
Maintenance	99	
Material	142	
Measured variable	123	
Measuring electrodes		
See Electrodes		
Measuring principle	123	
Measuring range	123	
Measuring system	6, 123	
Measuring tube		
Lining, temperature range	127	
Medium pressure range	129	
Medium temperature range	127	
N		
Nameplate		
Connections	8	
Sensor	7	
Transmitter	6	
Nominal diameter and flow rate	17	
O		
Operable flow range	123	
Operating conditions	126	
Operating elements	59	
Operation		
Display and operating elements		
Function matrix	63	
Operational safety	4	
Order code		
Accessories	100	
Sensor	7	
Transmitter	6	
Outlet runs	15	
Output	123	
Output signal	123	
P		
Performance characteristics		
Maximum measured error	125	
Reference operating conditions	125	
Pigs (cleaning)	25	
Post-installation check (checklist)	45	
Power consumption	124	

Power supply	124
Power supply failure	125
Pressure Equipment Directive	148
Pressure loss	
Adapters (reducers, expanders)	16
General information	132
Pressure tightness	130
Pressure-temperature ratings	144
Printed circuit boards, removing and installing	
Field housing	114
Wall-mount housing	116
Process connection	145
Process error	
Definition	65
Process error messages	108
Programming mode	
Disable	64
Enable	64
Promag E	
Ground cable	20
Installation	20
Seals	20
Tightening torques	21
Promag H	
Cleaning using pigs	25
Grounding rings	24
Installation	23
Seals	23
Weld nipple	25
Promag L	
Ground cable	26
Installation	26
Seals	26
Tightening torques	27
Promag P	
Ground cable	30
High-temperature version	31
Installation	30
Seals	30
Tightening torques	31
Promag W	
Ground cable	35
Installation	35
Seals	35
Tightening torques	36
Pulsating flow	86
Pulse output	
See Frequency output	
Pumps	
Mounting location	12
Pump types, pulsating flow	86

Q

Quick Setup	
Batching	89
Commissioning	85
Data back-up (of device data with T-DAT)	92
Pulsating flow	86
Transfer data	92

R

Registered trademarks	9
Relay output	
Configure relay contact (NC/NO)	96
Technical data	124
Remote operation	147
Remote version	
Connection	46
Replacing	
Device fuse	118
Electronics boards (installing/removing)	114
Exchangeable electrode	119

S

Safety icons	5
Safety instructions	4
Sanitary compatibility	148
S-DAT (HistoROM)	98
Seals	99
Promag E	20
Promag H	23
Promag L	26
Promag P	30
Promag W	35
Seals (sensor process connection)	20, 30, 35
Sensor installation	
See Installing sensor	
Serial number	6-8
Service interface	
Commubox FXA291	102
Shock resistance	126
Signal on alarm	124
SIP cleaning	126
Software	
Amplifier display	83
Versions (History)	121
Spare parts	113
Standards, guidelines	148
Status input	
Technical data	123
Storage	11
Storage temperature	126
Supply voltage	124
Surface roughness	146
Switching output	
See Relay output	
System error	
Definition	65
System error messages	104

T

T-DAT (HistoROM)	
Description	98
Save/load (data back-up, e.g. for replacing devices)	92
Temperature	
Storage	126
Temperature ranges	
Ambient temperature range	126
Fluid temperature	127

Tightening torques	
Promag E.....	21
Promag L.....	27
Promag P.....	31
Promag W.....	36
Transmitter	
Electrical connection	51
Installing the wall-mount housing	43
Length of connecting cable (remote version).....	19
Turning the field housing (aluminum)	41
Turning the field housing (stainless steel)	41
Transporting the sensor	10
Troubleshooting instructions.....	103
V	
Vibration resistance	126
Vibrations.....	15
Measures to prevent vibrations	15
Shock and vibration resistance.....	126
W	
Wall-mount housing, installing.....	43
Weight	
(SI units)	133
(US units)	139
Weld nipple, Promag H.....	25
Wiring	
See Electrical connection	
Write protection (HART on/off)	82

www.addresses.endress.com
