

# *SIP Call Button*

## *Operations Guide*

**Part #011049**

Document Part #930801C  
for Firmware Version 10.0.1

**CyberData Corporation**  
3 Justin Court  
Monterey, CA 93940  
(831) 373-2601

---

---

**SIP Call Button Operations Guide 930801C**  
**Part # 011049**

**COPYRIGHT NOTICE:**  
© 2014, CyberData Corporation, ALL RIGHTS RESERVED.

This manual and related materials are the copyrighted property of CyberData Corporation. No part of this manual or related materials may be reproduced or transmitted, in any form or by any means (except for internal use by licensed customers), without prior express written permission of CyberData Corporation. This manual, and the products, software, firmware, and/or hardware described in this manual are the property of CyberData Corporation, provided under the terms of an agreement between CyberData Corporation and recipient of this manual, and their use is subject to that agreement and its terms.

**DISCLAIMER:** Except as expressly and specifically stated in a written agreement executed by CyberData Corporation, CyberData Corporation makes no representation or warranty, express or implied, including any warranty or merchantability or fitness for any purpose, with respect to this manual or the products, software, firmware, and/or hardware described herein, and CyberData Corporation assumes no liability for damages or claims resulting from any use of this manual or such products, software, firmware, and/or hardware. CyberData Corporation reserves the right to make changes, without notice, to this manual and to any such product, software, firmware, and/or hardware.

**OPEN SOURCE STATEMENT:** Certain software components included in CyberData products are subject to the GNU General Public License (GPL) and Lesser GNU General Public License (LGPL) "open source" or "free software" licenses. Some of this Open Source Software may be owned by third parties. Open Source Software is not subject to the terms and conditions of the CyberData **COPYRIGHT NOTICE** or software licenses. Your right to copy, modify, and distribute any Open Source Software is determined by the terms of the GPL, LGPL, or third party, according to who licenses that software.

Software or firmware developed by CyberData that is unrelated to Open Source Software is copyrighted by CyberData, subject to the terms of CyberData licenses, and may not be copied, modified, reverse-engineered, or otherwise altered without explicit written permission from CyberData Corporation.

**TRADEMARK NOTICE:** CyberData Corporation and the CyberData Corporation logos are trademarks of CyberData Corporation. Other product names, trademarks, and service marks may be the trademarks or registered trademarks of their respective owners.



Technical Support

The fastest way to get technical support for your VoIP product is to submit a VoIP Technical Support form at the following website:  
<http://www.cyberdata.net/support/contactsupportvoip.php>

Phone: (831) 373-2601, Ext. 333

Email: support@cyberdata.net

Fax: (831) 373-4193

Company and product information is at [www.cyberdata.net](http://www.cyberdata.net).


# Important Safety Instructions

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
13. Prior to installation, consult local building and electrical code requirements.

**14. WARNING: The SIP Call Button enclosure is not rated for any AC voltages!**

 GENERAL ALERT	<p><b>Warning</b></p> <p><i>Electrical Hazard:</i> This product should be installed by a licensed electrician according to all local electrical and building codes.</p>
 GENERAL ALERT	<p><b>Warning</b></p> <p><i>Electrical Hazard:</i> To prevent injury, this apparatus must be securely attached to the floor/wall in accordance with the installation instructions.</p>
 GENERAL ALERT	<p><b>Warning</b></p> <p>The PoE connector is intended for intra-building connections only and does not route to the outside plant.</p>

## Pictorial Alert Icons

 GENERAL ALERT	<p><b>General Alert</b> This pictorial alert indicates a potentially hazardous situation. This alert will be followed by a hazard level heading and more specific information about the hazard.</p>
	<p><b>Ground</b> This pictorial alert indicates the Earth grounding connection point.</p>

## Hazard Levels

**Danger:** Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury. This is limited to the most extreme situations.

**Warning:** Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

**Caution:** Indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury. It may also alert users against unsafe practices.

**Notice:** Indicates a statement of company policy (that is, a safety policy or protection of property).

The safety guidelines for the equipment in this manual do not purport to address all the safety issues of the equipment. It is the responsibility of the user to establish appropriate safety, ergonomic, and health practices and determine the applicability of regulatory limitations prior to use. Potential safety hazards are identified in this manual through the use of words Danger, Warning, and Caution, the specific hazard type, and pictorial alert icons.

---

## Abbreviations and Terms

Abbreviation or Term	Definition
A-law	A standard companding algorithm, used in European digital communications systems to optimize, i.e., modify, the dynamic range of an analog signal for digitizing.
AVP	Audio Video Profile
Cat 5	TIA/EIA-568-B Category 5
DHCP	Dynamic Host Configuration Protocol
LAN	Local Area Network
LED	Light Emitting Diode
Mbps	Megabits per Second.
NTP	Network Time Protocol
PBX	Private Branch Exchange
PoE	Power over Ethernet (as per IEEE 802.3af standard)
RTFM	Reset Test Function Management
SIP	Session Initiated Protocol
u-law	A companding algorithm, primarily used in the digital telecommunication
UC	Unified Communications
VoIP	Voice over Internet Protocol

---

## Revision Information

Revision 930801C, which corresponds to firmware version 10.0.1, was released on March 11, 2014, and has the following changes:

- Adds the following warning to the following sections:
  - [Important Safety Instructions](#)
  - [Section 1.2, "Typical System Installation"](#)
  - [Section 2.2.2, "Connecting a Device to the Auxiliary Relay"](#)
  - [Section A.1, "Important Safety Instructions"](#)
- Warning Text: ["The PoE connector is intended for intra-building connections only and does not route to the outside plant."](#)

---

## Browsers Supported

The following browsers have been tested against firmware version 10.0.1:

- Internet Explorer (version: 10)
- Firefox (also called Mozilla Firefox) (version: 23.0.1 and 25.0)
- Chrome (version: 29.0.1547.66 m)
- Safari (version: 5.1.7)

# Contents

---

<b>Chapter 1 Product Overview</b>	<b>1</b>
1.1 How to Identify This Product .....	1
1.2 Typical System Installation .....	2
1.3 Product Features .....	3
1.4 Supported Protocols .....	3
1.5 Supported SIP Servers .....	4
1.6 Product Specifications .....	4
1.7 Dimensions .....	5
<b>Chapter 2 Installing the SIP Call Button</b>	<b>6</b>
2.1 Parts List .....	6
2.2 SIP Call Button Setup .....	7
2.2.1 SIP Call Button Connections .....	7
2.2.2 Connecting a Device to the Auxiliary Relay .....	8
2.2.3 Identifying the SIP Call Button Connectors and Jumpers .....	10
2.2.4 Network Connectivity and Data Rate .....	12
2.2.5 Restore the Factory Default Settings .....	13
2.2.6 Call Button and the Call Button LED .....	14
2.3.1 Intercom Web Page Navigation .....	16
2.3.2 Log in to the Configuration Home Page .....	17
2.3.3 Configure the Device .....	20
2.3.4 Configure the Network Parameters .....	22
2.3.5 Configure the SIP Parameters .....	24
2.3.6 Configure the Sensor Configuration Parameters .....	29
2.3.7 Configure the Audio Configuration Parameters .....	32
2.3.8 Configure the Event Parameters .....	36
2.3.9 Configure the Autoprovisioning Parameters .....	41
2.4.1 Reboot the Intercom .....	51
2.5.1 Command Interface Post Commands .....	52
<b>Appendix A Mounting the SIP Call Button</b>	<b>1</b>
A.1 Important Safety Instructions .....	1
A.2 Mount the SIP Call Button .....	2
<b>Appendix B Troubleshooting/Technical Support</b>	<b>7</b>
B.1 Frequently Asked Questions (FAQ) .....	7
B.2 Documentation .....	7
B.3 Contact Information .....	8
B.4 Warranty .....	9
B.4.1 Warranty & RMA Returns within the United States .....	9
B.4.2 Warranty & RMA Returns Outside of the United States .....	9
B.4.3 Spare in the Air Policy .....	10
B.4.4 Return and Restocking Policy .....	10
B.4.5 Warranty and RMA Returns Page .....	10
<b>Index</b>	<b>11</b>

# 1 Product Overview

## 1.1 How to Identify This Product

To identify the SIP Call Button, look for a model number label similar to the one shown in [Figure 1-1](#). Confirm the following:

- The model number on the label should be **011049**.
- The serial number on the label should begin with **0491**.

**Figure 1-1. Model Number Label**




## 1.2 Typical System Installation

The Session Initiation Protocol (SIP) Intercom is a SIP endpoint designed to provide VoIP phone connectivity in a tamper proof and secure package.


Figure 1-2 illustrate how the SIP Call Buttons can be installed as part of a VoIP phone system.

**Figure 1-2. Typical Installation**



 GENERAL ALERT	<p><b>Warning</b></p> <p><i>Electrical Hazard:</i> The device enclosure is not rated for any AC voltages.</p>
 GENERAL ALERT	<p><b>Warning</b></p> <p><i>Electrical Hazard:</i> This product should be installed by a licensed electrician according to all local electrical and building codes.</p>
 GENERAL ALERT	<p><b>Warning</b></p> <p><i>Electrical Hazard:</i> To prevent injury, this apparatus must be securely attached to the floor/wall in accordance with the installation instructions.</p>
 GENERAL ALERT	<p><b>Warning</b></p> <p>The PoE connector is intended for intra-building connections only and does not route to the outside plant.</p>

## 1.3 Product Features



- SIP
- User downloadable message up to 80 seconds
- Single button call to pre-set number
- Continuous repeat of message
- Call progress light
- Event-controlled relay
- Tamper sensor
- Web-based setup
- PoE-powered

## 1.4 Supported Protocols

The Intercom supports:

- SIP
- HTTP Web-based configuration

Provides an intuitive user interface for easy system configuration and verification of Intercom operations.

- DHCP Client
- RTP
- RTP/AVP - Audio Video Profile
- Audio Encodings
  - PCMU (G.711 mu-law)
  - PCMA (G.711 A-law)
  - Packet Time 20 ms

## 1.5 Supported SIP Servers

Go to the following link to find the SIP Call Button product page which will have information on how to configure the SIP Call Button for various supported SIP servers:

<http://www.cyberdata.net/support/server/index.html>


---

## 1.6 Product Specifications

Category	Specification
Network Rate	10/100 Mbps
Power Requirement	802.3af compliant or 5V at 1000 mA
Protocol	SIP
Part Number	011049
Dimensions	4.5" x 4.5" x 1.5"
Weight	1.6 lbs./shipping weight of 2.2 lbs. (0.7 kg/shipping weight of 1.0kg)
Auxiliary Relay	1A at 30 VDC

## 1.7 Dimensions

Figure 1-3. Dimensions—Size of Unit with Case




# 2 Installing the SIP Call Button

## 2.1 Parts List

[Table 2-1](#) illustrates the SIP Call Button parts.

**Table 2-1. Parts List**

Quantity	Part Name	Illustration
1	Intercom Assembly	
1	Installation Quick Reference Guide	
1	Intercom Mounting Accessory Kit	


## 2.2 SIP Call Button Setup

### 2.2.1 SIP Call Button Connections

Figure 2-1 shows the pin connections on the J7 (terminal block). This terminal block can accept 16 AWG gauge wire.

**Note** As an alternative to using PoE power, you can supply 12VDC at 1000 mA into the terminal block.

Figure 2-1. SIP Call Button Connections



## 2.2.2 Connecting a Device to the Auxiliary Relay


The SIP Call Button incorporates an on-board relay which enables users to control an external relay for activating an auxiliary device such as an electric door strike (see [Figure 2-2](#)). The SIP Call Button relay contacts are limited to 1 amp at 30VDC. The SIP Call Button relay activation time is selectable through the web interface and is controlled by DTMF tones generated from the phone being called. The DTMF tones are selectable from the web interface as well.

 GENERAL ALERT	<b>Warning</b> <i>Electrical Hazard:</i> The device enclosure is not rated for any AC voltages.
 GENERAL ALERT	<b>Warning</b> <i>Electrical Hazard:</i> This product should be installed by a licensed electrician according to all local electrical and building codes.
 GENERAL ALERT	<b>Warning</b> <i>Electrical Hazard:</i> To prevent injury, this apparatus must be securely attached to the floor/wall in accordance with the installation instructions.
 GENERAL ALERT	<b>Warning</b> <i>Electrical Hazard:</i> The relay contacts are dry and provided for a normally open and momentarily closed configuration. Neither the alternate power input nor PoE power can be used to drive a door strike.
 GENERAL ALERT	<b>Warning</b> The PoE connector is intended for intra-building connections only and does not route to the outside plant.

**Note** The three digit code for the auxiliary relay must be sent in conformance with RFC2833 DTMF generation.

The device incorporates an on-board relay which enables users to control an external relay for activating an auxiliary device such as an electric door strike (see [Figure 2-2, "Auxiliary Relay Wiring Diagram"](#)).


The relay contacts are limited to 1A at 30 VDC. The relay activation time is selectable through the web interface and is controlled by DTMF tones generated from the phone being called. The DTMF tones are selectable from the web interface as well.



## 2.2.3 Identifying the SIP Call Button Connectors and Jumpers

See the following figures and tables to identify the SIP Call Button connector locations and functions.

**Figure 2-3. Connector Locations**



**Table 2-2. Connector Functions**

Connector	Function
J2	Call Button Interface — Not Used
J6	Microphone Interface — Not Used
J7	Speaker Interface — Not Used
J8	Keypad Interface -- Not Used
J10	Proximity Sensor Interface — Not Used

Figure 2-4. Connector Locations




Table 2-3. Connector Functions


Connector	Function
J1	Ethernet Connector
J3	User Terminal Block Interface
J4	Reserved (Factory Use Only)
J5	Reserved (Factory Use Only)
J9	Strobe Power Interface (Reserved for future use)
J12	Reserved (Factory Use Only)

## 2.2.4 Network Connectivity and Data Rate

When you plug in the Ethernet cable (Figure 2-5) or power supply:

- The square, **GREEN Link** LED above the Ethernet port indicates that the network connection has been established (Figure 2-5). The Link LED changes color to confirm the auto-negotiated baud rate:
  - The **Link** LED is **YELLOW** at 10 Mbps.
  - The **Link** LED is **ORANGE** at 100 Mbps.
- The square, **YELLOW Activity** LED (Figure 2-5) blinks when there is network activity.

Figure 2-5. Link and Activity LEDs



## 2.2.5 Restore the Factory Default Settings


### 2.2.5.1 RTFM Switch

When the Intercom is operational and linked to the network, use the Reset Test Function Management (RTFM) switch ([Figure 2-6](#)) to set the factory default settings.

**Note** Each Intercom is delivered with factory set default values.

**Note** The Intercom will use DHCP to obtain the new IP address (DHCP-assigned address or default to 10.10.10.10 if a DHCP server is not present).

**Figure 2-6. RTFM Switch**



To set the factory default settings:

1. Press and hold the **RTFM** switch until the button LED starts blinking rapidly (about 10 seconds), then release the RTFM switch.

## 2.2.6 Call Button and the Call Button LED


### 2.2.6.1 Calling with the The Call Button

- You may initiate a call by pressing the **Call** button.
- An active call is indicated by the Call Button LED blinking at one second intervals.
- You can press the **Call** button to terminate an active call.

### 2.2.6.2 Call Button LED Function

- Upon initial power or reset, the Call Button LED will illuminate.
- During network setup the Call Button LED will blink 10 times per second. This can take from 5 to 60 seconds.
- When the software has finished initialization, the Call Button LED will blink twice.
- On the **Device Configuration Page**, there is an option called **Button Lit When Idle**. This option sets the normal state for the indicator light. The Call Button LED will still blink during initialization and calls.

**Figure 2-7. Call Button and Call Button LED**



## 2.3 Configure the Intercom Parameters

To configure the Intercom online, use a standard web browser.

Configure each Intercom and verify its operation *before* you mount it. When you are ready to mount an Intercom, refer to [Appendix A, "Mounting the SIP Call Button"](#) for instructions.

All Intercoms are initially configured with the following default IP settings:

When configuring more than one Intercom, attach the Intercoms to the network and configure one at a time to avoid IP address conflicts.

**Table 2-4. Factory Default Settings**



Parameter	Factory Default Setting
IP Addressing	DHCP
IP Address <sup>a</sup>	10.10.10.10
Web Access Username	admin
Web Access Password	admin
Subnet Mask <sup>a</sup>	255.0.0.0
Default Gateway <sup>a</sup>	10.0.0.1

a. Default if there is not a DHCP server present.

### 2.3.1 Intercom Web Page Navigation

Table 2-5 shows the navigation buttons that you will see on every Intercom web page.

**Table 2-5. Web Page Navigation**

Web Page Item	Description
 Home	Link to the <b>Home</b> page.
 Device Config	Link to the <b>Device Configuration</b> page.
 Networking	Link to the <b>Networking</b> page.
 SIP Config	Link to go to the <b>SIP Configuration</b> page.
 Sensor Config	Link to the <b>Sensor Configuration</b> page.
 Audio Config	Link to the <b>Audio Configuration</b> page.
 Event Config	Link to the <b>Event Configuration</b> page.
 Autoprovisioning	Link to the <b>Autoprovisioning Configuration</b> page.
 Update Firmware	Link to the <b>Update Firmware</b> page.

## 2.3.2 Log in to the Configuration Home Page

1. Open your browser to the Intercom IP address.

**Note** If the network does not have access to a DHCP server, the device will default to an IP address of 10.10.10.10.

**Note** Make sure that the PC is on the same IP network as the Intercom.

**Note** You may also download CyberData's VoIP Discovery Utility program which allows you to easily find and configure the default web address of the CyberData VoIP products.

CyberData's VoIP Discovery Utility program is available at the following website address:

[http://www.cyberdata.net/support/voip/discovery\\_utility.html](http://www.cyberdata.net/support/voip/discovery_utility.html)


**Note** The Call Button ships in DHCP mode. To get to the **Home** page, use the discovery utility to scan for the device on the network and open your browser from there.

2. When prompted, use the following default **Web Access Username** and **Web Access Password** to access the **Home Page** (Figure 2-8):

Web Access Username: **admin**

Web Access Password: **admin**

Figure 2-8. Home Page



3. On the **Home Page**, review the setup details and navigation buttons described in [Table 2-6](#).


**Table 2-6. Home Page Overview**

Web Page Item	Description
<b>Device Settings</b>	
Device Name	Shows the device name.
Change Username	Type in this field to change the username.
Change Password	Type in this field to change the password.
Re-enter Password	Type the password again in this field to confirm the new password.
<b>Current Settings</b>	
Serial Number	Shows the device serial number.
Mac Address	Shows the device Mac address.
Firmware Version	Shows the current firmware version.
IP Addressing	Shows the current IP addressing setting ( <b>DHCP</b> or <b>static</b> ).
IP Address	Shows the current IP address.
Subnet Mask	Shows the current subnet mask address.
Default Gateway	Shows the current default gateway address.
DNS Server 1	Shows the current DNS Server 1 address.
DNS Server 2	Shows the current DNS Server 2 address.
SIP Mode is	Shows the current status of the SIP mode.
Event Reporting is	Shows the current status of the Event Reporting mode.
Primary SIP Server	Shows the current status of the Primary SIP Server.
Backup Server 1	Shows the current status of Backup Server 1.
Backup Server 2	Shows the current status of Backup Server 2.
<b>Import/Export Settings</b>	
<b>Browse...</b>	Press the <b>Browse</b> button to select a configuration file to import.
<b>Import Configuration</b>	Press the <b>Import Configuration</b> button to save a board configuration to the board. <b>Note:</b> The board will have to be reset before changes will take effect.
<b>Export Configuration</b>	Press the <b>Export Configuration</b> button to download the current board configuration.
<b>Save</b>	Click on the <b>Save</b> button to save your configuration settings. <b>Note:</b> You need to reboot for changes to take effect.
<b>Reboot</b>	Click on the <b>Reboot</b> button to reboot the system.

### 2.3.3 Configure the Device

1. Click the **Device Configuration** button to open the **Device Configuration** page. See [Figure 2-9](#).

**Figure 2-9. Device Configuration Page**



2. On the **Device Configuration** page, you may enter values for the parameters indicated in [Table 2-7](#).

**Table 2-7. Device Configuration Parameters**

Web Page Item	Description
<b>Relay Settings</b>	
Activate Relay with DTMF Code	When selected, the relay can be activated with a DTMF code.
DTMF Activation Code	Type the desired DTMF activation code (25 character limit).
DTMF Activation Duration (in seconds)	Type the desired DTMF activation duration (in seconds) (2 character limit [activation times now go up to 99 seconds]).  <b>NOTE:</b> A DTMF activation duration of <b>0</b> will toggle the relay indefinitely or until the activation code is sent again
Activate Relay While Call Active	When selected, the relay will be activated for as long as the call is active.
Activate Relay on Button Press	When selected, the relay will be activated when the Call Button is pressed.
Relay on Button Press Timeout (in seconds)	Type the desired time (in seconds) that you want the relay to activate after the Call Button is pressed (1 character limit).
<b>Miscellaneous Settings</b>	
Button Lit When Idle	When selected, the Call Button LED remains on when idle.
<b>Save</b>	Click the <b>Save</b> button to save your configuration settings. <b>Note:</b> You need to reboot for changes to take effect.
<b>Test Relay</b>	Click on the <b>Test Relay</b> button to do a relay test.
<b>Reboot</b>	Click on the <b>Reboot</b> button to reboot the system.

3. You must click on the **Save** button and then the **Reboot** button for the changes to take effect.

## 2.3.4 Configure the Network Parameters

1. Click the **Networking** button to open the **Network Configuration** page (Figure 2-10).

**Figure 2-10. Network Configuration Page**

**CyberData SIP Call Button**

**Network Configuration**

**Stored Network Settings**

IP Addressing:	<input type="radio"/> Static <input checked="" type="radio"/> DHCP
IP Address:	10.10.10.10
Subnet Mask:	255.0.0.0
Default Gateway:	10.0.0.1
DNS Server 1:	10.0.0.1
DNS Server 2:	10.0.0.1
Hostname:	SipDevice0232a3
VLAN ID (0-4095):	0
VLAN Priority (0-7):	0

**DHCP Timeout**

DHCP Timeout in seconds\*: 60

\* A value of -1 will retry forever

\* You need to reboot for changes to take effect

**Save** **Reboot**

2. On the **Network Configuration** page, enter values for the parameters indicated in [Table 2-8](#).

**Table 2-8. Network Configuration Parameters**

Web Page Item	Description
<b>Stored Network Settings</b>	
IP Addressing	Select either <b>DHCP IP Addressing</b> or <b>Static IP Addressing</b> by marking the appropriate radio button. If you select <b>Static</b> , configure the remaining parameters indicated in <a href="#">Table 2-8</a> . If you select <b>DHCP</b> , go to <a href="#">Step 3</a> .
IP Address	Enter the Static IP address.
Subnet Mask	Enter the Subnet Mask address.
Default Gateway	Enter the Default Gateway address.
DNS Server 1	Enter the DNS Server 1 address.
DNS Server 2	Enter the DNS Server 2 address.
Hostname	This is the hostname provided to the DHCP server. This can be used in conjunction with a DNS server to address the device by host name instead of by IP address. Check your DHCP server and DNS server documentation for more information.
VLAN ID (0-4095)	Enter the VLAN ID number.  <b>Note:</b> The device supports 802.11Q VLAN tagging support. The switch port connected to the device will need to be in “trunking mode” for the VLAN tags to propagate.
VLAN Priority (0-7)	Enter the VLAN priority number.
<b>DHCP Timeout</b>	
DHCP Timeout in seconds	Enter the desired timeout duration (in seconds) that the device will wait for a response from the DHCP server before defaulting back to the stored static IP address.  <b>Note:</b> A value of <b>-1</b> will cause the device to retry indefinitely and a value of <b>0</b> will cause the device to reset to a default of 60 seconds.
<b>Save</b>	Click the <b>Save</b> button to save your configuration settings.  <b>Note:</b> You need to reboot for changes to take effect.
<b>Reboot</b>	Click on the <b>Reboot</b> button to reboot the system.

3. You must click on the **Save** button and then the **Reboot** button for the changes to take effect.

## 2.3.5 Configure the SIP Parameters

1. Click **SIP Config** to open the **SIP Configuration** page (Figure 2-11).

**Note** For specific server configurations, go to the following website address:

<http://www.cyberdata.net/support/server/index.html>

Figure 2-11. SIP Configuration Page

**SIP Configuration**

Enable SIP operation:  (NOT Registered)

**SIP Settings**

Primary SIP Server [registration\_status]: 10.0.0.253  
Primary SIP User ID: 199  
Primary SIP Auth ID: 199  
Primary SIP Auth Password: •••••

Backup SIP Server 1 (NOT Registered):  
Backup SIP User ID 1:  
Backup SIP Auth ID 1:  
Backup SIP Auth Password 1:

Backup SIP Server 2 (NOT Registered):  
Backup SIP User ID 2:  
Backup SIP Auth ID 2:  
Backup SIP Auth Password 2:

Use Cisco SRST:

Remote SIP Port: 5060  
Local SIP Port: 5060  
Outbound Proxy:  
Outbound Proxy Port: 0

Register with a SIP Server:   
Re-registration Interval (in seconds): 360  
NAT ping (check box if PBX is not local):   
Disable rport Discovery:

**Call disconnection**

Terminate call after delay (in seconds): 0  
Note: A value of 0 will disable this function

**RTP Settings**

RTP Port (even): 10500

**Dial Out Settings**

Dial out Extension: 204  
Extension ID: id204

\* You need to reboot for changes to take effect

**Buttons**

Save Reboot

2. On the **SIP Configuration** page, enter values for the parameters indicated in [Table 2-9](#).

**Table 2-9. SIP Configuration Parameters**

Web Page Item	Description
Enable SIP Operation	Enables or disables SIP operation.
<b>SIP Settings</b>	
Primary SIP Server [registration status]	Type the SIP server represented as either a numeric IP address in dotted decimal notation or the fully qualified host name (255 character limit [FQDN]).
Primary SIP User ID	Type the <b>SIP User ID</b> for the Primary SIP Server (up to 64 alphanumeric characters).
Primary SIP Auth ID	Type the <b>SIP Authenticate ID</b> for the Primary SIP Server (up to 64 alphanumeric characters).
Primary SIP Auth Password	Type the <b>SIP Authenticate Password</b> for the Primary SIP Server (up to 64 alphanumeric characters).
Backup SIP Server 1	<ul style="list-style-type: none"> <li>If all of the <b>SIP Server</b> and <b>Backup SIP Server</b> fields are populated, the device will attempt to stay registered with all three servers all of the time. You can leave the <b>Backup SIP Server 1</b> and <b>Backup SIP Server 2</b> fields blank if they are not needed.</li> <li>In the event of a registration failure on the <b>Primary SIP Server</b>, the device will use the next highest priority server for outbound calls (<b>Backup SIP Server 1</b>). If <b>Backup SIP Server 1</b> fails, the device will use <b>Backup SIP Server 2</b>.</li> <li>If a higher priority SIP Server comes back online, the device will switch back to this server.</li> </ul>
Backup SIP Server 2	
Backup SIP User ID 1	Type the <b>SIP User ID</b> for the Backup SIP Server (up to 64 alphanumeric characters).
Backup SIP User ID 2	Type the <b>SIP User ID</b> for the Backup SIP Server (up to 64 alphanumeric characters).
Backup SIP Auth ID 1	Type the <b>SIP Authenticate ID</b> for the Backup SIP Server (up to 64 alphanumeric characters).
Backup SIP Auth ID 2	Type the <b>SIP Authenticate ID</b> for the Backup SIP Server (up to 64 alphanumeric characters).
Backup SIP Auth Password 1	Type the <b>SIP Authenticate Password</b> for the Backup SIP Server (up to 64 alphanumeric characters).
Backup SIP Auth Password 2	Type the <b>SIP Authenticate Password</b> for the Backup SIP Server (up to 64 alphanumeric characters).
Use Cisco SRST	When selected, the backup servers are handled according to Cisco SRST (Survivable Remote Site Telephony).
Remote SIP Port	Type the <b>Remote SIP Port</b> number (default 5060) (5 character limit [values from 1 to 65535]).
Local SIP Port	Type the <b>Local SIP Port</b> number (default 5060) (5 character limit [values from 2000 to 65535]).
Outbound Proxy	Type the Outbound Proxy as either a numeric IP address in dotted decimal notation or the fully qualified host name (255 character limit [FQDN]).
Outbound Proxy Port	Type the Outbound Proxy Port number (5 character limit [values from 1 to 65535]).
Register with a SIP Server	Check this box to enable SIP Registration.
Re-registration Interval (in seconds)	Type the SIP registration lease time (in seconds).

**Table 2-9. SIP Configuration Parameters (continued)**

Web Page Item	Description
NAT ping (check box if PBX is not local)	Check this box if the PBX server is remote and you are experiencing problems establishing calls with the PBX.
Disable rport Discovery	Check this box prevent the device from including the public WAN IP address in the contact information that is sent to the remote SIP servers. This will generally only need to be enabled when using an SBC in conjunction with a remote SIP server.
<b>Call Disconnection</b>	
Terminate call after delay (in seconds)	Type the desired number of seconds that you want to transpire before a call is terminated.  <b>Note:</b> A value of <b>0</b> will disable this function.
<b>RTP Settings</b>	
RTP Port (even)	Specify the port number used for the RTP stream after establishing a SIP call. This port number has to be an even number and defaults to 10500.
<b>Dial Out Settings</b>	
Dial Out Extension	Type the dial out extension number (64 character limit).  <b>Note:</b> For information about dial-out extension strings and DTMF tones, see <a href="#">Section 2.3.5.1, "Dial Out Extension Strings and DTMF Tones (using rfc2833)".</a>
Extension ID	Type the desired Extension ID (64 character limit).
<b>Save</b>	Click the <b>Save</b> button to save your configuration settings.  <b>Note:</b> You need to reboot for changes to take effect.
<b>Reboot</b>	Click on the <b>Reboot</b> button to reboot the system.

3. You must click on the **Save** button and then the **Reboot** button for the changes to take effect.

### 2.3.5.1 Dial Out Extension Strings and DTMF Tones (using rfc2833)

On the [SIP Configuration Page](#), dial out extensions support the addition of comma delimited pauses and sending additional DTMF tones (using rfc2833). The first comma will pause three seconds after a call is first established with a remote device. Subsequent commas will pause for 2 seconds. A pause of one second will be sent after each numerical digit.

**Table 2-10. Examples of Dial-Out Extension Strings**

Extension String	Resulting Action
302	Dial out extension 302 and establish a call
302,,2	Dial out extension 302 and establish a call, wait 3 seconds then send the DTMF tone '2'
302,25,,,4,,1	Dial out extension 302 and establish a call, wait 3 seconds then send the DTMF tone '2', send out DTMF tone 5, wait 6 seconds, send out DTMF tone 4, wait 4 seconds, send out DTMF tone 1

**Note** The maximum number of total characters in the dial-out field is 64.

### 2.3.5.2 Point-to-Point Configuration

When the board is set to not register with a SIP server (see [Figure 2-12](#)), it's possible to set the intercom to dial out to a single endpoint.

In this case, the dial-out extension should be the IP address of the remote device. The Intercom can also receive Point-to-Point calls. The delayed DTMF functionality is available in the Point-to-Point Mode.

**Note** Receiving point-to-point SIP calls may not work with all phones.

**Figure 2-12. SIP Configuration Page Set to Point-to-Point Mode**

**CyberData SIP Call Button**

**SIP Configuration**

Enable SIP operation:  (NOT Registered)

**SIP Settings**

Primary SIP Server [registration\_status]: 10.0.0.253  
Primary SIP User ID: 199  
Primary SIP Auth ID: 199  
Primary SIP Auth Password: •••••

Backup SIP Server 1 (NOT Registered):  
Backup SIP User ID 1:  
Backup SIP Auth ID 1:  
Backup SIP Auth Password 1:

Backup SIP Server 2 (NOT Registered):  
Backup SIP User ID 2:  
Backup SIP Auth ID 2:  
Backup SIP Auth Password 2:

Use Cisco SRST:

Remote SIP Port: 5060  
Local SIP Port: 5060  
Outbound Proxy:  
Outbound Proxy Port: 0

Register with a SIP Server:  
Re-registration Interval (in seconds): 360  
NAT ping (check box if PBX is not local):   
Disable rport Discovery:

Call disconnection  
Terminate call after delay (in seconds): 0  
Note: A value of 0 will disable this function

RTP Settings  
RTP Port (even): 10500

Dial Out Settings  
Dial out Extension: 10.0.1.40  
Extension ID: id204

\* You need to reboot for changes to take effect

Save Reboot

Intercom is set to NOT register with a SIP server

### 2.3.5.3 Delayed DTMF

On the **SIP Configuration** page the dial out extension supports the addition of comma delimited pauses and sending additional DTMF tones (using rfc2833). The first comma will pause three seconds after a call is first established with a remote device. Subsequent commas will pause for 2 seconds. A pause of one second will be sent after each numerical digit.

**Table 2-11. Examples of Dial-Out Extension Strings**

Extension String	Resulting Action
302	Dial out extension 302 and establish a call
302,,2	Dial out extension 302 and establish a call, wait 3 seconds then send the DTMF tone '2'
302,25,,,4,,1	Dial out extension 302 and establish a call, wait 3 seconds then send the DTMF tone '2', send out DTMF tone 5, wait 6 seconds, send out DTMF tone 4, wait 4 seconds, send out DTMF tone 1

**Note** The maximum number of total characters in the dial-out field is 25.

## 2.3.6 Configure the Sensor Configuration Parameters

The door sensor (pins 5 and 6) on the header can be used to monitor a door's open or closed state. There is an option on the **Sensor Configuration** page to trigger on an open or short condition on these pins. The door sensor alarm will be activated when the **Door Open Timeout** parameter has been met.

The intrusion sensor is an optical sensor installed on the Call Button board and will be activated when the Call Button is removed from the case.

For each sensor there are four actions the Call Button can take:

- Flash the LED until the sensor is deactivated (roughly 10 times/second)
- Activate the relay until the sensor is deactivated
- Call a preset extension and play a pre-recorded audio file (once)

**Note** Calling a preset extension can be set up as a point-to-point call, but currently can't send delayed DTMF tones.

1. Click **Sensor Config** to open the **Sensor Configuration** page (Figure 2-13).

Figure 2-13. Sensor Configuration Page

**CyberData SIP Call Button**

**Sensor Configuration**

**Door Sensor Settings**

Door Sensor Normally Closed:  Yes  No  
Door Open Timeout (in seconds): 0

Flash Button LED:   
Activate Relay:   
Play Audio Remotely:   
Dial Out Extension: 204  
Dial Out ID: id204

**Intrusion Sensor Settings**

Flash Button LED:   
Activate Relay:   
Play Audio Remotely:   
Dial Out Extension: 204  
Dial Out ID: id204

\* You need to reboot for changes to take effect

**Save** **Reboot**

2. On the **Sensor Configuration** page, enter values for the parameters indicated in [Table 2-12](#).

**Table 2-12. Sensor Configuration Parameters**

Web Page Item	Description
<b>Door Sensor Settings</b>	
Door Sensor Normally Closed	Select the inactive state of the door sensors.
Door Open Timeout (in seconds)	Select the number of seconds that you want to pass before the door sensor is activated.
Flash Button LED	Check this box to flash the LED until the sensor is deactivated (roughly 10 times/second).
Activate Relay	Check this box to activate the relay until the sensor is deactivated.
Play Audio Remotely	Check this box to call a preset extension and play a prerecorded audio file (once).
Dial Out Extension	Enter the desired dial-out extension number.
Dial Out ID	Type the desired Extension ID (64 character limit).
<b>Test Door Sensor</b>	Use this button to test the door sensor.
<b>Intrusion Sensor Settings</b>	
Flash Button LED	Check this box to flash the LED until the sensor is deactivated (roughly 10 times/second).
Activate Relay	Check this box to activate the relay until the sensor is deactivated.
Play Audio Remotely	Check this box to call a preset extension and play a prerecorded audio file (once).
Dial Out Extension	Enter the desired dial-out extension number.
Dial Out ID	Type the desired Extension ID (64 character limit).
<b>Test Intrusion Sensor</b>	Use this button to test the Intrusion sensor.
<b>Save</b>	Click the <b>Save</b> button to save your configuration settings. <b>Note:</b> You need to reboot for changes to take effect.
<b>Reboot</b>	Click on the <b>Reboot</b> button to reboot the system.

3. You must click on the **Save** button and then the **Reboot** button for the changes to take effect.

## 2.3.7 Configure the Audio Configuration Parameters

The **Audio Configuration** page is used to add custom audio to the board. User uploaded audio will take precedence over the audio files shipped with the Call Button.




1. Click **Audio Config** to open the **Audio Configuration** page (Figure 2-14).

Figure 2-14. Audio Configuration Page



2. On the **Audio Configuration** page, enter values for the parameters indicated in [Table 2-13](#).

**Table 2-13. Audio Configuration Parameters**

Web Page Item	Description
<b>Audio Files</b>	
Audio Message	Specifies the audio file that will be played repeatedly for the extension number that is configured in the <b>Dial Out Settings</b> on the <b>SIP Configuration Page</b> (24 character limit).
Intrusion Sensor Triggered	Corresponds to the message "Intrusion Sensor Triggered" (24 character limit).
Door Ajar	Corresponds to the message "Door Ajar" (24 character limit).
	The <b>Browse</b> button will allow you to navigate to and select an audio file.
	The <b>Delete</b> button will delete any user uploaded audio and restore the stock audio file.
	The <b>Save</b> button will download a new user audio file to the board once you've selected the file by using the <b>Browse</b> button. The <b>Save</b> button will delete any pre-existing user-uploaded audio files.
	Click on the <b>Reboot</b> button to reboot the system.


### 2.3.7.1 User-created Audio Files

User created audio files should be saved in the following format:


RIFF (little-endian) data, WAVE audio, Microsoft PCM, 16 bit, mono 8000 Hz

You can use the free utility *Audacity* to convert audio files into this format. See [Figure 2-15](#) through [Figure 2-17](#).

**Figure 2-15. Audacity 1**




**Figure 2-16. Audacity 2**



When you export an audio file with Audacity, save the output as:

- **WAV (Microsoft) signed 16 bit PCM.**

**Figure 2-17. WAV (Microsoft) signed 16 bit PCM**



## 2.3.8 Configure the Event Parameters

1. Click the **Event Config** button to open the **Event Configuration** page (Figure 2-18). The **Event Configuration** page specifies a remote server that can be used to receive HTTP POST events when actions take place on the board.

Figure 2-18. Event Configuration Page

**CyberData SIP Call Button**

**Event Configuration**

Enable Event Generation:

Remote Event Server

Remote Event Server IP:

Remote Event Server Port:

Remote Event Server URL:

Events

Enable Button Events:

Enable Call Active Events:

Enable Call Terminated Events:

Enable Relay Activated Events:

Enable Relay Deactivated Events:

Enable Power on Events:

Enable Sensor Events:

Enable Security Events:

Enable 60 second Heartbeat Events:

\* You need to reboot for changes to take effect

Save Test Event Reboot

2. On the **Event Configuration** page, enter values for the parameters indicated in [Table 2-14](#).

**Table 2-14. Event Configuration**

Web Page Item	Description
Enable Event Generation	When selected, Event Generation is enabled.
<b>Remote Event Server</b>	
Remote Event Server IP	Type the Remote Event Server IP address. (64 character limit)
Remote Event Server Port	Type the Remote Event Server port number. (8 character limit)
Remote Event Server URL	Type the Remote Event Server URL. (127 character limit)
<b>Events</b>	
Enable Button Events	When selected, Button Events are enabled.
Enable Call Active Events	When selected, Call Active Events are enabled.
Enable Call Terminated Events	When selected, Call Terminated Events are enabled.
Enable Relay Activated Events	When selected, Relay Activated Events are enabled.
Enable Relay Deactivated Events	When selected, Relay Deactivated Events are enabled.
Enable Power On Events	When selected, Power On Events are enabled.
Enable Sensor Events	When selected, Sensor Events are enabled.
Enable Security Events	When selected, Security Events are enabled.
Enable 60 Second Heartbeat Events	When selected, 60 Second Heartbeat Events are enabled.
<b>Save</b>	Click the <b>Save</b> button to save your configuration settings. <b>Note:</b> You need to reboot for changes to take effect.
<b>Test Event</b>	Click on the <b>Test Event</b> button to test an event.
<b>Reboot</b>	Click on the <b>Reboot</b> button to reboot the system.

3. You must click on the **Save** button and then the **Reboot** button for the changes to take effect.

### 2.3.8.1 Example Packets for Events

The server and port are used to point to the listening server and the 'Remote Event Server URL' is the destination URL (typically the script running on the remote server that's used to parse and process the POST events).

**Note** The XML is URL-encoded before transmission so the following examples are not completely accurate.

Here are example packets for every event:

```
POST xmlhttp_parse_engine HTTP/1.1
Host: 10.0.3.79
User-Agent: CyberData/1.0.0
Content-Length: 197
Content-Type: application/x-www-form-urlencoded

<?xml version="1.0" encoding="ISO-8859-1"?>
<cyberdata NAME='CyberData SIP Device' MAC='0020f70015b6'>
<event>POWERON</event>
</cyberdata>

POST xmlhttp_parse_engine HTTP/1.1
Host: 10.0.3.79
User-Agent: CyberData/1.0.0
Content-Length: 199
Content-Type: application/x-www-form-urlencoded

<?xml version="1.0" encoding="ISO-8859-1"?>
<cyberdata NAME='CyberData SIP Device' MAC='0020f70015b6'>
<event>HEARTBEAT</event>
</cyberdata>

POST xmlhttp_parse_engine HTTP/1.1
Host: 10.0.3.79
User-Agent: CyberData/1.0.0
Content-Length: 196
Content-Type: application/x-www-form-urlencoded

<?xml version="1.0" encoding="ISO-8859-1"?>
<cyberdata NAME='CyberData SIP Device' MAC='0020f70015b6'>
<event>BUTTON</event>
</cyberdata>

POST xmlhttp_parse_engine HTTP/1.1
Host: 10.0.3.79
User-Agent: CyberData/1.0.0
Content-Length: 201
Content-Type: application/x-www-form-urlencoded

<?xml version="1.0" encoding="ISO-8859-1"?>
<cyberdata NAME='CyberData SIP Device' MAC='0020f70015b6'>
<event>CALL_ACTIVE</event>
</cyberdata>
POST xmlhttp_parse_engine HTTP/1.1
```

```
Host: 10.0.3.79
User-Agent: CyberData/1.0.0
Content-Length: 205
Content-Type: application/x-www-form-urlencoded

<?xml version="1.0" encoding="ISO-8859-1"?>
<cyberdata NAME='CyberData SIP Device' MAC='0020f70015b6'>
<event>CALL_TERMINATED</event>
</cyberdata>

POST xmlparse_engine HTTP/1.1
Host: 10.0.3.79
User-Agent: CyberData/1.0.0
Content-Length: 197
Content-Type: application/x-www-form-urlencoded

<?xml version="1.0" encoding="ISO-8859-1"?>
<cyberdata NAME='CyberData SIP Device' MAC='0020f70015b6'>
<event>RINGING</event>
</cyberdata>

POST xmlparse_engine HTTP/1.1
Host: 10.0.3.79
User-Agent: CyberData/1.0.0
Content-Length: 234
Content-Type: application/x-www-form-urlencoded

<?xml version="1.0" encoding="ISO-8859-1"?>
<cyberdata NAME='CyberData SIP Device' MAC='0020f70015b6'>
<event>MULTICAST_START</event>
<index>8</index>
</cyberdata>

POST xmlparse_engine HTTP/1.1
Host: 10.0.3.79
User-Agent: CyberData/1.0.0
Content-Length: 233
Content-Type: application/x-www-form-urlencoded

<?xml version="1.0" encoding="ISO-8859-1"?>
<cyberdata NAME='CyberData SIP Device' MAC='0020f70015b6'>
<event>MULTICAST_STOP</event>
<index>8</index>
</cyberdata>

POST xmlparse_engine HTTP/1.1
Host: 10.0.3.79
User-Agent: CyberData/1.0.0
Content-Length: 234
Content-Type: application/x-www-form-urlencoded
<?xml version="1.0" encoding="ISO-8859-1"?>
<cyberdata NAME='CyberData SIP Device' MAC='0020f70015b6'>
<event>RELAY_ACTIVATED</event>
</cyberdata>
POST xmlparse_engine HTTP/1.1
```

```
Host: 10.0.3.79
User-Agent: CyberData/1.0.0
Content-Length: 234
Content-Type: application/x-www-form-urlencoded
<?xml version="1.0" encoding="ISO-8859-1"?>
<cyberdata NAME='CyberData SIP Device' MAC='0020f70015b6'>
<event>RELAY_DEACTIVATED</event>
</cyberdata>

POST xmlparse_engine HTTP/1.1
Host: 10.0.3.79
User-Agent: CyberData/1.0.0
Content-Length: 234
Content-Type: application/x-www-form-urlencoded
<?xml version="1.0" encoding="ISO-8859-1"?>
<cyberdata NAME='CyberData SIP Device' MAC='0020f70015b6'>
<event>NIGHTRINGING</event>
</cyberdata>
```

## 2.3.9 Configure the Autoprovisioning Parameters

Autoprovisioning can be used to configure your device automatically on boot, after a periodic delay, after sitting idle for a period of time, or at a specified time.

The autoprovisioning file contains the board configuration in xml format. Autoprovisioned values in this file will override values stored in on-board memory.

The autoprovisioning file can be hosted with a tftp or a web server and by default is named according to the MAC address of the device (for example: 0020f7350058.config). The autoprovisioning filename can also be specified.

The device does not have a real time clock but can sync with a network time server on boot.

1. Click the **Autoprovisioning** button to open the **Autoprovisioning Configuration** page. See [Figure 2-19](#).

**Figure 2-19. Autoprovisioning Configuration Page**

**CyberData SIP Call Button**

**Autoprovisioning**

Autoprovisioning

Enable Autoprovisioning:

Get Autoprovisioning from DHCP:

Download Protocol:  HTTP  TFTP

Autoprovisioning Server (IP Address): 10.0.0.254

Autoprovisioning Filename:

Autoprovisioning autoupdate (in minutes): 0

Autoprovision at time (HHMMSS):

Autoprovision when idle (in minutes > 10): 0

Get Autoprovisioning Template

Clock

NTP Server: north-america.pool.ntp.org

Posix Timezone String (see manual): PST8PDT,M3.2.0/2:00:00,M11.1.0/2:00:01

Set Time with external NTP server on boot:

Periodically update with time server:

Time update period (in hours): 24

Set time from NTP Server

Current Time

Current Time in 24 hour format (HHMMSS): 140057

Set Time

\* Autoprovisioning file name: 0020f70232a3.config

\* You need to reboot for changes to take effect

Save Reboot

2. On the **Autoprovisioning Configuration** page, you may enter values for the parameters indicated in [Table 2-15](#)

**Table 2-15. Autoprovisioning Configuration Parameters**

Web Page Item	Description
<b>Autoprovisioning</b>	
Enable Autoprovisioning	See <a href="#">Section 2.3.9.1, "Autoprovisioning"</a> .
Get Autoprovisioning from DHCP	See <a href="#">Section 2.3.9.1, "Autoprovisioning"</a> .
Download Protocol	Allows you to select whether the autoprovisioning file is acquired via <b>TFTP</b> or <b>HTTP</b> .
Autoprovisioning Server (IP Address)	See <a href="#">Section 2.3.9.1, "Autoprovisioning"</a> (15 character limit).
Autoprovisioning Filename	Type the desired name for the autoprovisioning file.
Autoprovisioning autoupdate (in minutes)	Type the desired time (in minutes) that you want the Autoprovisioning feature to update (6 character limit).
Autoprovision at time (HHMMSS)	Type the desired time of day that you want the Autoprovisioning feature to update (must be 6 characters).
Autoprovision when idle (in minutes > 10)	Type the desired time (in minutes greater than 10) that you want the Autoprovisioning feature to update after a certain amount of idle time (6 character limit).
<b>Get Autoprovisioning Template</b>	Press the <b>Get Autoprovisioning Template</b> button to create an autoprovisioning file for this unit. See <a href="#">Section 2.3.9.2, "Get Autoprovisioning Template Button"</a>
<b>Clock</b>	
NTP Server	Allows you to select the NTP server (64 character limit).
Posix Timezone String	See <a href="#">Section 2.3.9.3, "Time Zone Strings"</a> (43 character limit).
Set Time with External NTP Server on boot	When selected, the time is set with an external NTP server when the device restarts.
Periodically update with time server	When selected, the time is periodically updated with a time server.
Time update period (in hours)	Allows you to select the time updated period (in hours) (4 character limit).
<b>Set time from NTP Server</b>	Allows you to set the time from the NTP server.
<b>Current Time</b>	
Current Time (UTC) in 24 hour format (HHMMSS)	Allows you to input the current time in the 24 hour format. (6 character limit)
<b>Set Time</b>	Click on this button to set the clock after entering the current time.
<b>Save</b>	Click on the <b>Save</b> button to save your configuration settings.
	<b>Note:</b> You need to reboot for changes to take effect.
<b>Reboot</b>	Click on the <b>Reboot</b> button to reboot the system.

3. You must click on the **Save** button and then the **Reboot** button for the changes to take effect.

### 2.3.9.1 Autoprovisioning

Autoprovisioning File It is not necessary to set every option found in the autoprovisioning template. As long as the XML is valid, the file can contain any subset. Options not autoprovisioned will default to the values stored in the on board memory. For example if you only wanted to modify the device name, the following would be a valid autoprovisioning file:

```
<?xml version="1.0" encoding="utf-8" ?>
<specific>
  <MiscSettings>
    <DeviceName>auto Call Button</DeviceName>
  </MiscSettings>
</specific>
```

Get Autoprovisioning from DHCP When this option is checked, the device will automatically fetch its autoprovisioning server address from the DHCP server. The device will use the address specified in **OPTION 150** (TFTP-server-name) or **OPTION 66**. If both options are set, the device will use **OPTION 150**.

Refer to the documentation of your DHCP server for setting up **OPTION 150**.

To set up a Linux DHCPD server to serve autoprovisioning information (in this case using both option 66 and 150), here's an example dhcpcd.conf:

```
# dhcpcd.conf
#
# Configuration file for ISC dhcpcd (see 'man dhcpcd.conf')
#
ddns-update-style ad-hoc;

option option-150 code 150 = ip-address;

subnet 10.0.0.0 netmask 255.0.0.0 {
    max-lease-time 120;
    default-lease-time 120;

    option routers                  10.0.0.1;
    option subnet-mask               255.0.0.0;

    option domain-name              "voiplab";
    option domain-name-servers      10.0.0.1;

    option time-offset                -8;      # Pacific Standard Time
    option tftp-server-name          "10.0.0.254";
    option option-150                  10.0.0.254;

    range 10.10.0.1 10.10.2.1;}
```

Autoprovisioning Server (IP Address)	Instead of using DHCP to provide the autoprovisioning tftp server address, you can specify an address manually.
Autoprovisioning Autoupdate	When the device is set to autoprovision either after a period of time, or when idle, or at a time of day, the device will do the following: <ul style="list-style-type: none"><li>• Re-download the autoprovisioning file.</li><li>• Compare this new file to the one downloaded on boot, and if it finds differences, force a system reset.</li><li>• After rebooting, the board will configure itself according to this new file.</li></ul>
Autoprovisioned Firmware Upgrades	An Autoprovisioned firmware upgrade only happens after a reboot, will take roughly three minutes, and the web page will be unresponsive during this time. <p>The '<b>FirmwareVersion</b>' value in the xml file <i>must</i> match the version stored in the '<b>FirmwareFile</b>'.</p> <pre>&lt;FirmwareVersion&gt;v10.0.1&lt;/FirmwareVersion&gt; &lt;FirmwareFile&gt;1001-callbutton-uImage&lt;/FirmwareFile&gt;</pre> <p>If these values are mismatched, the board can get stuck in a loop where it goes through the following sequence of actions:</p> <ol style="list-style-type: none"><li>1. The board downloads and writes a new firmware file.</li><li>2. After the next reboot, the board recognizes that the firmware version does not match.</li><li>3. The board downloads and writes the firmware file again.</li></ol> <p>CyberData has timed a firmware upgrade at 140 seconds. Therefore, if you suspect the board is stuck in a loop, either remove or comment out the <b>FirmwareVersion</b> line in the XML file and let the board boot as it normally does.</p>
Autoprovisioned Audio Files	Audio files are stored in non-volatile memory and an autoprovisioned audio file will only have to be downloaded once for each device. Loading many audio files to the device from the web page could cause it to appear unresponsive. If this happens, wait until the transfer is complete and then refresh the page. <p>The device uses the file name to determine when to download a new audio file. This means that if you used autoprovisioning to upload a file and then changed the contents of this file at the TFTP server, the device will not recognize that the file has changed (because the file name is the same). Since audio files are stored in non-volatile memory, if autoprovisioning is disabled after they have been loaded to the board, the audio file settings will not change. You can force a change to the audio files on the board by clicking <b>Restore Default</b> on the <b>Audio Configuration</b> page or by changing the autoprovisioning file with “<b>default</b>” set as the file name.</p>


### 2.3.9.2 Get Autoprovisioning Template Button

The **Get Autoprovisioning Template** button allows the user to generate, download, edit, and then store an autoprovisioning template on the server that serves the autoprovisioning files for devices.

To generate an autoprovisioning template directly from the device, complete the following steps:

1. On the **Autoprovisioning** page, click on the **Get Autoprovisioning Template** button.
2. You will see a window prompting you to save a configuration file (.config) to a location on your computer (Figure 2-20). The configuration file is the basis for the default configuration settings for your unit.
3. Choose a location to save the configuration file and click on **OK**. See Figure 2-20.

**Figure 2-20. Configuration File**



4. At this point, you can open and edit the autoprovisioning template to change the configuration settings in the template for the unit.
5. You can then upload the autoprovisioning file to a TFTP or HTTP server where the file can be loaded onto other devices.

### 2.3.9.3 Time Zone Strings

The posix time zone string tells the internal date and time utilities how to handle daylight savings time for different time zones. [Table 2-16](#) shows some common strings.

**Table 2-16. Common Time Zone Strings**

Time Zone	Time Zone String
US Pacific time	PST8PDT,M3.2.0/2:00:00,M11.1.0/2:00:00
US Mountain time	MST7MDT,M3.2.0/2:00:00,M11.1.0/2:00:00
US Eastern Time	EST5EDT,M3.2.0/2:00:00,M11.1.0/2:00:00
Phoenix Arizona <sup>a</sup>	MST7
US Central Time	CST6DST,M3.2.0/2:00:00,M11.1.0/2:00:00

a. Phoenix, Arizona does not use daylight savings time.

[Table 2-17](#) shows a breakdown of the parts that constitute the following time zone string:

- **CST6DST,M3.2.0/2:00:00,M11.1.0/2:00:00**

**Table 2-17. Time Zone String Parts**

Time Zone String Part	Meaning
CST6CDT	The time zone offset from GMT and three character identifiers for the time zone.
CST	Central Standard Time
6	The (hour) offset from GMT/UTC
CDT	Central Daylight Time
M3.2.0/2:00:00	The date and time when daylight savings begins.
M3	The third month (March)
.2	The 2nd occurrence of the day (next item) in the month
.0	Sunday
/2:00:00	Time of day to change
M11.1.0/2:00:00	The date and time when daylight savings ends.
M11	The eleventh month (November)
.1	The 1st occurrence of the day (next item) in the month
.0	Sunday
/2:00:00	Time of day to change


Time Zone String Examples

**Table 2-18** has some more examples of time zone strings.**Table 2-18. Time Zone String Examples**

Time Zone	Time Zone String
Tokyo <sup>a</sup>	IST-9
Berlin <sup>b</sup>	CET-1MET,M3.5.0/1:00,M10.5.0/1:00

a.Tokyo does not use daylight savings time.  
 b.For Berlin, daylight savings time starts on the last Sunday in March at 01:00 UTC, and ends on the last Sunday in October at 01:00 UTC, and is one hour ahead of UTC.

Time Zone Identifier A user-definable three or four character time zone identifier (such as PST, EDT, IST, MUT, etc) is needed at the beginning of the posix time zone string to properly set the time. However, the specific letters or numbers used for the time zone identifier are not important and can be any three or four letter or number combination that is chosen by the user. However, the time zone identifier cannot be blank.

**Figure 2-21. Three or Four Character Time Zone Identifier**

You can also use the following URL when a certain time zone applies daylight savings time:

<http://www.timeanddate.com/time/dst/2011.html>

World GMT Table


**Table 2-19** has information about the GMT time in various time zones.**Table 2-19. World GMT Table**

Time Zone	City or Area Zone Crosses
GMT-12	Eniwetok
GMT-11	Samoa
GMT-10	Hawaii
GMT-9	Alaska
GMT-8	PST, Pacific US
GMT-7	MST, Mountain US
GMT-6	CST, Central US
GMT-5	EST, Eastern US
GMT-4	Atlantic, Canada
GMT-3	Brazilia, Buenos Aries
GMT-2	Mid-Atlantic
GMT-1	Cape Verdes
GMT	Greenwich Mean Time, Dublin

**Table 2-19. World GMT Table (continued)**

<b>Time Zone</b>	<b>City or Area Zone Crosses</b>
GMT+1	Berlin, Rome
GMT+2	Israel, Cairo
GMT+3	Moscow, Kuwait
GMT+4	Abu Dhabi, Muscat
GMT+5	Islamabad, Karachi
GMT+6	Almaty, Dhaka
GMT+7	Bangkok, Jakarta
GMT+8	Hong Kong, Beijing
GMT+9	Tokyo, Osaka
GMT+10	Sydney, Melbourne, Guam
GMT+11	Magadan, Solomon Is.
GMT+12	Fiji, Wellington, Auckland


## 2.4 Upgrade the Firmware and Reboot the Intercom



To upload the firmware from your computer:

1. Retrieve the latest Intercom firmware file from the SIP Call Button **Downloads** page at:  
<http://www.cyberdata.net/products/voip/digitalanalog/callbutton/downloads.html>
2. Unzip the firmware version file. This file may contain the following:
  - Firmware file
  - Release notes
3. Log in to the Intercom home page as instructed in [Section 2.3.2, "Log in to the Configuration Home Page"](#).
4. Click the **Update Firmware** button to open the **Upgrade Firmware** page. See [Figure 2-22](#).

**Figure 2-22. Upgrade Firmware Page**



5. Select **Browse**, and then navigate to the location of the Intercom firmware file.

6. Click **Submit**.

**Note** This starts the upgrade process. Once the Intercom has uploaded the file, the **Uploading Firmware** countdown page appears, indicating that the firmware is being written to flash. The Intercom will automatically reboot when the upload is complete. When the countdown finishes, the **Upgrade Firmware** page will refresh. The uploaded firmware filename should be displayed in the system configuration (indicating successful upload and reboot).

Table 2-20 shows the web page items on the **Upgrade Firmware** page.

**Table 2-20. Firmware Upgrade Parameters**


Web Page Item	Description
<b>File Upload</b>	
Firmware Version	Shows the current firmware version.
<input type="button" value="Browse..."/>	Use the <b>Browse</b> button to navigate to the location of the Call Button firmware file that you want to upload.
<input type="button" value="Submit"/>	Click on the <b>Submit</b> button to automatically upload the selected firmware and reboot the system.

## 2.4.1 Reboot the Intercom

To reboot a Intercom:

1. Log in to the **Home Page** as instructed in [Section 2.3.2, "Log in to the Configuration Home Page".](#)
2. Click the **Reboot** button ([Figure 2-23](#)). A normal restart will occur.

**Figure 2-23. Reboot Button**



## 2.5 Command Interface

Some functions on the device can be activated using simple POST commands to the web interface. The examples in [Table 2-21](#) use the free unix utility, **wget commands**. However, any program that can send HTTP POST commands to the device should work.

### 2.5.1 Command Interface Post Commands

**Note** These commands require an authenticated session (a valid username and password to work).

**Table 2-21. Command Interface Post Commands**

Device Action	HTTP Post Command <sup>a</sup>
Trigger relay (for configured delay)	wget --user admin --password admin --auth-no-challenge --quiet -O /dev/null "http://10.0.3.71/cgi-bin/command.cgi" --post-data "test_relay=yes"
Place call to extension (example: extension 130)	wget --user admin --password admin --auth-no-challenge --quiet -O /dev/null "http://10.0.3.71/cgi-bin/command.cgi" --post-data "call=130"
Terminate active call	wget --user admin --password admin --auth-no-challenge --quiet -O /dev/null "http://10.0.3.71/cgi-bin/command.cgi" --post-data "terminate=yes"
Force reboot	wget --user admin --password admin --auth-no-challenge --quiet -O /dev/null "http://10.0.3.71/cgi-bin/command.cgi" --post-data "reboot=yes"
Trigger the Door Sensor Test (Sensor Config page)	wget --user admin --password admin --auth-no-challenge --quiet -O /dev/null "http://10.0.3.71/cgi-bin/sensorconfig.cgi" --post-data "doortest=yes"
Trigger the Intrusion Sensor Test (Sensor Config page)	wget --user admin --password admin --auth-no-challenge --quiet -O /dev/null "http://10.0.3.71/cgi-bin/sensorconfig.cgi" --post-data "intrusiontest=yes"

a. Type and enter all of each http POST command on one line.

# Appendix A: Mounting the SIP Call Button

## A.1 Important Safety Instructions

 GENERAL ALERT	<b>Warning</b> <i>Electrical Hazard:</i> The device enclosure is not rated for any AC voltages.
 GENERAL ALERT	<b>Warning</b> <i>Electrical Hazard:</i> This product should be installed by a licensed electrician according to all local electrical and building codes.
 GENERAL ALERT	<b>Warning</b> <i>Electrical Hazard:</i> To prevent injury, this apparatus must be securely attached to the floor/wall in accordance with the installation instructions.
 GENERAL ALERT	<b>Warning</b> The PoE connector is intended for intra-building connections only and does not route to the outside plant.

---

## A.2 Mount the SIP Call Button


Before you mount the SIP Call Button, make sure that you have received all the parts for each SIP Call Button. Refer to [Table A-1](#).

**Table A-1. Wall Mounting Components (Part of the Accessory Kit)**

Quantity	Part Name	Illustration
4	#6 x 1.25 inches Sheet Metal Screw	
4	#6 Ribbed Plastic Anchor	

---

**Table A-2. Gang Box Mounting Components**

Quantity	Part Name	Illustration
4	#6-32 x 0.625-inch Flat-Head Machine Screw.	

---

After the SIP Call Button is assembled, plug the Ethernet cable into the SIP Call Button Assembly (see [Figure A-1](#)).

Section 2.2.4, "Network Connectivity and Data Rate" explains how the **Link** and **Status** LEDs work.

**Figure A-1. Network Connector Prior to Installation**




Figure A-3 shows the wall mounting options for the SIP Call Button.

**Note** Be sure to connect the SIP Call Button to the Earth Ground.

**Figure A-2. Wall Mounting Options**




Figure A-3 shows the gang box mounting options for the SIP Call Button.

**Note** Be sure to connect the SIP Call Button to the Earth Ground.

**Figure A-3. Mounting Options**





Figure A-4 shows the maximum recommended wall cutout dimensions for mounting the SIP Call Button.

**Figure A-4. Maximum Recommended Wall Cutout Dimensions**



# Appendix B: Troubleshooting/Technical Support

---

## B.1 Frequently Asked Questions (FAQ)

A list of frequently asked questions (FAQs) are available on the SIP Call Button product page at:

<http://www.cyberdata.net/products/voip/digitalanalog/callbutton/faqs.html>

Select the support page for your product to see a list of frequently asked questions for the CyberData product:

---

## B.2 Documentation

The documentation for this product is released in an English language version only. You can download PDF copies of CyberData product documentation from the SIP Call Button product page at:

<http://www.cyberdata.net/products/voip/digitalanalog/callbutton/docs.html>

---

## B.3 Contact Information

Contact	CyberData Corporation 3 Justin Court Monterey, CA 93940 USA <a href="http://www.CyberData.net">www.CyberData.net</a> Phone: 800-CYBERDATA (800-292-3732) Fax: 831-373-4193
Sales	Sales 831-373-2601 Extension 334
Technical Support	The fastest way to get technical support for your VoIP product is to submit a VoIP Technical Support form at the following website:  <a href="http://www.cyberdata.net/support/contactsupportvoip.php">http://www.cyberdata.net/support/contactsupportvoip.php</a>  Phone: (831) 373-2601, Ext. 333 Email: support@cyberdata.net
Returned Materials Authorization	To return the product, contact the Returned Materials Authorization (RMA) department:  Phone: 831-373-2601, Extension 136 Email: RMA@CyberData.net  When returning a product to CyberData, an approved CyberData RMA number must be printed on the outside of the original shipping package. No product will be accepted for return without an approved RMA number. Send the product, in its original package, to the following address:  CyberData Corporation 3 Justin Court Monterey, CA 93940 Attention: RMA "your RMA number"
RMA Status Form	If you need to inquire about the repair status of your product(s), please use the CyberData RMA Status form at the following web address:  <a href="http://www.cyberdata.net/support/rmestatus.html">http://www.cyberdata.net/support/rmestatus.html</a>

---

## B.4 Warranty

CyberData warrants its product against defects in material or workmanship for a period of two years from the date of purchase. Should the product fail Within Warranty, CyberData will repair or replace the product free of charge. This warranty includes all parts and labor.

Should the product fail Out of the Warranty period, a flat rate repair charge of one half of the purchase price of the product will be assessed. Repairs that are Within Warranty period but are damaged by improper installation, modification, or abuse are deemed Out of Warranty and will be charged at the Out of Warranty rate. A device is deemed Out of Warranty when its purchase date is longer than two years or when the device has been damaged due to human error during installation, modification, or abuse. A replacement unit will be offered at full cost if the device cannot be repaired.

**End of Life Devices** are included under this policy. End of Life devices are devices that are no longer produced or sold. Technical support is still available for these devices. However, no firmware revisions or updates will be provided. If an End of Life device cannot be repaired, the replacement offered may be the current version of the device.

Products shipped to CyberData, both within and out of warranty, are shipped at the expense of the customer. CyberData will pay return shipping charges for repaired products.

CyberData shall not under any circumstances be liable to any person for any special, incidental, indirect or consequential damages, including without limitation, damages resulting from use or malfunction of the products, loss of profits or revenues or costs of replacement goods, even if CyberData is informed in advance of the possibility of such damages.

---

### B.4.1 Warranty & RMA Returns within the United States

If service is required, you must contact CyberData Technical Support prior to returning any products to CyberData. Our Technical Support staff will determine if your product should be returned to us for further inspection. If Technical Support determines that your product needs to be returned to CyberData, an RMA number will be issued to you at this point.

Your issued RMA number must be printed on the outside of the shipping box. No product will be accepted for return without an approved RMA number. The product in its original package should be sent to the following address:

CyberData Corporation

3 Justin Court.

Monterey, CA 93940

Attn: RMA "xxxxxx"

---

### B.4.2 Warranty & RMA Returns Outside of the United States

If you purchased your equipment through an authorized international distributor or reseller, please contact them directly for product repairs.

---

### B.4.3 Spare in the Air Policy

CyberData now offers a *Spare in the Air* no wait policy for warranty returns within the United States and Canada. More information about the *Spare in the Air* policy is available at the following web address:

<http://www.cyberdata.net/support/warranty/spareintheair.html>

---

### B.4.4 Return and Restocking Policy

For our authorized distributors and resellers, please refer to your CyberData Service Agreement for information on our return guidelines and procedures.

For End Users, please contact the company that you purchased your equipment from for their return policy.

---

### B.4.5 Warranty and RMA Returns Page

The most recent warranty and RMA information is available at the CyberData Warranty and RMA Returns Page at the following web address:

<http://www.cyberdata.net/support/warranty/index.html>

# Index

## Numerics

100 Mbps indicator light 12

## A

AC voltages 2  
 AC voltages, intercom enclosure is not rated 8, 1  
 act light 12  
 activate relay (door sensor) 31  
 activate relay (intrusion sensor) 31  
 address, configuration login 17  
 announcing a speaker's IP address 13  
 audio configuration 32  
 audio configuration page 32  
 audio encodings 3  
 audio files, user-created 34  
 Autoprovision at time (HHMMSS) 42  
 autoprovision at time (HHMMSS) 42  
 autoprovision when idle (in minutes > 10) 42  
 autoprovisioning 42, 43  
     autoprovisioned audio files 44  
     autoprovisioned firmware upgrades 44  
     autoprovisioning autoupdate 44  
     autoprovisioning from DHCP 43  
     autoprovisioning server (IP address) 44  
         get autoprovisioning template button 42  
 autoprovisioning autoupdate (in minutes) 42  
 autoprovisioning configuration 41, 42  
 autoprovisioning filename 42  
 autoprovisioning server (IP Address) 42  
 auxiliary relay 8  
 auxiliary relay wiring diagram 9

## B

backup SIP server 1 25  
 backup SIP server 2 25  
 backup SIP servers, SIP server  
     backups 25

## C

call button 12  
     LED 14  
 call button configuration  
     default IP settings 15  
 call button LED 14

changing  
     the web access password 20  
 Cisco SRST 25  
 command interface 52  
 commands 52  
 configurable parameters 19, 21, 23, 25, 50  
 configuration 19  
     audio 32  
     default IP settings 15  
     door sensor 29  
     intrusion sensor 29  
     network 22  
     SIP 24  
         using Web interface 15  
 configuration home page 17  
 configuration page  
     configurable parameters 19, 21, 23, 25, 50  
 contact information 8  
 contact information for CyberData 8  
 CyberData contact information 8

## D

default  
     device settings 11  
     gateway 15  
     IP address 15  
     subnet mask 15  
     username and password 15  
     web login username and password 17  
 default device settings 13  
 default gateway 15, 23  
 default IP settings 15  
 default login address 17  
 device configuration 20  
     device configuration parameters 42  
     the device configuration page 41  
 device configuration page 20  
 device configuration parameters 21  
 device configuration password  
     changing for web configuration access 20  
 DHCP Client 3  
 DHCP IP addressing 23  
 dial out extension (door sensor) 31  
 dial out extension (intrusion sensor) 31  
 dial out extension strings 26  
 dial-out extension strings 28  
 dimensions 4, 5  
 discovery utility program 17  
 DNS server 23  
 door sensor 29, 31, 33  
     activate relay 31

dial out extension 31  
 door open timeout 31  
 door sensor normally closed 31  
 flash button LED 31  
 download protocol, HTTP or TFTP 42  
 DTMF tones 26, 28  
 DTMF tones (using rfc2833) 26  
 dual speeds 12

## E

earth ground 4, 5  
 ethernet cable 3  
 expiration time for SIP server lease 25  
 export configuration button 19  
 export settings 19

## F

factory default settings 13  
 how to set 13  
 firmware  
 where to get the latest firmware 49  
 flash button LED (door sensor) 31  
 flash button LED (intrusion sensor) 31

## G

gang box mounting 4, 5  
 get autoprovisioning from DHCP 42  
 get autoprovisioning template 42  
 get autoprovisioning template button 42  
 GMT table 47  
 GMT time 47  
 green link light 12

## H

home page 17  
 http POST command 52  
 http web-based configuration 3

## I

identifier names (PST, EDT, IST, MUT) 47  
 identifying your product 1  
 illustration of device mounting process 2

import configuration button 19  
 import settings 19  
 import/export settings 19  
 importing and exporting the device's configuration 19  
 installation, typical device system 2  
 intrusion sensor 29, 31  
 activate relay 31  
 dial out extension 31  
 flash button LED 31  
 IP address 15, 23  
 IP addressing 23  
 default  
 IP addressing setting 15

## L

lease, SIP server expiration time 25  
 link LED 3  
 link light 12  
 local SIP port 25  
 log in address 17

## M

mounting the device 2

## N

navigation (web page) 16  
 navigation table 16  
 network configuration 22  
 network rate 4  
 Network Setup 22  
 Nightringer 45, 49  
 NTP server 42

## O

orange link light 12

## P

packet time 3  
 part number 4  
 parts list 6  
 password  
 for SIP server login 25

login 17  
 restoring the default 15  
 play audio remotely 31  
 point-to-point configuration 27  
 port  
     local SIP 25  
     remote SIP 25  
 posix timezone string  
     timezone string 42  
 POST command 52  
 power requirement 4  
 product  
     configuring 15  
     mounting 2  
     parts list 6  
 product features 3  
 product overview  
     product features 3  
     product specifications 4  
     supported protocols 3  
     supported SIP servers 4  
     typical system installation 2  
 product specifications 4  
 protocols supported 3

## R

reboot 50, 51  
 remote SIP port 25  
 Reset Test Function Management (RTFM) switch 13  
 resetting the IP address to the default 1, 7  
 restoring factory default settings 13, 11  
 restoring the factory default settings 13  
 return and restocking policy 10  
 RMA returned materials authorization 8  
 RMA status 8  
 report discovery setting, disabling 26  
 RTFM switch 13  
 RTP/AVP 3

## S

sales 8  
 sensor setup page 30  
 sensor setup parameters 29  
 sensors 31  
 server address, SIP 25  
 service 8  
 set the time from the NTP server 42  
 set time with external NTP server on boot 42  
 setting up the device 7  
 settings, default 13

SIP  
     enable SIP operation 25  
     local SIP port 25  
     user ID 25  
 SIP (session initiation protocol) 3  
 SIP configuration 24  
     SIP Server 25  
 SIP configuration parameters  
     outbound proxy 25  
     registration and expiration, SIP server lease 25  
     user ID, SIP 25  
 SIP registration 25  
 SIP remote SIP port 25  
 SIP server 25  
     password for login 25  
     SIP servers supported 4  
     user ID for login 25  
 SIP settings 26  
 Spare in the Air Policy 10  
 SRST 25  
 static IP addressing 23  
 status LED 3  
 subnet mask 15, 23  
 supported protocols 3

## T

tech support 8  
 technical support, contact information 8  
 time zone string examples 47

## U

user ID  
     for SIP server login 25  
 username  
     changing for web configuration access 20  
     default for web configuration access 17  
     restoring the default 15

## V

VLAN ID 23  
 VLAN Priority 23  
 VLAN tagging support 23  
 VLAN tags 23

## W

warranty 9  
warranty & RMA returns outside of the United States 9  
warranty & RMA returns within the United States 9  
warranty and RMA returns page 10  
warranty policy at CyberData 9  
web access password 15  
web access username 15  
web configuration log in address 17  
web page  
navigation 16  
web page navigation 16  
web-based configuration 15  
weight 4  
wget, free unix utility 52

## Y

yellow act light 12  
yellow link light 12