

OPTIVIEW™ CONTROL CENTER CENTRIFUGAL LIQUID CHILLERS

OPERATION MANUAL

Supersedes: 160.54-O1 (419)

Form 160.54-O1 (619)

MODEL YK (THROUGH STYLE G) R-134a COOLING ONLY

WITH OPTIVIEW CONTROL CENTER FOR ELECTROMECHANICAL STARTER, SOLID STATE STARTER, AND VARIABLE SPEED DRIVE



IMPORTANT! READ BEFORE PROCEEDING! GENERAL SAFETY GUIDELINES

This equipment is a relatively complicated apparatus. During installation, operation maintenance or service, individuals may be exposed to certain components or conditions including, but not limited to: refrigerants, materials under pressure, rotating components, and both high and low voltage. Each of these items has the potential, if misused or handled improperly, to cause bodily injury or death. It is the obligation and responsibility of operating/service personnel to identify and recognize these inherent hazards, protect themselves, and proceed safely in completing their tasks. Failure to comply with any of these requirements could result in serious damage to the equipment and the property in which it is situated, as well as severe personal injury or death to themselves and people at the site.

This document is intended for use by owner-authorized rigging, installation, and operating/service personnel. It is expected that these individuals possess independent training that will enable them to perform their assigned tasks properly and safely. It is essential that, prior to performing any task on this equipment, this individual shall have read and understood the on-product labels, this document and any referenced materials. This individual shall also be familiar with and comply with all applicable industry and governmental standards and regulations pertaining to the task in question.

SAFETY SYMBOLS

The following symbols are used in this document to alert the reader to specific situations:



Indicates a possible hazardous situation which will result in death or serious injury if proper care is not taken.



Identifies a hazard which could lead to damage to the machine, damage to other equipment and/or environmental pollution if proper care is not taken or instructions and are not followed.



Indicates a potentially hazardous situation which will result in possible injuries or damage to equipment if proper care is not taken.



Highlights additional information useful to the technician in completing the work being performed properly.



External wiring, unless specified as an optional connection in the manufacturer's product line, is not to be connected inside the control cabinet. Devices such as relays, switches, transducers and controls and any external wiring must not be installed inside the micro panel. All wiring must be in accordance with Johnson Controls' published specifications and must be performed only by a qualified electrician. Johnson Controls will NOT be responsible for damage/problems resulting from improper connections to the controls or application of improper control signals. Failure to follow this warning will void the manufacturer's warranty and cause serious damage to property or personal injury.

CHANGEABILITY OF THIS DOCUMENT

In complying with Johnson Controls' policy for continuous product improvement, the information contained in this document is subject to change without notice. Johnson Controls makes no commitment to update or provide current information automatically to the manual or product owner. Updated manuals, if applicable, can be obtained by contacting the nearest Johnson Controls Service office or accessing the Johnson Controls QuickLIT website at http://cgproducts. johnsoncontrols.com.

It is the responsibility of rigging, lifting, and operating/ service personnel to verify the applicability of these documents to the equipment. If there is any question regarding the applicability of these documents, rigging, lifting, and operating/service personnel should verify whether the equipment has been modified and if current literature is available from the owner of the equipment prior to performing any work on the chiller.

CHANGE BARS

Revisions made to this document are indicated with a line along the left or right hand column in the area the revision was made. These revisions are to technical information and any other changes in spelling, grammar or formatting are not included.

MANUAL DESCRIPTION	FORM NUMBER
Installation – Unit	160.54-N1
Wiring Diagram – Unit Style E with Electromechanical Starter	160.54-PW1
Wiring Diagram – Unit Style E with Mod A Solid State Starter	160.54-PW2
Wiring Diagram – Unit Style E with Mod B Solid State Starter	160.54-PW2.1
Wiring Diagram – Unit Style E with Variable Speed Drive	160.54-PW3
Wiring Diagram – Unit Style E (P Compressors) with Electromechanical Starter	160.54-PW8
Wiring Diagram – Unit Style E (P Compressors) with Mod B Solid State Starter	160.54-PW9
Wiring Diagram – Unit Style E (P Compressors) with Variable Speed Drive	160.54-PW10
OptiView™ Control Center Replacement Parts	160.54-RP1
Solid State Starter (Mod B) – Operation and Maintenance	160.00-O2
Solid State Starter (Mod A) – Operation and Maintenance	160.46-OM3.1

ASSOCIATED LITERATURE



TABLE OF CONTENTS

	System Operation Description	9
	Capacity Control	0 10
		10
SEC ⁻	TION 2 - OPTIVIEW CONTROL CENTER INTRODUCTION	13
	OptiView Control Center	15
	Interface Conventions Overview	16
	Display Only	16
	Programmable	16
	Navigation	17
	Analog Input Ranges	19
	Home Screen	20
	System Screen	23
	Evaporator Screen	25
	Condenser Screen	28
	Heat Recovery Screen (Software Version C.OPT.01.21.307)	31
	Head Pressure Control Screen (Software Version C.OPT.01.21.307)	35
	Heat Pump Screen (Software Version C.OPT.01.23.307 and Later).	37
	Refrigerant Level Control Screen (Flash Memory Card Versions C.MLM.01.06.XXX and Earlier)	40
	Refrigerant Level Control Screen (Software Version C.MLM.01.07.XXX to C.MLM.01.10D.XXX or C.OPT.01.10D (and Earlier))	42
	Refrigerant Level Control Setpoints Screen (Software Version C.MLM.01.07.XXX to C.MLM.01.10D.XXX o C.OPT.01.10D (and Farlier))	r 44
	Refrigerant Level Control Screen (Software Versions C.MLM.01.14.XXX and Later or C OPT 01 14 306 and Later)	46
	Compressor Screen (All P Compressors and Style F and Later Chillers with G. O. or H5-8 Compressors	40 :) 48
	Compressor Screen (Air Compressors and Style F and Eater Chillers with G H or I Compressors and) - 0
	Style G Chillers with K Compressors)	51
	Proximity Probe Calibration Screen (Style F and Earlier Chillers with G. H. or J. Compressors and	
	Style F and Later Chillers with G, H, or J Compressors)	54
	Hot Gas Bypass Screen	56
	Surge Protection Screen	58
	Variable Geometry Diffuser Screen	62
	Variable Geometry Diffuser Setpoints Screen	64
	Pre-Rotation Vanes Calibration Screen	67
	VSD Tuning Screen	69
	Oil Sump Screen	
	Electromechanical Starter Screen	74
	Mod A Solid State Starter Screen	76
	Mod B Solid State Starter Screen	78
	Medium Voltage Solid State Starter Screen	80
	Variable Speed Drive Screen	82
	Medium Voltage Variable Speed Drive Screen (Software Version C OPT 01 16 XXX and Later)	02
	Variable Speed Drive (VSD) Details Screen	
	Variable Speed Drive (VSD) Details Screen	
	Adaptive Capacity Control Details Screen (Software Version C OPT 01 18 307 and Farlier) (VSD and MV/VSD)	
	Adaptive Capacity Control Details Screen YORK Protocol Configuration (Software Version	
	C.OPT.01.19.307 and Later)	93
	Adaptive Capacity Control Details Screen Modbus Protocol Configuration (Software Version	
	C.OPT.01.19.307 and Later)	95
	,	,

TABLE OF CONTENTS (CONT'D)

Surge Map Screen - Table View (Software Version C.OPT.01.19.307 and Later).	98
Surge Map Screen - List View (Software Version C OPT 01 19 307 and Later)	100
Harmonic Filter Details Screen (Optional Equipment)	102
Motor Lubrication Screen 1	
Motor Lubrication Screen 2	
Motor Details Screen (Software Version C.OPT.01.22.307 and Later)	
Motor Setpoints Screen (Software Version C.OPT.01.22.307 and Later)	114
Setpoints Screen	117
Setup Screen	
Quick Start Screen (Software Version C.OPT.01.21.307 and Later)	
Schedule Screen	
User Screen	130
COMMS Screen	132
Printer Screen	134
Sales Order Screen	136
Operations Screen	138
History Screen	140
History Details Screen	142
Security Log Screen	143
Security Log Details Screen	145
Custom View Screen	147
Custom View Setup Screen	148
Trend Screen	150
Trend Setup Screen	152
Advanced Trend Setup Screen	154
Common Slots Screen	156
	464
SECTION 3 - DISPLAY MESSAGES	
Run Messages	
Start IIIIIbit Messages	
Pouting Messages	
Cucling Shutdown Messages	
Mod R Solid State Stater Cycling Shutdown Messages	
Niou B Soliu State Statel Cycling Shutuown Messages	
Safety Shutdown Messages	
Mod B Solid State Starter Safety Shutdown Messages	
Compressor Motor Variable Speed Drive: Safety Shutdown Messages	
SECTION 4 - PRINTING	
Printing Overview	
Acceptable Printers	
Printer Connections	
Printer Setup	
Control Center Setup	
Downloading System Prints to a Laptop	
Printer Connections	193

LIST OF FIGURES

FIGURE 1 - Model YK Chiller	9
FIGURE 2 - Compressor Pre-Rotation Vanes	10
FIGURE 3 - Refrigerant Flow-Through Chiller	11
FIGURE 4 - OptiView Control Center	15
FIGURE 5 - Home Screen	20
FIGURE 6 - System Screens	23
FIGURE 7 - Evaporator Screen	25
FIGURE 8 - Condenser Screen	28
FIGURE 9 - Heat Recovery Screen (Software Version C.Opt.01.21.307)	31
FIGURE 10 - Head Pressure Control Screen (Software Version C.Opt.01.21.307)	
FIGURE 11 - Heat Pump Screen (Software Version C.OPT.01.23.307 and Later)	
FIGURE 12 - Refrigerant Level Control Screen (Flash Memory Card Versions C.Mlm.01.06.XXX and Earl	lier)40
FIGURE 13 - Refrigerant Level Control Screen (Software Version C.Mlm.01.07.XXX to C.Mlm.01.10d.XX	X or
C.Opt.01.10d (and Earlier))	
FIGURE 14 - Refrigerant Level Control Setpoints Screen (Software Version C.Mlm.01.07.XXX to	
C.Mlm.01.10d.XXX or C.Opt.01.10d (and Earlier))	
FIGURE 15 - Refrigerant Level Control Screen (Software Versions C.Mlm.01.14.XXX and Later or	
C.Opt.01.14.306 and Later)	46
FIGURE 16 - Compressor Screen (All "P" Compressors and Style F and Later Chillers with	
G. Q. or H5-8 Compressors).	48
FIGURE 17 - Compressor Screen (Style E and Earlier Chillers with G. H. or J Compressors and	
Style G Chillers with K Compressors)	
FIGURE 18 - Proximity Probe Calibration Screen (Style F and Farlier Chillers with G H or J Compressor	rs
and Style F and Later Chillers with J or H3 Compressors)	54
FIGURE 19 - Hot Gas Bypass Screen	56
FIGURE 20 - Surge Protection Screen	58
FIGURE 21 - Variable Geometry Diffuser Screen	62
FIGURE 22 - Variable Geometry Diffuser Setpoints Screen	
FIGURE 23 - Pre-Rotation Vanes Calibration Screen	67
FIGURE 24 - VSD Tuning Screen	69
FIGURE 25 - Oil Sump Screen	71
FIGURE 26 - Electromechanical Starter Screen	74
FIGURE 27 - Mod A Solid State Statter Screen	76
FIGURE 28 - Mod B Solid State Starter Screen	78
FIGURE 29 - Medium Voltage Solid State Starter Screen	80
FIGURE 30 - Variable Speed Drive Screen with the Harmonic Filter Option	
FIGURE 31 - Medium Voltage Variable Speed Drive Screen (Software Version C. Opt 01, 16, XXX and Late	er) 84
FIGURE 32 - Variable Speed Drive (VSD) Details Screen for all TM Models, VSD, and LVD	.,
with 3 Drive Power Modules	
FIGURE 33 - Variable Speed Drive (VSD) Details Screen for all VSD and LVD with 1 Drive Power Module	e
FIGURE 34 - Adaptive Capacity Control Details Screen (Software Version C.Opt.01.18.307 and Earlier)	
(VSD and MVVSD)	91
FIGURE 35 - Adaptive Capacity Control Details Screen York Protocol Configuration	
(Software Version C.Opt.01.19.307 and Later).	93
FIGURE 36 - Adaptive Capacity Control Details Screen Modbus Protocol Configuration (Software Version	1
C.Opt.01.19.307 and Later)	95
FIGURE 37 - Surge Map Screen - Table View (Software Version C.Opt.01.19.307 and Later)	
FIGURE 38 - Surge Map Screen - List View (Software Version C.Opt.01.19.307 and Later)	
FIGURE 39 - Harmonic Filter Details Screen (for all TM and VSD Models of Drives)	
FIGURE 40 - Motor Lubrication Screen 1	
FIGURE 41 - Motor Lubrication Screen 2	
FIGURE 42 - Motor Details Screen (Software Version C.Opt.01.22.307 and Later)	110
FIGURE 43 - Motor Setpoints Screen (Software Version C.Opt.01.22.307 and Later)	114
FIGURE 44 - Setpoints Screen	117
•	

LIST OF FIGURES (CONT'D)

FIGURE 45 - Setup Screen	120
FIGURE 46 - Quick Start Screen (Software Version C.Opt.01.21.307 and Later)	125
FIGURE 47 - Schedule Screen	128
FIGURE 48 - User Screen	130
FIGURE 49 - COMMS Screen	132
FIGURE 50 - Printer Screen	134
FIGURE 51 - Sales Order Screen	136
FIGURE 52 - Operations Screen	138
FIGURE 53 - History Screen	140
FIGURE 54 - History Details Screen	142
FIGURE 55 - Security Log Screen	143
FIGURE 56 - Security Log Details Screen	145
FIGURE 57 - Custom View Screen	147
FIGURE 58 - Custom View Setup Screen	148
FIGURE 59 - Trend Screen	150
FIGURE 60 - Trend Setup Screen	152
FIGURE 61 - Advanced Trend Setup Screen	154
FIGURE 62 - Common Slots Screen	156
FIGURE 63 - Printer	189
FIGURE 64 - Breckman Printer	193
FIGURE 65 - Communications Block Diagram	193
FIGURE 66 - Sample Printout (Status)	194
FIGURE 67 - Sample Printout (Setpoints)	196
FIGURE 68 - Sample Printout (Schedule)	198
FIGURE 69 - Sample Printout (Sales Order)	198
FIGURE 70 - Sample Printout (History)	200
FIGURE 71 - Sample Printout (Security Log Report)	202
FIGURE 72 - Sample Printout (Trend Data New or Existing Points)	202
FIGURE 73 - Sample Printout (Custom Screen Report)	202
FIGURE 74 - Sample Printout (Adaptive Capacity Control New Map Point Report)	203
FIGURE 75 - Sample Printout (Adaptive Capacity Control Existing Map Points Report)	203

LIST OF TABLES

TABLE 1 - Addresses and Associated Data	19
TABLE 2 - Voltage (V)	85
TABLE 3 - Condenser Temperature Range	
TABLE 4 - Master Slot Numbers List for Use with Trend Feature	
TABLE 5 - Drive Overcurrent Limits	
TABLE 6 - Filter Overcurrent	
TABLE 7 - Filter Overload	178
TABLE 8 - VSD, LVD Converter over Temperature.	
TABLE 9 - VSD, LVD Inverter over Temperature	
TABLE 10 - VSD Filter over Temperature	
TABLE 11 - OKIDATA OKIPOS 441	
TABLE 12 - Brecknell CP130	
TABLE 13 - SI Metric Conversion	205

SECTION 1 - DESCRIPTION OF SYSTEM AND FUNDAMENTALS OF OPERATION

SYSTEM OPERATION DESCRIPTION

The YORK Model YK Chiller is commonly applied to large air conditioning systems, but may be used on other applications. The chiller consists of an open motor mounted to a compressor (with integral speed increasing gears), condenser, evaporator and variable flow control.

The chiller is controlled by a modern state of the art Microcomputer Control Center that monitors its operation. The Control Center is programmed by the operator to suit job specifications. Automatic timed start-ups and shutdowns are also programmable to suit nighttime, weekends, and holidays. The operating status, temperatures, pressures, and other information pertinent to operation of the chiller are automatically displayed and read on a graphic display. Other displays can be observed by pressing the keys as labeled on the Control Center. The chiller with the OptiView Control Center is applied with an Electromechanical Starter, YORK Solid State Starter (optional), or Variable Speed Drive (optional).

When the compressor motor is driven by a YORK Solid State Starter, one of three different starters could be applied. Later production chillers are equipped with either the Style B Liquid Cooled Solid State Starter (LCSSS) or the Medium Voltage Solid State Starter (MVSSS). Earlier vintage chillers are equipped with the Mod A Solid State Starter. This starter contains a Trigger Board that interfaces to a Logic Board that is installed inside of the Control Center.



FIGURE 1 - MODEL YK CHILLER



LD29026

FIGURE 2 - COMPRESSOR PRE-ROTATION VANES

When the compressor motor is driven by a YORK Variable Speed Drive, there could be a Variable Speed Drive (VSD) or a Medium Voltage Variable Speed Drive (MV VSD) applied.

In operation, a liquid (water or brine to be chilled) flows through the cooler, where boiling refrigerant absorbs heat from the liquid. The chilled liquid is then piped to fan coil units or other air conditioning terminal units, where it flows through finned coils, absorbing heat from the air. The warmed liquid is then returned to the chiller to complete the chilled liquid circuit. The refrigerant vapor, which is produced by the boiling action in the cooler, flows to the compressor where the rotating impeller increases its pressure and temperature and discharges it into the condenser. Water flowing through the condenser tubes absorbs heat from the refrigerant vapor, causing it to condense. The condenser water is supplied to the chiller from an external source, usually a cooling tower. The condensed refrigerant drains from the condenser into the liquid return line, where the variable orifice meters the flow of liquid refrigerant to the cooler to complete the refrigerant circuit.

The major components of a chiller are selected to handle the refrigerant, which would be evaporated at full load design conditions. However, most systems will be called upon to deliver full load capacity for only a relatively small part of the time the unit is in operation.

CAPACITY CONTROL

The major components of a chiller are selected for full load capacities, therefore capacity must be controlled to maintain a constant chilled liquid temperature leaving the cooler. Pre-rotation Vanes (PRV), located at the entrance to the compressor impeller, compensate for variation in load (See *Figure 2 on page 10*).

The position of these vanes is automatically controlled through a lever arm attached to an electric motor located outside the compressor housing. The automatic adjustment of the vane position in effect provides the performance of many different compressors to match various load conditions from full load with vanes wide open to minimum load with vanes completely closed.

Refrigerant Flow-Through Chiller (Falling Film Evaporator)



FIGURE 3 - REFRIGERANT FLOW-THROUGH CHILLER

THIS PAGE INTENTIONALLY LEFT BLANK

SECTION 2 - OPTIVIEW CONTROL CENTER INTRODUCTION

The OptiView Control Center is a microprocessor based control system for R-22 or R134a centrifugal chillers. It controls the leaving chilled liquid temperature via Pre-rotation Vane controls and has the ability to limit motor current via control of the Pre-rotation Vanes. It is compatible with YORK Solid State Starter (optional), Variable Speed Drive (optional), and Electromechanical Starter applications.

The panel comes configured with a full screen LCD Graphic Display mounted in the middle of a keypad interface. The graphic display allows the presentation of several operating parameters at once. In addition, the operator may view a graphical representation of the historical operation of the chiller as well as the present operation. For the novice user, the locations of various chiller parameters are clearly and intuitively marked. Instructions for specific operations are provided on many of the screens.

The graphic display also allows information to be represented in both English (temperatures in °F and pressures in psig) and Metric (temperatures in °C and pressures in kPa) mode. The advantages are most apparent, however, in the ability to display many languages.

The Control Center continually monitors the system operation and records the cause of any shutdowns (Safety, Cycling or Normal). This information is recorded in memory and is preserved even through a power failure condition. The user may recall it for viewing at any time. During operation, the user is continually advised of the operating conditions by various status and warning messages. In addition, it may be configured to notify the user of certain conditions via alarms. A complete listing of shutdown, status, and warning messages is detailed in the DISPLAY MES-SAGES portion of this manual.

There are certain screens, displayed values, programmable setpoints and manual control shown in this manual that are for Service Technician use only. They are only displayed when logged in at SERVICE access level or higher. The setpoints and parameters displayed on these screens are explained in detail in *OptiView Con*- *trol Center – Service Instructions (Form 160.54-M1).* These parameters affect chiller operation and should never be modified by anyone other than a qualified Service Technician. They are shown in this manual for reference only.

Advanced diagnostics and troubleshooting information for Service Technicians are included in *OptiView Control Center – Service Instructions (Form 160.54-M1)*. Also included in the service manual are detailed descriptions of chiller features, such as the Refrigerant Level Control, Variable Speed Drive Oil Pump, Hot Gas Bypass, High Speed Thrust Bearing Proximity Probe, Remote Setpoints, Smart Freeze Protection, and Standby Lubrication.

The Control Center expands the capabilities of remote control and communications. By providing a common networking protocol through the Building Automation System (BAS), YORK Chillers not only work well individually, but also as a team. This new protocol allows increased remote control of the chiller, as well as 24-hour performance monitoring via a remote site. In addition, compatibility is maintained with the present network of BAS communications. The chiller also maintains the standard digital remote capabilities as well. Both of these remote control capabilities allow for the standard Energy Management System (EMS) interface:

- 1. Remote Start
- 2. Remote Stop
- 3. Remote Leaving Chilled Liquid Temperature Setpoint adjustment (0 to 10 VDC, 2 to 10 VDC, 0 to 20mA or 4 to 20mA) or Pulse Width Modulation
- 4. Remote Current Limit Setpoint adjustment (0 to 10 VDC, 2 to 10 VDC, 0 to 20mA or 4 to 20mA) or Pulse Width Modulation
- 5. Remote READY TO START Contacts
- 6. Safety Shutdown Contacts
- 7. Cycling Shutdown Contacts

The chiller operating program resides in the OptiView Control Center Microboard. The Control Center could be equipped with either of the following Microboards:

- 031-01730-000 shipped in new production chillers until January 2004. The program resides in a replaceable Flash Memory Card. The software version (C.MLM.01.xx.yzz) is printed on label adhered to card. Program can be upgraded by replacing the card.
- 031-02430-000 shipped in new production chillers between January 2004 and June 2006. The program resides in non-removable onboard memory. The software version is C.OPT.01.xx.yzz, and is viewable on the DIAGNOSTICS Screen in SER-VICE access level. The program can be upgraded by downloading a new program from a Program Card. Program Cards are shirt-pocket-size portable memory storage devices available from YORK.
- 031-02430-001 Shipped in new production chillers after June 2006. This is an upgraded version of the 031-02430-000 microboard. The upgrade is necessary to operate with the Medium Voltage Solid State Starter, Medium Voltage Variable Speed Drive and those Variable Speed Drives and Style B Solid State Starters that serially communicate with the microboard using Modbus Protocol. Variable Speed Drive Modbus applications require software version C.OPT.01.16.307 (or later). Style B Solid State Starter Modbus applications require software version C.OPT.01.18.307 (or later).

The upgrade includes a larger BRAM (U38) and an additional RS-485 port on COM2 serial port for Modbus communications. When used in larger BRAM configuration, requires software version C.OPT.01.15.xxx (or later). This board is backward compatible with YK chillers presently using the 031-01730-000 or 031-02430-000 microboard.

Earlier vintage chillers could be equipped with a later Microboard due to service replacement.

Software versions (C.MLM.01.xx.yzz or C.OPT.01. xx.yzz) are alpha-numeric codes that represent the following application, language package, and revision levels:

- C Commercial chiller
- MLM Used on Microboard 031-01730-000
- OPT Used on Microboard 031-02430-000
- 01 YK chiller
- xx controls revision level (00, 01, and so on)
- y language package (0 equals English only, 1 equals NEMA, 2 equals CE, 3 equals NEMA/CE)
- zz language package revision level (00, 01, and so on)

Each time the controls portion or language section is revised, the respective revision level increments.

Throughout this manual, reference is made to functions and features that are only available in certain Flash Memory Card revision levels (C.MLM.01.xx.xxx). To cross reference C.MLM software to C.OPT software, refer to the controls revision level. Software version C.OPT.01.08A.300 is of the same controls revision level as C.MLM.01.08.105A/.206A. From this starting point, both receive the same updates at each revision. Software upgrades should only be performed by a Service Technician.

OPTIVIEW CONTROL CENTER



FIGURE 4 - OPTIVIEW CONTROL CENTER

The OptiView[™] Control Center display is highlighted by a full screen graphics display. This display is nested within a standard keypad, and is surrounded by SOFT keys which are redefined based on the currently displayed screen. Eight buttons are available on the right side of the panel, and are primarily used for navigation between the system screens. At the base of the display are 5 additional buttons. The area to the right of the keypad is used for data entry with a standard numeric keypad provided for entry of system setpoints and limits.

The DECIMAL key provides accurate entry of setpoint values.

A+/- key has also been provided to allow entry of negative values and AM/PM selection during time entry.



In order to accept changes made to the chiller setpoints, the CHECK key is provided as a universal 'Enter' key or 'Accept'' symbol.



In order to reject entry of a setpoint or dismiss an entry form, the 'X'key is provided as a universal 'Cancel' symbol.



Cursor Arrow keys are provided to allow movement on screens which contain a large amount of entry data. In addition, these keys can be used to scroll through history and event logs.

29348A

The Start/Stop control is operated via a three-position rocker switch. When toggled all the way to the right, it is considered in the STOP/RESET position. When in the middle position, this is considered the RUN state. When toggled to the left-most position, it is considered in the START state. Each state is described in detail below:

• STOP / RESET (O)

When in this position, the chiller will not run under any condition. For safety reasons, this position is required for many maintenance tasks to be completed (such as proximity probe and vane calibration). In addition, the switch must be placed in this state following a safety shutdown before the chiller is allowed to restart. This guarantees that manual intervention has taken place and the shutdown has been acknowledged.

• START (◀)

The switch can only remain in this position when being acted upon by a manual force. Once the user has released the switch, it automatically reverts to the RUN position. Generally, this state only occurs momentarily as the operator attempts to locally start the unit. Once this position has been sensed, if all fault conditions are cleared, the unit will enter the System Prelube (start sequence).

• RUN (■)

When in this position, the chiller is able to operate. The switch spring-returns to this state after it has been toggled to the START position. When in this state, the chiller is allowed to function normally, and will also allow the chiller to automatically restart following a cycling shutdown. The switch must be in this state to receive a valid remote start signal when operating under a remote control source.

INTERFACE CONVENTIONS OVERVIEW

The new graphical display on each control panel allows a wide variety of information to be presented to the user. Each screen description in this document will begin with a section entitled OVERVIEW which will describe the graphical elements on the screen and give a short summary of the functions available. Each element on the screen will then be categorized into three distinct groups: Display Only, Programmable, and Navigation. Below is a short description of what types of information are included in these groups.

The Programmable values and Navigation commands are also subject to access level restrictions as described below. For each of these elements, an indication is given to show the minimum access level required to program the value or navigate to the subscreen.

DISPLAY ONLY

Values in this group are read-only parameters of information about the chiller operation. This type of information may be represented by a numerical value, a text string, or an LED image. For numerical values, if the monitored parameter is above the normal operating range, the high limit value will be displayed along with the '>' symbol; if it is below the normal operating range, the low limit value will be displayed along with the '<' symbol. In some cases, the value may be rendered invalid by other conditions and the display will use Xs to indicate this.

PROGRAMMABLE

Values in this group are available for change by the user. In order to program any setpoints on the system, the user must first be logged in with the appropriate access level. Each of the programmable values requires a specific access level which will be indicated beside the specified value. All of the programmable controls in the system fall into one of the categories described below:

Access Level

In order to program any setpoints on the system, the user must first login with an appropriate access level. When power is applied to the chiller, the system begins with an access level of VIEW. This will allow the user to navigate to most screens and observe the values displayed there. However, the user will not be allowed to change any values. To change any values, the user must return to the HOME Screen (shown by default when power is applied to the system), and use the LOGIN button or utilize the CHANGE SETPOINTS key described below. At this point, the user will be prompted to enter a User ID and the corresponding password. By default, the User ID is zero (0). In order to gain standard OPERATOR level access, the password would be entered as 9 6 7 5, using the numeric keypad. OPERA-TOR access reverts to the VIEW level after 10 continuous minutes without a keypress. If a custom User ID and password have been defined (see User Screen on page 130), the user may enter that User ID and the corresponding password value.

If the correct password is received, the user is authorized with the appropriate access level. If an incorrect password is entered, the user is notified of the failure and prompted again. At this point the user may retry the password entry, or cancel the login attempt.

Change Setpoints

On screens containing setpoints programmable at the OPERATOR access level, a key with this label will be visible if the present access level is VIEW. This key brings up the access level prompt described above. It allows the user to login at a higher access level without returning to the HOME Screen. After login, the user may then modify setpoints on that screen.

Setpoints

The Control Center uses the setpoint values to control the chiller and other devices connected to the chiller system. Setpoints can fall into several categories. They could be numeric values (such as 45.0°F for the Leaving Chilled Liquid Temperature), or they could enable or disable a feature or function.

Regardless of which setpoint is being programmed, the following procedure applies:

- 1. Press the desired setpoint key. A dialog box appears displaying the present value, the upper and lower limits of the programmable range, and the default value.
- 2. If the dialog box begins with the word ENTER, use the numeric keys to enter the desired value. Leading zeroes are not necessary. If a decimal point is necessary, press the '•' key (for example 45.0).

Pressing the \blacktriangle key, sets the entry value to the default for that setpoint. Pressing the \lor key, clears the present entry. The \blacktriangleleft key is a backspace key and causes the entry point to move back one space.

If the dialog box begins with SELECT, use the \blacktriangleleft and \blacktriangleright keys to select the desired value.

If the previously defined setpoint is desired, press the 'X' (Cancel) key to dismiss the dialog box.

- 3. Press the ' \checkmark ' (Enter) key.
- 4. If the value is within range, it is accepted and the dialog box disappears. The chiller will begin to operate based on the new programmed value. If out of range, the value will not be accepted and the user is prompted to try again.

Manual Controls

Some keys are used to perform manual control functions. These may involve manual control of items such as the Pre-rotation Vanes, variable orifice or oil pump speed. Other keys in this category are used to initiate/ terminate processes such as calibrations or reports.

Free Cursor

On screens containing many setpoints, a specific SOFT key may not be assigned to each setpoint value. A SOFT key will be assigned to enable the cursor arrow keys below the numeric keypad which are used to HIGHLIGHT the desired setpoint field. At this point, the (\checkmark) key is pressed to bring up a dialog prompting the user to enter a new setpoint value. The (X) key cancels cursor mode. (See the *Schedule Screen on page 128* for an example.)

NAVIGATION

In order to maximize the amount of values which the panel can display to the user, and in order to place those values in context, multiple screens have been designed to describe the chiller operation. In order to move from one screen to the next, navigation keys have been defined. These keys allow the user to either move FORWARD to a subscreen of the present screen, or move BACKWARD to the previous screen. Except for the HOME Screen display, the upper-right SOFT key will always return the user to the HOME Screen. Navigating with SOFT keys is as simple as pressing the key next to the label containing the name of the desired screen. The system will immediately refresh the display with the graphics for that screen. Following is a layout of all the screens and how they are connected. Home Screen (page 20)

- System Screen (page 23) • Evaporator (*page 25*) Heat Pump (page 37) - Condenser (page 28) - Level Control (page 40 - 46) - Heat Recovery (page 31) - Heat Pump (page 37) - Head Pressure Control (*page 35*) Compressor (*page 48*) - Proximity Probe Calibration (page 54) Hot Gas Bypass (page 56) - Surge Protection Screen (page 58) - Variable Geometry Diffuser (*page 62*) - Pre-rotation Vanes Calibration (page 67) - VSD Tuning (page 69) Oil Sump (page 71) - Motor (page 74) - Electromechanical Starter Version (*page 74*) – Mod A Solid State Starter (page 76) - Mod B Solid State Starter (page 78) - Medium Voltage Solid State Starter (page 80) - VSD (*page 82*) - VSD Details (*page 87*) ACC Details (page 91) Surge Map (*page 98 - 100*) - Harmonic Filter Details (*page 102*) - Motor Lubrication (page 104) Motor Details Screen (page 110) - Motor Setpoints Screen (page 114) Setpoints (page 117) - Setup (*page 120*) - Schedule (page 128) User (*page 130*) Comms (page 132) Printer (page 134) Sales Order (page 136) Operations (page 138) - Diagnostics (Refer to OptiView Control Center - Service Instructions (Form 160.54-M1))Quick Start (page 125)

- History (page 140) - History Details (page 142) - Security Log Screen (page 143) └ Security Log Details Screen (*page 145*) - Custom View (page 147) └─ Custom Setup (*page 148*) - Trend (*page 150*) – Trend Setup (*page 152*) Advanced Trend Setup (page 154) Common Slots (page 156)

LANGUAGES

The Screens can be displayed in various languages. Language selection is done on the USER Screen. The desired language is selected from those available. Not all languages are available. English is the default language. If a language other than English is being displayed, an English-only speaking person should navigate to the USER Screen using the preceding navigation chart and select English as shown in the User Screen instructions in this manual.

ANALOG INPUT RANGES

The following table indicates the valid display range for each of the analog input values. In the event that the input sensor is reading a value outside of these ranges, the < or > symbols will be displayed beside the minimum or maximum value, respectively.

TABLE 1 - ADDRESSES AND ASSOCIATED DATA

	ENGLISH RANGE			METRIC RANGE		
ANALOG INPUT	LOW	HIGH	UNITS	LOW	HIGH	UNITS
Leaving Chilled Liquid Temperature	0.0	82.0	°F	-17.7	27.7	°C
Leaving Chilled Liquid Temperature – Heat Pump Duty	0.0	136.4	°F	-17.7	58.0	°C
Return Chilled Liquid Temperature	0.0	94.1	°F	-17.7	34.5	°C
Return Chilled Liquid Temperature – Heat Pump Duty	0.0	133.9	°F	-17.7	56.6	°C
Leaving Condenser Liquid Temperature	8.0	133.5	°F	-13.3	56.3	°C
Return Condenser Liquid Temperature	8.0	133.5	°F	-13.3	56.3	°C
Evaporator Refrigerant Temperature (Optional)	0.0	126.1	°F	-17.7	52.3	°C
Discharge Temperature	31.8	226.3	°F	-0.1	107.9	°C
Oil Temperature	31.8	226.3	°F	-0.1	107.9	°C
Condenser Pressure (R22 and R134a)	***0.0	315.0	psig	0.0	2172.4	kPag
Condenser Temperature (R22)*	-122.1	130.9	°F	-85.6	54.9	°C
Condenser Temperature (R134a)*	-98.7	160.1	°F	-72.6	71.7	°C
Evaporator Pressure (R22 – water)	49.4	128.8	psig	340.6	888.2	kPag
Evaporator Pressure (R22 – brine)	25.0	100.0	psig	172.4	689.6	kPag
Evaporator Pressure (R134a)	5.5	77.4	psig	37.9	533.7	kPag
Evaporator Pressure (R134a) – Heat Pump Duty	0.0	125.0	psig	0.0	861.8	kPag
Evaporator Temperature (R22 – water)*	13.0	67.0	°F	-10.5	19.4	°C
Evaporator Temperature (R22 – brine)*	-18.0	51.4	°F	-27.7	10.7	°C
Evaporator Temperature (R134a)*	-44.9	64.7	°F	-42.7	18.1	°C
Oil Sump Pressure (R22)	23.2	271.8	psig	160.0	1874.4	kPag
Oil Sump Pressure (R134a)	0.0	315.0	psig	0.0	2172.4	kPag
Oil Pump Pressure (R22 and R134a)	0.0	315.0	psig	0.0	2172.4	kPag
High Speed Thrust Bearing Proximity Position (Style E and earlier chillers with G, H, or J compressors and Style F and later chillers with J or H3 compressors)	8.0	99.0	mils	0.203	2.514	mm
High Speed Thrust Bearing Drain Temperature**	19.1	300.0	°F	-7.1	148.8	°C
Refrigerant Level	0.0	100.0	%	0.0	100.0	%
Drop Leg Refrigerant Temperature	0.0	121.7	°F	-17.7	49.8	°C
Motor Winding Temperature – RTD (Phase A, B, C)	32.0	399.5	°F	0.0	204.2	°C
Motor Winding Temperature – 50K Ohm Transmitter (Phase A, B, C)	31.2	412.5	°F	-0.5	211.4	°C
Motor Bearing Temperature – RTD (Shaft End and Opposite End)	32.0	399.5	°F	0.0	204.2	°C
Motor Bearing Vibration – Accelerometer (Shaft End and Opposite End)	0.0	30.0	_	_	_	-

*Saturation temperatures are calculated values. They will display XXX if the pressure used for the calculation is out of range.

**Not applicable to chillers equipped with Flash Memory Card version C.MLM.01.03 and later.

***7.5 psig Flash Memory Card version C.MLM.01.04 and later.

HOME SCREEN



FIGURE 5 - HOME SCREEN

OVERVIEW

When the chiller system is powered on, the above default display appears. The primary values which must be monitored and controlled are shown on this screen. The HOME Screen display depicts a visual representation of the chiller itself. Animation indicates chilled liquid flow.

DISPLAY ONLY

Chilled Liquid Temperature – Leaving

Displays the temperature of the liquid as it leaves the evaporator.

Chilled Liquid Temperature – Return

Displays the temperature of the liquid as it enters the evaporator.

Condenser Liquid Temperature – Leaving

Displays the temperature of the liquid as it leaves the condenser.

Condenser Liquid Temperature – Return

Displays the temperature of the liquid as it enters the condenser.

Motor Run (LED)

Is ON when the digital output controlling the motor starter contact is on.

Input Power (kW)

Available only if the chiller system is utilizing a Variable Speed Drive (VSD), Medium Voltage Variable Speed Drive (MV VSD), Mod B Solid State Starter or Medium Voltage Solid State Starter motor controller. This displays the total input power used by the system.

% Full Load Amps

This displays the percentage of Full Load Amps utilized by the system.

Operating Hours

Displays the cumulative operating hours of the chiller.

Heating Condenser Liquid Temperature – Leaving

(Software version C.OPT.01.21.307 and later)

Displays the temperature of the liquid as it leaves the heating condenser tube bundle. Only appears when the Heat Recovery is enabled.

Heating Condenser Liquid Temperature – Return

(Software version C.OPT.01.21.307 and later)

Displays the temperature of the liquid as it enters the heating condenser tube bundle. Only appears when the Heat Recovery is enabled.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Login

Access Level Required: VIEW

The OptiView Panel restricts certain operations based on password entry by the operator. Three different access levels are provided as follows:

- VIEW: The panel defaults to the lowest access level which is termed VIEW. In this mode, the chiller operating values and setpoints can be observed, but no changes can be made.
- OPERATOR: The second access level is termed OPERATOR and will allow the customer to change all of the setpoints required to operate the chiller system. The OPERATOR access level reverts to the VIEW level after 10 continuous minutes without a keypress.
- SERVICE: In the event that advanced diagnostics are necessary, a SERVICE access level has been provided. Only qualified service personnel utilize this access level. This level provides advanced control over many of the chiller functions and allows calibration of many of the chiller controls.

The access levels are listed above in hierarchical order beginning with the lowest level and proceeding to the highest level. Users logged in under higher access levels may perform any actions permitted by lower access levels.

The OPERATOR access level is accompanied by a 10-minute timeout. After ten (10) successive minutes without a keypress, the panel will revert to the VIEW access level. This prevents unauthorized changes to the chiller if a user was logged in at a higher access level and failed to logout. Proper procedure requires that after making necessary setpoint adjustments the user return to the HOME Screen and logout.

Logout

Access Level Required: OPERATOR

This key is displayed when a user is logged in at any level other than VIEW. Pressing it will return the access level to VIEW.

Print

Access Level Required: VIEW

Use this key to generate a hard-copy report of the present system status. This provides a snapshot of the primary operating conditions at the time the key is pressed. The History page provides enhanced reporting capability. (See *History on page 22*.) This option will not be present if the chiller is presently configured to log any incoming Adaptive Capacity Control map points. (See the *Adaptive Capacity Control Details Screen on page 95*.)

Message Clear

Access Level Required: SERVICE

When certain safety or cycling conditions have been detected and the chiller has been shutdown, the main status display of the chiller will continue to display a message indicating the cause of the shutdown. Using this key, the message can be cleared once the condition has been removed.

Warning Reset

Access Level Required: OPERATOR

Use of this key acknowledges a warning condition and resets the message display associated with it.

Soft Shutdown

(Flash Memory Card version C.MLM.01.06.xxx and later)

Access Level Required: OPERATOR

This key, available only when the compressor is running, is used to initiate a Soft Shutdown. A Soft Shutdown fully closes the Pre-rotation Vanes prior to shutting down the compressor. This reduces bearing wear by eliminating compressor backspin at shutdown. Pressing this key causes the vanes to be driven to the fully closed position. While the vanes are closing, Vanes Closing Before Shutdown is displayed on the System Status Line. When the Vane Motor Switch (VMS) closes, indicating the vanes have fully closed (or 3.5 minutes have elapsed, whichever occurs first), the Run signal is removed from the compressor motor starter and a System Coastdown is performed. While the vanes are closing, if a Local Stop is initiated with the Compressor Switch or any fault other than Leaving Chilled Liquid Temp – Low Temperature, Remote Stop, Multi-Unit Cycling – Contacts Open, System Cycling – Contacts Open Or Control Panel – Schedule occur, it will immediately enter System Coastdown. To restart the chiller after an operator initiated Soft Shutdown, the Compressor Switch must be placed in the Stop/Reset position (O) and then the Start position (3).

NAVIGATION

System

Used to provide additional system information.

Evaporator

A detailed view of all evaporator parameters, including the programmable Leaving Chilled Liquid Setpoints.

Condenser

A detailed view of all condenser parameters, including control of the liquid level functions.

Compressor

A detailed view of all the compressor parameters. This includes Pre-rotation Vane control, Hot Gas Bypass Control, Proximity Probe Calibration, and PRV Calibration.

Oil Sump

A detailed view of all the oil pump and oil sump parameters. This includes the Variable Speed Oil Pump when installed. It also controls the Seal Lubrication functionality.

Motor

A detailed view of the motor controller parameters, specific to the controller type presently utilized on the chiller system. This allows programming of the current limit and the pulldown demand limit values. For a VSD system, the Adaptive Capacity Control and Harmonic Filter information is controlled under this screen.

Setpoints

This screen provides a single location to program the most common system setpoints. It is also the gateway to many of the general system setup parameters such as Date/Time, Display Units, Scheduling, Printer Setup, and so on.

History

This screen provides access to a snapshot of system data at each of the last 10 shutdown conditions.

SYSTEM SCREEN



FIGURE 6 - SYSTEM SCREENS

OVERVIEW

This screen gives a general overview of common chiller parameters for both shells.

DISPLAY ONLY

Discharge Temperature

Displays the temperature of the refrigerant in its gaseous state at discharge of the compressor as it travels to the condenser.

Chilled Liquid Temperature – Leaving

Displays the temperature of the liquid as it leaves the evaporator.

Chilled Liquid Temperature – Return

Displays the temperature of the liquid as it enters the evaporator.

Chilled Liquid Temperature – Setpoint

Displays the active temperature setpoint to which the chiller is controlling the evaporator liquid. This value

could come from a 0 to 20mA, 4 to 20mA, 0 to 10 VDC or 2 to 10 VDC input in Analog Remote mode, PWM signal in Digital Remote mode, E-Link Gateway interface in ISN mode, or a locally programmed value.

Evaporator Pressure

Displays the present refrigerant pressure in the evaporator.

Evaporator Saturation Temperature

Displays the present saturation temperature in the evaporator.

Condenser Liquid Temperature – Leaving

Displays the temperature of the liquid as it leaves the condenser.

Condenser Liquid Temperature – Return

Displays the temperature of the liquid as it enters the condenser.

Condenser Liquid Temperature – Setpoint

(Software version C.OPT.01.23.307 and later)

Displays the active setpoint to which the Heat Pump is controlling the Leaving Condenser Liquid Temperature. Only displayed when Heat Pump is enabled on the SETUP Screen and the Operation mode is set to Heating mode on the HEAT PUMP Screen.

Heating Condenser Liquid Temperature – Leaving

(Software version C.OPT.01.21.307 and later)

Displays the temperature of the liquid as it leaves the heating condenser tube bundle. Only appears when the Heat Recovery is enabled.

Heating Condenser Liquid Temperature – Return

(Software version C.OPT.01.21.307 and later)

Displays the temperature of the liquid as it enters the heating condenser tube bundle. Only appears when the Heat Recovery is enabled.

Heating Condenser Liquid Temperature – Active Hot Water Setpoint

(Software version C.OPT.01.21.307 and later)

Displays the Hot Water Setpoint to which the Leaving Heating Condenser Liquid Temperature is being controlled. Only appears when Heat Recovery is enabled and Hot Water Control is enabled.

Delta P

(Software version C.OPT.01.21.307 and later) Displays the pressure difference between the condenser and evaporator (condenser minus evaporator). This is also called the Head Pressure. Only appears when Head Pressure Control is enabled.

Head Pressure Setpoint

(Software version C.OPT.01.21.307 and later)

Displays the active Head Pressure Setpoint to which the head pressure is being controlled. Only appears when Head Pressure Control is enabled.

Condenser Pressure

Displays the refrigerant pressure in the condenser.

Condenser Saturation Temperature

Displays the saturation temperature in the condenser.

Oil Sump Temperature

Displays the temperature of the oil in the sump.

Oil Pressure

Displays the pressure differential between the high side oil pressure transducer (output of oil filter) and the low side oil pressure transducer (compressor housing). The displayed value includes offset pressure derived from auto-zeroing during the System Prelube. If either of the transducers used to calculate this differential is out of range, the display field will show XX.X.

% Full Load Amps

This displays the percentage of Full Load Amps utilized by the system.

Current Limit

Displays the current limit value in use. This value could come from a 0 to 20mA, 4 to 20mA, 0 to 10 VDC or 2 to 10 VDC input in Analog Remote mode, PWM signal in Digital Remote mode, E-Link Gateway interface in ISN mode, or a locally programmed value.

PROGRAMMABLE

None

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

EVAPORATOR SCREEN



FIGURE 7 - EVAPORATOR SCREEN

2

OVERVIEW

This screen displays a cutaway view of the chiller evaporator. All setpoints relating to the evaporator side of the chiller are maintained on this screen. Animation of the evaporation process indicates whether the chiller is presently in a RUN condition. Animation of the liquid flow indicates chilled liquid flow.

DISPLAY ONLY

Chilled Liquid Flow Switch (Open / Closed)

Displays whether the liquid flow is present in the evaporator.

Chilled Liquid Pump

Displays the command presently sent by the Control Center to the Chilled Liquid Pump (RUN or STOP).

Evaporator Pressure

Displays the present refrigerant pressure in the evaporator.

Evaporator Saturation Temperature

Displays the present saturation temperature in the evaporator.

Return Chilled Liquid Temperature

Displays the temperature of the liquid as it enters the evaporator.

Leaving Chilled Liquid Temperature

Displays the temperature of the liquid as it leaves the evaporator.

Evaporator Refrigerant Temperature

Displays the temperature of the refrigerant in the evaporator, if the sensor is present.

Small Temperature Difference

Displays the difference between the Leaving Chilled Liquid temperature and the Evaporator Refrigerant Temperature. The Evaporator Refrigerant Temperature will be represented by the Refrigerant Temperature sensor input if the sensor is present, otherwise it will be represented by the Evaporator Saturation Temperature.

Leaving Chilled Liquid Temperature Setpoints – Setpoint

Displays the present setpoint to which the chiller is operating, whether controlled locally or remotely.

Leaving Chilled Liquid Temperature Setpoints – Shutdown

Displays the Leaving Chilled Liquid Temperature at which the chiller will shutdown on Leaving Chilled Liquid – Low Temperature. This temperature is entered as an offset with the Leaving Chilled Liquid Temperature Cycling Offset – Shutdown Setpoint below. Although the offset setpoint is changed manually, the offset being used can change automatically to prevent the Leaving Chilled Liquid Temperature from going below the minimum allowed value: 36°F (water), 34°F (water with smart freeze enabled) or 6°F (brine). The offset being used is displayed as Effective Offset. With software versions earlier than C.OPT.01.18.307, the value is displayed as OFFSET and reflects the programmed value only, not the offset being used. Refer to setpoint description below.

Leaving Chilled Liquid Temperature Setpoints – Restart

Displays the Leaving Chilled Liquid Temperature at which the chiller will restart after it has shutdown on LEAVING CHILLED LIQUID – LOW TEMPERA-TURE cycling shutdown. This temperature is set as an offset using the Leaving Chilled Liquid Temperature Cycling Offset – Restart Setpoint, displayed as OFF-SET adjacent to this value.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Local Leaving Chilled Liquid Temperature – Range

Access Level Required: OPERATOR

This is the range over which an analog (0 to 20mA, 4 to 20mA, 0 to 10 VDC or 2 to 10 VDC) in Analog Remote mode or a digital signal (PWM) in Digital Remote mode can reset the Leaving Chilled Liquid Temperature Setpoint above the operator programmed BASE Setpoint. Programmable as 10, 20, 30 or 40°F (software version C.OPT.01.18.307 (or later); 10°F or 20°F with earlier software versions). It is added to the BASE value to create a range over which the remote device can reset the setpoint. For example, if this setpoint is programmed for 10°F and the operator programmed value is 45°F, then the remote device can set the Leaving Chilled Liquid Temperature Setpoint over the range of 45.0° to 55.0°F.

Local Leaving Chilled Liquid Temperature – Setpoint

Access Level Required: OPERATOR

This value allows the user to define the Leaving Chilled Liquid Temperature that is to be maintained by the chiller. It is programmable over the range of 38.0°F to 70.0°F (water) or 10.0°F to 70.0°F (brine). If Smart Freeze (see page 27) is enabled, the range is 36.0°F to 70.0°F (water). The maximum allowed setpoint with Heat Pump duty enabled is 86.0°F (software version C.OPT.01.23.307 and later). A remote device can provide an analog signal (0 to 20mA, 4 to 20mA, 0 to 10 VDC or 2 to 10 VDC) in Analog Remote mode, or PWM signal in Digital Remote mode that changes the setpoint by creating an offset above the operator programmed BASE Leaving Chilled Liquid Temperature Setpoint. This offset may be defined as 10 to 20°F above the BASE Setpoint (See the Leaving Chilled Liquid Temperature Setpoints - Setpoint on page 25 description). Additionally, E-Link Gateway (in ISN Remote mode) can define the setpoint through a serial data stream. In this case, the incoming setpoint is not an offset that is applied to the locally programmed BASE Setpoint value, but rather is the setpoint value itself.

Leaving Chilled Liquid Temperature Cycling Offset – Shutdown

Access Level Required: OPERATOR

This value allows the user to specify the Leaving Chilled Liquid Temperature at which the chiller will shut down on a LEAVING CHILLED LIQUID - LOW TEMPERATURE cycling shutdown. This is done by defining an offset below the Leaving Chilled Liquid Temperature Setpoint. It is programmable over a range of 1°F to 64°F below the setpoint, to a minimum cutout of 36°F (water), 34°F (water with Smart Freeze enabled) or 6°F (brine). Anytime the Leaving Chilled Liquid Temperature Setpoint is increased, the shutdown threshold is 36.0°F (water) or 6.0°F (brine) for the next ten (10) minutes. If Smart Freeze (see page 27) is enabled, the threshold is 34.0°F for the next 10 minutes. After ten (10) minutes have elapsed, the shutdown threshold becomes the programmed setpoint value.

With software version C.OPT.01.18.307 (or later), the offset being used is displayed as Effective Offset in the upper right area of the display. Usually, the Offset used is the same as the value programmed for the Shutdown Setpoint. However, the Offset being used will automatically change based on the values programmed for the Leaving Chilled Liquid Temperature Setpoint and

FORM 160.54-O1 ISSUE DATE: 06/14/2019

SECTION 2 - OPTIVIEW CONTROL CENTER INTRODUCTION

the Shutdown Setpoint, to prevent the Leaving Chilled Liquid Temperature from going below the minimum allowed value: 36°F (water), 34°F (water with smart freeze enabled) or 6°F (brine). For example, if the Leaving Chilled Liquid Temperature Setpoint is set to 45°F (water) and the Shutdown Setpoint is set to 4°F, the Effective Offset is displayed as 4°F. If the leaving setpoint is lowered to 38°F, the Effective Offset will change to 2°F. If the leaving chilled setpoint is raised back to 45°F, the Effective Offset will revert back to the Shutdown Setpoint. With software versions prior to C.OPT.01.18.307, the value is displayed as Offset and reflects the programmed value only, not the offset being used.

Leaving Chilled Liquid Temperature Cycling Offset – Restart

Access Level Required: OPERATOR

This value allows the user to specify the Leaving Chilled Liquid Temperature at which the chiller will restart after a shutdown on a LEAVING CHILLED LIQUID – LOW TEMPERATURE cycling shutdown. This is done by defining an offset above the Leaving Chilled Liquid Temperature Setpoint. It is programmable over a range of 0°F to 70°F above the setpoint, to a maximum restart value of 80°F. The chiller will automatically restart when this temperature is reached. This setpoint can be used to reduce chiller cycling by delaying the chiller restart until the cooling load has increased.

Brine Low Evaporator Cutout

Access Level Required: SERVICE

This value is only available in Brine mode. It allows the user to specify the Evaporator Pressure at which a safety shutdown is initiated.

Sensitivity

Access Level Required: SERVICE

This value allows the user to adjust the sensitivity of the Leaving Chilled Liquid Temperature control.

Smart Freeze (Off / On)

Access Level Required: SERVICE

This value is only available if the chiller is not in Brine mode. It allows the user to enable the Smart Freeze Point Operation which allows the chiller to run closer to the freeze point without shutting down.

Refrigerant (Enabled / Disabled)

Access Level Required: SERVICE

When an Evaporator Refrigerant Sensor has been installed it must be enabled via this toggle before the system will utilize the new, enhanced resolution input.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Heat Pump

(Software version C.OPT.01.23.307 and later) Access Level Required: VIEW

Moves to a sub screen allowing programming and viewing of the Heat Pump Setpoints and parameters. Only appears when Heat Pump is enabled on the SET-UP Screen.

CONDENSER SCREEN



OVERVIEW

This screen displays a cutaway view of the chiller condenser. All setpoints relating to the condenser side of the chiller are maintained on this screen. Animation indicates condenser liquid flow. With software version C.OPT.01.21.307 and later, when Heat Recovery is enabled, the condenser flow animation will show flow when either the Condenser Liquid Flow Switch or the Heating Condenser Liquid Flow Switch says flow is present. When Heat Recovery is disabled, the condenser flow animation is based on the standard Condenser Flow Switch. This screen also serves as a gateway to controlling the Refrigerant Level, Heat Recovery and Head Pressure Control.

DISPLAY ONLY

Leaving Condenser Liquid Temperature

Displays the water temperature as it leaves the condenser.

Leaving Condenser Liquid Temperature Setpoint

(Software version C.OPT.01.23.307 and later)

Displays the active setpoint to which the Heat Pump is controlling the Leaving Condenser Liquid Temperature. Only displayed when Heat Pump is enabled on the SETUP Screen and the Operation mode is set to Heating mode on the HEAT PUMP Screen.

Return Condenser Liquid Temperature

Displays the water temperature as it enters the condenser.

Condenser Saturation Temperature

Displays the saturation temperature in the condenser.

Small Temperature Difference

Displays the difference between the Condenser Refrigerant temperature and the Leaving Condenser Liquid temperature. The Condenser Refrigerant temperature will be represented by the Condenser Saturation temperature.

Condenser Pressure

Displays the refrigerant pressure in the condenser.

Heating Condenser Liquid Temperature – Leaving

(Software version C.OPT.01.21.307 and later)

Displays the temperature of the liquid as it leaves the heating condenser tube bundle. Only appears when the Heat Recovery is enabled.

Heating Condenser Liquid Temperature – Return

(Software version C.OPT.01.21.307 and later)

Displays the temperature of the liquid as it enters the heating condenser tube bundle. Only appears when the Heat Recovery is enabled.

Heating Condenser Liquid Flow Switch (LED)

(Software version C.OPT.01.21.307 and later) Displays the status of the flow switch in the heating condenser tube bundle. Illuminates when liquid flow is present. Otherwise, it is extinguished. Only appears when the Heat Recovery is enabled.

Condenser Liquid Flow Switch (LED)

(Software version C.OPT.01.21.307 and later)

Displays the status of the flow switch in the standard condenser tube bundle. Illuminates when liquid flow is present. Otherwise, it is extinguished. Only appears when the Heat Recovery is enabled.

Drop Leg Refrigerant Temperature

Displays the temperature of the refrigerant in the drop leg between the condenser and evaporator shells, if the sensor is present.

Sub-Cooling Temperature

Displays the difference between the Condenser Refrigerant temperature and the Drop Leg Refrigerant temperature. The Condenser Refrigerant temperature will be represented by the Condenser Saturation temperature. If the Drop Leg Sensor is not present, this temperature is not displayed.

High Pressure Switch (Open / Closed)

Displays the present position of the high pressure switch. This will indicate whether a high pressure fault is present.

2

Condenser Liquid Flow Switch

Indicates whether flow is present in the condenser.

Condenser Liquid Pump (Run / Stop)

Indicates whether condenser liquid pump is operating.

Refrigerant Level Position

Displays the present position of the refrigerant level if this function is enabled.

Refrigerant Level Setpoint

Displays the setpoint to which the refrigerant level is being controlled.

Ramp Up Time Remaining

Displays the time remaining in the period in which the Refrigerant Level Setpoint is being ramped to a Refrigerant Level Target Setpoint. This is only displayed if the Refrigerant Ramp is enabled and the value is nonzero.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

High Pressure Warning Threshold

Access Level Required: SERVICE

This value allows the user to define the condenser pressure at which the chiller will initiate a warning.

When Heat Pump Duty is set to enabled, this setpoint is automatically set to 193 psig.

Drop Leg (Enabled / Disabled)

Access Level Required: SERVICE

When a Drop Leg Refrigerant Sensor has been installed it must be enabled via this toggle before the system will utilize the new, enhanced resolution input.

Fault Acknowledge

(Software version C.MLM.01.11.xxx (and later) or C.OPT.01.11.xxx (and later))

Access Level Required: SERVICE

This allows clearing of the High Condenser Pressure Fault while Shutdown (Condenser-High Pressure Stopped).

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Refrigerant Level Control

Access Level Required: SERVICE Moves to the subscreen allowing programming of the refrigerant liquid level control setpoints.

Heat Recovery

(Software version C.OPT.01.21.307 and later) Access Level Required: SERVICE

Moves to a sub screen allowing programming and viewing of the Heat Recovery setpoints and parameters. Only appears when the Heat Recovery is enabled.

Head Pressure Control

(Software version C.OPT.01.21.307 and later) Access Level Required: SERVICE

Moves to a sub screen allowing programming and viewing of the Head Pressure Control setpoints and parameters. Only appears when Head Pressure Control is enabled and Heat Recovery is disabled.

Heat Pump

(Software version C.OPT.01.23.307 and later) Access Level Required: VIEW

Moves to a sub screen allowing programming and viewing of the Heat Pump Setpoints and parameters. Only appears when Heat Pump is enabled on the SET-UP Screen.

HEAT RECOVERY SCREEN (SOFTWARE VERSION C.OPT.01.21.307)



OVERVIEW

This screen displays all parameters related to the Heat Recovery feature. It also allows for setting of the setpoints applicable to this feature.

The Heat Recovery feature is an optional feature and if so equipped, it must be enabled on the SETUP Screen. Once enabled, this screen is accessible from the CON-DENSER Screen. If the Head Pressure Control feature is also enabled, there is no separate HEAD PRES-SURE CONTROL Screen. Rather, the Head Pressure Control parameters and setpoints appear on this screen. The screen above is shown with Heat Recovery, Hot Water Control and Head Pressure Control enabled in Analog Control Source.

Heat Recovery cannot be used simultaneously with Heat Pump Duty. When Heat Pump Duty is enabled, Heat Recovery is automatically disabled and locked.

When Heat recovery is enabled, the condenser flow animation will show flow when either the Condenser Liquid Flow Switch or the Heating Condenser Liquid Flow Switch says flow is present. When Heat Recovery is disabled, the condenser flow animation is based on the standard Condenser Flow Switch. This screen also serves as a gateway to controlling the Refrigerant Level, Heat Recovery and Head Pressure Control.

A complete explanation of the Heat Recovery feature is contained in *OptiView Control Center – Service Instructions (Form 160.54-M1).*



Requires a login access level of SERVICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

DISPLAY ONLY

Return Heating Condenser Liquid Temperature

Displays the temperature of the liquid as it enters the heating condenser tube bundle.

Leaving Heating Condenser Liquid Temperature

Displays the temperature of the liquid as it leaves the heating condenser tube bundle.

Active Hot Water Setpoint

Displays the Hot Water Setpoint to which the Leaving Heating Condenser Liquid Temperature is being controlled. Only appears when Hot Water Control is enabled.

Return Condenser Liquid Temperature

Displays the temperature of the liquid as it enters the standard condenser tube bundle.

Leaving Condenser Liquid Temperature

Displays the temperature of the liquid as it leaves the standard condenser tube bundle.

Delta P

Displays the pressure difference between the condenser and evaporator (condenser minus evaporator). This is also called the Head Pressure. Only appears when Head Pressure Control is enabled.

Head Pressure Setpoint

Displays the active Head Pressure Setpoint to which the head pressure is being controlled. Only appears when Head Pressure Control is enabled.

Heating Condenser Liquid Flow Switch (LED)

Displays the status of the flow switch in the heating condenser tube bundle. Illuminates when liquid flow is present. Otherwise, it is extinguished.

Condenser Liquid Flow Switch (LED)

Displays the status of the flow switch in the standard condenser tube bundle. Illuminates when liquid flow is present. Otherwise, it is extinguished.

PID Control Mode

Only appears when Hot Water Control is enabled. Displays the function the Control Valve is controlling. If the chiller is equipped with both Heat Recovery and Head Pressure Control and both are enabled, there is not a control valve for each feature. Rather, there is one common valve that is either performing Hot Water Control for Heat Recovery or it is performing Head Pressure Control. It will not be performing control for both features at the same time. Normally, it will be performing Hot Water Control unless certain operating conditions cause it to switch over to Head Pressure Control. When performing Hot Water Control, Hot Water is displayed. When performing Head Pressure Control, Head Pressure is displayed. There are also conditions under which it is not controlling either one, in which case Inactive is displayed. Which feature will be controlling the valve at any given time and when it is inactive is determined by operating conditions as shown in the flow chart in the Heat Recovery Section in *OptiView Control Center – Service Instructions (Form 160.54-M1).*

Control Valve Output

Displays the position command being sent to the control valve. If Hot Water Control is enabled and there is flow in the Heating Condenser, the valve is performing Heat Recovery Control. Otherwise, if Head Pressure Control is enabled, it is performing Head Pressure Control. Displayed over the range of 0.0% to 100%. The actual value of the output signal for a given error depends on whether the PID Output Setpoint is set to direct or reverse. If set to direct, the 0.0% output will be at minimum; the 100% output will be at maximum. If set to reverse, the 0.0% output will be at maximum; the 100% output will be at minimum. Only appears when Hot Water Control is enabled or Head Pressure Control is enabled.

Control Valve Control Mode

Displays whether the Control Valve is in automatic or manual control. Only appears when Hot Water Control is enabled or Head Pressure Control is enabled.

PROGRAMMABLE

Hot Water Control

(Enabled or Disabled; default Disabled) Allows the Service Technician to enable and disable the Hot Water Control for the Heat Recovery feature. When enabled, Control Valve will control the Return Condenser Liquid Temperature to achieve the Hot Water Setpoint.

Hot Water Setpoint

(65.0 to 125°F; default 95°F) Sets the temperature to which the Control Valve will control the Leaving Heating Condenser Liquid Temperature. Only appears when Hot Water Control is enabled.

Head Pressure Setpoint

(15.0 to 60 PSID; default 23.0 PSID) Sets the pressure differential to which the Control Valve will control the Head Pressure. When both Hot Water Control and Head Pressure Control are enabled, the Control Valve will normally be performing Heat Recovery (controlling to the Hot Water Setpoint). However, it will switch over to Head Pressure Control when certain operating conditions are met as shown in the flow chart in the Heat Recovery Section in *OptiView Control Center – Service Instructions (Form 160.54-M1)*. Only appears when Head Pressure Control is enabled.

Remote Input Type

(0 to 10V or 4 to 20mA; default 0 to 10V) When operating in Analog Control Source, the LTC I/O Board accepts a Remote Hot Water Setpoint offset in the form of either a 0 to 10 VDC or 4 to 20mA input to the LTC I/O Board input (TB9-3/4). This setpoint configures the LTC I/O Board input to accept the input signal type applied. Only appears when the Hot Water Control is set enabled and the Control Source Setpoint (OPERA-TIONS Screen) is set to Analog.

Control Valve Output Settings – Type

(0 to 10V or 4 to 20mA; default 0 to 10V) Sets the output signal to the Control Valve to be in the form of either 0 to 10 VDC or 4 to 20mA. Only appears when Hot Water Control is enabled or Head Pressure Control is enabled.

Control Valve Output Settings – PID Output

(Direct or Reverse) Allows the output signal to the Control Valve to be set to direct or reverse acting. When set to direct, the voltage or current signal to the Control Valve is at minimum for a 0% command and at maximum for a 100% command. When set to reverse, the voltage or current signal to the Control Valve is at maximum for a 0% command and at minimum for a 100% command. Only appears when Hot Water Control is enabled or Head Pressure Control is enabled.

Control Valve Output Settings – Set

(0.0% to 100%; default 0.0%) Allows the Control Valve to be manually set to a pre-determined position between 0.0% and 100%. Only appears when Hot Water Control is enabled or Head Pressure Control is enabled.

Control Valve Output Settings – Auto

Places the Control Valve in automatic control. Only appears when Hot Water Control is enabled or Head Pressure Control is enabled.

Change Setpoints

Use to enter the Hot Water Control and Head Pressure Control PID variables below. Pressing this key places a green box around the first changeable setpoint. Use the up/down, left/right arrows to place the selection box around the desired setpoint. With the setpoint selected, press the ENTER (\checkmark) key. A dialog box appears with the range of settings. Using the NUMERIC keys, enter desired value. Then, press the ENTER (\checkmark) key.

Hot Water Control – P

Sets the Proportional Gain of the Hot Water Control (0.00 to 5.00; default 2.00). Use the CHANGE SETPOINTS key as described above to select/enter this setpoint. Only appears when Hot Water Control is enabled.

Hot Water Control – I

Sets the Integral Gain of the Hot Water Control (0.00 to 5.00; default 2.00). Use the CHANGE SETPOINTS key as described above to select/enter this setpoint. Only appears when Hot Water Control is enabled.

Hot Water Control – D

Sets the Derivative Gain of the Hot Water Control (0.00 to 5.00; default 0.00). Use the CHANGE SETPOINTS key as described above to select/enter this setpoint. Only appears when Hot Water Control is enabled.

Head Pressure Control – P

Sets the Proportional Gain of the Head Pressure Control (0.00 to 5.00; default 2.00). Use the CHANGE SETPOINTS key as described above to select/enter this setpoint. Only appears when Head Pressure Control is enabled.

Head Pressure Control – I

Sets the Integral Gain of the Head Pressure Control (0.00 to 5.00; default 2.00). Use the CHANGE SETPOINTS key as described above to select/enter this setpoint. Only appears when Head Pressure Control is enabled.

Head Pressure Control – D

Sets the Derivative Gain of the Head Pressure Control (0.00 to 5.00; default 0.00). Use the CHANGE SETPOINTS key as described above to select/enter this setpoint. Only appears when Head Pressure Control is enabled.

NAVIGATION

Home Returns user to HOME Screen.

Condenser

Returns user to CONDENSER Screen.

HEAD PRESSURE CONTROL SCREEN (SOFTWARE VERSION C.OPT.01.21.307)



FIGURE 10 - HEAD PRESSURE CONTROL SCREEN (SOFTWARE VERSION C.OPT.01.21.307)

OVERVIEW

This screen displays all parameters related to the Head Pressure Control feature. It also allows for setting of the setpoints applicable to this feature.

If equipped with this optional feature, it must be enabled on the SETUP Screen. Once enabled, this screen is accessible from the CONDENSER Screen

Head Pressure Control cannot be used simultaneously with Heat Pump Duty. When Heat Pump Duty is enabled, Head Pressure Control is automatically disabled and locked.

The condenser water flow animation will show flow when the Condenser Liquid Flow Switch senses flow is present.

A complete explanation of the Head Pressure Control feature is contained in OptiView Control Center -Service Instructions (Form 160.54-M1).



Requires a login access level of SERVICE. Service Technicians refer to the OptiView **Control Center - Service Instructions** (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

DISPLAY ONLY

Return Condenser Liquid Temperature

Displays the temperature of the liquid as it enters the standard condenser tube bundle.

Leaving Condenser Liquid Temperature

Displays the temperature of the liquid as it leaves the standard condenser tube bundle.

Delta P

Displays the pressure difference between the condenser and evaporator (condenser minus evaporator). This is also called the Head Pressure.

Head Pressure Setpoint

Displays the active Head Pressure Setpoint to which the head pressure is being controlled.

Control Valve Output

Displays the position command being sent to the Control Valve. Displayed over the range of 0.0% to 100%. The actual value of the output signal for a given error depends on whether the PID OUTPUT Setpoint is set to direct or reverse. If set to direct, the 0.0% output will be at minimum; the 100% output will be at maximum. If set to reverse, the 0.0% output will be at maximum; the 100% output will be at minimum.

Control Valve Control Mode

Displays whether the Control Valve is in automatic or manual control.

PROGRAMMABLE

Head Pressure Setpoint

(15.0 to 60 PSID; default 23.0 PSID) Sets the pressure differential to which the Control Valve will control the Head Pressure.

Control Valve Output Settings – Type

(0-10v or 4 to 20mA; default 0-10v) Sets the output signal to the Control Valve to be in the form of either 0 to 10 VDC or 4 to 20mA.

Control Valve Output Settings – PID Output

(Direct or Reverse) Allows the output signal to the Control Valve to be set to direct or reverse acting. When set to direct, the voltage or current signal to the Control Valve is at minimum for a 0% command and at maximum for a 100% command. When set to reverse, the voltage or current signal to the Control Valve is at maximum for a 0% command and at minimum for a 100% command.

Control Valve Output Settings – Set

(0.0% to 100%; default 0.0%) Allows the Control Valve to be manually set to a pre-determined position between 0.0% and 100%.

Control Valve Output Settings – Auto

Places the Control Valve in automatic control.

Change Setpoints

Use to enter the Head Pressure Control PID variables below. Pressing this key places a green box around the first changeable setpoint. Use the up/down, left/right arrows to place the selection box around the desired setpoint. With the setpoint selected, press the ENTER (\checkmark) key. A dialog box appears with the range of settings. Using the NUMERIC keys, enter desired value. Then, press the ENTER (\checkmark) key.

Head Pressure Control – P

Sets the Proportional Gain of the Head Pressure Control (0.00 to 5.00; default 2.00). Use the CHANGE SETPOINTS key as described above to select/enter this setpoint.

Head Pressure Control – I

Sets the Integral Gain of the Head Pressure Control (0.00 to 5.00; default 2.00). Use the CHANGE SETPOINTS key as described above to select/enter this setpoint.

Head Pressure Control – D

Sets the Derivative Gain of the Head Pressure Control (0.00 to 5.00; default 0.00). Use the CHANGE SETPOINTS key as described above to select/enter this setpoint.

NAVIGATION

Home

Returns user to HOME Screen.

Condenser

Returns user to CONDENSER Screen.
HEAT PUMP SCREEN (SOFTWARE VERSION C.OPT.01.23.307 AND LATER)



FIGURE 11 - HEAT PUMP SCREEN (SOFTWARE VERSION C.OPT.01.23.307 AND LATER)

OVERVIEW

Heat Pump is an available option on certain models of YK chillers. The feature is enabled and disabled on the SETUP Screen. When enabled, this HEAT PUMP Screen is accessible from the CONDENSER Screen. The Heat Pump control can be switched between Heating mode and Cooling mode using the Operational mode setpoint on this screen. In Heating mode, the chiller controls the Leaving Condenser Liquid Temperature to its setpoint. In Cooling mode, the chiller controls the Leaving Chilled Liquid Temperature to its setpoint.

When Heat Pump is enabled, certain conditions are automatically set as follows: The Heat Recovery and Head Pressure Control options are disabled and locked. The Condenser Temperature Range Setpoint is set to Extended. The Condenser High Pressure Warning Setpoint threshold is set to 193 psig.

The Quick Start feature is only available in Cooling mode and is automatically disabled when Heating mode is selected.

If chiller is equipped with a VSD, it will operate at full speed (50 Hz or 60 Hz) at all times in Heating mode. In Cooling mode, it operates normally.

All setpoints pertinent to this feature are maintained on this screen.

DISPLAY ONLY

Leaving Condenser Liquid Temperature

Displays the temperature of the liquid as it leaves the condenser

Return Condenser Liquid Temperature

Displays the temperature of the liquid as it enters the condenser

Leaving Condenser Liquid Temperature Setpoints – Setpoint

Displays the active Leaving Condenser Liquid Temperature Setpoint to which the Heat Pump is operating, whether controlled locally or remotely, in Heating mode.

Leaving Condenser Liquid Temperature Setpoints – Remote Range

Displays the temperature range over which a remote device (in Analog or Digital Remote mode) can reset the Heat Pump Leaving Condenser Liquid Temperature Setpoint in Heating mode. See the Leaving Condenser Liquid Temperature Setpoint – Range Setpoint description below.

Leaving Condenser Liquid Temperature Setpoints – Shutdown

Displays the Leaving Condenser Liquid Temperature at which the Heat Pump will shut down on LEAVING CONDENSER LIQUID – HIGH TEMPERATURE cycling shutdown in Heating mode. See Leaving Condenser Liquid Temperature Cycling Offset – Shutdown Setpoint description below.

Leaving Condenser Liquid Temperature Setpoints – Effective Offset

Displays the actual offset being used to create the Leaving Condenser Liquid Temperature setpoints – Shutdown temperature above. See Leaving Condenser Liquid Temperature Cycling Offset – Shutdown Setpoint description below.

Leaving Condenser Liquid Temperature Setpoints – Restart

Displays the Leaving Condenser Liquid Temperature at which the Heat Pump will restart after shutting down on LEAVING CONDENSER LIQUID – HIGH TEM-PERATURE cycling shutdown in Heating mode. See Leaving Condenser Liquid Temperature Cycling Offset – Restart Setpoint description below.

Leaving Condenser Liquid Temperature Setpoints – Offset

Displays the offset being used to create the Leaving Condenser Liquid Temperature Setpoints – Restart temperature above. See Leaving Condenser Liquid Temperature Cycling Offset – Restart Setpoint description below.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Heating Sensitivity

Access Level Required: SERVICE

Allows the user to adjust the Heat Pump sensitivity of the PRV response to changes in the Leaving Condenser Liquid Temperature as its being controlled in Heating mode. It determines the magnitude of PRV movement in response to a change in Leaving Condenser Liquid Temperature. Programmable over the range of NOR- MAL, 50% (default), 30%, 10%. Normal is the standard setting and provides the longest PRV pulse for a given change. The 50%, 30% and 10% selections provide decreasing pulse durations for the same amount of change in the Leaving Condenser Liquid Temperature. The 10% selection provides the shortest pulse duration. Select smaller settings, as necessary, to prevent overshoot of the Leaving Condenser Liquid Temperature Setpoint.

Operational Mode

Access Level Required: OPERATOR

This setpoint can only be changed when the chiller is stopped and the RUN switch is in the Stop-Reset position. This setpoint sets the Heat Pump operation to either Cooling (default) or Heating operation.

Local Leaving Condenser Liquid Temperature – Setpoint

Access Level Required: OPERATOR

This allows the user to define the Local Mode Heat Pump Leaving Condenser Liquid Temperature Setpoint that is to be maintained in Heating mode. It is programmable over the range of 65.0°F to 122.0°F (default 95.0°F). A remote device can provide an analog signal (0 to 20mA, 4 to 20mA, 0 to 10 VDC, 2 to 10 VDC) in Analog Remote mode, or a PWM signal in Digital Remote mode that changes the setpoint by creating an offset below this setpoint. This offset may be defined as a maximum of 10°F, 20°F, 30°F or 40°F below the local setpoint (see Local Leaving Condenser Liquid Temperature Range description below). An E-Link or Micro Gateway card (in ISN Remote mode) can set the setpoint through a serial communications interface. In this case, the incoming setpoint is not an offset below the local setpoint. Rather, it is the setpoint value.

Leaving Condenser Liquid Temperature – Range

Access Level Required: OPERATOR

This is the range over which an analog signal (0 to 20mA, 4 to 20mA, 0 to 10 VDC or 2 to 10 VDC) in Analog Remote mode or a PWM signal (1 to 11 seconds) in Digital Remote mode, can reset the Leaving Condenser Liquid Temperature Setpoint below the operator programmed local setpoint (see above) while the Heat Pump is in Heating mode. Programmable values are 10°F, 20°F, 30°F or 40°F (default 10°F). This number is subtracted

from the local setpoint to create a range over which the remote device can reset the setpoint. For example, if this setpoint is set for 10°F and the local setpoint is 90°F, the remote device can set the Leaving Condenser Liquid Temperature Setpoint over the range of 90°F to 80°F.

Leaving Condenser Liquid Temperature Cycling Offset – Shutdown

Access Level Required: OPERATOR

This setpoint allows the user to specify the Leaving Condenser Liquid Temperature at which the Heat Pump will shutdown on LEAVING CONDENSER LIQUID – HIGH TEMPERATURE cycling shutdown in Heating mode. This is done by defining an offset above the Leaving Condenser Liquid Temperature Setpoint. The offset is programmable over the range of 1°F to 59°F (default 1°F) above the setpoint, to a maximum of 125°F. Anytime the Leaving Condenser Liquid Temperature Setpoint is decreased, this shutdown threshold becomes 125°F for the next 10 minutes. After 10 minutes, the shutdown threshold becomes the programmed setpoint offset value.

The actual offset being used is displayed as Effective Offset on this screen. Usually, the offset that is used is the same as the programmed value. However, the setpoint used can change automatically to prevent the Leaving Condenser Liquid temperature from going above the maximum allowed temperature of 125°F. For example, if the offset is set to 6°F but the Leaving Condenser Liquid Temperature Setpoint is set to 120°F, the Effective Offset used will be 5 because 6 would allow it to exceed the maximum of 125.

Leaving Condenser Liquid Temperature Cycling Offset – Restart

Access Level Required: OPERATOR

This setpoint allows the user to specify the Leaving Condenser Liquid Temperature at which the Heat Pump will restart after a shutdown on a LEAVING CONDENSER LIQUID TEMPERATURE – HIGH TEMPERATURE cycling shutdown in Heating mode. This is done by defining an offset below the Leaving Condenser Liquid Temperature Setpoint. It is programmable over a range of 0°F to 67°F (default 0°F) below the Leaving Condenser Liquid Temperature Setpoint, to a minimum of 55°F. The chiller will automatically restart when this temperature is reached. This setpoint can be used to reduce chiller cycling by delaying the Heat Pump restart until the heating load has increased.

Heating LCHLT Shutdown

Access Level Required: OPERATOR

In Heating mode, the existing LEAVING CHILLED LIQUID TEMPERATURE – LOW TEMPERATURE cycling shutdown logic will include an additional check to its existing logic that will cause a shutdown in Heating mode. This setpoint allows the user to specify the Leaving Chilled Liquid Temperature at which the Heat Pump will shut down on LEAVING CHILLED LIQUID – LOW TEMPERATURE cycling shutdown when the Heat Pump is operating in Heating mode.

The low limit for this setpoint is the higher of (Leaving Condenser Liquid Temperature Setpoint minus 71°F) or (Cooling mode Leaving Chilled Liquid Temperature Shutdown Temperature). The high limit for this setpoint is the Leaving Condenser Liquid Temperature Setpoint. The default is (Leaving Condenser Liquid Temperature Setpoint minus 60°F).

The Heat Pump will restart when the Leaving Chilled Liquid Temperature exceeds this shutdown temperature by 5°F.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen

Condenser

Access Level Required: VIEW Returns user to CONDENSER Screen

Evaporator

Access Level Required: VIEW Returns user to EVAPORATOR Screen

REFRIGERANT LEVEL CONTROL SCREEN (FLASH MEMORY CARD VERSIONS C.MLM.01.06.XXX AND EARLIER)



FIGURE 12 - REFRIGERANT LEVEL CONTROL SCREEN (FLASH MEMORY CARD VERSIONS C.MLM.01.06. XXX AND EARLIER)

OVERVIEW

This screen displays a cutaway view of the chiller condenser, along with the liquid refrigerant level sensor and the flow control valve. All setpoints relating to the liquid level control are maintained on this screen. Through animation, the variable orifice position is displayed. In addition, the refrigerant flow control valve (variable orifice) can be manually operated.



Requires a login access level of SERVICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

DISPLAY ONLY

Refrigerant Level Position

Displays the present position of the liquid level. The refrigerant level is animated in the cutaway view of the condenser. When the actual level is 0% to 15%, the level is shown about 50% full. When the actual level is 16% to 31%, the level is shown about 60% full. When

the actual level is 32% to 47%, the level is shown about 70% full. When the actual level is 48% to 63%, the level is shown about 80% full. When the actual level is 64% to 79%, the level is shown as about 90% full. Actual levels above 79%, shown as 100% full.

Refrigerant Level Control Mode

Indicates whether the liquid level control is under manual or automatic control.

Raise (LED)

Is ON when the digital output controlling the Level Raise contact is on.

Lower (LED)

Is ON when the digital output controlling the Level Lower contact is on.

PROGRAMMABLE

[Refrigerant Level] Setpoint

Displays the setpoint to which the refrigerant level is being controlled.

[Refrigerant Level Control] Period

The entire chiller run time is divided into Level Control Periods.

[Refrigerant Level Control] Proportional Limit Open

This key establishes the response to the Proportion Error. The amount of change in the level within the Proportion Error is compared to Setpoints Proportion Limit Open (if level is above setpoint).

[Refrigerant Level Control] Proportional Limit Close

This key establishes the response to the Proportion Error. The amount of change in the level within the Proportion Error is compared to Setpoints Proportion Limit Close (if level is below setpoint).

[Refrigerant Level Control] Rate Limit Open

This key establishes the response to the rate of change, the amount of change in the level within the Level Control Period is compared to the Rate Limit Open (if level greater than setpoint).

[Refrigerant Level Control] Rate Limit Close

This key establishes the response to the rate of change, the amount of change in the level within the Level Control Period is compared to the Rate Limit Close (if level less than setpoint).

[Refrigerant Level Control] Raise (Manual)

This key puts the level control into manual mode and sends a RAISE command to the variable orifice.

[Refrigerant Level Control] Lower (Manual)

This key puts the level control into manual mode and sends a LOWER command to the variable orifice.

[Refrigerant Level Control] Hold (Manual)

This key puts the level control into manual mode and sends a HOLD command to the variable orifice.

[Refrigerant Level Control] Auto

Returns the level control to automatic mode.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Condenser

Access Level Required: VIEW Returns user to CONDENSER Screen. 2

REFRIGERANT LEVEL CONTROL SCREEN

(SOFTWARE VERSION C.MLM.01.07.XXX TO C.MLM.01.10D.XXX OR C.OPT.01.10D (AND EARLIER))



C.MLM.01.10D.XXX OR C.OPT.01.10D (AND EARLIER))

OVERVIEW

This screen displays a cutaway view of the chiller condenser, along with the liquid refrigerant level sensor and variable orifice. Some setpoints relating to the liquid level control are maintained on this screen, while others are contained on a subscreen. Through animation, the variable orifice position is displayed. In addition, the refrigerant flow control valve (variable orifice) can be manually operated.



Requires a login access level of SERVICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

DISPLAY ONLY

Refrigerant Level Position

Displays the present position of the liquid level. The refrigerant level is animated in the cutaway view of the condenser. When the actual level is 0% to 15%, the

level is shown about 50% full. When the actual level is 16% to 31%, the level is shown about 60% full. When the actual level is 32% to 47%, the level is shown about 70% full. When the actual level is 48% to 63%, the level is shown about 80% full. When the actual level is 64% to 79%, the level is shown as about 90% full. Actual levels above 79%, shown as 100% full.

Refrigerant Level Control Mode

Indicates whether the liquid level control is under manual or automatic control.

Raise (LED)

Is ON when the output controlling the Level Raise contact is on.

Lower (LED)

Is ON when the output controlling the Level Lower contact is on.

PROGRAMMABLE

Valve Preset Time

Upon entering chiller prelube, the Refrigerant Level close output is energized for the length of the programmable Valve Preset Time Setpoint (0 to 100 seconds; default 50).

Ramp-up Time

This ramp limit allows the level to go from the present level to the Refrigerant Level Setpoint over a period of time programmed as the Ramp-Up Time Setpoint (3 to 15 minutes; default 8).

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Condenser

Access Level Required: VIEW Returns user to CONDENSER Screen.

Setpoints

Access Level Required: SERVICE

Moves to a subscreen allowing programming of the Refrigerant Level Control Setpoints.

REFRIGERANT LEVEL CONTROL SETPOINTS SCREEN (SOFTWARE VERSION C.MLM.01.07.XXX TO C.MLM.01.10D.XXX OR C.OPT.01.10D (AND EARLIER))



FIGURE 14 - REFRIGERANT LEVEL CONTROL SETPOINTS SCREEN (SOFTWARE VERSION C.MLM.01.07. XXX TO C.MLM.01.10D.XXX OR C.OPT.01.10D (AND EARLIER))

OVERVIEW

This screen displays a cutaway view of the chiller condenser, along with the liquid refrigerant level sensor and variable orifice. Liquid Level Control setpoints are maintained on this screen. Through animation, the variable orifice position is displayed.



Requires a login access level of SERVICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

DISPLAY ONLY

Refrigerant Level Position

Displays the present position of the liquid level. The refrigerant level is animated in the cutaway view of the condenser. When the actual level is 0% to 15%, the level is shown about 50% full. When the actual level is 16% to 31%, the level is shown about 60% full. When the actual level 32% to 47%, the level is shown about 70% full. When the actual level is 48% to 63%, the

level is shown about 80% full. When the actual level is 64% to 79%, the level is shown as about 90% full. Actual levels above 79% are shown as 100% full.

PROGRAMMABLE

[Refrigerant Level] Setpoint

Displays the setpoint to which the refrigerant level is being controlled.

[Refrigerant Level Control] Period

The entire chiller run time is divided into Level Control Periods.

[Refrigerant Level Control] Proportional Limit Open

This key establishes the response to the Proportion Error. The amount of change in the level within the Proportion Error is compared to Setpoints Proportion Limit Open (if level is above setpoint).

[Refrigerant Level Control] Proportional Limit Close

This key establishes the response to the Proportion Error. The amount of change in the level within the Proportion Error is compared to Setpoints Proportion Limit Close (if level is below setpoint).

[Refrigerant Level Control] Rate Limit Open

This key establishes the response to the rate of change, the amount of change in the level within the Level Control Period is compared to the Rate Limit Open (if level greater than setpoint).

[Refrigerant Level Control] Rate Limit Close

This key establishes the response to the rate of change, the amount of change in the level within the Level Control Period is compared to the Rate Limit Close (if level less than setpoint).

[Refrigerant Level Control] Raise (Manual)

This key puts the control into manual mode and sends a RAISE command to the variable orifice.

[Refrigerant Level Control] Lower (Manual)

This key puts the control into manual mode and sends a LOWER command to the variable orifice.

[Refrigerant Level Control] Hold (Manual)

This key puts the control into manual mode and sends a HOLD command to the variable orifice.

[Refrigerant Level Control] Auto

Returns the Level Control to automatic mode.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Refrigerant Level Control

Access Level Required: SERVICE Returns user to REFRIGERANT LEVEL CONTROL Screen.

REFRIGERANT LEVEL CONTROL SCREEN (SOFTWARE VERSIONS C.MLM.01.14.XXX AND LATER OR C.OPT.01.14.306 AND LATER)



FIGURE 15 - REFRIGERANT LEVEL CONTROL SCREEN (SOFTWARE VERSIONS C.MLM.01.14.XXX AND LATER OR C.OPT.01.14.306 AND LATER)

OVERVIEW

This screen displays a cutaway view of the chiller condenser, along with the liquid refrigerant level sensor and variable orifice. Setpoints relating to the liquid level control are maintained on this screen. Through animation, the variable orifice position is displayed. Also, the refrigerant flow control valve (variable orifice) can be manually operated.

A variable orifice is used to control the condenser refrigerant level to the Refrigerant Level Setpoint. The control thresholds are applied in two different zones, as determined by the error relationship between the actual refrigerant level and the level setpoint. Zone 1 parameters are used when the error is less than or equal to 9%. Zone 2 parameters are used when the error is greater than 9%. When transitioning from Zone 2 to Zone 1, the error must be less than or equal to 9% for 60 seconds before the Zone 1 parameters are used. If the error is greater than 9%, the Zone 2 parameters are immediately implemented.



Requires a login access level of SERVICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

DISPLAY ONLY

Refrigerant Level Position

Displays the present level of the liquid level control. The refrigerant level is animated in the cutaway view of the condenser. When the actual level is 0% to 15%, the level is shown about 50% full. When the actual level is 16% to 31%, the level is shown about 60% full. When the actual level is 32% to 47%, the level is shown about 70% full. When the actual level is 48% to 63%, the level is shown about 80% full. When the actual level is 64% to 79%, the level is shown as about 90% full. Actual levels above 79% shown as 100% full. Indicates whether the liquid level control is under manual or automatic control.

Raise (LED)

ON when the digital output controlling the raise output is ON. Otherwise, it is OFF.

Lower (LED)

ON when the digital output controlling the Lower output is ON. Otherwise, it is OFF.

Zone Control State

Displays the zone control state (Zone 1, Zone 2, Or Zone 2 To Zone 1) currently in effect for the Refrigerant Level control. Zone Control Off is displayed when the chiller is shutdown.

Zone Time Remaining

Displays the time remaining in the 60 second countdown timer when transitioning from Zone 2 to Zone 1. When transitioning from Zone 2 parameter set to Zone 1 parameter set, the Zone 1 error requirement must be met for 60 continuous seconds before Zone 1 parameters are used.

Refrigerant Level Target

After the chiller has been running for 3 minutes, if the refrigerant level is less than the level setpoint, a linearly increasing ramp (Refrigerant Level target) is applied to the level setpoint. This ramp allows the level to go from the present level to the programmed level setpoint over a period of time programmed as the Ramp Up Time.

Ramp Up Time Remaining

Displays the time remaining in the Ramp Up time countdown timer while a Refrigerant Level target ramp is in effect.

PROGRAMMABLE

Setpoint

Specifies the desired refrigerant level to be maintained in the condenser.

Valve Preset Time

Specifies the duration of pre-positioning (close) pulse during the System Prelube when starting the chiller.

Ramp Up Time

Specifies the duration of the ramp up time applied to the Refrigerant Level Target when starting the chiller while the actual refrigerant level is less than the level setpoint after a 3 minute bypass at start.

Period (Zone 1)

Specifies the control period used during Zone 1 operation.

Rate (Zone 1)

Specifies the rate limit threshold used during Zone 1 operation.

Period (Zone 2)

Specifies the control period used in Zone 2 operation.

Rate (Zone 2)

Specifies the rate limit threshold used during Zone 2 operation.

[Refrigerant Level Control] Lower (Manual)

This key puts the Level Control into manual mode and sends a LOWER (open) command to the variable orifice.

[Refrigerant Level Control] Raise (Manual)

This key puts the Level Control into manual mode and sends a RAISE (close) command to the variable orifice.

[Refrigerant Level Control] Hold (Manual)

This key puts the Level Control into manual mode and sends a HOLD command to the variable orifice.

[Refrigerant Level Control] Auto

Returns the Level Control to automatic mode.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Condenser

Access Level Required: VIEW Returns user to CONDENSER Screen.

COMPRESSOR SCREEN (ALL P COMPRESSORS AND STYLE F AND LATER CHILLERS WITH G, Q, OR H5-8 COMPRESSORS)



FIGURE 16 - COMPRESSOR SCREEN (ALL "P" COMPRESSORS AND STYLE F AND LATER CHILLERS WITH G, Q, OR H5-8 COMPRESSORS)

OVERVIEW

This screen displays a cutaway view of the chiller compressor, revealing the impeller, and shows all conditions associated with the compressor. In addition, with the proper access level, the Pre-rotation Vanes may be manually controlled. Animation of the compressor impeller indicates whether the chiller is presently in a RUN condition. This screen also serves as a gateway to subscreens for calibrating the Pre-rotation Vanes, calibrating the Proximity Probe, configuring the Hot Gas Bypass, or providing advanced control of the Compressor Motor Variable Speed Drive.



Requires a login access level of SERVICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

DISPLAY ONLY

Oil Pressure

Displays the pressure differential between the high side oil pressure transducer (compressor bearing input) and the low side oil pressure transducer (oil sump). The displayed value includes offset pressure derived from auto-zeroing during the System Prelube. If either of the transducers used to calculate this differential is out of range, the display field will show XX.X.

The offset pressure is the pressure differential between the high oil pressure (HOP) transducer and the low oil pressure (LOP) transducer outputs during a three (3) second period beginning ten (10) seconds into the System Prelube. During this time, the transducers will be sensing the same pressure and their outputs should indicate the same pressure. However, due to accuracy tolerances in transducer design, differences can exist. Therefore to compensate for differences between transducers and assure differential pressure sensing accuracy, the offset pressure is subtracted algebraically from the differential pressure. The offset pressure calculation will not be performed if either transducer is out of range. The offset value will be taken as 0 psi in this instance.

Oil Sump Temperature

Displays the temperature of the oil in the sump

Discharge Temperature

Displays the temperature of the refrigerant in its gaseous state at discharge of the compressor as it travels to the condenser.

Discharge Superheat

Displays the discharge superheat, calculated as (Discharge Temperature – Condenser Saturation temperature).

High Speed Thrust Bearing Limit Switch (LED)

Displays the present position of the High Speed Thrust Bearing Limit Switch. Extinguished when closed. This is the normal position.

Vane Motor Switch (LED)

Illuminates when the vanes are completely closed.

Oil Return Solenoid (LED)

Illuminates when the solenoid is energized.

Pre-rotation Vanes Control Mode

Access Level Required: SERVICE Indicates whether the vanes are under manual or automatic control.

[Pre-rotation Vanes] Open (LED)

Access Level Required: SERVICE

Indicates whether the vanes are in the process of opening.

[Pre-rotation Vanes] Close (LED)

Access Level Required: SERVICE Indicates whether the vanes are in the process of closing.

Pre-rotation Vanes Position (Variable Speed Drive and Hot Gas Option Only)

Access Level Required: SERVICE

This value displays the present position of the Pre-rotation Vanes as a percentage between 0 and 100%.

Full Load Amps

Access Level Required: SERVICE

Displays the motor current as a percentage of the Full Load Amps (FLA) value.

Phase A, B, C Current (Solid State Starter Only)

Access Level Required: SERVICE

Displays the 3-phase motor current values being read from the Solid State Starter.

Oil Pump Drive Command Frequency (Variable Speed Oil Pump Only)

The value displays the present frequency at which the oil pump is being commanded to run.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

[Pre-rotation Vanes] Open (Manual)

Access Level Required: SERVICE

This key puts the vane control into manual mode and sends an OPEN command to the vanes.

[Pre-rotation Vanes] Close (Manual)

Access Level Required: SERVICE This key puts the vane control into manual mode and sends a CLOSE command to the vanes.

[Pre-rotation Vanes] Hold (Manual)

Access Level Required: SERVICE

This key puts the vane control into manual mode and sends a HOLD command to the vanes.

[Pre-rotation Vanes] Auto

Access Level Required: SERVICE This key returns the vane control to automatic mode.

Fault Acknowledge

This option allows clearing of the High Speed Thrust Bearing Limit Switch safety shutdown.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Pre-rotation Vane Calibration

Access Level Required: SERVICE

Only available if the chiller is stopped and the system uses a Variable Speed Drive or Hot Gas Bypass control. Moves to the subscreen allowing calibration of the Pre-rotation Vanes.

VSD Tuning (Variable Speed Drive Only)

Access Level Required: SERVICE

Moves to the subscreen allowing advanced tuning of the Variable Speed Drive.

Hot Gas

Access Level Required: SERVICE

Moves to a subscreen that allows programming of the Hot Gas Bypass control setpoints and manual control of the Hot Gas Bypass valve. Only displayed if Hot Gas Bypass feature has been enabled on the OPERATIONS Screen.

Surge

Access Level Required: VIEW

Moves to the subscreen that allows viewing and programming of the Surge Protection feature.

COMPRESSOR SCREEN (STYLE E AND EARLIER CHILLERS WITH G, H, OR J COMPRESSORS AND STYLE G CHILLERS WITH K COMPRESSORS)



FIGURE 17 - COMPRESSOR SCREEN (STYLE E AND EARLIER CHILLERS WITH G, H, OR J COMPRESSORS AND STYLE G CHILLERS WITH K COMPRESSORS)

OVERVIEW

This screen displays a cutaway view of the chiller compressor, revealing the impeller, and shows all conditions associated with the compressor. In addition, with the proper access level, the Pre-rotation Vanes may be manually controlled. Animation of the compressor impeller indicates whether the chiller is presently in a RUN condition. This screen also serves as a gateway to subscreens for calibrating the Pre-rotation Vanes, calibrating the Proximity Probe, configuring the Hot Gas Bypass, or providing advanced control of the Compressor Motor Variable Speed Drive.

DISPLAY ONLY

Oil Pressure

Displays the pressure differential between the high side oil pressure transducer (compressor bearing input) and the low side oil pressure transducer (oil sump). The displayed value includes offset pressure derived from auto-zeroing during the System Prelube. If either of the transducers used to calculate this differential is out of range, the display field will show XX.X. The offset pressure is the pressure differential between the high oil pressure (HOP) transducer and the low oil pressure (LOP) transducer outputs during a three (3) second period beginning ten (10) seconds into the System Prelube. During this time, the transducers will be sensing the same pressure and their outputs should indicate the same pressure. However, due to accuracy tolerances in transducer design, differences can exist. Therefore to compensate for differences between transducers and assure differential pressure sensing accuracy, the offset pressure is subtracted algebraically from the differential pressure. The offset pressure calculation will not be performed if either transducer is out of range. The offset value will be taken as 0 psi in this instance.

Oil Sump Temperature

Displays the temperature of the oil in the sump.

Discharge Temperature

Displays the temperature of the refrigerant in its gaseous state at discharge of the compressor as it travels to the condenser.

Discharge Superheat (Flash Memory Card version C.MLM.01.02 or later)

Displays the discharge superheat, calculated as (Discharge Temperature – Condenser Saturation temperature).

High Speed Thrust Bearing Oil Drain Temperature

Displays the temperature of the oil in the high-speed thrust bearing drain line. Not applicable to chillers equipped with Flash Memory Card version C.MLM.01.03 and higher.

High Speed Thrust Bearing Proximity Differential

Displays the distance between the high-speed thrust collar and the tip of the Proximity Probe. This measurement takes into account the reference position established at the time of compressor manufacture.

High Speed Thrust Solenoid (LED – Style E-R22 Only)

Indicates whether the solenoid is presently energized.

Vane Motor Switch (LED)

Indicates whether the vanes are completely closed.

Oil Return Solenoid (LED)

Indicates whether the solenoid is presently energized.

Vent Line Solenoid (LED – Style E-R22)

Indicates whether the solenoid is presently energized.

Liquid Line Solenoid (LED – Style E-R22 and E-R134a J-Compressors)

Indicates whether the solenoid is presently energized.

Pre-rotation Vanes Control Mode

Access Level Required: SERVICE

Indicates whether the vanes are under manual or automatic control.

[Pre-rotation Vanes] Open (LED)

Access Level Required: SERVICE Indicates whether the vanes are in the process of opening.

[Pre-rotation Vanes] Close (LED)

Access Level Required: SERVICE Indicates whether the vanes are in the process of closing.

Pre-rotation Vanes Position (Variable Speed Drive and Hot Gas Option Only)

Access Level Required: SERVICE

This value displays the present position of the Pre-rotation Vanes as a percentage between 0 and 100%.

Full Load Amps

Access Level Required: SERVICE

Displays the motor current as a percentage of the Full Load Amps (FLA) value.

Phase A, B, C Current (Solid State Starter Only)

Access Level Required: SERVICE

Displays the 3-phase motor current values being read from the Solid State Starter.

Oil Pump Drive Command Frequency (Variable Speed Oil Pump Only)

The value displays the present frequency at which the oil pump is being commanded to run.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

[Pre-rotation Vanes] Open (Manual)

Access Level Required: SERVICE

This key puts the vane control into manual mode and sends an OPEN command to the vanes.

[Pre-rotation Vanes] Close (Manual)

Access Level Required: SERVICE

This key puts the vane control into manual mode and sends a CLOSE command to the vanes.

[Pre-rotation Vanes] Hold (Manual)

Access Level Required: SERVICE

This key puts the vane control into manual mode and sends a HOLD command to the vanes.

FORM 160.54-O1 ISSUE DATE: 06/14/2019

[Pre-rotation Vanes] Auto

Access Level Required: SERVICE This key returns the vane control to automatic mode.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Proximity Probe Calibration

Access Level Required: SERVICE

Only available if the chiller is stopped. Moves to the subscreen allowing calibration of the High Speed Thrust Bearing Proximity Probe sensor.

Pre-rotation Vane Calibration

Access Level Required: SERVICE

Only available if the chiller is stopped and the system uses a Variable Speed Drive or Hot Gas Bypass control. Moves to the subscreen allowing calibration of the Pre-rotation Vanes.

VSD Tuning (Variable Speed Drive Only)

Access Level Required: SERVICE

Moves to the subscreen allowing advanced tuning of the Variable Speed Drive.

Hot Gas

Access Level Required: SERVICE

Moves to a subscreen that allows programming of the Hot Gas Bypass control setpoints and manual control of the Hot Gas Bypass valve. Only displayed if Hot Gas Bypass feature has been enabled on the OPERATIONS Screen.

Surge (Flash Memory Card version C.MLM.01.05.xxx and later)

Access Level Required: VIEW

Moves to the subscreen that allows viewing and programming of the Surge Protection feature.

VGD

(Software version C.MLM.01.10.xxx (and later) or C.OPT.01.10.302 (and later))

Access Level Required: VIEW

Only displayed if VGD feature enabled on OPERA-TIONS Screen. Moves to the subscreen that allows viewing and programming of the Variable Geometry Diffuser (VGD) feature.

PROXIMITY PROBE CALIBRATION SCREEN (STYLE E AND EARLIER CHILLERS WITH G, H, OR J COMPRESSORS AND STYLE F AND LATER CHILLERS WITH G, H, OR J COMPRESSORS)



FIGURE 18 - PROXIMITY PROBE CALIBRATION SCREEN (STYLE E AND EARLIER CHILLERS WITH G, H, OR J COMPRESSORS AND STYLE F AND LATER CHILLERS WITH J OR H3 COMPRESSORS)

OVERVIEW

This screen displays a cutaway view of the chiller compressor, revealing the Proximity Probe sensor and provides the capability of calibrating the Proximity Probe sensor.



Requires a login access level of SERVICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

DISPLAY ONLY

High Speed Thrust Bearing Proximity Position

Displays the distance between the high-speed thrust collar and the Proximity Probe that is used to measure the position.

High Speed Thrust Bearing Proximity Reference Position

Displays the presently defined offset reference position. This value is defined at the conclusion of a calibration sequence.

Oil Pressure

Displays the pressure differential between the high side oil pressure transducer (compressor bearing input) and the low side oil pressure transducer (oil sump). The displayed value includes offset pressure derived from auto-zeroing during the System Prelube. If either of the transducers used to calculate this differential is out of range, the display field will show XX.X.

Calibration in Progress (LED)

Indicates that the calibration sequence is in progress.

Calibration Messages

These are text messages which step the user through the calibration process and indicate its success or failure.

PROGRAMMABLE

Enter Reference

Press this key to enter the reference position manually.

FORM 160.54-O1 ISSUE DATE: 06/14/2019

Start Calibration

Press this key to start the calibration.

Cancel Calibration

Press this key to cancel calibration.

Accept Calibration

Press this key to accept calibration.

Fault Acknowledge

This option is only displayed if a fault is present. Allows clearing of High Speed Thrust Bearing related shutdowns.

NAVIGATION

Home Access Level Required: VIEW Returns user to HOME Screen.

Compressor

Access Level Required: VIEW Returns user to COMPRESSOR Screen.

HOT GAS BYPASS SCREEN



FIGURE 19 - HOT GAS BYPASS SCREEN

OVERVIEW

This screen displays a cutaway view of the Hot Gas Bypass Valve. The setpoints relating to the Hot Gas Bypass Control are maintained on this screen. Related Hot Gas control parameters are displayed for reference. The Hot Gas Valve can be manually controlled from this screen. Through animation, the relative valve position is displayed. The parameters displayed on this screen vary according to the software version and the selection made for the Motor Communications Protocol Setpoint when equipped with Variable Speed Drive (VSD) or Medium Voltage Variable Speed Drive (MV VSD).

Shown above as it appears in software version C.OPT.01.19.307 and later. Earlier version variations noted below.

DISPLAY ONLY

Valve Position

Displays the present position of the Hot Gas Valve as a value between 0% (closed) to 100% (full open). By animation, the valve is shown in its relative position. The valve position is animated. When the actual position is 0% to 19%, the valve is shown fully closed. When actual position is 20% to 39%, the valve is shown 25%

open. When the actual position is 40% to 59%, the valve is shown 50% open. when actual is 60% to 79%, the valve is shown as 75% open. Positions greater than 79% are shown as full open.

Pre-rotation Vanes Position

Displays the present Pre-rotation Vanes position as a value between 0% (closed) and 100% (full open).

Delta P/P

Displays the chiller head pressure calculated as (condenser pressure – evaporator pressure/evaporator pressure).

Temperature Differential (LCHLT – Setpoint)

Displays the difference between the Leaving Chilled Liquid Temperature and the Leaving Chilled Liquid Temperature Setpoint.

Surge Avoidance Surge Count

(Displayed as Total Surge Count in software version C.OPT.01.15.307 and earlier).

This is the total number of surges accumulated by the Surge Protection feature. If equipped with a VSD or MV VSD, it is only the surges detected while the drive is running at maximum frequency.

Surge Avoidance Surge Detected (LED)

Illuminates momentarily when a surge is detected by the Surge Protection feature. If equipped with a VSD or MV VSD these are only the surges detected while the drive is running at maximum frequency.

If equipped with software version C.OPT.01.18.307 or earlier, this is displayed as Surge Detected. It illuminates momentarily when a surge is detected by the Surge Protection feature. If equipped with a VSD, it illuminates whenever a surge is detected, regardless of the VSD operating speed.

ACC Surge Detected (LED)

[Software version C.OPT.01.19.307 and later only. Only displayed if equipped with a VSD (in Modbus Protocol Configuration only) or MV VSD].

Illuminates momentarily when a surge is detected by the ACC function in the Microboard, while the drive is running at less than maximum frequency.

Hot Gas Bypass Control Mode

Indicates whether the Hot Gas Bypass is under automatic, manual or override control. When in manual control, it is controlled from this screen. When in override control, Minimum Load, VSD Override or VGD Override is displayed as appropriate. Refer to *OptiView Control Center – Service Instructions (Form 160.54-M1)* for details of these messages. Software versions C.OPT.01.18.307 and earlier display OVERRIDE for any of these conditions.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Close Percentage

(5 to 15%)

This is the incremental amount that the Hot Gas Valve will be closed at 10 minute intervals after the HOLD period has elapsed.

Hold Period

(30 to 120 minutes)

This is the period of time after no more surges are detected that the Hot Gas Valve closing will begin.

Minimum Load

(0 to 4°F)

This sets the offset below the Leaving Chilled Liquid Temperature Setpoint at which the Hot Gas Valve will be opened to the position allowed by the Maximum Open Setpoint.

Maximum Open

(25 to 100%)

The maximum allowed position for the Hot Gas Valve during a Minimum load override condition.

[Hot Gas Bypass Control] Open (Manual)

Puts the Hot Gas Bypass valve in manual control mode. Each time this key is pressed, the valve position is increased by 5%.

[Hot Gas Bypass Control] Close (Manual)

Puts the Hot Gas Bypass valve in manual control mode. Each this key is pressed, the valve position is decreased by 5%.

[Hot Gas Bypass Control] Auto

Returns the Hot Gas Bypass Control to automatic mode.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Compressor

Access Level Required: VIEW Returns user to COMPRESSOR Screen.

SURGE PROTECTION SCREEN



OVERVIEW

This screen displays a cutaway view of the chiller compressor and all parameters relating to the Surge Protection feature. All setpoints relating to this screen are maintained on this screen.

The Surge Protection feature detects surge events and provides a running count of the surges detected over the lifetime of the chiller. It allows the user to define how many surges are excessive and how the control will react to an excess surge condition. When excess surging is detected, it can be configured to shutdown the chiller, or initiate a surge avoidance mode while allowing it to continue to run or simply display a warning message. The sensitivity of this surge detection is set by the Sensitivity Setpoint on this screen. The surges detected by this feature are also used for the Hot Gas Bypass feature (See *Hot Gas Bypass Screen on page 56*).

The detection and counting of surges in this feature is completely independent of the surge detection/counting performed by the Variable Speed Drive (VSD) Adaptive Capacity Control (ACC) Surge Detection. The ACC Surge Detection creates a surge map used to control the speed of the drive. If equipped with an ACC Board (new production chillers prior to March 2007), the ACC Surge Detection is performed there. If not equipped with an ACC Board, (new production chillers after March 2007), the ACC Surge Detection is performed in the Microboard (Refer to *OptiView Control Center – Service Instructions (Form 160.54-M1)*). With all Medium Voltage Variable Speed Drives (MV VSD), the ACC Surge Detection is performed in the Microboard.

Screen shown above as it appears in software version C.OPT.01.19.307 (and later). The parameters displayed on this screen vary according to the software version and the motor starter type as noted below.

DISPLAY ONLY

Delta P/P

A parameter that represents the system differential or Head Pressure. It is calculated as (condenser pressure – evaporator pressure) / evaporator pressure.

Surge Window Time

When the chiller enters run mode, this value counts up to the time programmed as the Count Window Setpoint. When it reaches the Count Window minutes, the number of surge events in the oldest minute is discardFORM 160.54-01 ISSUE DATE: 06/14/2019

ed and the number of surge events in the most recent minute is added, thus providing a rolling count of the total surge events that have occurred in the last Count Window minutes. This value is reset when the chiller

Surge Window Count

shuts down.

Displays the number of surge events that have occurred in the last 1 to 5 minutes as programmed with the Count Window Setpoint. If the chiller has been running for less than the Count Window minutes, it is the number of surge events that have occurred within the last number of minutes displayed as the Surge Window Time. The count is cleared when the chiller shuts down.

Surge Avoidance Surge Detected (LED)

Illuminates momentarily when a surge is detected by the Surge Protection feature. If equipped with a VSD or MV VSD these are only the surges detected while the drive is running at maximum frequency.

If equipped with software version C.OPT.01.18.307 or earlier, this is displayed as Surge Detected. It illuminates momentarily when a surge is detected by the Surge Protection feature. If equipped with a VSD, it illuminates whenever a surge is detected, regardless of the VSD operating speed.

ACC Surge Detected (LED)

[Software version C.OPT.01.19.307 and later only. Only displayed if equipped with a VSD (in Modbus Protocol Configuration only) or MV VSD] Illuminates momentarily when a surge is detected by the ACC function in the Microboard, while the drive is running at less than maximum frequency.

Surge Avoidance Surge Count

(Displayed as Total Surge Count in software version C.OPT.01.15.307 and earlier)

This is the total number of surges accumulated by the Surge Protection feature. If equipped with a VSD or MV VSD, it is only the surges detected while the drive is running at maximum frequency.

Extended Run Time Remaining

Displays the time remaining in the 10-minute Extended Run period. During this period, the Pre-rotation Vanes are driven closed and WARNING - SURGE PRO-TECTION - EXCESS SURGE LIMIT is displayed. See operation under Count Limit on page 60.



For fields requiring access level of SER-VICE. Service Technicians refer to the **OptiView Control Center - Service Instruc**tions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Shutdown (Enabled/Disabled)

Access Level Required: OPERATOR

Allows the user to select whether the chiller will shutdown or continue to run when an Excess Surge situation has been detected.

If this setpoint is Enabled and the Extended Run Setpoint is Disabled, a safety shutdown is performed when the Surge Window Count exceeds the Count Limit Setpoint.

If this setpoint is Enabled and the Extended Run Setpoint is Enabled, a safety shutdown is performed if the Surge Window Count exceeds the Count Limit Setpoint at the completion of the 10 minute Extended Run period.

Surge Protection - Excess Surge is displayed with either shutdown.

If this setpoint is Disabled, see operation under Count Limit on page 60.

With software version C.MLM.01.09.xxx (and later) or C.OPT.01.09.301 (and later):

- If equipped with a compressor Variable Speed Drive (VSD), the VSD output frequency must be at maximum before the Shutdown feature is implemented or Surge Warning messages are displayed.
- If equipped with a VSD and Hot Gas Bypass (Enabled), the VSD output frequency must be at maximum and the Hot Gas Valve must be at 100% before the Shutdown feature is implemented or Surge warning messages are displayed.

Extended Run (Enabled/Disabled)

Access Level Required: OPERATOR

Allows the user to select the surge correction/avoidance Extended Run mode. This will be implemented when an Excess Surge situation is detected as follows: Anytime the Surge Window Count exceeds the Count Limit, the Pre-rotation Vanes are driven closed for the next 10 minutes. While this load inhibit is in effect, WARNING – SURGE PROTECTION – EXCESS SURGE LIMIT is displayed. When 10 minutes have elapsed, the warning message and load inhibit are automatically cleared, provided the Surge Window Count is less than or equal to the Count Limit. If the Shutdown Setpoint is Enabled, and the Surge Window Count exceeds the Count Limit at the completion of this period, a safety shutdown is performed and Surge Protection – Excess Surge is displayed.

If the Hot Gas Bypass control is Enabled, the Hot Gas Bypass Valve position must be 100% before the Extended Run mode is implemented. If the chiller is equipped with a Compressor Motor Variable Speed Drive, output frequency must be at full speed (50 Hz/60 Hz) before the Extended Run mode is implemented. If the chiller is equipped with both Hot Gas Bypass and Compressor Motor Variable Speed Drive, both of the conditions must be met before Extended Run is implemented.

Count Window

Access Level Required: OPERATOR

Allows the user to define the period of time (1 to 5 minutes; default 5; default 3 with software version C.MLM.01.09.xxx (and later) or C.OPT.01.09.301 (and later)) in which the number of surge events (Surge Window Count) are compared to the maximum allowed (Count Limit), for the purpose of detecting an Excess Surge situation.

Count Limit

Access Level Required: OPERATOR

Allows the user to define the maximum number of surge events (4 to 20; default 4 ;default 15 with software version C.MLM.01.09.xxx (and later) or C.OPT.01.09.301 (and later)) that can occur within a defined period of time before an Excess Surge situation is detected. If the Surge Window Count exceeds the Count Limit, an Excess Surge situation has occurred.

When an Excess Surge situation is detected, the action depends upon the following:

• If both the Shutdown and Extended Run Setpoints are Disabled, the chiller will continue to run, displaying the message WARNING – EXCESS SURGE DETECTED. Refer to Hot Gas Bypass and Variable Speed Drive exceptions. See *Shutdown (Enabled/Disabled) on page 59* and *Extended Run (Enabled/Disabled) on page 59*.

- If the Shutdown Setpoint is Enabled and the Extended Run Setpoint is Disabled, the chiller will perform a safety shutdown and display Surge Protection – Excess Surge. Refer to Hot Gas Bypass and Variable Speed Drive exceptions. See *Shutdown (Enabled/ Disabled) on page 59* and *Extended Run (Enabled/Disabled) on page 59*.
- If the Shutdown Setpoint is Disabled and the Extended Run Setpoint is Enabled, the Pre-rotation Vanes are driven closed for 10 minutes and WARNING – SURGE PROTECTION – EXCESS SURGE LIMIT is displayed. When the 10 minutes have elapsed, if the Surge Window Count is less than or equal to the Count Limit, this message and load inhibit are automatically cleared. Alternating with this message is WARNING – EXCESS SURGE DETECTED that continues after the 10 minute period has elapsed until manually cleared with the WARNING RESET key. Refer to Hot Gas Bypass and Variable Speed Drive exceptions. See *Shutdown (Enabled/Disabled) on page 59* and *Extended Run (Enabled/Disabled) on page 59*.
- If both the Shutdown and Extended Run Setpoint are Enabled, the 10 minute Extended Run mode is invoked as described above. However, if the Surge Window Count exceeds the Count Limit at the completion of the 10 minute Extended Run period, a safety shutdown is performed and Surge Protection – Excess Surge is displayed. Refer to Hot Gas Bypass and Variable Speed Drive exceptions. See *Shutdown (Enabled/Disabled) on page* 59 and *Extended Run (Enabled/Disabled) on* page 59.

Surge Sensitivity

Access Level Required: SERVICE

Allows the user to define the surge detection sensitivity of the Surge Protection feature. The Surge Sensitivity Setpoint on the ACC DETAILS Screen sets the sensitivity of the ACC Surge Detection feature that is employed for ACC Surge Detection when configured in MODBUS serial communications protocol. Selectable over the range of 0.3 to 1.3; default 0.3. The smaller the number, the greater the sensitivity.

Clear Surge Count

Access Level Required: ADMIN

Allows user to set the Total Surge Count to zero.

FORM 160.54-O1 ISSUE DATE: 06/14/2019

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Compressor

Access Level Required: VIEW Returns user to COMPRESSOR Screen.

VARIABLE GEOMETRY DIFFUSER SCREEN



FIGURE 21 - VARIABLE GEOMETRY DIFFUSER SCREEN

OVERVIEW

(This feature applies to software version C.MLM.01.10. xxx (and later) or C.OPT.01.10.302 (and later))

This screen displays information pertinent to the VGD operation. Also, the VGD can be manually controlled from this screen.

DISPLAY ONLY

Stall Detector Voltage

Displays the Stall Detector output voltage (x.xx VDC), as received by the Microboard.

Pre-rotation Vanes Position

Displays the position of the Pre-rotation Vanes over the range of 0% (fully closed) to 100% (fully open). Displayed as XXX until calibration procedure is performed by Service Technician.

VGD Closed Limit Switch

(Software version C.OPT.01.23.307 and later)

Displays the status of the VGD Limit Switch. Displayed as CLOSED when the switch is closed. This would be when the VGD is in the fully closed position. Otherwise, displayed as OPEN.

Diffuser Gap Close (LED)

Illuminates when a close signal is being applied to the VGD.

Diffuser Gap Open (LED)

Illuminates when an open signal is being applied to the VGD.

Surge Avoidance Surge Detected (LED)

(Software version C.OPT.01.23.307 and later)

Illuminates momentarily when a surge is detected by the Surge Protection feature. If equipped with a VSD or MV VSD, these are only the surges detected while the drive is running at maximum frequency.

If equipped with software version C.OPT.01.22.307 or earlier, this is displayed as Surge Detected. It illuminates momentarily when a surge is detected by the Surge Protection feature, regardless of the VSD operating speed.

ACC Surge Detected (LED)

(Software version C.OPT.01.23.307 and later)

Only displayed if equipped with a VSD (in Modbus Protocol Configuration) or MV VSD. Illuminates momentarily when a surge is detected by the ACC function in the Microboard, while the drive is running at less than maximum frequency.

VGD Count

Displays the number of times the Stall Detector Board output voltage goes above the High Limit Setpoint. The count can be cleared with in ADMIN access level using the VGD CYCLE COUNT key on the VGD SETPOINTS Screen.

VGD Time (__Days __Hrs __Min __Sec)

Displays the accumulated time the Stall Detector Board output voltage is greater than the High Limit Setpoint while the chiller is running.

Control Status

Displays the current state of the VGD control. The states are: Stall Waiting, Stall Reacting, Probing, Surge Reacting, Surge Waiting, Hot Gas Override.

Time Remaining

While the VGD is in the Stall Waiting State, displays the time remaining in the Probe Wait Time interval (value programmed as the Probe Wait Time setpoint).

Diffuser Gap Control Mode

Indicates whether the VGD is under manual or automatic control.

PROGRAMMABLE

[VGD] Open (Manual)

This key puts the VGD in manual mode and sends an OPEN command to the VGD.

[VGD] Close (Manual)

This key puts the VGD in manual mode and sends a CLOSE command to the VGD.

[VGD] Hold (Manual)

This key puts the VGD in manual mode and sends a HOLD command to the VGD.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Compressor

Access Level Required: VIEW Returns user to COMPRESSOR Screen.

VGD Setpoints

Access Level Required: SERVICE Move to the subscreen that allows programming of the Variable Geometry Diffuser setpoints.

VARIABLE GEOMETRY DIFFUSER SETPOINTS SCREEN



FIGURE 22 - VARIABLE GEOMETRY DIFFUSER SETPOINTS SCREEN

OVERVIEW

(This feature applies to software version C.MLM.01.10. xxx (and later) or C.OPT.01.10.302 (and later))

The Variable Geometry Diffuser setpoints are maintained on this screen. All setpoints require a login access level of Service.



Requires a login access level of SERVICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

DISPLAY ONLY

Stall Detector Voltage

Displays the Stall Detector output voltage, as received by the Microboard.

Pre-rotation Vanes Position

Displays the position of the Pre-rotation Vanes over the range of 0% (fully closed) to 100% (fully open). Displayed as XXX until calibration procedure is performed by Service Technician.

VGD Closed Limit Switch

(Software version C.OPT.01.23.307 and later)

Displays the status of the VGD Limit Switch. Displayed as CLOSED when the switch is closed. This would be when the VGD is in the fully closed position. Otherwise, displayed as OPEN.

Diffuser Gap Close (LED)

Illuminates when a close signal is being applied to the VGD.

Diffuser Gap Open (LED)

Illuminates when an open signal is being applied to the VGD.

Surge Avoidance Surge Detected (LED)

(Software version C.OPT.01.23.307 and later)

Illuminates momentarily when a surge is detected by the Surge Protection feature. If equipped with a VSD or MV VSD, these are only the surges detected while the drive is running at maximum frequency.

If equipped with software version C.OPT.01.22.307 or earlier, this is displayed as Surge Detected. It illuminates momentarily when a surge is detected by the Surge Protection feature, regardless of the VSD operating speed.

ACC Surge Detected (LED)

(Software version C.OPT.01.23.307 and later)

Only displayed if equipped with a VSD (in Modbus Protocol Configuration) or MV VSD. Illuminates momentarily when a surge is detected by the ACC function in the Microboard, while the drive is running at less than maximum frequency.

VGD Count

Displays the number of times the Stall Detector Board output voltage goes above the High Limit Setpoint. The count can be reset with an ADMIN access level using the VGD CYCLE COUNT key on the VGD SETPOINTS Screen.

VGD Time (__Days __Hrs __Min __Sec)

Displays the accumulated time the Stall Detector Board output voltage is greater than the High Limit Setpoint while the chiller is running.

Control Status

Displays the current state of the VGD control. The states are: Stall Waiting, Stall Reacting, Probing, Surge Reacting, Surge Waiting, Hot Gas Override.

Time Remaining

While the VGD is in the Stall Waiting State, displays the time remaining in the Probe Wait Time interval (value programmed as the Probe Wait Time setpoint).

PROGRAMMABLE

Surge React

(1 to 30 seconds; default 5) – Specifies the length of the close pulse applied to the VGD in response to a surge.

PRV Offset

(0 to 5%; default 3) – If the VGD control is in the Stall Waiting state and the Pre-rotation Vanes position changes by more than this value, the Probing state will be entered. If the PRV Offset is set to 0%, the Stall Waiting state is performed based only on the Probe Wait Time setpoint interval.

Probe Wait

(0.5 to 15 minutes; default 10) – Specifies how long the VGD control remains in the Stall Waiting or Surge Waiting states before entering the Probing state.

Open Pulse

(1 to 9 seconds; default 2) – Specifies the length of the open pulse applied to the VGD during 10 second periods while in the Probing state.

High Limit

(0.5 to 1.2 VDC; default 0.6 VDC; (0.8 VDC with software version C.OPT.01.22.307 or earlier) – Specifies the Stall Detector Board output voltage that represents an acceptable amount of stall noise.

The minimum difference between the High Limit Setpoint and the Low Limit Setpoint is 0.1 VDC. If a Low Limit Setpoint is entered which is less than 0.1 VDC below the High Limit Setpoint, the High Limit Setpoint is adjusted so that it is 0.1 VDC above the newly entered Low Limit value.

Low Limit

(0.4 to 0.8 VDC; default 0.5 VDC; (0.6 VDC with software version C.OPT.01.22.307 or earlier) – in the Stall Reacting State, the VGD is driven closed until the Stall Detector Board output voltage decreases to this level.

The minimum difference between the High Limit Setpoint and the Low Limit Setpoint is 0.1 VDC. If a Low Limit Setpoint is entered which is less than 0.1 VDC below the High Limit Setpoint, the High Limit Setpoint is adjusted so that it is 0.1 VDC above the newly entered Low Limit value.

VGD Count

Access Level Required: ADMIN

Allows the user to clear the VGD Cycle Count.

Extreme Stall Duration

(Software version C.MLM.01.14.xxx (and later) or C.OPT.01.14.306 (and later))

 $(10 \text{ to } 20 \text{ minutes}; \text{ default } 10) - \text{Specifies the maximum allowed time an extreme stall condition can exist before the VGD operation is disabled and driven to the full open position to protect it from damage.$

PRV VGD Inhibit

(Software version C.OPT.01.14.xxx and later)

[40% - 100% default 100% (95% with software version C.OPT.01.22.307 and earlier)] While the Pre-rotation Vanes position is greater than this setpoint, extreme stall conditions are not checked, the VGD control is inhibited and the VGD is pulsed open according to the Open Pulse Setpoint. While this is in effect, PRV Position Override is displayed as Control Status.

65

NAVIGATION

Home

Access Level Required: SERVICE Returns user to HOME Screen.

VGD Screen

Access Level Required: SERVICE Returns user to VARIABLE GEOMETRY DIFFUSER Screen.

PRE-ROTATION VANES CALIBRATION SCREEN



FIGURE 23 - PRE-ROTATION VANES CALIBRATION SCREEN

OVERVIEW

This screen displays a cutaway view of the chiller compressor, revealing the Pre-rotation Vanes and provides the capability of calibrating the Pre-rotation Vanes for either Variable Speed Drive or Hot Gas Bypass applications.



Requires a login access level of SERVICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

DISPLAY ONLY

Pre-rotation Vanes Opening (LED)

Indicates the vanes are opening.

Pre-rotation Vanes Closing (LED)

Indicates the vanes are closing.

Calibration in Progress (LED)

Indicates the calibration sequence is in progress.

Calibration Messages

These are text messages which step the user through the calibration process and indicate its success or failure.

Pre-rotation Vanes Voltage

(Software version C.OPT.01.23.307 and later)

Displays the Pre-rotation Vanes position potentiometer feedback voltage when the PRV potentiometer is connected directly to the 031-02430 Microboard. This applies to those chillers equipped with Variable Geometry Diffuser, VSD (Modbus Communications configuration) and Hot Gas Bypass

Displayed as Hot Gas PRV Voltage in software version C.OPT.01.22.307 and earlier. In these versions, the PRV Position Potentiometer feedback voltage is displayed when the Hot Gas Bypass feature is enabled.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Start Calibration

This option is hidden after calibration has started.

Cancel Calibration

This option only becomes available after calibration has started.

NAVIGATION

Home Access Level Required: VIEW Returns user to HOME Screen.

Compressor

Access Level Required: VIEW Returns user to COMPRESSOR Screen.



VSD TUNING SCREEN

FIGURE 24 - VSD TUNING SCREEN

2

OVERVIEW

This screen applies to both Variable Speed Drives (VSD) and Medium Voltage Variable Speed Drives (MV VSD). It displays a cutaway view of the chiller compressor, revealing the Pre-rotation Vanes. Animation of the Pre-rotation Vanes indicates their position. In addition, this screen allows manual control of the vanes and manual control of the Command Frequency being sent to drive.

Shown above as it appears in software version C.OPT.01.19.307 and later. Earlier version variations noted below.



Requires a login access level of SERVICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

DISPLAY ONLY

Output Frequency

Displays the frequency at which the drive is operating the motor. This value is returned from the drive.

Pre-rotation Vanes Position

Displays the present Pre-rotation Vane position as a value between 0% (closed) and 100% (full open).

Delta P/P

Displays the chiller head pressure calculated as (condenser pressure - evaporator pressure/evaporator pressure).

Temperature Differential (LCHLT – Setpoint)

Displays the difference between the Leaving Chilled Liquid Temperature and the Leaving Chilled Liquid Temperature Setpoint.

Frequency Control Mode

Displays whether the Command Frequency to the drive is derived from manual or automatic frequency control mode.

Command Frequency

(Software version C.OPT.01.19.xxx and later)

When equipped with a VSD (with the Motor Communications Protocol Setpoint set to MODBUS; ACC Board not present) or equipped with a MV VSD, this is the speed command being sent to the Drive Logic Board in either Auto or Manual Speed Control mode. When equipped with a VSD (with Motor Communications Protocol Setpoint set to YORK; ACC Board present), it is only displayed in Manual Speed Control mode and it is the speed command being sent to the ACC Board in Manual Speed Control mode.

% Full Load Amps

(Software version C.OPT.01.19.xxx and later) Displays the motor current as a percentage of chiller Full Load Amps.

Output Current – Phase A, B, C

Displays the phase current measured to the motor.

Pre-rotation Vanes Control Mode

Indicates whether the vanes are under manual or automatic control.

[Pre-rotation Vanes] Open (LED)

Illuminates when an OPEN command is being sent to the vanes.

[Pre-rotation Vanes] Close (LED)

Illuminates when a CLOSE command is being sent to the vanes.

PROGRAMMABLE

Set

Allows manual programming of the Command Frequency value. Manually programming this value will put the drive frequency control in Manual Speed Control mode and send the programmed Command Frequency to the drive.

Auto

Puts the drive frequency control in automatic control. The Pre-rotation Vanes calibration must have been successfully performed before this entry will be accepted.

In software version C.OPT.01.23.307 (and later), default is changed from Manual to Auto and a panel being booted from a cleared BRAM will come up with the mode set to Auto. Also with this software version, the ISN, through serial communications, can no longer change this setpoint.

Fixed

Puts the drive frequency control in fixed speed mode, commanding it to run at maximum frequency (50 Hz or 60 Hz).

Raise

Puts the drive frequency control into manual mode. Each time it is pressed it increases the Command Frequency to the drive by the amount defined by the MANUAL INCREMENT key. It will not raise the value above the maximum allowed (50 Hz or 60 Hz).

Lower

Puts the drive frequency control into manual mode. Each time it is pressed it lowers the Command Frequency to the drive by the amount defined by the MANUAL INCREMENT key. It will not lower the value below the minimum allowed; (30 Hz for 60 Hz units; 25 Hz for 50 Hz units).

Manual Increment

(Increment Amount - Software version C.OPT.01.18. xxx and earlier)

Defines the amount by which the manual Raise and Lower commands will change the Command Frequency to the drive in Manual Speed Control mode. With software version C.OPT.01.18.xxx and earlier, this setting also affects the AUTO speed control mode.

[Pre-rotation Vanes] Open

Puts the vane control into manual mode and sends an OPEN command to the vanes.

[Pre-rotation Vanes] Close

Puts the vanes control into manual mode and sends a CLOSE command to the vanes.

[Pre-rotation Vanes] Hold

Puts the vane control into manual control and sends a HOLD command to the vanes.

[Pre-rotation Vanes] Auto

Puts the vane control into automatic mode.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Compressor

Access Level Required: VIEW Returns user to COMPRESSOR Screen.

OIL SUMP SCREEN



FIGURE 25 - OIL SUMP SCREEN

OVERVIEW

This screen displays a close-up of the chiller oil sump and provides all the necessary setpoints for maintaining the Variable Speed Oil Pump (VSOP). In addition, this screen allows manual control of the frequency command sent to the VSOP.

DISPLAY ONLY

Oil Pressure

Displays the pressure differential between the high side oil pressure transducer (output of oil filter) and the low side oil pressure transducer (compressor housing). The displayed value includes offset pressure derived from auto-zeroing during the System Prelube. (See explanation of auto-zeroing under the *Compressor Screen on page 48*). If either of the transducers used to calculate this differential is out of range, the display field will show XX.X.

Oil Sump Temperature

Displays the temperature of the oil in the sump.

Oil – Saturated Condenser Temperature Differential

(Software version C.OPT.01.21.307 and later) (Variable Speed Oil Pump Only)

Displays the difference between the Oil Sump Temperature and the Saturated Condenser Temperature. This parameter is useful when analyzing oil heater operation since it is used in the control of the oil heater.

Sump Oil Pressure (LOP)

Displays the low side oil pressure measured at the sump.

Pump Oil Pressure (HOP)

Displays the high side oil pressure measured at the compressor bearing input.

Oil Pump Run Output (LED)

Indicates whether the oil pump is being commanded to operate.

Oil Return Solenoid (LED)

Indicates whether the solenoid is energized.

Oil Heater (LED – Variable Speed Oil Pump Only)

Indicates whether the oil heater output is energized.

Oil Seal Lubrication Time Remaining

Access Level Required: SERVICE

If a Seal Lubrication is in progress, this will display the amount of time remaining in the lubrication process.

Next Oil Seal Lubrication

Access Level Required: SERVICE

This display will show the time remaining until the next Seal Lubrication when this function is enabled.

Target / Setpoint Oil Pressure (Variable Speed Oil Pump Only)

The Variable Speed Oil Pump (VSOP), if installed, operates to control to a defined Oil Pressure value. During prelube, and for the first 15 seconds after prelube, this setpoint value is 45.0 PSID. During this time, this field will display the target value. After 15 seconds, this value will display the user-programmed setpoint Oil Pressure.

Pulldown Time Remaining (Variable Speed Oil Pump Only)

Displays the time remaining until the user-programmed Oil Pressure Setpoint is used.

Variable Speed Oil Pump Control Mode (Variable Speed Oil Pump Only)

Indicates whether the Variable Speed Oil Pump speed is under manual or automatic control.

Oil Pump Drive Command Frequency (Variable Speed Oil Pump Only)

Displays the actual speed command being sent to the VSOP. This value could be the result of automatic control based on the Oil Pressure Setpoint, or the result of a manual speed command.

Manual Oil Pump Operation Time Left

Displays the time remaining in the 10-minute Manual Oil Pump operation described below.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Standby Lube (Enabled / Disabled)

Access Level Required: SERVICE

Allows the user to enable or disable the standby lube operation. When enabled, this function causes the oil pump to operate for a period of two (2) minutes at 24hour intervals from when the oil pump was last run for at least 2 minutes.

OIL RETURN MIN

(Software version C.OPT.01.21.307 and later; P,Q,H9 compressors only)

Access Level Required: SERVICE

To avoid an OIL – LOW TEMPERATURE DIFFER-ENTIAL cycling condition from preventing a chiller start after running at low load conditions for extended periods, the Oil Return Solenoid (1SOL) is cycled closed when the oil temperature gets too low on the P, Q and H9 compressor chillers, while the chiller is running. The OIL RETURN MIN SETPOINT key appears on the OIL SUMP Screen when the Chiller Style/Compressor Type Setpoint (on the OPERATIONS Screen) is set to P, Q or H9 compressor in SERVICE access level. This setpoint is programmable over the range of 80.0°F to 110.0°F (default 95.0°F) and controls the oil return Solenoid as follows:

- When the compressor is running and the Oil Sump Temperature is less than the Oil Return Min Setpoint, close (de-energize) the Oil Return Solenoid by de-energizing K12 relay.
- When the compressor is running and Oil Sump Temperature is more than Oil Return Min plus 7°F, open (energize) the Oil Return Solenoid by energizing K12 relay.
- During coastdown, the solenoid operation is not changed from standard logic, it remains closed. During startup the operation is not changed from standard logic, it remains closed for 1 minute after System Run.

In previous software versions, the Oil Return Solenoid (1SOL) is opened 1 minute into System Run and remains open until System Coastdown.

Pressure Setpoint (Variable Speed Oil Pump Only)

Access Level Required: SERVICE

The Variable Speed Oil Pump (VSOP) operates to control to a defined Oil Pressure value. This key allows the user to define the setpoint for the VSOP control.
Control Period (Variable Speed Oil Pump Only)

Access Level Required: SERVICE

By default, the automatic VSOP control algorithm operates every 300ms. This key allows the user to specify the control period in multiples of 300ms.

Variable Speed Oil Pump Speed Control: Set

Access Level Required: SERVICE

This key allows the user to specify a fixed manual speed at which the VSOP will run.

Raise

Access Level Required: SERVICE

This key puts the VSOP control into manual mode and increments the present speed command by 0.5 Hz.

Lower

Access Level Required: SERVICE

This key puts the VSOP control into manual mode and decrements the present speed command by 0.5 Hz.

Auto

Access Level Required: SERVICE

This key returns the VSOP to automatic mode where control is based on the Oil Pressure Setpoint.

Manual Pump

Access Level Required: OPERATOR

This key puts the oil pump control in manual mode and forces it to RUN. The oil pump is limited to running for a maximum of ten (10) minutes. If a longer running time is desired, this key must be pressed again. Manual Oil Pump control is disabled (and the button hidden) during System Prelube, System Run, Proximity Probe Calibration, Seal Lubrication, and System Coastdown.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

ELECTROMECHANICAL STARTER SCREEN



FIGURE 26 - ELECTROMECHANICAL STARTER SCREEN

OVERVIEW

This screen displays all information pertaining to an Electromechanical Starter.

DISPLAY ONLY

Motor Run (LED)

Indicates whether the digital output from the controls is commanding the motor to **RUN**.

Motor Current % Full Load Amps

Displays the motor current as a percentage of the Full Load Amps (FLA) value. For the Electromechanical Starter this is the data returned by the CM-2 board.

Current Limit Setpoint

Displays the current limit value in use. This value could come from a 0 to 20mA, 4 to 20mA, 0 to 10 VDC or 2 to 10 VDC input in Analog Remote mode, PWM signal in Digital Remote mode, E-Link Gateway interface in ISN mode, or a locally programmed value.

Pulldown Demand Time Left

Displays the time remaining in the programmed pulldown period if the value is nonzero.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Local Motor Current Limit

Access Level Required: OPERATOR

Allows the user to specify the maximum allowed motor current (as a percentage of FLA). When the motor current reaches this value, the Pre-rotation Vanes will not be permitted to open further. If the motor current rises above this value, the Pre-rotation Vanes will close to reduce the current to this value.

Pulldown Demand Limit

Access Level Required: OPERATOR

Allows the user to specify the current limit value (as a percentage of FLA) to which the chiller will be limited during the specified pulldown limit time. This value will override the Motor Current Limit value during this time period. This function is used to provide energy savings following chiller start-up.

Pulldown Demand Time

Access Level Required: OPERATOR

Allows the user to set a period of time for which the pulldown demand limit will be in effect after the chiller starts.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Motor Lube

(Software version C.MLM.01.14.xxx (and later) or C.OPT.01.14.306 (and later))

Access Level Required: VIEW

Moves to the subscreen allowing operator acknowledgement of the compressor motor lubrication and viewing of the compressor motor lubrication parameters.

Motor Details

(Software version C.OPT.01.22.307 and later) Access Level Required: SERVICE

Moves to a subscreen that provides information and setpoints pertinent to the Motor Monitoring feature.

MOD A SOLID STATE STARTER SCREEN



FIGURE 27 - MOD A SOLID STATE STARTER SCREEN

OVERVIEW

This screen displays all information pertaining to the Mod A Solid State Starter.

DISPLAY ONLY

Motor Run (LED)

Indicates whether the digital output from the controls is commanding the motor to RUN.

Motor Current % Full Load Amps

Displays the motor current as a percentage of the Full Load Amps (FLA) value. For the Solid State Starter this is the data returned by the Starter Logic Board.

Current Limit Setpoint

Displays the current limit value in use. This value could come from a 0 to 20mA, 4 to 20mA, 0 to 10 VDC or 2 to 10 VDC input in Analog Remote mode, PWM signal in Digital Remote mode, E-Link Gateway interface in ISN mode, or a locally programmed value.

Pulldown Demand Time Left

Displays the time remaining in the programmed pulldown period if the value is nonzero.

Scale/Model

Display information about the Liquid Cooled Solid State Starter Rating and the maximum allowed Full Load Amps.

Voltage – Phase A, B, C

Display the 3-phase input line voltage values being read from the Solid State Starter.

Current – Phase A, B, C

Display the 3-phase motor current values being read from the Solid State Starter.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Local Motor Current Limit

Access Level Required: OPERATOR

Allows the user to specify the maximum allowed motor current (as a percentage of FLA). When the motor current reaches this value, the Pre-rotation Vanes will not be permitted to open further. If the motor current rises above this value, the Pre-rotation Vanes will close to reduce the current to this value.

Pulldown Demand Limit

Access Level Required: OPERATOR

Allows the user to specify the current limit value (as a percentage of FLA) to which the chiller will be limited during the specified pulldown limit time. This value will override the Motor Current Limit value during this time period. This function is used to provide energy savings following chiller start-up.

Pulldown Demand Time

Access Level Required: OPERATOR

Allows the user to set a period of time for which the pulldown demand limit will be in effect after the chiller starts.

Full Load Amps

Access Level Required: SERVICE

Define the maximum amps at which the motor can operate. This value is viewable when logged in under the OPERATOR or VIEW access level.

Supply Voltage Range

Access Level Required: SERVICE

Allows the user to select a specific voltage range for voltage checking. When not disabled, this line voltage range is used to determine a low line and high line voltage threshold for initiating a shutdown.

Current Unbalance Check (Enabled / Disabled)

Access Level Required: SERVICE

Allows the user to control whether the logic checks for current unbalance and initiates a shutdown as a result.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Motor Lube

(Software version C.MLM.01.14.xxx (and later) or C.OPT.01.14.306 (and later))

Access Level Required: VIEW

Moves to the subscreen allowing operator acknowledgement of the compressor motor lubrication and viewing of the compressor motor lubrication parameters.

Motor Details

(Software version C.OPT.01.22.307 and later) Access Level Required: SERVICE

Moves to a subscreen that provides information and setpoints pertinent to the Motor Monitoring feature.

MOD B SOLID STATE STARTER SCREEN



FIGURE 28 - MOD B SOLID STATE STARTER SCREEN

OVERVIEW

This screen displays all information pertaining to the Mod B Solid State Starter.

DISPLAY ONLY

Motor Run (LED)

Indicates whether the digital output from the controls is commanding the motor to RUN.

Motor Current % Full Load Amps

Displays the motor current as a percentage of the Full Load Amps (FLA) value.

Current Limit Setpoint

Displays the current limit in use. This value could come from a 0 to 20mA, 4 to 20mA, 0 to 10 VDC or 2 to 10 VDC input in Analog Remote mode, PWM signal in Digital Remote mode, E-Link Gateway interface in ISN Remote mode or a locally programmed value in Local mode.

Pulldown Demand Time Left

Displays the time remaining in the programmed pulldown period.

Input Power

Displays the kilowatts measured by the Solid State Starter.

KW Hours

Displays the cumulative amount of kilowatts used over time.

Starter Model

Displays the Solid State Starter model that is applied to the chiller. Starter Models are 7L, 14L, 26L or 33L.

Voltage – Phase A, B, C

Displays the 3-phase input line voltage measured by the Solid State Starter.

Current – Phase A, B, C

Displays the 3-phase motor current values measured by the Solid State Starter.

Temperature – Phase A, B, C

Displays the temperatures of the Silicon Controlled Rectifier assemblies.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Local Motor Current Limit

Access Level Required: OPERATOR

Allows the user to specify the maximum allowed motor current (as percentage of FLA). When the motor current reaches this value, the Pre-rotation Vanes will not be permitted to open further. If the motor rises above this value, the Pre-rotation Vanes will close to reduce the current to this value.

Pulldown Demand Limit

Access Level Required: OPERATOR

Allows the user to specify the current limit value (as a percentage of FLA) to which the chiller will be limited during the specified pulldown time. This value will override the Motor Current Limit value during this time period. This function is used to provide energy savings following chiller start.

Pulldown Demand Time

Access Level Required: OPERATOR

Allows the user to set a period of time for which the pulldown demand limit will be in effect after the chiller starts.

Full Load Amps

Access Level Required: SERVICE

Defines the maximum amps at which the motor can operate. This value is viewable when logged in at OPERATOR or VIEW access level.

Voltage Range

Access Level Required: SERVICE

Allows the user to select specific line voltage range for voltage checking. When not disabled, this line voltage range is used to determine a low line and high line voltage threshold for initiating a shutdown.

Starting Current

Access Level Required: SERVICE

Defines the maximum allowed motor starting amps. The Solid State Starter will limit the motor starting current to this value.

Open SCR (Enabled/Disabled)

Access Level Required: SERVICE

Allows the user to enable or disable the Solid State Starter Open SCR safety detection. This must never be disabled unless under advisement of the YORK Factory.

Shorted SCR (Enabled/Disabled)

(Flash Memory Card version C.MLM.01.04b or later)

Access Level Required: SERVICE

Allows the user to enable or disable the Solid State Starter Shorted SCR safety detection. This must never be disabled unless under advisement of the YORK Factory.

KWH Reset

Access Level Required: ADMIN Allows the user to reset the cumulative Kilowatt hours.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Motor Lube

(Software version C.MLM.01.14.xxx (and later) or C.OPT.01.14.306 (and later)) Access Level Required: VIEW

Moves to the subscreen allowing operator acknowledge-

ment of the compressor motor lubrication and viewing of the compressor motor lubrication parameters.

Motor Details

(Software version C.OPT.01.22.307 and later) Access Level Required: SERVICE

Moves to a subscreen that provides information and setpoints pertinent to the Motor Monitoring feature.

MEDIUM VOLTAGE SOLID STATE STARTER SCREEN



FIGURE 29 - MEDIUM VOLTAGE SOLID STATE STARTER SCREEN

OVERVIEW

This screen displays all information pertinent to the Medium Voltage Solid State Starter (MVSSS). Software version C.OPT.01.15.307 (or later) is required for MVSSS applications.

DISPLAY ONLY

Motor Run (LED)

Indicates when the OptiView Control Center is commanding the motor to run.

Motor Current % Full Load Amps

Displays the motor current as a percentage of Job Full Load Amps Setpoint.

Current Limit Setpoint

Displays the current limit in use. This value could come from a 0 to 20mA, 4 to 20mA, 0 to 10 VDC or 2 to 10 VDC input in Analog Remote mode, PWM signal in Digital Remote mode, E-Link Gateway interface in ISN Remote mode or a locally programmed value in Local mode.

Pulldown Time Left

Displays the time remaining in the programmed pulldown period.

Input Power

Displays the kilowatts measured by and transmitted from the starter.

KW Hours

Displays the cumulative kilowatt hours. The microboard calculates this value from the Input Power transmitted from the starter. When the number exceeds 9999999 KWH, the value will rollover to zero.

Voltage – Phase A, B, C

Displays the 3-phase input line voltage as measured by and transmitted from the starter.

Current – Phase A, B, C

Displays the 3-phase motor current as measured by and transmitted from the starter.

Starter Model

Displays the starter model number as transmitted from the starter.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Local Motor Current Limit

Access Level Required: OPERATOR

Allows the user to specify the maximum allowed motor current (as a percentage of FLA). When the motor current reaches this value, the Pre-rotation Vanes will not be permitted to open further. If the motor current rises above this value, the Pre-rotation Vanes close to reduce the current to this value.

Pulldown Demand Limit

Access Level Required: OPERATOR

Allows the user to specify the current limit value (as a percentage of FLA) to which the chiller will be limited during the specified pulldown time. This value will override the Motor Current Limit Setpoint during this time period. The Pre-rotation Vanes are used to limit the motor current to this value.

Pulldown Demand Time

Access Level Required: OPERATOR

Allows the user to set the period of time for which the pulldown demand limit will be in effect.

Full Load Amps

Access Level Required: SERVICE

Defines the maximum amps at which the motor can operate. This value is viewable when logged in at at OPERATOR or VIEW access level.

Starting Current

Access Level Required: SERVICE

Defines the maximum allowed motor starting amps. The starter will limit the starting current to this value.

KWH Reset

Access Level Required: SERVICE

Allows the user to reset the cumulative Kilowatt hours.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Motor Lube

Access Level Required: VIEW

Moves to a subscreen allowing operator acknowledgement of the compressor motor lubrication and viewing of the compressor motor lubrication parameters.

Motor Details

(Software version C.OPT.01.22.307 and later) Access Level Required: SERVICE

Moves to a subscreen that provides information and setpoints pertinent to the Motor Monitoring feature.

VARIABLE SPEED DRIVE SCREEN

STSTEM STATUS SYSTEM RUN STSTEM DETAILS		15 Dec	2009 10 35 AM	CONTROL SOURCE	Home
LEAVING CHILLED	LIQUID CONTROL			Service	
VARIABLE SPE	ED DRIVE (VSD) SCREEN				
Pre-Rotation	% Full Load Amps	12 %	Local Motor Cu	ırrent Limit	100 %
Vanes Position	Current Limit Setpoint	100 %			
4 % P	ulldown Demand Time Left	4 Min			
Motor Run 兽	Output Voltage	62 V	Pulldown Dem	and Limit	100 %
	Output Frequency	32.3 Hz			
	Input Power	286 KW	Bulldown Dom	and Time	O Mia
	KW Hours	6 KWH	r ana own bein		
	Phase A Ph	iase B - F	'hase C		
	Output Current O A	0 A	0 A		/SD Details
Harmonic Filt	er L1	L2	L3		
Voltage To	tal Harmonic Distortion 0.0	% 0.0 %	0.0 %		CC Details
Supply Current T	otal Demand Distortion 0.0	% 0.0 %	0.0 %		ACC Details
			, <u></u>		
	Total Supply KVA	0 KVA			iltor Dotaile
	Total Power Factor	0.00			inter Details
		inden die			
KIMU Deset	Filter 0	ptiSave	Motor		lotor Dotaile
NWH Reset	Enabled	and Antonio and	Lupe		lotor Details
V					00312\/IPa

FIGURE 30 - VARIABLE SPEED DRIVE SCREEN WITH THE HARMONIC FILTER OPTION

OVERVIEW

This screen displays information pertaining to a VSD model drive with the harmonic filter option.

DISPLAY ONLY

Motor Run (LED)

Indicates whether the digital output from the controls is commanding the motor to RUN.

Motor Current % Full Load Amps

Displays the motor current as a percentage of the Full Load Amps (FLA) value.

Current Limit Setpoint

Displays the current limit value in use. This value could come from a 0 to 20mA, 4 to 20mA, 0 to 10 VDC or 2 to 10 VDC input in Analog Remote mode, PWM signal in Digital Remote mode, E-Link Gateway interface in ISN mode, or a locally programmed value.

Pulldown Demand Time Left

Displays the time remaining in the programmed pulldown period if the value is nonzero.

Output Voltage

Displays the present output voltage to the motor.

Output Frequency

Displays the present output frequency to the motor.

Output Current – Phase A, B, C

Displays the phase current measured to the motor.

Input Power

Displays the total kilowatts measured by the VSD or Harmonic Filter, if installed.

KW Hours

Displays the cumulative amount of kilowatts used over time as the VSD motor controller operates.

Pre-rotation Vane Position

Displays the Pre-rotation Vane position as a value between 0 and 100%.

Harmonic Filter Data (Harmonic Filter installed Only) Supply kVA

Displays the supply kVA measured by the filter.

Total Power Factor

Displays the relationship between the Input Power and the Supply kVA.

Voltage Total Harmonic Distortion – (L1, L2, L3)

Displays the Total Harmonic Distortion (THD) for each of the voltage lines as calculated by the filter.

Supply Current Total Demand Distortion – (L1, L2, L3)

Displays the Total Dynamic Distortion (TDD) for each of the supply current lines as calculated by the filter.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Local Motor Current Limit

Access Level Required: OPERATOR

Allows the user to specify the maximum allowed motor current (as a percentage of FLA). When the motor current reaches this value, the Pre-rotation Vanes will not be permitted to open further. If the motor current rises above this value, the Pre-rotation Vanes will close to reduce the current to this value.

Pulldown Demand Limit

Access Level Required: OPERATOR

Allows the user to specify the current limit value (as a percentage of FLA) to which the chiller will be limited during the specified pulldown limit time. This value will override the Motor Current Limit value during this time period. This function is used to provide energy savings following chiller start-up.

Pulldown Demand Time

Access Level Required: OPERATOR

Allows the user to set a period of time for which the pulldown demand limit will be in effect after the chiller starts.

kWH Reset

Access Level Required: ADMIN

Allows the user to reset the cumulative Kilowatt hours to zero (0).

Filter Inhibit (Harmonic Filter installed Only)

Access Level Required: SERVICE

Disables the harmonic filter from filtering. All harmonic filter data is displayed and is valid. The message Warning - Harmonic Filter - Operation Inhibited appears after making this program change. This is only available when chiller is stopped.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

VSD Details

Access Level Required: VIEW

Moves to the subscreen which provides more information about the Variable Speed Drive.

ACC Details

Access Level Required: SERVICE

Moves to the subscreen which provides more information about the Adaptive Capacity Control.

Filter Details (Harmonic Filter installed Only)

Access Level Required: VIEW

Moves to the subscreen which provides more information about the Harmonic Filter.

Motor Lube

(Software version C.MLM.01.14.xxx (and later) or C.OPT.01.14.306 (and later))

Access Level Required: VIEW

Moves to the subscreen allowing operator acknowledgement of the compressor motor lubrication and viewing of the compressor motor lubrication parameters.

Motor Details

(Software version C.OPT.01.22.307 and later) Access Level Required: SERVICE

Moves to a subscreen that provides information and setpoints pertinent to the Motor Monitoring feature.

MEDIUM VOLTAGE VARIABLE SPEED DRIVE SCREEN (SOFTWARE VERSION C.OPT.01.16.XXX AND LATER)



LD14337a

FIGURE 31 - MEDIUM VOLTAGE VARIABLE SPEED DRIVE SCREEN (SOFTWARE VERSION C.OPT.01.16. XXX AND LATER)

OVERVIEW

This screen displays information pertaining to a Medium Voltage Variable Speed Drive (MV VSD). The screen shown above is as it appears in software version C.OPT.01.20.307 (and later). For details of MV VSD operation and setpoints, refer to *Medium Voltage Variable Speed Drive – Service (Form 160.00-M6).*

DISPLAY ONLY

Motor Run (LED)

Indicates whether the digital output from the controls is commanding the chiller to run.

Motor Current % Full Load Amps

Displays the motor current as a percentage of the Full Load Amps (FLA).

Current Limit Setpoint

Displays the current limit value in use. This value could come from a 0 to 20mA, 4 to 20mA, 0 to 10 VDC or 2 to 10 VDC input in Analog Remote mode, PWM signal in Digital Remote mode, E-Link Gateway interface in ISN mode or a locally programmed value.

Pulldown Demand Time Left

Displays the time remaining in the programmed pulldown period if the value is not zero.

Output Voltage

Displays the output voltage to the motor. Value is provided by the MV VSD.

Output Frequency

Displays the present output frequency to the motor. Value is provided by the MV VSD.

Input Power

Displays the total kilowatts measured by the MV VSD. Value is provided by the MV VSD.

KW Hours

Displays the cumulative amount of kilowatts used over time as the VSD motor operates. Value is calculated by the OptiView Control Center from the Input Power value provided from the MV VSD.

Pre-rotation Vanes Position

Displays the Pre-rotation Vane position as a value between 0 and 100%.

Output Current

Displays the average of the 3-phase output current to the motor. Value is provided by the MV VSD.

Input Voltage

Displays the average of the 3-phase input voltage to the MV VSD. Value is provided by the MV VSD.

VSD Cooling Fans Output (LED)

Illuminates when the VSD cooling fans are being commanded to run.

Precharge Relay Output (LED)

Illuminates when the pre-charge relay is commanded to energize.

Output Current (Phase A, B, C)

Displays the three phases of output current to the motor.

DC Bus Voltage (Phase A, B, C)

Displays the three phases of DC Bus voltage

MV VSD Model

Displays the model number as received from the MV VSD. The model number is displayed as a number representing the horsepower rating (ie; 1500HP). With software version C.OPT.01.20.307 (and later), it is derived from the Motor Rated Voltage (Modbus Address 40012) and the Programmed Drive Current (Modbus Address 40013) values received from the MV VSD according to the following table. If this results in a model that is not defined in the lookup table, the model number is displayed as INVALID and the chiller will not be allowed to run while this is displayed

TABLE 2 - VOLTAGE (V)

	MOTOR I	RATED VOL	TAGE (V)	
		2300 V	3300 V	4160 V
	500	107 A	78 A	62 A
	600	129 A	93 A	74 A
	700	157 A	110 A	87 A
	800	172 A	124 A	99 A
	900	202 A	141 A	112 A
Model in	1000	224 A	156 A	125 A
HP	1250	280 A	195 A	155 A
	1500	336 A	235 A	186 A
	1750	392 A	274 A	217 A
	2000	438 A	312 A	248 A
	2250	494 A	345 A	274 A
	2500	561 A	391 A	310 A
Max. Job/F	Rated 100% F	LA (A) (Proc	grammed Dri	ve Current)

Motor Voltage Rating

Displays the voltage rating of the MV VSD as received from the MV VSD. With software version C.OPT.01.20.307 (and later), this is the Motor Voltage Rating (Modbus Address 40012) as received from the MV VSD. Displayed as 1300V, 3300V or 4160V. If an invalid value is received, Invalid is displayed and the chiller will not be allowed to run.

Output Frequency Rating

(Software version C.OPT.01.20.307 and later)

This is the rated output frequency (Modbus Address 40033), as received from the MV VSD. This value is the maximum drive frequency (Hz) when the MV VSD receives a 100% speed command from the OptiView Control Center. If the value received is not 50 Hz or 60 Hz, INVALID is displayed. If this is the case, then the Motor Voltage Rating (above) determines the maximum frequency as follows:

MOTOR VOLTAGE RATING	OUTPUT FREQUENCY RATING
2300 or 4160V	60 Hz
3300V	50 Hz



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Local Motor Current Limit

Access Level Required: OPERATOR

Allows the user to specify the maximum allowed motor current (as a percentage of FLA). When the motor current reaches this value, the Pre-rotation Vanes will not be permitted to open further. If the motor current rises above this value, the Pre-rotation Vanes will close to reduce the current to this value.

Pulldown Demand Limit

Access Level Required: OPERATOR

Allows the user to specify the current limit value (as percentage of FLA) to which the chiller will be limited during the specified pulldown limit time. This value will override the Motor Current Limit value during this time period. This function is used to provide energy savings following chiller start-up.

Pulldown Demand Time

Access Level Required: OPERATOR

Allows the user to set a period of time for which the pulldown demand limit will be in effect after the chiller starts.

Full Load Amps

Access Level Required: SERVICE

Defines the maximum amps at which the motor can operate this value is viewable when logged in at VIEW or OPERATOR level. With software version FORM 160.54-01

C.OPT.01.20.307 (and later), the maximum programmable value of this setpoint is equal to Programmed Drive Current (Modbus Address 40013) value received from the MV VSD. In previous software versions, it was derived from a lookup table based on the Motor Rated Voltage and MV VSD Model.

KWH Reset

Access Level Required: SERVICE

Allows the user to reset the cumulative Kilowatt hours to zero.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

ACC Details

Access Level Required: SERVICE

Moves to a subscreen which provides more information about the Adaptive Capacity Control.

Motor Lube

Moves to a subscreen allowing operator acknowledgement of the compressor motor lubrication and viewing of the compressor motor lubrication parameters.

Motor Details

(Software version C.OPT.01.22.307 and later) Access Level Required: SERVICE

Moves to a subscreen that provides information and setpoints pertinent to the Motor Monitoring feature.

VARIABLE SPEED DRIVE (VSD) DETAILS SCREEN



LD09096

FIGURE 32 - VARIABLE SPEED DRIVE (VSD) DETAILS SCREEN FOR ALL TM MODELS, VSD, AND LVD WITH 3 DRIVE POWER MODULES

OVERVIEW

This screen displays more detailed information pertaining to a Variable Speed Drive (VSD). A flash memory card version C.MLM.01.08.xxx and later is required for VSD and LVD drive models.



Requires a login access level of SERVICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

DISPLAY ONLY

Motor Run (LED)

Indicates whether the digital output from the controls is commanding the motor to RUN.

Motor Current % Full Load Amps

Displays the motor current as a percentage of the Full Load Amps (FLA) value. For the Variable Speed Drive this is the data returned by the VSD Logic Board.

Current Limit Setpoint

Displays the current limit value in use. This value could come from a 0 to 20mA, 4 to 20mA, 0 to 10 VDC or 2 to 10 VDC input in Analog Remote mode, PWM signal in Digital Remote mode, E-Link Gateway interface in ISN mode, or a locally programmed value.

Pulldown Demand Time Left

Displays the time remaining in the programmed pulldown period if the value is nonzero.

Water Pump Output (LED)

Indicates whether the relay controlling the water pump output is energized.

Precharge Relay Output (LED)

Indicates whether the relay controlling the precharge output is energized.

Trigger SCR Output (LED)

Indicates whether the relay controlling the Trigger SCR Output is energized.

DC Bus Voltage

Displays the DC Bus voltage as reported by the VSD.

DC Inverter Link Current

Displays the DC Inverter link current as reported by the VSD.

Internal Ambient Temperature

Displays the ambient temperature inside the VSD cabinet as reported by the VSD.

Converter Heatsink Temperature

Displays the heatsink temperature of the converter as reported by the VSD.

Heatsink Temperature – Phase A, B, C

The term heatsink temperature is used when the TM model drive is applied. The term baseplate temperature is used when the VSD and LVD model drive is applied. A single baseplate temperature is displayed on VSD and LVD model drives where only one power module is used. Three baseplate temperatures are displayed on VSD and LVD model drives where three power modules are used.

VSD Model

Access Level Required: SERVICE

Displays the horsepower configuration of the Variable Speed Drive control.

100% Full Load Amps

Displays the Full Load Amps value as reported by the VSD.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Local Motor Current Limit

Access Level Required: OPERATOR

Allows the user to specify the maximum allowed motor current (as a percentage of FLA). When the motor current reaches this value, the Pre-rotation Vanes will not be permitted to open further. If the motor current rises above this value, the Pre-rotation Vanes will close to reduce the current to this value.

Pulldown Demand Limit

Access Level Required: OPERATOR

Allows the user to specify the current limit value (as a percentage of FLA) to which the chiller will be limited during the specified pulldown limit time. This value will override the Motor Current Limit value during this time period. This function is used to provide energy savings following chiller start-up.

Pulldown Demand Time

Access Level Required: OPERATOR

Allows the user to set a period of time for which the pulldown demand limit will be in effect after the chiller starts.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

VSD

Access Level Required: VIEW Returns user to VSD Screen.

VARIABLE SPEED DRIVE (VSD) DETAILS SCREEN



00665VIP

FIGURE 33 - VARIABLE SPEED DRIVE (VSD) DETAILS SCREEN FOR ALL VSD AND LVD WITH 1 DRIVE POWER MODULE

OVERVIEW

This screen displays more detailed information pertaining to the VSD and LVD model of drive.



Requires a login access level of SERVICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

DISPLAY ONLY

Motor Run (LED)

Indicates whether the digital output from the controls is commanding the motor to RUN.

Motor Current % Full Load Amps

Displays the motor current as a percentage of the Full Load Amps (FLA) value. For the Variable Speed Drive this is the data returned by the VSD Logic Board.

Current Limit Setpoint

Displays the current limit value in use. This value could come from a 0 to 20mA, 4 to 20mA, 0 to 10 VDC or 2 to 10 VDC input in Analog Remote mode, PWM signal in Digital Remote mode, E-Link Gateway interface in ISN mode, or a locally programmed value.

Pulldown Demand Time Left

Displays the time remaining in the programmed pulldown period if the value is nonzero.

Water Pump Output (LED)

Indicates whether the relay controlling the water pump output is energized.

Precharge Relay Output (LED)

Indicates whether the relay controlling the precharge output is energized.

Trigger SCR Output (LED)

Indicates whether the relay controlling the Trigger SCR Output is energized.

DC Bus Voltage

Displays the DC Bus voltage as reported by the VSD.

DC Inverter Link Current

Displays the DC Inverter link current as reported by the VSD.

Internal Ambient Temperature

Displays the ambient temperature inside the VSD cabinet as reported by the VSD.

Converter Heatsink Temperature

Displays the heatsink temperature of the converter as reported by the VSD.

Baseplate Temperature

The term heatsink temperature is used when the TM model drive is applied. The term baseplate temperature is used when the VSD and LVD model drive is applied. A single baseplate temperature is displayed on VSD and LVD model drives where only one power module is used. Three baseplate temperatures are displayed on VSD and LVD model drives where three power modules are used.

VSD Model

Access Level Required: SERVICE

Displays the horsepower configuration of the Variable Speed Drive control.

100% Full Load Amps

Displays the Full Load Amps value as reported by the VSD.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Local Motor Current Limit

Access Level Required: OPERATOR

Allows the user to specify the maximum allowed motor current (as a percentage of FLA). When the motor current reaches this value, the Pre-rotation Vanes will not be permitted to open further. If the motor current rises above this value, the Pre-rotation Vanes will close to reduce the current to this value.

Pulldown Demand Limit

Access Level Required: OPERATOR

Allows the user to specify the current limit value (as a percentage of FLA) to which the chiller will be limited during the specified pulldown limit time. This value will override the Motor Current Limit value during this time period. This function is used to provide energy savings following chiller start-up.

Pulldown Demand Time

Access Level Required: OPERATOR

Allows the user to set a period of time for which the pulldown demand limit will be in effect after the chiller starts.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

VSD

Access Level Required: VIEW Returns user to VSD Screen.

ADAPTIVE CAPACITY CONTROL DETAILS SCREEN (SOFTWARE VERSION C.OPT.01.18.307 AND EARLIER) (VSD AND MV VSD)



LD12572

FIGURE 34 - ADAPTIVE CAPACITY CONTROL DETAILS SCREEN (SOFTWARE VERSION C.OPT.01.18.307 AND EARLIER) (VSD AND MVVSD)

OVERVIEW

This screen displays more detailed information pertaining to a Adaptive Capacity Control (ACC).



Requires a login access level of SERVICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

DISPLAY ONLY

Motor Run (LED)

Indicates whether the digital output from the controls is commanding the motor to RUN.

Motor Current % Full Load Amps

Displays the motor current as a percentage of the Full Load Amps (FLA) value. For the Variable Speed Drive this is the data returned by the VSD.

Current Limit Setpoint

Displays the current limit value in use. This value could come from a 0 to 20mA, 4 to 20mA, 0 to 10 VDC or 2 to 10 VDC input in Analog Remote mode, PWM signal in Digital Remote mode, E-Link Gateway interface in ISN mode, or a locally programmed value.

Pulldown Demand Time Left

Displays the time remaining in the programmed pulldown period if the value is nonzero.

VSD Output Frequency

Displays the frequency at which the VSD is operating the motor.

Pre-rotation Vane Position

Displays the Pre-rotation Vane position as a value between 0 and 100%.

ACC Surge Count

The total number of surge conditions detected by the Adaptive Capacity Control. The surge events detected by the Surge Protection feature are not included in this total.

Delta P/P

The value calculated by the Condenser and Evaporator pressures as reported by the Adaptive Capacity Control.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Local Motor Current Limit

Allows the user to specify the maximum allowed motor current (as a percentage of FLA). When the motor current reaches this value, the Pre-rotation Vanes will not be permitted to open further. If the motor current rises above this value, the Pre-rotation Vanes will close to reduce the current to this value.

Pulldown Demand Limit

Allows the user to specify the current limit value (as a percentage of FLA) to which the chiller will be limited during the specified pulldown limit time. This value will override the Motor Current Limit value during this time period. This function is used to provide energy savings following chiller start-up.

Pulldown Demand Time

Allows the user to set a period of time for which the pulldown demand limit will be in effect after the chiller starts.

Surge Sensitivity

Allows the user to define the surge detection sensitivity of the ACC Surge Detection.

Surge Margin Adjust

When the ACC maps a surge point, it will begin to adjust the chiller Command Frequency and vane controls at a certain Margin from the mapped point. This programmable value allows the Service Technician to modify the Margin at which these adjustments will begin to take place.

Manual Surge Point

This key will force the ACC to map a surge detection at the present operating conditions. Mapping a point at these conditions will cause the ACC to make adjustments to the Command Frequency in the future in order to prevent the chiller from operating at the conditions mapped. **USE WITH CAUTION**.

ACC Auto Map Print (Enabled / Disabled)

The chiller monitors the ACC communications and when a surge point is mapped, a short report of system parameters is printed. When this function is active, all other printing capability is disabled.

ACC Map Report

The chiller requests the entire surge map from the ACC. As the map is received, the parameters for each point are printed.

Surge Map Clear

This key instructs the ACC to clear all of the surge points presently mapped. This key will require confirmation of its selection by entry of a special password. *USE WITH CAUTION*.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

VSD

Access Level Required: VIEW Returns user to VSD Screen.

ADAPTIVE CAPACITY CONTROL DETAILS SCREEN YORK PROTOCOL CONFIGURATION (SOFTWARE VERSION C.OPT.01.19.307 AND LATER)



FIGURE 35 - ADAPTIVE CAPACITY CONTROL DETAILS SCREEN YORK PROTOCOL CONFIGURATION (SOFTWARE VERSION C.OPT.01.19.307 AND LATER)

OVERVIEW

This screen displays detailed information pertaining to the Adaptive Capacity Control (ACC). It is shown above with the OptiView-to-VSD serial communications hardware/interface in the York Protocol Configuration (Service Technicians refer to *OptiView Control Center – Service Instructions (Form 160.54-M1)* to determine existing hardware/interface configuration). This configuration was used in new production chillers prior to March 2007. In this configuration, the microboard communicates with the VSD Logic Board via the ACC Board using YORK protocol serial communications. The ACC Board performs the ACC function. The Motor Communications Protocol Setpoint (on the SETUP Screen) is set to YORK in this configuration.



Requires a login access level of SERVICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

DISPLAY ONLY

% Full Load Amps

Displays the motor current as a percentage of chiller Full Load Amps as calculated by the microboard from current values returned from the drive Logic Board.

Current Limit Setpoint

Displays the current limit setpoint value in use. This value could come from a 0 to 20mA, 4 to 20mA, 0 to 10 VDC or 2 to 10 VDC input in Analog Remote mode, PWM input in Digital Remote mode, E-Link Gateway interface in ISN Remote mode or locally programmed value in Local mode.

Motor Run (LED)

Illuminated when the Control Center is commanding the drive to run. Otherwise, it is extinguished.

Output Frequency

Displays the frequency at which the drive is operating the motor. This value is provided by the drive Logic Board.

Pre-rotation Vanes Position

Displays the present Pre-rotation Vane position as a value between 0% (closed) and 100% (full open). This value is provided by the ACC Board.

Delta P/P

Displays chiller head pressure calculated as (condenser pressure - evaporator pressure/evaporator pressure). This value is calculated by the ACC Board.

Temperature Differential (LCHLT – Setpoint)

Displays the difference between the Leaving Chilled Liquid Temperature and the Leaving Chilled Liquid Temperature Setpoint.

Command Frequency

This is only displayed in Manual Speed Control mode and it is the speed command being sent to the ACC Board in Manual Speed Control mode.

ACC Surge Count

This count is provided by the ACC Board. Increments each time the ACC Board detects a surge, whether running at maximum or less than maximum frequency.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Surge Margin Adjust

This value determines how close the frequency reduction will be allowed to get to the surge line. It is sent to the ACC Board. Programmable over the range of 0.0 (default) to 25.0 Hz. Service Technicians should refer to *Variable Speed Drive – Service Instructions (Form 160.00-M4)* prior to adjusting this setpoint.

Auto Map Print (Enable/Disable)

When enabled, the ACC surge map values from the ACC Board are printed to a connected printer each time a surge point is mapped, as shown in *SECTION 4* - *PRINTING* of this manual.

Manual Surge Point

Allows the Service Technician to manually log the present running operating conditions into the surge map (in the ACC Board) as a valid surge point. When this key is pressed, a dialog box appears requesting a special password to proceed.

Surge Map Print

Allows the Service Technician to print the entire surge map from the ACC Board to a connected printer, as shown in *SECTION 4 - PRINTING* of this manual.

Surge Map Clear

Allows the Service Technician to clear the surge map stored in the ACC Board. When this key is pressed, a dialog box appears requesting a special password to proceed.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

VSD

Access Level Required: VIEW Returns user to VSD Screen.

ADAPTIVE CAPACITY CONTROL DETAILS SCREEN MODBUS PROTOCOL CONFIGURATION (SOFTWARE VERSION C.OPT.01.19.307 AND LATER)



LD14339

FIGURE 36 - ADAPTIVE CAPACITY CONTROL DETAILS SCREEN MODBUS PROTOCOL CONFIGURATION (SOFTWARE VERSION C.OPT.01.19.307 AND LATER)

OVERVIEW

This screen displays detailed information pertaining to the Adaptive Capacity Control (ACC). It is shown above with the OptiView-to-VSD serial communications hardware/interface in the Modbus Protocol Configuration (Service Technicians refer to OptiView Control Center - Service Instructions (Form 160.54-M1) to determine existing hardware/interface configuration). This configuration is used in new production chillers after March 2007. In this configuration, the microboard communicates directly with the VSD Logic Board using Modbus protocol serial communications. The Microboard performs the ACC function and the ACC Board is not present. The Motor Communications Protocol Setpoint (on the SETUP Screen) is set to Modbus in this configuration. Due to service parts replacement, earlier production chillers could be in the Modbus configuration. All Medium Voltage Variable Speed Drives (MV VSD) use Modbus protocol.



Requires a login access level of SERVICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

DISPLAY ONLY

% Full Load Amps

Displays the motor current as a percentage of chiller Full Load Amps as calculated by the microboard from current values returned from the drive Logic Board.

Current Limit Setpoint

Displays the current limit setpoint value in use. This value could come from a 0 to 20 mA, 4 to 20 mA, 0 to 10 VDC or 2 to 10 VDC input in Analog Remote mode, PWM input in Digital Remote mode, E-Link Gateway interface in ISN Remote mode or locally programmed value in Local mode.

Motor Run (LED)

Illuminated when the Control Center is commanding the drive to run. Otherwise, it is extinguished.

Output Frequency

Displays the frequency at which the drive is operating the motor. This value is returned from the drive Logic Board.

Pre-rotation Vanes Position

Displays the present Pre-rotation Vane position as a value between 0% (closed) and 100% (full open).

Delta P/P

Displays chiller head pressure calculated as (condenser pressure - evaporator pressure/evaporator pressure). This value is calculated by the Microboard.

Temperature Differential (LCHLT – Setpoint)

Displays the difference between the Leaving Chilled Liquid Temperature and the Leaving Chilled Liquid Temperature Setpoint.

Command Frequency

This is the speed command being sent to the Drive Logic Board in either Auto or Manual Speed Control mode.

Speed Decrease Inhibit – Surge Map Point (LED)

Illuminates when the Microboard ACC function is unable to reduce speed due to a mapped surge point. Otherwise, it is extinguished.

Mapping Inhibited (LED)

Illuminates when the Microboard ACC function is not permitted to map points or reduce speed due to unstable Leaving Chilled Liquid Temperature, manual speed control, current limit in effect (chiller FLA only) or during Soft Shutdown (software version C.OPT.01.21.307 and later). Otherwise, it is extinguished.

ACC Surge Detected (LED)

Illuminates momentarily when a surge is detected by the ACC function in the Microboard, while the drive is running at less than maximum frequency.

Surge Avoidance Surge Detected (LED)

Illuminates momentarily when a surge is detected by the Surge Protection feature. This feature only detects surges that occur while the drive is running at maximum frequency.

ACC Surge Count

Increments when a surge is detected while the drive is running at less than maximum frequency.

Surge Map Point Count

Displays the total number of data points contained in the surge map.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

VSD Start Frequency

(Software version C.OPT.01.21.307 and later) Sets the starting frequency from which the ramp-up will begin. Programmable over the following range:

- 60 Hz units 30 Hz to 60 Hz (default 45 Hz)
- 60 Hz units with Quick Restart 30 Hz to 45 Hz (default 45 Hz)
- 50 Hz units 25 Hz to 50 Hz (default 37.5 Hz)
- 50 Hz units with Quick Restart 25 Hz to 37.5 Hz (default 37.5 Hz)

ACC Mapping Enable

(Software version C.OPT.01.21.307 and later)

Sets the Delta T (Leaving Chilled Liquid Temperature - Setpoint) needed to be met to enable surge mapping and speed reduction initially on startup. Programmable over the range of 0.5°F to 4.0°F (default 1.0°F). With software version C.OPT.01.23.307 (and later), the range is 0.5°F to 20.0°F.

Surge Margin Adjust

This value determines how close the frequency reduction will be allowed to get to the surge line. Programmable over the range of 0.0 Hz (default) to 25.0 Hz. Service Technicians should refer to *Variable Speed Drive – Service Instructions (Form 160.00-M4)* prior to adjusting this setpoint.

Surge Sensitivity

Allows the Service Technician to adjust the sensitivity of the ACC Surge Detection in the Microboard (surges that occur while the drive is running at less than maximum frequency). Programmable over the range of 1.5 to 2.5 with default of 2.0. Smaller values increase the sensitivity.

Auto Map Print (Enable/Disable)

When enabled, the ACC surge map values are printed to a connected printer each time a surge point is mapped, as shown in *SECTION 4 - PRINTING* of this manual.

Manual Surge Point

Allows the Service Technician to manually log the present running operating conditions into the surge map as a valid surge point. When this key is pressed, a dialog box appears requesting a special password to proceed.

Surge Map Print

Allows the Service Technician to print the entire surge map to a connected printer, as shown in *SECTION 4 -PRINTING* of this manual.

Surge Map Clear

Allows the Service Technician to clear the surge map. When this key is pressed, a dialog box appears requesting a special password to proceed.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

VSD

Access Level Required: VIEW Returns user to VSD Screen.

Surge Map

Access Level Required: SERVICE

Causes a jump to the subscreen that displays the surge map.

SURGE MAP SCREEN - TABLE VIEW (SOFTWARE VERSION C.OPT.01.19.307 AND LATER)



FIGURE 37 - SURGE MAP SCREEN - TABLE VIEW (SOFTWARE VERSION C.OPT.01.19.307 AND LATER)

OVERVIEW

The surge map can be shown in either Table (default) or List view as selected with the MAP VIEW key. Shown above is the Table View.

In this view, a table is used to graphically represent the surge map in the view window. The X-Axis is Delta P/P, the Y-Axis is Pre-rotation Vanes position and each drive frequency point in the surge map is represented by an "X". To view the details of any mapped point, position the green box (\Box) over the desired "X" using the keypad arrow keys ($\blacktriangle \lor \checkmark \circlearrowright$). The drive Output Frequency, Pre-rotation Vanes Position and Delta P/P of the selected point is displayed at the bottom of the screen under selected. The default position for the green box is in the upper left corner of the view window. Once moved, it will remain at the last position.

The Present Operating conditions are indicated with an "*" (as shown above) and are detailed at the bottom of the screen under present. If the present condition is the same as a mapped point, the "*" will be replaced by an "O".

This screen is applicable to Variable Speed Drives (VSD) (with the Motor Communications Protocol Setpoint set to MODBUS; ACC Board is not present) and Medium Voltage Variable Speed Drives (MV VSD). It is not accessible if equipped with a VSD in YORK Motor Communications Protocol Setpoint configuration (ACC Board is present).



Requires a login access level of SERVICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

DISPLAY ONLY

Mapping Inhibited (LED)

Illuminates while the Microboard ACC function is not permitted to map points or reduce speed due to unstable Leaving Chilled Liquid Temperature, manual speed control, current limit in effect (chiller FLA only) or during Soft Shutdown (software version C.OPT.01.21.307 and later). Otherwise, it is extinguished.

ACC Surge Detected (LED)

Illuminates momentarily when a surge is detected by the ACC function in the Microboard, while the drive is running at less than maximum frequency.

Speed Decrease Inhibit – Surge Map Point (LED)

Illuminates when the Microboard ACC function is not permitted to reduce speed due to a mapped surge point. Otherwise, it is extinguished.

Temperature Differential (LCHLT – Setpoint)

(Software version C.OPT.01.23.307 and later) Displays the difference between the Leaving Chilled Liquid Temperature and the Leaving Chilled Liquid Temperature Setpoint.

Output Frequency

Selected: Displays the drive output frequency of the selected surge point.

Present: Displays the present drive output frequency.

Pre-rotation Vanes Position

Selected: Displays the PRV position of the selected surge point. Present: Displays the present PRV position.

Delta P/P

Selected: Displays the Delta P/P of the selected surge point.

Present: Displays the present Delta P/P.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Map View

Allows a Service Technician to change the view from table to list.

Manual Surge Point

Allows the Service Technician to manually log the present running conditions into the surge map as a valid surge point. When this key is pressed, a dialog bog appears requesting a special password to proceed.

Remove Surge Point

Allows the Service Technician to remove a mapped surge point. When this key is pressed, a dialog box appears requesting a special password to proceed. The surge point is selected by placing the green box over the desired point. Then the REMOVE SURGE POINT key is pressed to remove it.

NAVIGATION

Home

Access Level Required: SERVICE Returns user to HOME Screen.

VSD

Access Level Required: SERVICE Returns user to VSD Screen.

ACC Details

Access Level Required: SERVICE Returns user to ACC Screen.

SURGE MAP SCREEN - LIST VIEW (SOFTWARE VERSION C.OPT.01.19.307 AND LATER)

ST	STEM STATUS						DA	TE .	TIME .	CONTROL SOURCE		
S	STEM RU	N					1	5 Jul 2008	1 42 PM	Local	Home	
T	AVING CH	ILLED I	IQUU	о сомт	BOL					Service		-
	SURGE M	AP SCR	EEN	-		1			1 -	Joernee		
		1	1						1)		11	
	D-P/P=	0.71;	PRV	Pos=	⊙;	Freq=	46.1	Hz			VSD	
	D-P/P=	0.73;	PRV	Pos=	8;	Freq=	44.6	Hz		7		1
	D-P/P=	0.76;	PRV	Pos=	10;	Freq=	43.4	Hz		-		
	D-P/P=	0.77;	PRV	Pos=	84;	Freq=	40.5	Hz			ACC Details	R
	D-P/P=	0.76;	PRV	Pos=	100;	Freq=	40.6	Hz			ACC Details	/
	D-P/P=	0.81;	PRV	Pos=	1;	Freq=	49.4	Hz				
	D-P/P=	0.81;	PRV	Pos=	8;	Freq=	48.9	Hz				
	D-P/P=	0.82;	PRV	Pos=	12;	Freq=	43.8	Hz		58.		
	D-P/P=	0.88;	PRV	Pos=	з;	Freq=	49.7	Hz		151		
	D-P/P=	0.88;	PRV	Pos=	7;	Freq=	47.3	Hz				
	D-P/P=	0.88;	PRV	Pos=	11;	Freq=	48.2	Hz			1	
	D-P/P=	0.84;	PRV	Pos=	48;	Freq=	42.6	Hz			Page Down	
	D-P/P=	0.89;	PRV	Pos=	100;	Freq=	43.7	Hz				-
	D-P/P=	0.91;	PRV	Pos=	5;	Freq=	48.0	Hz				
	D-P/P=	0.95;	PRV	Pos=	12;	Freq=	47.3	Hz			Map View	\mathbf{N}
	D-P/P=	0.92;	PRV	Pos=	37;	Freq=	47.4	Hz			List	1
	D-P/P=	0.93;	PRV	Pos=	85;	Freq=	44.2	Hz			1	1
	D-P/P=	0.90;	PRV	Pos=	94;	Freq=	43.3	Hz				
	D-P/P=	1.01;	PRV	Pos=	4;	Freq=	55.2	Hz		()		
	D-P/P=	0.96;	PRV	Pos=	10;	Freq=	48.3	Hz		C.		
	1.2	3	and the local	1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1	51		And the second second		/			

LD13833

FIGURE 38 - SURGE MAP SCREEN - LIST VIEW (SOFTWARE VERSION C.OPT.01.19.307 AND LATER)

OVERVIEW

The surge map can be shown in either Table (default) or List view as selected with the MAP VIEW key.

Shown above is the List view. In this view, the Delta P/P, Pre-rotation Vanes position and VSD output frequency of each mapped point are listed. It is the same report that is generated when the surge map is printed to a printer. Therefore, this view cannot be selected while a print is in progress. If the SURGE MAP key is pressed on the ACC DETAILS Screen while a print is in progress, the Map View is reset to Table if it is set to List.

The PAGE UP and PAGE DOWN keypad keys are used to scroll to the previous or next list of parameters.

This screen is applicable to Variable Speed Drives (VSD) (with the Motor Communications Protocol Setpoint set to MODBUS; ACC Board is not present) and Medium Voltage Variable Speed Drives (MV VSD). It is not accessible if equipped with a VSD in YORK Motor Communications Protocol Setpoint configuration (ACC Board is present).



Requires a login access level of SERVICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Map View

Allows the Service Technician to change the view from List to Table.

Page Up

This key scrolls the contents of the view window up to the previous list of parameters. If the window cannot be scrolled up, this key will not be displayed.

Page Down

This key scrolls the contents of the view window to the next list of parameters. If the window cannot be scrolled down, this key is not displayed. FORM 160.54-O1 ISSUE DATE: 06/14/2019

NAVIGATION

Home

Returns user to HOME Screen.

VSD

Returns user to VSD Screen.

ACC Details

Returns user to ACC DETAILS Screen.

HARMONIC FILTER DETAILS SCREEN (OPTIONAL EQUIPMENT)



FIGURE 39 - HARMONIC FILTER DETAILS SCREEN (FOR ALL TM AND VSD MODELS OF DRIVES)

OVERVIEW

This screen displays more detailed information pertaining to the IEEE-519 Harmonic Filter.

DISPLAY ONLY

Motor Run (LED)

Indicates whether the digital output from the controls is commanding the motor to RUN.

Motor Current % Full Load Amps

Displays the motor current as a percentage of the Full Load Amps (FLA) value. For the Variable Speed Drive this is the data returned by the VSD Logic Board.

Current Limit Setpoint

Displays the current limit value in use. This value could come from a 0 to 20mA, 4 to 20mA, 0 to 10 VDC or 2 to 10 VDC input in Analog Remote mode, PWM signal in Digital Remote mode, E-Link Gateway interface in ISN mode, or a locally programmed value.

Pulldown Demand Time Left

Displays the time remaining in the programmed pulldown period if the value is nonzero.

Operating Mode (Run / Stop)

Indicates whether the Harmonic Filter is operating.

VSD Model

Access Level Required: SERVICE

Displays the horsepower for which the attached Harmonic Filter is configured.

DC Bus Voltage

Displays the DC Bus voltage as measured by the Harmonic Filter.

Supply Contactor (LED)

Indicates whether the output to the Supply Contactor is energized.

Precharge Contactor (LED)

Indicates whether the output to the Precharge Contactor is energized.

Phase Rotation

Displays the phase rotation detected by the Harmonic Filter (A, B, C or C, B, A)

Total Supply kVA

Displays the total supply Kilovolt-Amps measured by the Harmonic Filter.

Baseplate/Heatsink Temperature

This displays the value of the temperature for the baseplate or heatsink, depending on the model of the drive. The term heatsink is used on all of the TM models of drives. The term baseplate is used on all of the VSD models of drives.

Voltage Peak (N-L1, N-L2, N-L3)

Displays the 3-phase peak voltages as measured by the Harmonic Filter (Neutral to Line).

RMS Voltage (L1-L2, L2-L3, L3-L1)

Displays the 3-phase RMS Voltages across each line.

Voltage Total Harmonic Distortion (L1, L2, L3)

Displays the 3-phase voltage Total Harmonic Distortion (THD) measurements.

RMS Filter Current (L1, L2, L3)

Displays the 3-phase filter current values as measured by the Harmonic Filter.

Supply Current Total Demand Distortion (L1, L2, L3)

Displays the 3-phase Current Total Demand Distortion (TDD) measurements.

RMS Supply Current (L1, L2, L3)

Displays the 3-phase RMS current in each line.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Local Motor Current Limit

Access Level Required: OPERATOR

Allows the user to specify the maximum allowed motor current (as a percentage of FLA). When the motor current reaches this value, the Pre-rotation Vanes will not be permitted to open further. If the motor current rises above this value, the Pre-rotation Vanes will close to reduce the current to this value.

Pulldown Demand Limit

Access Level Required: OPERATOR

Allows the user to specify the current limit value (as a percentage of FLA) to which the chiller will be limited during the specified pulldown limit time. This value will override the Motor Current Limit value during this time period. This function is used to provide energy savings following chiller start-up.

Pulldown Demand Time

Access Level Required: OPERATOR

Allows the user to set a period of time for which the pulldown demand limit will be in effect after the chiller starts.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

VSD

Access Level Required: VIEW Returns user to VSD Screen.

MOTOR LUBRICATION SCREEN 1



OVERVIEW

(This feature applies to software version C.MLM.01.14. xxx (and later) or C.OPT.01.14.306 (and later), or Y.OPT.01.00.308 up to Y.OPT.01.00C.308.)

This feature provides an indication when the compressor motor lubrication is required. The lubrication requirement and notification is based on the operating hours since last motor lubrication. There are up to three levels of notification, each indicating an increasing level of urgency. WARNING – MOTOR BEARING LUBE SUGGESTED is displayed when the hours exceed 1000 hours. If there is no response, WARNING – MOTOR BEARING LUBE REQUIRED is displayed when the hours exceed 1200 hours. If there is still no response, a safety shutdown is performed when the hours exceed 1400 hours and Motor – Lack Of Bearing Lubrication is displayed. See *SECTION 3 - DISPLAY MESSAGES on page 161* of this manual for details of these messages.

To provide a record of when a motor lubrication is performed, the Operator enters his/her initials, name or user ID using the MOTOR LUBE ACKNOWLEDGE key. The date and time of this entry is automatically logged as the Date of Last Lubrication and Time of Last Lubrication. This also clears any motor lubrication warning or safety that is in effect and resets the operating hours since last lubrication to zero.

If equipped with software version C.OPT.01.16.XXX (or later), this lubrication notification and shutdown feature can be enabled or disabled based on the customer's preference using the AUTO LUBE and SHUT-DOWN keys.

DISPLAY ONLY

Date of Last Motor Lubrication Warning or Fault

Displays the date of the last motor lubrication warning or safety shutdown.

Date of Last Motor Lubrication

Displays the date of the last motor lubrication. This parameter is automatically recorded when the Operator enters his/her initials, name or user ID using the MO-TOR LUBE ACKNOWLEDGE key.

Time of Last Motor Lubrication

Displays the time of the last motor lubrication. This parameter is automatically recorded when the Operator enters his/her initials, name or user ID using the MO-TOR LUBE ACKNOWLEDGE key.

Operator Initials at Last Motor Lubrication

Displays the initials, name or user ID entered by the Operator when the motor lubrication is performed. Entered as a 3 to 8 character string using the MOTOR LUBE ACKNOWLEDGE key.

Operating Hours Since Last Motor Lubrication

Displays the run hours (in whole hours) accumulated since the last motor lubrication. The value is reset to zero whenever the Operating hours (on the OPERA-TIONS Screen) is reset to zero or whenever the Operator enters his/her initials, name or user ID using the MOTOR LUBE ACKNOWLEDGE key.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Motor Lube Acknowledge

Access Level Required: OPERATOR

When the motor lubrication has been performed, the Operator must acknowledge the lubrication has been performed. This is done by entering his/her initials, name or user ID as a 3 to 8 character string. The entry is displayed as the Operator Initials at Last Lubrication. The date and time of this entry is automatically logged as the Date of Last Motor Lubrication and Time of Last Motor Lubrication. This entry also resets the operating hours since last lubrication to zero.

This entry also resets the motor lubrication warning messages: WARNING – MOTOR BEARING LUBE SUGGESTED, WARNING – MOTOR BEARING LUBE REQUIRED and safety shutdown Motor – Lack Of Bearing Lubrication.

Enter your initials, name or user ID using the following procedure. The entry must be a minimum of 3 characters and a maximum of 8 characters.

- 1. At the keypad, log in at OPERATOR access level using password 9 6 7 5. If resetting the safety shutdown Motor – Lack Of Lubrication, place Compressor Switch in Stop-Reset (O) position.
- 2. Press the MOTOR LUBE ACKNOWLEDGE key on the MOTOR LUBRICATION Screen. A dialog box appears. A red box highlights the first changeable location.
- 3. Use the ▲ ▼ keys to scroll sequentially through the alphabet to enter letters or numbers. Each time the ▲ is pressed, the next higher sequential alphabet letter or number is displayed. Each time the ▼ is pressed, the next lower alphabet letter or number is displayed. When the desired letter or number is displayed, use the ► key to forward space the red box for the next entry. Use the
 ▲ key to backspace, if necessary. To write over an existing entry or to place a blank space, scroll to the beginning of the alphabet. The selection prior to the letter A is a blank space. Use the key to enter a period/decimal point. During the entry process, if it is desired to exit the dialog box and retain the previous entry, press the CANCEL (X) key.
- When all of the desired characters have been entered, press the ENTER (✓) key.

Motor Lube Date

Access Level Required: ADMIN

Allows modification of the Date of Last Motor Lubrication.

Motor Auto Lube

(Software version C.OPT.01.16.XXX and later or Y.OPT.01.00.308 up to Y.OPT.01.00C.308.)

Access Level Required: SERVICE This setpoint accommodates those chillers that are

equipped with the optional Automatic Motor Lubrication hardware that automatically lubricates the motor at regular intervals. Since chillers equipped with this hardware don't require manual lubrication, the lubrication warnings displayed at 1000, 1200 and 1400 (safety shutdown) operating hours since last lubrication are unnecessary. Therefore, when the automatic lubrication hardware is present, this setpoint must be Enabled. With this setting, no lubrication warnings or safety shutdown will occur. If Disabled, as it should be when not equipped with the automatic lubrication hardware, the motor lubrication warnings and safety shutdown will occur at the associated operating hours.

Motor Auto Lube

(This feature applies to Software version Y.OPT.01.00D.308 (and later).)

The Motor Lube setpoint accommodates those chillers that are equipped with Automatic Motor Lubrication hardware that automatically lubricates the motor. Since chillers equipped with Automatic Motor Lubrication hardware will not display lubrication warnings. When the Auto Lube Setpoint on the Setup screen is set to QLS401 the lubrication intervals are set internal to the lube system. When the P203 is installed, the OptiView[™] controls the lubrication interval as set by the service technician. The OptiView[™] will look for a time when the chiller is not running beginning at 200 hours less than the Lube Period setting. If the chiller is stopped during that period, the auto lube will be performed. If the chiller is not stopped and lubricated by the time the Operating Hours Since Last Motor Lubrication reach the Lube Period setting + 200 hours, the chiller will stop to lubricate the motor and then restart.

If the Auto Lube setpoint is NONE, as it should be when not equipped with the Automatic Motor Lubrication hardware, the motor lubrication warnings and shutdown will occur at the associated elapsed run times. With this setting, the safety shutdown can be enabled or disabled according to the customer's preference. If enabled, the safety shutdown will occur at the normal interval. If disabled, a warning will be displayed but the safety shutdown will not occur.

Shutdown

(Software version C.OPT.01.16.XXX and later) Access Level Required: SERVICE

If the Auto Lube Setpoint above is set to Disabled, the Shutdown Setpoint is used to enable or disable the safety shutdown that occurs at 1400 operating hours since last lubrication. The safety shutdown can be enabled or disabled according to the customer's preference. If enabled, the safety shutdown will occur at the normal 1400 hours. If disabled, a warning will be displayed but the safety shutdown will not occur.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Motor

Access Level Required: VIEW Returns user to MOTOR Screen.

MOTOR LUBRICATION SCREEN 2

CLING SHUTDOWN - AUTO RESTART 02 Aug 2018 4:07 PM Local Access Struct Access Struct Access Struct Ho CAL STOP Service Motor Motor 01 Jan 1997 Date of Last Motor Lubrication Warning or Fault Motor 01 Jan 2000 Date of Last Motor Lubrication Motor Motor 12:08:09 AM Time of Last Motor Lubrication Motor Lubrication 00000000 Operator Initials at Last Motor Lubrication Ohr 0 Hr Operating Hours Since Last Motor Lubrication See Motor Nameplate Motor Lubricant Type Refer to the Operations and Maintenance Manual Maintenance Manual
OI Jan 1997 Date of Last Motor Lubrication Warning or Fault Mot 01 Jan 2000 Date of Last Motor Lubrication Mot 12:08:09 AM Time of Last Motor Lubrication Motor Lubrication 00000000 Operator Initials at Last Motor Lubrication Other Comparison 0 Hr Operating Hours Since Last Motor Lubrication Motor Lubrication See Motor Nameplate Motor Lubricant Type Refer to the Operations and Maintenance Manual Motor
CAL STUP Service MOTOR LUBRICATION SCREEN Mot 01 Jan 1997 Date of Last Motor Lubrication Warning or Fault Mot 01 Jan 2000 Date of Last Motor Lubrication Motor Lubrication 12:08:09 AM Time of Last Motor Lubrication 00000000 0 Hr Operator Initials at Last Motor Lubrication Motor Lubrication See Motor Nameplate Motor Lubricant Type Meter to the Operations and Maintenance Manual
01 Jan 1997 Date of Last Motor Lubrication Warning or Fault Mot 01 Jan 2000 Date of Last Motor Lubrication 1 12:08:09 AM Time of Last Motor Lubrication 1 00000000 Operator Initials at Last Motor Lubrication 1 0 Hr Operating Hours Since Last Motor Lubrication 1 See Motor Nameplate Motor Lubricant Type Refer to the Operations and Maintenance Manual 1
01 Jan 1997 Date of Last Motor Lubrication Warning or Fault Mot 01 Jan 2000 Date of Last Motor Lubrication 12:08:09 AM Time of Last Motor Lubrication 00000000 Operator Initials at Last Motor Lubrication 0 Hr Operating Hours Since Last Motor Lubrication See Motor Nameplate Motor Lubricant Type Refer to the Operations and Maintenance Manual Motor
01 Jan 1997 Date of Last Motor Lubrication Warning or Fault 01 Jan 2000 Date of Last Motor Lubrication 12:08:09 AM Time of Last Motor Lubrication 00000000 Operator Initials at Last Motor Lubrication 0 Hr Operating Hours Since Last Motor Lubrication See Motor Nameplate Motor Lubricant Type Refer to the Operations and Maintenance Manual Motor Lubricant
01 Jan 2000 Date of Last Motor Lubrication 12:08:09 AM Time of Last Motor Lubrication 00000000 Operator Initials at Last Motor Lubrication 0 Hr Operating Hours Since Last Motor Lubrication See Motor Nameplate Motor Lubricant Type Befer to the Operations and Maintenance Manual Motor Lubricant
01 Jan 2000 Date of Last Motor Lubrication 12:08:09 AM Time of Last Motor Lubrication 00000000 Operator Initials at Last Motor Lubrication 0 Hr Operating Hours Since Last Motor Lubrication See Motor Nameplate Motor Lubricant Type Refer to the Operations and Maintenance Manual Motor Lubricant
12:08:09 AM Time of Last Motor Lubrication 00000000 Operator Initials at Last Motor Lubrication 0 Hr Operating Hours Since Last Motor Lubrication See Motor Nameplate Motor Lubricant Type Refer to the Operations and Maintenance Manual Motor Lubricant
00000000 Operator Initials at Last Motor Lubrication 0 Hr Operating Hours Since Last Motor Lubrication See Motor Nameplate Motor Lubricant Type Refer to the Operations and Maintenance Manual Motor Lubricant Annual
Operator initials at Last Motor Lubrication O Hr Operating Hours Since Last Motor Lubrication See Motor Nameplate Motor Lubricant Type Refer to the Operations and Maintenance Manual Motor Lubricant Annual
O Hr Operating Hours Since Last Motor Lubrication See Motor Nameplate Motor Lubricant Type Refer to the Operations and Maintenance Manual Motor Lubricant Manual
See Motor Nameplate Motor Lubricant Type Refer to the Operations and Maintenance Manual
Refer to the Operations and Maintenance Manual
nelet to the operations and maintenance manual
for instructions on lubricating the motor
By acknowledging the Motor Lubrication Warning
or Fault, you agree that you have lubricated the
of bearing grease per specifications for the chiller
motor.
Lube Period Shutdowns Change Lube Motor Lube
1200 Hr Enabled Type Acknowledge

FIGURE 41 - MOTOR LUBRICATION SCREEN 2

OVERVIEW

(This feature applies to software version Y.OPT.01.00D.308 and later.)

This feature provides an indication when the compressor motor lubrication is required. The lubrication requirement and notification is based on the operating hours since last motor lubrication. There are up to three levels of notification, each indicating an increasing level of urgency. WARNING - MOTOR LUBE SUGGESTED is displayed when the operating hours since the last lubrication are 200 less than the Motor Lubrication Required period. If there is no response, WARNING - MOTOR BEARING LUBE REQUIRED is displayed when the operating hours since the last lubrication exceed the Motor Bearing Lube Required period. If there is still no response, a safety shutdown (Motor - Lack of Bearing Lubrication) is performed when the operating hours since the last lubrication exceed the Motor Lube period plus 200 hours. See SEC-TION 3 - DISPLAY MESSAGES on page 161 of this manual for details of these messages.

To provide a record of when a motor lubrication is performed, the Operator enters his/her initials, name, or user ID using the MOTOR LUBE ACKNOWLEDGE key. The date and time of this entry is automatically logged as the Date of Last Lubrication and Time of Last Lubrication. This also clears any motor lubrication warning or safety that is in effect and resets the operating hours since last lubrication to zero.

This lubrication notification and shutdown feature can be enabled or disabled based on the customer's preference using the AUTO LUBE and SHUTDOWN keys.

DISPLAY ONLY

Date of Last Motor Lubrication Warning or Fault

Displays the date of the last motor lubrication warning or safety shutdown.

Date of Last Motor Lubrication

Displays the date of the last motor lubrication. This parameter is automatically recorded when the Operator enters his/her initials, name or user ID using the MO-TOR LUBE ACKNOWLEDGE key.

Time of Last Motor Lubrication

Displays the time of the last motor lubrication. This parameter is automatically recorded when the Operator enters his/her initials, name or user ID using the MO-TOR LUBE ACKNOWLEDGE key.

Operator Initials at Last Motor Lubrication

Displays the initials, name or user ID entered by the Operator when the motor lubrication is performed. Entered as a 3 to 8 character string using the MOTOR LUBE ACKNOWLEDGE key.

Operating Hours Since Last Motor Lubrication

Displays the run hours (in whole hours) accumulated since the last motor lubrication. The value is reset to zero whenever the Operating hours (on the OPERA-TIONS Screen) is reset to zero or whenever the Operator enters his/her initials, name or user ID using the MOTOR LUBE ACKNOWLEDGE key.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Lube Period

Access Level Required: SERVICE

Adjustable over the range of 750 to 15000 hours to match the motor dataplate lubrication requirement. Service password required.

Shutdowns

Access Level Required: SERVICE

If the Auto Lube Setpoint is set to Disabled, the Shutdown Setpoint is used to enable or disable the safety shutdown that occurs if the operating hours exceed the shutdown setpoint since last lubrication. The safety shutdown can be enabled or disabled according to the customer's preference. If enabled, the safety shutdown will occur at the normal operating hours. If disabled, a warning will be displayed but the safety shutdown will not occur.

Change Lube Type

Access Level Required: SERVICE

Allows the service technician to pick what lubricant type will be displayed on the control panel from four commonly used lubricants or the default "See Motor Nameplate" message if the specified lubricant is other than one of the four common ones listed.

Motor Lube Acknowledge

Access Level Required: OPERATOR

When the motor lubrication has been performed, the Operator must acknowledge the lubrication has been performed. This is done by entering his/her initials, name or user ID as a 3 to 8 character string. The entry is displayed as the Operator Initials at Last Lubrication. The date and time of this entry is automatically logged as the Date of Last Motor Lubrication and Time of Last Motor Lubrication. This entry also resets the operating hours since last lubrication to zero.

This entry also resets the motor lubrication warning messages: WARNING – MOTOR BEARING LUBE SUGGESTED, WARNING – MOTOR BEARING LUBE REQUIRED and safety shutdown Motor – Lack Of Bearing Lubrication.

Enter your initials, name or user ID using the following procedure. The entry must be a minimum of 3 characters and a maximum of 8 characters.

- 1. At the keypad, log in at OPERATOR access level using password 9 6 7 5. If resetting the safety shutdown Motor – Lack Of Lubrication, place Compressor Switch in Stop-Reset (O) position.
- 2. Press the MOTOR LUBE ACKNOWLEDGE key on the MOTOR LUBRICATION Screen. A dialog box appears. A red box highlights the first changeable location.
- 3. Use the ▲ ▼ keys to scroll sequentially through the alphabet to enter letters or numbers. Each time the ▲ is pressed, the next higher sequential alphabet letter or number is displayed. Each time the ▼ is pressed, the next lower alphabet letter or number is displayed. When the desired letter or number is displayed, use the ► key to forward space the red box for the next entry. Use the < key to backspace, if necessary. To write over an existing entry or to place a blank space, scroll to the beginning of the alphabet. The selection prior to the letter A is a blank space. Use the key to enter a period/decimal point. During the entry process, if it is desired to exit the dialog box and retain the previous entry, press the CANCEL (X) key.
- When all of the desired characters have been entered, press the ENTER (✓) key.

Motor Lube Date

Access Level Required: ADMIN Allows modification of the Date of Last Motor Lubrication.

Start Auto Lube

Access Level Required: SERVICE

This button is only displayed when automatic lubrication hardware is installed and the setpoint is set in the Setup Screen. When the Auto-Lube is enabled, no lubrication warnings or safety shutdowns will occur. Pressing this button starts the auto-lube procedure for the P203 lube system.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Motor

Access Level Required: VIEW Returns user to MOTOR Screen.

MOTOR DETAILS SCREEN (SOFTWARE VERSION C.OPT.01.22.307 AND LATER)



FIGURE 42 - MOTOR DETAILS SCREEN (SOFTWARE VERSION C.OPT.01.22.307 AND LATER)

OVERVIEW

This screen displays information pertinent to the Motor Monitoring feature. The feature consists of motor winding temperature, motor bearing temperature, motor bearing vibration and motor cooling coil leak detection. Setpoints on this screen allow any combination of these items to be enabled or disabled based on the equipment applied. The motor could be equipped with different types of sensors for this monitoring. Either RTD's or Transmitters could be applied for winding and bearing temperature monitoring. Motor cooling coil leak detection could be done with either an optical or float sensor. Setpoints on this screen allow for the enabling of the actual sensor type applied.

Vibration baseline data can be entered manually or by running an auto baseline routine that plots a baseline over a 1 hour period while the chiller is running.

This screen also serves as a gateway to a subscreen that allows programming of the winding High Temperature Warning/Safety Shutdown thresholds and bearing High Temperature and High Vibration Warning/Safety Shutdowns. Also, individual winding temperature sensors can be disabled on this screen.

DISPLAY ONLY

Motor Run (LED)

Illuminates when the OptiView Control Center is commanding the motor to run.

%Full Load Amps

Displays the motor current as a percentage of chiller Full Load Amps.

Output Frequency

Only displayed when Motor Drive Type Setpoint is set to any VSD. Displays the frequency at which the VSD is operating the motor. This value is returned from the VSD Logic Board.

Pre-rotation Vanes Position

If equipped with a Pro-rotation Vanes potentiomer, displays the present Pre-rotation Vanes position as a value between 0% (closed) and 100% (full open).

Motor Windings

Temperature

Displays the enabled Motor Winding Temperatures for phase A, B and C. The setting of the Winding Temperature Protection Setpoint affects this display as follows: When winding RTDs are enabled, there are 2 temperatures per phase displayed (otherwise, there is only 1 per phase). When set to Disabled, no temperatures are displayed and the heading, text and data boxes do not appear. Individual temperatures can be disabled using the Temperature Disable Setpoint (on the MOTOR SETPOINTS Screen). When an individual temperature is disabled, the temperature data box does not appear. Any RTD input that registers as an open RTD is considered invalid and displays as XXX.X.

Average Winding Temperature

This value is calculated as the average of all enabled and valid Motor Winding Temperatures. Any winding temperature that registers as open, out of range or disabled is not used in the calculation. When RTD's are used for winding temperature measurement, there are a maximum of 6 temperatures used to calculate the average. When transmitters are used, there are a maximum of 3 temperatures used to calculate the average. The text description and data box do not appear when the Winding Temperature Protection Setpoint is set to disabled.

Motor Cooling Coil Leak Detected (LED)

Illuminates when the enabled Motor Cooling Coil Leak Detector (see *Motor Cooling Coil Leak Protection on page 113*) indicates a leak. The LED and text description do not appear when the Motor Cooling Coil Leak Protection Setpoint is set to Disabled.

Motor Bearings

Temperature

Displays the enabled Shaft End and Opposite End motor bearing temperatures. Any RTD input that registers as an open RTD, is considered invalid and displays as XXX.X. When the Bearing Temperature Protection Setpoint is set to Disable, no temperatures are displayed and the heading, text and data boxes do not appear.

Vibration

Displays the Shaft End and Opposite End vibration values. The vibration values are not in any particular units of measure. They are relative values. The larger the number, the greater the magnitude of vibration represented. When the Motor Vibration Protection Setpoint is set to Disabled, no vibration values are displayed and the heading, text and data boxes do not appear.

Vibration Baseline

Displays the Shaft End and Opposite End vibration values established during the running of the auto baseline routine using the AUTO BASELINE key or by manual entry using the MANUAL BASELINE key. The vibration values are not in any particular units of measure. They are relative values. The larger the number, the greater the magnitude of vibration represented. These values also create the High Vibration Shutdown and High Vibration Warning thresholds as follows: (NOTE: if the calculated value exceeds the minimum and maximum limits of the Shutdown (2.0 to 30.0) or Warning (1.0 to 15.0) threshold, the threshold is set to the respective upper or lower limit)

- Shaft End High Vibration Warning Shaft End Vibration Baseline X2
- Shaft End High Vibration Warning Default Shaft End Vibration Baseline X2
- Opposite Shaft End High Vibration Warning Opposite End Vibration Baseline X2
- Opposite Shaft End High Vibration Warning Default - Opposite End Vibration Baseline X2
- Shaft End High Vibration Shutdown Shaft End Vibration Baseline X3
- Shaft End High Vibration Shutdown Default -Shaft End Vibration Baseline X3
- Opposite Shaft End High Vibration Shutdown -Opposite Shaft End Vibration Baseline X3
- Opposite Shaft End High Vibration Shutdown Default - Opposite Shaft End Vibration Baseline X3

These automatically derived values can be overridden by manually entering a threshold on the MOTOR SETPOINTS Screen using the VIBRATION SETUP key. If no baseline values are entered, by either the auto baseline routine or manual entry, the message WARN-ING – MOTOR – BEARING VIBRATION BASE-LINE NOT SET is displayed and the baseline values are set to X.X while this message is displayed. When the Motor Vibration Protection Setpoint is set to Disabled, no baseline vibration values are displayed and the heading, text and data boxes do not appear.

Auto Baseline Time Left

Only appears when the auto baseline routine is running. Displays the time remaining in the 1 hour auto baseline routine.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Winding Temperature Protection

Access Level Required: SERVICE

Enables the type of temperature sensing device being used to sense motor winding temperature. When set to any setting other than Disabled, the respective temperatures are enabled, displayed and the HIGH WIND-ING TEMPERATURE Fault and Warning will occur when the programmed thresholds for those conditions are reached. The settings are:

- DISABLED Disables the Winding Temperature feature. No winding temperatures are displayed and the heading, text and data boxes do not appear. The High Winding Temperature Fault and Warning will not occur. This setting is used when the motor is not equipped with winding temperature sensors or if is desired to disable the feature for service reasons. This is the default setting. The winding displays can be individually disabled using the Temperature Disable Setpoint (ADMIN access level) on the MOTOR SETPOINTS Screen.
- RTD Enables and displays the 6 (2 per phase) Motor Winding Temperatures, as reported by the winding RTDs, via the Motor Monitoring Board serial communications.

- TRANSMITTER Enables and displays the 3 Motor Winding Temperatures, as reported by the winding transmitters via the Motor Monitoring Board serial communications.
- VSD TRANSMITTER Enables and displays the 3 Motor Winding Temperatures, as reported by the winding transmitters via the VSD Logic Board serial communications.

Bearing Temperature Protection

Access Level Required: SERVICE

Enables the type of temperature sensing device being used to sense motor bearing temperature. When set to any setting other than Disabled, the respective temperatures are enabled, displayed and the HIGH BEARING TEMPERATURE Fault and Warning will occur when the programmed thresholds for those conditions are reached. The settings are:

- DISABLED Disables the Bearing Temperature feature. No bearing temperatures are displayed and the heading, text and data boxes do not appear. The High Bearing Temperature Fault and Warning will not occur. This setting is when if the motor is not equipped with bearing temperature sensors or if is desired to disable the feature for service reasons. This is the default setting.
- RTD Enables and displays the 2 motor bearing temperatures, as reported by the bearing RTD's, via the Motor Monitoring Board serial communications.
- VSD TRANSMITTER Enables and displays the 2 motor bearing temperatures, as reported by the bearing transmitters via the VSD Logic Board serial communications.

Motor Vibration Protection

Access Level Required: SERVICE

Enables and disables the Motor Bearing Vibration protection feature. When set to any setting other than Disabled, the respective vibration values are enabled, displayed and the HIGH BEARING VIBRATION fault and Warnings will occur when the programmed thresholds for those conditions are reached. The settings are:

• DISABLED - Disables the Bearing Vibration Protection feature. No bearing vibration values are displayed and the heading, text and data boxes do not appear. The High Bearing Vibration Fault, Warning and Baseline Not Set Warning will not occur. This setting is used when the motor is not equipped with bearing vibration sensors or if is desired to disable the feature for service reasons. This is the default setting.

• ROLLING ELEMENT - Enables and displays the Bearing Vibration Protection feature. Displays the Shaft End and Opposite Shaft End vibration values as reported by the vibration sensors via the Motor Monitoring Board serial communications. The Vibration Baseline values, created by either manual entry or by running the auto baseline routine are shown, along with the AUTO BASELINE and AUTO BASELINE SETPOINT keys.

Motor Cooling Coil Leak Protection

Access Level Required: SERVICE

FORM 160.54-01

Enables the type of leak protection device being used to detect a leak of the motor cooling coil. When set to any setting other than Disabled, an LED status indicator is displayed and the Motor Cooling Coil safety fault will occur when the sensor indicates a leak. The settings are:

- DISABLED Disables the Motor Cooling Coil Leak Protection feature. The status LED and text do not appear. The Motor Cooling Coil Leak fault will not occur. This setting is used when the motor is not equipped with a leak detector or if it is desired to disable this feature for service reasons. This is the default setting.
- OPTICAL Enables the optical sensor digital input and displays the leak status, as reported by the optical leak sensor, via the Motor Monitoring Board serial communications.
- FLOAT Enables the float sensor digital input and displays the leak status, as reported by the float leak sensor, via the Motor Monitoring Board serial communications

Manual Baseline (Motor Bearing Vibration)

Access Level Required: SERVICE

Used to manually enter a vibration baseline value (0.1)to 5; default 2) for the Shaft End and Opposite Shaft End bearings. The vibration values are not in any particular units of measure. They are relative values. The larger the number, the greater the magnitude of vibration represented. Values entered appear on this screen as the Vibration Baseline values. A special password is required.

Auto Baseline (Motor Bearing Vibration) Access Level Required: SERVICE

Used to run the auto baseline routine. Only allowed after the chiller has been running for greater than 2 minutes. The vibration level of each bearing is independently averaged for 1 hour at 1 minute intervals while the chiller is running. While the routine is running, the time remaining in the 1 hour routine is displayed as auto baseline time left on this screen. At the completion of the routine, the derived values appear on the screen as the Vibration Baseline values (0.1 - 5; default 2). The vibration values are not in any particular units of measure. They are relative values. The larger the number, the greater the magnitude of vibration represented. A special password is required.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Motor

Access Level Required: VIEW Returns user to MOTOR Screen.

Setpoints

Access Level Required: SERVICE

Moves to a subscreen allowing programming of additional Motor Monitoring Setpoints.

MOTOR SETPOINTS SCREEN (SOFTWARE VERSION C.OPT.01.22.307 AND LATER)



FIGURE 43 - MOTOR SETPOINTS SCREEN (SOFTWARE VERSION C.OPT.01.22.307 AND LATER)

OVERVIEW

This screen allows programming of the winding and bearing High Temperature Warning/Safety Shutdown thresholds and the High Vibration Warning/Safety Shutdown thresholds, along with the vibration input gain. Also, individual winding temperature sensors can be disabled on this screen.

DISPLAY ONLY

Motor Windings

Temperature

Displays the Enabled/Disabled status of each winding sensor. The TEMPERATURE DISABLE Setpoint key can be used to enable or disable individual winding temperature sensors. Not shown when Winding Temperature Protection Setpoint on the MOTOR DETAILS Screen is set to Disabled.

High Winding Temperature Shutdown

Displays the High Winding Temperature safety shutdown threshold, as programmed with the WINDING SETUP Setpoint key. Not shown when Winding Temperature Protection Setpoint on the MOTOR DETAILS Screen is set to Disabled.

Winding Hotspot Allowance

Displays the Winding Hotspot Allowance temperature. Not shown when Winding Temperature Protection Setpoint on the MOTOR DETAILS Screen is set to Disabled.

Motor Bearings

High Vibration Shutdown

Displays the High Vibration safety shutdown threshold for the Shaft End and Opposite Shaft End bearings. Not shown when the Motor Vibration Protection Setpoint on MOTOR DETAILS Screen is set to Disabled. The threshold used for this setpoint will either be the values entered by the Vibration Setup Setpoint or values derived from the Vibration Baseline Setpoints (See *Vibration Setup on page 115*). Also displayed is the Delay, which is the amount of time the vibration must exceed the shutdown threshold before the shutdown occurs.

High Vibration Warning

Displays the High Vibration Warning threshold for the Shaft End and Opposite Shaft End bearings. Not shown when the Motor Vibration Protection Setpoint on MOTOR DETAILS Screen is set to Disabled. The threshold used for this setpoint will either be the values entered by the Vibration Setup Setpoint or values derived from the Vibration Baseline Setpoints (See *Vibration Setup on page 115*). Also displayed is the Delay, which is the amount of time the vibration must exceed the warning threshold before the warning is displayed.

Vibration Input Gain

Displays the Vibration Input Gain value, as programmed with the VIBRATION GAIN Setpoint key. Not shown when the Motor Vibration Protection Setpoint on MO-TOR DETAILS Screen is set to Disabled.

High Bearing Temperature Shutdown

Displays the High Bearing Temperature safety shutdown threshold, as programmed with the BEARING SETUP Setpoint key. Not shown when Bearing Temperature Protection Setpoint on MOTOR DETAILS Screen is set to Disabled.

High Bearing Temperature Warning

Displays the High Bearing Temperature warning threshold, as programmed with the BEARING SETUP Setpoint key. Not shown when Bearing Temperature Protection Setpoint on MOTOR DETAILS Screen is set to Disabled.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Temperature Disable

Access Level Required: ADMIN

Only shown when access level is ADMIN and Winding Temperature Protection Setpoint on MOTOR DE-TAILS Screen is not set to Disabled. Allows a Service Technician to disable individual winding temperature sensors. The respective temperature data box reflects enabled or disabled status. This could be applied to defective sensors or for service reasons. When a sensor is disabled, the respective temperature data box does not appear on the MOTOR DETAILS Screen.

Winding Setup

Access Level Required: SERVICE

Not shown when Winding Temperature Protection Setpoint on MOTOR DETAILS Screen is set to Disabled. Allows a Service Technician to program the High Winding Temperature (266 to 320°F; default 311) and Winding Hotspot Allowance (0 to 18°F; default 0) safety shutdown thresholds. Values entered are displayed in the respective data boxes.

Vibration Setup

Access Level Required: SERVICE

Not shown when Motor Vibration Protection Setpoint on MOTOR DETAILS Screen is set to Disabled.

Allows a Service Technician to program the High Vibration Shutdown (2.0 to 30; default Baseline X3) and WARNING (1.0 to 15; default Baseline X2) thresholds for the Shaft End and Opposite Shaft End bearings, along with the desired delays (shutdown - 0 to 30 seconds, default 15; WARNING - 0 to 120 seconds; default 30). The vibration thresholds are not in any particular units of measure. They are relative values. The larger the number, the greater the magnitude of vibration represented.

The thresholds used for Shutdown and warning will be either the values entered by this Vibration Setup Setpoint or values derived from the Vibration Baseline Setpoints. The values used by the software depend upon the sequence in which the setpoints are entered. If Vibration Baseline values are established (on the MOTOR DETAILS Screen with either the MANUAL BASELINE key or the AUTO BASELINE key) after thresholds have been entered with the Vibration Setup Setpoint, the baseline derived Shutdown and Warning thresholds override the thresholds entered with the Vibration Setup Setpoint. Thresholds entered with this Vibration Setup Setpoint, after baseline derived Shutdown and Warning thresholds are entered, override Baseline derived values. The active threshold values are displayed in the Motor Bearings High Vibration Shutdown and High Vibration Warning data boxes on this screen.

The Vibration Baseline values from which the Vibration Shutdown and Warning thresholds are derived, are displayed on the MOTOR DETAILS Screen. The thresholds are calculated from the Baseline values as follows: (NOTE: if the calculated value exceeds the minimum and maximum limits of the Shutdown (2.0 to 30.0) or Warning (1.0 to 15.0) threshold, the threshold is set to the respective upper or lower limit).

- Shaft End High Vibration Warning Shaft End Vibration Baseline X2
- Shaft End High Vibration Warning Default Shaft End Vibration Baseline X2
- Opposite Shaft End High Vibration Warning -Opposite End Vibration Baseline X2
- Opposite Shaft End High Vibration Warning Default - Opposite End Vibration Baseline X2
- Shaft End High Vibration Shutdown Shaft End Vibration Baseline X3
- Shaft End High Vibration Shutdown Default -Shaft End Vibration Baseline X3
- Opposite Shaft End High Vibration Shutdown -Opposite Shaft End Vibration Baseline X3
- Opposite Shaft End High Vibration Shutdown Default - Opposite Shaft End Vibration Baseline X3

If no baseline values are entered, by either the auto baseline routine or manual entry, the message WARN-ING – MOTOR – BEARING VIBRATION BASE-LINE NOT SET is displayed and the baseline values are set to X.X while this message is displayed. When the Motor Vibration Protection Setpoint is set to Disabled, no baseline vibration values are displayed and the heading, text and data boxes do not appear.

Vibration Gain

Access Level Required: ADMIN

Only shown when access level is ADMIN and Motor Vibration Protection Setpoint on MOTOR DETAILS Screen is not set to Disabled. Allows a Service Technician to enter values for vibration Input Gain [1:1, 11:1, 21:1 (default)].

Bearing Setup

Access Level Required: SERVICE

Not shown when Bearing Temperature Protection Setpoint on MOTOR DETAILS Screen is set to Disabled. Allows a Service Technician to enter values for High Bearing Temperature Shutdown (149°F to 212°F; default 203°F) and WARNING (140°F to 194°F; default 194°F) thresholds.

NAVIGATION

Home

Access Level Required: SERVICE Returns user to HOME Screen.

Motor Details

Access Level Required: SERVICE Returns user to MOTOR DETAILS Screen.

SETPOINTS SCREEN



FIGURE 44 - SETPOINTS SCREEN

OVERVIEW

This screen provides a convenient location for programming the most common setpoints involved in the chiller control. This screen also serves as a gateway to a subscreen for defining the setup of general system parameters.

DISPLAY ONLY

Leaving Chilled Liquid Temperature – Setpoint

Displays the present setpoint to which the chiller is operating whether controlled remotely or locally. This value could come from a 0 to 20 mA, 4 to 20mA, 0 to 10 VDC or 2 to 10 VDC input in Analog Remote mode, PWM signal in Digital Remote mode, E-Link Gateway interface in ISN mode, or a locally programmed value.

Leaving Chilled Liquid Temperature Cycling – Shutdown

Displays the Leaving Chilled Liquid Temperature at which the chiller will shut down to avoid over-cooling the building. This value is calculated by subtracting the Leaving Chilled Liquid Temperature Cycling Offset – Shutdown from the Leaving Chilled Liquid Temperature – Setpoint. If this value is below the absolute minimum allowed shutdown temperature the minimum value is displayed.

Leaving Chilled Liquid Temperature Cycling – Restart

Displays the Leaving Chilled Liquid Temperature at which the chiller will restart after it has shut down due to over-cooling temperature. This value is calculated by adding the Leaving Chilled Liquid Temperature Cycling Offset – Restart to the Leaving Chilled Liquid Temperature – Setpoint.

Current Limit Setpoint

(Flash Memory Card version C.MLM.01.01 or later)

Displays the active Current Limit Setpoint. In Local mode, this is the locally programmed Current Limit Setpoint. In ISN Remote mode, this is the setpoint received from the E-Link Gateway interface. In Analog Remote mode, this is the setpoint received via 0 to 10 VDC, 2 to 10 VDC, 0 to 20mA or 4 to 20mA input. In Digital Remote mode, this is the Pulse width Modulation signal input.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Local Leaving Chilled Liquid Temperature – Range

Access Level Required: OPERATOR

This is the range over which an analog signal (0 to 20 mA, 4 to 20mA, 0 to 10 VDC or 2 to 10 VDC) in Analog Remote mode or a digital signal (PWM) in Digital Remote mode can reset the Leaving Chilled Liquid Temperature Setpoint above the operator programmed BASE Setpoint. Programmable as either 10°F or 20°F, with a default of 20°F, it is added to the BASE value to create a range over which the remote device can reset the setpoint. For example, if this setpoint is programmed for 10°F and the operator programmed value is 45°F, then the remote device can set the Leaving Chilled Liquid Temperature Setpoint over the range of 45.0°F to 55.0°F.

Local Leaving Chilled Liquid Temperature – Setpoint

Access Level Required: OPERATOR

This value allows the user to define the Leaving Chilled Liquid Temperature that is to be maintained by the chiller. It is programmable over the range of 38.0°F to 72.0°F (water) or 10.0°F to 72.0°F (brine). If Smart Freeze is enabled, the range is 36.0°F to 70.0°F (water). The maximum allowed setpoint with Heat Pump duty enabled is 86.0°F (software version C.OPT.01.23.307 and later). A remote device can provide an analog signal (0 to 20 mA, 4 to 20mA, 0 to 10 VDC or 2 to 10 VDC) in Analog Remote mode, or PWM signal in Digital Remote mode that changes the setpoint by creating an offset above the operator programmed BASE Leaving Chilled Liquid Temperature Setpoint. This offset may be defined up to 10.0°F or 20.0°F above the BASE Setpoint (refer to the Remote Leaving Chilled Liquid Temperature Setpoint Range description). Additionally, E-Link Gateway (in ISN Remote mode) can define the setpoint through a serial data stream. In this case, the incoming setpoint is not an offset that is applied to the locally programmed BASE Setpoint value, but rather is the setpoint value itself.

Leaving Chilled Liquid Temperature Cycling Offset – Shutdown

Access Level Required: OPERATOR

This value allows the user to specify the Leaving Chilled Liquid Temperature at which the chiller will shut down on a LEAVING CHILLED LIQUID - LOW TEMPERATURE cycling shutdown. This is done by defining an offset below the Leaving Chilled Liquid Temperature Setpoint. It is programmable over a range of 1°F to 64°F below the setpoint, to a minimum cutout of 36°F (water), 34°F (water with Smart Freeze enabled) or 6°F (brine). It establishes the minimum allowed temperature for the Leaving Chilled Liquid Temperature and prevents over-cooling of the building. Anytime the Leaving Chilled Liquid Temperature Setpoint is increased, the shutdown threshold is 36.0°F (water) or 6.0°F (brine) for the next ten (10) minutes. If Smart Freeze is enabled, the threshold is 34.0°F for the next 10 minutes. After ten (10) minutes have elapsed, the shutdown threshold becomes the programmed setpoint value.

Leaving Chilled Liquid Temperature Cycling Offset – Restart

Access Level Required: OPERATOR

This value allows the user to specify the Leaving Chilled Liquid Temperature at which the chiller will restart after a shutdown on a LEAVING CHILLED LIQUID – LOW TEMPERATURE cycling shutdown. This is done by defining an offset above the Leaving Chilled Liquid Temperature Setpoint. It is programmable over a range of 0°F to 70°F above the setpoint, to a maximum restart value of 80°F. The chiller will automatically restart when this temperature is reached. This setpoint can be used to reduce chiller cycling by delaying the chiller restart until the cooling load has increased.

Remote Analog Input Range

(Flash Memory Card version C.MLM.01.01 or later)

Access Level Required: OPERATOR

This setpoint defines, for the Control Center, the remote signal range applied for remote reset of the Leaving Chilled Liquid Temperature Setpoint and Current Limit Setpoint in Analog Remote mode. If the remote signal is 0 to 10 VDC or 0 to 20mA, this setpoint must be programmed for 0 to 10 VDC. If the remote signal is 2 to 10 VDC or 4 to 20mA, this setpoint must be programmed for 2 to 10 VDC.

Motor Current Limit

Access Level Required: OPERATOR

Allows the user to specify the maximum allowed motor current (as a percentage of FLA). When the motor current reaches this value, the Pre-rotation Vanes will not be permitted to open further. If the motor current rises above this value, the Pre-rotation Vanes will close to reduce the current to this value.

Pulldown Demand Limit

Access Level Required: OPERATOR

Allows the user to specify the current limit value (as a percentage of Full Load Amps) to which the chiller will be limited during the specified pulldown limit time. This value will override the Motor Current Limit value during this time period. This function is used to provide energy savings following chiller start-up.

Pulldown Demand Time

Access Level Required: OPERATOR

Allows the user to set a period of time for which the pulldown demand limit will be in effect after the chiller starts.

Print

Access Level Required: VIEW Generates setpoints print report.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Setup

Access Level Required: VIEW

Moves to the subscreen allowing setup of general system parameters.

Quick Start

(Software version C.OPT.01.21.307 and later)

Access Level Required: ADMIN (to initially enable the feature); SERVICE (if feature is enabled)

Moves to the subscreen allowing the Quick Start feature to be enabled/disabled. Once enabled, this screen allows programming and viewing of Quick Start setpoints and parameters.



SETUP SCREEN

FIGURE 45 - SETUP SCREEN

OVERVIEW

This screen is the top level of the general configuration parameters. It allows programming of the time and date, along with specifications as to how the time will be displayed (12 or 24 hour format). In addition, the chiller configuration, as determined by the state of the Microboard Program Jumpers and Program Switches, is displayed. A qualified Service Technician, following instructions in *OptiView Control Center – Service Instructions (Form 160.54-M1)*, establishes this configuration for the desired operation. This screen also serves as a gateway to more subscreens for defining general system parameters.

DISPLAY ONLY

031-01730-000 Microboard Chilled Liquid Pump Operation: Displays **Standard** or **Enhanced**

Motor Type: Displays **Fixed Speed** or **Variable Speed**

Refrigerant Selection: Displays **R-22** or **R134a** Anti-Recycle: Displays Disabled or Enabled

Power Failure Restart: Displays **Manual** or **Automatic**

Liquid Type: Displays Water or Brine

Coastdown:

Displays **Standard** (150 seconds) or **Enhanced** (15 minutes – Steam Turbine applications)

Pre-Run: Displays **Standard** (50 seconds) or **Extended** (180 seconds)

Oil Pump Package: Displays **Fixed Speed** or **Variable Speed**

Power Line Frequency (VSD only): Displays **60 Hz** or **50 Hz**

031-02430-000 and 031-02430-001 Microboard Refrigerant Selection Displays R22 or R134a

Liquid Type Displays **Water** or **Brine**



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Set Date

Access Level Required: OPERATOR

Allows the user to specify the present date. This value is critical to logging system shutdowns accurately and for utilizing the scheduling capabilities. When prompted to enter a date value, the user must enter the day, month, and four-digit year (using leading zeroes as necessary). If within range, the value will be accepted. If out of range, the user is prompted for the information again. At this point the user may retry the date entry, or cancel the programming attempt.

Set Time

Access Level Required: OPERATOR

Allows the user to specify the present time. This value is critical to logging system shutdowns accurately and for utilizing the scheduling capabilities. When prompted to enter a time value, the user must enter the hour and minute desired (using leading zeroes as necessary). If the chiller is presently set to 24-hour mode, the time must be entered in the 24-hour format. Otherwise, the user must also select AM or PM for the entered time. If out of range, the user is prompted for the information again. At this point the user may retry the time entry, or cancel the programming attempt.

Clock (Enabled / Disabled)

Access Level Required: OPERATOR

Allows the user to enable or disable the Real Time Clock in order to conserve battery life. The clock will be disabled during manufacturing and must be enabled at system commissioning. In addition, when preparing for prolonged shutdown the clock should once again be disabled.

12/24 Hr

Access Level Required: OPERATOR

Allows the user to specify the format in which the time will be presented to the user. This setpoint will affect the display of the time on the chiller panel and on all reports generated. 12-hour time format will include the AM and PM modifiers and show the range of time between 1:00 and 12:59, while the 24-hour time format will show the range of time between 0:00 and 23:59.

031-02430-000 and 031-02430-001 Microboard only

Change Settings

Access Level Required: OPERATOR or higher

Used to enter the following setpoints. Pressing this key places a green selection box around the first changeable setpoint. The access level determines which setpoints can be changed. Use the \blacktriangle and \blacktriangledown keys to place the selection box around the desired setpoint. With the setpoint selected, press the ENTER (\checkmark) key. A dialog box appears with the range of settings.

Chilled Liquid Pump Operation

Access Level Required: SERVICE

Allows a Service Technician to select Chilled Liquid Pump control contacts (I/O Board TB2-44/45) operation as either standard or enhanced.

Motor Drive Type

Access Level Required: SERVICE

Allows a Service Technician to enter the applied compressor motor type as either Electromechanical (EM), Solid State Starter (SSS-Mod A), Solid State starter (SSS – Mod B), Variable Speed Drive-60 Hz or Variable Speed Drive-50 Hz.

Anti-Recycle

Access Level Required: SERVICE

Allows a Service Technician to enable or disable the anti-recycle timer.

Power Failure Restart

Access Level Required: OPERATOR

Allows the user to select Manual or Automatic restart after power failure.

Coastdown

Access Level Required: SERVICE

Allows a Service Technician to select either Standard (electric motor) or Enhanced (15 minutes–Steam Turbine applications). When Standard is selected, the duration depends on the Software used. With version C.OPT.01.16.XXX (and later), the duration is programmable using the Coastdown Time Setpoint below. With earlier software versions, the duration is fixed at 150 seconds.

Pre-Run

Access Level Required: SERVICE

Allows Service Technician to select either Standard (30 seconds) or Extended (180 seconds).

Oil Pump Package

Access Level Required: SERVICE

Allows Service Technician to enter the applied oil pump drive type as either Variable Speed or Fixed Speed.

Motor Communications Protocol

(VSD applications – Software version C.OPT.01.16.307 or later)

(Style B Liquid Cooled Solid State Starter applications – Software version C.OPT.01.18.307 or later)

Access Level Required: SERVICE

Only displayed when Motor Drive Type Setpoint above is selected as "VSD-60 Hz", "VSD-50 Hz" or "SSS-Mod B". Allows the Service Technician to enable the appropriate serial communications port for communications with the Style B Liquid Cooled Solid State Starter (LCSSS) or Variable Speed Drive (VSD). Entered as YORK to enable COM 5 (J15) or MODBUS to enable COM 2 (J13). Selection required is based on hardware and interface that is present. Section Solid State Starters or Section Adaptive Capacity Control Board to determine which hardware/interface is present. This setpoint and entry instructions are described in detail in Sections Microboard 031-02430-000 and 031-02430-001, and LTC I/O Board of OptiView Control Center – Service Instructions (Form 160.54-M1). The chiller must be stopped with the Start-Run-Stop/ Reset switch in the Stop/Reset position to change this setpoint.

Motor Node ID

(VSD applications-Software version C.OPT.01.16.307 or later) (Style B Liquid Cooled Solid State Starter applications – Software version C.OPT.01.18.307 or later)

Access Level Required: SERVICE

Only displayed when MODBUS is selected for the Motor Communications Protocol Setpoint above. Allows the Service Technician to enter the Modbus Address of the VSD Logic Board or Style B LCSSS Logic/Trigger Board. The Motor Node ID Setpoint must be set to "1" to match the address assigned to the VSD Logic Board or Style B LCSSS Logic/Trigger Board. This setpoint and entry instructions are described in detail in Sections Microboard 031-02430-000 and 031-02430-001, and LTC I/O Board of *OptiView Control Center – Service Instructions (Form 160.54-M1)*. The chiller must be stopped with the Start-Run-Stop/Reset switch in the Stop/Reset position to change this setpoint.

VSD applications: Set the Modbus Address of VSD Logic Board 031-02506 to "1" by setting Switch SW3 position 1 to ON with all other positions OFF.

Style B Solid State Starter applications: Set the Modbus Address of the Logic/Trigger Board 031-02505 to "1" by setting Switch SW1 position 1 to ON with all other positions OFF.

Coastdown Time

(Software version C.OPT.01.16.xxx (or later)) Access Level Required: SERVICE

Only displayed when Standard is selected as the Coastdown Setpoint above. Allows Service Technician to select appropriate coastdown time for compressor motor applied. Larger motors require a longer coastdown time to assure the motor rotation has stopped before the oil pump is turned off at completion of post-lube. Programmable range is determined by the Chiller Style/Compressor Setpoint (Style F/J7 and G/K6-K7, the range is 240 (default) to 900 seconds. All others, the range is 150 (default) to 900 seconds).

Condenser Temperature Range

(Software version C.OPT.01.19.307 or later) Access Level Required: ADMIN

Special order R134a chillers are allowed to operate at higher than standard condenser temperatures. The resulting higher operating pressures require higher condenser warning and safety shutdown thresholds than standard applications. These chillers are equipped with a special High Pressure Cutout Switch (HPCO) that can be set to trip at a higher pressure.

TABLE 3 - CONDENSER TEMPERATURE RANGE

	STANDARD	EXTENDED
Warning – High Pressure Limit – Maximum allowable value (psig)	162.5	193
Condenser – High Pressure – Trip/reset threshold (psig)	180/120	200/140
Condenser – High Pressure Stopped – Trip/reset threshold (psig)	160/160	170/170

This setpoint allows for either standard or higher temperature condenser temperature operation. It is set at the factory and requires an ADMIN password to change it. It is only visible when set to Extended. It is set to Extended for those chillers equipped for high condenser temperature operation. Otherwise, it is set to Standard. When Heat Pump Duty is set to Enabled, this setpoint is automatically set to Extended. For R134a chillers, see *Table 3 on page 123*.

PRV Position

(Software version C.OPT.01.21.307 and later) Access Level Required: SERVICE

New production chillers after June 2009 can be equipped with an optional Pre-rotation Vanes Potentiometer, regardless of other options. This setpoint allows the software to be used in all YK chillers, whether equipped with the potentiometer or not. The PRV position will be shown on respective screens when Enabled.

- Enabled Automatically set to this setting if Hot Gas Bypass or Variable Geometry Diffuser (VGD) is enabled on the OPERATIONS Screen or Motor Drive Type Setpoint is set to VSD or MVVSD. The actual connection point of the potentiometer is determined by the equipment configuration: If equipped with a VSD in YORK protocol configuration, it is connected to the ACC Board; in Modbus Protocol Configuration, it is connected to the Microboard J7. If not equipped with VSD, but equipped with Hot Gas Bypass, the connection point is determined by which I/O Board is present: with I/O Board 371-02514-000, it is connected to this board; otherwise, it is connected to the Microboard J7. If not equipped with Hot Gas Bypass but equipped with a VGD, it is connected to the Microboard J7.
- Disabled Set to this position when not equipped with a PRV potentiometer. If equipped with a VSD, MVVSD or the Hot Gas Bypass, or Variable Geometry Diffuser is enabled; this setpoint is automatically enabled and cannot be set to disabled.

Motor Monitoring

(Software version C.OPT.01.22.307 and later) Access Level Required: SERVICE Allows the Service Technician to enable or disable the Motor Monitoring feature.

Heat Recovery

(Software version C.OPT.01.21.307 and later) *Access Level Required: SERVICE* Allows the Service Technician to enable or disable the Heat Recovery feature.

Heat Recovery cannot be used simultaneously with Heat Pump Duty. When Heat Pump Duty is enabled, Heat Recovery is automatically disabled and locked.

Head Pressure Control

(Software version C.OPT.01.21.307 and later) Access Level Required: SERVICE Allows the Service Technician to enable or disable the Head Pressure Control feature.

Head Pressure Control cannot be used simultaneously with Heat Pump Duty. When Heat Pump Duty is enabled, Head Pressure Control is automatically disabled and locked.

Heat Pump Duty

(Software Version C.OPT.01.23.307 and later) Access Level Required: ADMIN

Allows the Service Technician to enable and disable the Heat Pump feature. The access level must be ADMIN and the Refrigerant Type must be set to R-134a (SW1-1) for the setpoint to appear on this screen. When Heat Pump Duty is enabled, Heat Recovery and Head Pressure Control are automatically disabled and locked.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Schedule

Access Level Required: VIEW Moves to the subscreen allowing definition of the chiller operation schedule.

Diagnostics

Access Level Required: SERVICE Moves to the subscreen allowing limited diagnostic ca-

Moves to the subscreen allowing limited diagnostic capability while operating.

Comms

Access Level Required: VIEW

Moves to the subscreen allowing configuration of system communications.

Printer

Access Level Required: VIEW

Moves to the subscreen allowing configuration and control of printer functions.

Sales Order

Access Level Required: VIEW

Moves to the subscreen displaying the Sales Order information for the chiller system.

Operations

Access Level Required: VIEW

Moves to the subscreen displaying operating parameters of the chiller system.

User

Access Level Required: VIEW

Moves to the subscreen allowing configuration of user preferences.

QUICK START SCREEN (SOFTWARE VERSION C.OPT.01.21.307 AND LATER)



FIGURE 46 - QUICK START SCREEN (SOFTWARE VERSION C.OPT.01.21.307 AND LATER)

OVERVIEW

The Quick Start feature is useful in data center and process control applications where it is desirable to reestablish cooling as fast as possible after a shutdown or power failure. This feature, when enabled, allows quicker starts and restarts than normal control. It does this by reducing the time cycle for chiller restart and once running, loading the chiller as fast as possible. After the chiller is running and has met a specified setpoint or a specified period of time has elapsed, control returns to normal.

Quick Start feature has two different start modes:

- Quick Restart When a chiller shutsdown, if certain conditions are met at the completion of coastdown (and within 30 seconds thereafter), the VSD is started immediately with no prelube. The vanes are given a constant open pulse and after the VSD achieves its start frequency, the speed ramp rate is faster than with normal control.
- Quick Normal Start If the conditions for a Quick Restart are not met, the next time the chiller is started, it has a prelube period just like a normal start, however the vanes will begin to open at the begin-

ning of prelube, instead of waiting until System Run. At the completion of prelube, the VSD is started and after the VSD achieves its Start Frequency, the speed ramp rate is faster than with normal control.

In order to use this feature, the chiller must be equipped with a Variable Speed Drive in Modbus Protocol Configuration or a Medium Voltage Variable Speed Drive. The low inrush current of a VSD allows more starts per hour and allows the chiller to start with a more open vane position. It must be enabled with an ADMIN password by a qualified Service Technician using the procedure in *OptiView Control Center – Service Instructions (Form 160.54-M1)*. Once enabled, all setpoints and parameters related to this feature are displayed on this screen, when logged in at SERVICE access level.

If Heat Pump Duty is enabled, Quick Start is only available when the Heat Pump Operational mode setpoint is set to Cooling. When Heat Pump Duty Operational mode is set to Heating, Quick Start is automatically Disabled.

Service Technicians refer to *OptiView Control Center* – *Service Instructions (Form 160.54-M1)* for complete explanation of this feature.

DISPLAY ONLY

Leaving Chilled Liquid Temperature

Displays the temperature of the liquid as it leaves the evaporator.

Leaving Chilled Active Setpoint

Displays the setpoint to which the Leaving Chilled Liquid is being controlled.

Quick Pulldown in Effect (LED)

Illuminates while a Quick Pulldown is in effect. This is in effect from a start initiate until the Quick Pulldown Setpoint Offset has been reached or the Pulldown Override Time has elapsed, whichever occurs first.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Change Setpoints

Access Level Required: SERVICE

Used to enter the following setpoints. Pressing this key places a green selection box around the first changeable setpoint. Use the \blacktriangle and \blacktriangledown keys to place the selection box around the desired setpoint. With the setpoint selected, press the ENTER (\checkmark) key. A dialog box appears with the range of settings.

Quick Start Mode

Access Level Required: ADMIN

(Enabled, Disabled; default Disabled) This setpoint is used to Enable and Disable the Quick Start feature. It can only be Enabled when the Motor Drive Type Setpoint is set to VSD and the Motor Communications Protocol is set to Modbus. or, the Motor Drive Type Setpoint is set to MVVSD. If Heat Pump Duty is enabled, the Quick Start feature is only available when the Heat Pump Operational mode setpoint is set to Cooling.

The default is Disabled. Quick Start can only be enabled using an ADMIN password. When logged in at ADMIN access level, a QUICK START key will appear on the SETPOINTS Screen. Pressing this key will navigate to the QUICK START Screen where this setpoint is used to enable/disable the feature. Quick Start can be Disabled when logged in at SER-VICE access level. However, once Disabled, it requires an ADMIN password to enable it again, as explained above. Quick Start mode will be automatically disabled when any of the following occur: The Motor Drive Type is changed to something other than VSD or MVVSD, or the Motor Communications Protocol is changed to YORK, or the Heat Pump Duty (if enabled) Operational Setpoint is set to Heating mode.

Quick Pulldown Setpoint Offset

Access Level Required: SERVICE

(0°F to 10°F; default 5°F) This setpoint sets the Leaving Chilled Liquid Temperature at which the control transitions from Quick Start mode to normal operation. It is entered in the form of an offset above the active Leaving Chilled Liquid Temperature (LCHLT) Setpoint. Once the Leaving Chilled Liquid Temperature falls below the Active LCHLT Setpoint plus Quick Pulldown Setpoint Offset, PRV (Quick Restart) and speed control (Quick Restart and Quick Normal Start) revert to normal automatic control. Lower values of this offset result in faster pulldown times but can result in overshoot of the LCHLT Setpoint. Setting the value to its minimum of 0 results in the fastest pulldown time but nearly always results in setpoint overshoot. Depending upon how close the Low Chilled Liquid Temperature shutdown threshold is to the LCHLT Setpoint, this could result in a LOW CHILLED LIQUID TEM-PERATURE cycling shutdown.

The Leaving Chilled Liquid Temperature and setpoint is shown on the QUICK START Screen for reference. This setpoint sets one of the two setpoints that determine when the control transitions from Quick Start mode to normal operation. The other is the Pulldown Override Time below.

Pulldown Override Time

Access Level Required: SERVICE

(0 min to 15 min; default 10 min) This setpoint is the length of time the PRV is held open (Quick Restart) and the ACC speed (Quick Restart and Quick Normal Start) is increased on startup if the Quick Pulldown Setpoint Offset is not reached. This could be due to hitting current limit during the pulldown. If the Quick Pulldown Setpoint Offset is not reached in the Pulldown Override Time, PRV and ACC speed control will revert back to normal automatic control.

VSD Start Frequency

Access Level Required: SERVICE

The VSD Start Frequency is as follows:

- 60 Hz units with quick start enabled equal 30 Hz to 45 Hz (default 45 Hz)
- 50 Hz units equal 25 Hz to 37.5 Hz (default 37.5 Hz)

This setpoint is the same as shown on the ACC DE-TAILS Screen. It can be programmed on either the ACC Screen or the QUICK START Screen. It sets the VSD Start Frequency from which the speed will ramp from.

Mapping Enable

Access Level Required: SERVICE

(0.5°F to 4.0°F; default 1.0°F) This is the same setpoint as shown on the ACC DETAILS Screen. It can be programmed on either the ACC Screen or the QUICK START Screen. It sets the Delta T needed to be met to enable surge mapping and speed reduction initially on startup.

Quick Ramp Current Threshold

Access Level Required: SERVICE

(20% to 80% FLA; default 50%) This setpoint sets the motor current threshold where the VSD speed command ramp rate changes. At or below this threshold the speed command ramp is 4X of standard control. Over this threshold, the ramp rate is 2X of standard control until it hits the standard current limiting over 80% FLA. Higher current thresholds can result in faster pulldown times. However, setting this value too high can result in slower pulldown times due to hitting the current limit sooner on pulldown.

NAVIGATION

Home

Access Level Required: SERVICE Returns user to HOME Screen.

Setpoints

Access Level Required: SERVICE Returns user to SETPOINTS Screen.



SCHEDULE SCREEN

FIGURE 47 - SCHEDULE SCREEN

OVERVIEW

The SCHEDULE Screen contains more programmable values than a normal display screen. As such, each programmable value is not linked to a specific button. Instead the SELECT key is used to enable the cursor arrows which are used to highlight the day and the start or stop time the user wishes to modify. At this point the user may press the (\checkmark) key to program the Start / Stop times for that day.

In order for the Start / Stop combination to be utilized, each Start time must have a corresponding Stop time which occurs later in the day. The presently programmed schedule for a given day can be cancelled by setting both the Start time and Stop time to 12:00AM. If the Start time equals the Stop time (with any time other than 12:00AM), the chiller is OFF for that day. If the user desires the chiller to operate continuously through several days, the Stop time of Day 1 can be set to 11:59 PM and the Start time of Day 2 can be set to 12:00 AM. The chiller will not stop but continue to operate until the stop of Day 2.

The user has the ability to define a standard set of Start / Stop times which are utilized every week. The user may then specify exception Start / Stop combinations for any day of the week up to 6 weeks in advance. At

the end of each week the schedule for the next week is created by combining the standard week definition and the next defined exception week. The schedule is then updated as each of the exception weeks shifts down, leaving a new, blank exception week in the 6th week slot.

DISPLAY ONLY

None



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Standard Week Start/Stop Times

Access Level Required: OPERATOR

For each day of the week, the user may specify a time for the chiller to start and a time for the chiller to stop. The times specified in this entry week will be used as the default for every week of chiller operation.

Exception Start/Stop Times

Access Level Required: OPERATOR

For each day of the week, the user may specify a time for the chiller to start and a time for the chiller to stop. These Start / Stop combinations may be scheduled up to five (5) weeks in advance and also for the present week. As each week goes by, the new schedule will be created for the present week using the Exception specification in combination with the Standard week definition, as described above.

Schedule (Enabled / Disabled)

Access Level Required: OPERATOR

Allows the user to enable or disable the monitoring function which enforces the scheduled starting and stopping of the chiller.

Repeat Sunday Schedule

Access Level Required: OPERATOR

Duplicates the schedule defined for Sunday for the remainder of the standard weekdays.

Reset All Exception Days

Access Level Required: OPERATOR Deletes all programming for exception days within the next 6 weeks.

Select

Access Level Required: OPERATOR

Places a selection box around a start time for a given day. Use \blacktriangleleft , \triangleright , \blacktriangle or \blacktriangledown cursor arrows to place the box around the desired start or stop time for a given day.

Print

Access Level Required: VIEW Generates a Schedule print report.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Setup

Access Level Required: VIEW Return to the previous SETUP Screen.

USER SCREEN



FIGURE 48 - USER SCREEN

OVERVIEW

This screen allows definition of custom User ID's and matching passwords. This allows the building administrator to assign custom passwords to those who are authorized to maintain the chiller.

Each custom user value is not linked to a specific button. Instead, the CHANGE button is pressed which enables the cursor arrows which are used to highlight the custom user parameter the user wishes to modify. At this point the (\checkmark) button is pressed and the value may be entered.

DISPLAY ONLY

None



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

System Language

Access Level Required: OPERATOR

Allows the user to define the language for all Screens. The desired language is selected by scrolling through the list of those available. English is the Default language and is selected by pressing the \blacktriangle key when the dialog box appears during the selection process. The selected language will not be displayed until after the user navigates from the USER Screen to another screen. The selections are: English, French, German, Hungarian, Italian, Japanese (software version C.OPT.01.20.307 and later), Portuguese, Simplified Chinese, Spanish, and Traditional Chinese.

English / Metric Units

Access Level Required: OPERATOR

Define the unit system (English or Metric) used by the chiller display.

Custom User ID (4)

Access Level Required: SERVICE

This allows the user to specify up to four (4) custom User ID values. Each User ID will then require a corresponding password and user level. A User ID can be defined for various maintenance personnel.

Custom User Password (4)

Access Level Required: SERVICE

This allows the user to specify up to four (4) custom password values. Each password will then require a corresponding User ID and user level.

Custom User Access Level (4)

Access Level Required: SERVICE

This allows the user to specify up to four (4) custom User Access Levels. Each access level will then require a corresponding password and User ID.

Date Format

(Software version C.OPT.01.23.307 and later) Access Level Required: OPERATOR This setpoint allows the date format to be displayed in DDD MMM YYY (default), DD.MM.YYY or YYYY-MM-DD.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Setup

Access Level Required: VIEW Returns user to SETUP Screen.



COMMS SCREEN

FIGURE 49 - COMMS SCREEN

OVERVIEW

(Screen shown from all applications equipped with Flash Memory Card version C.MLM.01.05.xxx and later. Screen layout from earlier versions slightly different.)

This screen allows definition of the necessary communications parameters. See *SECTION 4 - PRINTING* of this manual for details of the printer connections and setup. Presently, there are no COM 2 communications features available.

DISPLAY ONLY

None



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Chiller ID

Access Level Required: OPERATOR

Define the numeric chiller ID when used within an ISN network of chillers. This ID number is also printed at the top of reports obtained with a local printer.

Printer Setup and COM 2 Setup

Access Level Required: OPERATOR

Pressing either key places a green selection box around the first changeable parameter. Use the \blacktriangle and \lor keys to place the selection box around the desired parameter to be changed. With the selection box around the desired parameter, press the ENTER (\checkmark) key. A dialog box is displayed permitting data entry. In VSD or LC-SSS Modbus Protocol Configuration, COM2 button is not shown because COM2 serial port is used for this interface.

Printer Baud Rate

Define the baud rate at which the panel shall communicate to the printer.

Printer Data Bits

Define the number of data bits with which the panel shall communicate to the printer.

Printer Parity Bits

Define the number of parity bits with which the panel shall communicate to the printer.

Printer Stop Bits

Define the number of stop bits with which the panel shall communicate to the printer.

COM 2 Baud Rate

Define the baud rate at which the panel shall communicate through the modem port.

COM 2 Data Bits

Define the number of data bits with which the panel shall communicate to the modem port.

COM 2 Parity Bits

Define the number of parity bits with which the panel shall communicate through the modem port.

COM 2 Stop Bits

Define the number of stop bits with which the panel shall communicate through the modem port.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Setup

Access Level Required: VIEW Returns user to SETUP Screen.



PRINTER SCREEN

FIGURE 50 - PRINTER SCREEN

OVERVIEW

This screen allows definition of the necessary communications parameters for the printer. See *SECTION 4 - PRINTING* of this manual for details of the printer connections and setup.

DISPLAY ONLY

Time Remaining Until Next Print

Displays the time until the next print log will occur, if the function is enabled.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Log Start Time

Access Level Required: OPERATOR

Set the time at which scheduled print logs will begin.

Output Interval

Access Level Required: OPERATOR Define the interval at which log printing will occur.

Automatic Printer Logging (Enabled / Disabled)

Access Level Required: OPERATOR

Enable the printer to begin printing status reports beginning at the programmed start time and recurring at the interval defined above.

Printer Type

Access Level Required: SERVICE

Define the printer type connected to the chiller system.

ACC Auto Map Print (Enabled / Disabled)

Access Level Required: SERVICE

Only available if the chiller system utilizes a Variable Speed Drive motor controller. The chiller monitors the ACC communications and when a surge point is mapped, a short report of system parameters is printed. When this function is active, all other printing capability is disabled.

ACC Map Report

Access Level Required: SERVICE

Only available if the chiller system utilizes a Variable Speed Drive motor controller. The chiller requests the entire surge map from the ACC. As the map is received, the parameters for each point are printed.

Print Report

Access Level Required: OPERATOR

Select the report type to print when the PRINT RE-PORT key is selected. This can vary from status report (present system parameters), Setpoints report (present value of the system setpoints), Schedule report (present value of the system schedule times), or a Sales Order Data report (information provided on the SALES OR-DER Screen). A print report is generated upon completion of selection.

Print All Histories

Access Level Required: OPERATOR

Generate a report of the system data at the time of all stored shutdowns.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Setup

Access Level Required: VIEW Returns user to SETUP Screen.

SYSTEM STATUS) SYSTEM RUN	06 Jul 1999 11 21 AM	Local Home
SYSTEM DETAILS		Service
Order Information Commissioning Date 00 000 0000 Job Name Job Location Model Number York Order Number Panel Serial Number Chiller Serial Number	Nameplate Information Motor Code Volts Phases Frequency (Hz) LRA Full Load Amps Inrush Amps	Setup
Design Load Evaporator Conden	ser System Information	
Passes Passes	Refrigerant	Set Order Info
Design Working Pressure	Tons	
Fouling Factor	Giear Code	
Pressure Drop	Liquid Type	
Nozzle Arrangement In	Brine Percent	
Nozzle Arrangement Out	VSD /SSS/EM	
Leaving Temperature	Kilowatts Input	
Return Temperature	「「「「「」」	C \ S' 10
GPM		NY 15
Tubes	Print	Dy Est
		00320VIP

SALES ORDER SCREEN

FIGURE 51 - SALES ORDER SCREEN

OVERVIEW

This screen allows definition of the sales order parameters. The commissioning date is entered by the Service Technician at the time of chiller commissioning. These values should never be changed or entered by anyone other than a qualified Service Technician. Entry instructions are included in the *OptiView Control Center – Service Instructions (Form 160.54-M1)*. The remainder of the values are entered at the YORK Factory during the manufacturing of the chiller.

DISPLAY ONLY

Model Number

Factory defined model number of the chiller system.

Panel Serial Number

Factory defined serial number for the micropanel.

Chiller Serial Number

Factory defined serial number for the chiller system.

YORK Order Number

Factory defined order number under which the chiller was sold.

System Information

Factory defined conditions for which the chiller was originally rated and sold.

Condenser and Evaporator Design Load Information

Factory defined description of the condenser and evaporator configuration at time of shipment.

Nameplate Information

Factory defined information about the chiller motor configuration.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Commissioning Date

Access Level Required: SERVICE

Define the date at which the chiller was commissioned.

FORM 160.54-O1 ISSUE DATE: 06/14/2019

Job Name and Location

Access Level Required: SERVICE Factory defined job name and location the chiller is destined for.

Print

Access Level Required: VIEW This generates a listing of the Sales Order data.

NAVIGATION

Home Access Level Required: VIEW Returns user to HOME Screen.

Setup

Access Level Required: VIEW Returns user to SETUP Screen.

OPERATIONS SCREEN



FIGURE 52 - OPERATIONS SCREEN

OVERVIEW

This screen allows definition of general parameters having to do with the operation of the chiller.

DISPLAY ONLY

Chiller Run Time

(Flash Memory Card version C.MLM.01.04 or later)

Displays the amount of time the chiller has been running since the last start signal was received. Value is reset to zero when the chiller enters coastdown. It remains at zero while shutdown and during System Prelube.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Control Source

Access Level Required: OPERATOR

Define whether the control of the chiller will be Local, Digital Remote, Analog Remote, Modem Remote or ISN Remote.

Number of Starts

Access Level Required: ADMIN

Displays the number of the starts the chiller has initiated. This may be reprogrammed to a desired value, (generally when this value has been reset due to a Microboard replacement), but should not be done so arbitrarily.

Operating Hours

Access Level Required: ADMIN

Displays the total accumulated run time of the chiller. This may be reprogrammed to a desired value (generally when this value has been reset due to a Microboard replacement), but should not be done so arbitrarily.

Hot Gas Control (Enabled/Disabled)

Access Level Required: SERVICE Enables and disables the optional Hot Gas Bypass Control feature.

Refrigerant Level Control (Enabled / Disabled)

Access Level Required: SERVICE

Enables and Disables the Refrigerant Level Control Feature.

Flow Switch

(Style F and later chillers equipped with Flash Memory Card version C.MLM.01.08.xxx and later)

Access Level Required: SERVICE

Used to enter the applicable flow switch type. Style F and later chillers could be equipped with either Paddle-type or Thermal-Type Flow sensors. The actual type installed must be entered to allow the program to read the correct input. Key is only displayed if Style F chiller is selected with the Chiller Style/Compressor Setpoint below.

VGD (Enabled/Disabled)

(Software version C.MLM.01.10.xxx (and later) or C.OPT.01.10.302 (and later))

Access Level Required: SERVICE

Enables and disables the Variable Geometry Diffuser feature. If equipped with this feature, it should be enabled. Otherwise, it should be disabled.

Chiller Style/Compressor

(Flash Memory Card version C.MLM.01.07.xxx and later)

Access Level Required: SERVICE

Used to enter the chiller style/compressor combination. Once the applicable chiller style/compressor combination is entered, the program controls the chiller according to the requirements of the entered chiller style and compressor.

Edit Phone Numbers

(Flash Memory Card version C.MLM.01.05.xxx and later)

Access Level Required: SERVICE

Displays up to two service phone numbers. The Regional service phone number is displayed as the first number. Although the label and number can be changed appropriately, the default for this entry is "Johnson Controls North American Parts Center Toll Free Number 1-800-524-1330". The Local service phone number is displayed as the second number. Although blank by default, the appropriate label and number can be entered by a Service Technician.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

Setup

Access Level Required: VIEW Returns user to SETUP Screen.

HISTORY SCREEN

STSTEM STATUS			DATE	TIME)	CONTROL SOURCE	
SYSTEM RUN			23 Jan 2002	1 55 PM	Local	Home
STSTEM DETAILS		nou			ACCESS LEVEL	
N HISTORY SCREE		INUL		1	Service	
					-	
Last Normal Shu	tdown					Trending
					$\langle \langle \rangle$	· · · · · · · · · · · · · · · · · · ·
	- 16					
Last Fault While	Running				18. 1	Custom View
12:04:39 PM	23 Jan 2002	EVAPORATOR	- TRANSDUCER O	R LEAVING	LIQUID	
Last Ten Faults	"my	$\left(\right) $			-	-19
1.12:04:39 PM	23 Jan 2002	EVAPORATOR	- TRANSDUCER O	IR LEAVING		Security Log
2. 11:42:36 AM	23 Jan 2002	OIL - DIFFEREN	ITIAL PRESSURE	CALIBRATI	ON	
3.11:40:41 AM	23 Jan 2002	THRUST BEAR	ING - PROXIMITY	PROBE		
4.11:34:22 AM	23 Jan 2002	CONTROL PAN	EL - POWER FAIL	URE		
5.11:18:54 AM	23 Jan 2002	CONTROL PAN	EL - POWER FAIL	URE		
6. 11:13:07 AM	23 Jan 2002	CONTROL PAN	EL - POWER FAIL	URE		
7.11:09:19 AM	23 Jan 2002	CONTROL PAN	EL - POWER FAIL	URE		
8. 11:07:09 AM	23 Jan 2002	CONTROL PAN	EL - POWER FAIL	URE		
9. 10:10:44 AM	23 Jan 2002	CONTROL PAN	EL - POWER FAIL	URE		
10. 5:18:36 PM	18 Jan 2002	CONTROL PAN	EL - POWER FAIL	URE		
(13)		25	4	9>	- is	
Select Fault		5	Print All			
Normal			Histories			
	17	-)-		52	3.57	Ser
						00661VI

FIGURE 53 - HISTORY SCREEN

OVERVIEW

This screen allows the user to browse through the faults. In order to get a more thorough reporting of the system conditions at the time of the recorded shutdown, move to the subscreen HISTORY DETAILS.

The user may use the SELECT FAULT button to select the history to view. At this point the VIEW DETAILS button is used to jump to a subscreen containing stored chiller parameters values at the time of the shutdown. Additionally, the PRINT HISTORY button can be used to generate a hard-copy report of the parameter values at the time of the shutdown.

DISPLAY ONLY

Last Normal Shutdown

This window displays the date and time and the description of the last normal shutdown. A normal shutdown is defined as:

- Local (Panel rocker switch)
- Remote (Digital, Analog or ISN)

Last Fault While Running

This window displays the date and time and the description of the last safety or cycling shutdown while the system was running.

Last Ten Faults

This window displays a chronological listing (most recent first) of the date and time and the description of the last ten safety or cycling shutdowns that occur while the system is running or stopped.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Print History

Access Level Required: VIEW

This generates a report listing the status of the chiller parameters at the time of the selected shutdown.

Print All Histories

Access Level Required: VIEW

This generates a report listing the status of the chiller parameters at the time of each of the stored shutdowns.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

View Details

Access Level Required: VIEW

Causes a move to a subscreen containing the value of select chiller parameters at the time of the associated shutdown.

Trending

Access Level Required: VIEW

Causes a move to a subscreen allowing the user to view trending data on selected chiller parameters.

Custom View

(Flash Memory Card version C.MLM.01.04 or later)

Access Level Required: VIEW

Causes a move to a subscreen allowing the user to view the CUSTOM SETUP Screen.

Security Log

(Flash Memory Card version C.MLM.01.06 and later and "P" compressors C.MLM.04.02 and later)

Access Level Required: SERVICE

Causes a move to a subscreen allowing the user to view a record of the last 75 setpoint changes.

HISTORY DETAILS SCREEN



FIGURE 54 - HISTORY DETAILS SCREEN

OVERVIEW

This screen allows the user to see an on-screen printout of all the system parameters at the time of the selected shutdown. Not all screens are shown above. The number of screens required to display all of the data varies according to type of motor starter and options applied.

DISPLAY ONLY

History Printout

This is the on-screen printout of the system parameters.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Page Up

Access Level Required: VIEW Scroll up in the displayed data (if applicable).

Page Down

Access Level Required: VIEW Scroll down in the displayed data (if applicable).

Print History

Access Level Required: VIEW

This generates a report listing the status of the chiller parameters at the time of the selected shutdown.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

History

Access Level Required: VIEW Returns user to HISTORY Screen.

SYSTEM STATUS	23 Jan 200	1:53 PM	ontrol source) Local	Hama
STSTEN DETAILS			ACCESS LEVEL	Home
SECURITY LOG SC	REEN	. 1-	Jeivice	
Category	Setpoint	New Valu	e	History
1 Motor	Pulldown Demand Limit	100 %	ICT	
2 System	Chiller ID C	0		
3 System	Chiller ID	0 G		
🕴 Oil Sump	Control Period	1.2 Sec		
5 Oil Sump	Pressure Setpoint	40 PSID		
System	Remote Analog Input Range	/ 2-10 Volts		
7 Evaporator	Sensitivity	50%		
Evaporator	Restart Offset	2.0 *F		
S Evaporator	Leaving Chilled Local Setpoint	46.0 °F		
10 Motor	Pulldown Demand Time	10 Min		
11 Motor	Pulldown Demand Limit	90 %		
12 Oil Sump	Standby Lube	- Enabled		
13 Compressor	Proximity Fault Clear	Yes 🤇		
14 Compressor	High Speed Thrust Bearing Proximity Referen	nce 40 Mils		
" Je			, L	Print
Log Entry	View Details	914/ 	70,	25
				00662VIP

SECURITY LOG SCREEN

FIGURE 55 - SECURITY LOG SCREEN

OVERVIEW

(This screen only available with Flash Memory Card version C.MLM.01.06.xxx and later)

This screen displays a listing of the last 75 setpoint changes. They are listed and numbered in reverse order in which they were changed, with the most recent listed as number 1. Multiple pages are necessary to display all 75 changes. Not all setpoints are logged. Service Technicians refer to list in *OptiView Control Center – Service Instructions (Form 160.54-M1)*.

The details of any setpoint change can be viewed by navigating to a subscreen that displays the date and time of the change, access level and User ID used to make the change, the old setpoint value and the new setpoint value.



Requires a login access level of SERVICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

DISPLAY ONLY

Category

Displays the category of the setpoint (motor, evaporator, condenser, and so on.).

Setpoint

Displays the setpoint that was changed.

New Value

Displays the value that was entered at the time of the setpoint change.

PROGRAMMABLE

Log Entry

Allows the user to select a particular setpoint change for detail viewing.

Print

Generates a detailed report of all setpoint changes listed in the setpoint change log.

Page Up

Scroll up in the displayed data (if applicable).

Page Down

Scroll down in the displayed data (if applicable).

NAVIGATION

Home

Access Level Required: SERVICE Returns user to HOME Screen.

History

Access Level Required: SERVICE Returns user to HISTORY Screen.

View Details

Access Level Required: SERVICE

Causes a move to a subscreen containing the details of the setpoint change selected with the LOG ENTRY key.
SECURITY LOG DETAILS SCREEN



FIGURE 56 - SECURITY LOG DETAILS SCREEN

OVERVIEW

(This screen only available with Flash Memory Card version C.MLM.01.06.xxx and later)

This screen allows the user to view the details of a logged setpoint change, selected from the list on the SECURITY LOG Screen. The date and time the setpoint was changed, the new and old setpoint value and access level and User ID used to make the change are displayed. The data on this screen can be printed.



Requires a login access level of SERVICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

DISPLAY ONLY

Description

Displays the setpoint/category that was changed.

Time

Displays the time the setpoint was changed.

Date

Displays the date the setpoint was changed.

Access Level

Displays the login Access Level used to make the setpoint change.

User ID

Displays the login User ID used to make the setpoint change.

Old Value

Displays the previous setpoint value.

New Value

Displays the value entered at the time of the setpoint change.

PROGRAMMABLE

Print

Generates a report of change parameters displayed on this screen.

NAVIGATION

Home Access Level Required: SERVICE Returns user to HOME Screen. Security Log Access Level Required: SERVICE Returns user to SECURITY LOG Screen.

15 Feb 2000 3 50 PM Home EAVING CHILLED LIQUID CONTROL Service USTOM SCREEN History 45.0 °F Leaving Chilled Liquid Temperature 55.0 °F **Return Chilled Liquid Temperature** Setup 75.0 *F Leaving Condenser Liquid Temperature 65.0 *F Return Condenser Liquid Temperature 149.9 °F **Discharge Temperature** 61.8 *F **Discharge Superheat** 7.8 PSIA Evaporator Pressure 18.9 PSIA **Condenser** Pressure 27.2 PSID **Oil Pressure** 50 % % Full Load Amps Print

CUSTOM VIEW SCREEN

FIGURE 57 - CUSTOM VIEW SCREEN

OVERVIEW

(Flash Memory Card version C.MLM.01.04 or later)

This screen allows up to 10 Service Technician selected parameters to be displayed. These parameters are selected from a list on the CUSTOM VIEW SETUP Screen. This allows the Service Technician to display parameters pertinent to a particular problem during troubleshooting. At completion of the service call, the display can be cleared or the parameters can be left there for monitoring by operations personnel.

DISPLAY ONLY

None



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Print

Access Level Required: VIEW

This generates a listing of the parameters displayed on this screen.

00324VIP

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

History

Access Level Required: VIEW Returns user to HISTORY Screen.

Setup

Access Level Required: OPERATOR

Causes a jump to the subscreen that allows selection of the parameters to be displayed.

CUSTOM VIEW SETUP SCREEN

		0	8 Sep 1999	12:09 PM	Local ACCESS LEVE	Home
CUSTOM	D LIQUID CONTROL SETUP SCREEN			1 -	Service	
recc Select	Custom Slot 1		eaving Chille	ed Liquid Te	mperature	Custom View
utton to start	Custom Slot 2		Return Chille	ed Liquid Te	mperature	17
rogramming. 🗡	Custom Slot 3			E vaporato	r Pressure	
lse cursor keys	Custom Slot 4		vaporator S	aturation Te	mperature	
o select desired	Custom Slot 5	Leav	ing Condens	er Liquid Te	mperature	
oromatel 	Custom Slot 6	Ret	urn Condens	er Liquid Te	mperature	
ress Enter key	Custom Slot 7			Condense	r Pressure	Select
arameter	Custom Slot 8		Condenser S	aturation Te	mperature	Sereek
	Custom Slot 9		D	ischarge Te	mperature	
	Custom Slot 10		S	uperheat Te	mperature	
YORK Slo (c) 1997 - Wed 08 Sen	t #'s 1999 YORK INTE 1999 12:07:23]	RNATIONAL COM PM	PORATION			
near oo bep						
262 Ope 264 Num	rating Hours ber Of Starts					
262 Ope 264 Num Evaporator	rating Hours ber Of Starts				,	

FIGURE 58 - CUSTOM VIEW SETUP SCREEN

OVERVIEW

(Flash Memory Card version C.MLM.01.04 or later) This screen allows the Service Technician to select up to 10 parameters for display on the CUSTOM VIEW Screen.



Requires a login access level of SERVICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

DISPLAY ONLY

Slot Numbers

Lists the available parameters that can be displayed. The desired parameters for display are selected from this list.

PROGRAMMABLE

Page Up

Scroll up through list of available parameters.

Page Down

Scroll down through list of available parameters.

Select

First use the PAGE UP and PAGE DOWN keys to scroll through the Slot Numbers list and note the number of the parameters to be displayed. Pressing the SELECT key places a green colored selection box around Custom Slot 1. If it is desired to change an already entered parameter, use the 5 and 6 keys to place the selection box around the Slot Number to be changed. With the selection box around the Slot Number to be changed or entered, press the ENTER (\checkmark) key. A dialog box is displayed permitting data entry. Using the NUMERIC keypad keys, enter the desired Slot Number and press the ENTER (\checkmark) key.

Custom Slot (1-10)

Use the SELECT key and NUMERIC keypad keys as described above and enter the Slot Number from Slot Numbers list. Setting the Slot Number to zero clears the display of this Slot Number. FORM 160.54-O1 ISSUE DATE: 06/14/2019

NAVIGATION

Home Access Level Required: VIEW Returns user to HOME Screen.

Custom View

Access Level Required: SERVICE Returns user to CUSTOM VIEW Screen.



TREND SCREEN

OVERVIEW

As many as six Operator selected parameters (Data Points) can be plotted in an X/Y graph format. The X-Axis is scaled according to the selected Data Collection Interval and displayed in a time of day or elapsed time format, as selected with the X-Axis TOGGLE key. The Y-Axis is scaled for each parameter according to the selected minimum and maximum value for each parameter. Analog parameters are scaled in pressure, temperature, volts, amps, hertz or time. Digital on/off parameters are scaled as zero (off) and one (on). Only one Y-Axis label is displayed at a time. The Y-Axis TOGGLE Key is used to toggle the Y-Axis labels through the different parameters. The Y-Axis label that is being displayed is identified at the top of the graph. For identification, each plotted parameter and associated Y-Axis labeling is color coordinated.

On compressor applications other than "P" compressors, if equipped with Flash Memory Card version C.MLM.01.04.xxx and earlier, all trended Data Points are displayed simultaneously. On all "P" compressor applications or other compressor applications that are equipped with Flash Memory Card version C.MLM.01.05.xxx and later, the DATA SELECT key is used to display all trended Data Points simultaneously or select a single Data Point for display.

The parameters are sampled at the selected Data Collection Interval and plotted using 450 data points across the X-Axis. If the actual value of the sampled parameter is less than the Y-Axis label minimum for that parameter, the value will be plotted at the minimum value. Similarly, if the actual value is greater than the Y-Axis label maximum for that parameter, the value will be plotted at the maximum value.

There are three types of charts that can be created: One Screen, Continuous or Triggered (not applicable to Flash Memory Card version C.MLM.01.04.xxx and earlier). When plotting reaches the end of the X-Axis, if one screen is selected, trending stops and data is frozen. If continuous is selected, the oldest data is dropped from the left-hand side of the graph at the next collection interval. Thereafter, the oldest data is dropped from the left hand-side of the graph at each data collection interval. If triggered is selected, data collection can be set to start or stop based upon the selected Trigger Action (start or stop). If start is selected, data collection will not begin until the triggers have been satisfied and any selected trigger delay has elapsed. Data collection will stop at the completion of one screen of data as with the one screen. If stop is selected, data collection will not stop until the triggers have been satisfied and any selected trigger delay has elapsed.

FORM 160.54-O1 ISSUE DATE: 06/14/2019

SECTION 2 - OPTIVIEW CONTROL CENTER INTRODUCTION

If a power failure occurs while the trending is running, the trending is stopped. Upon restoration of power, the last screen of data that was collected will be displayed on the TREND Screen. The START key must be pressed to initiate a new TREND Screen.

DISPLAY ONLY

This screen allows the user to view the graphical trending of the selected parameters and is also a gateway to the graph setup screens.



A red screen with the words "TREND MAX MUST BE > TREND MIN" will appear if the Y-Axis minimum has been programmed to a value that is greater than the Y-Axis maximum for any parameter. If this appears, proceed to the TREND SETUP Screen to change the values.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Start

Access Level Required: OPERATOR

Pressing this key clears the graph, starts a new graph, sets the time of day to the present clock time and begins the trending. This key is only available if trending is stopped. If the selected Chart Type is triggered and Trigger Action is set to Start, data collection will not begin until the triggers have been satisfied and any selected trigger delay has elapsed. Otherwise, data collection will begin immediately.

Stop

Access Level Required: OPERATOR

Pressing this key stops the trending. The trend data is frozen on the display until another graph is started with the START key. The STOP key is only available if trending is running.

Print

(Flash Memory Card version C.MLM.01.05.xxx and later)

Access Level Required: VIEW

Allows the data on the TREND Screen to be printed in tabular format. If set to existing, a snapshot of the data

presently on the screen is sent to the printer. If set to new, all data collected after pressing this key will be sent to the printer as it is collected. If set to disabled, no data is sent to the printer. See *SECTION 4 - PRINTING* of this manual for printout example.

Data Select

(Flash Memory Card version C.MLM.01.05.xxx and later)

Access Level Required: VIEW

Allows the user to display all trended data points simultaneously or select a single trended data point for display, hiding the other data points. Selections are All Data or Data Point X (1-6).

Y-Axis

Access Level Required: VIEW

This key toggles the Y-Axis labels of the graph. Each key press changes the label to another of the selected parameters.

X-Axis

Access Level Required: VIEW

This key toggles the X-Axis labels of the graph. Each key press alternates the scaling between time of day and elapsed time. The Time of Day scaling is in 24hour format. The Elapsed Time scaling is the time elapsed since the START key was pressed, starting the trending.

NAVIGATION

Home

Access Level Required: VIEW Returns user to HOME Screen.

History

(Flash Memory Card version C.MLM.01.04.xxx and later) Access Level Required: VIEW Returns user to HISTORY Screen.

Trend Setup

Access Level Required:

This is only displayed if the trending is stopped. It causes a jump to a subscreen for configuring the trending display.

151

STSTEM STATUS 📜			DATE	TIME	CONTROL SOURCE	
SYSTEM RUN			23 Oct 2000	1 57 PM	Local Access Level	Home
EAVING CHILI	LED LIQUID C	ONTROL			Service	
TREND	SETUP SCRE	EN		- 1-		Sez .
Data Point 1	Slot	Leav	ving Chilled Liqu	iid Tempera	ture	Trend
	Minimum			0.	0 *F	-
~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~	Maximum			82.		
Data Point 2	Slot	N.		Motor	Run 🔿 📔	Slot #s
	Minimum				Off 📃	
	Maximum				On	
Data Point 3	Slot			Not Assig	ned	Select
					- Star	
Data Point 4	Slot			Not Assig	ned Ch	art Type
S.	5		,0	3×		riggered
Data Point S	Slot			Not Assig	ned Collec	tion Interval
15	25	7	*	.0	\$22 -	1 Sec
Data Point 6	Slot			Not Assig	ned 📄	
1.83	5	25'		\rangle	5	Triggers
Press Select b start programm	utton to Us ing. de	se eursor keys to select stired parameter.	Press Enter I parameter.	key to input	J.S.	
						00473V

TREND SETUP SCREEN

FIGURE 60 - TREND SETUP SCREEN

OVERVIEW

This screen is used to configure the TRENDING Screen. The parameters to be trended are selected from the COMMON SLOTS Screen or Common Slots Master list and entered as Slot Numbers for Data Points 1 through 6. The Y-Axis minimum and maximum values for each parameter are entered as Data Point Min and Data Point Max for Data Points 1 through 6. The interval at which all the parameters are sampled is selected as the Data Collection Interval.

DISPLAY ONLY

None



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Chart Type

Access Level Required: OPERATOR

Selects Continuous, One Screen Or Triggered (If compressor application is other than "P", applies only to Flash Memory Card version (C.MLM.01.05.xxx and later) type of graph.

Collection Interval

Access Level Required: OPERATOR

Selects the interval at which the parameters are sampled. There are 450 data points displayed across the X-Axis of the graph. Each point represents the instantaneous value of the parameter. The user selects the time interval between these points. This is called the Data Collection Interval, or the interval at which the parameter is sampled. This interval is programmable over the range of 1 second to 3600 seconds (1 hour), in one second increments. The selected interval not only determines the sample interval, but also the full screen time display. The full screen time display is a result of the selected interval in seconds, multiplied by the 450 data points. For example, if the Data Collection Interval is programmed for 900 seconds, the parameter would be sampled every 900 seconds, with the last 112.5 hours (4.7 days) of data viewable on the screen.

Therefore, the selected interval is a compromise between resolution and full screen time display. Select the desired Data Collection Interval as follows:

- 1. Determine the desired time interval (in seconds), between data samples.
- 2. Calculate the full screen time display as follows:
 - 450 x Data Collection Interval equals full screen seconds
 - Full screen seconds/60 equals full screen minutes
 - Full screen minutes/60 equals full screen hours
 - Full screen hours/24 equals full screen days
- 3. Decide if the resultant sample interval and full screen display meet the requirements. If not, select a different sample interval.

Select

Access Level Required: OPERATOR

This key is used to enter the Slot Numbers and the minimum and maximum Y-Axis values of each parameter to be trended. Pressing this key places a yellow box around Data Point 1 Slot Number. Use the \blacktriangle and \checkmark navigation keys to place the box around the value of Data Points 1 through 6 to be changed. With the desired value selected, press the X key. A dialog box is displayed permitting data entry.

Data Point Slot # (1-6)

Access Level Required: OPERATOR

Use the SELECT key as described above and enter the Slot Number from the COMMON SLOTS Screen or Master Slot Number List of the desired parameter to be trended. The selected parameter description will be displayed for the Data Point. Setting this Slot Number to zero will disable trending for that particular Data Point. Any or all points can be disabled.

Data Point Min (1-6)

Access Level Required: OPERATOR

Only displayed if the Associated Slot Number is not Zero. This is the minimum value displayed for the Y-Axis. Selecting a parameter for a Data Point sets this to the default value, which is the lowest value allowed for that parameter. It can be changed to a value that provides a more appropriate resolution for the parameter being monitored. To change, use the SELECT key as described above and enter the desired value. The value must always be set to a value less than the Data

JOHNSON CONTROLS

Point Max. Otherwise, a red graph is displayed on the TREND Screen with the words TREND MAX MUST BE > TREND MIN. If the parameter selected for this data point is a digital type (on/off), this value must be set to zero (0). Zero indicates the OFF state.

Data Point Max (1-6)

Access Level Required: OPERATOR

Only displayed if the associated Slot Number is not zero. This is the maximum value displayed for the Y-Axis. Selecting a parameter for a Data Point sets this to the default value, which is the highest value allowed for that parameter. It can be changed to a value that provides a more appropriate resolution for the parameter being monitored. To change, use the SELECT key as described above and enter the desired value. The value must always be set to a value greater than the Data Point Min. Otherwise, a red graph is displayed on the TREND Screen with the words TREND MAX MUST BE > TREND MIN. There are 20 Y-Axis divisions. If a MIN-MAX span is selected that is not evenly divided by 20, the program will automatically select the next higher MAX value that makes the span evenly divided by 20 (If compressor application is other than "P", applies only to Flash Memory Card version C.MLM.01.02 or later). For example, if 0.0 is selected as the MIN and 69.0 is selected as the MAX, the program will insert 70.0 as the MAX value. If the parameter selected for this data point is a digital type (on/off), this value must be set to one (1). One indicates the on state.

NAVIGATION

Home

Returns user to HOME Screen.

Trending

Returns user to TREND Screen.

Slot Numbers

(Flash Memory Card version C.MLM.01.02 or later) Causes a jump to a subscreen that lists the Slot Num-

bers of the most commonly monitored parameters. The desired parameters to be plotted are selected from this screen.

Triggers

(Flash Memory Card version C.MLM.01.05.xxx and later) Causes a jump to the Advanced TREND SETUP Screen, where the start/stop Triggers can be setup. Only displayed if triggered has been selected as Chart Type.

ADVANCED TREND SETUP SCREEN



OVERVIEW

(Flash Memory Card version C.MLM.01.05.xxx and later)

The desired data collection start/stop triggers are setup on this screen. The trend data collection can be set to start or stop based upon the status of up to two selected triggers.

The triggers can consist of digital events or analog parameters compared to thresholds. The triggers can be used individually or in combination. The digital and analog parameters are selected from the COMMON SLOTS Screen (or Master Slot Numbers List in this manual).

The parameter selected as the Primary Trigger is compared to a value selected as the Primary Test, using the Primary Operator as a comparator. If it is evaluated as true, then the data collection is started or stopped (after any selected trigger delay) according to the selected Trigger Action.

A Secondary Trigger can be evaluated with the Primary Trigger to start/stop data collection. The Primary to Secondary Operator is used to define the trigger combinations required to be true to start/stop data collection. The Secondary Trigger is setup and evaluated the same as the Primary Trigger. Entry fields are as follows:

- I. Primary Trigger
 - a. Primary Operator
 - b. Primary Test
- II. Primary to Secondary Operator
- III. Secondary Trigger
 - a. Secondary Operator
 - b. Secondary Test
- IV. Trigger Action
 - a. Delay of Trigger Delay

After the desired triggers are set, the START key on the TREND Screen must be manually pressed before the triggers will be evaluated. While waiting for the triggers to start or stop data collection, a status message is displayed in the upper right corner of the TREND Screen describing the pending action.

DISPLAY ONLY

None



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Primary Trigger

Access Level Required: OPERATOR

Selects the first parameter to be evaluated. Selection is made from the Slot Numbers listing on the TREND COMMON SLOTS Screen or the Master Slot Numbers List in this manual. Setting this Slot Number to zero disables the Primary Trigger.

Primary Operator

Access Level Required: OPERATOR

Selects the comparator for the Primary Trigger's relationship to the Primary Test. If the Primary Trigger is an analog value, selections are: <, <=, =, =>, >. If the Primary Trigger is a digital event, selections are: Equal To, Not Equal To.

Primary Test

Access Level Required: OPERATOR

Selects the value or condition that the Primary Trigger is compared to. Selection ranges from the Primary Trigger minimum value to the Primary Trigger maximum value.

Trigger Action

Access Level Required: OPERATOR

Selects whether the trend data collection will Start or Stop when the trigger comparisons are true. If set to Start, data collection will stop after one screen of data is collected.

Trigger Delay

Access Level Required: OPERATOR

Allows the data collection start or stop to be delayed after the triggers evaluate as true. The delay is selectable from 1 to 864000 seconds (10 days). Display is in days, hours, minutes and seconds. The delay timer begins when the triggers evaluate as true. If the Trigger Action is set to Start, data collection will begin after the triggers evaluate as true and the delay timer has elapsed. If the Trigger Action is set to Stop, data collection will stop after the triggers evaluate as true and the delay timer has elapsed.

Primary to Secondary Operator

Access Level Required: OPERATOR

Selects whether the Primary Trigger, Secondary Trigger or both have to be true in order to start or stop data collection. Selections are AND, OR, XOR and None. If NONE is selected, the Secondary Trigger is disabled.

Data collection will start/stop (as selected with Trigger Action) when:

- If AND selected: Both Primary AND Secondary are true
- If OR selected: Either Primary OR Secondary (or both) are true
- If XOR selected: Either Primary OR Secondary (but not both) are true

Secondary Trigger

Access Level Required: OPERATOR

Selects the second parameter to be evaluated. Selection is made from the Slot Numbers listing on the TREND COMMON SLOTS Screen or the Master Slot Numbers List in this manual. Setting this Slot Number to zero disables the Secondary Trigger.

Secondary Operator

Access Level Required: OPERATOR

Selects the comparator for the Secondary Trigger's relationship to the Secondary Test. If the Secondary trigger is an Analog value, selections are: <, <=, =, =>, >. If the Secondary Trigger is a digital event, selections are: Equal To, Not Equal To.

Secondary Test

Access Level Required: OPERATOR

Selects the value or condition that the Secondary Trigger is compared to. Selection ranges from the Secondary Trigger minimum to the Secondary Trigger maximum.

NAVIGATION

Home

Returns user to HOME Screen.

Trend Setup

Returns user to TREND SETUP Screen.

COMMON SLOTS SCREEN



FIGURE 62 - COMMON SLOTS SCREEN

OVERVIEW

This screen displays the Slot Numbers of the commonly monitored parameters. The Slot Numbers for the remainder of the available parameters are listed on the Master Slot Numbers List that follows.

From these lists, select up to six parameters to be trended. Return to the TREND SETUP Screen and enter the parameters Slot Numbers into Data Points 1 through 6.

DISPLAY ONLY

Slot Numbers

These are the Slot Numbers of the most commonly used parameters.



For fields requiring access level of SER-VICE. Service Technicians refer to the OptiView Control Center - Service Instructions (Form 160.54-M1) for operation instructions and explanation of all programmable setpoints and displayed values.

PROGRAMMABLE

Page Down

Access Level Required: OPERATOR Scroll down in the displayed data.

Page Up

Access Level Required: OPERATOR Scroll up in the displayed data.

Print

Access Level Required: OPERATOR

Generates a list of the Slot Numbers of the available parameters.

NAVIGATION

Home

Returns user to HOME Screen.

Trend Setup

Returns user to TREND SETUP Screen.

TABLE 4 - MASTER SLOT NUMBERS LIST FORUSE WITH TREND FEATURE

SLOT NUMBER	DESCRIPTION		
256	System: Chiller State		
257	System: Coastdown Time Remaining		
258	System: Prelube Time Remaining		
259	System: Are Safety Shutdown Contacts Closed		
260	System: Are Cycling Shutdown Contacts Closed		
261	System: Are Anticipatory Alarm Contacts Closed		
262	System: Operating Hours		
263	System: Run Time (in seconds)		
264	System: Number of Starts		
265	System: Is Stop Switch Closed		
266	System: Is Start Switch Closed		
267	System: Is Remote Ready to Start		
280	External Contact: Is Remote Stop Closed		
281	External Contact: Is Remote Start Closed		
282	External Contact: Is MultiUnit Cycling Closed		
283	External Contact: Is Remote Cycling Closed		
284	External Contact: Is Auxiliary Safety Open		
285	Jumper: Is Anti-Recycle Enabled		
286	Jumper: Coastdown Operation		
287	Jumper: Is Diagnostics Enabled		
288	Jumper: Liquid Type		
289	Jumper: Chilled Liquid Pump Operation		
290	Jumper: Motor Type		
291	Jumper: Power Failure Restart		
292	Jumper: Pre-Run Operation		
293	Jumper: Refrigerant Selection		
294	Jumper: VSD Motor Supply Line Frequency		
295	Jumper: Oil Pump Package		
304	Options: Control Mode		
305	Options: System Language		
306	Options: Chiller ID Number		
307	Options: Display Mode		
336	Security: Log In Level		
337	Security: Log In User ID		
512	Sched: Is Schedule Enabled		
1280	Pre-Rotation Vanes: Is Motor Switch Closed		
1281	Pre-Rotation Vanes: Position		
1282	Pre-Rotation Vanes: Are Vanes Opening		
1283	Pre-Rotation Vanes: Are Vanes Closing		
1284	Pre-Rotation Vanes: Are Vanes Holding		
1285	Pre-Rotation Vanes: Control Mode		
1296	Discharge: Temperature		
1536	Oil: Differential Pressure		
1537	Oil: Sump Temperature		

TABLE 4 - MASTER SLOT NUMBERS LIST FORUSE WITH TREND FEATURE (CONT'D)

SLOT NUMBER	DESCRIPTION
1538	Oil Pump: Control Mode
1539	Oil Pump: Is Pump On
1540	Oil Pump: Manual Time Left
1541	Oil Heater: Is Control Enabled
1542	Oil Heater: Is Heater On
1543	Oil Return Solenoid: Is Solenoid On
1792	Leaving Chilled Liquid: Temperature
1793	Leaving Chilled Liquid: Temperature Differential
1794	Leaving Chilled Liquid: Is Flow Switch Closed
1795	Leaving Chilled Liquid: Is Pump On
1796	Leaving Chilled Liquid: Local Temperature Setpoint
1797	Leaving Chilled Liquid: Remote Analog
	Temperature Setpoint
1798	Leaving Chilled Liquid: Remote BAS Temperature Setpoint
1799	Leaving Chilled Liquid: Remote Modem Temperature Setpoint
1800	Leaving Chilled Liquid: Selected Temperature Setpoint
1801	Leaving Chilled Liquid: Control Sensitivity
1802	Leaving Chilled Liquid: Remote Temperature
	Range
1803	Leaving Chilled Liquid: Restart Temperature Offset
1804	Leaving Chilled Liquid: Restart Temperature Setpoint
1805	Leaving Chilled Liquid: Shutdown Tempera- ture Offset
1806	Leaving Chilled Liquid: Shutdown Tempera- ture Setpoint
1807	Return Chilled Liquid: Temperature
1808	Evaporator: Pressure
1809	Evaporator: Saturation Temperature
1810	Evaporator: Small Temperature Difference
1811	Evaporator: Is Refrigerant Sensor Present
1812	Evaporator: Refrigerant Temperature
1813	Evaporator: Delta P / P
1814	Evaporator: Brine Low Cutout
1815	Smart Freeze Protection: Is Control Enabled
1816	Liquid Line Solenoid: Is Solenoid Installed
1817	Liquid Line Solenoid: Is Solenoid On
1818	Leaving Chilled Liquid: Remote Digital Tem- perature Setpoint
2048	Leaving Condenser Liquid: Temperature
2049	Leaving Condenser Liquid: Is Flow Switch Closed

SLOT NUMBER	DESCRIPTION		
2050	Leaving Condenser Liquid: Is Pump On		
2051	Return Condenser Liquid: Temperature		
2052	Condenser: Pressure		
2053	Condenser: Saturation Temperature		
2054	Condenser: Small Temperature Difference		
2057	Condenser: Is High Pressure Switch Closed		
2058	Condenser: High Pressure Warning Threshold		
2059	SubCooling: Temperature		
2060	Drop Leg Refrigerant: Is Sensor Present		
2061	Drop Leg Refrigerant: Temperature		
2062	Vent Line Solenoid: Is Solenoid Installed		
2063	Vent Line Solenoid: Is Solenoid On		
2304	Motor: Starter Type		
2305	Motor: Is Motor Starter On		
2306	Motor: Current %FLA		
2307	Motor: Is Motor Controller Switch Open		
2308	Motor: Current Limit Local Setpoint		
2309	Motor: Current Limit Remote Analog Setpoint		
2310	Motor: Current Limit Remote BAS Setpoint		
2311	Motor: Current Limit Remote Modem Setpoint		
2312	Motor: Current Limit Selected Setpoint		
2313	Motor: Pulldown Demand Time Remaining		
2314	Motor: Pulldown Demand Limit Setpoint		
2315	Motor: Pulldown Demand Time Setpoint		
2316	Motor: Anti-Recycle Time Remaining		
2317	Motor: Current Limit Remote Digital Setpoint		
2351	Motor - Operating Hours Since last Lubrication		
	(Mod A Solid State Starters)		
2560	SSS: Phase A Current		
2561	SSS: Phase B Current		
2562	SSS: Phase C Current		
2563	SSS: Phase A Voltage		
2564	SSS: Phase B Voltage		
2565	SSS: Phase C Voltage		
2566	SSS: Scale/Model		
2567	SSS: Full Load Amps		
2568	SSS: Supply Voltage Range		
2569	SSS: Is Current Unbalance Check Enabled		
	(Mod B Solid State Starters)		
2570	LcSss: Input Power		
2571	LcSss: Kilowatt Hours		
2572	LcSss: Phase A Current		
2573	LcSss: Phase B Current		
2574	LcSss: Phase C Current		

TABLE 4 - MASTER SLOT NUMBERS LIST FORUSE WITH TREND FEATURE (CONT'D)

SLOT NUMBER	DESCRIPTION		
2575	LcSss: Phase A Voltage		
2576	LcSss: Phase B Voltage		
2577	LcSss: Phase C Voltage		
2578	LcSss: Phase A Temperature		
2579	LcSss: Phase B Temperature		
2580	LcSss: Phase C Temperature		
2581	LcSss: Starter Model		
2582	LcSss: Full Load Amps		
2583	LcSss: Voltage Range		
2584	LcSss: Starting Current		
2585	LcSss: Is Serial Communications OK		
2586	LcSss: Panel to Sss Comm Errors		
2587	LcSss: Sss to Panel Comm Errors		
2816	VSD: Motor HP		
2817	VSD: 100% Full Load Amps		
2818	VSD: Input Power		
2819	VSD: Kilowatt Hours		
2820	VSD: DC Bus Voltage		
2821	VSD: DC Inverter Link Current		
2822	VSD: Output Frequency		
2823	VSD: Output Voltage		
2824	VSD: Phase A Current		
2825	VSD: Phase B Current		
2826	VSD: Phase C Current		
2827	VSD: Is Precharge Relay On		
2828	VSD: Is Trigger SCR On		
2829	VSD: Is Water Pump On		
2830	VSD: Control Mode		
2831	VSD: Command Frequency		
2832	VSD: Manual Frequency Increment		
2833	VSD: Internal Ambient Temperature		
2834	VSD: Converter Heatsink Temperature		
2835	VSD: Phase A Heatsink Temperature		
2836	VSD: Phase B Heatsink Temperature		
2837	VSD: Phase C Heatsink Temperature		
2838	VSD: Is Communications OK		
2839	VSD: Panel to ACC Comms Error Count		
2840	VSD: ACC to Panel Comms Error Count		
2841	VSD: ACC to VSD Comms Error Count		
2842	VSD: VSD to ACC Comms Error Count		
2843	VSD: VSD to Filter Comms Error Count		
2844	VSD: Filter to ACC Comms Error Count		
2845	ACC: Delta P/P		
2846	ACC: Stability Limit		

TABLE 4 - MASTER SLOT NUMBERS LIST FORUSE WITH TREND FEATURE (CONT'D)

SLOT NUMBER	DESCRIPTION		
2847	ACC: Surge Margin		
2848	ACC: Manual Surge Command		
2849	ACC: Surge Map Count		
2850	ACC: Surge Type		
2857	ACC: Surge Map Point Count		
2858	ACC: Surge Map Delta P/P		
2859	ACC: Surge Map Output Frequency		
2860	ACC: Surge Map PRV Position		
2861	Filter: Is Filter Installed		
2862	Filter: Is Operation Inhibited		
2863	Filter: Is Filter Running		
2864	Filter: Is Precharge Contactor Closed		
2865	Filter: Is Supply Contactor Closed		
2866	Filter: Phase Rotation		
2867	Filter: Motor HP		
2868	Filter: Supply kVA		
2869	Filter: Total Power Factor		
2870	Filter: DC Bus Voltage		
2871	Filter: Heatsink Temperature		
2872	Filter: L1 - L2 RMS Voltage		
2873	Filter: L2 - L3 RMS Voltage		
2874	Filter: L3 - L1 RMS Voltage		
2875	Filter: L1 - N Peak Voltage		
2876	Filter: L2 - N Peak Voltage		
2877	Filter: L3 - N Peak Voltage		
2878	Filter: L1 Total Harmonic Distortion		
2879	Filter: L2 Total Harmonic Distortion		
2880	Filter: L3 Total Harmonic Distortion		
2881	Filter: L1 RMS Filter Current		
2882	Filter: L2 RMS Filter Current		
2883	Filter: L3 RMS Filter Current		
2884	Filter: L1 RMS Supply Current		
2885	Filter: L2 RMS Supply Current		
2886	Filter: L3 RMS Supply Current		
2887	Filter: L1 Total Demand Distortion		
2888	Filter: L2 Total Demand Distortion		
2889	Filter: L3 Total Demand Distortion		
2890	Filter: Maximum Total Harmonic Distortion		
2891	Filter: Maximum Total Demand Distortion		
8192	Oil: Pump Pressure		
8193	Oil: Sump Pressure		
8194	Oil Seal Lube: Is Control Enabled		
8195	Oil Seal Lube: Time To Next Lube		

TABLE 4 - MASTER SLOT NUMBERS LIST FORUSE WITH TREND FEATURE (CONT'D)

SLOT NUMBER	DESCRIPTION
8196	Oil Seal Lube: Time Left
8197	VSOP: Speed Command
8198	VSOP: Control Mode
8199	VSOP: Manual Command Frequency
8200	VSOP: Is Pulldown In Effect
8201	VSOP: Pulldown Time Remaining
8202	VSOP: Target Setpoint
8203	VSOP: Pressure Setpoint
8204	VSOP: Control Period
8205	Refrigerant Level: Is Control Enabled
8206	Refrigerant Level: Position
8207	Refrigerant Level: Is Valve Closing
8208	Refrigerant Level: Is Valve Opening
8209	Refrigerant Level: Control Mode
8210	Refrigerant Level: Is Pulldown In Effect
8211	Refrigerant Level: Pulldown Time Remaining
8212	Refrigerant Level: Target Setpoint
8213	Refrigerant Level: Setpoint
8214	Refrigerant Level: Period
8215	Refrigerant Level: Proportional Limit Close
8216	Refrigerant Level: Proportional Limit Open
8217	Refrigerant Level: Rate Limit Close
8218	Refrigerant Level: Rate Limit Open
8221	HSTB: Oil Drain Temperature (Before C.MLM.01.03)
8222	HSTB: Is Solenoid Installed
8223	HSTB: Is Solenoid On
8224	HSTB: Proximity Position
8225	HSTB: Proximity Differential
8226	HSTB: Proximity Reference Position
8280	Stall Detector Board output voltage
8281	VGD open
8282	VGD close
8317	Stall DC Pressure Voltage

2

THIS PAGE INTENTIONALLY LEFT BLANK

SECTION 3 - DISPLAY MESSAGES

The Status Bar of the display contains a Status Line and, beneath it a Details Line. The Status Line contains a message describing the operating state of the chiller; whether it is stopped, running, starting or shutting down. The Details Line displays Warning, Cycling, Safety, Start Inhibit and other messages that provide further details of the Status Bar messages. The Status Messages listed below are displayed on the Status Line. All other messages are displayed on the Details Line.

To aid in the meaning of the message, messages are displayed in different colors as follows:

MESSAGE	COLOR
Normal Operation	Green
Warning	Yellow
Cycling Shutdown	Orange
Safety Shutdown	Red

For messages specific to the Variable Speed Drive, Medium Voltage Variable Speed Drive, Solid State Starter and Medium Voltage Solid State Starter, refer to the applicable service manual as follows: Variable Speed Drive – Service Instructions (Form 160.00-M4); Medium Voltage Variable Speed Drive – Service (Form 160.00-M6); Solid State Starter (Mod B) – Operation and Maintenance (Form 160.00-O2); Medium Voltage Solid State Starter – Service (Form 160.00-M5).

STATUS MESSAGES

System Ready To Start

The chiller is shut down but will start upon receipt of a local or remote start signal.

Cycling Shutdown – Auto Restart

The chiller is shut down on a cycling shutdown. The cause of the shutdown is still in effect and is displayed on the Details Line of the Status Bar. The chiller will automatically restart when the cycling condition clears.

Safety Shutdown – Manual Restart

The chiller is shut down on a safety shutdown. The cause of the shutdown is still in effect and is displayed on the Details Line of the Status Bar. The chiller can be started after the safety condition clears and the Operator moves the Compressor Switch to the Stop-Reset (O) position.

System Prelube

A chiller start has been initiated and the pre-start lubrication is being performed. The prelube duration is either 50 seconds or 180 seconds, as configured with a Microboard Program Switch. The prelube duration must never be changed by anyone other than a qualified Service Technician. The standard prelube duration is 50 seconds.

System Run

The chiller is running under the condition described in the Details Line of the Status Bar.

System Run – Cooling Mode

(Software version C.OPT.01.23.307 and later)

The chiller is running with Heat Pump Duty enabled and the Heat Pump Duty Operational mode setpoint set to Cooling mode. In this mode, the Heat Pump is controlling the Leaving Chilled Liquid Temperature to the Leaving Chilled Liquid Temperature Setpoint.

System Run – Heating Mode

(Software version C.OPT.01.23.307 and later)

The chiller is running with Heat Pump Duty enabled and the Heat Pump Duty Operational mode setpoint set to Heating mode. In this mode, the Heat Pump is controlling the Leaving Condenser Liquid Temperature to the Leaving Condenser Liquid Temperature Setpoint.

System Coastdown

The chiller has shut down and the Post-run lubrication is being performed. The Coastdown duration varies according to the microboard and setup. On 031-01730-000 microboards, it is 150 seconds for electric motor applications (standard); 15 minutes for Steam Turbine applications (enhanced), as determined by Program Jumper JP36. On 031-02430-000/001 microboards, the duration varies according to the software used. With software version C.OPT.01.16.XXX (and later), the Coastdown duration is determined by the setting of the Coastdown (standard or enhanced) and Coastdown Time Setpoints. If the Coastdown setpoint is set to enhanced (steam turbine applications), it is 15 minutes. If set to standard (electric motor applications), it is programmable over a range determined by the Chiller Style/Compressor Setpoint (for style F/J7 and G/K6K7, the range is 240 (default) to 900 seconds. All others, the range is 150 (default) to 900 seconds). With earlier software versions, the duration is fixed at 150 seconds.

Start Inhibit

The chiller is prevented from being started due to the reason displayed on the Details Line of the Status Bar.

Vanes Closing Before Shutdown

Displayed while the Pre-rotation Vanes are closing during a Soft Shutdown. During Soft Shutdowns, the Vanes are driven fully closed prior to shutting down the compressor. When the Vane Motor End Switch closes, indicating the Vanes have fully closed (or 3.5 minutes have elapsed, whichever occurs first), the Run Signal is removed from the compressor motor starter and a System Coastdown is performed. Soft Shutdowns are initiated by the following:

- 1. Leaving Chilled Liquid Low temperature
- 2. Remote Stop
- 3. Multi-Unit Cycling Contacts Open
- 4. System Cycling Contacts Open
- 5. Control Panel Schedule
- 6. Operator Initiated at Keypad (Flash Memory Card version C.MLM.01.06.xxx and later)

While the Vanes are closing during any Soft Shutdown, if a Local Stop is initiated with the Compressor Switch or any faults other than those listed above occur, the Soft Shutdown is terminated and it will immediately perform a System Coastdown.

RUN MESSAGES

Leaving Chilled Liquid Control

The chiller is running, controlling the Leaving Chilled Liquid to the Leaving Chilled Liquid Temperature Setpoint. There are no system conditions inhibiting this operation.

Heat Pump – Leaving Chilled Liquid Control

(Software version C.OPT.01.23.307 and later)

The Heat Pump is running, controlling the Leaving Chilled Liquid Temperature to the Leaving Chilled Liquid Temperature Setpoint. In this mode, Heat Pump Duty is enabled and the Heat Pump Duty Operational mode setpoint is set to Cooling mode. (Software version C.OPT.01.23.307 and later)

The Heat Pump is running, controlling the Leaving Condenser Liquid Temperature to the Leaving Condenser Liquid Temperature Setpoint. In this mode, Heat Pump Duty is enabled and the Heat Pump Duty Operational mode setpoint is set to Heating mode.

Current Pulldown Limit

The Pulldown Demand Limit Setpoint timer is in effect and the Compressor Motor current is greater than or equal to the Pulldown Demand Current Limit Setpoint value. The Pre-rotation Vane operation is being inhibited as described in Motor – High Current Limit message below.

Motor – High Current Limit

The Compressor Motor current is greater than or equal to the local or remote Current Limit Setpoint. The Current Limit Setpoint is programmed over a range of 30 to 100% of the Chiller Full Load Amps (FLA). When the motor current increases to the Inhibit Open threshold, the Pre-rotation Vanes are inhibited from further opening. This prevents a further current rise. If the current continues to rise to the Start Close threshold, the Vanes begin closing until the current falls to the Stop Close threshold. Automatic Vane operation is resumed and this message automatically clears when the motor current decreases to the Allow Open threshold. The thresholds are different for the various motor starter applications. To allow field calibration of the Solid State Starter (Mod A) Logic Board or CM-2 Current Module, pressing the Pre-rotation Vanes OPEN key in SERVICE access level, starts a 10 minute timer during which the current limit thresholds are elevated. See the following table:

	MOTOR CURRENT (%FLA)			
VANE CONTROL	ELECTRO- MECHANICAL/ SOLID STATE STARTER	VSD	SERVICE MODE	
On rise, inhibit open	100	100	107	
On fall, allow open	98	98	106	
On rise, start close	104	103	110	
On fall, stop close	102	101	109	

An example of current limit is as follows: If a Solid Sate Starter chiller FLA is 100 Amps, and the Current Limit Setpoint is 50%, the following will occur:

- 50 Amps inhibit vane open
- 52 Amps vanes begin closing
- 51 Amps vanes stop closing
- 49 Amps allow automatic vane control

With software versions prior to C.OPT.01.16.xxx, this message is also displayed when the Compressor Motor Variable Speed Drive has not yet reached full speed after having been commanded to do so in Manual Speed Control mode.

Load Control Mode

(Software version C.OPT.01.16.xxx and later)

Access Level Required: SERVICE

The Compressor Motor Variable Speed Drive has not yet reached full speed after having been commanded to do so in Manual Speed Control mode. While this is displayed, the Pre-rotation Vanes are inhibited from further opening.

START INHIBIT MESSAGES

Anti-Recycle XX min/Sec

The chiller is inhibited from starting because the 30 minute anti-recycle time has not yet elapsed. Time remaining is displayed.

Vane Motor Switch Open

The chiller is inhibited from starting because the Prerotation Vanes are not fully closed.

Motor – Current >15% FLA

This start inhibit is instantaneously set whenever the chiller is not running and a motor current of greater than 15% FLA is detected. The oil pump is started as soon as this fault is detected. The starting frequency for the Variable Speed Oil Pump is 45.0 Hz. The start inhibit is released when the motor current decreases to greater than or equal to 15% FLA and the Compressor Switch is placed in the Stop-Reset (O) position. A full System Coastdown is performed when this fault is released. With software version C.MLM.01.10D.xxx (and earlier) or C.OPT.01.10D.xxx (and earlier), the motor current must exceed 15% FLA for 10 continuous seconds before the start inhibit is set.

VSD – Frequency > 0 Hz

(Software version C.MLM.01.14.xxx (and later) or C.OPT.01.14.306 (and later))

This start inhibit is set whenever the chiller is shutdown and a Compressor Motor Variable Speed Drive (VSD) Output Frequency of greater than 0 Hz is detected. This fault is released and the chiller can be started after the frequency is at 0 Hz and the Compressor Switch is placed in the Stop-Reset (O) position. The oil pump is started (with a starting frequency of 45 Hz) as soon as this fault is detected. A System Coastdown is performed whenever this fault is released.

LCSSS – High Temperature Phase X - Stopped

(Mod. B Solid State Starter only)

The chiller is stopped and the Liquid Cooled Solid State Starter Logic/Trigger Board has detected that the temperature of phase A, B, or C (designated as X in this message) Silicon Controlled Rectifier (SCR) Module is greater than 110°F. The starter cooling pump will run and the chiller will be inhibited from starting until the temperature decreases to less than 109°F.

WARNING MESSAGES

Warning – Real Time Clock Failure

During the initialization process that occurs when power is applied to the Control Center, test data is written to a location in the BRAM battery backed memory device (IC location U52 on Microboard). This data is then read from the BRAM and compared to the test data. If the read data is not the same as that which was written to the device, it is assumed the BRAM and Real Time Clock operation is defective and this message is displayed. The BRAM should be replaced by a qualified Service Technician. This message automatically clears when the BRAM problem has been solved.

Warning – Condenser or Evaporator XDCR Error

The Evaporator Pressure transducer is indicating a higher pressure than the Condenser pressure transducer after the chiller has been running for 10 minutes. This is indicative of a Condenser or Evaporator transducer failure. This message will be displayed until the condition clears and the WARNING RESET Keypad key is pressed in Operator (or higher) access mode. Condition not checked in Brine mode. 3

Warning - Refrigerant Level Out Of Range

(Flash Memory Card version C.MLM.01.05C.xxx and earlier and "P" compressors with C.MLM.04.01B and earlier)

The output of the condenser refrigerant level sensor is greater than 5.1 VDC. This is indicative of a level sensor failure. While this condition exists, the refrigerant variable orifice is driven to the full open position. This message automatically clears when the refrigerant level sensor output is within range.

Warning – Standby Lube – Low Oil Pressure

A minimum of 15 PSID of oil pressure was not achieved in the first 30 seconds of a Standby Lubrication cycle, or the pressure decreased below this value during the remainder of the cycle. This message will be displayed and no further Standby Lubrications will be performed until the WARNING RESET key is pressed in Operator (or higher) access mode.

With software version C.OPT.01.23.307 (and later), this warning is also set when either the Pump Oil Pressure transducer or the Sump Oil Pressure transducer is less than 2 psig when a Standby Lube is requested by automatic control. This inhibits the Standby Lube cycle when the chiller is open to atmosphere.

Warning – Setpoint Override

A blank BRAM battery-backed memory device (IC location U52 on Microboard) or a failure of this device was detected during the initialization process that occurs when power is applied to the Control Center. Due to this failure, any or all of the programmed Setpoints could have been corrupted. Therefore, all Setpoints have been automatically changed to their Default values. All Setpoints will have to be programmed to their desired values. This message will clear when the WARNING RESET key is pressed in Operator (or higher) access mode.

Warning – Condenser – High Pressure Limit

The Condenser Pressure exceeds the High Pressure Warning Setpoint threshold, programmed by a Service Technician logged in at SERVICE access level. While this condition is in effect, the Pre-rotation Vanes are inhibited from further opening. This message automatically clears and the Vanes are permitted to open when the condenser pressure decreases to 5 psig below the Setpoint.

Warning – Evaporator – Low Pressure Limit

The Evaporator Pressure has decreased to the Warning threshold. This threshold is fixed in Water cooling applications. In Brine cooling applications, the threshold is a fixed amount above the programmable safety shutdown threshold. The Safety threshold in Brine applications is determined by the Brine solution and is determined by the YORK Factory. While this condition is in effect, the Pre-rotation Vanes are inhibited from further opening. This message automatically clears and the Vanes are permitted to open when the Evaporator Pressure increases to the reset value.

	WARNING THRESHOLD (psig)		RESET THRESHOLD (psig)		
	WATER	BRINE	WATER	BRINE	
R22	56.2	+1.9 more than Safety Setpoint	57.5	+3.2 more than Safety Setpoint	
R134a	27.0	+2.0 >Safety Setpoint	28.0	+3.0>Safety Setpoint	

Warning – Vanes Uncalibrated – Fixed Speed

The Compressor Motor Variable Speed Drive (VSD) is operating Fixed Speed (full speed) mode because the Pre-rotation Vanes position potentiometer calibration has not been performed.

Warning – Harmonic Filter – Operation Inhibited

The Compressor Motor Variable Speed Drive (VSD) Harmonic Filter has been inhibited. This message appears when the harmonic filter is inhibited on the Variable Speed Drive screen.

Warning – Harmonic Filter – Data Loss

Communications between the Harmonic Filter Logic Board and the Compressor Motor Variable Speed Drive VSD Logic Board or the Adaptive Capacity Control Board is not occurring. While this condition exists, all filter related parameters are displayed as X's. This message automatically clears when communications are restored.

Warning – Harmonic Filter – Input Frequency Range

The power line frequency detected by the Compressor Motor Variable Speed Drive (VSD) Harmonic Filter is outside the range of 58 Hz to 62 Hz (60 Hz), or 48 Hz to 52 Hz (50 Hz). While this condition exists, all filter related parameters are displayed as Xs. This message automatically clears when the line frequency is within range.

Warning – Harmonic Filter – Not Running

(Software version C.OPT.01.23.307 and later)

This warning is set when all of the following are true for 20 continuous seconds:

- Chiller is running
- Filter is enabled
- Filter present status is true
- Run Time greater than 20 seconds
- Filter operating mode is stopped

This warning is released when the chiller is stopped, but will be displayed until manually cleared using the WARNING RESET key when logged in at OPERA-TOR (or higher) access level.

Warning – Vanes Uncalibrated

The Hot Gas Bypass feature is enabled, but the Prerotation Vanes calibration procedure has not yet been performed.

Warning – External I/O – Serial Communications

Serial communications between the Microboard and the optional Analog I/O Board has been interrupted for at least 20 seconds.

Warning – Excess Surge Detected

(Flash Memory Card version C.MLM.01.05.xxx and later)

(Applies only if Surge Protection Shutdown feature is Disabled)

The Surge Window Count has exceeded the Count Limit. Message can be manually cleared after the Surge Window Count is less than or equal to the Count Limit, or the Shutdown feature is enabled or the chiller is stopped. To clear message press WARNING RESET key on HOME Screen when logged in at OPERATOR (or higher) access level.

Warning – Liquid Level Setpoint not Achieved

(Software version C.OPT.01.25C.308 (and later))

Automatic reset warning message is displayed when the Refrigerant Level is not within + or -15% of the Refrigerant Level Setpoint for 10 continuous minutes after the chiller has been running for 30 minutes. It will clear when within the 15% range or the chiller is stopped.

Warning – Surge Protection – Excess Surge Limit

(Flash Memory Card version C.MLM.01.05.xxx and later)

(Applies only if Surge Protection Extended Run feature is Enabled)

Displayed during the Surge Protection 10 minute Extended Run period. This period begins when the Surge Window Count exceeds the Count Limit. During this period, the Pre-rotation Vanes are driven closed. When 10 minutes have elapsed, this message and the Prerotation Vanes load inhibit are automatically cleared. Message and load inhibit are also cleared when the chiller is shutdown.



If the optional Hot Gas Bypass feature is enabled, the valve position must be at 100% before the Extended Run is implemented. If the chiller is chiller is equipped with a Compressor Motor Variable Speed Drive, the output frequency must be at full speed (50 Hz/60 Hz) before this control can be implemented.

Warning – Condenser Or VGD Sensor Failure

(Software version C.MLM.01.14.xxx (and later) or C.OPT.01.14.306 (and later))

The difference between the Stall Pressure transducer output and the Condenser Pressure transducer output has exceeded 0.28 VDC for 3 continuous minutes while the chiller was running. This feature verifies the operation of the Stall transducer and the Condenser transducer. Since both transducers are measuring essentially the same pressure, both outputs should be within the specified tolerance. This message must be manually cleared. It will be displayed until the transducer outputs are within the acceptable range of each other and the WARNING RESET key in SERVICE access level.

While this message is displayed, the Variable Geometry Diffuser (VGD) is driven to the full open position and held there until this warning is manually cleared. When cleared, the VGD returns normal operation.

Warning – Loss of Subcooler Liquid Seal

(Software version C.OPT.01.25C.308 (and later))

This Warning is displayed if the chiller has been running for 30 minutes or more and the Drop Leg Temperature is less than the Return Condenser Liquid Temperature continuously for two minutes. Setting the Drop Leg Sensor installed to Disabled will prevent this warning from being displayed.

Warning – Conditions Override VGD

(Software version C.MLM.01.14.xxx (and later) or C.OPT.01.14.306 (and later))

An extreme stall condition has been detected while the chiller was running. An extreme stall condition exists when the Stall Detector Voltage (output of the Stall Detector Board) exceeds twice the High Limit setpoint for the duration programmed in the Extreme Stall Duration Setpoint (10 to 20 minutes). While this message is displayed, the compressor Variable Geometry Diffuser (VGD) is driven to the full open position and held there until the message is manually cleared. This protects the VGD ring from possible damage from an extreme stall condition. This message can be cleared after the Stall Detector Voltage returns to less than two times the High Limit Setpoint and the WARNING RESET key is pressed in SERVICE access level.

The extreme stall condition is not checked under the following conditions:

- While the VGD is in manual control mode.
- While the VGD is fully closed (VGD Limit Switch closed).
- While the Pre-rotation Vanes position is greater than the PRV VGD INHIBIT Setpoint.

Warning - Motor Bearing Lube Suggested

(Software version C.MLM.01.14.xxx (and later) or C.OPT.01.14.306 (and later) or Y.OPT.01.00.308 up to Y.OPT.01.00C.308.)

The Operating Hours Since Last Motor Lubrication has exceeded 1000 hours. This will be displayed until manually cleared by the Operator or the Operating Hours Since Last Motor Lubrication exceed 1200 hours, whereupon it is replaced by the message WARNING - MOTOR BEARING LUBE REQUIRED below. The Operator clears this message by entering his/her initials, name or user ID in OPERATOR access level (or higher) using the MOTOR LUBE ACKNOWLEDGE key on the MOTOR LUBRICATION Screen. See the Motor Lubrication Screen 1 on page 104 for entry instructions. The date and time of this entry is automatically logged as the Date Of Last Motor Lubrication and Time Of Last Motor Lubrication. It also resets the Operating Hours Since Last Lubrication to zero. The date this warning occurs is stored as the Date Of Last Motor Lubrication Warning Or Fault. With software version C.OPT.01.16.xxx (and later), this warning message will not be displayed if the Auto Lube Setpoint on the MOTOR LUBRICATION Screen enabled.

Warning – Motor Bearing Lube Suggested

(This feature applies to software version Y.OPT.01.00D.308 and later.)

The Operating Hours Since Last Motor Lubrication has exceeded set hours minus 200. This will be displayed until manually cleared by the Operator or the Operating Hours Since Last Motor Lubrication exceed the set hours, whereupon it is replaced by the message WARNING - MOTOR BEARING LUBE REQUIRED below. The Operator clears this message by entering his/her initials, name or user ID in OPERATOR access level (or higher) using the MOTOR LUBE AC-KNOWLEDGE key on the MOTOR LUBRICATION Screen. See the Motor Lubrication Screen 2 on page 107 for entry instructions. The date and time of this entry is automatically logged as the Date Of Last Motor Lubrication and Time Of Last Motor Lubrication. It also resets the Operating Hours Since Last Lubrication to zero. The date this warning occurs is stored as the Date Of Last Motor Lubrication Warning Or Fault. This warning message will not be displayed if the Auto Lube Setpoint on the MOTOR LUBRICATION Screen enabled.

Warning – Motor Bearing Lube Required

(Software version C.MLM.01.14.xxx (and later) or C.OPT.01.14.306 (and later), or Y.OPT.01.00.308 up to Y.OPT.01.00C.308.)

The Operating Hours Since Last Motor Lubrication has exceeded 1200 hours. This replaces WARNING - MO-TOR BEARING LUBE SUGGESTED above. This is displayed until manually cleared by the Operator or the Operating Hours Since Last Motor Lubrication exceed 1400 hours, whereupon it is replaced by the message Motor - Lack Of Bearing Lubrication below. The Operator clears this message by entering his/her initials, name or user ID in OPERATOR access level (or higher) using the MOTOR LUBE ACKNOWLEDGE key on the MOTOR LUBRICATION Screen. See the Motor Lubrication Screen 1 on page 104 for entry instructions. The date and time of this entry is automatically logged as the Date Of Last Motor Lubrication and Time Of Last Motor Lubrication. It also resets the Operating Hours Since Last Lubrication to zero. The date this warning occurs is stored as the Date Of Last Motor Lubrication Warning Or Fault. With software version C.OPT.01.16.xxx (and later), this warning message will not be displayed if the Auto Lube Setpoint on the MOTOR LUBRICATION Screen enabled.

Warning – Motor Bearing Lube Required

(This feature applies to software version Y.OPT.01.00D.308 and later.)

The Operating Hours Since Last Motor Lubrication has exceeded the set hours. This replaces WARNING -MOTOR BEARING LUBE SUGGESTED above. This is displayed until manually cleared by the Operator or the Operating Hours Since Last Motor Lubrication exceed the set hours plus 200, whereupon it is replaced by the message Motor - Lack Of Bearing Lubrication below. The Operator clears this message by entering his/her initials, name or user ID in OPERATOR access level (or higher) using the MOTOR LUBE AC-KNOWLEDGE key on the MOTOR LUBRICATION Screen. See the Motor Lubrication Screen 2 on page 107 for entry instructions. The date and time of this entry is automatically logged as the Date Of Last Motor Lubrication and Time Of Last Motor Lubrication. It also resets the Operating Hours Since Last Lubrication to zero. The date this warning occurs is stored as the Date Of Last Motor Lubrication Warning Or Fault. This warning message will not be displayed if the Auto Lube Setpoint on the MOTOR LUBRICATION Screen enabled.

Warning – Motor – High Winding Temperature

(Software version C.OPT.01.22.307 and later)

This warning occurs when any of the enabled Motor Winding Temperatures exceeds the following: [High Winding Temperature Shutdown threshold - 18°F] for 3 continuous seconds. This warning will automatically clear when all winding temperatures decrease below the warning threshold. The value programmed for the above threshold is displayed as High Winding Temperature Shutdown on the MOTOR SETPOINTS Screen. It is programmed with the Winding Setup Setpoint on that screen. This warning not occur when the Winding Temperature Protection Setpoint is set to Disabled on the MOTOR DETAILS Screen. Also, it will not act on any RTD input registering as an open RTD or any individual winding temperature sensor that has been disabled with the Temperature Disable Setpoint on the MOTOR SETPOINTS Screen.

Warning – Motor – High Bearing Temperature

(Software version C.OPT.01.22.307 and later)

This warning occurs when either of the enabled motor bearing temperatures exceeds the programmed High Bearing Temperature Warning for 3 continuous seconds. This warning will automatically clear when all bearing temperatures decrease below the warning threshold. The value programmed for this threshold is displayed as High Bearing Temperature Warning on the MOTOR SETPOINTS Screen. It is programmed with the Bearing Setup Setpoint on that screen. This warning not occur when the Bearing Temperature Protection Setpoint is set to Disabled on the MOTOR DE-TAILS Screen. Also, it will not act on any RTD input registering as an open RTD.

Warning – Motor – Bearing Vibration Baseline Not Set

(Software version C.OPT.01.22.307 and later)

Displayed until both the Shaft End and Opposite Shaft End motor bearing vibration baseline values are entered on the MOTOR DETAILS Screen. This can be done either manually with the Manual Baseline Setpoint or automatically with the AUTO BASELINE key on that screen. While this message is displayed, the vibration baseline values are set to X.X.

Warning – Motor – High Bearing Vibration

(Software version C.OPT.01.22.307 and later)

Either the Shaft End or Opposite Shaft End motor bearing vibration has exceeded the value programmed for the High Vibration Warning Setpoint for the programmed number of Delay seconds. The warning will automatically clear when both vibration values decrease below the warning threshold. This warning does not occur when the Motor Vibration Protection Setpoint is set to Disabled on the MOTOR DETAILS Screen or while the WARNING – MOTOR – BEARING VIBRATION BASELINE NOT SET warning is displayed.

ROUTINE SHUTDOWN MESSAGES

Remote Stop

A shutdown command has been received from a remote device. Remote stop commands can be received in Digital Remote mode via I/O Board TB4-7/8 or in ISN Remote mode via the E-Link Gateway serial communications. If the chiller is running when this occurs, the Pre-rotation Vanes are driven fully closed prior to shutting down the chiller.

Local Stop

A local shutdown command has been received by placing the Keypad Start-Run-Stop/Reset switch in the Stop (O) position.

Place Compressor Switch In Run Position

The Control Center is in either Digital or ISN Remote mode. The Operator is requested to place the Compressor Switch in the RUN position. The Control Center will not accept a Remote start/stop command unless the switch is in the RUN position.

CYCLING SHUTDOWN MESSAGES

Multiunit Cycling – Contacts Open

The Multiunit Cycling contacts connected to I/O Board TB4-9, have opened to initiate a cycling shutdown. If the chiller is running when this occurs, the Pre-rotation Vanes are driven fully closed prior to shutting down the chiller. The chiller will automatically restart when the contacts close.

System Cycling – Contacts Open

The System Cycling contacts connected to I/O Board TB4-13, have opened to initiate a cycling shutdown. If the chiller is running when this occurs, the Pre-rotation Vanes are driven fully closed prior to shutting down the chiller. The chiller will automatically restart when the contacts close.

Oil – Low Temperature Differential

The chiller is prevented from starting because for one of the following reasons. The chiller will automatically restart when the conditions have been satisfied. In software version C.OPT.01.23.307 (and later), this condition is only checked while the chiller is stopped. In previous software versions, it is checked when stopped and during the first 10 seconds of prelube.

The chiller has been shut down for less than or equal to 30 minutes and the oil temperature minus the condenser saturation temperature is less than 30°F.

-OR-

The chiller has been shut down for greater than 30 minutes and the oil temperature minus the condenser saturation temperature is less than 40°F.

-OR-

Following a power failure, upon restoration of power, the oil temperature minus the condenser saturation temperature is less than 40°F.

Oil – Low Temperature

The oil temperature has decreased to less than 55° F. The chiller will automatically restart when the temperature increases to greater than 55.0° F and is greater than the Condenser Saturated temperature by 30° F or 40° F, as described above in the Oil – Low Temperature Differential message description.

Control Panel – Power Failure

A Control Power failure has occurred. If the power failure occurred while the chiller was running, it will automatically restart when power is restored. However, if the power failure duration was less than the duration of the applicable coastdown period (2.5 minutes standard; 15 minutes steam turbine) when power is restored, the remainder of the coastdown will be performed, prior to the chiller starting. This message can indicate a Cycling (auto-restart after power failure) or Safety (manual restart after power failure) shutdown, depending upon Control Center configuration. It indicates a cycling shutdown when displayed in orange characters; safety shutdown when displayed in red characters. The Control Center is configured for auto-restart or manual restart after power failure by a qualified Service Technician following instructions in OptiView Control Center - Service Instructions (Form 160.54-M1).

Leaving Chilled Liquid – Low Temperature

The Leaving Chilled Liquid Temperature has decreased to the programmed Shutdown Temperature Setpoint. If the chiller is running when this occurs, the Pre-rotation Vanes are driven fully closed prior to shutting down the chiller. The chiller will automatically restart when the temperature increases to the programmed Restart Temperature Setpoint.

If the chiller is operating in Heat Pump Heating mode, (Heat Pump Duty is enabled, and the Heat Pump Operational mode setpoint is set to Heating), there is additional logic that will cause this Shutdown when the Leaving Chilled Liquid Temperature (LCHLT) decreases below the programmed Heating LCHLT Shutdown Temperature Setpoint. For details of this setpoint, see the *Heat Pump Screen on page 37*.

Leaving Condenser Liquid – High Temperature

(Software version C.OPT.01.23.307 and later)

The Leaving Condenser Liquid Temperature has increased to the programmed Leaving Condenser Liquid Temperature Cycling Offset - Shutdown Setpoint. This shutdown is only applicable to Heat Pump Duty enabled and operating in Heating mode (Heat Pump Operational Setpoint set to Heating mode). See *Heat Pump Screen on page 37*. Anytime the Leaving Condenser Liquid Temperature Setpoint is decreased, the shutdown threshold becomes 125°F for the next 10 minutes. After 10 minutes have elapsed, the shutdown threshold becomes the programmed setpoint value. The Heat Pump will automatically restart when the temperature decreases to the programmed Leaving Condenser Liquid Temperature Cycling offset – Restart Setpoint.

Leaving Chilled Liquid – Flow Switch Open

The Chilled Liquid Flow Switch has remained open for 5 continuous seconds (2 seconds with software version C.OPT.01.15A.xxx and earlier) while the chiller was running or failed to close during the System Prelube period. The chiller will automatically restart when the flow switch closes.

With software version C.OPT.01.23.307 (and later), while this cycling shutdown is active, the evaporator pump relay contacts (TB2-44/45) remain closed until the chiller is given a stop command or has another fault. With all previous software versions, these contacts open at completion of coastdown.

Condenser – Flow Switch Open

The condenser water flow switch has remained open for 30 continuous seconds (2 seconds with software version C.OPT.01.15A.xxx and earlier) while the chiller was running. This check is bypassed for the first 30 seconds of System Run. The chiller will automatically restart when the flow switch closes.

With software version C.OPT.01.23.307 (and later), while this cycling shutdown is active, the condenser pump contacts (TB2-150/151) remain closed until the chiller is given a stop command or has another fault. With all previous software versions, these contacts open at completion of coastdown.

Motor Controller – Contacts Open

The CM-2 Current Module (Electromechanical starter applications) or Solid State Starter Logic Board (Mod A Solid State Starter applications) has shutdown the chiller. When detecting a fault condition that places the starter or motor at risk, these devices open the Motor Controller contacts "CM" (located on the respective device and connected between TB6-16 and TB6-53 in the Control Center) to initiate a shutdown. Since there are several different faults that are monitored, LED's on the respective device illuminate to identify the specific fault that has occurred. Refer to Solid State Starter (Mod A) – Operation and Maintenance (Form 160.46-OM3.1) for details of Mod A Solid State Starter initiated shutdowns and OptiView Control Center – Service Instructions (Form 160.54-M1) for CM-2 initiated shutdowns. The chiller will automatically restart when the Motor Controller contacts close. On some shutdowns, the respective device automatically closes the contacts when the fault condition clears. Other shutdowns require the Operator to perform a Manual Reset at the respective device.

DEVICE	MANUAL RESET FAULT	AUTOMATIC RESET FAULT
CM-2	Overload	None
Module	Overload	Phase Rotation/Loss
Solid State Starter	High Temp (more than 212°F)	High Temp start inhibit (more than 110°F)
	Fault Current	Trigger Board Out-of-Lock

Motor Controller – Loss Of Current

The Compressor Motor current decreased to 10% Full Load Amps (FLA) for 25 continuous seconds while the chiller was running. This could be caused by the starter de-energizing during run or a defect in the motor current feedback circuitry to the Control Center. The chiller will automatically restart at the completion of System Coastdown.

Power Fault

The CM-2 Current Module (Electromechanical Starter applications) or Solid State Starter Logic Board (Mod A Solid State Starter applications) has shutdown the chiller because it detected a fault condition that places the motor at risk. These devices open and close the Motor Controller "CM" contacts (located on the respective device and connected between TB6-16 and TB6-53 in the Control Center) in less than 3 seconds to initiate the shutdown and produce this message. An LED on the respective device illuminates to identify the specific fault that has occurred. Refer to Solid State Starter (Mod A) – Operation and Maintenance (Form 160.46-OM3.1) for details of Solid State Starter initiated shutdowns and OptiView Control Center - Service Instructions (Form 160.54-M1) for CM-2 initiated shutdowns. The chiller will automatically restart when the contacts close

DEVICE	SHUTDOWN
CM-2 Module	Power Fault
Solid State Starter	Power Fault
	Half Phase

Control Panel – Schedule

The programmed Daily Schedule Setpoint has shutdown the chiller. If this occurs while the chiller is running, the Pre-rotation Vanes are driven fully closed prior to shutting down the chiller. The chiller will automatically restart at the next scheduled start time.

Starter – Low Supply Line Voltage (Mod A Solid State Starter)

The voltage in any phase of the AC Power Line Voltage supplying the Solid State Starter has decreased to the low line voltage threshold for 20 continuous seconds. The chiller will automatically restart when the voltage returns to the restart level. The thresholds are as follows:

SUPPLY VOLTAGE RANGE (VOLTS)	SHUTDOWN (VOLTS)	RESTART (VOLTS)
380	305	331
400	320	349
415	335	362
440-480	370	400
550-600	460	502
Supply Voltage Range disabled	none	N/A

Starter – High Supply Line Voltage (Mod A Solid State Starter)

The voltage in any phase of the AC Power Line Voltage supplying the Solid State Starter has increased to the high line voltage threshold for 20 continuous seconds. The chiller will automatically restart when the voltage returns to the restart level. The thresholds are as follows:

SUPPLY VOLTAGE RANGE (VOLTS)	SHUTDOWN (VOLTS)	RESTART (VOLTS)
380	415	414
400	436	435
415	454	453
440-480	524	523
550-600	655	654
Supply Voltage Range disabled	none	N/A

Proximity Probe – Low Supply Voltage

(Style E and earlier chillers with G, H, or J compressors and Style F and later chillers with J or H3 compressors).

This message indicates the +24 VDC power supply voltage to the Proximity Probe has decreased to +19.0 VDC. This is below the minimum level required for reliable operation. The chiller will automatically restart when the voltage increases to greater than or equal to 19.7 VDC.

Oil – Variable Speed Pump – Drive Contacts Open

The Oil Pump Variable Speed Drive has shut down the chiller by opening its status contacts connected to the I/O Board TB3-70. The Drive initiates a shutdown anytime its internal protection circuits will not permit the Drive to run. The contacts remain open until its internal protection circuits are satisfied it is safe to operate. Some Drive initiated shutdowns require AC Power to be cycled to clear the fault. Refer to *OptiView Control Center – Service Instructions (Form 160.54-M1)*. The chiller will automatically restart when the contacts close.

MOD B SOLID STATE STARTER CYCLING SHUTDOWN MESSAGES

LCSSS Initialization Failed

When AC Power is restored to the system after a power failure, an initialization process occurs wherein the Control Center attempts to establish communications through the serial communications link with the Liquid Cooled Solid State Starter. If communications are not established within 10 consecutive attempts, a cycling shutdown is performed and this message is displayed. The Control Center attempts to establish communications until successful.

LCSSS – Serial Communications

After communications have been successfully established in the Initialization process, the Control Center initiates a data transmission to the Liquid Cooled Solid State Starter on the serial communications link every 2 seconds. After these communications have been established, if the Control Center does not receive a reply within 10 consecutive attempts, a cycling shutdown is FORM 160.54-O1 ISSUE DATE: 06/14/2019

performed and this message is displayed. This same cycling shutdown is performed, along with the same message, if the Liquid Cooled Solid State Starter does not receive a response from the Control Center after 10 consecutive attempts to communicate with the Control Center after Initialization has been successfully completed. The Control Center attempts to establish communications until successful.

LCSSS Shutdown – Requesting Fault Data

The Liquid Cooled State Starter Logic/Trigger Board has shut down the chiller but the Control Center has not yet received the cause of the fault from the LC-SSS, via the serial communications link. The LCSSS shuts down the chiller by opening the Motor Controller LCSSS Stop Contacts (K1 relay located on the starter Logic/Trigger Board and connected between TB6-16 and TB6-53 in the Control Center). The Microboard, in the Control Center then sends a request for the cause of the fault to the Logic/Trigger Board over the serial communications link. Since serial communications are initiated every 2 seconds, this message is typically displayed for a few seconds and then replaced with one of the following fault messages.

LCSSS – Stop Contacts Open

See LCSSS Shutdown – Requesting Fault Data on page 171. If the Control Center's Microboard does not receive the cause of a starter initiated shutdown with 20 seconds of the shutdown, it is assumed it is not forth-coming and that message is replaced with this message. The chiller can be started when the Motor Controller LCSSS Stop Contacts close.

A missing interlock jumper between Starter Logic/ Trigger Board J1-1 and J1-12 will also produce this message.

LCSSS – Power Fault

The Liquid Cooled Solid State Starter Logic/Trigger Board has detected that the compressor motor current in one or more phases has decreased to less than 10% of the FLA for a minimum of 1 line cycle. This check is inhibited during the first 4 seconds of System Run and until the motor current is greater than 25% of the Job FLA. The chiller will automatically restart upon completion of System Coastdown.

LCSSS – Low Phase (X) Temperature Sensor

The Liquid Cooled Solid State Starter Logic/Trigger Board has detected that the temperature of the starter phase A, B or C (designated as X in the message) Silicon Controlled Rectifier (SCR) Module has decreased to less than 37°F. This would generally be indicative of a disconnected or defective sensor. If all three SCR Modules are indicating a temperature of less than 37°F, the SCR Module cooling pump turns on. This is accomplished by disconnecting all three sensors. This feature allows Service Technicians to run the cooling pump while filling the cooling system by disconnecting plugs P2, P3 and P4 in the LCSSS.

LCSSS – Run Signal

The Liquid Cooled Solid State Starter receives two start signals from the Control Center simultaneously; one via the serial communications link and one via the start relay TB6-24 in the Control Center. If they are not received within 5 seconds of one another, a cycling shutdown is performed and this message is displayed. This is generally indicative of defective wiring.

LCSSS – Invalid Current Scale Selection

There is an invalid compressor motor current scale jumper combination installed in the Liquid Cooled Solid Starter Logic/Trigger Board J1. Jumper combination determines allowable "100% FLA" setpoint range; 7L-35 to 260A, 14L-65 to 510A, 26L-125 to 850A and 33L-215 to 1050A. The chiller will be permitted to start when the jumpers are configured correctly. Refer to *Solid State Starter (Mod B) – Operation and Maintenance (Form 160.00-O2)* for valid jumper configurations.

LCSSS – Phase Locked Loop

The Liquid Cooled Solid State Starter Logic/Trigger Board phase locked loop circuit was not able to maintain lock with phase A of the power line. This could be caused by a power line anomaly such as sag or jitter. A power line frequency jitter of up to 3 Hz/second can be tolerated. The chiller will automatically restart when lock has resumed.

LCSSS – Low Supply Line Voltage

The Liquid Cooled Solid State Starter Logic/Trigger Board has detected that the compressor motor AC Power Line Voltage, in any phase, decreased below the low line voltage threshold continuously for 20 seconds. The chiller will automatically restart when the voltage in all phases returns to the restart level. The thresholds are as follows:

SUPPLY VOLTAGE RANGE (VOLTS)	SHUTDOWN (VOLTS)	RESTART (VOLTS)
Disabled	None	N/A
200-208	160	174
220-240	185	200
380	305	331
400	320	349
415	335	362
440-480	370	400
550-600	460	502

LCSSS – High Supply Line Voltage

The Liquid Cooled Solid State Starter Logic/Trigger Board has detected that the compressor motor AC Power Line Voltage, in any phase, exceeded the high line voltage threshold continuously for 20 seconds. The chiller will automatically restart when the voltage in all phases returns to the restart level. The thresholds are as follows:

SUPPLY VOLTAGE RANGE (VOLTS)	SHUTDOWN (VOLTS)	RESTART (VOLTS)
Disabled	None	N/A
200-208	227	226
220-240	262	261
380	415	414
400	436	435
415	454	453
440-480	524	523
550-600	655	654

LCSSS – Logic Board Processor

Communication between the V25 Microprocessor and Digital Signal Processor (DSP) on the Liquid Cooled Solid State Starter Logic/Trigger Board has been interrupted. The chiller will automatically restart when communications are restored.

LCSSS – Logic Board Power Supply

Following application of power, this message is displayed and a snapshot of the LCSSS parameters and time of power failure are sent to the Control Center.

LCSSS – Phase Rotation/Loss

(Flash Memory Card version C.MLM.01.03 or earlier)

The Liquid Cooled Solid Starter Logic/Trigger Board has detected the three-phase compressor motor power line voltage phase rotation is not correct or the lineto-line voltage in any phase has decreased to less than 30% of nominal. The chiller will automatically restart when the power line conditions are acceptable.

LCSSS – Phase Loss

(Flash Memory Card version C.MLM.01.04 or later)

The Liquid Cooled Solid State Starter Logic/Trigger Board has detected the line-to-line RMS voltage in any phase has decreased to less than or equal to 30% of the lowest value of the programed voltage range. If the programmed voltage range is Disabled, a value of 60VAC is used as the threshold. The chiller will automatically restart when the line voltage is greater than the shutdown threshold. The voltage range is programmed by a Service Technician following instructions in *OptiView Control Center – Service Instructions (Form 160.54-M1)*.

COMPRESSOR MOTOR VARIABLE SPEED DRIVE: CYCLING SHUTDOWN MESSAGES

The following cycling shutdown messages are displayed on Compressor Motor Variable Speed Drive (VSD) applications only. These messages are generated by events that occur within the VSD. The chiller will automatically restart when the cycling condition clears. Service and troubleshooting information is contained in *Variable Speed Drive – Service Instructions* (Form 160.00-M1).

VSD Shutdown – Requesting Fault Data

The VSD has shutdown the chiller and the Control Center has not yet received the cause of the fault from the VSD, via the serial communications link. The VSD shuts down the chiller by opening the Motor Controller VSD STOP CONTACTS (located on the VSD Logic Board and connected between TB6-16 and TB6-53 in FORM 160.54-O1 ISSUE DATE: 06/14/2019

the Control Center). The Microboard in the Control Center then sends a request for the cause of the fault to the VSD Logic Board via the Adaptive Capacity Control Board, over the serial link. Since serial communications are initiated every 2 seconds, this message is typically displayed for a few seconds and then replaced with one of the below listed fault messages.

VSD – Stop Contacts Open

See VSD Shutdown – Requesting Fault Data on page 172. If the Control Center's Microboard does not receive the cause of the fault over the Serial Link within 20 seconds, it is assumed it is not forthcoming and that message is replaced with VSD – STOP CONTACTS OPEN message.

VSD Initialization Failed

Upon application of power, all boards go through the initialization process. At this time, memory locations are cleared, program jumper positions are checked and serial communications links are established. There are several causes for an unsuccessful initialization as follows:

- The Control Center and the VSD must be energized at the same time. The practice of pulling the fuse in the Control Center to remove power from the Control Center will create a problem. Power-up must be accomplished by closing the main disconnect on the VSD cabinet with all fuses in place. A power interruption to the VSD Logic Board will also generate this message.
- The eproms must be of the correct version for each VSD board and they must be installed correctly. The eproms are created as a set, and cannot be interchanged between earlier and later versions.
- Serial data communications must be established. See VSD – Serial Communications on page 176. If communications between the VSD Logic Board, Harmonic Filter Logic Board, ACC Board and Control Center Microboard does not take place during initialization, this message will be generated. The serial communications can be verified by selecting the VSD DETAILS Screen from the MOTOR Screen and observing the Full Load Amps value. A zero displayed for this and other VSD parameters, indicates a serial communications link problem.

- If the Harmonic Filter option is included, make sure the Filter Logic Board is not in continuous reset. This condition is evidenced by the Filter Logic Board's LED's alternately blinking. The filter can be eliminated as a cause of initialization failure by disconnecting the filter by placing switch SW1 on the Filter Logic Board in the OFF position and removing the ribbon cable between the Filter Logic Board and the VSD Logic Boards.
- VSD and Harmonic Filter horsepower ratings do not agree.

VSD – High Phase A Instantaneous Current

This shutdown is generated by the VSD if the motor current in phase A exceeds a given limit. The motor current is sensed by the current transformers on the VSD output pole assemblies and the signals are sent to the VSD Logic Board for processing. The maximum instantaneous permissible currents are as follows:

DRIVE MODEL	DRIVE HP RATING	THRESHOLD SHUTDOWN VALUE (AMPERE PEAK)
LVD, TM, VSD	270, 292, 351, 424	771
LVD, TM, VSD	385, 419, 503, 608	1200
LVD, TM, VSD	546, 575, 608 (400 VAC), 658, 704, 750, 790	1890
LVD, VSD	900, 914, 917, 948, 1100	2749
ТМ	845, 900, 1100	3093

TABLE 5 - DRIVE OVERCURRENT LIMITS

If an over current trip occurs, but the chiller restarts and runs without a problem, the cause may be attributed to a voltage sag on the utility power feeding the VSD that is in excess of the specified voltage range for this product. Thus is especially true if the chiller was running at, or near full load. If there should be a sudden dip in line voltage, the current to the motor will increase, since the motor wants to draw constant horsepower. The chiller Pre-rotation Vanes cannot close quickly enough to correct for this sudden increase in current, and the chiller will trip on an over current fault. 3

If the chiller will not restart, but keeps tripping on this same shutdown, an output pole problem is the most likely cause. The VSD would require service under these conditions.

With software version C.OPT.01.23.307 (and later), if this cycling shutdown occurs 3 times in 10 minutes, the third shutdown becomes a safety shutdown.

VSD – High Phase B Instantaneous Current

See the VSD – High Phase A Instantaneous Current message above.

VSD – High Phase C Instantaneous Current

See VSD – High Phase A Instantaneous Current on page 173.

VSD – Phase A Gate Driver

A second level of current protection exists on the VSD driver boards themselves. The collector-to-emitter saturation voltage of each IGBT is checked continuously while the device is gated on. If the voltage across the IGBT is greater than a set threshold, the IGBT is gated off and a shutdown pulse is sent to the VSD Logic Board shutting down the entire VSD system. A gate driver fault can be initiated when the VSD is not running.

VSD – Phase B Gate Driver

See the VSD – Phase A Gate Driver message above.

VSD – Phase C Gate Driver

See the VSD – Phase A Gate Driver message above.

VSD – Single Phase Input Power

This shutdown is generated by the SCR trigger control and relayed to the VSD Logic Board to initiate a system shutdown. The SCR Trigger control uses circuitry to detect the loss of any one of the three input phases. The Trigger will detect the loss of a phase within one half line cycle of the phase loss. This message is also displayed every time power to the VSD is removed or if the input power dips to a very low level.

VSD – High DC Bus Voltage

The VSD's DC Link Voltage is continuously monitored and if the level exceeds 745 VDC, a Bus Over-Voltage shutdown is initiated. If this shutdown occurs, it will be necessary to look at the level of the 460 VAC applied to the drive. The specified voltage range is 414 VAC to 508 VAC. If the incoming voltage is in excess of 508 VAC, steps should be taken to reduce the voltage to within the specified limits.

VSD – Logic Board Power Supply

This shutdown is generated by the VSD Logic Board and it indicates that the low voltage power supplies for the Logic Boards have dropped below their allowable operating limits. The power supplies for the Logic Boards are derived from the secondary of the 120 to 24VAC transformer, which in turn, is derived from the 480 to 120VAC control power transformer. This message usually means the power to the VSD has been removed.

VSD – Low DC Bus Voltage

If the DC link drops below 500 VDC (or 414 VDC for 50 Hz applications), the drive will initiate a system shutdown. A common cause for this shutdown is a severe sag in the incoming power to the drive. Monitor the incoming three-phase AC line for severe sags and also monitor the DC link with a voltmeter.

VSD – Low DC Bus Voltage

(575V/60 Hz applications)

(Software version C.OPT.01.15.xxx (or later))

If the DC Link Voltage falls below 600 VDC while running, this shutdown is performed.

VSD – DC Bus Voltage Imbalance

The DC link is filtered by many large electrolytic capacitors, rated for 450 VDC. These capacitors are wired in series to achieve 900 VDC capability for the DC link. It is important that the voltage be shared equally from the junction of the center, or series capacitor connection, to the negative bus and the positive bus. This center point should be approximately ¹/₂ of the total DC Link Voltage. Most actual Bus Voltage Imbalance conditions are caused by a shorted capacitor or a leaky or shorted IGBT transistor in an output phase bank assembly. This usually indicates the VSD requires service.

VSD – Precharge – DC Bus Voltage Imbalance

This message indicates the same as the VSD-DC Bus Voltage Imbalance message above, except the condition occurred during the prelube period.

VSD – High Internal Ambient Temperature

The ambient temperature monitored is actually the temperature detected by a component mounted on the VSD Logic Board. The high ambient trip threshold is set for 140°F (60.0°C) for TM model drives and 145°F (62.8°C) for VSD and LVD model drives. Some potential causes for this shutdown are: internal VSD fan failure, VSD water pump failure or an entering condenser water temperature that exceeds the allowable limit for the job. Additional causes for the shutdown are:

- Plugged Strainer The standard 1.5 in. Y-strainer contains a woven mesh element with 20 stainless steel wires per inch. This has been found to work adequately on most applications. Some users may have very dirty condenser water, which can cause the strainer to plug. Locations with special conditions may want to consider a dual strainer arrangement with quarter turn valves, to permit cleaning of one strainer with the unit still on line.
- Plugged Heat-exchanger In cases where the strainer plugs frequently, the heat-exchanger may eventually plug or become restricted to the point of reduced flow. At this point, we suggest you back-flush the heat-exchanger by reversing the two rubber hoses which supply condenser water to-from the heat-exchanger. If the rust cannot be back-flushed, the heat-exchanger might have to be replaced.
- Low Condenser Flow The VSD system requires 8 feet of pressure drop across the heat exchanger to maintain adequate GPM. If the pressure drop is less than 8 feet, it will be necessary to correct the flow problem or add a booster pump as is applied on retrofit chillers.

VSD – Invalid Current Scale Selection

Since the part number of the VSD Logic Board is the same on all horsepower sizes, the position of Program Jumpers tells the Logic Board the size of the VSD employed. This allows the VSD to properly scale the output current. If the jumper configuration is invalid, a shutdown is performed and this message is generated. Refer to *Variable Speed Drive – Service Instructions* (*Form 160.00-M1* for TM model drives and *Form 160.00-M4* for VSD and LVD model drives).

VSD – Low Phase A Inverter Heatsink Temperature

(For TM model drives)

A heatsink temperature sensor indicating a temperature less than 37°F will cause the chiller to shut down and display this message. In most cases, the problem will be an open transmitter or broken wiring to the transmitter. The normal transmitter resistance is 10K ohms at 77°F.

VSD – Low Phase B Inverter Heatsink Temperature

(For TM model drives)

See the VSD – Low Phase A Inverter Heatsink Temperature message above.

VSD – Low Phase C Inverter Heatsink Temperature

(For TM model drives)

See the VSD – Low Phase A Inverter Heatsink Temperature message above.

VSD – Low Converter Heatsink Temperature

All models of drives (TM, VSD, and LVD) have a temperature sensor mounted on the heatsink with the converter. A temperature of less than 37°F (2.8°C) causes the chiller to shut down and display this message. In most cases, the problem will be an open transmitter or broken wiring to the transmitter. The normal transmitter resistance is 10K ohms at 77°F (25.0°C).

VSD – Low Phase A Inverter Baseplate Temperature

(For drive models VSD and LVD where the drive has three power modules)

(Flash Memory Card version C.MLM.01.08 and later)

The chiller has shutdown because the baseplate temperature has decreased to less than $37^{\circ}F$ (2.8°C).

VSD – Low Phase B Inverter Baseplate Temperature

(For drive models VSD and LVD where the drive has three power modules)

(Flash Memory Card version C.MLM.01.08 and later)

The chiller has shutdown because the baseplate temperature has decreased to less than $37^{\circ}F(2.8^{\circ}C)$.

VSD – Low Phase C Inverter Baseplate Temperature

(For drive models VSD and LVD where the drive has three power modules)

(Flash Memory Card version C.MLM.01.08 and later)

The chiller has shutdown because the baseplate temperature has decreased to less than $37^{\circ}F$ (2.8°C).

VSD – Precharge – Low DC Bus Voltage

(For TM model drives)

During precharge, the DC link voltage must be equal to or greater than 50 VDC (460 VAC supply), 41 VDC (380 VAC to 415 VAC supply) within 1/2 second, and 500 VDC (460 VAC supply), 414 VDC (380 VAC to 415 VAC supply) within 15 seconds after the precharge relay is energized. If this condition is not met, a shutdown occurs and this message appears.

VSD – Precharge – Low DC Bus Voltage

(For VSD and LVD model drives)

During precharge, the DC link voltage must be equal to or greater than 60 VDC (575 VAC supply), 50 VDC (460 VAC supply), and 41 VDC (380 VAC to 415 VAC supply) within 4 seconds, and 600 VDC (575 VAC supply), 500 VDC (460 VAC supply), and 414 VDC (380 VAC to 415 VAC supply) within 20 seconds after the precharge signal is received. If this condition is not met, a shutdown occurs and this message appears.

VSD – Low Inverter Baseplate Temperature

(For drive models VSD and LVD where the drive has one power module.)

(If compressor other than "P", requires Flash Memory Card version C.MLM.01.05A.xxx and later)

A baseplate temperature sensor indicating a temperature of less than $37^{\circ}F$ will cause the chiller to shut down and display this message. In most cases, the problem will be an open transmitter or broken wiring to the transmitter. The normal transmitter resistance is 5K ohms at $77^{\circ}F$.

VSD – Logic Board Processor

This shutdown is generated if a communications problem occurs between the two microprocessors on the VSD Logic Board.

VSD – Run Signal

Redundant Run Signals are generated by the Control Center; one via TB6-24 and the second via the serial communications link. Upon receipt of either of the two Run Commands by the VSD, a 5 second timer shall commence timing. If both Run Commands are not received by the VSD Logic Board within 5 seconds, a shutdown is performed and this message is displayed. This is generally indicative of a wiring problem between the Control Center and the VSD.

VSD – Serial Communications

This message is generated when communications between the Adaptive Capacity Control (ACC) Board and the VSD Logic Board, or between the Control Center Microboard and the VSD Logic Board, is disrupted. This is generally indicative of defective wiring between J11 on the VSD Logic Board and J8 on the ACC Board when York Protocol is used. The J16 connector on the drive logic is used for ModBus Protocol. J16 and J11 cannot be connected at the same time.

Harmonic Filter – Logic Board or Communications

This message is generated when communications between the Harmonic Filter and the VSD Logic Board, is disrupted. If equipped with Flash Memory Card version C.MLM.01.06.xxx and later, the communications must be interrupted for 10 continuous communications cycles (20 seconds) before the shutdown will occur.

Harmonic Filter – High DC Bus Voltage

The DC link voltage of the harmonic filter is continuously monitored. If the level exceeds 860 VDC, or 1049 VDC for 575 VAC supply, this shutdown is performed. The Harmonic Filter has its own DC bus as part of the filter power assembly, and this DC Link is not connected in any way with the VSD's DC link. If this shutdown occurs, you must evaluate the supply voltage that is applied to the Harmonic Filter. Ensure that the supply voltage applied to the drive is maintained to the supply voltage range listed on the drive's nameplate. Take steps to reduce the level to within specified limits. The cause of this message is typically high line voltage or a surge on the utility supply.

3

Harmonic Filter – High Phase A Current

The maximum instantaneous Harmonic Filter current is monitored and compared to a preset limit. If this limit is exceeded, a shutdown is performed and this message is generated. The filter current is monitored using two DCCT's and these signals are processed by the Filter Logic Board. The preset limits are as follows:

TABLE 6 - FILTER OVERCURREN

DRIVE MODEL	DRIVE HP RATING	THRESHOLD SHUTDOWN LEVEL (AMPERE PEAK)
TM, VSD	270, 292, 351, 424	378
TM, VSD	385, 419, 503, 608	523
TM, VSD	608 (400 VAC), 658, 704, 790	781
VSD	868, 882, 914, 917, 948, 1100	1225
ТМ	845, 900, 1100	1225

If the VSD automatically restarts after this shutdown and continues to operate properly with the filter operating, it is likely the filter tripped due to a sag or surge in the voltage feeding the VSD. If this message reoccurs, preventing the chiller from starting, the VSD will require service.

Harmonic Filter – High Phase B Current

See Harmonic Filter – High Phase A Current.

Harmonic Filter – High Phase C Current

See Harmonic Filter – High Phase A Current.

Harmonic Filter – Phase Locked Loop

This shutdown indicates that a circuit called Phase Locked Loop on the Filter Logic Board has lost synchronization with the incoming power line. This is usually indicative of an open fuse in one of the filter's incoming power line.

Harmonic Filter – Precharge – Low DC Bus Voltage

During precharge, the filter's DC link must be equal to or greater than 41 VDC within 1/10 second, or at least 425 VDC (within 5 seconds), after the precharge relay is energized. If this condition is not met, a shutdown is performed and this message is generated.

VSD – Harmonic Filter-Precharge-Low DC Bus Voltage

(575 V 60 Hz applications)

(Software version C.OPT.01.15.xxx (or later))

If the DC Link Voltage does not reach at least 60 VDC (within 100 millisconds) or at least 630 VDC (within 5 seconds) after the filter precharge command has been received, this shutdown is performed.

Harmonic Filter – Low DC Bus Voltage

The Harmonic Filter generates its own Filter DC link Voltage by switching its IGBTs. This DC level is actually higher than the level that you could obtain by simply rectifying the input line voltage. Thus, the Harmonic Filter actually performs a voltage BOOST function. This is necessary in order to permit current to flow into the power line from the filter when the input line is at its peak level. This shutdown occurs when the filter's DC Link Voltage decreases to a level less than 80 VDC for all models, except for the 575 VAC 424 hp model that trips at 110 VDC, and the 575 VAC 608 hp model that trips at 140 VDC below the Filter DC Link Voltage setpoint. This Setpoint is determined by the Filter Logic Board via the sensing of the three phase input line-to-line voltage. This setpoint is set to the peak of the sensed input line-to-line voltage plus 59 volts, not to exceed 760 volts for all models, except for the 575 VAC 424 hp model in which the boost voltage is 88 VDC, and the 575 VAC 608 hp model in which the boost voltage is 118 VDC with a maximum regulated bus voltage of 993 VDC. The setpoint varies with the input line-to-line voltage. If this shutdown occurs occasionally, the likely cause is a severe sag in the input line voltage.

Harmonic Filter – DC Bus Voltage Imbalance

The Filter DC link is filtered by large, electrolytic capacitors, rated for 450 VDC. These capacitors are wired in series to achieve a 900 VDC capability for the DC link. It is important the voltage is shared equally from the junction of the center or series capacitor connection, to the negative bus and to the positive bus. If the imbalance voltage is greater than 50 VDC, this message appears.

VSD – Harmonic Filter-DC Bus Voltage Imbalance

(575 V 60 Hz applications)

(Software version C.OPT.01.15.xxx (or later))

If the Half DC Link Voltage does not remain within plus or minus 65 VDC of the DC Link Voltage divided by 2, this shutdown is performed.

Harmonic Filter – Input Current Overload

The three phases of RMS Filter current are monitored and if any one of the three phases continuously exceeds a given threshold for 7 seconds for TM model of drive, and 40 seconds for VSD model of drive, a chiller shutdown is performed and this message appears. The maximum permissible continuous RMS current ratings for the Harmonic Filter are as follows:

DRIVE MODEL	DRIVE HP RATING	THRESHOLD SHUTDOWN VALUE (AMPERE)
TM, VSD	270, 292, 351	128
VSD	424	138
TM, VSD	385, 419, 503	176
VSD	608 (575 VAC)	190
TM, VSD	608 (400 VAC), 658, 704, 790	278
VSD	868, 882, 914, 917, 948, 1100	385
ТМ	845, 900, 1100	385

TABLE 7 - FILTER OVERLOAD

Harmonic Filter – Logic Board Power Supply

The low voltage power supplies on the Filter Logic Board have decreased below their permissible operating range. The Filter Logic Board receives its power from the VSD Logic Board via the ribbon cable, connecting the two boards.

Harmonic Filter – Run Signal

When a digital run command is received at the Filter Logic Board from the VSD Logic Board via the 16 position ribbon cable, a 1/10 second timer is started. If a redundant run command does not occur on the serial data link from the VSD Logic Board before the timer expires, a shutdown is performed and this message is generated.

Harmonic Filter – DC Current Transformer 1

During initialization, with no current flowing through the DC Current Transformers (DCCT's), the DCCT output voltages are measured and compared with a preset limit via the Filter Logic Board. If the measured values exceed the preset limits, the DCCT's are presumed to be defective and this shutdown is generated.

Harmonic Filter – DC Current Transformer 2

See the *Harmonic Filter – DC Current Transformer 1* message above.

SAFETY SHUTDOWN MESSAGES

Evaporator – Low Pressure

The Evaporator Pressure, as sensed by the Evaporator transducer, has decreased to the safety shutdown threshold. For water cooling applications, the safety shutdown threshold is a fixed value for the respective refrigerant. For Brine cooling applications, the safety shutdown threshold varies according to the concentration of the Brine solution. The Brine shutdown threshold is programmed at the YORK Factory. It should not be changed by anyone other than a qualified Service Technician following instructions in *OptiView Control Center – Service Instructions (Form 160.54-M1)*. The chiller can be started after the Evaporator Pressure increases to the restart threshold and the Compressor Switch is placed in the Stop-Reset (O) position.

	SHUTDOWN (psig)	RESTART (psig)
Water Cooling - R22	54.3	54.4
- R134a	25.0	25.1
Brine Cooling - R22	25.0 to 54.3 as programmed	+0.1 more than Shutdown threshold
- R134a	6.0 to 25.0 as programmed	+0.1 more than Shutdown threshold

Evaporator – Low Pressure - Smart Freeze

(Flash Memory Card version C.MLM.01.02 or later)

Smart Freeze protection is activated and has shut down the chiller because the evaporator temperature has been below the Smart Freeze threshold for greater than the allowable number of seconds. If the Evaporator Refrigerant Temperature sensor RT7 is enabled, (using procedure in *OptiView Control Center – Service Instructions (Form 160.54-M1)*), this parameter is used as the Evaporator Refrigerant Temperature and the freeze threshold is 32.8° F (0.4°C). If RT7 is not enabled, the Evaporator Refrigerant Temperature used is the Evaporator Saturation Temperature, derived from the Evaporator Pressure transducer and the freeze threshold is 34.0° F (1.1°C).

The total count is incremented once for every second the Evaporator Refrigerant Temperature is below the freeze threshold (but is never decremented below zero). The number of seconds it will take the chilled liquid to freeze is based on how far the Evaporator Refrigerant Temperature is below the freeze threshold as follows:

 $\frac{\text{number of seconds}}{\text{to freezing}} = \frac{(4053.7)}{\text{freeze threshold} - \text{evap.}}$ refrigerant temp.

Smart Freeze is activated only if the feature has been enabled by a Service Technician (following instructions in *OptiView Control Center – Service Instructions (Form 160.54-M1)*) and the Leaving Chilled Liquid Temperature Setpoint is less than 38.0°F (3.3°C).

Evaporator – Transducer Or Leaving Liquid Probe

A possible defective Evaporator Pressure transducer or Leaving Chilled Liquid temperature transmitter has been detected. The pressure and temperature that these devices are indicating are not in the correct relationship to each other. The Control Center converts the Evaporator Pressure to a Saturated Temperature value and compares this value to the Leaving Chilled Liquid temperature (difference equals chilled liquid temp minus evaporator saturated temp). The difference should not be outside the range of -2.5° F to $+25.0^{\circ}$ F. If the transducer and transmitter are accurate, the Evaporator Saturated temperature should not be greater than 2.5°F warmer nor greater than 25.0°F colder than the Leaving Chilled Liquid Temperature. In order to initiate a shutdown, the difference must be outside the acceptable range continuously for 10 minutes. For Steam Turbine drive applications, this check is bypassed for the first 20 minutes of chiller operation. The chiller can be started after the Compressor Switch is placed in the Stop-Reset (O) position.

Evaporator – Transducer Or Temperature Sensor

A possible defective Evaporator Pressure transducer or Refrigerant Temperature Sensor has been detected. The Control Center converts the Evaporator Pressure to a Saturated Temperature value and compares this value to the optional Evaporator Refrigerant Temperature Sensor. If the difference between these temperatures is greater than 3.0°F, continuously for 1 minute, this shutdown is performed. This check is only performed under the following conditions:

- Chiller has been running for at least 10 minutes
- Evaporator Refrigerant Temperature (RT7) has been enabled by a Service Technician using instructions in *OptiView Control Center – Service Instructions (Form 160.54.M1)*
- Not in Brine Cooling mode (If compressor application other than "P", applies only to Flash Memory Card version C.MLM.01.02 and later)
- Smart Freeze is enabled (If compressor application other than "P", applies only to Flash Memory Card version C.MLM.01.05.xxx and later)
- Evaporator Temperature Sensor (RT7) or Evaporator Saturation Temperature is indicating a temperature of less than 32.0°F (If compressor application other than "P", applies only to Flash Memory Card version C.MLM.01.05.xxx and later)

The chiller can be started after the temperatures are within 3.0°F of one another and the Compressor Switch is placed in the Stop-Reset (O) position.

Condenser – High Pressure Contacts Open

The contacts of the electromechanical high pressure safety device, located on the condenser shell, have opened because this device has detected a pressure:

- More than 204 psig (R134a)
- More than 265.0 (R22)

The contacts will automatically close when the condenser pressure decreases to:

- Less than 160 psig (R134a)
- Less than 205 psig (R22)

The chiller can be started after the contacts close and the Compressor Switch is placed in the Stop-Reset (O) position.

Condenser – High Pressure

The condenser pressure, as sensed by the Condenser transducer, has increased to:

- More than 180.0 psig (R-134a)
- More than 265.0 psig (R-22).

The chiller can be started after the pressure decreases to:

- Less than 120.0 psig (R-134a)
- Less than 205 psig (R-22) and the Compressor Switch is placed in the Stop-Reset (O) position

For special order R-134a high condenser temperature chiller applications, the Condenser Temperature Range Setpoint (software version C.OPT.01.19.307 or later) is set to Extended. The trip/reset threshold is then 200/140 psig.

Condenser – High Pressure – Stopped

(Software versions C.MLM.01.11.xxx and later or C.OPT.01.11.303 and later)

The condenser pressure exceeded 160.0 psig (R-134a), 240.0 psig (R22) while the chiller was stopped. High temperature condenser water flowing through the condenser while the chiller is shutdown can cause a condenser high pressure condition resulting in loss of refrigerant. This safety fault anticipates this problem by annunciating the condenser high pressure condition. The chiller can be restarted after a Service Technician performs a special reset preset procedure contained in *OptiView Control Center – Service Instructions (Form 160.54-MI)*.

For special order R-134a high condenser temperature chiller applications, the Condenser Temperature Range Setpoint (software version C.OPT.01.19.307 or later) is set to Extended. The trip/reset is then 170/170 psig.

Condenser – Pressure Transducer Out Of Range

The Condenser Pressure transducer is indicating a pressure that is:

- Less than 6.8 psig (R-134a)
- Less than 24.2 psig (R-22)
- Or more than 300.0 psig (R-134a or R-22)

This is outside the normal operating range of the transducer. This is generally indicates a defective transducer. The chiller can be started after the transducer is indicating a pressure that is within range and the Compressor Switch is placed in the Stop-Reset (O) position.

Auxiliary Safety – Contacts Closed

The Auxiliary safety shutdown contacts, connected to I/O Board TB4-31 have closed, initiating a safety shutdown. This input is a general-purpose, user defined safety shutdown input. The chiller can be started after the contacts open and the Compressor Switch is placed in the Stop-Reset (O) position.

Discharge – High Temperature

The discharge temperature, as sensed by the Discharge Temperature Transmitter, has increased to greater than 220.0° F (104.4° C). The chiller can be started after the temperature decreases to less than 220.0° F (104.4° C) and the Compressor Switch is placed in the Stop-Reset (O) position.

Discharge – Low Temperature

The discharge temperature, as sensed by the Discharge Temperature Transmitter, has decreased to less than 30.0°F. The chiller can be started after the temperature increases to greater than 30.0°F and the Compressor Switch is placed in the Stop-Reset (O) position.

Oil – High Temperature

The oil temperature, as sensed by the Oil Temperature Transmitter, has increased to greater than 180.0°F (82.2°C). The chiller can be started after the temperature decreases to less than 180.0°F (82.2°C) and the Compressor Switch is placed in the Stop-Reset (O) position.

Oil – Low Differential Pressure

The differential oil pressure decreased to less than 15.0 PSID while the chiller was running or failed to achieve 25.0 PSID by the last 5 seconds of the System Prelube period. The differential oil pressure is the difference between the output of the Sump Oil Pressure transducer (system low pressure) and the output of the Pump Oil Pressure transducer (system high pressure). The chiller can be started after the Compressor Switch is placed in the Stop-Reset (O) position.
Oil – High Differential Pressure

The differential oil pressure increased to greater than 90.0 PSID (120.0 PSID with software versions C.MLM.01.08.xxx (and later) or C.OPT.01.08A.xxx (and later)) while the oil pump was running. The differential oil pressure is the difference between the output of the Sump Oil Pressure transducer (system low pressure) and the output of the Pump Oil Pressure transducer (system high pressure). The chiller can be started after the differential oil pressure decreases to less than 90.0 PSID and the Compressor Switch is placed in the Stop-Reset (O) position.

Oil – Pump Pressure Transducer Out Of Range

The Pump Oil Pressure transducer (system high pressure) is indicating a pressure that is less than 0.0 psig or greater than 315.0 psig. This is outside the normal operating range of the transducer. This generally indicates a defective transducer. The chiller can be started after the transducer is indicating a pressure that is within range and the Compressor Switch is placed in the Stop-Reset (O) position.

Oil – Sump Pressure Transducer Out Of Range

The Sump Oil Pressure transducer (system low pressure) is indicating a pressure that is outside the normal operating range of the transducer as follows:

- R134a is less than 0.0 psig or more than 315.0 psig.
- R22 is less than 23.2 psig or more than 271.8 psig.

This generally indicates a defective transducer. The chiller can be started after the transducer is indicating a pressure that is within range and the Compressor Switch is placed in the Stop-Reset (O) position.

Oil – Differential Pressure Calibration

The Sump and Pump oil pressure transducers indicated a differential oil pressure of greater than 15.0 PSID during the oil pressure transducer Auto-Zeroing period that begins 10 seconds into System Prelube and lasts for 3 seconds. This is indicative of a defective Sump or Pump transducer, since the oil pump is not running during this period and the actual differential oil pressure is 0 PSID. The transducers are sensing the same pressure during this period and their outputs should be similar. The chiller can be started after the Compressor Switch is placed in the Stop-Reset (O) position.

Oil – Variable Speed Pump – Setpoint Not Achieved

This is only applicable to chillers equipped with the Oil Pump Variable Speed Drive. One of the following conditions have occurred while in System Prelube, System Run or System Coastdown. The chiller can be started after the Compressor Switch is placed in the Stop-Reset (O) position. With software version C.OPT.01.18.307 (or later), this safety shutdown is not performed when the Refrigerant Selection (microboard SW1-1) is set to "R22".

1. The differential oil pressure was less than 35.0 PSID; (less than 25 PSID for "P" compressors equipped with software version C.01.10A.xxx (and earlier) or C.OPT.01.10A.xxx (and earlier) for 5 continuous seconds during the last 10 seconds of the System Prelube period or during the first 15 seconds of System Run.

-OR-

2. Anytime after the first 30 seconds of System Run, the differential oil pressure was less than the Oil Pressure Setpoint with the speed command from the Microboard at 60 Hz for 5 continuous seconds.

Control Panel – Power Failure

A Control Power failure has occurred. If the power failure duration was less than the duration of the applicable coastdown period (2.5 minutes standard; 15 minutes steam turbine), the remainder of the coastdown is performed upon restoration of power. The chiller can be started after the Compressor Switch is placed in the Stop-Reset (O) position. This message can indicate a Cycling (auto-restart after power failure) or Safety (manual restart after power failure) shutdown, depending upon Control Center configuration. It indicates a cycling shutdown when displayed in orange characters; safety shutdown when displayed in red characters. The Control Center is configured for auto-restart or manual restart after power failure by a qualified Service Technician following instructions in OptiView Control Center – Service Instructions (Form 160.54-M1).

Motor Or Starter – Current Imbalance

The three phase compressor motor current imbalance was greater than 30% continuously for 45 seconds. The imbalance is not checked until the chiller has been running for at least 45 seconds and the average of the three phases of motor current is greater than 80% of the programmed 100% chiller Full Load Amps. The average is calculated as:

Iave =
$$\frac{(Ia+Ib+Ic)}{3}$$

The imbalance is calculated as:

$$\frac{(\text{Ia-Iave}) + (\text{Ib-Iave}) + (\text{Ic-Iave})}{2(\text{Iave})} \times 100$$

The Style B Solid State Starter and Variable Speed Drive detects the unbalance condition and advise the OptiView Control Center Microboard via serial communications. The Style A Solid State Starter and Variable Speed Drives returns the 3-phase motor current values to the OptiView Control Center Microboard where the unbalance calculation is performed. This safety shutdown is not performed on Electromechanical Starter applications.

Thrust Bearing – Proximity Probe Clearance

(Style E and earlier chillers with G, H or J compressors and Style F and later Chillers with J or H3 compressors)

The clearance between the compressor high speed thrust collar and the tip of the Proximity Probe has increased more than +10 mils or decreased to less than -25 mils (for 2 continuous seconds) from the Reference Position. The minimum allowed clearance is 23 mils. Therefore, if the Reference position is less than 47 mils, the shutdown will occur when the actual clearance is less than 22 mils.

If equipped with software version C.MLM.01.10.xxx (and later) or C.OPT.01.10.302 (and later), the operation is as follows: the clearance is only checked during the last 20 seconds of System Prelube, during System Run and during coastdown. Therefore, the fault is only detected during those periods. Also, the +10 mil threshold must be exceeded for 2 continuous seconds (instantaneous with previous software).



This shutdown must be evaluated by a qualified Service Technician prior to starting the chiller. Starting the chiller without this evaluation could result in severe compressor damage. To prevent the chiller from starting without the proper evaluation, restart is inhibited until the clearance is within acceptable limits and a special reset procedure is performed by the Service Technician. The evaluation and reset procedure are contained in OptiView Control Center - Service Instructions (Form 160.54-M1).

Thrust Bearing – Proximity Probe Out Of Range

(Style E and earlier chillers with G, H or J compressors and Style F and later Chillers with J or H3 compressors)

The clearance between the compressor high speed thrust collar and the tip of the Proximity Probe has decreased to less than 17 mils.

If equipped with software version C.MLM.01.10.xxx (and later) or C.OPT.01.10.302 (and later), the operation is as follows: the clearance is only checked during the last 20 seconds of System Prelube, during System Run and during coastdown. Therefore, the fault is only detected during those periods.



This shutdown must be evaluated by a qualified Service Technician prior to starting the chiller. Starting the chiller without this evaluation could result in severe compressor damage. To prevent the chiller from starting without the proper evaluation, restart is inhibited until the clearance is within +10 mil to -25 mil of the Reference Position and a special reset procedure is performed by the Service Technician. The evaluation and reset procedure are contained in OptiView Control Center - Service Instructions (Form 160.54-M1).

Thrust Bearing – High Oil Temperature

(Not applicable to Flash Memory Card version C.MLM.01.03 and later)

The temperature of the oil in the High Speed Drain Line, as sensed by the Proximity Probe, has increased to greater than or equal to 250.0°F.



This shutdown must be evaluated by a qualified Service Technician prior to starting the chiller. Starting the chiller without this evaluation could result in severe compressor damage. To prevent the chiller from starting without the proper evaluation, restart is inhibited until the temperature decreases to less than $180.0^{\circ}F$ and a special reset procedure is performed by the Service Technician. The evaluation and reset procedure are contained in OptiView Control Center - Service Instructions (Form 160.54-M1).

Thrust Bearing – Oil Temperature Sensor

(Not Flash Memory Card version C.MLM.01.03 and later)

The temperature of the oil in the High Speed Drain Line, as sensed by the Proximity Probe, has decreased to less than 50.0°F during System Run or the last 10 seconds of System Prelube.



This shutdown must be evaluated by a qualified Service Technician prior to starting the chiller. Starting the chiller without this evaluation could result in severe compressor damage. To prevent the chiller from starting without the proper evaluation, restart is inhibited until the temperature increases to greater than 50.0°F and a special reset procedure is performed by the Service Technician. The evaluation and reset procedure are contained in OptiView Control Center -Service Instructions (Form 160.54-M1).

Thrust Bearing – Limit Switch Open

(All "P and Q" compressors and Style F Chillers with G or H5-8 compressors)

The High Speed Thrust Bearing Limit Switch contacts, connected to TB3-81, have opened. This occurs when the Bearing position decreases to less than the allowed position.



This shutdown must be evaluated by a qualified Service Technician prior to starting the chiller. Starting the chiller without this evaluation could result in severe compressor damage. To prevent the chiller from starting without the proper evaluation, restart is inhibited until the switch contacts have closed and a special reset procedure is performed by the Service Technician. The evaluation and reset procedure are contained in OptiView Control Center - Service Instructions (Form 160.54-M1).

Watchdog – Software Reboot

The Microboard's software Watchdog initiated a Microprocessor reset because it detected that a portion of the chiller operating program was not being executed. The result of this reset is a safety shutdown and re-initialization of the program. This is generally indicative of a severe electrical power disturbance or impending Microboard Failure. The chiller can be started after the Compressor Switch is placed in the Stop-Reset (O) position.

Surge Protection – Excess Surge

(Flash Memory Card version C.MLM.01.05.xxx and later) This applies only if Surge Protection Shutdown feature is Enabled.

The Surge Window Count surge events exceeded the Count Limit Setpoint. If the Surge Protection Extended Run feature is Disabled, the chiller shuts down as soon as the count exceeds the limit. If the Extended Run feature is Enabled, this shutdown occurs only if the count exceeds the limit at completion of the 10 minute Extended Run period. The chiller can be started after the Compressor Switch is placed in the Stop-Reset (O) position.

Motor – Lack of Bearing Lubrication

(Software version C.MLM.01.14.xxx (and later) or C.OPT.01.14.306 (and later))

The Operating Hours Since Last Motor Lubrication has exceeded 1400 hours. This message replaces WARN-ING MOTOR BEARING LUBE REQUIRED above. This safety shutdown remains in effect until the Operator places the Compressor Switch in the Stop-Reset (O) position and enters his/her initials, name or user ID in OPERATOR access level (or higher) using the MOTOR LUBE ACKNOWLEDGE key on the MO-TOR LUBRICATION Screen. See the Motor Lubrication Screen 1 on page 104 for entry instructions. The date and time of this entry is automatically logged as the Date Of Last Motor Lubrication and Time Of Last Motor Lubrication. It also resets the Operating Hours Since Last Lubrication to zero. The date this warning occurs is stored as the Date Of Last Motor Lubrication Warning Or Fault. With software version C.OPT.01.16. xxx (and later), this message will only be displayed if the Auto Lube Setpoint is disabled. With this setting, if the Shutdown Setpoint is enabled, this safety shutdown will occur. If shutdown is disabled, this warning message will be displayed but the safety shutdown will not be performed.

Motor – Lack of Bearing Lubrication

(This feature applies to software version Y.OPT.01.00D.308 and later.)

The Operating Hours Since Last Motor Lubrication has exceeded the setpoint hours plus 200. This message replaces WARNING MOTOR BEARING LUBE REQUIRED above. This safety shutdown remains in effect until the Operator presses the Clear Fault key on the display, and enters his/her initials, name or user ID in OPERATOR access level (or higher) using the MOTOR LUBE ACKNOWLEDGE key on the MO-TOR LUBRICATION Screen. See the Motor Lubrication Screen 2 on page 107 for entry instructions. The date and time of this entry is automatically logged as the Date Of Last Motor Lubrication and Time Of Last Motor Lubrication. It also resets the Operating Hours Since Last Lubrication to zero. The date this warning occurs is stored as the Date Of Last Motor Lubrication Warning Or Fault. This message will only be displayed if the Auto Lube Setpoint is disabled. With this setting, if the Shutdown Setpoint is enabled, this safety shutdown will occur. If shutdown is disabled, this warning message will be displayed but the safety shutdown will not be performed.

Motor – High Winding Temperature

(Software version C.OPT.01.22.307 and later)

This safety shutdown occurs when either of the following conditions are present: • Any of the enabled Motor Winding Temperatures exceeded the programmed High Winding Temperature Shutdown threshold plus the programmed Winding Hotspot Allowance threshold for 3 continuous seconds.

-OR-

• The Average Winding Temperature has exceeded the programmed High Winding Temperature Shutdown threshold for 3 continuous seconds.

The values programmed for the above safety thresholds are displayed as High Winding Temperature Shutdown and Winding Hotspot Allowance on the MOTOR SETPOINTS Screen. They are programmed with the Winding Setup Setpoint on that screen. The chiller can be started after all winding temperatures decrease to at least 18°F (10°C) below the shutdown threshold and the Compressor Switch is placed in the Stop-Reset position. This safety shutdown will not occur when the Winding Temperature Protection Setpoint is set to Disabled on the MOTOR DETAILS Screen. Also, it will not act on any RTD input registering as an open RTD or any individual winding temperature Setpoint on the MOTOR SETPOINTS Screen.

Motor – High Bearing Temperature

(Software version C.OPT.01.22.307 and later)

This safety shutdown occurs when either of the enabled motor bearing temperatures exceeds the programmed High Bearing Temperature Shutdown threshold for 3 continuous seconds. The value programmed for this safety threshold is displayed as High Bearing Temperature Shutdown on the MOTOR SETPOINTS Screen. It is programmed with the Bearing Setup Setpoint on that screen. The chiller can be started after both bearing temperatures decrease to at least 9°F below the shutdown threshold and the Compressor Switch is placed in the Stop-Reset position. This safety shutdown will not occur when the Bearing Temperature Protection Setpoint is set to Disabled on the MOTOR DETAILS Screen. Also, it will not act on any RTD input registering as an open RTD.

Motor – High Bearing Vibration

(Software version C.OPT.01.22.307 and later)

Either the Shaft End or Opposite Shaft End motor bearing vibration has exceeded the value programmed for the High Vibration Shutdown Setpoint for the programmed number of delay seconds. This safety shutdown does not occur when the Motor Vibration Protection Setpoint is set to Disabled on the MOTOR DETAILS Screen or while the WARNING – MOTOR – BEARING VIBRATION BASELINE NOT SET warning is displayed. The chiller can be started after the both vibration values decrease below the shutdown threshold and the Compressor Switch is placed in the Stop-Reset (O) position.

Motor – Cooling Coil Leak

(Software version C.OPT.01.22.307 and later)

The Motor Cooling Coil Leak Detector has registered a fault condition for at least 3 continuous seconds. The Motor Cooling Coil leak Protection Setpoint enables the type of sensor employed: If an optical sensor is being used, the input to the Motor Monitoring Board goes high to indicate a leak; if a float switch is used, the input goes low to indicate a leak. This safety shutdown will not occur when the Motor Cooling Coil Leak Protection Setpoint is set to Disabled. The chiller can be started after the leak sensor no longer indicates a leak and the Compressor Switch is placed in the Stop-Reset (O) position.

MOD B SOLID STATE STARTER SAFETY SHUTDOWN MESSAGES

LCSSS Shutdown – Requesting Fault Data...

The Liquid Cooled Solid State Starter Logic/Trigger Board has shut down the chiller but the Control Center has not yet received the cause of the fault from the LCSSS, via the serial communications link. The LC-SSS shuts down the chiller by opening the Motor Controller LCSSS Stop Contacts (K1 relay located on the Logic/Trigger Board and connected between TB6-16 and TB6-53 in the Control Center). The Microboard, in the Control Center, then sends a request for the cause of the fault to the Logic/Trigger Board over the serial communications link. Since serial communications are initiated every 2 seconds, this message is typically displayed for a few seconds and then replaced with one of the following fault messages.

LCSSS – High Instantaneous Current

The Liquid Cooled Solid State Starter Logic/Trigger Board detected that the compressor motor current in any phase exceeded 1.1(1.414 x RMS value of the programmed Start Current) for a minimum of 1 second. The chiller can be started after the Compressor Switch is placed in the Stop-Reset (O) position.

LCSSS – High Phase (X) Heatsink Temperature – Running

The Liquid Cooled Solid State Starter Logic/Trigger Board has detected the temperature of phase A, B or C (designed as X in the message) Silicon Controlled Rectifier (SCR) Modules has exceeded 212°F while the chiller was running. The safety can be reset after all SCR temperatures are less than 210°F and the Compressor Switch is placed in the Stop-Reset position (O). However, the chiller cannot be started until all SCR temperatures are less than 109°F. During the shutdown, the starter cooling pump runs until the temperature is less than 109°F.

LCSSS – 105% Motor Current Overload

The highest phase of the compressor motor current increased to greater than 105% of the programmed 100% chiller Full Load Amps continuously for 40 seconds. The chiller can be started after the Compressor Switch is placed in the Stop-Reset (O) position.

LCSSS – Phase (X) Shorted SCR

(Flash Memory Card version C.MLM.01.04 or later)

A shorted Silicon Controlled Rectifier (SCR) in phase A, B or C (designated as X in the message) has been detected by the Liquid Cooled Solid State Starter Logic/Trigger Board. The voltage across each SCR in monitored to detect the shorted condition. The shorted condition must exist continuously for 5 seconds in order to annunciate the fault. This check is disabled while the chiller is running. The chiller can be started after the condition has been corrected and the Compressor Switch is placed in the Stop-Reset (O) position.

LCSSS – Open SCR

An open Silicon Controlled Rectifier (SCR) has been detected by the Liquid Cooled Solid State Starter Logic/Trigger Board. The open condition must exist continuously for 5 seconds in order to annunciate the fault. The chiller can be started after the condition has been corrected and the Compressor Switch is placed in the Stop-Reset (O) position. This check is disabled when the chiller is shut down. In certain applications, local power line conditions could interfere with the open SCR detection technique. This requires a qualified Service Technician to disable this check. Refer to *OptiView Control Center – Service Instructions (Form 160.54-M1)*.

LCSSS – Phase (X) Open SCR

(Software versions C.MLM.01.11.xxx and later or C.OPT.01.11.303 and later)

An open SCR in phase A, B or C (designated as X in message) has been detected. This safety shutdown has the same criteria as LCSSS – OPEN SCR above. However, when the Solid State Starter Logic/Trigger Board is equipped with Eprom version C.SSS.01.03 (and later) and the OptiView Control Center is equipped with above software, the phase in which the open SCR occurred is identified.

LCSSS – Phase Rotation

(Flash Memory Card version C.MLM.01.04 or later)

The Liquid Cooled Solid State Starter Logic/Trigger Board has detected the three phase compressor motor power line voltage phase rotation is not correct. The chiller can be started after the phase rotation is correct and the Compressor Switch is placed in the Stop-Reset (O) position.

COMPRESSOR MOTOR VARIABLE SPEED DRIVE: SAFETY SHUTDOWN MESSAGES

The following safety shutdown messages are displayed on Compressor Motor Variable Speed Drive (VSD) applications only. These messages are generated by events that occur within the VSD. The chiller can be started after manual resets are performed as detailed below. Service and troubleshooting information is contained in *Variable Speed Drive – Service Instructions* (Form 160.00-M1).

VSD Shutdown – Requesting Fault Data

The VSD has shut down the chiller and the Control Center has not yet received the cause of the fault from the VSD, via the serial communications link. The VSD shuts down the chiller by opening the Motor Controller VSD Stop Contacts (located on the VSD Logic Board and connected between TB6-16 and TB6-53 in the Control Center). The Microboard in the Control Center then sends a request for the cause of the fault to the VSD Logic Board via the Adaptive Capacity Control Board, over the serial link. Since serial communications are initiated every 2 seconds, this message is typically displayed for a few seconds and then replaced with one of the following fault messages.

VSD – 105% Motor Current Overload

This shutdown is generated by the VSD Logic Board and it indicates that a motor overload has occurred. The shutdown is generated when the VSD Logic Board has detected that at least 1 of the 3 output phase currents has exceeded 105% of the chiller Full Load Amps (FLA) value for greater than 7 seconds for TM models of drive, and 40 seconds for VSD and LVD models of drives. The chiller FLA value is set by adjustment of the FLA potentiometer on the VSD Logic Board. The chiller can be started after the RESET push-button on the VSD Logic Board is pressed and the Compressor Switch is placed in the Stop-Reset (O) position.

VSD – High Phase A Inverter Heatsink Temperature

(For TM model of drive)

This shutdown will occur if the heatsink temperature exceeds 158°F on any of the output pole assemblies. This shutdown will seldom occur. In most cases where the coolant temperature has risen abnormally, the VSD will shut down on Ambient Temperature at 140.0°F before the heatsinks can reach 158°F. If this message is displayed, make sure there is adequate coolant level, ascertain the pump is operating when the chiller is running, and check the strainer in the primary of the heat exchanger for clogs and silt. The chiller can be started after the fault condition clears, the RESET button on the VSD Logic Board is pressed and the Compressor Switch is placed in the Stop-Reset (O) position.

VSD – High Phase B Inverter Heatsink Temperature

(For TM model of drive)

See the VSD – High Phase A Inverter Heatsink Temperature message above.

VSD – High Phase C Inverter Heatsink Temperature

(For TM model of drive)

See the VSD – High Phase A Inverter Heatsink Temperature message above.

VSD – High Converter Heatsink Temperature

(For TM model of drive)

This shutdown occurs if the heatsink temperature exceeds 170° F (76.7°C) on the converter.

VSD – High Converter Heatsink Temperature

This shutdown occurs if the heatsink temperature exceeds the temperature threshold level listed in the following table. The chiller can be started after the fault condition clears and the Compressor Switch is placed in the Stop-Reset (O) position.

TABLE 8 - VSD, LVD CONVERTER OVERTEMPERATURE

DRIVE MODEL	DRIVE HP RATING	THRESHOLD SHUTDOWN VALUE (°F)
	270, 292, 351, 424	
	385, 419, 503	
LVD, VSD	608 (575 VAC)	170
	608 (400 VAC), 658, 704, 790	
	868, 882, 900, 914, 917, 948	
VSD	1100	170
LVD	546, 575, 750	175
LVD	1100	222

VSD – High Inverter Baseplate Temperature

This shutdown only applies to VSD and LVD models of drives that contain one power module in the inverter. If the temperature of the power module exceeds $175^{\circ}F$ (79.4°C), then this shutdown occurs. To restart the chiller, wait for the fault condition to clear, press the RESET button on the VSD Logic Board, and place the Compressor Switch in the Stop-Reset (O) position.

VSD – High Phase A Inverter Baseplate Temperature

The chiller has shut down because the baseplate temperature has increased to greater than the temperature threshold level listed in the following table. The chiller can be started after the fault condition clears and the RE-SET button on the VSD Logic Board and the Compressor Switch are placed in the Stop-Reset (O) position.

TABLE 9 - VSD, LVD INVERTER OVERTEMPERATURE

DRIVE MODEL	DRIVE HP RATING	THRESHOLD SHUTDOWN VALUE (°F)	
	385, 419, 503	175	
LVD, VSD	608 (575 VAC)	175	
	608 (400 VAC), 658, 704, 790	196	
LVD, VSD	868, 882, 900, 914, 917, 948,		
VSD	1100	196	
LVD	546, 575,	190	
LVD	750	210	
LVD	1100	232	

VSD – High Phase B Inverter Baseplate Temperature

See the information listed under *VSD – High Phase A Inverter Baseplate Temperature.*

VSD – High Phase C Inverter Baseplate Temperature

See the information listed under *VSD – High Phase A Inverter Baseplate Temperature*.

VSD – Precharge Lockout

If the VSD fails to make pre-charge, the pre-charge relay shall drop out for 10 seconds. During that time, the VSD's fans and water pumps shall remain energized in order to permit the pre-charge resistors to cool. Following this 10-second cool-down period, pre-charge shall again be initiated. The VSD shall attempt to make pre-charge three consecutive times. If the VSD fails to make pre-charge on three consecutive tries, the unit will shut down, lockout, and display this message. The chiller can be started after the Compressor Switch is placed in the Stop-Reset (O) position.

Harmonic Filter – High Heatsink Temperature

(For TM model of drive)

The Harmonic Filter power assembly has one heatsink on smaller horsepower models, and two heatsinks on the larger horsepower models. If there are two heatsinks, the highest temperature is reported to the control panel. If the temperature on any heatsink exceeds 167°F (75°C), the unit shuts down. This message is 3

usually an indication of a low coolant level in the VSD cooling loop. The chiller can be started after the fault condition clears, the OVERTEMP RESET button on the Filter Logic Board is pressed, and the Compressor Switch is placed in the Stop-Reset (O) position.

Harmonic Filter – High Baseplate Temperature

(For VSD model of drive)

This shutdown occurs when the baseplate temperature exceeds the temperature threshold listed in the following table. The chiller can be started after the fault condition clears, the OVERTEMP RESET button on the Filter Logic Board is pressed, and the Compressor Switch is placed in the Stop-Reset (O) position.

TABLE 10 - V	/SD FILTER	OVER TEMPE	ERATURE
---------------------	------------	------------	---------

DRIVE HP RATING	THRESHOLD SHUTDOWN VALUE, °F (°C)
270, 292, 351	174 (79.0)
385, 419, 424, 503, 608 (575 VAC)	190 (88.0)
608 (400 VAC), 658, 704, 790	193 (89.4)
868, 882, 914, 917, 948, 1100	174 (79.0)

Harmonic Filter – High Total Demand Distortion

This shutdown indicates the filter is not operating correctly and the input current to the VSD/Filter is not sinusoidal. This shutdown will occur if the TDD exceeds 25% continuously for 45 seconds. TDD is an acronym for Total Demand Distortion, a term defined by the IEEE Std 519-1992 standard as the total rootsum-square harmonic current distortion, in percent of the maximum demand load current (15 or 30 min demand). In the filter option supplied by YORK, the displayed TDD is the total RMS value of all the harmonic current supplied by the main power to the VSD divided by the chiller Full Load Amps, in percent. A standard VSD, less the optional filter typically has an input current TDD level on the order of 28-30%. The chiller can be started after the Compressor Switch is placed in the Stop-Reset (O) position.

VSD – Low Frequency Detected

(Software version C.MLM.01.14.xxx (and later) or C.OPT.01.14.306 (and later))

After a 20 second bypass after entering System Run, if the VSD frequency decreases to below 1 Hz less than the minimum allowed frequency for 25 continuous seconds, this shutdown is initiated. With software version C.OPT.01.19.307 (and earlier), this fault occurs when the VSD frequency falls below 1 Hz less than the minimum allowed frequency after having reached the minimum frequency. The minimum allowed frequency for the VSD is 25 Hz for 50 Hz units; 30 Hz for 60 Hz units. The Compressor Switch is placed in the Stop-Reset (O) position.

SECTION 4 - PRINTING



OKIPOS 441 Serial Charcoal p/n 62113901 Beige p/n 62113601

FIGURE 63 - PRINTER

PRINTING OVERVIEW

A printer can be connected to the Control Center's Microboard to print the following reports. The screen from which each report can be generated is listed in parenthesis.

- Status Present system parameters (Printer, Home)
- Setpoints Present programmed values of all setpoints (Printer, Setpoints)
- Schedule Present value of programmed daily schedule (Printer, Schedule)
- Sales Order Information about SALES ORDER Screen (Printer, Sales Order)
- **History** System parameters at the time of the last normal stop, last fault while running and last 10 faults, whether running or not (Printer, History)
- Cycling or Safety Shutdown Initiated Print -Snapshot of all system parameters at instant of shutdown. Automatically occurs if printer is connected at time of shutdown.
- Adaptive Capacity Control (ACC) Surge Map

 System conditions at instant all surge points were mapped. (Compressor Motor Variable Speed Drive applications; requires SERVICE access level) (Printer, ACC)

• Trend (Flash Memory Card version C.MLM.01.05.xxx and later) - Prints a snapshot of the existing TREND Screen data or prints new data collected after the TREND PRINT key is pressed.

The printer can be permanently connected to the Control Center or connected as required to produce a report. If permanently connected, a DATA LOGGING feature can produce a status report automatically, beginning at an Operator selected start time and occurring at an Operator selected interval thereafter.

The following figures are examples of the different print reports. Solid State Starter application print reports shown. Electromechanical Starter and Variable Speed Drive reports are similar but print parameters applicable to those devices.

- Figure 66 Sample Printout (Status) on page 194
- Figure 67 Sample Printout (Setpoints) on page 196
- Figure 68 Sample Printout (Schedule) on page 198
- Figure 69 Sample Printout (Sales Order) on page 198
- Figure 70 Sample Printout (History) on page 200
- Figure 71 Sample Printout (Security Log Report) on page 202 (Flash Memory Card version C.MLM.01.06.xxx and later and "P" compressors C.MLM.04.02.xxx and later)
- Figure 72 Sample Printout (Trend Data New or Existing Points) on page 202 (Flash Memory Card version C.MLM.01.05.xxx and later)
- Figure 73 Sample Printout (Custom Screen Report) on page 202 (If compressor other than "P", applies only to Flash Memory Card C.MLM.01.04 and later)
- Figure 74 Sample Printout (Adaptive Capacity Control New Map Point Report) on page 203
- Figure 75 Sample Printout (Adaptive Capacity Control Existing Map Points Report) on page 203

ACCEPTABLE PRINTERS

The following printers can be used. Printers must be equipped with an RS-232 Serial interface.

Okidata -

Models: OKIPOS 441

- Dimensions: 6.9 in. wide x 9.64 in. deep x 5.98 in. high
- Paper: 3.0 in. wide
- Type: Dot Matrix Impact
- Purchase: 800-OKIDATA Spare printer Ribbon Okidata 52119001 Black

The Control Center provides the required formatting control codes for the printers above when the printer is selected on the PRINTER Screen in the instructions below. These codes are transmitted through the serial interface to the printer to provide a proper print format.

Different printers require different formatting control codes. Other printers might provide proper operation when connected to the Control Center. However, the print format may not be correct or as desired.

Proceed with caution and use the following guidelines if an unlisted printer is selected:

- 1. All must be capable of RS-232 serial communications.
- 2. Primary differences between printers involve the formatting control codes required by the printer. These codes are sent from the Control Center to the printer. For example, Weigh-Tronix printers require a control code to select 40 column width. This same code is interpreted by the Okidata printer as an instruction to print wide characters. In some instances, a printer will ignore a code it cannot interpret.
- 3. The Control Center requires a busy signal from the printer when the printer receive buffer is full. This causes the Control Center to momentarily terminate data transmission until the printer can accept more data. The busy signal polarity must be asserted low when busy.

PRINTER CONNECTIONS

Connect the printers to the Control Center Microboard as follows. Only one printer can be connected at a time.

TABLE 11 - OKIDATA OKIPOS 441

MICROBOARD	PRINTER	FUNCTION
J2-4	pin 3 Tx (data to printer)	
J2-2	pin 20	DSR (busy signal from printer)
J2-9	pin 7	Gnd
Cabinet		Shield

Hardware required:

Cable

• #18 AWG stranded 50 ft. maximum length.

Connectors

Microboard

• None. Strip 1/4 in. insulation from wire and insert into screw terminal block.

Printers

• Okidata - 25 pin plug DB-25P or equivalent; Shell DB-C2-J9 or equivalent.

PRINTER SETUP

The selected printer must be configured as follows. Refer to manual provided by printer manufacturer with respective printer.

OKIDATA OKIPOS 441

- 1. With the printer power off, remove the two screws which hold the RS232 Interface Module.
- 2. Pull the RS232 Interface Module out of the printer.
- 3. Set DIP switch SW2-2 to OFF to select 19200 BPS. Do not change any other switch settings.
- 4. Re-install the RS232 Interface Module and two mounting screws.
- 5. Load paper and install the printer ribbon into the printer.
- 6. Connect the printer cable to the printer and the microboard.
- 7. Connect the printer power cable to the printer and plug into a 100 VAC to 240 VAC power source.

CONTROL CENTER SETUP

Chiller ID

Access Level Required: OPERATOR

Using the COMMS Screen, assign an identification number to the chiller. This number will appear at the top of each report.

Printer Setup

Access Level Required: OPERATOR

Using the COMMS Screen, the Control Center must be configured to transmit data in the same format as the printer is configured to receive the data. The following values must be entered.

FIELD	VALUE	
Baud Rate	Set to 19200	
Data Bits	8	
Parity	None	
Stop Bits	1	

Printer Type

Access Level Required: OPERATOR

Using the PRINTER Screen, set the printer type to Weigh-Tronix.

Automatic Data Logging

Access Level Required: OPERATOR

If automatic data logging is desired, a status report can be automatically printed at a specified interval beginning at a specified time, using the PRINTER Screen. The interval is programmable over the range of 1 minute to 1440 minutes in 1 minute increments. The first print will occur at the programmed START time and occur at the programmed Output Interval thereafter. The time remaining until the next print is displayed on the PRINTER Screen.

- Automatic Printer Logging Enables and disables automatic data logging.
- Log Start Time Enter the time the first print is desired.
- Output Interval Enter the desired interval between prints.

DOWNLOADING SYSTEM PRINTS TO A LAPTOP

Downloading system histories to a file is another useful method to capture system operating conditions. The following instructions are used to establish communication between the OptiView Control Panel and a laptop computer.

1. Connect the laptop computer to the OptiView as described below.

Laptop (RS-232 Serial Port)			Opti` (Coi	View m 1)
PIN	DESC		Connector	Terminal
2	RX	to	J2	4 (TXD1)
4	DTR	to	J2	2 (DSR1)
5	GND	to	J2	9 GND

2. On OptiView Printer Screen, select "PC". This will allow faster data download than the printer selections. SETTINGS should match "H Port settings" see below. Earlier software select SEIKO if PC selection is not available.

- 3. Setup HyperTerminal
 - a. Go to START menu.
 - b. Select All Programs.
 - c. Select Accessories.
 - d. Select Communications.
 - e. Select HyperTerminal.
 - f. In the box displayed, it requires a name and icon for the connection. Select a name that is descriptive and select an icon. Select OK.
 - g. In the box labeled Connect using the select com port that will connect to the YK unit. This port is usually labelled Com 1. Select OK.
 - h. Port settings are as follows:

FIELD	VALUE	
Bits per second	57600	
Data bits	8	
Parity	None	
Stop Bits	1	
Flow Control	None	

- 4. Set HyperTerminal to capture a file.
 - a. Select Transfer from toolbar.
 - b. Select Capture Text from the drop-down list.
 - c. A Capture Text Filebox will be displayed. Verify location and file name.
 - d. Select Start.
- 5. Press the Print Screen key on the appropriate screen to be captured. The HyperTerminal will display the printed information and the information will be recorded as a .txt file.

When the print file has been recorded, select Transfer from the toolbar and capture from the drop down menu and select Stop. This will stop the transfer and allow access to the capture file. The following additional RS232 connections, are used to wire up serial devices for desktop and laptop computers.

RS-232 PIN ASSIGNMENTS (DB25 PC SIGNAL SET) (OLDER DESKTOPS ONLY)		
Pin 1	Protective Ground	
Pin 2	Transmit Data	
Pin 3	Recieved Data	
Pin 4	Request To Send	
Pin 5	Clear To Send	
Pin 6	Data Set Ready	
Pin 7	Signal Ground	
Din 9	Recieved line Signal Detector	
FIIIO	(Data Carrier Detect)	
Pin 20	Data Terminal Ready	
Pin 22	Ring Indicator	

The connector on the PC has Male pins, therefore the mating cable needs to terminate in a DB25/F (Female pin) connector.

RS-232 PIN ASSIGNMENTS (DB9 PC SIGNAL SET) (MOST LAPTOPS)		
Pin 1	Recieved line Signal Detector	
	(Data Carrier Detect)	
Pin 2	Recieved Data	
Pin 3	Transmit Data	
Pin 4	Data Terminal Ready	
Pin 5	Signal Ground	
Pin 6	Data Set Ready	
Pin 7	Request To Send	
Pin 8	Clear To Send	
Pin 9	Pin 9 Ring Indicator	

The connector on the PC has male pins; therefore, the mating cable needs to terminate DB9/F (female pin) connector.

Brecknell -

Models: Brecknell CP130

- Dimensions: 5.25 in. (13.3 cm) long x 3.75 in. (9.5 cm) wide x 2.5 in. (6.4 cm) high
- Paper: Thermal 57 mm (2.25 in.)
- Type: Dot Matrix
- Purchase: 800-637-0529 (North America) +44 (0) 845-246-6717 (Europe and ME)
- P/N AWT 05-505788 (printer, cable, 1 roll of paper)
- P/N AWT 05-505594 (power supply)
- P/N AWT 05-505671 (case, 20 rolls of paper)



FIGURE 64 - BRECKMAN PRINTER

PRINTER CONNECTIONS



LD14492

FIGURE 65 - COMMUNICATIONS BLOCK DIAGRAM

Connect the printer to the Control Center Microboard as follows. Only one printer can be connected at a time.

TABLE 12 - BRECKNELL CP130

Modify the cable and connect as shown below.

MICROBOARD	PRINTER	FUNCTION	
J2-4	Pin 3	TX Data to the printer	
J2-2	Pin 5	Busy signal from the printer	
J2-9	Pin 6	Signal Common	

YORK UPDATE CHILLER ID 0 (c) 1997 - 2001 YORK INTERNATIONAL CORP Mon 22 Nov 1999 8:50:45 AM	ORATION	[Skip the fo enabled] Hot Gas
SYSTEM RUN LEAVING CHILLED LIQUID CONTROL		Valve Position Pre-Rotation
[List all warnings presently active] Controls C.MLM.01.06.102		Surge
Run Time O Days 2 Hr 59 Min		Total Surge C Surge Window
Operating Hours	= 25 Hr	Surge Window
Number Of Starts	= 6	
Evaporator	- LOCAL	[Skip the fo Pump is not Variable Spee
Leaving Chilled Active Setpoint	= 45.0 ~F	Oil Pump Driv
Chilled Liquid Pump	= Run	Pulldown Time
Chilled Liquid Flow Switch	= Closed	[If Pulldown
Return Chilled Liquid Temperature	= 45.0 ~F	
Evaporator Pressure	= 75.0 Psig	[Skip the fo
Evaporator Saturation Temperature	= 44.4 ~F	enabled]
Evaporator Refrigerant Temperature	= 44.5 ~F	Reirigerant L
[If Refrigerant Sensor enabled]		Befrigerant L
Small Temperature Difference	= 0.5 ~F	Ramp Up Time
Condenser		[If Ramp Up
Condenser Liquid Dump	- Dun	Proximity Pro
Condenser Liquid Flow Switch	= Run = Closed	
Leaving Condenser Liquid Temperature	= 95.0 ~F	High Speed Th
Return Condenser Liquid Temperature	= 85.0 ~F	High Speed Th
Condenser Pressure	= 200.0 Psig	[If Mod C Chi
Condenser Saturation Temperature	= 101.4 ~F	[Skin the fo
Small Temperature Difference	= 6.4 ~F	Electromechan
Drop Leg Refrigerant Temperature	= 83.0 ~F	
[II Drop Leg Sensor enabled]	- 19 / wE	Motor Run
[If Drop Leg Sensor enabled]	- 10.4 47	% Full Load A
Compressor		[Skip the fol.
Discharge Temperature	= 120.0 ~F	Motor Run
Liquid Line Solenoid	= On	% Full Load A
Vent Line Solenoid	= On	Phase A Volta
[If Mod D Chiller or higher]		Phase B Volta Phase C Volta
Oil Sump		Phase A Curre Phase B Curre Phase C Curre
Oil Pump Run Output	= On	Inabe e carre
Sump Oil Pressure (LOP)	= 75.8 Psig	[Skip the fo
Pump Oil Pressure (HOP)	= 124.6 Psig	B SSS]
Oil Sump Temperature	= 4/.8 Psid $= 150.0$ \sim F	Liquid-Cooled
Oil Heater	= 130.0 ~r = Off	
[If Mod D Chiller or higher]	V	Starter Model
Oil Return Solenoid	= Off	Motor Run
[If Mod D Chiller or higher]		% Full Load A
		KW HOURS
1		Tubac comet

FIGURE 66 - SAMPLE PRINTOUT (STATUS)

[Skip the following section if Hot Gas] enabled] Hot Gas	Зура	ass is not
Valve Position Pre-Rotation Vanes Position	=	15 % 75 %
Surge		
Total Surge Count	=	127
Surge Window Time Surge Window Count	=	l Min O
[Skip the following section if Variable Pump is not installed] Variable Speed Oil Pump	Spe	eed Oil
Oil Pump Drive Command Frequency Pulldown Time Remaining [If Pulldown in effect]	=	25.0 Hz 9.0 Min
[Skip the following section if Liquid Le enabled] Refrigerant Level Control	evel	is not
Refrigerant Level Position Ramp Up Time Remaining	= =	35 % 15 Sec
[If Ramp Up in effect] Proximity Probe		
High Speed Thrust Bearing Proximity Diffe High Speed Thrust Solenoid [If Mod C Chiller]	ren	= 2 Mils = On
[Skip the following section if Motor Ty] Electromechanical Starter	pe i	s not EM]
		<u></u>
MOTOF Kun % Full Load Amps	=	94 %
[Skip the following section if Motor Type is Liquid-Cooled Solid State Starter	not	Mod A SSS]
Motor Run	=	On
% Full Load Amps	=	94 %
Phase A Voltage	=	447 V
Phase B Voltage	=	409 V
Phase C Voltage	=	442 V
Phase A Current	=	193 A
Phase B Current	=	204 A
Phase C Current	=	190 A
[Skip the following section if Motor Type B SSS]	pe i	s not Mod
Liquid-Cooled Solid State Starter		
Starter Model	=	26L
Motor Run	=	On
% Full Load Amps	=	95 %
kW Hours	=	20723 kWH
Input Power	=	8225 kW

FIGURE 66 - SAMPLE PRINTOUT (STATUS) (CONT'D)

Phase A Voltage	=	422 V
Phase B Voltage	=	449 V
Phase C Voltage	=	449 V
Phase A Current	=	253 A
Phase B Current	=	257 A
Phase C Current	=	262 A
Phase A Temperature	=	109 ~F
Phase B Temperature	=	109 ~F
Phase C Temperature	=	110 ~F
[Skip the following section if Motor Typ Variable Speed Drive	be i	.s not VSD]
Motor Run	=	On
% Full Load Amps	=	94 %
Pre-Rotation Vanes Position	=	75 %
Full Load Amps	=	402 A
Precharge Relay Output	=	Off
Trigger SCR Output	=	On
Water Pump Output	=	On
kW Hours	=	14528 kWH
Input Power	=	150 kW
Output Frequency	=	60 Hz
Output Voltage	=	800 V
DC Bus Voltage	=	600 V
DC Inverter Link Current	=	300 A
Phase A Output Current	=	195 A
Phase B Output Current	=	198 A
Phase C Output Current	=	193 A
Internal Ambient Temperature	=	88 ~F
Converter Heatsink Temperature	=	102 ~F
Phase A Heatsink Temperature [If TMIII VS	D]	= 93 ~F
Phase B Heatsink Temperature [If TMIII VS	D]	= 99 ~F
Phase C Heatsink Temperature [If TMIII VS	D]	= 97 ~F
Baseplate Temperature [If VyperDrive VSD]	=	106 ~F

FIGURE 66 - SAMPLE PRINTOUT (STATUS) (CONT'D)

	=	
Precharge Contactor		Off
Supply Contactor	=	On
Operating Mode	=	Running
Phase Rotation	=	ABC
Total Supply kVA	=	148 kVA
Total Power Factor	=	0.97
DC Bus Voltage	=	608 V
Heatsink Temperature [If TMIII VSD]	=	102 ~F
Baseplate Temperature [If VyperDrive VSD]	=	102 ~F
Voltage Peak N-L1	=	200 V
Voltage Peak N-L2	=	200 V
Voltage Peak N-L3	=	200 V
L1-L2 RMS Voltage	=	215 V
L2-L3 RMS Voltage	=	215 V
L3-L1 RMS Voltage	=	215 V
L1 RMS Filter Current	=	150 A
L2 RMS Filter Current	=	150 A
L3 RMS Filter Current	=	150 A
L1 RMS Supply Current	=	152 A
L2 RMS Supply Current	=	152 A
L3 RMS Supply Current	=	152 A
L1 Voltage Total Harmonic Distortion	=	1.5 %
L2 Voltage Total Harmonic Distortion	=	1.2 %
L3 Voltage Total Harmonic Distortion	=	1.1 %
L1 Supply Current Total Demand Distortion	=	2.6 %
L2 Supply Current Total Demand Distortion	=	2.3 %
L3 Supply Current Total Demand Distortion	=	2.8 %

FIGURE 66 - SAMPLE PRINTOUT (STATUS) (CONT'D)

4

YORK SETPOINTS CHILLER ID 0 (c) 1997 - 2001 YORK INTERNATIONAL CORPORA Mon 22 Nov 1999 8:48:27 AM	ATI	ON
Software Versions		
Controls BIOS Kernel GUI SIO GPIC Ext I/O 0110112091996 [Skip if External I/O board is not activ VSD [Skip if Motor Type is not VSD]	= = = = = ate	C.MLM.01.04 C.MLM.00.00 0.18 0.28 0.23 0.04
System Information	-	C.555.01.01
System Language Data Display Mode Control Source Remote Analog Input Range Clock	= = = =	English English Local 0-10 Volts Enabled
Jumper Settings		
Pre-Run Coastdown Chilled Liquid Pump Operation Refrigerant Selection Anti-Recycle Power Failure Restart Liquid Type Motor Type		Standard Standard R22 Enabled Auto Water Fixed Speed
Printer Setup		
Automatic Printer Logging Log Start Time Output Interval Printer Type Baud Data Bits Parity Stop Bits		Disabled 12:00 am 60 Min Okidata 9600 Baud 8 Bits None 1 Bit
COM 2 Setup Baud Data Bits Parity	= = =	19200 Baud 8 Bits Odd
Stop Bits Evaporator	=	1 Bit
Leaving Chilled Local Setpoint Leaving Chilled ISN Setpoint Leaving Chilled Modem Setpoint Leaving Chilled Analog Setpoint Leaving Chilled Digital Setpoint	= = = =	45.0 ~F 45.0 ~F 45.0 ~F 45.0 ~F 45.0 ~F

FIGURE 67 - SAMPLE PRINTOUT (SETPOINTS)

Remote Range	=	10.0 ~F
Sensitivity	=	Normal
Restart Offset	=	0.0 ~F
Restart Setpoint	=	45.0 ~F
Shutdown Offset	=	4.0~F
Shutdown Setpoint	_	41 0 ~F
Prine Lew Evaporator Cutout	_	54 3 Psig
Stine Low Evaporator Cutout	_	off
Smart Freeze	=	
Refrigerant	-	Enabled
Condenser		
High Pressure Warning Threshold	_	246 3 Peig
Drop Log	_	Enabled
ыр тед	_	Bildbred
Oil Sump		
Oil Pump Package	_	Variable
Spood		Variabic
Standby Luba	_	07
Standby Lube	_	011
[Skip the following section if Variable] is not installed] Variable Speed Oil Pump	Spe	ed Oil Pump
Prossure Setpoint	_	35 Reid
Control Period	_	0 9 Sec
control refloa		0.9 800
Proximity Probe		
J 11 J		-
[Skip the following section if Liquid Le ena	vel ble	is not ed]
[Skip the following section if Liquid Le ena Refrigerant Level Control	vel ble	is not ed]
[Skip the following section if Liquid Le ena Refrigerant Level Control	vel ble	is not ed]
[Skip the following section if Liquid Le ena Refrigerant Level Control 	vel ble =	is not ed] On
[Skip the following section if Liquid Le ena Refrigerant Level Control 	vel ble = =	is not ed] On 50 %
[Skip the following section if Liquid Le ena Refrigerant Level Control 	vel ble = = =	is not ed] On 50 % 3.5 Sec
[Skip the following section if Liquid Let ena Refrigerant Level Control 	vel ble = = =	is not ed] On 50 % 3.5 Sec 15 %
[Skip the following section if Liquid Let ena Refrigerant Level Control Level Control Setpoint Period Proportion Limit Open Proportion Limit Close	vel ble = = =	is not ed] On 50 % 3.5 Sec 15 % 45 %
[Skip the following section if Liquid Let ena Refrigerant Level Control Level Control Setpoint Period Proportion Limit Open Proportion Limit Close Rate Limit Open	vel ble = = = = =	is not ed] On 50 % 3.5 Sec 15 % 45 % 10 %
[Skip the following section if Liquid Le ena Refrigerant Level Control Level Control Setpoint Period Proportion Limit Open Proportion Limit Close Rate Limit Open Rate Limit Close	vel ble = = = = =	is not ed] On 50 % 3.5 Sec 15 % 45 % 10 % 10 %
[Skip the following section if Liquid Ler ena Refrigerant Level Control Level Control Setpoint Period Proportion Limit Open Proportion Limit Close Rate Limit Open Rate Limit Close [Skip the following section if Hot Gas Br enabled] Hot Gas	vel ble = = = = = yypa	is not ed] On 50 % 3.5 Sec 15 % 45 % 10 % 10 % ss is not
[Skip the following section if Liquid Ler ena Refrigerant Level Control 	vel ble = = = = = yypa	is not ed] On 50 % 3.5 Sec 15 % 45 % 10 % 10 % ss is not
[Skip the following section if Liquid Ler ena Refrigerant Level Control 	vel .ble = = = = = ypa =	is not ed] On 50 % 3.5 Sec 15 % 45 % 10 % 10 % ss is not Enabled 30 Min
[Skip the following section if Liquid Ler ena Refrigerant Level Control 	vel ble = = = = = = = = = = = = = =	is not ed] On 50 % 3.5 Sec 15 % 45 % 10 % 10 % ss is not Enabled 30 Min 5 %
[Skip the following section if Liquid Ler ena Refrigerant Level Control 	vel ble = = = = = = = = yypa = =	is not ed] On 50 % 3.5 Sec 15 % 45 % 10 % 10 % ss is not Enabled 30 Min 5 %
[Skip the following section if Liquid Ler ena Refrigerant Level Control 	vel ble = = = = = = = = = = = = = = = = =	is not ed] On 50 % 3.5 Sec 15 % 45 % 10 % 10 % ss is not Enabled 30 Min 5 % 1 ~F 90 %
[Skip the following section if Liquid Ler ena Refrigerant Level Control Level Control Setpoint Period Proportion Limit Open Proportion Limit Close Rate Limit Open Rate Limit Close [Skip the following section if Hot Gas B enabled] Hot Gas Hold Period Close Percentage Minimum Load Maximum Open	vel ble = = = = = = = = = = = = = = = = = = =	is not ed] On 50 % 3.5 Sec 15 % 45 % 10 % 10 % ss is not Enabled 30 Min 5 % 1 ~F 80 %
[Skip the following section if Liquid Ler ena Refrigerant Level Control Level Control Setpoint Period Proportion Limit Open Proportion Limit Close Rate Limit Open Rate Limit Close [Skip the following section if Hot Gas B enabled] Hot Gas Hold Period Close Percentage Minimum Load Maximum Open Surge	vel ble = = = = = = = = = = = = = = = = =	is not ed] On 50 % 3.5 Sec 15 % 45 % 10 % 10 % ss is not Enabled 30 Min 5 % 1 ~F 80 %
[Skip the following section if Liquid Ler ena Refrigerant Level Control Level Control Setpoint Period Proportion Limit Open Proportion Limit Close Rate Limit Open Rate Limit Close [Skip the following section if Hot Gas Br enabled] Hot Gas Hold Period Close Percentage Minimum Load Maximum Open Surge	vel ble = = = = = = = = = = = = = = = = = = =	is not ed] On 50 % 3.5 Sec 15 % 45 % 10 % 10 % ss is not Enabled 30 Min 5 % 1 ~F 80 %
[Skip the following section if Liquid Ler ena Refrigerant Level Control Level Control Setpoint Period Proportion Limit Open Proportion Limit Close Rate Limit Open Rate Limit Close [Skip the following section if Hot Gas Br enabled] Hot Gas Hold Period Close Percentage Minimum Load Maximum Open Surge Surge Sensitivity Shutdown	vel ble = = = = = = = = = = = = = = = = = = =	is not ed] On 50 % 3.5 Sec 15 % 45 % 10 % 10 % ss is not Enabled 30 Min 5 % 1 ~F 80 %
[Skip the following section if Liquid Ler ena Refrigerant Level Control Level Control Setpoint Period Proportion Limit Open Proportion Limit Close Rate Limit Open Rate Limit Close [Skip the following section if Hot Gas B enabled] Hot Gas Hold Period Close Percentage Minimum Load Maximum Open Surge Surge Sensitivity Shutdown Extended Run	vel ble = = = = = = = = = = = = = = = = = =	<pre>is not ed] On 50 % 3.5 Sec 15 % 45 % 10 % 10 % ss is not Enabled 30 Min 5 % 1 ~F 80 % O.3 Enabled Disabled</pre>
[Skip the following section if Liquid Ler ena Refrigerant Level Control Level Control Setpoint Period Proportion Limit Open Rate Limit Open Rate Limit Close [Skip the following section if Hot Gas B enabled] Hot Gas Hold Period Close Percentage Minimum Load Maximum Open Surge Surge Sensitivity Shutdown Extended Run Count Limit	vel ble = = = = = = = = = = = = = = = = = = =	is not ed] On 50 % 3.5 Sec 15 % 45 % 10 % ss is not Enabled 30 Min 5 % 1 ~F 80 % 0.3 Enabled Disabled 15
[Skip the following section if Liquid Ler ena Refrigerant Level Control Level Control Setpoint Period Proportion Limit Open Rate Limit Open Rate Limit Close [Skip the following section if Hot Gas B enabled] Hot Gas Hold Period Close Percentage Minimum Load Maximum Open Surge Surge Sensitivity Shutdown Extended Run Count Limit Count Window	vel ble = = = = = = = = = = = = = = = = = = =	<pre>is not ed] On 50 % 3.5 Sec 15 % 45 % 10 % 10 % ss is not Enabled 30 Min 5 % 1 ~F 80 % O.3 Enabled Disabled 15 5 Min</pre>
[Skip the following section if Liquid Ler ena Refrigerant Level Control Level Control Setpoint Period Proportion Limit Open Rate Limit Open Rate Limit Close [Skip the following section if Hot Gas B enabled] Hot Gas Hold Period Close Percentage Minimum Load Maximum Open Surge Surge Sensitivity Shutdown Extended Run Count Limit Count Window	vel ble = = = = ypa = = = = = = = = = = = = =	is not ed] On 50 % 3.5 Sec 15 % 45 % 10 % 10 % ss is not Enabled 30 Min 5 % 1 ~F 80 % 0.3 Enabled Disabled 15 5 Min

FIGURE 67 - SAMPLE PRINTOUT (SETPOINTS) (CONT'D)

SECTION	4 - F	PRINT	ING
---------	-------	-------	-----

[Skip the following section if Mo	tor Type is not EM]	Shorted SCR	= Disabled
electromechanical starter		[Skip the following section if M.	otor Type is not VSD
Local Motor Current Limit	= 100 %	Variable Speed Drive	
Remote ISN Current Limit	= 100 %		
Remote Analog Current Limit	= 100 %	Local Motor Current Limit	= 100 %
Remote Digital Current Limit	= 100 %	Remote ISN Current Limit	= 100 %
Remote Modem Current Limit	= 100 %	Remote Analog Current Limit	= 100 %
Pulldown Demand Limit	= 100 %	Remote Digital Current Limit	= 100 %
Pulldown Demand Time	= 0 Min	Remote Modem Current Limit	= 100 %
		Pulldown Demand Limit	= 100 %
[Skip the following section if Mo	tor Type is not Mod A	Pulldown Demand Time	= 0 Min
SSS]		Motor HP	= 351 HP
Liquid-Cooled Solid State Starter		Power Line Frequency	= 60 Hz
Local Motor Current Limit	= 100 %	[Skip the following section if M	otor Type is not VSD
Remote ISN Current Limit	= 100 %	Harmonic Filter Data	
Remote Analog Current Limit	= 100 %		
Remote Digital Current Limit	= 100 %	Filter Operation	= Enabled
Remote Modem Current Limit	= 100 %	Motor HP	= 351 HP
Pulldown Demand Limit	= 100 %		
Pulldown Demand Time	= 0 Min	[Skip the following section if M	otor Type is not VSD
Scale/Model	= 600 V, 281	Adaptive Capacity Control	
Supply Voltage Range	= Disabled		
Full Load Amps	= 150 A	Surge Margin Adjust	= 0 Hz
Current Imbalance Check	= Disabled	Stability Limit	= 4500
[Skip the following section if Mo	tor Type is not Mod B		
SSS]			
Liquid-Cooled Solid State Starter			
Local Motor Current Limit	= 100 %		
Remote ISN Current Limit	= 100 %		
Remote Analog Current Limit	= 100 %		
Remote Digital Current Limit	= 100 %		
Remote Modem Current Limit	= 100 %		
Pulldown Demand Limit	= 100 %		
Pulldown Demand Time	= 0 Min		
Starter Model	= 26L		
Voltage Range	= 440 - 480		
Full Load Amps	= 275 A		
Starting Current	= 1150 A		
)pen SCR	= Enabled		

FIGURE 67 - SAMPLE PRINTOUT (SETPOINTS) (CONT'D) FIGURE 67 - SAMPLE PRINTOUT (SETPOINTS) (CONT'D)

YORF	SCHE	DULE	:					
СНІІ	LER I	D 3						
© 199	97 - 199	9 YOI	RK INT	ERNAT	IONAL	CORPO	RATI	ON
MON 2	9 MAR 1	999	1 27	PM				
SCHEI	DULE							= OFF
STANI	DARD SCH	EDULI	Ξ					
SUN	START	=	OFF		STOP	=	OFF	
MON	START	=	8:00	AM	STOP	=	5:0	0 PM
TUE	START	=	8:00	AM	STOP	=	5:0	0 PM
WED	START	=	8:00	AM	STOP	=	5:0	0 PM
THU	START	=	8:00	AM	STOP	=	5:0	0 PM
FRI	START	=	8:00	AM	STOP	=	5:0	0 PM
SAT	START	=	OFF		STOP	=	OFF	
EXCEP	TION DA	YS						
02 AE	'R 1999	STAI	<'I' =	OFF		STOP	=	OFE
13 AF	PR 1999	STAP	RT =	8:00	AM	STOP	=	10:00 PM

FIGURE 68 - SAMPLE PRINTOUT (SCHEDULE)

YORK SALES ORDER CHILLER ID 3 © 1997 - 1999 YORK INTERNATIONAL CORPORAT	TON			
MON 29 MAR 1999 1 28 PM	101			
ORDER INFORMATION				
COMMISSIONING DATE	=	01	JAN	199
JOB NAME	=			
JOB LOCATION	=			
MODEL NUMBER	=			
YORK ORDER NUMBER	=			
PANEL SERIAL NUMBER	=			
CHILLER SERIAL NUMBER	=			
DESIGN LOAD - CONDENSER	=			
 PASSES	=			
DESIGN WORKING PRESSURE	=			
FOULING FACTOR	=			
PRESSURE DROP	=			
NOZZLE ARRANGEMENT IN	=			
NOZZLE ARRANGEMENT OUT	=			
LEAVING TEMPERATURE	=			
RETURN TEMPERATURE	=			
GPM	=			
TUBES	=			
DESIGN LOAD - EVAPORATOR				
 PASSES	=			
DESIGN WORKING PRESSURE	=			
FOULING FACTOR	=			
PRESSURE DROP	=			
NOZZLE ARRANGEMENT IN	=			
NOZZLE ARRANGEMENT OUT	=			
LEAVING TEMPERATURE	=			
RETURN TEMPERATURE	=			
GPM	=			
TUBES	=			

FIGURE 69 - SAMPLE PRINTOUT (SALES ORDER)

NAMEPLATE INFORMATION	
MOTOR CODE	=
POWER (VOLTS)	=
PHASES	=
FREQUENCY (HZ)	=
LOOKED ROTOR AMPS	=
FULL LOAD AMPS	=
INRUSH AMPS	=
SYSTEM INFORMATION	
REFRIGERANI	-
TONS	=
GEAR CODE	=
LIQUID TYPE	=
BRINE PERCENT	=
KILOWATTS INPUT	=
VSD / SSS / EM	=

FIGURE 69 - SAMPLE PRINTOUT (SALES ORDER) (CONT'D)

4

JOHNSON CONTROLS

FORM 160.54-O1
ISSUE DATE: 06/14/2019

YORK HISTORY 1 CHILLER ID 0 (c) 1997 - 2001 YORK INTERNATIONAL COR Mon 22 Nov 1999 9:23:12 AM	PORATI	ON
SYSTEM READY TO START LCSSS - LOGIC BOARD POWER SUPPLY [List any warnings that were active a shutdown]	t the 1	time of
Controls C.MLM.01.06.102 Run Time O Days 2 Hr 59 Min		
Operating Hours Number Of Starts Control Source	= = =	25 Hr 6 Local
Evaporator 		
Leaving Chilled Active Setpoint Chilled Liquid Pump Chilled Liquid Flow Switch Leaving Chilled Liquid Temperature Return Chilled Liquid Temperature Evaporator Pressure Evaporator Saturation Temperature Evaporator Refrigerant Temperature [If Refrigerant Sensor enabled] Small Temperature Difference	= = = = = =	45.0 ~F Stop Open 45.0 ~F 55.0 ~F 75.0 Psig 44.4 ~F 44.5 ~F 0.5 ~F
Condenser		
Condenser Liquid Pump Condenser Liquid Flow Switch Leaving Condenser Liquid Temperature Return Condenser Liquid Temperature Condenser Pressure Psig Condenser Saturation Temperature Small Temperature Difference Drop Leg Refrigerant Temperature [If Drop Leg Sensor enabled] Sub Cooling Temperature [If Drop Leg Sensor enabled]	= = = = = =	Stop Open 95.0 ~F 85.0 ~F 200.0 101.4 ~F 6.4 ~F 83.0 ~F 18.4 ~F
Compressor		
Discharge Temperature Liquid Line Solenoid [If Mod C Chiller] Vent Line Solenoid [If Mod D Chiller or higher]	=	120.0 ~F Off Off
Oil Sump		
Oil Pump Run Output Sump Oil Pressure (LOP) Pump Oil Pressure (HOP) Oil Pressure Oil Sump Temperature Oil Heater [If Mod D Chiller or higher]	= = = =	Off 75.8 Psig 76.6 Psig 0.0 Psid 150.0 ~F Off
Oil Return Solenoid [If Mod D Chiller or higher]	=	Off

[Skip the following section if Hot Gas E enabled] Hot Gas	Bypass is not
Valve Position	= 0 %
Pre-Rotation Vanes Position	= 0 %
Surge	
Total Surge Count	= 127
Surge Window Time	= 1 Min
Surge Window Count	= 0
[Skip the following section if Variable Pump	Speed Oil is not
Variable Speed Oil Pump	
Oil Pump Drive Command Frequency	= 25.0 Hz
Pulldown Time Remaining	= 9.0 Min
[If Pulldown in effect]	
[Skip the following section if Liquid Le enabled]	evel is not
Refrigerant Level Control	
Refrigerant Level Position	= 35 %
Ramp Up Time Remaining	= 15 Sec
[If Ramp Up in effect]	
Proximity Probe	
High Speed Thrust Bearing Provimity Diffe	ren = 2 Mile
High Speed Thrust Solenoid	= Off
[If Mod C Chiller]	011
[Skip the following section if Motor Typ Electromechanical Starter	be is not EM]
Motor Bun	= 0ff
% Full Load Amps	= 0 %
[Skip the following section if Motor Typ A SSS1	be is not Mod
Liquid-Cooled Solid State Starter	
Motor Run	= Off
% Full Load Amps	= 0 %
Phase A Voltage	= 447 V
Phase B Voltage	= 409 V
Phase C Voltage	= 442 V
Phase A Current	= 0 A
Phase C Current	= U A = 0 A
	- 0 A
[Skip the following section if Motor Typ B SSS]	be is not Mod
Liquid-Cooled Solid State Starter	
Starter Model	= 26L
Motor Run	= Off
% Full Load Amps	= 0 %
kW Hours	= 20723 kWH
Input Power	= 0 kW

FIGURE 70 - SAMPLE PRINTOUT (HISTORY) (CONT'D)

Phage A Veltage	_	122 17
Phase A Voltage	=	422 V
Phase B voltage	=	449 V
Phase C Voltage	=	449 V
Phase A Current	=	0 A
Phase B Current	=	0 A
Phase C Current	=	0 A
Phase A Temperature	=	109 ~F
Phase B Temperature	=	109 ~F
Phase C Temperature	=	110 ~F
[Skip the following section if Motor Typ Variable Speed Drive	be i	is not VSD]
Motor Run	=	OII
% Full Load Amps	=	0 %
Pre-Rotation Vanes Position	=	0 %
Full Load Amps	=	402 A
Precharge Relay Output	=	Off
Trigger SCR Output	=	Off
Water Pump Output	=	Off
kW Hours	=	14528 kWH
Input Power	=	0 kW
Output Frequency	=	0 Hz
Output Voltage	=	0 V
DC Bus Voltage	=	600 V
DC Inverter Link Current	=	0 A
Phase A Output Current	=	0 A
Phase B Output Current	=	0 A
Phase C Output Current		0 A
Internal Ambient Temperature	=	88 ~F
Converter Heatsink Temperature	=	102 ~F
Phase A Heatsink Temperature [If TMIII VS	D]	= 93 ~F

FIGURE 70 - SAMPLE PRINTOUT (HISTORY) (CONT'D)

Phase C Heatsink Temperature [If TMIII VS Baseplate Temperature [If VyperDrive VSD] [Skip the following section if Motor Type	D] = is	= 97 ~F 106 ~F not VSD,
or Filter is not present]		
Harmonic Filter Data		
Precharge Contactor	=	Off
Supply Contactor	=	Off
Operating Mode	=	Stoppeu
Phase Rotation	=	ABC
Total Supply KVA	_	U KVA
Total Power Factor	-	0.00
DC BUS VOLLAGE = 000 V	_	102
Reacondate Temperature [If VuperDrive VSD]	-	102 ~r 102 ~F
Maltaca Deak N-I.1	_	200 V
Voltage reak N-12	_	200 V
Voltage rear N-12 Voltage Peak N-I.3	=	200 V 200 V
T1-T2 RMS Voltage	=	215 V
L2-L3 RMS Voltage	=	215 V
I.3-I.1 RMS Voltage	=	215 V
1.1 RMS Filter Current	=	0 A
1.2 RMS Filter Current	=	0 A
L3 RMS Filter Current	=	0 A
L1 RMS Supply Current	=	0 A
L2 RMS Supply Current	=	0 A
L3 RMS Supply Current	=	0 A
L1 Voltage Total Harmonic Distortion	=	1.5 %
L2 Voltage Total Harmonic Distortion	=	1.2 %
L3 Voltage Total Harmonic Distortion	=	1.1 %
L1 Supply Current Total Demand Distortion	=	0.0 %
L2 Supply Current Total Demand Distortion	=	0.0 %
L3 Supply Current Total Demand Distortion	=	0.0 %

Phase B Heatsink Temperature [If TMIII VSD] = 99 ${\rm \sim F}$

FIGURE 70 - SAMPLE PRINTOUT (HISTORY) (CONT'D)

4

YORK SETPOINT CHANGE LOG				
(a) 1007 2001 YORK INTERNATIONAL CORPORATION				
Fri 05 Oct 2001 4.48.04 PM	1011	101		
111 00 000 2001 1.10.01 111				
Log Entry 1 Evaporator - Leaving Chilled	Lo	ocal Setpoint		
Date	=	05 Oct 2001		
Time	=	4:23:49 PM		
Access Level	=	Service		
User Id	=	4268		
Old Value	=	46.5 ~F		
New Value	=	48.0 ~F		
Log Entry 2 Condenser - High Pressure Wa	rni	.ng Threshold		
Date	=	05 Oct 2001		
Time	=	1:36:12 PM		
Access Level	=	Service		
User Id	=	4268		
Old Value	=	162.5 Psig		
New Value	=	225.0 Psig		
Log Entry 3 Condenser - Drop Leg				
Date	=	05 Oct 2001		
Time	=	1:36:02 PM		
Access Level	=	Service		
User Id	=	4268		
Old Value	=	Disabled		
New Value	=	Enabled		
Log Entry 4 Evaporator - Refrigerant				
Date		05 Oct 2001		
Time	_	1.35.48 DM		
Access Level	_	Service		
Here Id	_	1268		
Old Malua	_	4200 Dissblad		
New Welve	=	Disabled		
New Value	=	FURDIED		

FIGURE 71 - SAMPLE PRINTOUT (SECURITY LOG REPORT)

YORK TREND				
CHILLER ID 163				
© 1997 - 2000 YORK INTERNATIONAL CORPORATION				
MON 09 OCT 2000 3:33:47 PM				
DATA 1: LEAVING CHILLED LIQUID TEMPERATURE				
DATA 2: RETURN CHILLED LIQUID TEMPERATURE				
DATA 3: EVAPORATOR PRESSURE				
DATA 4: LEAVING CONDENSER LIQUID TEMPERATURE				
DATA 5: RETURN CONDENSER LIQUID TEMPERATURE				
DATA 6: CONDENSER PRESSURE				
TIME DATA 1 DATA 2 DATA 3 DATA 4 DATA 5 DATA	6			
3:33:47 PM 45.5 °F 55.0 °F 39.0 PSIG 95.0 °F 85.0 °F 120.0 P	SIG			
3:33:48 PM 45.5 °F 55.0 °F 39.0 PSIG 95.0 °F 85.0 °F 120.0 P	SIG			
3:33:49 PM 45.5 °F 55.0 °F 39.0 PSIG 95.0 °F 85.0 °F 120.0 P	SIG			
3:33:50 PM 45.5 °F 55.0 °F 39.0 PSIG 95.0 °F 85.3 °F 120.1 P	SIG			
3:33:51 PM 45.5 °F 55.2 °F 39.1 PSIG 95.1 °F 85.4 °F 120.2 P	SIG			

FIGURE 72 - SAMPLE PRINTOUT (TREND DATA NEW OR EXISTING POINTS)

CHILLER ID 0 (c) 1997 - 2001 YORK INTERNATIONAL CORPORATION Mon 21 Jun 1999 1:28:25 PM Leaving Chilled Liquid Temperature = 45.0 ~F Return Chilled Liquid Temperature = 55.0 ~F

YORK CUSTOM VIEW

Leaving Condenser Liquid Temperature	=	95.0 ~F
Return Condenser Liquid Temperature	=	85.0 ~F
Evaporator Saturation Temperature = 41.0	$\sim F$	
Condenser Saturation Temperature	=	78.5 ~F
Evaporator Pressure	=	70.0 Psig
Condenser Pressure	=	140.0 Psig
Oil Pressure	=	45.0 Psid
% Full Load Amps	=	50 %

FIGURE 73 - SAMPLE PRINTOUT (CUSTOM SCREEN REPORT)

Log Time: Mon 12:45:39 PM 21 Jun 1999	
D-P/P= 0.92; Prv Pos= 56; Freq= 39 Hz	
Surge Type	= Delta P/P Surge
Leaving Chilled Active Setpoint	= 45.0 ~F
Leaving Chilled Liquid Temperature	= 50.0 ~F
Return Chilled Liquid Temperature	= 59.3 ~F
Leaving Condenser Liquid Temperature	= 85.0 ~F
Return Condenser Liquid Temperature	= 94.9 ~F
Evaporator Pressure	= 7.2 Psig
Condenser Pressure	= 13.8 Psig
% Full Load Amps	= 94 %

FIGURE 74 - SAMPLE PRINTOUT (ADAPTIVE CAPACITY CONTROL NEW MAP POINT REPORT)

D-P/P = 1.20;	Prv Pos =	= 89;	Freq =	58 Hz
D-P/P = 1.41;	Prv Pos =	= 71;	Freq =	46 Hz
D-P/P = 0.98;	Prv Pos =	= 73;	Freq =	52 Hz
D-P/P = 0.71;	Prv Pos =	= 86;	Freq =	39 Hz
D-P/P = 0.86;	Prv Pos =	= 53;	Freq =	48 Hz
D-P/P = 1.14;	Prv Pos =	= 76;	Freq =	51 Hz
D-P/P = 0.84;	Prv Pos =	= 84;	Freq =	37 Hz
D-P/P = 0.99;	Prv Pos =	= 63;	Freq =	46 Hz

FIGURE 75 - SAMPLE PRINTOUT (ADAPTIVE CAPACITY CONTROL EXISTING MAP POINTS REPORT)

NOTES

The following factors can be used to convert from English to the most common SI Metric values.

TABLE 13 - SI METRIC CC	NVERSION
-------------------------	-----------------

MEASUREMENT	MULTIPLY ENGLISH UNIT	BY FACTOR	TO OBTAIN METRIC UNIT
Capacity	Tons Refrigerant Effect (ton)	3.516	Kilowatts (kW)
Power	Horsepower	0.7457	Kilowatts (kW)
Flow Rate	Gallons / Minute (gpm)	0.0631	Liters / Second (l/s)
Length	Feet (ft)	0.3048	Meters (m)
	Inches (in)	25.4	Millimeters (mm)
Weight	Pounds (lbs)	0.4536	Kilograms (kg)
Velocity	Feet / Second (fps)	0.3048	Meters / Second (m/s)
Pressure Drop	Feet of Water (ft)	2.989	Kilopascals (kPa)
	Pounds / Square Inch (psi)	6.895	Kilopascals (kPa)

TEMPERATURE

To convert degrees Fahrenheit (°F) to degrees Celsius (°C), subtract 32° and multiply by 5/9 or 0.5556.

Example: (45.0°F - 32°) x 0.5556 = 7.22°C

To convert a temperature range (i.e., a range of 10°F) from Fahrenheit to Celsius, multiply by 5/9 or 0.5556.

Example: 10.0° F range x $0.5556 = 5.6^{\circ}$ C range



5000 Renaissance Drive, New Freedom, Pennsylvania USA 17349 Copyright © by Johnson Controls 2019 Form 160.54-O1 (619) Issue Date: June 14, 2019 Supersedes: 160.54-O1 (419) 1-800-524-1330 www.johnsoncontrols.com