

POWER
FOR THE **WAVES**
PURE MARINE
CERTIFIED PRODUCT



marine HMD8 DSP

USER'S MANUAL

rev. 1a



Index

1. PRODUCT DESCRIPTION / PRECAUTIONS	3
2. PACKAGE CONTENTS	4
3. HMD8 DSP INSTALLATION	5
3.1 DEVICE INSTALLATION	5
4. CONNECTION PANEL DESCRIPTION	6
1 POWER	6
2 FUSE	7
3 CTRL (REM IN-OUT. / CONTROL)	7
4 SPEAKER OUT	8
5 SPEAKER IN	8
6 PRE IN	8
7 SUB OUT	9
8 OPTICAL IN	9
9 PRESET	9
10 UPGRADE switch	9
11 MICRO USB	9
12 DRC	9
13 LOGO STATUS	9
5. CONNECTIONS	10
5.1 POWER SUPPLY AND REMOTE TURN ON	10
5.2 MEMORY SELECTION SWITCH	11
5.3 INPUT SIGNALS	11
5.4 DIGITAL OPTICAL IN INPUT SIGNALS	12
5.5 OUTPUT SIGNALS	13
5.6 PC CONNECTION	14
6. CONFIGURATION SOFTWARE	15
6.1 LINK TO DEVICE	15
6.2 SAVE AND LOAD THE CONFIGURATION	16
6.3 SETTINGS	16
6.4 AUDIO SETUP	17
6.4.1 GENERAL GUIDELINES	17
6.4.2 SOURCES	19
6.4.3 INPUT CHANNELS	20
6.4.4 OUTPUT CHANNELS	22
6.4.5 OUTPUT CHANNEL GROUPS	23
6.4.6 LISTENING ZONES	24
6.4.7 MIXER	25
6.4.8 DELAYS AND DISTANCES	26
6.4.9 CROSSOVER	29
6.4.10 EQUALIZER	31
6.4.11 MEMORIES	32
6.4.12 GRAPH	38
6.4.13 WORK NOTES	40
6.5 EXTENDED FUNCTIONALITIES	41
6.5.1 WIZARD	41
6.5.2 FEATURES	42
6.5.3 REAL TIME ANALYSIS	42
6.5.4 STATUS BAR	43
7. TROUBLESHOOTING	44
7.1 SYNCHRONIZATION WITH A PC	44
7.2 FIRMWARE UPDATE	44
8. TECHNICAL SPECIFICATIONS	45

1. PRODUCT DESCRIPTION / PRECAUTIONS

Thank you for purchasing the **HMD8 DSP** amplifier for your marine sound system. Your amplifier has been designed and manufactured to exacting standards in order to ensure years of musical enjoyment in your vessel. For maximum performance, we highly recommend that you have your new amplifier installed by an authorized Hertz dealer. Your authorized dealer has the training, expertise and installation equipment to ensure optimum performance from this product. Should you decide to install the amplifier yourself, please take the time to read this manual thoroughly so as to familiarize yourself with its installation requirements and setup procedures. If you have any questions regarding the instructions in this manual or any aspect of your amplifier's operation, please contact your authorized Hertz dealer for assistance.

This section describes the main features of the amplifier and the connector panel. Some operating procedures for the correct installation and the best use of the product are also illustrated.

HMD8 DSP is a 9-channel amplifier with 8 amplified channels settable in bridge mode; it also features a 32 bit, 147 MHz clock speed, 24 bit AD/DA converter digital sound processor (DSP), essential to maximize the acoustic performance of your audio system. It features 6 Hi-Level / 6 Pre input channels on the master analog source and 1 S/PDIF optical digital.

It provides 8 amplified power outputs and 1 pre-amplified optimized to drive a subwoofer.

Before connecting the product, carefully read this manual.

Improper connections may cause damage to **HMD8 DSP** or to the speakers in your audio system.

It is important that you take the time to read this manual and that you plan out your installation carefully.



Protect Your Hearing.

Studies have shown that continuous exposure to high sound pressure levels can lead to permanent (irreparable) hearing loss. This and all other high-power amplifiers are capable of producing very high sound pressure levels when connected to a speaker system. Please limit your continuous exposure to high volume levels.

While driving, operate your audio system in a manner that still allows you to hear necessary noises to operate your vessel safely (horns, sirens, etc.).



This amplifier is designed for operation in vessels with 12V or else 24V and negative-ground electrical systems, according to the information silk-screened on the amplifier power connection terminal.

Use of this product in vessels with positive ground and/or voltages other than 12V or 24V may result in damage to the product and will void the warranty.

This product is not certified or approved for aircraft use.



The external case of this amplifier is designed to remove heat from the amplifier circuitry.

For optimum cooling performance, this external case should be exposed to as large a volume of air as possible.

Enclosing the amplifier in a small, poorly ventilated chamber can lead to excessive heat build-up and degraded performance.

If an installation calls for an enclosure around the amplifier, we recommend that this enclosure be ventilated with the aid of a fan.

In normal applications, fan-cooling is not necessary.



The amplifier needs to be installed in a dry, well-ventilated environment and in a manner which does not interfere with your vessel's factory installed electronic devices.

You should also take the time to securely mount the amplifier so that it does not come loose in the event of a collision / sudden jolt or as a result of the repeated vibrations the vessel is prone to during normal operation.



While this amplifier is specially designed for marine applications, it is not waterproof and it should not be mounted where it is likely to get wet.

The following are some considerations that you must take into account when planning your installation.

Remark: Check before drilling any holes in your vessel to make sure that you will not be drilling through the hull, a fuel tank, fuel line, wiring harness or other vital vessel system.

Remark: Do not run system wiring outside or underneath the vessel. This is an extremely dangerous practice which can result in severe damage to your vessel and person.

Remark: Protect all system wires from sharp edges (metal, fiberglass, etc.) by carefully routing them, tying them down and using grommets and loom where appropriate.

Remark: Do not mount the amplifier in the engine compartment or in any other area that will expose the amplifier circuitry to the elements.


WARNING: 1. A PC provided with Windows 7, Windows 8 or Windows 10 operating system, 1.5 GHz minimum processor speed, 2 GB RAM minimum memory and a 1024 x 600 pixels minimum resolution graphics card as well as at least 1 GB of available hard-disk space is required to install the software and setup the product.



2. Before connecting the product, carefully read this manual. Improper connections may cause damage to HMD8 DSP or to the speakers in your vessel audio system.

2. PACKAGE CONTENTS


- HMD8 DSP amplifier




- Multipolar cable, Rem/Control:




- Multipolar cable, Input Pre-IN:




- Multipolar cable, Hi-level Input:




- Output Multipolar cable:




- 2 - 30 A replacement fuse:
or
2 - 15 A replacement fuse:




- 1.8 m USB cable:



- 2.5 mm hex key:




- 4 - 4.2 x 50 mm self-tapping, cross head mounting screws:



- CD ROM containing:
HMD8 DSP Software
This owner's manual (.pdf)
Audio Test Tracks




- SWITCH for memory selection:





3. HMD8 DSP INSTALLATION


External size




Mounting size



WARNING for all cable INPUT/OUTPUT



How to mount



3.1 DEVICE INSTALLATION

The following represents the sequence for a typical amplifier installation, using an aftermarket source unit or OEM Interface processor.


Additional steps and different procedures may be required in some applications.

If you have any questions, please contact your authorized Hertz dealer for assistance.

1. Disconnect the negative battery post connection and secure the disconnected cable to prevent accidental re-connection during installation. This step is not optional!
2. Run positive and negative power wire from the battery location to the amplifier mounting location, taking care to route it in such a way that it will not be damaged and will not interfere with vessel operation.
3. Connect power wire to the positive battery post.
4. Connect negative power wire to the negative battery post. Use the same size power wire as the wire connected to the positive power supply connection.
5. Run signal cables and remote turn-on wire from the source unit or interface processor to the amplifier mounting location. Run also the control cables for memory switch.
6. Run speaker wire from the speakers to the amplifier mounting location.
7. Securely mount the amplifier using appropriate hardware.
8. Connect the remote turn-on wire and the positive and negative power wires to the amplifier's power connector plug.
9. Connect the input cables to the amplifier.
10. Connect the speaker wires to the speaker connector.
11. Carefully review the amplifier's control settings to make sure that they are set according to the system's needs.

At this point you can turn on the amplifier and start the software configuration, according to the design of your audio system.

4. CONNECTION PANEL - DESCRIPTION



1 POWER.

+ Power (11-15 VDC or 22-34 VDC according to POWER silk-screened value): connection terminal for power supply positive pole.

The jack accepts a stripped cable up to 15mm / 0.6" with maximum section of 8 AWG ($\varnothing$ 3,2mm / 0.12"). For better power transfer we recommend using cables with the largest possible cross-section and with the same cross-section as the cable connected to the negative pole.


- Power (Ground): connection terminal for the negative power supply pole of the amplifier. Connect here the negative battery cable or a cable connected to the metal part of the vessel chassis. The socket will take a stripped cable up to 15mm / 0.6" with a maximum section of 8 AWG ($\varnothing$ 3,2mm / 0.12"). For better power transfer, we recommend using cables with the largest possible section and with the same section as the cable connected to the positive pole. In order to correctly connect the ground (-), use a screw that is already present on the metal part of the vessel; if necessary, remove any paint residue or grease, using a tester to make sure there is continuity between the negative terminal (-) on the battery and the mounting point. If possible, connect all of the grounds on the audio components to the same grounding point. This helps to reduce most of the interference than can occur in audio reproduction.

WARNING: make sure the connection polarity is as indicated on the terminals. A misconnection may result in damage to the device. After applying power, wait at least 10 seconds before turning the device on.





2 FUSE

30 A blade protection fuse for 12V power supply or 15 A blade protection fuse for 24V power supply. In case the fuse needs to be replaced, use same type and value as the original.




3 CTRL (REM IN-OUT / CONTROLS): terminals to turn on and control the HMD8 DSP.

- **Remote IN:** input to turn on the device. The voltage must be between 7 and 14.5 VDC for 12V power supply or between 6 and 34 VDC for 24V power supply.
- **Remote OUT:** output to turn on other devices connected in cascade.
- **CONTROL 1:** it allows the memory selection. This control is active bringing the terminal to +12 V or +24 V according to power supply voltage. More details on **Memory selection switch** ([see section 5](#)).
- **CONTROL 2:** it allows the memory selection. This control is active bringing the terminal to +12 V or +24 V according to power supply voltage. More details on **Memory selection switch** ([see section 5](#)).




4 SPEAKER OUT.

HMD8 DSP is provided with a 16 pole multipolar connector to manage the power output signals.




5 SPEAKER IN.

HMD8 DSP is provided with a 12 pole multipolar connector to manage the input signals. Connect up to a maximum of 6 input channels using the multipolar connector supplied. The signal to be applied must have a value ranging between 2.2 and 22 Vrms. Such input channels can be then customized using the configuration software.



6 PRE IN

HMD8 DSP is provided with a 12 poles multipolar connector to manage the PRE IN input signals to interface head units featuring a PRE OUT output. Connect up to a maximum of 6 input channels using the multipolar connector supplied. The signal to be applied must have a value ranging between 0.6 and 6 Vrms. Such input channels can be then customized using the configuration software.



7 SUB OUT.

Pre-amplified output subject to low pass filtering optimized to drive a mono amplifier for an external subwoofer or active subwoofer.

8 OPTICAL IN.

HMD8 DSP accepts at its input PCM signals up to 192 kHz / 24 bit sampling frequency rate. Connect a fiber optic cable with a TOSLINK connector.

Remark: DOLBY DIGITAL (AC3) multi-channel signals coming from audio/video sources (such as the audio of a film in DVD) or DTS can not be reproduced.

9 PRESET.

HMD8 DSP features 7 setups preloaded in its memory, identified by the numbers 1 to 7 of the selector. They allow the product to be used without the need to connect it to a PC.

WARNING: Make sure you have connected the speakers according to the scheme of the selected preset before turning the amplifier on.



Remark: when using one of the 7 presets, communication via USB is inhibited and the configuration software is unable to detect the device even if it is connected to the PC.

By turning the selector to position 0, the device is fully configurable by the user through the configuration software via USB connection.

10 UPGRADE switch.

Switch ON allows the product to be updated in BOOT LOADER mode.

11 Micro USB.

USB micro receptacle to connect the product to a PC in order to manage the functions using the configuration software. The connection is USB 1.1/2.0/3.0 compatible.

12 DRC.

Terminal for future use.

13 LOGO STATUS.

HMD8 DSP is provided with a built-in control that manages its status and protects the circuits and connections to the speakers. The logo on the **HMD8 DSP** top cover will change its status in case of any possible product malfunctions.

A WHITE logo means:

HMD8 DSP is on.

Flashing RED/WHITE logo means:

The "**UPGRADE MODE**" switch on the product is set to "**ON**" position, or the product Firmware is being updated.

Flashing RED logo means:

- **HMD8 DSP** temperature reached 75° C and the thermal protection was triggered. It will start operating again at around 70° C.

RED logo flashing twice every second means:

- Output overload. The red LED flashes when the output load goes below the minimum allowed capacity of about 2Ω impedance. The LED comes on without flashing, activating the protection. When listening to music, if the acoustic reproduction stops for a few seconds, check if the red amplifier LED is flashing. This means there was an overload. Turn the amplifier off and check the speakers and wirings. This protection is self-restoring.
- Speaker wiring anomaly. The red LED flashes when a terminal on the speaker goes in short-circuit. When listening to music, if the acoustic reproduction stops for a few seconds, check to see if the red amplifier LED is flashing; this means there was a short circuit between the two terminals. Turn off the amplifier and check the speakers and wiring. This protection is self-restoring.

RED logo flashing four times every second means:


- "**OVER VOLTAGE**" protection activation, due to the fact that the battery voltage is higher than **18V** (for HMD8 DSP 12V); **36V** (for HMD8 DSP 24V) .
The product will turn off after 3 minutes.

RED logo means:

- Product internal fault. Please contact an authorized service centre. The product will turn off after 3 minutes.

5. CONNECTIONS

5.1 POWER SUPPLY AND REMOTE TURN ON




How to turn HMD8 DSP on and off

HMD8 DSP can be turned on/off by connecting the REMOTE IN terminal with a Remote Out signal coming from an after market audio source. When it is on the logo is white.

WARNING: select the version of the HMD8 DSP (12 V or 24 V) which has the same power supply voltage as the battery installed on the vessel.

5.2 MEMORY SELECTION SWITCH

Together with the amplifier, a three-position switch is provided for manual selection of memories. The connection scheme is shown in the image below.



Connection notes

- The **CTRL 2** wire of the control cable is connected to terminal 1 of the memory switch.
- The **CTRL 1** wire of the control cable is connected to terminal 3 of the memory switch.
- The terminal 2 of the memory switch must be connected to power supply voltage (+12 V or +24 V).

Memory selection switch positions


- Central position: **Memory 1** is selected.
- Pressing the bottom of the switch: **Memory 2** is selected.
- Pressing the top of the switch: **Memory 3** is selected.

Remark: with the memory selection switch at least one memory is always selected.


WARNING: when the amplifier is connected to the PC via the USB cable, the control for the memories selection is performed exclusively by the configuration software: the memory selection switch is automatically disabled.

5.3 INPUT SIGNALS


1. PRE INPUT ZONE 1 + ZONE 2 + SUB



2. PRE INPUT ZONE 1 + ZONE 2



5.4 DIGITAL OPTICAL IN INPUT




WARNING: the digital input accepts up to 192 kHz / 24 bit stereo PCM signals. So DOLBY DIGITAL (AC3) multi-channel signals coming from audio/video sources (such as the audio of a film in DVD) or DTS can not be reproduced. The output of these devices will therefore have to be set in STEREO mode for the signal to be reproduced.

How to select the OPTICAL input:

Using the **PC software** ([see sec. 6.4.2](#)) and "Finalize" the device.

5.5 OUTPUT SIGNALS



1. HMD8 DSP provides 8 amplified outputs. Through the PC Software, each output channel is provided with the following [\(see sec. 6.4.4\)](#):

- the dedicated audio channel send of the mixer [\(see sec. 6.4.7\)](#);
- a digital time delay line and distance setting [\(see sec. 6.4.8\)](#);
- an electronic crossover with 5 filter types and phase inversion activation [\(see sec. 6.4.9\)](#);
- a 10 pole graphic/parametric equalizer [\(see sec. 6.4.10\)](#);

In addition each output channel can:

- be assigned to a listening zone [\(see sec. 6.4.6\)](#)
- belong to one or more groups [\(see sec. 6.4.5\)](#)


CH 1 ÷ CH 8 AMPLIFIED OUTPUT CHANNELS CONFIGURATION

POWER CHANNEL CONFIG	
STEREO MODE	BRIDGE MODE
CH1 85 W @ 4 Ohm / 130 W @ 2 Ohm CH2 85 W @ 4 Ohm / 130 W @ 2 Ohm	CH1+ / CH2 - 260 W @ 4 Ohm
CH3 85 W @ 4 Ohm / 130 W @ 2 Ohm CH4 85 W @ 4 Ohm / 130 W @ 2 Ohm	CH3+ / CH4 - 260 W @ 4 Ohm
CH5 85 W @ 4 Ohm / 130 W @ 2 Ohm CH6 85 W @ 4 Ohm / 130 W @ 2 Ohm	CH5+ / CH6 - 260 W @ 4 Ohm
CH7 85 W @ 4 Ohm / 130 W @ 2 Ohm CH8 85 W @ 4 Ohm / 130 W @ 2 Ohm	CH7+ / CH8 - 260 W @ 4 Ohm

2. HMD8 DSP features a preamplified output (4 V Rms max.) SUB OUT that exclusively controls a mono amplifier for subwoofer, or one active subwoofer to amplify the sound system. This output corresponds to "OUT 9" PC Software graphic interface.

5.6 PC CONNECTION

1. HMD8 DSP connection with PC



6. CONFIGURATION SOFTWARE

This section describes the main features of the configuration software: Navigator.



The software was designed to be adopted by all products with onboard DSP in the Hertz marine catalog and future ones: when you connect the device to the software, it automatically configures itself to display the interface of that specific device connected.

Navigator can also be used without a real physical device, as it provides a series of virtual devices that fully reflect the respective real counterparts.

6.1 LINK TO DEVICE

When you start the software, an initial screen appears, listing all the devices you can connect to it. You can see an example in the image below:



- ① **real DEVICE connected to the PC:** the software detected an HMD8 DSP device connected via USB to the PC;
- ② **virtual DEVICE:** it is a virtual model of a real device;
- ③ **refresh button:** update all the lists.

Once the device has been selected, the software communicates with it and displays the current configuration.

Remark: the device must be switched on and connected to the PC so that it can appear in the list of the available devices.

6.2 SAVE AND LOAD THE CONFIGURATION

The software provides the ability to save the current configuration to a file, upload one already saved on your PC and other important features.

These are available on the top command bar, as shown in the image below.



- 1 OPEN**
Load configuration from a file saved on the PC.
- 2 SAVE**
Save the current configuration to a file on the PC.
- 3 SAVE AS**
Save a named copy of the current configuration to a file on the PC.
- 4 FINALIZE**
Writes the current status of the device to memory, the current configuration becomes permanent and is retained after power down.
- 5 DEVICE RESET TO FACTORY DEFAULT**
Clear the device memory containing the user settings; it returns to the default condition. Presets are not cleared.

Remark: in the default condition, the device does not reproduce any sound in the output channels: this is because the audio mixer (the routing of the inputs to the outputs) has a zero value for all the sends.

6.3 SETTINGS


The software provides the ability to change general settings. The icons for general settings are available on the top right command bar, as shown in the image below.



- 1 AUDIO SETTINGS**
access the audio settings panel. See **Real time analysis** ([see sec. 6.5.3](#)).
- 2 SETTINGS**
access the general settings panel of the configuration software.
- 3 HELP**
to open the user guide.
- 4 INFO**
access the panel containing information about the software.

Settings

The image below shows the general settings panel:



- ① **Sampling frequency:** allows you to set the sampling frequency used by the audio processor (DSP).
- ② **Language:** allows you to set the software interface language.
- ③ **Unit of measure:** allows you to set the unit of measurement choosing between centimeters (cm) or inches (in).

WARNING: the DSP mounted on this device is capable of processing the signal only at 48 kHz.



6.4 AUDIO SETUP

The following paragraphs describe the functions to adjust the system and its acoustic fine tuning.

WARNING: we recommend performing the various configuration tasks in the order described in the General guidelines



(see sec. 6.4.1).

6.4.1 GENERAL GUIDELINES

To carry out a correct system configuration, it is advisable to follow a precise logical order: a thorough understanding of all the phases necessary for the construction of the system is essential to avoid errors or, in the worst case, damage to the components.

The following procedure describes in steps how to obtain a correct audio configuration of the amplifier.

- Sources definition (see sec. 6.4.1.1)
- Input channels definition (see sec. 6.4.1.2)
- Output channels definition (see sec. 6.4.1.3)
- Crossover initialization (see sec. 6.4.1.4)
- Mixer setup (see sec. 6.4.1.5)
- Output level and delay adjustment (see sec. 6.4.1.6)
- Crossover and equalizer configuration (see sec. 6.4.1.7)
- Memories configuration (see sec. 6.4.1.8)

6.4.1.1 SOURCES DEFINITION

First you need to identify the sources you intend to use in your system. Give each one a meaningful name.

WARNING: assigning the name to the elements is of great help in the specialization of your system. It is advisable to do this for all setup elements where required, from here on out.



Disable the sources you do not intend to use.

6.4.1.2 INPUT CHANNELS DEFINITION

For each active source, assign a meaningful name to all input channels.

Disable those channels that are not used in the configuration.

Complete the configuration of each input channel by entering the sensitivity value if necessary.



6.4.1.3 OUTPUT CHANNELS DEFINITION

The output channels represent the points where the sound is reproduced, i.e. where the speakers are physically connected. Ultimately, the output configuration is the one that most characterizes the audio system. It is important to have the system project clearly in mind before starting: the type and the position of loudspeakers, the need for bridged channels, how many listening areas must be created.

So, for each output channel:

- assign a meaningful name;
- specify if it is a bridge mode channel;
- assign the channel to a listening zone;
- if necessary assign the channel to one or more groups.

Disable unused channels.

At this point it is possible to define the position of each speaker in the respective listening area. This setting is very important, because it provides essential information to the software for the automatic calculation of delays in order to align the sound stage.

6.4.1.4 CROSSOVER INITIALIZATION

To avoid damaging the speakers, before starting to play the system it is important to set the crossover filter of each output channel (for each source you intend to use) with an initial value that respects the dynamic range of each speaker.

At a later stage you can go back and adjust this setting to get the best result.

WARNING: this setting is related to a particular output channel, for the currently selected source. It must therefore be repeated for all output channels, for each source.



6.4.1.5 MIXER SETUP

Once the input and output configurations are known, the mixer can be set.

Remark: starting from the default configuration, at this point the system does not reproduce any sound yet.

We must specify how the inputs flow onto the outputs.

In the mixer, the signal of each output channel can be constructed as a weighted sum of the signals coming from the input channels.

WARNING: acting on the mixer, the system will start to reproduce audio. It is strongly recommended to keep the general volume of the system at a very low level, to avoid damaging the speakers.



Remark: although it might seem obvious, it is worth keeping in mind the fact that each source has its own mixer.

6.4.1.6 OUTPUT LEVEL AND DELAY ADJUSTMENT

Now that the system is playing, you can act on the levels of the individual output channels, to balance the energy contribution of each speaker and if necessary also the time alignment.

Remark: it is important to bear in mind that these adjustments refer to the position in which the listening area is centered.

WARNING: output level is related to a specific output channel. Its regulation must therefore be repeated for all output channels.



WARNING: delay adjustments are related to a specific output channel, for the currently selected source. They must therefore be repeated for all output channels, for each source.



6.4.1.7 CROSSOVER AND EQUALIZER CONFIGURATION

This step can be done once the system is well defined.

In fact it is the optimization of the sound stage, that is a compensation of all those factors, internal and external to the system, that ensures a correct sound reproduction.

The ultimate goal is to achieve a balanced setup, in which all the components act consistently to provide a neutral listening experience.

WARNING: these settings are related to a specific output channel, for the currently selected source. They must therefore be repeated for all output channels, for each source.



6.4.1.8 MEMORIES CONFIGURATION

The memories act on all the output channels and serve to give a particular nuance setting to the system.

Unlike the previous settings which are an essential and fixed part of the setup, the memory can be activated or deactivated by the end user while listening.

6.4.2 SOURCES

The Sources represent the devices from which to reproduce audio signals and which can be connected to the amplifier. Based on the technical specifications, an amplifier can be connected to one or more sources. Source selection is possible using the configuration software.



- ① **Selection button:** select the source.
- ② **Sources settings panel:** access the sources settings panel.
- ③ **Copy panel:** access the source copy panel.
- ④ **Help:** to open the user guide.


Remark: there is always a source selected. It is not possible to deselect all the sources.

Remark: it is not possible to select multiple sources at the same time.

Remark: each source has its own number of input channels.

■ SOURCES SETTINGS PANEL

The image below shows the settings panel for the sources.



The sources can be:

- renamed;
- disabled / enabled.


Remark: not all sources can be disabled: the master source is always enabled.

■ COPY PANEL

The image below shows the settings panel for the sources.

By selecting the copy destination checkbox and confirming, the following fields will be copied for all the output channels from the current source to the checked one:

- crossover;
- equalizer;
- delay (both the delay in milliseconds and the delay correction in samples).



6.4.3 INPUT CHANNELS

The Input channels depend directly on the currently selected source. Each source has its number of inputs and its type of inputs. In this amplifier the input channels are analog for the MASTER source and digital for the OPTICAL source.

■ ANALOG INPUT CHANNELS

The image below shows the inputs panel for the MASTER source.

- 1 **Input channel name:** this label is read-only.
- 2 **Sensitivity:** selection of the input sensitivity through the drop-down menu.
- 3 **Digital clip:** the LED lights up if the channel saturates the digital dynamic of the input converters.
- 4 **Input settings panel:** access the input settings panel.



The image below shows the sensitivity scale for an analog input channel: the value at the top indicates the lowest sensitivity level; the value at the bottom corresponds to the highest sensitivity level. The scale has double values: they are related to the type of analog input connector used, i.e. SPEAKER IN or PRE IN.


Procedure for sensitivity adjustment:

WARNING: the head unit level must be adjusted to the maximum undistorted level. If the initial head unit distortion level can not be determined, adjust the volume to approximately 80% of its maximum. If the head unit output level is set too low, the device may produce ground noise (hissing sound) when playing music tracks. This is due to the low signal / noise ratio provided by the head unit to the amplifier input. If you experience this problem, increase the head unit volume.


Remark: after adjusting the head unit level, select the sensitivity value that does not cause clipping on the inputs.

Step by step select an ever increasing sensitivity (i.e. decreasing numerical values on the scale) as long as the LED of the digital clip remains off.

Remark: repeat the sensitivity adjustment operation for all the analog inputs used.



The image below shows one of the input settings panels for the MASTER source.




The input channel can be:

- renamed;
- disabled / enabled.


▪ DIGITAL INPUT CHANNELS

The image below shows the inputs panel for the OPTICAL source.



Remark: for digital input channels sensitivity should not be adjusted.

The image below shows one of the input settings panels for the OPTICAL source.



The input channel can be:

- renamed;
- disabled / enabled.


6.4.4 OUTPUT CHANNELS

The output channels represent the fundamental elements of the audio system: in the final analysis they can be considered like installed speakers.

In the software, each channel has a color associated with it: when a specific channel is selected, the graphic interface elements that concern it take up that same color.

The image below shows the settings panel for the selected output channel.

- ① **Output channel name:** the user can customize the channel by assigning it a name that describes it.
- ② **Enabled switch:** it enables or disables the channel. It is recommended to disable all unused output channels.
- ③ **Listening zones:** a channel can belong to one and only one listening zone. The output panel displays only the channels of the current selected zone.
- ④ **Groups:** a channel can belong to one or more groups. A group of output channels shares a common group volume.
- ⑤ **Links:** it allows you to link the selected channel to other channels belonging to the same zone. The effect of this link is such that changes made to the volume, crossover or equalizer of the selected channel are also reflected on the linked channels.
- ⑥ **Bridge switch:** it allows you to set the channel in bridge configuration.



The image below describes the graphic interface behaviour related to the output channel settings.



- ① **Selection button:** select the channel.
- ② **Loudspeaker distance:** shows the distance of the speaker from the center of the listening area.
- ③ **Mute and solo:** allows you to mute the channel (mute) or to listen to it silencing all the others (solo).
- ④ **Channel level:** adjust the channel level.
- ⑤ **Digital clip:** the LED lights up if the channel saturates the digital dynamic.
- ⑥ **Output settings panel:** access the output settings panel.
- ⑦ **Bridged channels appearance:** when a channel is set to bridge mode, it logically joins the next to create one of greater power. In the software a channel in bridge mode is represented in this way.
- ⑧ **Disabled channels appearance:** a disabled channel is hidden and no longer appears in any of the graphical interface references.
- ⑨ **Loudspeaker position panel:** access the output channel position panel.
- ⑩ **Automatic delay calculation command:** this function automatically sets the delays of all output channels of the current zone starting from the position of the speakers.
- ⑪ **Help:** to open the user guide.

6.4.5 OUTPUT CHANNEL GROUPS

Each output channel can be associated with one or more groups. If the output channel is associated with one or more groups, its volume will also be adjusted according to the volumes of the associated groups.


The association with the groups can be performed in the output channel [\(see sec. 6.4.4\)](#) settings panel.

By selecting a group, you can adjust the volume in the relative panel showed in the image below:

- ① **Group level:** adjust the group level.
- ② **Selection button:** select the group.
- ③ **Groups settings panel:** open the groups settings panel.
- ④ **Help:** to open the user guide.



The next image shows the settings panel for the groups where you can rename them:



Remark: the most common use is to associate one or more outputs to a group to adjust the volume of the subwoofer.

6.4.6 LISTENING ZONES

The idea behind the zones is to provide the possibility to divide the output channels when they are spatially distant from each other so much as to consider them in different environments. The division into zones is therefore justified if the layout of the output channels is distributed over different environments.

Remark: for this reason it is possible to associate each output channel only to one zone.

One zone may contain more than one output channel.


The association of an output channel with a zone can be performed in the **output channel** ([see sec. 6.4.4](#)) settings panel.

The zone panel is showed in the image below.

- ① **Selection button:** select the zone.
- ② **Zones settings panel:** access the zones settings panel.
- ③ **Help:** to open the user guide.




Remark: the graphic interface behavior related to the output channels changes according to the selected zone.



The image above shows the settings panel for the zones where you can rename them:

The selected zone avails of the controls shown in the image below:



- ① **Mute and solo:** allows you to mute all the channels of that zone (mute) or to listen to them silencing the ones belonging to other zones (solo).
- ② **Zone level:** adjust the zone level.

6.4.7 MIXER

The mixer allows you to adjust the mixing percentage of the input channels on each output channel. The mixer is accessible through the top command bar.

To exit the mixer, press the related button again.



The image below shows the graphic interface of the mixer.



The mixer is structured as a matrix:

- the rows feature the inputs related to the currently selected source;
- the columns feature the output channels belonging to the selected zone.

Remark: by default the mixer has all sends at 0%.

Within each output channel, identified by the colored border, the signal can be composed by clicking and dragging the bar that indicates the percentage: this means that an input channel can go to one or more outputs.

Remark: a negative percentage of a specific input channel contribution indicates a phase inversion on that contribution.

Some use cases shown in the image above:

- if an input channel has been disabled (as the AN 6), the corresponding row in the mixer will be empty;
- if an output channel has been disabled (as the OUT 9), the corresponding column in the mixer will be empty.
- if an output channel is set in bridge mode (as the OUT 3 and OUT 5), the outline of the cluster will have two colors.

Remark: each source has its own mixer that must be set. If a source is enabled but its mixer has not been set, a warning message will be shown on the status bar.

Remark: if the output channels are positioned on different zones, it is necessary to select the zone to which they belong in order to adjust the mixer.

Remark: if in the mixer there are unused input channels, or outputs that do not receive any contribution, a warning is shown on the status bar.

WARNING: an output channel can receive a sum of contributions greater than 100%. We strongly advise against it because there is a risk of output digital clip. A warning will be shown on the status bar.



6.4.8 DELAYS AND DISTANCES

This setting is based on an automatic system that calculates the time needed for the sound to get from the speaker to the listener's ear.

Preliminary remarks

Sound moves through the air at a speed of 343 m/sec (1.125 ft/sec) at a temperature of 20 °C (68 °F). If you know the distance from the sound emission point, you can then calculate the time the sound takes to get to the listener's ear. If you set the distances of the different speakers, the software will automatically change them into time (ms -milliseconds). It does not assign a delay (0 ms) to the farthest speaker (usually the subwoofer) and progressively growing delays as much as the other speakers get closer to the listening point, in order for all the emission points to reach the listening point at the same time. Delay assignment according to distance calculation is theoretical. Small variations must be applied due to small errors in distance measurement, back-wave reflections inside closed environments and, primarily, the speaker phase problem. Two speakers reproducing two contiguous portions of the audio signal frequency spectrum (e.g.: woofer and midrange) will simultaneously reproduce the same frequencies in their crossing area, at an attenuated level. Due to the different nature of the speakers, they will have a phase difference that, for a short frequency interval, acts as a time delay. By using the delay correction you can partly correct these Phase Delay problems.

• DELAYS

The image below shows the delay panel:

- ① **Delay:** allows you to insert from the keyboard the delay value (in milliseconds) of the current selected output channel. If the delay value entered goes beyond the limits of the DSP, it will be set to the maximum value allowed.

WARNING: by editing the delay value in milliseconds and pressing enter, the delay correction in samples is automatically reset.

- ② **Delay correction:** the delay can be manually fine-tuned. A single sample at a time (1 smp) can be added to or subtracted from the delay line of the current output channel by pressing on the arrows.

Remark: 1 sample corresponds to a time delay of: $1 / \text{Sampling Frequency [Hz]} = [\text{seconds}]$. The actual sampling frequency can be read inside the global settings panel on the top right of the configuration software.

Remark: the correction of the delay in samples can be either positive or negative. In any case the starting value of the delay to which the correction is applied, is the one visible in the text box (1). Overall, the delay plus the correction for each output channel will always be limited between 0 ms and the maximum allowed by the DSP. Assigning a positive value for the correction (+xx) means increasing the delay for that speaker and thus moving it farther away from the listening point. Likewise, assigning a negative value (-xx) means decreasing the speaker delay and thus moving it closer to the listening point.

- ③ **Automatic delay calculation command:** this function automatically sets the delay of the current output channel starting from the position of the speaker. The next paragraph explains how to set the speakers position.

Remark: this command calculates the delay only for the currently selected output channel and for the current source. The delay correction in samples is reset.

- ④ **Help:** to open the user guide.



Remark: if necessary, the delay and the delay correction setting can be performed for each output channel and for each source.

• DISTANCES

The image below shows the output channels panel and the functions relating to the speakers position.



- ① **Loudspeaker position panel:** open the output channel position panel.

Remark: the loudspeaker position panel should be set for each zone that contains output channels.

- ② **Loudspeaker distance:** shows the distance of the speaker from the center of the listening area.

- ③ **Automatic delay calculation command:** this function automatically sets the delays of all the output channels of the current zone and for the current source, starting from the position of the speakers. The delay correction in samples is reset.

Remark: once the automatic delay calculation has been carried out, it is possible to make a fine adjustment by applying a delay correction to every single output channel through the delay panel.


Remark: it is advisable to use the automatic delay calculation command on all the zones that contain the output channels and for all the available sources of the device, unless you want to manually enter the delay value in the delay panel.

- ④ **Help:** to open the user guide.

The unit of measurement of the distance (centimeters or inches) can be set inside the global settings panel on the top right of the configuration software.

• LOUDSPEAKER POSITION PANEL

The image below shows the loudspeaker position panel and its functions.



- ① **Maximum distance limit:** this function is not active by default. When activated the possibility of moving the loudspeakers is reduced within the red dashed line. This limit represents the maximum loudspeakers distance allowed from the DSP delay lines; if all the loudspeakers in the map were moved away from the listening point, the red circumference would increase its radius and a gray circle would appear in the center to indicate the forbidden area within which the speakers cannot stand. If activated, this function ensures that you can then use the automatic delay calculation command. However this function may not be activated and the loudspeakers be positioned at any distance even outside the red circle: the drawback is that the automatic delay calculation command may not be able to calculate the delays based on distances.
- ② **Zoom out:** to reduce the image size.
- ③ **Zoom fit:** automatically sets the optimal view.
- ④ **Zoom in:** to enlarge the image size.
- ⑤ **Loudspeaker distance:** allows you to enter the loudspeaker distance with the keyboard. You can also click and drag the loudspeaker onto the map.
- ⑥ **Loudspeaker angle:** allows you to enter the loudspeaker angle with the keyboard. You can also click and drag the loudspeaker onto the map. The 0° angle is on the vertical axis upwards; the angles are positive in a clockwise direction.
- ⑦ **Loudspeaker selection buttons:** allows you to select a loudspeaker and bring it to foreground if it is hidden by other loudspeakers. Initially all the loudspeakers are in the listening point.
- ⑧ **Close button:** allows you to close the loudspeaker position panel without saving the changes. The distances are not updated.
- ⑨ **Confirmation button:** allows you to update the positions of the loudspeakers but does not calculate the delays. The set distances are visible in the output channels panel.
- ⑩ **Help:** to open the user guide.

Remark: the center of the map, that is the center of the axes, represents the listening point.

Remark: each zone has its own listening point with respect to which delays are calculated.

Remark: only the channels belonging to the currently selected zone are displayed on the map

Remark: the positions set for the output channels relate to the spatial location of the loudspeakers and are the same for all sources of the device.

WARNING: if an output channel is moved from one zone to another, its position is preserved but it is advisable to recalculate the delays of both zones involved using the automatic delay calculation command on the output channels panel.

6.4.9 CROSSOVER

With the crossover section it is possible to set different bands for every output channel.

Remark: the output channel you are acting on is indicated by the foreground color of the crossover panel.

The image below shows the crossover parameters that it is possible to set:

- ① **Type:** allows you to choose the type of crossover.
- ② **Name:** allows you to choose the name of the crossover.
- ③ **Slope:** opens a drop-down menu that allows you to select the slope.
- ④ **Frequency:** allows you to set the cut-off frequency by turning the knob or entering the value from the keyboard.
- ⑤ **Phase:** allows you to invert the signal phase by 180 °, whatever type or name you select.
- ⑥ **Copy panel:** opens the crossover copy panel.
- ⑦ **Help:** to open the user guide.

WARNING: the parameters are linked to each other in the order shown above. When a parameter is changed, it may cause changes to other parameters. Be careful when changing the parameters.

Remark: the crossover of each output channel is linked to the currently selected source. For each source it is necessary to set the crossovers on the output channels.




■ TYPE

The first parameter to set is the type and the available types are:


1. FLAT:

With **Flat type** the crossover display hides the other settings.




2. HIGH PASS

With **High Pass type** the crossover panel allows the name, slope and frequency selection.



3. LOW PASS

With **Low Pass type** the crossover panel allows the name, slope and frequency selection.



4. BAND PASS

The **Band Pass type** is the combination of the previous two (high and low pass); it is possible to select the name, slope and frequency for both filters.




■ NAME

After the type has been selected, the name filter option will display the following models:

1. Butterworth
2. LinkwitzRiley
3. Bessel
4. Chebyshev
5. QLP (quasi-linear phase)

■ SLOPE

When the name has been selected, the slope option will display the available slopes:



■ FREQUENCY

The last option to select is the cut-off frequency. It is possible to set it by using the knobs or writing the frequency directly in the text box below the knobs.




Remark: all the frequencies are in hertz (Hz).

The minimum and maximum value for frequencies is 20Hz and 20000 Hz respectively.

Remark: if QLP has been selected, the knobs are disabled because the frequency values are discretized.

■ COPY PANEL


The image below shows the copy panel for the crossover: it is possible to copy all the parameters of the current crossover to other output channels crossovers.




6.4.10 EQUALIZER

With the equalizer it is possible to emphasize or attenuate some frequencies rather than others. The equalizer setting can be performed in two ways:

■ Graphic equalizer



■ Parametric equalizer



The following functions are available for both the graphic and parametric equalizers.

- ① **Equalizer type selection:** allows you to select the equalizer type between graphic or parametric.
- ② **Bypass toggle button:** allows you to bypass or not the equalizer filters.
- ③ **Reset button:** restore to default values all sections of current equalizer.
- ④ **Copy panel:** open the equalizer copy panel.
- ⑤ **Help:** to open the user guide.

Remark: all the frequencies are in hertz (Hz) and all the gains are in decibel (dB).

Remark: the output you are acting on is indicated by the foreground color of the equalizer panel.

Remark: the equalizer of each output channel is linked to the currently selected source. For each source it is necessary to set the equalizers on the output channels.

■ GRAPHIC EQUALIZER

With the graphic equalizer it is possible to set only the gain for every band, from -12 dB to +12 dB:

The central frequency of each band is indicated above the slider and the gain can be set with the slider or using the text box below the slider.



■ PARAMETRIC EQUALIZER

With the parametric equalizer it is possible to set more parameters than graphic equalizer for every section.

WARNING: the parameters of each section of the parametric equalizer are linked to each other. When a parameter is changed, it may cause changes to other parameters. Be careful when changing the parameters.

By selecting the desired section it is possible to change the different parameters of this section. The first parameter you can set is the type of section filter.

The available types are:

- ① Flat
- ② Peaking
- ③ Low shelving
- ④ High shelving
- ⑤ Notch
- ⑥ All-pass



After selecting the filter type it is possible to set the Gain, Frequency and the Form factor (Q), except for Flat where it is not possible to set any parameters.

The minimum and maximum Gain is -12 dB and +12 dB. For Notch or All-pass the gain is set to 0 dB and cannot be changed.

For Low shelving the minimum and maximum frequency is 20 Hz and 1000 Hz respectively; for High shelving the minimum and maximum frequency is 8000 Hz and 20000 Hz respectively and for all other filter types (except for Flat) the minimum and maximum frequency is 20 Hz and 20000 Hz. The minimum and maximum value for Form factor (Q) is 0.5 and 16 for Peaking and All-pass types.

For the shelving types (low and high) the minimum and maximum value for Q is 0.5 and 1.41.


Finally, for the Notch type, the minimum and maximum value for Q is 1.44 and 16.



WARNING: when changing from the parametric type to the graphic type, some set parameters can be modified according to the constraints imposed by the graphic equalizer (filter type, frequency, form factor (Q), ...).

• COPY PANEL

The image on the side shows the copy panel for the equalizer: it is possible to copy all the sections of the current equalizer to other output channels equalizers.



6.4.11 MEMORIES

With memories it is possible to characterize the sound using a frequency filtering similar to the one of the equalizer.

Remark: you can activate only one memory at a time or deactivate it through the memory panel of the configuration software when the amplifier is connected to the PC.

When the configuration of the device is completed and it is disconnected from the PC, the memories are selected with the appropriate Memory selection switch (see sec. 5.2).

The images below describe the memories panel and the functions available when a memory is selected.

- ① **Selection toggle button:** to select and then activate the memory. It also activates the Advanced settings button.
- ② **Advanced settings panel:** to open the advanced settings panel of the selected memory. See Memory equalizer (see sec. 6.4.11.1).
- ③ **Memories settings panel:** to open the memories settings panel.
- ④ **Copy panel:** to open the memories copy panel.
- ⑤ **Help:** to open the user guide.



WARNING: each memory acts on all outputs!

WARNING: when a memory is deactivated all its customizations are deactivated!

When you hover the mouse over a memory button, the memories panel provides a preview of the filtering curve with a tooltip, like in the image below.



MEMORIES SETTINGS PANEL


The image on the side shows the settings panel for the memories.

The memories can be:

- renamed;
- disabled / enabled.


WARNING: when a memory is disabled it is definitively unusable.

It is not possible to rename or customize it.



COPY PANEL

This feature allows you to copy the advanced settings of the active memory to other memories.



6.4.11.1 Memory equalizer


Advanced memory settings include an equalizer that allows you to perform an additional equalization.

WARNING: the filters of this equalizer are applied to all the output channels when the memory is selected.



The equalizer setting can be performed in two ways:

GRAPHIC EQUALIZER



PARAMETRIC EQUALIZER




The following functions are available for both the graphic and parametric equalizers.

- ① **Equalizer panel:** allows you to select the memory equalizer filter panel.
- ② **Delta volume panel:** allows you to select the memory delta volume panel. See Memory volume ([see sec. 6.4.11.2](#)).
- ③ **Delays panel:** allows you to select the memory delays panel. See Memory delay ([see sec. 6.4.11.3](#)).
- ④ **Sound sensations band:** provides a subjective description of the sound frequencies.
- ⑤ **Equalizer type selection:** allows you to select the equalizer type between graphic or parametric.
- ⑥ **Bypass toggle button:** allows you to bypass or not the equalizer filters.
- ⑦ **Reset button:** restore to default values all sections of current equalizer.
- ⑧ **Help:** to open the user guide.

Remark: all the frequencies are in hertz (Hz) and all the gains are in decibel (dB).

GRAPHIC EQUALIZER

With the graphic equalizer it is possible to set only the gain for every band, from -12 dB to +12 dB:



The central frequency of each band is indicated above the slider and the gain can be set with the slider or using text box below the slider.

PARAMETRIC EQUALIZER

With the parametric equalizer it is possible to set more parameters for every section than the graphic equalizer.

WARNING: the parameters of each section of the parametric equalizer are linked to each other. When a parameter is changed, it may cause changes to other parameters. Be careful when changing the parameters

Remark: when the equalizer is in parametric mode, the frequency response of the single section currently selected is shown on the graph with a white dotted line.

By selecting the desired section it is possible to change the different parameters of this section. The first parameter you can set is the type of section filter.



The types available are:

- ① Flat
- ② Peaking
- ③ Low / High shelving

Remark: not all sections have all types of filters available.

After selecting the filter type it is possible to set the Gain, Frequency and the Form factor (Q), except for Flat where it is not possible to set any parameters.

The minimum and maximum Gain is -12 dB and +12 dB.

For Low shelving the minimum and maximum frequency is 20 Hz and 1000 Hz respectively; for High shelving the minimum and maximum frequency is 8000 Hz and 20000 Hz respectively; for Peaking the minimum and maximum frequency is 20 Hz and 20000 Hz.


The minimum and maximum value for the Peaking Form factor (Q) is 0.5 and 16; for shelving types (low and high) the Form factor (Q) ranges from 0.5 to 1.41.

WARNING: when changing from the parametric type to the graphic type, some set parameters can be modified according to the constraints imposed by the graphic equalizer (filter type, frequency, form factor (Q), ...).

6.4.11.2 Memory volume

The selected memory allows this further customization for the output channels volumes.

Remark: this function is applied to the output channels only when the memory is selected.



- ① **Delta volume checkbox:** allows you to enable or disable this additional feature of the selected memory.
- ② **Reset button:** restore all sliders to 0 dB.
- ③ **Help:** to open the user guide.

Remark: this function is enabled only if a check mark is placed in the related check box on the top tab!


Delta volume is an adjustment of the output channels level ranging from -12 dB to +12 dB: these corrections are added to the volumes set in the main output channels panel.

When the delta volume brings the output channel volume beyond the limits (above 0 dB or below -40 dB) the slider turns orange: in these cases, the maximum (0 dB) or minimum (-40 dB) value is assigned to the output channel.

6.4.11.3 Memory delay

The selected memory allows this further customization for the output channels delays.

Remark: this function is applied to the output channels only when the memory is selected.



- ① **Delays checkbox:** allows you to enable or disable this additional feature of the selected memory.
- ② **Reset button:** restore all the delays of the selected memory to 0 ms.
- ③ **Help:** to open the user guide.

Remark: this function is enabled only if a check mark is placed in the related check box on the top tab !


The memory delays function provides the ability to enter the delay value in milliseconds for each output channel: these delays replace those set in the delay panel or those calculated by the automatic delay calculation command (according to the speakers position).

When the memory is deselected (or the memory delay function is disabled by removing the check mark), the delays are restored to the original values set for each output channel.

6.4.12 GRAPH

1 GRAPH


The Graph displays the frequency response of the output channels. On the x-axis there is the frequency in hertz (Hz), represented with a logarithmic scale; on the y-axis the amplitude of the signal is represented in decibels (dB).



2 GRAPH SETTINGS

The image below shows the graph settings panel to select what to observe on the graph.


- ① **Expand graph:** allows you to enlarge the size of the graph, reducing the output channel settings panel. When clicked, its appearance changes.
- ② **Restore graph:** allows you to restore the original size of the graph. More details in the next paragraph.
- ③ **Help:** to open the user guide.



The frequency response of the currently selected output channel, identified by the white background around the name, is always shown on the graph.

By selecting the check boxes it is possible to simultaneously display more output channels frequency responses on the graph. Furthermore, if the sum box is checked, the sum of the frequency responses of the currently checked channels is shown on the graph.


If the parametric equalizer is used, the EQ. SECTION item appears at the bottom of the graph settings panel: putting the check mark on it, a dashed line that represents the frequency response of the equalizer selected section, is shown on the graph.



Remark: only the output channels belonging to the currently selected zone are listed on the graph settings panel.

3 GRAPH RESIZE

When the graph resize button is clicked, the graphic layout adopted by the software is shown in the image below.



As you can see, the input channels panel and the zone volume panel are hidden, while the output channels panel takes on a reduced graphic layout.

The image below shows an overview of the functions available on the output channel settings panel in this reduced mode:




- ① **Selection button:** the output channel is selected by clicking on its name. The currently selected channel has the name highlighted in white.
- ② **Channel level:** allows you to enter the channel level.
- ③ **Digital clip:** the LED lights up if the channel saturates the digital dynamic.
- ④ **Mute:** allows you to mute the channel (mute).
- ⑤ **Solo:** allows you to listen to the channel silencing all the others (solo).
- ⑥ **Bridged channels appearance:** when a channel is set to bridge mode, it is represented in this way.

6.4.13 WORK NOTES

The Work Notes panel allows you to capture a snapshot of the whole current configuration. This function makes a copy of the current configuration to the clipboard.

The images below show the Work Notes panel both when it is empty and when it contains snapshots.



- ① **Camera button:** allows you to take a snapshot of the current configuration.
- ② **Snapshot load button:** allows you to reload the configuration of that snapshot. Each button shows the snapshot capture time as identification.
- ③ **Snapshot delete button:** allows you to permanently delete a snapshot.
- ④ **Help:** to open the user guide.

Remark: there is no limit to the number of snapshots that can be captured.

WARNING: snapshots are volatile and are not saved on the computer: they are only work notes!

⚠ When the software is closed, all snapshots are lost.

Remark: if you want to save a configuration contained in a snapshot, you must first reload the configuration by clicking on the snapshot load button and then use the SAVE AS command located in the top command bar.

6.5 EXTENDED FUNCTIONALITIES

The software dynamically reshapes depending on the device to which it connects.

During synchronization, the device communicates the current configuration but also the details inherent to the functionalities it implements.

These functionalities are divided between **Wizards** (see sec. 6.5.1) and **Features** (see sec. 6.5.2).


The software provides an additional functionality which is independent of the connected device.

This is the **Real time analysis** (see sec. 6.5.3).

6.5.1 WIZARDS


Within this definition are grouped all the automatic procedures that facilitate the user during the audio setup process.

Ultimately, these are procedural abstractions whose purpose is to create a device configuration (or part of it), rationalizing the steps according to a simpler and more intuitive visual interface for the user.



6.5.1.1 Load configuration from a template

This automatic procedure simply allows you to load a configuration from one of the models that the software makes available.



WARNING: before loading the template make sure that all the connections have been performed correctly.



It is strongly advised to maintain a low volume of the system to avoid possible damage to the loudspeakers in the event of an error in the connections.

6.5.2 FEATURES

Within this group are instead all the extensions that can be activated or deactivated by the user during system operation.

Remark: HMD8 DSP does not implement any features.

6.5.3 REAL TIME ANALYSIS

WARNING: the Real time analysis functionality (RTA) is not a measuring instrument! It is an aid for setting up the audio system.



The Real time analysis allows you to observe the frequency spectrum of an audio signal on the graph. It works in real time and needs a microphone connected to the PC to detect the audio signal.

WARNING: before using the RTA function, you must select the audio input device connected to the PC.



To access the audio settings panel, there is a button on the right side toolbar:




The images below show the audio settings panel.

- 1 Input device:** allows you to select the audio input device connected to the PC.

Remark: it is highly recommended to use a good quality microphone that has a USB connector, and not the integrated microphone of the PC.

- 2 Bands:** allows you to choose the number of audio spectrum frequency bands between octave (10 frequency bands), 3rd octave (30 frequency bands), 6th octave (60 frequency bands), 12th octave (120 frequency bands).

- 3 Average:** allows you to choose the time window length in which the average is calculated (short; normal; long). This setting modifies the responsiveness of the bar graph.



Finally, to activate or deactivate the real time analysis, there is a toggle button on the top command bar:



The frequency spectrum of the detected audio signal will appear in the graph background. The decibel scale related to the amplitude of the RTA is shown on the right side of the graph.






Remark: when the RTA function is activated, the audio settings icon is disabled. To change the audio settings it is necessary to turn the RTA off.

6.5.4 STATUS BAR

The status bar is located at the bottom of the configuration software and provides some useful information for the user. In particular, some icons are shown on the right side of the status bar as in the following images:


- ① **Warning:** indicates the presence of potential configuration problems. This type of warning occurs when, in the mixer, one or more inputs of a source are not used, or an output channel does not receive any signal contribution.
- ② **Info:** provides useful information. These types of information occur when an output channel receives a total contribution greater than 100% in the mixer, or the delays of the output channels do not match the position of the speakers.
- ③ **OK:** indicates that no potential configuration problems are detected.



The number next to each symbol indicates the amount of warnings or information.

WARNING: all these messages are a reminder and can indicate a possible forgetfulness by the user. It is not necessary to fix all the warnings and infos to save the configuration on the PC or finalize the connected device, as long as the user is aware of it.

By clicking on the symbols an alert list panel opens that allows you to view the attached messages. The image below shows the alert list panel containing some sample messages.



7. TROUBLESHOOTING

7.1 SYNCHRONIZATION WITH A PC

1. HMD8 DSP operating problems

If, when calibrating the system with **HMD8 DSP** connected to a laptop there are operating problems, try disconnecting the laptop power supply cable.
With the laptop working on battery power you avoid a possible voltage difference in the USB ground between the vehicle (**HMD8 DSP**) and the ground (PC).

2. Connection lost between HMD8 DSP and the PC

If, while calibrating the system with the PC connected to **HMD8 DSP**, the amplifier is turned off and back on again, the connection is lost and the software cannot finalize the adjustments that were set. To avoid losing the settings, proceed as follows:

- Save the setup to a file on the PC using the **Save** or **Save As** function.
- Exit the software.
- Turn **HMD8 DSP** on.
- Launch the software again.
- Load the setup file again that was saved using the **Open** function.

3. HMD8 DSP does not respond

If while calibrating the system with the PC connected to **HMD8 DSP** the latter does not respond to the commands, proceed as follows:

- Turn off **HMD8 DSP** by disconnecting the Remote IN or even disconnecting the power cable for a second.
- Save the setup to a file on the PC using the **Save** or **Save As** function.
- Exit the software.
- Turn **HMD8 DSP** on.
- Launch the software again.
- Load the setup file again that was saved using the **Open** function.


4. Settings not saved

To successfully complete **HMD8 DSP** configuration and not lose the work done, remember to store the settings that were made. From the management software menu select **"Finalize"**.

7.2 FIRMWARE UPDATE


The device firmware can be updated using a specific application. Make sure the device is turned on and connected to the PC.

WARNING: if you are restoring the device from an error state and it doesn't normally turn on, move the upgrade switch to the **ON** position before supplying power. The logo will start flashing and you will be ready to start the update.



Run the application and follow the instructions.

WARNING: do not disconnect or power down the device until the procedure has been completed.



8. TECHNICAL SPECIFICATIONS

POWER SUPPLY

	HMD8 DSP 12 V	HMD8 DSP 24 V
Power supply voltage / fuse:	11 ÷ 15 VDC / 2 x 30 A	22 ÷ 34 VDC / 2 x 15 A
Operating power supply voltage:	6.5 V ÷ 17 V	14 V ÷ 36 V
Idling current:	1.6 A	0.96 A
Switched off without DRC:	1.7 mA	1.6 mA
Switched off with DRC:	5 mA	5 mA
Consumption @ 14.4 VDC, 2Ω, Max Musical Power:	55 A	27.5 A
Remote IN:	6 ÷ 15 VDC (1 mA)	6 ÷ 34 VDC (1 mA)
Remote OUT:	4 ÷ 15 VDC (150 mA)	14 ÷ 34 VDC (150 mA)
ART - Automatic Remote Turn on/off from OUTPUT BTL speakers (Selectable):	2 ÷ 7 VDC	2 ÷ 7 VDC
AST - Automatic Signal Turn on/off (Selectable):	Speaker-In	Speaker-In

AMPLIFIER STAGE

	HMD8 DSP 12 V / 24 V
Distortion - THD @ 1 kHz, 4Ω, 70% Rated Power:	0.06 %
Damping factor @ 1 kHz, 4Ω, 2 VRMS:	> 110
Bandwidth @ -1.5 dB:	10Hz ÷ 22 kHz
S/N ratio (A weighted @ 1 V Input) Master Input:	100 dBA
S/N ratio (A weighted @ 1 V Input) Optical Input:	105 dBA
Input sensitivity Pre-In:	0.6 ÷ 6 VRMS
Input sensitivity Speaker-In:	2.2 ÷ 22 VRMS
Minimum load impedance:	8Ch: 2Ω 4Ch - (Bridge 1/2; 3/4; 5/6; 7/8): 4Ω
Output power (RMS) @14.4 VDC, 1% THD (HMD8 DSP); @28.8 VDC, 1% THD (HMD8 DSP 24V):	
• 8 Ch @ 4Ω:	85 W x 8
• 8 Ch @ 2Ω:	130 W x 8
• 4Ch (Bridge 1/2; 3/4; 5/6; 7/8) @ 4Ω:	260 W x 4

INPUTS / OUTPUTS

	HMD8 DSP 12 V / 24 V
Pre-In Inputs:	Ch1 ÷ Ch6 customizzabile
Speaker-In Inputs:	Ch1 ÷ Ch6 customizzabile
Digital IN:	1 x Optical S/PDIF; Max 192 kHz / 24 bit
Sub Out (RCA Pre Out):	4 VRMS Max

DIGITAL SIGNAL PROCESSOR

	HMD8 DSP 12 V / 24 V
Filter type:	Full / Hi pass / Low Pass / Band Pass
Filter mode and slope:	Butterworth (6, 12, 18, 24, 30, 36, 42, 48, 54, 60 dB/oct) Linkwitz-Riley (12, 24, 36, 48, 60 dB/oct) Bessel (6, 12, 18, 24, 30, 36, 42, 48, 54, 60 dB/oct) Chebyshev (6, 12, 18, 24, 30, 36, 42, 48, 54, 60 dB/oct) QLP quasi-linear phase (6, 12 dB/oct)
Crossover frequency:	20 ÷ 20k Hz
Phase control:	0° / 180°
Output Equalizer:	Graphic and Parametric modes n. 10 parametric poles (Peaking, High Shelf, Low Shelf, Notch, All pass) ±12 dB gain, variable Q (0.5 - 16.0) n. 10 graphic poles
Time Alignment Distance:	0 ÷ 510 cm / 0 ÷ 200.8 inches
Time Alignment Delay:	0 ÷ 15 ms
Time Alignment Step:	1 cm
Time Alignment Fine SET:	1 sample
Memories:	n. 3 memories n. 3 parametric poles for each memory (Peaking, High Shelf, Low Shelf) ±12 dB gain, variable Q (0.5 - 16.0)
Preset (Drive Preset):	Rotary switch for 7 installation Presets

CONTROL CONNECTIONS

	HMD8 DSP 12 V / 24 V
From / to personal computer:	1 x micro USB-B
Memory selection:	CTRL 1 / CTRL 2

GENERAL REQUIREMENTS

	HMD8 DSP 12 V / 24 V
PC connections:	Micro USB 1.1 / 2.0 / 3.0 Compatible
Software/ PC requirements:	Microsoft Windows (32/64 bit): Win 7, Win 8, Win 10
Video resolution with screen resize:	min. 1024 x 600
Ambient operating temperature range:	0 °C to 55 °C (32 °F to 131 °F)

SIZE / WEIGHT

	HMD8 DSP 12 V / 24 V
Max size W x H x D (mm/inch):	243 x 48 x 159 / 9.56 x 1.89 x 6.2
Weight (kg/lb):	2 / 4.4

