

EPSON

EPSON RC+ 7.0

Ver.7.5

User's Guide

Project Management and Development

Rev.1

EM208S4439F

EPSON RC+ 7.0 (Ver.7.5)

User's Guide

Rev.1

Copyright © 2012-2020 SEIKO EPSON CORPORATION. All rights reserved.

FOREWORD

Thank you for purchasing our robot products.

This manual contains the information necessary for the correct use of the Manipulator.

Please carefully read this manual and other related manuals before installing the robot system.

Keep this manual handy for easy access at all times.

WARRANTY

The robot and its optional parts are shipped to our customers only after being subjected to the strictest quality controls, tests, and inspections to certify its compliance with our high performance standards.

Product malfunctions resulting from normal handling or operation will be repaired free of charge during the normal warranty period. (Please contact the supplier of your region for warranty period information.)

However, customers will be charged for repairs in the following cases (even if they occur during the warranty period):

1. Damage or malfunction caused by improper use which is not described in the manual, or careless use.
2. Malfunctions caused by customers' unauthorized disassembly.
3. Damage due to improper adjustments or unauthorized repair attempts.
4. Damage caused by natural disasters such as earthquake, flood, etc.

Warnings, Cautions, Usage:

1. If the robot or associated equipment is used outside of the usage conditions and product specifications described in the manuals, this warranty is void.
2. If you do not follow the WARNINGS and CAUTIONS in this manual, we cannot be responsible for any malfunction or accident, even if the result is injury or death.
3. We cannot foresee all possible dangers and consequences. Therefore, this manual cannot warn the user of all possible hazards.

TRADEMARKS

Microsoft, Windows, Windows logo, Visual Basic, and Visual C++ are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Pentium is a trademark of Intel Corporation.

XVL is a registered trademark of Lattice Technology, Co., Ltd.

Other brand and product names are trademarks or registered trademarks of the respective holders.

TRADEMARK NOTATION IN THIS MANUAL

Microsoft® Windows® 8 Operating system

Microsoft® Windows® 10 Operating system

Throughout this manual, Windows 8 and Windows 10 refer to above respective operating systems. In some cases, Windows refers generically to Windows 8 and Windows 10.

NOTICE

No part of this manual may be copied or reproduced without authorization.

The contents of this manual are subject to change without notice.

Please notify us if you should find any errors in this manual or if you have any comments regarding its contents.

MANUFACTURER

SEIKO EPSON CORPORATION

CONTACT INFORMATION

Contact information is described in “SUPPLIERS” in the first pages of the following manual:

Robot System Safety and Installation Read this manual first

1. Introduction	1
1.1 Welcome to EPSON RC+ 7.0	1
1.2 System Overview	2
1.2.1 Controller	2
1.2.2 Software	4
1.2.3 Simulator	5
1.2.4 System Block Diagram	5
1.3 Options	6
1.4 Precautions When Using Windows 8	6
1.5 EPSON RC+ 5.x and 6.x Users	6
1.6 EPSON RC+ 3.x and 4.x Users	6
1.7 SPEL for Windows Users	6
1.8 Manuals	7
1.9 Security for Controller Ethernet Connection	8
1.9.1 Setting Password for PC Ethernet Controller Connection	8
1.9.2 PC Ethernet Connection to Controller	10
1.9.3 Remote Ethernet	10
1.9.4 Disable the PC Ethernet Controller Connection Authentication	10
1.10 Security for Compact Vision CV2-A Ethernet Connection	11
2. Safety	12
2.1 Overview	12
2.2 Definitions	12
2.2.1 Robot Power	12
2.2.2 Safeguard	13
2.2.3 Operation Modes	13
2.2.4 Start Mode	13
2.2.5 Changing Operation Mode	14
2.2.6 Emergency Stop	14
2.2.7 Teach Pendant	14
2.3 Safety-related Requirements	15
2.4 Installation and Design Precautions	16
2.4.1 Designing a Safe Robot System	16
2.4.2 Robot System Installation, Start-up, and Testing	20
2.5 Precautions regarding Robot Operation	21
2.5.1 General Precautions	21
2.5.2 Automatic Operation	21
2.5.3 Teaching Robot Points	21
2.5.4 Return to Automatic Operation	22
2.5.5 Program Verification	22
2.5.6 Troubleshooting	22
2.5.7 Maintenance	23

2.5.8 Backup of Projects and Controller	23
2.6 End User Instruction Manual	24
2.7 End User Training	24
3. Getting Started	25
3.1 Hardware Installation	25
3.2 Software Installation	25
3.3 Windows Security Administration	25
4. Operation	26
4.1 System Power Up Procedure	26
4.2 Starting EPSON RC+ 7.0	26
4.2.1 Startup Sequence	26
4.2.2 Startup Configuration	29
4.2.3 Start Mode	29
4.2.4 Start Mode Dialog	30
4.2.5 Start Mode: Program	30
4.2.6 Start Mode: Auto	31
4.2.7 Auto Start	31
4.2.8 Using Monitor Mode	32
4.2.9 Windows Login	32
4.2.10 Command Line Options	33
4.2.11 Using Command Line Options	34
4.3 Communications with Controller	35
4.3.1 Configuring Communications with the Controller	35
4.3.2 USB Communications	35
4.3.3 Ethernet Communications	36
4.3.4 Connecting When Control Device is not PC	37
4.4 Writing your first Program	38
5. The EPSON RC+ 7.0 GUI	43
5.1 GUI Overview	43
5.2 Project Explorer Pane	44
5.3 Status Window Pane	44
5.4 Status Bar	45
5.5 Online Help	46
5.6 [File] Menu	47
5.6.1 New Command (File Menu)	47
5.6.2 Open Command (File Menu)	48
5.6.3 Close Command (File Menu)	48
5.6.4 Save Command (File Menu)	49
5.6.5 Save As Command (File Menu)	49

5.6.6 Restore Command (File Menu).....	49
5.6.7 Rename Command (File Menu)	49
5.6.8 Delete Command (File Menu).....	50
5.6.9 Import Command (File Menu).....	51
5.6.10 Print Command (File Menu).....	52
5.6.11 Exit Command (File Menu)	53
5.7 [Edit] Menu	54
5.7.1 [Undo] Command (Edit Menu)	54
5.7.2 [Redo] Command (Edit Menu)	54
5.7.3 [Cut] Command (Edit Menu)	54
5.7.4 [Copy] Command (Edit Menu)	54
5.7.5 [Paste] Command (Edit Menu).....	54
5.7.6 [Find] Command (Edit Menu).....	55
5.7.7 [Find Next] Command (Edit Menu)	55
5.7.8 [Replace] Command (Edit Menu)	56
5.7.9 [Select All] Command (Edit Menu).....	56
5.7.10 [Indent] Command (Edit Menu).....	56
5.7.11 [Outdent] Command (Edit Menu)	57
5.7.12 [Comment Block] Command (Edit Menu)	57
5.7.13 [Uncomment Block] Command (Edit Menu)	57
5.7.14 [Go To Definition] Command (Edit Menu).....	57
5.8 [View] Menu	58
5.8.1 [Project Explorer] Command (View Menu)	58
5.8.2 Status Window Command (View Menu).....	58
5.8.3 System History Command (View Menu).....	59
5.9 [Project] Menu	60
5.9.1 [New] Command (Project Menu)	60
5.9.2 [Open] Command (Project Menu).....	61
5.9.3 Recent Projects Submenu (Project Menu)	62
5.9.4 [Close] Command (Project Menu)	62
5.9.5 [Edit] Command (Project Menu)	62
5.9.6 [Save] Command (Project Menu)	64
5.9.7 [Save As] Command (Project Menu)	64
5.9.8 [Rename] Command (Project Menu).....	65
5.9.9 [Import] Command (Project Menu)	66
5.9.10 [Export] Command (Project Menu)	70
5.9.11 [Copy] Command (Project Menu)	72
5.9.12 [Delete] Command (Project Menu)	73
5.9.13 [Build] Command (Project Menu).....	73
5.9.14 [Rebuild] Command (Project Menu)	73
5.9.15 [Properties] Command (Project Menu)	74
5.10 [Run] Menu.....	88
5.10.1 [Run Window] Command (Run Menu).....	88
5.10.2 [Operator Window] Command (Run Menu)	88
5.10.3 [Step Into] Command (Run Menu).....	88

5.10.4	[Step Over] Command (Run Menu).....	88
5.10.5	[Walk] Command (Run Menu)	89
5.10.6	[Resume] Command (Run Menu).....	89
5.10.7	[Stop] Command (Run Menu).....	89
5.10.8	[Toggle Breakpoint] Command (Run Menu).....	89
5.10.9	[Clear All Breakpoints] Command (Run Menu)	90
5.10.10	[Display Variables] Command (Run Menu)	90
5.10.11	[Call Stack] Command (Run Menu).....	91
5.11	[Tools] Menu.....	92
5.11.1	[Robot Manager] Command (Tools Menu)	92
5.11.2	[Command Window] Command (Tools Menu).....	136
5.11.3	[I/O Monitor] Command (Tools Menu).....	138
5.11.4	Task Manager Command (Tools Menu).....	140
5.11.5	Macros Command (Tools Menu).....	143
5.11.6	[I/O Label Editor] Command (Tools Menu)	144
5.11.7	User Error Editor Command (Tools Menu)	146
5.11.8	[Controller] Command (Tools Menu).....	147
5.11.9	[Vision] Command (Tools Menu).....	150
5.12	[Setup] Menu	151
5.12.1	[PC to Controller Communications] Command (Setup Menu).....	151
5.12.2	[System Configuration] Command (Setup Menu)	152
5.12.3	[Preferences] Command (Setup Menu).....	169
5.12.4	[Options] Command (Setup Menu).....	176
5.13	[Window] Menu	177
5.13.1	[Cascade] Command (Window Menu)	177
5.13.2	[Tile Vertical] Command (Window Menu)	177
5.13.3	[Tile Horizontal] Command (Window Menu).....	178
5.13.4	[Arrange Icons] Command (Window Menu)	178
5.13.5	[Close All] Command (Window Menu).....	179
5.13.6	1, 2, 3 Command (Window Menu).....	179
5.13.7	[Windows] Command (Window Menu)	179
5.14	[Help] Menu	180
5.14.1	[How Do I] Command (Help Menu)	180
5.14.2	[Contents] Command (Help Menu).....	180
5.14.3	[Index] Command (Help Menu)	181
5.14.4	[Search] Command (Help Menu).....	181
5.14.5	[Manuals] Submenu (Help Menu).....	182
5.14.6	[About EPSON RC+ 7.0] Command (Help Menu).....	182

6. The SPEL+ Language	183
6.1 Overview	184
6.2 Program Structure.....	184
6.2.1 What is a SPEL+ program?	184
6.2.2 Calling functions.....	184
6.3 Commands and Statements	185
6.4 Function and Variable Names (Naming restriction).....	185
6.5 Data Types	186
6.6 Operators	186
6.7 Working with Variables.....	187
6.7.1 Variable scopes	187
6.7.2 Local variables	187
6.7.3 Module variables	187
6.7.4 Global variables	188
6.7.5 Global Preserve variables.....	188
6.7.6 Arrays	189
6.7.7 Initial values	189
6.7.8 Clearing arrays.....	189
6.8 Working with Strings	190
6.9 Working with Files	191
6.10 Multi-statements.....	193
6.11 Labels.....	193
6.12 Comments.....	193
6.13 Error Handling	194
6.14 Multi-tasking.....	196
6.15 Using Multiple Robots.....	197
6.16 Coordinate Systems.....	198
6.16.1 Overview	198
6.16.2 Robot Coordinate Systems.....	199
6.16.3 Local Coordinate Systems	202
6.16.4 Tool Coordinate Systems	203
6.16.5 ECP Coordinate Systems (Option).....	206
6.17 Robot Arm Orientations.....	209
6.17.1 SCARA robot arm orientations.....	209
6.17.2 6-axis robot arm orientations	210
6.17.3 RS series arm orientations.....	214
6.17.4 N series arm orientations	217
6.18 Robot Motion Commands	223
6.18.1 Homing the robot.....	223
6.18.2 Point to point motion	223
6.18.3 Linear motion	223
6.18.4 Curves	224
6.18.5 Joint motion	224

6.18.6	Controlling position accuracy.....	224
6.18.7	CP Motion Speed / Acceleration and Tool Orientation	225
6.18.8	PTP Speed / Acceleration for Small Distances	225
6.18.9	Pressing Motion	225
6.18.10	Collision Detection Function (Detection Function of Robot Motion Error)	226
6.18.11	Torque Restriction Function	229
6.19	Working with Robot Points	231
6.19.1	Defining points	231
6.19.2	Referencing points by point label	231
6.19.3	Referencing points with variables.....	232
6.19.4	Using points in a program.....	232
6.19.5	Importing points into program.....	232
6.19.6	Saving and loading points.....	233
6.19.7	Point attributes	233
6.19.8	Extracting and setting point coordinates	234
6.19.9	Alteration of points	235
6.20	Input and output control.....	236
6.20.1	Hardware I/O.....	236
6.20.2	Memory I/O	236
6.20.3	I/O Commands.....	236
6.21	Using Traps.....	237
6.21.1	Cautions of Trap when it triggers the system condition.....	238
6.22	Special Tasks	239
6.22.1	Precautions to Use the Special Tasks	239
6.22.2	NoPause/NoEmgAbort task specification.....	241
6.22.3	NoPause/NoEmgAbort task example	242
6.23	Background Task	243
6.23.1	Primary features of background task.....	243
6.23.2	Setup and start the background task.....	244
6.23.3	Holding background task (from being activated).....	245
6.23.4	Commands that will cause error in background task	247
6.23.5	Background task and Remote control	247
6.24	Predefined Constants	248
6.25	Calling Native Functions in Dynamic Link Libraries	253

7. Building SPEL+ Applications 259

7.1	Designing Applications	259
7.1.1	Creating the simplest application.....	259
7.1.2	Application layout.....	259
7.1.3	Auto start at power up.....	261
7.2	Managing Projects	262
7.2.1	Overview	262

7.2.2 Creating a new project	263
7.2.3 Configuring a project	263
7.2.4 Building a project	264
7.2.5 Backing up a project	264
7.3 Editing Programs	265
To open a program for editing	265
7.3.1 Program rules	265
7.3.2 Typing in program code	265
7.3.3 Syntax Help	266
7.3.4 Syntax Errors	267
7.4 Editing Points	268
7.5 Running and Debugging Programs	270
To run a program	270
7.5.1 The Run window	270
7.5.2 Debugging	272
7.6 The Operator Window	276
7.6.1 Operator window configuration	277
7.6.2 Auto start configuration	277
7.7 Using Remote Control	278
7.8 Using Encrypt Files	278
8. Simulator	280
8.1 Simulator Functions	280
8.1.1 Overview	280
8.1.2 System Requirements	281
8.2 Using the Simulator	282
8.2.1 Working with the samples	282
8.2.2 Working with the user created system	284
8.3 Description of Functions	292
8.3.1 [Robot Simulator] window layout	292
8.3.2 Simulator Settings	321
8.3.3 Part/Mounted Device Settings	329
8.3.4 Collision detection	330
8.3.5 CAD To Point	332
8.3.6 CAD to Point for ECP	340
8.3.7 Virtual controller	346
8.3.8 Connection with controller	347
8.3.9 Virtual Camera Settings and Camera View Display	349
8.3.10 Motion restriction by BOX	351
8.4 Simulator Specifications and Restrictions	352
8.4.1 EPSON RC+ 7.0 package	352
8.4.2 Specifications and precautions for the 3D display	352

8.4.3 Specifications and precautions for Simulation (program execution on PC)	354
8.4.4 Specifications and precautions of EPSON RC+.....	356
8.4.5 Restriction on SPEL+ command execution.....	356
8.4.6 Specifications and precautions of EPSON RC+ 7.0 Trial.....	359
9. Motion System	360
9.1 Standard Motion System	360
9.2 Drive Module Software Configuration.....	360
9.3 PG Motion System.....	360
10. Robot Configuration	361
10.1 Setting the Robot Model	361
10.1.1 Adding a standard robot.....	361
10.1.2 Calibrating a standard robot	362
10.1.3 Changing robot system parameters	362
10.1.4 Deleting a standard robot	363
10.1.5 Changing the Robot.....	364
10.2 Configuration of Additional Axes.....	365
10.2.1 Adding the additional S axis	365
10.2.2 Adding the additional T axis.....	365
10.2.3 Changing the parameters of robot with additional axes installed	365
10.2.4 Differences of the standard robot and robot with additional axes	366
10.2.5 Deleting the additional axes	368
11. Inputs and Outputs	369
11.1 Overview	369
11.2 I/O Commands.....	370
11.3 I/O Configuration.....	371
11.4 Monitoring I/O.....	371
11.5 Virtual I/O	371
11.6 Fieldbus Master I/O.....	371
11.7 Fieldbus Slave I/O.....	372
11.7.1 Modbus Slave	372
11.7.2 Supported Functions.....	372
11.7.3 Address map	373
11.7.4 Modbus RTU	374
11.7.5 Modbus TCP	374
11.7.6 How to Configure Modbus	374

12. Remote Control	377
12.1 Remote I/O.....	377
12.1.1 Remote Control Input Output Configuration	378
12.1.2 Control Device Configuration	378
12.1.3 Auto Mode with Remote Control	379
12.1.4 Teach Mode with Remote Control.....	379
12.1.5 Debugging Remote Control	379
12.1.6 Remote Inputs.....	380
12.1.7 Remote Outputs.....	384
12.1.8 Remote Input Handshake Timing	387
12.2 Remote Ethernet.....	390
12.2.1 Remote Ethernet Configuration	390
12.2.2 Control Device Configuration	391
12.2.3 Remote Ethernet Control Execution	391
12.2.4 Debugging Remote Ethernet Control.....	391
12.2.5 Remote Ethernet Command	392
12.2.6 Monitoring command	396
12.2.7 Response	397
12.2.8 Response timing of Remote Ethernet control.....	399
12.3 Remote RS232	399
12.3.1 Remote RS232 setting.....	399
12.3.2 Control device setting	400
12.3.3 Execution of remote RS232 control	400
12.3.4 Debugging remote RS232 control	401
12.3.5 Remote RS232 Command.....	401
12.3.6 Monitoring command	407
12.3.7 Response	407
12.3.8 Response timing of Remote Ethernet control.....	410
12.4 User-defined Remote Output I/O	410
12.4.1 What is user-defined remote output I/O?.....	410
12.4.2 Output conditions	410
12.4.3 Output.....	411
12.4.4 Restrictions	413
12.4.5 How to set the user-defined output remote I/O.....	415
12.4.6 Usage example	417
13. RS-232C Communications	419
13.1 RS-232C Software Configuration	419
13.2 RS-232C Commands.....	421
14. TCP/IP Communications	422
14.1 TCP/IP Setup	422
14.1.1 Ethernet Hardware	422

14.1.2 IP Addresses	422
14.1.3 IP Gateway	423
14.1.4 Testing Windows TCP/IP setup	423
14.2 TCP/IP Software Configuration	424
14.3 TCP/IP Commands	424

15. Security	425
---------------------	------------

15.1 Overview	425
15.2 Security Configuration	425
15.3 Security Audit Viewer	430
15.4 SPEL+ Security Command	430

16. Conveyor Tracking	431
------------------------------	------------

16.1 Overview	431
16.2 Conveyor Tracking Processes	433
16.3 System Structure	434
16.4 Hardware Installation	436
16.5 Wiring example of Vision Conveyor Tracking System	443
16.6 Conveyor Encoder Configuration	444
16.7 Verifying Encoder Operation	445
16.8 Verifying Hardware Conveyor Trigger / Vision Trigger	446
16.9 Key Terms	447
16.10 Conveyor Tracking Commands	448
16.11 Creating Conveyors in a Project	450
16.12 Configuring Conveyors	451
16.13 Vision Conveyors	453
16.14 Sensor Conveyors	474
16.15 Pickup Area	490
16.16 Adjusting the Z value	498
16.17 Queue Sorting	500
16.18 Cnv_QueReject	501
16.19 Sample Program	502
16.20 Multiple Conveyors	508
16.21 Multi-robot Conveyor	513
16.22 Abort Tracking	518
16.23 Conveyor Tracking with 6-Axis Robot	518
16.24 Tracking Mode	519
16.25 How to shorten the picking cycle time	519
16.26 Manipulator Posture	520
16.27 Tracking Abort Line	520

16.28 Tips for Accuracy Improvement of Conveyor Tracking	526
16.28.1 Overview	526
16.28.2 Tips for System Construction	526
16.28.3 Tips for Vision Calibration	528
16.28.4 Tips for Conveyor Calibration	529
16.28.5 Troubleshooting for Work Piece Detection	530
16.28.6 Offset.....	533
17. ECP Motion	534
17.1 Overview	534
18. Force Sensing	536
18.1 Overview	536
18.2 Specifications	537
18.3 Installation	537
18.4 Force Sensing Commands	542
18.5 Using the Force Sensing Trigger	543
19. Distance Tracking Function	544
19.1 Overview	544
19.1.1 Distance Tracking Accuracy.....	544
19.2 Connection Example.....	546
19.2.1 Basic Connection Example	546
19.2.2 Connection Example for Dispense Application.....	546
19.3 Commands.....	547
19.4 Steps to adjust parameters.....	547
19.4.1 Check Motions of Analog I/O Board.....	549
19.4.2 Teaching a Robot	549
19.4.3 Create a Motion Program.....	550
19.4.4 Add a Program for Distance Sensor Logging	551
19.4.5 ProportionalGain Setting	553
19.4.6 IntegralGain Setting	555
19.4.7 DifferentialGain Setting	556
19.5 Example of Dispense Application	557
19.5.1 Basic Example	557
19.5.2 Example with Application Amount Control	558
20. Real-Time I/O	559
20.1 Overview	559
20.2 Specifications	559
20.3 Usage.....	561

21. Additional Axis	564
21.1 Overview	564
21.2 Specifications.....	564
21.3 Usage.....	566
22. Calibration of Commercial Vision Sensor and Robot	568
22.1 Overview	568
22.2 Specifications.....	569
22.3 Camera Installation.....	570
22.4 Reference Points	571
22.5 Reference Points for Mobile Camera	571
22.6 Reference Points for Fixed Camera	571
22.7 Command List.....	572
23. Installing Controller Options	573
24. Software License Agreement	574
Appendix A: Automatic Processing of Project Import	A-1
Project Import for EPSON RC+ 6.*	A-1
Project Import for EPSON RC+ 5.*	A-1
Project Import for EPSON RC+ 3.* / 4.*	A-1
Project Import for SPEL for Windows 2.*	A-3
Appendix B: EPSON RC+ 7.0 Software	B-1
EPSON RC+ 7.0 Software Installation	B-1
To install the service pack	B-3
After Installing EPSON RC+ 7.0 Software.....	B-4
EPSON RC+ 7.0 Software Update	B-4
Appendix C: Simulator Functions List of Unsupported Manipulator Models	C-1
X5 series Manipulators	C-1
G6 series Manipulators	C-1
G10 series Manipulators	C-2
G20 series Manipulators	C-2

1. Introduction

1.1 Welcome to EPSON RC+ 7.0

Welcome to the EPSON RC+ 7.0 Project Management and Development Environment. EPSON RC+ 7.0 is used to develop application software for the Robot Controller.

EPSON RC+ 7.0 features

- Operable on Windows
- Integrated application development environment
- Communicates with the Controller by USB or Ethernet
- Allows you to connect one computer with multiple Controllers
- Multi simultaneous session
- SPEL+ programming language
A powerful, easy to use BASIC-like programming language that supports multi-tasking, robot motion control, I/O control, and networking.
- I/O systems including Digital I/O boards and Fieldbus I/O
- TCP/IP and RS-232 communications
- Background task
Controls entire system
- Database access
- Vision Guide option
Integrated vision robot guidance
- RC+ API option
Enables you to control the system using standard Microsoft .NET programming environments including Microsoft Visual Basic and Microsoft Visual C++.
- Security option
Allows you to administrate all EPSON RC+ users on your system. It also includes usage auditing, so you can track how many hours are spent using the system, and if changes were made.
- Conveyor Tracking option
Enables one or more robots to pick parts from moving conveyors using vision or sensors.
- PG Motion System option
Allows you to use third party motors and drivers to control auxiliary equipment such as XY tables, slides, etc.
- ECP option
Supports CP motion relative to a fixed point.
- GUI Builder option
Integrated GUI development tool
- Force Guide option
Allows a robot to use torque/force sensing and measurement
- Force Control
Force is controlled or measured by force sensor.

1.2 System Overview

EPSON RC+ 7.0 software, which is installed to the computer connected to the robot controller, contains several components that enable you to control an entire robotic work cell. EPSON RC+ 7.0 communicates with the controller using USB or Ethernet.

EPSON RC+ 7.0 and the Controller can be used in following environments:

Slave system	<p>The Controller is PLC or PC cell slave. Application is developed with EPSON RC+ 7.0.</p> <p>After saving the object code to the Controller, it does not need to be connected to the computer. The Controller is controlled by I/O or fieldbus.</p>
Standalone system	<p>Controls the robot and peripheral equipment as the robot controller. EPSON RC+ 7.0 displays the simple operator window in AUTO mode.</p> <p>By using RC+ API option, .NET application can be controlled.</p>
Offline development system	<p>Program edition and project build can be checked on the offline PC.</p>
Simulation system	<p>EPSON RC+ 7.0 on the PC which is connected to the Controller can execute the program without the actual I/O or robot by using the virtual I/O and dry run.</p>

1.2.1 Controller

RC700

The RC700 Controller is a powerful robotic work cell controller that controls our SCARA robots and 6-axis robots.

Controller features

- Sophisticated yet achieving reliability and stability
- Built in Motion System
The motion drive system can control up to 6 axes simultaneously and 1 robot, and can add up to three drive units
- Includes standard I/O
- Wide variety of options

For detailed information on the Controller, refer to the controller manual.

RC90

The RC90 Controller with the following label attached can be used in combination with EPSON RC+ 7.0.



EPSON RC+ 7.0	RC90 Controller firmware
	Ver.7.0.2.0
Before Ver.7.0.1	!!!
Ver.7.0.2 or later	OK

OK : Compatible

All functions of the EPSON RC+ 7.0 and the Controller are available.

!!! : Compatible

Connection is OK. We recommend using EPSON RC+7.0 Ver. 7.0.2 or later.

NOTE



Manual PDF for this robot system is available from EPSON RC+ 7.0 Ver. 7.0.2

NOTE



This option is available for Robot Controller RC90 (EPSON RC+ 5.0) without the label.

The RC90 Controller is a robot controller that can drive LS series manipulators.

Features:

- Built in motion drive system. The motion drive system can control one robot.
- Standard I/O
- Optional digital I/O expansion boards
- Optional Fieldbus slave support for DeviceNet, PROFIBUS-DP, CC-Link Ethernet/IP, PROFINET, and EtherCAT.
- RS-232 ports (standard + optional)

For details on the Controller, refer to the RC90 Controller manual.

RC90-B

EPSON RC+ 7.0	RC90-B controller firmware
	Ver.7.4.2.0 or later
Before Ver.7.4.1	!!!
Ver.7.4.2 or later	OK

OK : Compatible

All functions of the EPSON RC+ 7.0 and the Controller are available.

!!! : Compatible

Connection is OK. We recommend using EPSON RC+7.0 Ver. 7.4.2 or later.

NOTE



There is no label on RC90-B

The RC90-B Controller is a robot controller that can drive LS-B series manipulators.

Features:

- Built in motion drive system. The motion drive system can control one robot.
- Standard I/O
- Optional digital I/O expansion boards
- Optional Fieldbus slave support for DeviceNet, PROFIBUS-DP, CC-Link Ethernet/IP, PROFINET, and EtherCAT.
- RS-232 ports (standard + optional)

For details on the Controller, refer to the RC90 controller manual.

T series Manipulator

The T series Manipulators are Controller integrated SCARA robot.

For more details on Controller part, refer to T series Manipulator manual.

VT series Manipulator

The VT series Manipulators are Controller integrated 6-axis robot.

For more details on Controller part, refer to VT series Manipulator manual.

1.2.2 Software

EPSON RC+ 7.0 needs to be installed to your development PC. To communicate with the Controller, the computer should support USB 1.1 / 2.0 or Ethernet communication.

You can purchase options with the product or add them later.

Using EPSON RC+ 7.0, you can develop application software for the SPEL+ language that runs in the RC700 controller.

1.2.3 Simulator

Simulator functions enable easy robot motion check on your PC, which gives you flexibility to consider the system layout, measure the operation time, and create the robot programs.


They are useful in all the way from introduction stage of robot automation to launch of robot system.

Simulator is supported by EPSON RC+ 7.0 Ver.7.0.0 or later as standard.

For details, refer to 8. *Simulator*.

1.2.4 System Block Diagram

The following system block diagram shows methods for connecting a PC running EPSON RC+ 7.0 to one or more controllers.



1.3 Options

EPSON RC+ 7.0 enables the purchased Controller options.

Refer to 23. *Installing Controller Options* for details.

1.4 Precautions When Using Windows 8

Connecting development PC to Robot Controller using Ethernet

The robot controller does not support internet protocol version 6 (TCP/IPv6). When connecting the development PC to the robot controller using the Ethernet, be sure to use the internet protocol version 4 (TCP/IPv4).

1.5 EPSON RC+ 5.x and 6.x Users

EPSON RC+ 7.0 is compatible with EPSON RC+ 5.x and 6.x for the operation and language.

For EPSON RC+ 7.0, you can use all commands of EPSON RC+ 5.x and 6.x.

You can use the current numbers for the I/O and communication port.

To enable the EPSON RC+ 5.x and 6.x project in EPSON RC+ 7.0 environment, convert the project using [Project] menu-[Import].

With above conversion, the entire project will be copied by EPSON RC+ 7.0.

\EPSONRC50\Project directory → \EpsonRC70\Project directory

\EPSONRC60\Project directory → \EpsonRC70\Project directory

1.6 EPSON RC+ 3.x and 4.x Users

EPSON RC+ 7.0 is compatible with EPSON RC+ 3.x and 4.x for the operation.

For EPSON RC+ 7.0, there are new commands added to SPEL⁺ language. Though there are also some commands deleted or amended, most commands are available.

To enable the project of EPSON RC+ 3.x or 4.x in EPSON RC+ 7.0 environment, convert the project using [Project] menu-[Import].

With above conversion, the entire project will be copied by EPSON RC+ 7.0.

\EPSONRC\Project directory → \EpsonRC70\Project directory

Refer to *Appendix A: Automatic Processing of Project Import* for the details.

1.7 SPEL for Windows Users

EPSON RC+ 7.0 is compatible with SPEL for Windows 1.x and 2.x for the operation.

For EPSON RC+ 7.0, there are many new commands added to SPEL⁺ language, which replaces SPEL. Also there are some commands deleted or amended.

To enable the project of SPEL for Windows 2.x in EPSON RC+ 7.0 environment, convert the project using [Project] menu-[Import].

With above conversion, the file will be copied to a new directory or the program will optionally be converted by EPSON RC+ 7.0.

Refer to *Appendix A: Automatic Processing of Project Import* for the details.

1.8 Manuals



All documentation is installed on the PC in PDF format.

To view manuals on the PC:

- Select [Manuals] from the [Help] menu in EPSON RC+ 7.0
- From Windows desktop, click <Start>-[Programs]-[EPSON RC+ 7.0]

Available manuals are shown in the table below.

Manual	Contents
EPSON RC+ 7.0 Users Guide	Information for the entire system
SPEL ⁺ Language Reference	Information for the SPEL+ Language
Vision Guide	Hardware, software, and reference for Vision Guide
Force Guide	Hardware, software, and reference for force sensor
Part Feeding	Integration guideline, introduction, hardware, software for part feeding
Teach Pendant	TP
RC+ API 7.0	Information for options
GUI Builder 7.0	
Fieldbus IO	
PG Motion System	
AOI	
Remote Control Reference	Information for Remote I/O control extended function
Manipulator manual	Information for the purchased robot Each series has its own manual
Controller manual	Information for the purchased robot
Safety & Installation	Information for installing the robot system safely Paper manual will come with the product

NOTE 	The “NOTE” sections describe important information to be followed for operating the Robot system.
TIP 	The “TIP” sections describe hints for easier or alternative operations.

1.9 Security for Controller Ethernet Connection

From the following firmware version password authentication is required when connecting Controllers and PCs to a public (global) accessible network.

F/W : Ver.7.4.8.x (except T series Manipulator / VT series Manipulator)
Ver.7.4.58.x (T series Manipulator / VT series Manipulator)

Our robot system is provided on the assumption that customers use it in a closed local area network. We considered the use of a public IP address for the Controller that can be accessed via the Internet (directly or through a router) and changed the specification to support password authentication in order to secure the connection.

Password authentication is not performed in case of USB connections.

Be sure to use an IP address in the following private IP address ranges unless a public (global) IP address is required.

Private IP Address Ranges

10.0.0.1	to	10.255.255.254
172.16.0.1	to	172.31.255.254
192.168.0.1	to	192.168.255.254

1.9.1 Setting Password for PC Ethernet Controller Connection

It is necessary to set the authentication password in the Controller and the PC connection client for Ethernet connection when a public (global) IP address is used in the Controller.

To use a public IP address in the Controller, the authentication password must be set in advance. If there is no authentication password configured, you cannot use a public IP address for the controller.




Important

- Set a private IP address for the Controller before use.


When setting a global IP address for the Controller, be sure to understand risks such as unauthorized access before use.

Setting a password for Controller

- (1) Select EPSON RC+ 7.0 menu-[Setup]-[System Configuration]-[Controller]-[Configuration].
- (2) Click [Connection Password]-<Change> button.




- (3) Set the password. (The password must contain at least 8 characters.)




Setting a password for PC

On PC (RC+) side, the password can be set for each connection destination. (Ethernet connection only)


- (1) Click the following icon on EPSON RC+ 7.0 menu.



- (2) The [PC to Controller Communications] dialog box is displayed.
Select the target "Ethernet" connection. Click the <Password> button.




- (3) The [Change Connection Password] dialog box is displayed.
Type the password in [Enter New Password] and [Confirm New Password].



- (4) Click the <OK> button.
(5) When both passwords have been input and match, the password will be registered and the [PC to Controller Communications] dialog box will close.

The following message will be displayed when the passwords do not match.



Click the <OK> button to return to the [PC to Controller Communications] dialog box.

1.9.2 PC Ethernet Connection to Controller

When connecting to a Controller for which a public (global) IP address is configured, connection authentication using password is required.

When connecting to a Controller for which a private (local) IP address is configured, connection authentication using password is optional.

Note: Authentication is performed when the authentication password for a PC Ethernet connection is configured.

1.9.3 Remote Ethernet

To login via Remote Ethernet, password authentication is required.


All commands are not available until you log in via Remote Ethernet.

If the command is executed without login via Remote Ethernet, error “11” occurs.
For details on the error, refer to *12.2.7 Response-Error response*.

1.9.4 Disable the PC Ethernet Controller Connection Authentication

You can disable PC (Ethernet) connection authentication.
(Connection authentication is enabled by default.)

- (1) Select EPSON RC+ 7.0 menu-[Setup]-[System Configuration]-[Controller]-[Preferences].
- (2) Select the [Disable connection password] checkbox.
Click the <Apply> button.



Important

- Connection will not be secured if the connection authentication is disabled.
Please be very careful when connecting to Internet.

1.10 Security for Compact Vision CV2-A Ethernet Connection

From the following firmware versions password authentication is required when connecting Compact Vision units, Controllers, and PCs to a public (global) accessible network.

Controller F/W : Ver.7.5.0.x

Compact Vision F/W : Ver.3.1.3.x

Similar to our robot system, a Compact Vision CV2-A unit is provided on the assumption that customers use it in a closed local area network. We considered the use of a public IP address for the CV2-A that can be accessed via the Internet (directly or through a router) and changed the specification to support password authentication in order to secure the connection.

Be sure to use an IP address in the following private IP address ranges unless a public (global) IP address is required.

Private IP Address Ranges

10.0.0.1	to	10.255.255.254
172.16.0.1	to	172.31.255.254
192.168.0.1	to	192.168.255.254

For instructions on CV2-A connection password configuration, refer to the following manual.

Vision Guide Hardware & Setup 2.3.2 CV1/CV2 Camera Configuration

1.11 Security for Feeder Ethernet Connection

Similar to our robot system, a feeder (IF-240, IF-530, IF-80) is provided on the assumption that customers use it in a closed local area network. Be sure to use an IP address in the following private IP address ranges unless a public (global) IP address is required.

Private IP Address Ranges

10.0.0.1	to	10.255.255.254
172.16.0.1	to	172.31.255.254
192.168.0.1	to	192.168.255.254

The feeder does not have a security feature such as password authentication to prevent unauthorized access. If it is necessary to set a global (public) IP address to use the feeder, please carefully consider the risk of unauthorized access via the Internet.

For instructions on the feeder, refer to the following manual.

*Part Feeding 7.0 Introduction & Hardware (Common) & Software
Software 2.1.1 Part Feeding Page*

2. Safety

2.1 Overview




This chapter describes the important safety requirements for robotic systems using EPSON RC+ 7.0 and the Controller.

Installation of robots and robotic equipment should only be performed by qualified personnel in accordance with national and local codes. Please read and understand this entire chapter before using your EPSON RC+ 7.0 system.

Safety is the most important consideration when designing and operating any robotic system.

In this manual, important matters are shown with the symbols below.

Each symbol has following meanings.

 WARNING	<p>This symbol indicates that a danger of possible serious injury or death exists if the associated instructions are not followed properly.</p>
 WARNING	<p>This symbol indicates that a danger of possible harm to people caused by electric shock exists if the associated instructions are not followed properly.</p>
 CAUTION	<p>This symbol indicates that a danger of possible harm to people or physical damage to equipment and facilities exists if the associated instructions are not followed properly.</p>

2.2 Definitions

2.2.1 Robot Power

The status of robot power is explained below in terms of restriction to operation:

Operation-prohibited status:	Robot cannot be operated.
Restricted (low power) status:	Robot can operate at low speed and low torque.
Unrestricted (high power) status:	Robot can operate without restriction.

The robot will not operate regardless of the control actions taken by the operator when in the operation-prohibited state. During operation, when the safeguard circuit opens, the system will switch to operation-prohibited state.

The robot will operate at low speed and torque in the restricted state (low power). In the unrestricted state (high power), the robot will operate at the programmed speed and torque.

In the event that the robot should make an unexpected movement, the restricted state (low power) decreases operating speed allowing the operator to avoid danger. The torque is also decreased to minimize serious injury to the operator should one be struck by the robot. The maximum values of the decreased speed and torque are set according to the robot used and cannot be changed by the user.

As a safety precaution the initial power state of the robot will be set to either the restricted (low power) state or the operation-prohibited state. The system will not change to the unrestricted (high power) state if the appropriate procedures are not followed.

When the system is in restricted (low power) state or operation-prohibited state, a single failure will not cause a runaway action that surpasses the assigned speed or torque decrease. This is due to the multi-protect circuit and mutual monitoring circuit in the control system.

2.2.2 Safeguard

To ensure safe operation, install a safety system using safety doors, light curtains, safety floor mats, etc.



- The EMERGENCY connector on the controller has a safeguard input circuit to connect the safety device interlock switch. To protect operators working near the robot, be sure to connect the interlock switch and make sure that it works properly.

Safeguard open: : The safeguard input is turned OFF, and the interlock function operates.

Safeguard closed: : The safeguard input is turned ON.

If a closed safeguard is open during robot motion, the safeguard interlock function operates. The robot stops immediately and enters into pause state. Then, all robot motors are turned OFF. The descriptions below explain how the safeguard input works.

Safeguard open: : The robot stops immediately, motors are turned OFF, and further operation is impossible until either the safeguard is closed or Teach or TEST mode is turned ON and the enable circuit is engaged.

Safeguard closed: : The robot can automatically operate in unrestricted (high power) state.

For further details on the safeguard and interlock, refer to *2.4 Installation and Design Precautions* later in this chapter. For detailed wiring instructions, refer to the *Robot Controller manual, Setup & Operation: 9. EMERGENCY*.

2.2.3 Operation Modes

The operation mode is defined as the single control point for the controller, therefore you cannot use more than one operation mode at the same time.

There are four operation modes for the controller: AUTO, PROGRAM, TEACH, and TEST.

- AUTO operation modes allow you to execute programs in the controller when the safeguard is closed.
- PROGRAM operation mode allows you to execute and debug programs when the safeguard is closed.
- TEACH operation mode allows you to jog and teach the robot at slow speed while inside the safeguarded area.
- TEST operation mode allows you to execute a program at slow speed while the safeguard is opened.

2.2.4 Start Mode

The Start mode specifies the operation mode for EPSON RC+ 7.0 when it starts.

You can set the EPSON RC+ 7.0 to start in AUTO or PROGRAM mode.

For information on how to change the start mode, refer to *4. Operation*.

2.2.5 Changing Operation Mode

You can change from AUTO operation mode or PROGRAM operation mode to TEACH mode by setting the mode selector key switch on the Teach Pendant to the TEACH position.

TP1, TP2: Teach

TP3: TEACH/T1, TEACH/T2

When the mode selector key switch is changed back to Auto (TP1, TP2) or AUTO (TP3), the operation mode is returned to previous operation mode (AUTO or PROGRAM).

The AUTO operation mode can be changed to PROGRAM mode during the EPSON RC+ 7.0 startup sequence. A password can be used to allow only certain personnel to change the startup operation mode.

When EPSON RC+ 7.0 starts in AUTO operation mode, the AUTO operation mode cannot be changed to PROGRAM operation mode after the system has started. To change the operation mode, restart the system and log into PROGRAM mode, then set the start mode again and restart EPSON RC+ 7.0.

For more information, refer to 4. *Operation*.

To change to TEST operation mode:

TP1: Switch the mode selector key switch on the Teach Pendant to Teach, and then select Function key F1: Test Mode.

TP3: Switch the mode selector key switch on the Teach Pendant to TEACH/T1 or TEACH/T2, and then tap the [Test] tab.

For more information, refer to the following manuals.

Robot Controller option Teach Pendant TP1 or TP3 manual, 4. Operation Mode (TEACH/AUTO/TEST).



Robot Controller option Teach Pendant TP2 manual, 4. Operation Mode (TEACH/AUTO).

T2 mode cannot be used on RC700-A for complying with the UL standard.

2.2.6 Emergency Stop

The controller is equipped with an emergency stop input terminal. If the normally closed emergency stop circuit is broken, the power supplied to all motors will be shut off (and enter servo-free status) and the robot will be stopped by dynamic braking.



- The path that the robot will follow from the time the emergency stop switch is pressed until the device stops, as well as the stop position itself, cannot be positively determined. In many cases, the stop position will not exceed the target position for the operation prior the emergency stop. Depending on the robot's loading condition and operation speed, overruns are inevitable. Taking this into consideration, be sure the layout for the peripheral equipment includes extra space.

For detailed wiring instructions, refer to the *Robot Controller manual, Setup & Operation: 9. EMERGENCY*.

2.2.7 Teach Pendant

Operators can use the teach pendant to operate the robot in the TEACH or TEST operation mode.

For operation instructions, refer to the following manuals.

Robot Controller option Teach Pendant TP1, TP2, or TP3 manual.

2.3 Safety-related Requirements

Specific tolerances and operating conditions for safety are contained in the manuals for the robot, controller and other devices. Be sure to read those manuals as well.

For the installation and operation of the robot system, be sure to comply with the applicable local and national regulations.

Robot systems safety standards and other examples are given in this chapter. Therefore, to ensure that safety measures are complete, please refer to the other standards listed as well.

(Note: The following is only a partial list of the necessary safety standards.)

EN ISO 10218-1	Robots and robotic devices -- Safety requirements for industrial robots -- Part 1: Robots
EN ISO 10218-2	Robots and robotic devices -- Safety requirements for industrial robots -- Part 2: Robot systems and integration
ANSI/RIA R15.06	American National Standard for Industrial Robots and Robot Systems -- Safety Requirements
EN ISO 12100	Safety of machinery -- General principles for design -- Risk assessment and risk reduction
EN ISO 13849-1	Safety of machinery -- Safety-related parts of control systems -- Part 1: General principles for design
EN ISO 13850	Safety of machinery -- Emergency stop function-- Principles for design
EN ISO 13855	Safety of machinery -- Positioning of safeguards with respect to the approach speeds of parts of the human body.
EN ISO 13857	Safety of machinery -- Safety distances to prevent hazard zones being reached by upper and lower limbs.
EN ISO 14120	Safety of machinery -- Guards -- General requirements for the design and construction of fixed and movable guards
IEC 60204-1 EN 60204-1	Safety of machinery -- Electrical equipment of machines -- Part 1: General requirements
CISPR11 EN 55011	Industrial, scientific and medical (ISM) radio-frequency equipment -- Electromagnetic disturbance characteristics -- Limits and methods of measurement
IEC 61000-6-2 EN 61000-6-2	Electromagnetic compatibility (EMC) -- Part 6-2: Generic standards - - Immunity for industrial environments

2.4 Installation and Design Precautions

2.4.1 Designing a Safe Robot System

It is important to operate robots safely. It is also important for robot users to give careful consideration to the safety of the overall robot system design.

This section summarizes the minimum conditions that should be observed when using EPSON robots in your robot systems.

Please design and manufacture robot systems in accordance with the principles described in this and the following sections.

Environmental Conditions

Carefully observe the conditions for installing robots and robot systems that are listed in the “Environmental Conditions” tables included in the manuals for all equipment used in the system.

System Layout

When designing the layout for a robot system, carefully consider the possibility of error between robots and peripheral equipment. Emergency stops require particular attention, since a robot will stop after following a path that is different from its normal movement path. The layout design should provide enough margins for safety. Refer to the manuals for each robot, and ensure that the layout secures ample space for maintenance and inspection work.

When designing a robot system to restrict the area of motion of the robots, do so in accordance with the methods described in each manipulator manual. Utilize both software and mechanical stops as measures to restrict motion.

Install the emergency stop switch at a location near the operation unit for the robot system where the operator can easily press and hold it in an emergency.

Do not install the controller at a location where water or other liquids can leak inside the controller. In addition, never use liquids to clean the controller.

Disabling Power to the System using lock out / tag out

The power connection for the robot controller should be such that it can be locked and tagged in the off position to prevent anyone from turning on power while someone else is in the safeguarded area. For further details, refer to the section *Procedure of Lockout/Tagout* in the chapter *Safety Precautions* in the controller manual.

End Effector Design

Provide wiring and piping that will prevent the robot end effector from releasing the object held (the work piece) when the robot system power is shut off.

Design the robot end effector such that its weight and moment of inertia do not exceed the allowable limits. Use of values that exceed the allowable limits can subject the robot to excessive loads. This will not only shorten the service life of the robot but can lead to unexpectedly dangerous situations due to additional external forces applied to the end effector and the work piece.

Design the size of the end effector with care, since the robot body and robot end effector can interfere with each other.

Peripheral Equipment Design

When designing equipment that removes and supplies parts and materials to the robot system, ensure that the design provides the operator with sufficient safety. If there is a need to remove and supply materials without stopping the robot, install a shuttle device or take other measures to ensure that the operator does not need to enter a potentially dangerous zone.

Ensure that an interruption to the power supply (power shutoff) of peripheral equipment does not lead to a dangerous situation. Take measures that not only prevent a work piece held from being released as mentioned in “End effector Design” but that also ensure peripheral equipment other than the robots can stop safely. Verify equipment safety to ensure that, when the power shuts off, the area is safe.

Remote Control

To prevent operation by remote control from being dangerous, start signals from the remote controller are allowed only when the control device is set to REMOTE, the operation mode is set to AUTO or Program, and the system is configured to accept remote signals. Also when remote is valid, motion command execution and I/O output are available only from remote. For the safety of the overall system, however, safety measures are needed to eliminate the risks associated with the start-up and shutdown of peripheral equipment by remote control.

Emergency Stop

Each robot system needs equipment that will allow the operator to immediately stop the system's operation. Install an emergency stop device that utilizes emergency stop input from the controller and all other equipment.

During an emergency stop, the power that is supplied to the motor driving the robot is shut off, and the robot is stopped by dynamic braking.

The emergency stop circuit should also remove power from all external components that must be turned off during an emergency. Do not assume that the robot controller will turn off all outputs if configured to. For example, if an I/O card is faulty, the controller cannot turn off a component connected to an output. The emergency stop on the controller is hardwired to remove motor power from the robot, but not external power supplies.

Do not press the Emergency Stop switch unnecessarily while the Robot is operating. Pressing the switch during the operation makes the brakes work. This will shorten the life of the brakes due to the worn friction plates.

Normal brake life cycle: About 2 years (when the brakes are used 100 times/day or 1000 times of emergency stops for H8)

Do not turn OFF the Controller while the Manipulator is operating.

If you attempt to stop the Manipulator in emergency situations such as “Safeguard Open”, make sure to stop the Manipulator using the Emergency Stop switch of the Controller.

If the Manipulator is stopped by turning OFF the Controller while it is operating, following problems may occur.

- Reduction of the life and damage of the reduction gear unit

- Position gap at the joints

In addition, if the Controller was forced to be turned OFF by blackouts and the like while the Manipulator is operating, make sure to check the following points after power restoration.

- Whether or not the reduction gear is damaged

- Whether or not the joints are in their proper positions

If there is a position gap, perform calibration by referring to the Maintenance: Calibration in the Manipulator manual.

Following manuals contain information on the Emergency Stop.

Robot System Safety and Installation (RC700 / RC700-A, EPSON RC+7.0)
Manipulator manual

Please also read the descriptions in the manuals and use the robot system properly.

Before using the Emergency Stop switch, be aware of the followings.

- The Emergency Stop (E-STOP) switch should be used to stop the Robot only in case of emergencies.
- To stop the Robot operating the program except in emergency, use Pause (halt) or STOP (program stop) commands, or release the Safeguard system. Pause and STOP commands do not turn OFF the motors. Therefore, the brake does not function. Releasing the Safeguard system stops the Robot with a quick pause, and makes the brakes work. Pushing the Emergency Stop switch (E-STOP) turns OFF the motors and makes the brakes work. The brakes lock while the Robot is operating.
- For the Safeguard system, do not use the circuit for E-STOP.

For details of the Safeguard system, refer to the following manuals.

Safety and Installation 2.6 Connection to EMERGENCY Connector

To check brake problems, refer to the following manuals.

Manipulator Manual

Maintenance 2.1.2 Inspection Point

- Inspection While the Power is ON (Robot is operating)

Safety and Installation

5.1.1 Manipulator - Inspection While the Power is ON (Robot is operating)

Safeguard System

To ensure safety, a safeguard system should be installed for the robot system.

When installing the safeguard system, strictly observe the following points:

Refer to each manipulator manual, and install the safeguard system outside the maximum space. Carefully consider the size of the end effector and the work pieces to be held so that there will be no error between the moving parts and the safeguard system.

Manufacture the safeguard system to withstand calculated external forces (forces that will be added during operation and forces from the surrounding environment).

When designing the safeguard system, make sure that it is free of sharp corners and projections, and that the safeguard system itself is not a hazard.

Make sure that the safeguard system can only be removed by using a tool.

There are several types of safeguard devices, including safety doors, safety barriers, light curtains, safety gates, and safety floor mats. Install the interlocking function in the safeguard device. The safeguard interlock must be installed so that the safeguard interlock is forced to work in case of a device failure or other unexpected accident. For example, when using a door with a switch as the interlock, do not rely on the switch's own spring force to open the contact. The contact mechanism must open immediately in case of an accident.

Connect the interlock switch to the safeguard input of the drive unit's EMERGENCY connector. The safeguard input informs the robot controller that an operator may be inside the safeguard area. When the safeguard input is activated, the robot stops immediately and enters pause status, as well as either operation-prohibited status or restricted status (low power status).

Make sure not to enter the safeguarded area except through the point where the safeguard interlock is installed.

The safeguard interlock must be installed so that it can maintain a safe condition until the interlock is released on purpose once it initiates. The latch-release input is provided for the EMERGENCY connector on the Controller to release the latch condition of the safeguard

interlock. The latch release switch of the safeguard interlock must be installed outside of the safeguarded area and wired to the latch-release input.

It is dangerous to allow someone else to release the safeguard interlock by mistake while the operator is working inside the safeguarded area. To protect the operator working inside the safeguarded area, take measures to lock out and tag out the latch-release switch.

Presence Sensing Device

The above mentioned safeguard interlock is a type of presence sensing device, since it indicates the possibility of somebody being inside the safeguard system. When separately installing a presence sensing device, however, perform a satisfactory risk assessment and pay thorough attention to its dependability.

Here are precautions that should be noted:

- Design the system so that when the presence sensing device is not activated or a dangerous situation still exists that no personnel can go inside the safeguard area or place their hands inside it.
- Design the presence sensing device so that regardless of the situation the system operates safely.
- If the robot stops operating when the presence sensing device is activated, it is necessary to ensure that it does not start again until the detected object has been removed. Make sure that the robot cannot automatically restart.

Resetting the Safeguard

Ensure that the robot system can only be restarted through careful operation from outside the safeguarded system. The robot will never restart simply by resetting the safeguard interlock switch. Apply this concept to the interlock gates and presence sensing devices for the entire system.

Robot Operation Panel

The robot operation panel must not be located inside of the robot work envelope / workcell. Ensure that the robot system can be operated from outside of the safeguard.

2.4.2 Robot System Installation, Start-up, and Testing

Installation

When installing the robot and robot system, follow the instructions contained in each of the robot and robot controller manuals.

Start-up and Functional Testing

If the safeguard system is not ready at the time of start-up and functional testing, specify an area to install the safeguard system (as a temporary measure) and then begin.

During start-up and functional testing, do not allow workers inside the safeguarded area until the safeguard function is activated.

Before start-up and functional testing, carefully read the related manuals and obtain a good understanding of safety-related precautions.

Before supplying the robot and robot system with power for the first time, verify the items listed below.

Items to check before supplying with power

- Prescribed bolts are securely tightened to the robot.
- Electrical connections are set up correctly, and power supply conditions (including voltage, frequency, and error level) are within the specified range.
- Compressed air source (if applicable) is properly connected.
- Peripheral devices are properly connected.
- Safety device is equipped with an interlock switch, and it functions properly.
- Operating environment conditions conform to the conditions specified in the robot and controller manuals.

Items to check after supplying with power

- Start/stop, mode selection, and other functions work properly.
- Moving axes operate normally, and that the area of motion is limited as stipulated in the specifications.
- Emergency stop circuit functions correctly.
- Power supply can be shut off.
- Teach operation mode is functioning properly.
- Safety device and interlock switch function correctly.
- Other safeguards (if applicable) are installed correctly in their prescribed locations.
- Robot operates accurately in restricted status (low power status).
- Robot operates properly under rated loads and at maximum speed.

Restarting after a Change

When restarting the robot system after its hardware or software has been corrected or serviced, strictly observe the following:

- Before supplying the system with power, check the locations where the hardware was modified.
- Test the functions of the robot system to make sure that it operates correctly.

2.5 Precautions regarding Robot Operation

2.5.1 General Precautions

Before operation, become familiar with the location of all emergency stop switches.

During an emergency, always press the nearest emergency stop switch. There should never be any emergency stop switches in the system that do not operate.

After an emergency, do not restore the emergency stop circuit until it has been determined that the entire system is safe to restart.

If your robot is a 6-axis type, record the pulse values of the reference points used for the calibration. For details, refer to *Setup & Operation 3.7 Checking the Basic Orientation* in the Manipulator manual.

2.5.2 Automatic Operation

Ensure that system automatic operation is enabled only while the following requirements are being met:

- Emergency stop switches are installed in the prescribed location and operate correctly.
- No personnel are inside the safeguarded area of the system.
- Safety procedures that are established separately for the robot system (if applicable) are being followed.

2.5.3 Teaching Robot Points

If possible, teaching should be performed with no operator inside the safeguarded area.

TEACH mode can be used to allow the robot to be jogged or moved at slow speed when the safeguard is open. Before the operators go inside the safeguarded area, they must switch the mode selector key switch of the teach pendant to TEACH mode. Operators then carry the teach pendant while inside the safeguarded area. As a result, the operation mode cannot be changed from outside the safeguarded system while operator is inside the safeguarded area.

AUTO Mode:

With the safeguard circuit open, the robot motors will be turned off and the robot cannot be jogged under power. However, the robot can be moved by hand to a position with the safeguard circuit open and the position can then be taught.

TEACH Mode:

The robot can be jogged or moved at slow speed as long as the three position enable (dead man) switch is engaged.

Please observe the following guidelines for teaching points:

- Robot operators must receive training that utilizes the same type of robot. Before teaching, the operator should be thoroughly familiar with teaching procedures.
- Before teaching, remove all errors and malfunctions.
- Before the robot operator goes inside the safeguard system, confirm that the robot motors go off when the safeguard is open and that emergency stop switches are functioning correctly.
- The robot operator should visually check the robot system and safeguard system interior to ensure that there are no potential hazards.
- Design the system in such a way that prevents the overall robot system from being started up from any location while the operator is inside the safeguarded area.

- If there is a possibility of a dangerous situation arising from the operation of a device other than the robot, such as an actuator, take steps to prevent such operation or ensure that these devices can only be controlled by the teaching operator.

2.5.4 Return to Automatic Operation

If there are safety devices that have been temporarily disabled for system inspection or other reasons, always return them to their original status before restarting automatic operation.

2.5.5 Program Verification

If it is necessary to verify a program on the EPSON RC+ 7.0 while the system is in unrestricted (high power) status, first make sure that no personnel are inside the safeguarded area.

If it is necessary to verify a program on Teach Pendant TP1, TP3 (TEST operation mode), follow the rules below.

- An operator must receive training about the robot of the same type. Program verification should be done after the operator has a thorough knowledge about the operation procedure of TEST operation mode.
- Remove all obstacles and failures before the program verification.
- An operator should check that the Motor is turned OFF when the safeguard is opened, and check if the Emergency Stop switch functions properly before entering inside the safeguard.
- An operator should check the possibility of risk by checking the robot system and inside of the safeguard visually.
- If someone is inside the safeguard, do not allow the whole robot system to be controlled to start operation from outside.
- If there is a possibility that operation of equipment other than the robot, such as an actuator, may cause danger, do not allow the operation of equipment, or allow only the program verifier to control the equipment.

2.5.6 Troubleshooting

Troubleshoot from outside the safeguard system. If that is not possible, strictly observe the requirements below.

- Operators responsible for troubleshooting should be trained and qualified to perform such work.
- Establish work safety procedures to minimize the danger that operators inside the safeguard system will be exposed to.

2.5.7 Maintenance

In order to keep the robot and robot system operating safely, maintenance (and inspection) is important. Adequately trained personnel should perform the procedures required to do the maintenance work safely. Make sure that maintenance is performed according to the instructions in the robot and controller manuals (maintenance editions).

If maintenance is required inside the safeguarded area, take the following precautions:

- Shut off the power supply using lockout / tagout to prevent anyone from turning ON the robot power supply by mistake. For further details, refer to the section *Procedure of Lockout/Tagout* in the chapter *Safety Precautions* in the controller manual.
- If the robot system power supply cannot be shut off, strictly observe the following:
 - (1) Visually inspect the robot system to ensure that there are no conditions that could lead to a malfunction.
 - (2) If it is discovered that the robot system is damaged or malfunctioning, perform the required repairs and retest it before allowing the operator to go inside the safeguard system.
- Grant full control of the robot and robot system to those performing maintenance and/or repairs inside the safeguard system.
- Ensure that the robot system does not respond to any remote control devices.
- Ensure that all emergency stop devices are functioning correctly.
- Before starting the robot system in automatic operation, return all temporarily disabled safety devices to their original enabled status.
- Do not use tweezers or other metal tools to aid in battery replacement. This could cause a battery short. Replace a battery using only the specified type and be careful to observe the polarity of the battery.

2.5.8 Backup of Projects and Controller

After a project has been created or edited, or after system data including robot parameters has been edited, the project and controller files should be copied and stored in media other than the hard disk on the PC (e.g. USB memory key). Keep the backup media in a safe place in case of damaged data on the hard disk

To backup, select [Controller] from the EPSON RC+ 7.0 [Tools] menu and execute Backup Controller. Refer to the section *5.11.8 Controller Command*.

Backup Controller is a function to backup both the project and the controller.

To backup only the project data, select [Copy] from the [Project] menu. Refer to the section *5.9.11 Copy Command*.



- If your system cannot be restored by Restore Controller, you must restore robot calibration parameters (Hofs, CalPIs) before operating the robot. If you fail to do so, the robot will move to incorrect positions.

2.6 End User Instruction Manual

Be sure that the robot system instruction manual supplies a list of all the equipment included in the system (such as the robots, associated equipment, and safety devices) as well as a description of how to use each.

Be sure to provide the following in the manual:

- An easy to follow explanation of the robot system and how to install it, as well as a step by step summary of the system installation and external power supply connections.
- A description of all hazards and how to avoid them.
- A description (including interconnection diagrams) of the safety devices, interacting functions, and safeguard's interlocking function against hazardous conditions, in particular, the safeguard's interlocking function for devices installed to perform interactively.
- Precise instructions regarding usage of the system.

2.7 End User Training

Be sure those in charge of safety management confirm that the operators who program, operate, and maintain the robot and robot system obtain proper training and have the expertise to conduct the work safely.

Training should include at least the following:

- Study of regulation safety procedures, and safety-related recommendations by robot manufacturers and system designers.
- Clear explanation of the work involved.
- Description of all control equipment required for the work and their functions.
- Explanation of potential hazards involved in the work.
- Work safety procedures and specific methods of avoiding potential hazards.
- Safety device and interlock function testing and confirmation methods are working properly.

3. Getting Started

This chapter contains instructions for setting up and using EPSON RC+ 7.0. It is recommended that first time users first read the preceding Safety chapter, then read through this chapter to get more familiar with the system.

Contents

- Hardware Installation
- Software Installation
- Windows Security Administration

3.1 Hardware Installation

EPSON RC+ 7.0 is used with the Controller. You need to install the controller and robot before you can use EPSON RC+ 7.0 to develop and run SPEL+ applications.

You need to prepare the PC which has Windows which can run the EPSON RC+7.0, and which can connect with the Controller using USB or Ethernet.

The Controller comes pre-configured at the factory. For instructions on installation, refer to the Robot Controller manual.

3.2 Software Installation

EPSON RC+ 7.0 should be installed to the PC with Windows. For details of adding the options, version upgrade, and re-installation, refer to *Appendix B: EPSON RC+ 7.0 Software*.

3.3 Windows Security Administration

Users need Administrator rights to use the EPSON RC+. Other users such as Power User, Limited User, Guest User cannot use EPSON RC+.

To provide security within the EPSON RC+ environment, a Security software option is available. This option allows you to manage EPSON RC+ users and audit development activity. Refer to *15. Security* for details.

4. Operation

This chapter contains instructions for operation of the EPSON RC+ 7.0 system. The main topics are:

- System Power Up Procedure
- Starting EPSON RC+ 7.0
- System Shutdown Procedure
- Writing your first program

4.1 System Power Up Procedure

Follow this procedure to power up the system:

1. Ensure that all safeguards are in place and that all personnel are clear of the equipment.
2. Apply power to the Controller, monitor, and I/O devices.
3. Start the EPSON RC+ 7.0 software on the PC, if the PC is used in the system.

4.2 Starting EPSON RC+ 7.0

There are three ways to start EPSON RC+ 7.0. You can also configure the mode that EPSON RC+ 7.0 starts in.

Start Method 1

Double click on the EPSON RC+ 7.0 robot icon located on the Windows desktop.

Start Method 2

1. Click the Windows <Start> button.
2. Select the EPSON RC+ 7.0 [Program] group.
3. Select [EPSON RC+ 7.0]-[EPSON RC+ 7.0].

Start Method 3

Configure EPSON RC+ 7.0 to start automatically after Windows starts.

For details, refer to *4.2.7 Auto Start*.



When using the RC+ API option, you do not need to start EPSON RC+ 7.0. The library provided with RC+ API will load EPSON RC+ 7.0 into your .NET application process automatically.

4.2.1 Startup Sequence

When EPSON RC+ 7.0 starts, it reads initial settings for the current user and local system from the Windows registry.

The startup sequence depends on the following two factors:

- a. Control device
- b. Independent mode

When start mode is other than Independent mode
(Any control device)

If there is no project file specified in the startup command line, the last-opened project will be opened.

If the start mode is Auto, the [Start Mode] dialog will be displayed (see *4.2.4 Start Mode Dialog*).

If the start mode is Program, the EPSON RC+ 7.0 GUI will be displayed.


When start mode is Independent mode

(Control device : Remote)

If there is no project file specified in the startup command line, the last-opened project will be opened as read only.

If tasks are currently running, EPSON RC+ 7.0 will prompt to enter Monitor Mode.

If no tasks are currently running, a dialog below will be displayed.



Cooperative mode and Independent mode

The Robot Controller consists of the following two parts.

Real Part : Controls the SPEL⁺ program (Specialized for the real time control)

Windows Part : Controls the Windows applications (GUI)

The main function of the robot can be run by Real Part and some functions of the Controller uses the connected Windows Part (See below).

Function	RC+ Enabled	PC Enabled
Detail of available function	Vision Guide (PV1) RC+ API option Fieldbus master	PC file PC RS-232C Database access DLL calling

Real Part and connected Windows Part are started up separately at the each timing.

To operate the robot system without problem, you should synchronize these two parts. At the shipment of the Robot Controller, the **Independent mode** which these parts operate individually is applied.



According to the design of robot system, it may not need to synchronize Real Part and connected Windows Part. In this case, change to **Cooperative mode**.

For the instructions of this settings, see the section below *How to set the Cooperative mode*.

When the controller is in Cooperative mode, it has to wait until both of Real Part and connected Windows Part can start up without failure.













Meanwhile, on the front surface of the controller displays as below:

RC700 Seven-segment LED	RC90 LED
<p>Repeats</p> <p>alternately.</p>	<p>Repeats</p> <p>E-STOP AUTO E-STOP AUTO</p> <p>ERROR TEACH PROGRAM ERROR TEACH PROGRAM</p> <p>alternately.</p>

Then, it also has to wait until connected Windows part is ready and RC+ 7.0 can start up without failure.









4. Operation

The table below shows the startup sequence when the controller is in Cooperative mode:

	RC700 Seven-segment LED	RC90 LED	Console instruction	Background task
(1) Power ON	 No display	E-STOP AUTO ERROR TEACH PROGRAM  Blinking	Not available	Not started yet
(2) Real Part starts up	Repeats  and  alternately.	Repeats E-STOP AUTO E-STOP AUTO ERROR TEACH PROGRAM ERROR TEACH PROGRAM  and  alternately.	Not available	Not started yet
(3) Windows part starts up	Repeats  and  alternately.	E-STOP AUTO E-STOP AUTO ERROR TEACH PROGRAM ERROR TEACH PROGRAM  and  alternately.	Not available	Not started yet
(4) RC+ starts up	 Blinking	E-STOP AUTO ERROR TEACH PROGRAM  Blinking	Available	Already started

(Includes the startup of the Operator Window and RC+ API application)

The table below shows the startup sequence when the controller is in Independent mode:

	RC700 Seven-segment LED	RC90 LED	Console instruction	Background task
(1) Power ON	 No display	E-STOP AUTO ERROR TEACH PROGRAM  Blinking	Not available	Not started yet
(2) Real Part starts up	 Blinking	E-STOP AUTO ERROR TEACH PROGRAM  Blinking	Available *1	Already started
(3) Windows part starts up	 Blinking	E-STOP AUTO ERROR TEACH PROGRAM  Blinking	Available *1	Running
(4) RC+ starts up	 Blinking	E-STOP AUTO ERROR TEACH PROGRAM  Blinking	Available	Running

*1 When the control device is "PC":

It waits the command execution from the Operator Window or RC+ API application.

When the control device is other than "PC":


(2) At Real Part starts up, Remote function becomes enable and starts operating.



When the controller is in Cooperative mode, the state does not back to wait for the RC+ connection even after RC+ shutdown. Also when the control device is other than "PC", you need to be careful during the RC+ shutdown because the remote command is still executable.

How to set the Cooperative mode

- (1) Select [Setup]-[System Configuration] from the main menu and displays the [System Configuration] dialog box as shown below.
- (2) Select [SPEL Controller Board]-[Preferences].




- (3) Uncheck the [Independent mode] checkbox.
- (4) Click <Apply> button.
- (5) Click the <Close> button.

4.2.2 Startup Configuration

To configure startup, select [System Configuration] from the [Setup] menu. The [Startup] section has pages for Start Mode, Auto Start, and Windows Login.

4.2.3 Start Mode

This page has settings for the EPSON RC+ 7.0 start mode.



There are two start modes:

- Auto** This mode starts the system and displays the Operator Window.
- Program** This mode allows you to develop your projects. This is the default startup mode.
- Use the <Password> button to change the start mode password.

4.2.4 Start Mode Dialog

When the start mode is set for Auto, then a dialog is displayed at start up that allows you to change the startup mode using a password. After a few seconds, if the <Change To Program Mode> button has not been clicked, the system will initialize and the Operator Window will be displayed.

You can disable this startup dialog using command line options described later in this section, *4.2.10 Command Line Options*.



If you click the <Change To Program Mode> button, another dialog will be displayed, as shown below:



To change to Program mode, you must supply the password and click <OK>, or you can abort startup all together by clicking <Cancel>.

This allows authorized personnel to enter Program mode temporarily to make changes or adjustments.



NOTE When you change to PROGRAM mode from this dialog, it is only temporary. The next time EPSON RC+ 7.0 runs, the original start mode setting will be used.

4.2.5 Start Mode: Program

Program mode is the default start mode. This is the EPSON RC+ 7.0 development environment, from which you can:

- Create / edit projects.
- Configure the controller and set preferences.
- Run and debug programs.

4.2.6 Start Mode: Auto

Auto mode displays the Operator Window. The Operator Window is configured according to the settings in [Project]-[Properties].

The Auto mode is set by the control device as follows:

Control Device	Description
PC	The Operator Window can be used as a simple operator interface for production.
Remote I/O Remote Ethernet Remote RS232 TP3	The Operator window is displayed with no operator buttons to allow any diagnostic messages to be viewed.

4.2.7 Auto Start

You can configure EPSON RC+ 7.0 to automatically start when Windows starts.

From [Setup]-[System Configuration]-[Auto Start] page, set the [Start EPSON RC+ 7.0 after Windows start] check box.

In addition, if you set the checkbox above, you can specify EPSON RC+ 7.0 command line options (/auto, /nosplash, etc.) in the [Command line options] text box. Refer to the section 4.2.10 *Command Line Options*.


When the startup mode is Auto, a main function of the SPEL+ program can be started automatically. Check the [Auto start SPEL+ program in ## seconds] check box. Time from the EPSON RC+ 7.0 startup until a main function starts can be specified in the textbox on the right. In the example below, a main function starts 10 seconds after the EPSON RC+ 7.0 run. Startup of the main function can be aborted if it is within the specified time.

NOTE


When using auto start, ensure that your application can automatically start safely and inform operators how to abort the startup.

NOTE


When using the Windows 8, select the [Desktop] tile on the start screen and then check if the EPSON RC+ 7.0 starts up automatically.



4.2.8 Using Monitor Mode

Monitor Mode allows you to monitor operation of the controller. In Monitor Mode, you can do the following:

- View print output on the Run window
- Monitor I/O status using the I/O Monitor.
- Monitor task status using the Task Manager.
- Monitor variable values using Display Variables.

To enter the monitor mode, follow the steps below.


When control device is remote and independent mode is on

1. Start the EPSON RC+ 7.0.
2. If tasks are running, you will be prompted to connect and monitor operation. If tasks are not running, you will be prompted to connect in monitor mode, or switch to the Program mode.

4.2.9 Windows Login

You can configure automatic Windows login from the EPSON RC+ 7.0. In [Setup]-[System Configuration]-[Startup]-[Windows Login] page, check the [Enable windows auto login] check box. Then, enter the name and password of the user logging in. Optionally, you can supply a domain, if required.

However, you must have the authority of Windows Administrator to set login parameters. To configure automatic Windows login from the EPSON RC+ 7.0, you must reboot the system the first time. After the reboot, Windows login will be automatic.



4.2.10 Command Line Options

Refer to 4.2.11 *Using Command Line Options* to see how to use the command line options.

There are command line options for the EPSON RC+ 7.0 that provide the following functions:

Starting EPSON RC+ 7.0 for a specific project

When you start the EPSON RC+ 7.0, you can optionally specify a project name in the command line.

```
ERC70.EXE [drive:project_name]
```

drive:project_name The drive letter and name of a project. The name can include a subfolder of the \EpsonRC70\Projects directory.

Example: Open project *myapp* on drive C: at startup:

```
ERC70.EXE c:myapp
```

Change EPSON RC+ 7.0 startup mode

You can select the startup mode and override the startup dialog using command line options.

To start in Program mode (no password required)

```
ERC70.EXE /PROG
```

To start in Auto mode

```
ERC70.EXE /AUTO
```

Use these command line options to override and hide the startup dialog and open the Operator Window directly.

If only the AUTO flag is supplied and the control device is PC, EPSON RC+ 7.0 will open the project from the last session and display the operator window. EPSON RC+ 7.0 will only be visible in the Windows Task Manager. When the operator window is closed, EPSON RC+ 7.0 will be terminated.



When the control device is PC, you cannot close the operator window while tasks are running.

Example: Open project *myapp* on drive C and display the operator window:

```
ERC70.EXE c:myapp /AUTO
```

The Controller should be ON before starting EPSON RC+ 7.0 with the /AUTO command line option. If EPSON RC+ 7.0 cannot communicate with the controller, then an error message will be displayed with a retry button.

For more details, see 7.6 *Operator Window*.

Login

You can automatically login from the command line if you are not using the Auto Login feature for the security Option:

```
ERC70.EXE /LOGIN "userID", "password"
```

This is especially useful when you are starting in operator mode.

If the user I/D or password is invalid, it will display an error dialog and exit the EPSON RC+ 7.0.

Starting EPSON RC+ 7.0 specifying the language

You can specify the language to use in EPSON RC+ 7.0 GUI.

Japanese	: ERC70.EXE	/LANG_JAPANESE * ¹
English	: ERC70.EXE	/LANG_ENGLISH
German	: ERC70.EXE	/LANG_GERMAN * ²
French	: ERC70.EXE	/LANG_FRENCH * ²
Spanish	: ERC70.EXE	/LANG_SPANISH * ²
Chinese (Simplified)	: ERC70.EXE	/LANG_CHINESE_SIMP * ³
Chinese (Traditional)	: ERC70.EXE	/LANG_CHINESE_TRAD * ³

*¹ Available for Japanese OS

*² Available for English, German, French, and Spanish OS

*³ Available for Chinese OS

Disabling the EPSON RC+ 7.0 splash window

You can suppress the splash window displayed at startup using the following syntax:

ERC70.EXE /NOSPLASH

4.2.11 Using Command Line Options

Examples of command line options are:

Running from the Windows Run Box

You can specify a command from the Windows [Start] menu-[Run]-[Open] text box.

e.g. C:\EpsonRC70\exe\erc70.exe C:myapp

Making startup icons for your projects

You can create icons that automatically start EPSON RC+ 7.0 for different projects and start Auto or Program modes.


1. Right click on your desktop and select [New]-[Shortcut].
2. Click <Browse...> in the [Create Shortcut] dialog box.
Select "C:\EpsonRC70\exe\erc70.exe" and click the <OK> button. After the dialog changes, click the <Next> button.
3. Type a name for the shortcut and click <Finish>.
4. Right click the created icon and select [Properties]. Add an option such as "/AUTO" or "/PROG" to [Target:].

4.3 Communications with Controller

Your PC running EPSON RC+ 7.0 can communicate with a Controller using USB or Ethernet.

4.3.1 Configuring Communications with the Controller

To configure communications with the Controller, select [PC to Controller Communications] from the [Setup] menu. This will open the dialog shown below:



The dialog has a list of connections. The first connection is for USB and is fixed. You cannot delete it or rename it.

You can add one or more Ethernet connections and give each one a meaningful name.

The name for each connection is also shown in the Connections dropdown list on the main toolbar. If no name is supplied, the Ethernet IP address is shown in the dropdown list.

For more information on PC to Controller Communications, refer to 5.12.1. *PC to Controller Communications Command*.

4.3.2 USB Communications

USB 2.0 or USB 1.1 can be used to communicate with one controller. This is the default communication method for EPSON RC+ 7.0 and requires no configuration.

To connect to a controller via USB:

- (1) Connect a USB cable between the PC and the controller.
- (2) Turn ON the Controller.
- (3) Start EPSON RC+ 7.0.
- (4) Click the [PC to Controller Communications] button on the tool bar.
- (5) Ensure that connection #1 (USB) is selected.
- (6) Click the <Connect> button.
- (7) Click the <Close> button.



NOTE If the EPSON RC+ 5.0 is installed in the same computer and is performing the USB communication, the EPSON RC+ 7.0 cannot perform the USB communication. Make sure that the EPSON RC+ 5.0 is disconnected before connecting the EPSON RC+7.0.



NOTE When used with the Robot Controller RC620, the EPSON RC+ 7.0 cannot perform the USB communication.



CAUTION

- When performing the USB communication using the computer with Windows 8 or later, communication with the Controller is disconnected as the PC enters a sleep state. Before performing the USB communication, make sure to change the PC setting so that it will not enter the sleep mode.

4.3.3 Ethernet Communications



The robot controller does not support internet protocol version 6 (TCP/IPv6). When you connect the development PC to the robot controller using the Ethernet, make sure to use internet protocol version 4 (TCP/IPv4).

You can communicate with one or more Controllers from one PC using Ethernet. For Ethernet communications, each Controller must have a unique IP address. You can set the IP address, mask, and gateway for the controller from [Setup]-[System Configuration]-[Controller]-[Configuration]. The gateway setting is only required if you will be accessing the controller from outside of the local network.


You can connect a PC to a controller directly using an Ethernet cross-over cable, or you can connect the PC and controller to an Ethernet switch or hub.

Before you can communicate with a controller using Ethernet, you must configure the controller's IP address, IP mask, and IP gateway. This is accomplished by first connecting to the controller with USB, and then from the EPSON RC+ 7.0 [Setup]-[System Configuration]-[Controller]-[Configuration] page, set the IP address, IP mask, and IP gateway of the controller as shown below.

The following is the configuration of the controller at the time of shipment.

IP Address : 192.168.0.1
 IP Mask : 255.255.255.0
 IP Gateway : 0.0.0.0

Use the USB connection to configure Ethernet communications.



From the following firmware version password authentication is required when connecting Controllers and PCs to a global accessible network.

F/W : Ver.7.4.8.x (except T series Manipulator / VT series Manipulator)
 Ver.7.4.58.x (T series Manipulator / VT series Manipulator)


For details, refer to the following section.

- 1.9 Security for Controller Ethernet Connection
- 1.10 Security for Compact Vision CV2-A Ethernet Connection
- 1.11 Security for Feeder Ethernet Connection

4.3.4 Connecting When Control Device is not PC

Connecting while control device is not PC and tasks are not running

If your PC is not a control device and tasks are not running, you will see the following message box:




This allows you to [Leave the controller in Auto mode] to monitor operation, or [Switch the controller to Program mode] so you can edit and debug programs. If you choose to [Switch to Program mode], then the remote device cannot start programs until remote control has been enabled from the Run window.


Connecting from Remote Control while tasks are running

If the controller is running tasks with the control device set to Remote, you can connect the PC to the controller to monitor operation. For example, you can connect to a controller that is running tasks to temporarily monitor display output, tasks, and I/O, and then disconnect while tasks continue to run.

If the project on the PC is the same as on the controller, you will see the following message box when connection is established:



If the project on the PC is not the same as the project in the controller, you will see the following message box when connection is established:



If you choose to monitor controller operation, the Run window will open if EPSON RC+ 7.0 is started in Program mode. If EPSON RC+ 7.0 is started in Auto mode, the Operator window will appear. From the Run window or Operator window, you can view display output from Print statements executing in the application. You can also use the Task Manager and I/O monitor.

When monitoring controller operation, the controller remains in Auto mode. You cannot stop tasks from EPSON RC+ 7.0, because the control device is not PC. If you want to switch the controller to Program mode, you must first stop all tasks from the current control device, then connect to the controller from EPSON RC+ 7.0 and choose to switch to Program mode (see the previous section *Connecting while control device is not PC and tasks are not running*).

Disconnecting while tasks are running

You can only disconnect from the controller with tasks running when the control device is set to Remote.

1. Stop communications with the controller by selecting [Offline] from the [Connection] dropdown list on the toolbar.
2. You may now disconnect the communications cable between the PC and the controller. Tasks will continue to run in the controller.

4.4 Writing your first Program


After installing the controller, robot, and EPSON RC+ 7.0 software on the RC700 Robot Controller, follow these instructions to create a simple application program so that you will become more familiar with the EPSON RC+ 7.0 development environment.

1. Start EPSON RC+ 7.0

Double-click the EPSON RC+ 7.0 icon on the desktop.

2. Create a new project

- (1) Select New from the Project Menu.



- (2) Type in a name for a project in the [New Project Name] box. e.g. FirstApp

- (3) Click **OK** to create the new project.


When the new project is created, a program called “Main.prg” is created.

You will see the “Main.prg” window open with a cursor flashing in the upper left corner. Now you are ready to start entering your first program.

3. Edit the program


Type in the following program lines in the “Main.prg” edit window.

```
Function main
  Print "This is my first program."
Fend
```



4. Run the program

- (1) Press **F5** to run the program. (F5 is the hot key for the [Run Window] of the [Run] Menu). You will see the Status window located at the bottom of the main window showing the build operation status.
- (2) During project build, your program is compiled and linked. Then communications is established with the controller and project files are sent to the controller. If there are no errors during build, the Run window will appear.




- (3) Click the <Start> button on the [Run] window to run the program.
- (4) You should see text similar to the following displayed in the [Status] window:



```
19:32:45 Task main started
19:32:45 All tasks stopped
```

On the [Run] window, you will see the output of the print statement.


Now let's teach some robot points and modify the program to move the robot.

5. Teach robot points

- (1) Ensure that it is safe to operate the robot. Click the <Robot Manager> button  on the toolbar. You will see the [Robot Manager] window with the [Control Panel] page displayed.



- (2) Click on the <Motor On> button to turn on the robot motors. You will be prompted to confirm the operation.
- (3) Answer <Yes> to continue.
- (4) Click the [Jog & Teach] tab.



- (5) Click the <Teach> button in the lower right corner to teach point P0. You will be prompted for a point label and description.
- (6) Jog the robot by clicking the <+Y> jog button. Hold the button down to continue jogging. Let go when the robot is about half way out in the work envelope.
- (7) Jog the robot down by clicking the <-Z> button.
- (8) Now change the current point to P1 by selecting P1 in the Point dropdown list next to the <Teach> button.
- (9) Click the <Teach> button. You will see a confirmation message to teach the point.
- (10) Answer <Yes>.
- (11) Click the <+X> button to jog the robot in the +X direction.
- (12) Change the current point to P2 by selecting P2 in the Point dropdown list.
- (13) Click the <Teach> button. You will see a confirmation message to teach the point.
- (14) Answer <Yes>.

(15) Click the < Save all files >  toolbar button to save the changes.

6. Modify the program to include robot motion commands

(1) Insert three new Go statements into the Main.prg program as shown below:

```
Function main
    Print "This is my first program."
    Motor On
    Go P1
    Go P2
    Go P0

Fend
```

(2) Run the program by pressing F5 and then click on the <Start> button on the Run window.

(3) The robot should move to each of the points you taught.

7. Modify the program to change speed of robot motion commands

(1) Insert the Power, Speed, and Accel commands as shown in the program below:

```
Function main
    Print "This is my first program."
    Motor On
    Power High
    Speed 50
    Accel 50, 50
    Go P1
    Go P2
    Go P0

Fend
```

(2) Run the program by pressing F5

(3) Click on the <Start> button on the Run window.

The robot should go to each of the points you taught at 50% speed, acceleration, and deceleration. The Power High statement enables your program to run the robot at high (normal) power, which in turn allows the robot speed and acceleration to be increased.

8. Backup the project and system configuration

Even though this is only a sample project, we will backup the project and controller configuration. This is easy to do with EPSON RC+ 7.0. It is important that you keep regular backups of your applications on an external media such as a USB memory key.

Follow these steps to backup the project and system configuration:

- (1) From the [Project] menu, select [Copy].
- (2) Change the [Destination Drive] to an arbitrary drive.
- (3) Click <OK>. The project will be copied to the external media.
- (4) From the [Tools] menu, select [Controller].
- (5) Click on the <Backup Controller> button.
- (6) Select the arbitrary drive.
- (7) Click <OK>. The system configuration will be backed up on the external media.

Now that you have written your first program, you should read *7.1.1 Creating the simplest application*.


5. The EPSON RC+ 7.0 GUI

The chapter contains information on the EPSON RC+ 7.0 GUI.

- Overview
- Project Explorer Pane
- Status Window Pane
- Status Bar
- Online Help
- File Menu
- Edit Menu
- Display Menu
- Project
- Run
- Tools
- Setup
- Window
- Help

5.1 GUI Overview

EPSON RC+ 7.0 is a multiple document interface (MDI) application. There is one main parent window and several child windows which can be opened simultaneously. The main window has a menu bar, tool bar, and status bar, as shown below. In addition, there is a Project Explorer pane and Status Window pane.



5.2 Project Explorer Pane

The Project Explorer pane enables you to quickly open any file in the current project or jump to any function. The project files and functions are organized in a sorted tree structure.

Open a file or jump to a function : Double-click on the item.

Hide the Project Explorer : Click the X button on the bar above the pane.


Show the Project Explorer : Select Project Explorer from the View Menu.

Resize the Project Explorer : Move the mouse cursor over the right side of the pane, then drag the pane right or left to the desired width.

You can move the Project Explorer pane to either the left or right side of the main window. To move the pane, click down on the bar above the pane, then drag to either the left or right side of the main window and release the mouse button.

Context Menu

The Project Explorer Pane has a context menu for various operations for elements in the project tree. To access the context menu, right click on an item in the project tree.



5.3 Status Window Pane

The status pane displays status messages, such as project build status, system errors and warnings, etc.

Hide the Status pane : Click the X button on the bar above the pane.

Show the Status pane : Select Status Window from the View Menu.

Resize the Status pane : Move the mouse cursor over the top edge of the pane, and then drag the top edge up or down.

The Status pane is always located at the bottom of the main window and cannot be moved.



NOTE

If the Status pane is closed and an error message is displayed on the status pane, such as during project build, the Status pane will automatically be opened so that the error message can be seen.

5.4 Status Bar

The status bar located at the bottom of the main window displays the following:

Message area	Displays the syntax error for the current line and system messages.
Operation Mode status	Indicates the controller operation mode.
Emergency Stop status	Indicates if emergency stop is active.
Safeguard status	Indicates if one or more safeguard circuits is open.
Error status	Indicates if the controller is in the error state. Put the mouse cursor over the Error status area to see the warning message.
Warning status	Indicates if there is a warning. Put the mouse cursor over the Warning status area to see the warning message.
Current robot	Displays the currently selected robot number, name, type number, and the dry run status.
Tasks running status	Indicates that one or more tasks are running.
Current Line and Column	When a program editor window is active, the current line and column are displayed.
INS / OVR status	Indicates insert or overwrite mode.


5.5 Online Help

EPSON RC+ 7.0 has an extensive context sensitive help system.


There are several methods to get help.

- Select [Contents] from the [Help] menu to browse help topics.
- Select [Index] from the [Help] menu to enter the name of a specific topic.
- Select [Search] from the Help Menu to search for a specific topic.
- When editing programs, press F1 with the caret in the keyword of interest.

When a dialog is open, press F1 or click the Help button. For dialogs, the Help button is located in the window title bar on the right side and is shown as a question mark icon as shown below.



For MDI child windows, the Help button is located on the main toolbar and is also shown as a question mark icon as shown below.




5.6 [File] Menu

The EPSON RC+ 7.0 File Menu includes commands for managing and printing files in the current project.


5.6.1 New Command (File Menu)

Shortcuts

Toolbar: 

Keys: Ctrl + N


The New command is used to add new files to the current project. When the New command is selected, the New File dialog is opened.



Item	Description
File Name	Enter a name for the new file in this box. If you supply a valid file extension, the File Type selection will change to match the extension. For a file name, two byte characters such as Japanese, Chinese characters are not allowed. Up to 24 characters can be input.
File Type	Use this dropdown list to select Program, Include or Point file.
Existing Files	Shows the files for the selected type currently in the Project folder.
OK	Click OK when you are ready to create the new file.
Cancel	Cancels the operation.

5.6.2 Open Command (File Menu)


Shortcuts

Toolbar: 

Keys: Ctrl + O

Open one or more files in the current project for editing. You can open program files, include files, or point files.

If there is a file in the current project folder (as shown in the Edit Project dialog box) and the file is not in the current project, you will not be able to open the file. You must add the file to the project before you can open it. This also applies to include files and point files.



Item	Description
Program	Select this radio button to show a list of program files in the current project.
Include	Select this radio button to show a list of include files in the current project.
Points	Select this radio button to show a list of point files in the current project.
Select file to open	Click on the file name you want to open. You can select more than one file by using the Ctrl key or Shift key. The Ctrl key allows you to select or deselect any file. The Shift key allows you to select a group of files.
Open	Opens the selected file(s).
Cancel	Cancels the open operation.



You can also double click on a file name in the [Select file to open] list box to open the file without having to choose the <OK> button.

5.6.3 Close Command (File Menu)

Shortcuts

Keys: Ctrl + D

Close the currently active window.

Any of the windows can be closed with this command: Programs, Include files, Point files, Command Window, Run window, I/O Label Editor, user errors.



You can also close a window or dialog box by double clicking on the control box button located in the upper left corner of the window or dialog box.

5.6.4 Save Command (File Menu)

Shortcuts


Keys: Ctrl + S

The [Save] command writes the current file to disk. The current file can be a program file, include file, points file, I/O label editor, etc. This command is disabled if the current file does not need to be saved.

5.6.5 Save As Command (File Menu)

Save the program, include file, or point file in the currently active window with a new file name. The original file will be removed from the project but will remain on the disk. The new name will be used throughout the current project in place of the old name.

If you use [Save As] on an include file, you must rename the file in each of your #include statements that refer to it. For a file name, two byte characters such as Japanese, Chinese characters are not allowed.



5.6.6 Restore Command (File Menu)


Restores the currently active program, include file, I/O labels, user errors, or point files from disk.

Use this function to change a document to the state it was in since last saved.

You will be prompted to confirm this operation.

5.6.7 Rename Command (File Menu)

Use [Rename] to change the name of the program, include file, or point file you are currently editing.



To rename a file

- Click anywhere on the program window
- Select the Open command from the File Menu
- Select the Window from the Window Menu
- Select from the Window Menu list

Select Rename from the File Menu. Type in a new name for the file and click <OK>.

The new file name cannot be the same as the existing files. You will get an error message if you enter a new name that is already being used.


If you use [Rename] on an include file, you must rename the file in each of your #include statements that refer to it.

For a file name, two byte characters such as Japanese, Chinese characters are not allowed.

5.6.8 Delete Command (File Menu)

This command allows you to delete a file in the current project folder. You can delete program files, include files, and point files.

The file does not have to be registered in the project to delete.




Item	Description
Select file to delete	Click on the file name you want to delete. This file list displays all .PRG, .INC, and .PTS files in the current project folder.
Delete	Deletes the selected file. You will be prompted with a confirmation message before the file is deleted. If the file is currently open, it will be closed and removed from the current project before it is deleted from disk.
Cancel	Cancels the delete operation.

5.6.9 Import Command (File Menu)

Import a file from other EPSON RC+ 7.0 projects. Use this command to import program files, include files, point files, I/O labels, user errors, and macros.

- Program file names for importing must have a .PRG extension.
- Include file names for importing must have a .INC extension.
- Point file names for importing must have a .PTS extension.
- I/O labels must have the file name IOLABEL.DAT
- User errors must have the file name USERERRORS.DAT.
- Macros must have the .MAC extension.



To import a file


1. Select the file type from the [File Type] list box.
2. Navigate to the file you want to import.
3. Click <Open> to continue. If a file name is already used in the project folder, you will be prompted to confirm overwrite. The file will then be copied to the current project's folder.



If you need to import files from previous versions of EPSON RC+ or from SPEL for Windows 2.0, you must first import the project using [Project]-[Import], which converts the point files and label files into EPSON RC+ 7.0 formats. Then you can use File Import to import the desired files.

5.6.10 Print Command (File Menu)


Shortcuts

Toolbar: 

Keys: Ctrl + P

This command opens the Print dialog box. You can print programs, include files, point files, I/O labels, and user errors. Also you can print out a project summary.

Each document is printed with a header that includes the project name, product name, file name, date and time, and page number.



Item	Description
Select items to print	Check the items in the tree that you would like to print out.
Project Summary	Select this check box to print a summary of the programs and points used in the current project.
Program Files	Select this check box to print all program files, or click on the + button to view all program files and check the ones you want printed.
Include Files	Select this check box to print all include files, or click on the + button to view all include files and check the ones you want printed. This check box is not shown if there are no include files in the current project.
Robot Points	Select this check box to print all point files, or click on the + button to view all point files and check the ones you want printed.
Input Output Labels	Select this check box to print a listing of the all of the I/O labels used in the project.
User Errors	Prints a listing of all user errors for the current project. If either the label or message is non-blank, then the error definition will be printed.
Print	Prints the selected files. This button will be dimmed if nothing is selected to be printed.
Preview	Preview the selected files before printing. This button will be dimmed if nothing is selected to be printed.
Font...	Opens a dialog for selecting the printer font. The selected font is saved for subsequent printing.
Cancel	Closes the dialog box without printing anything.

5.6.11 Exit Command (File Menu)

Shortcuts

Keys: Alt + F4

Exits from EPSON RC+ 7.0.

If you are running a program from the Run Window and the control device is PC, you will see a message that a program is running and you will not be allowed to exit. You must stop all tasks first before you can exit.

If there are any open program files, include files, point files, I/O labels, or user point files that have not been saved, for each file you will be prompted to save it with Yes, No, or Cancel.


If you select <Yes>, then the file will be saved.

If you select <No>, then the program will exit without saving the files.

If you select <Cancel>, it will return to the EPSON RC+ 7.0 main window.

If the display of the dialog at EPSON RC+ 7.0 shutdown is enabled, the following dialog will be displayed at the shutdown and you can select a termination process.

For details on the shutdown dialog, refer to 5.12.3 [Preferences] Command (Setup Menu).



Item	Description
Exit EPSON RC+	Exits the EPSON RC+ 7.0.
Shutdown EPSON RC+ and Windows	Exits the EPSON RC+ 7.0 and shutdown the Windows.
Shutdown EPSON RC+ and Restart Windows	Exits the EPSON RC+ 7.0 and reboot the Windows.
OK	Executes the selected operation.
Cancel	Cancels the operation and close the dialog.

5.7 [Edit] Menu



TIP

The EPSON RC+ 7.0 <Edit> menu includes commands for editing files.

You can also access the <Edit> menu by right-clicking anywhere in a program editor window.

5.7.1 [Undo] Command (Edit Menu)

Shortcuts

Keys: Ctrl + Z

Undo the changes to the currently active program since it was open.

5.7.2 [Redo] Command (Edit Menu)


Shortcuts

Keys: Ctrl+Y

Redo the previous undo.

5.7.3 [Cut] Command (Edit Menu)

Shortcuts


Toolbar: 

Keys: Ctrl + X

Copies the current selection into the Clipboard and then deletes the selection.

5.7.4 [Copy] Command (Edit Menu)

Shortcuts


Toolbar: 

Keys: Ctrl + C

Copies the current selection into the Clipboard.

5.7.5 [Paste] Command (Edit Menu)

Shortcuts

Toolbar: 

Keys: Ctrl + V

Puts the contents of the Clipboard into the currently active document starting at the insertion point.


5.7.6 [Find] Command (Edit Menu)

Shortcuts

Keys: Ctrl + F

Find a text string in the current program or all programs in the project.

The first time you execute this function, the dialog box will be centered over the main window. If you reposition it, then the next time Find is executed, the dialog will appear where you last positioned it.



Item	Description
Find What	Type the text you want to search for. If any text was selected when you execute the Find command, it will be displayed here. When executing the Find with a text string selected, selected text will be displayed. If no text was selected, then the text from the last Find will be displayed. You are limited to one line of text. If selecting more than one line before executing Find, the search will not start.
Current File	Searches only in the current program file and include file.
All Files	Searches all files in the project.
Whole Word	Searches for the full word by itself and not as part of another word.
Match Case	Text must also match lower and upper case in order to be found.
Find	Starts the search. If the text is found in a file that is not open, then the file will be opened to display. This button will be dimmed if nothing is entered to be searched.
Find All	Search for all occurrences and list the results in the Status pane. Each result shows the file name, line number, and line where the text was found. You can then double click on a result to open the file where the text was found. The Find & Replace dialog will close after the results are displayed. This button will be dimmed if nothing is entered to be searched.
Close	Closes the dialog box.

5.7.7 [Find Next] Command (Edit Menu)

Shortcuts

Key: F3


Find the next occurrence of the search text specified in the last Find command.

5.7.8 [Replace] Command (Edit Menu)

Shortcuts

Keys: Ctrl + R

Search for a text string and replace it with new text. The first time you execute this function, the dialog box will be centered over the main window. If you reposition it, then the next time Replace is executed, the dialog will appear where you last positioned it.



Item	Description
Find What	Type the text you want to search for. If any text was selected when you execute the Replace command, it will be displayed here. If no text was selected, then the text from the last Find will be displayed.
Replace With	Enter the replacement text here. The replacement text can be empty.
Current File	Searches only in the current program file and include file.
All Files	Searches all files in the project.
Whole Word	Searches for the full word by itself and not as part of another word.
Match Case	Text must also match lower and upper case in order to be found.
Find	Finds the next occurrence.
Replace	If already found, replaces the current find, otherwise searches for the next occurrence.
Replace All	Replaces all occurrences.
Close	Closes the dialog box.

5.7.9 [Select All] Command (Edit Menu)

Shortcuts

Keys: Ctrl + A

Selects the entire program file, include file, point file, I/O labels, or user errors. You can then execute Cut or Copy.

5.7.10 [Indent] Command (Edit Menu)

Shortcuts

Key: Tab

Move the selected line one tab to the right.

5.7.11 [Outdent] Command (Edit Menu)

Shortcuts

Keys: Shift + Tab

Move the selected line one tab to the left.

5.7.12 [Comment Block] Command (Edit Menu)

Comments out the selected block of lines by adding the comment character to the beginning of each line.

To use, select one or more lines to be commented. Then :

- Select Comment Block from the Edit Menu.
- Right click and select Comment Block from the Context Menu.

A comment character will be added to the beginning of each of the selected lines.

5.7.13 [Uncomment Block] Command (Edit Menu)

Removes leading comment character from the selected block of lines.

To use, select one or more lines to be uncommented. Then:

- Select Uncomment Block from the Edit Menu.
- Right click and select Uncomment Block from the Context Menu.

The first comment character from each of the selected lines will be removed.

5.7.14 [Go To Definition] Command (Edit Menu)

Opens the window and sets the line where a function, variable, macro, point label, I/O label, or user error label is defined.

To use,

- Click on an identifier in a program window, and select Go To Definition from the Edit Menu.
- Right click on the identifier, and select Go To Definition from the Context Menu.

Identifier type	Display
Function name or variable	Program window where a function name or variable is declared.
Pont label	Point file which a label is defined.
I/O label	I/O label editor which a label is defined.
User error label	User error which a label is defined.

5.8 [View] Menu

The EPSON RC+ 7.0 View Menu includes commands for opening the Project Explorer and Status window. In addition, there is a command for viewing the system history.

5.8.1 [Project Explorer] Command (View Menu)

If you have closed the [Project Explorer] pane, you can open it by using this command.

For details, refer to *5.2 Project Explorer Pane*.

5.8.2 Status Window Command (View Menu)


If you have closed the [Status Window] pane, you can open it by using this command.

For details, refer to *5.3 Status Window Pane*.

5.8.3 System History Command (View Menu)

This command opens the System History window. This window shows events, errors, and warnings that have been logged in the current controller's system history.

The data can be sorted by clicking on any column header. To sort multiple columns, hold down the shift key and click on multiple columns headers.




Item	Description
Data To Display	Select which data you would like to view. Choices are All, Events, Errors, and Warnings.
From / To	Select the dates you want to view data from. When the window is first opened, these are automatically set to the first and last dates in the history data.
Message Contains	Type in text to be found in the error message. After typing in the text, click the Refresh button.
Time Zone	Select a time zone. Time of event, warning, and error occurrences are displayed according to the selected time zone.
Refresh	Click this button to reload the data from the controller.
Type Event	Information for operation and mode change.
Warning	Program can be executed continuously, however, needs countermeasure.
Error	Error occurred in the program or the Robot.
Number	For details of the number, refer to <i>SPEL⁺ Error Message</i> in the <i>SPEL⁺ Language Reference</i> .
Message	
Function and Line number	Function name and the line number are displayed when error occurred while executing a program.
Robot and axis number	Robot and the axis number are displayed when Robot error occurred.
Task number	Task number of the task with error is displayed when error occurred while executing the program. "0" is displayed for others.
Additional information 1 and 2	More details are displayed for some errors. For details, refer to <i>SPEL⁺ Error Message</i> in the <i>SPEL⁺ Language Reference</i> .

5.9 [Project] Menu

The EPSON RC+ 7.0 Project Menu includes commands for managing and building projects.

5.9.1 [New] Command (Project Menu)


The New command is used to create a new EPSON RC+ 7.0 project. Projects can be on any disk drive on the system. They are stored in the \EpsonRC70\Projects folder on the selected drive. Subfolder can also be created.




Item	Description
Project Name	Type in a new name for the project. The name can include alphanumeric characters along with underscores. For a project name, two byte characters such as Japanese, Chinese characters are not allowed.
Template	Select a project template. The new project will be a copy of the template project.
Select Drive	Select the desired disk drive for the new project.
Select Project Folder	This is a list of folders and projects on the selected drive. If you click on a name in this list, it will be displayed in the New Project Name text box. You can then edit the name, or you can create a new project with the same name as one that has already been created. In the later case, you will be prompted to overwrite the old project if it is in the same folder.
New Folder	Creates a new folder in the currently selected folder.
OK	Creates the new project.
Cancel	Aborts creating a new project.

5.9.2 [Open] Command (Project Menu)

Use this command to open an EPSON RC+ 7.0 project. When the project is opened, the previous project is closed. You will be prompted to save changes.



Item	Description
Select Drive	Select the desired disk drive for the project you want to open.
Select Project to Open	Select a project name from the list box. To open a folder, double click on the folder or click the + box located to the left of the folder.
Read Only	If you set this check box and open a project, you cannot edit the program file, include file, point file, I/O label, and user error.
Open	Opens the selected project.
Cancel	Cancels the operation.
Project Info	Displays general project properties for the selected project. To view project information, first select a project in the list, then click the <Project Info> button.




Project information for a project can be changed by selecting [Properties] from the [Project] menu after opening the project.

5.9.3 Recent Projects Submenu (Project Menu)

The Recent Projects submenu contains up to eight of the most recently used projects.

When you select a project in the menu, the current project is closed and the selected project is opened the same as if you used the [Open] command from the [Project] menu.



5.9.4 [Close] Command (Project Menu)


Use the [Close] command to close the current project. Several menu and toolbar commands will be disabled after the project is closed.

5.9.5 [Edit] Command (Project Menu)

The [Edit] command is used to define which program files, include files, and point files are to be used in the current project.

The [Project Files] contains a list of files in the current project folder. You can select which files to view from the [File Type] list box.

The [Project Make] contains a project make tree that includes program files, include files, and point files.



The files shown in the file list are in the current project disk directory. Before you can use a file in the project, you must put it into the project make tree using the <Add> button.

To create a new program

1. Type the name of program file in the [File Name] text box in the Program Files section. Add the PRG extension to the file name. For a file name, two byte characters such as Japanese, Chinese characters are not allowed.
2. Click the <Add> button. You will be prompted to create a new file. Answer <Yes> to create the file and put it in Program Files folder in the project make tree.

To add an existing program file

1. Select the Program in the [File Type] list box.
2. Select the program file name you want to add to the project from the list box.
3. Click the <Add> button, or double click on the program file name in the file list box.

The file will be added to the Program Files folder in the project make tree.

To create a new include file

1. Type the name of the include file in the [File Name] text box.
Add the INC extension to the file name. The name of the include file can also be the same name as a program. For a file name, two byte characters such as Japanese, Chinese characters are not allowed.
2. Click the <Add> button. You will get a message asking if it is okay to create the new file. Click <Yes> to create the file and put it in the Include Files folder in the project make tree.

To add an existing include file to the project

1. Select Include in the <File Type> list box.
2. Select the include file name you want to add to the project from the list box.
3. Click the <Add> button, or
double click on the include file name in the file list box. The file will be added to the list of include files of [Project Build] tree.

To add a new point file

1. Type the name of the point file you want to create into the [File Name] text box.
Add the PTS extension. For a project name, two byte characters such as Japanese, Chinese characters are not allowed.
2. Select the robot folder you want to register from the Robot Points folder in the [Project Build] tree.
3. Click the <Add> button. You will be prompted to create a new file. Click <Yes> to create the file and put it in the selected robot of the Robot Points folder.

To add an existing point file to the project

1. Select Points from the [File Type] list box.
2. Select the robot folder you want to register from the Robot Points folder in the [Project Build] tree.
3. Select the point file name you want to add to the project from the list.
4. Click the <Add> button. The file will be put in the selected robot of the Robot Points folder.

To remove a program file, include file, or point file

1. Select the file you want to remove in the [Project Build] tree.
2. Click the <Remove> button to remove the file from the [Project Build]. The file is not deleted from the project folder, so you will still see the file in the file list.

To add a new robot

Click the <New Robot> button. A robot will be added to the Robot Points folder in the [Project Build] tree.

To set a default point file

1. Select a point file to set as the default from each robot of Robot Points folder in the [Project Build] tree.
2. Click the <Set as default> button. The file will be set as the default of the registered robot.




The common point file is a point file that is available for all robots on the controller. To use this point file, you need to load it from the SPEL⁺ program to the robot using LoadPoints command.

The default point file is a point file that is automatically loaded to a robot with the project load. Each robot can have one point file as the default.


5.9.6 [Save] Command (Project Menu)

Shortcuts

Toolbar: 


This command saves the active program file, include file, point file, I/O labels, or user errors. This menu selection will be dimmed if nothing needs to be saved.



It's a good idea to save files frequently while you are editing project files. Just click the <Save all files> button  on the toolbar to save all of your files.

5.9.7 [Save As] Command (Project Menu)


Saves all files in the current project to a new drive and/or project name. The current project will be preserved.



Item	Description
New Project Name	Type in a new name for the project. The name can include alphanumeric characters along with underscores but cannot include two byte characters such as Japanese, Chinese characters. The maximum number of characters is 24. You can use the same name as the current project if you select a drive and folder that is not the same as the current project folder and the folder drive.
New Project Drive	Drives for the new project location.
Select Project Folder	Click on the desired folder for the project.
New Folder	Click this button to create a new folder under the Projects folder.
OK	Saves the project using the new name and location.
Cancel	Cancels the operation.

5.9.8 [Rename] Command (Project Menu)

This command renames the current project. The project folder and all associated project files are also renamed.



Item	Description
New Project Name	Type in a new name for the project. The name can include alphanumeric characters along with underscores but cannot include two byte characters such as Japanese, Chinese characters.
Existing Project	This list box shows other projects on the selected drive. The new name you choose cannot be one of the names in this list.
OK	Renames the project.
Cancel	Cancels the operation.

5.9.9 [Import] Command (Project Menu)

The Project Menu Import Command uses a wizard to import projects from a PC, the current controller, or a controller status folder.

When a project is imported, the files are copied to a new project folder, so the original project is not changed.




If the project to be imported is an EPSON RC+ 3.x / 4.x / 5.x /6.x project or a SPEL for Windows 2.0 project, the files are converted to EPSON RC+ 7.0 format.

The sections below have instructions for importing a project from each type of source location.

Importing a PC project


Follow these steps to import a project from a PC:

1. Select Import from the [Project] menu to open the [Import Project] dialog box.
2. Select <PC> and click <Next>.




3. Select the project type. You can select from the following:

- EPSON RC+ 7.0
- EPSON RC+ 3.x / 4.x / 5.x / 6.x
- SPEL for Windows 2.0




When project for EPSON RC+ 3.x / 4.x / 5.x /6.x or SPEL for Windows 2.0 is imported, the project is converted to project for EPSON RC+ 7.0 by automatic processing. For details, refer to *Appendix A: Automatic Processing of Project Import*.

4. Select the drive. After you select the project type and drive, the project list will be updated to show the projects available for import. Select the project to import in the list and click <Next>.
5. The new project name is set to the name of the imported project. You can modify the destination project name if desired. Select the destination drive and project folder, then click <Next>.



6. Verify the import source, import project, and destination project. Check [Open Destination Project After Import] if you want the project to open after import.




7. Click the <Import> button. If the destination project already exists, you will be asked if you want to overwrite it.


Importing a Controller project

Follow these steps to import a project from a controller:


1. Select Import from the [Project] menu to open the [Import Project] dialog box.
2. Select <Controller> and click <Next>.



3. The new project name is set to the name of the current project in the controller. You can modify the new project name if desired. Select the destination drive and project folder, then click <Next>.



4. Verify the import source, import project, and destination project. Check [Open Destination Project After Import] if you want the project to open after import.



5. Click the <Import> button. If the destination project already exists, you will be asked if you want to overwrite it.
6. The project in the destination project will be built.

Importing a Controller Status project


NOTE




The projects using Vision Guide cannot be imported from the Controller Status Folder.

Follow these steps to import a project from a Controller Status Folder:


1. Select [Import] from the [Project] menu to open the [Import Project] dialog box.
2. Select <Controller Status Folder> and click [Next].




3. Select a controller status folder and click <OK>.



4. The new project name is set to the project found in the controller status folder. You can modify the new project name if desired. Select the destination drive and folder, then click <Next>.



5. Verify the import source, import project, and destination project. Check [Open Destination Project After Import] if you want the project to open after import.



6. Click the <Import> button. If the destination project already exists, you will be asked if you want to overwrite it.

5.9.10 [Export] Command (Project Menu)

The Project Menu Export Command uses a wizard to export projects to EPSON RC+ 6.0 projects.


When a project is exported, the files are copied to a new project folder, so the original project is not changed.




SPEL+ commands and syntax added to the EPSON RC+ 7.0 are not supported by EPSON RC+ 6.0. It is recommended to change the compiler version according to the version of your controller and check the compatibility before exporting projects. For details, refer to *[Project]-[Properties]-[Compiler] Page* in 5.9.15 *[Properties] Command (Project Menu)*.

Follow these steps to export a project:


1. Select EPSON RC+ 7.0 menu-[Project]-[Export] to display the [Export Project] dialog.
2. Select a drive. A project list will be refreshed and exportable projects will be displayed. Select a project you want to export from the list and click <Next> button.



3. Name of a new project is set to the name of the exported project. The name of the new project can be changed. Select the destination drive and project folder. Then, click <Next>.



4. Confirm the export source and destination.




5. Click <Export>. If the destination already exists, you will be asked whether or not to overwrite the project.

5.9.11 [Copy] Command (Project Menu)

The [Copy] command copies all files in the current project to a specified drive, folder, and project name. You can use the current project name for the destination name if you select a new drive or folder. You can also specify a new name for the destination project.


You should use the [Copy] command to make backup copies of your project on a regular basis.



Item	Description
Destination Project Name	Type in a name for the new copy of the project. The name can include alphanumeric characters along with underscores but cannot include two byte characters such as Japanese, Chinese characters. The maximum number of characters is 24. You can use the same name as the current project if you select a drive and folder that is not the same as the current project's drive and folder.
Destination Drive	Drives for the project copy.
OK	Performs the copy process.
Cancel	Cancels the operation.

5.9.12 [Delete] Command (Project Menu)

This command deletes an entire project from a PC disk. All files in the project folder will be destroyed.



Item	Description
Project Drive	Select drive for the project to delete.
Project To Delete	Select a project to delete from the list.
Delete	Delete the project. You will be prompted to confirm the operation.
Cancel	Cancel the operation.

5.9.13 [Build] Command (Project Menu)

Shortcuts

Toolbar:  Keys: Ctrl + B

This command builds the current project so that it can be executed. The Build command does the minimum amount of work required to bring the project up to date in the robot controller. For example, if a change was made to one program file in the project, then Build will compile the changed file, link it with the remaining object files (if they exist), and send the new files to the controller.

When sending the required files to the compact vision, make sure to rebuild not build.

During the build process, the status window displays each step of the build. If there are any errors, they will be displayed on the status window.

5.9.14 [Rebuild] Command (Project Menu)

Shortcuts

Keys: Ctrl + Shift + B


Rebuilds the entire current projects. All program files are re-compiled, linked, and sent to the controller. All point files in the project are sent to the controller.

If using the camera of the compact vision, rebuild to send the required files to the compact vision.

5.9.15 [Properties] Command (Project Menu)

[Project]-[Properties]-[General] Page

Use this page to view and edit general properties for the current project. All project property settings are stored in the project file, which is also stored in the controller during project build.



Item	Description
Name	The name of the current project.
Created	Date and time when the project was created.
Last Modified	Date and time when the project was last modified.
Version	User version number of the project. You can type any text here.
Description	A description of the project. You can type any text here.
Notes	Any project notes can be entered into this section.
Apply	Set current values after changes have been made.
Restore	Revert back to previous values.
Close	Close the Project Properties dialog.




When the [Open Project] dialog is used, clicking the <Project Info> button will open a dialog that contains the general project properties entered on this page.

[Project]-[Properties]-[Source Files In Controller] Page

This page allows you to select which source files will be stored in the controller during project build.

After changes are applied, the next project build will clear the project in the controller and perform a rebuild.




Item	Description
Select Source Files To Store in Controller	This is a list of the source files in the project. Select which source files you want to have stored in the controller.
Apply	Set current values after changes have been made.
Restore	Reverts back to the previous values.
Close	Closes the [Project Properties] dialog.

[Project]-[Properties]-[Encrypted Files] Page

This page allows you to encrypt files in the current project.


For details on using encrypted files, refer to section 7.8 *Using Encrypted Files*.



CAUTION

■ **USE EXTREME CAUTION!**


Keep a record of the password(s) used for encryption in a safe place. Once a file is encrypted, it can only be opened with the password you enter. If you forget the password, the file contents **CANNOT BE RECOVERED**



Item	Description
Normal Files	This is a list of the source files in the project that are not encrypted. Select which source files you want to encrypt.
Encrypted Files	This is a list of the source files in the project that are encrypted. Select which source files you want to decrypt.
Encrypt >>	Encrypts the files selected in the [Normal files] list. When this button is clicked, you will be prompted for a password that will be used to access these encrypted files.
<<Decrypt	Decrypts the files selected in the [Encrypted files] list. When this button is clicked, you will be prompted for the password that was used to encrypt the files.
Apply	Set current values after changes have been made.
Restore	Reverts back to the previous values.
Close	Closes the [Project Properties] dialog box.

[Project]-[Properties]-[Compiler] Page


This page allows you to configure the compiler settings.



Item	Description
Compiler Version	<p>[Default] is the normal setting.</p> <p>When the projects cannot be built because new SPEL+ language keywords have been added that conflict with your variable names, you can select a previous version to build the projects. Specify the controller version that compiles the project.</p>
Strict Compile	<p>Checks the Boolean type strictly.</p> <p>If the program contains following descriptions, an error will occur.</p> <ul style="list-style-type: none"> Boolean variables are assigned to other numerical types Specifies a wait time to Wait Compares Boolean types
Globals must be declared in each file used	<p>Checks the Global variables (including Global Preserve variables) for each file.</p> <p>When this item is checked, you must declare Global variables in each file in which they are used, otherwise an error will occur at build time.</p>
TIP	<p>Enabling this item reduces a build time of a project which uses many Global variables.</p>
Apply	Sets current values after changes have been made.
Restore	Reverts back to the previous values.
Close	Closes the [Project Properties] dialog box.


[Project]-[Properties]-[Operator Settings]-[Operator Window]-[General] Page

This page allows you to configure the general settings for the Operator Window.



Item	Description
Window Title	Type in the title that you want to appear at the top of the operator window.
Window Size	Choose Normal or Maximized.
Font	Click on the button to open the fonts dialog. Choose the font you desire for the operator window. The current font name and size is displayed next to the button.
Vision Display	If this check box is set, the Vision Guide image will be displayed in the operator window.
Restore	Reverts back to the previous values.
Close	Closes the [Project Properties] dialog box.

[Project]-[Properties]-[Operator Settings]-[Operator Window]-[Controls] Page
 This page allows you to configure the controls for the Operator Window.



Item	Description
Pause and Continue	Check this box if you want the <Pause> and <Continue> buttons to be displayed. This will allow the operator to pause and continue from the operator window.
I/O Monitor	Check this box if you want the <I/O Monitor> button to be displayed. This will allow the operator to view input and output status.
Robot Manager	Check this box if you want the <Robot Manager> button to be displayed. This will allow the operator to open the Robot Manager from the operator window.
System History	If this check box is set, the <System History> button will appear. You can check the system history.
Apply	Set current values after changes have been made.
Restore	Reverts back to the previous values.
Close	Closes the [Project Properties] dialog.


Program Selections Details

Each project can have up to 64 programs that can be started from the Operator Window. The programs are named main, main1, main2, ... main63. Each program has an associated startup function using the same name as the program (main, main1, main2...main63).

In the program selections grid, you can define a friendly name for each of the 64 programs. You can also define which selections will be displayed in the Operator Window program list by checking the Enable checkbox.


[Project]-[Properties]-[Operator Settings]-[Robot Manager] Page

Use this page to configure the Robot Manager for operators.



Item	Description
Page and options enabled for operators	Check the pages that you want the operator to have access to when the Robot Manager is displayed from the operator window. In some pages, there are additional options.
Allow SFree / SLock	Allows the operator to free or lock joints from the [Control Panel] page.
Allow Home	Allows the operator to home the robot from the [Control Panel] page.
Allow Teach	Allows the operator to teach points from the [Jog & Teach] page.
Teach only defined points	Only defined points are shown in the point list on the [Jog & Teach] page.
Prompt for new point information	When the operator teaches a new point, a dialog will be displayed for entering the point label and description.
Allow Motion Commands	Allows the operator to execute motion commands from the [Jog & Teach] page.
Allow Edit	Allows the operator to edit point data on the [Points] page.
Allow Delete	Allows the operator to delete points on the [Points] page.
Apply	Set current values after changes have been made.
Restore	Reverts back to the previous values.
Close	Closes the [Project Properties] dialog box.

[Project]-[Properties]-[Operator Settings]-[I/O Monitor] Page
 Use this page to configure the I/O Monitor for operators.




Item	Description
Select views for operators	Configures the I/O views that operators use when opening the [I/O Monitor] from the [Operator Window]. You can configure the custom views.
Allow I/O status change for operator	Check this box if you want to allow operators to turn on or off the inputs and outputs.
Apply	Set current values after changes have been made.
Restore	Reverts back to the previous values.
Close	Closes the [Project Properties] dialog box.

[Project]-[Properties]-[Vision]


Project Camera Mapping

You can map project cameras to system cameras.

Project camera is a camera specified by Camera property of vision sequence or calibration.



System camera is a camera configured on System Configuration of RC+.




This function is useful when you use multiple projects on the same PC and refer to the different system camera numbers from the each project camera.

By default, project cameras are mapped one to one with system cameras.

When a project is opened, the cameras used in the project are automatically mapped to system cameras. If one or more cameras cannot be mapped, the [Resolve Camera Configuration] dialog box is displayed.

For more details, refer to the following manual.

Vision Guide Hardware & Setup System Cameras and Project Cameras




Item	Description
Project Camera	The project camera number to be mapped.
System Camera	Select the system camera to use for the project camera.
Apply	Set current values after changes have been made.
Restore	Reverts back to the previous values.
Close	Closes the [Project Properties] dialog box.

Mapping of a project camera:


For example, let's assume four system cameras are set in RC+ that has two projects; A and B as shown in the table below.

System camera	Model
1	NS1044BU
2	NS4133CU
3	acA1600-60gm
4	acA2500-14gm

To map a camera for the project A, select [Project]-[Properties]-[Vision] with opening the project A. When setting NS1044BU as a camera 1 that is used in this project, map Project Camera 1 to System Camera 1. (set Project Camera 2, 3, and 4 in the same step.)



To map a camera for the project B, select [Project]-[Properties]-[Vision] with opening the project B. When setting acA1600-60gm as camera 1 that is used in this project, map Project Camera 1 to System Camera 3. (set Project Camera 2, 3, and 4 in the same step.)




Network Camera Projects

The Compact Vision systems can manage two vision projects simultaneously.

Each vision project can be used by one Controller, so two Controllers can use the same Compact Vision unit.

In this page, you can configure the vision project number of the Compact Vision cameras used for this project.

“Project 1” is used by default.



Item	Description
System Camera	Select the system camera to use for the project camera.
Project #	Select the vision project number.
Network Camera Project Numbers	
Apply	Set current values after changes have been made.
Restore	Reverts back to the previous values.
Close	Closes the [Project Properties] dialog box.

Setting of a network camera project:


For example, let's assume there are two controllers, two projects, and a CV. Four cameras are connected to the CV and they are set as four system cameras to RC+ as shown in the table below.

System camera	Model
1	NS1044BU
2	NS4133CU
3	acA1600-60gm
4	acA2500-14gm


The two projects controlled by the compact vision must use different cameras.

In here, the project A uses the system camera 1 and 2, and the project B uses the system camera 3 and 4.

To set network camera project for the project A, select [Project]-[Properties]-[Vision] with opening the project A. Set Project # for the system cameras 1 and 2 that is used in this project to 1 as shown below. (Project # for the system cameras 3 and 4 is set to 1, however, Project # for a camera that is not used in a project is optional.)




To set network camera project for the project B, select [Project]-[Properties]-[Vision] with opening the project B. Set Project # for the system cameras 3 and 4 that is used in this project to 2 as shown below. (Project # for the system cameras 1 and 2 is set to 2, however, Project # for a camera that is not used in a project is optional.)



Now, the two projects; A and B can be used by the CV simultaneously .

[Project]-[Properties]-[GUI Builder]

On this page, you can specify the startup form for GUI Builder and also set the value of the help file used in your project.



Item	Description
Startup Form	Select the startup form for the current project. If no forms have been created in GUI Builder, then there will be no forms in the list.
Help File	Set help file that will be used by forms in GUI Builder.
Apply	Set current values after changes have been made.
Restore	Reverts back to the previous values.
Close	Closes the [Project Properties] dialog box.

5.10 [Run] Menu

The EPSON RC+ 7.0 [Run] menu includes commands for running and debugging programs.

5.10.1 [Run Window] Command (Run Menu)

Shortcuts

Toolbar:  Key: F5

Opens the [Run] window to run a program.

Before opening the [Run] window, all files will be saved automatically if there are any unsaved files and then the project will be built. If there are any errors during build, the Run window will not be opened.

(If the *Auto File Save* preference is off in [Setup]-[Preferences]-[Workspace], you will be prompted to save all files if there are any unsaved files.)

After the [Run] window opens, you must click the <Start> button to initialize program execution.

For more information, see *7.5.1 Run Window*.

5.10.2 [Operator Window] Command (Run Menu)

Shortcuts

Keys: Shift + F5

Opens the [Operator] window.

Before opening the [Operator] window, all files will be saved automatically if there are any unsaved files and then the project will be built. If there are any errors during build, the [Operator] window will not be opened.

(If the *Auto File Save* preference is off in [Setup]-[Preferences]-[Workspace], you will be prompted to save all files if there are any unsaved files.)

If the project is ready to run (last build was successful), then the [Operator] window will be opened.

For more information, see *7.6 Operator Window*.

5.10.3 [Step Into] Command (Run Menu)


Shortcuts

Toolbar:  Key: F11

Execute the current source line. If the current line is a function, the next step will be the first line in the function.

5.10.4 [Step Over] Command (Run Menu)

Shortcuts

Toolbar:  Key: F10

Execute the current source line. If the current line is a function, the entire function will be executed.

5.10.5 [Walk] Command (Run Menu)

Shortcuts

Key: F12


Execute lines until after the next motion command or output command, depending on the *Walk stops for output commands* preference on the [Setup]-[System Configuration]-[Controller]-[General] page.

5.10.6 [Resume] Command (Run Menu)

Shortcuts

Toolbar:  Key: F7


Opens the [Resume Tasks] dialog box. Use this command to resume one or more halted tasks. This command is available only when one or more tasks are in halt mode.



Item	Description
Select tasks to resume	A list of all currently halted tasks. Click on one or more tasks to resume.
Resume	Click to resume.
Select All	Click to select all of the tasks in the list.
Cancel	Cancel the operation and close the dialog.

5.10.7 [Stop] Command (Run Menu)

Shortcuts

Toolbar: 

Stops all tasks. This command is disabled when no tasks are running.

5.10.8 [Toggle Breakpoint] Command (Run Menu)

Shortcuts

Toolbar:  Key: F9

Sets the selected line as a breakpoint or returns it to normal. When a line is a breakpoint, a breakpoint icon is displayed in the program window left margin.

You can set breakpoints while tasks are running.

If a line cannot be a breakpoint (such as a blank line), then the breakpoint icon will not appear for that line.

5.10.9 [Clear All Breakpoints] Command (Run Menu)

Shortcuts

Keys: Ctrl + Shift + F9


Clears all breakpoints.

5.10.10 [Display Variables] Command (Run Menu)

Shortcuts

Key: F4


Displays a dialog box that shows the values for all variables in robot controller memory.



To change a variable value

1. Check the [Edit] checkbox.
2. Type the new value in the [Value] column. As you type in new values, the text color changes to red, indicating that the value is new and as not been written.
3. Click the <Write> button to save the changes. Click <Read> or uncheck [Edit] to cancel changes and restore the previous values.

When an array is displayed, the first element is shown. You can change which element to view by typing in the desired array subscript and then clicking the <Read> button.



The Preserved page displays the Global Preserve variables. The numbers of used and available bytes for preserved variables are also displayed.

You can save the values of Global Preserve variables in the controller to a file on the PC by clicking the <Save> button. The default file name is "GlobalPreserves.dat".

A "GlobalPreserves.dat" file is also saved by using Backup Controller from the Tools Menu.


You can load the global preserve variables that are stored in the file on the PC by clicking <Load> button.

For module variables, you must select the desired program.

Local variables are not displayed unless one or more tasks have reached a breakpoint or have been halted from the Task Manager. You can view local variables for each function in the call stack for each halted task.

5.10.11 [Call Stack] Command (Run Menu)

The Call Stack dialog displays the function call stack for one task.



The Call Stack command is available when a program window is clicked which contains a function that is currently halted.

The most recent function is at the top of the list, and parent functions are listed afterwards in descending order. The last function is the task function.

Each row in the list shows a program, function, and line number.

You can view the code for any of the function calls in the list by selecting a function, then clicking <Show>. The program window for the function you selected is then displayed and the line of the function call is marked by a yellow arrow in the editor left margin.

5.11 [Tools] Menu

EPSON RC+ 7.0 has several GUI tools to support the system development. All tools can be accessed from the [Tools] menu. Many also have tool bar buttons and hot keys.

The Tools Menu includes the following selections:

- **Robot Manager**
Motor control, Jog & Teach, change robot parameters.
- **Command Window**
Execute SPEL⁺ commands directly.
- **I/O Monitor**
Monitor and change I/O status.
- **Task Manager**
Monitor and control task status.
- **Macros**
Opens the Macro Window.
- **I/O Label Editor**
Edit I/O labels.
- **User Error Editor**
Edit user errors.
- **Controller**
Do maintenance on the controller, such as backup, restore, and export status.

5.11.1 [Robot Manager] Command (Tools Menu)

Shortcuts

Toolbar:  Key: F6

This command opens the [Robot Manager] window. This window contains several tabs that are used to control the robot motors and power, jog the robot and teach points, and view/edit several parameters for the robot.

You can configure how the Robot Manager window can be viewed in the development environment from the [Setup]-[Preferences]-[Robot Manager]-[General] page.

MDI window The Robot Manager is displayed as a child window along with the other child windows inside the EPSON RC+ 7.0 development environment main window.

Dialog The Robot Manager is displayed as a modal dialog which is displayed in the foreground over the development environment main window.



If the screen resolution is less than 1024 x 768, the Robot Manager will always be displayed in dialog mode so it can fit on the screen.

When you switch to the [Robot Manager] window, the robot's speed setting will be set to the speed (high, low) on the Jog & Teach window.

Motion command after the above operation will be executed at this speed. Set the speed again by the commands such as Motor, Speed, and Accel.

[Tools]-[Robot Manager]-[Control Panel] Page

The Control Panel page contains buttons for basic robot operations, such as turning motors on/off and homing the robot. It also shows status for Emergency Stop, Safeguard, Motors, and Power.



Status Indicators


Indicator	Description
Emergency Stop	Indicates if Emergency Stop has occurred. To clear the Emergency Stop status, click <Reset>.
Safeguard	Indicates whether the Safeguard input is on or off.
Motors	Indicates whether the robot motors are on or off.
Power	Indicates whether the robot motor power is high or low.

Controls	Description
Robot	Select a robot.
MOTOR OFF	Turns off all robot motors of the selected robot.
MOTOR ON	Turns on all robot motors of the selected robot.
POWER LOW	Puts the robot servo system in low power mode.
POWER HIGH	Puts the robot servo system in high power mode.
J1 to J4 checkboxes	You can free one or more joints using the checkboxes. Not available for 6-axis robots (including N series).
Free All	Click this button to free all joints from the servo control.
Lock All	Click this button to lock all joints under the servo control.
Reset	Resets the robot servo system and Emergency Stop condition.
Home	Moves the robot to the position specified by the HomeSet command.

[Tools]-[Robot Manager]-[Jog and Teach] Page

The [Jog & Teach] page is primarily used for jogging the robot to a desired position and teaching a point using the current coordinates and orientation.

You can jog the robot in World, Tool, Local, Joint, or ECP modes. You can also execute motion commands.

**Jog Controls**

The [Robot Manager]-[Jog & Teach] page contains several controls, described below.

[Robot]

Select a robot.

[Jogging] Group

This group contains controls for setting jog mode, speed, and jog buttons.

Mode

This dropdown list contains the following choices jog mode.

- World** Jogs the robot along the X, Y, Z axes in the current local, tool, arm, and ECP. For robots with 4 DOF (Cartesian coordinate or SCARA), you can also jog U (roll). For robots with 6 DOF (vertical 6-axis (including N series)), you can jog U (Z axis rotation of the base coordinate system), V (Y axis rotation of the base coordinate system), and W (X axis rotation of the base coordinate system). This is the default setting.
- Tool** Jogs the robot in the coordinate system defined by the current tool.
- Local** Jogs the robot in the coordinate system defined by the current local.
- Joint** Jogs each joint of the robot. A separate set of jog buttons will appear when using joint mode when using non-Cartesian robots.
- ECP** Jogs the robot along the axes of the coordinate system defined by the current external control point. Coordinates are World coordinates.

Speed

The speed for jogging and motion commands can be changed by selecting Low or High. When you start RC+ and the [Jog & Teach] panel is displayed, the speed is set to Low. Jogging is always in low power mode. The speeds and accelerations associated with the jog speed settings are shown below.

SCARA robot RS series

Speed	Jog Method	Speed	Accel	Decel
Low	Continuous World/Tool/ECP XYZ	10 mm/sec	100 mm/sec ²	200 mm/sec ²
	Continuous World/Tool/ECP UVW	2 deg/sec	20 deg/sec ²	40 deg/sec ²
	Continuous Joint	*	10 deg/sec ²	20 deg/sec ²
	Step	1/5 of default PTP speed	Default PTP acceleration	Default PTP deceleration
High	Continuous World/Tool/ECP XYZ	50 mm/sec	100 mm/sec ²	200 mm/sec ²
	Continuous World/Tool/ECP UVW	10 deg/sec	20 deg/sec ²	40 deg/sec ²
	Continuous Joint	*	10 deg/sec ²	20 deg/sec ²
	Step	Default PTP speed	Default PTP acceleration	Default PTP deceleration

* Speed of Continuous Joint depends on the robot model

Vertical 6-axis robot, N series

Speed	Jog Method	Speed	Accel	Decel
Low	Continuous World/Tool/ECP XYZ	10 mm/sec	200 mm/sec ²	400 mm/sec ²
	Continuous World/Tool/ECP UVW	2 deg/sec	20 deg/sec ²	40 deg/sec ²
	Continuous Joint	*	20 deg/sec ²	40 deg/sec ²
	Step	1/5 of default PTP speed	Default PTP acceleration	Default PTP deceleration
High	Continuous World/Tool/ECP XYZ	*	200 mm/sec ²	400 mm/sec ²
	Continuous World/Tool/ECP UVW	15 deg/sec	20 deg/sec ²	40 deg/sec ²
	Continuous Joint	*	20 deg/sec ²	40 deg/sec ²
	Step	Default PTP speed	Default PTP acceleration	Default PTP deceleration

* Speed of Continuous Joint and High speed Continuous XYZ depends on the robot model.

Jog Buttons

Use the jog buttons to jog the robot throughout the work envelope. They can be controlled only by the mouse.

The robot jogs one step at a time as you click the button in either “Long”, “Medium”, or “Short” mode of the Jog Distance. The robot jogs continuously by holding the button down.

To jog continuously without stepping, set the Jog Distance to Continuous. See *How to jog robot* for details

You can change the orientation of the jog buttons to align your PC monitor with the robot from [Setup]-[Preferences]-[Robot Manager]-[Jogging].

The jog buttons are displayed differently depending on the Jog mode. For World, Local, Tool, and ECP jogging, the X, Y, Z, U, V, W buttons appear (V and W are only for 6-axis robots (including N series)). For Joint jogging, the joint buttons labeled J1 - J6 appear.

The X, Y, and Z buttons jog the robot in the Cartesian axis.

The U buttons rotate the Tool coordinate system of the Z axis. (*roll*)

For 6-axis robots (including N series), the V buttons rotate the Tool coordinate system of the Y axis. (*pitch*).

The W buttons rotate the Tool coordinate system of the X axis. (*yaw*).

Local

This drop down list is used to select the current Local for jogging and teaching. Only Locals that have been defined are shown in the list. When you teach a point, the Local point attribute defaults to the current local number.

Tool

This drop down list is used to select the current Tool for jogging and teaching. Only Tools that have been defined are shown in the list.

Arm

This drop down list is used to select the current Arm for jogging and teaching. Only Arms that have been defined are shown in the list. Arms are not used with 6-axis robots (including N series).

ECP

This drop down list is used to select the current ECP for jogging. Only ECPs that have been defined are shown in the list. ECPs are only allowed if the External Control Point option has been activated.

Current Position Group

This group displays the current position of the robot. There are three ways to display position. World displays the current position and tool orientation in the selected local coordinate system, Joint displays the current joint values, and Pulse displays the current encoder pulse count for each joint.

Current Arm Orientation Group

This group displays the current arm orientation.

6-axis robot : Hand orientation, Elbow orientation, wrist orientation,
J1Flag value, J4Flag value, J6Flag value

N : Hand orientation, Elbow orientation, wrist orientation,
J4Flag value, J6Flag value

RS series : Hand orientation, J1Flag value, J2Flag value

Others : Hand orientation

Jog Distance Group

This group contains text boxes that are used to specify the distance that each axis moves when its corresponding jog button is pressed. There are radio buttons for selecting Continuous, Long, Medium, and Short jog distances. When “Continuous” is selected, the robot is jogged in continuous mode and the jog distance text boxes are grayed out. When “Long”, “Medium”, or “Short” are selected, the robot is jogged in step mode for the distance specified in the jog distance text box for the axis being jogged.

To change a jog distance, first select the distance to be changed, then type in the new value.

Distance	Set Value *	Default Value
Short	0 to 10	0.1
Medium	0 to 30	1
Long	More than 0 to 180	10

* If you enter a too large value, an error message appears when you attempt to jog.

When the jog mode is changed, the jog distance units change appropriately between millimeters (mm) and degrees (deg).



When the jog distance is longer than the default, jog distance is reset to default status by rebooting the controller.

[Teach Points] Tab

This tab shows the current point file name and point number.

Use the <Teach> button to register the current robot position.


Use the <Edit> button to select and view the current point in the Points tab.

See *How to teach points* for more information.

Execute Motion Tab

This tab executes motion commands.

Click <Execute> from this group to execute the motion.



When [USE LJM (Least Joint Motion)] checkbox is checked, posture of the manipulator is automatically adjusted to reduce the motion distance.

The default setting is unchecked.

The [Execute Motion] tab can be disabled from [Setup]-[Preferences]-[Robot Manager]-[Jog & Teach].

How to jog


In the upper left hand corner of the [Jog & Teach] page, you will see a control group called Jogging that contains jog buttons. In the World, Local, Tool, and ECP jog modes, the robot is jogged in the Cartesian coordinate system (X, Y, Z). In the Joint jog mode, each robot joint can be jogged separately.

The jog speed is determined by the Speed setting. In step mode, each time you click a jog button, the robot moves along the appropriate axis by the amount specified in the [Jog Distance] control group. In continuous mode, when a jog button held down, the robot moves continuously using linear interpolated motion.



For robots other than the 6-axis robots, the jog motion in step mode is PTP (point to point) motion. It is difficult to predict exact jog motion trajectory. Therefore, be careful that the robot doesn't collide with peripheral equipment and that the robot arms don't collide with the robot itself during jogging.


For the 6-axis robots, the jog motion is CP (Continuous Path) motion. Note that when jogging near the singularity, if you try to pass through the singularity, a warning dialog below will appear.



Click the <OK> button and click the same Jog button again to jog using PTP motion and pass the singularity.

It is difficult to predict exact jog motion trajectory in the PTP motion. Therefore, be careful that the robot doesn't collide with peripheral equipment and that the robot arms don't collide with the robot itself during jogging. Also, if you attempt the other jogs or operations, it cancels the switching to PTP motion. So when jogging near the singularity again, the same warning dialog will appear.

If passing the singularity in the continuous jog motion, the following warning message will appear.



When jogging in continuous mode, if an out of range condition occurs, the robot motors will turn off and an error will be displayed. In this case you must execute a Reset and Motor On from the Control Panel page to continue the jog.

To jog

Select the jog mode: World, Tool, Local, Joint, or ECP.

Select the jog speed: "Low" or "High".

Select "Continuous", "Long", "Medium", or "Short" jog distance. You can type in the desired jog distance when "Continuous" is not selected.

Click on one of the jog buttons with the left mouse button. If you hold the mouse button down, the robot will continue to jog.


When jogging is started, the jog button color changes from yellow to cyan. After jogging is completed, the jog button color returns to yellow.

If you click any jog button during a step jog, the robot will stop.

NOTE You can change the orientation of the jog buttons for the robot by selecting [Preferences]-[Robot Manager]-[Jogging] from the [Setup] menu. This allows you to align the orientation of the jog buttons with the orientation of the robot motion.

NOTE As shown in the illustrations below, when the robot reaches to the limit of the motion range during Continuous Jog motion, the robot stops before the limit of the motion range. Use Step Jog if you want to move the robot to the limit of the motion range. The robot motion stops when the following two conditions are satisfied.

- When the robot's current position becomes "approx. 5 mm or less from the limit of the motion range".
- When the robot operates Continuous Jog motion in the direction reaching to the limit of motion range as shown in the illustrations below.



Jogging in Teach Mode

You can jog and move the robot at slow speed with the safeguard open by using the Teach Pendant.

See the *Robot Controller option: Teach Pendant TP1, TP2, or TP3* manual.


How to teach points

To move the robot to the target point, the point data indicating the robot position is necessary.

Follow these steps to teach points from the [Robot Manager]:

1. Select the point file you are teaching points for from the [Point File] dropdown list box on the [Teach] page.
2. Select the point number you want to teach in the [Points] box.
3. Jog the robot to the desired position or free some or all axes to manually move the robot into position.
4. Click on the <Teach> button. This will save the robot's current position data. If the Prompt for New Point Data preference is active, you will be prompted for a point label and description.

Point labels can include up to 32 alphanumeric characters and underscores. Only alphabets can be used for the first letter. Characters can be upper case or lower case.




(As an alternative to clicking the <Teach> button, on the [Points] tab you can type in the coordinates of the point.)

[Tools]-[Robot Manager]-[Arch] Page

This page allows you to configure the depart Z and approach Z settings in the robot's Arch table. Arch is used for the Jump, Jump3, and Jump3CP motion commands. There are seven different setting pairs in the Arch table.

For details on using Arch, see the *SPEL⁺ Language Reference: Arch Statement*.



To change Arch settings

1. Put the cursor in the Depart Z or Approach Z cell of the row you want to change.
2. Type in the new value.

Press the TAB key to move to the next cell.

Item	Description
Robot	Select a robot.
Apply	Set the current values.
Restore	Reverts back to the previous values.
Defaults	Click the defaults button to display factory default settings.

[Tools]-[Robot Manager]-[Locals] Page

This page allows you to define local coordinate systems for a robot. When the page is selected, the current values are displayed.


A grid is used to display all of the values for the locals you can define. Local “0” is the base coordinate system and cannot be changed from this page.



To change the base coordinate system, use the Base command from the command window. See the SPEL+ Language Reference for more information.

When a local is undefined, then all fields for that local will be blank. When you enter a value in any of the fields for an undefined local, then the remaining fields will be set to zero and the local will be defined when you click the <Apply> button.

For details on using Local, see the *SPEL+ Language Reference: Local Statement*.

**Navigating the grid**

Use the TAB key to move to the next field. Use the arrow keys or the mouse to move to any field.


Item	Description
Local Wizard	Click this button to start the Local Wizard. Follow the instructions for each step to define a local. See details in the next section.
X	The X coordinate of the local origin in the base coordinate system.
Y	The Y coordinate of the local origin in the base coordinate system.
Z	The Z coordinate of the local origin in the base coordinate system.
U	Rotation angle of the local about the base Z axis (roll).
V	Rotation angle of the local about the base Y axis (pitch).
W	Rotation angle of the local about the base X axis (yaw).
Apply	Saves the current changes.
Restore	Reverts back to the previous values.
Clear	Clears all values for the selected local.

Using the Local Wizard


A wizard is provided for defining a local coordinate system. You can define a local using a single point or three points, as described in the following sections.

Using the Local Wizard to teach a single point local


1. Open the [Robot Manager] and click on [Locals] to show the [Locals] page.
2. Click the <Local Wizard> button. You will see the dialog shown below.




3. Click the <Next> button to proceed with the Local setting using the Jog & Teach. For details of the Local setting, refer to 7. *Vision Calibration* in the *Vision Guide 7.0 Software* manual.



4. Select the local number you want to define. For [How many points will be used], select [1 – Origin]. Since this is a single point local, you will just teach the origin of the new coordinate system. If you want to use the U, V, or W axes for the orientation of the coordinate system, check the [Use U, V, W tool coordinates for local rotation] checkbox. If this checkbox is unchecked, the new coordinate system is offset from local 0 in X and Y, but is not rotated about any axis. Click the <Next> button.




5. We will now teach the local origin point. Click the <Teach> button to open the [Local Wizard Teach Point] dialog box.




6. Jog the robot until the end effector is aligned with the local origin point. Then click the <Teach> button.

7. The new local definition is displayed as shown below. Click <Finish> to accept the new definition.




Using the Local Wizard to teach a three point local


1. Open the [Robot Manager] and click on [Locals] to show the [Locals] page.
2. Click the <Local Wizard> button. You will see the dialog shown below.




3. Click the <Next> button to proceed with the Local setting using the Jog & Teach. For details of the Local setting, refer to 7. *Vision Calibration* in the *Vision Guide 7.0 Software* manual.




4. Select the local number you want to define. For [How many points will be used], select [3 - Origin, X, Y]. Since this is a three point local, you will teach the origin of the new coordinate system, and then teach one point anywhere along the X axis and one point anywhere along the Y axis. Select which axis will be used to align the coordinate system. For example, if you select X, then the new coordinate system X axis will be aligned to the X axis point that you will teach in a later step. The Y axis point will be used to determine tilt. Click the <Next> button.




5. We will now teach the local origin point. Click the <Teach> button to open the [Local Wizard: Teach Point] dialog box.




6. Jog the robot until the end effector is aligned with the origin point. Then click the <Teach> button. The next step will be displayed.



7. We will now teach a point on the local X axis. Click the <Teach> button and jog the robot until the end effector is aligned with a point anywhere along the X axis of the new coordinate system. Click the <Teach> button on the [Teach Point] dialog box to continue.



8. We will now teach a point on the local Y axis. Click the <Teach> button and jog the robot until the end effector is aligned with a point anywhere along the Y axis of the new coordinate system. Click the <Teach> button on the [Teach Point] dialog box to continue.
9. The new local definition is displayed as shown below. Click <Finish> to accept the new definition.




[Tools]-[Robot Manager]-[Tools] Page

This page allows you to define tool settings for a robot. When the tab is selected, the current values are displayed.

A grid is used to display all the values for all 15 tools you can define.

When a tool is undefined, then all fields for that tool will be blank. When you enter a value in any of the fields for an undefined tool, then the remaining fields will be set to zero and the tool will be defined when you click the <Apply> button.

For more information on tools, see the *SPEL⁺ Language Reference: TLSet Statement*.



Navigating the grid


Use the <TAB> key to move to the next field. Use the arrow keys or the mouse to move to any field.

Item	Description
Robot	Select a robot.
Tool Wizard	This button starts the Tool Wizard. Follow the instructions for each step of the wizard to define a tool. See details in the next section.
X	The X coordinate of the tool.
Y	The Y coordinate of the tool.
Z	Z offset of tool.
U	Rotation angle of the tool about the Z axis (roll).
V	Rotation angle of the tool about the Y axis (pitch).
W	Rotation angle of the tool about the X axis (yaw).
Apply	Sets the current values.
Restore	Reverts back to the previous values
Clear	Clears all values for the selected tool.


Using the Tool Wizard

For SCARA Robots



1. Select [Robot Manager]-[Tools] tab to show the [Tools] page.
2. Click the <Tool Wizard> button. You will see the dialog box shown below. Select the tool number to define and click the <Next> button.





3. Click the <Next> button to proceed with the Tool setting using the Jog & Teach. For details of the Tool setting, refer to 7. *Vision Calibration* in the *Vision Guide 7.0 Software* manual.




4. Jog the robot until the tool is aligned with the reference point. Then click the <Teach> button to show the [Jog & Teach] dialog box. Jog the robot so that the tool is aligned with the reference point.



5. Click the <Teach> button to display the following dialog box. After rotating the U axis as shown below to change the angle, jog the X and Y axes until the tool is aligned with the reference point. Click the <Teach> button to show the [Jog & Teach] dialog box. Match the tool and the reference point.



6. Click the <Teach> button. The new tool definition is displayed as shown below. Click <Finish> to apply the new definition.



NOTE



The robot can be calibrated with a different posture from the wizard.

For 6-axis robots (including N series)

NOTE



There are two calibration methods for 6-axis robots. 3D Tool moves the robot in X, Y, Z, U, V, and W directions to calibrate, while 2D Tool moves the robot in X, Y, Z, and U directions. The robot can be calibrated with 2D Tool only when the robot posture is “V=0 degree, W=0 degree”, or “V=0 degree, W=180 degree (-180 degree).

NOTE



When comparing 2D Tool and 3D Tool, 2D Tool has following advantages and disadvantages. Choose the suitable method according to the intended use.


Advantages:

- Shorter calibration time than 3D Tool
- Since V and W axes are not moved, peripherals and cables are less likely to interfere the calibration


Disadvantages:

- Calibration accuracy may be worse than 3D Tool
- The Z-axis direction offset is not performed automatically (*1)


*1: If the Z-axis direction offset is required, enter the offset value in the following dialog box after calibration.




1. Select [Robot Manager]-[Tools] tab to show the [Tools] page.
2. Click the <Tool Wizard> button. You will see the dialog box shown below. Select either 3D Tool or 2D Tool.



3. Click the <Next> button to proceed with the Tool setting using the Jog & Teach. For details of the Tool setting, refer to 7. *Vision Calibration* in the *Vision Guide 7.0 Software* manual.



4. If using 3D Tool, select the tool number to define and the number of points to teach, and click the <Next> button.





NOTE



The “number of points to teach” is the amount of times to teach the same point (reference point) in the robot motion range while changing only the tool direction. The number to teach should be at least three. Although it depends on the teaching accuracy of each point, more accurate tool setting can be set by increasing the number.

To increase the tool setting accuracy, set the angle of approximately 10 degrees or more for J5 pulse in order to avoid singularity near 0 degree when teaching the reference point.

5. Jog the robot until the tool is aligned with the reference point. Then click the <Teach> button to show the [Jog & Teach] dialog box. Match the tool and the reference point.



6. Click the <Teach> button to show the following dialog box.
If using 3D Tool, rotate the U, V, and W axes as shown below, and then jog the X, Y, and Z axes until the tool is aligned with the reference point. Repeat teaching until the robot can reach the reference point from other tool orientation as often as you specified in (3).

If using 2D Tool, rotate only the U axis as shown below, and then jog the X, Y, and Z axes until the tool is aligned with the reference point.


Clicking the <Teach> button displays the [Jog & Teach] dialog box for both 3D Tool and 2D Tool. Match the tool and the reference point.

NOTE





When moving the U, V, and W axes, move the arm upward in order to avoid collision of the tool and the reference point.


For 3D Tool:



For 2D Tool:



7. The new tool definition is displayed as shown below. Click <Finish> to apply the new definition.

**NOTE**

Although it is recommended to calibrate the robot with the same posture as the wizard, it is possible to calibrate the robot with the different robot posture from wizard.


[Tools]-[Robot Manager]-[Arms] Page

This page allows you to define Arm settings for a robot. When the tab is selected, the current Arm values are displayed. The tab is disabled if the current robot does not support the Arm command.

A grid is used to display all the values for all 15 arm configurations you can define.

When an arm is undefined, then all fields for that arm will be blank. When you enter a value in any of the fields for an undefined arm, then the remaining fields will be set to zero and the tool will be defined when you click the <Apply> button.

For more information on arm parameters, see the *SPEL⁺ Language Reference: ArmSet Statement*.



Navigating the grid

Use the <TAB> key to move to the next field. Use the arrow keys or the mouse to move to any field.

Item	Description
Robot	Select a robot.
Arm Wizard	Open the wizard for configuring the additional arm using the camera. Define the tool by following the instructions. For details of the Local setting, refer to 7. <i>Vision Calibration</i> in the <i>Vision Guide 7.0 Software</i> manual.
L2 Dist	Distance between the center of joint 2 and the center of the orientation joint in millimeters.
J2 Offset	Angle of the line from the center of joint 2 to the center of the orientation joint in degrees.
Z Offset	The Z offset between the new orientation axis and the standard orientation axis.
L1 Dist	Distance between the center of the shoulder joint and the center of the elbow joint in millimeters.
U Offset	The angle offset between the standard orientation zero position and the new orientation axis zero position in degrees.
Apply	Set current values.
Restore	Revert to the previous values.
Clear	Clear all values for the selected arm

[Tools]-[Robot Manager]-[ECP] Page

This page allows you to define ECP (external control point) settings for a robot. When the page is selected, the current values are displayed.




If the ECP option is not enabled in the controller, this page will not be visible.

For detailed information on using external control points in your application, refer to 6.16.5 *ECP Coordinate Systems (Option)*.

A grid is used to display all of the values for all ECPs you can define.

When an ECP is undefined, then all fields for that ECP will be blank. When you enter a value in any of the fields for an undefined ECP, then the remaining fields will be set to zero and the ECP will be defined when you press the <Apply> button.

**Navigating the grid**



Use the <TAB> key to move to the next field. Use the arrow keys or the mouse to move to any field.

Item	Description
Robot	Select a robot.
X	The X coordinate of the ECP.
Y	The Y coordinate of the ECP.
Z	The Z coordinate of the ECP.
U	Rotation angle of the ECP about the Z axis (roll).
V	Rotation angle of the ECP about the Y axis (pitch).
W	Rotation angle of the ECP about the X axis (yaw).
Apply	Set current values.
Restore	Revert back to the previous values.
Clear	Clear all values for the selected ECP.

[Tools]-[Robot Manager]-[Pallets] Page

This page allows you to define the pallet (Pallet). When the page is selected, values for the available pallet are displayed. When a Pallet is undefined, then all fields for the Pallet will be blank. The Pallet will be defined when you press the <Apply> button.

For more information on Pallet, see the *SPEL+ Language Reference: Pallet Statement*.




Navigating the grid

Use the <TAB> key to move to the next field. Use the arrow keys or the mouse to move to any field.

Item	Description
Robot	Select a robot.
Points	Specify the point variable to use for pallet definition. Select either 3 or 4.
Columns	Specify the division number of Point number 1 (coordinate system data 1) and Point number 2 (coordinate system data 2) by an integer. The range is from 1 to 32767. (Division 1 × Division 2 <32767)
Rows	Specify the division number of Point number 1 (coordinate system data 1) and Point number 3 (coordinate system data 3) by an integer. The range is from 1 to 32767. (Division 1 × Division 3 <32767)
Outside	Optional. Creates an accessible pallet outside the specified columns and rows
X	Set the X coordinate in millimeters.
Y	Set the Y coordinate in millimeters.
Z	Set the Z coordinate in millimeters.
U	Set the U coordinate in degrees.
V	Set the V coordinate in degrees.
W	Set the W coordinate in degrees.
Apply	Set current values.
Restore	Revert back to the previous values.
Clear	Clear all values.

Using the Pallet Wizard

1. Select [Robot Manager]-[Tools] tab to show the [Pallets] page.
2. Click the <Pallet Wizard> button. You will see the dialog box shown below.




3. Select the pallet number to define, the number of points to teach, the number of rows and columns, and whether to use "Outside". Then, click the <Next> button.

NOTE




If a pallet is a well ordered rectangular shape, only 3 of the 4 corner points should be specified. However, in most situations, it is recommended to use 4 corner points to define a pallet.


4. Click the <Teach> button to show the [Teach first point] page.



5. Jog the robot to the first corner to teach the position of it. Click the <Teach> button to show the following dialog box.




6. Teach the second to forth corners by following the steps (4) and (5).
7. The new pallet definition is displayed as shown below. Click <Finish> to apply the new definition.



[Tools]-[Robot Manager]-[Box] Page

This page allows you to define Box (approach check area) settings for a robot. When the page is selected, the current values are displayed. When a Box is undefined, then all fields for that Box will be blank. When you enter a value in any of the fields for an undefined Box, then the remaining fields will be set to zero and the Box will be defined when you press the <Apply> button.

For more information on Box, see the *SPEL⁺ Language Reference: Box Statement*.

**Navigating the grid**


Use the <TAB> key to move to the next field. Use the arrow keys or the mouse to move to any field.

Item	Description
Robot	Select a robot.
Min X	Type in the minimum X limit value in millimeters.
Max X	Type in the maximum X limit value in millimeters.
Min Y	Type in the minimum Y limit value in millimeters.
Max Y	Type in the maximum Y limit value in millimeters.
Min Z	Type in the minimum Z limit value in millimeters.
Max Z	Type in the maximum Z limit value in millimeters.
Polarity	Sets the polarity to output I/O at approach check.
Apply	Sets current values.
Restore	Reverts back to the previous values.
Clear	Clears all values.


Setting both values to zero disables the limits.

Using the Box Wizard


1. Select [Robot Manager]-[Boxes] tab to show the [Boxes] page.
2. Click the <Box Wizard> button. You will see the dialog box shown below.




3. Select the Box number to define and click the <Next> button.
4. Click the <Teach> button to show the [Teach first corner of box] page.




5. Jog the robot to the first corner to teach the position of it. Click the <Teach> button to show the following dialog box.



6. Teach the second to forth corners by following the steps (4) and (5).
7. Select the polarity to output the I/O




8. The new box definition is displayed as shown below. Click <Finish> to apply the new definition.



[Tools]-[Robot Manager]-[Plane] Page

This page allows you to define Plane (approach check plane) settings for a robot. When the page is selected, the current values are displayed. When a Plane is undefined, then all fields for that Plane will be blank. When you enter a value in any of the fields for an undefined Plane, then the remaining fields will be set to zero and the Plane will be defined when you press the <Apply> button.

For more information on Plane, see the *SPEL⁺ Language Reference: Plane Statement*.




Navigating the grid

Use the <TAB> key to move to the next field. Use the arrow keys or the mouse to move to any field.

Item	Description
Robot	Select a robot.
X	Sets the X origin of the coordinate for approach check plane.
Y	Sets the Y origin of the coordinate for approach check plane.
Z	Sets the Z origin of the coordinate for approach check plane.
U	Sets the U origin of the coordinate for approach check plane.
V	Sets the V origin of the coordinate for approach check plane.
W	Sets the W origin of the coordinate for approach check plane.
Apply	Set current values.
Restore	Revert back to the previous values.
Clear	Clear all values.

Using the Plane Wizard

1. Select [Robot Manager]-[Planes] tab to show the [Planes] page.
2. Click the <Plane Wizard> button. You will see the dialog box shown below.




3. Select the plane number to define and the number of points to teach, and then click the <Next> button.




You can select either “1” or “3” for the number of points to teach. If you select “1”, the robot posture at teaching will be reflected. If you select “3”, the robot posture will not be reflected. For details, refer to the *SPEL+ Language Reference: Plane Statement*.

4. Click the <Teach> button to show the [Teach plane origin point] page.


If the number of point to teach is “1”:




5. Jog the robot to the reference point to teach the position of it. Click the <Teach> button to show the following dialog box.




6. The new plane definition is displayed as shown below. Click <Finish> to apply the new definition.




If the number of points to teach is “3”:



- 1) Jog the robot to the reference point to teach the position of it (Point #1). Click the <Teach> button to show the following dialog box.




- 2) Teach the X axis specified point (Point #2) and the Y axis specified point (Point #3) in the same way as the step 1).
7. The new plane definition is displayed as shown below. Click <Finish> to apply the new definition.



[Tools]-[Robot Manager]-[Weight] Page

This page is for changing the Weight parameters for the robot.

For details on the Weight parameters, see the *SPEL⁺ Language Reference: Weight Statement*.




Item	Description
Robot	Select a robot.
Weight	Type in the new total weight of the payload on the robot.
kg/lbs	Choose which unit the weight is represented in: kilograms or pounds.
Length	Type in the new length.
Apply	Sets the current values.
Restore	Reverts back to the previous values.
Defaults	Displays factory default settings.

[Tools]-[Robot Manager]-[Inertia] Page

This page is for changing the Inertia parameters.

For details on the Inertia parameters, see the *SPEL⁺ Language Reference: Inertia Statement*.




Item	Description
Robot	Select a robot.
Load inertia	Type in the new load inertia of the payload on the robot in kg·m ² . This includes the inertia of end effector plus the part to be carried.
Eccentricity	Type in the new eccentricity value in millimeters. This is the distance from rotational center of joint 4 to the center of gravity of end effector and part.
Apply	Set the current values.
Restore	Revert back to the previous values.
Defaults	Press the defaults button to display factory default settings.

[Tools]-[Robot Manager]-[XYZ Limits] Page

This page allows you to configure limits for X, Y and Z motion in the robot envelope.

For details on the XYZ limits, see the *SPEL⁺ Language Reference: XYLim Statement*.




Item	Description
Robot	Select a robot.
X, Y, Z	Type in the minimum and maximum X, Y, and Z limit values. Setting both values to zero disables the limits.
Read Current	Click this button to read the value from the current robot position. The button text shows the axis and minimum or maximum depending on which text field has the current focus.
Apply	Set the current values.
Restore	Revert back to previous values.
Defaults	Set default values.

[Tools]-[Robot Manager]-[Range] Page

This page allows you to configure the robot joint software limits.

For more information on Range, see the SPEL+ Language Reference and the manual for the robot you are using.

For details on configuring the motion range, see the *SPEL+ Language Reference: Range Statement*.




Item	Description
Robot	Select a robot.
J1 - J6	Type in the minimum and maximum encoder pulse values for each joint.
Read Current	Click this button to read the current joint value of the robot into the current field. The button text will change depending on which text field has focus.
Apply	Save the current changes.
Restore	Revert back to the previous values.
Defaults	Set the default values.

[Tools]-[Robot Manager]-[Home Config] Page

Home Config allows you to configure the optional user home position.

For details on configuring the home position, see the *SPEL⁺ Language Reference: HomeSet Statement*.



Changing home position

When you select the [Home Config] tab, the current home position is read from the robot controller and displayed in the text boxes. If the home position has never been defined, then the text boxes will be blank.

To define the home position, you can enter an encoder position value for each of the four robot joints in the text boxes, or you can select the [Jog & Teach] page to jog the robot to the desired home position, then select the [Home Config] page and click the <Read Current Position> button to read the current encoder position values.

Changing home order

The home command executes in steps. The number of steps equals the number of joints on the robot. Select the home step number for each joint using the dropdown list for each joint. More than one joint can be homed in the same step.

Testing home

After making changes to the home position and home order, you can click the [Robot Manager]-[Control Panel] tab and click the <Home> button.

Item	Description
Robot	Select a robot.
Read Current	Click this button to read the current position encoder pulse value into the currently selected text field. The button text will change according which text field is selected.
Defaults	Set the value of the [Home order] group box to the default value.
Apply	Save the current changes.
Restore	Revert back to the previous values.

5.11.2 [Command Window] Command (Tools Menu)

You can execute SPEL⁺ commands from the robot controller and view the results.

To open the Command window


Select Command Window from the Tools Menu

Or

Click on the  button on the toolbar.

Or

Type Ctrl+M



To execute SPEL⁺ commands from the Command window

1. Type in the desired command after the prompt (>). Commands can be entered in upper or lower case.
2. Press <Enter> to execute the command. The cursor can be anywhere on the line when you press <Enter>.
3. Wait for the prompt to return before typing in a new command.

When an error occurs, an error number will be displayed along with an error message.

You can use the arrow keys or the mouse to move the cursor to any line in the window that starts with a prompt (>) character and execute it by pressing <Enter>.

Command Window Keys

Key	Action
Ctrl+A	Select entire window.
Ctrl+C	Stop the program and initialize robot controller. If a robot motion command is in progress, the prompt will return when the command has been completed.
Ctrl+V	Execute Paste command. Paste from Clipboard to current selection.
Ctrl+W	Re-display last command line after the prompt.
Ctrl+X	Execute Cut command. Cut current selection and put in Clipboard.
Ctrl+Z	Undo last change.
Ctrl+Home	Go to the top of the window.
Ctrl+End	Go to last prompt at end of the window.
?	Translates to "PRINT" when used as the first character of a command. This can be used to display variables or any statement that requires a PRINT command.

5.11.3 [I/O Monitor] Command (Tools Menu)

The I/O Monitor window lets you monitor all controller hardware inputs and outputs and also memory I/O. There are up to four views available: one standard view and three custom views.

On the standard view, there are two grids. For each grid you can specify which type and size of I/O to monitor.

For each custom view, you can specify a list of any combination of input, output, or memory. By default, there is one custom view available. To use the other two custom views, right click on a tab and check the views you want to be visible. See the section *Custom I/O Views* later in this chapter.


Labels that have been defined using the [I/O Label Editor] are displayed next to each bit, byte, or word.

After the [I/O Monitor] window has been opened, the input and output status for the current view is constantly updated.


The I/O monitor will always be displayed on top of other child windows, such as program windows and point windows.

If a description has been entered for an I/O port (bit, byte, or word) in the I/O Label Editor, then a tool tip will be displayed when the mouse pointer is over the row containing the port.

You can turn outputs on and off by double clicking on the output LED images in the Status column.



To open the I/O Monitor
Select I/O Monitor from the Tools Menu.
Or

Click on the  tool bar button.
Or

Type Ctrl + I.

Using the I/O Monitor
Select the [Standard View] tab.

Scroll through the grids to locate the desired inputs or outputs to monitor.

You can split each grid into two scroll regions by selecting the split bar in the upper right corner of the grid and dragging it down. Each scroll region can be individually scrolled.

To turn an output off or on, double click on the LED image for the desired output.


When Virtual I/O is active, you can turn input bits on and off by double clicking on the input LED images in the Status column.

To view bytes and words in hexadecimal format, check the [Hexadecimal Values] checkbox.

You can resize the I/O monitor in the vertical direction to show more data. Move your mouse pointer to the lower right corner of the window to activate a size handle, then click down and drag the window down or up to the desired size.


Custom I/O Views

You can configure up to three custom I/O views. In each view, you can add any combination of I/O. You can also change the name of each view and hide each view.



To change a view

1. Click on a custom view tab. If none are currently shown, right click on the [Standard View] tab and select one of the three custom views to show it.



2. Click the <Add> button to add a new row to the list.
3. Select the <Type> by clicking in the [Type] column, then click the arrow to view a list of I/O types and select one.
4. In the [Port] column, select the port (bit, byte, or word, depending on I/O type).
5. Add more rows as needed by repeating steps 2 - 4.

<Apply>: Save the changes

<Delete>: Delete a row

<Restore>: Cancel changes.

To rename a view

1. Click on a custom view tab. If none are currently shown, right click on the [Standard View] tab and select one of the three custom views to show it.
2. Right click on the view tab and select [Rename].
3. Enter the new name for the view.

5.11.4 Task Manager Command (Tools Menu)

The Task Manager window allows you to Halt (suspend), Resume (continue), and Quit (abort) tasks.

To open the Task Manager

Select Task Manager from the Tools Menu.

Or

Type Ctrl + T.

Or

Click on the  button on the toolbar.

Operation

The Task Manager is used for suspending, resuming, stepping, and stopping tasks.

When Task Manager is started, you will see a grid containing status information for 32 tasks standard tasks and 11 trap tasks. Also, you will see the status information of 16 background tasks if the background task is enabled. There are 8 items shown for each task. To view all of the columns, use the scroll bar or resize the window.

Task	Number of task from 1 to 32 and 11 trap tasks.	
Name	Name of the function that was started as a task.	
Status	Current task status: Run, Wait, Halt, Pause, Aborted, Finished.	
Type	Task types	
	Normal	This task is a normal task
	NoPause	This task does not pause with Pause statement or when Pause input or Safety Door open occur.
	NoEmgAbort	This task continuously processes during the Emergency Stop or error occurrence.
Line	Current task line number.	
Function	Current task function name.	
Program	Current task program name.	
Start	The date and time that the task was started.	
CPU	CPU load factor of each task. This function assists problem detection of the user created tasks.	

In the following Example 1, the function repeats until the standard input I/O bit port 1 turns ON.

Since Sw() is the command in which the tasks are not switched, this task occupies the process. It may affect other user tasks or the whole system of the Controller. In order to specify such tasks, use the CPU load factor display.

Restrictions


Displayed values do not guarantee the accuracy. Due to limitations of measuring method, some differences are included. The load factor of the properly created program is minimal. Also, in a program like Example 2, commands are executed by other system tasks. Therefore, the load factor is displayed as “0”.

Example 1)

```
Function main
Do
Do
If Sw(1) = On Then Exit Do
Loop
Go P(0)
Loop
Fend
```

Example 2)

```
Function main
Do
Print "TEST"
Loop
Fend
```



Task	Name	Status	Type	Line	Function	Program	Start	CPU
1	main	Run	Normal	6	main	Main.prg	2014/05/22 12:02:46	50
2	sub1	Wait	Normal	29	sub1	Main.prg	2014/05/22 12:02:46	0
3	sub2	Wait	Normal	34	sub2	Main.prg	2014/05/22 12:02:46	0
4								
5								
6								
7								
8								
9								
10								
11								

Halt
 Resume
 Quit
 Pause
 Continue
 Stop

Item	Description
Halt	<p>Suspends the selected task. The halted task can be resumed by the <Resume> button. Halt can only be executed when a task is running (status is Run). When Halt is executed, the <Resume> button will be enabled. If a motion command associated with Halt is executed, the motion will be completed before the task reaches the Halt state.</p> <p>The task also temporarily stops when the task is NoPause type or NoEmgAbort type.</p>
Resume	<p>After one or more tasks are suspended with the <Halt> button, clicking <Resume> make the halted tasks continue where they left off. First, a confirmation dialog is displayed.</p>
Quit	<p>This button stops the selected task permanently. You cannot resume a task once you have executed Quit. To restart the task, you must start it from within a program or from the Run window. The task also stops when the task is NoPause type or NoEmgAbort type.</p>
Pause	<p>This button pauses tasks that can be paused. After pause, you must use either <Continue> or <Stop>.</p> <p>The task does not pause when the task is NoPause type or NoEmgAbort type.</p>
Continue	<p>This button continues all tasks that were paused with the <Pause> button.</p>
Stop	<p>This button stops all tasks.</p>

To Halt, Step, Walk, and Resume a task

The <Halt> button will become active after you select a running task.

Click the <Halt> button to stop the task you selected for a moment.

After a task has been halted, the source code will be displayed and the next step will be indicated. You can click on the <Resume> button to resume execution. (You can also execute [Step Into], [Step Over], or [Walk] from the [Run] Menu.)

To Pause and Continue tasks

Pause allows you to "suspend" all tasks that can be suspended.

Click on the <Pause> button to pause available tasks. The robot will decelerate to a stop immediately.

After executing Pause, click on <Continue> to resume all suspended tasks.


To view source code at the current execution line

Select a task row. Then right click and select [Go To Line]. The program editor will be opened at the current execution line

5.11.5 Macros Command (Tools Menu)

You can create SPEL+ command macros using the Macro Editor. Macros consist of one or more SPEL+ statements that can be executed from the command window. A macro statement may use global variables, I/O labels, and point labels. You can assign a macro to each of the Alt function keys except for Alt+F4, which is a Windows shortcut to close the application.

1. Select [Tools]-[Macros] to open the [Command Macros] dialog box.



2. Type the macro statements in the [Macro] text box.
3. Click the <Apply> button to save changes.
4. Click <Execute> to run the macro.
5. Click <Close> to close the dialog. You will be prompted to save the macros you have created or changed.

To open a macro and execute it, type <Alt> + function key. Then click <Execute> to run it. Macros never execute by pressing the function key. The separate execute step is provided for safety, since macros can move the robot and control I/O.

Macros can be executed while tasks are running. If invalid commands are executed while tasks are running, an error will occur.

5.11.6 [I/O Label Editor] Command (Tools Menu)

The I/O label editor lets you define meaningful names for inputs, outputs, and memory I/O for each project. The labels can be used in your programs, from the Command window, or in macros. They are also displayed in the I/O Monitor window.

To open the I/O Label Editor


Select I/O Label Editor from the Tools Menu.

Or

Type Ctrl + L.

Or

Click on the  button on the toolbar.



The I/O Label Spreadsheet

When you select [I/O Label Editor] from the [Tools] menu, a window opens that contains a tree and a spreadsheet editor.

The tree on the left side of the window shows the various types of I/O for the controller. For each type of I/O you can view and edit labels for bits, bytes (8 bits), and words (16 bits).

The first column of the spreadsheet shows the bit, byte, or word number, depending on which type of I/O you are viewing.

The second column contains the label for each bit, byte, or word in column 1. You can type in up to 32 characters for a label. Label characters can be alphanumeric or underscore.

The third column contains the description associated with the label.

If you add a description to an I/O point, then the description will be displayed as a tool tip on the I/O Monitor.




- The I/O Label Editor shows all available I/O types on your controller.
- For the Editor version, the I/O Label Editor shows the all I/O types.
For example, you can edit Fieldbus I/O labels, but you may not have a Fieldbus board installed in the controller.

To add or edit a label

Select the type of I/O you want to label in the tree. After you select the I/O type, the spreadsheet will be refreshed to display the labels for that type. The number of rows in the spreadsheet equals the number of bits, bytes, or words available for the type you have selected.

Use the mouse to scroll through the spreadsheet and put the cursor in the [Label] field next to the bit, bytes, or words number that you want to add a label to. Type in the label, which can be up to 32 alphanumeric characters without any spaces. Optionally, you can type a description for the label in the [Description] field.

After adding or editing labels, save the changes by executing [Save] from the [File] menu or by clicking on the < Save all files >  toolbar button. If any duplicate labels are detected, an error message will be displayed and the save operation will be aborted. You must correct the duplication before you can save the labels successfully.

To cut and paste labels and descriptions


You can cut and paste labels and descriptions by selecting with the mouse, then executing [Copy], [Cut], and [Paste] from the [Edit] menu.

You can also cut and paste entire rows using the following steps:

1. Select one or more rows by using the row selectors on the left and execute either the [Cut] or [Copy] command from the [Edit] menu. When selecting multiple rows, hold down the shift or control key while selecting rows with the mouse.
2. Select the row where you want to start the paste by clicking the row selector on the left of the row.
3. Execute the [Paste] command from the [Edit] menu.

5.11.7 User Error Editor Command (Tools Menu)

The User Error Editor allows you to define user errors.



User error numbers can be from 8000 to 8999.

Labels can be up to 16 characters in length.

It is recommended that you use the ER_ prefix for each error label and use all caps for the label. This makes it easy to see error labels in your code.

Some user error examples:

Error #	Label	Message
---------	-------	---------

8000	ER_VACUUM	Vacuum error has occurred.
------	-----------	----------------------------


8001	ER_INDEXOT	Indexer overtime has occurred.
------	------------	--------------------------------

In your program code, use the Error statement to generate a user error. For example:

```
On Vacuum
Wait Sw(VacOn), 1
If Tw = 1 Then
    Error ER_VACUUM
EndIf
```

The user error information is stored in the current project directory in a file called UserErrors.dat.

You can use the [Import] command from the [File] menu to import user errors from other projects.

After adding new error definitions, save the changes by executing Save from the [File] menu or by clicking on the <Save all files>  toolbar button. If any duplicate labels are detected, an error message will be displayed and the save operation will be aborted. You must correct the duplication before you can save the labels successfully.


5.11.8 [Controller] Command (Tools Menu)

Select Controller from the [Tools] menu to open the [Controller Tools] dialog box.

From the [Controller Tools] dialog box, you can save and restore the complete controller configuration and the project using the [Backup Controller] and [Restore Controller] commands. You can also save and view controller status, and reset the controller.

Before servicing the system, you should execute [Backup Controller] and store the system configuration on an external media such as a USB memory key.

If required, you can use [Restore Controller] to restore previously stored data.



Backup Controller

Use Backup Controller to save controller configuration data on your PC.

The current status is saved in a folder containing several files. The controller configuration settings, task status, I/O status, robot status, etc. are saved in these files. This is useful for users to send a snapshot of the controller status to the supplier of your region or to Epson technical support, should the need arise.




Backup Controller is equivalent to connecting a USB memory key to the controller and pressing the TRIG button on the controller to save controller status.

Controller status is stored in a folder named "B" followed by the controller type, the controller serial number, and the date / time.

You can configure the controller whether to save the project files in the status folder or not. See [Setup]-[System Configuration]-[Controller]-[Preferences].

1. Select [Tools]-[Controller].
2. Click on the <Backup Controller> button to open the [Browse For Folder] dialog box.




3. Select the disk drive and parent folder where you want to save the information. You can create a new parent folder by clicking the <Make New Folder> button.
4. Click <OK>. A new folder containing the backup files will be created in the selected folder named “B” followed by the controller type, the controller serial number, and the date / time.

Restore Controller

Use Restore Controller to load controller settings from previously saved backup data. You cannot restore the controller data while tasks are running. If you attempt to do so, an error message will be displayed.

To restore controller configuration:

1. Select [Tools]-[Controller].
2. Click on the <Restore Controller> button to open the [Browse For Folder] dialog box.




3. Select the drive and folder where the information is stored. Controller backup information is stored in a folder that is named “B” followed by the controller type, the controller serial number, and the date / time.



You can also select a folder containing export controller status information.

4. Click <OK> to display the dialog to select the restore data.



Robot names, serial numbers, calibrations checkbox

This checkbox allows you to restore the robot name, robot serial number, Hofs data, and CalPIs data. Make sure that the correct Hofs data is restored. If the wrong Hofs data is restored, the robot may move to wrong positions.

The default setting is unchecked.

Robot maintenance configuration checkbox

This checkbox allows you to restore the parts consumption data.

For details, refer to the following manual.

Robot controller RC700 / RC700-A Maintenance 6 Alarm.

This is not checked by the default setting.

Project checkbox

This checkbox allows you to restore the files related to projects.

The default setting is unchecked.

When the project is restored, all the values of Global Preserve variables are restored.

For details about Global Preserve variable backup, refer to 5.10.10 [Display Variables] Command (Run Menu).

Vision hardware configuration checkbox

This checkbox allows you to restore the vision hardware configuration.

For details, refer to the *EPSON RC+ 7.0 option: Vision Guide 7.0*.

This is not checked by the default setting.

Security configuration checkbox

This checkbox allows you to restore the security configuration.

For details, refer to 15. Security.

This is not checked by the default setting.

Force Sensing I/F configuration checkbox

This checkbox allows you to restore the Force Sensing I/F configuration.

For details, refer to *EPSON RC+ 7.0 option Force Guide 7.0*.

This is not checked by the default setting.


Password authentication settings checkbox

This checkbox allows you to restore the connection password that was stored in the controller.

5. Click the <OK> button to restore the system information.



Restore the system configuration saved using Backup Controller only for the same system. When different system information is restored, the following warning message appears.



Click the <No> button to cancel restoration of data except for special situations such as controller replacement.



When restoring the backup which includes the data of the robot configured to the Drive Unit, be sure to restore the data while the Drive Unit is connected and turned on.



When restoring the backup including the unsupported robot information to the target controller, an error occurs.



You cannot restore the backup including PG to the virtual controller.




You cannot restore the data that is backed up by the virtual controller to T series manipulators.

View Controller Status


Click the <View Controller Status> button to view the status data stored from a previous status export (see the Export Controller Status section above).

To view controller status:

1. Select [Tools]-[Controller].
2. Click on the <View Controller Status> button to open the [Browse For Folder] dialog.



3. Select the drive and folder where the information is stored. Controller status information is stored in a folder that is named “B” followed by the controller type, the controller serial number, and the date / time.
4. Click <OK> to view the selected controller status.
5. The [Controller Status Viewer] dialog will be displayed.



6. Select items to view from the tree on the left side of the dialog.
7. To view another controller status, click the ellipses button next to the Status Folder name and select a new status folder.

Reset Controller

Use the <Reset Controller> button to reset the SPEL controller.

Maintenance

It shows the parts consumption data for the Controller or Manipulator parts.

For details, refer to *Maintenance 6. Alarm* in the *RC700 / RC700-A Controller Manual*.

5.11.9 [Vision] Command (Tools Menu)

For instructions, refer to the following manual.

Vision Guide 7.0 Hardware & Setup 2. Software Configuration

5.12 [Setup] Menu


The [Setup] menu contains the following commands:

- PC to Controller Communications
- System Configuration
- Preferences
- Options

5.12.1 [PC to Controller Communications] Command (Setup Menu)




To configure communications with the Controller, select [PC to Controller Communications] from the [Setup] menu. The [PC to Controller Communications] dialog will be displayed as shown below:



Item	Description
Connect	Connect the selected communication.
Disconnect	Disconnect the communication.
Add	Add communication information of Ethernet or a virtual controller. Clicking this button opens the dialog to specify the communication type.
	<div data-bbox="657 1294 1011 1581" data-label="Image"> </div> <p>Program total execution time</p> <p>In the virtual controller, the total execution time of programs is limited to one hour.</p> <p>If total execution is over one hour, a warning message appears.</p> <p>You can execute the program again after the warning is displayed, and the total execution timer will be reset.</p>
Delete	Deletes selected communication information. Connection #1 “USB” cannot be deleted.
Apply	Saves changes.
Restore	Restores to previous settings.
Work Offline	You can build a project without connecting to the controller in Offline mode. Some functions such as Robot Manager are not available in this mode.
Auto Connect	If the connection is enabled, connects to the controller automatically.
Close	Closes the dialog.

5.12.2 [System Configuration] Command (Setup Menu)


The [System Configuration] command opens a dialog that contains several pages that are used to configure the system for the EPSON RC+ 7.0 environment.

To open the [System Configuration] dialog, select [Setup]-[System Configuration] .

[Setup]-[System Configuration]-[Startup]


[Setup]-[System Configuration]-[Startup]-[Start Mode] Page

From the Start Mode page, you can choose whether EPSON RC+ 7.0 starts in Auto mode or Program mode.



Item	Description
Auto	Select Auto to start EPSON RC+ 7.0 in Auto mode. Refer to 4. <i>Operation</i> for details.
Program	Select Program to start EPSON RC+ 7.0 in Program mode. Refer to 4. <i>Operation</i> for details.
Password	Click this button to change the password required to enter Program mode from Operator mode when EPSON RC+ 7.0 starts.
Apply	Saves the current changes.
Restore	Reverts back to previous settings.
Defaults	Click this button to set the default startup mode.
Close	Closes the System Configuration dialog.


[Setup]-[System Configuration]-[Startup]-[Auto Start] Page



Item	Description
Start EPSON RC+ after Windows start	Check this box if you want EPSON RC+ 7.0 to automatically start after Windows starts.
Command line options	Enter the command line options used when EPSON RC+ 7.0 is automatically started. This is active only when the Start EPSON RC+ 7.0 with Windows start checkbox is not checked.
Auto start SPEL+ program	Check this box if you want to execute the main program after a delay. This is active only when starting in Operator mode and the control device is "Self".
Apply	Saves the current changes.
Restore	Reverts back to previous settings.
Close	Closes the System Configuration dialog.

[Setup]-[System Configuration]-[Startup]-[Windows Login] Page

The Windows Login page allows you to configure the automatic login when Windows starts.




Item	Description
Enable windows auto login	Check this box if you want to automatically login to Windows when it starts. You must supply a valid user name, password, and domain.
User Name	Enter the name of a valid Windows user on the system.
Password	Enter the login password for the user.
Domain	Optional. If the PC is the member of a domain, enter the name here.
Apply	Saves the current changes.
Restore	Reverts back to previous settings.
Close	Closes the System Configuration dialog.

[Setup]-[System Configuration]-[Controller]

[Setup]-[System Configuration]-[Controller]-[General] Page


This page allows the user to view general information about the controller.



Item	Description
Serial #	Displays the serial number of the current controller.
MAC Address	Displays the MAC Address of the controller.
Firmware Version	Displays the firmware version used in the current controller.
Date / Time	Displays the current date and time in the controller.
Project Name	Displays the name of the project in the controller.
Close	Closes the Setup Controller dialog.

[Setup]-[System Configuration]-[Controller]-[Configuration] Page


This page allows the user to view and change the controller configuration settings.



Item	Description
Name	Use this text box to change the controller name. You may use any name up to 16 characters long using alphanumeric characters and underscore.
IP Address	Use this text box to set current IP address of the LAN-1 port. The IP Address must be on the same subnet as the PC.
IP Mask	Use this text box to set the IP mask of the LAN-1 port. Note that the IP Mask must match the IP mask used for your network.
IP Gateway	Use this text box to set the IP gateway of the LAN-1 port. This is only required if you will be accessing the controller from outside of the local network.
Control Device	Allows you to select the Control Device.
TP Password	Allows you to change the TP password.
T2 Password	Allows you to change the TP2 password.
Apply	Saves the current changes. If necessary, the controller will be reset to use the new settings.
Restore	Reverts back to previous settings.
Close	Closes the Setup Controller dialog.

[Setup]-[System Configuration]-[Controller]-[Preferences] Page

This page contains controller preference settings.

**RESET command turns off outputs**

When this preference is turned on, all outputs other than remote control outputs will be turned off when a Reset instruction is executed. The default setting is off.



The outputs of the standard I/O, expansion I/O, and Fieldbus I/O are included in the “outputs” mentioned in the above preferences [RESET command turns off outputs] and [Outputs off during Emergency Stop]. Memory I/O is not affected by these preferences. Therefore, memory I/O bits are not turned off by the RESET command execution or during Emergency Stop.

Outputs off during Emergency Stop

When this preference is turned on, all outputs other than remote control outputs will be turned off when emergency stop occurs. Also, no outputs can be turned on until the emergency stop condition is cleared. The default setting is on.

Uncheck this preference to execute I/O On/Off using the NoEmgAbort task or background task after Emergency Stop. If it remains checked, the execution order of turn off by this preference and turn on using the task are not guaranteed.



You should design your system to always remove all power to output devices when emergency stop occurs. Even if the controller turns off outputs, the I/O hardware could malfunction.

Allow motion with one or more joints free

When this preference is turned on, motion commands can be executed after SFree has been used to free one or more joints. The default setting is off.

Walk stops for output commands

When checked, the Walk command from the Run Menu will execute lines until after the next motion or output statement (whichever comes first). When unchecked, the Walk command will execute lines until after the next motion statement and will not stop for output statements. The default setting is on.

Dry run

This preference allows you to run programs without a robot connected to the controller. All program statements will work. Motion statements will execute approximately the same amount of time as when connected to a robot.

Virtual I/O

This preference allows you to run programs using virtual I/O. When Virtual I/O is enabled, I/O commands do not affect the hardware I/O. There are also several commands available for turning on inputs from within a program. The default setting is off.



Remote function is also available when virtual I/O is enabled.

Include project files when status exported

This preference allows you to configure whether project files are included or not when the controller status is exported. Refer to 5.11.8 [Controller] Command (Tools Menu). The default setting is on.

Safeguard open stops all tasks

Check this option to cause all normal tasks and NoPause task to stop when the safeguard is open. Only NoEmgAbort task and background tasks will continue.

This option can be used in applications where pause / continue are not required.

The default setting is off.

Auto safeguard position recovery

This preference allows you to move a robot back to the position where it was at the safeguard opened when continuing the program execution.

Auto recover ON Automatically turns ON a motor and moves a robot in low power status to the position where it was when the safeguard opened.

Continues the usual cycle. (Default)

Auto recover OFF In the Run Window and Operator Window, when an operator clicks the Continue button, a dialog with a Recover button will be shown. The operator needs to hold down the Recover button until the motor is ON and the robot's return is finished. Otherwise the robot will stop before reaching final position.

After verifying that the robot's return is finished, the operator clicks the Continue button to continue the usual cycle.



The peak current is generated in each manipulator when the motor is turned ON. If multiple manipulators are connected using a Drive Unit or a PG Unit, the motor on timing at recovery is changed intentionally for each manipulator to avoid generating the peak current simultaneously. In this case, each manipulator requires approx. 1.5 seconds to turn on the motor.

Independent Mode

This preference allows you to use the controller without interfacing with the Windows (Independent mode).

Use this option when you want to use the controller through the external device using Remote I/O. This option is checked by default.

Initialize global variables when Main XX function started

This preference allows you to initialize the global variables as the main function becomes active.

Turn off this preference when you sue the global variables from the background task.

Otherwise, the variables will be initialized by the controller and the variable-access conflict from tasks will occur. This is turned on by default.

Enable background tasks

This preference allows you to execute background tasks. This is turned off by default.

Enable advanced task commands

This preference allows you to execute StartMain, Cont, Recover, Reset Error commands. This is turned off by default.



- Before you execute StartMain, Cont, Recover, Reset Error commands, you should understand each command's specification and verify that the system has the appropriate condition to execute these commands.
- Improper use, such as executing commands continuously in a loop, can reduce the security of system.

Enable CP – PTP connection when CP is ON

This preference allows you to overlap the trajectories of CP motion and PTP motion during CP ON.



Over-speed error or Over-acceleration-speed error may occur according to the motion acceleration / deceleration speed setting. If the error occurs, adjust the acceleration / deceleration speed setting or uncheck this checkbox.

Auto LJM (Least Joint Motion)

This preference allows you to enable Auto LJM at the controller start up. To disable Auto LJM temporarily, use AutoLJM Off command.



If Auto LJM is enabled at all times, this function automatically adjusts the posture of the robot to reduce the motion distance, even when you intended to move the joint widely. Therefore, it is recommended to disable Auto LJM at the controller start up and operate the robot as you desired using AutoLJM On command or LJM function.

Disable LJM in Teach Mode

This preference allows you to invalidate LJM in the TEACH mode. The LJM function becomes invalid regardless of the command of AutoLJM. The default setting is unchecked.

Disable Point flag check

This preference allows you to continue operation even when point flags, one was specified as a target point and the other one after the motion completion, do not match in a CP motion.

However, if the flags do not match at the transferring point while CP On is used, the robot will stop at the point and the motion will not become a path motion.

Motor off when Enable switch off in Teach Mode

This preference is read-only. It shows whether motors will be turned off when the Enable switch is off during Teach Mode.

Enable robot maintenance data

This preference allows you to enable the parts consumption management for the Controller and robot parts.

The default setting is unchecked.



Initial status (at shipment) of controller firmware Ver.7.2.0.x or later is enabled.

Motor power low when ForcePowerLow signal OFF

This preference allows you to specify whether or not to invert the logic of the ForcePowerLow signal input value.

When this checkbox is selected, the ForcePowerLow signal will work as the forced low power function which operates the robot in the low power mode when remote I/O input signal is Low.

When this checkbox is unchecked, the ForcePowerLow signal will work as the forced low power function which operates the robot in the low power mode when the remote I/O input signal is High.

The default setting is unchecked.

For details of the ForcePowerLow signal, refer to *12.1.6 Remote Inputs*.

ForcePowerLow signal change pauses all tasks

This preference allows you to specify whether to stop or temporarily stop the tasks when the input of the ForcePowerLow (forced low power) signal is changed.

When this checkbox is selected, all tasks and commands will be temporarily stopped when the remote I/O input signal is changed. The program execution can be continued.

When this checkbox is unchecked, all tasks and commands will be stopped when the remote I/O input signal is changed. The program needs to be restarted.

The default setting is unchecked.

For details of the ForcePowerLow signal, refer to *12.1.6 Remote Inputs*.

Reserved tasks for API

This setting is used to execute more than one Spel class methods of the RC+ API.

You can set up to 16 tasks. The default is 0.



The RC+ API tasks use some of the normal tasks. Therefore, if this setting is used, the number of normal tasks available for the Spel+ programs will be as follows:


$$(\text{Normal tasks}) = 32 - (\text{RC+ API tasks})$$

Disable Test (T2)

This preference is read-only. It shows whether the execution of Test (T2) of TP3 is prohibited.


[Setup]-[System Configuration]-[Controller]-[Drive Units]

This page displays the status of the Drive Unit. It shows Output, Robot, and Axis settings of each Drive Unit.



[Setup]-[System Configuration]-[Controller]-[Robots]


[Setup]-[System Configuration]-[Controller]-[Robots]-[Model] page



Item	Description
Model	Displays the robot model.
Type	Displays the robot type.
Reach	Displays the robot length (J1 + J2 for SCARA robots) or reach for 6-axis robots.
Max payload	Displays maximum payload of the robot.
Add	Adds a robot.
Remove	Deletes a robot.
Close	Closes the System Configuration dialog.


[Setup]-[System Configuration]-[Controller]-[Robots]-[Robot**]-[Additional Axes]

For details of the additional ST axis, refer to *10.2 Configuration of Additional Axes*.



Item	Description
S Axis	Displays the configuration of additional S axis.
T Axis	Displays the configuration of additional T axis.
Apply	Saves the current changes.
Restore	Reverts back to previous settings.
Add	Adds an additional axis.
Remove	Deletes an additional axis.
Close	Closes the dialog.


[Setup]-[System Configuration]-[Controller]-[Robots]-[Robot**]-[Configuration]
page



Item	Description
Name	Enter a Name for the robot.
Serial #	Enter the Serial number of the robot.
Joint	These checkboxes determine if the respective joint is enabled or disabled.
Apply	Saves the current changes.
Restore	Reverts back to previous settings.
Close	Closes the Setup Controller dialog.

[Setup]-[System Configuration]-[Controller]-[Robots]-[Robot**]-[Calibration] Page


You can calibrate each joint of the robot from this page.



Item	Description
Joint to Calibrate	Select the joint that you want to Calibrate.
Calibrate	Starts the Calibration Wizard dialog that walks you through the calibration process.
Calpls	These are the Calpls settings for each joint. Normally, the calibration wizard will calculate these values.
Hofs	These are the Hofs settings for each joint. Normally, the calibration wizard will calculate these values.
Load Cal	Use this button to load data from a previously save calibration file. After the data is loaded, the grid will be refreshed to show the values.
Save Cal	Use this button to save the calibration data to a calibration file.
Apply	Saves the current changes.
Restore	Reverts back to previous settings.
Close	Closes the Setup Controller dialog.

[Setup]-[System Configuration]-[Controller]-[Robots]-[Robot**]-[Amplifiers] Page

This page shows the power values for the motor amplifiers installed in the controller.




Item	Description
Robot Amplifiers	This shows the power for each robot amplifier currently in the controller along with the associated drive unit and amplifier number.
Close	Closes the System Configuration dialog.

[Setup]-[System Configuration]-[Controller]-[Inputs / Outputs] Page

This page shows the I/O hardware installed in the controller.

There are no settings to configure.



[Setup]-[System Configuration]-[Controller]-[Inputs / Outputs]-[Fieldbus Master]

For details of Fieldbus master, refer to the following manual:

Robot Controller RC700/RC90 option: Fieldbus I/O manual

[Setup]-[System Configuration]-[Controller]-[Inputs / Outputs]-[Fieldbus Slave]

For details of Fieldbus slave, refer to the following manual:


Robot Controller RC700/RC90 option: Fieldbus I/O manual


[Setup]-[System Configuration]-[Controller]-[Remote Control]

For details of Remote function, refer to 12. Remote Control.

[Setup]-[System Configuration]-[Controller]-[Remote Control]-[Inputs] Page

Use this page to configure the controller remote control inputs.



Item	Description
Input #	Select an input bit to use for the corresponding input signal. Select "Not used" to disable the remote input. For example, if "Start" is assigned to I/O input bit 0, select "Not used" to use this as a normal I/O input.
	
Apply	Saves the current changes.
Restore	Reverts back to previous settings.
Defaults	Click this button to set the default remote inputs. First, a dialog box will be displayed asking you which type of inputs to use for defaults: Standard, Fieldbus master, or Fieldbus slave I/O. You can also select Clear All to set all remote inputs to Not used.
Load	Reads the assigned remote inputs and outputs from a file on the PC and save it in the controller.
Save	Saves the assigned remote inputs and outputs shown in the dialog to a file on the PC.
Close	Closes the Setup Controller dialog.




NOTE

Both the remote inputs and outputs are loaded or saved together when using <Load> or <Save>.

[Setup]-[System Configuration]-[Controller]-[Remote Control]-[Outputs] Page

Use this page to configure the controller remote control outputs.



Item	Description
Output #	Select an output bit to use for the corresponding output signal. Select "Not used" to disable the remote output. For example, if "Ready" is assigned to I/O output bit 0, select "Not used" to use this as a normal I/O output.
Apply	Saves the current changes.
Restore	Reverts back to previous settings.
Defaults	Click this button to set the default remote outputs. First, a dialog box will be displayed asking you which type of outputs to use for defaults: Standard, Fieldbus master, or Fieldbus slave I/O. You can also select <Clear All> to set all remote outputs to "Not used".
Load	Reads the assigned remote inputs and outputs from a file on the PC and save it in the controller.
Save	Saves the assigned remote inputs and outputs shown in the dialog to a file on the PC.
Close	Closes the Setup Controller dialog.




Both the remote inputs and outputs are loaded or saved together when using <Load> or <Save>.

[Setup]-[System Configuration]-[Controller]-[RS232]

[Setup]-[System Configuration]-[Controller]-[RS232]-[PC] Page

Use this page to configure the RS232 ports on PC.




To configure an RS-232 port

1. Select [System Configuration] from the [Setup] menu and select the page for the RS232C port you want to configure.
2. Select the [PC port] and change the settings as desired.
3. Set the [Enable] check box.
4. Click <Apply> to save the new settings and click <Close>.

[Setup]-[System Configuration]-[Controller]-[RS232]-[CU] Page

There is one page for each RS232C port. If there are no RS232C ports installed in the special slot, then no selections are visible in the tree.




To configure an RS-232 port

1. Select [System Configuration] from the [Setup] menu and select the page for the RS232C port you want to configure.
2. Change the settings as desired.
3. Click <Apply> to save the new settings.
4. Click <Close> to close the dialog box.

[Setup]-[System Configuration]-[Controller]-[TCP/IP] Pages

There is one page for each TCP / IP port in the controller.



To configure a TCP/IP port

1. Select [System Configuration] from the [Setup] menu and select the page for the TCP/IP port you want to configure.
2. Enter the host name or IP address for the controller or PC that you want this controller to communicate with.
3. Enter the TCP/IP port number. This must be the same port number that is used on the host device. It must be different from any of the other TCP/IP port numbers used for the other TCP/IP ports.
4. Change the other settings as desired.
5. Click <Apply> to save the new settings and click <Close>.

[Setup]-[System Configuration]-[Controller]-[Conveyor Encoders]

For details, refer to *16. Conveyor Tracking*.

[Setup]-[System Configuration]-[Vision]

For instructions, refer to the following manual.


Vision Guide 7.0 Hardware & Setup 2. Software Configuration

5.12.3 [Preferences] Command (Setup Menu)

The Preferences command opens a dialog that contains several pages that are used to configure user preferences for the EPSON RC+ 7.0 environment. To open the [Preferences] dialog box, select [Setup]-[Preferences].

[Setup]-[Preferences]-[Workspace] Page


From this page, you can configure your workspace preferences.



Item	Description
Auto file save	Checking this box will cause EPSON RC+ 7.0 to automatically save any open files before executing a command that requires the file to be saved. For example, if a file needs to be saved before executing a project build, the file will automatically be saved before running the build. Default is On.
Stop compile after first error	Stops compile after first error occurs. This makes it easier to see the first error in the status pane and allows you to fix one error at a time. Default is On.
Display the shutdown dialog on exit	Displays the shutdown dialog when closing the EPSON RC+ 7.0. For details, refer to 5.6.11 Exit Command (File Menu). Default is Off.
Do not open last project	If this radio button is selected, the last project will not be opened when EPSON RC+ 7.0 is started.
Open last project and program file	If this radio button is selected, the last project will be opened and any program windows that were previously opened will be opened.
Open last project and all windows	If this radio button is selected, the last project will be opened and all windows will be restored to their previous locations. This is the default setting.
Show Tip of the Day	If this check box is on, the Tip of the Day dialog will be displayed when EPSON RC+ 7.0 is started.
Apply	Saves the current changes.
Restore	Reverts back to previous settings.
Default	Sets the default values.
Load	Reads the preferences previously saved on the PC.
Save	Saves the preferences to a file on the PC.
Close	Closes the Preferences dialog.

[Setup]-[Preferences]-[Editor] Page

This page is used to configure your preferences for the program editor windows.




Item	Description
Auto Indent	Check this box if you want new lines to follow the indentation for the previous line. Also, lines will automatically be indented after Do, If, Else, For, Select, and Case statements. Default is on.
Auto End Construct	Check this box if you want EPSON RC+ 7.0 to add the end construct statement for a loop construct. For example, if you enter a For statement, then a Next statement will be added automatically. Default is on.
Margin Indicators	Check this box to display a margin on the left side. This margin is used to indicate lines with breakpoints, current step line, current execution line. Default is on.
Function Separators	Check this box to display a line after each Fend statement. Default is on.
Syntax Help	Check this box to enable the Syntax Help window. The Syntax Help window displays syntax for a keyword after it has been typed. Default is on.
Above Line	Select this button to display the syntax help above the input line.
Below Line	Select this button to display the syntax help below the input line.
Tab Stops	Type in the number of columns to move for the TAB key. Default is 4.
Font	Click on the Font button to open the fonts dialog. Choose the font you desire for the editor. The monitor window also uses the editor font. The current font name and size is displayed next to the button.
Apply	Applies the current settings.
Restore	Reverts back to the previous settings.
Defaults	Sets default value.
Load	Reads the preferences previously saved on the PC.
Save	Saves the preferences to a file on the PC.
Close	Closes the Preferences dialog.

[Setup]-[Preferences]-[Robot Manager]

[Setup]-[Preferences]-[Robot Manager]-[General] Page

This page lets you configure your preferences for the Robot Manager.




Item	Description
Display	Choose if you want the Robot Manager to be displayed as an MDI Window or as a Dialog.
Apply	Applies the current settings.
Restore	Reverts back to the previous settings.
Defaults	Sets default values.
Load	Reads the preferences previously saved on the PC.
Save	Saves the preferences to a file on the PC.
Close	Closes the Preferences dialog

The Robot Manager can be displayed as an MDI child window (default) or as a dialog. When displayed as an MDI child, the Robot Manager is displayed in the MDI document area and can remain open while you work with other windows and dialogs. When displayed as a dialog, you can only work with the Robot Manager controls until you close the dialog. When using screen resolutions less than 1024 × 768, only the Dialog mode is allowed.

[Setup]-[Preferences]-[Robot Manager]-[Jogging] Page

This page lets you configure the Robot Manager Jog and Teach page.



Setting Jog Button Orientation

Item	Description
Robot	Select a robot.

The jog button orientations are useful for “aligning” your PC monitor with the robot’s Cartesian coordinate system. Align the buttons so that the robot moves in the direction of the arrows.

You can change the orientation of the jogging buttons and arrow keys for the X and Y axes by selecting the desired top button from the **Top Button** dropdown list.

You can also click on one of the buttons to change it to the top button position.

Program Mode Options




These options affect the Robot Manager Jog & Teach page when used from program mode.

These settings do not affect the Robot Manager when used for operators in auto mode, such as for the Operator Window or from RC+ API. To configure the Robot Manager for operators, see [Project]-[Properties]-[Operator Settings]-[Robot Manager].

Item	Description
Confirm teach	Check this box if you want a confirmation prompt each time you press the <Teach> button on the Robot Manager Jog & Teach page.
Enable motion commands	Check this box if you want to execute motion commands (Go, Jump, etc.) from the Robot Manager Jog & Teach page.
Prompt for new point information	Check this box if you want to be prompted for point label and description when a new point is taught using the Teach button.
Apply	Applies the current settings.
Restore	Reverts back to the previous settings.
Defaults	Sets default values.
Load	Reads the preferences previously saved on the PC.
Save	Saves the preferences to a file on the PC.
Close	Closes the Preferences dialog.

[Setup]-[Preferences]-[Run Window] Page


This page allows you to change preferences for the Run Window.



Item	Description
Confirm Start	This checkbox allows you to select if you want to see a confirmation message box before a program is started.
Clear text window on start	Checking this will cause the Run Window text pane to be cleared each time the <Start> button is clicked.
Allow multiple tasks to be started	Checking this allows you to start a task from the Run window while other tasks are running. The <Start> button will not be disabled after starting a task.
Font	Click on the button to open the fonts dialog. Choose the font you desire for the Run window. The current font name and size is displayed next to the button.
Apply	Applies the current settings.
Restore	Reverts back to the previous settings.
Defaults	Sets default values.
Restore	Reverts back to the previous settings.
Defaults	Sets default values.
Load	Reads the preferences previously saved on the PC.
Save	Saves the preferences to a file on the PC.
Close	Closes the Preferences dialog.

[Setup]-[Preferences]-[Command Window] Page


This page allows you to change preferences for the Command Window.



Item	Description
Preserve contents	Checking this option will cause the command window to preserve its contents between sessions.
Font	Click on the Font button to change the font for the Command window.
Apply	Saves the current changes.
Restore	Reverts back to the previous values.
Defaults	Set default values.
Load	Reads the preferences previously saved on the PC.
Save	Saves the preferences to a file on the PC.
Close	Closes the Preferences dialog.

[Setup]-[Preferences]-[Language] Page

This page allows you to change the EPSON RC+ 7.0 GUI language.



When EPSON RC+ 7.0 is installed on a Windows system using a Western language, then the English, German, French, and Spanish selections are available.

When it is installed on a Windows system using Japanese, then English and Japanese are available.

When it is installed on a Windows system using Chinese, then English, Chinese (Simplified), and Chinese (Traditional) are available.

After selecting the desired language, you must reboot EPSON RC+ 7.0.

Item	Description
Language	This set of option buttons allows you to choose which language to use for the EPSON RC+ 7.0 GUI.
Apply	Saves the current changes.
Restore	Reverts back to the previous values.
Defaults	Set the default language.
Load	Reads the preferences previously saved on the PC.
Save	Saves the preferences to a file on the PC.
Close	Closes the Preferences dialog.

5.12.4 [Options] Command (Setup Menu)

This dialog allows you to view and enable options in the controller.

EPSON RC+ 7.0 uses a key that is stored in the Spel controller board to enable options on the system.



If an option is not enabled, you can purchase it from the supplier of your region. When you call to purchase, you must give the **Options Key Code** to the operator. You will then be given a code to enable the option for the current software options key.


After receiving the code, click the <OK> button and enter the code. The option you purchased should now be enabled.

5.13 [Window] Menu

The [Window] menu contains selections for managing the currently open EPSON RC+ 7.0 child windows.


5.13.1 [Cascade] Command (Window Menu)

Use Cascade to show all of the currently open files in windows of the same size, stacked one on top of another.




5.13.2 [Tile Vertical] Command (Window Menu)

Use Tile Vertical to evenly display all open windows vertically.




5.13.3 [Tile Horizontal] Command (Window Menu)

Use Tile Horizontal to evenly display all open windows horizontally.



5.13.4 [Arrange Icons] Command (Window Menu)

Arrange the icons for all child windows that have been minimized.




5.13.5 [Close All] Command (Window Menu)

This command closes all EPSON RC+ 7.0 child windows.

5.13.6 1, 2, 3 Command (Window Menu)


A listing of currently open document windows is displayed at the bottom of the [Window] menu.

When you choose an open window from the listing, you make that document active. A check mark appears in front of the document name of the currently active window.



5.13.7 [Windows] Command (Window Menu)

This command displays a dialog that contains a list of all currently open EPSON RC+ 7.0 windows.



Item	Description
Activate	Brings the selected window into focus.
Save	Saves the contents of the selected windows.
Close	Closes the selected windows.
OK	Closes the dialog.

5.14 [Help] Menu

The [Help] menu contains selections for accessing the help system and manuals along with version information.

5.14.1 [How Do I] Command (Help Menu)

Select [How Do I] to view topics that contain information for performing common tasks in EPSON RC+ 7.0.


Shortcuts

Keys: Ctrl + F1

5.14.2 [Contents] Command (Help Menu)

This command opens the Contents view for the EPSON RC+ 7.0 online help system.


From the Contents view, you can navigate through all of the topics in the help system. Double-click on a book icon to open or close the subtopic list contained within the book folder.



5.14.3 [Index] Command (Help Menu)

This command opens the Index view for the EPSON RC+ 7.0 online help system.


From the Index view, as you begin typing in a keyword, the alphabetical topic list will show the keywords starting with the letters you have typed.



5.14.4 [Search] Command (Help Menu)

This command opens the Search view for the EPSON RC+ 7.0 online help system.

From the Search view, you can type in one or more keywords and click List Topics to show a list of all topics containing one or more of the keywords. The keywords are highlighted in the topics as shown below.



5.14.5 [Manuals] Submenu (Help Menu)

The Help Menu Manuals submenu contains selections for each of the manuals in Adobe PDF format. These include manuals for EPSON RC+ 7.0, SPEL⁺ Language Reference, Controller, Robot, and the Options.

5.14.6 [About EPSON RC+ 7.0] Command (Help Menu)

The About command displays a dialog box showing the current version of the EPSON RC+ 7.0 software, along with copyright and license information. When calling technical support about EPSON RC+ 7.0, you should report the version you are using from this dialog.



6. The SPEL+ Language

This chapter contains information about the SPEL+ Language.

Contents

- Overview
- Program structure
- Commands and statements
- Function and variable names
- Data types
- Operators
- Working with variables
- Working with strings
- Multi-statements
- Labels
- Comments
- Error handling
- Multi-tasking
- Robot coordinate systems
- Robot arm orientations
- Robot motion commands
- Working with robot points
- Input and output control
- Using Traps

6.1 Overview

SPEL+ is a BASIC-like programming language that runs in the controller. It supports multitasking, motion control, I/O control.

Programs are written in ASCII text and then compiled into executable object files. Several language instructions can also be executed in immediate mode from the Command window.

6.2 Program Structure

6.2.1 What is a SPEL+ program?

A SPEL+ program is a collection of functions, variables, and macros. You can put one or more statement in each line of a program (Multi-Statement). Every program file has a “.prg” extension and is stored in the project directory.

Each project must include at least one program and define the function called "main". "Function main" is the default definition. If “Function main” is not found, an error occurs.

In addition, you can define other 63 main functions in the same project. Each program has own start function: main1, main2...main63. Each of the main functions can be started from the [Operator window], the remote console, or RC+ API.

A function definition begins with the Function statement and ends with the Fend statement.

The following program file contains two function definitions. Function Main calls function “Func1”.

```
MAIN.PRG
Function Main
    Call Func1
    ...
Fend
Function Func1
    Jump pickpnt
    ...
Fend
```

6.2.2 Calling functions

You can execute a user function by using the Call statement. The function can reside in any program file in the current project. You can also omit the Call statement if you don't need the return value. When Call is omitted, then parentheses for the arguments must not be supplied. To get a return value, use the function in the right hand side of an expression.

Here are some examples:

```
Call MyFunc(1, 2)
MyFunc 1, 2
Print MyFunc(1, 2)
```

6.3 Commands and Statements

Commands and statements consist of a SPEL+ instruction followed by the parameters for that instruction.

A command is executed immediately. You can execute commands from the Command window or from the Macros dialog box.

Statements can be used only in programs.

Statements can include more than one SPEL+ instruction. When you put several statements in a line of a program (Multi-Statement), use a semi-colon (;) to separate instructions.

The maximum length for a line is 512 characters.

6.4 Function and Variable Names (Naming restriction)

The function name can include up to 64 characters. The variable name can include up to 32 alphanumeric, Japanese, or underscore characters. Characters can be upper case or lower case.

The following names are valid:

```
Function main
Real real_var
Integer IntVar
```

Function and variable names cannot begin with an underscore.

SPEL+ keywords cannot be used as function or variable names.

String variables must have an additional dollar sign ('\$') suffix, as shown in the example below:

```
Function Test
String modname$
Print "Enter model name:"
Line Input modname$
Print "model is ", modname$
Fend
```

Restrictions for naming in SPEL+ language

- Characters can be alphanumeric, Japanese, or underscore character.
- Use alphabets for the first letter.
- Characters can be upper case or lower case.
- No keywords can be used.
- Maximum limits of names are as follows. (For one –byte character)

Name	Max. limit
Point label	32
I/O label	32
User error label	16
Function name	64
Variable name	32
Line label	32

6.5 Data Types

You can declare different types of data in your program. All variables must be declared.

The following table shows the different data types for the SPEL+ language.

Data Type	Size	Range
Boolean	2 byte	True or False
Byte	2 byte	-128 to +127
Double	8 bytes	-1.79E+308 to 1.79E+308 Number of significant figure is 14
Int32	4 bytes	-2147483648 to +2147483647
Int64	8 bytes	-9223372036854775808 to +9223372036854775807
Integer	2 bytes	-32768 to +32767
Long	4 bytes	-2147483648 to +2147483647
Real	4 bytes	-3.40E+38 to 3.40E+38 Number of significant figure is 6
Short	2 bytes	-32768 to +32767
String	256 bytes	All ASCII characters Up to 255 characters
UByte	2 bytes	0 to +255
UInt32	4 bytes	0 to 4294967295
UInt64	8 bytes	0 to 18446744073709551615
UShort	2 bytes	0 to 65535

6.6 Operators

The following table shows the operators for the SPEL+ language.

Keyword or Symbol	Example	Description
+	A+B	Addition
-	A-B	Subtraction
*	A*B	Multiplication
/	A/B	Division
**	A**B	Exponentiation
=	A=B	Equal
>	A>B	Greater than
<	A<B	Less than
>=	A>=B	Greater than or equal
<=	A<=B	Less or than equal
<>	A<>B	Not equal
And	A And B	Performs logical and bitwise AND operation.
Mod	A Mod B	Returns the remainder obtained by dividing a numeric expression by another numeric expression.
Not	Not A	Performs logical or bitwise negation of the operand.
Or	A Or B	Performs the bitwise Or operation on the values of the operands.
Xor	A Xor B	Performs the bitwise Xor operation on the values of the operand.

6.7 Working with Variables

6.7.1 Variable scopes

There are three different scopes for variables in SPEL⁺:

- Local
- Module
- Global

6.7.2 Local variables

Local variables are available to all statements in the same function. Functions using local variable names cannot refer to the same local variables in other functions. This is why they are called locals, because they are local to the function they are being used in.

To declare local variables in a function, use one of the variable declaration instructions at the beginning of the function after the Function statement:

Boolean, Byte, UByte, Integer, Short, UShort, Long, Int32, UInt32, Int64, UInt64, Real, Double, String

For example, the following function declares several local variables:

```
Function test
  Integer intVar1, intVar2
  Real realVar
  String dataStr$
  Integer array(10)
  .....
Fend
```

6.7.3 Module variables

Module variables are available to all functions in the same program file.

To declare module variables in a program, use one of the variable declaration instructions at the beginning of the program before any Function statements:

Boolean, Byte, UByte, Integer, Short, UShort, Long, Int32, UInt32, Int64, UInt64, Real, Double, String



In order to indicate that a variable is module level, precede the name with "m_", as shown in the example below. With this, you can improve the program readability.

For example, the following function declares several module level variables:

```
' Module level vars, used by all functions in this file
Integer m_IntVar1, m_IntVar2
Real m_RealVar
String m_DataStr$
Integer m_Array(10)
Function main
  m_IntVar1 = 25
  Call test
Fend

Function test
  Print m_IntVar1
Fend
```

6.7.4 Global variables

Global variables can be shared between all functions in a project. The Global instruction is used to declare a global variable.

To declare global variables in a program, use the Global instruction with the desired variable type (Boolean, Byte, UByte, Integer, Short, UShort, Long, Int32, UInt32, Int64, UInt64, Real, Double, String) at the beginning of the program before any Function statements:



TIP

In order to indicate that variables are global, precede the name with "g_", as shown in the example below. With this, you can improve the program readability.

Program: MAIN.PRG

```
Global Integer g_TotalCycles
Function main
  Call LoadPart
  :::
Fend
```

Program: LOADPART.PRG

```
Function LoadPart
  Jump pick
  On gripper
  Wait .1
  Jump place
  Off gripper
  Wait .1
  g_TotalCycles = g_TotalCycles + 1
Fend
```

For more information, see Data Types.

6.7.5 Global Preserve variables

You can preserve global variable values by using the optional Preserve parameter when you declare global variables.

Preserved variables are stored in the controller's SRAM.

If the data type of a preserved variable or the number of dimensions is changed, the variable values will be cleared.



NOTE

Be careful about the backup battery power, because you will lose the data of global preserve variables stored in SRAM if the battery is weak.

6.7.6 Arrays

You can declare local, module, and global variables with up to three dimensions as arrays for all data types.

To declare an array, use this syntax:

dataType name (ubound1 [, ubound2 [, ubound3]])

SPEL+ arrays are zero based. The first element is referenced with a value of zero.

The total available number of array elements for local variables is 200 for strings and 2000 for all other types.

The total available number of array elements for global preserve variables is 400 for strings and 4000 for all other types.

The total available number of array elements for global and module variables is 10,000 for strings and 100,000 for all other types.

To calculate the total elements used in an array, use the following formula. (If a dimension is not used, substitute 0 for the ubound values.)

$\text{total elements} = (\text{ubound1} + 1) * (\text{ubound2} + 1) * (\text{ubound3} + 1)$

Array declaration examples:

```
' Global string array
Global String gData$(10)
Function main
  ' Arrays local to this function
  Integer intArray(10)
  Real coords(20, 10)
```

Use Redim to change the bounds of an array at run time.

```
Integer a(10)
Redim a(20)
```

To preserve values when using Redim, add the Preserve optional argument.

```
Integer a(10)
Redim Preserve a(20)
```

Use UBound to get the maximum element number.

```
Integer i, a(10)
For i = 1 to UBound(a)
  a(i) = i
Next i
```

6.7.7 Initial values

All variables are initialized when first used except for Global Preserve variables. Strings are set to empty, and all other variables are set to zero.

6.7.8 Clearing arrays

Execute Redim (without Preserve) to clear all of the elements of array variables.

6.8 Working with Strings

A string in SPEL+ is a set of ASCII characters (Code &h01 ~ &hff) with a maximum length of 255.

You must declare strings in your programs with the String instruction.

All string variable names must end with a dollar sign (\$) suffix.

The following table shows the string commands available in SPEL+.

Keyword	Description
Asc	Returns the decimal ASCII value of the first character in a string.
Chr\$	Converts an ASCII value into a one character string.
FmtStr	Formats a numerical or date/time expression.
FmtStr\$	Formats a numerical or date/time expression.
Hex\$	Returns a string containing the hexadecimal value of a number.
InStr	Returns the position of a substring within a string.
LCase\$	Returns the specified string in lower case characters.
Left\$	Returns a substring beginning with the first character of a string.
Len	Returns the length (number of characters) of a string.
LTrim\$	Returns the specified string with left spaces removed.
Mid\$	Returns a substring of a string.
ParseStr	Parses a string into an array of tokens.
Right\$	Returns a substring from the end of a string.
RTrim\$	Returns the specified string with right spaces removed.
Space\$	Returns a string containing a specified number of space (ASCII 32) characters.
Str\$	Converts a number to a string.
String	Declare a string variable in a program.
Tab\$	Returns a tab string.
UCase\$	Returns the specified string in upper case characters.
Val	Converts a string to a number.

6.9 Working with Files

SPEL+ has several commands for handling files.

Keyword	Description
AOpen	Opens a file for append.
BOpen	Opens a file for binary access.
Close	Closes a file.
FileExists	Checks if a file exists.
FolderExists	Check if a folder exists.
FreeFile	Returns an unused file handle.
Input	Inputs one or more variables from a file
Kill	Deletes a file.
Line Input	Inputs line from a file.
Read	Reads a specified number of bytes into a string variable.
ReadBin	Reads binary data.
ROpen	Opens a file for reading.
Seek	Sets the current file pointer.
Flush	Writes data buffer to disk.
WOpen	Opens a file for writing.
Write	Writes out a variable at the current file pointer without appending a line terminator.
WriteBin	Writes binary data.

Before using a file you must open it with one of the following commands: AOpen, Bopen, ROpen, and WOpen. And specify a file number in the Open statement. File number can be 30 ~ 63.

Here is an example to save a text file and read it.

```
String data$(10)
```

```
Function SaveData()  
  Integer fNum, i  
  
  fNum = FreeFile  
  WOpen "c:\mydata\data.txt" As #fNum  
  ' Store the count  
  Print #fNum, UBound(data$)  
  For i = 0 To UBound(data$)  
    Print #fNum, data$(i)  
  Next i  
  Close #fNum  
Fend
```

```
Function LoadData()  
  Integer fNum, i  
  
  fNum = FreeFile  
  ROpen "c:\mydata\data.txt" As #fNum  
  Input #fNum, i  
  Redim data$(i)  
  For i = 0 To UBound(data$)  
    Input #fNum, data$(i)  
  Next i  
  Close #fNum  
Fend
```

6.10 Multi-statements

A program statement can contain several statements separated by semi-colons. The total length of a multi-statement program line cannot exceed 255 characters.

For example:

```
Function Test
    Pass P1; Pass P2; Go P3      ' Multi-statement
Fend
```

It is not recommended to use multi-statements. Multi-statements can make your code more difficult to read and debug.

6.11 Labels

A program line is an alphanumeric name followed by a colon (":") that marks a location in a program for a GoTo or GoSub statement. The name may be up to 32 characters long and can include alphanumeric characters and the underscore ("_") character if it is not the first character. You cannot use any SPEL+ keywords as labels.

For example:

```
Function Main
    Do
        Jump P1
        Jump P2
        If Sw(1) Then GoTo MainAbort
    Loop
MainAbort:    ' Program label
    Print "Program aborted"
Fend
```

6.12 Comments

Use comments to add notes to your programs. An apostrophe character (') starts a comment.

Example:

```
Function Main
    ' ***** Main Demo Program *****
    Xqt conveyor      ' Start up the task for conveyor
    Do
        Print "Press ENTER to run demo cycle"
        Print "Press CTRL+C to quit"
        Input dummy
        Call demo      ' Execute the demo function
    Loop              ' Return to start of main loop
```

6.13 Error Handling

When an error occurs in a SPEL+ function, you can cause execution to be transferred to an error handling routine for processing the error. The routine must be inside a function definition.

The table on the next page shows the program instructions that are used for error handling.

Item	Purpose
OnErr	Use the OnErr statement to define the location of the error handling routine.
Err	Use Err to retrieve the number for the current error status. Use this in the error handling routine to determine which error has occurred.
Error	Generate a user defined error which can be caught by an error handler.
Era	Use Era to retrieve the axis number for which the error occurred. This is normally used in the error handling routine.
Erl	Use Erl to retrieve the line number in which the error occurred. This is normally used in the error handling routine.
Ert	Use Ert to retrieve the task number in which the error occurred. This is normally used in the error handling routine.
ErrMsg\$	Use ErrMsg\$ to retrieve the error message associated with a specified error number.
Errb	Use Errb to retrieve the robot number in which the error occurred. This is normally used in the error handling routine.

User Errors

You can define your own error messages by using the User Error Editor which is available from the Tools Menu. For details refer to *5.11.7 User Error Editor Command (Tools Menu)*.

Example

The following example shows a simple error handling routine. When an error occurs, program execution goes to the ErrHandler label, where the error handler starts. The error number is displayed and the operator is asked to continue or not. If the operator enters "N" then the program executes the Quit All statement to end the program.

```
Function Main
  String cont$
  Integer i
  OnErr Goto Errhandler
  For i = 1 To 10
    Jump P(i)
  Next i
  Exit Function
' *** Error handler ***
Errhandler:
  enum = Err
  Print "Error #", enum, " occurred"
  Print "Continue (Y or N)?"
  Line Input cont$
  Select cont$
    Case "y", "Y"
      EResume Next
    Default
      Quit All
  Send
Fend
```

6.14 Multi-tasking

For some applications, you may want to control other equipment besides the robot, such as conveyors, pick and place units, etc. By using multi-tasking, you can control this other equipment with their own tasks.

SPEL⁺ supports up to 32 normal tasks and 16 background tasks (48 tasks in total) running simultaneously. A task is a function that has been started by the system or by the Xqt statement.

Use the Xqt statement to start another task from within a function. You can optionally specify a task number from 1 to 32 in the Xqt statement.

A task started from a background task is started as a background task. You can execute up to 16 background tasks simultaneously.

The table below shows the program instructions that are used for multitasking.

Statement	Purpose
Xqt	Starts a function as a task.
Halt	Temporarily suspends execution of a task.
Resume	Resumes a task that has been halted.
Quit	Stops a task.
Signal	Sends a signal to one or more tasks that are waiting for the signal using WaitSig.
SyncLock	Locks a resource for use by the current task and blocks other tasks from using the resource until SyncUnlock is executed.
WaitSig	Waits for a signal from another task.
Pause	Pause all tasks.

One example for starting another task is to run a conveyor system for the robot work cell.

Program: MAINTASK.PRG

```
Function Main
  Xqt Conveyor          ' Start the conveyor task
  Do
    ...
    ...
  Loop
Fend
```

Program: CONVTASK.PRG

```
Function Conveyor
  Do
    Select True
      Case Sw(10) = On
        Off convCtrl
      Case Sw(11) = On
        On convCtrl
    Send
  Loop
Fend
```

6.15 Using Multiple Robots

You can control more than one robot in the same project. Use the Robot statement to switch the current robot for the current task. For most applications, you should use a separate task for each robot.

Each robot has its own set of point files. You can configure which point files to use in the Project Editor. The default point file you configure for each robot is automatically loaded into memory when the main task is started.

The following program is an example where two robots run simultaneously, each with its own task.

```
Function main
```

```
    Xqt Robot1
```

```
    Xqt Robot2
```

```
Fend
```

```
Function Robot1
```

```
    Robot 1
```

```
    Speed 50
```

```
    Do
```

```
        Jump pick
```

```
        On gripper1
```

```
        Wait .1
```

```
        Jump place
```

```
        Off gripper1
```

```
        Wait .1
```

```
    Loop
```

```
Fend
```

```
Function Robot2
```

```
    Robot 2
```

```
    Speed 50
```

```
    Do
```

```
        Jump pick
```

```
        On gripper2
```

```
        Wait .1
```

```
        Jump place
```

```
        Off gripper2
```

```
        Wait .1
```

```
    Loop
```

```
Fend
```

6.16 Coordinate Systems

6.16.1 Overview

This section describes the coordinate systems for different types of robots supported in SPEL+. Right-handed rule is used for all coordinate systems.

The following coordinate systems are used in SPEL+:

Robot Coordinate System	This is the native coordinate system of the robot. This is also known as the default base coordinate system or world coordinate system.
Local Coordinate System	This is a user defined coordinate system located somewhere within the working envelop.
Tool Coordinate System	This is the coordinate system of the tool mounted on the robot end-effector. This is also known as the end effector coordinate system.






Figure: Transform order of the position/orientation from origin to tool.

6.16.2 Robot Coordinate Systems


Robot Coordinate System of SCARA Robot



Robot coordinate system Z axis




Robot coordinate system U axis




Robot Coordinate Systems of 6-Axis Robot


Table Top Mounting



Ceiling Mounting



Side (Wall) Mounting



In the robot coordinate system, +Z axis is defined in the opposite direction of gravity. X and Y axes are defined in horizontal plane as shown in the figures above.


The position and orientation are designated by the position data (X, Y, Z) and the orientation data (U, V, W).

Roll-Pitch-Yaw angles are used for the orientation data.


U corresponds to roll (Z-axis rotation), V corresponds to pitch (Y-axis rotation), and W corresponds to yaw (X-axis rotation).

The orientation is designated by rotating the coordinate axis of U, V, and W, in that order (movable axis expression).


Robot Coordinate System of Ceiling Mounting SCARA Robot (RS series)



Robot coordinate system Z axis




Robot coordinate system U axis



Robot Coordinate Systems of N Series Robot

Ceiling Mounting

Table Top Mounting



6.16.3 Local Coordinate Systems

This is a user defined coordinate system.

With SPEL⁺, up to 15 relative positional relationships from the robot coordinate system can be defined as local coordinate systems.

Point data is assigned with a local number from 1 to 15 as the local coordinate system, and the numbers can be used for point data attributes.

For example, program change can be minimized by using the local coordinate system, even when the robot orientation and position are changed.

To define a local coordinate system, use the Local statement or Robot Manager of the EPSON RC⁺.

The local coordinate system “0” matches the robot coordinate system (Base). Therefore, when “0” is used for the local number in the point editor or simulator, it is same as specifying the robot coordinate system.

6.16.4 Tool Coordinate Systems

This is the coordinate system of the tool mounted on the Joint #6 flange.

Point data is defined by the position and orientation of the tool coordinate system with respect to a robot coordinate system or a local coordinate system. The position is specified by the position data (X, Y, Z) and the orientation is specified by the orientation data (U, V, W) that correspond with roll, pitch, and yaw.


You can also define and use your own tool coordinate systems. To define the tool coordinate systems, use Tlset or Robot Manager of the EPSON RC+.

The default TOOL 0 coordinate systems are defined as follows according to the robot type.

SCARA Tool 0 coordinate system

The origin of tool 0 for SCARA robots is the center of the forth joint (rotation joint). When the fourth joint is adjusted to the position of 0 degrees, the tool 0 coordinate system axes are parallel to the robot coordinate system axes (see the figure below.)

The tool 0 coordinate system rotates as the fourth joint rotates.



6-axis Tool 0 coordinate system

Table and ceiling mounting robots:


The origin of tool 0 is the center of the flange on the sixth joint. When all joint angles are 0 degree, the vertically upward direction is the tool X axis, the tool Y is the same direction of X axis in the base coordinate system, and the tool Z axis is perpendicular to the sixth joint flange. (See the figure below).

The tool 0 coordinate system moves as the 6-axis robot changes its orientation.


Wall mounting robots:

The tool 0 coordinate system is defined as below. (tl: abbreviation of Tool)


Table Top Mounting



Ceiling Mounting



Side (Wall) Mounting



N series Tool 0 coordinate system

Ceiling mounting robots:

When all joint angles are 0 degree, the tool 0 coordinate system has the X axis in $-X$ axis direction, Y axis in the Y axis direction, and the Z axis in the $-Z$ axis direction on the robot coordinate system. (See the figure below)

Table top mounting:

When all joint angles are 0 degree, the tool 0 coordinate system has the X axis in $-X$ axis direction, Y axis in the Y axis direction, and the Z axis in the Z axis direction on the robot coordinate system. (See the figure below)

Ceiling Mounting





Table Top Mounting




6.16.5 ECP Coordinate Systems (Option)

Specify a coordinate system whose origin point is on the tip of the outside fixed tool (hereafter referred to as the external control point or ECP) to move the robot arm holding a part in the trajectory made on the external control point along with the part's edges.

The following figures give a concrete example.

An ordinal Move statement controls the moving speed and orientation change of the tool center point (TCP). In the case of Move statement with the ECP argument, the part's edge is controlled to take a straight and constant-speed trajectory instead of TCP. In the following example of no ECP, TCP takes a straight trajectory but the part's edge is distant from ECP.

If there is no orientation change, the trajectory is the same as normal operation of Move command.



The following commands are available for optional ECP:

- Move command
- Arc3 command
- Curve and CVMove commands
- ECP jog motion in Robot Manager

Use the ECPSet statement for defining an ECP coordinate system. A maximum of 15 ECP coordinate systems can be defined.


For details, refer to *17. ECP Motion*.

6.17 Robot Arm Orientations

When developing a robot program, it is necessary to specify the point data taught for a particular arm orientation. If you fail to do so, the position can deviate slightly depending on the arm orientation, which in turn can cause the arm to follow an unexpected path, resulting in interference with peripheral equipment. This can be dangerous! To prevent this from happening, the orientation that the arm will be in when moved to the given point should be specified ahead of time in the point data. Such information can also be changed from the program.

6.17.1 SCARA robot arm orientations

With two types of arm orientation, a SCARA robot can move to nearly any position and orientation within a given work envelope. Examples are shown in the figures on the next page.











Lefty arm orientation

Righty arm orientation


Examples of moving to the same point using Lefty and Righty arm orientations

6.17.2 6-axis robot arm orientations

The 6-axis robot can be operated in different arm orientations within a given work envelope as shown below:

	Righty hand orientation (Arm #1)	
	NoFlip wrist orientation	Flip wrist orientation
Above elbow orientation		
Below elbow orientation		
	Lefty hand orientation (Arm #1)	
	NoFlip wrist orientation	Flip wrist orientation
Above elbow orientation		
Below elbow orientation		

The following enlarged figures of right hand orientation are to assist understanding.



To specify orientation for the 6-axis robot, add a forward slash (/) followed by L (for Lefty hand orientation) or R (Righty hand orientation), A (Above elbow orientation) or B (Below elbow orientation), and NF (NoFlip wrist orientation) or F (Flip wrist orientation).

There are eight available orientations as shown below, however, the 6-axis robot cannot be operated in all of the orientations depending on point.

Available Orientation

1	/R /A /NF	5	/R /A /F
2	/L /A /NF	6	/L /A /F
3	/R /B /NF	7	/R /B /F
4	/L /B /NF	8	/L /B /F

At some points in the work envelope, the 6-axis robot can have the same position and orientation even if the fourth joint or the sixth joint is rotated 360 degrees. To distinguish these points, the J4Flag and J6Flag point attributes are provided.

To specify the J4Flag, add a forward slash (/) followed by J4F0 (-180 < the forth joint angle <= 180) or J4F1 (the forth joint angle <= -180 or 180 < the forth joint angle).

To specify the J6Flag, add a forward slash (/) followed by J6F0 (-180 < the sixth joint angle <= 180), J6F1 (-360 < the sixth joint angle <= -180 or 180 < the sixth joint angle <= 360), or J6Fn (-180*(n+1) < the sixth joint angle <= 180*n or 180*n < the sixth joint angle <= 180*(n+1)).


Singularity

The orientation in the boundary where the arm orientation switches to the other.


Hand singularity : The boundary where Righty hand orientation and Lefty hand orientation switch

Elbow singularity : The boundary where Above elbow orientation and Below elbow orientation switch


Wrist singularity : The boundary where NoFlip wrist orientation and Flip wrist orientation switch



Hand singularity



Elbow singularity



Wrist singularity


For the 6-axis robot, Hand / Wrist singularities exist also inside the motion range. When jogging near the singularity, follow the directions below.

PTP motion near the singularity


When jogging a robot from point P1 near the singularity to a point calculated by point operations such as $P1+X(10)$, the robot may move to unintended direction because the arm orientation is not properly specified.

For example, when jogging from a point where the wrist is NoFlip to another point calculated by point operations, if the wrist keeps the NoFlip orientation while jogging, Joints #4 and #6 may rotate widely (by approx. 180 degrees).

In this case, switch to the Flip wrist orientation to jog smoothly through the wrist singularity. This phenomenon occurs not only with the point operations but also when creating points automatically with Pallet command or the result values that run from vision sequence.



Proper motion



Unintended motion (Joints #4 and #6 rotate 180 degrees)

However in the cases, it is difficult for users to specify the proper arm orientations by a program. For this LJM function is a useful command. LJM function switches the arm orientations to enable the least motion of the joints. For the details of LJM function, refer to *SPEL+ Language Reference manual*.

Also, AutoLJM command can automatically apply LJM function to the motion commands which are included in a particular section of the program without using LJM function. For details of AutoLJM command, refer to the *SPEL+ Language Reference*.

In addition, you can set AutoLJM function to be enabled at the controller start up by setting preferences of the controller. However, if Auto LJM is enabled in preferences, this function automatically adjusts the posture of the manipulator to reduce the motion distance, even when you intend to move the joint widely. Therefore, it is recommended to build a program using AutoLJM command or LJM function to operate the manipulator as you desired.

If you specify all points by teaching, the arm orientations are also recorded. Therefore, the manipulator moves to the taught position without using LJM function or AutoLJM. Instead, the manipulator may move differently from the taught position by the use of LJM and AutoLJM.

LJM function for CP motion command

LJM function and AutoLJM command described above are also available for CP motion commands. However, since CP motion commands give priority to operate based on specified trajectories, the manipulator sometimes reach to the point with a different posture from the specified one. At this time, if CP motion command is used with CP On, an error from 4274 to 4278 will occur according to the mismatched point flag. To avoid the error, operate the manipulator with CP Off, or match the point flag of a target point and the one after motion completion. If operated with CP Off, the error does not occur and the manipulator can continue operation from the point where the mismatch happened.

Also, you can set the controller's preference so that the mismatches of flags are not considered as an error at the controller startup. However, path motions which use CP On will be disabled.

CP motion near the singularity (singularity avoiding function in CP motion)

When executing Move or CP motion near the singularity, the joint speed may increase rapidly. The overspeed error will occur and the joints will move widely and interfere with peripherals. In particular, the position of Joint #1 near the hand singularity and Joints #2 - #6 near the wrist singularity change greatly.


EPSON RC+ 7.0 has a singularity avoiding function to prevent acceleration errors during the execution of CP motion commands that pass the wrist singularity described above. With this function, the manipulator takes a detour to avoid an acceleration error by passing a different trajectory and returns to the original trajectory after passing the singularity. For details of the singularity avoiding function, refer to *AvoidSingularity* in the *SPEL+ Language Reference*.

Singularity avoiding function is enabled as default. If you want to avoid the error by reducing the motion speed in order to maintain the trajectory accuracy, you can disable the function temporarily by setting "0" to AvoidSingularity.


If you cannot avoid errors even if you use the singularity avoiding function, use PTP motion to enable the least motion of the joints or arrange the manipulator installation position and hand offset volume to prevent the CP motion near the singularity.

6.17.3 RS series arm orientations


The RS series can be operated in various arm orientations within a given work envelope as shown below:




Lefty arm orientation




Righty arm orientation




J1 F0 arm orientation



J1 F1 arm orientation



J2 F0 arm orientation



J2 F1 arm orientation

To specify the arm orientation of the RS series, add a forward slash (/) followed by:

- L (for Lefty hand orientation) or R (Righty hand orientation)
- J1F0 or J1F1
- J2F0 or J2F1.

For the RS series robots, some points in the work envelope can have the same position and orientation even if J1 or J2 is rotated 360 degrees.

To distinguish these points, the J1Flag and J2Flag point attributes are provided.

To specify the J1Flag, add a forward slash (/) followed by:

- J1F0 ($-90 < \text{the first joint angle} \leq 270$), or
- J1F1 ($-270 < \text{the first joint angle} \leq -90$ or $270 < \text{the first joint angle} \leq 450$)

To specify the J2Flag, add a forward slash (/) followed by:

- J2F0 ($-180 < \text{the second joint angle} \leq 180$), or
- J2F1 ($-360 < \text{the second joint angle} \leq -180$ or $180 < \text{the second joint angle} \leq 360$)

There are eight available orientations as shown below.

Note that some combinations are not available depending on the point.


Available Orientation

1	/R /J1F0 /J2F0	5	/R /J1F0 / J2F1
2	/L /J1F0 /J2F0	6	/L /J1F0 / J2F1
3	/R /J1F1 /J2F0	7	/R /J1F1 / J2F1
4	/L /J1F1 /J2F0	8	/L /J1F1 / J2F1

Singularity

The orientation in the boundary where the arm orientation switches to the other.

Hand singularity : The boundary where Righty hand orientation and Lefty hand orientation switch ($X=0, Y=0$)



Hand singularity

When jogging near the singularity, follow the directions below.

PTP motion near the singularity

When jogging a robot from point P1 near the singularity to a point calculated by point operations such as P1+X(10), the robot may move to unintended direction because the arm orientation is not properly specified.

For example, when jogging from a point where the hand is Righty to another point calculated by point operations, if the hand keeps the Righty orientation while jogging, Joints #1 may rotate widely (by approx. 180 degrees). In this case, switch to the Lefty hand orientation to jog smoothly through the wrist singularity.

This phenomenon occurs not only with the point operations but also when creating points automatically with Pallet command or the result values that run from vision sequence.

However in the cases, it is difficult for users to specify the proper arm orientations by a program. For this LJM function is a useful command. LJM function switches the arm orientations to enable the least motion of the joints. For the details of LJM function, refer to *SPEL+ Language Reference manual*.

Also, AutoLJM command can automatically apply LJM function to the motion commands which are included in a particular section of the program without using LJM function. For details of AutoLJM command, refer to the *SPEL+ Language Reference*.

In addition, you can set AutoLJM function to be enabled at the controller start up by setting preferences of the controller. However, if Auto LJM is enabled in preferences, this function automatically adjusts the posture of the manipulator to reduce the motion distance, even when you intend to move the joint widely. Therefore, it is recommended to build a program using AutoLJM command or LJM function to operate the manipulator as you desired.

If you specify all points by teaching, the arm orientations are also recorded. Therefore, the manipulator moves to the taught position without using LJM function or AutoLJM. Instead, the manipulator may move differently from the taught position by the use of LJM and AutoLJM.

CP motion near the singularity (singularity avoiding function in CP motion)

When executing Move or CP motion near the singularity, the joint speed may increase rapidly. The overspeed error will occur and the joints will move widely and interfere with peripherals. In particular, the position of Joint #1 near the hand singularity changes greatly.

EPSON RC+ 7.0 has a singularity avoiding function to prevent acceleration errors during the execution of CP motion commands that pass the hand singularity described above. With this function, the manipulator takes a detour to avoid an acceleration error by passing a different trajectory and returns to the original trajectory after passing the singularity. For details of the singularity avoiding function, refer to *AvoidSingularity* in the *SPEL+ Language Reference*.

Singularity avoiding function is enabled as default. If you want to avoid the error by reducing the motion speed in order to maintain the trajectory accuracy, you can disable the function temporarily by setting "0" to AvoidSingularity.

If you cannot avoid errors even if you use the singularity avoiding function, use PTP motion to enable the least motion of the joints or arrange the manipulator installation position and hand offset volume to prevent the CP motion near the singularity.

6.17.4 N series arm orientations

The N series can be operated in various arm orientations within a given work envelope as shown below:


Orientation of N series is different depending on “with” and “without” offset.

Offset is a distance between Joint #2 and Joint #1.


With offset: Distance from Joint #2 and Joint #1 is not 0mm

Without offset: Distance from Joint #2 and Joint #1 is 0mm

Orientation example of “with” and “without” offset is as follows:







With offset




Without offset

Without offset (Illustrations: N2-A450SR)

		Arm orientation	
		Righty arm orientation	Lefty arm orientation
Elbow orientation	Above		
	Below		

With offset (Illustration: N6-A1000S)



To specify orientation for the N series robot, add a forward slash (/) followed by L (for Lefty hand orientation) or R (Righty hand orientation), A (Above elbow orientation) or B (Below elbow orientation), and NF (NoFlip wrist orientation) or F (Flip wrist orientation).

There are eight available orientations as shown below, however, the 6-axis robot cannot be operated in all of the orientations depending on point.

Available Orientation

1	/R /A /NF	5	/R /A /F
2	/L /A /NF	6	/L /A /F
3	/R /B /NF	7	/R /B /F
4	/L /B /NF	8	/L /B /F

At some points in the work envelope, the 6-axis robot can have the same position and orientation even if the fourth joint or the sixth joint is rotated 360 degrees. To distinguish these points, the J4Flag and J6Flag point attributes are provided.

To specify the J4Flag, add a forward slash (/) followed by J4F0 (-180 < the forth joint angle <= 180) or J4F1 (the forth joint angle <= -180 or 180 < the forth joint angle).

To specify the J6Flag, add a forward slash (/) followed by J6F0 (-180 < the sixth joint angle <= 180), J6F1 (-360 < the sixth joint angle <= -180 or 180 < the sixth joint angle <= 360), or J6Fn (-180*(n+1) < the sixth joint angle <= 180*n or 180*n < the sixth joint angle <= 180*(n+1)).


Singularity

The orientation in the boundary where the arm orientation switches to the other.


Hand singularity : The boundary where Righty hand orientation and Lefty hand orientation switch

Elbow singularity : The boundary where Above elbow orientation and Below elbow orientation switch


Wrist singularity : The boundary where NoFlip wrist orientation and Flip wrist orientation switch



Hand singularity



Elbow singularity




Wrist singularity

For the N series robot, Hand / Wrist singularities exist also inside the motion range like the 6-axis robot. When jogging near the singularity, pay attention to the same points as the 6-axis robot. For details, refer to 6.17.2 6-axis robot arm orientations.

The following describes the elbow singularity area which is unique for N series robot.

Elbow singularity area

For the N series robot, the singularity exists where the P point is on the sphere shown in the figure below. The P point cannot be inside the sphere. Therefore, CP motion to pass inside the sphere is not available.



Elbow singularity area avoidance motion

When the robot passes through the sphere as shown in the figure below, the robot behaves differently depending on the mode of singularity avoiding function (AvoidSingularity).

Mode: SING_AVOID


The robot moves to the end point while avoiding the elbow singularity area as indicated with a red line (P-point trajectory) in the figure below. Also, an error occurs in the following cases.

- If SpeedS setting value is too large, error 4242, 4243, 4255, or 5044 occurs.
The errors can be prevented by setting SpeedS lower.
- If the motion is stopped/paused, or the safety door is opened during the singularity avoiding motion (PTP motion), error 4242, 4250, 4252, or 4256 occurs.
Do not stop the operation or open the safety door during the singularity avoiding motion.
- If the singularity avoiding motion mode (SING_AVOID) is selected for N series, an error 4255 or 4256 occurs.

Mode: Other than SING_AVOID


The error 4252 occurs when the robot touches the elbow singularity area as indicated with a blue line (P-point trajectory) in the figure below.

The elbow singularity area (Flange) is an area when Joint #5 is 0°.



Note:

- The pass motion can be confirmed by the sample simulator program “N2_sample”.
- With Jump3, Jump3CP, and JumpTLZ, the motion to pass the elbow singularity area is not available. (Shoulder and wrist singularity pass motions are possible.)
- In the singularity avoiding motion, the Joint #4 and #6 may rotate largely.
- In the singularity avoiding motion, onward and backward paths may differ.
- To display the elbow singularity area and its neighborhood on the simulator, select [Render Singularity Area of Elbow] in the [Simulator setting] dialog box.



6.18 Robot Motion Commands

SPEL+ includes several commands for controlling the robot from your programs.

6.18.1 Homing the robot

The Home command moves the robot to a user defined "park" or "idle" position. This command works for all robots. It is mainly used for absolute encoder robots that normally do not need to be mechanically homed. Use the HomeSet command to set the home position and the Hordr command to set the home order.

6.18.2 Point to point motion

Point to point (PTP) commands move the tool center point of the robot from its current position to a specified point. Motion of the tool center point may not be in a straight line.

To set the speed for point to point commands, use the Speed command. To set acceleration and deceleration, use the Accel command.

Command	Description
Go	Move directly to a point using point to point motion.
Jump	Jump to a point. First move up to the current LimZ setting, the move over the destination point, then move to the point. The Arch table settings determine the Jump profile.
Jump3	Jump to a point in 3 dimensions. Move in a straight line with the same orientation until the recede point. The motion between the recede points is PTP motion.
Pass	Move near one or more points.
TGo	Move directly to a point in a tool coordinate system.
BGo	Move in a PTP motion to the relative specified point in Base / Local coordinate system

6.18.3 Linear motion

Linear motion commands move the tool center point of robot from its current position to a specified point in a *straight line*. Linear motion is a CP (Continuous Path) motion.

To set velocity (speed) for straight motion, use the SpeedS command. To set acceleration and deceleration, use the AccelS command.

Command	Description
Move	Move in a straight line to the specified point.
TMove	Move in a straight line to the specified point in a tool coordinate system.
Jump3CP	Jump to a point in 3 dimensions using CP motion. Move in a straight line until the recede point. The motion between the recede points is also a straight line motion.
BMove	Move in a straight line to the relative specified point in Base / Local coordinate system

6.18.4 Curves

Curves commands move the robot in a circular arc. Curves is a CP (Continuous Path) motion.

To set velocity (speed) for Curves, use the SpeedS command. To set acceleration and deceleration, use the AccelS command.

Command	Description
Arc	Move the robot through one point to another point using circular interpolation.
Arc3	Move the robot in 3D using circular interpolation.
Curve	Creates a file containing a path specification.
CVMove	Executes a path specified by Curve.

6.18.5 Joint motion

Command	Description
JTran	The JTran command can be used to move one joint of the robot to a position specified in degrees or millimeters, depending on the joint type. The speed and acceleration are the same as for point to point motion commands -- i.e., specified with Speed or Accel commands.
PTran	The PTran command can be used to move one joint of the robot to an encoder pulse position. The speed and acceleration are the same as for point to point motion commands -- i.e., specified with Speed or Accel commands.
Pulse	The Pulse command can be used to move all joints of the robot to encoder pulse positions. The speed and acceleration are the same as for point to point motion commands -- i.e., specified with Speed or Accel commands.
PG_Scan	The PG_Scan command can be used to rotate a pulse generator axis of a Joint-type single axis PG robot continuously in CW/CCW directions. (To rotate it continuously, you need to enable the continuous rotation parameter.) The speed and acceleration are the same as for point to point motion commands -- i.e., specified with Speed or Accel commands.

6.18.6 Controlling position accuracy

Use the Fine command to adjust position accuracy for the end of a motion command. Fine specifies, for each joint, the allowable positioning error for detecting completion of any given move. The lower the Fine settings, the more accurate the final position of the joint, which can cause slower performance. Conversely, large Fine settings can speed up motion commands, but position accuracy will decrease. For many applications, the default settings can be used.

6.18.7 CP Motion Speed / Acceleration and Tool Orientation

When you attempt to change only the tool orientation while keeping the tool tip of the robot arm at the specified coordinate point or when the tool orientation variation is larger than the travel distance of the tool tip, moving the arm by normal CP motion commands will cause an increase in the variation of speed, acceleration and deceleration of tool orientation. In some cases, an error will occur.

To prevent these situations, add the ROT parameter to the CP motion commands. The arm will be moved based on the specified angular velocity and acceleration/deceleration of the main axis regarding the orientation variation.

The angular velocity and acceleration/deceleration of the main axis regarding the orientation variation should be specified with the SpeedR and AccelR commands in advance.

For example:

```
SpeedR 50           ' degree/sec
AccelR 200, 200     ' degree/sec2
Move P1 ROT
```



The tool orientation variation is normally comprised of orientation variations of more than one rotation axis.

The SpeedR and AccelR parameters specify the angular velocity and acceleration/deceleration of the main axis regarding the orientation variation. Therefore, actual angular velocity and acceleration/deceleration of the orientation variation are different from the parameters except for the case where the rotation axis of the orientation is only one.

While the motion command with the ROT parameter is executed, the specified SpeedS and AccelS parameters are invalid.

The ROT parameter can be used with the following motion commands:

```
Move    BMove
Arc      TMove
Arc3     Jump3CP
```

6.18.8 PTP Speed / Acceleration for Small Distances

You can change the speed and acceleration for small distances using PTPBoost and PTPBoostOK. Normally, PTPBoost is not required. In certain cases, you may want to shorten the cycle time even if vibration becomes larger, or conversely you may want to reduce vibration even if cycle time becomes longer. PTPBoost is a robot parameter with values from 0 – 100 that affects the speed and acceleration for small distances. Normally, for small distance motion, the desired speed cannot be attained using the current acceleration. By increasing PTPBoost, acceleration, deceleration, and speed are increased for small distance motion. To check if a motion command will be affected by PTPBoost, use the PTPBoostOK function. See PTPBoost and PTPBoostOK in the *SPEL+ Language Reference* manual for more details.

6.18.9 Pressing Motion

To use the pressing motion, use the following torque control mode commands.

```
TC          (Returns the torque control mode setting and current mode.)
TCSpeed     (Specifies / returns the speed limit in the torque control.)
TCLim       (Specifies the torque limit of each joint for the torque control mode.)
```

The low power mode is limited by a low power upper limit. Therefore, normally use the High power mode. For details and usage of the above commands, refer to “TC Statement”, “TCSpeed”, and “TCLim” in the *SPEL+ Language Reference* manual.

6.18.10 Collision Detection Function (Detection Function of Robot Motion Error)

Detect the robot motion error from differentiation between desired speed and the actual speed (speed deviation value). Errors can be detected by this function is classified into A and B.

A: Collision or contact of robot arm or hand occurs

B: Robot motion errors other than collision or contact

Also, error B is classified into below according to the power condition.

Error in high power

B1: Torque saturation due to a low Weight or Inertia setting.

B2: Torque saturation due to combined motion of multiple joints and movement of a long object.

B3: Torque saturation due to supply voltage reduction.

B4: Error motion due to hardware error or software malfunction.

Error in low power

B4: Error motion due to hardware error or software malfunction.

B5: Torque saturation in low power due to a hand or a long object that exceeds the weight described in the specifications.

Display either message below and stop the robot when detecting an error A or B. Reduce the damage of the robot or equipment.

Error 5057: detect the collision in high power. (Detect the robot motion error.)

Error 5058: detect the collision in low power. (Detect the robot motion error.)

The following error has been existed, however, this function can detect the above errors quickly.

Error 5042, 5043: Position error.

Error is not detected by torque saturation in short time. Detect a state with high risk that causes a malfunction and stop the robot. The following phenomena may occur if continuing robot operation in a state of B1 or B2. Make a state that errors not occur.

Loose binding parts such as screws.

Reduction gear is damaged.

Increase a risk of robot damage

Turn ON CollisionDetect command and detection is enabled. (Default in ON)

Default is different depending on the firmware version.

Ver.7.2.1.x or later: default: ON

Before Ver.7.2.0.x: default: OFF

When upgrading before Ver.7.2.0.x or Ver.7.2.1.x or later: default: OFF

Reboot a controller to return to the default.

The following describes the detail of error B when error 5057 or 5058 is detected without a collision or contact of the robot or arm.

In high power mode

Check the torque saturation by using PTRQ command. Torque saturation is occurred if the joint outputs “1” in PTRQ command.

In that case, make sure that the Weight setting is properly and in accord with the hand weight.

Also, make sure that Inertia setting is properly for joint #4 of SCARA robot and joint #6 of 6-axis robot.

Next, make sure that there is no torque saturation by using PTRQ command by combined motion that multiple joints (#2, #3 and #5 joints of 6-axis robot) operate in the same direction and throwing around the long object.

If torque saturation occurs, reduce acceleration/deceleration of Accel command until there is no torque saturation (the value: 1.0 or less is displayed in PTRQ).

Also, torque saturation may occur due to reduction of supply voltage that inputs to the controller. Check the power supply voltage is within the specifications.

You can turn ON/OFF the collision detection function per equipment if you want to use without performing those error detection due to equipment compatibility securement or similar reasons.

If other error occurs at the same time, take a countermeasure for that first.

In low power mode

Make sure that hand weight is within the specifications.

Also, check the torque saturation when errors occur on the joint #4 and 5 of 6-axis robot.

When torque saturation is occurred, it is long object that cannot be hold by low power mode. Hold in high power mode.

If other error occurs at the same time, take a countermeasure for that first.

Immediately stop result of the torque saturation by combination of the following motion and command. Error of A and B can be detected faster.

HP motion: LimitTorqueStop Command

LP motion: LimitTorqueStopLP Command

The following describes details of collision of the robot arm A and contact detection.

For reduction of damage on the arms and the end effectors due to the collision with peripherals, there are two functions: Collision detection function and torque restriction function.


The collision detection function detects the collision and stops the robot immediately.

The torque restriction function restricts torque at the collision and also stops the robot immediately.

These are functions to reduce damage on the robot at the collision, but cannot avoid damage completely. Also, the functions cannot be used for the purpose of human safety.

The force applied to the robot at the collision can be roughly divided into two types as shown on the right: the impact of speed right before the collision, and the pressing force by the motor torque after the collision.

The collision detection function and the torque restriction function reduce damage caused by the pressing force right after the collision. These functions do not have any effect on damage caused by the impact of speed.



The collision detection function detects collision by the speed deviation value for robot motion control (differentiation between the desired speed and the actual speed) showing an abnormal value which is greatly different from normal motion due to the collision.

Turn ON CollisionDetect command and the detection is enabled. (Default: ON)

Default is different depending on the firmware version.

Ver.7.2.1.x or later: default: ON

Before Ver.7.2.0.x : default: OFF

Reboot a controller to return to the default.

When enabled, this function reduces the time of pressing force by the motor torque, by detecting the collision and stopping the robot immediately. This reduces the pressing force by about 20%. To reduce the damage more, use this function together with the torque restriction function.

The collision detection function is automatically disabled during the pressing motion and the force sensing operation described in “6.18.9 Pressing Motion”.

Also, the function may have false detection in cases of powerful contact motion and significant acceleration and deceleration which may have consecutive torque saturation.

To confirm if there is a risk of false detection, use PTRQ.

If PTRQ is less than 1 for all axes, there is no risk of false detection.

If PTRQ is one, torque saturation is occurring on the axis. This means excessive acceleration and deceleration are applied, and it is not preferable for motor control. It also has a risk of damage on the manipulator. In such a situation, take the following countermeasures.

For contacting operation,

- Check if Weight and Inertia settings are appropriate
- Lower acceleration and deceleration
- Lower speed

When performing contacting motion:

- Lower acceleration and deceleration at a contact
- Set a contacting depth shallow

If you want to operate the manipulator without taking the above countermeasures, you can enable and disable the function for each axis. Set the function off for the axis which you want to disable the function.

For details of the command and function, refer to the following manual.

EPSON RC+ 7.0 SPEL+ Language Reference

CollisionDetect Statement

CollisionDetect Function

6.18.11 Torque Restriction Function

The torque restriction function reduces damage at the collision similarly with “6.18.10 Collision Detection Function”.

The torque restriction value used for this function is defined by adding the margin to the upper limit torque value used in the program in order to avoid malfunction. By using the torque restriction function, the pressing force can be reduced.

For example, if the torque is restricted at 30%, the pressing force can also be reduced to 30%. Also, the robot immediately stops when the torque reaches the upper limit value. By stopping the robot immediately, a further 20-30% reduction effect can be obtained. When the torque is restricted at 30% and the robot is stopped immediately, the total of less than 25% or equivalent reduction effect can be obtained.

For SCARA robots, the end of the extended shaft may get caught and bent. To reduce occurrence of the bent shaft, it is recommended to use this function to reduce the pressing force to the maximum degree.

If malfunction occurs, take any of the following measures for the axis of malfunction.

- Set LimitTorqueStop or LimitTorqueStopLP off
- Increase the threshold value of LimitTorque or LimitTorqueLP

To use the torque restriction function for jogging motion, follow the steps below.

- (1) Execute PTCLR and start torque measurement.
- (2) Execute the jogging motion.
- (3) Measure the maximum torque value by PTRQ, and then add the margin to it.
- (4) Set LimitTorqueLP and LimitTorqueLPStop.

If the robot is temporarily stopped in the low power motion, the value larger than the normal program operation or jogging motion may be obtained. In such case, execute the temporary stop while measuring PTRQ and include it into measurement.

For details of the command and function, refer to the following manual.

EPSON RC+ 7.0 SPEL+ Language Reference

LimitTorque Statement, LimitTorque Function,

LimitTorqueLP Statement, LimitTorqueLP Function,

LimitTorqueStop Statement, LimitTorqueStop Function,

LimitTorqueStopLP Statement, LimitTorqueStopLP Function

The following is a sample program which automatically configures the collision detection function and the torque restriction function.

The program repeats the motion called “all_ax_move”.

The program enables the collision detection function, measures the maximum torque in the first five moves, adds the margin to the measured value (1.2 times if HighPower, 1.4 times if LowPower), and sets the upper limit torque value to stop the robot at the upper limit torque.

This is the example of automatic setting to repeat motion with the above settings from the sixth time.

When the upper limit torque value is changed, the changed value will be considered as “1.0” for the subsequent PTRQ measurement. If the margin of 1.2 times is set, PTRQ will be slightly larger than 0.8, and if the margin of 1.4 times is set, PTRQ will be slightly smaller than 0.7.

Setting example)

```
Function main
  Integer icnt
  Real rtrq(6)

  Motor On
  Power High
  \ Power Low
  Weight 8
  Speed 50
  Accel 80, 80

  icnt = 1
  PTCLR
  LimitTorque 100          'init HighPower limit torque
  LimitTorqueLP 100        'init LowPower limit torque
  CollisionDetect On
  Do
    Call all_ax move
    Print PTRQ(1), PTRQ(2), PTRQ(3), PTRQ(4), PTRQ(5), PTRQ(6)
    icnt = icnt + 1
    If icnt = 5 Then
      If Power = 1 Then      'High power case
        Print "LimitTorque set"
        rtrq(1) = PTRQ(1) * 1.2 * LimitTorque(1) + 1.0
        rtrq(2) = PTRQ(2) * 1.2 * LimitTorque(2) + 1.0
        rtrq(3) = PTRQ(3) * 1.2 * LimitTorque(3) + 1.0
        rtrq(4) = PTRQ(4) * 1.2 * LimitTorque(4) + 1.0
        rtrq(5) = PTRQ(5) * 1.2 * LimitTorque(5) + 1.0
        rtrq(6) = PTRQ(6) * 1.2 * LimitTorque(6) + 1.0
        Print LimitTorque(1), LimitTorque(2), LimitTorque(3),
LimitTorque(4), LimitTorque(5), LimitTorque(6)
        LimitTorque rtrq(1), rtrq(2), rtrq(3), rtrq(4),
rtrq(5), rtrq(6)
        Print LimitTorque(1), LimitTorque(2), LimitTorque(3),
LimitTorque(4), LimitTorque(5), LimitTorque(6)
        LimitTorqueStop On
      Else                    'Low poser case
        Print "LimitTorqueLP set"
        rtrq(1) = PTRQ(1) * 1.4 * LimitTorqueLP(1) + 1.0
        rtrq(2) = PTRQ(2) * 1.4 * LimitTorqueLP(2) + 1.0
        rtrq(3) = PTRQ(3) * 1.4 * LimitTorqueLP(3) + 1.0
        rtrq(4) = PTRQ(4) * 1.4 * LimitTorqueLP(4) + 1.0
        rtrq(5) = PTRQ(5) * 1.4 * LimitTorqueLP(5) + 1.0
        rtrq(6) = PTRQ(6) * 1.4 * LimitTorqueLP(6) + 1.0
        Print LimitTorqueLP(1), LimitTorqueLP(2),
LimitTorqueLP(3), LimitTorqueLP(4), LimitTorqueLP(5),
LimitTorqueLP(6)
        LimitTorqueLP rtrq(1), rtrq(2), rtrq(3), rtrq(4),
rtrq(5), rtrq(6)
        Print LimitTorqueLP(1), LimitTorqueLP(2),
LimitTorqueLP(3), LimitTorqueLP(4), LimitTorqueLP(5),
LimitTorqueLP(6)
        LimitTorqueStopLP On
      EndIf
      If icnt > 5 Then
        icnt = 6
      Endif
    Loop While icnt > 0
  Fend

Function all_ax move
  Integer icount
  Go JA(10, 10, 10, 10, 10, 10)
  Go JA(-10, -10, -10, -10, -10, -10)
Fend
```

6.19 Working with Robot Points

A robot point is a set of coordinates that define a position in the robot work envelope. For SCARA and Cartesian robots, a point is defined by the position data (X, Y, Z) within the reference rectangular coordinate space and the orientation data (U) which is the rotation about the Z axis of the rectangular coordinate.

For 6-axis robots, a point is defined by the position and orientation of the tool coordinate system with respect to a reference rectangular coordinate system. The point is specified by the position data (X, Y, Z) and the orientation is specified by the orientation data (U, V, W) which correspond with *roll* (rotation about the Z axis), *pitch* (rotation about the Y axis), and *yaw* (rotation about the X axis).

When the additional ST axis is installed, the point is specified by the position data of each additional axis (S, T).

The X, Y, and Z coordinates of a point are specified in millimeters. The U, V, and W coordinates are specified in degrees.

The S and T coordinates of a point are specified in millimeters or degrees, according to the type of axis.

Points are referenced using the letter P followed by an integer number or integer expression or by a label defined in the point file editor or [Robot Manager]-[Jog & Teach] page.

6.19.1 Defining points

You can define points in a program statement, points editor window, [Robot Manager]-[Jog & Teach] page, or at the [Command] window.

In a program statement or at the Command window, you can assign coordinates to a point, or define a point that is the current robot arm position.

```
P1 = XY(200, 100, -25, 0)      ' Assign coordinates to point P1
Pick = XY(300, 200, -45, 0)   ' Assign coordinates to point pick
P10 = Here                    ' Assign a point to current position
```

6.19.2 Referencing points by point label

You can assign names to point numbers so you can refer to points by name in a program.

Assign names from the point editor (see *Editing Points*) or the [Robot Manager]-[Jog & Teach] page. Names must be unique for each point number when used in the same point file.

Point labels can include up to 32 one-byte alphanumeric, Japanese, and the underscore characters, or 16 two-byte characters. Characters can be upper case or lower case. Only alphabets and Japanese can be used for the first letter.

```
For i = 0 To 10
  Go pick
  Jump place
Next i
```

6.19.3 Referencing points with variables

Use the letter P followed by a variable name within parentheses that represents the point number you are referencing.

```
For i = 0 To 10
  Go P(i)
Next i
```



Although you can define points at the [Command] window for test purposes, it is recommended that all points be defined in a program, point editor, or with the [Robot Manager]-[Jog & Teach] page. Points defined at the [Command] window will be cleared from memory when you build a project or run a program unless you execute “SavePoints”.

6.19.4 Using points in a program

When starting programs, the default point file for the robot is loaded. You can also load other points in the program using the LoadPoints statement.

```
Function main
  Integer i

  LoadPoints "modell.pts"
  For i = 0 To 10
    Jump pick
    Jump place
  Next i
Fend
```

6.19.5 Importing points into program

You can import points into the current project while the program is running using the ImportPoints statement.

```
Function main
  Integer i

  ImportPoints "c:\models\modell.pnt", "robot1.pnt"
  LoadPoints "robot1.pnt"
  For i = 0 To 10
    Jump pick
    Jump place
  Next i
Fend
```

6.19.6 Saving and loading points

Use “LoadPoints” to load a point file in the current project. You can optionally specify the Merge parameter to combine points in a file with points that have already been loaded.

Use “SavePoints” to save the points in a point file. If the point file is in the current project, it will be updated on the PC when it is connected and the same project is open.

If the point file is not the current project, it will not be automatically updated on the PC. Use Project Synchronize to copy the file to the PC if desired.



- Rebuild the program if Project Synchronize is performed.

6.19.7 Point attributes

Each point definition can optionally specify a local number and various arm orientations, depending on the robot type. You can specify point attributes in point assignment statements or use individual statements and functions to change the attributes of a previously defined point.

Local point attribute

To specify a local coordinate system number for a point in an assignment statement, add a forward slash (/) followed by the local number after the coordinates of the point.

```
P1 = XY(300, -125.54, -42.3, 0) /1 ' P1 is in local 1
```

The local number can also be an expression enclosed in parentheses.

```
P2 = P3 /(mylocal)
```

Use the PLocal function and statement to read and set the local attribute of a point.

Hand point attribute

To specify orientation for the SCARA or 6-axis robot, add a forward slash (/) followed by L (for Lefty hand orientation) or R (for Righty hand orientation).

```
P2 = XY(200, 100, -20, -45) /L ' Hand orientation is Lefty
```

```
P3 = XY(50, 0, 0, 0) /2 /R ' Righty in Local 2
```

You can read and set point hand orientation using the Hand statement and function.

```
Hand P1, Righty
```

Elbow point attribute

To specify elbow orientation for the 6-axis robot in a point assignment statement, add a forward slash (/) followed by A (Above elbow orientation) or B (Below elbow orientation),

Elbow orientation is Below.

```
P1 = XY(0, 600, 400, 90, 0, 180) /B
```

You can read and set point elbow orientation using the Elbow statement and function.

Wrist point attribute

To specify wrist orientation for the 6-axis robot in a point assignment statement, add a forward slash (/) followed by NF (NoFlip wrist orientation) or F (Flip wrist orientation).

Wrist orientation is Flip.

```
P2 = XY(0, 600, 400, 90, 0, 180) /F
```

You can read and set point wrist orientation using the Wrist statement and function.

J4Flag and J6Flag point attributes

At some points in the work envelope, the 6-axis robot can have the same position and orientation even if the fourth joint or the sixth joint is rotated 360 degrees. To distinguish these points, the J4Flag and J6Flag point attributes are provided. These flags allow you to specify a position range for joint 4 and joint 6 for a given point.

To specify the J4Flag in a point assignment statement, add a forward slash (/) followed by J4F0 ($-180 < \text{the forth joint angle} \leq 180$) or J4F1 ($\text{the forth joint angle} \leq -180$ or $180 < \text{the forth joint angle}$).

```
P2 = XY(0, 600, 400, 90, 0, 180) /J4F1
```

To specify the J6Flag in a point assignment statement, add a forward slash (/) followed by J6F0 ($-180 < \text{the sixth joint angle} \leq 180$), J6F1 ($-360 < \text{the sixth joint angle} \leq -180$ or $180 < \text{the sixth joint angle} \leq 360$), or J6Fn ($-180*(n+1) < \text{the sixth joint angle} \leq 180*n$ or $180*n < \text{the sixth joint angle} \leq 180*(n+1)$).

```
P2 = XY(50, 400, 400, 90, 0, 180) /J6F2
```

J1Flag and J2Flag point attributes

At some points in the work envelope, the RS series can have the same position and orientation even if the first joint or the second joint is rotated 360 degrees. To distinguish these points, the J1Flag and J2Flag point attributes are provided. These flags allow you to specify a position range for joint 1 and joint 2 for a given point.

To specify the J1Flag in a point assignment statement, add a forward slash (/) followed by J1F0 ($-90 < \text{the first joint angle} \leq 270$) or J1F1 ($-270 \leq \text{the first joint angle} \leq -90$ or $270 < \text{the first joint angle} \leq 450$).

```
P2 = XY(-175, -175, 0, 90) /J1F1
```

To specify the J2Flag in a point assignment statement, add a forward slash (/) followed by J2F0 ($-180 < \text{the second joint angle} \leq 180$), J2F1 ($-360 < \text{the second joint angle} \leq -180$ or $180 < \text{the second joint angle} \leq 360$).

```
P2 = XY(300, 175, 40, 90) /J2F1
```

J1Ang and J2Flag point attributes

At the origin of the robot coordinate system, the RS series can have the same position and orientation even if the first joint is rotated. To distinguish these points, the J1Ang point attributes are provided.

6.19.8 Extracting and setting point coordinates

Use the CX, CY, CZ, CU, CV, CW, CS, and CT commands to get a coordinate of a point and set it.

```
xcoord = CX(P1)
P2 = XY(xcoord, 200, -20, 0)
ycoord = CY(P*)           ' Gets current Y position coordinate

CX(pick) = 25.5
CY(pick) = CY(pick) + 2.3
```


6.19.9 Alteration of points

There are several ways of modifying a point without re-teaching it. You can change one or more coordinate values with relative offsets or absolute values.

To set an absolute value for a coordinate, use a colon followed by the axis letter and the value.

To add a relative offset to a coordinate, use an axis letter followed by the offset value or expression in parentheses. If the offset is negative, then precede the axis letter with the minus sign. If parentheses are omitted, they will be automatically added.

Go P1 -Z(20)	Move to P1 with a z offset of -20mm
Go P1 :Z(-25)	Move to P1 with a z absolute position of -25mm
Go P1 -X(20) +Y(50) :Z(-25)	Move to P1 with offsets for X and Y relative offsets and an absolute position for Z

Point alteration of 6-axis robot

When changing the orientation by roll (U), pitch (V), and yaw (W) in the SPEL⁺ program, adding the angles to V and W axes (e.g. +V(10), +W(10)) does not mean the rotation of Y and X axes in the robot coordinate system. To change the orientation (U, V, and W) after teaching the points, set the robot to actual posture by Jog & Teach in the Robot Manager.

6.20 Input and output control

6.20.1 Hardware I/O

There are 24 DC inputs and 16 DC outputs on a standard controller.

By purchasing I/O boards, you can add additional inputs and outputs. You can expand the I/O by using the Fieldbus I/O master option and Fieldbus I/O slave option. Also, you can input/output the Analog signal by using the Analog I/O board option. Refer to *11. Inputs and Outputs* for details.

NOTE



I/O boards cannot be added to T series and VT series manipulators.

6.20.2 Memory I/O

There are 128 bytes (1024 bits) of memory I/O. Memory I/O is especially useful for synchronizing multi-tasking. Each memory bit can be treated as both an input and an output.

Use the commands with the "Mem" prefix for memory I/O.

6.20.3 I/O Commands

Command	Description
In	Reads one byte (eight bits) of input data.
InW	Reads one word (sixteen bits) of input data.
MemIn	Reads one byte (eight bits) of Memory I/O.
MemInW	Reads one word (sixteen bits) of Memory I/O.
MemOff	Turns off one Memory I/O bit.
MemOn	Turns on one Memory I/O bit.
MemSw	Read status of one bit of memory I/O.
Off	Turns off one output bit.
On	Turns on one output bit.
Out	Sets/reads one byte (eight bits) of output data.
OutW	Sets/reads one word (sixteen bits) of output data.
Oport	Reads the status of one output bit.
InBCD	Reads one byte of input data in BCD (binary coded decimal) format.
OpBCD	Outputs one byte of output data in BCD format.
Sw	Read status of one bit of hardware inputs or memory inputs.

6.21 Using Traps

Traps enable a program to jump to a label or enable a function to be called when a certain event occurs.

Traps are divided into the following two types:

- 4 Traps are fired by user defined input
- 7 Traps are fired by system

You should keep trap functions short and avoid continuous loops. According to the type, some Traps must be re-armed. Also, some motion commands are limited to execute in trap functions.


For details on Trap statement, see the *SPEL+ Language Reference manual*.

Here is a simple example for a trap. In this example, when input 1 turns on, it executes the SwlTrap function.

```
Function main
  ' Sets the trap
  Trap 1 Sw(1) = On Xqt SwlTrap
Do
  RunCycle
Loop
Fend
Function SwlTrap
  ' Turn on output 1 for 2 seconds
  On 1, 2
  ' Wait for trap condition to clear
  Wait Sw(1) = Off
  ' Re-arm the trap
  Trap 1 Sw(1) = On Xqt SwlTrap
Fend
```

Trap	Description
Trap 1 – 4 Goto	Triggered by an input condition specified by the user.
Trap 1 – 4 Call	User traps can use GoTo, Call, or Xqt.
Trap 1 – 4 Xqt	
Trap Emergency Xqt	When Emergency Stop occurs, a specified function is executed.
Trap Error Xqt	When an error occurs, a specified function is executed.
Trap SgOpen Xqt	When the Safeguard circuit is open, a specified function is executed.
Trap SgClose Xqt	When the Safeguard circuit is closed, a specified function is executed.
Trap Pause Xqt	When the system enters the Pause state, a specified function is executed.
Trap Abort Xqt	When all tasks (except background tasks) have been stopped by user or system, such as when a command corresponding to Abort All is executed, a specified function is executed.
Trap Finish Xqt	When all tasks (except background tasks) have been finished, a specified function is executed. However, the function will not be executed under the condition that executes Trap Abort.

6.21.1 Cautions of Trap when it triggers the system condition

 CAUTION	<ul style="list-style-type: none"> ■ Forced Flag <p>Specify Forced flag in the I/O output commands such as On/Off command to enable On/ Off of the I/O outputs during Emergency Stop, Safety Door open, Teach mode, and error condition.</p> <p>Do not connect external equipment that operates mechanically such as actuator to the I/O output that specifies Forced flag. Otherwise, the external equipment may move during Emergency Stop, Safety Door Open, Teach mode, or error condition and this will cause serious safety problems.</p> <p>Forced flag is designed to be specified for I/O outputs connected to external equipment without mechanical motion such as status display LEDs.</p>
--	--

Outputs off during Emergency Stop

Uncheck “Outputs off during Emergency Stop” in the Preferences page of System Configuration SPEL Controller Board to execute I/O On/Off using the Trap Emergency Xqt task after Emergency Stop. If this checkbox is checked, the execution order of turning Off by the controller and turning On using the task are not guaranteed.

6.22 Special Tasks

Each task of SPEL⁺ pauses by Pause input or Safety Door open and stops by Emergency Stop or Error. Therefore you cannot create a system that monitors the whole system.

To enable the Robot Controller to monitor the whole system, the following special tasks are provided:

NoPause/NoEmgAbort task

You can create a task that continues a processing even when the Pause is input or safeguard is open by specifying NoPause or NoEmgAbort as a task type when creating task by Xqt.


Background task

You can create a task that starts as the controller power is turned ON and continues a processing even when the Pause is input or safeguard is open.

These special tasks are useful tasks but may reduce the safety of the system by using them improperly.

Be sure to understand the following items when using these tasks.

6.22.1 Precautions to Use the Special Tasks

 CAUTION	<ul style="list-style-type: none"> ■ Forced Flag <p>Specify Forced flag in the I/O output commands such as On/Off command to enable On/ Off of the I/O outputs during Emergency Stop, Safety Door open, and error.</p> <p>Do not connect external equipment that operates mechanically such as actuator to the I/O output that specifies Forced flag. Connecting external equipment may cause serious safety problems and operate the external equipment during Emergency Stop, Safety Door Open, or error occurrence.</p> <p>Forced flag is designed to be specified for I/O outputs connected to external equipment without mechanical motion such as status display LEDs.</p>
--	--

NoEmgAbort Task

When Emergency Stop or errors occur, finish the task promptly after completing the error handling.

If you do not complete the NoEmgAbort task, the controller does not change to Ready status and you cannot cancel the Emergency Stop or the error. You cannot execute Reset command from the NoEmgAbort task to cancel the Emergency Stop or the error automatically.

NoEmgAbort task is designed for I/O process without motion and communication with external device using the Ethernet. Therefore there are commands such as robot motion commands that cannot be executed in the NoEmgAbort task. An error occurs if you use these commands. The list of these commands is in the next section.

For details, refer to EPSON RC+ 7.0 *Online Help* or *Xqt* in *SPEL⁺ Language Reference*.

NoPause Task

NoPause task continues the operation during the Pause or Safety Door open condition. However, when a robot is operating NoPause task, the task pauses as the robot pauses.

Background task

Background task always exists while the controller is working, and it is designed for monitor of the entire system and communication with external device. Therefore there are commands such as robot motion commands that cannot be executed in the background task.

An error occurs if you use these commands. The list of these commands is in the next section.

In addition, the background task continues processing even when Pause is input or safeguard is open, so it doesn't affect the controller state transition.

For details, refer to *6.23 Background Task*.

Outputs off during Emergency Stop

Uncheck this preference to execute I/O On/Off using the NoEmgAbort task or background task after Emergency Stop. If this checkbox is checked, the execution order of turn Off by the controller and turn On using the task are not guaranteed.

Setting of Safeguard open stops all tasks

When this preference is checked, NoPause task stops by Safety Door open. NoEmgAbort task or background task continues the task.

Setting of [Enable the Background task]

Set this preference when you use the background task.

Setting of [Initialize global variables as the MainXX starts]

Uncheck this preference when you use the global variables from the background task. When this checkbox is checked, the controller will initialize the variables and the variable-access conflict from tasks will occur.



CAUTION

■ Setting of [Enable advanced task commands]

Check this preference when you execute the commands below from a background task.

StartMain, Cont, Recover, Reset Error, Reset

When you execute these commands from a task, you should understand each command specification and verify that the system has the appropriate conditions.

Improper use, such as executing commands continuously in a loop, can reduce the security of system.

6.22.2 NoPause/NoEmgAbort task specification

Status by Event and Task

Event	Task Type		
	Normal	NoPause	NoEmgAbort
Pause Statement Pause Input Pause Button	Pause	Continue *1	Continue
Safety Door Open	Pause *2	Continue *1 *2	Continue
Error during Auto Mode	Stop	Stop	Continue
Error during Program Mode	Pause	Pause	Continue
Emergency Stop	Stop	Stop	Continue
Stop Button Stop Input	Stop	Stop	Stop
Halt Statement Halt Button	Pause	Pause	Pause
Brake Point	Pause	Pause	Pause
Switching to Teach Mode	Stop	Stop	Stop

*1 When the robot is operating, the task pauses as the robot pauses.

*2 When [Outputs off during Emergency Stop] is checked in the [Preferences] page of [Setup Controller], normal tasks and NoPause tasks stop by Safety Door open.

Task Execution

Normal	Omit the task type in Xqt statement, or specify Normal for the task type. Xqt NormalTask Xqt NormalTask, Normal
NoPause	Specify NoPause in Xqt statement. Xqt NoPauseTask, NoPause
NoEmgAbort	Specify NoEmgAbort in Xqt statement. Xqt NoEmgAbortTask, NoEmgAbort

You cannot change the task type after executing a task.

main to main63 that are executed at the beginning of the program are executed as normal tasks.

Type of a task executed in Trap Xqt is determined by the event type.

For details, refer to EPSON RC+ 7.0 *Online Help* or *Trap* in *SPEL+ Language Reference*.

Restricted Commands by Task Types

Normal	No restriction
NoPause	No restriction
NoEmgAbort	Cannot execute the following commands. Command for robot motion Commands for vision Reset, Xqt, Trap, etc. For details, refer to EPSON RC+ 7.0 <i>Online Help</i> or <i>Xqt</i> in <i>SPEL+ Language Reference</i> .

6.22.3 NoPause/NoEmgAbort task example

The following example shows a program that monitors the error of the controller and switches the I/O On/Off when error occurs according to the error number.

The program example of ErrOn, EStopOn, SafetyOn are indicated in the *EPSON RC+ 7.0 SPEL+ Language Reference*.

```
Function main
    Xqt ErrorMonitor, NoEmgAbort
    :
    :
Fend

Function ErrorMonitor
    Wait ErrorOn
    If 4000 < SysErr And Syserr < 5999 Then
        Print "Mortion Error = ", SysErr
        Off 10, Forced
        On 12, Forced
    Else
        Print "Other Error = ", SysErr
        Off 11, Forced
        On 13, Forced
    EndIf
Fend
```


6.23 Background Task

6.23.1 Primary features of background task

The purpose of the background task is to monitor the status of the cell as a whole and to communicate with external devices.


Function BgMain, a function specified as the “Background task” will be automatically activated as task 65 when the controller starts and loads the project.

If another task is created within the background task using the XQT command, that created task will be assigned to task No.65 (and onward in the ascending order) and will also function as a background task. In addition, specifying a task type for an XQT command in a background task has no meaning.

An operator is not necessarily aware of the operating Background task which does not stop at the input of emergency stop or safeguard signal. The Background task will not stop when an operator inputs “PAUSE” or “ABORT”.


In this sense, the background task functions for the application program to work as a part of the system.

On the other hand, the execution commands to operate the Manipulator, set-up commands for the Manipulator or the commands for image processing cannot be executed within the background task.

<div><p>CAUTION</p></div>	<div><ul style="list-style-type: none">■ Specify Forced flag in the I/O output commands operated from the background tasks to enable On/ Off of the I/O outputs during Emergency Stop, Safety Door open, and error.<p>Do not connect external equipment that operates mechanically such as actuators to the I/O output that specifies the Forced flag. Connecting external equipment may cause serious safety problems and operate the external equipment during Emergency Stop, Safety Door Open, or error occurrence.</p><p>Forced flag is designed to be specified for I/O outputs connected to external equipment without mechanical motion such as status display LEDs.</p></div>
--	--


6.23.2 Setup and start the background task

When you use the background task, first of all you need to check the [Enable background tasks] in the [Preferences] page of [Setup]-[System Configuration]-[SPEL Controller Board].



When you have already checked the box above and the Function BgMain exists in your program, it will automatically start as Task 65 as the controller starts and loads the project, it executes as a “Background task”.

However in PROGRAM mode, the Function BgMain will not start automatically. You need to start it using the <Start> button in the [Run] window. This is because the PROGRAM mode is for creating programs and debugging and it may be more efficient when it doesn't start the Function BgMain.




When the controller operating mode shifts from PROGRAM to AUTO mode, the Function BgMain will start automatically.

6.23.3 Holding background task (from being activated)

The purpose of the background task is to monitor the status of the cell as a whole and to communicate with external devices. It is activated before a non-background task is activated and continues to function when the non-background task either generates an error or is aborted by an operator. In this sense, the background task can be a program that never stops functioning.

The background task can be debugged in PROGRAM mode. Click the <Stop> button dropdown menu in the [Run] window and you can select the background task is to be aborted as well or not.



In the [Task Manager] window, the background tasks can be managed in the same way as the non-background tasks except for the <Pause/Cont> button. You can set a break point in a background task and step through the code.

As a rule, the background task cannot be controlled in AUTO mode. It is by design that any error that occurs in the background task cannot be recovered in AUTO mode. Therefore, thorough debugging in PROGRAM mode is recommended. Be particularly careful that the communication errors are handled properly without fail before using the background task in AUTO mode.

The following tables show how the background will (or will not) be affected by operation from the console.

Operator Window

Button	Background task
START	It will not be affected.
Abort	It will not be affected.
Pause	It will not be affected.
Continue	It will not be affected.

Remote Input

Button	Background task
Start / Stop	It will not be affected.
Pause / Continue	It will not be affected.
Reset	It will not be affected.
Shutdown	It will be stopped.

Run Window (PROGRAM mode)

Button	Background task
Start	You can select how to start the task.
Abort	You can select how to abort the task: abort only non-background task or abort all tasks including the background task.
Pause	It will not be affected.
Continue	It will not be affected.

Task Manager (PROGRAM mode)

Button	Background task
Halt / Resume	When the background task is selected, you cannot execute Halt/Resume.
Quit	When the background task is selected, you can execute Quit.
Pause/Cont	It will not be affected.
Stop	All tasks including the background task will stop.

Break point (PROGRAM mode)

Switch name	Background task
Set a break point	You can set a breakpoint to the background task. It will pause at the break point.
Step Into	Available
Step Over	Available
Continue	Available
Walk	Available, but the motion commands are not available to execute from the background task.

6.23.4 Commands that will cause error in background task

The following commands are prohibited in background tasks and execution will result in error:

- commands that relate to the Manipulator operation or operation settings
- commands that relate to the Vision relation instruction
- TRAP commands

If a program that is to be executed as the background task includes any of the following commands, it will result in error when executed.

However, using the command related to the Manipulator operation settings or the Manipulator settings to gain the current setting values or refer to them will not result in error:

Commands that will cause error are almost the same as with NoEmgAbort, but there are some commands such as Xqt that can be executed in a background task.

For details, refer to EPSON RC+ 7.0 *Online Help* or *Xqt* in *SPEL+ Language Reference*.

6.23.5 Background task and Remote control

No matter whether the background task is being executed or not, it doesn't affect the remote I/O outputs Ready, Running, and Pause. For example, even if the background task is being executed, when no non-background tasks (Task No. 1 - 32) are being executed, the READY output will be ON.

6.24 Predefined Constants

There are several predefined constants for use in SPEL+ program. A project build time, the values for these constants are substituted for the constant name.

Constant name	Value	Use
TRUE	-1	Boolean expression
FALSE	0	Boolean expression
High	1	
Low	0	
Off	0	
On	1	
Above	1	
Below	2	
NoFlip	1	
Flip	2	
Righty	1	
Lefty	2	
J1	1	
J2	2	
J3	4	
J4	8	
J5	16	
J6	32	
J7	64	
CR	CHR\$(13)	
CRLF	CHR\$(13)+ CHR\$(10)	
LF	CHR\$(10)	
MB_OK	0	MsgBox flags
MB_OKCANCEL	1	MsgBox flags
MB_ABORTRETRYIGNORE	2	MsgBox flags
MB_YESNOCANCEL	3	MsgBox flags
MB_YESNO	4	MsgBox flags
MB_RETRYCANCEL	5	MsgBox flags
MB_ICONSTOP	16	MsgBox flags
MB_ICONQUESTION	32	MsgBox flags
MB_ICONEXCLAMATION	48	MsgBox flags
MB_ICONINFORMATION	64	MsgBox flags
MB_DEFBUTTON1	0	MsgBox flags
MB_DEFBUTTON2	256	MsgBox flags
IDOK	1	MsgBox return
IDCANCEL	2	MsgBox return
IDABORT	3	MsgBox return
IDRETRY	4	MsgBox return
IDIGNORE	5	MsgBox return
IDYES	6	MsgBox return
IDNO	7	MsgBox return
BACKCOLORMODE_VISUALSTYLE	0	For GUI Builder
BACKCOLORMODE_USER	1	For GUI Builder
BORDERSTYLE_NONE	0	For GUI Builder
BORDERSTYLE_FIXEDSINGLE	1	For GUI Builder
BORDERSTYLE_FIXED3D	2	For GUI Builder
CNV_QUELEN_ALL	0	Cnv_QueLen
CNV_QUELEN_UPSTREAM	1	Cnv_QueLen
CNV_QUELEN_PICKUPAREA	2	Cnv_QueLen
CNV_QUELEN_DOWNSTREAM	3	Cnv_QueLen
DEVID_SELF	21	CLS
DEVID_TP	24	CLS
DEVID_TP3	30	CLS
DIALOGRESULT_NOE	0	For GUI Builder
DIALOGRESULT_OK	1	For GUI Builder

Constant name	Value	Use
DIALOGRESULT_CANCEL	2	For GUI Builder
DLG_IOMON	102	RunDialog
DLG_ROBOTMNG	100	RunDialog
DLG_VGUIDE	110	RunDialog
DOCK_NONE	0	For GUI Builder
DOCK_TOP	1	For GUI Builder
DOCK_BOTTOM	2	For GUI Builder
DOCK_LEFT	3	For GUI Builder
DOCK_RIGHT	4	For GUI Builder
DOCK_FILL	5	For GUI Builder
DROPDOWNSTYLE_SIMPLE	0	For GUI Builder
DROPDOWNSTYLE_DROPDOWN	1	For GUI Builder
DROPDOWNSTYLE_DROPDOWNLIST	2	For GUI Builder
ERROR_DOINGMOTION	2999	For GUI Builder
ERROR_NOMOTION	2998	For GUI Builder
EVENTTASKTYPE_NORMAL	0	For GUI Builder
EVENTTASKTYPE_NOPAUSE	1	For GUI Builder
EVENTTASKTYPE_NOEMGABORT	2	For GUI Builder
FORCE_LESS	0	Force SetTrigger
FORCE_GREATER	1	Force SetTrigger
FORCE_XFORCE	2	Force SetTrigger
FORCE_YFORCE	3	Force SetTrigger
FORCE_ZFORCE	4	Force SetTrigger
FORCE_XTORQUE	5	Force SetTrigger
FORCE_YTORQUE	6	Force SetTrigger
FORCE_ZTORQUE	7	Force SetTrigger
FORMBORDERSTYLE_NONE	0	For GUI Builder
FORMBORDERSTYLE_FIXEDSINGLE	1	For GUI Builder
FORMBORDERSTYLE_FIXED3D	2	For GUI Builder
FORMBORDERSTYLE_FIXEDDIALOG	3	For GUI Builder
FORMBORDERSTYLE_SIZABLE	4	For GUI Builder
IMAGEALIGN_TOPLEFT	1	For GUI Builder
IMAGEALIGN_TOPCENTER	2	For GUI Builder
IMAGEALIGN_TOPRIGHT	3	For GUI Builder
IMAGEALIGN_MIDDLELEFT	4	For GUI Builder
IMAGEALIGN_MIDDLECENTER	5	For GUI Builder
IMAGEALIGN_MIDDLERIGHT	6	For GUI Builder
IMAGEALIGN_BOTTOMLEFT	7	For GUI Builder
IMAGEALIGN_BOTTOMCENTER	8	For GUI Builder
IMAGEALIGN_BOTTOMRIGHT	9	For GUI Builder
IOTYPE_INPUT	0	IOLabel function
IOTYPE_OUTPUT	1	IOLabel function
IOTYPE_MEMORY	2	IOLabel function
IOSIZE_BIT	1	IOLabel function
IOSIZE_BYTE	8	IOLabel function
IOSIZE_WORD	16	IOLabel function
LANGID_ENGLISH	0	ErrMsg\$
LANGID_JAPANESE	1	ErrMsg\$
LANGID_GERMAN	2	ErrMsg\$
LANGID_FRENCH	3	ErrMsg\$
LANGID_SIMPLIFIED_CHINESE	4	ErrMsg\$
LANGID_TRADITIONAL_CHINESE	5	ErrMsg\$
MODE_STANDARD	1	PerformMode
MODE_HIGH_SPEED	2	PerformMode
MODE_LOW_OSCILLATION	3	PerformMode
ORIENT_HORIZONTAL	0	For GUI Builder
ORIENT_VERTICAL	1	For GUI Builder
PROGRESSBAR_STYLE_BLOCKS	0	For GUI Builder
PROGRESSBAR_STYLE_CONT	1	For GUI Builder
PROGRESSBAR_STYLE_MARQUEE	2	For GUI Builder
SCROLLBARS_NONE	0	For GUI Builder

Constant name	Value	Use
SCROLLBARS_HORIZ	1	For GUI Builder
SCROLLBARS_VERT	2	For GUI Builder
SCROLLBARS_BOTH	3	For GUI Builder
SETLATCH_PORT_CU_0	24	SetLatch
SETLATCH_PORT_CU_1	25	SetLatch
SETLATCH_PORT_DU1_0	56	SetLatch
SETLATCH_PORT_DU1_1	57	SetLatch
SETLATCH_PORT_DU2_0	280	SetLatch
SETLATCH_PORT_DU2_1	281	SetLatch
SETLATCH_TRIGGERMODE_LEADINGEDGE	1	SetLatch
SETLATCH_TRIGGERMODE_TRAILINGEDGE	0	SetLatch
SHUTDOWN_ALL	0	Shutdown
SHUTDOWN_RESTART	1	Shutdown
SHUTDOWN_EPSONRC	2	Shutdown
SING_NONE	0	AvoidSingularity
SING_THRU	1	AvoidSingularity
SING_THRUROT	2	AvoidSingularity
SING_VSD	3	AvoidSingularity
SING_AUTO	4	AvoidSingularity
SIZEMODE_NORMAL	0	For GUI Builder
SIZEMODE_STRETCHIMAGE	1	For GUI Builder
SIZEMODE_AUTOSIZE	2	For GUI Builder
SIZEMODE_CENTERIMAGE	3	For GUI Builder
SIZEMODE_ZOOM	4	For GUI Builder
STARTPOSITION_MANUAL	0	For GUI Builder
STARTPOSITION_CENTERSCREEN	1	For GUI Builder
STARTPOSITION_CENTERPARENT	2	For GUI Builder
TEXTALIGN_LEFT	1	For GUI Builder
TEXTALIGN_CENTER	2	For GUI Builder
TEXTALIGN_RIGHT	3	For GUI Builder
TEXTALIGN_TOPLEFT	1	For GUI Builder
TEXTALIGN_TOPCENTER	2	For GUI Builder
TEXTALIGN_TOPRIGHT	3	For GUI Builder
TEXTALIGN_MIDDLELEFT	4	For GUI Builder
TEXTALIGN_MIDDLECENTER	5	For GUI Builder
TEXTALIGN_MIDDLERIGHT	6	For GUI Builder
TEXTALIGN_BOTTOMLEFT	7	For GUI Builder
TEXTALIGN_BOTTOMCENTER	8	For GUI Builder
TEXTALIGN_BOTTOMRIGHT	9	For GUI Builder
TICKSTYLE_NONE	0	For GUI Builder
TICKSTYLE_TOPLEFT	1	For GUI Builder
TICKSTYLE_BOTTOMRIGHT	2	For GUI Builder
TICKSTYLE_BOTH	3	For GUI Builder
VISION_SORT_NONE	0	For Vision Guide
VISION_SORT_PIXELX	1	For Vision Guide
VISION_SORT_PIXELY	2	For Vision Guide
VISION_SORT_PIXELXY	3	For Vision Guide
VISION_SORT_CAMERAX	4	For Vision Guide
VISION_SORT_CAMERAY	5	For Vision Guide
VISION_SORT_CAMERAXY	6	For Vision Guide
VISION_SORT_ROBOTX	7	For Vision Guide
VISION_SORT_ROBOTY	8	For Vision Guide
VISION_SORT_ROBOTXY	9	For Vision Guide
VISION_SIZETOFind_ANY	0	For Vision Guide
VISION_SIZETOFind_LARGEST	1	For Vision Guide
VISION_SIZETOFind_SMALLEST	2	For Vision Guide
VISION_BACKCOLOR_NONE	0	For Vision Guide
VISION_BACKCOLOR_BLACK	1	For Vision Guide
VISION_BACKCOLOR_WHITE	2	For Vision Guide
VISION_CAMORIENT_STANDALONE	1	For Vision Guide

Constant name	Value	Use
VISION CAMORIENT FIXEDDOWN	2	For Vision Guide
VISION CAMORIENT FIXEDUP	3	For Vision Guide
VISION CAMORIENT MOBILEJ2	4	For Vision Guide
VISION CAMORIENT MOBILEJ4	5	For Vision Guide
VISION CAMORIENT MOBILEJ5	6	For Vision Guide
VISION CAMORIENT MOBILEJ6	7	For Vision Guide
VISION FOUNDCOLOR LIGHTGREEN	1	For Vision Guide
VISION FOUNDCOLOR DARKGREEN	2	For Vision Guide
VISION GRAPHICS ALL	1	For Vision Guide
VISION GRAPHICS POSONLY	2	For Vision Guide
VISION GRAPHICS NONE	3	For Vision Guide
VISION OPERATION OPEN	1	For Vision Guide
VISION OPERATION CLOSE	2	For Vision Guide
VISION OPERATION ERODE	3	For Vision Guide
VISION OPERATION DILATE	4	For Vision Guide
VISION OPERATION SMOOTH	5	For Vision Guide
VISION OPERATION SHARPEN1	6	For Vision Guide
VISION OPERATION SHARPEN2	7	For Vision Guide
VISION OPERATION HORIZEDGE	8	For Vision Guide
VISION OPERATION VERTEDGE	9	For Vision Guide
VISION OPERATION EDGEDETECT1	10	For Vision Guide
VISION OPERATION EDGEDETECT2	11	For Vision Guide
VISION OPERATION LAPLACE1	12	For Vision Guide
VISION OPERATION LAPLACE2	13	For Vision Guide
VISION OPERATION THIN	14	For Vision Guide
VISION OPERATION THICKEN	15	For Vision Guide
VISION OPERATION BINARIZE	16	For Vision Guide
VISION OPERATION ROTATE	17	For Vision Guide
VISION OPERATION FLIPHORIZ	18	For Vision Guide
VISION OPERATION FLIPVERT	19	For Vision Guide
VISION OPERATION FLIPBOTH	20	For Vision Guide
VISION OPERATION COLORFILTER	21	For Vision Guide
VISION OPERATION SUBTRACTABS	22	For Vision Guide
VISION OPERATION ZOOM	23	For Vision Guide
VISION ACQUIRE NONE	0	For Vision Guide
VISION ACQUIRE STATIONARY	1	For Vision Guide
VISION ACQUIRE STROBED	2	For Vision Guide
VISION TRIGGERMODE LEADINGEDGE	1	For Vision Guide
VISION TRIGGERMODE TRAILINGEDGE	2	For Vision Guide
VISION THRESHCOLOR BLACK	1	For Vision Guide
VISION THRESHCOLOR WHITE	2	For Vision Guide
VISION OBJTYPE CORRELATIO	1	For Vision Guide
VISION OBJTYPE BLOB	2	For Vision Guide
VISION OBJTYPE EDGE	3	For Vision Guide
VISION OBJTYPE POLAR	4	For Vision Guide
VISION OBJTYPE LINE	5	For Vision Guide
VISION OBJTYPE POINT	6	For Vision Guide
VISION OBJTYPE FRAME	7	For Vision Guide
VISION OBJTYPE IMAGEOP	8	For Vision Guide
VISION OBJTYPE OCR	9	For Vision Guide
VISION OBJTYPE CODEREADER	10	For Vision Guide
VISION OBJTYPE GEOMETRIC	11	For Vision Guide
VISION DETAILLEVEL MEDIUM	1	For Vision Guide
VISION DETAILLEVEL HIGH	2	For Vision Guide
VISION DETAILLEVEL VERYHIGH	3	For Vision Guide
VISION IMAGESOURCE CAMERA	1	For Vision Guide
VISION IMAGESOURCE FILE	2	For Vision Guide
VISION CODETYPE AUTO	0	For Vision Guide
VISION CODETYPE EAN13	2	For Vision Guide
VISION CODETYPE CODE39	3	For Vision Guide
VISION CODETYPE INTERLEAVED25	4	For Vision Guide

Constant name	Value	Use
VISION CODETYPE CODE128	5	For Vision Guide
VISION CODETYPE CODABAR	6	For Vision Guide
VISION CODETYPE PDF417	8	For Vision Guide
VISION CODETYPE QR	10	For Vision Guide
VISION CODETYPE EAN8	13	For Vision Guide
VISION CODETYPE UPCA	18	For Vision Guide
VISION CODETYPE UPCE	19	For Vision Guide
VISION CODETYPE UPC	20	For Vision Guide
VISION EDGETYPE SINGLE	1	For Vision Guide
VISION EDGETYPE PAIR	2	For Vision Guide
VISION IMAGECOLOR ALL	1	For Vision Guide
VISION IMAGECOLOR RED	2	For Vision Guide
VISION IMAGECOLOR GREEN	3	For Vision Guide
VISION IMAGECOLOR BLUE	4	For Vision Guide
VISION IMAGECOLOR GRAYSCALE	5	For Vision Guide
VISION POINTTYPE POINT	0	For Vision Guide
VISION POINTTYPE ENDPOINT	1	For Vision Guide
VISION POINTTYPE MIDPOINT	2	For Vision Guide
VISION POINTTYPE PERPTOLINE	3	For Vision Guide
VISION POINTTYPE STARTPOINT	4	For Vision Guide
VISION POINTTYPE PERPTOSTARTPOINT	5	For Vision Guide
VISION POINTTYPE PERPTOMIDPOINT	6	For Vision Guide
VISION POINTTYPE PERPTOENDPOINT	7	For Vision Guide
VISION REFTYPE TAUGHTPOINTS	1	For Vision Guide
VISION REFTYPE UPWARDCAMERA	2	For Vision Guide
VISION IMAGESIZE 320X240	1	For Vision Guide
VISION IMAGESIZE 640X480	2	For Vision Guide
VISION IMAGESIZE 800X600	3	For Vision Guide
VISION IMAGESIZE 1024X768	4	For Vision Guide
VISION IMAGESIZE 1280X1024	5	For Vision Guide
VISION IMAGESIZE 1600X1200	6	For Vision Guide
VISION IMAGESIZE 2048X1536	7	For Vision Guide
VISION IMAGESIZE 2560X1920	8	For Vision Guide
VISION WINTYPE RECTANGLE	1	For Vision Guide
VISION WINTYPE ROTATEDRECT	2	For Vision Guide
VISION WINTYPE CIRCLE	3	For Vision Guide
VISION ORIENT BOTH	1	For Vision Guide
VISION ORIENT HORIZ	2	For Vision Guide
VISION ORIENT VERT	3	For Vision Guide
VISION DIRECTION INSIDEOUT	1	For Vision Guide
VISION DIRECTION OUTSIDEIN	2	For Vision Guide
VISION POLARITY DARK	1	For Vision Guide
VISION POLARITY LIGHT	2	For Vision Guide
VISION PASSTYPE SOMEFOUND	1	For Vision Guide
VISION PASSTYPE ALLFOUND	2	For Vision Guide
VISION PASSTYPE SOMENOTFOUND	3	For Vision Guide
VISION PASSTYPE_ALLNOTFOUND	4	For Vision Guide
WIN IOMON	-1	For GUI Builder
WIN TASKMGR	-2	For GUI Builder
WIN FORCEMON	-3	For GUI Builder
WIN SIMULATOR	-4	For GUI Builder
WINDOWSTATE NORMAL	0	WindowsStatus
WINDOWSTATE MINIMIZED	1	WindowsStatus
WINDOWSTATE MAXIMIZED	2	WindowsStatus
WithMove	0	Recover
WithoutMove	1	Recover

6.25 Calling Native Functions in Dynamic Link Libraries

EPSON RC+ 7.0 allows you to call native functions in Dynamic Link Libraries (DLLs).

This is used for complicated arithmetic processing and call for a native function of an external device.

To call the native DLL function, use a `Declare` statement which is a function definition command from the SPEL+ program and write a function call as normal.

For details, refer to the *Declare* in the *EPSON RC+ 7.0 SPEL+ Language Reference*.

Sample of calling a native DLL

By using a development tool such as Microsoft Visual Studio 2019, you can create a native DLL that can be called from SPEL+. Here, it uses Visual Studio 2019 as a sample to create a function that executes the arithmetic operator.

Step 1: Decide on variable type for a native DLL

You need to plan the data type to use for transferring with the native DLL in the EPSON RC+ 7.0.

Correspondence table for the EPSON RC+ 7.0 data type and the C/C++ variable type is shown below.

You cannot use the C/C++ byte type and structure because the EPSON RC+ 7.0 has no correspond data for them.


Data correspondence

EPSON RC+ 7.0	C/C++
Boolean	short
Byte	short
Short	short
Integer	short
Long	int
Real	float
Double	double
String	char [256] * Null included

Step 2: Create a native DLL

- (1) Start Visual Studio 2019.


Select the “Create a new project” on the start window.



- (2) [Create a new project] dialog box will appear.

Select “Windows Desktop Wizard” from the project template list shown on the right of dialog box.


Click the <Next> button.



(3) Start the Windows Desktop Wizard.

Type in a name for a project in the [Project name] box.
(Here types in “MyCalculator”.)

Click the <Create> button.




(4) Set the project options.

Select the “Dynamic Link Library (.dll)” in the [Application type].

Check the [Export symbols] box in the [Additional options:].


Click the <OK> button.



- (5) A simple example of function “fnMyCalculator” will be created in MyCalculator.cpp. Add a function MyArithmetic which executes the arithmetic operator to this file.

```
MYCALCULATOR_API float MyArithmetic(short value1, short
value2, char * kind )
{
    if ( !strcmp(kind, "add") )
    {
        return (float)(value1 + value2);
    }
    else if ( !strcmp(kind, "sub") )
    {
        return (float)(value1 - value2);
    }
    else if ( !strcmp(kind, "mul") )
    {
        return (float)(value1 * value2);
    }
    else if ( !strcmp(kind, "div") )
    {
        return (float)(value1) / (float)(value2);
    }
    else
    {
        strcat_s(kind, 10, " NG");
        return 0;
    }
}
```

- (6) Export a function to enable it to be called from SPEL⁺.
 Select Visual Studio 2019 menu-[Project]-[Add New Item].
 The [Add New Item] dialog box will appear.



Select the [Visual C ++]-[Code] in the tree on the left.

Select “Module-Definition File (.def)” from the project template list shown on the center of dialog box.

Type in a file name in the [Name:].

(Here types in “MyCalculator.def” as a file name.)

Click the <Add> button.

Register “fnMyCalculator function” and “MyArithmetic function” to the created “MyCalculator.def” file.

```
LIBRARY      "MyCalculator"

EXPORTS

    fnMyCalculator
    MyArithmetic
```

- (7) Build the project and create the DLL.

Select [Win32] as a solution platform for Visual Studio 2019. Then, select Visual Studio 2019 menu-[Build]-[Build MyCalculator].

DLL will be successfully created if no error occurs.

NOTE



In EPSON RC+ 7.0, 64 bit native DLL is not available. When using a DLL created with a version older than Visual Studio 2015, it is necessary to install the runtime corresponding to that version in advance.

Step 3: Call the DLL function from SPEL+

You can now try your DLL function from SPEL+.



Before you call your function from the EPSON RC+ 7.0, you must debug it and check thoroughly if it can work without errors.

In case that error occurs (such as system error) in the native function, the EPSON RC+ 7.0 will not work normally.

- (1) Copy the created MyCalculator.dll to the EPSON RC+ 7.0 project folder (e.g. C:\EpsonRC70\projects\dlldcall).
- (2) Define a DLL function which executes the arithmetic operator in the SPEL+ program and write a function call for MyArithmetic in Function main.

```

Declare MyArithmetic, "MyCalculator.dll" (value1 As Integer,
value2 As Integer, ByRef calc$ As String) As Real
Function main
    Real result;
    String calc$

    calc$ = "add"
    result = MyArithmetic(1, 2, ByRef calc$);
    Print "1+2=", Str$(result)
    calc$ = "sub"
    result = MyArithmetic(1, 2, ByRef calc$);
    Print "1-2=", Str$(result)
    calc$ = "mul"
    result = MyArithmetic(1, 2, ByRef calc$);
    Print "1*2=", Str$(result)
    calc$ = "div"
    result = MyArithmetic(1, 2, ByRef calc$);
    Print "1/2=", Str$(result)
Fend
  
```

- (3) Build and execute the project.

The following result will be displayed.

```

1+2=3
1-2=-1
1*2=2
1/2=0.5
  
```



Before you build the project, be sure to copy the native DLL to the project folder without fail. If you fail, a warning or error will occur.

Please note the dependency of the DLL when using a third party DLL as a native DLL. If the dependent DLL does not exist in the project folder or the folder set in the environment variable PATH of Windows, a warning or error will occur.

7. Building SPEL+ Applications

7.1 Designing Applications

7.1.1 Creating the simplest application

The simplest SPEL+ application has one program and one point file. This is what is automatically defined for you when you create a new project. A blank program named “Main.prg” and a blank point file named “Points.pts” are created.

To write and run a simple application

1. Select [New Project] from the [Project] menu to create a new project.
2. Write your program source code in the file that was created for you called “Main.prg”.
3. Teach the robot points using the [Robot Manager]-[Jog & Teach] page.
4. Run the program by selecting [Run] Window from the [Run] menu or by pressing F5 (the shortcut key for the [Start] command).

7.1.2 Application layout

Before writing your application, you need to decide what your application will accomplish and how the project will be structured. Here are some general guide lines.

Programs

Each project can contain up to 64 programs that can be started from the Operator Window, Remote Control, RC+ API, or GUI Builder. Each program has a start function, as shown in the table below.

Program #	Program Name	Start Function
0	main	main
1	main1	main1
2	main2	main2
3	main3	main3
4	main4	main4
5	main5	main5
6	main6	main6
7	main7	main7
...
63	main63	main63

Your project must always define function main so that the main program can be started. The other programs are optional. If you use the Operator Window for your operator interface, you can define meaningful names for each of the programs used in your project in [Project]-[Properties]-[Operator setting]-[Operator Window].

Operator interface

Operator Window

Use the operator window provided with EPSON RC+ 7.0. You can configure EPSON RC+ 7.0 so that after Windows starts, EPSON RC+ 7.0 will start in Auto mode, which will automatically open the Operator Window.

Operators can select up to 64 programs. They can also optionally use the Pause/Continue buttons, I/O Monitor, Robot Manager, and System History viewer.

To use the Operator Window to allow programs to be started and stopped, the Control Device must be set to Self from [Setup]-[System Configuration]-[Controller]-[Configuration].

For details on configuring EPSON RC+ 7.0 for auto start, refer to *4.2.3 Start Mode*.

Remote Control

Use remote control to turn motors on/off, home the robot, start programs, etc. A simple push button box can be used, or a PLC can be connected.

When using Remote Control, the Control Device must be set to Remote from [Setup]-[System Configuration]-[SPEL Controller Board]-[Configuration].

Windows Applications using RC+ API

Use the RC+ API Option along with a Windows development tool such as Visual Basic, Visual C#, or Visual C++. See the RC+ API Manual for more information.

GUI Builder

To use the GUI Builder option, refer to the *GUI Builder manual*.

Safety interface

Use guard doors, safety mats, light curtains, etc. to protect the operator from injury.

Robot Points, Pallets, Tools, Locals

Decide on which points you need for the work cell. In many cases you will only need one point file per robot.

Take advantage of Pallets, Tools, and Locals. Time spent on using these can save hours later on the production line. For example, if your cell has many points that take a lot of time to train, consider using Locals so that if the end effector is damaged or replaced, you only need to redefine the Locals, not retrain all of the points.

Try to design in automatic or semi-automatic procedures for calibrating tools and locals. Even if you define them manually, write instructions on how to define them so the process can be repeated easily.

Inputs and outputs

Layout your I/O early in the design stages. Use I/O labels in your programs. You must purchase additional I/O boards if you need more than 24 inputs or 16 outputs. You can also use the Fieldbus option so the controller can be a Fieldbus slave.

Peripherals

The Robot Controller has one RS-232C port as standard. Available ports can be added up to 5 ports by installing an optional RS232C expansion board. Refer to *13. RS-232 Communications* for details.

NOTE



T series and VT series manipulator do not have RS-232C port on the controller. Optional RS-232C expansion board cannot be added.

You can use TCP/IP to connect peripheral equipment.
Refer to *14. TCP/IP Communications* for details.

7.1.3 Auto start at power up

Your application can automatically log in a Windows user and start you SPEL⁺ project after Windows boots.

Refer to *4.2.7 Auto Start*.

7.2 Managing Projects

7.2.1 Overview

What is an EPSON RC+ 7.0 Project?

An EPSON RC+ 7.0 project is a collection of SPEL⁺ program files, include files, robot point files, I/O labels, user errors, Vision settings, and conveyor settings used to run a SPEL⁺ application.

Why do you need projects?

Projects are a safe and convenient way to manage your SPEL⁺ applications. All the information for each application is kept in one project. By keeping all of your application code and point definitions in one project, it is easy to open a project and begin running or editing. Also, it is easy to create new versions of an application and run older versions.

Projects make it easier to maintain your application code with less chance of a program being lost.

There are also functions for copying and renaming projects, making it easy to create new projects from previous versions and for backing up projects to an external media such as a USB memory key.

What does an EPSON RC+ 7.0 project consist of?

Each project is stored in the \EpsonRC70\Projects directory.

The following paragraphs describe the components of a project.

Project file

This file contains all of the information that describes the project. This file is automatically created by EPSON RC+ 7.0. You should never edit this file. Doing so may cause errors when you open the project. The file extension is “.sprj”.

Program files

A program file is an ASCII text file that contains one or more SPEL⁺ functions. Each function in SPEL⁺ can be run as a separate task (thread) in the controller or called from other functions.

Include files can also be used. These contain macro definitions and must be included in a program file using the #include statement. The file extension is “.prg”.

Point files


A point file contains a list of robot points. The file extension is “.pts”.

Include files

In the include file, you can declare variables and macros. The file extension is “.inc”.

7.2.2 Creating a new project

Projects always reside in specific drive, \EpsonRC70\Projects folder. Also you can create a sub-folder to systematize the projects of different types.



To create a new project

1. Select [New Project] from the [Project] menu.
The [New Project] dialog box will appear.
2. Select the disk drive where you want the project to be stored on.
3. Select the project folder or create a new folder by clicking the <New Folder> button after selecting the parent folder.
4. Type in the name for the new project.
5. Optionally, select a template to base the project on.
6. Choose <OK> to create the project.


7.2.3 Configuring a project

Each application project you create must be configured properly before you can run the program.

There are two commands in the [Project] menu that allow you to configure a project: [Edit and Properties].

Editing a project

Select [Edit] from the [Project] Menu to open the [Edit Project] dialog. From this dialog, you configure program files, include files, and point files used in the current project.




For details on [Project]-[Edit], refer to 5.9.5 *[Edit] Command (Project Menu)*.

7.2.4 Building a project

Before you run any program in your application, you must build the project.


To build your application project

Select [Build] from the [Project] menu or click on the <Build> button  on the toolbar.

Or

Select [Rebuild] from the [Project] menu. This will rebuild the entire project.

Or

Select [Run Window] from the [Run] menu or click the <Run> button  on the toolbar. The project will be built before the [Run] Window appears.


Or

Select [Operator Window] from the [Run] Menu. The project will be built before the [Operator Window] appears.

After the files have been compiled and linked, the project files are sent to the controller.

Status Pane

This window shows progress messages and error messages during project build.



When errors occur during the build process, a message is displayed that includes the error number, program file name, and line number. Double click on the line with the error to go directly to the source code that caused the error.

7.2.5 Backing up a project

To make a backup copy of the current project, use the [Copy Project] command in the [Project] menu to copy the project to another disk drive or folder. You can also save the project under a different name.

This command is useful for transferring a project to an external media such as a USB memory.

7.3 Editing Programs

Before you can edit a program, it must be in the current project and opened in a program window.

To open a program for editing

1. Select [Open] from the [File] menu.
2. Select the file(s) you want to open.
3. Choose <OK> to open the file.

7.3.1 Program rules

A program contains one or more SPEL⁺ function definitions.

Lines can be blank. You can insert any number of blank lines to separate subroutines and functions, if desired.

The maximum length for each line is 512 characters, including the line number, if used.

7.3.2 Typing in program code

You can enter program statements in upper or lower case. Whenever you leave a line that has been changed, the line will be formatted. SPEL⁺ keywords are case formatted and spaces are inserted around operators and after semi-colons and commas.

Consider using mixed case or lower case for variables and function names instead of all CAPS. This will make your code easier to read.

Use indentation for statements within loops. The “Auto Indent” feature automatically moves the cursor under the start of the previous line. It also indents lines after If, Else, For, Select, Case, and Do statements.


```
For i = 1 To 10
    Jump P(i)
    Jump P0
Next i
```

Use the “Auto End Construct” feature to automatically add the end construct statement. For example, when you enter a For statement and press <Enter>, a Next statement is automatically created with an indented blank line above it.

7.3.3 Syntax Help


When you type in a SPEL+ keyword, the syntax help window will appear to show the syntax of the statement or function. After the statement is entered, the syntax helper will automatically close, or you can press the Esc key to close it. You can enable / disable Syntax Help from the [Setup]-[Preferences]-[Editor] tab.

A list box will be displayed for some parameters as you type. To select a value in the list, use the up and down arrow keys, or type the first few characters, to highlight the desired item, then press <Tab> to select the item. You can also type in a value not shown in the list, such as a variable or literal constant. Press <Esc> to hide the list box. In addition to <Tab>, you can use a comma or period to select an item. In the example shown below, the first parameter of the On statement can be an output label, so a list of output labels in the current project is displayed.



7.3.4 Syntax Errors

When a syntax error is detected, the line with the error will be displayed in red. If the caret is placed on the line with the error, then a brief message will be displayed on the status bar. For example, in the program shown below, the message "Expression expected" is displayed on the status bar.




7.4 Editing Points

You can edit the robot points from the robot point file. You can define new points or cut, copy, and paste points from one point file to another, including between projects.

To open a point file for editing

1. Select [Open] from the [File] menu to show the Open dialog box.
2. Choose the Points option button. You will see a list of point file names in the files list box.
3. Select the point file you want to edit by clicking on the name.
4. Click <Open> to open the file. You will see a spread sheet window for the point file you selected.

The robot points spread sheet window



The spreadsheet window contains one row for each point in the file. The spreadsheet always contains rows for all points, even if they are not defined. The cells for an undefined point are blank.

Item	Description
Row select column	This is the leftmost column. Click on this column to select a row.
Number column	Point number. Range is from 0 to a maximum point number.
Name column	Name of the point.
Coordinate columns	Coordinates of X, Y, Z in millimeters and U, V, and W in degrees.
Local number column	Drop down list of local numbers. Range is from “0” to “15”.
Hand column	Drop down list of robot hand orientations: Lefty and Righty.
Elbow column	Drop down list of robot elbow orientations: Above and Below. This column is shown only for 6-axis robots.
Wrist column	Drop down list of robot wrist orientations: Flip and NoFlip. This column is shown only for 6-axis robots.
J4Flag column	Drop down list of robot J4Flag: “0” and “1”. This column is shown only for 6-axis robots.
J6Flag column	Drop down list of robot J6Flag: “0” – “127”. This column is shown only for 6-axis robots.
J1Flag column	Drop down list of robot J1Flag: “0” and “1”. This column is shown only for RS series and 6-axis robots.
J2Flag column	Drop down list of robot J2Flag: “0” and “1”. This column is shown only for RS series.
J1Angle	Coordinate in units of degrees. This column is shown only for RS series and N series.
J4Angle	Coordinate in units of degrees. This column is shown only for N series.

To select one or more rows

Click on the row select column (leftmost column) to select a row. To select more than one row, point to the row select column of the first row you want to select. Hold down the left mouse button and drag the mouse down or up to select more rows.

To select all rows

Execute Select All from the Edit Menu, or type <Ctrl> + A.

To define a new point

Move the cursor anywhere in the row of the point you want to define using the mouse, and then click a cell you want to type in. Enter information for the point. This automatically defines the point, which means it will be sent to the robot controller at the next project build or Jog and Teach command.

For example, click on the Name column and type in a name of the point. Press the <TAB> key to move to the X coordinate column. Type a coordinate value and then press <Enter>. You will see zeros automatically entered in all of the other coordinates. This means that the point is defined.

To delete a point

Select the row containing the point and cut it by selecting [Cut] from the [Edit] menu or by typing <Ctrl> + X.

To cut and paste points

1. Select one or more rows and execute either [Cut] or [Copy] from the [Edit] menu.
2. Select the row where you want to start the paste.
3. Select [Paste] from the [Edit] menu.

7.5 Running and Debugging Programs

You can run programs from the Run Window or from the Operator Window. The Run Window is used primarily for testing and debugging. The Operator Window is used as an operator interface for simple applications or demos. You can also run programs using the RC+ API option or GUI Builder option.


To run a program

Select [Run] Window from the [Run] menu. This command will build the project (if required) and open the [Run] Window. The [Run] Window allows you to choose which function to execute. Select a function, and then click <Start>.

7.5.1 The Run window


The Run window includes controls for running the programs in the current project.

To open the Run window

Select [Run] Window from the [Run] Menu, or click on the <Run> button  on the toolbar. If necessary, all changed open files will be saved and the project will be built. If the build is successful, the Run window will appear.

To close the Run window

Choose [Close] from the [File] menu or click on the **X** button in the upper right hand corner of the window.



Item	Description
Text area	This is the area that takes up most of the run window. Output from your programs is displayed here. When your program uses an Input statement, you can type in the requested input from this text box. You can use the scroll bars to view the entire text buffer. If an error occurs while running a program, the error number, program file name, line number and function name will be displayed in this text area. You can double click on the line where the error is displayed to directly go to the source line that caused the problem.
Function	Select a function to start. Functions are sorted alphabetically. Function main is selected by default.
Low Power	When this box is checked, SPEL+ ignores the Power High command. This allows you to run your program in low power mode to verify operation without having to change the program.
Speed Factor	Specifies the robot motion speed factor. The speed factor is a percentage of maximum point to point speed and linear interpolated speed. For example, if you program executes Speed 80 and the speed factor is 50%, the robot will move at speed 40.
Start	Starts the function shown in the function drop down list.
Stop	Stops all tasks. If the robot is executing a motion command when this button is pressed, the robot will decelerate to a stop.
Pause	Pauses all tasks with pause enabled. Activates the <Continue> button. If the robot is executing a motion command when this button is pressed, the robot will decelerate to a stop.
Continue	Continues paused tasks.
CTRL+C	Same as <Stop> button.

7.5.2 Debugging

EPSON RC+ 7.0 supports source level debugging. You can set breakpoints and step through your source code. You can also pause / continue a program or halt a task using the Task Manager.

Setting and clearing breakpoints

Open the program where you want to set a breakpoint, and then click on the line where you want to stop. Use one of the following methods to set a breakpoint:

- If Margin Indicators are enabled, then click in the margin next to the line on the left. You will see a breakpoint symbol next to the line.

Or

- Type F9.

Or

- Select Toggle Breakpoint from the [Run] menu.


Execute one of the methods above to clear a breakpoint, or select [Clear All Breakpoints] from the [Run] menu.

You cannot set a breakpoint on non-executing statements, such as #define, #include, or blank lines.

After setting a breakpoint, the task will halt when the execution line is reached the breakpoint. You can set or clear a breakpoint while a task is running.

When reached a breakpoint, the program window containing the program source line at the breakpoint is opened and the line is highlighted in yellow. The task number is shown in the title of the program window.

If more than one task reaches a breakpoint, then a program window will be opened for each task. This allows you to step through each task that reached the breakpoint.



Stepping through a program

There are three commands on the [Run] Menu that are used for stepping through code.

[Step Into] steps through each line and also steps into functions when a step is executed on a Call statement.

[Step Over] steps through each line but when a Call statement is encountered, the function in the statement is executed completely.


Walk executes lines until after the next motion command and then halts the task. It will halt after the next output command if the [Setup]-[System Configuration]-[Controller]-[Preferences]-[Walk stops for outputs] checkbox is checked.

To step through code, you must set a breakpoint and run until the breakpoint is reached, or suspend a task from the Task Manager using the <Halt> button.

Viewing the Call Stack


Sometimes you may want to examine the call stack for the current task after you halt the task from the task manager, or reach a break point.

To view the call stack, select [Call Stack] from the [Run] Menu. The [Call Stack] list will be displayed, as shown below.



7. Building SPEL+ Applications


After you double click a function in the Call Stack list, the function will be displayed in a program window and an arrow in the left margin will point to the line where the next function in the call stack is being called. In the example below, the arrow in the SingleCycle function is pointing to the Gripper On statement to indicate that Gripper was called from SingleCycle.



Displaying variables

To view variable values, you can do one of the following:

1. When a task is halted by halt or breakpoint, you can view the value for a variable by moving the mouse cursor over the variable name. The value will be displayed in a tool tip window above the variable name.




2. Select [Display Variables] from the [Run] menu to display the variable display dialog. This dialog has three tabs for viewing Global, Module, and Local variables.

NOTE




Up to 600 variables can be displayed on each tab.



You can change the value of a variable by checking the [Edit] checkbox, then type in the new value in the value column. Next, click the <Write> button to change the variable. When the [Edit] box is checked, the variable values are not automatically updated. You can click the <Read> button to update all values.

7.6 The Operator Window


The Operator Window can be used as a simple interface for operators. You can configure EPSON RC+ 7.0 to open only the Operator Window when started. In addition, when Remote Control is being used, the Operator Window can be displayed for monitoring purposes.



Item	Description
Program to Run	Select a program to run.
Start	Starts the selected program.
Stop	Stops all tasks.
Pause	Pauses all tasks that are enabled for pause.
Continue	Continues paused tasks.
Robot Manager	Opens the Robot Manager dialog in operator mode. It cannot be shown while the program is running.
I/O Monitor	Opens the I/O Monitor in operator mode. This window can remain open while programs are running.
System History	Opens the System History window. This window can remain open while programs are running.
Status Bar	The status bar is located at the top of the window and shows emergency stop and safeguard status. In addition, if a warning is detected from the controller (such as low encoder battery), a warning label will be displayed on the right side of the status bar. If the mouse is over this label, you can see the warning error message. When there is no warning, the warning label is hidden.

7.6.1 Operator window configuration

You can configure the Operator Window from the Operator Window pages in [Project]-[Properties].



There are several settings for operator Robot Manager and I/O Monitor.

For details, refer to 5.9.15 [Properties] Command (Project Menu).

7.6.2 Auto start configuration

You can configure the system to let it log into Windows automatically. Also you can configure a program to start automatically from the [Operator] window. For details, refer to 4.2.7 Auto Start.



7.7 Using Remote Control

You can design your application to be run from external equipment using hardware I/O control. This includes push button boxes, PLCs, and other PC systems.

Refer to *12. Remote Control* for details.

7.8 Using Encrypt Files


Encrypted files allow you to prevent end users from viewing your source code. When a file is encrypted, you must supply a password to open the file. Other users cannot view the file contents, even with an external editor, such as Notepad.

Each encrypted file can have its own password, or you can choose to encrypt multiple files with one password. You can encrypt program files, include files, Vision Guide, and GUI Builder.

If an encrypted file is imported from another project, it will remain encrypted in the current project.

As an example, assume you have some special SPEL+ programming code that you do not want your end users to view. But you want to allow end users to change some of the code in the project. To do this, put all of the functions you want to be hidden in one or more encrypted program and include files. When you go to the customer site, you can view your encrypted code by supplying the password(s) to open the encrypted files.

When files are encrypted, their icons are shown with a lock in the Project Explorer and also in the title bar of the program window. In the screenshot below, the file `MainCycle.prg` is encrypted, so its icons include a lock image.



When you open an encrypted file, you will be prompted for the password.



NOTE



Up to 16 characters can be entered for password.



■ **USE EXTREME CAUTION!**

Keep a record of the password(s) used for encryption in a safe place.
Once a file is encrypted, it can only be opened with the password you enter.
If you forget the password, the file contents CANNOT BE RECOVERED.

To configure encrypted files in your project, select Properties from the Project menu, then select Encrypted Files in the tree on the left.

Refer to section 5.9.15 [*Properties*] *Command (Project Menu)* for details.

8. Simulator

8.1 Simulator Functions

Simulator functions enable easy robot motion checking on your PC, which gives you flexibility to consider the system layout, measure the operation time, and create robot programs.

They are useful from the introduction stage to the launch of robot system.

8.1.1 Overview

The following are the major simulator functions:

Robot motion 3D display

Shows robot orientation and motion in a 3D display from various viewpoints.
Offers accurate display data based on design data.

This function is not available for the manipulator series (models) as described below.
If a simplified layout consideration or measurement of motion time is needed, set an alternative model. However, external dimensions and motion range may differ.
Be careful when you set the alternative models.

For details on the unsupported models, refer to the following section.

Appendix C: Simulator Functions List of Unsupported Manipulator Models

Series	Model	Alternative model (When using a Virtual Controller)	
X5	All models	No alternative model	-
G6	Protected model G6-***D*, G6-***P*	Standard model, Cleanroom model G6-***S*, G6-***C*	*
G6-II	Protected model G6-***D*-II, G6-***P*-II	Standard model, Cleanroom model G6-***S*-II, G6-***C*-II	*
G10	Protected model G10-***D*, G10-***P*	Standard model, Cleanroom model G10-***S*, G10-***C*	*
G10-II	Protected model G10-***D*-II, G10-***P*-II	Standard model, Cleanroom model G10-***S*-II, G10-***C*-II	*
G20	Protected model G20-***D*, G20-***P*	Standard model, Cleanroom model G20-***S*, G20-***C*	*
G20-II	Protected model G20-***D*-II, G20-***P*-II	Standard model, Cleanroom model G20-***S*-II, G20-***C*-II	*

*: External dimensions and motion range differ.

Interference check

Checks whether the robot (including the hand and devices installed on the robot) interferes with itself or its peripherals.
(This function is not available for the robots that do not support 3D display.)

Robot operation time prediction

Predicts the robot operation time for a program.
Considers the speed setting (Speed, etc.) and acceleration / deceleration setting (Accel, etc.) when predicting the robot motion time.

SPEL+ program execution

Allows you to create, execute, and debug SPEL+ programs.

The restrictions on the simulator functions are described in *8.4 Simulator Specifications and Restrictions*.

8.1.2 System Requirements

Recommended specification

When using CAD data, we recommend the following environment.

OS	Windows 10 Pro 32 bit version / 64 bit version Windows 8.1 Pro 32 bit version / 64 bit version
CPU	Core i5 or more
Memory	2 GB or more
Hard disk spare capacity	4 GB or more
Graphic	DirectX10.1 or later must be available. OpenGL2.1 or later must be supported.

Minimum specification

To use one robot with several peripherals and operate them in a simple manner, the following environment is required.

OS	Windows 10 Pro 32 bit version Windows 8.1 Pro 32 bit version
CPU	1.6 GHz or more, 32 bit (x86) Multi Core Processor
Memory	1 GB or more
Hard disk spare capacity	4 GB or more
Graphic	OpenGL1.5 or later must be supported.

8.2 Using the Simulator


You can try the simulation functions using the provided sample virtual controllers and projects.

8.2.1 Working with the samples

You can operate a robot easily using the samples provided. Follow the steps below:

1. Connect with a sample virtual controller (robot)
2. Open the corresponding sample project
3. Display the [Robot Simulator] window
4. Operate the robot by executing a program
5. Next step


1. Connect with a sample virtual controller




Select “C4 Sample” from the EPSON RC+ 7.0 Tool bar-<Connection> list box.
When the connection is complete, the <Connection> list box shows “C4 Sample”.

2. Open a corresponding sample project

- (1) Click the EPSON RC+ 7.0 menu-[Project]-[Open...].
- (2) Select [Projects]-[SimulatorDemos]-[C4 Sample].



(3) Click the <Open> button. Then, the following program window appears.





```

Main.prg
C4 Sample Project
Use these programs with the C4 Sample virtual cont
Sample Program 1
Robot works on the center table.
Function main
Integer i
Motor On
Power High
Speed 100, 50, 50
Accel 100, 100, 50, 50, 50, 50
SpeedS 2000, 1000, 1000
AccelS 20000, 20000, 10000, 10000, 10000, 10000
Go XY(0, 450, 260, 90, 0, 180)
For i = 0 To 2
Jump3 Here -TLZ(50), P0 -TLZ(50), P0
Wait 0.1
Jump3 Here -TLZ(50), P1 -TLZ(50), P1
Wait 0.1
Jump3 Here -TLZ(50), P2 -TLZ(50), P2


```


3. Display the [Robot Simulator] window

Click the Tool bar-<Simulator 



4. Operate the robot by executing program

- (1) Click the Tool bar-<Run Window  > button. The project will be built and the [Run] window will appear.



- (2) Click the <Start> button.
The message “Are you ready to start?” appears. Click the <Yes> button.
The program starts and the robot moves in the 3D display.

5. Next step

If you want to change the sample, follow the steps in 8.2.2 *Working with the user created system - Steps 5 to 7*. If you want to create your own system, start from *Step 1*.

If you want to change the sample virtual controller, follow the steps in 8.3.7 *Virtual controller - Copy the sample or configured virtual controller* and change the copied sample.

8.2.2 Working with the user created system


You can create your own system and simulate the robot operation on your PC.

Follow the steps below:


1. Create a new virtual controller (Connection setting)
2. Connect with the virtual controller
3. Configure a robot
4. Display the [Robot Simulator] window
5. Create and place objects
6. Create a project and program
7. Operate the robot by executing the program
8. Measure the robot operation time
9. Test for collisions

1. Create a new virtual controller (Connection setting)


- (1) Click the EPSON RC+7.0 Tool bar-<Setup PC to robot controller communications.  > button. The [PC to Controller Communications] dialog appears.



- (2) Click the <Add> button. The [New Controller Connection] dialog appears.
 (3) Select the [Connection to new virtual controller] and click the <OK> button.



- (4) A new virtual controller named “Virtual 1” is created. Click the <Apply> button.

**Note: Program total execution time**

In the virtual controller, the total execution time of programs is limited to one hour.

If total execution is over one hour, a warning message appears.

You can execute the program again after the warning is displayed, and the total execution timer will be reset.

- (5) Close the dialog to return to the EPSON RC+ 7.0 main window.

2. Connect with the virtual controller


Connection: Virtual 1

- (1) Select the created “Virtual 1” connection from the EPSON RC+ 7.0 Tool bar-<Connection> list box. When the connection is complete, the <Connection> list box shows “Virtual 1”.

3. Configure a robot


In this tutorial, a C4-A601S robot model is used.

- (1) Select the EPSON RC+ 7.0 menu-[Setup]-[Controller].
- (2) Select the [Controller]-[Robots] from the tree, the message “There are currently no robots in the system. Click the Add button to add a robot” will appear.




- (3) Click the <Add> button to open the [Add New Robot] dialog box. Input the robot information as follows:


[Robot Name]: robot1
 [Robot Serial #]: 1
 [Drive Unit]: CU
 [Robot Type]: Six Axis
 [Series]: C4
 [Robot]: C4-A601S



- (4) Click the <Apply> button. The message “Restarting Controller” appears.
- (5) When the message disappears, close the window and go back to the EPSON RC+ 7.0 main window.

4. Display the [Robot Simulator] window


- (1) Click the Tool bar-<Simulator 



5. Place the objects

For this tutorial, we will add a box to the layout.

- (1) Click the <Box 



- (2) Select “SBox_1” from the [Layout Objects] and change the [Property]-[Position]. For this tutorial, enter X = 600, Y = 300.



To change the position, you can also drag the objects in the [2D Layout] tab.


To save the layout change, execute the EPSON RC+ 7.0 menu-[File]-[Save].


6. Create a project and program

(1) Create a new project


- (1)-1 Click the EPSON RC+ 7.0 menu-[Project]-[New Project].
- (1)-2 Enter a new project name. For this tutorial, enter “Test”.
- (1)-3 Click the <OK> button. Then, the project “Test” is created.


(2) Operate the robot and teach points.

- (2)-1 Click the Tool bar-<Robot Manager  > button. The [Robot Manager] window appears.
- (2)-2 Select the [Control Panel] tab and click the <MOTOR ON> button. The message appears to confirm the operation. Click the <Yes> button.
- (2)-3 Select the [Jog & Teach] tab. The following dialog appears.



- (2)-4 In the [Robot Simulator] window, move the robot joint to a point where it does not interfere with the box.

To move the robot joint, click the <Rotate/Jog  > button on the tool bar and drag the joint, or drag while simultaneously pressing the <Ctrl> key.



- (2)-5 Go back to the [Robot Manager] window and click the <Teach> button in the [Teach] tab. The message appears to confirm the operation. Click the <Yes> button.
- (2)-6 The [New Point Information] dialog appears. Click the <OK> button.
- (2)-7 Select “P1 - (undefined)” from the [Point] list box on the lower right.
- (2)-8 In the [Robot Simulator] window, drag the robot joint while simultaneously pressing the <Ctrl> key to another point without interfering with the box.

- (2)-9 Go back to the [Robot Manager] window and click the <Teach> button. The message appears to confirm the operation. Click the <Yes> button.
- (2)-10 The [New Point Information] dialog appears. Click the <OK> button.
- (2)-11 Click the Tool bar-<Save all files> button to save the P0 and P1 data.



You can also use the [Jog & Teach] window to move the robot.

- (3) Create and execute a program with robot motion.


- (3)-1 Create the following program in the program “Main.prg”.

```
Function main
    Go P0
    Go P1
Fend
```

- (3)-2 Click the Tool bar-<Build> button to build the program.
When the program building is completed, the message “Build complete, no errors” appears in the [Status] window.

7. Operate the robot by executing program

- (1) Click the Tool bar-<Run Window> button. The following window appears.




- (2) Click the <Start> button.
The message “Are you ready to start?” appears. Click <Yes> button.
The program starts and the robot moves in the 3D display.

8. Measure the robot operation time

The elapsed program run time (cycle time) is displayed in the Tool bar of the [Robot Simulator] window.

It is the execution time of the program from start to finish.



The following describes how to measure the operation time between two points (P0 → P1).

- (1) Change the program in the “Main.prg” file to the following program.

```
Function main
    Motor On
    Power High
    Speed 100
    Accel 100,100
    Go P0
Fend

Function main2
    Go P1
Fend
```

- (2) Click the Tool bar-<Build> button to build the project.
When the project build is complete, the message “Build complete, no errors” appears in the [Status] window.
- (3) Click the Tool bar-<Run Window> button.
- (4) Confirm that “main” is selected in the [Function] dropdown list and click the <Start> button.
The message “Are you ready to start?” appears. Click <Yes> button.
The program starts and the robot goes to P0, the point to start the time measurement, in the 3D display.
- (5) Select “main2” in the [Function] dropdown list.
- (6) Click the <Start> button.
The message “Are you ready to start?” appears. Click the <Yes> button.
The program starts and the robot moves in the 3D display.
Now, the cycle time displayed in the Tool bar is the execution time to move the robot from P0 to P1.



When you operate the real robot, the actual cycle time will be longer than the simulated cycle time according to the model, Fine, load settings. For details, refer to *8.4 Simulator Specifications and Restrictions*.




Also, when Speed, Accel values in the program are changed, the cycle time will reflect it.

Motion command includes Move and Jump as well as Go.

For the information on how to use these commands, refer to *Online Help* or *SPEL⁺ Language Reference manual*.

9. Test the collision detection

- (1) Go back to the [Robot Simulator] window.
- (2) Drag the robot joint while simultaneously pressing the <Ctrl> key to a point where it interferes with the box. When the robot joint hits the box, the display turns to red.
- (3) In the [Robot Manager] window, select “P2 - (undefined)” from the [Point] list box in the [Teach] tab.
- (4) Click the <Teach> button.
The message to confirm the operation appears. Click the <Yes> button.
- (5) The [New Point Information] dialog appears. Click the <OK> button.
- (6) Click the Tool bar-<Save all files> button and save the P2 information.
- (7) Go back to the [Robot Simulator] window and drag the robot joint while simultaneously pressing the <Ctrl> key to the point where it does not interfere with the box.
- (8) Click the Tool bar-<Reset Collision  > button. Then, the red display returns to normal.
- (9) Add the following function to the “Main.prg” program file.

```
Function main3
    Go P2
Fend
```
- (10) Click the Tool bar-<Build> button to build the project.
When the project build is complete, the message “Build complete, no errors” appears in the [Status] window.
- (11) Click the Tool bar-<Run Window> button.
- (12) Select “main3” in the [Function].
- (13) Click the <Start> button. The message “Are you ready to start?” appears. Click the <Yes> button. The program starts and the robot moves in the 3D display. When the robot joint hits the box, the display turns to red.




When a collision happens, the users can stop the controller program execution with an error. For details, refer to 8.3.4 *Collision detection*.

8.3 Description of Functions

This section describes how to use the [Robot Simulator] window and its functions.

8.3.1 [Robot Simulator] window layout




TIP



You can select the following display methods for the layout panel including (2) Layout Object and (3) Property Grid, and (6) Record/Playback panel.


















Hide, Floating, Auto Hide









Panel that you selected to Hide can be re-displayed by clicking <Ctrl> + <Shift> + <R> key.


(1) Tool bar



Button	Description
 Mode: Simulation	<p>Simulator operating mode.</p> <p>It switches between <Simulation Mode> and <Playback Mode>.</p>
 Layout Box	Adds a box object.
 Layout Sphere	Adds a sphere object.
 Layout Cylinder	Adds a cylinder object.
 Layout Plane	Adds a floor / wall object.
 Surveillance Area	Adds a surveillance area object.
 Surveillance Plane	Adds a surveillance plane object.
 CAD	<p>Adds a CAD object.</p> <p>When you click this button, a dialog appears to load the CAD data from a file.</p>
 Hand	<p>Adds a hand object.</p> <p>When you click this button, the dialog appears to load the CAD data from a file.</p> <p>Sample data is provided in EPSON RC+7.0 directory (EpsonRC70\Simulator\HandSamples)</p>
 Camera	<p>Add a virtual camera.</p> <p>When you click this button, the dialog appears to select a camera and lens.</p>
 Reset Collision	<p>Resets the collision detection status.</p> <p>When you click this button while the robot is not interfering with any layout objects, the red display turns to normal.</p>
 Simulator Settings	<p>Shows the [Simulator Settings] dialog.</p> <p>In this dialog, the 3D [Render Options] can be configured.</p>
 Screenshot	<p>Saves the current 3D display as an image file.</p> <p>A dialog appears to specify a file name and format before saving.</p>
 Create Movie	<p>Plays a simulation result (log file) in the Playback mode and saves into a movie file. A dialog appears to specify the file and format to save.</p>
 00:00:00:000 Elapsed Time	<p>Shows the program execution time as if you ran the same program with a real controller.</p> <p>When a program starts, the elapsed time counter counts from 0 and stops when the program finished. It pauses counting when the program is paused and resumes when the program continues execution.</p>
 Clear Elapsed Time	Resets the elapsed time.
 Clear TCP path	Clear the TCP path (including Render Singularity Avoiding path) which the robot displays.

Button	Description
<div> Teach Point</div>	<p>Displays the [Teach] dialog box. Current robot position can be registered as a point.</p> <div></div>
<div> Move</div>	<p>Displays the guides. The objects can be moved by dragging the guides.</p>
<div> Rotate/Jog</div>	<p>Displays the guides. The objects can be rotated by dragging the guides.</p> <p>The guides for the Manipulator are shown only at the Manipulator base.</p> <p>The guides for the manipulator arm change to blue when selected. Joint angle can be changed by dragging the guides.</p>
<div> CAD to Point</div>	<p>Switches to the mode for outputting the point data from the CAD data.</p>
<div> CAD to Point for ECP</div>	<p>Switches to the mode for outputting the point data for external control point (ECP) motion from the CAD data.</p>


(2) Layout Objects Pane



The Layout Objects pane shows the robot objects and layout objects in a tree format.

The context menu appears by right-clicking the layout object. The frequently used functions can be used without operating by the property grid.

The displayed items vary depending on objects.



[Cut], [Copy], and [Paste] commands in the [Edit] menu are available for the layout objects except CAD objects.

Also, the hierarchy of the layout objects can be changed by dragging and dropping.

What is an Object?

The objects in the simulator are either a “Robot Object” or a “Layout Object”:

A “Robot Object” includes the robot itself, its hand, local coordinates, point information, etc.

A “Layout Object” includes objects to be placed around the robot to simulate the robot peripheral environment in the 3D display.

◆ Robot Object

Robot : The robot itself. The display data is handled by the simulator.

Hand : The hand is created by loading the CAD data (XVL(.xv3), VRML2.0, STEP, and IGES) from a file.

Force Sensor : Set force sensor can be displayed.

Object to reflect force control data : Force Control, Force Guide

Object to reflect collision detection margin: Collision Margin

Object to reflect a robot parameter : Local, Tool, Box, Plane, Pallet

Object to reflect robot point data: Point

◆ Layout Objects

Simple object : Box, Sphere, Cylinder, Floor / Wall

The display data for these objects is handled by the simulator.
The object size can be changed as desired by editing properties.

CAD object : These objects are created by loading CAD data (XVL(.xv3), VRML2.0, STEP, IGES, and DXF) from a file.

◆ Camera Objects : The following devices can be displayed.

Devices that are supported in *EPSON RC+ 7.0 Option Vision Guide 7.0 Hardware & Setup* can be selected..

Camera : USB and GigE camera can be selected.

Lens : Each model of standard camera lens, megapixel camera lens, mega-pixel camera lens (HF), 1 inch lens can be selected.

Extension tube : Each length of tubes can be selected.


◆ Surveillance objects: Layout object that detects a contact or a collision with a robot.
There are two types; Surveillance Area and Surveillance Plane.
Similar to the layout objects, the display data is prepared in advance. You can adjust the size by changing the property.

(3) Property Grid Pane


In the Property Grid pane, you can view and change the settings of the robot objects and layout objects in the Layout Object pane.

◆ Robot Object Properties

Robot

Property	Value
Number	1
Name	C4L
Type	6-Axis
Series	C4
Model	C4-A901S
Change Robot	Click to change
Position	
X(mm)	0.000
Y(mm)	0.000
Z(mm)	0.000
Rotation	
X(degree)	0.00
Y(degree)	0.00
Z(degree)	0.00
Collision	
Check	True
Check Self	True
Color	 168,0,0
Transparent	False
Transparency(%)	50



Property	Value
Number	Robot number
Name	Robot name You can specify any name for a robot.
Type	Robot type The robot type (SCARA and 6-Axis) is shown. This property is read-only.
Series	Robot series The robot series is shown. This property is read-only.

Model	Robot model name The robot model is shown. This property is read-only.
Change Robot	If you want to change the robot model, click on  button. When you click on this button, a dialog appears to change the robot. For details, see <i>Changing the robot model</i> described later in this chapter.
Position	Robot position Specifies the robot's base center in the simulator World coordinates.
Rotation	Robot angle

Collision Property	Value
Check	Enables / disables the collision detection for layout objects. Enable : True (default) Disable : False Even if this is enabled, it does not detect collision between the robot base and layout objects.
Check Self	Enables / disables the collision detection for a robot itself. Enable : True (default) Disable : False
Color	Specify color to be used when collision of the arms is detected. Default: 168,0,0

Property	Value
Transparent	Semi-transparent : True Not semi-transparent : False (Default) The front-back relation of the objects may be incorrect depending on the viewing angle. For details, refer to <i>8.4 Simulator Specifications and Restrictions</i> .
Transparency	Specify the transparency in the range of 1 to 90%. Transparency increases as the setting value becomes larger.

Changing the robot model

When you want to change the displayed robot model, click the <Change Robot>  button. The [System Configuration]-[(Name of the displayed robot)]-[Model] dialog will be displayed. If you cannot see the  button, increase the property grid width and click the [Value] column of the grid once.





When you change the displayed robot model, all the settings for the robot (Local coordinates, Tool coordinates, etc.) will be initialized to the default values.

Collision Margin

Sets a collision detection margin for each robot arm collectively or separately.

When the robot type is changed from SCARA robot to 6-Axis robot or 6-Axis robot to SCARA robot, the Value will be reset. When changing to the same type robot, the value will be remained.

Property	Value
Visible	False
Size(mm)	0.100
Color	 255,216,0
Check	False
CollisionColor	 168,0,0

Property	Value
Visible	Display : True Not display : False (default)
Size	Margin size
Color	Margin color Default: 255,216,0
Check	Enable/disable the collision detection. Enable : True Disable : False (default)
CollisionColor	Specifies a color to be displayed when detecting a collision. Default: 168,0,0

Local / Tool / Box / Pallet

If the local coordinate system of the corresponding number is not defined yet, the check box is grayed.

No.	Visible
0	<input checked="" type="checkbox"/>
1	<input type="checkbox"/>
2	<input type="checkbox"/>
3	<input type="checkbox"/>
4	<input type="checkbox"/>
5	<input type="checkbox"/>

Property	Description
Visible	Shows / Not show corresponding settings. Visible : Check Not visible : Uncheck (default)



For Local 0 (Base), “Visible” is the default.

Plane

If the each setting of the corresponding number is not defined yet, the check box is grayed.

Number	Visible	Origin
1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
2	<input type="checkbox"/>	<input type="checkbox"/>
3	<input type="checkbox"/>	<input type="checkbox"/>
4	<input type="checkbox"/>	<input type="checkbox"/>
5	<input type="checkbox"/>	<input type="checkbox"/>

Property	Description
Visible	Shows / Not show corresponding settings. Visible : Check Not visible : Uncheck (default)
Origin	Shows / Not show the origin of corresponding settings. When the checkmark is not placed in [Visible], the [Origin] checkbox is grayed. Visible : Check Not visible : Uncheck (default)

Points

Display the point display setting status in the point file. Switch to show/non-show all points.

File Name	Visible
Points.pts	<input type="checkbox"/>

Property	Description
File Name	Show a point file name.
Visible	Shows / Not show all points Visible : Check Not visible : Uncheck If it is set to show some points, the check box shows indeterminate state.

Point

If the point of the corresponding number is not defined yet, the check box is grayed.

No.	Name	Visible
0		<input checked="" type="checkbox"/>
1		<input type="checkbox"/>
2		<input type="checkbox"/>
3		<input type="checkbox"/>
4		<input type="checkbox"/>
5		<input type="checkbox"/>
6		<input type="checkbox"/>

Property	Description
Name	Shows a point label In the dialog, point labels cannot be configured or edited.
Visible	Shows / Not show a point Visible : Check Not visible : Uncheck (default)



TIP If you cannot see the [Visible] column, increase the property grid display width.

Force Control

Show the display method of the force objects in the force file. Switch visible and not visible of the all force objects.

File Name	Visible
Force.frc	<input checked="" type="checkbox"/>

Property	Description
File Name	Show a force file name.
Visible	Shows / Not Show all force objects. Visible : Check Not visible : Uncheck If it is set to show some force objects, the check box shows indeterminate state.

Force Object

Show the display method of the force control objects, force trigger objects, and force monitor objects in the force file. Switch visible and not visible of the all force objects of the specified type.

If there is no force object of the specified type, the checkbox is grayed.

Type	Visible
Control	<input type="checkbox"/>
Trigger	<input type="checkbox"/>
Monitor	<input type="checkbox"/>

Property	Description
Type	Control (force control), Trigger (force trigger), and Monitor (force monitor) are shown.
Visible	Shows / Not Show all force objects of the specified type. Visible : Check Not Visible : Uncheck If it is set to "Visible" for some force objects, the check box shows indeterminate state.

Force Control, Force Trigger, Force Monitor

When the force object of the corresponding number is not defined yet, the checkbox is grayed.

Number	Name	Visible
0		<input type="checkbox"/>
1		<input type="checkbox"/>
2		<input type="checkbox"/>
3		<input type="checkbox"/>
4		<input type="checkbox"/>
5		<input type="checkbox"/>
6		<input type="checkbox"/>

Property	Description
Name	Show a force label. In the dialog, force label cannot be configured or edited.
Visible	Shows / Not Show the force object. Visible : Check Not Visible : Uncheck

Force Guide

Show the display method of the force guide object in the sequence which is set by the force guide, and switch visible and not visible of the all force objects.

Sequence	Visible
Sequence	<input type="checkbox"/>

Property	Description
Sequence	Show a force guide sequence name.
Visible	Shows / Not Show the all force objects. Visible : Check Not visible : Uncheck If it is set to “Visible” for some force objects, the check box shows indeterminate state.

Force Guide Object

When the force guide object type of the corresponding number (a step number in the sequence) is “Decision” or “SPELFunc”, the checkbox is grayed. When the [Enabled] property of the object is set to “False”, the [Name] is also grayed.

Number	Name	Visible
1	Contact01	<input type="checkbox"/>

Property	Description
Name	Show a force guide object name.
Visible	Shows / Not Show the force guide object. Visible : Check Not visible : Uncheck

Hands

Show a status of Visible and Collision of the configured hand.


Name	Visible	Collision
Hand_1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Hand_2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Property	Description
Name	Shows a hand name.
Visible	Shows / Not Show the hand. Not visible : Uncheck Visible : Check
Collision	Enable / Disable the collision detection. Disable : Uncheck Enable : Check

Hand

When a hand is registered with a robot, “Hand” is added in the Layout Objects tree.

Property	Value
Name	Hand_1
Mount Position	Tool0
Position	
X(mm)	0.000
Y(mm)	0.000
Z(mm)	0.000
Rotation	
X(degree)	0.000
Y(degree)	0.000
Z(degree)	0.000
Filename	c3.hand_close_whole.stp
Save as XVL...	Click to Save
Rendering Quality	Default
Unit	Millimeter
Scale	1.000
Visible	True
Show Label	False
Show Origin	False
Collision	
Check	True
Color	168,0,0
Collision Margin	
Visible	False
Size(mm)	0.100
Color	255,216,0
Check	False
CollisionColor	168,0,0
Transparent	False
Transparency(%)	50

Property	Value
Name	Hand name You can specify any name for a hand. (Default: Hand_1)
Mounted Position	Hand mounting position It can be attached to Force Sensor or Tool coordinate system.
Position	Mounting offset from the robot end effector position.
Rotation	Hand mounting direction
File name	CAD data file name of the hand It cannot be changed.
Save as XVL...	The loaded hand object can be saved in the XVL format. Click  and specify the destination. When the XVL-format hand data is loaded, this item is grayed out and cannot be used.
Rendering Quality	Set the rendering quality. Standard : Default Quality-preferred : Fine Speed-preferred : Fast
Visible	Visible : True (default) Not visible : False
Show Label	Displays the label : True Not display the label : False (default) This property sets whether to display the label when [Label Display] in the [Simulator setting] is specified.
Show Origin	Displays the origin coordinate system : True Not displays the origin coordinate system : False (default)

Collision Property	Value
Check	Enables / disables the collision detection. Enable : True (default) Disable : False Collision with the robot flange is not detected even when this property is set “True”.
Color	Specify the color to be used when collision is detected. Default: 168,0,0
Collision Margin Property	Value
Visible	Display : True Not display : False (default)
Size	Margin size
Color	Margin color to be displayed. Default: 255,216,0
Check	Enable / Disable the collision detection. Enable : True Disable : False (default)
CollisionColor	Specifies a color to be displayed when detecting a collision. Default : 168,0,0
Property	Value
Transparent	Semi-transparent : True Not semi-transparent : False (Default) The front-back relation of the objects may be incorrect depending on the viewing angle. For details, refer to <i>8.4 Simulator Specifications and Restrictions</i> .
Transparency	Specifies the transparency in the range of 1 to 90%. Transparency increases as the setting value becomes larger.

Force Sensor

By registering Force Sensor, “Force Sensor” is displayed in the layout object.

Force Sensor	
Property	Value
Number	FS1
Label	
Visible	True
Show Label	False
Model	S250N
Flange	S250NtoC4
Show Flange Offset	False
Show Sensor Tip	False
Collision	
Check	True
Color	168,0,0
Collision Margin	
Visible	False
Size(mm)	0.100
Color	255,216,0
Check	False
CollisionColor	168,0,0
Transparent	False
Transparency(%)	50

Property	Value
Number	Displays a sensor number registered in the controller.
Label	Displays a sensor name registered in the controller.
Visible	Visible : True (Default) Not visible : False
Show Label	Display a label : True Not display a label : False (Default) This property sets whether to display the label when [Label Display] in the [Simulator Setting] is set.
Model	Displays a model registered in the controller.
Flange	Displays a flange determined by combination of the robot and Force Sensor (default). Select “None” to hide.
Show Flange Offset	Show : True Not show : False (Default) Specifies whether to display the flange offset position in coordinate system.
Show Sensor Tip	Show : True Not show : False (Default) Specifies whether to display the tip position of Force Sensor in coordinate system.

For properties such as “Collision”, “Collision Margin” or “Transparent”, refer to the hand or layout objects properties.

◆ Layout Objects

Layout Box / Layout Sphere / Layout Cylinder / Layout Plane / CAD

There are common attributes for all objects and others are for particular objects.




SBox_1	
Property	Value
Name	SBox_1
Type	Layout
Position	
X(mm)	600
Y(mm)	600
Z(mm)	50
Half size	
X(mm)	50.000
Y(mm)	50.000
Z(mm)	50.000
Rotation	
X(degree)	0.00
Y(degree)	0.00
Z(degree)	0.00
Color	26,114,189
Visible	True
Show Label	False
Show Origin	False
Collision	
Check	True
Show Result	Whole
Color	168,0,0
Collision Point	
Radius(mm)	5
Color	168,0,0

Sphere_1	
Property	Value
Name	Sphere_1
Type	Layout
Position	
X(mm)	750.000
Y(mm)	750.000
Z(mm)	50.000
Radius(mm)	50.000
Rotation	
X(degree)	0.00
Y(degree)	0.00
Z(degree)	0.00
Color	26,114,189
Visible	True
Show Label	False
Show Origin	False
Collision	
Check	True
Show Result	Whole
Color	168,0,0
Collision Point	
Radius(mm)	5
Color	168,0,0

Cylinder_1	
Property	Value
Name	Cylinder_1
Type	Layout
Position	
X(mm)	900.000
Y(mm)	900.000
Z(mm)	50.000
Radius(mm)	50.000
Height(mm)	100.000
Rotation	
X(degree)	0.00
Y(degree)	0.00
Z(degree)	0.00
Color	26,114,189
Visible	True
Show Label	False
Show Origin	False
Collision	
Check	True
Show Result	Whole
Color	168,0,0
Collision Point	
Radius(mm)	5
Color	168,0,0



SPPlane_1	
Property	Value
Name	SPPlane_1
Type	Layout
Plane Type	Horizontal
Position	
X(mm)	0.000
Y(mm)	0.000
Z(mm)	0.000
Half size	
Height(mm)	2000.000
Width(mm)	2000.000
Rotation	
X(degree)	0.00
Y(degree)	0.00
Z(degree)	0.00
Color	0,0,102
Visible	True
Show Label	False
Show Origin	False
Collision	
Check	True
Show Result	Whole
Color	168,0,0
Collision Point	
Radius(mm)	5
Color	168,0,0


CAD 1	
Property	Value
Name	CAD_1
Type	Layout
Position	
X(mm)	-45.157
Y(mm)	328.320
Z(mm)	294.427
Rotation	
X(degree)	0.00
Y(degree)	0.00
Z(degree)	0.00
Filename	c3_hand_a.xv3
Save as XVL...	Click to Save
CAD to Point	True
Rendering Quality	Default
Unit	Millimeter
Scale	1.000
Visible	True
Show Edge	True
Show Label	False
Show Origin	False
Collision	
Check	True
Show Result	Whole
Color	168,0,0
Collision Point	
Radius(mm)	5
Color	168,0,0
Transparent	False
Transparency(%)	50

Property	Object	Value
Name	All	You can specify any name.
Plane Type	Plane	Floor : Horizontal (default) Wall : Vertical
Type	All	Clicking the  button to display the [Object Settings] dialog. You can set the type. Layout : Layout object (Default) Part : Part object Mounted Device: Mounted device
Position	All	Specifies a center point in simulator World coordinates. Layout Cylinder: Bottom surface center
Half size	Box	Specifies a length from the center. The box length is double this length.
Radius	Sphere Cylinder	Sphere radius Cylinder radius
Height	Cylinder Plane	Cylinder height Floor length / Wall height
Width	Plane	Floor width / Wall width
Rotation	All	Object angle (Z-axis centering)
File name	CAD	CAD data file name. It cannot be changed.
Save as XVL...	CAD	The loaded hand object can be saved in the XVL format. Click  and specify the destination. When the XVL-format hand data is loaded, this item is grayed out and cannot be used.
CAD to Point	CAD	Use this property to generate a point from the CAD data by using CAD To Point. For details, refer to 8.3.4 <i>CAD To Point</i> .
Rendering Quality	CAD	Set the rendering quality. Standard : Default Quality-preferred : Fine Speed-preferred : Fast
Unit	CAD	Set the unit of length for the CAD data.
Scale	CAD	Set the scale ratio of the CAD data.
Color	Box Sphere Cylinder	Display color Click the drop-down  to change display color. The display color setting dialog will be displayed. Refer to <i>Change layout object color</i> for the details.

Property	Object	Value
Visible	All	Visible : True (default) Not visible : False
Show Edge	CAD	Displays Edge (edge line) of the CAD data. Display : True (default) Not display : False The display time can be reduced and operability can be improved by hiding the edge lines.
Show Label	All	Displays the label : True Not display the label : False (default) This property sets whether to display the label when [Label Display] in the [Simulator setting] is specified.
Show Origin	All	Displays the origin coordinate system : True Not displays the origin coordinate system : False (default)
Transparent	CAD	Semi-transparent : True Not semi-transparent : False (default) The front-back relation of the objects may be incorrect depending on the viewing angle. For details, refer to 8.4 <i>Simulator Specifications and Restrictions</i> .
Transparency	CAD	Specify the transparency in the range of 1 to 90%. Transparency increases as the setting value becomes larger.
Collision		
Property	Object	Value
Check	CAD	Enables/disables the collision detection. Enable : True (default) Disable : False Collision with the robot flange is not detected even when this property is set "True".
Show result	CAD	Specify how to display the color configured in Color property when collision is detected. Entirely : Whole (default) Collision point : Point Entire object and collision point : WholeAndPoint
Color	CAD	Specify the color to be used when collision of the arms is detected. Default: 168,0,0
Collision Point		
Property	Object	Value
Radius(mm)	CAD	Specify the radius of collision point displayed when collision is detected.
Color	CAD	Specify the color to be used when collision is detected. Default: 168,0,0

Change layout object color


When you want to change layout object color, click on the drop-down  in the Color property and the dialog shown below will be displayed. If you cannot see the drop-down , increase the property grid width.



Click color you want to display. Layout object color will be changed.

If you do not want to change color, click anywhere other than the display color setting dialog. The dialog will be closed.

If you create a custom color, right-click any color in the bottom two rows (16 colors) in the [Custom] tab, and the color setting dialog will be displayed.















Create a custom color and click the <OK> button.

Created color will be displayed in the display color setting dialog.

◆ Camera Objects


Some properties are common for the both fixed camera and mobile camera, and other properties are only enabled for either one of them.

Property	Value
Name	Camera_1
Type	PC Vision
Connection Type	GigE
Model	acA640-120gm
Resolution	640 x 480
Extension Tube	0.0 mm
Lens Type	Mega Pixel
Focal Length	8 mm
Camera View	Click to Show
Margin(mm)	5
Camera Tip	
X(mm)	614.500
Y(mm)	600.000
Z(mm)	66.000
Visible	False
Show View Ray	True
Show View Center	True
Near Plane	
Width(mm)	46.0
Height(mm)	34.0
Distance(mm)	100.0
Visible	True
Color	 Yellow
Fill	False
Far Plane	
Width(mm)	650.0
Height(mm)	486.0
Distance(mm)	1500.0
Visible	True
Color	 Lime
Fill	True
Pixel Resolution	
Near X(mm)	0.072
Near Y(mm)	0.071
Far X(mm)	1.016
Far Y(mm)	1.013
Mount Type	Fixed
Position	
X(mm)	600.000
Y(mm)	600.000
Z(mm)	0.000
Rotation	
X(degree)	0.00
Y(degree)	0.00
Z(degree)	0.00
Visible	True
Show Label	False
Show Origin	False
Collision	
Check	True
Show Result	Whole
Color	 168,0,0
Collision Point	
Radius(mm)	5
Color	 168,0,0
Collision Margin	
Visible	False
Size(mm)	0.100
Color	 255,216,0
Check	False
CollisionColor	 168,0,0
Transparent	False
Transparency(%)	50

Property	Value
Name	Camera_1
Type	PC Vision
Connection Type	GigE
Model	acA640-120gm
Resolution	640 x 480
Extension Tube	0.0 mm
Lens Type	Mega Pixel
Focal Length	8 mm
Camera View	Click to Show
Margin(mm)	5
Camera Tip	
X(mm)	0.000
Y(mm)	481.000
Z(mm)	634.500
Visible	False
Show View Ray	True
Show View Center	True
Near Plane	
Width(mm)	46.0
Height(mm)	34.0
Distance(mm)	100.0
Visible	True
Color	 Yellow
Fill	False
Far Plane	
Width(mm)	650.0
Height(mm)	486.0
Distance(mm)	1500.0
Visible	True
Color	 Lime
Fill	True
Pixel Resolution	
Near X(mm)	0.072
Near Y(mm)	0.071
Far X(mm)	1.016
Far Y(mm)	1.013
Mount Type	Mobile
Robot	1
Joint	6
Offset Position	
X(mm)	50.000
Y(mm)	0.000
Z(mm)	0.000
Offset Rotation	
X(degree)	0.000
Y(degree)	0.000
Z(degree)	0.000
Position	
X(mm)	0.000
Y(mm)	415.000
Z(mm)	620.000
Rotation	
X(degree)	-90.00
Y(degree)	-90.00
Z(degree)	0.00
Visible	True
Show Label	False
Show Origin	False
Collision	
Check	True
Show Result	Whole
Color	 168,0,0
Collision Point	
Radius(mm)	5
Color	 168,0,0
Collision Margin	
Visible	False
Size(mm)	0.100
Color	 255,216,0
Check	False
CollisionColor	 168,0,0
Transparent	False
Transparency(%)	50

Property	Object	Value
Name	All	Displays the camera name.
Type	All	Displays the camera type. You can change it.
Connection Type	All	Displays connection type of camera.
Model	All	Displays a camera model. You can change it.
Resolution	All	Displays a camera resolution.
Extension Tube	All	Displays a length of extension tube. You can change it.
Lens Type	All	Displays a lens type. You can change it.
Focal Length	All	Displays focal length of lens. You can change it.
Show View Ray	All	Show / not show the view ray. Show : True (default) Not show: False
Show View Center	All	Show / not show the view center. Show : True (default) Not show: False

Camera View

Property	Object	Value
Click to Show	All	Clicks the  to show the camera view.
Margin	All	Sets a margin of lengthwise direction from camera view to a border of the camera view window. Show : True Not show: False (Default)

Camera Tip

Property	Object	Value
X, Y, Z	All	Displays the world coordinates on the edge of the camera lens. Change the value to change the camera position.
Visible	All	Visible : True (Default) Not visible : False

Near Plane/ Far Plane

Property	Object	Value
Width	All	Displays the camera view width.
Height	All	Displays the camera view height.
Distance	All	Displays distance of Camera Tip and Near Plane/ Far Plane.
Visible	All	Visible / not visible the depth of field. Visible : True (Default) Not visible : False
Color	All	Sets the camera view color.
Fill	All	Sets a fill of the camera view. In case of Near Plane: Display : True Not display: False (Default) In case of Far Plane: Display : True (Default) Not display: False

Pixel Resolution

Property	Object	Value
Near X, Y	All	Displays the size of Near Plane in pixel.
Far X, Y	All	Displays the size of Far Plane in pixel.

Mount type







Property	Object	Value
Mount type	All	Displays the mount type of camera. Fixed camera/mobile camera can be changed.
Robot	Mobile	Displays the mounted robot number. You can change it.
Joint	Mobile	Displays the mounted joint number. You can change it.
Offset Position	Mobile	Display the relative position from the mounted joint.
Offset Rotation	Mobile	Display the relative orientation from the mounted joint.


For properties such as “Collision”, “Collision Margin”, or “Transparent”, refer to the layout objects properties.

◆ Surveillance Objects

SurveillanceArea, SurveillancePlane

There are attributes that are enabled SurveillanceArea or SurveillancePlane or both.

Property	Value	Property	Value
Name	SurveillanceArea_1	Name	SurveillancePlane_1
Type	Layout	Type	Layout
<input type="checkbox"/> Position		<input type="checkbox"/> Position	
X(mm)	1000.000	X(mm)	2000.000
Y(mm)	1000.000	Y(mm)	2000.000
Z(mm)	500.000	Z(mm)	500.000
<input type="checkbox"/> Half size		<input type="checkbox"/> Half size	
X(mm)	1000.000	Height(mm)	500.000
Y(mm)	1000.000	Width(mm)	500.000
Z(mm)	500.000	<input type="checkbox"/> Rotation	
<input type="checkbox"/> Rotation		X(degree)	90.00
X(degree)	0.00	Y(degree)	0.00
Y(degree)	0.00	Z(degree)	0.00
Z(degree)	0.00	Color	 255,216,0
Color	 255,216,0	Visible	True
Visible	True	Show Label	False
Show Label	False	Show Origin	False
Show Origin	False	<input type="checkbox"/> Collision	
<input type="checkbox"/> Collision		Check	True
Check	True	Show Result	Whole
Show Result	Point	Color	 168,0,0
Color	 168,0,0	<input type="checkbox"/> Collision Point	
<input type="checkbox"/> Collision Point		Radius(mm)	5
Radius(mm)	5	Color	 168,0,0
Color	 168,0,0	I/O Control	Click to Show Detail
I/O Control	Click to Show Detail		


Property	Value
Name	You can specify any name.
Type	Set to Layout. Cannot change the setting.
Position	Specifies a center point in simulator World coordinates.
Half size	Specifies a length from the center. The length is double this length.
Color	Box Sphere Cylinder Display color Click the drop-down  to change display color. The display color setting dialog will be displayed. Refer to <i>Change layout object color</i> for the details.
Visible	Visible : True (default) Not visible : False
Show Label	Displays a label : True Not display a label : False (default) This property sets whether to display the label when [Label Display] in the [Simulator setting] is specified.
Show Origin	Displays the origin coordinate system : True Not displays the origin coordinate system : False (default)


Collision

Property	Value
Check	Enables/disables the collision detection and I/O control setting. Enable : True (default) Disable : False
Show result	Specify how to display the color configured in Color property when collision is detected. Entirely : Whole (default) Collision point : Point Entire object and collision point : WholeAndPoint
Color	Specify the color to be used when collision of the arms is detected. Default: 168,0,0

Collision Point

Property	Value
Radius(mm)	Specify the radius of collision point displayed when collision is detected.
Color	Specify the color to be used when collision is detected. Default: 168,0,0

Property	Value
I/O Control	Click  to display the [I/O Control] dialog box. Set the following items for each configured robots. Enable or Disable of Collision Check: Enable (True),Disable (False) I/O Output No. On/Off settings




When a robot collides or contacts with an object, Output No. of the specified I/O is turned On or Off.

This setting is valid only when a virtual controller is connected.


(4) 3D Display

In the 3D display, you can check the robot orientation and motion from various points of view.




Adding a layout object

When a layout object is added while the robot object is selected in [Layout Objects], it will be added as independent object.



When a layout object is added while the layout object is selected in [Layout Objects], it will be added as a grouped object of the selected object.



Grouped objects move together when the parent object moves.

RightTable/CenterTable/LeftTable of the sample virtual controller “C4 Sample” is an example of grouping.


Editing a layout object

[Cut], [Copy], and [Paste] commands in the [Edit] menu are available for the layout objects except CAD objects.


Changing a hierarchy of layout objects

To change a hierarchy of layout objects, drag and drop a layout object in the layout object.


Change the robot / layout object position

The grids indicating directions to move can be displayed by clicking the <Move>  button on the toolbar and clicking the object such as a robot or a box. They can also be displayed by clicking the object while pressing the <Shift> key.


To move the object, drag the grid corresponding to the axis.




Rotate the robot / layout object

The grids which indicate the rotation directions can be displayed by clicking the  button on the toolbar and clicking the object such as a robot base or a box. They can also be displayed by clicking the object while pressing the <Ctrl> key.

To rotate the object, drag the guide corresponding to the direction you want to rotate the object.




Move the robot joint

The robot joint can be moved by clicking the  button on the toolbar and dragging the joint. The selected joint is displayed in blue.

The joint can also be moved by dragging while pressing the <Ctrl> key.

If a robot moves to a point out of the motion range, the joint comes back to the previous point.



Change the view point

To rotate the view point, press the mouse left button and drag the 3D display.

To move the view point up and down, press the mouse right and left button and drag the 3D display.

Also, you can use the <L>, <R>, <D>, and <U> key to move the view point.

You can reset the view point from the menu opened by right click.

Zoom the layout


To zoom the 3D display, use the mouse wheel to scroll.

You can change the zoom level from the menu opened by right clicking with the mouse.

Check for collisions


When a collision between a robot and layout object is detected, the collided robot joint and layout object are displayed in red.

For details, refer to 8.3.4 *Collision detection*.



(5) 2D Layout



In the [2D Layout] panel, you can specify and check the robot objects and layout objects positions.




Change robot and layout object position

Drag an object (robot, box, etc.) to change its position.

To move an object in Z direction, use the <D> and <U> keys.

Drag  to change the size of an object, and drag  to rotate an object.

If you are moving a box, it is shown as in the figure on the right:



Zoom the layout

To zoom the 2D layout, use the mouse wheel to scroll.

Move the display area


To move the 2D layout display area, drag the 2D layout while simultaneously pressing the <Shift> key.















Rotate the display

To rotate the 2D layout display area, right-click on the 2D layout and use the options - [Rotate Clockwise] [Rotate CounterClockwise].

(6) Record / Playback


In Playback mode, you can record and produce simulation results.
Also, you can store the simulation results in movie files.




Function	Description
 RECORD	When the button is red  , it saves the simulation result into the specified log file. Every time you execute the program, the log file is overwritten with the new information. When the button is gray  , it doesn't save the simulation result. As the default, it doesn't save the simulation result.
 PLAY	Plays a simulation result of a specified log file.
 STOP	Stops the simulation playback.
 REWIND	Puts the playback step to the starting point.
 BACK	Goes back one step. The number of steps back is specified in [Play Speed].
 NEXT	Goes to next step. The number of steps to go is specified in [Play Speed].
 REPEAT	When this button is pressed, repeats the simulation playback.
 Log list	Specifies a recording file to record and play.
 New button	Create a new log file.
 Sampling	Displays the log file sampling interval.
 Play Speed	Specifies the playback interval with a number of steps.
 Play position	Display the current playing position.

Produce the robot motion by outputting to a recording file


- (1) Confirm that the mode is “Simulation” mode on the Simulator Tool bar.



- (2) Click on the <New> button in the [Record / Playback] window. The [New Recording] dialog appears.
- (3) Here, enter “TestPlayBack” and click the <OK> button. Now, you can see “TestPlayBack” in the Recording list.
- (4) Click on the <RECORD> button in the [Record / Playback] window, which enables recording. Now, the <RECORD> button is in red .
- (5) Start a program from the [Run] window to move the robot. The simulation result is saved in the recording file while executing the program.
- (6) Change the simulator operating mode to “Playback Mode” again.
- (7) Click on the <PLAY> button and the simulation result starts to play.

Produce the robot motion with saving in a movie file at once

- (1) Confirm that the mode is set to “Playback” on the Simulator Tool bar.
- (2) Click the <Create Movie> button in the Simulator Tool bar.
- (3) When the [Create Movie] dialog appears, select “TestPlayBack” from the Log list.




- (4) Specify the [Output File] and [AVI Compression] if necessary.
- (5) Click on the <OK> button. The [Create Movie] status window appears and the specified movie file is created with playing the log file.
- (6) The created movie file is “TestPlayBack.avi” in EPSON RC+ 7.0 project folder (\EpsonRC70\projects\“a project name”).

(7) Loading the CAD file

The CAD file can be loaded to lay out the hand or CAD object data in the 3D display. For details of available CAD data, refer to *Available CAD data for 3D display* in 8.4.2 *Specifications and precautions for the 3D display*.

Pressing the <CAD 



Function	Description
<Browse> button	Displays the dialog box for selecting the file. Select a CAD file to load.
Scale Unit	Select a unit of length used in the CAD data in order to match the unit with the simulator. This can be changed in the property grid after loading the data.
Rendering Quality	Specify the rendering quality. If “Fine” is selected, the data is displayed in details but it takes time. If “Fast” is selected, the details are not displayed (e.g. the screw holes are shown as a square), but the data can be displayed faster.
Enable CAD to Point	Check this checkbox to use the CAD to Point which extracts the points from the loaded CAD data. This can be changed in the property grid after loading the data. If the data is loaded as Hand, this item does not appear.
<Open> button	Starts loading the data.

(8) Saving the CAD file

The loaded CAD file can be converted to the XVL format to save. Converting the file to the XVL format can reduce the file size, resulting in a shorter loading time.


There are two ways to save the files: saving the CAD files one by one, or saving them altogether. The CAD files can be saved one by one in the property grid, or altogether in the [Save CAD/Hand] dialog box.


To save the CAD files one by one

- (1) Select the CAD object to save in the layout object.
- (2) Click [Click to Save] of the <Save as XVL...> property in the property grid.
- (3) The [Save As] dialog box appears. Click <Save>.
- (4) If the file is saved successfully, the confirmation message appears. Click <Yes>.

To save the CAD files altogether

- (1) If there is an unsaved CAD data or Hand data when you attempt to exit the EPSON RC+ or turn off the Controller, the [Save CAD/Hand] dialog box appears.




- (2) The changed data is saved in the same folder as the previous data.
The filename extension is changed to “xv3” automatically. If you want to change the file name or the destination to save, click the <Browse  > button to display the [Save As] dialog box, and then change the file name and destination.
- (3) Click the <Save> button.
- (4) If the file is saved successfully, “Success” will be displayed in [Status].
- (5) Click the <Close> button to close the dialog.

CAD/Hand save dialog box

Function	Description
[Save] checkbox	Check the checkbox of the object to save.
Status	If the file is saved successfully, it shows “Success”. If failed, it shows “Fail”.
Type	Displays either “Hand” or “Cad”.
Robot No.	If the type is “Hand”, the robot number is displayed.
Object Name	Displays the setting value of [Name] in the property grid.
Filename	Displays the name of the loaded file.
Save Filename	Displays the name of the destination file selected in the [Save As] dialog box.
Browse	Displays the [Save As] dialog box.
<Save> button	Starts saving the file.
<Cancel> button	Cancel saving the file.
<Close> button	Close the dialog. This button appears when saving is completed successfully.


8.3.2 Simulator Settings

Pressing the <Simulator Settings > button displays the [Simulator Settings] dialog box.

This dialog box is used to configure the 3D display. The settings will be kept after restarting the EPSON RC+ 7.0.

[Robot]

Settings related to 3D display of the robot.



Render Robot Options

Function	Description
Render Coarsely-displayed Robot	Displays the simplified robot data. The setting is effective the next time you connect the robot. This option is useful when the computer capacity is insufficient or the CAD data is large.
Render Duct Collision Area	Displays the range of collision detection at the robot duct with a bounding box. This option is available for G1 and LS series.
Render Singularity Area of Elbow	Displays the elbow singularity area and elbow singularity neighborhood on the simulator. This option is available for N series.
Render Joints	Displays an arrow that shows a supporting point and a rotation axis of the robot.
Length	Set a length for rendering the joints.
Render Rotation Direction	Display a rotation direction when rendering the joints.
Render Joint Name	Display the joint names (J1, J2, J3, J4, J5, J6) when rendering the joints.
Render On Front	Display the arrow of “Render Joints” in front of the robot.


Render TCP Path Options

Function	Description
Render TCP Path	Displays the path of the origin point on active Tool coordinate system for a fixed time.
Render Singularity Avoiding path	Only displays the path of operation to avoid render singularity for the path of the origin point on active Tool coordinate system.
Style	Select line or dot to indicate the paths.
Width	Specify the line width of paths.
Radius	Specify the diameter of dots indicating paths.
Color	Specify the color of paths.

[Parameter]

Settings related to 3D display of robot parameters.

You can set the local coordinate system, tool coordinate system, ECP coordinate system, and plane origin coordinate system.




Render Robot Parameter Options

Function	Description
Length	Set a length of the coordinate axis.
Render Rotation Direction	Display the rotational direction of the coordinate axis.
Render Axis Name	Display the coordinate axis names (X, Y, Z, U, V, W).
Render On Front	Display the arrow of “Render Robot Parameter” in front of the robot or the object.

[Point]

Settings related to 3D display of the point data of the robot.


**Render Point Options**

Function	Description
Radius	Specify the diameter of dots indicating points.
Color	Specify the color of dots indicating points.
Render Labels	Display a point label.
Style	Set a display style when rendering the point label. Label : Label registered in point file. Number : Point number NumberAndLabel: Point number and label
Render Orientation	Display an orientation at the point as a coordinate axis.
Size	Set a size of coordinate axis that shows the orientation at the point.
Render Rotation Direction	Display the rotational direction on the coordinate axis that shows the orientation at the point.
Render Axis Name	Display the coordinate axis name (X, Y, Z, U, V, W) of the coordinate axis that shows the orientation at the point.

[Force Sensor]

Settings related to 3D display of the force sensor.

You can set the coordinate system that shows a flange offset and tip of the force sensor.


**Render Force Sensor Options**

Function	Description
Length	Set a length of the coordinate system.
Render Rotation Direction	Display the rotational direction of the coordinate axis.
Render Axis Name	Display the coordinate axis names (X, Y, Z, U, V, W).
Render On Front	Display the arrow of “Render Force Sensor” in front of the robot or the object.

[Force]

Settings related to 3D display of the force control data.

You can set the force coordinate system and moving direction for force object or force guide object.


**Render Force Coordinate System Options**

Function	Description
Length	Set a length of the coordinate axis of the force coordinate system.
Render Rotation Direction	Display the rotational direction of the coordinate axis.
Render Axis Name	Display the coordinate axis names (Fx, Fy, Fz, Tx, Ty, Tz).
Render On Front	Display the arrow of “Render Force Coordinate System” in front of the robot or the force sensor.
Render Moving Direction	Show the moving direction of the robot by the force control.
Length	Set a length of an arrow that shows the moving direction of the robot.
Thickness	Set a thickness of an arrow that shows the moving direction of the robot.
Color	Set a color of an arrow that shows the moving direction of the robot.
Render Labels	Show a label of the force object and force guide object name.

[Camera]

Settings related to 3D display of the camera object.

You can set the display of the coordinate system that shows the camera tip.


**Render Camera Options**

Function	Description
Length	Set a length of the coordinate axis.
Render Rotation Direction	Display the rotational direction of the coordinate axis.
Render Axis Name	Display the coordinate axis names (X, Y, Z, U, V, W).
Render On Front	Display the arrow of “Render Camera” in front of the object.

[Object]

Settings related to 3D display of the general objects including robot, CAD object, and simple object.


You can set the display of coordinate system which shows an origin of the object and a selection color when the robot and CAD object move or rotate.

**Render Object Options**

Function	Description
Length	Set a length of the coordinate axis which shows an origin of the object.
Render Axis Name	Display a coordinate axis name. Display the coordinate axis names (X, Y, Z).
Render On Front	Display the arrow of “Render Object” in front of the object.
Select Color	Set a color when the robot and CAD object move, rotate, or jog.
Render Labels	Display names of robot and layout object.

[Other]

Other settings related to 3D display.



Render Other Options

Function	Description
Render World Monitor	Displays the World coordinates.
Length	Set a length of the coordinate axis which shows a world coordinate.
Render Axis Name	Displays the name of coordinates (X, Y, Z).
Render On Front	Display the arrow of “Render Other” in front of the object.
Render Back Face	Displays the surface of polygons.
Render Wireframe	Changes to the wire frame model (3D image only using lines and dots)
Render Bounding Box	Displays the robot and layout objects with a bounding box.
Render Grid	Displays the grids on the simulator.


CAD/Hand Save Options

Function	Description
Confirm save as XVL	Displays the [Save CAD/Hand] dialog box if there is CAD data or Hand object in other than XVL format when starting the simulator.

8.3.3 Part/Mounted Device Settings


You can move the layout objects along with the robot like part such as workpieces grasped by the robot or devices mounted on the robot arm.

Set the layout objects for part/mounted device settings in the [Part/Mounted Device Settings] dialog. In the dialog, there are two methods to display

1. Right-click the target object.
Select [Part/Mounted Device Settings] from the displayed context menu.
2. Click the <Downward arrow  > button displayed on [Type] of the property grid.

There are two methods to reset the Part/Mounted Device Settings and return the [Type] to “Layout”.

1. Click the <UnResister> button on the [Part/Mounted Device Settings] dialog.
2. Select the “Layout” on the [Type] property of property grid.



Function	Description
Type	Select from the following. Layout : Layout objects (Default) Part : Part objects Mounted Device : Mounted device
Render Object Origin	Display the object origin.
Robot	Set a robot that relates to the selected object.
Tool	When the [Type] is “Part”, set the tool coordinate system to place an object.
Render Selected Tool	Display the tool coordinate system.
Joint	When the [Type] is “Mounted Device”, set joint number to place an object.
Render Selected Joint	Display joints.
Offset From Selected Tool or Joint	Set a relative position from the selected tool or joint.
Zero Clear	Set the offset value to “0.000”.

Function	Description
Register	Register an object to the selected type.
UnRegister	Return the registered [Type] of the object to "Layout".
Cancel	Cancel the settings.

8.3.4 Collision detection

In the simulation, collisions can be detected between the robots including its hand and the layout objects. (X5 series cannot use this function.)

Here we describe the settings and details of collision detection.

Basic settings for collision detection

In the [Property Grid] of the robot, the following can be configured.

Property	Value
Check Collision	Enables / disables the collision detection for layout objects. Enable: True (default) Disable: False Collision between the robot base and layout objects is not detected even when this property is set "True".
Check Self Collision	Enables / disables the collision detection for a robot itself. Enable: True (default) Disable: False

Target of collision detection

In the Property Grid of the layout objects, the following can be configured.

Collision

Property	Object	Value
Check	CAD	Enables / disables the collision detection for a robot. Enable: True (default) Disable: False Collision with the robot flange is not detected even when this property is set "True".
Show result	CAD	Specify how to display the color configured in Color property when a collision is detected. Entirely : Whole (default) Collision point : Point Entire object and collision point : WholeAndPoint
Color	CAD	Specify a color to be used when collision is detected. Default: 168,0,0


Collision Point

Property	Object	Value
Radius(mm)	CAD	Specify the radius of collision point displayed when collision is detected.
Color	CAD	Specify the color to be used when collision of the arms is detected. Default: 168,0,0

Generate error when collision is detected

When you open the [Setup]-[System Configuration]-[Controller]-[Simulator] and check the [Generate error when collision detected] checkbox, if a collision is detected during SPEL⁺ program execution, an error occurs in the controller and the program stops.

After checking the check box, click <Apply> and then click <Close>.



NOTE



The purpose of this function is to find where the program has a problem and not to prevent the collision of robots.

It cannot guarantee that it has enough time for robots to stop when the simulator detects the collision.

Caution about the collision detection of Floor / Wall

A collision is detected when a floor or wall is in contact with the robot. If the robot or plane positions are changed so that the robot passes completely through the plane, then no collision is detected.

Accuracy of collision detection

The collision detection in the simulator cannot guarantee accuracy. Make sure to have a margin when you apply the simulation result for a real robot system.

Caution about the CAD data

Collision cannot be detected when the CAD data has only the wire frame models. To use the collision detection function, add surface to the CAD data.

The restrictions of the simulator are described in *8.4 Simulator Specifications and Restrictions*.

8.3.5 CAD To Point


CAD To Point outputs the edge (edge line) information included in the CAD data as a point data. This function enables the user to generate a point data according to the path by sequentially selecting the edges of the CAD data shown in the 3D display. Since this function automatically registers points of manipulator motion based on the CAD data of the work piece, it can save time to develop a program.

Follow the simple CAD data sample below to use CAD To Point.


In this example, a motion in which the tip of a syringe traces a periphery of the CAD object (tray) will be created.


1. Connect to the virtual controller (CAD To Point)
2. Open a project file
3. Select edges of the CAD object to generate a motion path
4. Export the edges as point data
5. Create a program
6. Execute the program and operate the manipulator

1. Connect to the virtual controller (CAD To Point)



Select “CAD To Point” from the EPSON RC+ 7.0 tool bar-<Current controller connection> list box. When the connection is completed, “CAD To Point” will be displayed in <Current controller connection> list box.


Click the tool bar-<Simulator  > to display the [Robot Simulator] window. The CAD object “Work” and the Hand are placed in “CAD To Point”.




2. Open a project file


- (1) Click the EPSON RC+ 7.0 menu-[Project]-[Open...].
- (2) Select [Projects]-[SimulatorDemos]-[CAD_To_Point].
- (3) Click the <Open> button.

3. Select edges of the CAD object to generate the motion path


- (1) Click the <CAD to Point > button on the toolbar to display the [CAD to Point] dialog box.




- (2) Hover the mouse over the CAD object and select a part having the edges. The selected part turns to be light blue and the edges are shown in blue.




- (3) Hover the mouse over a desired blue edge. The selected edge turns to be white. Select the line first. This sample program will not operate properly when selecting the curve first since this is designed to select the line first.




- (4) Click the white edge. The selected edge will be shown in the [Selected Edge] box of the [CAD to Point] dialog box.



In the 3D View, the selected edge is indicated with a red arrow.




The arrow indicates the direction from the starting point to the end point.


The direction of the arrow can be reversed by clicking the <Reverse > button.




If a start and end points of the consecutive edge with the same moving direction are piled up, the vertex color changes. When the both position (X,Y,Z) and orientation (U,V,W) match, the vertex is displayed in green. When only the position (X,Y,Z) matches, the vertex is displayed in light blue





The image will be shown as below after you select the edges one by one in counterclockwise to trace the periphery.




4. Export the edges as point data

Click the <Export Points > button of the [CAD to Point] dialog box to display the [Export Points] dialog box.



Click the <OK > button to output the point data to the rows No.0-20 in the point file named “robot1.pts”.




Number	Label	X	Y	Z	U	V	W	Local	Hand	Elbow	Wrist	J1Flag	J4Flag	J6Flag
0		100.000	460.000	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
1		100.000	590.000	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
2		99.214	593.892	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
3		97.071	597.071	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
4		93.892	599.214	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
5		90.000	600.000	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
6		10.000	600.000	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
7		6.108	599.214	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
8		2.929	597.071	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
9		0.786	593.892	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
10		0.000	590.000	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
11		0.000	460.000	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
12		0.786	456.108	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
13		2.929	452.929	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
14		6.108	450.786	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
15		10.000	450.000	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
16		90.000	450.000	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
17		93.892	450.786	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
18		97.071	452.929	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
19		99.214	456.108	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
20		100.000	460.000	215.000	90.000	0.000	180.000	0	Righty	Above	NoFlip	0	0	0
21														

5. Create a Program

- (1) Set the appropriate robot orientation for the point data

Open the point file “robot1.pts” from the layout object, and change the wrist orientation (Wrist) of the exported No. 0-20 from “NoFlip” to “Flip”.



Number	Label	X	Y	Z	U	V	W	Local	Hand	Elbow	Wrist	J1Flag	J4Flag	J6Flag
0		100.000	10.000	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
1		100.000	140.000	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
2		99.214	143.892	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
3		97.071	147.071	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
4		93.892	149.214	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
5		90.000	150.000	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
6		10.000	150.000	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
7		6.108	149.214	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
8		2.929	147.071	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
9		0.786	143.892	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
10		0.000	140.000	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
11		0.000	10.000	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
12		0.786	6.108	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
13		2.929	2.929	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
14		6.108	0.786	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
15		10.000	0.000	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
16		90.000	0.000	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
17		93.892	0.786	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
18		97.071	2.929	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
19		99.214	6.108	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
20		100.000	10.000	15.000	90.000	0.000	180.000 0		Righty	Above	Flip	0	0	0
21														

- (2) Write the following program in “Main.prg” program

```
Function main
```

```
Motor On
```

```
TLSet 1, XY(-112, -41, 80, 0, -90, 0)
```

```
Tool 1
```

```
Go P0
```

```
Move P1 CP
```

```
Arc P3, P5 CP
```

```
Move P6 CP
```

```
Arc P8, P10 CP
```

```
Move P11 CP
```

```
Arc P13, P15 CP
```

```
Move P16 CP
```

```
Arc P18, P20 CP
```

```
Pulse 0, 0, 0, 0, 0, 0
```

```
Motor Off
```

```
Fend
```




TIP By using Tool coordinate system 1, the tip of the syringe can trace outlines of workpiece.

- (3) Click the tool bar-<Build project>. The program will be built.


When the program build is completed normally, the message “Build complete, no errors” will be displayed in the Status window.


6. Execute the program and operate the manipulator

- (1) Click the tool bar<Open run window> to open the <Run> window
- (2) Click <Start>. Then, the message “Are you ready to start?” will be displayed. Click <Yes>.
- (3) The program will be executed. Check that the manipulator moves from P0 to P20 sequentially and the tip of the syringe traces the edge of Work in counterclockwise direction.







7. Function of CAD to Point

Pressing the <CAD to Point > button on the toolbar to display [Export Points] dialog box.



Edge

Function	Description
 Up button	Move the order of the selected edge to up.
 Down button	Move the order of the selected edge to down.
 Reverse button	Switch the start point and end point of the selected edge. Red arrow on the edge indicates the direction from start point to end point.
 Delete button	Delate the selected edge.

Edge Information


Function	Description
Type	Display the type of the selected edge. Types are Line, Curve, and Composite Curve.
Vertex Number	Display the number of vertex of selected edge. Increase or decrease division number to increase or decrease the number of vertex.
Division Number	Set the division number of the selected edge.


Offset

Function	Description
Position	Enable to move the vertex position to X, Y, and Z direction. Refer to the coordinate system of CAD object for the directions. Also, enable to expand or decrease from the center of the arc to radius direction if the edge is curve or composite curve which can approximate to the arc.
Orientation	Enable to rotate tool orientation to Rx, Ry, and Rz direction. Refer to the coordinate system of CAD object for the directions.

Render Option

Function	Description
Render Approach	Display the Z-axis (red arrow) of the render orientation to the vertex. It is useful when Z-axis of the render orientation cannot be seen due to workpieces.
Render Orientation	Display the orientation on the vertex. Only displays when the vertex is displayed.
Render CAD Origin	Display the origin of CAD object in coordinate system.
Render Vertex	Display the vertex of the selected edge.
Vertex Size	Set the vertex size.
Arrow Size	Change an arrow size that is directed to start point to end point of the selected edge.

Click the <Export Points > button on the [CAD to Point] dialog to display the [Export Points] dialog.



Point output

Function	Description
Robot	Set the robot to output the points.
Local	Set the local coordinate to output the points.
Point File	Set the point file to output the points.
Start Number	Set the start number of outputting points.

8.3.6 CAD to Point for ECP

CAD To Point for ECP is a function to output edge line information which is included in CAD data as point data to operate external control point (ECP) motion. By the robot grasps workpiece and selecting edges of CAD objects on the 3D view sequentially, you can generate point data along with the motion path. The robot motion points can be registered automatically based on CAD data such as part. Therefore, development time of programs can be shortened.


Use a sample using easy CAD data to execute CAD To Point for ECP.

In the example, create a motion to follow an outer circumference of grasped CAD object (tray) by the robot on the edge of fixed syringe.

Operate the following procedures:

1. Connect to virtual controller “CTP for ECP”
2. Open a project
3. Select CAD Object and ECP
4. Select an edge of CAD object and create a motion path of the robot
5. Output as point data
6. Create a program
7. Execute the program and move the robot


1. Connect to virtual controller “CTP for ECP”




Select “CTP for ECP” of [Connection:] on EPSON RC+ 7.0 toolbar.


When the connection is complete, “CTP for ECP” is displayed in the [Connection:] box.

Click the <Simulator > button on the toolbar to display the [Simulator] window. CAD objects: “sample_part” and “syringe”, and Hand objects are placed.




4. Select an edge of CAD object and create a motion path of the robot

- (1) Click the <Select Edge  > button to display the [CAD to Point for ECP] dialog.




- (2) To operate the sample program properly, select edges in counterclockwise rotation sequentially from edge of straight part of right tray.


For selection of surface including edges and edges, refer to 8.3.5 *CAD To Point*.



The straight part indicates edges on flat surface on the outer circumference.



The curve part indicates edges on side of the tray.



For division number and offset for each edge, refer to the following values.

Edge number		1	2	3	4	5	6	7	8
Type		Straight	Curve	Straight	Curve	Straight	Curve	Straight	Curve
Division number		0	2	0	2	0	2	0	2
Offset	Position (mm)	X	0	0	0	0	0	0	0
		Y	0	0	0	0	0	0	0
		Z	0	0	0	0	0	0	0
	Orientation (deg)	Rx	20	290	20	290	20	-70	20
		Ry	0	0	0	0	0	0	180
		Rz	0	0	270	0	180	90	0




TIP


The arrow direction of edges indicates direction of start and end point of generating point.


Click the <Reverse > button to invert the arrow direction. Make sure to set the arrow direction will be counterclockwise rotation.


When all edges are set properly, it will be as follows.



5. Output as point data

Click the <Export Points > button of the [CAD to Point (ECP support)] dialog to display the [Export Points] dialog.



Click the <OK > button to output the point data to No.0-12 of the point file “robot1.pts”.

6. Create a program

(1) Set the proper robot orientation for the point data.

Open the point file “robot1.pts” from the layout objects and perform the following.

Wrist orientation (Wrist) of output point No.0-12 : NoFlip → Flip

J6Flag of point No. 10-12 : 0 → 1

Number	Label	X	Y	Z	U	V	W	Local	Hand	Elbow	Wrist	J1Flag	J4Flag	J6Flag
0		65.000	641.854	718.804	0.000	0.000	-20.000	0	Righty	Above	NoFlip	0	0	0
1		-65.000	641.854	718.804	0.000	0.000	-20.000	0	Righty	Above	NoFlip	0	0	0
2		-17.678	674.035	707.091	-43.219	-13.995	-14.433	0	Righty	Above	NoFlip	0	0	0
3		40.000	665.347	710.253	-90.000	-20.000	0.000	0	Righty	Above	NoFlip	0	0	0
4		-40.000	665.347	710.253	-90.000	-20.000	0.000	0	Righty	Above	NoFlip	0	0	0
5		17.678	674.035	707.091	-136.781	-13.995	14.433	0	Righty	Above	NoFlip	0	0	0
6		65.000	641.854	718.804	-180.000	0.000	20.000	0	Righty	Above	NoFlip	0	0	0
7		-65.000	641.854	718.804	180.000	0.000	20.000	0	Righty	Above	NoFlip	0	0	0
8		-17.678	674.035	707.091	136.781	13.995	14.433	0	Righty	Above	NoFlip	0	0	0
9		40.000	665.347	710.253	90.000	20.000	0.000	0	Righty	Above	NoFlip	0	0	0
10		-40.000	665.347	710.253	90.000	20.000	0.000	0	Righty	Above	NoFlip	0	0	1
11		17.678	674.035	707.091	43.219	13.995	-14.433	0	Righty	Above	NoFlip	0	0	1
12		65.000	641.854	718.804	0.000	0.000	-20.000	0	Righty	Above	NoFlip	0	0	1

- (2) Create the following program in Main.prg program.

```

Function main

Motor On
Power High

Tool 1
ECP 1

Go P0

Move P1 ECP CP
Arc3 P2, P3 ECP CP

Move P4 CP
Arc3 P5, P6 ECP CP

Move P7 CP
Arc3 P8, P9 ECP CP

Move P10 CP
Arc3 P11, P12 ECP CP

Pulse 0, 0, 0, 0, 0, 0
Motor Off

Fend

```


- (3) Click the <Build> button on the toolbar. Build the program.

When the build is complete normally, the message “Build complete, no errors” appears in the [Status] window.

7. Execute the program and move the robot

- (1) Click the <Run> window button on the tool bar to display the Run window.
- (2) Click the <Start> button. When the message “Are you ready to start?” is appeared, click the <Yes>.
- (3) Confirm that the program is executed and follow an outer circumference of grasped CAD object (tray) by the robot on the edge of fixed syringe to operate ECP motion.

Functions of CAD to Point for ECP

Click the < CAD to Point for ECP  > button on the toolbar to display the [CAD to Point (ECP support)] dialog. For functions, refer to 8.3.5 *CAD to Point - 7. Function of CAD to Point*.

8.3.7 Virtual controller

To execute programs in the simulator, you need to create a virtual controller with defined robot and layout.

Robot settings and layout settings for the 3D display are saved for each virtual controller. If you want to transfer the robot or layout data, you can copy and transfer the data.


The virtual controller created by the EPSON RC+ 7.0 Ver. 7.3.0 cannot be used in lower versions of EPSON RC+.

Create a new virtual controller


Refer to 8.2.2 *Working with the user created system.*

Copy the sample or configured virtual controller


- (1) Click the EPSON RC+ 7.0 Tool bar-<Connection  > button.
The [PC to Controller Communications] dialog appears.



- (2) Click the <Add> button. The [New Controller Connection] dialog appears.
- (3) Select the <Connection to new virtual controller> option button and specify a virtual controller from the list box. Click the <OK> button.



- (4) New “Virtual 2” is created. Click the <Apply> button.




- (5) Close the dialog and go back to the EPSON RC+ 7.0 main window.

- (6) Connect to “Virtual 2” and display the [Robot Simulator] window.
The robot setting and layout setting of 3D display has been taken over from “Virtual 1”.
- (7) When you want to change the robot type, use the [Change Robot] in the robot object property.
For details, refer to 8.3.1 [Robot Simulator] layout – (3) Property Grid.

Virtual controller configuration

Normally you don't need to configure a virtual controller.

The configuration is available from the [Setup]-[System Configuration]-[Controller]-[Simulator] page.



[Performance] : You normally don't need to change the setting from 8 ms (default).

[Position Precision] : You normally don't need to change the setting from 16 ms (default).


The situations when you need to change these settings are described in 8.4 *Simulator Specifications and Restrictions*.

8.3.8 Connection with controller

Enable the Simulator in controller

From the [Setup]-[System Configuration]-[Controller]-[Simulator], check the [Enable Simulator] check box to enable the simulator function.

After checking the check box, click the <Apply> button and then click the <Close> button.



If collision with the simulator object is detected during a Jog motion or a robot motion command execution when the Simulator is enabled, the Manipulator stops operation and a Warning occurs.


To avoid collision with peripherals by using the Simulator, set 15 mm or greater margins to the simulator object.

Function restrictions when connected with controller

- You cannot change the manipulator from the [Robot Simulator] window.
- You cannot select and move the manipulator arms in the [Robot Simulator] window, except during the controller Dry run.
- When the manipulator connected to the controller is not supported in the Simulator, the object list and the manipulator in 2D layout and 3D window are not displayed.
- The [Record/Playback] functions are not available.


Operator Window

When you enable the Simulator, the <Simulator> button is added to the Operator Window. When you click on the <Simulator> button, the 3D display window appears.




8.3.9 Virtual Camera Settings and Camera View Display

Virtual camera settings are function to select camera or lens, and install as the fixed camera or mount as the mobile camera to the robot. Display of the camera view is a function to display images of the set camera. You can select the camera or lens and verify the layout by the simulator.



Add virtual cameras


Click the <Camera > button on the toolbar to display the [Add Cameras] dialog. After selecting devices and setting the mounting type, click the <Add> button.

Add Camera	
Camera	
Type :	Compact Visio
Connection Type :	GigE
Model :	acA640-120gm
Extension Tube :	0.0 mm
Lens	
Type :	Mega Pixel
Focal Length :	8 mm
Mount Setting	
Type :	Mobile
Robot :	1
Joint :	2
<div> Add Cancel </div>	

If setting [Type] to “Mobile”, right click on the camera object of the layout object to display the context menu. Select [Camera Mount Settings] to display the [Camera Mount Settings] dialog. Set the relative position to joints.

Camera view display

By clicking the [Show Camera View] from the context menu of the camera objects, the camera view is displayed.



Depending on the combinations of the actual cameras and lens, mechanical vignetting occurs and the area around the image is captured black. The combinations that cause mechanical vignetting are shown below. Please be noted when using an actual camera.

Camera model	Lens type	Focal length
acA1300-60gm	Standard	12mm
acA2500-20gm/gc	Standard	8mm, 12mm, 16mm, 50mm
	mega-pixel	8mm, 12mm, 16mm, 25mm, 50mm
	mega-pixel (HF)	8mm, 12mm, 16mm, 25mm
acA5472-5gm/gc	Standard	8mm, 12mm, 16mm, 50mm
	mega-pixel	8mm, 12mm, 16mm, 25mm, 50mm
	mega-pixel (HF)	8mm, 12mm, 16mm, 25mm

8.3.10 Motion restriction by BOX

By using the BOX command together with the GetRobotInsideBox function or the OnErr command, robot power and motion can be restricted when the tool center point (TCP) enters the approach check area (BOX).

Sample project using BOX


In the sample project, BOX2 is set outside BOX1. When the tool center point calculated based on the currently selected tool enters BOX2, the robot will stop temporarily. If the program execution is continued, the robot will resume operation in the restricted status (low speed, low power).

Then, when the robot enters BOX1 inside BOX2, the robot will abort operation.

Use the sample project to execute the motion restriction using BOX.

The sample project is in \EpsonRC70\projects\SimulatorDemos\BOX_sample.

For details of the usage of the project, refer to 8.2.1 *Working with the samples*.



8.4 Simulator Specifications and Restrictions

This section describes the simulator specification, its restrictions, and precautionary statements.

8.4.1 EPSON RC+ 7.0 package

EPSON RC+ 7.0 has two packages:

EPSON RC+ 7.0 : Standard package for developing the robot system

EPSON RC+ 7.0 Trial : Trial package for limited use (program execution on PC)

* It cannot connect with a robot controller.

	Program execution on PC	Connection with controller	Connection with controller + 3D display
EPSON RC+ 7.0	OK *2	OK	OK *1
EPSON RC+ 7.0 Trial	OK *2	-	-

*1 Requires the configuration to enable the simulator functions in EPSON RC+ 7.0. Refer to 8.3.8 *Connection with controller* for the detail information.

*2 Total execution time of program is limited.

8.4.2 Specifications and precautions for the 3D display

Available robots for 3D display

In the future, we will add more robots for 3D display. Please contact the supplier of your region for the latest information.

Some robots cannot use this function. For more details on unsupported models, refer to *Appendix C: Simulator Functions List of Unsupported Manipulator Models*.



The flexible duct is displayed roughly.

- Check the dimensions in the manipulator manual.
- The duct actually vibrates while the manipulator is moving, the simulator doesn't display the vibration. Check how the duct vibrates with your real manipulator.

The bellow for Cleanroom or Protection model is displayed roughly

- Check the dimensions in the manipulator manual.

Available CAD data for 3D display

The following format is available for 3D display to show the robot hand and CAD object.

- VRML 2.0
Limits of reading: VRML2.0 prototype is not supported.
- STEP (AP203/AP214)
Limits of reading: The file whose character code is only ASCII can be read. In addition, if Color is configured in Face, the specified Color is displayed.
- IGES
- DXF
DXF Format (DXF R13, DXF R14, DXF 2000/2000i, DXF 2002) of AutoCAD ® software



The data file must be saved in the specified folder on the PC and not saved in EPSON RC+.

The character code of file path for CAD data

For CAD data file in VRML 2.0 format and IGES format, the data cannot be loaded when the character code which is different from the language in the operating environment is included in the file path (a file and folder name). Change the file and folder name to be the same character code as the language in operating environment.

Memory usage of CAD data

The memory usage of 32 bit applications is limited to 2 GB. The CAD data cannot be loaded when the total of memory usage of the application and the CAD exceeds 2 GB. Therefore, the total number of polygons and polylines are limited to a million. When the error message appears, reduce the number of polygons and polylines.

CAD data setup orientation

Some CAD data coordinates may be different from those of the simulator.

Adjust the coordinates to the correct position by changing [Property]-[Rotation] after loading the CAD data.

When loading CAD data as a hand, set the origin of the CAD data in the Tool0 position of the manipulator. Set the coordinates to the correct position by changing [Property]-[Position] after loading the CAD data.

Number of available layout objects

You can create as many layout objects as you want.

However, when there are many objects to display, the display update interval becomes longer and the judgment of collision detection becomes rough. Especially for CAD data, displaying data that is too complicated is not recommended.

Shape of CAD object

The shape of objects may be displayed incorrectly (such as a clearance arises between the faces) depending on the CAD data. In such a case, the shape may be improved by converting the data to a different format.

Front-back relation of objects in semi-transparent display

The front-back relation of the objects may be incorrect when displaying the CAD and Hand objects in semi-transparent display.

Rendering speed

It may take a few seconds to render the objects depending on the display adapter, and operability such as in selecting the object may be decreased. It is recommended to update the driver to the latest version.

8.4.3 Specifications and precautions for Simulation (program execution on PC)

Overview

The Simulator produces the robot motions virtually on your PC.

It is designed to make the performance gap between the real system and the virtual system as small as possible. However, a few differences in the virtual system are inevitable. The operation time prediction and collision detection do not guarantee the precision.

Fully understand the contents in this chapter and check if the real system operates without any problems before you go to full-scale operation.

Operation time prediction

Operation time displayed in the [Robot Simulator] window is approximate time required for executing the program.

Time for the motion commands such as Go, Jump reflects the Speed and Accel values in the program. The operation time may vary when you operate the real robots from the displayed operation time according to conditions such as the Fine setting and servo delay.

In particular, when small ranges are used with the Fine instruction, the real robots need a longer operation time for accurate positioning.

The simulation cannot guarantee the precision but the margin of error in the operation time is within 10% when you execute motions with the standard cycle time (with the default Fine settings).

Considered in the operation time prediction	Not considered in the operation time prediction
Robot model Speed settings (Speed, Speeds, etc.) Acceleration settings (Accel, Accels, etc.) Load (Weight, Inertia) Others (ARCH, CP)	Fine setting Error within 10% from the default (Motions of standard cycle time) With larger setting than the default, the operation time will be shorter. With smaller setting than the default, the operation time will be shorter. Servo delay With the real robots, the operation will be longer.

Time for the other commands than the motion commands is a virtually executed time on PC; therefore the actual time varies widely depending on the PC performance.

When measuring the motion time between two points, as simple program as possible is recommended. Refer to 8.2.2 *Working with the user created system - 8. Measure the robot operation time.*

Collision Detection Precision

The Simulator Collision Detection provides an indication whether robots collide with the peripheral equipment or not when the program is executed. It does not consider the error in path due to servo delay. Be aware that a margin is necessary for the real robot system.

The Simulator judges collisions more accurately when the robot motion speed is slow.

The judgment of collision detection during program execution is accomplished with the 3D display update. When your PC has high graphics performance, the collision judgment becomes more accurate.

In Playback mode, the Simulator judges collisions in all steps and is useful when you need accurate detection.

The Simulator cannot guarantee the precision but the margin of error in the collision detection is within 10 mm when you execute motions with Speed 100% on a PC of the recommended specifications.

Motion duty and Overload error

In the Simulator, you cannot detect the overload error. Even when the motion duty is too high and the robot should have the overload error and stop, it keeps moving.

Duty 50% - As a measure of possible duty, the robot can really keep moving at duty 50% with the maximum acceleration/deceleration speed and without the overload error.

However, it depends on the robot model type, load, points to go to, and acceleration/deceleration speed setting, etc.

Time progress difference by PC condition

On a PC that meets the system condition, progress of the time in the Simulator and the real time (as you see on the watch) are almost the same (few percentages difference).



If you are running other applications such as Windows Media Player simultaneously, the time progress in the Simulator can widely vary from the real time. In this case, use the Simulator function while other applications are not running.

Also, on some PC models, the time progress in the Simulator may widely vary from the real time. In this case, set the [Performance] at 16 ms and the [Position Precision] at 20 ms, which may close the gap of the time progress.

Time confirmation program

(If the two printed times are within 27 to 33 seconds, there is no problem.)

```
Function main
  Print Time$
  Wait 30
  Print Time$
Fend
```

Execution on PC below the minimum of specification

You can install the EPSON RC+ and use the Simulator functions on a PC that doesn't meet the minimum of the specification.

However, it doesn't guarantee the correct motions because the following may happen:

- Operation time prediction is not accurate
- Collision Detection has a large margin of error
- 3D display skips updates

8.4.4 Specifications and precautions of EPSON RC+

Restriction on the controller settings

When you connect with a virtual controller, the following items are grayed and become unavailable to change.

- Setup: System Configuration: Controller: Configuration Page: IP Address, etc.
- Setup: System Configuration: Controller: Preference Page: Dry run, etc.

Backup and restore of the controller setting

The setting data that you backup in the virtual controller can be restored in a controller. Also, the setting data that you backup in a controller can be restored in a virtual controller. However, there are restrictions. For more details, refer to 5.11.8 [Maintenance] (Tools menu)-[Backup Controller] and [Restore Controller].

8.4.5 Restriction on SPEL+ command execution

(1) I/O operation and commands (On, Off, SW, Ctr, etc.)

All I/O including the option boards are available in a virtual controller. Operating I/O data is stored in the PC memory (virtual I/O mode). The I/O input status can be changed from the EPSON RC+ I/O Monitor window. Also, the I/O input status can be changed using the SetSw or SetIn statements in a SPEL+ program.



Even if you specify an asynchronous On/Off command, the I/O status cannot be changed after the specified time and the Ctr function always returns 0.

(2) Ethernet / RS-232C communication command (Print #, Input #, OpenCom, OpenNet, etc.)

All 16 Ethernet ports are available. However, an Ethernet port requires configuration of the IP address and TCP/IP port.

For RS-232C on the Controller, all 8 ports including the option RS-232C board are available.

NOTE

For RC700/RC700-A Controller and RC90 Controller, up to 5 ports including the standard port and the option RC-232C board are available. T series and VT series Manipulator do not have RS-232C ports on the Controller. Be careful of the number of the ports when using the project created in the virtual controller to the Controller.

As a default, Ethernet / RS-232C communication commands do not perform actual communication.

To use the actual Ethernet/RS-232C ports, be sure to configure as described in (3).

Output data from Print #, etc. is saved in the communication output file. In the input by Input#, etc, the return value is 0 (numeric data) or blank (string). However, if you create a communication response file, the return value depends on the file content.

Communication output file

When calling OpenCom or OpenNet command, a communication output file is created in the \EpsonRC70\Virtual\Mounted Volume\Project folder on the PC.

DummySend***.dat : Communication output file (***) is the port number)

When a communication output file already exists, the previous output data is deleted. The file is deleted when you switch the project; save the file in a proper folder if you need.

When executing the following program,

```
OpenCom #1
Print #1, 123
Print #1, "TEST DATA"
CloseCom #1
```

the DummySend001.dat file will contain...

```
123
TEST DATA
```

Communication response file

Copy the communication response file to the \EpsonRC70\Virtual\Mounted Volume\Project folder in before running a program. The file is deleted when you change the project; save the file in another folder if you need to keep it.

When calling OpenCom or OpenNet command, the communication response file is loaded.

DummyRead***.dat : Communication response file (***) is a port number)

When the following DummyRead001.dat file is used,

```
321
Test Data
```

and the following program is executed,


```
Integer i
String s$
OpenCom #1
Input #1, i
Input #1, s$
CloseCom #1
Print i
Print s$
```

the return values are i = 321 (numeric data), and s\$ = "Test Data" (string).

(3) How to enable the actual ports of Ether net/RS-232C in the virtual controller


Actual ports become available when [Real] is selected in [Setup]-[System Configuration]-[Controller]-[TCP/IP].

Change the port settings, then click <Apply> and <Close>.




Actual ports become available when [Real] is selected in [Setup]-[System Configuration]-[Controller]-[RS-232C] -[PC].

Select the PC port, then click <Apply> and <Close>.



Actual ports become available when [Real] is selected in [Setup]-[System Configuration]-[Controller]-[RS-232C] -[Controller].

Select the PC port, then click <Apply> and <Close>.



To use the actual Ethernet/RS-232C ports, select the actual ports in the configuration dialog.

(4) Vision command (VRun, VGet, etc.)

For the vision-related commands, communication with the Compact Vision (CV1) is not performed. However, the commands can be executed with virtual camera function. Vision sequence can be executed with an image file set in ImageFile property as an input image. Also the result can be acquired by VGet. When the PC vision is set and the GigE camera is connected, vision commands such as VRun and VGet can be executed using actual camera image. In this case, commands can be executed from the virtual camera function like the Compact Vision, when the GigE camera is not connected.

For the Vision Guide, refer to *EPSON RC+ option Vision Guide 7.0*.

(5) Other restrictions

For the Wait command, the following syntax is not supported:

Wait InsideBox()

Wait InsidePlane()

For the Time and Date commands, the time can be displayed, but the time setting is not available.

For the SimSet commands, the motion of the parts that specify Pick or Place and movement or rotation of the objects that specify PositonX, PositionY, PositionZ, RotaitonX, RotationY, or RotationZ cannot be recorded and produced by the [Record/Playback] functions.

(6) Program total execution time

In the virtual controller, the total execution time of programs is limited to one hour.

If total execution is over one hour, a warning message appears.

You can execute the program again after the warning is displayed, and the total execution timer will be reset.

8.4.6 Specifications and precautions of EPSON RC+ 7.0 Trial

Version upgrade from EPSON RC+ 7.0 Trial to EPSON RC+ 7.0

Follow the procedures in *Appendix B: EPSON RC+ 7.0 Software* to upgrade to EPSON RC+ 7.0. The EPSON RC+ 7.0 Trial version doesn't need to be uninstalled.



You can continue to use the projects and virtual controllers (layout) that you used in the EPSON RC+ 7.0 Trial in the EPSON RC+ 7.0 Standard version.

9. Motion System

EPSON RC+ supports the motion systems listed below.

- Standard Motion System
- PG Motion System

9.1 Standard Motion System

The standard motion system consists of the Control Units and the Drive Units (optional, up to three units).

You can connect one robot to the Control Unit directly. For details on the Robot Controller and maintenance, refer to the *Robot Controller* manual.

The Drive Units are automatically recognized at the startup of the Control Unit if they are connected to the system.

When addition and removal of the Drive Units are automatically recognized, the startup time becomes longer in order to reboot the Control Unit.

9.2 Drive Module Software Configuration

The drive module is configured at the factory before shipment. It is automatically recognized by the controller and you do not have to configure the settings.

Also, you do not have to configure the settings for the drive module in the Drive Unit which is automatically recognized.

9.3 PG Motion System

The PG (Pulse Generator) Motion System is an option.

When a PG board is installed in the controller, it is automatically recognized. You can select it in the robot configuration dialog.

For instructions on using the PG Motion System, refer to the *Robot Controller Option PG Motion System* manual.

10. Robot Configuration

This chapter contains information for adding robots and configuring additional axes.

- Robot Configuration
 - Adding a standard robot
- Additional axes Configuration
 - Adding a robot with additional axes

Robots are configured from the Robots folder on the [Setup]-[Controller] dialog tree.

10.1 Setting the Robot Model




- Each robot is configured before shipment. Therefore, it is normally unnecessary to change the settings. If you change the settings, it may cause the robot to malfunction or perform unusual motion. This is extremely hazardous and you should be careful.


10.1.1 Adding a standard robot

If you have purchased the PG motion system Option, you can add user defined robots. Refer to the *Robot Controller Option PG Motion System* manual.

1. From the Setup Menu, select System Configuration.
2. Click [Robots] in the tree on the left.



3. Click <Add> and the following dialog box will appear.



4. Type in a name for the new manipulator and enter the serial number on the manipulator's nameplate. Any serial number can be used, but it is recommended that you use the number that is stamped on the manipulator.
5. Select a motion system to use from the [Motion System] dropdown list. If there are no other motion systems installed, then "Standard" will already be selected.
6. Select a Drive Unit for your manipulator from the [Drive Unit] dropdown list.
7. Select a manipulator type from the [Robot type] box.
8. Select a manipulator series from the [Series] dropdown list.
9. Select a manipulator model from the [Model] dropdown list.
After you select a manipulator model, all manipulators available for the type of motor driver currently installed in the controller will be displayed. If you use [Dry run], all robots selected in step 9 will be shown.
10. Click <OK> and the controller will be rebooted.

10.1.2 Calibrating a standard robot

The calibration method differs according to the manipulator model.

For details, refer to the *Manipulator manual: Maintenance section: Calibration*.

10.1.3 Changing robot system parameters

The following system parameters for the robot can be changed from EPSON RC+ 7.0:

- Enable/Disable Joints

You can disable one or more joints from [Setup]-[System Configuration]-[Robots]-[Robot**]-[Configuration]. On robots with a ball screw Z axis, you must disable both joints 3 and 4 together.

- Hofs

Hofs are the joint home offsets. You can view and edit the values from [System Configuration]-[Robots]-[Robot**]-[Calibration]. However, it is recommended that you use the Robot Calibration wizard to set these values. These values are unique for each robot and are supplied from the factory. Hofs are especially important for SCARA robots because the values determine that both lefty and righty hand orientation will position the robot at the same point.

- CalPIs

CalPIs values are joint calibration offsets. You can view and edit the values from [System Configuration]-[Robots]-[Robot**]-[Calibration]. However, it is recommended that you use the Robot Calibration wizard to set these values. These values are unique for each robot and are supplied from the factory. CalPIs values are used to calibrate joint position after replacing a motor or encoder.

These are one-time settings for each robot. Additional robot parameters can be set from the Robot Manager.

To change robot parameters, follow these steps:

1. Select [System Configuration] from the [Setup Menu].
2. Under the [Robot] folder in the tree on the left, select [Robot**]-[Calibration].
3. Execute the calibration wizard or change values for Hofs or CalPIs.
4. Click <Apply> to make the changes permanent.

Saving robot calibration data

You can save and load individual robot calibration files. This is useful for moving a robot from one controller to another. When you save calibration data, a file is created with an MPD file extension. This file contains Hofs and CalPls values.

To save robot calibration data

1. Select [System Configuration] from the [Setup] menu.
2. Under the [Robot] folder in the tree on the left, select [Robot**]-[Calibration].
3. Ensure that the robot serial number is correct. The serial number will be used to create the default file name. It is recommended that the serial number be used.
4. Click the <Save Cal> button. Browse to a destination directory and click Save.

Loading robot calibration data

To load robot calibration data


1. Select [System Configuration] from the [Setup] menu.
2. Under the Robot folder in the tree on the left, select [Robot**]-[Calibration].
3. Click the <Load Cal> button.
4. Browse to the desired MPD file and click <Open>.

10.1.4 Deleting a standard robot


1. Select <System Configuration> from the <Setup> menu.
2. Under the [Robot] folder in the tree on the left, select [Robot**].



You can only delete the last robot.



3. Click <Delete> and the next dialog will appear.



4. Click <Yes> and the controller will be rebooted.

If you delete only an additional axis from its installed robot, refer to *10.2.5 Deleting the additional axes*.

10.1.5 Changing the Robot




CAUTION


- Changing the manipulator should be done with great caution. It initializes the robot calibration parameters (Hofs, CalPIs), additional axis information, and PG parameter data. Before changing the robot, make sure to save the calibration data by following the procedure below.

1. Select the EPSON RC+ 7.0 menu-[Setup]-[System Configuration].
2. Select [Robot]-[Robot**]-[Calibration] from the tree list. Then, click <Save>.

1. Select the EPSON RC+ 7.0 menu-[Setup]-[System Configuration].
2. Select [Robot]-[Robot**] from the tree list.



3. Click the <Change...> button. The following dialog box will be displayed.




4. Input the robot name and serial number printed on the name plate of the manipulator. Any serial number can be entered. However, enter the number printed on the manipulator.
5. Select the robot type in the [Robot type] box.
6. Select the series name of the manipulator in the [Series] box.
7. Select the robot model in the [Model] box. Available robots will be displayed according to the format of the currently installed motor driver. When [Dry run] is used, all the manipulators of the series selected in Step 6 will be displayed.
8. Click the <OK> button. The controller will be restarted.

10.2 Configuration of Additional Axes


Using the additional axes feature, you can configure the axes that move with the manipulator. You can configure up to two additional axes (S and T).

10.2.1 Adding the additional S axis

1. Select [System Configuration] from the [Setup] menu.
2. Under the [Robot] folder in the tree on the left, select [Robot**]-[Additional Axes].



3. Click <Add> and the next dialog will appear.



4. Select "PG" for a motion system.
5. Select a PG board A.
6. Click **OK** and the controller will be rebooted.

10.2.2 Adding the additional T axis



NOTE

After the additional S axis has been added to the robot, you can add the additional T axis. The procedure is the same as for the S axis. Refer to *10.2.1 Adding the additional S axis*.

10.2.3 Changing the parameters of robot with additional axes installed

For details, refer to the *Robot Controller Option PG Motion System* manual.

10.2.4 Differences of the standard robot and robot with additional axes


The robot with additional axes installed has some parts which are different from the standard robot when using GUI and SPEL⁺ commands.

For the SPEL⁺ commands, refer to the *SPEL⁺ Language Reference manual*.

The main differences in the EPSON RC+ 7.0 GUI are as below.


Tools: Robot Manager: Jog & Teach Page

You can jog the additional S and T axes. When the additional T axis is not installed, the jog buttons will be dimmed.



Tools: Robot manager: Weight Page

This page is for changing the Weight parameters for the robot. When the additional T axis is not installed, the corresponding weight setting will be dimmed.




10.2.5 Deleting the additional axes




When the additional T axis is installed, delete it first.

When only the additional S axis is installed, delete it.

1. Select System Configuration from the Setup Menu.
2. Under the [Robot] folder in the tree on the left, select [Robot**]-[Additional Axes].



3. Click <Delete> and the next dialog will appear.



4. Click <Yes> and the controller will be rebooted.

11. Inputs and Outputs

11.1 Overview

The controller I/O has the following types of I/O:

Standard I/O	This digital I/O comes standard with the controller.
Expansion I/O	This is optional digital I/O that can be added to the controller to expand standard I/O. The boards with 24 inputs and 16 outputs can be added. (Boards cannot be added to T, VT series Manipulator.)
Fieldbus master I/O	An optional board for the controller to expand the standard I/O. You can add one of the following boards which support the fieldbus master board. (PC) DeviceNet, EtherNet/IP, PROFIBUS-DP
Fieldbus slave I/O	An optional board for the controller to expand the standard I/O. You can add one of the following boards which support the Fieldbus slave mode. (Controller: RC700, RC90) You can add one of the following modules which support the Fieldbus slave mode. (Manipulator : T, VT) DeviceNet, EtherNet/IP, PROFIBUS-DP, CC-Link, PROFINET, EtherCAT, Modbus
Memory I/O	This is built-in memory bits that can be used for inter-task communications.
Analog I/O	This is option to add analog input/output function to the controller. (Boards cannot be added to T, VT series Manipulator.)

For Standard, Expansion, Fieldbus master, and Fieldbus slave I/O, there are input bits numbered starting with 0, and output bits numbered starting with 0.

For memory I/O, each memory bit is both an input and an output.

For specifications and instructions on wiring I/O, refer to the following manual.

Robot Controller manual: RC700, RC700A, RC90, RC90B

Manipulator manual: T, VT series

11.2 I/O Commands

The SPEL+ language has several commands for inputs and outputs listed below. For details on each command, see the SPEL+ Language Reference.

Input Commands

In	Reads one byte of input bits.
InBCD	Reads one byte of input bits in Binary Coded Decimal format.
InW	Reads one word of input bits.
Oport	Reads one output bit.
Sw	Reads one input bit.

Output Commands


Off	Turns off one output bit with optional time.
On	Turns on one output bit with optional time.
OpBCD	Sets one byte of output bits in Binary Coded Decimal format.
Out	Sets / reads one byte of output bits.
OutW	Sets / reads one word of output bits.

Memory I/O Commands

MemOff	Turns off one memory bit.
MemOn	Turns on one memory bit.
MemOut	Sets / reads one byte of memory bits.
MemSw	Reads one bit of memory.

11.3 I/O Configuration

To view the current I/O configuration, select [Setup]-[System Configuration]-[Inputs and Outputs]. This will show you what I/O is installed on the controller.



Standard and expansion I/O

The board is automatically configured by the controller. To add expansion I/O boards, refer to *Robot Controller manual*.

The standard I/O in the Drive Unit automatically increases depending on the number of Drive Unit.

Fieldbus master I/O / Fieldbus slave I/O

For details on how to configure, add, check the boards, refer to the *Robot Controller Option Fieldbus I/O manual*.

Analog I/O

The board is automatically configured by the controller. To configure, add, or confirm the analog I/O boards, refer to *Robot Controller manual*.

11.4 Monitoring I/O

To monitor I/O, use the I/O Monitor tool by selecting [Tools]-[I/O Monitor]. From the I/O monitor, you can view inputs and outputs or memory I/O in bit, byte, and word formats.

For details on how to use the I/O Monitor tool, see 5.11.3 [I/O Monitor] Command .

11.5 Virtual I/O

The Controller supports virtual I/O. When enabled, virtual I/O allows you to simulate your hardwired I/O. You can turn on / off any input bit or output bit. Normally this is used when the controller is in Dry Run mode with no robot or I/O connected.

Virtual I/O Commands

SetIn	Set the value of an 8 bit input port.
SetInW	Set the value of a 16 bit input port.
SetSw	Set the value of one input bit.

11.6 Fieldbus Master I/O

The Fieldbus master I/O is an option.

For details on how to use, refer to the *Robot Controller Option Fieldbus I/O manual*.

11.7 Fieldbus Slave I/O

The Fieldbus slave I/O includes the standard functions (Modbus RTU and Modbus TCP), and the options.

For types and usage of the optional Fieldbus slaves, refer to the *Robot Controller option Fieldbus I/O* manual.

11.7.1 Modbus Slave

Modbus TCP and Modbus RTU can be used as the Fieldbus slave I/O as standard.



Modbus cannot be used when other Fieldbus slave boards are installed.

Modbus is a protocol which has a dialect. Although connection with the standard Modbus protocol has been confirmed, use the Modbus slave in the system after checking connectivity with equipment to be connected.

11.7.2 Supported Functions

The Controller supports following Modbus functions.

Function code	Function name	Description
1	Read Coil Status	Use this function to read the status of the input bit port. No broadcast.
2	Read Input Status	Use this function to read the status of the output bit port. No broadcast.
3	Read Holding Registers	Use this function to read the status of the input word port. No broadcast.
4	Read Input Registers	Use this function to read the status of the output word port. No broadcast.
5	Force Single Coil	Use this function to configure an input bit port.
6	Preset Single Register	Use this function to configure an input word port.
15	Force Multiple Coils	Use this function to configure several input bit ports.
16	Preset Multiple Registers	Use this function to configure several input word port.

11.7.3 Address map

Input I/O				Output I/O			
Fieldbus I/O Address		Modbus Address		Fieldbus I/O Address		Modbus Address	
Word	Bit	Holding register	Coil	Word	Bit	Holding register	Coil
32	512	40032	512	32	512	30032	10512
	513		513		10513		
	514		514		10514		
	515		515		10515		
	516		516		10516		
	517		517		10517		
	518		518		10518		
	519		519		10519		
	520		520		10520		
	521		521		10521		
	522		522		10522		
	523		523		10523		
	524		524		10524		
	525		525		10525		
	526		526		10526		
	527		527		10527		
33	528	40033	528	33	528	30033	10528
	529		529		10529		
	530		530		10530		
	531		531		10531		
	532		532		10532		
	533		533		10533		
	534		534		10534		
	535		535		10535		
	536		536		10536		
	537		537		10537		
	538		538		10538		
	539		539		10539		
	540		540		10540		
	541		541		10541		
	542		542		10542		
	543		543		10543		
159	2544	40159	2544	159	2544	30159	12544
	2545		2545		12545		
	2546		2546		12546		
	2547		2547		12547		
	2548		2548		12548		
	2549		2549		12549		
	2550		2550		12550		
	2551		2551		12551		
	2552		2552		12552		
	2553		2553		12553		
	2554		2554		12554		
	2555		2555		12555		
	2556		2556		12556		
	2557		2557		12557		
	2558		2558		12558		
	2559		2559		12559		

NOTE



Note that the addresses are specified with the numbers fewer than the originals by 1.

The address to access to the input bit port 512 is 511.

11.7.4 Modbus RTU

Modbus RTU is the Fieldbus which uses the serial communication. It can be used with the RS-232C port which is installed to the Controller as standard, and the optional extended RS-232C port.

11.7.5 Modbus TCP


Modbus TCP is the Fieldbus which uses the Ethernet communication (socket communication). It can be used with the Ethernet installed to the Controller as standard.

11.7.6 How to Configure Modbus


(1) Use of Modbus

Modbus can be enabled in the following dialog box. This dialog box appears when the optional Fieldbus slave board is not installed.

[System Configuration]-[Controller]-[Inputs / Outputs]-[Fieldbus Slave]-[General]




Select any of “Disable”, “Modbus RTU”, or “Modbus TCP” from the pull-down menu.



Modbus does not function if the Fieldbus slave board is installed while “Modbus RTU” or “Modbus TCP” is selected. However, setting will be held.

(2) Modbus RTU detailed settings

If “Modbus RTU” is selected for the Fieldbus type, the detailed dialog box to enable Modbus RTU will be displayed. Set each item.



[Port]

Select the serial port number to be used.

Other settings such as the baud rate are done in the RS-232C configuration dialog box (other menu).



- If unused port number is selected, a controller error occurs after rebooting the Controller.
- To change the settings of the selected port such as a baud rate, disable Modbus in advance. Settings cannot be changed if the port is set to Modbus.

[Idle time]

Set the idle time to be added to the sending frame specified by the Modbus RTU protocol. By the protocol specification, the time for 3.5 characters is defined before and after the sending frame.

The idle time can be set in units of 1 ms. If “0” is specified for the setting value, the time for 3.5 characters will be set.

Set this item if the connected equipment cannot receive a response with the time for 3.5 characters.

[Slave address]

For the Modbus RTU slaves, the slave address set to the transmission frame is checked and the request for that address is only processed.


Set the desired address.



Be careful not to conflict with other equipment.

(3) Modbus TCP detailed settings

If “Modbus TCP” is selected for the [Fieldbus Type], the dialog box to enable Modbus TCP will be displayed. Set each item.



[Port]

Select the port number to be used. Default is “502”.



Set the port number not to conflict with other system.

12. Remote Control

By using Input/Output, Ethernet (TCP/IP), and RS-232C, the controller can control manipulators from an external device. The external device can execute several commands, including Motor On/Off, Start, Pause, Continue, and Stop.

For details on extended function of the remote I/O, refer to *EPSON RC+ 7.0 Remote Control Reference manual*.

12.1 Remote I/O

There are three basic steps required for remote control configuration:

1. Configure Remote Control inputs and outputs using the [Remote Control] tab on the [Setup]-[System Configuration]-[Remote Control] page.
Nothing is initially assigned to remote functions.
2. Set the control device to remote on the [Setup]-[System Configuration]-[Configuration] page.
To enable external remote inputs, assign the remote functions and also set the control device to remote. When control device setting is remote, the controller is only controllable from the remote device.

Remote control function can be used in the following systems.

Example: Control the robot from a PLC

Use remote control to control the robot (controller) from a PLC.

When using a PLC, you will need to be familiar with the handshake required to use remote inputs. See details below.

Example: Control the robot using a push button box with buttons and lights

The lights are connected to remote control outputs on the controller to indicate status, such as AutoMode, MotorOn, Error, etc. The buttons are connected to remote inputs to control motor power and start programs.

For details of each I/O connection, refer to the following manuals:


Robot Controller Setup & Operation	<i>I/O Connector</i>
	<i>I/O Remote Settings</i>
	<i>Expansion I/O Board</i>

Robot Controller Option Fieldbus I/O

12.1.1 Remote Control Input Output Configuration

The following is the procedure to assign the remote control functions to the I/O system.

1. Select [System Configuration] from the [Setup] menu and select the [Remote Control Inputs] or [Remote Control Outputs] page.
2. For each input or output you want to use for remote control, click on the Input # or Output # cell for the desired signal, then click the dropdown arrow and select a bit number in the list.
3. Click <OK> to save the new settings.




For details using this dialog, refer to 5.12.2 [System Configuration] Command (Setup Menu).

12.1.2 Control Device Configuration

The following is the procedure to set the control device to “Remote I/O”.

1. Select [System Configuration] from the [Setup] menu, and click on [SPEL Controller Board]-[Configuration] in the tree on the left.
Select “Remote” in the [Control Device] box.
2. Click <Apply> to save the new setting and the click <Close>.



For details on using this dialog, refer to 5.12.2 [System Configuration] Command (Setup Menu) – [Setup]-[System Configuration]-[Controller]-[Configuration].

12.1.3 Auto Mode with Remote Control

To run in auto cycle with remote control

1. The host device (e.g. PLC) should wait for the AutoMode and Ready remote output to turn on before issuing remote commands.
2. Now the remote input commands will be accepted.

To monitor remote operation from the EPSON RC+ 7.0 Operator Window

1. Set the EPSON RC+ 7.0 Start Up Mode to “Auto”.
For details, refer to 4.2.3 *Start Mode*.
2. The PC should also be configured to automatically log into Windows and start EPSON RC+ 7.0 at Windows start. Refer to 4.2.7 *Auto Start*.

12.1.4 Teach Mode with Remote Control

When using a remote control with Teach Mode ON, no remote input commands can be used. Remote status outputs will still operate.



- Remote status outputs (such as MotorOn, Home, etc.) will operate when Teach Mode is ON, even when the enable switch (dead man's switch) is disengaged. Therefore, DO NOT use remote status outputs to drive any devices that cause motion or any other safety hazard.

You can monitor teach mode status using the TeachMode remote output.

12.1.5 Debugging Remote Control

You can debug programs using Remote Control from the EPSON RC+ 7.0 development environment.

To run programs by remote control for debugging:

1. Create a program (in the same manner as usual).
2. Open the Run Window and click Enable Remote I/O.
3. Now the remote commands will be accepted.

You can set breakpoints and print messages to the Run window.



If you cannot wire the I/O, use virtual I/O mode for debugging. Remote function is also available when virtual I/O is enabled.

12.1.6 Remote Inputs

Remote inputs are used to control the Manipulators and start programs. Certain conditions must be met before inputs are enabled, as shown in the table below.

To accept external remote inputs, assign the remote function and set remote to the control device. When external remote input is available, “AutoMode output” turns ON.

Except “SelProg”, the signals execute each function when the signal starts in input acceptance condition. The function executes automatically. Therefore, no special programming is needed.



When an error occurs, you must execute a “Reset” to clear the error condition before any other remote input commands can be executed. Use the “Error output” and “Reset input” to monitor the error status and clear error conditions from the remote device.

Name	Default	Description	Input Acceptance Condition (*1)
Start	0	Executes function selected at SelProg. (*2)	Ready output ON Error output OFF EStopOn output OFF SafeguardOn output OFF Pause input OFF Stop input OFF
SelProg1	1	Specifies the executing Main function number. (*2)	
SelProg2	2		
SelProg4	3		
SelProg8	Not Set		
SelProg16	Not Set		
SelProg32	Not Set		
Stop	4	All tasks and commands are stopped.	
Pause	5	All tasks are paused. (*3)	Running output ON
Continue	6	Continues the paused task.	Paused output ON Pause input OFF Stop input OFF
Reset	7	Resets emergency stop and error. (*4)	Ready output ON
Shutdown	Not Set	Terminates the system	
ForcePowerLow (*6)	Not Set	Operates as the forced low power function. The robot is operated in the low power mode. Power High control from the command is not accepted. Executes the following according to the controller preferences. Stops or temporarily stops all the tasks and commands. (*12)	Any time This input is acceptable even AutoMode output is OFF.
SelRobot	Not Set	Changes the output condition of MotorsOn, AtHome, PowerHigh, and MCalReqd. (*9)	
SelRobot1 SelRobot2 SelRobot4 SelRobot8 SelRobot16	Not Set	Specify the number of robot which executes a command. (*5)	
SetMotorOn	Not Set	Turn ON robot motors. (*5) (*6)	Ready output ON EStopOn output OFF SafeguardOn output OFF SetMotorsOff input OFF

Name	Default	Description	Input Acceptance Condition (*1)
SetMotorOff	Not Set	Turn OFF robot motors. (*5)	Ready output ON
SetPowerHigh	Not Set	Set the robot power mode to High (*5)	Ready output ON EStopOn output OFF SafeguardOn output OFF SetPowerLow input OFF
SetPowerLow	Not Set	Set the robot power mode to Low. (*5)	Ready output ON
Home	Not Set	Move the Robot Arm to the home position defined by the user.	Ready output ON Error output OFF EStopOn output OFF SafeguardOn output OFF MotorsOn output ON Pause input OFF Stop input OFF
MCal	Not Set	Execute MCal (*5) (*7)	Ready output ON Error output OFF EStopOn output OFF SafeguardOn output OFF MotorsOn output ON Pause input OFF Stop input OFF
Recover	Not Set	After the safeguard is closed, recover to the position where the safeguard was open.	Paused output ON Error output OFF EStopOn output OFF SafeguardOn output OFF RecoverReqd output ON Pause input OFF Stop input OFF
ExtCmdSet	Not Set	Commands for an extended remote IO. For details, refer to the following manual. <i>Remote Control Reference</i> 4. Remote I/O to Be Used	
ExtRespGet	Not Set		
ExtCmdReset	Not Set		
ResetAlarm	Not Set	Cancel the alarm (*11)	
SelAlarm1 SelAlarm2 SelAlarm4 SelAlarm8	Not Set	Specify the alarm number to cancel (*10)	
ALIVE	Not Set	Input signal for alive monitoring of the controller. Same signal as the input will be output to ALIVE output. The master equipment can perform alive monitoring of the controller by switching the input periodically and checking the output signal.	
ExtCmd_0-15	Not Set	Commands for an extended remote IO. For details, refer to the following manual. <i>Remote Control Reference</i> 4. Remote I/O to Be Used	
ExtCmd_16-31	Not Set		
ExtCmd_32-47	Not Set		
ExtCmd_48-63	Not Set		
ExtCmd_64-79	Not Set		
ExtCmd_80-95	Not Set		
ExtCmd_96-111	Not Set		
ExtCmd_112-127	Not Set		

12. Remote Control

(*1) “AutoMode output” ON is omitted from the table. This is an input acceptance condition for all functions.

(*2) “Start input” executes Function specified by the following six bits: SelProg 1, 2, 4, 8, 16, and 32.

Function	SelProg1	SelProg2	SelProg4	SelProg8	SelProg16	SelProg32
Main	0	0	0	0	0	0
Main1	1	0	0	0	0	0
Main2	0	1	0	0	0	0
Main3	1	1	0	0	0	0
⋮						
Main60	0	0	1	1	1	1
Main61	1	0	1	1	1	1
Main62	0	1	1	1	1	1
Main63	1	1	1	1	1	1

0=OFF, 1=ON

(*3) “NoPause task” and “NoEmgAbort task” do not pause.

For details, refer to *EPSON RC+ 7.0 Online Help* or *Pause* in *SPEL+ Language Reference*.

(*4) Turns OFF the I/O output and initializes the robot parameter.

For details, refer to *EPSON RC+ 7.0 Online Help* or *Reset* in *SPEL+ Language Reference*.

(*5) The values specified by “SelRobot1, 2, 4, 8, and 16” correspond to the robot numbers.

Robot number	SelRobot1	SelRobot2	SelRobot4	SelRobot8	SelRobot16
0 (All)	0	0	0	0	0
1	1	0	0	0	0
2	0	1	0	0	0
3	1	1	0	0	0
⋮					
13	1	0	1	1	0
14	0	1	1	1	0
15	1	1	1	1	0
16	0	0	0	0	1

0=OFF, 1=ON

(*6) Initializes the robot parameter.

For details, refer to *EPSON RC+ 7.0 Online Help* or *Motor* in *SPEL+ Language Reference*.

(*7) For details, refer to *EPSON RC+ 7.0 Online Help* or *MCal* in *SPEL+ Language Reference*.

(*8) This is for experienced users only. Make sure that you fully understand the input specification before using.

CmdRunning output and CmdError output will not change for this input.

“NoEmgAbort task” will not stop by this input.

When the input changes from ON to OFF, all tasks and commands will stop.

(*9) This function changes the output condition of MotorsOn, AtHome, PowerHigh, and MCalReqd.

By setting this signal with the condition selected using SelRobot1 - SelRobot16, you can switch the output condition.

Once you select the condition, it will be kept until you change it or turn off / restart the Controller. All manipulators are selected as default.

(*10) The values specified by “SelAlarm1, 2, 4, and 8” correspond to the alarm numbers.

Alarm #	Target	SelAlarm1	SelAlarm2	SelAlarm4	SelAlarm8
1	Controller battery	1	0	0	0
2	Battery of the robot connected to CU	0	1	0	0
3	Grease of the robot connected to CU	1	1	0	0
4	Battery of the robot connected to DU1	0	0	1	0
5	Grease of the robot connected to DU1	1	0	1	0
6	Battery of the robot connected to DU2	0	1	1	0
7	Grease of the robot connected to DU2	1	1	1	0
8	Battery of the robot connected to DU3	0	0	0	1
9	Grease of the robot connected to DU3	1	0	0	1

0=OFF, 1=ON

The following parts are subject to grease up.

6-axis robot: Bevel gear on the Joint #6

SCARA, RS series: Ball screw spline unit on the Joint # 3

(*11) The specified alarm can be canceled by selecting the conditions using SelAlarm1-SelAlarm8 and setting this signal.

(*12) Operation of all tasks and commands, power mode of the robot, and PowerHigh command are executed by the setting value of the controller preferences.

Preferences (1): “Motor power low when ForcePowerLow signal OFF”

Preferences (2): “ForcePowerLow signal change pauses all tasks”

For details of the controller preferences, refer to *[Setup]-[System Configuration]-[Controller]-[Preferences]* in 5.12.2 *[System Configuration] Command (Setup Menu)*.

Preferences (1)	Preferences (2)	ForcePowerLow	All tasks and commands	Power mode	PowerHigh
0	0	1→0	Stop	Low only	Accept
0	0	0→1	Stop	Low only	Not accept
0	1	1→0	Continue	High/Low	Accept
0	1	0→1	Temp. stop	Low only	Not accept
1	0	1→0	Stop	Low only	Not accept
1	0	0→1	Stop	Low only	Accept
1	1	1→0	Temp. stop	Low only	Not accept
1	1	0→1	Continue	High/Low	Accept

12.1.7 Remote Outputs

Remote outputs provide status for the Manipulator(s) and Controller.

Remote outputs provide the assigned function used with any control device. The outputs execute automatically. Therefore, no special programming is needed.

Name	Default	Description
Ready	0	Turns ON when the controller startup completes and no task is running.
Running	1	Turns ON when task is running. However, turns OFF when “Paused output” is ON.
Paused	2	Turns ON when pause task exists.
Error	3	Turns ON when an error occurs. Use “Reset input” to recover from the error.
EStopOn	4	Turns ON at Emergency Stop.
SafeguardOn	5	Turns ON when the safeguard is open.
SError	6	Turns ON when critical error occurs. When a critical error occurs, “Reset input” does not function. Reboot the controller to recover.
Warning	7	Turns ON when warning occurs. The task runs as normal with the warning. However, be sure to eliminate the cause of the warning as soon as possible.
MotorsOn	Not set	Turns ON when the robot motor is ON. (*5)
AtHome	Not set	Turns ON when the robot is in the home position. (*5)
PowerHigh	Not set	Turns ON when the robot’s power mode is High. (*5)
MCalReqd	Not set	Turns ON when the robot hasn’t executed MCal. (*5)
RecoverReqd	Not set	Turns ON when at least one robot is waiting for Recover after the safeguard is closed.
RecoverInCycle	Not set	Turns ON when at least one robot is executing Recover.
WaitingRC	Not set	Turns ON when the Controller is waiting to connect with RC+.
CmdRunning	Not set	Turns ON when an input command is executing.
CmdError	Not set	Turns ON when an input command cannot be accepted.
CurrProg1 CurrProg2 CurrProg4 CurrProg8 CurrProg16 CurrProg32	Not set	Indicates the running or the last main function number (*1)
AutoMode	Not set	Turns ON in remote input acceptable status. (*2)
TeachMode	Not set	Turns ON in TEACH mode.
TestMode	Not set	Turns ON in TEST mode.
EnableOn	Not set	Turns ON when the enable switch is ON.
ErrorCode1 ⋮ ErrorCode8192	Not set	Indicates the error number.
InsideBox1 ⋮ InsideBox15	Not set	Turns ON when the robot is in the approach check area. (*3)
InsidePlane1 ⋮ InsidePlane15	Not set	Turns ON when a robot is on the approach plane area. (*4)
Alarm	Not set	Turns ON when any of the alarms is occurring. (*9)
Alarm1	Not set	Turns ON when a battery alarm of the controller is occurring.

Name	Default	Description
Alarm2	Not set	Turns ON when a battery alarm of the robot connected to CU is occurring.
Alarm3	Not set	Turns ON when a grease alarm of the robot connected to CU is occurring. (*10)
Alarm4	Not set	Turns ON when a battery alarm of the robot connected to DU1 is occurring.
Alarm5	Not set	Turns ON when a grease alarm of the robot connected to DU1 is occurring. (*10)
Alarm6	Not set	Turns ON when a battery alarm of the robot connected to DU2 is occurring.
Alarm7	Not set	Turns ON when a grease alarm of the robot connected to DU2 is occurring. (*10)
Alarm8	Not set	Turns ON when a battery alarm of the robot connected to DU3 is occurring.
Alarm9	Not set	Turns ON when a grease alarm of the robot connected to DU3 is occurring. (*10)
PositionX	Not set	Outputs current X coordinate in the World coordinate system (*6) (*7)
PositionY	Not set	Outputs current Y coordinate in the World coordinate system (*6) (*7)
PositionZ	Not set	Outputs current Z coordinate in the World coordinate system (*6) (*7)
PositionU	Not set	Outputs current U coordinate in the World coordinate system (*6) (*7)
PositionV	Not set	Outputs current V coordinate in the World coordinate system (*6) (*7)
PositionW	Not set	Outputs current W coordinate in the World coordinate system (*6) (*7)
Torque1	Not set	Outputs the current torque value of Joint #1 (*6) (*7)
Torque2	Not set	Outputs the current torque value of Joint #2 (*6) (*7)
Torque3	Not set	Outputs the current torque value of Joint #3 (*6) (*7)
Torque4	Not set	Outputs the current torque value of Joint #4 (*6) (*7)
Torque5	Not set	Outputs the current torque value of Joint #5 (*6) (*7)
Torque6	Not set	Outputs the current torque value of Joint #6 (*6) (*7)
CPU	Not set	Outputs the CPU load factor of the user program (*8)
ESTOP	Not set	Outputs how many times emergency stops have been executed.
ALIVE	Not set	Output signal for alive monitoring of the controller. The signal input by ALIVE input will be output. The master equipment can perform alive monitoring of the controller by switching the input periodically and checking the output signal.
ForceControlOn	Not set	Turns ON when the robot is executing the force control function. (*5)
ExtCmdGet	Not set	Commands for an extended remote IO. For details, refer to the following manual. <i>Remote Control Reference</i> <i>4. Remote I/O to Be Used</i>
ExtRespSet	Not set	
ExtCmdResult	Not set	
ExtError	Not set	
ExtResp 0-15	Not set	
ExtResp 16-31	Not set	
ExtResp 32-47	Not set	
ExtResp 48-63	Not set	
ExtResp 64-79	Not set	
ExtResp 80-95	Not set	

12. Remote Control

Name	Default	Description
ExtResp_96-111	Not set	Commands for an extended remote IO. For details, refer to the following manual.
ExtResp_112-127	Not set	<i>Remote Control Reference</i> <i>4. Remote I/O to Be Used</i>

(*1) Outputs the current or the last function number of CurrProg1, 2, 4, 8, 16, or 32.

Function name	CurrProg1	CurrProg2	CurrProg4	CurrProg8	CurrProg16	CurrProg32
Main	0	0	0	0	0	0
Main1	1	0	0	0	0	0
Main2	0	1	0	0	0	0
Main3	1	1	0	0	0	0
⋮						
Main60	0	0	1	1	1	1
Main61	1	0	1	1	1	1
Main62	0	1	1	1	1	1
Main63	1	1	1	1	1	1

0=OFF, 1=ON

(*2) Remote function is available in the followings conditions.

- The setting is Auto mode and the control device is remote.
- The setting is Program mode and Remote I/O is enabled.

(*3) For details, refer to EPSON RC+ 7.0 *Online Help* or *Box* in *SPEL⁺ Language Reference*.

(*4) For details, refer to EPSON RC+ 7.0 *Online Help* or *Plane* in *SPEL⁺ Language Reference*.

(*5) Manipulator status is output as follows, according to the condition selected in SelRobot.

Wait at least 40 ms before inputting the signal after changing the condition in SelRobot.

Name	(SelRobot1- SelRobot16) condition when inputting SelRobot	
	0: All robots are selected	1 - 16: Particular robot number is selected
MotorsOn	Turns ON when at least one motor is ON.	Turns ON when the motor of the selected robot is ON.
AtHome	Turns ON when all robots are in the home position.	Turns ON when the selected robot is in the home position.
PowerHigh	Turns ON when at least one robot's power mode is High.	Turns ON when the selected robot's power mode is High.
MCalReqd	Turns ON when at least one robot hasn't executed MCal.	Turns ON when the selected robot hasn't executed MCal.
ForceControlOn	Turns ON when at least one robot is executing the force control function.	Turns ON when the selected robot is executing the force control function.

(*6) Outputs information of the selected robot when SelRobot1, SelRobot2, SelRobot4, SelRobot8, and SelRobot16 are set. If not, information of Robot 1 will be output.

(*7) Outputs information in Real format.

(*8) Outputs the total load factor of the user created tasks. For details on the CPU load factor, refer to the task manager.

(*9) The signal turns on when the alarm occurs either in the controller alarm information or the robot alarm information.

(*10) The following parts are subject to grease up.

6-axis robot: Bevel gear on the Joint #6

SCARA, RS series: Ball screw spline unit on the Joint # 3

12.1.8 Remote Input Handshake Timing

The following charts indicate the timing sequences for the primary operations of the Controller.


The indicated time lapses (time durations) should be referred to only as reference values since the actual timing values vary depending on some factors such as the numbers of manipulators and running tasks. Check carefully and refer to the following charts for the timing interrelation when you enter an input signal.

During system design, make sure that you actuate only one remote input operation at a time, otherwise an error will occur.

The pulse width of an input signal must be 25 or more milliseconds to be detected.

[Unit: msec]


Timing Diagram for Operation Execution Sequence



*1 The motion of the CmdRunnig can be different from this figure according to the condition.


*2 Refer to only as reference value for a robot. It can be different according to the number of robots.

Timing Diagram for Program Execution Sequence



- *1 Differs according to the setting condition of Quick Pause and the program running condition when the PAUSE is input.
- *2 Shutdown input can be accepted when the Ready output is ON.

Timing Diagram for Safety Door Input Sequence



12.2 Remote Ethernet

Remote Ethernet makes it possible to control the robot and controller from external equipment by sending the remote commands through Ethernet (TCP/IP).



NOTE From the following firmware version password authentication is required when connecting Controllers and PCs to a global accessible network.

F/W : Ver.7.4.8.x (except T series Manipulator / VT series Manipulator)
Ver.7.4.58.x (T series Manipulator / VT series Manipulator)

For details, refer to the following section.


1.9 Security for Controller Ethernet Connection

1.10 Security for Compact Vision CV2-A Ethernet Connection

12.2.1 Remote Ethernet Configuration

To set the remote Ethernet functions valid, follow the procedures below to configure the parameter.

- (1) Select [System Configuration] from the [Setup] menu and select the [Remote Control]-[Ethernet] page.
- (2) Configure the necessary items for the remote Ethernet control.
- (3) Click <Apply> to save the new setting and click <Close>.




For the details of the dialog setting, refer to the section 5.12.2 [System Configuration] Command (Setup menu)–[Setup]–[System Configuration]–[Remote].

Following setting for the control device is not necessary when you select “Use only for monitoring”, and only acquire the value using the Remote Ethernet control.

12.2.2 Control Device Configuration

Set the control device to “Remote Ethernet” by the following procedure.

- (1) Select [System Configuration] from the [Setup] menu and select [Controller Configuration] page.
Select “Remote Ethernet” in the [Controller device] box.
- (2) Click <Apply> button to save the new settings, click <Close>.



For the details of the dialog setting, refer to the section 5.12.2 [System Configuration] Command (Setup menu) – [Setup]-[System Configuration]-[Setup].

12.2.3 Remote Ethernet Control Execution

Set the remote control available by the following procedure.

- (1) Connect from client equipment to the specified port in the Remote Ethernet of the Controller.
- (2) Specify the password set in the Remote Ethernet to the parameter and send the Login command.
- (3) Client equipment has to wait until Auto (GetStatus command response) is ON, before execution of remote command.
- (4) Now remote command will be accepted.
Each command executes the function the input acceptance condition.

12.2.4 Debugging Remote Ethernet Control

Program debug from EPSON RC+ 7.0 development environment is capable as follows.

- (1) Build a program as usual.
- (2) Open the Run window and click the <Ethernet Enable> button.

When you only acquire the value using the Remote Ethernet control, the <Ethernet Enable> button is not displayed. Click the <Start> button of the device specified as the control device.

- (3) Now remote command will be accepted.


Breakpoint setting and output to the Run window is available.



NOTE

If not Login within 5 minutes from external equipment, the connection will be cut down automatically. After Login, if no command is send within the timeout duration of the remote Ethernet, connection will be cut down. In this case, establish the connection again.

If error occurs execute the Reset command to clear the error condition before executing the operation command. To clear the error condition from external equipment by monitoring, use the “GetStatus” and “Reset” command.

 CAUTION	<p>■ If you set “0” in the [Timeout] box, time out duration is infinite. In this case, the task continues to execute even without the communication from client. This means the robot may keep moving and cause unexpected damage. Ensure the ways other than the communication to stop the task.</p>
---	---

12.2.5 Remote Ethernet Command

Format: \$ remote command {, parameter....} terminator

Note: Remote command with parameters uses (,) (comma) to separate \$ remote command and parameters. Do not put a space before and after the comma separated character and the parameter.

Remote command	Parameter	Contents	Input acceptance condition (*1)
Login	Password	Start the Controller Remote Ethernet function Authentication by password Execute Login correctly, commands execution is enabled until Logout	Available any time (*2)
Logout		Exit Controller Remote Ethernet function After Logout, execute the Login command to start remote Ethernet function. Logout during task execution causes an error.	Available any time (*2)
Start	Function No.	Execute the function of specified number (*3)(*11)	Auto ON Ready ON Error OFF EStop OFF Safeguard ON
Stop		Stop all tasks and commands	Auto ON
Pause		Pause all tasks (*4)	Auto ON Running ON
Continue		Continue paused tasks	Auto ON Paused ON
Reset		Clear emergency stop and error (*5)	Auto ON Ready ON
SetMotorsOn	Robot number	Turn ON the robot motor (*6)(*7)	Auto ON Ready ON EStop OFF Safeguard OFF
SetMotorsOff	Robot number	Turn OFF the robot motor (*7)	Auto ON Ready ON
SetCurRobot	Robot number	Select the manipulator	Auto ON Ready ON
GetCurRobot		Acquires the current manipulator number	Available any time (*2)
Home	Robot number	Move the arm to home position defined by user	Auto ON Ready ON Error OFF EStop OFF Safeguard OFF

Remote command	Parameter	Contents	Input acceptance condition (*1)
GetIO	I/O bit No.	Acquire the specified I/O bit	Available any time (*2)
SetIO	I/O bit No. & value	Set the I/O specified bit 1: Turn ON the bit 0: Turn OFF the bit	Ready ON
GetIOByte	I/O port No.	Acquire the specified I/O port (8 bit)	Available any time (*1)
SetIOByte	I/O port No. & value	Set the I/O specified port (8 bit)	Ready ON
GetIOWord	I/O word port No.	Acquire the specified I/O word port (16 bit)	Available any time (*2)
SetIOWord	I/O word port No. & value	Set the I/O specified word port (8 bit)	Auto ON Ready ON
GetMemIO	Memory I/O bit No.	Acquire the specified memory I/O bit	Available any time (*2)
SetMemIO	Memory I/O bit No. & value	Set the specified memory I/O bit 1: Turn ON the bit 0: Turn OFF the bit	Auto ON Ready ON
GetMemIOByte	Memory I/O port No.	Acquire the specified memory I/O port	Available any time (*2)
SetMemIOByte	Memory I/O port No. & value	Set the specified memory I/O port (8 bit)	Auto ON Ready ON
GetMemIOWord	Memory I/O word port No.	Acquire the specified memory I/O word port (16 bit)	Available any time (*2)
SetMemIOWord	Memory I/O word port No. & value	Set the specified memory I/O word port (16 bit)	Auto ON Ready ON
GetVariable	Parameter name {, type}	Acquire the value of backup (Global Preserve) parameter (*8)	Available any time (*2)
	[Parameter name] (Array element), [Parameter name type], [Number to acquire]	Acquire the value of backup (Global Preserve) array parameter (*9)	
SetVariable	Parameter name & value {, type}	Set the value in the backup (Global Preserve) parameter (*8)	Auto ON Ready ON
GetStatus		Acquire the Controller state	Available any time (*1)
Execute	Command string	Execute the command (*10) (*11)	Auto ON Ready ON Error OFF EStop OFF Safeguard OFF
Abort		Abort the command execution	Auto ON
GetAlm		Acquire the alarm state (*12)	Available any time (*2)
ResetAlm	Alarm number	Reset the alarm of the specified alarm number (*12)	Auto ON Ready ON

12. Remote Control

- (*1) The Controller state bit from GetStatus.
- (*2) “Available any time” is applicable if the following conditions are met.
When “Remote Ethernet” is set as the control device, or,
“Remote Ethernet” is not set as the control device, but set to be used for monitoring.
- (*3) Execute the function specified in the Main[Function No.].

Function Name	Function No.
Main	0
Main1	1
Main2	2
Main3	3
Main4	4
Main5	5
Main6	6
Main7	7
:	:
Main63	63

- (*4) Pause command is not available for “NoPause task” and “NoEmgAbort task”.
For the details, refer to the help or the section “*Pause*” in the EPSON RC+7.0 Language reference manual.
- (*5) I/O output will be turned OFF and the robot parameter will be initialized.
For the details, refer to the help or the section “*Reset*” in the EPSON RC+7.0 Language reference manual.
- (*6) The robot parameter will be initialized.
For the details, refer to the help or the section “*Motor*” in the EPSON RC+7.0 Language reference manual.
- (*7) When “0” is specified for the manipulator number, all the manipulator will be operated
If you wish to operate particular manipulator, specify the manipulator number (1 to 16) of the target manipulators.
- (*8) Parameter type means {Boolean | Byte | Double | Integer | Long | Real | String | Short | UByte | UShort | Int32 | UInt32 | Int64 | UInt64}.
- Type specified: for the backup parameters when the parameter name and type are same.
Type not specified: for the backup parameters when the parameter names are same.
- (*9) For the array element, specify an element you acquire as the following:
You need to specify an element if when acquiring from the head of the array.

1D array	Parameter name (0)	Acquire from the head.
	Parameter name (Element number)	Acquire from the specified element number.
2D array	Parameter name (0,0)	Acquire from the head.
	Parameter name (Element number 1, 2)	Acquire from the specified element number.
3D array	Parameter name (0,0,0)	Acquire from the head.
	Parameter name (Element number 1, 2, 3)	Acquire from the specified element number.

You cannot omit the parameter type and number to acquire.

You cannot specify a string for the parameter type.

Available number to acquire is up to 100. If you specify a number over the number of array elements, you have an error.

e.g.) "\$GetVariable,gby2(3,0),Byte,3"

It acquires values of gby2(3,0), gby2(3,1), gby2(3,2) of Byte type 2D array parameter gby2.

- (*10) Specify the command and parameters in the double quotation marks.

Command string to be executed and execution result string are restricted to 4060 bytes.

Robot motion command will be executed to the selected manipulator. Check which robot is selected by using GetCurRobot before command execution.

Following commands are available while Execute is running.

Commands available while Execute is running


Remote Command
Abort
GetStatus
SetIO
SetIOByte
SetIOWord
SetMemIO
SetMemIOByte
SetMemIOWord

When the commands specified in (SetIO, SetIOByte, SetIOWord, SetMemIO, SetMemIOByte, SetMemIOWord) are the same and executed at the same time, the command executed later will result in error. Make sure to check the execution result by using GetStatus after the execution of Execute command and output command which the Execute command is being executed.

- (*11) To execute commands of PCDaemon function, be sure to execute while the EPSON RC+ 7.0 is connected. If the EPSON RC+ 7.0 is not connected, command execution will result in error.
- (*12) For details of the alarms, refer to the following manuals.
Robot Controller RC700 / RC700-A Maintenance 6. Alarm
- (*13) "Command string" parameter of Execute command encloses in (" ") (double quotation marks). If the parameter includes (" "), refer to the following execution example. In SPEL+ language, Chr\$(34) is used for (" ") (double quotation marks). Refer to *Print# in SPEL+ Language Reference*.

Execution Example of TeraTerm:

(New-line Receive: AUTO, Transmit: CR+LF, Local echo: ON)



```

192.168.0.1 - Tera Term VT
File Edit Setup Control Window Help
$login
#login,0
$getstatus
#getstatus,00100000001,0000
$start,0
#start,0
$execute,"print "----""
#execute,"----"
$getstatus
#getstatus,00100000001,0000
$logout
#logout,0

```

12.2.6 Monitoring command

When the Remote Ethernet control is not set as the control device but set to be used for monitoring, following commands are only available to be executed.

Remote Command
Login
Logout
GetIO
GetIOByte
GetIOWord
GetMemIO
GetMemIOByte
GetMemIOWord
GetVariable
GetStatus
GetCurRobot
GetAlm

12.2.7 Response

When the Controller receives the command correctly, the response in the following format is shown in the executing command.

Command	Format
Remote command that acquire the value Except GetIO, GetVariable, and GetStatus	#[Remote command],[0] terminator
GetIO	#GetIO,[0 1] terminator *1
GetMemIO	#GetMemIO,[0 1] terminator *1
GetIOByte	#GetIOByte,[Hex string (00 to FF) of Byte (8Bit)] terminator
GetMemIOByte	#GetMemIOByte,[Hex string (00 to FF) of Byte (8Bit)] terminator
GetIOWord	#GetIOWord,[Hex string (0000 to FFFF) of Word (16Bit)] terminator
GetIOMemWord	#GetMemIOWord,[Hex string (0000 to FFFF) of Word (16Bit)] terminator
GetVariable	# GetVariable,[Parameter value] terminator
GetVariable (in case of array)	# GetVariable,[Parameter value 1],[Parameter value 2],...,terminator *4
GetStatus	#GetStatus,[Status],[Error, Warning code] tenimator Example) #GetStatus, <u>aaaaaaaaaaaa</u> , <u>bbbb</u> *2 *3
Execute	If the value is returned as a result of command execution #Execute,"[Execution result]" terminator
GetAlm	# GetAlm,[number of alarms],[alarm number] ..terminator e.g.) When no alarm is occurring # GetAlm,0 terminator e.g.) When Alarm 1 and 9 are occurring # GetAlm,2,1,9 terminator

*1 [0 | 1] I/O bit ON: 1/ OFF: 0

*2 Status

In the example above, 11 digits “aaaaaaaaaaaa” is for the following 11 flags.

Test/Teach/Auto/Warning/SError/Safeguard/EStop/Error/Paused/Running/Ready

ON: 1/ OFF: 0

If Ready and Auto are ON, it is “00100000001”.

*3 Error / Warning code

It is indicated in 4 digits. If there is no error and warning, it is 0000.

e.g.) 1 : #GetStatus,0100000001,0000

The bits for Auto and Ready are ON (1).

This means that AutoMode is ON and be in Ready state. You can execute the command.

e.g.)2: #GetStatus,0110000010,0517

This means the warning occurs during the operation. Take appropriate action for the warning code. (In this case, warning code is 0517)

Flag	Contents
Test	Turn ON in the TEST mode
Teach	Turn ON in the TEACH mode
Auto	Turn ON in the remote input acceptance condition
Warning	Turn ON in the warning condition Task can be executed as usual even in a warning condition. However, take action for the warnings as soon as possible.
SError	Turn ON in the serious error condition When a serious error occurs, reboot the Controller to recover from the error condition. "Reset input" is not available.
Safeguard	Turn ON with safety door open
EStop	Turn ON in the emergency condition
Error	Turn ON in the error condition Use "Reset input" to recover from the error condition.
Paused	Turn ON with paused task
Running	Turn ON with task executing Turn OFF when "Paused output" is ON
Ready	Turn ON with the Controller completed the startup and no task executing

*4 It returns values of specified number in the Number to acquire.

Error response


When the Controller cannot receive the remote command correctly, the error response is shown in the following format.

Format: ![Remote command],[Error code] terminator

Error code	Contents
10	Remote command does not begin with \$
11	Remote command is wrong Login is not executed
12	Remote command format is wrong
13	Login command password is wrong
14	Specified number to acquire is out of range (1 or more and 100 or less) Number to acquire is omitted Specified a string parameter
15	Parameter is not existed Dimension of parameter is wrong Element out of range is called
19	Request time out
20	Controller is not ready
21	Cannot execute since the Execute is running
98	Password is required for Login when using the global IP address.
99	System error Communication error

12.2.8 Response timing of Remote Ethernet control

Communication sequence




12.3 Remote RS232

Remote RS232 makes it possible to control the robot and controller from external equipment by sending the remote commands through RS-232C.

12.3.1 Remote RS232 setting

To set the remote RS232 functions valid, follow the procedures below to configure the remote RS232.

- (1) Select [Controller] from the [Setup] menu-[System Configuration] and display the [System Configuration] dialog box. Select [RS232] from the tree structure-[Controller]-[Remote].
- (2) Configure the necessary items for the remote RS232 control.
- (3) Click <Apply> to save the new setting and click <Close>.



For the details of the dialog setting, refer to the section 5.12.2 [System Configuration] (Setup menu) – [Setup]-[System Configuration]-[Remote].


When you only acquire the value using the Remote RS232 control, the RS232 Enable button is not displayed. Click the Start button of the device specified as the control device.

Following setting for the control device is not necessary when you select “Use only for monitoring”, and only acquire the value using the remote RS232 control.

12.3.2 Control device setting

Set the control device to “Remote RS232” by the following procedure.

- (1) Select Controller from the [Setup] menu and select [System Configuration] to display the [System Configuration] dialog box.
Select “Remote RS232” in the [Control Device] box.
- (2) Click <Apply> to save the new settings, and then click <Close>.



For the details of the dialog setting, refer to the section 5.12.2 [System Configuration] (Setup menu) – [Setup]-[System Configuration]-[Controller]-[Configuration].

12.3.3 Execution of remote RS232 control

Set the remote RS232 control available by the following procedure.

- (1) Open RS-232C port that is connected from client equipment to the specified port in the Remote RS232 of the Controller, using the communication parameter specified in the RS-232C port setting.
- (2) Send the remote start command (EOT).
- (3) Specify the password set in the Remote RS232 to the parameter and send the Login command.
- (4) Client equipment has to wait until Auto (GetStatus command response) is ON, before execution of remote command.
- (5) Now remote command will be accepted.
Each command executes the function when the input acceptance condition is satisfied.

12.3.4 Debugging remote RS232 control

Program debug from EPSON RC+ 7.0 development environment is capable as follows.

- (1) Build a program as usual.
- (2) Open the Run window and click the <RS232 Enable> button.

When you only acquire the value using the Remote RS232 control, the <RS232 Enable> button is not displayed. Click the Start button of the device specified as the control device.

- (3) Now remote command will be accepted.

Breakpoint setting and output to the Run window is available.

NOTE



After Login, if no command is send within the timeout duration of the RS-232C, the timeout error will be returned. In this case, re-execute from sending remote start command.

If error occurs, execute the Reset command to clear the error condition before executing the operation command. To clear the error condition from external equipment by monitoring, use the “GetStatus” and “Reset” command.



- If you set “0” in the [Timeout] box, time out duration is infinite. In this case, the task continues to execute even without the communication from client. This means the robot may keep moving and cause unexpected damage. Ensure the ways other than the communication to stop the task.

12.3.5 Remote RS232 Command

Remote start

Start the Remote RS232 function of the Controller.

EOT
1 byte

EOT : &H04(&H is hexadecimal)

Request format

STX	Command	Data	ETX	BCC
1byte	1Byte	Variable	1Byte	1Byte

STX : &H02

ETX : &H03

BCC : Checksum of sent and received data

XOR value from the command to ETX per 1Byte

12. Remote Control

Remote Command	Send command	Data	Description	Input Acceptance Condition (*1)
Login	'L' &H4C	Password	Authentication by password Execute Login correctly, commands execution is enabled until Logout	Available any time (*2)
Logout	'I' &H6C		After Logout, execute the Login command to start remote RS232 function. Logout during task execution causes an error.	Available any time (*2)
Start	'G' &H47	Function No. (1Byte)	Execute the function of specified number (*3)(*11) Example) Execute 'main' &H02&H47&H00&H03&H44	Auto ON Ready ON Error OFF EStop OFF Safeguard ON
Stop	'Q' &H51		Stop all tasks and commands	Auto ON
Pause	'P' &H50		Pause all tasks (*4)	Auto ON Running ON
Continue	'C' &H43		Continue paused tasks	Auto ON Paused ON
Reset	'R' &H52		Clear emergency stop and error (*5)	Auto ON Ready ON
SetMotorsOn	'M' &H4D	Robot number (1Byte)	Turn ON the robot motor (*6)(*7)	Auto ON Ready ON EStop OFF Safeguard OFF
SetMotorsOff	'N' &H4E	Robot number (1Byte)	Turn OFF the robot motor (*7)	Auto ON Ready ON
SetCurRobot	'Y' &H59	Robot number (1Byte)	Select the robot	Auto ON Ready ON
GetCurRobot	'y' &H79		Acquire the current robot number	Available any time (*2)
Home	'H' &H48	Robot number (1Byte)	Move the arm to home position defined by user	Auto ON Ready ON Error OFF EStop OFF Safeguard OFF
GetIO	'i' &H69	I/O bit No (2Byte)	Acquire the specified I/O bit Example) Acquire the I/O bit 1 &H02&H69&H0001&H03&H6B	Available any time (*2)
SetIO	'I' &H49	[I/O bit No.] (2Byte) [value] (1Byte)	Set the I/O specified bit &H01: Turn ON the bit &H00: Turn OFF the bit Example) Turn ON the I/O bit 1 &H02&H49&H0001&H01&H03&H4A	Auto ON Ready ON
GetIOByte	'b' &H62	I/O port No. (1Byte)	Acquire the specified I/O port (8 bit) (*8) Example) Acquire the I/O port 1 &H02&H62&H01&H03&H60	Available any time (*2)

Remote Command	Send command	Data	Description	Input Acceptance Condition (*1)
SetIOByte	'B' &H42	[I/O port No.](1Byte) [value] (1Byte)	Set the I/O specified port (8 bit) (*8) Example) Set &H0F to the I/O port 1 &H02&H42&H01&H0F&H03&H4F	Auto ON Ready ON
GetIOWord	'w' &H77	I/O word port No. (1Byte)	Acquire the specified I/O word port (16 bit) (*8) Example) Acquire the I/O word port 1 &H02&H77&H01&H03&H75	Available any time (*2)
SetIOWord	'W' &H57	[I/O word port No.] (1Byte) [value] (2Byte)	Set the I/O specified word port (16 bit) (*8) Example) Set &H010F to the I/O word port 1 &H02&H57&H01&H010F&H03&H5B	Auto ON Ready ON
GetMemIO	'o' &H6F	Memory I/O bit No. (2Byte)	Acquire the specified memory I/O bit (*8) Example) Acquire memory I/O bit 1 &H02&H6F&H0001&H03&H6D	Available any time (*2)
SetMemIO	'O' &H4F	[Memory I/O bit No.] (2Byte) [value] (1Byte)	Set the I/O specified bit (*8) &H01: Turn ON the bit &H00: Turn OFF the bit Example) Turn ON the memory I/O bit 1 &H02&H4F&H0001&H01&H03&H4C	Auto ON Ready ON
GetMemIOByte	't' &H74	Memory I/O port No. (1Byte)	Acquire the specified memory I/O port (8 bit) (*8) Example) Acquire the memory I/O port 1 &H02&H74&H01&H03&H76	Available any time (*2)
SetMemIOByte	'T' &H54	[Memory I/O port No.] (1Byte) [value] (1Byte)	Set the I/O specified port (8 bit) (*8) Example) Set &H0F to the memory I/O port 1 &H02&H54&H01&H0F&H03&H59	Auto ON Ready ON
GetMemIOWord	'u' &H75	Memory I/O word port No. (1Byte)	Acquire the specified memory I/O word port (16 bit) (*8) Example) Acquire the memory I/O word port 1 &H02&H75&H01&H03&H77	Available any time (*2)
SetMemIOWord	'U' &H55	[Memory I/O word port No.] (1Byte) [value] (1Byte)	Set the I/O specified word port (16 bit) (*8) Example) Set &H010F to the memory I/O word port 1 &H02&H55&H01&H010F&H03&H59	Auto ON Ready ON

12. Remote Control

Remote Command	Send command	Data	Description	Input Acceptance Condition (*1)
GetVariable	'v' &H76	[Parameter name],(&H2C) [type] (1Byte)	Acquire the value of backup (Global Preserve) parameter (*8) Example) Acquire the Global Integer g_Status &H02&H76&H67&H5F&H53&H74&H61&H74&H75&H73&H2C&H03&H03&H56	Available any time (*2)
		[Parameter name] (&H2C) (Array element) (&H2C), [Parameter type] (1Byte), (&H2C) [Number to acquire] (2Byte)	Acquire the value of backup (Global Preserve) array parameter (*9) Example) Acquire all of Global Integer g_intArray(10) &H02&H76&H67&H5F&H69&H6E&H74&H41&H72&H72&H61&H79&H2C &H0000&H2C&H03&H2C&H000A&H03&H42E Example) Acquire 10 elements from elements (3,5,0) of Global Integer g_int3Array(10,10,10) &H02&H76&H67&H5F&H69&H6E&H74&H33&H41&H72&H72&H61&H79&H2C &H0003&H2C&H0005&H2C&H0000&H2C&H03&H2C&H000A&H03&H77	
SetVariable	'V' &H56	[Parameter name], (&H2C) [value] (type size) (&H2C), [type] (1Byte)	Set the value in the backup (Global Preserve) parameter (*8) Example) Set &H0 to Global Integer g_Status &H02&H56&H67&H5F&H53&H74&H61&H74&H75&H73&H2C&H0000&H2C&H03&H03&H5A	Auto ON Ready ON
GetStatus	'S' &H53		Acquire the Controller state	Available any time (*10)
Execute	'X' &H58	Command string	Execute the command (*10) (*11) Example) Execute 'print here' &H02&H58&H22&H70&H72&H69&H6E&H74&H20&H68&H65&H72&H65&H22&H03&H10	Auto ON Ready ON Error OFF EStop OFF Safeguard OFF
Abort	'A' &H41		Abort the command execution (*10)	Auto ON
GetAlm	'z' &H7A		Acquire the alarm state	Available any time (*2)
ResetAlm	'Z' &H5A	Alarm number (1 Byte)	Reset the alarm of the specified alarm number e.g.) When resetting the Alarm 5 &H02&H5A&H05&H03&H5C	Auto ON Ready ON

(*1) The Controller state bit from GetStatus.

(*2) "Available any time" is applicable if the following conditions are met.

When "Remote Ethernet" is set as the control device, or,

"Remote Ethernet" is not set as the control device, but set to be used for monitoring.

(*3) Execute the function specified in the Main[Function No.].

Function Name	Function No.
Main	0
Main1	1
Main2	2
Main3	3
Main4	4
Main5	5
Main6	6
Main7	7
:	:
Main63	63

(*4) Pause command is not available for “NoPause task” and “NoEmgAbort task”.

For the details, refer to the help or the section “*Pause*” in the EPSON RC+7.0 Language reference manual.

(*5) I/O output will be turned OFF and the robot parameter will be initialized.

For the details, refer to the help or the section “*Reset*” in the EPSON RC+7.0 Language reference manual.

(*6) The robot parameter will be initialized.

For the details, refer to the help or the section “*Motor*” in the EPSON RC+7.0 Language reference manual.

(*7) When “0” is specified for the manipulator number, all the manipulator will be operated

If you wish to operate particular manipulator, specify the manipulator number (1 to 16) of the target manipulators.

(*8) Parameter type

Parameter type	Type value(1Byte)
Boolean	&H00
Byte	&H01
Double	&H02
Integer	&H03
Long	&H04
Real	&H05
String	&H06
UByte	&H07
Short	&H08
UShort	&H09
Int32	&H0A
UInt32	&H0B
Int64	&H0C
UInt64	&H0D

For the backup parameters when the parameter name and type are same.

(*9) For the array element, specify an element you acquire as the following:

You need to specify an element when acquiring from the head of the array.

Specify the array element in 2Byte value.

1D array	Parameter name&H2C&H0000	Acquire from the head.
	Parameter name, element number.	Acquire from the specified element number.
2D array	Parameter name &H2C&H0000&H2C&H0000	Acquire from the head.
	Parameter name, element number 1, element number 2	Acquire from the specified element number.
3D array	Parameter name &H2C&H0000&H2C&H0000&H2C&H0000	Acquire from the head.
	Parameter name, element number 1, element number 2, element number 3	Acquire from the specified element number.

You cannot specify a string for the parameter type.

Available number to acquire is up to 100. If you specify a number over the number of array elements, you have an error.

(*10) Specify the command and parameters in the double quotation marks.

Command string to be executed and execution result string are restricted to 4060 bytes.

Robot motion command will be executed to the selected manipulator. Check which robot is selected by using GetCurRobot before command execution.

Following commands are available while Execute is running.

Commands available while Execute is running

Remote Command
Abort
GetStatus
SetIO
SetIOByte
SetIOWord
SetMemIO
SetMemIOByte
SetMemIOWord

When the commands specified in (SetIO, SetIOByte, SetIOWord, SetMemIO, SetMemIOByte, SetMemIOWord) are the same and executed at the same time, the command executed later will result in error. Make sure to check the execution result by using GetStatus after the execution of Execute command and output command which the Execute command is being executed.

(*11) To execute commands of PCDaemon function, be sure to execute while the EPSON RC+ 7.0 is connected. If the EPSON RC+ 7.0 is not connected, command execution will result in error.

12.3.6 Monitoring command

When the remote RS232 control is not set as the control device but set to be used for monitoring, following commands are only available to be executed.

Remote Command
Login
Logout
GetIO
GetIOByte
GetIOWord
GetMemIO
GetMemIOByte
GetMemIOWord
GetVariable
GetStatus
GetCurRobot
GetAlm

12.3.7 Response

When the Controller receives the command correctly, the response in the following format is shown in the executing command.

Response Format

ACK	Command	Data	ETX	BCC
1Byte	1Byte	Variable	1Byte	1Byte

ACK : &H06

ETX : &H03

BCC : Checksum of sent and received data

XOR value from the command to ETX per 1Byte

Command	Format
Remote command that acquire the value Except the following commands	[ACK][Command](1Byte)[ETX][BCC]
GetCurRobot	[ACK] 'y' [Robot number] [ETX][BCC]
GetIO	[ACK] 'i' [&H00 &H01] [ETX][BCC] *1
GetMemIO	[ACK] 'o' [&H00 &H01] [ETX][BCC] *1
GetIOByte	[ACK] 'b' [Byte value (8Bit) (&H00 to &HFF)] [ETX][BCC]

Command	Format
GetMemIOByte	[ACK] 't'[Byte value (8Bit) (&H00 to &HFF)] [ETX][BCC]
GetIOWord	[ACK] 'w'[Word value (16Bit) (&H0000 to &HFFFF)] [ETX][BCC]
GetIOMemWord	[ACK] 'u'[Word value (16Bit) (&H0000 to &HFFFF)] [ETX][BCC]
GetVariable	[ACK] 'v'[Parameter value]*5 [ETX][BCC]
GetVariable (in case of array)	[ACK] 'v'[Parameter value 1] *5 [Parameter value 2] *5... [ETX][BCC] *4
GetStatus	[ACK] 'S'[Status][Error, Warning code] [ETX][BCC] e.g: [ACK] 'S'[aaaaaaaaa][bbbb][ETX][BCC] *2 *3
Execute	If the value is returned as a result of command execution [ACK] 'X'[Execution result]" [ETX][BCC]
GetAlm	[ACK] 'z' [number of alarms][alarm number]... [ETX][BCC] e.g) When no alarm is occurring &H06&H7A&H00&H03&H79 e.g.) When Alarm 1 and 9 are occurring &H06&H7A&H02&H01&H09&H03&H73

*1 [&H00 | &H01] I/O bit ON: &H01/ OFF: &H00

*2 Status

In the example above, 11 digits [aaaaaaaaa] is for the following 11 flags.
Test/Teach/Auto/Warning/SError/Safeguard/EStop/Error/Paused/Running/Ready
&H01 is ON /&H00 is OFF
If Ready and Auto are ON, it is
[&H00&H00&H01&H00&H00&H00&H00&H00&H00&H00&H01].

*3 Error / Warning code

It is indicated in 4 digits. If there is no error and warning, it is
"0000"(&H30&H30&H30&h30).

e.g.)1: [ACK]

'S[&H00&H00&H01&H00&H00&H00&H00&H00&H00&H01][&H30&H30&H30&h30]

The bits for Auto and Ready are &H01.

This means that AutoMode is ON and in Ready state. You can execute the command.

e.g.)2: [ACK]

'S[&H00&H00&H01&H01&H00&H00&H00&H00&H00&H01&H00][&H30&H35&H31&h37]

This means the warning occurs during the operation. Take appropriate action according to the warning code. (In this case, warning code is 0517)

Flag	Contents
Test	Turn ON in the TEST mode
Teach	Turn ON in the TEACH mode
Auto	Turn ON in the remote input acceptance condition
Warning	Turn ON in the warning condition Task can be executed as usual even a warning condition. However, take action for the warning as soon as possible.
SError	Turn ON in the serious error condition When a serious error occurs, Reboot the Controller to recover from the error condition. "Reset input" is not available.
Safeguard	Turn ON with safety door open
EStop	Turn ON in the emergency condition
Error	Turn ON in the error condition Use "Reset input" to recover from the error condition.
Paused	Turn ON with paused task
Running	Turn ON with task executing Turn OFF when "Paused output" is ON
Ready	Turn ON with the Controller completed the startup and no task executing

*4 It returns values of specified number in the Number to acquire.

*5 Binary data. If you convert it to the specified data type after acquisition, conversion process is required.

Error response

When the Controller cannot receive the remote command correctly, the error response is shown in the following format.

NAK	Command	Error code	ETX	BCC
1Byte	1Byte	2Byte	1Byte	1Byte

NAK : &H15


ETX : &H03

BCC : Checksum of sent and received data

XOR value from the command to ETX per 1Byte

Error code	Contents
10	Remote command does not begin with \$
11	Remote command is wrong Login is not executed
12	Remote command format is wrong
13	Login command password is wrong
14	Specified number to acquire is out of range (Less than 1 or more than 100) Number to acquire is omitted Specified a string parameter
15	Parameter is not existed Dimension of parameter is wrong Element out of range is called
16	BCC is wrong
19	Request time out
20	Controller is not ready
21	Cannot execute since the Execute is running
99	System error Communication error

12.3.8 Response timing of Remote Ethernet control



12.4 User-defined Remote Output I/O

12.4.1 What is user-defined remote output I/O?

User-defined remote output I/O is the remote output I/O that the user arbitrarily sets the output conditions.

Output to the I/O without creating dedicated tasks to the user program is possible.

- 8 user-defined remote output I/O are available.
- Output condition is specified by the condition expression of the SPEL language.
- Evaluation of output conditions are performed in 30 ms periods.
- Output method when condition is met can be selected from Level, Pulse, and Latch.
- Output polarity (active low/ active high) when condition is met can be selected.

12.4.2 Output conditions

Output conditions consist of the ON and OFF conditions. The OFF condition is set only when the output method is "Latch".

[ON condition]

Set the condition expression to start output.


[OFF condition]

Set the condition expression to terminate the latch output.

12.4.3 Output

Level output


It outputs with the selected polarity while the ON condition is met. Output terminates when the ON condition is not met.



Pulse output


It outputs with the selected polarity for the specified time (10 ms unit) after the ON condition is met.

Output terminates when the specified time elapses.



Latch output

Output starts with the selected polarity when ON condition is met. Output terminates when OFF condition is met and ON condition is not met at the same time.



12.4.4 Restrictions

Condition expressions of the SPEL language are used to specify conditions. However, they have following restrictions.

- Variables cannot be used.
- Labels cannot be used.
- Available functions are limited.

Available Functions

A	Abs	Acos	Agl	And
	Arm	ArmDef	Asc	Asin
	Atan	Atan2		
B	BClr	BClr64	BoxDef	BSet
	BSet64	BTst	BTst64	
C	Cos	CR	CS	CT
	CtrlDev	CtrlInfo	CU	CurPos
	CV	CW	CX	CY
	CZ			
D	DegToRad	DispDev	Dist	
E	ECP	ECPDef	ECPSet	ElapsedTime
	Era	Errb	ErrorOn	Ert
	EStopOn			
F	Fine	Fix		
G	GetRobotInsideBox	GetRobotInsidePlane		
H	Hand	Hofs	HomeDef	Hour
I	In	InBCD	Inertia	InPos
	InReal	InsideBox	InsidePlane	InW
J	J1Angle	J1Flag	J4Flag	J6Flag
	JRange			
L	LatchState	LimitTorque	LimZMargin	Local
	LocalDef	LShift	LShift64	
M	MCalComplete	MemIn	MemInW	MemSw
	Motor			
O	OLRate	Oport		

12. Remote Control


P	PAgl Plane PPls	PauseOn PlaneDef Power	PDef PLocal PTPBoost	PG_Lspeed Pls
Q	QPDecelR	QPDecelS		
R	RadToDeg RecoverPos RShift	RealAccel Rnd RShift64	RealPls RobotInfo	RealPos RobotType
S	SafetyOn SpeedFactor Stat	Sgn SpeedR Sw	Sin SpeedS SyncRobots	Speed Sqr SysErr
T	Tan TCLim TLDef	TaskDone TcSpeed TLSet	TaskInfo TeachOn Tool	TaskState Time
V	Val			
W	Weight			
X	XY	XYLimDef		

12.4.5 How to set the user-defined output remote I/O

(1) Add the use-defined output remote I/O


The user-defined output remote I/O are not defined as default. To use them, add the output remote I/O in the configuration dialog box and configure the output condition. The added I/O will be available in the remote output setting.

[System Configuration] - [Controller] – [Remote Control] – [User Outputs]



Click the <Add> button. The following dialog box will appear.

Select the items and set the condition expressions. Then, click the <Apply> button.



[Name]

Set the name of the signal. Default is “UseroutputX”.

X = I/O number

The name specified here is displayed in the remote output setting and the I/O monitor.

[Type]

Select the output type.

[Polarity]

Select the polarity to output when the condition is met.

Active high: High Active low: Low

[On Condition]

Set the condition to start output. Setting is required for all output types.

[Off Condition]

Setting is required if the Latch output is selected.

[Robot]

Setting is required if the expression related to the manipulator is used for On and Off conditions. The conditions for only one robot can be set.

This setting is not necessary if the manipulator-related condition is not used.


NOTE

If unregistered robot number is specified, an initialization error occurs at the Controller restart.

(2) Setting of remote outputs

To enable the added I/O outputs, assign the registered user definition to the target I/O. Assignment is done by the remote output.

[System Configuration]-[Controller]-[Remote Controller]-[Outputs]




The names of the added signals appear in [Output Signal]. Select the bit to output.

12.4.6 Usage example

If you want to turn ON the bit port 8 of the standard I/O for 500 ms when the bit port 0 of the standard I/O input is ON and the bit port 1 is OFF:


(1) User definition



1. Set “LED_1” for the [Name] in this example. Change the setting if necessary.
2. Select “Pulse” for [Type].
3. Select [Active High] for [Polarity] in order to output ON.
4. Set the On condition. In this example, set the following condition expression.

$$Sw(0) = \text{On} \text{ And } Sw(1) = \text{Off}$$
5. Set “500” for [Pulse Width].
6. Click the <Apply> button.

(2) Setting in the [Remote Control Outputs]



1. Select the output bit "8" for the configured name (LED_1).
2. Click the <Apply> button.

Now, output to the I/O will be executed according to the condition expression after rebooting.

13. RS-232C Communications

The Robot Controller supports:


- Windows part : Standard RS-232C port × 2
(Standard: Port 1001 only, High-speed: Port 1001, 1002)
- Standard RS-232C : 1 port as standard
- Expanded RS-232C : Option RS-232C port × 4 at maximum (2 ports per board)
However, RS-232C port × 2 at maximum when using Force
Sensor I/F board with RC700. (For a board, one is the
maximum.)

For instructions on how to install RS-232C boards, refer to the *Robot Controller* manual.

13.1 RS-232C Software Configuration

To configure a Windows Part RS-232C port

1. Select [System Configuration] from the [Setup] menu and open the dialog box.




2. Select [Controller]-[RS-232C]-[PC] from the tree on the left.
3. Set the [Enabled] check box.
4. Change the settings as desired.
5. Click <Apply> to save the new settings.
6. Click <Close>.



If several ports are used for communication at one time with more than a 19200 baud rate, error 2929 or 2922 may occur. In this case, select a lower baud rate or avoid using several ports at one time.

To configure a standard / option RS-232C port

1. Select [System Configuration] from the [Setup] menu and open the dialog box.



2. Select the [Controller]-[RS-232C]-[CU] from the tree on the left.
3. Select a port to configure.
4. Change the settings as desired.
5. Click <Apply> to save the new settings.
6. Click <Close>.

13.2 RS-232C Commands

The following is a list of all of the commands associated with RS-232C communications. For details, please see the online help or *SPEL⁺ Language Reference Manual*.

OpenCom	Opens a communications port.
ChkCom	Returns port status: the number of bytes waiting to be read or error condition.
CloseCom	Closes a communications port.
SetCom	Sets communications port parameters at runtime or from the Command window.
Print #	Sends characters out of the port.
Input #	Receives characters from the port into one or more variables.
Line Input #	Receives one line characters from the port into one string variable.
Read #	Receives one or more characters from the port into one string variable.
ReadBin #	Receives one or more bytes from the port.
Write #	Sends characters out of the port.
WriteBin #	Sends one or more bytes out of the port.

14. TCP/IP Communications

EPSON RC+ 7.0 supports 16 TCP/IP ports that allow peer to peer communications.

This chapter contains instructions on using TCP/IP, including IP addresses of LAN-1 port and Windows TCP/IP configuration.



CAUTION

- LAN-2 is not available for peer to peer communications of EPSON RC+ 7.0. For details, refer to *RC700 Robot Controller manual: Setup & Operation 7. LAN (Ethernet Communication) Port*.

14.1 TCP/IP Setup

Before you can use TCP/IP communications between PCs and controllers, you must configure your network. The following sections describe basic network configuration.

14.1.1 Ethernet Hardware


The Controller includes a built in Ethernet interface with an RJ45 connector accessible from the controller front panel. It supports 10BaseT (10 Mbps) and 10BaseTX (100 Mbps).

Your PC will need a 10BaseT 10/100 adapter to communicate with the Controller via Ethernet.

14.1.2 IP Addresses

The controller has a fixed IP address that you can configure from EPSON RC+ 7.0. To configure the IP address, mask, and gateway for the controller, refer to 5.12.2 [System Configuration] Command (Setup Menu).

The following table shows a typical IP address configuration.



Host Name	IP Address	Subnet	Subnet Mask
PC1	192.168.0.1	192.168.0	255.255.255.0
PC2	192.168.0.2	192.168.0	255.255.255.0
Controller1	192.168.0.3	192.168.0	255.255.255.0
Controller2	192.168.0.4	192.168.0	255.255.255.0

In this example, the network address (subnet) is 192.168.0. With a subnet mask of 255.255.255.0, there can be 254 hosts on this subnet (0 and 255 cannot be used).

Refer to the Microsoft Windows operating system manual for instructions on setting the PC IP address.

14.1.3 IP Gateway

If you are connecting PCs and controllers on different networks, you will need to route traffic between the networks using one or more routers. Each device communicating via Ethernet will need to have their default gateway address set to the address of the router for its subnet.

To configure the gateway address for the controller, refer to 5.12.2 [System Configuration] Command (Setup Menu).

14.1.4 Testing Windows TCP/IP setup

Use the ping command from a Command Window to test communications.

First, do a loopback test to check if you can ping your own address by using the local IP address:

```
C:\>ping 127.0.0.1
Pinging 127.0.0.1 with 32 bytes of data:
Reply from 127.0.0.1: bytes=32 time<10ms TTL=128
Reply from 127.0.0.1: bytes=32 time<10ms TTL=128
Reply from 127.0.0.1: bytes=32 time<10ms TTL=128
Reply from 127.0.0.1: bytes=32 time<10ms TTL=128
C:\>
```

Ping your PC's IP address:


```
C:\>ping 192.168.0.1
Pinging 192.168.0.1 with 32 bytes of data:
Reply from 192.168.0.1: bytes=32 time<10ms TTL=128
Reply from 192.168.0.1: bytes=32 time<10ms TTL=128
Reply from 192.168.0.1: bytes=32 time<10ms TTL=128
Reply from 192.168.0.1: bytes=32 time<10ms TTL=128
C:\>
```

Now ping controller on the network. :

```
C:\>ping 192.168.0.3
Pinging pc2 [192.168.0.3] with 32 bytes of data:
Reply from 192.168.0.3: bytes=32 time<10ms TTL=128
Reply from 192.168.0.3: bytes=32 time<10ms TTL=128
Reply from 192.168.0.3: bytes=32 time<10ms TTL=128
Reply from 192.168.0.3: bytes=32 time<10ms TTL=128
C:\>
```

14.2 TCP/IP Software Configuration

You can configure TCP/IP settings for the controller in a SPEL⁺ program using the SetNet command. You can also configure settings from the [TCP/IP] tab on the [Setup]-[System Configuration] dialog.



To configure a TCP/IP port

1. Select the TCP/IP port you want to configure from [Setup]-[System Configuration]-[Controller]-[TCP/IP].
2. Enter the IP address for the controller or PC that you want this controller to communicate with.

The controller does not support DNS, so you must specify an IP address for the host you are communicating with. You cannot specify a name for the host.
3. Enter the TCP/IP port number. This must be the same port number that is used on the host device. It must be different from any of the other TCP/IP port numbers used for the other TCP/IP ports.
4. Change the other settings as desired.
5. Click <Apply> to save the new settings and click <Close>.

14.3 TCP/IP Commands

Here is a list of all of the commands associated with TCP/IP communications. For details, please see the online help or SPEL⁺ Language Reference Manual.

OpenNet	Opens a TCP/IP port.
ChkNet	Returns port status: the number of bytes waiting to be read or error condition.
CloseNet	Closes a TCP/IP port.
SetNet	Sets communications port parameters at runtime or from the Command window.
Print #	Sends characters out of the port.
Input #	Receives characters from the port into one or more variables.
Line Input #	Receives one line characters from the port into one string variable.
Read #	Receives one or more characters from the port into one string variable.
ReadBin #	Receives one or more bytes from the port.
Write #	Sends characters out of the port.
WriteBin #	Sends one or more bytes out of the port.

15. Security

15.1 Overview

The Security function allows you to manage EPSON RC+ 7.0 users and also monitor usage.

When the Security function is activated, administrators can add groups and users. Each group can have one or more rights associated with it. For example, you can create a group called Maintenance that has rights to edit robot points, use Jog & Teach, and enable you to use the Command Window. When a user attempts to do something that he/she does not have a right for, a message "Permission denied" will be displayed.

Each login session is recorded in a Microsoft Access compatible data base. Security Log Viewer is included that allows you to view each session's activity.

User can login to EPSON RC+ with a name and password. Optionally, EPSON RC+ can use the Windows user name to log in automatically.

15.2 Security Configuration


EPSON RC+ 7.0 requires a path for security files. If you have more than one system on a network, it is recommended that you setup the security files path for all systems to store the security logs in a server on the network.

To administer EPSON RC+ 7.0 security:

1. Start EPSON RC+ 7.0.
2. Select [Setup]-[System Configuration].
3. Click on the [Security] tree.
4. On the [General] tree, type in the path for your security files or click the <Browse> button.
5. Click on the [Users] tree.
6. For each user on your system, click <New> button.
Each new user belongs to the Guest group by default. Click in the group field, then click the dropdown button to select the desired group.

[General] Tab

This tab allows you to configure the general security settings.



Automatic log in using current Windows user name

Check this box if you want EPSON RC+ 7.0 to use the current Windows login ID. When the Security function is active, you will not see a login dialog when EPSON RC+ starts, unless EPSON RC+ cannot find the user in the Security system.

Security data path


This is the path where security files will be stored.

This path should be protected with Windows security rights so that only Administrators can delete the files in this path. All other EPSON RC+ users should have only read rights to the files in this path.

Security User: Administrator

This page allows you to add and remove EPSON RC+ 7.0 users.

Two users are permanent: Administrator and Guest. Only the passwords can be changed for these users. You should always use a password for the Administrator, though no password is set at shipment time.



To add a user

1. Click the <Add> button.
2. A new user will be added to the tree.
3. Click the [Group] tree for the new user.
4. Click the dropdown button and select the group for the user.

To delete a user

1. Click the [User] you want to delete in the tree.
2. Click the <Delete> button.
3. A confirmation message to delete the user will appear.

To change a user's group

1. Click the [Group] dropdown for the user you want to change.
2. Click a dropdown button in the field and select a new group.


Editing Name, Login ID, and Password

1. Click a [User] you want to change.
2. Edit the field. All fields are not case sensitive.

Security Group: Administrator

This page allows you to configure user groups. Every EPSON RC+ 7.0 user must belong to a group.

Two groups cannot be deleted or modified: Administrators and Guests. Administrators have full rights, and Guests have no rights.



To add a group

1. Click the <Add> button.
2. Type in a name for the group.
3. Click the <Apply> button.

To delete a group

1. Select the group you want to delete.
2. Click the <Delete> button.
3. A confirmation message to delete the group will appear.

To change rights for groups

1. Select the group you want to change rights for.
Note that you cannot change rights for Administrators and Guests.
2. To add a right, set the checkbox(es) for the desired rights in the [Rights] checkbox list.
3. To remove rights, clear the checkbox(es) for the rights you want to remove in the [Right] checkbox list.

Group Rights

The list below shows the rights that are available for user groups. Administrators have full rights, and Guests have no rights.


Right	Description
Configure options	Users can change option settings in [Setup]-[Options].
Use Command Window	Users can open the command window and execute commands.
Configure system	Users can configure the entire EPSON RC+ system.
Jog	Users can open the [Jog & Teach] dialog and jog a robot.
Check security log	Users can see security logs.
Delete security log	Users can delete security logs in [Tools]-[Audit Viewer].
Teach points	Users can teach points and delete points from the Jog & Teach dialog.
Edit vision	Users can edit vision parameters.
Edit programs	Users can edit program.
Edit projects	Users can edit projects.
Edit points	Users can change points.
Change memory I/O	Users can turn ON/OFF memory I/O bits.
Change robot parameter	Users can open the [Robot Manager] dialog and change the settings.
Output port ON	Users can turn ON/OFF outputs.

15.3 Security Audit Viewer

When the Security function is enabled, EPSON RC+ 7.0 will keep track of who logs into the system and actions performed.

Activity is stored to the security data path in the Microsoft Access compatible data base format.

To view the security logs, select [Audit Viewer] from the [Tools] menu.



15.4 SPEL+ Security Command

Here are the SPEL+ commands that are enabled with the Security function. For details, please see the *EPSON RC+ 7.0 Online Help* or *SPEL+ Language Reference manual*.

Command	Description
LogIn Function	Logs in the application as another user at runtime.
GetCurrentUser\$ Function	Returns the login ID of the current user.

16. Conveyor Tracking

16.1 Overview

Conveyor Tracking is a process in which a robot picks up parts from a stationary or moving conveyor that are found by a vision system or sensor.

The EPSON RC+ 7.0 Conveyor Tracking option supports both tracking and indexed conveyor systems.

- **Tracking conveyor system**
Conveyor moves constantly. Vision system or sensor system finds the parts on it and robot picks them up as they move. During tracking, the robot can move along with the part as it picks up parts.
- **Indexed conveyor system**
Conveyor moves a specified distance and then stops. The vision system finds the parts and robot picks up each part. After finding and picking up all parts, the conveyor moves again.



A total of 16 physical conveyors can be defined on each system. A physical conveyor has one encoder whose signals are received by an encoder board.

Up to 16 logical conveyors can be defined in each project. To define a logical conveyor, set a conveyor number, a robot number, encoder number and select vision or sensor.

Multiple conveyors and multiple-robot conveyors are supported.

16. Conveyor Tracking


The Conveyor Tracking option is available for straight conveyors and circular conveyors, as shown in the figures below. These conveyors have different calibration and programming methods.



16.2 Conveyor Tracking Processes

Tracking conveyor system


1. Vision system or sensor system finds the parts on a continuously moving conveyor.
2. Robot picks up the parts on the conveyor as they move.



Configuration example of
Tracking Conveyor System (Vision System)

Indexed conveyor system

1. Conveyor moves a specified distance.
2. Vision system or sensor system finds the parts on the conveyor when it stops.
3. Robot picks up the parts found by vision system.
4. After finding and picking up all parts, conveyor moves by the specified distance again.



Configuration example of
Indexed Conveyor System (Vision System)

16.3 System Structure


Structure of Vision Conveyor Tracking System

The structure of the vision conveyor tracking system is shown in the figures below.


For this system, you need to set the same timing for the vision system to search for parts on the conveyor and for the encoder on the conveyor to latch position. To set the same timing, use the asynchronous reset mode in the vision system (if you don't use asynchronous reset mode, the timing of image acquisition is different from the encoder latch timing and the pickup precision will decrease).

Asynchronous reset mode allows the camera to acquire an image at the moment of trigger input and transfers the image to the vision sequence.

The hardware trigger or the software trigger can be selected for this system. The hardware trigger is wired to the counter trigger input of the PG board and latches the encoder on the conveyor by using the signals from the sensor and I/O. Software trigger latches the encoder on the conveyor by using a Spel program.




Vision Conveyor Tracking Overview (using a software trigger)



Structure of Sensor Conveyor Tracking System

The structure of the Sensor Conveyor Tracking System is shown in the figure below. This system uses a hardware trigger.



16.4 Hardware Installation

To use conveyor tracking, you must install encoders for each physical conveyor on the system. Each encoder is wired to a single channel on a PG (Pulse Generator) board. Each board can accommodate up to 4 encoders. A trigger input is also provided for each encoder to latch position, such as when used with a vision camera with a strobe.

PG board specifications


The table below shows the specification for the PG board.

Board Name	H756
Compatible Controller	RC700/ RC90 (EPSON RC+ 7.0)
Board Extension Capability	4 boards maximum
Encoder channels	4 channels / board
Encoder Type	ABZ phase differential input (RS-422 line receiver)
Input Pulse Rate	Max. 5 MPPS
Input Signal	Conveyor pulse latch input
Board Address	Set the DIP switch according the board number. (See DIP Switch Settings later in this chapter).
connector	DX10A - 100S (Hirose Electric Co.,Ltd.)
Power Supply	24V \pm 2V 200mA or under

The following encoder models have been tested:

OMRON E6B2-CWZ1X
TAMAGAWA TS5312N512-2000C/T

The figure below shows the layout of the PG board.



DIP switch settings

The board address is set by DIP switch (S2, S3) on the PG Board according to the board number, as shown in the following table.

Board #	Address	S2				S3			
		1 (A15)	2 (A14)	3 (A13)	4 (A12)	1 (A11)	2 (A10)	3 (A9)	4 (A8)
1	1100h	OFF	OFF	OFF	ON	OFF	OFF	OFF	ON
2	1200h	OFF	OFF	OFF	ON	OFF	OFF	ON	OFF
3	1300h	OFF	OFF	OFF	ON	OFF	OFF	ON	ON
4	1400h	OFF	OFF	OFF	ON	OFF	ON	OFF	OFF

If you purchased the PG board separately, place the attached Board No. Label sticker on the board panel prior to installation of the board in the Control Unit and keep a written record of the address setting and the board number.

If you have purchased the PG Board with the Control Unit, the board address has been set properly before shipment and further settings should not be necessary.

Jumper settings

The jumpers are reserved and should not be changed.

Rotary switch settings

The rotary switch S1 is reserved and should not be changed.

S1 : Position of 1

Signal Connections

The table below lists the connectors on the PG board and the compatible connectors for wiring:

Receptacle on the Board		DXA10A-100S (manufacturer: Hirose Electric Co.,Ltd.)
Wiring Plug Connectors	Individually pressed-in type	DX30-100P (for AWG#30) DX30A-100P (for AWG#28)
	Pressed-in-as-a-whole type	DX31-100P (for AWG#30) DX31A-100P (for AWG#28)
	Soldered type	DX40-100P
Connector for Wiring to the Cover		DX-100-CV1

Signal Assignments: PG board connector (DX10A-100S)

The signals on the PG board connector are assigned as shown in the table below.

Pin	Dir	Signal	Description	Pin	Dir	Signal	Description
1	-	-	Not used	51	-	-	Not used
2	-	-	Not used	52	-	-	Not used
3	-	-	Not used	53	-	-	Not used
4	-	-	Not used	54	-	-	Not used
5	-	-	Not used	55	-	-	Not used
6	-	-	Not used	56	-	-	Not used
7	-	-	Not used	57	-	-	Not used
8	-	-	Not used	58	-	-	Not used
9	-	-	Not used	59	-	-	Not used
10	In	TRG1	Trigger input for Counter1	60	-	-	Not used
11	In	TRG2	Trigger input for Counter2	61	-	-	Not used
12	In	TRG3	Trigger input for Counter3	62	-	-	Not used
13	In	TRG4	Trigger input for Counter4	63	-	-	Not used
14	In	EXTV	External power supply for Input circuit	64	In	EXTV GND	External power supply GND for Input circuit
15	In	EXTV	External power supply for Input circuit	65	In	EXTV GND	External power supply GND for Input circuit
16	-	-	Not used	66	-	-	Not used
17	-	-	Not used	67	-	-	Not used
18	-	-	Not used	68	-	-	Not used
19	-	-	Not used	69	-	-	Not used
20	-	-	Not used	70	-	-	Not used
21	-	-	Not used	71	-	-	Not used
22	-	-	Not used	72	-	-	Not used
23	-	-	Not used	73	-	-	Not used
24	-	-	Not used	74	-	-	Not used

Pin	Dir	Signal	Description	Pin	Dir	Signal	Description
25	In	+A1	Phase +A signal for Counter 1	75	In	+A3	Phase +A signal for Counter 3
26	In	-A1	Phase -A signal for Counter 1	76	In	-A3	Phase -A signal for Counter 3
27	In	+B1	Phase +B signal for Counter 1	77	In	+B3	Phase +B signal for Counter 3
28	In	-B1	Phase -B signal for Counter 1	78	In	-B3	Phase -B signal for Counter 3
29	In	+Z1	Phase +Z signal for Counter1	79	In	+Z3	Phase +Z signal for Counter 3
30	In	-Z1	Phase -Z signal for Counter 1	80	In	-Z3	Phase -Z signal for Counter 3
31	-	-	Not used	81	-	-	Not used
32	-	-	Not used	82	-	-	Not used
33	-	-	Not used	83	-	-	Not used
34	-	-	Not used	84	-	-	Not used
35	-	-	Not used	85	-	-	Not used
36	-	-	Not used	86	-	-	Not used
37	-	-	Not used	87	-	-	Not used
38	-	-	Not used	88	-	-	Not used
39	-	-	Not used	89	-	-	Not used
40	-	-	Not used	90	-	-	Not used
41	In	+A2	Phase +A signal for Counter 2	91	In	+A4	Phase +A signal for Counter 4
42	In	-A2	Phase -A signal for Counter 2	92	In	-A4	Phase -A signal for Counter 4
43	In	+B2	Phase +B signal for Counter 2	93	In	+B4	Phase +B signal for Counter 4
44	In	-B2	Phase -B signal for Counter 2	94	In	-B4	Phase -B signal for Counter4
45	In	+Z2	Phase +Z signal for Counter 2	95	In	+Z4	Phase +Z signal for Counter 4
46	In	-Z2	Phase -Z signal for Counter 2	96	In	-Z4	Phase -Z signal for Counter 4
47	-	-	Not used	97	-	-	Not used
48	-	-	Not used	98	-	-	Not used
49	-	-	Not used	99	-	-	Not used
50	-	GND	GND	100	-	GND	GND

Pin # 25 to 30, 41 to 46, 75 to 80, 91 to 96

Connect the pin numbers shown above with encoder output (+A, -A, +B, -B, +Z, -Z).

Pins # 10 to 13

When the conveyor pulse is latched by external signal, connect the pin numbers shown above with latch signal. Exactly when the signal is turned OFF to ON, the encoder pulse is latched.

Pins # 14, 15, 64 and 65

When using the pin # 10 to 13, connect external power with the pin numbers shown above.

When not using the pin # 10 to 13, it is not necessary to connect external power with the pin numbers shown above.

Signal Assignments: PG board connector terminal block 1

The signals on the PG board connector terminal block #1 are assigned as shown in the table below. The pin numbers in parentheses are the pins on the PG board connector.


Pin	Signal	Description	Pin	Signal	Description
1 (16)	-	Not used	26 (32)	-	Not used
2 (17)	-	Not used	27 (33)	-	Not used
3 (18)	-	Not used	28 (34)	-	Not used
4 (19)	-	Not used	29 (35)	-	Not used
5 (20)	-	Not used	30 (36)	-	Not used
6 (21)	-	Not used	31 (37)	-	Not used
7 (22)	-	Not used	32 (38)	-	Not used
8 (23)	-	Not used	33 (39)	-	Not used
9 (24)	-	Not used	34 (40)	-	Not used
10 (25)	+A1	Phase +A signal for Counter 1	35 (41)	+A2	Phase +A signal for Counter 2
11 (26)	-A1	Phase -A signal for Counter 1	36 (42)	-A2	Phase -A signal for Counter 2
12 (27)	+B1	Phase +B signal for Counter 1	37 (43)	+B2	Phase +B signal for Counter 2
13 (28)	-B1	Phase -B signal for Counter 1	38 (44)	-B2	Phase -B signal for Counter 2
14 (29)	+Z1	Phase +Z signal for Counter 1	39 (45)	+Z2	Phase +Z signal for Counter 2
15 (30)	-Z1	Phase -Z signal for Counter 1	40 (46)	-Z2	Phase -Z signal for Counter 2
16 (31)	-	Not used	41 (47)	-	Not used
17 (48)	-	Not used	42 (49)	-	Not used
18 (9)	-	Not used	43 (50)	GND	Ground
19 (60)	-	Not used	44 (61)	-	Not used
20 (10)	TRG1	Trigger input for Counter 1	45 (11)	TRG2	Trigger input for Counter 2
21 (1)	-	Not used	46 (5)	-	Not used
22 (2)	-	Not used	47 (6)	-	Not used
23 (3)	-	Not used	48 (7)	-	Not used
24 (4)	-	Not used	49 (8)	-	Not used
25 (14)	EXTV	External power supply	50 (64)	EXTV GND	External power supply ground

Signal Assignments: PG board connector terminal block 2

The signals on the PG board connector terminal block #2 are assigned as shown in the table below. The pin numbers in parentheses are the pins on the PG board connector.

Pin	Signal	Description	Pin	Signal	Description
1 (66)	-	Not used	26 (82)	-	Not used
2 (67)	-	Not used	27 (83)	-	Not used
3 (68)	-	Not used	28 (84)	-	Not used
4 (69)	-	Not used	29 (85)	-	Not used
5 (70)	-	Not used	30 (86)	-	Not used
6 (71)	-	Not used	31 (87)	-	Not used
7 (72)	-	Not used	32 (88)	-	Not used
8 (73)	-	Not used	33 (89)	-	Not used
9 (74)	-	Not used	34 (90)	-	Not used
10 (75)	+A3	Phase +A signal for Counter 3	35 (91)	+A4	Phase +A signal for Counter 4
11 (76)	-A3	Phase -A signal for Counter 3	36 (92)	-A4	Phase -A signal for Counter 4
12 (77)	+B3	Phase +B signal for Counter 3	37 (93)	+B4	Phase +B signal for Counter 4
13 (78)	-B3	Phase -B signal for Counter 3	38 (94)	-B4	Phase -B signal for Counter 4
14 (79)	+Z3	Phase +Z signal for Counter 3	39 (95)	+Z4	Phase +Z signal for Counter 4
15 (80)	-Z3	Phase -Z signal for Counter 3	40 (96)	-Z4	Phase -Z signal for Counter 4
16 (81)	-	Not used	41 (97)	-	Not used
17 (98)	-	Not used	42 (99)	-	Not used
18 (59)	-	Not used	43 (100)	GND	Ground
19 (62)	-	Not used	44 (63)	-	Not used
20 (12)	TRG3	Trigger input for Counter 3	45 (13)	TRG4	Trigger input for Counter 4
21 (51)	-	Not used	46 (55)	-	Not used
22 (52)	-	Not used	47 (56)	-	Not used
23 (53)	-	Not used	48 (57)	-	Not used
24 (54)	-	Not used	49 (58)	-	Not used
25 (15)	EXTV	External power supply	50 (65)	EXTV GND	External power supply ground


Encoder Input Circuit



16.5 Wiring example of Vision Conveyor Tracking System

Example using I/O Output (sink type) to Synchronize

Wire the vision trigger and the hardware conveyor trigger to the I/O output of the same bit number. The PG board detects the trigger when the I/O output turns from OFF to ON. Set the camera so that it also detects the trigger when the I/O output turns from OFF to ON.




Wiring example of the conveyor encoder, vision trigger, and hardware conveyor trigger (CV1, I/O output No. 0 and Counter 1 are used)

16.6 Conveyor Encoder Configuration

Before you can create any conveyors in a project, you must first add conveyor encoders to the system. Each physical conveyor must have an encoder.

First, you must install one PG board for every four encoders in the PC Control Unit and wire the encoders to the board(s).

To define system encoders in EPSON RC+, select [Setup]-[System Configuration] and select the [Conveyor Encoders].



Click the <Add> button to add an encoder. Encoders are added in the order of Axis number.

You can delete the last encoder in the list. Select it, then click the <Delete> button.

16.7 Verifying Encoder Operation


After wiring the encoders and adding them to RC+ (as described in the previous section), follow these steps to verify operation.

1. Start RC+.
2. Create a new project called “TestCnv”.
3. Refer to *16.11 Creating Conveyors in a Project* and create a conveyor.

Conveyor 1: Encoder

Type : Sensor

Make sure to perform the calibration, otherwise the conveyor tracking system cannot work properly. When you only check the encoder operation, it is not necessary to calibrate the conveyors.



4. Now you can use the Cnv_Pulse function to read pulses from Encoder 1 from a program or from the monitor window.

For example, execute this print statement from the monitor window to read the pulses from encoder 1. Then move the conveyor and execute the command again.

```
>print cnv_pulse(1)
```

You can also use a simple program as shown below. Start the program and move the conveyor. When the conveyor starts moving, the value of Cnv_Pulse will be changed.

```
Function main
Do
  Print Cnv_Pulse(1)
  Wait .5
Loop
Fend
```

16.8 Verifying Hardware Conveyor Trigger / Vision Trigger

Verifying the Hardware Conveyor Trigger

1. Move the conveyor and stop it.
2. Check the encoder pulse. Enter the following to the command window.

```
> Print Cnv_Pulse (Conveyor number)
```
3. Turn ON the I/O output number which the trigger is wired to. Latch the encoder pulse.
4. Check the latch pulse. Enter the following to the command window.

```
> Print Cnv_LPulse (Conveyor number)
```

 - If the same value as obtained in the Step 2 is latched, the verification is completed.
 - If not, check the hardware conveyor trigger wiring.

Verifying the Vision Trigger

1. Set the RuntimeAcquire property of the vision sequence to “Strobed” and the TriggerMode property to “Leading”.
2. Execute the vision sequence and put it into the trigger waiting state.
3. Turn ON the I/O output number which the trigger is wired to and release the shutter.
 - If the captured image is displayed on the VisionGuide window, the verification is completed.
 - If not, check the vision trigger wiring.

16.9 Key Terms

Here explains key terms used in this section.

Queue	<p>Waiting queue of the FIFO (First-In, First-Out) type for each conveyor.</p> <p>With the queue, you can register the pose data of work pieces running on the conveyor and user data. When you add data, it will be registered to the end of the queue. When you delete data from the queue, the remaining data in the queue will be moved up automatically.</p>
Queue depth	<p>The number of data entries registered in a queue.</p> <p>Maximum number of queue data is 1000.</p>
Queue user data	<p>Optional real value that can be registered in a queue.</p> <p>You can store additional information such as sorted data or part type determined by the image processing.</p>
Downstream Conveyor	<p>Use this when using multiple conveyors and you run them continuously. By making an association (upstream/downstream) between conveyors, you can move a queue using the Cnv_QueueMove command. "Multiple conveyors" is not necessarily more than one conveyor. You can use one long physical conveyor and set upstream side and downstream side as different logical conveyors. This enables the robots cooperative work, for instance, robot at the downstream side can pick up the work pieces that the robot at upstream fails to pick in time.</p>
Upstream Limit	<p>Dividing line in the upstream side of the Pickup Area.</p>
Downstream Limit	<p>Dividing line in the downstream side of the Pickup Area.</p>
Pickup Area	<p>The area between the upstream limit and downstream limit.</p> <p>The robot picks parts which flow in the Pickup Area.</p> <p>The robot starting pickup near the downstream limit continues its operation over the downstream limit.</p> <p>Make sure that the Pickup Area covers the whole robot motion range.</p> <p>For details, refer to <i>16.15 Pickup Area</i>.</p>

16.10 Conveyor Tracking Commands

All Conveyor Tracking commands begin with the same prefix: "Cnv_". Here is a list of all of the commands. For details, please see the *EPSON RC+ Online Help* or *SPEL+ Language Reference manual*.

Command	Description / Usage
Cnv_AbortTrack	Aborts a motion command to a conveyor queue point.
Cnv_Accel Function	Sets/ returns acceleration and deceleration of the conveyor.
Cnv_Accel	Sets acceleration and deceleration of the conveyor.
Cnv_DownStream Function	Returns the downstream limit for the specified conveyor.
Cnv_Downstream	Sets the downstream limit of the conveyor.
Cnv_Fine Function	Returns the setting of the range to judge if the tracking motion is completed or not for the specified conveyor.
Cnv_Fine	Sets / returns the value of Cnv_Fine for one conveyor.
Cnv_Mode Function	Returns the conveyor mode setting value.
Cnv_Mode	Sets the conveyor mode setting value.
Cnv_LPulse Function	Returns the pulse latched by a conveyor trigger.
Cnv_Name\$ Function	Returns the name of the specified conveyor.
Cnv_Number Function	Returns the number of a conveyor specified by name.
Cnv_OffsetAngle	Sets the angle offset. Usage: This command is available only for the circular conveyor.
Cnv_OffsetAngle Function	Returns the offset angle.
Cnv_Point Function	Returns a robot point in the specified conveyor's coordinate system derived from sensor coordinates. Usage: Use this function when registering a point in the queue.
Cnv_PosErr Function	Returns deviation in current tracking position compared to tracking target.
Cnv_Pulse Function	Returns the current position of a conveyor in pulses.
Cnv_QueueAdd	Adds a robot point to a conveyor queue. Usage: Use this command to register a point in the queue.
Cnv_QueueGet Function	Returns a point from the specified conveyor's queue. Usage: Use this command for robot tracking motion.
Cnv_QueueLen Function	Returns the number of items in the specified conveyor's queue. Usage: Use this command to keep the robot waiting until the part (queue) enters the tracking area.
Cnv_QueueList	Displays a list of items in the specified conveyor's queue.
Cnv_QueueMove	Moves data from upstream conveyor queue to downstream conveyor queue. Usage: Use this command for the multi conveyor system.
Cnv_QueueReject	Sets / displays the minimum distance to prevent the double conveyors register. For details, refer to Cnv_QueueReject.
Cnv_QueueReject Function	Sets / returns and displays the queue reject distance for a conveyor.
Cnv_QueueRemove	Removes items from a conveyor queue.

Command	Description / Usage
Cnv_QueueUserData Function	Sets / returns and displays user data associated with a queue entry.
Cnv_RobotConveyor Function	Returns the conveyor being tracked by a robot.
Cnv_Speed Function	Returns the current speed of a conveyor.
Cnv_Trigger	Latches current conveyor position for the next Cnv_QueueAdd statement. Usage: Use this command when using the software trigger.
Cnv_Upstream Function	Returns the upstream limit for the specified conveyor.
Cnv_Upstream	Sets the upstream limit of the conveyor.

NOTE



To track a part as the conveyor moves, you must use Cnv_QueueGet in a motion command statement. For example:

```
Jump Cnv_QueueGet (1) ' this tracks the part
```

You cannot assign the result from Cnv_QueueGet to a point and then track it by moving to the point.

```
P1 = Cnv_QueueGet (1)
Jump P1 ' this does not track the part!
```

When you assign the result from Cnv_QueueGet to a point, the coordinate values correspond to the position of the part when the point assignment was executed.


16.11 Creating Conveyors in a Project

Conveyors are configured for each EPSON RC+ project. Up to 16 conveyors can be created per project. A conveyor is a logical entity that combines a robot with one or more conveyors.


There are two types of conveyors: vision and sensor. If you will be using a vision camera to find the parts on the conveyor, you must first create a vision sequence to find the parts. This vision sequence is required when you define the conveyor.

To add a conveyor to a project

1. Select [Tools]-[Conveyor Tracking] to open the [Conveyor Tracking] configuration dialog.



2. To add a conveyor, click the <Add> button. The following dialog will appear.



3. Enter a name for the conveyor, then specify the Robot #, Encoder #, Type, Motion, and Orientation.





- A default conveyor name is created automatically when a new conveyor is added. You can change the name as desired.
- When you use a straight conveyor, select “Line” for [Motion].
- When you use a circular conveyor, select “Circular” for [Motion].

16.12 Configuring Conveyors

After a conveyor has been created, you can set its parameters.

1. Select [Tools]-[Conveyor Tracking].
2. Click on the conveyor you want to change.
3. There are three setup pages shown in the tree under each conveyor: [General], [Preferences], [Upstream Limit], [Downstream Limit], and [Conveyor Z].
To change the [Upstream Limit] and [Downstream Limit], refer to *16.15 Pickup Area - Changing the Upstream / Downstream limits positions*.
To change the settings of Reject Distance and queue position data sort, click on [Preferences].
To change other parameters, click on [General].
4. Click on [General] or [Preferences].
The following dialog appears. Edit any of the configuration options.



5. Click <Apply> to save changes.



If you changed Robot #, Encoder #, Orientation, Type, or Vision Sequence, then you need to calibrate the conveyor again.

The following table explains the parameters you can edit in the [General] and [Preferences] pages.

Name	You can name conveyors. There is a restriction on the number of characters to be input. 1-byte characters: up to 15 characters 2-byte characters: up to 7 characters
Robot #	You can select a robot number from the robots currently configured in the controller.
Encoder #	You can select an encoder number from the encoders currently configured in the controller.
Type	Vision: Detects work pieces using vision search. Sensor: Detects work pieces using a sensor.
Motion	You can select the conveyor motion; Straight conveyor or Circular conveyor.
Orientation	When you selected Straight conveyor, you can specify if the conveyor is level or tilted. <Tilted> is selected by default and normally you don't have to change it. Tilted: Conveyor slope is detected during the calibration. Level: Conveyor slope is not detected during the calibration. You need to observe the following: The conveyor must be level with the robot X and Y planes.
Vision Sequence	Select a vision sequence for the calibration. This is only necessary when using the vision type.
Downstream Conveyor	When two or more conveyors have been set, you can select a conveyor number for the downstream conveyor.
Calibrate...	Click this button to execute the calibration. The calibration procedure is different for each type and conveyor orientation.
Adjust Z	After the calibration is completed, you can calibrate the Z coordinate value of the conveyor again.
Reject Distance	You can set a minimum distance to prevent the registration of duplicate conveyors. <ul style="list-style-type: none"> • The distance also can be set from the SPEL program using the Cnv_QueueReject command. • If the distance is different from the one set by Cnv_QueueReject command, the Cnv_QueueReject command setting has precedence.
Queue position data sorted on X axis	You can select whether to sort the queue or not.



After the calibration, change the parameters for Robot #, Encoder #, Type, Motion, Orientation, Vision Sequence, Adjust Z, and Upstream/Downstream limit.

16.13 Vision Conveyors

A vision conveyor uses a camera to locate parts that will be retrieved by one or more robots. In this section, instructions are provided for vision conveyor calibration.

The straight conveyor and the circular conveyor have different calibration methods.

Vision conveyor camera and lighting

It is important to choose the correct camera and lighting for the vision conveyors used in your application.

For applications with a slow moving conveyor and non-critical pick up constraints, you may be able to use a Vision Guide camera and simple lighting with no strobe.

For applications with fast moving parts, you will need to use a camera that is capable of asynchronous reset along with a strobe lamp. This method is more expensive.

If you are using multiple asynchronous reset cameras in multiple tasks, you must use SyncLock to lock the vision system during VRun and waiting until the picture is acquired.

For example:


```
SyncLock 1      ' Lock vision for this task
VRun FindPart
On strobe, .2
Do
    VGet FindPart.AcquireState, state
Loop Until state = 3
SyncUnlock 1    ' Unlock vision
```

Vision calibration sequence

Before you can calibrate a vision conveyor, you must first create a calibration sequence. This sequence is used by the system during the calibration process and must be linked to a camera calibration. The conveyor system commands use camera coordinates in millimeters. Although you can use any type of Vision Guide camera calibration, you only need to use a Standalone calibration.


The calibration sequence needs a sequence that uses one object for each work piece.

Place two work pieces on the conveyor as shown below.



It is recommended to place the two parts diagonally in the field of view. Also, the first object of a sequence must be taught with the robot as Part 1. The second object of a sequence must be taught with the robot as Part 2.

Also, the two parts can be anywhere in the field of view. However, to make it as easy as possible for operators to calibrate the conveyor, the parts that will be found in the vision sequence should be located such that part 2 is after part 1 in the direction of part flow. In the figure below, object 1 in the vision sequence is Corr01, which locates Part 1. Object 2 is Corr02, which locates Part 2.








When calibrating the vision conveyor tracking, pay attention to the followings to calibrate properly.

- Check the conveyor direction in the image display.
- In “teaching in the vision search area”, place the work 1 on the upstream side and the work 2 on the downstream side.
- Set the objects for detecting the work 1 and 2 in numerical order in the calibration sequence.

The orientation of the camera’s FOV displayed in the image display may differ from it actually looks. See the illustrations below. When the camera’s mounting direction is reversed, you need to pay attention to the positional relation of the work pieces and the vision objects.




Vision conveyor calibration (Straight conveyor)

Follow these steps to calibrate a straight vision conveyor:




- When teaching part positions with the robot during calibration, it is important to position X, Y, and Z of each point accurately. The conveyor is calibrated in X, Y, Z, U, V, and W.
- To perform the fine calibration, in the step 15 and 17, set as wide distance as possible between the upstream limit and downstream limit. After the calibration, adjust the Pickup Area by resetting the upstream / downstream limits.
- For the level orientation, it determines the conveyor height with the position of robot end effector taught in the step 12. It cannot be used for the tilted conveyor for it does not detect the conveyor slope. The steps 19 to 20 are not displayed.
- For the tilted orientation, it calibrates the conveyor slope with the position of robot end effector taught in the steps 12, 14, 16, 18, and 20.

1. Select [Tools]-[Conveyor Tracking].
2. Select the conveyor you want to calibrate.
3. Select <Vision> for the [Type].




4. Set the [Vision Sequence].
5. Click the <Apply> button.
6. Click the <Calibrate> button. The [Conveyor Tracking Calibration] wizard will appear. Follow the instructions for each step. Before you can proceed to the next step, you must click the <Teach> button. You can go back to previous steps using the <Back> button.
7. Select the [Part Flow Direction] to best match the conveyor you are calibrating. The instruction pictures will change according to the setting. [Part Flow Direction] is only used to aid in the instructions. It has no effect on the calibration.
8. Place two parts on the conveyor as shown in the figure in the wizard.
9. Check the live video in [Vision]. The camera orientation may not be the same as the picture.


10. Arrange the parts to be inside the range correctly and click <Teach> button. Use the camera video to ensure that the parts are within the correct search area for each.
11. Move the conveyor until both parts are within reach of the robot. Do not move the parts, only the conveyor. Click the <Jog & Teach> button.




12. The [Jog & Teach] dialog will appear. Click the jog buttons to move the robot end effector to the pick position for Part 1. Click the <Teach> button.




13. Click the <Jog & Teach> button.




14. The [Jog & Teach] dialog will appear. Click the jog buttons to move the robot end effector to the pick position for Part 2. Click the <Teach> button.



15. Now move or place the part at the upstream limit.
Click the <Jog & Teach> button.




16. The [Jog & Teach] dialog will appear. Click the jog buttons to move the robot end effector to the pick position. Click the <Teach> button.




16. Conveyor Tracking


17. Move the conveyor so the part is at the downstream limit. Do not move the part, only the conveyor. Click the <Jog & Teach> button.




18. The [Jog & Teach] dialog will appear. Click the jog buttons to move the robot end effector towards the part. Click the <Teach> button.




19. Place a part on one side of the conveyor near the downstream limit. This point is used to determine the tilt of the conveyor from side to side. Click the <Jog & Teach> button.



20. The [Jog & Teach] dialog will appear. Click the jog buttons to move the robot end effector to the part position. Click the <Teach> button.



21. The calibration complete picture will be displayed. Click the <Finish> button.



Vision conveyor calibration (Circular conveyor)

Follow these steps to calibrate a circular vision conveyor:




- When teaching part positions with the robot during calibration, it is important to position X, Y, and Z of each point accurately. The conveyor is calibrated in X, Y, Z, U, V, and W.
- To perform the fine calibration, in steps 13, 17, and 19, teach the position when the robot is directly above the parts 1 and set as wide a distance as possible between the points to be taught.

1. Select [Tools]-[Conveyor Tracking].
2. Select the conveyor you want to calibrate.
3. Select <Vision> for the [Type].
4. Select <Circular> for the [Motion].
5. Select the conveyor rotating direction for the [Direction].




Be careful not to calibrate with a wrong direction, otherwise, the robot will not track the parts.




6. Select the [Vision Sequence].
7. Click the <Apply> button.
8. Click the <Calibrate> button. The [Conveyor Tracking Calibration] wizard will appear. Follow the instructions for each step. Before you can proceed to the next step, you must click the <Teach> button. You can go back to previous steps using the <Back> button.
9. Check if the conveyor direction shown in the wizard is the same as the conveyor you want to use.
10. Place two parts on the conveyor as shown in the figure in the wizard.
11. Select the [Vision] tab to see live video. The camera orientation may not be the same as the picture.

16. Conveyor Tracking


12. Arrange the parts to be inside the range correctly and click the <Teach> button.




13. Move the conveyor until both parts are within reach of the robot. Do not move the parts, only the conveyor.




14. The [Jog & Teach] dialog will appear. Click the jog buttons to move the robot end effector to the pick position for Part 1. Click the <Teach> button.




15. Click the <Jog&Teach> button.




16. The [Jog & Teach] dialog will appear. Click the jog buttons to move the robot end effector to the pick position for Part 2. Click the <Teach> button.




17. Remove Part 2. Move the conveyor to move Part 1. Click the <Jog&Teach> button.




18. The [Jog & Teach] dialog will appear. Click the jog buttons to move the robot end effector to the pick position. Click the <Teach> button.




19. Move the conveyor by hand to move Part 1.
Click the <Jog&Teach> button.




20. The [Jog & Teach] dialog will appear. Click the jog buttons to move the robot end effector to the pick position. Click the <Teach> button.




21. Place a part on the upstream limit. Click the <Jog & Teach> button.




22. The [Jog & Teach] dialog will appear. Click the jog buttons to move the robot end effector to the pick position. Click the <Teach> button.




23. Move the conveyor so the part is on the downstream limit. Click the <Jog & Teach> button.



24. The [Jog & Teach] dialog will appear. Click the jog buttons to move the robot end effector to the pick position. Click the <Teach> button.



25. The calibration complete picture will be displayed. Click the <Finish> button.



Vision conveyor operation check

After the calibration, we recommend that you check if the vision conveyor works properly. Select the suitable method since the verification procedures vary depending on the system. This section uses the program and the command window described in *16.19 Sample Program*.

Method 1: When the conveyor can be stopped arbitrary and the conveyor speed can be 30 mm/sec or less

1. Clear the all queue data registered to the conveyor.
`>Cnv_QueueRemove 1,all`
2. Place the part in the vision search area.
3. Execute the program “ScanConveyorStrobed” to register a queue.
4. Halt the program “ScanConveyorStrobed” and move the conveyor until the part enters the Pickup Area.
5. Pick up the part.
 When using the 6-axis robot, set U, V, and W values as follows.
 When using the SCARA robot, setting of U, V, and W are not necessary.
`>Go Cnv_Queueget (1,0):U(90):V(0):W(180)`
6. Check if the robot end effector is above the center of the part.
7. Move the conveyor at 50mm/sec or less and check if the robot follows the part. At this point, the end effector will be off the center of part but this is no problem.
8. Stop the tracking motion of the robot.
`>Cnv_AbortTrack`

In case the following symptoms occur with the above method, the Vision Guide or conveyor calibration was not executed properly. Perform the calibration again.

- In step (6), the robot end effector is more than 1 mm away from the center of the part.
- The robot cannot follow the part when the conveyor is moved in step (7).

Method 2: When the conveyor can be stopped arbitrary and the conveyor speed can be 100 mm/sec or less

1. Clear the all queue data registered to the conveyor.
`>Cnv_QueueRemove 1,all`
2. Place the part in the vision search area.
3. Execute the program “ScanConveyorStrobed” to register a queue.
4. Halt the program “ScanConveyorStrobed” and move the conveyor until the part enters the Pickup Area.

5. Pick up the part.

When using the 6-axis robot, set U, V, and W values as follows.

When using the SCARA robot, setting of U, V, and W are not necessary.

```
>Go Cnv_Queueget (1,0):U(90):V(0):W(180)
```

6. Check if the robot end effector is above the center of the part.
7. Change the mode to “High Power”.

```
>Power High
```
8. Move the conveyor and check if the robot follows the part. At this point, the end effector will be off the center of the part but this is no problem.
9. Stop the tracking motion of the robot.

```
>Cnv_AbortTrack
```

In case the following symptoms occur with the above method, the Vision Guide or conveyor calibration was not executed properly. Perform the calibration again.

- In step (6), the robot end effector is more than 2 mm away from the center of the part.
- The robot cannot follow the parts when the conveyor is moved in step (8).

Method 3: When the conveyor can be stopped arbitrary

1. Clear the all queue data registered to the conveyor.

```
>Cnv_QueueRemove 1,all
```
2. Place the part in the vision search area.
3. Execute the program “ScanConveyorStrobed” to register a queue.
4. Halt the program “ScanConveyorStrobed” and move the conveyor until the part enters the Pickup Area.

5. Pick up the part.

When using the 6-axis robot, set U, V, and W values as follows.

When using the SCARA robot, setting of U, V, and W are not necessary.

```
>Go Cnv_Queueget (1,0):U(90):V(0):W(180)
```

6. Check if the robot end effector is above the center of the part.
7. Stop the tracking motion of the robot.

```
>Cnv_AbortTrack
```
8. Use the program “Main” to check if the robot follows the part. At this point, change the wait time after tracking to 0.2 ~ 0.5 in the sample program.

In case the following symptoms occur with the above method, the Vision Guide or conveyor calibration was not executed properly. Perform the calibration again.

- In step (6), the robot end effector is more than 1 mm away from the center of the part.
- The robot moves to different position from the parts in step (8).

Method 4: When the conveyor cannot be stopped and the speed cannot be changed arbitrary

1. Move the conveyor.
2. Change the sample program as follows.
Change the wait time after tracking to 0.2 ~ 0.5
Set the tracking mode to "0"
3. Execute the sample program "Main".
4. Place the part after the conveyor speed becomes constant.
5. Check if the robot follows the part.
6. Change the sample program as follows.
Set the tracking mode to "1".
7. Execute the sample program "Main".
8. Place the part when the conveyor speed becomes constant.
9. Check if the robot follows the part.

In case the following symptoms occur with the above method, the Vision Guide or conveyor calibration was not executed properly. Perform the calibration again.

- When comparing step (5) and (9), a distance between the robot and the part is smaller in step (5).
- The robot moves to different position from the parts in step (5).

16.14 Sensor Conveyors


Sensor conveyor calibration (Straight conveyor)

Follow these steps to calibrate a straight sensor conveyor:




- When teaching part positions with the robot during calibration, it is important to position X, Y, and Z of each point accurately. The conveyor is calibrated in X, Y, Z, U, V, and W.
- To perform the fine calibration, in steps 9 and 11, set as wide a distance as possible between the upstream limit and the downstream limit. After calibration, adjust the Pickup Area by resetting the upstream / downstream limits.
- For the level orientation, the conveyor height is determined by the position of the robot end effector taught in step 8. It cannot be used for the tilted conveyor for it does not detect the conveyor slope. Steps 19 to 20 are not displayed.
- For the tilted orientation, it calibrates the conveyor slope with the position of robot end effector taught in the steps 8, 10, 12, and 14.

1. Select [Tools]-[Conveyor Tracking].
2. Select the conveyor you want to calibrate.




3. Click the <Calibrate> button. The Conveyor Tracking Calibration wizard will appear.
4. Follow the instructions for each step. Before you can proceed to the next step, you must click the <Teach> button. You can go back to previous steps using the <Back> button.
5. Select the [Part Flow Direction] to best match the conveyor you are calibrating. The instruction pictures will change according to the setting. [Part Flow Direction] is only used to aid in the instructions. It has no effect on the calibration.


6. For the first wizard step, place a part on the conveyor and move the conveyor toward the sensor until the sensor just turns on. Click the <Teach> button.




7. Move the conveyor by hand until the part is within reach of the robot. Do not move the part itself, only the conveyor. Click the <Jog & Teach> button.




8. The Jog & Teach dialog will appear. Click the jog buttons to move the robot end effector to the pick position. Click the <Teach> button.




9. Now move or place the part at the upstream limit. Click the <Jog & Teach> button.




10. The Jog & Teach dialog will appear. Click the jog buttons to move the robot end effector to the pick position. Click the <Teach> button.




11. Move the conveyor so the part is at the downstream limit. Do not move the part, only the conveyor. Click the <Jog & Teach> button.




12. The [Jog & Teach] dialog will appear. Click the jog buttons to move the robot end effector to the pick position. Click the <Teach> button.




13. Place a part on one side of the conveyor near the downstream limit. This point is used to determine the tilt of the conveyor from side to side. Click the <Jog & Teach> button.



14. The [Jog & Teach] window will appear. Click the jog buttons to move the robot end effector to the pick position. Click the <Teach> button.



15. The calibration complete picture will be displayed. Click the <Finish> button.



Sensor Conveyor Calibration (Circular conveyor)


Follow these steps to calibrate a circular sensor conveyor:



- When teaching part positions with the robot during calibration, it is important to position X, Y, and Z of each point accurately. The conveyor is calibrated in X, Y, Z, U, V, and W.
- To perform the fine calibration, in steps 10, 12, and 14, teach the position when the robot is directly above the parts and set as wide a distance as possible between the points being taught.


1. Select [Tools]-[Conveyor Tracking].
2. Select the conveyor you want to calibrate.
3. Select <Sensor> for the [Type].
4. Select <Circular> for the [Motion].
5. Select the conveyor rotating direction for the [Direction].

Be careful not to calibrate with a wrong direction, otherwise, the robot will not track the parts.




6. Click the <Apply> button.
7. Click the <Calibrate> button. The [Conveyor Tracking Calibration] wizard will appear. Follow the instructions for each step. Before you can proceed to the next step, you must click the <Teach> button. You can go back to previous steps using the <Back> button.
8. Check if the conveyor direction shown in the wizard is the same as the conveyor you want to use.


9. Place a part on the conveyor and move the conveyor toward the sensor until the sensor just turns on. Click the <Teach> button.




10. Move the conveyor by hand to move the part. Click the <Jog & Teach> button.




11. The [Jog & Teach] dialog will appear. Click the jog buttons to move the robot end effector to the pick position. Click the <Teach> button.




12. Move the conveyor to move the part. Click the <Jog & Teach> button.




13. The [Jog & Teach] dialog will appear. Click the jog buttons to move the robot end effector to the pick position. Click the <Teach> button.




14. Move the conveyor to move the part. Click the <Jog & Teach> button.




15. The [Jog & Teach] dialog will appear. Click the jog buttons to move the robot end effector to the pick position. Click the <Teach> button.




16. Place a part on the upstream limit. Click the <Jog & Teach> button.




17. The [Jog & Teach] dialog will appear. Click the jog buttons to move the robot end effector to the pick position. Click the <Teach> button.




18. Move the conveyor so the part is at the downstream limit. Click the <Jog & Teach> button.



19. The Jog & Teach dialog will appear. Click the jog buttons to move the robot end effector to the pick position. Click the <Teach> button.



20. The calibration complete picture will be displayed. Click the <Finish> button.



Sensor conveyor operation check

After the calibration, we recommend that you check if the sensor conveyor works properly. Select the suitable method since the verification procedures vary depending on the system.

This section uses the program and the command window described in *16.19 Sample Program*.

Method 1: When the conveyor can be stopped arbitrary and the conveyor speed can be 30 mm/sec or less

1. Clear the all queue data registered to the conveyor.
`>Cnv_QueueRemove 1,all`
2. Detect the part using the sensor.
3. Execute the program "ScanConveyor" to register a queue.
4. Halt the program "ScanConveyor" and move the conveyor until the part enters the Pickup Area.
5. Pick up the part.

When using the 6-axis robot, set U, V, and W values as follows.

When using the SCARA robot, setting of U, V, and W are not necessary.

`>Go Cnv_Queueget (1,0):U(90):V(0):W(180)`

6. Check if the robot end effector is above the center of the part.
7. Move the conveyor at 50mm/sec or less and check if the robot follows the part. At this point, the end effector will be off the center of the part but this is no problem.
8. Stop the tracking motion of the robot.

`>Cnv_AbortTrack`

In case the following symptoms occur with the above method, the conveyor calibration was not executed properly. Perform the calibration again.

- In step (6), the robot end effector is more than 1 mm away from the center of the part.
- The robot cannot follow the part when the conveyor is moving in step (7).

Method 2: When the conveyor can be stopped arbitrary and the conveyor speed can be 100 mm/sec or less

1. Clear the all queue data registered to the conveyor.
`>Cnv_QueueRemove 1,all`
2. Detect the part using the sensor.
3. Execute the program "ScanConveyor" to register a queue.
4. Halt the program "ScanConveyor" and move the conveyor until the part enters the Pickup Area.

5. Pick up the part.

When using the 6-axis robot, set U, V, and W values as follows.

When using the SCARA robot, setting of U, V, and W are not necessary.

```
>Go Cnv_Queueget(1,0):U(90):V(0):W(180)
```

6. Check if the robot end effector is above the center of the part.
7. Change the mode to “High Power”.
8. Move the conveyor and check if the robot follows the part. At this point, the end effector will be off the center of the part but this is no problem.
9. Stop the tracking motion of the robot.

```
>Cnv_AbortTrack
```

In case the following symptoms occur with the above method, the conveyor calibration was not executed properly. Perform the calibration again.

- In step (6), the robot end effector is more than 2 mm away from the center of the part.
- The robot cannot follow the part when the conveyor is moving in step (8).

Method 3: When the conveyor can be stopped arbitrary

1. Clear the all queue data registered to the conveyor.
2. Detect the part using the sensor.
3. Execute the program “ScanConveyor” to register a queue.
4. Halt the program “ScanConveyor” and move the conveyor until the part enters the Pickup Area.
5. Pick up the part.

When using the 6-axis robot, set U, V, and W values as follows.

When using the SCARA robot, setting of U, V, and W are not necessary.

```
>Go Cnv_Queueget(1,0):U(90):V(0):W(180)
```

6. Check if the robot end effector is above the center of the part.
7. Stop the tracking motion of the robot.
8. Use the program “Main” to check if the robot follows the part. At this point, change the wait time after tracking to 0.2 ~ 0.5 in the sample program.

```
>Cnv_AbortTrack
```

In case the following symptoms occur with the above method, the conveyor calibration was not executed properly. Perform the calibration again.

- In step (6), the robot end effector is more than 1 mm away from the center of the part.
- The robot moves to a different position from the part in step (8).

Method 4: When the conveyor cannot be stopped and the speed cannot be changed arbitrary

1. Move the conveyor.
2. Change the sample program as follows.
Change the wait time after tracking to 0.2 ~ 0.5
Set the tracking mode to "0"
3. Execute the sample program "Main".
4. Place the part after the conveyor speed becomes constant.
5. Check if the robot follows the part.
6. Change the sample program as follows.
Set the tracking mode to "1".
7. Execute the sample program "Main".
8. Place the part when the conveyor speed becomes constant.
9. Check if the robot follows the part.


In case the following symptoms occur with the above method, the conveyor calibration was not executed properly. Perform the calibration again.

- When comparing step (5) and (9), the distance between the robot and the part is smaller in step (5).
- The robot moves to the different position from the parts in step (5).

16.15 Pickup Area

The Pickup Area is the range where the robot can pick up parts.


In the figure below, the robot can pick up the parts in gray.



If the Pickup Area is not appropriate, the robot cannot pick up parts. Follow the steps and cautions below to carefully set the Pickup Area.

To define the Pickup Area:

1. After calibration, the Pickup Area will be defined as shown in the following figure. Note that the positions of upstream limit and downstream limit depend on the positions you teach during the calibration.




2. Decide the upstream limit position.

The robot starts pickup from the line defined by the upstream limit. The Pickup Area from the upstream limit must be within the robot motion range. (See the figure below.)



The robot does not start pickup until parts cross the upstream limit. If you set the upstream limit in uppermost position, you can reduce the robot standby time.




3. Decide the downstream limit position.

Once the robot starts pickup, it continues its operation even over the downstream limit to complete the whole operation. Therefore, set the downstream limit in uppermost possible position so that the robot can operate within its motion range until it completes the operation. (See the figure below.)



The downstream limit position depends on the conveyor speed and robot position when it starts pickup. If the robot goes over the motion range during the operation, move the downstream limit to upper side.




Changing the Upstream / Downstream limits positions

To change the upstream limit and downstream limit positions, follow the steps below.


To change the Upstream Limit:

1. Select [Tools]-[Conveyor Tracking].
2. Select the conveyor you want to edit.
3. Click [Upstream Limit].
4. The dialog shown below appears.

To define the X1 value, enter a value directly or use Jog & Teach. Entering values directly is for fine adjustment.



5. When you directly specify the value, enter the value in the box and click <Apply>.
6. When you use Jog & Teach, click the <Teach> button.
7. The dialog shown below appears. Follow the directions as you do during calibration.



To change the downstream limit, click [Downstream Limit] and edit the value in the same way as the upstream limit.




NOTE

Upstream and downstream positions can be changed from the Spel program by using Cnv_Upstream and Cnv_Downstream commands.
(Diagonal upstream and downstream cannot be changed from the Spel program)

Diagonal Upstream / Downstream Limits

After the calibration, you can set the dividing lines for the Pickup Area (upstream limit / downstream limit) directed diagonally to the part flow.

When you change the dividing lines to diagonal positions, the Pickup Area also changes as shown below. The area indicated in gray is widened by changing the dividing lines to diagonal positions. In addition, diagonal dividing lines are called the diagonal upstream / downstream limits.



The following are the advantages you can get by widening the Pickup Area.

- Reduce robot standby time by widening the upper side Pickup Area.
- Less possibility of missing parts which flow longer after the downstream limit.




If there are too many parts on the conveyor for the robot to pick up, it only makes the robot move for longer distance and longer time and the number of parts the robot can pick up may decrease, even in a widened Pickup Area.

The robot capacity (how fast or how many parts robot can pick up) depends on the Pickup Area width, robot standby position, and conveyor speed.


To set the diagonal upstream limit:

1. Select [Tools]-[Conveyor Tracking].
2. Select the conveyor you want to edit.
3. Click on [Upstream Limit].
4. The dialog shown below appears.



Check the [Diagonal Limit] check box in [Upstream Limit] and click the <Apply> button.

The following dialog appears.




To define the values for X1, Y1, X2, Y2, enter the values directly or use Jog & Teach. Entering values directly is for fine adjustment.

5. When you directly specify the values, enter the values in the boxes and click the <Apply> button.

6. When you use Jog & Teach, click the <Teach> button.


The dialog shown below appears.




7. Place two parts on the conveyor.

Click the <Jog & Teach> button.


8. The [Jog & Teach] dialog appears. Click the jog buttons to move the robot end effector to the pick position. Click the <Teach> button.



9. The dialog shown below appears. Click the <Jog & Teach> button.




10. The [Jog & Teach] dialog appears. Click the jog buttons to move the robot end effector to the pick position. Click the <Teach> button.



To set the diagonal downstream limit, click [Downstream Limit] to display the downstream limit setting page and check the [Diagonal Limit] check box, then click the <Apply> button.

The following dialog appears. Click the <Teach> button and follow the directions in the wizard.



Note that the “Error 4415” occurs when the diagonal upstream / downstream limits are defined as in the following cases.

- They are perpendicular to the part flow direction.
- They are parallel to the part flow direction.
- The diagonal upstream limit and downstream limit cross on the conveyor.

16.16 Adjusting the Z value

You can adjust the conveyor Z value after the calibration is completed.

Adjusting the Z value is a function to change the work pickup height that has been determined during calibration.


In the following cases, adjust the Z value:

- To use a pickup area that is different from the one defined during calibration.
- The tool has been changed on the robot after calibration.


To adjust the Z value:

1. Select [Tools]-[Conveyor Tracking].
2. Select the conveyor you want to edit.
3. Click on [Conveyor Z].
4. The dialog shown below appears.


Click on <Teach>.



5. The dialog shown below appears.
- Place a part on the conveyor in the robot motion range.
- Click on the <Jog & Teach> button.



6. The [Jog & Teach] dialog will appear. Click the jog buttons to move the robot end effector to the pick position.
- Click the <Teach> button.




16.17 Queue Sorting

When you set the queue sorting, it registers the queue data in the order of position along the X axis in the conveyor local coordinate system.

Set 0 for the index number of Cnv_QueGet command. If you set nothing, the robot picks up parts from the downstream side.

To set the queue sorting

1. Select [Tools]-[Conveyor Tracking].
2. Click the conveyor you want to configure and select the [Preferences].



3. Set the [Queue position data sorted on X axis] checkbox.
4. Click the <Apply> button.



When you set a diagonal upstream limit, register the queue data in the order of entering the Pickup Area.

Also, when you set a diagonal upstream limit, note that the queue sorting cannot be canceled.




The queue sorting function is applied to both upstream and downstream conveyors.

16.18 Cnv_QueReject

Cnv_QueReject avoids registering the same part doubly. If Cnv_QueReject value is not changed from the default (0), the robot may perform the pickup motion at the position where the part is not placed, since the same part is registered to the queue several times.

Cnv_QueReject can be set by using the command or by following the steps below.

1. Select [Tools] – [Conveyor Tracking].
2. Click the conveyor to set. Select [Preferences].



3. Set the value to [Reject Distance].
4. Click the <Apply> button.



If “Cnv_QueReject” is used in the program, the value set for “Cnv_QueReject” will be used instead of the value set in the above step.

16.19 Sample Program

Vision conveyor programming

Typically, two tasks are used to operate a vision conveyor. One task finds parts with the vision system and adds them to the conveyor queue.

The other task checks for parts in the Pickup Area of the conveyor queue. When a part is in the Pickup Area, the robot is commanded to pick up the part and place it to the specified position.

The following example shows two tasks. The scanning task uses the vision system to find parts and add them to the conveyor queue. There are two examples for the scanning task. “ScanConveyorNonStrobed” does not use a strobe lamp and hardware trigger. In this case, “Cnv_Trigger” must be called before running the vision sequence.

“ScanConveyorStrobed” uses a strobe lamp and hardware conveyor trigger. “PickParts” waits for parts to be present in the Pickup Area and commands the robot to pick and place each part.

If you are using an asynchronous reset camera and strobe, then the strobe trigger should also be wired to the trigger on the PG board. In this case, the vision sequence “RuntimeAcquire property” must be set to “Strobed”.

The following program is a sample with Conveyor #1.

This sample program automatically recovers when the robot tracks the work piece that is out of the tracking area.

```
Function main
    Xqt ScanConveyorStrobed      ' Task that registers queues
    Xqt PickParts                ' Task that tracks parts (queue)
Fend

Function ScanConveyorNonStrobed
    Integer i, numFound
    Real x, y, u
    Boolean found
    Cnv_OffsetAngle 1,xx        ' Command used for only circular conveyors
                                ' Adjust the tracking error with an offset value in xx

    ' Turn OFF the camera shutter and I/O (conveyor trigger)
    Off trigger; Off Cv_trigger
    Do
        ' Search for parts on the conveyor
        VRun FindParts
        ' Turn ON the camera shutter and I/O (conveyor trigger)
        On Trigger; On Cv_Trigger
    Do
        VGet FindParts.AcquireState, state
        Loop Until state = 3
        VGet FindParts.Parts.NumberFound, numFound
        ' Register the part that has been shot as a queue
        For i = 1 to numFound
            VGet FindParts.Parts.CameraXYU(i), found, x, y, u
```

```

        Cnv_QueueAdd 1, Cnv_Point(1, x, y)
    Next i
    'Turn OFF the camera shutter and I/O (conveyor trigger)
    Off Trigger; Off Cv_Trigger
    Wait .1
Loop
Fend

Function PickParts
    OnErr GoTo ErrHandler
    Integer ErrNum
    'Select the tracking mode
    Cnv_Mode 1,1
    WaitParts:
    Do
        'Wait until a part (queue) enters the Pickup Area
        Wait Cnv_QueueLen(1, CNV_QUELEN_PICKUPAREA) > 0
        'Start tracking the parts
        'When using the 6-axis robot
        Jump3 place_1, Cnv_QueueGet(1):Z(**):U(90):V(0):W(180),
            Cnv_QueueGet(1):U(90):V(0):W(180)
        'When using the SCARA robot
        Jump Cnv_QueueGet(1)
        On gripper
        'Set the time necessary for the robot to pick up the part
        Wait .1 'The robot moves at the same speed as the conveyor
            'for the Wait time specified to this part.
        'Move the picked part to a specified place
        Go place_2
        Off gripper
        'Set the time necessary for the robot to release the part
        Wait .1
        'Clear the picked part (queue)
        Cnv_QueueRemove 1, 0
    Loop
    'Clear the parts (queue) in the downstream side from the Pickup Area
    'Automatically recovers from the error
    '“The specified queue data is outside the set area”
ErrHandler:
    ErrNum = Err
    If ErrNum = 4406 Then
        Cnv_QueueRemove 1, 0
        EResume WaitParts
        'Displays the error other than
        '“The specified queue data is outside the set area”
    Else

```

```

        Print "Error!"
        Print "No.", Err, ":", ErrMsg$(Err)
        Print "Line :", Erl(0)
        'User error occurred
        Error 8000
    EndIf
Fend

```

NOTE


When you use the strobe light and software trigger, use the “ScanConveyorStrobed” function shown below.

```

Function ScanConveyorStrobed
    Integer i, numFound, state
    Real x, y, u
    Boolean found
    Cnv_OffsetAngle 1,xx      ' Command used only for circular conveyors
                                'Adjust the tracking error with an offset value in xx
    'Turn OFF the camera shutter
    Off trigger
    Do
        ' Search for parts on the conveyor
        VRun FindParts
        'Turn ON the camera shutter
        On Trigger
        Do
            VGet FindParts.AcquireState, state
        Loop Until state = 3
        Cnv_Trigger 1          'Latch the encoder with software trigger
        VGet FindParts.Parts.NumberFound, numFound
        'Register the part that has been shot as a queue
        For i = 1 to numFound
            VGet FindParts.Parts.CameraXYU(i), found, x, y, u
            Cnv_QueueAdd 1, Cnv_Point(1, x, y)
        Next i
        'Turn OFF the camera shutter
        Off Trigger
        Wait .1
    Loop
Fend

```

NOTE


If the asynchronous reset mode is not used, “ScanConveyorStrobed” is as follows.

```

Function ScanConveyorNonStrobed
    Integer i, numFound
    Real x, y, u
    Boolean found
    Cnv_OffsetAngle 1,xx      'Command used only for circular conveyors
                                'Adjust the tracking error with an offset value in xx
    Do
        Cnv_Trigger 1          'Latch the encoder with software trigger
        'Search for parts on the conveyor

```

```
VRun FindParts
VGet FindParts.Parts.NumberFound, numFound
`Register the part that has been shot as a queue
For i = 1 to numFound
    VGet FindParts.Parts.CameraXYU(i), found, x, y, u
    Cnv_QueueAdd 1, Cnv_Point(1, x, y)
Next i
Wait .1
Loop
Fend
```

Sensor conveyor programming

Typically, two tasks are used to operate a sensor conveyor. One task waits for a part to trip the sensor and add it to the conveyor queue. The other task checks for parts in the Pickup Area of the conveyor queue. When a part is in the Pickup Area, the robot is commanded to pick up the part and place it to the specified position.

This sample program automatically recovers when the robot tracks the work piece that is out of the tracking area.

```

Function main
    Xqt ScanConveyor      ' Task that registers queues
    Xqt PickParts         ' Task that tracks parts (queue)
Fend

Function ScanConveyor
    Double lpulse1        ' Previous latch pulse
    lpulse1 = Cnv_LPulse(1) ' Register the latch pulse as lpulse1
    Do
        ' Register a part as a queue only when it passes the sensor
        If lpulse1 <> Cnv_LPulse(1) Then
            Cnv_QueueAdd 1, Cnv_Point(1, 0, 0)
            lpulse1 = Cnv_LPulse(1) ' Update lpulse1
        EndIf
    Loop
Fend

Function PickParts
    OnErr GoTo ErrHandler
    Integer ErrNum
    'Select teh tracking mode
    Cnv_Mode 1,1
    WaitParts:
    Do
        ' Wait until a part (queue) enters the Pickup Area
        Wait Cnv_QueueLen(1, CNV_QUELEN_PICKUPAREA) > 0
        'Start tracking the parts
        'When using the 6-axis robot
        Jump3 place_1, Cnv_QueueGet(1):Z(**):U(90):V(0):W(180),
            Cnv_QueueGet(1):U(90):V(0):W(180)
        ' When using the SCARA robot
        Jump Cnv_QueueGet(1)
    On gripper
        ' Set the time necessary for the robot to pick up the part
        Wait .1 ' The robot moves at the same speed as the conveyor
            ' for the Wait time specified to this part.
        ' Move the picked part to a specified place

```



```

        Go place_2
        Off gripper
        'Set the time necessary for the robot to release the part
        Wait .1
        'Clear the picked part (queue)
        Cnv_QueueRemove 1, 0
    Loop
    'Clear the parts (queue) in the downstream side from the Pickup Area
    'Automatically recovers from the error
    '“The specified queue data is outside the set area”
ErrorHandler:
    ErrNum = Err
    If ErrNum = 4406 Then
        Cnv_QueueRemove 1, 0
        EResume WaitParts
    'Displays the error other than
    '“The specified queue data is outside the set area”
    Else
        Print "Error!"
        Print "No.", Err, ":", ErrMsg$(Err)
        Print "Line :", Erl(0)
        'User error occurred
        Error 8000
    EndIf
Fend

```

16.20 Multiple Conveyors


EPSON RC+ 7.0 supports multiple logical conveyors and robots. You can use multiple robots with one conveyor.

This section describes a conveyor system that uses one robot with two or more conveyors.

Conveyor tracking for several conveyors

This section describes a conveyor system where one robot picks up “Part 1” from Conveyor 1 and puts the picked parts above “Parts 2” on Conveyor 2 as shown in the figure below.


In this conveyor system, each conveyor needs one encoder and camera (sensor).



How to use several conveyors

The usage of several conveyors is described below.

1. Refer to *16.11 Creating Conveyors in a Project* and create Conveyor 1 and Conveyor 2. (Set the robot in the upstream side to the Conveyor 1.)
2. For the [Encoder] and [Vision Sequence], set the different number and sequence for each conveyor 1 and 2.



3. Calibrate Conveyor 1.
4. Refer to *16.13 Vision Conveyors* or *16.14 Sensor Conveyors* and check the conveyor operation.
5. Calibrate Conveyor 2.
6. Check the operation of Conveyor 2.

The following program is a sample.

This sample program automatically recovers when the robot tracks the work piece that is out of the tracking area.

```
Function main
```

```
    'Task that registers parts in the queues
```

```
    Xqt ScanConveyorStrobed
```

```
    'Task that tracks parts (queue)
```

```
    Xqt PickParts
```

```
End
```

```
Function ScanConveyorStrobed
```

```
    Integer i, j, numFound, state
```

```
    Real x, y, u
```

```
    Boolean found
```

```
    'Turn OFF the camera shutter and I/O (conveyor trigger)
```

```
    'Cv_trigger1: Conveyor 1, Cv_trigger2: Conveyor 2
```

```
    Off trigger; off Cv_trigger1; off Cv_trigger2
```

```
    Do
```

```
        'Register the parts (queue) of the Conveyor 1
```

```
        'Search for a part on the conveyor
```

```
        VRun FindParts1
```

```
        'Turn ON the camera shutter and I/O (conveyor trigger)
```

```
On Trigger; On Cv_Trigger1
Do
    VGet FindParts1.AcquireState, state
Loop Until state = 3
VGet FindParts1.Parts.NumberFound, numFound
' Register the part that has been shot as a queue
For i = 1 to numFound
    VGet FindParts.Parts.CameraXYU(i), found, x, y, u
    Cnv_QueueAdd 1, Cnv_Point(1, x, y)
Next i
' Turn OFF the camera shutter and I/O (conveyor trigger)
Off Trigger; Off Cv_Trigger
Wait .1

' Register the parts (queue) of the Conveyor 2
' Search for part on the conveyor
VRun FindParts2
' Turn ON the camera shutter and I/O (conveyor trigger)
On Trigger; On Cv_Trigger1
Do
    VGet FindParts2.AcquireState, state
Loop Until state = 3
VGet FindParts2.Parts.NumberFound, numFound
' Register the part that has been shot as a queue
For j = 1 to numFound
    VGet FindParts2.Parts.CameraXYU(j), found, x, y, u
    Cnv_QueueAdd 2, Cnv_Point(2, x, y)
Next j
' Turn OFF the camera shutter and I/O (conveyor trigger)
Off Trigger; Off Cv_Trigger2
Wait .1

Loop
Fend

Function PickParts
OnErr GoTo ErrHandler
Integer ErrNum
MemOff 1
MemOff 2
Do
    ' Tracking of Conveyor 1
    WaitPickup1:
    ' Turn ON the memory I/O when the Conveyor 1 tracking phase starts
    MemOn 1
```

```

' Clear the parts (queue) in the downstream side from the downstream limit
Do While Cnv_QueLen(1, CNV_QUELEN_DOWNSTREAM) > 0

    Cnv_QueRemove 1, 0
Loop
' Move to the standby position when there is no part (queue) in the Pickup Area
If Cnv_QueLen(1, CNV_QUELEN_PICKUPAREA) = 0 Then
    Jump place
EndIf
' Wait until a part (queue) enters the Pickup Area
Wait Cnv_QueLen(1, CNV_QUELEN_PICKUPAREA) > 0
' Start tracking the parts
Jump Cnv_QueGet(1)
On gripper
Wait .1
' Clear the picked part (queue)
Cnv_QueRemove 1, 0
' Finish the Conveyor 1 tracking phase
MemOff 1

' Tracking of the Conveyor 2
WaitPickup2:
' Start the Conveyor 2 tracking phase
MemOn 2
' Clear the parts (queue) in the downstream side from the downstream limit
Do While Cnv_QueLen(2, CNV_QUELEN_DOWNSTREAM) > 0

    Cnv_QueRemove 2, 0
Loop
' Move to the standby position when there is no part (queue) in the Pickup Area
If Cnv_QueLen(2, CNV_QUELEN_PICKUPAREA) = 0 Then
    Jump place
EndIf
' Wait until a part (queue) enters the Pickup Area
Wait Cnv_QueLen(2, CNV_QUELEN_PICKUPAREA) > 0
' Start tracking the parts
Jump Cnv_QueGet(2)
Off gripper
Wait .1
' Clear the picked part (queue)
Cnv_QueRemove 2, 0
' Finish the Conveyor 2 tracking phase
MemOff 2
Loop
' Clear the parts (queue) in the downstream side from the Pickup Area
' Automatically recovers from the error

```

```
' "The specified queue data is outside the set area"
ErrorHandler:
  ErrNum = Err
  If ErrNum = 4406 Then
    If MemSw(1) = On Then
      Cnv_QueueRemove 1
      EResume WaitPickup1
    EndIf
    If MemSw(2) = On Then
      Cnv_QueueRemove 2
      EResume WaitPickup2
    EndIf
    ' Automatically recovers from the error
    ' "The specified queue data is outside the set area"
  Else
    Print "Error!"
    Print "No.", Err, ":", ErrMsg$(Err)
    Print "Line :", Erl(0)
    ' User error occurred
    Error 8000
  EndIf
Fend
```

16.21 Multi-robot Conveyor


EPSON RC+ supports multiple logical conveyors and robots. You can use multiple robots with one conveyor, or multiple robots with multiple conveyors.

This section describes a conveyor system that uses two or more robots with one conveyor and a conveyor system that uses one robot with two or more conveyors.

Multi-robot conveyor

The multi-robot system uses two or more robots with one conveyor as shown below. In this system, the second robot (downstream) picks up the parts that the first robot (upstream) failed to pick up.


Although the system uses several robots, it uses only one camera (sensor), encoder, and conveyor.




How to use multi-robot conveyor

To use the multi-robot conveyors, set the upstream and downstream conveyors. Instructions for using multi-robot conveyors are described below.

1. Refer to *16.11 Creating Conveyors in a Project* and create conveyors 1 and 2. (Set the upstream-side robot to Conveyor 1.)
2. For [Encoder] and [Vision Sequence], set the same number and sequence for both conveyors 1 and 2.



3. Calibrate Conveyor 1.
4. Refer to the section *operation check* in *16.13 Vision Conveyors* or *16.14 Sensor Conveyors* and check the conveyor operation.
5. Set [Downstream Conveyor] to “2”.



6. Calibrate Conveyor 2.
7. Check the operation of Conveyor 2.
 - (7)-1 Clear the all queue data registered to each conveyor.


```
>Cnv_QueueRemove 1,all
```

```
>Cnv_QueueRemove 2,all
```
 - (7)-2 Place the part in the vision search area.
 - (7)-3 Execute the program “ScanConveyorStrobed(ScanConveyor)” and register a queue.
 - (7)-4 Halt the program “ScanConveyorStrobed” and move the conveyor until the part enters the Pickup Area.

- (7)-5 Stop the program “ScanConveyorStrobed” and move the conveyor until the part enters the Pickup Area of the conveyor 2.
- (7)-6 Execute the command below to move the queue from conveyor 1 to conveyor 2.
`>Cnv_QueueMove 1,0`
- (7)-7 Pick up the part.
`>Jump Cnv_Queueget (2)`
- (7)-8 Check if the robot end effector is above the center of a part. If the robot end effector is not above the center of the part, perform the calibration again.
- (7)-9 Move the conveyor and check if the robot follows the part. At this point, the end effector will be off the center of part but this is not a problem.
- (7)-10 Stop the tracking motion.
`>Cnv_AbortTrack`

8. The following is a sample program.

```

Function main
  Xqt ScanConveyorStrobed      'Task that registers queues
  'Task for the upstream robot to track the parts (queue)
  Xqt PickParts1
  'Task for the downstream robot to track the parts (queue)
  Xqt PickParts2
Fend

Function ScanConveyorStrobed
  Integer i, numFound, state
  Real x, y, u
  Boolean found
  'Turn OFF the camera shutter and I/O (conveyor trigger)
  Off trigger; off Cv_trigger
  Do
    'Search for a part on the conveyor
    VRun FindParts
    'Turn ON the camera shutter and the I/O (hardware conveyor trigger)
    On Trigger; On Cv_Trigger
    Do
      VGet FindParts.AcquireState, state
    Loop Until state = 3
    VGet FindParts.Parts.NumberFound, numFound
    'Register the found part to the queue of conveyor 1
    For i = 1 to numFound
      VGet FindParts.Parts.CameraXYU(i), found, x, y, u
      Cnv_QueueAdd 1, Cnv_Point(1, x, y)
    Next i
    'Turn OFF the camera shutter and the I/O (hardware conveyor trigger)
    Off Trigger; Off Cv_Trigger

```

```
        Wait .1
    Loop
Fend

Function PickParts1
    OnErr GoTo ErrHandler
    Integer ErrNum
    WaitParts:
    Do
        ' Wait until a part (queue) enters the Pickup Area
        Wait Cnv_QueueLen(1, CNV_QUELEN_PICKUPAREA) > 0
        ' Start tracking the part
        Jump Cnv_QueueGet(1)
        On gripper
        Wait .1
        ' Move the picked part to a specified place
        Jump place
        Off gripper
        Wait .1
        ' Clear the picked part (queue)
        Cnv_QueueRemove 1, 0
    Loop
    ' Move the parts (queue) in the downstream side than the Pickup Area of conveyor 1
    ' to the conveyor 2
ErrHandler:
    ErrNum = Err
    If ErrNum = 4406 Then
        Cnv_QueueMove 1, 0
        EResume WaitParts
        ' When an error except the conveyor tracking motion range error occurs,
        ' display the error
    Else
        Print "Error!"
        Print "No.", Err, ":", ErrMsg$(Err)
        Print "Line :", Erl(0)
        ' User error occurred
        Error 8000
    EndIf
Fend
```

```

Function PickParts2
    OnErr GoTo ErrHandler
    Integer ErrNum
    WaitParts:
    Do
        ' Wait until a part (queue) enters the Pickup Area
        Wait Cnv_QueueLen(2, CNV_QUELEN_PICKUPAREA) > 0
        ' Start tracking the part
        Jump Cnv_QueueGet(2)
        On gripper
        Wait .1
        ' Move the picked part to a specified place
        Jump place
        Off gripper
        Wait .1
        ' Clear the picked part (queue)
        Cnv_QueueRemove 2, 0
    Loop
    ' Clear the parts (queue) in the downstream side than the Pickup Area of conveyor 2
    ' Automatically recovers from the error
    ' "The specified queue data is outside the set area"
    ErrHandler:
        ErrNum = Err
        If ErrNum = 4406 Then
            Cnv_QueueRemove 2, 0
            EResume WaitParts
        ' When an error except "The specified queue data is outside the set area"
        ' occurs, display the error
        Else
            Print "Error!"
            Print "No.", Err, ":", ErrMsg$(Err)
            Print "Line :", Erl(0)
            ' User error occurred
            Error 8000
        EndIf
    Fend

```

16.22 Abort Tracking

There are some situations when you want to abort tracking a part that moves out of the Pickup Area while the robot is tracking the part. In this case, use the `Cnv_AbortTrack` command in a separate task that monitors the conveyor queue.

```
Function MonitorDownstream
  Robot 1
  Do
    If Cnv_QueueLen(1, CNV_QUELEN_DOWNSTREAM) > 0 Then
      Cnv_AbortTrack 0
    EndIf
    Wait .1
  Loop
Fend
```

16.23 Conveyor Tracking with 6-Axis Robot

When you use a 6-axis robot in a conveyor tracking system, you need to set the values of U, V, and W. For this, use the `Cnv_QueueGet` command.

The following shows the case where the robot end effector moves toward a part during the pickup.

```
Go Cnv_QueueGet (Conveyor number, [Index]) :U(90):V(0):W(180)
```

To use the `Jump3` command, write a program as follows:

```
Jump3 P1,Cnv_QueueGet(1):Z(**):U(90):V(0):W(180),
      Cnv_QueueGet(1):U(90):V(0):W(180)
```



P1 and Z(**) height should be the same.

The followings are points to be known before setting the Z(**) height.

- Home position of Z in the tracking coordinate is the calibration position.
- To raise the Z height in the tracking coordinate, offset in a positive (+) direction.
- To lower the Z height in the tracking coordinate, offset in a minus (-) direction.
- Robot coordinate P1 can be converted to the conveyor coordinate and displayed.

```
> print P1@cnv1
```

16.24 Tracking Mode

There are two tracking modes: picking quantity-priority mode and picking accuracy-priority mode. The mode can be selected by the Cnv_Mode command.

Tracking mode selection is only available for linear conveyors. For circular conveyors, the picking quantity-priority mode is only available.

Picking quantity-priority mode

Picking quantity-priority mode prioritizes reducing time to catch up with the work piece (queue) over the picking accuracy. This mode is suitable for the conveyor tracking system in which space between the work pieces is narrow.



When the picking quantity-priority mode is selected, tracking delay (situation in which the Manipulator does picking motion at the posterior part of the work piece to the direction of the conveyor motion) may occur. If the tracking delay occurs, write the program as follows.

```
Go Cnv_Queueget (Conveyor number, [Index]) + X (**)
```

Picking accuracy-priority mode

Picking accuracy-priority mode improves the picking accuracy while it takes more time to catch up with the work piece. This mode is suitable for the conveyor tracking system for small work pieces.

Picking accuracy-priority mode should be used for the conveyors of 350 mm/sec or less.



When the conveyor of 350 mm/sec or more is used, the tracking mode will be picking quantity-priority mode regardless of the setting of Cnv_Mode.



Although the tracking delay does not occur in the picking accuracy-priority mode, the Manipulator may slide to the direction of the conveyor motion in Go, Move, or Jump3 motions after the downward motion of the Z-axis. If this occurs, take following countermeasures (these may not be effective for Go and Move motions)

- For Go motion: Change to Jump motion. Or, reduce the values of Accel and Speed.
- For Move and Jump3 motions: Reduce the values of AccelS and SpeedS.

16.25 How to shorten the picking cycle time

There are following two methods to shorten the picking cycle time.

- Use the Arch command
- Use the Cnv_Accel command



The followings are the points to consider when using the Cnv_Accel command.

- Maximum Cnv_Accel value is 5000 mm/sec².
- If the Cnv_Accel setting value is 0 or exceeds 5001, the default value (2000 mm/sec²) will be set.
- If the acceleration error occurs, greater Cnv_Accel value cannot be specified. Decrease the Cnv_Accel value or decrease Accel or AccelS.
- When Cnv_Accel is used in the picking accuracy-priority mode, the manipulator may slide to the direction of the conveyor motion after the downward motion of the Z-axis.

16.26 Manipulator Posture

Manipulator posture during the tracking motion is always the default posture regardless of the posture at the conveyor tracking calibration. To specify the posture for the tracking, write a program as follows.

Example: tracks the work piece with Lefty arm position

```
jump Cnv_Queget(Conveyor number,[Index])/L
```



During tracking motion, singularity avoiding function cannot be used. Therefore, set the positions of the Manipulator and the conveyor so that the Manipulator does not pass through the singularity.

16.27 Tracking Abort Line

The tracking abort lines can be configured after the calibration. These lines can be placed straight or diagonally between the downstream limit and the robot's motion range as shown below.


The tracking abort lines cancel or abort the robot's tracking motion in following cases:


- When it is predicted before the robot starts tracking that it catches up the work piece downstream than the abort tracking line.
- When the work piece passes the tracking abort line after the robot starts the tracking motion. Also, the hand rises if a distance between the work piece and the end of the robot (tool) is shorter than a certain value. (the height can be specified)



Set the tracking abort line within the robot's motion range since the robot aborts the tracking motion when the work piece being tracked passes the line.

If errors such as the out of motion range error occurs even though the tracking abort line is set, set the line more upstream than the current position.






How to set a tracking abort line

Set a tracking abort line in the following way.


1. Select [Tools] - [Conveyor Tracking].
2. Select the conveyor to configure.
3. Select [Track Abort Line].
4. Check the [Enable tracking abort line] checkbox.
5. If you want to enable the diagonal tracking abort line, check the [Diagonal Track Abort Line] checkbox.
6. Click <Teach>. The GUI will be displayed.



How to set the Z rising height

The default rising height during tracking abort is 10 mm. The setting can be changed by the following steps.

1. Select [Tools] - [Conveyor Tracking].
2. Select the conveyor to configure.
3. Select [Track Abort Line].
4. Set the rising height and click <Apply>.



NOTE If the out of motion range error occurs while the hand rises, decrease the rising height.

How to check the tracking abort state

Tracking abort state can be checked by using the Cnv_Flag command.

If the return value for Cnv_Flag is as follows, take the countermeasures as described below.

If the return value is 0:

Tracking motion was completed.

If the return value is 1:

Tracking motion was canceled.

The downstream limit position is not proper. Set the downstream limit more upstream than the current position.

If the return value is 2:

Tracking motion was aborted.

The downstream limit position or the robot's waiting position is not proper. Set the downstream limit more upstream than the current position, or set the robot's waiting position closer to the downstream limit.

If the return value is 3:

Tracking motion was aborted.

The downstream limit position or the picking time is not proper. Set the downstream limit more upstream than the current position, or shorten the picking time.

If the return value is 4:

Cancel the tracking motion.

The robot tracked the work piece that is out of the tracking area. Pickup failure is occurring. To reduce the missed work pieces, take the following measures.

- Reduce the number of work pieces
- Increase the acceleration by Cnv_Accel
- Set the downstream conveyor



NOTE When the tracking motion is canceled or aborted, the program executes the next command without stopping.

Program

If the tracking abort line is configured, the error 4406 does not occur. When you set the tracking abort line, use Cnv_Flag as in the following program. Do not use this program when the abort line is not used.



Use the program 2 after the downstream limit is configured in the program 1 and Cnv_Flag do not return 2 and 3.



When using the program 1, the robot can operate without an error even though the downstream setting is not adequate since the robot aborts the tracking motion. However, abort of tracking increases the cycle time. It is recommended to adjust the downstream line if you are using the program 1.

Program 1

```
Function RB1
  Double OffX, OffY, ZPick
  ' Handling offset value
  OffX = 0
  OffY = 0
  ZPick = 0
  'Move to the waiting position
  Jump P0
  Do
    'Wait until the work piece passes the upstream limit
    Wait Cnv_QueueLen(1, CNV_QUELEN_PICKUPAREA) > 0
    Jump Cnv_QueueGet(1) +X(OffX) +Y(OffY) -Z(ZPick)      ' Start tracking

    If Cnv_Flag(1) = 0 Then
      On Vacuum1      'Vacuum ON
      Wait 0.1

      'Abort tracking since the work piece passes the tracking abort line during the picking
      If Cnv_Flag(1) = 3 Then
        Jump P2      'Move to the position to release the pickup-failed work piece
        Off Vacuum1  'Release the work piece
        Wait 0.1
        Jump P0      'Move to the waiting position

      'Pick up the work piece
      Else
        Cnv_QueueRemove 1, 0      'Delete the picked queue
        Jump P1      'Move to the position to release the work piece
        Off Vacuum1      'Release the work piece
        Wait 0.1
      EndIf

      'Cancel the tracking motion since the work piece passes the tracking abort line
      'during tracking
      ElseIf Cnv_Flag(1) = 1 Then
        Cnv_QueueRemove 1, 0      'Delete the queue data

      'Abort the tracking motion since the work piece passed the tracking abort line

      ElseIf Cnv_Flag(1) = 4 Then
        Cnv_QueueRemove 1, 0      'Delete the queue data

      'Abort the tracking motion since the work piece passed the tracking abort line
      'during tracking
      ElseIf Cnv_Flag(1) = 2 Then
        Cnv_QueueRemove 1, 0      'Delete the queue data
        Jump P0      'Move to the waiting position
```

```

    EndIf
  Loop
Fend

```

Program 2

```

Function RB1
  Double OffX, OffY, ZPick
  'Handling offset value
  OffX = 0
  OffY = 0
  ZPick = 0
  'Move to the waiting position
  Jump P0
  Do
    'Wait until the work piece passes the upstream limit
    Wait Cnv_QueLen(1, CNV_QUELEN_PICKUPAREA) > 0
    Jump Cnv_QueGet(1) +X(OffX) +Y(OffY) -Z(ZPick)    'Start tracking

    If Cnv_Flag(1) = 0 Then
      On Vacuum1                                'Vacuum ON
      Wait 0.1
      Cnv_QueRemove 1, 0                        'Delete the picked queue
      Jump P1                                  'Move to the position to release the work piece
      Off Vacuum1                              'Release the work piece
      Wait 0.1

      'Cancel the tracking motion since the work piece passes the tracking abort line
      'during tracking
      ElseIf Cnv_Flag(1) = 1 Then
        Cnv_QueRemove 1, 0                      'Delete the queue data

        'Cancel the tracking motion since the robot tracked the work piece
        'that is out of the tracking area
        ElseIf Cnv_Flag(1) = 4 Then
          Cnv_QueRemove 1, 0                    'Delete the queue data
        EndIf
      Loop
    Fend

```

16.28 Tips for Accuracy Improvement of Conveyor Tracking

16.28.1 Overview

This section provides the tips for improving the robot's performance to handle the work pieces in the Conveyor Tracking, which uses the vision system to detect the work pieces.

Process of Accuracy Improvement

Prepare the conveyor tracking in the following steps.

1. System construction
2. Vision calibration
3. Conveyor calibration
4. Check of the work piece detection accuracy and the detection rate
5. Check of the work piece handling accuracy

In order to improve the handling accuracy, proper preparations and adjustments in each step are necessary. The following sections describe tips for accuracy improvement for each step.

Subsequent descriptions use the SCARA robot. Please note that the tips are common in SCARA and 6-Axis robots.

16.28.2 Tips for System Construction

Tool Settings

In order to realize precise pickups, the end effector of the robot needs to pick up the work pieces correctly with a tool such as a vacuum pad attached.

To pick up the work piece accurately by the tool, it is necessary to configure the tool in [Tools] page.

Eccentricity of the tool causes a constant pickup position gap. Make sure to configure the tool settings.

Also, adjustment by the tool settings is not effective for the improper tool such as a randomly-distorted vacuum pad due to the degenerated rubber. Make sure to use the proper tool.



For details on the tool setting, refer to 5.11.1 [Robot Manager] Command (Tools Menu) - [Tools] page



For details on the tool number selection, refer to 5.11.1 [Robot Manager] Command (Tools Menu) - [Jog and Teach] page




After adjusting the tool, make sure to check the operation and ensure that the calibration result is accurate.

Installation and Environment

In order to realize precise pickups, the camera and the conveyor should be installed in the proper environment and calibrated properly.

Install the system with attention to the following points.



Important Points for Installation of the Conveyor System

- Use a proper camera and lens. Configure a work distance (distance from the lens to the object) properly.
Also, ensure parallelism of the camera and the conveyor in order not to cause distortion of the field of view (FOV).
- Ensure horizontality of the horizontal conveyor to match the positions of the robot coordinate system and the conveyor coordinate system.
For the tilted conveyors, calibrate the tilt properly.
- If the encoder slips, pulse of the conveyor movement cannot be counted correctly.
- If the contrast of the work piece and the conveyor is low, edges of the work piece are difficult to be detected.
- Ambient vibration and source of the impact may cause slippage and backlash of the camera, the conveyor, and the work pieces. It may result in decrease in accuracy.
- General fluorescent lights have periodic flickers and may affect the work detection.
Consider using fluorescent lights specialized for image processing or the LED lighting system.



Select and install the appropriate cameras and lenses to realize work detection which satisfies required pickup accuracy. Required work detection accuracy should be threefold of the required pickup accuracy.
For details on modification of the FOV for accuracy improvement, refer to 3. *Tips for Vision Calibration – Field of View of Cameras.*

16.28.3 Tips for Vision Calibration

Field of View of Cameras

A large field of view increases mm/pixel (length of 1 pixel) value and decreases detection accuracy of the work pieces.

If the following values from the calibration result do not satisfy the required accuracy, consider the following methods.

XmmPerPixel (X mm of one pixel),
YmmPerPixel (Y mm of one pixel)

- Reinstall the camera and the work piece to shorten the work distance (distance from the lens to the object)
- Use a high resolution camera
- Use a high resolution lens (e.g. our mega pixel lens) or a long-focal-length lens.



For details on the vision calibration, refer to the following manual.
Vision Guide 7.0 Software 7. Vision Calibration

Deviation and Tilt of the Field of View

If Error (deviation) or Tilt values displayed in the calibration result were more than “1”, it can be considered that calibration was not done properly.

For details, refer to the following manual.

Vision Guide Software 7.5.7 Calibration Complete Dialog Box

Previous values	
X mm per pixel:	
Y mm per pixel:	
Max X error:	
Max Y error:	
Avg X error:	
Avg Y error:	
X tilt:	
Y tilt:	
FOV:	

New values	
X mm per pixel:	0.1919
Y mm per pixel:	0.2032
Max X error:	0.1744
Max Y error:	0.1119
Avg X error:	-0.0017
Avg Y error:	-0.0026
X tilt:	-1.72
Y tilt:	28.05
FOV: 122.82 mm X 97.52 mm	

Dialog displaying the calibration results

Reference Point Detection

For the vision calibration, use a proper combination of the reference point and the vision object; for instance, use a perfect circle as a reference point and detect it by the Blob object. In addition, it is necessary to perform a calibration with the “aperture” and “focus” of the camera adjusted to the work piece.

- Adjust the camera aperture not too bright and not too dark in order to detect edges and marks of the work piece.
- Adjust the focus to see the work piece sharply. Blurs may affect the detection rate and accuracy.

NOTE


If the work piece is thick and the top face does not come into the focus when the focus is placed on the conveyor, adjust the focus to the top face and set the reference point at the same height to calibrate.

NOTE


For details on the reference points, refer to the following manual.

Vision Guide 7.0 Software 7.3 Reference Points and Camera Points

For details on the vision objects, refer to the following manual.

Vision Guide 7.0 Software 6. Vision Objects


16.28.4 Tips for Conveyor Calibration

Work Piece and Tool

In order to realize precise pickups, it is necessary to perform a correct teaching in the conveyor calibration. To move the center of the end effector to the feature point (e.g. the center point) of the work piece detected by the camera, it is recommended, for example, to use a work piece and a tool as described below.

Work piece : Teaching point is easy to be found

Tool : Tip point is easy to be found (Make sure to configure the tool settings.)



Example of the work piece and the tool used in the conveyor calibration

NOTE


Perform a model teaching by overlaying the model origin of the Corr or Geom object on the teaching point, and adjust the positions of the camera coordinate system and the conveyor coordinate system correctly. If the teaching point is the center of balance of the work piece (a perfect circle or a square), the center can be detected as the model origin by the Blob object.

Z Value Adjustment

The work piece and the tool used in the conveyor calibration can have a different height from those used in actual work piece handling. By adjusting the Z value after replacing the tool and the work piece, errors related to the Z offset can be solved.

In the following cases, Z value adjustment is effective.

Tool cannot reach and pick up the work piece. (Z offset is too large)

Robot collides with the work piece and damages it. (Z offset is too small)

Like the above cases, redoing of the whole conveyor calibration process may not be required. If there is a problem in the pickup height, adjust the Z value as a first step.

For details on the Z value adjustment, refer to *16.16 Adjusting the Z value*.



16.28.5 Troubleshooting for Work Piece Detection

Teaching of Pickup Position

In order to realize precise pickups, the pickup position of the work piece should be detected properly as a model origin. To compensate the constant pickup position gap in work piece handling due to the gap between the pickup position and the model origin, following methods are effective.

- Perform a model teaching by overlaying the model origin of the Corr or Geom object on the teaching point and set the CameraX and CameraY as the pickup position.
- To set the center of balance as a pickup position, detect it as a model origin by the Blob object and set the CameraX and CameraY as the pickup position.



CameraX: X coordinate of the detected work piece position in the camera coordinate system

CameraY: Y coordinate of the detected work piece position in the camera coordinate system



For details on the vision objects, refer to the following manual.

Vision Guide 7.0 Software 6. Vision Objects

If the Work Piece Cannot Be Detected in the Search Area

If the work piece which is in the search area cannot be detected and an image processing error occurs, it can be improved by adjusting the vision properties. See the following points.

- Adjust the camera's exposure time
Long exposure time affects the work detection since it may blur the image of the moving work piece.
Use the ExposureTime property to shorten the exposure time.
- Adjust the shape score value
If the work detection rate is unstable, it may be improved by adjusting the Accept property of the vision object.



For details on the vision properties, refer to the following manual.

Vision Guide 7.0 Properties and Results Reference

If Work Detection Does Not Satisfy the Required Accuracy

If the work detection does not satisfy the required accuracy, it can be improved by adjusting the vision properties. See the following points.

- Adjust the camera's exposure time
Long exposure time affects the work detection since it may blur the image of the moving work piece.
Use the ExposureTime property to shorten the exposure time.
- Adjust the camera's field of view
Wide field of view increases the length of 1 pixel and decreases the detection accuracy.
Check the XmmPerPixel and YmmPerPixel values.

NOTE



Example: If approximately 0.5 mm of the image blur at the 100 mm/sec of the conveyor speed is acceptable, set the exposure time to 5 msec.

NOTE


For details on the vision properties, refer to the following manual.
Vision Guide 7.0 Properties and Results Reference

If the Image Processing Cannot Be Done in Time

If the image processing cannot be done in time, it can be improved by adjusting the search area and the vision properties. See the following points.



Tips for the case if the image processing cannot be done in time

- Adjust the search window of the object
A large search window increases time to execute the vision objects. Adjust the search window as small as possible by eliminating the area where work pieces do not come in.
- Adjust the number of the objects to be detected
When you want to detect only one work piece at a time, setting the NumberToFind property to "1" may reduce the execution time.


- Adjust the range of the expected scale
If there is no great variability in size of the work pieces, set the ScaleEnable property to “False”. If there is a small variability, narrow the ranges of the ScaleFactorMax and the ScaleFactorMin properties as much as possible.
- Adjust the range of the angled detection
If there is no great variability in angle among the work pieces, set the AngleEnable property to “False”. If there is a small variability, narrow the range of the AngleRange property as much as possible.
- Adjust the timeout period
A process is aborted when the image processing time is considered to exceed the timeout period. If image processing times vary, both the detection rate and the execution time may be improved by shortening the Timeout property.



For details on the vision properties, refer to the following manual
Vision Guide 7.0 Properties and Results Reference

When Using A Thick Work Piece

If the work piece is thick, the camera’s FOV includes the lateral side of the work piece as shown in the figure below. If the top face and the lateral side of the work piece have similar color, those two faces may be detected as a single top face of the work piece. Pay attention to this influence especially when using the thick work pieces.



Influence of detecting the lateral side of the work piece




This influence can be decreased by increasing the work distance or replacing the lens with a one with a long focal distance and a narrow angle of view.

16.28.6 Offset

Pickup of moving parts

When the “pickup accuracy-priority mode” is selected for the tracking mode, the pickup position of the robot may deviate from the center of the part as shown below. This gap occurs as a result of accuracy errors of the vision system calibration, tool calibration, and tracking.



Followings are countermeasures for the problem.

1. Feed the part with an angle near 0 degree. Then, pick up the part.
2. Measure the gap between the center of the part and the robot's pickup position.
3. Repeat the steps 1 and 2 for five times and calculate the average.
4. Set the average calculated in the step 3 to the program as follows.
`Jump Cnv_QueueGet(1) +X(**)`
5. Feed the part with an angle near 90 degrees. Then, pick up the part.
6. If the gap is large, fine-tune the value set in the step (4).
7. Feed the part with an angle near 0. Then, pick up the part.
8. If the gap is large, fine-tune the value set in the step (6).
9. Repeat the steps 6 through 8 until you get the suitable accuracy for the system.

NOTE



When the conveyor speed is 200 mm/sec, the gap between the center of the part and the pickup position of the robot cannot be smaller than plus or minus 1 mm.

When the conveyor speed is faster than 200 mm/sec, the gap increases.

When the conveyor speed is slower than 200 mm/sec, the gap decreases.


NOTE



If the gap between the center of the part and the pickup position can be measured by using the vision system, compensate the “Offset” by following steps.

1. Feed the part with an angle near 0 degree. Then, pick up the part.
2. Take the image of the picked part, and record X and Y coordinates.
3. Repeat the steps 1 and 2 for five times and calculate the average.
4. Feed the part with an angle of about 90 degrees. Then, pick up the part.

5. Take the image of the picked part by the camera, and record the X and Y coordinates.
6. Repeat the steps 5 and 6 for five times and calculate the average.
7. Feed the part with an angle near 180 degrees. Then, pick up the part.
8. Take the image of the picked part by the camera and record X and Y coordinates.
9. Repeat the steps 7 and 8 for five times and calculate the average.
10. Feed the part with an angle near 270 degrees. Then, pick up the part.
11. Take the image of the picked part by the camera and record X and Y coordinates.
12. Repeat the steps 11 and 12 for five times and calculate the average.
13. Plot the values in the steps 3, 6, 9, and 12 as shown in the figure below, and calculate the offset value.



14. Set the offset value to the program as follows.

```
Jump Cnv_QueueGet(1) +X(offset)
```



If a negative value is set to “offset”, the error 4406 may occur when the following program is executed.

```
Wait Cnv_QueueLen(1, CNV_QUELEN_PICKUPAREA) > 0
Jump Cnv_QueueGet(1) -X(offset)
```


The error can be avoided by performing any of the followings.

- Set the wait time before Jump command.
- Set the “offset” when registering the queue and not to register when executing the Jump command.

17. ECP Motion

17.1 Overview

An ECP (external control point) motion is when the robot arm holding a part follows a specified trajectory (part's edges, etc.) using an outside fixed tool.



The ECP option supports the following:

- ECP definition by ECPSet statement and selection by ECP statement
- ECP motion commands (additional functions of Move, Arc3, Curve, and CVMove commands)
- Teaching with ECP jogging

This option is available for SCARA (including RS series), Cartesian and 6-axis robots (including N series). Also, it can be used with multi-robot systems.

Up to 15 ECP coordinate systems can be defined.

How to move the arm with ECP motion

In the following paragraphs, the process for moving the 6-axis robot arm with ECP motion is explained as an example.

1. Setting an ECP

The ECP (external control point) is a coordinate system data used for defining the robot position and orientation at a processing point on the tip of the outside fixed tool.

The ECP should be defined based on the robot coordinate system or desired local coordinate system.

For example, when a drawing shows that the ECP is located at X=300, Y=300, Z=300 based on the robot coordinate system, specify it as shown below.

```
ECPSet 1,XY(300,300,300,0,0,0) ' Defines ECP No.1
```

When you have no ECP location data, you can specify it by teaching.

As an example, attach the tool of which you know the data precisely and bring the tip of the tool close to the ECP and then teach its position anywhere as P0. Then, specify the ECP using P0 coordinate data as shown below.

```
ECPSet 1,P0 :U(0) :V(0) :W(0) ' Defines ECP No.1
```

The orientation data (U, V, W) were set to 0 in the above examples. In these cases, the orientation in the ECP coordinate system is equal to that in the reference robot coordinate system.

You can specify U, V, and W coordinates in the ECP coordinate system. However, this data is valid only during the tangential correction mode ON in the Curve statement and ECP jog motion.


2. Teaching

Teach the point data while moving the robot arm holding the actual part. In this section, the part is assumed to be a rectangular solid and the arm is moved straight so that it touches one side of the part of the ECP specified in the previous section 1. *Setting the ECP*.

For details on teaching, refer to 5.11.1 [Robot Manager] (Tools Menu)-[Tools]-[Robot Manager]-[Jog and Teach] Page.


2-1 Teaching the motion start point

Move the arm to the motion start point and teach it as P1.



2-2 Teaching the motion end point

Move the arm to the motion end point and teach it as P2.



ECP Jog Mode:

The ECP jog mode is an additional jog mode used for teaching besides the Joint, World, and Tool jog modes.



The ECP jog mode is based on the selected ECP coordinate system.

3. Executing Motion

To move the arm with ECP motion, add the “ECP” parameter to a motion command.

ECP 1	'	Select ECP
Go P1	'	Moves the arm to the motion start point
Move P2 ECP	'	Executes ECP motion

Use the Arc3 command to move the arm in an arc trajectory with the fixed tool. Use the Curve and CVMove commands to move the arm in cubic spline curves.

18. Force Sensing

NOTE



This option allows you to measure force and enable a stop trigger by force using ATI Force Sensor. This is available in EPSON RC+ 7.0 Ver.7.2.0 or later version, however, this option is for EPSON RC+ 7.0 Ver.7.2.0 or before version.


EPSON RC+ 7.0 Ver.7.2.0 or later version supports “Force Guide 7.0” that measures, controls, and triggers force by using Epson Force Sensor.

For details on Force Guide 7.0, refer to the following manual.

EPSON RC+ 7.0 option Force Guide 7.0

18.1 Overview

The EPSON RC+ Force Sensing Option allows you to integrate force sensing in your applications. The force sensor is typically mounted on the robot's U axis. The sensor has 6 axes: ForceX, ForceY, ForceZ, TorqueX, TorqueY, TorqueZ.



With this option you can do the following:

- Read one or all 6 force/torque sensing axes values.
- Set triggers for motion commands.
- Use multiple force sensors in the same application. (up to 2 sensors)



SCARA robot with Gamma force sensor

18.2 Specifications

EPSON RC+ supports ATI force sensors using PCI interface boards.

For the PCI interface board, we support the following products of National Instruments.

PCI-6220	Connect one force sensor
PCI-6224	Connect one or two force sensors
PCI-6034E	Connect one force sensor (Conventional)

Note that we offer only the software license of this option. If you need ATI Force Sensor, a set of the PCI interface board and the sensor, please purchase it separately.

For specifications on force sensors, please see the ATI website:

<http://www.ati-ia.com/products/ft/sensors.aspx>

In addition, it is required for the users to prepare for installation to the manipulator. For details, refer to “18.3 Installation”.

18.3 Installation

The Force Sensing Option must be enabled in the RC700 controller. If you purchased the option with your system, the option will already be installed and configured.

You can also purchase the Force Sensing Option and install it in the field. See the chapter *Installing EPSON RC+ Options* for details.

Installing the force transducer circuit board

If you are adding Force Sensing in the field, you must install the force transducer board(s) in your system, and then run the NI-DAQmx driver installer.

Board Installation

Before installing the force sensing circuit board(s), you must first install the National Instruments DAQmx drivers that came with the board. To install the National Instruments DAQ drivers:

1. Run the NI-DAQmx driver installer.
2. Accept defaults for each step of the installation wizard.
3. Shutdown the system.
4. Install the board(s).
5. Start the system.
6. Run the National Instruments Measurement & Automation Explorer program once to verify that the board(s) that were installed are recognized.

You do not need to install the ATI software that came with the force transducer.

NOTE




The calibration for the transducer must be loaded into memory. EPSON RC+ 7.0 handles this when you import the calibration data file as described in the section *Software Configuration* later in this chapter. The calibration data file can be located on the CD that came with the force transducer.

Mounting the force transducer


To mount the force transducer to the robot:

1. Remove the top cover of the transducer.
2. Remove the robot's end effector axis coupling and mount it to the transducer cover.
3. Install the transducer cover / coupling assembly onto the transducer.
4. Install the entire assembly on the end effector axis.

The following figures show mounting for gamma and nano transducers.




Mounting the Gamma Force Sensor




Mounting the Nano Force Sensor

Mounting tooling to force sensor

The following diagrams show the tooling mounting dimensions for Gamma and Nano force transducers.



Tool mounting for Gamma transducer



Tool mounting for Nano transducer

Connecting the force transducer

Use the cable supplied with the transducer to connect it to the PC board. The Nano transducer connects to an external interface box which in turn connects to the PC board.




CAUTION

- Make sure power is off before connecting or disconnecting the force transducer. Protect transducer from electro-static discharge. Do not touch the internal electronics or connector pins.

Routing the transducer cable

The transducer cable must be routed so that it is not stressed, pulled, kinked, cut, or otherwise damaged throughout the full range of motion. If the cable will rub other cables during cycling, use a plastic spiral wrap to protect it.


When the cable is cycling below the minimum bending radius the cable may fail due to fatigue. A small radius can be used if the cable is not being moved.




Software Configuration

To configure EPSON RC+ 7.0 Force Sensing:

1. Start EPSON RC+ 7.0, then select [Setup]-[System Configuration].
2. Click on the [Force Sensing] item in the tree on the left. If [Force Sensing] is not displayed, then the software options key for Force Sensing has not been enabled.
3. To add a board, click the <Add> button. A new force sensor will be shown in the tree on the left, and the controls used to configure the sensor will become enabled.



4. Enter the [NI DAQ device] name. This is assigned by the National Instruments software. To view NI DAQ device numbers, run the National Instruments Measurement & Automation Explorer.
5. Click the button shown on the right of [ATI Calibration File] to import a calibration file for the sensor. This can be found on the CD that came with the sensor. Navigate to the calibration file whose name includes the serial number of the sensor. Click <Open>, and the file will be copied to the EpsonRC70\force directory.
6. Leave the force and torque units at the default setting to use the native units. The actual units will be displayed in the sensor list after you click <Apply>. Or, you can select the desired units.
7. Click <Apply> to accept the new sensor.
8. From the [Tools] menu, select [Force Monitor]. This will open the [Force Monitor] window.



9. Apply pressure to the sensor. You should see the values change on the [Force Monitor] window. If you are using multiple sensors, change the sensor number on the monitor and verify that each sensor is working.

18.4 Force Sensing Commands

All Force Sensing commands begin with the same prefix: "Force_". Here is a list of all of the commands. For details, please see the online help or SPEL⁺ Language Reference Manual.

Force_Calibrate	Zeros out all axes for the current sensor.
Force_ClearTrigger	Clears all trigger conditions for the current sensor.
Force_GetForce	Returns the current value for one axis for the current sensor.
Force_GetForces	Returns the current values for all axes for the current sensor in an array.
Force_Sensor	Sets / returns the current sensor for the current task.
Force_SetTrigger	Sets /displays the force limit triggers for the current sensor.

18.5 Using the Force Sensing Trigger

You can configure the system to stop the robot after the force sensing trigger has been activated. You can set the trigger to activate when one or more force sensing axes reaches a preset limit. You use the Till command to check the trigger condition during motion.

Stopping Motion along Z axis

Use a trigger on the ZForce axis to stop the robot during Z axis motion.

For example:

' Set the force trigger to fire when force on Z axis is less than -10

```
Force_ClearTrigger
Force_SetTrigger FORCE_ZFORCE, -10, FORCE_LESS
Till Force
Jump P1
Speeds 1
Move P2 Till
```

You can combine other conditions with Force in the Till command:

```
Till Sw(1) = On Or Force
```

You can combine other force/torque conditions by calling Force_SetTrigger more than once. In this case, clear all triggers first before setting them.

```
Force_ClearTrigger
Force_SetTrigger FORCE_ZFORCE, -10, FORCE_LESS
Force_SetTrigger FORCE_XFORCE, 5, FORCE_GREATER
```

Stopping Motion along X or Y axes

Use a trigger on the XForce, XTorque, YForce, YTorque axes to stop the robot during Z axis motion. You need to align the force sensor by rotating the robot's U axis. The X and Y axes of the force sensor are marked on the transducer.

For example:

' Set the force trigger to fire when torque or force on X axis is less than -10

```
Force_ClearTrigger
Force_SetTrigger FORCE_XFORCE, -10, FORCE_LESS
Force_SetTrigger FORCE_XTORQUE, -10, FORCE_LESS
Till Force
Jump P1
Speeds 1
Move P2 Till
```

19. Distance Tracking Function

19.1 Overview

Distance tracking function controls the robot so that a constant distance can be kept between the robot and the workpiece.

Distance sensor which is connected to the analog I/O board (optional) is used.

To use the function, analog I/O board (optional) is required.

Select one axis from below as the direction to control.

Tool coordinate system: X axis, Yaxis, Zaxis

ECP coordinate system: X axis, Yaxis, Zaxis

ECP coordinate system can be selected only when the ECP (external control point motion) option is enabled.

Specify the axis to be controlled by AIO_TrackingSet.

The distance tracking function is available for SCARA robots (including RS series manipulators) and 6-Axis robots (including N series manipulators). Also, it can be used with multi-robot systems.

Note that the following A, B, and C when using the distance tracking function in multi-robot systems.

- | | |
|--------------------------|--|
| A: Two robots | : Up to two distance tracking sensors are available.
Two robots can use each distance tracking sensor to execute the distance tracking function simultaneously. |
| B: Three robots | : One distance tracking sensor is available.
One robot can use the distance tracking function.
However, three robots can use the one distance tracking sensor and execute the distance tracking function in order by switching it. |
| C: More than four robots | : The distance tracking function is not available. |

When using the distance tracking function in multi-robot systems, you cannot connect the force sensor.



- We recommend using a laser displacement meter for a distance sensor. For the specifications of the distance sensor, please check its manual thoroughly. Improper use of the sensor may result in abnormal motions of the robot.

For connection and use of analog I/O board, refer to the following manuals:

Robot Controller RC700 / RC700-A

Setup & Operation 14.6 Analog I/O Board

Robot Controller RC90 / RC90-B (EPSON RC+ 7.0)

Setup & Operation 13.5 Analog I/O Board

19.1.1 Distance Tracking Accuracy

For the accuracy achieved by this function, see the after mentioned experiment results.

However, the accuracy of the distance tracking function may differ depending on the robot model, speed, and workpiece shape.

Experiment conditions


Robot: 6-axis robot C4L

Laser displacement meter: Two types (See the table below for specifications)

	Medium speed, Medium accuracy laser displacement meter	High speed High accuracy laser displacement meter
Measured distance (mm)	20 to 30	7.2 to 8.8
Spot diameter (um)	Approx. 25×1200	Approx. ø20
Repeatability (um)	1	0.02
Sampling cycle	0.33, 1, 2, 5 ms (4 levels available)	20, 50, 100, 200, 500, 1000 us (6 levels available)
Light source (Laser class)	Class 2	Class 1

Experiment environment

Start point and target point have been taught in advance.



Without the distance tracking function:

Robot moves in a straight line from the start point to the target point.

With the distance tracking function:

The robot moves on a trajectory to keep a constant distance to the workpiece like the blue arrow (robot trajectory) shown in the above figure.

Experiment results

Values of the distance tracking accuracy are the width of variations in the distance measured values between the start point and end point of the distance tracking function. Two types of the laser displacement meter are used. (See the tables below for the experiment results.)

Distance tracking accuracy of
medium speed and medium accuracy laser displacement meter

Robot SpeedS (mm/s)	Robot AccelS (mm/s*s)	Workpiece tilt (mm)		
		5 deg.	10 deg.	15 deg.
10	100	± 0.03	± 0.04	± 0.06
30	300	± 0.06	± 0.09	± 0.14
50	500	± 0.09	± 0.15	± 0.32
100	1000	± 0.15	± 0.30	± 0.48


Distance tracking accuracy of
high speed and high accuracy laser displacement meter

Robot SpeedS (mm/s)	Robot AccelS (mm/s*s)	Workpiece tilt (mm)		
		5 deg.	10 deg.	15 deg.
10	100	± 0.02	± 0.04	± 0.05
30	300	± 0.04	± 0.06	± 0.13
50	500	± 0.06	± 0.11	± 0.20
100	1000	± 0.13	± 0.20	± 0.35

19.2 Connection Example

This section describes the connection example of the distance tracking function.

19.2.1 Basic Connection Example




Please prepare the following items by yourself.

1. Power (select depending on the distance sensor to be used.)
2. Distance sensor (e.g. laser displacement meter)
3. Development PC

19.2.2 Connection Example for Dispense Application

Distance tracking function is available for dispense applications. To realize the dispense application with high accuracy, it is important to keep a constant needle gap (distance between tip of the needle and the workpiece). Constant needle gap can be realized with the distance tracking function. Figure below is a connection example for dispense application.



Please prepare the following items by yourself.

1. Power (select depending on the distance sensor and dispenser to be used.)
2. Distance sensor (e.g. laser displacement meter)
3. Dispenser
4. Development PC

19.3 Commands

List of SPEL+ commands for the distance tracking function.

AIO_TrackingSet	: Sets the distance tracking function
AIO_TrackingStart	: Starts the distance tracking function
AIO_TrackingEnd	: Ends the distance tracking function
AIO_TrackingON Function	: Returns status of the distance tracking function

For more details on the commands, refer to the following manual:

EPSON RC+ 7.0 SPEL+ Language Reference

19.4 Steps to adjust parameters


The accuracy of the distance tracking function may differ depending on the robot model, speed, and workpiece shape.

Therefore, you need to set parameters depending on the working environment when using the distance tracking function.

To improve the accuracy of the distance tracking function, adjust parameters and set a proper value.

Parameters to be set are ProportionalGain, IntegralGain, and DifferentialGain. Those are parameters for AIO_TrackingStart.

In the steps to adjust parameters, it is assumed to use a flat metallic plate as a workpiece in the dispense application as shown below.




Steps to adjust parameters are below:

Statuses at the beginning are as follows:

Dispenser: Connection and settings have completed.

Laser displacement meter: Connected to analog I/O.

Describe in order of the preparation for parameter adjustment and parameter adjustment.



- The parameters used in this step are reference values. Please note that the operation may not be successful or the motion may be vibratory depending on the set parameters and some operating conditions.
- If the robot moves abnormally, immediately hold down the emergency button.

19.4.1 Check Motions of Analog I/O Board

The following steps describe how to check the motion of the analog I/O board.

- (1) Make sure that the analog I/O board and the laser displacement meter (distance sensor) are connected properly.

For connection and use of the analog I/O board, refer to the following manuals:


Robot Controller RC700 / RC700-A
Setup & Operation 14.6 Analog I/O Board

Robot Controller RC90 / RC90-B (EPSON RC+ 7.0)
Setup & Operation 13.5 Analog I/O Board

- (2) Execute the following command on the command window.
`>Print AIO_In (channel number of the analog I/O board)`
- (3) Output voltage from the laser displacement meter is displayed.
Check the displayed value and the value measured by the laser displacement meter.
If those values are the same, the analog I/O board works properly.

19.4.2 Teaching a Robot

Teach the start and target point of the distance tracking function.




- (1) Move the robot to a position where the laser displacement meter will be within the measurable range.
- (2) Set a robot position and orientation within the range and teach as the start point (P1).
When using the distance tracking function for a dispense application, be sure to check that the needle gap at the start point is same as the recommended gap value of the dispenser.
- (3) Move the robot to the target point.
- (4) Teach a moved point as the target point (P2).

Sometimes the laser displacement meter cannot measure the tilt of workpiece due to workpiece types (especially mirrored object), its tilt angle, and types of the laser displacement meter. In that case, place the bottom of a chassis of the laser displacement meter in parallel with the workpiece surface.

For layout of the distance sensor (laser displacement meter) and target workpiece, follow the specifications of each distance sensor.

Ex: When placing the workpiece and chassis of the laser displacement meter in parallel



For the arc-shaped workpiece as shown above, teach the trajectory of the arc shape by using Move or Arc command before executing the distance tracking function.

19.4.3 Create a Motion Program

Create a motion program for the distance tracking function.

Program example:

Move the robot from P1 to P2 by using the distance tracking function. Set the needle tip position of the dispenser for Tool coordinate system. However, the dispenser does not move until the parameter adjustment ends. Parameters of AIO_TrackingSet are examples. Be sure to set parameters depending on the working environment.

Function AIOTrackingSample

```
'-----Robot settings-----
Motor On
Power High
Speeds 30
Accels 300, 300

Tool 1
'-----Motion part-----
Move P1                                     ' Move to start point
AIO_TrackingSet 1, -1, 0, -3, 3, 0, 2      ' Set the distance tracking function

Wait 2
AIO_TrackingStart 1, 10, 0, 0              ' Start the distance tracking function

Move P2                                     ' Move to target point
AIO_TrackingEnd                             ' End the distance tracking function
Wait 2

Motor Off

Fend
```

Set the default values for parameters of AIO_TrackingStart as follows:

```
ProportionalGain : 10
IntegralGain      : 0
DifferentialGain  : 0
```

19.4.4 Add a Program for Distance Sensor Logging

To adjust the parameters (ProportionalGain, IntegralGain, DifferentialGain), you need to check the measured data of the laser displacement meter during execution of the distance tracking function.

Measured data of the laser displacement meter can be acquired by the following sample program.

Add ★ to the program created in 19.4.3.

```

Integer fileNum                                ' ★ Declare a file number
Function AIOTrackingSample

'=====
' Program to record the measured value of the distance sensor during execution of the
distance tracking function.
'=====

'----- Robot setting -----
Motor On
Power High
SpeedS 30
AccelS 300, 300
Tool 1

'----- Create a CSV file for recording -----
fileNum = FreeFile                            ' ★ Acquire a file number
WOpen "AIO_Monitor.csv" As #fileNum           ' ★ Save to Project folder

'-----Motion part-----
Move P1                                        ' Move to start point
Xgt AIO_Monitor    ' ★Start to record the measured value by distance sensor
AIO_TrackingSet 1, -1, 0, -3, 3, 0, 2
                                           ' Set the distance tracking function
Wait 2
AIO_TrackingStart 1, 10, 0, 0 ' Start the distance tracking function
Move P2                                        ' Move to target point
AIO_TrackingEnd                                ' End the distance tracking function
Wait 2
Quit AIO_Monitor    ' ★Quit recording the values by distance sensor
Close #fileNum      ' ★Close CSV
Motor Off

Fend

```

```

Function AIO_Monitor                            ' ★

'=====
' Called by AIOTrackingSample.
' Keep recording values input to Ch1 of analog I/O board to CSV.
'=====

Do                                              ' ★
    Print #fileNum, AIO_In(1)                  ' ★
    Wait 0.002                                ' ★
Loop                                           ' ★

Fend                                          ' ★

```

19.4.5 ProportionalGain Setting

This section describes how to execute the program created in 19.4.4 and adjust ProportionalGain.

(1) Test run in low speed

Execute the program created in 19.4.4 in low speed (10mm/s or less).

Set SpeedS to 10 or less and AccelS to 100 or less.

Make sure that the robot moves to the target point and the program works properly.

Since the value of ProportionalGain is small, the robot moves straight to the target point. Be sure to move the robot in the environment with no obstacles between the motion start point and target point.

When 4603: out of range error occurs:

Since the value of ProportionalGain is small, “4603: Out of range error” may occur.

If the error occurs, increase the value of ProportionalGain by 10.

(2) Test run in actual speed

Since it was confirmed that the program works properly at (1), execute the program in the desired working environment. Set robot speed and acceleration to desired value.

When 4603: out of range error occurs:

Parameter adjustment is required. Refer to the following tips to adjust parameters, and then check the motion again.


- Value of ProportionalGain is small. Increase the current value by 10.
- Robot speed is too fast. Move the robot in 100mm/s or less.

(3) Check the motion results

“AIO_Monitor.csv” is created in the project folder of EPSON RC+7.0. Open the file in spreadsheet software and create a line graph or a scatter plot by all data of column A.

Graph shown below will be created. Check the correction accuracy on the graph. In case of the the following graph, the correction accuracy is approx. 70um.

If the correction accuracy is within the target accuracy, parameter adjustment ends.




(4) Adjustment of ProportionalGain

If the correction accuracy does not achieve the target value, adjustment of ProportionalGain is required.

ProportionalGain is a parameter to set strength of correction. Adjust value of ProportionalGain and repeat the program execution to calculate a proper value.

Be sure to increase the value of ProportionalGain gradually. Changing the value to a larger one at one time is extremely hazardous and the robot may move unintentionally.

When adjusting ProportionalGain, keep IntegralGain and DifferentialGain to “0”.



When adjusting ProportionalGain, the correction accuracy is improved.

However, if increasing the value too much, the robot motion will be vibratory.

Refer to the upper graph: P=50

ProportionalGain value without robot vibrations and the best correction accuracy is an optimum value.

Refer to the upper graph: P=40


If the target correction accuracy is not achieved even if ProportionalGain is adjusted, you need to adjust IntegralGain.

19.4.6 IntegralGain Setting

IntegralGain is a parameter to clear an offset between the target value.

Adjust value of IntegralGain and repeat the program execution to calculate a proper value. Be sure to increase the value of IntegralGain gradually. Changing the value to a larger one at one time is extremely hazardous and the robot may move unintentionally.

When adjusting IntegralGain, keep ProportionalGain to the value calculated in 19.4.5 and DifferentialGain to “0”.



When adjusting IntegralGain, offset between the target value is cleared.

However, if increasing the value too much, the robot motion will be vibratory.

Refer to the upper graph: I=1.0

IntegralGain value without robot vibrations and the best correction accuracy is an optimum value.

Refer to the upper graph: I=0.7


19.4.7 DifferentialGain Setting

DifferentialGain is a parameter to improve the responsiveness of correction.

Adjust value of DifferentialGain and repeat the program execution to calculate a proper value.

Be sure to increase the value of DifferentialGain gradually. Changing the value to a larger one at one time is extremely hazardous and the robot may move unintentionally.

When adjusting DifferentialGain, enter the value calculated in 19.4.5 for ProportionalGain and the value calculated in 19.4.6 for DifferentialGain.



When adjusting DifferentialGain, the responsiveness of correction is improved.

However, if increasing the value too much, the robot motion will be vibratory.

Refer to the upper graph: D=100

DifferentialGain value without robot vibrations and the best correction accuracy is an optimum value.

Refer to the upper graph: D=40

Now, gain adjustment is completed.

19.5 Example of Dispense Application

The following describes a program example when using the distance tracking function for dispense applications.



- The parameters used in this step are reference values.
Please note that the operation may not be successful or the motion may be vibratory depending on the set parameters and some operating conditions.
- If the robot moves abnormally, immediately hold down the emergency button.

19.5.1 Basic Example

It is a program using the distance tracking function when the robot moves from P1 to P2. Dispenser is connected to output No.1 of the standard I/O.

For more details on connection of the standard I/O, refer to the following manuals:

Robot Controller RC700 / RC700-A

Setup & Operation 11. I/O Connector

Robot Controller RC90 / RC90-B (EPSON RC+ 7.0)

Setup & Operation 11. I/O Connector

Function AIOTrackingSample

```
'----- Robot settings-----
Motor On
Power High
SpeedS 30
AccelS 300, 300

Tool 1
'----- Motion part-----
Move P1                                ' Move to start point
AIO_TrackingSet 1, -1, 0, -3, 3, 0, 2
                                      ' Set the distance tracking function
AIO_TrackingStart 1, 10, 0, 0
                                      ' Start the distance tracking function

Move P2 !D1; On 1; D99; Off 1!
                                      ' Move to target point, start and end of dispenser application

AIO_TrackingEnd                        ' End of the distance tracking function
Motor Off

Fend
```

19.5.2 Example with Application Amount Control

It is a program example when controlling the application amount depending on the robot speed.

This program can prevent amassing fluid at the start point, end point, and corners.

When using this function, a dispenser with “external input of the application amount” is required.

For adjustment procedures of application amount and connection method, refer to the manual of the dispenser to be used.

Function Main

```

'-----Robot settings -----
Motor On
Power High
SpeedS 30
AccelS 300, 300
Tool 1

AIO_Set 1, On, RealTCPSpeed, 100, 0
                                ' Start the analog output of the robot speed

'-----Motion part-----
Move P1                                ' Move to start point
AIO_TrackingSet 1, -1, 0, -3, 3, 0, 2
                                ' Set the distance tracking function
AIO_TrackingStart 1, 10, 0, 0
                                ' Start the distance tracking function
Move P2 !D1; On 1; D99; Off 1!        ' Move to the end point
AIO_TrackingEnd                        ' End of the distance tracking function
AIO_Set 1, Off                        ' End the analog output of the robot speed
Motor Off

Fend

```

20. Real-Time I/O


You can use this function only with the controller RC700 / RC700-A.

20.1 Overview

Real-time I/O is a feature that allows you to input trigger signals into the R-I/O connector of the robot controller so that you can latch and acquire the robot position at high speed while it is operating.

An example of an application using real-time I/O is "Picture on the fly": This synchronizes the robot position detection and the vision position detection, and performs part pickup, alignment, and assembly without stopping the robot.

With the real-time I/O feature, you can reduce the robot stop time for vision image acquisition that is necessary for traditional vision applications.



20.2 Specifications

R-I/O Connector

The RC700 / RC700-A robot controller has an R-I/O connector that is used to connect the real-time I/O trigger input signals. An R-I/O input is a special input interface that monitors the signals at higher speed than the standard I/O inputs. There are two trigger input signals on each of the Control Unit and Drive Units. For example, set the transmission type sensor so that it reacts when the robot passes the camera acquisition point and use the R-I/O connector so that the R-I/O input is detected at the moment shutter clicked.

For the details of the hardware (connection connector, connection circuit), refer to the *Robot Controller* manual, *Setup & Operation: I/O Remote Settings*.

Real-time I/O commands

There are special commands provided for use the real-time I/O. The following are basic descriptions of these commands.

For more details, refer to the manual *SPEL+ Language Reference*.

LatchEnable

This command is used to enable or disable the latch function of the robot position information with the real-time I/O. When LatchEnable On executes, it enables the robot position latch function using the trigger input signals connected to the R-I/O connector. After the latch is enabled, the robot current position information is latched when the first trigger input is detected. To repeatedly latch the robot position, execute LatchEnable Off and then execute LatchEnable On again. To use the command repeatedly, it requires 60 ms minimum interval for each command processing time but it is not necessary to consider the command executing time.

SetLatch

Specifies the real-time input port that you connected the trigger input signal to, and the input logic. The table below shows the port numbers you can specify. Specify the port number that the robot using R-I/O is connected. If the other ports are specified, an error will occur. One robot cannot wait for the trigger signals from multiple ports.

		Point	Port number
Control Unit	INPUT	2 points	24,25
Drive Unit 1	INPUT	2 points	56,57
Drive Unit 2	INPUT	2 points	280,281
Drive Unit 3	INPUT	2 points	312,313

Execution of SetLatch requires approximately 40 msec for processing.

LatchState Function

This function returns the position latch status.

After it confirms that the latch has been done, it acquires the position information using the LatchPos Function.

LatchPos Function

This function returns the robot position information latched by the trigger input.

Executing the LatchPos Function needs approximately 15 msec for processing.

To return Tool 0 and Arm 0 positions:

Set the WithoutToolArm parameter when using the “Picture on the fly” application.

RobotPos Vision Sequence Property

When acquiring the parts place position by using the RobotPos result, set the robot position in image capturing to this property before acquiring the RobotPos result.

Also, set the RobotPos sequence property to set the robot coordinates of the image acquisition position to calculate the part position when you use a mobile camera system.

In any of the above cases, the system can calculate the correct part position by using the position acquired by LatchPos Function in this property.

For the details, refer to the manual *Vision Guide 7.0 Properties & Results Reference*.

Latch accuracy

The following is the theoretical sampling time used to latch the position information.

		Sampling time [μsec]
Control Unit	4-axis robot	32
	6-axis robot	32
Drive Unit	4-axis robot	32
	6-axis robot	21

You can get a rough idea of latch accuracy from the robot speed (parts moving speed) at the latch trigger input and the sampling time. For real accuracy, you must have a margin on the required accuracy because time delay and variation in the hardware may affect. The latch accuracy will improve as the robot moves slower at the trigger input.

$$\text{Latched position accuracy [mm]} = \text{Robot speed [mm/sec]} \times \text{Sampling time [sec]}$$

20.3 Usage

1. Basic example

The following program is a sample to connect any trigger signal to the R-I/O connector of the controller, latch the robot position information while it is operating at the trigger input, and show the latched position information.

```

Function Main
  Motor On
  Power High

  Speed 50; Accel 50, 50
  SpeedS 500; AccelS 5000

  Go P0                                ' Start point
  SetLatch SETLATCH_PORT_CU_0,
  SETLATCH_TRIGGERMODE_LEADINGEDGE
  LatchEnable On                        ' Enable the latch
  Move P1                              ' Start the operation, trigger input while operating


  Wait LatchState = True                ' Confirmed the latch is complete
  P3 = LatchPos                         ' Acquire the latched position
  LatchEnable Off                       ' Disable the latch

  Print P3                             ' Show the latched position
End

```

2. Example with Vision system

This is an example that uses the robot end effector to handle parts, passes above the external fixed upward camera acquisition point without stopping, and assembles the parts with an appropriate position correction.




This system has a transmission type sensor that outputs the trigger signal when the robot end effector handles a part and passes the camera acquisition point. Then, it connects the sensor output with both the R-I/O and the camera trigger input for external tuning and synchronizes the latched robot position information and the camera image. It calculates the part position error and offsets the position comparing the robot position information from the camera image to the robot position information from the real-time I/O.

In this case, the robot vision system must be calibrated as the upward fixed camera. Also, by registering the parts place position in advance, robot position information can be acquired for precise parts placement by CalRobotPlacePos result. Parts place position can be set in the CalRobotPlacePos property wizard.

For details on the camera trigger signal connection and the vision calibration, refer to the manual *Vision Guide 7.0*.

The following program is a sample.



```

Function Main
  Robot 1
  Motor On
  Power High

  Speed 100
  Accel 100, 100

  Jump InitPos                                     ' Move to the initial position
  Wait 1.0

  SetLatch 24, SETLATCH_TRIGGERMODE_LEADINGEDGE    ' Set the latch condition

  MemOff 0
  Xqt PictureOnFly_Camera                          ' Start the shooting task

  Jump StartPos C0                                 ' Move to the part feed point
  Wait 0.5

  LatchEnable On                                   ' Start waiting the latch

  MemOn 0                                           ' Enable the shooting

  Jump FrontPos C0 CP                               ' Move close to the camera
  Go PassingPos CP                                 ' Pass over the camera

  Go TargetPos :Z(-70) CP                           ' Move over the assembly point

  Wait MemSw(1) = On                               ' Wait until the image processing is complete
  Wait LatchState = True                           ' Wait for position latch completion
  LatchEnable Off                                   ' Disable the position latch
  Jump ExactTargetPos C0 LimZ (-70)                 ' Move to the assembly point
  Wait 0.5

  Jump InitPos                                     ' Move to the initial point
  Wait 0.5

  Motor Off

Fend
' Function to execute from work image capturing to work place acquisition
Function PictureOnFly_Camera

  ' Vision Result variable

```

```
Integer AcqStat      ' Strobe imaging completion flag
Boolean Found        ' Work detection status

Wait MemSw(0) = On    ' Waits the imaging start flag
MemOff 1              ' Clear the imaging completion flag
MemOff 0              ' Clear the imaging start flag
AcqStat = 0           ' Clear the strobe imaging flag

VRun PictureOnFly_i

Do Until AcqStat = 3    ' Wait for strobe
    VGet PictureOnFly_i.AcquireState, AcqStat
Loop

' Check the work detection
VGet PictureOnFly_i.Geom01.Found, Found

If Found = False Then
    Print "Work NotFound"
    Pause
Else
    MemOn 1            ' Change the camera imaging flag
EndIf

Wait LatchState = True ' Wait for the trigger

' Set the image capturing position (trigger position) to the Vision
VSet PictureOnFly_i.RobotPos, LatchPos (WithoutToolArm)

' Acquire the robot position
VGet PictureOnFly_i.Geom01.RobotPlacePos, Found, ExactTargetPos

Fend
```

21. Additional Axis

21.1 Overview

You can attach up to two additional drive axes (per manipulator) which can operate in association with the manipulator. The position data of the additional axis is saved with the robot point data. The additional axis can move simultaneously with the manipulator by motion commands and you can design an application using a traveling axis (manipulator on the straight axis) with simple programming.



If you want to operate the manipulator and drive axis separately, you need to define the additional axis as another manipulator using the multi-manipulators feature.



- When you use the additional axis as traveling axis and mount a manipulator(s) on the axis, the reaction force of manipulator(s) is put on the traveling axis. Therefore, you should limit the acceleration/deceleration speed with the Accel setting so that it is within the allowable inertia of traveling axis. In addition, the manipulator may swing widely at the positioning and possibly break the additional axis.

21.2 Specifications

Types of additional axis

The supported additional axis is the PG axis, controlled by the pulse generator board. However, note that the PG axis has some limitations.

Limitations of a PG additional axis

- a. Synchronizes with the manipulator to start motion but not to finish.
- b. Does not support Path motion with CP On and Pass. Stops for every motion.
- c. Does not go through the CVMove series of points
- d. Calibration is necessary using the MCAL command. Cannot operate the additional axis and the robot together until the calibration is complete. If movement of the PG additional axis is "0", and Go and Move are executed to the point where only the robot moves, the robot will move singly.

Number of additional axis

Up to two additional axes are available for each of the SCARA robot series (including RS series), Cartesian coordinate robot, 6-axis robot (including N series), and Joint type robot. However, the number of axes you can add is determined by how many axes are available with your controller.

Position data management

The additional axes are allocated to Joint #8 and #9 for all robot types. The position data are shown in the S and T coordinate values of point data of the manipulator to which you add the additional axes.

The additional axis as Joint #8 is called the additional S axis and Joint #9 is the additional T axis.

The coordinate values of additional axes are saved with the robot point data but don't have any effect on the robot coordinate system.

How to operate

The additional axis can move simultaneously with the manipulator (synchronous start / stop). However, if you use the PG axis, it doesn't synchronize with manipulator to finish and operate by the different acceleration/deceleration speed from the manipulator. See below for the details of motion commands.

Also, you can operate the additional axis and manipulator separately by proper management of the point data. However, you cannot operate separately both of them in arbitrary timing. In this case, use the multi-manipulators function and set the drive axis as another manipulator.

Command specification

Pulse, Go, BGo, TGo, Pass

The additional axis can operate in association with the manipulator motion. However, if you use the PG axis, it synchronizes only to start the motion and a motion command completes when both the manipulator and axis finish each motion. In addition, if the PG additional axis has a travel distance, the Path motion with CP On and Pass are prohibited and the axis moves with CP Off automatically.

Move, BMove, Tmove

The additional axis can operate in association with the manipulator motion. However, if you use the PG axis, it synchronizes only to start the motion and a motion command completes when both the manipulator and axis finish each motion. In addition, if the PG additional axis has a travel distance, the Path motion with CP On is prohibited and the axis moves with CP Off automatically.

Arc, Arc3

The additional axis can operate in association with the manipulator motion. It doesn't go through the specified midPoint and directly goes to the end point. If you use the PG axis, it synchronizes only to start the motion and a motion command completes when both the manipulator and axis finish each motion. In addition, if the PG additional axis has a travel distance, the Path motion with CP On is prohibited and the axis moves with CP Off automatically.

CVMove

The additional axis can operate in association with the manipulator motion. If you use a servo axis for the additional axis, for each of the S and T axis it creates a curve going through the S and T coordinates specified by a series of point data. However, if you use the PG axis for the additional axis, it doesn't go through the series of points and directly goes to the end point. Also, it synchronizes only to start the motion and a motion command completes when both the manipulator and axis finish each motion. In addition, if the PG additional axis has a travel distance, the Path motion with CP On is prohibited and the axis moves with CP Off automatically.

Jump

The additional axis executes PTP motion in association with the manipulator horizontal motion. However, if you use the PG axis, it synchronizes only to start the motion and a motion command completes when both the manipulator and axis finish each motion. In addition, if the PG additional axis has a travel distance, the Path motion with CP On is prohibited and the axis moves with CP Off automatically.

Jump3, Jump3CP

The additional axis can operate in association with the manipulator depart / span / approach motion. However, if you use the PG axis, it synchronizes only to start the motion and a motion command completes when both the manipulator and axis finish each motion. In addition, if the PG additional axis has a travel distance, the Path motion with CP On and Pass are prohibited and the axis moves with CP Off automatically.

JTran, PTran

The additional axis can operate separately by specifying as Joint #8, #9.

Example:

```
> JTran 8, 90      ' Move the additional S axis by 90 mm
> PTran 9, 10000   ' Move the additional T axis by 10000 pulse
```

21.3 Usage

Additional axis configuration

For the instruction of configuring the additional axis, refer to *10.2 Configuration of Additional Axes*.

If you use the PG axis for the additional axis, you need to set the PG parameters. For the details of PG parameters, refer to the *Robot Controller option: PG Motion System* manual.

Point data usage

This example specifies the position data of manipulator and additional ST axes and substitutes them to the point data.

```
P1 = XY(10, 20, 30, 40) :ST(10, 20)      ' SCARA robot
P1 = XY(10, 20, 30, 40, 50, 60) :ST(10, 20) ' 6-axis robot
```

This example specifies the position data of manipulator and additional ST axes and executes a PTP motion.

```
Go XY(10, 20, 30, 40) :ST(10, 20)
Go XY(10, 20, 30, 40, 50, 60) :ST(10, 20)
```

This example specifies the position data of additional ST axes individually

```
P1 = XY(10, 20, 30, 40) :S(10) :T(20)
P1 = XY(10, 20, 30, 40) :S(10)
P1 = XY(10, 20, 30, 40) :T(20)
```

This example omits the robot position assignment XY() and specifies only the additional axis position. Then, the point data is defined so that the manipulator doesn't move (undefined).

```
P1 = ST(10, 20)
Go P1      ' Only additional axis moves and the manipulator remains at the current
position.
```

This example operates only the additional axis.

```
Go ST(10, 20)      ' Only the additional axis moves.
```

This example omits the additional axis position assignment ST() and specifies only the manipulator position. Then, the point data is defined so that the additional axis doesn't move (undefined).

```
P1 = XY(10, 20, 30, 40)
Go P1      ' Only the manipulator moves and the additional axis remains at the current
position.
```

This example operates the manipulator only.

```
Go XY(10, 20, 30, 40)      ' Only the manipulator moves.
```

This example calculates the additional axis coordinate value using a point operator expression.

```
P1 = XY(10, 20, 30, 40, 50, 60) :ST(10, 20)
P2 = P1 + S(10) + T(20) ' Add the offset amount to the additional ST axes for
P1.
```

Note that you cannot use the point operator for undefined points.

```
P1 = XY(10, 20, 30, 40, 50, 60)
P2 = P1 + S(10) + T(20)
      \ Error (ST are undefined for P1 and
        you cannot use the point operator)
P1 = XY(10, 20, 30, 40, 50, 60) +ST(10, 20) \ Error
P1 = XY(10, 20, 30, 40, 50, 60) +S(10) +T(20) \ Error
Go ST(10, 20) + X(10)
      \ Error (XY are undefined and
        you cannot use the point operator)
```

This example shows the additional ST axes coordinate values retrieved from the point data.

```
Print CS(P1), CT(P1)
```

Pallet motion

When you specify a pallet with the point data including the position data of additional axis, the position data of additional axis is also calculated by the pallet operator. If you use the additional axis as traveling axis, you can define a wide range pallet than for a single manipulator.


Also, if you want to use the additional axis not as traveling axis and exclude the additional axis position from the pallet operator, define the pallet with the point data that clears the additional axis position data.

22. Calibration of Commercial Vision Sensor and Robot

22.1 Overview

When using the commercially available vision sensors or image processing systems, instead of our Vision Guide, it is necessary to calibrate the image processing result (image coordinate system, camera coordinate system) with the robot coordinate system. This chapter describes the calibration procedure.

The figure below shows commands and functions related to calibration and behaviors of data and files.



The vision calibration data can be created in the following steps.

- (1) Install the camera
- (2) Create the image processing sequence for calibration(in each vision sensor)
- (3) Teach the robot position for calibration at necessary parts
- (4) Perform image processing at necessary parts and acquire the image processing result.
- (5) Execute calibration (VxCalib command)
- (6) Save calibration data (VxCalSave command)



If you are using our Vision Guide option, refer to the *Vision Guide* manual. Calibration with the Vision Guide option can be configured by the wizard easily.



CAUTION

- We cannot answer the questions regarding communication settings and usage for commercial vision sensors. Please contact the manufacture directly.

22.2 Specifications

Calibration data/Calibration file

Up to 16 calibration data can be saved to the robot controller at the same time.

If you are using more than 16 calibration data, load them from the file and save to the file.

Up to 16 files can be created. Be careful not to exceed the maximum number of files.


Camera installation

Following seven camera mounting types are supported. For details, refer to 22.3 *Camera Installation*.

- 1: Standalone
- 2: Fixed downward camera
- 3: Fixed upward camera
- 4: Mobile camera on the Joint #2
- 5: Mobile camera on the Joint #4
- 6: Mobile camera on the Joint #5
- 7: Mobile camera on the Joint #6

Image coordinate system

Following image shows the adapted image coordinate system. The unit is pixel.



22.3 Camera Installation

Camera installation method can be selected for each calibration data. The data set required for calibration differs depending on mounting types. Note that the wrong setting may result in improper calibration.

EPSON RC+ 7.0 supports the following camera installations:

Camera Installation	Description
Standalone	Camera can be installed anywhere. Camera does not have a relation with the robot. With this method, position information in the Robot coordinate system cannot be acquired. However, it can be converted from the image coordinate system to the camera coordinate system. That is, simple length measurement can be performed.
Fixed downward	Camera and target objects do not move and is looking down into robot work envelope. The camera acquires position information in the Robot coordinate system. The camera must be installed vertically to the XY plane of the specified coordinate system. (Angle gap may result in poor accuracy) Specified coordinate systems are Robot coordinate system and Local coordinate system. Uses nine reference points.
Fixed upward	Camera does not move and is looking up into a portion of the robot work envelope. For example, this installation method is used to check the position of the object which is carried by the robot. It does not require a reference point. The calibration target is on the end effector or the object held by the robot.
Mobile camera on the Joint #2	Camera is mounted on Joint 2 on SCARA robot or Cartesian robot. It reports robot world coordinates. Uses one reference point.
Mobile camera on the Joint #4	Camera is mounted on Joint 4 on SCARA robot or Cartesian robot. It reports robot world coordinates. Uses one reference point.
Mobile camera on the Joint #5	Camera is mounted on Joint 5 on 6-Axis robot. It reports robot world coordinates. Uses one reference point.
Mobile camera on the Joint #6	Camera is mounted on Joint 6 on 6-Axis robot. It reports robot world coordinates. Uses one reference point.

22.4 Reference Points

Reference points are important points to be used to calibrate the relation of the image coordinates and the Camera or Robot coordinate systems.

Each calibration scheme requires one or more reference points. The methods for teaching these points vary according to the camera mounting and orientation.

For Standalone camera calibration, you manually enter the coordinate values of the reference points into the system.

For all other camera calibrations, you teach the reference points using the robot.

22.5 Reference Points for Mobile Camera

This scheme requires one reference point. Also, TowRefPoint parameter can be specified. If TowRefPoint parameter is True, a pair (two points) of the position data is required for the reference point. Each position data consists of two position data of the robot when the U axis is at 0 degree and 180 degrees in the specified coordinate system. By the TwoRefPoint function, the system can determine more precise position of the reference position in the robot coordinate system. However, this function is not necessary if the robot tool is defined accurately.


For the reference point, the taught points where the robot jogged can be used.

Here are some examples of taught reference points:

- A part or calibration target in the robot work envelope.
- A hole somewhere in the work envelope that a tool mounted on the robot end effector can be slipped into.

22.6 Reference Points for Fixed Camera

The 'Fixed Downward' and 'Standalone' calibration schemes require a calibration target plate or sheet that contains nine targets.



Fixed Camera Calibration Targets

For 'Fixed Downward' calibrations, the targets could be holes in a plate that a rod on the robot end effector can be slipped into. The distances between the targets do not have to be exact.

For Standalone cameras, a pattern sheet can be used. The horizontal and vertical distances between the targets must be known.

22.7 Command List

Following table shows the commands and functions related to Vision calibration.


For details, refer to the *SPEL+ Language Reference*.

Command name	Function
VxCalib Statement	Creates calibration data for the vision system.
VxCalDelete Statement	Deletes the calibration data.
VxCalLoad Statement	Loads the calibration data from a file.
VxCalInfo Function	Returns the calibration completion status and the calibration result.
VxCalSave Statement	Saves the calibration data to a file.
VxTrans Function	Converts pixel coordinates to robot coordinates and returns the converted point data

23. Installing Controller Options

When you purchase options with your system, the options have already been installed on your system before shipment. Of course, you can purchase options separately.

To see what options are enabled on your system, select [Setup]-[Options]. The following dialog will be displayed.




Item	Description
Option	Name of the option.
Key Enabled	Indicates that the option is enabled in the controller.

To enable an option on site

1. Copy and paste or write down the Options Key Code. You can view this from the [Setup]-[Controller]-[Options] dialog.
2. Call the supplier of your region to purchase the enable key code for the desired option.
3. You will receive a code to enable the option from the supplier of your region.
4. Select the option to enable on the grid, and then click the <Enable> button.
5. Enter in the code you received from the supplier of your region.

NOTE


The key code is case sensitive.



If the DMB Board or CF card is replaced

If the DMB board or CF card is replaced due to malfunction, all configured options will be disabled. Follow the procedure in *To enable an option on site* to configure the options again.

- * If the DMB board or CF card is replaced, the previous code for enabling the option cannot be used.

24. Software License Agreement

SOFTWARE LICENSE AGREEMENT

IMPORTANT! READ THIS SOFTWARE LICENSE AGREEMENT CAREFULLY BEFORE INSTALLING OR USING THIS SOFTWARE.

This software products and/or any accompanying explanatory written materials (the “Software”) should only be installed or used by the Licensee (“you”) on the condition you agree with SEIKO EPSON CORPORATION (including its affiliates and licensors, “EPSON”) to the terms and conditions of this Agreement. By installing or using the Software, you are representing to agree with all the terms and conditions of this Agreement. If you do not agree with the terms and conditions of this Agreement, you are not permitted to install or use the Software. In this Agreement, affiliates mean any corporation or entity of which EPSON owns, directly or indirectly, a majority of the assets or voting stock.

1. License.

EPSON grants you a personal, nonexclusive, limited license to

- (i) install and use the Software on any single computer or EPSON’s robot controller products, following the instructions, terms and conditions under the “Epson RC+7.0 User’s Guide” and its “Appendix B: EPSON RC +7.0 Software”;
- (ii) make one copy of the Software for backup and archival purposes. For clarity, such backup and archival copy so made shall be treated as the Software herein;

2. Limitations.

You shall use the Software in a manner permitted herein. You agree not to (i) modify, adapt, translate or make any derivative works from the Software and (ii) attempt to reverse engineer, decompile, disassemble or otherwise attempt to discover the source code of the Software. Unless otherwise provided herein, you shall not share, rent, lease, encumber, sublicense, lend or distribute the Software.

3. Third Party Software

The Software may contain third party’s software (“Third Party Software”, including open-source software, such as GNU General Public License and GNU Lesser/ Library GPL). For clarity, a Third Party Software named XVL Kernel, owned by Lattice Technology Co.,Ltd (“XVL Kernel”) is included in the Software. If the Software contains the Third Party Software, you shall review and comply with the terms and conditions applicable to such Third Party Software before using the Software.

4. Ownership.

Excluding the Third Party Software, any title, ownership, intellectual property rights and any other rights in and to the Software shall remain with EPSON. Any title, ownership, intellectual property rights and any other rights in and to XVL Kernel, which is a Third Party Software, shall remain with Lattice Technology Co.,Ltd. You shall not be granted any title, ownership, intellectual property rights or any other rights in and to the Software unless explicitly provided herein. The Software is protected by Japanese Copyright Law and international copyright treaties, as well as other intellectual property laws and treaties. You agree not to remove or alter any copyright and other proprietary notices on any copies of the Software.

5. Protection and Security.

You agree to use your best efforts and take all reasonable steps to safeguard the Software to ensure that no unauthorized person has access to it and that no unauthorized copy, publication, disclosure or distribution of the Software is made. You acknowledge that the Software contains valuable, confidential information and trade secrets and that unauthorized use and copy are harmful to EPSON. You shall hold in strict confidence the Software and any information obtained in connection with the Software.

6. No Warranty.

You acknowledge and agree that the use of the Software is at your sole risk. THE SOFTWARE IS PROVIDED “AS IS” AND WITHOUT ANY WARRANTY OF ANY KIND. EPSON DOES NOT AND CANNOT WARRANT THE PERFORMANCE OR RESULTS YOU MAY OBTAIN BY USING THE SOFTWARE. EPSON MAKES NO WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.

7. Limitation of Liability.

IN NO EVENT WILL EPSON BE LIABLE TO YOU, WHETHER ARISING UNDER CONTRACT, TORT (INCLUDING NEGLIGENCE), STRICT LIABILITY, BREACH OR WARRANTY, MISREPRESENTATION OR OTHERWISE, FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, INCIDENTAL OR SPECIAL DAMAGES, INCLUDING ANY LOST PROFITS OR LOST SAVINGS, EVEN IF EPSON OR ITS REPRESENTATIVE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR FOR ANY CLAIM BY ANY THIRD PARTY. IN THE EVENT LIMITATION OF LIABILITY HEREUNDER IS FOUND INVALID OR UNENFORCEABLE BY A COURT OF COMPETENT JURISDICTION, THE AGGREGATE LIABILITY OF EPSON TO YOU FOR ANY DAMAGES OR LOSS SHALL NOT EXCEED THE TOTAL AMOUNT PAID BY YOU TO EPSON IN CONSIDERATION OF THE SOFTWARE.

8. Termination.

Without prejudice to any other rights EPSON has, this Agreement shall immediately terminate without any notice upon failure by you to comply with its terms. You may also terminate this Agreement at any time by uninstalling and destroying the Software. For clarity, you shall not be released from any obligations imposed prior to the termination of this Agreement.

9. Export Restriction.

You agree not to transfer, export or re-export the Software and any data or information which you obtained from the Software or in connection with this Agreement without a proper license under Japanese law, restrictions and regulations or the laws of the jurisdiction in which you obtained the Software.

10. Governing Law and Severability

This Agreement shall be governed by and construed under the laws of Japan without regard to its conflicts of law rules. If any provision herein is found invalid or unenforceable by a court of competent jurisdiction, it will not affect the validity of the balance of this Agreement, which shall remain valid and enforceable according to its terms.

11. Updating Software Version.

Epson may provide you an updated version of the Software for the purpose of improvement and bug-fixes. Such updated Software shall be deemed to be the Software and be governed by this Agreement.

12. Entire Agreement.

This Agreement is the entire agreement between the parties with respect to the Software and supersedes any communication, advertisement, or representation concerning the Software. This Agreement shall be binding upon and inure to the benefit of the parties hereto and their respective successors, assigns and legal representatives.

13. General Provisions.

- (1) EPSON may change, modify or otherwise alter this Agreement in its sole discretion at any time with or without notice to you. You shall review this Agreement on a regular basis to acknowledge such changes. By using the Software after any such changes have been made, you are deemed to agree to comply with, and to be bound by, the modified Agreement.
- (2) Any translation of this Agreement is provided solely for your convenience and is not intended to modify the terms and conditions of this Agreement. In the event of a conflict between the Japanese version and any versions in other languages of this Agreement, the Japanese version shall prevail and govern.

14. U.S. Government End Users.

If you are acquiring the Software on behalf of any unit or agency of the United States Government, the following provisions apply. The Government agrees:

- (i) if the Software is supplied to the Department of Defense (DoD), the Software is classified as “Commercial Computer Software” and the Government is acquiring only “restricted rights” in the Software and its documentation as that term is defined in Clause 252.227-7013(c)(1) of the DFARS; and (ii) if the Software is supplied to any unit or agency of the United States Government other than DoD, the Government’s rights in the Software and its documentation will be as defined in Clause 52.227-19(c)(2) of the FAR or, in the case of NASA, in Clause 18-52.227-86(d) of the NASA supplement to the FAR.

©Seiko Epson Corporation 2016. All rights reserved.

Appendix A: Automatic Processing of Project Import

Project Import for EPSON RC+ 6.*

When projects created in EPSON RC+ 6.* are imported, all project files are copied to the new EPSON RC+ 7.0 project directory.

Vision Guide Conversion

When using the smart camera or flame grabber, model images of each object (Correlation object, Geometric object, etc.) are not imported.

Perform model teaching again after importing them.

Project Import for EPSON RC+ 5.*

When projects created in EPSON RC+ 5.* are imported, all project files are copied to the new EPSON RC+ 7.0 project directory. In addition, the following processes are executed automatically:

- Point file update
- User Program Conversion

Point File Update

For EPSON RC+ 5.*, the .PTS files are updated automatically to the EPSON RC+ 6.0 .PTS file version.

User Program Conversion

Project Import for EPSON RC+ 3.* / 4.*

When projects created in EPSON RC+ 3.* / 4.* are imported, the following processes are executed automatically:

- User program conversion
- Point file conversion
- I/O label file conversion
- User error label file conversion
- Vision Guide conversion

User Program Conversion

The tables below show the syntax conversions from EPSON RC+ 3.* / 4.* to EPSON RC+ 7.0.

Project Type	EPSON RC+ 4.*	EPSON RC+ 7.0
Syntax	While	Do While
	Wend	Loop
	Trap...Call	Trap...Xqt

Project Type	EPSON RC+ 3.*	EPSON RC+ 7.0
Syntax	While	Do While
	Wend	Loop
	Trap...Call	Trap...Xqt
	On \$, Off \$	MemOn, MemOff
	Sw(\$	MemSw(
	Sw \$(MemSw(
	In(\$	MemIn(
	In \$(MemIn(

Project Type	EPSON RC+ 3.*	EPSON RC+ 7.0
Syntax	Out \$	MemOut
	Xqt !	Xqt
	Quit !	Quit
	Resume !	Resume
	Halt !	Halt

Point File Conversion

For EPSON RC+ 3.*, the EPSON RC+ 7.0 *.PTS files are generated automatically from the .PNT files and corresponding .DEF files.

Project Type	EPSON RC+ 3.*	EPSON RC+ 7.0
Point File	*.PNT file (Point file) *.DEF file (Point label file)	*.PTS

For EPSON RC+ 4.*, the EPSON RC+ 7.0 *.PTS files are generated automatically from the .PNT files.

Project Type	EPSON RC+ 4.*	EPSON RC+ 7.0
Point File	*.PNT file (Point file)	*.PTS

I/O Label File Conversion

IOLabels.dat is generated automatically from the following three files.

Project Type	EPSON RC+ 3.* / 4.*	EPSON RC+ 7.0
I/O Label File	inplabel.txt outlabel.txt memlabel.txt	IOLabels.dat

User Error Label File Conversion

Files are changed automatically as the user error numbers are changed.

Project Type	EPSON RC+ 3.* / 4.*	EPSON RC+ 7.0
User Error Label	30000 to 30999	8000 to 8999
User Error Label File	UserErrors.txt	UserErrors.dat

Vision Guide Conversion

EPSON RC+ 3.* / 4.* project vision files are updated to EPSON RC+ 7.0 format automatically. Files related to sequence, objects, and calibration are all imported.

Note:

When using the smart camera or flame grabber, model images of each object (Correlation object, Geometric object, etc.) are not imported.

Perform model teaching again after importing them.

Project Import for SPEL for Windows 2.*

When projects created in SPEL for Windows 2.* are imported, the following processes are executed automatically.

- User program conversion
- Global Preserve variable table conversion
- Point file conversion
- Global variable conversion
- I/O label file conversion
- Local variable conversion

User Program Conversion

The table below shows the syntax conversions to EPSON RC+ 7.0.

Project Type	SPEL for Windows 2.*	EPSON RC+ 7.0
Syntax	While	Do While
	Wend	Loop
	Trap n...Call	Trap n...Xqt
	On \$, Off \$	MemOn, MemOff
	Sw(\$	MemSw(
	Sw \$(MemSw(
	In(\$	MemIn(
	In \$(MemIn(
	Out \$	MemOut
	Xqt !	Xqt
	Quit !	Quit
	Resume !	Resume
	Halt !	Halt
	Palet	Pallet
	Print"	Print "
	Date\$(0)	Date\$
	Time\$(0)	Time\$
	JS(0)	JS
	TW(0)	TW
	ZeroFlg(0)	ZeroFlg
	Entry	Global
	Config statement	SetCom statement
	Cooked	Line deleted
	SetRaw	Line deleted
	SelRB	Line deleted
	SelRB1	Line deleted
	Extern	Line deleted
	End	Quit All
	GetDate d\$	d\$ = Date\$
	GetTime t\$	t\$ = Time\$

Point File Conversion

EPSON RC+ 7.0 *.PTS files are generated automatically from the .PNT files and corresponding .DEF files.

Project Type	SPEL for Windows 2.*	EPSON RC+ 7.0
Point File	*.PNT file (Point file) *.DEF file (Point label)	*.PTS

I/O Label File Conversion

Converts the I/O labels automatically.

Project Type	SPEL for Windows 2.*	EPSON RC+ 6.0
I/O Label File	<i>ProjectName</i> .IOL	IOLabels.dat

Global Preserve Variable Table Conversion

Backup variable definitions created in the SPEL for Windows 2.* Project Menu are converted into Global Preserve declaration statements in the first program file.

(Example)

If the SPEL for Windows 2.* project defines an integer backup variable called “s_iValue”, the following statement is generated in the first program of the project.

Global Preserve Integer s_iValue

Global Variable Conversion

Global variables (Entry / Extern) in SPEL for Windows 2.* projects are converted to Global variables in EPSON RC+ 7.0.

Project Type	SPEL for Windows 2.*	EPSON RC+ 7.0
Global Variable (Command)	Entry / Extern command	Global command

Local Variable Conversion

Local variables in SPEL for Windows 2.* functions can be used throughout the entire file in which they are declared. These variables are converted to module variables or local variables in EPSON RC+ 7.0, depending on their scope.

If the variable is used in only one function, it is converted to a local variable in that function.

If the variable is used in more than one function, it is converted to a module variable.

Appendix B: EPSON RC+ 7.0 Software

EPSON RC+ 7.0 can be used in the following operating systems.

Windows 8.1 Pro (EPSON RC+ 7.0 Ver.7.1.0 or later)

Windows 10 Pro (EPSON RC+ 7.0 Ver.7.2.0 or later)


EPSON RC+ 7.0 Software Installation

The EPSON RC+ 7.0 software needs to be installed on your development PC.

- (1) Insert the EPSON RC+ 7.0 Setup DVD in the DVD drive.
- (2) The following dialog will be displayed. Click <Next>.




- (3) Enter your user name and company name and click <Next>.







- (4) Select the drive where you want to install EPSON RC+ 7.0 and click <Next>. The installation directory is called EpsonRC70. This cannot be changed.



- (5) The dialog for selecting the options to be installed will be displayed. Check the options you want to install and click <Next>.



- (6) The dialog to review the settings will be displayed. If you are satisfied with the settings, click <Next>.



- (7) If required, install “Windows Installer” on your system. This may take several minutes.

**NOTE**

Adobe Reader needs to be installed on your PC in order to view the EPSON RC+ 7.0 manuals. If the installer cannot find Adobe Reader on your system, it will be installed at this time. Follow the instructions in the Adobe installer. Do not restart the system after the Adobe Reader installation has completed.

- (8) After the installation has completed, restart your computer.
The EPSON RC+ 7.0 software installation is now completed.

**NOTE**

When installing RC; an error “Cannot create parser instance.” may occur. If the error occurs, uninstall RC+ once and execute Microsoft\VC151719.exe in the DVD and re-install RC+.

To install the service pack

If the following folder exists in the EPSON RC+7.0 setup DVD, the service pack is available.

\EpsonRC\Service_Packs


Install the latest service pack by double-clicking “erc***sp*.exe” in the folder. (***: RC+ version / *: service pack version)

For details of the service pack, refer to “readme*.txt”. (*: language)

After Installing EPSON RC+ 7.0 Software

EPSON RC+ 7.0 software may boot slowly when using PC with EPSON RC+7.0 software in an environment without the internet connection. Follow the steps below and change the configurations of the internet options.

- (1) Start the Internet Explorer and display the [Internet Options] dialog.
Click the [Advanced] tab.



- (2) Uncheck the [Check for publisher's certification revocation] checkbox.
- (3) Click the <OK> button.

EPSON RC+ 7.0 Software Update



NOTE

Make sure that EPSON RC + 7.0 is updated by a user with Administrator right.

Insert the EPSON RC+ 7.0 setup DVD into the DVD drive and follow the menu to update the software.

Appendix C: Simulator Functions List of Unsupported Manipulator Models

Simulator functions do not support the following Manipulator models.

X5 series Manipulators

All models do not support the simulator functions.

There is no alternative model.

G6 series Manipulators

Protected models as described in the table below do not support the simulator functions.

G6-451D	G6-551D	G6-651D	G6-451D-II	G6-551D-II	G6-651D-II
G6-451DR	G6-551DR	G6-651DR	G6-451DR-II	G6-551DR-II	G6-651DR-II
G6-451DW	G6-551DW	G6-651DW	G6-451DW-II	G6-551DW-II	G6-651DW-II
G6-451P	G6-551P	G6-651P	G6-451P-II	G6-551P-II	G6-651P-II
G6-451PR	G6-551PR	G6-651PR	G6-451PR-II	G6-551PR-II	G6-651PR-II
G6-451PW	G6-551PW	G6-651PW	G6-451PW-II	G6-551PW-II	G6-651PW-II
G6-453D	G6-553D	G6-653D	G6-453D-II	G6-553D-II	G6-653D-II
G6-453DR	G6-553DR	G6-653DR	G6-453DR-II	G6-553DR-II	G6-653DR-II
G6-453DW	G6-553DW	G6-653DW	G6-453DW-II	G6-553DW-II	G6-653DW-II
G6-453P	G6-553P	G6-653P	G6-453P-II	G6-553P-II	G6-653P-II
G6-453PR	G6-553PR	G6-653PR	G6-453PR-II	G6-553PR-II	G6-653PR-II
G6-453PW	G6-553PW	G6-653PW	G6-453PW-II	G6-553PW-II	G6-653PW-II

When connecting to Virtual Controller, the following models can be set as an alternative model. However, external dimensions and motion range of arms may differ.

Standard model : G6-***S*, G6-***S*-II

Cleanroom model : G6-***C*, G6-***C*-II

For more details, refer to the following manual:

SCARA Robot G6 series Manipulator Manual

G10 series Manipulators

Protected models as described in the table below do not support the simulator functions.

G10-651D	G10-851D	G10-651D-II	G10-851D-II
G10-651DR	G10-851DR	G10-651DR-II	G10-851DR-II
G10-651DW	G10-851DW	G10-651DW-II	G10-851DW-II
G10-651P	G10-851P	G10-651P-II	G10-851P-II
G10-651PR	G10-851PR	G10-651PR-II	G10-851PR-II
G10-651PW	G10-851PW	G10-651PW-II	G10-851PW-II
G10-654D	G10-854D	G10-654D-II	G10-854D-II
G10-654DR	G10-854DR	G10-654DR-II	G10-854DR-II
G10-654DW	G10-854DW	G10-654DW-II	G10-854DW-II
G10-654P	G10-854P	G10-654P-II	G10-854P-II
G10-654PR	G10-854PR	G10-654PR-II	G10-854PR-II
G10-654PW	G10-854PW	G10-654PW-II	G10-854PW-II

When connecting to Virtual Controller, the following models can be set as an alternative model. However, external dimensions and motion range of arms may differ.

Standard model : G10-***S*, G10-***S*-II

Cleanroom model : G10-***C*, G10-***C*-II

For more details, refer to the following manual:

SCARA Robot G10/G20 series Manipulator Manual

G20 series Manipulators

Protected models as described in the table below do not support the simulator functions.

G20-851D	G20-A01D	G20-851D-II	G20-A01D-II
G20-851DR	G20-A01DR	G20-851DR-II	G20-A01DR-II
G20-851DW	G20-A01DW	G20-851DW-II	G20-A01DW-II
G20-851P	G20-A01P	G20-851P-II	G20-A01P-II
G20-851PR	G20-A01PR	G20-851PR-II	G20-A01PR-II
G20-851PW	G20-A01PW	G20-851PW-II	G20-A01PW-II
G20-854D	G20-A04D	G20-854D-II	G20-A04D-II
G20-854DR	G20-A04DR	G20-854DR-II	G20-A04DR-II
G20-854DW	G20-A04DW	G20-854DW-II	G20-A04DW-II
G20-854P	G20-A04P	G20-854P-II	G20-A04P-II
G20-854PR	G20-A04PR	G20-854PR-II	G20-A04PR-II
G20-854PW	G20-A04PW	G20-854PW-II	G20-A04PW-II

When connecting to Virtual Controller, the following models can be set as an alternative model. However, external dimensions and motion range of arms may differ.

Standard model : G20-***S*, G20-***S*-II

Cleanroom model : G20-***C*, G20-***C*-II

For more details, refer to the following manual:

SCARA Robot G10/G20 series Manipulator Manual