

To our customers,

Old Company Name in Catalogs and Other Documents

On April 1st, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: <http://www.renesas.com>

April 1st, 2010
Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (<http://www.renesas.com>)

Send any inquiries to <http://www.renesas.com/inquiry>.

Notice

1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
2. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
7. Renesas Electronics products are classified according to the following three quality grades: "Standard", "High Quality", and "Specific". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as "Specific" without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics product for any application for which it is not intended without the prior written consent of Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as "Specific" or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is "Standard" unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; safety equipment; and medical equipment not specifically designed for life support.

"Specific": Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

H8S, H8/300 Series Simulator/Debugger

User's Manual

Renesas Microcomputer
Development Environment
System

Notes regarding these materials

1. This document is provided for reference purposes only so that Renesas customers may select the appropriate Renesas products for their use. Renesas neither makes warranties or representations with respect to the accuracy or completeness of the information contained in this document nor grants any license to any intellectual property rights or any other rights of Renesas or any third party with respect to the information in this document.
2. Renesas shall have no liability for damages or infringement of any intellectual property or other rights arising out of the use of any information in this document, including, but not limited to, product data, diagrams, charts, programs, algorithms, and application circuit examples.
3. You should not use the products or the technology described in this document for the purpose of military applications such as the development of weapons of mass destruction or for the purpose of any other military use. When exporting the products or technology described herein, you should follow the applicable export control laws and regulations, and procedures required by such laws and regulations.
4. All information included in this document such as product data, diagrams, charts, programs, algorithms, and application circuit examples, is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas products listed in this document, please confirm the latest product information with a Renesas sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas such as that disclosed through our website. (<http://www.renesas.com>)
5. Renesas has used reasonable care in compiling the information included in this document, but Renesas assumes no liability whatsoever for any damages incurred as a result of errors or omissions in the information included in this document.
6. When using or otherwise relying on the information in this document, you should evaluate the information in light of the total system before deciding about the applicability of such information to the intended application. Renesas makes no representations, warranties or guaranties regarding the suitability of its products for any particular application and specifically disclaims any liability arising out of the application and use of the information in this document or Renesas products.
7. With the exception of products specified by Renesas as suitable for automobile applications, Renesas products are not designed, manufactured or tested for applications or otherwise in systems the failure or malfunction of which may cause a direct threat to human life or create a risk of human injury or which require especially high quality and reliability such as safety systems, or equipment or systems for transportation and traffic, healthcare, combustion control, aerospace and aeronautics, nuclear power, or undersea communication transmission. If you are considering the use of our products for such purposes, please contact a Renesas sales office beforehand. Renesas shall have no liability for damages arising out of the uses set forth above.
8. Notwithstanding the preceding paragraph, you should not use Renesas products for the purposes listed below:
 - (1) artificial life support devices or systems
 - (2) surgical implantations
 - (3) healthcare intervention (e.g., excision, administration of medication, etc.)
 - (4) any other purposes that pose a direct threat to human lifeRenesas shall have no liability for damages arising out of the uses set forth in the above and purchasers who elect to use Renesas products in any of the foregoing applications shall indemnify and hold harmless Renesas Technology Corp., its affiliated companies and their officers, directors, and employees against any and all damages arising out of such applications.
9. You should use the products described herein within the range specified by Renesas, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas shall have no liability for malfunctions or damages arising out of the use of Renesas products beyond such specified ranges.
10. Although Renesas endeavors to improve the quality and reliability of its products, IC products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Please be sure to implement safety measures to guard against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other applicable measures. Among others, since the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
11. In case Renesas products listed in this document are detached from the products to which the Renesas products are attached or affixed, the risk of accident such as swallowing by infants and small children is very high. You should implement safety measures so that Renesas products may not be easily detached from your products. Renesas shall have no liability for damages arising out of such detachment.
12. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written approval from Renesas.
13. Please contact a Renesas sales office if you have any questions regarding the information contained in this document, Renesas semiconductor products, or if you have any other inquiries.

Trademarks

Microsoft, MS-DOS, Windows, Windows NT are registered trademarks of Microsoft Corporation.

Visual SourceSafe is a trademark of Microsoft Corporation.

IBM is a registered trademark of International Business Machines Corporation.

All brand or product names used in this manual are trademarks or registered trademarks of their respective companies or organizations.

Document Information

Product Code: S32HEWM

Version:

Copyright © Renesas Technology Corp. 2003. All rights reserved.

About This Manual

This manual describes the HEW system. This manual is composed of two parts. HEW part describes information on the basic “look and feel” of the HEW and customizing the HEW environment and detail the build. Figure in the HEW part are those of the SH series. Simulator/Debugger part describes Debugger functions of the High-performance Embedded Workshop.

This manual does not intend to explain how to write C/C++ or assembly language programs, how to use any particular operating system or how best to tailor code for the individual devices. These issues are left to the respective manuals.

Document Conventions

This manual uses the following typographic conventions:

Table 1 **Typographic Conventions**

Convention	Meaning
[Menu->Menu Option]	Bold text with ‘->’ is used to indicate menu options (for example, [File->Save As...]).
FILENAME.C	Uppercase names are used to indicate filenames.
<u>“enter this string”</u>	Used to indicate text that must be entered (excluding the “” quotes).
Key + Key	Used to indicate required key presses. For example, CTRL+N means press the CTRL key and then, whilst holding the CTRL key down, press the N key.
 (The “how to” symbol)	When this symbol is used, it is always located in the left hand margin. It indicates that the text to its immediate right is describing “how to” do something.

Contents

Section 1	Overview	1
Section 2	Simulator/Debugger Functions	3
2.1	Features	3
2.2	Target User Program	4
2.3	Simulation Range	4
2.4	Memory Management	5
2.5	Instruction-Execution Reset Processing	6
2.6	Exception Processing	7
2.7	H8S/2000 CPU Specific Functions	8
2.8	H8S/2600 CPU Specific Functions	9
2.9	H8SX Series CPU Specific Functions	10
2.10	Control Registers	10
2.11	Timer (H8S Series and H8SX Series)	11
2.11.1	Supported Range	11
2.11.2	Control Registers	11
2.11.3	Clocks	12
2.11.4	Using a Timer	12
2.11.5	Notes on Using a Timer	12
2.12	Trace	12
2.13	Standard I/O and File I/O Processing	13
2.14	Calculation of the Number of Instruction Execution Cycles	15
2.15	Break Conditions	16
2.16	Floating-Point Data	21
2.17	Display of Function Call History	21
2.18	Performance Measurement	22
2.18.1	Profiler	22
2.18.2	Performance Analysis	22
2.19	Pseudo-Interrupts	23
2.20	Coverage	24
Section 3	Debugging	25
3.1	Creating the Workspace for Simulator/Debugger	26
3.1.1	Selecting a Debugging Platform	26
3.1.2	Setting up a Workspace for the Simulator/Debugger	27
3.2	Modifying the Simulator/Debugger Settings	29

3.2.1	Modifying the Simulator System	29
3.2.2	Modifying the Memory Map and Memory Resource Settings	31
3.2.3	Set Memory Map Dialog Box.....	33
3.2.4	Set Memory Resource Dialog Box	35
3.3	Simulating Peripheral Functions.....	36
3.3.1	Registering Peripheral Function Simulation Modules	36
3.3.2	Changing the Addresses of Peripheral Functions	38
3.3.3	Changing the Interrupt Source Information of Peripheral Functions.....	40
3.3.4	Allocating Memory Resources to the Interrupt Priority Register	42
3.3.5	Viewing the Names of Connected Peripheral Functions	42
3.4	Using the Simulator/Debugger Breakpoints	42
3.4.1	Listing the Breakpoints.....	42
3.4.2	Setting a Breakpoint.....	44
3.4.3	Modifying Breakpoints	54
3.4.4	Enabling a Breakpoint	54
3.4.5	Disabling a Breakpoint	54
3.4.6	Deleting a Breakpoint	54
3.4.7	Deleting All Breakpoints	54
3.4.8	Viewing the Source Line for a Breakpoint	55
3.4.9	Closing Input or Output File.....	55
3.4.10	Closing All Input and Output Files	55
3.5	Viewing Trace Information.....	56
3.5.1	Opening the Trace Window	56
3.5.2	Specifying Trace Acquisition Conditions	56
3.5.3	Acquiring Trace Information	58
3.5.4	Searching for a Trace Record	59
3.5.5	Clearing the Trace Information.....	60
3.5.6	Saving the Trace Information in a File	60
3.5.7	Viewing the Source File	60
3.5.8	Trimming the Source	60
3.5.9	Analyzing Statistical Information.....	61
3.6	Viewing the Profile Information.....	63
3.6.1	Stack Information Files.....	63
3.6.2	Profile Information Files.....	65
3.6.3	Loading Stack Information Files	67
3.6.4	Enabling the Profile	69
3.6.5	Specifying Measurement Mode	69
3.6.6	Executing the Program and Checking the Results	69
3.6.7	List Sheet	70
3.6.8	Tree Sheet	71

3.6.9	Profile-Chart Window.....	74
3.6.10	Types and Purposes of Displayed Data.....	75
3.6.11	Creating Profile Information Files	76
3.6.12	Notes	77
3.7	Analyzing Performance.....	78
3.7.1	Opening the Performance Analysis Window	78
3.7.2	Specifying a Target Function.....	79
3.7.3	Starting Performance Data Acquisition	79
3.7.4	Resetting Data.....	79
3.7.5	Deleting a Target Function	80
3.7.6	Deleting All Target Functions.....	80
3.7.7	Saving the Currently Displayed Contents	80
3.8	Acquiring Code Coverage.....	81
3.8.1	Opening the Coverage Window.....	81
3.8.2	Acquiring All Coverage Information	84
3.8.3	Clearing All Coverage Information	84
3.8.4	Viewing the Source Window	84
3.8.5	Specifying the New Coverage Range	84
3.8.6	Changing the Coverage Range.....	84
3.8.7	Deleting the Selected Coverage Range.....	85
3.8.8	Acquiring Coverage Information	86
3.8.9	Clearing Coverage Information	86
3.8.10	Saving Coverage Information in a File	86
3.8.11	Loading Coverage Information from a File	87
3.8.12	Updating the Information.....	87
3.8.13	Confirmation Request Dialog Box.....	88
3.8.14	Save Coverage Data Dialog Box	89
3.8.15	Displaying the Coverage Information in the Editor Window	90
3.8.16	Displaying the Coverage Information in the [Disassembly] Window	91
3.9	Generating a Pseudo-Interrupt Manually	92
3.9.1	[Trigger] Window	92
3.9.2	[GUI I/O] Window.....	94
3.10	Standard I/O and File I/O Processing.....	98
3.10.1	Opening the Simulated I/O Window.....	98
3.10.2	I/O Functions	99
3.11	Creating a Virtual I/O Panel.....	102
3.11.1	Opening the [GUI I/O] Window	103
3.11.2	Creating a Button	104
3.11.3	Creating a Label.....	106
3.11.4	Creating an LED	109

3.11.5	Creating Fixed Text	112
3.11.6	Changing the Size and Position of an Item	114
3.11.7	Copying an Item	114
3.11.8	Deleting an Item	114
3.11.9	Showing the Grid.....	115
3.11.10	Saving I/O Panel Information	115
3.11.11	Loading I/O Panel Information	115
Section 4 Windows		117
Section 5 Command Lines.....		119
5.1	Commands (Functional Order)	119
5.1.1	Execution	119
5.1.2	Download.....	120
5.1.3	Register	120
5.1.4	Memory	121
5.1.5	Assemble/Disassemble	121
5.1.6	Break.....	122
5.1.7	Trace	122
5.1.8	Coverage	123
5.1.9	Performance.....	123
5.1.10	Watch	123
5.1.11	Script/Logging	124
5.1.12	Memory Resource.....	124
5.1.13	Simulator/Debugger Settings	124
5.1.14	Standard I/O and File I/O.....	125
5.1.15	Utility	125
5.1.16	Project/Workspace	126
5.1.17	Test Tool Facility.....	126
5.2	Commands (Alphabetical Order)	127
Section 6 Messages.....		133
6.1	Information Messages	133
6.2	Error Messages	134
Section 7 Tutorial		137
7.1	Preparation	137
7.1.1	Sample Program.....	137
7.1.2	Creating the Sample Program	137
7.2	Settings for Debugging	138

7.2.1	Allocating the Memory Resource	138
7.2.2	Downloading the Sample Program	140
7.2.3	Displaying the Source Program	141
7.2.4	Setting a PC Breakpoint.....	142
7.2.5	Setting the Profiler	143
7.2.6	Setting the Simulated I/O.....	144
7.2.7	Setting the Trace Information Acquisition Conditions	146
7.2.8	Setting the Stack Pointer and Program Counter.....	147
7.3	Start Debugging	147
7.3.1	Executing a Program.....	147
7.3.2	Using the Trace Buffer.....	151
7.3.3	Performing Trace Search	152
7.3.4	Checking Simulated I/O.....	153
7.3.5	Checking the Breakpoints	154
7.3.6	Watching Variables.....	154
7.3.7	Executing the Program in Single Steps.....	156
7.3.8	Checking Profile Information	162

Section 1 Overview

The simulator/debugger is a powerful development environment tool for embedded applications running on Renesas Technology microcomputers.

The simulator/debugger is used with the High-performance Embedded Workshop (HEW). The HEW provides a graphical user interface that eases the development and debugging of applications written in the C/C++ programming languages or assembly language for Renesas Technology microcomputers. Its aim is to provide a powerful yet intuitive way of accessing, observing and modifying the debugging platform on which the application is running.

READ the simulator/debugger and HEW help information before using the simulator/debugger.

Section 2 Simulator/Debugger Functions

This section describes the functions of the H8S, H8/300 series simulator/debugger.

2.1 Features

- Since the simulator/debugger runs on a host computer, software debugging can start without using an actual user system, thus reducing overall system development time.
- The simulator/debugger performs a simulation to calculate the number of instruction execution cycles for a program, thus enabling performance evaluation without using an actual user system.
- The simulator/debugger provides pseudo-interrupt and I/O-simulation functions for simple system-level simulation.
- The simulator/debugger offers the following functions that enable efficient program testing and debugging.
 - The ability to handle all of the H8S, H8/300 series CPUs
 - Functions to stop or continue execution when an error occurs during user program execution
 - Profile data acquisition and function-unit performance measurement
 - A comprehensive set of break functions
 - Functions to set or edit memory maps
 - Functions to display function call history
 - Coverage information is displayed in the C/C++ or assembly-source level
 - Visual debugging functions provided through the display of images or waveforms
- The breakpoints, memory map, performance, and trace can be set through the dialog boxes under Windows®. Environments corresponding to each memory map of the H8S, H8/300 series microcomputers can be set through the dialog box.
 - Intuitive user interface
 - Online help
 - Common display and operability

2.2 Target User Program

Load modules in the Elf/Dwarf2 format can be symbolically debugged with the simulator/debugger. Load modules in other formats can be downloaded, and their instructions can be executed; however, they cannot be symbolically debugged. For details, refer to section 17.18.2, Elf/Dwarf2 Support in the High-performance Embedded Workshop V.4.03 User's Manual.

2.3 Simulation Range

The simulator/debugger provides simulation functions for the H8/300, H8/300L, H8/300H, H8S/2600, H8S/2000, and H8SX series microcomputers.

The simulator/debugger supports the following H8S, H8/300 series microcomputer functions:

- All CPU instructions
- Exception processing
- Registers
- All address space
- CPU modes shown in table 2.1

Table 2.1 Platforms and CPU Modes

Names of Debugging Platforms	CPU Modes
H8/300 Simulator	H8/300
H8/300L Simulator	H8/300L
H8/300HA Simulator	H8/300H: advanced mode
H8/300HN Simulator	H8/300H: normal mode
H8S/2600A Simulator	H8S/2600: advanced mode
H8S/2600N Simulator	H8S/2600: normal mode
H8S/2000A Simulator	H8S/2000: advanced mode
H8S/2000N Simulator	H8S/2000: normal mode
H8SX Normal Simulator	H8SX: normal mode
H8SX Advanced Simulator	H8SX: advanced mode
H8SX Maximum Simulator	H8SX: maximum mode

The simulator/debugger does not support the following H8S, H8/300 series MCU functions. Programs that use these functions must be debugged with the H8S, H8/300 series emulator.

- Dual-port RAM
- Timer (Not supported in the H8/300 series only)
- Pulse-width modular
- Serial communication interface (SCI)
- A/D converter
- I/O ports
- Interrupt controller

2.4 Memory Management

Memory Map Specification: A memory map is used to calculate the number of memory access cycles during simulation. The following items can be specified:

- Memory type
- Start and end addresses of the memory area
- Number of memory access cycles
- Memory data bus width

For details, refer to section 3.2.2, Modifying the Memory Map and Memory Resource Settings. The user program can be executed in all areas except for the internal I/O area.

Memory Resource Specification: A memory resource must be specified to load and execute a user program. The following items can be specified:

- Start address
- End address
- Access type

The access type is readable/writable, read-only, or write-only.

Since an error occurs if the user program attempts an illegal access (for example, trying to write to read-only memory), such an illegal access in the user program can be easily detected.

Unlike the other memory, EEPROM is writable by the EEPMOV instruction even if its access type is read-only. Other instructions than EEPMOV are not available.

For details on memory resource setting, refer to section 3.2.2, Modifying the Memory Map and Memory Resource Settings.

2.5 Instruction-Execution Reset Processing

The simulator/debugger resets the instruction execution counts and the number of instruction execution cycles when:

- The program counter (PC) is modified after the instruction simulation stops and before it restarts.
- The Run command to which the execution start address has been specified is executed.
- Initialization is performed or the program is loaded.

2.6 Exception Processing

The simulator/debugger detects the generation of TRAPA instructions (H8/300H, H8S, and H8SX series only) and trace exceptions (H8S and H8SX series only) and simulates exception processing. Accordingly, simulation can be performed even when an exception occurs.

The simulator/debugger simulates exception processing with the following procedures.

1. Detects an exception during instruction execution.
2. Saves the PC and CCR in the stack area. EXR is also saved when the enabled bit of EXR is on. If an error occurs when saving, the simulator/debugger stops exception processing, shows that the exception processing error has occurred, and returns to the command input wait state.
3. Sets the I bit in CCR to 1.
4. Reads the start address from the vector address corresponding to the vector number. If an error occurs when reading, the simulator/debugger stops exception processing, shows that the exception processing error has occurred, and returns to the command input wait state.
5. Starts instruction execution from the start address. If the start address is 0, the simulator/debugger stops exception processing, shows that the exception processing error has occurred, and returns to the command input wait state.

2.7 H8S/2000 CPU Specific Functions

The H8S/2000-series simulator/debugger supports interrupt modes. Use the bits INTM1 and INTM0 in SYSCR to set the interrupt modes. Note that SYSCR only supports INTM1 and INTM0. The initial value of the SYSCR address is H'FF39, and this value can be changed by changing the [SYSCR Address] field in the [Simulator System] dialog box. The changed address value is saved in the session file.

The simulator/debugger supports interrupt modes 0, 1, and 2, though the availability of interrupt modes depends on the CPU in use.

The control levels for event-driven interrupts vary as follows:

- If [Interrupt] is selected and [Priority] is 0 in the [Action type] field of the [Select Break Type] dialog box, the control level is 0.
- If [Interrupt] is selected and [Priority] is not 0 in the [Action type] field of the [Select Break Type] dialog box, the control level is 1.

2.8 H8S/2600 CPU Specific Functions

MAC Instruction: The multiplication/accumulation operation (MAC instruction) can be performed on the H8S/2600 CPU. In this instruction, a saturation and non-saturation operations are selectable. The simulator/debugger determines the operation with a value of bit 7 (hereafter called as the MACS bit) in the SYSCR register of internal I/O.

MACS bit 0: Non-saturation operation

MACS bit 1: Saturation operation

EXR Register: The EXR register can be used on the H8S/2600 CPU. It is also possible to set the enable or disable state of this register. The simulator/debugger determines the operation with a value of bit 5 (hereafter called as the EXR bit) in the SYSCR register of internal I/O.

EXR bit 0: EXR disabled

EXR bit 1: EXR enabled

The SYSCR address is set in [SYSCR Address] in the [Simulator System] dialog box.

Note: Set the SYSCR address in the internal I/O. Note that the simulator/debugger determines the MACS bit as 0 (non-saturation) and the EXR bit as 0 (EXR disabled) when the SYSCR address is set other than the internal I/O.

For details, refer to section 3.2.1, Modifying the Simulator System.

2.9 H8SX Series CPU Specific Functions

Enabling/Disabling the Multiplier/Divider: The user can enable or disable the multiplier or the divider. This allows the user to check the difference in performance of the program in cases where the multiplier or the divider is used or not. To enable or disable the multiplier or the divider, check or uncheck [Multiplier] or [Divider] in the [Simulator System] dialog box, respectively.

Fetch Mode: A 16-bit or 32-bit fetch can be selected. This allows the user to check the difference in performance of the program with different fetch sizes. The fetch mode can be selected by setting of bit FETCHMD in the SYSCR register.

Endian: The endian can be specified by using the ENDIANCR register only when the current MCU mode is the advanced or maximum mode and the size of the address area is 16 Mbytes or 256 Mbytes. The byte order of little endian is also supported as the format to save data on memory, as well as that of big endian. This allows user programs created with little endian to be simulated and debugged.

Interrupt Control Mode Selection: Only bit INTM1 of the interrupt control register (INTCR) is supported. This bit allows selection of the interrupt control mode.

2.10 Control Registers

The H8S/2600 series and H8SX series simulators/debuggers support the SYSCR (system control register) as the control register mapped to the memory. It enables multiplication/accumulation operation, user program simulation for EXR accessing, and debugging.

The SYSCR address is set in [SYSCR Address] in the [Simulator System] dialog box. For modifying or displaying the control register, use the [IO] window.

For details, refer to section 3.2.1, Modifying the Simulator System in this document, or section 17.6, Looking at I/O Memory, in the High-performance Embedded Workshop V.4.03 User's Manual.

2.11 Timer (H8S Series and H8SX Series)

2.11.1 Supported Range

The H8S and H8SX series simulator/debugger supports channel 0 of 16-bit timer pulse unit 0. This simulator/debugger only supports interrupts by an overflow or a compare match, not a function with an input to or output from pins such as the input capture function.

2.11.2 Control Registers

This simulator/debugger supports timer registers. Table 2.2 shows the control registers supported by the simulator/debugger.

The addresses of the timer control registers, interrupt vector numbers, and positions of the interrupt priority registers can be changed in the [Peripheral Module Configuration] dialog box. For details on the [Peripheral Module Configuration] dialog box, refer to section 3.3, Simulating Peripheral Functions.

Table 2.2 Timer Control Registers Supported by the Simulator/Debugger

Timer	Supported Control Register	Support
TPU0	TSTR	△
	TCR	△
	TIER	○
	TSR	○
	TCNT	○
	TGRA	○
	TGRB	○
	TGRC	○
	TGRD	○

Note: ○: Supported

△: Partly supported (bits for the function described in section 2.11.1, Supported Range)

2.11.3 Clocks

The simulator/debugger supports an internal clock that provides timing in access to memory, a peripheral function clock, and clocks for operating the timers.

The numbers of cycles of the internal clock required for access to memory correspond to the specifications for the memory map. Set the frequency ratio of the internal clock to the peripheral function clock in the [Set Peripheral Function Simulation] dialog box.

Use the timer control register to specify the division ratio to create the clock for operating the timers.

2.11.4 Using a Timer

To use a timer, the timer module must be registered in the [Set Peripheral Function Simulation] dialog box, which is opened at initiation of the simulator/debugger.

For details on the timer module registration, refer to section 3.3, Simulating Peripheral Functions.

2.11.5 Notes on Using a Timer

1. Even if the actual CPU can only clear a bit to 0, the simulator can write 1 to this bit.
2. The user can select whether or not to cause a break when a timer interrupt occurs. This can be set in the [Simulator System] dialog box or by the EXEC_STOP_SET command.

2.12 Trace

The simulator/debugger writes the execution results of each instruction into the trace buffer. The conditions for trace information acquisition can be specified in the [Trace Acquisition] dialog box. Right-clicking on the [Trace] window displays the pop-up menu. Choose [Acquisition...] from the pop-up menu to display the [Trace Acquisition] dialog box. The acquired trace information is displayed in the [Trace] window.

The trace information can be searched. The search conditions can be specified in the [Trace Search] dialog box. Right-clicking on the [Trace] window displays the pop-up menu. Choose [Find...] from the pop-up menu to display the [Trace Search] dialog box.

For details, refer to section 3.5, Viewing Trace Information.

2.13 Standard I/O and File I/O Processing

The simulator/debugger enables the standard I/O and file I/O processing listed in table 2.4 to be executed by the user program. When the I/O processing is executed, the [Simulated I/O] window must be open.

Table 2.3 shows the supported I/O functions. The function codes have 16-bit address, 24-bit address, and 32-bit address versions. Select the version suitable for the CPU being used.

Table 2.3 I/O Functions

No.	Function Code	Function Name	Description
1	H'01 (16-bit address) H'11 (24-bit address) H'21 (32-bit address)	GETC	Inputs one byte from the standard input
2	H'02 (16-bit address) H'12 (24-bit address) H'22 (32-bit address)	PUTC	Outputs one byte to the standard output
3	H'03 (16-bit address) H'13 (24-bit address) H'23 (32-bit address)	GETS	Inputs one line from the standard input
4	H'04 (16-bit address) H'14 (24-bit address) H'24 (32-bit address)	PUTS	Outputs one line to the standard output
5	H'05 (16-bit address) H'15 (24-bit address) H'25 (32-bit address)	FOPEN	Opens a file
6	H'06	FCLOSE	Closes a file
7	H'07 (16-bit address) H'17 (24-bit address) H'27 (32-bit address)	FGETC	Inputs one byte from a file
8	H'08 (16-bit address) H'18 (24-bit address) H'28 (32-bit address)	FPUTC	Outputs one byte to a file
9	H'09 (16-bit address) H'19 (24-bit address) H'29 (32-bit address)	FGETS	Inputs one line from a file
10	H'0A (16-bit address) H'1A (24-bit address) H'2A (32-bit address)	FPUTS	Outputs one line to a file
11	H'0B	FEOF	Checks for end of the file
12	H'0C	FSEEK	Moves the file pointer
13	H'0D	FTELL	Returns the current position of the file pointer

For details on I/O functions, refer to section 3.10, Standard I/O and File I/O Processing.

2.14 Calculation of the Number of Instruction Execution Cycles

The simulator/debugger calculates the number of instruction execution cycles by using the expression, the data-bus width of the memory map, and the number of access cycles, which is described in the H8S, H8/300 Series Software Manual. However, note that the number of instruction execution cycles that is calculated on the simulator/debugger may differ from the one when the program is executed on the system.

MOVFP and MOVTPE Instructions: The number of cycles for transferring data of the E-clock synchronization instruction is the value between 9 and 16. The simulator/debugger calculates as '11 + number of operand access cycles'. The number of operand access cycles can be calculated from the data bus width of the memory and the number of access cycles.

EEPMOV Instruction: The number of cycles for the EEPROM-write instruction is the sum of the number of cycles for reading instructions and cycles for transferring data.

SLEEP Instruction: The simulator/debugger does not add the number of cycles considering the case when the SLEEP instruction is used for halting program.

Standard I/O and file I/O processing: The standard I/O and file I/O processing are specific functions for the simulator/debugger, and they are not added to the number of cycles. Note that the standard I/O and file I/O processing are the period while the branch to the position specified with the simulated I/O address of the BSR and JSR instructions is completed to return to the caller address after the I/O processing.

2.15 Break Conditions

The simulator/debugger provides the following conditions for interrupting the simulation of a user program during execution.

- Break due to the satisfaction of a break command condition
- Break due to the detection of an error during execution of the user program
- Break due to a trace buffer overflow
- Break due to execution of the SLEEP instruction
- Break due to the [STOP] button

Break Due to Satisfaction of a Break Command Condition: There are five break commands as follows:

- **BREAKPOINT:** Break based on the address of the instruction executed
- **BREAK_ACCESS:** Break based on access to a memory range
- **BREAK_CYCLE:** Break based on the instruction execution cycles
- **BREAK_DATA:** Break based on the value of data written to memory
- **BREAK_REGISTER:** Break based on the value of data written to a register
- **BREAK_SEQUENCE:** Break based on a specified execution sequence

If [Stop] is specified as the action to take when a break condition is satisfied, user program execution stops when the break condition is satisfied. For details, refer to section 3.4, Using the Simulator/Debugger Breakpoints.

When a break condition is satisfied and user program execution stops, the instruction at the breakpoint may or may not be executed before a break depending on the type of break, as listed in table 2.4.

Table 2.4 Processing When a Break Condition is Satisfied

Command	Instruction When a Break Condition is Satisfied
BREAKPOINT	Not executed
BREAK_ACCESS	Executed
BREAK_CYCLE	Executed
BREAK_DATA	Executed
BREAK_REGISTER	Executed
BREAK_SEQUENCE	Not executed

For BREAKPOINT and BREAK_SEQUENCE, if a breakpoint is specified at an address that is not the beginning of an instruction, the break will not be detected.

When a break condition is satisfied during user program execution, a break condition satisfaction message is displayed on the status bar and the execution stops.

Break Due to Error Detection during User Program Execution: The simulator/debugger detects simulation errors, that is, program errors that cannot be detected by the CPU exception generation functions. The [Simulator System] dialog box specifies whether to stop or continue the simulation when such an error occurs. Table 2.5 lists the error messages, error causes, and the action of the simulator/debugger in the continuation mode.

Table 2.5 Simulation Errors

Error Message	Error Cause	Processing in Continuation Mode
Address Error (Address: H'nnnnnnnn)	Odd PC value	Operates in the same way as the actual device operation.
	Instruction was fetched from the internal I/O area	
	Access in words from odd-number addresses	
	Access in longwords from odd-number addresses	
Memory Access Error (ADDRESS: H'00800000)	Access to a memory area that has not been allocated	On memory write, nothing is written; on memory read, all bits are read as 1.
	Write to a memory area having the write-protected attribute	
	Read from a memory area having the read disable attribute	
	Access to an area where memory data do not exist	
	Write to the EEPROM by instructions other than EEPMOV	
Illegal Instruction	Execution of a code that is not an instruction	Always stops.
	Execution of MOV.B Rn, @-SP or MOV.B @SP + Rn	Continues simulation but the result is not guaranteed.
Illegal Operation	Incorrect relation between the values in the C flag or H flag of the CCR in the DAA or DAS instruction and the values before adjustment	Continues simulation but the result is not guaranteed.
	Zero division executed by the DIVXU or DIVXS instruction, or overflow	

When a simulation error occurs in the stop mode, the simulator/debugger returns to the command input wait state after stopping instruction execution and displaying the error message. Table 2.6 lists the states of the program counter (PC) at a simulation error stop. The condition code register (CCR) value does not change at a simulation error stop.

Table 2.6 Register States at Simulation Error Stop

Error Message	PC Value
Address Error, Memory Access Error	- When an instruction is read: The start address of the instruction that caused the error. - When an instruction is executed: The instruction address following the instruction that caused the error.
Illegal Instruction	The start address of the instruction that caused the error.
Illegal Operation	The instruction address following the instruction that caused the error.

Use the following procedure when debugging programs that include instructions that generate simulation errors.

1. First execute the program in the stop mode and confirm that there are no errors except those in the intended locations.
2. After confirming the above, execute the program in the continuation mode.

Note: If an error occurs in the stop mode and simulation is continued after changing the simulator/debugger mode to the continuation mode, simulation may not be performed correctly. When restarting simulation, always restore the register contents and the memory contents to the state prior to the occurrence of the error.

Break Due to a Trace Buffer Overflow: After the [Break] mode is specified with [Trace Buffer Full Handling] in the [Trace Acquisition] dialog box, the simulator/debugger stops execution when the trace buffer becomes full. The following message is displayed in the [Output] window when execution is stopped.

```
Trace Buffer Full
```

Break Due to Execution of the SLEEP Instruction: When the SLEEP instruction is executed during instruction execution, the simulator/debugger stops execution. The following message is displayed in the [Output] window when execution is stopped.

Sleep

Note: When restarting execution, change the PC value to the instruction address at the restart location.

Break Due to the [Stop] Button: Users can forcibly terminate execution by clicking the [HALT] button during instruction execution. The following message is displayed on the status bar when execution is stopped.

Stop

Execution can be resumed with the GO or STEP command.

2.16 Floating-Point Data

Floating-point numbers can be used for the following real-number data, which makes floating-point data processing easier. The following data can be specified for floating-point data:

- Data when the break type is set to [Break Data] or [Break Register] in the [Select Break Type] dialog box
- Data in the [Memory] window
- Data in the [Fill Memory] dialog box
- Data in the [Search Memory] dialog box
- Input data in the [Register] dialog box

The floating-point data format conforms to the ANSI C standard.

In the simulator/debugger, the round-to-nearest (RN) mode is applied as the rounding mode for floating-point decimal-to-binary conversion.

If a denormalized number is specified for binary-to-decimal or decimal-to-binary conversion, it is left as a denormalized number in RN mode. If an overflow occurs during decimal-to-binary conversion, the infinity is returned in RN mode.

2.17 Display of Function Call History

The simulator/debugger displays the function call history in the [Stack Trace] window when simulation stops, which enables program execution flow to be checked easily. Selecting a function name in the [Stack Trace] window displays the corresponding source program in the [Editor] window. This allows the function that has called the current function to also be checked.

The displayed function call history is updated in the following cases:

- When simulation stops due to the break conditions described in section 2.15, Break Conditions.
- When register values are modified while simulation stops due to the above break conditions.
- While single-step execution is performed.

For details, refer to section 17.15, Viewing the Function Call History in the High-performance Embedded Workshop V.4.03 User's Manual.

2.18 Performance Measurement

The simulator/debugger has the profiler function and performance analysis function for performance measurement of the user program.

2.18.1 Profiler

The profiler function displays the memory address and size allocated to functions and global variables, the number of function calls, and the profile data for the entire user program. The profile data to be displayed depends on the CPU.

Profile information is displayed in list, tree, and chart formats.

Profile information is useful in optimizing user programs by reducing the size and putting the most frequently called functions in-line.

When using the profile information saved in a file, it is possible to optimize user programs based on dynamic information using the optimizing linkage editor.

For details, refer to section 3.6, Viewing the Profile Information, and description of PROfile in section 4.2.4, Optimize Option in the Optimizing Linkage Editor User's Manual.

2.18.2 Performance Analysis

The performance analysis function displays the number of execution cycles and function calls for the specified function in the user program. Since performance data for only the specified function is acquired, faster simulation is possible. For details, refer to section 3.7, Analyzing Performance.

2.19 Pseudo-Interrupts

The simulator/debugger can generate pseudo-interrupts during simulation in the following two ways:

1. Pseudo-interrupts generated by satisfaction of break conditions

A pseudo-interrupt can be generated using a break command to specify [Interrupt] as the action when a break condition is satisfied. For details, refer to section 3.4, Using the Simulator/Debugger Breakpoints.

2. Pseudo-interrupts generated from windows

A pseudo-interrupt can be generated by clicking a button in the [Trigger] or [GUI I/O] window. For details, refer to section 3.9, Generating a Pseudo-Interrupt Manually.

If another pseudo-interrupt occurs between a pseudo-interrupt occurrence and its acceptance, only the interrupt that has a higher priority can be accepted.

3. Break by pseudo-interrupts

The user can select whether or not to cause a break when a pseudo-interrupt occurs. This can be set in the [Simulator System] dialog box or by the EXEC_STOP_SET command.

Note: In the pseudo-interrupts, whether an interrupt is accepted is determined by interrupt information [Priority], not the vector number. Note that when H'8 is specified as the priority level of an interrupt, that interrupt is always accepted. The simulator/debugger does not simulate the operation of the interrupt controller.

2.20 Coverage

The simulator/debugger acquires instruction coverage information during instruction execution within the measurement range specified by the user.

In the measurement range, addresses are directly specified, and all functions in a file whose name has been specified are set.

The state of each instruction execution can be monitored through the instruction coverage information. In addition, this information can be used to determine which part of a program has not been executed.

The [Coverage] window displays the acquired instruction coverage information:

The instruction coverage information can be displayed in the [Editor] window by highlighting the column corresponding to the source line of the executed instruction.

For the address range or function to be measured, the coverage statistical information is displayed in percentage. This gives the user a clear idea how much the program has been executed.

The instruction coverage information can be saved in or loaded from a file. Only a file in the .COV format can be loaded.

For details, refer to section 3.8, Acquiring Code Coverage.

Section 3 Debugging

This section describes the simulator/debugger operations and their related windows and dialog boxes.

For details on the functions common to the HEW listed below, refer to the HEW help information.

- Preparations for Debugging
- Viewing a Program
- Operating Memory
- Displaying Memory Contents as Waveforms
- Displaying Memory Contents as an Image
- Modifying the Memory Contents
- Viewing the I/O Memory
- Looking at Registers
- Executing Your Program
- Viewing the Current Status
- Synchronizing Multiple Debugging Platforms
- Debugging with the Command Line Interface
- Elf/Dwarf2 Support
- Looking at Labels

3.1 Creating the Workspace for Simulator/Debugger

To use the simulator/debugger, a workspace for the simulator/debugger must be created. This section only describes the procedures specific to the simulator/debugger. For details, refer to the HEW user's manual.

3.1.1 Selecting a Debugging Platform

When you create a new workspace, the dialog box shown below appears. Specify the debugging platform in step 7.




Figure 3.1 Debugger Target Setting Display (Step 7)

- [Targets] Sets the debugger targets. Select (by checking) the debugger targets. No selection or a selection of more than one target is possible.
- [Target type] Specifies the type of the targets displayed in [Targets].

Note: Debugging may not be available if the operating mode of the selected debugger target is different from the mode selected in [Operating Mode] in step 2.

3.1.2 Setting up a Workspace for the Simulator/Debugger

Set up the workspace for the simulator/debugger in step 8.




Figure 3.2 Debugger Option Setting Display (Step 8)

[Configuration name]	By default, the HEW generates two configurations: [Release] and [Debug]. If a debugger target has been selected, a configuration for the selected target is also generated (an abbreviation including the target name). This configuration name can be changed in [Configuration name].
[Detail options]	Sets the debugger target options. To modify an option, select [Item] and click [Modify]. If the selected item cannot be modified, [Modify] remains gray even when [Item] is selected.
[Simulator I/O]	Simulation for standard I/O or file I/O from the user program is enabled ([Enable]) or disabled ([Disable]).
[Simulator I/O addr.]	Address for the above simulated I/O.
[Bus mode]	Currently not used by the simulator/debugger.

3.2 Modifying the Simulator/Debugger Settings

This section describes how to modify the simulator system, memory map, and memory resource settings after the simulator/debugger is started.

3.2.1 Modifying the Simulator System

The [System] tab in the [Simulator System] dialog box is used to modify the location to start the simulated I/O and execution mode.

Choose [Setup -> Simulator -> System...] or click the [Simulator System] toolbar button  to open the [System] tab in this dialog box.




Figure 3.3 Simulator System Dialog Box (System Tab)

The following items can be specified in this dialog box:

- | | |
|-------------------------|---|
| [CPU] | Displays the current CPU. (The CPU must be specified in the [Debug Settings] dialog box. |
| [Data Area Bit Size] | <p>Specifies the number of bits in the data space. The following values can be set in each CPU:</p> <p>H8/300, H8/300L, H8/300HN, H8S/2600N, and H8S/2000N: 16</p> <p>H8/300HA: 17 to 24</p> <p>H8S/2600A and H8S/2000A: 17 to 32</p> |
| [Program Area Bit Size] | <p>Specifies the number of bits in the program area. The following values can be set in each CPU:</p> <p>H8/300, H8/300L, H8/300HN, H8S/2600N, and H8S/2000N: 16</p> <p>H8/300HA: Same as the number of address space bits</p> <p>H8S/2600A and H8S/2000A: 17 to 32</p> |
| [SYSCR Address] | Specifies the SYSCR address. |
| [Simulated I/O Address] | <p>Specifies the start address of a simulated I/O that performs standard input/output or file input/output processing from the user program.</p> <p>[Enable] Checking this box enables the simulated I/O.</p> |
| [Response] | <p>Specifies the window refresh timing; that is, how many instructions should be executed between refresh operations (D'1 to D'2,147,483,647. The default is D'40000).</p> |
| [Execution Mode] | <p>Specifies whether the simulator/debugger stops or continues operation when a simulation error (including interrupts) occurs. It is also possible to specify an action to take place when an interrupt occurs by clicking the [Detail...] button.</p> <p>[Stop] Stops simulation.</p> <p>[Continue] Continues simulation.</p> |

Clicking the [OK] or [Apply] button stores the modified settings. Clicking the [Cancel] button closes this dialog box without modifying the settings.

3.2.2 Modifying the Memory Map and Memory Resource Settings

The [Memory] tab in the [Simulator System] dialog box is used to set and modify the memory map and memory resource.




Figure 3.4 Simulator System Dialog Box (Memory Tab)

The following items can be specified in this dialog box:

- [Memory Map] Displays the memory type, start and end addresses, data bus width, and the number of access cycles.
- [Memory Resource] Displays the access type and start and end addresses of the current memory resource.

[Memory Map] can be added, modified, or deleted using the following buttons:



Adds [Memory Map] items. Clicking this button opens the [Set Memory Map] dialog box (figure 3.5), and memory map items can be added.



Modifies [Memory Map] items. Select an item to be modified in the list box and click this button. The [Set Memory Map] dialog box (figure 3.5) opens and memory map items can be modified.



Deletes [Memory Map] items. Select an item to be deleted in the list box and click this button.

[Memory Resource] can be added, modified, or deleted using the following buttons:



Adds [Memory Resource] items. Clicking this button opens the [Set Memory Resource] dialog box, and memory map items can be specified.



Modifies [Memory Resource] items. Select an item to be modified in the list box and click this button. The [Set Memory Resource] dialog box opens and memory map items can be modified.



Deletes [Memory Resource] items. Select an item to be deleted in the list box and click this button.

[Memory Resource] is the same setting information as that of [Memory Resource] of the [Debugger] sheet in the [H8S, H8/300 Standard Toolchain] dialog box. Modifications are reflected on both items.

[Memory Map] and [Memory Resource] can be reset to the default value by the  button. Clicking the [OK] or [Apply] button stores the modified settings. Clicking the [Cancel] button closes this dialog box without modifying the settings.

When there is a linkage list file (.map) output by the optimizing linkage editor, the memory resource can be automatically allocated according to the memory map and linkage map information. For details, refer to section 13.1.9, Automatically Allocating the Memory Resource, in the High-performance Embedded Workshop V.4.03 User's Manual.

3.2.3 Set Memory Map Dialog Box

The [Set Memory Map] dialog box specifies the memory map of the target CPU.

The contents displayed in this dialog box depend on the target CPU. The simulator/debugger uses the specified data to calculate the number of cycles for memory accesses.




Figure 3.5 Set Memory Map Dialog Box

The following items are specified:

[Memory type]	Memory type
	[ROM] Internal ROM
	[RAM] Internal RAM
	[EXT] External memory
	[IO] Internal I/O
	[EEPROM] EEPROM
[Begin address]	Start address of the memory corresponding the memory type
[End address]	End address of the memory corresponding to the memory type
[Data bus size]	Memory data bus width
[Read state count]	Number of cycles (“states”) for read access to the specified type of memory
[Write state count]	Number of cycles (“states”) for write access to the specified type of memory

Clicking the [OK] button stores the settings. Clicking the [Cancel] button closes this dialog box without modifying the settings.

Note: The memory map setting for the area allocated to a system memory resource cannot be deleted or modified. First delete the system memory resource allocation on the [Memory] tab of the [Simulator System] dialog box, then delete or modify the memory map setting.

3.2.4 Set Memory Resource Dialog Box

The [Set Memory Resource] dialog box sets and modifies memory resources.




Figure 3.6 Set Memory Resource Dialog Box

The following items are specified:

[Begin Address] Start address of the memory area to be allocated

[End Address] End address of the memory area to be allocated

[Attribute]	Access type
[Read]	Read only
[Write]	Write only
[Read/Write]	Readable/writable

Click the [OK] button after specifying the [Begin Address], [End Address], and [Attribute].

Clicking the [Cancel] button closes this dialog box without modifying the settings.

Note: If memory resources are set, memory in the host computer will be used. If the user allocates too much memory resources, operation of the host computer will be extremely slow.

3.3 Simulating Peripheral Functions

The simulator/debugger is able to simulate peripheral functions by using DLL modules. This section describes how to register the peripheral function simulation modules to enable the simulation of individual peripheral functions, and how to set their configurations.

3.3.1 Registering Peripheral Function Simulation Modules

Peripheral function simulation modules can be registered in the [Set Peripheral Function Simulation] dialog box, which is opened on initiation of the simulator/debugger.

Once a peripheral function simulation module has been registered in this dialog box, the simulated peripheral function provided by that simulation module becomes available. The registered settings cannot be modified after the simulator/debugger has fully started up. To change the peripheral function simulation modules that are in use, restart the simulator/debugger to bring up this dialog box.




Figure 3.7 Set Peripheral Function Simulation Dialog Box

The following items are specified in this dialog box:

- | | |
|------------------------|--|
| [Peripheral Functions] | Shows information on the peripheral function simulation modules. |
| [Module Name] | Names of peripheral functions to be simulated |
| [File Name] | Names of files holding peripheral function simulation modules |

Check the checkbox under [Module Name] to register the corresponding peripheral function simulation module and make it available.

[Enable All]	Enables all peripheral function simulation modules.
[Disable All]	Disables all peripheral function simulation modules.
[Detail...]	Opens the [Peripheral Module Configuration] dialog box, allowing you to view information on the corresponding peripheral function, and change the address where it starts and the interrupt-source information.
[Peripheral Clock Rate]	The ratio between the peripheral clock and the internal clock (the number of cycles of the internal clock corresponding to one cycle of the peripheral clock) is specified here. The clock rate setting can be selected as 1, 2, 3, 4, 6, 8, 12, 16, 24, or 32.

Clicking the [OK] button makes the settings effective. Clicking the [Cancel] button closes this dialog box without storing the settings.

If you do not wish this dialog box to be opened when the simulator/debugger is subsequently initiated, check [Don't show this dialog box].

3.3.2 Changing the Addresses of Peripheral Functions

The addresses of peripheral functions can be changed in the [Address] tab of the [Peripheral Module Configuration] dialog box. To open this dialog box, select a peripheral function in [Peripheral Functions] of the [Set Peripheral Function Simulation] dialog box and then press the [Detail...] button.




Figure 3.8 Peripheral Module Configuration Dialog Box (Address Tab)

The following items can be set or displayed in this dialog box:

[Module]	Name of the peripheral function supported by the selected peripheral function simulation module
[Start Address]	Start address of the peripheral function selected in [Module]
[Register Address]	Names and addresses of registers of the peripheral function selected in [Module]. It is not possible to change the register addresses.

Clicking the [OK] or [Set] button makes the settings effective. Clicking the [Cancel] button closes this dialog box without storing the settings.

3.3.3 Changing the Interrupt Source Information of Peripheral Functions

The interrupt source information of peripheral functions can be changed in the [Interrupt] tab of the [Peripheral Module Configuration] dialog box. To open this dialog box, select a peripheral function in [Peripheral Functions] of the [Set Peripheral Function Simulation] dialog box and then press the [Detail...] button.




Figure 3.9 Peripheral Module Configuration Dialog Box (Interrupt Tab)

The following items can be displayed in this dialog box:

Interrupt Source:	Name of the interrupt source (or sources) supported by the peripheral function
Vector Number:	Interrupt vector number
Priority Register Address/ Bit Field Position:	Address of the interrupt priority register and positions of bits in the register

To change the interrupt-source information, open the [Set Interrupt Source Information] dialog box by double-clicking on the line for the interrupt source to be changed.




Figure 3.10 Set Interrupt Source Information Dialog Box

The following items can be set or displayed in this dialog box:

Interrupt Source:	Interrupt source name
Interrupt Vector Number:	Interrupt vector number (when the prefix is omitted, values input are taken as decimal, and the display is in decimal notation)
Priority Register Address:	Address of the interrupt priority register
Priority Register Size:	Size of the interrupt priority register
Priority Register Bit Position:	Positions of bits in the interrupt priority register

Clicking the [OK] button makes the settings effective. Clicking the [Cancel] button closes this dialog box without storing the settings.

3.3.4 Allocating Memory Resources to the Interrupt Priority Register

The peripheral function simulation module does not allocate the interrupt priority register (IPR) to a location in memory. Allocate the memory resource for the interrupt priority register (IPR) through user operation. For details on the setting of memory resources, refer to section 3.2.2, Modifying the Memory Map and Memory Resource Settings.

3.3.5 Viewing the Names of Connected Peripheral Functions

After the simulator/debugger has been initiated, [Peripheral Modules] on the [Platform] sheet of the [Status] window shows the names of the peripheral functions that are connected.

3.4 Using the Simulator/Debugger Breakpoints

Sophisticated breakpoint functions are available in the simulator/debugger in addition to the HEW standard PC breakpoints. The user can specify break conditions and actions after a break condition is satisfied, and can display the breakpoints set.

3.4.1 Listing the Breakpoints

Choose [View -> Code -> Eventpoints] or click the [Eventpoints] toolbar button  to open the [Event] window, which lists the breakpoints set.




Figure 3.11 Event Window

The following items are displayed:

[Type]	Break types [BP]: PC break [BA]: Access break [BD]: Data break [BR]: Register break (register name) [BS]: Sequential break [BCY]: Number-of cycles break
[State]	Whether the breakpoint is enabled or disabled [Enable]: Valid [Disable]: Invalid
[Condition]	Condition that causes a break. The contents to be displayed depend on the type of the break. When the type of the break is BR, the register name is displayed, and when the type of the break is BCY, the number of cycles is displayed. BP: PC = Program counter (Corresponding file name, line, and symbol name) BA: Address = Address (Symbol name) BD: Address = Address (Symbol name) BR: Register = Register name BS: PC = Program counter (Corresponding file name, line, and symbol name) BCY: Cycle = Number of cycles (displayed in hexadecimal)
[Action]	Operation of the simulator/debugger when a break condition is satisfied. [Stop]: Execution halts [File Input] (file name) [File state]: Memory data is read from file [File Output] (file name) [File state]: Memory data is written to file [Interrupt] (Interrupt type/priority): Interrupt processing

Conditions specifying [Stop] for [Action] is displayed on the [Software Break] tab and the conditions specifying another action type is on the [Software Event] tab.

3.4.2 Setting a Breakpoint

Selecting [Add...] from the pop-up menu in the [Event] window opens the [Select Break Type] dialog box, which allows the user to set a breakpoint.

Two further dialog boxes can be opened from the [Select Break Type] dialog box: [Set xx Condition] for specifying a break condition and [Set xx Action] for specifying an action to take when the break condition is satisfied. To open the [Select Break Type] dialog box from the [Event] window when you wish to select [Stop] as [Action type] in the [Select Break Type] dialog box, select [Add...] from the pop-up menu on the [Software Break] tab; if you wish to select another action type, select [Add...] from the pop-up menu on the [Software Event] tab.

Selecting a Break Type:

Selecting [Add...] from the popup menu on the [Event] window opens the [Select Break Type] dialog box. Select a break type in the [Break type] field of this dialog box.




Figure 3.12 Select Break Type Dialog Box

The following options are available:

[Break type]

- [PC Breakpoint]: Breakpoint set at an instruction
- [Break Access]: Break on access to a memory range
- [Break Data]: Break on detection of a memory value
- [Break Register]: Break on detection of a register value
- [Break Sequence]: Sequential breakpoints
- [Break Cycle]: Break after the specified number of cycles

Setting Break Conditions:

Click on [Detail...] after selecting the break type in the [Select Break Type] dialog box. This opens a dialog box that allows you to set conditions for the selected break type.

- [PC Breakpoint]




Figure 3.13 Set PC Breakpoint Condition Dialog Box

Up to 1024 PC-breakpoint conditions can be specified.

[Address]: Address of the instruction where a break will occur

[Count]: Number of times that the specified instruction is fetched
(1 to 16,383; the default value is 1; if the prefix is omitted, values input are taken as decimal, and the display is in decimal notation).

- [Break Access]




Figure 3.14 Set Access Break Condition Dialog Box

Up to 1024 access break conditions can be specified.

- | | |
|------------------|--|
| [Begin address]: | First address of the range of memory for which access generates a break |
| [End address]: | Last address of the range of memory for which access generates a break (if no data is input, the range corresponds to the first address alone) |
| [Access type]: | Read, write, or read/write |

- [Break Register]




Figure 3.15 Set Register Break Condition Dialog Box

Up to 1024 register break conditions can be specified.

- [Register]: Register name for which the break condition is specified
- [Option]: Match or mismatch with the data
- [Data]: Data value used in the break condition (if no data is input here, a break will occur whenever data is written to the register)
- [Data mask]: Mask condition (specifying 0 for a bit masks the bit)
- [Size]: Data size

- [Break Sequence]




Figure 3.16 Set Break Sequence Condition Dialog Box

Only one sequential break condition can be specified.

- [Address1] to [Address8]: Addresses that must be passed as conditions to generate the break (not all of the eight breakpoints have to be set).

- [Break Cycle]




Figure 3.17 Set Number-of-Cycles Break Condition Dialog Box

Up to 1024 number-of-cycles break conditions can be specified.

- [Cycle]: Number of cycles required to cause a break (H'1 to H'FFFFFFF).
The condition will be satisfied by execution for the number of cycles in the [Cycle] setting $\times$ n.
However, the specified number of cycles may differ from the number of cycles on which the condition is satisfied.
- [Count]: Number of times the break will occur
- [ALL]: The break will occur whenever the condition is satisfied.
- [Times]: The break will only occur up to the number of times specified as [Times] (1 to 65535; if the prefix is omitted, values input are taken as hexadecimal, and the display is in hexadecimal notation).

- [Break Data]




Figure 3.18 Set Data Break Condition Dialog Box

Data break conditions should be set as follows.

Up to 1024 data break conditions can be specified.

- [Address]: Address in memory for which the break condition is specified
- [Option]: How the data value is used to form the condition that must be satisfied for break generation
 - [Equal]: The value written to memory matches [Data].
 - [Not equal]: The value written to memory does not match [Data].
 - [Inverse sign]*: The sign of the value written to memory is the inverse of that for the previous value.
 - [Difference]*: The difference between the current and previous values written to memory exceeds [Data].
- [Data]: Data value used in the break condition
- [Data mask]: Mask condition (specifying 0 for a bit masks the bit). This option is only available when [Equal] or [Not equal] has been selected.
- [Size]: Data size
- [Sign]: Sign of the data.
 - This option is only available when [Difference] has been selected.

Note: Since [Inverse sign] and [Difference] require comparison of the data with the value previously written to memory, the break will never occur on the first test after a reset or break generation when either of these conditions has been selected.

Selecting an Action in Response to a Break:

If you click on [OK] after setting break conditions in the dialog boxes described on the preceding pages, the [Select Break Type] dialog box is opened again. Select an action type in the [Action type] field of this dialog box.




Figure 3.19 Select Break Type Dialog Box

The following options are available:

- [Stop]: Execution of the user program is stopped when the condition is satisfied.
- [File Input]: The contents of a specified file are read out and written to the specified memory when the condition is satisfied.
- [File Output]: The contents of the specified memory are read out and written to the specified file when the condition is satisfied.
- [Interrupt]: Interrupt processing proceeds when the condition is satisfied.

Setting Details of the Action:

Click on [Detail...] after selecting the action type in the [Select Break Type] dialog box. This opens a dialog box that allows you to set details of the selected action.

- [File Input]




Figure 3.20 Set File Input Action Dialog Box

When the condition is satisfied, data are read out from the specified file and written to the specified location in memory.

- [Input file]: File from which data are to be read out. When reading out by the simulator/debugger reaches the end of the file, reading out recommences from the beginning of the same file.
- [Address]: Memory address to which data should be written.
- [Data size]: Size of each data value in bytes (1/2/4/8).
- [Count]: Number of values to be written (H'1 to H'FFFFFFF; when the prefix is omitted, values input are taken as decimal, and the display is in decimal notation).

- [File Output]




Figure 3.21 Set File Output Action Dialog Box

When the condition is satisfied, the contents at the specified location in memory are written to the specified file.

[Output file]: Data file to which data are written.

[Append]: Selects whether the data should be appended to the file if an existing file is specified as the output file.

[Address]: Memory address to read data from.

[Data size]: Size of each data value to be read (1/2/4/8).

[Count]: Number of values to be read (H'1 to H'FFFFFFF; when the prefix is omitted, values input are taken as decimal, and the display is in decimal notation).

- [Interrupt]




Figure 3.22 Set Interrupt Action Dialog Box

When the condition is satisfied, interrupt processing proceeds. For details, refer to section 2.19, Pseudo-Interrupts.

- [Interrupt type 1]: Sets the following values for each CPU (when the prefix is omitted, values input are taken as hexadecimal, and the display is in hexadecimal notation)
- [Priority] Interrupt priority (H'0 to H'11; when the prefix is omitted, values input are taken as hexadecimal, and the display is in hexadecimal notation).
Whether or not the interrupt is accepted is determined by the CPU's specification of the selected debugging platform.
However, when H'8 or larger is specified for the priority, interrupts are always accepted.

- Point for Caution

When the same file is specified for multiple [File Input] actions, the simulator/debugger will read data from the file in the order of condition satisfaction. When the same file is specified for multiple [File Output] actions, the simulator/debugger will write data to the file in the order of condition satisfaction. However, when the same file is specified for [File Input] and [File Output], the only valid action is that for the first condition to be satisfied.

3.4.3 Modifying Breakpoints

Select a breakpoint to be modified, and choose [Edit...] from the pop-up menu to open the [Select Break Type] dialog box, which allows the user to modify the break conditions. The [Edit...] menu is only available when one breakpoint is selected.

3.4.4 Enabling a Breakpoint

Select a breakpoint and choose [Enable] from the pop-up menu to enable the selected breakpoint.

3.4.5 Disabling a Breakpoint

Select a breakpoint and choose [Disable] from the pop-up menu to disable the selected breakpoint. When a breakpoint is disabled, the breakpoint will remain in the list, but a break will not occur when the specified conditions have been satisfied.

3.4.6 Deleting a Breakpoint

Select a breakpoint and choose [Delete] from the pop-up menu to remove the selected breakpoint. To retain the breakpoint but not have it cause a break when its conditions are met, use the [Disable] option (see section 3.4.5, Disabling a Breakpoint).

3.4.7 Deleting All Breakpoints

Choose [Delete All] from the pop-up menu to remove all breakpoints.

3.4.8 Viewing the Source Line for a Breakpoint

Select a breakpoint and choose [Go to Source] from the pop-up menu to open the [Source] or [Disassembly] window at the address of the breakpoint. The [Go to Source] menu is only available when one breakpoint is selected.

3.4.9 Closing Input or Output File

Select a breakpoint and choose [Close File] from the pop-up menu to close the selected [File Input] or [File Output] data file and to reset the address to read the file.

3.4.10 Closing All Input and Output Files

Choose [Close All Files] from the pop-up menu to close all [File Input] and [File Output] data files and to reset the address for reading the file.

3.5 Viewing Trace Information

The simulator/debugger acquires the results of each instruction execution as trace information and displays it in the [Trace] window. The conditions for the trace information acquisition can be specified in the [Trace Acquisition] dialog box.

3.5.1 Opening the Trace Window

To open the [Trace] window, choose [View -> Code -> Trace] or click the [Trace] toolbar button .

3.5.2 Specifying Trace Acquisition Conditions

After the [Trace] window opens, specify the trace acquisition conditions in the [Trace Acquisition] dialog box. To open this dialog box, choose [Acquisition...] from the pop-up menu




Figure 3.23 Trace Acquisition Dialog Box

This dialog box specifies the conditions for trace information acquisition.

[Trace Start/Stop]

- | | |
|-----------|---|
| [Disable] | Disables trace information acquisition. |
| [Enable] | Enables trace information acquisition. |

[Instruction Type]

- | | |
|---------------|--|
| [Instruction] | Acquires trace information for all instructions. |
| [Subroutine] | Acquires trace information for the subroutine instructions only. |

[Trace Buffer Full Handling]


- | | |
|------------|--|
| [Continue] | Continues acquiring trace information even if the trace information acquisition buffer becomes full. |
| [Break] | Stops execution when the trace information acquisition buffer becomes full. |

The trace buffer capacity can be selected from 1 Kbyte (1,024 records), 4 Kbytes (4,096 records), 16 Kbytes (16,384 records), 32 Kbytes (32,768 records), 64 Kbytes (65,536 records), 128 Kbytes (131,072 records), or 256 Kbytes (262,144 records) in [Trace Capacity].

Clicking the [OK] button stores the settings. Clicking the [Cancel] button closes this dialog box without modifying the settings.

3.5.3 Acquiring Trace Information

After trace acquisition is enabled, trace information is acquired during instruction execution. The acquired information will be displayed in the [Trace] window.



PTR	Cycle	Address	CCR	Mult	Instruction	Access Data	Source	Label
-00013	0000029984	000E6C	I-----	---	ADDS.L ...	ER7<-00F...	}	
-00012	0000029995	000E6E	I----Z--	---	MOV.L ...	ER2<-000...		
-00011	0000030006	000E72	I-----	---	MOV.L ...	ER6<-00F...		
-00010	0000030017	000E76	I-----	---	RTS	PC<-0000...		
-00009	0000030021	000416	-----	---	ANDC.B ...	CCR<-00	set_imas...	
-00008	0000030032	000418	-----	---	JSR ...	PC<-0000...	main();	
-00007	0000030043	000800	-----	---	MOV.L ...	00FFFFB4...	void main(void)	_main
-00006	0000030047	000804	-----	---	MOV.L ...	ER6<-00F...		
-00005	0000030055	000806	----N--	---	SUB.W ...	R7<-FBAE		
-00004	0000030063	00080A	-----	---	MOV.W ...	R0<-0001	srand(1);	
-00003	0000030074	00080E	-----	---	JSR ...	PC<-0000...		
-00002	0000030078	0010D6	-----	---	EXTU.L ...	ERO<-000...		_srand
-00001	0000030096	0010D8	-----	---	MOV.L ...	00FFF06A...		
-00000	0000030107	0010E0	-----	---	RTS	PC<-0000...		

Figure 3.24 Trace Window

This window displays the following trace information items:

[PTR]	Pointer in the trace buffer (0 for the last executed instruction)
[Cycle]	Total number of instruction execution cycles (cleared by instruction-execution reset)
[Address]	Instruction address
[CCR]	Displays the contents of the condition code register (CCR) as a mnemonic.
[Mult]	Displays the flag in the multiplier as a mnemonic (H8S/2600 series only).
[Instruction]	Instruction mnemonic
[Access Data]	Data access information (display format: destination <- accessed data)
[Source]	C/C++ or assembly-language source programs
[Label]	Labels

3.5.4 Searching for a Trace Record

Use the [Trace Search] dialog box to search for a trace record. To open this dialog box, choose [Find...] from the pop-up menu.




Figure 3.25 Trace Search Dialog Box

This dialog box specifies the conditions for searching trace information. Specify a search item in [Item] and search for the specified contents in [Value].

[PTR]	Pointer in the trace buffer (0 for the last executed instruction, specify in the form of -nnn)
[Cycle]	Total number of instruction execution cycles
[Address]	Instruction address
[Instruction]	Instruction mnemonic

Clicking the [OK] button stores the settings and starts searching. Clicking the [Cancel] button closes this dialog box without searching.

When a trace record that matches the search conditions is found, the line for the trace record will be displayed in blue. When no matching trace record is found, a message dialog box will appear.

If a search operation is successful, choosing [Find Next] from the pop-up menu will move to the next found item.

3.5.5 Clearing the Trace Information

Choose [Clear] from the pop-up menu to empty the trace buffer that stores the trace information. If more than one [Trace] window is open, all [Trace] windows will be cleared as they all access the same buffer.

3.5.6 Saving the Trace Information in a File

Choose [Save...] from the pop-up menu to open the [Save As] dialog box, which allows the user to save the contents of the trace buffer as a text file. A range can be specified based on [PTR]. Note that this file cannot be reloaded into the trace buffer.

3.5.7 Viewing the Source File

The [Editor] window corresponding to the selected trace record can be displayed in the following two ways:

- Select a trace record and choose [View Source] from the pop-up menu.
- Double-click a trace record

The [Editor] or [Disassembly] window opens and the selected line is marked with a cursor.

3.5.8 Trimming the Source

Choose [Trim Source] from the pop-up menu to remove the white space from the left side of the source.

When the white space is removed, a check mark is shown to the left of the [Trim Source] menu. To restore the white space, choose [Trim Source] while the check mark is shown.

3.5.9 Analyzing Statistical Information

Choose [Statistic] from the pop-up menu to open the [Trace Statistic] dialog box and analyze statistical information under the specified conditions.



Figure 3.26 Trace Statistic Dialog Box

This dialog box allows the user to analyze statistical information concerning the trace information. The target of analysis is specified in [Item] and the input value or character string is specified by [Start] and [End].

When [Default] is selected, the input value or character string cannot be specified as a range. To specify a range, select [Range].

- [Set] Adds a new condition to the current one
- [New] Creates a new condition
- [Result] Obtains the result of statistical information analysis
- [Clear] Clears all condition and results of statistical information analysis

Clicking the [Close] button closes this dialog box.

3.6 Viewing the Profile Information

The profile function enables function-by-function measurement of the performance of the application program in execution. This makes it possible to identify parts of an application program that degrade its performance and the reasons for such degradation.

The HEW displays the results of measurement in three windows, according to the method and purpose of viewing the profile data.

3.6.1 Stack Information Files

The profile function allows the HEW to read the stack information files (extension: .SNI) which are output by the optimizing linkage editor (ver. 7.0 or later). Each of these files contains information related to the calling of static functions in the corresponding source file. Reading the stack information file makes it possible for the HEW to display information related to the calling of functions without executing the user application (i.e. before measuring the profile data). However, this feature is not available when [Setting->Only Executed Functions] is checked in the pop-up menu of the [Profile] window.

When the HEW does not read any stack information files, only the data on the functions executed during measurement will be displayed by the profile function.

To make the linkage editor create a stack information file, choose [Build -> H8S, H8/300 Standard Toolchain...], and select [Other] from the [Category] list box and check the [Stack information output] box in the [Link/Library] sheet of the [Standard Toolchain] dialog box.




Figure 3.27 Standard Toolchain Dialog Box (1)

3.6.2 Profile Information Files

To create a profile information file, measure a profile data of the application program then choose the [Output Profile Information Files...] menu option from the pop-up menu of the [Profile] window and specify the file name.

This file contains information on the number of times functions are called and global variables are accessed. The optimizing linkage editor (ver. 7.0 or later) is capable of reading the profile information file and optimizing the allocation of functions and variables in correspondence with the state of the actual operation of the program.

To input the profiler information file to the linkage editor, choose [Optimize] from the [Category] list box and check the [Include profile] box in the [Link/Library] sheet of the [Standard Toolchain] dialog box, and specify the name of the profile information file.





Figure 3.28 Standard Toolchain Dialog Box (2)

To enable the settings in the [Include profile] box, specify the [Optimize] list box as some setting other than [None].

3.6.3 Loading Stack Information Files

You can select whether or not to read the stack information file in a message box for confirmation that is displayed when a load module is loaded. Clicking the [OK] button of the message box loads the stack information file. The message box for confirmation will be displayed when:

- There are stack information files (extension: .SNI)
- The [Load Stack Information Files (SNI files)] check box is checked in the [Confirmation] tab of the [Options] dialog box (figure 3.29) that can be opened by choosing [Setup -> Options...] from the main menu.

**Figure 3.29 Options Dialog Box**

3.6.4 Enabling the Profile

Choose [View->Performance->Profile] to open the [Profile] window.

Choose [Enable Profiler] from the pop-up menu of the [Profile] window. The item on the menu will be checked.

3.6.5 Specifying Measurement Mode

You can specify whether to trace functions calls while profile data is acquired. When function calls are traced, the relations of function calls during user program execution are displayed as a tree diagram. When not traced, the relations of function calls cannot be displayed, but the time for acquiring profile data can be reduced.

To stop tracing function calls, choose [Disable Tree (Not traces function call)] from the pop-up menu in the [Profile] window (a check mark is shown to the left of the menu item).

When acquiring profile data of the program in which functions are called in a special way, such as task switching in the OS, stop tracing function calls.


3.6.6 Executing the Program and Checking the Results

After the user program has been executed and execution has been halted, the results of measurement are displayed in the [Profile] window.

The [Profile] window has two sheets; a [List] sheet and a [Tree] sheet.

3.6.7 List Sheet

This sheet lists functions and global variables and displays the profile data for each function and variable.



Function/Variable	F/V	Address	Size	Times	Cycle	Ext mem	I/O area	Int mem
PowerON_Reset	F	000400	H'00000028	1	79	1	0	9
main	F	000800	H'00000164	1	4674	0	0	320
_sort	F	000964	H'00000136	1	9829	0	0	637
_change	F	000A9A	H'000000A8	1	2733	0	0	152
_charput	F	000B42	H'00000000	255	20910	0	0	1020
_open	F	000B8A	H'00000090	3	578	0	0	39
_close	F	000C1A	H'00000036	3	384	0	0	21
_write	F	000CB4	H'00000060	509	10...	0	0	7639
__INIT_IOLIB	F	000D36	H'00000142	1	1408	4	0	74
__CLOSEALL	F	000E78	H'00000062	1	628	4	0	30
__INITSCT	F	000F3A	H'00000000	1	60	0	0	4
loop1	F	000F50	H'00000000	1	42	2	0	0
loop2	F	000F5A	H'00000000	1134	20456	0	0	1134
next_loop2	F	000F5C	H'00000000	1	12	0	0	0


Figure 3.30 List Sheet

Clicking the column header sorts the items in an alphabetical or ascending/descending order. Clicking the [Function/Variable] or [Address] column displays the source program corresponding to the address in the line.

Right-clicking on the mouse within the window displays a pop-up menu. For details on this pop-up menu, refer to section 3.6.8, Tree Sheet.

3.6.8 Tree Sheet

This sheet displays the relation of function calls along with the profile data that are values when the function is called. This sheet is available when [Disable Tree (Not traces function call)] is not selected from the pop-up menu in the [Profile] window.



Function	Address	Size	Stack Size	Times	Cycle	Ext mem	I/O area	Int mem
C:\Hew3\Sample\...								
PowerON_Reset	000400	H'00000028	H'00000008	1	79	1	0	9
main	000800	H'00000164	H'0000003E	1	4674	0	0	320
_srand	0010D6	H'0000000C	H'00000004	1	33	0	0	3
_rand	00109E	H'00000038	H'0000000C	10	1400	0	0	130
_print...	000F96	H'00000052	H'0000000C	22	3762	0	0	220
_change	000A9A	H'000000A8	H'0000003A	1	2733	0	0	152
_sort	000964	H'00000136	H'00000018	1	9829	0	0	637
_INITSCT	000F3A	H'00000000	H'FFFFFFFF	1	60	0	0	4
_CLOSEALL	000E78	H'00000062	H'0000000A	1	628	4	0	30
_INIT_IOLIB	000D36	H'00000142	H'00000010	1	1408	4	0	74

Figure 3.31 Tree Sheet

Double-clicking a function in the [Function] column expands or reduces the tree structure display. The expansion or reduction is also provided by the “+” or “-” key. Double-clicking the [Address] column displays the source program corresponding to the specific address.

Right-clicking on the mouse within the window displays a pop-up menu. Supported menu options are as follows:

- View Source
Displays the source program or disassembled memory contents for the address in the selected line.
- View Profile-Chart
Displays the [Profile-Chart] window focused on the function in the specified line.
- Enable Profiler
Toggles acquisition of profile data. When profile data acquisition is enabled, a check mark is shown to the left of the menu text.

- Not trace the function call

Stops tracing function calls while profile data is acquired. This menu is used when acquiring profile data of the program in which functions are called in a special way, such as task switching in the OS.

To display the relation of function calls in the [Tree] sheet of the [Profile] window, acquire profile data without selecting this menu. In addition, do not select this menu when optimizing the program by the optimizing linkage editor using the acquired profile information file.

- Find...

Displays the [Find Text] dialog box to find a character string in the [Function] column. Search is started by entering a character string to be found in the edit box and clicking [Find Next] or pressing the Enter key.

- Find Data...

Displays the [Find Data] dialog box.




Figure 3.32 Find Data Dialog Box

By selecting the column to be searched in the [Column] combo box and the search type in the [Find Data] group then pressing [Find Next] button or Enter key, search is started. If the [Find Next] button or the Enter key is input repeatedly, the second larger data (the second smaller data when Minimum is specified) is searched for.

- Clear Data

Clears the number of times functions are called and the profile data. Data in the [List] sheet of the [Profile] window and the data in the [Profile-Chart] window are also cleared.

- Output Profile Information Files...

Displays the [Save Profile Information Files] dialog box. Profiling results are saved in a profile information file (.pro extension). The optimizing linkage editor optimizes user programs according to the profile information in this file. For details of the optimization using the profile information, refer to the manual of the optimizing linkage editor.

Note: If profile information has been acquired by choosing the [Not trace the function call] menu, the program cannot be optimized by the optimizing linkage editor.

- Output Text File...

Displays the [Save Text of Profile Data] dialog box. Displayed contents are saved in a text file.

- Setting

This menu has the following submenus (the menus available only in the [List] sheet are also included).

- Show Functions/Variables

Displays both functions and global variables in the [Function/Variable] column.

- Show Functions

Displays only functions in the [Function/Variable] column.

- Show Variables

Displays only global variables in the [Function/Variable] column.

- Only Executed Functions

Only displays the executed functions. If a stack information file (.sni extension) output from the optimizing linkage editor does not exist in the directory where the load module is located, only the executed functions are displayed even if this check box is not checked.

- Include Data of Child Functions

Sets whether or not to display information for a child function called in the function as profile data.

- Properties...

This menu cannot be used in this simulator/debugger.

3.6.9 Profile-Chart Window

The [Profile-Chart] window displays the relation of calls for a specific function. This window displays the specified function in the middle, with the callers of the function on the left and the callees of the function on the right. The numbers of times the function calls the functions or is called by the functions are also displayed in this window.




Figure 3.33 Profile-Chart Window

Right-clicking the mouse within the window displays a pop-up menu. Supported menu options are as follows:

- **View Source**
Displays the source program or disassembled memory contents for the address of the function on which the cursor is placed when the right-hand mouse button is clicked. If the cursor is not placed on a function when the right-hand mouse button is clicked, this menu option remains gray.
- **View Profile-Chart**
Displays the [Profile-Chart] window for the specific function on which the cursor is placed when the right-hand mouse button is clicked. If the cursor is not placed on a function when the right-hand mouse button is clicked, this menu option remains gray.
- **Enable Profiler**
Toggles acquisition of profile data. When profile data acquisition is enabled, a check mark is shown to the left of the menu text.

- **Clear Data**
Clears the number of times functions are called. Data in the [List] and [Tree] sheets of the [Profile] window are also cleared.
- **Multiple View**
If a further [Profile-Chart] window is opened while an existing [Profile-Chart] window is already open, this option selects whether a new window is opened or the new data is displayed in the existing window. When a check mark is shown to the left of this menu item, a new window will be opened.
- **Output Profile Information Files...**
Displays the [Save Profile Information Files] dialog box. Profiling results are saved in a profile information file (.pro extension). The optimizing linkage editor optimizes user programs according to the profile information in this file. For details on optimization with the profile information, refer to the user's manual for the optimizing linkage editor.
- **Expands Size**
Redo the display with larger intervals between functions. The "+" key can also be used to do this.
- **Reduces Size**
Redo the display with smaller intervals between functions. The "-" key can also be used to this.

3.6.10 Types and Purposes of Displayed Data

The profile function is able to acquire the following information:

Address	You can view the locations in memory to which the functions are allocated. Sorting the list of functions and global variables in order of their addresses allows the user to view the way the items are allocated in the memory space.
Size	Sorting in order of size makes it easy to find small functions that are frequently called. Setting such functions as inline may reduce the overhead of function calls.
Stack Size	When there is deep nesting of function calls, pursue the route of the function calls and obtain the total stack size for all of the functions on that route to estimate the amount of stack being used.
Times	Sorting by the number of calls or accesses makes it easy to identify the frequently called functions and frequently accessed global variables.
Profile Data	Measurement of a variety of CPU-specific data is also available as follows:

- [Cycle] (the number of execution cycles)
- [Ext_mem] (the number of external memory accesses)
- [I/O_area] (the number of internal I/O area accesses)
- [Int_mem] (the number of internal memory accesses)

The number of execution cycles is calculated by subtracting the total execution cycles at a specific function call instruction execution from the total execution cycles at a return instruction execution of a specific function.

3.6.11 Creating Profile Information Files

To create a profile information file, choose the [Output Profile Information Files...] menu option from the pop-up menu. The [Save Profile Information Files] dialog box is displayed. Pressing the [Save] button after selecting a file name will write the profile information to the selected file. Pressing the [Save All] button will write the profile information to all of the profile information files.




Figure 3.34 Save Profile Information Files Dialog Box

3.6.12 Notes


1. The number of executed cycles for an application program as measured by the profile function includes a margin of error. The profile function only allows the measurement of the proportions of execution time that the functions occupy in the overall execution of the application program. Use the Performance Analysis function to precisely measure the numbers of executed cycles.
2. The names of the corresponding functions may not be displayed when the profile information on a load module with no debugging information is measured.
3. The stack information file (extension: .SNI) must be in the same directory as the load module file (extension: .ABS).
4. It is not possible to store the results of measurement.
5. It is not possible to modify the results of measurement.

3.7 Analyzing Performance

Use the [Performance Analysis] window to select a function name and analyze the performance.

3.7.1 Opening the Performance Analysis Window

Choose [View -> Performance -> Performance Analysis] or click the [PA] toolbar button  to open the [Performance Analysis] window.



Index	Function	Cycle	Count	%	Histogram
0	main	4674	1	0%	
1	sort	9829	1	1%	
2	change	2733	1	0%	

Figure 3.35 Performance Analysis Window

This window displays the number of execution cycles required for each specified function.

The number of execution cycles is calculated as follows:

Execution cycles = total number of execution cycles when execution returns from the function
 – total number of execution cycles when the target function is called

The following items are displayed:

- [Index] Index number of the set condition
- [Function] Name of the function to be measured (or the start address of the function)
- [Cycle] Total number of instruction execution cycles
- [Count] Total number of calls for the function
- [%] Ratio of execution cycle count required for the function to the execution cycle count required for the whole program

[Histogram] Histogram display of the above ratio

3.7.2 Specifying a Target Function

After the [Performance Analysis] window is open, choose [Add Range...] from the pop-up menu or press the Insert key to open the [Performance Option] dialog box, which allows the user to specify a function to be analyzed.




Figure 3.36 Performance Option Dialog Box

This dialog box specifies a function (including a label) to be evaluated. Up to 255 functions can be specified in total.

Clicking the [OK] button stores the setting. Clicking the [Cancel] button closes this dialog box without setting the function to be evaluated.

Select a function that has been set and choose [Edit Range] from the pop-up menu or press the Enter key to open the [Performance Option] dialog box and to change the function to be evaluated.

3.7.3 Starting Performance Data Acquisition

Choose [Enable Analysis] from the pop-up menu (a check mark is shown to the left of [Enable analysis]) to start acquiring performance analysis data.

3.7.4 Resetting Data

Choose [Reset Counts/Times] from the pop-up menu to clear the current performance analysis data.

3.7.5 Deleting a Target Function

Select a function and choose [Delete Range] from the pop-up menu to delete the selected target function and to recalculate the data within other ranges. The selected function can also be deleted by the Delete key.

3.7.6 Deleting All Target Functions

Choose [Delete All Ranges] from the pop-up menu to delete all the current target functions to be evaluated and to clear the performance analysis data.

3.7.7 Saving the Currently Displayed Contents

The contents currently displayed in the window can be saved in a text file. Select [Save to File...] from the pop-up menu.

3.8 Acquiring Code Coverage

The [Coverage] window acquires code coverage information (C0 coverage and C1 coverage) in the range specified by the user, and displays the information.

3.8.1 Opening the Coverage Window

Choose [View -> Code -> Coverage...] or click the [Coverage] toolbar button  to open the [Open Coverage] dialog box.




Figure 3.37 Open Coverage Dialog Box

This dialog box specifies the coverage acquiring range. To set coverage for a new range, the following two ways are available:

- Specifying the start and end addresses on the new window

[Start Address] Start address of coverage information display
(When a prefix is omitted, values input are taken as hexadecimal.)

[End Address] End address of coverage information display
(When a prefix is omitted, values input are taken as hexadecimal.)

- Specifying the file on the new window

[File] Source file whose extension is .C or .CPP in the current project.
Functions in the specified file can be set as the coverage range.
If the extension of the file is omitted, .C is complemented.
The file that has other extensions than .C or .CPP cannot be specified.
A placeholder or the [Browse...] button is available.

To use the settings saved in a coverage information file, choose the file from [Open a recent coverage file], or open a file open dialog box by [Browse to another coverage file] and select the file. When [Open a recent coverage file] is selected, up to four recent files that have been saved are displayed.

Clicking [OK] opens the [Coverage] window.

When the [Coverage] window has already been displayed for specifying address, settings are added in the window.

- Coverage window (specifying address)




Figure 3.38 Coverage Window (Specifying Address)

This window displays the coverage range and statistical information. The following items are displayed:

[Range]	Address range
[Statistic]	Percentage of the instructions executed within the range
[Status]	Enable or Disable status of the coverage range

When the [Coverage] window is closed, the acquired coverage information and the conditions to acquire information will be cleared.

- Coverage window (specifying source file)




Figure 3.39 Coverage Window (Specifying Source File)

This window displays the coverage range and statistical information. The following item is displayed:

[Functions]	List of functions
[Statistic]	Percentage of the instruction executed within the function
[Status]	Enable or Disable status of the respective function

Note: The functions can be sorted by their names or percentage, either in ascending or descending order, by clicking the column tab ([Functions] or [Statistic]).

When the [Coverage] window is closed, the acquired coverage information and the conditions to acquire information will be cleared.

3.8.2 Acquiring All Coverage Information

Choose [Enable All] from the pop-up menu and execute the user program to acquire all coverage information. By default, [Enable All] is selected.

3.8.3 Clearing All Coverage Information

Choosing [Clear All] from the popup menu clears all the coverage information that has been acquired.

3.8.4 Viewing the Source Window

Choose [View Source] from the pop-up menu to open the [Editor] window and to display the [Editor] window corresponding to the cursor location in the [Coverage] window.

3.8.5 Specifying the New Coverage Range

Choose [Add Range...] from the pop-up menu to open the [Open Coverage] dialog box (figure 3.37). For the [Open Coverage] dialog box, refer to section 3.8.1, Opening the Coverage Window.

3.8.6 Changing the Coverage Range

- Specifying the coverage range with an address

Choose the coverage range and [Edit Range...] from the pop-up menu to open the [Coverage Range] dialog box.




Figure 3.40 Coverage Range Dialog Box (Specifying Address)

This dialog box specifies the condition to acquire instruction execution information. The following items can be specified.

[Start address] Start address (When a prefix is omitted, values input are taken as hexadecimal.)

[End address] End address (When a prefix is omitted, values input are taken as hexadecimal.)

Clicking [OK] changes the coverage range.

- Specifying the coverage range with a source file

Choose [Edit Range...] from the pop-up menu to open the [Coverage Range] dialog box.




Figure 3.41 Coverage Range Dialog Box (Specifying Source File)

This dialog box specifies the condition to acquire instruction execution information. The following items can be specified.

[File] Source file whose extension is .C or .CPP in the current project.
 Functions in the specified file can be set as the coverage range.
 If the extension of the file is omitted, .C is complemented.
 The file that has other extensions than .C or .CPP cannot be specified.
 A placeholder or the [Browse...] button is available.

Clicking [OK] changes the coverage range.

3.8.7 Deleting the Selected Coverage Range

Select a coverage range and choose [Delete Range] from the pop-up menu to delete the selected coverage range.

3.8.8 Acquiring Coverage Information

Specify a coverage range, choose [Enable Coverage] from the pop-up menu, and execute the user program to acquire coverage information. By default, [Enable Coverage] is selected.

3.8.9 Clearing Coverage Information

Specify a coverage range and choose [Clear Data] from the pop-up menu to clear the acquired coverage information.

3.8.10 Saving Coverage Information in a File

Choose [Save Data...] from the pop-up menu to open the [Save Data] dialog box, which allows the user to save the coverage information in a file.




Figure 3.42 Save Data Dialog Box

This dialog box specifies the location and name of a coverage information file to be saved. The placeholder or the [Browse...] button can be used.

If a file name extension is omitted, .COV is automatically added. If a file name extension other than .COV or .TXT is specified, an error message will be displayed.

3.8.11 Loading Coverage Information from a File

Choose [Load Data...] from the pop-up menu to open the [Load Data] dialog box, which allows the user to load the coverage information from a file.




Figure 3.43 Load Data Dialog Box

This dialog box specifies the location and name of a coverage information file to be loaded. The placeholder or the [Browse...] button can be used.

Only .COV files can be loaded. If a file name extension other than .COV is specified, an error message will be displayed.

3.8.12 Updating the Information

Choose [Refresh] from the pop-up menu to update the [Coverage] window to the latest information.

3.8.13 Confirmation Request Dialog Box

A confirmation request dialog box will appear when [Clear All], [Clear Data], [Edit Range...], or [Delete Range] is clicked or an attempt is made to close the [Coverage] window.



Figure 3.44 Confirmation Request Dialog Box

Clicking [OK] clears the coverage data. Choosing [Save Coverage data] opens the [Save Data] dialog box (figure 3.44) to save the coverage data in a file before it is cleared.

3.8.14 Save Coverage Data Dialog Box

When [File -> Save Session] menu option is clicked, the [Save Coverage Data] dialog box will appear, which allows the user to save the [Coverage] window data in separate files or a single file.




Figure 3.45 Save Coverage Data Dialog Box

When multiple [Coverage] windows are open, a [Save Coverage Data] dialog box will appear for each open coverage window.

Clicking the [No To All] button closes the dialog box without saving any coverage data.

Clicking the [Yes To All] button saves the data of all [Coverage] windows in a single file.

Note: If a file is specified for the coverage range, not all [Coverage] windows can be saved in a single file.

3.8.15 Displaying the Coverage Information in the Editor Window

The coverage information is reflected to the [Editor] window by highlighting the coverage columns corresponding to the source lines of executed instructions. When the coverage settings are modified in the [Coverage] window, the coverage column display will be updated.





Figure 3.46 Coverage Column (Source)

3.8.16 Displaying the Coverage Information in the [Disassembly] Window

The coverage information is reflected to the [Disassembly] window by highlighting the [Coverage – ASM] columns corresponding to the disassembly lines of executed instructions. When the coverage settings are modified in the [Coverage] window, the [Coverage – ASM] column display will be updated.



Coverage - ASM	S..	Disasse...	Obj code	Label	Disassembly
	000800	01106DF2		_main	STM.L (ER2-ER3),
	000804	79370040			SUB.W #H'0040:16
	000808	0F10			MOV.W #1:3,R0
	00080A	5E000EA4			JSR @_srand:24
	00080E	7A0000002150			MOV.L #H'0000215
	000814	010069F0			MOV.L ERO,@ER7
	000818	5E000D9C			JSR @_printf_
	00081C	1922			SUB.W R2,R2
	00081E	7922000A			CMP.W #H'000A:16
F	000822	4C52			BGE @H'0876:8
	000824	5E000E74			JSR @_rand:24
	000828	17F0			EXTS.L ERO
	00082A	0F83			MOV.L ERO,ER3
	00082C	0F80			MOV.L ERO,ERO
T	00082E	4C02			BGE @H'0832:8
	000830	17B3			NEG.L ER3
	000832	0FF1			MOV.L ER7,ER1
	000834	7911000A			ADD.W #H'000A:16
	000838	0D20			MOV.W R2,R0

Figure 3.47 Coverage Column (Disassembly)

3.9 Generating a Pseudo-Interrupt Manually

Windows [Trigger] and [GUI I/O] allow the user to generate a pseudo-interrupt manually by pressing a button on the window.

3.9.1 [Trigger] Window

Choose [View -> CPU -> Trigger] or click the [Trigger] toolbar button  to open the [Trigger] window.




Figure 3.48 Trigger Window

This window displays trigger buttons that generate pseudo-interrupts manually. The details of the interrupt to be generated by pressing each trigger button can be specified in the [Trigger Setting] dialog box.

Up to 256 trigger buttons can be used.

For details on the interrupt processing in the simulator/debugger, refer to section 2.19, Pseudo-Interrupts.

- Setting a trigger button

Choose [Setting...] from the pop-up menu to open the [Trigger Setting] dialog box and to specify the details of the pseudo-interrupt to be generated by pressing each trigger button.




Figure 3.49 Trigger Setting Dialog Box

This dialog box allows the user to specify the details of the pseudo-interrupt to be generated by pressing each trigger button.

[Trigger]	Selects the trigger button to be specified in detail
[Name]	Specifies a name for the selected trigger button; the name will be displayed in the [Trigger] window
[Enable]	Checking this box enables the trigger button.
[Interrupt type1]	Interrupt vector number
[Priority]	Interrupt priority (H'0 to H'11; when the prefix is omitted, values input are taken as hexadecimal, and the display is in hexadecimal notation). Whether or not the interrupt is accepted is determined by the CPU's specification of the selected debugging platform. However, when H'8 or a larger value is specified for the priority, interrupts are always accepted.

Clicking the [OK] button stores the setting. Clicking the [Cancel] button closes this dialog box without setting the details of the interrupt.

Note: If the [Cancel] button is clicked after multiple trigger button settings are modified, the modifications of all those buttons are canceled.

- Changing the number of trigger buttons

Specify the number of trigger buttons displayed in the [Trigger] window in the [Number of Buttons] submenu in the pop-up menu. [4], [16], [64], or [256] can be selected.

- Changing the size of trigger buttons

Specify the size of trigger buttons displayed in the [Trigger] window in the [Size] submenu in the pop-up menu. [Large], [Normal], or [Small] can be selected.

3.9.2 [GUI I/O] Window

Choose [View -> Graphic -> GUI I/O] or click the [GUI I/O] toolbar button  to open the [GUI I/O] window.




Figure 3.50 GUI I/O Window

This window displays buttons that generate pseudo-interrupts manually. The details of the interrupt to be generated by pressing each button can be specified in the [Set Button] dialog box.

For details on the interrupt processing in the simulator/debugger, refer to section 2.19, Pseudo-Interrupts.

- Setting a button

Choose [Create Button] from the pop-up menu or click the [Create Button] toolbar button (). The mouse cursor turns into a “+” symbol. Create the button by dragging the mouse cursor from a higher-left to a lower-right position.





Figure 3.51 GUI I/O Window (Create Button)

Double-click the created button to open the [Set Button] dialog box.

**Figure 3.52 Set Button Dialog Box**

This dialog box allows the user to specify the details of the pseudo-interrupt to be generated by pressing each button.

[Button Name]	Specifies a name for the button; the name will be displayed in the [GUI I/O] window	
[Select Button Type]	Select [Input] or [Input and Interrupt].	
[Interrupt]	[Interrupt Type1]	Interrupt vector number
	[Priority]	Interrupt priority (H'0 to H'11; when the prefix is omitted, values input are taken as hexadecimal, and the display is in hexadecimal notation). Whether or not the interrupt is accepted is determined by the CPU's specification of the selected debugging platform. However, when H'8 or a larger value is specified for the priority, interrupts are always accepted.

3.10 Standard I/O and File I/O Processing

Use the [Simulated I/O] window to enable the simulation for standard I/O and file I/O from the user program.

3.10.1 Opening the Simulated I/O Window

Choose [View -> CPU -> Simulated I/O] or click the [Simulated I/O] toolbar button  to open the [Simulated I/O] window.




Figure 3.53 Simulated I/O Window

The standard output from the user program is displayed in this window. The key input from this window is handled as the standard input to the user program.

3.10.2 I/O Functions


Table 3.1 lists the supported I/O functions. The function codes have 16-bit address, 24-bit address, and 32-bit address versions. Select the version suitable for the CPU being used.

Table 3.1 I/O Functions


No.	Function Code	Function Name	Description
1	H'01 (16-bit address) H'11 (24-bit address) H'21 (32-bit address)	GETC	Inputs one byte from the standard input
2	H'02 (16-bit address) H'12 (24-bit address) H'22 (32-bit address)	PUTC	Outputs one byte to the standard output
3	H'03 (16-bit address) H'13 (24-bit address) H'23 (32-bit address)	GETS	Inputs one line from the standard input
4	H'04 (16-bit address) H'14 (24-bit address) H'24 (32-bit address)	PUTS	Outputs one line to the standard output
5	H'05 (16-bit address) H'15 (24-bit address) H'25 (32-bit address)	FOPEN	Opens a file
6	H'06	FCLOSE	Closes a file
7	H'07 (16-bit address) H'17 (24-bit address) H'27 (32-bit address)	FGETC	Inputs one byte from a file
8	H'08 (16-bit address) H'18 (24-bit address) H'28 (32-bit address)	FPUTC	Outputs one byte to a file
9	H'09 (16-bit address) H'19 (24-bit address) H'29 (32-bit address)	FGETS	Inputs one line from a file
10	H'0A (16-bit address) H'1A (24-bit address) H'2A (32-bit address)	FPUTS	Outputs one line to a file
11	H'0B	FEOF	Checks for end of the file
12	H'0C	FSEEK	Moves the file pointer
13	H'0D	FTELL	Returns the current position of the file pointer

To perform I/O processing, use the [Simulated I/O Address] in the [Simulator System] dialog box (refer to section 3.2.1, Modifying the Simulator System) in the following procedure.

1. Set the address specialized for I/O processing in the [Simulated I/O Address], select [Enable] and execute the program.
 2. When detecting a subroutine call instruction (BSR or JSR), that is, a simulated I/O instruction to the specified address during user program execution, the simulator/debugger performs I/O processing by using the R0 and R1 values (H8/300 and H8/300L series) or the ER1 value (H8/300H, H8S, and H8SX series) as the parameters.
- Set the function code (table 3.1) to the R0 register



- Set the parameter block address to the R1 or ER1 register (for the parameter block, refer to each function description)



- Reserve the parameter block and input/output buffer areas

Each parameter of the parameter block must be accessed in the parameter size.

After the I/O processing, the simulator/debugger resumes simulation from the instruction that follows the simulated I/O instruction.

Refer to the simulator/debugger help about each I/O function.

The following shows an example for inputting one character as a standard input (from a keyboard). Label SYS_CALL is specified as the simulated I/O address.

```
        MOV.W      #H' 0101, R0
        MOV.W      #PARM, R1
        JSR        @SYS_CALL
STOP    NOP
SYS_CALL NOP
PARM    .DATA.W    INBUF
INBUF   .RES.B     2
        .END
```

3.11 Creating a Virtual I/O Panel

The simulator/debugger has a GUI I/O function for simulating a simple key-input or key-output panel of the user target system in a window. This virtual I/O panel is created in the [GUI I/O] window. That is, virtual buttons and virtual LEDs are arranged in this window to allow the input and output of data.




Figure 3.54 Example of a GUI I/O Window

3.11.1 Opening the [GUI I/O] Window

Choose [View -> Graphic -> GUI I/O] or click the [GUI I/O] toolbar button  to open the [GUI I/O] window.




Figure 3.55 [GUI I/O] Window

This window is used to arrange the following items.

Button: Press a button for input of data to a virtual port or generation of a virtual interrupt.

Label: A character string which is shown when the value written to a selected address or bit was the specified value and hidden otherwise.

LED: A defined region in which a specified color is displayed (representing illumination of a LED) when the value written to a selected address or bit was the specified value.

Text: A region for the display of a text string.

3.11.2 Creating a Button

Click on the  button of the toolbar or choose [Create Button] from the pop-up menu. The mouse cursor turns into a “+” symbol. Create the button by dragging the mouse cursor from a higher-left to a lower-right position.





Figure 3.56 GUI I/O Window (Create Button)

- Specifying the event generated by clicking the button

Press the  button on the toolbar and double-click on the created button to open the [Set Button] dialog box.



The **Set Button Dialog** box is used to configure button settings. It includes fields for the button name, type selection (Input, Interrupt, or Input and Interrupt), input type (Address), address (3E0), data (55), and length (Byte). It also features a Bit Mask section with a 'Not Use' checkbox and a Mask Data field. A Bit No. section shows bit positions 7 through 0, each with a '-' symbol. A Bit Symbol field and a Bit Value field (set to 0) are also present. The Interrupt section includes fields for Interrupt Type1 (H'00000000), Interrupt Type2 (H'00000000), and Priority (0). The dialog box has OK and Cancel buttons at the bottom.

Figure 3.57 Set Button Dialog Box

Enter the name of the button, input port address, and input data. The button name must not include white space.

3.11.3 Creating a Label

Click on the  button of the toolbar or choose [Create Label] from the pop-up menu. The mouse cursor turns into a “+” symbol. Drag the mouse cursor from a higher-left to a lower-right position. This shows the frame for the label.




Figure 3.58 GUI I/O Window (Create Label)

Press the  button on the toolbar or choose [Select Item] from the pop-up menu and double-click on the created label to open the [Set Label] dialog box. Specify the responses to events. The label name must not include white space.

- Response to writing of either value to a selected bit

The settings shown below set up display of the character string “Printing in progress” or “Printer ready” when the value of bit 3 at address 0x3E0 is 0 or 1, respectively.




Figure 3.59 Set Label Dialog Box (Bit Selection)

- Response to writing of specified values to a selected address

The settings shown below set up display of the character string “Printing in progress” or “Printer ready” when the value 0x10 or 0x20, respectively, is written to address 0x3E0.




Figure 3.60 Set Label Dialog Box (Data Selection)

3.11.4 Creating an LED

Click on the  button on the toolbar or choose [Create LED] from the pop-up menu. The mouse cursor turns into a “+” symbol. Drag the mouse cursor from an upper left to a lower right position. This shows the frame for the LED output.




Figure 3.61 GUI I/O Window (Create LED)

Press the  button on the toolbar or choose [Select Item] from the pop-up menu and double-click on the created LED to open the [Set LED] dialog box. Specify the events and responses.

- Response to writing of either value to a selected bit

The settings shown below set up the display of green or red, respectively, in the LED area when the value of bit 2 at address 0x3E0 is 0 or 1.




Figure 3.62 Set LED Dialog Box (Bit Selection)

- Response to writing of specified values to a selected address

The settings shown below set up the display of green or red, respectively, in the LED area when the value 0x10 or 0x20 is written to address 0x3E0.




Figure 3.63 Set LED Dialog Box (Data Selection)

Clicking the [Color 1] or [Color 2] button opens the [Color] dialog box, which allows you to select the color.

3.11.5 Creating Fixed Text

Click the  button on the toolbar or choose [Create Text] from the pop-up menu. The mouse cursor turns into a “+” symbol. Create the text box by dragging the mouse cursor from a higher-left to a lower-right position.




Figure 3.64 GUI I/O Window (Create Fixed Text)

- Setting the format for the text

Press the  button on the toolbar and double-click on the created text to open the [Set Text] dialog box.



Figure 3.65 Set Text Dialog Box

Click the [Font...] button to select the font and size for the text. Then click the [Text] and [Back] buttons to specify the colors of the text and its background.

3.11.6 Changing the Size and Position of an Item

Press the  button on the toolbar and click on the item. The item is selected as shown in the figure below.




Figure 3.66 GUI I/O Window (Item Selected)

Drag the item to change its position or the control points to change its size.

3.11.7 Copying an Item

Press the  button on the toolbar or choose [Copy] from the pop-up menu. The mouse cursor turns into a “+” symbol. In this state, click on the item you wish to copy. Press the  button on the toolbar or choose [Paste] from the pop-up menu to create a new item with the same size and attributes.

3.11.8 Deleting an Item

Press the  button on the toolbar or choose [Delete] from the pop-up menu. The mouse cursor turns into a “+” symbol. In this state, click on the item you wish to delete.

3.11.9 Showing the Grid

Press the  button on the toolbar or choose [Display Grid] from the pop-up menu. This displays the grid on the background.




Figure 3.67 GUI I/O Window (Show Grid)

Clicking the  button again hides the grid.

3.11.10 Saving I/O Panel Information

It is possible to reuse created I/O panels by saving the information in files. Press the  button on the toolbar or choose [Save] from the pop-up menu to open the [Save GUI I/O Panel File] dialog box. Specify the directory where the file is to be stored and enter the file name.

3.11.11 Loading I/O Panel Information

Press the  button on the toolbar or choose [Load] from the pop-up menu to open the [Load GUI I/O Panel File] dialog box. Specify the file you wish to load. Panel information prior to the load will be deleted.

Section 4 Windows

Table 4.1 lists the windows.

Refer to the simulator/debugger help about the toolbar buttons.

Table 4.1 Simulator/Debugger Windows

Window Name	Function
Command Line	Debugging with the Command Line Interface
Coverage	Acquiring Code Coverage
Disassembly	Viewing the Assembly-Language Code
Editor	Viewing a Program
Event	Using the Simulator/Debugger Breakpoints
GUI I/O	Creating a Virtual I/O Panel
Image	Displaying Memory Contents as an Image
IO	Viewing the I/O Memory
Label	Looking at Labels
Local	Looking at Variables (local variables)
Memory	Viewing a Memory Area
Profile/Profile-Chart	Viewing the Profile Information
Performance Analysis	Analyzing Performance
Register	Looking at Registers
Simulated I/O	Standard I/O and File I/O Processing
Stack Trace	Viewing the Function Call History
Status	Viewing the Current Status
Trace	Viewing the Trace Information
Trigger	Generating a Pseudo-Interrupt Manually
Watch	Looking at Variables (any variables)
Wave	Displaying Memory Contents as Waveforms

Section 5 Command Lines

5.1 Commands (Functional Order)

The following tables show the commands in functional order.

Refer to the simulator/debugger help about each command.

5.1.1 Execution

Command Name	Abbreviation	Function
GO	GO	Executes user program
GO_RESET	GR	Executes user program from reset vector
GO_TILL	GT	Executes user program until temporary breakpoint
HALT	HA	Halts the user program
RESET	RE	Resets CPU
STEP	ST	Steps program (by instructions or source lines)
STEP_MODE	SM	Selects the step mode
STEP_OUT	SP	Steps out of the current function
STEP_OVER	SO	Steps program, not stepping into functions
STEP_RATE	SR	Sets or displays rate of stepping

5.1.2 Download

Command Name	Abbreviation	Function
BUILD	BU	Performs a build on the current project
BUILD_ALL	BL	Performs a build all on the current project
BUILD_FILE	BF	Compiles files
BUILD_MULTIPLE	BM	Builds multiple projects
CLEAN	CL	Deletes intermediate and output files produced in building
DEFAULT_OBJECT_FORMAT	DO	Sets the default object (program) format
FILE_LOAD	FL	Loads an object (program) file
FILE_LOAD_ALL	LA	Loads all object (program) files
FILE_SAVE	FS	Saves memory to a file
FILE_UNLOAD	FU	Unloads an object (program) file from memory
FILE_UNLOAD_ALL	UA	Unloads all object (program) files from memory
FILE_VERIFY	FV	Verifies file contents against memory
GENERATE_MAKE_FILE	GM	Generates a build makefile for the current workspace

5.1.3 Register

Command Name	Abbreviation	Function
REGISTER_DISPLAY	RD	Displays CPU register values
REGISTER_SET	RS	Changes CPU register contents

5.1.4 Memory

Command Name	Abbreviation	Function
CACHE	-	Sets caching on or off
MEMORY_COMPARE	MC	Compares memory contents
MEMORY_DISPLAY	MD	Displays memory contents
MEMORY_EDIT	ME	Modifies memory contents
MEMORY_FILL	MF	Modifies the content of a memory area by specifying data
MEMORY_FIND	MI	Finds a string in an area of memory
MEMORY_MOVE	MV	Moves a block of memory
MEMORY_TEST	MT	Tests a block of memory

5.1.5 Assemble/Disassemble

Command Name	Abbreviation	Function
ASSEMBLE	AS	Assembles instructions into memory
DISASSEMBLE	DA	Disassembles memory contents
SYMBOL_ADD	SA	Defines a symbol
SYMBOL_CLEAR	SC	Deletes a symbol
SYMBOL_LOAD	SL	Loads a symbol information file
SYMBOL_SAVE	SS	Saves a symbol information file
SYMBOL_VIEW	SV	Displays symbols

5.1.6 Break

Command Name	Abbreviation	Function
BREAKPOINT	BP	Sets a breakpoint at an instruction address
BREAK_ACCESS	BA	Specifies a memory range access as a break condition
BREAK_CLEAR	BC	Deletes breakpoints
BREAK_CYCLE	BCY	Specifies a cycle as a break condition
BREAK_DATA	BD	Specifies a memory data value as a break condition
BREAK_DATA_ DIFFERENCE	BDD	Specifies a difference between two values of data in memory as a break condition
BREAK_DATA_ INVERSE	BDI	Specifies inversion of the sign of a value of data in memory as a break condition
BREAK_DISPLAY	BI	Displays a list of breakpoints
BREAK_ENABLE	BE	Enables or disables a breakpoint
BREAK_REGISTER	BR	Specifies a register data as a break condition
BREAK_SEQUENCE	BS	Sets sequential breakpoints
SET_DISASSEMBLY_ SOFT_BREAK	SDB	Sets or deletes a software breakpoint at the disassembly level
SET_SOURCE_ SOFT_BREAK	SSB	Sets or deletes a software breakpoint at the source level
STATE_ DISASSEMBLY_ SOFT_BREAK	TDB	Enables or disables a software breakpoint at the disassembly level
STATE_SOURCE_ SOFT_BREAK	TSB	Enables or disables a software breakpoint at the source level

5.1.7 Trace

Command Name	Abbreviation	Function
TRACE	TR	Displays trace information
TRACE_ACQUISITION	TA	Enables or disables trace information acquisition
TRACE_SAVE	TV	Outputs trace information into a file
TRACE_STATISTIC	TST	Analyzes statistic information

5.1.8 Coverage

Command Name	Abbreviation	Function
COVERAGE	CV	Enables or disables coverage measurement
COVERAGE_DISPLAY	CVD	Displays coverage information
COVERAGE_LOAD	CVL	Loads coverage information
COVERAGE_RANGE	CVR	Sets a coverage range
COVERAGE_SAVE	CVS	Saves coverage information

5.1.9 Performance

Command Name	Abbreviation	Function
ANALYSIS	AN	Enables or disables performance analysis
ANALYSIS_RANGE	AR	Sets or displays performance analysis functions
ANALYSIS_RANGE_DELETE	AD	Deletes a performance analysis range
PROFILE	PR	Enables or disables profile
PROFILE_DISPLAY	PD	Displays profile information
PROFILE_SAVE	PS	Saves the profile information to file

5.1.10 Watch

Command Name	Abbreviation	Function
WATCH_ADD	WA	Adds an item for watching
WATCH_AUTO_UPDATE	WU	Selects or cancels automatic updating of watched items
WATCH_DELETE	WD	Deletes a watched item
WATCH_DISPLAY	WI	Displays the contents of the Watch window
WATCH_EDIT	WE	Edits the value of a watched item
WATCH_EXPAND	WX	Expands or collapses a watched item
WATCH_RADIX	WR	Changes the radix for display of watched items
WATCH_RECORD	WO	Outputs the history of updating of the values of a watched item to a file
WATCH_SAVE	WS	Saves the contents of the Watch window to a file

5.1.11 Script/Logging

Command Name	Abbreviation	Function
!	-	Comment
ASSERT	-	Checks if an expression is true or false
AUTO_COMPLETE	AC	Enables or disables the auto-complete function
ERASE	ER	Clears the [Command Line] window
EVALUATE	EV	Evaluates an expression
LOG	LO	Controls command output logging
SLEEP	-	Delays command execution
SUBMIT	SU	Executes a command file
TCL	-	Displays TCL information

5.1.12 Memory Resource

Command Name	Abbreviation	Function
MAP_DISPLAY	MA	Displays memory resource settings
MAP_SET	MS	Allocates a memory area

5.1.13 Simulator/Debugger Settings

Command Name	Abbreviation	Function
EXEC_MODE	EM	Sets and displays execution mode
EXEC_STOP_SET	ESS	Sets or displays the execution mode at the occurrence of an interrupt

5.1.14 Standard I/O and File I/O

Command Name	Abbreviation	Function
SIMULATEDIO_CLEAR	SIOC	Clears the contents of the [Simulated I/O] window
TRAP_ADDRESS	TP	Sets a simulated I/O address
TRAP_ADDRESS_DISPLAY	TD	Displays simulated I/O address settings
TRAP_ADDRESS_ENABLE	TE	Enables or disables the simulated I/O

5.1.15 Utility

Command Name	Abbreviation	Function
HELP	HE	Displays the command line help
INITIALIZE	IN	Initializes the debugging platform
QUIT	QU	Exits HEW
RADIX	RA	Sets default input radix
RESPONSE	RP	Sets an interval to refresh the window
STATUS	STA	Displays the debugging platform status
TOOL_INFORMATION	TO	Outputs information on the currently registered tool to a file

5.1.16 Project/Workspace

Command Name	Abbreviation	Function
ADD_FILE	AF	Adds a file to the current project
CHANGE_CONFIGURATION	CC	Sets the current configuration
CHANGE_PROJECT	CP	Sets the current project
CHANGE_SESSION	CS	Changes the current session
CHANGE_SUB_SESSION	CB	Changes the currently active session when simultaneous debugging is enabled
CLEAR_OUTPUT_WINDOW	COW	Clears the contents of the specified tab in the [Output] window
CLOSE_WORKSPACE	CW	Closes the current workspace
OPEN_WORKSPACE	OW	Opens a workspace
REFRESH_SESSION	RSE	Updates information on the session
REMOVE_FILE	REM	Removes a file from the current project
SAVE_SESSION	SE	Saves the current session
SAVE_WORKSPACE	SW	Saves the current workspace
UPDATE_ALL_DEPENDENCIES	UD	Updates all build dependencies of the current project

5.1.17 Test Tool Facility

Command Name	Abbreviation	Function
CLOSE_TEST	CT	Closes a test suite
COMPARE_TEST_DATA	CTD	Compares test data
LOAD_TEST_DATA	LTD	Loads test data to the [Load Test Image File] dialog box
OPEN_TEST	OT	Opens a test suite
RUN_TEST	RT	Executes a test
SAVE_TEST_DATA	STD	Saves test data

5.2 Commands (Alphabetical Order)

Table 5.1 lists the commands in alphabetical order.

Refer to the simulator/debugger help about each command.

Table 5.1 Simulator/Debugger Commands

No.	Command Name	Abbreviation	Function
1	!	-	Comment
2	ADD_FILE	AF	Adds a file to the current project
3	ANALYSIS	AN	Enables or disables performance analysis
4	ANALYSIS_RANGE	AR	Sets or displays performance analysis functions
5	ANALYSIS_RANGE_DELETE	AD	Deletes a performance analysis range
6	ASSEMBLE	AS	Assembles instructions into memory
7	ASSERT	-	Checks if an expression is true or false
8	AUTO_COMPLETE	AC	Enables or disables the auto-complete function
9	BREAKPOINT	BP	Sets a breakpoint at an instruction address
10	BREAK_ACCESS	BA	Specifies a memory range access as a break condition
11	BREAK_CLEAR	BC	Deletes breakpoints
12	BREAK_CYCLE	BCY	Specifies a cycle as a break condition
13	BREAK_DATA	BD	Specifies a memory data value as a break condition
14	BREAK_DATA_DIFFERENCE	BDD	Specifies a difference between two values of data in memory as a break condition
15	BREAK_DATA_INVERSE	BDI	Specifies inversion of the sign of a value of data in memory as a break condition
16	BREAK_DISPLAY	BI	Displays a list of breakpoints
17	BREAK_ENABLE	BE	Enables or disables a breakpoint
18	BREAK_REGISTER	BR	Specifies a register data as a break condition
19	BREAK_SEQUENCE	BS	Sets sequential breakpoints
20	BUILD	BU	Performs a build on the current project
21	BUILD_ALL	BL	Performs a build all on the current project
22	BUILD_FILE	BF	Compiles files
23	BUILD_MULTIPLE	BM	Builds multiple projects

Table 5.1 Simulator/Debugger Commands (cont)

No.	Command Name	Abbreviation	Function
24	CACHE	-	Sets caching on or off
25	CHANGE_CONFIGURATION	CC	Sets the current configuration
26	CHANGE_PROJECT	CP	Sets the current project
27	CHANGE_SESSION	CS	Changes the current session
28	CHANGE_SUB_SESSION	CB	Changes the currently active session when simultaneous debugging is enabled
29	CLEAN	CL	Deletes intermediate and output files produced in building
30	CLEAR_OUTPUT_WINDOW	COW	Clears the contents of the specified tab in the [Output] window
31	CLOSE_TEST	CT	Closes a test suite
32	CLOSE_WORKSPACE	CW	Close the current workspace
33	COMPARE_TEST_DATA	CTD	Compares test data
34	COVERAGE	CV	Enables or disables coverage measurement
35	COVERAGE_DISPLAY	CVD	Displays coverage information
36	COVERAGE_LOAD	CVL	Loads coverage information
37	COVERAGE_RANGE	CVR	Sets a coverage range
38	COVERAGE_SAVE	CVS	Saves coverage information
39	DEFAULT_OBJECT_FORMAT	DO	Sets the default object (program) format
40	DISASSEMBLE	DA	Disassembles memory contents
41	ERASE	ER	Clears the [Command Line] window
42	EVALUATE	EV	Evaluates an expression
43	EXEC_MODE	EM	Sets and displays execution mode
44	EXEC_STOP_SET	ESS	Sets or displays the execution mode at the occurrence of an interrupt
45	FILE_LOAD	FL	Loads an object (program) file
46	FILE_LOAD_ALL	LA	Loads all object (program) files
47	FILE_SAVE	FS	Saves memory to a file

Table 5.1 Simulator/Debugger Commands (cont)

No.	Command Name	Abbreviation	Function
48	FILE_UNLOAD	FU	Unloads an object (program) file from memory
49	FILE_UNLOAD_ALL	UA	Unloads all object (program) files from memory
50	FILE_VERIFY	FV	Verifies file contents against memory
51	GENERATE_MAKE_FILE	GM	Generates a build makefile for the current workspace
52	GO	GO	Executes user program
53	GO_RESET	GR	Executes user program from reset vector
54	GO_TILL	GT	Executes user program until temporary breakpoint
55	HALT	HA	Halts the user program
56	HELP	HE	Displays the command line help
57	INITIALIZE	IN	Initializes the debugging platform
58	LOG	LO	Controls command output logging
59	MAP_DISPLAY	MA	Displays memory resource settings
60	MAP_SET	MS	Allocates a memory area
61	MEMORY_COMPARE	MC	Compares memory contents
62	MEMORY_DISPLAY	MD	Displays memory contents
63	MEMORY_EDIT	ME	Modifies memory contents
64	MEMORY_FILL	MF	Modifies the content of a memory area by specifying data
65	MEMORY_FIND	MI	Finds a string in an area of memory
66	MEMORY_MOVE	MV	Moves a block of memory
67	MEMORY_TEST	MT	Tests a block of memory
68	OPEN_TEST	OT	Opens a test suite
69	OPEN_WORKSPACE	OW	Opens a workspace
70	PROFILE	PR	Enables or disables profile
71	PROFILE_DISPLAY	PD	Displays profile information
72	PROFILE_SAVE	PS	Saves the profile information to file
73	QUIT	QU	Exits HEW
74	RADIX	RA	Sets default input radix
75	REFRESH_SESSION	RSE	Updates information on the session

Table 5.1 Simulator/Debugger Commands (cont)

No.	Command Name	Abbreviation	Function
76	REGISTER_DISPLAY	RD	Displays CPU register values
77	REGISTER_SET	RS	Changes CPU register contents
78	REMOVE_FILE	REM	Removes a file from the current project
79	RESET	RE	Resets CPU
80	RESPONSE	RP	Sets an interval to refresh the window
81	RUN_TEST	RT	Executes a test
82	SLEEP	-	Delays command execution
83	SAVE_SESSION	SE	Saves the current session
84	SAVE_WORKSPACE	SW	Saves the current workspace
85	SET_DISASSEMBLY_ SOFT_BREAK	SDB	Sets or deletes a software breakpoint at the disassembly level
86	SET_SOURCE_ SOFT_BREAK	SSB	Sets or deletes a software breakpoint at the source level
87	SIMULATEDIO_CLEAR	SIOC	Clears the contents of the [Simulated I/O] window
88	STATE_DISASSEMBLY_ SOFT_BREAK	TDB	Enables or disables a software breakpoint at the disassembly level
89	STATE_SOURCE_ SOFT_BREAK	TSB	Enables or disables a software breakpoint at the source level
90	STATUS	STA	Displays the debugging platform status
91	STEP	ST	Steps program (by instructions or source lines)
92	STEP_MODE	SM	Selects the step mode
93	STEP_OUT	SP	Steps out of the current function
94	STEP_OVER	SO	Steps program, not stepping into functions
95	STEP_RATE	SR	Sets or displays rate of stepping
96	SUBMIT	SU	Executes a command file
97	SYMBOL_ADD	SA	Defines a symbol
98	SYMBOL_CLEAR	SC	Deletes a symbol
99	SYMBOL_LOAD	SL	Loads a symbol information file
100	SYMBOL_SAVE	SS	Saves a symbol information file
101	SYMBOL_VIEW	SV	Displays symbols

Table 5.1 Simulator/Debugger Commands (cont)

No.	Command Name	Abbreviation	Function
102	TCL	-	Enables or disables the TCL
103	TOOL_INFORMATION	TO	Outputs information on the currently registered tool to a file
104	TRACE	TR	Displays trace information
105	TRACE_ACQUISITION	TA	Enables or disables trace information acquisition
106	TRACE_SAVE	TV	Outputs trace information into a file
107	TRACE_STATISTIC	TST	Analyzes statistic information
108	TRAP_ADDRESS	TP	Sets a simulated I/O address
109	TRAP_ADDRESS_DISPLAY	TD	Displays simulated I/O address settings
110	TRAP_ADDRESS_ENABLE	TE	Enables or disables the simulated I/O
111	UPDATE_ALL_DEPENDENCIES	UD	Updates all build dependencies of the current project
112	WATCH_ADD	WA	Adds an item for watching
113	WATCH_AUTO_UPDATE	WU	Selects or cancels automatic updating of watched items
114	WATCH_DELETE	WD	Deletes a watched item
115	WATCH_DISPLAY	WI	Displays the contents of the Watch window
116	WATCH_EDIT	WE	Edits the value of a watched item
117	WATCH_EXPAND	WX	Expands or collapses a watched item
118	WATCH_RADIX	WR	Changes the radix for display of watched items
119	WATCH_RECORD	WO	Outputs the history of updating of the values of a watched item to a file
120	WATCH_SAVE	WS	Saves the contents of the Watch window to a file

Refer to the simulator/debugger help about each command.

Section 6 Messages

6.1 Information Messages

The simulator/debugger outputs information messages as listed in table 6.1 to notify users of execution status.

Table 6.1 Information Messages

Message	Contents
Break Access (Access Address: H'nnnnnnnn, Type: xxxx, Access Size: yyyy)	An access break condition was satisfied so execution has stopped. The information in parentheses shows the satisfied access break condition (accessed address, access type, and access unit).
Break Cycle (Cycle: H'nnnnnnnn)	A number-of-cycles condition was satisfied so execution has stopped. The information in parentheses shows the satisfied number-of-cycles condition (number of cycles).
Break Data (Access Address: H'nnnnnnnn, Data: H'mmmmmmmm)	A data break condition ([Equal] or [Not equal]) was satisfied so execution has stopped. The information in parentheses shows the satisfied data break condition (accessed address and value).
Break Data (Access Address: H'nnnnnnnn, Previous Data: H'mmmmmmmm, Current Data: H'mmmmmmmm)	A data break condition ([Inverse sign] or [Difference]) was satisfied so execution has stopped. The information in parentheses shows the satisfied data break condition (accessed address, and previous and current values).
Break Register (Register: XX, Value: H'mmmmmmmm)	A register break condition was satisfied so execution has stopped. The information in parentheses shows the satisfied register break condition (register name and value).
Break Sequence (PC: H'nnnnnn)	A sequential break condition was satisfied so execution has stopped. The information in parentheses shows the satisfied sequential break condition (address of the last instruction).
I/O DLL Stop	The peripheral function has stopped.
PC Breakpoint (PC: H'nnnnnn)	A PC breakpoint condition was satisfied so execution has stopped. The information in parentheses shows the satisfied PC-breakpoint condition (instruction address).
Sleep	Execution has been stopped by the SLEEP instruction.
Step Normal End	The step execution succeeded.

Table 6.1 Information Messages (cont)

Message	Contents
Stop	Execution has been stopped by the [Stop] button.
Trace Buffer Full	Since the Break mode was selected by [Trace buffer full handling] in the [Trace Acquisition] dialog box and the trace buffer became full, execution was terminated.

6.2 Error Messages

The simulator/debugger outputs error messages to notify users of the errors of user programs or operation. Table 6.2 lists the error messages.

Table 6.2 Error Messages

Message	Contents
Address Error	One of the following states occurred: • The PC value was an odd number. • An instruction was read from the internal I/O area. • Word data was accessed to an address that was not a multiple of 2. • Longword data was accessed to an address that was not a multiple of 2. Correct the user program to prevent the error.
Exception Error	An error occurred during exception processing. Correct the user program to prevent the error.
File Open Error	An error occurred during opening a file with the file-input/output action of Break. Correct the file setting.
File Input Error	An error occurred during reading a file with the file-input/output action of Break. Correct the file setting.
File Output Error	An error occurred during writing to a file with the file-input/output action of Break. Correct the file setting.
Illegal Instruction	Either of the following states occurred: • A code other than an instruction was executed. • MOV.B Rn, @-SP or MOV.B @SP+, Rn was executed. Correct the user program to prevent the error.

Table 6.2 Error Messages (cont)

Message	Contents
Illegal Operation	Either of the following states occurred: • The relationship between flags C and H of CCR and the value before correction was illegal in the DAA or DAS instruction. • A division by zero or an overflow occurred during DIVXU or DIVXS instruction execution. Correct the user program to prevent the error.
I/O area not exist	An attempt was made to delete the I/O area. Be sure to set the I/O area.
I/O DLL Illegal Interrupt Information (errNum=2xx)	Information on interrupts is incorrect. [errNum] shows the details on this error. Correct the information. [errNum] 200: The specified vector is outside the supported range. 201: The specified priority is outside the supported range.
I/O DLL Memory Access Error (errNum=0xx, Address=0XXXXXXXXX)	An error has occurred during a memory access to the peripheral function. [errNum] shows the details on this error and [Address] shows the address where this error occurred. Correct the user program according to the error information. [errNum] 001: The specified address is outside the supported range. 002: No memory exists in the specified area. 003: The required memory cannot be allocated. 004: The specified data size is outside the supported range. 005: The specified address cannot be accessed.
I/O DLL Register Access Error (errNum=1xx, RegisterName=xxxx)	An error has occurred during a register access to the peripheral function. [errNum] shows the details on this error and [RegisterName] shows the register where this error occurred. Correct the user program according to the error information. [errNum] 100: The register description is incorrect. 101: The specified data value is incorrect.

Table 6.2 Error Messages (cont)

Message	Contents
Memory Access Error (Address: H'nnnnnnnn)	One of the following events occurred (the information in parentheses shows the target address for the operation that generated the error): • A memory area that had not been allocated was accessed. • Data was written to a memory area having the write-protected attribute. • Data was read from a memory area having the read-disabled attribute. • A memory area in which memory does not exist was accessed. • Writing to the EEPROM was attempted by instructions other than EEPMOV Allocate memory, change the memory attribute, or correct the user program to prevent the memory from being accessed.
System Call Error	Simulated I/O error occurred. Modify the incorrect contents of registers R0, R1, and parameter block.
The memory resource has not been set up	The memory resource was set outside the range of memory mapping. Modify the memory resource settings so that no error will occur.

Section 7 Tutorial

7.1 Preparation

The basic functions of the simulator/debugger will be described in this section using a sample program.

Note: The contents of usage examples (figures) in this section will differ depending on the compiler version.

7.1.1 Sample Program


The HEW demonstration program is used for the sample program and is written in C language. It first sorts ten random data in the ascending order, and then in the descending order. The sample program:

- (1) Generates random data for sorting using the main function.
- (2) Inputs the array which stores the random data that is generated by the main function, then sorts the data in the ascending order using the sort function.
- (3) Inputs the array generated by the sort function, and sorts the data in the descending order using the change function.
- (4) Displays the random data and the sorted data using the printf function.

The HEW demonstration program is used as the sample program.

7.1.2 Creating the Sample Program

Note the following when creating the HEW demonstration program:

- Specify [Demonstration] for [Project Type] in [Creating a New Workspace].
- Specify [2600] for [CPU Series:].
- Specify [H8S/2600N Simulator] for [Target:].
- Specify [SimDebug_H8S-2600] () for the configuration on the toolbar before building the project.
- Specify [SimSessionH8S-2600] () for the session on the toolbar.
- This demonstration program uses no peripheral function (timer). In the [Set Peripheral Function Simulation] dialog box that opens when the session is changed, check [Don't show this dialog box] and then press the [OK] button.

Since this section explains the debugging function, [Demonstration] has not been optimized. Do not change this setting.

7.2 Settings for Debugging

7.2.1 Allocating the Memory Resource

The allocation of the memory resource is necessary to run the application being developed. When using the demonstration project, the memory resource is allocated automatically, so check the setting.

- Select [Simulator->Memory Resource...] from the [Setup] menu, and display the allocation of the current memory resource.




Figure 7.1 Simulator System Dialog Box (Memory Page)

The program and stack areas are allocated to the range of addresses H'00000000 to H'0000FFFF, which can be read from or written to.

- Close the dialog box by clicking [OK].

The memory resource can also be referred to or modified by using the [Debugger] page on the [H8S, H8/300 Standard Toolchain] dialog box. Changes made in either of the dialog boxes are reflected.

7.2.2 Downloading the Sample Program

When using the demonstration project, the sample program to be downloaded is automatically set, so check the settings.

- Open the [Debug Setting] dialog box by selecting [Debug Settings...] on the [Debug] menu.




Figure 7.2 Debug Settings Dialog Box

- Files to be downloaded are listed in [Download Modules].
- Close the [Debug Settings] dialog box by clicking the [OK] button.
- Download the sample program by selecting [Download Modules->All Download Modules] from the [Debug] menu.

7.2.3 Displaying the Source Program

The HEW supports the source-level debugging. Display the source file ("Tutorial.c") in the [Source] window.

- Open the [Source] window by double-clicking Tutorial.c on the [Workspace] window.




Figure 7.3 Source Window (Displaying the Source Program)

7.2.4 Setting a PC Breakpoint

Breakpoints can be set easily via the [Source] window. To set a breakpoint on a line that includes the sort function call:

- Place the cursor in the line that includes the sort function call and click the right mouse button to launch the pop-up menu, and select [Toggle Breakpoint] from the pop-up menu.




Figure 7.4 Source Window (Setting the Breakpoint)

A [•] is displayed at the line that includes the sort function call, indicating that the PC breakpoint is set at the address.

7.2.5 Setting the Profiler

- Open the [Profile] window by selecting [Profile] from the [View->Performance] menu.




Figure 7.5 Profile Window

- Open the pop-up menu by right clicking the mouse on the [Profile] window, and select [Enable Profiler] to enable acquisition of the profile information.

7.2.6 Setting the Simulated I/O

When the demonstration project is used, the simulated I/O is automatically set, so check the setting.

- Open the [Simulator System] dialog box by selecting [Simulator->System] from the [Setup] menu.




Figure 7.6 Simulator System Dialog Box (System Page)

- Confirm that [Enable] in [Simulated I/O Address] is checked.
- Click the [OK] button to enable the simulated I/O.
- Select [Simulated I/O] from the [View->CPU] menu and open the [Simulated I/O] window. The simulated I/O will not be enabled if the [Simulated I/O] window is not open.




Figure 7.7 Simulated I/O Window

7.2.7 Setting the Trace Information Acquisition Conditions

- Select [Trace] from the [View->Code] menu to open the [Trace] window. Open the pop-up menu by right clicking the mouse on the [Trace] window, and select [Acquisition...] from the pop-up menu.

The [Trace Acquisition] dialog box below will be displayed.



Figure 7.8 Trace Acquisition Dialog Box

- Set [Trace Start/Stop] to [Enable] in the [Trace Acquisition] dialog box, and click the [OK] button to enable the acquisition of the trace information.

7.2.8 Setting the Stack Pointer and Program Counter

To execute the program, the program counter must be set from the location of the reset vector. In the reset vector of the sample program, the PC value H'400 is written.

- Select [Reset CPU] from the [Debug] menu, or click the [Reset CPU] button on the toolbar.

Set the program counter to H'400 from the reset vector.



Figure 7.9 Reset CPU Button

7.3 Start Debugging

7.3.1 Executing a Program

- Select [Go] from the [Debug] menu, or click the [Go] button on the toolbar.



Figure 7.10 Go Button

The program halts where a breakpoint is set. An arrow is displayed in the [Source] window, indicating the location the execution has stopped. As the termination cause, [PC Breakpoint (PC: H'0B36)] is displayed in the [Output] window.





Figure 7.11 Source Window (Break Status)

The termination cause can be displayed in the [Status] window.

- Select [Status] from the [View->CPU] menu to open the [Status] window, and select the [Platform] sheet in the [Status] window.


**Figure 7.12 Status Window**

The above status window indicates that:

- (1) The cause of break is a PC breakpoint
- (2) Execution is performed from the reset
- (3) The number of executed instructions by the GO command is 39,580
- (4) The executed number of cycles from the reset is 278,634

Register values can be checked in the [Register] window.

- Select [Registers] from the [View->CPU] menu.



The screenshot shows a window titled "Register" with a table of registers. The table has two columns: "Name" and "Value". The registers listed are ER0 through ER7, PC, CCR, EXR, and MACH. The values are in hexadecimal. The CCR register has additional status flags shown to its right: "-0---Z-". The EXR register has additional status flags shown to its right: "-----1".

Name	Value
ER0	0000000A
ER1	FFFF000A
ER2	0000000A
ER3	00000000
ER4	00000000
ER5	00000000
ER6	00000000
ER7	0000FBAE
PC	000B36
CCR	00000100 -0---Z-
EXR	01111111 -----1
MACH	00000000


Figure 7.13 Register Window

Register values when the program is terminated can be checked.

7.3.2 Using the Trace Buffer

The trace buffer can be used to clarify the history of instruction execution.

- Select [Trace] from the [View->Code] menu and open the [Trace] window. Scroll up to the very top of the window.



The screenshot shows a window titled "Trace" with a toolbar containing icons for file operations, execution control (STOP), and a function key F(). Below the toolbar is a table with the following columns: PTR, Cycle, Address, CCR, Mult, Instruction, Access Data, Source, and Label. The table contains 14 rows of trace data, showing instructions like INC.W, MOV.W, MOV.B, and BNE, along with their cycle numbers, addresses, and the state of the CCR and Mult flags.

PTR	Cycle	Address	CCR	Mult	Instruction	Access Data	Source	Label
-01023	0000271335	001EEC	-----	---	INC.W #1,E0	E0<-0002		
-01022	0000271339	001EEE	----N---	---	MOV.W E1,R0	R0<-FAFA		
-01021	0000271343	001EF0	----N---	---	INC.W #1,E1	E1<-FAPB		
-01020	0000271348	001EF2	-----	---	MOV.B @ERO,R1L	R1L<-38		
-01019	0000271356	001EF4	-----	---	BNE @H'1EEC:8	PC<-00001EEC		
-01018	0000271360	001EEC	-----	---	INC.W #1,E0	E0<-0003		
-01017	0000271364	001EEE	----N---	---	MOV.W E1,R0	R0<-FAPB		
-01016	0000271368	001EF0	----N---	---	INC.W #1,E1	E1<-FAPC		
-01015	0000271373	001EF2	-----	---	MOV.B @ERO,R1L	R1L<-36		
-01014	0000271381	001EF4	-----	---	BNE @H'1EEC:8	PC<-00001EEC		
-01013	0000271385	001EEC	-----	---	INC.W #1,E0	E0<-0004		
-01012	0000271389	001EEE	----N---	---	MOV.W E1,R0	R0<-FAPC		
-01011	0000271393	001EF0	----N---	---	INC.W #1,E1	E1<-FAPD		
-01010	0000271398	001EF2	-----Z--	---	MOV.B @ERO,R1L	R1L<-00		

Figure 7.14 Trace Window (Trace Information Display)

7.3.3 Performing Trace Search

Click the right mouse button on the [Trace] window to launch the pop-up menu, and select [Find...] to open the [Trace Search] dialog box.





Figure 7.15 Trace Search Dialog Box

Setting the item to be searched to [Item] and the contents to be searched to [Value] and clicking the [OK] button begins the trace search. When the searched item is found, the first line is highlighted. To continue searching the same contents [Value], click the right mouse button in the [Trace] window to display the pop-up menu, and select [Find Next] from the pop-up menu. The next searched line is highlighted.




PTR	Cycle	Address	CCR	Mult	Instruction	Access Data	Source	Label
-01016	0000271368	001EF0	---N---	---	INC.W #1,E1	E1<-FAFC		
-01015	0000271373	001EF2	-----	---	MOV.B @ERO,R1L	R1L<-36		
-01014	0000271381	001EF4	-----	---	BNE @H'1EEC:8	PC<-00001EEC		
-01013	0000271385	001EEC	-----	---	INC.W #1,E0	E0<-0004		
-01012	0000271389	001EEE	---N---	---	MOV.W E1,R0	R0<-FAFC		
-01011	0000271393	001EF0	---N---	---	INC.W #1,E1	E1<-FAFD		
-01010	0000271398	001EF2	---Z---	---	MOV.B @ERO,R1L	R1L<-00		
-01009	0000271406	001EF4	---Z---	---	BNE @H'1EEC:8	PC<-00001EF6		
-01008	0000271410	001EF6	-----	---	MOV.W E0,R0	R0<-0004		
-01007	0000271420	001EF8	-----	---	RTS	PC<-00001500		
-01006	0000271424	001500	-----	---	EXTU.L ERO	ERO<-0000...		
-01005	0000271428	001502	-----	---	MOV.L ERO,ER1	ER1<-0000...		
-01004	0000271442	001504	-----	---	MOV.L ERO,@(...	0000FB8E<...		
-01003	0000271450	00150A	-----	---	BRA @H'1518:8	PC<-00001518		

Figure 7.16 Trace Window (Searched Result)

7.3.4 Checking Simulated I/O

Random data that is displayed by the printf function can be checked in the [Simulated I/O] window.



```

### Data Input ###
a[0]=16838
a[1]=5758
a[2]=10113
a[3]=17515
a[4]=31051
a[5]=5627
a[6]=23010
a[7]=7419
a[8]=16212
a[9]=4086

```

Figure 7.17 Simulated I/O Window

- Do not close the [Simulated I/O] window.

7.3.5 Checking the Breakpoints

A list of all the breakpoints that are set in the program can be checked in the [Event] window.

- Select [Eventpoints] from the [View -> Code] menu.




Figure 7.18 Event Window

A breakpoint can be set, a new breakpoint can be defined, and a breakpoint can be deleted using the [Event] window.

- Close the [Event] window.

7.3.6 Watching Variables

It is possible to watch the values of variables used in your program and to verify that they change in the way that you expected. For example, set a watch on the long-type array “a” declared at the beginning of the program, by using the following procedure:

- Select [Watch] from the [View -> Symbol] menu to open the [Watch] window. And click the right mouse button on the [Watch] window and choose [Add Watch...] from the pop-up menu.

The following dialog box will be displayed.




Figure 7.19 Add Watch Dialog Box

- Type array “a” and click the [OK] button.

The [Watch] window will show the long-type array “a”.

You can double-click the + symbol to the left of array “a” in the [Watch] window to expand the variable and show the individual elements in the array.




Figure 7.20 Watch Window

- Close the [Watch] window.

7.3.7 Executing the Program in Single Steps

The simulator/debugger has various stepping menus that are useful in debugging the program.

Menu	Description
Step In	Executes each statement (includes statements within the function)
Step Over	Executes a function call in a single step
Step Out	Steps out of a function, and stops at the next statement of the program that called the function
Step...	Executes the specified number of steps at the specified speed

[Step In]: Enters the called function and stops at the statement at the start of the called function.

- To step in the sort function, select [Step In] from the [Debug] menu, or click the [Step In] button on the toolbar.



Figure 7.21 Step In Button




Figure 7.22 Source Window (Step In)

- The PC location display (=>) in the [Source] window moves to the statement at the start of the sort function.

[Step Out]: Steps out of the called function and stops at the next statement in the called program.

- Select [Step Out] from the [Debug] menu to exit the sort function, or click the [Step Out] button on the toolbar.



Figure 7.23 Step Out Button




Figure 7.24 Source Window (Step Out)

[Step Over]: Executes a function call in a single step, and stops at the next statement in the main program.

Select [Step Over] from the [Debug] menu or click the [Step Over] button on the toolbar to step over the statements in the printf function.



Figure 7.25 Step Over Button




Figure 7.26 Source Window (Step Over)

When the printf function has been executed, *** Sorting results *** will be displayed in the [Simulated I/O] window.


7.3.8 Checking Profile Information

The profile information can be checked in the [Profile] window.

- Clicking the [Go] button and continuing execution from the current PC executes the SLEEP instruction and then stops.

[List] Sheet: Displays the profile information as a list.

- Open the [Profile] window by selecting [Profile] from the [View->Performance] menu. The [List] sheet will be displayed.



Function/Variable	F/V	Address	Size	Times	Cycle	Ext mem	I/O area	Int mem
\$MUL\$3	F	0E68	H'00000000	10	730	0	0	50
__fmtout	F	0E80	H'000008c2	22	78593	771	0	3577
1742	F	1742	H'00000000	40	48080	0	0	2488
19D6	F	19D6	H'00000000	102	40790	143	0	2203
1A46	F	1A46	H'00000000	22	968	0	0	88
1A5C	F	1A5C	H'00000000	124	7192	0	0	496
__fclose	F	1A76	H'000000A2	6	1107	0	0	69
__flopen	F	1B18	H'00000128	3	1656	15	0	51
__fputc	F	1C40	H'000000D6	255	73159	0	0	3824
\$DIVUL\$3	F	1D16	H'00000000	230	27140	0	0	690
__flshbuf	F	1D52	H'000000F0	255	123582	0	0	8408
__strlen	F	1EE6	H'00000014	40	4840	0	0	192
__alocbuf	F	1F78	H'0000008C	1	192	0	0	13


Figure 7.27 Profile Window (List Sheet)

In the above figure, it can be found that the `__fclose` function was called six times, the execution cycle was 1107, and the internal memory was accessed 69 times.

It is possible to search for the critical path, such as a function that is called or accesses the memory many times, for the program performance.

[Tree] Sheet: Displays the profile information as a tree diagram.

- Select the [Tree] sheet. Double-clicking the function name in the [Profile] window expands or minimizes the tree structure.



The screenshot shows the 'Profile' window with the 'Tree' sheet selected. The window title is 'Profile'. Below the title bar is a toolbar with icons for 'Enable', 'Show Functions/Variables', and 'Data'. The main area displays a tree structure of functions. The tree is expanded to show the following functions and their statistics:

Function	Address	Size	Stack Size	Times	Cycle	Ext mem	I/O area	Int mem
PowerON_Reset	0400	H'0000001C	H'00000000	1	56	1	0	4
__INIT_SCT	0CCA	H'00000000	H'00000000	1	20515	9	0	1133
main	0ACC	H'000000E0	H'00000000	1	2890	0	0	134
CLOSEALL	0A4E	H'00000048	H'00000000	1	407	4	0	9
fclose	0D4E	H'00000034	H'00000000	3	243	0	0	9
__fclose	1A76	H'000000A2	H'00000000	3	762	0	0	48
__INIT_IOLIB	0976	H'000000D8	H'00000000	1	749	4	0	31
freopen	0D82	H'0000005A	H'00000000	3	525	0	0	36

The bottom of the window has a tab bar with 'List' and 'Tree' tabs. The 'Tree' tab is currently selected.

Figure 7.28 Profile Window (Tree Sheet)

In above figure, it can be found that the `__fclose` function was called three times from the `_fclose` function, the execution cycle was 762, and the internal memory was accessed 48 times.

[Profile-Chart] Window: Displays the relation of calls for a specific function.

- Select the `__fclose` function on the [Profile] window. Open the pop-up menu by right clicking the mouse on the [Profile] window, and select [View Profile-Chart] to display the [Profile-Chart] window.




Figure 7.29 Profile-Chart Window

In the above figure, it can be found that the `__fclose` function was called three times from the `_fclose` and `_freopen` functions, and the `_close` function was called three times.

This is the end of the tutorial using the simulator/debugger.

Renesas Microcomputer Development Environment System User's Manual H8S, H8/300 Series Simulator/Debugger

Publication Date: Rev.4.00, July 25, 2007
Published by: Sales Strategic Planning Div.
Renesas Technology Corp.
Edited by: Customer Support Department
Global Strategic Communication Div.
Renesas Solutions Corp.

Renesas Technology Corp. Sales Strategic Planning Div. Nippon Bldg., 2-6-2, Ohte-machi, Chiyoda-ku, Tokyo 100-0004, Japan



RENESAS SALES OFFICES

<http://www.renesas.com>

Refer to "<http://www.renesas.com/en/network>" for the latest and detailed information.

Renesas Technology America, Inc.

450 Holger Way, San Jose, CA 95134-1368, U.S.A
Tel: <1> (408) 382-7500, Fax: <1> (408) 382-7501

Renesas Technology Europe Limited

Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K.
Tel: <44> (1628) 585-100, Fax: <44> (1628) 585-900

Renesas Technology (Shanghai) Co., Ltd.

Unit 204, 205, AZIACenter, No.1233 Lujiazui Ring Rd, Pudong District, Shanghai, China 200120
Tel: <86> (21) 5877-1818, Fax: <86> (21) 6887-7898

Renesas Technology Hong Kong Ltd.

7th Floor, North Tower, World Finance Centre, Harbour City, 1 Canton Road, Tsimshatsui, Kowloon, Hong Kong
Tel: <852> 2265-6688, Fax: <852> 2730-6071

Renesas Technology Taiwan Co., Ltd.

10th Floor, No.99, Fushing North Road, Taipei, Taiwan
Tel: <886> (2) 2715-2888, Fax: <886> (2) 2713-2999

Renesas Technology Singapore Pte. Ltd.

1 Harbour Front Avenue, #06-10, Keppel Bay Tower, Singapore 098632
Tel: <65> 6213-0200, Fax: <65> 6278-8001

Renesas Technology Korea Co., Ltd.

Kukje Center Bldg. 18th Fl., 191, 2-ka, Hangang-ro, Yongsan-ku, Seoul 140-702, Korea
Tel: <82> (2) 796-3115, Fax: <82> (2) 796-2145

Renesas Technology Malaysia Sdn. Bhd

Unit 906, Block B, Menara Amcorp, Amcorp Trade Centre, No.18, Jalan Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia
Tel: <603> 7955-9390, Fax: <603> 7955-9510

H8S, H8/300 Series Simulator/Debugger User's Manual



Renesas Electronics Corporation

1753, Shimonumabe, Nakahara-ku, Kawasaki-shi, Kanagawa 211-8668 Japan

REJ10B0211-0400