


Bulletin 193 EtherNet/IP Communication Auxiliary

Catalog Numbers 193-DNENCAT, 193-DNENCATR



Important User Information

Read this document and the documents listed in the additional resources section about installation, configuration, and operation of this equipment before you install, configure, operate, or maintain this product. Users are required to familiarize themselves with installation and wiring instructions in addition to requirements of all applicable codes, laws, and standards.

Activities including installation, adjustments, putting into service, use, assembly, disassembly, and maintenance are required to be carried out by suitably trained personnel in accordance with applicable code of practice.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.



WARNING: Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.



ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence.

IMPORTANT

Identifies information that is critical for successful application and understanding of the product.

Labels may also be on or inside the equipment to provide specific precautions.



SHOCK HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.



BURN HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.



ARC FLASH HAZARD: Labels may be on or inside the equipment, for example, a motor control center, to alert people to potential Arc Flash. Arc Flash will cause severe injury or death. Wear proper Personal Protective Equipment (PPE). Follow ALL Regulatory requirements for safe work practices and for Personal Protective Equipment (PPE).

	Important User Information	2
	Summary of Changes	7
	Who Should Use This Manual?	9
	Additional Resources	9
	 Chapter 1	
Installation and Wiring	Introduction	11
	Overview	11
	Features	13
	Installation	13
	Wiring	14
	Dimensions	15
	Network Design	16
	 Chapter 2	
Configure the EtherNet/IP Communication Auxiliary Module	Introduction	19
	Determining Network Parameters	19
	Setting the IP Network Address	20
	EtherNet/IP Node Address Selection Switches	20
	Assign Network Parameters via the BOOTP/DHCP Utility	21
	Assign Network Parameters Via a Web Browser & MAC Scanner Software	23
	Other Factors to Consider When Assigning Network Parameters	25
	Duplicate IP Address Detection	26
	Behavior of Modules With Duplicate IP Addresses	26
	DNS Addressing	27
	Electronic Data Sheet (EDS) File Installation	27
	Download the EDS File	27
	Register the EDS File	29
	Web Server	32
	Permanently Enabling the Web Server	33
	 Chapter 3	
Configure the DeviceNet Network	Introduction	35
	Configuration	35
	 Chapter 4	
Add Devices to the DeviceNet Network	Introduction	39
	DeviceNet Node Addressing	39
	Node Address Basics	40
	Set the Node Address	40
	Using the Hardware Mechanism	40
	Using the DeviceNet Node Commissioning Tool	41

	Add DeviceNet Modules to the Scan List.....	44
	Simple.....	45
	User-Defined	46
	Chapter 5	
View and Configure Parameters	Introduction.....	49
	View and Edit.....	49
	Chapter 6	
Automatic Device Recovery or Replace	Introduction.....	53
	Configuring Automatic Device Recovery or Replace	53
	Chapter 7	
Automation Controller Communication	Introduction.....	57
	EtherNet/IP Messaging.....	57
	I/O Messaging	57
	ControlLogix Configuration with Add-on Profiles.....	57
	EtherNet/IP Network Configuration with Add-on Profiles ...	59
	Accessing Module Data with Add-on Profiles.....	62
	ControlLogix Generic Configuration	63
	EtherNet/IP Generic Module Configuration	64
	Accessing Generic Module Data	68
	Logic Explicit Messaging.....	70
	Chapter 8	
Email/Text	Introduction.....	75
	Email Notifications.....	75
	Events	75
	Email Contents	75
	Email Configuration.....	76
	Configure Device Identity.....	77
	Text Notifications.....	78
	Limitations	79
	Chapter 9	
Device Parameters	Introduction.....	81
	Parameter Programming.....	81
	Parameter Listing.....	81
	Chapter 10	
Troubleshooting	Introduction.....	85
	Modes of Operation.....	85
	Power-Up Reset Mode.....	86
	Run Mode	87

	Recoverable Error Mode	88
	Unrecoverable Error Mode.....	88
	Troubleshooting Procedures	88
	Appendix A	
Specifications	Specifications	91
	Appendix B	
EtherNet/IP and DeviceNet Information	Electronic Data Sheet (EDS) Files	93
	Common Industrial Protocol (CIP) Objects.....	93
	Identity Object — CLASS CODE 0x01.....	93
	Message Router Object — CLASS CODE 0x02	94
	DeviceNet Object — CLASS CODE 0x03	94
	Assembly Object — CLASS CODE 0x04	95
	Connection Manager Object — CLASS CODE 0x06	102
	Parameter Object — CLASS CODE 0x0F.....	102
	Device Level Ring (DLR) Object — CLASS CODE 0x47 ...	103
	QoS Object — CLASS CODE 0x48.....	104
	Port Object — CLASS CODE 0x0F4.....	105
	TCP/IP Interface Object — CLASS CODE 0xF5	105
	Ethernet Link Object — CLASS CODE 0xF6.....	106
	Index	109

Notes:

This manual contains new and updated information as indicated in the following table.

Topic	Page
Removed Administrative Mode description	Chapter 2
Removed "Accessing and Enabling Use of Embedded Web Page"	Chapter 2
Removed "Automatically Configure the Scan List "	Chapter 4
Removes "Setting ADR in RSLogix"	Chapter 6
Removed "Setting IP Address Via Embedded Web Page"	Chapter 7
Removed "Non-Volatile Storage Object — CLASS CODE 0xA1"	Appendix B

Notes:

This manual is a reference guide for the EtherNet/IP™ Communication Auxiliary Module. It describes the procedures that you use to install, wire, configure, and troubleshoot your module.

Who Should Use This Manual?

This manual is intended for qualified personnel with a basic understanding of full-voltage motor starters, electric power, and network communication principles.

Additional Resources

These documents contain additional information concerning related products from Rockwell Automation.

Resource	Description
E3™ and E3 Plus™ Overload Relay Specifications, publication 193-TD012	Provides specifications for compatible overload relays.
E3 Plus EtherNet/IP™ adapter installation instructions, publication 2100-IN090	Provides installation instructions for overload relay adapter.
E3 and E3 Plus Solid-State Overload Relay User Manual, publication 193-UM002	Provides user data for compatible overload relays.
Industrial Automation Wiring and Grounding Guidelines, publication 1770-4.1	Provides general guidelines for installing a Rockwell Automation industrial system.
Product Certifications website, http://www.rockwellautomation.com/global/certification/overview.page	Provides declarations of conformity, certificates, and other certification details.

You can view or download publications at <http://www.rockwellautomation.com/global/literature-library/overview.page>. To order paper copies of technical documentation, contact your local Allen-Bradley distributor or Rockwell Automation sales representative.

Notes:

Installation and Wiring

Introduction

This chapter tells you how to successfully install the Bulletin 193 EtherNet/IP™ Communication Auxiliary Module and properly connect it to an EtherNet/IP and DeviceNet™ network.

Overview

The Bulletin 193 EtherNet/IP Communication Auxiliary Module is an EtherNet/IP to DeviceNet linking device. It provides a means for devices that primarily communicate on a DeviceNet network (for example, a Bulletin 193 or 592 E3 Plus™ Overload Relay or a Bulletin 825-P Electronic Overload Relay) to communicate to EtherNet/IP-based scanners. The EtherNet/IP Communication Auxiliary Module allows up to six DeviceNet-based devices to be scanned via Implicit Messaging and can bridge Explicit Messaging for all nodes on a DeviceNet network. The EtherNet/IP Communication Auxiliary Module uses an internal web server to configure the module, the DeviceNet network, and DeviceNet-based devices that fully support the Parameter Object.



SHOCK HAZARD: To prevent electrical shock, disconnect the EtherNet/IP Communication Auxiliary Module from its power source **before** installing or servicing. Install in suitable enclosure. Keep free from contaminants.



ATTENTION: The EtherNet/IP Communication Auxiliary Module contains ESD (electrostatic discharge) sensitive parts and assemblies. Static control precautions are required when you install, test, service, or repair the EtherNet/IP Communication Auxiliary Module. Component damage can result if you do not follow ESD control procedures. If you are not familiar with static control procedures, See Rockwell Automation publication 8000-4.5.2, “Guarding Against Electrostatic Damage”, or any other applicable ESD protection handbook.



ATTENTION: The purpose of this document is to serve as a guide for proper installation. The National Electrical Code (NEC) and any other governing regional or local code take precedence. Rockwell Automation cannot assume responsibility for the compliance or proper installation of the EtherNet/IP Communication Auxiliary Module or associated equipment. A hazard of personal injury and/or equipment damage exists if codes are ignored during installation.



ATTENTION: An incorrectly applied or installed EtherNet/IP Communication Auxiliary Module can result in damage to the components or reduction in product life. Wiring or application errors (for example, supplying incorrect or inadequate supply voltage or operating/storing in excessive ambient temperatures) can result in malfunction of the product.



ATTENTION: Only personnel familiar with the EtherNet/IP Communication Auxiliary Module and associated machinery should plan to install, set up, and maintain the system. Failure to comply may result in personal injury and/or equipment damage.




ATTENTION: This is a Class A product. In a domestic environment, this product can cause radio interference, in which case you may be required to take adequate measures.



ATTENTION: To remain compliant with UL/CSA Certifications, the DeviceNet power supply **must** meet NEC Class 2 Requirements.

Features


Figure 1 - Features



Installation

The EtherNet/IP Communication Auxiliary Module may be DIN Rail or panel mounted. To avoid overheating, the unit **must** be mounted vertically and requires 37.4 mm (1-1/2 in.) of clearance at the top and bottom to allow proper air flow. The temperature ratings for the unit are derated if the device is not mounted in this manner.

Figure 2 - Installation



Wiring

The EtherNet/IP Communication Auxiliary Module can accept all forms of DeviceNet cable. However, DeviceNet shielded cable is recommended. The module complies with the Open Device Vendors Association (ODVA) DeviceNet compliance testing when the distance between end nodes is 100 m or less with 60 or fewer network drops.

Table 1 - Wire and Torque Specifications





Wire		Torque
	1X 2X	24...12 AWG 24...16 AWG 5 lb.-in.
	1X 2X	0.2...2.5 mm ² 0.25...1 mm ² 0.56 N·m
	1X 2X	0.2...2.5 mm ² 0.2...1 mm ² 0.56 N·m

Figure 3 - Wiring Diagram




ATTENTION: Use a shielded DeviceNet cable to comply with CISPR 22 and CISPR 24.

Dimensions

Figure 4 - Dimension Diagram

Dimensions are shown in millimeters (inches).




Network Design

The EtherNet/IP Communication Auxiliary Module is available as a single Ethernet port (Cat. No. 193-DNENCAT) and dual Ethernet port (Cat. No. 193-DNENCATR) module that has RJ45 ports to connect to Ethernet cable CAT5 type or better. Rockwell Automation offers a wide variety of Allen-Bradley Ethernet patch cables with its Bulletin 1585 line of Ethernet cables (<http://ab.rockwellautomation.com/Connection-Devices/RJ45-Network-Media>).

Both the 193-DNENCAT and 193-DNENCATR devices support a Star Ethernet topology in which all Ethernet nodes wire back to a central Ethernet switch, hub, or router as shown in [Figure 5](#).


Figure 5 - Star Ethernet Topology



Rockwell Automation also offers a line of managed and unmanaged Allen-Bradley Ethernet Switches with its Stratix™ family of Ethernet switches. See <http://ab.rockwellautomation.com/Networks-and-Communications/Ethernet-IP-Network> for more information.

The Cat. No. 193-DNENCATR Module also supports a Ring Ethernet topology in which all Ethernet nodes are wired in series with one another until a complete network ring is made as shown in [Figure 6 on page 17](#).

Figure 6 - Ring Ethernet Topology



The Cat. No. 193-DNENCATR Module supports the Rockwell Automation Device Level Ring (DLR) topology as a slave device in which the EtherNet/IP network still continues to communicate if one of the network chains is disrupted.

Notes:

Configure the EtherNet/IP Communication Auxiliary Module

Introduction

This chapter describes how to configure an EtherNet/IP communication auxiliary module to operate on an EtherNet/IP network.

When you first install an EtherNet/IP communication auxiliary module, the module is Dynamic Host Configuration Protocol (DHCP) enabled.

Determining Network Parameters

To operate an EtherNet/IP network, you must define these parameters.

Table 2 - EtherNet/IP Network Parameters

Network Parameter	Description
IP Address	The IP address uniquely identifies the module. The IP address is in the form xxx.xxx.xxx.xxx where each xxx is a number from 0...255. Do not use the following IP addresses, because these are reserved values: <ul style="list-style-type: none"> • 0.0.0.1...0.255.255.255 • 127.0.0.0...127.255.255.255 • 224.255.255.255...255.255.255.255
Subnet Mask	Subnet addressing is an extension of the IP address scheme that allows a site to use a single network ID for multiple physical networks. Routing outside of the site continues by dividing the IP address into a net ID and a host ID via the class. Inside a site, the subnet mask is used to redivide the IP address into a custom network ID portion and host ID portion. NOTE: If you change the subnet mask of an already-configured module, you must cycle power to the module for the change to take effect.
Gateway	A gateway connects individual physical networks into a system of networks. When a node needs to communicate with a node on another network, a gateway transfers the data between the two networks.

If DNS addressing is used or if the module is referenced via a host name in an MSG instruction, you must define the following parameters. Consult with your Ethernet network administrator to determine whether these parameters need to be specified.

Table 3 - EtherNet/IP Network Parameters for DNS Addressing

Network Parameter	Description
Host Name	A host name is part of a text address that identifies the module. The full text address of a module is: <i>host_name.domain_name</i> .
Domain Name	A domain name is part of a text address that identifies the domain in which the module resides. The full text address of a module is: <i>host_name.domain_name</i> . The domain name has a 48-character limit.
Primary DNS Server Address	This identifies any DNS servers used in the network. You must have a DNS server configured if you specify an SMTP server with a name. The DNS server converts the domain name or host name to an IP address that can be used by the network. For more information on DNS addressing, See page 27 .
Secondary DNS Server Address	

Setting the IP Network Address

An EtherNet/IP communication auxiliary module ships with DHCP enabled. You can set the network Internet Protocol (IP) address by using the following:


- EtherNet/IP node address selection switches
- Bootstrap Protocol (BOOTP)/Dynamic Host Configuration Protocol (DHCP) server

For example, use the Rockwell Automation BOOTP-DHCP Server Utility, which is included with Rockwell Software's RSLinx™ Classic software.

- Web browser and MAC scanner software

EtherNet/IP Node Address Selection Switches

The EtherNet/IP communication auxiliary module comes with three node address selection switches that allow you to select the last octet for the IP address 192.168.1.*xxx*.

Figure 7 - Last Octet Selection

EXAMPLE When the top dial is set to **1**, the middle dial is set to **2**, and the bottom dial is set to **3**, the resulting IP address is: **192.168.1.123**.

When the node address selection switches are set to a value greater than 255, the IP address is set to DHCP Enabled or programmed for a static IP address.

Assign Network Parameters via the BOOTP/DHCP Utility

By default, the EtherNet/IP communication auxiliary module is DHCP Enabled. The BOOTP/DHCP utility is a standalone program that is located in the BOOTP-DHCP Server folder accessed from the Start menu.


IMPORTANT **Before starting the BOOTP/DHCP utility:** Make sure you have the hardware MAC ID of the module, which is printed on the front of the EtherNet/IP communication auxiliary module. The MAC ID has a format similar to: 00-0b-db-14-55-35.

This utility recognizes DHCP-enabled devices and provides an interface to configure a static IP address for each device.

To assign network parameters via the BOOTP/DHCP utility, perform this procedure:

1. Execute the BOOTP/DHCP software.
2. Choose Tool >Network Settings.


3. If appropriate for the network, type the subnet mask, gateway address, primary/secondary server addresses, and domain name in their respective fields.



4. Click OK.

The Request History panel displays the hardware addresses of modules issuing BOOTP or DHCP requests.

5. Double-click the MAC address of the module to be configured. The MAC address is printed on the front of the EtherNet/IP communication auxiliary module. The format of the hardware address resembles: 00-0b-db-14-55-35



The New Entry window appears with the module's media access control address (MAC).

The image shows a 'New Entry' dialog box with the following fields and values:

- Ethernet Address (MAC):** 00:00:BC:C1:90:52
- IP Address:** 192 . 168 . 1 . 100
- Hostname:** (empty)
- Description:** (empty)

Buttons: OK, Cancel

6. Type the IP address, host name, and a module description.
7. Click OK.
8. Cycle power to the module by removing and reapplying the DeviceNet connector.
9. To permanently assign this configuration to the module: Select the module in the Relation List panel and click Disable BOOTP/DHCP.

When module power is cycled, it uses the assigned configuration and does not issue a DHCP request.


If you do not click Disable BOOTP/DHCP, on a power cycle, the module clears the current IP configuration and again begins sending DHCP requests.

Assign Network Parameters Via a Web Browser & MAC Scanner Software


If you do not have access to a DHCP software utility, you can assign network parameters via a web browser (for example, Microsoft® Internet Explorer) and Media Access Control (MAC) scanner software (for example, MAC Scanner from Colasoft® - <http://www.colasoft.com/>). Follow these steps to configure the module using this method.

1. Locate and identify the MAC ID printed on the label of the EtherNet/IP communication auxiliary module. This address has a format that is similar to: 00-0b-db-14-55-35
2. Connect the EtherNet/IP communication auxiliary module to the same wide area network (WAN) as your personal computer.
3. Initiate the MAC scanner software.

4. Select the appropriate subnet to scan for available MAC addresses.




5. Scan the Subnet for all available MAC addresses.



6. Identify the IP address assigned to the MAC ID of the EtherNet/IP communication auxiliary module. The IP address has a format that is similar to 192.168.1.100.
7. Enable the EtherNet/IP Communication Auxiliary Web Server (page 33). Using a web browser, type the IP address on the address line. This allows you to view the internal web server of the module.
8. Select Administration Settings>Network Configuration to change the IP address of the EtherNet/IP communication auxiliary module to a static IP address.
9. The module prompts you for a User Name and Password. Type “Administrator” as the user name, leave the password field blank, then click “OK.”



10. Assign the appropriate network settings per the recommendation of the network administrator for the network that this module communicates on and click Apply.



11. Remove and reapply the DeviceNet connector to allow the communications changes to take effect.

Other Factors to Consider When Assigning Network Parameters

There are other factors to consider when assigning network parameters, which include the:

- network isolation from or integration into the plant/enterprise network.
- network size.
For large networks, even isolated networks, it might be more convenient and safe to use a BOOTP/DHCP server rather than RSLinx software. The BOOTP/DHCP server also limits the possibility of assigning duplicate IP addresses.
- company policies and procedures associated with plant floor network installation and maintenance.
- level of involvement by information technology personnel in plant floor network installation and maintenance.
- type of training offered to control engineers and maintenance personnel.

If the Rockwell Automation BOOTP or DHCP server is used in an uplinked subnet where an enterprise DHCP server exists, a module may get an address from the enterprise server before the Rockwell Automation utility even sees the

module. In this case, disconnect the uplink to set the address and configure the module to retain its static address **before** reconnecting to the uplink. This is not a problem if you have node names configured in the module and leave DHCP enabled.



ATTENTION: The EtherNet/IP Communication Auxiliary module must be assigned a fixed network address. The IP address of this module **must not** be dynamically provided. Failure to observe this precaution may result in unintended machine motion or loss of process control.

Duplicate IP Address Detection

When you change the IP address or connect the module to an EtherNet/IP network, the module checks to make sure that the IP address assigned to this module does not match the address of any other network device. If the module determines that another device on the network with a matching IP address, the EtherNet/IP port of the module goes into conflict mode where the Network Status LED indicator is solid red.

To resolve this conflict, use the instructions below to change the IP address of the module. Then, cycle power to the module or reset the modules by disconnecting and then reconnecting the Ethernet cable.

Two modules could possibly detect a conflict simultaneously. If this occurs, perform this procedure.

1. Remove the module with the incorrect IP address and correct its conflict.
2. Cycle power or disconnect the Ethernet cable from the second module and reconnect it.

Behavior of Modules With Duplicate IP Addresses

Devices in conflict over an IP address behave differently depending on whether connections have been established to either of the modules and whether both modules support duplicate IP address detection.

Table 4 - Device Conflict over Duplicate IP Addresses

If	then
Both modules support duplicate IP address detection,	The first started module uses and retains its IP address. The other module detects a conflict, gives up the IP address, and enters conflict mode.
Both modules support duplicate IP address detection and are started at roughly the same time,	One of the modules surrenders the IP address and enters conflict mode.
One module supports duplicate IP address detection and a second module does not,	The second module generally keeps its IP address, regardless of which module first obtains the IP address. The module that supports duplicate IP address detection detects the conflict and gives up the IP address.

DNS Addressing

To further qualify a module's address, use DNS addressing to specify a host name for a module. This also includes specifying a domain name and DNS servers. DNS addressing makes it possible to set up similar network structures and IP address sequences under different domains.

DNS addressing is only necessary if you refer to the module by host name, such as in path descriptions in MSG instructions.

To use DNS addressing, perform this procedure.

1. Assign a host name to the module.

NOTE: Contact the network administrator to have a host name assigned. Valid host names should comply with IEC-1131-3.

2. Configure the module's parameters.
3. In addition to the IP address, subnet mask, and gateway address, configure a host name for the module, domain name, and primary/secondary DNS server addresses.

Electronic Data Sheet (EDS) File Installation

Before the EtherNet/IP communication auxiliary module is configured to communicate on an EtherNet/IP network, it must be registered to the software that configures the network (for example, Rockwell Automation RSLinx Classic and RSNetWorx for EtherNet/IP software). You register the module by installing an EDS file. You can obtain the EDS file for the EtherNet/IP communication auxiliary module from one of two locations:

- embedded in the module **OR**
- the Allen-Bradley EDS file download website.


Download the EDS File

Embedded in the Module


The EDS file for the EtherNet/IP communication auxiliary module is embedded within the module. After the IP address for the module has been configured, connect the module to same Ethernet network as a personal computer. Using a web browser on the personal computer, you can download the EDS file using a web browser by following these steps:

TIP When using Firmware revision 3.000 and higher, see [page 33](#) for instructions on how to commission the EtherNet/IP communication auxiliary module and enable use of the embedded web page.

1. Type the IP address of the EtherNet/IP communication auxiliary module on the address line of the web browser.



2. Select EDS File link
3. Click Save to save the EDS file to the personal computer.




From the EDS File Download Site

The EDS file for the EtherNet/IP communication auxiliary module can also be downloaded from the Allen-Bradley EDS File download site. Using a web browser on the personal computer that is connected to the internet, you can download the EDS file by following these steps:

1. Type <http://www.ab.com/networks/eds> on the address line of the web browser.

2. Select EtherNet/IP as the network type, then click Search.



3. Locate the EDS file for the EtherNet/IP communication auxiliary module and download it to the personal computer.


Register the EDS File

After the EDS file has been downloaded, you need to register the EDS file with the software that configures the EtherNet/IP network. The following example lists the steps needed to register an EDS file with Rockwell Automation's RSLinx Classic software.

1. Start the EDS Hardware Installation Tool located at Start>Programs>Rockwell Software>RSLinx Tools.




2. Click Add to register a new device.




3. Click the “Register a single file” radio button, then browse to the location where the EDS file is located. Click Next.



- Click Next to accept the installation test results.




- Click Next to accept the graphic image.



6. Click Next to register the device.



7. Click Finish to successfully register the module.



Web Server

Use the embedded web server of the EtherNet/IP communication auxiliary module to configure the DeviceNet scanner and view diagnostic information of the EtherNet/IP communication auxiliary module. As a security precaution the embedded web server of the EtherNet/IP Communication Auxiliary is disabled by default. To temporarily enable the web server, you must enter into Administration Mode. To do this, set the rotary dials located on the front of the EtherNet/IP communication auxiliary module to 000 and cycle power. The device will then go online with the IP address used at the time of the previous startup.


After you have made all configuration changes, exit Administration Mode and return to Operation Mode by setting the rotary dials located on the front of the

EtherNet/IP communication auxiliary module back to their original position and cycle power. The EtherNet/IP Communication Auxiliary Web Server will be disabled unless it was permanently enabled.


Permanently Enabling the Web Server

In Administrative Mode, you can change any configuration parameter of the EtherNet/IP communication auxiliary module, including permanently enabling the embedded web server by following these steps:

1. Enter Administrative Mode by turning the rotary dials to 000 and cycle power on the EtherNet/IP communication auxiliary module
2. Access the web page
3. Navigate to Administrative Settings->Network Configuration
4. You will be prompted for a user name and password. The default user name is Administrator, and the default password is <blank>. Enter “Administrator” as the user name, and leave the “password” field blank as shown in the following picture.



5. Enable the Web Server Control and press “Apply Changes”.



Notes:

Configure the DeviceNet Network

Introduction


This chapter helps you to configure the DeviceNet Network by using the EtherNet/IP communication auxiliary module. You can configure a DeviceNet network by using the internal web interface from the EtherNet/IP communication auxiliary module.

Configuration

1. Enable the EtherNet/IP Communication Auxiliary Web Server ([page 33](#)). Using a web browser, navigate to the menu on the left and choose Scan List>Configuration>Advanced.



2. If desired, change the baud rate using the DeviceNet Baud Rate pull-down menu. The default value of 125K for the DeviceNet network.



NOTE: Autobaud is not supported with this product.

3. Type the size of the Scan List I/O Entry in the field.

The entry size determines the number of input and output bytes that the EtherNet/IP communication auxiliary module scans from each of the scanned devices. The maximum Scan List I/O Entry Size supported is 50 bytes; the default value is 8 bytes.




NOTE: Auto Device Replacement (ADR) is discussed in [Chapter 6, Automatic Device Recovery or Replace](#).

4. If necessary, adjust DNet IO Request Packet Interval (RPI) and DNet IO Inhibit.

DNet IO RPI determines the time it takes for data to be requested; DNet IO Inhibit is the time used on DeviceNet Change of State (COS) I/O. Both of these parameters are measured in milliseconds.


NOTE: Electronic keying is implemented on all scan list entries. Electronic keys are captured when a scan list is configured from the EtherNet/IP communication auxiliary module web page. The proper setting of the electronic keying becomes more important with ADR functions and replacing units in the network.

5. Select the “Scan List” tab from the configuration menu to change the DeviceNet node address of the EtherNet/IP communication auxiliary module.




6. Change the DeviceNet network address to the appropriate node address, then click Save.

NOTE: Typically, DeviceNet scanners have the node address of 0.



7. Click OK to finish changing the scanner DeviceNet network address.



Notes:

Add Devices to the DeviceNet Network

Introduction

This chapter describes how to assign an address to each DeviceNet module and configure the DeviceNet scanner to scan up to six modules.

DeviceNet Node Addressing

Each module that you add to the DeviceNet network must have a unique network node address. You can create a unique network node address by using hardware devices (for example, DIP and Selector Switches) or with the Node Commissioning tool from the internal web interface of the EtherNet/IP communication auxiliary module.

[Table 5](#) shows the recommended node addresses.

Table 5 - Recommended Node Addresses

Device:	Node Address:	Notes:
Scanner	0	<ul style="list-style-type: none"> For multiple scanners, assign the lowest addresses in sequence (0, 1...).
Any Device on the Network (except the scanner)	1...61	<ul style="list-style-type: none"> Give the lower addresses to devices with 15 bytes or more of input or output data. Gaps between addresses are acceptable and have no effect on system performance. If the final layout of the system is not certain, leave gaps between addresses to allow flexibility as the system is developed.
Computer Interface to the Network	62	<ul style="list-style-type: none"> If a computer is connected directly to the DeviceNet network, use address 62 for the computer. The reason for this is that many computer interface devices use 63 as the default address. The 1784-U2DN device can connect a computer directly to a DeviceNet network.
New DeviceNet Module	63	<ul style="list-style-type: none"> To avoid conflict, always leave address 63 open. This is due to the following: <ul style="list-style-type: none"> most DeviceNet devices have a factory preset address of 63. leaving address 63 open allows for configuration of a new device. the auto-address recovery feature requires address 63 to be open. Some devices do not have switches or push buttons to set the address. Therefore, the device must first be connected to the network then software (for example, RSNetworkx for DeviceNet) must be used to change the address. If another device is already using address 63, an address conflict occurs and communication with the newly connected device does not occur.

Node Address Basics

- Verify the node address assigned to the new device.
- Prevent duplicate node address assignments.
 - When connecting new DeviceNet modules with the Node Commissioning tool from the EtherNet/IP communication auxiliary module web interface, place one new DeviceNet module on the network at a time. See “New DeviceNet Module” in [Table 5 on page 39](#).
 - If DIP or selector switches on hardware are used, set the network node address for the device **before** connecting it to the network.
- Leave node address 63 open.

For more information about setting the node address for DeviceNet devices, See the Rockwell Automation Literature Library at: <http://www.rockwellautomation.com/global/literature-library/overview.page>

Set the Node Address

Using the Hardware Mechanism



Many DeviceNet devices feature a hardware mechanism to set the network node address (for example, a rotary switch or a push wheel switch). Use the following procedure to set the node address.

IMPORTANT Ensure that the node address of each device set by the hardware mechanism matches the node address used in the DeviceNet network. If the network node address is set higher than 63, you can use the Ethernet/IP Communication Auxiliary Node Commissioning tool instead of the hardware mechanism.

IMPORTANT For the node address change to take effect, cycle the power to the module.

1. Using [Table 5 on page 39](#) as a guide, select a node address to apply to the new device.

2. Change the node address using the appropriate mechanism for the new device.

Mechanism	Procedure
Rotary Switch 	Turn the rotary switch dials to the desired node address value. Usually, a small, flathead screwdriver is needed to turn the dials. Once the device is powered up, the rotary switch settings are recognized. If the set node address value needs to be changed, power down the device, turn the dials to the desired setting, then power up the device again.
Push Wheel Switch 	Turn the push wheel to the desired node address value.

Using the DeviceNet Node Commissioning Tool

A device's network node address can be set using the Node Commissioning Tool on the EtherNet/IP communication auxiliary module web page. This tool uses the Network Who to view the DeviceNet modules on the network.

See the following guidelines when using the Network Commissioning tool.


- Only use this tool with an online DeviceNet network.
- Only use this tool when adding new devices to the network if:
 - the new device **does not** feature a hardware mechanism to set the node address **or**
 - the new device's node address is set higher than 63.

NOTE: If the new device features a hardware mechanism and the node address is set at 63 or lower, the Network Commissioning tool does not change the node address of the device.


- Each time a new device is added to the DeviceNet network, the procedures beginning on [page 42](#) **must** be performed.
- To avoid conflict with duplicate node addresses, due largely in part to modules having a factory node setting of 63, configure a module to the online DeviceNet network one at a time.
- Record the node address for each device that is set by the Node Commissioning Tool.

Complete the following steps to set a device's node address using the Node Commissioning Tool on the EtherNet/IP communication auxiliary module web page.


1. From the EtherNet/IP communication auxiliary module web page, navigate to Scan List>Configuration>Node Commissioning.



2. Select the device where node address needs to be assigned. Once you have selected the proper device, the software populates the Current Settings and New Settings areas.




3. Double-click the “Node address” field’s value. The software highlights the value in blue.




4. Use the number keypad on the computer keyboard to change the network node address to the desired value, then click Apply.

Make sure that the desired value does not duplicate the node address of any other device.




A confirmation window appears, confirming a successful node address value change.



5. Click OK.

6. In the 'New settings' section, verify that the node address was changed to the desired value.

Note that the 'Current settings' area still displays the old node address until you select the device again from the Network Who list. Verify the node address was changed to the desired value in the "New settings" section of the page. Note that the "Current settings" area still displays the old node address until you select the device again from the Network Who list.



7. Repeat steps 1 ... 6 until all new or additional devices are added to the Device Network.


Add DeviceNet Modules to the Scan List

After each DeviceNet device has been assigned a unique node address, you can add up to six DeviceNet devices to the EtherNet/IP communication auxiliary module DeviceNet scan list. The EtherNet/IP communication auxiliary module provides two methods to configure the scan list, Simple and User-Defined.


Simple

1. From the EtherNet/IP communication auxiliary module web page, navigate to Scan List>Configuration>Scan List.


The EtherNet/IP communication auxiliary module reads the available DeviceNet modules on the DeviceNet network.



2. Click Config. The lowest six DeviceNet node addresses populate into the Scan List field on the right.



3. Click OK to complete the configuration.



The DeviceNet scanner on the EtherNet/IP communication auxiliary module begins scanning the DeviceNet devices.

User-Defined

If there are more than six DeviceNet devices on the network, you can select up to six DeviceNet devices to scan. Follow the steps below to select specific DeviceNet devices for the scan list.

1. From the EtherNet/IP communication auxiliary module web page, navigate to Scan List>Configuration>Scan List. The EtherNet/IP communication auxiliary module reads the available DeviceNet modules on the DeviceNet network.
2. Select the DeviceNet device in the Network Who screen to be added to the Scan List. The >> button becomes highlighted.




3. Click >> to move the selected device into the Scan List.



4. Repeat steps 2 and 3 to add five additional DeviceNet devices.
5. Click Save at the bottom right of the screen.

6. Click OK to complete the scan list configuration.



Notes:

View and Configure Parameters

Introduction


This chapter tells you how to view and configure parameters for a DeviceNet device that supports the full implementation of the Parameter Object.

View and Edit


The EtherNet/IP communication auxiliary module can view and configure parameters for a DeviceNet device that supports the full implementation of the Parameter Object. You can use the web interface to view and edit parameters for a DeviceNet Module in the scan list.

Follow the listed steps to view and edit parameters by using the web interface of the EtherNet/IP communication auxiliary module.


1. Enable the EtherNet/IP Communication Auxiliary Web Server ([page 33](#)), navigate to Scan List>Configuration, and select the DeviceNet device folder to view or edit its parameters. The selected DeviceNet device folder expands.




2. Click the Identity folder. The Identity tab appears, providing information about the selected device.




3. Click the Parameter folder. Subfields for this folder appear.




- Select a parameter group. A list of up to 15 parameters is displayed. If more than 15 parameters are available, select the page number or use the navigation arrows to view the additional parameter screens.




TIP To increase the update rate of the data being displayed on the screen, lower the value in the “Seconds before refresh:” field.




- Select a parameter group that contains programmable parameters, then click the Edit button. The value options appear.



- Click the down arrow on the pull-down boxes to adjust fixed values and/or enter numerical values in the fields without an arrow to adjust the values.



- Click Apply once all parameter edits have been completed. The EtherNet/IP communication auxiliary module downloads the new parameter values to the device. A confirmation window appears.



- Click OK.
- Continue editing the remaining parameters, if desired.

If a DeviceNet module does not support the parameter object, the following window appears:

NOTE:



Automatic Device Recovery or Replace

Introduction


This chapter explains how to use the Automatic Device Recovery or Replace (ADR) feature. Using this feature reduces downtime if you need to replace a device.

With the ADR feature, you do not need software tools to get a replacement device configured and online. The EtherNet/IP communication auxiliary module automatically configures the replacement device if the device was listed in the scan list and the appropriate electronic keying was selected.

IMPORTANT Not all DeviceNet devices support Automatic Device Recovery or Replace.


Configuring Automatic Device Recovery or Replace

1. Navigate to Scan List>Configuration>Advanced.
2. Select the appropriate electronic keying for your DeviceNet network application.



By default, the Device Type, Vendor, and Product Code are enabled. Electronic keying defines how closely a replacement device must match a failed device before the EtherNet/IP Auxiliary reconfigures a module. If the new module does not match the criteria of one of the checked boxes, the ADR does not function and an ADR error appears.


3. Once the scan list and DeviceNet module programmable parameters have been configured, click Upload ADR Data.



The EtherNet/IP communication auxiliary module upload and stores the configuration data from the modules in the scan list and a confirmation message appears.

4. Select Enable from the Auto Device Replace pull-down menu. This enables the ADR.

- Click Save, then cycle power on the EtherNet/IP communication auxiliary module.



An ADR download is performed immediately before the DeviceNet master allocates an I/O connection. For an ADR download to occur, the PLC must be online and scanning. See [page 68](#) for instructions on going online with the controller.

If the download is unsuccessful, an “ADR Error” for the appropriate node is reported in the corresponding “Scan List Entry Status Word”. If the electronic keys for the device at a given node address do not match the saved electronic keys, no ADR download takes place, an I/O connection is not allocated, and a “Keying Mismatch” is reported in the corresponding “Scan List Entry Status Word”.

After you enable the ADR, a warning appears if you change the scan list.



The EtherNet/IP communication auxiliary module also supports Auto Address Recovery (AAR). When the EtherNet/IP communication auxiliary module detects that a node is missing from the scan list and a module matching

the electronic key is detected on node 63, the module attempts to change its network node address to that of the missing scan list node number. When successful, the EtherNet/IP communication auxiliary module downloads the ADR information to the module.

Automation Controller Communication

Introduction

This chapter describes and gives examples of how EtherNet/IP messaging, I/O messaging, and Explicit Messaging are used.

EtherNet/IP Messaging

The EtherNet/IP communication auxiliary module supports two types of EtherNet/IP messaging.

- I/O Messaging — Used for deterministic EtherNet/IP communications with ControlLogix™, CompactLogix™, SoftLogix™, and EtherNet/IP scanners. Its primary use is to read and write I/O data for control purposes.
- Logic Explicit Messaging — Used for non-deterministic communications in which the data is not critical for control. Logic explicit messages have a lower priority than I/O messages and are used to read and write non-critical data.

I/O Messaging

RS Logix 5000™ software is used to configure I/O messaging between an automation controller and an EtherNet/IP communication auxiliary module on an EtherNet/IP network.

The following example provides the steps necessary to configure a Logix controller for I/O messaging.


ControlLogix Configuration with Add-on Profiles

An Add-on Profile is available for the EtherNet/IP communication auxiliary module and can be used with RSLogix 5000 version 17 and higher. The profile can be downloaded from:


<http://support.rockwellautomation.com/controlflash/LogixProfiler.asp>

An existing project can be used or a new project can be created to configure EtherNet/IP I/O Messaging. To create a project, perform the following steps.


1. Select File>New from the RSLogix 5000.
2. Select the controller type, chassis type, slot number, and project path. Then, enter a name for the controller and click OK.




3. Right-click the I/O Configuration folder, then select New Module. The Select Module Type window appears.



- Select the desired EtherNet/IP scanner module, then click OK.




- Enter the desired communication settings, then click Finish.




EtherNet/IP Network Configuration with Add-on Profiles

After the controller configuration, the EtherNet/IP communication auxiliary module has to be added to the I/O configuration.


1. Place the program in offline mode.



2. Right-click the EtherNet/IP scanner within the I/O Configuration folder, then select New Module to open the Select Module Type window.



3. Select the appropriate device (either 193-DNENCAT or 193-DNENECATR, then click OK.



- Enter a name for the EtherNet/IP communication auxiliary module. The name creates tags in RSLogix 5000 that can be used to read and write data from DeviceNet modules being scanned by the EtherNet/IP communication auxiliary module.




- Enter the IP address of the EtherNet/IP communication auxiliary module.



- Select Change to select a motor protection device with predefined tag names for Data Mapping. For non-motor protection devices, select Generic.

Predefined tag names exist for the E3 Plus EC1, EC2, EC3, EC4, and EC-5 models and the 825-P Overload Relay.




- Select the appropriate data format, then click OK.

- Click OK at the next window to have RSLogix 5000 create the predefined tags. The EtherNet/IP communication auxiliary module now shows as a module in the I/O Configuration folder.

Accessing Module Data with Add-on Profiles

With both the Logix controller and EtherNet/IP network configured, the Logix controller can exchange data with the EtherNet/IP communication auxiliary module.

- Open the Controller Tags window.



- Select the Monitor Tags tab.


MotorStarter:I.EC5	{...}	{...}	
MotorStarter:I.EC5[0]	{...}	{...}	
MotorStarter:I.EC5[0].TripPresent	0		Decimal
MotorStarter:I.EC5[0].WarningPresent	0		Decimal
MotorStarter:I.EC5[0].OutputA	0		Decimal
MotorStarter:I.EC5[0].OutputB	0		Decimal
MotorStarter:I.EC5[0].Input1	0		Decimal
MotorStarter:I.EC5[0].Input2	0		Decimal
MotorStarter:I.EC5[0].Input3	0		Decimal
MotorStarter:I.EC5[0].Input4	0		Decimal
MotorStarter:I.EC5[0].MotorCurrentPresent	0		Decimal
MotorStarter:I.EC5[0].GroundFaultCurren...	0		Decimal
MotorStarter:I.EC5[0].Input5	0		Decimal
MotorStarter:I.EC5[0].Input6	0		Decimal
MotorStarter:I.EC5[0].MotorVoltagePresent	0		Decimal
+ MotorStarter:I.EC5[0].L1Current	0		Decimal
+ MotorStarter:I.EC5[0].L2Current	0		Decimal
+ MotorStarter:I.EC5[0].L3Current	0		Decimal
+ MotorStarter:I.EC5[1]	{...}	{...}	
+ MotorStarter:I.EC5[2]	{...}	{...}	
+ MotorStarter:I.EC5[3]	{...}	{...}	
+ MotorStarter:I.EC5[4]	{...}	{...}	
+ MotorStarter:I.EC5[5]	{...}	{...}	
+ MotorStarter:I.AdvancedDataEC5	{...}	{...}	
MotorStarter:O	{...}	{...}	
MotorStarter:O.EC5	{...}	{...}	
MotorStarter:O.EC5[0]	{...}	{...}	
MotorStarter:O.EC5[0].OutputAData	0		Decimal
MotorStarter:O.EC5[0].OutputBData	0		Decimal
MotorStarter:O.EC5[0].ResetTrip	0		Decimal
MotorStarter:O.EC5[0].RemoteTrip	0		Decimal

In the preceding example, the predefined input and output tags were generated for each of the six scanned devices. Use the output tags to control the output relays for the scanned device. Use the input tags for diagnostic information from the device.


ControlLogix Generic Configuration

An existing project can be used or a new project can be created to configure EtherNet/IP I/O Messaging. To create a new project, perform the following steps.


1. Select File>New from the RSLogix 5000.
2. Select the controller type, chassis type, slot number, and project path. Then, enter a name for the controller and click OK.




3. Right-click the I/O Configuration folder, then select New Module. The Select Module Type window appears.



4. Select the desired EtherNet/IP scanner module, then click OK.




5. Enter the desired communication settings, then click Finish.




EtherNet/IP Generic Module Configuration

Once the Logix controller has been configured, the EtherNet/IP communication auxiliary module must be added to the I/O configuration.


1. Place the program in offline mode.




2. Right-click the EtherNet/IP scanner within the I/O Configuration folder, then select New Module to open the Select Module Type window.




3. Select Generic Ethernet Module, then click OK.



- Enter a name for the EtherNet/IP communication auxiliary module. The name creates a tag in RSLogix 5000 that can be used to read and write data from the devices being scanned by the EtherNet/IP communication auxiliary module.




- Select Data-INT for the Comm Format. The Data-INT format represents the data from the EtherNet/IP communication auxiliary module as a field of 16-bit values.



- Set the Connection Parameters. I/O data is accessed using Input Instance 101 and Output Instance 100. The size of the input connection and the output connection shall correspond to the size of the chosen instance. The configuration Assembly Instance is 102.

NOTE: In this example, configuration data is not used. Thus, the data size is set to 0



With firmware revision 3.000 and later, I/O data can be accessed using Input Instance 104 and Output Instance 105. The size of the input connection and the output connection shall correspond to the chosen instance. When choosing Input Instance 104, set the data size to 88. If you are using Output Instance 105, set the data size to 26. Additionally, a new revision has been added to configuration Instance 102. Revision 3 has a data size of 280.

	Assembly Instance:	Size:	
Input:	104	88	(16-bit)
Output:	105	26	(16-bit)
Configuration:	102	280	(8-bit)
Status Input:			
Status Output:			

7. Type the IP address of the EtherNet/IP communication auxiliary module.

Address / Host Name

IP Address: 192 . 168 . 1 . 14

Host Name:

8. Type the value for the time between each scan of the module. The recommended RPI time is 250 ms. Ensure that the Inhibit Module is not checked.

Module Properties: ControlNetwork (ETHERNET-MODULE 1.1)

General Connection* Module Info

Requested Packet Interval (RPI): 250.0 ms (1.0 - 3200.0 ms)

Inhibit Module

Major Fault On Controller If Connection Fails While in Run Mode

Use Unicast Connection over EtherNet/IP

Module Fault

Status: Offline


OK Cancel Apply Help

9. Click OK to add the EtherNet/IP communication auxiliary module to the I/O Configuration in RSLogix 5000.


Accessing Generic Module Data

With both the ControlLogix controller and the EtherNet/IP network configured, the ControlLogix controller can exchange data with the EtherNet/IP communication auxiliary module.

1. Go online, then switch the controller to Remote Run mode.



2. Open the Controller Tags window.



3. Select the Monitor Tags tab.

Name	Value	Force Mask	Style	Data Type
- MotorStarter:I	{...}	{...}		AB:ETHERNET_...
+ MotorStarter:I.Data	{...}	{...}	Decimal	INT[81]
- MotorStarter:O	{...}	{...}		AB:ETHERNET_...
+ MotorStarter:O.Data	{...}	{...}	Decimal	INT[24]
- MotorStarter:C	{...}	{...}		AB:ETHERNET_...
+ MotorStarter:C.Data	{...}	{...}	Hex	SINT[400]

An array of input and output tags were generated for each of the six scanned devices. To control the output relays for the scanned device, use the output tags; to obtain diagnostic information from the scanned device, use the input tags.

The format of output data is shown in the table to follow.

Table 6 - Output Assembly — Instance 100

Byte Size	Contents
Scan List I/O Size	Data to be delivered to the first scan list entry.
Scan List I/O Size	Data to be delivered to the second scan list entry.
Scan List I/O Size	Data to be delivered to the third scan list entry.
Scan List I/O Size	Data to be delivered to the fourth scan list entry.
Scan List I/O Size	Data to be delivered to the fifth scan list entry.
Scan List I/O Size	Data to be delivered to the sixth scan list entry.

The format of the input data is shown in [Table 8](#).

Table 7 - Output Assembly — Instance 105

Byte Size	Contents
4	Command Register Bit 0 = Scanlist Config Bit 1 = ADR Record
Scan List I/O Size	Data to be delivered to the first scan list entry
Scan List I/O Size	Data to be delivered to the second scan list entry
Scan List I/O Size	Data to be delivered to the third scan list entry
Scan List I/O Size	Data to be delivered to the fourth scan list entry
Scan List I/O Size	Data to be delivered to the fifth scan list entry
Scan List I/O Size	Data to be delivered to the sixth scan list entry

Table 8 - Input Assembly — Instance 101

Byte Size	Contents
4 bytes	Logix Status Word
2 bytes	DeviceNet Scanner Status (Parameter 1) See Table 11 on page 81
2 bytes	Scan List Entry 1 Status Word (Parameter 2) See Table 12 on page 82
2 bytes	Scan List Entry 2 Status Word (Parameter 3) See Table 13 on page 82
2 bytes	Scan List Entry 3 Status Word (Parameter 4) See Table 14 on page 82
2 bytes	Scan List Entry 4 Status Word (Parameter 5) See Table 15 on page 83
2 bytes	Scan List Entry 5 Status Word (Parameter 6) See Table 16 on page 83
2 bytes	Scan List Entry 6 Status Word (Parameter 7) See Table 17 on page 83
Scan List I/O Size	Produced I/O data from the first scan list entry.
Scan List I/O Size	Produced I/O data from the second scan list entry.
Scan List I/O Size	Produced I/O data from the third scan list entry.
Scan List I/O Size	Produced I/O data from the fourth scan list entry.
Scan List I/O Size	Produced I/O data from the fifth scan list entry.
Scan List I/O Size	Produced I/O data from the sixth scan list entry.
2 bytes	Data Link 1 Data
2 bytes	Data Link 2 Data
2 bytes	Data Link 3 Data
::	::
2 bytes	Data Link 48 Data

Table 9 - Input Assembly — Instance 104

Byte Size	Contents
4	Reserved (Must be 0)
2	Scanner Status Word (Parameter 1)
2	Scanner Node Address
2	Scan List Entry 1 Status Word (Parameter 2) See Table 12 on page 82
2	Scan List Entry 1 Node Address
2	Scan List Entry 2 Status Word (Parameter 3) See Table 13 on page 82
2	Scan List Entry 2 Node Address
2	Scan List Entry 3 Status Word (Parameter 4) See Table 14 on page 82
2	Scan List Entry 3 Node Address
2	Scan List Entry 4 Status Word (Parameter 5) See Table 15 on page 83
2	Scan List Entry 4 Node Address
2	Scan List Entry 5 Status Word (Parameter 6) See Table 16 on page 83
2	Scan List Entry 5 Node Address
2	Scan List Entry 6 Status Word (Parameter 7) See Table 17 on page 83
2	Scan List Entry 6 Node Address
Scan List I/O Size	Produced I/O data from the first scan list entry
Scan List I/O Size	Produced I/O data from the second scan list entry
Scan List I/O Size	Produced I/O data from the third scan list entry
Scan List I/O Size	Produced I/O data from the fourth scan list entry
Scan List I/O Size	Produced I/O data from the fifth scan list entry
Scan List I/O Size	Produced I/O data from the sixth scan list entry
2	Data Link 1 Data
2	Data Link 2 Data
2	Data Link 3 Data
2	Data Link 4 Data
...	...
2	Data Link 48 Data

Logic Explicit Messaging

CompactLogix, ControlLogix, and SoftLogix controllers can read and write specific information to and from DeviceNet modules on the same DeviceNet network through the EtherNet/IP communication auxiliary module using Explicit Messaging.

The following steps configure a ControlLogix explicit message using the MSG instruction to read diagnostic parameters from an E3 Plus Model and EC5 Overload Relay.

1. In an integer array named MSG_Read_Request, define the number of attributes to read and list the specific attribute numbers.

Name	Value	Force Mask	Style	Data Type
+ Local:1:1	(...)	(...)	(...)	AB:176S_SDN_496Bytes:1:0
+ Local:1:0	(...)	(...)	(...)	AB:176S_SDN_364Bytes:0:0
+ MSG_Read_Data	(...)	(...)	(...)	STATUS_OBJECT_READ_DATA
+ MSG_Read_Message	(...)	(...)	(...)	MESSAGE
- MSG_Read_Request	(...)	(...)	(...)	Decimal INT[20]
+ MSG_Read_Request[0]	6			Decimal INT
+ MSG_Read_Request[1]	15			Decimal INT
+ MSG_Read_Request[2]	1			Decimal INT
+ MSG_Read_Request[3]	17			Decimal INT
+ MSG_Read_Request[4]	18			Decimal INT
+ MSG_Read_Request[5]	19			Decimal INT
+ MSG_Read_Request[6]	20			Decimal INT

The MSG instruction returns in an integer array with the first integer representing the following information:


- number of attributes
- first attribute number being returned
- first attribute number data status
- first attribute data...
- last attribute number being returned
- last attribute number data status
- last attribute data

In the screen capture below, the user-defined structure listing the integers is being returned in this example.

Number_of_Attributes	INT	Decimal
Voltage_Attribute_Num	INT	Decimal
Voltage_Attribute_Status	INT	Decimal
Voltage_L1	INT	Decimal
Voltage_L2	INT	Decimal
Voltage_L3	INT	Decimal
Voltage_Average	INT	Decimal
Current_Attribute_Num	INT	Decimal
Current_Attribute_Status	INT	Decimal
Current_L1	INT	Decimal
Current_L2	INT	Decimal
Current_L3	INT	Decimal
Current_Average	INT	Decimal
Current_Ground_Fault	INT	Decimal
KW_Attribute_Num	INT	Decimal
KW_Attribute_Status	INT	Decimal
KW_L1	INT	Decimal
KW_L2	INT	Decimal
KW_L3	INT	Decimal
KW_Total	INT	Decimal
KVAR_Attribute_Num	INT	Decimal
KVAR_Attribute_Status	INT	Decimal
KVAR_L1	INT	Decimal
KVAR_L2	INT	Decimal
KVAR_L3	INT	Decimal
KVAR_Total	INT	Decimal
KVA_Attribute_Num	INT	Decimal
KVA_Attribute_Status	INT	Decimal
KVA_L1	INT	Decimal
KVA_L2	INT	Decimal
KVA_L3	INT	Decimal
KVA_Total	INT	Decimal
PF_Attribute_Num	INT	Decimal
PF_Attribute_Status	INT	Decimal
PF_L1	INT	Decimal
PF_L2	INT	Decimal
PF_L3	INT	Decimal
PF_Total	INT	Decimal


2. Set up the MSG instruction in the Configuration tab to read the list of attributes (Parameters Group) by configuring the following fields:

- Message Type: CIP Generic
- Service Type: Custom
- Service Code: 0x03 (hex)
- Class: 0x375 (hex)
- Instance: 1 (dec)
- Attribute: 0x00 (hex)
- Source Element: MSG_Read_Request [0]
- Source Length: 14 (bytes)
- Destination: MSG_Read_Data



3. Set up the communications path in the Communications tab to read the data from the E3 Plus Electronic Overload Relay located at Node 6 by configuring the communication path as “MotorStarter, 3, 6”.

NOTE: Motor Starter — the name of the EtherNet/IP communication auxiliary module
 3 — the port number of the DeviceNet Scanner of the EtherNet/IP communication auxiliary module.
 6 — the node address of the E3 Plus Electronic Overload Relay.



4. Click OK. When finished, the MSG instruction reads the 25 parameters from the E3 Overload Relay and places the results into MSG_Read_Data as shown below.

Name	Value	Force Mask	Style	Data Type
+ Local1:1	(...)	(...)		AB:1769_SDN_496Bytes:1:0
+ Local1:0	(...)	(...)		AB:1769_SDN_364Bytes:0:0
- MSG_Read_Data	(...)	(...)		STATUS_OBJECT_READ_DATA
+ MSG_Read_Data.Number_of_Attributes	6		Decimal	INT
+ MSG_Read_Data.Voltage_Attribute_Num	15		Decimal	INT
+ MSG_Read_Data.Voltage_Attribute_Status	0		Decimal	INT
+ MSG_Read_Data.Voltage_L1	120		Decimal	INT
+ MSG_Read_Data.Voltage_L2	0		Decimal	INT
+ MSG_Read_Data.Voltage_L3	0		Decimal	INT
+ MSG_Read_Data.Voltage_Average	60		Decimal	INT
+ MSG_Read_Data.Current_Attribute_Num	1		Decimal	INT
+ MSG_Read_Data.Current_Attribute_Status	0		Decimal	INT
+ MSG_Read_Data.Current_L1	46		Decimal	INT
+ MSG_Read_Data.Current_L2	0		Decimal	INT
+ MSG_Read_Data.Current_L3	0		Decimal	INT
+ MSG_Read_Data.Current_Average	23		Decimal	INT
+ MSG_Read_Data.Current_Ground_Fault	0		Decimal	INT
+ MSG_Read_Data.kW_Attribute_Num	17		Decimal	INT
+ MSG_Read_Data.kW_Attribute_Status	0		Decimal	INT
+ MSG_Read_Data.kW_L1	51		Decimal	INT
+ MSG_Read_Data.kW_L2	0		Decimal	INT
+ MSG_Read_Data.kW_L3	0		Decimal	INT
+ MSG_Read_Data.kW_Total	51		Decimal	INT
+ MSG_Read_Data.kVAR_Attribute_Num	18		Decimal	INT
+ MSG_Read_Data.kVAR_Attribute_Status	0		Decimal	INT
+ MSG_Read_Data.kVAR_L1	-5		Decimal	INT
+ MSG_Read_Data.kVAR_L2	0		Decimal	INT
+ MSG_Read_Data.kVAR_L3	0		Decimal	INT
+ MSG_Read_Data.kVAR_Total	-5		Decimal	INT
+ MSG_Read_Data.kVA_Attribute_Num	19		Decimal	INT
+ MSG_Read_Data.kVA_Attribute_Status	0		Decimal	INT
+ MSG_Read_Data.kVA_L1	51		Decimal	INT
+ MSG_Read_Data.kVA_L2	0		Decimal	INT
+ MSG_Read_Data.kVA_L3	0		Decimal	INT
+ MSG_Read_Data.kVA_Total	51		Decimal	INT
+ MSG_Read_Data.PF_Attribute_Num	20		Decimal	INT
+ MSG_Read_Data.PF_Attribute_Status	0		Decimal	INT
+ MSG_Read_Data.PF_L1	99		Decimal	INT
+ MSG_Read_Data.PF_L2	100		Decimal	INT
+ MSG_Read_Data.PF_L3	0		Decimal	INT
+ MSG_Read_Data.PF_Total	100		Decimal	INT

Notes:

Email/Text

Introduction

This chapter describes email notifications and how to configure an EtherNet/IP communication auxiliary module to send email messages and text notifications for different communication events.

Email Notifications

Events

Several communication events can trigger email notifications. These events are fault conditions for the DeviceNet scan list and EtherNet/IP communication auxiliary module.

Fault Conditions for the DeviceNet Scan List			
Minor Recoverable	Major Unrecoverable	Wrong Data Size	Slave Init Error
Minor Unrecoverable	Connection Timeout	No Such Device	I/O Data Overflow
Major Recoverable	Keying Mismatch	Frag/Idle Error	Automatic Device Replacement Error
Acknowledge Timeout			
Fault Conditions for the EtherNet/IP communication auxiliary module			
On Line	Global ADR Error	In Idle Mode	Duplicate Mac Error
Illegal Scan List Data	No Scanner Messages	Hardware Error	Data Link Error
No Network Messages	Transmit Failure	Bus Off Error	Non Volatile Storage Error

Email Contents

The subject and body contents in the email message are created from the following:

- Type of trip or warning that is detected
- Device name
- Device description
- Device location
- Contact information

EXAMPLE Email Subject:

193-DNENCATR Comms Aux has detected a fault

Email Body:

Fault Status:

Device Name: 193-DNENCATR Comms Aux

Device Description: Motor Starters

Device Location: Bay 6-U29


Contact Info: Contact Person contactperson@thecontact.com

The first word in the email subject is the device name. If a device name is not configured, then the product name attribute from the identity object is used.


Email Configuration

To be able to send an email, the IP address of the host name of a Simple Mail Transfer Protocol (SMTP) server must be configured and notifications must be selected. Follow these steps to configure an email notification.

1. In the web browser, type the IP address of the EtherNet/IP communication auxiliary module in the address bar, then press the enter key on the keyboard.



2. Select Administrative Settings Email Configuration. A login window appears.



3. Log in with the username “Administrator”, leave the password field blank, and click OK.

If desired, you can set a password within the Administrative Settings tab.

4. Type the information into the email notification fields as shown.

Email Recipient	The email address of the person who receives the notifications.
Email Sender	The email address from which the notification is sent.
SMTP Server	Consult with the network administrator for the SMTP server address.
SMTP Username	Consult with the network administrator for the SMTP username.
SMTP Password	Consult with the network administrator for the SMTP password.
SMTP Port	Consult with the network administrator which SMTP port number to use. Port 25 is the most common SMTP port.

5. Check the desired notification time, fault conditions, and local conditions to be included in notification emails to the recipient. You can change these values after the initial configurations.


6. Click Apply Changes to save the configuration.

Configure Device Identity

The properties of the Device Identity populate the notification email subject and email body. To configure the Device Identity, perform the following steps.

1. Select Administrative Settings>Device Identity.

2. Type the Device Identity information into the fields as described below.



Device Name	The name of the EtherNet/IP communication auxiliary module.
Device Description	The description of the EtherNet/IP communication auxiliary module.
Device Location	The location of the EtherNet/IP communication auxiliary module.
Contact Information	The contact information for the EtherNet/IP communication auxiliary module.
Device X Name	The name of the DeviceNet device being scanned.
Device X Description	The description of the DeviceNet device being scanned.

3. Click Apply Changes to save the configuration.

Text Notifications

The EtherNet/IP communication auxiliary module can send a text message to a wireless phone by emailing the wireless phone service provider. The format for the text message is provided by the service provider and looks similar to the example formats shown.

AT&T™	10-digit wireless phone number@txt.att.net
Sprint®	10-digit wireless phone number@messaging.sprint.pcs.com

Multiple email addresses can be entered into the Email Recipient field, separating each email address with a semicolon (;). The Email Recipient field is limited to 255 characters.

EXAMPLE An EtherNet/IP communication auxiliary module sending an email and text message when a Communications Timeout event occurs:



Limitations

Based on the functionality of the EtherNet/IP communication auxiliary module, there are some limitations on when the emails can be triggered.

- If two events occur simultaneously, an email is only sent for the most significant error.
- If the device has been configured to send an email for a lower prioritized event **and** this event occurs at the same time as a higher prioritized event for which the device has not been programmed to send an email, an email is not sent for either event.
- The Clear email is only sent when all events have been cleared **and** an event email has previously been sent.

Notes:

Device Parameters

Introduction

The EtherNet/IP communication auxiliary module provides parameters to let you view the status and configure the DeviceNet scanner with RSNetWorx™ for DeviceNet if you do not want to use the internal web server of the EtherNet/IP communication auxiliary module. [Table 10](#) lists the 14 available parameters.

Table 10 - Parameter List

1	Scanner Status	8	SL Entry Size
2	SL Entry 1 Status	9	Device Keys
3	SL Entry 2 Status	10	Scanlist Config
4	SL Entry 3 Status	11	ADR Record
5	SL Entry 4 Status	12	ADR Enable
6	SL Entry 5 Status	13	DNet IO RPI
7	SL Entry 6 Status	14	DNet IO Inhibit

Parameter Programming

IMPORTANT Parameter setting changes to the EtherNet/IP communication auxiliary module take effect immediately even during a “running” status.

Parameter Listing

The details for each of the 14 available parameters are listed below.

Table 11 - Parameter 1 — Scanner Status

Description	Access Rule	Data Type	Units	Value		
				Min.	Max.	Default
Provides the status of the Devicenet scanner.	Get	WORD	—	0	16383	0
Bit						
0 On Line	3	No Scanner Messages	6	Initializing		
1 Illegal Scan List	4	Transmit Failure	7	Duplicate MAC Failure		
2 No Network Messages	5	In Idle Mode	8	Bus Off		

Table 12 - Parameter 2 — SL Entry 1 Status

Description	Access Rule	Data Type	Units	Value		
				Min.	Max.	Default
Provides the status of the first scan list entry in the DeviceNet scanner.	Get	WORD	—	0	2047	0
Bit						
0	On Line	4	No Such Device	8	Device Went Idle	
1	Connection Timeout	5	Fragment Error	9	Automatic Device Replacement Error	
2	Keying Mismatch	6	Slave Initialization Error			
3	Wrong Data Size	7	I/O Data Overflow	10	Acknowledgement Timeout	

Table 13 - Parameter 3 — SL Entry 2 Status

Description	Access Rule	Data Type	Units	Value		
				Min.	Max.	Default
Provides the status of the second scan list entry in the DeviceNet scanner.	Get	WORD	—	0	2047	0
Bit						
0	On Line	4	No Such Device	8	Device Went Idle	
1	Connection Timeout	5	Fragment Error	9	Automatic Device Replacement Error	
2	Keying Mismatch	6	Slave Initialization Error			
3	Wrong Data Size	7	I/O Data Overflow	10	Acknowledgement Timeout	

Table 14 - Parameter 4 — SL Entry 3 Status

Description	Access Rule	Data Type	Units	Value		
				Min.	Max.	Default
Provides the status of the third scan list entry in the DeviceNet scanner.	Get	WORD	—	0	2047	0
Bit						
0	On Line	4	No Such Device	8	Device Went Idle	
1	Connection Timeout	5	Fragment Error	9	Automatic Device Replacement Error	
2	Keying Mismatch	6	Slave Initialization Error			
3	Wrong Data Size	7	I/O Data Overflow	10	Acknowledgement Timeout	

Table 15 - Parameter 5 — SL Entry 4 Status

Description	Access Rule	Data Type	Units	Value		
				Min.	Max.	Default
Provides the status of the fourth scan list entry in the DeviceNet scanner.	Get	WORD	—	0	2047	0
Bit						
0 On Line	4	No Such Device	8	Device Went Idle		
1 Connection Timeout	5	Fragment Error	9	Automatic Device Replacement Error		
2 Keying Mismatch	6	Slave Initialization Error				
3 Wrong Data Size	7	I/O Data Overflow	10	Acknowledgement Timeout		

Table 16 - Parameter 6 — SL Entry 5 Status

Description	Access Rule	Data Type	Units	Value		
				Min.	Max.	Default
Provides the status of the fifth scan list entry in the DeviceNet scanner.	Get	WORD	—	0	2047	0
Bit						
0 On Line	4	No Such Device	8	Device Went Idle		
1 Connection Timeout	5	Fragment Error	9	Automatic Device Replacement Error		
2 Keying Mismatch	6	Slave Initialization Error				
3 Wrong Data Size	7	I/O Data Overflow	10	Acknowledgement Timeout		

Table 17 - Parameter 7 — SL Entry 6 Status

Description	Access Rule	Data Type	Units	Value		
				Min.	Max.	Default
Provides the status of the sixth scan list entry in the DeviceNet scanner.	Get	WORD	—	0	2047	0
Bit						
0 On Line	4	No Such Device	8	Device Went Idle		
1 Connection Timeout	5	Fragment Error	9	Automatic Device Replacement Error		
2 Keying Mismatch	6	Slave Initialization Error				
3 Wrong Data Size	7	I/O Data Overflow	10	Acknowledgement Timeout		

Table 18 - Parameter 8 — SL Entry Size

Description	Access Rule	Data Type	Units	Value		
				Min.	Max.	Default
Defines the number of bytes to be scanned for I/O data from each DeviceNet Device.	Get/Set	USIN T	Bytes	1	50	8

Table 19 - Parameter 9 — Device Keys

Description	Access Rule	Data Type	Units	Value		
				Min.	Max.	Default
Determines how electronic keying is performed.	Get/Set	USINT	—	0	63	7
Bit						
0	Device Type	2	Product Code	4	Minor Revision	
1	Vendor	3	Major Revision	5	Minor of Higher	

Table 20 - Parameter 10 — Scanlist Config

Description	Access Rule	Data Type	Units	Value		
				Min.	Max.	Default
Triggers the building of a new DeviceNet scan list. 0 = Ready 1 = Build Scan List	Get/Set	BOOL	—	0	1	0

Table 21 - Parameter 11 — ADR Record

Description	Access Rule	Data Type	Units	Value		
				Min.	Max.	Default
Triggers the recording of configuration parameters from devices in the DeviceNet scan list to be used for Automatic Device Replacement. 0 = Ready 1 = Record Parameters	Get/Set	BOOL	—	0	1	0

Table 22 - Parameter 12 — ADR Enable

Description	Access Rule	Data Type	Units	Value		
				Min.	Max.	Default
Enables Automatic Device Replacement. 0 = Disable 1 = Enable	Get/Set	BOOL	—	0	1	0

Table 23 - Parameter 13 — DNet IO RPI

Description	Access Rule	Data Type	Units	Value		
				Min.	Max.	Default
Defines the requested packet interval rate in milliseconds used on DeviceNet Polled I/O messaging.	Get/Set	WORD	ms	2	1000	75

Table 24 - Parameter 14 — DNet IO Inhibit

Description	Access Rule	Data Type	Units	Value		
				Min.	Max.	Default
Defines the inhibit time in milliseconds used on DeviceNet Change of State (COS) I/O messaging.	Get	WORD	ms	2	1000	1

Troubleshooting

Introduction

This chapter helps you to troubleshoot the EtherNet/IP communication auxiliary module.



SHOCK HAZARD: Servicing energized industrial control equipment can be hazardous. Electrical shock, burns, or unintentional actuation of controlled industrial equipment may cause death or serious injury. For safety of maintenance personnel and others who may be exposed to electrical hazards associated with maintenance activities, follow local safety-related work practices (for example, the NFPS 70W; Part II, *Electrical Safety for Employee Workplaces*, in the United States) when working on or near energized equipment. Maintenance personnel must be trained in the safety practices, procedures, and requirements that pertain to their respective job assignments. Do not work alone on energized equipment.



ATTENTION: Do not attempt to defeat or override fault circuits. The cause of a fault indication must be determined and corrected before attempting operation. Failure to correct a control system or mechanical malfunction may result in personal injury and/or equipment damage due to uncontrolled machine system operation.


Modes of Operation

The EtherNet/IP communication auxiliary module has four EtherNet/IP modes of operation:

- Power-Up Reset mode
- Run mode
- Recoverable Error mode
- Unrecoverable Error mode

Power-Up Reset Mode

Figure 8 - Status LEDs



During the Power-Up Reset mode, the following procedure occurs.

- The various status indicators (LEDs) cycle simultaneously.
 - Module Status (MS) status indicator flashes green for approximately 0.25 seconds, flash red for another 0.25 seconds, then remain a solid green.
 - EtherNet/IP Network Status (NS) status indicator flashes green for approximately 0.25 seconds, flash red for another 0.25 seconds, then not illuminate.
 - Device Network Status (NS) status indicator flashes green for approximately 0.25 seconds, flashes red for another 0.25 seconds, then does not illuminate.

The MS and both NS status indicators then return to their standard illuminated state.

- The EtherNet/IP communication auxiliary module performs a duplicate IP address check to verify that another module is not assigned to the same IP address. If a duplicate IP address is detected on the network, the EtherNet/IP NS status indicator illuminates to a solid red, the MS status indicator flashes red, and the EtherNet/IP communication auxiliary module enters the Recoverable Error mode.

3. The EtherNet/IP communication auxiliary module performs a duplicate media access control (MAC) address check to verify that another module is not assigned to the same MAC address. If a duplicate MAC address is detected on the DeviceNet network, the DeviceNet NS status indicator illuminates a solid red, the MS status indicator flashes red, and the EtherNet/IP communication auxiliary module enters the Recoverable Error mode.
4. If the power-up or reset is successful, the overload relay enters into Run mode.

Run Mode

In Run mode, the EtherNet/IP communication auxiliary module does the following:

- operates as a slave device to a master device on an EtherNet/IP network.
- operates as a master device and scans up to six slave devices on a DeviceNet network.
- accepts messages from a master on the EtherNet/IP network.
- sends response messages, COS messages, or CYCLIC messages to a master.
- supports a Device Level Ring (DLR) for catalog number 193-DNENCATR.

If a communication error is detected, the EtherNet/IP communication auxiliary module either enters the Recoverable Error mode or Unrecoverable Error mode.

Operating as a Slave Device to a Master Device

As stated, the EtherNet/IP communication auxiliary module operates as a slave device to a master device on an EtherNet/IP network in Run mode. The EtherNet/IP NS LED flashes green if there are no network connections established with an EtherNet/IP network master. When one or more connections are in the “established” state, the EtherNet/IP NS LED illuminates a solid green. When one or more connections are in the “timed out” state, the EtherNet/IP NS flashes red.

Operating as a Master Device

As stated, the EtherNet/IP communication auxiliary module also operates as a master device and scans up to six slave devices on a DeviceNet network in Run Mode. The DeviceNet NS LED flashes green if there are no connections established with a DeviceNet slave device. When one or more connections are in the “established” state, the DeviceNet NS LED illuminates a solid green. When one or more connections are in the “timed out” state, the DeviceNet NS LED flashes red. If no slave devices are defined in the DeviceNet scan list, the MS LED flashes red.

Recoverable Error Mode

In this mode, the EtherNet/IP communication auxiliary module MS LED flashes red. The device responds to messages that are specified in offline mode recovery message protocol.

Error Type	Description	LED State
Recoverable	Duplicate IP address detected.	Flashing Red
	A device is not present on the DeviceNet scan list.	

Unrecoverable Error Mode

In this mode, the EtherNet/IP communication auxiliary module MS LED illuminates a solid red. The device continues in this state as long as the device is powered.

Error Type	Description	LED State
Unrecoverable	Power-up initialization failure.	Solid Red
	Data communication error.	

Troubleshooting Procedures

The following table identifies possible causes and corrective actions when troubleshooting EtherNet/IP related failures using the status LEDs.

Table 25 - Troubleshooting Procedures

Status LED	Color	State	Possible Cause	Corrective Action
EtherNet/IP Network Status (NS)	None	—	The EtherNet/IP communication auxiliary module is not receiving power.	Check the DeviceNet cable connections and verify that 24V DC exists between the red and black terminals.
	Green, Red, Not Illuminated	Flashing (once)	Normal	This is a normal power-up sequence.
	Green	Flashing	The EtherNet/IP communication auxiliary module is online, but with no connections established.	Check the EtherNet/IP master and its scan list for correct scanner configuration.
	Green	Solid	Normal operating state and the EtherNet/IP communication auxiliary module is allocated to a master.	No action is required.
	Red	Flashing	One or more EtherNet/IP connections timed out.	Reset the EtherNet/IP master device.
	Red	Solid	Diagnostics test failed on power-up/reset. An internal fault exists.	Cycle power to the unit. If the fault still exists, replace the unit.
	Duplicate EtherNet/IP module address exists. Two modules cannot have the same address.		Change the IP address to a valid setting and reset the device.	
	A fatal communication error occurred.		Check Ethernet media for proper installation.	

Status LED	Color	State	Possible Cause	Corrective Action
DeviceNet Network Status (NS)	None	—	The EtherNet/IP communication auxiliary module is not receiving power.	Check the DeviceNet cable connections and verify that 24V DC exists between the red and black terminals.
	Green, Red, Not Illuminated	Flashing (once)	Normal	This is a normal power-up sequence.
	Green	Flashing	The EtherNet/IP communication auxiliary module is not configured to scan any DeviceNet slave devices.	Check the DeviceNet scan list for the correct scanner configuration.
	Green	Solid	Normal operating state and the EtherNet/IP communication auxiliary module is scanning DeviceNet slave devices.	No action is required.
	Red	Flashing	One or more DeviceNet connections timed out.	Reset the EtherNet/IP communication auxiliary module.
	Red	Solid	Diagnostics test failed on power-up/reset. An internal fault exists.	Cycle power to the unit. If the fault still exists, replace the unit.
			Duplicate DeviceNet module address exists. Two modules cannot have the same address.	Change the MAC address to a valid setting and reset the device.
		A fatal communication error occurred.	Check DeviceNet media for proper installation.	
Module Status	None	—	The EtherNet/IP communication auxiliary module is not receiving power.	Check the DeviceNet cable connections and verify that 24V DC exists between the red and black terminals.
	Green, Red, Not Illuminated	Flashing (once)	Normal	This is a normal power-up sequence.
	Green	Flashing	The EtherNet/IP communication auxiliary module is properly scanning DeviceNet slave devices, but it is not being scanned by the EtherNet/IP master.	Check the Ethernet scan list for the correct scanner configuration.
	Green	Solid	Normal operating state, the EtherNet/IP communication auxiliary module is scanning DeviceNet slave devices, and is allocated to its master.	No action is required.
	Red	Flashing	One or more DeviceNet or EtherNet/IP connections timed out.	Reset the EtherNet/IP communication auxiliary module.
			The EtherNet/IP communication auxiliary module is not configured to scan any DeviceNet slave devices.	Check the DeviceNet scan list for correct scanner configuration.
Red	Solid	Diagnostics test failed on power-up/reset.	Cycle power to the device. If the fault still exists, replace the device.	
Link Link (front) Link (back)	None	—	The EtherNet/IP communication auxiliary module is not properly connected to an Ethernet network.	Check the Ethernet cabling to make sure it is properly installed.
	Green	Flashing	The Ethernet network is properly connected.	No action is required.
	Green	Solid	Communications are occurring on the Ethernet network.	No action is required.

Notes:

Specifications

Specifications

Table 26 - Ratings

Terminal Ratings		
Terminal Screw		M3
Wire Cross Section		See wiring diagram section
Torque		0.56...0.79 N·m (5...7 lb·in.)
Degree of Protection		IP20
Power Supply Ratings		
Rated Supply Voltage	U_s	24V DC
Rated Operating Range	U_e	24V -15%, +10% DC
Rated Supply Current	I_e	100 mA at 24V DC
Maximum Surge Current at Power-Up		6.4 A
Maximum Power Consumption		2.1 W
Environmental Ratings		
Ambient Temperature	T_{amb}	
Storage		-40...+85 °C (-40...+185 °F)
Operating (Open)		-20...+60 °C (-4...+140 °F)
Operating (Enclosed)		-20...+40 °C (-4...+104 °F)
Humidity		
Operating		5...95% non-condensing
Damp Heat - Steady State		per IEC 68-2-3
Damp Heat - Cyclic		per IEC 68-2-30
Cooling Method		Natural Convection
Vibration (per IEC 68-2-6)		3 G
Shock (per IEC 68-2-27)		30 G
Maximum Altitude		2000 m
Pollution Environment		Pollution Degree 2
Terminal Marking		EN 50012
Degree of Protection		IP20

Table 27 - Electromagnetic Compatibility

Electromagnetic Compatibility	
Electrostatic Discharge Immunity Test Level	8 kV Air Discharge 4 kV Contact Discharge B ⁽¹⁾ (2)
Performance Criteria	
RF Immunity Test Level	10V/m: 80 MHz...1 GHz 3V/m: 1.4 GHz...2 GHz 1V/m: 2.0 GHz...2.7 GHz B ⁽¹⁾⁽²⁾
Performance Criteria	
Electrical Fast Transient/Burst Immunity Test Level	2 kV (Power Protective Earth) 1 kV (control bus cable) B ⁽¹⁾⁽²⁾
Performance Criteria	
Surge Immunity Test Level	1 kV L-L (bus cable) B ⁽¹⁾⁽²⁾
Performance Criteria	
Radiated Emissions	Class A
Conducted Emissions	Class A

- (1) Performance Criteria B requires the DUT (device under test) not to experience degradation or loss of performance.
- (2) Environment 2 - Heavy Industrial.



ATTENTION: This is a class A product. In domestic environment, this product may cause radio interference, in which case you may be required to take adequate measures.

Table 28 - EtherNet/IP Communication

EtherNet/IP Communication	
Total Connections Supported	
TCP	150
CIP	47
Total CIP Unconnected Messages Supported	128
CIP Class 1 Connection Consumed	1
Packet Rates (packets/second)	
I/O	500
HIM/MSG	500
Media Support	
Twisted Pair	Yes
Fiber	No
Speed Duplex (Half/Full)	10/100
Duplicate IP Detection	Yes

Table 29 - Standards & Certifications

Standards and Certifications
UL 508
CSA 22.2, No. 14
EN 60947-4-1

EtherNet/IP and DeviceNet Information

Electronic Data Sheet (EDS) Files

EDS files are specially formatted ASCII files that provide all of the information necessary for a configuration tool (for example, RSNetWorx™ for EtherNet/IP) to access and alter the parameters of a device. The EDS file contains all the parameter information of a device: number of parameters, groupings, parameter name, min, max, and default values, units, data format and scaling. The EDS file for the EtherNet/IP communication auxiliary module is available from the Internet at www.ab.com/networks/eds/index.html. You can also obtain it from the EtherNet/IP communication auxiliary module's internal web page.

Common Industrial Protocol (CIP) Objects

The following CIP object classes are supported.

Table 30 - CIP Object Classes

Class	Object	EtherNet/IP	DeviceNet
0x01	Identity	X	X
0x02	Message Router	X	X
0x03	DeviceNet		X
0x04	Assembly	X	X
0x05	Connection		X
0x06	Connection Manager	X	
0x0F	Parameter	X	X
0x47	Device Level Ring Object	X	
0x48	Q05 Object	X	
0xA1	Non-Volatile Storage Object	X	X
0xF4	Port Object	X	X
0xF5	TCP/IP Interface	X	
0xF6	Ethernet Link	X	

Identity Object — CLASS CODE 0x01

The following class attributes are supported for the Identity Object.

Table 31 - Identity Object Class Attributes

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Revision	UINT	0x0001
2	Get	Max. Instance	UINT	0x00011

Identity Object instances contain the following instance attributes.

Table 32 - Identity Object Instance Attributes

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Vendor ID	UINT	
2	Get	Device Type	UINT	12
3	Get	Product Code	UINT	220 for 193-DNENCAT 221 for 193-DNENCATR
4	Get	Major Revision	USINT	1
		Minor Revision	USINT	1
5	Get	Status	WORD	Bit 0: Owned, shall be set when at least one connection is configured Bit 2: Configured Bit 8: Minor Recoverable fault Bit 9: Minor Unrecoverable fault Bit 10: Major Recoverable fault Bit 11: Major Unrecoverable fault
6	Get	Serial Number	UDINT	Unique number assigned for each device
7	Get	Product Name	SHORT_STRING	Product name
8	Get	State	USINT	3=Operational

The following common services are implemented for the Identity Object.

Table 33 - Identity Object Common Services

Service Code	Implemented for:		Service Name
	Class	Instance	
0x01	No	Yes	Get Attribute All
0x0E	Yes	Yes	Get Attribute Single
0x05	No	Yes	Reset

Message Router Object — CLASS CODE 0x02

No class or instance attributes are supported. The message router object exists only to route explicit messages to other objects.

DeviceNet Object — CLASS CODE 0x03

The following class attributes are supported for the DeviceNet Object.

Table 34 - DeviceNet Object Class Attributes

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Revision	UINT	2

A single instance of the DeviceNet Object is supported by the following attributes.

Table 35 - Single Instance of the DeviceNet Object

Attribute ID	Access Rule	Name	Data Type	Value
1	Get/Set	Node Address	USINT	0-63
2	Get/Set	Baud Rate	USINT	0=125K 1=250K 2=500K
13	Get	Active Node Table	Array of BOOL [64]	Identifies which nodes are online on the local network based on the node address.

The following services are implemented for the DeviceNet Object.

Table 36 - DeviceNet Object Common Services

Service Code	Implemented for:		Service Name
	Class	Instance	
0x0E	Yes	Yes	Get Attribute Single
0x10	No	Yes	Set Attribute Single

Assembly Object — CLASS CODE 0x04

The following class attributes are supported for the Assembly Object.

Table 37 - Assembly Object Class Attributes

Attribute ID	Access Rule	Name	Data Type	Value
2	Get	Max. Instance	UINT	120

Instance Attributes

Instances/Connection points implements the following data attributes.

Table 38 - Instance Attributes

Attribute ID	Access	Name	Type	Value	Description
3	Get/Set	Data	Array of UINT	—	Data produced/consumed by the module

Output Assemblies

The following output assembly instances are implemented.

Table 39 - Instance 100

Byte Size	Contents
Scan List I/O Size	Data to be delivered to the first scan list entry.
Scan List I/O Size	Data to be delivered to the second scan list entry.
Scan List I/O Size	Data to be delivered to the third scan list entry.
Scan List I/O Size	Data to be delivered to the fourth scan list entry.
Scan List I/O Size	Data to be delivered to the fifth scan list entry.
Scan List I/O Size	Data to be delivered to the sixth scan list entry.

Table 40 - Output Assembly — Instance 105 (available with firmware v 3.00 and higher)

Byte Size	Contents
4	Command Register Bit 0 = Scanlist Config Bit 1 = ADR Record
Scan List I/O Size	Data to be delivered to the first scan list entry
Scan List I/O Size	Data to be delivered to the second scan list entry
Scan List I/O Size	Data to be delivered to the third scan list entry
Scan List I/O Size	Data to be delivered to the fourth scan list entry
Scan List I/O Size	Data to be delivered to the fifth scan list entry
Scan List I/O Size	Data to be delivered to the sixth scan list entry

Input Assemblies

Table 41 - Instance 101

Byte Size	Contents
4 Bytes	Logix Status Word
2 Bytes	DeviceNet Scanner Status (Parameter 1) See Table 11 on page 81
2 Bytes	Scan List Entry 1 Status Word (Parameter 2) See Table 12 on page 82
2 Bytes	Scan List Entry 2 Status Word (Parameter 3) See Table 13 on page 82
2 Bytes	Scan List Entry 3 Status Word (Parameter 4) See Table 14 on page 82
2 Bytes	Scan List Entry 4 Status Word (Parameter 5) See Table 15 on page 83
2 Bytes	Scan List Entry 5 Status Word (Parameter 6) See Table 16 on page 83
2 Bytes	Scan List Entry 6 Status Word (Parameter 7) See Table 17 on page 83
Scan List I/O Size	Data to be delivered to the first scan list entry.
Scan List I/O Size	Data to be delivered to the second scan list entry.
Scan List I/O Size	Data to be delivered to the third scan list entry.
Scan List I/O Size	Data to be delivered to the fourth scan list entry.
Scan List I/O Size	Data to be delivered to the fifth scan list entry.
Scan List I/O Size	Data to be delivered to the sixth scan list entry.
2 Bytes	DataLink 1 Data
2 Bytes	DataLink 2 Data
2 Bytes	DataLink 3 Data
:::	:::
2 Bytes	Data Link 48 Data

Table 42 - Instance 103 (available with firmware v 2.00 and higher)

Byte Size	Contents
4 Bytes	Logix Status Word
4 Bytes	DeviceNet Scanner Status (Parameter 1) See Table 11 on page 81
4 Bytes	Scan List Entry 1 Status Word (Parameter 2) See Table 12 on page 82
4 Bytes	Scan List Entry 2 Status Word (Parameter 3) See Table 13 on page 82
4 Bytes	Scan List Entry 3 Status Word (Parameter 4) See Table 14 on page 82
4 Bytes	Scan List Entry 4 Status Word (Parameter 5) See Table 15 on page 83
4 Bytes	Scan List Entry 5 Status Word (Parameter 6) See Table 16 on page 83
4 Bytes	Scan List Entry 6 Status Word (Parameter 7) See Table 17 on page 83
Scan List I/O Size	Data to be delivered to the first scan list entry.
Scan List I/O Size	Data to be delivered to the second scan list entry.
Scan List I/O Size	Data to be delivered to the third scan list entry.
Scan List I/O Size	Data to be delivered to the fourth scan list entry.
Scan List I/O Size	Data to be delivered to the fifth scan list entry.
Scan List I/O Size	Data to be delivered to the sixth scan list entry.
2 Bytes	DataLink 1 Data
2 Bytes	DataLink 2 Data
2 Bytes	DataLink 3 Data
:::	:::
2 Bytes	Data Link 48 Data

Table 43 - Input Assembly — Instance 104 (available with firmware v 3.00 and higher)

Byte Size	Contents
4	Reserved (Must be 0)
2	Scanner Status Word (Parameter 1)
2	Scanner Node Address
2	Scan List Entry 1 Status Word (Parameter 2) See Table 12 on page 82
2	Scan List Entry 1 Node Address
2	Scan List Entry 2 Status Word (Parameter 3) See Table 13 on page 82
2	Scan List Entry 2 Node Address
2	Scan List Entry 3 Status Word (Parameter 4) See Table 14 on page 82
2	Scan List Entry 3 Node Address
2	Scan List Entry 4 Status Word (Parameter 5) See Table 15 on page 83
2	Scan List Entry 4 Node Address
2	Scan List Entry 5 Status Word (Parameter 6) See Table 16 on page 83
2	Scan List Entry 5 Node Address
2	Scan List Entry 6 Status Word (Parameter 7) See Table 17 on page 83
2	Scan List Entry 6 Node Address
Scan List I/O Size	Produced I/O data from the first scan list entry
Scan List I/O Size	Produced I/O data from the second scan list entry
Scan List I/O Size	Produced I/O data from the third scan list entry
Scan List I/O Size	Produced I/O data from the fourth scan list entry
Scan List I/O Size	Produced I/O data from the fifth scan list entry
Scan List I/O Size	Produced I/O data from the sixth scan list entry
2	Data Link 1 Data
2	Data Link 2 Data
2	Data Link 3 Data
2	Data Link 4 Data
...	...
2	Data Link 48 Data

*Configuration Assembly***Table 44 - Instance 102 (Revision 1)**

Byte Size	Contents
2 Bytes	Revision = 1
2 Bytes	ScanList I/O Size
2 Bytes	Data Link Update Interval (ms)
1 Byte	Data Link 1 Node
2 Bytes	Data Link 1 Parameter
1 Byte	Data Link 2 Node
2 Bytes	Data Link 2 Parameter
1 Byte	Data Link 3 Node
2 Bytes	Data Link 3 Parameter
1 Byte	Data Link 4 Node
2 Bytes	Data Link 4 Parameter
1 Byte	Data Link 5 Node
2 Bytes	Data Link 5 Parameter
1 Byte	Data Link 6 Node
2 Bytes	Data Link 6 Parameter
::::	::::
1 Byte	Data Link 48 Node
2 Bytes	Data Link 48 Parameter

Table 45 - Instance 102 (Revision 2) (available with firmware v 2.00 and higher)

Byte Size	Contents
2 Bytes	Revision = 2
2 Bytes	ScanList I/O Size
2 Bytes	Data Link Update Interval (ms)
2 Bytes	Reserved
2 Bytes	Data Link 1 Node
2 Bytes	Data Link 1 Parameter
2 Bytes	Data Link 2 Node
2 Bytes	Data Link 2 Parameter
2 Bytes	Data Link 3 Node
2 Bytes	Data Link 3 Parameter
2 Bytes	Data Link 4 Node
2 Bytes	Data Link 4 Parameter
2 Bytes	Data Link 5 Node
2 Bytes	Data Link 5 Parameter
2 Bytes	Data Link 6 Node
2 Bytes	Data Link 6 Parameter
::::	::::
2 Bytes	Data Link 48 Node
2 Bytes	Data Link 48 Parameter

Table 46 - Instance 102 (Revision 3) (available with firmware v 3.00 and higher)

Byte Size	Contents
2	Configuration Revision = 3
2	Scan List I/O Entry Size
2	Data Link Update Interval (ms)
2	DeviceNet I/O RPI (ms)
2	DeviceNet I/O Inhibit (ms)
1	DeviceNet Scanner Address
1	DeviceNet Scanner Baud Rate
1	DeviceNet Keys
1	ADR Enable
2	Reserved
2	Scan List 1 Node Address
2	Scan List 1 Vendor ID
2	Scan List 1 Device Type
2	Scan List 1 Product Code
2	Scan List 1 Major Revision
2	Scan List 1 Minor Revision
2	Scan List 2 Node Address
2	Scan List 2 Vendor ID
2	Scan List 2 Device Type
2	Scan List 2 Product Code

Byte Size	Contents
2	Scan List 2 Major Revision
2	Scan List 2 Minor Revision
2	Scan List 3 Node Address
2	Scan List 3 Vendor ID
2	Scan List 3 Device Type
2	Scan List 3 Product Code
2	Scan List 3 Major Revision
2	Scan List 3 Minor Revision
2	Scan List 4 Node Address
2	Scan List 4 Vendor ID
2	Scan List 4 Device Type
2	Scan List 4 Product Code
2	Scan List 4 Major Revision
2	Scan List 4 Minor Revision
2	Scan List 5 Node Address
2	Scan List 5 Vendor ID
2	Scan List 5 Device Type
2	Scan List 5 Product Code
2	Scan List 5 Major Revision
2	Scan List 5 Minor Revision
2	Scan List 6 Node Address
2	Scan List 6 Vendor ID
2	Scan List 6 Device Type
2	Scan List 6 Product Code
2	Scan List 6 Major Revision
2	Scan List 6 Minor Revision
1	Data Link 1 Node Address
1	Reserved (Must be 0)
2	Data Link 1 Parameter
1	Data Link 2 Node Address
1	Reserved (Must be 0)
2	Data Link 2 Parameter
1	Data Link 3 Node Address
1	Reserved (Must be 0)
2	Data Link 3 Parameter
...	...
1	Data Link 48 Node Address
1	Reserved (Must be 0)
2	Data Link 48 Parameter

The following services are implemented for the Assembly Object.

Table 47 - Ethernet Object Common Services

Service Code	Implemented for:			Service Name
	Class	Instance Consuming	Instance Producing	
0x0E	Yes	Yes	Yes	Get Attribute Single
0x10	No	Yes	No	Set Attribute Single

Connection Manager Object — CLASS CODE 0x06

No class or instance attributes are supported.

The following common service are implemented for the Connection Manager Object.

Table 48 - Connection Manager Object Common Services

Implemented for:	Service Name
Instance	
Yes	Forward Open
Yes	Forward Close
Yes	Unconnected Send

Parameter Object — CLASS CODE 0x0F

The following class attributes are supported for the Parameter Object.

Table 49 - Parameter Object Class Attributes

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Revision	UINT	0x0001
2	Get	Max Instance	UINT	0x0029
8	Get	Parameter Class Descriptor	WORD	0x000B

The following instance attributes are implemented for all parameter attributes.

Table 50 - Parameter Object Instance Attributes

Attribute ID	Access Rule	Name	Data Type	Value
1	Get/Set	Value	Specified in Descriptor	N/A
2	Get	Link Path Size	USINT	
3	Get	Link Path	Packed EPATH:	Path to specified object attribute
4	Get	Descriptor	WORD	Parameter Dependent
5	Get	Data Type	EPATH	
6	Get	Data Size	USINT	
7	Get	Parameter Name String	SHORT_STRING	
8	Get	Units String	SHORT_STRING	
9	Get	Help String	SHORT_STRING	
10	Get	Minimum Value	Specified in Descriptor	
11	Get	Maximum Value	Specified in Descriptor	
12	Get	Default Value	Specified in Descriptor	
13	Get	Scaling Multiplier	UINT	
14	Get	Scaling Divisor	UINT	
15	Get	Scaling Base	UINT	
16	Get	Scaling Offset	INT	
17	Get	Multiplier Link	UINT	
18	Get	Divisor Link	UINT	
19	Get	Base Link	UINT	
20	Get	Offset Link	UINT	
21	Get	Decimal Precision	USINT	Parameter Dependent

The following commons services are implemented for the Parameter Object.

Table 51 - Parameter Object Common Services

Service Code	Implemented for:		Service Name
	Class	Instance	
0x01	No	Yes	Get Attribute All
0x0E	Yes	Yes	Get Attribute Single
0x10	No	Yes	Set Attribute Single
0x4B	No	Yes	Get Enum String

Device Level Ring (DLR) Object — CLASS CODE 0x47

No class attributes are supported for the DLR object. A single instance (Instance 1) is supported.

Table 52 - DLR Object Single Instance

Attributes ID	Access Rule	Name	Data Type	Value
1	Get	Network Topology	USINT	0=Linear 1=Ring
2	Get	Network Status	USINT	0=Normal 1=Ring Fault 2=Unexpected Loop Detect 3=Partial Network Fault 4=Rapid Fault/Restore Cycle
10	Get	Active Supervisor Address	Structure of UDINT; array of 6 USINT	Ring Supervisor
12	Get	Capability Flags	DWORD	0x00000002

The following common services are implemented for the DLR object.

Table 53 - DLR Object Common Services

Service Code	Implemented for:		Service Name
	Class	Instance	
0x01	No	Yes	Get_Attributes_All
0x0E	No	Yes	Get_Attribute_Single

QoS Object — CLASS CODE 0x48

The following class attributes are supported for the QoS object.

Table 54 - QoS Object Class Attributes

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Revision	UINT	1

A single instance (Instance 1) is supported.

Table 55 - QoS Object Instance

Attribute ID	Access Rule	Name	Data Type	Value
1	Set	802: 1Q Tag Enable	USINT	0=Disable (default) 1=Enable
4	Set	DSCP Urgent	USINT	Default=55
5	Set	DSCP Schedule	USINT	Default=47
6	Set	DSCP High	USINT	Default=43
7	Set	DSCP Low	USINT	Default=31
8	Set	DSCP Explicit	USINT	Default=27

The following common services are implemented for the QoS object.

Table 56 - QoS Object Common Services

Service Code	Implemented for:		Service Name
	Class	Instance	
0x0E	Yes	Yes	Get_Attribute_Single
0x10	No	Yes	Set_Attribute_Single

Port Object — CLASS CODE 0x0F4

The Port object supports the following class attributes.

Table 57 - Port Object Class Attributes

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Revision	UINT	1
2	Get	Max. Instance	UINT	2
3	Get	Num. Instances	UINT	2
8	Get	Entry Port	UINT	1
9	Get	Port Instance Info	Array of Structure of	1
		Port Type	UINT	
		Port Number	UINT	

Two instances of the Port object are supported. Instance 1 represents the EtherNet/IP port and Instance 2 represents the DeviceNet port.

Table 58 - Port Object Instances

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Port Type	UINT	Inst 1=4; Inst 2=5
2	Get	Port Number	UINT	
3	Get	Link Object	Struct of	
		Path Length	UINT	
		Link Path	Padded EPATH	
4	Get	Port Name	Short String	Inst 1="Port A"; Inst 2="Port B"
5	Get	Port Type Name	Short String	Inst 1="EtherNet/IP"; Inst 2="DeviceNet"
7	Get	Node Address	Padded EPATH	
8	Get	Port Node Range	Struct of	This attribute is implemented for Inst 2 only.
		Min. Node Number	UINT	
		Max. Node Number	UINT	

The following services are implemented.

Table 59 - Port Object Services

Service Code	Implemented for:		Service Name
	Class	Instance	
0x01	Yes	Yes	Get_Attributes_All
0x0E	Yes	Yes	Get_Attribute_Single

TCP/IP Interface Object — CLASS CODE 0xF5

The TCP/IP object supports the following class.

Table 60 - TCP/IP Object Class

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Revision	UINT	3

For single port devices, one instance of the TCP/IP interface object is supported. For dual port devices, two instances of the TCP/IP interface object are supported.

Table 61 - TCP/IP Object Class Instances

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Status	DWORD	
2	Get	Configuration Capability	DWORD	0x00000014
3	Get/Set	Configuration Control	DWORD	0=Configuration from NVS 2=Configuration from DHCP
4	Get	Physical Link Object	Struct of: UINT Padded EPATH	For a single port device: 2 words 20 F6 24 01 (ENet Link Object Inst 1) For dual port device: NULL
5	Get/Set	Interface Configuration	Struct of: UDINT UDINT UDINT UDINT UDINT STRING	IP Address Network Mask Gateway Address Primary DNS Secondary DNS Default domain name for not fully qualified host names
6	Get/Set	Host Name	STRING	
8	Get/Set	TTL Value	USINT	Time to live value for EtherNet/IP multicast packets
9	Get/Set	Multicast Config	Struct of: USINT USINT UINT UDINT	Allocation Control Reserved Number of multicast addresses to allocate (1-4) Multicast starting address

The following common services are implemented for the TCP/IP interface object.

Table 62 - TCP/IP Interface Object Common Services

Service Code	Implemented for:		Service Name
	Class	Instance	
0x01	No	Yes	Get_Attributes_All
0x0E	Yes	Yes	Get_Attribute_Single
0x10	No	Yes	Set_Attribute_Single

Ethernet Link Object — CLASS CODE 0xF6

The following class attributes are supported for the Ethernet Link object.

Table 63 - Ethernet Link Object Class Attributes

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Revision	UINT	1

The following one instance of the Ethernet Link object is supported.

Table 64 - Ethernet Link Object Instance

Attribute ID	Access Rule	Name	Data Type	Value
1	Get	Interface Speed	UDINT	10 or 100 Mbit/sec
2	Get	Interface Flags	DWORD	See ENet/IP Spec
3	Get	Physical Address	ARRAY of 6 USINTs	MAC Address
4	Get	Interface Counters	Struct of: In Octets In Ucast Packets In NUCast Packets In Discards In Errors In Unknown Protos Out Octets Out Ucast Packets Out NUCast Packets Out Discards Out Errors	
5	Get	Media Encounters	Struct of: Alignment Errors FCS Errors Single Collisions SQE Test Errors Deferred Transmits Late Collisions Excessive Collisions MAC Transmit Errors Carrier Sense Errors Frame Too Long MAC Receive Errors	
6	Get/Set	Interface Control	Struct of: Control Bits Forced Interface Speed	
7	Get	Interface Type	USINT	
8	Get	Interface State	USINT	
10	Get	Interface Label	SHORT_STRING	Instance 1: Port 1 Instance 2: Port 2

The following common services are implemented for the Ethernet Link object.

Table 65 - Ethernet Link Object Common Services

Service Code	Implemented for:		Service Name
	Class	Instance	
	No	Yes	Get_Attributes_All
0x0E	Yes	Yes	Get_Attribute_Single
0x10	No	Yes	Set_Attribute_Single

Notes:

A

accessing module data 68
add-on profiles 57
 accessing module data 62
 ControlLogix configuration 57
 EtherNet/IP Network configuration 59
address
 node 39
addressing
 DeviceNet node 39
ADR See automatic device recovery or replace
assembly object 95
assign network parameters 21
automatic device recovery or replace 53
 configuring 53
automation controller communication 57

B

BOOTP/DHCP server
 setting IP network address 21 ... 23
BOOTP/DHCP Utility 21

C

CIP object 93
 assembly 95
 connection manager 102
 device level ring 103
 DeviceNet 94
 Ethernet link 106
 identity 93
 message router 94
 parameter 102
 port 105
 QoS 104
 TCP/IP interface 105
clearance 13
commissioning tool 41
common industrial protocol 93
communication
 automation controller 57
configuration 19
 ControlLogix 57, 63
 device identity 77
 email 76
 EtherNet/IP network 59
connection manager object 102
ControlLogix
 generic configuration 63

D

device identity 77
device level ring 17, 103
device parameters 81

DeviceNet

CIP object 94
 information 93

DeviceNet modules

adding to scan list 44

DeviceNet network

add devices 39

DeviceNet node

commissioning tool 41

DeviceNet node addressing 39**dimensions** 15**DLR** 103**DNS addressing** 27 ... ??**duplicate address detection** ?? ... 26**duplicate IP address**

device conflict 26
 module behavior 26

E

EDS See electronic data sheet
electromagnetic compatibility 92
electronic data sheet 27

download 27
 file information 93
 file installation
 register file 29

email 75

configuration 76
 contents 75
 event notifications 75
 limitations 79
 notifications 75

Ethernet link object 106**EtherNet/IP**

messaging 57

EtherNet/IP modules

set IP network address 20
 setting IP network address 20

F**Features** 13**H****hardware mechanism** 40**I****I/O**

messaging 57

I/O messaging

ControlLogix configuration 57

identity object 93**Installation** 11, 13**Installation and Wiring** 11**Introduction** 11**IP addresses**

duplication address detection ?? ... 26
 set 20
 swapping in redundant systems 26

L**listing**

parameter 81

logic explicit messaging 70**M****master device operation** 87**message router CIP object** 94**messaging**

EtherNet/IP 57
 I/O 57
 logic 70

modes

operation 85
 power-up reset 86
 recoverable error 88
 run 87
 unrecoverable error 88

module data

accessing 62, 68

N**Network** 16**network**

Design 16

network address

DNS addressing 27 ... ??
 set IP network address 20

Network Parameters

assign 21
 assign via web browser 23
 determining 19
 for DNS addressing 20
 MAC Scanner software 23
 other factors 25
 table of 19

node

address basics 40
 DeviceNet node 39
 recommended address 39
 setting address 40

Node Address Selection Switches 20

Last Octet Selection 21

notifications

email 75
 text 75, 78

O**operation**

master device 87
 slave device 87

operation modes 85
 power-up reset 86
 recoverable error 88
 run 87
 unrecoverable error 88
overview 11

Wire 14
Wiring 11, 14
 Diagram 15

P

parameter
 CIP object 102
 configure 49
 device 81
 edit 49
 listing 81
 programming 81
 view 49
port object 105
ports 16
programming parameters 81

Q

QoS object 104

R

ratings 91
Ring Ethernet Topology 16, 17

S

scan list
 adding DeviceNet modules 44
 simple addition method 45
 user-defined addition method 46
set IP network address 20
 BOOTP/DHCP server 21 . . . 23
 RSLinx or RSLogix 5000 20
 thumbwheel switch 20
slave device operation 87
specifications 14, 91
Star Ethernet Topology 16
Star EthernetSee **Star Ethernet Topology**
swap IP addresses 26

T

TCP/IP interface object 105
text notifications 78
thumbwheel switch
 set IP network address 20
torque 14
troubleshooting 85
 procedures 88

W

web server 32

Rockwell Automation Support

Use the following resources to access support information.

Technical Support Center	Knowledgebase Articles, How-to Videos, FAQs, Chat, User Forums, and Product Notification Updates.	https://rockwellautomation.custhelp.com/
Local Technical Support Phone Numbers	Locate the phone number for your country.	http://www.rockwellautomation.com/global/support/get-support-now.page
Direct Dial Codes	Find the Direct Dial Code for your product. Use the code to route your call directly to a technical support engineer.	http://www.rockwellautomation.com/global/support/direct-dial.page
Literature Library	Installation Instructions, Manuals, Brochures, and Technical Data.	http://www.rockwellautomation.com/global/literature-library/overview.page
Product Compatibility and Download Center (PCDC)	Get help determining how products interact, check features and capabilities, and find associated firmware.	http://www.rockwellautomation.com/global/support/pcdc.page

Documentation Feedback

Your comments will help us serve your documentation needs better. If you have any suggestions on how to improve this document, complete the How Are We Doing? form at http://literature.rockwellautomation.com/idc/groups/literature/documents/du/ra-du002_-en-e.pdf.

Rockwell Automation maintains current product environmental information on its website at <http://www.rockwellautomation.com/rockwellautomation/about-us/sustainability-ethics/product-environmental-compliance.page>.

Allen-Bradley, ControllLogix, Rockwell Software, Rockwell Automation, RSLogix, and TechConnect are trademarks of Rockwell Automation, Inc.

Trademarks not belonging to Rockwell Automation are property of their respective companies.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat:6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Rockwell Automation Publication 193-UM014C-EN-P - August 2016

Supersedes Publication 193-UM014B-EN-P - December 2011 - March 2009

Copyright © 2016 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.