



RJ5061 61 key Multi-function Keyboard

User Guide

Important Information

Be sure to obey the following information so as not to harm yourself or others or damage this instrument or other external equipment.

Power adapter:

- Please use only the specified AC adapter supplied with the product. An incorrect or faulty adapter can cause damage to the electronic keyboard.
- Do not place the AC adapter or power cord near to any source of heat such as radiators or other heaters.
- To avoid damaging the power cord, please ensure that heavy objects are not placed on it and that it is not subject to stress or over bending.
- Check the power plug regularly and ensure it is free from surface dirt. Do not insert or unplug the power cord with wet hands.

Do not open the body of the electronic keyboard:

- Do not open the electronic keyboard or try to disassemble any part of it. If the device is not functioning correctly, please stop using it and send it to a qualified service agent for repair.

Use of the electronic keyboard:

- To avoid damaging the appearance of the electronic keyboard or damaging the internal parts please do not place the electronic keyboard in a dusty environment, in direct sunlight or in places where there are very high or very low temperatures.
- Do not place the electronic keyboard on an uneven surface. To avoid damaging internal parts do not place any vessel holding liquid onto the electronic keyboard as spillage may occur.

Maintenance:

- To clean the body of the electronic keyboard wipe it with a dry, soft cloth only.

Connection:

- To prevent damage to the speaker of the electronic keyboard please adjust the volume of any peripheral device to the lowest setting and gradually adjust the volume accordingly to an appropriate level once the music is playing.

During operation:

- Do not use the keyboard at the loudest volume level for a long period.
- Do not place heavy objects onto the keyboard or press the keyboard with undue force.
- The packaging should be opened by a responsible adult only and any plastic packaging should be stored or disposed of appropriately.

Specification

- Specifications are subject to change without notice.


Contents

Important Information	1
Controls, Indicators and External Connections	4
Front Panel	4
External Connections.....	5
LED Display	5
Preparation Before First Use	6
Stand Assembly	6
Power	7
Use of AC/DC power adapter:	7
Battery operation:.....	7
Auto power off:	7
Jacks and Accessories	7
Using headphones:	7
Connecting an Amplifier or Hi-Fi Equipment:	8
Connecting a phone or audio device to the AUX Input to play music through the keyboard:	8
Connecting a Microphone:	9
Playing MP3 Music Files from a USB Memory Stick:.....	9
Keyboard Operation	10
Power and Volume	10
Power control:	10
Adjustment of the Master Volume:.....	10
Tone.....	11
Tone Selection:	11
Effect & Control.....	11
Split Keyboard:.....	11
Sustain:	12
Vibrato:.....	12
Transpose:	12
Metronome:	13
Panel Percussion Instruments:	13
Using the Pitch Wheel:.....	14
Rhythm	15

Selecting the rhythm:	15
Start / Stop:	15
Sync:	15
Fill in:.....	16
Accompaniment Volume Adjustment:	16
Tempo Adjustment:.....	16
Chord Accompaniment	17
Single Finger Chords:	17
Fingered Chords:	17
Chord Tone:	17
Intro / Ending	18
Recording Function.....	18
Rhythm Programming.....	19
Demo Songs	19
Setting Memories M1 and M2.....	19
Teaching Modes	20
Beginner Course:	20
Intermediate Course:	20
Advanced Course:	20
Progressive Learning:	21
Appendix I. Percussion Instruments	21
Appendix II. Rhythm Table	22
Appendix III. Tone Table	22
Appendix IV. Demo Song Table	23
Appendix V. Troubleshooting	24
Appendix VI. Chord Tables.....	25
Single Finger Chords	25
Fingered Chords	26
Appendix VII. Technical Specification.....	27
FCC Compliance Statement.....	28
FCC Class B Part 15	28
Product Disposal Instructions (European Union).....	28


Controls, Indicators and External Connections

Front Panel




- | | | |
|------------------------------|----------------------|---------------------------|
| 1. Stereo Speakers | 15. Memory Storage 1 | 29. Number Buttons |
| 2. Power Switch | 16. Memory Storage 2 | 30. Demo |
| 3. Sync | 17. Play/Pause | 31. Program |
| 4. Single Finger Chords | 18. Previous Track | 32. Rhythms |
| 5. Fingered Chords | 19. Next Track | 33. Playback |
| 6. Chord Tone | 20. Music Volume - | 34. Tones |
| 7. Split keyboard | 21. Music Volume + | 35. Record |
| 8. Fill In | 22. Start/Stop | 36. Keyboard Playing Area |
| 9. Main Volume +/- | 23. Metronome | 37. Chord Keyboard Area |
| 10. Accompaniment Volume +/- | 24. Vibrato | 38. Pitch Wheel |
| 11. Transpose +/- | 25. Sustain | 39. Tones List |
| 12. Tempo [Fast/Slow] | 26. Teach 1 | 40. LED Screen |
| 13. Intro/Ending | 27. Teach 2 | 41. Rhythms List |
| 14. Memory | 28. Teach 3 | |

External Connections



1. USB Input (For MP3 Playback)
2. AUX IN (For Music Playback)
3. MIC Input (For Electret Microphone)
4. Headphone Output
5. DC 9V Power Input

LED Display




1. 3-Digit LED Display

Preparation Before First Use

Stand Assembly


Please first assemble the stand using the screws and allen key supplied. The keyboard can then be secured to the stand using the straps and screws connected to the top bars.



Power

Use of AC/DC power adapter:

Please use the AC/DC power adapter that came with the electronic keyboard or a power adapter with DC 9V output voltage and 500mA output current with a centre positive plug. Connect the DC plug of the power adapter into the DC 9V power socket on the rear of the keyboard and then connect the other end into the mains wall socket and switch on.



Caution: When the keyboard is not in use you should unplug the power adapter from the mains power socket.

Battery operation:

Open the battery lid on the underneath of the electronic keyboard and insert 6 x 1.5V Size AA alkaline batteries. Ensure the batteries are inserted with the correct polarity and replace the battery lid.

Caution: Do not mix old and new batteries. Do not leave batteries in the keyboard if the keyboard is not going to be used for any length of time. This will avoid possible damage caused by leaking batteries.


Auto power off:

The keyboard has a power save function that switches the keyboard off after a period of around 4 to 5 minutes when not being played. Press the power on / off button to switch back on.

Jacks and Accessories


Using headphones:

Connect the 3.5mm headphone plug into the [PHONES] jack on the rear of the keyboard. The internal speaker will cut off automatically once headphones are connected.




Connecting an Amplifier or Hi-Fi Equipment:

This electronic keyboard has a built in speaker system but it can be connected to an external amplifier or other hi-fi equipment. First turn off the power to the keyboard and any external equipment you are looking to connect. Next insert one end of a stereo audio cable (not included) into the LINE IN or AUX IN socket on the external equipment and connect the other end into the [PHONES] jack on the rear of the electronic keyboard.




Connecting a phone or audio device to the AUX Input to play music through the keyboard:

This keyboard has a built-in speaker system that can be used to play music from your phone or mobile device. Insert one end of a stereo audio cable into the AUX IN socket on the back of the keyboard and connect the other end into your phone or audio device. Make sure the keyboard is switched on. Use the volume control of the phone to control the music volume. AUX in cable not included.




Connecting a Microphone:

Connect the 3.5mm microphone plug into the [MIC] jack on the rear of the keyboard. Note that the keyboard requires an electret or condenser microphone, not supplied.



Playing MP3 Music Files from a USB Memory Stick:

Insert the USB memory stick into the USB input at the rear of the keyboard. Press the PLAY/PAUSE key to start and stop the music playback. Once the music has started playing you can skip forward and backward through the MP3 tracks by pressing the control buttons. Adjust the volume of the music playback with the VOL - and + keys. Use the keys on the keyboard to play along.




Keyboard Operation

Power and Volume


Power control:

Press the [POWER] button to turn the power on and again to turn the power off. The LED display will light to indicate power on.



Adjustment of the Master Volume:


The keyboard has 16 levels of volume from V00(off) - V15. To change the volume, press the [VOLUME ▲/▼] buttons. The volume level is indicated by the LED display. Pressing both the [VOLUME ▲/▼] buttons at the same time will make the Main Volume return to the default level (level V10). The main volume level will revert to level V10 after power off and on.



Tone

Tone Selection:


When the keyboard is switched on the default TONE is "t00" Grand Piano. To change the tone, press the [TONE] button first and then directly input the number code on the keypad by pressing the corresponding digits 0-9. The tones can also be changed by using the + / - buttons. Refer to Appendix III for a list of the available tones.



Effect & Control

Split Keyboard:

To switch on Split Keyboard mode press the [SPLIT] button, the LED will show [SPL]. The keyboard will split into two keyboards at the 24th key from the left. You can adjust the TONE of the right hand side of the keyboard by pressing the corresponding digits 0-9 on the numerical keypad. The TONE of the left hand side of the keyboard will remain set to the tone chosen before the Split Keyboard mode was entered. In Split Keyboard mode the pitch of the left hand keys are raised by one octave and the right hand keys lowered by one octave. Press the [SPLIT] button again to exit Split Keyboard mode.



Sustain:

Press the [SUSTAIN] button to enter Sustain mode. The LED display will briefly display [SUS] to indicate sustain is on. Once this mode is selected the sound of each note played is prolonged. Pressing the [SUSTAIN] button again will turn the sustain feature off and exit this mode.




Vibrato:

Press the [VIBRATO] button to enter Vibrato mode. The LED display will briefly display [Vib] to indicate that vibrato is on. Once this mode is selected each time a note is played a trembling effect is added to the the note. Pressing the [VIBRATO] button again will turn the Vibrato feature off and exit this mode.




Transpose:

Pressing the [TRANPOSE ▲ /▼] buttons alters the musical scale of the note being played. You can adjust the scale by 6 levels upwards or downwards. Pressing both the [TRANPOSE ▲ /▼] buttons at the same time will make the musical scale revert to 00. The transpose level will be reset to 00 after power off and on.




Metronome:

Press the [METRONOME] button to start the tick-tock beat. There are four beats to choose from. Depending on what the performance needs, you can press the [TEMPO ▲ /▼] buttons to speed up or slow down. Press the [METRONOME] button repeatedly to cycle through to the required beat pattern. The LED display will indicate the beat you have chosen. The metronome effect is added to the music once you start playing. To exit this mode press the [START/STOP] or [METRONOME] button again.




Panel Percussion Instruments:

To access the Percussion sounds, press the [TONE] button first and then select tone number 128 on the keypad. Once the tone has been selected the keyboard's keys turn into percussion instruments and play the percussion sounds accordingly. Refer to Appendix I. for a table showing the percussion sounds available.



Using the Pitch Wheel:


Use the Pitch bend wheel to adjust the pitch of a note up or down for a continuous pitch variation between notes. This feature can help recreate an authentic playing sound for sounds such as strings and trombone where the original instrument can slide up between notes. It is also a common tool used for synthesiser compositions.



Rhythm

Selecting the rhythm:

You can choose from any of the 200 built in rhythms. Please refer to Appendix II. for the detailed rhythm table. Press the [RHY] button to enter the rhythm selection function. The LED display will show the current rhythm number. You can select the rhythm you require by pressing the corresponding digits on the numerical keypad or by pressing the + / - buttons.




Start / Stop:

Press the [START / STOP] button to play the rhythm selected. Press the [START / STOP] button again to stop the rhythm playback




Sync:

Press the [SYNC] button to select the sync accompaniment function. Pressing any of the first 19 keys on the left hand side of the keyboard will start the rhythm playing. Press the [START / STOP] button to stop the rhythm and exit the sync function.




Fill in:

You can fill in a length of interlude if you press the [FILL IN] button during the rhythm playback. After the fill in, the rhythm will continue playing as normal.




Accompaniment Volume Adjustment:

The Accompaniment Volume can be adjusted by pressing the [ACCOMP VOLUME ▲/▼] buttons. The LED display will show the volume as you are adjusting it. The adjustment range has 16 levels which are displayed as 000 – 015 and indicated by the LED display. Pressing both the [ACCOMP VOLUME ▲/▼] buttons at the same time will make the Accompaniment Volume return to the default level (level 010). The Main Volume control will also affect the output level of the accompaniment. At power on the accompaniment volume will reset to the default level.



Tempo Adjustment:


Press and hold the [TEMPO ▲/▼] buttons to adjust the playing tempo of the rhythm, metronome and demo song. The adjustment range is 30-240 bpm. Pressing both the [TEMPO ▲/▼] buttons at the same time will make the tempo revert to the default tempo for the rhythm selected. At power on the tempo will revert to 120 bpm.



Chord Accompaniment

Single Finger Chords:

Press the [SINGLE] button to activate the single finger chord function. The LED screen will display [C-1] Chords are played by pressing certain keys in the chord area on the left hand side of the keyboard (keys 1-19). The finger patterns required are shown in Appendix VI. Press the [START / STOP] button to start or stop the chord accompaniment. Press the [SINGLE] button again to exit single finger chord mode.



Fingered Chords:

Press the [FINGERED] button to activate the fingered chord function. The LED screen will display [C-2] Chords are played by pressing certain keys in the chord area on the left hand side of the keyboard (keys 1-19). The finger patterns required are shown in Appendix VI. Press the [START / STOP] button to start or stop the chord accompaniment. Press the [FINGERED] button again to exit fingered chord mode.

Note that no sound will be produced unless the correct finger patterns are formed.




Chord Tone:

In either fingered or single finger chord mode, press the [CHORD TONE] button repeatedly to select the desired chord tone. There are 7 chord tones to choose from, indicated on the LCD as [00] to [06]. The chord tone is reset to [00] after power off / on.




Intro / Ending

Press the [INTRO / END] button to enable the intro section, the display will show [int]. When the intro finishes playing, accompaniment shifts to the main section. Press [INTRO / END] button again to enable the ending section, the display will show [End]. When the ending is finished, the auto accompaniment stops automatically.




Recording Function

Press the [REC] button to enter the recording mode. The LED will indicate that the recording function is on by showing [rEC] on the LED display. Press any key to start recording. The maximum recording capacity is 46 notes. When the recording capacity is full the LED display will show [FUL]. Each time you press the [REC] button, the previous memory will be cleared and the keyboard will enter the recording mode again.




Press the [PLAY] button to play back the recorded notes.




Rhythm Programming

Press the [PROG] button to activate the Rhythm Program mode. The LED will indicate that the rhythm program function is on by showing [Pr9]. You can then play the keyboard and record your percussion track (up to 46 percussion beats). To listen to your piece press the [PLAY] button and the keyboard will playback your edited percussions. You can then play along to your recorded percussion. You can also adjust the speed of the playback using the [TEMPO ▲ /▼] buttons. To cancel the Programming mode, press the [PROG] button again.



Demo Songs

Press the [DEMO] button to play a demo song. The LED display will show [dXX] where XX is the number of the demo song, from 00 to 39. By pressing the + and - button on the numerical keypad you can choose the demo song you require. There are 40 demo songs to choose from in total. The keyboard will finish the chosen song and then play the next song. Press the [DEMO] button again to exit the demo mode. Refer to Appendix IV. for a list of the available Demo songs.



Setting Memories M1 and M2

The keyboard has two built in memories for saving specific tones, rhythms, and tempos. Before performing, select the TONE, RHYTHM and TEMPO you wish to use. While holding the [MEM] button, press the [M1] or [M2] button to store the settings, the LED display will show [S1] or [S2] and this will save the keyboard settings to that memory. You can access the stored settings by pressing the [M1] or [M2] buttons before performing, the LED display will show [n1] or [n2].


Note that the M1 and M2 memories will be cleared after the keyboard is switched off and back on again.



Teaching Modes

Beginner Course:

Press the [TEACH 1] button to enter the Beginner Course teaching mode. This mode is suitable for beginners to familiarise themselves with the rhythm and tempo of the song. The LED display will show [dXX] where XX is the number of the song selected, from 00 to 39 (refer to Appendix IV for the list of songs). Use the keypad or + - keys to select the desired song. The beat point will flash on the LED display to indicate the tempo. The LED display will indicate which key should be pressed, for example C 6. Use the key stickers provided with the keyboard applied to the keys in order to know which key to press. The keyboard will play the main melody in time with any key presses, even incorrect ones.



Intermediate Course:

Press the [TEACH 2] button to enter the Intermediate Course teaching mode. This mode is suitable for intermediate users. The LED display will show [d00] where XX is the number of the song selected, from 00 to 39 (refer to Appendix IV for the list of songs). Use the keypad or + - keys to select the desired song. The beat point will flash on the LED display to indicate the tempo. The LED display will indicate which key should be pressed, for example C 6. Once the correct key has been pressed it will then move onto the next section of the song. Use the key stickers provided with the keyboard applied to the keys in order to know which key to press.


Advanced Course:

Press the [TEACH 3] button to enter the advanced Course teaching mode. This mode is suitable for more advanced users. The LED display will show [d00] where XX is the number of the song selected, from 00 to 39 (refer to Appendix IV for the list of songs). Use the keypad or + - keys to select the desired song. The beat point will flash on the LED display to indicate the tempo. The LED display will show which key should be pressed, for example C 6. Use the key stickers provided and press the specified keys as the main melody plays. Note that the song will carry on playing even if an incorrect key is pressed.

Progressive Learning:

- In general, follow the sequence below to master any of the included songs.
- Listen to the song in DEMO mode to get an idea of the note timings and beat. When confident move on to the next stage.
- Access the same song in Beginner Course mode (TEACH 1) and duplicate the note timings and key presses. When mastered move onto the Intermediate Course (TEACH 2) and then the Advanced course (TEACH 3).

Appendix I. Percussion Instruments



61 Percussion Sounds									
C2	C# 2	D2	D# 2	E2	F2	F# 2	G2	G# 2	A2
A# 2	B2	C3	C# 3	D3	D# 3	E3	F3	F# 3	G3
G# 3	A3	A# 3	B3	C4	C# 4	D4	D# 4	E4	F4
F# 4	G4	G# 4	A4	A# 4	B4	C5	C# 5	D5	D# 5
E5	F5	F# 5	G5	G# 5	A5	A# 5	B5	C6	C# 6
D6	D# 6	E6	F6	F# 6	E6	G # 6	A6	A# 6	B6
C7									

Appendix II. Rhythm Table

No.	Rhythm Name	No.	Rhythm Name
00	Mambo	18	Cha Cha
01	16 Beat	19	Salsa
02	Waltz	20	Brazil Mambo
03	Rhumba	21	POP 8 Beat
04	Reggae	22	POP Mambo
05	Rock	23	Smooth Country
06	Slow Rock	24	POP Reggae
07	Bossanova	25	Lieder Mambo
08	Disco	26	Hard 8 Beat
09	Tango	27	Country Bossanova
10	Country	28	Hard Mambo
11	Pop	29	Bluegrass Tango
12	Beguine	30	South Country
13	Latin	31	Lieder POP
14	March Polka	32	Bluegrass Beguine
15	Samba	33	Rock Latin
16	Swing	34-199	Popular Rhythms
17	8 Beat		

Appendix III. Tone Table

No.	Tone Name	No.	Tone Name
00	Piano	18	String
01	Vibraphone	19	Soft Crystal
02	Church Organ	20	Koto FX
03	Reed Organ1	21	Reed Organ2
04	Electric Guitar1	22	Drawbar Organ1
05	Electric Guitar2	23	Drawbar Organ2
06	Electric Bass	24	Digital Piano
07	Synth Bass	25	The Strings
08	Violin	26	Sweet Harmonica
09	Orchestral Harp	27	Synth Strings
10	String Ensemble	28	Chorus
11	Soprano Sax	29	Square Lead
12	Clarinet	30	Mandolin
13	Flute	31	Marimba
14	Lead	32	Bright Crystal
15	Alto Sax	33	Lyric Crystal
16	Crystal FX	34-199	Popular Tones
17	Rotary Organ		

Appendix IV. Demo Song Table

















































No.	Name of Song	No.	Name of Song
00	Lambada	20	Fur Elise
01	Mozart piano sonata	21	Mary had a little lamb
02	Let it go	22	If you're happy and you know it
03	Passionate	23	Dream wedding
04	Music box dancer	24	He's got the whole world in his hands
05	Canon	25	A maiden's prayer
06	Brown	26	Spanish guitar
07	The cherry blossom	27	Greensleeves
08	Come back	28	Rainstorm
09	Dream	29	Bagpipe
10	Amazing Grace	30	Classical concert
11	Flight of the bumble bee	31	Imperial garden
12	Happy birthday to you	32	Carcassi etude, op. 60, no. 3
13	Twinkle twinkle little star	33	A state of mind
14	The cherry tree	34	Italian polka
15	Four seasons spring march	35	The fountain
16	Heipanpo	36	Cuckoo waltz
17	Loch Lomond	37	Clementine sonata
18	Red river valley	38	Chopin nocturnes
19	Serenade - Haydn	39	Mozart sonata k 284

Appendix V. Troubleshooting

Problem	Possible Reason / Solution
A faint noise is heard when turning the power on or off.	This is normal and nothing to worry about.
After turning the power on to the keyboard there was no sound when the keys were pressed.	Check the master volume is set to the correct volume. Check that headphones or any other equipment are not plugged into the keyboard as these will cause the built-in speaker system to cut off automatically. Check that fingered chord mode is not selected. Incorrect key presses in fingered chord mode will not produce any sound.
Sound is distorted or interrupted and the keyboard is not working properly.	Use of incorrect power adapter. Use the power adapter supplied or the batteries may need replacing.
There is a slight difference in timbre of some notes.	This is normal and is caused by the many different voice sampling ranges of the keyboard.
When using the sustain function some tones have long sustain and some short sustain.	This is normal. The best length of sustain for different tones has been pre-set.
The main volume or accompaniment volume is not right.	Check that the main (master) volume and accompaniment volume are set correctly. Note that the main volume also affects the accompaniment volume.
In SYNC status the auto accompaniment does not work.	Check to make sure that Chord mode has been selected and then play a note from the first 19 keys on the left hand side of the keyboard.
The pitch of the note is not correct	Check that the transpose is set to 00.
The keyboard switches off unexpectedly	This is not a fault. The keyboard has a power save function that switches the keyboard off after a period of not being played. Press the power on / off button to switch back on.
The left side keys (first 19 keys) make no sound	Check that FINGERED CHORD mode has not been selected. Note a sound will only be produced when a correct chord pattern is played. Refer to Appendix VI., Fingered Chords.

Appendix VI. Chord Tables

Single Finger Chords

	M	m	7	m7
C				
D				
D				
E				
E				
F				
F#				
G				
G#				
A				
B				
B				

Fingered Chords

CHORD ROOT	M	m	7	m7
C				
C#/(Db)				
D				
(D#)/Eb				
E				
F				
F#/(Gb)				
G				
(G#)/Ab				
A				
(A#)/Bb				
B				

Appendix VII. Technical Specification

- **Display**
LED Display, 3-Digit
- **Tone**
200 unique tones
- **Rhythm**
200 unique rhythms
- **Demo**
40 different demo songs
- **Effect and Control**
Split keyboard, Sustain, Vibrato, Transpose, Pitch bend
- **Chords**
Single Finger mode, Fingered mode, 7 Chord tones
- **Recording and Programming**
46 Note record memory, Playback, 46 Beat rhythm programming
- **Percussion**
12 different instruments
- **Accompaniment Control**
Start / Stop, Sync, Fill in, Intro/Ending, Tempo
- **Intelligent Teaching**
Metronome, 3 Teaching modes
- **External Jacks**
Power input, Headphone output, Microphone Input (Electret), AUX Input, USB MP3 playback
- **Diapason (Range of Keyboard)**
C2- C7 (61 keys)
- **Intonation**
<3cent
- **Weight**
3.2 kg
- **Power Adapter**
DC9V, 500mA
- **Output Power**
2 W x 2
- **Accessories included**
Power adapter, Sheet music stand, Keyboard stand, Stool, Headphones, User guide, Key stickers

FCC Compliance Statement

FCC Class B Part 15

This device complies with Part 15 of the Federal Communications Commission (FCC) Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference.

This device must accept any interference received, including interference that may cause undesired operation.

CAUTION:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the manufacturer's instructions, may cause interference harmful to radio communications.

There is no guarantee, however, that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio or TV technician for help.

Product Disposal Instructions (European Union)

The symbol shown here and on the product, means that the product is classed as Electrical or Electronic Equipment and should not be disposed with other household or commercial waste at the end of its working life. The Waste Electrical and Electronic Equipment (WEEE) Directive (2012/19/EU) has been put in place to encourage the recycling of products using best available recovery and recycling techniques to minimise the impact on the environment, treat any hazardous substances and avoid the increase of landfill. When you have no further use for this product, please dispose of it using your local authority's recycling processes. For more information please contact your local authority or the retailer where the product was purchased.



PDT Ltd.

Unit 4B, Greengate Industrial Estate, White Moss View, Middleton, Manchester,
M24 1UN, United Kingdom - info@pdtuk.com - Copyright PDT Ltd. © 2020