
# **\*YAMAHA**

DIGITAL KEYBOARD

# **OWNER'S MANUAL**

## EZ-300



Before using the instrument, be sure to read "PRECAUTIONS" on pages 5-7.













### **FCC INFORMATION (U.S.A.)**

by the interference.

- 1. IMPORTANT NOTICE: DO NOT MODIFY THIS UNIT!
  - This product, when installed as indicated in the instructions contained in this manual, meets FCC requirements. Modifications not expressly approved by Yamaha may void your authority, granted by the FCC, to use the product.
- 2. IMPORTANT: When connecting this product to accessories and/or another product use only high quality shielded cables. Cable/s supplied with this product MUST be used. Follow all installation instructions. Failure to follow instructions could void your FCC authorization to use this product in the USA.
- 3. NOTE: This product has been tested and found to comply with the requirements listed in FCC Regulations, Part 15 for Class "B" digital devices. Compliance with these requirements provides a reasonable level of assurance that your use of this product in a residential environment will not result in harmful interference with other electronic devices. This equipment generates/uses radio frequencies and, if not installed and used according to the instructions found in the users manual, may cause interference harmful to the operation of other electronic devices. Compliance with FCC regulations does not guarantee

that interference will not occur in all installations. If this product is found to be the source of interference, which can be determined by turning the unit "OFF" and "ON", please try to eliminate the problem by using one of the following measures: Relocate either this product or the device that is being affected

Utilize power outlets that are on different branch (circuit breaker or fuse) circuits or install AC line filter/s.

In the case of radio or TV interference, relocate/reorient the antenna. If the antenna lead-in is 300 ohm ribbon lead, change the lead-in to co-axial type cable.

If these corrective measures do not produce satisfactory results, please contact the local retailer authorized to distribute this type of product. If you can not locate the appropriate retailer, please contact Yamaha Corporation of America, Electronic Service Division, 6600 Orangethorpe Ave, Buena Park,

The above statements apply ONLY to those products distributed by Yamaha Corporation of America or its subsidiaries.

(class B)

### COMPLIANCE INFORMATION STATEMENT (Supplier's declaration of conformity procedure)

Responsible Party: Yamaha Corporation of America

Address: 6600 Orangethorpe Ave., Buena Park, Calif. 90620

Telephone: 714-522-9011 Type of Equipment: Digital Keyboard Model Name: EZ-300

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) this device may not cause harmful interference, and
- 2) this device must accept any interference received including interference that may cause undesired operation.

(FCC SDoC)

<sup>\*</sup> This applies only to products distributed by Yamaha Corporation of America.

This applies only to products distributed by Yamaha Corporation of America.

The model number, serial number, power requirements, etc., may be found on or near the name plate, which is at the bottom of the unit. You should note this serial number in the space provided below and retain this manual as a permanent record of your purchase to aid identification in the event of ťheft.

Model No.

Serial No.

(bottom en 01)

### For the AC adaptor



# **Explanation of Graphical Symbols**



The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

## IMPORTANT SAFETY INSTRUCTIONS

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8 Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 10 Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.

- 11 Only use attachments/accessories specified by the manufacturer.
- 12 Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- 13 Unplug this apparatus during
- lightning storms or when unused for long periods of time
- 14 Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

#### WARNING

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE.

(UL60065\_03)

# **PRECAUTIONS**

### PLEASE READ CAREFULLY BEFORE PROCEEDING

Please keep this manual in a safe and handy place for future reference.

### For the AC adaptor



### **WARNING**

- This AC adaptor is designed for use with only Yamaha electronic instruments. Do not use for any other purpose.
- · Indoor use only. Do not use in any wet environments.



### **CAUTION**

• When setting up, make sure that the AC outlet is easily accessible. If some trouble or malfunction occurs, immediately turn off the power switch of the instrument and disconnect the AC adaptor from the outlet. When the AC adaptor is connected to the AC outlet, keep in mind that electricity is flowing at the minimum level, even if the power switch is turned off. When you are not using the instrument for a long time, make sure to unplug the power cord from the wall AC outlet.

### For the instrument



### WARNING

Always follow the basic precautions listed below to avoid the possibility of serious injury or even death from electrical shock, short-circuiting, damages, fire or other hazards. These precautions include, but are not limited to, the following:

### Power supply/AC adaptor

- Do not place the power cord near heat sources such as heaters or radiators. Also, do not excessively bend or otherwise damage the cord, or place heavy objects on it.
- Only use the voltage specified as correct for the instrument. The required voltage is printed on the name plate of the instrument.
- Use the specified adaptor (page 94) only. Using the wrong adaptor can result in damage to the instrument or overheating.
- Check the electric plug periodically and remove any dirt or dust which may have accumulated on it.

### Do not open

This instrument contains no user-serviceable parts. Do not open
the instrument or attempt to disassemble or modify the internal
components in any way. If it should appear to be malfunctioning,
discontinue use immediately and have it inspected by qualified
Yamaha service personnel.

### Water warning

- Do not expose the instrument to rain, use it near water or in damp
  or wet conditions, or place on it any containers (such as vases,
  bottles or glasses) containing liquids which might spill into any
  openings. If any liquid such as water seeps into the instrument,
  turn off the power immediately and unplug the power cord from
  the AC outlet. Then have the instrument inspected by qualified
  Yamaha service personnel.
- · Never insert or remove an electric plug with wet hands.

### Fire warning

 Do not put burning items, such as candles, on the unit. A burning item may fall over and cause a fire.

### **Battery**

- Follow the precautions below. Failure to do so might result in explosion, fire, overheating or battery fluid leakage.
  - Do not tamper with or disassemble batteries.
  - Do not dispose of batteries in fire.

- Do not attempt to recharge batteries that are not designed to be charged.
- Keep the batteries separate from metallic objects such as necklaces, hairpins, coins, and keys.
- Use the specified battery type (page 94) only.
- Use new batteries, all of which are the same type, same model, and made by the same manufacturer.
- Always make sure all batteries are inserted in conformity with the +/- polarity markings.
- When the batteries run out, or if the instrument is not to be used for a long time, remove the batteries from the instrument.
- When using Ni-MH batteries, follow the instructions that came with the batteries. Use only the specified charger device when charging.
- Keep batteries away from small children who might accidentally swallow them.

 If the batteries do leak, avoid contact with the leaked fluid. If the battery fluid should come in contact with your eyes, mouth, or skin, wash immediately with water and consult a doctor. Battery fluid is corrosive and may possibly cause loss of sight or chemical burns.

### If you notice any abnormality

- When one of the following problems occur, immediately turn off
  the power switch and disconnect the electric plug from the outlet.
  (If you are using batteries, remove all batteries from the
  instrument.) Then have the device inspected by Yamaha service
  personnel.
  - The power cord or plug becomes frayed or damaged.
  - It emits unusual smells or smoke.
  - Some object has been dropped into the instrument.
  - There is a sudden loss of sound during use of the instrument.
  - If any cracks or breakages exist on the instrument.



### **CAUTION**

Always follow the basic precautions listed below to avoid the possibility of physical injury to you or others, or damage to the instrument or other property. These precautions include, but are not limited to, the following:

### Power supply/AC adaptor

- Do not connect the instrument to an electrical outlet using a multiple-connector. Doing so can result in lower sound quality, or possibly cause overheating in the outlet.
- When removing the electric plug from the instrument or an outlet, always hold the plug itself and not the cord. Pulling by the cord can damage it.
- Remove the electric plug from the outlet when the instrument is not to be used for extended periods of time, or during electrical storms.

### Location

- Do not place the instrument in an unstable position where it might accidentally fall over.
- Before moving the instrument, remove all connected cables, to prevent damage to the cables or injury to anyone who might trip over them.
- When setting up the product, make sure that the AC outlet you are
  using is easily accessible. If some trouble or malfunction occurs,
  immediately turn off the power switch and disconnect the plug
  from the outlet. Even when the power switch is turned off,
  electricity is still flowing to the product at the minimum level.
   When you are not using the product for a long time, make sure to
  unplug the power cord from the wall AC outlet.

 Use only the stand specified for the instrument. When attaching it, use the provided screws only. Failure to do so could cause damage to the internal components or result in the instrument falling over.

### **Connections**

- Before connecting the instrument to other electronic components, turn off the power for all components. Before turning the power on or off for all components, set all volume levels to minimum.
- Be sure to set the volumes of all components at their minimum levels and gradually raise the volume controls while playing the instrument to set the desired listening level.

### **Handling caution**

- . Do not insert a finger or hand in any gaps on the instrument.
- Never insert or drop paper, metallic, or other objects into the gaps on the panel. This could cause physical injury to you or others, damage to the instrument or other property, or operational failure.
- Do not rest your weight on, or place heavy objects on the instrument, and do not use excessive force on the buttons, switches or connectors.
- Do not use the instrument/device or headphones for a long period
  of time at a high or uncomfortable volume level, since this can
  cause permanent hearing loss. If you experience any hearing loss
  or ringing in the ears, consult a physician.

Yamaha cannot be held responsible for damage caused by improper use or modifications to the instrument, or data that is lost or destroyed.

Always turn the power off when the instrument is not in use.

Even when the [ the standby/On) switch is in standby status (display is off), electricity is still flowing to the instrument at the minimum level.

When you are not using the instrument for a long time, make sure you unplug the power cord from the wall AC outlet.

Make sure to discard used batteries according to local regulations.

### NOTICE

To avoid the possibility of malfunction/ damage to the product, damage to data, or damage to other property, follow the notices below.

### ■ Handling

- Do not use the instrument in the vicinity of a TV, radio, stereo equipment, mobile phone, or other electric devices. Otherwise, the instrument, TV, or radio may generate noise. When you use the instrument along with an application on your smart device such as a smartphone or tablet, we recommend that you set "Airplane Mode" to on on that device in order to avoid noise caused by communication.
- Depending on the condition of surrounding radio waves, the instrument may possibly malfunction.
- Do not expose the instrument to excessive dust or vibrations, or extreme cold or heat (such as in direct sunlight, near a heater, or in a car during the day) to prevent the possibility of panel disfiguration, damage to the internal components or unstable operation. (Verified operating temperature range: 5° – 40°C, or 41° – 104°F.)
- Do not place vinyl, plastic or rubber objects on the instrument, since this might discolor the panel or keyboard.
- Do not press the LCD screen with your finger because it is a sensitive, precision-made part. Doing so might cause an appearance abnormality, such as a stripe on the LCD, although this abnormality should disappear again within a short time.

### ■ Maintenance

 When cleaning the instrument, use a soft cloth. Do not use paint thinners, solvents, alcohol, cleaning fluids, or chemical-impregnated wiping cloths.

### ■ Saving data

 Some of the data of this instrument (page 59) are retained when the power is turned off. However, the saved data may be lost due to some failure, an operation mistake, etc. Save your important data onto an external device such as a computer (page 57).

### Information

### ■ About copyrights

- Copying of the commercially available musical data including but not limited to MIDI data and/or audio data is strictly prohibited except for your personal use.
- This product incorporates and bundles contents in which Yamaha owns copyrights or with respect to which Yamaha has license to use others' copyrights. Due to copyright laws and other relevant laws, you are NOT allowed to distribute media in which these contents are saved or recorded and remain virtually the same or very similar to those in the product.
  - \* The contents described above include a computer program, Accompaniment Style data, MIDI data, WAVE data, voice recording data, a score, score data, etc.
  - \* You are allowed to distribute medium in which your performance or music production using these contents is recorded, and the permission of Yamaha Corporation is not required in such cases.

## About functions/data bundled with the instrument

- Some of the preset songs have been edited for length or arrangement, and may not be exactly the same as the original.
- The bitmap fonts used in this instrument have been provided by and are the property of Ricoh Co., Ltd.

#### ■ About this manual

- The illustrations and LCD screens as shown in this manual are for instructional purposes only, and may appear somewhat different from those on your instrument.
- Windows is a registered trademark of Microsoft® Corporation in the United States and other countries.
- The company names and product names in this manual are the trademarks or registered trademarks of their respective companies.

Thank you for purchasing this Yamaha Digital Keyboard!

This instrument features a convenient lighting keyboard which makes it easy for beginners to play the keyboard. It also features a wide variety of built-in preset Songs, including pop and classical music, for your playing pleasure.

We recommend that you read this manual carefully so that you can fully take advantage of the advanced and convenient functions of the instrument.

We also recommend that you keep this manual in a safe and handy place for future reference.

### About the Manuals

In addition to this Owner's Manual, the following Online materials (PDF files) are available.

#### ■ Included Document



#### Owner's Manual

- Setting Up: This section explains how to set up and start using this instrument.
- Quick Guide: This section explains briefly how to use the basic functions.
- Reference: This section explains in detail how to use various functions.
- Appendix: This section includes specifications, Voice List, etc.

### ■ Online Materials (PDF)



#### **Drum Kit List**

This contains detailed information of the Drum Kit Voices (Voice No. 242-263; page 78). When you select these Voices, various drum, percussion and SFX sounds listed here are assigned to each key.



#### **MIDI Reference**

This contains MIDI-related information, such as the MIDI Implementation Chart.



#### **Computer-related Operations**

This contains instructions about computer-related functions.



#### **Smart Device Connection Manual**

This explains how to connect the instrument to smart devices, such as smartphones, tablet devices, etc.

To obtain these manuals, access the Yamaha Downloads, and then enter the model name for searching the desired files.

Yamaha Downloads https://download.yamaha.com/

NOTE |

For a general overview of MIDI and how you can effectively use it, search for "MIDI Basics" (only in English, German, French and Spanish) on the website above.



### Song Book (only in English, French, German and Spanish)

This contains music scores for the preset Songs (excepting for a Demo Song and some Songs due to copyright issues) of this instrument.

To obtain this Song Book, access the Yamaha website and download it from the product web page.

Yamaha Global Site https://www.yamaha.com

### Included Accessories

- Owner's Manual (this book)
- Music rest
- Online Member Product Registration
- AC adaptor\*
  - May not be included depending on your particular locale. Check with your Yamaha dealer.

### Formats and functions



#### **GM System Level 1**

"GM System Level 1" is an addition to the MIDI standard which ensures that any GM-compatible music data can be accurately played by any GM-compatible tone generator, regardless of manufacturer. The GM mark is affixed to all software and hardware products that support GM System Level.



#### XGlite

As its name implies, "XGlite" is a simplified version of Yamaha's high-quality XG tone generation format. Naturally, you can play back any XG song data using an XGlite tone generator. However, keep in mind that some songs may play back differently compared to the original data, due to the reduced set of control parameters and effects.



#### Style File Format (SFF)

The Style File Format combines all of Yamaha's auto accompaniment know-how into a single unified format.



#### USB

USB is an abbreviation for Universal Serial Bus. It is a serial interface for connecting a computer with peripheral devices. It allows "hot swapping" (connecting peripheral devices while the power to the computer is on).



### **Touch Response**

The exceptionally natural Touch Response feature gives you maximum expressive control over the level of the Voices.

# **Contents**

PRECAUTIONS		Reference	
NOTICE			
Information		Playing a Variety of Instrument Voices	24
About the Manuals		Selecting a Main Voice	24
Included Accessories		Playing the "Grand Piano"	
Formats and functions	9	Using the Metronome	
		Adding a Layer – Dual Voice	
Setting Up		Playing Different Voices with Your Left and Right Hands (Split)	
Panel Controls and Terminals	12	Changing the Touch Response of the Keyboard	
a		Applying Effects to the Sound	
Setting Up	14	Adding Harmony or Arpeggio	28
Power Requirements  Turning the Power On  Setting the Auto Power Off function	15	Playing the keyboard with two persons (Duo mode)	30
Adjusting the Master Volume	16	District Course	04
Connecting Headphones or External Spe	eaker 16	Playing Songs	31
Using a Pedal (Footswitch)	16	Selecting and Playing Back a Song	32
Using the Music Rest	16	Playing Songs Repeatedly (BGM function)	33
Dienlay Itome	17	Song Fast Forward, Fast Reverse, and Paus	e33
Display Items	- 17	Changing the Song Melody Voice	
		A-B Repeat	
Onich Onida		Turning Each Part On/Off	34
Quick Guide		Transferring Songs from a Computer to this Instrument	3/1
Basic Operations	18	Computer to this institution	
Transfer Your Favorite MIDI Song from	m	Using the Song Lesson Feature	35
the Computer to the Instrume	nt19	Lighting Keyboard (Light Guide Function)	36
Practice Playing a Song Using		Keys to Success	
Lesson Functions	20	Phrase Repeat	38
Play with Rhythm and	20	Listening, Timing and Waiting	39
Accompaniment (Styles)	21		
Record Your Performance		Learning How to Use "Touch" Control	44
		(Touch Tutor)	41
Use the Metronome	23		
Make Detailed Settings		Hearing and Experiencing the Sound of	
(Function Settings)	23	the Chords (Chord Study)	42
		Hear and experience a sound of a single chord Hear and experience basic chord progressions	
		Playing Chords along with Chord Progressions of a Song	43
		Play the chords in combination with "Waiting" of the Lesson function	43


Playing with Rhythm and Accompaniment	
(Styles)	44
Setting the Fingering Type	44
Setting the Smart Chord Key	
Playing Styles	45
Style Variations	46
Chord Types for Style Playback	47
Chords Heard When Smart Chord is Selected	48
Looking Up Chords Using the Chord Dictionary	49
Using the Music Database	50
Registering a Style File	50
Recording Your Performance	51
Track Structure of a Song	51
Quick Recording	51
Recording to a Specified Track	52
Clearing a User Song	52
Memorizing Your Favorite Panel Settings	53
Recalling Panel Settings from	
the Registration Memory	53
Memorizing Panel Settings to	
the Registration Memory	
Deleting the Registration Memory	
Disabling Recall of Specific Items (Freeze)	54
Selecting an EQ Setting for	
your Favorite Sound	55
Connecting to Other Devices	56
Playing an External Audio Device with	
the Built-in Speakers	
Connecting to a Computer	
Connecting a Smart Device	58
Lowering the volume of a melody part (Melody Suppressor function)	58
Backup and Initialization	59
Backup Parameters	59
Initialization	
The Functions	60

### **Appendix**

Troubleshooting	64
Song Book Sample	66
Voice List	76
Standard Kit 1 List	82
Song List	83
Style List	85
Music Database List	87
Effect Type List	89
Specifications	93
Index	95

# **Panel Controls and Terminals**


### **Front Panel**




[ ① ] (Standby/On) switch     [ MASTER VOLUME] dial     [ DEMO] button	page 16 page 33 page 33 page 24
⑤ [TEMPO/TAP] button	
• [. 2 0, 17.1 ] Satton	pago 02
In the Lesson mode	
6 PART	
[L] button	page 39
[R] button	page 39
In the Recording mode	
6 [REC TRACK 2] button	
[REC TRACK 1] button	page 52
[KEYS TO SUCCESS] button	page 36
[PHRASE REPEAT] button	
9 [1 LISTENING 2 TIMING 3 WAITING	
	-
⊕ CHORD DICT	
In the Song mode	
(In the second s	
(REW] button	
(P [FF] button	
(B) [PAUSE] button	page 33
In the Style mode	
(D [ACMP ON/OFF] button	nage 45
SPLIT POINT	
[INTRO/ENDING/rit.] button	
MAIN/AUTO FILL] button	
[SYNC START] button	
<del></del>	
[START/STOP] button	
(B) [REC] button	page 51
(b) CLEAR	
(F) [VOICE] button	
SONG MELODY VOICE	
(B) [SONG] button	
(§ [STYLE] button  (§ Number buttons [0]–[9], [+/YES], [-/NO]	
[PORTABLE GRAND] button	nage 10
① [DSP] button	
(b) TYPE	
@ [ARTICULATION] button	
[REGIST MEMORY] button	
MEMORY	

2	[FUNCTION] button	page 60
		page 36
<b>②</b>	[MUSIC DATABASE] button	
23	[DUAL] button	page 25
	① DUAL VOICE	page 25
Ø	[SPLIT] button	page 25
23	[HARMONY/ARPEGGIO] button	
		page 28
29	Drum illustrations for the Drum Kit.	page 24
	Each of these indicates the drum or percussion in assigned to the corresponding key for "Standard	

### **Rear Panel**





	[SUSTAIN] jack		
1	[PHONES/OUTPUT] jack	.page	16
32	[AUX IN] jack	.page	56
3	[USB TO HOST] terminal	.page	57
34	DC IN jack	.page	14

### Panel Setup (Panel Settings)

By using the controls on the panel, you can make various settings as described here. These settings of the instrument are together referred to as "panel setup" or "panel settings" in this manual.

### The "Press and hold" Symbol



Buttons having this indication can be used to call up an alternate function when the relevant button is pressed and held. Hold down this button until the function is called up.


## **Setting Up**

### **Power Requirements**

Although the instrument will run either from an AC adaptor or batteries. Yamaha recommends use of an AC adaptor whenever possible. An AC adaptor is more environmentally friendly than batteries and does not deplete resources.

### Using an AC Adaptor

Connect the AC adaptor in the order shown in the illustration.




### / WARNING

. Use the specified AC adaptor (page 94) only. Using the wrong AC adaptor can result in damage to the instrument or overheating.

### NARNING

- . When using the AC adaptor with a removable plug, make sure to keep the plug attached to the AC adaptor. Using the plug alone can cause electric shock or fire.
- . If the plug is accidentally removed from the AC adaptor, slide it back in until it clicks into place, taking care to avoid touching any internal metal parts. To avoid electric shock, short circuit or damage, also be careful that there is no dust between the AC adaptor and plug.



The shape of the plug differs depending on your area.

### **⚠** CAUTION

. When setting up the product, make sure that the AC outlet you are using is easily accessible. If some trouble or malfunction occurs, immediately turn the power off and disconnect the plug from the outlet.

#### NOTE


· Follow the order shown above in reverse when disconnecting the AC adaptor.

### **Using Batteries**


This instrument requires six "AA" size, Alkaline (LR6)/ Manganese (R6) batteries, or rechargeable nickelmetal hydride batteries (rechargeable Ni-MH batteries). The Alkaline batteries or rechargeable Ni-MH batteries are recommended for this instrument, since other types may result in poorer battery performance.

### / WARNING

- . When the batteries run out, or if the instrument is not to be used for a long time, remove the batteries from the instrumont
- 1 Make sure that the power of the instrument is off.
- 2 Open the battery compartment cover located on the instrument's bottom panel.



3 Insert the six new batteries, being careful to follow the polarity markings on the inside of the compartment.



4 Replace the compartment cover, making sure that it locks firmly in place.

Make sure to set the battery type correctly (page 15).

#### NOTICE

- . Connecting or disconnecting the AC adaptor with batteries installed may turn the power off, resulting in loss of data being recorded or transferred at the time.
- · When battery power becomes too low for proper operation, the volume may be reduced, the sound may be distorted, and other problems may occur. When this happens, make sure to replace all batteries with new ones or already recharged ones.

#### NOTE I

- . This instrument cannot charge the batteries. Use only the specified charger device when charging.
- Power will be automatically drawn from the AC adaptor if an AC adaptor is connected while batteries are installed in the instrument.

### ■ Setting the battery type


Depending on the battery type to be used, you need to change the battery type setting on this instrument. Alkaline (and manganese) batteries are chosen by default. After installing new batteries and turning the power on, make sure to set the Battery Type appropriately (rechargeable or not) via Function number 064 (page 63).

#### NOTICE

· Failure to set the battery type may shorten the amount of the battery life. Make sure to set the battery type correctly.

### Turning the Power On

1 Turn down the [MASTER VOLUME] dial to "MIN."



2 Press the [(1)] (Standby/On) switch to turn the power on.

The Voice name appears on the display. Adjust the volume as desired while playing the keyboard.

3 Press and hold the [(1)] (Standby/On) switch for about a second to set the instrument to standby mode.



### 

• Even when the [ (|) ] (Standby/On) switch is in standby status, electricity is still flowing to the product at the minimum level. Remove the electric plug from the outlet when the instrument is not to be used for extended periods of time, or during electrical storms.

#### NOTICE

• Press only the [ () ] (Standby/On) switch when turning the power on. Any other operations such as pressing the pedal are not allowed. Doing so may cause the instrument to malfunction.

### Setting the Auto Power Off function

To prevent unnecessary power consumption, this instrument features an Auto Power Off function that automatically turns the power off if the instrument is not operated for a specified period of time. The amount of time that elapses before the power is automatically turned off is 30 minutes by default: however, you can change the setting.

### ■ To set the time that elapses before Auto Power Off is executed:

Press the [FUNCTION] button several times until "AutoOff" (Function 063; page 63) appears, then use the [+/YES] or [-/NO] button to select the desired value.

**Settings:** oFF, 5, 10, 15, 30, 60, 120 (minutes) Default value: 30 (minutes)

### ■ To disable the Auto Power Off function:

Turn the power on while holding down the lowest key on the keyboard. A message "oFF AutoOff" appears briefly, then the instrument starts up with the Auto Power Off function disabled. The Auto Power Off function also can be disabled by selecting Off in Function number 063 (page 63).



#### NOTICE

- . Depending on the instrument status, the power may not turn off automatically, even after the elapse of the specified period of time. Always turn off the power manually when the instrument is not in use.
- · When the instrument is not operated for a specified period of time while connected to an external device such as an amplifier, speaker or computer, make sure to follow the instructions in the Owner's Manual to turn off the power to the instrument and the connected devices, in order to protect the devices from damage. If you do not want the power to turn off automatically when a device is connected, disable Auto Power Off.

· Generally, the data and settings are maintained even when the power is turned off with the Auto Power Off function. For details, see page 59.

### Adjusting the Master Volume


To adjust the volume of the entire keyboard sound, use the [MASTER VOLUME] dial while playing the kevboard.



#### **CAUTION**

 Do not use the instrument for a long period of time at a high or uncomfortable volume level, since this can cause permanent hearing loss.

### Connecting Headphones or External Speaker



Connect a pair of headphones to the [PHONES/ OUTPUT] jack. This jack also functions as an external output. By connecting to a computer, keyboard amplifier, recorder, or other audio device, you can output the audio signal of this instrument to that external device. The speakers of this instrument are automatically shut off when a plug is inserted into this jack.

#### **<b>↑** CAUTION


- . Do not use the instrument or headphones for a long period of time at a high or uncomfortable volume level, since this can cause permanent hearing loss.
- . Before connecting the instrument to other electronic components, turn off the power of all the components. Also, before turning any components on or off, make sure to set all volume levels to minimum. Otherwise, damage to the components or electrical shock may occur.

### NOTICE

. To avoid possible damage to the external device, first turn on the power to the instrument, then to the external device. When turning off the power, do so in reverse order: first turn off the power to the external device, then to the instrument.

· When connecting the headphones or external speaker to the instrument, set the Master EQ (page 55) to "2 Headphone." The Master EQ can be set in Function settings (page 61; Function 025)

### Using a Pedal (Footswitch)



You can control three functions: Sustain, Articulation (page 27), and Arpeggio (page 29) as you play by pressing a footswitch (FC5 or FC4A; sold separately) plugged into the [SUSTAIN] jack. By default, Sustain is assigned, so that the sound can be heard for a long time even if you take your finger off the keyboard while pressing the footswitch, like a damper pedal on a piano. To use a function other than Sustain, use the function settings (Function 029; page 61).

#### NOTE |


- Plug or unplug the footswitch while the power is off. Also, do not press the footswitch when turning the power on. Doing so changes the polarity of the footswitch, resulting in reversed
- The Sustain function does not affect Split Voices (page 25) or the Styles (Auto Accompaniment; page 44).

### Using the Music Rest

Insert the music rest into the slots as shown.



## **Display Items**



## **Quick Guide**

### **Basic Operations**

This instrument features three basic functions: Voice, Song, and Style. This section shows you how to use these three functions and how to use the number buttons and [+/YES], [-/NO] buttons which are useful for various functions.

Press one of the following buttons to select a basic function.




The above operation calls up the name and number of the current Voice, Song, or Style, and shows it in the display.

- 2 Select a Voice, Song, or Style by using the number buttons [0]–[9], [+/YES], [-/NO].
  - Number buttons [0]–[9]


The Number buttons can be used to directly enter a Voice, Song, or Style number or parameter value.

Example: Selecting Voice 003, Bright Piano



### ■ [+/YES], [-/NO] buttons

Press the [+/YES] button briefly to increase the value by 1, or press the [-/NO] button briefly to decrease the value by 1. Press and hold either button to continuously increase or decrease the value in the corresponding direction. Pressing both buttons simultaneously lets you reset a parameter to the default value.



3 Start playing the Voice, Song or Style that you selected.

Voice.....Play the keyboard.

Pressing the [PORTABLE GRAND] button will reset the Voice settings to the Grand Piano Voice (Voice No.001 Live!ConcertGrandPiano).



Song ......Press the [START/STOP] button to start Song playback.

Style ......Press the [START/STOP] button to start only the rhythm part.


For instructions on playing the chord accompaniment part etc., refer to page 45.

# **Transfer Your Favorite MIDI Song from the Computer** to the Instrument

→ Page 57

Windows10 is used for the examples in this manual.


Connect the [USB TO HOST] terminal (page 13) on rear panel of this instrument and the computer via a USB cable.




Press the [+/YES] button in the function settings (Storage; Function 059; page 63) to turn the "Storage Mode" on.

3 Copy your favorite song file from the computer to the instrument folder on the computer display.

For other important information about copying files, refer to "Computer-related Operations" on the website (page 8).



4 After copying is completed, remove the instrument drive from the computer.



- 5 Disconnect the USB cable connecting the instrument to the computer.
- 6 Press the [-/NO] button in the same function settings as in step 2 to turn the "Storage Mode" off.
- 7 Start playback of the transferred Song (Song No. 208 –).

For instructions on playing back a Song, refer to page 32.

### **Practice Playing a Song Using Lesson Functions**

→ Page 35

This instrument features the following Lesson functions. Select and practice your favorite preset Songs, and improve your playing skills with the Song Book, which includes the music scores of the preset Songs, or important points for "Keys to Success," etc.

### **Keys to Success**

You can select just the key phrases of the Song - the ones you like most or need to work on - and practice them one by one. Enjoy this Lesson by passing and completing each step.



Select the Song you want to learn, and then press the [KEYS TO SUCCESS] and [START/STOP] buttons to start Lesson.



### **Phrase Repeat**

This lets you practice difficult phrases repeatedly. It's ideal for use as a final practice before you go on to the last Step to try to pass in the Keys to Success mode, or when you just want to practice a difficult phrase repeatedly.

### Listening, Timing and Waiting

You can practice the preset Songs in the following three steps, independently for the right or left hand, or both hands.

These three lessons can be used with Keys to Success or Phrase Repeat. If you feel it difficult to play the specific phrase in Keys to Success, use the Waiting lesson to have the phrase pause until you play the correct note (page 39).

- Lesson 1 (Listening) ..... Listen to the model melody/chords of the part you selected carefully and remember it well.
- Lesson 2 (Timing) ........ Play the notes with the correct timing.
- Lesson 3 (Waiting) ....... Play the correct notes.

Select the Song you want to learn, and then press the [1 LISTENING 2 TIMING 3 WAITING] button to start your desired Lesson.



### **Play with Rhythm and Accompaniment (Styles)**


→ Page 44

This instrument includes an Auto Accompaniment feature that automatically plays appropriate "Styles" (rhythm + bass + chord accompaniment), controlled simply by playing only the root note of a chord. These Styles give you automatic, fingertip control of a full backing band.

Press the [STYLE] button.




- 2 Use the number buttons [0]-[9], [+/YES], [-/NO] buttons to select the desired Style.
- 3 Press the [ACMP ON/OFF] button to turn on the Auto Accompaniment.




4 Press the [SYNC START] button to turn Synchro Start on.

This puts the Style playback in "standby" and Style starts playing back when you play the keyboard.




5 Press the [INTRO/ENDING/rit.] button.

An Intro part is added before starting Style playback.



6 Play the root note of a chord with your left hand in the Auto Accompaniment range to start Style playback.



- Play the root note of a chord with your left hand and the melody part with your right
- 8 Press the [INTRO/ENDING/rit.] button to stop Style playback.

The Ending part is added before stopping Style playback.

### **Record Your Performance**

→ Page 51

You can record your performance.

- Make the necessary settings, such as Voice selection, etc.
- Press the [REC] button to enter the Record Ready mode.



Press the [REC] button to exit from the Record Ready mode.

- 3 Play the keyboard to start recording.
- 4 Press the [START/STOP] button to stop recording.



To play back the recorded Song, press the [START/STOP] button.

### **Use the Metronome**

→ Page 24

Press the [METRONOME] button to start the Metronome.



2 Press the [METRONOME] button again to stop the Metronome.

Pressing the [TEMPO/TAP] button enables you to adjust the Metronome tempo.

### **Make Detailed Settings (Function Settings)**

→ Page 60

After learning how to use this instrument, use the [FUNCTION] button to set various parameters. This instrument contains 64 settings. Each time you press the [FUNCTION] button, the setting item is selected in sequence, and the value of the selected item can be changed by using the number buttons [0]–[9], and [+/YES], [-/NO] buttons.



You can select the setting items by simultaneously holding down the [FUNCTION] button and pressing the [+/YES] or [-/NO] button.

When the Function settings display does not appear, press one of the [VOICE], [SONG] or [STYLE] buttons, and then press the [FUNCTION] button again.

Pressing one of the [VOICE], [SONG] or [STYLE] buttons also lets you exit from the Function settings.

### **Lighting Keyboard (Light Guide function)**

This instrument features the Light Guide function which makes the keys you press or those specified by Song data light. Although this function is turned on by default, you can turn the function off by holding down the [FUNCTION] button for longer than a second.

# Playing a Variety of Instrument Voices


In addition to piano, organ, and other "standard" keyboard instruments, this instrument has a large range of Voices that includes guitar, bass, strings, sax, trumpet, drums and percussion, and even sound effects—giving you a wide variety of musical sounds.

### **Selecting a Main Voice**

Press the [VOICE] button.

The Voice number and name will be shown.





2 Use the number buttons [0]–[9], [+/YES], [-/NO] buttons to select the desired Voice.

Refer to the Voice List on page 76.



3 Play the keyboard.



#### **Preset Voice Types**

001–241	Instrument Voices (including sound effects).
242-263 (Drum Kit)	Various drum and percussion sounds are assigned to individual keys, from which they can be played. Details on the instruments and key assignments of each Drum Kit can be found in the Standard Kit 1 List on page 82 and "Drum Kit List" on the website (page 8).
264–283	Arpeggios are automatically reproduced by simply playing the keyboard (page 28).
284-622	XGlite Voices (page 79)
000	One Touch Setting The One Touch Setting feature automatically selects the most suitable Voice when you select a Style or Song (excepting the Song inputted from other devices). Simply select Voice number "000" to activate this feature.

### Playing the "Grand Piano"

When you want to reset various settings to default and simply play a Piano sound, press the [PORTA-BLE GRAND] button.



The Voice "001 Live!ConcertGrandPiano" will automatically be selected as the Main Voice.

### **Using the Metronome**

The instrument features a built-in Metronome (a device that keeps an accurate tempo), convenient for practicing.

Press the [METRONOME] button to start the Metronome.



2 Press the [METRONOME] button again to stop the Metronome.

#### To change the Tempo:

Press the [TEMPO/TAP] button to call up the Tempo value, then use the number buttons [0]–[9], [+/YES], [-/NO].



Press the [+/YES] and [-/NO] buttons simultaneously to instantly reset the value to the default tempo.

### To set the Time Signature:

Press and hold the [METRONOME] button to call up "TimeSigN" (Function 030; page 62), then use the number buttons, [+/YES] and [-/NO] buttons.


### To set the Metronome Volume:

This can be set via Function number 032 (page 62).

### Adding a Layer - Dual Voice

In addition to the Main Voice, you can layer a different Voice over the entire keyboard as a "Dual Voice."

# Press the [DUAL] button to turn on the layer.



#### NOTE

- Pressing and holding the [DUAL] button for longer than a second calls up "D. Voice," allowing you to select a different Dual Voice.
- 2 Play the keyboard.



sound at the same time.

# 3 To exit from the layer, press the [DUAL] button again.

#### To select a different Dual Voice:


Although turning on Dual will select a Dual Voice suitable for the current Main Voice, you can easily select a different Dual Voice by pressing and holding the [DUAL] button to call up "D.Voice" (Function 008; page 61), then using the number buttons [0]–[9], [+/YES], [-/NO].

# Playing Different Voices with Your Left and Right Hands (Split)

By dividing the keyboard into the two separate areas, you can play one Voice with your left hand and a different Voice with your right.

Furthermore, you can play both a Main Voice and Dual Voice in the right-hand area of the keyboard while playing a different Voice (called "Split Voice") in the left-hand area.

Split Point ... default setting: 054 (F#2)



The highest key for the left-hand area is referred to as the "Split Point" (Function 003; page 60) which can be changed from the default F#2 key.

# Press the [SPLIT] button to turn on the Split function.

The keyboard is divided into the left- and righthand areas.



#### NOTE A

- Pressing and holding the [SPLIT] button for longer than a second calls up "S. Voice," allowing you to select a different Split Voice.
- 2 Play the keyboard.



3 To exit from the Split function, press the [SPLIT] button again.

### To select a different Split Voice:


Press and hold the [SPLIT] button to call up "S.Voice" (Function 012; page 61), then use the number buttons [0]–[9], [+/YES], [-/NO].

# Changing the Touch Response of the Keyboard

The keyboard of this instrument is equipped with a Touch Response feature that lets you dynamically and expressively control the level of the Voices according to your playing strength.

Press the [FUNCTION] button several times until "TouchRes" (Function 004; page 60) appears.

After a few seconds, the current Touch Response appears.



Appears when the Touch Response is not "Fixed."

2 Use the number buttons [1]–[4], [+/YES], [-/NO] buttons to select a Touch Response setting between 1 and 4.

#### **Touch Response**

1	Soft	Produces relatively high volume even with light playing strength. Best for players with a light touch who want to maintain a consistent, relatively loud volume.
2	Medium	Produces a fairly "standard" keyboard response.
3	Hard	The keys must be played very strongly to generate loud volume. This setting is best for a wide dynamic range and optimum expressive control of the sound, from pianissimo to fortissimo.
4	Fixed	All notes are produced at the same volume no matter how hard the keyboard is played.

### 3 Play the keyboard.

The strength meter will light according to the strength with which you play the keyboard.

When you play softly.

When you play at medium strength.



When you play strongly.



#### NOTE

 When the Touch Response is "Fixed," the strength meter is at fixed medium strength.

### **Applying Effects to the Sound**

This instrument can apply various Effects as listed below to the instrument's sound.

#### DSP

The DSP (digital signal processor) is an effect in which digital signal processing is applied to the sound to change it.

There are various types of DSP. When the DSP is turned on, the most suitable type will be selected for the current Main Voice. If you want to select a specific type, use operation steps 2 and 3 below. For details on DSP types, refer to page 91.


1 Check whether the DSP is ON or not. If the "DSP" icon is not shown on the display, press the [DSP] button.



Depending on the selected Voice, the DSP may automatically be turned on.

#### NOTE A

- The DSP is only applied to the Main Voice. It is not applied to the Dual Voice (page 25) or Split Voice (page 25)
- The DSP cannot be turned on during Lessons.
- 2 Hold down the [DSP] button for longer than a second to call up "DSPType" (Function 023; page 91). After a few seconds, the current DSP type appears.



- 3 Use the number buttons [0]–[9], [+/YES], [-/NO] buttons to select the desired type.
- 4 Play the keyboard.
- 5 Press the [DSP] button again to turn off the DSP.

#### ● Articulation

Articulation is an effect that reproduces the playing methods that are unique to specific instruments. The Articulation effect is applied to notes you play only while holding down the [ARTICULATION] button. The Voice to which the Articulation effect is applied is called "S. Art Lite Voice" (Super Articulation Lite Voice). The S. Art Lite Voices have the added indication "\*\*\*" in the Voice List (page 76).

### **Examples of the Articulation effect**

If you select a guitar Voice, you can realistically reproduce the following guitar-specific playing techniques.

## Example: Voice number 044 "S.Art Lite Nylon Guitar Harmonics"

Playing the keyboard while holding down the [ARTICULATION] button produces harmonics sounds.

## Example: Voice number 048 "S.Art Lite Distortion Guitar"

Pressing the [ARTICULATION] button produces a scratching noise.

Only when an S. Art Voice is selected, the most suitable Articulation effect is automatically applied to the Voice.

When other Voices are selected, the modulation effect is applied to the Voices.

### 1 Select the desired S. Art Lite Voice.



2 Press the [ARTICULATION] button while playing the keyboard.



Release the [ARTICULATION] button to turn Articulation off.

### Adding the Articulation effect by using the pedal

If you assign the Articulation function to the pedal (footswitch) with "PdlFunc" (Function 029; page 61), you can apply the effect by pressing the pedal.

#### NOTE I

- The Articulation effect is applied only to a Main Voice.
- S.Art Lite Voices sound differently depending on the velocity, etc.

#### Reverb

Adds the ambience of a club or concert hall to the sound. Although the best-suited Reverb type is called up by selecting a Song or Style, you can select another one via Function number 020 (page 61). When you select "oFF," the Reverb effect is turned off. And you can also set the Reverb level via Function number 021 (page 61).

#### Chorus

Makes the Voice sound richer, warmer and more spacious. Although the best-suited Chorus type is called up by selecting a Song or Style, you can select another one via Function number 022 (page 61). When you select "oFF," the Chorus effect is turned off. You can also set the Chorus depth for Voices via Function numbers 007 (page 60), 011, 015 (page 61).

The Chorus depth cannot be applied to the Styles or Songs.

#### Sustain

By turning on the Sustain parameter of Function number 024 (page 61), you can add a fixed, automatic sustain to the Main/Dual Voices played on the keyboard. Or, you can produce a natural sustain as desired with the footswitch (sold separately; page 16).

### NOTE |

 Even if you turn on Sustain, there are some Voices to which sustain is not applied.

### **Adding Harmony or Arpeggio**

You can add harmony or arpeggio notes to the Voice played on the keyboard.

By specifying the Harmony Type, you can apply harmony parts, such as duet or trio, or add tremolo or echo effects to the played sound of the Main Voice. Also, when the Arpeggio Type is selected, arpeggios (broken chords) are automatically played back when you simply play the appropriate notes on the keyboard. For example, you could play the notes of a triad—the root, third, and fifth—and the Arpeggio function will automatically create a variety of interesting phrases.

Press the [HARMONY/ARPEGGIO] button to turn on the Harmony or Arpeggio function.



When the Harmony or the Arpeggio is turned on, the most suitable one will be selected for the current Main Voice.


If you want to select a specific type, select it by the operation steps 2 and 3 at right.

#### NOTE |

- The Harmony effect can be added to only the Main Voice.
- When selecting a Voice number between 264 and 283, the Arpeggio function will automatically be turned on.
- When selecting a Harmony Type between 001 and 005, the harmony effect will only be added to your right-hand melody play if you turn on the Style (page 45) and press chords in the auto accompaniment range of the keyboard.

### 2 Hold down the [HARMONY/ARPEGGIO] button for longer than a second so that "Harm/Arp" (Function 026; page 61) appears on the display.

After "Harm/Arp" is shown for a few seconds, the current type appears.



# 3 Use the number buttons [0]–[9], [+/YES], [-/NO] buttons to select the desired type.

When you want to specify a Harmony Type, refer to the Harmony Type list on page 89; to specify an Arpeggio Type, refer to the Arpeggio Type list on page 90.

#### NOTE

- When playing one of the Arpeggio Types 143 to 176, select the corresponding Voice below as the Main Voice. 143–173: Drum Kit Voices (Voice No. 242–252)
  174 (China): StdKitl + Chinese Perc. (Voice No.253)
  175 (Indian): Indian Kit 1 (Voice No.254) or Indian Kit 2 (Voice No. 255)
  176 (Arabic): Arabic Kit (Voice No. 259)
- 4 Press a note or notes on the keyboard to trigger the Harmony or Arpeggio.

When a Harmony Type is selected, a harmony part (for example, duet or trio) or an effect (for example, tremolo or echo) can be added to the played sound of the Main Voice.

Also, when an Arpeggio Type is selected, arpeggios (broken chords) are automatically played back when you simply play the appropriate notes on the keyboard. The particular arpeggio phrase differs depending on the number of pressed notes and the area of the keyboard.



5 To turn the Harmony or Arpeggio off, press the [HARMONY/ARPEGGIO] button again.

### How to play the various Types


The method of sounding the Harmony effect (01–26) differs depending on the selected type. For Types 01–05, turn the Auto Accompaniment on and play it by pressing a chord in the auto accompaniment section of the keyboard, then play some keys in the right-hand side to produce the Harmony effect. For Types 06–26, turning auto accompaniment on or off has no effect. However, it is necessary to play two notes simultaneously for Types 06–12.

• Harmony Type 001 to 005



Press the right-hand keys while playing chords in the auto accompaniment range of the keyboard when Auto Accompaniment is on (page 45).

• Harmony Type 006 to 012 (Trill)



• Harmony Type 013 to 019 (Tremolo)



• Harmony Type 020 to 026 (Echo)



Arpeggio Type 027 to 176
 When Split is off:



Arpeggio function applies to the Main Voice and the Dual Voice

#### When Split is on:



Arpeggio function applies only to the split Voice

#### NOTE I

- Arpeggio cannot be applied to the Split and Main/ Dual Voices simultaneously.
- Selecting a Voice number between 274 and 283 as the Main Voice will turn on Arpeggio and Split automatically.

### To adjust the Harmony Volume:

This can be adjusted via Function number 027 (page 61).

### To adjust the Arpeggio Velocity:


This can be adjusted via Function number 028 (page 61).

# Holding the Arpeggio Playback via the Pedal (Footswitch) (Hold)

You can set the instrument so that Arpeggio playback continues even after the note has been released, by pressing the pedal connected to the [SUSTAIN] jack.


Press a [FUNCTION] button a number of times until the "PdlFunc" (Function 029; page 61) item appears on the display.

After "PdlFunc" is shown for a few seconds, the current setting is shown.



2 Select the desired function by using the number buttons [1]–[3] or [+/YES], [-/NO] buttons. (In this case, number button [2] to select "Arp Hold.")

If you want to restore the pedal function to sustain, select "Sustain." If you want to use both hold and sustain functions. select "Sus+ArpH."




3 Try playing the keyboard with Arpeggio playback using the pedal.

Even if you release the notes, Arpeggio playback will continue. To stop Arpeggio playback, release the footswitch.

# Playing the keyboard with two persons (Duo mode)

When the Duo mode is activated on this instrument, two different players can play the instrument simultaneously, with the same sound, over the same octave range—one person on the left and the other on the right. This is useful for learning applications, in which one person (a teacher, for example) plays a model performance and the other person watches and practices while sitting at the first person's side.

- Press a [FUNCTION] button several times until "DuoMode" (Function 051; page 63) appears on the display.
- 2 Use the [+/YES] button to select "on." The F#3 key becomes the Duo Split Point and the keyboard is divided into two sections: one for the left Voice and one for the right Voice.



Duo Split Point default setting: 066 (F#3)



#### NOTE

- The right Voice section and the left Voice section of the keyboard are both set to the same Voice (Main Voice).
- The Duo Split Point can be changed via Function number 053 (nage 63)
- 3 One person can play the left Voice section of the keyboard while the other plays the right Voice section.
- 4 To exit from Duo mode, select "oFF" via "DuoMode" (Function 051; page 63) by executing steps 1.

### Changing the Left Voice

Only the left Voice can be changed via "DuoLVc" (Function 052; page 63).

#### NOTE

- When playing different Voices between the left and right, the right Voice name is shown in the display.
- Certain functions such as Lesson, Harmony/Arpeggio and Dual cannot be used in the Duo mode.

### How sounds are output in the Duo mode

The performance sound of the left Voice will sound from the left speaker, and the performance sound of the right Voice will sound from the right speaker, in the initial Duo mode setting ("Separate"). This output setting can be changed from the "DuoType" setting (Function 058; page 63).

#### NOTE I

In the Duo mode, the pan, volume and tonal characteristics of the stere sound may differ from those in the normal mode, due to the setting of DuoType = "Separate" (page 63). Particularly with Drum Kits, the difference may be more obvious, since each key of a Drum Kit features a different stereo pan position.

#### Using sustain in the Duo mode

Sustain can be applied to the left and right Voice sections in Duo mode just as it normally is by using one of the following methods in the Duo mode like the usual mode.

- Press the footswitch (page 16) connected to the [SUSTAIN] jack.
- Set "Sustain" (Function 024; page 61) to on. Sustain is applied to all notes.

#### NOTE I

- Sustain cannot be applied independently to the left Voice section and the right Voice section.
- While Sustain is set to on via Function 024, the setting of hold is maintained even when the power is turned off.

# **Playing Songs**

You can simply enjoy listening to the internal Songs, or use them with just about any of the functions, such as Lesson.

### Song Category


The Songs are organized by category as listed below.

Song No.	Song Category	Descriptions
001	DEMO	This demonstration Song showcases the various sounds of the instrument.
002–011	POP	This category features a collection of hit songs. Have fun playing your favorite song.
012-042	FAVORITE	We've collected various folk songs from around the world which have been handed down from through the generations, as well as famous classical pieces. Try playing the melodies of these Songs.
043–051	INSTRUMENT MASTER	These Songs feature solo instruments other than piano—letting you enjoy playing other instrumental voices along with orchestral accompaniment.
052-074	PIANO REPERTOIRE	These include famous pieces from around the world along with well-known piano pieces. Enjoy the beautiful, resonant piano sound as you play solo or along with orchestral backing.
075–090	LEARN TO PLAY	Each of these Songs has two variations: a simple one which even beginners can practice with ease, and another more challenging version.
091–110	FAVORITE WITH STYLE	Enjoy performing a piece with Style accompaniment (automatic accompaniment data). (Keys to Success (page 36) is designed so that you master playing the melody with your right hand first, and then learn the roots of the chords with your left hand.)
111–116	JAPANESE SONG	This category features a collection of songs that are well-known in Japan and have been enjoyed for generations. Experience these traditional melodies for yourself.
117–129	DUET	Get together with a friend or family member and make great music together. (The Songs have been arranged so that it is also possible to perform them alone.)
130–140	PIANO SOLO	This category features a collection of well-known classical piano compositions. Enjoy the beautiful sounds of the piano.
141–150	TOUCH TUTOR	Learn how to use expressive "touch" control while playing the key- board according to the strength level displayed in the LCD.
151–162	CHORD STUDY	Hear and experience the sound of chords and easy chord progressions while playing the lighting keyboard.
163–202	CHORD PROGRESSION	Learn how to play chords with Songs featuring simple, fundamental chord progressions.
203-207	USER SONG	Songs (User Songs) you record yourself.
208–	FLASH MEMORY	Songs transferred from a computer. For instructions on how to transfer, refer to page 19 or "Computer-related Operations" on the website (page 8).

### **Selecting and Playing Back a** Song

1 Press the [SONG] button, and then use the number buttons [0]-[9], [+/YES], [-/NO] to select the desired Sona.

Refer to the Song List (page 83).



### Press the [START/STOP] button to start playback.

To stop playback, press the [START/STOP] button again.



### Changing the Tempo

Press the [TEMPO/TAP] button to call up the Tempo value, then use the number buttons, [-/NO] and [+/YES] buttons to adjust the Tempo value.



Press the [+/YES] and [-/NO] buttons simultaneously to reset the value to the default tempo of the current Song or Style (page 44).

### Using the Tap function:

While a Song or Style is playing back, press the [TEMPO/TAP] button just twice at the desired tempo to change the tempo. While Song or Style playback is stopped, tap the [TEMPO/TAP] button several times to start playback at the tapped tempo-four times for a 4-beat Song or Style or three times for a 3-beat Song or Style.



### Adjusting the Song Volume

To adjust the volume balance between Song playback and keyboard, you can adjust the Song Volume. This can be set via Function number 019 (page 61).

# Playing Songs Repeatedly (BGM function)

With the default setting, pressing the [DEMO] button will play back only 11 Songs (Song No. 001–011) repeatedly. This setting can be changed so that, for example, all internal Songs automatically play back, letting you use the instrument as a background music source.

# Hold down the [DEMO] button for longer than a second.

"DemoGrp" (Function 061; page 63) is shown in the display for a few seconds, followed by the current repeat playback target.



### 2 Use the [+/YES] or [-/NO] button to select a playback group.

1	Demo	Preset Songs (001–011)
2	Preset	All preset Songs (001–140)
3	User	All User Songs (203–207)
4	Download	All Songs transferred from a computer (208–)

### NOTE |

 When User Songs and Download Songs data do not exist, Demo Songs are played back.

# 3 Press the [DEMO] button to start play-

To stop playback, press the [DEMO] button again or press the [START/STOP] button.

### Random Song Playback


When the Demo Group (above) is set to something other than "Demo," the playback order via the [DEMO] button can be changed between numerical order and random order. To do this, press the [FUNCTION] button several times until "PlayMode" (Function 062; page 63) is called up, then select "Normal" or "Random."

### Song Fast Forward, Fast Reverse, and Pause

Like the transport controls on an audio player, this instrument lets you fast forward (FF), rewind (REW) and pause (PAUSE) playback of the Song.

### Fast Forward

During playback, press this button to rapidly skip ahead to a later point in the Song.



#### **Fast Reverse**

During playback, press this button to rapidly return to an earlier point in the Song.

### **Pause**

During playback, press this button to pause playback, and press again to start from that point.

#### [ NOTE

- When the A-B repeat (page 34) is specified, the Fast Reverse and Fast Forward will only work within the range between A and B.
- [REW], [FF] and [PAUSE] button cannot be used during Song playback by using the [DEMO] button.

### **Changing the Song Melody Voice**

You can change a Song's melody Voice to any other desired Voice.

- 1 Select and play back a Song.
- Select the desired Voice.
- 3 Press and hold the [VOICE] button for longer than a second.

"SONG MELODY VOICE" appears in the display for a few seconds, and the selected Voice replaces the Song's original melody Voice.

### NOTE I

- You can change the melody Voice even when the Song playback is stopped.
- Selecting another Song will cancel the changed Melody Voice.
- · You cannot change the melody Voice of a User Song.

### **A-B Repeat**

You can play back only a specific section of a Song repeatedly by setting the A point (start point) and B point (end point) in one-measure increments.



- Start playback of the Song (page 32).
- When playback reaches to the point you want to specify as the start point, press the [A-B REPEAT] button to set the A point.



3 When playback reaches to the point you want to specify as the end point, press the [A-B REPEAT] button again to set the B point.

The specified A-B section of the Song will now play repeatedly.

NOTE |

- You can also set the A-B Repeat function when the Song is stopped. Simply use the [REW] and [FF] buttons to select the desired measures, pressing the [A-B REPEAT] button for each point, then start playback.
- If you want to set the start point "A" at the top of the Song, press the [A-B REPEAT] button before starting playback.

# ↓ To cancel repeat playback, press the [A-B REPEAT] button.

To stop playback, press the [START/STOP] button.

NOTE I

• The A-B Repeat function will be canceled when you select another Song.

### **Turning Each Part On/Off**

As indicated above the panel buttons (shown below), Songs other than Song numbers 163–202 consist of two parts; L and R, which can be turned on or off individually by pressing the corresponding button, L or R.



### When a User Song (number 203-207; page 51) is selected

The L and R indicators light when the tracks contain data, and are unlit when a track is muted or contains no data.

# When Songs other than a User Song is selected

The L and R indicators always light regardless of whether a track contains data or not.

By turning the left- and right-hand parts on or off during playback, you can listen to the Part (that is turned on), or practice the other part (that is turned off) on the keyboard.

NOTE |

on page 57.

 Selecting another Song will cancel the on/off status of the Parts.

# Transferring Songs from a Computer to this Instrument

By using a USB cable to connect the [USB TO HOST] terminal of this instrument to a computer, you can transfer song files from the computer.

For details, refer to the "Connecting to a Computer"

# Using the Song Lesson Feature

Use these convenient features to practice the preset Songs and improve your playing skills. The Lessons are arranged for optimum, enjoyable learning, so select the one suitable for you and take your keyboard skills higher, step by step.


You can refer to the music score in the Song Book (free downloadable scores). To obtain the Song Book, access the Yamaha website and download it from the product web page.

https://www.yamaha.com

### **Keys to Success**

(Page 36)

You can select just the key phrases of the Song—the ones you like most or need to work on—and practice them one by one. This lesson is ideal for beginning players.




Each Song consists of several Steps. Each time you play all the way through the current Step, your performance will be evaluated. A score of "60" or more indicates that you passed this Step and you should try the next Step, which begins automatically.

The passing status ★ is saved, but you can go on to next Step even when you didn't pass the Step, or you can retry the Step later.

### **Phrase Repeat**

(Page 38)

You can practice two or more phrases at once repeatedly by specifying them, as desired. This is ideal as a finishing practice before you try a last (finishing) Step to pass in the Keys to Success mode, or when you just want to practice the difficult phrase(s) repeatedly.



### Listening, Timing and Waiting

(Page 39)

You can practice the preset Songs in three steps, independently for the right or left hand, or both hands together. This is ideal when you want to practice all the way through the Song with the selected part.

- Lesson 1 (Listening) ...... Listen to the playback part you will play. Remember it as best as you can.
- Lesson 2 (Timing) ....... Learn to play the notes with the correct timing. Even if you play wrong notes, the correct notes will sound.
- Lesson 3 (Waiting) ....... Learn to play the correct notes. The Song pauses until you play the right note.



You can combine the Keys to Success lesson (page 36) and Phrase Repeat lesson (page 38) with the Listening, Timing or Waiting lesson (page 40). If you feel it difficult to play the specific phrase in the Keys to Success lesson, use Listening, Timing or Waiting lesson to listen to the phrase, to practice only the timing to play, or to let the phrase pause until you play the correct notes.

In addition, various learning functions are provided for your enjoyable playing experience as follows:

- Touch Tutor (page 41)
- Chord Study (page 42)
- Chord Progressions (page 43)

# **Lighting Keyboard (Light Guide Function)**

When using the Song Lesson function, keys that you should press next will light in succession. The lighting keyboard can help you play the keyboard easily, even if you have limited music reading skills.

### When you do not want the keyboard to light:

Hold down the [FUNCTION] button for longer than a second to call up "Light" (Function 037; page 62) and press the [-/NO] button to turn the Light Guide function off.

In addition to the Song Lesson, the keys you press or those specified by Song data light.

Compatible Song data includes not only the preset Songs but also Songs transferred from the computer to the instrument or played on the computer.

#### NOTE

- The keys light only when playing the MIDI Songs. They do not light when playing the Audio Songs.
- When playing the MIDI Song data on a computer, you can determine the channel which lights the keyboard. For details, refer to the "Light Part 1 Setting" (Function 038) or "Light Part 2 Setting" (Function 039) on page 62.

### **Keys to Success**

In this lesson, you can practice individual phrases in the Song (with each Step) to effectively master the entire Song.

### 1 Prepare the Song Book.

Download the Song Book from the Yamaha website (page 8), or you can refer to the scores of some Songs at the end of this manual.

The amount of Steps and lesson parts (which are pre-programmed) will differ depending on the Song. For details, refer to the Song Book.

#### NOTE I


 All preset Songs 002 to 202 other than 001 can be used with this mode, especially the "LEARN TO PLAY" category Songs.

# 2 Press the [SONG] button, then select a Song for your lesson.

Here, select Song "Für Elise (Basic)" from the "LEARN TO PLAY" category, then open the corresponding page of the Song Book.

# 3 Press the [KEYS TO SUCCESS] button to engage this lesson.

The keyboard icon, "Step01" and lesson part ("R" or "L" or "LR") appears on the display, indicating that you are to start this lesson from scratch. If you have already passed several Steps, the next Step number appears on the display.



# ✓ Press the [START/STOP] button to start Lesson.

After the lead-in, playback of the current Step starts.



#### NOTE

- For your practice enjoyment, a special arrangement is applied to each Song. This is why playback tempo may be slower than original.
- 5 Practice the phrase in the current Step.

Referring to the notation in the Song Book, play the lighting keyboard.

## 6 Confirm the evaluation in the current Step.

When the current Step reaches the end, your performance will be evaluated and your score (from 0–100) is shown in the display.



A score between "0"-"59" indicates that you did not pass this Step and you should try the same Step again, which begins automatically. A score of "60"-"100" indicates that you passed this Step and you should try the next Step, which begins automatically.

### NOTE |

 If the specified part is both hands, you cannot pass the Step until you play both hands, even if you play one of the hands well. Only a message such as "Left Part is correct!" appears in the display.

## 7 Execute Step 02, 03, 04, and so on.

In the last Step of each Song, you will practice all the way through the Song. When you pass all Steps, the Keys to Success mode will automatically be turned off and playback stops.

NOTE I


• Even during lesson, you can select another Step by using the [+/YES]/[-/NO] buttons.

## 8 To stop this Lesson, press the [KEYS TO SUCCESS] button.


## **Confirming the Passing Status**

You can confirm the passing status of each Song simply by selecting a Song and each Step.

### When Step is selected



### When Song is selected



## **Clearing the Passing Status**

You can clear existing passing status entries for the entire Song or a specific Step of the Song.

●To clear the passing status entries of all Steps: Select the desired Song then hold down the [KEYS TO SUCCESS] button for longer than three seconds, with the Keys to Success mode disabled. A "Cleared" message will appear on the display.

### To clear the passing status entry for a specific Step:

Select the desired Song, enable Keys to Success, select the desired Step, then hold down the [KEYS TO SUCCESS] button for longer than three seconds. A "Cleared" message will appear on the display.

NOTE I


• This operation cannot be executed during playback.

## **Phrase Repeat**

You can practice a difficult phrase repeatedly by selecting a specific number of the Phrase Marks preprogrammed in the Preset Songs (excepting the Song numbers 001 and 141–202). You can confirm the Phrase Mark location in the Song Book (page 8).

#### NOTE

- Phrase Mark is a pre-programmed marker in certain Song data, which indicates a specific location in the Song.
- Depending on the selected Song, some phrases include only one note.



### Practicing only a single Phrase

During Song playback, press the [PHRASE REPEAT] button at the phrase you want to practice. The corresponding Phrase number will appear in the display and, after a lead-in, repeat playback will start. Turn off the L or R part (page 34), then practice the phrase which is turned off repeatedly until you are satisfied.



Even during repeat playback, you can select any other phrase number via the [+/YES] or [-/NO] button, and you can return to normal playback by pressing the [PHRASE REPEAT] button again.

### **Practicing two or more Phrases**

By setting Phrase A (as the start point) and Phrase B (as the end point), you can practice two or more Phrases repeatedly. During Phrase Repeat playback, press the [A-B REPEAT] button to assign the current Phrase to Phrase A. When playback reaches to the desired Phrase, press the [A-B REPEAT] button again to assign Phrase B. "A-B Rep" appears on the display, and Repeat playback between Phrases A and B starts. To cancel this setting, press the [A-B REPEAT] button again.

#### NOTE |

- You can set Phrases A and B also when playback is stopped by selecting the Phrase number via the [+/YES] and [-/NO] buttons
- Specifying only Point A results in repeat playback between Point A and the end of the Song.

## **Listening, Timing and Waiting**

### ●Lesson 1—Listening

In this Lesson, you need not play the keyboard. The model melody/chords of the part you selected will sound. Listen to it carefully and remember it well. When the Light Guide (Function 037; page 62) is on, the keys which are sounding will light.

### ●Lesson 2—Timing

In this Lesson, simply concentrate on playing the notes with the correct timing. Play the keyboard at the time the keys light. Even if you play wrong notes, the correct notes will sound.

### ●Lesson 3—Waiting

In this Lesson, try playing the lit notes on the lighting keyboard. These correct notes are also shown on the display. The Song pauses until you play the right note, and playback tempo will change to match the speed at which you are playing at.

#### NOTE .

- If you want to keep a steady playback tempo maintained during Lesson 3: Waiting, set the Your Tempo parameter to OFF via the Function number 035 (page 62).
- Drum sounds are not played in the Waiting Lesson.


## Press the [SONG] button then select a Song for your lesson.

### NOTE I

 The Song Lesson can be applied also to the Songs transferred from a computer (page 57), but cannot be applied to the User Songs.

#### NOTE I

- Songs 163 to 202 are not compatible with the Listening, Timing and Waiting Lessons.
- 2 Press either or both the [R] and [L] buttons to select the part you want to practice.



#### NOTE |

- If "No LPart" appears on the display by pressing the [L] button, the current Song does not contain a left-hand part.
- 3 Press the [1 LISTENING 2 TIMING 3 WAITING] button until the desired lesson is shown on the display and start it.

Pressing this button repeatedly will change the Lesson number from 1: LISTENING → 2: TIMING

→ 3: WAITING → off → 1.....



#### NOTE |

- During playback, you can change the Lesson mode by pressing this button, and you can stop the Lesson at any time by pressing the [START/STOP] button.
- When you play the Lesson Song, the Main Voice automatically changes to "000" (One Touch Setting; page 24). The Dual or Split Voice cannot be used during the Lesson.
- When the melody Voice of the Song is changed, the key position shown in the display may be shifted (in octave units), depending on the selected Voice.
- 4 When Lesson playback reaches to the end, check your evaluation Grade on the display.

"2 Timing" and "3 Waiting" will evaluate your performance in four levels.

After the evaluation display has appeared, the lesson will start again from the beginning.


5 Press the [START/STOP] button to stop the Lesson mode.

### **Turning the Guide Note off**

When the "Guide" function is on, you can hear the Guide note while you are practicing with Lesson 3 (Waiting), and this is ideal when you are not sure of which keys to play next. The Guide note will sound slightly behind the timing to indicate the correct note, when you fail to play the correct note with the correct timing. When you play the correct note with the correct timing, the Guide note will not sound and the playback continues.

If you don't want to hear the Guide note, turn the function to off in the following steps.

Press the [FUNCTION] button several times until "Guide" (Function 036; page 62) appears.



2 Use the [+/YES] and [-/NO] buttons to select the value "oFF."

The default value of this function is "on" (Guide note will sound.)

NOTE

 The Guide setting cannot be changed during the Lesson mode.

The Guide function can be used for all preset Songs, except Songs in categories "FAVORITE WITH STYLE" (left-hand part) and "CHORD PROGRES-SION." and No.51.

## Keys to Success with Listening, Timing or Waiting

You can combine the Keys to Success lesson (page 36) with the Listening, Timing or Waiting lesson (page 39).

- Per to Steps 1–3 on page 36.
- 2 Select the desired Step via the [+/YES]/
  [-/NO] buttons, then press the
  [1 LISTENING 2 TIMING 3 WAITING] button
  repeatedly to select the desired lesson.

The selected lesson playback starts under the Keys to Success mode. Practice the phrase of the current Step via the selected Lesson. As evaluation for each Step, just "Timing is correct!" or "Your playing is correct!" appears, and the passing status is not available.

- 3 To return to only the Keys to Success mode, press the [1 LISTENING 2 TIMING 3 WAITING] button repeatedly until "StepXX" (XX: number) appears in the display.
- 4 To exit from the Lesson mode, press the [KEYS TO SUCCESS] button.

## Phrase Repeat with Listening, Timing or Waiting

With Phrase Repeat set to On, press the [1 LISTEN-ING 2 TIMING 3 WAITING] button once, twice or three times to start and use Lesson playback with Phrase Repeat. Pressing the same button again several times to exit from the Lesson mode stops playback and allows use of just the Phrase Repeat mode.

NOTE |

• In this status, the evaluation function is not available.

# Learning How to Use "Touch" Control (Touch Tutor)

This learning feature lets you practice how hard or soft to play the keys for musical expression, referred to as "Touch" in this chapter, by playing back Song numbers 141 to 150 (in the "Touch Tutor" category). Playing back Songs from this category shows indications for the appropriate playing strength. Try playing according to the level displayed in the LCD as the Song progresses.

NOTE


- Be sure to set the Touch Response parameter (page 26) to a value other than "Fixed." When set to "Fixed," the Touch Tutor function is inactive.
- Select a Song from Song numbers 141 to 150 in the "Touch Tutor" category by executing Step 1 in "Selecting and Playing Back a Song" on page 32.

To play with the same Voice that is used in a performance data, select Voice number "000" (OTS; page 24). After this operation, please make sure to go back to the Touch Tutor display by pressing the [SONG] button.



- 2 Press the [START/STOP] button to play back the selected Song.
- 3 When the following display appears, play the lighting keyboard at the strength level displayed in the LCD.

Play while the strength level is shown.



Strength targets are indicated by " = ".

Your actual playing "Touch" is indicated by " ..."

Try playing so that the following indications appear (as target values) while you play.

ТОИСН ...... : Soft


ТОИСН ...... : Medium

ТОИСН ...... : Hard

The positions of " = " and " | " are displayed with a gap when your touch is softer or harder than the target value.


## Your touch is harder than the target value

(Target value: medium, your touch: hard)




### Your touch is same as the target value

(Target value: medium, your touch: medium)



### Your touch is softer than the target value

(Target value: medium, your touch: soft)



When your touch is accurate, the instrument evaluates the accuracy of the touch (velocity) and indicates the following evaluation results on the display. If you continue to play the keys with your "touch" to match the target value on the display, your grade will gradually increase. If you continue to play the keys inaccurately, your grade will gradually decrease.

Great! > VeryGood > Good > OK

### ↓ To stop the playback, press the [START/ STOP] button.

To exit from the Touch Tutor mode, select a Song from any other category, except "Touch Tutor."

NOTE |

• This function cannot be used with Keys to Success.

# Hearing and Experiencing the Sound of the Chords (Chord Study)

You can hear and experience the sound of the chords used in a typical performance by playing back Song numbers 151 to 162 (in the "Chord Study" category). Song numbers 151 to 157 are very simple Songs consisting of a single chord (C, Dm, Em, F, G, Am, Bm; respectively) played in various positions, letting you listen to and master the chords one by one. On the other hand, Song numbers 158 to 162 consist of several chords strung together in a pattern, for experiencing and understanding basic chord progressions. Hear and experience the sound of simple chords and progressions by playing back these Songs, and play the lighting keyboard.

## Hear and experience a sound of a single chord

- Select a Song from Song numbers 151 to 157 in the "CHORD STUDY" category by executing Step 1 in "Selecting and Playing Back a Song" on page 32.
- 2 Press the [START/STOP] button to play back the selected Song.
- 3 Play the lighting keyboard.



If you feel it difficult to play the notes, use the Waiting function (page 39) to have the Song automatically pause until you play the correct notes. Press the [1 LISTENING 2 TIMING 3 WAITING] button repeatedly until "WAITING" appears in the display. To exit from the Waiting function, press the same button again.

To stop the playback, press the [START/ STOP] button.

## Hear and experience basic chord progressions

- Select a Song from Song numbers 158 to 162 by pressing the [+/YES]/[-/NO] buttons.
- 2 Press the [START/STOP] button to play back the selected Song.
- 3 Play the lighting keyboard.

Listen to the basic chord progression, and play along with the Song repeatedly until you can smoothly perform and play along with the chord changes.

If you feel it difficult to play the notes, use the Waiting function (page 39) to have the Song automatically pause until you play the correct notes. Press the [1 LISTENING 2 TIMING 3 WAITING] button repeatedly until "WAITING" appears in the display. To exit from the Waiting function, press the same button again.

4 To stop the playback, press the [START/ STOP] button.

## Playing Chords along with Chord Progressions of a Song

Song numbers 163 to 202 in the "Chord Progression" category are constructed from typical chord progressions. You can listen to and get a feel for the chord progressions by playing back the Song and playing the lighting keyboard. The number of keys that are indicated for you to play progress in sequence—from a single root note, to two notes, then three and four—getting you to gradually and naturally memorize the chords. Also, you can change the key of the Song, allowing you to practice the progressions in all keys for full mastery of the chords.

- Select a Song from Song numbers 163 to 202 in the "Chord Progression" category by executing Step 1 in "Selecting and Playing Back a Song" on page 32.
- 2 Press the [PHRASE REPEAT] button. After "CHORD PROGRESSION" scrolls across the display, the tonic pitch of the selected Song and the number of the keys to be pressed are shown.

The tonic pitch of the selected Song: C


PHRASE REPEAT

Appears when Chord Progression is on.

The number of the keys to press: 1

NOTE |

- The initial key setting is C major or A minor.
- 3 Press the [+/YES]/[-/NO] buttons to select the number of the keys to be played. Each time the [+/YES] button is pressed, the number of the keys to press is increased from just one root note (1Note) to two notes (2Notes), three notes (3Notes) and four notes (All).



NOTE I

- The number of the keys to press can also be set by using the number buttons [1]-[4].
- Press the [START/STOP] button to play back the selected Song.
- 5 Play the lighting keyboard.




NOTE I

- When you play the keyboard within the range of C5–B5, the notes will not sound.
- 6 Press the [PHRASE REPEAT] button again to turn the Chord Progression function off.

### To change the key of a Song:

When Chord Progression is on, press one of the keys in the top octave (C5–B5; indicated to the right of "roop" on the panel, just above the keys) to change the tonic pitch of the Song.



For example, if you press the key D5 in the Song of C major, the key changes to D major.

NOTE |

The key of a Song cannot be changed during playback.

#### The number of the keys to be played

- Only one root note (1Note)
- Press only the root note of the chord.
- Two notes (2Notes)

Press the 3<sup>rd</sup> interval of a chord along with the root note, and understand the difference between major chords and minor chords.

Three notes (3Notes)

Press the 5<sup>th</sup> interval of a chord along with the root note and the 3<sup>rd</sup>.

• Four notes (All)

Press all the notes that make up the chord. Very often, chords are played with just three notes; however, another interval (such as a 7th) is sometimes added. Keep in mind that depending on the chord, there may be no 4<sup>th</sup> note.

## Play the chords in combination with "Waiting" of the Lesson function

You can practice the playing the chords in combination with "Waiting" (page 39) of the Lesson function by simply pressing the [1 LISTENING 2 TIMING 3 WAITING] button once.

NOTE

 Even if you play notes in octaves outside of the notes of the lighting keyboard (excluding the range of C5–B5, which are used to change the key of a Song), as well as different inversions of the chords, the playback will progress.

## Playing with Rhythm and Accompaniment (Styles)

This instrument includes an Auto Accompaniment feature that automatically plays appropriate "Styles" (rhythm + bass + chord accompaniment), controlled simply by playing only root note or all notes of a chord with your left hand.

You can select how you want to play the chords from two ways: "Smart Chord," which lets you play chords by playing a key with only one finger, and "Multi Finger," which lets you play them normally, with all the constituent notes.

## **Setting the Fingering Type**

How you play the chords when playing Styles is called "Fingering Type," which can be specified via Function number 017 (page 61). With this instrument, you can choose from two Fingering Types.

- Smart Chord (Default setting)
   You can play the Style by playing only the root note of a chord.
- Multi Finger

This is a way to play the Style by playing all notes of a chord. However, major, minor, seventh, and minor sevenths can also be easily played by pressing one to three keys.

For information about chords, refer to "Chord Types for Style Playback" (page 47) or use the Chord Dictionary function (page 49).

Press the [FUNCTION] button several times until "FingType" (Function 017; page 61) appears.

"FingType" is shown in the display for a few seconds, followed by the current Fingering Type.




- 2 Use the number buttons [0]-[9] or [+/YES] and [-/NO] buttons to select "SmartChd" or "Multi."
- 3 Press the [STYLE] button to exit from the Fingering Type settings.

## **Setting the Smart Chord Key**

If the Fingering Type is set to "SmartChd," you need to set the keys of the Songs you want to play in advance. The specified key is called the Smart Chord Key.

Press the [FUNCTION] button until "S.ChdKey" (Function 018; page 61) appears.

The current Smart Chord Key appears.



2 Press the [+/YES] and [-/NO] buttons to select the Smart Chord Key that matches the score.

For example, when you want to play the music score below, you need to set the Smart Chord Key to "FL2" (2 flats) (page 48).




3 Press the [STYLE] button to exit from the Smart Chord Key settings.

## **Playing Styles**

## Press the [STYLE] button, then use the number buttons [0]-[9], [+/YES], [-/NO] to select the desired Style.

The Style List is provided on the front panel, or in the Style List (page 85).




## 2 Press the [ACMP ON/OFF] button to turn on the Auto Accompaniment.



This icon appears when automatic accompaniment is on.

With this operation, the area of the keyboard to the left of the Split Point (054: F#2) becomes the "Auto Accompaniment range" and is used only for specifying the chords.



You can change the Split Point via Function number 003 (page 60) by holding down the [ACMP ON/OFF] button for longer than a second.

### NOTE |

• The strength meter (page 17) does not respond to playing in the Auto Accompaniment range.


## 3 Press the [SYNC START] button to turn Synchro Start on.

This puts the Style playback in "standby" and Style starts playing back when you play the keyboard.



## 4 Play a key in the Auto Accompaniment range to start playback.

If the Fingering Type is set to "SmartChd," play only the root note of a chord with your left hand. If the Fingering Type is "Multi," play all notes of a chord referring to page 47. Play a melody with the right hand and chords with the left hand.



## 5 Press the [START/STOP] button to stop playback.



You can add intro, ending and rhythm variations to Style playback by using "Sections." For details, refer to page 46.

#### To play back the rhythm part only

If you press the [START/STOP] button (without pressing the [ACMP ON/OFF] button in step 2), only the rhythm part can be played back, and you can play a melody performance using the entire keyboard range.

#### NOTE I

 Since the Pianist category Styles (197–205) have no rhythm parts, no sound will be produced if you start rhythm-only playback. When playing these Styles, make sure to carry out Steps 2–4 on this page.

## **Changing the Tempo**

Refer to "Changing the Tempo" on page 32.

## **Adjusting the Style Volume**

To adjust the volume balance between Style playback and keyboard, you can adjust the Style Volume. This can be set via Function number 016 (page 61).

## **Style Variations**

Each Style consists of "Sections" that allow you to vary the arrangement of the accompaniment to match the song you are playing.



#### INTRO

This is used for the beginning of the Song. When the Intro finishes, Style playback shifts to the Main section. The length of the Intro (in measures) differs depending on the selected Style.

#### MAIN

This is used for playing the main part of the Song. Playback of the Main section repeats indefinitely until another Section's button is pressed. There are two variations (A and B), and the Style playback sound changes harmonically in response on the chords you play with your left hand.

#### AUTO FILL

This is automatically added before changing to Main A or B.

#### ENDING

This is used for the ending of the Song. When the Ending finishes, the Style playback stops automatically. The length of the Ending (in measures) differs depending on the selected Style.

## 1 - 3

Same as Steps 1-3 in page 45.

☐ Press the [MAIN/AUTO FILL] button to select Main A or Main B.




5 Press the [INTRO/ENDING/rit.] button.



Now, you're ready to start Style playback from the Intro section.

## 6 Play a chord with your left hand to start playback of the Intro.

For example, play a C major chord. For information on how to enter chords, refer to page 47.




## 7 After the Intro finishes, play the keyboard according to the progression of the Song you are playing.

Play chords with your left hand while playing melodies with your right hand, and press the [MAIN/ AUTO FILL] button as necessary. The Section will change to Fill-in then Main A or B.



8 Press the [INTRO/ENDING/rit.] button.



The Section switches to the Ending. When the Ending is finished, Style playback stops automatically. You can have the Ending gradually slow down (ritardando) by pressing the [INTRO/END-ING/rit.] button again while the Ending is playing back.

## **Chord Types for Style Playback**

For users who are new to chords, this chart conveniently shows how to play common chords in the Auto Accompaniment range of the keyboard. You can also use the Chord Dictionary function (page 49) to find out how to play the chords. Since there are many useful chords and many different ways to use them musically, refer to commercially available chord books for further details.

When the Fingering Type is "Multi," play the notes that make up the chord in the Auto Accompaniment range. When the Fingering Type is "SmartChd." play the root note "\*" in the Auto Accompaniment range.

\* indicates the root note.

Major	Minor	Seventh	Minor Seventh	Major Seventh
С	Cm	C <sub>7</sub>	Cm <sub>7</sub>	CM <sub>7</sub>
* • •	*	*   •   •	*	*   •   •     •
D	Dm	D <sub>7</sub>	Dm <sub>7</sub>	DM <sub>7</sub>
	* • •	*	* • •	*   •
E	Em	E <sub>7</sub>	Em <sub>7</sub>	EM <sub>7</sub>
*   •				
F	Fm	F <sub>7</sub>	Fm <sub>7</sub>	FM <sub>7</sub>
G	Gm	G <sub>7</sub>	Gm <sub>7</sub>	GM <sub>7</sub>
* • •				* •
Α	Am	A7	Am <sub>7</sub>	AM <sub>7</sub>
	* • •			*
В	Bm	В <sub>7</sub>	Bm <sub>7</sub>	BM <sub>7</sub>

- Inversions can be used as well as in "root" position—with the following exceptions: m7, m7 \( \delta 5, \) m7(11), 6, m6, sus4, aug, dim7, 7 \( \delta 5, \) 6(9), sus2
- · Inversions of the 7sus4 chords are not recognized if the notes are omitted.
- When playing a chord which cannot be recognized by this instrument, nothing is shown on the display. In such a case, only a specific
  part, such as the rhythm, will be played.

When "Multi" is selected, major, minor, seventh, and minor sevenths can also be easily played by pressing one to three keys.

Easy Chords for root "C"



To play a major chord Press the root note (★) of the chord.



To play a minor chord Press the root note together with the nearest black key to the left of it.



To play a seventh chord Press the root note together with the nearest white key to the left of it.



To play a minor seventh chord Press the root note together with the nearest white and black keys to the left of it (three keys altogether).

## **Chords Heard When Smart Chord is Selected**

When the Fingering Type is "SmartChd," if you set Smart Chord Key based on the composition of the score (page 44), play the root note in the Auto Accompaniment range. This lets you hear the respective chords below.

Key							Root	Note					
Signature on the music score	Smart Chord Key (Display)	С	Db	D	E♭	E	F	F#	G	G#	A	ВЬ	В
6,,,,	FL7	C dim	D♭m	D dim7	E♭ 1+5	E	F dim	F# 7	G	G# m	A	B♭ m7 ♭5	В
	FL6	C dim	D <b>▶</b> 7	D	E♭m	E	F m7 ▶5	F#	G dim	G# m	A dim7	B♭ 1+5	В
<b>2</b> , <b>3</b> , <b>5</b> , <b>5</b> , <b>6</b>	FL5	C m7 ▶5	DÞ	D dim	E♭m	E dim7	F 1+5	F#	G dim	G# 7	A	B♭m	В
<b>6</b> , , ,	FL4	C 1+5	Dŀ	D dim	E♭ 7	Е	Fm	F#	G m7 ♭5	G#	A dim	B♭m	B dim7
<b>&amp; !</b>	FL3	C m	Dŀ	D m7 ▶5	Εb	E dim	Fm	F# dim7	G 1+5	G#	A dim	B♭ 7	В
	FL2	C m	D♭ dim7	D 1+5	E♭	E dim	F 7	F#	G m	G#	A m7 ▶5	ВЬ	B dim
<b>&amp;</b> ,	FL1	C 7	DÞ	D m	Εŀ	E m7 ↓5	F	F# dim	G m	G# dim7	A 1+5	В♭	B dim
No key signature	SP0 (Default)	С	D♭ dim	D m	E♭ dim7	E 1+5	F	F# dim	G 7	G#	A m	ВЬ	B m7 ▶5
<b>*</b>	SP1	С	D♭ dim	D 7	Εb	E m	F	F# m7 ♭5	G	G# dim	A m	B♭ dim7	B 1+5
<b>6</b> <sup>‡</sup>	SP2	С	D♭ m7 ♭5	D	E♭ dim	Em	F dim7	F# 1+5	G	G# dim	A 7	ВЬ	B m
<b>6</b> ##	SP3	C dim7	D♭ 1+5	D	E♭ dim	E 7	F	F# m	G	G# m7 ▶5	A	B♭ dim	B m
<b>6</b> ***	SP4	С	D♭m	D	E♭ m7 ♭5	E	F dim	F# m	G dim7	G# 1+5	A	B♭ dim	В7
	SP5	C dim	D⊩m	D dim7	E♭ 1+5	E	F dim	F# 7	G	G# m	A	B♭ m7 ♭5	В
	SP6	C dim	D♭ 7	D	E♭m	E	F m7 ▶5	F#	G dim	G# m	A dim7	B♭ 1+5	В
<b>***</b>	SP7	C m7 ▶5	Dŀ	D dim	E♭m	E dim7	F 1+5	F#	G dim	G# 7	A	B♭m	В

#### NOTE I


<sup>•</sup> The "1+5" chord indication on the instrument's display is the same as that of a major chord.

## Looking Up Chords Using the Chord Dictionary

The Dictionary function is useful when you know the name of a certain chord and want to quickly learn how to play it.

Press and hold the [1 LISTENING 2 TIMING 3 WAITING] button for longer than a second to call up "Dict."

"Dict." will appear in the display.




This operation will divide the entire keyboard into the three ranges as illustrated below.

- The range to the right of "ROOT": Lets you specify the Chord Root, but produces no sound.
- The range between "CHORD TYPE" and "ROOT":

Lets you specify the Chord Type, but produces no sound.

 The range to the left of "CHORD TYPE": Lets you play and confirm the Chord specified in the above two ranges.



- 2 As an example, learn how to play a GM7 (G major seventh) chord.
  - 2-1. Press the "G" key in the section to the right of " [OOT]" so that the "G" is shown as the root note.





2-2. Press the key labeled "M7" in the section between "CHORDTYPE" and "ROOD"."

The notes you should play for the specified chord are lit. They are also shown in the keyboard display.



Chord name (root and type)



To call up possible inversions of the chord, press the [+/YES]/[-/NO] buttons.

NOTE |

- About major chords: Simple major chords are usually indicated only by the root note. For example, "C" refers to C major. However, when specifying major chords here, make sure to select "M" (major) after pressing the root note.
- These chords are not shown in the Chord Dictionary function: 6(9), M7(9), M7(#11), \( \beta \), M7\( \beta \), M7\( \beta \), M7\( \text{p} \), mM7(9), mM7\( \beta \), 7\( \beta \), 5, sus2
- 3 Following the notation and keyboard diagram in the display, try playing a chord in the range to the left of "CHORD TYPE".

When you've played the chord properly, a bell sound signals your success and the chord name in the display flashes.

4 To exit from the Chord Dictionary mode, press one of these buttons; [VOICE], [SONG] or [STYLE].

## **Using the Music Database**

If you have difficulty finding and selecting the desired Style and Voice, use this feature. From the Music Database, just selecting the favorite music genre calls up the ideal settings.

Press the [MUSIC DATABASE] button. Both the Auto Accompaniment and Synchro Start are automatically turned on.



2 Use the number buttons [0]–[9], [+/YES], [-/NO] to select the desired Music Database.

This operation calls up the panel settings such as Voice and Style that are registered to the selected Music Database. The category name of Music Database List is provided on the front panel, or in the Music Database List (page 87).


3 Play the keyboard as described in Steps 4–5 on page 45.

## **Registering a Style File**

Style data created on another instrument or computer can be registered (loaded) to Style numbers 206–215, and you can play them just the same as the internal preset Styles.

- Transfer the Style file (\*\*\*.STY) from a computer to this instrument by connecting this instrument and the computer.

  For instructions, refer to "Computer-related Operations" on the website (page 8).
- 2 Press the [FUNCTION] button several times until "StyleReg" (Function 060; page 63) appears.



After about two seconds, a registerable Style file name will appear in the display.

- 3 If some Style files have already been transferred to the instrument, select the desired Style by using the [+/YES] or [-/NO] button.
- ⚠ Press the [0] button.

As the Load destination, "\*\*\*Load To?" (\*\*\*: 206–215) appears on the display. If desired, select a different number using the [+/YES] or [-/NO] button.

5 Press the [0] button.

A confirmation message will appear. To cancel the operation, press the [-/NO] button.

6 Press the [+/YES] button to actually load the file.

After a while, a message indicating completion of the operation appears.

#### NOTICE

- The load operation cannot be cancelled during execution. Never turn off the power during the operation.
   Doing so may result in data loss.
- Press the [STYLE] button, use the [+/YES] or [-/NO] button to select a Style from 206–215, and then try playing it back.

For instructions on playing the Style, refer to page 45.

## Recording Your Performance

You can record up to 5 of your performances as User Songs (User 1–5: Song numbers 203–207). The recorded User Songs can be played back on the instrument. The recorded User Song can be played back in the same way as the preset Songs.

## **Track Structure of a Song**

You can record your performance to the following two tracks of a User Song individually or simultaneously.

### ●Track 1:

Your melody performance is recorded to this track.

#### ●Track 2:

Your melody performance, or Style playback (Chord changes and Section changes), is recorded to this track



### ●Recording Data Capacity:

A total of approximately 10,000 notes can be recorded to the five User Songs.

## **Quick Recording**


The operation is convenient for recording a new Song without having to specify a track.

## Make the desired settings such as Voice and Style settings.

If you want to record only the melody performance, turn ACMP off (page 45). If you want to record Style playback or Rhythm playback as well as melody performance, turn ACMP on (page 45).

## Press the [REC] button to enter the Record Ready mode.

This operation selects the lowest-numbered unrecorded User Song ("User 1"—"User 5") as the recording target, if a User Song has not been specified in advance or if Record Ready mode has been entered from the Style mode. If you want to select another Song, use the [+/YES] and [-/NO] buttons.



To exit from the Record Ready mode, press the [REC] button again to stop flashing on the display.

#### NOTICE


 If all User Songs contain recorded data, "User 1 (Song Number 203)" will automatically be selected. In this case, since you will record over and erase any previous data in "User 1," we recommend that you save your important data to a computer (see page 59).

#### NOTE

 ACMP cannot be turned on or off in this status while you can select another Style in this status by using the [STYLE] and Number buttons.

### 3 Play the keyboard to start recording.

If ACMP is turned on, you can independently record just the rhythm sound of Style playback by pressing the [START/STOP] button then changing the Section (page 46).



## Press the [START/STOP] button to stop recording.

When using a Style, you can stop recording also by pressing the [INTRO/ENDING/rit.] button then waiting until playback ends.

#### NOTICE

- After Recording stops, a "Writing!" message is shown on the display for a while. Never attempt to turn the power off while this is shown in the display. Doing so can damage the internal memory and result in a loss of data.
- 5 To play back the recorded Song, press the [START/STOP] button.

#### Limitations while Recording

- You cannot record the Reverb Level, Metronome click, or the Transpose and Tuning settings.
- The following settings and buttons are not available, or if operated, the new settings cannot be recorded: ACMP ON/OFF, Split Point, Reverb Type, Chorus Type, Harmony/Arpeggio Type, [FUNCTION] button, [PORTABLE GRAND] button.
- When you play the keyboard while turning the DSP on and record your performance, make sure to record it to track 1.

## **Recording to a Specified Track**

1 Make the desired settings, such as those of Voice or Style.


If you want to record the melody performance, turn ACMP off (page 45). If you want to record Style playback, turn ACMP on (page 45).

2 While holding down the [REC] button, press the desired Track button 1 or 2 to engage the Record mode.

If you want to record Style playback, make sure to select the Track 2. If you want to record melody performance, select either Track 1 or Track 2 as desired. The illustration below is the example when selecting Track 2.



The User Song appears on the display.



Flashing: Track is selected as a recording target. Lit: Track contains data

Unlit: Track contains no data or is muted.

You can record your performance while playing back or muting the recorded track. To play back or mute the track, press the [REC TRACK 1] or [REC TRACK 2] button. Each time the corresponding button is pressed, playback/mute is switched.


- ? Press the [+/YES], [-/NO] buttons to select the User Song you want to record.
- ⚠ Same as in Steps 3 to 5 (page 51) in "Quick Recording."

When playing back the recorded Song, pressing [REC TRACK 1] or [REC TRACK 2] button allows you to mute Track 1 or Track 2. Each time the button is pressed, playback/mute is switched.

## **Clearing a User Song**

- 1 Press the [SONG] button then select the desired User Sona by using the Number buttons.
- 2 Press and hold the [REC] button for longer than a second.

A confirmation message appears.



To cancel the operation, press the [-/NO] button.

3 Press the [+/YES] button.

A confirmation message appears again.



To cancel the operation, press the [-/NO] button.

⚠ Press the [+/YES] button to clear the Sona.

A "Writing!" message appears while the Song is being cleared.

## Memorizing Your Favorite Panel Settings

This instrument has a Registration Memory feature that lets you memorize your favorite settings for easy recall whenever they're needed. Up to nine complete setups can be memorized and assigned to each number button 1–9. (Factory settings are recorded to 1-9.)

## **Recalling Panel Settings from the Registration Memory**

### 1 Press the [REGIST MEMORY] button.

"LoadNo.?" appears on the display.






Appears after [REGIST MEMORY] button is pressed.

## 2 Press one of the [1]–[9] buttons to call up the panel settings you memorized.

The recalled Registration Memory number and the Voice Name in the Memory appear on the display.



The Registration Memory number can be changed by pressing one of the other [1]–[9] buttons. To exit from Registration Memory, press the [REGIST MEMORY] button.

### **Factory settings**

Registration Memory Number	Voice Name in Memory
R01	S.Art Lite Nylon Guitar Harmonics
R02	S.Art Lite Steel Guitar Harmonics
R03	S.Art Lite Distortion Guitar
R04	S.Art Lite Slap Bass
R05	S.Art Lite Strings
R06	S.Art Lite Gospel Choir
R07	S.Art Lite Tenor Sax
R08	S.Art Lite Brass Section
R09	S.Art Lite Flute

### Parameters that are memorized to Registration Memory

- Style settings\*
  - Style number, ACMP on/off, Style volume, Tempo, Main A/B, Fingering Type, Smart Chord Key
  - Voice settings
  - **Main Voice settings:** Voice number and all settings of the related Functions
  - **Dual Voice settings:** Dual on/off and all settings of the related Functions
  - **Split Voice settings:** Split on/off and all settings of the related Functions
- Effect settings: Reverb Type, Reverb level, Chorus Type, DSP on/off, DSP Type, Sustain on/off
- Harmony/Arpeggio settings: Harmony/Arpeggio on/off and all settings of the related Functions
- Other settings: Transpose, Split Point, All settings for the Function "DUO". Pedal Function
- \* When a Song is selected, the Style settings cannot be recorded or called up.

## **Memorizing Panel Settings to the Registration Memory**

- Make the desired settings such as those for Voice and Style.
- 2 Press and hold down the [REGIST MEM-ORY] button for longer than a second.

"MemNo.?" appears on the display.



3 Press one of the [1]–[9] buttons to memorize the current panel settings.

If you select a Registration Memory number that already contains data, an "Overwr?" message appears in the display. To overwrite, press the [+/YES] button; to cancel, press [-/NO].



When memorizing is completed, "Mem OK" is displayed.


#### NOTICE

- If you select a Registration Memory number that already contains data, the previous data is deleted and overwritten by the new data.
- To restore all Registration Memories to the factory settings, execute Backup Clear operation (page 59).
- Do not turn off the power while memorizing settings to the Registration Memory, otherwise the data may be damaged or lost.


## **Deleting the Registration Memory**

1 Hold down the [REGIST MEMORY] button for longer than a second.

"MemNo.?" is shown in the display.



2 Hold down the [1]-[9] buttons corresponding to the Registration Memory number you want to delete for longer than a second.



"CIrRegX?" ("X" represents the Registration Memory number) is shown in the display.

3 Press the [+/YES] button to delete the Registration Memory.

Press the [-/NO] button to cancel deleting the Registration Memory. When deleted, the Registration Memory number on the display disappears.

123 45 789

## Disabling Recall of Specific Items (Freeze)

Registration Memory lets you recall all the panel setups you made with a single button press. However, depending on the situation when you perform, there may be some settings you do not want to recall. When you want to switch the Voice settings but still maintain the Style settings, for example, you can "freeze" only the Style settings and have those Style settings remain, even when you select another Registration Memory number.


Select the items you want to freeze via Function numbers 048, 049, and 050 (page 63).

## Selecting an EQ Setting for your Favorite Sound

Six different master equalizer (EQ) settings let you create the optimum sound when listening through different reproduction systems—the instrument's internal speakers, headphones, or an external speaker system.

Press the [FUNCTION] button several times until the "MasterEQ" (Function 025; page 61) item appears on the display.

"MasterEQ" is shown in the display for a few seconds, and the current Master EQ type appears.



2 Use the [+/YES] or [-/NO] button to select the desired Master EQ type.

#### Master EQ types

1	Speaker	Optimum for listening via the instrument's built-in speakers.
2	Headphone	Optimum for headphones, or for listening via external speakers.
3	Boost	Features more powerful sound.
4	Piano	Optimum for piano solo performance.
5	Bright	Lowers the mid range for a brighter sound.
6	Mild	Lowers the high range for a softer sound.

## Connecting to Other Devices

### **!** CAUTION

Before connecting, turn off the power of both this instrument and the external audio device. Also, before turning the power on or
off, make sure to set all volume levels to minimum (0). Otherwise, damage to the devices, electrical shock, or even permanent
hearing loss may occur.

## Playing an External Audio Device with the Built-in Speakers

You can output the sound of an audio device, such as a smartphone, with the built-in speakers of this instrument by connecting it via a cable. This lets you play the keyboard along with playback of your music player.


#### NOTICE

 To avoid damage to the external audio device and this instrument, first turn on the power to the external device, and then to the instrument. When turning off the power, first turn off the power to the instrument, and then to the external device.

#### NOTE

- If you are using a computer or a smart device such as a smartphone or tablet, you can also connect it to the [USB TO HOST] terminal (see "Connecting to a Computer" on page 57).
- Turn off the power for both the external audio device and this instrument.
- 2 Connect the audio device to the instrument's [AUX IN] jack.

Use the cable (no resistance) which has the stereo-mini plug at one side for connecting to this instrument and the plug matching the output jack of the external audio device at the other side.



3 Turn on the external audio device, then this instrument.

## 4 Play back the connected external audio device.

The sound of the audio device is output through the speakers of this instrument.

5 Adjust the volume balance between the external audio device and this instrument.

Adjust the audio playback volume on the audio device, then adjust the entire volume by rotating the [MASTER VOLUME] control of the instrument.

#### NOTE


- You can adjust the level of the input from the external audio device by calling up "AuxInVol" via Function number 043 (page 62) and using the [0]-[9], [+/YES], [-/NO] buttons. If you increase the volume to more than 50, the audio device sound may be distorted.
- 6 Play the keyboard along with the sound of the audio device.

You can cancel or lower the volume of the melody part of audio playback. For details, refer to page 58.

7 After finishing the performance, stop playback of the audio device.

## **Connecting to a Computer**

By connecting the [USB TO HOST] terminal of this instrument to a computer via a USB cable, you can perform the following convenient functions.



#### NOTE ,

- Use an AB type USB cable of less than 3 meters.
- USB 3.0 cables cannot be used.

## Transferring MIDI Files, such as Song or Style Files

You can play Song files transferred from a computer to the instrument (page 19), or take User Songs (page 51) recorded on the instrument and transfer them to the computer for further editing and/or saving.

You need to turn the function settings "Storage Mode" (Function 059; page 63) on before making the file transfer. For details, refer to "Computer-related Operations" on the website (page 8).

#### Files that can be transferred

- · Song files (Extension: .MID)
- Song files created on other instruments or computers can be transferred to this instrument. Note that user Songs created with this instrument cannot be transferred to a computer as a single file.
- · Style files (Extension: .STY)
  - This instrument does not have a function for creating Style files, but you can import a style file created on another device. The maximum capacity per file is 50KB. Files that exceed the limit will not be recognized on this instrument.
- · Backup files (Extension: .BUP)
- You can transfer the data of "Parameters backed up as needed" and "Parameters backed up when the power is turned off"(excluding "Passing Status of Keys to Success") on page 59 to the computer and save the data as a single backup file.

#### NOTE I

- Files up to a total of about 1.4 MB can be transferred to this instrument.
- If you transfer a Style file to this instrument, you need to register it before using it on the instrument. For details, refer to "Registering a Style File" (page 50).
- Files transferred to the instrument are listed in the instrument in the order of symbol, number and alphabet.

#### NOTE A

While Storage Mode is set to on, you cannot play the instrument, nor can you transmit/receive MIDI or Audio data. Set Storage Mode to on only when transferring files.

### Transmitting/Receiving MIDI Data

The USB cable connection to a computer lets you listen to MIDI Songs played back on the computer or record your performance on the instrument as MIDI data to the computer.

## Transmitting/Receiving Audio Data (USB Audio Interface)

The USB cable connection to a computer also lets you play the audio data on the computer with high sound quality on the instrument or record your performance on the instrument as an Audio data to the computer.

A dedicated driver must be installed for transmitting/ receiving Audio data. For details, refer to "Computerrelated Operations" on the website (page 8).

#### NOTE I

- The volume can be adjusted both on the computer and by using the instrument's [MASTER VOLUME] dial. You can also adjust the level of the audio input sound via [USB TO HOST] terminal by calling up "USBINVol" via Function number 044 (page 62) and using the [0]-[9], [+/YES], [-/NO] buttons.
- When outputting the audio playback from the instrument to the computer—for example, when recording the audio input sound from the [USB TO HOST] terminal with the performance played on the instrument—you cannot adjust the level of the audio data with the [MASTER VOLUME] dial.
- If you are using the instrument with a music production application, such as a DAW (Digital Audio Workstation), set "Loop-back" (Function 045; page 62) to off. If this is instead set to on, a mix of the audio data and the sound of the instrument is sent to DAW, which may cause howling and unexpected loud sounds.

## **Connecting a Smart Device**

By connecting a smart device such as a smartphone or tablet to the instrument, you can take advantage of various functions. For details on connections, refer to "Smart Device Connection Manual" on the website (page 8). For information about the compatible smart devices and apps, access the following page: https://www.yamaha.com/kbdapps/

#### NOTE

- If you are using the instrument with a music production application such as a DAW (Digital Audio Workstation), set "Loopback" (Function 045; page 62) to off. If it is set to on, a mix of the audio data and the sound of the instrument is sent to DAW, which may cause howling and unexpected loud sounds.
- · Use an AB type USB cable of less than 3 meters.
- USB 3.0 cables cannot be used.
- You can adjust the level of the audio input sound via [USB TO HOST] terminal by function settings "USBINVol" (Function 044; page 62).

## Lowering the volume of a melody part (Melody Suppressor function)

When you output the audio sound of an external audio device or a computer connected to the [AUX IN] jack or the [USB TO HOST] terminal through this instrument, you can cancel or lower the volume of the melody part of audio playback. You can use the function to practice the melody part along with the audio playback.

- Play back audio on the connected external device.
- 2 Press the [FUNCTION] button several times to call up "MelodySP" (Function 046; page 62).




3 Press the [+/YES] button to select "on."

#### NOTE

 When the instrument is connected to the [USB TO HOST] terminal, and Audio Loop Back (Function 045; page 62) is set to OFF, the Melody Suppressor function cannot be used. 4 To cancel the Melody Suppressor function, press the [-/NO] button to select "oFF."

When the melody or vocal sound may not be canceled (or lowered) as expected

Press the [FUNCTION] button several times to call up "SupprPan" (Function 047; page 62) while the Melody Suppressor function is turned on.



2 Adjust the pan position of the sound to be cancelled (lowered) by using the [+/YES], [-/NO] buttons.

#### NOTE

 Depending on the particular music content, the melody or vocal sound may not be canceled as expected even if the Melody Suppressor is turned on.

## Backup and Initialization

## **Backup Parameters**

The following Backup parameters will be maintained even if the power is turned off.

### Parameters backed up as needed

- · User Songs (page 51)
- Style Number 206-215 (page 50)

#### Parameters backed up when the power is turned off

- Registration Memory (page 53)
- · Passing Status of Keys to Success (page 37)
- Function Settings: (page 60)

Tuning, Split Point, Touch Response, Style Volume, Song Volume, Metronome Volume, Your Tempo, Demo Group, Demo Play Mode, Master EQ type, Sustain, Auto Power Off, Battery Type, Guide, Audio Loop Back, Fingering Type, [AUX IN] Audio Volume, [USB TO HOST] Audio Volume, Style Freeze, Transpose Freeze, Voice Freeze

In addition to the Backup parameters above, all the data (including Style data that have not been loaded) transferred from the connected computer will be maintained even if you turn off the power.

Backup parameters other than "Passing Status of Keys to Success" can be transferred and saved to a computer as a single Backup file (with the extension: .BUP). This backup file can be loaded to the instrument for future.

For details on using a computer with this instrument, refer to "Computer-related Operations" on the website (page 8).

#### NOTICE

- Backup is executed automatically when the power is turned off. When the power is turned off in the following cases, backup is not executed.
  - Disconnected AC adaptor
  - Power failure
  - Low or no battery power

## **Error during Backup Operation**

When connecting to a computer with Storage Mode (Function 059; page 63) set to on, the memory space on the instrument may be insufficient for creating a backup file for transferring to the computer. In this situation, the error message "Not enough storage for backup" scrolls on the display. If you want to save a backup file to the computer, delete unnecessary Song files or Style files on this instrument to ensure sufficient memory space, and then set Storage Mode to off and back to on again. A backup file will be created.

If you do not save a backup file on the computer, there is no problem if an error message is displayed, and you can ignore the message.

#### NOTE I

- The size of a backup file varies depending on the amount of data stored on the instrument. The maximum capacity is about 620KB.
- Even if a backup file for transferring to a computer is not created, the backup data is retained in the instrument.


## **Initialization**

You can initialize your original data via the following two methods.

### **Backup Clear**


This operation initializes the backup parameters and the Registration Memories.

While holding down the highest white key, press the  $[\begin{array}{c} b\end{array}]$  (Standby/On) switch to turn the power on.



#### Flash Clear

This operation deletes all the Songs and Styles that have been transferred from a computer. Note that Style data registered to Style numbers 206–215 will be maintained. While simultaneously holding the highest white key and the three highest black keys, press the [ (b) ] (Standby/On) switch to turn the power on



#### NOTICE


 Keep in mind that Backup Clear and Flash Clear also delete the data you have purchased. Be sure to save the important data to a computer.

## The Functions

The Functions settings provide access to a range of detailed instrument parameters such as Tuning, Split Point, Voices and Effects.

Press the [FUNCTION] button several times until the desired item appears.

Each time the [FUNCTION] button is pressed, the Function number increases one by one. To decrease the Function number by one, simultaneously hold down the [FUNCTION] button and press the [-/NO] button briefly. Simply pressing only the [+/YES] or [-/NO] button does not change the Function number.




After a few seconds, the Function name may be replaced with the setting value depending on the selected Function.

### NOTE |

- When the Function settings display does not appear, press one of the [VOICE], [SONG] or [STYLE] buttons, and then press the [FUNCTION] button again.
- The Function number does not appear in the display during Song, Style or Metronome playback. The beat value appears instead.

2 Set the value by using the number buttons [0]–[9], [+/YES], [-/NO].



3 To exit from the Function settings, press one of these buttons; [VOICE], [SONG] or [STYLE].

#### **Function List**

Function				Default	
Number	Function name	Display	Range/Settings	Value	Descriptions
Overall					
001	Transpose	Transpos	-12-12	00	Determines the pitch of the instrument in semitone increments.
002	Tuning	Tunin9	427.0Hz-453.0Hz	440.0Hz	Determines the fine tuning of the pitch of the entire instrument in approx. 0.2Hz increments.
003	Split Point	SplitPnt	036-096 (C1-C6)	54 (F#2)	Determines the highest key for the Split Voice and sets the Split "point"—in other words, the key that separates the Split (lower) and Main (upper) Voices. This setting is applied to the Accompaniment Split Point setting (page 45).
004	Touch Response	TouchRes	1 (Soft), 2 (Medium), 3 (Hard), 4 (Fixed)	2 (Medium)	Refer to page 26.
Main Vo	ice (page 24)			1	
005	Volume	M.Volume	000-127	*	Determines the volume of the keyboard performance when performing along with a Song or a Style.
006	Octave	M.Octave	-2 - +2	*	Determines the octave range for the Main Voice.
007	Chorus Depth	M.Chorus	000–127	*	Determines how much of the Main Voice's signal is sent to the Chorus effect.

Function Number	Function name	Display	Range/Settings	Default Value	Descriptions
Dual Voi	ce (page 25)				
800	Dual Voice	D.Voice	001-622	*	Determines the Dual Voice.
009	Volume	D.Volume	000-127	*	Determines the volume of the Dual Voice.
010	Octave	D.Octave	-2 - +2	*	Determines the octave range for the Dual Voice.
011	Chorus Depth	D.Chorus	000–127	*	Determines how much of the Dual Voice's signal is sent to the Chorus effect.
	ce (page 25)			1	
012	Split Voice	S.Voice	001–622	*	Determines the Split Voice.
013	Volume	S.Volume	000–127	*	Determines the volume of the Split Voice.
014	Octave	S.Octave	-2 - +2	*	Determines the octave range for the Split Voice.
015	Chorus Depth	S.Chorus	000–127	*	Determines how much of the Split Voice's signal is sent to the Chorus effect.
Style (pa	age 44)				
016	Style Volume	StyleVol	000–127	100	Determines the volume of the Style while a Style is selected (page 45).
017	Fingering Type	Fin9Type	1 (SmartChd) 2 (Multi)	1 (SmartChd)	Determines the method of chord detection in the Accompaniment Section when playing with a Style.
018	Smart Chord Key	S.ChdKey	FL7 (7 Flats   ) - SP0 (No Key Signature) - SP7 (7 Sharps #)	SP0 (No Key Signature)	Determines the Key Signature when the Fingering Type is set to "SmartChd." For example, if there are 2 sharps (‡) in your music score, press the [+/YES][-/NO] buttons until "SP2" appears on the display.
Song (pa	age 31)		II.		
019	Song Volume	SongVol	000-127	100	Determines the volume of the Song when a Song is selected (page 32).
Effects	l		l	l	
020	Reverb Type	Reverb	1-4 (Hall 1-4) 5 (Cathedral) 6-8 (Room 1-3) 9-10 (Stage 1-2) 11-12 (Plate 1-2) 13 (Off)	**	Determines the Reverb type, including Off (page 91).
021	Reverb Level	RevLevel	000–127	064	Determines how much of the Voice's signal is sent to the Reverb effect.
022	Chorus Type	Chorus	1 (Chorus1) 2 (Chorus2) 3 (Chorus3) 4 (Flanger1) 5 (Flanger2) 6 (Off)	**	Determines the Chorus type, including Off (page 91).
023	DSP Type	DSPType	01–38	*	Determines the DSP Type (page 91).
024	Sustain	Sustain	ON/OFF	OFF	Determines whether the Sustain function is on or off (page 27).
025	Master EQ Type	MasterEQ	1 (Speaker) 2 (Headphone) 3 (Boost) 4 (Piano) 5 (Bright) 6 (Mild)	1 (Speaker)	Determines what type of equalization is applied to the speaker output or headphone output for optimum sound in different listening situations (page 55).
Harmon	y/Arpeggio (page 2	8)			
026	Harmony/ Arpeggio Type	Harm/Are	001-026 (Harmony) 027-176 (Arpeggio)	*	Determines the Harmony type or Arpeggio type.
027	Harmony Volume	HarmUo1	000–127	*	Determines the volume of the Harmony effect.
028	Arpeggio Velocity	ArrVelo	1 (Original) 2 (Key)	**	Determines the Arpeggio velocity. If "Key" is selected, arpeggios will be played back at a volume matching the strength at which you play the keyboard. If "Original" is selected, arpeggios will be played back at their original volume regardless of your playing strength.
Pedal (p	ages 27, 29)				_
029	Pedal Function	PdlFunc	1 (Sustain) 2 (Arp Hold) 3 (Sus+ArpH) 4 (Articulation)	1 (Sustain)	Sustain: Sustain will be produced while the pedal is held down. Arp Hold: Arpeggio playback will continue while the pedal is held down. Sus + ArpH: Sustain will be produced and Arpeggio playback will continue while the pedal is held down. Articulation: Articulation effect will be produced while the pedal is held down.

Function Number	Function name	Display	Range/Settings	Default Value	Descriptions
Metrono	me (page 24)		1		
030	Time Signature Numerator	TimeSigN	00–60	**	Determines the time signature of the Metronome.
031	Time Signature Denominator	TimeSigD	Half note, Quarter note, Eighth note, Sixteenth note	**	Determines the length of each Metronome beat.
032	Metronome Volume	MetroVol	000-127	100	Determines the volume of the Metronome.
Lesson	(page 35)		-		
033	Lesson Track (R)	R-Part	01–16	01	Determines the track number for your right hand lesson. The setting is only effective for Songs in SMF format 0 transferred from a computer.  Select a Song you want to use for the lessons, select the "R-Part," and then use the number buttons [0]–[9], [+/YES] and [-/NO] to select the channel you want to play back as the specified righthand part. We recommend that you select channel 1 for the righthand part.
034	Lesson Track (L)	L-Part	01–16	02	Determines the track number for your left hand lesson. The setting is only effective for Songs in SMF format 0 transferred from a computer.  Select a Song you want to use for the lessons, select the "L-Part," and then use the number buttons [0]–[9], [+/YES] and [-/NO] to select the channel you want to play back as the specified left-hand part. We recommend that you select channel 2 for the left part.
035	Your Tempo	YourTemp	ON/OFF	ON	This parameter is for Lesson 3 "Waiting." When this is set to ON, playback tempo will change for matching the speed you are playing at. When this is set to OFF, playback tempo will be maintained regardless of the speed you are playing at.
036	Guide	Guide	ON/OFF	ON	Determines whether the Guide note sounds (ON) or not (OFF) during the "Waiting" lesson.
Light Gu	uide (Lighting Keyb	oard)			
037	Light Guide	Light	ON/OFF	ON	Turns the Light Guide function (page 36) on/off.
038	Light Part 1 Setting	LightPt1	01–16	01	Determines the 1st part (channel) which lights the keyboard when playing a MIDI Song contained on the computer with this instrument.
039	Light Part 2 Setting	LightPt2	01–16	02	Determines the 2nd part (channel) which lights the keyboard when playing a MIDI Song contained on the computer with this instrument.
MIDI			-		
040	Local Control	Local	ON/OFF	ON	Determines whether the instrument's keyboard controls the inter- nal tone generator (ON) or not (OFF). When you are recording your keyboard performance to the application software on the computer via MIDI, set this parameter to OFF.
041	External Clock	ExtClock	ON/OFF	OFF	Determines whether the instrument synchronizes to the internal clock (OFF) or an external clock (ON). When you are recording your keyboard performance to the application software on the computer via MIDI, set this parameter to ON.
042	Initial Send	InitSend	YES/NO	-	Allows you to send the data of the panel settings to a computer. Press [+/YES] to send, or press [-/NO] to cancel.
Audio (p	pages 56, 57, 58)				1
043	[AUX IN] Audio Volume	AuxInVol	000–127	050	Determines the volume of audio playback, input from the [AUX IN] jack (page 56).
044	[USB TO HOST] Audio Volume	USBINVol	000–127	100	Determines the volume of audio playback, input from the [USB TO HOST] terminal (page 57).
045	Audio Loop Back	Loopback	ON/OFF	ON	Determines whether Audio sound input from the [USB TO HOST] terminal is returned to the computer or not with the performance played on the instrument. If you want to output only the sound played on this instrument to the computer, set this parameter to OFF.
046	Melody Suppressor	MelodySP	ON/OFF	OFF	When you output the audio sound of an external audio device or a computer connected to the [AUX IN] jack or the [USB TO HOST] terminal through this instrument, select 'ON' to cancel or lower the volume of the melody part of audio playback (page 58).
047	Suppressor Pan	SupprPan	L63-C-R63	С	Determines the position of the playback sound of the external audio device to be canceled or lowered (page 58).

Function Number	Function name	Display	Range/Settings	Default Value	Descriptions
Regist F	reeze (page 54)				
048	Style Freeze	StyleFrz	ON/OFF	OFF	When you want to call up the Registration Memory without over- writing the current Style setting, select "ON."
049	Transpose Freeze	TransFrz	ON/OFF	OFF	When you want to call up the Registration Memory without over- writing the current Transpose setting, select "ON."
050	Voice Freeze	VoiceFrz	ON/OFF	OFF	When you want to call up the Registration Memory without over- writing the current Voice setting, select "ON."
Duo (pa	ge 30)				
051	Duo Mode	DuoMode	ON/OFF	OFF	Turns the Duo mode (page 30) on/off.
052	Duo L Voice	DuoLUc	001-622	*	Determines the voice in the left section.
053	Duo Split Point	DuoPnt	036-096 (C1-C6)	066 (F#3)	Sets the key that divides the keyboard range into the left section and right section.
054	Duo R Volume	DuoRVo1	000-127	*	Determines the volume of the right section.
055	Duo L Volume	DuoLVo1	000-127	*	Determines the volume of the left section.
056	Duo R Octave	DuoROct	-3 - +3	*	Determines the pitch of the right section in octave units.
057	Duo L Octave	DuoLOct	-3 - +3	*	Determines the pitch of the left section in octave units.
058	Duo Type	DuoTчре	1 (Balance) 2 (Separate)	2 (Separate)	This function is effective in Duo Mode (page 30). Balance: The performance sounds of the left section and the right section will sound from both the left and right speakers. Separate: The performance sound of the left section will sound from the left speaker, and the performance sound of the right sec- tion will sound from the right speaker.
Storage					
059	Storage Mode	Storage	ON/OFF	OFF	When transferring Song or Style files between the instrument and the computer, set the Storage Mode to ON. While the Storage Mode is ON, you cannot play the instrument.
Style Fil	e				
060	Style Register	StyleReg	001–nnn	-	Select and register a Style file from flash files that are loaded from computer (page 50).
Demo (p	page 33)		I		
061	Demo Group	DemoGre	1 (Demo) 2 (Preset) 3 (User) 4 (Download)	1 (Demo)	Determines the repeat playback group.
062	Demo Play Mode	PlayMode	1 (Normal) 2 (Random)	1 (Normal)	Determines the repeat playback mode.
Auto Po	wer Off (page 15)		•		<u>'</u>
063	Auto Power Off Time	AutoOff	OFF, 5/10/15/30/60/ 120 (minutes)	30 minutes	Specifies the time that will elapse before the instrument's power is automatically turned off.
Battery	(page 14)		•		<u>'</u>
064	Battery Type	Battery	1 (Alkaline) 2 (Ni-MH)	1 (Alkaline)	Selects the type of batteries you have installed to this instrument. Alkaline: Alkaline battery/manganese battery Ni-MH: Rechargeable battery

<sup>\*</sup> The appropriate value is automatically set for each Voice combination.
\*\* The appropriate value is automatically set for each Song, Style or Arpeggio.

## **Troubleshooting**

Problem	Possible Cause and Solution
When the instrument is turned on or off, a popping sound is temporarily produced.	This is normal and indicates that the instrument is receiving electrical power.
When using a mobile phone, noise is produced.	Using a mobile phone in close proximity to the instrument may produce interference. To prevent this, turn off the mobile phone or use it further away from the instrument.
Noise is heard from the instrument's speakers or headphones when using the instrument with an application on a smart device.	When you use the instrument along with the application on your smart device, we recommend that you set "Airplane Mode" to "ON" on your smart device in order to avoid noise caused by communication.
There is no sound even when the keyboard is played or when a Song or Style is being played back.	Check that nothing is connected to the [PHONES/OUTPUT] jack on the rear panel. When a set of headphones is plugged into this jack, no sound is output.
	Check the Local Control on/off setting. (See page 62 Function 040.) Make sure Local Control is set to ON.
The instrument does not respond when the instrument is operated.	Is Storage Mode set to ON? Make sure Storage Mode is set to OFF; refer to "Storage" on page 63 (Function 059).
Playing keys in the right hand area of the keyboard does not produce any sound.	When using the Dictionary function (page 49), the keys in the right hand area are used only for entering the chord root and type.
Not all of the voices seem to sound, or the sound seems to be cut off.	The instrument is polyphonic up to a maximum of 48 notes—including Dual voice, Split Voice, Style, Song, and Metronome.  Notes exceeding this limit will not sound.
The harmony doesn't sound.	The method of sounding the Harmony effect (001–026) differs depending on the selected type. For Types 001–005, turn the Auto Accompaniment on and play it by pressing a chord in the auto accompaniment section of the keyboard, then play some keys in the right-hand side to produce the Harmony effect. You can play the types 006–026 without turning Auto Accompaniment on. However, it is necessary to play two notes simultaneously for Types 006–012.
The Style or Song does not play back when the [START/STOP] button is pressed.	Is External Clock set to ON? Make sure External Clock is set to OFF; refer to the function settings on page 62 (Function 041).
The ACMP ON indicator does not appear when the [ACMP ON/OFF] button is pressed.	Always press the [STYLE] button first when you are going to use any Style-related function.     The ACMP ON indicator does not appear when the Duo mode is on.
The Style does not sound properly.	Make sure that the Style Volume (page 61 Function 016) is set to an appropriate level.
	Is the Split Point set to an appropriate key for the chords you are playing? Set the Split Point to an appropriate key (page 60 Function 003). Is the "ACMP" indicator showing in the display? If it is not showing, press the [ACMP ON/OFF] button so that it does show.
The Style does not sound as you play a chord.	If the Fingering Type (Function 017; page 61) is set to Multi, the following conditions will occur.  • The auto accompaniment will sometimes not change when related chords are played in sequence (e.g., some minor chords followed by the minor seventh).  • Two-note fingerings will produce a chord based on the previously played chord.  • Playing two same root keys in the adjacent octaves produces accompaniment based only on the root.
The footswitch (for sustain) seems to produce the opposite effect. For example, pressing the footswitch cuts off the sound and releasing it sustains the sounds.	The polarity of the footswitch is reversed. Make sure that the footswitch plug is properly connected to the [SUSTAIN] jack before turning on the power.
The sound of the voice changes from note to note.	This is normal. The AWM tone generation method uses multiple recordings (samples) of an instrument across the range of the keyboard; thus, the actual sound of the voice may be slightly different from note to note.

Problem	Possible Cause and Solution
The volume is too soft. The sound quality is poor. The rhythm stops unexpectedly or will not play. The recorded data of the Song, etc. does not play correctly. The LCD display suddenly goes dark, and all panel settings are reset.	The batteries are low or dead. Replace all six batteries with completely new ones, or use the included AC adaptor.
Power suddenly and unexpectedly turns off.	This is normal and the Auto Power Off function may have been activated (page 15). If you need to disable the Auto Power Off function, select "Off" in the Function settings (Function 063; page 63).
When the instrument is turned on, power is turned off suddenly and unexpectedly.	The protection circuit has been activated due to over current. This may occur when an AC adaptor other than the one specified is used, or an AC adaptor is damaged. Use the specified adaptor (page 94) only. If it should appear to be malfunctioning, discontinue use immediately and have it inspected by qualified Yamaha service personnel.
The application on your smart device doesn't recognize the instrument.	Is Storage Mode set to ON? Make sure that Storage Mode is set to OFF; refer to the function settings on page 63 (Function 059).

## **Song Book Sample**

This score is provided with the part of the Song Book (free downloadable scores).

The Song Book contains not only the scores for all internal songs (excepting for a Demo Song and some Songs due to copyright issues) but also music terms and important points for your practice. To obtain this Song Book, access the Yamaha website and download it from the product web page.

Yamaha Global Site https://www.yamaha.com

## Für Elise

L. v. Beethoven

### Basic

Song No.075							
Für Elise ~ With Step Map ~68							
Für Elise is an all-time classical favorite.							
The beautiful, well-known melody is repeated a number of times.							
In each step you won't be practicing alone. You have a wonderful orchestra to back you up!							
First, listen to the example a few times. It won't be long before you'll want to start playing it yours	elf!						
Step 01 Warm-up Exercise - "The Semitone Mystery"	70						
Step 02 Diligent Practice Time	71						
Step 03 Warm-up Exercise - "Basic Accompaniment"	72						
Step 04 Diligent Practice Time	72						
Step 05 First Half Review	73						
Step 06 Diligent Practice Time	73						
Step 07 Warm-up Exercise - "The Jump Competition"	74						
Step 08 "EEEEE!"	74						
Step 09 "Left! Right! Left! Right!"	75						
Step 10 Second Half Review	75						
Step 11 Play the Whole Song!	75						

<sup>\*</sup> The Song Book is provided in English, French, German and Spanish.

This example introduces part of the English Song Book.

## Before Playing...





♦ Finger Numbering






Sit near the middle of the keyboard.


## **Reading the Score**

The Keyboard, Staff Lines, and Clef





## ♦ Notes and Rests





4

4

### # (Sharp) (Flat) (Natural)

Accidentals

Raise a semitone Lower a semitone Return to normal pitch












### Song No.075

Basic

## Für Elise


 $\sim$  With Step Map  $\sim$ 


Play with both hands as if gently telling a story. It might help to sing or hum the melody as you play. Similar melody lines and rhythms are repeated in this song, so there aren't as many sections to practice as you might think. Enjoy learning each section as you build proficiency.





## Song No.075 III Für Elise Basic









## Song No.075 III Für Elise Basic






## Warm-up Exercise - "The Semitone Mystery"

Let's start with a warm-up exercise using three fingers of the right hand.

We'll start by ascending and descending the white and black keys. Check out the illustrations until you understand how the fingers are supposed to move, then get started!


You'll find it easier to play if you bend your fingers slightly.





Go back to the beginning and play it again.

Song No.075 III Für Elise Basic



## **Diligent Practice Time**

Right! Now that we're warmed up let's try playing along with the orchestra in 3/4 time.

The melody will be built up little by little.

Compare each line... notice that many of the shapes formed by the notes are very similar.



### Song No.075 Für Elise Basic

## Step 03




## Warm-up Exercise - "Basic Accompaniment"

And now a warm-up exercise for the left hand.

It's important to spread your fingers widely from the start.

Don't play the black keys too strongly.





## Step 04



## **Diligent Practice Time**

Connect the notes smoothly, as if the left hand were passing them to the right hand. You'll be able to play smoothly if you move the left hand into position for the next phrase as soon as it finishes playing the first phrase.



Song No.075 Für Elise Basic





#### **First Half Review**

You've reached the halfway step! Have you learned all the material provided in the preceding steps? Now let's go back and play through all the first-half exercises. If you find that you're having trouble playing any of the material, go back and review the steps using the Step Map as a guide.





#### **Diligent Practice Time**

OK, let's begin the second half!

You'll be able to play the melody nicely if you lift your fingers from the keyboard between the slurs.

It might be easier to grasp the key release timing if you sing along with the melody.


Don't panic and play too strongly where the left hand has to play short notes.



Always have left-hand finger 5 ready to play the next note!



#### Song No.075 III Für Elise Basic



#### "EEEEE!"

The only note in this step is E!

Make the connection between the left and right hands as smooth as possible.



Song No.075 Für Elise Basic






#### "Left! Right! Left! Right!"

Play "D# E" repeatedly, alternating the left and right hands.

Have the next hand ready in position to play D\$ so you won't have to rush.







#### **Second Half Review**

Try playing all the way through the second half.

As we did after the first half, if there are places you can't play with confidence go back and review the steps.





#### **Play the Whole Song!**

This is the finishing step!

Don't be afraid of making mistakes. Just concentrate on playing the entire song from start to finish.

Practice this with the lessons learned in each step in mind, and gradually you'll master the whole song.

## **Voice List**

#### **Maximum Polyphony**

The instrument has 48-note maximum polyphony. This means that it can play a maximum of up to 48 notes at once, regardless of what functions are used. Auto accompaniment uses a number of the available notes, so when auto accompaniment is used the total number of available notes for playing on the keyboard is correspondingly reduced. The same applies to the Split Voice and Song functions. If the maximum polyphony is exceeded, earlier played notes will be cut off and the most recent notes have priority (last note priority).

#### NOTE

- The Voice List includes MIDI program change numbers for each voice. Use these program change numbers when playing the instrument via MIDI from an external device.
- Program change numbers are often specified as numbers "0–127."
  For these cases, it is necessary to subtract 1 from the intended program change number to select the appropriate sound, because this list uses a "1–128" numbering system. For example, to select program change number 38 in the list below, transmit program change number 37
- Some voices may sound continuously or have a long decay after the notes have been released while the sustain pedal (footswitch) is

#### Panel Voice List

Panei v			MIDI	
Voice		Select	MIDI Program	Walaa Nama
No.	MSB (0-127)	LSB (0-127)	Change# (1-128)	Voice Name
			PIAN	
1	0	115	1	Live! Concert Grand Piano
2	0	112	1	Grand Piano
3	0	112	2	Bright Piano
4	0	112	7	Harpsichord
5	0	112	4	Honky Tonk Piano
6	0	112	3	MIDI Grand Piano
7	0	113	3	CP80
			E.PIAI	NO
8	0	118	5	Cool! SuitcaseEP
9	0	118	6	JazzChorusEP
10	0	120	5	PhaseEP
11	0	119	5	Cool! TremoloEP
12	0	121	5	Cool! ElectricPiano
13	0	117	5	StageEP
14	0	114	5	Cool! Galaxy Electric Piano
15	0	113	6	Hyper Tines
16	0	112	5	Funky Electric Piano
17	0	112	6	DX Modern Electric Piano
18	0	114	6	Venus Electric Piano
19	0	112	8	Clavi
20	0	113	8	WahClavi
			ORG/	ÂN
21	0	118	19	Cool! Organ
22	0	117	19	Cool! Rotor Organ
23	0	112	17	Jazz Organ 1
24	104	49	17	Jazz Organ 1+RotaryFast
25	0	113	17	Jazz Organ 2
26	104	50	17	Jazz Organ 2+RotaryFast
27	0	112	19	Rock Organ
28	0	120	19	Octave Shift Organ
29	0	114	19	Purple Organ
30	0	112	18	Click Organ
31	0	116	17	Bright Organ
32	0	127	19	Theater Organ
33	0	121	20	16'+2' Organ
34	0	120	20	16'+4' Organ
35	0	113	20	Chapel Organ
36	0	112	20	Pipe Organ
37	0	112	21	Reed Organ
			ACCOR	DION
38	0	112	22	Musette Accordion
39	0	113	22	Traditional Accordion
40	0	113	24	Bandoneon
41	0	113	23	Modern Harp
42	0	114	23	Blues Harp
43	0	115	23	Harmonica

	Bank	Select	MIDI	
Voice No.	MSB (0-127)	LSB (0-127)	Program Change# (1-128)	Voice Name
			GUITA	
44	8	96	1	S.Art Lite Nylon Guitar Harmonics ***
45	8	96	2	S.Art Lite Steel Guitar Harmonics ***
46	8	97	1	S.Art Lite Nylon Guitar Slide ***
47	8	97	2	S.Art Lite Steel Guitar Slide ***
48	8	96	6	S.Art Lite Distortion Guitar ***
49	0	116	25	Dynamic Nylon Guitar
50	0	118	30	Dynamic Overdriven
51	0	121	31	Dynamic Distortion Guitar
52	0	122	25	Nylon Guitar
53	0	112	25	Classical Guitar
54	104	25	26	Steel Guitar
55	0	112	26	Folk Guitar
56	0	112	27	Jazz Guitar
57	0	117	28	60s Clean Guitar
58	0	113	26	12Strings Guitar
59	0	112	28	Clean Guitar
60	0	127	28	Wah Guitar
61	0	113	27	Octave Guitar
62	0	112	29	Muted Guitar
63	0	112	30	Overdriven Guitar
64	0	112	31	Distortion Guitar
65	0	127	31	Wah Distortion Guitar
			BAS	
66	8	96	18	S.Art Lite Slap Bass ***
67	0	116	34	Dynamic Electric Bass
68	0	112	34	Finger Bass
69	0	112	33	Acoustic Bass
70	0	112	35	Pick Bass
71	0	112	36	Fretless Bass
72	0	112	37	Slap Bass
73	0	121	40	Funk Bass
74	0	112	39	Synth Bass
75	0	113	39	Hi-Q Bass
76	0	113	40	Dance Bass
		,	STRIN	
77	8	96	50	S.Art Lite Strings ***
78	0	117	50	Live! Strings
79	104	23	49	Studio Strings
80	0	112	49	Strings
81	0	112	50	Chamber Strings
82	0	115	50	Marcato Strings
83	0	113	50	Slow Strings
84	0	112	45	Tremolo Strings
85	0	112	51	Synth Strings

		0-1- :	M/P:	
Voice		Select	MIDI Program	Water Name
No.	MSB (0-127)	LSB (0-127)	Change# (1-128)	Voice Name
86	0	112	46	Pizzicato Strings
87	0	116	46	Orchestra Pizzicato Strings
88	0	113	41	Sweet! Violin
89	0	112	41	Violin
90	0	112	43	Cello
91	0	112	44	Contrabass
92	0	112	47	Harp
93	0	112	56	Orchestra Hit
50		112	CHO	
94	8	96	55	S.Art Lite Gospel Choir ***
95	0	112	53	Choir
96	104	12	54	Gospel Hmm
97	104	13	54	Gospel Wow
98	0	113	53	Vocal Ensemble
99	0	112	55	Air Choir
100	0	112	54	Vox Humana
100		112	SAXOPH	
101	8	96	83	S.Art Lite Tenor Sax ***
102	0	122	67	Sax Section
103	0	117	67	Sweet! Tenor Sax
103	0	112	67	Tenor Sax
104	0	112	66	Alto Sax
106	0	112	65	Soprano Sax
107	0	112	68	Baritone Sax
107	0	114	67	Breathy Tenor Sax
	0	116		
109	·		66	Small Sax Section
110	0	112	72	Clarinet
111	0	112	69 70	Oboe
112	0	112		English Horn
113	0	112	71	Bassoon
		440	TRUME	
114	0	112	57	Trumpet
115	0	127	57	Distortion Trumpet
116	0	112	58	Trombone
117	0	113	58	Trombone Section
118	0	112	60	Muted Trumpet
119	0	112	61	French Horn
120	0	112	59	Tuba
		r	BRAS	
121	8	96	57	S.Art Lite Brass Section ***
122	0	117	63	Live! Brass
123	0	112	62	Brass Section
124	0	113	62	Big Band Brass
125	0	116	62	Octave Brass
126	0	113	63	80s Brass
127	0	119	62	Mellow Horns
128	0	115	63	Funky Brass
129	0	114	63	Techno Brass
130	0	112	63	Synth Brass
			FLUT	
131	8	96	74	S.Art Lite Flute ***
132	0	114	74	Sweet! Flute
133	0	115	74	Sweet! Classical Flute
134	0	112	74	Flute
135	0	112	73	Piccolo
136	0	112	76	Pan Flute
137	0	112	75	Recorder
138	0	112	80	Ocarina
			SYNT	Н
139	104	20	91	Gemini
140	104	21	91	Hands Up!
141	0	112	81	Square Lead
				· ·

Voice	Bank	Select	MIDI	
No.	MSB (0-127)	LSB (0-127)	Program Change# (1-128)	Voice Name
142	0	112	82	Sawtooth Lead
143	0	108	82	RS Tech Saw
144	0	112	88	Under Heim
145	0	112	85	Portatone
146	0	115	82	Analogon 1
147	0	119	82	Fargo 1
148	104	53	82	Analogon 2
149	104	54	82	Fargo 2
150	0	112	86	Voice Lead
151	0	121	82	Funky Lead
152	0	118	89	Sweet Heaven
153	0	121	89	Dream Heaven
154	0	113	89	Symbiont
155	0	112	99	Stardust
156	0	112	101	Brightness
157	0	112	92	Xenon Pad
158	0	112	95	Equinox
159	0	112	89	Fantasia
160	0	113	90	Dark Moon
		_		
161	0	113	101	Bell Pad
162	0	126	90	RS Analog Pad
163	0	116	91	RS Short Resonance
			PERCUS	
164	0	112	12	Vibraphone
165	0	113	12	Jazz Vibes
166	0	112	13	Marimba
167	0	112	14	Xylophone
168	0	112	115	Steel Drums
169	0	112	9	Celesta
170	0	112	11	Music Box
171	0	112	15	Tubular Bells
172	0	112	48	Timpani
			WORI	
173	0	112	106	Banjo
174	0	0	111	Fiddle
175	0	0	110	
176	0	0	16	Bagpipe Dulaimas 1
				Dulcimer 1
177	0	35	16	Dulcimer 2
178	0	96	16	Cimbalom
179	0	121	16	Santur
180	0	97	108	Kanoon
181	0	98	106	Oud
182	0	96	106	Rabab
183	0	0	109	Kalimba
184	0	113	21	Harmonium 1 (Single Reed)
185	0	114	21	Harmonium 2 (Double Reed)
186	0	115	21	Harmonium 3 (Triple Reed)
187	0	114	105	Tanpura
188	0	96	112	Pungi
189	0	117	74	Bansuri
190	0	0	105	Sitar 1
191	0	32	105	
				Detuned Sitar
192	0	35	105	Sitar 2
193	0	0	112	Shehnai
194	0	97	106	Gopichant
195	0	116	117	Tabla
196	0	115	111	Er Hu
197	0	118	74	Di Zi
198	0	116	106	Pi Pa
100	0	113	108	Gu Zheng
199				
200	0	40	47	Yang Qin

	Bank	Select	MIDI	
Voice No.	MSB (0-127)	LSB (0–127)	Program Change# (1-128)	Voice Name
202	0	124	74	Suling
203	0	0	107	Shamisen
204	0	0	108	Koto
205	0	96	108	Taisho-kin
	1	l .	DUAI	*
206	-	-	-	Octave Piano
207	-	-	-	Piano & Strings
208	-	-	-	Piano Pad
209	-	-	-	Octave Harpsichord
210	-	-	-	Tiny Electric Piano
211	-	-	-	Electric Piano Pad
212	-	-	-	Full Organ
213	-	-	-	Octave Jazz Guitar
214	-	-	-	Octave Strings
215	-	-	-	Orchestra Section
216	-	-	-	Octave Pizzicato Strings
217	-	-	-	Strings Session
218	-	-	-	Brass Tutti
219	-	-	-	Orchestra Tutti
220	-	-	-	Octave French Horns
221	-	-	-	Octave Harp
222	-	-	-	Orchestra Hit & Timpani
223	-	-	-	Octave Choir
224	-	-	-	Jazz Brass Section
225	-	-	-	Jazz Section
226	-	-	-	Ballroom Sax Ensemble
227	-	-	-	Ballroom Brass
228	-	-	-	Flute & Clarinet
229	-	-	-	Trumpet & Trombone
230	_	_	_	Fat Synth Brass
231	_	_	_	Octave Lead
232	_	_	_	Super 5th Lead
	1	5	OUND E	
233	0	0	121	Fret Noise
234	0	0	122	Breath Noise
235	0	0	123	Seashore
236	0	0	124	Bird Tweet
237	0	0	125	Telephone Ring
238	0	0	126	Helicopter
239	0	0	127	Applause
240	0	113	116	Hand Clap
241	0	0	128	Gunshot
			DRUM	
242	127	0	88	Power Kit
243	127	0	1	Standard Kit 1
244	127	0	2	Standard Kit 2
245	127	0	9	Room Kit
246	127	0	17	Rock Kit
247	127	0	25	Electronic Kit
248	127	0	26	Analog Kit
249	127	0	113	Dance Kit
250	127	0	33	Jazz Kit
251	127	0	41	Brush Kit
252	127	0	49	Symphony Kit
253	126	0	128	StdKit 1 + Chinese Perc.
254	126	0	40	Indian Kit 1
255	126	0	115	Indian Kit 2
256	126	0	55	StdKit 1 + Indonesian Perc. 1
257	126	0	56	StdKit 1 + Indonesian Perc. 2
258	126	0	57	StdKit 1 + Indonesian Perc. 2
259	126	0	37	Arabic Kit
260	126	0	41	Cuban Kit
200	120		7.	Oubun Mt

	Bank	Select	MIDI	
Voice No.	MSB (0-127)	LSB (0-127)	Program Change# (1–128)	Voice Name
261	126	0	1	SFX Kit 1
262	126	0	2	SFX Kit 2
263	126	0	113	Sound Effect Kit
	•		ARPEGO	GIO**
264	-	-	-	Concerto
265	-	-	-	Latin Rock
266	-	-	-	Brass Section
267	-	-	-	Piano Ballad
268	-	-	-	Synth Sequence
269	-	-	-	Guitarist
270	-	-	-	Pickin'
271	-	-	-	Spanish
272	-	-	-	Funky Clavi
273	-	-	-	Harpeggio
274	-	-	-	Finger Bass Left
275	-	-	-	Combo Jazz Left
276	-	-	-	Paul's Bass Left
277	-	-	-	Trance Bass Left
278	-	-	-	Acid Bass Left
279	-	-	-	Piano Ballad Left
280	-	-	-	Salsa Piano Left
281	-	-	-	Piano Arpeggio Left
282	-	-	-	Guitar Arpeggio Left
283	-	-	-	Strum Left

- \* When you select a Voice of the DUAL category, two voices sound at the same time.
- \*\* Selecting a Voice number between 264 and 283 will turn on Arpeggio.
- \*\*\* S.Art Lite voice (page 27)

#### **XGlite Voice List**

	Bank	Select	MIDI		
Voice		1	Program	Voice Name	
No.	MSB (0-127)	LSB (0-127)	Change# (1-128)		
			XG PIA	NO	
284	0	0	1	Grand Piano	
285	0	1	1	Grand Piano KSP	
286	0	40	1	Piano Strings	
287	0	41	1	Dream	
288	0	0	2	Bright Piano	
289	0	1	2	Bright Piano KSP	
290	0	0	3	Electric Grand Piano	
291	0	1	3	Electric Grand Piano KSP	
292	0	32	3	Detuned CP80	
293	0	0	4	Honky Tonk Piano	
294	0	1	4	Honky Tonk Piano KSP	
295	0	0	5	Electric Piano 1	
296	0	1	5	Electric Piano 1 KSP	
297	0	32	5	Chorus Electric Piano 1	
298	0		6		
		0		Electric Piano 2	
299	0	1	6	Electric Piano 2 KSP	
300	0	32	6	Chorus Electric Piano 2	
301	0	41	6	DX + Analog Electric Piano	
302	0	0	7	Harpsichord 1	
303	0	1	7	Harpsichord KSP	
304	0	35	7	Harpsichord 2	
305	0	0	8	Clavi	
306	0	1	8	Clavi KSP	
		<b>)</b>	G CHRO	MATIC	
307	0	0	9	Celesta	
308	0	0	10	Glockenspiel	
309	0	0	11	Music Box 1	
310	0	64	11	Music Box 2	
311	0	0	12	Vibraphone	
312	0	1	12	Vibraphone KSP	
313	0	0	13	Marimba	
314	0	1	13	Marimba KSP	
315	0	64	13	Sine Marimba	
316	0	97	13	Balimba	
317	0	98	13	Log Drums	
318	0	0	14	Xylophone	
319	0	0	15	Tubular Bells	
320	0	96	15	Church Bells	
321	0	96	15	Carillon	
321	0	97	-		
	_		XG ORG		
322	0	0	17	Drawbar Organ 1	
323	0	32	17	Detuned Drawbar Organ	
324	0	33	17	60s Drawbar Organ 1	
325	0	34	17	60s Drawbar Organ 2	
326	0	35	17	70s Drawbar Organ 1	
327	0	37	17	60s Drawbar Organ 3	
328	0	40	17	16+2'2/3 Organ	
329	0	64	17	Organ Bass	
330	0	65	17	70s Drawbar Organ 2	
331	0	66	17	Cheezy Organ	
332	0	67	17	Drawbar Organ 2	
333	0	0	18	Percussive Organ 1	
334	0	24	18	70s Percussive Organ	
335	0	32	18	Detuned Percussive Organ	
336	0	33	18	Light Organ	
337	0	37	18	Percussive Organ 2	
338	0	0	19	Rock Organ	
339	0	64	19	Rotary Organ	
340	0	65	19	Slow Rotary Organ	
341	0	66	19	Fast Rotary Organ	

Voice	Bank	Select	MIDI	
Voice No.	MSB (0-127)	LSB (0-127)	Program Change# (1-128)	Voice Name
342	0	0	20	Church Organ 1
343	0	32	20	Church Organ 3
344	0	35	20	Church Organ 2
345	0	40	20	Notre Dame
346	0	64	20	Organ Flute
347	0	65	20	Tremolo Organ Flute
348	0	0	21	Reed Organ
349	0	40	21	Puff Organ
350	0	0	22	Accordion
351	0	0	23	Harmonica 1
352	0	32	23	Harmonica 2
353	0	0	24	Tango Accordion 1
354	0	64	24	Tango Accordion 2
			XG GUI	
355	0	0	25	Nylon Guitar 1
356	0	25	25	Nylon Guitar 3
357	0	43	25	Velocity Guitar Harmonics
358	0	96	25	Ukulele
359	0	0	26	Steel Guitar
360	0	35	26	12-string Guitar
361		40	26	Nylon & Steel Guitar
362	0	41	26	,
			0	Steel Guitar with Body Sound
363	0	96	26	Mandolin
364	0	0	27	Jazz Guitar
365	0	32	27	Jazz Amp
366	0	0	28	Clean Guitar
367	0	32	28	Chorus Guitar
368	0	0	29	Muted Guitar
369	0	40	29	Funk Guitar
370	0	41	29	Muted Steel Guitar
371	0	45	29	Jazz Man
372	0	0	30	Overdriven Guitar
373	0	43	30	Guitar Pinch
374	0	0	31	Distortion Guitar
375	0	40	31	Feedback Guitar 1
376	0	41	31	Feedback Guitar 2
377	0	0	32	Guitar Harmonics 1
378	0	65	32	Guitar Feedback
379	0	66	32	Guitar Harmonics 2
			XG BA	
380	0	0	33	Acoustic Bass
381	0	40	33	Jazz Rhythm
382	0	45	33	Velocity Crossfade Upright Bas
383	0	0	34	Finger Bass 1
384	0	18	34	Finger Bass Dark
385	0	40	34	Bass & Distorted Electric Guita
386	0	43	34	Finger Slap Bass
387	0	45	34	Finger Bass 2
388	0	65	34	Modulated Bass
			-	
389	0	0	35	Pick Bass
390	0	28	35	Muted Pick Bass
391	0	0	36	Fretless Bass 1
392	0	32	36	Fretless Bass 2
393	0	33	36	Fretless Bass 3
394	0	34	36	Fretless Bass 4
395	0	0	37	Slap Bass 1
396	0	32	37	Punch Thumb Bass
397	0	0	38	Slap Bass 2
398	0	43	38	Velocity Switch Slap
	-	0	39	Synth Bass 1
399	0	U	39	Syriui Dass I

	Bank Select		MIDI	
Voice No.	MSB (0-127)	LSB (0-127)	Program Change# (1-128)	Voice Name
401	0	0	40	Synth Bass 2
402	0	6	40	Mellow Synth Bass
403	0	12	40	Sequenced Bass
404	0	18	40	Click Synth Bass
405	0	19	40	Synth Bass 2 Dark
405	0	40	40	Modular Synth Bass
407	0	41	40	DX Bass
407			XG STRI	
408	0	0	41	Violin
409	0	8	41	Slow Violin
410	0	0	42	Viola
411	0	0	43	Cello
412	0	0	44	Contrabass
413	0	0	45	Tremolo Strings
414	0	8	45	Slow Tremolo Strings
415	0	40	45	Suspense Strings
416	0	0	45 46	Pizzicato Strings
416	0	0	46	Orchestral Harp
417	0	0	47	Timpani
410		-	KG ENSE	
419	0	0	49	
419	0	3	49	Strings 1 Stereo Strings
		-		-
421	0	8	49	Slow Strings
422	0	35	49	60s Strings
423	0	40	49	Orchestra 1
424	0	41	49	Orchestra 2
425	0	42	49	Tremolo Orchestra
426	0	45	49	Velocity Strings
427	0	0	50	Strings 2
428	0	3	50	Stereo Slow Strings
429	0	8	50	Legato Strings
430	0	40	50	Warm Strings
431	0	41	50	Kingdom
432	0	0	51	Synth Strings 1
433	0	64	51	Synth Strings 4
434	0	0	52	Synth Strings 2
435	0	0	53	Choir Aahs
436	0	3	53	Stereo Choir
437	0	32	53	Mellow Choir
438	0	40	53	Choir Strings
439	0	0	54	Voice Oohs
440	0	0	55	Synth Voice 1
441	0	40	55	Synth Voice 2
442	0	41	55	Choral
443	0	64	55	Analog Voice
444	0	0	56	Orchestra Hit 1
445	0	35	56	Orchestra Hit 2
446	0	64	56	Impact
			XG BR	
447	0	0	57	Trumpet
448	0	32	57	Warm Trumpet
449	0	0	58	Trombone 1
450	0	18	58	Trombone 2
451	0	0	59	Tuba
452	0	0	60	Muted Trumpet
453	0	0	61	French Horn 1
454	0	6	61	French Horn Solo
455	0	32	61	French Horn 2
456	0	37	61	Horn Orchestra
457	0	0	62	Brass Section
458	0	35	62	Trumpet & Trombone Section
458		55	02	Trumper & Hombone Section

Voice No.         MSB (0-127)         LSB (0-127)         MIDI Program (1-128)         Voice Name           460         0         20         63         Resonant Synth Brass           461         0         0         64         Synth Brass 2           462         0         18         64         Soft Brass           463         0         41         64         Choir Brass           XG REED           464         0         0         65         Soprano Sax           465         0         0         66         Sax Section           466         0         40         66         Sax Section           467         0         0         67         Tenor Sax           468         0         40         67         Breathy Tenor Sax           469         0         0         68         Baritone Sax           470         0         0         69         Obce           471         0         0         70         English Horn           472         0         0         71         Bassoon           473         0         0         72         Clarinet	
No.   MSB   C-127   C-127   C-128   C-1428   C-1427   C-1428   C-1	
460	
461	
Method	
XG REED   A64   O	
464	
465	
466	
467	
468	
469	
470         0         0         69         Oboe           471         0         0         70         English Horn           472         0         0         71         Bassoon           473         0         0         72         Clarinet           XG PIPE           474         0         0         73         Piccolo           475         0         0         74         Flute           476         0         0         75         Recorder           477         0         0         76         Pan Flute           478         0         0         77         Blown Bottle           479         0         0         79         Whistle           480         0         0         80         Ocarina           XG SYNTH LEAD           481         0         0         81         Square Lead 1           482         0         6         81         Square Lead 2           483         0         8         81         LM Square           484         0         18         81         Hollow           485         0         <	
472         0         0         71         Bassoon           473         0         0         72         Clarinet           XG PIPE           474         0         0         73         Piccolo           475         0         0         74         Flute           476         0         0         75         Recorder           477         0         0         76         Pan Flute           478         0         0         77         Blown Bottle           479         0         0         79         Whistle           480         0         80         Ocarina           XG SYNTH LEAD           481         0         0         81         Square Lead 1           482         0         6         81         Square Lead 2           483         0         8         81         LM Square           484         0         18         81         Hollow           485         0         64         81         Mellow           486         0         64         81         Mellow           487         0         65 <t< td=""><td></td></t<>	
473   0   0   72   Clarinet   XG PIPE	
XG PIPE   474	
474         0         0         73         Piccolo           475         0         0         74         Flute           476         0         0         75         Recorder           477         0         0         76         Pan Flute           478         0         0         77         Blown Bottle           479         0         0         79         Whistle           480         0         0         80         Ocarina           XG SYNTH LEAD           481         0         0         81         Square Lead 1           482         0         6         81         Square Lead 2           483         0         8         81         LM Square           484         0         18         81         Hollow           485         0         19         81         Shroud           486         0         64         81         Mellow           487         0         65         81         Solo Sine	
475         0         0         74         Flute           476         0         0         75         Recorder           477         0         0         76         Pan Flute           478         0         0         77         Blown Bottle           479         0         0         79         Whistle           480         0         0         80         Ocarina           XG SYNTH LEAD           481         0         0         81         Square Lead 1           482         0         6         81         Square Lead 2           483         0         8         81         LM Square           484         0         18         81         Hollow           485         0         19         81         Shroud           486         0         64         81         Mellow           487         0         65         81         Solo Sine	
476         0         0         75         Recorder           477         0         0         76         Pan Flute           478         0         0         77         Blown Bottle           479         0         0         79         Whistle           480         0         0         80         Ocarina           XG SYNTH LEAD           481         0         0         81         Square Lead 1           482         0         6         81         Square Lead 2           483         0         8         81         LM Square           484         0         18         81         Hollow           485         0         19         81         Shroud           486         0         64         81         Mellow           487         0         65         81         Solo Sine	
477         0         0         76         Pan Flute           478         0         0         77         Blown Bottle           479         0         0         79         Whistle           480         0         0         80         Ocarina           XG SYNTH LEAD           481         0         0         81         Square Lead 1           482         0         6         81         Square Lead 2           483         0         8         81         LM Square           484         0         18         81         Hollow           485         0         19         81         Shroud           486         0         64         81         Mellow           487         0         65         81         Solo Sine	
478         0         0         77         Blown Bottle           479         0         0         79         Whistle           480         0         0         80         Ocarina           XG SYNTH LEAD           481         0         0         81         Square Lead 1           482         0         6         81         Square Lead 2           483         0         8         81         LM Square           484         0         18         81         Hollow           485         0         19         81         Shroud           486         0         64         81         Mellow           487         0         65         81         Solo Sine	
479         0         0         79         Whistle           480         0         0         80         Ocarina           XG SYNTH LEAD           481         0         0         81         Square Lead 1           482         0         6         81         Square Lead 2           483         0         8         81         LM Square           484         0         18         81         Hollow           485         0         19         81         Shroud           486         0         64         81         Mellow           487         0         65         81         Solo Sine	
480         0         0         80         Ocarina           XG SYNTH LEAD           481         0         0         81         Square Lead 1           482         0         6         81         Square Lead 2           483         0         8         81         LM Square           484         0         18         81         Hollow           485         0         19         81         Shroud           486         0         64         81         Mellow           487         0         65         81         Solo Sine	
XG SYNTH LEAD	
481         0         0         81         Square Lead 1           482         0         6         81         Square Lead 2           483         0         8         81         LM Square           484         0         18         81         Hollow           485         0         19         81         Shroud           486         0         64         81         Mellow           487         0         65         81         Solo Sine	
483         0         8         81         LM Square           484         0         18         81         Hollow           485         0         19         81         Shroud           486         0         64         81         Mellow           487         0         65         81         Solo Sine	
484         0         18         81         Hollow           485         0         19         81         Shroud           486         0         64         81         Mellow           487         0         65         81         Solo Sine	
485         0         19         81         Shroud           486         0         64         81         Mellow           487         0         65         81         Solo Sine	
486 0 64 81 Mellow 487 0 65 81 Solo Sine	
487 0 65 81 Solo Sine	
488 0 66 81 Sine Lead	
489 0 0 82 Sawtooth Lead 1	
490 0 6 82 Sawtooth Lead 2	
491 0 8 82 Thick Sawtooth	
492 0 18 82 Dynamic Sawtooth	
493 0 19 82 Digital Sawtooth	
494 0 20 82 Big Lead	
495 0 24 82 Heavy Synth	
496 0 96 82 Sequenced Analog	
497 0 0 83 Calliope Lead	
498 0 65 83 Pure Lead	
499         0         0         84         Chiff Lead           500         0         0         85         Charang Lead	
500 0 0 65 Charang Lead  501 0 64 85 Distorted Lead	
502 0 0 86 Voice Lead	
503 0 0 87 Fifths Lead	
504 0 35 87 Big Five	
505 0 0 88 Bass & Lead	
506 0 16 88 Big & Low	
507 0 64 88 Fat & Perky	
508 0 65 88 Soft Whirl	
XG SYNTH PAD	
509 0 0 89 New Age Pad 510 0 64 89 Fantasy	
510 0 64 89 Fantasy 511 0 0 90 Warm Pad	
511 0 0 90 Warm Pad 512 0 0 91 Poly Synth Pad	
513 0 0 92 Choir Pad	
514 0 66 92 Itopia	
515 0 0 93 Bowed Pad	
516 0 0 94 Metallic Pad	
517 0 0 95 Halo Pad	

	Bank	Select	MIDI	
Voice	MSB	LSB	Program	Voice Name
No.	(0-127)	(0-127)	Change# (1-128)	
518	0	0	96	Sweep Pad
E 4 0			SYNTH E	
519 520	0	0 64	97 97	Rain Harmo Rain
521	0	65	97	African Wind
522	0	66	97	Carib
523	0	0	98	Sound Track
524	0	27	98	Prologue
525	0	0	99	Crystal
526	0	12	99	Synth Drum Comp
527	0	14	99	Popcorn
528	0	18	99	Tiny Bells
529 530	0	35 40	99 99	Round Glockenspiel
530	0	40	99	Glockenspiel Chimes Clear Bells
532	0	42	99	Chorus Bells
533	0	65	99	Soft Crystal
534	0	70	99	Air Bells
535	0	71	99	Bell Harp
536	0	72	99	Gamelimba
537	0	0	100	Atmosphere
538	0	18	100	Warm Atmosphere
539	0	19	100	Hollow Release
540	0	40	100	Nylon Electric Piano
541	0	64	100	Nylon Harp
542	0	65	100	Harp Vox
543	0	66	100	Atmosphere Pad
544 545	0	0	101 102	Brightness
545	0	64	102	Goblins Goblins Synth
547	0	65	102	Creeper
548	0	67	102	Ritual
549	0	68	102	To Heaven
550	0	70	102	Night
551	0	71	102	Glisten
552	0	96	102	Bell Choir
553	0	0	103	Echoes
554	0	65	103	Big Pan
555	0	0	104	Sci-Fi
FFO			XG WO	
556 557	0	97	78 105	Shakuhachi
557 558	0	97	105	Tamboura Banjo
559	0	28	106	Muted Banjo
555		_	G PERCL	
560	0	0	113	Tinkle Bell
561	0	96	113	Bonang
562	0	97	113	Altair
563	0	98	113	Gamelan Gongs
564	0	99	113	Stereo Gamelan Gongs
565	0	100	113	Rama Cymbal
566	0	0	114	Agogo
567	0	0	115	Steel Drums
568	0	97	115	Glass Percussion
569 570	0	98	115 116	Thai Bells Woodblock
570	0	0 96	116	
571	0	96	117	Castanets Taiko Drum
573	0	96	117	Gran Cassa
574	0	0	118	Melodic Tom 1
575	0	64	118	Melodic Tom 2
576	0	65	118	Real Tom

	Bank	Select	MIDI	
Voice No.	MSB (0-127)	LSB (0-127)	Program Change# (1-128)	Voice Name
577	0	66	118	Rock Tom
578	0	0	119	Synth Drum
579	0	64	119	Analog Tom
580	0	65	119	Electronic Percussion
581	0	0	120	Reverse Cymbal
		XG	SOUND I	FFECTS
582	64	0	1	Cutting Noise 1
583	64	0	2	Cutting Noise 2
584	64	0	4	String Slap
585	64	0	17	Flute Key Click
586	64	0	33	Shower
587	64	0	34	Thunder
588	64	0	35	Wind
589	64	0	36	Stream
590	64	0	37	Bubble
591	64	0	38	Feed
592	64	0	49	Dog
593	64	0	50	Horse
594	64	0	51	Bird Tweet 2
595	64	0	56	Maou
596	64	0	65	Phone Call
597	64	0	66	Door Squeak
598	64	0	67	Door Slam
599	64	0	68	Scratch Cut
600	64	0	69	Scratch Split
601	64	0	70	Wind Chime
602	64	0	71	Telephone Ring 2
603	64	0	81	Car Engine Ignition
604	64	0	82	Car Tires Squeal
605	64	0	83	Car Passing
606	64	0	84	Car Crash
607	64	0	85	Siren
608	64	0	86	Train
609	64	0	87	Jet Plane
610	64	0	88	Starship
611	64	0	89	Burst
612	64	0	90	Roller Coaster
613	64	0	91	Submarine
614	64	0	97	Laugh
615	64	0	98	Scream
616	64	0	99	Punch
617	64	0	100	Heartbeat
618	64	0	101	Footsteps
619	64	0	113	Machine Gun
620	64	0	114	Laser Gun
621	64	0	115	Explosion
622	64	0	116	Firework

## **Standard Kit 1 List**

• For drum kits other than Standard Kit 1, refer to "Drum Kit List" on the website (page 8).

The leavest 1			Voice No. 243	
The lowest key				Standard Kit 1
C1	С	1	сиск	Seq Click H
C#1	C#	1	W/T	Brush Tap
D1	D	1	Ø.	Brush Swirl
D#1	D#	1	S S	Brush Slap
E1	Е	1		Brush Tap Swirl
F1	F	1	<b>₽</b> R	Snare Roll
F#1	F#	1	Y	Castanet
G1	G	1	1	Snare Soft
G#1	G#	1		Sticks
A1	Α	1	121	Bass Drum Soft
A#1	A#	1		Open Rim Shot
B1	В	1	1/2	Bass Drum Hard
C2	С	2	1/23	Bass Drum
C#2	C#	2	<b>Z</b>	Side Stick
D2	D	2	2	Snare
D#2	D#	2		Hand Clap
E2	Е	2	<b>3</b> 3	Snare Tight
F2	F	2	EL	Floor Tom L
F#2	F#	2		Hi-Hat Closed
G2	G	2	H	Floor Tom H
G#2	G#	2		Hi-Hat Pedal
A2	Α	2	<b>₽</b> L	Low Tom
A#2	A#	2		Hi-Hat Open
B2	В	2	<b>₽</b> M	Mid Tom L
C3	С	3		Mid Tom H
C#3	C#	3	<del>*\</del> ?	Crash Cymbal 1
D3	D	3	₽н	High Tom
D#3	D#	3	<b>÷</b> ₹Î	Ride Cymbal 1
E3	Е	3		Chinese Cymbal

			Voice No. 243		
				Standard Kit 1	
F3	F	3	¥€R	Ride Cymbal Cup	
F#3	F#	3		Tambourine	
G3	G	3	\$	Splash Cymbal	
G#3	G#	3		Cowbell	
A3	Α	3	÷\2	Crash Cymbal 2	
A#3	A#	3	7	Vibraslap	
B3	В	3	R2	Ride Cymbal 2	
C4	С	4	T T	Bongo H	
C#4	C#	4	<b>₩</b> L	Bongo L	
D4	D	4		Conga H Mute	
D#4	D#	4	H	Conga H Open	
E4	Е	4	) <u>L</u>	Conga L	
F4	F	4	Ţ Ųij	Timbale H	
F#4	F#	4	Ųj Min	Timbale L	
G4	G	4	<b>A</b> H	Agogo H	
G#4	G#	4	<b></b> ₽L	Agogo L	
A4	Α	4		Cabasa	
A#4	A#	4	<b>S</b>	Maracas	
B4	В	4	H	Samba Whistle H	
C5	С	5	L	Samba Whistle L	
C#5	C#	5	<b></b> S s	Guiro Short	
D5	D	5	<b>₽</b> L	Guiro Long	
D#5	D#	5	1	Claves	
E5	Е	5	H	Wood Block H	
F5	F	5	₹\ E	Wood Block L	
F#5	F#	5	<b>™</b> M	Cuica Mute	
G5	G	5	<b>6</b>	Cuica Open	
G#5	G#	5	<b>4</b>	Triangle Mute	
A5	Α	5		Triangle Open	
—— A#5	A#	5	17.	Shaker	
B5	В	5		Jingle Bells	
C6	С	6		Bell Tree	

## **Song List**

Song No.	Song Name		
	Demo		
001	Demo (Yamaha Original)		
	POP		
002	Happy (Pharrell Williams)		
003	It's My Life (Jon Bon Jovi/Martin Sandberg/Richie Sambora)		
004	Viva La Vida (Guy Berryman/Jon Buckland/Will Champion/Chris Martin)		
005	Bad Romance (Stefani Germanotta/Nadir Khayat)		
006	Shape Of You (Ed Sheeran/Kevin Briggs/Kandi Burruss/ Tameka Cottle/Steve Mac/Johnny McDaid)		
007	Duele El Corazon (Enrique Iglesias/M. Hasibur Rahman/Francisco Sal- dana/Juan Luis Morera/Servando Moriche Primera Mus- sett/Patrick Ingunza/Silverio Ramon Lozada Schwarck)		
800	Titanium (David Guetta/Sia Furler/Giorgio Tuinfort/Nick Van De Wall)		
009	Perfect (Ed Sheeran)		
010	<b>Treasure</b> (Bruno Mars/Ari Levine/Philip Lawrence/Fredrick Brown/Thibaut Berland/Christopher Acito)		
011	Something Just Like This (Andrew Taggart/Chris Martin/Guy Berryman/Jonny Buckland/Will Champion)		
	FAVORITE		
012	Frère Jacques (Traditional)		
013	Der Froschgesang (Traditional)		
014	Aura Lee (Traditional)		
015	London Bridge (Traditional)		
016	Sur le pont d'Avignon (Traditional)		
017	Old MacDonald Had a Farm (Traditional)		
018	Nedelka (Traditional)		
019	Aloha Oe (Q. Liliuokalani)		
020	Sippin' Cider Through a Straw (Traditional)		
021	Old Folks at Home (S. C. Foster)		
022	Bury Me Not on the Lone Prairie (Traditional)		
023	Santa Lucia (A. Longo)		
024	If You're Happy and You Know It (Traditional)		
025	Beautiful Dreamer (S. C. Foster)		
026	Greensleeves (Traditional)		
027	Kalinka (Traditional)		
028	Holdilia Cook (Traditional)		
029	Ring de Banjo (S. C. Foster)		
030	La Cucaracha (Traditional)		
031	Funiculi Funicula (L. Denza)		
032	Largo (from the New World) (A. Dvořák)		
033	Brahms' Lullaby (J. Brahms)		
034	Liebesträume Nr.3 (F. Liszt)		
035	Pomp and Circumstance (E. Elgar)		
036	Chanson du Toreador (G. Bizet)		
037	Jupiter, the Bringer of Jollity (G. Holst)		

Song No.	Song Name
038	The Polovetsian Dances (A. Borodin)
039	Die Moldau (B. Smetana)
040	Salut d'Amour op.12 (E. Elgar)
041	Humoresques (A. Dvořák)
042	Symphony No.9 (from the New World - 4th movement) (A. Dvořák)
	INSTRUMENT MASTER
043	Sicilienne/Fauré (G. Fauré)
044	Swan Lake (P. I. Tchaikovsky)
045	Grand March (Aida) (G. Verdi)
046	Serenade for Strings in C major, op.48 (P. I. Tchaikovsky)
047	Pizzicato Polka (J. Strauss II)
048	Romance de Amor (Traditional)
049	Menuett BWV Anh.114 (J. S. Bach)
050	Ave Verum Corpus (W. A. Mozart)
051	Radetzky Marsch (J. Strauss I)
	PIANO REPERTOIRE
052	Wenn ich ein Vöglein wär (Traditional)
053	Die Lorelei (F. Silcher)
054	Home Sweet Home (H. R. Bishop)
055	Scarborough Fair (Traditional)
056	My Old Kentucky Home (Traditional)
057	Loch Lomond (Traditional)
058	Silent Night (F. Gruber)
059	Deck the Halls (Traditional)
060	O Christmas Tree (Traditional)
061	Sonata Pathétique 2nd Adagio Cantabile (L. v. Beethoven)
062	Ave Maria/J. S. Bach - Gounod (J. S. Bach/C. F. Gounod)
063	Jesus bleibet meine Freude (J. S. Bach)
064	Prelude op.28-15 "Raindrop" (F. Chopin)
065	Nocturne op.9-2 (F. Chopin)
066	Etude op.10-3 "Chanson de L'adieu" (F. Chopin)
067	Romanze (Serenade K.525) (W. A. Mozart)
068	Arabesque (J. F. Burgmüller)
069	La Chevaleresque (J. F. Burgmüller)
070	Für Elise (L. v. Beethoven)
071	Turkish March (W. A. Mozart)
072	24 Preludes op.28-7 (F. Chopin)
073	Annie Laurie (Traditional)
074	Jeanie with the Light Brown Hair (S. C. Foster)
	LEARN TO PLAY
075	Für Elise (Basic) (L. v. Beethoven)
076	Für Elise (Advanced) (L. v. Beethoven)
077	Twinkle Twinkle Little Star (Basic) (Traditional)

078 Twinkle Twinkle Little Star (Advanced) (Traditional)

Song No.	Song Name
079	Turkish March (Basic) (W. A. Mozart)
080	Turkish March (Advanced) (W. A. Mozart)
081	Ode to Joy (Basic) (L. v. Beethoven)
082	Ode to Joy (Advanced) (L. v. Beethoven)
083	The Entertainer (Basic) (S. Joplin)
084	The Entertainer (Advanced) (S. Joplin)
085	Londonderry Air (Basic) (Traditional)
086	Londonderry Air (Advanced) (Traditional)
087	The Last Rose of Summer (Basic) (Traditional)
088	The Last Rose of Summer (Advanced) (Traditional)
089	Amazing Grace (Basic) (Traditional)
090	Amazing Grace (Advanced) (Traditional)
	FAVORITE WITH STYLE
091	O du lieber Augustin (Traditional)
092	Mary Had a Little Lamb (Traditional)
093	When Irish Eyes Are Smiling (E. R. Ball)
094	Little Brown Jug (Traditional)
095	Ten Little Indians (Traditional)
096	On Top of Old Smoky (Traditional)
097	My Darling Clementine (P. Montrose)
098	Oh! Susanna (S. C. Foster)
099	Red River Valley (Traditional)
100	Turkey in the Straw (Traditional)
101	Muffin Man (R. A. King)
102	Pop Goes the Weasel (Traditional)
103	Grandfather's Clock (H. C. Work)
104	Camptown Races (S. C. Foster)
105	When the Saints Go Marching In (Traditional)
106	Yankee Doodle (Traditional)
107	Battle Hymn of the Republic (Traditional)
108	I've Been Working on the Railroad (Traditional)
109	American Patrol (F. W. Meacham)
110	Down by the Riverside (Traditional)
	JAPANESE SONG
111	Furusato (T. Okano)
112	Momiji (T. Okano)
113	Aogeba Totoshi (Traditional)
114	Haruga Kita (T. Okano)
115	Soushunfu (A. Nakada)
116	Akatonbo (K. Yamada)
	DUET
117	O Christmas Tree (Traditional)
118	We Wish You a Merry Christmas (Traditional)
119	Im Mai (Traditional)
120	Mary Had a Little Lamb (Traditional)
121	Yankee Doodle (Traditional)
122	Ten Little Indians (Traditional)

Song Name			
Scarborough Fair (Traditional)			
Three Blind Mice (Traditional)			
Battle Hymn of the Republic (Traditional)			
My Darling Clementine (P. Montrose)			
The Cuckoo (Traditional)			
London Bridge (Traditional)			
Close Your Hands, Open Your Hands (J. J. Rousseau)			
PIANO SOLO			
Valse op.64-1 "Petit Chien" (F. Chopin)			
Menuett/Beethoven (L. v. Beethoven)			
Andante grazioso (Sonate K.331) (W. A. Mozart)			
Melodie (Album für die Jugend) (R. Schumann)			
Fröhlicher Landmann (Album für die Jugend) (R. Schumann)			
Von fremden Ländern und Menschen (Kinderszenen) (R. Schumann)			
Thema (Impromptus D.935-3) (F. Schubert)			
Invention Nr.1 (J. S. Bach)			
Gavotte/J. S. Bach (J. S. Bach)			
Arietta/Grieg (E. Grieg)			
To a Wild Rose (E. A. MacDowell)			

Song No.	SPECIAL APPENDIX			
TOUCH TUTOR				
141-150	Touch Tutor 01-Touch Tutor 10			
	CHORD STUDY			
151-162	Chord Study 01-Chord Study 12			
	CHORD PROGRESSION			
163-202	Maj1234-min1736			

- Some Songs have been edited for length or for ease in learning, and may not be exactly the same as the original.
- A Song Book (free downloadable scores) is available that includes scores for internal Songs (excepting for a Demo Song and some Songs due to copyright issues). To obtain this Song Book, access the Yamaha website and download it from the product web page.

https://www.yamaha.com

## **Style List**

Style	
No.	Style Name
	8BEAT
1	BritPopRock
2	8BeatModern
3	Cool8Beat
4	Happy8Beat
5	Shake8Beat
6	BoyBandPop
7	SweetPop
8	ContemporaryRock
9	StadiumRock
10	70sRock
11	HardRock 1
12	60sGuitarPop
13	8BeatAdria
14	60s8Beat
15	8Beat
16	OffBeat
17	Folkrock
18	60sRock
19	HardRock 2
20	RockShuffle
21	8BeatRock
	16BEAT
22	16Beat
23	DancehallPop
24	CinematicPop
25	PopShuffle
26	GuitarPop
27	16BeatUptempo
28	KoolShuffle
29	HipHopLight
	BALLAD
30	70sGlamPiano
31	EpicDivaBallad
32	OrchestraRockBallad
33	PianoBallad
34	LoveSong
35	6/8ModernEP
36	6/8SlowRock
37	OrganBallad
38	PopBallad
39	16BeatBallad
	DANCE
40	ClubBeat
41	SkyPop
42	AgagBeat
43	Electronica
44	FunkyHouse
45	RetroClub
46	USHipHop
47	MellowHipHop
48	Chillout

Style No.	Style Name			
49	EuroTrance			
50	Ibiza			
51	SwingHouse			
52	Clubdance			
53	ClubLatin			
54	Garage 1			
55	Garage 2			
56	TechnoParty			
57	UKPop			
58	HipHopGroove			
59	HipShuffle			
60	HipHopPop			
	DISCO			
61	ModernDisco			
62	70sDisco			
63	LatinDisco			
64	SaturdayNight			
65	DiscoHands SWING&JAZZ			
00				
66 67	BigBandFast			
	BigBandBallad			
68	AcousticJazz AcidJazz			
69				
70 71	JazzClub			
71	Swing 1 Swing 2			
73	Five/Four			
73 74	Dixieland			
75	Ragtime			
75	R&B			
76 BluesRock				
77	UK Soul			
78	JustR&B			
79	WorshipAcoustic1			
80	WorshipAcoustic2			
81	WorshipRockBallad			
82	Soul			
83	DetroitPop			
84	60sRock&Roll			
85	6/8Soul			
86	CrocoTwist			
87	Rock&Roll			
88	ComboBoogie			
89	6/8Blues			
	COUNTRY			
90	CountryPop			
91	CountrySwing			
92	Country2/4			
93	Bluegrass			
	LATIN			
94	BrazilianSamba			
95	BrazilianBossa			

Style No.	Style Name
96	Bachata
97	CubanSon
98	Guajira
99	BossaNova
100	Forro
101	Sertanejo 1
102	Sertanejo 2
103	Baião
104	TangoArgentino
105	CumbiaPeruana
106	CumbiaColombiana
107	Vallenato
108	Joropo
109	Parranda
110	Merengue
111	ReggaetonPop
112	Reggaeton
113	Tijuana
114	PasoDuranguense
115	CumbiaGrupera
116	BaladaBanda
117	MexicanMambo
118	Mambo
119	Salsa
120	Beguine
121	Reggae
121	WORLD
122	Hawaiian
123	CelticDance
124	ScottishReel
125	4/4Standart
126	Rumba2/4
127	Saeidy
128	
129	WehdaSaghira IranianElec
130	Emarati
131	
	AfricanGospelReggae
132	HighLife1
133	AfricanGospel
134	Makossa
135	ModernAfrobeat
136	HighLife2
137	OrganHighLife
138	IgboHighLife
139	SocaCalypso
140	Azonto
141	IndianPop
142	Bhangra
143	Bhajan
144	BollyMix
145	Tamil
146	Kerala

Style No.	Style Name
147	GoanPop
148	Rajasthan
149	Dandiya
150	Qawwali
151	FolkHills
152	ModernDangdut1
153	Keroncong
154	ModernDangdut2
155	DangdutUmum
156	DangdutSlowLegend
157	Dangdut3/4
158	KoploRampak
159	LanggamModern
160	DangdutJawa
161	Congdut
162	VietnamesePopBallad
163	Vietnamese6/8Ballad
164	XiQingLuoGu
165 166	YiZuMinGe
100	JingJuJieZou  BALLROOM
107	
167	VienneseWaltz
168 169	EnglishWaltz Slowfox
170	Foxtrot
170	
171	Quickstep Tango
173	Pasodoble
173	Samba
175	ChaChaCha
176	Rumba
177	Jive
177	TRADITIONAL
178	US March
179	6/8March
180	GermanMarch
181	PolkaPop
182	OberkrainerPolka
183	Tarantella
184	Showtune
185	ChristmasSwing
186	ChristmasWaltz
	WALTZ
187	ItalianWaltz
188	SwingWaltz
189	JazzWaltz
190	ValsMexicano
191	CountryWaltz
192	OberkrainerWalzer
193	Musette
	CHILDREN
194	Learning2/4

Chida	
Style No.	Style Name
195	Learning4/4
196	Learning6/8
	PIANIST
197	Stride
198	PianoSwing
199	PianoBoogie
200	Arpeggio
201	Habanera
202	SlowRock
203	8BeatPianoBallad
204	6/8PianoMarch
205	PianoWaltz

## **Music Database List**

MDB No.	MDB Name	
MIDE NO.	ALL TIME HITS	
1	Jude Hey	
2	Jumping	
3	WrldRock	
4	All OK	
5	YourTune	
6	USA Surf	
7	JustCall	
8	Get Home	
9	GtrWheel	
10	IWasBorn	
11		
12	Sailing BluJeans	
13		
	Holiday	
14	Imagine	
15	Marriage WitoShdo	
16	WiteShde	
17	NowNever	
18	Hard Day	
19	USA Pie	
20	Norway	
21	YesterBd	
22	A Magic	
	POP & ROCK	
23	UR Shape	
24	Love Me	
25	Ideal	
26	SweetPop	
27	Just Way	
28	Speed	
29	Cheerful	
30	SwftShke	
31	Watches	
32	PrtTmLvr	
33	S Party	
34	MoonShdw	
35	NikitSng	
36	GirlsMne	
37	Radio	
38	Attempt	
39	OnAStrng	
40	WhatWant	
41	ThankFor	
42	Tmbourin	
43	RubyGirl	
44	TopWorld	
45	TeachSng	
46	Each Min	
47	' ShakenUp	
48	CrocRock	
49	HurryLov	
50	Champion	
51	Jailhous	

MDB No.	MDB Name		
52	Rock&RII		
53	HonkyTnk		
54	JustU&Me		
55	LveSmile		
56	Wish I		
	BALLAD		
57	StayWith		
58	DontMiss		
59	HiBallad		
60	Red Lady		
61	IvoryAnd		
62	TheWorld		
63	Paradise		
64	Whisper		
65	Woman		
66	CndleWnd		
67	Fly Away		
68	Love You		
69	SavingAl		
70	InTheDrk		
71	Say You		
72	Way Were		
73	Inspirng		
	OLDIES		
74	Diana's		
75	Tonight		
76	SandLter		
77	No Rain		
78	Ghetto		
79	PrettyWm		
80	Sherry		
81	Sally's		
	DANCE & DISCO		
82	SkyStars		
83	Bad Love		
84	PokerPop		
85	FevrNite		
86	StyAlive		
87	Westerly		
88	Run Free		
89	DISCO		
90	JoelLife		
91	Coupled		
92	SingBack		
93	Janeiro		
94	BoomRoom		
95	DontHide		
96	RewCraig		
97	LondonRU		
98	WerUBeen		
99	MkeMusic		
100	10,2 Sun		
101	Trust		

MDB No.	MDB Name
102	MarieClb
	SWING & JAZZ
103	Moon Of
104	Patrol
105	Rhythm
106	CatSwing
107	Misbehav
108	Safari
109	SoWhatIs
110	TimeGone
111	TasteHny
112	Two Foot
113	Blk&Whte
114	EnterRag
115	TakeFour
116	Birdland
117	MistyFln
	COUNTRY
118	OnTheRd
119	BlueSong
120	InMyMind
121	RoadHome
122	GreenGrs
123	EverNeed
124	Lucille
125	Tennesse
	LATIN
126	LoveAmor
127	Brasil
128	ChryPink
129	MyShadow
130	BosaWave
131	DntWorry
132	I'm Pola
133	Mambo Jm
134	One Note
135	PasoCani
136	Beguine
137	Tijuana
138	Puntuali
139	Cielito
140	The Liar
141	Unfrgivn
	ENTERTAINMENT Deindren
142	Raindrop
143	Califrag
144	CatMemry
145 146	MyPrince
	Showbiz
147	JinglBel SilentNt
148	SilentNt Christms
149	Omisulis

Favorite

150

MDB No.	MDB Name
151	RedRdolf
152	Moon WIz
153	AroundWd
	WALTZ & TRAD
154	DadClock
155	RockBaby
156	SomeLara
157	Doodah!
158	Dreamer
159	Birthday
160	Sunshine
161	Tex Rose
162	ThePolka
163	Yankee's
164	DanubeWz
165	D'amor
166	Reine de
167	MnchHaus
168	Comrades
169	Van Maas
170	ClariPka

## **Effect Type List**

#### **Harmony Types**

No.	Harmony Type		Description
001	Duet		
002	Trio	If you want to	sound one of the harmony types 01–05, play keys to the right side of the Split Point
003	Block		chords in the left side of the keyboard after turning Auto Accompaniment on. One, two
004	Country		of harmony are automatically added to the note you play. When playing back a Song chord data, harmony is applied whichever keys are played.
005	Octave		
006	Trill 1/4 note	J	
007	Trill 1/6 note	J <sub>3</sub> J	
008	Trill 1/8 note	♪	If you keep holding down two different notes, the notes alternate (in a trill)
009	Trill 1/12 note		continuously.
010	Trill 1/16 note	Ą	(The trill speed differs depending on the selected type.)
011	Trill 1/24 note	Ħ	
012	Trill 1/32 note	J	
013	Tremolo 1/4 note	ا	
014	Tremolo 1/6 note	JJ	
015	Tremolo 1/8 note	<b>)</b>	
016	Tremolo 1/12 note	Ĵ	If you keep holding down a note, the note is repeated continuously.  (The repeat speed differs depending on the selected type.)
017	Tremolo 1/16 note	A	(The repeat speed allies deportally of the solicited type.)
018	Tremolo 1/24 note	Ħ	
019	Tremolo 1/32 note	ß	
020	Echo 1/4 note	٦	
021	Echo 1/6 note	JJ	
022	Echo 1/8 note	♪	
023	Echo 1/12 note	77	If you play a note, echo is applied to the note played.  (The echo speed differs depending on the selected type.)
024	Echo 1/16 note	Ą	The same speed amond deponding on the selected type.
025	Echo 1/24 note	Ħ	
026	Echo 1/32 note	ß	

Arpeggio Ty	pes
Arpeggio No.	Arpeggio Name
027	UpOct
028	DownOct
029	UpDwnOct
030	SynArp1
031	SynArp2
032	SynArp3
033	SynArp4
034	SyncEcho
035	PulsLine
036	StepLine
037	Random
038	Down&Up
039	SuperArp
040	AcidLine
041	TekEcho
042	VelGruv
043	Planet
044	Trance1
045	Trance2
046	Trance3
047	ChordAlt
048	SynChrd1
048	SynChrd2
050	Syncopa
050	Hybrid1
052	Hybrid2
053	Hybrid3
054	Hybrid4
055	Hybrid5
056	PfArp1
057	PfArp2
058	PfArp3
059	PfArp4
060	PfClub1
060	PfClub2
062	PfBallad
063	PfChd8th
063	EPArp
065	PfShufle
066	PfRock
067	
	Clavi1
068	Clavi2
069 070	RocknPf
070	70RockPf
071	SlowflPf SoulPf
072	
073	ChordUp ChdDance
075 076	LatinRck Salsa1
076	
	Salsa2
078	Reggae1
079	Reggae2
080	Reggae3
081	6/8R&B
082	Gospel
083	BalladEP
084	Strum1
085	Strum2
086	Strum3
087	Strum4
088	Pickin1
089	Pickin2
090	Funky

Arpeggio No.         Arpeggio Name           091         GtrChrd1           092         GtrChrd2           093         GtrChrd3           094         GtrArp           095         FngrPck2           097         CleanGtr           098         Slowfl           099         Samba1           100         Samba2           101         Spanish1           102         Spanish2           103         Harp1           104         Harp2           105         FngrBas1           106         FngrBas2           107         FngrBas3           108         CoolFunk           109         SlapBass           110         AcidBas2           111         AcidBas2           112         FunkyBas           113         CmbJazB3           116         NewR&BBs           117         CmbJazB3           116         NewR&BBs           117         DreamBas           117         TranceBs           120         TranceBs           121         LatinBas           122         Strings3 <th></th> <th></th>		
092         GtrChrd2           093         GtrChrd3           094         GtrArp           095         FngrPck1           096         FngrPck2           097         CleanGtr           098         Slowfl           099         Samba1           100         Samba2           101         Spanish1           102         Spanish2           103         Harp1           104         Harp2           105         FngrBas1           106         FngrBas2           107         FngrBas3           108         CoolFunk           109         SlapBass           110         AcidBas1           111         AcidBas2           112         FnkyBas           113         CmbJazB1           114         CmbJazB3           115         CmbJazB3           116         NewR&BBs           117         HipHopBs           118         SmoothBs           119         DreamBas           120         TranceBs           121         LatinBas           122         Strings2	Arpeggio No.	Arpeggio Name
093         GtrChrd3           094         GtrArp           095         FngrPck1           096         FngrPck2           097         CleanGtr           098         Slowfl           099         Samba1           100         Samba2           101         Spanish1           102         Spanish2           103         Harp1           104         Harp2           105         FngrBas1           106         FngrBas2           107         FngrBas3           108         CoolFunk           109         SlapBass           110         AcidBas1           111         AcidBas2           112         FunkyBas           113         CmbJazB1           114         CmbJazB3           115         CmbJazB3           116         NewR&BBs           117         HipHopBs           118         SmoothBs           119         DreamBas           120         TranceBs           121         LatinBas           122         Strings1           123         Strings3		
094         GtrArp           095         FngrPck1           096         FngrPck2           097         CleanGtr           098         Slowfl           099         Samba1           100         Samba2           101         Spanish1           102         Spanish2           103         Harp1           104         Harp2           105         FngrBas1           106         FngrBas2           107         FngrBas3           108         CoolFunk           109         SlapBass           110         AcidBas1           111         AcidBas2           112         FunkyBas           113         CmbJazB1           114         CmbJazB3           115         CmbJazB3           116         NewR&BBs           117         HipHopBs           118         SmoothBs           119         DreamBas           120         TranceBs           121         LatinBas           122         Strings2           124         Strings2           125         Strings2		
095         FngrPck1           096         FngrPck2           097         CleanGtr           098         Slowfl           099         Samba1           100         Samba2           101         Spanish1           102         Spanish2           103         Harp1           104         Harp2           105         FngrBas1           106         FngrBas2           107         FngrBas3           108         CoolFunk           109         SlapBass           110         AcidBas1           111         AcidBas2           111         AcidBas2           112         FunkyBas           113         CmbJazB1           114         CmbJazB2           115         CmbJazB2           115         CmbJazB3           116         NewR&Bs           117         HipHopBs           118         SmoothBs           119         DreamBas           120         TranceBs           121         LatinBas           122         Strings2           124         Strings2		
096         FngrPck2           097         CleanGtr           098         Slowfl           099         Samba1           100         Samba2           101         Spanish1           102         Spanish2           103         Harp1           104         Harp2           105         FngrBas1           106         FngrBas2           107         FngrBas3           108         CoolFunk           109         SlapBass           100         AcidBas1           111         AcidBas2           112         FnnkyBas           113         CmbJazB1           114         CmbJazB3           115         CmbJazB3           116         NewR&Bs           117         HipHopBs           118         SmoothBs           119         DreamBas           120         TranceBs           121         LatinBas           122         Strings1           123         Strings2           124         Strings3           125         StringUp           126         StrmQUp		
097         CleanGtr           098         Slowfi           099         Samba1           100         Samba2           101         Spanish1           102         Spanish2           103         Harp1           104         Harp2           105         FngrBas1           106         FngrBas2           107         FngrBas3           108         CoolFunk           109         SlapBass           110         AcidBas1           111         AcidBas2           112         FunkyBas           113         CmbJazB1           114         CmbJazB3           115         CmbJazB3           116         NewR&BBs           117         HipHopBs           118         SmoothBs           119         DreamBas           120         TranceBs           121         LatinBas           122         Strings1           123         Strings2           124         Strings3           125         Strings4           126         StrogDwn           127         Strings4		
098         Slowfl           099         Samba1           100         Samba2           101         Spanish1           102         Spanish2           103         Harp1           104         Harp2           105         FngrBas1           106         FngrBas2           107         FngrBas3           108         CoolFunk           109         SlapBass           110         AcidBas1           111         AcidBas2           111         AcidBas2           112         FunkyBas           113         CmbJazB1           114         CmbJazB3           115         CmbJazB3           116         NewR&BBs           117         HipHopBs           118         SmoothBs           119         DreamBas           120         TranceBs           121         LatinBas           122         Strings2           124         Strings2           124         Strings2           125         Strings4           126         StrngUp           127         StrngUp		
099         Samba1           100         Samba2           101         Spanish1           102         Spanish2           103         Harp1           104         Harp2           105         FngrBas1           106         FngrBas2           107         FngrBas3           108         CoolFunk           109         SlapBass           110         AcidBas1           111         AcidBas2           111         AcidBas2           112         FunkyBas           113         CmbJazB1           114         CmbJazB2           115         CmbJazB3           116         NewR&Bs           117         HipHopBs           118         SmoothBs           119         DreamBas           120         TranceBs           121         LatinBas           122         Strings1           123         Strings2           124         Strings3           125         Strings4           126         StrngUp           128         OrcheStr           129         Jupiter		
100         Samba2           101         Spanish1           102         Spanish2           103         Harp1           104         Harp2           105         FngrBas1           106         FngrBas2           107         FngrBas3           108         CoolFunk           109         SlapBass           110         AcidBas1           111         AcidBas2           112         FunkyBas           113         CmbJazB1           114         CmbJazB3           115         CmbJazB3           116         NewR&BBs           117         HipHopBs           118         SmoothBs           119         DreamBas           119         DreamBas           120         TranceBs           121         LatinBas           122         Strings1           123         Strings3           125         Strings4           126         StrogDwn           127         StrngUp           128         OrcheStr           129         Jupiter           130         Pizz1		
101         Spanish1           102         Spanish2           103         Harp1           104         Harp2           105         FngrBas1           106         FngrBas2           107         FngrBas3           108         CoolFunk           109         SlapBass           110         AcidBas1           111         AcidBas2           112         FunkyBas           113         CmbJazB1           114         CmbJazB2           115         CmbJazB3           116         NewR&BBs           117         HipHopBs           118         SmoothBs           119         DreamBas           120         TranceBs           121         LatinBas           122         Strings1           123         Strings2           124         Strings3           125         Strings4           126         StrngDwn           127         StrngUp           128         OrcheStr           129         Jupiter           130         Pizz1           131         Pizz2		
102         Spanish2           103         Harp1           104         Harp2           105         FingrBas1           106         FingrBas2           107         FingrBas3           108         CoolFunk           109         SlapBass           110         AcidBas1           111         AcidBas2           112         FunkyBas           113         CmbJazB1           114         CmbJazB2           115         CmbJazB3           116         NewR&BBs           117         HipHopBs           118         SmoothBs           119         DreamBas           120         TranceBs           121         LatinBas           122         Strings1           123         Strings2           124         Strings2           125         Strings4           126         StrngDwn           127         StrngUp           128         OrcheStr           129         Jupiter           130         Pizz1           131         Pizz2           132         BrasSec1		
103 Harp1 104 Harp2 105 FngrBas1 106 FngrBas2 107 FngrBas3 108 CoolFunk 109 SlapBass 110 AcidBas1 111 AcidBas2 112 FunkyBas 113 CmbJazB1 114 CmbJazB2 115 CmbJazB3 116 NewR&Bs 117 HipHopBs 118 SmoothBs 119 DreamBas 120 TranceBs 121 LatinBas 122 Strings1 123 Strings2 124 Strings3 125 Strings4 126 StrngDwn 127 StrngUp 128 OrcheStr 129 Jupiter 130 Pizz1 131 Pizz2 132 BrasSec1 133 BrasSec2 134 BrasSec3 135 FunkBras 136 SoulReed 137 DiscoLd 137 DiscoLd 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 151 Smooth 151 Smooth 152 NewGospl 153 CmbJazz1 153 Smooth 155 NewGospl 155 NewGospl 155 NewGospl 155 NewGospl 155 CmbJazz1		
104         Harp2           105         FngrBas1           106         FngrBas2           107         FngrBas3           108         CoolFunk           109         SlapBass           110         AcidBas1           111         AcidBas2           112         FunkyBas           113         CmbJazB1           114         CmbJazB2           115         CmbJazB3           116         NewR&BBS           117         HipHopBs           118         SmoothBs           119         DreamBas           120         TranceBs           121         LatinBas           122         Strings1           123         Strings2           124         Strings3           125         Strings4           126         StrgDwn           127         StrgDyn           127         StrgDyn           127         StrgBUp           128         OrcheStr           129         Jupiter           130         Pizz1           131         Pizz2           132         BrasSec1		•
105 FngrBas1 106 FngrBas2 107 FngrBas3 108 CoolFunk 109 SlapBass 110 AcidBas1 111 AcidBas2 112 FunkyBas 113 CmbJazB1 114 CmbJazB2 115 CmbJazB3 116 NewR&BBs 117 HipHopBs 118 SmoothBs 119 DreamBas 120 TranceBs 121 LatinBas 120 Strings2 121 Strings2 122 Strings2 124 Strings3 125 Strings4 126 StrngDwn 127 StrngUp 128 OrcheStr 129 Jupiter 130 Pizz1 131 Pizz2 132 BrasSec1 133 BrasSec2 134 BrasSec3 135 FunkBras 136 SoulFleed 137 DiscoLd 138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc2 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 151 Smooth 151 Smooth 152 NewGospl 153 CmbJazz1		
106 FngrBas2 107 FngrBas3 108 CoolFunk 109 SlapBass 110 AcidBas1 111 AcidBas2 112 FunkyBas 113 CmbJazB1 114 CmbJazB1 115 CmbJazB3 116 NewR&BBS 117 HipHopBs 118 SmoothBs 119 DreamBas 120 TranceBs 121 LatinBas 122 Strings1 123 Strings2 124 Strings3 125 Strings4 126 StrrgDwn 127 StrngUp 128 OrcheStr 129 Jupiter 129 Jupiter 130 Pizz1 131 Pizz2 132 BrasSec1 133 BrasSec2 134 BrasSec3 135 FunkBras 136 SoulReed 137 DiscoLd 137 DiscoLd 138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Soul 150 ClscHip 151 Smooth 151 Smooth 152 NewGospl 153 CmbJazz1		
107 FngrBas3 108 CoolFunk 109 CoolFunk 109 SlapBass 110 AcidBas1 111 AcidBas2 1112 FunkyBas 113 CmbJazB1 114 CmbJazB1 115 CmbJazB1 116 NewR&BBs 117 HjPHopBs 118 SmoothBs 119 DreamBas 120 TranceBs 121 LatinBas 122 Strings1 123 Strings2 124 Strings3 125 Strings4 126 StrngDwn 127 StrngUp 128 OrcheStr 129 Jupiter 130 Pizz1 131 Pizz2 132 BrasSec1 133 BrasSec2 134 BrasSec3 135 FunkBras 136 SoulReed 137 DiscoLd 138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Soul 150 ClscHip 151 Smooth 151 Smooth 151 Smooth 151 Smooth 152 NewGospl 153 CmbJazz1 153 CmbJazz1 153 CmbJazz1 153 CmbJazz1 153 NewGospl 155 NewGospl 155 CmbJazz1		
108         CoolFunk           109         SlapBass           110         AcidBas1           111         AcidBas2           112         FunkyBas           113         CmbJazB1           114         CmbJazB2           115         CmbJazB3           116         NewR&BBs           117         HipHopBs           118         SmoothBs           119         DreamBas           120         TranceBs           121         LatinBas           122         Strings1           123         Strings2           124         Strings3           125         Strings4           126         StrgDwn           127         StrgDwn           127         StrgUp           128         OrcheStr           129         Jupiter           130         Pizz1           131         Pizz2           132         BrasSec1           133         BrasSec2           134         BrasSec3           135         FunkBras           136         SoulReed           137         DiscoLd		
109         SlapBass           110         AcidBas1           111         AcidBas1           111         AcidBas2           112         FunkyBas           113         CmbJazB1           114         CmbJazB3           115         CmbJazB3           116         NewR&BBs           117         HipHopBs           118         SmoothBs           119         DreamBas           120         TranceBs           121         LatinBas           122         Strings1           123         Strings2           124         Strings3           125         Strings4           126         StrngDwn           127         StrngUp           128         OrcheStr           129         Jupiter           130         Pizz1           131         Pizz2           132         BrasSec1           133         BrasSec2           134         BrasSec3           135         FunkBras           136         SoulReed           137         DiscoLd           138         SmoothPd <tr< td=""><td></td><td></td></tr<>		
110         AcidBas1           111         AcidBas2           112         FunkyBas           113         CmbJazB1           114         CmbJazB2           115         CmbJazB3           116         NewR&BBs           117         HipHopBs           118         SmoothBs           119         DreamBas           120         TranceBs           121         LatinBas           122         Strings1           123         Strings2           124         Strings3           125         Strings4           126         StrngDwn           127         StrngUp           128         OrcheStr           129         Jupiter           130         Pizz1           131         Pizz2           132         BrasSec1           133         BrasSec2           134         BrasSec3           135         FunkBras           136         SoulReed           137         DiscoLd           138         SmoothPd           139         PercArp           140         Ethnic		
111         AcidBas2           112         FunkyBas           113         CmbJazB1           114         CmbJazB2           115         CmbJazB3           116         NewR&BBS           117         HipHopBs           118         SmoothBs           119         DreamBas           120         TranceBs           121         LatinBas           122         Strings1           123         Strings2           124         Strings3           125         Strings4           126         StrngDwn           127         StrngUp           128         OrcheStr           129         Jupiter           130         Pizz1           131         Pizz2           132         BrasSec1           133         BrasSec2           134         BrasSec3           135         FunkBras           136         SoulReed           137         DiscoLd           138         SmoothPd           139         PercArp           140         Ethnic           141         Cresendo		
112         FunkyBas           113         CmbJazB1           114         CmbJazB2           115         CmbJazB3           116         NewR&BBs           117         HipHopBs           118         SmoothBs           119         DreamBas           120         TranceBs           121         LatinBas           122         Strings1           123         Strings2           124         Strings3           125         Strings4           126         StrngDwn           127         StrgDup           128         OrcheStr           129         Jupiter           130         Pizz1           131         Pizz2           132         BrasSec1           133         BrasSec2           134         BrasSec3           135         FunkBras           136         SoulReed           137         DiscoLd           138         SmoothPd           139         PercArp           140         Ethnic           141         Cresendo           142         DiscoCP		
113		
114 CmbJazB2 115 CmbJazB3 116 NewR&BBs 117 HipHopBs 118 SmoothBs 119 DreamBas 120 TranceBs 121 LatinBas 122 Strings1 123 Strings2 124 Strings3 125 Strings4 126 StrngDwn 127 StrngUp 128 OrcheStr 129 Jupiter 130 Pizz1 131 Pizz2 132 BrasSec1 133 BrasSec2 134 BrasSec3 135 FunkBras 136 SoulReed 137 DiscoLd 138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 151 Smooth 151 Smooth 152 NewGospl 153 CmbJazz1		
115 CmbJazB3 116 NewR&BBs 117 HipHopBs 118 SmoothBs 119 DreamBas 120 TranceBs 121 LatinBas 122 Strings1 123 Strings2 124 Strings3 125 Strings4 126 StrngDwn 127 StrngUp 128 OrcheStr 129 Jupiter 130 Pizz1 131 Pizz2 132 BrasSec1 133 BrasSec2 134 BrasSec3 135 FunkBras 136 SoulReed 137 DiscoLd 138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Soul 150 ClscHip 151 Smooth 151 Smooth 152 NewGospl 153 CmbJazz1		
116         NewR&BBS           117         HipHopBs           118         SmoothBs           119         DreamBas           120         TranceBs           121         LatinBas           122         Strings1           123         Strings2           124         Strings3           125         Strings4           126         StrngDwn           127         StrngUp           128         OrcheStr           129         Jupiter           130         Pizz1           131         Pizz2           132         BrasSec1           133         BrasSec2           134         BrasSec3           135         FunkBras           136         SoulFleed           137         DiscoLd           138         SmoothPd           139         PercArp           140         Ethnic           141         Cresendo           142         DiscoCP           143         Perc1           144         Perc2           145         R&B           146         Funk1           147		
117         HipHopBs           118         SmoothBs           119         DreamBas           120         TranceBs           121         LatinBas           122         Strings1           123         Strings2           124         Strings2           125         Strings4           126         StrngDwn           127         StrngUp           128         OrcheStr           129         Jupiter           130         Pizz1           131         Pizz2           132         BrasSec1           133         BrasSec2           134         BrasSec3           135         FunkBras           136         SoulReed           137         DiscoLd           138         SmoothPd           139         PercArp           140         Ethnic           141         Cresendo           142         DiscoCP           143         Perc1           144         Perc2           145         R&B           146         Funk1           147         Funk2           148 <td></td> <td></td>		
118         SmoothBs           119         DreamBas           120         TranceBs           121         LatinBas           122         Strings1           123         Strings2           124         Strings3           125         Strings4           126         StrngDwn           127         StrngUp           128         OrcheStr           129         Jupiter           130         Pizz1           131         Pizz2           132         BrasSec1           133         BrasSec2           134         BrasSec3           135         FunkBras           136         SoulReed           137         DiscoLd           138         SmoothPd           139         PercArp           140         Ethnic           141         Cresendo           142         DiscoCP           143         Perc1           144         Perc2           145         R&B           146         Funk1           147         Funk2           148         Funk3           149		
119         DreamBas           120         TranceBs           121         LatinBas           122         Strings1           123         Strings2           124         Strings4           125         Strings4           126         StrngDwn           127         StrngUp           128         OrcheStr           129         Jupiter           130         Pizz1           131         Pizz2           132         BrasSec1           133         BrasSec2           134         BrasSec3           135         FunkBras           136         SoulReed           137         DiscoLd           138         SmoothPd           139         PercArp           140         Ethnic           141         Cresendo           142         DiscoCP           143         Perc1           144         Perc2           145         R&B           146         Funk1           147         Funk2           148         Funk3           149         Soul           150		
120 TranceBs 121 LatinBas 122 Strings1 123 Strings2 124 Strings3 125 Strings4 126 Strings4 127 Strings4 128 OrcheStr 129 Jupiter 130 Pizz1 131 Pizz2 132 BrasSec1 133 BrasSec2 134 BrasSec3 135 FunkBras 136 SoulReed 137 DiscoLd 138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc2 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 151 NewGospl 153 NewGospl 153 CmbJazz1		
121 LatinBas 122 Strings1 123 Strings2 124 Strings3 125 Strings4 126 Stringbup 127 StringUp 128 OrcheStr 129 Jupiter 130 Pizz1 131 Pizz2 132 BrasSec1 133 BrasSec2 134 BrasSec3 135 FunkBras 136 SoulReed 137 Discold 138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 151 Smooth 152 NewGospl 153 CmbJazz1		
122         Strings1           123         Strings2           124         Strings3           125         Strings4           126         StrngDwn           127         StrngUp           128         OrcheStr           129         Jupiter           130         Pizz1           131         Pizz2           132         BrasSec1           133         BrasSec2           134         BrasSec3           135         FunkBras           136         SoulReed           137         DiscoLd           138         SmoothPd           139         PercArp           140         Ethnic           141         Cresendo           142         DiscoCP           143         Perc1           144         Perc2           145         R&B           146         Funk1           147         Funk2           148         Funk3           149         Soul           150         ClscHip           151         Smooth           152         NewGospl           153		
123 Strings2 124 Strings3 125 Strings4 126 Strings4 127 StringUp 128 OrcheStr 129 Jupiter 130 Pizz1 131 Pizz2 132 BrasSec1 133 BrasSec2 134 BrasSec3 135 FunkBras 136 SoulReed 137 DiscoLd 138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
124 Strings3 125 Strings4 126 StringDwn 127 StrngDwn 128 OrcheStr 129 Jupiter 130 Pizz1 131 Pizz2 132 BrasSec1 133 BrasSec2 134 BrasSec3 135 FunkBras 136 SoulReed 137 DiscoLd 138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 151 Smooth		
125 Strings4 126 StrongDwn 127 StrngUp 128 OrcheStr 129 Jupiter 130 Pizz1 131 Pizz2 132 BrasSec1 133 BrasSec2 134 BrasSec3 135 FunkBras 136 SoulReed 137 DiscoLd 138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 151 Smooth 152 NewGospl 153 CmbJazz1		
126 StrngDwn 127 StrngUp 128 OrcheStr 129 Jupiter 130 Pizz1 131 Pizz2 132 BrasSec1 133 BrasSec2 134 BrasSec3 135 FunkBras 136 SoulReed 137 DiscoLd 138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 FunkI 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
127 StrngUp 128 OrcheStr 129 Jupiter 130 Pizz1 131 Pizz2 132 BrasSec1 133 BrasSec2 134 BrasSec3 135 FunkBras 136 SoulReed 137 DiscoLd 138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
128 OrcheStr 129 Jupiter 130 Pizz1 131 Pizz2 132 BrasSec1 133 BrasSec2 134 BrasSec3 135 FunkBras 136 SoulReed 137 DiscoLd 138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
129 Jupiter 130 Pizz1 131 Pizz2 132 BrasSec1 133 BrasSec2 134 BrasSec3 135 FunkBras 136 SoulReed 137 DiscoLd 138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 CiscHip 151 NewGospl 153 NewGospl 153 CmbJazz1		
130 Pizz1 131 Pizz2 132 BrasSec1 133 BrasSec2 134 BrasSec3 135 FunkBras 136 SoulReed 137 DiscoLd 138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
131 Pizz2 132 BrasSec1 133 BrasSec2 134 BrasSec3 135 FunkBras 136 SoulFleed 137 DiscoLd 138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
132 BrasSec1 133 BrasSec2 134 BrasSec2 135 FunkBras 136 SoulReed 137 DiscoLd 138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
133 BrasSec2 134 BrasSec3 135 FunkBras 136 SoulReed 137 DiscoLd 138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 CiscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
134 BrasSec3 135 FunkBras 136 SoulReed 137 DiscoLd 138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
135 FunkBras 136 SoulReed 137 DiscoLd 138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
136 SoulReed 137 DiscoLd 138 SmothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 CiscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
137 DiscoLd  138 SmoothPd  139 PercArp  140 Ethnic  141 Cresendo  142 DiscoCP  143 Perc1  144 Perc2  145 R&B  146 Funk1  147 Funk2  148 Funk3  149 Soul  150 CiscHip  151 NewGospl  153 CmbJazz1		
138 SmoothPd 139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
139 PercArp 140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
140 Ethnic 141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 CiscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
141 Cresendo 142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 CiscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
142 DiscoCP 143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
143 Perc1 144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
144 Perc2 145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
145 R&B 146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
146 Funk1 147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
147 Funk2 148 Funk3 149 Soul 150 ClscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
148 Funk3 149 Soul 150 ClscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
149 Soul 150 ClscHip 151 Smooth 152 NewGospl 153 CmbJazz1		
150         ClscHip           151         Smooth           152         NewGospl           153         CmbJazz1		
151 Smooth 152 NewGospl 153 CmbJazz1		
152 NewGospl 153 CmbJazz1		
153 CmbJazz1		
154 CmbJazz2		
	154	CmbJazz2

Arpeggio No.	Arpeggio Name
155	Bebop
156	JazzHop
157	FolkRock
158	Unpluggd
159	НірНор
160	Trance
161	Dream
162	2 Step
163	ClubHs1
164	ClubHs2
165	EuroTek
166	House
167	Ibiza1
168	Ibiza2
169	Ibiza3
170	Garage
171	Samba
172	African
173	Latin
174	China
175	Indian
176	Arabic

- When playing one of the Arpeggio Types 143 to 176, select the corresponding Voice below as the Main Voice.
  - 143-173: Select a Drum Kit (Voice No.242-252).
  - 174 (China): Select "StdKit1 + Chinese Perc." (Voice No.253).
  - 175 (Indian): Select "Indian Kit 1" (Voice No.254) or "Indian Kit 2" (Voice No.255).
  - 176 (Arabic): Select "Arabic Kit" (Voice No.259).

#### **Reverb Types**

No.	Reverb Type	Description
01-04	Hall 1-4	Concert hall reverb.
05	Cathedral	Rich reverb simulating the acoustics of a cathedral. Good for pipe organ sounds.
06-08	Room 1–3	Small room reverb.
09–10	Stage 1-2	Reverb for solo instruments.
11-12	Plate 1-2	Simulated steel plate reverb.
13	Off	No effect.

#### **Chorus Types**

No.	Chorus Type	Description
1–3	Chorus 1–3	Conventional chorus program with rich, warm chorusing.
4–5	Flanger 1–2	This produces a rich, animated wavering effect in the sound.
6	Off	No effect.

- Some Styles/Songs may have types that are not listed above.
   The Reverb/Chorus Type is reset when you select another Style/Song.

#### **DSP Types**

No.	DSP Type	Description
01	Dual Rotary Speaker Bright Slow	
02	Dual Rotary Speaker Bright Fast	Cimulatea a vetam anaglar
03	Rotary Speaker Slow	Simulates a rotary speaker.
04	Rotary Speaker Fast	
05	Small Stereo Distortion	Stereo distortion for guitar. Setting for distortion sound.
06	Small Stereo Overdrive	Stereo distortion for guitar. Setting for overdrive sound.
07	Small Stereo Vintage Amp	Stereo distortion for guitar. Setting for vintage sound.
80	British Combo Classic	British combo amp simulator. Setting for classic sound.
09	British Combo Top Boost	British combo amp simulator. Setting for "TOP BOOST" sound.
10	British Combo Heavy	British combo amp simulator. Setting for heavy sound.
11	British Legend Blues	British stack amp simulator. Setting for blues sound.
12	British Legend Heavy	British stack amp simulator. Setting for heavy sound.
13	British Legend Clean	British stack amp simulator. Setting for clean sound.
14	Stereo Amp Sim Crunch	Stores amp simulator
15	Stereo Amp Sim Blues	Stereo amp simulator.
16	Chorus 1	
17	Chorus 3	Conventional chorus program with rich, warm chorusing.
18	Chorus 4	Conventional chords program with fich, warm chordsing.
19	Chorus 5	
20	Celeste 2	A 3-phase LFO adds modulation and spaciousness to the sound.
21	Symphonic	Adds more stages to the modulation of Celeste.
22	Flanger1	Creates a sound similar to that of a jet airplane.
23	Vintage Phaser Stereo	This simulates an analog phaser, giving a strong vintage flavor to the sound. It is effective in stereo.
24	Phaser	Cyclically modulates the phase to add modulation to the sound.
25	E-Piano Phaser	Cyclically modulates the phase to add modulation to the sound. For electric piano.
26	Auto Wah	Cyclically modulates the center frequency of a wah filter.
27	Auto Wah + Distortion	Distortion can be applied to the output of Auto Wah.
28	Clavi Touch Wah	Clavinet Touch Wah
29	Tremolo	
30	E-Piano Tremolo	Rich Tremolo effect with both volume and pitch modulation.
31	Guitar Tremolo	
32	Ensemble Detune	Chorus effect without modulation, created by adding a slightly pitch-shifted sound.

No.	DSP Type	Description
33	Tempo Auto Pan	Tempo-synchronized auto pan.
34	Echo	Two delayed sounds (L and R), and independent feedback delays for L and R.
35	Cross Delay	The feedback of the two delayed sounds is crossed.
36	Compressor Medium	Compressor with medium setting.
37	3Band EQ	A mono EQ with adjustable LOW, MID, and HIGH equalization.
38	Harmonic Enhancer	Adds new harmonics to the input signal to make the sound stand out.

## **Specifications**

			EZ-300
Product Name			Digital Keyboard
Size/Weight	Dimensions (W x I	O x H)	945 mm x 369 mm x 118 mm (37-3/16" x 14-1/2" x 4-5/8")
Size/ Weight	Weight		4.8 kg (10 lb 9 oz) (not including batteries)
		Number of Keys	61
	Keyboard	Touch Response	Soft, Medium, Hard, Fixed
		Light Guide	Yes
Control Interface	Display	Туре	LCD
		Backlight	Yes
		Language	English
	Panel	Language Tone Generation	English
	Tone Generation	Technology	AWM Stereo Sampling
Voices	Polyphony (max.)		48
Voices	Preset	Number of Voices	622 (241 Panel Voices + 22 Drum/SFX kits + 20 Arpeggio + 339 XGlite Voices)
	Compatibility		GM/XGlite
		DSP	38 types
	Types	Reverb	12 types
	Types	Chorus	5 types
		Master EQ	6 types
		Dual	Yes
Effects		Split	Yes
1	E eti e e	Sustain	Yes
	Functions	Harmony	26 types 150 types
		Arpeggio Melody Suppressor	Yes
		Articulation	Yes (11 Super Articulation Lite Voices)
		Number of Styles	205
	D	Fingering	Smart Chord, Multi finger
	Preset	Style Control	ACMP ON/OFF, SYNC START, START/STOP, INTRO/ENDING/rit., MAIN/AUTO FILL
	External Styles		10
Otyles	Other Features	Music Database	170
		One Touch Setting (OTS)	Yes
	Compatibility		Style File Format (SFF)
	Preset	Number of Preset Songs	202 (including Touch Tutor: 10, Chord Study: 12, Chord Progression: 40)
	Recording	Number of Songs	5
Songs (MIDI)		Number of Tracks	2
		Data Capacity	Approx. 10,000 notes
	Format	Playback	SMF Formats 0 & 1
	Lesson	Recording	Original File Format  Keys to Success, Lesson 1–3 (Listening, Timing, Waiting), Phrase Repeat, A-B Repeat, Chord Dictionary, Touch Tutor, Chord Study, Chord Progression
Control Interface  Voices  Effects  Accompaniment Styles  Songs (MIDI)  Functions  Storage and Connectivity  Sound System	USB Audio (USB 7	TO HOST)	44.1 kHz, 16 bit, stereo
	Registration Memory	Number of Buttons	9
Functions	Overall Controls	Metronome	Yes
		Tempo Range	11–280
		Transpose	-12 to 0, 0 to +12
		Tuning	427.0-440.0-453.0 Hz (approx. 0.2 Hz increments)
	Minnellanan	Duo DIANO Dittor	Yes
	Miscellaneous	PIANO Button	Yes ([PORTABLE GRAND] Button)
	Storage	Internal Memory DC IN	Approx. 1.4 MB 12 V
	Connectivity	Headphones/Output	Standard stereo phone jack (PHONES/OUTPUT)
		Sustain	Sustain, Articulation, Arpeggio
		AUX IN	Yes (Stereo mini jack)
		USB TO HOST	Yes
0	Amplifiers	1	2.5 W + 2.5 W
Sound System	Speakers		12 cm x 2

Power Supply	Power Supply	AC Adaptor	Users within U.S or Europe: PA-130 or an equivalent recommended by Yamaha Others: PA-3C,PA-130 or an equivalent recommended by Yamaha
		Batteries	Six 1.5 V "AA" size alkaline (LR6), manganese (R6) or six 1.2 V "AA" size Ni-MH rechargeable batteries (HR6)
	Power Consumpti	on	5 W (When using PA-130 AC adaptor)
	Auto Power Off		Yes (Time can be set)
Included Accessories			Owner's Manual  Music Rest  AC adaptor * (PA-130 or an equivalent recommended by Yamaha)  Online Member Product Registration  May not be included depending on your particular area. Please check with your Yamaha dealer.
Separately Sold Accessories (May not be available depending on your area.)		our area.)	AC adaptor: Users within U.S. or Europe: PA-130 or an equivalent recommended by Yamaha Others: PA-3C, PA-130 or an equivalent recommended by Yamaha Keyboard stand: L-2C Headphones: HPH-50/HPH-100/HPH-150 Fortswitch: FCdA/FC/5

<sup>\*</sup> The contents of this manual apply to the latest specifications as of the publishing date. To obtain the latest manual, access the Yamaha website then download the manual file. Since specifications, equipment or separately sold accessories may not be the same in every locale, please check with your Yamaha dealer.

## Index

A
A-B Repeat
B         Backup       .59         Backup Clear       .59         Battery       .14         Battery Type       .15, 63         Beat       .17         BGM       .33
Chord       17, 47         Chord Dictionary       49         Chord Progressions       43         Chord Study       42         Chorus       27         Chorus Type       61, 91         Clear (User Song)       52         Computer       19, 57         Computer-related Operations       8         Copyright       97
D         DEMO       33         Display       17         Drum Kit List       .8         DSP       .26         DSP Type       .61, 91         Dual       .25         Dual Voice       .25, 61         Duo       .30         Duo Split Point       .30, 63
Effect

F         Fast Forward       33         Fast Reverse       36         Fingering Type       44         Flash Clear       56         Footswitch       16, 25         Freeze       56         Function List       66         Functions       23, 60	3 4 9 4 0
<b>G</b> GM System Level 1  Guide	
Harmony	9
Initial Send	9
Key → Transpose	7
Layer	5 6 9
M         MAIN       46         Master EQ       55         Master EQ types       55         Master Volume       16         Measure       17         Melody Suppressor       56         Metronome       23, 22         Metronome Volume       24, 62         MIDI Basics       68         MIDI Reference       44         Multi Finger       44         Music Database       50         Music Database List       85         Music Rest       16	5 5 6 7 8 4 2 8 8 4 0 7

One Touch Setting	24
_	
P	
Part	34
Passing Status	37
Pause	33
Pedal16,	
Phrase Repeat 20,	
Pitch → Transpose	60
Pitch → Tuning	60
PORTABLE GRAND18,	
Power	.14
_	
R	
Random Playback	33
Recording22,	51
Registration Memory	53
Reverb	27
Reverb Type 61,	91
Rhythm	45
rit. (ritardando)	46
_	
8	
Sections	46
Smart Chord 44,	48
Smart Chord Key	44
Smart Device	58
Smart Device Connection	
Manual	8
Song18,	31
Song Book 8,	36
Song Book Sample	
Song Category	31
Song List	83
Song Melody Voice	33
Song Volume 32,	
Specifications	
Split	
Split Point25,	45
Split Voice 25,	
Standard Kit 1 List	
Storage Mode19,	
Style18, 21,	
Style File	
Style List	
Style Volume45,	
Sustain16,	
Synchro Start	45
-	
Ī	
Tap function	
Tempo 24	32

Time Signature	.20, 39 26 41 .51, 52 60
USB Audio Interface USB TO HOST User Song	57
Voice	76 61 61 60 .24, 62
<b>W</b> Waiting20,	39, 43
YGlito.	۵

#### Credits and Copyrights for the preset Songs

#### **Bad Romance**

Words and Music by Stefani Germanotta and Nadir Khayat

Copyright (c) 2009 Sony/ATV Music Publishing LLC and House Of Gaga Publishing Inc.

All Rights Administered by Sony/ATV Music Publishing LLC, 424 Church Street, Suite 1200, Nashville, TN 37219 International Copyright Secured All Rights Reserved

#### Duele El Corazon

Words and Music by Enrique Iglesias, M. Hasibur Rahman, Francisco Saldana, Juan Luis Morera, Servando Moriche Primera Mussett, Patrick Ingunza and Silverio Ramon Lozada Schwarck

Copyright (c) 2016 Kobalt Music Copyrights SARL, Xuanlu Music Inc., EMI Blackwood Music Inc., Blue Kraft Music Publishing, Sony/ATV Music Publishing LLC, Yele Publishing, Sony/ATV Bailar, Warner-Tamerlane Publishing Corp., Patrick Ingunza Music, WB Music Corp. and Azul Siete Music

All Rights for Kobalt Music Copyrights SARL and Xuanlu Music Inc. Administered Worldwide by Kobalt Music Group Ltd.

All Rights for EMI Blackwood Music Inc., Blue Kraft Music Publishing, Sony/ATV Music

Publishing LLC, Yele Publishing and Sony/ATV Bailar Administered by Sony/ATV Music

Publishing LLC, 424 Church Street, Suite 1200, Nashville, TN 37219

All Rights for Patrick Ingunza Music Administered by Warner-Tamerlane Publishing Corp.

All Rights for Azul Siete Music Administered by WB Music Corp.

All Rights Reserved Used by Permission

#### Happy

from DESPICABLE ME 2

Words and Music by Pharrell Williams

Copyright (c) 2013 EMI April Music Inc., More Water From Nazareth and Universal Pictures Global Music

All Rights on behalf of EMI April Music Inc. and More Water From Nazareth Administered by Sony/ATV Music Publishing LLC, 424 Church Street, Suite 1200, Nashville, TN 37219

All Rights on behalf of Universal Pictures Global Music Controlled and Administered by Universal Music Works International Copyright Secured All Rights Reserved

#### It's My Life

Words and Music by Jon Bon Jovi, Martin Sandberg and Richie Sambora

Copyright (c) 2000 Universal Music Publishing International Ltd., Bon Jovi Publishing, GV-MXM, Sony/ATV Music Publishing LLC and Aggressive Music

All Rights for Universal Music Publishing International Ltd. and Bon Jovi Publishing Administered by Universal Music Works

All Rights for GV-MXM Administered Worldwide by Kobalt Songs Music Publishing

All Rights for Sony/ATV Music Publishing LLC and Aggressive Music Administered by Sony/ATV Music Publishing LLC, 424 Church Street, Suite 1200, Nashville, TN 37219

All Rights Reserved Used by Permission

#### Perfect

Words and Music by Ed Sheeran

Copyright (c) 2017 Sony/ATV Music Publishing (UK) Limited

All Rights Administered by Sony/ATV Music Publishing LLC, 424 Church Street, Suite 1200, Nashville, TN 37219 International Copyright Secured All Rights Reserved

#### Shape Of You

Words and Music by Ed Sheeran, Kevin Briggs, Kandi Burruss, Tameka Cottle, Steve Mac and Johnny McDaid

Copyright (c) 2017 Sony/ATV Music Publishing (UK) Limited, EMI April Music Inc., Air Control Music, Kandacy Music, Tiny Tam Music, Shek'em Down Music, Pepper Drive Music, Tony Mercedes Music, Rokstone Music and Spirit B-Unique Polar Patrol

All Rights on behalf of Sony/ATV Music Publishing (UK) Limited, EMI April Music Inc., Air Control Music, Kandacy Music and Tiny Tam Music Administered by Sony/ATV Music Publishing LLC, 424 Church Street, Suite 1200, Nashville, TN 37219

All Rights on behalf of Shek'em Down Music Administered by Songs Of Windswept Pacific and Hitco Music

All Rights on behalf of Songs Of Windswept Pacific and Hitco Music Administered by BMG Rights Management (US) LLC

All Rights on behalf of Pepper Drive Music Administered by Warner-Tamerlane Publishing Corp.

All Rights on behalf of Tony Mercedes Music Administered by WB Music Corp.

All Rights on behalf of Rokstone Music in the United States and Canada Administered by Universal - PolyGram International Publishing Inc.

All Rights on behalf of Spirit B-Unique Polar Patrol Controlled and Administered by Spirit B-Unique Polar Patrol Songs International Copyright Secured All Rights Reserved

 - contains samples of "No Scrubs" by Kevin Briggs, Kandi Burruss and Tameka Cottle (c) 1999 EMI April Music Inc., Air Control Music, Kandacy Music, Tiny Tam Music, Shek'em Down Music, Pepper Drive Music and Tony Mercedes Music

#### Something Just Like This

Words and Music by Andrew Taggart, Chris Martin, Guy Berryman, Jonny Buckland and Will Champion

Copyright (c) 2017 Sony/ATV Music Publishing LLC, EMI April Music Inc., Nice Hair Publishing and Universal Music Publishing MGB Ltd.

All Rights on behalf of Sony/ATV Music Publishing LLC, EMI April Music Inc. and Nice Hair Publishing Administered by Sony/ATV Music Publishing LLC, 424 Church Street, Suite 1200, Nashville, TN 37219

All Rights on behalf of Universal Music Publishing MGB Ltd. Administered in the United States and Canada by Universal Music - MGB Songs

International Copyright Secured All Rights Reserved

#### Titanium

Words and Music by David Guetta, Sia Furler, Giorgio Tuinfort and Nick Van De Wall

Copyright (c) 2011 What A Publishing Ltd., KMR Music Royalties II SCSp, EMI Music Publishing Ltd., Sony/ATV Music Publishing LtC and Afrojack Publishing

All Rights for What A Publishing Ltd. and KMR Music Royalties II SCSp Administered Worldwide by Kobalt Songs Music Publishing All Rights for EMI Music Publishing Ltd. and Sony/ATV Music Publishing LLC. Administered by Sony/ATV Music Publishing LLC, 424 Church Street, Suite 1200, Nashville, TN 37219

All Rights for Afrojack Publishing Administered by BMG Rights Management (US) LLC All Rights Reserved Used by Permission

#### Treasure

Words and Music by Bruno Mars, Ari Levine, Philip Lawrence, Fredrick Brown, Thibaut Berland and Christopher Acito

(c) 2012 BMG GOLD SONGS, MARS FORCE MUSIC, UNIVERSAL MUSIC CORP., TOY PLANE MUSIC, NORTHSIDE INDE-PENDENT MUSIC PUBLISHING LLC, WB MUSIC CORP., ROC NATION MUSIC, MUSIC FAMAMANEM and SONGS MUSIC PUBLISHING, LLC 0/b/0 BECAUSE EDITIONS LTD.

All Rights for BMG GOLD SONGS and MARS FORCE MUSIC Administered by BMG RIGHTS MANAGEMENT (US) LLC

All Rights for TOY PLANE MUSIC Controlled and Administered by UNIVERSAL MUSIC CORP.

All Rights for ROC NATION MUSIC and MUSIC FAMAMANEM Administered by WB MUSIC CORP.

All Rights Reserved Used by Permission

#### Viva La Vida

Words and Music by Guy Berryman, Jon Buckland, Will Champion and Chris Martin Copyright (c) 2008 by Universal Music Publishing MGB Ltd.
All Rights in the United States and Canada Administered by Universal Music - MGB Songs International Copyright Secured All Rights Reserved

#### Information for users on collection and disposal of old equipment and used batteries:



These symbols on the products, packaging, and/or accompanying documents mean that used electrical and electronic products and batteries should not be mixed with general household waste.

For proper treatment, recovery and recycling of old products and used batteries, please take them to applicable collection points, in accordance with your national legislation.



By disposing of these products and batteries correctly, you will help to save valuable resources and prevent any potential negative effects on human health and the environment which could otherwise arise from inappropriate waste handling.

For more information about collection and recycling of old products and batteries, please contact your local municipality, your waste disposal service or the point of sale where you purchased the items.

#### For business users in the European Union:

If you wish to discard electrical and electronic equipment, please contact your dealer or supplier for further information.



Information on Disposal in other Countries outside the European Union:

These symbols are only valid in the European Union. If you wish to discard these items, please contact your local authorities or dealer and ask for the correct method of disposal.

#### Note for the battery symbol (bottom two symbol examples):

This symbol might be used in combination with a chemical symbol. In this case it complies with the requirement set by the EU Battery Directive for the chemical involved.

(weee battery eu en 02)

#### Memo



## LIMITED 1-YEAR WARRANTY ON PORTABLE KEYBOARDS (NP, PSRE, PSREW, PSRF, PSRI, PSS, SHS, EZ, DGX230, DGX530, YPG AND YPT SERIES)

Thank you for selecting a Yamaha product. Yamaha products are designed and manufactured to provide a high level of defect-free performance. Yamaha Corporation of America ("Yamaha") is proud of the experience and craftsmanship that goes into each and every Yamaha product. Yamaha sells its products through a network of reputable, specially authorized dealers and is pleased to offer you, the Original Owner, the following Limited Warranty, which applies only to products that have been (1) directly purchased from Yamaha's authorized dealers in the fifty states of the USA and District of Columbia (the "Warranted Area") and (2) used exclusively in the Warranted Area. Yamaha suggests that you read the Limited Warranty thoroughly and invites you to contact your authorized Yamaha dealer or Yamaha Customer Service if you have any questions.

Coverage: Yamaha will, at its option, repair or replace the product covered by this warranty if it becomes defective, malfunctions or otherwise fails to conform with this warranty under normal use and service during the term of this warranty, without charge for labor or materials. Repairs may be performed using new or refurbished parts that meet or exceed Yamaha specifications for new parts. If Yamaha elects to replace the product, the replacement may be a reconditioned unit. You will be responsible for any installation or removal charges and for any initial shipping charges if the product(s) must be shipped for warranty service. However, Yamaha will pay the return shipping charges to any destination within the USA if the repairs are covered by the warranty. This warranty does not cover (a) damage, deterioration or malfunction resulting from accident, negligence, misuse, abuse, improper installation or operation or failure to follow instructions according to the Owner's Manual for this product; any shipment of the product (claims must be presented to the carrier); repair or attempted repair by anyone other than Yamaha or an authorized Yamaha Service Center; (b) any unit which has been altered or on which the serial number has been defaced, modified or removed; (c) normal wear and any periodic maintenance; (d) deterioration due to perspiration, corrosive atmosphere or other external causes such as extremes in temperature or humidity; (e) damages attributable to power line surge or related electrical abnormalities, lightning damage or acts of God; or (f) RFI/EMI (Interference/noise) caused by improper grounding or the improper use of either certified or uncertified equipment, if applicable. Any evidence of alteration, erasing or forgery of proof-of-purchase documents will cause this warranty to be void. This warranty covers only the Original Owner and is not transferable.

In Order to Obtain Warranty Service: Warranty service will only be provided for defective products within the Warranted Area. Contact your local authorized Yamaha dealer who will advise you of the procedures to be followed. If this is not successful, contact Yamaha at the address, telephone number or website shown below. Yamaha may request that you send the defective product to a local authorized Yamaha Servicer or authorize return of the defective product to Yamaha for repair. If you are uncertain as to whether a dealer has been authorized by Yamaha, please contact Yamaha's Service Department at the number shown below, or check Yamaha's website at www.Yamaha.com. Product(s) shipped for service should be packed securely and must be accompanied by a detailed explanation of the problem(s) requiring service, together with the original or a machine reproduction of the bill of sale or other dated, proof-of-purchase document describing the product, as evidence of warranty coverage. Should any product submitted for warranty service be found ineligible therefore, an estimate of repair cost will be furnished and the repair will be accomplished only if requested by you and upon receipt of payment or acceptable arrangement for payment.

Limitation of Implied Warranties and Exclusion of Damages: ANY IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE SHALL BE LIMITED IN DURATION TO THE APPLICABLE PERIOD OF TIME SET FORTH ABOVE. YAMAHA SHALL NOT BE RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OR FOR DAMAGES BASED UPON INCONVENIENCE, LOSS OF USE, DAMAGE TO ANY OTHER EQUIPMENT OR OTHER ITEMS AT THE SITE OF USE OR INTERRUPTION OF PERFORMANCES OR ANY CONSEQUENCES. YAMAHA'S LIABILITY FOR ANY DEFECTIVE PRODUCT IS LIMITED TO REPAIR OR REPLACEMENT OF THE PRODUCT, AT YAMAHA'S OPTION. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state. This is the only express warranty applicable to the product specified herein; Yamaha neither assumes nor authorizes anyone to assume for it any other express warranty.

If you have any questions about service received or if you need assistance in locating an authorized Yamaha Servicer, please contact:



CUSTOMER SERVICE Yamaha Corporation of America 6600 Orangethorpe Avenue, Buena Park, California 90620-1373 Telephone: 800-854-1569 www.yamaha.com

Do not return any product to the above address without a written Return Authorization issued by YAMAHA.

# for customers in European Economic Area Important Notice: Guarantee Information **EEA**) and Switzerland

rāmān Yamaha-tuotteen sekā ETA-alueen ja Sveitsin takuuta koskevat yksityiskohtaiset tiedot saatte alla olevasta nettiosoit-

Tärkeä ilmoitus: Takuutiedot Euroopan talousalueen (ETA)\* ja Sveitsin asiakkaille

teesta. (Tulostettava tiedosto saatavissa sivustollamme.) Voitte myös ottaa yhteyttä paikalliseen Yamaha-edustajaan.

For detailed guarantee information about this Yamaha product, and Pan-EEA\* and Switzerland warranty service, please either visit the website address below (Printable file is available at our website) or contact the Yamaha representative office for your Important Notice: Guarantee Information for customers in EEA\* and Switzerland country, \* EEA: European Economic Area

Wichtiger Hinweis: Garantie-Information für Kunden in der EWR\* und der Schweiz

Für nähere Garantie-Information über dieses Produkt von Yamaha, sowie über den Pan-EWR\*- und Schweizer Garantieservice, besuchen Sie bitte entweder die folgend angegebene Internetadresse (eine druckfähige Version befindet sich auch auf unserer Webseite), oder wenden Sie sich an den für Ihr Land zuständigen Yamaha-Vertrieb. \*EWR: Europäischer Wirtschaftsraum

Pour des informations plus détailées sur la garantie de ce produit Yamaha et sur le service de garantie applicable dans l'ensemble Remarque importante: informations de garantie pour les clients de l'EEE et la Suisse

de l'EEE ainsi qu'en Suisse, consultez notre site Web à l'adresse ci-dessous (le fichier imprimable est disponible sur notre site Web) ou contactez directement Yamaha dans votre pays de résidence. \* EEE : Espace Economique Européen Belangrijke mededeling: Garantie-informatie voor klanten in de EER\* en Zwitserland

Voor gedetailleerde garantie-informatie over dit Yamaha-product en de garantieservice in heel de EER\* en Zwitserland, gaat u naar de onderstaande website (u vind een afdrukbaar bestand op onze website) of neemt u contact op met de vertegenwoordiging van Yamaha in uw land. \* EER: Europese Economische Ruimte

Para una información detalada sobre este producto Yamaha y sobre el soporte de garantía en la zona EEE\* y Suiza, visite la dirección web que se incluye más abajo (la version del archivo para imprimir esta disponible en nuestro sitio web) o póngase en Españo contacto con el representante de Yamaha en su país. \* EEE: Espacio Económico Europeo Aviso importante: información sobre la garantía para los clientes del EEE\* y Suiza

Per informazioni dettagliate sulla garanzia refativa a questo prodotto Yamaha e l'assistenza in garanzia nei paesi EEA\* e in Svizzera, potete consultare il sito Web all'indirizzo riportato di seguito (è disponibile il file in formato stampabile) oppure contattare Avviso importante: informazioni sulla garanzia per i clienti residenti nell'EEA\* e in Svizzera l'ufficio di rappresentanza locale della Yamaha, \* EEA: Area Economica Europea

Aviso importante: informações sobre as garantias para clientes da AEE\* e da Suiça

Para obter uma informação pormenorizada sobre este produto da Yamaha e sobre o serviço de garantia na AEE\* e na Suíça, visite o site a seguir (o arquivo para impressão está disponível no nosso site) ou entre em contato com o escritório de representação da Yamaha no seu país. \* AEE: Área Econômica Européia

ΕΟΧ και την Ελβετία, επισκεφτείτε την παρακάτω ιστοσελίδα (Εκτυπώσιμη μορφή είναι διαθέσιμη στην ιστοσελίδα μας) ή Για λεπτομερείς πληροφορίες εγγύησης σχεπκά με το παρόν προϊόν της Yamaha και την κάλυψη εγγύησης σε όλες τις χώρες του απευθυνθείτε στην αντιπροσωπεία της Yamaha στη χώρα σας. \* ΕΟΧ: Ευρωπαϊκός Οικονομικός Χώρος

Σημαντική σημείωση: Πληροφορίες εγγύησης για τους πελάτες στον ΕΟΧ\* και Ελβετία

För detaljerad information om denna Yamahaprodukt samt garantisen/ce i hela EES-området\* och Schweiz kan du antingen besöka nedanslående webbaddress (en utskriftsvänlig fil finns på webbplatsen) eller kontakta Yamahas officiella representant i Viktigt: Garantiinformation för kunder i EES-området\* och Schweiz ditt land. \* EES: Europeiska Ekonomiska Samarbetsområdet

Detaljert garantiinformasjon om dette Yamaha-produktet og garantiservice for hele EØS-området\* og Sveits kan fås enten ved å besøke nettadressen nedenfor (utskriftsversjon finnes på våre nettsider) eller kontakte kontakte Yamaha-kontoret i landet der du Norsk Viktig merknad: Garantiinformasjon for kunder i EØS\* og Sveits

De kan finde detaljerede garantioplysninger om dette Yamaha-produkt og den fælles garantiserviceordning for EØO\* (og Schweiz) ved at besøge det websted, der er angivet nedenfor (der findes en fil, som kan udskrives, på vores websted), eller ved at kontakte Yamahas nationale repræsentationskontor i det land, hvor De bor, \* EØO: Det Europæiske Økonomiske Område Vigtig oplysning: Garantioplysninger til kunder i EØO\* og Schweiz bor \*EØS: Det europeiske økonomiske samarbeidsområdet

Szwajcarii, należy odwiedzić wskazaną poniżej stronę internetową (Plik gotowy do wydruku znajduje się na naszej stronie internetowej) Podrobné záruční informace o tomto produktu Yamaha a záručním servisu v celém EHS\* a ve Švýcarsku naleznete na níže uvedené webové adrese (soubor k tisku je dostupný na naších webových stránkách) nebo se můžete obrátit na zastoupení firmy A jelen Yamaha termékre vonatkozó részletes garancia-információk, valamint az EGT\*-re és Svájcra kiterjedő garanciális szolgáltatás tekintetében keresse fel webhelyűnket az alábbi címen (a webhelyen nyomtatható fájít is talál), vagy pedig lépjen Täpsema teabe saamiseks selle Yamaha toote garantii ning kogu Euroopa Majanduspiirkonna ja Šveitsi garantiiteeninduse kohta, külastage palun veebisaiti alljärgneval aadressil (meie saidil on saadaval prinditav fail) või pöörduge Teie regiooni Yamaha apmeklējiet zemāk norādīto tīmekļa vietnes adresi (tīmekļa vietnē ir pieejams drukājams fails) vai sazinieties ar jūsu valsti Jei reikia išsamios informacijos apie šį "Yamaha" produktą ir jo techninę priežiūrą visoje EEE" ir Šveicarijoje, apsilankykite mūsų Podrobné informácie o záruke týkajúce sa tohto produktu od spoločnosti Yamaha a garančnom servise v EHP\* a Švajčiarsku nájdete na webovej stránke uvedenej nižšie (na našej webovej stránke je k dispozicii súbor na tlač) alebo sa obráťte na zástupcu За подробна информация за гаранцията за този продукт на Yamaha и гаранционното обслужване в паневропейската зона на ЕИП\* и Швейцария или посетете посочения по-долу уеб сайт (на нашия уеб сайт има файл за печат), или се свържете с Pentru informații detaliate privind acest produs Yamaha și serviciul de garanție Pan-SEE\* și Elveția, vizitați site-ul la adresa de mai jos (fișierul imprimabil este disponibil pe site-ul nostru) sau contactăți biroul reprezentanței Yamaha din tara dumneavoastră. Lai saņemtu detalīzētu garantijas informāciju par šo Yamaha produktu, kā arī garantijas apkalpošanu EEZ\* un Šveicē, lūdzu, Aby dowiedzieć się więcej na temat warunków gwarancyjnych tego produktu firmy Yamaha i serwisu gwarancyjnego w całym EOG\* spletno mesto, ki je navedeno spodaj (natisljiva datoteka je na voljo na našem spletnem mestu), ali se obrnite na Yamahinega svetainėje toliau nurodytu adresu (svetainėje yra spausdintinas failas) arba kreipkitės į "Yamaha" atstovybe savo šaliai. Za podrobnejše informacije o tem Yamahinem izdelku ter garancijskem servisu v celotnem EGP in Švici, obiščite lub skontaktować się z przedstawicielstwem firmy Yamaha w swoim kraju. \* EOG — Europejski Obszar Gospodarczy Fontos figyelmeztetés: Garancia-információk az EGT\* területén és Svájcban élő vásárlók számára представителния офис на Yamaha във вашата страна \* ЕИП: Европейско икономическо пространство kapcsolatba az országában működő Yamaha képviseleti irodával. \* EGT: Európai Gazdasági Térség Oluline märkus: Garantiiteave Euroopa Majanduspiirkonna (EMP)\* ja Šveitsi klientidele Важно съобщение: Информация за гаранцията за клиенти в ЕИП\* и Швейцария Notificare importantă: Informații despre garanție pentru clienții din SEE\* și Elveția Dôležité upozornenie: Informácie o záruke pre zákazníkov v EHP\* a Švajčiarsku Důležité oznámení: Záruční informace pro zákazníky v EHS\* a ve Švýcarsku społočnosti Yamaha vo svojej krajine. \* EHP: Európsky hospodársky priestor Pomembno obvestilo: Informacije o garanciji za kupce v EGP\* in Švici Svarīgs paziņojums: garantijas informācija klientiem EEZ\* un Šveicē Važna obavijest: Informacije o jamstvu za države EGP-a i Švicarske apkalpojošo Yamaha pārstāvniecību. \* EEZ: Eiropas Ekonomikas zona Dėmesio: informacija dėl garantijos pirkėjams EEE\* ir Šveicarijoje Ważne: Warunki gwarancyjne obowiązujące w EOG\* i Szwajcarii predstavnika v svoji državi. \* EGP: Evropski gospodarski prostor Yamaha ve své zemi, \* EHS: Evropský hospodářský prostor esinduse poole. \* EMP: Euroopa Majanduspiirkond 'EEE - Europos ekonominė erdvė \* SEE: Spaţiul Economic European EAAnviká Svenska Deutsch

Lietuviu kalba

https://europe.yamaha.com/warranty/

Za detaline informacije o jamstvu za ovaj Yamahin proizvod te jamstvenom servisu za cijeli EGP i Švicarsku, molimo Vas da posjetite web-stranicu navedenu u nastavku ili kontaktirate ovlaštenog Yamahinog dobavljača u svojoj zemlji.

\* EGP: Europski gospodarski prostor

Limba română

Slovenščina

#### NORTH AMERICA

#### CANADA

Yamaha Canada Music Ltd.

135 Milner Avenue, Toronto, Ontario M1S 3R1, Canada

Tel: +1-416-298-1311

#### U.S.A.

Yamaha Corporation of America

6600 Orangethorpe Avenue, Buena Park, CA 90620,

Tel: +1-714-522-9011

#### CENTRAL & SOUTH AMERICA

#### MEXICO

Yamaha de México, S.A. de C.V. Av. Insurgentes Sur 1647 Piso 9, Col. San José Insurgentes, Delegación Benito Juárez, CDMX, C.P. 03900, México Tel: +52-55-5804-0600

#### BRAZII.

Yamaha Musical do Brasil Ltda.

Praça Professor José Lannes, 40-Cjs 21 e 22, Brooklin Paulista Novo CEP 04571-100 – São Paulo – SP, Brazil

Tel: +55-11-3704-1377

#### ARGENTINA

Yamaha Music Latin America, S.A.,

Sucursal Argentina Olga Cossettini 1553, Piso 4 Norte, Madero Este-C1107CEK,

Buenos Aires, Argentina Tel: +54-11-4119-7000 PANAMA AND OTHER LATIN

#### AMERICAN REGIONS/

CARIBBEAN REGIONS Yamaha Music Latin America, S.A.

Edificio Torre Davivienda, Piso: 20 Avenida Balboa, Marbella, Corregimiento de Bella

Vista, Ciudad de Panamá, Rep. de Panamá Tel: +507-269-5311

#### EUROPE

#### THE UNITED KINGDOM/IRELAND

Yamaha Music Europe GmbH (UK) Sherbourne Drive, Tilbrook, Milton Keynes,

MK7 8BL, U.K. Tel: +44-1908-366700

GERMANY

Yamaha Music Europe GmbH Siemensstrasse 22-34, 25462 Rellingen, Germany Tel: +49-4101-303-0

#### SWITZERLAND/LIECHTENSTEIN

Yamaha Music Europe GmbH, Branch

Switzerland in Thalwil Seestrasse 18a, 8800 Thalwil, Switzerland

Tel: +41-44-3878080 AUSTRIA/CROATIA/CZECH REPUBLIC/

#### HUNGARY/ROMANIA/SLOVAKIA/ SLOVENIA

Yamaha Music Europe GmbH, Branch Austria Schleiergasse 20. 1100 Wien, Austria Tel: +43-1-60203900

#### POLAND

Yamaha Music Europe

Sp.z o.o. Oddział w Polsce ul. Wielicka 52, 02-657 Warszawa, Poland

Tel: +48-22-880-08-88

#### BULGARIA

#### Dinacord Bulgaria LTD.

Bul.Iskarsko Schose 7 Targowski Zentar Ewropa 1528 Sofia, Bulgaria Tel: +359-2-978-20-25

#### MALTA

Olimpus Music Ltd. Valletta Road, Mosta MST9010, Malta Tel: +356-2133-2093

#### NETHERLANDS/BELGIUM/ LUXEMBOURG

Yamaha Music Europe, Branch Benelux

Clarissenhof 5b, 4133 AB Vianen, The Netherlands Tel: +31-347-358040

#### FRANCE

Yamaha Music Europe

7 rue Ambroise Croizat, Zone d'activités de Pariest, 77183 Croissy-Beaubourg, France Tel: +33-1-6461-4000

Yamaha Music Europe GmbH, Branch Italy Via Tinelli N.67/69 20855 Gerno di Lesmo (MB),

Italy

Tel: +39-039-9065-1

#### SPAIN/PORTUGAL

Yamaha Music Europe GmbH Ibérica, Sucursal en España

Ctra. de la Coruña km. 17.200. 28231

Las Rozas de Madrid, Spain Tel: +34-91-639-88-88

#### GREECE

Philippos Nakas S.A. The Music House 19th klm. Leof. Lavriou 190 02 Peania – Attiki. Greece Tel: +30-210-6686260

#### SWEDEN

Yamaha Music Europe GmbH Germany Filial Scandinavia

JA Wettergrensgata 1, 400 43 Göteborg, Sweden Tel: +46-31-89-34-00

#### DENMARK

Yamaha Music Denmark.

Fillial of Yamaha Music Europe GmbH, Tyskland Generatorvej 8C, ST. TH., 2860 Søborg, Denmark Tel: +45-44-92-49-00

#### FINLAND

F-Musiikki Ov

Antaksentie 4 FI-01510 Vantaa, Finland Tel: +358 (0)96185111

#### NORWAY

Yamaha Music Europe GmbH Germany -

Norwegian Branch Grini Næringspark 1, 1332 Østerås, Norway Tel: +47-6716-7800

### ICELAND

Hljodfaerahusid Ehf.

Sidumula 20 IS-108 Reykjavik, Iceland Tel: +354-525-5050

#### CYPRUS

Nakas Music Cyprus Ltd.

Nikis Ave 2k 1086 Nicosia Tel: + 357-22-511080

Major Music Center

21 Ali Riza Ave. Ortakoy P.O.Box 475 Lefkoşa, Cyprus

Tel: (392) 227 9213

#### RUSŠIA

Yamaha Music (Russia) LLC.

Room 37, entrance 7, bld. 7, Kievskaya street, Moscow, 121059, Russia Tel: +7-495-626-5005

#### OTHER EUROPEAN REGIONS

Yamaha Music Europe GmbH Siemensstrasse 22-34, 25462 Rellingen, Germany Tel: +49-4101-303-0

#### AFRICA

MIDDLE EAST

Yamaha Music Gulf FZE

IAEZA-16 Office 512 PO Box 17328 Jebel Ali FZE, Dubai, UAE Tel: +971-4-801-1500

#### TURKEY

Yamaha Music Europe GmbH

Merkezi Almanya Türkiye İstanbul Şubesi Mor Sumbul Sokak Varyap Meridian Business 1.Blok No:1 113-114-115 Bati Atasehir Istanbul, Turkey Tel: +90-216-275-7960

#### ISRAEL

RBX International Co., Ltd. P.O Box 10245, Petach-Tikva, 49002 Tel: (972) 3-925-6900

#### OTHER REGIONS

Yamaha Music Gulf FZE

JAFZA-16, Office 512, P.O.Box 17328, Jebel Ali FZE, Dubai, UAE Tel: +971-4-801-1500

#### ASIA

#### THE PEOPLE'S REPUBLIC OF CHINA

Yamaha Music & Electronics (China) Co., Ltd. Yunhedasha, 1818 Xinzha-lu, Jingan-qu. Shanghai, China Tel: +86-400-051-7700

#### HONG KONG

Tom Lee Music Co., Ltd. 11/F., Silvercord Tower 1, 30 Canton Road, Tsimshatsui, Kowloon, Hong Kong Tel: +852-2737-7688

#### INDIA

Yamaha Music India Private Limited P-401, JMD Megapolis, Sector-48, Sohna Road, Gurugram-122018, Haryana, India Tel: +91-124-485-3300

#### INDONESIA

PT Yamaha Musik Indonesia Distributor Yamaha Music Center Bldg, Jalan Jend, Gatot Subroto Kav. 4, Jakarta 12930, Indonesia Tel: +62-21-520-2577

KOREA Yamaha Music Korea Ltd.

11F, Prudential Tower, 298, Gangnam-daero, Gangnam-gu, Seoul, 06253, Korea Tel: +82-2-3467-3300

#### MALAYSIA

Yamaha Music (Malaysia) Sdn. Bhd. No.8, Jalan Perbandaran, Kelana Jaya, 47301

Petaling Jaya, Selangor, Malaysia Tel: +60-3-78030900

#### SINGAPORE

Yamaha Music (Asia) Private Limited Block 202 Hougang Street 21, #02-00, Singapore 530202, Singapore Tel: +65-6740-9200

#### TAIWAN

Yamaha Music & Electronics Taiwan Co., Ltd.

2F., No. 1, Yuandong Rd., Banqiao Dist., New Taipei City 22063, Taiwan (R.O.C.) Tel: +886-2-7741-8888

#### THAILAND

Siam Music Yamaha Co., Ltd.

3, 4, 15, 16th Fl., Siam Motors Building, 891/1 Rama 1 Road, Wangmai, Pathumwan, Bangkok 10330, Thailand Tel: +66-2215-2622

#### VIETNAM

Yamaha Music Vietnam Company Limited 15th Floor, Nam A Bank Tower, 201-203 Cach Mang Thang Tam St., Ward 4, Dist.3, Ho Chi Minh City, Vietnam Tel: +84-28-3818-1122

#### OTHER ASIAN REGIONS

https://asia-latinamerica-mea.yamaha.com/ index.html

#### OCEANIA

#### AUSTRALIA

Yamaha Music Australia Pty. Ltd.

Level 1, 80 Market Street, South Melbourne, VIC 3205 Australia Tel: +61-3-9693-5111

#### NEW ZEALAND

Music Works LTD P.O.BOX 6246 Wellesley, Auckland 4680, New Zealand Tel: +64-9-634-0099

#### REGIONS AND TRUST

TERRITORIES IN PACIFIC OCEAN https://asia-latinamerica-mea.yamaha.com/ index html

Yamaha Global Site https://www.yamaha.com/ Yamaha Downloads https://download.yamaha.com/

> Manual Development Group © 2020 Yamaha Corporation

Published 10/2021 POTY-C0

