

General-Purpose AC Servo

MITSUBISHI SERVO AMPLIFIERS & MOTORS

MELSERV~~o~~-J4

CC-Link IE Field Network Interface

MODEL

MR-J4- _GF_ (-RJ)

SERVO AMPLIFIER

INSTRUCTION MANUAL

(I/O MODE)

● Safety Instructions ●

Please read the instructions carefully before using the equipment.

To use the equipment correctly, do not attempt to install, operate, maintain, or inspect the equipment until you have read through this Instruction Manual, Installation guide, and appended documents carefully. Do not use the equipment until you have a full knowledge of the equipment, safety information and instructions. In this Instruction Manual, the safety instruction levels are classified into "WARNING" and "CAUTION".




Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.




Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight injury to personnel or may cause physical damage.

Note that the CAUTION level may lead to a serious consequence according to conditions. Please follow the instructions of both levels because they are important to personnel safety. What must not be done and what must be done are indicated by the following diagrammatic symbols.



Indicates what must not be done. For example, "No Fire" is indicated by .




Indicates what must be done. For example, grounding is indicated by .

In this Instruction Manual, instructions at a lower level than the above, instructions for other functions, and so on are classified into "POINT".

After reading this Instruction Manual, keep it accessible to the operator.

1. To prevent electric shock, note the following

WARNING

- Before wiring and inspections, turn off the power and wait for 15 minutes or more until the charge lamp turns off. Then, confirm that the voltage between P+ and N- is safe with a voltage tester and others. Otherwise, an electric shock may occur. In addition, when confirming whether the charge lamp is off or not, always confirm it from the front of the servo amplifier.
- Ground the servo amplifier and servo motor securely.
- Any person who is involved in wiring and inspection should be fully competent to do the work.
- Do not attempt to wire the servo amplifier and servo motor until they have been installed. Otherwise, it may cause an electric shock.
- Do not operate switches with wet hands. Otherwise, it may cause an electric shock.
- The cables should not be damaged, stressed, loaded, or pinched. Otherwise, it may cause an electric shock.
- During power-on or operation, do not open the front cover of the servo amplifier. Otherwise, it may cause an electric shock.
- Do not operate the servo amplifier with the front cover removed. High-voltage terminals and charging area are exposed and you may get an electric shock.
- Except for wiring and periodic inspection, do not remove the front cover of the servo amplifier even if the power is off. The servo amplifier is charged and you may get an electric shock.
- To prevent an electric shock, always connect the protective earth (PE) terminal (marked ) of the servo amplifier to the protective earth (PE) of the cabinet.
- To avoid an electric shock, insulate the connections of the power supply terminals.

2. To prevent fire, note the following

CAUTION

- Install the servo amplifier, servo motor, and regenerative resistor on incombustible material. Installing them directly or close to combustibles will lead to smoke or a fire.
- Always connect a magnetic contactor between the power supply and the main circuit power supply (L1/L2/L3) of the servo amplifier, in order to configure a circuit that shuts down the power supply on the side of the servo amplifier's power supply. If a magnetic contactor is not connected, continuous flow of a large current may cause smoke or a fire when the servo amplifier malfunctions.
- Always connect a molded-case circuit breaker, or a fuse to each servo amplifier between the power supply and the main circuit power supply (L1/L2/L3) of the servo amplifier, in order to configure a circuit that shuts down the power supply on the side of the servo amplifier's power supply. If a molded-case circuit breaker or fuse is not connected, continuous flow of a large current may cause smoke or a fire when the servo amplifier malfunctions.
- When using the regenerative resistor, switch power off with the alarm signal. Otherwise, a regenerative transistor malfunction or the like may overheat the regenerative resistor, causing smoke or a fire.
- Provide adequate protection to prevent screws and other conductive matter, oil and other combustible matter from entering the servo amplifier and servo motor.

3. To prevent injury, note the following

CAUTION

- Only the voltage specified in the Instruction Manual should be applied to each terminal. Otherwise, a burst, damage, etc. may occur.
- Connect cables to the correct terminals. Otherwise, a burst, damage, etc. may occur.

⚠ CAUTION

- Ensure that polarity (+/-) is correct. Otherwise, a burst, damage, etc. may occur.
- The servo amplifier heat sink, regenerative resistor, servo motor, etc. may be hot while power is on and for some time after power-off. Take safety measures, e.g. provide covers, to prevent accidental contact of hands and parts (cables, etc.) with them.

4. Additional instructions

The following instructions should also be fully noted. Incorrect handling may cause a fault, injury, electric shock, fire, etc.

(1) Transportation and installation

⚠ CAUTION

- Transport the products correctly according to their mass.
- Stacking in excess of the specified number of product packages is not allowed.
- Do not hold the front cover when transporting the servo amplifier. Otherwise, it may drop.
- Install the servo amplifier and the servo motor in a load-bearing place in accordance with the Instruction Manual.
- Do not get on or put heavy load on the equipment. Otherwise, it may cause injury.
- The equipment must be installed in the specified direction.
- Leave specified clearances between the servo amplifier and the cabinet walls or other equipment.
- Do not install or operate the servo amplifier and servo motor which have been damaged or have any parts missing.
- Do not block the intake and exhaust areas of the servo amplifier. Otherwise, it may cause a malfunction.
- Do not drop or strike the servo amplifier and servo motor. Isolate them from all impact loads.
- When you keep or use the equipment, please fulfill the following environment.


Items		Environment
Ambient temperature	Operation	0 °C to 55 °C (non-freezing)
	Storage	-20 °C to 65 °C (non-freezing)
Ambient humidity	Operation	5 %RH to 90 %RH (non-condensing)
	Storage	
Ambience		Indoors (no direct sunlight), free from corrosive gas, flammable gas, oil mist, dust, and dirt
Altitude		Max. 2000 m above sea level (Contact your local sales office for the altitude for options.)
Vibration resistance		5.9 m/s ² at 10 Hz to 55 Hz (directions of X, Y, and Z axes)

- When the product has been stored for an extended period of time, contact your local sales office.
- When handling the servo amplifier, be careful about the edged parts such as corners of the servo amplifier.
- The servo amplifier must be installed in the metal cabinet.
- When fumigants that contain halogen materials such as fluorine, chlorine, bromine, and iodine are used for disinfecting and protecting wooden packaging from insects, they cause malfunction when entering our products. Please take necessary precautions to ensure that remaining materials from fumigant do not enter our products, or treat packaging with methods other than fumigation (heat method). Additionally, disinfect and protect wood from insects before packing products.


(2) Wiring

⚠ CAUTION

- Wire the equipment correctly and securely. Otherwise, the servo motor may operate unexpectedly.
- Do not install a power capacitor, surge killer, or radio noise filter (FR-BIF(-H) option) on the servo amplifier output side.
- To avoid a malfunction, connect the wires to the correct phase terminals (U/V/W) of the servo amplifier and servo motor.
- Connect the servo amplifier power output (U/V/W) to the servo motor power input (U/V/W) directly. Do not let a magnetic contactor, etc. intervene. Otherwise, it may cause a malfunction.



- The connection diagrams in this instruction manual are shown for sink interfaces, unless stated otherwise.
- The surge absorbing diode installed to the DC relay for control output should be fitted in the specified direction. Otherwise, the emergency stop and other protective circuits may not operate.



- When the cable is not tightened enough to the terminal block, the cable or terminal block may generate heat because of the poor contact. Be sure to tighten the cable with specified torque.
- Connecting a servo motor for different axis to the U, V, W, or CN2 may cause a malfunction.
- Configure a circuit to turn off EM2 or EM1 when the main circuit power is turned off to prevent an unexpected restart of the servo amplifier.

(3) Test run and adjustment

⚠ CAUTION

- Before operation, check the parameter settings. Improper settings may cause some machines to perform unexpected operation.
- Never adjust or change the parameter values extremely as it will make operation unstable.
- Do not close to moving parts at servo-on status.

(4) Usage

⚠ CAUTION

- Provide an external emergency stop circuit to ensure that operation can be stopped and power switched off immediately.
- Do not disassemble, repair, or modify the equipment.


⚠ CAUTION

- Before resetting an alarm, make sure that the run signal of the servo amplifier is off in order to prevent a sudden restart. Otherwise, it may cause an accident.
- Use a noise filter, etc. to minimize the influence of electromagnetic interference. Electromagnetic interference may be given to the electronic equipment used near the servo amplifier.
- Burning or breaking a servo amplifier may cause a toxic gas. Do not burn or break it.
- Use the servo amplifier with the specified servo motor.
- The electromagnetic brake on the servo motor is designed to hold the motor shaft and should not be used for ordinary braking.
- For such reasons as service life and mechanical structure (e.g. where a ball screw and the servo motor are coupled via a timing belt), the electromagnetic brake may not hold the motor shaft. To ensure safety, install a stopper on the machine side.

(5) Corrective actions

⚠ CAUTION

- Ensure safety by confirming the power off, etc. before performing corrective actions. Otherwise, it may cause an accident.
- When it is assumed that a hazardous condition may occur due to a power failure or product malfunction, use a servo motor with an electromagnetic brake or external brake to prevent the condition.
- Configure an electromagnetic brake circuit which is interlocked with an external emergency stop switch.



- When any alarm has occurred, eliminate its cause, ensure safety, and deactivate the alarm before restarting operation.
- Provide an adequate protection to prevent unexpected restart after an instantaneous power failure.

(6) Maintenance, inspection and parts replacement

⚠ CAUTION

- Make sure that the emergency stop circuit operates properly such that an operation can be stopped immediately and a power is shut off by the emergency stop switch.
- It is recommended that the servo amplifier be replaced every 10 years when it is used in general environment.
- When using a servo amplifier whose power has not been turned on for a long time, contact your local sales office.

(7) General instruction

● To illustrate details, the equipment in the diagrams of this Instruction Manual may have been drawn without covers and safety guards. When the equipment is operated, the covers and safety guards must be installed as specified. Operation must be performed in accordance with this Specifications and Instruction Manual.

● DISPOSAL OF WASTE ●

Please dispose a servo amplifier, battery (primary battery) and other options according to your local laws and regulations.



EEP-ROM life

The number of write times to the EEP-ROM, which stores parameter settings, etc., is limited to 100,000. If the total number of the following operations exceeds 100,000, the servo amplifier may malfunction when the EEP-ROM reaches the end of its useful life.

- Write to the EEP-ROM due to parameter setting changes
- Write to the EEP-ROM due to device changes

STO function of the servo amplifier

When using the STO function of the servo amplifier, refer to chapter 13 of "MR-J4-_GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)".

For the MR-J3-D05 safety logic unit, refer to app. 5 of "MR-J4-_GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)".

Compliance with global standards

For the compliance with global standards, refer to app. 4 of "MR-J4-_GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)".

«About the manual»

You must have this Instruction Manual and the following manuals to use this servo. Ensure to prepare them to use the servo safely.

Relevant manuals

Manual name	Manual No.
MELSERVO MR-J4-_GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)	SH(NA)030218ENG
MELSERVO-J4 MR-J4 Servo Amplifier Instruction Manual (Troubleshooting)	SH(NA)030109ENG
MELSERVO MR-D30 Instruction Manual (Note 5)	SH(NA)030132ENG
MELSERVO Servo Motor Instruction Manual (Vol. 3) (Note 1)	SH(NA)030113ENG
MELSERVO Linear Servo Motor Instruction Manual (Note 2)	SH(NA)030110ENG
MELSERVO Direct Drive Motor Instruction Manual (Note 3)	SH(NA)030112ENG
MELSERVO Linear Encoder Instruction Manual (Note 2, 4)	SH(NA)030111ENG
EMC Installation Guidelines	IB(NA)67310ENG

- Note
1. It is necessary for using a rotary servo motor.
 2. It is necessary for using a linear servo motor.
 3. It is necessary for using a direct drive motor.
 4. It is necessary for using a fully closed loop system.
 5. It is necessary for using an MR-D30 functional safety unit.

This Instruction Manual does not describe the following items. For details of the items, refer to each chapter/section of the detailed explanation field. "MR-J4-_GF_" means "MELSERVO MR-J4-_GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)".

Item	Detailed explanation
Installation	MR-J4-_GF_ Chapter 2
Signals and wiring	MR-J4-_GF_ Chapter 3
Normal gain adjustment	MR-J4-_GF_ Chapter 6
Special adjustment functions	MR-J4-_GF_ Chapter 7
Outline drawings	MR-J4-_GF_ Chapter 9
Characteristics	MR-J4-_GF_ Chapter 10
Options and auxiliary equipment	MR-J4-_GF_ Chapter 11
Absolute position detection system	MR-J4-_GF_ Chapter 12
Using STO Function	MR-J4-_GF_ Chapter 13
Using a Linear servo motor	MR-J4-_GF_ Chapter 14
Using a direct drive motor	MR-J4-_GF_ Chapter 15
Fully closed loop system	MR-J4-_GF_ Chapter 16
Application of functions	MR-J4-_GF_ Chapter 17

«U.S. customary units»

U.S. customary units are not shown in this manual. Convert the values if necessary according to the following table.

Quantity	SI (metric) unit	U.S. customary unit
Mass	1 [kg]	2.2046 [lb]
Length	1 [mm]	0.03937 [inch]
Torque	1 [N•m]	141.6 [oz•inch]
Moment of inertia	1 [$(\times 10^{-4} \text{ kg}\cdot\text{m}^2)$]	5.4675 [oz•inch ²]
Load (thrust load/axial load)	1 [N]	0.2248 [lbf]
Temperature	N [$^{\circ}\text{C}$] $\times 9/5 + 32$	N [$^{\circ}\text{F}$]

CONTENTS

1. FUNCTIONS AND CONFIGURATION	1- 1 to 1-10
1.1 For proper use of the I/O mode	1- 1
1.2 I/O mode specification list.....	1- 2
1.3 Function list.....	1- 5
1.4 Configuration including peripheral equipment	1- 8
2. POINT TABLE OPERATION	2- 1 to 2-92
2.1 Link device	2- 1
2.1.1 Profile	2- 1
2.1.2 Detailed explanation of the RYn/RXn profile.....	2- 4
2.1.3 Detailed explanation of the RWwn/RWrn profile.....	2- 8
2.1.4 Code.....	2-10
2.1.5 Data communication timing chart.....	2-21
2.1.6 Remote register-based position/speed setting	2-24
2.2 Switching power on for the first time.....	2-27
2.3 Automatic operation mode	2-29
2.3.1 Automatic operation mode	2-29
2.3.2 Automatic operation using point table.....	2-30
2.4 Manual operation mode	2-58
2.4.1 JOG operation.....	2-58
2.5 Home position return mode	2-62
2.5.1 Outline of home position return.....	2-63
2.5.2 Method -5 (Home position ignorance (Servo-on position as home position))	2-69
2.5.3 Automatic positioning to home position function.....	2-70
2.6 Point table setting method	2-71
2.6.1 Setting procedure	2-71
2.6.2 Detailed setting window	2-73
2.6.3 Single-step feed	2-74
2.7 Programming example by function	2-75
2.7.1 System configuration example	2-75
2.7.2 Reading the servo amplifier status.....	2-78
2.7.3 Writing an operation command	2-79
2.7.4 Reading data	2-81
2.7.5 Writing data	2-83
2.7.6 Operation.....	2-86
2.8 Program example for continuous operation.....	2-89
3. PARAMETERS	3- 1 to 3-32
3.1 Parameter list.....	3- 1
3.1.1 Basic setting parameters ([Pr. PA_ _]).....	3- 2
3.1.2 Gain/filter setting parameters ([Pr. PB_ _]).....	3- 3
3.1.3 Extension setting parameters ([Pr. PC_ _])	3- 4
3.1.4 I/O setting parameters ([Pr. PD_ _])	3- 7
3.1.5 Extension setting 2 parameters ([Pr. PE_ _]).....	3- 8
3.1.6 Extension setting 3 parameters ([Pr. PF_ _]).....	3- 9
3.1.7 Linear servo motor/DD motor setting parameters ([Pr. PL_ _])	3-11

3.1.8 Positioning control parameters ([Pr. PT_ _]).....	3-12
3.1.9 Network setting parameters ([Pr. PN_ _]).....	3-14
3.2 Detailed list of parameters	3-15
3.2.1 Basic setting parameters ([Pr. PA_ _]).....	3-15
3.2.2 Extension setting parameters ([Pr. PC_ _])	3-16
3.2.3 I/O setting parameters ([Pr. PD_ _])	3-17
3.2.4 Positioning control parameters ([Pr. PT_ _]).....	3-18
3.2.5 Network setting parameters ([Pr. PN_ _]).....	3-26
3.3 How to set the electronic gear	3-27
3.3.1 Electronic gear settings in the point table method and program method	3-27
3.3.2 Electronic gear setting in the indexer method.....	3-29
3.4 Stop method for RY (n + 1) 0 (Upper stroke limit) off or RY (n + 1) 1 (Lower stroke limit) off	3-30
3.5 Stop method at software limit detection.....	3-31

4. TROUBLESHOOTING	4- 1 to 4-16
---------------------------	---------------------

4.1 Explanation for the lists.....	4- 1
4.2 Alarm list	4- 2
4.3 Warning list	4-12
4.4 Troubleshooting at power on	4-15

5. INDEXER OPERATION	5- 1 to 5 -50
-----------------------------	----------------------

5.1 Link device	5- 1
5.1.1 Profile	5- 1
5.1.2 Detailed explanation of the RYn/RXn profile.....	5- 4
5.1.3 Detailed explanation of the RWwn/RWrn profile.....	5- 7
5.1.4 Code.....	5- 9
5.1.5 Data communication timing chart.....	5-17
5.2 Switching power on for the first time.....	5-18
5.3 Automatic operation mode.....	5-20
5.3.1 Automatic operation mode	5-20
5.3.2 Rotation direction specifying indexer	5-21
5.3.3 Shortest rotating indexer operation.....	5-31
5.4 Manual operation mode	5-40
5.4.1 Station JOG operation.....	5-40
5.4.2 JOG operation.....	5-42
5.5 Home position return mode	5-44
5.5.1 Outline of home position return	5-44
5.5.2 Torque limit changing dog type home position return.....	5-45
5.5.3 Torque limit changing data set type	5-47
5.5.4 Homing method 35, 37 (Homing on current position).....	5-49
5.5.5 Safety precautions	5-50

6. APPLICATION OF FUNCTIONS	6- 1 to 6-40
------------------------------------	---------------------

6.1 Simple cam function.....	6- 1
6.1.1 Outline of simple cam function	6- 2
6.1.2 Simple cam function block	6- 2
6.1.3 Simple cam specification list	6- 3
6.1.4 Control of simple cam function.....	6- 4

6.1.5 Operation in combination with the simple cam	6- 5
6.1.6 Setting list.....	6- 6
6.1.7 Data to be used with simple cam function	6- 7
6.1.8 Function block diagram for displaying state of simple cam control	6-20
6.1.9 Operation.....	6-21
6.1.10 Cam No. setting method	6-26
6.1.11 Stop operation of cam control	6-27
6.1.12 Restart operation of cam control.....	6-29
6.1.13 Cam axis position at cam control switching	6-30
6.1.14 Clutch	6-37
6.1.15 Cam position compensation target position.....	6-38
6.1.16 Cam position compensation time constant	6-39
6.1.17 Backup restore function	6-39

MEMO

[illegible]

1. FUNCTIONS AND CONFIGURATION

1. FUNCTIONS AND CONFIGURATION

The items shown in the following table are the same as those for the motion mode. For details, refer to each section indicated in the detailed explanation field. "MR-J4-_GF_" means "MR-J4-_GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)".

Item	Detailed explanation
Function block diagram	MR-J4-_GF_ section 1.2
Combinations of servo amplifiers and servo motors	MR-J4-_GF_ section 1.4
Model designation	MR-J4-_GF_ section 1.6
Structure (parts identification)	MR-J4-_GF_ section 1.7
Configuration including peripheral equipment	MR-J4-_GF_ section 1.8

1.1 For proper use of the I/O mode

(1) Servo amplifier/MR Configurator2


The I/O mode is available with the servo amplifier and MR Configurator2 with the following software versions.

Product name	Model	Software version	
		Point table method	Indexer method
Servo amplifier	MR-J4-_GF_(-RJ)	A1 or later	A3 or later
MR Configurator2	SW1DNC-MRC2-_	1.52E or later	1.60N or later

(2) Parameter setting


(a) Selection of station-specific mode

Set [Pr. PN03 Station-specific mode setting] to "1" to select the I/O mode as the station-specific mode.



(b) Selection of the positioning mode

Select a positioning mode with [Pr. PA01 Operation mode] to use.



1. FUNCTIONS AND CONFIGURATION

1.2 I/O mode specification list

Only the specifications of the I/O mode are listed here. For other specifications, refer to section 1.3 of "MR-J4-_GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)".

Item			Description
Servo amplifier model			MR-J4-_GF_(-RJ)
Command method	Point table	Operational specifications	Positioning with specification of point table No. (255 points)
		Position command input (Note 1)	Set in the point table. Setting range of feed length per point: -999999 to 999999 [$\times 10^{\text{STM}}$ μm], -99.9999 to 99.9999 [$\times 10^{\text{STM}}$ inch], -999999 to 999999 [pulse]
			Set in the point table. Setting range of feed length per point: 0 to 999999 [$\times 10^{\text{STM}}$ μm], 0 to 99.9999 [$\times 10^{\text{STM}}$ inch], 0 to 999999 [pulse]
		Speed command input	Set the acceleration/deceleration time constants in the point table. Set the S-pattern acceleration/deceleration time constants with [Pr. PT51].
		System	Signed absolute value command method/incremental value command method
		Torque limit	Set with a parameter or link device.
	Position command data input	Operational specifications	Positioning with a setting of a remote register
		Position command input	Set the position command data with a remote register. Setting range of feed length: -999999 to 999999 [$\times 10^{\text{STM}}$ μm], -99.9999 to 99.9999 [$\times 10^{\text{STM}}$ inch], -999999 to 999999 [pulse]
		Speed command input	Select from point tables with a remote register. Set the speed command data (speed) with a remote register. Set the S-pattern acceleration/deceleration time constants with [Pr. PT51].
		System	Signed absolute position command method, incremental value command method
	Indexer (Note 3)	Operational specifications	Positioning by specifying the station position The maximum number of divisions: 255
		Speed command input	Selected from the point table by the remote register. Set speed command data (rotation speed and acceleration/deceleration time constants) by the remote register.
		System	Rotation direction specifying indexer/shortest rotating indexer
		Torque limit	Set with a parameter or link device.
Operation mode	Automatic operation mode	Point table	Point table No. input method/position data input method Operates each positioning based on position command and speed command.
			Varying-speed operation (2 to 255 speeds)/automatic continuous positioning operation (2 to 255 points)/Automatic continuous operation to a point table selected at startup/automatic continuous operation to the point table No. 1
		Indexer	Positions to the specified station. Rotation direction settable
			Positions to the specified station. Rotates in the shorter direction from the current position.
	Manual operation mode	Point table	In accordance with the speed data set in parameters, JOG operation is performed by using CC-Link IE Field Network communication.
		Indexer	Decelerates to a stop regardless of the station.
			Rotates in a direction specified by the rotation direction decision when the start signal turns on. Positions to the nearest station where the servo motor can decelerate to a stop when the start signal turns off.

For details of the home position return types, refer to section 2.5.

1. FUNCTIONS AND CONFIGURATION

Item			Description
Home position return mode	Point table	Homing on index pulse (method 34)	For details of the home position return types, refer to section 2.5.
		Homing on current position (method 35)	
		Homing on current position (method 37)	
	Indexer	Torque limit switching dog type	For details of the home position return types, refer to section 5.5.
		Torque limit switching data set type	
		Homing on current position (method 35)	
		Homing on current position (method 37)	
	Automatic positioning to home position function		High-speed automatic positioning to a defined home position
	Other functions		Absolute position detection/external limit switch/software stroke limit

- Note
1. STM is the ratio to the setting value of the position data. STM can be changed with [Pr. PT03 Feeding function selection].
 2. If a direct drive motor or incremental type linear encoder is used, the dog type last Z-phase reference home position return or dogless Z-phase reference home position return cannot be used.
 3. The indexer method is available with servo amplifiers with software version A3 or later. When using the indexer method, use MR Configurator2 with software version 1.60N or later.

1. FUNCTIONS AND CONFIGURATION

1.3 Function list

POINT	
●	The symbol in the control mode column means as follows: CP: Point table method PS: Indexer method

The following table lists the functions of this servo. For details of the functions, refer to each section indicated in the detailed explanation field. "MR-J4-_GF_" means "MR-J4-_GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)".

Function	Description	Control mode		Detailed explanation
		CP	PS	
Model adaptive control	This function achieves a high response and stable control following the ideal model. The two-degrees-of-freedom model adaptive control enables you to set a response to the command and response to the disturbance separately. Additionally, this function can be disabled. To disable this function, refer to section 7.5 of "MR-J4-_GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)".	○	○	
Point table method	Set 1 to 255 point tables in advance, and select any point table to perform operation in accordance with the set values. To select point tables, use external input signals or communication function.	○		Chapter 2
Indexer method	Set 2 to 255 divided stations in advance to perform operation to the station positions. This is available with servo amplifiers with software version A3 or later.		○	Chapter 5
Roll feed display function (available in the future)	Positions based on specified travel distance from a status display "0" of current/command positions at start.			
Home position return	For the home position return types, refer to section 2.5 and 5.5.	○	○	Section 2.5 Section 5.5
High-resolution encoder	Rotary servo motors compatible with the MELSERVO-J4 series are equipped with a high-resolution encoder of 4194304 pulses/rev.	○	○	
Absolute position detection system	Home position return is required only once, and not required at every power-on.	○	○	MR-J4-_GF_ chapter 12
Gain switching function	You can switch gains during rotation/stop, and can use input devices to switch gains during operation.	○	○	MR-J4-_GF_ section 7.2
Advanced vibration suppression control II	This function suppresses vibration at an arm end or residual vibration.	○	○	MR-J4-_GF_ section 7.1.5
Machine resonance suppression filter	This filter function (notch filter) decreases the gain of the specific frequency to suppress the resonance of the mechanical system.	○	○	MR-J4-_GF_ section 7.1.1
Shaft resonance suppression filter	When a load is mounted to the servo motor shaft, resonance by shaft torsion during driving may generate a mechanical vibration at high frequency. The shaft resonance suppression filter suppresses the vibration.	○	○	MR-J4-_GF_ section 7.1.3
Adaptive filter II	The servo amplifier detects mechanical resonance and sets filter characteristics automatically to suppress mechanical vibration.	○	○	MR-J4-_GF_ section 7.1.2
Low-pass filter	Suppresses high-frequency resonance which occurs as the servo system response is increased.	○	○	MR-J4-_GF_ section 7.1.4
Machine analyzer function	Analyzes the frequency characteristic of the mechanical system by simply connecting an MR Configurator2 installed personal computer and the servo amplifier. MR Configurator2 is necessary for this function.	○	○	
Robust filter	For roll feed axis, etc. of which a response level cannot be increased because of the large load to motor inertia ratio, this function improves a disturbance response.	○	○	[Pr. PE41]
Slight vibration suppression control	Suppresses vibration of ±1 pulse generated at a servo motor stop.	○		[Pr. PB24]
Electronic gear	Position commands can be multiplied by 1/864 to 33935.	○		[Pr. PA06]
	Position commands can be multiplied by 1/9999 to 9999.		○	[Pr. PA07]

1. FUNCTIONS AND CONFIGURATION

Function	Description	Control mode		Detailed explanation
		CP	PS	
Auto tuning	Automatically adjusts the gain to optimum value if load applied to the servo motor shaft varies.	○	○	MR-J4-_GF_ section 6.3
Brake unit	Used when the regenerative option cannot provide enough regenerative power. Can be used for the 5 kW or more servo amplifier.	○	○	MR-J4-_GF_ section 11.3
Power regeneration converter	Used when the regenerative option cannot provide enough regenerative power. Can be used for the 5 kW or more servo amplifier.	○	○	MR-J4-_GF_ section 11.4
Regenerative option	Use a regenerative option when the built-in regenerative resistor of the servo amplifier does not have sufficient regenerative capacity for a large regenerative power generated.	○	○	MR-J4-_GF_ section 11.2
Alarm history clear	Clears alarm histories.	○	○	[Pr. PC21]
Input signal selection (device settings)	The input devices including PC (proportional control) can be assigned to certain pins of the CN3 connector.	○	○	[Pr. PD03] to [Pr. PD05]
Output signal selection (device settings)	The output devices including MBR (electromagnetic brake interlock) can be assigned to certain pins of the CN3 connector.	○	○	[Pr. PD07] to [Pr. PD09]
Output signal (DO) forced output	Turns on/off the output signals forcibly independently of the servo status. Use this function for checking output signal wiring, etc.	○	○	MR-J4-_GF_ section 4.5.1 (1) (d)
Torque limit	Limits the servo motor torque.	○	○	[Pr. PA11] [Pr. PA12]
Test operation mode	Jog operation/positioning operation/motor-less operation/DO forced output/program operation/single-step feed Note that MR Configurator2 is necessary for positioning operation, program operation, and single-step feed.	○	○	Section 2.6.3 MR-J4-_GF_ section 4.5
Analog monitor output	Outputs servo status with voltage in real time.	○	○	[Pr. PC09] [Pr. PC10]
MR Configurator2	Using a personal computer, you can perform the parameter setting, test operation, monitoring, and others.	○	○	MR-J4-_GF_ section 11.7
Linear servo system	Linear servo systems can be configured using a linear servo motor and linear encoder.	○	○	MR-J4-_GF_ chapter 14
Direct drive servo system	Direct drive servo systems can be configured to drive a direct drive motor.	○	○	MR-J4-_GF_ chapter 15
Fully closed loop system	Fully closed loop system can be configured using the load-side encoder.	○	○	MR-J4-_GF_ chapter 16
One-touch tuning	Adjusts gains just by pressing buttons on the servo amplifier or by clicking a button on MR Configurator2. In I/O mode, one-touch tuning via network is not possible.	○	○	MR-J4-_GF_ section 6.2
SEMI-F47 function	This servo amplifier complies with the SEMI-F47 standard. Thus, even when an instantaneous power failure occurs during operation, the electrical energy charged in the capacitor is used and [AL. 10 Undervoltage] is not triggered.	○	○	MR-J4-_GF_ section 7.4 [Pr. PA20] [Pr. PF25]
Tough drive function	This function makes the equipment continue operating even under the condition that an alarm occurs. The tough drive function includes two types: the vibration tough drive and the instantaneous power failure tough drive.	○	○	MR-J4-_GF_ section 7.3
Drive recorder function	This function continuously monitors the servo status and records the status transition before and after an alarm for a fixed period of time. You can check the recorded data on the drive recorder window on MR Configurator2 by clicking the "Graph" button. However, the drive recorder is not available when: 1. The graph function of MR Configurator2 is being used. 2. The machine analyzer function is being used. 3. [Pr. PF21] is set to "-1". 4. The controller is not connected (except the test operation mode). 5. An alarm related to the controller is occurring.	○	○	[Pr. PA23]

1. FUNCTIONS AND CONFIGURATION

Function	Description	Control mode		Detailed explanation
		CP	PS	
STO function	This amplifier complies with the STO function as functional safety of IEC/EN 61800-5-2. You can create a safety system for the equipment easily.	○	○	MR-J4-_GF_ chapter 13
Servo amplifier life diagnosis function	You can check the cumulative energization time and the number of on/off times of the inrush relay. This function gives an indication of the replacement time for parts of the servo amplifier including a capacitor and a relay before they malfunction. MR Configurator2 is necessary for this function.	○	○	
Power monitoring function	This function calculates the power running energy and the regenerative power from the data in the servo amplifier such as speed and current. Power consumption and others are displayed on MR Configurator2.	○	○	
Machine diagnosis function	From the data in the servo amplifier, this function estimates the friction and vibrational component of the drive system in the equipment and recognizes an error in the machine parts, including a ball screw and bearing. MR Configurator2 is necessary for this function.	○	○	MR-J4-_GF_ section 17.5
Limit switch	External limit switches can be used to limit travel intervals of the servo motor.	○	○	
S-pattern acceleration/deceleration	Enables smooth acceleration and deceleration. Set S-pattern acceleration/deceleration time constants with [Pr. PT51]. As compared with linear acceleration/deceleration, the acceleration/deceleration time will be longer for the S-pattern acceleration/deceleration time constants regardless of command speed.	○		[Pr. PT51]
Software limit	Limits travel intervals by address using parameters. Enables the same function with the limit switch by setting parameters.	○		MR-J4-_GF_ section 5.3
Speed limit	The servo motor speed can be limited.			
Lost motion compensation function	This function improves the response delay generated when the machine moving direction is reversed.	○	○	MR-J4-_GF_ section 7.6
Super trace control	This function sets constant and uniform acceleration/deceleration droop pulses to almost 0.	○	○	MR-J4-_GF_ section 7.7
SLMP	SLMP (SeamLess Message Protocol) is a protocol to access SLMP-compatible devices from external devices (such as a personal computer and an HMI) or CPU module via Ethernet. The parameters of servo amplifiers can be set (read or written) and monitored.	○	○	
Functional safety unit	MR-D30 can be used to expand the safety observation function. This is available with servo amplifiers with software version A3 or later.	○	○	
Simple cam function	This function enables the encoder following function, mark sensor input compensation function, synchronous operation using positioning data, and synchronous interpolation operation. This is available with servo amplifiers with software version A3 or later.	○		Chapter 6

1. FUNCTIONS AND CONFIGURATION

1.4 Configuration including peripheral equipment




CAUTION

- Connecting a servo motor of the wrong axis to U, V, W, or CN2 of the servo amplifier may cause a malfunction.
- The CN1A and CN1B connectors are dedicated for CC-Link IE Field Network. Do not connect a network other than CC-Link IE Field Network. Otherwise, a malfunction may occur.

POINT

- Equipment other than the servo amplifier and servo motor are optional or recommended products.

The following illustration is an example of MR-J4-20GF-RJ.



1. FUNCTIONS AND CONFIGURATION

- Note
1. The power factor improving AC reactor can also be used. In this case, the power factor improving DC reactor cannot be used. When not using the power factor improving DC reactor, short P3 and P4.
 2. For 1-phase 200 V AC to 240 V AC, connect the power supply to L1 and L3. Leave L2 open. Refer to section 1.3 of "MR-J4-_GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)" for the power supply specifications.
 3. Depending on the main circuit voltage and operation pattern, bus voltage decreases, and that may cause the forced stop deceleration to shift to the dynamic brake deceleration. When dynamic brake deceleration is not required, slow the time to turn off the magnetic contactor.
 4. This is for MR-J4-_GF_-RJ servo amplifier. MR-J4-_GF_ servo amplifier does not have CN2L connector. When using MR-J4-_GF_-RJ servo amplifier in the linear servo system or in the fully closed loop system, connect an external encoder to this connector. Refer to table 1.1 of "MR-J4-_GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)" and "Linear Encoder Instruction Manual" for the connectible external encoders.
 5. Always connect between P+ and D terminals. When using a regenerative option, refer to section 11.2 of "MR-J4-_GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)".

MEMO

[illegible]

2. POINT TABLE OPERATION

2. POINT TABLE OPERATION

The items shown in the following table are the same as those for the motion mode. For details, refer to each section indicated in the detailed explanation field. "MR-J4-_GF_" means "MR-J4-_GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)".

Item	Detailed explanation
Startup	MR-J4-_GF_ Section 4.2
Switch setting and display of the servo amplifier	MR-J4-_GF_ Section 4.3
Test operation	MR-J4-_GF_ Section 4.4
Test operation mode	MR-J4-_GF_ Section 4.5

POINT	
●	When you use a linear servo motor, replace the following left words to the right words. Load to motor inertia ratio → Load to motor mass ratio Torque → Thrust

2.1 Link device

2.1.1 Profile

Some input devices can be assigned to the CN3 pin using [Pr. PD03] to [Pr. PD05]. When using the CC-Link IE Field Network communication and CN3 connector's input signal, assigned devices other than upper stroke limit, lower stroke limit and proximity dog can be used simultaneously.

One output devices can be assigned to the CN3 pin with [Pr. PD07] to [Pr. PD09]. The assigned devices can be used together when using the CC-Link IE Field Network communication and CN3 connector's output signal.

When turning off input/output signals, turn off both CC-Link IE Field Network communication and external I/O signals of the CN3 connector. The following shows the profile of link devices communicated with the master station in cyclic transmission.

2. POINT TABLE OPERATION

Table 2.1 RYn/RXn profile

Master station → Servo amplifier (RYn)				Servo amplifier → Master station (RXn)			
(Note) Device No.	Device	Symbol	CN3 connector pin No.	(Note) Device No.	Device	Symbol	CN3 connector pin No.
RYn0	Servo-on	SON		RXn0	Ready	RD	
RYn1	Forward rotation start	ST1		RXn1	In-position	INP	9
RYn2	Reverse rotation start	ST2		RXn2	Rough match	CPO	
RYn3	Proximity dog	DOG	19	RXn3	Not used		
RYn4	Not used			RXn4	Limiting torque	TLC	
RYn5				RXn5	Not used		
RYn6	Automatic/manual selection	MD0		RXn6	Electromagnetic brake interlock	MBR	13
RYn7	Temporary stop/restart	TSTP		RXn7	During a temporary stop	PUS	
RYn8	Monitor output execution demand	MOR		RXn8	Monitoring	MOF	
RYn9	Instruction code execution demand	COR		RXn9	Instruction code execution completion	COF	
RYnA to RYnF	Not used			RXnA	Warning	WNG	
RY (n + 1) 0	Upper stroke limit	FLS		RXnB	Battery warning	BWNG	
RY (n + 1) 1	Lower stroke limit	RLS		RXnC	Travel completion	MEND	
RY (n + 1) 2	Operation alarm reset	ORST		RXnD	Dynamic brake interlock	DB	
RY (n + 1) 3	Cam control command	CAMC		RXnE	Position range output	POT	
RY (n + 1) 4	Not used			RXnF	Not used		
RY (n + 1) 5	Clutch command	CLTC		RX (n + 1) 0	Home position return completion 2	ZP2	
RY (n + 1) 6 to RY (n + 1) F	Not used			RX (n + 1) 1	Not used		
				RX (n + 1) 2			
RY (n + 2) 0	Position command execution demand	PSR		RX (n + 1) 3	Under cam control	CAMS	
RY (n + 2) 1	Speed command execution demand	SPR		RX (n + 1) 4	Cam position compensation execution completed	CPCC	
RY (n + 2) 2 to RY (n + 2) 6	Not used			RX (n + 1) 5	Clutch on/off status	CLTS	
RY (n + 2) 7	Proportional control	PC		RX (n + 1) 6	Clutch smoothing status	CLTSM	
RY (n + 2) 8	Gain switching	CDP		RX (n + 1) 7 to RX (n + 1) F	Not used		
RY (n + 2) 9	Not used			RX (n + 2) 0	Position command execution completion	PSF	
RY (n + 2) A	Position/speed specifying method selection	CSL		RX (n + 2) 1	Speed command execution completion	SPF	
RY (n + 2) B	Absolute value/incremental value selection	CAOR		RX (n + 2) 2 to RX (n + 2) F	Not used		
RY (n + 2) C to RY (n + 2) F	Not used			RX (n + 3) 0 to RX (n + 3) 9	Not used		
RY (n + 3) 0 to RY (n + 3) 9	Not used			RX (n + 3) A	Malfunction	ALM	15
RY (n + 3) A	Reset	RES		RX (n + 3) B	Remote station communication ready	CRD	
RY (n + 3) B to RY (n + 3) F	Not used			RX (n + 3) C to RX (n + 3) F	Not used		

Note. "n" depends on the station No. setting.

2. POINT TABLE OPERATION

Table 2.2 RWwn/RWrn profile

Master station → Servo amplifier (RWwn)		Servo amplifier → Master station (RWrn)	
(Note) Device No.	Device	(Note) Device No.	Device
RWwn0	Monitor 1	RWrn0	Monitor 1 data - Lower 16 bits
RWwn1	Not used	RWrn1	Monitor 1 data - Upper 16 bits
RWwn2	Monitor 2	RWrn2	Monitor 2 data - Lower 16 bits
RWwn3	Not used	RWrn3	Monitor 2 data - Upper 16 bits
RWwn4	Instruction code - Lower 16 bits	RWrn4	Respond code
RWwn5	Instruction code - Upper 16 bits	RWrn5	Not used
RWwn6	Point table No. selection	RWrn6	Point table No. output
RWwn7	Not used	RWrn7	Not used
RWwn8	Position command data - Lower 16 bits/Point table No.	RWrn8	
RWwn9	Position command data - Upper 16 bits	RWrn9	
RWwnA	Speed command data - Lower 16 bits/Point table No.	RWrnA	
RWwnB	Speed command data - Upper 16 bits	RWrnB	Not used
RWwnC	Writing data - Lower 16 bits	RWrnC	
RWwnD	Writing data - Upper 16 bits	RWrnD	
RWwnE	Cam No. setting	RWrnE	
RWwnF	Not used	RWrnF	Not used

Note. "n" depends on the station No. setting.

2. POINT TABLE OPERATION

2.1.2 Detailed explanation of the RYn/RXn profile

(1) RYn profile

Device No.	Device	Description						
RYn0	Servo-on	Turn on RYn0 to power on the base circuit, and make the servo amplifier ready to operate. (servo-on status) Turn it off to shut off the base circuit, and coast the servo motor.						
RYn1	Forward rotation start	1. Absolute value command method Turning on RYn1 during automatic operation will execute one positioning based on the position data set in the point tables. Turning on RYn1 during home position return will also start home position return. Turning on RYn1 during JOG operation will rotate the servo motor in the forward rotation direction while it is on. The forward rotation means address increasing direction. 2. Incremental value command method Turning on RYn1 during automatic operation will execute one positioning in the forward rotation direction based on the position data set in point tables. Turning on RYn1 during home position return will also start home position return. Turning on RYn1 during JOG operation will rotate the servo motor in the forward rotation direction while it is on. The forward rotation means address increasing direction. Turning on both RYn1 and RYn2 during JOG operation will stop the servo motor.						
RYn2	Reverse rotation start	Use this device with the incremental value command method. Turning on RYn2 during automatic operation will execute one positioning in the reverse rotation direction based on the position data set in point tables. Turning on RYn2 during JOG operation will rotate the servo motor in the reverse rotation direction while it is on. The reverse rotation means address decreasing direction. Turning on RYn2 during home position return will execute automatic positioning to the home position. Turning on both RYn1 and RYn2 during JOG operation will stop the servo motor.						
RYn3	Proximity dog	When RYn3 is turned off, a proximity dog will be detected. The polarity for dog can be changed with [Pr. PT29]. <table><tr><td>[Pr. PT29]</td><td>Polarity for proximity dog detection</td></tr><tr><td>___ 0 (initial value)</td><td>Detection with off</td></tr><tr><td>___ 1</td><td>Detection with on</td></tr></table>	[Pr. PT29]	Polarity for proximity dog detection	___ 0 (initial value)	Detection with off	___ 1	Detection with on
[Pr. PT29]	Polarity for proximity dog detection							
___ 0 (initial value)	Detection with off							
___ 1	Detection with on							
RYn6	Automatic/manual selection	Turning on RYn6 sets automatic operation mode, and turning it off sets manual operation mode.						
RYn7	Temporary stop/restart	Turning on RYn7 will temporarily stop the servo motor. Turning on RYn7 again will restart. However, if RYn7 is turned on during home position return, turning on RYn7 again does not restart the home position return operation. Turning on RYn1 (Forward rotation start)/RYn2 (Reverse rotation start) during a temporary stop will not rotate the servo motor. Changing the automatic operation mode to manual operation mode during a temporary stop will erase a travel remaining distance.						
RYn8	Monitor output execution demand	Turning on RYn8 sets the following data. At this time, RXn8 turns on. While RYn8 is on, the monitor value is always updated. RWrn0: Lower 16 bits of data requested with RWwn0 (Monitor 1) RWrn1: Upper 16 bits of data requested with RWwn0 (Monitor 1) RWrn2: Lower 16 bits of data requested with RWwn2 (Monitor 2) RWrn3: Upper 16 bits of data requested with RWwn2 (Monitor 2) RWrn4: Respond code indicating a normal or error result						
RYn9	Instruction code execution demand	Turning on RYn9 executes the processing corresponding to the instruction code set with RWwn4 and RWwn5. After executing the instruction code is completed, a respond code indicating a normal or error result is stored in RWrn4, and RXn9 turns on. Refer to section 2.1.4 (2) for details of instruction codes.						

2. POINT TABLE OPERATION

Device No.	Device	Description
RY (n + 1) 0	Upper stroke limit	To start the operation, turn on RY (n + 1) 0 and RY (n + 1) 1. Turning off the device corresponding to the servo motor rotation direction will bring the servo motor to a slow stop and make it servo-locked. The stop method can be changed with [Pr. PD12]. The home position is not erased; however, home position return may be required in some cases. Refer to [Pr. PD12] and section 3.4 for details.
RY (n + 1) 1	Lower stroke limit	
RY (n + 1) 2	Operation alarm reset	Turn on RY (n + 1) 2 from off to reset [AL. F4 Positioning warning].
RY (n + 1) 3	Cam control command	When using cam control command, set [Pr. PT35] to "_ 1 _" to enable it. Turning RY (n + 1) 3 on switches the control from the normal positioning control to the cam control.
RY (n + 1) 5	Clutch command	This is used to turning on/off the main shaft clutch command. This is used when [Cam control data No. 36 - Main shaft clutch control setting] is set to " _ _ _ 1".
RY (n + 2) 0	Position command execution demand	Turning on RY (n + 2) 0 sets the point table No. or position command data set in RWwn8 and RWwn9. If a point table No. or position command data is set to the servo amplifier, a respond code indicating a normal or error result is set in RWn4 and RX (n + 2) 0 (Position command execution completion) turns on. Refer to section 2.1.6 for details.
RY (n + 2) 1	Speed command execution demand	Turning on RY (n + 2) 1 sets the point table No. or speed command data set in RWwnA and RWwnB. If a point table No. or speed command data is set to the servo amplifier, a respond code indicating a normal or error result is set in RWn4 and RX (n + 2) 1 (Position command execution completion) turns on. Refer to section 2.1.6 for details.
RY (n + 2) 7	Proportional control	Turn on RY (n + 2) 7 to switch the speed amplifier from the proportional integral type to the proportional type. If the servo motor at a stop is rotated even one pulse due to any external factor, it generates torque to compensate for a position shift. When the servo motor shaft is to be locked mechanically after RXnC (Travel completion) is turned off, switching on RY (n + 2) 7 (Proportional control) upon turning RXnC (Travel completion) off will suppress the unnecessary torque generated to compensate for a position shift. When the shaft is to be locked for a long time, turn on RY (n + 2) 7 (Proportional control) and make the torque less than the rated torque with the torque limit.
RY (n + 2) 8	Gain switching	Turn on RY (n + 2) 8 to use the values of [Pr. PB29] to [Pr. PB36] and [Pr. PB56] to [Pr. PB60] as the load to motor inertia ratio and gain values.
RY (n + 2) A	Position/speed specifying method selection	Select how to give a position command and speed command. Off: Specify a point table No. with RWwn6 (Point table No. selection) to give a position command and speed command. On: Set position command data and speed command data in RWwn8 to RWwnB to give a position command and speed command. To turn on RY (n + 2) A, set " _ _ _ 2" in [Pr. PT62].
RY (n + 2) B	Absolute value/incremental value selection	Select the command method of position data with RY (n + 2) B. RY (n + 2) B is enabled when the position/speed specifying method using remote registers is selected with RY (n + 2) A (Position/speed specifying method selection) and the absolute value command method is selected with [Pr. PT01]. Off: Position data is used as an absolute value. On: Position data is used as an incremental value.
RY (n + 3) A	Reset	Turn on RY (n + 3) A to reset alarms. However, some alarms cannot be cleared with RY (n + 3) A.

2. POINT TABLE OPERATION

(2) RXn profile

Device No.	Device	Description
RXn0	Ready	When the servo-on is on and the servo amplifier is ready to operate, RXn0 turns on.
RXn1	In-position	When the number of droop pulses is in the preset in-position range, RXn1 turns on. The in-position range can be changed with [Pr. PA10]. When the in-position range is increased, INP may be always on during low-speed rotation.
RXn2	Rough match	When a command remaining distance is lower than the rough match output range set with [Pr. PT12], RXn2 turns on. This is not outputted during base circuit shut-off.
RXn4	Limiting torque	RXn4 turns on when a generated torque reaches a value set with [Pr. PA11 Forward rotation torque limit] or [Pr. PA12 Reverse rotation torque limit].
RXn6	Electromagnetic brake interlock	When using the device, set operation delay time of the electromagnetic brake in [Pr. PC02]. When a servo-off status or alarm occurs, RXn6 turns off.
RXn7	During a temporary stop	When a deceleration begins for a stop, RXn7 turns on by RYn7 (Temporary stop/restart). When RYn7 (Temporary stop/restart) is enabled again and an operation is restarted, RXn7 turns off.
RXn8	Monitoring	Refer to RYn8 (Monitor output execution demand).
RXn9	Instruction code execution completion	Refer to RYn9 (Instruction code execution demand).
RXnA	Warning	When a warning occurs, RXnA turns on. When a warning is not occurring, turning on the power will turn off RXnA after 4 s to 5 s.
RXnB	Battery warning	RXnB turns on when [AL. 92 Battery cable disconnection warning] or [AL. 9F Battery warning] has occurred. When the battery warning is not occurring, turning on the power will turn off RXnB after 4 s to 5 s.
RXnC	Travel completion	When the droop pulses are within the in-position output range set with [Pr. PA10] and the command remaining distance is "0", RXnC turns on. When turning on RYn0 (servo-on), RXnC turns on at the same time.
RXnD	Dynamic brake interlock	RXnD turns off when the dynamic brake needs to operate.
RXnE	Position range output	When an actual current position is within the range set with [Pr. PT19] to [Pr. PT22], RXnE turns on. This will be off when a home position return is not completed or base circuit shut-off is in progress.
RX (n + 1) 0	Home position return completion 2	When a home position return completes normally, RX (n + 1) 0 turns on. RX (n + 1) 0 is always on unless the home position is erased. In the incremental system, it turns off with one of the following conditions. 1) [AL. 69 Command error] occurs. 2) Home position return is not being executed. 3) Home position return is in progress. If a home position return completes once in the absolute position detection system, RX (n + 1) 0 is always on. However, it will be off with one of the conditions 1) to 3) or the following conditions 4) to 8). 4) The home position return is not performed after [AL. 25 Absolute position erased] and [AL. E3 Absolute position counter warning] occurred. 5) The home position return is not performed after the electronic gear ([Pr. PA06] and [Pr. PA07]) was changed. 6) The home position return is not performed after the setting of [Pr. PA03 Absolute position detection system selection] was changed from "Disabled" to "Enabled". 7) [Pr. PA14 Rotation direction selection/travel direction selection] was changed. 8) [Pr. PA01 Operation mode] was changed.
RX (n + 1) 3	Under cam control	It turns on when the control switches to the cam control. It turns off when the control switches to the normal positioning control.
RX (n + 1) 4	Cam position compensation execution completed	It turns on when the control switches to the cam control. It turns off when the position compensation is executed during cam control. It turns on when the position compensation is complete.
RX (n + 1) 5	Clutch on/off status	It turns on with clutch-on. It is always off when [Cam control data No. 36 - Main shaft clutch control setting] is set to "___ 0".

2. POINT TABLE OPERATION

Device No.	Device	Description
RX (n + 1) 6	Clutch smoothing status	It outputs clutch smoothing status. The output depends on the setting in [Cam control data No. 42 - Main shaft clutch smoothing system] as follows: 0: Direct Always off 1: Time constant method (index) Always on in clutch-on status. It turns off when the clutch is off and the smoothing is complete.
RX (n + 2) 0	Position command execution completion	Refer to RY (n + 2) 0 (Position command execution demand).
RX (n + 2) 1	Speed command execution completion	Refer to RY (n + 2) 1 (Speed command execution demand).
RX (n + 3) A	Malfunction	When an alarm occurs, RX (n + 3) A will turn on. When an alarm is not occurring, turning on the power will turn off RX (n + 3) A after 4 s to 5 s.
RX (n + 3) B	Remote station communication ready	Turning on the power turns on RX (n + 3) B. When an alarm occurs, RX (n + 3) B will turn off.

2. POINT TABLE OPERATION

2.1.3 Detailed explanation of the RWwn/RWrn profile

(1) RWwn profile

Device No.	Device	Description	Setting range
RWwn0	Monitor 1	Setting a monitor code to monitor in RWwn0 and turning on RYn8 store data in RWrn0 and RWrn1. At this time, RXn8 turns on. Refer to section 2.1.4 (1) for monitor codes for status display.	Refer to section 2.1.4 (1).
RWwn2	Monitor 2	Setting a monitor code to monitor in RWwn2 and turning on RYn8 store data in RWrn2 and RWrn3. At this time, RXn8 turns on. Refer to section 2.1.4 (1) for monitor codes for status display.	Refer to section 2.1.4 (1).
RWwn4	Instruction code - Lower 16 bits	Set an instruction code No. used to read or write a parameter or point table data or to refer to an alarm. Setting an instruction code No. in RWwn4 and turning on RYn9 execute the instruction. RXn9 turns on after executing the instruction is completed. Refer to section 2.1.4 (2) for the instruction code No.	Refer to section 2.1.4 (2).
RWwn5	Instruction code - Upper 16 bits	When a value other than "0000h" is set in this device, the instruction code is not executed even if RYn9 is turned on and "_ 1 _" is set in Respond code.	0000h
RWwn6	Point table No. selection	Set a point table No. to execute in the automatic operation mode. To select the home position return mode, set "0" in RWwn6. Even if a value out of the setting range is set, an alarm or warning does not occur. However, the set value is invalid and the previous setting value is used.	0 to 255
RWwn8	Point table No./Position command data - Lower 16 bits	This function can be used while RY (n + 2) A (Position/speed specifying method selection) is on (the remote register-based position/speed specifying method is selected). (1) For the point table No. setting Setting a point table No. in RWwn8 and turning on RY (n + 2) 0 set the point table No. in the servo amplifier. After the setting is completed, RX (n + 2) 0 turns on. (2) For the position command data setting/point table No. (speed command) setting or for the position command data setting/speed command data setting Setting the lower 16 bits in RWwn8 and upper 16 bits in RWwn9 and turning on RY (n + 2) 0 write both the upper and lower 16 bits of the position command data. After the writing is completed, RX (n + 2) 0 turns on. Use [Pr. PT62] to select whether to set a point table No. or position command data. Refer to section 2.1.6 for details of the point table No. or position command data.	Point table No.: 1 to 255 Absolute value command: Position command data -999999 to 999999 Incremental value command: Position command data 0 to 999999
RWwn9	Position command data - Upper 16 bits		
RWwnA	Point table No./Speed command data - Lower 16 bits	This function can be used while RY (n + 2) A (Position/speed specifying method selection) is on (the remote register-based position/speed specifying method is selected). (1) For the point table No. setting or for the position command data setting/point table No. (speed command) setting Setting a point table No. in RWwnA and turning on RY (n + 2) 1 set the point table No. in the servo amplifier. After the setting is completed, RX (n + 2) 1 turns on. (2) For the position command data setting/speed command data setting Setting the lower 16 bits in RWwnA and upper 16 bits in RWwnB and turning on RY (n + 2) 1 write both the upper and lower 16 bits of the speed command data. After the writing is completed, RX (n + 2) 1 turns on. Use [Pr. PT62] to select whether to set a point table No. or speed command data. Refer to section 2.1.6 for details of the point table No. or speed command data. When setting a servo motor speed in this remote register, always set an acceleration time constant and deceleration time constant in the point table No. 1.	Point table No.: 1 to 255 Speed command data: 0 to permissible speed
RWwnB	Speed command data - Upper 16 bits		

2. POINT TABLE OPERATION

Device No.	Device	Description	Setting range
RWwnC	Writing data - Lower 16 bits	Set writing data used to write a parameter or point table data or to clear the alarm history. Setting writing data in RWwnC and RWwnD and turning on RYn9 write the data to the servo amplifier. When the writing is completed, RXn9 turns on. Refer to section 2.1.4 (2) (b) for writing data.	Refer to section 2.1.4 (2) (b).
RWwnD	Writing data - Upper 16 bits		
RWwnE	Cam No. setting	Select cam No. This is enabled when [Cam control data No. 49 - Cam No.] is set to "0". Set the cam control data on the cam setting window of MR Configurator2.	0 to 8

(2) RWrn profile

Device No.	Device	Description	Setting range
RWrn0	Monitor 1 data - Lower 16 bits	The lower 16 bits of the data corresponding to the monitor code set in RWwn0 is stored.	
RWrn1	Monitor 1 data - Upper 16 bits	The upper 16 bits of the data corresponding to the monitor code set in RWwn0 is stored. A sign is set if no data is set in the upper 16 bits.	
RWrn2	Monitor 2 data - Lower 16 bits	The lower 16 bits of the data corresponding to the monitor code set in RWwn2 is stored.	
RWrn3	Monitor 2 data - Upper 16 bits	The upper 16 bits of the data corresponding to the monitor code set in RWwn2 is stored. A sign is set if no data is set in the upper 16 bits.	
RWrn4	Respond code	When the codes set in RWwn0 to RWwnD have been executed normally, "0000" is set.	
RWrn6	Point table No. output	The point table No. is set when RXnC (Travel completion) turns on. In the following condition, "0" is set in RWrn6. <ul style="list-style-type: none"> • Power on • Servo-off • During home position return • Home position return completion RWrn6 will keep a previous condition in the following conditions. <ul style="list-style-type: none"> • At operation mode change • When an operation mode was switched by turning RYn6 (Automatic/manual selection) off to on or on to off. • During manual operation • Automatic positioning to home position is in progress. 	
RWrnC	Reading data - Lower 16 bits	Data corresponding to the reading code set in RWwn4 is set.	
RWrnD	Reading data - Upper 16 bits		
RWrnE	Cam No. during control	When cam control is being executed, the cam No. currently being executed is set. When cam control is not being executed, the previously executed cam No. is set.	

2. POINT TABLE OPERATION

2.1.4 Code

(1) Monitor code

Use any of the instruction codes 0100h to 011Fh to read the decimal point position (multiplying factor) of the status display.

Setting any code No. that is not given in this section sets an error code (_ _ _ 1) in Respond code (RWrn4). At this time, "0000" is set in RWrn0 to RWrn3.

Code No.	Monitored item	Response data (Servo amplifier → Master station)	
		Data length	Unit
0000h			
0001h	Current position	32 bits	10^{STM} [μm]/ $10^{(\text{STM}-4)}$ [inch]/[pulse] (Note 1)
0002h			
0003h	Command position	32 bits	10^{STM} [μm]/ $10^{(\text{STM}-4)}$ [inch]/[pulse] (Note 1)
0004h			
0005h	Command remaining distance	32 bits	10^{STM} [μm]/ $10^{(\text{STM}-4)}$ [inch]/[pulse] (Note 1)
0006h			
0007h			
0008h	Point table No.	16 bits	
0009h			
000Ah	Cumulative feedback pulses	32 bits	[pulse]
000Bh			
000Ch			
000Dh			
000Eh	Droop pulses	32 bits	[pulse]
000Fh			
0010h			
0011h	Regenerative load ratio	16 bits	[%]
0012h	Effective load ratio	16 bits	[%]
0013h	Peak load ratio	16 bits	[%]
0014h	Instantaneous torque	16 bits	[%]
0015h	ABS counter	16 bits	[rev]
0016h	Servo motor speed	32 bits	0.01 [r/min]/0.01 [mm/s]
0017h			
0018h	Bus voltage	16 bits	[V]
0019h	ABS position - Lower 32 bits	32 bits	[pulse]
001Ah			
001Bh	ABS position - Upper 32 bits	32 bits	[pulse]
001Ch	Position within one-revolution	32 bits	[pulse]
001Dh			
001Eh			
001Fh			
0020h	Cam axis one cycle current value	32 bits	10^{STM} [μm]/ $10^{(\text{STM}-4)}$ [inch]/[pulse] (Note 2)
0021h	Cam standard position	32 bits	10^{STM} [μm]/ $10^{(\text{STM}-4)}$ [inch]/[pulse] (Note 2)
0022h	Cam axis feed current value	32 bits	10^{STM} [μm]/ $10^{(\text{STM}-4)}$ [inch]/[pulse] (Note 2)
0024h	Cam stroke amount in execution	32 bits	10^{STM} [μm]/ $10^{(\text{STM}-4)}$ [inch]/[pulse] (Note 2)
0025h	Main axis current value	32 bits	10^{STM} [μm]/ $10^{(\text{STM}-4)}$ [inch]/[pulse] (Note 2)
0026h	Main axis one cycle current value	32 bits	10^{STM} [μm]/ $10^{(\text{STM}-4)}$ [inch]/[pulse] (Note 2)

2. POINT TABLE OPERATION

- Note
1. The unit can be changed to 10^{STM} [μm], $10^{(\text{STM}-4)}$ [inch], or [pulse] with the setting of [Pr. PT01].
 2. Depending on the setting of [Cam control data No. 30 Main shaft input axis selection], the parameters used to set the unit and feed length multiplication will change as follows. For details of each parameter, refer to section 3.2.4 and 6.1.7 (3).

Setting of [Cam control data No. 30]	Parameter for the unit setting	Parameter for the feed length multiplication setting
"0" or "1"	[Pr. PT01]	[Pr. PT03]
"2"	[Cam control data No. 14]	[Cam control data No. 14]

(2) Instruction code

Refer to section 2.1.5 (2) for the timing charts of the instruction codes.



(a) Reading instruction code

The data requested to be read with the instruction codes 0000h to 0AFFh is stored in reading data (RWrnC and RWrnD).

Set the instruction code No. corresponding to the item in RWwn4 and RWwn5. The instruction code No. and response data are all hexadecimal.

Setting any instruction code No. which is not given in this section stores an error code (_ _ 1 _) in respond code (RWrn4). If any unusable parameter or point table is read, an error code (_ _ 2 _) is stored. At this time, "0000" is stored in reading data (RWrnC and RWrnD).

2. POINT TABLE OPERATION

Code No.		Item/function	Reading data content (Servo amplifier → Master station)	
RWwn5	RWwn4		RWrnC	RWrdD
0000h	0000h	Operation mode Reads the current operation mode.	0000: CC-Link IE operation mode 0001: Test operation mode	Always 0
0000h	0002h	Travel distance multiplying factor Reads the multiplying factor of the position data in the point table set with [Pr. PT03].	0000: × 1 0100: × 10 0200: × 100 0300: × 1000	Always 0
0000h	0010h	Current alarm (warning) reading Reads the alarm No. or warning No. that is currently occurring.		Always 0
0000h	0020h	Alarm number in alarm history (latest alarm)		Always 0
0000h	0021h	Alarm number in alarm history (one alarm ago)		
0000h	0022h	Alarm number in alarm history (two alarms ago)		
0000h	0023h	Alarm number in alarm history (three alarms ago)		
0000h	0024h	Alarm number in alarm history (four alarms ago)		
0000h	0025h	Alarm number in alarm history (five alarms ago)		
0000h	0026h	Alarm number in alarm history (six alarms ago)		
0000h	0027h	Alarm number in alarm history (seven alarms ago)		
0000h	0028h	Alarm number in alarm history (eight alarms ago)		
0000h	0029h	Alarm number in alarm history (nine alarms ago)		
0000h	002Ah	Alarm number in alarm history (ten alarms ago)		
0000h	002Bh	Alarm number in alarm history (eleven alarms ago)		
0000h	002Ch	Alarm number in alarm history (twelve alarms ago)		
0000h	002Dh	Alarm number in alarm history (thirteen alarms ago)		
0000h	002Eh	Alarm number in alarm history (fourteen alarms ago)		
0000h	002Fh	Alarm number in alarm history (fifteen alarms ago)		



2. POINT TABLE OPERATION

Code No.		Item/function	Reading data content (Servo amplifier → Master station)	
RWwn5	RWwn4		RWnrc	RWnrd
0000h	0030h	Alarm occurrence time in alarm history (latest alarm)	Returns the occurrence time of the alarm that occurred before.	Always 0
0000h	0031h	Alarm occurrence time in alarm history (one alarm ago)		
0000h	0032h	Alarm occurrence time in alarm history (two alarms ago)		
0000h	0033h	Alarm occurrence time in alarm history (three alarms ago)		
0000h	0034h	Alarm occurrence time in alarm history (four alarms ago)		
0000h	0035h	Alarm occurrence time in alarm history (five alarms ago)		
0000h	0036h	Alarm occurrence time in alarm history (six alarms ago)		
0000h	0037h	Alarm occurrence time in alarm history (seven alarms ago)		
0000h	0038h	Alarm occurrence time in alarm history (eight alarms ago)		
0000h	0039h	Alarm occurrence time in alarm history (nine alarms ago)		
0000h	003Ah	Alarm occurrence time in alarm history (ten alarms ago)		
0000h	003Bh	Alarm occurrence time in alarm history (eleven alarms ago)		
0000h	003Ch	Alarm occurrence time in alarm history (twelve alarms ago)		
0000h	003Dh	Alarm occurrence time in alarm history (thirteen alarms ago)		
0000h	003Eh	Alarm occurrence time in alarm history (fourteen alarms ago)		
0000h	003Fh	Alarm occurrence time in alarm history (fifteen alarms ago)		
0000h	0040h	Input device status 0 Reads the status (OFF/ON) of input devices.	Bit 0 to bit F indicate the OFF/ON status of the corresponding input devices. 0: Servo-on 1: Forward rotation start 2: Reverse rotation start 3: Proximity dog 4, 5: For manufacturer setting 6: Automatic/manual selection 7: Temporary stop/restart 8: Monitor output execution demand 9: Instruction code execution demand A to F: For manufacturer setting	Always 0

2. POINT TABLE OPERATION

Code No.		Item/function	Reading data content (Servo amplifier → Master station)	
RWwn5	RWwn4		RWrnC	RWrnD
0000h	0041h	Input device status 1 Reads the status (OFF/ON) of input devices.	Bit 0 to bit F indicate the OFF/ON status of the corresponding input devices. 0: Upper stroke limit (Note) 1: Lower stroke limit (Note) 2: Operation alarm reset 3: Cam control command 4: For manufacturer setting 5: Clutch command 6 to F: For manufacturer setting Note. Servo amplifiers with software version A2 or earlier indicate the state of input (RY (n + 1) 0/R Y (n + 1) 1) from the controller regardless of the setting value for the [Pr. PD41 Sensor input method selection]. By setting [Pr. PD41], servo amplifiers with software version A3 or later can switch between indicating the state of input (LSP/LSN) from the servo amplifier and input (RY (n + 1) 0/R Y (n + 1) 1) from the controller. When [Pr. PD41] is the initial value, the state of input to the servo amplifier is indicated. When it is set to input to the servo amplifier, bit 0 and bit 1 of setting value [Pr. PA14 Rotation direction selection/travel direction selection] are interchanged.	Always 0
0000h	0042h	Input device status 2 Reads the status (OFF/ON) of input devices.	Bit 0 to bit F indicate the OFF/ON status of the corresponding input devices. 0: Position command execution demand 1: Speed command execution demand 2 to 5: For manufacturer setting 6: Internal torque limit selection 7: Proportional control 8: Gain switching 9: For manufacturer setting A: Position/speed specifying method selection B: Absolute value/incremental value selection C to F: For manufacturer setting	Always 0
0000h	0043h	Input device status 3 Reads the status (OFF/ON) of input devices.	Bit 0 to bit F indicate the OFF/ON status of the corresponding input devices. 0 to 9: For manufacturer setting A: Reset B to F: For manufacturer setting	Always 0
0000h	0081h	Energization time Reads the energization time since shipment.	Returns the energization time [h].	Always 0
0000h	0082h	Power on frequency Reads the number of power-on times since shipment.	Returns the number of power-on times.	Always 0
0000h	00A0h	Load to motor inertia ratio Reads the estimated load to motor inertia ratio on the servo motor shaft.	Return unit [0.01 times] Returns the estimated load to motor inertia ratio.	Always 0

2. POINT TABLE OPERATION

Code No.		Item/function	Reading data content (Servo amplifier → Master station)	
RWwn5	RWwn4		RWrnC	RWrnD
0000h	00B0h	Home position within one-revolution (CYC0) Reads the cycle counter value of an absolute home position.	Return unit [pulse] Stores the lower 16 bits of the cycle counter value of the absolute home position (32-bit data).	Stores the upper 16 bits of the cycle counter value of the absolute home position.
0000h	00B2h	Home position multi-revolution data (ABS0) Reads the multi-revolution counter value of an absolute home position.	Return unit [rev] Returns the multi-revolution counter value.	Always 0
0000h	00C0h	Error parameter No./Point data No. reading Reads the parameter No. and point table No. that have an error.	 <p>Parameter No. or point table No.</p> <p>Parameter group</p> <p>0: [Pr. PA _ _] 1: [Pr. PB _ _] 2: [Pr. PC _ _] 3: [Pr. PD _ _] 4: [Pr. PE _ _] 5: [Pr. PF _ _] 6 to A: For manufacturer setting B: [Pr. PL _ _] C: [Pr. PT _ _] E: [Pr. PN _ _]</p> <p>Type</p> <p>1: Parameter 2: Point table</p>	Always 0
0000h	0100h to 011Fh	Monitor multiplying factor Reads the multiplying factor of data to be read with a monitor code. The instruction codes 0100h to 011Fh correspond to each of the monitor codes 0000h to 001Fh. To the instruction code that has no corresponding monitor code, "0000h" is applied.	0000: × 1 0001: × 10 0002: × 100 0003: × 1000	Always 0
0000h	0200h	Parameter group reading Reads the parameter group written with the code No. 8200h.	 <p>Parameter group</p> <p>0: [Pr. PA _ _] 1: [Pr. PB _ _] 2: [Pr. PC _ _] 3: [Pr. PD _ _] 4: [Pr. PE _ _] 5: [Pr. PF _ _] 6 to A: For manufacturer setting B: [Pr. PL _ _] C: [Pr. PT _ _] E: [Pr. PN _ _]</p>	Always 0

2. POINT TABLE OPERATION

Code No.		Item/function	Reading data content (Servo amplifier → Master station)	
RWwn5	RWwn4		RWnrc	RWnrd
0000h	0201h to 02FFh	Parameter data reading Reads the setting values of the parameters in the group read with the code No. 0200h. The lower two digits of the code No. which are converted to decimal correspond to the parameter No.	Stores the lower 16 bits of the setting value of the requested parameter No.	Stores the upper 16 bits of the setting value of the requested parameter No.
0000h	0301h to 03FFh	Data form of parameter Reads the data form of the setting values of the parameters in the group read with the code No. 0200h. The lower two digits of the code No. which are converted to decimal correspond to the parameter No.	Stores the data form of the requested parameter No. <div data-bbox="734 533 917 582"> <div>0</div> <div></div> <div></div> <div></div> </div> <div data-bbox="917 604 1220 1019"> <p>Decimal point position 0: No decimal point 1: First least significant digit (no decimal point) 2: Second least significant digit 3: Third least significant digit 4: Forth least significant digit</p> <p>Data form 0: Data is used unchanged in hexadecimal. 1: Data must be converted into decimal.</p> <p>Parameter writing type 0: Enabled after writing 1: Enabled when power is cycled after writing 2: Enabled when the controller is reset</p> </div>	Always 0
0000h	0401h to 04FFh	Position data of point table No. 1 to 255 Reads the position data of point table No. 1 to 255.	Stores the lower 16 bits of the position data of the requested point table No.	Stores the upper 16 bits of the position data of the requested point table No.
0000h	0601h to 06FFh	Servo motor speed of point table No. 1 to 255 The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Stores the lower 16 bits of the servo motor speed of the requested point table No.	Stores the upper 16 bits of the servo motor speed of the requested point table No.
0000h	0701h to 07FFh	Acceleration time constant of point table No. 1 to 255 The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Stores the acceleration time constant of the requested point table No.	Always 0
0000h	0801h to 08FFh	Deceleration time constant of point table No. 1 to 255 The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Stores the deceleration time constant of the requested point table No.	Always 0
0000h	0901h to 09FFh	Dwell of point table No. 1 to 255 The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Stores the dwell of the requested point table No.	Always 0
0000h	0A01h to 0AFFh	Auxiliary function of point table No. 1 to 255 The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Stores the sub functions of the requested point table No.	Always 0

2. POINT TABLE OPERATION

(b) Writing instruction code

Data requested to be written with the instruction codes 8000h to 91FFh is written to the servo amplifier.

Set the instruction code No. corresponding to the item in instruction code (RWwn4 and RWwn5) and the data to be written in writing data (RWwnC and RWwnD). The instruction code No. and response data are all hexadecimal.

Setting any instruction code No. which is not given in this section will store an error code (_ _ 1 _) in respond code (RWrn4).

Code No.		Item	Writing data contents (Master station → Servo amplifier)	
RWwn5	RWwn4		RWwnC	RWwnD
0000h	8010h	Alarm reset command Clears the alarm that is currently occurring.	1EA5	Do not write data.
0000h	8101h	Feedback pulse value display data clear command Resets the display data of the status display "Cumulative feedback pulses" to "0".	1EA5	Do not write data.
0000h	8200h	Writing command of parameter group Writes the group of the parameter to write with code No. 8201h to 82FFh and 8301h to 83FFh. Writes the group of the parameter to read with code No. 0201h to 02FFh and 0301h to 03FFh.	<div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-right: 10px;">0</div> <div style="border: 1px solid black; padding: 2px; margin-right: 10px;">0</div> <div style="border: 1px solid black; padding: 2px; margin-right: 10px;">0</div> <div style="border: 1px solid black; padding: 2px; margin-right: 10px;"> </div> <div style="border: 1px solid black; padding: 2px; margin-right: 10px;"> </div> </div> <div style="margin-left: 20px;"> Parameter group 0: [Pr. PA _ _] 1: [Pr. PB _ _] 2: [Pr. PC _ _] 3: [Pr. PD _ _] 4: [Pr. PE _ _] 5: [Pr. PF _ _] 6 to A: For manufacturer setting B: [Pr. PL _ _] C: [Pr. PT _ _] E: [Pr. PN _ _] </div>	Do not write data.
0000h	8201h to 82FFh	Data RAM command of parameter Writes the setting values of the parameters in the group written with code No. 8200h to the RAM. This setting value is cleared when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the parameter No. An error code is returned if a value outside the range of a parameter is written.	Set the lower 16 bits of the parameter setting value.	Set the upper 16 bits of the parameter setting value. For 16-bit parameters, this setting is not required.
0000h	8301h to 83FFh	Data EEPROM command of parameter Writes the setting values of the parameters in the group written with code No. 8200h to the EEPROM. The setting value written in the EEPROM is held even when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the parameter No. An error code is returned if a value outside the range of a parameter is written.	Set the lower 16 bits of the parameter setting value.	Set the upper 16 bits of the parameter setting value. For 16-bit parameters, this setting is not required.

2. POINT TABLE OPERATION

Code No.		Item	Writing data contents (Master station → Servo amplifier)	
RWwn5	RWwn4		RWwnC	RWwnD
0000h	8401h to 84FFh	Position data RAM command of point table Writes the position data of point table No. 1 to 255 to the RAM. This setting value is cleared when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Set the lower 16 bits of the position data.	Set the upper 16 bits of the position data.
0000h	8601h to 86FFh	Servo motor speed data RAM command of point table Writes the servo motor speed of point table No. 1 to 255 to the RAM. This setting value is cleared when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Set the lower 16 bits of the servo motor speed.	Set the upper 16 bits of the servo motor speed.
0000h	8701h to 87FFh	Acceleration time constant data RAM command of point table Writes the acceleration time constant of point table No. 1 to 255 to the RAM. This setting value is cleared when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Set the acceleration time constant.	Do not write data.
0000h	8801h to 88FFh	Deceleration time constant data RAM command of point table Writes the deceleration time constant of point table No. 1 to 255 to the RAM. This setting value is cleared when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Set the deceleration time constant.	Do not write data.
0000h	8901h to 89FFh	Dwell data RAM command of point table Writes the dwell of point table No. 1 to 255 to the RAM. This setting value is cleared when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Set the dwell.	Do not write data.
0000h	8A01h to 8AFFh	Auxiliary function data RAM command of point table Writes the auxiliary functions of point table No. 1 to 255 to the RAM. This setting value is cleared when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Set the auxiliary function.	Do not write data.

2. POINT TABLE OPERATION


Code No.		Item	Writing data contents (Master station → Servo amplifier)	
RWwn5	RWwn4		RWwnC	RWwnD
0000h	8B01h to 8BFFh	Position data EEPROM command of point table Writes the position data of point table No. 1 to 255 to the EEPROM. The setting value written in the EEPROM is held even when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Set the lower 16 bits of the position data.	Set the upper 16 bits of the position data.
0000h	8D01h to 8DFFh	Servo motor speed data EEPROM command of point table Writes the servo motor speed of point table No. 1 to 255 to the EEPROM. The setting value written in the EEPROM is held even when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Set the lower 16 bits of the servo motor speed.	Set the upper 16 bits of the servo motor speed.
0000h	8E01h to 8EFFh	Acceleration time constant data EEPROM command of point table Writes the acceleration time constant of point table No. 1 to 255 to the EEPROM. The setting value written in the EEPROM is held even when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Set the acceleration time constant.	Do not write data.
0000h	8F01h to 8FFFh	Deceleration time constant data EEPROM command of point table Writes the deceleration time constants of point table No. 1 to 255 to the EEPROM. The setting value written in the EEPROM is held even when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Set the deceleration time constant.	Do not write data.
0000h	9001h to 90FFh	Dwell data EEPROM command of point table Writes the dwell of point table No. 1 to 255 to the EEPROM. The setting value written in the EEPROM is held even when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Set the dwell.	Do not write data.
0000h	9101h to 91FFh	Auxiliary function data EEPROM command of point table Writes the auxiliary functions of point table No. 1 to 255 to the EEPROM. The setting value written in the EEPROM is held even when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Set the auxiliary function.	Do not write data.

2. POINT TABLE OPERATION

Code No.		Item	Writing data contents (Master station → Servo amplifier)	
RWwn5	RWwn4		RWwnC	RWwnD
A02Dh	8400h	Cam axis one cycle length setting RAM writing	Set the lower-order 16 bits for the cam axis one cycle length.	Set the upper-order 16 bits for the cam axis one cycle length.
A02Dh	8500h	Cam stroke amount setting RAM writing	Set the lower-order 16 bits for the cam stroke amount.	Set the upper-order 16 bits for the cam stroke amount.

(3) Respond code (RWrn4)

If any of monitor codes, instruction codes, point table No. selection, point table No./position command data, and point table No./speed command data set in remote registers is outside the setting range, the corresponding error code is set in respond code (RWrn4). If the setting is within the setting range, "0000" is set.



Error of the monitor code

Code No.	Error detail	Details
0	Normal result	The code has been completed normally.
1	Code error	An incorrect code No. is specified.
2		
3		

Error of the reading instruction code and writing instruction code

Code No.	Error detail	Details
0	Normal result	The instruction has been completed normally.
1	Code error	An incorrect code No. is specified.
2	Parameter selection error	A parameter No. that cannot be referred to is specified.
3	Writing data out of range	A value out of the range is set.

Error of the point table No./position command data

Code No.	Error detail	Details
0	Normal result	The instruction has been completed normally.
1		
2		
3	Writing data out of range	A value out of the range is set.


Error of the point table No./speed command data

Code No.	Error detail	Details
0	Normal result	The instruction has been completed normally.
1		
2		
3	Writing data out of range	A value out of the range is set.

2. POINT TABLE OPERATION

2.1.5 Data communication timing chart

(1) Monitor code



Set a monitor code (refer to section 2.1.4 (1)) in RWwn0 (Monitor 1) and RWwn2 (Monitor 2) and turn on RYn8 (Monitor output execution demand). Turning on RYn8 (Monitor output execution demand) sets the following data. All 32-bit data is set in remote registers after divided into the upper 16 bits and lower 16 bits Data is all hexadecimal. At this time, RXn8 (Monitoring) turns on.

RWrn0 (Monitor 1 data - Lower 16 bits): Lower 16 bits of data requested with RWwn0 (Monitor 1)
 RWrn1 (Monitor 1 data - Upper 16 bits): Upper 16 bits of data requested with RWwn0 (Monitor 1)
 RWrn2 (Monitor 2 data - Lower 16 bits): Lower 16 bits of data requested with RWwn2 (Monitor 2)
 RWrn3 (Monitor 2 data - Upper 16 bits): Upper 16 bits of data requested with RWwn2 (Monitor 2)

A sign is set if no data is set in RWrn1 or RWrn3. For "+", "0000" is set, and "FFFF" is set for "-". Monitor data RWrn0 to RWrn3 set in remote registers are constantly updated while RXn8 (Monitoring) is ON.

When RXn8 (Monitoring) turns off, the update of the monitor data RWrn0 to RWrn3 stops, and does not restart until RXn8 (Monitoring) turns on again.


If a monitor code out of the specifications is set in either RWwn0 (Monitor 1) or RWwn2 (Monitor 2), the corresponding error code (_ _ _ 1) is stored in RWrn4 (Respond code). At this time, "0000" is stored in the monitor data RWrn0 to RWrn3. Refer to section 2.1.4 (3) for details of respond code.

Until RXn8 turns on after RYn8 is turned on, do not change the setting values of RWwn0 and RWwn2.

2. POINT TABLE OPERATION

(2) Instruction code

(a) Reading instruction code (0000h to 0AFFh)



Note. The value of RWwn5 (Instruction code - Upper 16 bits) is fixed to "0".

Set a reading instruction code (refer to section 2.1.4 (2) (a)) in RWwn4 (Instruction code - Lower 16 bits) and turn on RYn9 (Instruction code execution demand). Turning on RYn9 (Instruction code execution demand) sets the data corresponding to the reading code in RWrnC (Reading data - Lower 16 bits) and RWrnD (Reading data - Upper 16 bits). Data is all hexadecimal. At this time, RXn9 (Instruction code execution completion) also turns on. Read the reading data to be set in RWrnC (Reading data - Lower 16 bits) and RWrnD (Reading data - Upper 16 bits) while RYn9 (Instruction code execution demand) is on. The data set in RWrnC (Reading data - Lower 16 bits) and RWrnD (Reading data - Upper 16 bits) is held until RYn9 (Instruction code execution demand) is turned on with the next reading instruction code set.


If the instruction code out of the specifications is set in RWwn4 (Instruction code - Lower 16 bits), an error code (_ _ 1 _) is set in respond code. If any unusable parameter or point table is read, an error code (_ _ 2 _) is set.

Turn off RYn9 (Instruction code execution demand) after the data reading is completed.

Until RXn9 turns on after RYn9 is turned on, do not change the setting value of RWwn4. Turn off RYn9 after the data reading is completed.

2. POINT TABLE OPERATION

(b) Writing instruction code (8000h to 91FFh)



Note. The value of RWwn5 (Instruction code - Upper 16 bits) is fixed to "0".

Set a writing instruction code (refer to section 2.1.4 (2) (b)) in RWwn4 (Instruction code - Lower 16 bits) and the data to write (data to execute) in RWwnC (Writing data - Lower 16 bits) and RWwnD (Writing data - Upper 16 bits) in hexadecimal, and turn on RYn9 (Instruction code execution demand).

Turning on RYn9 (Instruction code execution demand) writes the data set with RWwnC (Writing data - Lower 16 bits) and RWwnD (Writing data - Upper 16 bits) to the item corresponding to the writing instruction code. After the writing is completed, RXn9 (Instruction code execution completion) turns on.

If the instruction code out of the specifications is set in RWwn4 (Instruction code - Lower 16 bits), an error code (_ _ 1 _) is set in respond code.

Turn off RYn9 (Instruction code execution demand) after RXn9 (Instruction code execution completion) has turned on.


Until RXn9 turns on after RYn9 is turned on, do not change the setting values of RWwn4, RWwnC, and RWwnD. Turn off RYn9 while RXn9 is on.

2. POINT TABLE OPERATION

(2) For the position command data setting and point table No. (speed command) setting

Specify a position address with a remote register, and specify speed command data with a point table No. Then, execute positioning using the servo motor speed, acceleration time constant, and deceleration time constant.

Before executing positioning, set "___ 1" in [Pr. PT62] to enable the operation that follows the settings of the position command data and point table No. (speed command).



Note. This data is stored in the RAM of the servo amplifier. Thus, the data is cleared when the power supply is shut off.

Set the lower 16 bits of the position command data in RWwn8 (Position command data - Lower 16 bits), the upper 16 bits of the position command data in RWwn9 (Position command data - Upper 16 bits). Set the point table No. for the speed command in RWwnA (Point table No.), and then turn on RY (n + 2) 0 (Position command execution demand) and RY (n + 2) 1 (Speed command execution demand). Turning on RY (n + 2) 0 and RY (n + 2) 1 stores the position command data and point table No. into the RAM of the servo amplifier.

When the data is stored, RX (n + 2) 0 (Position command execution completion) and RX (n + 2) 1 (Speed command execution completion) turn on.

Until RX (n + 2) 0 and RX (n + 2) 1 turn on after RY (n + 2) 0 and RY (n + 2) 1 are turned on, do not change the settings of the position data and point table No.

If data outside the setting range is set in RWwn8 (Position command data - Lower 16 bits), RWwn9 (Position command data - Upper 16 bits), or RWwnA (Point table No.), an error code (refer to section 2.1.4 (3)) is set in respond code.


Turn on RYn1 (Forward rotation start) or RYn2 (Reverse rotation start) after RX (n + 2) 0 (Position command execution completion) and RX (n + 2) 1 (Speed command execution completion) have turned on.

2. POINT TABLE OPERATION

(3) For the position command data setting and speed command data setting

Specify a position address and servo motor speed with remote registers, and execute positioning. At this time, the acceleration time constant and deceleration time constant set in point table No. 1 are used.

Before executing positioning, set "___2" in [Pr. PT62] to enable the operation that follows the settings of the position command data and speed command data.



Note. This data is stored in the RAM of the servo amplifier. Thus, the data is cleared when the power supply is shut off.

Set the lower 16 bits of the position command data in RWwn8 (Position command data - Lower 16 bits), the upper 16 bits of the position command data in RWwn9 (Position command data - Upper 16 bits). Set the speed instruction data in RWwnA (Speed command data), and then turn on RY(n+2)0 (Position command execution demand) and RY(n+2)1 (Speed command execution demand).

Turning on RY(n+2)0 and RY(n+2)1 stores the position command data and speed command data into the RAM of the servo amplifier.

When the data is stored, RX(n+2)0 (Position command execution completion) and RX(n+2)1 (Speed command execution completion) turn on.

If data outside the setting range is set in RWwn8 (Position command data - Lower 16 bits), RWwn9 (Position command data - Upper 16 bits), or RWwnA (Point table No.), an error code (refer to section 2.1.4 (3)) is set in respond code.

Turn on RYn1 (Forward rotation start) or RYn2 (Reverse rotation start) after RX(n+2)0 (Position command execution completion) and RX(n+2)1 (Speed command execution completion) have turned on.


2. POINT TABLE OPERATION

2.2 Switching power on for the first time


POINT
●To use the servo amplifier in the I/O mode, set [Pr. PN03] to " _ _ _ 1". In addition, the GX Works setting is required. For the GX Works setting, refer to section 4.1.4 (2) of "MR-J4-_GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)".

When switching the power on for the first time, follow this section to make a startup.

Startup procedure



2. POINT TABLE OPERATION



2. POINT TABLE OPERATION

2.3 Automatic operation mode

2.3.1 Automatic operation mode


(1) Command method

Set point tables in advance, and select any point table by using CC-Link IE Field Network communication. Start the operation using RYn1 (Forward rotation start) or RYn2 (Reverse rotation start). Absolute value command method and incremental value command method are provided in automatic operation mode.

(a) Absolute value command method

As position data, set the target address to be reached.


Setting range: -999999 to 999999 [$\times 10^{\text{STM}}$ μm] (STM = Feed length multiplication [Pr. PT03])
-999999 to 999999 [$\times 10^{(\text{STM}-4)}$ inch] (STM = Feed length multiplication [Pr. PT03])
-999999 to 999999 [pulse]



(b) Incremental value command method

As position data, set the travel distance from the current address to the target address.

Setting range: 0 to 999999 [$\times 10^{\text{STM}}$ μm] (STM = Feed length multiplication [Pr. PT03])
0 to 999999 [$\times 10^{(\text{STM}-4)}$ inch] (STM = Feed length multiplication [Pr. PT03])
0 to 999999 [pulse]



2. POINT TABLE OPERATION

2.3.2 Automatic operation using point table

(1) Absolute value command method

By the auxiliary function of the point table, you can set a point table used under the absolute value command method or the incremental value command method.

(a) Point table

Set the point table values using MR Configurator2 or link devices.

Set the position data, servo motor speed, acceleration time constant, deceleration time constant, dwell and auxiliary function to the point table.

To use the point table under the absolute value command method, set "0", "1", "8", or "9" to the auxiliary function. To use the point table under the incremental value command method, set "2", "3", "10", or "11" to the auxiliary function.

When you set a value outside this range to the point table, the set value will be clamped with the maximum or minimum value. When changing the command unit or the connected motor results in the set value outside this range, [AL. 37] will occur.

Item	Setting range	Unit	Description
Position data	-999999 to 999999 (Note 1)	$\times 10^{\text{STM}}$ μm $\times 10^{(\text{STM}-4)}$ inch pulse	(1) When using this point table under the absolute value command method Set the target address (absolute value). (2) When using this point table under the incremental value command method Set the travel distance. A "-" sign indicates a reverse rotation command.
Servo motor speed	0 to permissible speed	r/min mm/s (Note 2)	Set the command speed of the servo motor for execution of positioning. The setting value must be within the permissible instantaneous speed of the servo motor used. If a value smaller than "1" is set for the servo motor speed, the servo motor may not rotate.
Acceleration time constant	0 to 20000	ms	Set a time until the servo motor rotates at the rated speed.
Deceleration time constant	0 to 20000	ms	Set a time from when the servo motor rotates at the rated speed until when the motor stops.
Dwell	0 to 20000	ms	Set the dwell. To disable the dwell, set "0" or "2" to the auxiliary function. To perform continuous operation, set "1", "3", "8", "9", "10" or "11" to the auxiliary function and 0 to the dwell. When the dwell is set, the position command of the selected point table is completed, and after the set dwell has elapsed, the position command of the next point table is started.

2. POINT TABLE OPERATION

Item	Setting range	Unit	Description
Auxiliary function	0 to 3, 8 to 11		<p>Set the auxiliary function.</p> <p>(1) When using this point table under the absolute value command method</p> <p>0: Automatic operation is performed in accordance with a single point table selected.</p> <p>1: Automatic continuous operation is performed to the next point table without a stop.</p> <p>8: Automatic continuous operation is performed without a stop to the point table selected at start-up.</p> <p>9: Automatic continuous operation is performed without stopping a point table No. 1.</p> <p>(2) When using this point table under the incremental value command method</p> <p>2: Automatic operation is performed in accordance with a single point table selected.</p> <p>3: Automatic continuous operation is performed to the next point table without a stop.</p> <p>10: Automatic continuous operation is performed to the point table selected at start-up.</p> <p>11: Automatic continuous operation is performed without stopping a point table No. 1.</p> <p>When a different rotation direction is set, smoothing zero (command output) is confirmed and then the rotation direction is reversed.</p> <p>Setting "1" or "3" to point table No. 255 results in an error.</p> <p>Refer to (3) (b) in this section.</p>

Note 1. When the unit of the position data is μm or inch, the location of the decimal point is changed according to the STM setting.
2. The unit will be "mm/s" in the linear servo motor control mode.

(b) Parameter setting

Set the following parameters to perform automatic operation.

1) Command method selection ([Pr. PT01])


Select the absolute value command method as shown below.



2) Rotation direction selection ([Pr. PA14])

Select the servo motor rotation direction when RYn1 (Forward rotation start) is switched on.

[Pr. PA14] setting	Servo motor rotation direction when RYn1 (Forward rotation start) is switched on
0	CCW rotation with + position data CW rotation with - position data
1	CW rotation with + position data CCW rotation with - position data



2. POINT TABLE OPERATION

3) Position data unit ([Pr. PT01])

Set the unit of the position data.

[Pr. PT01] setting	Position data unit
_ 0 _	mm
_ 1 _	inch
_ 3 _	pulse

4) Feed length multiplication ([Pr. PT03])

Set the feed length multiplication (STM) of the position data.

[Pr. PT03] setting	Position data input range (Note 2)		
	[mm]	[inch]	[pulse] (Note 1)
___ 0	- 999.999 to + 999.999	- 99.9999 to + 99.9999	- 999999 to + 999999
___ 1	- 9999.99 to + 9999.99	- 999.999 to + 999.999	
___ 2	- 99999.9 to + 99999.9	- 9999.99 to + 9999.99	
___ 3	- 999999 to + 999999	- 99999.9 to + 99999.9	

- Note 1. The feed length multiplication setting ([Pr. PT03]) is not applied to the unit multiplication factor. Adjust the unit multiplication factor in the electronic gear setting ([Pr. PA06] and [Pr. PA07]).
- Note 2. The "-" sign has different meanings under the absolute value command method and the incremental value command method. Refer to section 2.3.1 for details.

(c) Operation

Selecting RWwn6 for the point table and switching on RYn1 starts positioning to the position data at the set speed, acceleration time constant and deceleration time constant. At this time, RYn2 (Reverse rotation start) is invalid.

Item	Used device	Description
Automatic operation mode selection	RYn6 (Automatic/manual selection)	Switch on RYn6.
Point table selection	RWwn6 (Point table No. selection)	Set the point table No. to use.
Start	RYn1 (Forward rotation start)	Switch on RYn1 to start.

2. POINT TABLE OPERATION

(2) Incremental value command method

POINT
<p>● The incremental value command method ([Pr. PT01] = __ _ 1) is not available in the absolute position detection system. When using the absolute position detection system, select the absolute value command method ([Pr. PT01] = __ _ 0).</p>

(a) Point table

Set the point table values using MR Configurator2 or link devices.

Set the position data, servo motor speed, acceleration time constant, deceleration time constant, dwell and auxiliary function to the point table.

When you set a value outside the setting range to the point table, the set value will be clamped with the maximum or minimum value. When changing the command unit or the connected motor results in the set value outside the setting range, [AL. 37] will occur.

Item	Setting range	Unit	Description
Position data	0 to 999999 (Note 1)	$\times 10^{\text{STM}}$ μm $\times 10^{(\text{STM}-4)}$ inch pulse	Set the travel distance. The unit can be changed by [Pr. PT03] (Feed length multiplication).
Servo motor speed	0 to permissible speed	r/min mm/s (Note 2)	Set the command speed of the servo motor for execution of positioning. The setting value must be the permissible instantaneous speed or less of the servo motor used.
Acceleration time constant	0 to 20000	ms	Set a time until the servo motor rotates at the rated speed.
Deceleration time constant	0 to 20000	ms	Set a time from when the servo motor rotates at the rated speed until when the motor stops.
Dwell	0 to 20000	ms	Set the dwell. To disable the dwell, set "0" to the auxiliary function. To perform continuous operation, set "1", "8" or "9" to the auxiliary function and 0 to the dwell. When the dwell is set, the position command of the selected point table is completed, and after the set dwell has elapsed, the position command of the next point table is started.
Auxiliary function	0, 1, 8 to 9		Set the auxiliary function. 0: Automatic operation is performed in accordance with a single point table selected. 1: Automatic continuous operation is performed to the next point table without a stop. 8: Automatic continuous operation is performed without a stop to the point table selected at start-up. 9: Automatic continuous operation is performed without stopping a point table No. 1. Refer to section 4.2.2 for details.

Note 1. When the unit of the position data is μm or inch, the location of the decimal point is changed according to the STM setting.
 2. The unit will be "mm/s" in the linear servo motor control mode.


2. POINT TABLE OPERATION

(b) Parameter setting

Set the following parameters to perform automatic operation.

1) Command method selection ([Pr. PT01])



Select the incremental value command method as shown below.



2) Rotation direction selection ([Pr. PA14])

Select the servo motor rotation direction when RYn1 (Forward rotation start) or RYn2 (Reverse rotation start) is switched on.

[Pr. PA14] setting	Servo motor rotation direction	
	RYn1 (Forward rotation start)	RYn2 (Reverse rotation start)
0	CCW rotation (address increase)	CW rotation (address decrease)
1	CW rotation (address increase)	CCW rotation (address decrease)



3) Position data unit ([Pr. PT01])

Set the unit of the position data.

[Pr. PT01] setting	Position data unit
_ 0 _ _	mm
_ 1 _ _	inch
_ 3 _ _	pulse

4) Feed length multiplication ([Pr. PT03])

Set the feed length multiplication (STM) of the position data.

[Pr. PT03] setting	Position data input range		
	[mm]	[inch]	[pulse] (Note)
___ 0	0 to + 999.999	0 to + 99.9999	0 to + 999999
___ 1	0 to + 9999.99	0 to + 999.999	
___ 2	0 to + 99999.9	0 to + 9999.99	
___ 3	0 to + 999999	0 to + 99999.9	

Note. The feed length multiplication setting ([Pr. PT03]) is not applied to the unit multiplication factor.
Adjust the unit multiplication factor in the electronic gear setting ([Pr. PA06] and [Pr. PA07]).

2. POINT TABLE OPERATION

(c) Operation

Selecting RWwn6 for the point table and switching on RYn1 starts a forward rotation of the motor over the travel distance of the position data at the set speed, acceleration time constant and deceleration time constant.

Switching on RYn2 starts a reverse rotation of the motor in accordance with the values set to the selected point table.

When the positioning operation is performed consecutively under the incremental value command method, the servo motor rotates in the same direction only.

To change the travel direction during continuous operation, perform the operation under the absolute value command method.

Item	Used device	Description
Automatic operation mode selection	RYn6 (Automatic/manual selection)	Switch on RYn6.
Point table selection	RWwn6 (Point table No. selection)	Set the point table No. to use.
Start	RYn1 (Forward rotation start)	Switch on RYn1 to start.
	RYn2 (Reverse rotation start)	Switch on RYn2 to start.

2. POINT TABLE OPERATION


(3) Automatic operation timing chart

(a) Automatic individual positioning operation

1) Absolute value command method ([Pr. PT01] = __ _ 0)

While the servo motor is stopped under servo-on state, switching on RYn1 (Forward rotation start) starts the automatic positioning operation.

The following shows a timing chart.



Note. The detection of external input signals is delayed by the set time in the input filter setting of [Pr. PD11].


Considering the output signal sequence from the controller and signal variations due to hardware, configure a sequence that changes the point table selection earlier.

2. POINT TABLE OPERATION

2) Incremental value command method ([Pr. PT01] = ___ 1)

While the servo motor is stopped under servo-on state, switching on RYn1 (Forward rotation start) or RYn2 (Reverse rotation start) starts the automatic positioning operation.

The following shows a timing chart.



Note. The detection of external input signals is delayed by the set time in the input filter setting of [Pr. PD11].

Considering the output signal sequence from the controller and signal variations due to hardware, configure a sequence that changes the point table selection earlier.

2. POINT TABLE OPERATION

(b) Automatic continuous positioning operation

By merely selecting a point table and switching on RYn1 (Forward rotation start) or RYn2 (Reverse rotation start), the operation can be performed in accordance with the point tables having consecutive numbers.

1) Absolute value command method ([Pr. PT01] = __ _ 0)

By specifying the absolute value command or the incremental value command in the auxiliary function of the point table, the automatic continuous operation can be performed.

The following shows how to set.

Point table setting		
Dwell	Auxiliary function	
	When position data is absolute value	When position data is incremental value
1 or more	1	3

a) Positioning in a single direction

The following shows an operation example with the set values listed in the table below.


In this example, point table No. 1 and point table No. 3 are under the absolute value command method, and point table No. 2 is under the incremental value command method.

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Auxiliary function
1	5.00	3000	100	150	100	1
2	5.00	2000	150	200	200	3
3	15.00	1000	300	100	Disabled	0 (Note)

Note. Always set "0" or "2" to the auxiliary function of the last point table among the consecutive point tables.

0: When using the point table under the absolute value command method

2: When using the point table under the incremental value command method



2. POINT TABLE OPERATION

b) Positioning in the reverse direction midway

The following shows an operation example with the set values listed in the table below.


In this example, point table No. 1 and point table No. 3 are under the absolute value command method, and point table No. 2 is under the incremental value command method.

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Auxiliary function
1	5.00	3000	100	150	100	1
2	7.00	2000	150	200	200	3
3	8.00	1000	300	100	Disabled	0 (Note)

Note. Always set "0" or "2" to the auxiliary function of the last point table among the consecutive point tables.

0: When using the point table under the absolute value command method

2: When using the point table under the incremental value command method



2. POINT TABLE OPERATION

2) Incremental value command method ([Pr. PT01] = __ _ 1)

The position data of the incremental value command method is the sum of the position data of consecutive point tables.

The following shows how to set.


Point table setting	
Dwell	Auxiliary function
1 or more	1

a) Positioning in a single direction

The following shows an operation example with the set values listed in the table below.

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Auxiliary function
1	5.00	3000	100	150	100	1
2	6.00	2000	150	200	200	1
3	3.00	1000	300	100	Disabled	0 (Note)

Note. Always set "0" to the auxiliary function of the last point table among the consecutive point tables.



Note. Switching on RYn2 (Reverse rotation start) starts positioning in the reverse rotation direction.

2. POINT TABLE OPERATION

(c) Varying-speed operation

By setting the auxiliary function of the point table, the servo motor speed during positioning can be changed. Point tables are used by the number of the set speed.

1) Absolute value command method ([Pr. PT01] = _ _ _ 0)

Set "1" or "3" to the auxiliary function to execute the positioning at the speed set in the following point table.

At this time, the position data selected at start is valid, and the acceleration/deceleration time constant set in the next and subsequent point tables is invalid.

By setting "1" or "3" to sub functions until point table No. 254, the operation can be performed at maximum 255 speeds.

Always set "0" or "2" to the auxiliary function of the last point table.

To perform varying-speed operation, always set "0" to the dwell.

Setting "1" or more will enables the automatic continuous positioning operation.

The following table shows an example of setting.

Point table No.	Dwell [ms] (Note 1)	Auxiliary function	Varying-speed operation
1	0	1	Consecutive point table data
2	0	3	
3	Disabled	0 (Note 2)	
4	0	3	Consecutive point table data
5	0	1	
6	Disabled	2 (Note 2)	

Note 1. Always set "0".

2. Always set "0" or "2" to the auxiliary function of the last point table among the consecutive point tables.

2. POINT TABLE OPERATION

a) Positioning in a single direction

The following shows an operation example with the set values listed in the table below.

In this example, point table No. 1 and point table No. 3 are under the absolute value command method, and point table No. 2 is under the incremental value command method.


Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms] (Note 1)	Auxiliary function
1	5.00	3000	100	150	0	1
2	3.00	2000	Disabled	Disabled	0	3
3	10.00	1000	Disabled	Disabled	0	1
4	6.00	500	Disabled	Disabled	Disabled	2 (Note 2)

Note 1. Always set "0".

2. Always set "0" or "2" to the auxiliary function of the last point table among the consecutive point tables.

0: When using the point table under the absolute value command method

2: When using the point table under the incremental value command method



2. POINT TABLE OPERATION

b) Positioning in the reverse direction midway

The following shows an operation example with the set values listed in the table below.

In this example, point table No. 1 and point table No. 3 are under the absolute value command method, and point table No. 2 is under the incremental value command method.


Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms] (Note 1)	Auxiliary function
1	5.00	3000	100	150	0	1
2	7.00	2000	Disabled	Disabled	0	3
3	8.00	1000	Disabled	Disabled	Disabled	0 (Note 2)

Note 1. Always set "0".

2. Always set "0" or "2" to the auxiliary function of the last point table among the consecutive point tables.

0: When using the point table under the absolute value command method

2: When using the point table under the incremental value command method



2. POINT TABLE OPERATION

2) Incremental value command method ([Pr. PT01] = _ _ _ 1)

Setting "1" to the auxiliary function executes positioning at the speed set in the following point table.

At this time, the position data selected at start is valid, and the acceleration/deceleration time constant set in the next and subsequent point tables is invalid.

By setting "1" to sub functions until point table No. 254, the operation can be performed at maximum 255 speeds.

Always set "0" to the auxiliary function of the last point table.

To perform varying-speed operation, always set "0" to the dwell.

Setting "1" or more will enable the automatic continuous positioning operation.

The following table shows an example of setting.

Point table No.	Dwell [ms] (Note 1)	Auxiliary function	Varying-speed operation
1	0	1	Consecutive point table data
2	0	1	
3	Disabled	0 (Note 2)	
4	0	1	Consecutive point table data
5	0	1	
6	Disabled	0 (Note 2)	

Note 1. Always set "0".


2. Always set "0" to the auxiliary function of the last point table among the consecutive point tables.

The following shows an operation example with the set values listed in the table below.

Point table No.	Position data [10 ⁵ μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms] (Note 1)	Auxiliary function
1	5.00	3000	100	150	0	1
2	3.00	2000	Disabled	Disabled	0	1
3	2.00	1000	Disabled	Disabled	0	1
4	6.00	500	Disabled	Disabled	Disabled	0 (Note 2)

Note 1. Always set "0".

2. Always set "0" to the auxiliary function of the last point table among the consecutive point tables.



2. POINT TABLE OPERATION

(d) Automatic repeat positioning operation

By setting the auxiliary function of the point table, the operation pattern of the set point table No. can be returned to, and the positioning operation can be performed repeatedly.

1) Absolute value command method ([Pr. PT01] = _ _ _ 0)

Setting "8" or "10" to the auxiliary function performs automatic continuous operation or varying-speed operation until that point table, and after the completion of positioning, performs the operation again from the operation pattern of the point table No. used at start-up.

Setting "9" or "11" to the auxiliary function performs automatic continuous operation or varying-speed operation until that point table, and after the completion of positioning, performs the operation again from the operation pattern of point table No. 1.

a) Automatic repeat positioning operation by absolute value command method

Example 1. Operations when "8" is set to the auxiliary function of point table No. 4

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Auxiliary function
1	4.00	1500	200	100	150	1
2	5.00	3000	100	150	100	1
3	5.00	2000	150	200	200	3
4	15.00	1000	300	100	150	8

Operation sequence


1) Starting with point table No. 2

2) Executing point table No. 3

3) Executing point table No. 4

4) Executing again point table No. 2 used at start-up when "8" is set to the auxiliary function of point table No. 4

5) Repeating the above execution in the sequence of 2) to 3) to 4) to 2) to 3) to 4)



Note. RWn6 is not outputted in automatic continuous operation.


2. POINT TABLE OPERATION

Example 2. Operations when "9" is set to the auxiliary function of point table No. 3

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Auxiliary function
1	0.00	3000	100	150	100	1
2	5.00	2000	150	200	200	1
3	15.00	1000	300	100	150	9

Operation sequence

- 1) Starting with point table No. 2
- 2) Executing point table No. 3
- 3) Executing point table No. 1 when "9" is set to the auxiliary function of point table No. 3
- 4) Repeating the above execution in the sequence of 1) to 2) to 3) to 1) to 2) to 3)



Note. RWn6 is not outputted in automatic continuous operation.

2. POINT TABLE OPERATION


b) Automatic repeat positioning operation by incremental value command method

Example 1. Operations when "10" is set to the auxiliary function of point table No. 4

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Auxiliary function
1	4.00	1500	200	100	150	1
2	5.00	3000	100	150	100	3
3	10.00	2000	150	200	200	1
4	5.00	1000	300	100	150	10

Operation sequence

- 1) Starting with point table No. 2
- 2) Executing point table No. 3
- 3) Executing point table No. 4
- 4) Executing again point table No. 2 used at start-up when "10" is set to the auxiliary function of point table No. 4
- 5) Repeating the above execution in the sequence of 1) to 2) to 3) to 4) to 2) to 3) to 4)



Note. RWrn6 is not outputted in automatic continuous operation.


2. POINT TABLE OPERATION

Example 2. Operations when "11" is set to the auxiliary function of point table No. 3

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Auxiliary function
1	5.00	3000	100	150	100	3
2	10.00	2000	150	200	200	1
3	5.00	1000	300	100	150	11

Operation sequence

- 1) Starting with point table No. 2
- 2) Executing point table No. 3
- 3) Executing point table No. 1 when "11" is set to the auxiliary function of point table No. 3
- 4) Repeating the above execution in the sequence of 1) to 2) to 3) to 1) to 2) to 3)



Note. RWrn6 is not outputted in automatic continuous operation.

2. POINT TABLE OPERATION


c) Varying-speed operation by absolute value command method

Example. Operations when "8" is set to the auxiliary function of point table No. 3

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Auxiliary function
1	5.00	3000	100	150	0	1
2	5.00	2000	Disabled	Disabled	0	3
3	15.00	1000	Disabled	Disabled	0	8

Operation sequence

- 1) Starting with point table No. 1
- 2) Varying the speed and executing point table No. 2
- 3) Varying the speed and executing point table No. 3
- 4) Executing point table No. 1 used at start-up in CW direction when "8" is set to the auxiliary function of point table No. 3
- 5) Repeating the above execution in the sequence of 1) to 2) to 3) to 4) to 2) to 3) to 4)



Note. RWn6 is not outputted in automatic continuous operation.

2. POINT TABLE OPERATION


d) Varying-speed operation by incremental value command method

Example. Operations when "10" is set to the auxiliary function of point table No. 3

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Auxiliary function
1	5.00	3000	100	150	0	3
2	10.00	2000	150	200	0	1
3	5.00	1000	300	100	0	10

Operation sequence

- 1) Starting with point table No. 1
- 2) Varying the speed and executing point table No. 2
- 3) Varying the speed and executing point table No. 3
- 4) Varying the speed, and executing point table No. 1 when "10" is set to the auxiliary function of point table No. 3
- 5) Repeating the above execution in the sequence of 1) to 2) to 3) to 4) to 2) to 3) to 4)



Note. RWn6 is not outputted in automatic continuous operation.

2. POINT TABLE OPERATION

2) Incremental value command method ([Pr. PT01] = __ _ 1)

Setting "8" to the auxiliary function performs automatic continuous operation or varying-speed operation until that point table, and after the completion of positioning, performs the operation again from the operation pattern of the set point table.

Setting "9" to the auxiliary function performs automatic continuous operation or varying-speed operation until that point table, and after the completion of positioning, performs the operation again from the operation pattern of point table No. 1.

a) Automatic repeat positioning operation by incremental value command method

Example 1. Operations when "8" is set to the auxiliary function of point table No. 3

Point table No.	Position data [10 ⁵ μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Auxiliary function
1	4.00	1500	200	100	150	1
2	5.00	3000	100	150	100	1
3	6.00	2000	150	200	200	8


Operation sequence

1) Starting with point table No. 2

2) Executing point table No. 3

3) Executing again point table No. 2 used at start-up when "8" is set to the auxiliary function of point table No. 3

4) Repeating the above execution in the sequence of 1) to 2) to 3) to 2) to 3)



Note. RWn6 is not outputted in automatic continuous operation.


2. POINT TABLE OPERATION

Example 2. Operations when "9" is set to the auxiliary function of point table No. 2

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Auxiliary function
1	5.00	3000	100	150	100	1
2	6.00	2000	150	200	200	9

Operation sequence

- 1) Starting with point table No. 2
- 2) Executing point table No. 1 when "9" is set to the auxiliary function of point table No. 2
- 3) Repeating the above execution in the sequence of 1) to 2) to 1) to 2)



Note. RWrn6 is not outputted in automatic continuous operation.

2. POINT TABLE OPERATION


b) Varying-speed operation by incremental value command method

Example. Operations when "8" is set to the auxiliary function of point table No. 2

Point table No.	Position data [10 ^{STM} μm]	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Auxiliary function
1	5.00	3000	100	150	0	1
2	6.00	2000	Disabled	Disabled	0	8

Operation sequence

- 1) Starting with point table No. 1
- 2) Varying the speed and executing point table No. 2
- 3) Executing again point table No. 1 used at start-up when "8" is set to the auxiliary function of point table No. 2
- 4) Repeating the above execution in the sequence of 1) to 2) to 3) to 2) to 3)



Note. RWrn6 is not outputted in automatic continuous operation.

2. POINT TABLE OPERATION

(e) Temporary stop/restart

When RYn7 (Temporary stop/restart) is switched on during automatic operation, the servo motor decelerates with the deceleration time constant of the point table being executed, and then stops temporarily.

Switching on RYn7 (Temporary stop/restart) again restarts the servo motor rotation for the remaining distance.

During a temporary stop, RYn1 (Forward rotation start) or RYn2 (Reverse rotation start) does not function even if it is switched on.


When any of the following conditions is satisfied during a temporary stop, the remaining travel distance is cleared and the temporary stop is reset.

- The operation mode is switched from the automatic mode to the manual mode.
- The servo motor enters the servo-off status.
- The stroke limit or software limit is detected.
- The controller is reset.

The temporary stop/restart input functions in the following states.


Operation status	Automatic operation	Manual operation	Home position return
During a stop	Temporary stop	Temporary stop	Temporary stop
During acceleration		Temporary stop	Temporary stop
At a constant speed		Temporary stop	Temporary stop
During deceleration	Temporary stop	Temporary stop	Temporary stop
During a temporary stop		Restart	Stop

1) When the servo motor is rotating




2. POINT TABLE OPERATION

2) During dwell



(f) Suspension of automatic operation

To stop the automatic operation, stop the servo motor with RYn7 (Temporary stop/restart), switch off RYn6 (Automatic/manual selection), and then set to the manual mode. The travel remaining distance is cleared.




2. POINT TABLE OPERATION

(g) Changing the operation mode


When the operation mode is changed, wait for 6 ms or more after the change, and then turn on RYn1 (Forward rotation start) or RYn2 (Reverse rotation start).

Changing the operation mode during operation will stop the operation in execution and decelerate the servo motor to a stop. Before turning on RYn1 (Forward rotation start) or RYn2 (Reverse rotation start), make sure that RXnC (Travel completion) is turned on.

1) When you change the operation mode while the operation is being stopped




2) When you change the operation mode during operation (from the point table operation to JOG operation)



2. POINT TABLE OPERATION

3) When you change the operation mode during operation (from the point table operation to home position return)



2. POINT TABLE OPERATION

2.4 Manual operation mode

For the machine adjustment, home position adjustment, and others, positioning to any point is possible using the JOG operation.

2.4.1 JOG operation


(1) Setting

According to the purpose of use, set input devices and parameters as shown below. In this case, RWwn6 (Point table No. selection) is disabled.


Item	Used device/parameter	Setting
Manual operation mode selection	RYn6 (Automatic/manual selection)	Switch off RYn6.
Servo motor rotation direction	[Pr. PA14]	Refer to (2) in this section.
JOG speed	[Pr. PT65]	Set the servo motor speed.
Acceleration/deceleration time constant	Acceleration time constant: [Pr. PT49] Deceleration time constant: [Pr. PT50]	Set an acceleration time constant and deceleration time constant.

(2) Servo motor rotation direction

[Pr. PA14] setting	Servo motor rotation direction	
	RYn1 (Forward rotation start) on	RYn2 (Reverse rotation start) on
0	CCW rotation	CW rotation
1	CW rotation	CCW rotation



[Pr. PA14]: 0



[Pr. PA14]: 1


(3) Operation

Turning on RYn1 (Forward rotation start) performs the operation according to the JOG speed, acceleration time constant, and deceleration time constant set with parameters. For the rotation direction, refer to (2) in this section. Switching on RYn2 (Reverse rotation start) starts the rotation in the reverse direction of RYn1 (Forward rotation start).

Simultaneously switching on or off RYn1 (Forward rotation start) and RYn2 (Reverse rotation start) stops the operation.

2. POINT TABLE OPERATION

(4) Timing chart



2. POINT TABLE OPERATION

(5) Temporary stop/restart

When RYn7 (Temporary stop/restart) is switched on during JOG operation, the servo motor decelerates with the deceleration time constant being executed ([Pr. PT50]), and then stops temporarily. Turning on RYn7 (Temporary stop/restart) again restarts the JOG operation. However, if both RYn1 (Forward rotation start) and RYn2 (Reverse rotation start) are on or off, the operation does not restart.

During a temporary stop, RYn1 (Forward rotation start) or RYn2 (Reverse rotation start) does not function even if it is switched on.


When any of the following conditions is satisfied during a temporary stop, the temporary stop is reset.

- The manual operation mode is switched to the automatic operation mode.
- The servo motor enters the servo-off status.
- The stroke limit or software limit is detected.
- The controller is reset.

The temporary stop/restart input functions in the following status.


Operation status	Automatic operation	Manual operation	Home position return
During a stop		Pause	Pause
During acceleration	Pause	Pause	Pause
At a constant speed	Pause	Pause	Pause
Deceleration		Pause	Pause
During a temporary stop	Restart	Restart	Stop

(a) When the servo motor is rotating



2. POINT TABLE OPERATION

(b) When the servo motor has been restarted during a temporary stop



2. POINT TABLE OPERATION

2.5 Home position return mode

POINT
<ul style="list-style-type: none">● Before performing the home position return, make sure that the limit switch operates.● Check the home position return direction. An incorrect setting will cause a reverse running.● Check the input polarity of the proximity dog. Otherwise, it may cause an unexpected operation.● In the following cases, make sure that the Z-phase has been passed through once before performing a home position return. Z-phase unpassed will trigger [AL. 90.5 Home position return incomplete warning].<ul style="list-style-type: none">▪ When using an incremental linear encoder in the linear servo motor control mode▪ When using an incremental external encoder in the fully closed loop control mode▪ For the use in the DD motor control mode● To execute a home position return securely, start a home position return after moving the linear servo motor to the opposite stroke end.

2. POINT TABLE OPERATION

2.5.1 Outline of home position return

A home position return is performed to match the command coordinates with the machine coordinates. Under the incremental method, each power-on of the input power supply requires the home position return. Contrastingly, in the absolute position detection system, once you have performed the home position return at machine installation, the current position will be retained even if the power supply is shut off. Therefore, the home position return is unnecessary when the power supply is switched on again.

This section shows the home position return types of the servo amplifier. Select the optimum method according to the configuration and uses of the machine.

When a home position return is started with the controller, Controlword bit 4 will turn on. For details of the home position return, refer to the controller instruction manual.

(1) Home position return types

POINT	
●	For the home position return types for which "Motion mode" is described in the detailed explanation field, refer to section 4.6 of "MR-J4-_GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)". In addition, replace the following left signals to the right signals.
▪ Statusword bit 10 Target reached	→ RXnC (Travel completion)
▪ Statusword bit 12 Homing attained	→ RX (n + 1) 0 (Home position return completion 2)
▪ Controlword bit 4 Homing operation start	→ RYn1 (Forward rotation start)
▪ DOG (Proximity dog)	→ RYn3 (Proximity dog)
▪ TLC (Limiting torque)	→ RXn4 (Limiting torque)

Select the optimum home position return type according to the machine type or others.

Method No.	Home position return type	Rotation direction	Description	Detailed explanation
-1	Dog type (Rear end detection, Z-phase reference)	Forward rotation	Deceleration starts at the front end of the proximity dog. After the rear end is passed, the position specified by the first Z-phase signal, or the position of the first Z-phase signal shifted by the specified home position shift distance is used as the home position.	Motion mode
-33		Reverse rotation		
-4	Stopper type (Stopper position reference)	Forward rotation	A workpiece is pressed against a mechanical stopper, and the position where it is stopped is set as the home position.	
-36		Reverse rotation		
-2	Count type (Front end detection, Z-phase reference)	Forward rotation	At the front end of the proximity dog, deceleration starts. After the front end is passed, the position specified by the first Z-phase signal after the set distance or the position of the Z-phase signal shifted by the set home position shift distance is set as a home position.	
-34		Reverse rotation		
-5	Home position ignorance (Servo-on position as home position)		Servo-on position is set as the home position.	Section 2.5.2
-6	Dog type (Rear end detection, rear end reference)	Forward rotation	Deceleration starts from the front end of the proximity dog. After the rear end is passed, the position is shifted by the travel distance after proximity dog and the home position shift distance. The position after the shifts is set as the home position.	Motion mode
-38		Reverse rotation		

2. POINT TABLE OPERATION

Method No.	Home position return type	Rotation direction	Description	Detailed explanation
-7	Count type (Front end detection, front end reference)	Forward rotation	Deceleration starts from the front end of the proximity dog. The position is shifted by the travel distance after proximity dog and the home position shift distance. The position after the shifts is set as the home position.	Motion mode
-39		Reverse rotation		
-8	Dog cradle type	Forward rotation	A position, which is specified by the first Z-phase signal after the front end of the proximity dog is detected, is set as the home position.	
-40		Reverse rotation		
-9	Dog type last Z-phase reference	Forward rotation	After the front end of the proximity dog is detected, the position is shifted away from the proximity dog in the reverse direction. Then, the position specified by the first Z-phase signal or the position of the first Z-phase signal shifted by the home position shift distance is used as the home position.	
-41		Reverse rotation		
-10	Dog type front end reference	Forward rotation	Starting from the front end of the proximity dog, the position is shifted by the travel distance after proximity dog and the home position shift distance. The position after the shifts is set as the home position.	
-42		Reverse rotation		
-11	Dogless Z-phase reference	Forward rotation	The position specified by the first Z-phase signal, or the position of the first Z-phase signal shifted by the home position shift distance is used as the home position.	
-43		Reverse rotation		
3	Homing on positive home switch and index pulse	Forward rotation	Same as the dog type last Z-phase reference home position return. Note that if the stroke end is detected during home position return, [AL. 90 Home position return incomplete warning] occurs.	
4	Homing on positive home switch and index pulse	Forward rotation	Same as the dog cradle type home position return. Note that if the stroke end is detected during home position return, [AL. 90 Home position return incomplete warning] occurs.	
5	Homing on negative home switch and index pulse	Reverse rotation	Same as the dog type last Z-phase reference home position return. Note that if the stroke end is detected during home position return, [AL. 90 Home position return incomplete warning] occurs.	
6	Homing on negative home switch and index pulse	Reverse rotation	Same as the dog cradle type home position return. Note that if the stroke end is detected during home position return, [AL. 90 Home position return incomplete warning] occurs.	
7	Homing on home switch and index pulse	Forward rotation	Same as the dog type last Z-phase reference home position return.	
8	Homing on home switch and index pulse	Forward rotation	Same as the dog cradle type home position return.	
11	Homing on home switch and index pulse	Reverse rotation	Same as the dog type last Z-phase reference home position return.	
12	Homing on home switch and index pulse	Reverse rotation	Same as the dog cradle type home position return.	
19	Homing without index pulse	Forward rotation	Same as the dog type front end reference home position return. Note that if the stroke end is detected during home position return, [AL. 90 Home position return incomplete warning] occurs.	
20	Homing without index pulse	Forward rotation	Although this type is the same as the dog cradle type home position return, the stop position is not on the Z-phase. Starting from the front end of the dog, the position is shifted by the travel distance after proximity dog and the home position shift distance. The position after the shifts is set as the home position. If the stroke end is detected during home position return, [AL. 90 Home position return incomplete warning] occurs.	

2. POINT TABLE OPERATION

Method No.	Home position return type	Rotation direction	Description	Detailed explanation
21	Homing without index pulse	Reverse rotation	Same as the dog type front end reference home position return. Note that if the stroke end is detected during home position return, [AL. 90 Home position return incomplete warning] occurs.	Motion mode
22	Homing without index pulse	Reverse rotation	Although this type is the same as the dog cradle type home position return, the stop position is not on the Z-phase. Starting from the front end of the dog, the position is shifted by the travel distance after proximity dog and the home position shift distance. The position after the shifts is set as the home position. If the stroke end is detected during home position return, [AL. 90 Home position return incomplete warning] occurs.	
23	Homing without index pulse	Forward rotation	Same as the dog type front end reference home position return.	
24	Homing without index pulse	Forward rotation	Although this type is the same as the dog cradle type home position return, the stop position is not on the Z-phase. Starting from the front end of the dog, the position is shifted by the travel distance after proximity dog and the home position shift distance. The position after the shifts is set as the home position.	
27	Homing without index pulse	Reverse rotation	Same as the dog type front end reference home position return.	
28	Homing without index pulse	Reverse rotation	Although this type is the same as the dog cradle type home position return, the stop position is not on the Z-phase. Starting from the front end of the dog, the position is shifted by the travel distance after proximity dog and the home position shift distance. The position after the shifts is set as the home position.	
33	Homing on index pulse	Reverse rotation	Although this type is the same as the dogless Z-phase reference home position return, the creep speed is applied as the movement start speed.	
34	Homing on index pulse	Forward rotation	Although this type is the same as the dogless Z-phase reference home position return, the creep speed is applied as the movement start speed.	
35	Homing on current position		The current position is set as the home position. This type can be executed not in the Operational enabled state.	
37	Homing on current position		The current position is set as the home position. This type can be executed not in the Operational enabled state.	

2. POINT TABLE OPERATION

(2) Parameters for home position return

To perform the home position return, set each parameter as follows.


- (a) Select the home position return type and home position return direction with [Pr. PT45 Home position return type].

Setting value	Home position return direction	Home position return type
-1	Address increasing direction	Dog type (rear end detection, Z-phase reference)
-2		Count type (front end detection, Z-phase reference)
-4		Stopper type (stopper position reference)
-5		Home position ignorance (Servo-on position as home position)
-6		Dog type (rear end detection, rear end reference)
-7		Count type (front end detection, front end reference)
-8		Dog cradle type
-9		Dog type last Z-phase reference
-10		Dog type front end reference
-11		Dogless Z-phase reference
-33	Address decreasing direction	Dog type (rear end detection, Z-phase reference)
-34		Count type (front end detection, Z-phase reference)
-36		Stopper type (stopper position reference)
-38		Dog type (rear end detection, rear end reference)
-39		Count type (front end detection, front end reference)
-40		Dog cradle type
-41		Dog type last Z-phase reference
-42		Dog type front end reference
-43		Dogless Z-phase reference

Setting value	Home position return direction	Home position return type
3	Address increasing direction	Method 3
4		Method 4
5	Address decreasing direction	Method 5
6		Method 6
7	Address increasing direction	Method 7
8		Method 8
11	Address decreasing direction	Method 11
12		Method 12
19	Address increasing direction	Method 19
20		Method 20
21	Address decreasing direction	Method 21
22		Method 22
23	Address increasing direction	Method 23
24		Method 24
27	Address decreasing direction	Method 27
28		Method 28
33		Method 33
34	Address increasing direction	Method 34
35		Method 35
37		Method 37 (Data set type)

2. POINT TABLE OPERATION

- (b) Select the polarity where the proximity dog is detected with the DOG (Proximity dog) polarity selection of [Pr. PT29 Function selection T-3].
Setting "0" detects a proximity dog when RYn3 (Proximity dog) is switched off. Setting "1" detects a proximity dog when RYn3 (Proximity dog) is switched on.



2. POINT TABLE OPERATION

(3) Temporary stop/restart

When RYn7 (Temporary stop/restart) is switched on during home position return, the servo motor decelerates with the home position return deceleration time constant being executed ([Pr. PT56] or [Pr. PT57]), and then stops temporarily. Turning on RYn7 (Temporary stop/restart) again resets the temporary stop, but the operation does not restart. Turning on RYn1 (Forward rotation start) after the temporary stop is reset restarts the home position return.

During a temporary stop, RYn1 (Forward rotation start) or RYn2 (Reverse rotation start) does not function even if it is switched on.


When any of the following conditions is satisfied during a temporary stop, the temporary stop is reset.

- The home position return mode is switched to the automatic operation mode or manual operation mode.
- The servo motor enters the servo-off status.
- The stroke limit or software limit is detected.
- The controller is reset.

The temporary stop/restart input functions in the following status.

Operation status	Automatic operation	Manual operation	Home position return
During a stop		Pause	Pause
During acceleration	Pause	Pause	Pause
At a constant speed	Pause	Pause	Pause
Deceleration		Pause	Pause
During a temporary stop	Restart	Restart	Stop

When the home position return is being executed



Note. Select the deceleration time constant from [Pr. PT56] and [Pr. PT57] using the setting value of [Pr. PT55].


2. POINT TABLE OPERATION

2.5.2 Method -5 (Home position ignorance (Servo-on position as home position))

POINT	
	●When you perform this home position return, it is unnecessary to switch to the home position return mode.

The position at servo-on is used as the home position.

(1) Timing chart



2. POINT TABLE OPERATION

2.5.3 Automatic positioning to home position function

POINT	
●	The automatic positioning to the home position cannot be performed from outside the setting range of position data. In this case, perform the home position return again using the home position return.

After power-on, if the home position return is performed again after the home position return is performed to define the home position, this function enables automatic positioning to the home position rapidly. For the absolute position detection system, the home position return is unnecessary after the power-on.

When the automatic positioning to the home position is performed at home position return incompleteness, [AL. 90.1] will occur.


After the power-on, perform the home position return in advance.

Set link devices and parameters as follows:

Item	Used device/parameter	Setting
Home position return mode selection	RYn6 (Automatic/manual selection)	Switch on RYn6.
	RWwn6 (Point table No. selection)	Set "0" in RWwn6.
Home position return speed	[Pr. PT05]	Set the servo motor speed to travel to the home position.
Home position return acceleration/deceleration time constant	Acceleration time constant: [Pr. PT56] Deceleration time constant: [Pr. PT56] (When "___ 0" is set in [Pr. PT55]) [Pr. PT57] (When "___ 1" is set in [Pr. PT55])	Set an acceleration time constant and deceleration time constant.

Set the home position return speed of the automatic positioning to home position function with [Pr. PT05].

Set the acceleration time constant with [Pr. PT56]. Select the deceleration time constant from [Pr. PT56] and [Pr. PT57] using the setting value of [Pr. PT55]. Turning on RYn2 (Reverse rotation start) executes the automatic return function to the home position.




2. POINT TABLE OPERATION

2.6 Point table setting method


The following shows the setting method of point tables using MR Configurator2.

2.6.1 Setting procedure

Click "Positioning-data" in the menu bar and click "Point Table" in the menu.



The following window will be displayed by clicking.



(1) Writing point table data (a)

Select changed point table data and click "Selected Items Write" to write the changed point table data to the servo amplifier.

(2) Writing all point table data (b)

Click "Write All" to write all the point table data to the servo amplifier.

(3) Reading all point table data (c)

Click "Read" to read and display all the point table data from the servo amplifier.

(4) Initial setting of point table data (d)

Click "Set to default" to initialize all the data of point table No. 1 to 255. This function also initializes data currently being edited.


2. POINT TABLE OPERATION

- (5) Verifying point table data (e)
Click "Verify" to verify all the data displayed and data of the servo amplifier.
- (6) Detailed setting of point table data (f)
Click "Detailed Setting" to change position data range and unit in the point table window. Refer to section 2.6.2 for details.
- (7) Single-step feed (g)
Click "Single-step Feed" to perform the single-step feed test operation. Refer to section 2.6.3 for details.
- (8) Copy and paste of point table data (h)
Click "Copy" to copy the selected point table data. Click "Paste" to paste the copied point table data.
- (9) Inserting point table data (i)
Click "Insert" to insert a block to the previous row from the selected point table No. The selected point table No. and lower rows will be shifted down one by one.
- (10) Deleting point table data (j)
Click "Delete" to delete all the data of the point table No. selected. The lower rows of the selected point table No. will be shifted up one by one.
- (11) Changing point table data (k)
After selecting the data to be changed, enter a new value, and click "Enter". You can change the displayed range and unit with "(6) Detailed setting of point table data" in this section.
- (12) Reading point table data (l)
Click "Open" to read the point table data.
- (13) Saving point table data (m)
Click "Save As" to save the point table data.
- (14) Updating project (n)
Click "Update Project" to update the point table data to a project.

2. POINT TABLE OPERATION

2.6.2 Detailed setting window

You can change position data range and unit with the detailed setting for the point table window. For the position data range and unit of [Pr. PT01] setting, refer to section 2.3.2. To reflect the setting for the corresponding parameter, click "Update Project" in the point table window.



(1) Command method selection (PT01 *CTY) 1)

Select a positioning command method from the absolute position command method and incremental value command method.

(2) Miscellaneous

(a) Feed length multiplication parameter setting STM (PT03 *FTY) 2)

Select any feed length multiplication from 1/10/100/1000.

(b) Position data unit setting (PT01 *CTY) 3)

Select any unit of position data from mm/inch/pulse. While pulse is selected, setting of feed length multiplication will be disabled.

2. POINT TABLE OPERATION

2.6.3 Single-step feed




CAUTION

- The test operation mode is designed for checking servo operation. Do not use it for actual operation.
- If the servo motor operates unexpectedly, use EM2 (Forced stop 2) to stop it.

POINT

- MR Configurator2 is required to perform single-step feed.
- Test operation cannot be performed if RYn0 (Servo-on) is not turned off.

The positioning operation can be performed in accordance with the point table No. set by MR Configurator2. Select the test operation/single-step feed by the menu of MR Configurator2. When the single-step feed window is displayed, input the following items and operate.



Point table operation

- (1) Point table No. setting
Input a point table No. into the input box (a) "Point table No."
- (2) Forward/reverse the servo motor
Click "Operation Start" (b) to rotate the servo motor.
- (3) Pause the servo motor
Click "Pause" (c) to temporarily stop the servo motor.
While the servo motor is temporarily stopped, click "Operation Start" (b) to restart the rotation by the travel remaining distance.
While the servo motor is temporarily stopped, click "Stop" (d) to clear the travel remaining distance.
- (4) Stop the servo motor
Click "Stop" (d) to stop the servo motor. At this time, the travel remaining distance is cleared. Click "Operation Start" (b) to restart the rotation.
- (5) Forced stop of the servo motor software
Click "Forced Stop" (e) to make an instantaneous stop. When "Forced Stop" is enabled, "Operation Start" cannot be used. Click the "Forced Stop" again to enable the "Operation Start".
- (6) Switch to the normal operation mode
Before switching from the test operation mode to the normal operation mode, turn off the servo amplifier.

2. POINT TABLE OPERATION


2.7 Programming example by function

This section explains specific programming examples for operating or monitoring the servo and for reading or writing parameters based on the device configuration shown in section 2.7.1.

2.7.1 System configuration example

As shown below, a CC-Link IE Field Network master/local module is mounted to operate two servo amplifiers.

(1) System configuration



(2) Network parameter setting in the master station

In the programming examples, the network parameters are set as follows:

Item		Setting condition
Start I/O No.		0000
Operation setting	Data link error station setting	Clear
	Setting at CPU STOP	Held
Type		Master station
Mode setting		Standard
Total No. of connected units		2
Remote input (RX) Refresh device		X1000
Remote output (RY) Refresh device		Y1000


Item	Setting condition
Remote register (RW _r) Refresh device	W0
Remote register (RW _w) Refresh device	W100
Special relay (SB) Refresh device	SB0
Special register (SW) Refresh device	SW0
CPU down specification	Clear
Scan mode specification	Asynchronous sequence scan

2. POINT TABLE OPERATION

(3) Assignment of remote inputs/outputs (RX, RY)

The following shows the assignment of remote inputs/outputs (RX, RY) of the station to the devices of the programmable controller CPU.

The devices actually used are shaded.




2. POINT TABLE OPERATION

(4) Assignment of remote registers (RWw, RWr)

The following shows the assignment of remote registers (RWw, RWr) of the station to the devices of the programmable controller CPU.

The devices actually used are shaded.





2. POINT TABLE OPERATION

2.7.2 Reading the servo amplifier status

When the servo amplifier with station No. 1 enters remote station communication ready, the output module Y30 turns on.

This program turns on Y30 when the CC-Link IE Field Network communication is normally established.





Servo amplifier status		
X1000: RD (Ready)	X1016: ---	X102C: ---
X1001: INP (In-position)	X1017: ---	X102D: ---
X1002: CPO (Rough match)	X1018: ---	X102E: ---
X1003: ---	X1019: ---	X102F: ---
X1004: TLC (Limiting torque)	X101A: ---	X1030: ---
X1005: ---	X101B: ---	X1031: ---
X1006: MBR (Electromagnetic brake interlock)	X101C: ---	X1032: ---
X1007: PUS (Temporary stop)	X101D: ---	X1033: ---
X1008: MOF (Monitoring)	X101E: ---	X1034: ---
X1009: COF (Instruction code execution completion)	X101F: ---	X1035: ---
X100A: WNG (Warning)	X1020: PSF (Position command execution completion)	X1036: ---
X100B: BWNG (Battery warning)	X1021: SPF (Speed command execution completion)	X1037: ---
X100C: MEND (Travel completion)	X1022: ---	X1038: ---
X100D: DB (Dynamic brake interlock)	X1023: ---	X1039: ---
X100E: POT (Position range)	X1024: ---	X103A: ALM (Malfunction)
X100F: ---	X1025: ---	X103B: CRD (Remote station communication ready)
X1010: ZP2 (Home position return completion 2)	X1026: ---	X103C: ---
X1011: ---	X1027: ---	X103D: ---
X1012: ---	X1028: ---	X103E: ---
X1013: ---	X1029: ---	X103F: ---
X1014: ---	X102A: ---	
X1015: ---	X102B: ---	

2. POINT TABLE OPERATION

2.7.3 Writing an operation command

The servo amplifier with station No. 1 performs positioning operation according to point table No. 2.
Turning on X20 starts the operation.



2. POINT TABLE OPERATION

Operation command		
Y1000: SON (Servo-on)	Y1016: ---	Y102C: ---
Y1001: ST1 (Forward rotation start)	Y1017: ---	Y102D: ---
Y1002: ST2 (Reverse rotation start)	Y1018: ---	Y102E: ---
Y1003: DOG (Proximity dog)	Y1019: ---	Y102F: ---
Y1004: ---	Y101A: ---	Y1030: ---
Y1005: ---	Y101B: ---	Y1031: ---
Y1006: MD0 (Automatic/manual selection)	Y101C: ---	Y1032: ---
Y1007: TSTP (Temporary stop/restart)	Y101D: ---	Y1033: ---
Y1008: MOR (Monitor output execution demand)	Y101E: ---	Y1034: ---
Y1009: COR (Instruction code execution demand)	Y101F: ---	Y1035: ---
Y100A: ---	Y1020: PSR (Position command execution demand)	Y1036: ---
Y100B: ---	Y1021: SPR (Speed command execution demand)	Y1037: ---
Y100C: ---	Y1022: ---	Y1038: ---
Y100D: ---	Y1023: ---	Y1039: ---
Y100E: ---	Y1024: ---	Y103A: RES (Reset)
Y100F: ---	Y1025: ---	Y103B: ---
Y1010: FLS (Upper stroke limit)	Y1026: ---	Y103C: ---
Y1011: RLS (Lower stroke limit)	Y1027: PC (Proportional control)	Y103D: ---
Y1012: ORST (Operation alarm reset)	Y1028: CDP (Gain switching)	Y103E: ---
Y1013: ---	Y1029: ---	Y103F: ---
Y1014: ---	Y102A: CSL (Position/speed specifying method selection)	
Y1015: ---	Y102B: CAOR (Absolute value/incremental value selection)	

2. POINT TABLE OPERATION

2.7.4 Reading data


Data of the servo amplifier is read.

(1) Reading monitor

The cumulative feedback pulses of the servo amplifier with station No. 2 are read to D10.

Code No.	Description
H000A	Cumulative feedback pulse data (hexadecimal)

Turning on X20 reads the monitor of the cumulative feedback pulses.




(2) Reading parameters

[Pr. PA04 Function selection A-1] of the servo amplifier with station No. 2 is read to D1.

Code No.	Description
H8200	Select the parameter group.
H0204	Setting value in [Pr. PA04] (hexadecimal)

Turning on X20 reads [Pr. PA04].

A respond code at the execution of the instruction code is set in D3.



2. POINT TABLE OPERATION


(3) Reading an error

An error of the servo amplifier with station No. 2 is read to D1.

Code No.	Description
H0010	Alarm or warning that is currently occurring (hexadecimal)

Turning on X20 reads the current alarm.

A respond code at the execution of the instruction code is set in D3.



2. POINT TABLE OPERATION

2.7.5 Writing data

This section explains programs for writing data to the servo amplifiers.


(1) Writing servo motor speed data of a point table

The servo motor speed data of point table No. 1 of station No. 2 is changed to "100".

Code No.	Description
H8D01	Write the servo motor speed data of point table No. 1 (hexadecimal).

Setting data	Description
K100	Servo motor speed data of point table No. 1 (decimal)

Turning on X20 writes the servo motor speed data of point table No. 1.
A respond code at the execution of the instruction code is set in D3.



2. POINT TABLE OPERATION

(2) Writing parameters

The parameter [Pr. PT65 JOG speed] of the servo amplifier with station No. 2 is changed to "100". Specify the parameter group PT as follows:

Code No.	Description
H8200	Selecting the parameter group

Setting data	Description
H000C	Setting data (hexadecimal)


The parameter [Pr. PT65] is changed to "100" as follows:

Code No.	Description
H820C	Write [Pr. PT65] (hexadecimal).

Setting data	Description
K100	Setting data (decimal)


Turning on X20 writes [Pr. PT65].

A respond code at the execution of the instruction code is set in D3.



2. POINT TABLE OPERATION

- (3) Program example for resetting an alarm of the servo amplifier
- (a) A command from the programmable controller clears an alarm occurring in the servo amplifier with station No. 2.
- Turning on X20 clears an alarm occurring in the servo amplifier.




- (b) An instruction code clears an alarm in the servo amplifier with station No. 2.

Code No.	Description
H8010	Alarm reset command (hexadecimal)

Setting data	Description
1EA5	Execution data (hexadecimal)

Turning on X20 resets the servo amplifier.

A respond code at the execution of the instruction code is set in D3.



2. POINT TABLE OPERATION

2.7.6 Operation

This section explains programs for operating the servo amplifiers.


(1) JOG operation

The servo amplifier with station No. 1 performs JOG operation and reads the "current position".

Code No.	Description
H0001	Current position data (hexadecimal)

Turning on X22 starts forward rotation JOG operation.

Turning on X23 starts reverse rotation JOG operation.



2. POINT TABLE OPERATION


(2) Setting position data and speed data with remote registers

The servo amplifier with station No. 2 is operated with position data of "100000" and speed data of "1000" specified with the direct specification mode.


Set [Pr. PT62] to "___2" in advance.

Setting data	Description
K100000	Position command data (decimal)
K1000	Speed command data (decimal)

Turning on X20 starts positioning operation according to the position and speed settings specified with the remote registers.



(3) Setting the point table No. with remote registers (incremental value command method)
The servo amplifier with station No. 2 is operated with the incremental value and point table No. 5 specified in the direct specification mode.
Set [Pr. PT62] to "___ 0" in advance.




2. POINT TABLE OPERATION

2.8 Program example for continuous operation

This section shows program examples including operations from servo start-up to a series of CC-Link IE communication. The examples use the following device configuration.

As shown below, a CC-Link system master/local module is mounted to operate one servo amplifier.



Input signal assignment

Input signal	Signal name	Operation at input ON
X20	Reset command	The servo amplifier is reset when an alarm has occurred.
X21	Servo-on command	The servo-on is activated.
X22	Forward rotation JOG command	When the manual operation mode is set, forward rotation JOG operation is performed.
X23	Reverse rotation JOG command	When the manual operation mode is set, reverse rotation JOG operation is performed.
X24	Automatic/manual selection	Off: Manual operation mode On: Automatic operation mode
X25	Home position return command	When the automatic operation mode is set and home position return has not been completed, the dog type home position return is performed.
X26	Proximity dog command	Off: Proximity dog ON (Note) On: Proximity dog OFF
X27	Position start command	When the automatic operation mode is set and home position return has been completed, positioning operation is performed according to the position and speed settings specified with the remote registers.
X28	Position/speed specifying method switching command	This signal enables the remote register-based position/speed specifying method.

Note. This setting is for when [Pr. PT29] is set to " _ _ _ 0" (Dog detection with off).


The servo amplifier with station No. 1 performs positioning operation and reads the servo motor speed data. Set [Pr. PT62] to " _ _ _ 2" in advance.

Operation: Alarm reset, dog type home position return, JOG operation, automatic operation with position command data and speed command data


Code No.	Description
H0016	32-bit motor speed data (hexadecimal)

Setting data	Description
K50000	Position command data (decimal)
K100	Speed command data (decimal)

2. POINT TABLE OPERATION



2. POINT TABLE OPERATION



[illegible]

3. PARAMETERS

3. PARAMETERS

CAUTION

- Never make a drastic adjustment or change to the parameter values as doing so will make the operation unstable.
- Do not change the parameter settings as described below. Doing so may cause an unexpected condition, such as failing to start up the servo amplifier.
 - Changing the values of the parameters for manufacturer setting
 - Setting a value out of the range
 - Changing the fixed values in the digits of a parameter
- When you write parameters with the controller, make sure that the station No. of the servo amplifier is set correctly. Otherwise, the parameter settings of another station may be written, possibly causing the servo amplifier to be an unexpected condition.

3.1 Parameter list

POINT

- | |
|--|
| <ul style="list-style-type: none">● The parameter whose symbol is preceded by * is enabled with the following conditions:<ul style="list-style-type: none">*: After setting the parameter, cycle the power or reset the controller.**: After setting the parameter, cycle the power.● Abbreviations of operation modes indicate the followings.<ul style="list-style-type: none">Standard: Standard (semi closed loop system) use of the rotary servo motorFull.: Fully closed loop system use of the rotary servo motorLin.: Linear servo motor useDD: Direct drive (DD) motor use |
|--|

Refer to chapter 5 in "MR-J4-_GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)" for the parameters with "Motion mode" in the detailed explanation field.

3. PARAMETERS

3.1.1 Basic setting parameters ([Pr. PA_ _])

No.	Symbol	Name	Initial value	Unit	Operation mode				Detailed explanation
					Standard	Full.	Lin.	DD	
PA01	**STY	Operation mode	1000h		○	○	○	○	Motion mode
PA02	**REG	Regenerative option	0000h		○	○	○	○	
PA03	*ABS	Absolute position detection system	0000h		○	○	○	○	
PA04	*AOP1	Function selection A-1	2000h		○	○	○	○	
PA05		For manufacturer setting	10000						Section 3.2.1
PA06	*CMX	Electronic gear numerator	1		○	○	○	○	
		Number of gear teeth on machine side	1		○			○	
PA07	*CDV	Electronic gear denominator	1		○	○	○	○	
		Number of gear teeth on servo motor side	1		○			○	
PA08	ATU	Auto tuning mode	0001h		○	○	○	○	Motion mode
PA09	RSP	Auto tuning response	16		○	○	○	○	
PA10	INP	In-position range	1600	[μm]/ 10 ⁻⁴ [inch]/ [pulse]	○	○	○	○	Section 3.2.1
PA11	TLP	Forward rotation torque limit/positive direction thrust limit	1000.0	[%]	○	○	○	○	Motion mode
PA12	TLN	Reverse rotation torque limit/negative direction thrust limit	1000.0	[%]	○	○	○	○	
PA13		For manufacturer setting	0000h						
PA14	*POL	Rotation direction selection/travel direction selection	0		○	○	○	○	
PA15	*ENR	Encoder output pulses	4000	[pulse/rev]	○	○	○	○	
PA16	*ENR2	Encoder output pulses 2	1		○	○	○	○	
PA17	**MSR	Servo motor series setting	0000h				○		
PA18	**MTY	Servo motor type setting	0000h				○		
PA19	*BLK	Parameter writing inhibit	00ABh		○	○	○	○	
PA20	*TDS	Tough drive setting	0000h		○	○	○	○	
PA21	*AOP3	Function selection A-3	0001h		○	○	○	○	
PA22	**PCS	Position control composition selection	0000h		○	○	○	○	
PA23	DRAT	Drive recorder arbitrary alarm trigger setting	0000h		○	○	○	○	
PA24	AOP4	Function selection A-4	0000h		○	○	○	○	
PA25	OTHOV	One-touch tuning - Overshoot permissible level	0	[%]	○	○	○	○	
PA26	*AOP5	Function selection A-5	0000h		○	○	○	○	
PA27		For manufacturer setting	0000h						
PA28			0000h						
PA29			0000h						
PA30			0000h						
PA31			0000h						
PA32			0000h						

3. PARAMETERS

3.1.2 Gain/filter setting parameters ([Pr. PB_ _])

No.	Symbol	Name	Initial value	Unit	Operation mode				Detailed explanation
					Standard	Full.	Lin.	DD	
PB01	FILT	Adaptive tuning mode (adaptive filter II)	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	Motion mode
PB02	VRFT	Vibration suppression control tuning mode (advanced vibration suppression control II)	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB03		For manufacturer setting	18000		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB04	FFC	Feed forward gain	0	[%]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB05		For manufacturer setting	500		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB06	GD2	Load to motor inertia ratio/load to motor mass ratio	7.00	[Multiplier]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB07	PG1	Model loop gain	15.0	[rad/s]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB08	PG2	Position loop gain	37.0	[rad/s]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB09	VG2	Speed loop gain	823	[rad/s]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB10	VIC	Speed integral compensation	33.7	[ms]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB11	VDC	Speed differential compensation	980		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB12	OVA	Overshoot amount compensation	0	[%]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB13	NH1	Machine resonance suppression filter 1	4500	[Hz]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB14	NHQ1	Notch shape selection 1	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB15	NH2	Machine resonance suppression filter 2	4500	[Hz]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB16	NHQ2	Notch shape selection 2	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB17	NHF	Shaft resonance suppression filter	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB18	LPF	Low-pass filter setting	3141	[rad/s]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB19	VRF11	Vibration suppression control 1 - Vibration frequency	100.0	[Hz]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB20	VRF12	Vibration suppression control 1 - Resonance frequency	100.0	[Hz]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB21	VRF13	Vibration suppression control 1 - Vibration frequency damping	0.00		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB22	VRF14	Vibration suppression control 1 - Resonance frequency damping	0.00		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB23	VFBF	Low-pass filter selection	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB24	*MVS	Slight vibration suppression control	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB25	*BOP1	Function selection B-1	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB26	*CDP	Gain switching function	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB27	CDL	Gain switching condition	10	[kpulse/s]/ [pulse]/ [r/min]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB28	CDT	Gain switching time constant	1	[ms]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB29	GD2B	Load to motor inertia ratio/load to motor mass ratio after gain switching	7.00	[Multiplier]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB30	PG2B	Position loop gain after gain switching	0.0	[rad/s]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB31	VG2B	Speed loop gain after gain switching	0	[rad/s]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB32	VICB	Speed integral compensation after gain switching	0.0	[ms]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB33	VRF11B	Vibration suppression control 1 - Vibration frequency after gain switching	0.0	[Hz]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB34	VRF12B	Vibration suppression control 1 - Resonance frequency after gain switching	0.0	[Hz]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB35	VRF13B	Vibration suppression control 1 - Vibration frequency damping after gain switching	0.00		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB36	VRF14B	Vibration suppression control 1 - Resonance frequency damping after gain switching	0.00		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB37		For manufacturer setting	1600		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB38			0.00		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB39			0.00		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB40			0.00		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB41			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB42			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB43			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB44			0.00		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PB45	CNHF	Command notch filter	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

3. PARAMETERS

No.	Symbol	Name	Initial value	Unit	Operation mode				Detailed explanation
					Standard	Full.	Lin.	DD	
PB46	NH3	Machine resonance suppression filter 3	4500	[Hz]	○	○	○	○	Motion mode
PB47	NHQ3	Notch shape selection 3	0000h		○	○	○	○	
PB48	NH4	Machine resonance suppression filter 4	4500	[Hz]	○	○	○	○	
PB49	NHQ4	Notch shape selection 4	0000h		○	○	○	○	
PB50	NH5	Machine resonance suppression filter 5	4500	[Hz]	○	○	○	○	
PB51	NHQ5	Notch shape selection 5	0000h		○	○	○	○	
PB52	VRF21	Vibration suppression control 2 - Vibration frequency	100.0	[Hz]	○	○	○	○	
PB53	VRF22	Vibration suppression control 2 - Resonance frequency	100.0	[Hz]	○	○	○	○	
PB54	VRF23	Vibration suppression control 2 - Vibration frequency damping	0.00		○	○	○	○	
PB55	VRF24	Vibration suppression control 2 - Resonance frequency damping	0.00		○	○	○	○	
PB56	VRF21B	Vibration suppression control 2 - Vibration frequency after gain switching	0.0	[Hz]	○	○	○	○	
PB57	VRF22B	Vibration suppression control 2 - Resonance frequency after gain switching	0.0	[Hz]	○	○	○	○	
PB58	VRF23B	Vibration suppression control 2 - Vibration frequency damping after gain switching	0.00		○	○	○	○	
PB59	VRF24B	Vibration suppression control 2 - Resonance frequency damping after gain switching	0.00		○	○	○	○	
PB60	PG1B	Model loop gain after gain switching	0.0	[rad/s]	○	○	○	○	
PB61		For manufacturer setting	0.0						
PB62			0000h						
PB63			0000h						
PB64			0000h						

3.1.3 Extension setting parameters ([Pr. PC_ _])

No.	Symbol	Name	Initial value	Unit	Operation mode				Detailed explanation
					Standard	Full.	Lin.	DD	
PC01	ERZ	Error excessive alarm level	0	[rev]/[mm]	○	○	○	○	Motion mode
PC02	MBR	Electromagnetic brake sequence output	0	[ms]	○	○	○	○	
PC03	*ENRS	Encoder output pulse selection	0000h		○	○	○	○	
PC04	**COP1	Function selection C-1	0000h		○	○	○	○	
PC05	**COP2	Function selection C-2	0000h		○	○	○	○	
PC06	*COP3	Function selection C-3	0000h		○	○	○	○	
PC07	ZSP	Zero speed	50	[r/min]/[mm/s]	○	○	○	○	
PC08	OSL	Overspeed alarm detection level	0	[r/min]/[mm/s]	○	○	○	○	
PC09	MOD1	Analog monitor 1 output	0000h		○	○	○	○	
PC10	MOD2	Analog monitor 2 output	0001h		○	○	○	○	
PC11	MO1	Analog monitor 1 offset	0	[mV]	○	○	○	○	
PC12	MO2	Analog monitor 2 offset	0	[mV]	○	○	○	○	
PC13		For manufacturer setting	0						
PC14			0						
PC15			0						
PC16			0000h						
PC17	**COP4	Function selection C-4	0000h		○	○	○	○	
PC18	*COP5	Function selection C-5	0010h		○	○	○	○	
PC19	*COP6	Function selection C-6	0000h		○	○	○	○	
PC20	*COP7	Function selection C-7	0000h		○	○	○	○	

3. PARAMETERS

No.	Symbol	Name	Initial value	Unit	Operation mode				Detailed explanation
					Standard	Full.	Lin.	DD	
PC21	*BPS	Alarm history clear	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	Motion mode
PC22		For manufacturer setting	0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC23			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC24	RSBR	Forced stop deceleration time constant	100	[ms]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC25		For manufacturer setting	0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC26		Function selection C-8	0000h		(Note) <input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC27	**COP9	Function selection C-9	0000h		(Note) <input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC28		For manufacturer setting	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC29		Function selection C-B	1000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC30		For manufacturer setting	0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC31	RSUP1	Vertical axis freefall prevention compensation amount	0	[0.0001 rev]/ [0.01 mm]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC32		For manufacturer setting	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC33			0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC34			100		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC35			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC36			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC37			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC38	ERW	Error excessive warning level	0	[rev]/[mm]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC39		For manufacturer setting	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC40			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC41			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC42			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC43			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC44			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC45			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC46			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC47			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC48			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC49			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC50			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC51			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC52			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC53			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC54			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC55			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC56			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC57			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC58			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC59			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC60			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC61			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC62			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC63			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC64			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC65			50.00		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC66			10		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC67	FEWL	Following error output level	0000h	[pulse]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC68	FEWH		00C0h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PC69	FEWF	Following error output filtering time	10	[ms]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

3. PARAMETERS

No.	Symbol	Name	Initial value	Unit	Operation mode				Detailed explanation
					Standard	Full.	Lin.	DD	
PC70		For manufacturer setting	100						Motion mode
PC71			10						
PC72			20.00						
PC73			10						
PC74			10.0						
PC75			10						
PC76	*COPE	Function selection C-E	0001h	[%]	○	○	○	○	Section 3.2.2
PC77	TL2	Internal torque limit 2	0.0		○			○	
PC78		For manufacturer setting	0000h						Motion mode
PC79			0000h						
PC80			0000h						

Note. It is available when the scale measurement function is enabled ([Pr. PA22] is "1 ___" or "2 ___").

3. PARAMETERS

3.1.4 I/O setting parameters ([Pr. PD_ _])

No.	Symbol	Name	Initial value	Unit	Operation mode				Detailed explanation
					Standard	Full.	Lin.	DD	
PD01	*DIA1	Input signal automatic on selection 1	0000h		○	○	○	○	Motion mode
PD02		For manufacturer setting	0000h		○	○	○	○	
PD03	*DI1	Input device selection 1	000Ah		○	○	○	○	
PD04	*DI2	Input device selection 2	000Bh		○	○	○	○	
PD05	*DI3	Input device selection 3	0022h		○	○	○	○	
PD06		For manufacturer setting	0000h		○	○	○	○	
PD07	*DO1	Output device selection 1	0005h		○	○	○	○	
PD08	*DO2	Output device selection 2	0004h		○	○	○	○	
PD09	*DO3	Output device selection 3	0003h		○	○	○	○	
PD10		For manufacturer setting	0000h		○	○	○	○	
PD11	*DIF	Input filter setting	0004h		○	○	○	○	
PD12	*DOP1	Function selection D-1	0101h		○	○	○	○	Section 3.2.3
PD13	*DOP2	Function selection D-2	0000h		○	○	○	○	Motion mode
PD14	*DOP3	Function selection D-3	0000h		○	○	○	○	
PD15		For manufacturer setting	0000h						
PD16			0000h						
PD17			0000h						
PD18			0000h						
PD19			0000h						
PD20			0						
PD21			0						
PD22			0						
PD23			0						
PD24			0000h						
PD25			0000h						
PD26			0000h						
PD27			0000h						
PD28			0000h						
PD29			0000h						
PD30			0						
PD31			0						
PD32			0						
PD33			0000h						
PD34			0000h						
PD35			0000h						
PD36			0000h						
PD37	*TPOP	Touch probe function selection	0000h		○	○	○	○	
PD38		For manufacturer setting	002Ch						
PD39			002Dh						
PD40			0						
PD41	*DOP4	Function selection D-4	0000h		○	○	○	○	
PD42		For manufacturer setting	0000h						
PD43			0000h						
PD44			0000h						
PD45			0000h						
PD46			0000h						
PD47			0000h						
PD48			0000h						

3. PARAMETERS

3.1.5 Extension setting 2 parameters ([Pr. PE_ _])

No.	Symbol	Name	Initial value	Unit	Operation mode				Detailed explanation
					Standard	Full.	Lin.	DD	
PE01	**FCT1	Fully closed loop function selection 1	0000h			○			Motion mode
PE02		For manufacturer setting	0000h						
PE03	*FCT2	Fully closed loop function selection 2	0003h			○			
PE04	**FBN	Fully closed loop control - Feedback pulse electronic gear 1 - Numerator	1			○			
PE05	**FBD	Fully closed loop control - Feedback pulse electronic gear 1 - Denominator	1			○			
PE06	BC1	Fully closed loop control - Speed deviation error detection level	400	[r/min]		○			
PE07	BC2	Fully closed loop control - Position deviation error detection level	100	[kpulse]		○			
PE08	DUF	Fully closed loop dual feedback filter	10	[rad/s]		○			
PE09		For manufacturer setting	0000h						
PE10	FCT3	Fully closed loop function selection 3	0000h			○			
PE11		For manufacturer setting	0000h						
PE12			0000h						
PE13			0000h						
PE14			0111h						
PE15			20						
PE16			0000h						
PE17			0000h						
PE18			0000h						
PE19			0000h						
PE20			0000h						
PE21			0000h						
PE22			0000h						
PE23			0000h						
PE24			0000h						
PE25			0000h						
PE26			0000h						
PE27			0000h						
PE28			0000h						
PE29			0000h						
PE30			0000h						
PE31			0000h						
PE32			0000h						
PE33			0000h						
PE34	**FBN2	Fully closed loop control - Feedback pulse electronic gear 2 - Numerator	1			○			
PE35	**FBD2	Fully closed loop control - Feedback pulse electronic gear 2 - Denominator	1			○			
PE36		For manufacturer setting	0.0						
PE37			0.00						
PE38			0.00						
PE39			20						
PE40			0000h						
PE41	EOP3	Function selection E-3	0000h		○	○	○	○	

3. PARAMETERS

No.	Symbol	Name	Initial value	Unit	Operation mode				Detailed explanation
					Standard	Full.	Lin.	DD	
PE42		For manufacturer setting	0						Motion mode
PE43			0.0						
PE44	LMCP	Lost motion compensation positive-side compensation value selection	0	[0.01%]	○	○	○	○	
PE45	LMCN	Lost motion compensation negative-side compensation value selection	0	[0.01%]	○	○	○	○	
PE46	LMFLT	Lost motion filter setting	0	[0.1 ms]	○	○	○	○	
PE47	TOF	Torque offset	0	[0.01%]	○	○			
PE48	*LMOP	Lost motion compensation function selection	0000h		○	○	○	○	
PE49	LMCD	Lost motion compensation timing	0	[0.1 ms]	○	○	○	○	
PE50	LMCT	Lost motion compensation non-sensitive band	0	[pulse]/ [kpulse]	○	○	○	○	
PE51		For manufacturer setting	0000h						
PE52			0000h						
PE53			0000h						
PE54			0000h						
PE55			0000h						
PE56			0000h						
PE57			0000h						
PE58			0000h						
PE59			0000h						
PE60			0000h						
PE61			0.00						
PE62			0.00						
PE63			0.00						
PE64			0.00						

3.1.6 Extension setting 3 parameters ([Pr. PF_ _])

No.	Symbol	Name	Initial value	Unit	Operation mode				Detailed explanation
					Standard	Full.	Lin.	DD	
PF01		For manufacturer setting	0000h						Motion mode
PF02			0000h						
PF03			0000h						
PF04			0						
PF05			0000h						
PF06	*FOP5	Function selection F-5	0000h		○	○			
PF07		For manufacturer setting	0000h						
PF08			0000h						
PF09			0						
PF10			0						
PF11			0						
PF12	DBT	Electronic dynamic brake operating time	2000	[ms]	○	○			
PF13		For manufacturer setting	0000h						
PF14			10						
PF15			0000h						
PF16			0000h						
PF17			0000h						

3. PARAMETERS

No.	Symbol	Name	Initial value	Unit	Operation mode				Detailed explanation
					Standard	Full.	Lin.	DD	
PF18	**STOD	STO diagnosis error detection time	10	[s]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	Motion mode
PF19	TSL	Friction failure prediction - Compensation coefficient 1	0	[0.001%/°C]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF20	TIC	Friction failure prediction - Compensation coefficient 2	0	[0.1%]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF21	DRT	Drive recorder switching time setting	0	[s]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF22		For manufacturer setting	200		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF23	OSCL1	Vibration tough drive - Oscillation detection level	50	[%]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF24	*OSCL2	Vibration tough drive function selection	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF25	CVAT	SEMI-F47 function - Instantaneous power failure detection time	200	[ms]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF26		For manufacturer setting	0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF27			0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF28			0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF29		For manufacturer setting	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF30			0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF31	FRIC	Machine diagnosis function - Friction judgement speed	0	[r/min]/ [mm/s]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF32		For manufacturer setting	50		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF33			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF34	*MFP	Machine diagnosis function selection	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF35		For manufacturer setting	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF36			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF37			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF38			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF39			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF40	MFPP	Friction failure prediction parameter	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF41	FPMT	Failure prediction - Servo motor total travel distance	0	[rev]/[m]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF42	PAV	Friction failure prediction - Average characteristic	0	[0.1%]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF43	PSD	Friction failure prediction - Standard deviation	0	[0.1%]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF44		For manufacturer setting	0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF45	VAV	Vibration failure prediction - Average characteristic	0	[0.1%]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF46	VSD	Vibration failure prediction - Standard deviation	0	[0.1%]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF47		For manufacturer setting	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF48			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF49			100		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF50			100		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF51			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF52			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF53			0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF54			0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF55			0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF56			0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF57			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF58			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF59			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF60			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF61			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF62			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF63			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PF64			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

3. PARAMETERS

3.1.7 Linear servo motor/DD motor setting parameters ([Pr. PL_ _])

No.	Symbol	Name	Initial value	Unit	Operation mode				Detailed explanation
					Standard	Full.	Lin.	DD	
PL01	**LIT1	Linear servo motor/DD motor function selection 1	0301h				○	○	Motion mode
PL02	**LIM	Linear encoder resolution - Numerator	1000	[μm]			○		
PL03	**LID	Linear encoder resolution - Denominator	1000	[μm]			○		
PL04	*LIT2	Linear servo motor/DD motor function selection 2	0003h				○	○	
PL05	LB1	Position deviation error detection level	0	[mm]/ [0.01 rev]			○	○	
PL06	LB2	Speed deviation error detection level	0	[mm/s]/ [r/min]			○	○	
PL07	LB3	Torque/thrust deviation error detection level	100	[%]			○	○	
PL08	*LIT3	Linear servo motor/DD motor function selection 3	0010h				○	○	
PL09	LPWM	Magnetic pole detection voltage level	30	[%]			○	○	
PL10		For manufacturer setting	5						
PL11			100						
PL12			500						
PL13			0000h						
PL14			0000h						
PL15			20						
PL16			0						
PL17	LTSTS	Magnetic pole detection - Minute position detection method - Function selection	0000h				○	○	
PL18	IDLV	Magnetic pole detection - Minute position detection method - Identification signal amplitude	0	[%]			○	○	
PL19		For manufacturer setting	0						
PL20			0						
PL21			0						
PL22			0						
PL23			0000h						
PL24			0						
PL25			0000h						
PL26			0000h						
PL27			0000h						
PL28			0000h						
PL29			0000h						
PL30			0000h						
PL31			0000h						
PL32			0000h						
PL33			0000h						
PL34			0000h						
PL35			0000h						
PL36			0000h						
PL37			0000h						
PL38			0000h						
PL39			0000h						
PL40			0000h						
PL41			0000h						
PL42			0000h						
PL43			0000h						
PL44			0000h						
PL45			0000h						

3. PARAMETERS

No.	Symbol	Name	Initial value	Unit	Operation mode				Detailed explanation
					Standard	Full.	Lin.	DD	
PL46		For manufacturer setting	0000h						Motion mode
PL47			0000h						
PL48			0000h						

3.1.8 Positioning control parameters ([Pr. PT_ _])

No.	Symbol	Name	Initial value	Unit	Operation mode				Detailed explanation
					Standard	Full.	Lin.	DD	
PT01	**CTY	Command mode selection	0300h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	Section 3.2.4
PT02		For manufacturer setting	0001h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT03		Feeding function selection	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT04		For manufacturer setting	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	Motion mode
PT05		Home position return speed	100.00		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT06	CRF	Creep speed	10.00		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT07	ZST	Home position shift distance	0	$\mu\text{m}/10^{-4} [\text{inch}]/[\text{pulse}]$	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	Section 3.2.4
PT08		For manufacturer setting	0	$10^{\text{STM}} \mu\text{m}/10^{(\text{STM}-4)} [\text{inch}]/[\text{pulse}]$	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT09		Travel distance after proximity dog	0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT10	ZTM	Stopper type home position return stopper time	100	[ms]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	Motion mode
PT11	ZTT	Stopper type home position return torque limit value	15.0	[%]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT12	CRP	Rough match output range	0	$10^{\text{STM}} \mu\text{m}/10^{(\text{STM}-4)} [\text{inch}]/[\text{pulse}]$	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	Section 3.2.4
PT13		For manufacturer setting	100		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT14			0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT15	LMPL	Software limit +	0000h	$10^{\text{STM}} \mu\text{m}/10^{(\text{STM}-4)} [\text{inch}]/[\text{pulse}]$	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT16	LMPH		0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT17	LMNL	Software limit -	0000h	$10^{\text{STM}} \mu\text{m}/10^{(\text{STM}-4)} [\text{inch}]/[\text{pulse}]$	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT18	LMNH		0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT19	*LPPL	Position range output address +	0000h	$10^{\text{STM}} \mu\text{m}/10^{(\text{STM}-4)} [\text{inch}]/[\text{pulse}]$	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT20	*LPPH		0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT21	*LNPL	Position range output address -	0000h	$10^{\text{STM}} \mu\text{m}/10^{(\text{STM}-4)} [\text{inch}]/[\text{pulse}]$	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT22	*LNPH		0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT23		For manufacturer setting	0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT24			0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT25			0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT26			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT27	*ODM	Indexer method - Operation mode selection	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT28	*STN	Number of stations per rotation	8	[stations]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT29	*TOP3	Function selection T-3	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT30		For manufacturer setting	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
PT31			0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

3. PARAMETERS

No.	Symbol	Name	Initial value	Unit	Operation mode				Detailed explanation
					Standard	Full.	Lin.	DD	
PT32		For manufacturer setting	0000h						Section 3.2.4
PT33		0000h							
PT34	*PDEF	Point table default	0000h		○	○	○	○	
PT35	*TOP5	Function selection T-5	0000h		○	○	○	○	
PT36		For manufacturer setting	0000h						
PT37		10							
PT38		0000h							
PT39	INT	Torque limit delay time	100	[ms]	○			○	
PT40	*SZS	Station home position shift distance	0	[pulse]	○			○	
PT41	ORP	Home position return inhibit function selection	0000h		○	○	○	○	Motion mode
PT42		For manufacturer setting	0						
PT43		0							
PT44		0000h							
PT45	HMM	Home position return type	37		○	○	○	○	
PT46		For manufacturer setting	0000h						
PT47		0000h							
PT48		0000h							
PT49	STA	Acceleration time constant	0	[ms]	○	○	○	○	Section 3.2.4
PT50	STB	Deceleration time constant	0	[ms]	○	○	○	○	
PT51	STC	S-pattern acceleration/deceleration time constant	0	[ms]	○	○	○	○	
PT52		For manufacturer setting	0						Motion mode
PT53		0.0							
PT54		0							
PT55	*TOP8	Function selection T-8	0000h		○		○	○	
PT56	HMA	Home position return acceleration time constant	0	[ms]	○		○	○	
PT57	HMB	Home position return deceleration time constant	0	[ms]	○		○	○	
PT58		For manufacturer setting	100.00						Section 3.2.4
PT59		500.00							
PT60		1000.00							
PT61		200.00							
PT62	*DSS	Remote register-based position/speed specifying method selection	0000h		○	○	○	○	
PT63		For manufacturer setting	0000h						Motion mode
PT64		0000h							
PT65	PVC	Jog speed command	100.00	[r/min]/ [mm/s]	○	○	○	○	Section 3.2.4
PT66		For manufacturer setting	20000.00						Motion mode
PT67	VLMT	Speed limit	500.00	[r/min]/ [mm/s]	○	○	○	○	
PT68		For manufacturer setting	0102h						
PT69	ZSTH	Home position shift distance (extension parameter)	0	[μm]/ 10 ⁻⁴ [inch]/ [pulse]	○	○	○	○	Section 3.2.4
PT70		For manufacturer setting	0000h						Motion mode
PT71	DCTH	Travel distance after proximity dog (extension parameter)	0	10 ^{STM} [μm]/ 10 ^(STM-4) [inch]/ [pulse]	○	○	○	○	Section 3.2.4

3. PARAMETERS

No.	Symbol	Name	Initial value	Unit	Operation mode				Detailed explanation
					Standard	Full.	Lin.	DD	
PT72		For manufacturer setting	0000h						Motion mode
PT73			0000h						
PT74			0000h						
PT75			0000h						
PT76			0000h						
PT77			0000h						
PT78			0000h						
PT79			0000h						
PT80			0000h						

3.1.9 Network setting parameters ([Pr. PN_ _])

No.	Symbol	Name	Initial value	Unit	Operation mode				Detailed explanation
					Standard	Full.	Lin.	DD	
PN01	CERT	For manufacturer setting	0	[ms]	○	○	○	○	Motion mode
PN02		Communication error detection time	0						
PN03	**NWMD	Communication mode setting for CC-Link IE communication	0000h		○	○	○	○	Section 3.2.5
PN04	**NWNO	CC-Link IE communication network number	0		○	○	○	○	Motion mode
PN05	CERI	Communication error detection frequency setting	0	[%]	○	○	○	○	
PN06	NOP1	Function selection N-1	0000h		○	○	○	○	Section 3.2.5
PN07		For manufacturer setting	0000h						Motion mode
PN08			0000h						
PN09			0000h						
PN10			0000h						
PN11			0000h						
PN12			0000h						
PN13			0000h						
PN14			0000h						
PN15			0000h						
PN16			0000h						
PN17			0000h						
PN18			0000h						
PN19			0000h						
PN20			0000h						
PN21			0000h						
PN22			0000h						
PN23			0000h						
PN24			0000h						
PN25			0000h						
PN26			0000h						
PN27			0000h						
PN28			0000h						
PN29			0000h						
PN30			0000h						
PN31			0000h						
PN32			0000h						

3. PARAMETERS

3.2 Detailed list of parameters

POINT
<ul style="list-style-type: none"> ● For parameters which are not described in this section, refer to chapter 5 of "MR-J4- _GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)". ● Set a value to each "x" in the "Setting digit" columns.

3.2.1 Basic setting parameters ([Pr. PA_ _])

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				CP	PS
PA01 **STY Operation mode	___x	Control mode selection Select a control mode. 0: Positioning mode (point table method) 8: Positioning mode (indexer method) When Pr. PN03] is "___1", the above setting is enabled. When [Pr. PN03] is "___0", refer to "MR-J4- _GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)". This digit is available with servo amplifier with software version A3 or later.	0h	<input type="radio"/>	<input type="radio"/>
	__x_	Operation mode selection 0: Standard control mode 1: Fully closed loop control mode 4: Linear servo motor control mode 6: DD motor control mode The following settings will trigger [AL. 37 Parameter error]. • A value other than "0", "1", "4", and "6" is set to this digit. • When set to Positioning mode (indexer method), a value other than "0" and "6" is set to this digit.	0h	<input type="radio"/>	<input type="radio"/>
	_x__	For manufacturer setting	0h		
	x___		1h		
PA06 *CMX Electronic gear numerator		Set an electronic gear numerator. (Refer to section 3.3.1.) Set the electronic gear within the following range. Setting out of the range will trigger [AL. 37 Parameter error]. $1/865 < CMX/CDV < 2717471$ Setting range: 1 to 16777215	1	<input type="radio"/>	
PA06 *CMX Number of gear teeth on machine side		Set the number of gear teeth on machine side. (Refer to section 3.3.2.) Set the electronic gear within the following range. Setting a value out of the setting range will trigger [AL. 37 Parameter error]. This parameter setting is used with servo amplifier with software version A3 or later. (1) $1 \leq CMX \leq 16384$, $1 \leq CDV \leq 16384$ (2) $\frac{1}{9999} \leq \frac{CMX}{CDV} \leq 9999$ (3) $CDV \times STN \leq 32767$ (STN: Number of stations per rotation [Pr. PT28]) (4) $CMX \times CDV \leq 100000$ When a small value is set to the electronic gear ratio with the manual operation mode, the servo motor may not drive at the set servo motor speed. Travel distance of 1 station = Pt (servo motor resolution) $\times \frac{1}{STN} \times \frac{CMX}{CDV}$ Setting range: 1 to 16777215	1		<input type="radio"/>

3. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				CP	PS
PA07 *CDV Electronic gear numerator		Set an electronic gear denominator. (Refer to section 3.3.1.) Set the electronic gear within the range of [Pr. PA06]. Setting out of the range will trigger [AL. 37 Parameter error]. Setting range: 1 to 16777215	1	○	
PA07 *CDV Number of gear teeth on servo motor side		Set the number of gear teeth on servo motor side. (Refer to section 3.3.2.) Set the electronic gear within the range of [Pr. PA06]. Setting a value out of the setting range will trigger [AL. 37 Parameter error]. This parameter setting is used with servo amplifier with software version A3 or later. Setting range: 1 to 16777215	1		○
PA10 INP In-position range		Set an in-position range per command pulse. To change it to the servo motor encoder pulse unit, set [Pr. PC06]. In the I/O mode, the in-position range is the range where RXnC (Travel completion) and RXn1 (In-position) are outputted. The unit will be as follows depending on the positioning mode. <ul style="list-style-type: none"> Point table method When [Pr. PC06] is set to "___ 0", the unit can be changed to [μm], 10-4 [inch] or [pulse] with the setting of [Pr. PT01]. When [Pr. PC06] is set to "___ 1", the unit is fixed to [pulse]. Indexer method It will be command unit [pulse]. (a load-side rotation expressed by the number of encoder resolution pulses) For example, when making an in-position range "± 1 degree" for the rotation angle on the load side, set $4194304 \times (1/360) = 11650$ pulses. The indexer method can be used with servo amplifiers with software version A3 or later. Setting range: 0 to 65535	1600 Refer to Function column for unit.	○	○

3.2.2 Extension setting parameters ([Pr. PC__ _])

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				CP	PS
PC77 TL2 Internal torque limit 2		The parameter is set for limiting the torque of the servo motor. Set rated torque to 100.0%. No torque is generated when this parameter is set to "0.0". While automatic operation, manual operation and home position return operation is stopped, this parameter is enabled. During operation, the setting value of [Pr. PA11] and [Pr. PA12] is enabled. This parameter is available with servo amplifiers with software version A3 or later. Setting range: 0.0 to 1000.0	0.0 [%]		○

3. PARAMETERS

3.2.3 I/O setting parameters ([Pr. PD_ _])

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode															
				CP	PS														
PD12 *DOP1 Function selection D-1	___ x	Stop method selection at stroke limit detection Select a stop method for RY (n + 1) 0 (Upper stroke limit) off or RY (n + 1) 1 (Lower stroke limit) off. (Refer to section 3.4.)	1h	<input type="radio"/>	<input type="radio"/>														
		<table border="1"><tr><th rowspan="2">Setting value</th><th colspan="2">Control mode</th></tr><tr><th>CP</th><th>PS</th></tr><tr><td>1</td><td colspan="2">Slow stop</td></tr><tr><td>2</td><td>Slow stop (deceleration to a stop by deceleration time constant)</td><td></td></tr><tr><td>3</td><td>Quick stop (stop by clearing remaining distance)</td><td></td></tr></table>				Setting value	Control mode		CP	PS	1	Slow stop		2	Slow stop (deceleration to a stop by deceleration time constant)		3	Quick stop (stop by clearing remaining distance)	
		Setting value					Control mode												
						CP	PS												
1	Slow stop																		
2	Slow stop (deceleration to a stop by deceleration time constant)																		
3	Quick stop (stop by clearing remaining distance)																		
Setting a value other than the value listed in the setting value field will trigger [AL. 37].																			
__ x _	For manufacturer setting	0h																	
_ x _ _	Stop method selection at software limit detection Select a stop method selection at software limit detection. (Refer to section 3.5.) 1: Slow stop 2: Slow stop (deceleration to a stop by deceleration time constant) 3: Quick stop (stop by clearing remaining distance) Setting "0" will trigger [AL. 37].	1h	<input type="radio"/>																
x _ _ _	Servo motor thermistor enabled/disabled selection 0: Enabled 1: Disabled For servo motors without thermistor, the setting will be disabled.	0h	<input type="radio"/>	<input type="radio"/>															

3. PARAMETERS

3.2.4 Positioning control parameters ([Pr. PT_ _])

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				CP	PS
PT01 **CTY Command mode selection	___ x	Positioning command method selection 0: Absolute value command method 1: Incremental value command method	0h	○	
	__ x _	For manufacturer setting	0h		
	_ x _ _	Position data unit 0: mm 1: inch 3: pulse	3h	○	
	x _ _ _	For manufacturer setting	0h		
PT03 *FTY Feeding function selection	___ x	Feed length multiplication (STM) 0: × 1 1: × 10 2: × 100 3: × 1000 This digit will be disabled when [pulse] of "Position data unit" is set in [Pr. PT01].	0h	○	
	__ x _	For manufacturer setting	0h		
	_ x _ _		0h		
	x _ _ _		0h		
PT07 ZST Home position shift distance		Set a shift distance from the Z-phase pulse detection position in the encoder. Up to 2^{31} can be set with [Pr. PT69]. The unit will be as follows depending on the positioning mode. • Point table method It will be change to [μm], 10^{-4} [inch], or [pulse] with [Pr. PT01]. • Indexer method It will be command unit [pulse]. (unit of a load-side rotation expressed by the number of servo motor resolution pulses) Refer to the Function column of [Pr. PA10] for the command unit. The indexer method is available with servo amplifiers with software version A3 or later. Setting range: 0 to 65535	0 Refer to Function column for unit.		
PT09 DCT Travel distance after proximity dog		Set a travel distance after proximity dog for the count type home position return (front end detection, Z-phase reference) (Homing method -2, -34) and the following dog reference home position returns. The following shows the home position return of the dog reference. • Dog type rear end reference home position return (Homing method -6, -38) • Count type home position return (Front end reference) (Homing method -7, -39) • Dog type front end reference home position return (Homing method -10, -42) • Homing without index pulse (Homing method 19, 20, 21, 22, 23, 24, 27, 28) Up to 2^{31} can be set with [Pr. PT71]. The unit can be changed to 10^{STM} [μm], $10^{(\text{STM}-4)}$ [inch], or [pulse] with the setting of [Pr. PT01]. Setting range: 0 to 65535	0 Refer to Function column for unit.	○	
PT12 CRP Rough match output range		Set a range of the command remaining distance which outputs rough match. The unit will be as follows depending on the positioning mode. • Point table method It will be change to [μm], 10^{-4} [inch], or [pulse] with [Pr. PT01]. • Indexer method It will be command unit [pulse]. (unit of a load-side rotation expressed by the number of servo motor resolution pulses) Refer to the Function column of [Pr. PA10] for the command unit. The indexer method is available with servo amplifiers with software version A3 or later. Setting range: 0 to 65535	0 Refer to Function column for unit.	○	○

3. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				CP	PS
PT15 LMPL Software limit + (lower four digits)		Set an address increasing side of the software stroke limit. Upper and lower are a set. Set the setting address in hexadecimal. Setting address: <div><div><div>Upper four digits</div><div>Lower four digits</div></div><div><div>[Pr. PT15]</div><div>[Pr. PT16]</div></div></div>	0000h Refer to Function column for unit.	○	
PT16 LMPH Software limit + (upper four digits)		Setting a same value with "Software limit -" will disable the software limit. (Refer to section 5.3 of "MR-J4- _GF_ (-RJ) Servo Amplifier Instruction Manual (Motion Mode)".) When changing the parameter setting with MR Configurator2, change it during servo-off or in the home position return mode. The unit can be changed to 10 ^{STM} [μm], 10 ^(STM-4) [inch], or [pulse] with the setting of [Pr. PT01]. Setting range: 0000h 0000h to FFFFh FFFFh	0000h Refer to Function column for unit.		
PT17 LMNL Software limit - (lower four digits)		Set an address decreasing side of the software stroke limit. Upper and lower are a set. Set the setting address in hexadecimal. Setting address: <div><div><div>Upper four digits</div><div>Lower four digits</div></div><div><div>[Pr. PT17]</div><div>[Pr. PT18]</div></div></div>	0000h Refer to Function column for unit.	○	
PT18 LMNH Software limit - (upper four digits)		Setting a same value with "Software limit +" will disable the software limit. (Refer to section 5.3 of "MR-J4- _GF_ (-RJ) Servo Amplifier Instruction Manual (Motion Mode)".) When changing the parameter setting with MR Configurator2, change it during servo-off or in the home position return mode. The unit can be changed to 10 ^{STM} [μm], 10 ^(STM-4) [inch], or [pulse] with the setting of [Pr. PT01]. Setting range: 0000h 0000h to FFFFh FFFFh	0000h Refer to Function column for unit.		

3. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				CP	PS
PT19 *LPPL Position range output address + (lower four digits)		Set an address increasing side of the position range output address. Upper and lower are a set. Set a range which RXnE (Position range) turns on with [Pr. PT19] to [Pr. PT22]. Setting address: <div style="display: flex; justify-content: center; align-items: center; margin-top: 10px;"> <div style="border-bottom: 1px solid black; width: 100px; text-align: center;">Upper four digits</div> <div style="border-bottom: 1px solid black; width: 100px; text-align: center;">Lower four digits</div> </div> <div style="display: flex; justify-content: center; margin-top: 10px;"> <div style="margin-right: 100px;">└─┘</div> <div>└─┘ [Pr. PT19]</div> </div> <div style="display: flex; justify-content: center; margin-top: 10px;"> <div style="margin-right: 100px;">└─┘</div> <div>└─┘ [Pr. PT20]</div> </div>	0000h Refer to Function column for unit.	○	
PT20 *LPPH Position range output address + (upper four digits)			0000h Refer to Function column for unit.		
PT21 *LNPL Position range output address - (lower four digits)		Set an address decreasing side of the position range output address. Upper and lower are a set. Set a range which RXnE (Position range) turns on with [Pr. PT19] to [Pr. PT22]. Setting address: <div style="display: flex; justify-content: center; align-items: center; margin-top: 10px;"> <div style="border-bottom: 1px solid black; width: 100px; text-align: center;">Upper four digits</div> <div style="border-bottom: 1px solid black; width: 100px; text-align: center;">Lower four digits</div> </div> <div style="display: flex; justify-content: center; margin-top: 10px;"> <div style="margin-right: 100px;">└─┘</div> <div>└─┘ [Pr. PT21]</div> </div> <div style="display: flex; justify-content: center; margin-top: 10px;"> <div style="margin-right: 100px;">└─┘</div> <div>└─┘ [Pr. PT22]</div> </div>	0000h Refer to Function column for unit.	○	
PT22 *LNPH Position range output address - (upper four digits)			0000h Refer to Function column for unit.		
PT27 *ODM Indexer method - Operation mode selection	___ x __ x _ _ x _ _ x _ _ _	For manufacturer setting Manual operation method selection 0: Station JOG operation 1: JOG operation This digit is available with servo amplifier with software version A3 or later. For manufacturer setting	0h 0h 0h 0h	<div style="display: flex; align-items: center; justify-content: center;"> <div style="width: 100%; height: 100%; border: 1px solid black; position: relative;"> <div style="position: absolute; top: 0; right: 0; width: 50%; height: 50%; border: 1px solid black;"></div> </div> </div>	○
PT28 *STN Number of stations per rotation		Set the number of stations per rotation (number of indexer stations). Setting "0" or "1" to this setting will set it to "2". This parameter is available with servo amplifiers with software version A3 or later. Setting range: 0 to 255	8 [stations]		


3. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				CP	PS
PT34 **PDEF Point table default		<p>Use this parameter when initializing point tables and cam data. The point tables and the cam data will be the following status by being initialized. Point table: All "0" Cam data: Erased</p> <p>Initialize the point tables with the following procedures: 1) Set "5001h" to this parameter. 2) Cycle the power of the servo amplifier. After the servo amplifier power is on, the initialization completes in about 20 s. "dF" will be displayed on the display (five-digit, seven-segment LED) during the initialization. After the initialization, the setting of this parameter will be "0000h" automatically.</p> <p>Initialize the cam data with the following procedures: 1) Set "5010h" to this parameter. 2) Cycle the power of the servo amplifier. After the initialization, the setting of this parameter will be "0000h" automatically.</p> <p>Initialize the point tables and the cam data with the following procedures: 1) Set "5011h" to this parameter. 2) Cycle the power of the servo amplifier. After the servo amplifier power is on, the initialization completes in about 20 s. "dF" will be displayed on the display (five-digit, seven-segment LED) during the initialization. After the initialization, the setting of this parameter will be "0000h" automatically.</p> <p>Initializing cam data is possible with servo amplifiers with software version A3 or later.</p>	0000h	○	
PT35 *TOP5 Function selection T-5	___x	For manufacturer setting	0h		
	__x_		0h		
	_x__	<p>Simple cam function selection 0: Disabled 1: Enabled (cam position compensation disabled) 2: Enabled (cam position compensation enabled by touch probe 1 (TPR1)) 3: Enabled (cam position compensation enabled by touch probe 2 (TPR2)) Simple cam function is enabled when the control mode is in the point table method. Enabling this digit in other control modes will trigger [AL. 37 Parameter error]. Setting a value other than "0" to this digit when MR-D30 is connected will trigger [AL. 37] This digit is available with servo amplifier with software version A3 or later.</p>	0h	○	
	x___	For manufacturer setting	0h		
PT39 INT Torque limit delay time		<p>Set delay time from outputting RXnC (Travel completion) to enabling [Pr. PC77 Internal torque limit 2]. This parameter is available with servo amplifiers with software version A3 or later.</p> <p>Setting range: 0 to 1000</p>	100 [ms]		○
PT40 *SZS Station home position shift distance		<p>Set a shift distance of the station home position with encoder pulse unit at home position return. Setting this parameter enables to shift the station home position (station No. 0) to the position for home position return. The following shows cautions for the setting.</p> <ul style="list-style-type: none"> The setting of the station home position shift distance is disabled at home position return. Cycling the power will enable the setting. When the home position shift distance is longer than the in-position range, RXn1 (In-position) will not be on regardless of cycle of the power after returning to home position. <p>This parameter is available with servo amplifiers with software version A3 or later.</p> <p>Setting range: -32000 to 32000</p>	0 [pulse]		○


3. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode																																																								
				CP	PS																																																							
PT45 HMM Home position return type		Set the home position return method. Refer to the following table for details. Setting a value other than setting values ("-1", "-3", "-33", "35" and "37" regarding the indexer method) in the following tables will trigger [AL. F4] At this time, home position return cannot be executed.	37	○	○																																																							
<table><tr><td>Setting value</td><td>Home position return direction</td><td>How to execute home position return</td><td>Setting value</td><td>Home position return direction</td><td>How to execute home position return</td></tr><tr><td>-1</td><td rowspan="2">Address increasing direction</td><td>Dog type (rear end detection Z- phase reference)/ Torque limit changing dog type (Note 1)</td><td>-33</td><td rowspan="9">Address decreasing direction</td><td>Dog type (rear end detection Z- phase reference)/ Torque limit changing dog type (Note 1)</td></tr><tr><td>-2</td><td>Count type (front end detection, Z- phase reference)</td><td>-34</td><td>Count type (front end detection, Z- phase reference)</td></tr><tr><td>-3</td><td></td><td>Torque limit changing data set type (Note 1)</td><td>-36</td><td>Stopper type (stopper position reference)</td></tr><tr><td>-4</td><td rowspan="2">Address increasing direction</td><td>Stopper type (stopper position reference)</td><td>-38</td><td>Dog type (rear end detection, rear end reference)</td></tr><tr><td>-5</td><td>Home position ignorance (Servo- on position as home position) (Note 2)</td><td>-39</td><td>Count type (front end detection, front end reference)</td></tr><tr><td>-6</td><td rowspan="6">Address increasing direction</td><td>Dog type (rear end detection, rear end reference)</td><td>-40</td><td>Dog cradle type</td></tr><tr><td>-7</td><td>Count type (front end detection, front end reference)</td><td>-41</td><td>Dog type last Z- phase reference</td></tr><tr><td>-8</td><td>Dog cradle type</td><td>-42</td><td>Dog type front end reference</td></tr><tr><td>-9</td><td>Dog type last Z- phase reference</td><td>-43</td><td>Dogless Z-phase reference</td></tr><tr><td>-10</td><td>Dog type front end reference</td><td></td><td></td></tr><tr><td>-11</td><td>Dogless Z-phase reference</td><td></td><td></td></tr></table>						Setting value	Home position return direction	How to execute home position return	Setting value	Home position return direction	How to execute home position return	-1	Address increasing direction	Dog type (rear end detection Z- phase reference)/ Torque limit changing dog type (Note 1)	-33	Address decreasing direction	Dog type (rear end detection Z- phase reference)/ Torque limit changing dog type (Note 1)	-2	Count type (front end detection, Z- phase reference)	-34	Count type (front end detection, Z- phase reference)	-3		Torque limit changing data set type (Note 1)	-36	Stopper type (stopper position reference)	-4	Address increasing direction	Stopper type (stopper position reference)	-38	Dog type (rear end detection, rear end reference)	-5	Home position ignorance (Servo- on position as home position) (Note 2)	-39	Count type (front end detection, front end reference)	-6	Address increasing direction	Dog type (rear end detection, rear end reference)	-40	Dog cradle type	-7	Count type (front end detection, front end reference)	-41	Dog type last Z- phase reference	-8	Dog cradle type	-42	Dog type front end reference	-9	Dog type last Z- phase reference	-43	Dogless Z-phase reference	-10	Dog type front end reference			-11	Dogless Z-phase reference		
Setting value	Home position return direction	How to execute home position return	Setting value	Home position return direction	How to execute home position return																																																							
-1	Address increasing direction	Dog type (rear end detection Z- phase reference)/ Torque limit changing dog type (Note 1)	-33	Address decreasing direction	Dog type (rear end detection Z- phase reference)/ Torque limit changing dog type (Note 1)																																																							
-2		Count type (front end detection, Z- phase reference)	-34		Count type (front end detection, Z- phase reference)																																																							
-3		Torque limit changing data set type (Note 1)	-36		Stopper type (stopper position reference)																																																							
-4	Address increasing direction	Stopper type (stopper position reference)	-38		Dog type (rear end detection, rear end reference)																																																							
-5		Home position ignorance (Servo- on position as home position) (Note 2)	-39		Count type (front end detection, front end reference)																																																							
-6	Address increasing direction	Dog type (rear end detection, rear end reference)	-40		Dog cradle type																																																							
-7		Count type (front end detection, front end reference)	-41		Dog type last Z- phase reference																																																							
-8		Dog cradle type	-42		Dog type front end reference																																																							
-9		Dog type last Z- phase reference	-43		Dogless Z-phase reference																																																							
-10		Dog type front end reference																																																										
-11		Dogless Z-phase reference																																																										

3. PARAMETERS

No./symbol/ name	Setting digit	Function				Initial value [unit]	Control mode	
							CP	PS
PT45 HMM Home position return type		Setting value	Home position return direction	How to execute home position return	Setting value	Home position return direction	How to execute home position return	
		3	Address increasing direction	Method 3	21	Address decreasing direction	Method 21	
		4	Address increasing direction	Method 4	22	Address decreasing direction	Method 22	
		5	Address decreasing direction	Method 5	23	Address increasing direction	Method 23	
		6	Address decreasing direction	Method 6	24	Address increasing direction	Method 24	
		7	Address increasing direction	Method 7	27	Address decreasing direction	Method 27	
		8	Address increasing direction	Method 8	28	Address decreasing direction	Method 28	
		11	Address decreasing direction	Method 11	33	Address decreasing direction	Method 33	
		12	Address decreasing direction	Method 12	34	Address increasing direction	Method 34	
		19	Address increasing direction	Method 19	35		Method 35	
		20	Address increasing direction	Method 20	37		Method 37 (Data set type)	
	<p>Note 1. Torque limit changing dog type and torque limit changing data set type is available only in the indexer method. The indexer method is available with servo amplifiers with software version A3 or later.</p> <p>2. This setting value is available with servo amplifier with software version A1 or later.</p>							
PT49 STA Acceleration time constant		<p>Set an acceleration time from 0 r/min or 0 mm/s to the rated speed for the command. If the servo motor is started when a value exceeding 20000 ms is set, [AL. F4] will occur, and the servo motor will not operate.</p>				0 [ms]	○	○
		<p>If the preset speed command is lower than the rated speed, acceleration/deceleration time will be shorter.</p>  <p>For example for the servo motor of 3000 r/min rated speed, set 3000 (3 s) to increase speed from 0 r/min to 1000 r/min in 1 s.</p> <p>Setting range: 0 to 50000</p>						

3. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				CP	PS
PT50 STB Deceleration time constant		<p>Set a deceleration time from the rated speed to 0 r/min or 0 mm/s for the command. If the servo motor is started when a value exceeding 20000 ms is set, [AL. F4] will occur, and the servo motor will not operate.</p> <p>Setting range: 0 to 50000</p>	0 [ms]	<input type="radio"/>	<input type="radio"/>
PT51 STC S-pattern acceleration/ deceleration time constant		<p>This enables to start/stop the servo motor or linear servo motor smoothly. Set the time of the arc part for S-pattern acceleration/deceleration. Setting "0" will make it linear acceleration/deceleration.</p>  <p>Long setting of STA ([Pr. PT49 Acceleration time constant]) or STB ([Pr. PT50 Deceleration time constant]) may produce an error in the time of the arc part for the setting of the S-pattern acceleration/deceleration time constant. The setting will be disabled at home position return. When 1000 ms or more value is set, it will be clamped to 1000 ms.</p> <p>The upper limit value of the actual arc part time is limited by</p> $\frac{2000000}{STA} \text{ for acceleration or by } \frac{2000000}{STB} \text{ for deceleration.}$ <p>(Example) At the setting of STA 20000, STB 5000 and STC 200, the actual arc part times are as follows.</p> <p>During acceleration: 100 ms</p> $\frac{2000000}{20000} = 100 \text{ [ms]} < 200 \text{ [ms]}$ <p>Therefore, it will be limited to 100 [ms].</p> <p>During deceleration: 200 ms</p> $\frac{2000000}{5000} = 400 \text{ [ms]} > 200 \text{ [ms]}$ <p>Therefore, it will be 200 [ms] as you set.</p> <p>Setting range: 0 to 5000</p>	0 [ms]	<input type="radio"/>	

3. PARAMETERS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode												
				CP	PS											
PT62 *DSS Remote register-based position/ speed specifying method selection	To enable the parameter, turn on link device RY (n + 2) A (position/speed specifying method selection). Select a setting value according to the position command and speed command in the following table.															
	___ x	Point table method position/speed specifying method selection <table><tr><th>Setting value</th><th>Position command</th><th>Speed command</th></tr><tr><td>0</td><td>Point table No.</td><td>Point table No.</td></tr><tr><td>1</td><td rowspan="2">Position data</td><td>Point table No.</td></tr><tr><td>2</td><td>Servo motor speed (Note)</td></tr></table> Note. Be sure to set an acceleration/deceleration time constant to point table No. 1.	Setting value	Position command	Speed command	0	Point table No.	Point table No.	1	Position data	Point table No.	2	Servo motor speed (Note)	0h	○	
	Setting value	Position command	Speed command													
	0	Point table No.	Point table No.													
	1	Position data	Point table No.													
2	Servo motor speed (Note)															
__ x _	Position/speed specifying method selection of indexer method This digit is available with servo amplifier with software version A3 or later. <table><tr><th>Setting value</th><th>Position command</th><th>Speed command</th></tr><tr><td>0</td><td rowspan="2">Next station No.</td><td>Point table No.</td></tr><tr><td>1</td><td>Servo motor speed (Note)</td></tr></table> Note. Be sure to set an acceleration/deceleration time constant to point table No. 1.	Setting value	Position command	Speed command	0	Next station No.	Point table No.	1	Servo motor speed (Note)	0h		○				
Setting value	Position command	Speed command														
0	Next station No.	Point table No.														
1		Servo motor speed (Note)														
_ x _ _	For manufacturer setting	0h														
x _ _ _		0h														
PT65 PVC Jog speed command		Set a Jog speed command. If a value smaller than "1.00" is set, the servo motor may not rotate. Setting range: 0.00 to permissible instantaneous speed	100.00 [r/min]/ [mm/s]	○	○											
PT69 ZSTH Home position shift distance (extension parameter)		Set the extension parameter of [Pr. PT07]. When [Pr. PT69] is used, the home position shift distance can be calculated as follows. Home position shift distance = [Pr. PT07] + ([Pr. PT69] × 65536) The unit will be as follows depending on the positioning mode. ▪ Point table method It will be change to [μm], 10 ⁻⁴ [inch], or [pulse] with [Pr. PT01]. ▪ Indexer method It will be command unit [pulse]. (unit of a load-side rotation expressed by the number of servo motor resolution pulses) Refer to the Function column of [Pr. PA10] for the command unit. Additionally, when a value of "1001" or more is set, it will be clamped to "1000". The indexer method is available with servo amplifiers with software version A3 or later. Setting range: 0 to 32767	0 Refer to Function column for unit.	○	○											
PT71 DCTH Travel distance after proximity dog (extension parameter)		Set the extension parameter of [Pr. PT09]. When [Pr. PT71] is used, the travel distance after proximity dog can be calculated as follows. Travel distance after proximity dog = [Pr. PT09] + ([Pr. PT71] × 65536) The unit can be changed to 10 ^{STM} [μm], 10 ^(STM-4) [inch], or [pulse] with the setting of [Pr. PT01]. Setting range: 0 to 32767	0 Refer to Function column for unit.	○												

3. PARAMETERS

3.2.5 Network setting parameters ([Pr. PN_ _])

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				CP	PS
PN03 **NWMD Communi- cation mode setting for CC-Link IE communi- cation	___ x	Station-specific mode setting Select the motion mode for connection with a simple motion module or the I/O mode for connection with a master/local module. 0: Motion mode 1: I/O mode	0h	○	○
	__ x _	For manufacturer setting	0h		
	_ x _ _		0h		
	x _ _ _		0h		
PN06 NOP1 Function selection N-1	___ x	Communication error alarm history writing selection Select whether [AL. 8D.1 CC-Link IE communication error 1] and [AL. 8D.2 CC-Link IE communication error 2] are recorded in the alarm history at their occurrence. 0: Disabled 1: Enabled When the parameter is set to "1", follow the correct procedure for turning off the power to prevent the occurrence of [AL. 8D.1] or [AL. 8D.2] at power supply shut-off (network disconnection). For details, refer to [Pr. PN06 Communication error detection method selection].	0h	○	○
	__ x _	Communication error detection method selection Select the condition for detecting the occurrences of [AL. 8D.1 CC-Link IE communication error 1] and [AL. 8D.2 CC-Link IE communication error 2]. 0: Detected only at servo-on. 1: Continuously detected. When the parameter is set to "0", if link device RYn0 (servo-on) is set to "1" in the I/O mode, [AL. 8D.1] and [AL. 8D.2] are detected. When turning off the power in the I/O mode, set link device RYn0 to "0" first. When the parameter is set to "1", [AL. 8D.1] and [AL. 8D.2] are continuously detected while data is being linked. When turning off the power, turn off the servo amplifier first and then the controller.	0h	○	○
	_ x _ _	For manufacturer setting	0h		
	x _ _ _		0h		


3. PARAMETERS

3.3 How to set the electronic gear

3.3.1 Electronic gear settings in the point table method and program method

- (1) Setting [mm], [inch], or [pulse] with "Position data unit" of [Pr. PT01].

Adjust [Pr. PA06] and [Pr. PA07] so that the servo motor setting matches with the travel distance of the machine.



P_t : Servo motor encoder resolution: 4194304 [pulse/rev]

ΔS : Travel distance per servo motor revolution [mm/rev]/[inch/rev]/[pulse/rev]

$$CMX/CDV = P_t/\Delta S$$

The following setting example explains how to calculate the electronic gear.

POINT
<p>● To calculate the electronic gear, the following specification symbols are required.</p> <p>Pb: Ball screw lead [mm]</p> <p>1/n: Reduction ratio</p> <p>P_t: Servo motor encoder resolution [pulse/rev]</p> <p>ΔS: Travel distance per servo motor revolution [mm/rev]</p>

(a) Setting example of a ball screw

Machine specifications


Ball screw lead Pb = 10 [mm]

Reduction ratio: $1/n = Z_1/Z_2 = 1/2$

Z_1 : Number of gear teeth on servo motor side

Z_2 : Number of gear teeth on load gear

Servo motor encoder resolution $P_t = 4194304$ [pulse/rev]



$$\frac{CMX}{CDV} = \frac{P_t}{\Delta S} = \frac{P_t}{n \cdot Pb \cdot \alpha \text{ (Note)}} = \frac{4194304}{1/2 \cdot 10 \cdot 1000} = \frac{4194304}{5000} = \frac{524288}{625}$$

Note. Because the command unit is "mm", $\alpha = 1000$ is set. When the unit is "inch", convert the setting into $\alpha = 10000$. When the unit is "pulse", convert the setting into $\alpha = 1$.

Therefore, set CMX = 524288 and CDV = 625.

3. PARAMETERS

(b) Setting example of a conveyor


Machine specifications

Pulley diameter: $r = 160$ [mm]

Reduction ratio: $1/n = Z_1/Z_2 = 1/3$

Z_1 : Number of gear teeth on servo motor side

Z_2 : Number of gear teeth on load gear



Servo motor encoder resolution $P_t = 4194304$ [pulse/rev]

$$\frac{CMX}{CDV} = \frac{P_t}{\Delta S} = \frac{P_t}{n \cdot r \cdot \pi \cdot \alpha \text{ (Note)}} = \frac{4194304}{1/3 \cdot 160 \cdot \pi \cdot 1000} = \frac{4194304}{167551.61} \approx \frac{524288}{20944}$$

Note. Because the command unit is "mm", $\alpha = 1000$ is set. When the unit is "inch", convert the setting into $\alpha = 10000$. When the unit is "pulse", convert the setting into $\alpha = 1$.

Reduce CMX and CDV to within the setting range or lower and round off each value to the closest whole number.


Therefore, set $CMX = 524288$ and $CDV = 20944$.

3. PARAMETERS


3.3.2 Electronic gear setting in the indexer method

Adjust [Pr. PA06] and [Pr. PA07] to align the rotation amount "m" of the servo motor shaft necessary to rotate the load side for "n" times. The following shows a setting example of the electronic gear.

- (1) Number of pulley teeth on machine side: 50, number of pulley teeth on servo motor side: 20
Set [Pr. PA06] = 50 and [Pr. PA07] = 20.




- (2) Number of pulley teeth on machine side: 50, number of pulley teeth on servo motor side: 20, with geared servo motor of 1/9
Set [Pr. PA06] = 450 and [Pr. PA07] = 20.



3. PARAMETERS

3.4 Stop method for RY (n + 1) 0 (Upper stroke limit) off or RY (n + 1) 1 (Lower stroke limit) off

Select a servo motor stop method for when RY (n + 1) 0 (Upper stroke limit) or RY (n + 1) 1 (Lower stroke limit) is off with the first digit of [Pr. PD12].




- Stop method selection for RY (n + 1) 0 (Upper stroke limit) off or RY (n + 1) 1 (Lower stroke limit) off
- 1: Slow stop
 - 2: Slow stop (deceleration to a stop by deceleration time constant)
 - 3: Quick stop (stop by clearing remaining distance)

[Pr. PD12] setting	Operation status		Remark
	During rotation at constant speed	During deceleration to a stop	
<p>— — — 1 (initial value)</p>	<p>— No S-pattern acceleration/ deceleration - - - With S-pattern acceleration/ deceleration</p> <p>Servo motor speed</p> <p>RY (n + 1) 0 or RY (n + 1) 1</p> <p>ON OFF</p>	<p>— No S-pattern acceleration/ deceleration - - - With S-pattern acceleration/ deceleration</p> <p>Servo motor speed</p> <p>RY (n + 1) 0 or RY (n + 1) 1</p> <p>ON OFF</p>	<p>Erases the droop pulse portion and stops the motor. Maintains the home position. However, a difference will be generated between the command position and the current position. Perform a home position return again.</p>
<p>— — — 2</p>	<p>— No S-pattern acceleration/ deceleration - - - With S-pattern acceleration/ deceleration</p> <p>Servo motor speed</p> <p>RY (n + 1) 0 or RY (n + 1) 1</p> <p>ON OFF</p>	<p>— No S-pattern acceleration/ deceleration - - - With S-pattern acceleration/ deceleration</p> <p>Servo motor speed</p> <p>RY (n + 1) 0 or RY (n + 1) 1</p> <p>ON OFF</p>	<p>Decelerates to a stop with the deceleration time constant currently selected with the point table. Continues operation for a delay portion of the S-pattern acceleration/ deceleration time constants. Maintains the home position. A difference will not be generated between the command position and the current position.</p>
<p>— — — 3</p>	<p>— No S-pattern acceleration/ deceleration - - - With S-pattern acceleration/ deceleration</p> <p>Servo motor speed</p> <p>RY (n + 1) 0 or RY (n + 1) 1</p> <p>ON OFF</p>	<p>— No S-pattern acceleration/ deceleration - - - With S-pattern acceleration/ deceleration</p> <p>Servo motor speed</p> <p>RY (n + 1) 0 or RY (n + 1) 1</p> <p>ON OFF</p>	<p>Erases the droop pulse portion and stops the motor. Continues operation for a delay portion of the S-pattern acceleration/ deceleration time constants. Maintains the home position. A difference will not be generated between the command position and the current position.</p>

3. PARAMETERS

3.5 Stop method at software limit detection

Select a stop method of the servo motor for when a software limit ([Pr. PT15] to [Pr. PT18]) is detected with the setting of the third digit in [Pr. PD12]. The software limit limits a command position controlled in the servo amplifier. Therefore, actual stop position will not reach the set position of the software limit.



Stop method selection at software limit detection
 1: Slow stop
 2: Slow stop (deceleration to a stop by deceleration time constant)
 3: Quick stop (stop by clearing remaining distance)

[Pr. PD12] setting	Operation status		Remark
	During rotation at constant speed	During deceleration to a stop	
— 1 — (initial value)	— No S-pattern acceleration/ deceleration - - - With S-pattern acceleration/ deceleration 	— No S-pattern acceleration/ deceleration - - - With S-pattern acceleration/ deceleration 	Erases the droop pulse portion and stops the motor. Maintains the home position. However, a difference will be generated between the command position and the current position. Perform a home position return again.
— 2 —	— No S-pattern acceleration/ deceleration - - - With S-pattern acceleration/ deceleration 	— No S-pattern acceleration/ deceleration - - - With S-pattern acceleration/ deceleration 	Decelerates to a stop with the deceleration time constant currently selected with the point table. Continues operation for a delay portion of the S-pattern acceleration/ deceleration time constants. Keeps the home position. A difference will not be generated between the command position and the current position.
— 3 —	— No S-pattern acceleration/ deceleration - - - With S-pattern acceleration/ deceleration 	— No S-pattern acceleration/ deceleration - - - With S-pattern acceleration/ deceleration 	Erases the droop pulse portion and stops the motor. Continues operation for a delay portion of the S-pattern acceleration/ deceleration time constants. Keeps the home position. A difference will not be generated between the command position and the current position.

[illegible]

4. TROUBLESHOOTING

4. TROUBLESHOOTING

POINT	
●	Refer to "MELSERVO-J4 Servo Amplifier Instruction Manual (Troubleshooting)" for details of alarms and warnings.
●	As soon as an alarm occurs, make the Servo-off status and interrupt the main circuit power.
●	[AL. 37 Parameter error] and warnings (except [AL. F0 Tough drive warning]) are not recorded in the alarm history.
●	In the initial setting, [AL. 8D.1 CC-Link IE communication error 1] and [AL. 8D.2 CC-Link IE communication error 2] are not recorded in the alarm history. The alarms are recorded by setting [Pr. PN06] to " _ _ _ 1".

When an error occurs during operation, the corresponding alarm and warning are displayed. When an alarm or warning is displayed, refer to "MELSERVO-J4 Servo Amplifier Instruction Manual (Troubleshooting)" to remove the failure. When an alarm occurs, ALM will turn off.

4.1 Explanation for the lists

(1) No./Name/Detail No./Detail name

Indicates each No./Name/Detail No./Detail name of alarms or warnings.

(2) Stop method

For the alarms and warnings in which "SD" is written in the stop method column, the servo motor stops with the dynamic brake after forced stop deceleration. For the alarms and warnings in which "DB" or "EDB" is written in the stop method column, the servo motor stops with the dynamic brake without forced stop deceleration.

(3) Alarm deactivation

After its cause has been removed, the alarm can be deactivated in any of the methods marked ○ in the alarm deactivation column. Warnings are automatically canceled after the cause of occurrence is removed. Alarms are deactivated with alarm reset, CPU reset, or cycling the power.

Alarm deactivation	Explanation
Alarm reset	1. Reset command from controller 2. Click "Occurring Alarm Reset" in the "Alarm Display" window of MR Configurator2
CPU reset	Resetting the controller itself
Cycling the power	Turning off the power and on again

4. TROUBLESHOOTING

4.2 Alarm list

	No.	Name	Detail No.	Detail name	Stop method (Note 2, 3)	Alarm deactivation		
						Alarm reset	CPU reset	Cycling the power
Alarm	10	Undervoltage	10.1	Voltage drop in the control circuit power	EDB	○	○	○
			10.2	Voltage drop in the main circuit power	SD	○	○	○
	11	Switch setting error	11.1	Axis number setting error/ Station number setting error	DB			○
			11.2	Disabling control axis setting error	DB			○
	12	Memory error 1 (RAM)	12.1	RAM error 1	DB			○
			12.2	RAM error 2	DB			○
			12.3	RAM error 3	DB			○
			12.4	RAM error 4	DB			○
			12.5	RAM error 5	DB			○
			12.6	RAM error 6	DB			○
	13	Clock error	13.1	Clock error 1	DB			○
			13.2	Clock error 2	DB			○
	14	Control process error	14.1	Control process error 1	DB			○
			14.2	Control process error 2	DB			○
			14.3	Control process error 3	DB			○
			14.4	Control process error 4	DB			○
			14.5	Control process error 5	DB			○
			14.6	Control process error 6	DB			○
			14.7	Control process error 7	DB			○
			14.8	Control process error 8	DB			○
			14.9	Control process error 9	DB			○
			14.A	Control process error 10	DB			○
			14.B	Control process error 11	DB			○
	15	Memory error 2 (EEP-ROM)	15.1	EEP-ROM error at power on	DB			○
			15.2	EEP-ROM error during operation	DB			○
			15.4	Home position information read error	DB			○
	16	Encoder initial communication error 1	16.1	Encoder initial communication - Receive data error 1	DB			○
			16.2	Encoder initial communication - Receive data error 2	DB			○
			16.3	Encoder initial communication - Receive data error 3	DB			○
			16.5	Encoder initial communication - Transmission data error 1	DB			○
			16.6	Encoder initial communication - Transmission data error 2	DB			○
			16.7	Encoder initial communication - Transmission data error 3	DB			○
			16.A	Encoder initial communication - Process error 1	DB			○
			16.B	Encoder initial communication - Process error 2	DB			○
			16.C	Encoder initial communication - Process error 3	DB			○
			16.D	Encoder initial communication - Process error 4	DB			○
			16.E	Encoder initial communication - Process error 5	DB			○
			16.F	Encoder initial communication - Process error 6	DB			○

4. TROUBLESHOOTING

	No.	Name	Detail No.	Detail name	Stop method (Note 2, 3)	Alarm deactivation		
						Alarm reset	CPU reset	Cycling the power
Alarm	17	Board error	17.1	Board error 1	DB			○
			17.3	Board error 2	DB			○
			17.4	Board error 3	DB			○
			17.5	Board error 4	DB			○
			17.6	Board error 5	DB			○
			17.7	Board error 7	DB			○
			17.8	Board error 6 (Note 6)	EDB			○
			17.9	Board error 8	DB			○
	19	Memory error 3 (Flash-ROM)	19.1	Flash-ROM error 1	DB			○
			19.2	Flash-ROM error 2	DB			○
			19.3	Flash-ROM error 3	DB			○
	1A	Servo motor combination error	1A.1	Servo motor combination error 1	DB			○
			1A.2	Servo motor control mode combination error	DB			○
			1A.4	Servo motor combination error 2	DB			○
	1B	Converter error	1B.1	Converter unit error	DB			○
	1E	Encoder initial communication error 2	1E.1	Encoder malfunction	DB			○
			1E.2	Load-side encoder malfunction	DB			○
	1F	Encoder initial communication error 3	1F.1	Incompatible encoder	DB			○
			1F.2	Incompatible load-side encoder	DB			○
	20	Encoder normal communication error 1	20.1	Encoder normal communication - Receive data error 1	EDB			○
			20.2	Encoder normal communication - Receive data error 2	EDB			○
			20.3	Encoder normal communication - Receive data error 3	EDB			○
			20.5	Encoder normal communication - Transmission data error 1	EDB			○
			20.6	Encoder normal communication - Transmission data error 2	EDB			○
			20.7	Encoder normal communication - Transmission data error 3	EDB			○
			20.9	Encoder normal communication - Receive data error 4	EDB			○
			20.A	Encoder normal communication - Receive data error 5	EDB			○
	21	Encoder normal communication error 2	21.1	Encoder data error 1	EDB			○
			21.2	Encoder data update error	EDB			○
			21.3	Encoder data waveform error	EDB			○
			21.4	Encoder non-signal error	EDB			○
			21.5	Encoder hardware error 1	EDB			○
			21.6	Encoder hardware error 2	EDB			○
			21.9	Encoder data error 2	EDB			○

4. TROUBLESHOOTING

	No.	Name	Detail No.	Detail name	Stop method (Note 2, 3)	Alarm deactivation		
						Alarm reset	CPU reset	Cycling the power
Alarm	24	Main circuit error	24.1	Ground fault detected by hardware detection circuit	DB			○
			24.2	Ground fault detected by software detection function	DB	○	○	○
	25	Absolute position erased	25.1	Servo motor encoder - Absolute position erased	DB			○
			25.2	Scale measurement encoder - Absolute position erased	DB			○
	27	Initial magnetic pole detection error	27.1	Initial magnetic pole detection - Abnormal termination	DB	○		○
			27.2	Initial magnetic pole detection - Time out error	DB	○		○
			27.3	Initial magnetic pole detection - Limit switch error	DB	○		○
			27.4	Initial magnetic pole detection - Estimated error	DB	○		○
			27.5	Initial magnetic pole detection - Position deviation error	DB	○		○
			27.6	Initial magnetic pole detection - Speed deviation error	DB	○		○
			27.7	Initial magnetic pole detection - Current error	DB	○		○
	28	Linear encoder error 2	28.1	Linear encoder - Environment error	EDB			○
	2A	Linear encoder error 1	2A.1	Linear encoder error 1-1	EDB			○
			2A.2	Linear encoder error 1-2	EDB			○
			2A.3	Linear encoder error 1-3	EDB			○
			2A.4	Linear encoder error 1-4	EDB			○
			2A.5	Linear encoder error 1-5	EDB			○
			2A.6	Linear encoder error 1-6	EDB			○
			2A.7	Linear encoder error 1-7	EDB			○
			2A.8	Linear encoder error 1-8	EDB			○
	2B	Encoder counter error	2B.1	Encoder counter error 1	EDB			○
			2B.2	Encoder counter error 2	EDB			○
	30	Regenerative error	30.1	Regeneration heat error	DB	○ (Note 1)	○ (Note 1)	○ (Note 1)
			30.2	Regeneration signal error	DB	○ (Note 1)	○ (Note 1)	○ (Note 1)
			30.3	Regeneration feedback signal error	DB	○ (Note 1)	○ (Note 1)	○ (Note 1)
	31	Overspeed	31.1	Abnormal motor speed	SD	○	○	○
	32	Overcurrent	32.1	Overcurrent detected at hardware detection circuit (during operation)	DB			○
			32.2	Overcurrent detected at software detection function (during operation)	DB	○	○	○
			32.3	Overcurrent detected at hardware detection circuit (during a stop)	DB			○
			32.4	Overcurrent detected at software detection function (during a stop)	DB	○	○	○
	33	Overvoltage	33.1	Main circuit voltage error	EDB	○	○	○

4. TROUBLESHOOTING

	No.	Name	Detail No.	Detail name	Stop method (Note 2, 3)	Alarm deactivation		
						Alarm reset	CPU reset	Cycling the power
Alarm	34	SSCNET receive error 1	34.1	SSCNET receive data error	SD	○	○ (Note 5)	○
			34.2	SSCNET connector connection error	SD	○	○	○
			34.3	SSCNET communication data error	SD	○	○	○
			34.4	Hardware error signal detection	SD	○	○	○
			34.5	SSCNET receive data error (safety observation function)	SD	○	○	○
			34.6	SSCNET communication data error (safety observation function)	SD	○	○	○
	35	Command frequency error	35.1	Command frequency error	SD	○	○	○
	36	SSCNET receive error 2	36.1	Continuous communication data error	SD	○	○	○
			36.2	Continuous communication data error (safety observation function)	SD	○	○	○
	37	Parameter error	37.1	Parameter setting range error	DB	△	○	○
			37.2	Parameter combination error	DB	△	○	○
			37.3	Point table setting error	DB	△	△	○
	39	Program error	39.1	Program error	DB	△	△	○
			39.2	Instruction argument external error	DB	△	△	○
			39.3	Register No. error	DB	△	△	○
			39.4	Non-correspondence instruction error	DB	△	△	○
	3A	Inrush current suppression circuit error	3A.1	Inrush current suppression circuit error	EDB	△	△	○
	3D	Parameter setting error for driver communication	3D.1	Parameter combination error for driver communication on slave	DB	△	△	○
			3D.2	Parameter combination error for driver communication on master	DB	△	△	○
	3E	Operation mode error	3E.1	Operation mode error	DB	△	○	○
			3E.6	Operation mode switch error	DB	△	△	○
	42	Servo control error (for linear servo motor and direct drive motor)	42.1	Servo control error by position deviation	EDB	(Note 4)	(Note 4)	○
			42.2	Servo control error by speed deviation	EDB	(Note 4)	(Note 4)	○
			42.3	Servo control error by torque/thrust deviation	EDB	(Note 4)	(Note 4)	○
		Fully closed loop control error (for fully closed loop control)	42.8	Fully closed loop control error by position deviation	EDB	(Note 4)	(Note 4)	○
			42.9	Fully closed loop control error by speed deviation	EDB	(Note 4)	(Note 4)	○
			42.A	Fully closed loop control error by position deviation during command stop	EDB	(Note 4)	(Note 4)	○
	45	Main circuit device overheat	45.1	Main circuit device overheat error 1	SD	○ (Note 1)	○ (Note 1)	○ (Note 1)
			45.2	Main circuit device overheat error 2	SD	○ (Note 1)	○ (Note 1)	○ (Note 1)

4. TROUBLESHOOTING

	No.	Name	Detail No.	Detail name	Stop method (Note 2, 3)	Alarm deactivation		
						Alarm reset	CPU reset	Cycling the power
Alarm	46	Servo motor overheat	46.1	Abnormal temperature of servo motor 1	SD	○ (Note 1)	○ (Note 1)	○ (Note 1)
			46.2	Abnormal temperature of servo motor 2	SD	○ (Note 1)	○ (Note 1)	○ (Note 1)
			46.3	Thermistor disconnected error	SD	○ (Note 1)	○ (Note 1)	○ (Note 1)
			46.4	Thermistor circuit error	SD	○ (Note 1)	○ (Note 1)	○ (Note 1)
			46.5	Abnormal temperature of servo motor 3	DB	○ (Note 1)	○ (Note 1)	○ (Note 1)
			46.6	Abnormal temperature of servo motor 4	DB	○ (Note 1)	○ (Note 1)	○ (Note 1)
	47	Cooling fan error	47.1	Cooling fan stop error	SD	△	△	○
			47.2	Cooling fan speed reduction error	SD	△	△	○
	50	Overload 1	50.1	Thermal overload error 1 during operation	SD	○ (Note 1)	○ (Note 1)	○ (Note 1)
			50.2	Thermal overload error 2 during operation	SD	○ (Note 1)	○ (Note 1)	○ (Note 1)
			50.3	Thermal overload error 4 during operation	SD	○ (Note 1)	○ (Note 1)	○ (Note 1)
			50.4	Thermal overload error 1 during a stop	SD	○ (Note 1)	○ (Note 1)	○ (Note 1)
			50.5	Thermal overload error 2 during a stop	SD	○ (Note 1)	○ (Note 1)	○ (Note 1)
			50.6	Thermal overload error 4 during a stop	SD	○ (Note 1)	○ (Note 1)	○ (Note 1)
	51	Overload 2	51.1	Thermal overload error 3 during operation	DB	○ (Note 1)	○ (Note 1)	○ (Note 1)
			51.2	Thermal overload error 3 during a stop	DB	○ (Note 1)	○ (Note 1)	○ (Note 1)
	52	Error excessive	52.1	Excess droop pulse 1	SD	○	○	○
			52.3	Excess droop pulse 2	SD	○	○	○
			52.4	Error excessive during 0 torque limit	SD	○	○	○
			52.5	Excess droop pulse 3	EDB	○	○	○
	54	Oscillation detection	54.1	Oscillation detection error	EDB	○	○	○
	56	Forced stop error	56.2	Over speed during forced stop	EDB	○	○	○
			56.3	Estimated distance over during forced stop	EDB	○	○	○
	61	Operation error	61.1	Point table setting range error	DB	○	△	○
	63	STO timing error	63.1	STO1 off	DB	○	○	○
			63.2	STO2 off	DB	○	○	○
			63.5	STO by functional safety unit	DB	○	○	○
	64	Functional safety unit setting error	64.1	STO input error	DB	△	△	○
			64.2	Compatibility mode setting error	DB	△	△	○
			64.3	Operation mode setting error	DB	△	△	○

4. TROUBLESHOOTING

	No.	Name	Detail No.	Detail name	Stop method (Note 2, 3)	Alarm deactivation		
						Alarm reset	CPU reset	Cycling the power
Alarm	65	Functional safety unit connection error	65.1	Functional safety unit communication error 1	SD			○
			65.2	Functional safety unit communication error 2	SD			○
			65.3	Functional safety unit communication error 3	SD			○
			65.4	Functional safety unit communication error 4	SD			○
			65.5	Functional safety unit communication error 5	SD			○
			65.6	Functional safety unit communication error 6	SD			○
			65.7	Functional safety unit communication error 7	SD			○
			65.8	Functional safety unit shut-off signal error 1	DB			○
			65.9	Functional safety unit shut-off signal error 2	DB			○
	66	Encoder initial communication error (safety observation function)	66.1	Encoder initial communication - Receive data error 1 (safety observation function)	DB			○
			66.2	Encoder initial communication - Receive data error 2 (safety observation function)	DB			○
			66.3	Encoder initial communication - Receive data error 3 (safety observation function)	DB			○
			66.7	Encoder initial communication - Transmission data error 1 (safety observation function)	DB			○
			66.9	Encoder initial communication - Process error 1 (safety observation function)	DB			○
	67	Encoder normal communication error 1 (safety observation function)	67.1	Encoder normal communication - Receive data error 1 (safety observation function)	DB			○
			67.2	Encoder normal communication - Receive data error 2 (safety observation function)	DB			○
			67.3	Encoder normal communication - Receive data error 3 (safety observation function)	DB			○
			67.4	Encoder normal communication - Receive data error 4 (safety observation function)	DB			○
			67.7	Encoder normal communication - Transmission data error 1 (safety observation function)	DB			○
	68	STO diagnosis error	68.1	Mismatched STO signal error	DB			○
	69	Command error	69.1	Forward rotation-side software limit detection - Command excess error	SD	○	○	○
			69.2	Reverse rotation-side software limit detection - Command excess error	SD	○	○	○
			69.3	Forward rotation stroke end detection - Command excess error	SD	○	○	○
			69.4	Reverse rotation stroke end detection - Command excess error	SD	○	○	○
			69.5	Upper stroke limit detection - Command excess error	SD	○	○	○
			69.6	Lower stroke limit detection - Command excess error	SD	○	○	○

4. TROUBLESHOOTING

	No.	Name	Detail No.	Detail name	Stop method (Note 2, 3)	Alarm deactivation		
						Alarm reset	CPU reset	Cycling the power
Alarm	70	Load-side encoder initial communication error 1	70.1	Load-side encoder initial communication - Receive data error 1	DB			○
			70.2	Load-side encoder initial communication - Receive data error 2	DB			○
			70.3	Load-side encoder initial communication - Receive data error 3	DB			○
			70.5	Load-side encoder initial communication - Transmission data error 1	DB			○
			70.6	Load-side encoder initial communication - Transmission data error 2	DB			○
			70.7	Load-side encoder initial communication - Transmission data error 3	DB			○
			70.A	Load-side encoder initial communication - Process error 1	DB			○
			70.B	Load-side encoder initial communication - Process error 2	DB			○
			70.C	Load-side encoder initial communication - Process error 3	DB			○
			70.D	Load-side encoder initial communication - Process error 4	DB			○
			70.E	Load-side encoder initial communication - Process error 5	DB			○
			70.F	Load-side encoder initial communication - Process error 6	DB			○
	71	Load-side encoder normal communication error 1	71.1	Load-side encoder normal communication - Receive data error 1	EDB			○
			71.2	Load-side encoder normal communication - Receive data error 2	EDB			○
			71.3	Load-side encoder normal communication - Receive data error 3	EDB			○
			71.5	Load-side encoder normal communication - Transmission data error 1	EDB			○
			71.6	Load-side encoder normal communication - Transmission data error 2	EDB			○
			71.7	Load-side encoder normal communication - Transmission data error 3	EDB			○
			71.9	Load-side encoder normal communication - Receive data error 4	EDB			○
			71.A	Load-side encoder normal communication - Receive data error 5	EDB			○

4. TROUBLESHOOTING

	No.	Name	Detail No.	Detail name	Stop method (Note 2, 3)	Alarm deactivation		
						Alarm reset	CPU reset	Cycling the power
Alarm	72	Load-side encoder normal communication error 2	72.1	Load-side encoder data error 1	EDB			○
			72.2	Load-side encoder data update error	EDB			○
			72.3	Load-side encoder data waveform error	EDB			○
			72.4	Load-side encoder non-signal error	EDB			○
			72.5	Load-side encoder hardware error 1	EDB			○
			72.6	Load-side encoder hardware error 2	EDB			○
			72.9	Load-side encoder data error 2	EDB			○
	74	Option card error 1	74.1	Option card error 1	DB			○
			74.2	Option card error 2	DB			○
			74.3	Option card error 3	DB			○
			74.4	Option card error 4	DB			○
			74.5	Option card error 5	DB			○
	75	Option card error 2	75.3	Option card connection error	EDB			○
			75.4	Option card disconnected	DB			○
	79	Functional safety unit diagnosis error	79.1	Functional safety unit power voltage error	DB	○ (Note 7)		○
			79.2	Functional safety unit internal error	DB			○
			79.3	Abnormal temperature of functional safety unit	SD	○ (Note 7)		○
			79.4	Servo amplifier error	SD			○
			79.5	Input device error	SD			○
			79.6	Output device error	SD			○
			79.7	Mismatched input signal error	SD			○
			79.8	Position feedback fixing error	DB			○
	7A	Parameter setting error (safety observation function)	7A.1	Parameter verification error (safety observation function)	DB			○
			7A.2	Parameter setting range error (safety observation function)	DB			○
			7A.3	Parameter combination error (safety observation function)	DB			○
			7A.4	Functional safety unit combination error (safety observation function)	DB			○
	7B	Encoder diagnosis error (safety observation function)	7B.1	Encoder diagnosis error 1 (safety observation function)	DB			○
			7B.2	Encoder diagnosis error 2 (safety observation function)	DB			○
			7B.3	Encoder diagnosis error 3 (safety observation function)	DB			○
			7B.4	Encoder diagnosis error 4 (safety observation function)	DB			○
	7C	Functional safety unit communication diagnosis error (safety observation function)	7C.1	Functional safety unit communication setting error (safety observation function)	SD	○ (Note 7)	○	○
			7C.2	Functional safety unit communication data error (safety observation function)	SD	○ (Note 7)	○	○
	7D	Safety observation error	7D.1	Stop observation error	DB	○ (Note 3)		○
			7D.2	Speed observation error	DB	○ (Note 7)		○
	82	Master-slave operation error 1	82.1	Master-slave operation error 1	EDB	○	○	○

4. TROUBLESHOOTING

	No.	Name	Detail No.	Detail name	Stop method (Note 2, 3)	Alarm deactivation		
						Alarm reset	CPU reset	Cycling the power
Alarm	84	Network module initialization error	84.1	Network module undetected error	DB			○
			84.2	Network module initialization error 1	DB			○
			84.3	Network module initialization error 2	DB			○
	85	Network module error	85.1	Network module error 1	SD			○
			85.2	Network module error 2	SD			○
			85.3	Network module error 3	SD			○
	86	Network communication error	86.1	Network communication error 1	SD	○		○
			86.2	Network communication error 2	SD	○		○
			86.3	Network communication error 3	SD	○		○
	8A	USB communication time-out error/serial communication time-out error/Modbus-RTU communication time-out error	8A.1	USB communication time-out error/serial communication time-out error	SD	○	○	○
			8A.2	Modbus-RTU communication time-out error	SD	○	○	○
	8D	CC-Link IE communication error	8D.1	CC-Link IE communication error 1	SD	○		○
			8D.2	CC-Link IE communication error 2	SD	○		○
			8D.3	Master station setting error 1	DB	○		○
			8D.5	Master station setting error 2	DB			○
			8D.6	CC-Link IE communication error 3	SD	○		○
			8D.7	CC-Link IE communication error 4	SD	○		○
			8D.8	CC-Link IE communication error 5	SD	○		○
			8D.9	Synchronization error 1	SD			○
			8D.A	Synchronization error 2	SD			○
	8E	USB communication error/serial communication error/Modbus-RTU communication error	8E.1	USB communication receive error/serial communication receive error	SD	○	○	○
			8E.2	USB communication checksum error/serial communication checksum error	SD	○	○	○
			8E.3	USB communication character error/serial communication character error	SD	○	○	○
			8E.4	USB communication command error/serial communication command error	SD	○	○	○
			8E.5	USB communication data number error/serial communication data number error	SD	○	○	○
			8E.6	Modbus-RTU communication receive error	SD	○	○	○
			8E.7	Modbus-RTU communication message frame error	SD	○	○	○
			8E.8	Modbus-RTU communication CRC error	SD	○	○	○
	88888	Watchdog	8888_	Watchdog	DB			○

4. TROUBLESHOOTING

Note 1. Leave for about 30 minutes of cooling time after removing the cause of occurrence.

2. The following shows three stop methods of DB, EDB, and SD.

DB: Stops with dynamic brake. (Coasts for the servo amplifier without dynamic brake.)

Coasts for MR-J4-03A6(-RJ) and MR-J4W2-0303B6. Note that EDB is applied when an alarm below occurs;

[AL. 30.1], [AL. 32.2], [AL. 32.4], [AL. 51.1], [AL. 51.2], [AL. 888]

EDB: Electronic dynamic brake stop (available with specified servo motors)

Refer to the following table for the specified servo motors. The stop method for other than the specified servo motors will be DB.

Series	Servo motor
HG-KR	HG-KR053/HG-KR13/HG-KR23/HG-KR43
HG-MR	HG-MR053/HG-MR13/HG-MR23/HG-MR43
HG-SR	HG-SR51/HG-SR52
HG-AK	HG-AK0136/HG-AK0236/HG-AK0336

SD: Forced stop deceleration

3. This is applicable when [Pr. PA04] is set to the initial value. The stop system of SD can be changed to DB using [Pr. PA04].

4. The alarm can be canceled by setting as follows:

For the fully closed loop control: set [Pr. PE03] to "1 _ _ _".

When a linear servo motor or direct drive motor is used: set [Pr. PL04] to "1 _ _ _".

5. In some controller communication status, the alarm factor may not be removed.

6. This alarm will occur only in the J3 compatibility mode.

7. Reset this while all the safety observation functions are stopped.

4. TROUBLESHOOTING

4.3 Warning list

	No.	Name	Detail No.	Detail name	Stop method (Note 2, 3)
Warning	90	Home position return incomplete warning	90.1	Home position return incomplete	
			90.2	Home position return abnormal termination	
			90.5	Z-phase unpassed	
	91	Servo amplifier overheat warning (Note 1)	91.1	Main circuit device overheat warning	
	92	Battery cable disconnection warning	92.1	Encoder battery cable disconnection warning	
			92.3	Battery degradation	
	93	ABS data transfer warning	93.1	ABS data transfer requirement warning during magnetic pole detection	
	95	STO warning	95.1	STO1 off detection	DB
			95.2	STO2 off detection	DB
			95.3	STO warning 1 (safety observation function)	DB
			95.4	STO warning 2 (safety observation function)	DB
			95.5	STO warning 3 (safety observation function)	DB
	96	Home position setting warning	96.1	In-position warning at home positioning	
			96.2	Command input warning at home positioning	
			96.3	Servo off warning at home positioning	
			96.4	Home positioning warning during magnetic pole detection	
	97	Positioning specification warning	97.1	Program operation disabled warning	
			97.2	Next station position warning	
	98	Software limit warning	98.1	Forward rotation-side software stroke limit reached	
			98.2	Reverse rotation-side software stroke limit reached	
	99	Stroke limit warning	99.1	Forward rotation stroke end off	(Note 4, 5)
			99.2	Reverse rotation stroke end off	(Note 4, 5)
			99.4	Upper stroke limit off	(Note 5)
			99.5	Lower stroke limit off	(Note 5)
	9A	Optional unit input data error warning	9A.1	Optional unit input data sign error	
			9A.2	Optional unit BCD input data error	
	9B	Error excessive warning	9B.1	Excess droop pulse 1 warning	
			9B.3	Excess droop pulse 2 warning	
			9B.4	Error excessive warning during 0 torque limit	
	9C	Converter error	9C.1	Converter unit error	
	9D	CC-Link IE warning 1	9D.1	Station number switch change warning	
			9D.2	Master station setting warning	
			9D.3	Overlapping station number warning	
			9D.4	Mismatched station number warning	

4. TROUBLESHOOTING

	No.	Name	Detail No.	Detail name	Stop method (Note 2, 3)
Warning	9E	CC-Link IE warning 2	9E.1	CC-Link IE communication warning	
	9F	Battery warning	9F.1	Low battery	
			9F.2	Battery degradation warning	
	E0	Excessive regeneration warning	E0.1	Excessive regeneration warning	
	E1	Overload warning 1	E1.1	Thermal overload warning 1 during operation	
			E1.2	Thermal overload warning 2 during operation	
			E1.3	Thermal overload warning 3 during operation	
			E1.4	Thermal overload warning 4 during operation	
			E1.5	Thermal overload error 1 during a stop	
			E1.6	Thermal overload error 2 during a stop	
			E1.7	Thermal overload error 3 during a stop	
			E1.8	Thermal overload error 4 during a stop	
	E2	Servo motor overheat warning	E2.1	Servo motor temperature warning	
	E3	Absolute position counter warning	E3.1	Multi-revolution counter travel distance excess warning	
			E3.2	Absolute position counter warning	
			E3.4	Absolute positioning counter EEPROM writing frequency warning	
			E3.5	Encoder absolute positioning counter warning	
	E4	Parameter warning	E4.1	Parameter setting range error warning	
	E5	ABS time-out warning	E5.1	Time-out during ABS data transfer	
			E5.2	ABSM off during ABS data transfer	
			E5.3	SON off during ABS data transfer	
	E6	Servo forced stop warning	E6.1	Forced stop warning	SD
			E6.2	SS1 forced stop warning 1 (safety observation function)	SD
			E6.3	SS1 forced stop warning 2 (safety observation function)	SD
	E7	Controller forced stop warning	E7.1	Controller forced stop input warning	SD
	E8	Cooling fan speed reduction warning	E8.1	Decreased cooling fan speed warning	
			E8.2	Cooling fan stop	
	E9	Main circuit off warning	E9.1	Servo-on signal on during main circuit off	DB
			E9.2	Bus voltage drop during low speed operation	DB
			E9.3	Ready-on signal on during main circuit off	DB
			E9.4	Converter unit forced stop	DB
	EA	ABS servo-on warning	EA.1	ABS servo-on warning	
	EB	The other axis error warning	EB.1	The other axis error warning	DB
	EC	Overload warning 2	EC.1	Overload warning 2	

4. TROUBLESHOOTING

	No.	Name	Detail No.	Detail name	Stop method (Note 2, 3)
Warning	ED	Output watt excess warning	ED.1	Output watt excess warning	
	F0	Tough drive warning	F0.1	Instantaneous power failure tough drive warning	
			F0.3	Vibration tough drive warning	
	F2	Drive recorder - Miswriting warning	F2.1	Drive recorder - Area writing time-out warning	
			F2.2	Drive recorder - Data miswriting warning	
	F3	Oscillation detection warning	F3.1	Oscillation detection warning	
	F4	Positioning warning	F4.4	Target position setting range error warning	
			F4.6	Acceleration time constant setting range error warning	
			F4.7	Deceleration time constant setting range error warning	
			F4.9	Home position return type error warning	
	F5	Simple cam function - Cam data miswriting warning	F5.1	Cam data - Area writing time-out warning	
			F5.2	Cam data - Area miswriting warning	
			F5.3	Cam data checksum error	
	F6	Simple cam function - Cam control warning	F6.1	Cam axis one cycle current value restoration failed	
			F6.2	Cam axis feed current value restoration failed	
			F6.3	Cam unregistered error	
			F6.4	Cam control data setting range error	
			F6.5	Cam No. external error	
			F6.6	Cam control inactive	
	F7	Machine diagnosis warning	F7.1	Vibration failure prediction warning	
			F7.2	Friction failure prediction warning	
			F7.3	Total travel distance failure prediction warning	

- Note
1. Leave for about 30 minutes of cooling time after removing the cause of occurrence.
 2. The following shows two stop methods of DB and SD.
DB: Stops with dynamic brake. (Coasts for the servo amplifier without dynamic brake.)
Coasts for MR-J4-03A6(-RJ) and MR-J4W2-0303B6.
SD: Forced stop deceleration
 3. This is applicable when [Pr. PA04] is set to the initial value. The stop system of SD can be changed to DB using [Pr. PA04].
 4. For MR-J4-_A_ servo amplifier, quick stop or slow stop can be selected using [Pr. PD30].
 5. For MR-J4-_GF_ servo amplifier, quick stop or slow stop can be selected using [Pr. PD12]. (I/O mode only)

4. TROUBLESHOOTING

4.4 Troubleshooting at power on

When an error occurs at the power supply of the controller or servo amplifier, improper boot of the servo amplifier might be the cause. Check the display of the servo amplifier, and take actions according to this section.

Display	Description	Cause	Checkpoint	Action
AA	The power of the controller was turned off.	The power of the controller was turned off.	Check the power of the controller.	Switch on the power of the controller.
		An Ethernet cable was disconnected.	"AA" is displayed in the corresponding station and following stations.	Replace the Ethernet cable of the corresponding station.
			Check if the connectors (CN1A, CN1B) are unplugged.	Connect it correctly.
Ab	Initialization communication with the controller has not completed.	An Ethernet cable was disconnected.	"Ab" is displayed in the corresponding station and following stations.	Replace the Ethernet cable of the corresponding station.
		The power of the servo amplifier was switched on when the power of the controller was off.	Check the power of the controller.	Switch on the power of the controller.
		The servo amplifier is malfunctioning.	"Ab" is displayed in the corresponding station and following stations.	Replace the servo amplifier.
		The controller is malfunctioning.	Replace the controller, and then check the repeatability.	Replace the controller.
AC	The synchronous communications by specified cycle could not be made.	The setting of the station No. is incorrect.	Check that a device is not assigned to the same station No.	Set it correctly.
		Station No. does not match with the station No. set to the controller.	Check the controller setting and station No.	Set it correctly.
		The communication cycle does not match.	Check the communication cycle at the controller side.	Set it correctly.
		The servo amplifier parameter setting is incorrect.	Check the following parameter settings. [Pr. PN03] [Pr. PD41]	Set it correctly.
		Data link was established again.	Network configuration was changed.	After checking the network configuration, cycle the power of the servo amplifier.
		The controller setting is incorrect.	Check the controller setting.	Set it correctly.
		The servo amplifier is malfunctioning.	"AC" is displayed in the corresponding station and following stations.	Replace the servo amplifier.
		The controller is malfunctioning.	Replace the controller, and then check the repeatability.	Replace the controller.
b##. C##. d##. (Note)	The system has been in the test operation mode.	Test operation mode has been enabled.	Test operation select switch (SW1-1) is turned on.	Turn off the test operation select switch (SW1-1).
off	Operation mode for manufacturer setting is set.	Operation mode for manufacturer setting is enabled.	Check that the test operation select switch (SW1-1) and manufacturer setting switch (SW1-2) are not on.	Set the auxiliary station number setting switch (SW1) correctly.

Note. ## indicates station No.

[illegible]

5. INDEXER OPERATION

5. INDEXER OPERATION

The items shown in the following table are the same as those for the motion mode. For details, refer to each section indicated in the detailed explanation field. "MR-J4-_GF_" means "MR-J4-_GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)".

Item	Detailed explanation
Startup	MR-J4-_GF_ section 4.2
Switch setting and display of the servo amplifier	MR-J4-_GF_ section 4.3
Test operation	MR-J4-_GF_ section 4.4
Test operation mode	MR-J4-_GF_ section 4.5

POINT
<ul style="list-style-type: none">● The indexer operation can be used with servo amplifiers with software version A3 or later.● In the absolute position detection system, rotating the shaft one revolution or more during power-off may erase a home position. Therefore, do not rotate the shaft one revolution or more during power-off. At operation start-up after a home position is erased, [AL. 90 Home position return incomplete warning] will occur. In that case, execute the home position return again.● There are the following restrictions on [Pr. PA06 Number of gear teeth on machine side] and the servo motor speed (N).<ul style="list-style-type: none">▪ When [Pr. PA06] ≤ 2000, $N < 3076.7 \text{ r/min}$▪ When [Pr. PA06] > 2000, $N < (3276.7 - \text{CMX})/10 \text{ r/min}$When the servo motor is operated continuously at a servo motor speed higher than the limit value, [AL. E3 Absolute position counter warning] will occur.● The setting of [Pr. PC77 Internal torque limit 2] will be enabled automatically depending on the operation status. Since the initial value of [Pr. PC77] is 0.0%, change the value to use the indexer operation. If the value is unchanged, the servo motor coasts during a stop.

5.1 Link device

5.1.1 Profile

Some input devices can be assigned to the pins of the CN3 connector with [Pr. PD03] to [Pr. PD05]. The assigned devices other than the upper stroke limit, lower stroke limit, and proximity dog can be used together with CC-Link IE Field Network communication and input signals of the CN3 connector.

Some output devices can be assigned to the pins of the CN3 connector with [Pr. PD07] to [Pr. PD09]. The assigned devices can be used together with CC-Link IE Field Network communication and output signals of the CN3 connector.

When turning off input/output signals, turn off both CC-Link IE Field Network communication and external I/O signals of the CN3 connector. The following shows the profile of link devices communicated with the master station in cyclic communication.

5. INDEXER OPERATION

Table 5.1 RYn/RXn profile

Master station → Servo amplifier (RYn)				Servo amplifier → Master station (RXn)			
(Note) Device No.	Device	Symbol	CN3 connector pin No.	(Note) Device No.	Device	Symbol	CN3 connector pin No.
RYn0	Servo-on	SON		RXn0	Ready	RD	
RYn1	Start	ST1		RXn1	In-position	INP	9
RYn2	Rotation direction specifying	SIG		RXn2	Rough match	CPO	
RYn3	Proximity dog	DOG	19	RXn3	Unavailable		
RYn4	Unavailable			RXn4	Limiting torque	TLC	
RYn5				RXn5	Unavailable		
RYn6	Operation mode selection 1	MD0		RXn6	Electromagnetic brake interlock	MBR	13
RYn7	Operation mode selection 2	MD1		RXn7	Unavailable		
RYn8	Monitor output execution demand	MOR		RXn8	Monitoring	MOF	
RYn9	Instruction code execution demand	COR		RXn9	Instruction code execution completion	COF	
RYnA to RYnF	Unavailable			RXnA	Warning	WNG	
RY (n + 1) 0	Upper stroke limit	FLS		RXnB	Battery warning	BWNG	
RY (n + 1) 1	Lower stroke limit	RLS		RXnC	Travel completion	MEND	
RY (n + 1) 2	Operation alarm reset	ORST		RXnD	Dynamic brake interlock	DB	
RY (n + 1) 3 to RY (n + 1) F	Unavailable			RXnE	Unavailable		
RY (n + 2) 0	Position command execution demand	PSR		RXnF			
RY (n + 2) 1	Speed command execution demand	SPR		RX (n + 1) 0	Home position return completion 2	ZP2	
RY (n + 2) 2 to RY (n + 2) 6	Unavailable			RX (n + 1) 1 to RX (n + 1) F	Unavailable		
RY (n + 2) 7	Proportional control	PC		RX (n + 2) 0	Position command execution completion	PSF	
RY (n + 2) 8	Gain switching	CDP		RX (n + 2) 1	Speed command execution completion	SPF	
RY (n + 2) 9	Unavailable			RX (n + 2) 2 to RX (n + 2) F	Unavailable		
RY (n + 2) A	Position/speed specifying method selection	CSL		RX (n + 3) 0 to RX (n + 3) 9			
RY (n + 2) B to RY (n + 2) F	Unavailable			RX (n + 3) A	Malfunction	ALM	15
RY (n + 3) 0 to RY (n + 3) 9				RX (n + 3) B	Remote station communication ready	CRD	
RY (n + 3) A	Reset	RES		RX (n + 3) C to RX (n + 3) F	Unavailable		
RY (n + 3) B to RY (n + 3) F	Unavailable						

Note. "n" depends on the station No. setting.

5. INDEXER OPERATION

Table 5.2 RWwn/RWrn profile

Master station → Servo amplifier (RWwn)		Servo amplifier → Master station (RWrn)	
(Note 1) Device No.	Device	(Note 1) Device No.	Device
RWwn0	Monitor 1	RWrn0	Monitor 1 data - Lower 16 bits
RWwn1	Unavailable	RWrn1	Monitor 1 data - Upper 16 bits
RWwn2	Monitor 2	RWrn2	Monitor 2 data - Lower 16 bits
RWwn3	Unavailable	RWrn3	Monitor 2 data - Upper 16 bits
RWwn4	Instruction code - Lower 16 bits	RWrn4	Respond code
RWwn5	Instruction code - Upper 16 bits	RWrn5	Unavailable
RWwn6	Next station No. selection	RWrn6	Station No. output
RWwn7	Speed selection	RWrn7	Unavailable
RWwn8	Next station No. (Note 2)	RWrn8	
RWwn9	Unavailable	RWrn9	
		RWrnA	
RWwnA	Speed command data - Lower 16 bits/Point table No. (Note 2)	RWrnB	
RWwnB	Speed command data - Upper 16 bits (Note 2)	RWrnC	Reading data - Lower 16 bits
RWwnC	Writing data - Lower 16 bits	RWrnD	Reading data - Upper 16 bits
RWwnD	Writing data - Upper 16 bits	RWrnE	Unavailable
RWwnE	Unavailable	RWrnF	
RWwnF			

- Note 1. "n" depends on the station No. setting.
 2. Use this device when the remote register-based position/speed specifying method is selected.

5. INDEXER OPERATION

5.1.2 Detailed explanation of the RYn/RXn profile

(1) RYn profile

Device No.	Device	Description													
RYn0	Servo-on	Turn on RYn0 to power on the base circuit, and make the servo amplifier ready to operate. (servo-on status) Turn it off to shut off the base circuit, and coast the servo motor.													
RYn1	Start	1. Automatic operation mode Turning on RYn1 will execute one positioning operation to the specified station No. 2. Manual operation mode When the station JOG operation is set, turning on RYn1 will rotate the servo motor in the direction specified with RYn2 only while RYn1 is on. Turning off RYn1 will execute a positioning to a station position at which the servo motor can decelerate to a stop. When the JOG operation is set, turning on RYn1 will rotate the motor in the direction specified with RYn2 only while RYn1 is on. Turning off will decelerate the motor to a stop regardless of the station position. 3. Home position return mode Turning on RYn1 will start home position return.													
RYn2	Rotation direction specifying	Specify the rotation direction at start by turning on/off RYn2. 1. Automatic operation mode The rotation direction varies depending on the setting of [Pr. PA14]. RYn2 is only for the rotation direction specifying indexer. This is not used with the shortest rotating indexer operation. <table border="1"><thead><tr><th>RYn2</th><th>Pr. PA14</th><th>Servo motor rotation direction</th></tr></thead><tbody><tr><td rowspan="2">Off</td><td>0</td><td>CCW or positive direction</td></tr><tr><td>1</td><td>CW or negative direction</td></tr><tr><td rowspan="2">On</td><td>0</td><td>CW or negative direction</td></tr><tr><td>1</td><td>CCW or positive direction</td></tr></tbody></table> 2. Manual operation mode The rotation direction varies depending on the setting of [Pr. PA14]. The relation between the parameter and rotation direction is the same as that for the automatic operation mode. 3. Home position return mode RYn2 is disabled. Specify the rotation direction in the home position return mode with [Pr. PT45].	RYn2	Pr. PA14	Servo motor rotation direction	Off	0	CCW or positive direction	1	CW or negative direction	On	0	CW or negative direction	1	CCW or positive direction
RYn2	Pr. PA14	Servo motor rotation direction													
Off	0	CCW or positive direction													
	1	CW or negative direction													
On	0	CW or negative direction													
	1	CCW or positive direction													
RYn3	Proximity dog	When RYn3 is turned off, a proximity dog will be detected. The polarity for dog can be changed with [Pr. PT29]. <table border="1"><thead><tr><th>[Pr. PT29]</th><th>Polarity for proximity dog detection</th></tr></thead><tbody><tr><td>___0 (initial value)</td><td>Detection with off</td></tr><tr><td>___1</td><td>Detection with on</td></tr></tbody></table>	[Pr. PT29]	Polarity for proximity dog detection	___0 (initial value)	Detection with off	___1	Detection with on							
[Pr. PT29]	Polarity for proximity dog detection														
___0 (initial value)	Detection with off														
___1	Detection with on														
RYn6	Operation mode selection 1	Select an operation mode with the settings of RYn6 and RYn7. <table border="1"><thead><tr><th>RYn7</th><th>RYn6</th><th>Operation mode</th></tr></thead><tbody><tr><td>Off</td><td>Off</td><td>Home position return mode</td></tr><tr><td>Off</td><td>On</td><td>Manual operation mode</td></tr></tbody></table>	RYn7	RYn6	Operation mode	Off	Off	Home position return mode	Off	On	Manual operation mode				
RYn7	RYn6	Operation mode													
Off	Off	Home position return mode													
Off	On	Manual operation mode													
RYn7	Operation mode selection 2	<table border="1"><tbody><tr><td>On</td><td>Off</td><td>Automatic operation mode (rotation direction specifying indexer)</td></tr><tr><td>On</td><td>On</td><td>Automatic operation mode (shortest rotating indexer)</td></tr></tbody></table>	On	Off	Automatic operation mode (rotation direction specifying indexer)	On	On	Automatic operation mode (shortest rotating indexer)							
On	Off	Automatic operation mode (rotation direction specifying indexer)													
On	On	Automatic operation mode (shortest rotating indexer)													

5. INDEXER OPERATION

Device No.	Device	Description
RYn8	Monitor output execution demand	Turning on RYn8 sets the following data and turns on RXn8. While RYn8 is on, the monitor value is always updated. RWrn0: Lower 16 bits of data requested with RWwn0 (Monitor 1) RWrn1: Upper 16 bits of data requested with RWwn0 (Monitor 1) RWrn2: Lower 16 bits of data requested with RWwn2 (Monitor 2) RWrn3: Upper 16 bits of data requested with RWwn2 (Monitor 2) RWrn4: Respond code indicating a normal or error result
RYn9	Instruction code execution demand	Turning on RYn9 executes the processing corresponding to the instruction code set with RWwn4 and RWwn5. After the instruction code execution is completed, a respond code indicating a normal or error result is stored in RWrn4, and RXn9 turns on. Refer to section 2.1.4 (2) for details of instruction codes.
RY (n + 1) 0	Upper stroke limit	To execute the operation, turn on RY (n + 1) 0 and RY (n + 1) 1. Turning off the device corresponding to the servo motor rotation direction will bring the servo motor to a slow stop and make it servo-locked. The stop method can be changed with [Pr. PD12]. The home position is not erased; however, home position return may be required in some cases. Refer to [Pr. PD12] and section 3.4 for details.
RY (n + 1) 1	Lower stroke limit	
RY (n + 1) 2	Operation alarm reset	Turn on RY (n + 1) 2 from off to reset [AL. F4 Positioning warning].
RY (n + 2) 0	Position command execution demand	Turning on RY (n + 2) 0 sets the next station No. set in RWwn8. If a next station No. is set to the servo amplifier, a respond code indicating a normal or error result is set in RWrn4 and RX (n + 2) 0 (Position command execution completion) turns on. Refer to section 2.1.6 for details.
RY (n + 2) 1	Speed command execution demand	Turning on RY (n + 2) 1 sets the point table No. or speed command data set in RWwnA and RWwnB. If a point table No. or speed command data is set to the servo amplifier, a respond code indicating a normal or error result is set in RWrn4 and RX (n + 2) 1 (Position command execution completion) turns on. Refer to section 2.1.6 for details.
RY (n + 2) 7	Proportional control	Turn on RY (n + 2) 7 to switch the speed amplifier from the proportional integral type to the proportional type. If the servo motor at a stop is rotated even one pulse due to any external factor, it generates torque to compensate for a position shift. When the servo motor shaft is to be locked mechanically after RXnC (Travel completion) is turned off, switching on RY (n + 2) 7 (Proportional control) upon turning RXnC (Travel completion) off will suppress the unnecessary torque generated to compensate for a position shift. When the shaft is to be locked for a long time, turn on RY (n + 2) 7 (Proportional control) and make the torque less than the rated torque with the torque limit.
RY (n + 2) 8	Gain switching	Turn on RY (n + 2) 8 to use the values of [Pr. PB29] to [Pr. PB36] and [Pr. PB56] to [Pr. PB60] as the load to motor inertia ratio and gain values.
RY (n + 2) A	Position/speed specifying method selection	Select how to give a position command and speed command. Off: Specify a next station No. with RWwn6 to give a position command. Specify a point table No. with RWwn7 to give a speed command. On: When [Pr. PT62] is set to " __ 0 __", specify a next station No. with RWwn8 to give a position command, and specify a point table No. with RWwnA to give a speed command. When [Pr. PT62] is set to " __ 1 __", specify a next station No. with RWwn8 to give a position command, and specify speed command data with RWwnA and RWwnB to give a speed command.
RY (n + 3) A	Reset	Turn on RY (n + 3) A to reset alarms. However, some alarms cannot be cleared with RY (n + 3) A.

5. INDEXER OPERATION

(2) RXn profile

Device No.	Device	Description
RXn0	Ready	When the servo-on is on and the servo amplifier is ready to operate, RXn0 turns on.
RXn1	In-position	When the number of droop pulses is in the preset in-position range, RXn1 turns on. The in-position range can be changed with [Pr. PA10]. When the in-position range is increased, RXn1 may be always on during low-speed rotation.
RXn2	Rough match	When a command remaining distance is lower than the rough match output range set with [Pr. PT12], RXn2 turns on. This is not outputted during base circuit shut-off.
RXn4	Limiting torque	RXn4 turns on when a generated torque reaches a value set with [Pr. PA11 Forward rotation torque limit] or [Pr. PA12 Reverse rotation torque limit].
RXn6	Electromagnetic brake interlock	When using the device, set operation delay time of the electromagnetic brake in [Pr. PC02]. When a servo-off status or alarm occurs, RXn6 turns off.
RXn8	Monitoring	Refer to RYn8 (Monitor output execution demand).
RXn9	Instruction code execution completion	Refer to RYn9 (Instruction code execution demand).
RXnA	Warning	When a warning occurs, RXnA turns on. When a warning is not occurring, turning on the power will turn off RXnA after 4 s to 5 s.
RXnB	Battery warning	RXnB turns on when [AL. 92 Battery cable disconnection warning] or [AL. 9F Battery warning] has occurred. When the battery warning is not occurring, turning on the power will turn off RXnB after 4 s to 5 s.
RXnC	Travel completion	When the number of droop pulses is within the in-position output range set with [Pr. PA10] and the command remaining distance is "0", RXnC turns on. In the servo-off status, when the number of droop pulses is within the in-position range of each next station position and the command remaining distance is "0", RXnC turns on as well.
RXnD	Dynamic brake interlock	RXnD turns off when the dynamic brake needs to operate.
RX (n + 1) 0	Home position return completion 2	When a home position return completes normally, RX (n + 1) 0 turns on. RX (n + 1) 0 is always on unless the home position is erased. In the incremental system, it turns off with one of the following conditions. 1) [AL. 69 Command error] occurs. 2) Home position return is not being executed. 3) Home position return is in progress. If a home position return completes once in the absolute position detection system, RX (n + 1) 0 is always on. However, it will be off with one of the conditions 1) to 3) or the following conditions 4) to 8). 4) The home position return is not performed after [AL. 25 Absolute position erased] and [AL. E3 Absolute position counter warning] occurred. 5) The home position return is not performed after the electronic gear ([Pr. PA06] and [Pr. PA07]) was changed. 6) The home position return is not performed after the setting of [Pr. PA03 Absolute position detection system selection] was changed from "Disabled" to "Enabled". 7) [Pr. PA14 Rotation direction selection/travel direction selection] was changed. 8) [Pr. PA01 Operation mode] was changed.
RX (n + 2) 0	Position command execution completion	Refer to RY (n + 2) 0 (Position command execution demand).
RX (n + 2) 1	Speed command execution completion	Refer to RY (n + 2) 1 (Speed command execution demand).
RX (n + 3) A	Malfunction	When an alarm occurs, RX (n + 3) A will turn on. When an alarm is not occurring, turning on the power will turn off RX (n + 3) A after 4 s to 5 s.
RX (n + 3) B	Remote station communication ready	Turning on the power will turn on RX (n + 3) B. When an alarm occurs, RX (n + 3) B will turn off.

5. INDEXER OPERATION

5.1.3 Detailed explanation of the RWwn/RWrn profile

(1) RWwn profile

Device No.	Device	Description	Setting range
RWwn0	Monitor 1	Setting a monitor code to monitor in RWwn0 and turning on RYn8 store data in RWrn0 and RWrn1. At this time, RXn8 turns on. Refer to section 2.1.4 (1) for monitor codes for status display.	Refer to section 2.1.4 (1).
RWwn2	Monitor 2	Setting a monitor code to monitor in RWwn2 and turning on RYn8 store data in RWrn2 and RWrn3. At this time, RXn8 turns on. Refer to section 2.1.4 (1) for monitor codes for status display.	Refer to section 2.1.4 (1).
RWwn4	Instruction code - Lower 16 bits	Set an instruction code No. used to read or write a parameter or point table data or to refer to an alarm. Setting an instruction code No. in RWwn4 and turning on RYn9 execute the instruction. RXn9 turns on after the instruction execution is completed. Refer to section 2.1.4 (2) for the instruction code No.	Refer to section 2.1.4 (2).
RWwn5	Instruction code - Upper 16 bits	When a value other than "0000h" is set in this device, the instruction code is not executed even if RYn9 is turned on and "_ 1 _" is set in respond code.	0000h
RWwn6	Next station No. selection	Set a target next station No. Even if a value out of the setting range is set, an alarm or warning does not occur. However, the set value is invalid and the previous setting value is used.	0 to 254
RWwn7	Speed selection	To execute the positioning operation, select a point table No. that stores speed command data.	Point table No.: 1 to 255
RWwn8	Next station No.	This function can be used while RY (n + 2) A (Position/speed specifying method selection) is on (the remote register-based position/speed specifying method is selected). Setting a target next station No. in RWwn8 and turning on RY (n + 2) 0 set the next station No. in the servo amplifier. After the setting is completed, RX (n + 2) 0 turns on.	0 to 254
RWwnA	Point table No./speed command data - Lower 16 bits	This function can be used while RY (n + 2) A (Position/speed specifying method selection) is on (the remote register-based position/speed specifying method is selected). (1) When using speed data of point tables Set [Pr. PT62] to "_ _ 0 _". Setting a point table No. in RWwnA and turning on RY (n + 2) 1 set the point table No. in the servo amplifier. After the setting is completed, RX (n + 2) 1 turns on. (2) When setting a servo motor speed directly Set [Pr. PT62] to "_ _ 1 _". Setting the lower 16 bits of the speed command data in RWwnA and the upper 16 bits of the speed command data in RWwnB and turning on RY (n + 2) 1 enable the settings. After the setting is completed, RX (n + 2) 1 turns on. Use [Pr. PT62] to select whether to set a point table No. or speed command data. Refer to section 2.1.6 for details of the point table No. or speed command data. When setting a servo motor speed in this remote register, always set an acceleration time constant and deceleration time constant in point table No. 1.	Point table No.: 1 to 255 Speed command data: 0 to permissible speed
RWwnB	Speed command data - Upper 16 bits		
RWwnC	Writing data - Lower 16 bits	Set writing data used to write a parameter or point table data or to clear the alarm history. Setting writing data in RWwnC and RWwnD and turning on RYn9 write the data to the servo amplifier. When the writing is completed, RXn9 turns on. Refer to section 2.1.4 (2) (b) for writing data.	Refer to section 2.1.4 (2) (b).
RWwnD	Writing data - Upper 16 bits		

5. INDEXER OPERATION

(2) RWrn profile

Device No.	Device	Description	Setting range
RWrn0	Monitor 1 data - Lower 16 bits	The lower 16 bits of the data corresponding to the monitor code set in RWwn0 are stored.	
RWrn1	Monitor 1 data - Upper 16 bits	The upper 16 bits of the data corresponding to the monitor code set in RWwn0 are stored. A sign is set if no data is set in the upper 16 bits.	
RWrn2	Monitor 2 data - Lower 16 bits	The lower 16 bits of the data corresponding to the monitor code set in RWwn2 are stored.	
RWrn3	Monitor 2 data - Upper 16 bits	The upper 16 bits of the data corresponding to the monitor code set in RWwn2 are stored. A sign is set if no data is set in the upper 16 bits.	
RWrn4	Respond code	When the codes set in RWwn0 to RWwnD have been executed normally, "0000" is set.	
RWrn6	Station No. output	<p>The station No. is set when RXnC turns on.</p> <p>In the following conditions, "0" is set in RWrn6.</p> <ul style="list-style-type: none"> • The home position return is not completed. • The home position return is completed. <p>In the following conditions, RWrn6 holds the value used in the previous operation.</p> <ul style="list-style-type: none"> • The operation mode is changed. • During manual operation 	
RWrnC	Reading data - Lower 16 bits	Data corresponding to the reading code set in RWwn4 is set.	
RWrnD	Reading data - Upper 16 bits		

5. INDEXER OPERATION

5.1.4 Code

(1) Monitor code

Use any of the instruction codes 0100h to 011Fh to read the decimal point position (multiplying factor) of the status display.

Setting any code No. that is not given in this section will set an error code (_ _ _ 1) in respond code (RWrn4). At this time, "0000" is set in RWrn0 to RWrn3.

Code No.	Monitored item	Response data content (Servo amplifier → Master station)	
		Data length	Unit
0000h			
0001h			
0002h			
0003h			
0004h			
0005h			
0006h			
0007h			
0008h	Station No.	16 bits	
0009h			
000Ah	Cumulative feedback pulses	32 bits	[pulse]
000Bh			
000Ch			
000Dh			
000Eh			
000Fh	Droop pulses	32 bits	[pulse]
0010h			
0011h	Regenerative load ratio	16 bits	[%]
0012h	Effective load ratio	16 bits	[%]
0013h	Peak load ratio	16 bits	[%]
0014h	Instantaneous torque	16 bits	[%]
0015h	ABS counter	16 bits	[rev]
0016h	Servo motor speed	32 bits	0.01 [r/min]/0.01 [mm/s]
0017h			
0018h	Bus voltage	16 bits	[V]
0019h			
001Ah			
001Bh			
001Ch			
001Dh	Position within one-revolution	32 bits	[pulse]
001Eh			
001Fh			

(2) Instruction code

Refer to section 2.1.5 (2) for the timing charts of the instruction codes.



(a) Reading instruction code

The data requested to be read with the instruction codes 0000h to 0AFFh is stored in reading data (RWrnC and RWrnD).

Set the instruction code No. corresponding to the item in RWwn4 and RWwn5. The instruction code No. and response data are all hexadecimal.

Setting any instruction code No. that is not given in this section will store an error code (_ _ 1 _) in respond code (RWrn4). If any unusable parameter or point table is read, an error code (_ _ 2 _) is stored. At this time, "0000" is stored in reading data (RWrnC and RWrnD).

5. INDEXER OPERATION

Code No.		Item/function	Reading data content (Servo amplifier → Master station)	
RWwn5	RWwn4		RWrnC	RWrdD
0000h	0000h	Operation mode Reads the current operation mode.	0000: CC-Link IE operation mode 0001: Test operation mode	Always 0
0000h	0002h	Travel distance multiplying factor Reads the multiplying factor of the position data in the point table set with [Pr. PT03].	0000: × 1 0100: × 10 0200: × 100 0300: × 1000	Always 0
0000h	0010h	Current alarm (warning) reading Reads the alarm No. or warning No. that is currently occurring.	 <p>Detail of the alarm or warning currently occurring</p> <p>No. of the alarm or warning currently occurring</p>	Always 0
0000h	0020h	Alarm number in alarm history (latest alarm)	 <p>Detail of an alarm that occurred before</p> <p>No. of an alarm that occurred before</p>	Always 0
0000h	0021h	Alarm number in alarm history (one alarm ago)		
0000h	0022h	Alarm number in alarm history (two alarms ago)		
0000h	0023h	Alarm number in alarm history (three alarms ago)		
0000h	0024h	Alarm number in alarm history (four alarms ago)		
0000h	0025h	Alarm number in alarm history (five alarms ago)		
0000h	0026h	Alarm number in alarm history (six alarms ago)		
0000h	0027h	Alarm number in alarm history (seven alarms ago)		
0000h	0028h	Alarm number in alarm history (eight alarms ago)		
0000h	0029h	Alarm number in alarm history (nine alarms ago)		
0000h	002Ah	Alarm number in alarm history (ten alarms ago)		
0000h	002Bh	Alarm number in alarm history (eleven alarms ago)		
0000h	002Ch	Alarm number in alarm history (twelve alarms ago)		
0000h	002Dh	Alarm number in alarm history (thirteen alarms ago)		
0000h	002Eh	Alarm number in alarm history (fourteen alarms ago)		
0000h	002Fh	Alarm number in alarm history (fifteen alarms ago)		



5. INDEXER OPERATION

Code No.		Item/function	Reading data content (Servo amplifier → Master station)	
RWwn5	RWwn4		RWrnC	RWrnD
0000h	0030h	Alarm occurrence time in alarm history (latest alarm)	Returns the occurrence time of the alarm that occurred before.	Always 0
0000h	0031h	Alarm occurrence time in alarm history (one alarm ago)		
0000h	0032h	Alarm occurrence time in alarm history (two alarms ago)		
0000h	0033h	Alarm occurrence time in alarm history (three alarms ago)		
0000h	0034h	Alarm occurrence time in alarm history (four alarms ago)		
0000h	0035h	Alarm occurrence time in alarm history (five alarms ago)		
0000h	0036h	Alarm occurrence time in alarm history (six alarms ago)		
0000h	0037h	Alarm occurrence time in alarm history (seven alarms ago)		
0000h	0038h	Alarm occurrence time in alarm history (eight alarms ago)		
0000h	0039h	Alarm occurrence time in alarm history (nine alarms ago)		
0000h	003Ah	Alarm occurrence time in alarm history (ten alarms ago)		
0000h	003Bh	Alarm occurrence time in alarm history (eleven alarms ago)		
0000h	003Ch	Alarm occurrence time in alarm history (twelve alarms ago)		
0000h	003Dh	Alarm occurrence time in alarm history (thirteen alarms ago)		
0000h	003Eh	Alarm occurrence time in alarm history (fourteen alarms ago)		
0000h	003Fh	Alarm occurrence time in alarm history (fifteen alarms ago)		
0000h	0040h	Input device status 0 Reads the status (OFF/ON) of input devices.	Bit 0 to bit F indicate the OFF/ON status of the corresponding input devices. 0: Servo-on 1: Start 2: Rotation direction specifying 3: Proximity dog 4 to 5: For manufacturer setting 6: Operation mode selection 1 7: Operation mode selection 2 8: Monitor output execution demand 9: Instruction code execution demand A to F: For manufacturer setting	Always 0

5. INDEXER OPERATION

Code No.		Item/function	Reading data content (Servo amplifier → Master station)	
RWwn5	RWwn4		RWrnC	RWrnD
0000h	0041h	Input device status 1 Reads the status (OFF/ON) of input devices.	Bit 0 to bit F indicate the OFF/ON status of the corresponding input devices. 0: Upper stroke limit (Note) 1: Lower stroke limit (Note) 2: Operation alarm reset 3 to F: For manufacturer setting Note. The input from the servo amplifier (LSP/LSN) and the input from the controller (RY (n + 1) 0/RY (n + 1) 1) are switched depending on the setting of [Pr. PD41 Sensor input type selection]. When the input from the servo amplifier is set, the values of bit 0 and bit 1 are exchanged in the POL enabling condition.	Always 0
0000h	0042h	Input device status 2 Reads the status (OFF/ON) of input devices.	Bit 0 to bit F indicate the OFF/ON status of the corresponding input devices. 0: Position command execution demand 1: Speed command execution demand 2 to 6: For manufacturer setting 7: Proportional control 8: Gain switching 9: For manufacturer setting A: Position/speed specifying method selection B to F: For manufacturer setting	Always 0
0000h	0043h	Input device status 3 Reads the status (OFF/ON) of input devices.	Bit 0 to bit F indicate the OFF/ON status of the corresponding input devices. 0 to 9: For manufacturer setting A: Reset B to F: For manufacturer setting	Always 0
0000h	0081h	Energization time Reads the energization time since shipment.	Returns the energization time [h].	Always 0
0000h	0082h	Power on frequency Reads the number of power-on times since shipment.	Returns the number of power-on times.	Always 0
0000h	00A0h	Load to motor inertia ratio Reads the estimated load to motor inertia ratio on the servo motor shaft.	Return unit [0.01 times] The load to motor inertia ratio is returned.	Always 0
0000h	00B0h	Home position within one-revolution (CYC0) Reads the cycle counter value of an absolute home position.	Return unit [pulse] Stores the lower 16 bits of the cycle counter value of the absolute home position (32-bit data).	Stores the upper 16 bits of the cycle counter value of the absolute home position.
0000h	00B2h	Home position multi-revolution data (ABS0) Reads the multi-revolution counter value of an absolute home position.	Return unit [rev] Returns the multi-revolution counter value.	Always 0

5. INDEXER OPERATION

Code No.		Item/function	Reading data content (Servo amplifier → Master station)	
RWwn5	RWwn4		RWnrc	RWnrd
0000h	00C0h	<p>Error parameter No./Point data No. reading</p> <p>Reads the parameter No. and point table No. that have an error.</p>	 <p>Parameter No. or point table No.</p> <p>Parameter group</p> <ul style="list-style-type: none"> 0: [Pr. PA _ _] 1: [Pr. PB _ _] 2: [Pr. PC _ _] 3: [Pr. PD _ _] 4: [Pr. PE _ _] 5: [Pr. PF _ _] 6 to A: For manufacturer setting B: [Pr. PL _ _] C: [Pr. PT _ _] E: [Pr. PN _ _] <p>Type</p> <ul style="list-style-type: none"> 1: Parameter 2: Point table 	Always 0
0000h	0100h to 011Fh	<p>Monitor multiplying factor</p> <p>Reads the multiplying factor of data to be read with a monitor code.</p> <p>The instruction codes 0100h to 011Fh correspond to each of the monitor codes 0000h to 001Fh.</p> <p>To the instruction code that has no corresponding monitor code, "0000h" is applied.</p>	<p>0000: × 1</p> <p>0001: × 10</p> <p>0002: × 100</p> <p>0003: × 1000</p>	Always 0
0000h	0200h	<p>Parameter group reading</p> <p>Reads the parameter group written with the code No. 8200h.</p>	 <p>Parameter group</p> <ul style="list-style-type: none"> 0: [Pr. PA _ _] 1: [Pr. PB _ _] 2: [Pr. PC _ _] 3: [Pr. PD _ _] 4: [Pr. PE _ _] 5: [Pr. PF _ _] 6 to A: For manufacturer setting B: [Pr. PL _ _] C: [Pr. PT _ _] E: [Pr. PN _ _] 	Always 0
0000h	0201h to 02FFh	<p>Parameter data reading</p> <p>Reads the setting values of the parameters in the group read with the code No. 0200h.</p> <p>The lower two digits of the code No. which are converted to decimal correspond to the parameter No.</p>	Stores the lower 16 bits of the setting value of the requested parameter No.	Stores the upper 16 bits of the setting value of the requested parameter No.

5. INDEXER OPERATION

Code No.		Item/function	Reading data content (Servo amplifier → Master station)	
RWwn5	RWwn4		RWnrc	RWnrd
0000h	0301h to 03FFh	Data form of parameter Reads the data form of the setting values of the parameters in the group read with the code No. 0200h. The lower two digits of the code No. which are converted to decimal correspond to the parameter No.	Stores the data form of the requested parameter No. <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-right: 5px;">0</div> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="border: 1px solid black; width: 20px; height: 20px; margin-bottom: 2px;"></div> <div style="border: 1px solid black; width: 20px; height: 20px; margin-bottom: 2px;"></div> <div style="border: 1px solid black; width: 20px; height: 20px; margin-bottom: 2px;"></div> <div style="border: 1px solid black; width: 20px; height: 20px;"></div> </div> </div> <ul style="list-style-type: none"> Decimal point position 0: No decimal point 1: First least significant digit (no decimal point) 2: Second least significant digit 3: Third least significant digit 4: Forth least significant digit Data form 0: Data is used unchanged in hexadecimal. 1: Data must be converted into decimal. Parameter writing type 0: Enabled after writing 1: Enabled when power is cycled after writing 2: Enabled when the controller is reset 	Always 0
0000h	0601h to 06FFh	Servo motor speed of point table No. 1 to 255 The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Stores the lower 16 bits of the servo motor speed of the requested point table No.	Stores the upper 16 bits of the servo motor speed of the requested point table No.
0000h	0701h to 07FFh	Acceleration time constant of point table No. 1 to 255 The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Stores the acceleration time constant of the requested point table No.	Always 0
0000h	0801h to 08FFh	Deceleration time constant of point table No. 1 to 255 The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Stores the deceleration time constant of the requested point table No.	Always 0

5. INDEXER OPERATION

(b) Writing instruction code

Data requested to be written with the instruction codes 8000h to 91FFh is written to the servo amplifier.

Set the instruction code No. corresponding to the item in instruction code (RWwn4 and RWwn5) and the data to be written in writing data (RWwnC and RWwnD). The instruction code No. and response data are all hexadecimal.

Setting any instruction code No. that is not given in this section will store an error code (_ _ 1 _) in respond code (RWrn4).

Code No.		Item	Writing data content (Master station → Servo amplifier)	
RWwn5	RWwn4		RWwnC	RWwnD
0000h	8010h	Alarm reset command Clears the alarm that is currently occurring.	1EA5	Do not write data.
0000h	8101h	Feedback pulse value display data clear command Resets the display data of the status display "Cumulative feedback pulses" to "0".	1EA5	Do not write data.
0000h	8200h	Writing command of parameter group Writes the group of the parameter to write with code No. 8201h to 82FFh and 8301h to 83FFh. Writes the group of the parameter to read with code No. 0201h to 02FFh and 0301h to 03FFh.	<div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-right: 10px;">0</div> <div style="border: 1px solid black; padding: 2px; margin-right: 10px;">0</div> <div style="border: 1px solid black; padding: 2px; margin-right: 10px;">0</div> <div style="border: 1px solid black; padding: 2px; margin-right: 10px;"> </div> </div> <div style="margin-left: 20px;"> Parameter group 0: [Pr. PA _ _] 1: [Pr. PB _ _] 2: [Pr. PC _ _] 3: [Pr. PD _ _] 4: [Pr. PE _ _] 5: [Pr. PF _ _] 6 to A: For manufacturer setting B: [Pr. PL _ _] C: [Pr. PT _ _] E: [Pr. PN _ _] </div>	Do not write data.
0000h	8201h to 82FFh	Data RAM command of parameter Writes the setting values of the parameters in the group written with code No. 8200h to the RAM. This setting value is cleared when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the parameter No. An error code is returned if a value outside the range of a parameter is written.	Set the lower 16 bits of the parameter setting value.	Set the upper 16 bits of the parameter setting value. For 16-bit parameters, this setting is not required.
0000h	8301h to 83FFh	Data EEP-ROM command of parameter Writes the setting values of the parameters in the group written with code No. 8200h to the EEP-ROM. The setting value written in the EEP-ROM is held even when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the parameter No. An error code is returned if a value outside the range of a parameter is written.	Set the lower 16 bits of the parameter setting value.	Set the upper 16 bits of the parameter setting value. For 16-bit parameters, this setting is not required.


5. INDEXER OPERATION

Code No.		Item	Writing data content (Master station → Servo amplifier)	
RWwn5	RWwn4		RWwnC	RWwnD
0000h	8601h to 86FFh	Servo motor speed data RAM command of point table Writes the servo motor speed of point table No. 1 to 255 to the RAM. This setting value is cleared when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Set the lower 16 bits of the servo motor speed.	Set the upper 16 bits of the servo motor speed.
0000h	8701h to 87FFh	Acceleration time constant data RAM command of point table Writes the acceleration time constant of point table No. 1 to 255 to the RAM. This setting value is cleared when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Set the acceleration time constant.	Do not write data.
0000h	8801h to 88FFh	Deceleration time constant data RAM command of point table Writes the deceleration time constant of point table No. 1 to 255 to the RAM. This setting value is cleared when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Set the deceleration time constant.	Do not write data.
0000h	8D01h to 8DFFh	Servo motor speed data EEP-ROM command of point table Writes the servo motor speed of point table No. 1 to 255 to the EEP- ROM. The setting value written in the EEP-ROM is held even when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Set the lower 16 bits of the servo motor speed.	Set the upper 16 bits of the servo motor speed.
0000h	8E01h to 8EFFh	Acceleration time constant data EEP-ROM command of point table Writes the acceleration time constant of point table No. 1 to 255 to the EEP-ROM. The setting value written in the EEP-ROM is held even when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Set the acceleration time constant.	Do not write data.
0000h	8F01h to 8FFFh	Deceleration time constant data EEP-ROM command of point table Writes the deceleration time constants of point table No. 1 to 255 to the EEP-ROM. The setting value written in the EEP-ROM is held even when the power supply is shut off. The lower two digits of the code No. which are converted to decimal correspond to the point table No.	Set the deceleration time constant.	Do not write data.

5. INDEXER OPERATION

(3) Respond code (RWrn4)

If any of monitor codes, instruction codes, point table No. selection, point table No./position command data, and point table No./speed command data set in remote registers is outside the setting range, the corresponding error code is set in respond code (RWrn4). If the setting is within the setting range, "0000" is set.



5.1.5 Data communication timing chart

Data communication timing charts for the indexer operation are the same as those for the point table operation. Refer to section 2.1.5.


5. INDEXER OPERATION

5.2 Switching power on for the first time


POINT	●To use the servo amplifier in the I/O mode, set [Pr. PN03] to "___ 1". In addition, the GX Works setting is required. For the GX Works setting, refer to section 4.1.4 (2) of "MR-J4-_GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)".
-------	--

When switching power on for the first time, follow this section to make a startup.

Startup procedure



5. INDEXER OPERATION



5. INDEXER OPERATION


5.3 Automatic operation mode

POINT
<ul style="list-style-type: none"> ● There are the following restrictions on [Pr. PA06 Number of gear teeth on machine side] and the servo motor speed (N) in the absolute position detection system. <ul style="list-style-type: none"> ▪ When [Pr. PA06] ≤ 2000, $N < 3076.7$ r/min ▪ When [Pr. PA06] > 2000, $N < 3276.7 - \text{CMX r/min}$ When the servo motor is operated continuously at a servo motor speed higher than the limit value, [AL. E3 Absolute position counter warning] will occur. ● When the same next station No. is specified as station No. of the current position and a positioning operation is executed, the motor does not start because the travel distance is judged as "0".

5.3.1 Automatic operation mode

(1) Logic of indexer


A circumference of the load side (360 degrees) is divided into up to 255 stations. The positioning is executed by selecting a station with RWwn6 (Next station No. selection) or RWwn8 (Next station No.). The following diagram is an example for when [Pr. PA14] is set to "0".




The station No. 0 is set as a home position. The number of divisions is set with [Pr. PT28].

(2) Rotation direction

There are two operation methods: Rotation direction specifying indexer, which always rotates in a fixed direction and executes positioning to a station; Shortest rotating indexer, which automatically changes a rotation direction to the shortest distance and executes positioning to a station



Rotation direction specifying indexer



Shortest rotating indexer

5. INDEXER OPERATION

5.3.2 Rotation direction specifying indexer

In this operation mode, the servo motor rotates in a fixed direction to execute positioning to a station.

(1) When not using the position/speed specifying method

The positioning is executed by selecting a station No. with RWwn6 (Next station No. selection). Use the value set in the point table as the servo motor speed, acceleration or deceleration time constant during operation.

(a) Device/parameter

Set input devices and parameters as follows:

Item	Device/parameter to be used	Setting
Indexer method selection	Control mode selection of [Pr. PA01]	Select " _ _ 8" (positioning mode (indexer method)).
Position/speed specifying method	RY (n + 2) A (Position/speed specifying method selection)	Turn off RY (n + 2) A.
Next station position	RWwn6 (Next station No. selection)	Set any next station No.
Selection of rotation direction specifying indexer	RYn6 (Operation mode selection 1)	Turn off RYn6.
	RYn7 (Operation mode selection 2)	Turn on RYn7.
Rotation direction selection	RYn2 (Rotation direction specifying)	The rotation direction to a station No. will be as follows. Off: Station No. decreasing direction On: Station No. increasing direction
Servo motor speed	Point table	Set a servo motor speed.
Acceleration time constant/deceleration time constant	Point table	Set an acceleration time constant and deceleration time constant.
Speed command data selection	RWwn7 (Speed selection)	Set a point table No. that stores speed command data.
Torque limit (Note)	[Pr. PA11] [Pr. PA12]	Set a torque limit value for during operation.
	[Pr. PC77]	Set a torque limit value for during stop.
	[Pr. PT39]	Set time to switch the torque limit value from during operation until during stop.


Note. The torque limit will change from [Pr. PC77 Internal torque limit 2] to the setting value of [Pr. PA11 Forward rotation torque limit] or [Pr. PA12 Reverse rotation torque limit] when RYn1 (Start) is inputted. After RXnC (Travel completion) is turned on, the time set with [Pr. PT39] has passed, the torque limit will change from [Pr. PA11 Forward rotation torque limit] or [Pr. PA12 Reverse rotation torque limit] to the setting value of [Pr. PC77 Internal torque limit 2].

5. INDEXER OPERATION


(b) Other parameter settings

1) Setting an assignment direction of station No.


Select an assignment direction of station No. with [Pr. PA14].



[Pr. PA14] setting	Servo motor rotation direction RYn1 (Start) is on
0 (initial value)	Next station No. will be assigned in CW direction in order of 1, 2, 3...
1	Next station No. will be assigned in CCW direction in order of 1, 2, 3...



[Pr. PA14]: 0 (initial value)



[Pr. PA14]: 1

2) Setting the number of stations

Set the number of stations with [Pr. PT28].


	[Pr. PT28] setting				
Number of stations	2	3	4	...	255
Station No.				...	

(c) Operation

When a station No. is selected with RWwn6, a point table in which speed command data is stored is selected with RWwn7, and RYn1 is switched on, positioning to the selected station will start at the set speed and acceleration/deceleration time constant.




5. INDEXER OPERATION

(d) Timing chart



5. INDEXER OPERATION

- Note
1. Configure a sequence in which RWwn6 and RWwn7 is changed earlier taking into consideration the communication delay time.
 2. RYn1 is disabled even if it is turned on during operation. To perform the next operation, make sure that RXnC turns on, and then turn on RYn1.
 3. When RYn1 turns on, the servo motor speed and acceleration/deceleration time constants are switched with RWwn7. They are not switched with RWwn7 (Speed selection) while the servo motor is rotating..
 4. Operation is performed as follows.

Operation	*1	*2	*3
Next station No.	No. 1	No. 3	No. 1
Servo motor speed Acceleration time constant Deceleration time constant	Point table No. 1	Point table No. 1	Point table No. 2
Positioning			

5. [Pr. PT39] can be used to set the delay time from when RXn1 turns on until when the torque limit value changes to the value of [Pr. PC77].
6. After power-on, RXn1 turns on if the number of droop pulses is within the in-position range of each station position.
7. Configure a sequence as follows: After an operation mode is selected, RYn1 (Start) turns on upon the lapse of the switching hold time ("8 ms + communication delay time").

5. INDEXER OPERATION

- (2) When using the position/speed specifying method (with speed data of point tables)

The positioning is executed by selecting a station No. with RWwn8 (Next station No.). Use the value set in the point table as the servo motor speed, acceleration or deceleration time constant during operation.

- (a) Device/parameter

Set input devices and parameters as follows:

Item	Device/parameter to be used	Setting
Indexer method selection	Control mode selection of [Pr. PA01]	Select " _ _ _ 8" (positioning mode (indexer method)).
Position/speed specifying method	RY (n + 2) A (Position/speed specifying method selection)	Turn on RY (n + 2) A.
	[Pr. PT62]	Set [Pr. PT62] to " _ _ 0 _".
Next station position	RWwn8 (Next station No.)	Set any next station No.
Selection of rotation direction specifying indexer	RYn6 (Operation mode selection 1)	Turn off RYn6.
	RYn7 (Operation mode selection 2)	Turn on RYn7.
Rotation direction selection	RYn2 (Rotation direction specifying)	The rotation direction to a station No. will be as follows. Off: Station No. decreasing direction On: Station No. increasing direction
Servo motor speed	Point table	Set a servo motor speed.
Acceleration time constant/deceleration time constant	Point table	Set an acceleration time constant and deceleration time constant.
Speed command data selection	RWwnA (Point table No./speed command data - Lower 16 bits)	Set a point table No. that stores speed command data.
Torque limit (Note)	[Pr. PA11] [Pr. PA12]	Set a torque limit value for during operation.
	[Pr. PC77]	Set a torque limit value for during stop.
	[Pr. PT39]	Set time to switch the torque limit value from during operation until during stop.

Note. The torque limit will change from [Pr. PC77 Internal torque limit 2] to the setting value of [Pr. PA11 Forward rotation torque limit] or [Pr. PA12 Reverse rotation torque limit] when RYn1 (Start) is inputted. After RXnC (Travel completion) is turned on, the time set with [Pr. PT39] has passed, the torque limit will change from [Pr. PA11 Forward rotation torque limit] or [Pr. PA12 Reverse rotation torque limit] to the setting value of [Pr. PC77 Internal torque limit 2].

- (b) Other parameter settings


Refer to (1) (b) in this section.

- (c) Operation

Selecting a station No. with RWwn8 and a point table in which speed command data is stored with RWwnA and switching on RYn1 start positioning to the selected station at the set speed, acceleration time constant and deceleration time constant.




5. INDEXER OPERATION

(d) Timing chart



5. INDEXER OPERATION

- Note
1. Configure a sequence in which RWwn8 and RWwnA is changed earlier taking into consideration the communication delay time.
 2. RYn1 is disabled even if it is turned on during operation. To perform the next operation, make sure that RXnC turns on, and then turn on RYn1.
 3. For details of the operation timing for RY (n + 2) 0 and RY (n + 2) 1, refer to section 2.1.6 (2).
 4. Operation is performed as follows.

Operation	*1	*2	*3
Next station No.	No. 1	No. 3	No. 1
Servo motor speed			
Acceleration time constant	Point table No. 1	Point table No. 1	Point table No. 2
Deceleration time constant			
Positioning			

5. [Pr. PT39] can be used to set the delay time from when RXn1 turns on until when the torque limit value changes to the value of [Pr. PC77].
6. After power-on, RXn1 turns on if the number of droop pulses is within the in-position range of each station position.
7. Configure a sequence as follows: After an operation mode is selected, RYn1 (Start) turns on upon the lapse of the switching hold time ("8 ms + communication delay time").

5. INDEXER OPERATION

- (3) When using the position/speed specifying method (by setting a servo motor speed directly)
The positioning is executed by selecting a station No. with RWwn8 (Next station No.). Use the value set in the link device as the servo motor speed during operation. Use the value set in point table No. 1 as the acceleration or deceleration time constant during operation.

(a) Device/parameter

Set input devices and parameters as follows:

Item	Device/parameter to be used	Setting
Indexer method selection	Control mode selection of [Pr. PA01]	Select " _ _ _ 8" (positioning mode (indexer method)).
Position/speed specifying method	RY (n + 2) A (Position/speed specifying method selection)	Turn on RY (n + 2) A.
	[Pr. PT62]	Set [Pr. PT62] to " _ _ 1 _".
Next station position	RWwn8 (Next station No.)	Set any next station No.
Selection of rotation direction specifying indexer	RYn6 (Operation mode selection 1)	Turn off RYn6.
	RYn7 (Operation mode selection 2)	Turn on RYn7.
Rotation direction selection	RYn2 (Rotation direction specifying)	The rotation direction to a station No. will be as follows. Off: Station No. decreasing direction On: Station No. increasing direction
Servo motor speed	RWwnA (Speed command data - Lower 16 bits) RWwnB (Speed command data - Upper 16 bits)	Set a servo motor speed.
Acceleration time constant/deceleration time constant	Point table No. 1	Set an acceleration time constant and deceleration time constant.
Torque limit (Note)	[Pr. PA11] [Pr. PA12]	Set a torque limit value for during operation.
	[Pr. PC77]	Set a torque limit value for during stop.
	[Pr. PT39]	Set time to switch the torque limit value from during operation until during stop.

Note. The torque limit will change from [Pr. PC77 Internal torque limit 2] to the setting value of [Pr. PA11 Forward rotation torque limit] or [Pr. PA12 Reverse rotation torque limit] when RYn1 (Start) is inputted. After RXnC (Travel completion) is turned on, the time set with [Pr. PT39] has passed, the torque limit will change from [Pr. PA11 Forward rotation torque limit] or [Pr. PA12 Reverse rotation torque limit] to the setting value of [Pr. PC77 Internal torque limit 2].

(b) Other parameter settings


Refer to (1) (b) in this section.

(c) Operation

Selecting a station No. with RWwn8 and a servo motor speed with RWwnA and RWwnB and switching on RYn1 start positioning to the selected station at the set speed, acceleration time constant and deceleration time constant of point table No. 1.




5. INDEXER OPERATION

(d) Timing chart



5. INDEXER OPERATION

- Note
1. Configure a sequence in which RWwn8, RWwnA, and RWwnB is changed earlier taking into consideration the communication delay time.
 2. RYn1 is disabled even if it is turned on during operation. To perform the next operation, make sure that RXnC turns on, and then turn on RYn1.
 3. For details of the operation timing for RY (n + 2) 0 and RY (n + 2) 1, refer to section 2.1.6 (2).
 4. Operation is performed as follows.

Operation	*1	*2	*3
Next station No.	No. 1	No. 3	No. 1
Servo motor speed Acceleration time constant Deceleration time constant	Point table No. 1	Point table No. 1	Point table No. 3
Positioning			

5. [Pr. PT39] can be used to set the delay time from when RXn1 turns on until when the torque limit value changes to the value of [Pr. PC77].
6. After power-on, RXn1 turns on if the number of droop pulses is within the in-position range of each station position.
7. Configure a sequence as follows: After an operation mode is selected, RYn1 (Start) turns on upon the lapse of the switching hold time ("8 ms + communication delay time").

5. INDEXER OPERATION

5.3.3 Shortest rotating indexer operation

This operation mode automatically changes a rotation direction to the shortest distance to execute positioning to a station.

(1) When not using the position/speed specifying method

The positioning is executed by selecting a station No. with RWwn6 (Next station No. selection). Use the value set in the point table as the servo motor speed, acceleration or deceleration time constant during operation.

(a) Device/parameter

Set input devices and parameters as follows:

Item	Device/parameter to be used	Setting
Indexer method selection	Control mode selection of [Pr. PA01]	Select " _ _ _ 8" (positioning mode (indexer method)).
Position/speed specifying method	RY (n + 2) A (Position/speed specifying method selection)	Turn off RY (n + 2) A.
Next station position	RWwn6 (Next station No. selection)	Set any next station No.
Selection of shortest rotating indexer operation	RYn6 (Operation mode selection 1)	Turn on RYn6.
	RYn7 (Operation mode selection 2)	Turn on RYn7.
Servo motor speed	Point table	Set a servo motor speed.
Acceleration time constant/deceleration time constant	Point table	Set an acceleration time constant and deceleration time constant.
Speed command data selection	RWwn7 (Speed selection)	Set a point table No. that stores speed command data.
Torque limit (Note)	[Pr. PA11] [Pr. PA12]	Set a torque limit value for during operation.
	[Pr. PC77]	Set a torque limit value for during stop.
	[Pr. PT39]	Set time to switch the torque limit value from during operation until during stop.

Note. The torque limit will change from [Pr. PC77 Internal torque limit 2] to the setting value of [Pr. PA11 Forward rotation torque limit] or [Pr. PA12 Reverse rotation torque limit] when RYn1 (Start) is inputted. After RXnC (Travel completion) is turned on, the time set with [Pr. PT39] has passed and the torque limit will change from [Pr. PA11 Forward rotation torque limit] or [Pr. PA12 Reverse rotation torque limit] to the setting value of [Pr. PC77 Internal torque limit 2].

(b) Other parameter settings (the number of stations)

Set the number of stations with [Pr. PT28]. The setting is the same as that of the rotation direction specifying indexer. Refer to section 5.3.2 (1) (b) 2).

[Pr. PA14 Rotation direction selection] is not used with the shortest rotating indexer operation.

(c) Operation


When a station No. is selected with RWwn6, a point table in which speed command data is stored is selected with RWwn7, and RYn1 is switched on, positioning to the selected station will start at the set speed and acceleration/deceleration time constant.

5. INDEXER OPERATION

(d) Timing chart




POINT
<ul style="list-style-type: none"> ● Always perform a home position return. Executing positioning operation without home position return will trigger [AL. 90 Home position return incomplete warning] and RYn1 (Start) will be disabled. ● When travel distances are the same to a target station position from CCW and from CW, the shaft will rotate to the station No. increasing direction.

The following shows a timing chart.



5. INDEXER OPERATION

- Note
1. Configure a sequence in which RWwn6 and RWwn7 is changed earlier taking into consideration the communication delay time.
 2. RYn1 is disabled even if it is turned on during operation. To perform the next operation, make sure that RXnC turns on, and then turn on RYn1.
 3. When RYn1 turns on, the servo motor speed and acceleration/deceleration time constants are switched with RWwn7. They are not switched with RWwn7 (Speed selection) while the servo motor is rotating.
 4. Operation is performed as follows.

Operation	*1	*2	*3
Next station No.	No. 1	No. 3	No. 1
Servo motor speed Acceleration time constant Deceleration time constant	Point table No. 1	Point table No. 1	Point table No. 2
Positioning			

5. [Pr. PT39] can be used to set the delay time from when RXn1 turns on until when the torque limit value changes to the value of [Pr. PC77].
6. After power-on, RXn1 turns on if the number of droop pulses is within the in-position range of each station position.
7. Configure a sequence as follows: After an operation mode is selected, RYn1 (Start) turns on upon the lapse of the switching hold time ("8 ms + communication delay time").

5. INDEXER OPERATION

- (2) When using the position/speed specifying method (with speed data of point tables)

The positioning is executed by selecting a station No. with RWwn8 (Next station No.). Use the value set in the point table as the servo motor speed, acceleration or deceleration time constant during operation.

- (a) Device/parameter

Set input devices and parameters as follows:

Item	Device/parameter to be used	Setting
Indexer method selection	Control mode selection of [Pr. PA01]	Select " _ _ _ 8" (positioning mode (indexer method)).
Position/speed specifying method	RY (n + 2) A (Position/speed specifying method selection)	Turn on RY (n + 2) A.
	[Pr. PT62]	Set [Pr. PT62] to " _ _ 0 _".
Next station position	RWwn8 (Next station No.)	Set any next station No.
Selection of shortest rotating indexer operation	RYn6 (Operation mode selection 1)	Turn on RYn6.
	RYn7 (Operation mode selection 2)	Turn on RYn7.
Servo motor speed	Point table	Set a servo motor speed.
Acceleration time constant/deceleration time constant	Point table	Set an acceleration time constant and deceleration time constant.
Speed command data selection	RWwnA (Point table No./speed command data - Lower 16 bits)	Set a point table No. that stores speed command data.
Torque limit (Note)	[Pr. PA11] [Pr. PA12]	Set a torque limit value for during operation.
	[Pr. PC77]	Set a torque limit value for during stop.
	[Pr. PT39]	Set time to switch the torque limit value from during operation until during stop.

Note. The torque limit will change from [Pr. PC77 Internal torque limit 2] to the setting value of [Pr. PA11 Forward rotation torque limit] or [Pr. PA12 Reverse rotation torque limit] when RYn1 (Start) is inputted. After RXnC (Travel completion) is turned on, the time set with [Pr. PT39] has passed, the torque limit will change from [Pr. PA11 Forward rotation torque limit] or [Pr. PA12 Reverse rotation torque limit] to the setting value of [Pr. PC77 Internal torque limit 2].

- (b) Other parameter settings


Refer to (1) (b) in this section.

- (c) Operation

Selecting a station No. with RWwn8 and a point table in which speed command data is stored with RWwnA and switching on RYn1 start positioning to the selected station at the set speed, acceleration time constant and deceleration time constant.




5. INDEXER OPERATION

(d) Timing chart



5. INDEXER OPERATION

- Note
1. Configure a sequence in which RWwn8 and RWwnA is changed earlier taking into consideration the communication delay time.
 2. RYn1 is disabled even if it is turned on during operation. To perform the next operation, make sure that RXnC turns on, and then turn on RYn1.
 3. For details of the operation timing for RY (n + 2) 0 and RY (n + 2) 1, refer to section 2.1.6 (2).
 4. Operation is performed as follows.

Operation	*1	*2	*3
Next station No.	No. 1	No. 3	No. 1
Servo motor speed Acceleration time constant Deceleration time constant	Point table No. 1	Point table No. 1	Point table No. 2
Positioning			

5. [Pr. PT39] can be used to set the delay time from when RXn1 turns on until when the torque limit value changes to the value of [Pr. PC77].
6. After power-on, RXn1 turns on if the number of droop pulses is within the in-position range of each station position.
7. Configure a sequence as follows: After an operation mode is selected, RYn1 (Start) turns on upon the lapse of the switching hold time ("8 ms + communication delay time").

5. INDEXER OPERATION

- (3) When using the position/speed specifying method (by setting a servo motor speed directly)

The positioning is executed by selecting a station No. with RWwn8 (Next station No.). Use the value set in the link device as the servo motor speed during operation. Use the value set in point table No. 1 as the acceleration or deceleration time constant during operation.

- (a) Device/parameter

Set input devices and parameters as follows:

Item	Device/parameter to be used	Setting
Indexer method selection	Control mode selection of [Pr. PA01]	Select " _ _ _ 8" (positioning mode (indexer method)).
Position/speed specifying method	RY (n + 2) A (Position/speed specifying method selection)	Turn on RY (n + 2) A.
	[Pr. PT62]	Set [Pr. PT62] to " _ _ 1 _".
Next station position	RWwn8 (Next station No.)	Set any next station No.
Selection of shortest rotating indexer operation	RYn6 (Operation mode selection 1)	Turn on RYn6.
	RYn7 (Operation mode selection 2)	Turn on RYn7.
Servo motor speed	RWwnA (Speed command data - Lower 16 bits) RWwnB (Speed command data - Upper 16 bits)	Set a servo motor speed.
Acceleration time constant/deceleration time constant	Point table No. 1	Set an acceleration time constant and deceleration time constant.
Torque limit (Note)	[Pr. PA11] [Pr. PA12]	Set a torque limit value for during operation.
	[Pr. PC77]	Set a torque limit value for during stop.
	[Pr. PT39]	Set time to switch the torque limit value from during operation until during stop.

Note. The torque limit will change from [Pr. PC77 Internal torque limit 2] to the setting value of [Pr. PA11 Forward rotation torque limit] or [Pr. PA12 Reverse rotation torque limit] when RYn1 (Start) is inputted. After RXnC (Travel completion) is turned on, the time set with [Pr. PT39] has passed, the torque limit will change from [Pr. PA11 Forward rotation torque limit] or [Pr. PA12 Reverse rotation torque limit] to the setting value of [Pr. PC77 Internal torque limit 2].

- (b) Other parameter settings

Refer to (1) (b) in this section.

- (c) Operation




Selecting a station No. with RWwn8 and a servo motor speed with RWwnA and RWwnB and switching on RYn1 start positioning to the selected station at the set speed, acceleration time constant and deceleration time constant of point table No. 1.

(d) Timing chart

[illegible]

5. INDEXER OPERATION

- Note
1. Configure a sequence in which RWwn8, RWwnA, and RWwnB is changed earlier taking into consideration the communication delay time.
 2. RYn1 is disabled even if it is turned on during operation. To perform the next operation, make sure that RXnC turns on, and then turn on RYn1.
 3. For details of the operation timing for RY (n + 2) 0 and RY (n + 2) 1, refer to section 2.1.6 (2).
 4. Operation is performed as follows.

Operation	*1	*2	*3
Next station No.	No. 1	No. 3	No. 1
Servo motor speed Acceleration time constant Deceleration time constant	Point table No. 1	Point table No. 1	Point table No. 3
Positioning			

5. [Pr. PT39] can be used to set the delay time from when RXn1 turns on until when the torque limit value changes to the value of [Pr. PC77].
6. After power-on, RXn1 turns on if the number of droop pulses is within the in-position range of each station position.
7. Configure a sequence as follows: After an operation mode is selected, RYn1 (Start) turns on upon the lapse of the switching hold time ("8 ms + communication delay time").

5. INDEXER OPERATION

5.4 Manual operation mode

POINT
<p>● When the operation mode is changed during operation, inputting RYn1 (Start) is disabled until the operation stops. Switch on RYn1 (Start) after the operation stops.</p>

For the machine adjustment, home position adjustment, and others, you can shift the position to any position with the station JOG operation or JOG operation.

5.4.1 Station JOG operation


(1) Setting

Set devices and parameters as shown below to suit the purpose. With this operation, RWwn6 (Next station No. selection) and RWwn8 (Next station No.) are disabled.


Item	Device/parameter to be used	Setting
Indexer method selection	Control mode selection of [Pr. PA01]	Select " _ _ 8" (positioning mode (indexer method)).
Manual operation mode selection	RYn6 (Operation mode selection 1)	Turn on RYn6.
	RYn7 (Operation mode selection 2)	Turn off RYn7.
Station JOG operation selection	[Pr. PT27]	Select " _ _ 0 _" (Station JOG operation).
Rotation direction selection	RYn2 (Rotation direction specifying)	The rotation direction to a station No. will be as follows. Off: Station No. decreasing direction On: Station No. increasing direction
Selection of station No. assignment direction	[Pr. PA14]	Refer to (2) in this section.
Servo motor speed	[Pr. PT65]	Set a servo motor speed.
Acceleration time constant/deceleration time constant	Acceleration time constant: [Pr. PT49] Deceleration time constant: [Pr. PT50]	Set an acceleration time constant and deceleration time constant.

(2) Setting an assignment direction of station No.


Select an assignment direction of station No. with [Pr. PA14].



[Pr. PA14] setting	Servo motor rotation direction RYn1 (Start) is on
0 (initial value)	Next station No. will be assigned in CW direction in order of 1, 2, 3...
1	Next station No. will be assigned in CCW direction in order of 1, 2, 3...



[Pr. PA14]: 0 (initial value)



[Pr. PA14]: 1


5. INDEXER OPERATION

(3) Operation

Turning on RYn1 (Start) will start rotating the servo motor in the direction specified with the rotation direction decision, and turning off RYn1 will execute a positioning to the closest station position at which the servo motor can decelerate to a stop. However, the shaft stops based on a set time constant depending on the setting value of deceleration time constant. The speed may not reach the specified servo motor speed.

(4) Timing chart

The following shows a timing chart.



Note 1. The torque limit delay time can be set with [Pr. PT39].

Note 2. RYn1 is disabled even if it is turned on during operation. To perform the next operation, make sure that RXnC (Travel completion) turns on, and then turn on RYn1.

Note 3. Configure a sequence as follows: After an operation mode is selected, RYn1 (Start) turns on upon the lapse of the switching hold time ("8 ms + communication delay time").

5. INDEXER OPERATION

5.4.2 JOG operation

(1) Setting

Set devices and parameters as shown below to suit the purpose. With this operation, RWwn6 (Next station No. selection) and RWwn8 (Next station No.) are disabled.

Item	Device/parameter to be used	Setting
Indexer method selection	Control mode selection of [Pr. PA01]	Select " _ _ 8" (positioning mode (indexer method)).
Manual operation mode selection	RYn6 (Operation mode selection 1)	Turn on RYn6.
	RYn7 (Operation mode selection 2)	Turn off RYn7.
JOG operation selection	[Pr. PT27]	Select " _ _ 1 _" (JOG operation).
Rotation direction selection	RYn2 (Rotation direction specifying)	The rotation direction to a station No. will be as follows. Off: Station No. decreasing direction On: Station No. increasing direction
Selection of station No. assignment direction	[Pr. PA14]	Refer to section 5.4.1 (2).
Servo motor speed	[Pr. PT65]	Set a servo motor speed.
Acceleration time constant/deceleration time constant	Acceleration time constant: [Pr. PT49] Deceleration time constant: [Pr. PT50]	Set an acceleration time constant and deceleration time constant.


(2) Operation

Turning on RYn1 (Start) will start rotating the servo motor in the direction specified with the rotation direction decision and turning off RYn1 will decelerate the servo motor to a stop regardless of the station position.

5. INDEXER OPERATION

(3) Timing chart

The following shows a timing chart.



- Note 1. The torque limit delay time can be set with [Pr. PT39].
- Note 2. Configure a sequence as follows: After an operation mode is selected, RYn1 (Start) turns on upon the lapse of the switching hold time ("8 ms + communication delay time").

5. INDEXER OPERATION

5.5 Home position return mode

POINT	
●	Before performing the home position return, check that the limit switch operates and RYn2 turns on.
●	Check the home position return direction. An incorrect setting will cause a reverse running.
●	Check the input polarity of the external limit. Otherwise, it may cause an unexpected operation.
●	In the following case, make sure that the Z-phase has been passed through once before performing a home position return. <ul style="list-style-type: none">▪ For the use in the DD motor control mode Z-phase unpassed will trigger [AL. 90.5 Home position return incomplete warning].

5.5.1 Outline of home position return

A home position return is performed to match the command coordinates with the machine coordinates. Under the incremental method, each power-on of the input power supply requires the home position return. Contrastingly, in the absolute position detection system, once you have performed the home position return at machine installation, the current position will be retained even if the power supply is shut off. Therefore, the home position return is unnecessary when the power supply is switched on again.

This section shows the home position return types of the servo amplifier. Select the optimum method according to the configuration and uses of the machine.

Type	Home position return type	Feature
Torque limit changing dog type	Deceleration starts from the front end of the proximity dog. A position of the first Z-phase signal with which the servo motor can decelerate to a stop or a position moved by the home position shift amount from the Z-phase is set as the home position.	<ul style="list-style-type: none">• This is a typical home position return method using an external limit.• The repeatability of the home position return is high.• The machine is less loaded.• Used when the width of the external limit can be set equal to or greater than the deceleration distance of the servo motor.
Torque limit changing data set type	The current position is set as the home position.	<ul style="list-style-type: none">• An external limit is not required.
Homing method 35, 37 (Homing on current position)	The current position is set as the home position.	<ul style="list-style-type: none">• The home position return can be performed in the servo-off status.

5. INDEXER OPERATION

5.5.2 Torque limit changing dog type home position return

This is a home position return type using a proximity dog. Deceleration starts from the front end of the proximity dog. A position of the first Z-phase signal with which the servo motor can decelerate to a stop or a position moved by the home position shift amount from the Z-phase is set as the home position.

(1) Device/parameter


Set input devices and parameters as follows:

Item	Device/parameter to be used	Setting
Home position return mode selection	RYn6 (Operation mode selection 1)	Turn off RYn6.
	RYn7 (Operation mode selection 2)	Turn off RYn7.
Torque limit changing dog type home position return	[Pr. PT45]	Select "-1" or "-33" (dog type (rear end detection, Z-phase reference)). -1: Address increasing direction -33: Address decreasing direction
Dog input polarity	[Pr. PT29]	Select a proximity dog input polarity.
Home position return speed	[Pr. PT05]	Set the rotation speed specified until an external limit is detected.
Creep speed	[Pr. PT06]	Set the rotation speed specified after an external limit is detected.
Home position shift distance	[Pr. PT07], [Pr. PT69]	Set this item to shift the home position, which is specified by the first Z-phase signal after the external limit is detected.
Acceleration time constant/deceleration time constant	Acceleration time constant: [Pr. PT56] Deceleration time constant: [Pr. PT56] or [Pr. PT57]	Set an acceleration time constant and deceleration time constant. For the deceleration time constant, when [Pr. PT55] is set to "___0", the value of [Pr. PT56] is used, and when [Pr. PT55] is set to "___1", the value of [Pr. PT57] is used.
Torque limit value for the execution of home position return	[Pr. PA11]	Set a torque limit value for home position return in the forward rotation direction.
	[Pr. PA12]	Set a torque limit value for home position return in the reverse rotation direction.
Torque limit value during stop	[Pr. PC77]	Set a torque limit value for during stop.

- Note
1. The setting of the station home position shift distance is disabled at home position return. Cycling the power will enable the setting.
 2. [Pr. PT40 Station home position shift distance] is enabled as an offset to the position that the home position return is performed. If a larger value than the in-position range is set to [Pr. PT40], the completion output of positioning will not turn on (short circuit) at the first power on after home position return.

5. INDEXER OPERATION

(2) Timing chart



- Note 1. When the rest of command travel distance is other than "0", RYn1 (Start) is not enabled even if it is turned on.
- Note 2. Counting will start when the rest of command travel distance becomes "0".
- Note 3. Configure a sequence as follows: After an operation mode is selected, RYn1 (Start) turns on upon the lapse of the switching hold time ("8 ms + communication delay time").

5. INDEXER OPERATION

5.5.3 Torque limit changing data set type

POINT	
●	When the data set type home position return is selected, [AL. 42] and [AL. 52] will not be detected.
●	If the servo motor is rotated in the home position return mode and the mode is changed to automatic mode without home position return, the following may occur. <ol style="list-style-type: none">1. [AL. 42] or [AL. 52] can occur.2. Even though [AL. 42] or [AL. 52] does not occur, the motor will try to compensate a position gap to the command position at start signal input because the current position is out of position with the command position. Watch out for the servo motor rotation due to the compensation for the gap to zero between command position and current position.
●	When [AL. 90] is occurring, performing home position return will automatically cancel the alarm.
●	When [AL. 25] is occurring, cycling the power will cancel the alarm.

When setting any position as home, use the torque limit changing data set type home position return. The JOG operation, the manual pulse generator operation, and others can be used for the travel. With this home position return, torque will not be generated simultaneously at switching to the home position return mode. Any home position can be set by rotating the shaft with an external force. Additionally, the proximity dog is not used. The proximity dog is disabled even if it is turned off.


(1) Device/parameter

Set input devices and parameters as follows:

Item	Device/parameter to be used	Setting
Home position return mode selection	RYn6 (Operation mode selection 1)	Turn off RYn6.
	RYn7 (Operation mode selection 2)	Turn off RYn7.
Torque limit changing data set type home position return	[Pr. PT45]	Select "-3" (data set type).
Torque limit value during stop	[Pr. PC77]	Set a torque limit value for during stop.

5. INDEXER OPERATION

(2) Timing chart



Note 1. Configure a sequence that changes the operation mode earlier by the communication delay time.

2. Configure a sequence as follows: After an operation mode is selected, RYn1 (Start) turns on upon the lapse of the switching hold time ("8 ms + communication delay time").

5. INDEXER OPERATION

5.5.4 Homing method 35, 37 (Homing on current position)


In the servo-off status, any home position can be set by rotating the servo motor shaft with an external force. When using the servo motor with an electromagnetic brake, use the torque limit changing data set type because the brake operates in the servo-off status.

(1) Device/parameter

Set input devices and parameters as follows:

Item	Device/parameter to be used	Setting
Home position return mode selection	RYn6 (Operation mode selection 1)	Turn off RYn6.
	RYn7 (Operation mode selection 2)	Turn off RYn7.
Homing method 35, 37	[Pr. PT45]	Select "-5" or "37" (Homing on current position).

(2) Timing chart



Note 1. Configure a sequence that changes the operation mode earlier by the communication delay time.

Note 2. Configure a sequence as follows: After an operation mode is selected, RYn1 (Start) turns on upon the lapse of the switching hold time ("8 ms + communication delay time").

5. INDEXER OPERATION

5.5.5 Safety precautions

(1) RWrn6 (Station No. output)

- (a) When a home position return is not executed in the absolute position detection system or incremental system, "0" is set in RWrn6.
- (b) When one or more home position returns are completed in the absolute position detection system...
 - 1) At power-on or forced stop, the corresponding station No. is set in RWrn6 if the number of droop pulses is within the in-position range of each next station position.
 - 2) After power-on or during servo motor driving after the forced stop reset, RWrn6 will retain the value of the previous operation even when the number of droop pulses is within the in-position range of the target next station if the remaining command travel distance is not "0".
 - 3) After power-on or after servo motor driving following the forced stop reset, the corresponding station No. is set in RWrn6 under the following conditions: The rest of the command travel distance is "0", and the number of droop pulses is within the in-position range of the target next station at which the servo motor should stop.

(2) Torque limit

When RYn1 (Start) is inputted to automatic operation mode, manual operation mode, or torque limit changing dog type home position return, the torque limit will change from the setting value of [Pr. PC77 Internal torque limit 2] to the setting value of [Pr. PA11 Forward rotation torque limit] or [Pr. PA12 Reverse rotation torque limit]. Additionally, after positioning completion signal is outputted, the time set with [Pr. PT39] has passed and the torque limit will change from [Pr. PA11 Forward rotation torque limit] or [Pr. PA12 Reverse rotation torque limit] to the setting value of [Pr. PC77 Internal torque limit 2]. Since the initial value of [Pr. PC77] is 0.0%, change the value to use the indexer operation. If the value is unchanged, the servo motor coasts during a stop.

(3) Deceleration to a stop function

When the operation is stopped with the deceleration to a stop function during each operation mode of the rotation direction specifying indexer, shortest rotating indexer, and station JOG, the shaft will stop regardless of the station position.

6. APPLICATION OF FUNCTIONS

6. APPLICATION OF FUNCTIONS

This chapter explains application of using servo amplifier functions.

6.1 Simple cam function

CAUTION

- Note that the number of write times to the Flash-ROM where the cam data is stored is limited to approximately 10000. If the total number of write times exceeds 10000, the servo amplifier may malfunction when the Flash-ROM reaches the end of its useful life.

POINT


- The simple cam function is available with servo amplifiers with software version A3 or later.
- The simple cam function can be used with the point table method.
- This function is not available with the servo amplifier to which the MR-D30 unit has been connected.
- When writing cam data and cam control data, do so after switching to test operation mode or after network communication is established between the servo amplifier and controller.
- When [AL. F5.2 Cam data miswriting warning] occurs during cam data writing, set [Pr. PT34] to "5010" to initialize the cam data.
- Simple cam function is not compatible with infinite feed function. When using the infinite feed function, configure the incremental system.
- When using simple cam function, execute operation so that the machine speed of the input axis is less than "[Cam control data No. 48 - Cam axis one cycle length] × 1/2 ÷ 100 [mm/s]". Failure to do so may cause the input axis and output axis to become out of synchronization.

6. APPLICATION OF FUNCTIONS

6.1.1 Outline of simple cam function

Simple cam function enables synchronous control by using software instead of controlling mechanically with cam.


The following shows a movement trajectory when the cam below is used and the input axis is rotated once.



By setting cam data and cam control data, the simple cam function enables synchronous control with an input axis (synchronous encoder input or point table command) with a start of positioning.

6.1.2 Simple cam function block

The function block diagram of the simple cam is shown below. Use MR Configurator2 to set the cam data and the cam control data.



6. APPLICATION OF FUNCTIONS

6.1.3 Simple cam specification list

(1) Specification list

Item			MR-J4-_GF_-RJ
Memory capacity (Note)		Storage area for cam data	8 Kbytes (Flash-ROM)
		Working area for cam data	8 Kbytes (RAM) (Note 2)
Number of registration			Max. 8
Comment			Max. 32 single-byte characters for each cam data
Cam data and cam control data	Stroke ratio data type	Cam resolution	256/512/1024/2048
		Stroke ratio [%]	-100.000 to 100.000
	Coordinate data type	Number of coordinate	2 to 1024
		Coordinate data	Input value: 0 to 999999 Output value: -999999 to 999999
Cam curve			12 types (constant speed/constant acceleration/5th curve/single hypotenuse/cycloid/distorted trapezoid/distorted sine/distorted constant speed/trapezoid/reverse trapezoid/double hypotenuse/reverse double hypotenuse)

Note The memory capacity includes a use area (storage area for cam data) for storing in the servo amplifier and an actual operation area (working area for cam data).

(2) Cam resolution

(a) Stroke ratio data type

Cam resolution	Max. number of registration
256	8
512	4
1024	2
2048	1




(b) Coordinate data type

Number of coordinate	Max. number of registration
128	8
256	4
512	2
1024	1

6. APPLICATION OF FUNCTIONS

6.1.4 Control of simple cam function

The following three cam controls are available by setting the cam data and the cam control data with MR Configurator2.

Cam control method	Description	Actual movement
To-and-fro control	Reciprocates within a specified cam stroke.	<p>Cam data and cam control data</p>  <p>Cam axis one cycle current value (Input)</p> <p>Cam conversion processing</p> <p>Feed current value (Output)</p>
Feed control	Updates a cam standard position per cycle.	<p>Cam data and cam control data</p>  <p>Cam axis one cycle current value (Input)</p> <p>Cam conversion processing</p> <p>Feed current value (Output)</p> <p>Cam standard position (First cycle)</p> <p>Cam standard position (Second cycle)</p> <p>Cam standard position (Third cycle)</p>
Linear control	Performs linear control to keep the one-cycle stroke ratio as 100%.	<p>Cam data and cam control data</p>  <p>Cam axis one cycle current value (Input)</p> <p>Cam conversion processing</p> <p>Feed current value (Output)</p> <p>Cam standard position (First cycle)</p> <p>Cam standard position (Second cycle)</p> <p>Cam standard position (Third cycle)</p> <p>Stroke amount \times 100%</p>


6. APPLICATION OF FUNCTIONS

6.1.5 Operation in combination with the simple cam

(1) Encoder following function


The servo amplifier receives A/B-phase output signal from a synchronous encoder and starts the servo motor with the signal.

Up to 4 Mpulses/s can be inputted from the synchronous encoder to use with the servo amplifier.



(2) Simple cam position compensation function

The servo amplifier receives input signals from the touch probe, calculates compensation, and compensates the position of the cam axis.



6. APPLICATION OF FUNCTIONS

6.1.6 Setting list

(1) List of items set with MR Configurator2

Set the following on the cam setting window of MR Configurator2.

Setting item		Setting
Cam control data	Main shaft input axis selection	Select a command input method for the cam axis. Select "synchronous encoder axis" or "servo input axis".
	Cam No. selection	Select the number to create the cam control data.
	Resolution setting	Set the cam resolution. Select from 256/512/1024/2048.
	Cam axis one cycle length	Set a travel distance of cam one cycle. Command unit is used as an input unit.
	Cam stroke amount	Set a cam stroke amount for the stroke ratio of 100% when using the stroke ratio data type cam control.
Cam data		Create the cam data on the cam creating window of MR Configurator2. After the data is created, write the cam data to the servo amplifier.

(2) List of items set with parameters of the servo amplifier

Set the following with the parameters of the servo amplifier.

Setting item	Setting
Operation mode selection	Select "Positioning mode (point table method)" with [Pr. PA01 Operation mode].
Cam function setting	Enable the cam function with [Pr. PT35 Function selection T-5].
Cam data selection	Select the cam data to be executed with RWwnE (Cam No. setting). Selecting the cam data for execution is also possible with [Cam control data No. 49 - Cam No.].

6. APPLICATION OF FUNCTIONS

6.1.7 Data to be used with simple cam function

CAUTION


●Note that the number of write times to the Flash-ROM where the cam control data and cam data are stored is limited to approximately 10000. If the total number of write times exceeds 10000, the servo amplifier may malfunction when the Flash-ROM reaches the end of its useful life. If data needs to be changed very frequently, use the temporal writing function and write the data to the RAM, not to the Flash-ROM.

(1) Memory configuration of cam control data and cam data

POINT

●When [AL. F5.2 Cam data miswriting warning] occurs during cam data writing, set [Pr. PT34] to "5010" to initialize the cam data.

The cam control data and the cam data used for the simple cam are stored in Flash-ROM inside the servo amplifier. When the power is turned on, the cam data and the cam control data are copied from the Flash-ROM to the RAM inside the servo amplifier, and then cam control will be executed.



Note. When the power is turned on, the cam data and the cam control data are copied from the Flash-ROM to the RAM.

Use MR Configurator2 to write the cam data and cam control data.

Be sure to write the cam data and the cam control data in servo-off state.

Two writing methods are available.

Writing method	Description
Temporary writing	Write the cam control data and the cam data to the RAM of the servo amplifier. After writing, the cam control data and the cam data will be reflected. The written data will be disabled if the power is turned off. Use this when creating and adjusting the cam control data and the cam data.
Writing	Write the cam control data and the cam data to the Flash-ROM. The data will be enabled when the power is cycled after writing After cycling the power, control is performed based on the written data. Conduct this after the cam control data and the cam data are finalized.

6. APPLICATION OF FUNCTIONS

(2) Cam data

POINT	
●	If the cam data is set incorrectly, the position command and speed command may increase and may cause machine interference or [AL. 31 Overspeed]. When you have created and changed cam data, make sure to perform test operations and make appropriate adjustments.

The following two types are available for the cam data.


Cam data type	Description
Stroke ratio data type	Cam curve of one cycle is divided equally by the number of cam resolution and defined. The cam curve will be created according to the stroke ratio data of the number of cam resolution.
Coordinate data type	Data in which cam curve of one cycle is defined with two or more points. The coordinate data is defined as (input value, output value). The input value will be the cam axis one cycle current value, and the output value will be the stroke value from the cam standard position.

(a) Stroke ratio data type

The following are set in the stroke ratio data type. Set the following items on the cam setting window of MR Configurator2. When "Cam No." is set to "0", straight-line control is performed so that the stroke ratio at the last point of the cam data becomes 100%.

Setting item	Setting	Setting range
Cam No.	Set a Cam No.	0: Linear cam 1 to 8: User-created cam
Setting method	Set "1: Stroke ratio data type".	
Cam resolution	Set the number of divisions for the cam curve of one cycle.	Select from 256/512/1024/2048.
Cam data start position	Set the positions of the cam data and cam control data to the position of when "Cam axis one cycle current value" is "0".	0 to "Cam resolution - 1"
Stroke ratio data	Set the stroke ratio from the first to the last point.	-100.000 to 100.000

The following is a setting example for "cam resolution = 512" in the stroke ratio data type.




6. APPLICATION OF FUNCTIONS

1) Feed current value

The feed current value of the cam axis is calculated as follows:

$$\text{Feed current value} = \text{Cam standard position} + (\text{Cam stroke amount} \times \text{Stroke ratio to cam axis one cycle current value})$$


When the cam axis one cycle current value is in the middle of the specified stroke ratio data, the intermediate value is calculated using the cam data before and after the value.




2) Cam standard position

The cam standard position is calculated as follows:

$$\text{Cam standard position} = \text{The preceding cam standard position} + (\text{Cam stroke amount} \times \text{Stroke ratio at the last point})$$



For to-and-fro control, create the cam data in which the stroke ratio at the last point is 0%.



6. APPLICATION OF FUNCTIONS

3) Cam data start position


This setting is available only for the stroke ratio data type cam data.

The cam data position where the "cam axis one cycle current value" becomes "0" can be set as the cam data start position.

The initial value of the cam data start position is "0". The cam axis is controlled with the cam data from the 0th point (stroke ratio = 0%).

When a value other than "0" is set as the cam data start position, cam control is started from the point where the stroke ratio is not 0%.

Set the cam data start position for each cam data within the setting range of "0 to (Cam resolution - 1)".



4) Timing of applying cam control data

New values are applied to "Cam No." and "Cam stroke amount" when RY (n + 1) 3 (Cam control command) turns on.

"Cam standard position" is updated when "Cam axis one cycle current value" passes through the 0th point of the cam data.


6. APPLICATION OF FUNCTIONS

(b) Coordinate data type


The following are set in the coordinate data type. Set the following items on the cam setting window of MR Configurator2. When "Cam No." is set to "0", straight-line control is performed so that the stroke ratio at the last point of the cam data becomes 100%.

Setting item	Setting	Setting range
Cam No.	Set a Cam No.	0: Linear cam 1 to 8: User-created cam
Setting method	Set "2: Coordinate data type".	
Number of coordinate	Set the number of coordinates for the cam curve of one cycle. The number of coordinates includes 0th point.	2 to 1024
Cam data start position	Setting is not necessary.	
Coordinate data	Set the coordinate data (input value X_n and output value Y_n) for the number of coordinates. Set from the 0th coordinate data (X_0 and Y_0). Set an input value larger than that of the coordinate data.	-999.999 to 999.999

The following is a setting example for the coordinate data type.



If "input value = 0" and "input value = cam axis one cycle length" are not set in the coordinate data, a control is executed by the line created from the closest two points.




6. APPLICATION OF FUNCTIONS

1) Feed current value

The feed current value of the cam axis is calculated as follows:

Feed current value = Cam standard position + Output value to cam axis one cycle current value

When the cam axis one cycle current value is in the middle of the specified stroke ratio data, the intermediate value is calculated using the cam data before and after the value.




2) Cam standard position


The cam standard position is calculated as follows:

Cam standard position =

The preceding cam standard position + Output value corresponding to "Input value = Cam axis one cycle length" - Output value corresponding to "Input value = 0"



For to-and-fro control, use the output value corresponding to "Input value = Cam axis one cycle length" that is equal to output value corresponding to "Input value = 0".



6. APPLICATION OF FUNCTIONS

3) Cam data start position

The cam data start position is not used in the coordinate data type.

4) Timing of applying cam control data

A new value is applied to "Cam No." when RY (n + 1) 3 (Cam control command) turns on.

"Cam standard position" is updated when the cam axis one cycle current value passes through "0".

(3) List of cam control data

The following table lists the cam control data added for the simple cam function.

Set the cam control data in the cam control data window of MR Configurator2.

POINT
<ul style="list-style-type: none"> ● Once the servo amplifier is powered off, the temporarily written data will be deleted. To store the temporarily written data, be sure to write it to the Flash-ROM before powering off the servo amplifier. ● To enable the cam control data whose symbol is preceded by *, cycle the power after setting. The cam control data is not applied by the temporal writing of MR Configurator2.

No.	Symbol	Name	Initial value	Unit	Operation mode				Control mode	
					Standard	Full.	Lin.	DD	P	R
1	MCYSM (Note)	Main axis one cycle current value setting method	0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
2	CPRO (Note)	Cam axis position restoration target	0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
3	CBSSM (Note)	Cam standard position setting method	0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
4	CCYSM (Note)	Cam axis one cycle current value setting method	0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
5	MICYS (Note)	Main axis one cycle current value (initial setting value)	0	[μm]/ 10 ⁻⁴ [inch]/ 10 ⁻³ [degree]/ [pulse]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
6	CIBSS (Note)	Cam standard position (initial setting value)	0	[μm]/ 10 ⁻⁴ [inch]/ [pulse]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
7	CICYS (Note)	Cam axis one cycle current value (initial setting value)	0	[μm]/ 10 ⁻⁴ [inch]/ 10 ⁻³ [degree]/ [pulse]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
8		For manufacturer setting	0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
9			0							
10			0							
11			0							
12			0							
13			0							
14	*ETYP	Synchronous encoder axis unit	0000h		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
15	*ECMX	Synchronous encoder axis unit conversion: Numerator	0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
16	*ECDV	Synchronous encoder axis unit conversion: Denominator	0		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

6. APPLICATION OF FUNCTIONS

No.	Symbol	Name	Initial value	Unit	Operation mode				Control mode	
					Standard	Full	Lin.	DD	P	S
17		For manufacturer setting	0							
18			0							
19			0							
20			0							
21			0							
22			0							
23			0							
24			0							
25			0							
26			0							
27			0							
28			0							
29			0							
30	*MAX	Main shaft input axis selection	0		○	○	○	○	○	○
31		For manufacturer setting	0		○	○	○	○	○	○
32	MMIX	Main shaft input method	0000h		○	○	○	○	○	○
33		For manufacturer setting	0							
34			0							
35			0							
36	CLTMD	Main shaft clutch control setting	0000h		○	○	○	○	○	○
37		For manufacturer setting	0							
38			0							
39			0							
40			0							
41			0							
42	CLTSMM (Note)	Main shaft clutch smoothing system	0		○	○	○	○	○	○
43	CLTSMT (Note)	Main shaft clutch smoothing time constant	0		○	○	○	○	○	○
44		For manufacturer setting	0							
45			0							
46			0000h							
47			0							
48	CCYL (Note)	Cam axis one cycle length	0		○	○	○	○	○	○
49	CNO (Note)	Cam No.	0		○	○	○	○	○	○
50		For manufacturer setting	0		○	○	○	○	○	○
51	CSTK (Note)	Cam stroke amount	0		○	○	○	○	○	○
52		For manufacturer setting	0							
53			0							
54			0							
55			0							
56			0							
57			0							
58			0							
59			0							

6. APPLICATION OF FUNCTIONS

No.	Symbol	Name	Initial value	Unit	Operation mode				Control mode	
					Standard	Full	Lim.	DD	Pos	Rel
60	CPHV	Cam position compensation target position	0	[μ m]/ 10^{-4} [inch]/ 10^{-3} [degree]/ [pulse]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
61	CPHT	Cam position compensation time constant	0	[ms]	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

Note. The data is updated at cam control switching.

(4) Detailed list of cam control data

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				Pos	Rel
1 *MCYSM Main axis one cycle current value setting method		Select a setting method for the main axis one cycle current value. 0: Previous value 1: Main axis one cycle current value (initial setting value) 2: Calculated from input axis	0	<input type="radio"/>	<input type="radio"/>
2 *CPRO Cam axis position restoration target		Select a target whose cam axis position is restored. 0: Cam axis one cycle current value 1: Cam standard position 2: Cam axis feed current value	0	<input type="radio"/>	<input type="radio"/>
3 *CBSSM Cam standard position setting method		Select a setting method for the cam standard position used to restore the cam axis one cycle current value. 0: Feed current value 1: Cam standard position (initial setting value) 2: Previous value The cam standard position of the last cam control is stored in the previous value. The feed current value is stored when the cam standard position of the last cam control has not been saved. Turning off the power clears the previous value.	0	<input type="radio"/>	<input type="radio"/>
4 *CCYSM Cam axis one cycle current value setting method		Select a setting method for the cam axis one cycle current value used for restoration when "Cam standard position" and "Cam axis feed current value" have been set as the cam axis position restoration targets. 0: Previous value 1: Cam axis one cycle current value (initial setting value) 2: Main axis one cycle current value The cam axis one cycle current value of the last cam control is stored in the previous value. Turning off the power clears the previous value.	0	<input type="radio"/>	<input type="radio"/>
5 *MICYS Main axis one cycle current value (initial setting value)		Set the initial value of the main axis one cycle current value. • When [Cam control data No. 30] is set to "1" The unit will be changed to [μ m], 10^{-4} [inch], or [pulse] with the setting of [Pr. PT01]. • When [Cam control data No. 30] is set to "2" The unit will be changed to [μ m], 10^{-4} [inch], 10^{-3} [degree], or [pulse] with the setting of [Cam control data No. 14]. Setting range: 0 to [Cam control data No. 48] - 1	0 Refer to Function column for unit.	<input type="radio"/>	<input type="radio"/>

6. APPLICATION OF FUNCTIONS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				$\frac{0}{1}$	$\frac{0}{1}$
6 *CIBSS Cam standard position (initial setting value)		This is enabled when [Cam control data No. 3] is set to "1". Set the initial value of the cam standard position in the output axis position unit. The unit will be changed to [μm], 10 ⁻⁴ [inch], or [pulse] with the setting of [Pr. PT01]. Setting range: -999999 to 999999	0 Refer to Function column for unit.	<input type="radio"/>	
7 *CICYS Cam axis one cycle current value (initial setting value)		Set the position to start the search processing to restore the cam axis one cycle current value. Set this item when restoring the position of the return path with the to-and-fro control cam pattern. • When [Cam control data No. 30] is set to "1" The unit will be changed to [μm], 10 ⁻⁴ [inch], or [pulse] with the setting of [Pr. PT01]. • When [Cam control data No. 30] is set to "2" The unit will be changed to [μm], 10 ⁻⁴ [inch], 10 ⁻³ [degree], or [pulse] with the setting of [Cam control data No. 14]. Setting range: 0 to [Cam control data No. 48] - 1	0 Refer to Function column for unit.	<input type="radio"/>	
14 *ETYP Synchronous encoder axis unit	___x	Control unit 0: mm 1: inch 2: degree 3: pulse	0h	<input type="radio"/>	
	__x_	Feed length multiplication 0: × 1 1: × 10 2: × 100 3: × 1000 This digit is disabled when [Cam control data No. 14] is set to "___2" or "___3".	0h	<input type="radio"/>	
	_x__	For manufacturer setting	0h		
	x___		0h		
15 *ECMX Synchronous encoder axis unit conversion: Numerator		Set a numerator used to convert encoder pulses of the synchronous encoder axis into the synchronous encoder axis unit. Set the numerator within the following range. $\frac{1}{16000} \leq \frac{\text{ECMX}}{\text{ECDV}} \leq 6000$ Setting a value out of the range will trigger [AL. F6 Cam control warning]. When "0" is set, handle the numerator in the same way as when "1" is set. Setting range: 0 to 16777215	0	<input type="radio"/>	
16 *ECDV Synchronous encoder axis unit conversion: Denominator		Set a denominator used to convert encoder pulses of the synchronous encoder axis into the synchronous encoder axis unit. Set a value within the range of [Cam control data No. 15]. Setting a value out of the range will trigger [AL. F6 Cam control warning]. When "0" is set, handle the denominator in the same way as when "1" is set. Setting range: 0 to 16777215	0	<input type="radio"/>	
30 *MAX Main shaft input axis selection		Select an input axis of the main shaft input. 0: Disabled 1: Servo input axis 2: Synchronous encoder axis Synchronous encoder axis is enabled only in standard control mode.[AL. 37] will occur when this parameter is set to "2" in the following state. • When scale measurement mode is disabled • When an encoder other than A/B-phase differential output encoder or A/B/Z-phase differential output encoder is connected	0	<input type="radio"/>	

6. APPLICATION OF FUNCTIONS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				$\frac{0}{1}$	$\frac{0}{1}$
32 *MMIX Main shaft input method	___ x	Main input method 0: Input + 1: Input - 2: No input	0h	<input type="radio"/>	<input type="radio"/>
	__ x _	Sub input method Set how to total cam position compensation. 0: Input + (cam position compensations are totaled) 1: Input - (cam position compensations are totaled after their plus and minus signs are reversed) 2: No input (cam position compensations are totaled as 0)	0h	<input type="radio"/>	<input type="radio"/>
	_ x _ _	For manufacturer setting	0h	<input type="radio"/>	<input type="radio"/>
	x _ _ _		0h	<input type="radio"/>	<input type="radio"/>
36 *CLTMD Main shaft clutch control setting	___ x	ON control mode 0: No clutch 1: Clutch command ON/OFF	0h	<input type="radio"/>	<input type="radio"/>
	__ x _	For manufacturer setting	0h	<input type="radio"/>	<input type="radio"/>
	_ x _ _		0h	<input type="radio"/>	<input type="radio"/>
	x _ _ _		0h	<input type="radio"/>	<input type="radio"/>
42 *CLTSMM Main shaft clutch smoothing system	<input type="radio"/>	Select a clutch smoothing system. 0: Direct 1: Time constant method (index)	0	<input type="radio"/>	<input type="radio"/>
43 *CLTSMT Main shaft clutch smoothing time constant	<input type="radio"/>	This is enabled when [Cam control data 42] is set to "1". Set the smoothing time constant. Setting range: 0 to 5000	0 [ms]	<input type="radio"/>	<input type="radio"/>
48 *CCYL Cam axis one cycle length	<input type="radio"/>	Set an input amount required for cam one cycle. • When [Cam control data No. 30] is set to "0" or "1" The unit will be changed to [μm], 10 ⁻⁴ [inch], or [pulse] with the setting of [Pr. PT01]. • When [Cam control data No. 30] is set to "2" The unit will be changed to [μm], 10 ⁻⁴ [inch], 10 ⁻³ [degree], or [pulse] with the setting of [Cam control data No. 14]. Setting range: 0 to 999999	0 Refer to Function column for unit.	<input type="radio"/>	<input type="radio"/>
49 *CNO Cam No.	<input type="radio"/>	Set the cam No. of the cam to be executed. When "0" is set, the selections of remote register RWwnE will be prioritized. When a value other than "0" is set, the selections of remote register RWwnE will be disabled. Setting range: 0 to 8	0	<input type="radio"/>	<input type="radio"/>
51 *CSTK Cam stroke amount	<input type="radio"/>	Set a cam stroke amount for the stroke ratio of 100% when using the stroke ratio data type cam. The unit will be changed to [μm], 10 ⁻⁴ [inch], or [pulse] with the setting of [Pr. PT01]. Setting range: -999999 to 999999	0 Refer to Function column for unit.	<input type="radio"/>	<input type="radio"/>

6. APPLICATION OF FUNCTIONS

No./symbol/ name	Setting digit	Function	Initial value [unit]	Control mode	
				$\frac{P}{O}$	$\frac{S}{L}$
60 *CPHV Cam position compensation target position		<p>Set a compensation target position to the input axis of the cam axis.</p> <p>Set the position of the touch probe using the cam axis one cycle current value.</p> <ul style="list-style-type: none"> When [Cam control data No. 30] is set to "1" The unit will be changed to [μm], 10^{-4} [inch], or [pulse] with the setting of [Pr. PT01]. When [Cam control data No. 30] is set to "2" The unit will be changed to [μm], 10^{-4} [inch], 10^{-3} [degree], or [pulse] with the setting of [Cam control data No. 14]. <p>Setting range: 0 to [Cam control data No. 48] - 1</p>	0 Refer to Function column for unit.	<input type="radio"/>	
61 *CPHT Cam position compensation time constant		<p>Set the time to apply the position compensation for the input axis of the cam axis.</p> <p>Setting range: 0 to 65535</p>	0 [ms]	<input type="radio"/>	

6. APPLICATION OF FUNCTIONS

- (a) Relation among the main shaft input axis, position data unit, and feed length multiplication setting
The parameters used to set the position data unit and feed length multiplication differ depending on the setting of [Cam control data No. 30 Main shaft input axis selection].

Item		Main shaft input axis selection ([Cam control data No. 30])		
		0 (Disabled)	1 (Servo input axis)	2 (Synchronous encoder axis)
Main axis one cycle current value setting method ([Cam control data No. 5])	Unit	[Pr. PT01]	[Pr. PT01]	[Cam control data No. 14]
	Multipli- cation	[Pr. PT03]	[Pr. PT03]	
Cam standard position (initial setting value) ([Cam control data No. 6])	Unit	[Pr. PT01]	[Pr. PT01]	[Pr. PT01]
	Multipli- cation	[Pr. PT03]	[Pr. PT03]	[Pr. PT03]
Cam axis one cycle current value (initial setting value) ([Cam control data No. 7])	Unit	[Pr. PT01]	[Pr. PT01]	[Cam control data No. 14]
	Multipli- cation	[Pr. PT03]	[Pr. PT03]	
Synchronous encoder axis unit conversion: Numerator ([Cam control data No. 15])	Unit	[Pr. PT01]	[Pr. PT01]	
	Multipli- cation	[Pr. PT03]	[Pr. PT03]	
Synchronous encoder axis unit conversion: Denominator ([Cam control data No. 16])	Unit	[Pr. PT01]	[Pr. PT01]	
	Multipli- cation	[Pr. PT03]	[Pr. PT03]	
Cam axis one cycle length ([Cam control data No. 48])	Unit	[Pr. PT01]	[Pr. PT01]	
	Multipli- cation	[Pr. PT03]	[Pr. PT03]	
Cam stroke amount ([Cam control data No. 51])	Unit	[Pr. PT01]	[Pr. PT01]	[Pr. PT01]
	Multipli- cation	[Pr. PT03]	[Pr. PT03]	[Pr. PT03]
Cam position compensation amount ([Cam control data No. 60])	Unit	[Pr. PT01]	[Pr. PT01]	[Cam control data No. 14]
	Multipli- cation	[Pr. PT03]	[Pr. PT03]	

- (b) Synchronous encoder axis unit conversion gear setting

The input travel distance of the synchronous encoder is in encoder pulse units. You can convert the unit into a desired unit through unit conversation by setting [Cam control data No. 15 Synchronous encoder axis unit conversion: Numerator] and [Cam control data No. 16 Synchronous encoder axis unit conversion: Denominator].

Set [Cam control data No. 15] and [Cam control data No. 16] according to the control target machine.


$$\begin{array}{lcl} \text{Synchronous encoder} & \text{Synchronous encoder} & \\ \text{axis travel distance} & = \text{input travel distance} \times & \frac{[\text{Cam control data No. 15}]}{[\text{Cam control data No. 16}]} \\ \text{(after unit conversion)} & \text{(encoder pulse unit)} & \end{array}$$

The travel distance (number of pulses) set in [Cam control data No. 16] is set in [Cam control data No. 15] in synchronous encoder axis position units.

Set [Cam control data No. 16] in encoder pulse units of the synchronous encoder.

6. APPLICATION OF FUNCTIONS

6.1.8 Function block diagram for displaying state of simple cam control



6. APPLICATION OF FUNCTIONS

6.1.9 Operation

POINT
●Execute operation so that the machine speed of the input axis is less than "[Cam control data No. 48 - Cam axis one cycle length] × 1/2 ÷ 100 [mm/s]". Failure to do so may cause the input axis and output axis to become out of synchronization.

This section explains the operation of the simple cam function using a rotary cutter system as an example.

(1) Configuration example

The rotary knife cuts the sheet conveyed by the conveyor at a constant speed into a desired length. To prevent variations in the sheet length and a cutting position mismatch, this device reads registration marks that have been printed on the sheet, and compensates cutting positions.




Fig. 6.1 System configuration example

6. APPLICATION OF FUNCTIONS

Setting example: When the sheet length is 200.0 mm, the circumferential length of the rotary knife axis (synchronous axis length) is 600.0 mm, and the sheet synchronous width is 10.0 mm




Fig. 6.2 Driving example

Basic settings require to use the simple cam function

Item	Setting	Setting value
Operation mode selection ([Pr. PA01])	Select "Point table method".	"1000"
Simple cam function setting ([Pr. PT35])	Enable the simple cam function.	"_ 1 _ _"

When the conveyor axis (main axis) feeds a sheet by the set length, the rotary knife makes one rotation (600 mm) to cut the sheet. Set the following items as follows.

Item	Setting	Setting value
Cam axis one cycle length ([Cam control data No. 48])	Set the sheet length.	200.000
Cam stroke amount ([Cam control data No. 51])	Set the rotation amount per rotation in "μm".	600000
Synchronous encoder axis unit ([Cam control data No. 14])	Set the unit of the sheet length.	0 (mm)
Unit of rotary knife axis ([Pr. PT01])	Set "mm" as the unit of position data.	"_ 0 _ _"
Cam data	Create the cam data with the operation pattern shown in Fig. 6.2.	

Set the following items as follows to use the encoder following function.

Item	Setting	Setting value
Main shaft input axis selection ([Cam control data No. 30])	Select the synchronous encoder axis.	2
Synchronous encoder axis unit multiplication: Numerator ([Cam control data No. 15])	Refer to the synchronous encoder axis unit conversion gear setting in section 6.1.7 (4) (b).	Refer to section 6.1.7 (4) (b).
Synchronous encoder axis unit multiplication: Denominator ([Cam control data No. 16])		

6. APPLICATION OF FUNCTIONS

(2) Operation

The following table shows an example of the procedure before operation.

Step	Setting and operation
1. Data setting	Refer to the setting example on the previous page and set the data.
2. Initial position adjustment	Adjust the synchronous positions of the conveyor axis and rotary knife axis. <ul style="list-style-type: none"> When the position of the conveyor axis (main axis current value) is "0", set the position of the rotary knife axis (feed current value) to "0". Since the position at power-on is "0", the home position return of the conveyor axis is not required. Perform the home position return on the rotary knife axis at the point where the blade of the cutter becomes the top. Adjust the conveyor axis and rotary knife axis so that the 0 position of both axes is located at the center of the sheet length.
3. Selecting cam data	Select the cam data to be executed with RWwnE (Cam No. setting). The user can use [Cam control data No. 49 - Cam No.] to select the cam data.
4. Servo-on	Switch on RYn0 (Servo-on).
5. Switching cam control	Switch on RY (n + 1) 3 (Cam control command) to switch the control to the cam control.
6. Starting the conveyor axis	Check that RX (n + 1) 3 (During cam control) is on and start the conveyor axis. The rotary knife axis is driven in synchronization with the conveyor axis.




Fig. 6.3 Timing chart

6. APPLICATION OF FUNCTIONS


(3) Compensation by touch probe

This system detects registration marks that have been equally printed on the sheet, and compensates the difference between the actual cam axis one cycle current value and the ideal cam axis one cycle current value (set value of the cam position compensation target position) by shifting the synchronous phase of the rotary knife axis and the conveyor axis.

Setting example: When the ideal registration mark position is 150 mm and the mark is not detected unless the conveyor feeds the sheet by 151 mm due to stretch

By executing compensation, the rotary knife cuts the sheet keeping the distance of 50 mm between the ideal position for detecting the registration mark and the position for cutting the sheet.

Item	Setting and operation
Cam position compensation target position ([Cam control data No. 60])	In this example, the ideal position for detecting the registration mark is 150 mm position from the cam axis one cycle current value. Set "150" for the cam position compensation target position.
Cam position compensation time constant ([Cam control data No. 61])	In this example, the position compensation is executed by one-shot. Set "0" for the cam position compensation time constant.



Note. The dot-and-dash line in the above figure shows a waveform of when compensation is not executed.

Fig. 6.4 Control example of cam position compensation

6. APPLICATION OF FUNCTIONS

(4) Details of cam position compensation

The cam position compensation processing compensates the difference between the target position for detecting the sensor and the actual position for detecting the sensor by shifting the cam axis one cycle current value. $ccyl'$, the cam axis one cycle length (sheet length) after compensation, is calculated as follows:

CCYL: Cam axis one cycle length ([Cam control data No. 48])


CPHV: Cam position compensation target position ([Cam control data No. 60])

$ccyl'$: Cam axis one cycle length (after compensation)

$cpos$: Cam axis one cycle current value at sensor detection


$CPHV - cpos$: Distance between the target sensor detection position and actual sensor detection position

- When the sensor detection position is before the target position ($CPHV \geq cpos$): $ccyl' = CCYL - (CPHV - cpos)$



Increase the conveyor travel distance by adding the difference ($CPHV - cpos$) to the cam axis one cycle current value. Adjust the filter time constant for acceleration/deceleration at compensation with [Cam control data No. 61 Cam position compensation time constant].

- When the sensor detection position is after the target position ($CPHV < cpos$): $ccyl' = CCYL + (cpo - CPHV)$



Decrease the conveyor travel distance by subtracting the difference ($cpo - CPHV$) from the cam axis one cycle current value. Adjust the filter time constant for acceleration/deceleration at compensation with [Cam control data No. 61 Cam position compensation time constant].

6. APPLICATION OF FUNCTIONS

6.1.10 Cam No. setting method

POINT	
●	When the cam No. is set to a value other than "0" to "8", [AL. F6.5 Cam No. external error] will occur. If the cam data of a specified cam No. does not exist, [AL. F6.3 Cam unregistered error] occurs. At this time, the cam control is not executed and the servo motor does not start. Turning off the cam control command clears [AL. F6.3] and [AL. F6.5].

The cam No. can be set and changed using the RWwnE (cam No. setting) in the same way as it is designated in [Cam control data No. 49], and selected in Point table No. selection.

The priority level of cam control parameter and RWwnE are as follows.

[Pr. PT35] setting	[Cam control data No. 49] setting	RWwnE	Setting
_ 0 _ _ (Simple cam function disabling setting)	×	×	The cam function will be disabled with the setting of [Pr. PT35].
_ 1 _ _ (Simple cam function enable setting)	"0" (initial value)	○	Cam No. is determined by the RWwnE setting.
	Other than "0"	×	The cam No. is set with the setting of [Cam control data No. 49]. Cam No. setting by the RWwnE is disabled.

Note. ○: Enable, ×: Disable

6. APPLICATION OF FUNCTIONS

6.1.11 Stop operation of cam control


If one of the following stop causes occurs on the output axis during cam control, the cam control stops after the output axis is stopped. (RX (n + 1) 3 (Under cam control) turns off.)

To restart the cam control, adjust the synchronous position of the output axis.

Stop cause	Command stop processing	Remark
Software stroke limit detection	Instantaneous stop	Refer to (1).
Stroke limit detection	Instantaneous stop	Refer to (1).
Stop due to forced stop 1 or 2, or alarm occurrence	Instantaneous stop or deceleration to a stop	Stop due to base circuit shut-off Refer to (1). Stop by the forced stop deceleration function Refer to (2).
RY (n + 1) 3 (Cam control command) OFF	Instantaneous stop	Refer to (1).
Servo-off	Instantaneous stop	Coasting state

(1) Instantaneous stop

The operation stops without deceleration. The servo amplifier immediately stops the command.




6. APPLICATION OF FUNCTIONS

(2) Deceleration stop

The output axis decelerates to stop according to [Pr. PC51 Forced stop deceleration time constant]. After a deceleration stop starts, the cam axis one cycle current value and feed current value are not updated. The path of the feed current value is drawn, and the stop is made regardless of the cam control.

Decelerate the input axis to stop when decelerating the output axis to stop in synchronization with the input axis.




When using a positioning command (internal command) for the input axis, inputting a temporary stop or switching the operation mode decelerates the input axis to stop. Since the output axis stops in synchronization with the input axis, the synchronous relationship is kept and the cam control does not stop.

When the control mode is switched to the home position return mode, the cam control will stop.

6. APPLICATION OF FUNCTIONS

6.1.12 Restart operation of cam control

When the cam control is stopped during operation, a gap is generated in the synchronization between the main shaft and the driven shaft. To solve the gap, return the main shaft and the driven shaft to the synchronization starting point and then start the synchronous operation.




The above shows an example for when the synchronization starting point is the point where both command position and feed current value are "0".

6. APPLICATION OF FUNCTIONS

6.1.13 Cam axis position at cam control switching

The cam axis position is determined by the positional relationship of three values of "Cam axis one cycle current value", "Cam axis standard position" and "Cam axis feed current value". When the control has been switched to the cam control (RY (n + 1) 3 (Cam control command) is on), defining the positions of two of these values restores the position of the remaining one value.



The following table lists the parameters required to be set for the cam axis position restoration. Refer to section 6.1.7 (3) for the settings.

Cam axis position restoration target ([Cam control data No. 2])	Cam standard position setting method ([Cam control data No. 3])	Cam standard position (initial setting value) ([Cam control data No. 6])	Cam axis one cycle current value setting method ([Cam control data No. 4])	Cam axis one cycle current value (initial setting value) ([Cam control data No. 7])	Restoration processing details
0: Cam axis one cycle current value	○	○ (Note)		○ (Used as the search starting point of cam pattern.)	"Cam axis one cycle current value" is restored based on "Cam standard position" and "Cam axis feed current value".
1: Cam standard position			○	○ (Note)	"Cam standard position" is restored based on "Cam axis one cycle current value" and "Cam axis feed current value".
2: Cam axis feed current value	○	○ (Note)	○	○ (Note)	"Cam axis feed current value" is restored based on "Cam axis one cycle current value" and "Cam standard position".

○: Required

Note. Set this parameter when [Cam control data No. 3] is set to "1".

(1) Cam axis one cycle current value restoration

When RY (n + 1) 3 (Cam control command) turns on, "Cam axis one cycle current value" is restored based on "Cam standard position" and "Cam axis feed current value" and the control is switched to the cam control. Set the "cam standard position" used for the restoration with cam control data. The feed current value at cam control switching is used as "Cam axis feed current value".

The cam axis one cycle current value is restored by searching for a corresponding value from the beginning to the end of the cam pattern.


Set the starting point for searching the cam pattern with "[Cam control data No. 7 Cam axis one cycle current value (initial setting value)]". (It is also possible to search from the return path in the cam pattern of to-and-fro control.)




6. APPLICATION OF FUNCTIONS

(a) Cam pattern of to-and-fro control


1) Searching from "Cam axis one cycle current value = 0" (Cam data start position = 0)



2) Searching from a value in the middle of the cam axis one cycle current value (Cam data start position = 0)




3) Searching from a value in the middle of the cam axis one cycle current value (Cam data start position $\neq 0$)




6. APPLICATION OF FUNCTIONS

4) Searching fails




(b) Cam pattern of feed control

1) Searching from "Cam axis one cycle current value = 0" (Cam data start position = 0)




2) Searching from a value in the middle of the cam axis one cycle current value (Cam data start position = 0)




6. APPLICATION OF FUNCTIONS

- 3) Searching from a value in the middle of the cam axis one cycle current value (Cam data start position $\neq 0$)



- 4) The first searching has failed and the second searching starts


POINT
<p>● If the first searching has failed, the second searching may not be processed in the next cycle for a cam pattern with a feed stroke smaller than 100%. By setting or positioning a cam standard position in advance, an intended cam axis one cycle current value can be found in the first searching.</p>




6. APPLICATION OF FUNCTIONS

(2) Cam standard position restoration

If the cam axis position restoration target is set to "Cam standard position restoration" and RY (n + 1) 3 (Cam control command) turns on, the "cam standard position" will be restored based on "Cam axis one cycle current value" and "Cam axis feed current value" and the control is switched to the cam control. Set the "cam axis one cycle current value" used for restoration with cam control data. The feed current value of when RY (n + 1) 3 (Cam control command) is on is used as the "cam axis feed current value".



The following shows an example for restoring the cam standard position to start an operation from a point where both the feed current value and the cam axis one cycle current value are 0" in the cam whose cam data start position is not "0".




6. APPLICATION OF FUNCTIONS

(3) Cam axis feed current value restoration

POINT
<ul style="list-style-type: none">● When the restored cam axis feed current value differs from the feed current value at cam control switching, the cam axis feed current value moves to the value restored just after cam control switching.● If the difference between the restored cam axis feed current value and the feed current value is larger than the value set in [Pr. PA10 In-position range], [AL. F6.2 Cam axis feed current value restoration failed] will occur and the control cannot be switched to the cam control. Note that, if increasing the value of the in-position range may lead to a rapid cam switching.

If the cam axis position restoration target is set to "Cam axis feed current value restoration" and RY (n + 1) 3 (Cam control command) turns on, "Cam axis feed current value" is restored based on "Cam axis one cycle current value" and "Cam standard position" and the control is switched to the cam control. Set the "cam axis one cycle current value" and "cam standard position" used for the restoration with cam control data.



6. APPLICATION OF FUNCTIONS

6.1.14 Clutch

The clutch is used to transmit/disengage command pulses from the main shaft input side to the output axis module through turning the clutch ON/OFF, controlling start/stop of the servo motor operation. Set whether or not to use the clutch control with [Cam control data No. 36 - Main shaft clutch control setting]. Although the clutch ON/OFF can be changed during cam control, the setting of [Cam control data No. 36] cannot be changed from "1 (Clutch command ON/OFF)" to "0 (No clutch)" during cam control.

(1) ON control mode


(a) "No clutch"

When [Cam control data No. 36 - Main shaft clutch control setting] is set to "0 (No clutch)", other clutch parameters are not used due to direct coupled operation.

(b) Clutch command ON/OFF

Turning on/off RY (n + 1) 5 (Clutch command) turns on/off the clutch.

(Settings in the OFF control mode are not used in the clutch command ON/OFF mode.)



(2) Clutch smoothing method


Smoothing is processed with the time constant set in [Cam control data No. 43 Main shaft clutch smoothing time constant] at clutch ON/OFF. After clutch ON smoothing is completed, smoothing is processed with the set time constant when the speed of the input values changes.

The travel distance from turning on to off of the clutch does not change with smoothing.

Travel distance after clutch smoothing = Travel distance before clutch smoothing

Time constant method exponential curve smoothing


Set [Cam control data No. 42 - Main shaft clutch smoothing system] to "1 (Time constant method (index))".



6. APPLICATION OF FUNCTIONS

6.1.15 Cam position compensation target position


Perform compensation to match the cam axis one cycle current value with the cam position compensation target position ([Cam control parameter No. 60]) by inputting a cam position compensation request.



6. APPLICATION OF FUNCTIONS

6.1.16 Cam position compensation time constant

The compensation amount calculated when cam position compensation is requested is divided into the time set in [Cam control data No. 61 Cam position compensation time constant] and used for compensation.



6.1.17 Backup restore function

POINT

- For details on the backup restore function, refer to section 17.3 in "MR-J4-_GF_(-RJ) Servo Amplifier Instruction Manual (Motion Mode)", and GOT User's Manual.

The backup/restoration function is a function for backing up and restoring all parameter data and point table data in MR-J4-_GF_(-RJ) to GOT by using SLMP. When executing cam backup and restore, the following restrictions apply.

- When the "Simple cam function selection" of [Pr. PT35] is disabled, cam data can be restored but backing it up is not possible. When backing up cam data, do so after enabling "Simple cam function selection" of [Pr. PT35].
- When restoring cam data, do so after network communication is established between the servo amplifier and controller.
- When restoring cam data for the second time, do so after cycling the power of the servo amplifier. Executing restoration without cycling the power will trigger [AL. F5.2 Cam data - Area miswriting warning].

[illegible]

REVISIONS

*The manual number is given on the bottom left of the back cover.

Revision Date	*Manual Number	Revision
Feb. 2016	SH(NA)030221ENG-A	First edition
Feb. 2017	SH(NA)030221ENG-B	<p>Indexer positioning function and simple cam function are added.</p> <p>4. Additional instructions</p> <p>(1) Transportation and installation The ambient humidity is changed.</p> <p>(2) Wiring Partially added.</p> <p>(5) Corrective actions Partially added.</p> <p>(6) Maintenance, inspection and parts replacement Partially added and partially changed.</p> <p>«About the manual» "MELSERVO MR-D30 Instruction Manual" is added.</p> <p>Section 1.1 (1) Contents were partially added to the table.</p> <p>Section 1.1 (2) Configuration change, (b) is newly added.</p> <p>Section 1.2 "Indexer" is added.</p> <p>Section 1.3 "Indexer" and "Simple cam function" are added.</p> <p>Section 2.1.1 Partially changed and "Simple cam function" is added.</p> <p>Section 2.1.2 "Simple cam function" is added.</p> <p>Section 2.1.3 "Simple cam function" is added.</p> <p>Section 2.1.4 Partially changed and "Simple cam function" is added.</p> <p>Section 2.3.1 (1) (b) Partially changed.</p> <p>Section 2.3.2 (3) Partially changed.</p> <p>Section 2.4.1 (4) Partially changed.</p> <p>Chapter 3 POINT is changed.</p> <p>Section 3.1 "Indexer" and "Simple cam function" are added.</p> <p>Section 3.2.1 [Pr. PA01], [Pr. PA06], and [Pr. PA07] are added. [Pr. PA10] is partially changed.</p> <p>Section 3.2.2 Newly added.</p> <p>Section 3.2.3 [Pr. PD12] is partially changed.</p> <p>Section 3.2.4 [Pr. PT07], [Pr. PT12], [Pr. PT34], [Pr. PT62], and [Pr. PT69] are partially changed. [Pr. PT27], [Pr. PT35], [Pr. PT39], [Pr. PT40], and [Pr. PT45] are added.</p> <p>Section 3.3.2 Newly added.</p> <p>Chapter 5 Newly added.</p> <p>Chapter 6 Newly added.</p>

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

MEMO

[illegible]

Country/Region	Sales office	Tel/Fax
USA	Mitsubishi Electric Automation, Inc. 500 Corporate Woods Parkway, Vernon Hills, IL 60061, U.S.A.	Tel : +1-847-478-2100 Fax : +1-847-478-2253
Mexico	Mitsubishi Electric Automation, Inc. Mexico Branch Mariano Escobedo #69, Col. Zona Industrial, Tlalnepantla Edo. Mexico, C.P.54030	Tel : +52-55-3067-7500 Fax : —
Brazil	Mitsubishi Electric do Brasil Comercio e Servicos Ltda. Avenida Adelino Cardana, 293, 21 andar, Bethaville, CEP 06401-147, Barueri SP, Brazil	Tel : +55-11-4689-3000 Fax : +55-11-4689-3016
Germany	Mitsubishi Electric Europe B.V. German Branch Mitsubishi-Electric-Platz 1, 40882 Ratingen, Germany	Tel : +49-2102-486-0 Fax : +49-2102-486-1120
UK	Mitsubishi Electric Europe B.V. UK Branch Travellers Lane, UK-Hatfield, Hertfordshire, AL10 8XB, U.K.	Tel : +44-1707-28-8780 Fax : +44-1707-27-8695
Italy	Mitsubishi Electric Europe B.V. Italian Branch Centro Direzionale Colleoni - Palazzo Sirio, Viale Colleoni 7, 20864 Agrate Brianza (MB), Italy	Tel : +39-039-60531 Fax : +39-039-6053-312
Spain	Mitsubishi Electric Europe B.V. Spanish Branch Carretera de Rubi, 76-80-Apdo. 420, 08190 Sant Cugat del Valles (Barcelona), Spain	Tel : +34-935-65-3131 Fax : +34-935-89-1579
France	Mitsubishi Electric Europe B.V. French Branch 25, Boulevard des Bouvets, 92741 Nanterre Cedex, France	Tel : +33-1-55-68-55-68 Fax : +33-1-55-68-57-57
Czech Republic	Mitsubishi Electric Europe B.V. Czech Branch Avenir Business Park, Radlicka 751/113e, 158 00 Praha 5, Czech Republic	Tel : +420-251-551-470 Fax : +420-251-551-471
Poland	Mitsubishi Electric Europe B.V. Polish Branch ul. Krakowska 50, 32-083 Balice, Poland	Tel : +48-12-347-65-00 Fax : +48-12-630-47-01
Russia	Mitsubishi Electric (Russia) LLC St. Petersburg Branch Piskarevsky pr. 2, bld 2, lit "Sch", BC "Benua", office 720; 195027 St. Petersburg, Russia	Tel : +7-812-633-3497 Fax : +7-812-633-3499
Sweden	Mitsubishi Electric Europe B.V. (Scandinavia) Fjellievagen 8, SE-22736 Lund, Sweden	Tel : +46-8-625-10-00 Fax : +46-46-39-70-18
Turkey	Mitsubishi Electric Turkey A.S. Umraniye Branch Serifali Mahallesi Nutuk Sokak No:5, TR-34775 Umraniye / Istanbul, Turkey	Tel : +90-216-526-3990 Fax : +90-216-526-3995
UAE	Mitsubishi Electric Europe B.V. Dubai Branch Dubai Silicon Oasis, P.O.BOX 341241, Dubai, U.A.E.	Tel : +971-4-3724716 Fax : +971-4-3724721
South Africa	Adroit Technologies 20 Waterford Office Park, 189 Witkoppen Road, Fourways, South Africa	Tel : +27-11-658-8100 Fax : +27-11-658-8101
China	Mitsubishi Electric Automation (China) Ltd. Mitsubishi Electric Automation Center, No.1386 Hongqiao Road, Shanghai, China	Tel : +86-21-2322-3030 Fax : +86-21-2322-3000
Taiwan	SETSUYO ENTERPRISE CO., LTD. 6F, No.105, Wugong 3rd Road, Wugu District, New Taipei City 24889, Taiwan	Tel : +886-2-2299-2499 Fax : +886-2-2299-2509
Korea	Mitsubishi Electric Automation Korea Co., Ltd. 7F-9F, Gangseo Hangang Xi-tower A, 401, Yangcheon-ro, Gangseo-Gu, Seoul 07528, Korea	Tel : +82-2-3660-9510 Fax : +82-2-3664-8372/8335
Singapore	Mitsubishi Electric Asia Pte. Ltd. 307 Alexandra Road, Mitsubishi Electric Building, Singapore 159943	Tel : +65-6473-2308 Fax : +65-6476-7439
Thailand	Mitsubishi Electric Factory Automation (Thailand) Co., Ltd. 12th Floor, SV.City Building, Office Tower 1, No. 896/19 and 20 Rama 3 Road, Kwaeng Bangpongpan, Khet Yannawa, Bangkok 10120, Thailand	Tel : +66-2682-6522 to 6531 Fax : +66-2682-6020
Indonesia	PT. Mitsubishi Electric Indonesia Gedung Jaya 11th Floor, JL. MH. Thamrin No.12, Jakarta Pusat 10340, Indonesia	Tel : +62-21-3192-6461 Fax : +62-21-3192-3942
Vietnam	Mitsubishi Electric Vietnam Company Limited Unit 01-04, 10th Floor, Vincom Center, 72 Le Thanh Ton Street, District 1, Ho Chi Minh City, Vietnam	Tel : +84-8-3910-5945 Fax : +84-8-3910-5947
India	Mitsubishi Electric India Pvt. Ltd. Pune Branch Emerald House, EL-3, J Block, M.I.D.C., Bhosari, Pune - 411026, Maharashtra, India	Tel : +91-20-2710-2000 Fax : +91-20-2710-2100
Australia	Mitsubishi Electric Australia Pty. Ltd. 348 Victoria Road, P.O. Box 11, Rydalmere, N.S.W 2116, Australia	Tel : +61-2-9684-7777 Fax : +61-2-9684-7245
Japan	Mitsubishi Electric Corporation Tokyo Building, 2-7-3, Marunouchi, Chiyoda-ku, Tokyo 100-8310, Japan	Tel : +81-3-3218-2111

MELSERVO and CC-Link IE are trademarks or registered trademarks of Mitsubishi Electric Corporation in Japan and/or other countries.
Ethernet is a trademark of Xerox Corporation.
Modbus is registered trademark of SCHNEIDER ELECTRIC USA, INC.
All other product names and company names are trademarks or registered trademarks of their respective companies.

Warranty

1. Warranty period and coverage

We will repair any failure or defect hereinafter referred to as "failure" in our FA equipment hereinafter referred to as the "Product" arisen during warranty period at no charge due to causes for which we are responsible through the distributor from which you purchased the Product or our service provider. However, we will charge the actual cost of dispatching our engineer for an on-site repair work on request by customer in Japan or overseas countries. We are not responsible for any on-site readjustment and/or trial run that may be required after a defective unit is repaired or replaced.

[Term]

The term of warranty for Product is twelve (12) months after your purchase or delivery of the Product to a place designated by you or eighteen (18) months from the date of manufacture whichever comes first ("Warranty Period"). Warranty period for repaired Product cannot exceed beyond the original warranty period before any repair work.

[Limitations]

- (1) You are requested to conduct an initial failure diagnosis by yourself, as a general rule.
It can also be carried out by us or our service company upon your request and the actual cost will be charged. However, it will not be charged if we are responsible for the cause of the failure.
- (2) This limited warranty applies only when the condition, method, environment, etc. of use are in compliance with the terms and conditions and instructions that are set forth in the instruction manual and user manual for the Product and the caution label affixed to the Product.
- (3) Even during the term of warranty, the repair cost will be charged on you in the following cases;
 - (i) a failure caused by your improper storing or handling, carelessness or negligence, etc., and a failure caused by your hardware or software problem
 - (ii) a failure caused by any alteration, etc. to the Product made on your side without our approval
 - (iii) a failure which may be regarded as avoidable, if your equipment in which the Product is incorporated is equipped with a safety device required by applicable laws and has any function or structure considered to be indispensable according to a common sense in the industry
 - (iv) a failure which may be regarded as avoidable if consumable parts designated in the instruction manual, etc. are duly maintained and replaced
 - (v) any replacement of consumable parts (battery, fan, smoothing capacitor, etc.)
 - (vi) a failure caused by external factors such as inevitable accidents, including without limitation fire and abnormal fluctuation of voltage, and acts of God, including without limitation earthquake, lightning and natural disasters
 - (vii) a failure generated by an unforeseeable cause with a scientific technology that was not available at the time of the shipment of the Product from our company
 - (viii) any other failures which we are not responsible for or which you acknowledge we are not responsible for

2. Term of warranty after the stop of production

- (1) We may accept the repair at charge for another seven (7) years after the production of the product is discontinued. The announcement of the stop of production for each model can be seen in our Sales and Service, etc.
- (2) Please note that the Product (including its spare parts) cannot be ordered after its stop of production.

3. Service in overseas countries

Our regional FA Center in overseas countries will accept the repair work of the Product. However, the terms and conditions of the repair work may differ depending on each FA Center. Please ask your local FA center for details.

4. Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to:

- (1) Damages caused by any cause found not to be the responsibility of Mitsubishi.
- (2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products.
- (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products.
- (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

5. Change of Product specifications

Specifications listed in our catalogs, manuals or technical documents may be changed without notice.

6. Application and use of the Product

- (1) For the use of our General-Purpose AC Servo, its applications should be those that may not result in a serious damage even if any failure or malfunction occurs in General-Purpose AC Servo, and a backup or fail-safe function should operate on an external system to General-Purpose AC Servo when any failure or malfunction occurs.
- (2) Our General-Purpose AC Servo is designed and manufactured as a general purpose product for use at general industries. Therefore, applications substantially influential on the public interest for such as atomic power plants and other power plants of electric power companies, and also which require a special quality assurance system, including applications for railway companies and government or public offices are not recommended, and we assume no responsibility for any failure caused by these applications when used.
In addition, applications which may be substantially influential to human lives or properties for such as airlines, medical treatments, railway service, incineration and fuel systems, man-operated material handling equipment, entertainment machines, safety machines, etc. are not recommended, and we assume no responsibility for any failure caused by these applications when used. We will review the acceptability of the abovementioned applications, if you agree not to require a specific quality for a specific application. Please contact us for consultation.

MODEL	MR-J4-GF-(RJ) INSTRUCTIONMANUAL(I/O MODE)
MODEL CODE	1CW863

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : TOKYO BLDG MARUNOUCHI TOKYO 100-8310