

TravelMate Notebook Series

Quick Guide

Product registration

When using your product for the first time, it is recommended that you immediately register it. This will give you access to some useful benefits, such as:

- Faster service from our trained representatives.
- Membership in the Acer community: receive promotions and participate in customer surveys.
- The latest news from Acer.

Hurry and register, as other advantages await you!

How to register

To register your Acer product, please visit **www.acer.com**. Select your country, click **PRODUCT REGISTRATION** and follow the simple instructions.

You will also be asked to register your product during the setup process, or you can double-click the Registration icon on the desktop.

After we receive your product registration, you will be sent a confirmation email with important data that you should keep in a safe place.

Obtaining Acer accessories

We are happy to inform you that Acer's warranty extension program and Notebook accessories are available online. Come and visit our online shop and find what you need at **store.acer.com**.

The Acer store is being progressively rolled out, and, unfortunately may not be available in some regions. Please check back regularly to see when it will be available in your country.

© 2012. All Rights Reserved.

TravelMate Notebook Series Quick Guide

Original Issue: 05/2012

Model Number : _____

Serial Number: _____

Purchase Date: _____

Place of Purchase: _____

Acer recommends...

Productivity Software

Work Great with Microsoft® Office 2010 - Express your ideas, solve problems and simplify everyday projects with Office 2010.

Photo editing - Easily edit and print your photos with Windows Live Photo Gallery. Then share them on Facebook, YouTube or Windows Live.

Search & Decide with Bing - Find and organize the answers you need using Bing™, so you can make faster, more informed decisions.

First things first

We would like to thank you for making an Acer notebook your choice for meeting your mobile computing needs.

Your guides

To help you use your Acer notebook, we have designed a set of guides:

First off, the **setup poster** helps you get started with setting up your computer.

The **TravelMate Generic User Guide** contains useful information applying to all models in the TravelMate product series. It covers basic topics such as using the keyboard and audio, etc. Please understand that due to its nature, the **Generic User Guide** will occasionally refer to functions or features which are only contained in certain models of the series, but not necessarily in the model you purchased. Such instances are marked in the text with language such as "only for certain models".

The **Quick Guide** introduces you to the basic features and functions of your new computer. For more on how your computer can help you to be more productive, please refer to the **TravelMate Generic User Guide**. This guide contains detailed information on such subjects as system utilities, data recovery, expansion options and troubleshooting. In addition it contains warranty information and the general regulations and safety notices for your notebook. It is available in Portable Document Format (PDF) and comes preloaded on your notebook. Follow these steps to access it:

- 1 Click on  **Start > All Programs > Documentation**.
- 2 Click on **TravelMate Generic User Guide**.



.....




Note: Viewing the file requires Adobe Reader. If Adobe Reader is not installed on your computer, clicking on **TravelMate Generic User Guide** will run the Adobe Reader setup program first. Follow the instructions on the screen to complete the installation. For instructions on how to use Adobe Reader, access the **Help and Support** menu.


Your Acer notebook tour

After setting up your computer as illustrated in the setup poster, let us show you around your new Acer notebook.

Front view










#	Icon	Item	Description
1		Webcam	Web camera for video communication. <i>A light next to the webcam indicates that the webcam is active.</i>
2		Screen	Also called Liquid-Crystal Display (LCD), displays computer output.
		Power indicator	Indicates the computer's power status.
3		Battery indicator	Indicates the computer's battery status. 1. Charging: The light shows amber when the battery is charging. 2. Fully charged: The light shows blue when in AC mode.
		HDD indicator	Indicates when the hard disk drive is active.

#	Icon	Item	Description
4		Communication switch / indicator	Enables/disables the computer's communication devices / indicates the computer's wireless connectivity device status.
5		Microphones	Two internal microphones for stereo sound recording.

Keyboard view

















#	Icon	Item	Description
1		Caps Lock	Lights up when Caps Lock is activated.
2		Keyboard	For entering data into your computer.
3		Touchpad	Touch-sensitive pointing device which functions like a computer mouse.
4		Fingerprint reader	Fingerprint reader for Acer ProShield Security Suite (configuration may vary by model).
5		Click buttons (left and right)	The left and right buttons function like the left and right mouse buttons.

#	Icon	Item	Description
6		Num Lock	Lights up when Num Lock is activated.
		P key	Programmable key (configuration may vary by model).
		Acer email key	Opens your default email application.
7		Backup key	Launches Acer Backup Management for three-step data backup.
		Microphone mute	Mutes the microphone.
		Power button / indicator	Turns the computer on and off. Indicates the computer's power status.


Hotkeys







The computer employs hotkeys or key combinations to access most of the computer's controls like screen brightness and volume output.

To activate hotkeys, press and hold the <Fn> key before pressing the other key in the hotkey combination.


Hotkey	Icon	Function	Description
<Fn> + <F3>		Communication	Enables/disables the computer's communication devices.
<Fn> + <F4>		Sleep	Puts the computer in Sleep mode.
<Fn> + <F5>		Display toggle	Switches display output between the display screen, external monitor (if connected) and both.
<Fn> + <F6>		Screen blank	Turns the display screen backlight off to save power. Press any key to return.
<Fn> + <F7>		Touchpad toggle	Turns the internal touchpad on and off.
<Fn> + <F8>		Speaker toggle	Turns the speakers on and off.
<Fn> + <↑>		Brightness up	Increases the screen brightness.
<Fn> + <↓>		Brightness down	Decreases the screen brightness.
<Fn> + <↑>		Volume up	Increases the sound volume.
<Fn> + <↓>		Volume down	Decreases the sound volume.
<Fn> + <Home>		Play/Pause	Play or pause a selected media file.
<Fn> + <Pg Up>		Stop	Stop playing the selected media file.
<Fn> + <Pg Dn>		Previous	Return to the previous media file.
<Fn> + <End>		Next	Jump to the next media file.








Left view



#	Icon	Item	Description
1		Kensington lock slot 	Connects to a Kensington-compatible computer security lock. Note: Wrap the computer security lock cable around an immovable object such as a table or handle of a locked drawer. Insert the lock into the notch and turn the key to secure the lock. Some keyless models are also available.
2		DC-in jack	Connects to an AC adapter.
3		USB port with power-off charging	Connects to USB devices. <i>If a port is black, it is USB 2.0 compatible; if it is blue it is also USB 3.0 compatible.</i>
4		USB port	
5		Multi-in-1 card reader	Accepts Secure Digital (SD), MultiMediaCard (MMC), Memory Stick (MS), Memory Stick PRO (MS PRO), xD-Picture Card (xD). Note: Push to remove/install the card. Only one card can operate at any time.
6		ExpressCard/34 slot	Accepts one ExpressCard/34 module. Note: Push to remove/insert the module.

Right view







#	Icon	Item	Description
1		Microphone jack	Accepts inputs from external microphones.
		Headphones/ speaker jack	Connects to audio devices (e.g., speakers, headphones).
2		USB port	Connects to USB devices. <i>If a port is black, it is USB 2.0 compatible; if it is blue it is also USB 3.0 compatible.</i>
3		USB / eSATA port	Connects to USB or eSATA devices. Note: <i>If you plug in an eSATA device you will have three USB ports available.</i>
4		HDMI port	Supports high-definition digital video connections.
5		External display (VGA) port	Connects to a display device (e.g., external monitor, LCD projector).
6		Ethernet (RJ-45) port	Connects to an Ethernet 10/100/1000 based network.


Information on USB 3.0

- Compatible with USB 3.0 and earlier USB devices.
- For optimal performance, use USB 3.0-certified devices.
- Defined by the USB 3.0 (SuperSpeed USB) specification.
- Supports power-off USB charging, allowing you to charge supported mobile devices while the notebook is switched off.

Base view



#	Icon	Item	Description
1		Battery bay	Houses the computer's battery pack.
2		Battery lock	Locks the battery in position.
3		Hard disk bay	Houses the computer's hard disk (secured with screws).
		Memory compartment	Houses the computer's main memory.

#	Icon	Item	Description
4		Acer DASP (Disk Anti-Shock Protection)	Protects the hard disk from shocks and bumps.
5		Speakers	Emit stereo sound.
6		Acer ProDock connector	Connects to the optional Acer ProDock.
7		Battery release latch	Releases the battery for removal.

Environment

- Temperature:
 - Operating: 5 °C to 35 °C
 - Non-operating: -20 °C to 65 °C
- Humidity (non-condensing):
 - Operating: 20% to 80%
 - Non-operating: 20% to 80%