

Nikon

DIGITAL CAMERA

COOLPIX S32

User's Manual






En

Waterproofing

The following are important notes about the camera's waterproofing. Before using the camera, please thoroughly read the information in “**Important** Shockproof, Waterproof, Dustproof, Condensation” (BOOK xv).

Waterproofing-related Messages

The camera will display messages related to its waterproof capabilities when you select certain settings or perform certain operations. Read and follow the information displayed in the messages when they are displayed.



Waterproofing-related messages are displayed in the following situations.

- When turning on and setting the camera for the first time
- When setting the camera to **Shoot under water** (BOOK 39)
- When turning the camera on after charging

Note: If the cover is closed without removing foreign particles, water may seep inside the camera or the camera may become damaged. Make sure to inspect and clean the cover.

- Introduction**
- Parts of the Camera**
- The Basics of Shooting and Playback**
- Shooting Features**
- Playback Features**
- Recording and Playing Back Movies**
- General Camera Setup**
- Connecting the Camera to a TV, Computer, or Printer**
- Technical Notes and Index**

Introduction

Read This First

Thank you for purchasing the Nikon COOLPIX S32 digital camera. Before using the camera, please read the information in "For Your Safety" (□ viii-xi) and "<Important> Shockproof, Waterproof, Dustproof, Condensation" (□ xv-xxi), and familiarize yourself with the information provided in this manual. After reading, please keep this manual handy and refer to it to enhance your enjoyment of your new camera.

Confirming the Package Contents

In the event that any items are missing, please contact the store where you purchased the camera.



COOLPIX S32
Digital Camera



Camera Strap



Rechargeable Li-ion Battery
EN-EL19



Charging AC Adapter
EH-70P¹



USB Cable UC-E16



Brush²

- User's Manual (this manual)
- Getting Started
- Warranty

¹ A plug adapter is included if the camera was purchased in a country or region that requires a plug adapter. The shape of the plug adapter varies with the country or region of purchase (□ 10).

² The brush is used for cleaning the waterproof packing.

About This Manual

If you want to start using the camera right away, see "The Basics of Shooting and Playback" (☞ 8).

To learn about the parts of the camera and basic operations, see "Parts of the Camera" (☞ 1).

Downloading the "Reference Manual"

Refer to the *Reference Manual* (PDF format) for more detailed information.

The *Reference Manual* can be downloaded from the Nikon website.

<http://nikonimlib.com/manual/>

The *Reference Manual* can be viewed using Adobe Reader, available for free download from the Adobe website.

Other Information

- Symbols and Conventions

To make it easier to find the information you need, the following symbols and conventions are used in this manual:

Icon	Description
	This icon indicates cautions and information that should be read before using the camera.
	This icon indicates notes and information that should be read before using the camera.
 /  / 	These icons indicate other pages containing relevant information;  *: "Reference Section",  : "Technical Notes and Index."

* Refer to the *Reference Manual* for pages indicated with .

- SD, SDHC, and SDXC memory cards are referred to as "memory cards" in this manual.
- The setting at the time of purchase is referred to as the "default setting."
- The names of menu items displayed in the camera monitor, and the names of buttons or messages displayed on a computer monitor appear in bold.
- In this manual, images are sometimes omitted from monitor display samples so that monitor indicators can be more clearly shown.
- Illustrations and monitor content shown in this manual may differ from the actual product.

Information and Precautions

Life-Long Learning

As part of Nikon's "Life-Long Learning" commitment to ongoing product support and education, continually updated information is available online at the following sites:

- For users in the U.S.A.: <http://www.nikonusa.com/>
- For users in Europe and Africa: <http://www.europe-nikon.com/support/>
- For users in Asia, Oceania, and the Middle East: <http://www.nikon-asia.com/>

Visit these sites to keep up-to-date with the latest product information, tips, answers to frequently asked questions (FAQs), and general advice on digital imaging and photography. Additional information may be available from the Nikon representative in your area. Visit the site below for contact information:

<http://imaging.nikon.com/>

Use Only Nikon Brand Electronic Accessories

Nikon COOLPIX cameras are designed to the highest standards and include complex electronic circuitry. Only Nikon brand electronic accessories (including battery chargers, batteries, Charging AC adapters, and AC adapters) certified by Nikon specifically for use with this Nikon digital camera are engineered and proven to operate within the operational and safety requirements of this electronic circuitry.

THE USE OF NON-NIKON ELECTRONIC ACCESSORIES COULD DAMAGE THE CAMERA AND MAY VOID YOUR NIKON WARRANTY.

The use of third-party rechargeable Li-ion batteries not bearing the Nikon holographic seal could interfere with normal operation of the camera or result in the batteries overheating, igniting, rupturing, or leaking.

For more information about Nikon brand accessories, contact a local authorized Nikon dealer.

Holographic seal: Identifies this device as an authentic Nikon product.



Before Taking Important Pictures

Before taking pictures on important occasions (such as at weddings or before taking the camera on a trip), take a test shot to ensure that the camera is functioning normally. Nikon will not be held liable for damages or lost profits that may result from product malfunction.

About the Manuals

- No part of the manuals included with this product may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form, by any means, without Nikon's prior written permission.
- Nikon reserves the right to change the specifications of the hardware and software described in these manuals at any time and without prior notice.
- Nikon will not be held liable for any damages resulting from the use of this product.
- While every effort was made to ensure that the information in these manuals is accurate and complete, we would appreciate it were you to bring any errors or omissions to the attention of the Nikon representative in your area (address provided separately).

Notice Concerning Prohibition of Copying or Reproduction

Note that simply being in possession of material that was digitally copied or reproduced by means of a scanner, digital camera or other device may be punishable by law.

- **Items prohibited by law from being copied or reproduced**

Do not copy or reproduce paper money, coins, securities, government bonds or local government bonds, even if such copies or reproductions are stamped "Sample." The copying or reproduction of paper money, coins, or securities which are circulated in a foreign country is prohibited. Unless the prior permission of the government was obtained, the copying or reproduction of unused postage stamps or post cards issued by the government is prohibited.

The copying or reproduction of stamps issued by the government and of certified documents stipulated by law is prohibited.

- **Cautions on certain copies and reproductions**

The government has issued cautions on copies or reproductions of securities issued by private companies (shares, bills, checks, gift certificates, etc.), commuter passes, or coupon tickets, except when a minimum of necessary copies are to be provided for business use by a company. Also, do not copy or reproduce passports issued by the government, licenses issued by public agencies and private groups, ID cards and tickets, such as passes and meal coupons.

- **Comply with copyright notices**

The copying or reproduction of copyrighted creative works such as books, music, paintings, woodcut prints, maps, drawings, movies, and photographs is governed by national and international copyright laws. Do not use this product for the purpose of making illegal copies or to infringe copyright laws.

Disposing of Data Storage Devices

Please note that deleting images or formatting data storage devices such as memory cards or built-in camera memory does not completely erase the original image data. Deleted files can sometimes be recovered from discarded storage devices using commercially available software, potentially resulting in the malicious use of personal image data. Ensuring the privacy of such data is the user's responsibility.

Before discarding a data storage device or transferring ownership to another person, erase all data using commercial deletion software, or format the device and then completely refill it with images containing no private information (for example, pictures of empty sky). Care should be taken to avoid injury or damage to property when physically destroying data storage devices.

For Your Safety

To prevent damage to your Nikon product or injury to yourself or to others, read the following safety precautions in their entirety before using this equipment. Keep these safety instructions where all those who use the product will read them.



This icon marks warnings, information that should be read before using this Nikon product, to prevent possible injury.

WARNINGS

⚠ Turn off in the event of malfunction

Should you notice smoke or an unusual smell coming from the camera or Charging AC Adapter, unplug the Charging AC Adapter and remove the battery immediately, taking care to avoid burns. Continued operation could result in injury. After removing or disconnecting the power source, take the equipment to a Nikon-authorized service representative for inspection.

⚠ Do not disassemble

Touching the internal parts of the camera or Charging AC Adapter could result in injury. Repairs should be performed only by qualified

technicians. Should the camera or Charging AC Adapter break open as the result of a fall or other accident, take the product to a Nikon-authorized service representative for inspection, after unplugging the product and/or removing the battery.

⚠ Do not use the camera or Charging AC Adapter in the presence of flammable gas

Do not use electronic equipment in the presence of flammable gas, as this could result in explosion or fire.

⚠ Handle the camera strap with care

Never place the strap around the neck of an infant or child.

⚠ **Keep out of reach of children**

Particular care should be taken to prevent infants from putting the battery, brush, or other small parts into their mouths.

⚠ **Do not remain in contact with the camera, Charging AC Adapter, or AC adapter for extended periods while the devices are on or in use**

Parts of the devices become hot. Leaving the devices in direct contact with the skin for extended periods may result in low-temperature burns.

⚠ **Do not leave the product where it will be exposed to extremely high temperatures, such as in an enclosed automobile or in direct sunlight**

Failure to observe this precaution could cause damage or fire.

⚠ **Observe caution when handling the battery**

The battery may leak, overheat, or explode if improperly handled.

Observe the following precautions when handling the battery for use in this product:

- Before replacing the battery, turn the product off. If you are using the Charging AC Adapter/AC adapter, be sure it is unplugged.
- Use only a Rechargeable Li-ion Battery EN-EL19 (included). Charge the battery by using a camera that supports battery charging or by using a Battery Charger MH-66 (available separately). To charge the battery with the camera, use either Charging AC Adapter EH-70P (included) or the **Charge by computer** function.
- When inserting the battery, do not attempt to insert it upside down or backwards.
- Do not short or disassemble the battery or attempt to remove or break battery insulation or casing.
- Do not expose the battery to flame or to excessive heat.

- Do not immerse in or expose to water.
- Put the battery in a plastic bag before transporting it. Do not transport or store with metal objects such as necklaces or hairpins.
- The battery is prone to leakage when fully discharged. To avoid damage to the product, be sure to remove the battery when no charge remains.
- Discontinue use immediately should you notice any change in the battery, such as discoloration or deformation.
- If liquid from the damaged battery comes in contact with clothing or skin, rinse immediately with plenty of water.

 **Observe the following precautions when handling the Charging AC Adapter**

- Keep dry. Failure to observe this precaution could result in fire or electric shock.
- Dust on or near the metal parts of the plug should be removed with a dry cloth. Continued use could result in fire.

- Do not handle the plug or go near the Charging AC Adapter during lightning storms. Failure to observe this precaution could result in electric shock.
- Do not damage, modify, forcibly tug or bend the USB cable, place it under heavy objects, or expose it to heat or flames. Should the insulation be damaged and the wires become exposed, take it to a Nikon-authorized service representative for inspection. Failure to observe these precautions could result in fire or electric shock.
- Do not handle the plug or Charging AC Adapter with wet hands. Failure to observe this precaution could result in electric shock.
- Do not use with travel converters or adapters designed to convert from one voltage to another or with DC-to-AC inverters. Failure to observe this precaution could damage the product or result in overheating or fire.

⚠ Use appropriate cables

When connecting cables to the input and output jacks, use only the cables provided or sold by Nikon for the purpose, to maintain compliance with product regulations.

⚠ Handle moving parts with care

Be careful that your fingers or other objects are not pinched by the lens cover or other moving parts.

⚠ Observe caution when using the flash

Using the flash close to your subject's eyes could cause temporary visual impairment. The flash should be no less than 1 m (3 ft 4 in.) from the subject. Particular care should be observed when photographing infants.

⚠ Do not operate the flash with the flash window touching a person or object

Failure to observe this precaution could result in burns or fire.

⚠ Avoid contact with liquid crystal

Should the monitor break, care should be taken to avoid injury caused by broken glass and to prevent liquid crystal from the monitor touching the skin or entering the eyes or mouth.

⚠ Turn the power off when using inside an airplane or the hospital

Turn the power off while inside the airplane during take off or landing. Follow the instructions of the hospital when using while in a hospital.

The electromagnetic waves emitted by this camera may disrupt the electronic systems of the airplane or the instruments of the hospital.

Notices

Notice for Customers in the U.S.A.

IMPORTANT SAFETY INSTRUCTIONS -

SAVE THESE INSTRUCTIONS.

DANGER - TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS

For connection to a supply not in the U.S.A., use an attachment plug adapter of the proper configuration for the power outlet if needed. The power supply unit is intended to be correctly orientated in a vertical or floor mount position.

Federal Communications Commission (FCC) Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This

equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.



Nikon
COOLPIX S32

CAUTIONS

Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Nikon Corporation may void the user's authority to operate the equipment.

Interface Cables

Use the interface cables sold or provided by Nikon for your equipment. Using other interface cables may exceed the limits of Class B Part 15 of the FCC rules.

Notice for customers in the State of California

WARNING

Handling the cord on this product will expose you to lead, a chemical known to the State of California to cause birth defects or other reproductive harm.

Wash hands after handling.

Nikon Inc.,
1300 Walt Whitman Road Melville,
New York 11747-3064 USA
Tel: 631-547-4200

Notice for customers in Canada

CAN ICES-3 B / NMB-3 B

Notice for Customers in Europe

CAUTIONS

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

This symbol indicates that electrical and electronic equipment is to be collected separately.



The following apply only to users in European countries:

- This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- Separate collection and recycling helps conserve natural resources and prevent negative consequences for human health and the environment that might result from incorrect disposal.
- For more information, contact the retailer or the local authorities in charge of waste management.

This symbol on the battery indicates that the battery is to be collected separately.



The following apply only to users in European countries:

- All batteries, whether marked with this symbol or not, are designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- For more information, contact the retailer or the local authorities in charge of waste management.

<Important> Shockproof, Waterproof, Dustproof, Condensation

- Make sure to read the following instructions as well as the instructions provided in "Caring for the Product" (2).

Notes About Shockproof Performance

This camera has passed Nikon's in-house test (drop test from a height of 1.5 m (5 ft) on a 5 cm (2 in.) thick plywood panel) compliant with MIL-STD 810F Method 516.5-Shock*.

This test does not guarantee the waterproof performance of the camera or that the camera will be free from damage or trouble under all conditions.

Changes in appearance, such as paint peeling off and deformation of the drop shock portion are not subject to the Nikon's in-house test.

- * U.S. Department of Defense test method standard.

This drop test drops 5 cameras in 26 directions (8 edges, 12 corners, and 6 faces) from a height of 122 cm (48 in.) to make sure that one to five cameras pass the test (if any defect is detected during the test, another five cameras are tested to make sure that the test criteria are satisfied for one to five cameras).

● Do not subject the camera to excessive shock, vibration or pressure by dropping or hitting it.

Failure to observe this precaution could cause water to seep inside the camera and result in camera malfunction.

- Do not use the camera deeper than 10 m (33 ft) underwater.
- Do not subject the camera to water pressure by exposing it to high-pressure running water.
- Do not sit down with the camera in the pocket of your trousers.
Do not forcibly stuff the camera into a bag.

Notes About Waterproof and Dustproof Performances

The camera is equivalent to IEC/JIS waterproof grade 8 (IPX8) and IEC/JIS dustproof grade 6 (IP6X) and enables shooting pictures underwater at a depth of 10 m (33 ft) for up to 60 minutes.*


This rating does not guarantee the waterproof performance of the camera or that the camera will be free from damage or trouble under all conditions.

* This rating indicates that the camera has been designed to withstand the specified water pressure for the specified period of time when the camera is used according to the methods defined by Nikon.

● If the camera is subjected to excessive shock, vibration or pressure by dropping or hitting it, the waterproof performance is not guaranteed.

- If the camera is exposed to shocks, it is recommended to consult your retailer or Nikon-authorized service representative to confirm the waterproof performance (charged service).
 - Do not use the camera deeper than 10 m (33 ft) underwater.
 - Do not subject the camera to water pressure by exposing it to rapid flowing water or waterfalls.
 - Your Nikon warrantee may not cover troubles caused by water seeping inside the camera due to improper handling of the camera.
- The waterproof performance of this camera is designed to work for fresh water and seawater only.
- The inner portion of this camera is not waterproof. Water seeping inside the camera could cause a malfunction.
- Accessories are not waterproof.
- If liquids or water droplets come into contact with the outside of the camera or the inside of the battery-chamber/memory card slot cover, immediately wipe the liquids off with a soft dry cloth. Do not insert wet memory cards or the battery.
If the battery-chamber/memory card slot cover is opened or closed under wet conditions near a waterfront or underwater, this could cause water to seep inside the camera or result in camera malfunction.
- Do not open or close the cover with wet hands. This could cause water to seep inside the camera or result in camera malfunction.

- If a foreign substance adheres to the outside of the camera or the inside of the battery-chamber/memory card slot cover (such as the hinge, memory card slot, and connectors), remove it immediately with a blower. If a foreign substance adheres to the waterproof packing inside the battery-chamber/memory card slot cover, remove it with the included brush. Do not use the included brush for anything other than cleaning the waterproof packing.
- If a foreign substance such as suntan oil, sunscreen lotion, hot spring, bath mix powder, detergent, soap, organic solvent, oil, or alcohol adheres to the camera, immediately wipe it off.
- Do not leave the camera in high-temperature conditions of 40°C (104°F) or more (in particular, a place exposed to direct sunlight, inside the cabin of a car, on a boat, on the beach, or near a heating device) for a long period of time. This could cause deterioration of the waterproof performance.



Before Using the Camera Underwater

1. Make sure that there are no foreign substances inside the battery-chamber/memory card slot cover.

- Any foreign substances such as sand, dust or hair inside the battery-chamber/memory card slot cover should be removed with a blower.
- Any liquid such as water droplets inside the battery-chamber/memory card slot cover should be wiped off with a soft dry cloth.

2. Make sure that the waterproof packing (□ 2) of the battery-chamber/memory card slot cover is not cracked or deformed.

- The waterproof performance of waterproof packing may start to deteriorate after one year.
If the waterproof packing begins to deteriorate, consult your retailer or Nikon-authorized service representative.

3. Make sure that the battery-chamber/memory card slot cover is firmly closed.

- Slide the cover until it clicks into place.

Notes About Using the Camera Underwater

Observe the following precautions to prevent water from seeping inside the camera.

- Do not dive into water deeper than 10 m (33 ft) with the camera.
- Do not continuously use the camera underwater for 60 minutes or more.
- Use the camera in the water temperature range 0°C–40°C (32°F–104°F) when using it underwater.
Do not use the camera at hot springs.
- Do not open or close the battery-chamber/memory card slot cover underwater.
- Do not subject the camera to shock when using it underwater.
Do not jump into water with the camera or subject it to high water pressure conditions such as rapids or waterfalls.
- This camera does not float in water. Make sure not to drop the camera underwater.

Cleaning After Using the Camera Underwater


- After using the camera underwater, clean the camera within 60 minutes. If you leave the camera in wet conditions where salt particles or other foreign substances adhere to it, this could cause damage, discoloration, corrosion, a bad smell or deterioration of waterproof performance.
- Before cleaning the camera, thoroughly remove water droplets, sand, salt particles, or other foreign substances from your hands, body, and hair.
- It is recommended to clean the camera indoors to avoid a place where it could be exposed to water spray or sand.
- Do not open the battery-chamber/memory card slot cover until all foreign substances are washed off with water and all moisture is wiped off.

1. Keep the battery-chamber/memory card slot cover closed and wash off the camera with fresh water.

Lightly rinse the camera with tap water, or immerse the camera in a shallow basin filled with freshwater for about 10 minutes.

- If the buttons or switches do not operate properly, foreign substances may have adhered to the camera.

Foreign substances can cause the camera to malfunction; wash the camera thoroughly.



2. Wipe off water droplets with a soft cloth and dry the camera in the well-ventilated and shady place.

- Place the camera on a dry cloth to dry it.

Water will flow out from openings in the microphone or speakers.

- Do not dry the camera with hot air from a hair dryer or clothes dryer.
- Do not use chemicals (such as benzine, thinner, alcohol, or cleanser), soap, or neutral detergents.

If the waterproof packing or body of the camera becomes deformed, the waterproof performance will deteriorate.

3. After making sure that there are no water droplets on the camera, open the battery-chamber/memory card slot cover, gently wipe off any water remaining inside the camera with a dry soft cloth, and use the blower to remove any foreign substances.

- If you open the cover before the camera is thoroughly dried, water droplets may fall on the memory card or battery.
The water droplets may also seep inside the battery-chamber/memory card slot cover (in locations such as waterproof packing, hinges, memory card slot, or terminals). If that happens, wipe the water off with a dry soft cloth.
- If the cover is closed when the inside is wet, this could cause condensation or malfunction.
- If the microphone or speaker openings are clogged with water droplets, the sound may deteriorate or become distorted.
 - Wipe the water off with a dry soft cloth.
 - Do not puncture the microphone or speaker openings with a sharp implement. If the inside of the camera is damaged, the waterproof performance will deteriorate.


Notes About Operating Temperature and Humidity and Condensation

The operation of this camera has been tested at temperatures -10°C – $+40^{\circ}\text{C}$ (14°F – 104°F). When you use the camera in cold climate regions, observe the following precautions. Keep the camera and spare batteries in a warm place before use.

- The performance of the batteries (number of pictures shot and shooting time) will drop temporarily.
- If the camera is in a very cold state, the performance may drop temporarily, for example, the monitor may be darker than normal immediately after the camera is turned on or residual images may be produced.
- When snow or water droplets adhere to the exterior of the camera, immediately wipe them off.
 - If the buttons or switches are frozen, they may not operate smoothly.
 - If the microphone or speaker openings are clogged with water droplets, the sound may deteriorate or become distorted.

● Operating environmental conditions such as temperature and humidity may cause fogging (condensation) on the inside of the monitor, lens, or flash window.

This is not a camera malfunction or defect.



● Environmental conditions that are likely to cause condensation inside of the camera

Fogging (condensation) may occur on the inside of the monitor, lens, or flash window in the following environmental conditions where there are sharp temperature changes or high humidity.

- The camera is suddenly immersed in low temperature underwater from high temperature on land.
- The camera is moved from a cold place to a warm place, such as inside a building.
- The battery-chamber/memory card slot cover is open or closed in a high-humidity environment.

● Clearing the fogging

- Open the battery-chamber/memory card slot cover after turning off the camera in a place where the ambient temperature is stable (avoid any place that has high temperature/high humidity, sand or dust).

To clear the fogging, remove the battery and memory card, and leave the camera with the battery-chamber/memory card slot cover open to allow the camera to adjust to the ambient temperature.

- If the fogging does not clear, consult your retailer or Nikon-authorized service representative.

Table of Contents

Introduction	ii
Read This First	ii
Confirming the Package Contents	ii
About This Manual	iii
Information and Precautions	v
For Your Safety	viii
WARNINGS	viii
Notices	xii
<Important> Shockproof, Waterproof, Dustproof, Condensation	xv
Notes About Shockproof Performance	xv
Notes About Waterproof and Dustproof Performances	xvi
Before Using the Camera Underwater	xvii
Notes About Using the Camera Underwater	xviii
Cleaning After Using the Camera Underwater	xviii
Notes About Operating Temperature and Humidity and Condensation	xxi
Parts of the Camera	1
The Camera Body	1
Attaching the Camera Strap	3
The Monitor	4
Shooting Mode	4
Playback Mode	5
Using the Flexible Buttons	6
The Basics of Shooting and Playback	8
Preparation 1 Insert the Battery	8
Preparation 2 Charge the Battery	10
Preparation 3 Insert a Memory Card	12
Internal Memory and Memory Cards	13
Preparation 4 Setting the Display Language, Date, and Time	14
Step 1 Turn the Camera On	18
Step 2 Frame a Picture	20
Using the Zoom	21
Step 3 Focus and Shoot	22
The Shutter-release Button	23
Step 4 Play Back Images	24
Step 5 Delete Images	25
Restrict Image Deletion (Image Lock)	27
Shooting Features	28
Functions Available in Shooting Mode (Shooting Menu)	28
■ Point and Shoot	30
Using the Flash	31
Using the Self-timer	33
Using the Smile Timer	35
Choose a Style (Shooting Suited to Scenes and Effects)	37
Tips and Notes	38
Decorate	43
Change Colors	44
Change Sounds	47


Choose a Size.....	49
Choose a Photo Size.....	49
Choose a Movie Frame Size.....	50
Functions That Cannot Be Used Simultaneously.....	51
Focusing.....	53
Using Face Detection.....	53
Using Skin Softening.....	54
Subjects Not Suitable for Autofocus.....	54
Focus Lock.....	55
Playback Features.....	56
Playback Zoom.....	56
Thumbnail Playback.....	57
Functions Available in Playback Mode (Playback Menu).....	58
Recording and Playing Back Movies....	60
Recording Movies.....	60
Playing Back Movies.....	63
General Camera Setup.....	65
Camera Settings Menu.....	65
Connecting the Camera to a TV, Computer, or Printer	67
Connection Methods.....	67
Using ViewNX 2.....	69
Installing ViewNX 2.....	69
Transferring Images to the Computer	70
Viewing Images.....	72

Reference Section	601
Have Fun with Pictures.....	602
Exchange Messages.....	602
Leave a Message	602
Leave a Reply	604
Play Recordings	605
Erase Recordings.....	605
Picture Play.....	607
Before Editing Images	607
<input checked="" type="checkbox"/> Make Photo Albums.....	608
<input checked="" type="checkbox"/> Add a Fisheye Effect	609
<input checked="" type="checkbox"/> Toy Camera	610
<input checked="" type="checkbox"/> Soften Pictures.....	611
<input checked="" type="checkbox"/> Add Starbursts.....	611
<input checked="" type="checkbox"/> Add a Diorama Effect.....	612
<input checked="" type="checkbox"/> Change Colors.....	613
<input checked="" type="checkbox"/> Highlight Colors.....	614
<input checked="" type="checkbox"/> Decorate	615
Grading	616
Grade Pictures	616
View Graded Pictures.....	618
Remove All Grades	619
View	620
<input checked="" type="checkbox"/> View by Date.....	620
<input checked="" type="checkbox"/> Slide Show.....	621
Choose Pictures.....	621
Choose a Theme	625
<input checked="" type="checkbox"/> View Movie.....	626

Settings.....	27
<input checked="" type="checkbox"/> Retouch.....	27
Copy.....	27
Rotate Pictures.....	30
Small Picture.....	31
Print Order.....	32
Camera Settings.....	34
Welcome Screen.....	34
Date and Time.....	35
Brightness.....	36
Print Date.....	37
Electronic VR.....	38
AF Assist.....	39
Format Memory/Format Card.....	40
Language.....	41
Menu Background.....	41
Video Mode.....	42
Charge by Computer.....	43
Reset All.....	44
Firmware Version.....	44
Connections.....	45
Connecting the Camera to a TV.....	45
Connecting the Camera to a Printer...	47
Connecting the Camera to a Printer...	48
Printing Individual Images.....	50
Printing Multiple Images.....	52
Additional Information.....	55
Error Messages.....	55
File Names.....	58
Optional Accessories.....	59
Technical Notes and Index	1
Caring for the Product.....	2
The Camera.....	2
The Battery.....	5
Charging AC Adapter.....	6
Memory Cards.....	7
Cleaning and Storage.....	8
Cleaning.....	8
Storage.....	9
Troubleshooting	10
Specifications	18
Approved Memory Cards.....	23
Index.....	26



Parts of the Camera

The Camera Body



1	Shutter-release button	22
2	Power switch/power-on lamp	18
3	Flash	31
4	Self-timer lamp	33
	AF-assist illuminator	65



5	● (CAM movie-record) button	60
6	Eyelet for camera strap	3
7	Speaker	64
8	Microphone (stereo)	60
9	Lens (with protective glass)	



1	Flexible buttons	6, 28, 58
2	Monitor	4
3	Charge lamp	11
	Flash lamp	32
4	Multi selector ▲: telephoto	21
	▼: wide-angle	21
5	◀ (shooting/playback mode) button	24
6	Battery-chamber/ memory card slot cover	8, 12
7	USB/audio/video output connector	67
8	Battery chamber	8
9	Memory card slot	12
10	HDMI micro connector (Type D)	67
11	Waterproof packing	xvi, xvii
12	Tripod socket	20

Attaching the Camera Strap


Pass the strap through either the left or right strap eyelet and attach the strap.



The Monitor


The information that is displayed in the monitor during shooting and playback changes depending on the camera's settings and state of use.

Shooting Mode



1	Flexible icons.....	6	11	Image lock icon.....	27
2	"Date not set" indicator.....	14, 65	12	Zoom indicator.....	21
3	Shutter speed.....	23	13	Shooting mode.....	30, 37
4	Aperture value.....	23	14	Movie recording time remaining.....	60
5	Flash mode.....	31	15	Number of exposures remaining (still images).....	18, 50
6	Change colors icon.....	44	16	Internal memory indicator.....	18
7	Self-timer indicator.....	33	17	Focus indicator.....	22
8	Smile timer.....	35	18	Focus area.....	22
9	Shoot at intervals icon.....	39	19	Focus area (face detection).....	22
10	Battery level indicator.....	18			

Playback Mode



1	Flexible icons.....	6
2	Date of recording	14
3	Time of recording.....	14
4	Message (reply).....	58,  4
5	Message	58,  2
6	Crop indicator.....	56
7	Battery level indicator.....	18
8	Charging AC Adapter connection indicator	
9	Image lock icon.....	27
10	Volume indicator.....	64
11	Switch to full-frame	57
12	Playback mode	58
13	Movie/message recording time	
14	Current image number	
15	Internal memory indicator	13
16	Grade mark	58,  16

If Information Is Not Displayed During Shooting Mode and Playback Mode


Apart from certain information, information is not displayed if no operations are performed for several seconds. Information is displayed again when either a flexible button or the multi selector is pressed.

Using the Flexible Buttons


If you press a flexible button while the shooting screen or playback screen is displayed, the menu for the current mode is displayed. Once the menu is displayed, you can change various settings.

In this document, the flexible buttons are referred to as "flexible button 1" through "flexible button 4", in order from top to bottom.

Shooting mode




Playback mode




Selecting Items

- To select an item, press the flexible button next to it.
- When  is displayed, press flexible button 1 to return to the previous screen.



- When the menu content continues on another page, a guide indicating the page position is displayed.

Press the multi selector  to display other pages.



Use  to display other pages.

To select an item, press the flexible button next to the item.

The last setting selected (including the default setting) is displayed in white.


Notes About Setting Menu Options

Some menu options cannot be selected depending on how the camera is set up. These options are displayed in gray.

The Basics of Shooting and Playback

Preparation 1 Insert the Battery


1 Open the battery-chamber/memory card slot cover.



2 Insert the battery.

- Push the orange battery latch in the direction indicated by the arrow (①), and fully insert the battery (②).
- The battery locks into place when inserted correctly.

Battery latch




Be Careful to Insert the Battery in Correct Direction

Inserting the battery upside down or backwards could damage the camera.



3 Close the battery-chamber/memory card slot cover.

- Lay the cover completely flat in the direction indicated by the arrow (①), and fully slide it in (②).



Damage Caution


Sliding the cover while it is open may damage the camera.



Removing the Battery

Turn the camera off and make sure that the power-on lamp and the monitor have turned off, and then open the battery-chamber/memory card slot cover.

Move the battery latch in the direction indicated by the arrow (①) to eject the battery (②).



High Temperature Caution

The camera, battery, and memory card may be hot immediately after using the camera.


Opening and Closing the Battery-chamber/Memory Card Slot Cover

Do not open and close the battery chamber/memory card slot cover in a sandy or dusty environment or with wet hands. If the cover is closed without removing foreign particles, water may seep inside the camera or the camera may become damaged.


- If foreign particles get inside the cover or camera, immediately remove them with a blower or brush.
- If liquid such as water gets inside the cover or camera, immediately wipe it off with a soft and dry cloth.

Preparation 2 Charge the Battery

1 Turn off the camera and open the battery-chamber/memory card slot cover.



2 Prepare the included Charging AC Adapter.




If a plug adapter* is included with your camera, attach the plug adapter to the plug on the Charging AC Adapter. Push the plug adapter firmly until it is securely held in place. Once the two are connected, attempting to forcibly remove the plug adapter could damage the product.

* The shape of the plug adapter varies according to the country or region in which the camera was purchased.

The Charging AC Adapter comes with the plug adapter attached in Argentina and Korea.

3 Make sure the battery is installed in the camera, and then connect the camera to the Charging AC Adapter in order of ① to ③.

- Keep the camera turned off.
- Make sure that the plugs are properly oriented. Do not insert or remove the plugs at an angle when connecting or disconnecting them.



- The charge lamp slowly flashes green to indicate that the battery is charging.
- Shooting is not possible while the camera is connected to the Charging AC Adapter.

Charge lamp	Description
Flashes slowly (green)	The battery is charging.
Off	When charging is complete, the charge lamp stops flashing green and turns off. About 2 hours and 35 minutes are required to charge a fully exhausted battery.
Flashes quickly (green)	<ul style="list-style-type: none">• The ambient temperature is not suited to charging. Charge the battery indoors with an ambient temperature of 5°C to 35°C (41°F to 95°F).• The USB cable or Charging AC Adapter is not properly connected, or there is a problem with the battery. Disconnect the USB cable or unplug the Charging AC Adapter and correctly connect it again, or change the battery.

4 Disconnect the Charging AC Adapter from the electrical outlet and then disconnect the USB cable.




Charging Using a Computer or Battery Charger

- You can also charge the battery by connecting the camera to a computer (67, 43).
- You can use the Battery Charger MH-66 (available separately; 59) to charge the battery without using the camera.

Preparation 3 Insert a Memory Card


- 1 Turn off the camera and open the battery-chamber/memory card slot cover.



- 2 Insert the memory card.

- Slide the memory card in until it clicks into place.

Memory card slot




 **Be Careful to Insert the Memory Card in Correct Direction**

Inserting the memory card upside down or backwards could damage the camera and the memory card.



3 Close the battery-chamber/memory card slot cover.

- Lay the cover completely flat in the direction indicated by the arrow (①), and fully slide it in (②).



Damage Caution

Sliding the cover while it is open may damage the camera.




Formatting Memory Cards

The first time you insert a memory card that has been used in another device into this camera, make sure to format it with this camera. Insert the card into the camera and select **Format card** in the camera settings menu.

Removing Memory Cards

Turn the camera off and make sure that the power-on lamp and the monitor have turned off, and then open the battery-chamber/memory card slot cover.

Gently push the memory card into the camera (①) to partially eject the card (②).



High Temperature Caution

The camera, battery, and memory card may be hot immediately after using the camera.

Internal Memory and Memory Cards


Camera data, including images and movies, can be saved either in the camera's internal memory or on a memory card. To use the camera's internal memory, first remove the memory card.

Preparation 4 Setting the Display Language, Date, and Time


When the camera is turned on for the first time, the language-selection screen, the date and time setting screen for the camera clock, and the menu background setting screen are displayed.

- If you exit without setting the date and time,  will flash when the shooting screen is displayed.


1 Press the power switch to turn on the camera.



2 Use the multi selector to select the desired language and press flexible button 4 (OK).




3 Press flexible button 3 (○ Yes).




4 Use flexible button 2, 3, or 4 to select the date format.

- Select **Y/M/D Year/Month/Day, M/D/Y Month/Day/Year, or D/M/Y Day/Month/Year**.




5 Set the date and time, and press flexible button 4 (OK).

- Select a field: Press **◀▶** (changes between **D, M, Y, h, and m**).
- Edit the date and time: Press **▲▼**.
- Apply the setting: Select **m** and press flexible button 4 (**OK**).
- To enable daylight saving time, press flexible button 3 (**⌚**). When the daylight saving time function is enabled, **⌚** is displayed in the monitor. To turn off the daylight saving time function, press flexible button 3 (**⌚**) again.




6 Press flexible button 3 (O Yes).




7 Use **◀▶** to select the background image to be displayed when a menu or setting screen is displayed, and press flexible button 4 (**OK**).

- To restore the default background image, press flexible button 3 (**RESET**).




8 Confirm the waterproofing-related message and press **▶**.

- There are six message screens.



9 Confirm the message on the screen shown at right and press flexible button 4 (**OK**).

- The monitor changes to the shooting screen (18).



Changing the Language Setting, the Date and Time Setting, and the Menu Background Setting

- You can change the **Language, Date and time**, and **Menu background** settings in the  camera settings menu (□ 65).
- You can enable or disable daylight saving time in the  camera settings menu by selecting **Date and time**. When enabled, the clock moves forward one hour; when disabled, the clock moves back one hour.

The Clock Battery

- The camera's clock is powered by a built-in backup battery. The backup battery charges when the main battery is inserted into the camera or when the camera is connected to an optional AC adapter, and it can run the clock for several days after about ten hours of charging.
- If the camera's backup battery becomes exhausted, the date and time setting screen is displayed when the camera is turned on. Set the date and time again. → Step 3 of "Preparation 4 Setting the Display Language, Date, and Time" (□ 14)


Imprinting the Shooting Date on Printed Images

- You can permanently imprint the shooting date on images as they are captured by setting **Print date** in the camera settings menu (□ 65).
- If you want the shooting date to be printed without using the **Print date** setting, print using the ViewNX 2 software (□ 69).

Step 1 Turn the Camera On

1 Press the power switch.


- The monitor turns on.
- To turn the camera off, press the power switch again.



2 Check the battery level indicator and the number of exposures remaining.

Battery level indicator

Display	Description
	The battery level is high.
	The battery level is low.
Battery exhausted.	The camera cannot capture images. Recharge the battery.




Number of exposures remaining

Number of Exposures Remaining

The number of images that can be taken is displayed.

- **[IN]** is displayed when no memory card is inserted in the camera, and images are saved in the internal memory.

The Auto Off Function





- The time that elapses before the camera enters standby mode is about three minutes.
- While the camera is in standby mode, the monitor turns back on if you perform any of the following operations:
 - Press the power switch, shutter-release button, **■** (shooting/playback mode) button, or **●** (■ movie-record) button

Step 2 Frame a Picture

1 Hold the camera steady.

- Keep fingers and other objects away from the lens, flash, AF-assist illuminator, microphone, and speaker.



2 Frame the picture.



When Using a Tripod

We recommend using a tripod to stabilize the camera in the following situations.

- When shooting in dim lighting
- When shooting with the flash mode (31) set to  **Flash off**
- When using the telephoto setting

Using the Zoom

When you press the multi selector **▲▼**, the zoom lens position changes.

- To zoom in closer to the subject: Press **▲** (telephoto)
- To zoom out and view a larger area: Press **▼** (wide-angle)


When you turn the camera on, the zoom moves to the maximum wide-angle position.

- A zoom indicator is displayed in the monitor when the multi selector **▲▼** is pressed.



Zoom indicator

- If you press **▲** when the camera is zoomed in to the maximum optical zoom position, you can use the digital zoom to magnify the image further by up to about 4x.



Maximum optical zoom

Digital zoom enabled

Digital Zoom and Interpolation


While using digital zoom, the image quality decreases due to interpolation depending on the image size and the amount of digital zoom magnification.

When using digital zoom, we recommend reducing the image size in  **Photo size** under  **Choose a size** in order to minimize image deterioration (49).

Step 3 Focus and Shoot

1 Press the shutter-release button halfway.

- When the subject is in focus, the focus area glows green (multiple focus areas can glow green).
- When you are using digital zoom, the camera focuses on the subject in the center of the frame and the focus area is not displayed. When the camera has focused, the focus indicator (4) glows green.
- If the focus area or focus indicator flashes, the camera is unable to focus. Modify the composition and try pressing the shutter-release button halfway again.



2 Without lifting your finger, press the shutter-release button the rest of the way down.



The Shutter-release Button

Press halfway



To set focus and exposure (shutter speed and aperture value), press the shutter-release button lightly until you feel a slight resistance. Focus and exposure remain locked while the shutter-release button is pressed halfway.

Press all the way



Press the shutter-release button all the way to release the shutter and take an image.

Do not use force when pressing the shutter-release button, as this may result in camera shake and blurred images. Press the button gently.


✓ Notes About Saving Images and Recording Movies

The indicator showing the number of exposures remaining or the indicator showing the maximum movie length flashes while images are being saved or while a movie is being recorded. **Do not open the battery-chamber/memory card slot cover or remove the battery or memory card** while an indicator is flashing. Doing this could result in loss of data, or in damage to the camera or the memory card.

Step 4 Play Back Images


1 Press the **▶** (shooting/playback mode) button.

- If you press and hold down the **▶** (shooting/playback mode) button while the camera is turned off, the camera turns on in playback mode.



2 Use the multi selector to select an image to display.

- Press and hold down **◀▶** to scroll through the images quickly.
- To return to shooting mode, press the **▶** (shooting/playback mode) button or shutter-release button.




Step 5 Delete Images

1 Display the image you want to delete in the monitor and then press flexible button 3 (>Delete).




2 Use flexible button 2, 3, or 4 to select the deletion method.

- Select **Delete this picture only**, **Erase selected pictures** (26), or **ALL Erase all pictures**.
- To exit without deleting, press flexible button 1 (Exit).



3 Press flexible button 3 (Yes).


- Deleted images cannot be recovered.
- To exit without deleting, press flexible button 4 (No).



Selecting Which Images You Want to Delete

1 Use the multi selector  to select an image to be deleted, and then press flexible button 2 (✓).

- The selected image is indicated by a check mark.
- A check mark is displayed or removed every time you press flexible button 2 (✓).
- Press flexible button 3 (RESET) to remove all check marks.




2 Add check marks to all images that you want to delete and press flexible button 4 (OK) to confirm the selection.

- A confirmation dialog is displayed. Follow the instructions displayed in the monitor.

Restrict Image Deletion (Image Lock)


To prevent accidental deletion of images, you can lock image deletion (25) and formatting (65, 40).

- 1 Press and hold down flexible buttons 1 and 4 at the same time while in shooting mode or playback mode.



- 2 Press flexible button 3 (O Yes).

- Image lock is set.
- When image lock is set,  is displayed in the monitor.



Removing Image Lock

The procedure for removing image lock is the same as for setting image lock.

Shooting Features

Functions Available in Shooting Mode (Shooting Menu)

Press a flexible button to display a menu. You can change the following settings.

Flexible button	Option	Description	
 Point and shoot	–	Sets the shooting mode to  Point and shoot.	30
 Flash mode/ self-timer	Flash	Allows you to set the flash mode.	31
	Self-timer	The camera is equipped with a self-timer that releases the shutter about ten seconds after you press the shutter-release button. You can also set the smile timer.	33, 35
 More picture options	Choose a style	Allows you to select the scene settings and effects used for shooting.	37
	Decorate	Allows you to add a frame around your images when taking images.	43
	Change colors	Allows you to select  Brighter/darker or  More vivid/less vivid from the menu, or use  Highlight colors to keep one specified color in the image, and change the other colors to black and white.	44

Flexible button	Option	Description	
 Settings	Change sounds	Allows you to configure the shutter and button sounds.	47
	Choose a size	Allows you to set the size of photos (still images) and movies.	49
	Camera settings	Allows you to change a number of general settings.	65

Point and Shoot

When this camera is used for the first time, the shooting mode is set to  Point and shoot. The camera automatically selects the optimum scene when you frame an image, making it even easier to take images using settings that suit the scene.

 Point and shoot is the default shooting mode for this camera.

- The area of the frame that the camera focuses on varies depending on the composition of the image.
- When the camera detects a human face, it focuses on that face ( 53). The skin softening feature makes the skin tones in human faces appear smoother ( 54).
- The flash may fire when shooting in low light.
- When shooting in low light, the use of a tripod is recommended.
- The camera does not detect the scene when the digital zoom is being used.

Notes About Motion Detection

In  Point and shoot and **Shoot close-ups** ( 38), when the camera detects subject movement or camera shake, ISO sensitivity and shutter speed are increased to reduce blurring.

Using the Flash

You can select the flash mode to match the shooting conditions.

Enter shooting mode → flexible button 2 (⌚) → flexible button 2 (⚡ Flash)

Available Flash Modes

⌚ AUTO Auto flash

The flash fires when necessary, such as in dim lighting.

⌚ Flash off

The flash does not fire.


- We recommend using a tripod to stabilize the camera when shooting in dark surroundings.

⚡ Always fire flash

The flash fires whenever an image is taken. Use to “fill-in” (illuminate) shadows and backlit subjects.

Use flexible button 2, 3, or 4 to select the flash mode.

- Select ⌚ AUTO Auto flash, ⌚ Flash off, or ⚡ Always fire flash.
- To cancel, press flexible button 1 (⌚).






The Flash Lamp

The status of the flash can be confirmed by pressing the shutter-release button halfway.

- On: The flash fires when you press the shutter-release button all the way down.
- Flashing: The flash is charging. The camera cannot shoot images.
- Off: The flash does not fire when an image is taken.

If the battery level is low, the monitor turns off while the flash is charging.



The Flash Mode Setting

- The setting may not be changed when using some shooting modes or settings.
- The setting applied in Point and shoot is saved in the camera's memory even after the camera is turned off.


Using the Self-timer

The camera is equipped with a self-timer that releases the shutter about ten seconds after you press the shutter-release button.

Enter shooting mode → flexible button 2 (⌚) → flexible button 3 (⌚ Self-timer)


1 Press flexible button 2 (10s 10 s).

- When **⌚ Smile timer** is selected, the camera uses face detection to detect a human face, and then automatically releases the shutter when a smile is detected (35).



2 Frame the picture and press the shutter-release button halfway.

- Focus and exposure are set.



3 Press the shutter-release button the rest of the way down.

- Countdown starts. The self-timer lamp flashes and then glows steadily about one second before the shutter is released.
- When the shutter is released, the self-timer is set to **OFF off**.
- To stop the countdown, press the shutter-release button again.




Using the Smile Timer

When the camera detects a smiling face, you can take an image automatically without pressing the shutter-release button. The skin softening function makes the skin tones of human faces smoother.

Enter shooting mode → flexible button 2 (⌚) → flexible button 3 (⌚ Self-timer)

1 Press flexible button 3 (⌚ Smile timer).



2 Frame the picture.

- Point the camera at a human face.

3 Without pressing the shutter-release button, wait for the subject to smile.

- If the camera detects that the face framed by the double border is smiling, the shutter is automatically released.
- Whenever the camera detects a smiling face, it automatically releases the shutter.

4 End automatic shooting.

- To end automatic shooting, set the self-timer to **OFF off**.



Notes About Smile Timer

Under some shooting conditions, the camera may be unable to detect faces or detect smiles (53). The shutter-release button can also be used for shooting.



When the Self-timer Lamp Flashes

When using smile timer, the self-timer lamp flashes when the camera detects a face and flashes quickly immediately after the shutter is released.


Choose a Style (Shooting Suited to Scenes and Effects)

When a style (shooting scenes and effects) is selected, camera settings are automatically optimized for the selected scene. The expected effect may not be achieved depending on the subject.

Enter shooting mode → flexible button 3 (SCENE) → flexible button 2 (SCENE) Choose a style

Use the multi selector  to select the desired style (shooting scene and effect) and press flexible button 4 (OK).

- To cancel, press flexible button 1 ().



 Shoot night scenes ¹ (38) (default setting)	 Shoot close-ups ^{2, 3} (38)
 Photograph food ² (38)	 Shoot at intervals (39)
 Shoot under water ^{2, 3} (39)	 Take a series of pictures (40)
 Photograph fireworks ^{1, 4} (40)	 Shoot backlit scenes ⁵ (40)
 Mirror ^{2, 3} (41)	 Add a bubble effect ^{2, 3} (41)
 Add a neon effect ^{2, 3} (41)	 Add a cartoon effect ^{2, 3} (42)
 Take soft pictures ^{2, 3} (42)	 Create a diorama effect ^{2, 3} (42)

1 The camera focuses at infinity.

2 The camera focuses on the area in the center of the frame. When the zoom is set to a position where the zoom indicator turns green, the camera can focus on subjects as close as about 20 cm (8 in.) from the front of the protective glass, or about 5 cm (2 in.) at the maximum wide-angle position.

3 The flash may be unable to light the entire subject at distances of less than 30 cm (1 ft).

4 Use of a tripod is recommended, because the shutter speed is slow.

5 The camera focuses on the area in the center of the frame.

Tips and Notes

Shoot night scenes

- When the shutter-release button is pressed all the way, the camera captures a series of images which are combined into a single image and saved.
- Once the shutter-release button is pressed all the way, hold the camera still until a still image is displayed. After taking an image, do not turn the camera off before the monitor switches to the shooting screen.
- The angle of view (i.e., the area visible in the frame) seen in the saved image is narrower than that seen in the monitor at the time of shooting.
- The flash setting is fixed at  **Flash off** (31).
- The self-timer can be set, but  **Smile timer** is not available (33, 35).

Shoot close-ups

- The camera automatically zooms to the closest position at which it can focus.
- The flash is set to  **Flash off**, but the setting can be changed (31).
- The self-timer can be set, but  **Smile timer** is not available (33, 35).

Photograph food

- The camera automatically zooms to the closest position at which it can focus.
- Use the multi selector  to adjust the hue setting and press flexible button 4 . The hue setting is saved in the camera's memory even after the camera is turned off.
- The flash setting is fixed at  **Flash off** (31).
- The self-timer can be set, but  **Smile timer** is not available (33, 35).

⌚ Shoot at intervals

- The camera can automatically capture still images at pre-determined intervals. Images captured in one shooting are saved in one folder and can be viewed in a slide show (58).
- Press flexible button 2 (**30s Shoot every 30 seconds**), flexible button 3 (**1m Shoot once a minute**), or flexible button 4 (**5m Shoot every 5 minutes**) to set the shooting interval.
- The maximum number of images that can be captured depends on the selected interval.
 - **Shoot every 30 seconds**: Approx. 280 images
 - **Shoot once a minute**: Approx. 140 images
 - **Shoot every 5 minutes**: Approx. 30 images
- Use a sufficiently charged battery to prevent the camera from turning off during shooting.
- Press the shutter-release button all the way down to capture the first image. In between each shot, the monitor turns off and the power-on lamp flashes. The monitor automatically turns on again just before the next image is captured.
- Press the shutter-release button halfway to stop shooting.
- The flash is set to **AUTO Auto flash**, but the setting can be changed (31).
- The self-timer is not available (33).

⌚ Shoot under water

- When **Shoot under water** is set, the waterproofing-related messages are displayed. Confirm each message and press the multi selector **▶** to display the next message. Press flexible button 4 (**OK**) to skip the messages and change to the shooting screen.
- See “<Important> Shockproof, Waterproof, Dustproof, Condensation” (15 xv-xxi) for more information about using the camera underwater.
- The flash is set to **Flash off**, but the setting can be changed (31).
- The self-timer can be set, but **Smile timer** is not available (33, 35).

Take a series of pictures

- The camera captures a series of still images that allow you to clearly see detailed movements in a moving subject.
- While the shutter-release button is held all the way down, the camera shoots up to 11 images continuously at a rate of about 4.7 frames per second (fps) (when **Choose a size** > **Photo size** is set to  **Large (13 megapixels)**).
- The frame rate for continuous shooting may vary depending upon the current photo size setting, the memory card used, or shooting condition.
- Focus, exposure, and hue are fixed at the values determined with the first image in each series.
- The flash setting is fixed at  **Flash off** (31).
- The self-timer is not available (33).

Photograph fireworks

- The shutter speed is fixed at about four seconds.
- The flash setting is fixed at  **Flash off** (31).
- The self-timer is not available (33).

Shoot backlit scenes

- When taking images with very bright and dark areas in the same frame, such as backlit scenes, the high dynamic range (HDR) compositing is applied and loss of details in highlights or shadows is minimized.
- When the shutter-release button is pressed all the way, the camera shoots images continuously at high speed, and saves the following two images.
 - A non-HDR composite image
 - An HDR composite image in which the loss of details in highlights or shadows is minimized
- If there is only enough memory to save one image, an image processed at the time of shooting, in which dark areas of the image are corrected, is the only image saved.
- Once the shutter-release button is pressed all the way, hold the camera still until a still image is displayed. After taking an image, do not turn the camera off before the monitor switches to the shooting screen.
- The angle of view (i.e., the area visible in the frame) seen in the saved image is narrower than that seen in the monitor at the time of shooting.
- The flash setting is fixed at  **Flash off** (31).
- The self-timer can be set, but  **Smile timer** is not available (33, 35).

⌚ Mirror

- You can take images that are vertically or horizontally symmetrical over the center of the frame.
- Press flexible button 2 (⌚ **Top → bottom**) or flexible button 3 (⌚ **Left → right**) to set the flip direction.

When ⌚ **Top → bottom** is selected, the top half of the screen is flipped over the bottom half, and the image is composited and displayed. When ⌚ **Left → right** is selected, the left half of the screen is flipped over the right half.

- The flash is set to **⌚ AUTO Auto flash**, but the setting can be changed (⌚ 31).
- The self-timer can be set, but ⌚ **Smile timer** is not available (⌚ 33, 35).

⌚ Add a bubble effect

- This effect makes the image appear to be projected on a bubble.
- A guide is displayed in the monitor. Compose the shot so that the main subject is contained within the guide.
- The flash setting is fixed at **⌚ AUTO Auto flash**, but the setting can be changed (⌚ 31).
- The self-timer can be set, but ⌚ **Smile timer** is not available (⌚ 33, 35).

⌚ Add a neon effect

- This effect makes the outlines of the image appear to glow with neon tubing.
- Use the multi selector **◀▶** to select the outline color and press flexible button 4 (**OK**). The color setting is saved in the camera's memory even after the camera is turned off.
- After taking an image, do not turn the camera off before the monitor switches to the shooting screen.
- The flash setting is fixed at **⌚ AUTO Auto flash**, but the setting can be changed (⌚ 31).
- The self-timer can be set, but ⌚ **Smile timer** is not available (⌚ 33, 35).

Add a cartoon effect

- Performs tone compensation and makes the image appear like a cartoon.
- After taking an image, do not turn the camera off before the monitor switches to the shooting screen.
- The flash setting is fixed at **AUTO Auto flash**, but the setting can be changed (31).
- The self-timer can be set, but  **Smile timer** is not available (33, 35).

Take soft pictures

- Softens the image by adding a slight blur to areas outside of the guide displayed in the monitor.
- A guide is displayed in the monitor. Compose the shot so that the main subject is contained within the guide.
- The flash is set to **AUTO Auto flash**, but the setting can be changed (31).
- The self-timer can be set, but  **Smile timer** is not available (33, 35).

Create a diorama effect

- This effect is well-suited for images captured from a high vantage point with the main subject in the center of the image.
- A guide is displayed in the monitor. Compose the shot so that the main subject is contained within the guide.
- The flash is set to **Flash off**, but the setting can be changed (31).
- The self-timer can be set, but  **Smile timer** is not available (33, 35).

Decorate


You can add a frame around your images when taking images. Nine different frames are available.

Enter shooting mode → flexible button 3 (SCENE) → flexible button 3 (Decorate)

- The **Choose a size** > **Photo size** setting is fixed at **Small (2 megapixels)** (49).

1 Use the multi selector **◀▶** to select the desired frame and press flexible button 4 (OK).

- To cancel, press flexible button 1 ().
- You can press flexible button 3 () to remove the frame.



2 Frame the subject and take a picture.

Notes About Decorate

- The area that is captured becomes smaller when a thicker frame is selected.
- When using borderless printing to print images that you have added frames to, the frames may not be printed.


Change Colors

You can adjust brightness (exposure compensation) and vividness when taking images. You can also select one color to keep in your images and turn the rest of the colors to shades of black and white. See 46 for details on each effect.

Enter shooting mode → flexible button 3 (SCENE) → flexible button 4 (Change colors)

1 Use flexible button 2, 3, or 4 to select the setting.

- Select Brighter/darker, More vivid/less vivid, or Highlight colors.




2 Use the multi selector  to select the brightness, vividness, or to select the color you want to highlight.

- The screen displayed when Brighter/darker is selected in step 1 is used here as an example.
- Press flexible button 3 (RESET) to turn the effect off.



3 Press flexible button 4 (OK).
• To cancel, press flexible button 1 (D).



4 Frame the subject and take a picture.

Notes About Change Colors


- The setting is saved in the camera's memory even after the camera is turned off.
- Images adjusted with **Change colors** are indicated by .



☒ Brighter/Darker (Exposure Compensation)

You can adjust overall image brightness.


- Use **◀** to move the cursor to the left to make the overall image darker. Use **▶** to move the cursor to the right to make it brighter.



◆ More Vivid/Less Vivid (Saturation)

You can adjust the overall vividness of the image.


- Use **◀** to move the cursor to the left to make the overall image more dull. Use **▶** to move the cursor to the right to make it more vivid.



❖ Highlight Colors

You can create a black and white image in which only the specified color remains.

- Use **◀▶** to move the cursor and select the color to highlight.



Change Sounds

Allows you to configure the shutter and button sounds. You can select one of eight different sounds, or turn sounds off.

Enter shooting mode → flexible button 4 (选拍) → flexible button 2 (♪ Change sounds)

选拍 Pick a shutter sound

Allows you to select the sound heard when the shutter is released and when the focus has been locked.

When using **Take a series of pictures** (40) or when recording movies, the shutter sound is not heard.

- If you select , the shutter sound and the sound heard when the focus has been locked are muted.

♪ Pick a button sound

Allows you to select the beep heard when the camera switches between shooting and playback modes, when using the menus, when the camera is connected to a computer or printer, etc.


- Regardless of this setting, sounds that are heard when an error occurs and when the camera is turned on do not change.
- If you select , button sounds and the sounds heard when an error occurs and when the camera is turned on are muted.

♪ Turn sounds on or off

Turn all sounds on or off. When the mute is canceled after muting sounds once, the shutter sound and button sound used before muting will be used again.

1 Press flexible button 2 or flexible button 3.

-  **Pick a shutter sound**: Set the shutter sound.
-  **Pick a button sound**: Set the button sound.




2 Use the multi selector  to select the type of sound.

-  Set the standard sounds.
-  Sounds are not heard.
- Press flexible button 3 (▶) to play the selected sound.
- To cancel, press flexible button 1 (◀).
- The screen displayed when  **Pick a shutter sound** was selected in step 1 is shown here as an example, but the procedure is the same if you select  **Pick a button sound**.



3 Press flexible button 4 (OK).

- The sound is set.



Muting All Sounds

On the screen displayed in step 1, press flexible button 4 ( **Turn sounds on or off**) → flexible button 3 ( **Turn sounds off**), in that order, to mute all sounds.

To cancel the mute, press flexible button 4 ( **Turn sounds on or off**) → flexible button 2 ( **Turn sounds on**), in that order.

Choose a Size

Set the size of photos (still images) and movies.

Choose a Photo Size

Select the combination of image size and compression ratio that is used when saving images. The higher the image mode setting, the larger the size at which images can be printed, and the lower the compression ratio, the higher the quality of the images, but the number of images that can be saved is reduced.

Enter shooting mode → flexible button 4 (Ψ) → flexible button 3 (Fn Choose a size) → flexible button 2 (CAM Photo size)

Option*	Size* (pixels)	Compression ratio	Aspect ratio (horizontal to vertical)
■ Large (13 megapixels) (default setting)	4160 × 3120	Approx. 1:4	4:3
■ Medium (4 megapixels)	2272 × 1704	Approx. 1:8	4:3
■ Small (2 megapixels)	1600 × 1200	Approx. 1:8	4:3

* The total number of pixels captured, and the number of pixels captured horizontally and vertically.
Example: ■ **Large (13 megapixels)** = approx. 13 megapixels, 4160 × 3120 pixels

Setting the Photo Size

- This setting also applies to **Choose a style** and **Change colors**.
- The setting may not be changed when using certain settings of other functions.

Number of Images That Can Be Saved

- The approximate number of images that can be saved can be checked in the monitor when shooting (LCD 18).
- Note that due to JPEG compression, the number of images that can be saved may vary greatly depending on the image content, even when using memory cards with the same capacity and the same photo size setting. In addition, the number of images that can be saved may vary depending on the make of the memory card.
- If the number of exposures remaining is 10,000 or more, the number of exposures remaining display shows "9999".

Choose a Movie Frame Size

Select the desired movie option to record.

Enter shooting mode → flexible button 4 (Ψ) → flexible button 3 (Fn Choose a size) → flexible button 3 (Movie frame size)

Option	Image size	Aspect ratio (horizontal to vertical)	Frame rate
 Large (1080p) (default setting) ¹	1920 × 1080	16:9	Approx. 30 fps
 Small (640)	640 × 480	4:3	Approx. 30 fps
 Small (old-fashioned) ²	640 × 480	4:3	Approx. 15 fps

- When no memory card is inserted (i.e., when using the camera's internal memory), you can select  **Small (640)** or  **Small (old-fashioned)**.
- Allows you to record movies with an atmosphere and hue similar to movies shot on old 8mm film.

Functions That Cannot Be Used Simultaneously

Some functions cannot be used with other menu options.

Restricted function	Option	Description
Flash	Choose a style (37)	When Shoot night scenes , Photograph food , Take a series of pictures , Photograph fireworks , or Shoot backlit scenes is selected, the flash cannot be used.
Self-timer	Choose a style (37)	When Shoot at intervals , Take a series of pictures , or Photograph fireworks is selected, the self-timer cannot be used.
Smile timer	Choose a style (37)	When any option in Choose a style is enabled, Smile timer cannot be used.
	Highlight colors (46)	When Highlight colors is enabled, Smile timer cannot be used.
Decorate	Smile timer (35)	When Smile timer is selected, Decorate cannot be used.
	Choose a style (37)	When any option in Choose a style is enabled, Decorate cannot be used.
Change colors	Smile timer (35)	When Smile timer is selected, Change colors cannot be used.
	Choose a style (37)	When any option in Choose a style is enabled, Change colors cannot be used.
Pick a shutter sound	Take a series of pictures (40)	When Take a series of pictures is selected, the shutter sound is disabled.
Photo size	Decorate (43)	When Decorate is selected, the Photo size setting is fixed at Small (2 megapixels) .
Print date	Take a series of pictures (40)	When Take a series of pictures is selected, the date cannot be imprinted on images.

Restricted function	Option	Description
Electronic VR	Choose a style (37)	When Shoot night scenes , Shoot at intervals , Take a series of pictures , Photograph fireworks , or Shoot backlit scenes is selected, electronic VR is disabled.
Digital zoom	Smile timer (35)	When Smile timer is selected, digital zoom cannot be used.
	Choose a style (37)	When Shoot night scenes , Shoot under water , Shoot backlit scenes , Take soft pictures , or Create a diorama effect is selected, digital zoom cannot be used.

Focusing

The focus area varies depending on the shooting mode and settings.

Using Face Detection

In the following shooting modes and settings, the camera uses face detection to automatically focus on human faces.

- **Point and shoot** (30)
- **Shoot at intervals** (39) and **Take a series of pictures** (40) when using **Choose a style**
- **Smile timer** (35)



If the camera detects more than one face, a double border is displayed around the face that the camera focuses on, and single borders are displayed around the other faces.

If no faces are detected when the shutter-release button is pressed halfway, the camera focuses on the subject in the center of the frame.

Notes About Face Detection

- The camera's ability to detect faces depends on a variety of factors, including the direction in which the faces are looking.
- The camera may be unable to detect faces in the following situations:
 - When faces are partially hidden by sunglasses or otherwise obstructed
 - When faces take up too much or too little of the frame

Using Skin Softening

When the shutter is released while using one of the shooting modes and settings listed below, the camera detects human faces and processes the image to soften facial skin tones (up to three faces).

-  **Point and shoot** (□ 30)
- **Smile timer** (□ 35)

Notes About Skin Softening

- It may take more time than usual to save images after shooting.
- Under some shooting conditions, the desired skin softening results may not be achieved, and skin softening may be applied to areas of the image where there are no faces.

Subjects Not Suitable for Autofocus

The camera may not focus as expected in the following situations. In some rare cases, the subject may not be in focus despite the fact that the focus area or the focus indicator glows green:

- Subject is very dark
- Objects of sharply differing brightness are included in the scene (e.g. the sun behind the subject makes that subject appear very dark)
- No contrast between the subject and surroundings (e.g. a portrait subject wearing a white shirt is standing in front of a white wall)
- Several objects are at different distances from the camera (e.g. the subject is inside a cage)
- Subjects with repeating patterns (window blinds, buildings with multiple rows of similarly shaped windows, etc.)
- Subject is moving rapidly


In the situations noted above, try pressing the shutter-release button halfway to refocus several times, or focus on another subject positioned at the same distance from the camera as the actual desired subject, and use focus lock (□ 55).

Focus Lock

Focus lock shooting is recommended when the camera does not activate the focus area that contains the desired subject. The following explains how to use focus lock when  Point and shoot is enabled and the focus area is displayed in the center of the frame.


1 Position the subject in the center of the frame and press the shutter-release button halfway.

- Confirm that the focus area glows green.
- Focus and exposure are locked.



2 Without lifting your finger, recompose the picture.

- Make sure to maintain the same distance between the camera and the subject.



3 Press the shutter-release button the rest of the way down to take the picture.



Playback Features

Playback Zoom

Pressing the multi selector **▲** in full-frame playback mode (24) zooms in on the image.



Image is displayed full-frame.




Image is zoomed in.

Displayed area guide

- You can change the zoom ratio by pressing **▲▼**.
- To view a different area of the image, press flexible button 3 (a) to lock the zoom ratio and press **▲▼↔**.
If you want to change the zoom ratio, press flexible button 3 (a) and then change the zoom ratio as desired.
- If you are viewing an image that was captured using face detection, the camera zooms in on the face detected at the time of shooting (except when viewing an image size smaller than 320 x 240). To zoom in on an area of the image where there are no faces, press flexible button 3 (a) and then press **▲**.
- When a zoomed image is displayed, press flexible button 1 (X) to return to full-frame playback mode.

8 Crop: Creating a Cropped Copy


When using playback zoom, you can crop the image and save the displayed area of the image as a separate file by pressing flexible button 4 (8).

Thumbnail Playback

Press the multi selector ▼ in full-frame playback mode (24) to display images in contact sheets of thumbnail images.



Full-frame Playback



Thumbnail Playback

- While using thumbnail playback mode, press **◀▶** to select an image, and the selected image is magnified and displayed at the center of the screen. Select an image and press **▲**, and the selected image is displayed in the full-frame playback mode.

Functions Available in Playback Mode (Playback Menu)

When viewing images in full-frame playback mode, you can select one of the flexible buttons (6) and display the corresponding menu.

Playback menu	Option	Description	
 Have fun with pictures	Exchange messages ¹	Allows you to add voice messages to your images.	 2
	Picture play ¹	Allows you to edit your images using a variety of functions.	 7
	Grading	Allows you to add grade marks to your images. You can play back only images that have grade marks. Protects selected images from accidental deletion.	 16
 View	View by date	Allows you to play back images by selecting the shooting date from the calendar.	 20
	Slide show	Allows you to view images in an automatic slide show.	 21
	View movie ²	Allows you to play back movies (63).	 63

Playback menu	Option	Description	
Erase	Erase this picture only	Allows you to delete only the image currently displayed (25).	25
	Erase selected pictures	Allows you to select multiple images and delete them (26).	26
	Erase all pictures	Allows you to delete all images (25).	25
Settings	Retouch	Allows you to copy or rotate images or create a small copy of the current image.	27
	Print order	Allows you to specify the image to be printed and the number of copies to be printed.	32
	Camera settings	Allows you to change a number of general settings (65).	34

1 Available when a still image is displayed.

2 Available when a movie is displayed.

Recording and Playing Back Movies

Recording Movies

When no memory card is inserted (i.e., when using the camera's internal memory), the movie frame size (50) can be set to **Small (640)** or **Small (old-fashioned)**.


1 Display the shooting screen.

- Check the remaining amount of movie recording time.



2 Press the ● (movie-record) button to start movie recording.

- The camera focuses on the subject in the center of the frame.



3 Press the ● (movie-record) button again to end recording.

✓ Maximum Movie Length

Individual movie files cannot exceed 4 GB in size or 29 minutes in length, even when there is sufficient free space on the memory card for longer recording.

- The maximum movie length for a single movie is displayed on the shooting screen.
- Recording may end before either limit is reached if camera temperature becomes elevated.
- The actual movie length may vary depending on the movie content, subject movement, or type of memory card.

✓ Notes About Saving Movies

After a movie has been recorded, it is not fully saved to the internal memory or memory card until monitor display returns to the shooting display. **Do not open the battery-chamber/memory card slot cover or remove the battery or memory card.** Removing the memory card or the battery while a movie is being saved may result in loss of the movie data or damage to the camera or to the memory card.

✓ Notes About Movie Recording

- Memory cards with an SD Speed Class rating of 6 or faster are recommended when recording movies (23). Movie recording may stop unexpectedly when memory cards with a lower Speed Class rating are used.
- When recording movies while **Electronic VR** (65, 38) in the camera settings is set to **Auto**, the angle of view (i.e., the area visible in the frame) is narrow compared to that of still images.
- The optical zoom ratio cannot be changed once recording starts.
- There may be some degradation in image quality when digital zoom is used.
- The sounds of multi selector operation, autofocus lens drive movement, and aperture operation when brightness changes may be recorded.
- The following phenomena may be seen in the monitor while recording movies. These phenomena are saved in the recorded movies.
 - Banding may occur in images under fluorescent, mercury-vapor, or sodium-vapor lighting.
 - Subjects that move quickly from one side of the frame to the other, such as a moving train or car, may appear skewed.
 - The entire movie image may be skewed when the camera is panned.
 - Lighting or other bright areas may leave residual images when the camera is moved.
- Depending on the distance to the subject or the amount of zoom applied, subjects with repeating patterns (fabrics, lattice windows, etc.) may have colored stripes (interference patterns, moire, etc.) in them during movie recording and playback. This occurs when the pattern in the subject and the layout of the image sensor interfere with each other; it is not a malfunction.

✓ Camera Temperature


- The camera may become warm when shooting movies for an extended period of time or when the camera is used in a hot area.
- If the inside of the camera becomes extremely hot when recording movies, the camera will automatically stop recording.
The amount of time remaining until the camera stops recording (10s) is displayed.
After the camera stops recording, it turns itself off.
Leave the camera off until the inside of the camera has cooled.

✓ Notes About Autofocus

Autofocus may not perform as expected (54). Should this occur, try the following:
Frame another subject—positioned at the same distance from the camera as the intended subject—in the center of the frame, press the ● (movie-record) button to start recording, and then modify the composition.


Playing Back Movies

- 1 Press the **▶** (shooting/playback mode) button to switch to playback mode.
- 2 Use the multi selector **◀▶** to select the desired movie and press flexible button 2 (■).
 - Movies can be identified by the movie recording time indicator (5).



- 3 Press flexible button 4 (■ View movie).


- You can play movies.



Functions Available During Playback

You can use the flexible buttons to perform the following operations.

Paused



During playback

Volume indicator

Function	Icon	Description
Advance	⌚	Hold down the button to advance the movie.
Rewind	⏪	Hold down the button to rewind the movie.
Pause	⏸	Pause playback. The operations listed below can be performed while paused.
		⌚ Advance the movie one frame. Hold down the button for continuous advancing.
		⏪ Rewind the movie one frame. Hold down the button for continuous rewinding.
		▶ Resume playback.
End	✗	Return to full-frame playback mode.

Adjusting Volume

Press the multi selector $\blacktriangle\blacktriangledown$ during playback.

Deleting movies

To delete a movie, select the desired movie in full-frame playback mode (24) and press flexible button 3 (25).

General Camera Setup

Camera Settings Menu

Enter shooting mode or playback mode → flexible button 4 (MENU) → flexible button 4 (CAMERA SETTINGS) (CAMERA SETTINGS)

The settings of the menu options listed below can be configured.


Option	Description	Page
Welcome screen	Allows you to select whether or not the welcome screen is displayed when the camera is turned on.	34
Date and time	Allows you to set the camera clock.	35
Brightness	Allows you to adjust the brightness of the monitor.	36
Print date	Allows you to imprint the shooting date on images.	37
Electronic VR	Allows you to choose whether to use electronic VR (vibration reduction) when shooting.	38
AF assist	Allows you to enable or disable the AF-assist illuminator.	39
Format memory/ Format card	Allows you to format the internal memory or the memory card.	40
Language	Allows you to change the camera's display language.	41
Menu background	Allows you to change the background used on the menu screen.	41
Video mode	Allows you to adjust TV-connection settings.	42
Charge by computer	Allows you to set whether or not the battery in the camera is charged when the camera is connected to a computer.	43

Option	Description	
Reset all	Allows you to reset the camera's settings to their default values.	 44
Firmware version	View the current camera firmware version.	 44

Connecting the Camera to a TV, Computer, or Printer

Connection Methods

You can enhance your enjoyment of images and movies by connecting the camera to a TV, computer, or printer.



- Before connecting the camera to an external device, make sure the remaining battery level is sufficient and turn the camera off. Before disconnecting, make sure to turn the camera off.
- If the AC Adapter EH-62G (available separately) is used, this camera can be powered from an electrical outlet. Do not use any other make or model of AC adapter as it may cause the camera to heat up or malfunction.
- For information about the connection methods and subsequent operations, refer to the documentation included with the device in addition to this document.

Viewing images on a TV

6845



Images and movies captured with the camera can be viewed on a TV.
Connection method: Connect the video and audio (stereo) plugs of the optional audio video cable to the TV's input jacks. Alternatively, connect a commercially available HDMI cable to the TV's HDMI input jack.

Viewing and organizing images on a computer

68 69



You can transfer images to a computer to perform simple retouching and manage image data.

Connection method: Connect the camera to the computer's USB port with the USB cable.

- Before connecting to a computer, install ViewNX 2 on the computer (68 69).
- If any USB devices that draw the power from the computer are connected, disconnect them from the computer before you connect the camera to it. Connecting the camera and other USB-powered devices to the same computer simultaneously may cause a camera malfunction or excessive power supply from the computer, which could damage the camera or memory card.

Printing images without using a computer

6848



If you connect the camera to a PictBridge-compatible printer, you can print images without using a computer.

Connection method: Connect the camera directly to the printer's USB port with the USB cable.

Using ViewNX 2

Install ViewNX 2 to upload, view, edit, and share photos and movies.

Your Imaging Toolbox

ViewNX 2™



Installing ViewNX 2

An Internet connection is required.

For system requirements and other information, see the Nikon website for your region.

1 Download the ViewNX 2 installer.

Start the computer and download the installer from:

<http://nikonimlib.com/nvnx/>

2 Double-click the downloaded file.

3 Follow the on-screen instructions.

4 Exit the installer.

Click **Yes** (Windows) or **OK** (Mac).


Transferring Images to the Computer

1 Choose how images will be copied to the computer.

Choose one of the following methods:

- **Direct USB connection:** Turn the camera off and ensure that the memory card is inserted in the camera. Connect the camera to the computer using the USB cable. The camera automatically turns on.

To transfer images that are saved in the camera's internal memory, remove the memory card from the camera before connecting it to the computer.



- **SD card slot:** If your computer is equipped with an SD card slot, the card can be inserted directly in the slot.
- **SD card reader:** Connect a card reader (available separately from third-party suppliers) to the computer and insert the memory card.

If a message is displayed prompting you to choose a program, select Nikon Transfer 2.

- **When using Windows 7**

If the dialog shown at right is displayed, follow the steps below to select Nikon Transfer 2.

1 Under **Import pictures and videos**, click **Change program**. A program selection dialog will be displayed; select **Import File using Nikon Transfer 2** and click **OK**.

2 Double-click **Import File**.

If the memory card contains a large number of images, it may take a while for Nikon Transfer 2 to start. Wait until Nikon Transfer 2 starts.




✓ Connecting the USB Cable

The connection may not be recognized if the camera is connected to the computer via a USB hub.

2 Transfer images to the computer.

- Click **Start Transfer**.



- At default settings, all the images on the memory card will be copied to the computer.

3 Terminate the connection.

- If the camera is connected to the computer, turn the camera off and disconnect the USB cable. If you are using a card reader or card slot, choose the appropriate option in the computer operating system to eject the removable disk corresponding to the memory card, and then remove the card from the card reader or card slot.

Viewing Images

Start ViewNX 2.

- Images are displayed in ViewNX 2 when transfer is complete.
- Consult online help for more information on using ViewNX 2.



Starting ViewNX 2 Manually

- **Windows:** Double-click the **ViewNX 2** shortcut icon on the desktop.
- **Mac:** Click the **ViewNX 2** icon in the Dock.



Technical Notes and Index

Caring for the Product	2
The Camera.....	2
The Battery.....	5
Charging AC Adapter.....	6
Memory Cards	7
Cleaning and Storage	8
Cleaning	8
Storage	9
Troubleshooting	10
Specifications	18
Approved Memory Cards	23
Index	26
	1

Caring for the Product

The Camera

To ensure continued enjoyment of this Nikon product, observe the precautions described below in addition to the warnings in "For Your Safety" (☞ viii-xi) and "<Important> Shockproof, Waterproof, Dustproof, Condensation" (☞ xv-xxi) when using or storing the device.

Do Not Drop

The product may malfunction if subjected to strong shock or vibration. Additionally, do not touch or apply force to the lens.

Handle the Lens and All Moving Parts with Care

Do not apply force to the lens, lens cover, monitor, memory card slot, or battery chamber. These parts are easily damaged. Applying force to the lens cover could result in camera malfunction or damage to the lens. Should the monitor break, care should be taken to avoid injury caused by broken glass and to prevent the liquid crystal from the display touching the skin or entering the eyes or mouth.

Do Not Allow Damp to Enter Inside the Camera

This camera is provided with JIS/IEC protection class 8 (IPX8) equivalent waterproofing. If water seeps inside the camera, however, this could cause the components to rust and result in a high repair charge or the camera may not be repairable.

After using the camera at the beach or underwater, make sure that the battery-chamber/memory card slot cover is firmly closed, and then immerse the camera in a shallow container filled with freshwater for 10 minutes.

After using the camera underwater, do not leave the camera wet for 60 minutes or more. This could cause deterioration of the waterproofing performance.

✓ Prevent Water From Seeping Inside the Camera

If the inside of the camera becomes wet, this could result in camera malfunction and the camera may not be repairable. To prevent water seeping (water submersion) accidents, be sure to observe the following cautions when using the camera.

- When the battery-chamber/memory card slot cover is closed, make sure that the camera strap, hair, lint, dust, sand grains, other foreign substances, or dirt are not attached on the waterproofing packing and portions that make a contact with the waterproofing packing.
- Do not open or close the battery-chamber/memory card slot cover in areas exposed to water spray, high winds, dust or sand.
- When an external force is applied on the camera, it could become deformed or the airtight seals may become damaged and cause water to seep inside the camera. Do not place a heavy object on the camera, drop the camera, or apply excessive force on the camera.
- If water seeps inside the camera, immediately stop using the camera. Wipe off moisture from the camera, and at once take the camera to your Nikon-authorized service representative.

✓ Shock and Vibration

Do not drop the camera, strike it against a hard object such as a rock, or throw it at a water surface. Do not leave the camera in an area subject to vibration. If the camera is subjected to excessive shock, this could result in camera malfunction or damage.

✓ Maximum Depth

This camera is designed to withstand water pressure up to a depth of 10 m (33 ft) for approx. 60 minutes. At greater depth, water could seep inside the camera, resulting in camera malfunction.

✓ Avoid Sudden Changes in Temperature

- Sudden changes in temperature, such as when entering or leaving a heated building on a cold day, can cause condensation to form inside the device. To prevent condensation, place the device in a carrying case or a plastic bag before exposing it to sudden changes in temperature.
- Do not expose the camera to high temperatures by leaving it on the beach or in direct sunlight before entering the water.

Keep away from Strong Magnetic Fields

Do not use or store this device in the vicinity of equipment that generates strong electromagnetic radiation or magnetic fields. Strong static charge or the magnetic fields produced by equipment such as radio transmitters could interfere with the monitor, damage data saved on the memory card, or affect the product's internal circuitry.

Do Not Point the Lens at Strong Light Sources for Extended Periods

Avoid pointing the lens at the sun or other strong light sources for extended periods when using or storing the camera. Intense light may cause deterioration of the image sensor, producing a white blur effect in photographs.

Turn the Product off Before Removing or Disconnecting the Power Source

Do not remove the battery while the product is on, or while images are being saved or deleted. Forcibly cutting power in these circumstances could result in loss of data or in damage to product memory or internal circuitry.

Notes About the Monitor

- Monitors and electronic viewfinders are constructed with extremely high precision; at least 99.99% of pixels are effective, with no more than 0.01% being missing or defective. Hence while these displays may contain pixels that are always lit (white, red, blue, or green) or always off (black), this is not a malfunction and has no effect on images recorded with the device.
- Images in the monitor may be difficult to see under bright lighting.
- The monitor is lit by an LED backlight. Should the monitor begin to dim or flicker, contact your Nikon-authorized service representative.

The Battery

- Be sure to read and follow the warnings in "For Your Safety" (viii-xi) before use.
- Check the battery level before using the camera and replace or charge the battery if necessary. Do not continue charging once the battery is fully charged as this will result in reduced battery performance. Whenever possible, carry a fully charged spare battery when taking pictures on important occasions.
- Do not use the battery at ambient temperatures below 0°C (32°F) or above 40°C (104°F).
- Charge the battery indoors with an ambient temperature of 5°C to 35°C (41°F to 95°F) before use.
- When the battery temperature is between 45°C–55°C (113°F–131°F), the chargeable capacity may decrease.
- When charging the battery inserted into this camera using the Charging AC Adapter or a computer, the battery is not charged at ambient temperatures below 5°C (41°F) or above 55°C (131°F).
- Note that the battery may become hot during use; wait for the battery to cool before charging. Failure to observe these precautions could damage the battery, impair its performance, or prevent it from charging normally.
- On cold days, the capacity of batteries tends to decrease. If an exhausted battery is used at a low temperature, the camera will not turn on. Be sure that the battery is fully charged before heading outside to take pictures in cold weather. Keep spare batteries in a warm place and exchange as necessary. Once warmed, a cold battery may recover some of its charge.
- Dirt on the battery terminals can prevent the camera from functioning. Should the battery terminals become dirty, wipe them off with a clean, dry cloth before use.
- If the battery will not be used for some time, insert it in the camera and completely exhaust it before removing it for storage. The battery should be stored in a cool location with an ambient temperature of 15°C–25°C (59°F–77°F). Do not store the battery in hot or extremely cold locations.
- Always remove the battery from the camera or battery charger when it is not being used. When inserted, minute amounts of current are drawn from the battery even when not in use. This may result in excessive draining of the battery and complete loss of function. Turning the camera on or off while the battery is exhausted can result in reduced battery life.
- Recharge the battery at least once every six months and completely exhaust it before returning it to storage.

- After removing the battery from the camera or battery charger, put the battery in a plastic bag and store it in a cool place.
- A marked drop in the time a fully-charged battery retains its charge, when used at room temperature, indicates that the battery needs to be replaced. Purchase a new EN-EL19 battery.
- Replace the battery when it no longer holds a charge. Used batteries are a valuable resource. Please recycle used batteries in accordance with local regulations.

Charging AC Adapter

- Be sure to read and follow the warnings of "For Your Safety" (☞ viii-xi) thoroughly before using the battery charger.
- The Charging AC Adapter EH-70P is for use only with compatible devices. Do not use with another make or model of device.
- The EH-70P is compatible with AC 100-240 V, 50/60 Hz electrical outlets. When using in other countries, use a plug adapter (commercially available) as necessary. For more information about plug adapters, consult your travel agency.
- Do not, under any circumstances, use another make or model of AC adapter other than Charging AC Adapter EH-70P or USB-AC adapter. Failure to observe this precaution could result in overheating or in damage to the camera.

Memory Cards

- Use only Secure Digital memory cards. See “Approved Memory Cards” (⌚:23) for recommended memory cards.
- Observe the precautions noted in the documentation included with your memory card.
- Do not affix labels or stickers to the memory card.
- Do not format the memory card using a computer.
- The first time you insert a memory card that has been used in another device into this camera, be sure to format it with this camera. We recommend formatting new memory cards with this camera before using them with this camera.
- Note that ***formatting a memory card permanently deletes all images and other data on the memory card***. If there is data saved on the memory card that you wish to keep, copy that data to a computer before formatting.
- If the message **Card is not formatted. Format card?** is displayed when the camera is turned on, the memory card must be formatted. If there is data on the memory card that you do not want to delete, press flexible button 4 (**X No**). Copy that data to a computer before formatting. To format the memory card, press flexible button 3 (**O Yes**).
- Observe the following precautions while formatting the memory card, saving and deleting images, and copying images to a computer, otherwise data or the memory card itself may be damaged.
 - Do not open the battery-chamber/memory card slot cover to remove the battery or memory card.
 - Do not turn off the camera.
 - Do not disconnect the AC adapter.

Cleaning and Storage

Cleaning

Do not use alcohol, thinner, or other volatile chemicals.

Lens	Avoid touching glass parts with your fingers. Remove dust or lint with a blower (typically a small device with a rubber bulb attached to one end that is pumped to produce a stream of air out the other end). To remove fingerprints or other stains that cannot be removed with a blower, wipe the lens with a soft, dry cloth or an eyeglass cleaning cloth, using a spiral motion that starts at the center of them and working toward the edges. If this fails, clean the lens using a cloth lightly dampened with commercial lens cleaner.
Monitor	Remove dust or lint with a blower. To remove fingerprints and other stains, clean the monitor with a soft, dry cloth, being careful not to apply pressure.
Body	<p>Use a blower to remove dust, dirt, or sand, then wipe gently with a soft, dry cloth. After using the camera underwater or at the beach, gently wipe off any sand or salt with a soft cloth lightly dampened with fresh water and dry thoroughly.</p> <ul style="list-style-type: none">• If you handle the camera using hands where sunscreen lotion is applied, this could cause deterioration of the camera exterior. <p>Note that foreign matter inside the camera could cause damage not covered by the warranty.</p>



More Information

See "Notes About Waterproof and Dustproof Performances" (☞ xvi) and "Cleaning After Using the Camera Underwater" (☞ xviii) for more information.

Storage

Turn the camera off when not in use. Be sure that the power-on lamp is off before putting the camera away. Remove the battery if the camera will not be used for an extended period. Do not store the camera with naphtha or camphor moth balls, or in any of the following locations:

- Next to equipment that produces strong electromagnetic fields, such as televisions or radios
- Exposed to temperatures below –10°C (14°F) or above 50°C (122°F)
- Places that are poorly ventilated or subject to humidity of over 60%

To prevent mold or mildew, take the camera out of storage at least once a month. Turn the camera on and release the shutter a few times before putting the camera away again.

For storing the battery, follow the precautions in "The Battery" (D-5) in "Caring for the Product".

Troubleshooting

If the camera fails to function as expected, check the list of common problems below before consulting your retailer or Nikon-authorized service representative.

Power, Display, Settings Issues

Problem	Cause/Solution	
The camera is on but does not respond.	<p>Wait for recording to end.</p> <p>If the problem persists, turn the camera off.</p> <p>If the camera does not turn off, remove and reinsert the battery or batteries or, if you are using an AC adapter, disconnect and reconnect the AC adapter.</p> <p>Note that although any data currently being recorded will be lost, data that have already been recorded will not be affected by removing or disconnecting the power source.</p>	<p>–</p> <p>8, 18, 6659</p>
Battery inserted in the camera cannot be charged.	<ul style="list-style-type: none">Confirm all connections.When connected to a computer, the camera may not charge for any of the reasons described below.<ul style="list-style-type: none">- Off is selected for Charge by computer in the camera settings menu.- Battery charging stops if the camera is turned off.- Battery charging is not possible if the camera's display language and date and time have not been set, or the date and time were reset after the camera's clock battery was exhausted. Use the Charging AC Adapter to charge the battery.- Battery charging may stop if the computer is in sleep mode.- Depending upon the computer specifications, settings, and status, battery charging may not be possible.	<p>10</p> <p>65, 6643</p> <p>–</p> <p>14, 17</p> <p>–</p> <p>–</p>
Camera cannot be turned on.	The battery is exhausted.	18

Problem	Cause/Solution	Book
Camera turns off without warning.	<ul style="list-style-type: none"> The camera automatically turns off to save power (auto off function). The camera or battery have become too cold and cannot operate properly. The inside of the camera has become hot. Leave the camera off until the inside of the camera has cooled, and then try turning it on again. The camera turns off if the USB cable connecting it to a computer or printer is disconnected. Reconnect the USB cable. 	19 19 – 67, 70, 68, 48
Monitor is blank.	<ul style="list-style-type: none"> The camera is off. The battery is exhausted. The camera has entered standby mode to save power. Press the power switch, shutter-release button,  (shooting/playback mode) button, or  (movie-record) button. The flash lamp flashes while the flash is charging. Wait for the flash to charge. The camera and computer are connected via a USB cable. The camera and TV are connected via an audio/video cable or an HDMI cable. 	18 18 1, 19 32 67, 70 67, 68, 45
Monitor is hard to read.	<ul style="list-style-type: none"> Adjust the monitor brightness. The monitor is dirty. Clean the monitor. 	65, 66, 36 19
Date and time of recording are not correct.	<ul style="list-style-type: none"> If the camera clock has not been set,  flashes during shooting and movie recording. Images and movies saved before the clock is set are dated "00/00/0000 00:00" or "01.01.14 00:00" respectively. The shooting date and time of still images is not displayed during playback. Set the correct time and date using Date and time in the camera settings menu. The camera clock is not as accurate as ordinary watches or clocks. Periodically compare the time of the camera clock with that of a more accurate timepiece and reset as required. 	14, 65, 66, 35

Problem	Cause/Solution	
Print date not available.	Date and time in the camera settings menu has not been set.	14, 65, 66, 35
Date not imprinted on images even when Print date is enabled.	The date cannot be imprinted on movies and images captured using Take a series of pictures .	65, 66, 37
Screen for setting time and date is displayed when camera is turned on.	The clock battery is exhausted; all settings were restored to their default values.	14, 17
Camera settings reset.		
Cannot select Format memory or Format card .	You cannot format while image lock is set. Remove image lock.	27
Camera becomes hot.	The camera may become warm when shooting movies for an extended period of time or when the camera is used in a hot area; this is not a malfunction.	–
Camera makes sound.	Depending on the settings, the camera may produce an audible focusing sound.	–

Shooting Issues

Problem	Cause/Solution	
Cannot switch to shooting mode.	<ul style="list-style-type: none">Disconnect the HDMI cable or USB cable.The camera cannot be switched to shooting mode while connected to a power outlet via the Charging AC Adapter.	67, 70, 45, 48 10
No image captured when the shutter-release button is pressed.	<ul style="list-style-type: none">When the camera is in playback mode, press the  (shooting/playback mode) button or the shutter-release button.When menus are displayed, press the  (shooting/playback mode) button or the shutter-release button.The battery is exhausted.When the flash lamp is flashing, the flash is charging.	1, 24 1 18 32
Camera cannot focus.	<ul style="list-style-type: none">The subject is too close. Try moving away from the subject or setting Choose a style to Shoot close-ups.The subject is hard to focus on.Set AF assist in the camera settings menu to Auto.Turn the camera off and then on again.	38 54 65, 48 39 18
Images are blurred.	<ul style="list-style-type: none">Use the flash.Enable electronic VR.Use a tripod to stabilize the camera when shooting (using the self-timer at the same time is more effective).	31 65, 48 38 33
Bright specks appear in images captured with flash.	The flash is reflecting off particles in the air. Set the flash mode setting to Flash off .	31

Problem	Cause/Solution	
Flash does not fire.	<ul style="list-style-type: none"> The flash mode is set to  Flash off. Choose a style is set to a function that disables the flash. 	31 38
Digital zoom cannot be used.	When Choose a style is set to Shoot night scenes , Shoot under water , Shoot backlit scenes , Take soft pictures , or Create a diorama effect , digital zoom cannot be used.	38, 39, 40, 42
No sound when shutter is released.	<ul style="list-style-type: none"> Turn sounds on or off in Change sounds is set to Turn sounds off, or Pick a shutter sound is set to  in the shooting menu. Shutter sound is not heard when Choose a style is set to Take a series of pictures. Do not block the speaker. 	47 40 1
AF-assist illuminator does not light.	Off is selected for AF assist in the camera settings menu. AF-assist illuminator may not light depending on the current settings, even when Auto is selected.	65,  39
Images appear smeared.	The lens is dirty. Clean the lens.	 8
Colors are unnatural.	Hue is not adjusted properly.	38, 44
Randomly spaced bright pixels ("noise") appear in image.	The subject is dark, and the shutter speed is too slow or ISO sensitivity is too high. Noise can be reduced by using the flash.	31
Images are too dark (underexposed).	<ul style="list-style-type: none"> The flash mode is set to  Flash off. The flash window is blocked. The subject is beyond the range of the flash. Adjust exposure compensation. 	31 20  19 46
Images are too bright (overexposed).	Adjust exposure compensation.	46

Problem	Cause/Solution	
Saving images takes time.	<p>It may take more time to save images in the following situations.</p> <ul style="list-style-type: none"> When the noise reduction function is in operation, such as when shooting in a dark environment When the skin softening function is applied while shooting When Choose a style is set to Shoot night scenes, Take a series of pictures, Shoot backlit scenes, Add a neon effect, or Add a cartoon effect 	- 54 38, 40, 41, 42
A ring-shaped belt or rainbow-colored stripe appears in the monitor or images.	When shooting with backlighting or when a very strong light source (such as sunlight) is in the frame, a ring-shaped belt or rainbow-colored stripe (ghosting) may occur. Change the position of the light source, or frame the image so that the light source does not enter the frame, and try again.	-

Playback Issues

Problem	Cause/Solution	
File cannot be played back.	<ul style="list-style-type: none"> This camera may not be able to play back images saved with another make or model of digital camera. This camera cannot play back movies recorded with another make or model of digital camera. This camera may not be able to play back data edited on a computer. 	-
Cannot zoom in on image.	<ul style="list-style-type: none"> Playback zoom cannot be used with movies, and images with an image size of 160 × 120 or smaller. When viewing small images, the playback zoom ratio that is displayed may not match the actual image zoom ratio. This camera may not be able to zoom in on images captured with another make or model of digital camera. 	-
Cannot record messages.	<ul style="list-style-type: none"> Messages cannot be attached to movies. Messages cannot be attached to images captured with other cameras. 	- 58,  

Problem	Cause/Solution	Book
Cannot edit image.	<ul style="list-style-type: none"> Some images cannot be edited. Images that have already been edited may not be edited again. There is not enough free space in the internal memory or on the memory card. This camera is unable to edit images captured with other cameras. Editing functions used for images are not available for movies. 	43,  7,  9,  18,  20,  31 – – – –
Cannot rotate image.	This camera cannot rotate images captured with another make or model of digital camera.	–
Cannot delete image.	<ul style="list-style-type: none"> Images cannot be deleted while image lock is set. Remove image lock. Graded images are protected. Remove the grades. 	27 58,  17,  19
Images are not displayed on TV.	<ul style="list-style-type: none"> Video mode is not correctly set in the camera settings menu. The cables are connected to the HDMI micro connector (Type D) and to the USB/audio/video output connector simultaneously. The memory card contains no images. Replace the memory card. Remove the memory card to play back images from the internal memory. 	65,  42 67, 70,  45,  47 12
Nikon Transfer 2 does not start when camera is connected.	<ul style="list-style-type: none"> The camera is off. The battery is exhausted. The USB cable is not correctly connected. The camera is not recognized by the computer. The computer is not set to start Nikon Transfer 2 automatically. For more information about Nikon Transfer 2, refer to help information contained in ViewNX 2. 	18 18 67, 70 – 70

Problem	Cause/Solution	
The PictBridge startup screen is not displayed when the camera is connected to a printer.	With some PictBridge-compatible printers, the PictBridge startup screen may not be displayed and it may be impossible to print images when Auto is selected for the Charge by computer option in the setup menu. Set the Charge by computer option to Off and reconnect the camera to the printer.	65,  43
Images to be printed are not displayed.	<ul style="list-style-type: none"> The memory card contains no images. Replace the memory card. Remove the memory card to print images from the internal memory. 	12
Cannot select paper size with camera.	<p>The camera cannot be used to select the paper size in the following situations, even when printing from a PictBridge-compatible printer. Use the printer to select the paper size.</p> <ul style="list-style-type: none"> The printer does not support the paper sizes specified by the camera. The printer automatically selects the paper size. 	67,  51,  52 -

Specifications

Nikon COOLPIX S32 Digital Camera

Type	Compact digital camera
Number of effective pixels	13.2 million
Image sensor	1/3.1-in. type CMOS; approx. 14.17 million total pixels
Lens	NIKKOR lens with 3x optical zoom
Focal length	4.1–12.3 mm (angle of view equivalent to that of 30–90 mm lens in 35mm [135] format)
f-number	f/3.3–5.9
Construction	6 elements in 5 groups
Digital zoom magnification	Up to 4x (angle of view equivalent to that of approx. 360 mm lens in 35mm [135] format)
Vibration reduction	Electronic VR (movies)
Motion blur reduction	Motion detection (still pictures), electronic VR (still pictures)
Autofocus (AF)	Contrast-detect AF
Focus range	<ul style="list-style-type: none">• [W]: Approx. 30 cm (1 ft)–∞, [T]: Approx. 50 cm (1 ft 8 in.)–∞• Shoot close-ups, Photograph food, Shoot under water, Mirror, Add a bubble effect, Add a neon effect, Add a cartoon effect, Take soft pictures, Create a diorama effect, Highlight colors: Approx. 5 cm (2 in.) (wide-angle position)–∞ <p>(All distances measured from center of front surface of the protective glass)</p>
Focus-area selection	Center, face detection
Monitor	6.7 cm (2.7-in.), approx. 230k-dot, TFT LCD with anti-reflection coating and 5-level brightness adjustment
Frame coverage (shooting mode)	Approx. 96% horizontal and 96% vertical (compared to actual picture)
Frame coverage (playback mode)	Approx. 100% horizontal and 100% vertical (compared to actual picture)

Storage	
Media	Internal memory (approx. 25 MB), SD/SDHC/SDXC memory card
File system	DCF, Exif 2.3, and DPOF compliant
File formats	Still pictures: JPEG Voice messages: WAV Movies: MOV (Video: H.264/MPEG-4 AVC, Audio: LPCM stereo)
Image size (photo size)	<ul style="list-style-type: none"> 13 megapixels [4160 × 3120] 4 megapixels [2272 × 1704] 2 megapixels [1600 × 1200]
ISO sensitivity (Standard output sensitivity)	ISO 125–1600
Exposure	
Metering mode	Matrix, center-weighted (digital zoom less than 2×), spot (digital zoom 2× or more)
Exposure control	Programmed auto exposure and exposure compensation (-2.0 – +2.0 EV in steps of 1 EV)
Shutter	Mechanical and CMOS electronic shutter
Speed	<ul style="list-style-type: none"> 1/2000–1 s 4 s (Choose a style is set to Photograph fireworks)
Aperture	Electronically-controlled ND filter (-2 AV) selection
Range	2 steps (f/3.3 and f/6.6 [W])
Self-timer	Approx. 10 s, smile timer
Flash	
Range (approx.) (ISO sensitivity: Auto)	[W]: 0.3–3.1 m (1–10 ft) [T]: 0.6–1.7 m (2 ft–5 ft 6 in.)
Flash control	TTL auto flash with monitor preflashes
Interface	Hi-Speed USB
Data transfer protocol	MTP, PTP
Video output	Can be selected from NTSC and PAL
HDMI output	Automatically selected from 480p, 720p, and 1080i

I/O terminal	Audio/video (A/V) output; digital I/O (USB) HDMI micro connector (Type D) (HDMI output)
Supported languages	Arabic, Bengali, Bulgarian, Chinese (Simplified and Traditional), Czech, Danish, Dutch, English, Finnish, French, German, Greek, Hindi, Hungarian, Indonesian, Italian, Japanese, Korean, Marathi, Norwegian, Persian, Polish, Portuguese (European and Brazilian), Romanian, Russian, Serbian, Spanish, Swedish, Tamil, Telugu, Thai, Turkish, Ukrainian, Vietnamese
Power sources	<ul style="list-style-type: none"> One Rechargeable Li-ion Battery EN-EL19 (included) AC Adapter EH-62G (available separately)
Charging time	Approx. 2 h 35 min (when using Charging AC Adapter EH-70P and when no charge remains)
Battery life ¹	
Still pictures	Approx. 220 shots when using EN-EL19
Movies (actual battery life for recording) ²	Approx. 1 h 35 min when using EN-EL19
Tripod socket	1/4 (ISO 1222)
Dimensions (W × H × D)	Approx. 107.6 × 66.1 × 40.4 mm (4.3 × 2.7 × 1.6 in.) (excluding projections)
Weight	Approx. 175 g (6.2 oz) (including battery and SD memory card)
Operating environment	
Temperature	-10°C – +40°C (14°F–104°F) (for land use) 0°C–40°C (32°F–104°F) (for underwater use)
Humidity	85% or less (no condensation)
Waterproof	JIS/IEC protection class 8 (IPX8) equivalent (under our testing conditions) Capacity to shoot pictures underwater up to a depth of 10 m (33 ft) and for 60 minutes
Dustproof	JIS/IEC protection class 6 (IP6X) equivalent (under our testing conditions)
Shockproof	Cleared our testing conditions ³ compliant with MIL-STD 810F Method 516.5-Shock

- Unless otherwise stated, all figures assume a fully-charged battery and an ambient temperature of $23 \pm 3^\circ\text{C}$ ($73.4 \pm 5.4^\circ\text{F}$) as specified by the Camera and Imaging Products Association (CIPA).
 - 1 Battery life may vary depending on conditions of use, such as the interval between shots or the length of time that menus and images are displayed.
 - 2 Individual movie files cannot exceed 4 GB in size or 29 minutes in length. Recording may end before this limit is reached if camera temperature becomes elevated.
 - 3 Dropped from a height of 1.5 m (5 ft) onto a surface of 5 cm (2 in.) thick plywood (changes in appearance, such as paint peeling off and deformation of the drop shock portion and waterproof performance are not subject to the test).

These tests do not guarantee that the camera will be free from damage or trouble under all conditions.

Rechargeable Li-ion Battery EN-EL19

Type	Rechargeable lithium-ion battery
Rated capacity	DC 3.7 V, 700 mAh
Operating temperature	0°C–40°C (32°F–104°F)
Dimensions (W × H × D)	Approx. 31.5 × 39.5 × 6 mm (1.3 × 1.6 × 0.3 in.)
Weight	Approx. 14.5 g (0.5 oz)

Charging AC Adapter EH-70P

Rated input	AC 100–240 V, 50/60 Hz, 0.07–0.044 A
Rated output	DC 5.0 V, 550 mA
Operating temperature	0°C–40°C (32°F–104°F)
Dimensions (W × H × D)	Approx. 55 × 22 × 54 mm (2.2 × 0.9 × 2.2 in.) (excluding plug adapter) For Argentina: Approx. 55 × 59 × 63 mm (2.2 × 2.4 × 2.5 in.) For Korea: Approx. 55 × 59 × 66.5 mm (2.2 × 2.4 × 2.7 in.)
Weight	Approx. 47 g (1.7 oz) (excluding plug adapter) For Argentina and Korea: Approx. 72 g (2.6 oz)

Specifications

- Nikon will not be held liable for any errors this manual may contain.
- The appearance of this product and its specifications are subject to change without notice.

Approved Memory Cards

The following Secure Digital (SD) memory cards have been tested and approved for use in this camera.

- Memory cards with an SD Speed Class rating of 6 or faster are recommended for recording movies. When using a memory card with a lower Speed Class rating, movie recording may stop unexpectedly.

	SD memory card	SDHC memory card ²	SDXC memory card ³
SanDisk	2 GB ¹	4 GB, 8 GB, 16 GB, 32 GB	64 GB, 128 GB
TOSHIBA	–	4 GB, 8 GB, 16 GB, 32 GB	64 GB
Panasonic	2 GB ¹	4 GB, 8 GB, 16 GB, 32 GB	64 GB
Lexar	–	4 GB, 8 GB, 16 GB, 32 GB	64 GB, 128 GB

¹ If the memory card will be used with a card reader or similar device, make sure that the device supports 2 GB cards.

² SDHC compliant. If the memory card will be used with a card reader or similar device, make sure that the device supports SDHC.

³ SDXC compliant. If the memory card will be used with a card reader or similar device, make sure that the device supports SDXC.

- Contact the manufacturer for details on the above cards. We cannot guarantee camera performance when using memory cards made by other manufacturers.



AVC Patent Portfolio License

This product is licensed under the AVC Patent Portfolio License for the personal and noncommercial use of a consumer to (i) encode video in compliance with the AVC standard ("AVC video") and/or (ii) decode AVC video that was encoded by a consumer engaged in a personal and non-commercial activity and/or was obtained from a video provider licensed to provide AVC video. No license is granted or shall be implied for any other use.

Additional information may be obtained from MPEG LA, LLC.

See <http://www.mpeglallc.com>.

Trademark Information

- Microsoft, Windows and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Mac and OS X are trademarks or registered trademarks of Apple Inc. in the U.S. and other countries.
- Adobe and Acrobat are registered trademarks of Adobe Systems Inc.
- SDXC, SDHC and SD Logos are trademarks of SD-3C, LLC.
- PictBridge is a trademark.
- HDMI, HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.

HDMI

- All other trade names mentioned in this manual or the other documentation provided with your Nikon product are trademarks or registered trademarks of their respective holders.

FreeType License (FreeType2)

Portions of this software are copyright © 2012 The FreeType Project (<http://www.freetype.org>). All rights reserved.

MIT License (HarfBuzz)

Portions of this software are copyright © 2014 The HarfBuzz Project (<http://www.freedesktop.org/wiki/Software/HarfBuzz>). All rights reserved.

Index

Symbols

Point and shoot	30
Playback mode	24
Camera settings menu	65
(movie-record) button	1, 60
(shooting/playback mode) button	2, 24
JPG	58
.MOV	58
.WAV	58

A

AC adapter	67, 59
Add a bubble effect	37, 41
Add a cartoon effect	37, 42
Add a diorama effect	12
Add a fisheye effect	10
Add a neon effect	37, 41
Add starbursts	11
AF-assist illuminator	1, 65, 39
Always fire flash	31
Aperture value	23
Audio/video cable	68, 45, 59
Audio/video-in jack	68, 45
Auto flash	31
Auto off	19
Autofocus	54

B

Battery	8, 10, 17
Battery chamber	2
Battery charger	11, 59
Battery level	18
Battery-chamber/memory card slot cover	2, 8, 12
Brightness	46
Brush	xvi
Button sound	47

C

Camera settings	29, 34
Camera settings menu	65
Change colors (playback mode)	13
Change colors (shooting mode)	28, 44
Change sounds	29, 47
Charge by computer	65, 43
Charge lamp	2, 11
Choose a size	29, 49
Choose a style	28, 37
Compression ratio	49
Computer	68, 70
Copy	27
Create a diorama effect	37, 42
Crop	56

Refer to the *Reference Manual* for pages indicated with .

D	
Date and time	14, 65, 35
Date format.....	15, 35
Daylight saving time	15, 35
Decorate (playback mode).....	15
Decorate (shooting mode)	28, 43
Delete	25
Digital zoom.....	21
Direct print.....	68, 47
DPOF print.....	54
DSCN	58
E	
Electronic VR	65, 38
Erase recordings	5
Exchange messages.....	58, 2
Exposure compensation.....	46
Extension.....	58
Eyelet for camera strap.....	1
F	
Face detection	53
File name.....	58
Firmware version.....	66, 44
Flash	1, 28, 31
Flash lamp	2, 32
Flash mode	31
Flash off.....	31
Flexible buttons	6
Focus.....	22, 53
Focus indicator	4
Focus lock	55
Format internal memory	65, 40
Format memory cards.....	13, 65, 40
Formatting	13, 65, 40
FSCN	58
Full-frame playback mode	24
G	
Grade pictures.....	16
Grading.....	58, 16
H	
Have fun with pictures.....	58
HDMI cable.....	68, 45
HDMI micro connector.....	2
Highlight colors (playback mode)	14
Highlight colors (shooting mode)	46
I	
Identifier	58
Image lock	27
Internal memory	13
L	
Language	65, 41
Leave a message (recording a message)	2
Leave a reply (recording a message)	4
Lens.....	1, 18

Refer to the *Reference Manual* for pages indicated with .

M

Make photo albums	68
Memory card	12, 23
Memory card slot	2, 12
Menu background	16, 65, 41
Microphone (stereo)	1
Mirror 	37, 41
Monitor	2, 4, 8
Monitor brightness	65, 36
Movie frame size	50
Movie length	60
Movie playback	63
Movie recording	60
Movie-record button	1, 60
Multi selector	2

N

Nikon Transfer 2	70
Number of exposures remaining...	18, 50

O

Optical zoom	21
Optional accessories	59

P

Paper size	51, 52
Photo size	49
Photograph fireworks 	37, 40
Photograph food 	37, 38
PictBridge	68, 47
Picture play	58, 57

Play recordings 

Playback	24, 63
Playback menu	58
Playback mode	24
Playback zoom	56
Power	18
Power switch/power-on lamp	1, 18
Power-on	11
Pressing halfway	23
Print	68, 32, 50, 52
Print date	17, 65, 37
Print order	59, 32
Print order option	17, 33
Printer	68, 47

R

Rechargeable battery	10
Rechargeable Li-ion battery	8, 10
Recording movies	60
Reset all	66, 44
Restrict image deletion	27
Retouch	59, 27
Rotate pictures	30
RSCN	58

S

Saturation	46
Self-timer	28, 33
Self-timer lamp	1, 34
Shoot at intervals 	37, 39

Refer to the *Reference Manual* for pages indicated with .

Shoot backlit scenes 	37, 40
Shoot close-ups 	37, 38
Shoot night scenes 	37, 38
Shoot under water 	37, 39
Shooting	18, 20, 22
Shooting/playback mode button	2, 24
Shutter sound	47
Shutter speed	23
Shutter-release button	1, 22
Slide show	58,  21
Small picture	 31
Smile timer	35
Soften pictures	 11
Speaker	1
SSCN	 58
Strap	3

I

Take a series of pictures 	37, 40
Take soft pictures 	37, 42
Thumbnail playback	57
Toy camera	 10
Tripod socket	2,  20
TV	68,  45

U

USB cable	68, 70,  48
USB/audio/video output connector	 2, 67, 70,  45,  47
Using skin softening	54

V

Video mode	65,  42
View	58
View by date	58,  20
View graded pictures	 18
View movie	58,  26
ViewNX 2	69
Vividness	46
Volume	64,  5

W

Welcome screen	65,  34
----------------	------------------------------------------------------------------------------------------

Z

Zoom	21
Zoom in	21
Zoom out	21

Refer to the *Reference Manual* for pages indicated with .

No reproduction in any form of this manual, in whole or in part (except for brief quotation in critical articles or reviews), may be made without written authorization from NIKON CORPORATION.

NIKON CORPORATION

© 2014 Nikon Corporation

Printed in Singapore



CT5F02(11)
6MN39211-02