Reference Manual 00809-0100-2410, Rev EA December 2019

Rosemount[™] 2410 Tank Hub





ROSEMOUNT

Rosemount[™] 2410 Tank Hub

NOTICE

Read this manual before working with the product. For personal and system safety, and for optimum product performance, ensure you thoroughly understand the contents before installing, using, or maintaining this product.

For equipment service or support needs, contact your local Emerson Automation Solutions/Rosemount Tank Gauging representative.

Spare Parts

Any substitution of non-recognized spare parts may jeopardize safety. Repair, e.g. substitution of components etc, may also jeopardize safety and is under no circumstances allowed.

Rosemount Tank Radar AB will not take any responsibility for faults, accidents, etc caused by non-recognized spare parts or any repair which is not made by Rosemount Tank Radar AB.

ACAUTION

The products described in this document are NOT designed for nuclear-qualified applications. Using non-nuclear qualified products in applications that require nuclear-qualified hardware or products may cause inaccurate readings. For information on Rosemount nuclear-qualified products, contact your local Emerson Sales Representative.

A WARNING

WARNING - Substitution of components may impair Intrinsic Safety.

WARNING - To prevent ignition of flammable or combustible atmospheres, disconnect power before servicing.

AVERTISSEMENT - La substitution de composants peut compromettre la sécurité intrinsèque.

AVERTISSEMENT - Ne pas ouvrir en cas de presence d'atmosphere explosive.

Contents

Chapter 1	Introduction	5
	1.1 Safety messages	5
	1.2 Symbols	6
	1.3 Manual overview	7
	1.4 Technical documentation	8
	1.5 Service support	9
	1.6 Product recycling/disposal	9
	1.7 Packing material	9
Chapter 2	Overview	
	2.1 Introduction	11
	2.2 Communication	
	2.3 Components	
	2.4 System overview	
	2.5 Installation procedure	
Chapter 3	Installation	25
	3.1 Safety messages	25
	3.2 Installation considerations	26
	3.3 Mechanical installation	27
	3.4 Electrical installation	
Chapter 4	Configuration	63
	4.1 Safety messages	63
	4.2 Introduction	64
	4.3 Configuration tools	
	4.4 Basic configuration of a Rosemount 2410 Tank Hub	65
	4.5 Advanced configuration	
	4.6 Configuration using TankMaster WinSetup	
Chapter 5	Operation	
	5.1 Safety messages	
	5.2 Integral display	69
	5.3 Start-up information	71
	5.4 Error codes	72
	5.5 LED	74
	5.6 Specifying display variables	77
Chapter 6	Service and troubleshooting	
	6.1 Safety messages	
	6.2 Service	80

	6.3 Troubleshooting	
Appendix A	Specifications and reference data	113
	A.1 General specifications	113
	A.2 Communication/display/configuration specifications	
	A.3 Electrical specifications	
	A.4 Mechanical specifications	127
	A.5 Environmental specifications	
	A.6 Dimensional drawings	129
	A.7 Ordering information	
Appendix B	Product certifications	135
	B.1 European directive information	
	B.2 Ordinary location certification	135
	B.3 Installing equipment in North America	
	B.4 North America	136
	B.5 Europe	140
	B.6 International	141
	B.7 Brazil	
	B.8 China	143
	B.9 Technical Regulations Customs Union (EAC)	144
	B.10 Japan	145
	B.11 Republic of Korea	146
	B.12 India	147
	B.13 Additional certifications	148
	B.14 Conduit plugs and adapters	149
	B.15 Approval drawings	150
Appendix C	Advanced configuration	159
	C.1 Safety messages	159
	C.2 Access the advanced configuration options in WinSetup	160
	C.3 Change the communication parameters for the primary bus	161
	C.4 Open the secondary bus window	
	C.5 Configure a virtual relay output	162
	C.6 Set up a Rosemount 2410 for hybrid density applications	167
	C.7 Volume configuration	170
	C.8 Arithmetic operations	175
	C.9 Configure the analog output	179
	C.10 Configuration of analog input / $HART^{\text{@}}$ slave device	

1 Introduction

1.1 Safety messages

Instructions and procedures in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that potentially raises safety issues is indicated by a warning symbol (\triangle). Refer to the following safety messages before performing an operation preceded by this symbol.

A WARNING

Failure to follow these installation guidelines could result in death or serious injury.

- Ensure only qualified personnel perform the installation.
- Use the equipment only as specified in this manual. Failure to do so may impair the protection provided by the equipment.

Explosions could result in death or serious injury.

- Verify that the operating environment of the device is consistent with the appropriate hazardous locations certifications.
- Before connecting a handheld communicator in an explosive atmosphere, ensure that the instruments in the loop are installed in accordance with intrinsically safe or nonincendive field wiring practices.
- Do not remove the gauge cover in explosive atmospheres when the circuit is alive.

Electrical shock could cause death or serious injury.

• Use extreme caution when making contact with the leads and terminals.

AWARNING

Any substitution of non-recognized parts may jeopardize safety. Repair (e.g. substitution of components) may also jeopardize safety and is not allowed under any circumstances.

A WARNING

Physical access

Unauthorized personnel may potentially cause significant damage to and/or misconfiguration of end users' equipment. This could be intentional or unintentional and needs to be protected against.

Physical security is an important part of any security program and fundamental to protecting your system. Restrict physical access by unauthorized personnel to protect end users' assets. This is true for all systems used within the facility.

1.2 Symbols

Table 1-1: Symbols

CE	The CE marking symbolizes the conformity of the product with the applicable European Community Directives.
(Ex)	The EU-Type Examination Certificate is a statement of a Notified Certification Body declaring that this product meets the Essential Health and Safety Requirements of the ATEX directive
FM	The FM APPROVED Mark indicates that the equipment is approved by FM Approvals according to applicable Approval Standards and is applicable for installation in hazardous locations
	Protective Earth
÷	Ground
\triangle	Caution - see reference manual
85 °C	Use wiring rated for maximum ambient temperature + 15 °C Examples:
	For connections in ambient temperatures up to 70 °C use wiring rated 85 °C minimum.
	For connections in ambient temperatures up to 60 °C use wiring rated 75 °C minimum.
	For connections in ambient temperatures up to 50 °C use wiring rated 65 °C minimum.

1.3 Manual overview

This manual provides information on installation, configuration and maintenance of the Rosemount[™] 2410 Tank Hub.

Chapter Overview provides a brief description of the various components in a Rosemount Tank Gauging system and recommended installation procedure.

Chapter Installation covers installation considerations as well as mechanical and electrical installation.

Chapter Configuration describes how to configure the Rosemount 2410 Tank Hub by using the TankMaster WinSetup configuration program.

Chapter Operation describes the integral display and how to specify display variables. It also includes start-up information, error messages, and LED functionality

Chapter Service and troubleshooting covers tools, troubleshooting, and various service instructions.

Appendix Specifications and reference data contains specifications, dimensional drawings, and ordering table.

Appendix Product certifications contains safety approval information and approval drawings.

Appendix Advanced configuration describes various advanced configuration options.

1.4 Technical documentation

The Rosemount[™] Tank Gauging System includes the following documentation:

Reference manuals

- Rosemount Tank Gauging System Configuration Manual (00809-0300-5100)
- Rosemount 2460 System Hub (00809-0100-2460)
- Rosemount 2410 Tank Hub (00809-0100-2410)
- Rosemount 5900S Radar Level Gauge (00809-0100-5900)
- Rosemount 5900 Proof Test with Reference Reflector (00809-0200-5900)
- Rosemount 5900C Radar Level Gauge (00809-0100-5901)
- Rosemount 2240S Multi-Input Temperature Transmitter (00809-0100-2240)
- Rosemount 2230 Graphical Field Display (00809-0100-2230)
- Rosemount 5300 Guided Wave Radar (00809-0100-4530)
- Rosemount 5408 Radar Level Transmitter (00809-0300-4408)
- Rosemount Tank Gauging Wireless System (00809-0100-5200)
- Rosemount TankMaster WinOpi (00809-0200-5110)
- Rosemount TankMaster WinSetup 00809-0100-5110
- Rosemount TankMaster Floating Roof Monitoring (00809-0500-5100)00809-0500-5100

Product data sheets

- Rosemount Tank Gauging System Data Sheet (00813-0100-5100)
- Rosemount 2460 System Hub Product Data Sheet (00813-0100-2460)
- Rosemount 2410 Product Data Sheet (00813-0100-2410)
- Rosemount 5900S Product Data Sheet (00813-0100-5900)
- Rosemount 5900C Product Data Sheet (00813-0100-5901)
- Rosemount 2240S Product Data Sheet (00813-0100-2240)
- Rosemount 2230 Product Data Sheet (00813-0100-2230)
- Rosemount 5300 Product Data Sheet (00813-0100-4530)
- Rosemount 5408 Product Data Sheet (00813-0100-4408)

1.5 Service support

For service support contact the nearest Emerson Automation Solutions /Rosemount Tank Gauging representative. Contact information can be found on the web site www.Emerson.com.

1.6 Product recycling/disposal

Recycling of equipment and packaging should be taken into consideration and disposed of in accordance with local and national legislation/regulations.

1.7 Packing material

Rosemount Tank Radar AB is fully certified according to ISO 14001 environmental standards. By recycling the corrugated paperboard, or wooden boxes, used for shipping our products you can contribute to take care of the environment.

Reuse and recycling

Experience has shown that wooden boxes can be used several times for various purposes. After careful disassembly the wooden parts may be reused. Metal waste may be converted.

Energy recovery

Products which have served their time may be divided into wood and metal components and the wood can be used as fuel in sufficient ovens.

Due to its low moisture content (approximately 7%) this fuel has a higher calorific value than ordinary wood fuel (moisture content approximately 20%).

When burning interior plywood the nitrogen in the adhesives may increase emissions of nitrogen oxides to the air 3-4 times more than when burning bark and splinter.

Note

Landfill is not a recycling option and should be avoided.

2 Overview

2.1 Introduction

The Rosemount[™] 2410 Tank Hub collects measurement data and status information from field devices designed for the Rosemount Tank Gauging system via the intrinsically safe 2-wire **Tankbus**⁽¹⁾. The Tankbus carries both data transmission and power supply (see also Tankbus).

Figure 2-1: System Integration



- A. Rosemount TankMaster
- B. Rosemount 2460 System Hub
- C. Modem
- D. Host
- E. Servo gauges
- F. Secondary Bus (Non-IS)
- G. Relay Outputs
- H. Primary Bus

- I. Rosemount 2410 Tank Hub
- J. Tankbus
- K. Secondary bus (IS)
- L. Rosemount 2230 Field Display
- M. Rosemount 5900S Radar Level Gauge
- N. Rosemount 2240S Temperature Transmitter
- O. Zone 1
- P. Zone 0

The Rosemount 2410 is designed for use in hazardous area Zone 1 (Class 1, Division 1) and communicates with field devices in Zone 1 via the intrinsically safe Tankbus.

The Rosemount 2410 is available in two versions for single tanks or multiple tanks. The multiple tanks version supports up to 10 tanks and 16 devices.

⁽¹⁾ The intrinsically safe Tankbus complies with the FISCO FOUNDATION^M Fieldbus standard.

Measurement data and status information from one or more tanks is distributed via the Primary Bus to a Rosemount 2460 System Hub. Data is buffered by the system hub and distributed to a TankMaster PC, or a host system, whenever the 2460 receives a request for data. In case no system hub is included in the system, the Rosemount 2410 Tank Hub can communicate directly with a host computer.

The Rosemount 2410 has two external buses for communication with host systems. The **Primary Bus** is typically used with the TRL2 Modbus[®] or RS-485 Modbus protocol for communication with a 2460 System Hub. If there is no Rosemount 2460 included, the Primary bus can communicate directly, or via a modem, with the TankMaster PC.

The **Secondary Bus** supports various protocols such as TRL2 Modbus, Enraf[®], and Varec which allows you to connect to other systems as well.

The Rosemount 2410 is equipped with two **solid state relays** that allows controlling external devices such as valves and pumps.

An **integral display** (optional) presents measurement data and device status such as warnings and error messages. At start-up, communication settings and optional hardware configuration is presented as well as whether it is a Single tank or Multiple tank version of the Rosemount 2410 Tank Hub.

Using the input from a Rosemount 5900S Radar Level Gauge and one or two pressure sensors, the Rosemount 2410 can be configured for online presentation of **Observed Density** to a host computer. The tank hub also calculates **Average Temperature** and strapping table based **Volume**.

The Rosemount 2410 can be equipped with two **relays** which can be controlled by level, temperature, and water level. The output can be connected to an external system for alarm indication or process control. The relays are user configurable for normally open or closed operation.

The Rosemount 2410 can be configured with up to ten **"virtual" relay** functions. This allows you to specify several different source variables to trigger a relay.

The Rosemount 2410 supports the Emerson's Wireless solution, which is based on *Wireless*HART[®] the emerging industry standard for wireless field networks. By connecting to an Emerson Wireless 775 THUM[™] Adapter, the Rosemount 2410 can be integrated in a wireless network to provide measurement data at greatly reduced field wiring costs. The tank hub supports communication with Emerson Wireless Gateways 1410 and 1420.

2.2 Communication

The Rosemount Tank Gauging system supports various communication interfaces between a Rosemount 2410 and a TankMaster PC or other host computers as illustrated in Figure 2-2 to Figure 2-4.

Both the Primary bus and the Secondary bus can be used for either TRL2 Modbus (standard) or RS485 Modbus communication⁽²⁾.

On the Secondary bus you may use other communication protocols as well, such as Enraf, Varec etc.

⁽²⁾ See Cabling for the TRL2/RS485 Bus for information on cable requirements.



Figure 2-2: Typical Configuration of a Rosemount 2410 and 2460 System Hub Connected to PC/Host

- A. Field devices
- B. Tankbus
- C. Rosemount 2410
- D. Primary bus: TRL2 Modbus, RS485 Modbus
- E. Secondary bus: Enraf and others, HART 4-20 mA analog output/input
- F. Rosemount 2460
- G. DCS
- H. TRL2 Modbus, RS485 Modbus
- I. RS232
- J. Modem
- K. USB / RS232
- L. TankMaster



Figure 2-3: Typical Configuration of a Rosemount 2410 Connected to PC/Host

- D. Primary bus: TRL2 Modbus, RS485 Modbus
- E. Secondary bus: Enraf and others, HART 4-20 mA analog output/input
- F. Modem
- G. USB/RS232
- H. TankMaster

A THUM Adapter, connected to the Intrinsically Safe Secondary⁽³⁾ bus, allows wireless communication between a Rosemount 2410 Tank Hub and a Smart Wireless Gateway.

Figure 2-4: Typical Configuration of a Rosemount 2410 with Wireless Connection to Smart Wireless Gateway and PC/Host



- A. Field devices
- B. Tankbus
- C. Rosemount 2410
- D. Secondary bus (IS): WirelessHART
- E. Smart Wireless THUM Adapter
- F. Primary bus: TRL2 Modbus, RS485 Modbus
- G. Smart Wireless Gateway
- H. TankMaster



⁽³⁾ The Non-IS Secondary Bus can not be used simultaneously with the IS HART 4-20 mA Secondary Bus.

2.3 Components

Figure 2-5: Rosemount 2410 Components





- A. Intrinsically safe terminal compartment
- B. Non-intrinsically safe terminal compartment
- C. Integral display (optional)
- D. Write protection switch
- E. Cable entries for IS connection (two ½ 14 NPT)
- F. Cable entries for Non-IS connection (two 1/2 14 NPT, two 3/4- 14 NPT)
- G. Grounding terminal

2.4 System overview

The Rosemount Tank Gauging system is a state-of-the art inventory and custody transfer radar tank level gauging system. It is developed for a wide range of applications at refineries, tank farms and fuel depots, and fulfills the highest requirements on performance and safety.

The field devices on the tank communicate over the intrinsically safe Tankbus. The Tankbus is based on a standardized fieldbus, the FISCO⁽⁴⁾ FOUNDATION[™] Fieldbus, and allows integration of any device supporting that protocol. By utilizing a bus powered 2-wire intrinsically safe fieldbus the power consumption is minimized. The standardized fieldbus also enables integration of other vendors' equipment on the tank.

The Rosemount Tank Gauging product portfolio includes a wide range of components to build small or large customized tank gauging systems. The system includes various devices, such as radar level gauges, temperature transmitters, and pressure transmitters for complete inventory control. Such systems are easily expanded thanks to the modular design.

The Rosemount Tank Gauging system is a versatile system that is compatible with and can emulate all major tank gauging systems. Moreover, the well-proven emulation capability enables step-by-step modernization of a tank farm, from level gauges to control room solutions.

It is possible to replace old mechanical or servo gauges with modern Rosemount Tank Gauging devices, without replacing the control system or field cabling. It is further possible to replace old HMI/SCADA-systems and field communication devices without replacing the old gauges.

There is a distributed intelligence in the various system units which continuously collect and process measurement data and status information. When a request for information is received an immediate response is sent with updated information.

The flexible Rosemount Tank Gauging system supports several combinations to achieve redundancy, from control room to the different field devices. Redundant network configuration can be achieved at all levels by doubling each unit and using multiple control room work stations.

⁽⁴⁾ See documents IEC 61158-2

Figure 2-6: Rosemount Tank Gauging System Architecture



- A. Non-hazardous area
- B. Hazardous area
- C. Rosemount 5900S Radar Level Gauge
- D. Rosemount 2240S Temperature Transmitter
- E. Rosemount 2230 Graphical Field Display
- F. Rosemount 2410 Tank Hub
- G. Rosemount 3051S Pressure Transmitter
- H. Rosemount TankMaster PC
- I. Rosemount 2460 System Hub
- J. Rosemount 2180 Field Bus Modem

- K. Plant Host Computer
- L. TRL2 Modbus
- M. Segment coupler
- N. Rosemount 644 Temperature Transmitter
- O. Rosemount 5300 Level Transmitter
- P. Rosemount 5408 Level Transmitter
- Q. Custody transfer / Inventory tank gauging
- R. Operational control
- S. Plant host computer



Figure 2-7: Rosemount Tank Gauging System Architecture for Wireless Systems

- B. Hazardous area
- C. Rosemount TankMaster PC
- D. Emerson Wireless 1420 Gateway
- E. Rosemount 2410 Tank Hub
- F. Tankbus
- G. Emerson Wireless 775 THUM Adapter
- H. Rosemount 5900S Radar Level Gauge
- I. Rosemount 2240S Temperature Transmitter
- J. Rosemount 3051S Pressure Transmitter
- K. Rosemount 2230 Graphical Field Display
- L. Segment coupler
- M. Rosemount 644 Temperature Transmitter



Figure 2-8: Rosemount Tank Gauging System Architecture in a FOUNDATION Fieldbus Network

- A. Non-hazardous area
- B. Hazardous area
- C. Rosemount 5900S Radar Level Gauge
- D. Rosemount 2240S Temperature Transmitter
- E. PC
- F. Rosemount 2230 Graphical Field Display
- G. Rosemount 3051S Pressure Transmitter

- H. Rosemount 644 Temperature Transmitter
- I. FOUNDATION Fieldbus Power Supply
- J. Segment coupler
- K. Rosemount 5300 Level Transmitter
- L. Rosemount 5408 Level Transmitter
- M. Custody transfer / Inventory tank gauging
- N. Operational control

2.4.1 TankMaster HMI software

Rosemount TankMaster is a powerful Windows-based Human Machine Interface (HMI) for complete tank inventory management. It provides configuration, service, set-up, inventory, and custody transfer functions for Rosemount Tank Gauging systems and other supported instruments.

Rosemount TankMaster is designed to be used in the Microsoft[®] Windows environment providing easy access to measurement data from your Local Area Network (LAN).

The Rosemount TankMaster WinOpi program lets the operator monitor measured tank data. It includes alarm handling, batch reports, automatic report handling, historical data sampling as well as inventory calculations such as Volume, Observed Density and other parameters. A plant host computer can be connected for further processing of data.

The Rosemount TankMaster WinSetup program is a graphical user interface for installation, configuration and service of devices in the Rosemount Tank Gauging system.

2.4.2 Rosemount 2460 System Hub

The Rosemount 2460 System Hub is a data concentrator that continuously polls and stores data from field devices such as radar level gauges and temperature transmitters in a buffer memory. Whenever a request for data is received, the system hub can immediately send data from the updated buffer memory for a group of tanks.

Measured and calculated data from one or more tanks is communicated via the Rosemount 2410 Tank Hub to the system hub buffer memory. Whenever a request is received, the system hub can immediately send data from a group of tanks to a TankMaster PC, or a host.

The Rosemount 2460 can be used to connect devices from other vendors as well, such as Honeywell[®] Enraf and Whessoe.

The Rosemount 2460 has eight slots for communication interface boards. These boards can be individually configured for communication with hosts or field devices. They can be ordered either for TRL2, RS485, Enraf BPM or Whessoe 0-20 mA/RS485 communication. Two slots can also be configured for RS232 communication.

One of the system hub's three Ethernet ports is used for Modbus TCP connection to host systems. By simply connecting the system hub to the existing LAN network, communication over Ethernet is established.

The system hub can provide redundancy for critical operations, by using two identical devices. The primary system hub is active and the other one is in passive mode. If the primary unit stops working properly, the secondary unit is activated and a failure message is sent to TankMaster (or a DCS system).

2.4.3 Rosemount 2410 Tank Hub

The Rosemount 2410 Tank Hub acts as a power supply to the connected field devices in the hazardous area using the intrinsically safe Tankbus.

The tank hub collects measurement data and status information from field devices on a tank. It has two external buses for communication with various host systems.

There are two versions of the Rosemount 2410 Tank Hub; one for single tank operation and one for multiple tanks operation. The multiple tanks version of the Rosemount 2410 supports up to 10 tanks and 16 devices. With the Rosemount 5300 the Rosemount 2410 supports up to 5 tanks.

The Rosemount 2410 is equipped with two relays which support configuration of up to 10 "virtual" relay functions allowing you to specify several source signals for each relay.

The Rosemount 2410 supports Intrinsically Safe (IS) and Non-Intrinsically Safe (Non-IS) analog 4-20 mA inputs/outputs. By connecting an Emerson Wireless 775 THUM Adapter to the IS HART 4-20 mA output, the tank hub is capable of wireless communication with an Emerson Wireless Gateway in a *Wireless*HART[®] network.

2.4.4 Rosemount 5900S Radar Level Gauge

The Rosemount 5900S Radar Level Gauge is an intelligent instrument for measuring the product level inside a tank. Different antennas can be used in order to meet the requirements of different applications. The Rosemount 5900S can measure the level of almost any product, including bitumen, crude oil, refined products, aggressive chemicals, LPG and LNG.

The Rosemount 5900S sends microwaves towards the surface of the product in the tank. The level is calculated based on the echo from the surface. No part of the Rosemount 5900S is in actual contact with the product in the tank, and the antenna is the only part of the gauge that is exposed to the tank atmosphere.

The 2-in-1 version of the Rosemount 5900S Radar Level Gauge has two radar modules in the same transmitter housing allowing two independent level measurements using one antenna and one tank opening.

2.4.5 Rosemount 5300 Guided Wave Radar

The Rosemount 5300 is a premium 2-wire guided wave radar for level measurements on liquids, to be used in a wide range of medium accuracy applications under various tank conditions. Rosemount 5300 includes the Rosemount 5301 for liquid level measurements and the Rosemount 5302 for liquid level and interface measurements.

2.4.6 Rosemount 5408 Radar Level Transmitter

The Rosemount 5408 is a non-contacting level transmitter for accurate and reliable level measurement on small storage and buffer tanks.

The Rosemount 5408 provides accurate and reliable level measurements for metallic and non-metallic vessels. It is suitable for almost any liquid and is ideal for challenging applications with agitators, foam, high temperatures, and pressures. It is also an excellent choice for level measurement in tanks with small diameter (2- to 4-inch) stiling wells.

The narrow beam makes the Rosemount 5408 the ideal solution for bulk solids in small to medium sized silos with rapid level changes.

For safety functions such as overfill prevention, level deviation monitoring, or dry-run prevention, the Rosemount 5408:SIS is the ideal choice.

2.4.7 Rosemount 2240S Multi-Input Temperature Transmitter

The Rosemount 2240S Multi-input Temperature Transmitter can connect up to 16 temperature spot sensors and an integrated water level sensor.

2.4.8 Rosemount 2230 Graphical Field Display

The Rosemount 2230 Graphical Field Display presents inventory tank gauging data such as level, temperature, and pressure. The four softkeys allow you to navigate through the different menus to provide all tank data, directly in the field. The Rosemount 2230 supports up to 10 tanks. Up to three Rosemount 2230 displays can be used on a single tank.

2.4.9 Rosemount 644 Temperature Transmitter

The Rosemount 644 is used with single spot temperature sensors.

2.4.10 Rosemount 3051S Pressure Transmitter

The Rosemount 3051S series consists of transmitters and flanges suitable for all kinds of applications, including crude oil tanks, pressurized tanks and tanks with / without floating roofs.

By using a Rosemount 3051S Pressure Transmitter near the bottom of the tank as a complement to a Rosemount 2410 Radar Level Gauge, the density of the product can be calculated and presented. One or more pressure transmitters with different scalings can be used on the same tank to measure vapor and liquid pressure.

2.4.11 Rosemount 2180 Field Bus Modem

The Rosemount 2180 Field Bus Modem (FBM) is used for connecting a TankMaster PC to the TRL2 communication bus. The Rosemount 2180 is connected to the PC using either the USB or the RS232 interface.

2.4.12 Emerson Wireless Gateway and Emerson Wireless 775 THUM[™] Adapter

An Emerson Wireless THUM Adapter allows wireless communication between a Rosemount 2410 Tank Hub and an Emerson Wireless Gateway. The gateway is the network manager that provides an interface between field devices and the Rosemount TankMaster inventory software or host / DCS systems.

See the Rosemount Tank Gauging System Data Sheet for more information on the various devices and options.

2.5 Installation procedure

Follow these steps for a proper installation:

Procedure

- 1. Review Mounting Considerations. See Installation considerations.
- 2. Mount the Rosemount 2410 Tank Hub. See Mechanical installation.
- 3. Wire the Rosemount 2410. See Electrical installation.
- 4. Make sure covers and cable/conduit connections are tight.
- 5. Power up the Rosemount 2410.
- 6. Configure the Rosemount 2410 (Configuration):
 - tank database
 - tags
 - integral display
 - Primary/Secondary Bus
 - Relay output
 - Hybrid density
- 7. Verify operation.
- 8. Optional: Enable the Write Protection switch if required.

3 Installation

3.1 Safety messages

Instructions and procedures in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that potentially raises safety issues is indicated by a warning symbol (\triangle). Refer to the following safety messages before performing an operation preceded by this symbol.

WARNING

Failure to follow safe installation and servicing guidelines could result in death or serious injury.

- Ensure only qualified personnel perform the installation.
- Use the equipment only as specified in this manual. Failure to do so may impair the protection provided by the equipment.
- Do not perform any services other than those contained in this manual unless you are qualified.

Explosions could result in death or serious injury.

- Verify that the operating environment of the device is consistent with the appropriate hazardous locations certifications.
- Before connecting a handheld communicator in an explosive atmosphere, ensure that the instruments in the loop are installed in accordance with intrinsically safe or non-incendive field wiring practices.
- Do not remove the gauge cover in explosive atmospheres when the circuit is alive.
- To prevent ignition of flammable or combustible atmospheres, disconnect power before servicing.

High voltage that may be present on leads could cause electrical shock.

- Avoid contact with leads and terminals.
- Ensure the main power to the Rosemount 2410 Tank Hub is off and the lines to any other external power source are disconnected or not powered while wiring the gauge.

3.2 Installation considerations

The Rosemount[™] 2410 Tank Hub may be installed on various locations at the plant. Mounting at the tank foot may be convenient when you would like to have easy access to measuring data, diagnostics and other information on the optional integral display.

The Rosemount 2410 Tank Hub can also be mounted on the tank roof if this is the preferred location. In case the tank hub is exposed to long periods of sunshine, a sunshade should be used to prevent it from being heated to temperatures above the maximum operating temperature.

Ensure that environmental conditions are within specified limits as listed in Specifications and reference data.

Ensure that the Rosemount 2410 is installed such that it is not exposed to higher pressure and temperature than specified in Specifications and reference data.

The multi-tank version of the Rosemount 2410 Tank Hub is able to serve several tanks. In that case it may be placed at a suitable location further away from the tanks.

The Rosemount 2410 is designed with two Tankbus terminals and several cable entries which allows alternative cable routings to suit various requirements.

Do not install the Rosemount 2410 in non-intended applications, for example environments where it may be exposed to extremely intense magnetic fields or extreme weather conditions.

Important

Check the Rosemount 2410 Tank Hub for any signs of damage prior to installation. Ensure that the glass on the integral display is undamaged, and O-rings and gaskets are in good condition.

3.2.1 Installation planning

It's a good idea to plan the installation in order ensure that all components in the system are properly specified. The planning stage should include the following tasks:

- Make a plan of the site and specify suitable locations for the devices
- Consider power budget
- Specify cabling and connections (for example whether devices will be "daisy-chained" or not)
- Specify cable glands that will be needed for the various devices
- Specify location of terminators on the Tankbus
- Make a note of identification codes such as Unit ID/Device ID of each device
- Assign Modbus[®] addresses for level gauges and other tank devices to be used in the tank database of the Rosemount 2410 and the tank database of the Rosemount 2460 System Hub (see the Rosemount Tank Gauging System Configuration Manual, document no. 00809-0300-5100 for more information)

See Electrical installation for more information on cables and glands.

3.3 Mechanical installation

The Rosemount 2410 is designed for mounting on a pipe stand or on a wall.

3.3.1 Pipe mounting

Prerequisites

Note

Ensure that the Rosemount 2410 is installed to minimize vibration and mechanical shock.

Procedure

1. Attach the bracket to the pipe.

Ensure that the Rosemount 2410 Tank Hub is placed in a direction so that the display is clearly visible and wiring can be properly connected.



- B. 4 nuls and was
- C. Bracket
- 2. Tighten the nuts. Use moderate torque to ensure that the bracket does not break.
- 3. Attach the tank hub to the bracket by sliding it from the top downwards.



4. Secure the tank hub to the bracket by tightening the screw.



3.3.2 Wall mounting

Prerequisites

Note

Ensure that the Rosemount 2410 is installed such that vibration and mechanical shock is minimized.

Procedure

1. Mount the bracket on the wall by using four M8 screws and flat washers.

Note

Countersunk screws are not suitable.



2. Attach the tank hub to the bracket and tighten the screw.



3.4 Electrical installation

3.4.1 Cable entries

The Rosemount 2410 electronics housing has four $\frac{1}{2}$ - 14 NPT and two $\frac{3}{4}$ - 14 NPT entries. The connections must be made in accordance with local or plant electrical codes.

Make sure that unused ports are properly sealed to prevent moisture or other contamination from entering the terminal block compartment of the electronics housing.

Note

Use the enclosed metal plugs to seal unused ports. The plastic plugs mounted at delivery are not sufficient as seal!

Note

Thread sealing (PTFE) tape or paste on male threads of conduit is required to provide a water/dust tight conduit seal and to meet the required degree of ingress protection as well as to enable future removal of the plug/gland.

Note

NPT is a standard for tapered threads.Tightening torque is not given by the standard. Common recommendation is to tighten the NPT gland by hand and then use a wrench to tighten the NPT gland. Keep in mind that over tightening may be detrimental for the sealing function or even damage the threads in the housing. Engage the gland with 5 to 6 threads. Note that there will be a number of threads left outside the housing as in Figure 3-1.

Figure 3-1: Cable Entry with NPT Threaded Gland



A. The NPT threaded gland leaves a number of threads outside the housing

Glands must meet the following requirements for the Non-IS cable entries:

- Ex de explosion protection
- IP class 66 and 67
- material: metal (recommended)

3.4.2 Power supply

The Rosemount 2410 Tank Hub accepts supply voltage 48 - 240 Vac (50/60 Hz) and 24 - 48 Vdc. The Rosemount 2410 provides intrinsically safe power to all devices connected to the Tankbus.

Related information

Tankbus

3.4.3 Cable selection for power supply

Cables must be suitable for the supply voltage and approved for use in hazardous areas, where applicable. For instance, in the U.S., explosion-proof conduits must be used in the vicinity of the vessel.

Suitable conduits with sealing device or flame proof cable glands must be used depending on local requirements.

Appropriate cross sectional area of wires must be used in order to prevent a too high voltage drop to the connected device. Use 0.75 mm² to 2.5 mm² (18 AWG to 13 AWG) in order to minimize the voltage drop.

3.4.4 Grounding

The housing should always be grounded in accordance with national and local electrical codes. Failure to do so may impair the protection provided by the equipment. The most effective grounding method is direct connection to earth ground with minimal impedance. There are grounding screw connections inside the terminal compartments which are identified by ground symbols: $\textcircled{}/ \doteq$. There is also a grounding screw on the housing.

Note

Grounding the device via threaded conduit connection may not provide sufficient ground.

Grounding - Tankbus

Signal wiring of the fieldbus segment (Tankbus) can not be grounded. Grounding one of the signal wires may shut down the entire fieldbus segment.

Shield wire ground

Tankbus

To protect the fieldbus segment (Tankbus) from noise, grounding techniques for shield wire usually require a single grounding point for shield wire to avoid creating a ground loop. The ground point is typically at the power supply.

The Rosemount Tank Gauging devices are designed for "daisy-chain" connection of shield wiring in order to enable a continuous shield throughout the Tankbus network.

Primary/Secondary Bus

Cable shield for the Primary and Secondary Bus should normally be grounded at host or System Hub end only.

3.4.5 Cable selection for the Tankbus

Use shielded twisted pair wiring for the Rosemount 2410 Series in order to comply with FISCO⁽⁵⁾ requirements and EMC regulations. The preferred cable is referred to as type "A" fieldbus cable. The cables must be suitable for the supply voltage and approved for use in hazardous areas, where applicable. In the U.S. explosion-proof conduits may be used in the vicinity of the vessel.

We recommend cable size 1.0 mm^2 or 18 AWG in order to facilitate wiring. However, cables within the range 0.5 to 1.5 mm^2 or 20 to 16 AWG can be used.

The FISCO FOUNDATION[™] Fieldbus specification requires that cables for the Tankbus comply with the following cable parameters:

Parameter ⁽¹⁾	Value
Loop resistance	15 Ω/km to 150 Ω/km
Loop inductance	0.4 mH/km to 1 mH/km
Capacitance	45 nF/km to 200 nF/km
Maximum length of each spur ⁽²⁾ cable	60 m in apparatus class IIC and IIB
Maximum cable length including trunk ⁽³⁾ and spurs	1000 m in apparatus class IIC and 1900 m in apparatus class IIB

Table 3-1: FISCO Cable Parameters

(1) For further information see requirements of the IEC 61158-2 standard

(2) A spur is an unterminated part of the network.

(3) A trunk is the longest cable path between two devices on the fieldbus network, and is the part of the network which has terminations at both ends. In the Rosemount Tank Gauging system, a trunk is typically located between the Rosemount 2410 Tank Hub and a segment coupler or the last device in a daisy-chain configuration.

⁽⁵⁾ See IEC 61158-2

3.4.6 Power budget

The Rosemount 2410 Tank Hub delivers 250 mA to the Tankbus. In Smart Wireless systems a Rosemount 2410 Tank Hub equipped with active analog inputs/outputs may deliver 200 mA. The number of tanks served by the tank hub depends on the type of connected field devices and their power consumption⁽⁶⁾. Power consumption per field device is listed in Table 3-2.

Field device	Power consumption
Rosemount 5900S Radar Level Gauge	50 mA
Rosemount 5900C Radar Level Gauge	50 mA
Rosemount 5900S Radar Level Gauge, 2-in-1 solution	100 mA
Rosemount 5300 Level Transmitter	21 mA
Rosemount 5408 Level Transmitter	21 mA
Rosemount 2230 Graphical Field Display	30 mA
Rosemount 2240S Multi-input Temperature Transmitter	30 mA including 565, 566 and 765 temperature sensors
Rosemount 644 Temperature Transmitter	12 mA
Rosemount 3051S, and Rosemount 2051 Pressure Transmitters	18 mA

The Rosemount 2410 Tank Hub is available in a single tank version as well as a multiple tank version which supports up to 10 tanks⁽⁷⁾.

3.4.7 Tankbus

The Rosemount Tank Gauging system is easy to install and wire. Devices can be "daisychained" thus reducing the number of external junction boxes.

In a Rosemount Tank Gauging system devices communicate with a Rosemount 2410 Tank Hub via the intrinsically safe Tankbus. The Tankbus complies with the FISCO⁽⁸⁾ FOUNDATION Fieldbus standard. The Rosemount 2410 acts as power supply to the field devices on the Tankbus. A FISCO system enables more field devices to be connected to the segment compared to conventional IS systems based on the entity concept.

The tank hub is designed for use in hazardous area Zone 1 (Class 1, Division 1) and communicates with field devices via the intrinsically safe Tankbus.

Termination

A terminator is needed at each end of a FOUNDATION[™] Fieldbus network. A trunk is defined as the longest cable path between two devices on the fieldbus network. In the Rosemount

⁽⁶⁾ May be fewer than the 16 devices per segment, stated in the FOUNDATION^T Fieldbus standard.

⁽⁷⁾ Maximum five Rosemount 5300 level transmitters.

⁽⁸⁾ FISCO=Fieldbus Intrinsically Safe Concept

Tank Gauging system, a trunk is typically located between the Rosemount 2410 Tank Hub and a splitter or the last device in a daisy-chain configuration. Generally, one terminator is placed in the fieldbus power supply, and the other one in the last device in the fieldbus network.

Note

Ensure that there are **two** terminators on the fieldbus.

In a Rosemount Tank Gauging system the Rosemount 2410 Tank Hub acts as power supply. Since the tank hub normally is the first device in the fieldbus segment, the built-in termination is enabled at factory.

Other devices such as the standard version of the Rosemount 5900S Radar Level Gauge, the Rosemount 2230 Graphical Field Display, and the Rosemount 2240S Multi-input Temperature Transmitter also have built-in terminators which can easily be enabled by inserting a jumper in the terminal block when necessary.

When adding new devices at the end of an existing FOUNDATION Fieldbus network, the termination is moved to the farthest field device in order to fulfill the requirement on locating the terminator at the end of the trunk. However, in case a field device is added to the network with a short cable, this rule may be slightly bent by leaving the terminator in its original position.

Fieldbus segment design

When designing a FISCO fieldbus segment you will have to make sure that cabling complies with FISCO requirements as described in Cable selection for the Tankbus.

You will also have to ensure that the total operating current of the connected field devices is within the output capability of the Rosemount 2410 Tank Hub. The tank hub is able to deliver $250^{(9)}$ mA. Consequently, the total number of field devices has to be considered so that the total current consumption is less than 250 mA, see Power budget.

Since the field devices on the Tankbus must have at least a 9 V input voltage at their terminals, you will have to take into account the voltage drop in the fieldbus cables. In many cases distances are relatively short between the Rosemount 2410 and field devices on the tank and you may use existing cables as long as the FISCO requirements are fulfilled (see Cable selection for the Tankbus).

Typical characteristics for such a cable is:

Table 3-3: Typical Characteristics of Instrumentation Cable

Parameter	Value	
Loop resistance	42 Ω/km	
Inductance	0.65 mH/km	
Capacitance	115 nF/km	
Cross-sectional area	0.75 mm ² (18 AWG)	

The Rosemount 2410 outputs 12.5 Vdc. Considering the minimum voltage supply of 9 V on the field device terminals, a maximum voltage drop of 3.5 V on the Tankbus can be allowed. At a maximum current consumption of 250 mA (12.5 Vdc) with all field devices

⁽⁹⁾ In Smart Wireless Systems the Rosemount 2410 can deliver 200 mA on the Tankbus

located at the far end of the Tankbus, a total "worst case" cable resistance of approximately 14Ω (3.5 V/250 mA) is allowed. This corresponds to a cable length of 333 m (1092 ft) in case typical cable characteristics are assumed as specified in Table 3-3.

However, normally the current consumption is less than 250 mA. A typical configuration would include a tank supplied with a Rosemount 5900S Radar Level Gauge, a Rosemount 2230 Graphical Field Display, a Rosemount 2240S Multi-input Temperature Transmitter, and a Rosemount 3051S Pressure Transmitter. In this case the current consumption would be 128 mA allowing a cable length of 677 m (2221 ft) between the Rosemount 2410 Tank Hub and the field devices on the tank. With fewer devices on the Tankbus, an even longer cable would be allowed.

Table 3-4 shows the maximum distance between a Rosemount 2410 Tank Hub and the field devices on a tank for different cable cross-sectional areas. The table shows the maximum distance to a tank at a total current consumption of 250 mA as well as for a typical installation as outlined above.

Cable characteristics		Maximum distance to tank (m/ft)	
Cross-sectional area	Typical loop resistance (Ω/km)	Maximum Current consumption (250 mA)	Typical installation (128 mA)
20 AWG (0.5 mm ²)	66	212 (695)	414 (1358)
18 AWG (0.75 mm ²)	42	333 (1092)	651 (2136)
17 AWG (1.0 mm ²)	33	424 (1391)	829 (2720)
16 AWG (1.5 mm ²)	26	538 (1765)	1052 (3451)

Table 3-4: Maximum Distance from Power Source to Field Devices on the Tank for Different Cable Areas

Related information

Cable selection for the Tankbus

Example 1

The example illustrated in Figure 3-2 includes a tank located 300 m away from a Rosemount 2410 Tank Hub acting as power supply. In the calculations below it is assumed that the cable length between the field devices on the tank can be ignored.

The tank is equipped with the following field devices: a Rosemount 5900S Radar Level Gauge, a Rosemount 2240S Multi-input Temperature Transmitter, and a Rosemount 2230 Graphical Field Display. The total current consumption of the three devices is 110 mA (see Table 3-2).


G. Voltage drop=1.4 V

The total operating current of the connected field devices on the tank is 50+30+30 mA=110 mA. This is within the output capability of the Rosemount 2410 Tank Hub.

Calculations

The tank hub is powered by an intrinsically safe power supply: 12.5 V, 250 mA.

Voltage drop to the tank: 110 mA x 0.30 km x 42 Ω /km=1.4 V.

Voltage at the tank = 12.5 V - 1.4 V=11.1 V.

Result: the input voltage of 11.1 V to the field devices is above the minimum requirement of 9 V.

Related information

Power budget

Example 2

The second example, illustrated in Figure 3-3, includes two tanks with a Rosemount 2410 Tank Hub acting as power supply to the field devices on both tanks.

The first tank is located 300 m away from the Rosemount 2410 Tank Hub and the second tank a further 350 m away.

Both tanks have two field devices: a Rosemount 5408 Radar Level Transmitter and a Rosemount 644 Temperature Transmitter. The total current consumption of the two devices is 32 mA (see Table 3-2).

Figure 3-3: Example of Installation on Two Tanks



- A. Rosemount 2410 Tank Hub
- B. Tankbus
- C. 300 m
- D. Voltage drop=0.80 V
- E. (Spur < 60 m)
- F. Rosemount 5408 Level Transmitter
- G. Rosemount 644 Temperature Transmitter
- H. Segment coupler
- I. 350 m
- I. Voltage drop=0.47 V

The total operating current of the connected field devices on the two tanks is 32+32 mA=64 mA. This is within the output capability of the Rosemount 2410 Tank Hub.

Calculations

The tank hub is powered by an intrinsically safe power supply: 12.5 V, 250 mA.

Voltage drop to the first tank: 64 mA x 0.30 km x 42 Ω /km=0.80 V.

Voltage at first tank = 12.5 V - 0.80 V=11.70 V.

Voltage drop between first and second tank: 32 mA x 0.35 km x 42 Ω /km=0.47 V.

Voltage at second tank =12.5 V - 0.80 V - 0.47 V=11.23 V.

For both tanks the input voltage to the field devices is above the minimum requirement of 9 V.

The field devices may be connected to the Tankbus via segment couplers as illustrated in Figure 3-3. The spur length must not exceed 60 m according to the FISCO standard. In the example above, it is assumed that the voltage drop between the segment coupler and the devices can be ignored.

Related information

Power budget

Tankbus Segment coupler

In case "daisy-chain" connection is not suitable, a Tankbus Segment $Coupler^{(10)}$ can be used to connect the various devices.

Features:

- Entity and FISCO compliant
- adjustable short-circuit limit
- robust die-cast aluminium housing
- protection degree IP67
- integrated bus terminating resistor (switch integrated inside the housing)
- cable shielding: capacitive or direct connection to housing potential selectable via switch

Note

Sufficient equipotential bonding of the installation must be ensured. The device is connected via the bolt on the housing to the system's potentializer.

Figure 3-4: Dimensions (mm)



⁽¹⁰⁾ Part no. 6853511-493. Contact Emerson Automation Solutions/Rosemount Tank Gauging for more information.

Figure 3-5: Segment coupler features



- A. Switch for capacitive or direct connection between shield and housing potential
- B. Switch for activating terminating resistor
- C. Current limitation for all ports via a rotary switch; 30, 35, 45, or 60 mA
- D. Connection of housing potential
- E. LED power on indication
- F. LED short-circuit indication
- G. Trunk IN
- H. Trunk OUT
- I. Spurs
- J. Case ground

In case there are different device types connected to the segment coupler, set the current limitation switch (3) to the closest value above the largest current consumption of the connected devices. See Table 3-2 for information on current consumption for various Rosemount Tank Gauging devices.

Examples

Rosemount 5900S; set the switch to 60mA.

Rosemount 5300 and 5408; set the switch to 30 mA.

Rosemount 2230; set the switch to 35 mA.



Figure 3-6: Field Devices Connected via Segment Couplers

- E. Rosemount 644 Temperature Transmitter
- *F.* Segment coupler with active terminator (end of trunk)
- G. (Spur<60 m)
- H. Rosemount 2240S Temperature Transmitter
- I. Segment coupler

Related information

Power budget

3.4.8 Typical installations

System with devices connected to a Rosemount 2410 on a single tank

The example in Figure 3-7 illustrates a system with daisy-chained field devices on a single tank. Terminators are installed at both ends of the fieldbus segment as required in a FOUNDATION[™] Fieldbus system. In this example the terminators are enabled in the Rosemount 2410 Tank Hub and a field device (Rosemount 2240S) at the end of the network segment.

In addition to the field instruments on the Tankbus, Figure 3-7 illustrates how an instrument such as a pressure transmitter can be connected to the intrinsically safe 4 -20 mA analog input of the Rosemount 2410 Tank Hub.

Figure 3-7: Example of a System with Devices Connected to a Rosemount 2410 on a Single Tank



- A. Rosemount 2410 Tank Hub
- B. Rosemount 2230 Graphical Display
- C. Tankbus
- D. IS Analog Input (Secondary bus)
- E. Rosemount 3051S Pressure Transmitter
- F. Rosemount 5900S Radar Level Gauge
- G. Rosemount 2240S Multi-input Temperature Transmitter
- H. Built-in terminator enabled on the last device
- I. Tankbus length up to 1000 meter depending on number of devices and cable type

The Rosemount 2410 Tank Hub has a built-in terminator and intrinsically safe power supply with integrated power conditioner. The maximum distance between the Rosemount 2410 Tank Hub and the field devices depends on the number of devices connected to the Tankbus and cable type.

Maximum number of HART Slave devices:

- Passive current loop: 5
- Active current loop: 3

See Cable selection for the Tankbus and Tankbus for more information about cable selection and the Tankbus.

Non I.S. current loop alternative options:

- 1. Passive current loop. Input voltage range: 10.5 35 V
- 2. Active current loop. Output voltage range: 12.8 24 V @ 21.75 0 mA.

I.S. current loop alternative options:

- 1. Passive current loop. Input voltage range: 10.5 30 V
- 2. Active current loop. Output voltage range: 6.2 23 V @ 21.75 0 mA.

Note polarity for connection of polarity sensitive buses and I/O (for example RS485 and analog I/O).

See Intrinsically safe terminal block for information on the Intrinsically Safe terminal block.

See Specifications and reference data for more information on electrical characteristics for analog input and output.

2-in-1 version of the Rosemount 5900S in a SIL safety installation

Figure 3-8 illustrates an example with a 2-in-1 version of the Rosemount 5900S in a SIL safety installation. A 4-wire cable is used to connect the Primary and Secondary Tankbuses through the same cable entry. The SIL alarm wire is connected through a separate cable entry. A junction box provides sufficient number of connections for the field devices to the Primary and Secondary Tankbus.

Primary Tank Hub is connected to the electronic unit of the 5900S 2-in-1 level gauge for SIL overfill alarm.

Secondary Tank Hub is connected to the 5900S electronic unit used for level measurements.



Figure 3-8: SIL System with a Rosemount 5900S 2-in-1 Connected to Separate Tank Buses

- A. Pressure transmitter
- B. Rosemount 2240S Temperature Transmitter
- C. Rosemount 5900S Radar Level Gauge
- D. 4-wire cable for connection of Primary Tankbus and Secondary Tankbus
- E. Primary Rosemount 2410
- F. Secondary Rosemount 2410
- G. Primary Tankbus
- H. Rosemount 2230
- I. Junction box
- J. Secondary Tankbus
- K. Terminators for Primary and Secondary Tankbus

Rosemount 2410 Tank Hub connected to several field devices at the end of the Tankbus (fieldbus segment)

Figure 3-9 illustrates an example with four tanks connected to a Rosemount 2410 Tank Hub (requires Rosemount 2410 with multiple tanks option). The field devices are connected to a segment coupler at the end of the Tankbus.

A separate bus terminator is not required if one of the field devices with built-in terminator is connected at the end of the fieldbus segment. There are other options available as well, for example using a separate terminator plugged into the segment coupler, or a segment coupler with integrated bus terminator.

Figure 3-9: Example of a Rosemount Tank Gauging System with a Rosemount 2410 Tank Hub Connected to Several Field Devices at the end of the Tankbus (Fieldbus Segment)



- A. Rosemount 2410 Tank Hub
- B. Tankbus length up to 1000 meter depending on number of devices and cable type
- C. Tankbus
- D. (Trunk)
- E. Field Communicator
- F. (Spurs < 60 m)
- G. Rosemount 5408 Level Transmitter
- H. Rosemount 644 Temperature Transmitter
- I. Segment coupler with integrated bus terminator
- J. Rosemount 2230 Display
- K. Rosemount 2240S Temperature Transmitter

The Rosemount 2410 Tank Hub has a built-in terminator and intrinsically safe power supply with integrated power conditioner.

Note that the total length of the Tankbus (fieldbus segment) must be within the FISCO specifications and the spurs must not exceed 60 meter, see Cable selection for the Tankbus.

Several tanks daisy-chained to a Rosemount 2410

Figure 3-10 illustrates an example with a number of field devices daisy-chained to a Rosemount 2410 Tank Hub (requires multiple tanks option).

If a field device is connected to the end of the Tankbus (fieldbus segment), the built-in terminator can be used. Another option is to use a separate bus terminator.

Figure 3-10: Example of a Rosemount Tank Gauging system with several tanks daisychained to a Rosemount 2410



- A. Rosemount 2410 Tank Hub
- B. Tankbus
- C. Rosemount 2230 Display
- D. Rosemount 5408 Level Transmitter
- E. Rosemount 644 Temperature Transmitter
- F. Tankbus length up to 1000 meter depending on number of devices and cable type
- G. Rosemount 2230 Display with built-in terminator

The Rosemount 2410 Tank Hub has a built-in terminator and intrinsically safe power supply with integrated power conditioner.

Note that the total length of the Tankbus (fieldbus segment) must be within the FISCO specifications, see Cable selection for the Tankbus.

Three tanks connected to the Tankbus via segment couplers

Figure 3-11 illustrates an example with three tanks connected to a Rosemount 2410 Tank Hub (requires multiple tanks option). For each tank the field devices are connected to the Tankbus via a segment coupler.

The fieldbus segment needs to be terminated at both ends. A terminator is enabled in the Rosemount 2410 Tank Hub. At the end of the fieldbus segment you may use the built-in

terminator in one of the field devices, or an external terminator plugged into one of the devices, or a segment coupler with integrated bus terminator.





- A. Rosemount 2410 Tank Hub
- B. Rosemount 2230
- C. Rosemount 5408 Level Transmitter
- D. Tankbus length up to 1000 meter depending on number of devices and cable type
- E. Rosemount 644 Temperature Transmitter
- F. Tankbus
- G. (Spur < 60 m)
- H. Segment coupler
- I. Rosemount 2230 Display with built-in terminator

The Rosemount 2410 Tank Hub has a built-in terminator and intrinsically safe power supply with integrated power conditioner.

Note that the total length of the Tankbus (fieldbus segment) must be within the FISCO specifications and the spurs must not exceed 60 meter, see Cable selection for the Tankbus.

Rosemount Tank Gauging system with external terminator

In case the last device on the Tankbus has no internal terminator, an external terminator⁽¹¹⁾ according to FISCO model and Entity model can be used instead. It can be screwed into a free cable gland on the device.

⁽¹¹⁾ Part no. 6853511-494. Contact Emerson Automation Solutions/Rosemount Tank Gauging for more information.



Figure 3-12: Example of Rosemount Tank Gauging System with External Terminator

- A. Rosemount 2410 Tank Hub with intrinsically safe power supply, integrated power conditioner, and built-in terminator
- B. Rosemount 2230 Display
- C. Rosemount 644 Temperature Transmitter
- D. Rosemount 5300 Level Transmitter
- E. External terminator
- F. Red+
- G. Black-
- H. ½ inch NPT

Related information

Tankbus

Cable selection for the Tankbus

3.4.9 Cabling for the TRL2/RS485 Bus

A standard Rosemount Tank Gauging system includes one or several Rosemount 2410 Tank Hubs communicating with a Rosemount 2460 System Hub using the TRL2/RS485 Modbus protocol as shown in Communication.

TRL2 Bus

The TRL2 bus requires twisted and shielded pair wiring with a minimum cross-sectional area of 0.50 mm² (AWG 20 or similar). The maximum length of the TRL2 bus is approximately 4 km /13000 ft. The TRL2 field bus can normally use existing cables in the tank area.

Cable cross-sectional area for the TRL2 wiring should follow the recommendations in Table 3-5.

Table 3-5: Minimum Cable Area for the TRL2 Bus

Maximum distance	Minimum cross-sectional area
3 km	0.50 mm ² (AWG 20)
4 km	0.75 mm ² (AWG 18)

Note

Wherever two or more TRL2 buses run alongside each other, sharing the same cable or conduit tube, use twisted and shielded wire and ensure that each pair of bus wires is individually shielded in order to avoid crosstalk.

Figure 3-13: Individually Shielded Pair Cables Minimizes Crosstalk



Table 3-6 shows typical cable types that can be used for connecting the TRL2 bus. Other cables of similar type may also be used.

Table 3-6: Recommended Cable Standards for the TRL2 Bus

Туре	Manufacturing standard	Core size
Signal	BS 5308 part 1, type 1	1 mm ²
Signal (armoured)	BS 5308 part 2, type 1	1 mm ²

RS485 Bus

The RS485 bus should meet the following requirements:

- twisted and shielded pair wiring
- characteristic impedance of 120 Ω
- maximum cable length 1200 m / 4000 ft.

3.4.10 Non-IS connection

The non-IS explosion-proof/flameproof compartment has a terminal block for connecting power supply, communication buses to host systems, relay outputs, and HART[®] 4-20 mA analog input and output.

Prerequisites

Note

Ensure that o-rings and seats are in good condition prior to mounting the cover in order to maintain the specified level of ingress protection. The same requirements apply for cable inlets and outlets (or plugs). Cables must be properly attached to the cable glands.

Procedure

- 1. A Ensure that the power supply is switched off.
- 2. Ensure that the cover jam screw (F) (see Figure 3-14) is completely threaded into the housing. It is intended to disallow the removal of the transmitter cover in flameproof environments without the use of tooling. The cover jam screw is threaded into the housing at factory.
- 3. Remove the cover on the non-IS terminal compartment.
- 4. Run the wires through the cable gland/conduit. Install wiring with a drip loop in such a way that the lower part of the loop is under the cable/conduit entry.
- 5. Connect wires to the terminal block. See Table 3-8 for information on the terminal block connections.
- 6. Use the enclosed metal plug to seal any unused port.
- 7. \triangle Tighten the conduits/cable glands.
- 8. A The cover on the terminal compartment should be tightened to mechanical stop (metal to metal). Make sure the cover is fully engaged to meet explosion-proof requirement and to prevent water from entering the terminal compartment.
- 9. Loosen the cover jam screw until it contacts the cover. Turn the jam screw an additional 1/2 turn counterclockwise to secure the cover.

Note

Application of excessive torque may strip the threads.

10. Verify that the cover cannot be removed.

Figure 3-14: Non-IS Terminal Compartment





- D. Cable entries
- E. Terminal block
- F. Cover jam screw

Conductor recommendations

Ensure that you use cables suitable for the terminal block of the Rosemount 2410. The terminal block is designed for cables that meet the specifications as illustrated in Figure 3-15.

Figure 3-15: Conductor and Insulation Requirements



A. Stripping length: 10 mm

B. Conductor cross-sectional area, see Table 3-7

Table 3-7: Terminal Connection for Details for End User

Туре	Rated (V)	Rated (A)	Strip length (mm)	Solid wire size (mm²)	Stranded wire size (mm ²)	Flexible wire size (mm ²)	Clamping range (mm ²)	Resistance (MΩ)
ZDUB 2.5-2/2AN	550	21	10	0.5 - 4	0.5 - 2.5	0.5 - 2.5	0.13 - 4	1.33
ZDUB 2.5-2/4AN	550	21	10	0.5 - 4	0.5 - 2.5	0.5 - 2.5	0.13 - 4	1.33

No other wire sizes or types than the ones specified in instructions must be used. The terminal blocks must either be mounted next to another block of the same type and size or with an end plate.

Manually cut cross connections and cross connections with blank ends [ZQV's >=20 poles) shall not be used.

Connect the conductor to the terminal block

Procedure

Use a screw driver to insert the conductor into the terminal block as illustrated in Figure 3-16

Figure 3-16: Connecting the Conductor to the Terminal Block





3.4.11 Non-IS terminal block

Figure 3-17: Terminal Block in the Explosion-proof/flameproof Compartment



A. Ground screw

B. Ground screws for communication bus shields

Table 3-8: Terminal Assignment for Non-intrinsically Safe Side (XP/Exd/Exe)

Terminal	Designation	Function	
1	N / -	Power, Neutral / DC -	
2	L/+	Power, Line / DC +	
3	K1 A	Relay 1 output (optional). Hardware configurable NO/NC.	
4	K1 com	Relay 1 common	
5	K2 A	Relay 2 output (optional). Hardware configurable NO/NC.	
6	K2 com	Relay 2 common	
7a/7b	P Bus B	Primary communication bus	
8a/8b	P Bus A		
9	S Pwr -	Secondary bus power - (optional)	
10	S Pwr +	Secondary bus power +(optional)	
11	S Bus B	Secondary communication bus - (optional)	
12	S Bus A	Secondary communication bus + (optional)	
PE	PE	Power supply protective ground	
GND_1	GND_1	Housing chassis/shield Primary bus	
GND_2	GND_2	Housing chassis/shield Secondary bus	

Power supply

The Rosemount 2410 accepts supply voltage 24-48 Vdc and 48-240 Vac (50/60 Hz).

Primary communication bus

The Rosemount 2410 communicates with a host or a 2460 System Hub via TRL2 Modbus or RS-485 Modbus protocol.

Secondary communication bus

The secondary bus can be used for communication using a number of protocols such as TRL2 Modbus, HART 4-20 mA, Enraf, Varec and L&J.

Relay outputs

There are two optional relay outputs. You can choose Normally Open (NO) or Normally Closed (NC) by setting a switch as described in Relay output configuration.

NO and NC refers to the contact position when a relay is deenergized. This is also referred to as the Alarm state. The terminology can be summarized as follows:

Table 3-9: Designation of Relay Contact Positions

Normally C	Closed (NC)	Normally Open (NO)		
Deenergized	Energized	Deenergized	Energized	
Closed	Open	Open	Closed	
Not active	Active	Not active	Active	
Alarm (Reset)	Normal	Alarm (Reset)	Normal	

Note

Ensure that maximum current through the relays does not exceed the specifications in Specifications and reference data.

Related information

Relay output configuration Configure a virtual relay output

Non-IS terminal block for SIL safety systems

For Safety Integrity Level (SIL) systems the Rosemount 2410 has a terminal block on the Non-IS side with connection to a SIL Alarm Relay output.

Figure 3-18: Non-IS (XP/Exd/Exe) Terminal Block



- A. Ground screw
- B. Ground screws
- C. SIL Relay

Table 3-10: Terminal Assignment for SIL Version of the Rosemount 2410 Non-IS Terminal Block

Terminal	Designation	Function	
1	N / -	Power, Neutral / DC -	
2	L/+	Power, Line / DC +	
3	K1 A	Relay 1 output (optional). Hardware configurable NO/NC.	
4	K1 com	Relay 1 common	
5	K2 A	Relay 2 output (optional). Hardware configurable NO/NC.	
6	K2 com	Relay 2 common	
7a/7b	P Bus B	Primary communication bus	
8a/8b	P Bus A		
9		Not used	
10		Not used	
11	Alarm B	SIL Alarm Relay B	
12	Alarm A	SIL Alarm Relay A	
PE	PE	Protective power supply ground	
GND_1	GND_1	Housing chassis/shield Primary bus	
GND_2	GND_2	Housing chassis/shield Secondary bus	

3.4.12 IS connection

The IS compartment has a terminal block for connecting the intrinsically safe Tankbus for communication with field devices on the tank. This terminal block is also used for intrinsically safe HART 4-20 mA analog input/output communication.

Prerequisites

Note

Ensure that o-rings and seats are in good condition prior to mounting the cover in order to maintain the specified level of ingress protection. The same requirements apply for cable inlets and outlets (or plugs). Cables must be properly attached to the cable glands.

Procedure

- 1. \triangle Make sure that the power supply is switched off.
- 2. Remove the cover on the IS terminal compartment.
- 3. Pull the cable through the cable gland/conduit. Install cables with a drip loop in such a way that the lower part of the loop is under the cable/conduit entry.
- 4. Connect wires according to Table 3-11.
- 5. Use the enclosed metal plug to seal any unused port.
- 6. Tighten the conduit/cable gland.
- 7. A The cover on the terminal compartment should be tightened to mechanical stop (metal to metal). Make sure the cover is fully engaged to meet explosion-proof requirement and to prevent water from entering the terminal compartment.

Figure 3-19: IS terminal compartment





- A. IS compartment
- B. Wiring with drip loop
- C. Terminal block
- D. Ground screws
- E. Cable entries

3.4.13 Intrinsically safe terminal block

The Intrinsically safe side of the Rosemount 2410 Tank Hub connects to the Tankbus which communicates with field devices on the tank.

Figure 3-20: Intrinsically Safe Terminal Block



A. Ground screws

Table 3-11: Terminal Assignment for Intrinsically Safe Side

Terminal	Designation	Function
1a	FB +	Intrinsically Safe Tankbus positive (+) terminal
1b	FB +	Intrinsically Safe Tankbus positive (+) terminal
2a	FB -	Intrinsically Safe Tankbus negative (-) terminal
2b	FB -	Intrinsically Safe Tankbus negative (-) terminal
3	IS I/O+	IS Input/Output + HART / 4-20 mA (Secondary Bus)
4	IS I/O -	IS Input/Output - HART / 4-20 mA (Secondary Bus)
5	W3	Notuced (future option)
6	W4	Not used (luture option)
GND_1	GND_1	Housing chassis/Tankbus shield
GND_2	GND_2	Housing chassis/Tankbus shield

Tankbus

The devices on the tank communicates with the Rosemount 2410 via the intrinsically safe Tankbus. All field devices in the Rosemount Tank Gauging system have built-in communication modems for FISCO FOUNDATION[™] Fieldbus (FF) communication and will automatically communicate with the Rosemount 2410 when connected to the Tankbus.

Optional secondary bus

In addition to the Tankbus an optional intrinsically safe bus is available for communication with devices not compatible with FOUNDATION[™] Fieldbus. It allows you to connect devices for intrinsically safe HART 4-20 mA analog input/output communication.

IS terminal block for SIL safety systems

For Safety Integrity Level (SIL) systems the Rosemount 2410 has a terminal block with a SIL Alarm output for connection to a Rosemount 5900S Radar Level Gauge.

Figure 3-21: IS/Exi Terminal Block for SIL Systems



B. Ground screws

Table 3-12: Terminal Assignment for SIL Version of the Rosemount 2410 IS Terminal Block

Terminal	Designation	Function
1a	FB +	Intrinsically Safe Tankbus positive (+) terminal
1b	FB +	Intrinsically Safe Tankbus positive (+) terminal
2a	FB -	Intrinsically Safe Tankbus negative (-) terminal
2b	FB -	Intrinsically Safe Tankbus negative (-) terminal
3	IS I/O+	IS Input/Output +
4	IS I/O -	IS Input/Output -
5	Alarm -	SIL Alarm input - (connect to terminal block on Rosemount 5900S)
6	Alarm +	SIL Alarm input+ (connect to terminal block on Rosemount 5900S)
GND_1	GND_1	Housing chassis/Tankbus shield
GND_2	GND_2	Housing chassis/Tankbus shield

3.4.14 Wiring diagrams

Figure 3-22: Wiring Diagram on the Intrinsically Safe (IS/Exi) Side



- A. Rosemount 2410
- B. Terminal block on intrinsically safe side
- C. Not used (future option)
- D. SIL systems: Alarm
- E. IS secondary bus
- F. Intrinsically safe Tankbus
- G. Rosemount 2230
- H. Rosemount 5900S
- I. Rosemount 2240S



Figure 3-23: Wiring Diagram on the Non-intrinsically Safe (XP/Exd/Exe) Side

- F. Secondary power
- G. Primary bus
- H. Modem



Figure 3-24: Wiring Diagram for Rosemount 2410 and Rosemount 5900S in a SIL Safety System

- D. Tankbus
- E. Rosemount 5900S Radar Level Gauge

4 Configuration

4.1 Safety messages

Instructions and procedures in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that potentially raises safety issues is indicated by a warning symbol (\triangle). Refer to the following safety messages before performing an operation preceded by this symbol.

AWARNING

Failure to follow safe installation and servicing guidelines could result in death or serious injury.

- Ensure only qualified personnel perform the installation.
- Use the equipment only as specified in this manual. Failure to do so may impair the protection provided by the equipment.
- Do not perform any services other than those contained in this manual unless you are qualified.

Explosions could result in death or serious injury.

- Verify that the operating environment of the device is consistent with the appropriate hazardous locations certifications.
- Before connecting a handheld communicator in an explosive atmosphere, ensure that the instruments in the loop are installed in accordance with intrinsically safe or non-incendive field wiring practices.
- Do not remove the gauge cover in explosive atmospheres when the circuit is alive.

4.2 Introduction

A Rosemount[™] Tank Gauging system includes a wide range of devices for tank monitoring. It is a flexible and scalable system which can be adapted to various applications and small or large tank farms. A typical system includes one or more of the following devices:

- control room PC with Rosemount TankMaster program for operational control
- Rosemount 2460 System Hub that collects measurement data from Rosemount 2410 Tank Hubs
- Rosemount 2410 Tank Hub which collects measurement data from field devices on the tanks
- various field instruments such as the Rosemount 5900S Radar Level Gauge, Rosemount 2240S Multi-input Temperature Transmitter, Rosemount 2230 Graphical Field Display, Rosemount 3051S Pressure Transmitter
- Emerson Wireless Gateway and Emerson Wireless THUM Adapter for wireless communication between field devices and control room host system

See the Rosemount Tank Gauging System Data Sheet (Document no. 00813-0100-5100) for a comprehensive description of the components in a Rosemount Tank Gauging system.

4.3 Configuration tools

The Rosemount 2410 Tank Hub is configured by using the Rosemount TankMaster Winsetup configuration program. Winsetup is a user-friendly software package that includes basic configuration options as well as advanced configuration and service functions.

See the Rosemount Tank Gauging System Configuration Manual (Document no. 00809-0300-5100) for more information on how to use the TankMaster WinSetup software to configure the Rosemount 2410 Tank Hub.

See also the Rosemount Wireless Tank Gauging System Reference Manual (Document no. 00809-0100-5200) for information on how to set up a Rosemount 2410 in a *Wireless*HART[®] system.

4.4 Basic configuration of a Rosemount 2410 Tank Hub

This is a general description of how to configure a Rosemount 2410 Tank Hub. The Rosemount Tank Gauging System Configuration Manual (Document no. 00809-0300-5100) provides a detailed description of how to use the Rosemount TankMaster WinSetup program as a configuration tool for the Rosemount 2410.

Communication

Depending on the particular system configuration, a Rosemount 2410 Tank Hub may communicate directly with a host computer or via a Rosemount 2460 System Hub.

In case the Rosemount 2410 is connected to a Rosemount 2460 System Hub, you will have to specify which communication protocol channel to be used.

The Rosemount 2410 has default Modbus[®] address=247. The address should be changed to the recommended address range. The Modbus address must match the address specified in the Rosemount 2460's tank database.

The Rosemount 2410 Tank Hub can be used in a *Wireless*HART system by connecting an Emerson Wireless THUM[™] Adapter. The THUM adapter allows the Rosemount 2410 to communicate with a host system via an Emerson Wireless Gateway.

Tank database

The Rosemount 2410 has a tank database that maps field devices to tanks. It also stores Modbus addresses of level gauges and auxiliary tank devices (ATD) such as the Rosemount 2240S Multi-input Temperature Transmitter. The Modbus addresses are used for communication with Rosemount 2460 System Hub and host computers.

Device tags

For each tank, device tags are specified for the level gauge and the auxiliary tank devices (ATD). ATD devices include all instruments on the tank except the level gauge. Device tags are used as identifiers in TankMaster.

Integral display

The Rosemount 2410 can be configured to present measurement data on the optional integral display. The display alternates between the selected items at a rate given by the Display Toggle Time parameter.

Measurement data such as Level, Level Rate, Free Water Level and many other tank variables can be displayed.

Measurement units for Level, Level Rate, Volume, Temperature, Density, and Pressure can be specified regardless of which units are used for presentation in, for example, the TankMaster programs.

4.5 Advanced configuration

The installation wizard in TankMaster Winsetup comprises a basic configuration of the Rosemount 2410. There are more options available in case further configuration is needed:

- Primary/Secondary Bus configuration
- Up to ten "virtual" Relay Functions
- Hybrid Density
- Delta Level
- Analog Output
- Analog Input / HART Slave⁽¹²⁾

Related information

Advanced configuration

4.6 Configuration using TankMaster WinSetup

A Rosemount 2410 Tank Hub can easily be installed and configured by using the TankMaster Winsetup configuration program. The WinSetup installation wizard guides you through the basic configuration needed for starting up a Rosemount 2410.

See the Rosemount Tank Gauging System Configuration Manual (Document no. 00809-0300-5100) for more information on using the TankMaster WinSetup software to configure a Rosemount Tank Gauging system and a Rosemount 2410 Tank Hub.

See also the Rosemount Tank Gauging Wireless System Reference Manual (Document no. 00809-0100-5200) for information on how to set up a *Wireless*HART[®] system.

4.6.1 Installation wizard

The TankMaster WinSetup wizard is the recommended tool for installing the Rosemount 2410 and supports basic configuration. To start the installation wizard:

⁽¹²⁾ Analog Input and HART Slave functions are configured in the Properties window of Auxiliary Tank Device (ATD), see Configuration of analog input / HART[®] slave device.

Procedure

1. In the WinSetup workspace select the **Devices** folder.



- 2. Right-click and select Install New, or from the menu bar select Devices → Install New.
- 3. Choose device type Rosemount 2410 Tank Hub.
- 4. Follow the instructions in the installation wizard.

Need help?

See the Rosemount Tank Gauging System Configuration Manual (Document no. 00809-0300-5100) for more information on using the TankMaster WinSetup program to configure the Rosemount 2410.

4.6.2 Advanced configuration

Advanced options such as the Secondary Bus, Relay Output and Hybrid Density are available in the *Rosemount 2410 Properties* window. See Advanced configuration for more information.

4.6.3 Installing a Rosemount 2460 System Hub

In case the Rosemount Tank Gauging system includes a Rosemount 2460 System Hub, it should be installed prior to installing the Rosemount 2410 Tank Hub. Installation includes the following basic steps:

Prerequisites

Ensure that the Rosemount TankMaster WinSetup program is up and running.

Procedure

- 1. Enable and configure a Protocol Channel in order to establish communication with the appropriate port on the TankMaster PC.
- 2. Start the installation wizard in TankMaster WinSetup.
 - a) Right-click the **Devices** folder.

- b) Select Install new.
- 3. Choose device type 2460 System Hub.

460 System Hub	•		P
2460 System Hub <u>T</u> ag:	1		2
SYSHUB-		EMERSON	
		ROSEMOUNT	
			2
Install Offline			

- Specify a name tag in the 2460 System Hub Tag input field. This tag will be used as an identifier of the system hub in various windows and dialogs.
- 5. Click the **Next** button to proceed with the installation wizard.
- 6. Verify communication with the host computer/TankMaster PC.
- 7. Verify that Host ports and Field ports are properly configured.

Host ports are used for communication with TankMaster work stations or other host systems. Field ports are used for communication with field devices such as the Rosemount 2410 Tank Hub, the Rosemount 5900S Radar Level Gauge, and others.

8. Configure the tank database. Ensure that Modbus Addresses of the connected devices are properly set. These addresses must correspond to the Rosemount 2410 Tank Hub database settings.

Need help?

See the Rosemount 2460 System Hub Reference Manual for more information on how to setup the Rosemount 2460 System Hub.

5 Operation

5.1 Safety messages

Instructions and procedures in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that potentially raises safety issues is indicated by a warning symbol (\triangle). Refer to the following safety messages before performing an operation preceded by this symbol.

A WARNING

Failure to follow safe installation and servicing guidelines could result in death or serious injury.

- Ensure only qualified personnel perform the installation.
- Use the equipment only as specified in this manual. Failure to do so may impair the protection provided by the equipment.
- Do not perform any services other than those contained in this manual unless you are qualified.

Explosions could result in death or serious injury.

- Verify that the operating environment of the device is consistent with the appropriate hazardous locations certifications.
- Before connecting a handheld communicator in an explosive atmosphere, ensure that the instruments in the loop are installed in accordance with intrinsically safe or nonincendive field wiring practices.
- Do not remove the gauge cover in explosive atmospheres when the circuit is alive.

5.2 Integral display

The Rosemount[™] Rosemount 2410 Tank Hub can be equipped with an optional integral display for presentation of measurement data and diagnostics. When the device is switched on, the display presents information such as device model, communication protocol (Modbus[®], Enraf, etc.) and address, relay configuration, software version, serial number, unit ID, and write protection status. See Table 5-2 for more information on start-up information.

When the Rosemount 2410 is up and running the display presents Level, Signal Amplitude, Volume and other measurement variables depending on how the display is configured. The available parameters are listed in Table 5-1.

The display has two rows for data presentation. The upper row shows tank name (up to six characters) and measurement values. The lower row shows variable type and measurement unit.

You can specify which variables to present on the display by using a configuration tool such as the Rosemount TankMaster WinSetup program, see Specifying display variables for more information.

The display toggles between different measurement values and units at a rate which can be configured by using the WinSetup program.



- A. Measurement value
- B. Toggling between measurement variable and measurement unit
- C. Write protection switch

Variable	Presentation on display	Description
Level	LEVEL	Product level
Ullage	ULLAGE	Distance from the upper reference point to the product surface
Level Rate	LRATE	The speed of level movement up or down
Signal Strength	SIGN S	Signal amplitude of the surface echo
Free Water Level	FWL	Free water level at the bottom of the tank
Vapor Pressure	VAP P	Automatic or manual Vapor Pressure value
Liquid Pressure	LIQ P	Automatic or manual Liquid Pressure value
Air Pressure	AIR P	Automatic or manual Air Pressure value
Ambient Temperature	AMB T	Automatic or manual Ambient Temperature value
Vapor Average Temperature	VAP T	Average temperature of vapor above the product surface
Liquid Average Temperature	LIQT	Average temperature for all spot sensors submersed in liquid
Tank Average Temperature	TANK T	Average value of all temperature sensors in the tank
Spot 1 Temperature	TEMP 1	Temperature value for spot sensor no. 1
Spot n Temperature	TEMP n	Temperature value for spot sensor no. "n"
Spot 16 Temperature	TEMP 16	Temperature value for spot sensor no. 16
Observed Density	OBS D	Automatic or manual Observed Density
Reference Density	REF D	Product density at standard reference temperature 15°C (60°F)
Volume	TOV	Total observed volume
Flow Rate	FRATE	Flow rate
User Defined 1	UDEF 1	Up to 5 user defined variables
Tank Height	TANK R	Distance from Tank Reference Point to Zero Level
Delta Level	ΔLVL	The difference between two level values

Table 5-1: Measurement Variables and Presentation on the Rosemount 2410 Display

5.3 Start-up information

When the Rosemount 2410 starts up, all LCD segments light up for approximately 5 seconds. The start-up information appears on the display when the software initialization procedure is finished. The Primary Bus configuration appears first, followed by the Secondary Bus configuration. Each item appears a few seconds on the display:

Item	Example
Model number and type (multiple / single tank version)	Rosemount 2410 MULTI
Primary communication bus hardware option (TRL2, RS485, Enraf GPU, HART® master, HART slave)	PR HW RS-485 HART M HART S SIL AR
Primary communication bus protocol	PRI MODBUS
Primary Bus communication address	ADDR 247
Primary Bus communication settings (Baud rate, stop bits and parity)	9600 1 0
Secondary communication bus hardware option (TRL2, Enraf GPU, HART wireless, HART master, HART slave, other emulation options)	EN GPU HART W HART M HART S SIL AR
Secondary communication bus protocol	SEC ENRAF
Secondary Bus communication address	10
Secondary Bus communication settings (Baud rate, stop bits and parity)	1200 1 0
Software version	1.B1 SW
Serial number	SN 12 345678
Unit ID (when Modbus is available on Primary or Secondary bus)	UNID 23456
Write protection status (ON/OFF)	ON W PROT
Relay option	K2 RELAY

Table 5-2: Start-up Information on the Rosemount 2410 Display

5.4 Error codes

In addition to presenting measurement values, the display can show software and hardware error messages. In case of an error, the upper row shows "ERROR" and the lower row toggles between "FAIL" and the error code.


Figure 5-2: Error Codes can be Presented on the Rosemount 2410 Display

The following error codes are used:

Table 5-3: List of Error Codes and Messages that may Appear on the Display

Code	Error	
RAM	Ram failure	
FPROM	FPROM	
HREG	Holding register error	
OMEM	Other memory error	
SYS	System error	
DPLY	Display error	
AUX	AUX	
FF ST	FF stack	
TBUS	Tank Bus	
HOST C	Host	
D MNGR	Data manager	
CFG	Invalid Configuration	
SW	Software	

Related information

Error messages

5.5 LED

There are three Light Emitting Diodes (LED) on the Rosemount 2410 front for status and error information.

Figure 5-3: The Rosemount 2410 has Three LEDs



- A. Error LED (Red)
- B. Status LED (Yellow)
- C. Power On LED (Green)

The following color codes are used for the Rosemount 2410 LEDs:

Table 5-4: LED Color Codes

LED Type	Color	Description
Power On	Green	The green LED indicates that the Rosemount 2410 is powered on.
Status	Yellow	The yellow Status LED blinks at a constant rate of one flash every other second in normal operation to indicate the Rosemount 2410 software is running
Error	Red	The red Error LED is turned off in normal operation. If an error occurs, the Error LED flashes a sequence that corresponds to a certain error code.

Related information

Error LED

5.5.1 LED start-up information

When the Rosemount 2410 is starting, both the Status and the Error LEDs indicate possible hardware or software errors as shown in Table 5-5:

Error type	Status LED	Error LED	Description
Hardware	Blinking	Blinking	Status and Error are blinking simultaneously
Checksum	Blinking	Blinking	Status and Error are toggling
Other	On	Blinking	Unknown error

Table 5-5: LEDs Are Used for Error Indication at Rosemount 2410 Start-up

5.5.2 Error LED

In normal operation the Error LED (Red) is turned off. In case a device error occurs, the LED will flash a sequence that corresponds to the error code followed by a five second pause.



Figure 5-4: Error Codes are Presented by the Error LED

The following errors codes may appear:

	Table	5-6:	LED	Error	Codes
--	-------	-------------	-----	-------	-------

Code	Error type
1	FPROM
2	HREG
3	Software
4	Other memory error
5	System
6	Display
7	Aux
8	FF stack
9	Tankbus
10	Host communication
11	Data manager
12	Configuration

Example

In case of a device error, the red LED will repeat a flash sequence that corresponds to the particular type of error that occurred. For example, in case of a Display error (code=6), the LED will show a sequence of 6 flashes followed by a 5 seconds pause. After the pause the flashing starts over again in the same manner. This flash/pause sequence will be continuously repeated.

Display error (code 6) appears with the following Error LED (red) flash sequence as illustrated in Figure 5-5:



Related information

Error messages

5.6 Specifying display variables

The Rosemount 2410 can be configured to present measurement data on the optional integral display. Measurement data such as Level, Level Rate, Free Water Level and many other tank variables can be displayed.

Measurement units for Level, Volume, Temperature, Density, Pressure, and Weight can be specified.

The display will alternate between the selected items at a rate given by the **Display Toggle Time** parameter.

When the Rosemount 2410 is installed and configured, the display can easily be set up with the Rosemount TankMaster WinSetup program to show tanks and measurement variables. The current display settings can be changed at any time in the *Rosemount 2410 Local Display* window as shown below:

Procedure

- 1. In the *Rosemount TankMaster WinSetup* configuration program, right-click the Rosemount 2410 icon.
- 2. Choose the **Properties** option.
- 3. In the Rosemount 2410 Tank Hub window, select the Local Display tab.

Units For Dis Level: Pressure:	splay m bar A	Level Densi	Rate: m/h	Temperature: Volume:	deg C 🔹	
Common Ta Display T TK-1 TK-1 (Tar (Tar (Tar (Tar	nk Configuration anks 2 3 1k Pos 4) 1k Pos 5) 1k Pos 5) 1k Pos 7) 1k Pos 8) 1k Pos 9) 1k Pos 9)	Display Tank Paramete V Level Ullage Level Rate Signal Strength FV/L Vapor Pressure Liquid Pressure Air Pressure Air Pressure Air Temperature	Vapor Temperature Vapor Temperature Tank Temperature Temperature 1 Temperature 2 Temperature 3 Temperature 4 Temperature 4 Temperature 6 Temperature 7	Temperature 8 Temperature 9 Temperature 10 Temperature 11 Temperature 12 Temperature 13 Temperature 14 Temperature 16 Observed Density	Reference Density Flow Rate Volume User Defined 1 User Defined 2 User Defined 3 User Defined 4 User Defined 5 Tank Height Delta Level	
Display Tog Individual Ta	gle Time: 3 ank Configuration	Seconds				

- 4. Select the desired tanks and tank parameters such as Level, Temperature, Vapor Pressure, or any other preferred tank parameter.
- 5. Choose measurement units for the Rosemount 2410 integral display.

The first time the *Local Display* tab is opened, the same measurement units are used as specified in the TankMaster WinSetup *Server Preferences/Units* window.

6. Click the **Individual Tank Configuration** button in case you would like to specify different display settings for different tanks.

Display Tanks	Display Tank Paramete	ers		
TK-1	Level	Vapor Temperature	Temperature 8	Reference Densit
C TK-2	Ullage	🔽 Liquid Temperature	Temperature 9	Flow Rate
○ TK-3	Level Rate	🔲 Tank Temperature	Temperature 10	Volume
🔘 (Tank Pos 4)	📃 Signal Strength	Temperature 1	Temperature 11	User Defined 1
🔘 (Tank Pos 5)	FWL	Temperature 2	Temperature 12	🔲 User Defined 2
🔘 (Tank Pos 6)	Vapor Pressure	Temperature 3	Temperature 13	🔲 User Defined 3
🔘 (Tank Pos 7)	Middle Pressure	Temperature 4	Temperature 14	🔲 User Defined 4
🔘 (Tank Pos 8)	Liquid Pressure	Temperature 5	Temperature 15	User Defined 5
🔘 (Tank Pos 9)	Air Pressure	Temperature 6	Temperature 16	🔲 Tank Height
🔘 (Tank Pos 10)	Air Temperature	Temperature 7	Observed Density	🔲 Delta Level

- 7. Click the **OK** button to save the configuration and close the window.
- 8. In the *Rosemount 2410 Tank Hub* window click the OK button to save the configuration and close the window.

Need help?

See the Rosemount Tank Gauging System Configuration Manual (Document no. 00809-0300-5100) for more information on using the TankMaster Winsetup PC software to configure the Rosemount 2410 Tank Hub.

6 Service and troubleshooting

6.1 Safety messages

Instructions and procedures in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that potentially raises safety issues is indicated by a warning symbol (\triangle). Refer to the following safety messages before performing an operation preceded by this symbol.

A WARNING

Failure to follow safe installation and servicing guidelines could result in death or serious injury.

- Ensure only qualified personnel perform the installation.
- Use the equipment only as specified in this manual. Failure to do so may impair the protection provided by the equipment.
- Do not perform any services other than those contained in this manual unless you are qualified.

Explosions could result in death or serious injury.

- Verify that the operating environment of the device is consistent with the appropriate hazardous locations certifications.
- Before connecting a handheld communicator in an explosive atmosphere, ensure that the instruments in the loop are installed in accordance with intrinsically safe or non-incendive field wiring practices.
- Do not remove the gauge cover in explosive atmospheres when the circuit is alive.
- To prevent ignition of flammable or combustible atmospheres, disconnect power before servicing.

6.2 Service

This section briefly describes functions which may be useful for service and maintenance of a Rosemount 2410 Tank Hub. If not otherwise stated, most examples are based on using the TankMaster WinSetup tool to access these functions. The Rosemount Tank Gauging System Configuration Manual (Document No. 00809-0300-5100) provides more information on how to use the TankMaster WinSetup program.

6.2.1 Viewing input and holding registers using TankMaster[™]

In a Rosemount Tank Gauging system, measurement data is continuously stored in **Input Registers** of devices such as the Rosemount 2410 Tank Hub, Rosemount 5900 Radar Level Gauge, and others. By viewing the input registers of a device, you can verify that the device is working properly.

Holding Registers store various device parameters used to control measurement performance.

Procedure

- 1. Start the TankMaster WinSetup program.
- 2. In the TankMaster WinSetup workspace window, select the device icon.



- 3. Right-click and select View Input/View Holding Registers option, or from the Service menu choose Devices → View Input/View Holding Registers. Now the View Input/Holding Register window appears.
- 4. In the **Registers Type** list, select **Predefined** or **All**.

Option	Description
Predefined	View a basic selection of registers.
All	View a range of registers by your own choice (for advanced service).

5. For the All option, you have to specify a range of registers by setting a start value in the **Start Register input** field, and the total number of registers to be displayed in the **Number of Registers** field (1-500). Up to 50 registers is recommended for a quick update of the list.

6. The **Registers Scope** drop-down list has three options:

Scope	Description	Access level
Basic	Standard setting that includes the most commonly used registers	View Only
Service	Includes a wider range of registers for advanced service and troubleshooting	Supervisor
Developer	For advanced users only	Administrator

- 7. In the **Show Values in** pane, choose the appropriate register format Decimal or Hexadecimal.
- Click the Read button. Now the View Input/Holding Registers window is updated with the current register values.

6.2.2 Editing holding registers using TankMaster[™]

Most Holding Registers can be edited simply by typing a new value in the appropriate Value input field. Some Holding Registers (marked grey in the Value column) can be edited in a separate window. In this case you can choose from a list of options or you can change separate data bits.

For more information see the Rosemount Tank Gauging System Configuration Manual (Document No. 00809-0300-5100).

6.2.3 View the device live list in TankMaster[™]

The **Device Live List** lets you view devices connected to the Tankbus. You can, for example, see Device Id, Tag, and whether the devices are configured or not.

The **Device Live List** is useful when you are going to configure devices in a Rosemount Tank Gauging system, in order to verify that the required devices are connected to the Tankbus.

Procedure

- 1. Start the TankMaster WinSetup program.
- 2. In the *TankMaster WinSetup* workspace, select the Rosemount 2410 icon.

3. Right-click and select Live List.

Figure 6-1: The Device Live List Window

	Device Type	Device Id	Manufact. Id	Device No	FF Address	Handled	Connected	Configured	Opened	Auto Mode	Tag
	5900 RLG	0	Rosemount	1	232	Yes	Yes	Yes	Yes	Yes	5900-DEVICE-000000000
2	2240 TTM	16	Rosemount	2	245	Yes	Yes	Yes	Yes	Yes	Device-0011512240-EPM-0x000000
}	No Device										
ŀ	No Device										
5	No Device										
5	No Device										
'	No Device										
3	No Device										
)	No Device										
0	No Device										
11	No Device										
12	No Device										
13	No Device										
4	No Device										
15	No Device										
6	No Device										

Device live list window

The Rosemount 2410 Tank Hub *Device Live List* window shows the following information:

Table 6-1: Device Live List Description

ltem	Description
Device Type	Examples of supported devices: Rosemount 5900S, 2410, 2240S, 2230, 5300, 5408, 848T, and 3051S.
	For unknown devices the device type number is shown.
Device ID (Unit ID)	A unique code that identifies a particular device. You can choose to view the device ID in decimal or hex format depending on what format is supported by the device.
Manufact Id	Identifies the manufacturer.
Device No	Index used to identify devices by the FF stack.
FF Address	$FOUNDATION^{^{M}}Fieldbus \ \mathbf{address} \ \mathbf{used} \ \mathbf{for} \ \mathbf{communication} \ \mathbf{on} \ \mathbf{the} \ \mathbf{Tankbus}.$
Handled	Bit 0 of the Live List Status input register which indicates the current Tankbus communication status of the device.
Connected	"No" means that the device has been disconnected from the Tankbus.
Configured	"Yes" indicates that the device is configured in the Rosemount 2410 tank database, i.e. the device is mapped to a particular tank.
Opened	Bit 1 of the Live List Status input register which indicates the current Tankbus communication status of the device.
Auto Mode	"Yes" in normal operation. "No" indicates that the device is in Out of Service mode.
Tag	A removable tag provided with the device lets you identify the device to a physical location. This field shows the Tag number of the device (when available).

6.2.4 Backing up a device configuration using TankMaster[™]

Using Rosemount TankMaster WinSetup to save the current device configuration to file:

Procedure

- 1. Start the Rosemount TankMaster WinSetup program.
- 2. In the TankMaster WinSetup workspace window, right-click the device icon.
- 3. Choose the Save Database to File option.

This option is also available from the **Service/Devices** menu.



4. Choose the **Holding Registers** and **Predefined Registers** options (the User-Defined option should only be used for advanced service).

🗍 Save Database to File - HU	B-101 (Version 1.C4)						
Registers Type	Registers						
Holding Registers	Predefined Registers						
Scope:	First Register:						
All Registers	Last Register:						
Save Modified Values Only							
Folder Name							
C:\Rosemount\TankMaster\Backup\Device backup 2014-11-15 Browse							
<u>S</u> ave C	ancel <u>H</u> elp						

- 5. Click the **Browse** button, select a folder and type a name for the backup file.
- 6. Click the Save button to start saving the database registers.

6.2.5 Recover a backup configuration database using TankMaster[™]

Rosemount TankMaster WinSetup lets you replace the current Holding Register database with a backup database stored on disk. This can be useful, for example, if you want to recover lost configuration data.

To load a Holding Register database do the following:

Procedure

- 1. In the TankMaster WinSetup workspace window, select the device icon.
- 2. Right-click and select **Upload Database**, or from the **Service** menu choose **Devices**/ **Upload Database**.

🔲 Upload Database - LT-5900 (Version 2.A)	×
File Name C:\Rosemount\TankMaster\Backup\Device backup 2014-12-23\LT-5900_HREG.dnr	Ţ
Upload Cancel <u>H</u> elp	

- 3. Click the **Browse** button and choose a database file to be uploaded, or type a path and file name.
- 4. Click the **Upload** button.

6.2.6 View and configure diagnostic registers using TankMaster[™]

The Rosemount TankMaster WinSetup program lets you view the current device status. The *View Diagnostic Register* window shows a selection of database registers that gives you an instant view of how the gauge operates. You may also configure the window by adding registers of special interest.

Procedure

1. In the *TankMaster WinSetup* workspace window, right-click the device icon.



2. Right-click and select View Diagnostic Registers.

View Diagnostic Registers - LT-1 (Version	0.E7)		×
LT-1	t>> Log sta	inted NO	🔲 Show in Hex
Name	Register	Value	Unit
Status-DeviceStatus	1000	2	
Status-DeviceError	1002	0	
Status-DeviceWarning	1004	16400	
Standard-MeasStatus	4002	0	
Standard-Ullage	4008	4,42197	m
Standard-SignalStrength	4012	1004,81	mV
DetMeasInfo-Gain	5112	1	
Configure Print	Close		Help

Diagnostics registers window

The register values in the diagnostics window are of read only type. They are loaded from the device as the window is opened.

A grey background color of the table cell in the Value column means that the register is of either Bitfield or ENUM type. An expanded Bitfield/ENUM window can be opened for this type of register. Double-click the cell to open the Expanded Bitfield/ENUM window.

If needed, the values can be presented as hexadecimal numbers. This applies to all registers of Bitfield and ENUM types. Select the **Show in Hex** check box to present Bitfield and ENUM registers as hexadecimal numbers.

The **Configure** button lets you open the *Configure Diagnostic Registers* window where you can change the list of registers to be displayed in the *View Diagnostic Registers* window. See the Rosemount Tank Gauging System Configuration Manual for more information.

The **Configure Diagnostic Registers** window also has a **Log Setup** button for access to the **Register Log Scheduling** window which allows you to setup a log schedule for automatic start and stop of register logging. See Logging measurement data using TankMaster[™] for more information.

6.2.7 Upgrading the device firmware using TankMaster[™]

Rosemount TankMaster WinSetup includes the option to upgrade the Rosemount 2410 and other devices in a Rosemount Tank Gauging system with new firmware.

Prerequisites

Ensure that the latest versions of *.ini-files are installed on the TankMaster PC. New *.ini files can easily be installed by running the TankMaster setup program located in the DeviceIniFiles folder on the TankMaster installation CD.

Procedure

- 1. Ensure that the Rosemount 2410 communicates with TankMaster without any interruptions or disturbances.
- 2. In the *Rosemount TankMaster WinSetup* workspace window (Logical View), open the **Devices** folder and select the device to be upgraded (or select the **Devices** folder to allow multiple devices programming).

3. Right-click and select the **Program** option (**Program All** option for multiple devices programming). The device will automatically appear in the **Program These Devices** pane.

📋 Program Devices	×			
Device <u>T</u> ypes:	IUB			
Available Devices:	Program these Devices:			
	Move > HUB-101			
	Move All N			
	MORE AIL //			
	< R <u>e</u> move			
	<< Remove <u>A</u> ll			
Eile Name and Program Version				
I:\1A3_01\CRY\2410_APPL_1A3_01.cry Browse Betries:				
Type 2410, Version 1.A3, AF	PL 3			
Successfully Programmed De	vices: Device Programming Failed:			
<u>Start Programming</u>	Close Help			

4. In case the **Devices** folder in the WinSetup workspace was selected for multiple programming, choose the desired device to be programmed from the *Available Devices* pane and click the **Move** button.

Program Devices		×			
Device Types: All devices					
Available Devices:		Program these Devices:			
SYSHUB-201 HUB-101 ⊕-(○) HUB-102 ⊕-(○) HUB-102 ⊕-(○) HUB-103	Move >	(Q) HUB-101			
⊕ (O) HUB-104	< R <u>e</u> move				
	<< Remove <u>A</u> ll				

- 5. Repeat for each device to be programmed. Use the **Remove** button if you wish to change the list of devices to be programmed.
- 6. Click the **Browse** button to locate the flash program file. File extension *.cry is used for these files.

Example

For a Rosemount 2410, a flash file name may typically look like: 2410_APPL_xxx_yy.cry, where "x" and "y" indicate software version.

7. Click the **Start Programming** button.

C	Start Device Prog	Iramming
Γ	Statistics	
	Device:	HUB-101
	Blocks Total:	3539
L	Blocks Sent:	
L	Program Time:	
L		
	Start Programming	Abort Close Help

Now the Start Device Programming window appears.

8. Click the Start Programming button to activate device programming.

Programming may take up to two hours for a Rosemount 2410 connected to a TankMaster PC via a 2460 System Hub. The programming procedure will continue with one device after the other until all Tank Hubs selected in the *Program Devices* window are upgraded. The Rosemount 2410 operates as normal during the reprogramming procedure.

By connecting a Rosemount 2410 directly to a host computer, and using the RS485 Modbus[®] protocol at a maximum baud rate of 38400, programming time may be reduced to 5 to 10 minutes (see Change the communication parameters for the primary bus for information on how to configure the Primary Bus).

Once programming is finished, the tank hub will automatically perform a restart indicated by "WAIT" on the integral display for a couple of minutes.

Postrequisites

Note

In case the current firmware version is significantly older than the new one, it is recommended that you load the default configuration database once the device is reprogrammed. Contact Emerson Automation Solutions/Rosemount Tank Gauging service department if you need further advice.

6.2.8 Write protection using TankMaster[™]

A Rosemount 2410 can be software write protected to avoid unintentional configuration changes. Software write protection locks the holding register database.

Procedure

- 1. Start the Rosemount TankMaster WinSetup program.
- 2. In the TankMaster WinSetup workspace, select the Logical View tab.
- 3. Right-click the device icon.

⊟ 🗊 тк-59 ⊟ 🗐 SYSHUB-201	
⊟	Collapse All
ATD-59	Uninstall
🕂 📄 Fixed Roof	Save Database to File
	Upload Database
	View Input Registers
	View Holding Registers
	View Diagnostic Registers
	Restart
	Logging
	Program
	Live List
	Manual Relay Control
	Simulation
	Write Protect
	Properties

4. Select Write Protect.

📋 2410 Tank Hub Write Protect - HUB-101	x
Write Protect State: Not Protected	
Change Write Protect State	
New State: Protected	
Write Protect Counter: 0	
Ok Apply Cancel Help	

5. In the **New State** drop-down list, select **Protected**, and then click the **Apply** button to save the new write protect state. Now the holding register database is locked. As long as the device is write protected

Now the holding register database is locked. As long as the device is write protected no configuration changes can be made.

6. Click the **OK** button to close the *Write Protect* window.

6.2.9 Write protection switch

A switch on the front of the Rosemount 2410 Tank Hub can be used to prevent unauthorized changes of the holding register database.

Figure 6-2: The Rosemount 2410 Tank Hub Write Protection Switch on the Built-in Integral display



A. Write protection switch

6.2.10 Simulation mode

The Simulation Mode function lets you verify communication between a Rosemount 2410 Tank Hub and a host system without connecting actual field devices.

The **Rosemount 2410 Tank Hub Simulation** window allows you to choose which parameters to be calculated by the Rosemount 2410. Calculations are based on input from simulated tank measurement data such as product level, average temperature, liquid pressure, and other variables.

The Simulation HREGS holding registers (starting with register number 3800) lets you specify the desired simulation data.

For information on how to view and edit holding registers, see Viewing input and holding registers using TankMaster[™] or the Rosemount Tank Gauging System Configuration Manual (Document No. 00809-0300-5100).

Procedure

1. In the *TankMaster WinSetup* workspace select the Rosemount 2410 icon.

2. Click the right mouse button and choose the **Simulation** option to open the *Rosemount 2410 Tank Hub Simulation* window:

📋 2410 Tank Hub Simulation - HUB-1	
Simulation Mode : Single Tank 💌	Device Status:
Tank Position : 1]
Simulation Time : 10	min
Calculate Parameter Average Temperatures Total Observed Volume Observed Density	
Calculation based on simulated input values and current configuration.	
	Start Stop Cancel

3. Choose simulation mode **Single Tank** and the desired tank in the Tank Position field, or choose the **All** option to simulate all tanks connected to the Rosemount 2410.

Tank Position refers to the position in the Rosemount 2410 tank database.

- 4. In the **Simulation Time** field, enter for how long the simulation will continue. Simulation can be stopped at any time by pressing the **Stop** button.
- 5. Calculate Parameter.

In the standard configuration the check-boxes are unchecked, which means that each simulation parameter is given a specific standard simulation value as specified in the simulation holding register area:

Table 6-2: Simulation Paramters

Simulation Parameter	Simulation Holding Register
Average Temperature	HR3868
Total Observed Volume	HR3994
Observed Density	HR3976

6. Click the **Start** button to start simulating the tank parameters.

Note

Simulation continues for the specified period of time. It can also be stopped manually at any time by pressing the Stop button in the *Simulation* window.

In the *WinSetup* workspace the Rosemount 2410 icon changes to the following appearance to indicate that Simulation Mode is active:



Advanced simulation

If a **Calculate Parameter** check-box is selected, the simulation parameter is calculated based on input data from the holding registers Simulation HREGS 3800 to 4056. You can simulate one or more parameters simultaneously.

Figure 6-3: Calculation Parameter

2410 Tank Hub Simulation - HUB-1			×
Simulation Mode : Single Tank		Device Status:	
Tank Position : 1			
Simulation Time : 10	min		
Calculate Parameter Average Temperatures Total Observed Volume Observed Density Calculation based on simulated input values and current configuration.			
	Start	Stop Cance	3

Procedure

- 1. For Average Temperature, the temperature element positions must be configured:
 - a) Right-click the auxiliary tank device (ATD) icon in the WinSetup workspace.
 - b) Choose the **Properties** option.
 - c) Select the **Average Temperature Calculation** tab. See the Rosemount Tank Gauging System Configuration Manual (Document No. 00809-0300-5100) for more information.

The resulting product average temperature is available in input register IR2100 (tank 1). It is also available in input register area starting with IR30000 (IR30044 for tank 1).

2. The Volume Calculation function must be activated in order to enable advanced Volume simulation. See Volume configuration for more information.

The volume calculation result is presented in input register IR4702, IR3400 (tank 1) and in input register area starting with IR30000 (IR30148 for tank 1).

3. To simulate Observed Density the Hybrid Density function must be activated. See Hybrid density configuration for more information.

The resulting Observed Density is available in input register IR3500 (tank 1). It is also available in input register area starting with IR30000 (IR30116 for tank 1).

6.2.11 Testing the relays using TankMaster[™]

The Manual Control of Relay function lets you manually open or close the Rosemount 2410 Tank Hub built-in relays in order to verify the relay function. After the specified Safety Reset Time the relay automatically returns to normal mode. To change relay state by using the TankMaster WinSetup program do the following:

Procedure

- 1. In the *TankMaster WinSetup* workspace, select the Rosemount 2410 icon.
- 2. Right-click and select Manual Control Relay.
- 3. Select the virtual relay functions to be tested; Virtual Relay 1, Virtual Relay 2, etc. Up to ten virtual relay functions can be configured for a Rosemount 2410 Tank Hub.

Manual Control of	Relay - HUB-1			x
Relay : Relay Output : Safety Reset Time : Manual Relay State :	Virtual Relay 1 Relay 1 30.0 sec Alarm	Device Status : RELAY MANUAL SET IN RESI	ET STATE	
		Set	Cancel	

4. Specify a Safety Reset Time.

This value specifies the time period for the relay to stay in the test state. When the specified period of time has elapsed, the relay automatically returns to the original state. The relay will reset even if communication with the TankMaster PC would fail.

- 5. Choose the desired Manual Relay State. Available options are:
 - Alarm
 - Normal
 - Toggle
- 6. Click the Set button.

Now the selected relay changes state for the specified number of seconds and then returns to the previous state.

Related information

Configure a virtual relay output

6.2.12 Relay output configuration

To change the Normally Open/Normally Closed settings of the K1 and K2 relays, do the following:

Procedure

- 1. A Disconnect the power supply.
- 2. A Disconnect the relays.
- 3. Remove the front cover.



- 4. Remove the plastic display cover.
- 5. Switch the jumpers to the desired settings: Normally Open (NO) or Normally Closed (NC).



6. Replace the plastic display cover and the front cover.

Note

Ensure that o-rings and seats are in good condition prior to mounting the cover in order to maintain the specified level of ingress protection.

6.2.13 Loading the default database using TankMaster[™]

The various configuration parameters of the Rosemount 2410 Tank Hub is stored in a Holding Register database. The Holding Register factory setting is stored in the default database. TankMaster WinSetup offers the option to load the default database. This may be useful if, for example, you would like to try out new database settings and then be able to reload the original factory settings.

Prerequisites

In case error messages appear or other problems occur concerning the database, troubleshooting the cause of these problems is recommended before loading the default database.

It is recommended that the current database is backed up before the Default Database is loaded. See Backing up a device configuration using TankMaster[™] for information on how to save the current database.

Note

When the default database is loaded to the Rosemount 2410 Tank Hub, measurement units are reset to Metric units.

Note

The device address remains unaltered when the default database is loaded.

Procedure

- 1. In the *TankMaster WinSetup* workspace window, select the desired device icon.
- 2. Right-click and select View Holding Register.
- 3. Choose the All option and type 65510 in the Start Register input field.

View Holding Registers - HUB-1 (Versio Search for ○ Predefined ⓒ ▲II (Advanced)	s • (ow Values in — ● <u>D</u> ec ○ <u>H</u> ex		
<u>S</u> tart Register:	<u>N</u> um	ber of Registers:		
65510	10			
Name	Register	Value	Unit	
WORD	65510	65510		
DWORD	65512	-1		
DWORD	65514	-1		
DWORD	65516	-1		
DWORD	65518	-1		
DWORD	65520	-1		
DWORD	65522	-1		
DWORD	65524	-1		
DWORD	65526	-1		
DWORD	65528	-1		-
<u>R</u> ead <u>Apply</u>	Close	Help		

- 4. Type the desired number of registers to be displayed in the **Number of Registers** field and click the **Read** button.
- 5. In the Value input, type 65510.
- 6. Click the **Apply** button to load the default database.

- 7. Finish by clicking the **Close** button.
- 8. Verify that measurement units are compatible with the current host system configuration.

6.2.14 Logging measurement data using TankMaster[™]

The Rosemount 2410 supports logging of diagnostic registers. This function is useful for verifying that the gauge works properly. The logging function can be accessed by using the Rosemount TankMaster WinSetup program.

Procedure

- 1. Start the Rosemount TankMaster WinSetup program.
- 2. In the *TankMaster WinSetup* workspace window, select the device icon.
- 3. Right-click and select Logging.

💼 Register Lo	og Scheduling - L	T-1	X
Log Scher Manua © M Automa	dule I Mode anual atic Mode utomatic		Sample Rate
Start	Date (Y-M-D)	Time (H:M:S)	Max File Size
Stop	2009-04-01	19:23:28	100 KB
	Start	Stop	
	OK	Cancel	Help

4. Select Manual or Automatic mode.

Option	Description
Manual	Manual mode lets you start logging at any time. Logging will proceed until it is stopped by clicking the Stop button.
Automatic	In Automatic mode you have to specify a Start and Stop time. Logging will proceed until the stop date and time is reached.

The resulting log file will not exceed the size specified by the Max File Size parameter. When the number of log files has reached the Max Log Files value, TankMaster starts replacing the contents of existing log files.

Log files

Log files are stored in plain text file format and can be viewed in any word processing program. They are stored in the following folder: C:\Rosemount\TankMaster\Log, where C is the disk drive where the Rosemount TankMaster software is installed.

A log file contains the same input registers as the **View Diagnostic Registers** window, see View and configure diagnostic registers using TankMaster[™]. You can change which input registers to be included in the log file by configuring the **View Diagnostic Registers** window, see the Rosemount Tank Gauging System Configuration Manual for more information.

Figure 6-4: Log File

SEGO	T01-017	29_ HUB-1.	og - Notep	ad										×
<u>E</u> ile <u>E</u> dit	Format	<u>V</u> iew <u>H</u> elp												
⊨===== Device Device: Started	Name: I 2410 logging	HUB-1 2009-02-05	16:54:48											
Date	Time	IR1002	IR1004	IR1000	IR4002	IR4012	IR5112	IR1420	IRO	IR4	IR54	IR4006	IR2	
2009-02	2-05 16:	54:58	0	0	0	65536	2392,43	8	1	96521	9652	9652	9,65209	
2009-02	2-05 16:	55:08	0	0	0	65536	2392,7	8	1	96521	9652	9652	9,6521	
2009-02	2-05 16:	55:18	0	0	0	65536	2395,7	8	1	96521	9652	9652	9,65215	
2009-02	2-05 16:	55:28	0	0	0	65536	2392,06	8	1	96522	9652	9652	9,65213	
2009-02	2-05 16:	56:14	0	0	0	65536	2393,5	8	1	96522	9652	9652	9,6522	
2009-02	2-05 16:	56:24	0	0	0	65536	2388,86	8	1	96522	9652	9652	9,65217	
2009-02	2-05 17:	03:29	0	0	0	65536	2390,95	8	1	96521	9652	9652	9,65204	
2009-02	2-05 17:	07:08	0	0	0	65536	2392,85	8	1	96521	9652	9652	9,65205	
2009-02	2-05 17:	07:18	0	0	0	65536	2392.93	8	1	96521	9652	9652	9.65207	
2009-02	2-05 17:	07:28	0	0	0	65536	2392,92	8	1	96521	9652	9652	9.65207	
			-	-	-			-					-,	~
<				111									>	:

6.3 Troubleshooting

Table 6-3: Troubleshooting chart

Symptom	Possible cause	Action
No contact with the Rosemount 2410 Tank	Wiring	Check that wires are properly connected to the terminals.
Hub		Check for dirty or defective terminals.
		• Check wire insulation for possible short circuits to ground.
		• Check that the Rosemount 2410 Tank Hub is connected to the right communication port on the control room PC (if no 2460 System Hub or FCU 2160 is used).
	RS485 wiring	Check for proper polarity at the terminals.
	Field Bus Modem (FBM)	Check the LEDs for proper communication.
		• Check that the FBM is connected to the right port on the control room PC.
		• Check that the FBM is connected to the right port on the 2160 Field Communication Unit (FCU).
	Connection to Rosemount 2460 System Hub	Check that the Rosemount 2410's Primary/ Secondary bus is connected to the right port on the Rosemount 2460 System Hub.
	Configuration of Rosemount 2460 System Hub	• Check the communication address specified for the Rosemount 2410 in the Rosemount 2460's tank database.
		Check configuration of communication parameters for the Rosemount 2460 ports.
		• Check that the correct communication channel is selected.
		• See the Rosemount 2460 Reference Manual (Document No. 00809-0100-2460) for more information on how to configure the 2460 System Hub.
	Connection to FCU 2160	Check that the Rosemount 2410 Primary/ Secondary bus is connected to the right field bus port on the FCU 2160.
		Check communication port LED:s inside the 2160 Field Communication Unit (FCU).

Symptom	Possible cause	Action
	Configuration of FCU 2160	• Check the communication address specified for the Rosemount 2410 in the FCU Slave Database.
		 Check configuration of communication parameters for the FCU Fieldbus ports.
		Check that the correct communication channel is selected.
		See the Rosemount Tank Gauging System Configuration Manual (Document No. 00809-0300-5100) for more information on how to configure the FCU 2160.
	Configuration of communication protocol	In TankMaster WinSetup/Protocol Channel Properties: • check that the protocol channel is enabled
		 check the protocol channel configuration (port, parameters, modem).
No contact with the Rosemount 2410 Tank Hub	Hardware failure	 Check the Rosemount 2410 Tank Hub; check the Error LED or the integral display for information.
		 Check the 2460 System Hub (or 2160 Field Communication Unit).
		Check the Field Bus Modem.
		Check the communication port on the control room PC.
		 Check that all devices connected to the Primary/ Secondary bus are powered.
		Contact Emerson Automation Solutions/ Rosemount Tank Gauging service department.
	Software failure	• Restart the Rosemount 2410 by disconnecting and connecting the power supply (note the communication parameters that appear on the display during startup).

Symptom	Possible cause	Action			
No communication with one or more devices on the Tankbus	Wiring	 Check that the devices appear in the <i>Device Live</i> List (see View the device live list in TankMaster[™]). 			
		 Check diagnostics information, see View and configure diagnostic registers using TankMaster[™] for warning or error messages. 			
		 Check that wires are properly connected to the terminals. 			
		Check for dirty or defective terminals.			
		 Check wire insulation for possible short circuits to ground. 			
		 Check diagnostics information (see View and configure diagnostic registers using TankMaster[™]) for information that indicate bad communication on the Tankbus: - Input registers 1300 to 1328 provide general information on Tankbus communication - Input registers 1330 to 1648 provide information on specific devices on the Tankbus. 			
		 Check diagnostics information (see View and configure diagnostic registers using TankMaster[™]) for possible hardware faults that indicate short circuits or ground faults: - check Input Register 1326 for short circuits - check Input Register 1328 for ground faults. 			
		 Check that there are no multiple shield grounding points 			
		 Check that the cable shield is grounded at the power supply end (Rosemount 2410 Tank Hub) only. 			
		 Check that the cable shield is continuous throughout the Tankbus network. 			
		 Check that the shield inside the instrument housing does not come into contact with the housing. 			
		• Check that there is no water in conduits.			
		 Check for proper polarity at the terminals (Rosemount 5300 and 5408). 			
		• Use shielded twisted pair wiring.			
		Connect wiring with drip loops.			
		Check the loop impedance.			

Symptom	Possible cause	Action
	Incorrect Tankbus termination	• Check that there are two terminators on the Tankbus (see section Termination).
		• Check that terminations are placed at both ends of the Tankbus.
		• Check that the built-in termination in the Rosemount 2410 Tank Hub is enabled.
	Too many devices on the Tankbus	• Check that the total current consumption of the devices on the Tankbus is less than 250 mA, see Power budget.
		• Remove one or more devices from the Tankbus. The Rosemount 2410 Tank Hub supports a single tank. The multiple tank version of the Rosemount 2410 supports up to 10 tanks.
No communication with one or more devices on the Tankbus	Cables are too long	Check that the input voltage on the device terminals is 9 V or more (see section Fieldbus segment design).
	Software or hardware failure	 Check diagnostics information, see View and configure diagnostic registers using TankMaster[™].
		Check Device Status input register, see Device status.
		Contact Emerson Automation Solutions/ Rosemount Tank Gauging service department.
TankMaster does not present measurement data from one or more devices connected to the Tankbus. The devices communicate on the Tankbus and appear in the Devices live list	Incorrect configuration of the 2160 FCU slave database	Check the Modbus communication addresses in the 2160 FCU slave database. In TankMaster WinSetup open the <i>FCU Properties/Slave Database</i> window. See the Rosemount Tank Gauging System Configuration Manual (Document No. 00809-0300-5100) for more information on how to configure the 2160 FCU slave database.
No communication with one or more devices on the TankbusCables are too longC c c setNo communication with one or more devices on the TankbusCables are too longC c setSoftware or hardware failure.TankMaster does not present measurement data from one or more devices connected to the Tankbus. The devices communicate on the Tankbus and appear in the Device Live List.Incorrect configuration of the 2160 CU slave databaseC c c c on devices communicate on the Tankbus and appear in the Device Live List.Incorrect configuration of the Rosemount 2460 tank databaseC c 	Check the Modbus communication addresses in the 2460 tank database. In TankMaster WinSetup open the 2460 Properties/Slave Database window. See the Rosemount 2460 Reference Manual (Document No. 00809-0100-2460) for more information on how to configure the 2460 tank database.	

Symptom	Possible cause	Action
	Incorrect configuration of the Rosemount 2410 tank database	 Check the Rosemount 2410 tank database; ensure that the device is available and mapped to the right tank. Rosemount 2460 System Hub tank database: Check the Rosemount 2410 tank database configuration; verify that the ATD Modbus address is equal to the Temp Device address
		 Check the Rosemount 2410 tank database configuration; verify that the Level Modbus address is equal to the Level Device address.
		• See the Rosemount 2460 Reference Manual (Document No. 00809-0100-2460) for more information on how to configure the tank databases of the 2460 System Hub and the Rosemount 2410 Tank Hub.
		2160 FCU Slave Database:
		 Check the Rosemount 2410 tank database configuration; verify that the ATD Modbus address is equal to the 2410 Temp Modbus address.
		• Check the Rosemount 2410 tank database configuration; verify that the Level Modbus address is equal to the 2410 Level Modbus address.
		• See the Rosemount Tank Gauging System Configuration Manual (Document No. 00809-0300-5100) for more information on how to configure the FCU 2160 Slave Database and the Rosemount 2410 tank database.
	Software or hardware failure	 Check diagnostics information, see View and configure diagnostic registers using TankMaster[™].
		Check Device Status input register, see Device status.
		Contact Emerson Automation Solutions/ Rosemount Tank Gauging service department.
	Too many devices connected to the Tankbus	• Check the model code to find out what type of Rosemount 2410 Tank Hub that is used: Single tank or Multiple tank version.
		Change to a Rosemount 2410 Tank Hub for multiple tanks.

Symptom	Possible cause	Action
Incorrect temperature reading from temperature transmitter	Configuration error	Check configuration of the temperature transmitter; in TankMaster Winsetup open Properties for the ATD device associated with the tank.
		• See the Rosemount Tank Gauging System Configuration Manual (Document No. 00809-0300-5100) for more information on how to configure ATD devices such as a Rosemount 2240S Multi-Input Temperature Transmitter.
	Measurement units are not compatible with host system	 If default database is loaded to the Rosemount 2410 Tank Hub, do one of the following: in TankMaster WinSetup verify system units and re-install the tank associated with the Rosemount 2410 Tank Hub
		 update Holding Registers with correct measurement units
	Hardware failure	 Check diagnostics information, see View and configure diagnostic registers using TankMaster[™].
		Check temperature elements.
		Contact Emerson Automation Solutions/ Rosemount Tank Gauging service department.
Incorrect level reading from radar level gauge	Configuration error	• Check configuration of the level gauge; in TankMaster Winsetup open Properties for the level gauge associated with the tank.
		• See the Rosemount 5900S Reference Manual (Document no. 00809-0100-5900) and the Rosemount Tank Gauging System Configuration Manual (Document No. 00809-0300-5100) for more information on how to configure a Rosemount 5900S Radar Level Gauge.
	Measurement units are not compatible with host system	 If default database is loaded to the Rosemount 2410 Tank Hub, do one of the following: in TankMaster WinSetup verify system units and re-install the tank associated with the tank hub
		update Holding Registers with correct measurement units
	Hardware failure	 Check diagnostics information, see View and configure diagnostic registers using TankMaster[™].
		Contact Emerson Automation Solutions/ Rosemount Tank Gauging service department.

Table 6-3:	Troubles	shooting	chart ((continued)	

Symptom	Possible cause	Action
No output on the Rosemount 2410 integral display	Hardware failure	Check the model code to verify that the Rosemount 2410 was ordered with the LCD display option.
		Check display connection.
		 Check diagnostics information, see View and configure diagnostic registers using TankMaster[™].
		Contact Emerson Automation Solutions/ Rosemount Tank Gauging service department.
The Error LED (red) is	Various reasons such as hardware or	• See Error codes and Error messages.
blinking	software failure, communication, or configuration error	Check Device Status input register (see Device status).
The Status LED (yellow) is blinking	Normal operation. The yellow Status LED blinks at a constant rate of one flash every other second.	See LED for more information.
Configuration can not be saved	Write protection switch is set to the ON position	Check write protection switch on the display, see Write protection switch.
	The Rosemount 2410 is write protected in TankMaster WinSetup	Check write protection in TankMaster WinSetup, see Write protection using TankMaster [™] .
	Application software installed which is incompatible with current holding register setup	Reset holding registers to the default database setting, see Loading the default database using TankMaster [™] and restart the Rosemount 2410 Tank Hub.
	Corrupt holding registers	Reset holding registers to the default database setting, see Loading the default database using TankMaster [™] and restart the Rosemount 2410 Tank Hub.
Rosemount 2410 icon in TankMaster WinSetup is red	Simulation mode active	Stop simulation mode; open WinSetup <i>Set</i> <i>Simulation Mode</i> window and click the Stop button.
All measurement values are indicated with "SensFail" in the WinSetup <i>Tank View</i> window, and with "Error" in the WinOpi <i>Tank View</i> window.	Map conflict. One or more tank measurement variables are mapped to the wrong source parameter. For example: Vapor Temperature is mapped to Manual Value.	Check diagnostics information (see View and configure diagnostic registers using TankMaster [™]) for possible Device Warning messages: - in case there is a "Data Manager" warning, check Input Register 6244 - if register 6244 indicates a "TMV Mapping" warning check Input Registers 6260 to 6270 for tank measurement variable mapping conflicts
		• In TankMaster Winsetup, right-click the ATD device icon associated with the current tank, and click the Properties option. In the 22XX ATD window select the Advanced Parameter Source Configuration tab. Check that tank measurement variables are mapped to the right source parameters.

6.3.1 Device status

The current device status is shown in Input Register 1000. You can view the device status register by opening the *Diagnostic* window or the *View Input Registers* window.

Double-clicking the Value field of the Device Status register opens an expanded bitfield window with information on the current device status as shown in Figure 6-5.

Figure 6-5: Input Register Device Status

					A	Ą					
		[•		
👕 View Diagnostic Registers - HUB-101 (Vers	ion 1.A1)			x		1	🗂 Ex	pand	ed Bitfield	l	x
HUB-101 Kex	Log sta	rted NO	🔲 Show in I	Hex					Name	Value	
Name	Register	Value 🕇	Unit	-				0	N/A	0	- 11
Status-DeviceStatus	1000	2						1	DeviceWarning	0	-
Status-DeviceError	1002	0		\				2	N/A	0	-
Status-DeviceWarning	1004	2560						3	N/A	0	-
DevInfo-HwConfig	1106	442625		۱N				4	N/A	0	-
DevInfo-SwConfig	1108	0		- N				5	N/A	0	
PrimaryBus-RecMessages	1206	19732	#					7	N/A DeviceError	0	-
PrimaryBus-MessagesToMe	1208	17519	#		N N			<u></u>	Sim Mode Active	0	-
PrimaryBus-SentMessages	1210	17517	#		X			0	N/A	0	-
SecondaryBus-RecMessages	1256	0	#		N		-	3	N/A	0	-
SecondaryBus-MessagesToMe	1258	0	#				-	10	N/A	0	-
SecondaryBus-SentMessages	1260	0	#					12	N/A	0	-
TankbusInfo-NoOfConnectedDevice	1300	2	#					12	N/A	0	-
TankbusInfo-NoOfConfiguredDevice	1301	2	#				-	1.0	N/A	0	-
TankbusInfo-No0f0penDevice	1302	2	#				-	14	N/A	0	
TankbusInfo-TotalNoOfRWCommands	1304	42275	#	•				10	10/24	0	-
Configure Print	Close		Help						Cancel	Help	

A. Double-click the Value field to open the Expanded Bitfield window

Table 6-4: Device Status Messages

Message	Bit no.	Description	Action
Device Warning	1	A device warning is active.	See Warning messages for details.
Device Error	7	A device error is active.	See Error messages for details.
Simulation Mode Active	8	Simulation mode active.	Stop Simulation mode.
Write Protected	18	The device is write protected with a switch or in the TankMaster WinSetup program.	Check the write protection switch, see Write protection switch. Check write protection state in TankMaster WinSetup, see Write protection using TankMaster [™] .

Related information

View and configure diagnostic registers using TankMaster Viewing input and holding registers using TankMaster

6.3.2 Warning messages

Warning messages are displayed in the Rosemount TankMaster program. Input Register 1004 provides an overview of active device warnings (see View and configure diagnostic registers using TankMaster[™] or Viewing input and holding registers using TankMaster[™] for information on how to view diagnostics and various Input registers in TankMaster WinSetup).

For each warning message that may appear in Input register 1004, detailed information can be found in Input registers 6200 to 6248 as shown in Table 6-5.

Message	Description	Action
RAM warning	Input register no. 6200.	
FPROM warning	Input register no. 6204.	
Hreg warning	Input register no. 6208.	
SW warning	Input register no. 6212.	
Other memory warning	Input register no. 6216. Bit 1: Stack	
System warning	Input register no. 6220.	
Display warning	Input register no. 6224. Bit 0: Communication Bit 1: Configuration	
Aux warning	Input register no. 6228. Bit 0: Internal temperature Bit 1: Power	
FF stack warning	Input register no. 6232.	
Tankbus communication warning	Input register no. 6236. Bit 0: Device restarted Bit 1: Device open failed Bit 2: Device address changed Bit 3: Live List no free position Bit 4: Port changed Bit 5: Exceeded FF number of retries Bit 6: Power failure Bit 7: Ground failure	Contact Emerson Automation Solutions/Rosemount Tank Gauging service department.
Host communication warning	Input register no. 6240. Bit 0: Multiple configuration Bit 1: Primary bus configuration Bit 2: Secondary bus configuration	
Data Manager warning	Input register no. 6244. Bit 0: Frozen data Bit 1: TMV mapping	
Configuration warning	Input register no. 6248. Bit 0: Invalid strapping table Bit 1: Tank configuration Bit 11: Model Code invalid string Bit 12: Model Code invalid code	

Table 6-5: Warning Message Descriptions
Message	Description	Action
Map conflict tank no.	Input register no. 6260	
Map conflict TMV type (TMV=Tank Measurement Variable)	Input register no. 6260 Input register no. 6262 0: TMV Level 1: TMV Ullage 2: TMV Level Rate 3: TMV Signal Strength 4: TMV Free Water Level 5: TMV Vapor Pressure 6: TMV Liquid Pressure 7: TMV Air Pressure 8: TMV Ambient Temperature 9: TMV Vapor Avg Temperature 9: TMV Vapor Avg Temperature 10: TMV Liquid Avg Temperature 11: TMV Tank Avg Temperature 12-27: TMV Temp1 - TMV Temp 16 50: TMV Observed Density 51: TMV Reference Density 51: TMV Reference Density 52: TMV Flow Rate 53: TMV Tank Volume 54: TMV Tank Height 55: TMV Middle Pressure 56: TMV Delta Level 60-64: TMV USER DEF 1 - 5	 Check that tank measurement variables are mapped to the right source parameters: 1. In TankMaster Winsetup, right-click the ATD device icon associated with the current tank. 2. Click the Properties option. 3. In the 22XX ATD window select the Advanced Parameter Source
Map conflict device I	Input register no. 6264	
Map conflict device 1 TV no. (TV=Tank Variable)	Input register no. 6266 TV number 0 - 1019 (Level, Ullage, Level Rate, Signal Strength etc.)	Contact Emerson Automation Solutions/Rosemount Tank Gauging service department.
Map conflict device 2	Input register no. 6268	
Map conflict device 2 TV no. (TV=Tank Variable)	Input register no. 6270 TV number 0 - 1019 (Level, Ullage, Level Rate, Signal Strength etc.)	
Internal map conflict	Input register no. 6272 Bit 1: TMV Vapor average temperature Bit 2: TMV Liquid average temperature Bit 3: TMV Tank average temperature Bit 4: TMV Observed Density	

Table 6-5: Warning Message Descriptions (continued)

Message	Description	Action
	Bit 5: TMV Reference Density	
	Bit 6: TMV Tank Volume	
	Bit 7: Mult TV Map	
	Bit 8: TMV Internal Map	
	Bit 9: TMV Arithmetic Value	

6.3.3 Error messages

Error messages may be displayed on the Rosemount 2410 integral display and in the Rosemount Tankmaster program. You also have the option to view Input Register 1002 for an overview of active device errors (see View and configure diagnostic registers using TankMaster[™] or Viewing input and holding registers using TankMaster[™] for information on how to view diagnostics and various Input registers with TankMaster WinSetup).

For each error message that may appear in Input register 1002, detailed information can be found in Input registers 6100 to 6124 as shown in Table 6-6.

Message	Description	Action
RAM error	Input register no. 6100. A gauge data memory (RAM) error has been detected during the startup tests. Note: this automatically resets the gauge.	Contact Emerson Automation Solutions/Rosemount Tank Gauging service department.
FPROM error	Input register no. 6102: Bit 0: checksum Bit 1: Application version Bit 2: Application checksum	Probably a checksum error in the application software. Try to reprogram the Rosemount 2410.
HREG error	Input register no. 6104: Bit 0: Checksum Bit 1: Limit Bit 2: Version Bit 3: Read Bit 4: Write	Probably a checksum error caused by power failure between a configuration change and CRC update. Reset to factory configuration (see Loading the default database using TankMaster [™]) and reconfigure the Rosemount 2410. Use the Reset command before checking the error status.

Table 6-6: Error Message Descriptions

Message	Description	Action
SW error	Input register no. 6106: Bit 0: Undefined SW Error Bit 1: Task Not Running Bit 2: Out of stack space Bit 3: Unused RAM access Bit 4: Divide by zero Bit 5: Reset Counter Overflow Bit 15: Simulated SW Error	 The Rosemount 2410 software is having trouble running stable. 1. Switch off the power to the tank hub for at least one minute. 2. Switch power on again. If the problem persists, contact Emerson Automation Solutions/Rosemount Tank Gauging service department.
Other Memory Error	Input register no. 6108: Bit 0: CheckSum Bit 1: Stack	Contact Emerson Automation Solutions/Rosemount Tank Gauging service department
Sys Error	Input register no. 6110. Bit 0: Task Supervisor	
Display Error	Input register no. 6112. Bit 0: Hardware Bit 1: Com Bit 2: Configuration	
Aux Error	Input register no. 6114. Bit 0: Internal temperature out of limits Bit 1: Internal temp measurement failed Bit 2: Internal temperature device failed Bit 3: Relay 1 Bit 4: Relay 2 Bit 5: Power	
FF Stack Error	Input register no. 6116.	
Tankbus Communication Error	Input register no. 6118. Bit 0: Unknown device connected to the Tankbus	
Host Communication Error	Input register no. 6120. Bit 1: Hardware Primary modem Bit 2: Hardware Secondary modem Bit 3: Illegal Primary modem Bit 4: Illegal Secondary modem	

Table 6-6: Error Message Descriptions (continued)

Table 6-6: Error Message Descriptions (continued)

Message	Description	Action
Data Manager Error	Input register no. 6122. Bit 1: Tank configuration	
Configuration Error	Input register no. 6124.	

A Specifications and reference data

A.1 General specifications

A.1.1 Single tank version

- Supports one Rosemount 5900S 2-in-1 gauge or up to two Rosemount 5900 standard gauges
- Total Observed Volume (TOV) and API corrected Net Standard Volume (NSV) calculation with 100-point strapping table

A.1.2 Multiple tank version

For a Rosemount 5300/5408/5900 system configuration:

- The software supports 16 field devices and 10 tanks per tank hub
- Maximum five type Rosemount 5300 gauges per tank hub

The actual number of tanks/instruments a tank hub supports depends on the configuration, which types of units are connected and how many:

- Hybrid calculations (mass and density) for up to three tanks
- Total Observed Volume (TOV) and API corrected Net Standard Volume (NSV) calculation with 100-point strapping table for one tank

For more information, see Table A-4.

A.1.3 Examples of connected field devices

Radar level gauges (type 5900⁽¹³⁾, 5300, and 5408), Rosemount 2240S Multi-input Temperature Transmitter, Rosemount 644 Temperature Transmitter, Temperature/Water Level Sensors, Rosemount 3051S Scalable Pressure Transmitter, Rosemount 2230 Graphical Field Display

A.1.4 Start-up time

Less than 30 s

⁽¹³⁾ One Rosemount 5900S with a 2-in-1 solution or maximum two standard Rosemount 5900 gauges installed on separate tanks can be connected to one tank hub.

A.2 Communication/display/configuration specifications

A.2.1 Tankbus

The intrinsically safe side of the Rosemount 2410 connects to the Tankbus, which communicates with the field devices on the tank using FOUNDATION[™] Fieldbus.

A.2.2 Fieldbus

Rosemount 2410 communicates with a Rosemount 2460 System Hub, Rosemount TankMaster, or a host via the supported communication protocols for the primary and secondary fieldbus.

Primary fieldbus:	TRL2 Modbus, RS485 Modbus, Analog output/input 4-20 mA/HART or ${\rm Enraf}^{\$}$
Secondary fieldbus:	TRL2 Modbus, Analog output/input 4-20 mA/HART, <i>Wireless</i> HART [®] or other vendors' protocols, such as Enraf, L&J Tankway and Sakura MDP/V1

For combination guidance, see Table A-1 and Table A-2.

A.2.3 Relay outputs

SIL 3 relay output:	One certified SIL 3 relay is available for overfill prevention. This non- intrinsically safe solid state relay is closed/energized during normal operation.
	Maximum voltage and current: 260 Vac/Vdc, 80 mA single pole
Relay outputs (SIL 2 or non- SIL):	Maximum two relays, controlled by 10 independent virtual relay functions, which can be configured for different tanks and process variables. The two non-intrinsically safe solid state relays are user configurable for normally energized or de-energized operation. Maximum voltage and current: 350 Vac/Vdc, 80 mA single pole

For combination guidance, see Table A-1 and Table A-2.

A.2.4 Analog input/output

The tank hub supports analog output and input 4-20 mA/HART, active or passive, IS or non-IS. The analog output is available as certified SIL 2.

Analog input

Maximum number of input channels: 1

Input Current range: 0-23 mA

Configurable Min and Max alarm limits.

For IS parameters, see Product certifications.

External Supply Voltage:

- Passive Non-IS: 7.2 35 Vdc
- Passive IS: 8.7 30 Vdc

Maximum Output Voltage (open loop):

- Active Non-IS: 24 Vdc
- Active IS: 23 Vdc

HART master:

- Maximum 5 HART Slave Devices (Passive)
- Maximum 3 HART Slave Devices (Active)

Figure A-1: Loop Resistance: Passive Non-IS Analog Input



Max Loop Resistance⁽¹⁴⁾ @ 23 mA = 43.4 * (External Power Supply Voltage -7.2) $[\Omega]$

⁽¹⁴⁾ Any sense resistance must be subtracted from calculated max loop resistance to receive the maximum cable resistance.



Max Loop Resistance⁽¹⁴⁾ @ 23 mA = 43.4 * (External Power Supply Voltage – 8.7) [Ω]







A. Loop resistance $[\Omega]$

B. Lift-off voltage [V]

Max Loop Resistance⁽¹⁴⁾ = $(20.1 - \text{Lift-off Voltage})/\text{Max Loop Current} - 590 [\Omega]$

Analog output

Maximum number of output channels: 1

Output range: 3.5-23 mA

Software configurable High and Low Alarm Limits.

Separate software configurable alarms for process and hardware failures.

Low voltage and invalid loop current detection.

SIL 2 capable.

External Supply Voltage:

- Passive Non-IS: 8.0 35 Vdc
- Passive IS: 9.4 30 Vdc

Maximum Output Voltage (open loop):

- Active Non-IS: 24 Vdc
- Active IS: 23 Vdc



Max Loop Resistance⁽¹⁴⁾ @ 23 mA = 43.4 * (External Power Supply Voltage – 8) $[\Omega]$





Max Loop Resistance⁽¹⁴⁾ @ 23 mA = 43.4 * (External Power Supply Voltage – 9.4) $[\Omega]$



Max Loop Resistance⁽¹⁴⁾ = $(20.3 - \text{Lift-off Voltage})/\text{Max Loop Current} - 330 [\Omega]$





A.2.5 Fieldbus combinations

Table A-1: Fieldbus Combination Matrix (Non-SIL)

		Primary Fieldbus options				
		TRL2	RS485	Enraf	Analog out passive (non- IS)	Analog In passive (non- IS)
Secondary Fieldbus options	Code	R	4	E	В	7
TRL2	R	Yes	Yes	No	No	No
Enraf	E	Yes	Yes	No	No	No
WirelessHART [®]	W	Yes	Yes	Yes	Yes	Yes
L&J Tankway 1500 XL/MCG 2000	L	Yes	Yes	No	No	No
Varec Mark/Space GT 1800/1900	V	Yes	Yes	No	No	No
Whessoe WM 550/660 (digital current loop)	Н	Yes	Yes	No	No	No
GPE 31422/31423 (digital current loop)	G	Yes	Yes	No	No	No
Sakura MDP/V1	U	Yes	Yes	No	No	No
Tokyo Keiso	Т	Yes	Yes	No	No	No
Analog out active (IS)	С	Yes	Yes	Yes	No	No
Analog out active (non-IS)	A	Yes	Yes	Yes	No	No
Analog out passive (IS)	D	Yes	Yes	Yes	No	No
Analog out passive (non-IS)	В	Yes	Yes	Yes	No	No
Analog in active (IS)	8	Yes	Yes	Yes	No	No
Analog in active (non-IS)	6	Yes	Yes	Yes	No	No
Analog in passive (IS)	9	Yes	Yes	Yes	No	No
Analog in passive (non-IS)	7	Yes	Yes	Yes	No	No
None	0	Yes	Yes	Yes	No	No
Ready for upgrade	F	Yes	Yes	Yes	No	No

Yes = Primary Fieldbus and Secondary Fieldbus can be combined

No = Combination not possible

Table A-2: Fieldbus Combination Matrix (SIL)

		Primary Fieldbus options				
		TRL2	RS485	Enraf	Analog out passive (non-IS)	Analog In passive (non-IS)
Secondary Fieldbus options	Code	R	4	E	В	7
TRL2	R	SIL 2 (relay)	SIL 2 (relay)	No	No	No
Enraf	E	SIL 2 (relay)	SIL 2 (relay)	No	No	No
WirelessHART	W	SIL 2 (relay)	SIL 2 (relay) or SIL 3 (relay)	SIL 2 (relay)	SIL 2 (4-20 mA and/or relay)	SIL 2 (relay)
L&J Tankway 1500 XL/MCG 2000	L	SIL 2 (relay)	SIL 2 (relay)	No	No	No
Varec Mark/Space GT 1800/1900	V	SIL 2 (relay)	SIL 2 (relay)	No	No	No
Whessoe WM 550/660 (digital current loop)	Н	SIL 2 (relay)	SIL 2 (relay)	No	No	No
GPE 31422/31423 (digital current loop)	G	SIL 2 (relay)	SIL 2 (relay)	No	No	No
Sakura MDP/V1	U	SIL 2 (relay)	SIL 2 (relay)	No	No	No
Tokyo Keiso	Т	SIL 2 (relay)	SIL 2 (relay)	No	No	No
Analog out active (IS)	С	SIL 2 (4-20 mA and/or relay)	SIL 2 (relay) or SIL 3 (relay)	SIL 2 (4-20 mA and/or relay)	No	No
Analog out active (non-IS)	A	SIL 2 (4-20 mA and/or relay)	SIL 2 (4-20 mA and/or relay)	SIL 2 (4-20 mA and/or relay)	No	No
Analog out passive (IS)	D	SIL 2 (4-20 mA and/or relay)	SIL 2 (relay) or SIL 3 (relay)	SIL 2 (4-20 mA and/or relay)	No	No
Analog out passive (non- IS)	В	SIL 2 (4-20 mA and/or relay)	SIL 2 (4-20 mA and/or relay)	SIL 2 (4-20 mA and/or relay)	No	No
Analog in active (IS)	8	SIL 2 (relay)	SIL 2 (relay) or SIL 3 (relay)	SIL 2 (relay)	No	No
Analog in active (non-IS)	6	SIL 2 (relay)	SIL 2 (relay)	SIL 2 (relay)	No	No
Analog in passive (IS)	9	SIL 2 (relay)	SIL 2 (relay) or SIL 3 (relay)	SIL 2 (relay)	No	No
Analog in passive (non-IS)	7	SIL 2 (relay)	SIL 2 (relay)	SIL 2 (relay)	No	No
None	0	SIL 2 (relay) or SIL 3 (relay)	SIL 2 (relay) or SIL 3 (relay)	SIL 2 (relay) or SIL 3 (relay)	No	No

Table A-2: Fieldbus	Combination Matrix	(SIL)	(continued)
---------------------	---------------------------	-------	-------------

		Primary Fieldbus options				
		TRL2	RS485	Enraf	Analog out passive (non-IS)	Analog In passive (non-IS)
Secondary Fieldbus options	Code	R	4	E	В	7
Ready for upgrade	F	SIL 2 (4-20 mA and/or relay)	SIL 2 (4-20 mA and/or relay)	SIL 2 (4-20 mA and/or relay)	No	No

SIL = Primary Fieldbus and Secondary Fieldbus can be combined with SIL

No = Combination not possible

A.2.6 Integral display output variables

The integral digital read-out display can toggle between:

- Level
- Level rate
- Ullage
- Signal strength
- Volume (TOV)
- Liquid average temperature
- 1-16 spot temperature
- Vapor average temperature
- Ambient temperature
- Free water level
- Vapor pressure
- Liquid pressure
- Air pressure
- Observed density
- Reference density
- Flow rate

A.2.7 Display output units

Level, free water level, and ullage:	meter, millimeter, feet, or imperial 1/16
Level rate:	meter/second, meter/hour, feet/second, or feet/hou

Flow rate:	meter³/hour, liter/minute, barrel/hour, or US gallon/ hour
Total Observed Volume (TOV):	meter ³ , liters, barrel, or US gallon
Temperature:	°F, °C, or °K
Pressure:	psi, psiA, psiG, bar, barA or barG, atm, Pa, or kPa
Density:	kg/m³, °API, or 60/60DegF
Signal strength:	mV

Density, mass, and more volume parameters are calculated in Rosemount TankMaster (GOV, GSV, NSV, WIA/WIV).

A.2.8 Configuration tools

Rosemount TankMaster

A.2.9 Autoconfiguration support

Yes (Tankbus addressing)

A.3 Electrical specifications

A.3.1 Power supply (nominal values)

24-48 Vdc (-15% to +10%) 48-240 Vac (-15% to +10%), 50/60 Hz

A.3.2 Power consumption

Max. 20 W depending on configuration. Recommended Miniature Circuit Breaker (MCB): 2A slow

A.3.3 Tankbus cabling

0.5-1.5 mm² (AWG 22-16), twisted shielded pairs. Recommended cabling is shielded twisted pairs, 0.75 mm² (AWG 18). Tankbus cabling must fulfill FISCO cable and installation requirements, and must also be approved for use at minimum 85 °C (185 °F).

FISCO (Fieldbus Intrinsically Safe Concept)

The following cable characteristics are specified for FISCO:

Table A-3: FISCO Cable Parameters

Parameter ⁽¹⁾	Value
Loop resistance	15 Ω/km to 150 Ω/km
Loop inductance	0.4 mH/km to 1 mH/km
Capacitance	45 nF/km to 200 nF/km
Maximum length of each spur ⁽²⁾ cable	60 m in apparatus class IIC and IIB
Maximum cable length including trunk ⁽³⁾ and spurs	1000 m in apparatus class IIC and 1900 m in apparatus class IIB

(1) For further information see requirements of the IEC 61158-2 standard

(2) A spur is an unterminated part of the network.

(3) A trunk is the longest cable path between two devices on the fieldbus network, and is the part of the network which has terminations at both ends. In the Rosemount Tank Gauging system, a trunk is typically located between the Rosemount 2410 Tank Hub and a segment coupler or the last device in a daisy-chain configuration.

Power budget

Table A-4: Power Consumption for Various Rosemount Tank Gauging Devices

Field device	Power consumption
Rosemount 5900S Radar Level Gauge	50 mA
Rosemount 5900C Radar Level Gauge	50 mA
Rosemount 5900S Radar Level Gauge, 2-in-1 solution	100 mA
Rosemount 5300 Level Transmitter	21 mA
Rosemount 5408 Level Transmitter	21 mA
Rosemount 2230 Graphical Field Display	30 mA
Rosemount 2240S Multi-input Temperature Transmitter	30 mA including 565, 566 and 765 temperature sensors
Rosemount 644 Temperature Transmitter	12 mA
Rosemount 3051S, and Rosemount 2051 Pressure Transmitters	18 mA

Allowed cabling distances

Figure A-9: Cable Distances



The total cable distance A+B+C+D must not exceed the values given in Table A-5.

Cable diameter	Loop resistance	Maximum cabling distance from power source to all devices on the tank							
		With maximum power usage of 250 mA Distance in m (ft)	With typical power usage of 128 mA for 5900S, 2240S, 2230, 3051S Distance in m (ft)	With typical power usage of 178 mA for 5900S 2-in-1, 2240S, 2230, 3051S Distance in m (ft)					
20 AWG (0.5 mm²)	66 Ω/km	212 (695)	414 (1358)	298 (978)					
18 AWG (0.75 mm²)	42 Ω/km	333 (1092)	651 (2136)	468 (1535)					
17 AWG (1.0 mm²)	33 Ω/km	424 (1391)	829 (2720)	596 (1955)					
16 AWG (1.5 mm²)	26 Ω/km	538 (1765)	1000 (3281)	756 (2480)					

Table A-5: Allowed Cabling Distances for Different System Configurations

The typical cabling distance from the tank hub toward the control room is up to 4 km (2.5 miles) depending on which protocol is used.

A.3.4 Power and relay cabling

0.5-2.5 mm² (AWG 22-14), twisted shielded pairs

A.3.5 Maximum Tankbus cable lengths

Depends on the cable. For details, see the Rosemount Tank Gauging System Data Sheet.

A.3.6 Built-in Tankbus terminator

The Rosemount 2410 Tank Hub has a built-in tank bus terminator, which can be disconnected if required.

A.4 Mechanical specifications

A.4.1 Housing material

Polyurethane-covered die-cast aluminum

A.4.2 Cable entry (connection/glands)

Non-IS side: Two ½ - 14 NPT and Two ¾ - 14 NPT entries for cable glands or conduits IS side: Two ½ - 14 NPT entries for cable glands or conduits Three metal plugs to seal any unused ports are included in the delivery Optional:

- M20 x 1.5 and M25 x 1.5 conduit/cable adapter
- Cable glands in metal (½ 14 NPT and ¾ 14 NPT)
- 4-pin male eurofast connector or A size Mini 4-pin male minifast connector

A.4.3 Installation

Can be installed on a 33.4-60.3 mm (1-2 in.) diameter pipe or wall, at ground level close to the tank or on top of the tank using existing cabling.

A.4.4 Weight

4.7 kg (10.4 lbs)

A.5 Environmental specifications

A.5.1 Temperature limits

Ambient temperature

-40 to 70 °C (-40 to 158 °F). Minimum start-up temperature is -50 °C (-58 °F). With LCD display: -25 to 70 °C (-13 to 158 °F)

Storage temperature

-50 to 85 °C (-58 to 185 °F) With LCD display: -40 to 85 °C (-40 to 185 °F)

A.5.2 Humidity

0 - 100% relative humidity

A.5.3 Ingress protection

IP 66 and IP 67 (NEMA[®] 4X)

A.5.4 Metrology sealing possibility

Yes

A.5.5 Write-protect switch

Yes (hardware and software write-protection)

A.5.6 Transient/built-in lightning protection

In accordance with IEC 61000-4-5, level 4 kV line to ground. Compliant with IEEE 587 category B transient protection and IEEE 472 surge protection.

A.6 Dimensional drawings

Figure A-10: Rosemount 2410 Tank Hub Dimensions



Dimensions are in millimeters (inches).

A.7 Ordering information

A.7.1 Rosemount 2410 Tank Hub

Table A-6: Rosemount 2410 Tank Hub Ordering Information

Model	Product description			
2410	Tank Hub			
Tankbus	Tankbus: number of tanks			
S ⁽¹⁾	Single tank			
M ⁽²⁾	Multiple tanks (up to ten level devices per tank hub)			
Tankbus	: power and communication			
F	Intrinsically safe FOUNDATION [™] Fieldbus (IEC 61158) power supply			
Primary	fieldbus			
R	TRL2 Modbus			
4	RS485 Modbus			
E	Enraf [®] Bi-phase Mark GPU			
B ⁽³⁾	Analog output 4-20 mA/HART [®] , passive (non-IS)			
7 ⁽³⁾	Analog input 4-20 mA/HART [®] , passive (non-IS)			
Seconda	ry fieldbus			
R ⁽⁴⁾	TRL2 Modbus			
E ⁽⁴⁾	Enraf Bi-phase Mark GPU			
W ⁽⁵⁾⁽⁶⁾	WirelessHART [®] (IEC 62591) connectivity (IS)			
L ⁽⁴⁾	L&J Tankway Slave 1500 XL/MCG 2000			
V ⁽⁴⁾	Varec [®] Mark/Space GT 1800/1900			
H ⁽⁴⁾	Whessoe WM 550/660 (digital current loop)			
G ⁽⁴⁾	GPE 31422/31423 (digital current loop)			
U ⁽⁴⁾	Sakura(MDP/V1)			
T ⁽⁴⁾	Tokyo Keiso			
C ⁽⁶⁾⁽⁷⁾	Analog output 4-20 mA/HART, active (IS)			
A ⁽⁶⁾⁽⁷⁾	Analog output 4-20 mA/HART, active (non-IS)			
D ⁽⁷⁾	Analog output 4-20 mA/HART, passive (IS)			
B ⁽⁷⁾	Analog output 4-20 mA/HART, passive (non-IS)			
8 ⁽⁶⁾⁽⁷⁾	Analog input 4-20 mA/HART, active (IS)			
6 ⁽⁶⁾⁽⁷⁾	Analog input 4-20 mA/HART, active (non-IS)			
9(7)	Analog input 4-20 mA/HART, passive (IS)			
7 ⁽⁷⁾	Analog input 4-20 mA/HART, passive (non-IS)			

Table A-6: Rosemount 2410 Tank Hub Ordering Information (continued)

0 ⁽⁷⁾	None			
F ⁽⁷⁾	None, ready for upgrade of secondary bus			
Safety ce	Safety certification (SIS)			
3(8)(9)	Certified IEC 61508 SIL 3 (Using relay 1xSPST, solid-state. Certification is valid only when connected to a safety-certified Rosemount 5900 according to reference manual).			
S ⁽⁹⁾⁽¹⁰⁾	Certified IEC 61508 SIL 2 (using analog or relay output)			
F ⁽⁹⁾⁽¹⁰⁾⁽¹¹)	None, ready for upgrade of safety certification (SIS)			
0	None			
Relay out	put			
2	2xSPST, solid-state			
1	1xSPST, solid-state			
F	None, ready for upgrade of relay output			
0	None			
Integral o	lisplay			
1	LCD			
0	None			
Power su	pply			
Р	Extended input range: 48-240 Vac at 50/60 Hz, and 24-48 Vdc			
Firmware				
S	Standard			
Hazardou	us location certification			
E1	ATEX Flameproof			
E7	IECEx Flameproof			
E5	FM-US Explosion-proof			
E6	FM-Canada Explosion-proof			
E4 ⁽¹²⁾⁽¹³⁾	Japan Flameproof			
E2	INMETRO Flameproof (Brazil)			
EP ⁽¹⁴⁾	KC Flameproof (South Korea)			
EW	CCOE/PESO Flameproof Certification (India)			
EM	Technical Regulations Customs Union (EAC) Flameproof			
NA	No hazardous location certification			
Custody	transfer type approval ⁽¹⁵⁾			
R	OIML R85 E 2008 performance certification			
А	CMI (Czech Republic W&M approval)			

В	NMI (Australia)					
С	PTB (German W&M approval)					
E	TJA (Estonia W&M approval)					
G	GUM (Poland)					
I	Ministero (Italy)					
K ⁽¹⁶⁾	GOST (Kazakhstan)					
L	LNE (France)					
М	BMS (Belgium W&M)					
N	NMi (the Netherlands W&M approval)					
0	ONML (Algeria)					
Q	IPQ (Portugal)					
S ⁽¹⁶⁾	GOST (Russia)					
Т	ANM (Tunisia)					
W	METAS (Switzerland W&M approval)					
Y	Justervesenet (Norway W&M approval)					
0	None					
0	None					
Housing	None					
Housing	Aluminum (polyurethane-covered), IP 66/67					
Housing A Cable/co	Aluminum (polyurethane-covered), IP 66/67					
Housing A Cable/co	Aluminum (polyurethane-covered), IP 66/67 nduit connections ¹ ⁄ ₂ -14 NPT and ³ ⁄ ₄ -14 NPT	Female thread, includes: • 1 pcs 1½-14 NPT plug				
Housing A Cable/co	Aluminum (polyurethane-covered), IP 66/67 nduit connections 1/2-14 NPT and 3/4-14 NPT	Female thread, includes: • 1 pcs 1½-14 NPT plug • 2 pcs ¾-14 NPT plugs				
Housing A Cable/co 1	Aluminum (polyurethane-covered), IP 66/67 nduit connections ½-14 NPT and ¾-14 NPT M20 x 1.5 and M25 x 1.5 adapters	Female thread, includes: 1 pcs 1½-14 NPT plug 2 pcs ¾-14 NPT plugs Female thread, includes: 1 pcs 1½-14 NPT plug 2 pcs ¾-14 NPT plug 2 pcs ¾-14 NPT plugs 4 pcs 1½-14 NPT plugs 4 pcs 1½-14 NPT->M20x1.5 adapters 2 pcs ¾-14 NPT->M25x1.5 adapters				

Table A-6: Rosemount 2410 Tank Hub Ordering Information (continued)

E	eurofast [®] male connector	Includes:			
М	minifast [®] male connector	1 pcs male connector			
		• 1 pcs 1 ¹ / ₂ -14 NPT plug			
		• 2 pcs ¾-14 NPT plugs			
Mechani	cal installation				
W	Mounting kit for wall installation				
Р	Mounting kit for both wall and pipe installation (1-2-in.	vertical or horizontal pipes)			
Options (include with selected model number)				
Safety ce	rtificate				
QT ⁽¹⁸⁾	IEC 61508 certificate and FMEDA data				
Overfill p	Overfill protection approval				
U1 ⁽¹⁹⁾	TÜV/DIBt WHG approval for overfill protection				
U2 ⁽¹⁹⁾	SVTI approval for overfill protection (Switzerland)				
Tag plate					
ST	Engraved SST tag plate				
Extended	Extended warranty				
WR3	3-year limited warranty				
WR5	5-year limited warranty				
Typical N	lodel Number: 2410 S F R 0 3 2 1 P	S E1 R A 1 P ST			

Table A-6: Rosemount 2410 Tank Hub Ordering Information (continued)

(1) Supports one Rosemount 5900S 2-in-1 gauge or up to two Rosemount 5900 standard gauges.

(2) Up to five Rosemount 5300, up to 10 Rosemount 5408 per tank hub.

(3) Requires Secondary Fieldbus code W.

(4) Requires Primary Fieldbus code R or 4.

(5) Requires a separate Emerson Wireless 775 THUM Adapter (not included, to be ordered as a separate item).

(6) Power-supply integrated. Maximum Tankbus current reduced to 200 mA.

(7) Requires Primary Fieldbus code R, 4 or E.

(8) Requires Secondary Fieldbus code 0, or Secondary Fieldbus code W, C, D, 8, 9, and Primary Fieldbus code 4.

(9) Requires Number of tanks code S.

(10) Requires Relay output code 2 or 1, or Primary Fieldbus Code B, or Secondary Fieldbus code A, B, C or D for SIL 2 (Safety certification code S).

(11) Requires Secondary Fieldbus code 0 or F for SIL3 (Safety certification code 3).

(12) Requires Secondary Fieldbus code T or U.

(13) Requires Cable/conduit connections code 1.

(14) Requires Custody transfer type approval code R or 0.

(15) Requires a Rosemount 5900S Radar Level Gauge with corresponding Custody transfer type approval.

(16) Requires Hazardous location certification code E1.

(17) Min. temperature -20 °C (-4 °F). ATEX/IECEx Ex e approved.

(18) Requires Safety certification (SIS) code S or 3.

(19) Requires Safety certification (SIS) code 3, or Relay output code 1 or 2.

B Product certifications

Rev 2.11

B.1 European directive information

The most recent revision of the EU Declaration of Conformity can be found at Emerson.com/Rosemount.

B.2 Ordinary location certification

As standard, the transmitter has been examined and tested to determine that the design meets the basic electrical, mechanical, and fire protection requirements by a nationally recognized test laboratory (NRTL) as accredited by the Federal Occupational Safety and Health Administration (OSHA).

B.3 Installing equipment in North America

The US National Electrical Code[®] (NEC) and the Canadian Electrical Code (CEC) permit the use of Division marked equipment in Zones and Zone marked equipment in Divisions. The markings must be suitable for the area classification, gas, and temperature class. This information is clearly defined in the respective codes.

B.4 North America

B.4.1 E5 USA Explosion-proof

Certificate	FM16US0123X
Standards	FM Class 3600:2018, FM Class 3610:2018, FM Class 3615:2018, FM Class 3810:2005, NEMA 250-2003, ANSI/IEC 60529:2004, ANSI/UL 60079-0:2013, ANSI/UL 60079-7:2017, ANSI/UL 60079-11:2014, ANSI/UL 61010-1:2004
Markings FISCO	For b = Tank Bus (Fieldbus - Power and Communication): F and when d = Secondary Communication Bus (Non-IS): R, E, 5, K, L, V, H, G, A, U, T, B, 6, 7, 0, or F: FISCO POWER SUPPLY XP CL 1, DIV 1 GPS C, D & Associated Apparatus providing IS circuit to CL I, DIV 1, GPS C & D; DIP CL II/III, DIV. 1, GP E, F & G; CL I, ZONE 1 AEx db eb [ib] IIB Amb. Temp. Limits -50°C to +70°C Temp. Class T4 SEE CONTROL DRAWING D9240040-901 ENCL. TYPE 4X, IP66, IP67.
Markings FISCO HART active	When b = Tank Bus (Fieldbus - Power and Communication): F and when d = Secondary Communication Bus (HART [®] /4-20mA Active IS Input/ Output): W, C or 8: FISCO POWER SUPPLY XP CL 1, DIV 1 GPS C, D & Associated Apparatus providing IS circuit to CL I, DIV 1, GPS C & D; DIP CL II/III, DIV. 1, GP E, F & G; CL I, ZONE 1 AEx db eb [ib] IIB ENTITY IS I/O ACTIVE: XP CL 1, DIV 1 GPS C, D & Associated Apparatus providing IS circuit to CL 1, DIV 1, GPS C & D ACTIVE: CL I, ZONE 0 AEx db eb [ia IIC] IIB Amb. Temp. Limits -50°C to +70°C Temp. Class T4 SEE CONTROL DRAWING D9240040-901 Type 4X; IP66/67.
Markings FISCO HART passive	When b = Tank Bus (Fieldbus - Power and Communication): F and when d = Secondary Communication Bus (HART®/4-20mA Passive IS Input/ Output): D or 9. FISCO POWER SUPPLY XP CL 1, DIV 1 GPS C, D & Associated Apparatus providing IS circuit to CL I, DIV 1, GPS C & D; DIP CL II/III, DIV. 1, GP E, F & G; CL I, ZONE 1 AEx db eb [ib] IIB ENTITY IS I/O PASSIVE: CL I, ZONE 1 AEx db eb ib IIB Amb. Temp. Limits -50°C to +70°C Temp. Class T4 SEE CONTROL DRAWING D9240040-901 Type 4X; IP66/67.
Markings Entity	When b = Tank Bus (Fieldbus - Power and Communication): E and when d = Secondary Communication Bus (Non-IS): R, E, 5, K, L, V, H, G, A, U, T, B, 6, 7, 0, or F: ENTITY IS POWER SUPPLY XP CL I, DIV 1 GPS C, D & Associated Apparatus providing IS circuit to CL I, DIV 1, GPS C & D; DIP CL II/III, DIV. 1, GP E, F & G; CL I, ZONE 1 AEx db eb [ib] IIB ENTITY Uo: 15.0 V, Io: 200 mA, Po: 3.0 W Co: 1.9μ F, Lo: 143μ H Amb. Temp. Limits

-50°C to +70°C Temp. Class T4 SEE CONTROL DRAWING D7000002-611 Type 4X; IP66/67.

Markings Entity HART active	When b = Tank Bus (Fieldbus - Power and Communication): E and when d = Secondary Communication Bus (HART [®] /4-20mA Active IS Input/ Output): W, C or 8. ENTITY IS POWER SUPPLY XP CL I, DIV 1 GPS C, D & Associated Apparatus providing IS circuit to CL I, DIV 1, GPS C & D; DIP CL II/III, DIV. 1, GP E, F & G; CL I, ZONE 1 AEx db eb [ib] IIB ENTITY IS I/O ACTIVE: XP CL I, DIV 1 GPS C, D & Associated Apparatus providing IS circuit to CL I, DIV 1, GPS C & D ACTIVE: CL I, ZONE 0 AEx db eb [ia IIC] IIB Amb. Temp. Limits -50°C to +70°C Temp. Class T4 SEE CONTROL DRAWING D7000002-611 Type 4X: JP66/67
Markings Entity HART passive	When b = Tank Bus (Fieldbus - Power and Communication): E and when d = Secondary Communication Bus (HART [®] /4-20mA Passive IS Input/ Output): D or 9: ENTITY IS POWER SUPPLY XP CL I, DIV 1 GPS C, D & Associated Apparatus providing IS circuit to CL I, DIV 1, GPS C & D; DIP CL II/III, DIV. 1, GP E, F & G; CL I, ZONE 1 AEx db eb [ib] IIB ENTITY IS I/O PASSIVE: CL I, ZONE 1 AEx db eb ib IIB Amb. Temp. Limits -50°C to +70°C

Temp. Class T4 SEE CONTROL DRAWING D7000002-611 Type 4X;

Ex marking	Comm. Bus	Ui V	li mA	Pi W	Ci μF	Li mH	Uo V	lo mA	Po W	Co μ F	Lo mH	Group
Ex db eb [ib] IIB T4	FISCO	-	-	-	-	-	15	354	5.32	-	-	IIB
Ex db eb [ia IIC] IIB	HART/4-20mA	-	-	-	-	-	23.1	95.3	0.55	0.14	3.9	IIC
T4	Active									1.0	15	IIB
										3.67	33	IIA
Ex db eb ib IIB T4	HART/4-20mA Passive	30	300	1	0	0	-	-	-	-	-	IIB
Ex db eb [ib] IIB T4	Fieldbus	-	-	-	-	-	15	200	3	1.99	143	IIB

Special Conditions for Safe Use (X):

IP66/67.

B.4.2 E6 Canada Explosion-proof

Certificate	FM16CA0068X
Standards	CSA C22.2 No 0.4:2017 CSA C22.2 No. 0.5:2016 CSA C22.2 No. 30-M1986:1986 (Reaffirmed 2016) CSA C22.2 No. 94-M91:1991 (Reaffirmed 2011) CSA C22.2 No. 1010.1:2004 (Reaffirmed 2009) CAN/CSA 60079-0:2015 CAN/CSA 60079-1:2016 CSA C22.2 60079-7:2016 CAN/CSA 60079-11:2014 CSA C22.2 No. 60529:2016
Markings FISCO	For b = Tank Bus (Fieldbus - Power and Communication): F and when d = Secondary Communication Bus (Non-IS): R, E, 5, K, L, V, H, G, A, U, T, B, 6, 7, 0, or F: FISCO POWER SUPPLY XP CL 1, DIV 1 GPS C, D & Associated Apparatus providing IS circuit to CL I, DIV 1, GPS C & D; DIP CL II/III, DIV. 1, GP E, F & G; CL I, ZONE 1 Ex db eb [ib] IIB Amb. Temp. Limits -50°C to +70°C Temp. Class T4 SEE CONTROL DRAWING D9240040-901 Type 4X; IP66/67
Markings FISCO HART active	When b = Tank Bus (Fieldbus - Power and Communication): F and when d = Secondary Communication Bus (HART [®] /4-20mA Active IS Input/ Output): W, C or 8: FISCO POWER SUPPLY XP CL 1, DIV 1 GPS C, D & Associated Apparatus providing IS circuit to CL I, DIV 1, GPS C & D; DIP CL II/III, DIV. 1, GP E, F & G; CL I, ZONE 1 Ex db eb [ib] IIB ENTITY IS I/O ACTIVE: XP CL 1, DIV 1 GPS C, D & Associated Apparatus providing IS circuit to CL 1, DIV 1, GPS C & D ACTIVE: CL I, ZONE 0 Ex db eb [ia IIC] IIB Amb. Temp. Limits -50°C to +70°C Temp. When b = Tank Bus (Fieldbus - Power and Communication): F and when d = Secondary Communication Bus (HART [®] /4-20mA Passive IS Input/Output): D or 9. Class T4 SEE CONTROL DRAWING D9240040-901 Type 4X; IP66/67
Markings FISCO HART passive	When b = Tank Bus (Fieldbus - Power and Communication): F and when d = Secondary Communication Bus (HART [®] /4-20mA Passive IS Input/ Output): D or 9: FISCO POWER SUPPLY XP CL 1, DIV 1 GPS C, D & Associated Apparatus providing IS circuit to CL I, DIV 1, GPS C & D; DIP CL II/III, DIV. 1, GP E, F & G; CL I, ZONE 1 Ex db eb [ib] IIB ENTITY IS I/O PASSIVE: CL I, ZONE 1 Ex db eb ib IIB Amb. Temp. Limits -50°C to +70°C Temp. Class T4 SEE CONTROL DRAWING D9240040-901 Type 4X; IP66/67
Markings Entity	When b = Tank Bus (Fieldbus - Power and Communication): E and when d = Secondary Communication Bus (Non-IS): R, E, 5, K, L, V, H, G, A, U, T, B, 6, 7, 0, or F: ENTITY IS POWER SUPPLY XP CL I, DIV 1 GPS C, D & Associated Apparatus providing IS circuit to CL I, DIV 1, GPS C & D; DIP CL II/III, DIV. 1, GP E, F & G; CL I, ZONE 1 Ex db eb [ib] IIB Amb. Temp. Limits -50°C to +70°C Temp. Class T4 SEE CONTROL DRAWING D7000002-611 Type 4X; IP66/67

Markings Entity HART active	When b = Tank Bus (Fieldbus - Power and Communication): E and when d = Secondary Communication Bus (HART [®] /4-20mA Active IS Input/ Output): W, C or 8: ENTITY IS POWER SUPPLY XP CL I, DIV 1 GPS C, D & Associated Apparatus providing IS circuit to CL I, DIV 1, GPS C & D; DIP CL II/III, DIV. 1, GP E, F & G; CL I, ZONE 1 Ex db eb [ib] IIB ENTITY IS I/O ACTIVE: XP CL I, DIV 1 GPS C, D & Associated Apparatus providing IS circuit to CL I, DIV 1, GPS C & D ACTIVE: CL I, ZONE 0 Ex db eb [ia IIC] IIB Amb. Temp. Limits -50°C to +70°C Temp. Class T4 SEE CONTROL DRAWING D7000002-611 Type 4X; IP66/67
Markings Entity HART passive	When b = Tank Bus (Fieldbus - Power and Communication): E and when d = Secondary Communication Bus (HART®/4-20mA Passive IS Input/ Output): D or 9: ENTITY IS POWER SUPPLY XP CL I, DIV 1 GPS C, D & Associated Apparatus providing IS circuit to CL I, DIV 1, GPS C & D; DIP CL II/III, DIV. 1, GP E, F & G; CL I, ZONE 1 Ex db eb [ib] IIB ENTITY IS I/O PASSIVE: CL I, ZONE 1 Ex db eb ib IIB Amb. Temp. Limits -50°C to +70°C Temp. Class T4 SEE CONTROL DRAWING D7000002-611 Type 4X; IP66/67

Ex marking	Comm. Bus	Ui	li	Pi	Ci	Li	Uo	lo	Ро	Со	Lo	Group
		v	mA	w	μ F	mΗ	v	mA	w	μ F	mΗ	
Ex db eb [ib] IIB T4	FISCO	-	-	-	-	-	15	354	5.32	-	-	IIB
Ex db eb [ia IIC] IIB	HART/4-20mA	-	-	-	-	-	23.1	95.3	0.55	0.14	3.9	IIC
14	Active									1.0	15	IIB
										3.67	33	IIA
Ex db eb ib IIB T4	HART/4-20mA Passive	30	300	1	0	0	-	-	-	-	-	IIB
Ex db eb [ib] IIB T4	Fieldbus	-	-	-	-	-	15	200	3	1.99	143	IIB

Special Conditions for Safe Use (X):

B.5 Europe

B.5.1 E1 ATEX Flame-proof

Certificate	FM10ATEX0012X
Standards	EN 60079-0:2012 + A11:2013, EN 60079 - 1:2014, EN 60079 - 7:2015, EN 60079 - 11:2012, EN 60529:1992 + A1:2013 + A2:2013
Markings: 🖾	TANK HUB II 2(2) G Ex db eb [ib] IIB T4 Ta = -50°C to 70°C; IP66, IP67
	TANK HUB (with Active Modem HART Board) II 2(2) G Ex db eb [ib] IIB T4 Ta = -50° C to $+70^{\circ}$ C, IP66 / IP6 II 2(1) G Ex db eb [ia IIC] IIB T4 Ta = -50° C to 70° C; IP66, IP67 TANK HUB (with Passive Modem HART Board) II 2(2) G Ex db eb [ib] IIB T4 Ta = -50° C to $+70^{\circ}$ C, IP66 / IP67 II 2 G Ex db eb [ib] IIB T4 Ta = -50° C to 70° C; IP66 / IP67

Ex marking	Comm. Bus	Ui	li	Pi	Ci	Li	Uo	lo	Ро	Co	Lo	Group
		v	mA	w	μ F	mH	v	mA	w	μ F	mH	
Ex db eb [ib] IIB T4	FISCO	-	-	-	-	-	15	354	5.32	-	-	IIB
Ex db eb [ia IIC] IIB	HART/4-20mA	-	-	-	-	-	23.1	95.3	0.55	0.14	3.9	IIC
14	Active									1.0	15	IIB
										3.67	33	IIA
Ex db eb ib IIB T4	HART/4-20mA Passive	30	300	1	0	0	-	-	-	-	-	IIB
Ex db eb [ib] IIB T4	Fieldbus	-	-	-	-	-	15	200	3	1.99	143	IIB

Special Conditions for Safe Use (X):

B.6 International

B.6.1 E7 IECEx Flame-proof

Certificate	IECEx FMG 10.0005X
Standards	IEC 60079-0:2011
	IEC 60079-1:2014
	IEC 60079-7:2015
	IEC 60079-11:2011
Markings	Ex db eb [ib] IIB T4 Ta = -50 °C to 70 °C; FISCO
	or
	Ex db eb [ib] IIB T4 Ta = -50 °C to 70 °C; FISCO and
	Ex db eb [ia IIC] IIB T4 Ta = -50 °C to 70 °C Entity
	or
	Ex db eb [ib] IIB T4 Ta = -50 °C to 70 °C; FISCO and
	Ex db eb ib IIB T4 Ta = -50 °C to 70 °C Entity
	or
	Ex db eb ib IIB T4 Ta = -50 °C to 70 °C Entity
	or
	Ex db eb ib IIB T4 Ta = -50 °C to 70 °C Entity and
	Ex db eb [ia IIC] IIB T4 Ta = -50 °C to 70 °C Entity
	or
	Ex db eb [ib] IIB T4 Ta = -50 °C to 70 °C Entity and
	Ex db eb ib IIB T4 Ta = -50 °C to 70 °C Entity
	IP66; IP67

Special Conditions for Safe Use (X):

Ex marking	Comm. Bus	Ui	li	Pi	Ci	Li	Uo	lo	Ро	Со	Lo	Group
		V	mA	W	μ F	mH	V	mA	W	μ F	mH	
Ex db eb [ib] IIB T4 Gb	FISCO	-	-	-	-	-	15	354	5.32	-	-	IIB
Ex db eb [ia IIC Ga]	HART/4-20mA	-	-	-	-	-	23.1	95.3	0.55	0.14	3.9	IIC
IIB 14 Gb	Active									1.0	15	IIB
										3.67	33	IIA
Ex db eb ib IIB T4 Gb	HART/4-20mA Passive	30	300	1	0	0	-	-	-	-	-	IIB
Ex db eb [ib] IIB T4 Gb	Fieldbus	-	-	-	-	-	15	200	3	1.99	143	IIB

B.7 Brazil

B.7.1 E2 INMETRO Flame-proof

Certificate	UL-BR 17.1017X
Standards	ABNT NBR IEC 60079-0:2013, ABNT NBR IEC 60079-1:2016, ABNT NBR IEC 60079-7:2008, ABNT NBR IEC 60079-11:2013
Markings	Ex db e [ib] IIB T4 Gb Ex db e [ia IIC] IIB T4 Gb Ex db e ib IIB T4 Gb Tamb= -50 °C a +70 °C IP66/IP67

Special Conditions for Safe Use (X):

Ex marking	Comm. Bus	Ui V	li mA	Pi W	Ci μF	Li mH	Uo V	lo mA	Po W	Co μ F	Lo mH	Group
Ex db e [ib] IIB T4 Gb	FISCO	-	-	-	-	-	15	354	5.32	-	-	IIB
Ex db e [ia IIC Ga]	HART/4-20mA	-	-	-	-	-	23.1	95.3	0.55	0.14	3.9	IIC
IIB T4 Gb	Active									1.0	15	IIB
										3.67	33	IIA
Ex db e ib IIB T4 Gb	HART/4-20mA Passive	30	300	1	0	0	-	-	-	-	-	IIB
Ex db e [ib] IIB T4 Gb	Fieldbus	-	-	-	-	-	15	200	3	1.99	143	IIB

1. See certificate for special conditions.

B.8 China

B.8.1 E3 China Flame-proof

Certificate	GYJ17.1468X
Standards	GB 3836.1 – 2010, GB 3836.2 – 2010, GB 3836.3 – 2010, GB 3836.4 – 2010, GB 3836.20 – 2010
Markings	Ex d e [ib] IIB T4 Gb Ex d e [ia IIC Ga] IIB T4 Gb Ex d e ib IIB T4 Gb

Special Conditions for Safe Use (X):

Ex marking	Comm. Bus	Ui	li	Pi	Ci	Li	Uo	lo	Ро	Co	Lo	Group
		V	mA	W	μ ŀ	mH	V	mA	W	μ ŀ	mH	
Ex d e [ib] IIB T4 Gb	FISCO	-	-	-	-	-	15	354	5.32	-	-	IIB
Ex d e [ia IIC Ga] IIB	HART/4-20mA	-	-	-	-	-	23.1	95.3	0.55	0.14	3.9	IIC
14 Gb	Active									1.0	15	IIB
										3.67	33	IIA
Ex d e ib IIB T4 Gb	HART/4-20mA Passive	30	300	1	0	0	-	-	-	-	-	IIB

1. See certificate for special conditions.

B.9 Technical Regulations Customs Union (EAC)

B.9.1 EM EAC Flame-proof

 Certificate
 RU C-SE.AA87.B.00345

 Markings
 1Ex d e [ib] IIB T4 Gb

 1Ex d e [ia IIC Ga] IIB T4 Gb

 1Ex d e IIB T4 Gb

 Tamb= -50 °C a +70 °C

 IP66/IP67

Ex marking	Comm. Bus	Ui	li	Pi	Ci	Li	Uo	lo	Ро	Co	Lo	Group
		V	mA	W	μ ŀ	mH	V	mA	w	μŀ	mH	
Ex d e [ib] IIB T4 Gb	FISCO	-	-	-	-	-	15	354	5.32	-	-	IIB
Ex d e [ia IIC Ga] IIB	HART/4-20mA	-	-	-	-	-	23.1	95.3	0.55	0.14	3.9	IIC
14 Gb	Active									1.0	15	IIB
										3.67	33	IIA
Ex d e ib IIB T4 Gb	HART/4-20mA Passive	30	300	1	0	0	-	-	-	-	-	IIB
Ex d e [ib] IIB T4 Gb	Fieldbus	-	-	-	-	-	15	200	3	1.99	143	IIB
B.10 Japan

B.10.1 E4 Japan Flame-proof

Certificate	CML 17JPN2086X
Markings	Ex d e [ib] IIB T4 Gb; FISCO
	Ex d e [ia IIC Ga] IIB Gb T4; HART/4-20mA Active
	Ex d e ib IIB Gb; HART/4-20mA Passive

Special Conditions for Safe Use (X):

1. See certificate for special conditions.

Ex marking	Comm. Bus	Ui	li	Pi	Ci	Li	Uo	lo	Ро	Со	Lo	Group
		v	mA	w	μ F	mΗ	v	mA	W	μ F	mΗ	
Ex d e [ib] IIB T4 Gb	FISCO	-	-	-	-	-	14.96	343.3	5.14	-	-	IIB
Ex d e [ia IIC Ga] IIB	HART/4-20mA	-	-	-	-	-	23.1	95.3	0.55	0.14	3.9	IIC
14 Gb	Active									1.0	15	IIB
										3.67	33	IIA
Ex d e ib IIB T4 Gb	HART/4-20mA Passive	30	300	1	0	0	-	-	-	-	-	IIB

B.11 Republic of Korea

B.11.1 EP Korea Flame-proof

Certificate	13-KB4BO-0458, 13-KB4BO-0459, 13-KB4BO-0460
Markings	Ex de [ib] IIB T4
	Ex de [ia IIC] IIB T4
	Ex de [ib IIC] IIB T4
	(-50°C ≤ Ta ≤ +70°C)

Ex marking	Comm. Bus	Ui	li	Pi	Ci	Li	Uo	lo	Ро	Со	Lo	Group
		v	mA	w	μ F	mΗ	v	mA	w	μ F	mΗ	
Ex d e [ib] IIB T4	FISCO	-	-	-	-	-	15	354	5.32	-	-	IIB
Ex d e [ia IIC] IIB T4	HART/4-20mA	-	-	-	-	-	23.1	95.3	0.55	0.14	3.9	IIC
	Active									1.0	15	IIB
										3.67	33	IIA
Ex d e ib IIB T4	HART/4-20mA Passive	30	300	1	0	0	-	-	-	-	-	IIB

B.12 India

B.12.1 EW CCOE Flame-proof

Certificate	P380588/1
Markings	Ex d e [ib] IIB T4 Gb
	Ex d e [ia IIC Ga] IIB T4 Gb
	Ex d e ib IIB T4 Gb

Ex marking	Comm. Bus	Ui	li	Pi	Ci	Li	Uo	lo	Ро	Со	Lo	Group
		v	mA	W	μ F	mΗ	v	mA	w	μ F	mΗ	
Ex d e [ib] IIB T4 Gb	FISCO	-	-	-	-	-	15	354	5.32	-	-	IIB
Ex d e [ia IIC Ga] IIB	HART/4-20mA	-	-	-	-	-	23.1	95.3	0.55	0.14	3.9	IIC
14 Gb	Active									1.0	15	IIB
										3.67	33	IIA
Ex d e ib IIB T4 Gb	HART/4-20mA Passive	30	300	1	0	0	-	-	-	-	-	IIB
Ex d e [ib] IIB T4 Gb	Fieldbus	-	-	-	-	-	15	200	3	1.99	143	IIB

B.13 Additional certifications

B.13.1 Safety Certification (SIS)

3 Functional Safety

Certificate	ROS 1312032 C001
	SIL 3 2-in-1 (1002) option (SIS-relays)
Standards	IEC 61508:2010 Parts 1-7

S Functional Safety

Certificate	ROS 1312032 C004
	SIL 2 1-in-1 (1001) option, with 4-20mA or K1/K2 relay
Standards	IEC 61508:2010 Parts 1-7
Certificate	ROS 1312032 C005
	SIL 2 2-in-1 (1001) option, with 4-20mA or K1/K2 relay
Standards	IEC 61508:2010 Parts 1-7

B.14 Conduit plugs and adapters

IECEx Flameproof and Increased Safety

Certificate	IECEx FMG 13.0032X
Standards	IEC60079-0:2011, IEC60079-1:2007-04, IEC60079-7:2006-07
Markings	Ex d e IIC Gb

ATEX Flameproof and Increased Safety

Certificate	FM13ATEX0076X
Standards	EN60079-0:2012, EN60079-1:2007, IEC60079-7:2007
Markings	
	II 2 G Ex d e IIC Gb

Table B-1: Conduit Plug Thread Sizes

Thread	Identification mark
M20 x 1.5	M20
1/2 - 14 NPT	½ NPT

Table B-2: Thread Adapter Thread Sizes

Male thread	Identification mark
M20 x 1.5 – 6g	M20
1⁄2 - 14 NPT	½ - 14 NPT
³ ⁄ ₄ - 14 NPT	¾ - 14 NPT
Female thread	Identification mark
M20 x 1.5 – 6H	M20
1⁄2 - 14 NPT	½ - 14 NPT
G1/2	G1/2

B.15 Approval drawings

Follow the installation guidelines presented in Factory Mutual system control drawings in order to maintain certified ratings for installed devices.

The following drawings are included in the documentation for the Rosemount 2410 Tank Hub:

D9240040-901 System Control Drawing for hazardous location installation of FISCO intrinsically safe FM ATEX, FM IECEx, FM-US, and FM-C approved apparatus.

See the "Manuals & Drawings" CD ROM that is shipped with the Rosemount 2410 Tank Hub for electronic copies of the system control drawings.

Drawings are also available on: Rosemount 2410 Tank Hub drawings.

Fig	ure B-1: Sys	stem Control D	rawing				
WERK ISSUE OF ORDER No. WERK ISSUE OF ORDER NO. WERK ISSUE OF ORDER NO. WEEK ISSUE OF ORDER NO. WEEK 1113 3 SINE-8259 1555 4 SINE-8531 1629 5 SINE-9655 R43 6 SINE-9657 1910	ROSEMOUNT 2410 ENTITY POWER SUPPLY US/Ganada US/Canada ECEx PC 1, DIV 1, 655 C, D & Associated Apparatulus Ex db eb [1b] IIB 14 eb (-590-c13++79°C) providing 15 cares to C1, DIV 1, 655 C & D Ex db eb [1b] IIB 14 eb (-590-c13++79°C) DIP c1, III) DIV 1, 655 C & D ATEX DIP c1, III) DIV 1, 655 C & D ATEX DIP c1, III) DIV 1, 655 C & D ATEX DIP c1, III) DIV 1, 655 C & D ATEX DIP c1, III) DIV 1, 655 C & D ATEX DIP c1, III) DIV 1, 655 C & D ATEX	Installation Notes: 1. FISCO allows the interconnection of Approved intritiscally safe devices with FISCO and the interconnection of Approved intritiscally safe devices with FISCO 1. FISCO allows the interconnection of Approved intritiscally safe devices with FISCO 1. O, Voc or Vt = < U or Vmax, Io, loc or it = < ii or Imax, Po = < Pi or Pmax FISCO Parameters: Uo (Voc) = 15.0 V; lo (lsc) = 354 mA; Po (Pout) = 5.32 W 2. Control equipment connected to the Associates Apparatus must not use or generate more than 2. Control equipment connected to the Associates Apparatus must not use or generate more than 2. Control equipment connected to the Associates Apparatus must not use or generate more than 2. Control equipment connected to the Associates Apparatus must not use or generate more than 2. Control equipment connected to the Associates Apparatus must not use or generate more than 2. Control equipment connected to the Associates Apparatus must not use or generate more than 2. Control equipment connected to the Associates Apparatus must not use or generate more than 2. Control equipment connected to the Associates Apparatus must not use or generate more than 2. Control equipment connected to the Associates Apparatus must not use or generate more than 2. Control equipment connected to the Associates Apparatus must not use or generate more than 2. Control equipment connected to the Associates Apparatus must not use or generate more than 2. Control equipment connected to the Associates Apparatus must not use or generate more than 3. Control equipment connected to the Associates Apparatus must not use or generate more than 3. Control equipment connected to the Associates Apparatus must not use or generate more than 3. Control equipment connected to the Associates Apparatus must not use or generate more than 3. Control equipment connected to the Associates Apparatus must not use or generate more than 3. Control equipment connected to the Associate apparatus must not use or generate more than 3. Co	 the structure sease must be used when instanted in bases in any base in environments. Earth connection. Minimum cable area 4 mm2 Field Apparatus manufacturers installation drawing must be followed when installing this equipment. Installation in the USA should be in accordance with ANSNISA-PP12.6 "Installation of Intrinsically cable size systems for Hazardous (Classified) Locations" and the National Electrical Code (NNSINFPA 70). It is possible to disconnect the integrated termination by means of a jumper located inside 	8. The ENTITY CONCEPT allows the interconnection of Approved intrisically safe devices with ENTITY parameters not specifically examined in combination as a system when. Uo, Voc or Vt = < Ui or Vmax, lb, loc or ft = < Ii or Imax, Po = < Pi or Pmax.		Tested Provided and Control The product code The product code 0.0 0.04.4 0.04.4 24.10 SYSTEM CONTROL DWG. 0.1 0.02.9 6 Prepover of Control of Contro of Contro of Control of Control of Control of Control of Control	The second secon
ORIGINAL SIZE A3	FIELDBUS INTRINSICALLY SAFE CONCEPT (FISCO) APPROVAL FISCO allows interconnection of intrinsically safe apparatus to associated apparatus not specially examined in such combination. The critication is that the voltage (U) or Vmax), the current (i) or Imax), and the power (Pi or Pmax) which an intrinsically safe apparatus can receive and ramain intrinsically safe considering tauts, must be equal or greater than voltage (U) or cor VI), the current (io, iso rit) and the power (Pi or Pmax) which an intrinsically safe apparatus can receive and ramain intrinsically safe considering tauts, must be equal or greater than voltage (U) or cor VI), the current (io, iso rit) and the power (Pi or Pmax) here which an intrinsically the associated apparatus, considering tauts apparatus (onjer than the familiation) conceeded to the Fieldus must be less than or equal to 5 nF and	10 uH respectively. In each S. Freidens segment only one active device, normally the associated apparatus, is allowed to necessary energy for the Freidulus. The voltage (IIo, Voc or Vt) of the associated apparatus is provide the necessary energy for the Freidulus. The voltage (IIo, Voc or Vt) of the associated apparatus is limited to a range of 14 Vt or 17.5 V. In this instance Rosemount 2410 has voltage as given in table below. All other equipment connected on the bus cable has to be passive, meaning that they are not allowed to provide energy to the respirate abe to be passed contracted device. Separately powered equipment needs galvanc isolation to assure that the intrinsically safe Fieldbus circuit remains passive.	Loop Resistance Rc. 15150 ohm/km Loop Inductance Lc. 0.41 mH/km Capacitance per unit length Cc. 45200 hF/km C.C.=Co line to IIIe + 0.5 Cc line to screen, if both lines are floating or C.C.=Co line to IIIe + 0.5 Cc line to screen, if screen if screen if one line C.E.=Co line to IIIe + 0.5 Cc line to screen if screen if screen if comcel to one line Length of trunk cable: Less than or equal to 51 Mm for IIC (5Km for IIB)	At each end of the trunk cable an approved infallible line terminator with the following parameters should be installed: $R >=90 \text{ ohm}$, $C <=2.2 \text{ tr}$ (recommended parameters are: $R = 100.4 \cdot 20$ ahm, $C = 10.4 \cdot 0.2 \text{ uF}$). One of the allowed terminations might already be integrated in the associated apparatus. Rosemount 2410 is equipped with integrated limitation, see note 7. FISCO limits the number of passive devices connected to a single segment to 32 devices. If the above rules are respected, up to a total length of 1000 m (sum of trunk and spur cables) of cable is permitted. The inductance and capacitance of the cable will not impair the intrinsic safety of the installation.	ENTITY CONCEPT APPROVAL The Entity concept allows interconnection of intrinsically safe apparatus to associated apparatus not specifically storing in combination as a system. The approved values of max, open circuit voltage (0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0	WARNING - Substitution of components may impair Intrinsic Safety. WARNING - To prevent grittion of fammable or combustible atmospheres, disconnect power before servicing. AVERTISSEEMENT - La substitution de composants peut componentie la securité intrinsèque. AVERTISSEMENT - Ano securitor in a cado presence d'Atmosphere explosione.	AVELLI DOLINELY THE pas down or cas up preserve diamophrate explosive. FM Approved Product No revision to this draw without prior Factory M. Approval.











C Advanced configuration

C.1 Safety messages

Instructions and procedures in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that potentially raises safety issues is indicated by a warning symbol (\triangle). Refer to the following safety messages before performing an operation preceded by this symbol.

A WARNING

Failure to follow safe installation and servicing guidelines could result in death or serious injury.

- Ensure only qualified personnel perform the installation.
- Use the equipment only as specified in this manual. Failure to do so may impair the protection provided by the equipment.
- Do not perform any services other than those contained in this manual unless you are qualified.
- Any substitution of non-recognized parts may jeopardize safety. Repair (e.g. substitution of components) may also jeopardize safety and is not allowed under any circumstances.

Explosions could result in death or serious injury.

- Verify that the operating environment of the device is consistent with the appropriate hazardous locations certifications.
- Before connecting a handheld communicator in an explosive atmosphere, ensure that the instruments in the loop are installed in accordance with intrinsically safe or non-incendive field wiring practices.
- Do not remove the gauge cover in explosive atmospheres when the circuit is alive.
- To prevent ignition of flammable or combustible atmospheres, disconnect power before servicing.

High voltage that may be present on leads could cause electrical shock.

- Avoid contact with leads and terminals.
- Ensure the main power to the Rosemount 2410 Tank Hub is off and the lines to any other external power source are disconnected or not powered while wiring the gauge.

C.2

Access the advanced configuration options in WinSetup

There are advanced configuration options for the Rosemount[™] 2410 Tank Hub which are not included in the TankMaster WinSetup installation wizard. These options are available via the *Properties* option in the WinSetup configuration software.

Procedure

- 1. In the *TankMaster WinSetup* workspace, right-click the Rosemount 2410 Tank Hub icon.
- 2. Choose the **Properties** option.
- The **2410 Tank Hub** window appears.
- 3. Select the **Configuration** tab.

🗍 2410 Tank Hub - HUB-110			×
Communication Configuration	Tank Database Device Tags Local Disp	ay Advanced Configuration	
Primary Bus	: Virtual Relay No 1	Hybrid Density No 1	
Secondary B	us Virtual Relay No 2	Hybrid Density No 2]
Enraf Emulati	on Virtual Relay No 3	Hybrid Density No 3	
Enraf Maste	r Virtual Relay No 4		
	Virtual Relay No 5	Delta Level]
	Virtual Relay No 6	Analog Output]
	Virtual Relay No 7		
	Virtual Relay No 8		
	Virtual Relay No 9		
	Virtual Relay No 10		
	0	K Cancel <u>A</u> pply	Help

The *Configuration* window contains buttons for Primary and Secondary Bus, Virtual Relays, and Hybrid Density calculation.

Related information

Change the communication parameters for the primary bus Open the secondary bus window Configure a virtual relay output Set up a Rosemount 2410 for hybrid density applications

C.3

Change the communication parameters for the primary bus

The Rosemount 2410 has a Primary Bus which is used for communication with a Rosemount 2460 System Hub. It may also be connected directly to a control room PC. The Primary Bus supports TRL2, RS485, and other communication buses. The Rosemount 2410 automatically detects what modem is installed in the Primary Bus slot and communication parameters are set accordingly. For some modem types (such as RS485) the non standard option allows you to configure communication with other protocols than the standard Modbus[®].

Procedure

- 1. Open the *Primary Bus* window.
 - a) In the *TankMaster WinSetup* workspace, right-click the Rosemount 2410 Tank Hub icon.
 - b) Choose the **Properties** option. The **2410 Tank Hub** window appears.
 - c) Select the **Configuration** tab.
 - d) Click the Primary Bus button.

The *Primary Bus Configuration* window lets you configure protocol, baudrate, and other communication parameters when the standard settings are not appropriate.

Modem :	TRL2			
Configuration :	Standard	-		
- Non Standard	Configuration		Standard Conl	figuration
Protocol :	Auto Detect	-	Protocol :	Modbus
Baudrate :		-	Baudrate :	4800
DataBits :		~	DataBits :	8
Parity :		-	Parity :	None
Stop Bits :		T	Stop Bits :	1

- 2. To change communication parameters:
 - a) In the **Configuration** drop-down menu, change from **Standard** to **Non Standard**.
 - b) Choose the desired Protocol.
 - c) Choose appropriate communication parameter values for Baudrate, Databits, Parity, and Stop Bits.

d) Click **Apply** to store the current configuration, or click **OK** to store the configuration and close the **Primary Bus Configuration** window.

C.4 Open the secondary bus window

The Rosemount 2410 Secondary Bus is used for communication with emulated devices. It supports many different modems and protocols such as the TRL2 Modbus, Enraf, Varec, and L&J.

Procedure

- 1. In the *TankMaster WinSetup* workspace, right-click the Rosemount 2410 Tank Hub icon.
- 2. Choose the **Properties** option. The **2410** *Tank Hub* window appears.
- 3. Select the **Configuration** tab.
- 4. Click the Secondary Bus button.

The **Secondary Bus Configuration** window allows you to change protocol, baudrate, address, and other communication settings.

Modem : Enraf BPM			
Configuration : Standard	Ŧ		
Non Standard Configuration		Standard Con	figuration
Protocol : Auto Detect	-	Protocol :	Enraf
Baudrate :	T	Baudrate :	1200
DataBits :	_	DataBits :	7
Parity :	T	Parity :	Odd
Stop Bits :	T	Stop Bits :	1

C.5 Configure a virtual relay output

The Rosemount 2410 has two relays which can be configured with one or two set points. Virtual relay output, (Disabled, Relay1, Relay2), source, set-point etc. can also be specified.

The Rosemount 2410 Tank Hub supports virtual relay functionality that lets you specify up to ten source parameters to control the two hardware relays. The output of a virtual relay can be directed towards any of the two relays, allowing a high configuration flexibility. You may, for example, use one of the relays (Relay1 or Relay2) as a high level alarm for several tanks by using Level as source parameter for each tank. Many other configurations are possible using the two relays for various virtual relay configurations.

Procedure

- 1. In the TankMaster WinSetup workspace, right-click the Rosemount 2410 icon.
- 2. Choose the **Properties** option. The **2410 Tank Hub** window appears.
- 3. Select the **Configuration** tab.
- 4. Click one of the Virtual Relay No. buttons.

📋 2410 Tank Hub Virtual Relay No 1	- HUB-101	
 Virtual Relay Output C Disabled In Relay 1 C Relay 2 	Virtual Relay Zone	The Arrow Shows the direction the Variable is ascending, from lowest to highest value. —— Point in absolute value. Hysteresis in absolute value.
Source Tank Name / Tank Position:	Second Point	Virtual Relay State in Zone 3: Zone 3 Alarm (Reset)
, Tank Parameter: Level ▼	Hysteresis: -0.1000	29,4000 Zone 2 Normal
Switch Delay: Ioggle Period: 0.0 s 5.0 s Disable Invalid Parameter Alarm	Point: 1.0000 Hysteresis: 0.1000	FIRST 1.0000 PDINT 1.0000 Virtual Relay State in Zone <u>1</u> : Zone 1 Alarm (Reset) -
Virtual Relay Status:		Current Source Value: 18.96837
СК		Description: Normal (Active) : Alarm (Not Agtive) : Opened Closed
		OK Cancel <u>Apply</u> Help

C.5.1 Using two/three relay zones

You may use two or three relay zones. Different relay states can be used in each of these zones.

With two relay zones, use one set point: First Point.

With three relay zones, use two set points: First Point and Second Point.

C.5.2 First and second set points

The first and second set points define the transitions between Zone 1, 2 and 3. You can set different relay states in each of these zones.

First Point defines the transition between Zone 1 and 2.

Second Point defines the transition between Zone 2 and 3.

C.5.3 Hysteresis

When the source variable passes a set point, the relay switches from one state to the other. When the source signal returns back into the previous zone, the relay does not switch back to the previous state until it has passed both the set point and the hysteresis zone.

C.5.4 Virtual relay states

There are three virtual relay states available:

Table C-1: Rosemount 2410 Relay States

Virtual Relay State	Description
Alarm	In the Alarm state the relay is de-energized. Depending on how the relays are connected, they will be either open or closed in the de-energized state.
	Note that a relay defined as Normally Open will be open in the Alarm state.
	If the relay is configured as Normally Closed it will be closed in the Alarm state.
Normal	In the Normal state the relay is energized.
Toggle	The relay switches periodically between Normal and Alarm

The Virtual Relay Output setting determines whether the relays are active or disabled.

Table C-2: Rosemount 2410 Relay Control Modes

Virtual Relay Output	Description
Disabled	The relay function is turned off.
Relay 1/Relay 2	Specifies the actual relay that the Relay Output is connected to. The Rosemount 2410 Tank Hub can be equipped with one or two relays.

C.5.5 Source

Specifies the measurement variable that triggers the relay switching.

"Tank Name/Tank Position" refers to the tank position in the Rosemount 2410 tank database. The tank database maps all devices connected to the Rosemount 2410 Tank Hub to the specific tanks, see the Rosemount Tank Gauging System Configuration Manual (Document no. 00809-0300-5100) for more information about configuration of the Rosemount 2410 tank database.

Tank Parameter refers to the measurement variable that triggers the relay switching. For example, Level, Delta_Level, Ullage or any other variable can be chosen as source.

C.5.6 Switch delay

This is the delay time for the relay to switch into alarm state, i.e. the amount of time it takes for a relay to respond to an alarm. You can use this parameter to prevent the relay from switching due to small temporary variations of the source signal. This may for example occur if there is a turbulent product surface.

C.5.7 Toggle period

When the relay is in Toggle state it switches between On and Off at a rate defined by the Toggle Period.

C.5.8 Relay output configuration

The relay output can be selected as either Normally Open or Normally Closed referring to the contact position when the relay is de-energized. This also refers to the Alarm (Reset) state.

The relay terminology can be summarized as shown in Table C-3:

Table C-3: Relay state terminology

Normall	y Closed	Normal	ly Open
Closed	Open	Open	Closed
De-energized Energized		De-energized	Energized
Not Active Active		Not Active	Active
Alarm (Reset) Normal		Alarm (Reset)	Normal

Related information

Relay output configuration

C.5.9 Relay zones

You can use one or two set points for relays connected to the Rosemount 2410 Tank Hub. Consequently, there are two or three zones in which different relay states can be specified. For each zone you can set any of the three available relay states Normal, Alarm or Toggle.

For each set point you can specify a hysteresis zone preventing the relay from switching back to its previous state as long as the source variable is changed only small amounts around a certain set point. The principle of relay set points and hysteresis zones is shown in the figure below. Note that in this example only two states are used.



- A. Source signal
- B. Set Point 2
- C. Set Point 1
- D. Relay state
- E. Relay State Zone 1
- F. Relay State Zone 2
- G. Relay State Zone 3
- H. Time
- I. ZONE 3
- J. ZONE 2
- K. ZONE 1
- L. Hysteresis zone
- 1. The source signal passes set point 1, and the relay state changes according to the definition for Zone 1.
- 2. When the source signal returns into Zone 2, it does not change to the Zone 2 state until it has passed the hysteresis zone.
- 3. The source signal passes set point 2, and the relay state is changed according to the definition for Zone 3.
- 4. The relay switches back to the Zone 2 relay state when the source signal has passed set point 2 and the associated hysteresis value.

C.6

Set up a Rosemount 2410 for hybrid density applications

The Rosemount TankMaster software can be used in a hybrid density system to calculate Observed Density. Density calculations are also available for a host system connected directly to a Rosemount 2410 without using TankMaster. Then the density calculations are performed internally by the Rosemount 2410 Tank Hub.

Procedure

- 1. Install and connect the devices on the tank including the Vapor Pressure sensor (P3) and the Liquid Pressure sensor (P1).
- 2. Start the TankMaster Winsetup configuration program.
- 3. Configure the Rosemount 2410 Tank Hub⁽¹⁵⁾. Ensure that the appropriate devices are associated with the current tank in the Rosemount 2410 tank database as illustrated below.

Example

In the example below a Rosemount 5900S Radar Level Gauge, a Rosemount 2240S Multi-input Temperature Transmitter, and two Rosemount 3051S Pressure Transmitters (P1 and P3) are installed on the tank.

	Device Type	Unit ID	Device connected to field bus	Tank Position		Tank Position	Tank Name	Level Modbus Address	ATD Modbus Address
1	3051 Pressure	2169359407	Yes	1		1	TK-1	1	101
2	3051 Pressure	2236835852	Yes	1		2			
3	5900 RLG	0	Yes	1		3			
4	2240 MT T	16	Yes	1		4			
5	No Device		No	Not Configured		5			
6	No Device		No	Not Configured	-	6			
7	No Device		No	Not Configured	-	7			
8	No Device		No	Not Configured	-	8			
9	No Device		No	Not Configured	-	9			
10	No Device		No	Not Configured	-	10			
11	No Device		No	Not Configured	1-				
12	No Device		No	Not Configured	Enter tank name with max 10 characters.				
13	No Device		No	Not Configured	ť	'ne name v 'he name v	viii de used in heid vill also he used a	a aispiays. Is base for the	
14	No Device		No	Not Configured	d	levice tags	in TankMaster.		
15	No Device		No	Not Configured					
16	No Device		No	Not Configured					

- 4. Configure the Rosemount 5900S Radar Level Gauge⁽¹⁵⁾.
- 5. Configure the Auxiliary Tank Devices⁽¹⁵⁾ (Rosemount 2240S Multi-input Temperature Transmitter).

⁽¹⁵⁾ See the Rosemount Tank Gauging System Configuration Manual (Document no. 00809-0300-5100) for more information.

6. In the **22XX ATD/Advanced Parameter Source Configuration** window, ensure that the Vapor Pressure (P3) and Liquid Pressure (P1) parameters are mapped to the actual source devices on the tank as shown below.

In case there is no vapor pressure sensor installed, a manual value can be used instead.

22XX ATD - ATD-T	K-1						
Communica 2240 MTT Auxilian	ation v Sensor	2230 Gra	Average Temperature Calculation	alog Input	2240 MT Advanced Pa	T Temperature Sensor arameter Source Configu	ration
Parameter Mapping	, 1					, s	
Vapor Pressure	▼ barG	Ŧ	Source Device Type / ID / No 3051 PT / 268441203 / (No 1)	Pressure 1	er T		
Liquid Pressure	▼ barG	-	3051 PT / 238041201 / (No 2)	Pressure 1	•		
Level	▼ m	v	Not Configured	Level	-		
Level	▼ m		Not Configured	Level	-		
Level	y m	Ţ	Not Configured	Level	Ŧ		
Level		Ţ	Not Configured	Level	Ŧ		
		0	 Show only devices configured for tank po Show all devices. 	sition: 1			
Description of User Def p	arameter			Manual Value Cor	figuration		
User Def 2 desc:							
User Def 3 desc:							
User D ef 4 desc:							
User D ef 5 desc:							
				ОК	Cancel	Apply	Help

- 7. Configure the Hybrid Density function, see Hybrid density configuration.
- 8. Configure the tank as described in the Rosemount Tank Gauging System Configuration Manual.

C.6.1 Hybrid density configuration

To configure the hybrid density function do the following:

Procedure

- 1. In the *TankMaster WinSetup* workspace, right-click the Rosemount 2410 icon.
- 2. Choose the **Properties** option. The **2410 Tank Hub** window appears.
- 3. Select the **Configuration** tab.
- 4. Click the **Hybrid Density No. [X]** button to open the **2410 Tank Hub Hybrid Density Configuration** window. Up to three tanks can be configured for Hybrid Density calculations.

2410 Tank Hub - HUB-101				_ X
Primary Bus	Virtual Relay No 1	Hybrid	Density No 1	
Secondary Bus	Virtual Relay No 2	Hybrid	Density No 2	
	Virtual Relay No 3	Hybrid	Density No 3	
	Virtual Relay No 4			
	Virtual Relay No 5			
	Virtual Relay No 6			
	Virtual Relay No 7			
	Virtual Relay No 8			
	Virtual Relay No 9			
	Virtual Relay No 10			
	ОК	Cancel	<u>A</u> pply	Help

5. From the **Tank Name/Hub Position** drop-down list select the tank to be configured for hybrid density calculations.



6. Enter Local Gravity, Air Density and Vapor Density. These parameters are used for calculating the Observed Density.

See the TankMaster WinOpi Reference Manual (Document No. 00809-0200-5110) for more information on inventory calculations. Enter Upper and Lower Density Limits for the Observed Density. Density values outside this range will be notified by TankMaster.

7. Enter the P1 Sensor Position, i.e. the position of the center of the Liquid Pressure sensor membrane.

8. Enter the Hybrid Min Level.

This value specifies the lowest product level at which TankMaster calculates the Observed Density. Normally, the accuracy of pressure sensors is reduced at low pressures, i.e. at product levels close to the sensor membrane. Therefore, you can specify a limit below which the density calculation is "frozen". For example, if Hybrid Min Level is equal to 2.0 meter, the Rosemount Tank Gauging system will present a fixed density value for product levels below 2.0 meter.

Note

Specify the actual product level and not the distance between the pressure sensor and the product surface.

- 9. Enter the P3 Sensor Position, i.e. the position of the center of the Vapor Pressure sensor membrane measured from the tank Zero Level/Datum Plate.
- 10. Click the **OK** button to save the Hybrid Density configuration.

C.7 Volume configuration

To configure the Rosemount 2410 Tank Hub for volume calculations, choose one of the standard tank shapes, or the strapping table option, see Table C-4. Select None if volume calculation is not used. For the standard tanks, a Volume Offset parameter can be specified to be used for a non-zero volume that corresponds to the Zero Level. This may be useful, for example, if you like to include the product volume below the zero level.

Volume calculation is performed by using a predefined tank shape or a strapping table.

Note

For application software version 1.B5 and older, tank volume calculation has to be enabled in Holding Register 6136.

One of the following standard tank shapes can be chosen:

- Sphere
- Horizontal Cylinder
- Vertical Cylinder
- The following parameters must be entered for a standard tank shape:
- Tank diameter
- Tank length (for horizontal cylinder)
- Volume Offset (use this parameter if you like to include product volume below the zero level)
- For application software version 1.B5 and older, tank volume calculation has to be enabled by setting bit 31 "TANK_VOLUME" in Holding Register 6136

Related information

Enable volume calculation in a Rosemount 2410 Tank Hub

C.7.1 Strapping table

The Strapping Table option should be used when the tank shape deviates significantly from an ideal sphere or cylinder, or when high volume accuracy is required.

The Strapping Table divides the tank into segments. Level values and corresponding volumes are entered starting at the bottom of the tank. These figures can typically be obtained from tank drawings or from a certificate provided by the tank manufacturer.

A maximum of 100 strapping points can be entered. For each level value the corresponding total volume up to the specified level is entered. The volume value is interpolated if the product surface is between two level values in the table.

C.7.2 Holding and Input registers for volume configuration

Holding registers 4300 to 4732 are used for volume configuration. The different parameters are given in Table C-4.

Name	Holding Register	Description
Volume control	4300	Bit 1: Volume over Zero. By setting this bit presentation of negative volumes for product levels below the Zero level is prevented.
Tank Geometry	4302	0: None 1: Strapping table 2: Sphere 3: Horizontal cylinder 4: Vertical cylinder
Strap table length	4304	Number of strapping table points used
Zero Level To Bottom	4306	Distance from zero level to the tank bottom
L1	4308	Tank diameter
L2	4310	Tank length (for horizontal cylinder)
Interpolation method	4314	0: linear 1: Quadratic
Level offset	4316	Strapping table offset. You can use this function to shift the zero level (empty tank) from the Datum Plate to the bottom of the tank. The Level Offset will be added to the measured level and then used to find the corresponding volume value in the strapping table. A positive Level Offset value will increase the displayed volume.

Table C-4: Holding Registers for Volume Configuration

Name	Holding Register	Description
Volume offset	4318	Strapping table volume offset. Use this function to include product volume below the zero level. This offset will be added to the calculated volume.
		Note The Volume Offset is added when predefined tank shapes are used as well.
Volume unit	4320	40: Us Gallons 41: Liter 42: UK Gallons 43: Cubic Meter 46: Barrels 112: Cubic Feet
Tank no. (The Rosemount 2410 tank database shows which devices are mapped to the different tanks)	4322	0: not active 1: tank 1 2: tank 2 n: tank n 10: tank 10
Strap table level 0	4334	Level value for strapping table point no. 0
Strap table volume 0	4336	Volume value for strapping table point no. 0
Strap table level 1	4338	Level value for strapping table point no. 1
Strap table volume 1	4340	Volume value for strapping table point no. 1
Strap table level 99	4730	Level value for strapping table point no. 99
Strap table volume 99	4732	Volume value for strapping table point no. 99

Table C-4: Holding Registers for Volume Configuration (continued)

The TankMaster WinSetup program lets you edit Holding registers for volume calculations as illustrated in Figure C-2.

Search for C <u>P</u> redefined • <u>A</u> ll (Advanced) Register Size:	16 bits 💌	Show Values in —		
<u>è</u> tart Register:	<u>N</u>	umber of Registers		
4300	3	0	1	
Name	Register	Value	Unit	•
Vol-VolControl	4300	0		
Vol-TankGeometry	4302	4		
Vol-StrapTableLength	4304	0		_
Vol-ZeroLevelToBottom	4306	0	m	
Vol-L1	4308	10	m	
Vol·L2	4310	0	m	
Vol-Reserved_L3	4312	0	m	
Vol-InterpolateMethod	4314	0		
Vol-LevelOffs	4316	0	m	
Vol-VolumeOffs	4318	0	m3	•

Figure C-2: Holding Register View for Volume Configuration in TankMaster WinSetup

When the Rosemount 2410 is configured for volume calculations the resulting volume values are available in input register area IR3400 to IR3458, IR4700 to IR4710, and IR30000 to IR38000 as illustrated in Figure C-3.

The volume calculation result is available in input register IR4702 as well as in input register area starting with IR3400 (tank 1). The result can be presented in the *View Input Registers* window as illustrated in Figure C-3.

T View Input Registers - HUB-101 (Version 1.A1)					
Search for Show Values in					
Predefined Ope					
<u>S</u> tart Register:	Num	ber of Registers			
4700	50				
Name	Register	Value	Unit		
TankVolume-Level	4700	14.4683	m		
TankVolume-Volume	4702	1136.33	m3		
TankVolume-InitStatus	4704	0			
TankVolume-CalcStatus	4706	0			
TankVolume-UsedTankGeometry	4708	4			
TankVolume-UsedInterpolateFunction	4710	0			
DWORD	4712	9999			
DWORD	4714	9999			
DWORD	4716	9999			
DWORD	4718	9999		-	
View Input Registers - HUR-101 (Version 1.A1)					
Tiew Input Registers - HUB-101 (Versio	on 1.A1)			x	
📋 View Input Registers - HUB-101 (Versio	on 1.A1)		l	x	
View Input Registers - HUB-101 (Versic Search for	on 1.A1) Sh	ow Values in	Ŀ	x	
View Input Registers - HUB-101 (Versic Search for C Predefined	on 1.A1)	ow Values in — • <u>D</u> ec		×	
View Input Registers - HUB-101 (Versic Search for C predefined G All (Advanced) Register Size: Defa	on 1.A1)	ow Values in — ● <u>D</u> ec ⊃ <u>H</u> ex		x	
View Input Registers - HUB-101 (Versic Search for C predefined C (Al (Advanced) Register Size: Defa Start Register:	on 1.A1)	ow Values in Dec <u>H</u> ex ber of Registers	:	×	
View Input Registers - HUB-101 (Versic Search for C Predefined C Al (Advanced) Register Size: Defa Start Register: 3400	on 1.A1)	ow Values in ● <u>D</u> ec ○ <u>H</u> ex ber of Registers		×	
View Input Registers - HUB-101 (Versic Search for C predefined C All (Advanced) Register Size: Defa Start Register: 3400 Name	In 1.A1)	ow Values in Dec Hex ber of Registers Value	Unit	×	
View Input Registers - HUB-101 (Versic Search for Predefined All (Advanced) Register Size: Defa Start Register: [3400 Name StdVolumeAree-TK1_Volume	In 1.A1)	ow Values in Dec Hex ber of Registers Value 1136.33	Unit	×	
View Input Registers - HUB-101 (Versic Search for Predefined All (Advanced) Register Size: Defa Stat Register: 3400 Name StdVolumeArea-TK1_Volume StdVolumeArea-TK1_FlowRate	on 1.A1)	ow Values in Dec Hex ber of Registers Value 1136.33 0	Unit	×	
View Input Registers - HUB-101 (Versic Search for Predefined All (Advanced) Register Size: Defa Start Register: [3400 Name StdVolumeArea-TK1_Volume StdVolumeArea-TK1_FlowPate StdVolumeArea-TK1_Status	n 1.A1)	ow Values in Dec Hex ber of Registers Value 1136.33 0 0	Unit		
View Input Registers - HUB-101 (Versic Search for Predefined All (Advanced) Register Size: Defa Stat Register: 3400 Name StdVolumeArea-TK1_Volume StdVolumeArea-TK1_FlowRate StdVolumeArea-TK1_Status StdVolumeArea-TK2_Volume	n 1.A1)	ow Values in Dec Hex ber of Registers Value 1136.33 0 0 0	: Unit		
View Input Registers - HUB-101 (Versic Search for Pedefined All (Advanced) Register Size: Defa Stat Register: 3400 Name StdVolumeArea-TK1_Volume StdVolumeArea-TK1_FowRate StdVolumeArea-TK2_Volume StdVolumeArea-TK2_Volume StdVolumeArea-TK2_Volume	n 1.A1) Null Null Null Null Null So Register 3400 3402 3404 3406 3408	ow Values in ▶ Dec Hex ber of Registers Value 1136.33 0 0 0 0 0	Unit		
View Input Registers - HUB-101 (Versic Search for C Bredefined d d dvanced) Register Size: Defa Star Register: [3400 Name StdVolumeAvea-TK1_Volume StdVolumeAvea-TK1_Status StdVolumeAvea-TK2_Status StdVolumeAvea-TK2_Status StdVolumeAvea-TK2_Status StdVolumeAvea-TK2_Status	n 1.A1)	ow Values in • Dec • Hex ber of Registers Value 1136.33 0 0 0 0 0 0 0	Unit	×	
View Input Registers - HUB-101 (Versic Search for Predefined All (Advanced) Register Size: Defa Stat Register: 3400 Name StdVolumeArea-TK1_Volume StdVolumeArea-TK1_Volume StdVolumeArea-TK2_Volume StdVolumeArea-TK2_Volume StdVolumeArea-TK2_Volume StdVolumeArea-TK2_Volume StdVolumeArea-TK2_Volume StdVolumeArea-TK2_Volume StdVolumeArea-TK2_Volume StdVolumeArea-TK2_Volume StdVolumeArea-TK2_Volume StdVolumeArea-TK3_Volume	n 1.A1)	ow Values in	Unit	×	
View Input Registers - HUB-101 (Versic Search for Pedefined All (Advanced) Register Size: Defa Stat Register: 3400 Name StdVolumeArea-TK1_Volume StdVolumeArea-TK1_FlowRate StdVolumeArea-TK2_Volume StdVolumeArea-TK2_FlowRate StdVolumeArea-TK2_FlowRate StdVolumeArea-TK2_Volume StdVolumeArea-TK3_FlowRate StdVolumeArea-TK3_Volume	n 1.A1) Num 50 Num 50 3402 3404 3408 3410 3412 3414	ow Values in	Unit		
View Input Registers - HUB-101 (Versic Search for Dedefined dial (Advanced) Register Size: Defa Start Register: 3400 Name StdVolumeArea-TK1_Volume StdVolumeArea-TK1_Volume StdVolumeArea-TK2_Status StdVolumeArea-TK2_FlowRate StdVolumeArea-TK2_FlowRate StdVolumeArea-TK2_FlowRate StdVolumeArea-TK3_FlowRate StdVolumeAre	n 1.A1) Num Num Num Num So Register 3400 3402 3404 3406 3410 3412 3412 3415	w Values in Dec Hex ber of Registers Value 1136.33 0 0 0 0 0 0 0 0	Unit		
View Input Registers - HUB-101 (Versic Search for Predefined All (Advanced) Register Size: Defa Stat Register: 3400 Name StdVolumeArea-TK1_Volume StdVolumeArea-TK1_Volume StdVolumeArea-TK2_Volume StdVolumeArea-TK2_Volume StdVolumeArea-TK2_Volume StdVolumeArea-TK3_Status StdVolumeArea-TK3_FlowRate StdVolumeArea-TK3_FlowRate StdVolumeArea-TK3_FlowRate StdVolumeArea-TK3_FlowRate StdVolumeArea-TK3_Status StdVolumeArea-TK3_Volume StdVolumeArea-TK3_Volume StdVolumeArea-TK3_Volume StdVolumeArea-TK3_Volume StdVolumeArea-TK3_Volume StdVolumeArea-TK3_Volume StdVolumeArea-TK3_Volume StdVolumeArea-TK4_Volume	on 1.A1)	> Dec > Dec > Hex > ber of Registers Value 1136.33 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Unit		
View Input Registers - HUB-101 (Versic Search for Predefined All (Advanced) Register Size: Defa Stat Register: 3400 Name StdVolumeArea-TK1_Volume StdVolumeArea-TK1_Volume StdVolumeArea-TK2_Volume StdVolumeArea-TK2_FlowRate StdVolumeArea-TK2_Status StdVolumeArea-TK2_Status StdVolumeArea-TK3_Status StdVolumeArea-TK3_Status StdVolumeArea-TK3_Status StdVolumeArea-TK3_Status StdVolumeArea-TK3_Status StdVolumeArea-TK3_Status StdVolumeArea-TK3_Status StdVolumeArea-TK3_Volume Clientea-Cli	n 1.A1) Num 50 Register 3402 3402 3406 3408 3412 3414 3418 3418 ose	w Values in ▶ Dec Hex ber of Registers Value 1136.33 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Unit		

Figure C-3: Input Register View for Volume Read-out in TankMaster WinSetup

The volume values are also available in input register area starting with IR30000 (IR30148 for tank 1).

Related information

Viewing input and holding registers using TankMaster

Enable volume calculation in a Rosemount 2410 Tank Hub

For application software version 1.B5 and older, tank volume calculation has to be enabled by setting bit 31 "TANK_VOLUME" in Holding Register 6136.

Procedure

- 1. In the *TankMaster Winsetup* workspace, right-click the Rosemount 2410 icon.
- 2. Choose the View Holding Registers option.
- 3. In the Start Register box, type 6136, and then click the Read button.

TView Holding Registers - HUB-104 (Version 1.B5)				
Search for Registers Type Registers Size:		ow Values in		
All registers Vice Default				
Registers Scope		C <u>H</u> exadecimal		
<u>S</u> tart Register:	N	umber of Regist	ers:	
6136		10		
Name Re		Value	Unit 🔺	
SysCtrl-BlockAutoMap1	6136	0		
SysCtrl-BlockAutoMap2	6138	U		
SysCtrl-StdQ_LevelUnit	6140	44		
SysCtrl-StdQ_LevelRateUnit	6142	247		
SysCtrl-StdQ_TempElementUnit	6144	153391689		
SysCtrl-StdQ_TempUnit	6146	33		
SysCtrl-StdQ_Reserved	6148	0		
SysCtrl-StdQ_PressureUnit	6150	519		
SysCtrl-StdQ_DensityUnit	6152	92		
SysCtrl-StdQ_VolumeUnit	6154	43	-	
<u>R</u> ead <u>Apply</u>	Close	+	lelp	

- 4. For register 6136, double-click the Value field.
- 5. Scroll down to bit 31. If bit 31=0, double-click the Value field to set bit 31=1.

	Name	Value 🔺
19	TEMP_7	0 -
20	TEMP_8	0
21	TEMP_9	0
22	TEMP_10	0
23	TEMP_11	0
24	TEMP_12	0
25	TEMP_13	0
26	TEMP_14	0
27	TEMP_15	0
28	TEMP_16	0
29	OBSERVED_DENSITY	0
30	REFERENCE_DENSITY	0
31	TANK_VOLUME	1
		•
ок	Cancel	Help

- 6. Click OK.
- 7. In the *View Holding Registers* window, click the Apply button and close the window.

C.8 Arithmetic operations

The Rosemount 2410 Tank Hub supports various arithmetic calculations. Holding Registers 4800 to 4879 are used for up to 10 arithmetic operations. You may perform several operations for multiple tanks.

Arithmetic operations can, for example, be used to calculate the difference between product levels measured by two level gauges.

Name	Holding Register no.	Description
Arithmetic1 operation	4800	Arithmetic operation to perform 0: None 1: Subtraction 2: Addition 3: Multiplication 4: Division
Arithmetic1 miscellaneous configuration	4801	Ignore Source Unit
Arithmetic1 TMV type destination	4802	Tank measurement variable in which the result is stored. 56: TMV Delta Level 60: TMV User Defined 1 61: TMV User Defined 2 62: TMV User Defined 3 63: TMV User Defined 4 64: TMV User Defined 5
Arithmetic1 tank number destination	4803	Tank in which the result is stored. 0: Not active 1: Tank 1 2: Tank 2 3: Tank 3 4: Tank 4 5: Tank 5 6: Tank 6 7: Tank 7 8: Tank 8 9: Tank 9 10: Tank 10
Arithmetic1 A TMV Type	4804	Tank measurement variable type for arithmetic operation parameter A

Table C-5: Rosemount 2410 Holding Registers for Arithmetic Operations

Name	Holding Register no.	Description
Arithmetic1 A tank number	4805	Tank for the arithmetic operation parameter A.
		0: Not active
		1: Tank 1
		2: Tank 2
		3: Tank 3
		4: Tank 4
		5: Tank 5
		6: Tank 6
		7: Tank 7
		8: Tank 8
		9: Tank 9
		10: Tank 10
Arithmetic1 B TMV Type	4806	Tank measurement variable type for arithmetic operation parameter B
Arithmetic1 B tank	4807	Tank for the arithmetic operation parameter B.
number		0: Not active
		1: Tank 1
		2: Tank 2
		3: Tank 3
		4: Tank 4
		5: Tank 5
		6: Tank 6
		7: Tank 7
		8: Tank 8
		9: Tank 9
		10: Tank 10
Arithmetic2 operation	4808	
Arithmetic3 operation	4816	
-	-	
Arithmetic10 operation	4872	

Table C-5: Rosemount 2410 Holding Registers for Arithmetic Operations (continued)

See Delta level calculation for an example on how to set up arithmetic operations.

C.8.1 Delta level calculation

The following example illustrates how to use TankMaster WinSetup to configure a Rosemount 2410 to calculate the difference between product levels for two tanks Tank

No. 1 and Tank No. 3. The result is stored in tank measurement variable Delta_Level in Tank 1.

A Virtual Relay Output can be configured to use the measurement variable Delta_Level as source parameter to trigger the relay whenever the level difference exceeds a specified value.

Figure C-4: Arithmetic Operations are Configured in Holding Registers 4800 to 4879

🛅 View Holding Registers - HUB-101 (Ver	sion 1.A1)		X	
Search for		w Values in		
• Predefined		Dec		
С <u>A</u> ll (Advanced)	0	े <u>Н</u> ех		
<u>S</u> tart Register:	<u>N</u> umt	per of Registers:		
TmvArithmetic-Arithm1_Operation	▼ 50			
Name	Register	Value	Unit 🔺	
TmvArithmetic-Arithm1_Operation	4800	1 🔫		-1
TmvArithmetic-Arithm1_MiscConfig	4801	0		
TmvArithmetic-Arithm1_TmvTypeDest	4802	56 🔫		-2
TmvArithmetic-Arithm1_TankNoDest	4803	1 🔫	•	- 3
TmvArithmetic-Arithm1_A_TmvType	4804	0 🔫	•	-4
TmvArithmetic-Arithm1_A_TankNo	4805	1 🔫	-	- 5
TmvArithmetic-Arithm1_B_TmvType	4806	0 🔫	-	-6
TmvArithmetic-Arithm1_B_TankNo	4807	3 🔫	-	-7
TmvArithmetic-Arithm2_Operation	4808	0		
TmvArithmetic-Arithm2_MiscConfig	4809	0	-	
<u>B</u> ead <u>Apply</u>	Close	Help		

Procedure

- 1. Choose subtraction.
- 2. Put the result in Tank Measurement Variable TMV_Delta_Level.
- 3. Put the result in Tank 1. Now the result will be stored in TMV_Delta_Level for Tank 1.
- 4. For arithmetic operation parameter A choose Tank Measurement Variable=Level.
- 5. Choose arithmetic operation parameter A from Tank 1.
- 6. For arithmetic operation parameter B choose Tank Measurement Variable=Level.
- 7. Choose arithmetic operation parameter B from Tank 3.

Search for Predefined	Sho	ow Values in — • <u>D</u> ec	
C <u>A</u> ll (Advanced)	0	े <u>Н</u> ех	
tart Register:	Numl	ber of Registers	
[mvArithmetic-Arithm1_Value	▼ 50		
Name	Register	Value	Unit 🔺
fmvArithmetic-Arithm1_Value	4800	13.1624	
fmvArithmetic-Arithm1_Status	4802	0	
fmvArithmetic-Arithm1_Unit	4804	45	
fmvArithmetic-Arithm1_ValueA	4806	14.4682	-
fmvArithmetic-Arithm1_StatusA	4808	0	
fmvArithmetic-Arithm1_ValueB	4810	1.30572	-
fmvArithmetic-Arithm1_StatusB	4812	0	
fmvArithmetic-Arithm2_Value	4814	0	
fmvArithmetic-Arithm2_Status	4816	32768	
fmvArithmetic-Arithm2_Unit	4818	65535	-

Figure C-5: The Result is Displayed in Input Register 4800 and Higher

- A. The result is displayed in Input Register 4800.
- B. Parameter A
- C. Parameter B

Related information

Configure a virtual relay output

C.9 Configure the analog output

To configure the Rosemount 2410 Tank Hub analog output:

Procedure

- 1. In the *TankMaster Winsetup* workspace, right-click the Rosemount 2410 icon.
- 2. Choose the **Properties** option.
- 3. Select the **Configuration** tab.
- 4. Click the Analog Output button to open the Analog Output Configuration window.

Note

This button is available if the Analog Output option is activated for the Rosemount 2410 Tank Hub.

🗂 2410 Tank Hu	ub - HUB-110			X
Communication Configuration Tank Database Device Tags Local Display Advanced Configuration				
	Primary Bus	Virtual Relay No 1	Hybrid Density No 1	
	Secondary Bus	Virtual Relay No 2	Hybrid Density No 2	
	Enraf Emulation	Virtual Relay No 3	Hybrid Density No 3	
	Enraf Master	Virtual Relay No 4		
		Virtual Relay No 5	Delta Level	
		Virtual Relay No 6	Analog Output	
		Virtual Relay No 7		
		Virtual Relay No 8		
		Virtual Relay No 9		
		Virtual Relay No 10		
				1
		ОК	Cancel <u>A</u> pply	Help

5. Select the **Enable** check box to activate the Analog Output option.

Analog Output Configuration	
🔽 Enable	
Source	Analog Output Values
Tank Name / Tank Position :	Status :
TK-1	ОК
Parameter :	Value :
Level	14.473 m
Value Unit :	Current :
m	15.578 mA
Value Range Value at 4 mA : 0.000 m Value at 20 mA : 20.000 m	
Alarm Mode :	
High Alarm Current 💌	
Advanced	72.4 %
OK Cancel	Apply Help

6. In the **Tank Name/Tank Position** list, choose the tank that will provide the desired measurement data source for the Analog Output.
Need help?

If no tank name is configured you can check the tank hub's tank database in case you need to verify that the selected tank position corresponds to the desired tank.

- 7. Choose the tank parameter and value unit to associate with the 4 20 mA Analog Output.
- 8. Under **Value Range**, set the source values that correspond to the analog output values 4 mA and 20 mA, respectively.

You can specify any value as long as the 20 mA value is above the 4 mA value. Alarm mode is activated in case the measurement value goes out of range.

9. In the Alarm Mode list, set the alarm mode as desired.

Alarm mode specifies the analog output state when a measurement error occurs, or when the measurement value is out of range.

Option	Description
High	The output current is set to 21.75 mA (default setting).
Low	The output current is set to 3.75 mA (default setting).
Freeze current	The output current is set to the present value at the time when the error occurs.

10. Optional: Click the **Advanced** button to specify Low/High Alarm Currents and Low/ High Saturation Limits.

Analog Output Configuration Adv	ranced
Low Alarm Current :	3.750 mA
High Alarm Current :	21.750 mA
Low Saturation Limit :	3.900 mA
High Saturation Limit :	20.800 mA
OK Cancel	Apply Help

The output range for the analog output is 3.5 to 23 mA.

C.9.1 View the current status

The Analog Output Status window displays information on the current status.

Procedure

To view the current status information, click the button to the right of the **Status** field. In case an error has occurred the Status field indicates "BAD":

Analog Output Configuration	
🔽 Enable	
Source	Analog Output Values
Tank Name / Tank Position :	Status :
TK-1 💌	BAD
Parameter :	Value :
Level	0.000 m
Value Unit :	Current :
m	21.750 mA
Value Range Value at 4 mA : 0.000 m Value at 20 mA : 20.000 m	
Alarm Mode : High Alarm Current	110.9 %
Advanced	
OK Cance	Apply Help

Example

Analog Output Status	×
Status :	
In alarm mode. Invalid Tank Measurement Variable (TMV).	
	Close

C.10 Configuration of analog input / HART[®] slave device

C.10.1 Rosemount 2410 Tank Hub analog input

To configure a 4-20 mA device connected to the Rosemount 2410 Tank Hub do the following:

Procedure

1. In the *TankMaster WinSetup* workspace, right-click the Rosemount 2410 Tank Hub icon and choose the **Device Live List** option.

2. In the 2410 Tank Hub Device Live List, identify the Analog Input device.

The Analog Input appears as Device Type=Analog Input.

1	Device Type	Device ID	Manufact. ID	Device No	Address	Handled	Connected	Connected via	Configured	Opened	Auto Mode	Tag
ſ	2240 MTT	4875	Rosemount	0	232	Yes	Yes	FF	No	No	No	2240-DEVICE-0000004875
Т	3051C PT	358854	Rosemount	21	1	Yes	Yes	HART	No	Yes	Yes	
Т	5300 GWR	2171724286	Rosemount	0	233	Yes	Yes	FF	No	No	No	2240-DEVICE-0000004875
	5400 RLT	2171786368	Rosemount	0	240	Yes	Yes	FF	No	No	No	2240-DEVICE-0000004875
Т	544 Temp	36200633	Rosemount	0	242	Yes	Yes	FF	No	No	No	2240-DEVICE-0000004875
	5900 RLG	3442	Rosemount	1	247	Yes	Yes	FF	Yes	Yes	Yes	5900-DEVICE-0000003442
	Analog Input	1	Unknown	31	0	Yes	Yes	AIN	Yes	Yes	Yes	
1	No Device											
	No Device											
	No Device											
	No Device											
2	No Device											
3	No Device											
4	No Device											
5	No Device											
;	No Device											

- 3. In the *TankMaster WinSetup* workspace, right-click the Rosemount 2410 Tank Hub icon and choose the **Properties** option.
- 4. Select the Tank Database tab.
- 5. Associate the Analog Input with a tank in the tank hub's tank database and click the **Apply** button.

10	Tank Pusicions.					2410 Tarik Nallies and Addresses:							
	Device Type	Device ID	Connected	Connected via	Tank Position	Tank Position	Tank Name	Level Modbus Address	ATD Modbus Address				
1	2240 MTT	4875	Yes	FF	lot Configure 👻	1	TK-1	1	120				
2	3051C PT	358854	Yes	HART	Not Configured	2							
3	5300 GWR	2171724286	Yes	FF	Not Configured	3							
4	5400 RLT	2171786368	Yes	FF	Not Configured	4							
5	5900 RLG	3442	Yes	FF	1	5							
6	Analog Input	1	Yes	AIN	1	6							
7	No Device		No		Not Configured	7							
8	644 Temp	36200633	Yes	FF	Not Configured	8							
9	No Device		No		Not Configured	9							
0	No Device		No		Not Configured	10							
1	No Device		No		Not Configured								
2	No Device		No		Not Configured	Enter tank r	name with max 10	characters.					
3	No Device		No		Not Configured	(2410 max 5	5 characters and 2230 max 10 characters).						
4	No Device		No		Not Configured	The name v	will also be used as base for the						
5	No Device		No		Not Configured	device tags	ce tags in Tankmaster.						
6	No Device		No		Not Configured								
Sł	now Unit ID 🦳	Show "Device ID	" column as HE>	K		Note that i devices in before clo	t is recommen TankMaster vi sing 2410 confi	ded to install a "Device Tag: guration !	the new s" page				

Need help?

See the Rosemount Tank Gauging System Configuration Manual (Document no. 00809-0300-5100) for more information on how to configure the tank database.

6. Select the **Device Tags** tab and click the **Install New Devices in TankMaster** button. Now the Analog Input will be installed as an ATD in the **TankMaster WinSetup** workspace. Note that although the analog input is actually connected to the Rosemount 2410 Tank Hub, it is handled as an ATD.

- 7. In the *TankMaster WinSetup* workspace, right-click the ATD device icon and choose the **Properties** option.
- 8. Select the Analog Input tab.

Communication Average Temperature C 2240 MTT Auxiliary Sensor 2230 Graphical Field Display Enable Value Unit : bar	Analog Input Values Status : OK
2240 MTT Auxiliary Sensor 2230 Graphical Field Display	Analog Input Advanced Parameter Source Configuration Analog Input Values Status : OK
I Frable Value Unit : ∎bar	Analog Input Values Status : OK
Value Unit : 🗾 🔽	Status : OK
Value Unit : 🛛 🖢 💌	Status : OK
Value Range	Value : 1.446 Bar
Value at 4 mA : 0.000 Bar	Current : 15.569 mA
Value at 20 mA : 2.000 Bar	
Advanced	72.3 %

- 9. Ensure that the **Enable** check box is selected.
- 10. In the Value Unit list, select a suitable unit to match the input source.
- 11. Under **Value Range**, enter the parameter values that correspond to the analog input values 4 and 20 mA.

You can specify any value as long as the 20 mA value is higher than the 4 mA value. If the measured value goes outside the range values, the analog input enters alarm mode.

12. Optional: Click the **Advanced** button in case you would like to configure Filter Factor and Current Limits.

Analog Input Configuration Advanc	ed 📃 💌
Low Current Limit : 3.800	mA
High Current Limit : 20.800	mA
Filter Factor : 0.100	
OK Cancel	Apply Help

By setting a Filter Factor you can suppress spurious fluctuations in the analog input signal. A value between 0 and 1 can be used. The default value is 0.1. A higher value means less filtering.

The Current Limits define the lower and upper limits of the input currents. Outside this range an error will be indicated. The current limits should correspond to the error limits of connected instruments. If for example an instrument sets the output current in alarm mode to 3.8 mA, you should set the lower error limit to 3.8 or higher.

- 13. In the *Analog Input Values* pane, verify that Status is OK and that the expected measurement results appear in the Value and Current fields.
- 14. Select the Advanced Parameter Source Configuration tab.
- 15. Map the Analog Input to the desired tank parameter.

Example

In this example it is mapped to Vapor Pressure.

Communication	Average Temperature Cal	culation	2240 MTT Temperature Sensor
2240 MTT Auxiliary Sensor	2230 Graphical Field Display	Analog Input	Advanced Parameter Source Configuration
Parameter Mapping Vapor Pressure Vapor Pressure Middle Pressure fit	Source Device Type / ID / No Not Configured Not Configured	Source Parame	Ner v
Air Pressure Vapor Temperature Usguid Temperature Tank Temperature Temperature 1 Temperature 3 Temperature 3 Temperature 4 Temperature 5 Temperature 5 Temperature 7	Not Configured Not Configured Not Configured Not Configured Not Configured Show only devices configured for	Level Level Level Level Level tank position: 1	v v v v
Temperature 8 Temperature 9 Temperature 10 Temperature 11 Temperature 12 Temperature 13 User Def 2 desc:	· Jiniwan derices.	Manual Value Co	onfiguration
Jser Def 5 desc:			

16. In the **Source Device Type / ID / No** list, select **Analog Input** to make sure that the 4 - 20 mA signal of the connected instrument is mapped to the selected parameter.

Communic	ation		Average Temperature (Calculation		2240 MTT Temperature Sensor
2240 MTT Auxilia	ry Sensor	2	230 Graphical Field Display	An	alog Input	Advanced Parameter Source Configuration
arameter Mapping		Unit	Source Device Type / ID / 1	٩o	Source Param	eter
Vapor Pressure	- bar	G 🚽	Not Configured	-	Level	-
Level	▼ ft	Ţ	Analog Input / 1 / (No 31) 3051 PT / 268441203 / (No 1) 5900 RLG / 133 / (No 2) 2230 GED / 119 / (No 3)		Level	_
Level		Ŧ	2240 MTT / 133 / (No 4)		Level	<u></u>
Level	▼ ft	v	Not Configured	-	Level	v
Level	▼ ft	-	Not Configured	Ţ	Level	v
Level	- ft	-	Not Configured	-	Level	T
			 Show only devices configure Show all devices. 	d for tank po:	sition: 1	
Description of User Def (parameter				Manual Value (Configuration
Jser Def 1 desc:						
Jser Def 2 desc:						
Jser Def 3 desc:						
Iser Def 4 desc:						
Iser Def 5 desc:						

17. In the Source Parameter list, select AIN 1.

2240 MTT Auxiliary Sensor 2230 Graphical Field Display Analog Input Advanced Parameter Source Configuration arameter Mapping Unit Source Device Type / ID / No Source Parameter Vapor Pressure barG Analog Input / 1 / (No 31) AIN 1 Level It Not Configured Hait TV Level It Not Configured AIN 1 Level It Not Configured AIN 1 Level It Not Configured AIN 3 Level It Not Configured AMage 1 Level It Not Configured Manual Value 1 Level It Not Configured Manual Value 2 Manual Value 1 Manual Value 5 E Pressure 2 Show only devices configured for tank point Manual Value 5 E Color Devices Show all devices E Manual Value 10 Manual Value 10 Manual Value 11 Manual Value 11 Manual Value 12 Manual Value 12	Communic	ation			Average Temperature Ca	alculation		2240 MTT Temperature Sensor
Parameter Mapping Unit Source Device Type / ID / No Source Parameter ✓ Vapor Pressure barG Analog input / 1 / (No 31) AIN 1 ▼ Level R Not Configured AIN 1 ▼ Level R Not Configured AIN 3 Level R Not Configured AIN 3 Level R Not Configured AIN 3 Level R Not Configured AIN 4 Level R Not Configured AIN 2 Level R Not Configured AIN 4 Manual Value 1 Manual Value 2 Manual Value 3 Manual Value 4 Costopion of User Def parameter Show only devices configured for tark pois Manual Value 6 Manual Value 6 Iser Def 1 desc:	2240 MTT Auxiliar	y Sensor		2230	Graphical Field Display	Ana	log Input	Advanced Parameter Source Configuration
Level R Not Configured Not Value 1 Norual Value 1	Parameter Mapping ✓ Vapor Pressure	•	Unit barG	Ŧ	Source Device Type / ID / No Analog Input / 1 / (No 31)	•	Source Parameter	.
Level n n Ah 3 Level n n Pressure 2 Level n n Not Configured Pressure 2 Level n n Not Configured Manual Value 1 Coscription of User Def parameter Show only devices configured for tark point Manual Value 6 Manual Value 6 User Def 1 desc: Show all devices. Manual Value 7 Manual Value 7 User Def 2 desc: Show all devices. Manual Value 7 Manual Value 7 User Def 4 desc: Show all devices. Manual Value 7 Manual Value 7	Level		ft ft	Ψ Ψ	Not Configured		Hart SV Hart TV Hart QV AIN 1 AIN 2	
Level It Not Configured Not Configured Manual Value 1 Manual Value 2 Manual Value 3 Manual Value 3 Manual Value 4 Show only devices configured for tank posit Manual Value 7 Manual Value 6 Manual Value 7 Manual Value 7 Manual Value 7 Manual Value 8 Manual Value 7 Manual Value 9 Manual Value 7 Manual Value 10 Manual Value 10 Manual Value 12 Manual Value 12	Level		ft ft		Not Configured		AIN 3 Pressure 1 Pressure 2 Pressure 3	
Description of User Def parameter Jeer Def 3 desc: Jeer Def 4 desc: Jeer D	Level	-	ft	-	Not Configured		Manual Value 1 Manual Value 2 Manual Value 3 Manual Value 4	
User Def 1 desc:	Description of User Def p	arameter			 Show all devices. 	for tank pos	Manual Value 6 Manual Value 7 Manual Value 8 Manual Value 9 Manual Value 10	
User Def 2 desc: User Def 3 desc: User Def 4 desc:	Jser Def 1 desc:						Manual Value 11 Manual Value 12	-
Jser Def 3 desc:	Jser Def 2 desc:							
	Jser Def 3 desc:		_					
User Def 5 desc:	Jser Def 5 desc:		-					

- 18. In *TankMaster WinSetup*, install and configure the tank that the analog input is associated with in the Rosemount 2410 tank database (see Step 5).
- 19. Verify that the tank parameter receives measurement data from the analog input by, for example, opening the *Tank View* window in TankMaster WinOpi.

C.10.2 HART slave configuration

The Rosemount 2410 Tank Hub can act as HART Master for up to three HART slaves in multi-drop configuration. Current mode 4-20 mA is supported in case only one HART device is connected.

Procedure

- 1. Identify the HART Slave in the Rosemount 2410 Tank Hub **Device Live List**. It will appear as "HART" in the column named "Connected via".
- 2. Open the Rosemount 2410 tank database and locate the device which will act as a HART Slave.
- 3. Associate the HART slave with a tank position in the Rosemount 2410 tank database and click the **Apply** button.

	Device Type	Device ID	Connected	Connected via	Tank Position	Tank Position	Tank Name	Level Modbus Address	ATD Modbus Address			
-	2240 MTT	4875	Yes	FF	lot Configure 👻	1	TK-1	1	120			
2	3051C PT	358854	Yes	HABT	1	2						
}	5300 GWR	2171724286	Yes	FF	Not Configured	3						
	5400 RLT	2171786368	Yes	FF	Not Configured	4						
i	5900 RLG	3442	Yes	FF	1	5						
	Analog Input	1	Yes	AIN	Not Configured	6						
	No Device		No		Not Configured	7						
	644 Temp	36200633	Yes	FF	Not Configured	8						
	No Device		No		Not Configured	9						
)	No Device		No		Not Configured	10						
	No Device		No		Not Configured							
2	No Device		No		Not Configured	Enter tank r	ame with max 10	characters.				
3	No Device		No		Not Configured	(2410 max 5	ne will be used in field displays ax 5 characters and 2230 max 10 characters). ne will also be used as base for the ags in TankMaster.					
ŀ	No Device		No		Not Configured	The name v						
ī	No Device		No		Not Configured	device tags						
5	No Device		No		Not Configured							
Sł	now Unit ID 🕅	Show "Device ID	'' column as HE>	<		Note that i devices in before clo	t is recommen TankMaster via sing 2410 confi	ded to install a "Device Tag guration !	the new s" page			

- 4. Select the **Device Tags** tab and click the **Install New Devices in TankMaster** button. Now the HART Slave device will be installed as an Auxiliary Tank Device (ATD) in the TankMaster WinSetup workspace. Note that although the HART device is actually connected to the Rosemount 2410, it is handled as an ATD in TankMaster.
- 5. In the *TankMaster WinSetup* workspace, right-click the ATD device icon and choose **Properties**.
- 6. Select the Advanced Parameter Source Configuration tab.
- 7. Select the desired check box to enable mapping of tank measurement variable to source device and parameter.
- 8. Choose the desired tank parameter and value unit.

Example

۰.	/		•	1 1 1		I
<u>۱</u>	anor	νισσει		IPCTPU	in thi	s evamnie
v	apor	i i Coourc	13 30	ICCLCU	III UIII	champic.

Communic 2240 MTT Auxiliar	ation y Sensor	2230	Average Temperature Cale Graphical Field Display	culation An	alog Input	2240 MTT Temperature Sensor Advanced Parameter Source Configuration
Parameter Mapping	Unit	Ţ	Source Device Type / ID / No 3051 PT / 268441203 / (No 1)	•	Source Parameter Hart PV	
Level		T	Not Configured	v	Level	_
Level		Ŧ	Not Configured	Ţ	Level	T
Level		Ŧ	Not Configured	Ţ	Level	v
Level		Ŧ	Not Configured	Ţ	Level	Ŧ
Level	₩ ft	Ŧ	Not Configured	Ŧ	Level	—
			 Show only devices configured fo Show all devices. 	r tank po	sition: 1	
Description of User Def p	arameter				Manual Value Config	uration
User Def 1 desc:						
User Def 2 desc:						
User Def 3 desc:						
User Def 4 desc:						
User Def 5 desc:						

9. In **Source Device Type / ID / No** list, select the appropriate HART device.

Example

In the example above, a 3051 PT is selected.

- 10. Choose the appropriate source parameter; Hart PV, Hart SV, Hart TV, or Hart QV.
- 11. In case there are more HART slaves connected, repeat Step 4 to Step 7.
- 12. In *TankMaster WinSetup*, install and configure the tank that the HART Slave device was associated with in the Rosemount 2410 tank database (see step Step 3).
- 13. Verify that the tank parameter receives measurement data from the HART Slave by, for example, opening the *Tank View* window in TankMaster WinOpi.

C.10.3 HART slave mapping

In case a Rosemount 2240 Multi-Input Temperature Transmitter is used, some parameters can not be mapped manually to a HART Slave as described in section HART slave configuration. See Table C-6 for a list of parameters that can be mapped.

Parameters	Mapping
Free Water Level	Х
Vapor Pressure	Х
Liquid Pressure	Х
Vapor temperature	χ ⁽¹⁾
Liquid temperature	X ⁽¹⁾
Temperature 1	X ⁽¹⁾
Temperature 2	X ⁽¹⁾
Temperature 3	X ⁽¹⁾
Temperature 4	X ⁽¹⁾
Temperature 5	χ ⁽¹⁾
Temperature 6	χ ⁽¹⁾
Temperature 7	X ⁽¹⁾
Temperature 8	X ⁽¹⁾
Temperature 9	X ⁽¹⁾
Temperature 10	X ⁽¹⁾
Temperature 11	X ⁽¹⁾
Temperature 12	χ ⁽¹⁾
Temperature 13	χ ⁽¹⁾
Temperature 14	X ⁽¹⁾
Delta level	χ(2)
User defined 1	х

Table C-6: Possible Parameter Mapping with Rosemount 2410 Tank Hub via FCU 2160

(1) In case no 2240 Temperature Transmitter is mapped

(2) Not available at the same time as User Defined 1

FCU 2160

In case a FCU 2160 is included in the Rosemount Tank Gauging system, make sure that the Slave Database is configured accordingly.

A Rosemount 2410 Tank Hub that includes an analog input and/or a HART slave should be configured as follows:

- Ain=2
- Hin=3

	Slave Type	Addr	Bus	Temp	Ain / Cin	HIn	Relays	int1 (s)	Int2 (s)	Level Offset	_	
1A	2410 Level 👻	1	FB1	-	2	3	2	1,0	10,0			
2A	2410 Level	2	FB1		0	0	0	1,0	10,0		_	
3A	2410 Level	3	FB1		0	0	0	1,0	10,0			
4A	2410 Level	4	FB2		2	3	2	1,0	10,0			
5A	TRL/2 RTG	0	FB3	-	2			1,0	-			
6A	REXRTG	11	FB3	0	0	0	0	1,0	10,0			
7A	TRL/2 RTG	0	FB1		2			1,0				
8A	TRL/2 RTG	0	FB1	-	0			1,0		-		
9A	TRL/2 RTG	0	FB2	-	0			1,0		-		
10A	TRL/2 RTG	0	FB2	-	0			1,0		-		
11A	TRL/2 RTG	0	FB2		0		-	1,0		-		
124	TBL/2 BTG	Π	FB2		Π			10			_	
•										<u> </u>		

Figure C-6: Configuration of FCU 2160 Slave Database

Global Headquarters and Europe Regional Office Tank Gauging

Emerson Automation Solutions Box 150 (Visiting address: Layoutvägen 1) SE-435 23 Mölnlycke Sweden +46 31 337 00 00 +46 31 25 30 22

Sales.RTG@Emerson.com

Latin America Regional Office

Emerson Automation Solutions 1300 Concord Terrace, Suite 400 Sunrise, FL 33323, USA + 1 954 846 5030 + 1 954 846 5121 RMTLAContactUS@Emerson.com

Middle East and Africa Regional Office

Emerson Automation Solutions Emerson FZE P.O. Box 17033 Jebel Ali Free Zone - South 2 Dubai, United Arab Emirates III +971 4 8118100 C +971 4 8865465 C RTGMEA.Sales@Emerson.com

North America Regional Office Tank Gauging

Asia Pacific Regional Office

Emerson Automation Solutions 1 Pandan Crescent Singapore 128461 1 +65 6777 8211 2 +65 6777 0947 Specialist-OneLevel.RMT-AP@Emerson.com

in Linkedin.com/company/Emerson-Automation-Solutions

Twitter.com/Rosemount_News

Facebook.com/Rosemount

🔛 Youtube.com/user/RosemountMeasurement

©2019 Emerson. All rights reserved.

Emerson Terms and Conditions of Sale are available upon request. The Emerson logo is a trademark and service mark of Emerson Electric Co. Rosemount is a mark of one of the Emerson family of companies. All other marks are the property of their respective owners.



Rosemount