

**Honeywell** | THE FUTURE IS WHAT WE MAKE IT

# MAXPRO<sup>®</sup> NVR 6.7

Installation and Configuration Guide



---

## Installation & Configuration Guide

---

# Revisions

<b>Issue</b>	<b>Date</b>	<b>Description</b>
1.0 Rev D	Mar, 2014	Updated document for 3.1 Build 65 Rev C
1.0 Rev E	Aug, 2014	Updated document for 3.1 SP1
2.0 Rev A	Aug, 2015	Updated document for 3.5
3.0 Rev A	August, 2016	Updated document for 4.0 Release
800-16419V4-A	Feb, 2017	Updated document for 4.1 Release
800-16419V5-A	August 2017	Updated document for 4.5 Release
800-16419V5-B	November 2017	Updated document for 4.7 Release
800-16419V5-C	February, 2018	Updated document for 4.9 Release
800-16419V5-D	June, 2018	Updated document for 5.0 Release
800-16419V5-E	September, 2018	Updated document for 5.0 T Patch Release
800-16419V5-F	October, 2018	Updated document for 5.0 SP1 Release
800-16419V5-G	February, 2019	Updated document for 5.5 Release
800-16419V5-J	May, 2019	Updated document for 5.6 Release
800-26013-A	November 2019	Updated document for 6.0 Release
800-26013-B	August 2020	Updated document for 6.3 Release
800-26013-C	February 2021	Updated document for 6.7 Release

# TABLE OF CONTENTS

Cautions and Warnings .....	29
FCC Compliance Statement .....	29
Personal Data Storage .....	30
Important Safeguards .....	30
Warranty and Service.....	33
List of Symbols.....	33
<b>Chapter 1 - About This Guide.....</b>	<b>37</b>
Overview.....	37
Intended Audience.....	37
Scope.....	37
Overview Of Contents.....	38
Related Documents.....	39
Typographical Conventions .....	39
<b>Chapter 2 - Introduction to MAXPRO® NVR .....</b>	<b>41</b>
Overview.....	41
MAXPRO NVR Turnkey Boxed Solutions .....	41
MAXPRO NVR Software Only Solution.....	41
MAXPRO NVR Family .....	43
MAXPRO NVR Features .....	44
Mask Compliance Detection .....	44
Social Distancing Violation Detection.....	44

Alarms for both Mask Detection and Social Distancing .....	44
Operating Conditions.....	44
Non-Compliant Social Distancing Regions.....	44
Analytic Alarms in NVR .....	45
Scalable Analytics Server .....	45
Bulk configurations of cameras from NVR .....	46
Bi-Directional Audio Support for MAXPRO NVR .....	46
Series 60 Camera Integration .....	46
Support for Ex-Proof Camera models .....	47
Enhancements in FishEye camera Dewarping Support .....	47
Mask Compliance Detection .....	48
Social Distancing Violation Detection.....	48
Alarms for both Mask Detection and Social Distancing .....	48
Operating Conditions.....	48
Recommended Operating Conditions For Mask Detection .....	48
Recommended Operating Conditions For Distancing Violation detection	49
Support for Remote Analytics Server.....	53
Series 60 Camera Integration .....	53
Supported Events/Alarms.....	54
Supported key Features .....	55
Thermal Camera Integration - HRCF-FD384H/HRCF-FD640H .....	55
SSA - Software Service Agreement for MAXPRO .....	55
NDAA Series 30 camera Integration in MAXPRO NVR & VMS.....	56
Supported Events .....	56
Supported key Features .....	56
MPEG2 Encoder Support with MAXPRO NVR and VMS.....	57
Additional Cameras Support.....	57
Additional Resolution Support.....	57
Video Guard service for SIRA compliance.....	57
New Features in NVR 5.6.....	57
Support for Equip series V2 Cameras .....	57
Support for HRHQ104 DVR.....	59
Support for smooth Rendering at VMS.....	59
New Features in NVR 5.5.....	59

Analytics Annotations Support.....	59
Enhancements in Video connection .....	59
New features in NVR 5.0 .....	59
Patches Merged in SP1 .....	59
5.0 T Patch .....	59
Windows Expiry Patch.....	60
Archival Improvements .....	60

Include Archived Clips .....	60
Primary and Archived Location.....	60
Camera Name & Clip status .....	60
Archival Schedule Check box.....	60
Archival Clip and Deletion Retry .....	61
Validation Message For Network Credentials .....	61
Disabled Password Never Expires.....	61
Playing archived clips through Client machine .....	61
Improved GPU rendering.....	62
GPU Rendering Combinations .....	62
60FPS support for EQUIP-S 1080P cameras .....	62
NAS Recording support.....	63
Video Anonymization .....	63
Installation .....	63
Support for 128 Channel.....	64
Privacy Protection Settings (GDPR).....	64
Password Complexity and Expiry Enhancements.....	65
UI Improvements .....	66
Improvements in Status Monitor .....	66
System and Performance Improvements .....	66
Integrity Service Settings .....	67
New Equip 1080p and 4MP Camera Integration.....	67
RTSP H.265 Support .....	68
Enhancements in MAXPRO Mobile APP.....	68
Grand Eye New Evolution support.....	68
Industry Standards .....	68
Flexible Licensing.....	69
Role Based Operator Privileges.....	69
Easy Configuration .....	69
64 channel Support.....	69
Auto Discovery .....	69
MultiStream .....	69
Third Party ONVIF Profile G supported cameras:.....	70
MAXPRO Web Configurator .....	70

New Deletion Schedule.....	70
GPU Rendering Support.....	70
Analog Capture Card Support.....	70
User-Friendly and Feature-Rich User Interface .....	70
MAXPRO Status Monitor .....	71
Recording and Playback Operations.....	71
On Demand live Streaming (VOD).....	71
Profile-G or Edge Sync Support .....	72
Low bandwidth Stream Settings:.....	72
Optimize Stream Usage Settings:.....	72
Enriched Video Viewing Experience .....	73
Efficient Event and Alarm Viewing Capability .....	73
Simultaneous Video Recording and Video Viewing .....	73
Video Motion Detection (VMD) Support .....	73
Search.....	73
SMART Motion Search .....	73
360 Immersive Experience (Dewarping) Support.....	73
New EquiP Series Camera Models Support .....	74
New high performance and specialty EquiP Camera Support.....	74
3D Positioning.....	74
New EquiP Camera Model Dewarping .....	74
H.265 Codec Support.....	74
Meta Data Conversion Utility .....	75
Multi-language Support .....	75
Keyboard Support .....	75
Clip Export .....	75
MAXPRO NVR Clip Player .....	75
Email Notification.....	75
Video Surround Feature .....	75
Profile Cameras .....	75
Reports .....	76
Integration Capability .....	76
Audio .....	76
Web Client.....	76
Archival.....	76

Mobile Apps .....	76
Advanced Security.....	77
MAXPRO NVR Typical System Architecture.....	77
MAXPRO NVR Standalone System Diagram.....	77
MAXPRO NVR Hybrid Standalone System Diagram.....	78
MAXPRO NVR Distributed System Architecture.....	79

### **Chapter 3 - Commissioning MAXPRO NVR..... 81**

Overview of Commissioning Procedure.....	81
Steps in the Commissioning Procedure .....	81
Setting up the MAXPRO NVR .....	81
Installing the Software in the Server and Client Computers .....	82
Configuring the MAXPRO NVR.....	82
Verifying the Configuration.....	82

### **Chapter 4 - Setting up the MAXPRO NVR ..... 83**

Overview .....	83
Setting up the MAXPRO NVR Turnkey Box Solutions .....	83
Typical MAXPRO NVR System Diagram.....	84
Typical MAXPRO NVR Hybrid System Diagram.....	85
Connecting the Monitors .....	85
Powering on the MAXPRO NVR Unit .....	85
To power on the MAXPRO NVR unit .....	86
To turn off the power for MAXPRO NVR.....	86
Changing the MAXPRO NVR IP Address and Machine Name .....	86
Changing the IP address .....	87
Changing the computer name .....	88
Configuring the Monitor Display Properties.....	88
Configuring Display Settings for the Context Menu .....	88
Configuring Display Setting from the Control Panel .....	88
Setting up the MAXPRO NVR Software-Only Solution.....	89
Before you Begin .....	89
Hardware Specifications .....	89
MAXPRO NVR Software System Architecture.....	89



MAXPRO NVR Software Solution Standalone System.....	89
MAXPRO NVR Software Solution Distributed System .....	90
MAXPRO NVR Hybrid Connections .....	90
Rear Panel Connectors.....	90
Hybrid XE Connections.....	91
Hybrid SE Connections.....	93
Hybrid PE Connections .....	94
Connecting a Video Source .....	95
Looping Output Termination .....	96
Connecting Control Outputs.....	97
Connecting Sensors .....	97
Connecting an Analog PTZ Camera .....	98
Attaching the 4-Pin Adapter.....	98
Connecting the Joystick Controller .....	99
Connecting a Joystick Controller to MAXPRO NVR .....	99
How to log on to the UltraKey Plus keyboard? .....	99
How to log off from the UltraKey Plus keyboard?.....	99
NetBIOS Naming Convention Limitations .....	100

## **Chapter 5 - Installing the NVR Software..... 101**

Overview .....	101
Before you Begin.....	101
MAXPRO NVR Software - Operating System Prerequisites .....	101
Before you Begin - Windows Updates .....	102
Before you Begin - Disable Defragmentation .....	103
Before you Begin - Disable Volume Shadow Copy, Windows Backup Services	103
Before you Begin - Changing the default Windows Administrator Account	
Created By NVR.....	103
Before you Begin - Installed SQL Service Pack on older SQL Server versions	
103	
MAXPRO NVR Software Installation .....	104
How to Install MAXPRO NVR .....	104

Full Installation.....	107
Installing Web Client .....	112
Prerequisites to access MAXPRO NVR Server through Web Client.....	112
Client Installation.....	114
Uninstalling MAXPRO NVR.....	117
Client Uninstall .....	117
Full Uninstall.....	117
NetBIOS Naming Convention Limitations.....	119

## **Chapter 6 - Logging on and Getting Started .....121**

Logging on Using Profiles.....	121
Logging on to MAXPRO NVR .....	122
Tips for Logging on.....	123
Changing the Default Password.....	123
Configuring MAXPRO NVR Windows/ Desktop Client.....	124
Managing Profiles.....	124
Saving a Server Address in a Profile.....	124
Setting the Default Profile.....	126
Modifying a Profile .....	126
Deleting a Profile .....	127
Editing the Ports .....	127
Port Forwarding.....	128
Getting to Know the MAXPRO NVR User Interface .....	130
Viewer Tab .....	131
Configurator Tab.....	132
Search Tab.....	133
Report Tab.....	134
Setting Preferences .....	134
Settings for Video Rendering.....	135
Rendering Settings for a GPU system.....	136
Pausing the Video Rendering.....	137
Settings for Alarm Preview Pane .....	138
Setting the Alarm Threshold Value .....	140
Configuring the Snapshot Clip Export Settings .....	141

Configuring the OSD Settings.....	141
Configuring the Timeline Settings .....	142
Configuring the Diagnostic Settings .....	143
Configuring the Advanced Settings .....	144
To configure the Advanced settings .....	145
Encryption Certificate deployment scenario .....	146
Configuring the Default Settings .....	147
Licensing Information.....	147
Viewing the Version and License Information of MAXPRO NVR.....	147
Registration and Licensing .....	150
SSA - Software Service Agreement for MAXPRO .....	150
Analytics License .....	151
Logging off.....	152
Closing the MAXPRO®NVR User Interface .....	152

## **Chapter 7 - Configuring MAXPRO NVR..... 153**

Overview .....	154
Before you Begin.....	155
Firewall Settings .....	155
Configuring the Honeywell cameras with MAXPRO NVR Wizard.....	155
MAXPRO NVR Wizard Settings on the Task bar.....	160
Navigating to Configurator tab.....	161
Configuring the System Settings.....	161
Configuring General Settings.....	162
Event Recording Settings.....	163
Email Settings.....	163
Site Info Settings .....	164
Archival Schedule Settings.....	164
Edge Sync Settings .....	165
Manual Archival .....	165
Holidays/Exceptions Settings.....	167
Configuring the Disk Management Settings .....	167
Configuring the Cameras .....	171
Adding IP Cameras / Encoders.....	172

Configuring the Camera Properties .....	176
Configuring the Auto Discovery Settings.....	180
Adding Additional Streams for a Camera .....	182
Deleting Additional Streams .....	183
Discovering and Adding Third Party ONVIF and AXIS Cameras.....	184
Discovering and Adding Multi-channel Encoders .....	185
Adding FLIR Camera .....	187
Adding RTSP Cameras/Encoders .....	188
Configuring the Input and Output for an IP Camera .....	189
Configuring 360/180 Cameras .....	192
Configuring the Panomorph Settings for the Cameras with Immervision Support.....	192
Configuring Oncam Grandeye Cameras .....	193
Adding Axis 360/180 Camera .....	195
Adding Arecont 360/180 Camera.....	197
Configuring the New EquiP Model Camera for Dewarping.....	200
Managing Analog Cameras .....	202
Adding/Deleting Analog Cameras.....	202
Configuring Analog Cameras .....	203
Configuring the Input and Output for an Analog Camera .....	209
Spot Monitoring .....	214
Server VMD (SMART VMD) .....	214
Updating the Cameras .....	218
Deleting the Cameras.....	218
Configuring the Schedules .....	218
Creating a Schedule.....	218
Deleting a Schedule .....	220
Configuring the Sequences.....	220
Creating a Sequence.....	220
Rearranging the Cameras In the Sequence.....	221
Removing Presets from a Sequence .....	221
Updating a Sequence .....	222
Deleting a Sequence .....	222
Performing User Administration .....	222

Adding a User .....	224
Updating a User .....	226
Deleting a User .....	227
Recommended stream Settings.....	227
Recommendation to use Low bandwidth stream option .....	227
Automatic Retry for Backfilled Clips.....	228
Perform the steps in the order as mentioned below:.....	228
Upgrade MAXPRO NVR.....	228
Configure the Automatic Retry parameter values .....	229
Enable Recording During On Demand Streaming .....	230
Privacy Protection Settings (GDPR Favored).....	232
Anonymization.....	232
Four Eye Authentication .....	232
Clip Export Option .....	233
Licensing .....	233
How to enable Anonymization.....	233
How to view Anonymized video .....	235
How to enable Four Eye Authentication .....	237
How Four Eye Authentication feature Works .....	237
Video Anonymization .....	239
How to Anonymize objects based on Environment.....	240
Improved GPU Rendering .....	242
Settings for Rendering Video through GPU .....	242
GPU Rendering Combinations .....	244
How to identify if a camera is Rendering in GPU Mode.....	244
Guidelines to configure NAS Drive for Recording.....	245
Step 1: Create Directory in NAS.....	245
Step 2: Map the User details with NVR User .....	245
Step 3: Configure the NAS Drive in NVR .....	246
QNAP NAS for Recording .....	246
Limitations in Configuring NAS for recording .....	247
Playing archived clips through Client machine .....	248
Different Scenarios to playback Archived Clip.....	249
How to configure the Archival and Deletion retry settings.....	251

Annotations.....	252
Introduction .....	252
How to get/configure Annotation Feature.....	253
Upgrade the Camera Firmware.....	253
Install the VA packages .....	254
Remove Old VA Package .....	254
Upgrade to Latest VA Packages.....	255
Obtain the License and install.....	255
Configuring Intrusion trace.....	257
Configuring Loitering trace.....	261
Loitering Trace with PTZ Camera .....	265
Configure and Enable Annotation in NVR.....	266
How to enable Annotation in NVR.....	266
Snapshots with Annotations.....	272
Setting the Audio Codec in Camera Web Page .....	273
Video Guard service for SIRA compliance.....	274
NDAAC HC Series 30 Camera Support.....	275
Supported Events .....	276
Series 30 Cameras Features.....	276
MPEG2 Encoder Support.....	282
Multicast Streaming IP for Encoder.....	283
How to configure Multicast IP for ENC Encoder.....	283
Configuring Remote Analytics Server.....	285
Scalable Analytics Server.....	285
Converting a NVR Machine to a Analytics Remote Server .....	285
How to Add Analytics Server in NVR Machine .....	288
Manging Cameras for Analytics Server .....	289
Editing Remote Analytics Server Details.....	290
Bulk configurations of cameras from NVR .....	291

How to configure General Settings for cameras in bulk.....	291
How to configure Schedule Settings for cameras in Bulk .....	293
How to configure Preferences for cameras in Bulk.....	294
How to configure Stream Settings for cameras in Bulk .....	296
How to configure SVM D for cameras in bulk.....	299
Bi-Directional Audio Support for MAXPRO NVR.....	300
How to configure Bi-Directional Audio for a camera.....	301
Limitation .....	302
Series 60 Camera Integration.....	302
Configuring Social Distancing ROI Duration and Show .....	303

## **Chapter 7 - Verifying the Configuration ..... 305**

Overview .....	305
Before you Begin.....	305
Activities to Perform in this Phase.....	305
Checking the Connection with the MAXPRO NVR Server.....	306
Checking the Device listing in the Devices Window.....	306
Checking the Acknowledgment and Clearing of Alarms.....	306
Checking the Live Video from Cameras .....	307
Checking the Playback of Recorded Video .....	307
Checking the Panning, Tilting, and Zooming .....	308
Checking the Creation of Images .....	308
Checking the Creation of Clips .....	308
Checking the Salvo View Feature.....	309
Checking the Search for Recorded Video in MAXPRO NVR.....	309
Checking the Generation of Event History/ Operator Log Report.....	309

## **Chapter 8 - Upgrade MAXPRO NVR Software..... 311**

Overview .....	311
----------------	-----

Upgrade to MAXPRO NVR 6.7 Build 687 .....	311
Upgrade to MAXPRO NVR 6.3 Build 643 .....	316
Upgrade to MAXPRO NVR 6.0 Build 622 .....	316
Before Upgrading .....	316
Pre-requisite .....	316
Upgrade to MAXPRO NVR 5.6 (Build 572) .....	321
Upgrade to MAXPRO NVR 5.5 (Build 558) .....	322
Upgrade to MAXPRO NVR 5.0 SP1(Build 532).....	324
Uninstalling SP1 .....	325
Upgrade to MAXPRO NVR 5.0 Build 522(T Patch).....	326
Upgrade to MAXPRO NVR 5.0 Build 509 Rev D.....	327
Before Upgrading .....	327
Upgrade to MAXPRO NVR 4.9 Build 204 .....	331
Upgrade to MAXPRO NVR 4.7 Build 188 .....	332
Upgrade to MAXPRO NVR 4.1 Build 123 Rev B.....	332
Upgrade to MAXPRO NVR 4.5 Build 162 .....	334
Upgrade to MAXPRO NVR 4.1 Build 123 Rev B.....	336
Upgrade to MAXPRO NVR 4.0.....	337
Taking the Database Backup .....	338
How to upgrade to MAXPRO NVR 4.0.....	338

## **Chapter 9 - MAXPRO NVR Web Client .....343**

Introducing Web Client.....	343
Limitation with Privacy Protection Settings .....	344
Installing Web Client.....	344
Prerequisites to access MAXPRO NVR Server through Web Client.....	344
Setting the MAXPRO Web Configurator .....	345
To set the Web Configurator.....	346
Creating Self Signed Certificate.....	351
Binding the generated certificate with https .....	354
Installing the Certificate.....	355
Procuring and Installing CA Certificate.....	357
Installing an SSL Certificate in Windows Server 2008 (IIS 7.0).....	357



Create the Certificate Signing Request.....	357
Installing the Certificate.....	361
Bind the Certificate to a website .....	364
Install any Intermediate Certificates.....	365
Changing Default Port 443 for the MAXPRO Web Client and MAXPRO Mobile app	366
Step 1: Changing the Default Port 443 on the MAXPRO NVR.....	367
Step 2: Changing the Port in the MAXPRO Web Client and MAXPRO Mobile app	368
Viewing the Certificate Information .....	368

## **Chapter 10 - MAXPRO NVR Mobile App ..... 371**

Introduction.....	371
Enhancements in NVR 5.0 Release .....	371
MAXPRO NVR Mobile app Installation .....	372
Minimum Requirements .....	372
Installing the MAXPRO NVR Mobile app .....	374
Typical Network Configuration and Settings .....	375
Creating Users for the MAXPRO NVR Mobile app.....	377
Limitation with Privacy Protection Settings.....	378
Adding the MAXPRO NVR to the MAXPRO NVR Mobile app .....	379
Logon using Touch ID (Fingerprint Authenticated).....	383
Enable HIS Streaming.....	388
Adding Multiple NVR Recorders .....	388
Editing NVR Recorder Details.....	390
Deleting the Saved NVR Recorders .....	392
Changing Default Port 443 .....	392
Limitation with Privacy Protection Settings in MAXPRO Mobile App.....	392

## **Chapter A - Appendix A ..... 395**

Customizing IP Address and Machine Name and Scheduling Metadata and Database Backup .....	395
Changing the Default IP address and Machine Name.....	395
Scheduled Metadata and Database Backup.....	395
Scheduled Task for Backing up the Metadata and Database.....	396

Meta Data Conversion Utility .....	400
Offline Mode .....	401
How to access the Meta Data Conversion Utility .....	401
Updating the Unique system ID for all Cameras .....	402
Updating the Unique system ID for Specific Cameras .....	403
How to update the Unique ID in Offline Mode .....	404
How to Enable Video on demand feature in MAXPRO NVR .....	406
How to Enable the Camera Stream .....	407

## **Chapter B - Appendix B .....409**

Image Stream Combinations for Onecam Grandeye Cameras .....	409
For Onecam Grandeye Evolution Cameras.....	409
Device Characteristics of Onecam Grandeye Cameras .....	409
VMD Settings and Motion-based Recording Configuration .....	410
Overview of MAXPRO NVR Recording Options .....	410
Configuring the Pre and Post Event Recording Settings .....	412
Configuring Camera Settings for VMD-Based Recording .....	413
Server VMD (SMART VMD) .....	414
Configuring Built-in VMD .....	414
Disabling Motion Detection .....	414
Fine Tuning the Video Motion Detection.....	414
Increasing VMD Sensitivity.....	415
Decreasing VMD Sensitivity .....	415
VMD Configuration Examples .....	416
Event and Alarm Types .....	417
Camera Level Events and Alarm types .....	417
Video Analytics Events.....	418
Recorder Level Events and Alarm types .....	418
SMART VMD Level Events and Alarm types .....	419
Configuring Loitering & Intrusion Trace Alarms .....	419
How to upgrade the Firmware of a camera .....	419
How to configure Loitering Trace Alarm.....	420
MAXPRO®NVRs - AXIS Camera/Encoders Discovery and Configuration (using ONVIF).....	425

Step 1: Enable ONVIF Web Service on AXIS Camera/Encoder .....	425
Scenario Description .....	425
Step 2: Discover and Configure the AXIS Camera/Encoder in MAXPRO® NVR428	

## **Chapter C - Patches Released on Top of NVR 4.0..... 431**

Overview .....	431
AXIS Patch .....	431
Issues Fixed .....	431
Skylake Patch .....	431
Release Highlights: .....	432
Issues Fixed .....	432
How to increase the Limit for Rendering Camera .....	433
How to Disable the GPU Rendering .....	433

This page is intentionally left blank

# LIST OF FIGURES

- Figure 1-1: MAXPRO NVR SE System Diagram 54**
- Figure 1-2: MAXPRO NVR HYBRID XE Standalone System Architecture 55**
- Figure 1-3: MAXPRO NVR Distributed System Architecture 56**
- Figure 3-1: Typical MAXPRO NVR Hybrid System Diagram 63**
- Figure 3-2: Network and Sharing Center 64**
- Figure 3-3: LAN Properties 65**
- Figure 3-4: MAXPRO NVR Software Solution Standalone System 67**
- Figure 3-5: MAXPRO NVR Software Solution Distributed System 67**
- Figure 3-6: Hybrid XE Connections 69**
- Figure 3-7: Hybrid SE Connections 70**
- Figure 3-8: Hybrid PE Connections 71**
- Figure 3-9: Input and Output Ports For MAXPRO NVR Hybrid PE 72**
- Figure 3-10: Connecting a Video Source 73**
- Figure 3-11: Looping Output Termination 73**
- Figure 3-12: Control Outputs 74**
- Figure 3-13: Connecting Sensors 74**
- Figure 3-14: 4-Pin Adapter 75**
- Figure 4-1: Automatic Windows Update Enabled Warning Message 78**
- Figure 4-2: Pending Reboot Error Message 78**
- Figure 4-3: License Agreement 81**
- Figure 4-4: Customer Information and Destination Folder details 81**
- Figure 4-5: Validation of User Credentials 82**
- Figure 4-6: Choose Installation Type 82**
- Figure 4-7: Choose Installation Type 83**
- Figure 4-8: Database Server Log on 84**
- Figure 4-9: Choose location for MAXPRO NVR database Path 85**

**Figure 4-10: Choose Recording Drives 86**  
**Figure 4-11: Localization Support 86**  
**Figure 4-12: Summary 87**  
**Figure 4-13: Reboot prompt 88**  
**Figure 4-14: MAXPRO NVR 6.0 Client Configuration 90**  
**Figure 4-15: Localization Support 90**  
**Figure 4-16: Summary 91**  
**Figure 4-17: Reboot prompt 92**  
**Figure 4-18: Retaining Trinity Database 94**  
**Figure 4-19: Installation Finish 95**  
**Figure 5-1: MAXPRO NVR Log on dialog box 98**  
**Figure 5-2: Server Settings dialog box 100**  
**Figure 5-3: Setting the Default Profile 101**  
**Figure 5-4: Editing the Ports 102**  
**Figure 5-5: Port Forwarding Scenario 1 103**  
**Figure 5-6: Port Forwarding scenario 2 104**  
**Figure 5-7: Viewer tab 105**  
**Figure 5-8: Configurator tab 107**  
**Figure 5-9: Search tab 108**  
**Figure 5-10: Report tab 109**  
**Figure 5-11: General Settings tab 110**  
**Figure 5-12: Rendering Settings tab 110**  
**Figure 5-13: Rendering Settings tab 111**  
**Figure 5-14: Settings for pausing the Video Rendering 112**  
**Figure 5-15: Settings for the Alarm Preview Pane 113**  
**Figure 5-16: Setting the Alarm Threshold 113**  
**Figure 5-17: Settings for SnapShot Clip Export 114**  
**Figure 5-18: OSD Settings tab 114**  
**Figure 5-19: Timeline Settings tab 115**  
**Figure 5-20: Diagnostic Settings tab 115**  
**Figure 5-21: Advanced Settings Tab 116**  
**Figure 5-22: Advance Settings Tab Service Restart 117**  
**Figure 5-23: About MAXPRO NVR 119**  
**Figure 5-24: License Management Console 119**  
**Figure 6-1: CONFIGURATION page 126**

**Figure 6-2: CAMERA DISCOVERY page 128**

**Figure 6-3: Discovered Cameras 128**

**Figure 6-4: INSTALLATION page 129**

**Figure 6-5: MAXPRO NVR Wizard Task bar Settings 130**

**Figure 6-6: System page 131**

**Figure 6-7: Archive Progress 134**

**Figure 6-8: Disk Management page 136**

**Figure 6-9: Graphical Illustration 138**

**Figure 6-10: Drive Type 139**

**Figure 6-11: Camera page 140**

**Figure 6-12: Camera Properties pane 144**

**Figure 6-13: Auto Discovery Window 148**

**Figure 6-14: Camera Properties Pane 149**

**Figure 6-15: Adding Stream 149**

**Figure 6-16: Camera Type field displaying “ONVIF DEVICE” for a ONVIF camera 152**

**Figure 6-17: Encoder discovery 153**

**Figure 6-18: Adding the Encoder 154**

**Figure 6-19: Adding FLIR Model Camera 155**

**Figure 6-20: Saving FLIR Camera 156**

**Figure 6-21: RTSP Settings 157**

**Figure 6-22: IO page 158**

**Figure 6-23: Panomorph Settings 160**

**Figure 6-24: Grandeye Dewarping Settings 162**

**Figure 6-25: Discovering AXIS 360 Camera 163**

**Figure 6-26: Adding Remaining Axis Channels 164**

**Figure 6-27: AXIS Channels 165**

**Figure 6-28: Adding Arecont 360 Model Camera 166**

**Figure 6-29: Adding Remaining Arecont channels 166**

**Figure 6-30: Arecont Channels 167**

**Figure 6-31: EquiP- Fisheye camera Settings 168**

**Figure 6-32: Dewarping Success Message 169**

**Figure 6-33: Dewarped Views List 170**

**Figure 6-34: Adding or Deleting Analog Camera 171**

**Figure 6-35: Camera page 172**

**Figure 6-36: Camera properties pane 173**

Figure 6-37: Color Correction dialog box	175
Figure 6-38: Camera properties pane	177
Figure 6-39: Input and Output Ports For MAXPRO NVR Hybrid XE	179
Figure 6-40: Input and Output Ports For MAXPRO NVR Hybrid SE	180
Figure 6-41: MAXPRO NVR Hybrid PE Rear View	181
Figure 6-42: Input and Output Ports For MAXPRO NVR Hybrid PE	182
Figure 6-43: Detection of relevant motion	183
Figure 6-44: SMART VMD Configuration	184
Figure 6-45: Schedule page	186
Figure 6-46: Sequence page	187
Figure 6-47: User page	191
Figure 6-48: Enable On Demand	196
Figure 6-49: License Privacy protection Settings	198
Figure 6-50: Privacy protection Settings	199
Figure 6-51: Anonymization Camera Level	199
Figure 6-52: Anonymization at USer level	200
Figure 6-53: Blur View	201
Figure 6-54: Pixelize Views	201
Figure 6-55: Enable Four Eye	202
Figure 6-56: Four Eye Authentication	202
Figure 6-57: Four Eye Authentication Success	203
Figure 6-58: Authenticating User	204
Figure 8-1: Welcome Wizard	253
Figure 8-2: Installation Complete	253
Figure 8-3: Welcome Wizard	254
Figure 8-4: Installation Complete	255
Figure 8-5: Welcome Wizard	256
Figure 8-6: Installation Complete	256
Figure 8-7: Welcome Wizard	257
Figure 8-8: Installation Complete	257
Figure 8-9: Welcome Wizard	258
Figure 8-10: Validation of User Credentials	259
Figure 8-11: Localization Support	259
Figure 8-12: Summary	260
Figure 8-13: Upgrade Finish	260



**Figure 8-14: Welcome Wizard 262**  
**Figure 8-15: Installation Complete 262**  
**Figure 8-16: Welcome Wizard 263**  
**Figure 8-17: Installation Complete 264**  
**Figure 8-18: Welcome Wizard 265**  
**Figure 8-19: Installation Complete 265**  
**Figure 8-20: Welcome Wizard 267**  
**Figure 8-21: Installation Complete 267**  
**Figure 8-22: Taking Database backup using the MAXPRO NVR Agent 268**  
**Figure 8-23: Validation of User Credentials 269**  
**Figure 8-24: Choose Metadata Path 270**  
**Figure 8-25: Summary 270**  
**Figure 8-26: Reboot prompt 271**  
**Figure 9-1: MAXPRO WebConfigurator 275**  
**Figure 9-2: MAXPROWebConfigurator-Server Configuration 278**  
**Figure 9-3: MAXPROWebConfigurator-Security Configuration 279**  
**Figure 9-4: Home 281**  
**Figure 9-5: Server Certificate 281**  
**Figure 9-6: Specify Friendly Name 282**  
**Figure 9-7: Generated Certificate 282**  
**Figure 9-8: Site Bindings Dialog 283**  
**Figure 9-9: Edit Site Bindings 283**  
**Figure 9-10: Certificate Error 284**  
**Figure 9-11: Untrusted Certificate 284**  
**Figure 9-12: Certificate 285**  
**Figure 9-13: Certificate Import Wizard 285**  
**Figure 9-14: IIS Home 286**  
**Figure 9-15: Create Certificate Request 287**  
**Figure 9-16: Request Certificate 287**  
**Figure 9-17: Request Certificate 288**  
**Figure 9-18: Request Certificate 289**  
**Figure 9-19: IIS Manger 290**  
**Figure 9-20: IIS Manger 290**  
**Figure 9-21: Complete Certificate request 291**  
**Figure 9-22: IIS manger-Server Certificate 291**

**Figure 9-23: Site Bindings Dialog 292**  
**Figure 9-24: Add Site Bindings 292**  
**Figure 9-25: Certificate 293**  
**Figure 9-26: Certificate Import Wizard 294**  
**Figure 9-27: Server Configuration 295**  
**Figure 9-28: Program Maintenance 297**  
**Figure 9-29: Certificate dialog 297**  
**Figure 10-1: System Diagram 305**  
**Figure A-1: Computer Management 322**  
**Figure A-2: Task Scheduler 323**  
**Figure A-3: Create Basic Task 323**  
**Figure A-4: Task Trigger 324**  
**Figure A-5: Daily Dialog 324**  
**Figure A-6: Action dialog 325**  
**Figure A-7: Start a Program 325**  
**Figure A-8: Meta Data Conversion Utility Login 327**  
**Figure A-9: Meta Data Conversion Utility 327**  
**Figure A-10: Define Unique ID screen 328**  
**Figure A-11: Updating Unique ID 329**  
**Figure A-12: Offline Mode 330**  
**Figure A-13: Offline Updating Unique ID 330**  
**Figure B-1: I-frame Example 337**  
**Figure B-2: Camera configuration page 339**  
**Figure B-3: Sensitivity Level Comparison: Normal Field of View 341**  
**Figure B-4: Sensitivity Level Comparison: Wide Field of View 341**  
**Figure B-5: Combination Field of View Example 342**  
**Figure B-6: Upgrade Firmware - Setup Page 344**  
**Figure B-7: Smart Plan Setup Page 345**  
**Figure B-8: Extensional smart function page 345**  
**Figure B-9: Xtralis Login 346**  
**Figure B-10: Loiter Trace Page 346**  
**Figure B-11: Loiter Trace Configuration 347**  
**Figure B-12: Loiter Trace - Calibrate 347**  
**Figure B-13: Loiter Trace - Zones 348**  
**Figure B-14: Loiter Trace - Parameters 348**

**Figure B-15: Loiter Trace - Live View Logs 349**

**Figure B-16: User List 350**

**Figure B-17: ONVIF User Setup 350**


**Figure B-18: Server Maintenance 351**

**Figure B-19: Axis Credentials 353**

This page was intentionally left blank

# PRECAUTIONS

## Cautions and Warnings



Installation and servicing should be performed only by qualified and experienced technicians to conform to all local codes and to maintain your warranty.



WEEE (Waste Electrical and Electronic Equipment). Correct disposal of this product (applicable in the European Union and other European countries with separate collection systems). This product should be disposed of, at the end of its useful life, as per applicable local laws, regulations, and procedures.

## FCC Compliance Statement

Information to the User: This equipment has been tested and found to comply with the limits for a Class A digital device. Pursuant to Part 15 of the FCC Rules, these limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not

installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.



**Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la Classe B est conforme à la norme NMB-003 du Canada.

## Personal Data Storage

Please be aware that this product can store personal data.

Personal data is protected by the General Data Protection Regulation (2016/679) in Europe and therefore the owners of personal data have obtained certain rights thanks to this regulation.

We strongly advise you to be fully aware of these owner ("data subjects") rights as well as which limitations you have to obey regarding the use and distribution of this data.

Further details can be found on the GDPR website of the EU: [https://ec.europa.eu/commission/priorities/justice-and-fundamental-rights/data-protection/2018-reform-eu-data-protection-rules\\_en](https://ec.europa.eu/commission/priorities/justice-and-fundamental-rights/data-protection/2018-reform-eu-data-protection-rules_en)

## Important Safeguards

### 1. Read Instructions

All the safety and operating instructions should be read before the appliance is operated.

### 2. Retain Instructions

The safety and operating instructions should be retained for future reference.

### 3. Cleaning

Unplug this equipment from the wall outlet before cleaning it. Do not use liquid aerosol cleaners. Use a damp soft cloth for cleaning.

### 4. Attachments

Never add any attachments and/or equipment without the approval of the manufacturer as such additions may result in the risk of fire, electric shock, or other personal injury.

### 5. Water and/or Moisture

Do not use this equipment near water or in contact with water.

### 6. Ventilation

Place this equipment only in an upright position. Ensure product ventilation openings are not obstructed.

#### 7. Accessories

Do not place this equipment on an unstable cart, stand, or table. The equipment may fall, causing serious injury to a child or adult, and serious damage to the equipment. Wall or shelf mounting should follow the manufacturer's instructions, and should use a mounting kit approved by the manufacturer.



This equipment and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the equipment and cart combination to overturn.

#### 8. Power Sources

This equipment should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power, please consult your equipment dealer or local power company.

#### 9. Power Cords

Operator or installer must remove power, BNC, alarm, and other connections before moving the equipment.

#### 10. Lightning

For added protection for this equipment during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the equipment due to lightning and power-line surges.

#### 11. Overloading

Do not overload wall outlets and extension cords to avoid the risk of fire or electric shock.

#### 12. Objects and Liquids

Never push objects of any kind through openings of this equipment as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the equipment.

#### 13. Servicing

Do not attempt to service this equipment yourself. Refer all servicing to qualified service personnel.

#### 14. Damage Requiring Service

Unplug this equipment from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- When the power-supply cord or the plug has been damaged
- If liquid is spilled or objects have fallen into the equipment
- If the equipment has been exposed to rain or water

- If the equipment does not operate normally by following the operating instructions, adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the equipment to its normal operation.
- If the equipment has been dropped or the cabinet damaged
- When the equipment exhibits a distinct change in performance—this indicates a need for service.

#### 15. Replacement Parts

When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or that have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.

#### 16. Safety Check

Upon completion of any service or repairs to this equipment, ask the service technician to perform safety checks to determine that the equipment is in proper operating condition.

#### 17. Field Installation

This installation should be made by a qualified service person and should conform to all local codes.

#### 18. Correct Batteries



**Warning: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.**

#### 19. Operating Temperature

An operating temperature range is specified so that the customer and installer may determine a suitable operating environment for the equipment.

#### 20. Elevated Operating Ambient Temperature

If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the specified operating temperature range.

#### 21. Reduced Air Flow

Installation of the equipment in the rack should be such that the amount of airflow required for safe operation of the equipment is not compromised.

#### 22. Mechanical Loading

Mounting of the equipment in the rack should be such that a hazardous condition is not caused by uneven mechanical loading.

#### 23. Circuit Overloading

Consideration should be given to connection of the equipment to supply circuit and the effect that overloading of circuits might have on over-current protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.



## 24. Reliable Earthing (Grounding)

Reliable grounding of rack mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (for example, use of power strips).

# Warranty and Service

Subject to the terms and conditions listed on the Product warranty, during the warranty period Honeywell will repair or replace, at its sole option, free of charge, any defective products returned pre-paid.




In the event you have a problem with any Honeywell product, please call Technical Support at 1-800-323-4576 (North America only) for assistance or to request a Return Merchandise Authorization (RMA) number.









Be sure to have the model number, serial number, and the nature of the problem available for the technical service representative.









Prior authorization must be obtained for all returns, exchanges, or credits. Items shipped to Honeywell without a clearly identified Return Merchandise Authorization (RMA) number may be refused.

# List of Symbols

The following is a list of symbols that might appear on the NVR.

Symbol	Explanation
	The WEEE symbol. This symbol indicates that when the end-user wishes to discard this product, it must be sent to separate collection facilities for recovery and recycling. By separating this product from other household-type waste, the volume of waste sent to incinerators or landfills will be reduced, and thus natural resources will be conserved.
	The UL compliance logo. This logo indicates that the product has been tested and is listed by the Underwriters Laboratories.
	The FCC compliance logo. This logo indicates that the product conforms to Federal Communication's Commission compliance standards.

Symbol	Explanation
	<p>The direct current symbol. This symbol indicates that the power input/output for the product is direct current.</p>
	<p>The alternating current symbol. This symbol indicates that the power input/output for the product is alternating current.</p>
	<p>The LDPE symbol. This symbol indicates that this product is made of Low-Density Polyethylene (LDPE).</p>
	<p>The Direct Current symbol. This symbol indicates that the product operates from a 12 V direct current.</p>
	<p>The Lead-free symbol. This symbol indicates that the product does not contain lead (Pb).</p>
	<p>The CCC compliance logo. This logo indicates that the product conforms with the China Compulsory Certification guidelines.</p>
	<p>The Environment Friendly Use-period symbol. This symbol indicates the length of time that this electronic product can be used without harming the environment.</p>
	<p>The RCM Compliance symbol. This symbol indicates that the product conforms with the Australian RCM guidelines.</p>

Symbol	Explanation
	<p>The TUV Lab symbol. This symbol indicates that the product has been safety tested by the TUV Lab.</p>
	<p>The Direct Current symbol. This Direct Current symbol indicates that the product operates direct current.</p>
	<p>This symbol indicates that the product is to be used indoors.</p>
	<p>The CE Compliance logo. This logo indicates that the product conforms to the relevant guidelines/standards for the European Union harmonization legislation.</p>
	<p>The Protective Earth symbol. This symbol indicates that the marked terminal is intended for connection to the protective earth/grounding conductor.</p>
	<p>This symbol is used to direct attention to important information.</p>
	<p>This symbol warns that the corresponding action could result in an electric shock.</p>
	<p>This symbol indicates On/Standby functionality of the corresponding control/button/switch.</p>

This page is intentionally left blank

# ABOUT THIS GUIDE

## Overview

This guide describes the procedures and guidelines for installing, configuring and using the MAXPRO® NVR system.

## Intended Audience

This document is intended for field and commissioning engineers.

## Scope

This guide describes the installation and configuration procedures for both the MAXPRO NVR turnkey boxed solutions (MAXPRO NVR XE, SE, PE and MAXPRO NVR Hybrid XE, SE, PE models) and MAXPRO NVR software-only solution. This guide covers the following four major sections:

- Installing MAXPRO NVR
- Logging in and Familiarizing NVR
- Configuring MAXPRO NVR
- Upgrading MAXPRO NVR
- Configuring Web Client
- Installing and Configuring MAXPRO NVR Mobile App

# Overview Of Contents

The following table describes the detailed structure and the contents of each chapter in this guide.

No	Chapter	Description
1	<a href="#">Introduction to MAXPRO NVR</a>	Introduces the MAXPRO NVR system and types of Video surveillance solutions.
2	<a href="#">Commissioning MAXPRO NVR</a>	Describes the commissioning procedures for the MAXPRO NVR system.
3	<a href="#">Setting up the MAXPRO NVR</a>	Describes the tasks to set up the: <ul style="list-style-type: none"> <li>• <b>MAXPRO NVR Single Box solutions.</b></li> <li>• <b>MAXPRO NVR Software-Only solution.</b></li> </ul>
4	<a href="#">Installing the NVR Software</a>	Describes the procedures to install the MAXPRO NVR software.
5	<a href="#">Logging on and Getting Started</a>	Describes how to log on and gives an overview of the MAXPRO NVR.
6	<a href="#">Configuring MAXPRO NVR</a>	Describes the tasks for configuring the MAXPRO NVR.
7	<a href="#">Verifying the Configuration</a>	Describes the tasks to verify the MAXPRO NVR configuration.
8	<a href="#">Upgrade MAXPRO NVR Software</a>	Describes how to upgrade MAXPRO NVR
9	<a href="#">MAXPRO NVR Web Client</a>	Describes the procedures to install and configure the MAXPRO NVR Web Client.
10	<a href="#">MAXPRO NVR Mobile App</a>	Describes the procedures to install and configure the MAXPRO NVR Mobile App.
12	<a href="#">Appendix A</a>	Describes the procedures to customize MAXPRO NVR Single-box Turnkey solutions and setting up the Anti virus software on MAXPRO NVRs.
13	<a href="#">Appendix B</a>	Describes the Image Stream Combinations and Device Characteristics of OnCam Grandeye Cameras, Configuring VMD Settings and Motion-based Recording, Event and Alarm Types and MAXPRO® NVRs - AXIS Camera/Encoders Discovery and Configuration (using ONVIF).
14	<a href="#">Patches Released on Top of NVR 4.0</a>	Lists the various patches that are released on top of MAXPRO NVR 4.0. It also explains the enhancements that you can experience after installing the specific patch.

# Related Documents

This document listed in the table serves as a necessary prerequisite for understanding MAXPRO NVR.

Document title	Part number	Description
MAXPRO NVR Operator's Guide	800-26014-C	This document is written for everyday MAXPRO NVR users who perform the basic video surveillance operations.

# Typographical Conventions

This guide uses the following typographical conventions.

Font	What it represents	Example
Honeywell Sans Medium	Words or characters that you must type. The word "enter" is used if you must type text and then press the Enter or Return key.	Enter the <b>password</b> .
	Menu titles and other items you select	Double-click <b>Open</b> from the <b>File</b> menu.
	Buttons you click to perform actions	Click <b>Exit</b> to close the program.
Honeywell Cond Extrabold	Heading	Installation
Honeywell Sans Extrabold (Italic)	Cross-reference to external source	Refer to the <b>MAXPRO® NVR Installation and Configuration Guide</b> .
Honeywell Sans (Italic)	Cross-reference within the guide	See <a href="#">Installation</a> .

This page is intentionally left blank



## Overview

Honeywell's MAXPRO® NVR line includes turnkey solutions—NVR (XE, SE, PE) with 8 to 64 channels and NVR Hybrid (XE, SE, PE) with 16 to 64 channels—and software solutions that range from 4 to 64 and 128 channels. It supports ONVIF Profile S and PSIA interoperability standards, RTSP, native integration for third-party cameras—including 360° camera support—and encoders from Honeywell, Axis and other manufacturers, making it a truly open system. MAXPRO NVR provides easy to use desktop clients, web clients and mobile apps. The advanced IP video capabilities make MAXPRO NVRs easy-to-install with 3-clicks\* to live video and easy-to-use with features such as Video Surround, Calendar Search, SMART Motion Search and SMART VMD for every day security users as well as advanced video surveillance users.

\* - With default settings and in a local area network for specific models.

## MAXPRO NVR Turnkey Boxed Solutions

Honeywell's MAXPRO NVRs offer ideal solutions from entry to enterprise IP video surveillance systems. Supporting Honeywell's high definition (HD) cameras and broad integration with third-party IP cameras and encoders. The MAXPRO family of NVRs is a powerful HD IP recording and security monitoring system for a variety of applications. MAXPRO NVR comes pre-installed with the required software and pre-licensed with the required channels depending on the MAXPRO NVR model you purchase.

## MAXPRO NVR Software Only Solution

Honeywell's MAXPRO NVR Software is a flexible, scalable and open IP video surveillance system. Supporting Honeywell's high definition (HD) cameras and broad integration with third party IP cameras and encoders, the MAXPRO NVR family is a powerful, high definition IP recording and security monitoring system for a variety

of applications. MAXPRO NVR Software solution ensures flexibility for end-user IT departments when the choosing NVR hardware to deploy and end users will find it as easy as a simple DVR to configure and operate.

MAXPRO NVR Software is an open platform that supports broad third party device integrations with support for PSIA and ONVIF Profile S standards, real time streaming protocol (RTSP) standard and native device integrations. MAXPRO NVR provides easy-to-use desktop, web clients and mobile apps. MAXPRO NVR Software comes with all required software applications and a license for 4, 8, 16, 32, 64 or 128 channels while allowing for up to 128 cameras as your system grows. Minimum hardware specifications for different levels of recording and monitoring performance are provided for IT departments to choose the appropriate hardware platform for their system. This, along with quick and easy commissioning wizards for discovery and system configuration, makes installing HD IP systems quick and efficient without requiring any IP expertise. Simple and logical configuration pages make setup a breeze even for the novice installer. The following table describes the software solutions available.

# MAXPRO NVR Family

The following table describes the various MAXPRO NVR Hybrid and MAXPRO NVR offerings that are available.

							
	<b>MAXPRO NVR Hybrid XE (Xpress Edition)</b>	<b>MAXPRO NVR Hybrid SE (Standard Edition)</b>	<b>MAXPRO NVR Hybrid PE (Professional Edition)</b>	<b>MAXPRO NVR XE (Xpress Edition)</b>	<b>MAXPRO NVR SE (Standard Edition)</b>	<b>MAXPRO NVR PE (Professional Edition)</b>	<b>MAXPRO NVR Software</b>
<b>Description</b>	Simple, affordable NVR Hybrid	Flexible, scalable NVR Hybrid	Enterprise class NVR Hybrid	Simple, affordable NVR	Flexible, scalable NVR	Enterprise class NVR	Flexible, software only NVR
<b>Channels</b>	16 Analog or 16 IP	16 Analog and 48 IP or only 64 IP	16 Analog and 48 IP or only 64 IP	8 or 16	Up to 64	Up to 128	4, 8, 16, 32, 64 or 128
<b>Maximum Frame Rate at 4CIF/ VGA IP</b>	480 fps (16 ch IP)	1920 fps (64 ch IP)	1920 fps (64 ch IP)	480 fps	1920 fps	1920 fps	Server hardware dependent- Minimum hardware specs recommended for various fps
<b>at 720p IP</b>	480 fps (16 ch IP)	1920 fps (64 ch IP)	1920 fps (64 ch IP)	480 fps	1920 fps	1920 fps	
<b>at 1080p IP (4 Mbps bitrate)</b>	480 fps (16 ch IP)	1280 fps (64 ch IP)	1920 fps (64 ch IP)	480 fps	1280 fps	1920 fps	
<b>at CIF or 4CIF/D1 Analog</b>	480 fps CIF or 120 fps 4CIF/D1 (16 ch Analog)	480 fps CIF or 120 fps 4CIF/D1 (16 ch Analog)	480 fps CIF or 120 fps 4CIF/D1 (16 ch Analog)				
<b>Storage</b>	1 - 16 TB, internal fixed	1 - 24 TB removable bays	Up to 68 TB RAID 5/6, removable bays	1 - 12 TB internal fixed	1 - 48 TB, removable bays	Up to 68TB RAID 5/6, removable bays	Server hardware dependent
<b>Form Factor</b>	Desktop	Workstation/Server	Server	Desktop	Workstation/Server	Server	Server hardware dependent

**Note:** *The product options available in your region may vary, please contact your local Honeywell representative for more information.*

## MAXPRO NVR Features

MAXPRO NVR (Turnkey NVR/Hybrid boxes - XE, SE, PE and Software only solution) offers the following key features that differentiate it from other IP video surveillance systems.

### Mask Compliance Detection

Mask Compliance Detection feature detects the people who are with and without Masks in a given scene. This feature detects in a real time scenario and generates an event for People with/without mask. It helps in monitoring the people those who are violating the compliance of not wearing a mask in public places. This feature requires dedicated license to configure and use.

### Social Distancing Violation Detection

Social Distancing Violation detection feature detects distance between two people and raises an alarm if the social distance norm is violated. This feature helps to ensure social distancing is followed in your premises. This feature requires dedicated license to configure and use.

### Alarms for both Mask Detection and Social Distancing

Following are the list of alarms that are generated in NVR for Mask and Social Distancing detection features:

- Person Detected with Mask
- Person Detected without Mask
- Social Distancing Violation
- Non- Compliant Social Distancing Regions

### Operating Conditions

There are various recommendation with respect to operating conditions for both Mask Detection and Social Distancing to give good results. It is recommended to refer these operating conditions before using these feature.

### Non-Compliant Social Distancing Regions

This feature helps user to identify the areas in which the sub regions/areas of camera views where the most number of Non-complaint social Distancing violations are happening.

In order to generate this alarm, user need to create at least one region. The system monitors the Social distancing violations and then monitors in to each region how many social distancing violations are occurred. The algorithm calculates the most violated regions and raises an alarm. This alarm is displayed in percentage of viola-

tion for a given time. This alarm is generated periodically every 5 hours (Configurable See [Configuring Social Distancing ROI Duration and Show](#) section). A maximum of 6 ROI's can be created.

**Note:** User has to configure the Social Distancing first in order to configure this alarm.

## Analytic Alarms in NVR

The below screen displays the list of alarms that are generated in NVR for Mask Detection, Social Distancing violation and Non-Complaint Social Distancing Region features.

The screenshot shows a window titled "Alarm" with a table of alarm events. The table has five columns: Description, Event details, Device, IO Status, and Date Time. The events are listed in two sections, one with a pink background and one with a blue background. An "Acknowledge" button is visible between the two sections.

Description	Event details	Device	IO Status	Date Time
Social Distancing Violation	--	SD	NONE	12/16/2020 8
Person detected without mask	--	Camera52	NONE	12/16/2020 8
Social Distancing Violation	--	SD	NONE	12/16/2020 8
Social Distancing Violation	--	SD	NONE	12/16/2020 8
Social Distancing Violation	--	SD	NONE	12/16/2020 8
Non-Compliant Social Distancing Regions	--	SD	NONE	12/16/2020 8
Social Distancing Violation	--	SD	NONE	12/16/2020 8
Person detected without mask	--	Camera52	NONE	12/16/2020 8
Social Distancing Violation	--	SD	NONE	12/16/2020 8
Social Distancing Violation	--	SD	NONE	12/16/2020 8
Social Distancing Violation	--	SD	NONE	12/16/2020 8
Social Distancing Violation	--	SD	NONE	12/16/2020 8
Social Distancing Violation	--	SD	NONE	12/16/2020 8
Social Distancing Violation	--	SD	NONE	12/16/2020 8
Person detected without mask	--	Camera52	NONE	12/16/2020 8
Social Distancing Violation	--	SD	NONE	12/16/2020 8

## Scalable Analytics Server

This feature is introduced to manage the load on a NVR box while rendering analytics based cameras. Earlier only one local analytics server was available for multiple cameras that support analytics. This results in high consumption of CPU and low rendering capability of live video in NVR cameras.

Scalability feature helps customer to share the analytics server load on different remote machines and utilize the analytic algorithms efficiently. User can map the required cameras to each remote server and view the alarms in VMS,

A new tab named Analytics Server is introduced under Configurator tab to add additional analytics server and to choose the one while configuring Social Distancing, Mask compliance and SVMMD features. This provides flexibility and increases the processing time to manage the load over analytics server when configuring multiple features.

- A maximum of 5 Analytics Remote boxes can be added under this tab.
- For each Analytics Remote box, 4 camera with 30 FPS and up to 8 cameras with 5 FPS can be assigned

## Bulk configurations of cameras from NVR

This feature allows you to perform Bulk camera configuration for main and sub stream's, to ease the effort of configuring multiple cameras at the customer site. This feature improves the productivity for dealers and system integrators while configuring many NVRs. The configuration of cameras from the NVR is done one by one today (either post discovery or manual addition). This leads to higher lead time to configure and setup customer sites.

You can perform the following using Bulk configuration screen:

- General Settings
- Schedule Settings
- Preference Settings
- Stream Settings including child stream configurations specific to camera model
- SVMD Configuration

## Bi-Directional Audio Support for MAXPRO NVR

This feature helps an operator to send Bi-directional audio warnings/messages to any audio output of cameras from MAXPRO VMS machines. Currently Mic and speech is supported from VMS viewer only.

This feature supports standard audio Codec format G.711 ulaw and only Honeywell ONVIF Camera model are supported.

*Only Honeywell ONVIF Camera models are supported.*

*Only fixed G.711 ulaw Codec format is supported.*

*Mutlistream is supported, but can be enabled in only one stream at a time.*

*It is recommended for the user to enable and speak for one camera at a time.*

## Series 60 Camera Integration

MAXPRO VMS R670 supports Series 60 Camera integration with MAXPRO NVR 6.7 recorder. The following tables explain the list of supported camera models, and events/alarms supported.

Type	Camera Models	Firmware Details
Premium Model	HC60W35R2	HoneywellL60-Series_IPC_HC60WXXRX_V1.0.21.20200828
	HC60W35R4	
	HC60W45R2	
	HC60W45R4	
	HC60WB5R2	
	HC60WB5R5	
	HC60WZ2E30	
Mainstream Model	HC60W34R2L	
	HC60W34R2	
	HC60W44R2L	
	HC60W44R2	
	HC60WB4R2L	
	HC60WB4R2	
Series60 IR PTZ	HC60WZ5R30	
Series30	HC30W25R3-12V	

## Support for Ex-Proof Camera models

MAXPRO NVR 6.7 supports Ex-Proof Camera integration. The following tables explain the list of supported camera models, Codec and Resolutions supported.

Camera Models	Codec & FPS Supported	Resolutions Supported
HEIPTZ-2201W-IR	H264, H265, MPEG FPS: 50 for PAL FPS: 50 for NTSC	1920 x 1080, 1280 x 960, 1280 x 720, 704 x 576, 640 x 480, 352 x 288
HEICC-2301T	H264, H265, MPEG FPS: 50 for PAL FPS: 60 for NTSC	1920 x 1080, 1280 x 960, 1280 x 720, 704 x 480, 640 x 480, 352 x 240

## Enhancements in FishEye camera Dewarping Support

This enhancement for FishEye camera allows you to view/perform the following

- When one of the Quad-view column display 360° view then the user can select a designated location to display for the rest of the 3 columns.
- Allow PTZ function during live-view and playback.
- Enable PTZ operation on Quad-view setting & Dewarped image.
- Oncam GPU rendering support

This improvement is supported only to the following camera models:

- HC12-IEC1-O: C-12 Indoor Camera
- HC12-OPC1-O: C-12 Outdoor Plus Camera

Refer to the MAXPRO NVR 6.7 Operator Guide on how to configure and use this feature

## Mask Compliance Detection

Mask Compliance Detection feature detects the people who are with and without Masks in a given scene. This feature detects in a real time scenario and generates an event for People with/without mask. It helps in monitoring the people those who are violating the compliance of not wearing a mask in public places. This feature requires dedicated license to configure and use. Refer to the MAXPRO NVR 6.7 Operators Guide on how to configure and use this feature.

## Social Distancing Violation Detection

Social Distancing Violation detection feature detects distance between two people and raises an alarm if the social distance norm is violated. This feature helps to ensure social distancing is followed in your premises. This feature requires dedicated license to configure and use. Refer to the MAXPRO NVR 6.7 Operators Guide on how to configure and use this feature

## Alarms for both Mask Detection and Social Distancing

Following are the list of alarms that are generated in NVR for Mask and Social Distancing detection features:

- Person Detected with Mask
- Person Detected without Mask
- Social Distancing Violation

## Operating Conditions

There are various recommendation with respect to operating conditions for both Mask Detection and Social Distancing to give good results. It is recommended to refer these operating conditions before using these feature.

## Recommended Operating Conditions For Mask Detection

Mask Detection algorithm is developed to detect people who are with and without Masks in live video.

This section provides recommended specifications that can provide good or better mask detection accuracies.

### Recommended Operating Conditions

Parameter	Specification
Camera height from the ground	8 – 10 feet



Camera field of view and orientation/tilt	Mounting should be suitable to obtain frontal face images. H-FOV should not more than 60 degrees. Ceiling mounted or overhead mounted cameras which have near vertical view of faces looking down is not recommended for the application. Bright light in the background or sunlight which results in poor image quality of face in not recommended. Wide angle camera with long field of view is not recommended.
Image quality	Full HD 2M pixel camera video streams with high bitrate (5 to 8 Mbps for 30fps) with no blur and good focus. For 3MP cameras the recommended bit rate 10 to 15 Mbps. Good quality video encoding should be used (H.264/H.265)
Illumination	100-150 lux (uniform illumination on both sides of face)
Face pose for MD	Frontal pose can have +/-45 deg variation
Detection Distances	Maximum distance from camera 15 feet along the ground. Highly preferred that people enter into the field of view from distances not more than 15 feet and there is no clutter or moving objects (prefer a static background such a wall so that false detections are avoided)

### Configuration parameters:

Parameter	Specification
Minimum Size of the face with Mask	50 x 50 Pixels
Minimum Confidence level recommended	50%

**Note:** To avoid false alarm please follow the operating condition and keep the confident level more the 80%.

### Recommended Operating Conditions For Distancing Violation detection

This section provides specifications of the conditions that can provide a good or better social distancing solution with respect to camera placement and operating conditions requirements.

Required operating conditions can be divided in two sections as explained:


- Conditions for person detection
- Conditions for calibration selection of ground plane.

#### Person Detection Conditions

Below figures explains different preferred camera placements and conditions for person detection. It is to be noted that the numbers given in the figures are approximate and can vary:

##### Placement 1: Normal Perspective View

### Placement 1: Normal Perspective View




This placement explains that the person recognition can be good till around 30 feet, when the camera placement is < 8 feet (given that average height of person is between 5-6 feet), and when the person is at approximately 20-30 feet from the camera. Also, lighting should be > 250 lux and the light should be falling on the person with no back lighting for better accuracies.

### Placement 2: Camera at a higher height or ceiling height


This placement explains the configuration wherein the camera is placed at a much higher height than the person.

#### Placement2: Camera Placed at higher heights and looking sharply down to the ground plane



If the camera height is as shown in the above figure, the FR accuracies can be reduced with distance. But at lesser distances from camera (<10-12 feet), FR can be accurate enough. Again, adequate amount of light falling on the face for good features is an important requirement.

### Placement 3: Camera at higher height from the ground




In this placement the camera height is nearly overhead, the person detection model is not tested when there is just head and shoulders view in the video stream. It is recommended that silhouette of the person is seen.

## Calibration Conditions

Calibration is the most important step for distance measurement between two people. The primary requirement of this step is that the ground plane on which distances between people are measured and the ground plane that is calibrated should be the same. Details of this statement in form of figures are given in this section.


### Condition 1: Camera Perspective View with one ground plane

This condition details the meaning of ground plane being at the same level. The level of the ground where people are moving and the measurement for social distancing should be one planar level. This is the most important requirement for accuracies of calibration. The configuration is done on Ground Plane Level 1 and Social distancing output will be done on this plane only. Stairs are not counted for the solution.




**Condition 2: Multiple ground planes**

This conditions gives the sketch wherein there are people moving on the pathway (one ground plane level) and a staircase too. The staircase is of different ground plane level when compared to the pathway ground nearby. Hence the current solution calibration can be done on the pathway and NOT on the stairs. Our solution will not address output for people on the stairs



**Condition 3: Multiple Ground Planes with slope as the second plane**

This condition explains a sketch wherein the stairs in Condition 2 is replaced by a slope. Even in this situation, our solution will not give correct results on the slope. The calibration needs to be done on Ground Plane 1 and results also will be for ground plane 1.



**Note:** In registry there is an option to change at what distance Social Distancing alarm should be generated. For example: 4 ft, 10 ft.

## Support for Remote Analytics Server

MAXPRO R670 release support for Remote analytics Server configuration for Mask, Social Distancing and SVM on i8700 & 9700 Machines. This configuration is required if the existing systems are not capable to take up the load of Analytics and to avoid overshoot of system resources memory. See [Configuring Remote Analytics Server](#) section for more information.

**Note:** Analytics server is supported only on Windows 10 OS platform.

## Series 60 Camera Integration

MAXPRO VMS R630 supports Series 60 Camera integration with MAXPRO NVR 6.7 recorder. The following tables explain the list of supported camera models, and events/alarms supported.

Type	Camera Models	Firmware Details
------	---------------	------------------

Premium Model	HC60W35R2	Honeywell L60- Series_IPC_HC60WXXRX_V1.0.21.20200 828
	HC60W35R4	
	HC60W45R2	
	HC60W45R4	
	HC60WB5R2	
	HC60WB5R5	
	HC60WZ2E30	
Mainstream Model	HC60W34R2L	
	HC60W34R2	
	HC60W44R2L	
	HC60W44R2	
	HC60WB4R2L	
	HC60WB4R2	

## Supported Events/Alarms

Series 60 Camera models support the following events/alarms:

Event
Tampering
Image too bright
Image too dark
Image too blur event
Motion Detection
Intrusion Detection
Loitering Detection
Line crossing Detection
Unattended Object Detection
Missing Object Detection
Face Detection

## Supported key Features

- HTTPS integration: The camera supports complete HTTPS protocol while integrating with NVR.
- Smart Stream III
  - Smart Codec
  - Smart FPS
  - Dynamic intra Frame Period (DIF)
- Alarms
- Profile S compliant
- Multicast
- Edge Sync Recording Support
- Full Encrypted Communication (including Encrypted Profile G communication)

## Thermal Camera Integration - HRCF-FD384H/HRCF-FD640H

MAXPRO R630 supports integration of Silent Sentinel and Thermal Cameras. Following are the cameras and firmware details:

Type	Camera Model	Firmware Details
Silent Sentinel	HRCF-FD640H	V4 :v1.0.1D20200603
	HRCF-FD384H	
Thermal Camera	HVCT-B4010I	V5.5.26 build 200514
	HVCT-B4020I	
	HVCT-D4010I	

Refer the MAXPRO integration with MODUM Technical Notes for detailed information on the how to integrate the HRCF-FD384H/HRCF-FD640H Thermal cameras with MAXPRO NVR.

## SSA - Software Service Agreement for MAXPRO

Software Service Agreement (SSA) is a flexible version specific licensing process which allows a user to get the support on the MAXPRO VMS licenses across multiple versions. From 6.0 release user need to buy a valid license to upgrade or for fresh installation. In addition user can buy SSA support license for a specific duration which helps to get support from Honeywell.

Please contact Honeywell Customer support. See the back cover for the contact information in respective regions. **Licensing changes for Software Service Agreement.**

## NDA Series 30 camera Integration in MAXPRO NVR & VMS

Series 30 Camera integration is supported in 6.0 release with MAXPRO NVR recorder. The following tables explain the list of supported camera models, firmware version and events.

**Note:** FishEye camera does not support HTTPS.

#	Camera Models	Firmware Details
1	HC30W42R3	v1.0.18.20190523 Note: If a camera has older firmware, please upgrade to the above firmware version and perform factory default once.
2	HC30W45R3	
3	HC30W45R2	
4	HC30WB2R1	
5	HC30WB5R1	
6	HC30WB5R2	
7	HC30WE2R3	
8	HC30WE5R3	
9	HC30WE5R2	
10	HC30WF5R1	

## Supported Events

Series 30 Camera models support the following events:

Event
Motion Detection
Tamper
Image too blur
Image too dark
Image too bright
People Detection
Intrusion

## Supported key Features

- Smart Stream III
  - Smart Codec
  - Smart FPS
  - Dynamic intra Frame Period (DIF)
- HTTPS
- Alarms
- Profile S compliant



- Multicast

## MPEG2 Encoder Support with MAXPRO NVR and VMS

NVR 6.0 supports legacy MPEG2 Encoders with Live and playback, Alarms and VMS in VMS functionalities. The following encoders are supported.

- ENC8M2
- VE8M2

Supported Firmware Version: 1.2.261

## Additional Cameras Support

In addition to above HC Series 30 cameras, NVR 6.0 supports the below camera models:

- H4W8GR4IN
- H4W8GR1IN

**Supported Codec Formats:** H.265, H.264, H.264H, H.264B, MJPEG.

## Additional Resolution Support

For HFD6GR1 model camera, following additional resolutions are supported:

- 2432 x 1216
- 1920 x 1080
- 960 x 480
- 640 x 320
- 512 x 256

## Video Guard service for SIRA compliance

MAXPRO NVR 6.0 release supports SIRA compliance with Video Guard Agent. This is to meet the specifications defined as part of the City wide Surveillance initiative by the Security Industry Regulatory Agency (SIRA) of Dubai, UAE, and being adopted across Middle-East countries.

## New Features in NVR 5.6

### Support for Equip series V2 Cameras

The following is the list of Equip Series V2 camera integration is supported in MAX-PRO VMS:

**Note:** *Recommended to use NVR 5.6 and above to connect to the below camera firmware.*

#	Camera Model	Type
1	H2W2GR1	WDR cameras
2	H3W2GR1V	
3	H3W4GR1V	
4	H4W2GR1V	
5	H4W4GR1V	
6	HBW2GR1V	
7	HBW2GR3V	
8	HBW4GR1V	
9	HCW2GV	
10	H4L2GR1V	Ultra Low Light
11	HCL2GV	
12	HBL2GR1V	

The below table details the Firmware version compatible with the NVR 5.6 Build 572:

Camera Model	Firmware	Web Version	Onvif Version	ISOM Version	Xtralis Intrusion	Xtralis Loitering	Intrusion Detection	Loitering Detection	Trigger Line Detection
Equip S Series V2 Firmware version					VA Packages				
Ultra Low Light	1.00000000.18, 2019-04-23 Or above.	3.2.1.722 805	16.1.2	1.3.1, 2019-04-21	1.01.19	1.01.19	1.0.8, 2019-01-15	1.0.8, 2019-01-15	1.0.8 2019-01-15
WDR cameras	1.00000000.18, 2019-04-09 Or above.	3.2.1.716 054	16.1.2	1.3.1, 2019-04-04					

The above Equip S Series V2 Firmware version supports the following features:

- New VA events added with Annotation support
  - Xtralis IntrusionTrace™
  - Xtralis LoiterTrace™

- Intrusion Detection
- Loitering Detection
- Trigger Line Detection

**Note:** Annotation feature is supported only with Xtralis XO package.

- Profile -G Edge Sync recording
- Multicast

## Support for HRHQ104 DVR

NVR 5.6 supports HRHQ104/108/116 DVR (V1.00.00HW001.1.190422) as 4/8/16ch encoders

## Support for smooth Rendering at VMS

NVR 5.6 Build 570 installation is mandatory for smooth reverse playback in MAX-PRO VMS.

## New Features in NVR 5.5

### Analytics Annotations Support

Camera built in Annotations feature helps to trace and locate the moving subjects in live/recorded video and generates an alarm if intrusion or loitering is detected. After this feature is enabled in NVR, subjects in video when found in Region Of Interest, is bounded by rectangle box and on alarm conditions, it will be signified with a change in color of bounding box.

Annotation support for Intrusion Trace and Loiter Trace in Live and Playback video is supported with only Equip-S Series specific cameras

See [Annotations](#) section on how to configure this feature.

### Enhancements in Video connection

Improvements in video connection from Viewer.

## New features in NVR 5.0

### Patches Merged in SP1

#### 5.0 T Patch

- Refer to the 800-22559V1-E\_MAXPRO NVR\_5.0\_T Patch\_Whats\_New\_Release\_Notes for complete information on new features in 5.0 T Patch.

## Windows Expiry Patch

This patch is to make MAXPRO VMS application not to apply password expiry option for windows users. Refer to the MAXPRO® VMS\_ Windows Expiry\_Patch\_Release Notes for detailed information.

## Archival Improvements

### Include Archived Clips

This feature allows user to search Archived clips including the recording clips. User needs to select Include Archived Clips check box under Filter area while searching for recorded clips. Based on the search criteria the archived clips are displayed in Grey color. When user drag and drop the archived clips in to the panel then camera name and clips status as REC is displayed. Refer to the [MAXPRO® NVR Operator Guide](#) for complete details on how to search for Archived clips.

**Note:** *If user selects Include archived clip check box and then search for archived clips, it displays only auto archived clips. It will not display the manually archived clips.*

### Primary and Archived Location

The Archived clips in the Result window also displays the location of Archived clip as explained below.

- Archived: The clip is available in Archived path
- Primary, Archived: The clips is available in both primary storage and Archived path

### Camera Name & Clip status

In Viewer screen following are the improvements:

- Under Snapshots/clips, the folder naming structure is changed to camera name.
- When a user drag and drops a archived clip into panel, the archival camera name with clip status Rec is displayed.
- If Archived clips are played in MAXPRO clip player then the camera name and clip status is also displayed.

### Archival Schedule Check box

Ensure Clip scheduled for archival are not deleted until archived check box is introduced in System tab > Archival Schedule to ensure that clips will not be deleted by the system until it is archived. The following are the benefits if user selects this check box.

- If the clip deletion schedule is reached for a specific clip then this feature will retry and archive the clip.

This check box settings is applicable for the following:

- Integrity services
- Neo Deletion Scheduled
- Disk Space Full
- Distress deletion

## Archival Clip and Deletion Retry

This feature is introduced to allow user to configure the Archival and Deletion retry settings in the config file available in bin folder. For any reason if the archival drive disconnects then based on the config file settings the:

- Archival clip retry feature will help to get the pending archival clips.
- Deletion clip retry feature will retry the process and deletes the clips.

The default value for retry process is set to 4. User can set the required number for archival and deletion retry process.

See [How to configure the Archival and Deletion retry settings](#) section on how to set the retry process.

## Validation Message For Network Credentials

If user adds a Network Drive for Archival without Domain, Username and Password then a validation message is displayed to provide the network credentials.

## Disabled Password Never Expires

In User tab, if IS Windows user check box is selected then the Password Never Expire check box is disabled and it cannot be cleared. This ensures that for a Windows user the password will never expires.

## Playing archived clips through Client machine

User was unable to access and play the archived clips from NVR server machine. If user drag and drops the archived clips into the viewer then an error message is displayed.

User needs to have the privileges to access the archived clips from remote NVR clients. Refer to the See [Playing archived clips through Client machine](#) for complete details of the possible combinations to play the archived clips from client machine.

See [Different Scenarios to playback Archived Clip](#) section to playback Archived clips.

## Improved GPU rendering

GPU Rendering capability is now enhanced to handle the camera video packets along with decompression technique. User can view smooth and clear live video through GPU rendering. User should modify the registry value in client or server machine to enable GPU rendering mode. See [Improved GPU Rendering](#) section on page 242 for more information.

## GPU Rendering Combinations

The below table explains the combination settings between Enabling GPU Rendering option in Preference tab and Registry settings.

IF	And If	Then
User enables Enable GPU Rendering check box in Preferences > Rendering options tab	user sets GPU_Rendering_Value flag to 1	Both Decompression and Rendering will be processed through in GPU mode.
User enables Enable GPU Rendering check box in Preferences > Rendering options tab	user sets GPU_Rendering_Value flag to 0	Decompression process will happen through GPU and Rendering will be processed in CPU mode.
user does not select Enable GPU Rendering check box in Preferences > Rendering options tab	user sets GPU_Rendering_Value flag to 1	Both decompression and Rendering will be processed through CPU.

## 60FPS support for EQUIP-S 1080P cameras

EQUIP-S 1080 P Model cameras are now supported with 60FPS rendering through GPU Rendering Mode. The following are the list of cameras support 60 FPS.

**Note:** *Cameras beyond 1080 resolution will not support 60 FPS rendering.*

- H4L2GR1V
- HBL2GR1V
- HCL2GV
- H4W2GR1V
- HBW2GR1V
- HBW2GR3V
- H3W2GR1V
- HCW2GV
- H2W2GR1

## NAS Recording support

Network Attached Storage (NAS) external drive is now supported for recording video clips along with other drives in MAXPRO NVR. This helps user to extend the storage capacity to save the recordings. User needs to configure the directory and user permission in respective NAS web page to use this feature. See [Guidelines to configure NAS Drive for Recording](#) section on page 245 for complete information

**Note:** *If customer is using Infotrend NAS then they have to create the user inside the NAS box. The username could be NVR-Admin or Administrator.*

## Video Anonymization

This feature allows user to configure or mask identifiable objects based on the scene environment. It provides flexibility to choose and configure the required camera based on the mounting position. User need to select the required Environment from the Stream Preferences Settings based on the camera mounting position. The following are the options supported. See [Video Anonymization](#) section on page 239 for more information on how to configure based on scene environment.

- Variable Scene: If the scene contains both stationary and moving people or objects then select this option to anonymize the objects in the scene.
- High Motion Scene: To anonymize the objects in high motion in the scene.
- Still Scene: To anonymize the objects in a scene where the scene predominantly contains stationary people and objects.

## Installation

- NVR 5.0 Installation is supported for Windows 2016 OS (Server).

Introduced the following new services

- TrinityIntegrity Service: A service that runs in background and ensures all the system data is synchronized. As part of 5.0 release it includes features such as Delete Orphan Data and Drive Feature. See Integrity Service Settings section for more information.
- Trinityupdate Service: A service introduced to scale recording capacity on demand and to enable necessary steps required for additional recording services.
- NeoStorageserver3 and NeoStorageserver4: These services are to support 128 channels in a system and starts automatically after a user crosses 64 and 96 channels respectively. These services will stop when user deletes the cameras and the count goes less than <64 and <97 respectively.

## Support for 128 Channel

Additional 64 channels are provided with the existing 64 channels, resulting in a total of 128 channels in NVR Software and PE RAID System. User needs to buy license for the additional channels. If only Encoders are added in the system then without additional license user can add up to 128 Channels. However, adding additional channels depends on the type of encoder.

## Privacy Protection Settings (GDPR)

### Anonymization Support

Anonymization feature is to help the business owner to meet the EU GDPR compliance standards easily. The objective of this feature is to hide the identifiable personal data or personal identity in a video surveillance system using masking techniques. This feature is specific to European Union region and valid license is required to enable this feature.

Anonymization at NVR level can be set in Configurator > Systems tab and only an Administrator can use this feature and grant access in User tab. This feature can also be enabled at camera level under Stream > Preferences tab. Equip Series cameras are supported by this feature.

To mask the identifiable objects based on the scene environment, see [How to Anonymize objects based on Environment](#) section on page 240 for more information.

The Anonymization feature supports two types of masking:

- Blur: Blurs the region
- Pixelize: Pixelizes the region

### Four Eye Authentication Support

This feature is also part of Privacy Protection setting and to meet the EU GDPR compliance standards easily. This feature is to restrict all users in a surveillance system to perform Playback operation. While performing playback operation at least two people from different roles should authenticate. For an Administrator, user authentication is not required and can do any playback operation. For an operator user, a popup is displayed and an Administrator user or any other User with different role needs to authenticate to perform playback operation.

In MAXPRO NVR, a check box is introduced to enable this feature in Systems tab. By default this check box is not selected. User need to obtain valid license to enable this feature.

The following table explains the Four Eye Authentication based on the user and roles

User	Authenticating User	Valid Authentication
Operator	Administrator Or any other user with different role	Yes



Operator	Operator	No
Operator	Operator 2	Yes

Clip Export with Anonymization support

Anonymization feature is supported for both Playback and Clip Export operation.

**Note:** *If a user exports a clip with Anonymization using Clip Export option then only WMV format is supported.*

## Password Complexity and Expiry Enhancements

The following are the enhancements:

- Improved change of password security by introducing complexity requirements. The following are the password requirements.
- The password should have a minimum length of 12 characters.
- The password should consist of at least one number, one uppercase letter and one special character
- If user changes the password, it will expire for every 90 days. Earlier it was no expiry
- If user wants to set the password which should never expire then navigate to Configurator > Users tab. Select the Password Never Expire check box for the specific user.
- User is notified with the message Your Password will expire in no.of days on the top right corner of the screen.
- If Admin password is expired then the administrator can use the Change Password feature in NVR log in screen to create a new one.

**Note:** *Only administrator will have access to user screen and can change the password for operator. Operator should contact administrator for changing the password and settings.*

In Upgrade Scenario

If user upgrades to NVR 5.0 then the password complexity requirements will be applicable.

In Fresh Installation Scenario

In case of Fresh Installation, the following are the recommendations:

- Only default username is displayed and the password field will be blank
- User must create new password
- In Create New Password dialog box, leave the Old Password field blanks and proceed.

## UI Improvements

For better user experience and accessibility the following features are rearranged in Systems tab

- Archival Schedule
- In camera level added after 30 minutes (s) as a new entry.
- Edge Sync Settings
- Privacy Protection Settings

## Improvements in Status Monitor

- Additional status message Database Connection lost is included. This will help user to know the status of database connection.
- Color Indications:
  - Green: Everything is Fine
  - Blinking between Yellow and Green: Not Recording
  - Blinking between Yellow and Red: Database Connection Lost

## System and Performance Improvements

- There is no Metadata from 5.0 Release onwards.
- No separate drive is required for Metadata
- New Recording file system with no Index files except PassIndex is introduced and it is for per camera and per drive.
- Plug-in a new recording drive which can have recordings of another 5.0 NVR, and play the same recordings by adding the same Unique Number of the camera.
- Supports backward compatibility (5.0 version can play till 4.9 version recordings (With Metadata) including 5.0 recordings). No recording loss in user's perspective.
- Recording, Retrieval and Recycle features will have no dependency on index files.
- PassIndex only use as catalyst
- New naming convention for Segment files (Num\_StartTime\_EndTime)
- Access recordings directly from recording drive
- Each recording drive is self sufficient
- XML Corruption recovery
- Auto recovery of corrupted XMLs by NEO on the run
- No functionality loss

## Integrity Service Settings

This is a new a service that runs in background and ensure all system data to be synchronized. Following are the features this service provides as part of 5.0 release.

Step 1. Delete Orphan Data: In this feature, system will find and clean up orphan clips from file system or DB. Orphan data will be identified based on camera configured deletion settings.

Step 2. Drive Feature: In this feature, Drive Full Scan is performed until a new fixed drive is detected in NVR system. Based on the scan result, data sync up or orphan data clean up process is initiated using the current camera configuration or if the camera is not found then, by default the data after 30 days will be deleted.

For Example: If NVR 1 is down due to some technical issues, then the hard disk of NVR 1 can be used in NVR2. NVR2 initiates the scan, detects the drives and displays the recordings of NVR 1.

- Running on schedule base is same as windows scheduler.
- Has capability to process deleted camera's data for Orphan deletion.

Step 3. Schedule of when to start the service can be configured.

Step 4. Allows Neo to recycle data first (since by default it deletes clips with retention period + 24 hours)

## New Equip 1080p and 4MP Camera Integration

Step 1. Configuration is done through Honeywell proprietary ISOM APIs

Step 2. After integrating the new Equip Camera, system will be able to perform the following

- H.264, H.265 and MJPEG coded support
- HTTPS support

Step 3. New events supported: With the Equip series camera integration the following events are generated.

- Abandoned Object detection
- Object Missing detected
- Trigger Line detection

The following Equip series Camera models are supported using ISOM API's

#	Camera Model	Description	Firmware Details
1	H4L2GR1V	2MP Lowlight outdoor dome	Version: 1.000.0000.10, Build Date: 2018-05-29
2	HBL2GR1V	2MP Lowlight IR bullet	ISOM Version 1.2.1_Build 20180529 VA Package
3	HCL2GV	2MP Lowlight box camera	Version: 1.0.8_build20180529

#	Camera Model	Description	Firmware Details
4	H4W2GR1V	2MP WDR outdoor dome	
5	H4W4GR1V	4MP WDR outdoor dome	
6	HBW2GR1V	2MP WDR bullet, 2.7-13.5mm	Version: 1.000.0000.9, Build Date: 2018-05-25
7	HBW2GR3V	2MP WDR bullet, 5-60mm	ISOM Version: V 1.2.1_Build 20180524
8	H3W2GR1V	2MP WDR indoor dome	
9	H3W4GR1V	4MP WDR indoor dome	
10	HCW2GV	2MP WDR box camera	
11	H2W2GR1	2MP Pancake camera	

## RTSP H.265 Support

- Any H.265 URL can be added and streamed with Generic-RTSP streamer name.

## Enhancements in MAXPRO Mobile APP

- Introduced new Mobile app versions
- For Andriod: 1.3.0 (100030004)
- For IOS: 1.3.0 (100030001)
- New Supported OS: minSDKVersion = 21
- Finger Print Authentication is supported for Android version of MAXPRO Mobile app. However, this feature is available on Fingerprint supported devices.

### Limitation with Privacy Protection Settings

- If Anonymization is enabled in NVR application, then user will not be able to see the video in MAXPRO mobile app/Web client. An error message is displayed.
- If Four Eye Authentication option is enabled in NVR application then user will not be able to view playback video in MAXPRO mobile app/Web client.

## Grand Eye New Evolution support

EVO18 0 and EVO12

## Industry Standards

MAXPRO NVR is an open platform and supports broad third party device integrations with support for PSIA and ONVIF Profile S standards, Real Time Streaming Protocol (RTSP) standard and native device integrations.

## Flexible Licensing

MAXPRO NVR comes with all required software applications and licenses.

## Role Based Operator Privileges

MAXPRO NVR offers role-based operator privileges supporting Windows and Local users. You can add up to 1024 users under the Users tab.

## Easy Configuration

A quick and easy 3-click\* wizard to set up the system with auto-configuration and auto-discovery of IP cameras, recording and monitoring configuration, makes installing HD IP systems quick and efficient without requiring any IP expertise. Simple and logical configuration pages make setup a breeze, even for the novice installer.

\* - With default settings and in a local area network for specific models.

## 64 channel Support

MAXPRO NVR (SE, PE), Hybrid NVR (SE, PE) and Software only solution now support 64 channels. You can connect up to 64 cameras based on your type of solution.

## Auto Discovery

Discovering the IP cameras in the network is now simpler with the enhanced auto discovery interface. You can define the IP range to search for the cameras in the network and also camera credentials can be set at once for the newly discovered cameras.

## MultiStream

MAXPRO NVR provides you with the flexibility to add multiple streams with different resolutions on a single camera. Depending on the type of camera you can add and configure additional streams and can define the Video Quality Settings, Recording Settings, and Stream Preference settings. Based on your requirements you can view or render different resolutions on a single camera. It also allows you to set various parameters for your recording, including audio.

## Third Party ONVIF Profile G supported cameras:

Following new Third Party ONVIF compliance Profile-G cameras are now supported in NVR 4.7.

Profile G Cameras	Camera Type	Firmware Details
Tyco	ADCi350-B111	V3.1.0 170215
Samsung	QNO-7010R	1.04_170224
Panasonic	WV-SFV631L	2.41

## MAXPRO Web Configurator

Enhanced the Web configurator user interface with new themes, for a better user experience while configuring the System, Server and Security configurations for Web client and mobile.

## New Deletion Schedule

Introduced new deletion schedule where user can now retrieve the recordings of the last 5 years.

## GPU Rendering Support

Cost-effective enhanced HD video rendering on remote desktop clients with support for monitoring of up to 18 1080p HD cameras in real time (30 fps) with no-time-lapse using the GPU capabilities of built-in processor graphics with Intel® 4th generation and above processors. This feature allows a user to render high resolution cameras while optimizing the CPU consumption. To know about improvised GPU rendering capability, see [Improved GPU Rendering](#) section on page 242 section.

## Analog Capture Card Support

MAXPRO NVR Hybrid supports an Analog Capture card through which you can manually add 16 analog cameras. Each capture card comes with 16-channel support and allows you to manage the analog cameras.

## User-Friendly and Feature-Rich User Interface

The MAXPRO NVR user interface is based on Honeywell's flagship MAXPRO® VMS user interface which offers a feature-rich user experience. Utilization of this familiar interface allows for the "Learn One, Know Them All" concept that ensures familiarity across a broad range of Honeywell products.

## MAXPRO Status Monitor

MAXPRO Status Monitor is a brand new application in NVR V4.0 release that helps you to search and monitor the NVR's (System or Recording Engine) in the current network. You can monitor a single system/recording engine or multiple systems/recording engines at once. This application is installed along with the NVR 4.0 software update and can be accessed on the desktop.

You can manually add or auto search for NVRs and then connect to a single or multiple NVRs (System or Recording Engine) to monitor the status of various parameters.

For a system you can monitor parameters such as CPU Consumption, Average Disk Queue Length, Disk Write/Read and so on, depending upon the NVR connected.

For a Recording engine you can monitor parameters such as Total FPS Received/Recorded, Total Bitrate Received/Recorded, Total Active Cameras and so on.

## Recording and Playback Operations

MAXPRO NVR supports simultaneous recording, live and playback viewing, search and system management of all supported IP cameras including HD formats in a single server instance.

## On Demand live Streaming (VOD)

On Demand Live Streaming feature allows you to configure and store recordings at camera level. Later the recordings at the camera level can be synchronized back to view in NVR viewer. This avoids persistent stream recording. MAXPRO NVR configured as On Demand Live Streamer streams video from camera, only when a client request a live stream for viewing. When all the clients close the particular camera, then streaming from the camera is stopped.

The NVR configured as On Demand streamer supports only Sync back edge recording.

On Demand live streaming is compatible from MAXPRO NVR Viewer, MAXPRO NVR Web Clients and MAXPRO NVR Mobile app clients.

In your PC, by default On demand Live Streaming registry value is set to zero (disabled). User needs to change the value to 1 to use this feature. See [How to Enable Video on demand feature in MAXPRO NVR](#) section for more information.

Recording support in On Demand video Streaming: It is also an add-on for the existing Edge Sync Recording feature. This feature helps user to enable recording during on demand video streaming. A check box is introduced in Configurator > System tab to enable this feature. Earlier only live video was supported.

## Profile-G or Edge Sync Support

Profile-G or Edge Sync feature allows you to synchronize the recordings from the camera SD card to NVR. Camera SD card contains recordings that are configured on demand. This feature enables the user to playback only those recordings which are saved on demand in the SD card. User can enable the edge sync feature in Camera page and configure the day and time for synchronizing in System window to get the recordings from the camera. Edge Sync feature is applicable only to the cameras with SD card. This feature is supported only for New EquiP Series model cameras.

Automatic Retry clips is an add-on for the existing Edge Sync Recording feature. This feature is meant to retry and download the failed clips. It allows user to configure various parameters in the config file to avoid clips download failure. If any clip fails to download then based on the user configuration auto retry feature downloads the clips to NVR.

## Low bandwidth Stream Settings:

Use Low Resolution Stream: This feature is to view the low resolution video in any format of salvo layout. User needs to configure the low resolution (for any Primary or secondary stream) in MAXPRO NVR camera page. For the following scenario under which you can use this option:

- For a specific site if you want to use the Low Resolution stream option then you need to configure the stream settings in the camera tab. See [Recommendation to use Low bandwidth stream option](#) section for more information.

**Note:** *If you want to set the bit-rate value for a low bandwidth site then you can set this value in the camera web page*

Receive Only I Frame/Low Bandwidth Streaming: This feature is applicable only for the sites with Low bandwidth. It allows user to receive and view only I Frame considering the bandwidth at the site. This feature is only supported for MAXPRO NVR.

Use Extended time Outs: This helps in increasing the default time outs for NVR connections, stream connections and snapshots retrieval. This feature is only supported for MAXPRO NVR.

## Optimize Stream Usage Settings:

Enable Stream Switch: Enable stream switch automatically switches between low and high resolution streams in the salvo layout based on the users selection. User should have minimum two streams available to use this feature. By default camera will stream in high resolution video in single salvo layout and the same camera when it is drag and dropped in multiple salvo, it streams with low resolution video. This feature is only supported for MAXPRO NVR.



## Enriched Video Viewing Experience

MAXPRO NVR offers an enriched video viewing experience through the intuitive video rendering engine that optimizes CPU utilization by altering the video frame rate.

## Efficient Event and Alarm Viewing Capability

MAXPRO NVR provides the ability to investigate events and alarms by simultaneously viewing alarm videos at various stages. For every alarm, users can view the video captured during pre-alarm, on-alarm, and post-alarm, and also view live video from the camera which triggered the alarm.

## Simultaneous Video Recording and Video Viewing

MAXPRO NVR supports multiple simultaneous operations such as video recording and video viewing or alarm monitoring on the server unit without the need for an additional workstation. It also provides the option of remote monitoring clients. You can view live video while simultaneously performing searches.

## Video Motion Detection (VMD) Support

MAXPRO NVR supports both camera-based and server-based video motion detection (VMD). Camera-based VMD support depends on the integration method and the motion detection performance depends on camera analytics. Server-based VMD (SMART VMD) is supported for all video devices supported by NVR, and is based on Honeywell Active Alert analytics algorithms supporting object-based motion detection with reduced false alarms.

## Search

MAXPRO NVR supports multiple search features: Timeline Search, Preview Search, Alarm/Events Search, Calendar Search and SMART Motion Search.

## SMART Motion Search

SMART Motion Search feature allows you to search for a missing object by searching on motion in recorded video within a short span of time. This feature overcomes the traditional way of searching an object in recorded videos. It also provides you with before and after recordings of a missing object.

## 360 Immersive Experience (Dewarping) Support

MAXPRO NVR supports client side dewarping integration with Oncam Grandeye and Immervision 360 applications.

## New EquiP Series Camera Models Support

Additional 8 new EquiP camera models are now supported (HFD6GR1, HSW2G1, HCD8G, HBD8GR1, H4D8GR1, HDZ302DE, HDZ302D, HDZ302DIN). In addition the following are the advanced features that are offered through these cameras:

- Intrusion trace (Need to purchase separate license to enable this feature in camera)
- Face Detection
- Audio Detection (For cameras with Built-in Microphone or External Microphone)
- SD Card Failure

## New high performance and specialty EquiP Camera Support

- HM4L8GR1: 8 MP IR Rugged Multi-Imager Dome
- HMBL8GR1: 8 MP IR Rugged Multi-Imager Bullet
- H4L6GR2: Low-Light 6 MP IR Rugged Dome
- HBL6GR2: Low-Light 6 MP IR Rugged Bullet
- HEPB302W01A04: 1080p 30x Explosion-Proof IP Camera, 4 m cable
- HEPB302W01A10: 1080p 30x Explosion-Proof IP Camera, 10 m cable
- HTMZ160T302W: Dual Sensor Thermal/Visual IP PTZ Camera

## 3D Positioning

3D Positioning feature enables you to view a specific object in a live video in 3-dimensional view. On a live video you need to draw a region to view a specific object. This feature is supported only with New EquiP PTZ (HDZ302DE, HDZ302D, HDZ302DIN) camera models.

## New EquiP Camera Model Dewarping

New EquiP FishEye Camera (HFD6GR1) is capable of delivering FishEye view of the surrounding and which can also be Dewarped to different view types depending on the mounting position.

## H.265 Codec Support

H265 codec type is now supported to optimize the storage requirements for higher resolution cameras. H265 is only supported for New EquiP model cameras (HFD6GR1, HSW2G1, HCD8G, HBD8GR1, H4D8GR1, HDZ302DE, HDZ302D and HDZ302DIN). H.265 cameras supports GPU based Rendering. Now you can render upto 23 H.265 cameras with 1080P Resolution at 30 FPS/30 GOP.

Limitations of H.265 Codec Type:

- H.265 is not supported in MAXPRO Mobile app

- H.265 is not supported in Web client

## Meta Data Conversion Utility

Meta data conversion utility allows you to replace or update the unique system ID number of the recorded clips and Meta data details for all or specific cameras. This utility helps you to retain your recorded clips and Meta data details during Failover /Failback operations. This allows a user to effectively playback the recorded clip without loss of video.

## Multi-language Support

MAXPRO NVR supports multiple languages such as English, French, Arabic, Russian, Spanish, Italian, Dutch, German, Czechoslovakian, Portuguese and Polish. English is the default language.

## Keyboard Support

MAXPRO NVR supports industry standard Honeywell keyboards connected over Ethernet such as UltraKey Plus and UltraKey Lite

## Clip Export

MAXPRO NVR supports exporting clips with audio in - WMV, ASF and Honeywell MPVC formats. It also supports exporting still images/snapshots in .BMP format. The clips can be signed with digital signatures to ensure authenticity.

## MAXPRO NVR Clip Player

MAXPRO NVR Clip Player is a Honeywell proprietary clip player designed to only playback exported MAXPRO Video Container format (MPVC) clips. This clip player is part of the NVR 4.0 package and can be accessed in the NVR installation folder.

## Email Notification

MAXPRO NVR supports email notification on camera, system and operator events.

## Video Surround Feature

MAXPRO NVR offers Video Surround, which provides the ability to track subjects of interest as they move between areas covered by adjacent cameras. Simply double-click on the panel where the subject is currently visible to track the subject.

## Profile Cameras

Multi-zoom views on HD video and support for Profile cameras to create virtual cameras by digitally zooming into the field of view. Example: Zoom in on a cash register in one view of the HD camera and at the same time monitor the cash operator in the zoom out view of the HD camera

## Reports

Using the MAXPRO NVR, you can generate Event History and Operator Log reports, each of which has its own significance. These reports can be exported in PDF, Crystal Reports, Excel and Word formats.

## Integration Capability

Multiple MAXPRO NVRs can be deployed for system expansion using a distributed architecture and integrated with the MAXPRO Viewer multi-site software or MAXPRO VMS enterprise video management system. MAXPRO also integrates with WIN-PAK® and Pro-Watch® Access Control Systems.

## Audio

MAXPRO NVR supports 1-way audio (camera to NVR) for specific IP cameras. Please refer to the MAXPRO NVR compatibility list at [www.security.honeywell.com/hota/compatibility/index.html](http://www.security.honeywell.com/hota/compatibility/index.html) for the models supported.

## Web Client

The MAXPRO NVR Web Client allows you to remotely access the MAXPRO NVR server using a web browser like Internet Explorer and perform video surveillance. It gives you the flexibility to view live video and perform the basic video surveillance functions remotely over the web. MAXPRO NVR Web Client supports viewing the live video, viewing Recorded Video (Playback), taking a Snapshot and viewing Presets.

## Archival

This feature enables you to archive the recorded video from the system manually or automatically to a NAS or SAN disk. You can define a specific schedule to archive the recordings periodically or you can manually archive whenever required. For both cases you should configure the archival disk/drive in the Configurator > Disk tab. To configure NAS for recording, see [Guidelines to configure NAS Drive for Recording](#) section on page 245 for complete information.

## Mobile Apps

MAXPRO NVR supports mobile monitoring clients on iOS and Android with MAXPRO NVR Mobile apps. The apps can be used to perform common daily tasks such as viewing live video, zooming in for full screen viewing, playback or searching for video by date and time, perform PTZ control through presets, monitor & manage alarms and taking a snapshot of a video frame. Recent enhancements also include One configuration for both Local and Remote server connection, Fingerprint Authentication login is support (only for IOS devices), Digital Zoom (only for IOS devices), HIS Streaming and HTTPS support

## Advanced Security


MAXPRO NVR supports advanced security features with encryption support for communication between desktop client to NVR and secure https login for the Web Client and Mobile App.

**Note:** Honeywell recommends you to use a valid certificate from a Certificate Authority that would ensure robust security along with integrity and authenticity, instead of using self-signed certificate. Refer to the 800-23557-E - Securing MAXPRO VMS\_NVR Technical Notes for security settings.

# MAXPRO NVR Typical System Architecture

## MAXPRO NVR Standalone System Diagram

The following figure illustrates the MAXPRO NVR SE system architecture.




### MAXPRO NVR SE System Diagram

**Note:** The NVR SE box in the above system diagram is used as an example of a typical system. Other System diagrams for NVRs (XE, PE and Software only) look similar to the NVR SE and will only have minor differences.

# MAXPRO NVR Hybrid Standalone System Diagram

The following figure illustrates the MAXPRO NVR HYBRID XE Standalone system architecture.




## MAXPRO NVR HYBRID XE Standalone System Architecture

**Note:** The Hybrid NVR XE box in the above system diagram box is used as an example of a typical system. Other system diagrams for Hybrid NVRs (SE, PE) look similar to the Hybrid NVR XE and will only have minor differences.

# MAXPRO NVR Distributed System Architecture

The following figure illustrates the MAXPRO NVR distributed system architecture.



**MAXPRO NVR Distributed System Architecture**

This page is intentionally left blank



## Overview of Commissioning Procedure

Commissioning is the process of setting up the MAXPRO NVR system hardware, installing the software and configuring the NVR system. At the end of the commissioning process, the MAXPRO NVR system is equipped for use by operators to perform video surveillance operations.

## Steps in the Commissioning Procedure

The process of commissioning involves the following phases.

- Setting up the MAXPRO NVR system
- Installing the Software in the Server and Client Computers
- Configuring the MAXPRO NVR
- Verifying the Configuration

## Setting up the MAXPRO NVR

Setting up the MAXPRO NVR involves:

- Determining the number of MAXPRO NVR server and client computers at the location.
- Choosing the desired MAXPRO NVR system architecture.
- Connecting the monitors to the MAXPRO NVR. After connecting the monitors, configure the monitor display properties.
- Connecting the keyboards (for example, Ultrakey) to the MAXPRO NVR unit.

See the [Setting up the MAXPRO NVR Turnkey Box Solutions](#) section on page 83 for information on how to setup the MAXPRO NVR XE/SE/PE or MAXPRO NVR Hybrid XE/SE/PE system.

See the [Setting up the MAXPRO NVR Software-Only Solution](#) section on page 89 for information on how to setup the MAXPRO NVR Software installed on a 3rd party Server.

## Installing the Software in the Server and Client Computers

**Note:** Full/Fresh installation is NOT required on Honeywell's boxed solutions: MAXPRO NVR XE, SE, PE and MAXPRO NVR Hybrid XE, SE, PE. Fresh client installation is only required on client computers.

The following steps are involved to install the MAXPRO NVR software on a 3rd party hardware:

- Step 1. The server and client computers meet the minimum hardware and software requirements.
- Step 2. Installing the MAXPRO NVR software.



**Caution: Don't install any Email client on the MAXPRO NVR server machine.**

See the [MAXPRO NVR Software Installation](#) section on page 104 for information on software requirements and installation instructions for the MAXPRO NVR software.

## Configuring the MAXPRO NVR

In this phase, you need to configure the MAXPRO NVR through the user interface. Configuring MAXPRO NVR includes the following:

- Configuring the Honeywell cameras with MAXPRO NVR Wizard
- Configuring the system level settings
- Configuring the disk management settings
- Configuring the schedule based recording for cameras
- Performing user administration

See the [In this chapter...](#) section on page 153 for information on how to configure the MAXPRO NVR system.

## Verifying the Configuration

Verifying the configuration involves checking whether the surveillance operations can be performed using MAXPRO NVR. Surveillance operations include: viewing the live video, performing the pan, tilt, and zoom on the video, and starting the video recording.

See the [Verifying the Configuration](#) section on page 305 for information on how to perform the verification.

# SETTING UP THE MAXPRO NVR

## Overview

This chapter describes the settings for setting up the MAXPRO NVR system.

- For setting up the MAXPRO NVR Single-box solution, see the [Setting up the MAXPRO NVR Turnkey Box Solutions](#) section on page 83.
- For setting up the MAXPRO NVR Software-Only solution, see the [Setting up the MAXPRO NVR Software-Only Solution](#) section on page 89.
- For setting up a peripheral Joystick Controller, see the [Connecting the Joystick Controller](#) section on page 99.


## Setting up the MAXPRO NVR Turnkey Box Solutions

Setting up the MAXPRO NVR unit and client computers is the first phase in the commissioning process.

Refer to the specific [MAXPRO NVR Data Sheet](#) on Honeywell Video web site. ([www.honeywellvideo.com](http://www.honeywellvideo.com)) for information on hardware specifications for the MAXPRO NVR unit.

# Typical MAXPRO NVR System Diagram

The following figure illustrates the MAXPRO NVR SE system diagram.




## Typical MAXPRO NVR System Diagram

**Note:** In the above system diagram NVR SE box is used as an example of a typical system. Other System diagrams for NVRs (XE, PE and Software only) look similar to the NVR SE and will have minor differences.

# Typical MAXPRO NVR Hybrid System Diagram

The following figure illustrates the MAXPRO NVR Hybrid system diagram.



**Typical MAXPRO NVR Hybrid System Diagram**

**Note:** In the above system diagram Hybrid NVR SE box is used as an example of a typical system. Other system diagrams for Hybrid NVRs (XE, PE) look similar to the NVR Hybrid SE and will have minor differences.

See [MAXPRO NVR Hybrid Connections](#) section on page 90 for rear panel connectors to connect analog video source, looping outputs and IOs.

## Connecting the Monitors

Connect one or more local monitors to one of the monitor connections on the back panel of your MAXPRO NVR unit. The number of monitors that you can connect to the MAXPRO NVR unit varies based on the NVR Edition you purchase. Refer to the specific [MAXPRO NVR Data Sheet](#) on Honeywell Video web site ([www.honeywell-video.com](http://www.honeywell-video.com)) for more information.

## Powering on the MAXPRO NVR Unit

**Note:** Honeywell recommends using an Uninterrupted Power Supply (UPS) for the MAXPRO NVR unit and the cameras. Powering the cameras and unit from a UPS ensures that the MAXPRO NVR unit can continue to record video during a power outage or during transient power events. If you need to monitor video during a power outage, consider a UPS for the client workstations as well.

## To power on the MAXPRO NVR unit

- Step 1. Turn on camera(s) and other hardware connected to the MAXPRO NVR unit.
- Step 2. Press and hold the power button on front of the MAXPRO NVR unit. The power button turns “blue” after the MAXPRO NVR unit is turned on.
- Step 3. After powering on the unit, you are prompted to log on. For MAXPRO NVR turnkey units shipped with v4.0 or later version, the default Windows desktop login user has user name: NVR-Admin, password: Password\$123. The user name and password are case sensitive. You will be prompted to create a new password the first time that you log in. After logging on, the MAXPRO NVR Wizard automatically starts up but may take two minutes to initiate.

**Note:** Honeywell recommends to disable the Administrator User account and create a new Administrator User account. See [Securing MAXPRO NVR](#) section on page 299 for more information.

## To turn off the power for MAXPRO NVR

- Step 1. Close the MAXPRO NVR application.
- Step 2. Click Start>Shut Down. Wait for the MAXPRO NVR unit to shut down.

## Changing the MAXPRO NVR IP Address and Machine Name


Your MAXPRO NVR unit has pre-configured network ports with the following default IP addresses:


- 192.168.1.101 for NIC1 (Camera Network)
- 172.25.254.101 for NIC2 (Client Workstation Network)

**Note:** NIC2 may not be available on all NVR options, please refer to the data sheet for more information.

If more than one MAXPRO NVR unit is on the same network, you must assign a unique IP address and computer name to each unit (the default name is MAXPRO-NVR).


## Changing the IP address

- Step 1. Click the network icon  in the notification area, click Open Network and Sharing Center (See [Typical MAXPRO NVR Hybrid System Diagram](#)), and then click Change adapter settings.



### Network and Sharing Center

- Step 2. Right-click Camera Network or Client Workstation Network, and then click Properties. The Local Area Connection Properties dialog box (Similar to [MAXPRO NVR Software Solution Distributed System](#)) appears.



### LAN Properties

- Step 3. Click Internet Protocol Version 4 (TCP/IPv4), and then click Properties.
- Step 4. Click Use the following IP address, and then, in the IP address, Subnet mask, and Default gateway boxes, type the IP address settings.

- Step 5. Click Use the following DNS server addresses, and then, in the Preferred DNS server and Alternate DNS server boxes, type the addresses of the primary and secondary DNS servers.

## Changing the computer name

- Step 1. Click Start, right-click Computer, and then click Properties. The System window appears.
- Step 2. Click Advanced system settings. The System Properties dialog box appears.
- Step 3. Click the Computer Name tab, and then click Change...
- Step 4. In Computer name, delete the old computer name, type a new computer name, and then click OK. The name cannot contain spaces or all numbers or any of the following characters: < >; “ \* + = \ | ?.
- Step 5. After changing the computer name, you are prompted to restart the computer.
- Step 6. Navigate to the C:\Program Files\Honeywell\MaxproNVR\TrinityFramework\bin folder, and then double-click MaxProNVRMachineNameUtility.exe to open the Maxpro NVR Utility.
- Step 7. The new computer name automatically appears in the Machine Name field. If it does not, enter the name manually and click Update. The message `Machine Name Updated Successfully` appears when the update is complete.

## Configuring the Monitor Display Properties

The recommended display settings for the monitor are dialog box resolution of 1280 x 1024 pixels and color quality of 65K colors non-interlaced. The display settings can be configured from the Windows control panel or from the Windows desktop through the context menu.

### Configuring Display Settings for the Context Menu

- Step 1. Right-click on the Windows desktop and select Screen resolution.
- Step 2. Select the appropriate Resolution.
- Step 3. Click OK to save the setting and close the dialog box.

### Configuring Display Setting from the Control Panel

- Step 1. Click Start > Control Panel, to open the Windows control panel screen.
- Step 2. Under Appearance and Personalization, click Adjust screen resolution.
- Step 3. Select the appropriate Resolution.
- Step 4. Click OK to save the setting and close the dialog box.



# Setting up the MAXPRO NVR Software-Only Solution

Setting up the MAXPRO NVR server and client computers is the first phase in the commissioning process.

## Before you Begin

Determine the following at the location.

- Number of server and client computers required.
- Hardware configuration of the computers.
- Number of peripheral devices such as joystick controllers (Ultrakey keyboard), and other devices that are needed.

## Hardware Specifications

The MAXPRO NVR server and client computers must meet the minimum hardware specifications, refer to the [MAXPRO NVR Software Data Sheet](#) for more information.

## MAXPRO NVR Software System Architecture


MAXPRO NVR software solution can be set up in the following two ways:

- Standalone System
- Distributed System

Corresponding system architectures are displayed below

### MAXPRO NVR Software Solution Standalone System


The following figure illustrates the MAXPRO NVR Standalone system.



**MAXPRO NVR Software Solution Standalone System**

# MAXPRO NVR Software Solution Distributed System

The following figure illustrates the MAXPRO NVR Distributed system.




**MAXPRO NVR Software Solution Distributed System**

## MAXPRO NVR Hybrid Connections

### Rear Panel Connectors

The rear panel of the NVR contains the connectors used for attaching cameras, sensors, and relays to the NVR. Below are the diagrams that outline the location and connections of Hybrid XE, SE and PE connectors and also the Input and Output Ports For MAXPRO NVR Hybrid PE.

# Hybrid XE Connections




#)	Connector)	Connects to...)
1)	AC Power)	Electrical outlet)
2)	Video Inputs)	Analog cameras)
3)	VGA Port)	VGA monitor)
4)	DVI-D Port)	DVI monitor)
5)	Display Port)	DP monitor)
6)	HDMI Port)	HDMI monitor)
7)	LAN1 - Camera Network Port)	Network)
8)	USB Ports (x4)	Various devices)
9)	LAN2 - Client/Workstation Network Port)	Network)
10)	S/PDIF (Optical)	Not supported)
11-15)	Audio Inputs and Outputs)	Line in - line level)
)	)	Speaker out)
)	)	Microphone in - not used)
16)	Control Outputs)	
17)	Alarm Inputs)	
18)	Video Out Port 1-8)	Analog camera looping output)
19)	Termination Resistor)	*)
20)	Video Out Port 9-16)	Analog camera looping output)
21)	Termination Resistor)	*)
22)	RCA Connector)	Spot monitor (RCA)
23)	Audio 1-16)	Not supported)
24)	RS485)	PTZ device **)
25)	Power Switch)	

\*) ON position when the looping outputs are not used.)

\*\*) An analog PTZ device must be configured to use COM5 port (see [Third Party IP Device and Analog Camera Configuration](#)).


### Hybrid XE Connections

# Hybrid SE Connections



## Hybrid SE Connections


## Hybrid PE Connections



#	Connector	Connects to...
1	AC Power (x2)	Electrical outlet
2	VGA Port	VGA monitor
3	DVI-D Port	Monitor
4	Display Port	Monitor
5	HDMI	Not supported
6	LAN1 - Camera Network Port	Network
7	LAN2 - Client Workstation Network Port	Network
8-11	USB Ports (x4)	Various devices
12-16	Audio inputs and outputs	Line in - line level Speaker out Microphone in - not used
17	S/PDIF (Optical)	
18	RAID Management Port	RAID device
19	Video Input 1-8	Cameras
20	Video Input 9-16	Cameras
21	Not used	
22	RS485	PTZ device *
23	Input and Output Ports	Alarm inputs and Control outputs

\* An analog PTZ device must be configured to use the COM4 port (see [Third Party Device Configuration](#)).

## Hybrid PE Connections




## Input and Output Ports For MAXPRO NVR Hybrid PE

### Connecting a Video Source

There are different types of Video Sources that can be plugged into the NVR including DVD players, VHS players, and CCTV Cameras. Hybrid XE, SE and PE support 16 channel analog video source. The connectors use the BNC standard.

#### 16 Channel




### Connecting a Video Source

**Note:** The video inputs are 75  $\Omega$  BNC connectors. Plug one end into the video source (DVD, Camera, etc.) and plug the other end into the desired BNC input on the NVR.

## Looping Output Termination

If the image appears distorted or virtually un-viewable, turn the termination resistor to the ON position, making it terminated. When it is necessary to terminate a looping output, the NVR has built-in termination that allows users to select individual outputs. It is not always necessary to terminate the output; it depends on the device to which you are connecting. As a rule, if the image appears distorted or virtually un-viewable, it likely needs to be terminated.

**Note:** Please refer to the specific Hybrid unit data sheet for more information on number of looping outputs supported on a specific unit.




### Looping Output Termination

**Note:** Always leave the dip switch set to the ON position when the Looping Outputs are not used and only the installer should decide to turn it ON /OFF.



## Connecting Control Outputs

Each NVR Hybrid has Control Outputs. These outputs can be used to trigger devices such as Sirens, Phone Dialers, Lights, and any other relay activated device. There is no power supplied to the ports. Use an external power supply if necessary.



### Control Outputs

Use 12V, below 300mA. For controlling lights or other devices, use another external relay.


- Maximum voltage is 24V AC @ 1 amp
- Output uses a Form C Relay

**Note:** Please refer to the specific Hybrid unit data sheet for more information on number of control outputs supported on a specific unit.

## Connecting Sensors

Each NVR Hybrid has Sensor inputs. These inputs can be used with devices such as infrared devices, motion device, glass breakage alarms, door and window trips, and so on. The Sensors can be set to Normally Open or Normally Closed inside the software.

There are Common Grounds (-) and sensor inputs (+). There is no power supplied to the ports so an external power supply must be used if power is necessary.




### Connecting Sensors

**Note:** Please refer to the specific Hybrid unit data sheet for more information on number of sensor inputs supported on a specific unit.

## Connecting an Analog PTZ Camera

Setting up a PTZ Camera is simple. The NVR Hybrid comes pre-assembled with an internal PTZ adapter. The cabling may be run up to 4,000 ft using 22 Gauge Twisted Pair. It is important to understand how the PTZ connects to the NVR. The NVR outputs an RS-232 signal and converts in to an RS-422/485 signal which is then sent to the PTZ camera.

### Attaching the 4-Pin Adapter



4-Pin Adapter

Step 1. Locate the PTZ adapter cable.

Step 2. Connect the wires of the PTZ adapter to the PTZ camera. The yellow wire should connect to the RX+ on the camera and the orange wire should connect to the RX-.

Step 3. Connect the other end of the adapter to the XVR unit as shown.

Step 4. Assign the PTZ camera an ID number in PTZ Setup that coincides with the number assigned to the camera. This is normally done utilizing a dip-switch configuration method on the addressable dome. For Example: If the camera is plugged into input number 5, set the PTZ unit to ID number 5.

# Connecting the Joystick Controller

Joystick Controllers (UltraKey Plus or UltraKey Lite over Ethernet) can be connected to MAXPRO NVR without any configuration.

Honeywell UltraKey joystick controller is an industry-leading approach to intelligent, user-friendly control of video management systems. Using the UltraKey keyboard, you can perform actions such as selecting a panel, PTZ operations, selecting a video source such as a camera, and others in the Viewer tab.

## Connecting a Joystick Controller to MAXPRO NVR

To connect a Joystick Controller to MAXPRO NVR

- The UltraKey can be connected through the Ethernet. Set the UltraKey IP Address and System Controller (IP Address of MAXPRO NVR) through the UltraKey configuration settings. Refer to the [UltraKey manual](#) for more information.

## How to log on to the UltraKey Plus keyboard?

First time users of MAXPRO NVR must explicitly log on to UltraKey Plus keyboard in order to use MAXPRO NVR.

- Step 1. Power-on the UltraKey Plus keyboard.
- Step 2. Press the Menu key on the LCD.
- Step 3. Press the MAX-1000 Setup key on the LCD. The Left, Up, Right, and Down buttons appear on the LCD.
- Step 4. Press the Ent hard key located on the right side of the UltraKey Plus keyboard.
- Step 5. Enter the default PIN password 1234.
- Step 6. Press Ent. The UltraKey Plus keyboard is now ready for use for performing the video management functions.

## How to log off from the UltraKey Plus keyboard?

- Step 1. Press the Menu key on the LCD.
- Step 2. Press the MAX-1000 Setup key on the LCD. The Left, Up, Right, and Down buttons appear on the LCD.
- Step 3. Press the Down key.
- Step 4. Press the Ent hard key twice located on the right side of the UltraKey Plus keyboard. The log off confirmation message appears.
- Step 5. Press the Ent hard key.

## NetBIOS Naming Convention Limitations

This section describes the naming conventions for computer accounts in Microsoft Windows, NetBIOS domain names, DNS domain names, Active Directory sites, and organizational units (OUs) that are defined in the Active Directory directory service.

### For MAXPRO NVR

In remote connection scenario, the NVR Hostname will be more than 15 characters. However, NetBIOS naming convention supports only 15 characters for hostname.

- If user is trying to connect to a database and if it failing, then ensure that the hostname of the computer is not more than 15 characters.

Refer the following Microsoft web page of more details on NetBIOS limitations.

<https://support.microsoft.com/en-us/help/909264/naming-conventions-in-active-directory-for-computers-domains-sites-and>

# INSTALLING THE NVR SOFTWARE

## Overview

This chapter describes the procedures for installing the MAXPRO NVR software. Follow the appropriate section in this chapter to complete your MAXPRO NVR software installation.

**Caution:** For Honeywell's turnkey box solutions, MAXPRO NVR XE/SE/PE and MAXPRO NVR Hybrid XE/SE/PE, the server and client software required is pre-installed on the box. The instructions in this chapter for Server software fresh installation are NOT applicable for the turnkey box solutions. On the NVR and Hybrid NVR box solutions, only the installation upgrade process might apply depending on the existing software version on the unit. For client workstations, the client installation procedure is applicable.

## Before you Begin

The client and server computers must meet the hardware and software specifications listed in the respective NVR Data Sheet.

## MAXPRO NVR Software - Operating System Prerequisites

Before you install Honeywell MAXPRO NVR software, please note the MAXPRO NVR Server and Client operating system requirements listed in the following section.

- MAXPRO NVR Server

The computer that is designated as the server must run on one of the following operating systems:

- Microsoft® Windows® 8.1 Professional 64-bit or Windows 10 Professional 64-bit must be installed on the NVR before installing MAXPRO NVR software.

- Microsoft® Windows® Server 2008 R2 Standard, Service pack 1 or Windows Server 2012 R2 Standard or Windows Server 2016 must be installed on the NVR before installing MAXPRO NVR Software.
- MAXPRO NVR Client Workstation


The computer that is designated as the client workstation must run on one of the following operating systems:

- Microsoft® Windows® 7 Professional 32-bit / 64-bit, Service pack 1 or Windows 8.1 Professional 32-bit/64-bit or Windows 10 Professional 32-bit/64-bit must be installed on the workstation before installing MAXPRO NVR client software.

Please refer to the *Microsoft® Windows Patches Tested with MAXPRO®NVR* document for further details on Windows updates that have been tested with the current software version shipping with MAXPRO NVRs.



## Before you Begin - Windows Updates

If Windows updates are enabled in your system, then [Figure](#) warning message appears and the installation continues.



### Automatic Windows Update Enabled Warning Message

If any pending reboot is there due to windows updates, then [Figure](#) error message appears, and the installation stops. Please ensure that you reboot your computer after the Windows updates are finished.



### Pending Reboot Error Message

**Note:** Ensure that *services.msc* console is closed before Installing or upgrading the MAXPRO NVR.

## Before you Begin - Disable Defragmentation

Before starting the installation of MAXPRO NVR, it is recommended that you disable Defragmentation.

- Step 1. Click Start -> Run -> type DFRGUI.
- Step 2. In the Disk Defragmenter dialog click Configure Schedule
- Step 3. Click to clear the Run on the schedule (recommended) check box.
- Step 4. Click Start, (Right-click) Computer-> Manage, select Task scheduler ->Task scheduler library -> Microsoft -> Windows -> Defrag. Right-click on the ScheduleDefrag and then select Disable.
- Step 5. Perform the following steps to make changes in the Registry Settings to disable defragmentation at boot time:
  - a. Open the Registry Editor. Navigate to HKEY\_LOCAL\_MACHINE> SOFTWARE> Microsoft> Dfrg> BootOptimizeFunction.
  - b. Right-click on the keyword "Enable" and then click Edit.
  - c. In the Value Data field type, N and then click OK.
  - d. Right-click on the keyword "Optimizecomplete" and then click Edit.
  - e. In the Value Data field, replace Yes with No. (case sensitive) Click OK.
  - f. Close the Registry Editor. The changes take effect when Windows is restarted.

## Before you Begin - Disable Volume Shadow Copy, Windows Backup Services

- Step 1. Turn off the Protection settings for all the drives including OS installed drive in My Computer -> Properties -> Advanced System Settings -> System Protection tab.
- Step 2. Select the drive under Protection settings and click Configure.
- Step 3. Under Restore Settings select Turn off system protection and click OK.

## Before you Begin - Changing the default Windows Administrator Account Created By NVR

Honeywell recommends to login with new Administrator user account for installing MAXPRO NVR. To create a new Administrator user account and to disable the default Administrator account, perform the following two steps as explained in:

- [Step 1: Create a new user account with administrator privileges, page 300](#)
- [Step 6: Disable the Administrator Account, page 304.](#)

## Before you Begin - Installed SQL Service Pack on older SQL Server versions

Install the SQL Service Pack on older SQL Server versions (any SQL version below 2016) to work with MAXPRO VMS. Refer to the [800-26010-A - Securing MAXPRO VMS-NVR Technical Notes](#) for more information.


# MAXPRO NVR Software Installation

To complete the MAXPRO NVR software installation follow the procedures in these sections:

- Step 1. First complete, [How to Install MAXPRO NVR](#)
- Step 2. Choose the installation that best suits your requirements, and follow the appropriate steps.
  - **Full Installation:** Full installation can be selected to install the Server and Client on the same system.
  - **Client Installation:** Client installation can be selected to install MAXPRO NVR desktop client on the client workstations.


## How to Install MAXPRO NVR

1. Insert the MAXPRO NVR 6.7 DVD in the DVD drive. The setup runs automatically. If the setup does not run automatically, browse the DVD drive, and double-click setup.exe. A message box appears as shown below.




2. Click Yes to validate the setup files are not corrupted before continuing the installation and click No to skip the validation to continue the setup. The Welcome installation wizard appears as shown below.







3. Click Next. The License Agreement screen appears.



4. Read the license agreement, and then select I accept the terms of the license agreement. Click Next, the Customer Information screen appears.



5. Type your Registered To name.
6. Type your Company Name.
7. Click Change if you want to change the destination folder, and then select the folder where MAXPRO NVR must be installed.
8. Click Next. The Choose Installation Type wizard is displayed.



9. Select the Client Installation or Full Installation as it applies to your system installation.

### Select Features to Install

<p><b>Full Installation</b> Note: Full Installation is only needed for Software solutions.</p>	<p>Installs Trinity Framework, MAXPRO NVR Recording Application, MAXPRO NVR Database Application, Mobile App Application, Analytics Application and MAXPRO NVR Client on the same computer. See the <a href="#">See "Full Installation" on page 107</a> for more information.</p>
<p><b>Client Installation</b></p>	<p>Installs Client, Trinity Framework, and Adapters. See the <a href="#">See "Client Installation" on page 114</a> for more information.</p>

## Full Installation


MAXPRO NVR 6.7 Full installation can be selected to install the Server and Client on the same system.

**Note:** *Full Installation is only needed for Software solutions. Don't install any Email client on the MAXPRO NVR server machine.*

#### To perform a full installation

1. Perform steps 1 through 9 of [How to Install MAXPRO NVR](#), and then select the Full Installation option in the Choose Installation Type screen appears.
2. Click Next. The Choose Installation Type screen appears.
3. You have two options to choose from:


- Fresh Installation: Select this option if you are installing MAXPRO NVR for the first time and then click Next. The SQL Login screen appears.  
Or
- Upgrade Existing Installation: Select this option if you want to retain/restore the configuration settings from a backup of the previously installed version of MAXPRO NVR and click Next. The SQL Login screen appears.




4. Click Browse, and then select any existing SQL database server instance, such as the existing SQL database server instance on the same network. If you do not want to select an existing database server instance, proceed to step 5.
5. Select Connect using option as Windows authentication or SQL Server authentication. If you select SQL Sever authentication, type the Log on ID and Password.

**Note:** *If you are installing MAXPRO NVR on a new computer that does not have SQL Server 2012 Express installed, you will be prompted to install it. Follow the on-screen instructions to complete the installation. In addition VC++ 2008 redistributable will be installed as a prerequisite as part of MAXPRO NVR installation. Refer What' New Release Notes for more information on issues.*

6. Click Next. The SQL credentials validation status appears. After successful validation, the Choose Database Location screen appears.




7. There are two scenarios that are possible here, depending on your installation type:
  - For Fresh installation of a MAXPRO NVR Database: The default path where the MAXPRO NVR database is created automatically displays for a MAXPRO NVR database fresh installation. Click Next to use the default path or click Browse to select a new path if necessary and then click Next. The Choose Recording Drives screen appears.
  - To retain the existing MAXPRO NVR Database: The path where the MAXPRO NVR database is saved for a previously installed version of the MAXPRO NVR software automatically displays. Click Next. A message “Trinity Database file already exists. Do you want to retain the database” appears shown below. If you
    - Click Yes. The Localization Support screen appears.
    - Click No. The Choose Recording Drives screen appears.



8. Select the drive check box for the drive on which to save the camera recordings (to use as a video storage drive) and click Next. The Localization Support screen appears.


**Caution: It is recommended that you do not choose the operating system drive for saving the camera recordings (as a video storage drive). Selecting an Operating System drive for video storage can lead to system instability and crash.**




**Caution: By Default, English language will be installed. Please ensure to select all the languages required for your system. If an additional language is required after the installation is completed, the software will need to be uninstalled and installed again.**

**Note:** Only English language will be supported/installed in Beta release.

9. Select the languages in which you want to install MAXPRO NVR and then click Next. The Installation Summary screen appears.



10. If you want to change any settings, click Back, else click Next. When the installation is complete, the following message is displayed. The approximate time for installing the prerequisites and MAXPRO NVR Products displays.



11. Click OK. The Finish dialog appears with the options to Validate and to Finish the installation.
  - Click Validate to verify the installed files on your NVR. If there are no errors then a message appears - Setup has been validated successfully without any error. Click here to view report. If there are errors, the message shows there are errors and the report can be reviewed to identify the error and contact Honeywell technical support if required to correct them on reinstall.
  - Click Finish. The installation wizard starts all the services which may take a few minutes. After the wizard closes, as mentioned in step 10 it is recommended to Restart the system manually for the changes to take effect. If you are prompted to reboot the system then a confirmation message is displayed.
12. Click OK to complete the MAXPRO NVR installation.

## Installing Web Client

By default MAXPRO NVR 6.7 installs the Web Client component on your machine. It also installs the MAXPROWEBConfigurator utility to change or update the system and server configuration. If you want to access the MAXPRO NVR Server using Web Client remotely through a supported web browser then you should install Silverlight on the remote machine.

**Caution: For better security, close the browser upon logout.**

## Prerequisites to access MAXPRO NVR Server through Web Client

The following are the prerequisites to access the MAXPRO NVR server through Web Client:



- Silverlight: Ensure that Silverlight version 5 and above is installed on your machine. If you don't have the Silverlight plug-in on your machine, you can download it from the following Microsoft link. <http://www.microsoft.com/getsilverlight/Get-Started/Install/Default.aspx>

**Note:** *Silverlight plug-in is not supported by Chrome version 42.x or above and Microsoft Edge browser.*

- Web Browsers Supported on Windows Systems: Ensure that at least one of the following supported web browsers are installed on your PC:
  - Internet Explorer version 8 or above
  - Firefox version 15.0.1 or above
  - Chrome version 32.x to 41.x only.

**Note:** *MAXPRO NVR Web Client is only supported for the below Web Browsers on Windows 10 with Silverlight plug-in installed:*

- Internet Explorer version 11 or above
- Firefox version 40 or above


**Caution: For better security, close the browser upon logout.**

- Web Browsers Supported on MAC systems: Not supported.

## Client Installation


MAXPRO NVR 6.7 Client installation gives you an option to install MAXPRO NVR Client on the client workstations.

1. Select Client Installation in Choose Installation Type screen and then click Next. The Client Configuration screen appears.




2. Type the MAXPRO NVR Server name or IP address, and then click Next. The Localization Support screen appears.

**Note:** *If you do not know the server name or if the server is not accessible, then type the local host/computer name. The server name can be changed after the installation in the Client.*




**Caution: By Default, English language will be installed. Please ensure to select all the languages required for your system. If an additional language is required after the installation is completed, the software will need to be uninstalled and installed again.**

3. Select the languages in which you want to install MAXPRO NVR and then click Next. The Installation Summary screen appears.



4. If you want to review or change any settings click Back, otherwise click Next. The setup status of various components appears. When the installation is complete, the following message is displayed.



5. Click OK. The Finish dialog appears. Click Finish. The installation wizard starts all the services which may take a few minutes. After the wizard closes, it is

recommended to Restart the system manually for the changes to take effect. If you are prompted to reboot the system then the reboot message is displayed.

6. Click OK to complete the MAXPRO NVR Client installation.

## Uninstalling MAXPRO NVR

To uninstall MAXPRO NVR, choose any of the following uninstall procedures that best suit your requirement.

- Client uninstall
- Full uninstall

### Client Uninstall

Choose this option to uninstall MAXPRO NVR Client components.

To uninstall the client

- Step 1. Go to Control Panel->Programs and Features, select the MAXPRO NVR Client and click uninstall.

Or

Insert the MAXPRO NVR setup DVD in the DVD drive, browse the DVD drive, and then double-click Setup.exe.

Or

Go to the MAXPRO NVR setup folder on your computer, and then double-click Setup.exe. The uninstall wizard starts.

- Step 2. Click Next. The message “Do you want to completely remove the selected application and all of its features” appears. The uninstall status of various components appears.
- Step 3. Click Finish. You are prompted to reboot your computer to complete the uninstall procedure.


### Full Uninstall

The following components are uninstalled: MAXPRO NVR Server and Client components. You can choose the option to retain a backup of database and clip (recording) metadata as per your input during the full uninstall process.


To perform full uninstall

- Step 1. Go to Control Panel->Programs and Features, select MAXPRO NVR 6.7 and click uninstall.  
Or  
Insert the MAXPRO NVR setup DVD in the DVD drive, browse the DVD drive, and then double-click Setup.exe.

Or  
Go to the MAXPRO NVR setup folder on your computer, and then double-click Setup.exe. The uninstall Welcome wizard is displayed.



A message Do you want to completely remove the selected application and all of its feature? is displayed. Click Yes or No as applicable.




Step 2. Click Yes. The Restoring Trinity Database screen is displayed.

Step 3. Click Yes or No as applicable.

- If you click "Yes" and then click Browse to specify a new path for backup location for storing the database. Click Next, the database is retained for future installations of MAXPRO NVR. The uninstall status of various components appears and uninstallation finish screen appears.

- If you click “No” and then click Yes to confirm deleting the Trinity database. The database is deleted. The uninstall status of various components appears and uninstallation finish screen appears.



#### **Installation Finish**

- Step 4. Click Finish. The uninstall wizard closes and you are prompted to reboot your computer.

## **NetBIOS Naming Convention Limitations**

This section describes the naming conventions for computer accounts in Microsoft Windows, NetBIOS domain names, DNS domain names, Active Directory sites, and organizational units (OUs) that are defined in the Active Directory directory service.

### **For MAXPRO NVR**

In remote connection scenario, the NVR Hostname will be more than 15 characters. However, NetBIOS naming convention supports only 15 characters for hostname.

- If user is trying to connect to a database and if it failing, then ensure that the hostname of the computer is not more than 15 characters.

Refer the following Microsoft web page of more details on NetBIOS limitations.

<https://support.microsoft.com/en-us/help/909264/naming-conventions-in-active-directory-for-computers-domains-sites-and>

This page is intentionally left blank



## LOGGING ON AND GETTING STARTED

In this chapter...

Section	See page...
<a href="#">Logging on Using Profiles</a>	<a href="#">page 121</a>
<a href="#">Managing Profiles</a>	<a href="#">page 124</a>
<a href="#">Port Forwarding</a>	<a href="#">page 128</a>
<a href="#">Getting to Know the MAXPRO NVR User Interface</a>	<a href="#">page 130</a>
<a href="#">Setting Preferences</a>	<a href="#">page 134</a>
<a href="#">Licensing Information</a>	<a href="#">page 147</a>
<a href="#">SSA - Software Service Agreement for MAXPRO</a>	<a href="#">page 150</a>
<a href="#">Logging off</a>	<a href="#">page 152</a>
<a href="#">Closing the MAXPRO®NVR User Interface</a>	<a href="#">page 152</a>


## Logging on Using Profiles

The MAXPRO NVR server addresses are saved in profiles. You need to select the profile before logging on. You can set a profile as the default profile. When a profile is set as the default, you do not need to select the profile each time you log on to MAXPRO NVR. You can also modify and delete profiles.

# Logging on to MAXPRO NVR




**Caution:** On Honeywell provided systems shipped with v4.0 or later version, a default Windows user: NVR-Admin with password: Password\$123 is already configured and hence you are automatically logged on. Honeywell recommends you to create and use a new Administrator account to install and logon to MAXPRO NVR. See [Securing MAXPRO NVR](#) section on page 299 for more information. Logon as Administrator only when an administrative activity need to be performed, Operator is preferred for all other activity.

Step 1. Double-click  on the desktop. The Log On dialog box appears.

Or

Click Start -> Programs -> Honeywell -> MAXPRO NVR. The Log On dialog box ([MAXPRO NVR Log on dialog box](#)) appears.



## MAXPRO NVR Log on dialog box

- Step 2. Click the Language option, and then select the required language from the drop-down list. The supported languages (selected during installation) are Arabic, Czechoslovakian, Dutch, Polish, Portuguese, French, German, Russian, Italian, Spanish, Korean and English. The default language is English (US English).
- Step 3. Clear the Windows Logged-In User check box and then enter your Username. The default user name is admin. Honeywell recommends to create a new NVR user (See [Adding a User](#) ) in the Configurator tab and use the same to logon.

Step 4. Type your Password. The default password is trinity.

**Note:** Honeywell recommends you to change the default Password before you logon to MAXPRO VMS. See [Changing the Default Password](#) section to change the password. See [Securing MAXPRO NVR](#) chapter for more details on security settings. See [Password Complexity and Expiry Enhancements](#) section for more information on password setting.

**Note:** Select the Windows Logged-In User check box for logging on using the Windows authentication (uses current logged in Windows account credentials). If the Windows Logged-In User check box is cleared, the MAXPRO NVR user name and password is used for authentication. Ensure that you avoid using the @ character in your password. Logon as Administrator only when an administrative activity need to be performed, Operator is preferred for all other activity.

Step 5. If there is no profile set as default, then select the Profile corresponding to the MAXPRO NVR server to which you want to connect.

**Note:** Set profiles if you have multiple MAXPRO NVRs and use the drop-down to choose which NVR you would like to connect to.

Step 6. Click Login. The Viewer tab appears.

## Tips for Logging on

- Click the Language option, and then select the required language from the drop-down list. The supported languages are Arabic, Czechoslovakian, Dutch, Polish, Portuguese, French, German, Russian, Italian, Spanish, and English. The default language is English (US English).
- Select the Windows Logged-In User check box for logging on using the Windows authentication (uses current logged in Windows account credentials). If the Windows Logged-In User check box is cleared, the MAXPRO NVR user name and password is used for authentication.
- Ensure that you avoid using the @ character in your password.
- Set profiles if you have multiple MAXPRO NVRs and use the drop-down list to choose which NVR you would like to connect to.
- Select the Display Video on Alarm check box to display the viewer as an alarm monitor.


**Note:** Alarm monitor supports pop-up of camera associated to IO events only. Pop-up on motion alarms is not currently supported.

## Changing the Default Password

Honeywell recommends you to change the default password and create a new password before logging on to MAXPRO NVR software. See [Securing MAXPRO NVR](#) for more security settings.

To change the default password:

- Step 1. In the NVR login screen, click Change Password. The Change Password dialog box appears.

A screenshot of the 'Change Password' dialog box. It has a title bar with a close button (X). The dialog contains the following fields: 'Profile' with a dropdown menu showing 'Default Profile(T15-SYS2)', 'User Name' with a text input field, 'Old Password' with a text input field and a lock icon, 'New Password' with a text input field and a lock icon, and 'Confirm Password' with a text input field. At the bottom, there are two buttons: 'Save' and 'Cancel'.

- Step 2. Select the Profile from the drop-down list for which you want to change the password.
- Step 3. Type the Username. For Fresh installation admin is the user name.
- Step 4. Type the Old Password.

**Note:** Old password is blank for Fresh installations. In upgrade scenarios, enter the old password which is configured before upgrading. See [Securing MAXPRO NVR](#) for more security settings. See [Password Complexity and Expiry Enhancements](#) section for more information on password setting

- Step 5. Type the New password. See [Password Requirement](#) .
- Step 6. Type the new password once again to Confirm Password.
- Step 7. Click Save.

## Password Requirement

Ensure that the new password must meet the following requirements.


1. Minimum length – 12 and Maximum length – 20
2. Password should consists one number, one uppercase letter and one special character.
  - a. Number– a digit zero through nine in any script except ideographic scripts.
  - b. Uppercase letter – any kind of letter from any language which has uppercase variant.
  - c. Special character – any kind of punctuation character – any kind of hyphen, dash, opening bracket, closing bracket, quotes, underscore etc


# Configuring MAXPRO NVR Windows/ Desktop Client

## Managing Profiles

### Saving a Server Address in a Profile

To save a server address

- Step 1. In the client workstation, double-click the  icon on the desktop to display the Log On dialog box.
- Step 2. Click Server Settings. The Server Settings dialog box appears ([Server Settings dialog box](#)).




**Server Settings dialog box**


- Step 3. Click Add.
- Step 4. Type the Profile Name to identify the profile.
- Step 5. Type the Server IP/Name (numerical IP address or the network name of the MAXPRO NVR server).
- Step 6. Click Save.
- Step 7. Click OK. The server address is saved in the profile.

*Tip:* You can click Set Default in the server settings dialog box to set the profile as the default profile.

## Setting the Default Profile

To set the default profile

- Step 1. Select the profile you want to set as default before logging on to the MAXPRO NVR.
- Step 2. In the User menu, , click Profiles > Set Default Profile. The profile is set as the default profile. The default profile appears selected in the Profile box in the Log On dialog box.




### Setting the Default Profile


## Modifying a Profile

You can modify the profile name and the server address saved in the profile.

To modify a profile

- Step 1. In the client workstation, double-click the  icon on the desktop to display the Log On dialog box.
- Step 2. Click Server Settings. The Server Settings dialog box appears.
- Step 3. In the Choose Profile box, select the profile you want to modify. The profile details appear under Configuration in the Server Settings dialog box.
- Step 4. Change the Profile Name, as applicable.
- Step 5. Change the Server IP/Name, as applicable.
- Step 6. Click Save.
- Step 7. Click OK. The profile is modified.

## Deleting a Profile

- Step 1. In the client workstation, double-click the  icon on the desktop to display the Log On dialog box.
- Step 2. Click Server Settings. The Server Settings dialog box appears.
- Step 3. In the Choose Profile box, select the profile you want to delete.
- Step 4. Click Remove.
- Step 5. Click OK. The profile is deleted.


## Editing the Ports

The MAXPRO NVR user interface includes a provision to modify the port number used by MAXPRO NVR client to connect to the following components:

- Trinity Server
- Trinity Controller
- NeoEngine Server

To edit the ports:

- Step 1. In the Server Settings dialog box, click Edit Ports. The port numbers associated to Server IP/Name, Controller IP/Name and Storage Engine IP/Name are enabled for editing.



### Editing the Ports

- Step 2. Change the port numbers, as applicable.
- Step 3. Click Save.

**Note:** Port 20000 is used for ONVIF discovery.

# Port Forwarding

The Port Forwarding feature is generally used when an Internet client wants to connect to a particular NVR in a private Local Area Network (LAN). This feature is enabled by defining port forwarding rules in the Router. By defining these rules, you can send data using the range of ports on the internet side to a port and IP addresses on the private LAN network.


## Scenarios of Port Forwarding

**Note:** The scenarios described in the subsequent sections, only cover port forwarding required for the NVR client to connect to the NVR. For using MAXPRO NVR Mobile and MAXPRO NVR Web Client from the Internet, the port used by Web Server on the NVRs (Default Ports: 80, 443) should also be set up for port forwarding. See the [Changing Default Port 443 for the MAXPRO Web Client and MAXPRO Mobile app](#) section on page 366 for further details.

It is not recommended to access NVR Client via Internet. Only NVR Web client and Mobile client is recommended to access via Internet.

### Scenario1- Services mapped to different ports

Two NVRs in a private LAN are configured behind the router, and all the services on the NVRs are running on the default ports. In the router's port forwarding section you need to map the ports for each of the services running in the NVRs. An internet MAXPRO NVR client can connect to a NVR, by specifying the public IP address given to the router and corresponding ports mapped in the port forwarding table in the router.



### Port Forwarding Scenario 1

In the above figure:

MAXPRO NVR 1 and MAXPRO NVR 2 have the default port numbers, 20007, 26026, 10000, 10010 configured for the following services respectively:

- Trinity Server
- Trinity Controller
- Storage Engine (NEOStorageServer, NEOStorageServer2)



In the router's port forwarding table, the default ports numbers for these services are mapped to the public port numbers (8001, 8002, 8003, 8004) of the router.


An external MAXPRO NVR client can access MAXPRO NVRs using the following settings:

- Server IP: 199.63.245.84
- Server Port: 8001
- Controller IP: 199.63.245.84
- Controller Port: 8002
- Storage Engine IP: 199.63.245.84
- Storage Engine Ports: 8003, 8004

**Note:** The mapping of the ports 8001, 8002, 8003, 8004 to the respective NVR IP and ports (20007, 26026, 10000, 10010) helps an external MAXPRO NVR desktop Client to connect to the MAXPRO NVR system.

Scenario 2: Services mapped to existing ports

A single NVR is configured behind the router, and all the services on the NVR are running on the default ports. In the router's port forwarding section specify the default ports. The Internet client can just specify the public IP Address and default ports to connect to the NVR. The drawback of mapping to the same ports is that only one NVR can be behind the router.



### Port Forwarding scenario 2

In the above figure:

There is a single MAXPRO NVR 1 with the default port numbers, 20007, 26026, 10000, 10010 configured for the following services respectively:

- Trinity Server
- Trinity Controller
- Storage Engine (NEOStorageServer, NEOStorageServer2)

In the router's port forwarding table, the default ports numbers for these services are specified.

An external MAXPRO NVR client can access the MAXPRO NVRs using the following settings:

- Server IP: 199.63.245.84
- Server Port: 20007
- Controller IP: 199.63.245.84
- Controller Port: 26026
- Storage Engine IP: 199.63.245.84
- Storage Engine Ports:10000 and 10010

**Note:** *In these scenarios, as ports are not mapped in the router, you can connect to only one MAXPRO NVR from an external MAXPRO NVR desktop Client.*

## Getting to Know the MAXPRO NVR User Interface


The user interface of MAXPRO NVR is easy-to-use with its intuitive icons and user-friendly features. You can configure the devices in the video surveillance network through the MAXPRO NVR user interface. The user interface consists of tabs, tree-structures, status bar, floating windows, and icons. On opening the user interface, you see the following four tabs: Viewer, Configurator, Search and Report. Based on the tab you select, windows, tree structures, and other settings relevant to the tab appear on the screen.

A status bar is displayed at the bottom of the user interface. The status bar displays: the connection status with the MAXPRO NVR server and controller, the status of clip creation, the role of the user, the number of unacknowledged alarms, and the time.

**Note:** *The tabs that are displayed in MAXPRO NVR User Interface is dependent on the user roles and privileges.*

# Viewer Tab

Figure illustrates the Viewer tab.



## Viewer tab


The following components are displayed on the Viewer tab screen.

Component	Description
Devices/Site window	A floating window that displays the recorders and cameras in a tree structure. You can select one or more devices from the <b>Devices</b> window to view its video in the Salvo Layout. Refer <a href="#">MAXPRO® NVR Operator's Guide</a> for more information. Intellisense search The Intellisense search option simplifies the search for cameras. Intellisense search supports wild characters while searching. Refer <a href="#">MAXPRO® NVR Operator's Guide</a> for more information.
Alarm window	Click to display a floating window that lists the alarms. You can acknowledge and clear the alarms from this window. Refer Alarms section in <a href="#">MAXPRO® NVR Operator's Guide</a> for more information.
Snapshot/Clip/ Archival window	Click to display a floating window that lists the images and clips in a tree structure. You can select the images, clips and Archival clips to view. Refer Snapshot and Clips section in <a href="#">MAXPRO® NVR Operator's Guide</a> for more information.
Sequences window	Click to display a floating window that lists the sequences. You can play the sequence using the play sequence action. See the <a href="#">Configuring the Sequences</a> section on page 220.

Component	Description
Views window	A floating window that lists the salvo views. The <b>View</b> window consists of <b>My Salvo Views</b> and <b>Shared Salvo views</b> . Refer Salvo View section in <a href="#">MAXPRO® NVR Operator's Guide</a> for more information.
Salvo Layout	An arrangement of panels in which video is displayed. Refer Salvo Layouts and Panels section in <a href="#">MAXPRO® NVR Operator's Guide</a> for more information.
Timeline window	A window that enables you to view video from a specified date and time. Refer Video Recording and Viewing section in <a href="#">MAXPRO® NVR Operator's Guide</a> .

## Configurator Tab

Figure illustrates the Configurator tab.



### Configurator tab


The settings in the Configurator tab enable you to add and configure the video devices and set up the MAXPRO NVR system.

Components	Description
System tab	Helps you to configure the system level settings, Site information, Archival Schedule/deletion, Holidays/Exceptions settings, Event Server Configuration and Edge Syn Settings for MAXPRO NVR.
Disk tab	Helps you to configure the disk settings for video storage.

Components	Description
Camera tab	Helps you to configure the camera settings.
Schedules tab	Helps you to configure the schedules for recording video.
IO tab	Helps you to configure the input and output for a camera.
Sequence tab	Helps you to select a sequence of cameras for live video.
User tab	Helps in user administration.

## Search Tab

Figure illustrates the Search tab.




### Search tab

You can search for recorded video and events in MAXPRO NVR from the Search tab.

# Report Tab

Figure illustrates the Report tab.



## Report tab

# Setting Preferences

The Preferences option in the User menu enables you to configure the general settings and the On Screen Display (OSD) settings. On the General Settings tab, you can configure the frame rate for panels that are not selected in the salvo layout, the video rendering settings, the video to be displayed for alarms, and the alarm threshold settings. The OSD settings can be configured to change the font properties such as type, color, and size for the text that appears over the video displayed in a panel.

You can also select the default values for the general and OSD settings using the Preferences option.

MAXPRO NVR supports three modes of encryption between client and server. On the Advance Settings tab you can select the options such as Default Encryption, Windows Authentication Encryption and Certificate Based Encryption under the Application Security Settings for secure communication.


**Note:** Honeywell recommends you to use a valid certificate from a Certificate Authority that would ensure robust security along with integrity and authenticity, instead of using self-signed certificate. Refer to the 800-23557-E - Securing MAXPRO VMS\_NVR Technical Notes for security settings.

# Settings for Video Rendering


There are two types of rendering modes, Default and No Video Display. The Default rendering is the recommended mode which enables the user to view live video from multiple cameras at optimum quality. Selecting No Video Display means that no video is displayed. You can also set the frame rate for panels that are not selected in the salvo layout. The frame rate for the panels that are not selected can be set to improve the video signal transmission over lower bandwidth networks.

To select the video rendering option

Step 1. Click the Preferences option in the user menu.




The Preferences dialog box appears. By default, the General Settings tab ([General Settings tab](#)) is selected.



**General Settings tab**

Step 2. Click the Rendering Settings tab ([Rendering Settings tab](#)).



### Rendering Settings tab


- Step 3. Select the Renderer Option (Default/No Video Display) for video rendering.
- Step 4. Select the Mange CPU Load (Throttle Frame Rate) check box if you want to throttle the frame rate if the CPU usage reaches 90 per cent.
- Step 5. Select the Show Time Stamp For Live check box if you want the camera name and time to be displayed on the live video.
- Step 6. Select Show Milli Sec check box if you want the milliseconds to be displayed in the timestamp on video.
- Step 7. Select Show FPS check box if you want the frames per second to be displayed on video.
- Step 8. Select the Deinterlace Selected Panel check box if you want to deinterlace the selected panel.
- Step 9. Select the check box beside Set FPS Limit For Unselected Panel.
- Step 10. Select the FPS Limit. The default frame rate is 5 fps and is the recommended setting for unselected panels.
- Step 11. Click Apply.
- Step 12. Click OK to close the dialog box.

## Rendering Settings for a GPU system

To avail GPU rendering (30 fps in your salvo view) you need to configure the video rendering settings under Workstation Level Settings. You can render up to 18 cameras at 1080P resolution 30fps on a client machine with recommended workstation specifications (refer to NVR data sheet for specifications). To know about improvised GPU rendering capability, see [Improved GPU Rendering](#) section on page 242 section.




Step 1. Click the Preferences option in the user menu.



The Preferences dialog box appears. By default, the General Settings tab is selected.

Step 2. Click the Rendering Settings tab ([Rendering Settings tab](#)).



#### Rendering Settings tab

Step 3. Clear the following check boxes:  
By default these two check boxes are selected.

- Mange CPU Load (Throttle Frame Rate)
- Set FPS Limit For Unselected Panel

Step 4. Click Apply.


Step 5. Click OK to close the dialog box.

## Pausing the Video Rendering

You can pause the video rendering to momentarily stop the rendering of video when a tab that does not display video is selected (for example, when the Report tab is selected, the video rendering can be paused to improve the application performance). The rendering of video starts again when you select a different tab in the user interface.


To select the tab which pauses video rendering

Step 1. Click the Preferences option in the User menu.



The Preferences dialog box appears. By default, the General Settings tab is selected.

Step 2. For Pause Video Rendering, select the check box next to the tab names that you want to select ([Settings for pausing the Video Rendering](#)).



**Settings for pausing the Video Rendering**

Step 3. Click Apply.

Step 4. Click OK to close the dialog box.

## Settings for Alarm Preview Pane

When the video related to an alarm is played from the Alarm window, the salvo layout changes to a four panel layout. You can define the video display for each panel namely, Pre Alarm, Post Alarm, Live, and On Alarm. The following table defines these options.


Option	Description
Pre Alarm	The video before the occurrence of the event that triggered the alarm is played.
Post Alarm	The video after the occurrence of the event that triggered the alarm is played.
Live	Live video is played.

Option	Description
On Alarm	The video is played from the occurrence of the event that triggered the alarm.

**Note:** You can view video related to alarms for the cameras connected to MAXPRO NVR. For Pre Alarm, Post Alarm, and On Alarm, the video is played only when the video recording pertaining to the date and time of alarm is available.


To define the video display for each preview panel

Step 1. Click the Preferences option in the User menu.



The Preferences dialog box appears. By default, the General Settings tab is selected ([Settings for the Alarm Preview Pane](#)).

Step 2. Select the video option for each panel corresponding to Preview Pane. When you select Pre Alarm and Post Alarm, a dialog box appears. Select the time in seconds for which you want to view video related to pre alarm and post alarm in the dialog box and click OK.



#### Settings for the Alarm Preview Pane

Step 3. Click Apply.

Step 4. Click OK to close the dialog box.

## Setting the Alarm Threshold Value


Each event type supported in the NVR has a pre-defined Severity Level value associated to it. When the event occurs, the value is compared with the value in the Alarm Severity Threshold box in the Preferences dialog box. The alarm is triggered only when the Severity Level value is greater than the Alarm Severity Threshold value. See Appendix B, [Event and Alarm Types](#) section on page 417 for default Event and Alarm types and their severity levels for Camera, Recorder and SMART VMD.

For example, the alarm is triggered if the Severity Level for an event is 50 and the Alarm Severity Threshold value is 40.

**Note:** Severity level for alarms are displayed in the Alarm window Refer the Alarms section in [MAXPRO® NVR Operator's Guide](#) for more information.


To set the Alarm Severity Threshold value

Step 1. Click the Preferences option in the User menu.



The Preferences dialog box appears. By default, the General Settings tab is selected ([Setting the Alarm Threshold](#)).

Step 2. Under Server Level Settings, type an Alarm Severity Threshold.



### Setting the Alarm Threshold


Step 3. Click Apply.

Step 4. Click OK to close the dialog box.

# Configuring the Snapshot Clip Export Settings


You can configure the time interval for the exported snapshot.

Step 1. Click the Preferences option in the User menu.



The Preferences dialog box appears. By default, the General Settings tab is selected ([Settings for SnapShot Clip Export](#)).

Step 2. Under SnapShot Clip Export Settings, select the Clip Export time in seconds.



## Settings for SnapShot Clip Export


Step 3. Click Apply.

Step 4. Click OK to close the dialog box.

# Configuring the OSD Settings


You can configure the OSD settings to change the properties such as type, color, and size of the text that appears over the video displayed in a panel.

Step 1. Click the Preferences option in the User menu.



The Preferences dialog box ([OSD Settings tab](#)) appears.

Step 2. Click the OSD Settings tab.



#### **OSD Settings tab**

Step 3. Click Edit and select the font and color properties in the dialog box.


Step 4. Click OK to close the font properties dialog box.

Step 5. Click Apply in the Preferences dialog box.

Step 6. Click OK to close the Preferences dialog box.


## **Configuring the Timeline Settings**

Step 1. Click the Preferences option in the User menu.



The Preferences dialog box ([Timeline Settings tab](#)) appears.

Step 2. Click the Timeline Settings tab.




### Timeline Settings tab

- Step 3. Under Timeline Jump Control Configuration, set the time for the intervals (Interval 1 to Interval 6) as applicable.
- Step 4. Under Snapshot Duration Settings, select the Daywise or Hourwise option button as applicable.
- Step 5. Under Calendar Search Month View Snapshot Time, type the preferred time and seconds and then click AM or PM as applicable.
- Step 6. Click Apply.
- Step 7. Click OK to close the Preferences dialog box.


## Configuring the Diagnostic Settings

- Step 1. Click the Preferences option in the User menu.



The Preferences dialog box ([Diagnostic Settings tab](#)) appears.

- Step 2. Click the Diagnostic Settings tab.



#### **Diagnostic Settings tab**

- Step 3. Under Change log level settings, select the check boxes corresponding to logs as applicable.
- Step 4. Click Apply.
- Step 5. Click OK to close the Preferences dialog box.

## **Configuring the Advanced Settings**

Encryption secures the communication between server and client. You can encrypt the data between client to server using encryption feature. MAXPRO NVR supports three types of encryption modes to communicate with NVR box through client. Each encryption has specific pre-requisites. The following are the pre-requisites for each encryption mode.

- Default Encryption: None
- Windows Authentication Encryption:
- System clock time should be synced between client and server machine. It also recommended to use the time sync utility to sync the time between client and server.
- Workgroup: If the machines are in workgroup then the password used by a client to log on as a windows user should be the same as Server PC.
- Domain User: All valid domain users are allowed to log on.
- Certificate Based Encryption (Recommended):
- System clock time should be in sync between client and server machine. It is also recommended to use the time sync utility to sync the time between client and server.
- Certificate needs to be installed in all Client and Server PCs. A client without a certificate is not allowed to log on.
- Internet connection is required to Install the certificate.




- Certificate Based Encryption works across workgroup and domain.

**Note:** VeriSign Class 3 Code Signing 2010 CA issued certificate is tested for certificate based encryption. Honeywell recommends you to use a valid certificate from a Certificate Authority that would ensure robust security along with integrity and authenticity, instead of using self-signed certificate. Refer to the 800-23557-E - Securing MAXPRO VMS\_NVR Technical Notes for security settings.


## To configure the Advanced settings

Step 1. Click the Preferences option in the User menu.



The Preferences dialog box ([Advanced Settings Tab](#)) appears.

Step 2. Click the Advanced Settings tab.



### Advanced Settings Tab

Step 3. Click Certificate Based Encryption option (Recommended), a certificate is used for encrypting the data between client and server. To encrypt the data using Certificate Based Encryption, perform the following:

- Browse the certificate (.pfx file).
- Type the Certificate Password and then click the Import Certificate button to import the certificate.


Tip: You can also import the certificate from the following link:  
[http://technet.microsoft.com/en-us/library/cc776889\(v=ws.10\).aspx](http://technet.microsoft.com/en-us/library/cc776889(v=ws.10).aspx)

Or

Under Application Security Settings, select the Default Encryption or Windows Authentication Encryption options as applicable.

**Note:** Honeywell recommends you to opt for Certificate Based Encryption and use a valid certificate from a Certificate Authority. The CA certificate would ensure robust security along with integrity and authenticity, instead of using self-signed certificate. Refer to the 800-23557-E - Securing MAXPRO VMS\_NVR Technical Notes on how to Secure Communication between Client and Server for MAXPRO NVR & VMS section.

Step 1. Click OK. A services restarting progress bar is displayed. Its takes several minutes to restart all the services.



#### Advance Settings Tab Service Restart


**Note:** All services will be restarted and all clients will be auto-reconnected.

Step 2. Click Apply to close the Preferences dialog box.

## Encryption Certificate deployment scenario

The following figures depicts the Encryption certificate deployment scenarios:

**Note:** Honeywell recommends you to use a valid certificate from a Certificate Authority that would ensure robust security along with integrity and authenticity, instead of using self-signed certificate. Refer to the 800-23557-E - Securing MAXPRO VMS\_NVR Technical Notes for security settings.



## Configuring the Default Settings

- Step 1. Click Reset to apply default settings while setting preferences.
- Step 2. Click System Defaults to apply the system default settings while setting preferences.

## Licensing Information

### Viewing the Version and License Information of MAXPRO NVR




**Caution: Honeywell's turnkey box solutions come pre-licensed or included with all the camera licenses. This varies for MAXPRO NVR models, please refer to the respective data sheets.**


The MAXPRO NVR Software license has a 60-day activation period. During this trial period NVR allows you to add up to 64 cameras. To continue using the software beyond the first 60 days, you must register the software. On registration, the license is limited to the number of camera licenses purchased with the software.

You can view the version and license information of MAXPRO NVR software from the User menu.

Step 1. From the User menu on the top right, click About from the drop-down list.




The version information of MAXPRO NVR appears [Figure](#) .



#### About MAXPRO NVR

Step 2. Click the License option. The License Management Console dialog box [Figure](#) appears.




### License Management Console

The License Management Console dialog box displays the number of days remaining in the 60-day activation period since the software was installed. You must purchase the license to continue using MAXPRO NVR.

License Type is shown as Permanent if your NVR has been licensed. General Features shows the license information on number of channels and clients.

### Video Analytics License

Below sample images represents with video analytics licenses for Mask and Social Distancing Detection feature.



## Registration and Licensing

Registering the software only requires the Host ID file from the server system. This is a unique ID generated for the NVR Server. Click the drum icon to create a Host ID. You are prompted to select the path where you want to generate the Host ID (HID) file, and then click OK. Save the file to a USB flash drive or hard drive.

Refer to the [MAXPRO NVR Quick Start Guide](#) for detailed information on registration and licensing of Software only NVR.

### Completing the Licensing

After you receive the license certificate, perform the following steps to license the NVR.

- Step 1. Download the License Certificate file and save it to a USB flash drive.
- Step 2. Launch MAXPRO NVR on the MAXPRO NVR Server.
- Step 3. From the User menu, click About.
- Step 4. On the MAXPRO® NVR dialog box, click License.
- Step 5. On the License Management Console dialog box, select Install License in the License drop-down list.
- Step 6. The New License Configuration Wizard launches. Click Next.
- Step 7. On the Locate Your License File dialog box, click Browse to locate your license certificate (for example, on the USB flash drive), and then click Next.
- Step 8. The License Comparison dialog box displays the details of the existing license and the newly procured license. Compare the Existing License and the Selected License columns corresponding to General Features and Devices. When you are satisfied, click Next.

**Note:** Any discrepancy in the license must be reported to Honeywell Sales Support. For example, the Maximum supported cameras row under the Selected License column displays the number of cameras for which the license is purchased. If the number of cameras is less or more than the number of cameras for which the license was purchased, contact Honeywell Sales Support immediately.

- Step 9. On the Device Configuration Changes dialog box, check that the details are accurate, and then click Next.
- Step 10. On the Confirm New License dialog, click Finish.
- Step 11. On the New License Configuration Wizard dialog box, click Yes.


## SSA - Software Service Agreement for MAXPRO

Software Service Agreement (SSA) is a flexible version specific licensing process which allows a user to get the support on the MAXPRO NVR licenses across multiple versions. From 6.0 release user need to buy a valid license to upgrade or for fresh installation. In addition, user can buy SSA support license for a specific dura-

tion which helps to get support from Honeywell. Please contact Honeywell Customer support. See the back cover for the contact information in respective regions.

**Note:** license is valid only for a specific release. When applied, on a wrong version, the license will be rejected. For example if you install 5.0 license on a 6.0 installed machine, then a message **Selected license is invalid for MAXPRO NVR 6.0. Please select correct license file** is displayed.

To install the procured license see [Registration and Licensing](#) for more information. Once the SSA license is procured and installed, the License console Management window displays the SSA info entry with validity as shown in the below example.



## Analytics License

In some scenario if user changes the Mask and Social Distancing camera license then there will not be any impact on Analytics service about the number of camera count.


For example: If you have 5 Mask /Social Distancing camera license and if you change it to 2 camera license then the alarms from the unlicensed 3 cameras will be generated in NVR for mask and social distancing until the configuration is modified.

Once the camera configuration is changed then the unlicensed camera will not function as Analytics camera and Mask/social distancing alarms will not be generated.

## Logging off

You can log off from MAXPRO NVR from the User menu. The name of the currently connected user is displayed as the User menu on the top right of each screen.

Step 1. Click the User menu. The user menu options appear.




Step 2. Click Log Off. The Log on dialog box appears after logging off from MAXPRO NVR.

## Closing the MAXPRO® NVR User Interface

You can close the MAXPRO NVR user interface from the User menu. The name of the currently connected user is displayed as the User menu on the top right of each screen.

Step 1. Click the User menu. The user menu options appear.



Step 2. Click Exit. A dialog box appears prompting you to confirm the action.

Step 3. Click Yes.



## CONFIGURING MAXPRO NVR

In this chapter...

<b>Section</b>	<b>See page...</b>
Overview	page 154
Configuring the Honeywell cameras with MAXPRO NVR Wizard	page 155
Navigating to Configurator tab	page 161
Configuring the System Settings	page 161
Configuring the Disk Management Settings	page 167
Configuring the Cameras	page 171
Adding IP Cameras / Encoders	page 172
Configuring the Auto Discovery Settings	page 180
Discovering and Adding Third Party ONVIF and AXIS Cameras	page 184
Discovering and Adding Multi-channel Encoders	page 185
Adding FLIR Camera	page 187
Adding RTSP Cameras/Encoders	page 188
Configuring the Input and Output for an IP Camera	page 189
Configuring 360/180 Cameras	page 192
Managing Analog Cameras	page 202
Configuring the Input and Output for an Analog Camera	page 209
Server VMD (SMART VMD)	page 214
Updating the Cameras	page 218
Deleting the Cameras	page 218
Configuring the Schedules	page 218
Configuring the Sequences	page 220

Section	See page...
Performing User Administration	page 222
Recommendation to use Low bandwidth stream option	page 227
Automatic Retry for Backfilled Clips	page 228
Enable Recording During On Demand Streaming	page 230
Privacy Protection Settings (GDPR Favored)	page 232
Guidelines to configure NAS Drive for Recording	page 245
Annotations	page 252
Scalable Analytics Server	page 285
Bulk configurations of cameras from NVR	page 291
Bi-Directional Audio Support for MAXPRO NVR	page 300
Series 60 Camera Integration	page 302

## Overview

Configuring MAXPRO NVR involves setting up the system to perform video surveillance and IP recording operations. This is the most important phase for commissioning MAXPRO NVR system as it involves setting up the MAXPRO NVR IP address, organizing devices, users, and roles. The MAXPRO NVR configuration task is performed only by the user having the NVR Administrator role. This is the initial task performed after the setting up the MAXPRO NVR system.



**Caution: Logon as Administrator only when an administrative activity need to be performed, Operator is preferred for all other activity.**

**Note:** For a user having the Operator role, the contents in this chapter serve as a reference.

MAXPRO NVR configuration involves the following tasks:

- Configuring the Honeywell cameras with MAXPRO NVR Wizard.
- Configuring the System settings
- Configuring the Disk settings
- Configuring the Cameras
- Adding IP Cameras / Encoders
- Manually adding cameras
- Discovering and Adding Third Party PSIA, ONVIF and AXIS Cameras
- Discovering and Adding Multi-channel Encoders
- Adding FLIR Camera
- Adding RTSP Cameras/Encoders

- Adding Streams
- Configuring the Input and Output for an IP camera
- Configuring 360/180 Cameras
- Managing Analog Cameras
- Configuring Analog Cameras
- Configuring the Input and Output for an Analog camera
- Server VMD (SMART VMD)
- Updating the Cameras
- Deleting the Cameras
- Configuring the Schedules
- Configuring the Sequences
- Performing User administration

## Before you Begin

- Ensure that you have completed MAXPRO NVR server and client hardware setup and software installation.

## Firewall Settings




**Caution: The Firewall settings are pre-configured for boxed solutions – MAXPRO NVR XE, SE, PE and MAXPRO NVR Hybrid XE, SE, PE. For MAXPRO NVR Software-Only solution, the Firewall settings are automatically configured during the installation process.**

## Configuring the Honeywell cameras with MAXPRO NVR Wizard

MAXPRO NVR Wizard is an easy three-step\* procedure to live video for Honeywell devices. This wizard automatically starts each time you power on the MAXPRO NVR system.

(\* 3 clicks with default settings and in a local area network for specific models)


Step 1. The CONFIGURATION page appears.



### CONFIGURATION page

- If you want to change the default settings, select YES or NO corresponding to the fields listed in the following table or click STEP 2 to accept the default settings, and proceed to the CAMERA DISCOVERY page in [step 2](#).

Field	Description
CONFIGURATION SETTINGS	
Video Format	Select “NTSC” or “PAL” based on your region.
Enable Continuous Recording	Start recording as soon as soon as the camera is added. 24/7 continuous recording is enabled for all the cameras.
Dynamic IP Synchronization	MAXPRO NVR software automatically synchronizes any change in the camera’s IP address.  For example, if a camera is restarted, and a new IP is associated to the camera, then the MAXPRO NVR software automatically detects the changed IP address and synchronizes it to the camera so that live viewing and recording is not disturbed.
Auto Add Discovered Camera	Any newly connected camera is automatically discovered and added to the camera’s list.

Field	Description
DISCOVERY SETTINGS	
Choose Camera Network	<p>Enables you to choose your camera network from the drop-down list.</p> <p>Click the refresh icon  to refresh the drop-down list.</p>
Auto IP Assignment	<p>Assigns a valid address to cameras with Automatic Private IP Addressing (APIPA).</p> <p>Note: Use this option only if you do not have a DHCP server and want to assign an IP address in your computer network range to the cameras.</p> <p>Range for IP Assignment: The MAXPRO NVR system automatically detects all the cameras in this range on the network.</p> <p>From, To: Type the IP range.</p>
Filter Discovered Cameras	<p>Enables you to filter the discovered cameras based on the camera model and IP range.</p> <ul style="list-style-type: none"> <li>Filter By Camera Type: Select this check box and then select a camera model from the drop-down list by clicking the respective check boxes.</li> <li>Filter By IP Range: Select this check box and then type the IP range in From and To.</li> </ul>

- Select the required language from the drop-down list. The supported languages are Arabic, Czechoslovakian, Dutch, French, German, Russian, Italian, Polish, Portuguese, Spanish, and English. The default language is English (US English).
- Select the Launch Wizard on Windows startup check box to launch the wizard automatically each time you start Windows.

**Note:** Click *RESET* to restore the default settings for each of the fields listed in the above table.

Step 2. The CAMERA DISCOVERY page appears.



### CAMERA DISCOVERY page


- All the settings that you have saved on the CONFIGURATION page are listed, along with the discovered cameras. As each connected camera is discovered (notice the message that displays on the lower right of your monitor) it is added to the list. This list disappears as the cameras are added to the MAXPRO NVR software.



### Discovered Cameras

**Note:** The ADD button on the CAMERA DISCOVERY page appears only if you have selected “NO” corresponding to Auto Add Discovered Camera in the CONFIGURATION page. Select the check boxes corresponding to a camera from the discovered list, and then click ADD button to add the discovered cameras of your choice to the MAXPRO NVR software.

- A MAXPRO NVR Wizard pop-up message appears detailing the available free channels in the system on NVR Hybrid units if there are analog cameras (pre-configured or added manually). It also gives you a hint about deleting the unused analog channels to add IP cameras. Click OK to continue.




- Click BACK to return to the CONFIGURATION page or click DONE when the number of cameras discovered equals the number of connected cameras.



**Caution: Only Honeywell IP cameras and HVE encoders (except Honeywell Performance Series and New equip® Series IP cameras) are discovered and added in the MAXPRO NVR Wizard. To discover and add other third party PSIA/ONVIF compliant cameras, see the [Discovering and Adding Third Party ONVIF and AXIS Cameras](#) section on page 184. For adding and configuring third party RTSP cameras, the RTSP settings must be specified, see [Adding RTSP Cameras/Encoders](#) section on page 188.**

**Note:** MAXPRO NVR Wizard discovers only 1 channel for multi-channel Encoders and allows you to add only 1 channel from the wizard that is first channel. You can add the additional channels from the Camera tab.

Step 3. The INSTALLATION page appears.




**INSTALLATION page**

- Click LAUNCH. The MAXPRO NVR Log On dialog appears. Please wait while the system logs you on automatically as a Windows Logged-In User. MAXPRO NVR launches and the Viewer tab appears. The Devices window on the left pane lists all the discovered network cameras.

Video is visible as soon as the cameras are dragged and dropped into the panels (also known as Salvo Layouts) on the Viewer. Refer Live Video section in [MAXPRO® NVR Operator's Guide](#) for more information.

## MAXPRO NVR Wizard Settings on the Task bar

If you right-click the MAXPRO NVR Wizard on the Task bar, a shortcut menu appears with a list of quick configuration settings.




**MAXPRO NVR Wizard Task bar Settings**

<b>Setting</b>	<b>Select..</b>
Configure	To open the Configuration page.
Auto Discover Cameras	To automatically discover the cameras.
Auto Add Cameras	To automatically add the discovered cameras to the list.
Auto IP Assignment	To assign a valid address to cameras with Automatic Private IP Addressing (APIPA).
Exit	To close the MAXPRO NVR Wizard.



## Navigating to Configurator tab

Step 1. Double-click the  icon on your desktop. The MAXPRO NVR Log On dialog box appears.



**Caution:** Only on the Honeywell provided systems shipped with v4.0 or later version has a default Windows user name, NVR-Admin and password Password\$123 is already configured and hence you automatically log in. Honeywell recommends you to create and use a new Administrator account to install and configure MAXPRO NVR. See [Before you Begin - Changing the default Windows Administrator Account Created By NVR](#), page 103 section for more information.

Step 2. Clear the Windows Logged-In User check box and then type the Username. The default user name is admin.

Step 3. Type your Password. The default password is trinity.

**Note:** Select the Windows Logged-In User check box for logging on using the Windows authentication (uses current logged in Windows account credentials). If the Windows Logged-In User check box is cleared, the MAXPRO NVR user name and password is used for authentication. If there is no profile set as default, then select the Profile corresponding to the MAXPRO NVR server to which you want to connect.

Tip: Set profiles if you have multiple MAXPRO NVR units and use the drop-down to choose which NVR unit you would like to connect to.

Step 4. Select the Display Video on Alarm check box to display the viewer as an alarm monitor.

**Note:** Alarm monitor supports pop-up of camera associated to IO events only. Pop-up on motion alarms is not currently supported.

Step 5. Click Login. The Viewer screen appears by default.

Step 6. Click the Configurator tab to open the Configurator screen. The System page opens by default.

## Configuring the System Settings


The System settings help in configuring the following:

- General System Settings - enable configuring the device name, device description, and device address for MAXPRO NVR.
- Event Recording Settings - enable configuring the times associated to event and user based recording.
- Email Settings - enable configuring the SMTP server settings for e-mail communication of events.
- Site Info - enable configuring and displaying the Site info and License type information.

- Archival Schedule - enable configuring the archive schedule for the recordings.
- Edge Sync Settings: allows you to sync and back fill the recordings from camera SD card to NVR. You can configure when to sync or back fill.
- Privacy Protection Settings: enables user to configure the type of masking in live video. See [Privacy Protection Settings \(GDPR Favored\)](#) for complete information.
- Holiday/Exception Settings for Schedules - enable configuring the holidays and exceptions for schedule based recording.

To view the system settings

- Click the Configurator tab. The System page appears by default.



## System page

# Configuring General Settings

The general settings enable configuring of the device address, device name, and device description for MAXPRO NVR.

Under General Settings

- The Device Address displays by default. You can type a new device address as applicable.
- The Device Name displays by default. You can type a new device name as applicable.
- The Description of the device displays by default. You can type a new description as applicable.

Tip: The information in the Device Address and the Device Name fields is mandatory. Device Address must be set to the machine name or IP address of the NVR for the system to work properly.

## Event Recording Settings

The event recording settings enable configuring of the times associated to video motion detection and user based recording.

Under Event Recording Settings

- The Pre-event Time (the length of time (in seconds) recording takes place before motion is detected) and displays by default. Select a new Pre-event Time as applicable. You can set this value from NONE to 15 seconds. The default Pre-event Time is 5 seconds.
- The default Record for time is 30 seconds. This is the amount of time that the NVR records or boosts recording frame rate after the motion event trigger time. You can set this value from 5 seconds to 5 minutes.

**Note:** Honeywell recommends that you retain the default setting of 30 seconds to get optimal recorded time on an event.

- The User based Recording Time (duration for which the recording is done after the user action) displays by default. Select a new User based Recording Time as applicable. The user based recording is the recording initiated by the user manually and is applicable for all the cameras connected to MAXPRO NVR.  
To start user based recording  
Right-click the panel displaying live video and click Start Recording.  
To stop the recording  
Right-click the panel displaying live video and click Stop Recording.

## Email Settings

The email settings enable configuring of the SMTP server settings for email communication of events.

Under Email Settings

- Type the From address
- Type the SMTP Server Name.
- The Port displays by default. Type a new Port number as applicable.
- Type the User Name of the user.
- Type the Password of the user.
- Select the Use Default Credentials check box if you want to use the credentials that are used while logging on.



- Select the Stop Email Service check box, if you do not want to send an email from the configured settings.
- Select the Enable SSL check box.

## Site Info Settings

Site Info settings allows you to quickly provide or refer the information related to Part Number, Serial Number, Voucher Number/System ID and the type of license being used to a support focal.

**Note:** For MAXPRO NVR turnkey solutions shipped with v4.0 or later version, the Site Info details are configured in the factory.

Under Site Info

- Type the Part Number of the NVR box. If the field is empty, the part number can be input without any credentials. To modify the Part Number, click  and then type the factory password provided by Honeywell Technical Support.
- Type the Serial Number. To modify the Serial Number, click  and then type the factory password provided by Honeywell Technical Support.
- The Voucher Number/System ID is displayed by default and it is non-editable.
- The License Type details are displayed by default and it is non-editable.
- Under Notes type any required information regarding the site based on your requirements.

## Archival Schedule Settings

The Archival Schedule settings enables you to configure the archiving schedule for your recordings. Ensure that the storage drive (NAS or SAN or USB) is configured in Disk tab and select the Drive Purpose as Archival. See [Configuring the Disk Management Settings](#) section on page 167 for more information. To configure NAS drive for recording, see [Guidelines to configure NAS Drive for Recording](#) section on page 245 for complete information.

Under Archival Schedule

- Click Auto [24/7] option to archive the recordings automatically 24/7.  
Or  
Click Every Day at option to select the required time for archival from the drop-down list.
- Select Ensure Clip scheduled for archival are not deleted until archived check box to ensure that clips will not be deleted by the system until it is

archived. If the clip deletion schedule is reached for a specific clip then this feature will retry and archive the clip.

**Note:** *The default Archival Schedule configured and recommended is Every Day at 12:00 AM. This is recommended versus the Auto [24/7] option for optimal performance and load on NVR.*

The default Archival Schedule configured and recommended is Every Day at 12:00 AM. This is recommended versus the Auto [24/7] option for optimal performance and load on NVR.

## Edge Sync Settings

Edge Sync settings enables you to set the schedule for synchronizing the recordings from the camera SD card. This feature is supported for Profile-G compliant cameras where the recordings are stored at the camera level.

Under Edge Sync Recording at:


- Click Every option and then select the time in minutes or hours to synchronize the recordings.  
Or  
Click Every Day at option to set the specific time in hours during which the synchronizing should trigger.
- Limit Past Sync: This option allows you to set number of days passed for which you want system to sync the recordings from camera. For example - if you set 10 days, then system will sync the recording within last 10 days from camera.


## Manual Archival

Manual archive can be performed in Search tab. You need to search and then archive the required recording. Before performing the manual archive ensure that you configure the drive in Disk tab and select the Drive Purpose as Archival. See [Configuring the Disk Management Settings](#) section on page 167.

To perform manual archive:

- Step 1. Navigate to Search tab and search the required Recording. Refer [MAX-PRO NVR Operator's Guide](#), How to search for recorder video and events section for more information. The recorded video is searched based on the search conditions. The search results are listed in the Results window.
- Step 2. In the Results pane, select the required recording from the list of recording. Press Ctrl to select multiple recordings.


Step 3. Click  at the bottom of the pane. The Clip Archival is in progress. Please Wait... message is displayed **Archive Progress**.



### Archive Progress

**Note:** If the Archival type Disks is not configured then you cannot archive the clips manually and Failed to archive clip message is displayed.

Once the Manual Archive is success then the selected clips are displayed in Green color (**Archive Progress**) and a Manual archival folder is created automatically for the respective camera. If it fails then the selected clips are displayed in Pink color.



## Holidays/Exceptions Settings

The holidays/exceptions settings enable setting of the holiday and exceptions for schedule based video recording.

Step 1. Under Holidays/Exceptions

To set holidays and exceptions

- Select a day from the calendar, and click Set as Holiday to set the selected day as a holiday. The selected holiday displays under List of Holidays.
- Select a day from the calendar, and click Set as Exception to set the selected day as a exception. The selected exception displays under List of Exceptions.

To remove holidays and exceptions

- Under List of Holidays, select the check box for the holiday you want to remove, and then click Remove Holiday.
- Select the check box for the exception you want to remove, and click Remove Exception.


Step 2. Click Save to save the information or click Reset to clear the information entered.

## Configuring the Disk Management Settings

Disk Management helps you to configure the disk settings for saving the recorded video. All the drives available on the MAXPRO NVR system are automatically added in the Disk Management page. To configure NAS drive for recording, see [Guidelines to configure NAS Drive for Recording](#) section on page 245 for complete information.

Step 1. Click the Configurator tab. The System page displays by default.

Step 2. Click the Disk tab to open the Disk Management page.



### Disk Management page

All the drives available on the MAXPRO NVR system are listed.

By default, the check boxes corresponding to all the drives except C:\ are selected. C:\ is reserved for the Operating System data.



**Caution: It is recommended that you do not choose the operating system drive for saving the camera recordings (as a video storage drive). Selecting an Operating System drive for video storage can lead to system instability.**

Step 3. The following information displays under Disk Management.

- Drive Name - displays the drive name such as C:\, D:\ and so on.
- Drive Type - displays the drive type (Fixed or Network). To configure NAS drive for recording, see [Guidelines to configure NAS Drive for Recording](#) section on page 245 for complete information.
- Drive Purpose - displays the purpose of the drive (Recording/ Archival)

**Note:** For Manual or Auto Archiving, ensure that you configure the Drive and select the Drive purpose option as Archival.

Tip: By default, only the fixed drives are listed. See [step 5](#) to explicitly add a network drive or fixed drive.

- Storage Path - displays the default storage path for saving the recorded video. You can type a new path for saving the recorded video.



- Selected for Storage - By default, this check box is selected for all the fixed drives that are listed except C: To disable video recording on a particular drive, clear the Select for Storage check box corresponding to the drive.
- Total Space (GB) - displays the total space available on the drive.
- Free Space (GB) - displays the free space available on the drive.
- Current Recording Drive - displays a status indicator indicating that recording is taking place on the drive. "Green" indicates that current recorded video is saved on the drive.
- NAS Domain - displays the domain name of NAS
- NAS Username - Type the username to access the NAS

**Note:** *If the domain, username and password mismatches with the external drive (NAS) credentials then TotalSpace(GB) column displays Invalid Drive message. To configure NAS drive for recording, see [Guidelines to configure NAS Drive for Recording](#) section on page 245 for complete information. If user adds a Network Drive for Archival without Domain, Username and Password then a validation message is displayed to provide the network credentials.*

- NAS Password - Type the password to access the NAS. If you select the NAS as the recording drive then ensure to follow the below.
- We should not use "-" during the share folder creation.
- If we select the shared drive for Recording, In NAS need to be create user say Administrator or NVR-admin with same password, where NVR services is running.
- If Neo services is running with "NVRservicesuser", since we do not know the password of this user (due to Cyber security) even though if we are creating user in NAS, Recording will not work.

#### Step 4. Under Disk Space

The overall drive statistics specified for the recorded video at any point of time is indicated by the following fields:

- Total available disk space - displays the total storage space available on the drives used for saving the recorded video.
- Used non video disk space - displays the disk space used by non video data on the drives.
- Used video disk space - displays the disk space on the drives used for saving the recorded video.
- Free disk space - displays the free disk space available on the drives.

**Note:** *The statistics provided in the Disk Space section does not include Archival drives.*

You can also view a graphical illustration of the drive statistics with legends for each of the above fields.

The screenshot shows the Honeywell MAXPRO NVR Configurator interface. The 'Disk' tab is active, displaying a table for disk management and a 'Disk Space' section with a pie chart and statistics.

Drive Name	Drive Type	Drive Purpose	Storage Path	Selected For Storage	Current Recording Drive	Total Space(GB)	Free Space(GB)
C:\	FIXED	RECORDING	C:\RecordedClips	<input checked="" type="checkbox"/>	<span style="color: green;">●</span>	930.26	881.36
				<input checked="" type="checkbox"/>	<span style="color: yellow;">●</span>		
				<input checked="" type="checkbox"/>	<span style="color: yellow;">●</span>		
				<input checked="" type="checkbox"/>	<span style="color: yellow;">●</span>		

**Disk Space Statistics:**

- Total available disk space: 930.26 GB
- Used disk space: 48.9 GB
- Free disk space: 881.36 GB
- Recording recycle at: 5% (48.51 GB)
- Low disk alarm at: 6% (57.82 GB)

### Graphical Illustration

- In the Recording recycle at box, type a value. The Recording recycle refers to a state when the oldest video recordings are automatically deleted, if there is no disk space on the drives for new video recordings.
- In the Low disk alarm at box, type a value. The Low disk alarm refers to a state when the space on the drives for video storage is nearing the maximum size of the drives.



**Caution: The Low disk alarm at value must be always greater than the Recording recycle at value.**

Tip: Click Refresh to refresh the information under Disk Space at any point in time.

Step 5. Click Add Drive to add a fixed drive or a network drive.

- The fixed drive that you are adding must be available on the MAXPRO NVR system, else an “Invalid Drive” text displays in the Total Space (GB) column.
- Add Network Drive using map drive as \\Drivename\Folder.
- Add a network drive path in the following format: \\<IP address >\<folder name> for example, \\192.168.1.12\Recorded Clips.

**Note:** The Network drive added must be valid with proper folder permissions set for the installed default user, else an Invalid Drive text displays in the Total Space (GB) column.




**Caution: Please exercise caution while using a network drive as a Recording type video storage drive, since network interruptions and network performance can lead to loss of video recordings.**

- Step 6. Click Save to save the information or click Reset to clear the information entered.

## Removing a drive

- Step 1. Select the check box corresponding to the drive you want to remove as shown below.



### Drive Type

- Step 2. From the Drive Type drop-down list, select Network and then click Delete. By default Fixed drive is selected. If you try to delete the Fixed drive then a message Only Network Drives can be Deleted is displayed.



**Caution: Do not delete all drives from the system otherwise user will not get an option to add the drives again. Contact to Honeywell technical support in case of this scenario.**

## Configuring the Cameras

Cameras are sources for a video input in MAXPRO NVR. The maximum number of cameras that can be configured in MAXPRO NVR depends on the model and for each camera you can also add multiple streams depending on the camera type. You can add the following types of cameras:

- IP Cameras/Encoders: MAXPRO NVR can automatically discover these devices in the network and adds it to the MAXPRO NVR user interface. See the [Adding IP Cameras / Encoders](#) section on page 172 for more information.
- Analog Cameras: User is required to manually add these cameras to the respective channel and configure the camera. See the [Adding/Deleting Analog Cameras](#) section on page 202 for more information. The maximum number of analog cameras that you can configure in MAXPRO NVR Hybrid series (XE, SE, PE) is 16.

## Adding IP Cameras / Encoders


The MAXPRO NVR Wizard automatically discovers Honeywell cameras in the network and adds it to the MAXPRO NVR user interface. Alternatively, you can also discover and add all the supported cameras in MAXPRO NVR in the Camera page.

**Note:** It is not recommended to add Encoder/Multi-channel video stream across NEO storage.

To add IP cameras

Step 1. Click the Configurator tab. The System page displays by default.

Step 2. Click the Camera tab to open the Camera page.



### Camera page

**Note:** All Honeywell cameras that are discovered and added using the MAXPRO NVR Wizard appear in the Camera page when you first open it.

Step 3. Click the Auto Discovery button, the Auto Discovery screen is displayed.

- Click Start Discovery to discover the cameras in the network. By default, the cameras discovered are displayed under Cameras Discovered pane. The cameras are added based on the IP range and Video Format settings. See the [Configuring the Auto Discovery Settings](#) section on page 180 for more information. Only device integrations with auto discovery support are discovered automatically in the NVR. All other devices need to be added manually.
- To add only specific cameras, select the required camera check boxes and then click Add Cameras. The selected cameras appear under the Camera pane.

**Note:** The cameras added will have the default parameters for all their settings.

Step 4. Under the Camera screen, select a camera to change the default parameters for the following settings.

- Enable/Disable - Enables or disables a camera for recording and live video. By default the check box corresponding to a camera to enable live video preview is selected. To disable live video preview, clear the check box corresponding to a camera. The live video appears under Preview at the bottom right corner of the camera General/Primary Stream page See the [Configuring the Camera Properties](#) section on page 176 for more information.
- Number - Displays the camera number. You cannot modify the camera number.
- Camera Name - Displays the camera name. You can type a new camera name limited to a maximum of 50 alphanumeric characters.
- IP Address - Displays the IP address of the camera. You can type the new IP address for the camera as applicable. The IP address should include the Port number 80. For example if the IP address is 111.221.0.333 then you should add the port number (80) as 111.222.0.333:80.
- Camera Type - Displays the type of camera.

**Note:**

- For the camera type, “Generic - RTSP, you must specify the RTSP settings for the camera in the camera properties. See the [Adding RTSP Cameras/Encoders](#) section on page 188 for more information.
- To add the discovered multi-channel encoders, see the [Discovering and Adding Multi-channel Encoders](#) section on page 185.

**Note:**

- User Name- Displays the default user name, “admin” for the camera. You can type a new user name for the camera as applicable. Change this only if the user has been changed on the camera.
- Password - Displays the password, if any, for the camera. You can type a new password for the camera as applicable. Change this only if the password has been changed on the camera.



**Caution: The camera Username and Password in the NVR needs to match the username and password configured on the device for the NVR to be able to connect to the camera and get video.**

- Device Stream No - Displays the channel ID. You cannot modify this field.
- Unique System No - Display the unique camera ID. You can modify and assign a new number as applicable.


**Note:**

- Unique System Number can be used to assign a unique camera number across all your NVRs. This helps in having an unique camera number in your entire system.

- Unique System Number should not be modified for the NVRs upgraded from older versions to 4.0.
- For fresh installation of 4.0 we recommend the Unique System Number should be updated when the camera is added to the NVR system. If the Unique System Number is modified later then the older recording cannot be retrieved.
- Unique system Number can be discovered as callup number in VMS based on the user configuration in VMS discovery window.

**Note:**

- Stream Count - Displays the number of streams associated with the camera. By default it displays 1. if a additional stream is added then the stream count increases. Multistream or Dual stream is not supported for encoders.
- NVR System Load, Storage Calculator -



- NVR System Load provides system load estimate based on the estimation of recording bit rate of cameras currently configured on your NVR versus maximum recording bit rate supported for the NVR in graphical manner (Percentage load is displayed and the indicator changes to red if the load is above the limit).

**Tip:** Hover the mouse over the NVR System Load indicator for more details.

**Note:**

- Part Number of your NVR system should be entered in the System tab for the Maximum estimate to be shown in the System Load. Please reopen the NVR client after updating the part number, if the part number is updated after opening the client.
- NVR System Load is based on the recording bit rate only and does not include archival recording.
- Maximum Bit Rate is based on the part number entered in System tab and Current Bit Rate Estimate is based on the cameras configured in the NVR.
- For Software only NVR System, 4 Mbps bit rate per camera license is assumed to calculate the Maximum Bit Rate but the maximum bit rate supported can vary based on your NVR Server hardware specification.
- The Current Bit Rate Estimate is based on the estimated bit rate value for configured cameras based on standard conditions and can vary based on your site environment. All the estimated bit rate calculations are based on

fixed bit rate (Mbps) and might vary based on the site environment if the camera is set to VBR (variable bit rate) mode.

- It is very important to stay within the estimator guidelines to ensure the MAXPRO NVR will operate normally.
- Over configuration of the system can lead to unsatisfactory performance.

**Note:**


- Storage Calculator provides recording storage estimate based on the recording configuration (bit rate estimate of cameras, recording schedule and retention) of current cameras on NVR versus the maximum Recording storage drive space supported by the NVR in graphical manner (Percentage recording storage estimate is displayed and the indicator changes to red if the storage estimated is above the NVR recording storage capacity).

**Tip:** Hover the mouse over the Storage Calculator indicator for more details.


**Note:**


- Archival storage calculations is not included in the estimation.
- This is an estimate for reference purpose only. While providing a reasonable storage estimate it should not be inferred that the results are absolute and will apply to all the systems and locations.
- Recording bit-rate and duration can be dramatically effected by PTZ cameras, higher levels of activity, image quality, light levels and noise.
- All the Estimator calculations are based on the fixed bit rate (Mbps) and might vary based on the site environment if the camera is set to VBR (variable bit rate) mode.

**Note:**

**Tip:** Click on the Status Monitor icon  to launch status monitor. Refer to the [MAXPRO NVR Operator's Guide](#) for more information on using MAXPRO Status Monitor.

# Configuring the Camera Properties

Step 1. For the required camera, click  on the left corner to open the camera properties pane see [the Figure](#).



## Camera Properties pane

Step 2. Click Launch Camera Web Page to launch the web page for the camera. Use the camera's web page to view IP and firmware settings, bit rate statistics, camera exposure, day night and white balance settings, and set up video motion detection and other analytic events.

Step 3. Under General > PTZ > PTZ Settings

- Device Type - Select whether the camera is a PTZ or fixed.
- PTZ Sensitivity - Select the PTZ Sensitivity for PTZ camera. Available PTZ options are: Minimum, Low, Normal, High and Maximum.

**Note:** The PTZ Sensitivity field is not available for fixed cameras.

Step 4. Under General > 360 Settings

**Note:** If Camera Type is OnCam Grandeye Fisheye (OnCam-GE-\*\*\*-Fisheye), the 360 Settings tab does not display Enable Panomorph, Immersion settings and shows Enable Dewarping, OnCam Grandeye settings.

- Enable Panomorph: Select the Enable Panomorph check box to enable the Panomorph feature.
- Mounting position: Select the Mounting Position. You have three options to choose from: Wall, Ceiling, and Ground.
- Modes: Select the Mode for the camera. The available modes are PTZ Mode, Quad Mode, and Perimeter Mode. The default mode is PTZ Mode



- Lens ID: Select the Lens ID for the camera. The supported lens ids from v3.5 or later are AO\*\*V, A0IFV, A0NKV, A1UST, A8TRT, B0QQV, B4QQV, B5SST, B6SST and B8QQT. By default AO\*\*V Lens

**Caution: Only Immervision certified camera models can support this feature enabled. Before configuring this feature, please check whether your camera has the Panomorph lens.**

**Note:**

- To view live video from Immervision certified cameras, Refer Video Viewing Options from Immervision Enabled Cameras section in [MAXPRO NVR Operator's Guide](#).
- The recommended Aspect Ratio for Immervision Certified cameras is 4:3.

**Note:**

- Enable Dewarping: Select the Enable Dewarping check box to enable the dewarping feature for OnCam Grandeye fisheye cameras.
- Mounting position: Select the Mounting Position. You have three options to choose from: Wall, Ceiling, and Ground.
- Modes: Select the Mode for the camera. The available modes are Virtual camera view, Panorama 2x180 views, Panorama 1x360 view and Panorama 1x180 view.

**Note:** To view live video from OnCam Grandeye cameras, Refer Video Viewing Options from OnCam Grandeye Cameras section in [MAXPRO® NVR Operator's Guide](#).

Step 5. Under General > Preference > Stream Preference Settings

- Live - Select the preferred stream of the camera which you want to use for streaming live video.
- Continuous - Select the preferred stream of the camera which you want to record continuously.
- Event Recording - Select the preferred stream of the camera which you want to record on events.
- Mobile/Web - Select the preferred stream of the camera which you want to use for streaming in Mobile/Web application.
- Anonymization Algorithm: Select the preferred algorithm option to anonymize the live video scene based on the environment. The available options are:
  - Variable Scene: If the scene contains both stationary and moving people or objects then select this option to anonymize the objects in the scene.
  - High Motion Scene: To anonymize the objects in high motion in the scene.
  - Still Scene: To anonymize the objects in a scene where the scene predominantly contains stationary people and objects.
- High Resolution - Select the preferred stream of the camera which you want to categorize as High Resolution stream.

- Low Resolution - Select the preferred stream of the camera which you want to categorize as Low Resolution stream.

**Note:** *The stream selected as Low Resolution settings will be used in SMART VMD.*

- Multicast Enabled - Select this check box to enable the Multicast feature for the camera. After selecting the check box enter the following details:
- Multicast Address: Type the Multicast IP address.
- Multicast Port: Type the Multicast IP Port number.

Step 6. Under Primary Stream > Recording > Video Quality Settings

- Resolution - The Resolution is defaulted to a fixed value based on the camera model (for example, HD3MDIP model defaults to 1280 x 720 resolution).
- Frame Rate - Select the FPS for a camera. FPS refers to the number of pictures displayed in exactly one second. FPS is a measure of how much information is used to store and display motion video. The term applies to digital video. Each frame is a still image; displaying frames in quick succession creates the illusion of motion.

**Note:** *30 FPS is the maximum frame rate in NTSC format and 25 FPS is the maximum frame rate in PAL format supported by MAXPRO NVR.*

*Ensure that you set the Primary stream for recording which is 720p resolution and secondary stream for Live which is 4CIF. See [Recommended stream Settings](#) section for more information.*

*You can set the Bit rate value in the specific camera web page.*

- Video Codec Type - Select the Codec type for the camera. The available options are H.264, H.265 and MJPEG. H.265 cameras can render in both CPU and GPU modes. To know about improvised GPU rendering capability, To know about improvised GPU rendering capability, see [Improved GPU Rendering](#) section on page 242 section.

Limitations of H.265 Codec Type:

- H.265 is not supported in MAXPRO Mobile app
- H.265 is not supported in Web client.

**Note:** *Only HFD6GR1, HSW2G1, HCD8G, HBD8GR1, H4D8GR1, HDZ302DE, HDZ302D and HDZ302DIN model cameras support H.265 Codec type.*

- Compression Level - The Compression Level is defaulted to “Medium”. You can select a new Compression ratio as applicable.
- GOP - The GOP is defaulted to “5”. Type a new GOP as applicable. Group of Pictures (GOP) are individual frames (number of pictures) that are grouped together and played back for viewing. A GOP consists of “IFrame” picture type that represents a fixed image independent of other picture types. Each GOP begins with this type of picture.

- Video Format - Select the Video Format (NTSC or PAL). The NTSC and PAL are the widely used video formats.
- Streaming Mode - The Streaming Mode is defaulted to UDP. You can select TCP streaming mode as applicable. The Streaming Mode is supported only for specific models of Honeywell, AXIS and ONVIF Cameras.
- Continuous - Select the FPS for Continuous recording.
- Event - Select the FPS for Event based recording.

Live/Recording Quality can be varied by controlling GOP. The formula for this is calculated as follows: Recording Quality resulting FPS = Live FPS/(GOP\*I Frame Number for recording).

For example, in the following table if Live FPS is configured as “30” and Continuous recording is set to record “Every I frame” and Event recording is set to “Same as Live” with GOP value set to “5”, the result is 6 FPS continuous recording quality and 30 FPS event recording quality.

**Note:** GOP value below 5 may not be achieved from all the cameras.

Live settings		Record quality resulting FPS			
FPS	GOP	Same as Live	Every I frame	Every 2nd I frame	Every 3rd I Frame
30	2	30	15	7.5	5
30	3	30	10	5	3.33
30	5	30	6	3	2
30	10	30	3	1.5	1
30	15	30	2	1	0.67
30	16	30	1.88	0.94	0.63
30	20	30	1.5	0.75	0.5
30	30	30	1	0.5	0.33

- Enable Edge Sync- This option is supported for Profile-G compliant cameras and used for checking whether the camera is really Profile-G compliant. Click the Get Configuration button, if the camera is a Profile-G compliant camera then the Get Configuration button disappears and Enable Edge Sync check box is enabled. Select the check box and then Sync/view the recordings using Edge Sync Settings option from the Systems tab. If the camera is not Profile-G compliant then NVR application displays Edge Sync not supported or enabled for this device message at the bottom.

Step 7. If audio is supported for the camera then Enable Audio check is displayed. Select the check box to enable audio. 1-way audio (camera to NVR) is supported for specific IP cameras. Please visit URL: <http://www.security.honeywell.com/hota/> for the compatibility list and the models supported.

**Note:** Profile-G compliant camera time should be in sync with NVR time. Ensure you configure the NTP server to avoid Time Sync related issues.

Step 8. Under Primary Stream > Schedules:

- Recording Settings:

- Continuous Recording - All cameras added are defaulted to “24/7” recording. You can choose a different option from the drop-down list.
- Event Based Recording - This is “None” by default. Select an option from the drop-down if you want to do motion/event based recording.
- Recording Deletion Settings:
  - Type the required number (Days) for the Continuous Recording video deletion duration.
  - Type the required number (Days) for the Event Recording video deletion duration.

**Note:** *If user is upgrading from 6.0 to 6.3 then whatever value user selected in 6.0 will be converted to days in 6.3. Similarly if user uninstalls 6.3 then the value entered is mapped to nearest bigger number in the drop down list.*

- Archive Recording Older Than:
  - Continuous - This is “None” by default. Select an option from the drop-down if you want to archive the continuous recording.
  - Event - This is “None” by default. Select an option from the drop-down if you want to archive the event recording.
- Delete Archived Recording After:
  - Continuous Recording - This is “365 Days” by default. Select the number of days from the drop-down after which the archived continuous recording can be deleted.
  - Event Recording - This is “365 Days” by default. Select the number of days from the drop-down after which the archived event recording can be deleted.


Step 9. Under Primary Stream > Preferences > Stream Preferences Settings. See [step 5](#) for more information.

Step 10. Click Save.

## Configuring the Auto Discovery Settings

The Auto Discovery Settings enable you to select the IP address range for discovery, set the video format (NTSC/PAL), username and password of a camera as it is being added to the NVR from the Discovery window. The Username and Password set for the camera in MAXPRO NVR must match the username and password on the camera (actual device) to stream video into MAXPRO NVR. See [the Figure](#) .

**Note:** *Auto Discovery Settings are only applicable for Honeywell, AXIS and ONVIF cameras.*



### Auto Discovery Window

To configure the Auto Discovery Settings

- On the Camera page, click the Auto Discovery button, the Auto Discovery screen appears. Perform the following:
- Under Select the IP Address range for discovery, type and set the IP address in From and To fields.
- Under Settings, select “NTSC” or “PAL” from Video Format list.
- Under Set camera credentials
- Type a Username for the camera.
- Type a Password for the camera.

**Note:** You cannot edit the Camera Type field. The cameras credentials settings provides the username and password for Honeywell (for models already added in NVR database), AXIS (for models already added in NVR database) and ONVIF cameras discovery and addition. If a Honeywell or AXIS ONVIF model that is not already added in NVR database is discovered, then the camera credentials set for ONVIF is used for discovery and addition. You can find all the models that are already added in NVR database by checking the models listed in the Camera Type drop-down in the Camera tab.


- Click Apply to save the changes or click Reset to clear the information entered. The username and password entered is applicable for all NTSC or PAL cameras. However, the username and password can be changed while configuring a particular camera.


## Adding Additional Streams for a Camera

MAXPRO NVR V4.0 supports adding multiple streams for a single camera. The number of streams that can be added depends on the model of the camera. You can also configure each stream for a specific device based on your need. For example you can configure the first stream for Live recording and the second stream for event based recording. Multistream or Dual stream is not supported for encoders.

**Note:** It is not recommended to add Encoder/Multi-channel video stream across NEO storage.

To configure the additional streams for a camera

- Step 1. Click the Camera tab, the camera page is displayed with the list of cameras discovered.
- Step 2. For the required camera, click  on the left corner, the camera properties pane is displayed see [the Figure](#).
- Step 3. Click the Add Stream button, an additional stream (Stream 2) is added see [the Figure](#).



### Adding Stream

**Note:**

- Based on the type of camera the Add Stream button is enabled/disabled. If the camera supports additional streams then the Add Stream button is enabled. You can add streams until the button is enabled.
- System stream limit is 128. This is the maximum number of streams that can be added including multi-stream for cameras and multi-channel encoders or multi-imager 180/360 cameras. Multistream or Dual stream is not supported for encoders.

**Note:**

Step 4. Under Stream 2:

- Type the required Name for the additional stream.
- Select Enable Stream check box to enable the stream Or clear the check box to disable this stream.

Step 5. For the Stream 2 Recording, Schedules, Preference settings, repeat [step 6](#) through [step 10](#) of [Configuring the Camera Properties](#) section on page 176. Similarly you can add and configure multiple streams for a camera.

**Note:** *Ensure that the Resolution and FPS should match with the Camera and the NVR secondary stream settings, else live video can not be displayed.*

*Ensure that you set the Primary stream for recording which is 720p resolution and secondary stream for Live which is 4CIF. See [Recommended stream Settings](#) section for more information.*

*You can set the Bit rate value in the specific camera web page.*

## Deleting Additional Streams

Step 1. For the required camera, click  on the left corner, the camera properties pane is displayed see [the Figure](#) .

**Note:** *If an additional stream is added then only the Delete Stream button is enabled.*

Step 2. Click the required stream tab (For example Stream 1, 2, 3) and then click the Delete Stream button. A confirmation message Do you really want to delete the stream? is displayed at the bottom of the screen.

Step 3. Click Yes to delete Or click No to cancel. If you delete the primary stream then all the configured child streams will be deleted.

## Discovering and Adding Third Party ONVIF and AXIS Cameras

The third party ONVIF and AXIS cameras that are discovered in the MAXPRO NVR user interface do not display the model name. However, the Camera Type field associated to the ONVIF and AXIS cameras displays “ONVIF DEVICE” and “No Streamer Type” in the Camera Discovered pane on the Auto Discovery screen.

No	Camera Name	IP Address	Camera Type	User Name
19	MPC20-HD54IPX-	10.78.72.170	ONVIF DEVICE	admin
20	MPC06-HD3MDIH-	10.78.72.156	OnCam-GE-Hal-Composite2	
21	MPC03-HD3MDIH-	10.78.72.153	OnCam-GE-Hal-FishEye	
22	MPC15-H4D2S2X-	10.78.72.165	OnCam-GE-Hal-FullPanorama	
23	MPC17-H4W1F-16	10.78.72.167	OnCam-GE-Hal-VGAFishEye	
24	MPC02-H3D1FX-1	10.78.72.152	ONVIF 1 CHANNEL ENCODER	
25	MPC07-H3D2F-15	10.78.72.157	ONVIF 16 CHANNEL ENCODER	
26	MPC10-H3D2FX-1	10.78.72.160	ONVIF 4 CHANNEL ENCODER	
27	CB6-13-H4SVPX-1	10.78.72.187	ONVIF 8 CHANNEL ENCODER	

### Camera Type field displaying “ONVIF DEVICE” for a ONVIF camera

You must add the discovered camera(s) using the Add Cameras button to view the model name(s). After adding the camera(s), you can view the model name(s) from the Camera Type drop-down list in the left pane of the Camera page.

AXIS and ONVIF cameras also support the TCP and UDP based streaming modes. You can choose the required streaming mode during the configuration depending upon what camera supports.

**Tip:** To discover and configure the AXIS Camera/Encoders as an ONVIF device in MAXPRO NVRs, see Appendix B [MAXPRO®NVRs - AXIS Camera/Encoders Discovery and Configuration \(using ONVIF\)](#) section on page 425.

To add third party ONVIF cameras in MAXPRO NVR through Auto Discovery

- Step 1. In the Camera page, click the Auto Discovery button. After the discovery select the required check boxes of third party ONVIF cameras.
- Step 2. Under Settings, select the Video Format from the drop-down list.
- Step 3. Under Set camera credentials, type the User Name and Password of the third party ONVIF camera.
- Step 4. Click Save.
- Step 5. Click the Add Cameras button to add the camera.

**Tip:** After adding a third party ONVIF camera model using Auto Discovery, you can also manually add a new third party ONVIF camera. Click the **Manual Add** button located at the bottom of the **Camera** page and then select the model from the **Camera Type** drop-down list.



## Adding ONVIF devices manually when Auto discovery is not supported

MAXPRO NVR v3.5 or later supports manual addition of ONVIF cameras and encoders with the support of additional device types - ONVIF DEVICE (for cameras) and ONVIF ENCODER DEVICE (for encoders).

To manually add ONVIF devices in MAXPRO NVR when Auto Discovery is not supported

**Note:** *Manual addition is recommended only when auto discovery is not supported in case of camera/encoder streaming across subnets.*

Step 1. Click Manual Add. A new camera is added in the camera pane.

- From the Camera Type drop-down list, select the required ONVIF DEVICE (for cameras) or ONVIF 1/4/8/16 CHANNEL ENCODER DEVICE (for encoders) option.

Step 2. Type the Camera Name and IP Address.

Step 3. Type the User Name and Password of the ONVIF device.

Step 4. Under camera properties pane, configure the General and Primary Stream settings.

**Note:** *For streaming to start, the (Resolution and FPS) in camera properties pane should be set to match the values supported by the camera/encoder.*

Step 5. Click Save.

## Discovering and Adding Multi-channel Encoders


An Encoder connects to an analog camera using a coaxial cable and converts analog video streams to digital video streams, which can be sent over an IP network. Multistream or Dual stream is not supported for encoders.

Each encoder varies based on the number of channels (cameras) supported. Please visit URL: <http://www.security.honeywell.com/hota/> for the most up to date list of encoders supported by MAXPRO NVR.

MAXPRO NVR automatically discovers its supported encoders and displays them in the Camera Discovered pane as shown below.

**Note:** *It is not recommended to add Encoder/Multi-channel video stream across NEO storage.*





### Adding the Encoder


**Note:** The Video Channel Number field can be modified, but it is recommended that you do not change the information in this field.

## Adding FLIR Camera

The FLIR cameras are not discovered automatically in MAXPRO NVR; hence you must add these cameras manually. The IP address of the FLIR camera should include the port number 8081 (default ONVIF port used by camera). For example: xxx.xxx.xxx:8081.

To add FLIR Camera in MAXPRO NVR

- Step 1. In MAXPRO NVR, click the Configurator tab. The System page displays by default.
- Step 2. Click the Camera tab to open the Camera page.
- Step 3. Click Manual Add. A new camera is added under Camera list.
- Step 4. Type the required Camera Name.
- Step 5. Type the IP Address of the camera as shown in figure. The IP address should include the Port number 8081. For example if the IP address is 111.221.0.333 then you should add the port number (8081) as 111.222.0.333:8081.
- Step 6. Select the required FLIR Series model camera from the Camera Type drop-down list as shown below ( [the Figure](#) ) for example FLIR F-Series).




#### Adding FLIR Model Camera


- Step 7. Scroll right to manually type the User Name and Password. The default user name is admin and password is admin.
- Step 8. Click Save.

### Adding RTSP Cameras/Encoders

Real Time Streaming Protocol (RTSP) is a control protocol for streaming video over the Internet. It allows you to select the TCP or UDP based streaming modes depending upon what the camera supports. For the camera type “Generic RTSP”, you must specify the following RTSP setting.



#### RTSP Settings

- Type the RTSP URL. Click  for help on RTSP URLs format that can be assigned to different camera types.

**Note:** *The Help that opens lists only a few manufacturers. Most cameras are RTSP, and all RTSP third party cameras can be configured. If the RTSP URL format for a particular camera type is not listed in the Help, then the URL format can be obtained from the camera manufacturer.*

- Click Get Configuration to get the resolution and compression format for the camera.
- For RTSP, all settings such as FPS must be configured on the camera web page, and the default port 554 must be used.
- If “Get Configuration” fails, a message appears to choose the compression and resolution. You must go to the Camera web page and set both of them, and then configure the same settings in MAXPRO NVR.

Step 9. Click Save.

**Tip:** If a particular camera is not discovered by the system, you can add it manually by clicking **Manual Add**.

## Configuring the Input and Output for an IP Camera


Most IP cameras have a monitor input and a control output that can be configured. For example the input of the camera could be connected to a motion detector and the output of the camera to a door opener. Once configured, movement detected at the door would trigger the door to be opened. For electrical characteristics of the input and output refer to the camera documentation.

In MAXPRO NVR, the inputs and outputs of a camera are configured by default in the database while adding a camera if the integration supports it (Refer to compatibility list on HOTA for the models with support for IO with MAXPRO NVR and the no of IOs supported by each model). MAXPRO NVR has a specialized interface that lists the inputs and outputs associated to the configured cameras.

To configure input and output

Step 1. Click the Configurator tab. The System page ( [the Figure](#) ) displays by default.

Step 2. Click the I/O tab.



### IO page

Step 3. The Input(s) pane lists the inputs for the configured cameras. Select the appropriate options in the fields as explained in the following table.

Field	Description
Global Event ID	Unique event ID
Name	External input name.
Enable/Disable	Enables or Disables the input.
Camera	Displays the associated camera name.
State (CLOSED/ OPEN)	The default option is CLOSED.  Defines the normal (non-alarm or non-active) state of the input. For example a normally closed input would have its input terminal normally connected to common or ground. To activate the normally closed input, the input needs to be opened (connection to ground or common removed). For example: A magnetic door switch raises alarm if the contacts are open when the door opens.
Record (No/Yes)	The default option is No. If set to Yes recording will start when an input is activated.  <b>Note</b> Recording is based on the time you set under <b>System</b> tab > <b>Event recording settings</b> . You can specify the <b>Pre-event time</b> and <b>Record For</b> time to record the video.

Field	Description
Trigger (NONE/ControlOutput)	The default option is NONE. If a control output is selected, then the selected output is activated when the corresponding input activates.  <b>Note</b> A cameras input can only activate the same cameras output.
Send Alarm Monitor (NO/YES)	The default option is No. If set to YES, video will pop up in the viewer when an input is activated. Ensure that "Display Video on Alarm" check box is selected in the MAXPRO NVR Log on dialog box.

- Step 4. The Output(s) pane lists the outputs for the configured cameras. Select the appropriate options in the fields as explained in the following table. Or you can also access the Output tab in Viewer screen.

Field	Description
Output Number	Control output number.
Name	Control output name.
State (CLOSED/OPEN)	The default option is OPEN. Defines the normal (non-alarm or non-active) state of the output relay contacts.
Camera	Displays the associated camera name.
ON/OFF	Manual control of the output. Click ON to close the relay contacts. Click OFF to open the relay contacts.

- Step 5. In the Output(s) pane, select an output and then click On to turn on the relay manually or Click Off to turn off the relay manually.

- Step 6. Click Save or click Reset to undo the changes.

To trigger the output from viewer screen:

- Step 1. Click the Viewer tab.
- Step 2. On the left pane, click Outputs tab, the list of camera outputs are displayed in Sites.
- Step 3. Right-click the required camera output and then set ON or OFF.

# Configuring 360/180 Cameras

## Configuring the Panomorph Settings for the Cameras with Immervision Support


ImmerVision's Panomorph lens enables 360 degree Field of View (FOV). This lens is compatible with industry standard analog and IP cameras.


By using the Panomorph lens with your IP/ Analog camera, you can:

- View live, record and playback the complete 360x180 FOV.
- Eliminate blind spots in the FOV.
- Increase the video surveillance coverage.
- Detect, track and analyze throughout the entire area.
- Playback the recorded video with digital watermark for evidence purposes.

**Caution: Only Immervision certified camera models can support this feature enabled. Before configuring this feature, please check whether your camera has the Panomorph lens.**

To configure Panomorph settings

Step 1. On the Camera page, for the required camera, click  on the left corner to open the camera properties pane see [the Figure](#) .



### Panomorph Settings

Step 2. Under General > 360 Settings

- Select the Enable Panomorph check box to enable the Panomorph feature.
- Select the Mounting Position. You have three options to choose from: Wall, Ceiling, and Ground.



- Select the Mode for the camera. The available modes are PTZ Mode, Quad Mode, and Perimeter Mode. The default mode is PTZ Mode.
- Select the Lens ID for the camera. The supported lens ids in v3.5 or later are AO\*\*V, AOIFV, AONKV, A1UST, A8TRT, BOQQV, B4QQV, B5SST, B6SST and B8QQT. By default AO\*\*V Lens ID is selected. For Sony 360 camera the A8TRT lens ID is selected automatically.

Step 3. Click Save.

**Note:**

- To view live video from Immervision certified cameras, Refer Video Viewing Options from Immervision Enabled Cameras section in [MAXPRO® NVR Operator's Guide](#).
- The recommended Aspect Ratio for Immervision Certified cameras is 4:3.

## Configuring Oncam Grandeye Cameras

The integration of the unique 360-degree Oncam Grandeye H.264 IP cameras in MAXPRO NVR enables video surveillance, acquisition and tracking that identifies suspicious behavior enabling the interrogation and verification of a potential threat. This in-turn provides the necessary intelligence needed to make a measured response to any critical situation. Grandeye's customized security solutions are designed to address to meet all of today's security and liability requirements.

MAXPRO NVR supports only Oncam Grandeye H.264 Evolution camera.

The Evolution series cameras support the following views, that help in effective video surveillance of a site:

- Evolution - FishEye(OnCam-GE-Evo-Fisheye)
- Virtual Camera View
- Panorama 2x 180 views
- Panorama 1x 360 view
- Panorama 1x 180 view

## Adding Oncam Grandeye Cameras

The Oncam Grandeye cameras are not discovered automatically in MAXRPRO NVR, hence you must add these cameras manually.


**Note:** *For Evolution cameras, please first set the active camera stream (resolution) on the camera web page. Select the same settings as camera active stream in the NVR-camera properties pane for video to be displayed.*


To add Oncam Grandeye cameras

Step 1. On the Camera page, click Manual Add.

Step 2. Enter the following information:

- Camera Name
- IP address
- Camera Type
- User Name - Type the default user name, “admin”.
- Password - Type the default password, “admin”.
- Device Stream Number (Defaulted)
- Unique System Number
- Stream Count (Defaulted)

Step 3. Click  to open the camera properties pane see [the Figure](#) .:



### Grandeye Dewarping Settings

Step 4. Under General > 360 Settings

- Select the Enable Dewarping check box to enable the dewarping settings.

**Note:** For the streamers other than GrandEye, the Enable Panorama options are not visible.

- Select the Mounting Position. The available options are Wall, Ceiling and Ground.
- Select the Modes. The available options are Virtual Camera View, Panorama 2x 180 views, Panorama 1x 360 view, and Panorama 1x 180 view. The Mounting Position and Modes are only applicable to Evolution cameras.

Step 5. Click Save.

## Image Stream Combinations for Oncam Grandeye Cameras

Evolution camera works best when configured with a particular resolution and fps. See the [Image Stream Combinations for Oncam Grandeye Cameras](#) section on page 409 in Appendix B for the optimum resolution and fps configurations for each of the cameras.

## Viewing Live Video from Oncam Grandeye Cameras

Refer Video Viewing Options from Oncam Grandeye Cameras section in [MAXPRO® NVR Operator's Guide](#).

## Device Characteristics of Oncam Grandeye Cameras


See Appendix B, [Device Characteristics of Oncam Grandeye Cameras](#) section on page 409.

## Adding Axis 360/180 Camera

To add Axis 360/180 camera


**Note:** *v3.1 SP1 or later supports discovering and adding Axis 360/180 models. Earlier these were supported through RTSP only in v3.1 or lower versions.*

- Step 1. In MAXPRO NVR, click the Configurator tab. The System page displays by default.
- Step 2. Click the Camera tab to open the Camera page.
- Step 3. Click Auto Discovery button. The Auto Discovery screen is displayed and the discovery starts by default.
  - If discovery is stopped then click Start Discovery to discover the cameras in the network. The cameras are added based on the IP range and Video Format settings. See the [Configuring the Auto Discovery Settings](#) section on page 180 for more information. Only device integrations with auto discovery support are discovered automatically in the NVR. All other devices need to be added manually. For Axis M3007-PV and M3027-PVE model cameras, ONVIF should be enabled on the camera prior to discovery. see Appendix B, [MAXPRO®NVRs - AXIS Camera/Encoders Discovery and Configuration \(using ONVIF\)](#) section on page 425.
- Step 4. After the discovery, to add the Axis 360/180 camera models, select the check boxes of Axis 360/180 camera model as shown in [the Figure](#) . Axis 360/180 cameras are listed in the discovery pane with their model numbers for example Axis M3007 and so on.




## Discovering AXIS 360 Camera

Step 5. Click Add Cameras. A message Do you want to add the remaining analog channels to the system? is displayed at the bottom of the screen as shown in the Figure .



## Adding Remaining Axis Channels

Step 6. Click Yes to add the remaining channels. The list of channels associated with the camera is added in the Camera list as shown in the Figure .



### AXIS Channels

**Note:** Depending on the mounting position, the Axis 360/180 camera (this does not apply to AXIS multi-imager cameras) supports eight or less video streams with one stream per channel added. Each channel added consumes 1 channel license. For Encoders if you add 4 channels then it will consumes 1 channel license. By default, the Axis 360/180 camera adds eight channels under camera list covering below views. Views which are not required for your specific application can be deleted. To reclaim the used channel license, select the specific channel in the list and then click Delete.

1. Overview: A non-dewarped 360° view
2. Panorama: One dewarped 180° panoramic view
3. Double Panorama: Two dewarped 180° panoramic views (Not available when the camera is mounted on a wall)
4. Quad View: Four dewarped 90° views, one for each direction (Not available when the camera is mounted on a wall)
5. View Area 1: A dewarped 90° view with PTZ (pan/tilt/zoom) functionality
6. View Area 2: A dewarped 90° view with PTZ (pan/tilt/zoom) functionality
7. View Area 3: A dewarped 90° view with PTZ (pan/tilt/zoom) functionality
8. View Area 4: A dewarped 90° view with PTZ (pan/tilt/zoom) functionality


## Adding Arecont 360/180 Camera

To add Arecont 360/180 Camera in MAXPRO NVR

**Note:**




Step 5. Click Add Camera. A message Do you want to add the remaining analog channels to the system? is displayed at the bottom of the screen as shown below.



### Adding Remaining Arecont channels


Step 6. Click Yes to add the remaining analog channels. The list of channels associated with the Arecont 360 camera is added in the Camera list as shown below. By default the Arecont 360 camera adds four channels under camera list.



## Configuring the New EquiP Model Camera for Dewarping

To dewarp the New EquiP model camera

- Step 1. Add the New EquiP Fisheye Model (HFD6GR1) camera.
- Step 2. On the Camera page, for the New EquiP Fisheye Model (HFD6GR1) camera, click **+** on the left corner to open the camera properties pane.




### EquiP- Fisheye camera Settings

- Step 3. Under General > 360 Settings, select the Enable check box to enable the dewarping feature.
- Step 4. Under General > 360 Settings
  - Select the Mounting Position. You have three options to choose from: Wall, Ceiling, and Ground. Based on the mounting position the views are displayed.
- Step 5. Click the Get Configuration button. The dewarping configuration takes a while to download the dewarping configuration. A message Successfully downloaded configuration is displayed in the bottom of the camera screen.

**Note:** For each Mounting Position, you need to click Get Configuration button to download the corresponding configuration.





### Dewarping Success Message

Step 6. After successful download of configuration, click Save.

Step 7. Under General > 360 Settings


- Select the Mounting Position. You have three options to choose from: Wall, Ceiling, and Ground. Based on the mounting position the views are displayed.
- Select the Mode for the camera. The available modes are FishEye Mode, Quad Mode, and Perimeter Mode. The default mode is FishEye Mode.

**Note:** Based on the Mounting Position the modes/views are displayed.

- Lens ID for the camera is disabled.

Step 8. Click Save to complete the configuration.

- Step 9. In Viewer, drag and drop the EquiP Fisheye Model (HFD6GR1) camera and then right-click to view the Dewarping options as shown below. For various Dewarped views refer to the [MAXPRO® NVR Operator's Guide](#).



#### Dewarped Views List


## Managing Analog Cameras

MAXPRO NVR Hybrid now supports Analog Capture card through which you can connect up to 16 analog cameras. Refer to [MAXPRO NVR Hybrid Connections](#) section on page 90 that depict the MAXPRO NVR Hybrid SE, XE and PE box with analog capture card.

## Adding/Deleting Analog Cameras

- Step 1. Connect the required number of cameras manually to analog capture card. The maximum number of analog cameras can be connected is 16.
- Step 2. Click the Configurator tab. The System page displays by default.

- Step 3. Click the Camera tab to open the Camera page. All analog cameras that are pre-configured in the factory image appear in the Camera page when you first open it.



#### Adding or Deleting Analog Camera

- Step 4. Click Manual Add. A new camera is added in the camera pane.
- Under Camera Type - Displays the type of camera. Select the Analog Capture Card option to add analog cameras.

To delete Analog Camera

- Step 1. Select the required analog camera channel check box.
- Step 2. Click Delete. A confirmation message appears “Do you really want to delete camera(s)”
- Step 3. Click Yes to delete.


## Configuring Analog Cameras

Pre-requisite to configure analog cameras: Ensure that you connect the required number of cameras manually to the analog capture card and then perform the below steps.

To configure analog cameras

Step 1. Click the Configurator tab. The System page displays by default.

Step 2. Click the Camera tab to open the Camera page.



### Camera page

**Note:** All analog cameras that are pre-configured in the factory image appear in the Camera page when you first open it.

Step 3. Under the Camera pane, select a camera to change the default parameters for the following settings.

- Enable/Disable - Enables or disables a camera for recording and live video. By default the check box corresponding to a camera to enable live video preview is selected. To disable live video preview, clear the check box corresponding to a camera. The live video appears under Video Preview at the bottom right corner of the Camera page.
- Number - Displays the camera number. You cannot modify the camera number.


**Note:** Analog channels must have Number field value of 1 to 32, please add and configure all the analog channels required before adding other devices.

- Camera Name - Displays the camera name. You can type a new camera name limited to a maximum of 50 alphanumeric characters.
- IP Address - This is -- by default for analog cameras. You can provide any valid IP if required.
- Camera Type - Displays the type of camera. Select the Analog Capture Card option to add analog cameras.
- User Name: Displays the default user name, "Admin" for the camera. You can type a new user name for the camera as applicable. Change this only if the user has been changed on the camera.

- Password: Displays the password, if any, for the camera. You can type a new password for the camera as applicable. Change this only if the password has been changed on the camera.
- Device Stream No: Displays the channel ID. You cannot modify this field.
- Unique System No: Display the unique camera ID. You can modify and assign a new number as applicable.
- Stream Count: Displays the number of streams associated with the camera. Analog cameras does not support additional streams. By default it displays 1.

Tip: Based on the Analog Capture Card model, system will prompt a message to add all supported channels by default. Click Yes to add all supported channels or No to add only 1 channel.

Step 4. For the required camera, click **+** on the left corner to open the camera properties pane see [the Figure](#) .



### Camera properties pane

**Note:** The camera properties pane is disabled when there are no cameras available in the system.

Step 5. Under General > PTZ > PTZ Settings

- Device Type - Select whether the camera is a PTZ or Fixed. By default, ACUIX cameras are PTZ enabled. See Advanced PTZ Settings
- PTZ Sensitivity - Select the PTZ Sensitivity for PTZ camera. Available PTZ options are: Minimum, Low, Normal, High and Maximum.

**Note:** The PTZ Sensitivity field is not available for fixed cameras.

Step 6. Under Primary Stream > Recording > Video Quality Settings

- Resolution - The Resolution is defaulted to a fixed value based on the camera model (for example, HD3MDIP model defaults to 1280 x 720 resolution).
- Frame Rate - Select the FPS for a camera. FPS refers to the number of pictures displayed in exactly one second. FPS is a measure of how much information is used to store and display motion video. The term applies to digital video. Each frame is a still image; displaying frames in quick succession creates the illusion of motion.

**Note:** *30 FPS is the maximum frame rate in NTSC format and 25 FPS is the maximum frame rate in PAL format supported by MAXPRO NVR.*


- Video Codec Type - Select the Codec type for the camera.
- Compression Level - The Compression Level is defaulted to “Medium”. You can select a new Compression ratio as applicable.
- GOP - The GOP value is proportional to Frame Rate value. If you set the Frame Rate value as 15 then the GOP value is updated to 15. You can also type a new GOP as applicable.  
Group of Pictures (GOP) are individual frames (number of pictures) that are grouped together and played back for viewing. A GOP consists of “IFrame” picture type that represents a fixed image independent of other picture types. Each GOP begins with this type of picture.

**Note:** *It is recommended to maintain the same GOP value as Frame Rate value.*

- Video Format - Select the Video Format (NTSC or PAL). The NTSC and PAL are the widely used video formats.
- Streaming Mode - The Streaming Mode is defaulted to UDP. You can select TCP streaming mode as applicable. The Streaming Mode is supported only for AXIS and ONVIF Cameras.
- Continuous - Select the FPS for Continuous recording.
- Event - Select the FPS for Event based recording.

Step 7. Click Video Display Settings. The Color Correction dialog box appears.

**Note:** *The Video Display Settings feature is available only on the desktop local client on the NVR Hybrid Server machine.*



### Color Correction dialog box

Step 8. Under Video Display Settings

- Move the slider right or left to increase or decrease the Brightness, Contrast, Hue, Saturation U and Saturation V.  
Or  
Type the required value in the respective boxes to adjust the video display settings.  
Or  
Click Default to set the default values.

Step 9. Click Save to save the display settings.

Step 10. Under Primary Stream > Schedules

- Recording Settings:
- Continuous Recording - All cameras added are defaulted to “24/7” recording. You can choose a different option from the drop-down list.
- Event Based Recording - This is “None” by default. Select an option from the drop-down if you want to do motion based recording.
- Recording Deletion Settings:
- Select the Event Recording clip deletion duration.
- Select the Continuous Recording clip deletion duration.
- Archive Recording Older Than:
- Continuous - This is “None” by default. Select an option from the drop-down if you want to archive the continuous recording.
- Event - This is “None” by default. Select an option from the drop-down if you want to archive the event recording.

- Delete Archived Recording After:
- Continuous Recording - This is “365 Days” by default. Select the number of days from the drop-down after which the archived continuous recording can be deleted.
- Event Recording - This is “365 Days” by default. Select the number of days from the drop-down after which the archived event recording can be deleted.

Step 11. Under Primary Stream > Preferences > Stream Preferences Settings. See [step 5](#) for more information.

Step 12. Click Save.


## PTZ Settings for Analog Camera


MAXPRO NVR now supports the advanced PTZ settings for an analog PTZ camera.

**Note:** Advanced PTZ settings are available only for analog PTZ cameras.

To set the PTZ settings

Step 1. Select the required analog PTZ camera from the camera pane.

Step 2. Click  on the left corner to open the camera properties pane.



### Camera properties pane

Step 3. Under General > PTZ > PTZ Settings

- Device Type - Select the camera as a PTZ camera. The PTZ settings are displayed.
- Select the PTZ Protocol. Available PTZ Protocol options are VCL, Pelco P, Pelco D, Maxpro, GE Kalatel.

**Note:** Vicon protocol is not supported in this release.




- Select the required Baud Rate. Available Baud Rates options are 110, 300,600, 1200, 2400, 4800, 9600, 14400, 19200, 38400, 56000, 57600, 115200, 128000, 256000.
- Select the Parity. Available Parity options are ODD and EVEN
- Type the Hardware ID, if the analog camera type is a PTZ camera. The hardware ID is based on the PTZ Protocol.
- Select the PTZ Sensitivity for a PTZ camera. Available PTZ options are: Low, Normal, High and Maximum.
- Select the COM Port name. Available COM Port names options are COM 1 and NONE For Hybrid PE, COM Port names are COM1, COM2, COM3, COM4 and NONE. Select COM 4 for analog PTZ control.
- Select the Stop Bits. Available stop bits options are 1 and 2.
- Select the Data Bits. Available data bits options are 7 and 8.

Step 4. Click Save.

## Configuring the Input and Output for an Analog Camera

The input and output hardware configuration for an analog camera in MAXPRO NVR Hybrid is configured by default and when you add an analog camera, then by default the camera is mapped to their respective input and output ports. The first input/output port is mapped to the first camera, similarly the second camera is mapped to the second input/output port of the box and so on. The input output combinations cannot be mapped to any other analog or IP camera other than the default configuration.

The below figures depicts the typical input and output ports (Highlighted in Red) and RS-485 connectors for MAXPRO NVR Hybrid XE, SE and PE Box. The SENSOR is the input port and CONTROL is the output port for both Hybrid XE (See the figure [Input and Output Ports For MAXPRO NVR Hybrid XE](#)) and SE Box (See the figure [Input and Output Ports For MAXPRO NVR Hybrid SE](#)). The detailed input and output ports for NVR Hybrid PE box is shown in [Input and Output Ports For MAXPRO NVR Hybrid PE](#).




#)	Connector)	Connects to...¶
1)	AC Power)	Electrical outlet¶
2)	Video Inputs)	Analog cameras¶
3)	VGA Port)	VGA monitor¶
4)	DVI-D Port)	DVI monitor¶
5)	Display Port)	DP monitor¶
6)	HDMI Port)	HDMI monitor¶
7)	LAN1 - Camera Network Port)	Network¶
8)	USB Ports (x4)	Various devices¶
9)	LAN2 - Client/Workstation Network Port)	Network¶
10)	S/PDIF (Optical)	Not supported¶
11-15)	Audio Inputs and Outputs)	Line in - line level¶
>	)	Speaker out¶
>	)	Microphone in - not used¶
16)	Control Outputs¶	
17)	Alarm Inputs¶	
18)	Video Out Port 1-8)	Analog camera looping output¶
19)	Termination Resistor)	*¶
20)	Video Out Port 9-16)	Analog camera looping output¶
21)	Termination Resistor)	*¶
22)	RCA Connector)	Spot monitor (RCA)¶
23)	Audio 1-16)	Not supported¶
24)	RS485)	PTZ device **¶
25)	Power Switch¶	

\* ON position when the looping outputs are not used.¶

\*\* An analog PTZ device must be configured to use COM5 port (see [Third Party IP Device and Analog Camera Configuration](#)).§

### Input and Output Ports For MAXPRO NVR Hybrid XE



Connect up to 16 analog cameras to the Video Input connectors.

Connect supplied keyboard and mouse before powering up the NVR.




Connect a local monitor to one of the monitor outputs.



Connector	Connects to...
1 Power Switch	
2 AC Power	Electrical outlet
3 Video Inputs, Outputs (BNC)	Analog cameras
4 Control Outputs	
5 Alarm Inputs	
6 VGA Port	VGA monitor
7 DVI-D Port	Monitor
8 Display Port	Monitor
9 HDMI Port	HDMI monitor
10 LAN1 - Camera Network Port	Network
11 USB Ports (x4)	Various devices
12 LAN2 - Client/Workstation Network Port	Network
13 S/PDIF (Optical)	Not supported
14 Audio Inputs and Outputs	Line in - line level
	Speaker out
	Microphone in - not used
	Sport monitor (RCA)
	Analog camera looping output
	Analog camera looping output
	PTZ device *

\* analog PTZ device must be configured to use the COM5 port (see [Third Party IP Device and Camera Configuration](#)).


**Input and Output Ports For MAXPRO NVR Hybrid SE**



#	Connector	Connects to...
1	AC Power (x2)	Electrical outlet
2	VGA Port	VGA monitor
3	DVI-D Port	Monitor
4	Display Port	Monitor
5	HDMI	Not supported
6	LAN1 - Camera Network Port	Network
7	LAN2 - Client Workstation Network Port	Network
8-11	USB Ports (x4)	Various devices
12-16	Audio inputs and outputs	Line in - line level Speaker out Microphone in - not used
17	S/PDIF (Optical)	
18	RAID Management Port	RAID device
19	Video Input 1-8	Cameras
20	Video Input 9-16	Cameras
21	Not used	
22	RS485	PTZ device *
23	Input and Output Ports	Alarm inputs and Control outputs

\* An analog PTZ device must be configured to use the COM4 port (see [Third Party Device Configuration](#)).

### MAXPRO NVR Hybrid PE Rear View



**Input and Output Ports For MAXPRO NVR Hybrid PE**

## Spot Monitoring

The Spot Monitoring feature allows you to view the live video of analog cameras from the box. You need to connect a physical monitor to the RCA port on Hybrid boxes to view the live video.

## Server VMD (SMART VMD)

Video Motion Detection (VMD) is a built-in intelligent feature that enables you to configure motion detection for the live video streamed by MAXPRO NVR using its connected cameras. Configuring motion detection involves defining one or more Region of Interest (ROI) in the field of view. Regions are drawn in the field of view to specify where the motion should be detected or excluded.

The Server VMD running on the MAXPRO NVR provides superior performance comparing to regular VMD, due to its capability to differentiate real object motion from:

- Image or camera noises
- Irrelevant motion due to weather (example: rain, snow)
- Lighting changes

Few cameras have built-in VMD capabilities. There is a provision included in the MAXPRO NVR user interface to manually configure VMD (known as Server-based VMD) for the cameras that do not have the VMD feature built-in them.



**Caution: At a time, a camera can be configured only with built-in (camera based VMD) or the Server VMD (SMART VMD). If both are enabled then only SMART VMD alarms will be displayed to user and built-in (camera based VMD) alarms will be ignored.**

## SMART VMD-Technology Overview


SMART VMD uses the same detection module as full analytics.

SAMRT VMD	Traditional VMD (Cameras and Head-ends)
<ul style="list-style-type: none"> <li>• Object based- triggers alarms based on moving objects.</li> <li>• Ignores changes in lighting, video noise, and rain.</li> <li>• Ignores other false alarm triggers that affect pixel-based VMD.</li> <li>• Processing at lower frame rate, simple object validation: low CPU requirements.</li> </ul>	<ul style="list-style-type: none"> <li>• Pixel based - compares image pixels, detects changes with a single threshold.</li> <li>• Does not adapt to changing environment.</li> <li>• Susceptible to nuisance alarms from illumination changes, rain, moving trees.</li> </ul>

## Detection of Relevant Motion

- Statistical modeling to maintain high detection sensitivity, while filtering out non-salient motion.

- Significant improvement over standard video motion detection.



#### Detection of relevant motion

### To configure SMART VMD

**Note:** Before enabling Server VMD for a camera configured to stream H.264 or MPEG4 video, please ensure that the GOP size is set to be smaller or equal to the stream frame rate. For objects that do not persist in the region till the stream contains at least 1 iFrame, SMART VMD ignores as noise to reduce false alarms. Example: Insect flying in front of a camera. It is recommended that you configure large enough regions to capture relevant motion in the area of interest. Server VMD is not supported on 360 camera (fisheye or panomorph) views.

- Step 1. Select the Enable SMART VMD check box.
- Step 2. Click Configure. The SMART VMD Configuration dialog box appears (see [SMART VMD Configuration](#)).
- Step 3. Click Include Region and a new include region (in green) appears. On the field of view, click and drag the corners of the rectangle to position and resize the region where you want the motion to be detected. Repeat the operation to include more regions.
- Step 4. Click Exclude Region and a new exclude region (in red) appears. On the field of view, click and drag the corners of the rectangle to position and resize the region where you do not want motion to be detected. Repeat the operation to exclude more regions.
- Step 5. To delete a region, select the region from the Configured Regions drop-down list, then click Delete Region.





### SMART VMD Configuration

**Note:**

- You can draw a maximum of 10 ROIs (includes Include and Exclude regions).
- Include regions are shown as green rectangles and Exclude regions are shown in red rectangles in the field of view.
- Each region is assigned a unique identifier number for easy identification.
- The Exclude region overwrites the Include region. No motion is detected in the area that is inside any of the exclusion regions.

**Note:**

Step 6. Under Alarm Settings

- Type the Hold Time (sec). This indicates the hold time for the motion video after the detected motion stops. When motion is detected and motion video has started being recorded, if motion stops briefly and then resumes within Hold Time (sec), no “Motion stopped” event is generated. This brief gap in detected motion is ignored and motion triggered recording continues without interruption. On the other hand, if motion stops and no new motion is detected within Hold Time (sec), then the “Motion stopped” event is reported. Motion triggered recording is then stopped after additional Post-Alarm duration. The Hold Time range is 0 to 30 seconds.
- The Object Size Threshold (the minimum object size required to trigger an alarm) is displayed as a yellow rectangle in the field of view. Click and drag the corners of the rectangle to resize the minimum object size for motion detection.

**Note:** *The Object Size Threshold is a universal threshold across the entire image. By default, the Object Size Threshold is set to the smallest size, and therefore even very small motions trigger an alarm. This may not be appropriate for all sites and cameras, and the yellow rectangle size should be adjusted if the default size is not adequate.*

Tip: Click the Refresh Image button to refresh the video.

Step 7. Click Save to save the changes or click Cancel to abort the changes.

## Updating the Cameras

You can modify the settings of a camera to change the camera name, IP address, camera type, fixed/PTZ, advanced camera settings, and so on. You can update the camera settings only if you have admin rights.

To update a camera

- Step 1. Click the Configurator tab. The System page displays by default.
- Step 2. Click the Camera tab to navigate to the Camera page. The list of cameras configured are displayed.
- Step 3. Select the row corresponding to the camera you want to modify.
- Step 4. Change the settings such as camera name, IP address, and so on.
- Step 5. Click Save.

## Deleting the Cameras

- Step 1. Click the Configurator tab. The System page displays by default.
- Step 2. Click the Camera tab to navigate to the Camera page.
- Step 3. Select the check box corresponding to the camera you want to delete.
- Step 4. Click Delete. A confirmation message appears at the bottom of the display area.
- Step 5. Click Yes. The selected camera is deleted.


## Configuring the Schedules

A schedule defines the date and times when continuous recording and video analytics (motion detection) functions are enabled for a camera. You can create schedules for camera(s) to record video at recurring intervals for continuous recording or event based recording (for example, motion event). There are four default schedules: 24 x 7, Weekday, DayTime, NightTime.

## Creating a Schedule

You can create schedules for the camera to record video at recurring intervals.

- Step 1. Click the Configurator tab. The System page displays by default.
- Step 2. Click the Schedule tab to navigate to the Schedule page. By default MAXPRO NVR supports the following 4 default schedules: 24 x 7, Weekday, DayTime, and NightTime.



### Schedule page

**Note:** You cannot modify/delete any of the default schedules.

- Step 3. Click Add to create a new schedule.
- Step 4. Configure the schedule details as listed in the following table.

Type	Setting
Schedule Name	The schedule name appears by default. You can type a new schedule name as applicable.
Schedule Description	Type the schedule description.
<b>Schedule settings</b>	
Select row	Select the day of the week.
From	Select the from date.
To	Select the to date.
Select	Click Select. The schedule details entered appear under Scheduler Settings.
Clear	Click Clear to clear the information entered.

- Step 5. Click Save or click Reset to undo the changes. You can create a maximum of 50 schedules in MAXPRO NVR.

## Deleting a Schedule

You can delete a schedule for the camera when you do not want to record video at recurring intervals.

- Step 1. Click the Configurator tab. The System page displays by default.
- Step 2. Click the Schedule tab to navigate to the Schedule page.
- Step 3. Under Schedules, select the schedule you want to delete from the list. The schedule's details appear.
- Step 4. Click Delete, and then click Yes in response to the confirmation message.

## Configuring the Sequences


A sequence is a set of live video streamed one after the other from cameras for a specified time interval. You can select the cameras or presets to be included in a sequence and also specify the time interval for which the video from each camera or preset must be displayed. Presets must be defined for the cameras before including them in the sequence.

## Creating a Sequence

You can create a sequence to display video that is captured from different cameras connected to MAXPRO NVR. You can add a maximum of 50 sequences in MAXPRO NVR.

To create a sequence

- Step 1. Click the Configurator tab. The System page displays by default.
- Step 2. Click the Sequence tab to navigate to the Sequence page.



Sequence page

Step 3. Click Add.

Step 4. Under Details

- The Sequence Name appears by default. You can type a new Sequence Name as applicable. The Sequence Name is limited to a maximum of 18 alphanumeric characters.
- The Hold Time (Sec) box appears by default. You can type or select a new Hold Time (Sec) for the camera to display video before advancing to the next camera.

Step 5. Under Sequence camera Association

- Select the check box corresponding to the camera that must be included in the sequence under the Available List, and then click >. The selected camera appears under the Associated List.
- Click >> to move all the cameras to the Associated List.
- Select the check boxes corresponding to the camera that you do not want to include in the sequence under the Associated List and then click <. The selected camera appears under the Available List.
- Click << to move all the cameras to the Available List.
- To include presets in the sequence, select the preset number from the drop-down list under the Preset column next to a camera. The video from each camera in the list is displayed sequentially.

**Note:** The drop-down list is not visible in the Preset column for a fixed camera.

Step 6. Click Save.

## Rearranging the Cameras In the Sequence

You can rearrange the cameras and presets in the sequence. When you rearrange them, the sequence of live video streaming from each of the cameras is altered based on the rearrangement.

To rearrange the cameras

Step 1. Select the check box corresponding to the camera you want to rearrange inside the sequence.

Step 2. Click Up to move the camera one row up, or click Down to move the camera one row down.

Step 3. Click Save.

## Removing Presets from a Sequence

You can remove a preset when you do not want it to be associated with a sequence.

To remove presets from a camera

Step 1. In the Preset column, do not select any preset from the drop-down list.

Step 2. Click Save.

## Updating a Sequence

Updating a sequence allows you to change the sequence of video display from cameras.

To update a sequence

- Step 1. Click the Configurator tab. The System page displays by default.
- Step 2. Click the Sequence tab to navigate to the Sequence page.
- Step 3. Select the check box corresponding to the sequence you want to update.
- Step 4. You can change the sequence name, dwell time and sequence of the cameras.
- Step 5. Click Save.

## Deleting a Sequence

- Step 1. Click the Configurator tab. The System page displays by default.
- Step 2. Click the Sequence tab to navigate to the Sequence page.
- Step 3. Select the check box corresponding to the sequence you want to delete.
- Step 4. Click Delete. A confirmation message appears on the top of the display area.
- Step 5. Click Yes.

## Performing User Administration

A user in MAXPRO NVR is responsible for performing various operations like viewing video, reporting alarms, and other video surveillance tasks. You can create two types of users in MAXPRO NVR: System Local User and Windows User.



**Caution: Logon as Administrator only when an administrative activity need to be performed, Operator is preferred for all other activity.**

### System Local User

A System local user can access only MAXPRO NVR Client. This user may not have access to a client workstation.

### Windows User

A Windows user can access a client workstation and also MAXPRO NVR Client.

### Users and Roles

Roles are provided to a user. These roles comprise a set of privileges. When a user is associated to a role, the privileges that are available for the role are also assigned to the user.

The various roles available in MAXPRO NVR are as follows:

- NVR Administrator
- Operator
- Supervisor
- Internet Operator
- Live View Operator

For MAXPRO NVR Software-Only Solution

The first time MAXPRO NVR is installed, two default users are created.

- admin/trinity - Non-Windows user. Honeywell recommends to create a new NVR user (See [Adding a User](#) ) in the Configurator tab and use the same to logon.
- Installed user - Windows user. You enter the credentials for this user while installing the MAXPRO NVR software.

For MAXPRO NVR Turnkey (XE,SE,PE) Solution

There are 3 default users created for NVR turnkey units shipped with v4.0 or later version.

- admin/trinity - Non-Windows user. Honeywell recommends to create a new NVR user (See [Adding a User](#) ) in the Configurator tab and use the same to logon.
- NVR-Admin/Password\$123- Windows user.
- NVRServiceUser - Windows non-interactive user used for NVR Services.

**Note:** For a Windows user, Honeywell recommends to disable the default Administrator User account and create a new Administrator User account. See [Securing MAXPRO NVR](#) section on page 299 for more information. Logon as Administrator only when an administrative activity need to be performed, Operator is preferred for all other activity.

The following table lists the various user roles and the privileges applicable to the

	<b>Viewer</b>	<b>Configurator</b>	<b>Search</b>	<b>Report</b>
NVR Administrator	X	X	X	X
Operator	X	-	-	-
Supervisor	X	-	X	X
Internet Operator	X	-	-	-
Live View Operator	X	-	-	-

role.

## Legend

- “X” indicates that the user’s role has access to the privilege.
- “-” indicates that the user’s role does not have access to the privilege.

### Note:

- The Internet Operator role is optimized for remote monitoring at lower bandwidths (minimum bandwidth requirements still apply to be able to stream required video data)
- The Live View Operator role can only access live video, and does not have access to playback operations.

### Note:

When you install MAXPRO NVR for the first time, a default user named “admin” is created. The admin user is assigned the role “NVRAdministrator”. Only the user having “NVRAdministrator” privilege can add new users, assign roles to the added users, add or modify the privileges to the users, and perform various configurations in MAXPRO NVR.

## Adding a User

You can add a user by providing a unique user name and a password. Only the “NVR Administrator role” user can add a new user in MAXPRO NVR. You can add up to 1024 users in MAXPRO NVR. After you add a new user, you can assign a role to it.

To add a user

Step 1. Click the Configurator tab. The System page displays by default.

Step 2. Click the User tab to navigate to the User page.

The screenshot displays the Honeywell MAXPRO NVR Configurator interface. The top navigation bar includes 'Viewer', 'MAXPRO NVR Configurator', 'Search', and 'Report'. A red notification at the top right states 'Your license will expire within...' and 'ADMIN' is visible in the top right corner. The main menu has tabs for 'System', 'Disk', 'Camera', 'Schedule', 'I/O', 'Sequence', 'User', and 'Analytics Server'. The 'User' tab is selected, showing the 'Configure system users and camera association' page.

The 'User' section contains a table with the following columns: User Name, Domain, User Description, Role, Password, Is Windows User, Email Address, and Password Never Expires. The table lists several users, including 'arul', 'Nagaraja', 'admin', and 'Administrator'. The 'Nagaraja' and 'Administrator' users have the 'NVRAdministrator' role and the 'Password Never Expires' checkbox checked.

Below the table is the 'Association of Cameras to User / Selection of events for email notification' section. It has tabs for 'Camera Association', 'Recorder Event Association', 'Input Event Association', and 'Camera Event Association'. The 'Camera Association' tab is active, showing two lists: 'Available List' and 'Associated List'. The 'Associated List' contains items like 'Cam\_MASK & SD', 'Camera111111111', 'MPC13-H3D252X-', and 'MPC16-H3D2522'. At the bottom right, there are 'Add', 'Save', and 'Delete' buttons.



### User page

- Step 3. Click Add. A new row is created with a default set of values for the user.
- Step 4. Under the User Name column, the default user name is displayed. You can type a new user name as applicable.
- Step 5. Under the Domain column, type the Windows domain name if the user is a Window's user and is part of a Window's domain network.
- Step 6. Under the User Description column, type a description for the user.
- Step 7. Under the Role column, select the role you want to assign to the user from the drop-down list.
- Step 8. Under the Password column, type the user's password.

**Note:** *Minimum length of the password is 6 characters. While adding a User, if the password of other users added before 3.1 release is less than 6 characters then an error message is displayed and all passwords need to be updated to meet the minimum requirement.*

- Step 9. Under the IsWindowsUser column, select the check box if the user is a Window's user. If IS Windows user check box is selected then the Password Never Expire check box is disabled and it cannot be cleared. This ensures that for a Windows user the password will never expire.
- Step 10. Under the Email Address column, type the user's email address.
- Step 11. Under Password Never Expires, select the check box to ensure that the user password never expires.

**Note:** *If IS Windows user check box is selected then the Password Never Expire check box is disabled and it cannot be cleared. This ensures that for a Windows user the password will never expire.*

- Step 12. Under Anonymization, select the check to anonymize the live video for the specific user. See [Privacy Protection Settings \(GDPR Favored\)](#) for complete information on Anonymization feature.
- Step 13. Click the Camera Association tab to associate cameras to the user.
  - To associate one camera at a time, under the Available List, select a camera and then click >. The selected camera appears under the Associated List.
  - Click >> to associate all cameras to the Associated List.
  - To remove an associated camera, under the Associated List, select a camera and then click <. The selected camera appears under the Available List.
  - Click << to disassociate all the cameras to the Available List.
- Step 14. Click the Recorder Event Association tab to associate recorder events to the user.
  - To associate one particular event, under the Available List, select the check box corresponding to the event and then click >. The selected recorder event appears under the Associated List.
  - Click >> to associate all events to the Associated List.
  - To remove an event, under the Associated List, select a check box corresponding to the event and then click <. The selected event appears under the Available List.

- Click << to disassociate all the events to the Available List.

Step 15. Click the Input Event Association tab to associate input events to the user.

- To associate one particular input event, under the Available List, select the check box corresponding to the input event and then click >. The selected input event appears under the Associated List.
- Click >> to associate all the input events to the Associated List.
- To remove an input event, under the Associated List, select a check box corresponding to the input event and then click <. The selected input event appears under the Available List.
- Click << to disassociate all the input events to the Available List.

Step 16. Click the Camera Event Association tab to associate camera events to the user.

- To associate one particular event, under the Available List, select the check box corresponding to the event and then click >. The select camera event appears under the Associated List.
- Click >> to associate all the camera events to the Associated List.
- To remove an event, under Associated List, select a check box corresponding to the event and then click <. The selected camera event appears under the Available List.
- Click << to disassociate all the camera events to the Available List.

Step 17. Click Save to save the information.

**Note:** You can add a maximum of 1024 users in MAXPRO NVR.

## Updating a User

You can modify the settings of a user to change the user ID, password, role, description, IsWindowsUser flag, and email address. You can update user settings only if you have admin rights.

**Note:** Minimum length of the password is 6 characters. While adding a User, if the password of other users added before 3.1 release is less than 6 characters then an error message is displayed and all passwords need to be updated to meet the minimum requirement.

To update a user

Step 1. Click the Configurator tab. The System page displays by default.

Step 2. Click the User tab to navigate to the User page.

Step 3. Select the check box corresponding to the user you want to modify.

Step 4. Change the settings such as user name, user description, and so on.

Step 5. Click Save.

## Deleting a User

You can remove a user from MAXPRO NVR. When you delete a user, all the associations made to the user are also removed.

To delete a user

- Step 1. Click the Configurator tab. The System page displays by default.
- Step 2. Click the User tab to navigate to the User page.
- Step 3. Select the check box corresponding to the user you want to delete.
- Step 4. Click Delete. A confirmation message appears at the bottom of the display area.
- Step 5. Click Yes.

## Recommended stream Settings

To view the video streaming in NVR you must configure the primary stream for recording and secondary stream for live video streaming in both Camera tab and Web Page. If the configuration in NVR camera tab and specific Camera web page is different then the video is not displayed.

To configure the Primary and secondary stream settings:

- Step 1. In NVR Camera tab, set the Primary Stream for recording that is for high resolution.
- Step 2. Set the Secondary stream for Live video streaming that is low resolution.

**Note:** Set the Primary stream for recording which is 720p resolution and secondary stream for Live which is 4CIF.

- Step 3. Launch the specific camera web page and then ensure that the same camera parameters are set in web page.

## Recommendation to use Low bandwidth stream option

Before enabling the Use Low resolution stream option in MAXPRO VMS you need to perform the following:

- Step 1. In MAXPRO NVR Camera tab > Primary/Secondary Stream > Preference, select the Secondary stream from the Low resolution drop down.

**Note:** Set the Primary stream for recording which is 720p resolution and secondary stream for Live which is 4CIF.

- Step 2. In MAXPRO VMS > Preferences > Advanced Tab > Low Bandwidth Stream Settings, select the Use Low Resolution Stream check box.

The below table explains the parameter that you can set for Primary and Secondary Streams.

Primary /Main Stream		Secondary /Sub Stream
Codec Format	H.264B	H.264B
Resolution	720 P (1280 x 720)	VGA (640x480)
FPS	12	5
Bit Rate Type	CBR	CBR
Bit Rate	640 - 720	192

## Automatic Retry for Backfilled Clips

Perform the steps in the order as mentioned below:

- Step 1. Upgrade MAXPRO NVR
- Step 2. Configure the Automatic Retry parameter values

## Upgrade MAXPRO NVR

### MAXPRO NVR 4.9 Build 204:

Upgrade is supported from MAXPRO NVR v4.0 Build 87 Rev H, v4.0 Build 97 Rev B, V4.1 Build 123 Rev B, v4.5 Build 162, MAXPRO NVR v4.7 Build 188 to MAXPRO NVR 4.9 Build 204. This update applies to the MAXPRO Family - Turnkey NVR and NVR Hybrid solutions (XE, SE, PE) and Software only.

**Note:** For unsupported lower versions, first upgrade to 4.0 87 Rev H and then apply the NVR v4.9 Build 204 patch.

- Step 1. Install the MAXPRO NVR 4.9 Build 204.
- Step 2. Navigate to C:\Program Files (x86)\Honeywell\MaxproNVR\TrinityFramework\bin\ and then access the TrinityBackfillService.exe.config file.
- Step 3. In the config file, locate Inside app setting section.
- Step 4. Change the value = 1 for <add key="StreamOverTCP" value="0"/> parameter.



**Caution:** If user fails to change the XML value from UDP to TCP then it will cause multiple clips synchronization failure.

## Configure the Automatic Retry parameter values

To configure the Retry parameter details

- Step 1. Navigate to C:\Program Files (x86)\Honeywell\MaxproNVR\Trinity-Framework\bin\ and then access the TrinityBackfillService.exe.config file.
- Step 2. In the config file, locate Inside app setting section and its values as shown below.
  - <add key="DownloadRetryCount" value="0"/>
  - <add key="FailClip\_RetryInterval" value="06:00"/>
  - <add key="FailClip\_RetryCount" value="3"/>
  - <add key="FailClip\_ConfigRefreshInterval" value="1"/>
  - <add key="FailClip\_StartTimeOnServiceStart" value="00:00"/>
  - <add key="NoOfFailedClipsPerBatch" value="10" />
  - <add key="ClipDownloadTimeoutMultiplier" value="1.5" />
- Step 3. Change the values as mentioned in the below table. The values shown below are default values and user can change based on there requirement.

Parameter Value to change	Description
"DownloadRetryCount" value="0"	Immediate number of consecutive retries for a failed clips.
"FailClip_RetryInterval" value="06:00"	Number of Schedule retries the pooling interval. The default value is set to 6 hours. For every 6 hours once MAXPRO NVR will retry to download the failed clips
"FailClip_RetryCount" value="3"	Number of Schedule retries for automatic retry. The default value is set to 3. For example if the clip is failed, the first retry is attempted after 6 hours consecutively for 3 times.
"FailClip_ConfigRefreshInterval" value="1"	This key helps user to set the configuration change refreshing interval for above auto retry changes. For example: FailClip_RetryInterval value change will be activated after ConfigRefreshInterval time reaches without service restart. The default value is set to 1 second.

Parameter Value to change	Description
"FailClip_StartTimeOnService-Start" value="00:00"	This key will decide from when the Fail Retry should start after starting the service. This is the reference point to FailClip_RetryInterval" value. Retry operation triggers after StartTimeOnServiceStart value.
"NoOfFailedClipsPerBatch" value="10"	Number of clips to retry with a given camera before attempting the retry on another cameras. Once all the cameras are done with retry then the control comes back to the first camera and fetches the number of clips mentioned for retry.
"ClipDownloadTimeoutMultiplier" value="1.5"	A Multiplier factor to the Maximum Time (actual Clip playback duration or 10min, whichever is higher) until that the backfill service waits to Timeout for downloading a clip.

Step 4. Click Close to close the config file.

## Enable Recording During On Demand Streaming

This feature helps user to enable recording during on demand video streaming. Earlier only live video was supported.

For Event Based recording with ON demand streaming, Continuous Recording Schedule option should be selected as None and Event based recording should be configured as 24/7 with condition that there will not be pre event recording only post event recording exists.

**Note:** *To set event based On Demand streaming recording, Continuous Recording Schedule option should be selected as None and Event based recording should be configured as 24/7, However, there will not be pre event recording only post event recording exists.*


*User should associate alarms to the required camera(s), prior enabling On Demand stream option.*

- Step 1. Log on to MAXPRO NVR.
- Step 2. Navigate to Configurator > System tab.
- Step 3. Select Enable On Demand Stream check box as highlighted below.



### Enable On Demand

Step 4. Click Save. A message id displayed as shown below.



**Note:** If you enable On Demand Stream feature in Systems tab then it will be enabled for all the camera in NVR. If you want to disable On Demand Stream feature for the required camera then go to required camera settings > Preferences tab and then clear the On Demand Stream check box as shown below. Click Save once done.

Stream ID	Stream Name	IP Address	Camera Model	Admin	NA		
<input type="checkbox"/>	<input checked="" type="checkbox"/>	28	(28) 28_HDZ302LIK-81	10.78.72.81	HDZ302LIK	admin	NA
<input type="checkbox"/>	<input checked="" type="checkbox"/>	29	(29) 29_HDZ302LIW-45	10.78.72.45	HDZ302LIW	admin	NA
<input type="checkbox"/>	<input checked="" type="checkbox"/>	32	(32) 32_H4W4DG1-182	10.79.3.182	H4W4GR1	admin	NA
<input type="checkbox"/>	<input checked="" type="checkbox"/>	34	(34) 34_HCW4G-191	10.79.3.191	HCW4G	admin	NA
<input type="checkbox"/>	<input checked="" type="checkbox"/>	35	(35) 35_HCW2G-187-NC	10.79.3.187	HCW2G	admin	NA
<input type="checkbox"/>	<input checked="" type="checkbox"/>	36	(36) 36_HCW2G-186	10.79.3.186	HCW2G	admin	NA

# Privacy Protection Settings (GDPR Favored)

## Anonymization

Anonymization feature is to help the business owner to meet the EU GDPR compliance standards easily. The objective of this feature is to hide the identifiable personal data or personal identity in a video surveillance system using masking techniques. You can even configure the masking type based on the scene environment. This feature is specific to European union region and valid license is required to enable this feature. Only an Administrator can use this feature and grant access in User tab. Equip Series cameras are supported for this feature. To mask the identifiable objects based on the scene environment, see [How to Anonymize objects based on Environment](#) section on page 240 for more information.

The following Camera association and type of masking is supported:

- Blur
- Pixelize

## Four Eye Authentication

This feature is also part of Privacy Protection setting and to meet the EU GDPR compliance standards easily. This feature is to restrict all users in a surveillance system to perform Playback operation. While performing playback operation at least two people from different roles should authenticate. For an Administrator, user authentication is not required and can do any playback operation.



For an operator user, a popup is displayed and an Administrator user or any other User with different role needs to authenticate to perform playback operation. By default this option is not selected. User need to obtain valid license to enable this feature.

The following table explains the Four eye authentication based on the user and roles:

User	Authenticating User	Valid Authentication
Operator	Administrator Or any other user with different role	Yes
Operator	Operator	No
Operator	Operator 2	Yes

## Clip Export Option


Clip export with Anonymization is supported: Anonymization feature is supported in both Playback and Clip Export operation. Refer [MAXPRO® NVR Operator's Guide](#) on how to export a clip.

**Note:** If a user exports a Anonymized clip then only WMV format is supported.

## Licensing

Both Anonymization and Four Eye Authentication (GDPR Favored) features are license based. Contact Honeywell Tech support, see the back cover for contact information.

Once the license is enabled the entries for both the features are displayed in License Management Console > Privileges screen as shown below.



**License Privacy protection Settings**


## How to enable Anonymization

**Note:** To mask the identifiable objects based on the scene environment, see [How to Anonymize objects based on Environment](#) section on page 240 for more information.

### At System Level

**Note:** Only Administrator can use this feature and provide access to an operator.

- Step 1. In Configurator > System tab, navigate to Privacy Protection Setting tab.
- Step 2. From the Anonymization type drop down, select the masking type. The available options are:
  - Blur: Blurs the Identifiable object
  - Pixelize: Pixelizes the Identifiable object




### Privacy protection Settings

## At Camera Level

At camera level user can enable or disable the Anonymization based on the requirement.

- Step 1. In Configurator > Camera tab, navigate to the camera properties for the specific camera.
- Step 2. Under Primary Stream > Preference tab, select the Anonymization Enabled check box as shown below. By default it is not selected.
- Step 3. Environment: Select the preferred Environment option to anonymize the live video scene based on the scene environment. The available options are:
  - Variable Scene: If the scene contains both stationary and moving people or objects then select this option to anonymize the objects in the scene.
  - High Motion Scene: To anonymize the objects in high motion in the scene.
  - Still Scene: To anonymize the objects in a scene where the scene predominantly contains stationary people and objects.




## Anonymization Camera Level

### At User level

An Administrator can enable Anonymization for a specific user in Users tab. The corresponding user will be able to view only anonymized video.

- Step 1. Navigate to Configurator > User tab.
- Step 2. For the required User, select the Anonymization check box as shown below. By default it is Enabled for all the operators.



The screenshot shows the 'Configurator' interface with the 'User' tab selected. The table below lists users and their settings. The 'Anonymization' column is highlighted with a red box, showing that all listed users have the checkbox checked.

User Description	Role	Password	Is Windows User	Email Address	Password Never Expires	Anonymization
	NVRAdministrator		<input type="checkbox"/>		<input type="checkbox"/>	<input checked="" type="checkbox"/>
Administrator	NVRAdministrator		<input type="checkbox"/>		<input type="checkbox"/>	<input checked="" type="checkbox"/>
Administrator	NVRAdministrator		<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
			<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>
			<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>

### Anonymization at User level

### How to view Anonymized video


- An Administrator should have grant permission to an operator to view the Anonymized video.
- After selecting the type of Anonymization from the drop down, drag and drop the required camera on to the video panel. Following images displays the types of anonymization.

For Blur



Blur View

For Pixelize




Pixelize Views

# How to enable Four Eye Authentication

- Step 1. Under Configurator > System tab, navigate to Privacy Protection Setting tab.
- Step 2. Select the Enable Four Eye Authentication check box as show below.

**Note:** Once this option is enabled it will be applicable to entire NVR system. By default this check box is not selected. User need to obtain valid license to enable this feature.




## Enable Four Eye

# How Four Eye Authentication feature Works

For an Non Administrator user

- Step 1. When an Non Administrator user tries to perform a playback operation then the following dialog box appears on th screen.



## Four Eye Authentication

- Step 2. Enter the credentials of Administrator user or a User from different role.

**Note:** For authentication, the logged in user and the Administrator user should not be of same role.

The following table explains the Four eye authentication based on the user and roles

User	Authenticating User	Valid Authentication
Operator	Administrator Or any other user with different role	Yes
Operator	Operator	No
Operator	Operator 2	Yes


Step 3. Click the Authenticate button to view the playback video. After authentication the Four eye authenticated user and logged in user icons are displayed on the top of the screen as highlighted below. For example: In the below image for a test1 user, an administrator authenticates and the corresponding users are created.

- Until the four eye authenticated user is logged in, the operator can perform any playback operation.



#### Four Eye Authentication Success

- If the four eye authenticated user logs off as highlighted below then again for any playback operation the Admin authentication is required.



**Authenticating User**


## Video Anonymization

This feature allows user to configure or mask identifiable objects based on the scene environment. It provides flexibility to choose and configure the required camera based on the mounting position. The following are the options supported.

- Variable Scene: If the scene contains both stationary and moving people or objects then select this option to anonymize the objects in the scene.
- High Motion Scene: To anonymize the objects in high motion in the scene.
- Still Scene: To anonymize the objects in a scene where the scene predominantly contains stationary people and objects.

## How to Anonymize objects based on Environment

- Step 1. For the required camera, click on the left corner to open the camera properties pane.
- Step 2. Click General > Preference > Stream Preference Settings as shown below.



- Step 3. Under Environment, select the preferred option. The available options are:

Options	Description
Variable Scene	Select this option if the scene contains both stationary and moving people or objects.
High Motion Scene	Select if you want to anonymize the objects in high motion scene
Still Scene	Select to anonymize the objects in a scene where the scene predominantly contains stationary people and objects.

- Step 4. Click Save.

Following images display the type of video anonymization scenes based on the environment selection in NVR.

For Variable Scene





For High Motion Scene



For Still Scene



## Improved GPU Rendering

GPU Rendering capability is now enhanced to handle the camera video packets along with decompression technique. This helps the system not to depend on CPU for rendering video. User can view smooth and clear live video through GPU rendering. User should modify the registry value in client or server machine to enable GPU rendering mode.


**Note:** The following list of camera models/machine will not render in GPU mode:

- GrandEye Camera Models
- Dewarping Camera Models
- Anonymizaion enabled cameras
- Analog Cameras
- 32 bit processor rendering client machine


## Settings for Rendering Video through GPU

**Note:** Ensure that user has enabled the Enable GPU Rendering check box in Preferences > Rendering options tab to render video through GPU.

- Step 1. In a client or server machine, open the Registry Editor.
- Step 2. Navigate to the path HKEY\_LOCAL\_MACHINE\SOFTWARE\WOW6432Node\Honeywell\MaxproNVR\TrinityFramework\Client as shown below.



- Step 3. On the left pane, double-click GPU\_RENDERING\_VALUE. The Edit DWORD dialog appears as shown below.



- Step 4. Modify the value to 1 in Value data box.

**Note:** If the Value data flag is set to 0 then rendering will happen through CPU mode.

Step 5. Click OK. Drag and drop the cameras required cameras on to the panel to view the improvised GPU rendering mode.


## GPU Rendering Combinations

The below table explains the combination settings between Enable GPU Rendering option and Registry settings.

IF	And If	Then
User enables Enable GPU Rendering check box in Preferences > Rendering options tab	user sets GPU_Rendering_Value flag to 1	Both Decompression and Rendering will be processed through in GPU mode.
User enables Enable GPU Rendering check box in Preferences > Rendering options tab	user sets GPU_Rendering_Value flag to 0	Decompression process will happen through GPU and Rendering will be processed in CPU mode.
user does not select Enable GPU Rendering check box in Preferences > Rendering options tab	user sets GPU_Rendering_Value flag to 1	Both decompression and Rendering will be processed through CPU.

## How to identify if a camera is Rendering in GPU Mode

After Enabling GPU: The font and clarity of live video is displayed as shown below.



# Guidelines to configure NAS Drive for Recording

## Step 1: Create Directory in NAS

**Note:** The steps described below may vary from one NAS to another.

- Step 1. Logon to respective NAS web page
- Step 2. Click Settings > Privilege. The Privilege page is displayed.
- Step 3. Click Shared Folders > Add. The Add/Edit folder page is displayed.
- Step 4. Under General provide the following information for new directory
  - Folder Name: Type the name of folder to store recording
  - Description: Type the description if required
  - Location: Select the required location to store
  - Protocol: Select CIFS/SMB protocol
- Step 5. Click the Save button. The new folder directory is created and displayed under shared folder.

## Step 2: Map the User details with NVR User


**Note:** The steps described below may vary from one NAS to another.

- Step 1. Click Settings > Privilege. The Privilege page is displayed.
- Step 2. Click User tab and then Add. The Add User page is displayed.
- Step 3. Under Add User Provide the details for the following:
  - Username: Provide the same Username of NVR NeoStorageServer
  - Password: Provide the same password of NVR NeoStorageServer
  - Re-enter the password
  - Description: provide the description of the user
  - Group: configure the group to which the user belongs to.
  - Home Directory: Select the required Home directory
  - Password Expiration: set the required password expiration duration.
  - Click Quota tab to set the quota details
- Step 4. Click OK. The newly created user is displayed under list of users pane.

**Note:** If customer is using Infotrend NAS then they have to create the user inside the NAS box. The username could be NVR-Admin or Administrator.

## Step 3: Configure the NAS Drive in NVR

- Step 1. Click the Configurator tab. The System page displays by default.
- Step 2. Click the Disk tab to open the Disk Management page
- Step 3. Click Add Drive to add a network drive. A new drive row is added with Network as shown below.



- Step 4. Under Disk Management, select the following information:

- Drive Name - Select the Network drive.
- Drive Type - Select Network.
- Drive Purpose - Select Recording. By default Recording is selected

**Note:** If you select Archival as Drive Purpose then you have to provide the details for NAS Domain, NAS Username and NAS Password. If user adds a Network Drive for Archival without Domain, Username and Password then a validation message is displayed to provide the network credentials.

- Step 5. In Storage Path, add a network drive path in the following format: \\<IP address >\<folder name> For example, \\192.168.1.12\Test.
- Step 6. Click the Save button. The Network Drive path will be appended with RecordedClips folder. The complete path is displayed as \\<IP address >\<folder name>\RecordedClips. If the NAS drive is Selected for Storage then the Current Recording Drive turns to Green.


## QNAP NAS for Recording

When user configures the QNAP NAS for recording, then recycle function is not happening. QNAP is creating Recycle bin folder in shared folders. The deleted clips are being stored in recycle bin which is available on the same shared folder.

To avoid QNAP creating Recycle bin folder in shared folder user needs to disable the Enable Network Recycle Bin check box option.


To disable Network Recycle Bin option

- Step 1. Logon to QNAP NAS web page.
- Step 2. Click Control Panel > System. The System page is displayed as shown below.



Step 3. Navigate to Network & File Services > Network Recycle Bin. The Network Recycle Bin page is displayed.

Step 4. Clear the Enable Network Recycle Bin check box as highlighted below.



Step 5. Click Apply to save the changes.

## Limitations in Configuring NAS for recording

- User should not use “-”, “@” (Hyphen/At the Rate) during the share folder creation
- If user selects the NAS drive for Recording, then in NAS Web page user need to be create user with same credentials as NVR NeoStorageServer services.

For example if NVR service is running with credentials Administrator or NVR-admin then the same user should be created in NAS web page.

- If Neo service is running with “NVRservicesuser” credentials then it is important to have same credentials for NAS User. If different user credentials are created in NAS then recording will not work.
- If user adds multiple directories from same NAS into NVR then the available space will be incorrect (it will add NAS space for every such directory added)
- In Disk management window, after configuring the storage path for NAS drive, the Total Space (GB) columns displays Invalid Drive. For NVR to show the drive details the recording has to switch to the NAS drive.
- If customer is using Infotrend NAS then they have to create the user inside the NAS box. The username could be NVR-Admin or Administrator.

## Playing archived clips through Client machine

### Pre-requisite

User was unable to access and play the archived clips from NVR server machine. If user drag and drops the archived clips into the viewer then an error message is displayed.

User needs to have the below privileges to access the archived clips from remote NVR clients. Below table details out the possible combinations to play the archived clips from client machine.

- Scenario 1: If user has configured Fixed drive in NVR Server For Archival.

Configured Archival path NVR Server	Then Client should have access to this path	Description
NVR Server (10.78.34.100): D:\archival	\\10.78.34.100\D \$\archival	User can access with this admin share only if the logged in user of NVR client is a local administrator in NVR server.

- Scenario 2: If user has configured shared path in NVR Server for archival then user need to configure the Archival drive as UNC path.

Configured Archival path NVR Server	Then Client should have access to this path (Read Only access)
NVR Server \\10.78.34.100\archival	\\10.78.34.100\archival



## How to achieve the above Scenario 2 in Domain Environment

- NVR Server and NVR client should be added to the same domain environment

Refer the Windows specific documentation on how to configure the NVR Server and NVR client to the same domain controller.

- Add two user in the Domain Controller as mentioned below
- Add one Domain user as the Local Administrator in NVR Server
- Add another Domain user as a local Administrator in NVR Client (Check whether it is only local administrator or less privileges access)

## How to achieve Scenario 2 in Work group

- Scenario 3: If user using NAS drive

If NVR Server Path (using NAS as archival location):	The Client path to access
\\10.78.34.200\NVR_A_ARCHIVAL	\\10.78.34.200\NVR_A_ARCHIVAL

- Scenario 4: If user using SAN then client can be accessed as mentioned in Scenario 1 above.

## Different Scenarios to playback Archived Clip

Clip does not exist or you do not have the permission to view it” message is displayed if user drag and drop a archived clip on a salvo. This is because of the client machine has no access to the Archived shared path. Access permission to Archival shared drive should be granted to client machine also.

Below table explains various scenarios in which the archived clip is playable. User needs to perform suitable scenario settings to avoid the error message and playback the clip.

If NVR Server Credentials	then NVR Client Credentials	If Shared Drive Credentials are	If Drive Type is	Playback Supported	Workaround if Playback Fails
Administrator, Password1	Administrator, Password1	NA	Fixed	Yes	None
Administrator, Password1	Administrator, Password2	NA	Fixed	No	None

If NVR Server Credentials	then NVR Client Credentials	If Shared Drive Credentials are	If Drive Type is	Playback Supported	Workaround if Playback Fails
Administrator, Password1	NVR-admin, Password1	NA	Fixed	No	<b>Workaround for Client</b> - In fixed path, machine need to create the Client user name with same password and provide (Read) permission for the Archival drive or folder.
Administrator, Password1	MaxproNVR, Password1	NA	Fixed	No	<b>Workaround for Client</b> - In fixed path, machine need to create the Client user name with same password and provide (Read) permission for the drive or folder.
Administrator, Password1	Administrator, Password1	Administrator, Password1	Shared	Yes	NA
Administrator, Password1	Administrator, Password1	NVR-admin, Password1	Shared	No	<b>Workaround for Client</b> - In Shared path, machine need to create the Client user name with same password and provide (Read) permission for the Archival drive or folder.
Administrator, Password1	NVR-admin, Password1	Administrator, Password1	Shared	No	<b>Workaround for Client</b> - In Shared path, machine need to create the Client user name with same password and provide (Read) permission for the Archival drive or folder.
Administrator, Password1	NVR-admin, Password1	NVR-admin, Password1	Shared	Yes	In server machine it will not stream
NVR-admin, Password1	Administrator, Password1	NVR-admin, Password1	Shared	No	<b>Workaround for Client</b> - In Shared path, machine need to create the Client user name with same password and provide (Read) permission for the Archival drive or folder.
Administrator, Password1	Administrator, Password2	Administrator, Password2	Shared	Yes	None
Administrator, Password2	Administrator, Password2	Administrator, Password1	Shared	No	None

If NVR Server Credentials	then NVR Client Credentials	If Shared Drive Credentials are	If Drive Type is	Playback Supported	Workaround if Playback Fails
Administrator, Password1	Administrator, Password2	NVR-admin, Password1	Shared	No	<b>Workaround for Client</b> - In Shared path, machine need to create the Client user name with same password and provide (Read) permission for the Archival drive or folder.
Administrator, Password1	NVR-admin, Password1	Administrator, Password2	Shared	No	<b>Workaround for Client</b> - In Shared path, machine need to create the Client user name with same password and provide (Read) permission for the Archival drive or folder.
Administrator, Password1	NVR-admin, Password1	NVR-admin, Password2	Shared	Yes	NA
NVR-admin, Password1	Administrator, Password1	Administrator, Password2	Shared	No	None
NVR-admin, Password1	Administrator, Password1	NVR-admin, Password2	Shared	No	<b>Workaround for Client</b> - In Shared path, machine need to create the Client user name with same password and provide (Read) permission for the Archival drive or folder.
NVR-admin, Password1	NVR-admin, Password2	Administrator, Password1	Shared	No	<b>Workaround for Client</b> - In Shared path, machine need to create the Client user name with same password and provide (Read) permission for the Archival drive or folder.

## How to configure the Archival and Deletion retry settings

### Recommendations:

Honeywell recommends before configuring Archival Clip and Deletion Retry settings ensure that the following parameters are set based on the site requirement:

- The default value for DiskAlarmThresholdInGB is 100: This indicates when the available free space in archival location is less than 100 GB then an alarm is triggered.
- The default value for DiskRecyclingInGB is 30: This indicates if the available free space is below 30 GB, then the older archived clips are recycled to create space for the newly archiving clips.
- The default value for DiskSwitchLimitInGB is 5: This indicates if the available free space in the archival location goes less than 5 GB then Low Disk Space

alarm is triggered and the archival process will be attempted to next available archival location if configured.

- Step 1. Navigate to C:\Program Files (x86)\Honeywell\MaxproNVR\Trinity-Framework\bin\TrinityArchival.exe.config.
- Step 2. Right-click and open with Notepad.
- Step 3. Scroll down to locate the below two values and change the count value for each parameter based on the requirement. The default value is 4.

```
<add key="MaxTryCountForArchival" value="4" />  
<add key="MaxTryCountForArchiveDeletion" value="4" />
```

- If Value is set to 0 = Indefinite tries
- If Value is set to > than 0 = Indicated the number of attempts to archive or delete the archived clips respectively.

**Note:** *Archival/Deletion Retry settings will be moved to default count value if user upgrades to future versions of VMS/NVR.*

## Annotations

### Introduction

Annotation feature helps to trace and locate the moving subjects in live/recorded video and generates an alarm if intrusion or loitering is detected. After this feature is enabled in NVR, subjects in video when found in Region Of Interest, is bounded by rectangle box and on alarm conditions, it will be signified with a change in color of bounding box. This helps the operator to quickly trace the direction of the moving subject.

Equip-S series camera supports Annotation feature along with Intrusion trace and Loitering Trace alarms. These alarms are in-built with Equip-S series camera and are made available by installing required analytics licenses.

Annotation with Intrusion Trace alarm: This feature helps in detecting a subject, if it enters a predefined restricted area. The system will annotate and detects the object with Green rectangular box. If the object is detected in the restricted area then the annotated Green rectangular box turns to Red and an alarm is generated.

Annotation with Loitering Trace alarm: This feature helps in detecting an object if loitering beyond the specified duration of time in a predefined region. The subjects is bounded by the box along with the duration (time in seconds) for which it is identified in the region of interest. If the subject is loitering in the region beyond a predefined time then the annotation boxes turns to Red and an alarm is generated.

**Note:** *Currently Annotation feature works with only with old GPU rendering modes.*

Annotation feature is supported with the following camera models and firmware version:

S.No	Camera Model	Firmware	Loiter	Intrusion
1	H4D8GR1	2.420.HW00.9, Build Date: 2018-12-17	V1.20.60	V1.20.60
2	HCD8G			
3	HBD8GR1			
4	HFD6GR1	1.000.HW00.9, Build Date: 2018-12-17	V1.20.60	V1.20.60
5	HFD8GR1			
6	HDZ302DE	1.000.0043.3, Build Date: 2019-01-07	V1.20.60	V1.20.60
7	HDZ302D			
8	HDZ302DIN			

**Note:** The PTZ Model cameras (HDZ302DE, HDZ302D, HDZ302DIN) after the firmware upgrade will be compatible with MAXPRO NVR T-Patch 532 and above versions.


## How to get/configure Annotation Feature

To get and use the Annotation feature in MAXPRO NVR/VMS, user needs to perform the following configurations in the order as mention below:

1. Upgrade the Camera Firmware
2. Install the VA packages
  - c. Remove Old VA Package
  - d. Upgrade to Latest VA Package
3. Obtain the License to use Annotation feature
4. Configure and Enable Annotation in NVR
5. Enable Annotations in VMS

### Upgrade the Camera Firmware

- Step 1. Launch the Equip-S series model camera web page and then click on Setup tab.
- Step 2. Check the existing version of Firmware in Information > Version page.
- Step 3. In the left pane, navigate to System Setup > Upgrade. The Firmware Upgrade page is displayed as shown below.




- Step 4. Click the Import button and then browse the Firmware to import.
- Step 5. Click Upgrade. Once the upgrade complete, Firmware Upgrade successful message is displayed.

## Install the VA packages

### Remove Old VA Package

If the existing VA package is old then:

- Step 1. Navigate to Video Analytics > Smart Plan. The Smart Plan page is displayed.
- Step 2. Click on the Extensional Smart function tab as shown below.



- Step 3. Click Remove to remove the old VA package. Clear the alarm check box and then and save. Once it is saved click remove button, otherwise remove button will be in disable state only. Vice versa, it should be selected and saved to open VA Webpage.
- Step 4. Repeat the step 1 through step 3 to remove the old VA package of Loitering trace.

## Upgrade to Latest VA Packages


- Step 1. In th same camera web-page, navigate to System Setup > Upgrade. The Firmware Upgrade page is displayed as shown below.
- Step 2. Click the Import button and then browse the latest VA packages (Intrusion trace and Loitering trace) to import.
- Step 3. Click Upgrade. Once the upgrade complete, VA package upgrade successful message is displayed.

## Enable Extensional Smart Function

- Step 1. Navigate to Video Analytics > Smart Plan. The Smart Plan page is displayed.
- Step 2. If the Extensional Smart function is off, click to turn ON to configure and use Annotation feature.


## Obtain the License and install

- Step 1. Contact Honeywell Technical Support to obtain the license for Intrusion Trace and Loitering Trace features.
- Step 2. In the Extensional Smart function page, for a specific feature, click the Open button. For example Intrusion Trace as shown below.




The Honeywell Video Analytics page is displayed.

For Intrusion trace



For Loitering Trace





- Step 1. Click on Add Additional License button.
- Step 2. Enter the license key and then click OK to activate.


## Configuring Intrusion trace

### Pre-requisite:


Before you configure the Intrusion trace feature ensure you have:

- a. Upgraded the camera firmware.
- b. Upgraded the Intrusion trace VA package
- c. Obtained and installed the required license


Step 1. Click on the Configure tab, the Configure page is displayed as shown below. By default the Calibrate tab is selected.



Step 2. Click on Take Snapshot, read and perform the on screen instructions to adjust the current front marker as shown below.




Step 3. Under Current back marker, click on Take Snapshot, read and perform the on screen instructions to adjust the current back marker as shown below.




Step 4. Once done, click Save in the bottom of the page. Data saved successfully message is displayed.

- Step 5. Click on Zones and then click on Add area to add define the area for intrusion trace. This will be the area under which an alarm is generated if an object is detected. User can define multiple zones.



- Step 6. Read the on screen instructions and set the parameters for the zone such as Minimum width, Maximum width, Minimum height, Maximum height, Minimum area, Maximum area, Minimum speed, Maximum speed, Time and Distance acceptance, minimum time and minimum distance.
- Step 7. Click Save at the bottom of the page. Data Saved successfully message is displayed.
- Step 8. Click on Parameters and set the parameter for all the defined zones as shown below.



Step 9. Click Save at the bottom of the page. Data Saved successfully message is displayed.

Step 10. Click on the Live tab to view the configured intrusion feature.


## Configuring Loitering trace

### Pre-requisite:


Before you configure the Loitering trace feature ensure you have:

- a. Upgraded the camera firmware
- b. Upgraded the Loitering trace VA package
- c. Obtained and installed the required license.


- Step 1. Click on the Configure tab, the Configure page is displayed as shown below. By default the Calibrate tab is selected.




- Step 2. Click on Take Snapshot, read and perform the on screen instructions to adjust the current front marker as shown below.




- Step 3. Under Current back marker, click on Take Snapshot, read and perform the on screen instructions to adjust the current back marker as shown below.



- Step 4. Once done, click Save in the bottom of the page. Data saved successfully message is displayed.
- Step 5. Click on Zones and then click on Add area to add define the area for loitering trace. This will be the area under which an alarm is generated if an object found loitering more than the predefined time (Maximum Loitering time). User can define multiple zones.




- Step 6. Click Save at the bottom of the page. Data Saved successfully message is displayed.
- Step 7. Click on Parameters and set the parameter for all the defined zones. Such as maximum Loitering Time, Contrast sensitivity level, Object sensitivity level, Maximum static time and Times Strategy as shown below.





- Step 8. Click Save at the bottom of the page. Data Saved successfully message is displayed.
- Step 9. Click on the Live tab to view the configured Loitering feature. In camera web page user can see the loiter alarm in the list as shown below.




## Loitering Trace with PTZ Camera

For a PTZ camera Loitering trace should be configured with a predefined preset. If a camera has multiple presets then in camera web page the specific preset should be selected and saved in order to view the same in NVR.

However, Annotation will work with in the preset defined. if there is a minor variation beyond the preset area then Annotations will not be displayed.

The preset should be selected in camera web page > IVS Analysis > Smart Plan > Extensional Smart function > Preset as shown below.



## Configure and Enable Annotation in NVR

Annotation in NVR can be enabled if it is already configured in the supported camera web page. Equip-S series camera supports Annotation with Intrusion Trace and Loitering Trace.

Ensure you have completed the following in camera web page before enabling Annotation in NVR.

- a. Upgraded the camera firmware
- b. Upgraded the Intrusion and Loitering VA package
- c. Obtained and installed the required license
- d. Configured Intrusion and Loitering Trace features


### How to enable Annotation in NVR

#### In Camera Web Page

- Step 1. Navigate to Video Analytics > Smart Plan. The Smart Plan page is displayed.
- Step 2. If the Extensional Smart function is off, click to turn ON.
- Step 3. Select the Intrusion Trace or Loitering Trace check box to enable Annotation.

## In Preference Box


- In Preference > Rendering Setting tab, select the View Annotations when a camera is displayed check box to enable annotations for all the supported cameras (Equip-S Series)




- In Camera Properties, navigate to any stream and then select the Enable Annotation check box for the particular stream.

**Note:** For Sub stream 2 Annotation will not work, if the resolution is taken from camera sub stream 2. This is a camera side limitation.

For PTZ camera based on the Preset selection, annotation will not work if there is a slight movement beyond the defined preset.



- In Video panel, hover the mouse in the bottom of the panel to view the options and then click on Show Annotations for that particular camera as shown below. You can also click the same icon to Hide annotations only for that camera.




### Annotation with Intrusion Trace in VMS/NVR (Live/playback)

After the Annotation feature is enabled for Intrusion trace, rectangular bounding boxes will be accompanied with any moving object in the scene. If any object is moving within the predefined area then the object is highlighted with Red rectangular box and an alarm is generated as shown below.

Annotation with Intrusion Trace (Live) without alarm



Annotation with Intrusion Trace (Live) with alarm



Annotation with Intrusion Trace (Playback) Without alarm




Annotation with Intrusion Trace (Playback) With alarm




### Annotation with Loitering Trace in VMS/NVR (Live/playback)

If an object loiters within the predefined zone then a Green colored rectangular bounding box is displayed. If the same object loiters beyond the Maximum Loitering Time, then the object will be highlighted with a Red Rectangular box as shown below.


Object within the Maximum Loitering Time (Live)




Object beyond the Maximum Loitering Time (Live)



Loitering Trace in Playback without alarm



Loitering Trace in Playback with alarm



## Snapshots with Annotations

- Capturing snapshots with Annotation bounding box in Live and Recorded video is supported. User can find the captured snapshots under Snapshots/ Clips pane.




# Setting the Audio Codec in Camera Web Page

Latest version of Equip S Series V2 camera firmware will not render video in NVR with the previous versions of MAXPRO NVR 5.0/5.5. To overcome this issue user need to set the Audio codec for all the streams to AAC in the specific camera web page.

## How to set the Audio Codec

- Step 1. Logon to specific camera web page (for ex HBW4GR1V).
- Step 2. Navigate to Setup > Audio Setup > Audio. The Audio settings are displayed on the left pane as shown below.



- Step 3. Under Audio In area > Main Stream, select AAC from the Format drop-down list.
- Step 4. Under Sub Stream, select the Enable check box.
- Step 5. Select the required Sub Stream from the drop down list and then select AAC option from the Format drop-down list.
- Step 6. Under Audio Out area, select AAC from the Format drop-down list.
- Step 7. Click Save.

## Video Guard service for SIRA compliance

MAXPRO R600 release supports SIRA compliance with Video Guard Device Integration. This is to meet the specifications defined as part of the City wide Surveillance initiative by the Security Industry Regulatory Agency (SIRA) of Dubai, UAE, and being adopted across Middle-East countries.


User can run this service in NVR box to be in compliant with SIRA standards. To enable the service user needs to use MAXPRO Video Guard Configurator available in Bin folder. This configurator connects to MAXPRO NVR, sends the recorder information to video guard systems and synchronize the heartbeat messages (Polling) and system time.

**Note:** *Network time sync should be disabled when NVR is configured to communicate with Video Guard device.*


*It is required to restart NEO engine once the timezone is changed by Video Guard service.*

## How to run the WCF service using MAXPRO Video Guard Configurator

1. Navigate to MAXPRO NVR Bin folder and then locate the MAXPRO Video Guard Configurator.exe.
2. Double-click the exe. A login window is displayed as shown below.



3. Type the Username and Password in the box provided.  
Or  
Select Is Window User check box to login using windows credentials.
4. Click the Login button. The MAXPRO Video Guard Configurator application is displayed as shown below.



5. Select the Enable Video Guard Services check box. By default it is cleared.
6. Under Video Guard Device Configuration:
  - Type the Video Guard Device IP
  - Type the Site Number
7. Under NVR Configuration:
  - Select the NIC card from the drop down list
8. Click the Save button.

## NDAA HC Series 30 Camera Support

The following tables explain the list of supported camera models, firmware version and events supported with Series 30 cameras.

**Note:** Series 30 camera should be discovered with correct user name and password else the camera can lock out for 5 minutes.

#	Camera Models	Firmware Details
1	HC30W42R3	v1.0.18.20190523 Note: If a camera has older firmware, please upgrade to this version or above and perform factory default once
2	HC30W45R3	
3	HC30W45R2	
4	HC30WB2R1	
5	HC30WB5R1	
6	HC30WB5R2	
7	HC30WE2R3	
8	HC30WE5R3	
9	HC30WE5R2	
10	HC30WF5R1	

## Supported Events

The following events are support with Series 30 Camera Integration.:

Event
Motion Detection
Tamper Detection
Image too blur
Image too dark
Image too bright
People Detection
Intrusion

## Series 30 Cameras Features

HC Series 30 cameras supports the following features.

- Smart Stream III
  - Smart Codec
  - Smart FPS
  - Dynamic intra Frame Period (DIF)
- HTTPS

**Note:** HC30WF5R1 model camera does not support HTTPS.


- Alarms
- Profile S compliant
- Multicast

User need to configure the below Smart Stream III features at camera side to use it in NVR. These features helps the end user to reduce the bandwidth usage in the network. Once these features are configured user can add or discover the camera in NVR for surveillance purpose.


- Smart Codec: Based on region of interest in the scene the code format is automatically applied. The user can adjust the quality balance between ROI (Region of Interest) and non-ROI area. It is applicable only for H.264 and H.265 codec format. See [How to configure Smart Codec](#).
- Smart FPS: Dynamically manages and adjust the FPS based on the motion in the scene. If there is a high motion in the scene then higher FPS is utilized and vice versa. See [How to Enable Smart FPS](#)
- DIF (Dynamic intra Frame Period): Automatically adjusts the I frame interval time from 1 up to 10 seconds based on the motion in scene. See [How to Enable DIF](#)
- HTTPS: Allows user to enable secure communication for video over the network using secure protocol. See [How to enable Https for series 30 Cameras](#)

## How to configure Smart Codec


1. Log on to the HC30 Series camera.
2. Click the Setup tab. The General Settings page is displayed.
3. On the left pane, navigate to Camera Setup > Video. The Stream list is displayed o the right pane as shown below.



4. Click Video Settings for Stream 1. The Stream setting page is displayed.




5. Select the Codec format. Only H.265 and H.264 is supported. The corresponding settings are displayed.
6. Under Smart Stream III, select the Smart Codec check box. The Mode and Quality Priority options are displayed as shown below.




7. Select the required Mode from the drop-down list. The available options are
  - Auto tracking: Automatically sets the ROI and non ROI area for smart codec
  - Manual: Manually need to define the ROI and non ROI area for smart codec
  - Hybrid: Automatically sets the ROI and non ROI area for smart codec

**To manually set the mode:**

1. Select Manual option from the Mode drop-down list.
2. Click the Manual Window Settings. The video rendering page is displayed.




3. Click the New button to define or add new ROI and then click Save.
4. Click Close to complete defining ROI.
5. Under Quality Priority, move the slider left or right accordingly to balance the quality between ROI and non ROI region as shown below. Refer the camera page help for more details.




6. Click Save to complete the configuration. Similarly configure the Smart Codec manually for other streams.

## How to Enable Smart FPS

1. In the camera web page, click Setup > Camera Setup > Video > Video Settings for Stream 1. The Stream setting page is displayed.



2. Under Smart Stream III, select the Smart FPS check box as highlighted below.




3. Click Save. Similarly enable the Smart FPS manually for other streams




## How to Enable DIF

1. In the camera web page, click Setup > Camera Setup > Video > Video Settings for Stream 1. The Stream setting page is displayed.




2. Under Smart Stream III, select the Dynamic intra frame period check box as highlighted below. Refer the camera help for more details.



3. Click Save to complete enabling. Similarly enable the DIF manually for other streams

## How to enable Https for series 30 Cameras

1. Log on to the HC30 Series camera.
2. Click the Setup tab. The General Settings page is displayed.
3. On the left pane, navigate to Network Setup > HTTPS. The HTTPS tab is displayed on the right pane as shown below.



4. Under Mode, click HTTPS only option.
5. Under ONVIF, click HTTP & HTTPS option.
6. Under Streaming protocols, click HTTP & HTTPS option.

**Note:** Ensure that you select the options as mentioned above to secure the communication. HC30WF5R1 model camera does not support HTTPS.

7. Click Save to complete.

## Event Settings

Refer the HC Series 30 camera help on how to configure the events.

## MPEG2 Encoder Support

NVR 6.0 release supports legacy MPEG2 Encoders with Live and playback, Alarms and VMS in VMS functionalities. The following encoders are supported.

- ENC8M2
- VE8M2

Supported Firmware Version: 1.2.261

Supported Features are:

- Live
- Playback
- Export

**Note:** *It is not recommended to add Encoder/Multi-channel video stream across NEO storage.*

## Multicast Streaming IP for Encoder

MAXPRO NVR 6.0 supports multicast streaming IP configuration for encoders. User can assign a IP to view the encoder streams in multiple NVR clients.


## How to configure Multicast IP for ENC Encoder

Multicast Streaming IP address can be set in two ways:

- Using Encoder Web page
- Using VX Manager

### Using Encoder webpage

1. Launch the Encoder (ENC8M2 or VE8M2) web page.
2. On the left pane, navigate to Network Settings node > Streaming Address. The Streaming Address Settings page is displayed on the right pane.




3. In the Streaming Address Multicast box, type the multicasting IP address.


**Note:** *Unicast streaming IP address is not supported.*

## Using VX Manager

1. Launch the VX Manager and discover the required encoder as shown below.



2. Right-click on the required encoder and then click IP Settings. The Change IP Settings dialog box is displayed.



3. Under Streaming address area, select the Change check box to enable the 1st streaming address box.
4. Type the required multicast streaming IP address and then click OK. The Password box is displayed.
5. Type the password and then click OK. The IP address is updated and an Update Results status box is displayed.
6. Click OK to complete. Similarly you can change or assign the new IP address.
7. Add the encoder manually in NVR for video streaming.

## Configuring Remote Analytics Server

This section explains how to configure the remote analytics server for Mask and Social Distancing. It also explains how to revert a remote server machine.

## Scalable Analytics Server

This feature is introduced to manage the load on a NVR box while rendering analytics based cameras. Earlier only one local analytics server was available for multiple cameras that support analytics. This results in high consumption of CPU and low rendering capability of live video in NVR cameras.

Scalability feature helps customer to share the analytics server load on different remote machines and utilize the analytic algorithms efficiently. User can map the required cameras to each remote server and view the alarms in VMS,

A new tab named Analytics Server is introduced under Configurator tab to add additional analytics server and to choose the one while configuring Social Distancing, Mask compliance and SVMD features. This provides flexibility and increases the processing time to manage the load over analytics server when configuring multiple features.

- A maximum of 5 Analytics Remote boxes can be added under this tab.
- For each Analytics Remote box, 4 camera with 30 FPS and up to 8 cameras with 5 FPS can be assigned

**Note:** *If Mask & Social Distancing alarms are not coming after upgrading the NVR machine from previous market released version to current version (6.7) within stipulated time(15 Mins) then user need to restart the machine.*

## Converting a NVR Machine to a Analytics Remote Server


Any NVR machine can be converted into a Remote Analytics server to balance the analytics camera load on CPU. User need to ensure the below to convert a NVR machine to Analytics Server

- It should be an NVR machine without cameras. No cameras should be added
- All Neo services should be in stop state to minimize the load on analytic server.
- If you are using remote analytics servers, then ensure to enable encryption in remote analytics box as well. It is recommend to use different certificates for encryption. See [How to Encrypt the Remote Analytic Server](#) section.

In order to do ease the above steps for user, MaproNvrAnalyticServerConfigUtility is introduced. User can configure this in Remote machine to convert it to analytics server machine.

## How to configure Analytics Server

1. In Remote NVR machine, navigate to NVR Bin folder and locate MaproNvrAnalyticServerConfigUtility.
2. Run the Utility in Administrator mode. The Analytics Server Configuration dialog box appears.




3. Click the “Use as Analytics Server” toggle button to enable.
4. Under NVR Details, type the following details as explained below:
  - IP Address: This is IP address of the NVR machine where analytic cameras are added
  - Port Number of the NVR machine
  - User name and Password of the NVR machine
5. Click Save to complete the configuration.

**Note:** If Mask & Social Distancing alarms are not coming in NVR machine from the remote analytic server even after applying the encryption, then user need to reapply the encryption certificate again in remote analytic server.

## How to Encrypt the Remote Analytic Server


1. In Remote NVR machine, navigate to NVR Bin folder and locate MaproNvrAnalyticServerConfigUtility.
2. Run the Utility in Administrator mode. The Analytics Server Configuration dialog box appears.




3. Click the “Use as Analytics Server” toggle button to enable.
4. Click the Certificate Setting tab.
5. Under Application Security, click the Certificate Based Encryption option.
6. Type the following details as explained below:
  - Certificate File Path: Browse to select the certificate.
  - Certificate Password: Type the certificate Password
  - Certificate Store Name: Type the certificate Store Name
  - Certificate Subject Name: Type the certificate subject name
7. Click Import Certificate button.
8. Click Save to complete the configuration.

## How to Add Analytics Server in NVR Machine

1. In the Configurator > Camera tab, click the Analytics Server tab. The Analytics Server screen is displayed with the list of analytics server already configured.



2. Click Add Server from the right most corner of the screen.




3. For the New Remote Analytics Server provide Server Name, IP Address and Port Number of the server.
4. Click Save to add the new analytics server.



## Manging Cameras for Analytics Server

This window allows you to assign analytics server to multiple cameras in bulk. If you have multiple analytics server then you can associate specific cameras to view the alarms accordingly.


1. In the Analytics Server screen, click Manage Cameras from the right most corner of the screen. The Manage Camera dialog box is displayed.




2. From the Analytics Server drop-down, select the required server. This selection applies to all the cameras that will be associated in next steps.
3. From the Available Cameras pane, select the required camera check boxes to associate
4. Click Save. The selected cameras are displayed in Associated Cameras pane.


**Note:** If you want to assign a different analytic server to a specific camera, then under Associated Cameras > Associated Camera Server, select the required server from the drop down list.

## Editing Remote Analytics Server Details

1. In the list of Analytics Server, click . The Analytics Server Details box is displayed. By default General tab is displayed.



2. Under Server Details, edit the Name, IP Address and Port number of the NVR machine.
3. Click Camera tab to view the list of cameras associated.



4. To add or delete the associated cameras, then click the Manage Camera link to view the Manage Camera dialog box, See [Managing Cameras for Analytics Server](#) section.
5. Click Save.

## Bulk configurations of cameras from NVR


This feature allows you to perform Bulk camera configuration for main and sub stream's, to ease the effort of configuring multiple cameras at the customer site. This feature improves the productivity for dealers and system integrators while configuring many NVRs. The configuration of cameras from the NVR is done one by one today (either post discovery or manual addition). This leads to higher lead time to configure and setup customer sites.

You can perform the following using Bulk configuration screen:


- General Settings
- Schedule Settings
- Preference Settings
- Stream Settings including child stream configurations specific to camera model
- SVMMD Configuration

### How to configure General Settings for cameras in bulk

1. In the camera tab, click Bulk Configure button at the bottom of the screen. The Bulk Configure screen is displayed.




2. Select the required number of camera check boxes and then click the General Setting button. The General Setting dialog box is displayed.



**Note:** The Stream Settings and Preferences buttons will be enabled while configuring Child Streams. User need to enable Child Streams toggle button to configure streams.


3. In PTZ tab, select the Device Type from the drop down list.
4. Click Other Settings tab, select Enable Anonymization and Environment Preferences options from the drop-down list.




5. Click Apply to complete general settings for the selected cameras.

# How to configure Schedule Settings for cameras in Bulk

1. Navigate to the Bulk Configure screen.



2. Select the required number of camera check boxes and then click the Schedule button. The Schedule dialog box is displayed.




3. On Selected camera pane, the list of selected camera are displayed. You can also search and remove the cameras from here.

4. Select and enter the following as explained below:
  - Continuous - Select the FPS for Continuous recording.
  - Event - Select the FPS for Event based recording.
  - Recording Deletion After (In Days):
    - Select the Event Recording video deletion duration.
    - Select the Continuous Recording video deletion duration.
  - Archive Recording After:
    - Continuous - This is “None” by default. Select an option from the drop-down if you want to archive the continuous recording.
    - Event - This is “None” by default. Select an option from the drop-down if you want to archive the event recording.
  - Archive Deletion After Recording After:
    - Continuous Recording - This is “365 Days” by default. Select the number of days from the drop-down after which the archived continuous recording can be deleted.
    - Event Recording - This is “365 Days” by default. Select the number of days from the drop-down after which the archived event recording can be deleted.
5. Click Apply to complete the configuration.



## How to configure Preferences for cameras in Bulk

**Note:** Preferences setting is applicable only to the specific stream index. User has to select same stream either stream 1 2 or 3 and then click preference to apply settings .


1. Navigate to the Bulk Configure screen and then enable the Child Streams toggle button as shown below.



2. Select the required cameras of same stream.  
Or  
Select the required stream from the Streams drop-down list as shown below.



3. Click the Preferences button. The Preferences dialog box is displayed.




4. On Selected camera pane, the list of selected camera are displayed. You can also search and remove the cameras from here
5. Perform the following as explained below:
  - Live - Select the preferred stream of the camera which you want to use for streaming live video.
  - Continuous - Select the preferred stream of the camera which you want to record continuously.
  - Event Recording - Select the preferred stream of the camera which you want to record on events.
  - Mobile/Web - Select the preferred stream of the camera which you want to use for streaming in Mobile/Web application.
  - High - Select the preferred stream of the camera which you want to categorize as High Resolution stream.
  - Low - Select the preferred stream of the camera which you want to categorize as Low Resolution stream.
  - Click Apply to complete the configuration

## How to configure Stream Settings for cameras in Bulk

**Note:** Stream setting is applicable only to the specific camera models. User need to select the camera models which supports multiple streams.




1. Navigate to the Bulk Configure screen and then enable the Child Streams toggle button as shown below.




2. Select the required cameras of same model.  
Or  
Select the required model of camera from the Model drop-down list as shown below.


**Note:** If cameras with different models are selected then a message, Stream of same model should be selected is displayed at the bottom of the screen. Click OK to proceed.



The selected models are displayed as shown below:



3. Click the Stream Setting button. The Stream Setting dialog box is displayed.




4. On Selected camera pane, the list of selected camera are displayed. You can also search and remove the cameras from here
5. Under Video configure the following as explained below:
  - Resolution - The Resolution is defaulted based on the camera model (for example, HD3MDIP model defaults to 1280 x 720 resolution).
  - Frame Rate - Select the FPS for a camera. FPS refers to the number of pictures displayed in exactly one second. FPS is a measure of how much information is used to store and display motion video. The term applies to digital video. Each frame is a still image; displaying frames in quick succession creates the illusion of motion.
  - Video Codec Type - Select the Codec type for the camera. This is populated based on the camera model selected. H.265 cameras can render in both CPU and GPU modes.
  - Compression Level - The Compression Level is defaulted to “Medium”. You can select a new Compression ratio as applicable.


- Video Format - Select the Video Format (NTSC or PAL). The NTSC and PAL are the widely used video formats.
  - GOP - Type a new GOP as applicable. Group of Pictures (GOP) are individual frames (number of pictures) that are grouped together and played back for viewing. A GOP consists of “IFrame” picture type that represents a fixed image independent of other picture types. Each GOP begins with this type of picture.
  - Continuous Recording (5 FPS) - Select the FPS for Continuous recording.
  - Event Recording (5 FPS) - Select the FPS for Event based recording.
  - Under Other Parameters
    - Select the On Demand Streaming options from the drop-down list.
    - Enable Audio In/Out: This is for audio supported camera. Select the required In and Out option from the drop-down list.
6. Click Apply to complete the configuration

## How to configure SVMD for cameras in bulk

1. Navigate to the Bulk Configure screen.



2. Select the required number of camera check boxes and then click the SVMD Configuration button. The Analytics Configuration dialog box is displayed.



**Note:** The Image what u see here is from first camera of NVR  
 Only Enable SVMD and Region configuration can be done in this dialog box.  
 Associating cameras to Analytics server has to be done from either camera configuration window or from Analytics Server tab.

3. Select the Enable SVMD Configuration check box
4. Under Regions, click the Include Region button to create required numbers of region(s) on the image.
5. Select the required region to display from the Region drop-down. Available options are All, None or (Region 1, 2, 3 and so on). Configure the Object size threshold if required.
6. If you want to exclude any region then select the region using mouse and then click Exclude Region button.
7. Under Alarm Settings, set the Alarm Hod time in seconds.
8. Click Save to complete the configuration.

## Bi-Directional Audio Support for MAXPRO NVR


This feature helps an operator to send Bi-directional audio warnings/messages to any audio output of cameras from MAXPRO VMS machines. Currently Mic and speech is supported from VMS viewer only.

This feature supports standard audio Codec format G.711 ulaw and only Honeywell ONVIF Camera model are supported.


- Note:** *Only Honeywell ONVIF Camera models are supported.  
Only fixed G.711 ulaw Codec format is supported.  
Mutlistream is supported, but can be enabled in only one stream at a time.  
It is recommended for the user to enable and speak for one camera at a time.  
Windows 2016, 2019 windows server machines are not supported for beta release.*

## How to configure Bi-Directional Audio for a camera

1. In NVR, for a Honeywell Onvif camera, navigate to Camera properties > Primary Stream > Recording tab.



2. For a specific stream, select the Enable Audio In/Out check boxes as explained below:
  - Enable Audio In: Camera to VMS Operator
  - Enable Audio Out: Operator to camera connected with speakers.
3. In VMS > Viewer screen. select the audio enabled camera in the panel (One at a time) and then enable the Mic button on the Timeline bar to speak and Disable the Mic button to end the speech as highlighted below.



## Limitation

- AAC compression format is not supported for Audio Out from MAXPRO NVR. It is recommended to configure G711 u law as Audio Out compression format in the camera webpage.
- From NVR to VMS, user will notice a latency of 1.5 Seconds in audio.

## Series 60 Camera Integration

MAXPRO VMS R670 supports Series 60 Camera integration with MAXPRO NVR 6.7 recorder. The following tables explain the list of supported camera models, and events/alarms supported.

Type	Camera Models	Firmware Details
Premium Model	HC60W35R2	Honeywell_L60- Series_IPC_HC60WXXRX_V1.0.21.20200 828
	HC60W35R4	
	HC60W45R2	
	HC60W45R4	
	HC60WB5R2	
	HC60WB5R5	
	HC60WZ2E30	
Mainstream Model	HC60W34R2L	
	HC60W34R2	
	HC60W44R2L	
	HC60W44R2	
	HC60WB4R2L	
	HC60WB4R2	

Series60 IR PTZ	HC60WZ5R30	
Series30	HC30W25R3-12V	

## Configuring Social Distancing ROI Duration and Show

User can configure the Registry entries to increase the duration of alarms generation for a specific time and highlight the same using color indication.

Following are the two parameters that are allowed to configure:

- **sdGraphicROIDuration** : The Non-complaint Social Distancing Regions alarm is generated for every 5 hours (By Default). The Value of this key is in Minutes (By Default 300 Mins (5 hours))
- **sdGraphicROIShow**: This key is used for displaying when alarm occurs then in live view user can see the regions in specific color coding based on number of violations occurred. For example
  - the highest violated region more than 80% is RED
  - 20 to 80 percent region violated is YELLOW
  - the succeeding less value (Less than 0) is displayed in GREEN

Perform the below steps to modify the values:

1. Navigate to Computer\HKEY\_LOCAL\_MACHINE\SOFTWARE\WOW6432Node\Honeywell\TrinityFramework\RenderingServer
2. Locate sdGraphicROIDuration and then change the value (By Default 300 Mins (5 hours)).
3. Locate the sdGraphicROIShow and then change the color code value.

This page is intentionally left blank



# VERIFYING THE CONFIGURATION

## Overview

Verifying the configuration of the MAXPRO NVR is the final phase in the commissioning process. In this phase, you need to verify the working of the MAXPRO NVR.

## Before you Begin

Ensure that the configuration of MAXPRO NVR is complete.

## Activities to Perform in this Phase

In this phase, using the MAXPRO NVR user interface, check for the following one after the other.

- Connection with the MAXPRO NVR sever (logging on)
- Camera listing in the devices window
- Live video display from cameras
- Playback of recorded video
- Inserting comments and marking the point of interest using the bookmark feature in Timeline window
- Playback of loop (mark in and mark out feature) in Timeline window
- Panning, tilting, and zooming functions
- Acknowledgment of alarms and clearing of alarms
- Image creation
- Clip creation
- Video from the surrounding cameras (video pursuit or surrounding cameras feature in MAXPRO NVR)
- Saving the salvo layout using the salvo view feature
- Searching recorded video in MAXPRO NVR

- Generating and viewing the event and operator log report

## Checking the Connection with the MAXPRO NVR Server

The MAXPRO NVR server addresses are stored in profiles. You can save the address of each server in profiles from the Log On dialog box that appears when you start MAXPRO NVR.

To connect to a MAXPRO NVR server from the client computer

Step 1. In the Username box, type the user name. The default user name is “admin”.

Step 2. In the Password box, type the password. The default password is “trinity”.

**Note:** Honeywell recommends to create a new NVR user (See [Adding a User](#) ) in the Configurator tab and use the same to logon.

Step 3. In the Profile box, select the profile in which the server address is saved.

Step 4. Click Login. The Viewer Screen appears.

You can set a profile as the default profile. When a profile is set as default, you need not select the profile each time you log on to MAXPRO NVR. You can also modify and delete profiles.

**Note:** See the [Configuring MAXPRO NVR Windows/ Desktop Client](#) section on page 124 for more information on how to save server addresses in profiles, how to set a profile as default profile, and how to modify and delete the profiles.

## Checking the Device listing in the Devices Window

By default, the Viewer tab is selected when you log on to MAXPRO NVR. The Devices window in the Viewer tab lists the IP cameras connected to and discovered by MAXPRO NVR.

See the [Getting to Know the MAXPRO NVR User Interface](#) section on page 130 for more information on the Device window.

## Checking the Acknowledgment and Clearing of Alarms

Clicking the Alarms tab next to the Device tab opens the Alarms window that lists all the alarms in a floating window. You can acknowledge and clear the alarms.

Alarms notify the occurrence of events to the operators. You can configure alarms to be triggered when events such as recorder disk space nearing full, motion detection, and others happen. The events that trigger an alarm can be selected while configuring the recorders, cameras, and switchers. The events can be associated to event groups.

Each alarm goes through the following states.

#### New or Unacknowledged

When an alarm is triggered it appears in the Alarm window. You can click the Alarm tab to view the Alarm window. The state of the alarm after it is triggered is referred to as unacknowledged. You can view the list of all the unacknowledged alarms in a table in the Alarm window.

See the [Getting to Know the MAXPRO NVR User Interface](#) section on page 130 for more information on the Alarms.

## Checking the Live Video from Cameras

To ensure that all the cameras are connected and functioning properly, you need to check for live video from them.

To select the cameras and view live video

- Double-click a camera in the Devices window.  
Or  
You can also drag a camera to a panel in the salvo layout. The panel starts displaying live video.

You can select multiple cameras and view live video in different panels of the salvo layout.

See the [Getting to Know the MAXPRO NVR User Interface](#) section on page 130 for more information on how to view live video from cameras.

## Checking the Playback of Recorded Video

To playback video, the recording from the camera must be available and the recording settings for the camera must be configured. Recorded video can be played from the Timeline window.

The following operations can be performed on the recorded video.

- Playing recorded video using the timeline
- Playing recorded video using Mark In and Mark Out points in timeline
- Marking points of interest in the timeline using bookmarks

Refer to the [MAXPRO® NVR Operator's Guide](#) for more information on how to configure the recording settings for the cameras connected to MAXPRO NVR.

## Checking the Panning, Tilting, and Zooming

Using the digital PTZ feature in MAXPRO NVR, you can perform panning and tilting on live and recorded video and clips. The digital PTZ feature when enabled allows you to perform panning and tilting on the video display that is zoomed or enlarged in a panel.

Refer to the [MAXPRO® NVR Operator's Guide](#) for more information on PTZ.

## Checking the Creation of Images

A frame of video displayed in the panel can be saved as an image. The image can be saved in Bitmapmed Graphics (BMP), Joint Photographic Experts Group (JPG) format, Portable Graphics format (PNG), and Graphics Interchange Format (GIF).

Only the images saved in the Snapshots/Clips folder at the location in the hard drive in which MAXPRO NVR files are installed can be viewed in the Snapshot/Clip window.

You can double-click the image view option in the site window to view images on the salvo layout. You can view the images in the form of thumbnails or filmstrip. You can also select the image size large, medium, and small as per the requirement.

For example, X:\ProgramFiles\Honeywell\TrinityFramework\Snapshots/Clips. Here, X: is the hard drive.

Refer to the [MAXPRO® NVR Operator's Guide](#) for more information on creating the images.

## Checking the Creation of Clips

You can create clips from recorded video. These clips can be saved with digital signatures. Digital signatures ensure authenticity of clips. Digital signatures are primarily used to authenticate videos that are produced in courts as evidence. A digital signature generates a unique string for the clip using algorithms recommended by the W3C. The World Wide Web Consortium (W3C) is an international consortium where member organizations, a full-time staff, and the public work together to develop Web standards. If the video in the clip is modified, a verification check for the unique string fails indicating that the content is tampered. When a clip is saved with the digital signature, a package file with the .PKG extension is created to save the clip.

Refer to the [MAXPRO® NVR Operator's Guide](#) for more information on creating clips.

## Checking the Salvo View Feature

A salvo layout that is customized based on the preferences of the operators is referred to as a salvo view. Cameras and scan sequences that are selected frequently and the preferred salvo layout can be saved as a salvo view.

Refer to the [MAXPRO® NVR Operator's Guide](#) for more information on how to create, select, and manage salvo views.

## Checking the Search for Recorded Video in MAXPRO NVR

Operators can search for recorded video from cameras connected to MAXPRO NVR. The search results can be filtered based on conditions like video recorded today, yesterday, and others.

You can search for recorded video from the Search tab.

Refer to the [MAXPRO® NVR Operator's Guide](#) for more information on how to search for recorded video, and how to play the search results.

## Checking the Generation of Event History/ Operator Log Report

Two types of reports, namely event history report and operator log report, can be generated.

The event history report can be generated for cameras, monitors, and recorders. The event history report lists the events related to a device during a time period. For example, for a camera, you can generate the event history report to know the occurrence of events like enabling of camera motion detection, starting of background recording, and so on.

The operator log report can be generated to view the activities performed by users. The operator log report lists the activities performed by users during a time period. For example, creating clips, adding bookmarks.

You can generate reports from the Report tab.

Refer to the [MAXPRO® NVR Operator's Guide](#) for more information on how to generate and view the reports.

This page is intentionally left blank.

# UPGRADE MAXPRO NVR SOFTWARE

## Overview

This chapter describes the procedures to upgrade the MAXPRO NVR software. Follow the appropriate section in this chapter to upgrade your MAXPRO NVR software.

The following are the upgrade scenarios covered:

- [Upgrade to MAXPRO NVR 6.7 Build 687](#)
- [Upgrade to MAXPRO NVR 6.3 Build 643](#)
- [Upgrade to MAXPRO NVR 6.0 Build 622](#)
- [Upgrade to MAXPRO NVR 5.6 \(Build 572\)](#)
- [Upgrade to MAXPRO NVR 5.5 \(Build 558\)](#)
- [Upgrade to MAXPRO NVR 5.0 SP1 \(Build 532\)](#)
- [Upgrade to MAXPRO NVR 5.0 Build 522 \(T Patch\)](#)
- [Upgrade to MAXPRO NVR 5.0 Build 509 Rev D](#)
- [Upgrade to MAXPRO NVR 4.9 Build 204](#)
- [Upgrade to MAXPRO NVR 4.7 Build 188](#)
- [Upgrade to MAXPRO NVR 4.5 Build 162](#)
- [Upgrade to MAXPRO NVR 4.1 Build 123 Rev B](#)
- [Upgrade to MAXPRO NVR 4.0](#)

**Note:** Downgrade to previous version of NVR is only supported if user has restored the Database backup during installation. For example: If user upgrades from 4.1 to 5.0 and if for any reason uninstalls the 5.0 build then, 4.1 installation will also be uninstalled from the machine. If user has restored the DB backup during 5.0 installation then downgrade (4.1) build will be available..

### Upgrade to MAXPRO NVR 6.7 Build 687

Upgrade to 6.7 is supported from the following build only:

- MAXPRO® NVR 6.3 Build 643
- MAXPRO® NVR 6.0 Build 622


Below tables explains the upgrade support to MAXPRO and Pro-Watch R670:

Upgrade Support	MNVR/MVMS 670	Retain License	Change to Demo License
MNVR/MVMS 600	✓	✓	✗
MNVR/MVMS 630	✓	✓	✗
PNVR/PVMS 650	✗	NA	NA
PNVR/PVMS 650 SP1	✗	NA	NA

Upgrade Support	PWNVR/PWVMS 670	Retain License	Change to Demo License
MNVR/MVMS 600	✓	✗	✓
MNVR/MVMS 630	✓	✗	✓
PWNVR/PWVMS 650	✓	✓	✗
PWNVR/PWVMS 650 SP1	✓	✓	✗


To upgrade to NVR 6.7:

- Step 1. Insert the MAXPRO NVR 6.7 setup DVD in the DVD drive, browse the DVD drive, and then double-click setup.exe. A dialog box appears with the question - “Do you want to validate the setup before continuing MAXPRO NVR 6.7 installation?”.




- Step 2. Click Yes to validate the setup files are not corrupted before continuing the installation and click No to skip the validation to continue the setup. The installation wizard starts and the Welcome screen appears.





### Welcome Wizard

Step 3. Click Next. The Validation of User Credentials appears.



### Validation of User Credentials


Step 4. Select your Domain Name/Host Name.

Step 5. Type your Windows User Name.

Step 6. Type your Windows Password.

**Note:** Honeywell recommends to use the newly created Administrator user account as explained in [Before you Begin - Changing the default Windows Administrator Account Created By NVR](#), page 103.

Step 7. Click Next. The Localization Support wizard appears.




### Localization Support



**Caution: By Default, English language will be installed. Please ensure to select all the languages required for your system. If an additional language is required after the installation is completed, the software will need to be uninstalled and installed again.**


Step 8. Select the languages in which you want to upgrade MAXPRO NVR and then click Next. The Data Security Wizard appears.



### Data Security


Step 9. Select the Enable Enhanced Data Security check box to improve data security in your system.

Step 10. Click Next. The Summary wizard appears.



### Upgrade Summary

Step 11. Click Next. The upgrade status of various components appears. Once the upgrade is complete, the Finish dialog appears.



### Upgrade Finish

Step 12. Click Finish to complete the upgrade.

## Upgrade to MAXPRO NVR 6.3 Build 643

Upgrade to 6.3 is supported from the following build only:

- MAXPRO® NVR 6.0- Build 622

To upgrade to MAXPRO\_NVR\_6.3:

- Step 1. Browse to the setup folder and double-click MAXPRO\_NVR\_6.3 Setup.exe. The installer extracts the setup files and a confirmation message is displayed to disable the Automatic Windows updates.
- Step 2. Click Yes to proceed, the installation wizard starts and the Welcome page appears.
- Step 3. Click Continue to start the installation. The installation process continues and once the installation is complete the completion page is displayed.
- Step 4. Click Finish to complete the installation and close the wizard.

## Upgrade to MAXPRO NVR 6.0 Build 622

Upgrade to 6.0 is supported as explained below:

- MAXPRO® NVR 6.0- Build 615
- MAXPRO® NVR 6.0- Build 612
- MAXPRO® NVR 5.6- Build 583
- MAXPRO® NVR 5.6- Build 572
- MAXPRO® NVR 5.5- Build 560
- MAXPRO® NVR 5.5- Build 559
- MAXPRO® NVR 5.0 SP1- Build B532
- MAXPRO® NVR 5.0\_T patch Build 522
- MAXPRO® NVR 5.0 Build 509 Rev D

## Before Upgrading



**Caution:** If user had configured the Network drive as Recording drive in the previous version of NVR, then after upgrading to 6.0 Build XXXX, none of the cameras will display video. Ensure that you delete/modify the Network path configured as Recording drive and then upgrade.

## Pre-requisite

Before upgrading to MAXPRO NVR 6.0, user must install the below SQL service pack for successful upgrade. Refer to the [800-26010-A - Securing MAXPRO VMS-NVR Technical Notes](#) for more information on how to download and install the below service pack.


- SQL2012SP4

To upgrade to NVR 6.0:


Step 1. Insert the MAXPRO NVR 6.0 setup DVD in the DVD drive, browse the DVD drive, and then double-click setup.exe

Or

Go to the MAXPRO NVR setup folder on your computer, and then double-click setup.exe. In Choose Installation Type wizard, click Upgrade Existing Installation option.




Step 2. Click Next. A dialog box appears with the question - “Do you want to validate the setup before continuing MAXPRO NVR 6.0 installation?”, click Yes to validate the setup files are not corrupted before continuing the installation and click No to skip the validation to continue the setup. The installation wizard starts and the Welcome screen appears.



### Welcome Wizard

Step 3. Click Next. The Validation of User Credentials appears.



### Validation of User Credentials


Step 4. Select your Domain Name/Host Name.

Step 5. Type your Windows User Name.

Step 6. Type your Windows Password.

**Note:** Honeywell recommends to use the newly created Administrator user account as explained in [Before you Begin - Changing the default Windows Administrator Account Created By NVR](#), page 103.

Step 7. Click Next. The Localization Support wizard appears.




#### Localization Support



**Caution: By Default, English language will be installed. Please ensure to select all the languages required for your system. If an additional language is required after the installation is completed, the software will need to be uninstalled and installed again.**


Step 8. Select the languages in which you want to upgrade MAXPRO NVR and then click Next. The Data Security Wizard appears.



### Data Security

Step 9. Select the Enable Enhanced Data Security check box to improve data security in your system.


Step 10. Click Next. The Summary wizard appears.



### Upgrade Summary

Step 11. Click Next. The upgrade status of various components appears. Once the upgrade is complete, the Finish dialog appears.





### Upgrade Finish

Step 12. Click Finish to complete the upgrade.


## Upgrade to MAXPRO NVR 5.6 (Build 572)

Upgrade to NVR 5.6 Build 572 is supported from the following builds only.


- MAXPRO NVR v5.0 Build 509 Rev D
- MAXPRO NVR 5.0\_T patch Build 522
- MAXPRO NVR 5.0 SP1 Build 532
- MAXPRO NVR 5.5 Build 558

To upgrade to MAXPRO\_NVR\_5.6:

Step 1. Browse to the setup folder and double-click MAXPRO\_NVR\_5.6 Setup.exe. The installer extracts the setup files and a confirmation message is displayed to disable the Automatic Windows updates as shown below.




Step 2. Click Yes to proceed, the installation wizard starts and the Welcome page appears.



#### Welcome Wizard

Step 3. Click Continue to start the installation. The installation process continues and once the installation is complete the completion page is displayed as shown below.



#### Installation Complete

Step 4. Click Finish to complete the installation and close the wizard.

## Upgrade to MAXPRO NVR 5.5 (Build 558)


Upgrade to NVR 5.5 Build 558 is supported from the following builds only.

- MAXPRO NVR v5.0 Build 509 Rev D
- MAXPRO NVR 5.0\_T patch Build 522


- MAXPRO NVR 5.0 SP1 Build 532

To upgrade to MAXPRO\_NVR\_5.5:

- Step 1. Browse to the setup folder and double-click MAXPRO\_NVR\_5.5 Setup.exe. The installer extracts the setup files and a confirmation message is displayed to disable the Automatic Windows updates as shown below.




- Step 2. Click Yes to proceed, the installation wizard starts and the Welcome page appears.



#### Welcome Wizard

- Step 3. Click Continue to start the installation. The installation process continues and once the installation is complete the completion page is displayed as shown below.



#### Installation Complete

Step 4. Click Finish to complete the installation and close the wizard.

### Upgrade to MAXPRO NVR 5.0 SP1(Build 532)


Upgrade to 5.0 Service Pack 1 is supported from the following builds only.

- MAXPRO NVR v5.0 Build 509 Rev D
- MAXPRO\_NVR\_5.0\_T patch Build 522


**Note:** If SP1 is installed on top of 5.0 Build 509 Rev D then MAXPRO\_NVR\_5.0\_T patch Build 522 is installed internally.

To upgrade to MAXPRO\_NVR\_ R500\_SP1

Step 1. Double click MAXPRO\_NVR\_ R500\_SP1 Setup.exe. The installer extracts the files and displays the Windows update message.




Step 2. Click Yes to proceed, the installation wizard starts and the Welcome page appears.



### Welcome Wizard

- Step 3. Click Continue to start the installation. The installation process continues and once the installation is complete the completion page is displayed as shown below.



### Installation Complete

- Step 4. Click Finish to complete the installation and close the wizard.

## Uninstalling SP1

In Add/Remove program windows there will be two entries as:

- MAXPRO\_NVR\_ 5.0\_T patch Build 522
- MAXPRO\_NVR\_ 5.0 SP1 Build 531

If user wants to go back to v5.0 Build 509 Rev D then from Add/Remove Program window uninstall the applications in the order as mentioned below:


- Step 1. Uninstall SP1  
Step 2. Uninstall 5.0\_T patch Build 522

## Upgrade to MAXPRO NVR 5.0 Build 522(T Patch)


Upgrade to 5.0 T patch is supported from v5.0 Build 509 to MAXPRO NVR 5.0 Build 522 only.

To upgrade to MAXPRO\_NVR\_ R500\_T patch

- Step 1. Double click MAXPRO\_NVR\_ R500\_T patch Setup.exe. The WinRAR self extracts the files and displays the Windows update message.



- Step 2. Click Yes to proceed, the installation wizard starts and the Welcome page appears.



### Welcome Wizard

- Step 3. Click Continue to start the installation. The installation process continues and once the installation is complete the completion page is displayed as shown below.



#### Installation Complete

Step 4. Click Finish to complete the installation and close the wizard.

## Upgrade to MAXPRO NVR 5.0 Build 509 Rev D

Upgrade to 5.0 is supported as explained below:

- From v4.0 Build 87 Rev H to MAXPRO NVR 5.0 Build 509 Rev D
- From NVR 4.1 Build 123 Rev B to NVR 5.0 Build 509 Rev D
- From NVR 4.5 Build 162 Rev B to NVR 5.0 Build 509 Rev D
- From NVR 4.7 Build 188 to NVR 5.0 Build 509 Rev D
- From NVR 4.9 Build 204 to NVR 5.0 Build 509 Rev D

## Before Upgrading




**Caution:** If user had configured the Network drive as Recording drive in the previous version of NVR, then after upgrading to 5.0 Build 509, none of the cameras will display video. Ensure that you delete/modify the Network path configured as Recording drive and then upgrade.

To upgrade to NVR 5.0:

Step 1. Insert the MAXPRO NVR 5.0 setup DVD in the DVD drive, browse the DVD drive, and then double-click setup.exe


Or

Go to the MAXPRO NVR setup folder on your computer, and then double-click setup.exe. A dialog box appears with the question - “Do you want to validate the setup before continuing MAXPRO NVR 5.0 installation?”, click Yes to validate the setup files are not corrupted before continuing the installation and click No to skip the validation to continue the setup. The installation wizard starts and the Welcome screen appears.



### Welcome Wizard

Step 2. Click Next. The Validation of User Credentials appears.



### Validation of User Credentials

Step 3. Select your Domain Name/Host Name.


Step 4. Type your Windows User Name.



Step 5. Type your Windows Password.

**Note:** Honeywell recommends to use the newly created Administrator user account as explained in [Before you Begin - Changing the default Windows Administrator Account Created By NVR](#), page 103.

Step 6. Click Next. The Localization Support wizard (Figure ) appears.




**Localization Support**




**Caution: By Default, English language will be installed. Please ensure to select all the languages required for your system. If an additional language is required after the installation is completed, the software will need to be uninstalled and installed again.**

- Step 7. Select the languages in which you want to upgrade MAXPRO NVR and then click Next. The Summary screen appears.



### Summary

- Step 8. Click Next. The upgrade status of various components appears. Once the upgrade is complete, the Finish dialog appears.



### Upgrade Finish

Step 9. Click Finish to complete the upgrade.

**Note:** While upgrading the client to 5.0, a System Warning dialog with Unknown Hard Error message is displayed

*Cause:* This issue may occur due to conflict between third party applications or due to system file corruption.

*Solution:* Refer and perform the steps as explained in the Microsoft link [https://answers.microsoft.com/en-us/windows/forum/windows\\_8-performance/explorerexe-system-warning-dialog-with-unknown/4c0be311-c9d5-46e7-b352-c8656f5c0226?auth=1](https://answers.microsoft.com/en-us/windows/forum/windows_8-performance/explorerexe-system-warning-dialog-with-unknown/4c0be311-c9d5-46e7-b352-c8656f5c0226?auth=1)

Or

<https://www.drivethelife.com/windows-10/fix-unknown-hard-error-windows-10.html>


## Upgrade to MAXPRO NVR 4.9 Build 204

Upgrade to 4.9 is supported as explained below:

- From NVR 4.0 87 Rev H to NVR 4.9 Build 204
- From NVR 4.0 97 Rev B to NVR 4.9 Build 204
- From NVR 4.1 Build 123 Rev B to NVR 4.9 Build 204
- From NVR 4.5 Build 162 Rev B to NVR 4.9 Build 204
- From NVR 4.7 Build 188 to NVR 4.9 Build 204

To upgrade to MAXPRO NVR 4.9 Service Pack


Step 1. Double click MAXPRO NVR 4.9 Setup.exe. The WinRAR self extracts the files and displays the Windows update message.



Step 2. Click Yes to proceed, the installation wizard starts and the Welcome page appears.

### Installation Complete

Step 1. Click Yes if required. The installation process continues and once the installation is complete the completion page is displayed as shown below.



Step 2. Click Finish to complete the installation and close the wizard.

**Note:** If Korean language is not installed in your previous build (such as NVR 4.5 Build 162 or 4.7 Build 188) then a confirmation message to support Korean Language is displayed. Click Yes if required.


## Upgrade to MAXPRO NVR 4.1 Build 123 Rev B

Upgrade is supported as explained below:

- From NVR 4.0 87 Rev H to NVR 4.1 Build 123 Rev B
- From NVR 4.0 87 Rev H SP1 to NVR 4.1 Build 123 Rev B
- From NVR 4.0 87 Rev H (beta) to NVR 4.1 Build 123 Rev B

To upgrade to MAXPRO NVR 4.1 Service Pack

Step 1. Double click MAXPRO NVR 4.1 Setup.exe. The WinRAR self extracts the files and displays the Windows update message.



### Installation Complete

Step 4. Click Finish to complete the installation and close the wizard.

## Upgrade to MAXPRO NVR 4.7 Build 188


Direct Upgrade to 4.7 is supported as explained below:

- From NVR 4.0 87 Rev H to NVR 4.7 Build 188
- From NVR 4.0 97 Rev B to NVR 4.7 Build 188


- From NVR 4.1 Build 123 Rev B to NVR 4.7 Build 188
- From NVR 4.5 Build 162 Rev B to NVR 4.7 Build 188

To upgrade to MAXPRO NVR 4.7 Service Pack

Step 1. Double click MAXPRO NVR 4.7 Setup.exe. The WinRAR self extracts the files and displays the Windows update message.




Step 2. Click Yes to proceed, the installation wizard starts and the Welcome page appears.



**Welcome Wizard**

Step 3. Click Continue to start the installation. The installation process continues and once the installation is complete the completion page is displayed as shown below.

**Note:** If Korean language is not installed in your previous build (such as NVR 4.5 Build 162) then a confirmation message to support Korean Language is displayed. Click Yes if required.




### Installation Complete

Step 4. Click Finish to complete the installation and close the wizard.

## Upgrade to MAXPRO NVR 4.5 Build 162

### Pre-requisites

Before installing NVR 4.5 build 162 Service pack, ensure that all other applications in the PC is closed. If any application is still running then Process can not access the file message is displayed as shown below.




Upgrade is supported as explained below:


- From NVR 4.0 87 Rev H to NVR 4.1 Build 123 Rev B
- From NVR 4.0 87 Rev H SP1 to NVR 4.1 Build 123 Rev B
- From NVR 4.0 87 Rev H (beta) to NVR 4.1 Build 123 Rev B
- From NVR 4.1 Build 123 Rev B to NVR 4.5 Build 162

To upgrade to MAXPRO NVR 4.5 Service Pack

- Step 1. Double click MAXPRO NVR 4.5 Setup.exe. The WinRAR self extracts the files and displays the Windows update message.




- Step 2. Click Yes to proceed, the installation wizard starts and the Welcome page appears.



#### Welcome Wizard

- Step 3. Click Continue to start the installation. A confirmation message to support Korean Language is displayed as shown below.



### Installation Complete

Step 4. Click Yes if required. The installation process continues and once the installation is complete the completion page is displayed as shown below.



Step 5. Click Finish to complete the installation and close the wizard.


## Upgrade to MAXPRO NVR 4.1 Build 123 Rev B

Upgrade is supported as explained below:

- From NVR 4.0 87 Rev H to NVR 4.1 Build 123 Rev B
- From NVR 4.0 87 Rev H SP1 to NVR 4.1 Build 123 Rev B
- From NVR 4.0 87 Rev H (beta) to NVR 4.1 Build 123 Rev B


To upgrade to MAXPRO NVR 4.1 Service Pack

Step 1. Double click MAXPRO NVR 4.1 Setup.exe. The WinRAR self extracts the files and displays the Windows update message.




Step 2. Click Yes to proceed, the installation wizard starts and the Welcome page appears.





#### Welcome Wizard

Step 3. Click Continue to start the installation. After the installation is finished, the following page appears.



#### Installation Complete

Step 4. Click Finish to complete the installation and close the wizard.

## Upgrade to MAXPRO NVR 4.0

Upgrade is supported from MAXPRO NVR 3.1 SP1 or later version to MAXPRO NVR 4.0 Build 87 Rev H.

If you are upgrading from a version lower than 3.1 SP1 to MAXPRO NVR 4.0 then an error message is displayed. Upgrade to v3.1 SP1 Build 70C on top of the lower versions and then upgrade to NVR 4.0 Build 87 Rev H.


**Note:** Ensure that Services.msc console is closed before Installing or upgrading the MAXPRO NVR. See the [Before you Begin - Disable Defragmentation](#) section on page 103.

If you are upgrading to MAXPRO NVR 4.1 Build 123 Rev B then upgrade is supported as explained below:

- From NVR 4.0 87 Rev H to NVR 4.1 Build 123 Rev B
- From NVR 4.0 87 Rev H SP1 to NVR 4.1 Build 123 Rev B
- From NVR 4.0 87 Rev H (beta) to NVR 4.1 Build 123 Rev B

## Taking the Database Backup

Honeywell recommends database backup before running the upgrade. Database backup can be done from MAXPRO NVR Agent.



### Taking Database backup using the MAXPRO NVR Agent

**Note:** In MAXPRO NVR 3.1 or later version, a new scheduled backup mechanism is added which will retain the last 7 days of Database Backup. In case of upgrade, if the backup is set in the system already then same backup drives are maintained in the configuration and used in the new backup mechanism.

Or

If the backup is not set then by default the first recording drive is selected for database backup according to the alphabetical order. If you want to change the drive then edit the *TakeNVRbackup.bat* file which is available in *C:\Install\BackupData* and mention the required drive name.

## How to upgrade to MAXPRO NVR 4.0


Step 1. Insert the MAXPRO NVR 4.0 setup DVD in the DVD drive, browse the DVD drive, and then double-click setup.exe

Or


Go to the MAXPRO NVR setup folder on your computer, and then double-click setup.exe. A dialog box appears with the question - "Do you want to validate the setup before continuing MAXPRO NVR 4.0 installation?", click Yes to validate the

setup files are not corrupted before continuing the installation and click No to skip the validation to continue the setup. The installation wizard starts and the Welcome screen appears.

**Note:** If any pending reboot is there due to windows updates, the following error message appears, and the installation stops. Please ensure that you reboot your computer and run the setup again.



Step 2. Click Next. The Validation of User Credentials appears.



#### Validation of User Credentials


Step 3. Select your Domain Name/Host Name.

Step 4. Type your Windows User Name.

Step 5. Type your Windows Password.

**Note:** Honeywell recommends to use the newly created Administrator user account as explained in [Before you Begin - Changing the default Windows Administrator Account Created By NVR](#), page 103.

Step 6. Click Next. The Choose Metadata Path appears.




### Choose Metadata Path

Step 7. Click Browse to specify a new path for Metadata in NVR Application.

**Note:** *If you want to move your metadata to a non-OS partition then please choose the appropriate path. Upgrade will move the metadata accordingly.*

Step 8. Click Next. The summary screen appears.




### Summary

Step 9. Click Next. The upgrade status of various components appears.


**Note:** During upgrade, SQL Server 2008 Express is not upgraded to SQL Server 2012 Express to reduce upgrade time and only the Trinity database is updated with changes required for v4.0.

Step 10. When the upgrade is about to complete, the following message is displayed.



Step 11. Click OK. The Finish dialog appears with the options to Validate and to Finish the installation.

- Click Validate to verify the installed files on your NVR. If there are no errors then a message appears - Setup has been validated successfully without any error. Click here to view report. If there are errors, the message shows there are errors and the report can be reviewed to identify the error and contact Honeywell technical support if required to correct them on reinstall.
- Click Finish. The installation wizard starts all the services which may take a few minutes. After the wizard closes, as mentioned in [step 10](#) it is recommended to Restart the system manually for the changes to take effect. If you are prompted to reboot the system then the following message is displayed.



**Reboot prompt**

Step 12. Click OK to complete the MAXPRO NVR upgrade.

This page is intentionally left blank

# MAXPRO NVR WEB CLIENT

In this chapter...

<b>Section</b>	<b>See page...</b>
<a href="#">Introducing Web Client</a>	<a href="#">page 343</a>
<a href="#">Installing Web Client</a>	<a href="#">page 344</a>
<a href="#">Setting the MAXPRO Web Configurator</a>	<a href="#">page 345</a>
<a href="#">Creating Self Signed Certificate</a>	<a href="#">page 351</a>
<a href="#">Installing the Certificate</a>	<a href="#">page 355</a>
<a href="#">Procuring and Installing CA Certificate</a>	<a href="#">page 357</a>

## Introducing Web Client

The MAXPRO NVR Web Client allows you to remotely access the MAXPRO NVR server and perform video surveillance using a web browser such as Internet Explorer. It gives you the flexibility to view live video and perform the basic video surveillance functions remotely over the web.

MAXPRO NVR Web client is available with MAXPRO NVR 4.0. By default MAXPRO NVR installs the Web client and MAXPRO Web Configurator along with the NVR 4.0 installation. You can use the web client once you have installed the NVR 4.0.

MAXPRO NVR Web Client functions involve the following tasks:

- Viewing the live video
- Viewing Recorded Video (Playback)
- Taking Snapshot
- Viewing Presets

## Limitation with Privacy Protection Settings

- Anonymization is not supported in Web. If user is tries to see Anonymized video and also camera Anonymized option is enabled then an error message “Trying to access Anonymized Stream” is displayed.
- When an Operator (non-admin) logs into the Web Client and tries to view playback for any video then an error message “Four Eye authentication Privilege Failure” is displayed.

## Installing Web Client

By default MAXPRO NVR 4.0 installs the Web Client component on your machine. It also installs the MaxproWEBConfigurator utility to change or update the system and server configuration. If you want to access the MAXPRO NVR Server using Web Client remotely through a supported web browser then you should install Silverlight on the remote machine.

## Prerequisites to access MAXPRO NVR Server through Web Client

The following are the prerequisites to access the MAXPRO NVR server through Web Client.

- Silverlight: Ensure that Silverlight version 5 and above is installed on your machine. If you don't have the Silverlight plug-in on your machine, you can download it from the following Microsoft link. <http://www.microsoft.com/getsilverlight/Get-Started/Install/Default.aspx>



**Caution: For better security, close the browser upon logout.**

**Note:** *Silverlight plug-in is not supported by Chrome version 42.x or above and Microsoft Edge browser.*

- Web Browsers Supported on Windows Systems: Ensure that at least one of the following supported web browsers are installed on your PC:
- Internet Explorer version 8 or above
- Firefox version 15.0.1 or above
- Chrome version 32.x to 41.x only.

**Note:** *MAXPRO NVR Web Client is only supported by below Web Browsers on Windows 10 with Silverlight plug-in installed*

- Internet Explorer version 11 or above
- Firefox version 40 or above

**Note:**

- Web Browsers Supported on MAC systems: Not supported.



# Setting the MAXPRO Web Configurator

By default MAXPRO NVR installs the Web Configurator and  is displayed on your desktop.

MAXPRO NVR Web Configurator is a utility and it allows you to perform the following:


- Step 1. System Configuration
- Step 2. Server Configuration
- Step 3. Security Configuration


**System Configuration tab:** The system configuration tab allows you to update the administrator user credentials and the FPS for a better Stream quality. It also allows you to set the protocol for secure communication.

**Server Configuration tab:** The server configuration tab allows you to update the Web Server and MAXPRO NVR Server IP details.

**Security Configuration tab:** The Security Configuration tab automates the manual process of [Creating Self Signed Certificate](#), [Installing the Certificate](#), [Binding the generated certificate with https](#) and registers the same with IIS to use the same. It also allows you to configure the Silverlight control to access a service in another domain.

## To set the Web Configurator

- Step 1. Double-click  on the desktop. The MAXPRO Web Configurator dialog box appears. By default the System Configuration tab is selected.



### MAXPRO WebConfigurator

- Step 2. Under User Configuration: When the (non-window) Administrator log on name and password is changed then you can update the credentials of MAXPRO NVR Web Client to log on.
- Type the Username and Password and then click Update.

**Note:** You can update only the NVR Administrator credentials used by the Web Server. If you are changing the default administrator user credentials (admin/trinity) in NVR through the desktop client, then you should change and update the credentials in MaxproWEBConfigurator as well for Web Server to communicate with NVR and Web Clients.

The Administrator credentials used by the Web Server should be configured as a non-Windows Administrator user in the MAXPRO NVR through the desktop client. As a good security practice, it is recommended to update the default credentials on your system.

- Step 3. Under Stream Quality Configuration:
- Select the required Frames Per Second options as applicable and then click Save. The available options are:

- **As Per Frame:** Select this option to view the video as per the camera stream settings. If the camera supports 30 frames per second to stream the video then you can view 30 frames per second and accordingly your bandwidth is consumed. By default As Per Frame option is selected and it is recommended not to change this option, because this provides you with the best quality video.
- **Only IFrame:** select this option if your bandwidth is low and if you want to view only one IFrame per second.

**Note:** MAXPRO NVR Web Client supports streaming quality resolution up to 1080p. Cameras configured above 1080p resolution are not supported. If you drag and drop a camera configured with megapixel resolutions (above 1080p) then a message appears and video is not displayed as shown below.




Step 4. Under Protocol Configuration:

- Click the appropriate Protocol options for secure communication. The available options are HTTP, HTTPS, HTTPS (Only Video). By default HTTP and HTTPS protocol is selected.

**Note:**

- Video to the Web Client is always transmitted over HTTP. Non-video data is transmitted over HTTPS/HTTP based on the protocol configuration settings.
- Please ensure ports required for both video and non-video data is considered in any port forwarding settings.

**Note:** If you want to access the web client using secured connection then click the HTTPS option. When you access the MAXPRO NVR server using the URL `https://<MAXPRO NVR Server IP or Machine /Computer name>/MAXPROWEB/` then the following message is displayed. Click Continue to this website to proceed. It is recommended to verify the certificate to check whether it is issued by a valid Certificate Authority. See [Viewing the Certificate Information](#) for more information.



*The above message appears by default when you access the NVR server for the first time. Honeywell recommends you to buy a Domain Name specific certificate, create it and then install it. See the [Creating Self Signed Certificate](#) section on page 351 and [Installing the Certificate](#) section on page 355 for more information. Or You can use the MAXPRO Web Configurator utility to create the Self Signed Certificate.*

*Or*

*You can create a self signed certificate and then install it. See the [Creating Self Signed Certificate](#) section on page 351 and [Installing the Certificate](#) section on page 355 for more information.*

*The above settings are applicable to Internet Explorer, Chrome, Firefox and Safari web browsers. These settings are valid if the web client is accessed using the Domain/Host Name. If you access the web client using the IP then the above settings are not valid.*

**Caution: For better security, close the browser upon logout.**

Step 5. Under PTZ Configuration:

- Select the Enable PTZ check box to perform PTZ operations on a PTZ camera from Web Client.

**Note:** *PTZ feature is not supported and It is not recommended to use this feature in the current release. Enabling PTZ will help in performing PTZ operations fro DOME cameras from web client.*

Step 6. Click Save.

Step 7. Click the Server Configuration tab. The Server Configuration screen appears.

MAXPRO Web Configurator (NVR)

MAXPRO NVR

System Configuration **Server Configuration** Security Configuration

SERVER CONFIGURATION

Web Server IP:

MAXPRO Server IP:

Server Public IP:

PORT CONFIGURATION

Http Port:

Https Port:

Save

#### MAXPROWebConfigurator-Server Configuration

**Note:** By default the Web Server and the MAXPRO Server is installed on the NVR server machine and the IPs are set by default to local IP or computer/machine name. If it is not set by default in your system then it is recommended to change these settings to NVR Server (local) computer/machine name. For Honeywell supplied NVR boxes, default computer/machine name is MAXPRO-NVR and can be updated in the configuration from the tool.

Step 8. Under Server Configuration:


- Web Server IP: If the MAXPRO NVR server computer/machine name or IP (as applicable) is changed then you should change the Web Server IP. Type the new computer/machine name or IP (as applicable) in this box and then click Update.
- MAXPRO Server IP: If the MAXPRO NVR server computer/machine name or IP (as applicable) is changed then you should change the MAXPRO Server IP. Type the new computer/machine name or IP (as applicable) in this box and then click Update. Both Web Server IP and MAXPRO Server IP should be same.
- Server Public IP: If you want to host the MAXPRO Web client via internet (or Public) then you need to provide the Public Server IP. Type the new Public IP (as applicable) in this box and then click Update.

Step 9. Under Port Configuration:

- Http Port: If you want to change the http default port 80 to some other port number then type the required port number and click Apply.
- Https Port: If you want to change the https default port 443 to some other port number then type the required port number and click Apply. Port change option in the Configurator tool is available from 3.1 Build 65 Rev C or higher version.

Step 10. Click Save.

Step 11. Click the Security Configuration tab. The Security Configuration screen appears.



#### MAXPROWebConfigurator-Security Configuration

Step 12. Under SSL Certificate Configuration:

- Type the Port number in the box provided if the Https binding is other than 443 and then click Apply. The default port is 443.

**Note:** Honeywell recommends you to use a valid certificate from a Certificate Authority that would ensure robust security along with integrity and authenticity, instead of using self-signed certificate. Refer to the 800-23557-E - Securing MAXPRO VMS\_NVR Technical Notes for security settings.

Step 13. Under Transport Security, select the Enable Strict Transport Security check box to avoid or protect from hacking.

Step 14. Under Client Policy Configuration: Allows you to modify the C:\inetpub\wwwroot\clientaccesspolicy.xml & C:\inetpub\wwwroot\crossdomain.xml file.

- Click the required Client Policy option. The available options are
- Auto Generate (Default): This options makes entries to the above files such that the local Silverlight application (Web client) is able to make request to local ISOM.
- Manual: If Web Client and ISOM are on different machine or any other Silverlight application is trying to access ISOM then the above xml file need to be modified. Choose manual to make the modification manually. For more information on configuring Cross Domain or Client Access Policy browse the below websites: [http://www.adobe.com/devnet/articles/crossdomain\\_policy\\_file\\_spec.html](http://www.adobe.com/devnet/articles/crossdomain_policy_file_spec.html)  
[https://msdn.microsoft.com/library/cc197955\(v=vs.95\).aspx](https://msdn.microsoft.com/library/cc197955(v=vs.95).aspx)
- Allow All (non Secure): Non secure mode. If you want to allow all Silverlight clients to connect to ISOM hosted on the machine then you can click this option. Use with caution. This options also helps to troubleshoot the wrong configurations by providing full access temporarily.

**Note:** Auto mode is flexible and is the recommended mode.



**Caution: Ensure that you exercise caution while choosing the options other than the Default.**

Step 15. Click Save.

## Creating Self Signed Certificate

**Note:** Honeywell recommends you to use a valid certificate from a Certificate Authority that would ensure robust security along with integrity and authenticity, instead of using self-signed certificate. See [Procuring and Installing CA Certificate](#) section. Or Refer to the 800-23557-E - Securing MAXPRO VMS\_NVR Technical Notes for security settings.


Self signed certificate is required if you want to access the MAXPRO NVR server using your domain name. You should create a certificate, bind it to the https and then install the certificate to access the server using the web browser (Internet Explorer, Chrome, Firefox and Safari).

To create self signed certificate

Step 1. Open the Internet Information Manager (IIS) window.


Step 2. Select the server node under Connections pane.

Step 3. Under IIS, double click the Server Certificate option [Figure](#) .



## Home


The Server Certificate window is displayed.



## Server Certificate




- Step 4. Click the Create Self-Signed Certificate on the right-most pane. The Specify Friendly Name dialog appears.



### Specify Friendly Name


- Step 5. Type a friendly name for the certificate and then click OK. A new certificate is generated and listed under server certificates list as shown below:



### Generated Certificate


# Binding the generated certificate with https

- Step 1. In the Internet Information Manager (IIS) window, expand the server node under Connections pane.
- Step 2. Navigate to Sites > Default Web Site.
- Step 3. Click Bindings in the right-most pane. The Site Bindings dialog appears.



## Site Bindings Dialog

- Step 4. Select the type as https and then click Edit. The Edit Site Bindings dialog appears.



## Edit Site Bindings

- Step 5. Select the Demo SSL certificate from the SSL Certificate drop-down list.

Step 6. Select All Unassigned from the IP Address drop-down list.

**Note:** Ensure that you select All Unassigned option from the IP Address drop-down list and the port should be 443.

Step 7. Type the port number as 443.

Step 8. Click OK.


## Installing the Certificate

Once you have created a self signed certificate you need to install the certificate in the Internet Explorer on machines accessing the web client. If you do not install the certificate then the web browser displays the following error as shown in the figure [Certificate Error](#).

**Note:** Honeywell recommends you to use a valid certificate from a Certificate Authority that would ensure robust security along with integrity and authenticity, instead of using self-signed certificate. See [Procuring and Installing CA Certificate](#) section.




**Caution:** For better security, close the browser upon logout.



### Certificate Error

To view the error details, click on the Certificate Error message. A Untrusted Certificate message box is displayed as shown below:




### Untrusted Certificate

To install the certificate


Step 1. Click View Certificate as shown in the figure [Untrusted Certificate](#). The Certificate dialog box appears as below.

Tip: You can install the certificate using Internet Explorer. Once the installation is done you can access the MAXPRO NVR server using other browsers on the same machine using your domain name.



### Certificate

Step 2. Click the Install Certificate button. Certificate Import Wizard dialog box appears.



### Certificate Import Wizard

Step 3. Click the Browse button and then select the Trusted Certificate Authorities option.

- Step 4. Click Next until Finish button is displayed.
- Step 5. Click the Finish button. A confirmation message “you want to add the new certificate” is displayed.

## Procuring and Installing CA Certificate

**Note:** Honeywell recommends you to use a valid certificate from a Certificate Authority that would ensure robust security along with integrity and authenticity, instead of using self-signed certificate. Refer to the 800-23557-E - Securing MAXPRO VMS\_NVR Technical Notes for more security settings.

## Installing an SSL Certificate in Windows Server 2008 (IIS 7.0)


Windows Server 2008 includes Internet Information Services (IIS) 7.0. This new version makes several big changes in the way that SSL certificates are generated, making it much easier than previous versions of IIS. In addition to the new method of requesting and installing SSL certificates, IIS 7 includes the ability to:

- Request more than one SSL certificate at a time
- Import, export, and renew SSL certificates easily in IIS
- Quickly create a self-signed certificate for testing

### Create the Certificate Signing Request


The first step in ordering an SSL certificate is generating a Certificate Signing Request. This is very easy to do in IIS7 using the following instructions. perform the below steps to create the Certificate Signing Request:

- Step 1. Click on the Start menu, go to Administrative Tools, and then click on Internet Information Services (IIS) Manager. The IIS manger window is displayed.



#### IIS Home

- Step 2. Click on the name of the server in the Connections pane on the left. Double-click on Server Certificates.



#### Create Certificate Request

- Step 3. In the Actions pane on the right, click on Create Certificate Request. The Request Certificate dialog box appears.

The screenshot shows a dialog box titled "Request Certificate" with a sub-header "Distinguished Name Properties". Below the sub-header is a note: "Specify the required information for the certificate. State/province and City/locality must be specified as official names and they cannot contain abbreviations." The form contains the following fields:

- Common name: google.com
- Organization: Google, Inc.
- Organizational unit: Web
- City/locality: Mountain View
- State/province: California
- Country/region: US (dropdown menu)

At the bottom of the dialog box, there are four buttons: "Previous", "Next", "Finish", and "Cancel". The "SSLShopper.com" logo is visible in the bottom left corner.


**Request Certificate**

- Step 4. Enter all of the following information about your company and the domain you are securing and then click Next.

Name	Description	Examples
Common Name	The fully qualified domain name (FQDN) of your server. This must match exactly what you type in your web browser or you will receive a name mismatch error.	*.google.com mail.google.com
Organization	The legal name of your organization. This should not be abbreviated and should include suffixes such as Inc, Corp, or LLC.	Google Inc.
Organizational Unit	The division of your organization handling the certificate. (Most CAs don't validate this field)	IT Web
City/Local-ity	The city where your organization is located.	Mountain View
State/prov-ince	The state/region where your organization is located. This shouldn't be abbreviated.	California

Name	Description	Examples
Country/ Region	The two-letter ISO code for the country where your organization is located.	US GB


Step 5. Leave the default Cryptographic Service Provider. Increase the Bit length to 2048 bit or higher. Click Next.



**Request Certificate**



- Step 6. Click the button with the three dots and enter a location and filename where you want to save the CSR file. Click Finish.



#### Request Certificate

- Step 7. Once you have generated a CSR you can use it to order the certificate from a certificate authority. If you don't already have a favorite, you can compare SSL features from each provider using our SSL Wizard or by comparing cheap SSL certificates, Wildcard Certificates, or EV certificates. Once you paste the contents of the CSR and complete the ordering process, your order is validated, and you will receive the SSL certificate file.


## Installing the Certificate

To install your newly acquired SSL certificate in IIS 7, first copy the file somewhere on the server and then follow these instructions:

**Note:** Honeywell recommends you to use a valid certificate from a Certificate Authority that would ensure robust security along with integrity and authenticity, instead of using self-signed certificate See [Procuring and Installing CA Certificate](#) section.


To install the certificate

- Step 1. Click on the Start menu, go to Administrative Tools, and click on Internet Information Services (IIS) Manager.
- Step 2. Click on the name of the server in the Connections column on the left. Double-click on Server Certificates.



**IIS Manger**

Step 3. In the Actions column on the right, click on Complete Certificate Request...as shown below.



**IIS Manger**


Step 4. Click the button with the three dots and select the server certificate that you received from the certificate authority. If the certificate doesn't have

a .cer file extension, select to view all types. Enter any friendly name you want so you can keep track of the certificate on this server. Click OK.



#### Complete Certificate request


Step 5. If successful, you will see your newly installed certificate in the list. If you receive an error stating that the request or private key cannot be found, make sure you are using the correct certificate and that you are installing it to the same server that you generated the CSR on. If you are sure of those two things, you may just need to create a new Certificate Request and reissue/replace the certificate. Contact your certificate authority if you have problems with this.



## IIS manger-Server Certificate


### Bind the Certificate to a website

- Step 1. In the Internet Information Manager (IIS) window, expand the server node under Connections pane.
- Step 2. Navigate to Sites > Default Web Site.
- Step 3. Click Bindings in the right-most pane. The Site Bindings dialog appears.




#### Site Bindings Dialog

- Step 4. Click on the Add...button
- Step 5. Change the Type to https and then select the SSL certificate that you just installed. Click OK.



#### Add Site Bindings


Step 6. You will now see the binding for port 443 listed. Click Close.



## Install any Intermediate Certificates


Most SSL providers issue server certificates off of an Intermediate certificate so you will need to install this Intermediate certificate to the server as well or your visitors will receive a Certificate Not Trusted Error. You can install each Intermediate certificate (sometimes there is more than one) using these instructions:

- Step 1. Download the intermediate certificate to a folder on the server.
- Step 2. Double click the certificate to open the certificate details.
- Step 3. At the bottom of the General tab, click the Install Certificate button to start the certificate import wizard. Click Next.



**Certificate**

Step 4. Select Place all certificates in the following store and click Browse.



#### Certificate Import Wizard

Step 5. Check the Show physical stores checkbox, then expand the Intermediate Certification Authorities folder, select the Local Computer folder beneath it. Click OK.

Step 6. Click Next, then Finish to finish installing the intermediate certificate.



## Changing Default Port 443 for the MAXPRO Web Client and MAXPRO Mobile app


Changing the default Port 443 for the MAXPRO Web Client and MAXPRO Mobile app is a two step process:

- Changing the port 443 on the MAXPRO NVR.
- Changing the port in the MAXPRO Mobile app and MAXPRO Web Client.


**Note:** MAXPRO NVR Web Client and MAXPRO Mobile app share a common port. Different ports cannot be assigned to the Web Client and Mobile app.

## Step 1: Changing the Default Port 443 on the MAXPRO NVR

By default, Port 443 is configured for the MAXPRO Web Client and MAXPRO Mobile app to connect to the NVR. If you need to modify the default port, perform the following procedure. If you require further assistance, please contact your Network Administrator.

Step 1. Double-click  on the desktop. The MAXPRO Web Configurator dialog box appears. By default the System Configuration tab is selected.

Step 2. Click the Server Configuration tab the following screen appears.




### Server Configuration

Step 3. Under Port Configuration:

- Http Port: If you want to change the http default port 80 to some other port number then type the required port number and click Apply.
- Https Port: If you want to change the https default port 443 to some other port number then type the required port number and click Apply.

**Note:** Port change option in the configurator tool is available from 3.1 Build 65 Rev C or higher version.

## Step 2: Changing the Port in the MAXPRO Web Client and MAXPRO Mobile app

- Step 1. Launch MAXPRO Mobile by tapping  on your mobile device.
- Step 2. Before you log on: Tap + in the right hand side to add NVR
- Step 3. Add the MAXPRO NVR Server:
  - Select whether you want to connect through Remote network or Local network
  - In the name field, enter the name (For example Demo/Site name) for the NVR.
  - In the IP Address field, type the IP address/Host Name of the unit
  - Type the Port number. The default port number is 443.
  - Tap Add.

To change the port in MAXPRO NVR Web Client:

- Type the URL `https://<MAXPRO NVR Server IP or Computer/Machine name>:<PORT>/MAXPROWEB/` in your web browser and then press Enter. The log In page appears.


**Note:** *<MAXPRO NVR Server IP or Computer/Machine name> needs to be replaced by the IP address or Computer/Machine name (as applicable) of the MAXPRO NVR Server machine on which both the Web Server and the NVR Server are installed by default. <PORT> needs to be replaced by the new port. For example: if the port is changed to 1024 with the steps above, enter the URL as `https://74.x.x.x:1024/MAXPROWEB/`*



**Caution: For better security, close the browser upon logout.**

## Viewing the Certificate Information


If you see the below security message then it may not be from the valid certificate authority and it would be the case of self signed. It is recommended to exercise caution and verify the certificate and check whether the certificate details are matching with the server machine.



To verify the certificate details:




- Step 1. Click Continue to this web site (not recommended) link to proceed. The NVR Web Login page is displayed.
- Step 2. Click Certificate Error as shown below. The Mismatch Address pop up message is displayed.



### Program Maintenance

- Step 3. Click View Certificate. The Certificate dialog box is displayed.



### Certificate dialog

- Step 4. Verify the following fields to check whether it is matching with the details of Server machine.
  - Issued to

- Issued By
- Valid From

Step 5. Click the Details tab and then check other details.



**Caution: For better security, close the browser upon logout.**

## Introduction

This chapter describes how to connect to a MAXPRO® NVR using the MAX-PRO®NVR Mobile app on an Apple® or Android™ mobile devices. It also covers how to install the app and creating the users for the MAXPRO NVR Mobile app.

With MAXPRO NVR Mobile App, you can perform every day video surveillance tasks such as:



- Configure and Logon using Touch ID (For Fingerprint recognition supported mobile device only). Fingerprint Authentication login is supported for both Android and IOS devices.
- HIS Streaming support where you can view live video if you have not installed valid/trusted certificate.
- One time configuration for both Local and Remote connection.
- Live video view to monitor your house, facility, customers or employees.
- Digital zoom in and zoom out for full screen view in landscape or portrait.
- Playback or search for recorded video by date and time.
- Take a snapshot of a live or recorded video frame and use as an image.
- Create favorite salvos (cameras up to 3x3 on tablets and 2x4 on phones per salvo).
- Perform PTZ control through Presets.
- Monitor & Manage Alarms.
- Search for MAXPRO NVR and download the FREE app at the Apple® iTunes® App Store or Google Play. For NVR 3.5 SP1 or older version search for: MAXPRO Mobile.

### Enhancements in NVR 5.0 Release

- Support for New Mobile app versions
- For Android: 1.3.0 (100030004)

- For IOS: 1.3.0 (100030001)
- New Supported OS: minSDKVersion = 21

The following table explains the features available in MAXPRO NVR Apps and MAXPRO Mobile Apps:

FEATURES	 MAXPRO NVR APPS	 MAXPRO MOBILE APPS
Live View	✓	✓
Supported MAXPRO NVR version	v4.0 or later	v3.5 SP1 or earlier
Playback or search by date & time	✓	✓
Snapshot image	✓	✓
PTZ Control	Presets	–
Discover and list cameras	✓	✓
Maximum cameras supported in salvo view	Phone: 2 x 4 Tablet: 3 x 3	2 x 2
Full screen view	✓	✓
User authentication and permissions integrated with recorder	✓	✓
Save Favorites/Salvos	✓	–
Alarms/Events	✓	–
Secure Login	https	http
Mobile server deployment	Included with NVR Server v4.0 or later	Included with NVR Server v3.5 SP1 or earlier
SUPPORTED MOBILE DEVICES		
Apple® iPad®, iPhone® and iPod touch®	✓	✓
Android® Phone and Tablet	✓	✓

NOTE: For more details, please check the MAXPRO NVR product manuals.

Apple, iPhone, iPad, iPod touch and iTunes are trademarks of Apple Inc. Android® is a registered trademark of Google.

## MAXPRO NVR Mobile app Installation

The MAXPRO NVR Mobile app is compatible with MAXPRO NVR v4.0 or later versions.

### Minimum Requirements

The MAXPRO NVR Mobile app minimum requirements are:

- Apple iPad, iPhone, and iPod touch running IOS 8 and later
- Android phones and tablets running v4.4 and later
- Internet connection to the MAXPRO NVR
- Wifi or 3G/4G connection for the Apple or Android device

The following table depicts the minimum bandwidth required for MAXPRO NVR mobile app to function normally:

Camera	Quality	Segment Size(for 3s)	Web	Mobile-Wifi	Mobile-4G	Mobile-3G	Minimum Client Bandwidth Required	No.of Streams
Analogue	Good	25-30KB	10-11s	10-11s	10-11s	10-11s	700 kbps	<b>SINGLE STREAM</b>
CIF	Good	48-55KB	9-10s	10-11s	10-11s	11-12s	700 kbps	
CIF	Best	65-75KB	10-13s	10-13s	11-13s	11-15s	700 kbps	
2CIF	Good	110-135KB	11-13s	11-12s	11-13s	12-24s	3 Mbps	
2CIF	Best	150-160KB	11-13s	11-12s	9-12s	13-25s	3 Mbps	
4CIF	Good	140-150KB	11-13s	11-12s	-	-	3 Mbps	
4CIF	Best	160-180KB	11-13s	-	-	-	5 Mbps	
720p	Best	700-800KB	11-13s				10 Mbps	
1080p	Best	1.2-1.5MB	11-13s	-	-	-	10 Mbps	

These metrics are for SINGLE STREAM drawn at a time from device , if multiple streams are drawn the the latency will increase based on the client badwid.


# Installing the MAXPRO NVR Mobile app

- Step 1. Download the app by searching for MAXPRO NVR Mobile from the appropriate mobile app store, either the Apple App Store or the Google Play Store (<https://play.google.com/>).

## Apple mobile device



## Android mobile device





- Step 2. When the application is successfully installed, the Honeywell MAXPRO

Mobile icon appears on the device.


#### Apple mobile device

#### Android mobile device



## Typical Network Configuration and Settings

The [System Diagram](#) figure shows a typical system setup. In applications where the mobile device connects to the MAXPRO NVR through a public router, you must configure port forwarding on the router as shown in the port forwarding table. Please contact your Network Administrator for assistance.



### System Diagram

Up to three mobile devices can be used simultaneously to view video from the NVR.

### Note:


- The default ports for the Mobile app on MAXPRO NVR is 80 and 443. See the [Changing Default Port 443 for the MAXPRO Web Client and MAXPRO Mobile app](#) section on page 366 for instructions on how to change the port number if Port 80, 443 is already used or if there is more than one MAXPRO NVR behind the router in the network.
- Video to the Mobile app is always transmitted over HTTP and Non-video data is always transmitted over HTTPS.
- Please ensure ports required for both video and non-video data are considered in any port forwarding settings required.

Public Router IP Address	External Port	MAXPRO NVR IP Address	Internal Port
74.xxx	80	192.168.1.101	80
74.xxx	443	192.168.1.101	443




# Creating Users for the MAXPRO NVR Mobile app

The MAXPRO NVR Mobile app uses a non-Windows authentication. You need to create non-Windows users in NVR to allow access from authorized mobile device users.

Step 1. Launch MAXPRO NVR (double-click the MAXPRO NVR icon  on your desktop).

Step 2. On the Configurator tab, select the User tab, then click Add at the bottom.



- Double-click User in the User Name column. Type in a name for the MAXPRO Mobile user. This is the name that will be used to log on to the mobile device to connect to the MAXPRO NVR.
- (Optional) Double-click in the User Description column to add an appropriate description (for example, Mobile app operator).
- In the Role drop-down list, select the appropriate user permission (for example, Operator, as shown above).
- Select the Password Never Expire check box if you do not want to change the password periodically.

- Select Anonymization Check box to use the Privacy Protection feature (GDPR Favored). See Privacy Protection Settings section for more information.

## Limitation with Privacy Protection Settings


- If Anonymization is enabled in NVR application, then user will not be able to see the video in MAXPRO mobile app/Web client. An error message is displayed.
- Anonymization is not supported in Web. If user is tries to see Anonymized video and also camera Anonymized option is enabled then an error message “Trying to access Anonymized Stream” is displayed.
- If Four Eye Authentication option is enabled in NVR application then user will not be able to view playback video in MAXPRO mobile app/Web client
- When an Operator (non-admin) logs into the Web Client and tries to view playback for any video then an error message “Four Eye authentication Privilege Failure” is displayed.

## Selecting the Cameras to be Remotely Viewed

Step 1. Provide access for the MAXPRO Mobile user to selected cameras, as required.

- Select the required cameras in the Available List, then click the right arrow to move them to the Associated List.



- Click Save.



## Adding the MAXPRO NVR to the MAXPRO NVR Mobile app



In the MAXPRO NVR Mobile app, you must add the MAXPRO NVR so that you can view video.




- Step 1. Launch MAXPRO NVR Mobile by tapping  on your mobile device.
- Step 2. Before you log on: Tap  in the right hand side to view the available NVRs or to add new NVR.

**Apple mobile device**

**Android mobile device**




In the Add Recorder screen:



- In the NVR Name field, type the name (For example Demo/Site name) for the NVR.
- In the Local IP field, type the local IP address/Host name of the unit.
- In the Remote IP field, type the remote IP address/Host name of the unit.

- Type the Port number. The default port number is 443.



Step 3. Log on: You can Log on in two ways, Manual and Finger Print Touch ID. (Finger Print Touch ID logon is supported only for IOS devices).



- For Manual Logon:
- In the Username field enter the name that was created for the mobile device user in MAXPRO NVR (see the [Creating Users for the MAXPRO NVR Mobile app](#) section on page 377).
- In the Password field enter the appropriate password.
- Under Connect to, ensure that your Recorder is selected or tap > to connect to a different recorder.
- Select the Remember User Name check box If you want the app to remember the User Name for your future login.
- (Only for Android Devices): Select the Validate Server Authenticity check box If you want to validate the server.
- Tap on Terms at the bottom of the screen to read the EULA terms and conditions.

### Apple mobile device

### Android mobile device

Tap Sign In.

Tap Log In.



- For Touch ID logon, see [Logon using Touch ID \(Fingerprint Authenticated\)](#) for more information.

## Logon using Touch ID (Fingerprint Authenticated)

Touch ID logon (For Fingerprint recognition supported mobile device only): This feature is supported for fingerprint secured Android and IOS mobile devices. Maximum of 5 users fingerprints can be configured per mobile device. The first login should be manual login and you need to enter the credentials manually. After that, the succeeding logins can be based on fingerprint authentication. The Fingerprint authentication logon option is displayed after the first manual logon. You can see the fingerprint icon on the bottom left corner of the login screen. Touch ID logon feature is supported for both Android and IOS devices. To use the Touch ID logon facility user needs to verify the Touch ID

### Verifying the Touch ID

Pre-requisite:



To verify the Touch ID configuration, it is assumed that the user should have configured the Fingerprint authentication under Settings to unlock the mobile. Refer corresponding Mobile (IOS) user manuals to set the Fingerprint based authentication to unlock.

Step 1. Manually logon to the MAXPRO app and then navigate to Settings screen as shown below.

**Apple mobile device**

**Android mobile device**

Tap Settings.








Step 2. Tap the toggle button to turn on the Touch ID Login as shown below.

**Apple mobile device**

**Android mobile device**



- Step 3. Once the Touch ID login is ON, the Configure Touch ID screen is displayed as shown below.





- Step 4. Follow the instructions on the screen during the verification process. You need to touch and hold the Home button multiple times to verify the fingerprint. If the verification is successful then the Success message is displayed as shown.

**Apple mobile device**

**Android mobile device**

Tap Done to complete.



Tap Done to complete.



Step 5. Tap Done to complete the configuration. Fingerprint authentication option is now displayed as highlighted below.

**Apple mobile device**

**Android mobile device**



Step 6. Place your finger on the Fingerprint icon as highlighted above. You will be logged in to MAXPRO app.


**Note:** Ensure that the first logon should be Manual logon.

## Enable HIS Streaming

HIS Streaming feature allows you to view the live video even if you don't have a valid certificate installed on the server for a secure connection. You can still view the live video frame by frame to ensure the surveillance process is smooth and continuous. By default, the HIS Streaming feature is enabled in the app. This feature detects your trusted certificate status automatically and intimates if you are viewing live video through HIS Streaming. You can use HIS streaming in the following scenarios:

- if you have not installed a valid/trusted certificate on the Server.
- if your trusted certificate is expired.



By default, HIS Streaming is enabled in the Settings screen as shown below.




## Adding Multiple NVR Recorders

To add additional NVR on the mobile app:

**Note:** Maximum 20 NVR configurations are allowed.


- Step 1. Tap  on the login screen. The list of already saved NVRs under My Recorders screen is displayed.
- Step 2. Tap . The Add Recorder screen is displayed.
- Step 3. Add the MAXPRO NVR Recorder as follows:
- In the NVR Name field, type the name (For example Demo/Site name) for the NVR.
  - In the Local IP field, type the local IP address/Host name of the unit.
  - In the Remote IP field, type the remote IP address/Host name of the unit.
  - Type the Port number. The default port number is 443.
- Step 4. Repeat the step 1 through step 3 to add multiple NVR Recorders.




# Editing NVR Recorder Details


To edit the NVR Recorder details:


## Apple mobile device

Tap . The already saved NVRs are displayed.  
On the required NVR recorder, gently swipe to right-side. The **Edit** and **Delete** options are displayed as shown.



## Android mobile device

Tap . The already saved NVRs are displayed.  
On the required NVR recorder, gently swipe to right-side. The **Edit** and **Delete** options are displayed as shown.




### Apple mobile device

Tap on **Edit**. The **Edit Recorder** screen is displayed.  
Modify the required details.  
Tap **Save** once you modify the details.



NVR Name	
2	
Local IP	Port
10.78.72.125	443
Remote IP	Port
19.18.17.16	443




### Android mobile device

Tap on **Edit**. The **Edit Recorder** screen is displayed.  
Modify the required details.  
Tap **Save** once you modify the details.




Name NVR	
Test3	
Local IP	Port
host.hm.com	443
Remote IP	Port
host.rm.com	443




# Deleting the Saved NVR Recorders


To delete the saved NVR Recorders:


## Apple mobile device

Tap . The already saved NVRs are displayed.  
On the required NVR recorder, gently swipe to right-side. The **Edit** and **Delete** options are displayed as shown.  
Tap **Delete** to delete the existing NVR server. A warning message is displayed.  
Tap **Yes** to delete Or Tap **Cancel** to retain.



## Android mobile device

Tap . The already saved NVRs are displayed.  
On the required NVR recorder, gently swipe to right-side. The **Edit** and **Delete** options are displayed as shown.  
Tap **Delete** to delete the existing NVR server. A warning message is displayed.  
Tap **Yes** to delete Or Tap **Cancel** to retain.



# Changing Default Port 443

To change the default Port 443 for the MAXPRO Web Client and MAXPRO NVR Mobile app, see the [Changing Default Port 443 for the MAXPRO Web Client and MAXPRO Mobile app](#) section on page 366 for more information.

**Note:** Honeywell recommends you to use a valid certificate from a Certificate Authority that would ensure robust security along with integrity and authenticity, instead of using self-signed certificate. See [Procuring and Installing CA Certificate](#) section.

# Limitation with Privacy Protection Settings in MAXPRO Mobile App

- If Anonymization is enabled in NVR application then user will not be able to see the video in MAXPRO mobile app/Web client and an error message is displayed.



- If Four eye authentication option is enabled in NVR application then user will not be able to view playback video in MAXPRO mobile app/Web client.

This page is intentionally left blank

# Customizing IP Address and Machine Name and Scheduling Metadata and Database Backup

## Changing the Default IP address and Machine Name

See the [Changing the MAXPRO NVR IP Address and Machine Name](#) section on page 86 for more information.

## Scheduled Metadata and Database Backup

A common batch file is created for taking the scheduled metadata and database backup.

The following sections describe the procedures to setup scheduled metadata and database backup.


**Note:** *It is recommended to set up scheduled backups of Metadata and Database with the below steps if they are not already configured on your NVR. The backups can be used to recover a system anytime later in case of a failure or if the OS drive is reimaged with a recovery disk, please contact Technical Support for assistance. Please note the below steps do not include backup or recovery of the Video Storage drives containing the raw video data. Below is the recommended configuration:*

- a. Separate Metadata partition (For example M:) of 50 GB or higher size on the non-OS hard drive. Metadata can be pointed to the separate partition during the install/upgrade.
- b. The database backup is recommended to be pointed to the Metadata partition.
- c. The Metadata backup is recommended to be pointed to the OS partition.


# Scheduled Task for Backing up the Metadata and Database

In this scenario, create a scheduled task that helps in taking either a daily backup or a weekly backup or a monthly back up of the metadata based on your requirement.

- Step 1. On the Microsoft Windows® 7 computer, right-click the Computer option, and click Manage in the context menu as shown in the following figure.




The Computer Management window appears.




**Computer Management**

Step 2. Right-click Task Scheduler on the left pane, and click Create Basic Task in the context menu as shown in the following figure.



### Task Scheduler

The Create a Basic Task dialog box appears.




### Create Basic Task

Step 3. Type the Name of the task.

Step 4. Type a Description for the task.


Step 5. Click Next. The Task Trigger dialog box appears.



### Task Trigger

Step 6. Select the Daily option. You can select other options based on your requirement.

Step 7. Click Next. The Daily dialog box appears.




### Daily Dialog

Step 8. In the Start box, select the start date and time of the task.

Step 9. Select the Synchronize across time zones check box to synchronize the time across different time zones.

Step 10. Type the days in Recur every, to run the task periodically.


Step 11. Click Next. The Action dialog box appears.



### Action dialog

Step 12. Select the Start a Program option.

Step 13. Click Next. The Start a Program dialog box appears.



### Start a Program

Step 14. Select the Program/script that is required to run the task. Click Browse and choose the .bat file - TakeNVRBackup.bat.

TakeNVRbackup.bat file is available in the path C:\Install\BackupData for NVRs with v3.5 or later version.

**Note:** Please save the batch file (if you make any changes) in the following location: C:\Install\BackupData\TakeNVRBackup.bat. The following are the two new entries in the .bat file set BackupDBDrive=M: set BackupMetaDataDrive=C. By default the Backup Database (BackupDB) is stored in M drive and the Metadata (BackupMetaData) is stored in C drive. It is recommended to choose M and C drive for DB and Metadata backup, but you can choose your own drives (for example: E, D, H drives) to store the backup file.

```
@echo off
echo
*****
echoBatch File to take MAXPRONVR Metadata and Database Backup
echo
*****
REM
*****
REM To Change the Backup Drive please change the value below
set BackupDBDrive=M:
set BackupMetaDataDrive=C:
REM
*****
```

**Note:** To change the Backup Drive, change the value of set BackupDBDrive=D:\.

Step 15. Click Next after you have selected the above batch file. The Summary dialog box appears.

Step 16. Verify the information, and then click Finish.

## Meta Data Conversion Utility

Meta data conversion utility is used for updating the unique ID number of a camera in a primary/redundant box. You can use this utility only if you are opting for Redundancy feature.

You need to run this utility before configuring the Redundancy feature in MAXPRO VMS and ensure that all the Primary NVR boxes are updated with proper unique IDs for the cameras.

This utility updates the unique system ID number of the recorded clips and Meta data details for all or specific cameras. It retains your recorded clips and Meta data details during Failover /Failback operations. This allows a user to effectively playback the recorded clip without loss of video. You can also define a new Unique ID for all or required cameras based on the existing Unique IDs.

Meta data conversion utility is available in Bin folder of the installation path and you need to run this utility in each NVR box individually to update the unique system number. This utility is applicable only for existing MAXPRO NVR 4.0 Build 87 H solution box.



## Offline Mode


You can also use this utility to synchronize the Unique ID in offline mode for specific cameras. Offline Mode option enables you to update the unique ID manually if you have modified/updated the unique ID only in one NVR box (such as Primary box). To synchronize the unique ID number in both the primary and redundant box you need to run this utility in the Redundant NVR box.

For example for an existing Redundancy User: After Failover/Failback operation, if you have modified/updated the Unique ID in Primary box and the same is not updated in the Redundant box then you cannot playback the clips when the system was in Failover/Failback mode. You need to run this utility in the Redundant box in order to synchronize the IDs and to playback the clips without interruption. See [How to update the Unique ID in Offline Mode](#) section on page 404.

## How to access the Meta Data Conversion Utility

To access the Meta Data Conversion Utility

- Step 1. Navigate to the MAXPRO NVR 4.0 installation path (C:\Program Files (x86)\Honeywell\TrinityFramework\Bin) folder and then click the Meta Data Conversion Utility. The login screen appears as shown below.




### Meta Data Conversion Utility Login

- Step 2. Type the Username and Password in box provided.  
Or  
Select the Is Windows User to login using windows default credentials.

**Note:** Select the Is Windows User check box for logging on using the Windows authentication (uses current logged in Windows account credentials). If the Is Windows User check box is cleared, the MAXPRO NVR user name and password is used for authentication. Ensure that you avoid using the @ character in your password.




- Step 3. Click Login. The Meta Data Conversion Utility home screen appears as shown below.




**Meta Data Conversion Utility**

## Updating the Unique system ID for all Cameras

To update the Unique system ID for all cameras

- Step 1. Access and launch the Meta Data Conversion Utility as explained in [How to access the Meta Data Conversion Utility](#) section on page 401. By default the Recorded Clips Location and Meta data location is updated with your default path.
- Step 2. Click  to add additional location for Recorded Clips Location.  
Or  
Click  to delete any Recorded Clips Location.
- Step 3. Click  to browse and update the existing Meta data path.
- Step 4. Click All Cameras option.
- Step 5. In the Start System Number box, type the starting number for all the cameras.
- Step 6. Click Next. The next screen for the utility is displayed and the New Unique ID for all the cameras is updated automatically from the start number defined as shown below.




#### Define Unique ID screen

- Step 7. Click Run to execute the utility.  
Or  
Click Back to go back to home screen to change the settings.

## Updating the Unique system ID for Specific Cameras

To update the Unique system ID for Specific Cameras

- Step 1. Perform step 1 through step 3 of [Updating the Unique system ID for all Cameras](#) section on page 402.
- Step 2. Click Specific Camera(s) option, and then click Next. The next screen for the utility is displayed and the New Unique ID column for all the cameras is displayed blank as shown below.




### Updating Unique ID

- Step 3. Scroll up and down to view the specific cameras and then type the required New Unique ID in the corresponding box.
- Step 4. Click Run to execute the utility.  
Or  
Click Reset to reset all ID.

## How to update the Unique ID in Offline Mode


To update the unique ID in offline mode

- Step 1. In the Meta Data Conversion Utility home page, click Specific Camera(s) option, and then select the Offline Mode check box as shown below.



**Offline Mode**

- Step 2. Click Next. The next screen for the utility is displayed and the New Unique ID column for all the cameras is displayed blank as shown below.




#### Offline Updating Unique ID

- Step 3. Scroll up and down to view the specific cameras to update the unique ID and then type the required New Unique ID in the corresponding box.
- Step 4. Click Run to execute the utility.  
Or  
Click Reset to reset all ID.

## How to Enable Video on demand feature in MAXPRO NVR

- Step 1. Launch the Registry Editor Window.
- Step 2. Navigate to the below registry path HKEY\_LOCAL\_MACHINE->SOFTWARE->Wow6432Node->Honeywell->MaxproNVR->TrinityFramework.
- Step 3. Locate OnDemandLiveStreaming parameter and in the Data column.
- Step 4. By default value is 0 means its not enabled, If user want to enable Video on demand feature it must be set to 1 as shown below. Change the 0x00000000 (0) value to 0x00000001 (1)



Step 5. Restart the PC and both the NEO (NEO 1 and 2) services for the changes to take effect.

**Note:** In VMS no need to perform any settings or config changes to enable VOD feature. No recordings will take place in NVR once Video On Demand feature is enabled.

## How to Enable the Camera Stream

To Enable/Disable cameras and Enable Camera stream Redirect to NVR in ISOM

Step 1. Navigate the path in NVR C:\Program Files (x86)\Honeywell\UVISOM.

Step 2. Open web.config file in notepad and check the below 2 entries:

```
<add key="RedirectStreamtoNVR" value="0"/>
```

```
<add key="EnableDisableCamera" value="0"/>
```

Step 3. By default both are set to "0". means it is disabled. To enable the feature change the value from 0 to 1 as highlighted below.

**Note:** Once Video On Demand is configured to be used in MAXPRO NVR then Enable/Disable camera feature can be turned off.

```
web.config - Notepad
File Edit Format View Help
<add key="RemoteIpLookupUrl" value="https://icanhazip.com/" />
<add key="ForceRemoteIp" value="" />
<!--add key="MaximumAllowedStreamCount" value="64"/-->
<add key="MaximumAllowedStreamSessionCount" value="32"/>
<add key="MaximumAllowedHISStreamSessionCount" value="16"/>
<add key="MaximumAllowedHPSStreamSessionCount" value="32"/>
<add key="MaximumAllowedHLSStreamSessionCount" value="16"/>
<add key="MaximumAllowedRTSPStreamSessionCount" value="32"/>
<add key="MaximumAllowedSourceSessionCount" value="64"/>
<add key="NotSupportedStreamTypeCompressCombo" value="HPS|MJPEG; RTSP|MJPEG; RTSP|MPEG4; HLS|MJPEG" />
<add key="MaxResolutionSupported" value="1920x1080" />
<add key="ChunkTimeout" value="800"/>
<add key="MUSDeployment" value="LOCAL"/>
<add key="InstalledProduct" value="MAXPRONVR"/>
<add key="RTSPPort" value="54"/>
<add key="HasAnalogCameraSupportForHLS" value="false"/>
<!-- For tridium alone used for redirecting to old isom-->
<add key="TargetOldISOMIP" value="127.0.0.1"/>
<add key="TargetOldISOMIPPort" value="" />
<add key="TargetOldISOMProtocol" value="http" />
<add key="RedirectStreamONVR" value="0" />
<add key="Enabledisablecamera" value="0" />
</appSettings>
<unity>
<typeAliases>
<!-- Global.asax types -->
<typeAlias alias="singleton" type="Microsoft.Practices.Unity.ContainerControlledLifetimeManager" />
<!-- SDK Manager types-->
<typeAlias alias="IPermissionAdapter" type="Honeywell.Security.Isom.Server.IAdapter.IPermissionAdapter" />
<typeAlias alias="IAccountAdapter" type="Honeywell.Security.Isom.Server.IAdapter.IAccountAdapter" />
<typeAlias alias="IDeviceAdapter" type="Honeywell.Security.Isom.Server.IAdapter.IDeviceAdapter" />
<typeAlias alias="ISiteAdapter" type="Honeywell.Security.Isom.Server.IAdapter.ISiteAdapter" />
<typeAlias alias="IRecorderAdapter" type="Honeywell.Security.Isom.Server.IAdapter.IRecorderAdapter" />
<typeAlias alias="ICameraAdapter" type="Honeywell.Security.Isom.Server.IAdapter.ICameraAdapter" />
<typeAlias alias="IStreamAdapter" type="Honeywell.Security.Isom.Server.IAdapter.IStreamAdapter" />
<typeAlias alias="IEventAdapter" type="Honeywell.Security.Isom.Server.IAdapter.IEventAdapter" />
<typeAlias alias="nvrIPermissionOperations" type="USP.WebAPI.Adapters.NVR.Operations.IPermissionOperations" />
<typeAlias alias="nvrISiteOperations" type="USP.WebAPI.Adapters.NVR.Operations.ISiteOperations" />
<typeAlias alias="nvrIRecorderOperations" type="USP.WebAPI.Adapters.NVR.Operations.IRecorderOperations" />
<typeAlias alias="nvrICameraOperations" type="USP.WebAPI.Adapters.NVR.Operations.ICameraOperations" />
</typeAliases>
</unity>
```

To enable this feature in MAXPRO VMS Server then perform the following steps:

- Step 1. Navigate the path in VMS C:\Program Files (x86)\Honeywell\UVISOM.
- Step 2. Repeat the step 2 to step 3 of [How to Enable the Camera Stream](#) section.

**Note:** Make sure MAXPRO Web client is working.



## Image Stream Combinations for Oncam Grandeye Cameras

### For Oncam Grandeye Evolution Cameras

Camera Type	Resolution	Best fps (MAX)(H.264)
Evolution	1056x960	15
	2144x1944	10
	1448x1360	15
	528x480	15

## Device Characteristics of Oncam Grandeye Cameras

Characteristic	Camera Type	Comments
Camera provides variable fps. Example: For highest resolution, 2144x1944, maximum fps a camera can provide is 3. On several occasions, it is seen that fps varies from 1 to 3, and very rarely a camera provides 3 fps.	Halocam	As per Grandeye, fps varies and cannot go beyond the maximum value, 3. This is the design specific behavior of the camera.

Characteristic	Camera Type	Comments
Camera provides variable fps. Example: For highest resolution, 2144x1944, maximum fps a camera can provide is 10. On several occasions, it is seen that fps varies from 6 to 10, and very rarely a camera provides 10 fps.	Evolution	As per Grandeye, fps varies and cannot go beyond the maximum value 10. This is the design specific behavior of the camera.
Before streaming, the active Camera stream (Resolution) must be set in the Camera Web page. In MAXPRO NVR, if you do not select the active stream, video is not displayed.	Evolution	As per Grandeye this is the design specific behavior of the camera.

## VMD Settings and Motion-based Recording Configuration

VMD setup consists of:

- Event-based recording configuration on MAXPRO NVRs.
- Server VMD (SMART VMD) settings on all video devices supported in MAXPRO NVR.
- Built-in VMD (Camera based VMD) settings on Honeywell IP cameras.

## Overview of MAXPRO NVR Recording Options

Each IP camera configured in the NVR can be set for Continuous (background) recording, event-based recording, or both.

When using event-based recording, Honeywell recommends that you:

- Set up recording on events at a higher frame rate
- Set up continuous (background) recording at a lower frame rate

Continuous (background) recording at a lower frame rate and event-based recording with boosted higher frame rate ensure that:

- Video recording is not missed in the event that the motion is not sufficient to trigger a VMD event on the camera; that is, the motion does not meet the configured VMD threshold on the camera.
- Video records longer than pre and post event recording with the lower frame rate; that is, Continuous (background) recorded video provides better forensics.

MAXPRO NVR supports recording at different frame rates for each camera using a single live stream from the camera and recording quality settings. The NVR Recording Quality Setting options for Continuous (background) and Event recording are:

- Same as Live
- Every IFrame
- Every Second IFrame
- Every Third IFrame.

**Example:**

For a camera configured in the NVR with these settings:

- FPS = 5
- GOP = 5
- Record Quality Setting: Background/Continuous Recording = Every IFrame
- Event Based Recording = Same as Live

The result is a Continuous (background) record rate of 1 FPS and a boosted event-based record rate of 5 FPS.

**Note:**

- A combination of continuous and event-based recording from a camera can be achieved using the relationship between Frames Per Second (FPS) and Group Of Pictures (GOP).
- FPS is a measure of the images every second from the camera, while GOP determines how frames are sequenced.
- Every GOP starts with an I-frame (full image) and is followed by smaller images which are relative to the images preceding it. So, for a GOP of 5 there will be one I-frame for every 5 frames.

**Note:**

The following figure shows an example of three seconds of video at 5 FPS and 5 GOP.



**I-frame Example**

The NVR record Quality Settings for Continuous (background) and Event recording can be used to achieve different level of FPS by selecting one of the following options.

- Same as Live: Every frame is recorded (5 FPS in the example)

- Every I-frame: Every I-frame is recorded (1 FPS in the example)
- Every Second I-frame: Every second I-frame is recorded (1 frame every 2 seconds in the example)
- Every Third I-frame: Every third I-frame is recorded (1 frame every 3 seconds in the example)

For more detailed information on the relationship between FPS and GOP and example settings to achieve different frame rates, refer to the table below:

**Note:** GOP value below 5 may not be achieved from all the cameras.


Live settings		Record quality resulting FPS			
FPS	GOP	Same as Live	Every I frame	Every 2nd I frame	Every 3rd I Frame
30	2	30	15	7.5	5
30	3	30	10	5	3.33
30	5	30	6	3	2
30	10	30	3	1.5	1
30	15	30	2	1	0.67
30	16	30	1.88	0.94	0.63
30	20	30	1.5	0.75	0.5
30	30	30	1	0.5	0.33

## Configuring the Pre and Post Event Recording Settings

See the [Event Recording Settings](#) section on page 163 for more information on configuring the pre and post event recording settings.

# Configuring Camera Settings for VMD-Based Recording

- Step 1. Click the Configurator tab and then the Camera tab to open the Camera configuration page.



## Camera configuration page

- For built-in (Camera-based) VMD configuration, open the camera web page by clicking Launch Web View for Advanced Setup. See the [Configuring Built-in VMD](#) section on page 414 for more information.
- For Server-based VMD (SMART VMD) configuration, select the Enable SMART VMD check box and click Configure. See the [Server VMD \(SMART VMD\)](#) section on page 414 for more information.

**Note:** Built-in (Camera-based) VMD support in NVR is based on the type of device integration and may not be supported for all devices. Please refer to the MAXPRO NVR compatibility list on HOTA website (<http://www.security.honeywell.com/hota/>) for details. Server VMD (SMART VMD) is supported for all video devices supported by NVR.

- Step 2. Select a camera to configure the following items in the Camera pane:

- Continuous Recording (default=24x7): In the Continuous Recording drop-down list, select the appropriate value. Honeywell recommends 24x7 for continuous recording. There are several standard options for scheduled recording. You can define additional schedules in the Schedules tab.
- Event Based Recording (default=NONE): In the Event based Recording drop-down list, select the appropriate value. Select a setting other than NONE to activate event-based recording. The typical setting would be 24x7. There are also several standard options for scheduled recording. You can define additional schedules in the Schedules tab.

## Server VMD (SMART VMD)

See the [Server VMD \(SMART VMD\)](#) section on page [414](#) for more information.

## Configuring Built-in VMD

To Configure Camera based VMD on Honeywell IP Cameras:

Use the Camera Web Client to configure VMD on the camera itself.

For motion detection, an Administrator can enable and configure up to five zones within a scene. The enabled and configured zones are monitored for motion.

- Step 1. Click the Video Analytics tab.
- Step 2. Click the Region drop-down list in the Video Motion Detection pane, then select a region from the five available.
- Step 3. Click the VMD drop-down arrow, and then select Enable.
- Step 4. The regions appear as colored rectangles in their default positions. Click and drag the box to resize and place it over the camera image. This box is the region of interest.
- Step 5. Click Motion Threshold and then select the sensitivity level:
  - Low (30%) (most sensitive)
  - Medium (50%)
  - High (80%) (least sensitive).

It is recommended that you use the medium sensitivity at 50% as the initial setting. It can be further adjusted as explained in [Fine Tuning the Video Motion Detection](#) section on page [414](#).

- Step 6. Click Apply.

**Note:**

- To ensure that the VMD settings have been applied, navigate to another tab, and then back to the Video Settings tab. Check the VMD settings for the changes you made.
- In the unlikely event that the VMD settings are not applied, please try to log off from the software and log on again. Then repeat step 1 through step 5 above.

## Disabling Motion Detection

To disable a zone, click the VMD drop-down arrow and then select Disable.

## Fine Tuning the Video Motion Detection

For optimum results, adjust the VMD configuration to match the camera field of view, regions of interest and other factors. The recommended configuration procedure is:

- Step 1. Identify areas in the image where motion detection alarms should be triggered. In some applications, motion anywhere in the image needs to be reported. In other applications, you may wish to monitor specific areas such as doors, parking lot entrances, or other areas of interest.
- Step 2. Select one of the five available regions for each area of interest and draw the region-of-interest box for that region to fully cover the area of interest.

Tip: The camera only measures motion inside the drawn box. For example, a person or vehicle moving along the boundary of the box may or may not trigger an alarm, because their motion is only partially evaluated. Therefore, it is important to adjust the region-of-interest boxes to fully cover the required areas of interest.

- Step 3. Test your initial configuration setup by observing VMD performance to ensure that relevant scene motion triggers alarms and to ensure that the camera is not reporting false alarms (such as VMD alarms triggered due to image noise). In cameras with a wide field of view, or when activity happens far away from the camera, people and vehicles may appear rather small in the image. In such cases, it may not be possible to apply a single area of interest to the whole field of view to reliably detect motion. In such cases, Honeywell recommends covering the camera view with multiple, smaller region-of-interest boxes, concentrating on specific areas where motion alarms are important, such as entrances, restricted access areas, and so on.
- Step 4. Use the medium sensitivity of 50% as the initial setting. You can adjust this further if required.

**Note:** *Observe VMD performance in all expected lighting conditions after the initial configuration is applied. Ensure that relevant scene motion triggers alarms and ensure that the camera is not reporting false alarms (such as VMD alarms triggered due to image noise).*

## Increasing VMD Sensitivity

If the relevant scene motion does not trigger VMD alarms, try the following adjustments to increase VMD sensitivity.

- Decrease the sensitivity level from 80% to 50%, or from 50% to 30%. This change causes smaller objects to trigger alarms and it requires smaller contrast level to report an alarm. This should be the primary adjustment mechanism.
- Reduce the size of the region-of-interest box and, if needed, add more regions. Note that this adjustment causes smaller objects to also trigger VMD alarms.

Tip: After VMD sensitivity is increased, observe the performance in other lighting conditions in case further tuning is required to prevent false alarms.

## Decreasing VMD Sensitivity

If VMD alarms are triggered even when there is no motion and no significant changes in the video, try the following adjustments to decrease VMD sensitivity.

- Increase the sensitivity level from 30% to 50%, or from 50% to 80%. This primary adjustment mechanism increases the required contrast level (or amount of noise) required to trigger an alarm. Higher sensitivity levels also require larger amounts of motion to be observed before a VMD alarm is triggered.
- Increase the size of the region-of-interest box. This adjustment prevents smaller objects (or smaller areas of noise) from triggering VMD alarms.

## VMD Configuration Examples

The sensitivity level examples below are provided only for illustration. Other factors such as lighting level, contrast, and image noise may affect VMD performance and may require further tuning adjustments as described above.

### Normal Field of View


In a normal field of view, with a person walking in front of the camera, the maximum recommended region-of-interest box sizes would be as shown by the red boxes.



### Sensitivity Level Comparison: Normal Field of View

#### Wide Field of View

In a wide field of view camera, the car shown below ([Sensitivity Level Comparison: Wide Field of View](#)) would be expected to trigger a VMD alarm if the VMD region-of-interest box is not larger than indicated by the red box.



### Sensitivity Level Comparison: Wide Field of View

#### Combination Field of View

For cameras with a wide-angle field of view covering a large outdoor scene, people who walk far away from the camera might appear rather small in the image. If motion needs to be detected in the entire field of view, the following region-of-interest box configuration is recommended.



- Three smaller boxes, set to 30% sensitivity, covering the upper portion of the image where people appear small.
- Two larger boxes, set to 50% sensitivity, covering the lower portion of the image where objects appear larger.

[Combination Field of View Example](#) illustrates a typical region-of-interest box configuration in a combination field of view.



**Combination Field of View Example**

## Event and Alarm Types

This section describes about the various default Event and Alarm types with severity level for Camera, Recorder and SMART VMD.

### Camera Level Events and Alarm types

The following table displays the 17 default camera level Events and Alarm types with description and severity level.

The EventSeverity level above 50 is an alarm and below 50 is an event.

See the [Setting the Alarm Threshold Value](#) section on page 140 to set the Alarm Severity Threshold value.

EventID	EventDescription	EventSeverity
3	Camera User Recording Started	20
4	Camera User Recording Completed	20
5	Camera Disconnected	40
6	Camera Connected	40
7	Camera Continuous Recording Disabled	20
8	Camera Continuous Recording Enabled	20
9	Camera Event Recording Started	30
10	Camera Event Recording Completed	30

EventID	EventDescription	EventSeverity
11	Camera Disabled	20
12	Camera Enabled	20
13	Camera User Recording Error	30
14	Camera NoMotion Detected	40
15	Camera Motion Detected	40
16	Camera Motion Started	40
17	Camera Motion Stopped	30
18	Camera Motion Stopped in all regions	10
139	ExternallInput2	40

## Video Analytics Events

The following table displays the 5 default Video Analytics Events with description and severity level. New EquiP series model cameras (HFD6GR1, HSW2G1, HCD8G, HBD8GR1, H4D8GR1, HDZ302DE, HDZ302D, HDZ302DIN) generates the following events.

**Note:** User need to configure the following events in the camera web page to view in the Alarms window.

EventID	EventDescription	EventSeverity
2066	Face Detected	40
	Tamper Detected	
	Audio Detected	
	Device SD Card Full	
	Device SD Card Failure	

## Recorder Level Events and Alarm types

The following table displays the 4 default Recorder level Events and Alarm types with description and severity level.

EventID	EventDescription	EventSeverity
1	Recorder Connected	70
2	Recorder Disconnected	70
22	Low disk space	70
27	Missing Storage Drive	50

EventID	EventDescription	EventSeverity
33	Low Archival Disk Space	70
34	Missing Archival Drive	50

## SMART VMD Level Events and Alarm types

The following table displays the default SMART VMD level Events and Alarm types with description and severity level.


EventID	Event Description	EventSeverity
28	SMART VMD Connected	40
29	SMART VMD Disconnected	40

## Configuring Loitering & Intrusion Trace Alarms

H4L6GR2 and HBL6GR2 camera models support both Intrusion Trace and Loitering Trace Alarms. User needs to configure these alarms in specific camera web page. You need to first upgrade the firmware of the camera and then configure the alarms.

### How to upgrade the Firmware of a camera

- Step 1. Launch the required camera web page.
- Step 2. Click the Setup tab.
- Step 3. On the left pane, navigate to System Setup > Upgrade. The Upgrade page is displayed as shown below.



Upgrade Firmware - Setup Page


Step 4. Click Import to import the Latest Firmware file and then click Upgrade.

## How to configure Loitering Trace Alarm

**Note:** You can configure and use only one alarm license at once. If you want to view another type of alarm then uninstall the previous firmware, install the required firmware and then configure the alarm.

Tip: The below procedure is also applicable to configure the Intrusion Trace Alarms.


Step 1. After the camera firmware upgrade is done, in the camera web page navigate to Video Analytics > Smart Plan. The Smart Plan page is displayed on the left side as shown below.



### Smart Plan Setup Page


Step 2. Under Smart Plan, turn ON the Extensional smart function option. The Extensional smart function tab is enabled.

Step 3. Click the Extensional smart function tab to view the LoiterTrace alarms as shown below.




### Extensioal smart function page

Step 4. Click Open. The Xtralis authentication window is displayed as shown below.



### Xtralis Login


Step 5. Enter the credentials and then click OK. The LoiterTrace page is displayed as shown below.



### Loiter Trace Page


Step 6. Under Configure > Calibrate tab:

- a. Click Take Snapshot under Current front marker to take the snapshot and adjust the viewer on the right pane as shown below.



### Loiter Trace Configuration

- b. Click Take Snapshot under Current back marker to take the snapshot and adjust the viewer on the right pane as shown below




### Loiter Trace - Calibrate

- c. Click Save once done.

Step 1. Under Configure > Zones tab:


- a. Add and edit the detection zones and masking zones.
- b. Drag to move the zones and circles to change the shapes as shown below.
- c. Click Save once done.



### Loiter Trace - Zones

Step 1. Under Configure > Parameters tab:


a. Set the global parameters as shown below.



### Loiter Trace - Parameters

b. Click Save once done.

- Step 1. Once the configuration is done, click the Live tab. The Live View tab is displayed.
- Step 2. Click Start Loiter Logging button at the bottom of page to start loitering process. Based on the global parameters set the loiter alarms are generated and displayed on the left pane as shown below. These alarms are also generated in MAXPRO NVR > Alarms window. Similarly you can configure the Intrusion Trace Alarms.



### Loiter Trace - Live View Logs



# MAXPRO® NVRs - AXIS Camera/Encoders Discovery and Configuration (using ONVIF)

This section describes the steps to discover and configure the AXIS Camera/Encoders as an ONVIF device in MAXPRO NVRs.

If you have questions concerning this document, please contact Honeywell Technical Support. See the back cover for contact information.

## Step 1: Enable ONVIF Web Service on AXIS Camera/Encoder

### Scenario Description

If you are unable to discover AXIS cameras/encoders using ONVIF compliance standard in MAXPRO® NVR, ensure that ONVIF Web service is enabled and set up on the AXIS device.


The above scenario is noticed if you log on to the camera web page (for example to set the IP address on the AXIS device) prior to discovering and configuring the device in NVR through ONVIF; as a result the ONVIF Webservice gets disabled automatically.

Perform the steps in [Option 1: Add a ONVIF user in the camera web page](#) section on page 426. or [Option 2: Reset to factory default settings](#) section on page 427 to enable ONVIF on the AXIS devices.

**Note:** *AXIS P1347 Network Camera is used as an example to show the steps required. Perform similar steps for other AXIS ONVIF devices.*


## Option 1: Add a ONVIF user in the camera web page.

- Step 1. Log on to the AXIS camera web page. The AXIS camera home page appears with live video.
- Step 2. Click Setup and then navigate to System Options > ONVIF. The User List dialog box appears.



### User List

- Step 3. Click the Add button. The ONVIF User Setup dialog box appears (see [Figure](#) ).




#### **ONVIF User Setup**

- Step 4. Type the user name and password in the respective boxes.
- Step 5. Confirm the password and then click OK. The newly added user is displayed in the User List box. Ensure that you enter the same User name and Password in MAXPRO® NVR Discovery (Advance Settings) dialog box.


### **Option 2: Reset to factory default settings**

- Step 1. Log on to the AXIS camera web page. The AXIS camera home page appears with live video.
- Step 2. Click Setup and then navigate to System Options > Maintenance. The Server Maintenance page appears.



### Server Maintenance

Step 3. In the Maintain Server area, click Restore. A confirmation box appears.



Step 4. Click OK.

**Note:** Restore operation resets all the parameters, except the IP and focus parameters, to the original factory settings.


Step 5. Add and discover the AXIS camera in MAXPRO NVR using the default user name root and password pass.

## Step 2: Discover and Configure the AXIS Camera/Encoder in MAXPRO® NVR

Step 1. In MAXPRO NVR, click the Configurator tab. The System page displays by default.

Step 2. Click the Camera tab to open the Camera page.


Step 3. Click the Auto Discovery button, the Auto Discovery screen is displayed.



Step 4. After the discovery, to add the AXIS cameras, first clear the check boxes corresponding to all other cameras other than AXIS cameras.

Step 5. Select a AXIS camera that you want to add under. type the User Name and Password of the third party AXIS camera as shown in the following figure. See the [Configuring the Auto Discovery Settings](#) section on page 180 for more information.

**Note:** The default user name is root and password is pass.



#### Axis Credentials

Step 6. Click Apply.

Step 7. In the Discover cameras here area, click Add to add the camera.

# PATCHES RELEASED ON TOP OF NVR 4.0

## Overview

This chapter lists the various patches that are released on top of MAXPRO NVR 4.0. It also explains the enhancements that you can experience after installing the specific patch.

In this chapter...

Section	See page...
<a href="#">AXIS Patch</a>	page C-431
<a href="#">Skylake Patch</a>	page C-431

## AXIS Patch

Patch Version: (Build 87H\_T2 patch)

Installation: To be installed on top of MAXPRO NVR 4.0

## Issues Fixed

The following are the issues fixed in this patch:

- AXIS camera stops responding after upgrading the firmware version to 6.30.1. This issues is fixed by providing AXIS new Firmware support 6.XXXX.
- Fixed the SMART VMD Issue: Recording is not in progress for the cameras which are configured only for motion based recording. However, motion based alarms are generated.

## Skylake Patch


Patch Version: (NVR 4.0 SP1 Build 97)

Installation: To be installed on top of MAXPRO NVR 4.0

## Release Highlights:

This Patch includes the following enhancements:

- Step 1. Supports Sky-Lake Processor
- Step 2. For Archival under Delete Archived Recordings After > Continuous recording drop-down, new deletion schedules are implemented such as 2,3,4 and 5 years as highlighted below.



- Step 3. Updated the Resolutions for Equip S2 series (HICC-2500MI, HIVDC-2500MI) cameras.
- Step 4. Updated the Number of Streams [3 Streams] for Equip S2 series (HICC-2500MI, HIVDC-2500MI) cameras.
- Step 5. Support for 15 Performance series camera s models.
- Step 6. Limit for Rendering Camera can be increased in Registry. The default value is 20. See [How to increase the Limit for Rendering Camera](#) section for more information.

## Issues Fixed


The following are the issues fixed in this patch:

- Step 1. Sandy-Bridge Issue: Provided the support to disable the GPU Rendering feature from Preferences dialog box. See [How to Disable the GPU Rendering](#) section for more information.
- Step 2. I18N: Fixed the issue: Values are not displaying in the Archival drop-down list in Polish language
- Step 3. Fixed the Clip Player Day light Saving Time issue
- Step 4. T2 Patch changes - Axis v6.0 support and fixed the SVMd issue
- Step 5. Fixed the Incorrect GPU driver installation and the cameras are not rendering issue.



# How to increase the Limit for Rendering Camera


- Step 1. Open the Registry Editor window.
- Step 2. Navigate to HKEY\_LOCAL\_MACHINE\SOFTWARE\Wow6432Node\Honeywell\Max proNVR\TrinityFramework\Client and then double-click GPU\_CAMERA\_LIMIT on the right pane. The Edit DWORD dialog box appears as shown below.



- Step 3. In the Value data field, modify the value based on your requirement and then click OK. The default value is 20.

# How to Disable the GPU Rendering

- Step 1. Click the Preferences option in the user menu. The Preferences dialog box is displayed. By default, the General Settings tab is selected.
- Step 2. Click the Rendering Settings tab as shown below.



- Step 3. Select the Enable GPU Rendering check box to enable and to render video using GPU.  
OR  
Clear the Enable GPU Rendering check box to disable GPU Rendering.

# INDEX

## A

- Acknowledgement and Clearing of Alarms 242
- Adding Analog Cameras 170
- Adding Arecont 360 Camera 165
- Adding AXIS 360 Camera 163
- Adding FLIR Camera 170
- Adding IP Cameras/Encoders 139
- Adding Onecam Grandeye Cameras 161
- Adding the Cameras 139
- Admin 98
- Advanced Discovery Settings 147, 185
- Advanced Security 53
- Advantages 52
- Alarm Preview Pane 112
- Alarm Threshold Value 113
- Alternate DNS server 65
- Analog Capture Card Support 49
- Anonymization 44
- Archival 53
- Arecont 360 Camera, Adding 165
- Aspect Ratio 160

- Audio 53
- Auto Add Cameras 130
- Auto Discover Cameras 130
- Auto Discovery 48
- Auto IP Assignment 130
- Automatic Retry for Backfilled Clips 194
- Auto-protection and Auto-updates 321
- AXIS Patch 355
- AXIS 360 Camera, Adding 163

## B

- Backing up the Metadata and Database 321
- Binding the generated certificate with https 283, 292

## C

- Camera Level Events and Alarm types 342
- Certificate Information 296
- Changing Default Port 80 for the MAXPRO Mobile app 271, 342
- Changing Default Port 80 for the MAXPRO Web Client and MAXPRO Mobile app 271

Changing the Default IP address and Machine Name 321  
 Changing the MAXPRO NVR IP Address and Machine Name 64  
 Channels 37  
 Checking the Connection with the MAXPRO NVR Server 242  
 Clip Export 52  
 Closing The MAXPRO® NVR SE User Interface 120  
 Commissioning 59  
 Complete Installation 83  
 Compression 146, 174  
 Computer Name 65  
 Configurator Tab 107  
 configure Loitering Trace Alarm 344  
 Configuring Cameras 139  
 Configuring Diagnostic Settings 115  
 Configuring MAXPRO NVR 60, 123  
 Configuring MAXPRO NVR SE 123  
 Configuring Oncam Grandeye Cameras 160  
 Configuring System Settings 131  
 Configuring the Advance Settings 116  
 Configuring the Disk Management Settings 135  
 Configuring the Input and Output for an Analog Camera 177  
 Configuring the Input and Output for an IP Camera 187  
 Configuring the Monitor Display Properties 65, 65  
 Configuring the New EquiP Model Camera 167  
 Configuring the OSD Settings 114  
 Configuring the Schedules 185  
 Configuring the Snapshot Clip Export Settings 114  
 Configuring the System Settings 131  
 Configuring the Timeline Settings 115  
 Connecting a PTZ Camera 74  
 Connecting a Video Source 72  
 Connecting Control Outputs 73  
 Creating Self Signed Certificate 280, 286  
 Creation of Clips 243  
 Creation of Images 243  
 Custom Installation 89  
 Customizing MAXPRO NVR Single-box Turnkey Solutions (XE,SE,PE) 321

## D

Default 100  
 Default IP addresses 64  
 Default Settings 118  
 Deleting A Profile 101  
 Deleting Cameras 185  
 Device Listing 242  
 Devices Window 105  
 Diagnostic Settings 115  
 DVR 35

## E

Easy Configuration 48  
Edge Syn Recording 49  
Edge Sync Settings 133  
Efficient Event and Alarm Viewing Capability 50  
E-mail Notification 52  
Email Settings 132  
Enable Recording During On Demand Streaming 195  
Enriched Video Viewing Experience 50  
Event and Alarm Types 342  
Event Recording 147, 176  
Event Recording Settings 132  
Event Server Configuration 133  
Exit 130

## F

Familiarizing 104  
FCC Compliance Statement 25  
Firewall settings 125  
Flexible Licensing 47  
FLIR Camera, Adding 154  
Form Factor 37  
Four Eye Authentication 44  
FPS 110

## G

General System Settings 131  
Generating Event History 244

Getting to Know the MAXPRO NVR User Interface 104  
GOP 146, 174  
GPU Rendering 357  
GPU Rendering Support 48

## H

Help Tab 109  
Help tab 109  
Holidays/Exceptions Settings 135  
Honeywell devices 125  
Honeywell provided systems 97  
Honeywell's boxed solutions 59, 118  
How to enable Anonymization 198  
How to enable Four Eye Authentication 201  
How to Install MAXPRO® NVR 79  
How to upgrade the Firmware 344  
H.265 145  
H.265 cameras 51  
H.265 Codec Support 51

## I

Immervision Support 159  
Important Safeguards 26  
Industry Standards 47  
Installing MAXPRO Web Client Manually 342  
Installing the Certificate 284, 293  
Installing Web Client 274  
Integration Capability 52

Intended Audience 25  
Internet Protocol Version 4 (TCP/IPv4) 65  
Introducing Web Client 273  
Introduction 273  
IP expertise 36

## K

Keyboard Support 52

## L

Live Video from Cameras 242  
Logging Off 104  
Logging on 97  
Logging On To MAXPRO NVR SE 97  
Logging On Using Profiles 97  
Logon using Touch ID 311  
Loitering & Intrusion Trace Alarms 344  
Looping Output Termination 73  
LPR - Event Server Management 48

## M

Making Connections 72  
Managing Analog Cameras 159  
MAXPRO NVR 35  
MAXPRO NVR Clip Player 52  
MAXPRO NVR DVD 79  
MAXPRO NVR PE 37  
MAXPRO NVR SE 37

MAXPRO NVR SE server addresses 97  
MAXPRO NVR Software 37  
MAXPRO NVR Software Prerequisites 79  
MAXPRO NVR System Architecture 54  
MAXPRO NVR Web Client Features 280, 286  
MAXPRO NVR Wizard 60  
MAXPRO NVR XE 37  
MAXPRO Status Monitor 49  
MAXPRO Web Configurator 48  
MaxProNVRMachineNameUtility.exe 65  
MAXPRO®NVRs - AXIS Camera/Encoders Discovery and Configuration (using ONVIF) 349  
Meta Data Conversion Utility 52, 326  
Mobile Apps 53  
Modifying A Profile 101  
Multicast Enabled 145  
Multi-channel Encoders 153  
Multi-language Support 52  
MultiStream 48

## N

NeoEngine Server 102  
New EquiP Camera Model Dewarping 51  
New EquiP Series Camera Models Support 51  
NIC2 64

## O

Offline Mode 326  
On Demand live Streaming 49

On Screen Display (OSD) s 109

ONVIF standards 36

Operator Log Report 244

OSD Settings 114

## P

Panning, Tilting, and Zooming 243

Panomorph Settings 159

Password 98

Password Complexity 45

Patches Released 355

Performing PTZ operations 280

Playback of recorded video 243

Port Forwarding 102

Powering on the MAXPRO NVR Unit 63

Privacy Protection Settings (GDPR Favored) 44

profile 100

Profile Cameras 52

Profile-G 49

PSIA 36

PTZ 75

## R

Rear Panel Connectors 68

Recommendation to use Low bandwidth stream option 193

Recorder Level Events and Alarm types 343

Recording and Playback Operations 49

Region of Interest (ROI) 182

Registration and Licensing 120

Rendering Camera 356

Report tab 109

Reports 52

Role based Operator Privileges 48

RTSP Settings 156

## S

Salvo View 244

Scheduled Metadata and Database Backup 321

Scheduled Task for Backing up the Metadata and Database 321

Scope 31

Search 51

Search Tab 108

Search tab 108

Searching for Recorded Video in the IP Engine 244

Server Address 100

Server IP/Name 100

Setting preferences 109

Setting the MAXPRO Web Configurator 274

Setting up a site 97, 123, 273, 355

Setting up the MAXPRO NVR 59

Setting up the server and client computers 59

Settings for the MAXPRO NVR Single-box Turn-key Solution 61

Settings for the MAXPRO NVR Software-Only Solution 61

Simultaneous Video Recording and Video Viewing 50

Skylake Patch 355

SMART Motion Search 51

Snapshot Clip Export Settings 114

Spot Monitoring 182

Storage 37

System and Performance Improvements 46

## T

Task bar 129

Third Party ONVIF Profile G supported cameras 48

Timeline 243

Timeline Settings 115

Traditional VMD (Cameras and Head-ends) 183

trinity 98

Trinity Controller 102

Trinity Server 102

## U

UltraKey 75

Uninstalling MAXPRO Web Client 274

Uninstalling MAXPRO® NVR 92

Updating Cameras 154

upgrade the Firmware of a camera 344

Upgrade to MAXPRO NVR 5.0 258

Upgrading MAXPRO NVR 92

Upgrading to MAXPRO NVR 4.1 271

Upgrading to MAXPRO NVR 4.1 Build 123 Rev B 271

UPS 63

User Friendly and Feature Rich User Interface 49

User menu 119

Username 98

## V

Venus 51

Verifying the Touch ID 311

Video Analytics Events 343

Video Motion Detection (VMD) Support 50

Video Rendering 110, 111

Video Surround Feature 52

view Anonymized video 200

Viewer 129

Viewer Tab 105

VOD 49

## W

Warranty and Service 28

Web Client 53

Window



## Honeywell Building Technologies – Security Americas (Head Office)

Honeywell Commercial Security

715 Peachtree St. NE

Atlanta, GA 30308

[www.security.honeywell.com/](http://www.security.honeywell.com/)

☎ +1 800 323 4576

## Honeywell Building Technologies – Security Mexico

Mexico: Av. Santa Fe 94, Torre A, Piso 1, Col. Zedec,

CP 0121, CDMX, Mexico.

Colombia: Edificio Punto 99, Carrera 11a.

98-50, Piso 7, Bogota, Colombia.

clarsupport@honeywell.com

☎ 01.800.083.59.25

[www.honeywell.com](http://www.honeywell.com)

## Honeywell Colombia SAS

Carrera 11A # 98-50

Edificio Punto 99, Piso 7, Bogotá DC

Colombia

## Honeywell Building Technologies – Security Middle East/N. Africa

Emaar Business Park, Sheikh Zayed Road

Building No. 2, 2nd floor, 201

Post Office Box 232362

Dubai, United Arab Emirates

☎: +971 44541704

[www.honeywell.com/security/me](http://www.honeywell.com/security/me)

## Honeywell Building Technologies – Security Europe/South Africa

Aston Fields Road, Whitehouse Industrial Estate

Runcorn, WA7 3DL,

United Kingdom

[www.honeywell.com/security/uk](http://www.honeywell.com/security/uk)

☎ 08448 000 235

## Honeywell Building Technologies – Security Northern Europe

Stationsplein Z-W 961,

1117 CE Schiphol-Oost, Netherlands

[www.security.honeywell.com/nl](http://www.security.honeywell.com/nl)

☎ +31 (0) 299 410 200

## Honeywell Building Technologies – Security Deutschland

Johannes-Mauthe-Straße 14 72458 Albstadt, Germany

[www.security.honeywell.de](http://www.security.honeywell.de)

☎ +49 (0) 7431 801-0

## Honeywell Building Technologies – Security France

Immeuble Lavoisier

Parc de Haute Technologie 3-7 rue Georges Besse 92160 Antony, France

[www.security.honeywell.com/fr](http://www.security.honeywell.com/fr)

☎ +33 (0) 1 40 96 20 50

## Honeywell Building Technologies – Security & Fire (Pacific)

Honeywell Ltd. 9 Columbia Way, BAULKHAM HILLS NSW 2153

Visit: [www.honeywellsecurity.com.au](http://www.honeywellsecurity.com.au). Email: hsf.comms.pacific@Honeywell.com

☎ Tech Support: Australia: 1300 220 345, New Zealand: +64 9 623 5050

## Honeywell Building Technologies – Security Italia SpA

Via Achille Grandi 22, 20097 San Donato Milanese (MI), ITALY

[www.security.honeywell.com/it](http://www.security.honeywell.com/it)

## Honeywell Commercial Security - España

Josefa Valcárcel, 24

28027 - Madrid

España

[www.honeywell.com](http://www.honeywell.com)

☎ +34 902 667 800

## Honeywell Building Technologies – Security Россия и СНГ

121059 Moscow, UI, Kiev 7 Russia

[www.security.honeywell.com/ru](http://www.security.honeywell.com/ru)

☎ +7 (495) 797-93-71

## Honeywell Building Technologies – Security Asia Pacific

Building #1, 555 Huanke Road,

Zhang Jiang Hi-Tech Park Pudong New Area,

Shanghai, 201203, China

[www.asia.security.honeywell.com](http://www.asia.security.honeywell.com)

☎ 400 840 2233

## Honeywell Building Technologies – Security and Fire (ASEAN)

Honeywell International Sdn Bhd

Level 25, UOA Corp Tower, Lobby B

Avenue 10, The Vertical, Bangsar South City

59200, Kuala Lumpur, Malaysia

Visit Partner Connect: [www.partnerconnect.honeywell.com](http://www.partnerconnect.honeywell.com)

Email: [buildings.asean@honeywell.com](mailto:buildings.asean@honeywell.com)

## Technical support (Small & Medium Business):

Vietnam: ☎ +84 4 4458 3369

Thailand: ☎ +66 2 0182439

Indonesia: ☎ +62 21 2188 9000

Malaysia: ☎ +60 3 7624 1530

Singapore: ☎ +65 3158 6830

Philippines: ☎ +63 2 231 3380

## Honeywell Home and Building Technologies (India)

HBT India Buildings

Unitech Trade Centre, 5th Floor,

Sector – 43, Block C, Sushant Lok Phase – 1,

Gurgaon – 122002, Haryana, India

Visit Partner Connect: [www.partnerconnect.honeywell.com](http://www.partnerconnect.honeywell.com)

Email: [HBT-IndiaBuildings@honeywell.com](mailto:HBT-IndiaBuildings@honeywell.com)

Toll Free No: 1-800-103-0339

☎ +91 124 4975000

## Honeywell Building Technologies – Security and Fire (Korea)

Honeywell Co., Ltd. (Korea)

5F SangAm IT Tower,

434, Worldcup Buk-ro, Mapo-gu,

Seoul 03922, Korea

Visit: <http://www.honeywell.com>

Email: [info.security@honeywell.com](mailto:info.security@honeywell.com)

Customer support: [HSG-CS-KR@honeywell.com](mailto:HSG-CS-KR@honeywell.com); +82 1522-8779

☎ +82-2-799-6114



**Document: 800-26013-C - MAXPRO®NVR 6.7 Installation and Configuration Guide – 2/2021**

[www.honeywell.com/security](http://www.honeywell.com/security)

+1 800 323 4576 (North America only)

<https://honeywellsystems.com/ss/techsupp/index.html>

[www.honeywell.com/security/uk](http://www.honeywell.com/security/uk)

+44 (0) 1928 754 028 (Europe only)

<https://honeywellsystems.com/ss/techsupp/index.html>