



HBM2280

Product introduction

<https://www.youtube.com/watch?v=rBJ6exujLjU>

https://www.youtube.com/watch?v=aJTJVTM_1ng&t=12s

CONTENT

§1 SAFETY	1
§1.1 SIGNAL EXPLANATION	1
§1.2 ARC WELDING DAMAGE	1
§1.3 THE KNOWLEDGE OF ELECTRIC AND MAGNETIC FIELDS	5
§2 SUMMARY	6
§2.1 BRIEF INTRODUCTION	6
§2.2 MODULE EXPLANATION	7
§2.3 WORKING PRINCIPLE	7
§2.4 VOLT-AMPERE CHARACTERISTIC	8
§3 INSTALLATION AND ADJUSTMENT	9
§3.1 PARAMETERS	9
§3.2 DUTY CYCLE & OVER HEAT	10
§3.3 MOVEMENT AND PLACEMENT	10
§3.4 POWER SUPPLY INPUT CONNECTION	11
§3.5 POLARITY CONNECTION (MMA)	11
§3.6 ASSEMBLING THE EQUIPMENT(TIG)	12
§4 OPERATION	13
§4.1 LAYOUT FOR THE PANEL	13
§4.2 CONTROL PANEL	15
§4.3 ARGON ARC WELDING OPERATION	19
§4.3.1 TIG welding (AT operation)	19
§4.3.2 TIG welding (TF operation)	20
§4.4 WELDING PARAMETER	21
§4.4.1 Joint forms in TIG/MMA	21
§4.4.2 The explanation of welding quality	22
§4.4.3 TIG Parameters Matching	22
§4.5 OPERATION ENVIRONMENT	24
§4.6 OPERATION NOTICES	24
§5 MAINTENANCE & TROUBLESHOOTING	25
§5.1 MAINTENANCE	25
§5.2 TROUBLESHOOTING	26
§5.3 ELECTRICAL PRINCIPLE DRAWING	29

§1 SAFETY

§1.1 Signal Explanation



• The above signals mean warning! Notice! Running parts and getting an electric shock or thermal parts will take damage for your body or others. The corresponding notices are as follows. It is quite a safe operation after taking several necessary protection measures.

§1.2 Arc Welding Damage

• The following signals and word explanations are to some damages for your body or others happening on the welding operation. While seeing these, please remind of yourself or others to be dangerous.

• Only ones who are trained professionally can install, debug, operate, maintain and repair the equipment.

• During the operation, non-concerned people should be left, especially for children.

• After shut off the machine power, please maintain and examine the equipment according to §5 because of the DC voltage existing in the electrolytic capacitors.



ELECTRIC SHOCK CAN KILL.

• Never touch electrical parts.

• Wear dry, hole-free gloves and clothes to insulate yourself.

• Insulate yourself from work and ground using dry insulation. Make certain the insulation is large enough to cover your full area of physical contact with work and ground.

• Take carefully when using the equipment in small place, falling-off and wet circumstance.

• Never close the machine power before installation and adjustment.

• Ensure to install the equipment correctly and ground the work or metal to be welded to a good electrical (earth) ground according to the operation manual.

• The electrode and work (or ground) circuits are electrically "hot" when the welder is on. Do not touch these "hot" parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.

• In semiautomatic or automatic wire welding, the electrode, electrode reel, welding head, nozzle or

semiautomatic welding gun are also electrically "hot".

- Always be sure the work cable makes a good electrical connection with the metal being welded. The connection should be as close as possible to the area being welded.
- Maintain the electrode holder, work clamp, welding cable and welding machine in good, safe operating condition. Replace damaged insulation.
- Never dip the electrode in water for cooling.
- Never simultaneously touch electrically "hot" parts of electrode holders connected to two welders because voltage between the two can be the total of the open circuit voltage of both welders.
- When working above floor level, use a safety belt to protect yourself from a fall should you get a shock.



FUMES AND GASES CAN BE DANGEROUS.

- Welding may produce flames and gases hazardous to health. Avoid breathing these fumes and gases. When welding, keep your head out of the fume. Use enough ventilation and/or exhaust at the arc to keep fumes and gases away from the breathing zone. When welding with electrodes which require special ventilation such as stainless or hard facing or on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes, keep exposure as low as possible and below Threshold Limit Values using local exhaust or mechanical ventilation. In confined spaces or in some circumstances, outdoors, a respirator may be required. Additional precautions are also required when welding on galvanized steel.
- Do not weld in locations near chlorinated hydrocarbon vapors coming from degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.
- Shielding gases used for arc welding can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.
- Read and understand the manufacturer's instructions for this equipment and the consumables to be used, including the material safety data sheet and follow your employer's safety practices.



ARC RAYS CAN BURN.

- Use a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the

arc when welding or observing open arc welding.

- Use suitable clothing made from durable flame-resistant material to protect your skin and that of your helpers from the arc rays.
- Protect other nearby personnel with suitable, non-flammable screening and/or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.



SELF-PROTECTION

- Keep all equipment safety guards, covers and devices in position and in good repair. Keep hands, hair, clothing and tools away from V-belts, gears, fans and all other moving parts when starting, operating or repairing equipment.
- Do not put your hands near the engine fan. Do not attempt to override the governor or idler by pushing on the throttle control rods while the engine is running.



DO NOT

- add the fuel near an open flame welding arc or when the engine is running. Stop the engine and allow it to cool before refueling to prevent spilled fuel from vaporizing on contact with hot engine parts and igniting. Do not spill fuel when filling tank. If fuel is spilled, wipe it up and do not start engine until fumes have been eliminated.



WELDING SPARKS can cause fire or explosion.

- Remove fire hazards from the welding area. If this is not possible, cover them to prevent the welding sparks from starting a fire. Remember that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas. Avoid welding near hydraulic lines. Have a fire extinguisher readily available.
- Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situation.
- When not welding, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.
- Do not heat, cut or weld tanks, drums or containers until the proper steps have been taken to insure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause

an explosion even though they have been "cleaned".

- Vent hollow castings or containers before heating, cutting or welding. They may explode.
- Sparks and spatter are thrown from the welding arc. Wear oil free protective garments such as leather gloves, heavy shirt, cuff less trousers, high shoes and a cap over your hair. Wear ear plugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.
- Connect the work cable to the work as close to the welding area as practical. Work cables connected to the building framework or other locations away from the welding area increase the possibility of the welding current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.



Rotating parts may be dangerous.

- Use only compressed gas cylinders containing the correct shielding gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition.
- Always keep cylinders in an upright position securely chained to an undercarriage or fixed support.
- Cylinders should be located:
 - Away from areas where they may be struck or subjected to physical damage.
 - A safe distance from arc welding or cutting operations and any other source of heat, sparks, or flame.
- Never allow the electrode, electrode holder or any other electrically "hot" parts to touch a cylinder.
- Keep your head and face away from the cylinder valve inlet when opening the cylinder valve.
- Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use.

§ 1.3 The knowledge of Electric and Magnetic Fields

Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). The discuss on the effect of EMF is ongoing all the world. Up to now, no material evidences show that EMF may have effects on health. However, the research on damage of EMF is still ongoing. Before any conclusion, we should minimize exposure to EMF as few as possible.

In order to minimize EMF, we should use the following procedures:

- Route the electrode and work cables together - Secure them with tape when possible.
- All cables should be put away and far from the operator.
- Never coil the power cable around your body.
- Make sure welding machine and power cable to be far away from the operator as far as possible according to the actual circumstance.
- Connect the work cable to the workpiece as close as possible to the area being welded.
- The people with heart-pacemaker should be away from the welding area.

§2 SUMMARY

§ 2.1 Brief Introduction

MAGIC MIG-200C welding machine adopts the latest pulse width modulation (PWM) technology and insulated gate bipolar transistor (IGBT) power module, which can change work frequency to medium frequency so as to replace the traditional hulking work frequency transformer with the cabinet medium frequency transformer. Thus, it is characterized with portable, small size, light weight, low consumption and etc.

The machine adopts ZVS and PFC full bridge inverter technology. Single phase alternating current(AC) after full bridge rectifier, after PFC for power factor correction, adopting the boost booster technology, and then through filter, the whole bridge rectifier. In order to improve the efficiency of the power supply, this machine is using ZVS technology and the phase-shifting control the average current control mode, makes the efficiency and power factor of the power supply had a remarkable improvement. At the same time, this machine can realize three welding patterns, such as MMA, MIG, TIG, so it can satisfy all kinds of welding.

MAGIC MIG-200C Characteristics:

- ★ The ZVS soft switch technology reduces the IGBT switching loss.
- ★★ The efficiency of the machine has a lot of improvement, in the state of MMA, it can reach nearly 80%;
- ★ The machine uses the average current control mode, and have general protection functions, for example the limited overshoot, the limit of the pulse width, overvoltage, over-current, over-heating and so on. Those functions obviously improve the stability and security of the welding machine.
- ★ The panel combines two kinds of control modes, making it easy for

user to operate.

- ★ MCU control system, responds immediately to any changes.
- ★ Reduce the weight of the machine, improve the mobility of the welder.

MAGIC MIG-200C is suitable for all positions welding for various plates made of stainless steel, carbon steel, alloyed steel, titanium, magnesium, copper, etc, which is also applied to pipe installation, mould mend, petrochemical, architecture decoration, car repair, bicycle, handicraft and common manufacture.

MMA — Manual Metal Arc welding

PWM — Pulse-Width Modulation

IGBT — Insulation Gate Bipolar Transistor

TIG — Tungsten Inert Gas welding

§2.2 Module Explanation



§2.3 Working Principle


The working principle of MAGIC MIG-200C is shown as the following figure. Single phases work frequency AC 220V (50 Hz) is rectified into DC (about 310V), then is converted to medium frequency AC (about 44KHz) by inverter device (IGBT), after reducing voltage by medium transformer (the main transformer) and rectifying by medium frequency rectifier (fast-recovery diode), and is outputted by inductance filtering. The circuit adopts current feedback control technology to insure current output stably. Meanwhile, the welding current parameter can be adjusted continuously and steplessly to meet with the requirements of welding craft.



§2.4 Volt-Ampere Characteristic

MAGIC MIG-200C welding machine has an excellent volt-ampere characteristic, whose graph is shown as the following figure. The relation between the conventional rated loading voltage U_2 and the conventional welding current I_2 is as follows:

When $I_2 < 600A$, $U_2 = 10 + 0.04I_2 (V)$; When $I_2 > 600A$, $U_2 = 34(V)$.



§3 Installation and Adjustment

§3.1 Parameters


Model	MAGIC MIG-200C		
Rated input voltage (V)	1-220V		
Frequency (Hz)	50-60		
	MIG	TIG	MMA
Rated input power (KW)	5.7	4.37	6.3
Rated input current (A)	36.0	28.1	40.5
Rated input apparent power (KVA)	7.8	6.21	8.9
Welding current adjust range (A)	10-200		
Welding voltage adjust range (A)	10-26V		
Duty Cycle (40°C, 10min)	25%	200A	
	60%	150A	
	100%	130A	
No load voltage (V)	50V (adjustable)		
Power factor	MIG 0.73	TIG 0.70	MMA 0.71
Machine figure size (length x width x height)	460*223*421		
Efficiency (%)	≥80%		
Protection class	IP23		
Insulation class	F		
Net Weight (kg)	15.5		

cooling	AF
Wire diameter (mm)	Fe: 0.6/0.8/0.9/1.0/1.2; 0.8/1.0 Al: 0.9/1.0 Flux: 0.9/1.0/1.2
Electrode Type	6013, 7018, 7014 etc

§3.2 Duty cycle & Over heat

The letter "X" stands for duty cycle, which is defined as the proportion of the time that a machine can work continuously within a certain time (10 minutes). The rated duty cycle means the proportion of the time that a machine can work continuously within 10 minutes when it outputs the rated welding current.

The relation between the duty cycle "X" and the output welding current "I" is shown in the right figure.



If the welder is over-heat, the IGBT over-heat protection unit inside it will output an instruction to cut output welding current, and brighten the over-heat pilot lamp on the front panel. At this time, the machine should be relaxed for 15 minutes to cool the fan. When operating the machine again, the welding output current or the duty cycle should be reduced.

3.3 Movement and placement

Please take care for the welder when moving it, and do not make it sloped.

It also can be moved by the handle on the top of the welder. Place the welder well when moving it to the right position. When the machine gets to the destination, it needs to be fixed up to avoid gliding.

When using forklift, its arm length must be long enough to reach the outside so as to ensure lifting safely.

The movement may result in the potential danger or substantive hazard, so please make sure that the machine is on the safe position before using it.

§3.4 Power supply input connection

MAGIC MIG-200C welding machines' power supply connects to 220V.

When the power supply voltage is over the safe work voltage, there are over voltage and under voltage protection inside the welder, the alarm light will on, at the same time, the current output will be cut off.


If the power supply voltage continually goes beyond the safe work voltage range, it will shorten the welder life-span. The below measures can be used:

- Change the power supply input net. Such as, connect the welder with the stable power supply voltage of distributor;
- Induce the machines using power supply in the same time;
- Set the voltage stabilization device in the front of power cable input.


§3.5 Polarity Connection (MMA)

MMA (DC): Choosing the connection of DCEN or DCEP according to the different electrodes.

Please refer to the electrode manual.



§3.6 Assembling the equipment (TIG)



Workpiece is connected to the positive electrode of welding machine, and welding torch is connected to the negative electrode, which is called DC POSITIVE CONNECTION; otherwise, that is called DC NEGATIVE CONNECTION. Generally, it is usually operated in DC POSITIVE CONNECTION in TIG welding mode.

The control cable of torch switch consists of 2 wires, pedal control of 3 wires and the arm socket has 14 leads.

Consumable parts for TIG torch, such as tungsten electrode, tip, gas nozzle, electrode shield (short-long), please enquire us by mail or phone according to the accessory codes.

When TP-series welding machines are operated in HF ignition method, the ignition spark can cause interferences in equipment near the welding machine. Be sure to take specially safety precautions or shielding measures.

§4 Operation

§4.1 Layout for the panel



- 6 MIG gun quick connector The MIG welder's positive polarity output.
- 7 Positive output The welder's positive polarity output.
- 8 Shield gas connector Is connected to the gas input pipe of torch.
- 9 Arm socket Is connected to the torch switch control wire. (It has 14 leads and lead 8- lead 9 are connected to torch switch control wire).
- 10 Negative output The welder's negative polarity output.
- 11 Shield gas input joint To connect one head of the gas hose while the other head of which is connected to argon gas cylinder.

- 12 Power source switch Switch to "ON", the welder is turned on, while switch to "OFF", the welder is turned off.
- 13 Power source input To connect power source.
- 14 Fan When the electric welding machine is over-heat, the fan operates. It is used for cooling the components and parts inside the welder.

§4.2 Control panel



Overview

The key feature of the control panel is the logical way in which the controls are arranged. All the main parameters needed for day-to-day working can easily be

- selected with the keys.
- altered with the adjusting dial.
- shown on the display during welding.

The illustration below shows an overview of the main settings needed for day-to-day working. the following section is a detailed description of these settings.

(1) Current and wire feeding speed adjusting knob




In different mode of welding, this button has diverse function. In the mode of MMA, it is used to adjust the welding current, in the state of MIG, it is used to regulate the wire feeding speed. The range of the current and speed are displayed in the table.

TYPE	MAG3C MIG-200C
The range of adjusting current (A)	10-200
The range of wire feeding speed (m/min)	3.0-25

(2) The LCD display




According to the different welding state, this displayer will display the state of the working and the related setting parameters. For example, in the state of MMA, when the user sets the related parameters on the basis of using state, it will display the related parameters such as current, ARC force, welding-way, Diameter, Thickness, the Electrode and so on. When in the state of welding, it will display the setting parameters, current voltage and current.




(3) The control knob



In the process of use, this knob is mainly used for switching and confirm the page. When shifting the button right or left, the corresponding page will jump to the right or left. When pressing the knob, the page jump into the lower page. For example, when in the state of MMA, knob rotation and page jump show in the figure below.



The direction of the page jumping while shifting the knob in the right



(4) The adjusting button of voltage, down slope and arc force



In the different mode of welding, this knob has different function:

- (1) In the mode of MMA, it can adjust the arc force, the range is 0-10;
- (2) In the mode of TIG, it can adjust the time of down slope;
- (3) In the mode of MIG, it can adjust the welding voltage, the range is 10-25V.

(5) The knob of the inductance



The button is used for adjusting the output inductance, the range is 0-10, so as to make the machine welding performance is better.

NOTE:


Only "Parameter selection keys" and "Adjusting dial" can be used in the welding process.
Only "Rod electrode welding key", and "Adjusting dial" can be used on MMA mode.

§4.3 Argon Arc Welding Operation

§4.3.1 TIG welding (4T operation)

The start current and crater current can be pre-set. This function can compensate the possible crater that appears at the beginning and end of the welding. Thus, 4T is suitable for the welding of medium thickness plates.

Pulsed TIG long welding (4T):




Introduction:

- 0: Press and hold the gun switch, Electromagnetic gas valve is turned on. The shielding gas starts to flow;
 - 0- 1): Pre flow time, adjustment range of pre flow time :0.1-1.0S;
 - 1): Striking success, adjustment range of start current: 5-250A (315A);
 - 12) Loosen the gun switch, the output current slopes up from start current; if the output pulse function is turned on, the output current is pulsed;
 - 12- 13): Output current slopes up to the setting current value; adjustment range of up slope time 0-10.0S ;
 - 13- 14): Welding process. During this period, the gun switch is loosen;
- Note: If the output pulse function is turned on, the output current is pulsed. If the output pulse function is turned off, the output current is DC current;
- 14) Repress down the gun switch, the output current slopes down to crater current; if the output pulse function is turned on, the slope down current is pulsed;
 - 14- 15): Down slope time, adjustment rang of down slope time: 0-10.0S;
 - 15- 16): Crater current holds time; adjustment range of crater current: 5-250A (315A);

- 16: Loosen the gun switch, stop arc, and keep on argon flowing;
- 16-17: Post flow time, adjustment range of post flow time: 0.1-10.0S;
- 17: Electromagnetic valve is closed and stop argon flowing. Welding is finished.

§4.3.2 TIG welding (JT operation)

Pulsed TIG short welding (JT):



Introduction

- 0: Press and hold the gun switch, Electromagnetic gas valve is turned on. The shielding gas starts to flow;
- 0-11: Pre flow time, adjustment range of pre flow time :0.1-1.0S;
- 11-12: Striking success, the output current slopes up to the setting current from minimum current (5A); if the output pulse function is turned on, the slope up current is pulsed;
- 12-13: During the whole welding process, the gun switch is pressed and held without releasing;
Note: If the output pulse function is turned on, the output current is pulsed. If the output pulse function is turned off, the output current is DC current;
- 13: Loosen the gun switch, the output current slopes down; if the output pulse function is turned on, the slope down current is pulsed;
- 13-14: The output current slopes down to minimum current (5A), stop arc; adjustment range of down slope time: 0-5S;
- 14-15: Post flow time, adjustment range of post flow time: 0.1-10.0S;
- 15: Electromagnetic valve is closed and stop argon flowing. Welding is finished.

Short circuit protect function:

- ① TIG /DC/LIFT: If the tungsten electrode touches the workpiece when welding, the current will drop to 30A, which can reduce the tungsten spoilage furthestly, prolong the using life of the tungsten electrode, and prevent tungsten clipping.
- ② TIG /DC/HP: If the tungsten electrode touches the workpiece when welding, the current will drop to 0 within 1s, which can reduce the tungsten spoilage furthestly, prolong the using life of the tungsten electrode, and prevent tungsten clipping.
- ③ MMA operation: if the electrode touches workpiece over two seconds, the welding current will drop to the 0 automatically to protect the electrode.


Prevent arc-break function: TIG operation, Avoid arc-break with special means, even if arc-break occurs the HF will keep the arc stable.

Notices:

- Check the condition of welding and connection units firstly, otherwise there will be malfunction such as ignition spark, gas leakage, out of control and so on.
- Check that whether there is enough Argon gas in the shield gas cylinder, you can test the electromagnetic gas valve through the switch in the front panel.
- Do not let the torch aim at your hand or else of your body. When you press the torch switch, the arc is ignited with a high-frequency, high-voltage spark, and the ignition spark can cause interferences in equipment.
- The flow rate is set according to the welding power used in the job. Turn the regulation screw to adjust the gas flow which is shown on the gas hose pressure meter or the gas bottle pressure meter.
- The spark ignition works better if you keep the 3mm distance from the workpiece to the tungsten electrode during the ignition.

§4.4 Welding Parameters

§4.4.1 Joint forms in TIG/MMA



a butt joint b lap joint c corner joint d T joint

§4.4.2 The explanation of welding quality

The relation of welding area color & protect effect of stainless steel

Welding area color	argent , golden	blue	red-grey	grey	black
Protect effect	best	better	good	bad	worst

The relation of welding area color & protect effect of Ti- alloy

Welding area color	bright argent	orange-yellow	blue-purple	excess	white powder of titanium oxid
Protect effect	best	better	good	bad	worst

§4.4.3 TIG Parameters Matching

The corresponding relationship between gas nozzle diameter and electrode diameter

Gas nozzle diameter/mm	Electrode diameter/mm
6.4	0.5
8	1.0
9.5	1.6or2.4
11.1	3.2

Notice: the above parameters originate from 《Welding Dictionary》 P142, Volume 1 of Edition 2.

Welding current range/A	DC positive connection	
	Gas nozzle diameter/mm	Gas flow rate/L•min ⁻¹
10-100	4-9.5	4-5
101-150	4-9.5	4-7
151-200	6-13	6-8
201-300	8-13	8-9

tungsten electrode diameter /mm	sharpened of the electrode diameter/mm	angleofcone(°)	background current/A
1.0	0.125	12	2-15

1.0	0.25	20	5-30
1.6	0.3	25	8-50
1.6	0.8	30	10-70
2.4	0.8	35	12-90
2.4	1.1	45	15-150
3.2	1.1	60	20-200

TIG of stainless steel (single root welding)

Workpiece thickness /mm	Joint form	tungsten electrode diameter/mm	welding wire diameter/mm	Argon gas flow rate/L•min ⁻¹	welding current (DCEP)	Welding speed/cm•min ⁻¹
0.8	Butt joint	1.0	1.6	5	20-50	66
1.0	Butt joint	1.6	1.6	5	50-80	56
1.5	Butt joint	1.6	1.6	7	65-105	30
1.5	Corner joint	1.6	1.6	7	75-125	25
2.4	Butt joint	1.6	2.4	7	85-125	30
2.4	Corner joint	1.6	2.4	7	95-135	25
3.2	Butt joint	1.6	2.4	7	100-135	30
3.2	Corner joint	1.6	2.4	7	115-145	25
4.8	Butt joint	2.4	3.2	8	150-225	25
4.8	Corner joint	3.2	3.2	9	175-250	20

Notice: the above parameters originate from 《Welding Dictionary》 P136, Volume 1 of Edition 2.

Parameters of piping back sealing welding for mild steel (DCEP)

Piping diameter Φ/mm	Tungsten electrode diameter/mm	Gas nozzle diameter/mm	Welding wire diameter/mm	Welding current/A	Arc voltage/V	Argon flow rate / L•min ⁻¹	Welding rate / cm•min ⁻¹
38	2.0	8	2	75-90	11-13	6-8	4-5
42	2.0	8	2	75-95	11-13	6-8	4-5
60	2.0	8	2	75-100	11-13	7-9	4-5
76	2.5	8-10	2.5	80-105	14-16	8-10	4-5

108	2.5	8~10	2.5	90~110	14~16	9~11	5~6
133	2.5	8~10	2.5	90~115	14~16	10~12	5~6
159	2.5	8~10	2.5	95~120	14~16	11~13	5~6
219	2.5	8~10	2.5	100~120	14~16	12~14	5~6
273	2.5	8~10	2.5	110~125	14~16	12~14	5~6
325	2.5	8~10	2.5	120~140	14~16	12~14	5~6

Notice: the above parameters originate from 《Welding Dictionary》 P167, Nihon 1 of Edition 2.

§4.5 Operation Environment

- Height above sea level is below 1000m.
- Operation temperature range: -10℃~+40℃.
- Relative humidity is below 90 % (20%), relative humidity is below 50 % (40%).
- The inclination of the power source does not exceed 10°.
- Protect the machine against heavy rain or in hot circumstance against direct sunshine.
- The content of dust, acid, corrosive gas in the surrounding air or substance can not exceed normal standard.
- Take care that there is sufficient ventilation during welding. There is at least 30cm free distance between the machine and wall.

§4.6 Operation Notices

- Read §1 carefully before attempting to use this equipment.
- Connect the ground wire with the machine directly, and refer to §3.5.
- In case closing the power switch, no-load voltage may be exported. Do not touch the output electrode with any part of your body.
- Before operation, no concerned people should be left. Do not watch the arc in unprotected eyes.
- Ensure good ventilation of the machine to improve duty ratio.
- Turn off the engine when the operation finished to economize energy source.
- When power switch shuts off protectively because of failure. Don't restart it until problem is resolved. Otherwise, the range of problem will be extended.

§5 Maintenance & Troubleshooting

§5.1 Maintenance

In order to guarantee that arc welding machine works high-efficiently and in safety, it must be maintained regularly. Let customers understand the maintenance methods and means of arc welding machine more, enable customers to carry on simple examination and safeguarding by oneself, try one's best to reduce the fault rate and repair times of arc welding machine, so as to lengthen service life of arc welding machine. Maintenance items in detail are in the following table.

- Warning: For safety while maintaining the machine, please shut off the supply power and wait for 5 minutes, until capacity voltage already drop to safe voltage 36V!

date	Maintenance item
Daily examination	<p>Observe that whether panel knob and switch in the front and at the back of arc welding machine are flexible and put correctly in place. If the knob has not been put correctly in place, please correct; if you can't correct or fix the knob, please replace immediately;</p> <p>If the switch is not flexible or it can't be put correctly in place, please replace immediately; Please get in touch with maintenance service department if there are no accessories.</p> <p>After turn-on power, watch/listen to that whether the arc welding machine has shaking, whistle calling or peculiar smell. If there is one of the above problems, find out the reason to get rid of; if you can't find out the reason, Please contact local this area agent or the branch company.</p> <p>Observe that whether the display value of LED is intact. If the display number is not intact, please replace the damaged LED. If it still doesn't work, please maintain or replace the display PCB.</p> <p>Observe that whether the min/max value on LED accords with the set value. If there is any difference and it has affected the normal welding craft, please adjust it.</p> <p>Check up that Whether fan is damaged and is normal to rotate or control. If the fan is damaged, please change immediately. If the fan does not rotate after the arc welding machine is overheated, observe that whether there is something blocked in the blade, if it is blocked, please get rid of; if the fan does not rotate after getting rid of the above problems, you can poke the blade by the rotation direction of fan. If the fan rotates normally, the start capacity should be replaced; if not, change the fan.</p> <p>Observe that whether the fast connector is loose or overheated. If the arc welding</p>

	<p>machine has the above problems, it should be fastened or changed.</p> <p>Observe that Whether the current output cable is damaged. If it is damaged, it should be wrapped up, insulated or changed.</p>
Monthly examination	<p>Using the dry compressed air to clear the inside of arc welding machine. Especially for clearing up the dust on radiator, main voltage transformer, inductance, IGBT module, the fast recover diode and PCB, etc.</p> <p>Check up the bolt in arc welding machine, if it is loose, please screw down it. If it is skid, please replace. If it is rusty, please erase rust on bolt to ensure it works well.</p>
Quarter-yearly examination	<p>Whether the actual current accords with the displaying value. If they does not accord, they should be regulated. The actual current value can be measured by the adjusted plier-type ampere meter.</p>
Yearly examination	<p>Measure the insulating impedance among the main circuit, PCB and case, if it below 1MΩ, insulation is thought to be damaged and need to change, and need to change or strengthen insulation.</p>

§ 5.2 Troubleshooting

- Before arc welding machines are dispatched from the factory, they have already been debugged accurately. So forbid anyone who is not authorized by us to do any change to the equipment!
- Maintenance course must be operated carefully. If any wire becomes flexible or is misplaced, it maybe potential danger to user!
- Only professional maintenance personal who is authorized by us could overhaul the machine!
- Guarantee to shut-off the arc welding machine's power before turn on the outline of the equipment!
- If there is any problem and has no the authorized professional maintenance personal, please contact local agent or the branch company!

If there are some simple troubles of TP-series welding machine, you can consult the following overhauling chart:

S/N	Troubles	Reasons	Solution
-----	----------	---------	----------

S/N	Troubles	Reasons	Solution	
1	Turn on the power source, and fan works, but the power pilot lamp is not on.	The power light damaged or connection is not good.	Check and repair the front panel and input wire	
		The transformer of power is broken	Repair or change the transformer	
		Control PCB failures	Repair or change the control panel	
2	Turn on the power source, and the power lamp is on, but fan doesn't work	There is something in the fan	Clear out	
		The start capacitor of fan damaged	Change capacitor	
3	Turn on the power source, the power lamp is not on, and fan doesn't work	The fan motor damaged	Change fan	
		No power supply input	Check whether there is power supply	
4	The fan inside the machine damaged	The fan inside the machine damaged	Change it (10A)	
		The LED in the display is not intact.	Change the LED	
5	The max and min value displayed doesn't accord with the set value.	The max value is not accordant (refer to § 3.1)	Adjust potentiometer trim on the power board.	
		The min value is not accordant (refer to § 3.1)	Adjust potentiometer trim on the current meter.	
6	No no-load voltage output (MMA)	The machine is damaged	Check the main circuit and the PTH.	
7	No gas flow (TIG)	Gas cylinder is close or gas pressure is low	Open or change the gas cylinder	
		Something in the valve	Remove it	
		Electromagnetic valve is damaged	Change it	
8	Gas always flows	The gas-valve on the front panel is on	The gas-valve on the front panel is off	
		Something in the valve	Remove it	
		Electromagnetic valve is damaged	Change it	
9	The adjustment knob of pre-gas time on the front panel is damaged	The welding current potentiometer on the front panel connection is not good or damaged	Repair or change the potentiometer	
		The welding current displayed isn't accordant with the actual value.	Adjust potentiometer trim on the power board.	
10	The welding current displayed isn't accordant with the actual value.	The max value displayed isn't accordant with the actual value. (Please refer to § 3.1)	Adjust potentiometer trim on the power board.	
		The min value displayed isn't accordant with the actual value. (Please refer to § 3.1)	Adjust potentiometer trim on the power board.	
11	The penetration of molten pool is not enough.	The welding current is adjusted too low	Increase the welding current.	
		The arc is too long in the welding process	Use 2T operation	
12	The alarm lamp on the front panel is on	Over heat protection	Too much welding current	Reduce the welding current output

S/N	Troubles	Reasons	Solution
		Working time too long	Reduce the duty cycle (work intermittently)
		Over-voltage protection	Power supply fluctuates Using the stable power supply
		Low-voltage protection	Power supply fluctuates Using the stable power supply
			Too many machines using power supply in the same time Reduce the machines using power supply in the same time
		Over-current protection	Unusual current in the main circuit Check and repair the main circuit and drive PCB