ALEOS 4.14.0 Software Configuration

User Guide for AirLink RV55



41113782 Rev. 2

- **Important** Notice Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e., have errors) or be totally lost. Although significant delays or losses of data are rare when wireless devices such as the Sierra Wireless product are used in a normal manner with a well-constructed network, the Sierra Wireless product should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. Sierra Wireless accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using the Sierra Wireless product, or for failure of the Sierra Wireless product to transmit or receive such data.
- Liability The information in this manual is subject to change without notice and does not represent a commitment on the part of Sierra Wireless. SIERRA WIRELESS AND ITS AFFILIATES SPECIFICALLY DISCLAIM LIABILITY FOR ANY AND ALL DIRECT, INDIRECT, SPECIAL, GENERAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS OR REVENUE OR ANTICIPATED PROFITS OR REVENUE ARISING OUT OF THE USE OR INABILITY TO USE ANY SIERRA WIRELESS PRODUCT, EVEN IF SIERRA WIRELESS AND/OR ITS AFFILIATES HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR THEY ARE FORESEEABLE OR FOR CLAIMS BY ANY THIRD PARTY.

Notwithstanding the foregoing, in no event shall Sierra Wireless and/or its affiliates aggregate liability arising under or in connection with the Sierra Wireless product, regardless of the number of events, occurrences, or claims giving rise to liability, be in excess of the price paid by the purchaser for the Sierra Wireless product.

- **Patents** This product may contain technology developed by or for Sierra Wireless Inc. This product includes technology licensed from QUALCOMM[®]. This product is manufactured or sold by Sierra Wireless Inc. or its affiliates under one or more patents licensed from MMP Portfolio Licensing.
- **Copyright** © Sierra Wireless. All rights reserved.

Trademarks Sierra Wireless[®], AirPrime[®], AirLink[®], and the Sierra Wireless logo are registered trademarks of Sierra Wireless.

Windows[®] and Windows Vista[®] are registered trademarks of Microsoft Corporation.

 $Macintosh^{\ensuremath{\mathbb{R}}}$ and Mac OS $X^{\ensuremath{\mathbb{R}}}$ are registered trademarks of Apple Inc., registered in the U.S. and other countries.

 $\mathsf{QUALCOMM}^{\texttt{B}}$ is a registered trademark of $\mathsf{QUALCOMM}$ Incorporated. Used under license.

Other trademarks are the property of their respective owners.

Contact Information

Sales information and technical support, including warranty and returns	Web: sierrawireless.com/company/contact-us/ Global toll-free number: 1-877-687-7795 6:00 am to 5:00 pm PST
Corporate and product information	Web: sierrawireless.com

>>> Contents

Introduction	4
Overview	4
Sierra Wireless AirLink Products 14	4
About Documentation	4
Tools and Reference Documents 1	5
Gateway Configuration	6
Recovery Mode	
Toolbar	
Configuring your AirLink Gateway	
Saving a Custom Configuration as a Template	
Applying a Template	
Update the ALEOS Software and Radio Module Firmware	
Recommendations	
Step 2—Update the ALEOS Software and Radio Module Firmware	
Updating Only the Radio Module Firmware	
Enterprise LAN Management	3
Configuring Your Gateway for use in a PCI Compliant System	4
Status	6
Home	6
Cellular	9
Cellular status for Ready to Connect eSIM	;9
General	.0
Statistics	
Monitor	
Advanced	
Ethernet	
Wi-Fi	
LAN IP/MAC Table	
VPN	8

Security
Services
Location
Serial
Applications
Policy Routing
RSR (Reliable Static Routing)
PNTM (Private Network Traffic Management)71
About
WAN/Cellular Configuration
Monitoring WAN Connections
Related Features
General
Interface Priority
Bandwidth Throttle
Ping Response
Cellular
General
Multi SIM: Multiple SIM Card Support
Manual SIM Switching
Automatic SIM Switching
Network Credentials
Band Setting
Cellular Watchdog
IPv6 Support
Multiple SIM Configuration

SIM PIN	100
Enable the SIM PIN	100
Change the SIM PIN ALEOS Enters at Reboot	
Disable the SIM PIN	
Static Configuration	
Ethernet > Monitor	
Reliable Static Routing (RSR)	
Policy Routing	
Dynamic Mobile Network Routing (DMNR)	
PNTM Configuration	121
Wi-Fi Configuration	124
General	124
Access Point (LAN) Mode	128
Captive Portal	132
WEP	135
WPA/WPA2 Personal	
WPA2 Enterprise	137
Client (WAN) Mode	137
LAN Configuration	
DHCP/Addressing	144
General	144
IP Passthrough	146
DHCP Reservation List	
DHCP Server Options	
DHCP Vendor Specific Options	
Ethernet	
RADIUS Framed Route	156

41113782

	USB	156
	Installing the USB Drivers	157
	Link WAN Coverage	159
	Host Port Routing.	160
	Global DNS	163
	PPPOE	165
	Configure the AirLink gateway to Support PPPoE	166
	Configuring a PPPoE Connection in Windows 7	167
	VLAN	170
	VRRP	171
	Host Interface Watchdog	176
VF	PN Configuration	
	General	
	Standard Vs. Legacy IPsec Implementation	
	VPN Failover	
	IPsec (Legacy)	
	GRE	
	OpenVPN Tunnel.	
		201
Se	curity Configuration	206
	Solicited vs. Unsolicited	
	Port Forwarding	206
	Single port	
	Range of ports	208
	DMZ	211
	Port Filtering—Inbound	212
	Port Filtering — Outbound	213
	Trusted IPs—Inbound (Friends)	215
	Trusted IPs—Outbound	216

MAC Filtering
Services Configuration
ALMS (AirLink Management Service) 218
ACEmanager
Power Management
Dynamic DNS
Understanding Domain Names
Dynamic Names
SMS
SMS Overview
Sending SMS Commands to an AirLink Gateway
SMS Modes
Password Only
Control Only
Gateway Only
Control and Gateway
SMS Wakeup
SMS Security
Trusted Phone Number
SMS Password Security
SMS > Advanced
SMSM2M
AT (Telnet/SSH)
Email (SMTP)
Management (SNMP)
Time (NTP)
Authentication
LDAP Authentication
RADIUS Authentication
TACACS+ Authentication
Device Status Screen

Location
ALEOS Supported Location Report Protocols
Before Configuring Location
Enable Location Service
Global Settings
Servers 1 to 4
Local/Streaming
Local/Streaming—Local IP Report 300
Events Reporting Configuration
Introduction
Configuring Events Reporting 305
Configuring Events Reporting
Email
SMS
Relay Link
SNMP TRAP
Location Reports
Events Protocol Reports
Turn Off Services
Report Data Group
Event Types
Serial Configuration
RS232 Configuration
General
PAD
Reverse Telnet/SSH
PPP
SLIP
MODBUS
MODBUS Address List
Configuring IP to Serial with Answer and Serial to IP

LED Indicator
Applications Configuration
Data Usage
Garmin
ALEOS Application Framework
I/O Configuration
Analog inputs
Digital inputs
Relay outputs
Current State
Pulse Count
Configuration
Transformed Analog
Admin
Change Password
AAF User Password
Advanced
Reset
Reset to Custom Configuration
Radio Tools
Log
Configure Logs
Trace Level Logging
Remote Logging
View Logs
Radio Module Firmware
Windows Dial-up Networking (DUN) 398
Installing a Device Driver
Creating a Dial-Up Networking (PPP) Connection

Modbus/BSAP Configuration	417
Modbus Overview	417
Telemetry	
Remote Terminal Unit (RTU)	
Supervisory Control and Data Acquisition (SCADA)	
Programmable Logic Controller (PLC)	
Modbus TCP/IP	
Configuring AirLink routers at the Polling Host for Modbus on UDP	
Configuring Remote AirLink routers for Modbus with UDP	
	420
SNMP: Simple Network Management Protocol	421
Management Information Base (MIB)	421
SNMP Traps	421
Sierra Wireless MIB	421
AT Commands	466
	466 466
AT Command Set Summary	
AT Command Set Summary	466
AT Command Set Summary	466 467
AT Command Set Summary	466 467 468 470
AT Command Set Summary	466 467 468 470
AT Command Set Summary	466 467 468 470 476
AT Command Set Summary	466 467 468 470 476 497
AT Command Set Summary Reference Tables. Device Updates Status. WAN/Cellular LAN Wi-Fi. VPN	466 467 468 470 476 497 499
AT Command Set Summary Reference Tables. Device Updates Status. WAN/Cellular LAN Wi-Fi. VPN Security	466 467 468 470 476 497 499 508 514
AT Command Set Summary Reference Tables. Device Updates Status. WAN/Cellular LAN Wi-Fi. VPN Security Services.	466 467 468 470 476 497 499 508 514 515
AT Command Set Summary	466 467 468 470 476 497 499 508 514 515 525
AT Command Set Summary Reference Tables. Device Updates Status. WAN/Cellular LAN Wi-Fi. VPN Security Services Location Serial	466 467 468 470 476 497 499 508 514 515 525 532
AT Command Set Summary	466 467 468 470 476 497 499 508 514 515 525

Applications	 548
Admin	 553
SMS Commands	 556
SMS Command format	 556

Q & A and Troubleshooting
ACEmanager Web UI
Templates
Updating the ALEOS Software and Radio Module Firmware
Poor Wireless Network Connection
Connection not working
Wi-Fi
LTE Networks
SIM Card is Blocked
Remote connections
Radio Band Selection
Low Voltage Standby Mode
Reliable Static Routing (RSR)
Inbound Ports Used by ALEOS
Setting for Band
Ethernet Ports
LAN Networks
Wi-Fi
VPN
Port Forwarding
SMS
AirLink Management Service
Location
Event Reporting
TCP Connections
TCP/IP and UDP/IP Auto Answer
ALEOS Application Framework (AAF)
Network Operator Switching
Glossary of Terms
Index

>> 1: Introduction

Note: This user guide is intended for the AirLink RV55. If you have a different AirLink gateway or router, refer to the ALEOS Software Configuration User Guide for your gateway or router.

Overview

ACEmanager[™] is the free, web-based utility used to manage and configure AirLink[®] gateways. It is a web application integrated in the ALEOS[™] software that runs on the AirLink RV55. AirLink Embedded Operating System (ALEOS) is purpose-built to maintain a wireless connection and to configure the RV55 to the needs of the system. ACEmanager provides comprehensive configuration, monitoring, and control functionality to all AirLink gateways and routers.

ACEmanager enables you to:

- Log in and configure parameters
- Adjust network settings
- Change security settings
- Update events reporting and control outputs
- Update ALEOS software and radio module firmware
- Copy configuration settings to other AirLink RV55s

Since ACEmanager can be accessed remotely over-the-air as well as locally, the many features of ALEOS can be managed from any location.

An ALEOS configuration template can be created using ACEmanager, after a single device is configured and installed, to program other AirLink RV55s with the same configuration values. This enables quick, accurate deployment of large pools of devices.

Sierra Wireless AirLink Products

For more information on specific AirLink products, go to www.sierrawireless.com

About Documentation

Each chapter in the ALEOS Configuration User Guide describes a section (a tab in the user interface) of ACEmanager.

Chapters in this user guide explain:

- Parameter descriptions in ACEmanager
- Relevant configuration details
- User scenarios for certain sections in the guide.

Tools and Reference Documents

Document	Description
AirLink RV55 Hardware User Guide	 This hardware document describes how to: Install the AirLink RV55 Connect the radio antennas Connect a notebook computer and other input/output (I/O) devices Interpret the LEDs and indicators on the AirLink RV55.
ALMS User Guide	AirLink Management Service features online help, videos and "How-To" pages that explain how to use ALMS for the remote management of Sierra Wireless AirLink gateways.

>> 2: Gateway Configuration

To access ACEmanager:

- 1. Insert the SIM card, if applicable. Refer to the AirLink Gateway Hardware User Guide for details.
- 2. Power on the AirLink router.
- **3.** Launch your browser and enter the IP address and port number: https://192.168.13.31:9443

Note: When you first log in, your browser may display warnings related to the self-signed certificate. Please accept any warnings and continue.

ACEmanager is supported on the latest versions of Internet Explorer[®] and Firefox[®].

Antine Parties	ACEmanager

Figure 2-1: ACEmanager: Main Login screen

- **4.** Log in:
 - · User Name: "user" (entered by default)
 - Default Password:
 - For devices that support unique passwords, the default password is printed on the device label.
 - For other devices, the default password is 12345.

Note: ACEmanager sessions, by default, time out in 15 minutes. If there is no activity for this idle timeout period, you are redirected to the Login screen. To change the session idle timeout period, see Session Idle Timeout (minutes) on page 225.

Note: For system security, ensure that you change the default ACEmanager password. The new password must be at least 8 characters long. For more information, see Change Password on page 369.

If your device is using a non-unique default password to log in to ACEmanager, a message to change the default password is displayed.

		It password to log in. recommend you change	your password
Please Change	Your ACEmanager Pass	word	
	Old Password:		
	New Password:		
	Retype New Password:		

Note: By clicking "Not Now", you may continue without changing the default password; however, you must accept the risk of bypassing this critical and strongly recommended security measure.

After your initial log in to ACEmanager, you have the option of displaying the gateway status parameters on subsequent Login screens.

- 1. In ACEmanager, go to Services > Device Status Screen.
- 2. In the Device Status on Login Screen field, select Enable. (For details, see Device Status Screen on page 278.)

LOGIN	
ther tame user	
Palaente	Light
DEVICE STATUS	
Henrork State:	instaurt. Ready
33 (48.5)	(relation) The T
Nation/A Salvice	40
WAR IP Address	25 100.54.15
LTE Bignal Strangth (RSRP)	-114
LTE Signal Quality (#3390).	4
LTE Signal Interference (SIMP)	112
Location Pix:	Location Fix Acquired
Satahite Count:	43
Location (Las, Long):	401720752307014

Figure 2-2: ACEmanager: Main Login screen with Location and Device Status enabled.

If you have Location fields selected on the Device Status screen, but Location Service is disabled, the gateway Login screen will show Location Service Disabled.

Recovery Mode

In the unlikely event that ALEOS becomes corrupted, or if the RV55 is unresponsive to ACEmanager input and AT commands, you can manually put the gateway into recovery mode.

Recovery mode enables you to update the ALEOS software and return the gateway to working order.

Note: ALEOS software updates done in Recovery mode do not preserve any custom settings such as cellular settings, AAF applications, etc.

To enter Recovery mode:

- 1. Use an Ethernet cable to connect the gateway to your computer. (Recovery mode is not supported on USBnet.)
- 2. Power on the AirLink gateway.
- **3.** On the gateway, press the Reset button for more than 20 seconds. (Release the button when the Power LED flashes amber.)
- 4. Launch your browser and enter the IP address and port number http://192.168.13.31:9191.

Note: The HTTPS log-in feature described on page 16 does not apply to Recovery Mode.

The following screen appears:

			Report 1	Set NETT Lags Tagent the
PLOSO PACES				
Bringe.	No file selected	Npdate		
Allong is it recently	vale. The may be due to a standing of	ompart 40.625 emps or a long		

Figure 2-3: Recovery screen

- 5. (Optional) Click Get ALEOS Logs to download a log file for later evaluation.
- 6. Click Browse... and navigate to the appropriate ALEOS software version for your gateway.
- 7. Click Update.

The screen lets you know that the update was successful and automatically reboots the gateway.

	Support Website
INSTALLATION SUCCESS	
$\sum_{i=j_1,\ldots,i}^{N-1}$. We have its properties .	
Do optimentive primer	
	Description 20016 Spring Marrieds, Inc.

When the reboot is complete, the gateway exits Recovery mode, and the ACEmanager Login screen appears.

If you select an inappropriate version of ALEOS, an error message, such as the following appears.

	Sugaret Details
UPDATING	
Drynun software update failed. Abor Check failed: Could not find signatu package	g or certificate in the
Back	Get ing

If this happens, click the Log button and save the log file for review by Sierra Wireless or your authorized reseller.

Click Back to return to the previous screen to select the correct version of ALEOS.

If you have inadvertently entered Recovery mode, you can exit it by doing one of the following:

- Press the reset button on the gateway to reboot it.
- Click the Reboot button on the Recovery screen.
- Wait 10 minutes. If no action is taken within 10 minutes of the device entering Recovery mode (for example, if the Recovery screen has not been loaded by the web browser), it automatically reboots and exits Recovery mode.

Toolbar

The buttons on the ACEmanager toolbar are:

- Software and Firmware: Updates the ALEOS software and the radio module firmware
- Template:
 - · Download and save a configuration as a template
 - · Upload a saved template to apply settings
- Reboot: Reboots the gateway
- Refresh All: Refreshes all ACEmanager pages
- Help
- Logout

Configuring your AirLink Gateway

There are three options for configuring the AirLink gateway:

Use your browser-based ACEmanager (as detailed in this guide)

- Use a terminal emulator application (e.g., Tera Term, PuTTY, etc.) to enter AT commands for many of the configuration options.
- Use the cloud-based AirLink Management Service application (see www.sierrawireless.com/products-and-solutions/gateway-solutions/alms/ for more details.)

Saving a Custom Configuration as a Template

If you have a gateway configured to match your requirements, you can use ACEmanager to download and save that gateway's configuration as a template and then apply it to other Sierra Wireless AirLink gateways.

Note: Sierra Wireless recommends that templates be created and applied to AirLink gateways running the same version of ALEOS. If you apply a template created using an older version of ALEOS to a gateway running a newer version of ALEOS, settings for newly added features are not updated.

To download and save a custom configuration as a template:

- 1. Connect a laptop to the gateway with the configuration you want to save as a template.
- 2. In ACEmanager, click the Template button on the toolbar.



Figure 2-4: ACEmanager: Template button

The following window appears:

Template	Close
Apply Template Upload and apply a template configuration to your device	This will automatically apply the template requiring a reboot after completion.
Browse No file selected.	Uplead
Download Template You can download a complete comprehensive template of You can specify an optional Template Name as well as o Template Name: Include Passwords: Include Device Info:	

Figure 2-5: ACEmanager: Template window

Use the bottom half of the window to download and save a template.

3. If desired, enter a Template Name. The file is saved using this name and a .xml file extension. Spaces and special characters are not supported, and, if entered, are deleted from the file name.

If no Template name is entered, the file is saved as SWIApplyTemplate.xml.

- 4. Choose whether or not to:
 - Include Passwords

When Include Passwords is selected, passwords configured in ACEmanager (such as the email password, the SMS ALEOS Command password, the Serial PPP password, etc.) are shown in plain text in the template file. When the template is uploaded to a gateway, the passwords are included and replace any existing password configured on the gateway.

If Include Passwords is not selected, password fields are not included in the template file, and existing passwords persist when the template is uploaded to a gateway.

Note: The ACEmanager login password is not included when you select the Include Passwords option.

- **Include Device Info** (selected by default) When selected, the template file includes a "snap-shot" of the current Status tab information with the current settings. This could be useful for troubleshooting.
- 5. Click Download. The download status appears at the bottom of the window.

Template		Close
Apply Template Upload and apply a templat	te configuration to your device.	This will automatically apply the template requiring a reboot after completion
Browse. Not	file selected.	Uplead
	Aete comprehensive template of al Template Name as well as op	your device's configuration here. tional Status Information.
Template Name:	MyTemplate	
Include Passwords.		
Include Device Info:	¥	Download
Status: Template Dow	moad Completer	

Figure 2-6: Download template complete

Once the download is complete, the following window opens:

You have clicsen to	openi	
1 MyTemplate.	ared	
	Document (SIL2 KII)	
	92 566 13 31 9191	
What should firefs	or other weights divise a line of the	
O Domwith	XMLEditor (stefault)	•
W Save File		
11 Do this gat	mutically for files like this from now on	8
	MINES POSSESSON CONTRACTOR	

Figure 2-7: Open or Save the template file

- 6. In most cases, you will want to save the file to your computer for uploading to other AirLink gateways, but you also have the option to open the file.
 - Select Save File and click OK—file is saved to your computer (by default to the Downloads folder). If you entered a template name, the file is saved using that name. Otherwise, it is saved under the default name, SWIApplyTemplate.xml.
 - Select Open and click OK—file opens in a text or XML editor as a human readable file. Use this option if you selected Include Device Info when you saved the file and want to view the device information (the text between the <devicestatus> and </ devicestatus> tags is the snap-shot of the Device Info), or you want to compare this template with another template.

Warning: Do not attempt to change settings directly in the template file. Changing settings in the template file could result in unexpected behavior in the AirLink gateway. Alter the template only if you are specifically directed to do so by your distributor or Sierra Wireless Technical Support.

Tip: If you want to compare a new template with the previous one, download and save the old template before applying the new one. You can use any 3rd party text comparison tool to check the differences between two templates.

Applying a Template

Note: If you are using Internet Explorer 9 to upload the template, see **Templates** on page 559 for instructions on configuring the browser's Internet options to allow the upload.

Note: Sierra Wireless recommends resetting the gateway to the factory default settings before applying the template.

To upload and apply a template to an AirLink gateway:

- 1. Connect the computer (where the template is saved) to the AirLink gateway you want to upload the template to, or connect to the gateway over the air.
- 2. Log in to ACEmanager, and go to Admin > Reset.
- 3. Select the Reset Mode:
 - Preserve Core Settings—Recommended if you are applying a template remotely using a remote ACEmanager connection (or ALMS). For a list of preserved settings, see Reset Configuration on page 380.
 - Reset All—Recommended if you are applying a template locally (i.e your computer is physically connected to the gateway).
- 4. Once the gateway reboots, log in to ACEmanager.
- 5. In ACEmanager, click the Template button on the toolbar.

ACEmanager

Figure 2-8: ACEmanager: Template button

The following window appears:

Template		Close
Apply Template Upload and apply a templa	te configuration to your device	. This will automatically apply the template requiring a reboot after completion.
Browse No	file selected.	Upload
	al Template Name as well as o	f your device's configuration here. ptional Status Information. Coversional

Figure 2-9: ACEmanager: Template window

Use the top half of the window to upload and apply a template to your AirLink gateway.

- 6. Click Browse... and navigate to the template you want to upload.
- 7. Click Open. The template file name appears beside the Browse... button.

Template Close
Apply Template Upload and apply a template configuration to your device. This will automatically apply the template requiring a reboot after completion.
Browse MyTemplate.xml Uplead
Download Template You can download a complete comprehensive template of your device's configuration here. You can specify an optional Template Name as well as optional Status Information.
Tempiate Name: MyTempiate
include Passwords:
include Device Info: V
Status: Template Download Complete!

Figure 2-10: Apply Template file opened

- 8. Click Upload.
- 9. When the upload is complete, a Reboot button appears on the window.

Template		Close
Apply Template Upload and apply a templ	ate configuration to your device	This will automatically apply the template requiring a rebost after completion.
Browse_ My		Upisad
Template Upload Co	mpiete!	
Status: Settings Wr	tten to Device. Reboot is rec	pired!
Reboot		
	plete comprehensive template o al Template Name as well as o	f your device's configuration here. ptional Status Information.
Template Name:		
Include Passwords:		
Include Device Info:	×.	Download
Status: Template Do	wnicad Complete!	

Figure 2-11: Template file uploaded

- 10. Click Reboot.
- **11.** To confirm that the new template has been applied or to find out which template is currently on a gateway, go to Status > About and check the Template Name field.

Note: The Template Name field shows the last template applied and does not indicate any configuration changes made since the last template was applied.

ad updated tone \$10(8)	ta di multi das	1140-0	1000	in a second second			a anticological data	Period and a second	-	-	-
an open come of the party									Sec.2		
these.		Desite Mark				avie .					
Cellular		Table Math	in Type			ENTER					
		latin Mydu	de bilentifier			CELERIC					
Ethernel		lade Firm	an Vicini			SWI9RSOC.)	11 OE 24 US 184	dell printers 20	188821214	8.11	
Deal Vitral i	1	Radic Hands	owe Version			18					
		NU PRI D				1008373, 00	0.061				
LUN IFAMC Salde		Leter PRI	0			W07283, G0	INTRO 802.04	1_000			
VIN	41	Decial Plants				29196243015	010307				
Security		atalian/RA	P Dentra 10			Device ID D	holded				
	-87	tranel No	ic Address			10 14 10 48	1070				
Services		LEOS But	loan Vesia			4.13.8					
Location		LEDS BA	dante			85					
Deal Invited		Device Hard	ware Coolig	and the second		212910000	0000000000000	000000000			
Sec		hod Versio				811					
Applications		Noney Ve	ener :			23-0603	1044236074				
Policy Routing		ICU Form	ere Versten			12.00					
115		COLD Versus				 83					
		weighted the	19			 RVS/ Terry Te	NC.				
PHIM		Antaine COA	A check								
Ahme											

Figure 2-12: ACEmanager: Status > About

Note: If no template has been applied to the gateway since it was set or reset to the factory default settings, the template field is blank.

Update the ALEOS Software and Radio Module Firmware

To take advantage of new features available in the latest version of ALEOS, update the ALEOS software and radio module firmware on your AirLink gateways.

You can use ACEmanager to update one gateway at a time or you can use AirLink Management Service (ALMS) to update one or multiple gateways at the same time.

Important: Sierra Wireless always recommends updating ALEOS to the latest version to take advantage of new features and security updates. If your application requires you to install an earlier version of ALEOS than your current version, please note that Sierra Wireless:

- does not recommend using any version prior to ALEOS 4.9.3.
- recommends that ALEOS devices be reset to factory defaults following any downgrade operation.

Note: ALEOS software releases may not apply to all AirLink devices. Please ensure that the version you select is compatible with your device.

Note: If the update includes a radio module firmware update, the radio module firmware stored on the gateway is also automatically updated. If there is not enough room in the storage, the radio module firmware update fails, so you may need to remove one of the versions stored on the gateway to free up space. For more information, see Radio Module Firmware on page 393.

Step 1—Planning Your Update

- 1. Sierra Wireless recommends that you download a template from the gateway(s) before you begin the update process. For instructions, see Saving a Custom Configuration as a Template on page 20.
- 2. For each of the gateways you want to update, make a note of the:
 - · Device Model
 - · Radio Module Type
 - · Radio Module Identifier

ALEOS Software VersionThis information is available in ALMS and in ACEmanager (Status > About).

		East Court Court
flumme.	Desits Madel	avis.
Cellular	Radic Muthin Type	EMITER
	Flanter Module Identifier	GENERIC
Etherneri	Radio Pierseale Viccient	SWI9930C, 01 08 54 (8 statistic persons 2018/88/21 21 49 11
Doubl With # 5	Radu Hanbare Version	11
	THE PRI D	H108373, 002 081
LINERYNWC Salde	Career PRID	WW7203, GENERAC_802.013_000
VPN	AT Decial Norther	25196248015016307
Security	# LacalizyRAP Dentes D	Device ID Doubled
and the second second	47 Ethand Mar Address	10 14 16 49 10 FB
Services	ALLOS Sultan Version	+118
Location	ALEOS Build survive	-
Deal Instal	Dence Hardware Configuration	2139100000000000000000000000000000000000
	Boot Variante	411
Applications	#7 Baconey Verson	23-0x3:56+425e54
Policy Routing	MCU Fermane Version	82.00
11	MSID Version	10
636	Tempiata Name	RVSTkeydes
PHTM.	Modate COMA check	

Figure 2-13: ACEmanager: Status > About

- **3.** If you are planning to use ACEmanager to do the update:
 - **a.** Go to source.sierrawireless.com and select your product and mobile network operator to get to the download page for your gateway.
 - **b.** Download the new ALEOS software version for your system. If new radio module firmware is available, it is included with the ALEOS software in a .zip file.

Important: Do not install radio module firmware unless you are prompted to do so.

Note: If low power mode (see page 228) or time of day reboot (page 378) are enabled, Sierra Wireless recommends that you disable these features before beginning the update.

Recommendations

If you have any questions about the update process, contact your authorized Sierra Wireless distributor before updating the radio module firmware.

Scheduling the update

The update can take up to 30 minutes to complete, depending on the speed of your network connection. The AirLink gateway being updated will be off-line during the update, so take this into account when scheduling the update.

Important: *BE PATIENT!* The firmware update can take up to 30 minutes to complete. Waiting for the process to complete is faster than troubleshooting the problems that can be caused by interrupting the process midway. (Interrupting the process may result in having to return the gateway to the factory for repairs.)

Note: For LTE-M/NB-IoT AirLink gateways: Due to the lower data rates supported by LTE-M/NB-IoT networks, over-the-air software updates can take an extended period of time. When using a Windows PC and ACEmanager to update ALEOS software over-the-air, please ensure that sleep and low power states are disabled on the PC so that the file transfer is not disrupted. Under these conditions, the ALEOS upgrade may take between 3 to 5 hours.

Sierra Wireless recommends using ALMS or AMM for remote software upgrades.

Step 2—Update the ALEOS Software and Radio Module Firmware

Using ACEmanager to Update a Single AirLink Gateway

To update the ALEOS software and radio module firmware on one AirLink gateway:

1. Connect the AirLink gateway you want to update to your laptop, launch your browser and enter the URL for the gateway as described on page 16. If it is a remote gateway, enter the domain name or public IP (WAN) address.

Note: If you are connected to the gateway remotely, any files transferred to the gateway are transferred over-the-air and you may incur data charges.

2. Log in to ACEmanager.

Default user name: user

Default password: Printed on the device label. If the password is not printed on the label, the default password is 12345.

3. Click the Software and Firmware link.

The Software and Firmware update window opens.

Note: These instructions show typical Software and Firmware update windows. Details such as the ALEOS version, device model, radio firmware version, etc. may vary, depending on the gateway you are updating.

Software and Firmware			Close
arrently installed System informati NLEOS Software Version:	4.8.0	ALEOS Build number:	018
Device Model: Radio Module Type: Radio Firmware Version: 8449			
Select . ALEOS Soft	-		11 2012/02/04 21:00 20
Browse No 1			
1. Initialization			
2. Uploading			Cancel
3. Applying			
4. Rebooting			

Figure 2-14: Software and Firmware update window

The update window gives you the option to update both ALEOS and the radio module firmware, or update only the radio module firmware.

Unless advised otherwise by Sierra Wireless, **select ALEOS software** (which updates ALEOS and prompts you to update the radio module firmware if a newer version is available for your gateway).

4. Click Browse... and navigate to the ALEOS software you downloaded from the Sierra Wireless Web site. This is a .bin file named for the gateway and the ALEOS software version. For example, RV55_4.12.0.010.bin.

Software and F	imware				Slo
Currently installed Byst ALEOS Software V		on 4.8.0	ALEOS 8	kuid number:	018
Device Model:		RV50			
Radio Module Type Badio Firmane Ve					GENNA-UMTS 61 2015/03/04 21:30:3
Select *	ALEOS Soft	eare C Radi	Module Firm	14379	
Brows	e RV5	0_4.9.0.004	bin	Update	
1. in	tialization				
2. Uj	ploading				Cancel
3. Aş	aplying				
4. R	ebooting				

Figure 2-15: ALEOS file selected in Software and Firmware update window

5. Click Update.

The ALEOS software update runs automatically and green check marks appear beside each step as it is completed.

Software and Firms	Nare		Close
Currently installed System Inf			
ALEOS Software Version		ALEOS Build number:	018
Device Model:	RV50		
Radio Module Type:		Radio Module Identifier:	
Radio Firmware Version:	SWI8X15C_05.05	58.00 r27038 carmd-fwbu	Id1 2015/03/04 21:30:23
Select ® ALEO	Software 🔿 Radio	Module Firmware	
Browse	RV50_4.9.0.004	bin Update	
🖌 1. Initializ	ation		
			Cancel
= 2. Upload	ing		Constant
3. Applyin	g		
4. Reboot	ing		

Figure 2-16: ALEOS software update in progress

Important: Do not disconnect the AirLink gateway from the computer, and do not power cycle or reset the gateway during the update. If you see any error messages, refer to the Updating the ALEOS Software and Radio Module Firmware on page 560.

6. Depending on the gateway and your Mobile Network Operator, you may be prompted to update the radio module firmware.

If you do not receive a prompt, the radio firmware is up to date. Proceed to step 9. **Only** if prompted to update the firmware, proceed to step 7.



Figure 2-17: Prompt for Radio Module Firmware

- 7. Under Applying, click Browse... and navigate to the radio module firmware file that was included in the .zip file you downloaded. This is an .iso file named for the gateway's radio module and the mobile network operator's network (or "GENERIC", if it is intended for more than one operator network). For example, MC7354_GENER-IC_2820.iso.
- 8. Click Upload Radio Firmware.

A message appears on the window indicating that the firmware has been successfully uploaded.

Note: Sierra Wireless recommends that you do NOT skip the radio module firmware update unless advised to do so by Sierra Wireless or an authorized distributor. If you choose to skip the radio module firmware update, you'll see the following warning.

WEINER	
De generalité soud the depthé et de Madale Continuing may result la dévice failure requin Praise relative la des sour guide les more detail	ing physical access or a factory return to correct
Continue anossy?	
	OK Cand

Once the radio module firmware is uploaded, the gateway begins applying the firmware upgrade. On the AirLink gateway, the LED chase begins to indicate that the firmware is being applied.

As indicated on the window, the radio module firmware may take 10 to 20 minutes to upload and install.

Important: Do not disconnect the AirLink gateway from the computer or reboot the gateway while the firmware update is in progress. During the radio module firmware update, the gateway LEDs flash rapidly in sequence (an LED chase or caterpillar). When the radio module firmware update is complete, the gateway reboots automatically.

Note: When you update the radio module firmware, the firmware stored on the gateway is also updated. If there is not enough room in the storage, the radio module firmware update fails. In that case, first remove one of the versions stored on the gateway to free up space. For more information, see Radio Module Firmware on page 393.

9. When the update is complete, the AirLink gateway reboots. The Software Update progress window appears.



When the reboot is complete, you are returned to the Login screen.

- **10.** After you log in, go to Status > About.
- 11. Click Refresh.
- **12.** Check the ALEOS Software Version and the Radio Firmware Version fields to confirm that the ALEOS software and the radio module firmware have been updated.

Using AirLink Management Service (ALMS) to Update One or Multiple AirLink gateways Over-the-Air

You can use AirLink Management Service to update the ALEOS software and radio module firmware over-the-air on one or multiple AirLink gateways.

If you don't have an ALMS account:

- 1. In ACEmanager, go to the Services tab and ensure that ALMS is enabled and the server URL is https://na.m2mop.net/device/msci/com. If this is not the case, enter the correct URL, click Apply and then click Reboot.
- 2. Go to www.sierrawireless.com/ALMS for more information.

Updating to ALEOS software with an ALMS account:

- 1. Go to airvantage.net and log in.
- **2.** Follow the instructions in the online ALMS documentation to update the ALEOS software and radio module firmware.

Updating Only the Radio Module Firmware

Important: Use this feature only if directed by Sierra Wireless or an authorized reseller.

If Sierra Wireless or your authorized reseller directs you to update only the Radio Module Firmware:

1. Select the Radio Module Firmware button.

NLEOS Selfware Versien: 4.10.0 ALEOS Build number: 013 Sence Model: LX60 Radio Module Type: WP7601 Radio Muslule Identifier: VERIZON
Radio Module Type: WP2601 Radio Medule Identifier VEB820M
Sada Firmware Version: SW600079 82,18.00.00 000000 peekine 2017/11/02 23(09:88

2. Select the appropriate firmware file for your gateway and click Update. This is an .iso file named for the gateway's radio module and the mobile network operator's network (or "GENERIC", if it is intended for more than one operator network). For example, MC7354_GENERIC_2820.iso.

If you select a file for radio module firmware that is not supported on your gateway, you will see a warning message similar to the following:

WARNING	
Carrier 10 decembratic with AL102. Contraining may maail to dealer Suize requiring ph Physics refer to the communication manufacture.	yrinal access or a factory mum to conser
instali anovany?	
	O Cancel

Unless you have been advised by Sierra Wireless to do so, we recommend that you do not install an unsupported version of the radio module firmware.

3. Click Update.

The radio module firmware update runs automatically and green check marks appear beside each step as it is completed.

4. When the update is complete, the AirLink gateway reboots. The Software Update progress window appears.

OF THARE I	PDATE	
The line	to program	
to net shat down	he dence with the process is completed	1

When the reboot is complete, you are returned to the Login screen.

- 5. After you log in, go to Status > About.
- 6. Check that the Radio Firmware Version has been updated.

Enterprise LAN Management

You can use AirLink gateways in the following configurations:

• Standalone with a connection to a single device

When using the AirLink gateway with a single device, ensure that the device is DHCP enabled.



• With a router

The router allows several devices to use the AirLink gateway's connection to the network. When using the AirLink gateway with a router:


• Configure the router to be DHCP enabled.

And either:

· Configure the router to use Network Address Translation (NAT).

Or

 Configure ALEOS (in ACEmanager) to use Host Port Routing. For information on using ALEOS with a router that is not configured to use NAT, see Host Port Routing on page 160.



Note: Other than for VLANs, ALEOS does not provide DHCP addresses to router connected devices.

Over the Air (OTA) Connections

Access AirLink gateways

You can use an OTA connection to access AirLink gateways that are in either configuration described above (stand alone or with a router).

Access connected devices

To use an OTA connection to access a connected device through the AirLink gateway, configure the device in ALEOS as the DMZ or port forwarding destination. For information on inbound OTA connections to the host, see DMZ on page 211 and Port Forwarding on page 206.

Configuring Your Gateway for use in a PCI Compliant System

The credit card industry requires retailers to comply with Payment Card Industry (PCI) standard to maintain a secure environment when processing payment card transactions. For these transactions, the AirLink gateway acts as a wireless data conduit for routers and PoSs (point-of-sale-terminals) that have been configured for PCI compliance.




Figure 2-18: Sample PCI compliant network

The PCI compliant network must be set up so that:

- The USBnet is on a different subnet from the point-of-sale-terminal.
- All security protocols must be established from the point-of-sale terminal to the payment processor.
- Payment card terminals must be on a dedicated LAN or VLAN.

• The AirLink gateway must be connected to a router that is configured for PCI compliance.

Note: The serial port on the AirLink gateway has no access to the IP data path and does not need to be disabled.

If you are using the AirLink gateway for a payment card industry application, to meet PCI Data Security Standard compliance requirements the following steps must be done by a PCI certified service company.

For each gateway:

- 1. Connect the AirLink gateway to a router that has been configured for PCI compliance.
- **2.** Log in to ACEmanager:
 - User Name: "user" (entered by default)
 - · Default Password:
 - For devices that support unique passwords, the default password is printed on the device label.
 - For other devices, the default password is 12345.

Note: For system security, and in accordance with PCI recommendations, ensure that you change the default ACEmanager password. The new password must be at least 8 characters long. For more information, see Change Password on page 369.

3. Go to Applications > ALEOS Application Framework and set the ALEOS Application Framework field to Disable.

All fields in the Status group are read-only and provide information about the AirLink RV55. Depending on individual settings, the onboard radio module, and the type of network, the actual status pages may look different than the pages shown here.

Tip: To be sure you are viewing the current status for all fields, click the Refresh button on the upper right side of the screen.

On the Status tab, you'll find the following pages:

- Home
- Cellular
- Ethernet
- Wi-Fi
- LAN IP/MAC Table
- VPN
- Security
- Services
- Location
- Serial
- Applications
- Policy Routing
- RSR (Reliable Static Routing)
- PNTM (Private Network Traffic Management)
- About

Home

The Home section of the Status tab is the first page displayed when you log in to ACEmanager. It shows basic information about the WAN network connection, the mobile network connection, and important information about the RV55.

4 41000 (144) (1222)	35.31.99	COMMENT OF STREET, STR	
turner 1			
	[1] Hermoni		
Cathology	All Instance Tasks	Indept Reals	
1.Dest wal			
and a second state	# Adve One Post Appage	1125420524	
Buar WUT	AT Adhes WW Put Address		
LAR IP MILE Table	47 Canvel Mills Pré PreferLongts		
175	MAR Kamarati Interfacia	Cetator	
Sec.	end romant startage	Barw	
Smarily	AT Castomer Sevice Iyame	29(9)(2408-06/00)(207	
families.	Caston Lydense	E theo, O heave, 1 minutes	
Location	() Meaning Englis		
Bast Serbit	DAD Proce	Evaluat	
	DHD Cathe	Dailet	
Applications	CHD Owner	Bugind	
Palicy Busing	APT CHIE Bever 1 (PrvR)	76.963.171.7	
858	AT Chill Server 3 (Pres)	PE HEA.471.8	
	All DAS Server 1 (Pvb)		
PETR	AT LODS Devver 2 (Pvf)		

Figure 3-1: ACEmanager: Status > Home

Field	Description		
General			
Network State	 Current state of the WAN network connection Network Ready—Connected to a mobile broadband network and ready to transfer data Network Ready - eSIM Not Activated—The R2C eSIM (if available) has not been activated in ALMS Network Ready - eSIM Activation State Unknown—The activation state is unknown. This could be because the eSIM activation state has not yet been reported by ALMS (the RV55, the eSIM, and ALMS have not synchronized after device registration or a device reset), or status reports from ALMS have been disabled. Network or server issues may also result in an unknown activation state. If this state persists and you believe the eSIM has been activated, please contact your Sierra Wireless Sales representative. Connected - No Service Network Link Down—The network link is not available Not Connected 		
Active WAN IPv4 IP Address	The current IPv4 WAN IP address for the gateway		
Active WAN IPv6 IP Address	The current IPv6 WAN IP address for the gateway		
Current WAN IPv6 Prefix Length	The length, in bits, of the WAN IPv6 prefix		
IPv4 Network Interface	Current active network interface		

Field	Description			
IPv6 Network Interface	Current active network interface			
Customer Device Name	By default, the name is the serial number of the gateway. If you have configured a device name in the IP Manager section of the Services > Dynamic DNS tab, that name appears in this field.			
Device Uptime	Length of time since the gateway last rebooted (in days, hours, and minutes)			
Advanced (DNS)	<u>.</u>			
DNS Proxy	 Determines which DNS server the connected clients use for domain name resolution Enabled—DNS Proxy is activated. Connected DHCP clients acquire the AirLink gateway's IP address as their DNS server. The AirLink gateway performs DNS lookups on behalf of the clients. Disabled—Connected DHCP clients acquire the DNS servers used by the gateway. To set this option, see DNS Proxy on page 164. 			
DNS Cache	 Status of the DNS Local Cache feature Enabled—The built-in DNS server caches queries and entries, which can reduce WAN traffic overall by sending out less DNS-related traffic. Disabled—DNS queries and entries are not cached. To set this option, see DNS Local Cache on page 164. 			
DNS Override	 Override WAN-granted DNS Enabled—Locally configured DNS servers are used. Disabled—DNS servers provided by the active WAN connection are used. 			
DNS Server 1 (IPv4)	1st DNS server IPv4 address currently in use by the WAN connection to resolve domain naminto IP addresses			
DNS Server 2 (IPv4)	2nd DNS server IPv4 address			
DNS Server 1 (IPv6)	1st DNS server IPv6 address currently in use by the WAN connection to resolve domain names into IP addresses			
DNS Server 2 (IPv6)	2nd DNS server IPv6 address			

Cellular

The Cellular section provides specific information about the connection including the IP address and how much data has been transmitted or received. Some of the information on this ACEmanager page is repeated on the Home page for quick reference.

Cellular status for Ready to Connect eSIM

The Status > Cellular page is labeled **Cellular (R2C Capable)** for devices that support Sierra Wireless R2C eSIM (Ready to Connect embedded SIM), as shown in Figure 3-2. For R2C eSIM-capable devices, the Cellular (R2C Capable) page displays status information about all available external SIM slots and the eSIM. You can find more information about eSIM status items in the following tables.



Figure 3-2: ACEmanager Status > Cellular (R2C Capable)

General

manus with Carbolar	Star W-FI LBH VMI Security Services 5	Lonation Events Reporting David Seriel Applications 572 Admin				
	10.51Pw	Exercise (second second				
		Summer summer summer summer				
have	(Albertata)					
Lotter and	Linear					
	All Phone Technol	34				
Obscient	W Gebas Consettor Pottosi Family	P4				
Deal (10.1)	Column P referen	10.254.123.27				
ADDITION: THEM	Calkier PM Address					
	Callular Poll Prein Langih					
100	W Delase Talk	Conselled				
Security .	M Celular State Details	(P Acquine				
20216	Collair Doll & Coll Connection	Test landed				
Satracau	Germer Avietunt/We	Available				
propriet.	AT 252 Malacon Operator	101.101.0P				
Data Sector	Sarong Nation Operator	TELAS				
	47 Signal Managh-Wittl:	-++				
Apple officer.	47 LTE Signal Strength (WSWP)	-104				
Table Howing	AT LTE INSHAR OXAMI (REMOU	-tr				
810	47 LTE Topul Interference (LEPR)	*3				
	EINECAG	3577188800201804				
Sheet.	AT SM D	89 522 30 10004 30 emility				
	artitizes	ing bits tom				
	WT Mampur of 5984, present					
	AF Parrier DN	Bat				
	of Recordary 100	BAT .				
	Water IN	241				
	All Hadds Technology	17E-shared Pb				
	Helenst Service Tax	40				
	Active Programmy Daniel	UTU BANKD 4				

Figure 3-3: ACEmanager: Status > Cellular > General

Table 3-1:	Reported	Signal	Strength	and	Quality Values	
------------	----------	--------	----------	-----	-----------------------	--

Network	Signal Strength and Quality values		
UMTS	 Signal Strength (RSSI) Signal Quality (ECI0) Received Signal Power Code (RSCP) 		
LTE	 Signal Strength (RSSI) LTE Signal Strength (RSRP) LTE Signal Quality (RSRQ) LTE Signal Interference (SINR) 		

General	
Phone Number	The phone number associated with the Mobile Network Operator account. If the Mobile Network Operator does not allow the account to display the phone number or there is no Mobile Network account for the gateway, "NA" is displayed.
Cellular Connection Protocol Family	The current IP version of the cellular network connection • IPv4 • IPv6 • Both IPv4 and IPv6
	Note: Cellular Connection Protocol Family, Cellular IPv6 Address and Cellular IPv6 Prefix Length do not appear when only IPv4 connections are possible.
Cellular IP Address	IPv4 Cellular WAN IP Address If there is no mobile network connection, 0.0.0.0 is displayed.
Cellular IPv6 Address	Shows the IPv6 Cellular WAN IP Address if an IPv6 connection is established.
Cellular IPv6 Prefix Length	Shows the IPv6 prefix length, in bits, if an IPv6 connection is established.
Cellular State	Current state of the cellular connection: Connected Not Connected No Service

Cellular State Details	Provides additional details about the current cellular state, for example the gateway may not connected because the SIM card is not installed. Possible messages are:			
	Disconnected			
	Connecting			
	Data connection failed. Waiting to retry			
	Not Connected - Radio Connect off			
	Not Connected - Waiting for Activity			
	No SIM or Unexpected SIM Status			
	SIM Locked, but bad SIM PIN			
	SIM PIN Incorrect, 5 Attempts Left			
	SIM PIN Incorrect, 4 Attempts Left			
	SIM PIN Incorrect, 3 Attempts Left			
	SIM PIN Incorrect, 2 Attempts Left			
	SIM PIN Incorrect, 1 Attempt Left			
	SIM PIN Incorrect, 0 Attempts Left			
	SIM Blocked, Bad unlock code			
	SIM Locked: 10 PUK Attempts Left			
	SIM Locked: 9 PUK Attempts Left			
	SIM Locked: 8 PUK Attempts Left			
	SIM Locked: 7 PUK Attempts Left			
	SIM Locked: 6 PUK Attempts Left			
	SIM Locked: 5 PUK Attempts Left			
	SIM Locked: 4 PUK Attempts Left			
	SIM Locked: 3 PUK Attempts Left			
	SIM Locked: 2 PUK Attempts Left			
	SIM Locked: 2 FOR Attempt Left			
	SIM Blocked, unblock code incorrect			
	IP Acquired			
Collular End to				
Cellular End-to- End Connection	Describes the state of the cellular network connection, based on Cellular network monitoring (see Cellular > Monitor on page 103). Possible states are:			
	 Not Verified—The monitoring function is set to disable and therefore the availability of the cellular network cannot be verified. 			
	 Pending—The monitoring function is enabled, but has not yet completed its test. Once the first test is complete, this option only appears again if monitoring is disabled and then re- enabled. 			
	 Established—The monitoring system has determined that service is available on the cellular network. 			
	 Not Established—The monitoring system has determined that the cellular interface has no service (ping test failed). 			
Carrier Availability	Indicates whether or not the mobile network operator (carrier) is able to provide service to the gateway's radio module			
	Possible values:			
	Available			
	Not Available			
SIM Network Operator	The SIM card's home network, i.e, the Mobile Network Operator when the gateway is not roaming			

Serving Network Operator Signal Strength (RSSI)	 The network currently in use This field only appears when the gateway has a network connection. If the gateway is not roaming, this field is the same as the SIM Network Operator field. If the gateway is roaming, this field displays the roaming Mobile Network Operator. Received Signal Strength Indicator The average received signal power measured in the air interface channel Indicates if there is a strong signal available for the AirLink gateway to connect to See also LTE Signal Strength (RSRP) and LTE Signal Quality (RSRQ). The value varies, depending on the network characteristics and the AirLink gateway.			
	RSSI	Si	gnal strength	
	> -78 dBm	G	bod	
	-78 dBm to -93 dBm	Fa	iir	
	-94 dBm to -102 dBn	n Po	oor	
	< -103 dBm	In	adequate	
Signal Quality (ECI0)				
	ECI0	Sign	al quality	
	0 to -6	Good		
	-7 to -10	Fair		
	-11 to -20	Poor		
ESN/EID/IMEI	Electronic Serial Numb	per for the int	ernal radio	
SIM ID	Identification number for the SIM card in use			
APN Status	 Current APN in use by the network connection (Configured) is a default APN based on the SIM card in use. (User Entered) is a custom APN entered manually into the configuration. 			
	• (Configured) is a c		based on the SIM car	
	• (Configured) is a c	a custom AP	based on the SIM can N entered manually i	into the configuration.
Number of SIMs present	(Configured) is a c (User Entered) is Note: APN is configured	a custom AP ed on the WA	based on the SIM can N entered manually i NV/Cellular configura	into the configuration.
Number of SIMs	(Configured) is a c (User Entered) is Note: APN is configure Indicates the number c Indicates which SIM ca	a custom AP ed on the WA of SIMs (inclu ard slot or R2	AN/Cellular configura ding R2C eSIM, if av	into the configuration.
Number of SIMs present	(Configured) is a configured is a configured is a configured is a configured is a configure indicates the number of the num	a custom AP ed on the WA of SIMs (inclu ard slot or R2 cards are inst	ased on the SIM can N entered manually i <i>N/Cellular configura</i> ding R2C eSIM, if av C eSIM (if available) alled, the Primary SI	into the configuration. ation tab. vailable) installed in the RV55.

Allow R2C eSIM Usage	 Status of the Allow R2C eSIM Usage setting. Enable—the R2C eSIM is available to be used for network connections Disable—the R2C eSIM is not available for network connections. Only the external SIM card slots are available. 		
R2C eSIM Activation Status	 Status of the R2C eSIM activation state. This status is retrieved from ALMS. Unknown—the activation state is unknown. This could be because the R2C eSIM activation state has not yet been reported by ALMS (the RV55, the eSIM, and ALMS have not synchronized after device registration or a device reset), or status reports from ALMS have been disabled. Network or server issues may also result in an unknown activation state. 		
	Note: The R2C eSIM activation status depends on ALMS reporting the activation status to the RV55. Due to system latencies, ALMS may not be aware of the R2C eSIM activation status the first time it connects to the RV55. If the R2C eSIM is activated in the meantime, an Unknown state may persist if the Device Initiated Interval is configured to last an extended period of time. 24 hours is the default setting (see page 219 for more infor- mation). On the Services > ALMS page, you can click Connect to trigger a sync to refresh the R2C eSIM state rather than wait for the Device Initiated Interval. Alternatively, you can reboot the RV55 to force a resync with ALMS. If the Unknown state still persists and you believe the R2C eSIM has been activated, please contact your Sierra Wireless Sales repre- sentative.		
	 Not Active—the R2C eSIM has not been activated in ALMS Active—the R2C eSIM has been activated 		
Radio Technology	Type of service being used by the gateway (e.g. LTE, HSPA+, UMTS, HSPA, or GPRS) If you are connected to a network other than that of your Mobile Network Operator, the network service type indicates that you are roaming (and additional charges may apply).		
Network Service Type	Type of network the gateway is connected to (e.g. 4G, 3G)		
Active Frequency Band	Current cellular band being used (LTE BAND 2, etc.)		
Signal Strength an Different radio technolog ACEmanager depend o Values on page 40.	d Quality gies have different ways of reporting signal strength and signal quality. The fields displayed in in the type of network it is connected to. For details, see Reported Signal Strength and Quality		
Received Signal Code Power (RSCP)	The RSCP is the power measured by the receiver on a particular physical channel. It provides an indication of signal strength for UMTS connections, and appears under Cellular > Advanced. Expected values are in the range of -50 dB to -120 dB.		

LTE Signal Strength (RSRP)	Reference Signal Received Power The average signal power of all cell-specific reference signals within the LTE channel Indicates whether the AirLink gateway has a strong connection to the wireless network The value varies, depending on the network characteristics and the AirLink gateway.				
	RSRP	Signal strength			
	> -105 dBm	Good			
	-105 dBm to -115 d	IBm Fair			
	-116 dBm to -1000	dBm Poor			
	< -1000 dBm	Inadequate			
	See also LTE Signal Quality (RSRQ) and Signal Strength (RSSI).				
LTE Signal Quality (RSRQ)Reference Signal Received QualityThe RSRQ indicates the quality of the AirLink gateway's connection to the wireless noise or interference affecting the quality of the connection?) See also Signal Stress and LTE Signal Strength (RSRP). The value varies, depending on the network characteristics and the AirLink gateway					
	RSRQ	Signal quality			
	> -9 dB	Good			
	-9 dB to -12 dB	Fair			
	< -12 dB	Poor			
	Note: For additional in (described on page 47		k, use the *CELLINFO2? AT command		

LTE Signal Interference (SINR Level) LTE Signal Interference	Signal Interference Plus Noise (SINR) Level only applies to Sprint and Verizon Wireless LTE networks. The maximum value for each level is: • Level 0 = -9 dB • Level 1 = -6 dB • Level 2 = -4.5 dB • Level 3 = -3 dB • Level 4 = -2 dB • Level 5 = +1 dB • Level 6 = +3 dB • Level 7 = +6 dB • Level 8 = +9 dB Signal to noise and interference ratio Higher values indicate that signal power is much greater than noise and interference.				
(SINR)	SINR Throughput				
	> 10 Excellent				
	6–10 Good				
	0-5 Fair				
	< 0	Poor			
		I			

Statistics

(Malaine)		
war with	and a	
Dytes D. relation	2007	
Period of Ryber Stat	2-12-1	
галала Бинноскиа	APPM	
INCOME VER	A.1	
Pack Index Ind	•	

Figure 3-4: ACEmanager: Status > Cellular > Statistics

Statistics	
Bytes Sent	Number of bytes sent to the mobile network since system startup or reboot
Bytes Received	Number of bytes received from the mobile network since system startup or reboot
Persisted Bytes Sent	Number of bytes sent The count starts when the gateway first goes on air and persists over reboot. The field resets to zero on reset to factory default settings.For the RV55, this value is the cumulative traffic for all SIM cards, if more than one SIM card is present.
Persisted Bytes Received	Number of bytes received The count starts when the gateway first goes on air and persists over reboot. The field resets to zero on reset to factory default settings. For the RV55, this value is the cumulative traffic for all SIM cards, if more than one SIM card is present.

Packets Sent	Number of packets sent to the network since system startup or reboot	
Packets Received	Number of packets received from the network since system startup or reboot	

Monitor

E Monitor		
 Find to be at the over day. 	B-C	
Al Musile Type	Dire Me	
Al Playtest P & Hune	6006	
han Fidera Page (second)	>	
CHURLEN Hereire All Check	LADOR	
Al Control BAH Three in the Onionie (15. E	

Figure 3-5: ACEmanager: Status > Cellular > Monitor

Monitor	
Test Interval (seconds)	The configured amount of time between tests of the cellular connection
Monitor Type	The configured type of test being run on the interface to diagnose its ability to provide end-to- end connectivity
Ping Test IP Address	The configured IP address used for testing interface connectivity
Time Between Pings (seconds)	The configured time between individual pings
Cellular Network Watchdog	Status of the Cellular Network Watchdog (Enabled or Disabled) See Network Watchdog on page 77.
Current WAN Time in Use (minutes)	The length of time the cellular WAN has been in use

Advanced

- Advanced		
AL IVSI	302220023287679	
AT Serving Network PLMN	345250	
AL COLLD	28355330	
AT LADIEC	11002	
AL ESIC	٥	
DONR Sister	Desibled	
AL Coll Info	Collinfo: TOH: 2325 RSSI:	65 LAC: 11002 CollD: 28305330
AT Channel	205	
Network Operator Switching	Manually disabled	
L II. To L Operating Mode	Unknown	
Carrier Aggregation Indicator	Valid	
Corner Appreprine Information		
Frequency Band	Channel	Bandwidth
LIL DAND 5	2505	5 60 12

Figure 3-6: ACEmanager: Status > Cellular > Advanced

Advanced			
IMSI	International Mobile Subscriber Identity number		
Serving Network PLMN	The PLMN of the currently attached network		
Cell ID	Unique number that identifies each base transceiver station (BTS) or sector of a BTS within an LAC		
PN Offset	This field appears only for CDMA networks. Base station identifier used in CDMA networks.		
LAC/TAC	Location Area Code or Tracking Area Code (LTE)		
BSIC	Base Station Identity Code		
DMNR Status	 Dynamic Mobile Network Routing (DMNR) is only supported on the Verizon Wireless network. DMNR status: Enabled Disabled 		
DMNR Foreign Agent Registration Status	 This field only appears if DMNR is enabled. The status of transactions with the Home agent Pass — Connected subnets registered or de-registered successfully Fail—Unable to register or de-register connected subnets Unknown 		
DMNR Reverse Tunnelling Agent Status	This field only appears if DMNR is enabled. Status of the NEMO tunnel: • Up • Down		

Cell Info	Cell information such as the Base Station Identity Code (BSIC), TCH, Received Signal Strength Indicator (RSSI), Location Area Code (LAC), and the cell ID			
	For additional information, including cell info for LTE networks, see *CELLINFO2? on page 470 and LTE Networks on page 563.			
Channel	WAN network channel			
	The current active channel number for the mobile network connection			
Network Operator	Network Operator Switching status (See Radio Module Firmware on page 393.) Possible status:			
Switching	OK—The SIM in use matches the currently active radio module firmware.			
	 Manually disabled—SIM-based image switching is disabled on the Admin > Radio Module Firmware screen. 			
	 Disabled: <carrier> firmware is not in the local store—The required radio module firmware is not stored on the gateway. For instructions on how to install the radio module firmware, see Radio Module Firmware on page 393.</carrier> 			
	 Disabled: Unknown MCC/MNC—The gateway does not recognize the Mobile Country Code (MCC) or the Mobile Network Code (MNC) for the SIM card. 			
	 Disabled: SIM card not ready at boot—SIM card error. Ensure that the SIM card is installed properly, and has a valid account associated with it. If the problem persists, contact your Mobile Network Provider. 			
	 Disabled: SIM card not usable at boot—The gateway is unable to read the SIM card. Check the Network State field to ensure that the SIM card is not PIN-blocked. Ensure that the SIM card is installed properly, and has a valid account associated with it. If the problem persists, contact your Mobile Network Provider. 			
	 Disabled: DVT-Mode—The gateway is in an advanced diagnostic mode, normally only used at the factory. Contact your Sierra Wireless authorized distributor. 			
	• Disabled: internal error—Indicates a problem with the Network Operator Switching feature. Contact your Sierra Wireless authorized distributor.			
LTE IoT Operating Mode	This field appears only if the RV55 is connected to a Cat-M1 or NB-IoT LTE network. The value indicates the connected IoT network type. Possible values:			
	Cat-M1			
	NB-IoT			
Sierra SIM Applet Version	The Sierra SIM applet version is displayed if the active SIM is either an R2C eSIM or an external Sierra SIM.			
R2C eSIM SIM ID	ICCID of the R2C eSIM (if present)			
Carrier	This field appears only for LTE-Advanced networks			
Aggregation Indicator	Indicates whether or not carrier aggregation is enabled			
mulcator	Carrier Aggregation Indicator:			
	Valid—Secondary band/channel information is available			
	 Information not available—No secondary band/channel information is available 			
Carrier Aggregation Information	Carrier Aggregation Information appears only for LTE-Advanced networks when carrier aggregation is enabled. The Carrier Aggregation Information table displays the following information about multiple SCCs (secondary component carriers) for LTE carrier aggregation: • Frequency Band			
	Channel			
	Bandwidth			

Ethernet

2.5		Section 2			Contraction Collinson	nai Applications	VC Admin	
of spines	el line - 202010 1	CIECTION CONTRACTOR				Survey States	a failed for	
fume:								
Collision		13 Ethernet LAV						
		DHCP Mode			Ada			
Oternet			47 LISS Mode		UNINET			
NR-FE		state of a state of a	Estimated Clients		A			
ANIPA	IAC Table	VRBP Mode Press APP			Dated Number			
vini					1.000			
		Edwarmert Post State Post Number	MAC Address	Siste	Part Medie	Packets Sent	Packets Received	
Security		Pat 1	50.14.3E-48.9E/TE	Datamached	LAN			
lerinas	G		1.003 Schoot Arti					
Locather	10	13 Ethernat WV01						
		#F Ethamat State	** Ethernet State		Not Connected			
Serial		al Eshernet Illuste Det	atu'		Decemented			
Approxi	lane -	Ethwinat End-to-En	ed Commection		Not Verheit			
Publicy B	140	Ethenet IF Addres	Etherset IF Address			0.0.0.8		
	and a	11 Thursday						
ĸя		100 C	02241		495. 827			
PHIM		Cultures I th Precision						
Abend		Change in a score	Cateropy IP Pactoris Received		(ma)			
Allera		11 Mentor	1 United					
		AT Take belowed (second	ida).		18.7			
		of Munitur Sylve			Deater			
		AT Prog Test #* Addre	**		5.0.0.8			
		Sime Detween Pro-			28			
		AT CLOSET HAVE TIME	(n (bee (minutes)					
		11 VCAR						
		VLAN						
			bettertisco			VLAN III		
			VLAN 1					
			VLANZ					
			VCAR3		1 C			

Figure 3-7: ACEmanager: Status > Ethernet

Field	Description	
Ethernet LAN		
DHCP Mode	 Status of DHCP mode Server—The AirLink gateway is acting as a DHCP server for all Ethernet connections. Disable—The AirLink gateway is not acting as a DHCP server or client. All devices connected to the AirLink gateway must have a static LAN IP or use PPPoE. Auto—Default setting used by authorized AirLink resellers for initial gateway configuration. See DHCP Mode on page 145 for more information. 	
DHCP Auto Status	 Status of DHCP mode (This field only appears when the DHCP mode is Auto.) Server—ALEOS is acting as a DHCP server. Client—ALEOS is acting as a DHCP client. 	
USB Mode	Which USB port mode is set (USBnet, USB serial, or Disabled)	
Connected Clients	Number of connected devices that obtained their IP address through DHCP over Ethernet or USBnet. The value in this field does not include devices connected via PPP or PPPoE.	
VRRP Mode	VRRP status	
Proxy ARP	 Proxy ARP status: Enabled Disabled For more information, see Proxy ARP (Primary Gateway) on page 161. 	
Ethernet Port Status		
Port Number	Port number (The number of Ethernet ports available varies depending on the gateway.)	
MAC Address	MAC addresses of the Ethernet ports	
Status	 Status of the Ethernet port(s): Disabled—The Ethernet port has not been enabled (Default) Link Speed—Link speed depends on the gateway and the network Disconnected—No device is connected to the Ethernet port Disabled (Public IP)—The Connection mode is set to "Ethernet Uses Public IP". All the Ethernet ports except the Public Mode Ethernet port are automatically disabled. 	
Port Mode	Mode of each Ethernet port	
Packets Sent	Number of packets sent over the Ethernet port	
Packets Received	Number of packets received over the Ethernet port	
Ethernet WAN		
Ethernet State	Current state of the Ethernet connection: Connected Not Connected No Service 	
Ethernet State Details	State Details Provides additional details about the current Ethernet connection status. Possible messages are: • IP Acquired • Disconnected • Not configured for WAN	

Field	Description
Ethernet End-to-End Connection	Describes the state of the Ethernet network connection, based on Ethernet network monitoring (see Ethernet > Monitor on page 106). Possible states are:
	• Not Verified—The monitoring function is set to disable and therefore the availability of the Ethernet network cannot be verified.
	• Pending—The monitoring function is enabled, but has not yet completed its test. Once the first test is complete, this option only appears again if monitoring is disabled and then re-enabled.
	 Established—The monitoring system has determined that service is available on the cellular network.
	• Not Established—The monitoring system has determined that the cellular interface has no service (ping test failed).
Ethernet IP Address	Ethernet IP address
Statistics	
Gateway IP Packets Sent	Number of gateway packets sent to the network since system startup or reboot.
Gateway IP Packets Received	Number of gateway packets received from the network since system startup or reboot.
Monitor	
Test Interval (minutes)	The configured amount of time between testing the Ethernet WAN connection
Monitor Type	The configured type of test being run on the interface to diagnose its ability to provide end- to-end connectivity
Ping Test IP Address	The configured IP address used for tests of interface connectivity
Time Between Pings (seconds)	The configured time between individual pings
Current WAN Time in Use	The length of time the Ethernet WAN has been in use
VLAN	
Interface	Identities Interface name of the configured VLANs
VLAN ID	Identities ID of the configured VLANs

Wi-Fi

If you have an AirLink RV55 with Wi-Fi, click the Wi-Fi tab on the left side of the screen to view the Wi-Fi Status.

of spheric lines (Marileo 12)	110.116	Papers 44 August Robust Conc
		The second second second second second
hone	1 (2 WAP) Dates	
Cethater		
	VALUE & Mode	Access Paint
Benet	WLF1 B Masia	Cleff
beeff Wed it	LI WEPLA Access Part	
AN IPMAC Table	690	369604001561030Y
175	Security Encryption Type	Oper
	Connectant Clients	*
Secontly	Cardiganal Access Poart Mode	brgit
Services	Land AP Pressency (DHU)	2.412
	Channel in Use	1
lacative	Access Print MAC Address	3c #1 #1 d# 34/34
Dual Secial	ViciPi Dolge to EPwriet	Doutinet
Applitations	(1) We Poll Class	
Salley Reading	AT SHA Date	Inst Connected
1941	41 mi-Fi State Denaits	Associating.
PATH	W-FI Estita-Est Convertise	tus verlea
	100	
Altonial	Security Excryption Type	
	P Adaves	0.018
	16-Fi Cleri MAC Address	Separt and San San Ta
	Statemente Aucoreas Proint Monte	Not Connected
	CurrentLast Unet Charter	
	13 WePLA Statistics	
	Access Plant Pachata Transmittett	<i>T</i> :
	Access Point Pachate Received	8
	() We Pi B. Statistica	
	Client Packets Transmitted	6
	Client Packets Received	*
	11 Maritar	
	AT Text tobactual (non-amile)	36
	# Wester Type	Deaths
	AT Fing Test IF Address	0.048
	Time Belgeon Page (extended	2
	AT Current WASh Time in Use (menutes)	

Figure 3-8: ACEmanager: Status > Wi-Fi (example, with Wi-Fi A Access Point and Wi-Fi B Client)

Field	Description	
Wi-Fi Status		
Wi-Fi A, Wi-Fi B Mode	Wi-Fi A and B modes. For more information, see Wi-Fi Configuration on page 124.	
Access Point (LAN) These fields only appear wh	en the Wi-Fi A and/or B mode is set to Access Point (LAN).	
SSID	Configured SSID	
Security Encryption Type	Wi-Fi security encryption (security authentication) type (i.e. WEP, WPA, WPA2 Personal, WPA2 Enterprise)	
Connected Clients	Number of connected clients	
Configured Access Point Mode	Current Wi-FI access point mode. For example if the access point mode on the gateway is configured for n/ac Enabled (for 5 GHz band) and the client only supports b/g (2.4 GHz band), the access point mode in use is b/g (2.4 GHz band).	
Local AP Frequency (GHz)	Frequency being used by the Access Point	
Channel in Use	Channel being used by the Access Point	
Access Point MAC Address	MAC address that hosts connect to when the gateway is configured as an access point. For more information, see Access Point (LAN) Mode on page 128.	
Wi-Fi Bridge to Ethernet	 Status of the Bridge Wi-Fi to Ethernet field. Enabled—The Ethernet interface and the Wi-Fi interface share the same subnet. This allows routing between all LAN devices. Disabled—Wi-Fi LAN devices are isolated from all other LAN devices. (default) See Bridge Wi-Fi to Ethernet on page 132. 	
Client (WAN) These fields only appear wh	en the Wi-Fi A or B mode is set to Client (WAN).	
Wi-Fi State	Current state of the Wi-Fi connection: Connected Not Connected No Service 	
Wi-Fi State Details	 Provides additional details about the current Wi-Fi connection. Possible messages are: IP Acquired Disconnected Associating Associated Connecting 	

Field	Description	
Wi-Fi End-to-End Connection	 Describes the state of the Wi-Fi network connection, based on Wi-Fi network monitoring (see Monitor on page 127). Possible states are: Not Verified—The monitoring function is disabled, and therefore the availability of the Wi-Fi network cannot be verified. Pending—The monitoring function is enabled, but has not yet completed its test. Once the first test is complete, this option only appears again if monitoring is disabled and then re-enabled. Established—The monitoring system has determined that service is available on the Wi-Fi network. Not Established—The monitoring system has determined that the Wi-Fi interface has no service (ping test failed). 	
SSID	SSID that the AirLink gateway is connected to or associated with	
Security Encryption Type	Wi-Fi security encryption (security authentication) type (i.e. WEP, WPA, WPA2 Personal, WPA2 Enterprise)	
IP Address	WAN IP address the gateway received from the access point	
RSSI	Signal strength (in dBm) of the remote AP that the Wi-Fi client is connected to.	
Wi-Fi Client MAC Address	MAC address the gateway uses to connect to a Wi-Fi access point when it is configured for Client mode. For more information, see Client (WAN) Mode on page 137.	
Remote Access Point Mode	The current access mode for the client/remote AP (b/g/n or n/ac)	
Current/Last Used Channel	This field only appears when the Wi-Fi mode selected is Client (WAN). The current channel or the last channel used.	
Wi-Fi A and Wi-Fi B Sta	tistics	
Access Point Packets Transmitted	This field appears in Access Point (LAN) mode. The number of packets transmitted since the last startup/reboot.	
Access Point Packets Received	This field appears in Access Point (LAN) mode. The number of packets received since the last startup/reboot.	
Client Packets Transmitted	This field appears in Client (WAN) mode. Wi-Fi WAN packets transmitted	
Client Packets Received	This field appears in Client (WAN) mode. Wi-Fi WAN packets received	
Monitor	·	
Test Interval (seconds)	The configured amount of time between tests of the Wi-Fi connection	
Monitor Type	The configured type of test being run on the interface to diagnose its ability to provide end- to-end connectivity	
Ping Test IP Address	The configured IP address used for testing interface connectivity	
Time Between Pings (seconds)	The configured time between individual pings	

Field	Description
Current WAN Time in Use (minutes)	The time, in minutes, that the gateway has been connected to the current WAN network.
	Note: The value of this field is 0 if the gateway is not connected to a WAN mobile network.
Remote AP MAC Address	This field only appears when the Wi-Fi Status is Associated, Connecting, or Connected. The MAC address of the remote access point
Remote AP Frequency (GHz)	This field only appears when the Wi-Fi Status is Associated, Connecting, or Connected. The frequency being used by the remote access point
Packets Transmitted	Number of IP packets sent to the access point host interface over Wi-Fi LAN since the system startup
Packets Received	Number of IP packets received by the access point host interface over Wi-Fi LAN since the system startup

LAN IP/MAC Table

The LAN IP/MAC table shows the status of the local network.

of sector time, spectrum to a	1.0.48		THE REAL TRACT
States.	IPMAC .		
Catalar	if Address	MAC Address	State-
[2herter]	142.108.54.108	527557523648	arthur .
05.0			
LAN WHEN THE			
ura .			
Security			
Services			
Lanathere			
a citad in			
Service			
Applications			
Applications Falses Realiting			
Applications Policy Realing			
Sector Applications Policy Routing REM PREM			

Figure 3-9: ACEmanager: Status > LAN

Field	Description	
IP/MAC		
IP Address	Local IP Address of devices on the LAN	
MAC Address	MAC Address of devices on the LAN	
Status	 The status of the connection: active—the connection is up and active inactive—no recent activity on the connection authorized—a client whose MAC address is included in the list of authorized MAC addresses is connected via a captive portal. See Captive Portal on page 132. unauthorized—an unauthorized client attempting to connect to the Wi-Fi network via a captive portal has been given an IP address, but is not connected 	

VPN

The VPN section gives an overview of the VPN settings and indicates whether a VPN connection has been made.

Nature WeterCalturar Due		e Events Reporting Dual Serial Applications 40 Admin
al-sphericise: 39(20) 1212)	14.	Anny Breen Coron
Hanne	Incoming Out of Same	Bachel
Delbahar	Ourgoing Management Out at Tank	Alternet
	Outgoing Hast Out of Band	Dischart
Diternet	Page FPS made	Dualited
Dua/WitH	VPN T Bratun	Hist Example
	VPN3 Balon	Not Exatled
LAW INVESTIGATION	VPN 3 States	That Englished
VPM	VPN 4 Status	Vist Enabled
a1.7021	WHV 5 Statue	That Examined
Becurity	Fallow -Ponary VPN	There
Dervices .	Pateur - Penary VPILStatus	Disabled
Location	Failever - Sacondary VIVI	New
1,10,000	Parlment - Secondary VIII Status	Doubled
Dual Serial	Parlaner - Overall VPN Status	Doubled
Applications	Failure - Hamber of Pismary VPN Failures	9
	Pairow - Barter of Secondary VPN Falaree	0
Pulky Routing	Pailove - Norther of Selfches to Pitmary VPN.	8
NSR	Pallow - Number of Exterior to Secondary VPN	
PRIM		
Almat		

Figure 3-10: ACEmanager: Status > VPN

Field	Description
Incoming Out of Band	Whether Incoming Out of Band traffic is allowed or blocked
Outgoing Management Out of Band	Whether outgoing ALEOS Out of Band traffic is allowed or blocked
Outgoing Host Out of Band	Whether Outgoing Host Out of Band traffic is allowed or blocked
IPsec FIPS mode	Whether IPsec FIPS mode is enabled (available when Standard VPN Implementation is enabled)

Field	Description	
VPN 1 to 5 Status	 Status of each VPN connection: Disabled—VPN is disabled (default) Not Connected—The VPN failed to connect. This could be because of a mismatch in the configuration between the client and the server, no data connection on the gateway, etc. Connected—The VPN is connected and ready to transmit traffic. Configuration Error—This status appears when: Two VPNs have both the same Local Address and the same Remote Address More than one VPN has the remote address set to "0.0.0.0" Note: This restriction does not apply to the Additional Remote Subnets. When either of these errors exist, only the first of the conflicting VPNs is operational. To determine which VPNs are in conflict: Go to Admin > Configure Log. For the VPN Subsystem, ensure that Display in Log is set to Yes. The Verbosity can be either Info or Debug. Click View Log. 	
Failover - Primary VPN	 4. The resulting log shows you which VPNs are in conflict. ID of the primary VPN (for VPN Failover) i.e. VPN 1, VPN 2, VPN 3, VPN 4, VPN 5, or None (Default is None.) Setting persists over reboot. 	
Failover - Primary VPN Status	 Status of the primary VPN: Disabled—VPN Failover is disabled. (default) Connecting—The VPN is trying to connect to the responder. Active—The VPN tunnel is ready and transferring traffic. Backup—This is currently the backup VPN connection. Failed—Dead Peer Detection (DPD) has determined that the VPN responder is dead, or a ping sent to the VPN host failed. Out of Service—There have been 5 DPD failures within an hour. 	
Failover - Secondary VPN	ID of the Secondary VPN (for VPN Failover) i.e. VPN 1, VPN 2, VPN 3, VPN 4, VPN 5, or None (Default is None.) Setting persists over reboot.	
Failover - Secondary VPN Status	 Status of the Secondary VPN: Disabled—VPN Failover is disabled. (default) Connecting—The VPN is trying to connect to the responder. Active—The VPN tunnel is ready and transferring traffic. Backup—This is currently the backup VPN connection. Failed—Dead Peer Detection (DPD) has determined that the VPN responder is dead, or a ping sent to the VPN host failed. Out of Service—There have been 5 DPD failures within an hour. 	

Field	Description	
Failover - Overall VPN Status	Status of the overall VPN:	
Status	Disabled—VPN Failover is disabled. (default)	
	 Connecting—One of the VPNs is trying to connect to the responder. 	
	 Active—One VPN tunnel is currently in use. The backup VPN is available. 	
	Backup_Unavailable—One VPN tunnel is currently in use. The backup VPN is not available.	
	• Out of Service—Neither the primary nor secondary VPN is operational.	
	N/A—The overall VPN status is temporarily not available. Click Refresh.	
Failover - Number of Primary VPN Failures	Number of times DPD has failed on the primary VPN since the gateway has been rebooted or the "Set VPN Policy" button was clicked	
Failover - Number of Secondary VPN Failures	Number of times DPD has failed on the Secondary VPN since the gateway has beer rebooted or the "Set VPN Policy" button was clicked	
Failover - Number of Switches to Primary VPN	Number of times traffic was switched to the primary VPN since the gateway has been rebooted or the "Set VPN Policy" button was clicked	
Failover - Number of Switches to Secondary VPN	Number of times traffic was switched to the Secondary VPN since the gateway has been rebooted or the "Set VPN Policy" button was clicked	

Security

The Security section provides an overview of the security settings on the AirLink gateway.

Statue INVECTIVATION 1	NCTI LAN VIN Security Section	Linutter Svens Reporting Solial Applications 20	Advis
AN ADDRESS TO A DRESS OF A	1.1.5 (c) 444	Auto Materia	1000
Name	Digvast	Daame	
Caberry	Pellowethy	Deatest	
	Part Filtering Interact	Disative	
Ellipsingi	PartFilturing Calibound	Deatted	
104.00	Fullmand Freework Minite	Casine	
	Transfer transfer Primodel	Déame	
LAW (PRIME Taken	MACHINE	Diame	
1990	# Napart Smerk		
Including.			
Services			
Location			
lete .			
Applications			
Policy Realing			
8.54			
PHDM			
Advant .			

Figure 3-11: ACEmanager: Status > Security

Field	Description
DMZ Host	Setting for the DMZ Host (Automatic, Manual, or Disabled) DMZ defines a single LAN connected device where all unsolicited data should be routed.
Port Forwarding	Status of port forwarding (Enabled or Disabled)
Port Filtering Inbound	Status of inbound port filtering (Allowed Ports, Blocked Ports, or Disabled)
Port Filtering Outbound	Status of outbound port filtering (Allowed Ports, Blocked Ports, or Disabled)
Outbound Firewall Mode	Status of the outbound firewall (Enabled or Disabled)
Trusted Hosts (Friends)	Status of the Trusted Hosts (Friends) list (Disabled or Enabled) When this option is enabled, the AirLink gateway only accepts connections from trusted remote IP addresses.
MAC Filtering	Status of MAC filtering (Enabled or Disabled)
IP Reject Count	Number of IP addresses that have been rejected

Services

Mus RUNCelurar S	Sual'shift Life WHI Becurity Berviews	Location Events Reporting Dust Series Applications 10 Allege
a spanning and the	111 PM	Stany (P. Sale) (See
holes		
Cottalact	H 40.90	
	ALMS Grane	Disaster
Berbel	ALMS LWMDM Swive 1PL	
Daar William	AQMS Protocol in Linu	LWARM
AN INVESTIGATION	AWU Management Terral	Disaster
-	11-ACE names	
	Remote Access	Disatter
Generality	Lanal Accesa	Date HTTP and HTTPS
territor.	WAPS APP Age and	Same as ison
an affects	1) Prove Management	
head flowball	Ergen Hans	E.
Apply advant	11 Dynamic DNII	
Valuy Roading	Dynamic DMS Service	Disabled
154	11 Fire (899)	
PRITIN .	Use BNPP is update time	Deamer
Advent#	() Alternative	
	The second second	
	LDAP address atom	Dagitiet
	RADUIT authentication	Disation
	TADACS+ automotication	Distance

This section shows the status of AirLink services, including ALMS and remote access.

Figure 3-12: ACEmanager: Status > Services

Field	Description	
ALMS		
The status items under ALM	S vary according to th	ne services you have enabled.
(TVENS		
A MODELS		Honishap Ladure (4) - 1008/2020 1908 48
ALM3 LWM2M Server URL		
ALMS Protocol In Use		IWM20
AVM Management Tunnel		Enabled
AVM Management Turnet Port		1190
AVM Management Tunnel Status		Down
ALMS Status	Status of the connect	ction to the AirLink Management Service
	For details, see Stat	us on page 220.

Field	Description
ALMS LWM2M Server URL	Shows the LWM2M server URL that is currently in use
ALMS Protocol in Use	Shows the current ALMS Protocol in use (LWM2M or MSCI)
AMM Management Tunnel	Shows the status of the AMM Management Tunnel (Enabled, Disabled).
AMM Management Tunnel Port	Appears when AMM Management Tunnel is enabled. Shows the port used for the OpenVPN connection to AMM (1190 is the default port).
AMM Management Tunnel Status	Appears when AMM Management Tunnel is enabled. Shows whether or not the AMM Management Tunnel is established (Down, Established).
ACEmanager	
Remote Access	 ACEmanager remote access (over the WAN link): Disabled (default) HTTPS Only Both HTTP and HTTPS
Local Access	ACEmanager local access (Ethernet, USBnet): HTTPS Only Both HTTP and HTTPS (default)
Wi-Fi AP Access	 This field only applies to the Wi-Fi model of the RV55. ACEmanager Wi-Fi access: Same as Local (default) Disabled
Power Management	
Engine Hours	 Time the engine has been running. Depending on your configuration, this is based on: Voltage on the Power Pin from the vehicle battery (Engine Hours On Voltage Level) Voltage on the Ignition Sense Pin (Engine Hours Ignition Enable)
Dynamic DNS	
Dynamic DNS Service	Service in use for Dynamic DNS translation
Full Domain Name	If the Dynamic DNS Service is configured to use a 3rd party host, the domain name configured is displayed. If the Dynamic DNS Service is configured to use IP Manager, this field does not display.
Time (SNTP)	
Use SNTP to update time	Daily SNTP updates of the system time
Authentication	
LDAP Authentication	Status of the LDAP client: Enabled Disabled (default)

Field	Description
RADIUS Authentication	Status of the RADIUS client: Enabled Disabled (default)
TACACS+ Authentication	Status of the TACACS+ client: • Enabled • Disabled (default)

Location

The Location tab provides AirLink gateway location and movement information for use with tracking applications.

Nature Mathematican Da	ar 199-PT [1.4	1 179	Seconte	Services	Lengthere	Svens Reporting	Duar Bernel	Applications	10	Admin
in playing sector 0.0	11.798							8		internal states of
Hartse		ur dence				Ended				
Cettalar	Local	iefs.				Location Fo	Acquest			
	Gives:	Reboot Watch	ing .			Ended				
Ethioreni	Sand	No Court				4				
Duat W5 Ft	SPS	Saturities in Fix.				IL 19, 16 29				
LAN PUBLIC Table	0(0)	ASS Satellies	n Fia							
LAR BUBLIC THERE	Gatte	e Satofiten befr	() ()							
ALC: NO PAGE	5xDr	u Selektes In P								
Decarity .	(4755	Satellites in Fis	Q			1				
	Labo					4917300 Ma	£3			
Services	Lingt	ule				-12306808				
Location	Plant	15				.0				
	Spee	((uniti)				0				
Dogt Sector	Exter	anad Position Ur	carbinety (mater	4		43				
Applications										
Puttor Rooting										
H SH										
PRITER										
Rhout										

Figure 3-13: ACEmanager: Status > Location

Field	Description
Location Service	Status of the Location Service Enabled Disabled
The remainder of the fields of	nly appear if Location Service is enabled.

Field	Description
Location Fix	Status of the Location fix No Location Fix Location Fix Acquired Differential Location Fix Acquired
GNSS Reboot Watchdog	Status of the GNSS Reboot Watchdog (see page 284) Enabled Disabled
Satellite Count	Number of satellites the Location receiver detects
GPS Satellites In Fix	Shows the IDs for the GPS satellites used to acquire the fix
GLONASS Satellites In Fix	Shows the IDs for the GLONASS satellites used to acquire the fix
Galileo Satellites In Fix	Shows the IDs for the Galileo satellites used to acquire the fix
BeiDou Satellites In Fix	Shows the IDs for the BeiDou satellites used to acquire the fix
QZSS Satellites In Fix	Shows the IDs for the QZSS satellites used to acquire the fix
Latitude	Latitude of the Location receiver Click the Map link to view the current location of the gateway, using Google Maps™.
Longitude	Longitude of the Location receiver
Heading	Direction in which the AirLink gateway is moving. No configuration is needed for Heading or Speed; these are calculated automatically.
Speed (km/h)	Speed (in kilometers per hour) derived from location service
GNSS Firmware Version	Current version of firmware on the gateway's GNSS (Global Navigation Satellite System) module
Estimated Position Uncertainty (meters)	Estimated error margins in location fixes. The status remains at 99.0 (maximum) until a location fix is acquired.

Statue valoritienster dual W-PC sAle Security Services Location Events Reporting Dual Sense Applications (20 299 Admin Last optimizations - Million 1 10 at 198 these. ((10332304)) Cellular BS232 Pvé Dubid Etheniati #5232 Oue Flat Mode Duebed **HS232 Reserved by External Application** Deadned Doubl WD #1 #7 REEL Put Male Normal (AT command) LAN RYNKC Takle AT 88237 TCP Auto Annient Drustited VPN. **HS212** TCP Persistent Connection Deable AT 115232 LIDP Acto Annest Drusbled Security RSU22 bytes seet. 6. Services R3232 Syles received ż HS252 Hot signal level DCD - DTR - DDR - C15 - H15 Location . Doot Sector Applications Publicy Roading 818 SWIM. About

Figure 3-14: ACEmanager: Status > Serial

Field	Description			
RS232 Status				
RS232 Port	 Status of the serial port: Enabled—The serial port is functional (default). Disabled— The serial port has been manually disabled. To enable the serial port, go to Port Configuration on page 289. 			
RS232 Reserved by External Application	 Reservation status of the serial port: Enabled—The serial port is reserved for ALEOS Application Framework (ALEOS AF), and cannot be used for any other serial-related ALEOS features. Disabled — The serial port is available for non-ALEOS AF, serial-related ALEOS features. To reserve the serial port for ALEOS AF, go to Applications > ALEOS Application Framework on page 358.) 			
RS232 Port Mode	Default power-up mode for the serial port. When the AirLink gateway is power-cycled, the serial port enters the mode specified by this command after 5 seconds.			
Login reverse telnet	This field only appears when reverse telnet is selected as the Serial Port Mode. Status of login for reverse telnet. For more information, see Reverse Telnet/SSH on page 293.			

Serial

Field	Description
RS232 TCP Auto Answer	 This parameter determines how the AirLink gateway responds to an incoming TCP connection request. The AirLink gateway remains in AT Command mode until a connection request is received. DTR must be asserted (S211=1 or &D0) and the gateway must be set for a successful TCP connection. The AirLink gateway sends a "RING" string to the host. A "CONNECT" sent to the host indicates acknowledgment of the connection request and the TCP session is established. Disabled (default) Enabled
RS232 TCP Persistent Connection	Status of the TCP Persistent Connection feature. See TCP Persistent Connection on page 330.
RS232 UDP Auto Answer	How UDP auto answer mode is configuredDisabled (default)Enabled
RS232 bytes sent	Number of bytes sent over serial port to host
RS232 bytes received	Number of bytes received over serial port from host
RS232 Host signal level	 Status of the following parameters related to the host signal level: DCD—Data Carrier Detect—Control signal to the PC DTR—Data Terminal Ready—Used to establish a connection DSR—Data Set Ready—Used to establish a connection CTS—Clear to Send—Data flow control RTS—Request to Send—Data flow control Each parameter can have a value of LOW (signal not asserted) or HIGH (signal being asserted). The first three parameters (DCD, DTR, and DSR) may be helpful for troubleshooting. If the values shown for these parameters are not as expected: Press Refresh to ensure you have the latest values. Check the cable connections.

Applications

The Applications section of the Status group provides information on the status of the Garmin gateway and data service.

Refue VideoCentular	Dual HN-P1 LAN 1PW Desuring Dervices Lenation	Sveris Reporting Dual bene Applications 20 Johnn			
o quiverse della tr	Li bi Aw	rate datas farm			
Home	Al Garren Status	Not Drated			
Celhitur	Data Serata	Available (under unage limit)			
Training	Available RAM (KII)-	1000ba			
L Parrows	Available Flash (KD)	1			
Doat WEEE	CPU Last (last 16 minutes)	R 14040E			
LAX IPANC Table	ALECCE Application Francescok	Deathet			
	Tienal Part Reported	Deather			
virsi	GCOM DW Part Researce Reserve	Duative			
Security					
Service					
Location					
Dual Serial					
Pulicy Basimp					
RSR					
PATH					
Advent					

Figure 3-15: ACEmanager: Status > Applications

Field	Description
Data Service	Data Service field displays "Available (under usage limit)" if the configured usage limit has not been exceeded.
Available RAM (KB)	Available RAM in kilobytes (1000 bytes), updated every 30 seconds
Available Flash (KB)	Available Flash on the user partition in kilobytes (1024 bytes), updated every 30 seconds
CPU Load (Last 15 minutes)	CPU load, averaged over the last 15 minutes and updated every 30 seconds The CPU load relates to how many applications are attempting to execute in parallel over the 15-minute period. If the load is greater than 1, some applications are waiting for CPU capacity to become available and may be delayed in launching.
ALEOS Application Framework	Whether ALEOS Application Framework is enabled or disabled
Serial Port Reserved	Reservation of the serial port: Disabled (default) Enabled

Field	Description
Serial Port 2 Reserved	Reservation of serial port 2: Disabled (default) Enabled
QCOM DM Port Resource Reserve	Reservation of the QCOM DM port: Disabled (default) Enabled

Policy Routing

The Policy Routing section of the Status group provides information on the routing policy configuration.

1011-paident (max 321-022) [71	(100-17 AM)		And Designed	1.000
Harter.	Policy Reader 1 Status	Duality		
Culture	Parko Rose 2 Status	During		
Colorar.	Partics Reads 3 Statue	Divided		
Elliperturk	Polici Rode 4 Status	Dastwo		
99149	Policy Reade 5 Status	Deathe		
LAN STREET, Table				
(see				
Security				
Section				
Location				
Server				
Applications				
Pulicy Houting				
ACO/A				
PATH				

Figure 3-16: ACEmanager: Status > Policy Routing

Field	Description
Policy Route # Status	Displays the Policy Route Status for each of the five configurable policies

RSR (Reliable Static Routing)

The RSR section of the Status group provides basic information about the RSR configuration. For more information, see Reliable Static Routing (RSR) on page 108.

similarity, preprint of the	Colora		and the second s
			Tangar (Salara) Course
tene .	Remaine Statu Houde (R2R)	trained	
Letter	Tracking Down	Enabered	
1.7345	HIR Active Room	turne	
Uthermank	RSR Test Result	Linteren .	
15-15	R8R feet Torwitteng		
Unit Writtlac: Tailine			
17%			
haiser Hp			
Serves			
(acation			
Semal			
Aggilications			
Painty Rooting			
100			
Patta			
these .			

Figure 3-17: ACEmanager: Status > RSR

Field	Description
Reliable Static Route	Status of the Reliable Static Routing feature: Enabled Disabled
Tracking Object	Status of the Tracking Object: Enabled Disabled
RSR Active Route	 Active route for Reliable Static Routing Primary—Specified network traffic is currently using the configured primary route. Backup—Specified network traffic is currently using the configured backup route. None—RSR is not enabled.
RSR Test Result	Result of the most recent Object Tracking test
RSR Test Timestamp	Time of the most recent Object Tracking test

PNTM (Private Network Traffic Management)

The PNTM section of the Status group provides basic information about the PNTM configuration.

Note: PNTM is available only on Verizon Wireless' private network. PNTM status appears only when the RV55 has a Verizon SIM installed.

And the state of the	2.00				100	transfer Elizabeth
lana -	(Partie					
otholas	Page #	Status	Devilentum	0.001	To Packets	To Byten
	1.	Domes	0000	Deduce UF	+ · · ·	
Hurter	2.	Thomas	0.008	Dedrafed-17	#.:	1
0.0	3	Disation	0.03.8	Dadupted-6F	+	
		Doutled	0.023	Deduning-EF		
AM INMAC Takin		Transient	0.048	Debuild-RF	+	
19	4	Damed	0000	Dedicated-EF	- 10 - E	
	P.	Dounled.	8888	Dedrafed-EF	17	1
acardy.	8	Disatile f.	0.008	Dadicated - EF		
APTROX		Duated	0.02.8	Dedtaled-Eft	* .	
	10	District	6558	Debutes HF	1. E	
produce.		Damid	0088	Deduced-EF	1. E.	4
initial	12	Dealer	0008	Delinated - 8P		
	49	Dames	6888	Enduated -EF	+.	
vpHcattern.	14	Dealing	0.02.8	Demoke-th	÷.	
SKQ Round	10 NC	Damet	6.8.8.8	Dedicate all	¥.	*
54.						
NATE:						

Figure 3-18: ACEmanager: Status > PNTM

Field	Description
Rule #	PNTM rule number
Status	Status of the PNTM rule (Enabled or Disabled)
Destination	The destination IP address
DSCP	The priority level
Tx Packets	Number of packets transmitted
Tx Bytes	Number of bytes transmitted

About

The About section of the Status group provides basic information about the AirLink gateway.

at aphibed lines (1922)118-11 10	1.16.000	Aug Distant Cases		
Photos	Decce Noted	RVI		
	Radi: Wetkin Type	EMTER		
Collabor Haddo Maddar Igge Radio Maddar Igge		GENERC		
Ethernet	Radio Firmuna Version	SWIMAGC_01 19 04 04 40 minist primes 2010/06/21 21 40 11		
Daal WLFL	Radio Handware Version	18		
	SHU PHI D	9999373, 002 591		
LAN IPBARC Lable	Cener PRID	WARTER GENERAL_MAD AND		
VPM	# Reial Norther	29/902408/150/92387		
Security	#F Lecator/RAP Device ID	Device ID Databled		
1. Mar.	W Ethernet Mat. Auktoria	10-14-18-14-1070		
Services	ALCOS Suffware Version	+0.0		
Locetter	ALEOS Build sumber	80		
Dual Serial	Dence Herbrand Configuration:	2125130000000000000000000000000000000000		
	Hast Versian	431		
Applications	All Baccory Version	23-0000000000		
Palley Routing	MCU Firmure Version	10.00		
	MSO Wence	43		
IISR	Terplate fame			
Philippi	Mastale COMA check			

Figure 3-19: ACEmanager: Status > About

Field	Description
Device Model	Model of the gateway (e.g.,RV55)
Radio Module Type	Model number of the internal radio module (e.g. WP7601, MC7354)
Radio Module Identifier	Identifier for the internal mobile radio module
Radio Firmware Version	Firmware version in the radio module
Radio Hardware Version	Hardware version of the radio module (does not appear for all carriers)
SKU PRI ID	Product Release Instructions ID number
Carrier PRI ID	Product Release Instructions ID number
Serial Number	Serial number used by ALEOS to identify itself for various management applications
Location/RAP Device ID	Device ID used by Location/RAP and other reporting
Ethernet Mac Address	MAC address of the main Ethernet port
ALEOS Software Version	Version of ALEOS software running on the AirLink gateway

Field	Description
ALEOS Build number	Build number for the ALEOS Software
Device Hardware Configuration	AirLink gateway's hardware configuration
Boot Version	Version of boot code installed on the gateway
Recovery Version	Recovery ALEOS version installed
MCU Firmware Version	Version of micro controller unit (MCU) firmware installed on the gateway
MSCI Version	MSCI version of the ALEOS internal configuration database
Template Name	If you have installed a custom-named template, the name appears here. Otherwise, the field is blank.

>> 4: WAN/Cellular Configuration

The WAN/Cellular tab in ACEmanager allows you to view and modify mobile network connection settings. The settings available depend on the gateway model and the radio module. This chapter is divided into sections based on the left side menu items.

The first time you power up the gateway on its home network, it automatically begins the activation/provisioning process and attempts to connect to the network. This process typically takes 5 to 10 minutes. If the gateway does not automatically connect to the network, see Network Credentials on page 90.

Note: The fields displayed vary depending on the ACEmanager settings.


Monitoring WAN Connections

ALEOS enables you to:

- Monitor each WAN interface—cellular, Ethernet WAN, and Wi-Fi—independently, regardless of which one is active
- Set the priority for each WAN interface

Monitoring confirms whether or not the interface provides connectivity from the gateway to a ping destination on the WAN. Interface priority enables you to choose which interface has priority and which interface to switch to if the highest-priority interface is not available.

Interface priority checks the link layer connection (for example, in an Ethernet WAN setup, the connection to the router). It does not verify whether or not the router has a WAN connection. With monitoring, you can configure the gateway to ping a destination on the WAN. If the gateway does not receive a response to the ping, it attempts to connect to the next highest priority interface. See Figure 4-1 and Table 4-1.



Configured	Interface Priority Configuration Details	What Happens
Interface Priority only	Highest Priority = Ethernet Second Priority = Cellular	 If the gateway is able to communicate with the router and receive an IP address, it assumes it has WAN connectivity. The router's connection to the WAN is not verified. If the gateway is unable to establish communication with the router (i.e. no IP address, cable unplugged) it attempts to connect to the cellular network.
Interface Priority plus Monitoring	Highest Priority = Ethernet Second Priority = Cellular	 If the gateway receives a response to a ping sent over the Ethernet WAN network, it uses the Ethernet WAN interface. If the gateway does not receive a response to a ping sent over the Ethernet WAN, it attempts to connect to the cellular network.

Table 4-1: Example: Interface Priority with and without Monitoring Enabled

Related Features

The network watchdog is also part of the monitoring process. If none of the WAN interfaces are available, the network watchdog, if configured, reboots the gateway after the configured period with no WAN connection. If you have Accelerated Interface Scan enabled, ALEOS attempts to regain connectivity on one of the available interfaces until the reboot occurs.

As a final strategy, if the network watchdog fails to re-establish connectivity, there is a backoff mechanism whereby the gateway waits for 1 hour before starting the network watchdog mechanism again to prevent frequent rebooting.

To configure these options, see the following sections:

- Interface Priority—See Interface Priority on page 76.
- Monitoring Cellular network—See Cellular > Monitor on page 103.
- Monitoring Ethernet WAN network—Ethernet > Monitor on page 106.
- Monitoring Wi-Fi network—Monitor on page 127.
- Configuring the Network Watchdog—Network Watchdog on page 77.

General

Interface Priority

This screen allows you to set the WAN interface priority. If multiple available interfaces have the same priority, the order of priority is: Ethernet, Wi-Fi, and cellular.

Instan WUICeBular III.		rives Assarbed Events Reporting Adulat	Applications 10 Admin.		
	0.0	- Ener	the second lateral lateral		
	THWW INStan Plane Endpantie				
Interland Property.	- (www.sectoral-conductoral				
Sample Thomas	Select Hefers Hore				
	Wilk Industries Priority				
Warg Burgerson	Merteur	Cumulation Elation	Privite		
aller	Calular	Unanalatie - Hat-Convedent	745		
Deneral	Ibetel	Unavailable that Sciencedert	Pres		
	VAU Interface Privets (Additional)				
and that I combigeration	interface .	Connection Nation	Pranty		
Miller J Configuration	841	Unavailable - Hat Convedent	Animi u		
Martin	Contractor materials				
Inecture	AF metwork imatheog Terrer	10 Minutes and			
Side Configuration	Accelerated Intelligen Tops	Date o			
Manue 1					
Inframe States Reads (1934)					
Manage Reserves					
MAN Configuration					
HETH Configuration					

Figure 4-2: ACEmanager: WAN/Cellular > General > Interface Priority

Field	Description		
WAN Interface Priority Configuration			
Network Interface Read-only field that shows the current network interface or None if the gateway does not hav a network connection.			

Field	Description
WAN Interface Prior	rity
Priority	 Rank the available WAN interfaces by selecting the order of priority. The highest priority interface will become the default route for IP traffic. The default order of priority is: Ethernet—First Wi-Fi—Second (if Wi-Fi is supported on the gateway) Cellular—Third If the highest-priority interface is not available, the gateway attempts to connect to the second-highest priority interface. Interface priority is evaluated as follows: Ethernet—Does the gateway have an IP address from the router? Wi-Fi—Can the gateway access the Wi-Fi access point? Cellular—Can the gateway access the Mobile Network Operator's network? Tip: To ensure end-to-end connectivity (gateway to destination), enable monitoring for the relevant interfaces. See Cellular > Monitor on page 103, Ethernet > Monitor on page 106, and Monitor on page 127. Note: Changes to the interface priority take effect without a reboot.
Network Watchdog	
Network Watchdog Timer	 Network Watchdog Timer If there is no WAN connection for the time configured in this field, the gateway reboots. Options are: Disable—When this field and the Accelerated Interface Scan field are set to Disable, the gateway never reboots as a result of lack of network connectivity. 5 Minutes 10 Minutes 15 Minutes (Default) 30 Minutes 45 Minutes 1 Hour
Accelerated Interface Scan	If this option is enabled, the gateway sends out a ping every 30 seconds while the gateway is waiting to reboot (according to the Network Watchdog Timer configuration). This option is only available if the network watchdog is enabled.

Bandwidth Throttle

This feature helps you manage your data account by allowing you to configure the AirLink gateway to restrict the real-time available bandwidth. You can:

- Place limits on traffic (uplink, downlink, or both)
- Allow for burst of traffic on the uplink, downlink, or both, while still maintaining the over-all desired bandwidth limit

Traffic that exceeds the limits is dropped. Status fields keep running tallies of data sent and received and the number of uplink and downlink packets dropped.

All shares and the second		TRACT INC.	dia dia man	
lamont .				
mariles fronty	1 Lewis Tribi			
and the fronty	W Abote	been at		
Service Tennis	# Downlow Sandeldth (Kispil)	25600		
The Personnel	All Maximum Columnics Burst State 2011	51200		
	Maximum Harding Description Data (MR)			
Culture	ef upon barderth (Kips)	12288		
Derwent .	all Maxmun Uples Bush Site (Md)	24676		
10219	Maximum Mentlik Uption Date (MR)	1000		
248 Stat * Configuration	Operation Age 4 Root	3		
1997 Flore 3 ComPage relation	41 Downlink Pactors Roal	3		
Manning	AT Downey Packets Drosped			
	47 Lipinis Bulky Serie			
Eltimenut	All Applicat Practices Savel	1		
Table Configuration	(A) Lipica Packets Dropped			
A Contraction				
Marillor				
Induction States: Name (FLSR)				
Putty Radius				
DBBB Configuration				
PNTR Configuration				

Figure 4-3: ACEmanager: WAN/Cellular > General > Bandwidth Throttle

Field	Description
Bandwidth Throttle	
Mode	Allows you to Enable or Disable the feature Default is Disable.
Downlink Bandwidth (Kbps)	 The maximum downlink bandwidth in Kilobits per second (Kbps) This is the long-term bandwidth limit. Options are: 0-512000 (500 Mbps) Default is 25600. 0 = feature disabled for downlink traffic

Field	Description	
Maximum Downlink Burst Size (Kb)	 Maximum size for bursts of downlink traffic in Kilobits (Kb) This field allows the AirLink gateway to handle temporary bursts of downlink traffic without dropping packets. When the actual downlink traffic is less than the value configured in the Downlink Bandwidth (Kbps) field, ALEOS collects credits that can be used for bursty traffic. The value in this field is the maximum amount of credit that can be collected. Options are: 64–512000 (500 Mb) Default is 51200. 	
	Note: Sierra Wireless recommends that the Maximum Downlink Burst Size be set at 2x the value configured in the Downlink Bandwidth (Kbps) field. If the Maximum Downlink Burst Size is set at more than 60x the value configured in the Downlink Bandwidth (Kbps) field, the bandwidth throttle feature is disabled for downlink traffic.	
Maximum Monthly Downlink Data (MB)	An estimate of the maximum monthly downlink data in Megabytes (MB), based on the value set in the Downlink Bandwidth (Kbps). Maximum monthly downlink data (MB) = Downlink bandwidth × 2592000 ÷ 8192 Where: 2592000 is the number of seconds in a month (30 days/month) 1 MB = 1024 KB; 1024 × 8 = 8192 Kb/MB	
Uplink Bandwidth (Kbps)	 The maximum uplink bandwidth in Kilobits per second (Kbps) This is the long-term bandwidth limit. Options are: 0-204800 (200 Mbps) Default is 12288. 0 = feature disabled for uplink traffic 	
Maximum Uplink Burst Size (Kb)	Maximum size for bursts of uplink traffic in Kilobits (Kb) This field allows the AirLink gateway to handle temporary bursts of uplink traffic without dropping packets. When the actual uplink traffic is less than the value configured in the Uplink Bandwidth (Kbps) field, ALEOS collects credits that can be used for bursty traffic. The value in this field is the maximum amount of credit that can be collected. Options are: 32–204800 (200 Mb) Default is 24576.	
	Note: Sierra Wireless recommends that the Maximum Uplink Burst Size be set at 2x the value configured in the Uplink Bandwidth (Kbps) field. If the Maximum Uplink Burst Size is set at more than 60x the value configured in the Uplink Bandwidth (Kbps) field, the bandwidth throttle feature is disabled for uplink traffic.	
Maximum Monthly Uplink Data (MB)	An estimate of the maximum monthly uplink data i in Megabytes (MB), based on the va set in the Uplink Bandwidth (Kbps) Maximum monthly uplink data (MB) = Uplink bandwidth × 2592000 ÷ 8192 Where: 2592000 is the number of seconds in a month (30 days/month) 1 MB = 1024 KB; 1024 × 8 = 8192 Kb/MB	
Downlink Bytes Rcvd	Number of downlink bytes received The value is updated every 30 seconds, and is reset to zero on gateway reboot or reset to factory default settings.	

Field	Description
Downlink Packets Rcvd	Number of downlink packets received The value is updated every 30 seconds, and is reset to zero on gateway reboot or reset to factory default settings.
Downlink Packets Dropped	Number of downlink packets dropped because the limits set in Downlink Bandwidth (Kbps) and Maximum Downlink Burst Size (Kb) have been exceeded The value is updated every 30 seconds, and is reset to zero on gateway reboot or reset to factory default settings.
Uplink Bytes Sent	Number of uplink bytes sent The value is updated every 30 seconds, and is reset to zero on gateway reboot or reset to factory default settings.
Uplink Packets Sent	Number of uplink packets sent The value is updated every 30 seconds, and is reset to zero on gateway reboot or reset to factory default settings.
Uplink Packets Dropped	Number of uplink packets dropped because the limits set in Uplink Bandwidth (Kbps) and Maximum Uplink Burst Size (Kb) have been exceeded The value is updated every 30 seconds, and is reset to zero on gateway reboot or reset to factory default settings.

Ping Response

NUMBER OF STREET	129		States and Street, Str
and the second s	Response to two ring that Fing	14205 Personal	
Restant Prints	Nanganan Is Walking Put Pag	for Designation of the	
They bear and			
atheas			
General			
100 Exi I Configuration			
MEAN TONY problem			
The second se			
Bertout			
Mile Configuration			
Mantha			
helindine kilolis (kilolis (Kiloli)			
which Rowling			
MAR Configuration			
PATH Local Attack			

Figure 4-4: ACEmanager: WAN / Cellular > General > Ping Response

Field	Description			
Response to Incoming IPv4 Ping	 When an IPv4 ping is received by the gateway from a remote location, the Response to Incoming Ping redirects it to the selected location. No response: The incoming ping is completely ignored. ALEOS Responds (default): ALEOS responds to the incoming ping. Pass to Host: The ping is forwarded to the DMZ host with any response from the host forwarded back to the OTA location. If no host is connected, there is no ping response. 			
	Note: Some Mobile Network Operators may block all ICMP traffic on their network. When ICMP is blocked by the operator, a ping sent to the gateway from a remote location is not received.			
Response to Incoming IPv6 Ping	 When an IPv6 ping is received by the gateway from a remote location, the Response to Incoming Ping redirects it to the selected location. No response (default): The incoming ping is completely ignored. ALEOS Responds: ALEOS responds to the incoming ping. 			
	Note: Some Mobile Network Operators may block all ICMP traffic on their network. When ICMP is blocked by the operator, a ping sent to the gateway from a remote location is not received.			

Cellular

General

The General Page contains the following sections:

- Multi SIM: Multiple SIM Card Support
- Manual SIM Switching
- Automatic SIM Switching
- Network Credentials
- Band Setting
- Cellular Watchdog
- Advanced

The RV55, with its two SIM card slots, has Multi SIM and Automatic SIM switching capability. Settings for configuring these features appear on the Cellular > General page. For information on multiple SIM settings, see Multi SIM: Multiple SIM Card Support on page 84, Automatic SIM Switching on page 86 and Multiple SIM Configuration on page 98.

Cellular configuration for Ready to Connect eSIM

The WAN/Cellular > Cellular page is labeled **Cellular (R2C Capable)** for devices that support Sierra Wireless R2C (Ready to Connect) eSIM, as shown in Figure 4-5. For R2C eSIM-capable devices, the Cellular (R2C Capable) page displays Multi-SIM settings for external SIM slots and the eSIM. If your RV55 does not support an R2C eSIM, Multi-SIM settings do not appear.

Searce	I CRAM DW		
With Take Printing	47 June 101	Receited	
Rentantile Throllin	AT Prevay UR	NIX she w	
Page Responses	At Secondary SNI	(Bert	
Column (KIX) Casemon	#F Hat1	(DM Present)	
financial (47 KQC within	DM Present	
	AT allow N2C +DW Usage	Train +	
200 Bed I Configuration	Ache 1M ExcedPortegie Switching	Dealer +	
NUC and Longar steel	Column 100 Services		
Repaired	AT Target Did Dat	mer w	
800-mat	of Salth other 192	TANTAL RANGE AND	

Figure 4-5: ACEmanager WAN/Cellular > Cellular (R2C Capable) > General

		Constant Provide Division of Constants of Con-
		Summer South Street Street
inerer di	() (Auto dati	
Secondaria Proprint		
Sectoretti Sectore	41 Admi 300	that 1
	40 honorite	that if the
Peg Desposes	-41 Secondary UM	Bel. w.
admini .	and incert	CBI Present
	at hot 2	SM Assett
	in the Roder Model Forman's	GDERC
Mill and a Configuration	while BH David for state Dettiling	Itale -
NET You I LANSAGE MAN	Different Int Becklere	
Amuniter		and the second se
	AT Target BM (SA	Bell w
(Meesser)	41.9455 Adve Sile	Tankin Lijon Ste
Name Configuration	() Administration (International)	
Monthan .	manufactory is being believed () and 10 minutes may be entered	tur Ficche DM Daard Filmman Sectiong is anabies, i wil in presenter to 12 million
totable Slattic Room (RSR)	47 Service Lond Treased remained	0
	AT Reaming Treasult (minutes)	0
loiki p Mondarg	Mark Printery Network 1014 of Streets	0
	40 hour Tanual constant	8
	Officeret Codestal	
	47 30-PA Diversity	itaan -
	AT IF made as Preliment	Reagerful Sales -
	Colligant Soften	
	and the second sec	
	47 Sameri Rado Motos Band	Al Same
	#C Galley for Deni	ettern v
	Aut 20	Topic -
	Sand 41	tura -
	Databa Wattidag	
	Calular Indexet manifold	lines w
	(10eed)	
	42 Rel Carrier (Centelle) Peleskan	0
	UNE option (Records Chart Marry M.	Instein W
	UT: Resolution Trian	diama -
	AT Beauti at come time	Totest v
	Calular Deceasion Torine statistics	
	Enetwidd Camping	Date +
	two-brait .	Date v
	Accept Development Traffic	Seeks +
	Spherwal Post	(trans. V)
	Batra Estanara Pol	1024

Figure 4-6: ACEmanager: WAN / Cellular > Cellular > General

Multi SIM: Multiple SIM Card Support

The AirLink RV55 has two SIM card slots and is capable of supporting a primary and secondary SIM card. Depending on product variant, a Ready to Connect eSIM may also be available. By default, the external SIM card in the upper slot (slot 1) is the primary SIM card. To configure which SIM card is the primary SIM card, see Primary SIM on page 85.

When the RV55 powers up or reboots, it detects how many and which SIM cards are inserted. It connects to the cellular network using the primary SIM card, if present. If there is no SIM card in the primary SIM card slot, the RV55 connects to the mobile network using the secondary SIM card.

You can configure Automatic SIM Switching to respond to changes in the cellular network state, or you can switch SIM cards manually using the Switch Active SIM button or the *SWITCHSIM AT command.

Levelse	
e Angles	8-41
Al Piten, All	and the
AT SECONDER JR	Bed 12
er sault	MARY and
ALAM 5	MM Alexand
Autor Mater Materia Income	CHICHER C
Autor RM Harak Konsener Prakting	Prime in the

Figure 4-7: ACEmanager: WAN/Cellular > Cellular > General (Dual SIM settings)

FIND SM	
AT Adva SW	RPC WIN
AT Chimary SIM	520 xGM V
All Secondary BIM	SHIT V
AL SIGH1	Bill Freseni
AT RECEIPTING	SIM Prevent
AT Allow R7C eSild Darge	Fostie V
Active SIV Based Firmware Switching	Unabled 😒

Figure 4-8: ACEmanager: WAN / Cellular > Cellular > General (Multi-SIM R2C Capable)

Field	Description
Multi SIM	
Active SIM	Shows the location of the Active SIM card, i.e. the SIM card account that is used for the current data connection.
	You can also use the *ACTIVESIM? AT Command to query which SIM card is currently being used for the data connection.

Field	Description
Primary SIM	 Select the primary SIM card. If multiple SIM cards are installed, the Primary SIM card is used for network connections. Options are: Slot 1—The external SIM card in Slot 1 (upper slot) is the primary SIM card. (default) Slot 2—The SIM card in Slot 2 (lower slot) is the primary SIM card. R2C eSIM (if available)—The R2C eSIM is the primary SIM. If there is no SIM card in the primary SIM card slot, the gateway connects to the cellular network using the secondary SIM. You can also use the *PRIMARYSIM AT Command to query or set the primary SIM card slot.
Secondary SIM	Selects the SIM card slot or R2C eSIM (if available) to be the Secondary SIM card.
Slot 1	Indicates whether or not a SIM card is inserted in SIM slot 1 (the upper SIM slot) You can also use the *SIM1PRESENT? AT Command to query the presence of a SIM card in slot 1.
Slot 2	Indicates whether or not a SIM card is inserted in SIM slot 2 (the lower SIM slot) You can also use the *SIM2PRESENT? AT Command to query the presence of a SIM card in slot 2.
R2C eSIM	Indicates whether or not a Ready to Connect eSIM is present on the RV55.
Allow R2C eSIM Usage	 Select whether to allow the RV55 to use the Ready to Connect eSIM for network connections. Enable (default) Disable
Active SIM Based Firmware Switching	 Enable or disable SIM-based radio module image switching. Enable—Allows SIM switches to also trigger radio module firmware image switches if installed SIM cards require different radio module firmware. When enabled, the Active Radio Module Firmware status appears, and the range of the Secondary Network Timeout changes from 10–255 minutes to 1–5 hours (1 default).
	Note: Enable this feature for fixed (stationary) applications only. Ensure that the Network Watchdog Timer and Cellular Watchdog timer are disabled. Otherwise, the RV55 could reboot and switch back to the primary SIM (which is normal SIM switching behavior) while cellular service is still relying on the secondary network for its connection.
	Note: The firmware image switch can take 5 to 10 minutes. During this time, the WAN interface connection will be interrupted.
	• Disabled—The RV55 does not automatically select the appropriate radio module firmware when SIM switching occurs. You can manually switch the active SIM and then manually switch the radio module firmware (see Manually Selecting the Radio Module Firmware on page 397).

Manual SIM Switching

PR an PRAME 1		
 Log-DM SM 	U. C. S.	
At Avilie Avia 70	Auto a second state	

Figure 4-9: ACEmanager: WAN/Cellular > Cellular > General (Dual SIM settings)

Field	Description
Target SIM Slot	 Select the inactive SIM to be the active SIM card. Options vary according to your product variant, but may include: Slot 1 Slot 2R2C eSIM (if available)
Switch Active SIM	If the RV55 has multiple SIM cards installed, click the Switch Active SIM button to switch to the target SIM card. No reboot is required, but you may need to refresh the screen in order to see the change.

Automatic SIM Switching

VALUEDED - Delay Schwart 5 and 12 minutes can be amared	and if Active SBI Based Permane Switching is analysis; it will be overwritten in 12 minutes
P Sente Loss Trineout (rendes)	0
AT Rearing Timeset (ronanc)	10
Non-Phonary National Trevenut Disarts)	(f) (manual sector)
Scan Timesul (minutes)	30

Figure 4-10: ACEmanager: WAN/Cellular > Cellular > General > Automatic SIM Switching

If you have multiple SIM cards installed, you can use the Automatic SIM switching fields to configure the circumstances in which the RV55 automatically switches the SIM card being used for network connectivity. The configurable cases are:

- Service Loss Timeout—switch SIMs if the network's data connection is lost for x minutes
 - If Cellular > Monitor is enabled, the Cellular Monitor ping test determines whether the end-to-end connection is lost. If the ping test fails, the Service Loss Timeout begins.
- Roaming—switch SIMs if roaming for x minutes
- Secondary network—if the gateway has been connected to the secondary SIM for x minutes, switch to the primary SIM. Use this parameter if you prefer the gateway to use the primary SIM whenever possible.
- Scan Timeout—After a Service Loss Timeout and an attempted switch to the secondary SIM, the Scan Timeout switches the gateway back to the primary SIM if no connection is made during the timeout. Similarly, if the gateway does not connect to the primary cellular network after startup or reboot, the Scan Timeout triggers the gateway to use the secondary SIM.

These settings work together, so it's important to plan how you want automatic SIM switching to work before configuring these fields.

Note: Sierra Wireless recommends that whenever you configure automatic SIM switching, you include a setting for Scan Timeout. This helps to ensure that if the desired network is not available, the gateway maintains a data connection by attempting to connect to the other network. If you intend to use Active SIM-based Firmware Switching, disable the Scan Timeout by setting it to 0. This ensures the firmware image switch does not take place if the gateway cannot connect to the secondary network.

Service loss example

In this example, the desired outcome is to use the primary SIM (for example, a less expensive network connection) whenever possible, but if necessary, to switch to the secondary SIM to maintain the data connection.

The Network Watchdog and Cellular Watchdog are both disabled or configured for a longer interval than the Service Loss Timeout, which enables SIM switching to persist. The watchdogs may prompt the gateway to reboot, which causes the gateway to revert to using the primary SIM card.

Note: If Active SIM Based Firmware Switching is enabled, switching to the secondary SIM also loads the appropriate radio module firmware for the secondary SIM card. As well, if Active SIM Based Firmware Switching is enabled, the Secondary Network Timeout changes from minutes (as shown in Figure 4-11) to hours.

WINNERS A delay between 5 and 10 minutes can be entered built Adva SIV Dexed Limitate Switching is erabled, if will be intervaliente 10 minutes		
All Service Loss Timeout (minutes)	20	
MT Reaming funeral (minutes)	D	
Al Non Primary Network Timeout (minutes)	80	
MT Scan Timeord (minutes)	10	

Figure 4-11: ACEmanager: WAN/Cellular > Automatic SIM Switching

With this configuration:

• If the RV55 loses the data connection on the primary SIM for 20 minutes, it switches to the secondary SIM.

Note: If Active SIM Based Firmware Switching is enabled, switching to the secondary SIM also loads the appropriate radio module firmware for the secondary SIM card.

- If the RV55 connects to the network using the secondary SIM, it uses the secondary SIM for 60 minutes and then attempts again to connect to the primary SIM's network for another 10 minutes.
- If the RV55 cannot connect to the secondary network for 10 minutes (the Scan Timeout), it attempts to reconnect using the primary SIM for another 20 minutes.

Note: The "service loss" used for automatic SIM switching is based on network information about the cellular connection. You can also use the Cellular Monitor to trigger the change in cellular network state. This enhances your network monitoring capability by sending pings to a configured IP address to confirm your end-to-end connection. If the ping test fails, then the Service Loss Timeout begins, followed by the SIM switch. To configure the Cellular Monitor, see Cellular > Monitor on page 103.

Roaming example

In this example, the desired outcome is to avoid roaming as much as possible, but if the roaming network is the only one available, to maintain a data connection.

TRANSPORT A deter between 5 and 40 mm des can be entered b	ad if Active SBN Based Fernware Switching to enabled, it will be overwritten to 12 minutes
If Sentice Look Timesul (minutes)	0
Paursing Teneout (minutes)	10
Plan Primary Network Time (ul (minutes)	0
* Scan Timeout (manufest)	30

Figure 4-12: ACEmanager: WAN/Cellular > Automatic SIM Switching (Roaming example)

With this configuration:


- If the RV55 is roaming, for example, on the primary SIM for 10 minutes, it switches to the secondary SIM.
- If the secondary SIM's network is not immediately available, the RV55 continues to attempt to connect for 30 minutes. The RV55 switches to the secondary SIM's network as soon as it becomes available. If, after 30 minutes, the RV55 is still unable to establish a data connection with the secondary SIM, the RV55 switches back to the primary SIM.

Automatic SIM Switching		
Service Loss Timeout (minutes)	 If the data connection is lost for more than the configured time (in minutes), the gateway switches to the inactive SIM card. Options are: 0—The feature is disabled (default) 10-255 (5-255 if Active SIM Based Firmware Switching is disabled) You can also use the *MSNOSERVICETOUT AT Command to configure or query this setting. 	
	Tip: If you prefer to use the Primary SIM account as much as possible, configure the Non-Primary Network Timeout (minutes)/(hours) and the Scan Timeout (minutes) so the gateway will periodically check, and switch back to the Primary network when it becomes available.	

Roaming Timeout (minutes)	If the gateway has been roaming for longer than the time (in minutes) configured in this field, it automatically switches to the inactive SIM card. Options are:
	• 0—The feature is disabled (default)
	• 10-255
	You can also use the *MSROAMINGTOUT AT Command to configure or query this setting.
	This option is useful if the gateway frequently crosses an international border where there are different Mobile Network Operators in each country. You can set up the gateway with two SIM cards—one for a Mobile Network Operator in each country. The gateway then automatically switches to the SIM that is not roaming (after a configured delay) whenever the gateway crosses the border.
Non-Primary Network Timeout (minutes)/ (hours)	If the gateway has been connected to a network using a secondary SIM card for the time configured in this field (in minutes), it automatically switches to the primary SIM card. This allows you to configure the gateway to fallback to the primary network if, for example, the data rate is better on the primary network. Options are:
	0—The feature is disabled (default)
	• 10-255
	Note: If Active SIM Based Firmware Switching is enabled, the range changes to 0–255 hours (default is 0).
	You can also use the *MSSECONDARYTOUT AT Command to configure or query this setting.
Scan Timeout (minutes)	 If the gateway has been trying to connect to a network for more than the configured time (in minutes), the gateway switches to the other SIM card. Options are: 0—The feature is disabled (default) 10–255
	You can also use the *MSSCANTOUT AT Command to configure or query this setting.
	Note: If you are using Automatic SIM switching, this field should always be configured.
	Note: The automatic SIM switch is initiated if the gateway is unable to establish a data connection or if the SIM card is unable to register on the network. If this is a new SIM card, check that the APN in Use is correct and that it is able to register on the network.

Network Credentials

F/Nelwork Credenitals	
AL 3C RX Diversity	buay V
AT L'Address Preference	Pet and Peti Galaway 🗠



Network Credentials	
RX Diversity (3G only)	 Allows two antennas to provide a more reliable connection Disable Enable (default) If you are not using a diversity antenna, diversity should be disabled.
	Note: Two antennas are required when connecting to an LTE network.
IP Address Preference	 Use this field to select the preferred IP Address version. To use IPv6, it must be supported by your Mobile Network Operator and your account (SIM and APN). Options are: IPv4—When the gateway connects to the mobile network, it is assigned only an IPv4 address. IPv4 and IPv6 Gateway—When the gateway connects to the mobile network, it is assigned an IPv4 address and an IPv6 address. The IPv6 address and routing information are passed to the LAN clients so that they can acquire IPv6 addresses and pass IPv6 traffic over the mobile network. Note: The LAN client must have IPv6 enabled and must be configured to use SLAAC (Stateless address auto configuration). The IPv6 address and routing information, and DNS servers are passed to the LAN clients via SLAAC.
	Note: Other than routing IPv6 packets between the WAN and the LAN, no other AirLink features (except VPN) are supported on IPv6.
	The IP addresses are displayed on the Status > Home screen.
	Note: For more information, see IPv6 Support on page 97.

Band Setting

Fillend Selling	
All Current Radio Module Band	All bands
AT Selling for Band	Al bands. W
Band 25	buble M
Hand 41	Fosta V

Figure 4-14: ACEmanager: WAN/Cellular > Cellular > General > Network Credentials

Current Radio Module Band	Band reported by the radio module as the one currently in use.
Setting for Band	For setting band details for your gateway, see Setting for Band on page 567.
Band 26	These fields appear depending on your AirLink device and radio module. They allow you to disable Band 26 and Band 41. Leave the default settings unless advised by your
Band 41	Mobile Network Operator to change them.

Cellular Watchdog

[] Collular Welchdog Cellular Network Welchdog

Fnable 🗸

Figure 4-15: ACEmanager: WAN / Cellular > Cellular > General > Network Credentials

Cellular Network Watchdog	Cellular Network Watchdog Options are:	
	• Enable—When this Watchdog is enabled, the gateway reboots after several failed attempts to attach to the mobile network. (default)	
	 Disable—When this field and the Network Watchdog Timer field are both set to Disable, the gateway never reboots as a result of lack of network connectivity. 	

Advanced

- Artomord	
All Sel Carrier (Operator) Selection	0
111 Adve Revelection Interval	Disabled
LTE Reselection Time	20 Seconds 🗠
MT Always on connection	Foxbled V
Cellular Debounce Timer (seconds)	4
Enable MSS Clamping	Percel 1
Maximum Segment Size - MSS (byles)	1460
Turn Off NAT	Doctor V
Accept Unscholed Trailin	Disable 🗸
Ephomoral Port	bullt v
Starting Ephemeral Port	1024
MT Service Domain Preference	Circuit switched and packet switched

Figure 4-16: ACEmanager: WAN/Cellular > Cellular > General > Advanced

 mode= 1: Manual—use only the operator <oper> specified</oper> mode= 4: Manual/automatic—if manual selection fails, goes to automatic mode format= 0: Alphanumeric ("name") format= 2: Numeric oper="name" See also +COPS on page 481 and *NETOP? on page 474. Note: Not all carriers or accounts allow specifying the operator. If the carrier doesn't 	Selection m	 mode= 4: Manual/automatic—if manual selection fails, goes to automatic mode format= 0: Alphanumeric ("name") format= 2: Numeric oper="name" See also +COPS on page 481 and *NETOP? on page 474.
--	-------------	---

LTE Active Reselection Interval	 available. When an LTE AirLink gateway is connected to a non-LTE network, it may not hand over to an LTE network when one becomes available if data is being continuously transmitted or received. When the LTE Active Reselection Interval timer is configured, the AirLink gateway temporarily halts uplink data for the length of time configured in the LTE Reselection Time field if the gateway is connected to a non-LTE network. This allows the radio module to go idle and reconnect to an LTE network, if one is available. 	
	 Note: If the LTE signal that the AirLink gateway receives is weaker than the HSPA+ signal, the gateway may not revert to LTE, depending on the local network characteristics. This feature should be disabled: If the SIM in the gateway is not provisioned to work on an LTE network If the gateway is roaming 	
	 To use this feature: 1. From the drop-down menu in the LTE Active Reselection Interval field, select how long the AirLink gateway is not on an LTE network before the reselection process begins. (Disabled is the default.) 	
	Al contra vela Al pro terce Primerina (1966-1976) Al contra contra successione	1.14.00 2.6000 2.0000 2.0000 2.0000 1.0000
	Acting to the Handwid Handwid Handwid Handwid Handwid Microsoft Microsoft Lide Account was needed by	Perunk v Vittari Vitta
	 Click Apply. Reboot the gateway. 	Peekkel _
LTE Reselection Time	LTE network (i.e. how long the reselect	vay radio should attempt to find and connect to an tion process described in LTE Active Reselection sion during the reselection process is buffered.

Always on connection	 This field is intended for International gateways on the Vodafone network. This option allows you to configure the AirLink gateway to use minimal wireless network resources when there has not been any outgoing WAN network traffic. Enabled—The AirLink gateway maintains a mobile network data connection. (default) Disabled-Connect on traffic—The AirLink gateway only establishes a mobile network data connection: When there is network traffic If SMS Wakeup is configured and the gateway receives the specified type of SMS (For information on configuring SMS Wakeup, see SMS Wakeup on page 253.) Note: You can also use AT*RADIO_CONNECT to switch the mobile network connection
	on and off. See *RADIO_CONNECT on page 490.
Connection Timeout (minutes)	 This field is intended for International gateways on the Vodafone network. This field only appears when Always on connection is set to Disabled - Connect on traffic, and defines the timeout period for Always on connection. If there is no outgoing packet through the WAN interface during the period set in this field (in minutes), the AirLink gateway disables the WAN connection. This timer is triggered after every outgoing packet, except AT*IPPINGADDR keep alive packets. 2–65535 minutes (default is 2)
	Note: You can also use AT*TRAFWUPTOUT to set the timeout period. See *TRAFWUPTOUT on page 495.
Cellular Debounce Timer (seconds)	Use this field to configure how long it takes for the gateway to respond after cellular service is lost. This timer can prevent service interruptions caused by brief cellular network outages. • 0-20 seconds (default is 4)
Enable MSS Clamping	 MSS (Maximum TCP Segment Size) Clamping controls the maximum packet size used for TCP connections between a local (LAN-side) host and a remote host over the cellular WAN interface. MSS Clamping helps avoid possible issues with sending and receiving large TCP packets over the cellular network when other standard MTU mechanisms do not appear to be working with your installation. Options are: Manual—MSS is clamped to the specified maximum value bi-directionally for all inbound (remote-to-LAN) and outbound (LAN-to-remote) TCP connections when the TCP session is established using the cellular interface. Automatic (default)—MSS is clamped at 40 bytes (20 byte IP header + 20 byte TCP backets and a remote header).
Maximum Sagmant Siza	 header) less than the MTU of the cellular interface. Disable
Maximum Segment Size - MSS (bytes)	 When MSS Clamping is set to Manual, set the Maximum TCP Segment Size 256–1460 bytes (default is 1460)

Turn Off NAT	When enabled, ALEOS routes outbound packets from connected devices without performing NAT on them. For example, when a connected device that has an IP address of 192.168.13.100 sends data to a remote destination, the outbound packets have a source IP of 192.168.13.100.
	If you are configuring RADIUS Framed Route, set this field to Enable. For more information, see RADIUS Framed Route on page 156. In most other cases, it is best to leave this field at the default setting (Disable).
Accept Unsolicited Traffic	If you are configuring RADIUS Framed Route, set this field to Enable. For more information, see RADIUS Framed Route on page 156. In most other cases, it is best to leave this field at the default setting (Disable).
Ephemeral Port	Enable or Disable the Ephemeral Port feature
	• Disable—The source port in packets the AirLink gateway receives from a connected device and then sends out is not changed. The source port assigned to the packet when it was created in the customer's connected device is used. (default)
	• Enable—The AirLink gateway changes the source port on all outgoing NATed UDP packets, using the range configured in the Starting Ephemeral Port field.
Starting Ephemeral Port	This field appears only when the Ephemeral Port field is set to Enable. It allows you to set the starting port range used by a LAN device as the source port for over-the-air (OTA) destinations using NAT.
	Note: This field is intended for advanced users only. In most cases, use the default value.
	The NAT for the LAN device uses a range of 1000 ports as source ports for OTA destinations beginning with the configured Ephemeral port. Options are: • 1024 (default)–64535
	If you have a network with multiple LAN devices that are sending data to the same server and the server is not receiving data from one (or more) of the devices, it may be because the Mobile Network Operator has a WAN firewall that is blocking the ports used by the NAT for over-the-air (OTA) destinations. This field enables you to avoid the blocked ports by changing the source port range used to send the data. For example, some users have found that changing the starting port to 42000 has resolved the issue.
	Note: The ephemeral port setting does not affect any outbound traffic initiated by the device such as Location reports, Events Reporting, Device Initiated ALMS connection, etc.
Service Domain Preference	Controls whether the LTE radio attaches to the cellular network in Circuit switched mode (CS-Only), Packet Switched mode (PS-Only), or Circuit switched and Packet switched modes (CS+PS). Leaving at the default setting is recommended. Changing the setting to Packet switched may resolve connection issues related to Circuit switched mode. Options are:
	Circuit switched
	Packet switched
	Circuit switched and packet switched (default)

Cellular IOT Preferences

The following settings appear for WP7702-equipped devices only. Sierra Wireless recommends leaving these settings at default unless you experience problems with your application.

#T 176 minimum Operation	(there w)
AT LTE Cou.M1 Operation	ham w
AT LTE MB-HT Cannelion	Same V
47 Extended Discontinuous Persoditor	Come of

LTE Wideband Operation	 Appears only for WP7702-equipped devices. Enables or disables LTE Wideband operation. Options are: Enable (default) Disable
LTE Cat-M1 Operation	 Appears only for WP7702-equipped devices. Enables or disables LTE Cat-M1 operation. Options are: Enable (default) Disable
LTE NB-IOT Operation	 Appears only for WP7702-equipped devices. Enables or disables LTE NB-IOT operation. When enabled, Sierra Wireless recommends disabling LTE Cat-M1 and LTE Wideband operation. Options are: Enable (default) Disable
Extended Discontinuous Reception	 Appears only for WP7702-equipped devices. Enables or disables extended discontinuous reception (eDRX or extended sleep mode). By default, the WP7702 radio is configured to support an extended sleep mode (eDRX enabled) when idle to conserve power. However, if using a static IP, eDRX prevents the radio from responding to inbound connection requests. For static IP scenarios, it is necessary to disable eDRX to allow inbound connections, albeit at the expense of higher average current consumption. Options are: Enable (default) Disable

IPv6 Support

IPv6 support is available for cellular network connections. The LAN connections can be Ethernet or Wi-Fi (depending on your gateway model), but the WAN connection must be an active cellular connection. IPv6 support has been tested on the Verizon Wireless network.




Figure 4-17: IPv6 support network

To configure the RV55 to use IPv6 addressing:

- 1. In ACEmanager, go to the Status > Home screen.
- If the Network Interface field value is anything other than Cellular, go to the WAN/ Cellular screen > WAN Interface Priority Configuration section and set the priority for Cellular to First.
- **3.** If any of the LAN clients are using Wi-Fi to connect to the gateway, go to the Wi-Fi screen and for each SSID being used, set the Bridge Wi-Fi to Ethernet field to Enabled. Note that you should only do this for trusted Wi-Fi clients.
- 4. Reboot the gateway.

IPv6 Technical Implementation Details

Sierra Wireless IPv6 supports:

- Linux operating system
- SLAAC addressing for clients
- Router advertisement for the IPv6 DNS server addresses

Note: Make sure rdnssd daemon is installed on your LAN client to take the IPv6 DNS server addresses.

Troubleshooting tip: If you experience problems with Internet access, try setting the MTU for LAN clients to 1280.

Multiple SIM Configuration

To configure multiple SIM cards:

1. In ACEmanager, go to WAN/Cellular, and from the left menu, select either SIM Slot 1 Configuration or SIM Slot 2 Configuration or R2C eSIM Configuration.

The following examples show how to configure SIM Slot 1. The steps are the same for other SIM slots.

al anna (anna (anna (anna anna anna a		Daniel B. Ruby Robert	
Germanuté	Li fadocot (Jadanilata		
Interface Princip	Afficiation	APRINGTOWN	
Benchurdet: Thrusten	AT Dramma APN		
Plag Brokenen	AT More Based, APAL	(Death	
Dillion	ar baines	(SALING	
Garage and Contract of Contrac	[] information		
SHI SALT CONTRACTOR	AT Saleson Automication Node	828 +	
The local divergencement	AT Intersects Lines (2)		
Abarbar	AT Nation Pastows		
(Place size			
Mate Configuration			
Barrier			
Andrew Market Woman (#1052			
NET PORT OF			
Intel Configuration			
PATRA Configuration			

Figure 4-18: ACEmanager: WAN / Cellular > SIM Slot 1 Configuration

2. Use the information in the following table to configure the SIM card.

Field	Description
Network Credential	8
	es not automatically connect to the network, you may need to manually configure your APN using eld. You may also need to contact your Mobile Network Operator to confirm the APN and gateway.
APN in Use	 This field only appears for the Active SIM. The APN in use for the current mobile network connection. When you power on the AirLink gateway, the APN the gateway is using for authentication on the mobile network is displayed. If a user-entered Override APN is configured, the Override APN is displayed. If there is no Override APN configured, an automatically-selected APN is displayed. If ALEOS is unable to find the appropriate APN to use (No APN found), contact your Mobile Network Operator for the APN and enter it in the Override APN field.
Override APN	 The APN entered in this field takes priority over the automatically selected APN or a blank APN. 1. Enter the APN in this field (maximum 100 characters). 2. Click Apply. 3. Click Reboot. Note: If you reset the gateway to factory defaults, you have the option to preserve the custom APN, if entered. See Reset Configuration on page 380. Note: For gateways on the Sprint network, the correct APN is automatically sent to the gateway. Leave this field blank unless specifically asked by Sprint to enter an APN.
Allow Blank APN	 Allows connection with a blank APN for supported networks. <i>Note: ALEOS will only use a blank APN if both Allow Blank APN is enabled and the Override APN field is blank.</i> Options are: Enable—ALEOS attempts to connect to the network and acquire an APN from the network. Disable (default)—ALEOS automatically selects an APN, or uses a manually entered Override APN.
SIM PIN	Click this button to configure the PIN for the SIM card in SIM slot 1. For more information, see SIM PIN on page 100. By default, the gateway does not use a SIM PIN for the SIM in slot 1.
Advanced	
Network Authentication Mode	 Specifies the authentication method to use when connecting to a mobile network Options are: NONE CHAP PAP (default)

Field	Description
Network User ID	Network User ID The login that is used to log in to the mobile network, when required. • Maximum 128 characters
Network Password	Network Password is the password that, when required, is used to log in to the mobile network.Maximum 30 characters

SIM PIN

If you have a SIM card with a PIN configured, you can configure ALEOS to enter the PIN on reboot, so human intervention is not required.

Note: R2C eSIM does not support SIM PIN.

This feature has two requirements:

- A PIN-locked SIM card—Contact your Mobile Network Operator to ensure that they support this feature and to obtain a PIN-locked SIM card and PIN.
- The SIM PIN feature in ACEmanager must be enabled. See Enable the SIM PIN.

If the AirLink gateway has a PIN-locked SIM installed and this feature is not enabled in ACEmanager, the AirLink gateway is unable to go on air and the Network Status field on the Status > Home screen displays the message "SIM PIN incorrect, # attempts left".

Note: On gateways with ALEOS 4.7.0 or later, you can use AT Commands to enable, disable, or change the SIM PIN the SIM card requests when the gateway boots up. For details, see *CHGSIMPIN on page 478 and *ENASIMPIN on page 482.

Enable the SIM PIN

To enable or enter the SIM PIN:

- 1. In ACEmanager, go to WAN/Cellular > SIM Slot 1 or 2 Configuration.
- 2. Click the SIM PIN button. The following pop-up window appears.

SIM PIN	Close
Set SIM PIN	
SM Pin :	Don't change Enable Disable
Enter SIM Pin :	
Retype SIM Pin :	
Status :	Save Cancel Network Ready

3. Select Enable.

4. Enter the PIN (obtained from your Mobile Network Operator or set using *CHGSIMPIN—see page 478) twice and click Save.

5. Reboot the AirLink gateway.

After rebooting:

- The AirLink gateway uses the configured PIN on subsequent reboots.
- The SIM PIN pop-up window shows the default settings. "Don't change" is selected and the SIM PIN fields are blank. "Don't change" indicates that the PIN is used in the same way on every boot.

Note: If you enter an incorrect PIN, the AirLink gateway is unable to go on air, and the Network Status field on the Status > Home screen displays "SIM PIN incorrect, # attempts left". The failed PIN is not retried on subsequent reboots to prevent exhausting the available number of retries with repeated attempts with an incorrect PIN.

Change the SIM PIN ALEOS Enters at Reboot

To change the SIM PIN ALEOS enters at reboot:

- 1. In ACEmanager, go to WAN/Cellular > SIM Slot 1 or 2 Configuration.
- 2. Click the SIM PIN button. The following pop-up window appears.

SIM PIN	Close
Set SIM PIN	
SM Pin :	Don't change Enable Disable
Enter StM Pin :	
Retype SIM Pin :	
Status :	Save Cancel Network Ready

- 3. Select Enable.
- 4. Enter the new PIN twice and click Save.
- 5. Reboot the AirLink gateway.

After rebooting:

- The AirLink gateway uses the configured PIN on subsequent reboots.
- The SIM PIN pop-up window shows the default settings. Don't change is selected and the SIM PIN fields are blank. "Don't change" indicates that the PIN is used in the same way on every boot.

Note: If you enter an incorrect PIN, the Network Status field on the Status > Home screen displays "SIM PIN incorrect, # attempts left". The failed PIN is not retried on subsequent reboots to prevent exhausting the available number of retries with repeated attempts using an incorrect PIN.

Disable the SIM PIN

To disable the SIM PIN:

- 1. In ACEmanager, go to WAN/Cellular > SIM Slot 1 or 2 Configuration.
- 2. Click the SIM PIN button. The following pop-up window appears.

SIM PIN		Close
SM Prc	Oon't change Enable It Disable	
Enter Still Pin:		
Retype SM Pirc		
		ave Cancel
Status:	Disconnected	

- **3.** Select Disable.
- **4.** Enter the PIN twice and click Save. If you enter an incorrect PIN or no PIN, the feature will not be disabled.
- **5.** Reboot the AirLink gateway.

After rebooting:

- The AirLink gateway no longer uses the stored PIN on subsequent reboots.
- The SIM PIN pop-up window shows that the feature is Disabled.

Unblocking a SIM PIN

When you enable, change or disable a SIM PIN, you have a set number of attempts to enter the correct PIN, depending on your Mobile Network Operator. If the correct PIN is not entered in the allotted number of attempts, the SIM PIN becomes blocked and you need a PUK code to unblock it.

To unblock a SIM PIN:

- 1. Contact your Mobile Network Operator to obtain a PUK code.
- 2. In ACEmanager, go to WAN/Cellular > SIM Slot 1 or 2 Configuration.
- **3.** Click the SIM PIN button.

When the PIN is blocked, an additional field (Enter SIM Unblock Key (PUK)) appears.

SIM PIN	0 cae
Vid Ha.	10 Evel daaree 48 gewee 10 Evelop
Contraction (
Keis ver 310 Max	
Print SP Frank Lyp (SR)	
	Sec. Lance
8 da 1	Shirthings and Talkassi in C

- 4. Select Enable.
- 5. Enter the new PIN code.

6. Enter the PUK and click Save.

Be careful when entering the PUK. You have a limited number of attempts to enter the correct PUK (generally 10) before the SIM card is disabled. If the PUK does not unblock the SIM PIN after the first few attempts, contact your Mobile Network Operator.

If you have exhausted all the alloted attempts to enter the correct PUK, the Mobile Network Operator may give you a new SIM card, or a new code to enable your existing SIM card.

To enter the code:

- a. Remove the SIM card from your AirLink gateway (following the instructions in the AirLink gateway Hardware User Guide) and insert it in a cell phone that accommodates a MiniSIM (2FF) card.
- **b.** Enter a new code provided by the Mobile Network Operator and then return the SIM card to the AirLink gateway.

timus WWWCellular Dus	TAN THE THE	6 Security	Bervices	Leaster	Events Reporting	Dust Benal	Applications	an a	Admin
er geheid ime geschlie i 1728	455.							Anna Pr	ter:
General	# Tot Hand (Inc	indu)			900				
Interface Privity	W. Monitor Type.				Deathed				
Rentral Texture	# Porg Tast IP Add	***			0000				
	Time Delivery PS	(alexand) age			20				
Peq trapmer	Number of Progr				5				
allalar									
Gennet									
MAN AND CONTRACTOR									
Mill Mord Configuration									
Manne									
during .									
Table Configuration									
Munitur									
And a second sec									
lečada Sunic Rose (NSR) ulicy Rassing MHD Cooffgension									

Cellular > Monitor

Figure 4-19: ACEmanager: WAN / Cellular > Cellular > Monitor

Use these fields to monitor the cellular network connection.

ALEOS 4.14.0 Software Configuration User Guide for AirLink RV55

Field	Description
Test Interval (seconds)	 The amount of time between tests of the cellular connection. Available range is: 1–15300 seconds (Default is 900.) Most applications work well with an interval of 900 to 3600 seconds (15 to 60 minutes).
Monitor Type	 Determines the type of test run on the interface to diagnose its ability to provide end-to-end connectivity for this interface. Options are: Disabled—No end-to-end diagnostic runs and the service state cannot be verified. Therefore it is assumed that this interface provides service if an IP is assigned. Traffic Monitor—A ping test is only performed if there is no traffic during the configured interval. Ping Test—A ping is sent at the end of the test interval regardless of whether or not there has been any traffic during the interval (i.e. if the interface receives ingress traffic regularly, no additional traffic is generated by the gateway).
	Note: Using pings to monitor the interface may accrue data charges. Each individual ping is approx- imately 98 bytes (196 bytes for ping sent plus ping response).
Ping Test IP Address	Enter the IP address to ping.
Time Between Pings (seconds)	 Time between individual pings Available range is: 1-20 seconds (Default is 20.) If the first ping fails, the AirLink gateway sends additional pings at the configured interval. If all pings fail, the AirLink gateway declares the service state as "Not Established" and attempts to switch to another interface according to the Interface Priority (see page 76) configuration, and interface availability. If this field is set to 10 (with Number of Pings set to 5) and the test is started and fails, the interface does not provide service for a total of 50 seconds.
Number of Pings	Sets the number of consecutive missed pings before the AirLink gateway declares the service state as "Not Established" and attempts to switch to another interface. Available range is: • 1–12 (Default is 5.)

Ethernet

Static Configuration

Before configuring the Ethernet WAN mode, go to LAN > Ethernet and ensure that the Ethernet port is set to WAN.

Mana State U.F		s Localise Events Repetting Serial day	plication (O) Admin
al-ami(4+4-300000000000000000000000000000000000	D HM	(Tauret 1.4)	mark (Ambern Course
limetal	(Hithered See		
Interface Presety	III		
A STATISTICS OF A STATISTICS	MOTE to under to use plate configuration, the t	Shamat put river to set to 104% media.	
Revenuel Through	Ethernal WWW Mode	(pair y)	
Perig Responses	There were at	0.000	
Cellular	Strate WHE Network	0.000	
	State WHY Cale way	0.50.0	
General	State WHY DIVE 1	0.000	
SHE MAD I CONTRACTORY	These WHILEHEL	0.0.0	
1948 Shot 3 Conclusion			
the loss I constitution			
Barrier'			
Adjustment .			
Party Configuration			
House .			
Hubble State Reals (R.171)			
Policy Rading			
Intel Conference			
PRIM Configuration			

Figure 4-20: ACEmanager: Wan/Cellular > Ethernet > Static Configuration

Field	Description
Ethernet WAN	
Ethernet WAN	 Set the Ethernet WAN IP address mode Options are: Dynamic (default)—WAN IP address is assigned by the DHCP server Static—Choose this mode to statically assign an IP address when required.
Mode	After you select Static, click Apply.
Static WAN IP	Enter the static IP address for the AirLInk RV55 Example: 192.168.0.55
Static WAN	Enter the subnet mask
Netmask	Example: 255.255.255.0
Static WAN	Enter the static IP address for the router/gateway
Gateway	Example: 192.168.0.1

	Description
Static WAN	Enter the static IP address for the primary DNS server ^a
DNS1	Example: 192.168.0.2
Static WAN	Enter the static IP address for the secondary DNS server ^a
DNS2	Example: 192.168.0.3

Ethernet > Monitor

tuius VMACetutar Dust	10-PI LMS . VPIE Becurity Bervices Lo	catton Events Reporting Duar Service	A Applications 3/2 advent
and approved in the OWNER PORTAL	ny .		Data States (Sec.
General	44 Test televal (records)	300	
Interface Printly	47 Manager Type	Onaties -	
Manchestern Throuthe	H Porg Text P Address	0000	
	Tana Between Pingt (seconds)	20	
7Mg Response	Hunder of Plags	5	
Colleger			
Galeral			
101 Build Configuration			
100 Mod J Configuration			
Testiar			
Educat			
Nate Configuration			
Personal Viceo Vic			
Baliable State Rooks (RSH)			
Public Routing			
DBDG Configuration			

Figure 4-21: ACEmanager: WAN / Cellular > Ethernet > Monitor

Field	Description	
Test Time Interval (seconds)	 The amount of time between tests of the Ethernet WAN connection. Available range is: 1-15300 seconds (Default is 300.) Most applications work well with an interval of 900 to 3600 seconds (15 to 60 minutes). 	
Monitor Type	 Determines the type of test run on the interface to monitor its ability to provide end-to-end connectivity for this interface. Options are: Disabled—No end-to-end diagnostic runs and the service state cannot be verified. Therefore is assumed that this interface provides service if an IP is assigned. Traffic Monitor—A ping test is only performed if there is no traffic during the configured interv Ping Test—A ping is sent at the end of the test interval regardless of whether or not there ha been any traffic during the interval (i.e. if the interface receives ingress traffic regularly, no additional traffic is generated by the gateway). 	
Ping Test IP	Note: Using pings to monitor the interface may accrue data charges. Each individual ping is approximately 98 bytes (196 bytes for ping sent plus ping response). Enter the IP address to ping.	
Address Time Between Pings (seconds)	 Time between individual pings Available range is: 1-20 seconds (Default is 20.) If the first ping fails, the AirLink gateway sends additional pings at the configured interval. If all pings fail, the AirLink gateway declares the service state as "Not Established" and attempts to switch to another interface according to the Interface Priority (see page 76) configuration, and interface availability. If this field is set to 10 (with Number of Pings set to 5) and the test is started and fails, the interface does not provide service for a total of 50 seconds. 	
Number of Pings	Sets the number of consecutive missed pings before the AirLink gateway declares the service state as "Not Established" and attempts to switch to another interface. Available range is: • 1–12 (Default is 5.)	

Reliable Static Routing (RSR)

Reliable Static Routing enables you to force specified traffic to use different routing rules (rather than the default, which is usually cellular) to direct specified traffic (from or to either the AirLink gateway or a connected device) to a designated primary route. If the primary route fails, the specified traffic uses a backup route.

First, you designate specific traffic to use the primary route, based on the destination IP address and subnet mask. A configured Tracking Object Test verifies the validity of the primary route. If the test fails, the backup route is used. The Tracking Object Test continues to run and as soon as it returns a "Pass", traffic is switched back to the primary route.

You can direct the traffic to a network or to an individual host.




Figure 4-22: RSR directed to a destination network




Figure 4-23: RSR directed to a destination IP address (individual host)

In a business continuity application where the router also has a routable IP address from a wireline gateway connection (as shown in Figure 4-24) the IT administrator may prefer to use that lower cost connection for data sourced from the AirLink gateway, such as SNMP or ALMS data. When reliable static routing is configured, the Tracking Object tests the validity of the primary route, and data from the AirLink gateway is transmitted through the primary route (in this example, the wireline connection). If the tracking object determines that the primary route is down, data is transmitted through the backup (in this example, the wireless connection).




Figure 4-24: Private Mode with Reliable Static Routing

Sierra Wireless recommends a Private Mode network (Figure 4-24) as the most reliable configuration to use in a business continuity failover application as defined in the AirLink Hardware User Guide with Reliable Static Routing and Reverse Telnet.

To configure Reliable Static Routing:

- 1. Connect the hardware as shown in Figure 4-24.
- 2. Use the Tracking Object to test the connection:
 - **a.** In ACEmanager, go to WAN/Cellular > Reliable Static Route (RSR).

WWWCefatar 701	21 LAB VIN Security Security 5	station Event Reporting	Serial	Applications	10	4444	
Company and the	194		1000		-		
eneral	in Hallande Date Roads (1124).						
Internation Provide							
Bandoottin Técnitie	110 Training Object					_	
Prog Response.	Therining Objand	Deam of					
-	Total IP Address	0.0.0.0					
lamine	Seal Martina Teal Internal Intercentic	300	Diserver (
MALINE CONTRACTOR	Territ Tremend (Securetile)	6					
	Maximum receipter of feet Halfney	3					
The day 1 Construction							
Minetine .							
Benel							
Intel Configuration							
Married Woman							
states Name Posts							
which Howship							
MAR Configuration							

Figure 4-25: ACEmanager: WAN/Cellular > Reliable Static Route (RSR) > Tracking Object

- **b.** Under Tracking Object, enter the Test IP address, using a host behind the gateway that has a reliable IP address, such as 8.8.8.8.
- c. From the drop-down menu, select Ethernet 1 as the Test Interface.
- **d.** Leave the default values for the Test Interval, Test Timeout, and Maximum number of retries.
- e. In the Tracking Object field, select Enable.
- f. Click Apply.
- **g.** The Tracking Object pings the Test IP address configured in step b. In ACEmanager go to Status > RSR and note the result in the RSR Test Result field.
- 3. Disable Tracking Object.

Note: Configure all the other fields before setting the Enable/Disable Reliable Static Routing field. Once you enable RSR, some fields on this page are not editable.

4. Go to WAN/Cellular > Reliable Static Route (RSR) > Reliable Static Route (RSR).

2mint	WWCellulat	90.71	1.66	3990	Storty	Sector	Location	Trees Separting	Seitel	fastistics	10.	Aton
	terra maner	276.1299							1		(CEE)	
larmet.			TITAL C	in Deta Pa	AL DOTATI							
in er fa	en frank			w Thefe Have				2444				_
-	om theory							(27772).Z				
Toyl	-			e krikarthycza				Atumatic - u				
Column 1			Galler	in for Prima	vivilate			0.0.0.0				
Games	-		Batha	interior.				Column				
(((())	et il Catelligueation		Derry	dian (* Neb	101			0.0.0				
944.35	e I Defige dies		Death	alleri Suttina	(Barr			0000				
-	t		5400	glues				de Training (- 14			
Iberei	6			decent.				10111-04	*****			-
Sale	Automation.		56,000	ort Lines								
-												
Antoin	State State (197	í										
Puly 6	continue (
10000	entipe etco											
-	and garantees											

Figure 4-26: ACEmanager: WAN/Cellular > Reliable Static Route (RSR) > Reliable Static Route (RSR)

- 5. Select the interfaces for the primary and backup routes. The options are:
 - Ethernet 1 (default for primary route)
 - USB
 - Wi-Fi
 - · Cellular (default for backup route)

If you select Ethernet 1, you are given the option to enter a gateway IP address that is used as the next hop for reaching the destination network.¹

Process International	Noral v
WE WE DESIGN FOR THE SECOND	0000

- If the Tracking Object test completed in step 2 was successful, leave this field at the default value (0.0.0.0).
- If the Tracking Object test completed in step 2 failed, enter the gateway IP address in this field.
- 6. Set the Destination IP/Network and Destination Subnet Mask.

To configure the RSR destination as a network for this example, enter:

- 64.100.20.128 in the Destination IP/Network field.
- 255.255.255.252 in the Destination Subnet Mask field.

To configure the RSR destination as an individual host for this example, enter:

- 64.100.20.128 in the Destination IP/Network field.
- 255.255.255.255 in the Destination Subnet Mask field.

^{1.} This applies to both the primary and the Backup interface.

- 7. Set the Tracking Object (Tracking Object 1 or No Tracking Object). Normally, you would select Tracking Object 1 from the drop-down menu.
- **8.** Under Tracking Object, leave the Enable/Disable Tracking Object set at Disable until you finish configuring the other Tracking Object fields.
- **9.** Enter the Test IP address (normally an IP address within the Traffic Selection Criteria Network/Subnet).
- **10.** From the drop-down menu, select the desired Test Interface (normally the same interface as the primary route). Options are:
 - Ethernet 1
 - USB
 - Wi-Fi
 - · Cellular
- **11.** Enter the Test Interval in seconds. This is the interval between Tracking Object Tests. For most applications, the default values for the Test Interval, Test Timeout, and Maximum number of retries should be fine.

If you want to change these values, be aware of the following:

- Selecting a short test interval increases network traffic and may lead to false failures if the network is busy.
- Selecting a long test interval may mean that traffic does not switch to the secondary route quickly enough when the primary route fails.
- The test interval must be greater than the product of Test Timeout × Maximum number of Test Retries.

[Test Interval] > [Test Timeout] × [Maximum number of Retries]

- **12.** Enter the Test Timeout in seconds. This is the time to wait for a response. If this time expires before a response is received, the test attempt fails.
- **13.** Enter the Maximum number of Test Retries. If the first Tracking Object Test fails, this is the number of times the gateway sends additional test messages (without receiving a response) before it declares the test as failed and switches the specified traffic to the backup network.
- **14.** In the Tracking Object field, select Enable.
- 15. In the RSR field, select Enable.

Note: Alway click Apply after enabling or disabling this feature.

Go to Status > WAN/Cellular to check the RSR Test Result and confirm that traffic is being sent through the primary route. If the RSR Test Result field indicates that the Tracking Object Test has failed, validate the connectivity of the primary path. (A test result of Unknown indicates that the test has not yet run.)

Policy Routing

You can use Policy Routing to configure up to 5 policy routing rules used to determine the WAN interface over which outbound traffic is sent. When policy routing is configured, all traffic from the gateway is compared to the rules, in order of priority. If a match is found, the traffic flows over the WAN interface specified by the rule. If no match is found or the selected interface is not available, the active WAN interface is used.

Do not include devices in the policy if they need to access ACEmanager.

You can create rules based on the following components:

- Destination IP address/destination subnet mask
- Destination port
- Source IP address/source subnet mask
- Source port

Any component left with its default value is excluded from the traffic filtering.

Examples:

- If Source IP/subnet mask and Destination IP/subnet mask are configured, traffic from specific LAN hosts with a remote destination matching the configured destination IP and subnet mask uses the policy and is sent over the configured interface. All other traffic uses the current active WAN interface.
- If only the Destination port is configured, traffic from the gateway or from any connected device being sent to the configured remote port uses the policy. All other traffic uses the current active WAN interface.

Note: It is possible to configure a policy routing rule in such a way that you could lose the network connection you are using to configure the gateway with ACEmanager. For example, if you are using ACEmanager through an Ethernet connection to configure the gateway with IP address 192.168.13.100 and you inadvertently configure a rule to send all traffic destined for 192.168.13.100 over the cellular interface, the Ethernet connection you are using to configure the gateway will be lost. If that happens, use a different IP address.

Instan	WANCellular	Dus (19-7)	1.01	VPR	Security	Fervices	Location	Svents Reporting	Dust Server	Applopture	80	Adren	
ut upma	alone series	prai.Mai									-16		
Gaseral	65												
histo	ist Priority		Policy Ro					8-20-10-10-10-10-10-10-10-10-10-10-10-10-10					
Manipi	adh throllo		Palety Rep Network to					Disatis +					
Proph	-		Gatavanty B	Addeda				0000					
Celhater				Total Net				0.0.0					
	43 C		Destination Port					0					
-	et 1 Configuration		Sauce IF Addess Source Euleret Mark					8000					
100.04	el 2 Confignialist		Some Pe	P-C-0000				0					
North	#17		Matu: Failum					9					
therese								Disatile +					
Sec. 1	Collaration		H Pains fi	talo I									
iteres.	¥11	1	14 Painty Roots 2										
la-fadre	- State Roome (RS	1	+) Palacy We	nda 4									
Publica Pl	testra .												
DRIVER C	antiperation.		H Palicy R	oute 5									
PHTM C	anDynamics												

Figure 4-27: ACEmanager: Policy Routing

Field	Description
Policy Route	
Policy Route #	 Configure all the relevant fields for the policy routing rule before you set this field to Enable. Once the rule is enabled, none of the other fields are editable. Options are: Disable (default) Enable
	Note: Always click Apply after enabling or disabling this feature.
Policy Route # Status	This field shows the status of the rule. It only appears when the policy route rule is enabled.
Network Interface	 The interface over which configured traffic exits the gateway once the rule is enabled Options are: Ethernet Cellular Wi-Fi (only available on the Wi-Fi version of the RV55)
Gateway IP Address	This field only appears if Ethernet or Wi-Fi is selected in the Network Interface field. Enter the remote gateway IP address for the selected network. Note: This field is optional.
Destination IP Address	Enter the destination IP address or subnet for traffic that this policy routing rule applies to.
	Note: The destination IP or subnet cannot be the same as the ping test IP used for monitoring the cellular, Ethernet, or Wi-Fi interface. (See Monitoring WAN Connections on page 74.)
Destination Subnet Mask	Enter the destination subnet mask for traffic that this policy routing rule applies to. If a destination IP is used, the subnet mask must be configured. For a single destination, use 255.255.255.255 as the subnet mask.
Destination Port	Enter the destination port for traffic that this policy routing rule applies to.
Source IP Address	Enter the source IP address for traffic that this policy routing rule applies to.
Source Subnet Mask	Enter the source subnet mask for traffic that this policy routing rule applies to. If the source IP is used, the subnet mask must be configured. For a single source, use 255.255.255.255 as the subnet mask.
	Note: /26 to /31 subnet masks are also supported.
Source Port	Enter the source port for traffic that this policy routing rule applies to.
Metric	Set the priority for the policy routing rule. The lower the number the higher the priority. Range is: 0–99
Failover	When failover is enabled, if outbound traffic cannot flow over the configured network interface, it flows over the current active interface.

Dynamic Mobile Network Routing (DMNR)

Note: DMNR is supported only on the Verizon Wireless network. These settings appear only when the RV55 has a Verizon SIM installed.

DMNR provides direct communication between customer sites (for example, between remote subnets and the corporate data center) through a Mobile Network Operator's (MNO's) private network (isolated from Internet traffic).

DMNR creates a tunnel between the home agent on the MNO's private network and the AirLink gateway.

Note: Primary Access Mode DMNR is supported only on Ethernet LANs. DMNR is not supported on Wi-Fi LANs, nor on Wi-Fi bridged to Ethernet configurations (Bridge Wi-Fi to Ethernet).




Figure 4-28: DMNR Configuration

Before configuring DMNR:

- 1. Go to LAN > DHCP/Addressing and ensure that the Host Connection Mode is set to All Hosts Use Private IPs (default).
- 2. Go to LAN > Host Port Routing and set the Primary Gateway field to Disable.
- **3.** Go to LAN > Ethernet > Device IP and change the default address from 192.168.13.x to the same subnet as the DMNR subnet.

- Go to VPN and disable any VPNs you have set up.
 Once DMNR is configured, all traffic from the connected LANs goes through the DMNR tunnel.
- 5. Go to Security > Port Forwarding and set the DMZ Enabled field to Disable.
- **6.** Reboot the gateway.

Note: For the DMNR registration process to complete successfully, there must be a switch, router, or other device physically connected to the AirLink gateway's Ethernet port.

Note: Ensure that the default route of the switch or router points to the AirLink gateway.

To configure DMNR:

1. Go to WAN/Cellular > DMNR Configuration.

WARCellular 1112		ar Deets Reporting Social Applications 10 Advan				
monthly and the		Figure Annual Same				
General						
Independence (Princetta	() Determs Bable Advance Routing					
Contract () and a	DMMCENSIN	Deater +				
Rendwaldh Thombs	Home Address	12.34				
Prog Responses	Home Agard Address	06 174.25.2				
10 Merchanter	11 AP-102 OP1	254				
Odferfer	11-10-042-9227	million				
Courses.	Support F	172 14 1 00				
and the state of the state	Retent 2	172.14.2.84				
BR ber 11a-Hjulaten	Submit 5	172 14 2 08				
W.Sei 2 Configuration	Submit é	0.000				
Munitor	System 5	0.000				
	Salmert 0	0000				
(Berlef)	Toolsen 7	0000				
Sam Configuration	Supret 8	0000				
	Subret 1 NetBack	255.255.255.252				
Heathar	Octored 2 Hattingsh	295 255 255 248				
Butation (Kette: Nowin: (N-144)	Support 3 Herbitants	255 255 255 240				
and the second	Supret 4 Heddawi	0000				
Pakty Reneting.	Summit 5 NetMach	0.0.0				
tation Configuration	Termet t Nelligen	0.050				
Perto Configuration	Subort 7 Netkinss	0.048				
	Tudout 8 Nethols	0.000				
	ErTernen Agent					
	Re-regarded Time (second)	60				
	Roly Time Internal (percenter)	3				
	Mainton Relo Charl	1				
	Regulation Request Ultrans Gecondo	69534				
	Efference Turnelling Agent					
	Maximum Transmission Unit - MTU (Senal)	1404				
	Maximum Segment Star - MICI (bylex)	1390				
	Force Frightendatus	Date of				

Figure 4-29: ACEmanager: WAN/Cellular > DMNR Configuration

Field	Description
Dynamic Mobile Network	< Routing
DMNR Enable	 Enables Dynamic Mobile Network Routing. Options are: Enable Disable (default)^a
	Note: Configure all the other parameters first and then set this field to Enable. When this field is set to Enable, the other fields in this window are read-only.
	Note: Alway click Apply after enabling or disabling this feature.
Home Address	Enter a home address for the AirLink gateway. This address is used to distinguish the AirLink gateway used for DMNR. Use 1.2.3.4 for all gateways configured for DMNR. This field cannot be left blank.
Home Agent Address	IP address of the Home Agent (available from your Mobile Network Operator)
N-MHAE-SPI	NEMO Authentication Extension Security Parameter Index (available from your Mobile Network Operator)
N-MHAE-KEY	NEMO Authentication Extension Key (available from your Mobile Network Operator)
	Note: The value regularly used successfully for gateways on the Verizon Wireless network (subject to change) is VzWNeMo.
Subnet 1–8	Enter the IP addresses for the subnets you want to include in the DMNR network. You can configure up to 8 subnets. 0.0.0.0 indicates that the subnet is not configured.
	Note: If you want to remove a subnet from the DMNR configuration, replace the IP address with 0.0.0.0 rather than deleting it.
Subnet 1–8 NetMask	Enter the subnet masks for the subnets you want to include in the DMNR network. 0.0.0.0 indicates that the subnet mask is not configured.
	Note: If you want to remove a subnet mask from the DMNR configuration, replace the IP address with 0.0.0.0 rather than deleting it.
a If you diaphla DMND when	the DMND turned is up, no disconnect message is capt, resulting in a temperatur mismetch

2. Configure the fields as outlined in the following table.

a. If you disable DMNR when the DMNR tunnel is up, no disconnect message is sent, resulting in a temporary mismatch between the reachability of the (NEMO) subnets on the gateway and the Home Agent.

- **3.** Click the + beside Foreign Agent and Reverse Tunnelling Agent.
- 4. Configure the Foreign Agent and Reverse Tunnelling Agent.

Field	Description
Foreign Agent	
Re-registration Timer (seconds)	 The frequency with which the foreign agent re-registers its subnets If the registration status is Down, the foreign agent re-registers its subnets when the time configured in this field expires. If the registration status is Up, the frequency with which the foreign agent re-registers its subnets is equal to the Registration Response Lifetime minus the value configured in this field. The Registration Response Lifetime is usually equal to the Registration Request Lifetime (seconds). Once you have enabled DMNR, you can confirm the Registration Response Lifetime in ACEmanager. Options are: 1–60 seconds (Default is 60.)
Retry Time Interval (seconds)	 The interval (in seconds) between retries if the re-registration fails. Options are: 1–5 seconds (Default is 5.)
Maximum Retry Count	 Maximum number of re-registration tries allowed. Options are: 0-5 (Default is 3.)
Registration Request Lifetime (seconds)	Enter the desired registration lease time (in seconds). Options are: • 0-65534 seconds (Default is 65534.)
Reverse Tunnelling Ager	it
Maximum Transmission Unit - MTU (bytes)	Use this field to set the tunnel MTU for packets sent over the DMNR/GRE tunnel. Note that the tunnel adds 24 bytes to each packet so the tunnel MTU should be set at least 24 bytes lower than the Mobile Network MTU in order to avoid packet fragmentation. Options are: • 576–1500 (Default is 1404.)
Maximum Segment Size - MSS (bytes)	Use this field to set the TCP maximum segment size for the packets (in bytes). Options are: • 68–1436 (Default is 1350.)
Force Fragmentation	 Allows you to override the "Do not fragment" bit in the incoming packet header and send large packets through the DMNR tunnel Options are: Enable—The "Do not fragment" bit in the incoming packet header is cleared. This setting is useful if you need to send large packets or you do not know the MTU of all the routers in the network path. Disable—The "Do not fragment" bit in the incoming packet header is respected. If the bit is set, packets larger than the MTU are dropped. If the bit is clear, packets larger than the MTU are fragmented and sent. (Default)

5. In the DMNR Enable field, select Enable.

Once DMNR is enabled, the fields are read-only. If you want to change any of the field entries, set the DMNR Enable field to Disable, make the required change, and then set the field to Enable.

Interne WWWCeffular 1911	ri LAN NPN Security Services Local	tee Presta Reporting Serial Application (0) Admin.					
diameters 24200-000	14.00	generating general generating generating					
		Honorendi Hannak Kanna					
Gemanal	NUCLEAR AND ADDRESS OF ADDRESS						
Interlace Princip	Trouble give the transformer	11 Outurns: Rooke Talent Rooking					
	Tanka provine	frame					
Revised# Nexts	Parte Address	1234					
Plug being seiner	Home Agent Address	88 Y/x28.2					
officiari	10.00402-001	294					
- Contract	THAT WE HET	mbae					
General	Baland 1	172 ht 1.68					
INLUCT Configentive 2	Subset 2	17214214					
	Subset 3	172.54.2.68					
diff. Bet 2 Configuration	Tuber 4	0.503					
marker	- Thérait ()	0.243					
1111	Balant's	0008					
(Brair sard)	Dutnet 7	0000					
tuni Lowhpenitori	Summer S	DDD -					
(Double)	Ramet Chelling	201 310 310 313					
	Submet C Freithnen	296.287.395.348					
Haleshie Static Howie (RSN)	Suzzel 3 Fellison Suzzel 4 Hellison	201205200240					
Policy Howling	Theorem 1 to additional	0.008					
BERRY CONTRACTORS	Dutret 0 Felture	0005					
WTW Lawingscolies	Buttered 7 HardWater	0088					
	Butnet 1 Accepted	Yos					
	Butteri 2 Accepted	Yes					
	Thetweet 3 Accepted	Yee					
	The limit a Accepted	Ru I					
	Bulmet 3 Accepted	the second se					
	Shamad & Augusta &	No.					
	Theorem 7 Accepted	The second se					
	Buttool & Accepted	the second se					
	11Parault Apen						
	Registration States	United					
	He regulation Trive Committee	**					
	Rates Tonie Velenial (second)	1					
	Harman Rely Count	1					
	Regulation Request (John Seconds)	68534					
	Reportation Response Lifetime (seconds)						
	Total INVEL and						
	Total RAM [®] received	0					
	TORNER Taxating spec						
	Revenue Termelling Agent Status	Grant					
	Hanthum Transmission Lmd - MTU Italian	1404					
	Harry Tegrari Sta- 411 (total)	1202					
	Toma Flagmentation	Deater					
	Trawlet	0					
	M2 particle						

Figure 4-30: ACEmanager: WAN/Cellular > DMNR Enabled

Once DMNR is enabled, additional status fields appear, as described in the following table.

Field	Description			
Dynamic Mobile Network	Routing			
Subnet 1–8 Accepted	 Confirms that the subnet configuration is accepted. Options displayed are: Yes—The subnet is configured and accepted. No—The subnet is not configured or not accepted. 			
Foreign Agent				
Registration Status	 Foreign agent registration status Options displayed are: Pass—A response has been received from the Home Agent. Fail—No response from the Home Agent. Unknown—Initial state 			
Registration Response Lifetime (seconds)	Shows the length of the current lease time (in seconds).			
Total RRQ sent	Number of Registration Requests sent			
Total RRP received	Number of Registration Responses received			
Reverse Tunnelling Ager	it			
Reverse Tunnelling Agent Status	 DMNR tunnel status This field only appears when DMNR is enabled. Options displayed are: Up—DMNR tunnel is up. Down—DMNR tunnel is down. 			
Force Fragmentation	 Status of the Force Fragmentation field Enabled Disabled For more information, see Force Fragmentation on page 118. 			
TX packets	 Number of packets transmitted The counter is reset when: DMNR is disabled. When the DMNR tunnel (Reverse Tunnelling Agent Status) is down. 			
RX packets	Number of packets received The counter is reset when: DMNR is disabled. When the DMNR tunnel (Reverse Tunnelling Agent Status) is down.			

PNTM Configuration

Note: This feature is available only on Verizon Wireless' private network. These settings appear only when the RV55 has a Verizon SIM installed.

You can use Private Network Traffic Management (PNTM) to tag and prioritize traffic for up to 15 destinations.

For more information on private networking, contact Verizon Wireless.

To configure PNTM:

1. In ACEmanager, go to WAN/Cellular > PNTM Configuration.

man With Collabor Wi		Countries Counter Reporting Sector Applications 10 Addate
ng Andrey (see . 2002) to be	0.46	Taxatta Anna Anna Conn
General	Example and the state	
Interface Priority	(Churche Contribution 4	
Residentify Throatile	Total Contractor P 1	0000
And Research	Dates Mart 1	259,256,256,0
-	55CP 1	Default If
Terrarial	-PHIM Composition 2	
BH Dire 5 Configuration	(i-CHOM Configuration 1)	
IN that 2 Configuration	(Institute Containable &	
Mandar	Tel Content of Content	
(thereas)	101 MIRE Certification 2	
State Configuration	(IS) PH/TM Configuration II	
Abundur	In the second	
Automic States Aurora (4124)	Line PHPM Configuration 7	
Andrew Woosefulg	(H)PHTM Configuration 8	
Intel Configuration	in Phille Configuration 8	
The Configuration		
	(+54)(TM Centpoler H	
	ini-Pathia Configuration 11	
	(Incention of the American State	
	jepPiDi Collgaster D	
	(ISPATIA Deltacolori 14	
	International Statement (St.	

Figure 4-31: ACEmanager: WAN/Cellular > PNTM Configuration

2.	Configure the PNTM	parameters as described in the following table.
----	--------------------	---

Field	Description
PNTM Configuration #	
Status #	Configure all the fields for the PNTM before you set this field to Enable. Once the PNTM is enabled, all the fields are read-only and this field shows the status of the PNTM connection.
	Note: Always click Apply after enabling or disabling this feature.
Destination IP #	Enter the destination IP address.
Subnet Mask #	Enter the destination subnet mask.
DSCP #	Select the desired priority level.

>>> 5: Wi-Fi Configuration

ALEOS provides Wi-Fi configuration capabilities and support for the Wi-Fi model of AirLink RV55 router.

Wi-Fi works in one of the following modes:

- Access Point (LAN) Mode
- Client (WAN) Mode

The configuration options vary, depending on the mode selected.

Note: The Wi-Fi tab appears ONLY on the Wi-Fi model of the AirLink RV55 router.

General

To configure the Wi-Fi settings:

1. In ACEmanager, go to Wi-Fi > General.



Figure 5-1: ACEmanager: Wi-Fi > General

Field	Description
General	
Wi-Fi Modes	Allows you to choose the Wi-Fi mode of operation. For the RV55 with Dual Wi-Fi, the Wi-Fi modes allow you to configure Wi-Fi A only, Wi-Fi B only, or both Wi-Fi A and Wi-Fi B. The options are:
	Wi-Fi Disable—Both Wi-Fi radios are disabled
	• Wi-Fi A Access Point—Wi-Fi A radio is configured as an access point, and Wi-Fi B is disabled
	Wi-Fi A Client—Wi-Fi A radio is configured as a client, and Wi-Fi B is disabled
	• Wi-Fi B Access Point—Wi-Fi B radio is configured as an access point, and Wi-Fi A is disabled
	Wi-Fi B Client—Wi-Fi B radio is configured as a client, and Wi-Fi A is disabled
	 Wi-Fi A Access Point Wi-Fi B Access Point—Wi-Fi A and Wi-Fi B radios are configured as access points
	 Wi-Fi A Client Wi-Fi B Access Point—Wi-Fi A radio is configured as a client, and Wi-Fi B is configured as an access point
	• Wi-Fi A Access Point Wi-Fi B Client—Wi-Fi A radio is configured as an access point, and Wi-Fi B is configured as a client

2. Select the Wi-Fi mode, and click Apply.

The fields available on the General screen depend on the option chosen.

11111	Destroy (Autority)	25.44790					COLUMN STATE	A Designation of Street, or other
							annang pro	All Community Station
ipersonal and								
WITCH	Charte	L1 Genmal						
		VIE PS Modele			We Fi A Dard		•	
mate	A BARRISHI A.P.4	Caranty Circle			United States	100.00		
wite	A Barmole AF 2	Charl Mude			Advente v			
			call Treesed (Seconds)		10			
	A Remote AP 3	Augitable Network						
	A literation (AP) 4	Cannect Statue			Associating			
	A Remote AF 1	11 Martha						
	A Theosetic AP 6	WT Test Internal Care	ondel.		3830			
mild	A Harmonia AP T	AT MONTO Type			Durne	-		
-	2000	AT Fing Test P Add	1986		0.0.0.0			
mana	A Recentle AP 8	Time Balances P	(demands)		20			
wn,	A Termoto AP 9	Humber of Pings			5			
-	A Barnata AP to	Disaine Wi #1955	Shaw Menkineg		Draim 17			
THE R. P. LEWIS CO., NO. 10	WH ROULESS	Threshold		-06				
	WHITE RESIDENT			10				
		WHEN Senator La	on that Tirts (seconds)		3			
	WAT Service file	stored Wait Time directory	diá	10				

Figure 5-2: ACEmanager: Wi-Fi > General > Wi-Fi A Client (WAN) Mode

3. On the General screen, you can configure:

Field	Description
General	
Mode	See Wi-Fi Modes on page 125.
Country Code	To ensure that the gateway conforms to any national restrictions regarding allowable Wi-Fi channels, select the country in which the gateway will be operating. (Default is United States.)
	Note: The default Country Code setting enables the maximum number of Wi-Fi channels. All other Country Code settings configure a subset of channels; they do not enable channels beyond those available in the default setting.
Client Mode	 Appears when Mode is set to Client (WAN). Allows you to choose the connection mode. Options are: Automatic (default)—The WAN connection automatically switches from the mobile broadband network to a Wi-Fi network whenever a configured Wi-Fi Access Point (AP) is within range. Manual—When Manual is selected, click the Connect button to connect to an available access point.
Access Point Rescan Timeout (seconds)	 This field only appears when Client Mode is set to Automatic. Determines how often the AirLink gateway re-scans for a configured Access Point when it is not connected to an Access Point. Options are: 10—3600 seconds (Default is 10) Note: It is best to leave the default value.
Available Network	Identifies the currently associated Wi-Fi network Only one Wi-Fi network is shown, even if additional networks are configured and in range.
Connect Status	 Indicates the gateway's connection status: Not Connected — The gateway is not connected to a Wi-Fi network, and none of the configured networks are available. Connecting — The gateway is connecting to a Wi-Fi network. Connected — The gateway is connected to the Wi-Fi network shown in the Available Network field. Associating — The gateway is searching for a Wi-Fi network in the configured list of APs. Associated — The gateway has found a Wi-Fi network, but is not connected to it.

Field	Description
Monitor	
Test Interval (seconds)	 The amount of time between tests of the Wi-Fi connection. Available range is: 1–15300 seconds (Default is 300) Most applications work well with an interval of 900 to 3600 seconds (15 to 60 minutes).
Monitor Type	 Determines the type of test run on the interface to diagnose its ability to provide end-to-end connectivity for this interface. Options are: Disabled—No end-to-end diagnostic runs and the service state cannot be verified. Therefore it is assumed that this interface provides service if an IP is assigned. Traffic Monitor—A ping test is only performed if there is no traffic during the configured interval. Ping Test—A ping is sent at the end of the test interval regardless of whether or not there has been any traffic during the interval (i.e. if the interface receives ingress traffic regularly, no additional traffic is generated by the gateway).
Ping Test IP	Each individual ping is approximately 98 bytes (196 bytes for ping sent plus ping response).
Address	
Time Between Pings (seconds)	 Time between individual pings Available range is: 1–20 seconds (Default is 20) If the first ping fails, the AirLink gateway sends additional pings at the configured interval. If all pings fail, the AirLink gateway declares the service state as "Not Established" and attempts to switch to another interface according to the Interface Priority (see page 76) configuration, and interface availability. If this field is set to 10 (with Number of Pings set to 5) and the test is started and fails, the interface does not provide service for a total of 50 seconds.
Number of Pings	Sets the number of consecutive missed pings before the AirLink gateway declares the service state as "Not Established" and attempts to switch to another interface. Available range is: • 1–12 (Default is 5)

Field	Description
Enable Wi-Fi RSSI Link Monitoring	 Enables the gateway to monitor RSSI to determine whether to switch the network interface. When the RSSI is consistently below the loss threshold for a qualification period, the network interface switches from Wi-Fi to Cellular. When RSSI is consistently high enough for a qualification period, the network interface switches back from Cellular to Wi-Fi. Options are: Enable (when enabled, additional RSSI settings appear) Disable
Wi-Fi RSSI Loss Threshold	Sets the level at which the Wi-Fi signal is considered to be "lost" (defined as an absolute signal strength in dBm) Available range is: • -10020 dBm (Default is -55 dBm)
Wi-Fi RSSI Hysteresis	Sets the signal level at which the Wi-Fi signal is considered to be "acquired" (defined as a relative level above the Loss Threshold in dB) Available range is: • 0-30 dB (Default is 10 dB)
Wi-Fi Service Loss Wait Time (seconds)	 Sets the timer for the "loss" state. If the signal level is consistently below the Loss Threshold for the Service Loss Wait Time, the link is considered "lost" and the gateway switches network interfaces. Available range is: 0-3600 seconds (Default is 3)
Wi-Fi Service Restored Wait Time (seconds)	 Sets the timer for the "acquired" state. If the signal level is consistently above the Loss Threshold + RSSI Hysteresis for the Service Restored Wait Time, the link is considered "restored" and the gateway resumes using Wi-Fi as the WAN interface. Available range is: 0-3600 seconds (Default is 10)

Access Point (LAN) Mode

In this mode, the AirLink gateway acts as an access point.

To configure Access Point (LAN) mode:

- 1. Select Access Point (LAN) from the drop-down menu in the Mode field.
- 2. Click Apply.
- 3. If you have not already done so, configure the General settings.
- 4. On the left menu, under Access Point (LAN), select General.

	POLYMAN AND A REAL PROPERTY OF A DESCRIPTION OF A DESCRIP	and the second se	
e onimitére (11) étaire	12,40,464	- Arresta	CARL COMPANY (COM
			10
leren al			
	10mm h h Okmette		
to 19 A Accord Parts		22,900	
	Azzana Pant Mula	Bhaine gran 2 a Sita 🖙	
and A General	Channel and Programs	1-1+0.011 (*)	
with a same	fine and the second		
	10WHT 4 Markat		
	Bearan Interval (relife econds)	100	
	2/DB Manual	1	
	102 the second	National and	

Figure 5-3: ACEmanager: Wi-Fi > Access Point (LAN)

Field	Description
General	
Access Point Mode	 The access point mode configures operation for either n/ac or b/g/n. Options are: Enable b/g/n (default) (for 2.4 GHz band) Enable n/ac (for 5 GHz band)
Channel, Frequency, Width	This field only appears when n/ac is selected in the Access Point Mode field. Select from the list of Wi-Fi channel/frequency/width in the 5 GHz band. Each option includes the channel, frequency, and bandwidth. When a wider channel is available, higher data rates are possible. Choosing the 5 GHz band enables faster and more efficient Wi-Fi. The available 5 GHz channels are Ch 36, Ch 40, Ch 44, Ch 48, Ch 149, Ch 153, Ch 157, Ch 161, Ch 165. Default: Ch 44 (5.220 GHz) 20 MHz
	Note: The drop-down list displays the channels that are supported by the RV55. Depending on the regulatory restrictions in the country selected in the Country Code field, some listed channels may not be operational. For more information, see The Wi-Fi channel I selected is not working. on page 563.
	Note: If you select WPA Personal security authentication along with n/ac, note that only 20 MHz channels can be used with WPA Personal. For example, Ch 36 (5.180 GHz) 20 MHz or Ch 165 (5.825 GHz) 20 MHz can be used. See Security Authentication type on page 132.

Field	Description
Channel and Frequency	This field only appears when b/g/n is selected in the Access Point Mode field. Select from the list of Wi-Fi channel/frequency. The available 2.4 GHz channels are 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11 Default: 1– 2.412 GHz.
	Note: The drop-down list displays the channels that are supported by the gateway. Depending on the regulatory restrictions in the country selected in the Country Code field, some listed channels may not be operational For more information, see The Wi-Fi channel I selected is not working. on page 563.
Advanced	
Beacon Interval (milliseconds)	 How frequently the AirLink gateway sends periodic message (beacons) to advertise its availability (in milliseconds) Options are: 1-65535 milliseconds (Default is 100)
DTIM Interval	 The number of beacons the client device can sleep through before waking up to check for messages For example, if the DTIM Interval is set to 3, the client wakes up every third beacon. The higher the setting in the DTIM Interval field, the longer the client device can sleep, and the more battery power the client device can potentially save. However, high DTIM intervals can also reduce throughput to the client. Options are: 1–255 (Default is 1)
802.11w support	 Enable 802.11w operation. The 802.11w standard uses Security Association Query Requests to ensure that clients are legitimate. Options are: Disabled (default) Optional Required When Optional is selected, devices that support 802.11w will be protected, while other devices will still connect to the router. Select Required to force 802.11w operation. The router will reject unsupported clients and access points.

5. On the left menu, select the SSID you want to configure.

14/4444004 - \$152014.210	120 PM	Survey to Courts American
elected	Transmission and an	
O & ALCONE PARE	11WH4488D	
errenden rees.	5960	2R90240015010307
World, R. General	Drivatuari 1950	bam -
WHATE IN	Maximum Clients	10
	Allow Clients to Sea One Another	trans -
	Simply 10-Fi to Etheland	Inste -
	Client Ageout Timer (asconde)	900
	Access Port Note	594
	Security Huttentication Type	(Sum
	11W/DADHCP	
	Hoat P	192 168 17 31
	Starting P	192 168 17 100
	Ending P	102.168.17.250
	OF PARTNER	255 255 255 0
	El WIFT & Caston Portal	
	AT Enable	Dantes
	40 Status	matter .

Figure 5-4: ACEmanager: Wi-Fi > Access Point (LAN) > SSID

SSID #	
SSID	 You can set the SSID or it can be automatically generated (default). The SSID (Service Set Identifier) default value is the same as the AirLink gateway serial number which appears on the label on the bottom of the gateway. You can only configure one SSID. The maximum length for the SSID is 32 characters. It can include: Upper and lower case letters Numbers Spaces Special characters: '-= []\;',./~! @ # \$ % ^ & * ()_+ { } !: "<>? Special characters used must also be supported by connected devices.
Broadcast SSID	Choose whether or not to broadcast the SSID Options are: • Enable (default)—SSID is broadcast • Disable—SSID is hidden (not broadcast) Note: The option to hide the SSID is provided as a convenience and does not enhance security.

Maximum Clients	Indicates the maximum number of concurrent users (clients) supported Options:1 to 10 (Default is 10.)		
Allow Clients to See One Another	Enabled by default. If you do not want clients on the network to be able to see each other, select Disable.		
Bridge Wi-Fi to Ethernet	 This field allows you to create a unified bridge (virtual interface) between the AirLink gateway's Wi-Fi and Ethernet interfaces. Options are: Enable—the Ethernet interface and the Wi-Fi interface share the same subnet. The Wi-Fi devices get their DHCP IP addresses from the Ethernet pool (when Ethernet DHCP is enabled). This allows routing between all LAN devices. Disable—Wi-Fi is a separate LAN subnet from the Ethernet LAN. There is no routing between the two interfaces and their connected devices. (default) 		
Client Ageout Timer (seconds)	 Length of time (in seconds) that a client is inactive before the access point drops the connection to the client. Options are: 60-3600 (Default is 900) 		
Access Point Mode	Displays the access point mode selected in the General settings.		
Security Authentication type	 Select the authentication type. Options are: Open—No authentication is needed when this option is selected. This option allows any user to connect to the AP and is generally not recommended. WEP WPA Personal WPA2 Enterprise 		
DHCP Available only when the Wi-Fi has its own subnet (Bridge Wi-Fi to Ethernet is disabled.)			
Host IP	Displays the AP's IP address. Default: 192.168.17.31		
Starting IP	Displays the beginning IP address to be served. Default: 192.168.17.100		
Ending IP	Displays the ending IP address to be served. Default: 192.168.17.250		
IP Netmask	Displays the subnet IP netmask of the Wi-Fi network. Default: 255.255.255.0		
Captive Portal See Captive Portal.			

Captive Portal

Captive portal enables you to redirect traffic from unauthenticated clients to a specified portal before granting devices full Internet access.

Captive portal has three components:

- Redirecting HTTP traffic
- Providing website authentication
- Managing RADIUS server accounts

Note: Captive Portal replaces the Wi-Fi Landing Page feature from previous versions of ALEOS. After you have configured Captive Portal settings, you can direct traffic to a page hosted by the captive portal solution you are using. Redirecting HTTP traffic is handled by the AirLink gateway. For website authentication and managing RADIUS server accounts, use a solution compatible with Coova Chilli such as Colony Networks or HotspotSystem.

Before you begin:

- 1. Set Wi-Fi mode to Access Point (LAN).
- 2. On the SSID page, ensure Bridge Wi-Fi to Ethernet is set to Disable.

Note: Captive portal is only available when the Wi-Fi mode is set to Access Point (LAN).

To configure the gateway to redirect HTTP traffic:

- **1.** On the Wi-Fi screen, select SSID on the side menu.
- **2.** In the Captive portal section, set the Enable field to "Enable" and configure the other fields in this section as described in the following table.

Captor Decid			
Al employe		Franke (* 19	
er _{States}		Let a	
M Contrat		(Lenin)	
ALCONT Name			
^{NI} UAM Secre			
AL DO Knowle		A (A)	
⁶⁷ 182 ID			
M CARLES SHOULD			
All extends the endedless lender of the		ND2	
⁵¹ RADIUS Gener Accounting For		1813	
AT CALVER Second			
⁶⁷ GNC Auf and sub-arrive da		Invalues.	
I shall MAL address a sheap colline.	el.		
	U.V., 64	haara.	
			$(2\pi M_{\rm e})W_{\rm eff}(r)$
I will di 1961 e a beage a sar wateko			
	Demandering, Packies	an, anndes des grands	
1	-		Arts March

Figure 5-5: ACEmanager: Wi-Fi > SSID > Captive Portal

Note: You can also use AT Commands to configure Captive Portal fields. See Wi-Fi on page 499.

Enable	Enables or disables the captive portal feature Options are: • Enable • Disable (default)
Status	Shows the current status of captive portal Possible statuses include: Idle, Inactive, Disabled, Initializing, Running, Stopped, and Error. This field also displays error messages when there is an error with the configuration of captive portal.
Restart	Use the Restart button to restart the feature with the current configuration.

UAM Server	URL of the portal to which you want to redirect users. This portal must be hosted by a Coova Chilli-compatible server solution.	
UAM Secret	Shared secret between the gateway and the captive portal. You must configure the shared secret on both the gateway and the captive portal side.	
DNS mode	Select the DNS method used to inform the client about the DNS address to use for host name resolution. Options are:	
	 Auto (default)—The Mobile Network Operator's DNS server is used 	
	Any DNS	
	• User Defined—Overrides the default DNS server with the DNS server configured in the DNS IP1 and DNS IP2 fields.	
DNS IP1	This field only appears when DNS mode is set to "User Defined". User defined DNS IP 1	
DNS IP2	This field only appears when DNS mode is set to "User Defined". User defined DNS IP 2	
NAS ID	RADIUS NAS Identifier for each device accessing a portal	
RADIUS Server IP	IP of the computer where the RADIUS server is running	
RADIUS Server Authentication Port	The UDP port used for RADIUS authentication requests Default port is 1812.	
RADIUS Server Accounting Port	The UDP port used for RADIUS accounting requests Default port is 1813.	
RADIUS Secret	Shared secret with the RADIUS server	
MAC Authentication Mode	 Select the MAC authentication mode. Options are: Local (default)—Allows you to enter a list of authorized MAC addresses Server—Allows you to authorize the host from RADIUS (outside of ALEOS) 	
List of MAC addresses always authorized	This field is only visible when the MAC authentication mode is set to Local. List the MAC address of devices that do not require authentication for Internet access. The maximum number of entries is 10.	
List of URLs always accessible	List the URLs that are accessible prior to authentication, using the Domain names, IP addresses, or network segments. The maximum number of entries is 10.	

3. Click Restart or reboot the gateway.

After a non-authenticated client connects to the access point and attempts to access a Web page (on port 80), the request is directed to the captive portal. After the client is authenticated by the captive portal, the client should be able to access the Internet.

WEP

When you choose WEP in the Wi-Fi Security Authentication Type field, an additional section appears:

(WTF	
Keylength	G1 bill key (conversion from passishnass) — M
WEP Passphrase	******
WEP Key	c235485511

Figure 5-6: ACEmanager: Wi-Fi > Access Point WEP section

Note: ALEOS provides WEP only for backward compatibility with older equipment. WEP is an unsecured authentication type, and is deprecated by the 802.11 standard. Sierra Wireless strongly discourages the use of WEP for the same reasons as TKIP use is discouraged (see page 136).

Field	Description
Key length	Length of the security key to use Options are: 64 bit key (generated from passphrase) (default) 128 bit key (generated from passphrase) Custom Key—64 or 128 bit key (user specifies 5 or 10 hex characters)
WEP Passphrase	 WEP passphrase to be used 8–26 alphanumeric ASCII characters This field does not appear if the Custom Key option is selected in the Key length field.
WEP Key	 Displays the WEP key in hex characters The WEP Key is generated from the WEP Passphrase when you select 64-bit key or 128-bit key in the Key length field*. This is the Key required by AP clients to connect to the gateway. To generate the WEP Key: Set the Key length. Enter the WEP Passphrase. Click Apply. Reboot the gateway. The current WEP Key is displayed in ACEmanager only after rebooting. * If you selected Custom Key in the Key length field, enter the desired custom key in hex characters only (5–10 hex characters). When logging in with a Custom Key, you can enter the hex characters or the ASCII equivalent. For example, if the custom key is 68656c6c6f, you can log in using 68656c6c6f or the ASCII equivalent (hello).

WPA/WPA2 Personal

If WPA Personal or WPA2 Personal are selected for the Wi-Fi Security Authentication Type field, a WPA/WPA2 Personal section appears.

A MEAN AND ALL MEANING		
Program.	4. S. S.	
WKA Kanagi da wa		

Figure 5-7: ACEmanager: Wi-Fi > Access Point WPA/WPA2 security options

Field	Description
WPA/WPA2 Personal	
Wi-Fi Encryption	 Specify the encryption type for WPA or WPA2 authentication. Options are: AES (default) TKIP
	Note: Do not select TKIP when 802.11w support is Optional or Required. TKIP is a depre- cated Wi-Fi security protocol and is not supported with 802.11w Protected Management Frames.
WPA Passphrase	 Specify the WPA Passphrase AP clients use to connect to the gateway. Default: None. The WPA Passphrase must be 8 to 64 characters long. It can include: Upper and lower case letters Numbers Spaces Special characters: '-=[]\;',./~!@#\$%^&*()_+{} : "<>? Special characters used must also be supported by connected devices. The WPA Passphrase is case-sensitive. If your password is not at least 8 characters long, a warning message appears when you click Apply.

WPA2 Enterprise

If WPA2 Enterprise is selected for the Wi-Fi Security Authentication Type field, a WPA2 Enterprise section appears.

Network administrators can use WPA2 Enterprise to design network Authentication around their specific needs and policies, and to change or revoke access rights for individual users. WPA2 Enterprise uses RADIUS authentication.

Никаз разлаго		
RADUS Automication Server IP Address		
RADUS Autoentration Server Port	1812	
Shared Secret		
RADUS Accounting Server IP Address		
PADUS Accounting Server Port	1813	
Shared Secret		

Figure 5-8: ACEmanager: Wi-Fi > Access Point WPA2 Enterprise security options

Field	Description	
WPA/WPA2 Enterprise		
RADIUS Authentication Server IP Address	IP address for the RADIUS Authentication Server	
RADIUS Authentication Server Port	RADIUS Authentication Server port number Default is 1812	
Shared Secret	The shared secret is an ASCII string, typically up to 64 characters	
RADIUS Accounting Server IP Address	IP address for the RADIUS Accounting Server	
RADIUS Accounting Server Port	RADIUS Accounting Server port number Default is 1812	
Shared Secret	The shared secret is an ASCII string, typically up to 64 characters	

Client (WAN) Mode

In Client Mode, the AirLink gateway acts as a Wi-Fi client and can connect to an access point. While connected, the Wi-Fi or WAN link is primarily an uplink for the AirLink gateway and all connected devices. All outbound traffic is routed over the Wi-Fi connection instead of the mobile broadband connection.

Client Mode has been tested with the top 5 WLAN Access Point vendors: Cisco[®], Aruba Networks[®], Motorola[™], HP[®], and NETGEAR[®].

You can configure up to 10 Access Points for each AirLink gateway. Only one Access Point is used at a time for the client connection. Having additional APs configured allows for portability. Since the AirLink gateway generally runs unattended, it does not do a broadcast discovery to display all available APs in the area. You need to know the specific configuration details for the APs you want to configure in ACEmanager.

Select Client Mode in the Wi-Fi Mode field, and in the left menu, select Client (WAN).

To configure Client (WAN) mode:

- 1. Select Client (WAN) from the drop-down menu in the Mode field.
- 2. Click Apply.
- 3. if you have not already done so, configure the General settings.
- 4. On the left menu, select Client (WAN), and select the desired Remote AP from the list in the left menu.

Note: Access Points that have already been configured have a dot beside them.

diamintes 300012100	17 PM	Description (Section	NAMES OF TAXABLE
		Natural Victoria Vi	Instand Barrier
General	The second se		
ALL & Carel	() (200-PL & Barriste AP 1		
	Rende 100 1		
THE PLAN BROWN AND A	2 4GHz Phetweece	At 3 stills Charles	
WORLD, Research AP 2	SGH: Preference	AR EDWA Charloste (*	
	Security Authoritication Type	Test v	
Worklid Bernards AP 2	#22 five support	Syland +	
III.71 A Network AP 4			
multi A Income AP 3			
muri A burnahi AP b			
multi A Increase AP 1			
Intel A Remarks AP 3			
Intel A Remarks AP 8			
20.4) A Hample AP 10			

Figure 5-9: ACEmanager: Wi-Fi Client (WAN) Remote AP configuration

Field	Description	
Remote AP 1, Remo	te AP 2 Remote AP 10	
Remote SSID(#)	 Use this field to configure the remote access point you want the AirLink gateway to be able to scan for and connect to. The gateway scans for available APs in the order they are configured in ACEmanager, so you may want to configure the most commonly used AP as Remote Wi-Fi AP 1. For the Remote AP SSID, the gateway supports: Upper and lower case letters Numbers Spaces Special characters: ' - = []\; ', . /~! @ # \$ % ^ & * ()_ + {} : "< > ? Special characters used must also be supported by connected devices. The SSID is case-sensitive. 	
	Note: The configured parameters for the remote AP must be accurate. The AirLink gateway does not prompt if there is a mismatch.	
2.4GHz Preference	 Select the 2.4GHz channels that the gateway uses for Wi-Fi. The RV55 will scan and associate to the Access Points that are operating on the specified channels and frequencies. The options are: Not Preferred—The RV55 will only connect to an Access Point operating on 2.4 GHz channels if an Access Point operating on 5GHz channels is not available. All 2.4GHz Channels Specific 2.4GHz Channels 	
	Note: Setting both 2.4GHz and 5GHz Preference fields to Not Preferred will create an Invalid Configuration file. The Wi-Fi Client will fail to associate to a Remote Access Point.	
Specific 2.4GHz Channels	When Specific 2.4GHz Channels is selected under 2.4GHz Preferences, the Specific 2.4GHz Channels field appears. 24CHt Preference 24CHt Preference	

Field	Description	
5GHz Preference	 Preference Select the 5GHz channels that the gateway uses for Wi-Fi. The RV55 will associate to the Access Points that are operating on the specified channel frequencies. The options are: Not Preferred—The RV55 will only connect to an Access Point oper channels if an Access Point operating on 2.4GHz channels is not ave All 5GHz Channels Specific 5GHz Channels Note: Setting both 2.4GHz and 5GHz Preference fields to Not Preferred Invalid Configuration file. The Wi-Fi Client will fail to associate to a Remover. 	
Specific 5GHz Channels	When Specific 5GHz Channels is selec Channels field appears.	ted under 5GHz Preferences, the Specific 5GHz
	SOH: Proference	Specific SONL Charles 🕓
	Specific 500 to Chennelis	
	Enter the desired 5GHz channels as a c	comma-delimited list; for example, 36,40,149.
Security Authentication Type	or channels that are excluded by your of effect. See also The Wi-Fi channel I set Use this field to configure the authentica • Open—No authentication is neede Open (no authentication) AP is gen	ation type used by the access point. Options are:
		condary authentication through a landing page, the . This type of AP may not allow full functionality for e AirLink gateway.
802.11w support	 Enable 802.11w operation. The 802.11w standard uses Security Association Query Requests to ensure that clients are legitimate. Options are: Disabled (default) Optional Required When Optional is selected, devices that support 802.11w will be protected, while other devices will still connect to the router. Select Required to force 802.11w operation. The router will reject unsupported clients an access points. 	

Field	Description				
WEP	Security Automatication Type: WDT + Client Prevent of				
	 Client Password—Enter a WEP password. The WEP password must be 8 to 125 characters long. It can include: Upper and lower case letters Numbers Spaces Special characters: '-= []\; ', . /~! @ #\$ % ^ & * ()_+ {} !: "<> ? Special characters used must also be supported by connected devices. The WEP password is case-sensitive. If your password is not at least 8 characters long, a warning message appears when you click Apply. 				
	Enter a valid password, click an empty area on the page to remove the warning, and then click Apply again.				
WPA/WPA2 Personal	Social By Avilian Type WTW/WTAC Tentonal III. Old n. Pulsaved				
	 Client Password—Enter a WPA password. The WPA password must be 8 to 125 characters long. It can include: Upper and lower case letters Numbers Spaces Special characters: '-= []\;',./~! @ #\$%^&*()_+{}]:"<>? Special characters used must also be supported by connected devices. The WPA password is case-sensitive. If your password is not at least 8 characters long, a warning message appears when you click Apply. 				
	Enter a valid password, click an empty area on the page to remove the warning, and then click Apply again.				
WPA2 Enterprise					
Authentication Type	 Select either: EAP-TLS—Extensible Authentication Protocol-Transport Layer Security PEAP—Protected Extensible Authentication Protocol 				

Field	Description					
Authentication Type	If you select EAP-TLS, the following fields appear:					
	1 AV2 to A threadening					
	Adhenington (page 1977 Stor)					
	Consideration Chatters and International					
	Contraction Item On taxia					
	CONTRACTOR CONTRACTOR					
	VINCENTRY VINCENT					
	A multiple file AL di Plade Ke					
	Cheral Frends Ray Francisco 1					
	Client EAP Identity—Enter the Extensible Authentication Protocol (EAP) Identity. The Client EAP Identity is an ASCII string.					
	 Client CA Certificate—Click the Client CA Certification button, navigate to the certificate file and click Upload file. 					
	Currently Installed Client CA Certificate—Status field shows the current Client CA Certificate file name.					
	 Client Certificate—Click the Client Certification button, navigate to the certificate file and click Upload file. 					
	 Currently Installed Client Certificate—Status field shows the current Client Certificate file name. 					
	 Client Private Key—Click the Client Private Key button, navigate to the desired file and click Upload file. 					
	Currently Installed Client Private Key—Status field shows the current Client Private Ke					
	 Client Private Key Password—Enter the Private Key password. The Client Private Key Password is an ASCII string. 					
	Note: The certificate and certificate key must meet the following conditions:					
	• The certificate must be an X.509 certificate					
	 The certificate and the private key must be in .pem format, and they must be in separate files. 					
	• There is no limit to the size of the private key, but the larger the key, the more the performance is affected. Sierra Wireless recommends that the key does not exceed 2048 bits.					
	Note: The RV55 supports pre-defined cipher suites using 128-bit cipher algorithms.					

Field	Description					
	If you select PEAP, the following fields appear:					
	(2) 2 to 4 the dealers					
	Aum energies Hoe Access Form Ontertain Classifier Defension Classifier Defension Classifier Control (Control (Control (Control)))	NAR Record M No MAR In the te				
	 Access Point Certificate—Select whether to use PEAP Authentication with or without a Client CA Certificate. By default, using the certificate is required (and the Client CA Certificate must be installed). 					
	Note: If you select Not Used and clic configuration may put your system at	k Apply, you must accept a warning that this risk.				
	Client EAP Identity—Enter the Extensible Authentication Protocol (EAP) Identity. The Client EAP Identity is an ASCII string.					
	Client EAP Password—Enter the EA	Client EAP Password—Enter the EAP password.				
	• Client CA Certificate—Click the Client CA Certification button, navigate to the icate file and click Upload file.					
	Currently Installed Client CA Certificate—Status field shows the current Client CA Certificate file name.					
	Note: The certificate and certificate key n The certificate must be an X.509 cert	-				
	 The certificate and the private key must be in .pem format, and they must be in separate files. 					
		vate key, but the larger the key, the more the ess recommends that the key does not exceed				
	Note: The RV55 supports pre-defined cip	her suites using 128-bit cipher algorithms.				

>> 6: LAN Configuration

You can use the AirLink RV55 to route data between one or more connected devices and the Internet via the mobile network.

Port Use

Applications running on a LAN client such as a router or laptop must use different ports from those used by ALEOS features on the AirLink RV55. For a list of inbound ports used by ALEOS, see Inbound Ports Used by ALEOS on page 566.

DHCP/Addressing

This page governs the DHCP and addressing for all interfaces.

The LAN Address Summary is a display of the IP addresses assigned to interfaces on their respective configuration pages. To change the addressing for the Ethernet interface, go to the Ethernet side menu. To change the addressing for the USBnet interface, go to the USB side menu.

The DHCP/Addressing page includes the following sections:

- General
- IP Passthrough
- DHCP Reservation List
- DHCP Server Options
- DHCP Client Options
- DHCP Vendor Specific Options

General

inter WAADCellulat (WLF)	LAN VITH	Security	Services 🖉 Linatio	n 👔 Eonath Hasp	orting Sector	Applications	1/0 Afmin
manuerre 193993293976					1	Caracter Anna	(Nation) Carl
DHCP/W&trysung	(F3/General						
Ethernet	The second second						
	Lease Timer the	aeda)		8640	- DC		
	LAN Address Spermary						
058	1 AM Addition of Ser	THATY					
V15	Contract and second and second		Constant March	Advance Milde	THE DESCRIPTION	Thereas ID	Taxan ID
	Interface	Device IP	Sabeet Hask	Access WAN	DHCP Mode	Starting IP	Ending IP
	Contract and second and second		Scinet Hask 201.201.208.8	Addates WWA	DHCP Mode Auto	Starting IP 83.8.3	Ending IP

Figure 6-1: ACEmanager: LAN > DHCP/Addressing > General

Field	Description		
General			
Lease Timer (seconds)	 The amount of time the DHCP client is given for the use of the IP address (in seconds) Options are: 120-4294967295—Number of seconds the IP address is leased for. If you want to set the value to "infinity", enter 4294967295 (equivalent to 136 years). The actual maximum value depends on the maximum supported by your DHCP client. The default lease time is 86400 seconds (24 hours). 		
LAN Address Summa	ary		
	nich have been enabled. By default, only the Ethernet and USBNET Interfaces are enabled. LAN if configured and Wi-Fi if it is configured as Access Point (LAN) and not bridged to		
Interface	The physical interface port or VLAN ID If Wi-Fi is bridged to Ethernet, "Ethernet/Wi-Fi" is displayed.		
Device IP	The IP address of the AirLink gateway for the specified interface port. By default, this is set to 192.168.13.31 for Ethernet, 192.168.17.31 for Wi-Fi, and 192.168.14.31 for USB/net.		
Subnet Mask	Subnet mask indicates the range of device IP addresses that can be reached directly. Changing this limits or expands the number of clients that can connect to the AirLink gateway. The default of 255.255.255.0 means that 253 IP addresses can connect to the AirLink gateway. Uses 192.168.13. as the first three octets of the IP address if the gateway IP is 192.168.13.31.		
	Note: Do not use the same IP addresses/subnet mask for WAN and LAN connections. For example, you cannot have 192.168.13.0/24 as a LAN subnet if the WAN the gateway is connecting to is using 192.168.13.0/24.		
Access WAN	Appears if the interface is configured to allow connected device(s) access to the Internet		
	Note: Internet access cannot be disabled for Ethernet or Wi-Fi hosts.		
DHCP Mode	Indicates whether or not the interface has a DHCP server enabled to provide dynamically allocated IP addresses provided to connected devices		
	Note: The DHCP server can only be disabled for Ethernet and VLAN.		
Starting IP	Ethernet DHCP pool starting IP address (DHCP low address)		
Ending IP	The ending IP for the interface (DHCP high address). If the starting and ending IP are the same, there is a single address in the pool and only one connected device receives an IP address from the DHCP server for that interface. Some interfaces, such as USB, can only have a single device connection. For others, statically assigned IP addresses in the same subnet, but outside of the DHCP pool, can still connect and use the gateway in the same way as a DHCP connected device.		

IP Passthrough

[]IP Passihrough	
All IP Passihrough	Elicited 9
IP Passihrough Node	MAC Address
IP Passihrough Ethemet Port	Part w
111 Socihinungh Submei Marek	255 255 255 0
IP Pasisthrough Default Cateway (Optional)	0.0.0.0
Reset Host Interface	bruite v
NAC Address	00/00/00/00/00/00

Figure 6-2: ACEmanager: LAN > DHCP/Addressing > IP Passthrough

Field	Description
IP Passthrough In IP Passthrough mode, the	AirLink gateway passes the WAN IP address to the selected LAN interface or device.
	y available on the WAN cellular interface. In order for IP Passthrough to work, and for rded to the LAN interface or device, the setting DMZ Host Enabled must be set to Automatic.
IP Passthrough	 Select the interface that will be used for IP passthrough. Options are: Disabled—Private IP addresses are used (default) Ethernet—Ethernet interface is used for IP passthrough USB—USB interface is used for IP passthrough Serial DUN—Serial DUN interface is used for IP passthrough
IP Passthrough Mode	 Choose the IP passthrough mode. Options are: First Host—The first connected device gets the WAN IP. Subsequent devices do not receive an IP address. (default) MAC Address—This option is available for the Ethernet interface only. The device with the configured MAC address gets the WAN IP. Subsequent devices use the private IP address corresponding to the interface configured in IP Passthrough.
IP Passthrough Subnet Mask	Enter the IP passthrough subnet mask. This field does not appear when IP Passthrough is set to Serial DUN. The default setting is 255.255.25.0
IP Passthrough Default Gateway (Optional)	Configure the address of the IP passthrough default gateway. The default setting is 0.0.0.0
Reset Host Interface	 When this option is enabled, the host interface is reset when the device gets a new WAN IP. Options are: Enable (default) Disable
MAC Address	When IP Passthrough Mode is set to MAC Address, enter the MAC address of the device that you want to receive the WAN IP.

DHCP Reservation List

IP Address
Add None

Figure 6-3: ACEmanager: LAN > DHCP/Addressing > DHCP Reservation List

Field	Description		
DHCP Reservation Li	st		
Reservation List	 Use this list to reserve IP addresses for up to 20 connected devices, based on their MAC addresses. This feature is useful if you have multiple connected devices behind the AirLink gateway where you need to use DHCP addressing and also need to assign a specific IP addresses to some devices. To reserve an IP address: Click Add More. Complete the MAC Address and IP Address fields. The device does not need to be connected when you complete these fields. Click Apply. To delete a reserved IP address, click the X beside the reserved IP address. <i>Note:</i> A reserved IP address must be from a private subnet configured for the applicable interface. For example, 192.168.13.10 for an Ethernet connected device. When Host Connection Mode is set to Public for a particular interface, the DHCP 		
	 reservations for that interface are overridden. Any device connected to the specified interface (and port for Ethernet) receives the public IP. Any other device connected to the same interface type does not receive any IP from DHCP. The reservation list supports Ethernet and Wi-Fi hosts. 		
	If Wi-Fi Bridge to Ethernet mode is enabled, you can reserve an IP address for a Wi-Fi connected device in the Ethernet range only.		
MAC Address	Enter the MAC address of the device you want to reserve an IP address for.		
IP Address	Enter the IP address you want to reserve for the device.		

DHCP Server Options

TU in Use					
		1500			
phone	Interface	Server Option Co	ade	Option Value	

Figure 6-4: ACEmanager: LAN > DHCP/Addressing > DHCP Server Options

Field	Description		
DHCP Server Options Enables IT Administrators to	configure up to 10 DHCP options, allowing you to push DHCP options to connected devices.		
MTU Source	 Use this field to select where the Maximum Transmit Unit (MTU) value for LAN and Wi-Fi clients is obtained. Options are: Auto—The MTU value distributed to clients is obtained from the radio module. This option ensures that all interfaces use the same MTU as the radio module. (default) When Auto is selected in this field, the MTU value configured for Option Code 026 Interface MTU is ignored. Manual—The MTU value configured for the Server Option Code 026 Interface MTU is distributed to clients. Note: If you are using a new SIM card for the first time, Auto MTU takes effect after the second reboot.		
MTU in Use	This field only appears when MTU Source is set to Auto. Displays the Maximum Transmit Unit (MTU) value (from the radio module) being distributed to clients		
Interface	Select the interface to use: All (default) Ethernet USB Wi-Fi (only available for RV55 with Wi-Fi)		
	Note: VLAN hosts only receive the DHCP options when the Interface is set to All.		

Field	Description
Server Option Code	Choose from the options in the drop-down menu. For a list of supported Option Codes, see Table 6-1. For additional information on the option codes, refer to the Internet Engineering Task Force (IETF) memorandum on Internet Protocols and Standards, RFC 2131.
	Note: When MTU Source is set to Auto, the MTU value configured for Server Option Code 026 Interface MTU is ignored.
Option Value	The format for the option value depends on the Server Option Code selected, as formats must conform with RFC 2132. For a list of accepted formats for each of the supported DHCP Option Codes, see Table 6-1. Use a comma to separate multiple values.

Table 6-1: Supported DHCP Options

DHCP Option	Type of entry	Accepted values (if applicable)
002 Time Offset	32-bit unsigned integer	-43200-43200 ^a
003 Router	1 or more IP addresses	
006 Domain Name Server	1 or more IP addresses	
007 Log Server	1 or more IP addresses	
009 LPR Server	1 or more IP addresses	
012 Hostname	ASCII string	No spaces (_ and - are valid)
013 Boot File Size	16-bit unsigned integer	1-65535
015 Domain Name	Fully Qualified Domain Name (FQDN)	
016 Swap Server	1 or more IP addresses	
017 Root Path	ASCII string	
018 Extension Path	ASCII string	
019 IP Forward Enable/Disable	Single octet Boolean	0 (Disable) or 1 (Enable)
020 Non-Local Source Routing	Single octet Boolean	0 (Disable) or 1 (Enable)
021 Policy Filter	1 or more pairs of IP addresses or IP address/mask pairs	
022 Max Datagram Reassembly Size	16-bit unsigned integer	576-65535
023 IP TTL	8-bit unsigned integer	1–255
026 Interface MTU	16-bit unsigned integer	68–65535 (Default is 1500.)
027 All Subnets Are Local	Single octet Boolean	0 (Disable) or 1 (Enable)

Table	6-1:	Supported	DHCP	Options
IUNIC	• • •	oupportou	DIIOI	options

DHCP Option	Type of entry	Accepted values (if applicable)
031 Perform Router Discovery	Single octet Boolean	0 (Disable) or 1 (Enable)
032 Router Solicitation Address	Single IP address	
034 Trailer Encapsulation	Single octet Boolean	0 (Disable) or 1 (Enable)
035 ARP Timeout	32-bit unsigned integer	6–65535
036 Ethernet Encapsulation	Single octet Boolean	0 (Disable) or 1 (Enable)
037 TCP TTL	8-bit unsigned integer	1–255
038 TCP Keepalive	32-bit unsigned integer	0-65535
040 NIS Domain	ASCII string	Domain name
041 NIS Server	Single IP address	
042 NTP Server	Single IP address	
044 NetBIOS Name Server	1 or more IP addresses	
045 NetBIOS Datagram Distribution Server	1 or more IP addresses	
046 NetBIOS Node Type	8-bit unsigned integer	1, 2, 4, or 8
047 NetBIOS Scope	ASCII string	
048 X Windows System Font Server	1 or more IP addresses	
049 X Windows System Display Manager	1 or more IP addresses	
064 NIS+ Domain	Domain name	
065 NIS+ Server	Single IP address	
066 TFTP Server	ASCII string or IP address	Name, domain name, or IP address
067 Bootfile Name	ASCII string	Name
068 Mobile IP Home	1 or more IP addresses	
069 SMTP Server	1 or more IP addresses	
070 POP3 Server	1 or more IP addresses	
071 NNTP Server	1 or more IP addresses	
074 IRC Server	1 or more IP addresses	

a. The time offset is entered as seconds. See Table 6-2 for a list of hour/second conversions.

Hour	Seconds	Hour	Seconds
0	0		
1	3600	-1	-3600
2	7200	-2	-7200
3	10800	-3	- 10800
4	14400	-4	- 14400
5	18000	-5	- 18000
6	21600	-6	-21600
7	25200	-7	-25200
8	28800	-8	-28800
9	32400	-9	-32400
10	36000	-10	-36000
11	39600	-11	-39600
12	43200	-12	-43200

Table 6-2: Time Offset Hour/Second conversions

DHCP Client Options

DECPOSe	TOPONS		
ptions			
	Intertace	Chent Option Code	Option Wiles
_	A V	012 Hostname - M	

Figure 6-5: ACEmanager: LAN > DHCP/Addressing > DHCP Client Options

Field	Description
DHCP Client Options Enables IT Administrators to	push DHCP Option 12 to connected devices.
Interface	 Select the interface to use: All (default) Ethernet Wi-Fi (only available for RV55 with Wi-Fi) Note: VLAN hosts only receive the DHCP options when the Interface is set to All.

Field	Description
Client Option Code	Option 12 Hostname is the only option available.
Option Value	Text string with no spaces (_ and - are valid).

DHCP Vendor Specific Options

endor Spe	ectfic Options			
	Vendor Classe	Vendor Option Code	Vendor Option Length	Vendor Option Value
< .			undefined ~	

Figure 6-6: ACEmanager: LAN > DHCP/Addressing > DHCP Vendor Specific Options

Field	Description
DHCP Vendor Specific Enables IT Administrators to	Options configure up to 5 vendor-specific options
Vendor Class	Enter the vendor class
Vendor Option Code	Enter the vendor option code. Possible entries are: • 0-255
Vendor Option Length	 This field allows you to specify the DHCP vendor specific option length in order to ensure that the DHCP datagram is correctly formatted for the DHCP client. Options are: Undefined—Use this setting for IP addresses and strings (default) 1 byte—Use for decimal values of 255 or less 2 bytes—Use for decimal values between 256 and 65535 4 bytes—Use for decimal values greater than 65535 <i>Note: If the size used for the data is not correct, the option is ignored by the client.</i>
Vendor Option Value	 Enter the vendor option value in one of the following formats: Dotted-quad IPv4 address Decimal number Colon-separated hex digits Text string Use a comma to separate multiple values.

Ethernet

The AirLink RV55 is equipped with an Ethernet port that can be enabled or disabled as needed. When the port is disabled, the connected device cannot connect via Ethernet, and ARP queries do not receive responses on the port.

a spinistion (1773) is a constant			1 Sector	ere fap: totel (in
DHCP3A-bitraming	() [Genul			
Barnel	# Devic P		192.998 13.31	
158	# Stating IF		192 168 13 100	
Link WKR Covernage	Entry P		162 168 13 155	
	CHOP network mask		255 255 255 0	
haat Poet Heading	AL SHOP Made		Adds w	
Globar DH3:	Ethomat Port Configuration			
MMGE	Port Number	Stars	Post Minde	Link Setting
	Pat 1	21404	SAN (#	(64) (m)
A.A.M.				
Assa:				
tost konstace Wetchdug				

Figure 6-7: ACEmanager: LAN > Ethernet

Field	Description
General	
Device IP	The Ethernet IP address of the AirLink gateway. By default this is set to 192.168.13.31.
Starting IP	Ethernet DHCP pool starting IP address Default is 192.168.13.100.
	Note: If only one computer or device is connected directly to the Ethernet port, this is the IP address it is assigned.
Ending IP	The ending IP address for the Ethernet interface DHCP pool Default is 192.168.13.150.
DHCP network mask	The Netmask given to any Ethernet DHCP client Default is 255.255.255.0.

ALEOS 4.14.0 Software Configuration User Guide for AirLink RV55

Field	Description
DHCP Mode	 Determines how DHCP operates on the Ethernet interface Options are: Server—The AirLink gateway acts as a DHCP server for all Ethernet connections. Disable—The AirLink gateway acts as neither a DHCP server or client. All devices connected to the AirLink gateway must have a static LAN IP or use PPPoE. Auto—When the gateway is powered on or reboots, it attempts to determine if a DHCP server is present on the Ethernet network. If a DHCP server is found, the gateway obtains an IP address and it can communicate with AirLink Management Service (ALMS). If a DHCP server is not found, the gateway becomes a DHCP server. (default) When using Auto DHCP, set the Ethernet port as Auto or LAN (not WAN). See Mode on page 155. For a full-featured auto DHCP, see Ethernet WAN Auto Mode. Most of the time you can leave this field set to the default value.
Port Number	Ethernet Port number The number of Ethernet ports available varies depending on the gateway or router model.
State	State of the Ethernet Port (Enable or Disable)
	Note: When the port is disabled, the device ignores any physical connection to the Ethernet port.

Field	Description
Mode	 You can set the following modes on the Ethernet port: Auto—When the gateway is powered on or reboots, it attempts to determine if a DHCP server is present on the Ethernet network. If a DHCP server is found, the gateway obtains an IP address from the DHCP server. If no DHCP server is found, the port acts as a bridged LAN connection. LAN—The Ethernet port acts as a LAN connection. WAN— The port is used as a WAN connection. Any security settings configured on the gateway, such as DMZ, IP filters, and port forwarding rules apply to this WAN connection.
Link Setting	Configures the Ethernet port speed and duplex setting Most of the time you can leave the default setting and the device you are connecting automatically negotiates the speed and duplex setting with the AirLink gateway. However, if the connected device has a fixed setting, use this field to change the AirLink gateway setting to match that of the connected device. Note: If you select 100 Mb Full Duplex or 10 Mb Full Duplex for the gateway, ensure that the same speed is selected on the connected device.
	 The options are: Auto—(default) The gateway auto-negotiates with the connected device to use the fastest speed possible—10 Mb, 100 Mb, or 1000 Mb. For best results, ensure that the connected device is also set to auto-negotiation. If your highest priority is power saving, select one of the 100 Mb or 10 Mb settings. 100 Mb Full Duplex 100 Mb Half Duplex 10 Mb Full Duplex 10 Mb Half Duplex You can view the current speed and duplex setting on the Status > Ethernet page. See page 51.

RADIUS Framed Route

If you have a private APN that is authenticated with a unique user name and password through a RADIUS authentication server, Framed Route enables you to associate a pool of IP address (for example a /24 subnet) with that user name, effectively creating a remote branch of a private corporate network. Refer to the RADIUS specifications for more details.

For an AirLink gateway to work effectively with Framed Route, set the following two fields on the LAN > Ethernet screen to "Enable":

- Accept Unsolicited Traffic—Enabling this field allows a device on the corporate network to dial out to a device connected on the LAN side of the AirLink gateway.
- Turn Off NAT—Enabling this field allows traffic from the LAN side of the AirLink gateway to flow back to the corporate network.

USB

The AirLink gateway is equipped with a USB port that increases the methods by which you can send and receive data from a connected computer. You can set up the USB port to work as either a virtual Ethernet port or a virtual serial port, or you can disable it to prevent access by USB. You may need to install a USB driver to use these modes. For more information, see Installing the USB Drivers on page 157.

By default, the port is set to work as a virtual Ethernet port.

Note: Sierra Wireless recommends that you use a USB 2.0 cable with your AirLink gateway and connect directly to your computer for best throughput.

To change the USB port to allow virtual serial port communication:

 In ACEmanager, go to LAN > USB, and choose USB Serial as the USB Device Mode. To disable the USB port, select Disable from the same menu.

an analysis and the second second	2.40	Twenter Oak Mitten Com
DICFAddressing	(1) General	
Effortunt	AT USB Deutra Mode	Langer -
artur.	Contra USB P	192.168.14.31
Link Wild Coverage	Head CASE OF	192 108 14 100
	USE Network Mays	255.255.255.0
Hunt Port Reading	AT USB Dens Ects	Tanta w
Gilobal D403	Lossifiet T Heat WHEE Connectivity	frame +
PPPol		
WLMI-		
vester		
InvolutionFace Watching		

Figure 6-8: ACEmanager: LAN > USB

Field	Description
General	
USB Device Mode	 The USB mode on gateway startup USB Serial—USB port acts as a virtual Serial port. USBNET—USB port acts as a virtual Ethernet port. (default) Disabled—USB port is disabled. You can also configure this parameter using the AT Command *USBDEVICE. See *USBDEVICE on page 498. Note: A reboot is required to activate the USB mode change.
USB Serial Mode	 When USB Device Mode is set to USB Serial, select the USB Serial Mode. Options are: AT (default) PPP
Device USB IP	The USBNET IP address of the AirLink gateway. By default this is set to 192.168.14.31.
Host USB IP	The IP for the computer or device connected to the USB port
USB Network Mask	Use this field to configure a subnet mask for USBNET Default is 255.255.255.0
USB Serial Echo	 The AT command echo mode when the USB is configured as a virtual serial port Options: Enable—Echoes commands to the computer (so you can see what you type) (default) Disable—Does not echoes commands to the computer (you cannot see what you type)
USBNET Host WAN Connectivity	Controls access to the WAN over the USB port Options are: • Enable—USB can be used to access the WAN (default) • Disable—Access to the WAN over USB is blocked.

Installing the USB Drivers

A USB driver is required if you want to use the USB port on the gateway as a virtual serial port (USB Serial). If you want to use the USB port as a virtual Ethernet port (USBnet), a driver is not required as the default Microsoft Windows 7 and Windows 8 drivers are used.

To install the USB Serial drivers for Windows 7 and Windows 8:

- 1. Go to source.sierrawireless.com and download the USB Serial Driver One-Click Tool.
- 2. Double-click the downloaded file (AirLink_Serial_<version number>.exe).
- **3.** As the drivers installs, a progress box appears in the lower right-hand corner of the monitor.

Sierra Wireless Device Drivers	Installing
In Prograss (100%) Please wait	

Figure 6-9: USB Serial One-Click Tool progress window

- In ACEmanager, go to LAN > Ethernet and set the USB Device Mode field to USB Serial.
- Connect a gateway to the computer using a USB cable.
 The driver installation completes and a window opens indicating the Serial Port number.



Figure 6-10: USB Serial Driver Installation Complete

At any time, you can open Device Manager to check the Serial Port number.

File Action View Help	
(m) [m] [] (m) (n)	
🕒 📩 Disk drives	
🗈 🌯 Display adapters	
DVD/CD-ROM drives	
P I Human Interface Devices	
IDE ATA/ATAPI controllers	
IEEE 1394 Bus host controllers	
Imaging devices	
Keyboards	
> Image: Second Action of the second action of t	
> 🕘 Modema	
Monitors	
Network adapters	
 Ports (COM & LPT) 	
AirLink USB Serial Port (COM9)	
Processors	
B SD host adapters	
SM Driver	
Sound, video and game controllers	
System devices	
Universal Serial Bus controllers	

Figure 6-11: Device Manager

Note: USB serial and USBnet drivers available at source.sierrawireless.com also work with Linux CDC-ACM drivers.

Note: The COM port number assigned by driver installation is the next port that is available. The port number might vary depending on the number of devices connected (using serial or virtual serial).

Once the driver is installed, you can use the USB port just like a standard serial port.

Link WAN Coverage

You can link WAN coverage to a selected LAN port (Ethernet or USB). If the AirLink gateway loses WAN coverage, the selected port is disabled for a configurable duration.

Anno BERColland Wolf		
a damente de construction en se		famile sum from the
DCP-Addressing		
Diamat	() Setural	
	Line WMI Coverage to Meetace	Dente w
10	interface Decation Daration	Interface Disaming when WAM Disabled
na WWW.Commission		
teat Part Renting		
106at 1015		
WV-E LAN		
n.hs		
0007		

Figure 6-12: ACEmanager: LAN > Link WAN Coverage

Field	Description	
General		
Link WAN coverage to Interface	 This disables the specified port when there is no WAN connection. Options are: Disable (default) Ethernet USB 	
Interface Disabled Duration	 Sets the period of time (in seconds) that the LAN interface is disabled when linking a LAN port to the WAN. Either the Ethernet or the USB LAN port can be linked to the WAN connection, but not at the same time. Options are: Interface Disabled when WAN is disconnected (default) 5 seconds 10 seconds 20 seconds 25 seconds 30 seconds 	

Host Port Routing

Host port routing enables the AirLink gateway to handle network communication for up to two non-NATed networks behind the gateway or router connected to the AirLink gateway. The following illustration shows a typical network configuration.






Figure 6-13: Host Port Routing Network Configuration

angelant tesa. NUNUT 1132	of the	Austra Hervert [] [av
OHCF/Addressing	and the second	
CHC/HEFEERING	Prov ARP (Primary Galeway)	Claim v
Elbertel	Heat furtherent 2	192 168 10 0
	Heat forward Submit Masic 2	265 258 255 0
1/10E	Host Network 2 Route	Ethernet Part in
Line Webb Coverage	Host Network 3	192.108.20.0
	Host Network Subret Mark 3	255 255 255 0
that Post Rading	Hoal Network 2 Route	Galances -
Under OAX	Heat Network 3 Galeway	192 168 13 20
annot		
VLAB		
where-		
Reat laterface Webchdag		

Figure 6-14: ACEmanager: LAN > Host Port Routing

Field	Description
Proxy ARP (Primary Gateway)	When enabled, the AirLink gateway responds to Address Resolution Protocol (ARP) requests to resolve WAN addresses for devices on the connected LANs. In doing so, the gateway becomes the primary gateway for connected LANs. Default is Enabled.
Host Network 2 Host Network 3	Enter the IP address for Host Network 2 and 3. These are LAN networks connected to the AirLink gateway behind a router or gateway. They do not have the same IP range as the AirLink gateway LAN network. For example, 192.168.10.0.
Host Network Subnet Mask 2 Host Network Subnet Mask 3	The subnet for the applicable network. For example, 255.255.255.0, which would with the setting above define a secondary network of 192.168.10.0/24.

Host Network 2 Route Host Network 3 Route	 Choose the appropriate option, depending on how ARP requests are handled on the network. Options are: Ethernet— Select this option if the network uses a router that acts as an ARP proxy for addresses on subnets connected to it. For example, in Figure 6-14 on page 161, when traffic is destined for host 192.168.10.100 in network 2, the AirLink gateway sends an ARP request for 192.168.10.100.
	Note: If Proxy ARP is not enabled on the router, the transmission fails (destination unreachable).
	 Gateway—Select this option if the network uses a device that does not handle ARP requests for network devices attached to it. When Gateway is selected, ALEOS handles ARP requests for the connected LAN devices. Any traffic destined for a host on the network behind a gateway is routed, by the device, through the gateway IP. For example, in Figure 6-14 on page 161, when traffic is destined for host 192.168.20.100 in network 3, the AirLink gateway sends an ARP request for the gateway (192.168.13.20), not the host. When you select Gateway, Proxy ARP is not required on the router.
Host Network 2 Gateway Host Network 3 Gateway	Enter the IP address for the gateway. This setting appears after selecting Gateway in the Host Network Route field and clicking Apply.

Global DNS

When the mobile network grants the IP address to the device, it includes the IP addresses of its DNS servers. Global DNS allows you to override the Mobile Network Operator's DNS settings for all connected devices. This is useful when the connected devices need to use a private network.

Note: If there are no alternate DNS servers defined, the default is the WAN network DNS server.

al addition to watch the loss	on the	and the second s
		Second Second Second Second
DECPAddressing		
	11 Dented EME- Post	
Dermit	AT Permaty DATE	18.0.0.1
19.64	AT Secondary CNIE	10.0.0.2
Linii Will Caverage	Did Prog	(braine +)
	DND Dentite	Date v
three Port Routing	bh9 Loop Dade	frame -
Dame SWS	AT Attenuate Promaty Chall	0.0.0.0
12.114	Altertate Secondary DNIT	88.00
WW4	Allemate OHD Park	53
VLAB		
And and a second se		
Hard Merthics Watchdog		

Figure 6-15: ACEmanager: LAN > Global DNS

Field	Description
Primary DNS	Primary Mobile Network Operator's DNS IP Address. This and the secondary DNS are generally granted by the mobile network along with the Network IP.
Secondary DNS	Secondary Mobile Network Operator's DNS IP Address

Field	Description
DNS Proxy	Determines whether or not the AirLink gateway is used as a DNS proxy server.
	Note: Using the AirLink gateway as a proxy DNS server can help reduce mobile network data use.
	Options are:
	 Enable (default) —All connected DHCP clients (PPP, PPPoE, Wi-Fi, USBNET, and Ethernet) send their DNS IP address resolution requests to the AirLink gateway. The AirLink gateway performs DNS lookups on behalf of the DHCP client.
	 If the AirLink gateway is able to resolve the request, it sends a response to the DHCP client.
	 If the AirLink gateway does not have the necessary information to resolve the request, it sends the request to the DNS server configured in the DNS Override field. When the AirLink gateway receives a response, it forwards it to the DHCP client and saves the information so that it can resolve the same request in the future.
	• Disable—All connected DHCP clients send their DNS IP address resolution requests to the DNS server received from the mobile network or the alternate server specified by DNS Override, if enabled. The AirLink gateway is not used as a DNS server.
DNS Override	Overrides the Mobile Network Operator's DNS address with the DNS server configured in the Alternate Primary DNS and Alternate Secondary DNS fields. Options are:
	Disable (default)—Mobile Network Operator's DNS server is used
	Enable—Alternate DNS server is used
	In order to ensure consistent DNS resolution, DNS override, when configured, applies to all WAN interfaces, including Ethernet WAN with static IP configuration. (See Static Configuration on page 105.)
DNS Local Cache	Configures caching for the gateway's DNS server. Options are:
	• Enable—The built-in DNS server caches queries and entries, which can reduce WAN traffic overall by sending out less DNS-related traffic.
	Disable—DNS queries and entries are not cached.
Alternate Primary DNS	Configure the primary DNS server to use instead of the Mobile Network Operator's DNS server
Alternate Secondary DNS	Configure the secondary DNS server to use instead of the Mobile Network Operator's DNS server
Alternate DNS Port	If you want to specify the port on the connected device that the AirLink gateway sends IP address resolution responses to:
	1. Ensure that the DNS Override field is set to Enable.
	2. Enter the desired port number in this field.
	3. Click Apply.
	When this field is set to 53 (default) or 0, packets are sent to port 53, the standard DNS port.

PPPOE

PPPoE (Point-to-Point Protocol over Ethernet) allows a point-to-point connection while using Ethernet. Just like the dial up protocol on which it is based, PPPoE can use traditional user name and password authentication to establish a direct connection between two Ethernet devices on a network (e.g., your AirLink gateway and your computer or router).

examples for PPPoE with your AirLink gateway:

- Backup connectivity solution for your network
- Individualized Internet connection on a LAN
- Password restricted Internet connection

Only one computer, router, or other network device at a time can connect to the AirLink gateway using PPPoE. If you are using the AirLink gateway connected to a router as a back up Internet connection for your network, you should configure the router to use the PPPoE connection and not the individual computers.

Note: To configure a PPPoE connection on some operating systems, you need administrator privileges to the computer you are configuring or access granted by an administrator on the network to add/remove devices to your computer.

nma MilliCellular Mi	Construction of the second	Towers Separating Secol Application 1977 Admin
Carbon Philippins	11 1744	and the second second
#CPAddowning	AT Not Advertisation the In	NOR *
Barriet	HT Heart Lines (E)	
	AT High Passest	
50 C		
ee WAN Coverage		
out Port Realing		
Initial DNS		
met .		
AR		
LAN		

Figure 6-16: ACEmanager: LAN > PPPoE

Field	Description
Host Authentication Mode	 Host Authentication Mode: Use PAP or CHAP to request the user login and password during PPP or CHAP negotiation on the host connection. The username and password set in *HOSTUID and *HOSTPW is used. NONE (default) PAP and CHAP CHAP

Field	Description
Host User ID	User ID for authentication (up to 64 bytes)
Host Password	Password for authentication

Configure the AirLink gateway to Support PPPoE

Note: You must disable the DHCP server for PPPoE to work.

To configure an AirLink gateway to support PPPoE:

- 1. In ACEmanager, go to LAN > Ethernet.
- **2.** Under General, in the DHCP Server Mode field, select Disable.

Note: PPPoE authentication is optional. If you use PPPoE authentication, no other tethered LAN connection will have network access, regardless of whether or not the PPPoE host is connected. If you are using non-authenticated PPPoE, other tethered LAN connections will have network access until a PPPoE host is connected.

- 3. If you want to use authenticated PPPoE:
 - **a.** Go to LAN > PPPoE, and in the Host Authentication Mode field, select PAP and CHAP.
 - b. In the Host User ID, enter a user ID for the PPPoE connection.
 - c. In the Host Password field, enter a password for the PPPoE to connection.
- 4. Click Apply.
- 5. Reboot the gateway.

Tip: If you leave Host User ID and Host Password blank, any computer or device can connect to the AirLink gateway using PPPoE.

Note: ACEmanager shows the existing value for the PPPoE password as stars (****).

Optional: Configure the Device Name

- 1. In ACEmanager, go to Services > Dynamic DNS.
- 2. In the Service field, select IP Manager.
- **3.** Under Dynamic IP, enter a name in the Device Name field, such as AirLink gateway or the ESN. The name can be up to 20 characters long.

The name you choose for Device Name does not affect the connection, but may need to be configured in PPPoE settings for the router, device, or computer you connect to your AirLink gateway.

Configuring a PPPoE Connection in Windows 7

1. In Windows 7, go to Start > Control Panel.




Figure 6-17: Windows 7: Control Panel

2. Select Network and Internet.



Figure 6-18: Windows 7: Control Panel > Network and Internet

3. Select Network and Sharing Center.




Figure 6-19: Windows 7: Control Panel > Network and Sharing Center

4. In the middle of the page, under Change your networking settlings, select Set up a new connection or network.

an Married Married	hanat	
-	a brow the state of the summer to the binners	
Set up a new ne	twork.	
Current to a be	ct 50 A wincless network. Statunetwork in coster a new winness profile.	
Connect to a wo		
Service a shering	of VTN connection to your acception.	
Set up a dial-up	connection	
Set up a that up Connect to the 1	connection monet useg a tiel-up connection.	

Figure 6-20: Set Up an Connection or Network

5. Select Connect to the Internet and click Next.



6. Select Broadband (PPPoE).


(Planter place SP (prov yes)) (Plantered year (SP (prov year))	
(Perroversity over 15P gave you)	
Show characters	
E femender this password	
Broadband Connection	
saw this connection	
	E Remember this password Broadband Connection


- **7.** If you are using authenticated PPPoE, enter the User name and Password you configured in ACEmanager.
- **8.** If desired, change the Connection name to something such as PPPoE that clearly identifies the connection.
- 9. Click Connect.

For subsequent connections, you can click the network icon in the Task bar () and select the PPPoE connection.

VLAN

ALEOS supports up to three Virtual Local Area Networks (VLANs) on its Ethernet port. VLANs are logical groupings of network devices that share the same broadcast domain. All devices on the same VLAN can ping each other without routing. ALEOS does not support routing between VLANs.





								ess) weinen (Car
HC2/Millioning	VLAN							
itariari 1121	Martice	91,481-81	Device IP	Subard Mask	Access HAR	DACP Norver Maile	Starting P ⁴	Long P
	0.4911	15	10.11T.01	201218-201214	788.14	Erate	192 198 75 108	182 186 75 150
ank VAVE Commission	YLAN2	16	982.008.96.24	218.248.268.5	Yes -	train -	182 148,76 108	182 186 75 250
tool Pert Realing	VLAV3	4	8888	0.0.0.0	184 w	Zmathe	0.848	8.0.0.0
Died DVS								
4946								
CAR								
NAMP .								

Figure 6-22: ACEmanager: LAN > VLAN

Field	Description
Interface	Displays the three VLANs you can configure
VLAN ID	VLAN ID • 0—VLAN is disabled (default) • 1–4094—Valid range for VLAN ID
Device IP	The IP address of the AirLink gateway for that VLAN interface
Subnet Mask	The subnet mask indicates the range of host IP addresses that can be reached directly. Changing the subnet mask limits or expands the number of devices that can connect to the AirLink gateway.
Access WAN	 Choose whether or not devices on the configured VLAN have access to the WAN. Yes No
DHCP Server Mode	Choose whether or not the AirLink gateway acts as a DHCP server Options are: Enable—AirLink gateway acts as the DHCP server Disable (default)
Starting IP	VLAN interface DHCP pool starting IP address
Ending IP	VLAN interface DHCP pool ending IP address

VRRP

VRRP (Virtual Router Redundancy Protocol) enables you to configure a backup WAN connection to be used if the primary connection fails. You can configure VRRP on the AirLink gateway's Ethernet port or for VLANs.

You configure a VRRP Master and VRRP Backup device(s) and set their priorities. The device with the highest priority (normally the VRRP Master) becomes the primary route for the data connection.

The VRRP Master and Backups share a common virtual IP.

For information on configuring VLANs, see VLAN on page 170.

One common scenario is to use a 3rd party router for the primary connection and the AirLink gateway, either with or without VLANs, for the backup connection.




Figure 6-23: VRRP Network Configuration without VLANs




Figure 6-24: VRRP Network Configuration with VLANs

							and the state of t	
DeCP-Addressing	WWP Mode							
Oberial	VIBP							
1940	montace	NLAR 10	Group 40	Printilly	Moritanial IB*	Mode	Interval	
Lee WWF Command	Ellenad		60	100	102 101 13.40	Becklift a	Ψ.	
	VLART	18	0	100	80.08	BADUF +	1	
kott Patt Rotting	16.4412		4	100	+0.0.0	BADRUP w	+	
Tomar DVS	8.411	R.	0	190	80.00	BACKUP: w	1	
PPNE								
er'age								
-								

Figure 6-25: ACEmanager: LAN > VRRP (no VLANs)

alf against the strategy of the second	(A.79)					11.1	a la maria la casa
DPO?(Addressing	WHEP incd				Date u		
Distant	VMRP						
Le tout	Interface	VLAH EE	Group 10	Printing	Writeel IP	Ricks	blenel
Los WA Concept	Distant	0	a	100	0.0.0.0	SADAUP +	4
	VEALST.		15	100	192 198 13.40	ALCEUP. or	10.
Real Piet Bodleg	VLAN2	10	28	100	192-108-12-41	SADUP	Ť
Distributi 1943	16.4913	0	0	10)	888.8	BHORD [®] IN	1
NINE							
VLAN							
5744 S							
TERP .							
Aust Interface Watchdog							

Figure 6-26: ACEmanager: LAN > VRRP (VLANs)

You can also set up VRRP using two AirLink gateways—one configured as the VRRP Master and the other as the VRRP Backup. The Backup AirLink gateway provides an alternate route when the Master AirLink gateway loses coverage.

For example, if you have cellular accounts with two different Mobile Network Operators (MNOs) you might prefer to use MNO A's connection, but to maintain continuity, you would like traffic to switch to MNO B if A's network is down and switch back to A's network once the connection is re-established.




Figure 6-27: VRRP Network Configuration using two AirLink gateways

Field	Description
VRRP Enabled	Allows you to activate VRRP. Options are: Enable Disable (default)
VRRP—The VLAN ID, C VRRP Backup devices	Group ID, and Virtual IP address must be the same on the VRRP Master and
Interface	Displays Ethernet port on AirLink gateway and the VLAN numbers
VLAN ID	Displays the VLAN ID This value is inherited from the LAN > VLAN screen. (See VLAN on page 170.) • 0—VLAN is disabled • 1-4094—Valid range for VLAN ID
Group ID	Enter the VRRP Group ID. Configure the VRRP Master (for example, the 3rd party router) and the VRRP Backup (for example the AirLink gateway) with the same Group ID. Options are: • 0-255 (Default is 0.)

Field	Description
Priority	Use this field to configure the priority for the AirLink gateway. The device with the highest priority (typically a 3rd party router) provides the primary data traffic route. If the device loses its connection to the WAN, its priority number drops. If the device fails, then when the failure is detected, the next highest priority router becomes the active router. The priority number configured on the VRRP Backup (typically the AirLink gateway) should be less than the initial priority number on the VRRP Master and greater than the value that the VRRP Master's priority number would be if it drops as a result of losing its WAN connection. For example, if the VRRP Master router has an initial priority number of 200 that drops to 80 if it loses its WAN connection, setting the AirLink gateway's priority to 100 ensures that it becomes the primary route if the VRRP Master loses its WAN connection. When the 3rd party router re-establishes its connection, its priority returns to 200 and it once again becomes the primary route for data. Options are: • 1–255 (Default is 100.)
Virtual IP	Configure the same virtual IP for the VRRP Backup (typically the AirLink gateway) and the VRRP Master (typically a 3rd party router). The virtual IP must be unique within the VLAN subnet and cannot be within a pool of addresses assigned via DHCP.
Mode	 Indicates the initial mode for the AirLink gateway Options are: MASTER BACKUP (default) Note: Designating a device as "Master" in this field does not make it the primary route for data unless it is also given a higher priority number than the VRRP Backup device. See Priority.
Interval	 If the AirLink gateway is acting as VRRP Master, it advertises its Master status at the interval (in seconds) configured in this field. Options are: 1–65535 seconds (Default value is 1.)

Host Interface Watchdog

The Host Interface Watchdog provides a way for you to ensure that the LAN connection is alive. You can use this feature to monitor:

- A host connected to the LAN via an Ethernet or USB connection
- A host computer associated with a gateway that has the Wi-Fi mode is set to "Access Point" or "Both" (See Global DNS on page 163).

When the Host Interface Watchdog is enabled, ALEOS sends a ping to the connected device at configured intervals. You can disable Force Keepalive to only send a ping when there is no traffic on the LAN interface. (See Force LAN Keepalive on page 177.)

If there is no response to the ping, the LAN interface is reset.

Note: The network interface is automatically determined from the IP address and the LAN configuration. If you have multiple interfaces bridged (see Bridge Wi-Fi to Ethernet on page 132) all interfaces in the bridge and the bridge itself are reset.

After the interface comes back up, ALEOS sends another ping to the connected device. If there is still no response to this ping, the AirLink gateway reboots. After a reboot caused by the LAN Interface Watchdog, ALEOS waits an hour before attempting pings to prevent repeated frequent reboots.

Note: DUN (PPP) is not supported. If the IP address for the host is on a DUN network, the feature is disabled.

Note: The feature is not disabled when the interface uses Public Mode, but it cannot monitor the host interface unless the mobile network provides a static IP.

of speladorblines, "Philipped' 1,487	LPN .		second second second
			And Description Con-
NCP-Addressing	LAN Kongaline IP Address	0.000	
linement	LAN Keepsher Harvel (Himsley)	0	
	Forte URI Keepalise	Drate w	
58			
on With Coverage			
end Port Reading			
uper 3MT			
unu dets			
1996 1996			
1995 1996 1997			

Figure 6-28: ACEmanager: LAN > Host Interface Watchdog

Field	Description
LAN Keepalive IP address	Enter the IP address of the device to ping If a device IP address is not configured, the Host Interface Watchdog is disabled.
LAN Keepalive Interval (minutes)	The interval (in minutes) at which ALEOS pings the LAN-connected device Options are: 1–1440 If this field is set to 0, the Host Interface Watchdog is disabled. (default) To prevent the gateway from rebooting frequently when a connection is not available, if the gateway reboots as a result of a failed keepalive ping, it waits 60 minutes before sending another keepalive ping. Once the ping is successful, the gateway returns to the interval configured in this field.
Force LAN Keepalive	 Enabled (default)—The network interface statistics are not monitored and a ping is always sent at the interval configured in the Keepalive Interval field. Disabled—The network interface statistics are monitored and connectivity is assumed when there is traffic received. A ping is only sent when there is no traffic for a period greater than the interval set in the Keepalive Interval field.

>> 7: VPN Configuration

The AirLink RV55 can act as a Virtual Private Network (VPN) device, providing enterprise VPN access to any device connected to the AirLink gateway even when a device has no VPN client capability on its own. The AirLink gateway supports three types of VPN: IPsec, GRE, and OpenVPN. The RV55 can support up to five VPN tunnels at the same time.

Note: Dynamic Mobile Network Routing (DMNR) is not compatible with VPN tunnels. If you are using DMNR, disable all VPN tunnels.

General

On the General page you can select your IPsec Implementation and reset all VPN tunnels so that the RV55 doesn't have to be rebooted in order for changes to be used.

The available settings on the General page depend on which IPsec implementation you have selected.

Standard Vs. Legacy IPsec Implementation

The AirLink RV55 supports Legacy IPsec implementation (in place prior to ALEOS 4.12.0) or the new Standard IPsec implementation. Sierra Wireless recommends that you migrate any existing Legacy VPN implementations to the Standard version for increased features and support. For configuration information, see IPsec (Legacy) on page 184 and IPsec (Standard) on page 190.

The Standard implementation is fully IKEv1 and IKEv2 compliant, and supports MOBIKE when operating over IKEv2. Standard implementation also offers increased security through certificate-based authentication and a larger set of cryptographic algorithms than the Legacy implementation. You can use Standard for Host-terminated or LAN-terminated applications (see Figure 7-3). In addition, the Standard implementation provides the option to configure IPsec tunnels to FIPS (Federal Information Processing Standards) standards. For more information, see IPsec FIPS Mode on page 180.

or uphial loss 102.21	10 T 74 H 1 PM	antennos antenno dente
		family and then the
General		
	() General	
Fatherer		
LOUIS T	Proc inglementation	TADAL *
VPB 1	Renati VPR Tamonia	Passed VIN Davisation
Vial 2	11 Out of Band Philosop	
Andrew Tarley	Monthan Cart	
A649 2	AT incoming Traffic	Studied -
VPB 4	AT Galaxies Galecolat Outgoing Table	(Append +
VPN 5	11 LAN Hoat Generated Outgoing Traffic	Batel -

Figure 7-1: ACEmanager: VPN > General (Legacy)

of spinist installing the print of the	10.00	attractionals assesses and
a deserve a server of		Transition Aug Distance Canon
General		
	(){General	
Faituver	Second and the second se	(1920) (2020) 1
VPICT	Fian Ingleinentation	. Standard -
40.00	Pany Lanal Termination	1.Mi
VPH 3	Pant FIPS Moto	Cheatra -
	Research WHY Yammake	Frank VPN Transels
VPN 3	and the second se	
VPM.4	[1] Out at Band Polysies	
	W Incartang Talka	(Build +
VPN 3	Contractory and the second sec	
	W Galaxyay Garanated Outgoing Traffic	Alcent +
	All LAN Heat Generated Outgoing Traffic	Burned -

Figure 7-2: ACEmanager: VPN > General (Standard)




Figure 7-3: IPsec VPN Local Termination types

Field	Description
General	
IPsec Implementation	 Selects the IPsec Implementation. Legacy Standard For more information, see IPsec Overview on page 183, IPsec (Legacy) on page 184, and IPsec (Standard) on page 190.
	Note: Legacy and Standard implementations are independent. Once you have configured IPsec tunnels for Standard VPN implementation, if you change IPsec Implementation to Legacy, you must reconfigure IPsec tunnels for the Legacy implementation.

Field	Description
IPsec Local Termination	 Available only with Standard IPsec Implementation. Select where the VPN tunnel terminates. Local termination type: LAN (default)—Network terminated. Use for LAN-to-LAN configuration. Host—Host terminated. Use for Host-to-LAN configuration.
IPsec FIPS Mode	Available only with Standard IPsec Implementation. Enables FIPS mode of operation. When enabled, a FIPS-approved cryptographic module is used for IPsec data protection, and only FIPS-approved cryptographic algorithms are allowed for tunnel configurations.
	Note: FIPS is only supported for IKEv2 tunnels.
	Options are: • Disable (default) • Enable
	Note: ACEmanager saves FIPS and non-FIPS IPsec tunnel configura- tions separately. Settings for one mode (IKE and ESP algorithms, for example) do not apply to the other mode if you switch the mode. After you have enabled FIPS mode and configured IPsec tunnels, disabling FIPS mode will return IPsec tunnel settings to non-FIPS settings. Re-enabling FIPS mode restores your FIPS mode IPsec tunnel settings.
Reset VPN Tunnels	Resets and reconfigures all VPN tunnels. After making VPN configuration changes, click this button to reset the VPN tunnels and begin using the new settings. Rebooting the device is not necessary.
Out of Band Policies	
while other incoming and/or outgoing of-band configurations should be	of-band traffic, where some traffic can be routed through an encrypted VPN, going traffic is routed through the public Internet ("Out of Band" traffic). Oute set up with care, as a configuration with both an enterprise VPN and inadvertently expose company resources.
Incoming Traffic	 Controls incoming public Internet traffic. Options are: Blocked—Incoming public Internet traffic is blocked. Only traffic through the VPN tunnel is allowed. (default) Allowed—Incoming public Internet traffic is allowed.
Gateway Generated Outgoing Traffic	 Controls outgoing AirLink gateway-generated traffic. Blocked—Outgoing traffic from the AirLink gateway to the public Internet is blocked. Only traffic through the VPN tunnel is allowed. Allowed—Outgoing traffic from the AirLink gateway to the public Internet is allowed. (default)
LAN Host Generated Outgoing Traffic	 Controls outgoing LAN Host-generated traffic. Options are: Blocked—Public Internet traffic from the host device is blocked. Only traffic through the VPN tunnel is allowed. (default) Allowed—Public Internet traffic from the host device is allowed.

VPN Failover

VPN Failover is only available for IPsec VPN tunnels. To use this feature, configure a primary and a secondary VPN tunnel. Dead Peer Detection (DPD) verifies the status of the active connection. For example, if the primary/active VPN goes down (i.e. DPD detects that the end device is not responding) traffic is automatically switched to a backup VPN tunnel. The VPN Failover feature continues to ping the VPN responder for the tunnel that has gone down. If configured to do so, once the primary VPN tunnel is up, traffic automatically reverts to the primary VPN. Status fields on the Failover page inform you of the current status of the two VPNs.




Figure 7-4: VPN Failover Configuration

To configure VPN Failover:

- Configure two IPsec VPN tunnels. The one you want to designate as the primary VPN must have Dead Peer Detection configured. For the Secondary VPN, you only need to configure the remote gateway address. For other settings, such as the local and remote subnets, the secondary VPN uses the same settings as the primary VPN. For instructions on configuring IPsec VPN tunnels, see IPsec (Legacy) on page 184 and IPsec (Standard) on page 190.
- 2. Go to VPN > Failover and configure the first three fields. See the table following the screen shot for details.
- 3. Click Apply and Reset VPN Tunnels or reboot the AirLink gateway.

of generative states	218-13-88-10-40	AND DESCRIPTION OF
General	Penary 3PH	(here =)
Taman	Secondary VPN	100 ···
una e	Reater	Annes -
Verse 4	Premary VPA Status	Deated
1014 E	Geconitally WH Status	Circulated
	Overall VPN Status	Oragend.
Anne 1	Mampine of Printate VPNi Failures	1
VP19-4	Number of Decondary (PNI Patients	8
1400	Assembler of Darkdives to Philinary 1916	¥.
Vice 5	Number of Deficies in December VPN	¥

Figure 7-5: ACEmanager: VPN > Failover

Field	Description	
Primary VPN	ID of the primary VPN (for VPN Failover): VPN 1, VPN 2, VPN 3, VPN 4, VPN 5, or Non (default)	
Secondary VPN	ID of the Secondary VPN (for VPN Failover): VPN 1, VPN 2, VPN 3, VPN 4, VPN 5, or None (default)	
Revertive	 When VPN Failover is configured and this field is set to Enable, traffic automatically switches from the Secondary VPN back to the primary VPN when the failure is resolved and the primary VPN tunnel is up again. Options are: Enable (default) Disable 	
Primary VPN Status	 Status of the primary VPN: Disabled (default)—VPN Failover is disabled. Connecting—The VPN is trying to connect to the responder. Active—The VPN tunnel is ready and transferring traffic. Backup—This is currently the backup VPN connection. Failed—Dead Peer Detection (DPD) has determined that the VPN responder is dead, or a ping sent to the VPN host failed. Out of Service—There have been 5 DPD failures within an hour. 	
Secondary VPN Status	 Status of the Secondary VPN: Disabled (default)—VPN Failover is disabled. Connecting—The VPN is trying to connect to the responder. Active—The VPN tunnel is ready and transferring traffic. Backup—This is currently the backup VPN connection. Failed—Dead Peer Detection (DPD) has determined that the VPN responder is dead, or a ping sent to the VPN host failed. Out of Service—There have been 5 DPD failures within an hour. 	

Field	Description	
Overall VPN Status	 Status of the overall VPN: Disabled—VPN Failover is disabled. (default) Connecting—One of the VPNs is trying to connect to the responder. Active—One VPN tunnel is currently in use. The backup VPN is available. Backup_Unavailable—One VPN tunnel is currently in use. The backup VPN is nor available. Out of Service—Neither the primary nor secondary VPN is operational. N/A—The overall VPN status is temporarily not available. Click Refresh. 	
Number of Primary VPN Failures	Number of times DPD has failed on the primary VPN since the device last lost its WAN connection.	
Number of Secondary VPN Failures	Number of times DPD has failed on the Secondary VPN since the device last lost its WAN connection.	
Number of Switches to Primary VPN	Number of times traffic was switched to the primary VPN since the device last lost its WAN connection.	
Number of Switches to Secondary VPN	Number of times traffic was switched to the Secondary VPN since the device last lost i WAN connection.	

IPsec Overview

The IP protocol that drives the Internet is inherently insecure. Internet Protocol Security (IPsec), which is a standards-based protocol, secures communications of IP packets over public networks.

IPsec is a common network layer security control and is used to create a virtual private network (VPN).

Note: ALEOS offers two IPsec implementations: Standard and Legacy (compatible with ALEOS releases prior to 4.12.0). All installations are encouraged to upgrade to ALEOS 4.12.0 to take advantage of the new Standard implementation, with its increased security. For configuration information, see IPsec (Legacy) on page 184 and IPsec (Standard) on page 190.

The advantages of using the IPsec feature includes:

- Data Protection: Data Content Confidentiality allows you to protect your data from any unauthorized view, because the data is encrypted (encryption algorithms are used).
- Access Control: Access Control implies a security service that prevents unauthorized use of a Security Gateway, a network behind a gateway or bandwidth on that network.
- Data Origin Authentication: Data Origin Authentication verifies the actual sender, thus eliminating the possibility of forging the actual sender's identification by a third-party.
- Data Integrity: Data Integrity Authentication allows both ends of the communication channel to confirm that the original data sent has been received as transmitted, without being tampered with in transit. This is achieved by using authentication algorithms and their outputs.

The IPsec architecture model includes the Sierra Wireless AirLink gateway as a local gateway at one end, communicating through a VPN tunnel with a remote VPN gateway at the other end. The remote gateway is connected to a remote network and the VPN is connected to the local network. You can configure up to three remote subnets.

The IPsec VPN employs the IKE (Internet Key Exchange) protocol to set up a Security Association (SA) between the AirLink RV55 and AirLink Connection Manager or a Cisco (or Cisco compatible) enterprise VPN server. IPsec has two phases for setting up an SA between peer VPNs. Phase 1 creates a secure channel between the RV55 VPN and the enterprise VPN, thereby enabling IKE exchanges. Phase 2 sets up the IPsec SA that is used to securely transmit enterprise data.

Note: If you configure custom settings, they are saved and the tunnel can be disabled and reenabled without needing to re-enter the settings. For a successful configuration, all settings for the VPN tunnel must be identical between the AirLink RV55 VPN and the enterprise VPN server.

You can also configure VPN Failover for IPsec VPN tunnels. For more information, see VPN Failover on page 181.

IPsec (Legacy)

The Legacy IPsec implementation was in place prior to ALEOS 4.12.0. You can configure IPsec tunnels in Legacy mode if you absolutely must retain an existing configuration. Otherwise, Sierra Wireless recommends using the Standard IPsec implementation. For more information, see Standard Vs. Legacy IPsec Implementation on page 178.

To configure an IPsec VPN tunnel in Legacy mode:

- 1. In ACEmanager, go to VPN.
- 2. On the General page, under IPsec Implementation, select Legacy.
- **3.** Select the VPN you want to configure (1, 2, 3, 4, or 5).
- **4.** In the VPN Type field, select IPsec Tunnel. The screen expands to show the IPsec Tunnel fields.

-)	6 COUNT AND ADDRESS	Same of Asta Same in				
General						
	11 Terr					
Falkorer	42 1999 1 fum	ProcTation -				
1998 B	AT VPICT Datus	Int Culled				
WTH 2						
VPN 2	151-General Engine	151General English				
	47 1996 Galaxiesy Autorese	306.81 123.21				
XTN 4	47 Pro-shared Kap 1					
WPM 6	all May identify Type	· · · ·				
	My identity - 92					
	47 Past Hartity Type	(P				
	Past methy . 3*					
	AT Negaliamon Mode	Hatt				
	41 WE Exclusion Adjustical	40-08 +				
	47 INT: Authentication Algorithms	30401 -				
	AT WE Key Creat	100 -				
	47 INE SA LIN Time	7200				
	at we ono	Deates -				
	AT Local Address Type	Topest Address -				
	47 Local Adduce	192 168 13.0				
	AT Local Address - Hermann	255.255.255.0				
	Af Earnoin Address Type	(buind traines -				
	47 Spermin Address	10 11 12 0				
	45 Damain Address - Netwark	255 255 255 0				
	47 Partics Fernant Sacrony	(No. 10)				
	47 (Plac Entrypton Algorithm	405-08 +				
	47 Plac Automation Reportion	last -				
	of diffice way farming	1942 -				
	47 Prime Sch Life Term	7200				
	11 Additional Trimute Subsets					
	Remark Salmer 2 Address Type	Tamataman v:				
	Forests Taland 2 Address	0000				
	Ferrate Salarel 2 Address - Sutmatk	255 255 255 0				
	Mannata Subant 3 Address Type	(Juneal Address: +)				
	Remote Salmed 3 Address	0000				
	Remote Subnet 3 Hallesss - Netmank	255 255 255 0				

Figure 7-6: ACEmanager: VPN > VPN 1 > IPSec Tunnel (Legacy)

- 5. See the following table for instructions on completing the IPsec Tunnel fields.
- 6. Once the configuration is complete, click Apply and Reset VPN Tunnels or reboot the AirLink gateway.
- 7. Check the VPN Status field to confirm the status of the VPN connection.

Field	Description	
Туре		
VPN # Type	Use this field to select the type of VPN tunnel. If you configure custom settings, they a saved and the tunnel can be disabled and re-enabled without needing to re-enter the settings. Options are: • Tunnel Disabled (default) • IPsec Tunnel • GRE Tunnel • OpenVPN Tunnel (only available for VPN 1)	
VPN # Status	 Status of the VPN connection: Not Enabled—VPN is disabled (default) Not Connected—The VPN failed to connect. This could be because of a mismatch in the configuration between the client and the server, no data connection on the device, etc. Connected—The VPN is connected and ready to transmit traffic. Configuration Error—This status appears when: Two VPNs have the same Local Address and Remote Address More than one VPN has the remote address set to "0.0.0.0" When either of these errors exist, only the first of the conflicting VPNs is operational. To determine which VPNs are in conflict: Go to Admin > Configure Log. For the VPN Subsystem, ensure that Display in Log is set to Yes. The Verbosity can be either Info or Debug. Click View Log. The resulting log shows you which VPNs are in conflict. 	
General (Legacy VPN Gateway	The IP address of the server that this VPN client connects to. This address must be open to	
Address	connections from the AirLink gateway. The default VPN Gateway IP Addresses are static address on Sierra Wireless Servers. They are:VPNGateway IP Address1208.81.123.212208.81.123.223208.81.123.264208.81.123.235208.81.123.24You can use these default IP addresses to confirm that an IPsec connection can be established with your wireless configuration before making any configuration changes, and as an example to model your VPN configuration after.	

Field	Description			
Pre-shared Key 1	 The pre-shared key (PSK) is used to initiate the VPN tunnel. Pre-shared key length: Maximum supported length is 128 characters. Valid characters are: 1234567890abcdefghijkImnopqrstuvwxyzABCDEFGHIJKLM NOPQRSTUVWXYZ!%-~@#\$^* Invalid characters: ><?& 			
My Identity Type	 Sets the host authentication ID. Options are: IP (default)—The My Identity - IP field appears with the WAN IP address assigned by the carrier FQDN—The My Identity - FQDN field appears. Enter a fully qualified domain name (FQDN) e. g., modemname.domainname.com User FQDN—The My Identity - FQDN field appears. Enter a User FQDN whose values should include a username (e.g. user@domain.com) 			
My Identity - IP or My Identity - FQDN	 My Identity—IP appears only when IP is selected from the My Identity Type drop- down menu. The WAN IP address assigned by the carrier appears. My Identity—FQDN appears only when User FQDN or FQDN is selected from the My Identity Type drop-down menu. Enter an FQDN or User FQDN. Note: If you are using a FQDN for your device (My Identity Type) either: Set up a Dynamic DNS on the Services > Dynamic DNS tab (See Dynamic DNS on page 235) or Use a DNS server as your domain host 			
Peer Identity Type	 Required in some configurations to identify the client or peer side of a VPN connection. Options are: IP (default)—The Peer Identity - IP field appears with the IP address of a VPN server set up by Sierra Wireless for your testing purposes FQDN—The Peer Identity - FQDN field appears. Enter an FQDN (e. g. modemname.domainname.com) User FQDN—The Peer Identity - FQDN field appears. Enter a User FQDN whose values should include a username (e.g., user@domain.com) 			
Peer Identity - IP or Peer Identity - FQDN	 Peer Identity—IP appears only when IP is selected from the Peer Identity Type drop- down menu. The VPN Gateway IP Address appears. Peer Identity—FQDN appears only when User FQDN or FQDN is selected from the Peer Identity Type drop-down menu. Enter the Peer FQDN or Peer User FQDN. 			
Negotiation Mode	 Enable Aggressive mode for the VPN. Aggressive mode offers increased performance at the expense of security. Options are: Main (default) Aggressive 			
IKE Encryption Algorithm	Determines the type and length of encryption key used to encrypt/decrypt IKE packets. 3DES supports 168-bit encryption. AES (Advanced Encryption Standard) supports both 128-bit and 256-bit encryption. Options are: DES, 3DES, AES-128 (default), and AES-256			
IKE Authentication Algorithm	MD5 is an algorithm that produces a 128-bit digest for authentication. SHA is a more secure algorithm that produces a 160-bit digest. Options are: MD5 and SHA1 (default)			

Field	Description	
IKE Key Group	Options are: DH1, DH2 (default), or DH5	
IKE SA Life Time	Determines how long the VPN tunnel is active in seconds. Options are: 180 to 86400; Default: 7200	
IKE DPD	 Dead Peer Detection (DPD) Options are: Disable (default) Enable When DPD is enabled, the AirLink gateway checks to see if the server is still present if there has been no traffic for a configured interval. If it does not receive an acknowledgment, it retries at 5 second intervals. If there is no acknowledgment after 5 retries, the status of the VPN is set to Not Connected and the device attempts to renegotiate IPSEC security parameters with its peer. 	
	Note: Sierra Wireless recommends that you Enable IKE DPD. Otherwise the AirLink gateway has no way of detecting that the connection to the VPN server is still available.	
IKE DPD Interval (seconds)	Use this field to set the DPD interval (in seconds). If there has been no traffic for the period of time set in this field, the AirLink gateway retries checking with the server, as described in IKE DPD. Options are: 0 to 3600 (default is 1200) If this field is set to 0, DPD monitoring is turned off (or disabled as described in the IKE DPD section), but the AirLink gateway still responds to DPD requests from the server.	
Local Address Type	 The network information of the device. Options are: Subnet Address (default) Use the Host Subnet Single Address 	
Local Address	Device subnet address	
Local Address - Netmask	Device subnet mask information Default: 255.255.25.0	
Remote Address Type	 The network information of the IPsec server behind the IPsec gateway. Options are: Subnet Address (default) Single Address 	

Field	Description		
Remote Address	If the remot	ou can only have one remote	s) connected to the gateway ote address netmask should also be 0.0.0.0. address of 0.0.0.0 for all the VPNs.
	VPN	Remote Address	
	1	10.11.12.0	
	2	10.11.13.0	
	3	10.11.14.0	
	4	10.11.15.0	
	5	10.11.16.0	
Remote Address - Netmask	Remote subnet mask information Default: 255.255.255.0 0.0.0.0 is allowed for the remote address subnet mask as long as the remote address is also 0.0.0.0.		
Perfect Forward Secrecy	Perfect Forward Secrecy (PFS) is enabled by default. Leave the default setting in this field. To disable PFS, see IPsec Key Group.		
IPsec Encryption Algorithm	Determines the type and length of encryption key used to encrypt/decrypt ESP (Encapsulating Security Payload) packets. 3DES supports 168-bit encryption. AES (Advanced Encryption Standard) supports both 128-bit and 256-bit encryption. Options are: None, DES, 3DES, AES-128 (default), and AES-256.		
IPsec Authentication Algorithm	Can be configured with MD5 or SHA1. MD5 is an algorithm that produces a 128-bit digest for authentication. SHA is a more secure algorithm that produces a 160-bit digest. Options are: None, MD5 and SHA1 (default)		
IPsec Key Group	Use this field to select the DH (Diffie-Hellman) group pre-shared key length used for authentication, or to disable Perfect Forward Secrecy (PES)		
authentication, or to disable Perfect Forward Secrecy (PFS). The DH group number determines the length of the key used in the Longer keys are more secure, but take longer to compute. Also not VPN exchange must use the same DH group.		ngth of the key used in the key exchange process. onger to compute. Also note that both peers in the	
	PFS is enabled by default. It adds additional security because each session uses a unique temporary public/private key pair to generate the shared secret. One key cannot be derived from another. This ensures previous and subsequent encryption keys are secure, even if one key is compromised.		
	Note: In the Legacy IPsec implementation, it is not possible to disable PFS. If PFS is set to disabled in ACEmanager, the RV55, by default, negotiates PFS using the DH2 key group.		
	 DH1— DH2— 	e: –Disables PFS •Uses DH Group 1 (key lengt •Uses DH Group 2 (default– •Uses DH Group 5 (key lengt	-key length is 1,024 bits)

Field	Description
IPsec SA Life Time	Determines how long the VPN tunnel is active in seconds Options are: 180 to 86400; Default: 7200
Additional Remote Su	bnets
Remote Subnet 2 Address Type	The network information for subnet 2 IPsec server behind the IPsec gateway. Options are: Subnet Address (default) and Single Address
Remote Subnet 2 Address The IP address for the subnet 2 device behind the gateway	
Remote Subnet 2 Address - NetmaskRemote subnet 2 mask information Default: 255.255.255.0	
Remote Subnet 3 Address Type	The network information for subnet 3 IPsec server behind the IPsec gateway. Options are: Subnet Address (default) and Single Address
Remote Subnet 3 Address	The IP address for the subnet 3 device behind the gateway
Remote Subnet 3 Address - Netmask	Remote subnet 3 mask information Default: 255.255.255.0

IPsec (Standard)

The Standard implementation offers increased security and connectivity, and is the recommended configuration. For more information, see Standard Vs. Legacy IPsec Implementation on page 178.

To configure an IPsec VPN tunnel in Standard mode:

- 1. In ACEmanager, go to VPN.
- 2. On the General page, under IPsec Implementation, select Standard.
- **3.** Select your desired Local Termination and (depending on your application) enable FIPS mode.
- 4. Select the VPN you want to configure (1, 2, 3, 4, or 5).
- **5.** In the VPN Type field, select IPsec Tunnel. The screen expands to show the IPsec Tunnel fields.

diamental combi	101-46-48		growing as			
			Reported Ve	and Consult Stre		
General						
Failure	1H Type					
100	All units 1 base Press Taxon					
Anni e	Art units 1 Markon		Dormedied			
VRN 2						
	111 linewal (Mandavit)					
riset 3						
N996-8	1991 ClientSover Mode		(· · · · ·			
WHIS .	seni Galance Addance		l#1 123.21			
1012.0	Antonio Xie Custorige	1.802				
	Registation Made Dead Pres Detection (DPD)	Ner				
	P Compression					
	LOP Treastanting					
	WE Har Lifetree (seconds)	120				
	(CDP Nay L/Retrick (Jaccordan)	126				
	Peter New Texas Pro		M.E.			
	Contraction of the cont	1.00	0100			
	11 Thefacurb					
	Louid Administration	1 day	the information in the local section in the			
	Local Ammenational		108 13 0(24			
	Renals Address Businet Link	10	11 12 0/24			
	Randa Addesis/Detrol Examples Ltd					
	Exercipi ALMD and AMM Server Traffic From Turne	i Dar	Dame -			
	Galeway tirtual #" Type	10ph	Mature +			
	Galaxies Without P					
	11 Advertisation					
	Adheditation technol		Pre-alanti Key =			
	All Liberthy Tale					
	Mathematic - W					
	40 kmmby - Custom					
	Paur Marilla Type Paur Marilla - IP					
	Paul Marille - Castory					
	Privatigent Nav					
		100				
	() WE faculty					
	edi Algorithme					
	Exclusion	Anthentication		in Gilep		
	asville et	fetet		and the set		
	har Geed -	for inet -	The law			
	Indiana	Sullied -	1907 124	H H		
	HUTE thank HE Approximately are NOT DECUME	C Do NOT and United Vectors any	for legals soliterina.			
	111E3P Seconds PPS Created					
	Teste La construction de la constru					
	ESP Algorithms		- I - 112			
	Exception	Asthentication		re Grine		
	ano 121	- 1944		eentee yi		
	(tet land	intimet -	Het be	el +		
	There is a second secon	bettinet	19816	ef		
	ACTE: Manual SIP Apprehense" and NOT SECURE: Do NOT sea unless transmary for legacy systems.					

Figure 7-7: ACEmanager: VPN > VPN 1 > IPsec Tunnel (Standard)

- 6. See the following table for instructions on completing the IPsec Tunnel fields.
- 7. Once the configuration is complete, click Apply and Reset VPN Tunnels or reboot the AirLink gateway.
- 8. Check the VPN Status field to confirm the status of the VPN connection.

Field	Description		
Туре			
VPN # Type	 Use this field to select the type of VPN tunnel. If you configure custom settings, they are saved and the tunnel can be disabled and re-enabled without needing to re-enter the settings. Options are: Tunnel Disabled (default) IPsec Tunnel GRE Tunnel OpenVPN Tunnel (only available for VPN 1) 		
VPN # Status	 Status of the VPN connection: Disabled—VPN is disabled (default) Error Connecting—The VPN failed to connect. This could be because of a mismatch in the configuration between the client and the server, no data connection on the device, etc. Connected—The VPN is connected and ready to transmit traffic. Not Connected—The tunnel is enabled and trying to connect. Error in Gateway—The gateway/peer was an FQDN, and it could not be found; i.e., the IP address could not be found. 		
General (Standard)			
VPN Client/Server Mode	 Client Server Note: Server Mode is not compatible with Host-to-LAN configurations. Do not select Server when IPsec Local Termination is set to Host.		
	 Note: In Server Mode, the following is not a supported configuration: Negotiation Mode—Aggressive Internet Key Exchange—IKEv1 Authentication Method—Pre-Shared Key Sierra Wireless recommends setting Negotiation Mode to Main (default) in this case. 		

Field	Description			
VPN Gateway Address	server that the AirLink gate pass IPv4 tra	his VPN client connects to. T way. The RV55 supports IPv6 affic from the local IPv4 subr	or FQDN (Fully Qualified Domain Name) of the his address must be open to connections from the 6 addresses for "4-in-6" tunnels, where it is able to net to remote IPv4 subnets over the IPv6 network. are static addresses on Sierra Wireless Servers.	
	VPN	Gateway IP Address		
	1	208.81.123.21		
	2	208.81.123.22		
	3	208.81.123.26		
	4	208.81.123.23	_	
	5	208.81.123.24	_	
VPN Peer Address	 established with your wireless configuration before making any configuration changes, and as an example to model your VPN configuration after. Available in Server Mode. The IP address or FQDN (Fully Qualified Domain Name) of the client/peer that can connect to this VPN server. This address must be open to connections from the AirLink gateway. Note: The default IP Address in this field relates to the VPN Gateway Address setting described above. It can be disregarded when configuring the VPN Peer Address. 			
Internet Key Exchange (FIPS)	 IKEv1 (default) IKEv2 (default in FIPS mode—IKEv2 is the only option available) 			
Negotiation Mode	Enable Aggressive mode for the VPN. Aggressive mode offers increased performance at the expense of security.			
	Note: This setting applies to IKEv1 mode only.			
	Options are: • Main (default) • Aggressive			
МОВІКЕ	 Available when Internet Key Exchange: IKEv2 is selected. MOBIKE allows a VPN turstay connected, even if the WAN interface used by the tunnel changes. For example tunnel stays connected if the WAN interface changes from Ethernet to cellular. Optio Enable (default) Disable 		e used by the tunnel changes. For example, the	

Field	Description
Dead Peer Detection (DPD)	 Dead Peer Detection (DPD) Options are: Disable (default) Enable When DPD is enabled, the AirLink gateway checks to see if the server is still present if there has been no traffic for a configured delay. If it does not receive an acknowledgment after several retries, the status of the VPN is set to Not Connected and an attempt is made to restart the tunnel.
	Note: Sierra Wireless recommends that you enable DPD. Otherwise the AirLink gateway has no way of detecting that the connection to the VPN server is still available.
DPD Delay (seconds)	Use this field to set the DPD delay (in seconds). If there has been no traffic for the period of time set in this field, the AirLink gateway retries checking with the server, as described in Dead Peer Detection (DPD). Options are: 0 to 3600 (default is 10) Setting this field to 0 disables Dead Peer Detection as described in Dead Peer Detection (DPD). The AirLink gateway always responds to DPD requests from the server.
DPD Timeout (seconds)	Available for IKEv1 only. Periodic interval for Dead Peer Detection. If there is no communication from the server (including DPD responses) within this interval, the status of the VPN is set to Not Connected and an attempt is made to restart the tunnel.
IP Compression	 Enable or disable IP packet compression. When enabled, IP packets are compressed before being encrypted, improving throughput for slow connections. Disable (default) Enable Note: Disable IP Compression if the VPN server (Server Address field) doesn't support compression.
UDP Encapsulation	 Allows you to enable UDP encapsulation in cases where it must be manually enabled if firewall restrictions require it. If either peer is behind a NAT device, UDP encapsulation is automatically enabled. Enabled—When the VPN server is behind a firewall, firewall configuration is simplified as the firewall only has to allow ports 500 (IKE) and 4500 (IKE and UDP-encapsulated ESP). Disabled (Default)—When disabled, port 50 must also be allowed for the ESP protocol to pass. Note: This setting can usually be left at default. Do not use if the gateway is IPv6.
IKE Key Lifetime (seconds)	Sets the lifetime for the IKE Security Association (SA). After this time expires, a new SA is negotiated, either by re-keying (IKEv2) or re-authentication (IKEv1). Range: 180–86400 (default 7200) Note: Either end may initiate the negotiation; both ends need not agree.

Field	Descriptio	n	
ESP Key Lifetime (seconds)	negotiated b		ociation (SA). After this time expires, a new SA is
	Note: Eithe	r end may initiate the negotiat	tion; both ends need not agree.
Perfect Forward Secrecy (PFS)	 Perfect Forward Secrecy (PFS) is enabled by default. Options are: Disabled Enabled (default) 		
Network			
Local Address Type	Use the	c information of the device. Op Host Subnet Address or Subnet (default)	otions are:
Local Address/Subnet	If Specify Ac notation; for	ddress or Subnet is selected, o example, 192.168.13.0/24.	enter the local address or subnet in CIDR
	Note: More than one local address/subnet is not supported.		
Remote Address/ Subnet List	server. Thes gateway. Note that yo	se addresses/subnets will be a ou can only have one remote a	on) of the device(s) connected to the remote VPN accessible from any hosts connected locally to the address of 0.0.0.0/0 for all the VPNs.
		ore or after commas.	omma-separated list, ensuring that there are no
	Default valu	es are:	
	VPN	Remote Address	
	1	10.11.12.0/24	
	2	10.11.13.0/24	
	3	10.11.14.0/24	
	4	10.11.15.0/24	
	5	10.11.16.0/24	
Remote Address/ Subnet Exemption	Comma-sep	parated list of Remote Address	ses or subnets (in CIDR notation) to be exempted
List		subnets or addresses as a co pre or after commas.	omma-separated list, ensuring that there are no

Field	Description		
Exempt ALMS and AMM Server Traffic From Tunnel	 Selects whether or not to exclude ALMS and AMM server traffic from the tunnel. You may enable this setting if the addresses of the ALMS/AMM servers are within the range of the remote subnet(s), and the remote server is not configured to route this traffic to the ALMS/ AMM servers. Disable (default) Enable 		
Gateway Virtual IP Type	 Appears when IPsec Local Termination is set to Host. Selects how the virtual IP address is assigned. Automatic—The RV55 receives the virtual IP address dynamically from the VPN server (default when IKEv2 is used). Manual—Manually assign the virtual IP address. Note: You can select Automatic for the Gateway Virtual IP Type only when IKEv2 is used. When IKEv1 is used, Manual is the only option available.		
Gateway Virtual IP	Appears when IPsec Local Termination is set to Host and Gateway Virtual IP Type is Manual. Enter the virtual IP address of the VPN server. Default value is 0.0.0.0.		
	Note: The default value is not a valid IP address. To create a working VPN tunnel, you must enter an IP address according to your network's design.		
Authentication			
Authentication Method	 Pre-shared Key Certificate When Pre-shared Key is selected, the Authentication settings appear as in Figure 7-7. When Certificate is selected, the Authentication settings are as shown below. 		
	Value for Mallina Value for Mallina Value for Mallina Value for Mallina Loss CA Cardificase Loss CA Cardificase Consulta and Local Cardificate Task Local Cardificate Final Local Cardificate Ray Task Local Cardificate Ray Final Local Cardificate Ray Task Local Local Cardificate Ray Final Local Cardificate Ray Task Local Local Ray		
Load CA Certificate	Loads the server root CA (Certificate Authority) certificate. When you click the button, a window pops up and enables you to browse and select the file containing the root CA certificate. For more information, see Loading Certificates and Certificate Keys on page 204.		
Currently installed CA Certificate	Displays the filename of the most recently uploaded root certificate		
Load Local Certificate	Loads the client certificate. For more information, see Loading Certificates and Certificate Keys on page 204. When you click the button, a window pops up and enables you to browse and select the file containing the client certificate.		

Local CertificateLoad Local CertificateKeyCurrently installedLocal Certificate KeyRemote CertificateIdentity	Displays the filename of the most recently uploaded client certificate. Loads the client certificate key. For more information, see Loading Certificates and Certificate Keys on page 204. When you click the button, a window pops up and enables you to browse and select the file containing the client certificate key.	
Key Comparison Currently installed Local Certificate Key Comparison Remote Certificate Identity End	Certificate Keys on page 204. When you click the button, a window pops up and enables you to browse and select the file	
Currently installed Local Certificate KeyCRemote Certificate IdentityE		
Local Certificate KeyRemote CertificateIdentity		
Identity i	Displays the filename of the most recently uploaded client certificate key	
My Identity Type	Enter the remote certificate identity, or leave this field blank to accept any remote certificat identity.	
	Appears when the Authentication Method is Pre-shared Key. Sets the host authentication ID. Options are:	
•	 IP (default)—IP address of the active WAN link. This could be the static IP assigned to your SIM. 	
•	Custom	
My Identity - IP	The WAN IP address assigned by the carrier appears.	
My Identity - Custom	Enter your own custom name.	
1	Note: If you are using a FQDN for your device (My Identity Type) either:	
•		
	page 169.) or	
•	Use a DNS server as your domain host	
Peer Identity Type	Required in some configurations to identify the peer side of a VPN connection. Options are IP (default)	
•		
Peer Identity - IP	Normally, this shows the same address as the gateway.	
Peer Identity - E Custom	Enter your own custom name.	
	This field appears only if the Authentication Method is Pre-shared Key. The pre-shared key (PSK) is used to authenticate the VPN tunnel.	
•	 Pre-shared key length: Maximum supported length is 128 characters. 	
•	 Valid characters are: 1234567890abcdefghijkImnopqrstuvwxyzABCDEFGHIJKLM NOPQRSTUVWXYZ!%-~@#\$^{^*} 	
•		
IKE Security or IKE Secu	rity (FIPS) (when FIPS Mode is enabled)	
	vs in the IKE Algorithms table. Each row is called a proposal. This enables the client and	

with the weakest ones in the last proposal.

Note: Algorithms marked with a *, such as *3DES and *MD5, are intended for backwards compatibility and should not be used for new installations. These algorithms are not available in FIPS mode.

Field	Description	
IKE Encryption Algorithm	Determines the type and length of encryption key used to encrypt/decrypt IKE packets. Options are: Not Used, *3DES, AES-128, AES-192, AES-256, and AES-256gcm16 (IKEv2 only)	
IKE Authentication Algorithm	Determines the type and length of digest used for authentication. Options are: Not Used, *SHA1, *MD5, SHA512, SHA384, SHA256	
IKE Key Group	 Use this field to select the DH (Diffie-Hellman) group key length used for authentication. Options are: Not Used, DH21 (ecp521), DH20 (ecp384), DH19 (ecp256), DH26 (ecp224), DH18 (modp8192), DH17 (modp6144), DH16 (modp4096), DH15 (modp3072), DH14 (modp2048), *DH5 (modp1536), *DH2 (modp1024), *DH1 (modp768) 	
You can define up to three r server to negotiate which all with the weakest ones in the	bled or ESP Security (FIPS)-PFS Enabled (when FIPS Mode is enabled) rows in the ESP Algorithms table. Each row is called a proposal. This enables the client and gorithms to use. Normally, the most secure algorithms would be selected in the first proposal, e last proposal.	
-	orithms are not available in FIPS mode.	
ESP Encryption Algorithm	Determines the type and length of encryption key used to encrypt/decrypt ESP (Encapsulating Security Payload) packets. Options are: Not Used, *3DES, AES-128, AES-192, AES-256, AES-256gcm16, and null (used for testing purposes only—packets are not encrypted)	
ESP Authentication Algorithm	Determines the type and length of digest used for authentication. Options are: Not Used, *SHA1, *MD5, SHA512, SHA384, and SHA256	
ESP Key Group	Use this field to select the DH (Diffie-Hellman) group key length used for authentication, or to disable Perfect Forward Secrecy (PFS).	
	Note: This solumn does not annear when Perfect Ferward Searcey (PES) is disabled	
	Note: This column does not appear when Perfect Forward Secrecy (PFS) is disabled.	
	The DH group number determines the length of the key used in the key exchange process. Longer keys are more secure, but take longer to compute. Also note that both peers in the VPN exchange must use the same DH group.	
	The DH group number determines the length of the key used in the key exchange process. Longer keys are more secure, but take longer to compute. Also note that both peers in the	
	The DH group number determines the length of the key used in the key exchange process. Longer keys are more secure, but take longer to compute. Also note that both peers in the VPN exchange must use the same DH group. PFS is enabled by default. It adds additional security because each session uses a unique temporary public/private key pair to generate the shared secret. One key cannot be derived from another. This ensures previous and subsequent encryption keys are secure,	

GRE

The AirLink gateway can act as a Generic Routing Encapsulation (GRE) endpoint, providing a means to encapsulate a wide variety of network layer packets inside IP tunneling packets. With this feature you can reconfigure IP architectures without worrying about connectivity. GRE creates a point-to-point link between routers on an IP network.

Note: Only one GRE tunnel can be configured at one time.

To configure GRE:

- **1.** In ACEmanager, go to VPN.
- 2. Select the VPN you want to configure (1, 2, 3, 4, or 5).
- **3.** In the VPN Type field, select GRE Tunnel. The screen expands to show the GRE fields.

		Transition (1997) (1994) (1994)
	(2) here	
allows/	Sector and	
-	WE APPE 1 Type	OR Seven +
	WT MPN 1 Station	Not Concerned
6.81		
1953	11 General (1996)	
	W APRILIANS Address	209.81.123.21
VPR-8	- Hermite Address Tape	Same Arrest -
18.5	AT Remote Address	10.11.12.0
	W Hamila Address - Netwark	255 255 255 8
	W Handaline Period (parameter	0
	Al Norgalive Roman	6
	GRE TTL	755

Figure 7-8: ACEmanager: VPN > VPN1 > GRE Tunnel

- 4. See the following table for instructions on completing the GRE fields.
- 5. Once the configuration is complete, click Apply and reboot the AirLink RV55.

Field	Description
Туре	
VPN # Type	Options are: Tunnel Disabled or GRE Tunnel. Enabling the GRE Tunnel will expose other options for configuring the tunnel.
VPN # Status	Indicates the status of the GRE tunnel on the device Options are: Disabled, Connected or Not Connected
General (GRE)	
VPN Gateway Address	The IP address of the device that this client connects to. This IP address must be open to connections from the device.

Field	Description
Remote Address Type	The network information of the GRE server behind the GRE gateway
Remote Address	The IP address of the device behind the gateway
Remote Address - Netmask	The subnet network mask of the device behind the GRE gateway
	Note: Never use a 16-bit subnet mask: GRE tunnel establishment will fail.
Keepalive Period (seconds)	The amount of time to wait for a GRE keepalive packet from the VPN server gateway. If at least one packet is received within this time, the GRE tunnel status (VPN # Status) is "Connected".
	Note: The VPN server must have its keepalive functionality enabled.
	Options are: 0–65535, 0 default (disabled)
Keepalive Retries	The maximum number of GRE keepalive packet tracking timeouts before the GRE tunnel status (VPN # Status) becomes "Not Connected". Options are: 0–65535, 5 default
GRE TTL	GRE time to live (TTL) value is the upper bound on the time that a GRE packet can exist in a network. In practice, the TTL field is reduced by one on every router hop. This number is in router hops and not in seconds.

OpenVPN Tunnel

Note: OpenVPN Tunnel configuration is only available on VPN 1.

OpenVPN uses SSL/TLS to facilitate key exchange and supports up to 256-bit encryption. OpenVPN is capable of crossing network address translators (NATs) and firewalls. Peers can authenticate each other using pre-shared keys, certificates, or username and password.

The AirLink gateway client authenticates the server using a PKI certificate. The server likewise authenticates the client. The Root CA certificate for the server certificate must be loaded on the device.

To configure an OpenVPN tunnel:

- **1.** In ACEmanager, go to VPN.
- 2. Select the VPN 1.
- **3.** In the VPN Type field, select OpenVPN Tunnel. The screen expands to show the OpenVPN Tunnel fields.

et address to dopped	242,000		Experience Apply Talanta Case
General			
2- 1-2-11/10/11	11700		
Split Narred	WT VENU X Xype	CoamiPN Turnel +	
Fallerver	all years status	Not Connected	
Antes a			
	1 2 General (OperWPR)		
AlaM 3	OpenW91 Role	Chert	
VPH 2	Turnet Mitche	Rentry	
CLD 0-7	Pretamid	LOP	
VPH 4	Pass Put	9300	
VPN 3	Peni Merity	0.9.0.0	
	Enclyption Algorithm	Bundish +	
	Auflustic plus Algorithm	(844.1 ···	
	Compression	120 +	
	Load Next Certificate	Example in the Court of the	
	Rost Cartificate Name		
	Clean Certificate	Erstin +	
	Load Clevel Centrole	Land Clinic Continue	
	Class Cecilizate Name		1
	Load Over Cetilicate Kay	Land Chara Calible at	n Koy
	Diett Cetificate Ney Illana		
	User Name		
	User Password		
	User NamicPassened Retry	Deatth -	
	Additional TLB Authoritication	Engine +	
	Load Clant TLS Key	Line Clinit 11.5 West	1
	Chert TLII Kay Name		
	Server Castilizatia Wetlication	143 Cet Type	
	() Abuncat		
	Report MTU	1500	
	MBB Fie	1400	
	Fagnet	1300	
	Allow Pree Dynamic IP	Emitte v	
	Re-regatation (seconds)	36400	
	Fing internal (backweis)	10	
	Savel Restat (seconds)	60	
	144T	Engin -	

Figure 7-9: ACEmanager: VPN > VPN 1 > OpenVPN Tunnel

- 4. See the following table for instructions on completing the OpenVPN Tunnel fields.
- 5. Once the configuration is complete, click Apply and reboot the AirLink gateway.

Field	Description	
General		
VPN 1 Type	Options are: Tunnel Disabled or OpenVPN Tunnel. Enabling the OpenVPN Tunnel will expose other options for configuring the tunnel.	

Field	Description	
VPN 1 Status	Indicates the status of the OpenVPN tunnel on the device	
	Options are: Disabled, Connected or Not Connected	
General (OpenVPN)		
OpenVPN Role	The AirLink gateway can only be an OpenVPN client. Default: Client	
Tunnel Mode	The Tunnel Mode is set to "Routing".	
Protocol	Displays the protocol used for configuration. Only supports UDP	
Peer Port	The Peer Port is the UPD port on the peer device.	
Peer Identity	Enter the IP address or Fully Qualified Domain Name (FQDN) of the peer device.	
Encryption Algorithm	Options are: DES, Blowfish, DES, Cast128, AES-128, and AES-256	
Authentication Algorithm	Options are: MD5, SHA-1, and SHA-256	
Compression	Options are: LZ0 or NONE	
Load Root Certificate	Loads the server root CA (Certificate Authority) certificate.	
	When you click the button, a window pops up and enables you to browse and select the file containing the root CA certificate. For more information, see Loading Certificates and Certificate Keys on page 204.	
Root Certificate Name	Displays the name of the most recently uploaded root certificate	
Client Certificate	Enables or disables use of a client certificate.	
Load Client Certificate	This field appears only if Client Certificate is enabled. Loads the client certificate. When you click the button, a window pops up and enables you to browse and select the fil containing the client certificate. For more information, see Loading Certificates and Certificate Keys on page 204.	
Client Certificate Number	Displays the number of the most recently uploaded client certificate.	
Load Client	This field appears only if Client Certificate is enabled. Loads the client certificate key.	
Certificate Key	When you click the button, a window pops up and enables you to browse and select the file containing the client certificate key. For more information, see Loading Certificates and Certificate Keys on page 204.	
Client Certificate Key Name	Displays the name of the most recently uploaded client certificate key	
User Name	The user name required for client authentication	
User Password	The user password required for client authentication	
User Name/Password Retry	Enables or disables retries if there is an authentication error after entering credentials.	
Additional TLS Authentication	Enables or disables use of Transport Layer Security (TLS) authentication.	

Field	Description	
Load Client TLS Key	This field appears only if Additional TLS Authentication is enabled. Loads the client TLS key. When you click the button, a window pops up and enables you to browse and select the file containing the client TLS key. For more information, see Loading Certificates and Certificate Keys on page 204.	
Client TLS Key Name	Displays the name of the most recently uploaded client TLS key.	
Server Certificate Verification	 Selects the method used to verify the server certificate. Options are: NS Cert Type Key Usage/Extended Key Usage 	
Advanced		
Tunnel-MTU	Default: 1500 bytes	
MSS Fix	Default: 1400 bytes	
Fragment	Default: 1300 bytes	
Allow Peer Dynamic IP	Options are: Enable or Disable	
Re-negotiation (seconds)	Default: 86400 (24 hours)	
Ping Interval (seconds)	Sets the keep-alive sent by the client. Default: 10 seconds	
Tunnel Restart (seconds)	Enter the time (in seconds) for a tunnel restart. Default: 60 seconds	
NAT	Enables or disables the Mobile Network Operator NAT (note: not a local NAT).	

Loading Certificates and Certificate Keys

Note: The certificate and certificate key must meet the following conditions:

- The certificate must be an X.509 certificate
- The certificate and the private key must be in .pem format, and they must be in separate files.
- There is no limit to the size of the private key, but the larger the key, the more the performance is affected. Sierra Wireless recommends that the key does not exceed 2048 bits.

Note: The RV55 supports pre-defined cipher suites using 128-bit cipher algorithms.

To load a certificate or certificate key:

1. Click the button for the type of certificate or key you want to upload.

Coar VTN Fole	Class
ugende nie nade Landel Maste	suer: Pering
Huah sad	10 M
Pres Data	9300
How Mariak	0.000
Encryption Alcolithm	LOVER M
An dis related as Alagorithms	511A1 V
Second and a second	LACE A
Loud Foce Centre an	Load Roos Certificate
Real Calification Conce	
Clene Certificate	unacity in
has the device in the set	the solution of the line for
Genel Challenge (Kanasa	
Lood Client Cerlificare Key	Load Clean Cardinase Key
Genel Chatchad a Kory Panner	
Uner Nome	
Ren Pressent	
Sound from an two second of the large	Description of
Additional TLC Authentication	LINE H
Laze I Claudi I I O Keny	Tree Manual 11 S Ray
Client TLC Key Name	
A sea Cost dest a Verdent en	March 6 Spec

2. Click Browse... and then select the appropriate file for your device. (Loading a Root Certificate is shown below.)

Load Root Certificate	Close
UpLoad Cettificate	
Select a Certificate file : Browse No file selected.]
Upload File to Device	

3. Click Upload File to Device.

>> 8: Security Configuration

The Security tab covers firewall-type functions. These functions include how data is routed or restricted from one side of the device to the other, i.e., from computers or devices connected to the device (LAN) and from computers or devices contacting it from a remote source (WAN). These features are set as rules.

Tip: For additional security, Sierra Wireless recommends that you change the default password for ACEmanager. See Change Password on page 369.

Solicited vs. Unsolicited

How the device responds to data being routed from one network connection to the other depends on the origin of the data.

- If a computer on the LAN initiates a contact to a WAN location (such as a LAN connected computer accessing an Internet web site), the response to that contact is solicited.
- If, however, a remote computer initiates the contact (such as a computer on the Internet accessing a camera connected to the device), the connection is considered unsolicited.

Port Forwarding

In Port Forwarding, any unsolicited data coming in on a defined Public Port is routed to the corresponding private port and IP of a host connected on the LAN. You can forward a single port or a range of ports.



Figure 8-1: Port Forwarding

Note: You can set up a maximum of 48 port forwarding rules, 24 on the Port Forwarding screen and an additional 24 on the Extended Port Forwarding screen.

Single port

To define a port forwarding rule for a single port:

- 1. In ACEmanager, go to Security > Port Forwarding.
- 2. In the Port Forwarding field, select Enable.
- 3. Click "Add More" to display a rule line.

ford Forecasiding		Host Enabled		Deate v				
standed Part Forwarding	Pot/Forwarding touter +							
fatt Tübering - Indepand	Port Forwarding							
Part range ranne		Public Start Part	Public End Part	Protocal	Heat P	Private Start Port		
full fillering - Delboard		8080	0	YOF & LEP	192 168 13 100	80		
raded Ps. Ideand (Heeds)		and the second sec				And there		
liceled iPs - Outbeard								

Figure 8-2: ACEmanager: Security > Port Forwarding (Single Port)

4. In the Public Start Port field, enter the desired public network port number. Values between 1 and 65535 are supported, although Sierra Wireless recommends using a value greater than 1024.

Unsolicited data coming in on this port is forwarded to the port you select in the Private Start Port field.

- 5. In the Public End Port field, enter 0.
- 6. Select the desired protocol (see Protocol on page 210):
 - TCP
 - UDP
 - · TCP & UDP
- 7. Enter the IP address of the computer you want to forward data to.
- **8.** In the Private Start Port field, enter the number of the port on the destination computer that you want to forward data to.
- 9. Click Apply.

You do not need to reboot immediately, if you have additional changes to make, but port forwarding does not take effect until the device is rebooted.

The Port Forwarding screen allows for 24 port forwarding rules.

10. Optional—If you need additional port forwarding rules, click Extended Port Forwarding on the left menu, and continue adding rules, up to a total over both screens of 48.

Allasting and the sound clean					102	In Passad Law
Part Forwarding		led Part Forwarding				
Lansaded Part Forwarding		Peter Start Part	Public End Port	Protocol	Haved UP	Private Start Port
Part Fillering - Jackwood		9080	9095	10P w	192 168 13 101	80
Port Filering - Delbandi Trasled IPs - Internet & newtraj Trasled IPs - Chilbourit	L					Add Moor

Figure 8-3: ACEmanager: Security > Extended Port Forwarding

11. Reboot.

Range of ports

To define a port forwarding rule for a range of ports:

- 1. In ACEmanager, go to Security > Port Forwarding.
- 2. In the Port Forwarding field, select Enable.

						all Anna Carr		
but large the		kest Enabled		Danie w				
advantual Port Tarwarding	Part	orwarding		Eryster -				
fort littering - tabased	PortForwarding							
FOR CONTRACT OF CONTRACT		Poblic Sliert Port	Public End Port	Protocal	Hoat #P	Private Start Part		
Port Fillering Durbound		8080	0	1075-009-1-	192,168 13 100	-80		
trasted iPs . Intrasted (Friendu)		15001	15010	107.000	192 108 13 101	5001		
hashed iPa - Outbrand						Add Mare		

Figure 8-4: ACEmanager: Security > Port Forwarding (Port Range)

- 3. Set the port range for incoming data:
 - **a.** In the Public Start Port field, enter the desired public network port number. Values between 1 and 65535 are supported, although Sierra Wireless recommends using a value greater than 1024.
 - **b.** In the Public Port End field, enter the last public network port number in the range. The value you enter in the Public Port End field must be greater than the value in the Public Start Port field, or ALEOS rejects the selection.

Unsolicited data coming in on ports in this range are forwarded to a range of ports, starting with the port you select in the Private Start Port field.

- 4. Select the desired protocol (see Protocol on page 210):
 - TCP
 - · UDP
 - TCP & UDP
- 5. Enter the IP address of the computer you want to forward data to.

To forward a port to a local ALEOS Service, set the Host IP to 127.0.0.1.

- **6.** In the Private Start Port field, enter the starting port number for the range of ports on the destination computer that you want to forward data to.
- 7. If you want to add another range, click Add More to display a new rule line.
- 8. Click Apply.

The Port Forwarding screen allows for 24 port forwarding rules.

9. Optional—If you need additional port forwarding rules, click Extended Port Forwarding on the left menu, and continue adding rules, up to a total over both screens of 48.

ah pagear Anna 2020019 4,1012							Course of	101418 24
fort farwarding	Extent	led PortForwarding						
Conduct Part Forwarding		Public Start Port	Public End P	ort Pro	tocel	Hust P	Pes	valu Start Port
Part fillering - Indused		9090	9095	TUP		192,168,13,1	01 00	
Part Hiltoring - Detbound Trusted IPs. Jackcond (Friends) Trusted IPs. Jackcond RAC: Hiltoring								And they

Figure 8-5: ACEmanager: Security > Extended Port Forwarding

10. Reboot.

You do not need to reboot immediately, if you have additional changes to make, but port forwarding does not take effect until the device is rebooted.

Note: Sierra Wireless recommends that the total number of port forwardings be fewer than 1000 ports, including single port forwarding and port forwarding within a range.

Field	Description
Port Forwarding	Enables port forwarding rules. Options are Enable and Disable (default).
Public Start Port	 Port on the public network or starting port on the public network for a range of ports. Supported values: 1–65535 (Recommended values: greater than 1024)

Field	Description
Public End Port	 Ending port for a range of ports on the public network. For a single port forwarding, this field must be 0. For a range of ports, this value must be greater than the value in the Public Start Port field.
Protocol	 The protocol to be used with the forwarded port: TCP—Only unsolicited data requests using TCP are forwarded UDP—Only unsolicited data requests using UDP are forwarded TCP & UDP—Unsolicited data requests using either TCP or UDP are forwarded
Host IP	IP address of the computer (or device) you want to forward data to.
Private Start Port	Port on the destination computer used as the port for single port forwarding rules, or as the start port for a port forwarding range.

Port Forwarding Example

The following example shows you how to configure a port forward rule for a range of 6 ports on an Ethernet-connected device:

- 1. In ACEmanager, go to Security > Port Forwarding, and enable Port Forwarding.
- 2. Click "Add More" to display a rule line.
- 3. Enter 8080 for the Public Start Port.
- 4. Enter 8085 for the Public End Port.
- 5. Select TCP & UDP.
- 6. Enter 192.168.13.100 as the Host IP.
- 7. Enter 80 as the Private Start Port.

straining straining a 1999	11				10	an needs for
Part Networking	DM2	Hurt Esabled		Dante -		
Calender Part Turwalding	Put Fares Drg Crate v					
Part Hibeing - Ribeinstel	Peth	orwarding				
set out all second		Public Start Port	Peblic End Part	Protocal	Host IP	Private Start Port
Part Hillaring - Coldinand		8080	0	TOPAUM +	192 168 13 100	80
fixeled IPs - Mound (Friends)						and Mare
Itseled 84s - Outband						
MAC Fillening						

Figure 8-6: ACEmanager: Port Forwarding example

- 8. Click Apply.
- 9. Reboot.

You do not need to reboot immediately, if you have additional changes to make, but port forwarding does not take effect until the device is rebooted.

An unsolicited TCP and UDP data request coming in to the AirLink gateway on port 8080 is forwarded to the LAN connected device, 192.168.13.100, at port 80. In addition, unsolicited data requests coming in from the Internet on ports 8081, 8082, 8083, 8084, and 8085 are forwarded to ports 81, 82, 83, 84, and 85 respectively.

DMZ

The DMZ is used to direct unsolicited inbound traffic to a specific LAN device such as a computer running a web server or other internal application. The DMZ with public mode is particularly useful for certain services like VPN, NetMeeting, and streaming video where the remote server may require a WAN connection to the LAN device rather than being NATed by the router.

Options for DMZ are Automatic, Manual, and Disable (default is Disable).

Automatic uses the first connected device. If more than one host is available (multiple Ethernet on a switch connected to the device and/or Ethernet with USBnet) and you want to specify the host to use as the DMZ, select Manual and enter the IP address of the desired host.

					1	A Desired Street	
fort Forwarding	0.0623	out Enabled		Automatic •	ŝ.		
Extended Port Forwarding	[3M2.)	ost Filo use		182 Mil 14 100			
Part Fillering - transmit	PortForwardeg Double +						
	Port F	orwarding					
Port Filtering - Outbound		Public Start Port	Public End Port	Protocol	Host #	Private Start Port	
Trusted IPs - Iniscund (Friende)		8080	0	TOP & LOP -	192.168.13.100	80	
	-					Auto Morre	
Trusted IPs - Outbound							

Figure 8-7: ACEmanager: Security > Port Forwarding (DMZ)

Field	Description
DMZ Host Enabled	 The AirLink gateway allows a single client to connect to the Internet through a demilitarized zone (DMZ). Options are: Automatic—enables the first connected device or the Public Mode interface as the DMZ
	Note: In order for IP Passthrough to work, and for inbound packets to be forwarded to the LAN interface or device, DMZ Host Enabled must be set to Automatic.
	 Manual—inserts a specific IP address in the DMZ IP field Disable—no connected device receives unsolicited traffic from the cellular network or Internet (default)
DMZ Host IP	This field only appears if Manual is selected for the DMZ Enabled field. It is the IP address of the private mode host that should be used as the DMZ.
DMZ Host IP in use	IP address of the host to which inbound unsolicited packets are sent When the device passes the Network IP to the configured public host, the DMZ IP in Use displays the public IP.

Example of configuring the DMZ on an Ethernet connected device:

- 1. In the DMZ Host Enabled field, select Manual.
- 2. Enter 192.168.13.100 for the DMZ IP.
- **3.** Select Ethernet as the Default Interface.

An unsolicited data request coming in to the AirLink gateway on any port is forwarded to the LAN device, 192.168.13.100, at the same port.

Note: The DMZ settings are independent of the number of Port Forward entries and can be used with port forwarding to pass anything not forwarded to specific ports.

Port Filtering—Inbound

Port Filtering—Inbound restricts unsolicited access to the AirLink gateway and all LAN-connected devices.

You can enable Port Filtering to either block or allow specified ports. When enabled, all ports not matching the rule are allowed or blocked depending on the mode.

You can configure Port Filtering either on individual ports or for a range of ports. Click Add More for each port filtering rule you want to add.

Note: Inbound restrictions do not apply to responses to outbound data requests. To restrict outbound access, you need to set the applicable outbound filter.

of cardwing parts, 72,222,000 16,1223	UNIC .				Carlo State		
Part Porventing	-						
end rarmining	WARNING Se	electing Alloweri Plarts will "black" all p los nomille management, the allowed p	corts not allowed, and will "prevent re ports hat straugh include 2008, 17539	note access? If the manager 17335, and ACEmanager 201	well ports are no		
Extended Port Farwarding	The user has selected for ACEmanager)						
feet Pittering - Inteland	Inbound Purt	ridering Mode	Deatest .				
	Filtered Ports						
Part Filtering - Outsound	1	Start Port		End Port			
		8000	1	9191			
Trusted IPs - Insound (Priende)				1.771.002			
Trusted IPs - Inisbund (Priende) Trusted IPs - Outbound		17336		17330			

Figure 8-8: ACEmanager: Security > Port Filtering - Inbound

Field	Description
Inbound Port Filtering Mode	 Options are: Disable (default) Blocked Ports—ports through which traffic is blocked (Shown in Filtered Ports list) Allowed Ports—ports through which traffic is allowed (Shown in Filtered Ports list)
Filtered Ports	
Start Port	A single port or the first port in a range of ports on the public network (mobile network accessible)
End Port	The end of the range on the public network (mobile network accessible).

Warning: Selecting Allowed Ports will *block* all ports not allowed, and will *prevent remote access* if the management ports are not allowed. To allow remote management, the allowed ports list should include 8088, 17339, 17336, and ACEmanager port 9191 (or the port you selected for ACEmanager).

Port Filtering — Outbound

Port Filtering—Outbound restricts LAN access to the external network, i.e., the Internet.

Port Filtering can be enabled to block ports specified or allow specified ports. When enabled, all ports not matching the rule will be allowed or blocked depending on the mode.

Port Filtering can be configured on individual ports or for a range of ports. Click Add More for each port filtering rule you want to add.

Note: Outbound restrictions do not apply to responses to inbound data requests. To restrict inbound access, you need to set the applicable inbound filter.

tatus IRAN/Celtular WI-P)	LAN	7641	Security	Services	Constant	Events Reporting	Satisf	Applications	9D	Aimir	
et sanlatest linus - School on yor ha rig	NIC							- Anno		it inte	
Port Forwarding	Outrop	d Pat File	ring Node			Daalle					
Extended Port Porwarding	Fillered Ports										
fort Fillering - Inbound	1			Blant Port			End Port				
And the second character			7077				70	15			
Part Fillening - Outbound	_									ADE More	
Rusted IPs - Inbound (P/Ienda)											
Nusted IPs - Outboard											
MAC Filtering											

Figure 8-9: ACEmanager: Security > Port Filtering - Outbound

Field	Description
Outbound Port Filtering Mode	 Allowed and blocked ports through which traffic is either allowed or blocked (respectively) are listed. Options are: Disable (default) Blocked Ports—ports through which traffic is blocked (Shown in Filtered Ports list) Allowed Ports—ports through which traffic is allowed (Shown in Filtered Ports list) Note: Outbound IP filter supports up to 9 ports.
Start Port	The first of a range or a single port on the LAN
End Port	The end of the range on the LAN

Trusted IPs—Inbound (Friends)

Trusted IPs—Inbound restricts access to the AirLink gateway and all LAN connected devices.

Tip: Trusted IPs-Inbound was called Friends List in legacy AirLink products.

When enabled, IP packets with a source address not matching those in the list or range of trusted hosts will be ignored/dropped by the gateway.

Note: Inbound restrictions do not apply to responses to outbound data requests. To restrict outbound access, you need to set the applicable outbound filter.

Vapolis/104 71502064.08.217	N			Course of C	1999) (2010					
for formality	AT Internal Trust	eri IP (Prenda Liet) Mada	Desire							
amount Part Forwarding	Informed IP Lin:									
fort Filtering - Informati										
and a second second										
orr Filtering - Outbound	Inboaid Traited IP Range									
name Ph. Stowest (Friends)		Range Start	100	Range End						
name Ph. Dationand	Defined 64.100.10.2 64.100.10.16									
ACTIVA DE SACINA DE LA	-				that More					

Figure 8-10: ACEmanager: Security >Trusted IPs - Inbound (Friends)

Field	Description					
Inbound Trusted IP (Friends List) Mode	Disables or Enables port forwarding rules. Options are Disable (default) or Enable.					
Inbound Trusted IP List	Enter a single trusted IP address for example 64.100.100.2. Click Add More to add additional IP addresses to the list.					
Inbound Trusted IP Range	Use this section of the page to enter a range of trusted IP addresses.					
Range Start	Specify the start and end IP addresses for the trusted IP address range, for example,					
Range End	entering 64.100.10.2 as the Range Start and 64.100.10.15 as the Ranges End would allow 64.100.10.5 but would not allow 64.100.10.16.					

Trusted IPs—Outbound

Trusted IPs—Outbound restricts LAN access to the external network (Internet).

When enabled, only packets with the destination IP addresses matching those in the list of trusted hosts will be routed from the LAN to the external location.

Note: Outbound restrictions do not apply to responses to inbound data requests. To restrict inbound access, you need to set the applicable inbound filter.

Inter WolleCetteter Wolff	1.01	3996	sacruat	Services	Location	Events Reporting	statel.	Applications	10	Admin
r spinier tear 2000/2011 rt. 52.53	Auto-							ALC: N		- 20
fort Forwanting	O/tro	nd Firewal	Made			Deater				
Extensies Part Forwarding	Outbeu	and Thuste	e IP Lint							
						Trusted IP				
Port Fillering - Inbound					6	100.10.25				
on Fillening - Outbound										Add More
Nusled IPs - Intround (Priends)										
fusted Ps - Dutbound										
AAC Filtering										

Figure 8-11: ACEmanager: Security > Trusted IPs - Outbound

Field	Description
Outbound Firewall Mode	 Disables or enables the Outbound Firewall Options are: Disable (default)—Allows all outbound traffic Enable—Only outbound traffic destined for an IP address on the Trusted IP list is allowed. All other outbound traffic is blocked.
Outbound Trusted IP List	Each entry can be configured to allow a single IP address (e.g., 64.100.100.2) Click Add More to add additional IP addresses to the list.

MAC Filtering

MAC filtering restricts LAN connection access. You can create a list of up to 20 devices that are allowed a connection based on their MAC address. When MAC filtering is enabled, devices not on the allowed list are explicitly blocked. Hosts directly connected to the device but not in the Allowed list may show an active physical connection, but are blocked from sending traffic of any kind to the device or any other host connected to the device.

					Rent	of the same	and the second
fort Formatiling	MAC Filtering			Dualite			
Extended Port Forwarding	MAC Address al	poed List					
Port Fillering - Inbound				MAC ADDIESS			
			01	23 45 67 IIP ab			
fort Filtering - Outbound			193	34 06 78 9a bc			
Nuxted IPe - Indound (Privenda)						1	Age More
Susteil IPs - Outbountil							

Figure 8-12: ACEmanager: Security > MAC Filtering

Field	Description
MAC Filtering	Enable or disable (default) MAC Filtering
MAC Address allowed List	Allows devices with the MAC Addresses listed to connect to the host and transfer data. Add MAC addresses by clicking on the Add More button. When adding MAC addresses, use a colon between the digit groups, for example 01:23:45:67:89:ab.
	Note: After adding all the desired MAC addresses, reboot the device. The MAC Address allowed List takes effect after the device is rebooted.
MAC Address	This is the MAC Address of the interface adapter on a computer or other device.
	Tip: You can use the Status > LAN IP/MAC Table page to obtain the MAC addresses of DHCP connected devices.

>> 9: Services Configuration

The Services tab sections allow the configuration of external services that extend the functionality of the AirLink RV55.

These services include:

- ALMS (AirLink Management Service)
- ACEmanager
- Power Management
- Dynamic DNS
- SMS
- AT (Telnet/SSH)
- Email (SMTP)
- Management (SNMP)
- Time (NTP)
- Authentication
- Device Status Screen

ALMS (AirLink Management Service)

d specific ress (2002214-01)	8.44 PW	Canada and Anna Canada
		townshift through the said the
LME .		
CEmanaper -	[1] Amoni Management Service	
C.C. Constanting of	AT ALME Produced	109M2N +
Power Management	Protocor in Cele	UNKOK
lynamic 2015	at Device mitaled interval (mouder)	5440
14-14-14-14-14-14-14-14-14-14-14-14-14-1	AT ALMILITATION	
awa.	AT make	Doobshap: Failure (2)- 000000018 17:53:34
AT (Tohest: \$340	Connet	Committee of the second se
Email (SHITP)	11 MILCI	
Nanagament (SHIP)	AT Samer 1993.	https://www.mit/mep.net/dev
Time (1911)	All Auto Synchronick Configuration	lian -
in the second se	A1 TLS Vanty Peer Certificate	date v
authentication (AT HITSE Gener And ACEvery Services	LAN DHY
Device Statys Screen	[] LAWAGAN	
	Hares filme internal (seconds)	0
	Mixads Register Dis Startup	Date +
	11 AMP	
	ALEOS Application Framework	Exative
	ACIES. Protocol Paraword	
	Marwal Connection: Plates	
	Garrent	(Manual)

Figure 9-1: ACEmanager: Services > ALMS

Field	Description
AirLink Managen	nent Service
ALMS Protocol	 This field is used to select the underlying communication protocol used with ALMS. In most cases, it is best to leave the default settings, but if the gateway is unable to communicate with ALMS, you may need to change this setting. First check to ensure that the gateway is registered on ALMS, and if the default is LWM2M, confirm that the network allows UDP traffic. Options are: LWM2M—Lightweight M2M (default) LWM2M uses DTLS secured communication, with server/gateway mutual authentication, and uses less bandwidth than MSCI. To use LWM2M, the network must allow UDP traffic. MSCI—Multi-Protocol Serial Communication Select this setting if you are using a private server that does not support LWM2M, or the network does not allow UDP traffic. (MSCI uses TCP.) Try LWM2M, Fallback to MSCI After the gateway is powered on or rebooted, and has a WAN connection, it attempts for two minutes to communicate with ALMS using LWM2M. If it is successful, the field is reset to LWM2M. If it is unsuccessful, the field is reset to LWM2M. If it is unsuccessful, the field is reset to LWM2M. Fallback to MSCI. Use this setting if you are unsure whether or not the server being used supports LWM2M.
Protocol in Use	Shows the current ALMS Protocol in use
Device Initiated Interval (minutes)	 This field determines how often the AirLink gateway communicates with ALMS to check for software updates, setting changes, etc. If the protocol in use is MSCI, the gateway sends a check-in message, after which all pending jobs on ALMS are carried out. If the protocol in use is LWM2M, the gateway sends a registration update, after which all pending jobs on ALMS are carried out. ALMS can also query the AirLink gateway at a regular interval if settings allow. Refer to AirLink Management Service documentation for more information. Default: 1440 minutes (24 hours).
ALMS Name	Use this field to assign a name of your choice to the AirLink gateway. This name is used by the ALMS server to identify your device. By default, this field is blank. You can also use an AT command to assign or query the name. See *AVMS_NAME on page 515.

Field	Description
Status	Displays the status of the ALMS connection
	For MSCI:
	Success—Device successfully contacted ALMS during its latest communication
	• Disabled—ALMS communications are disabled. (Appears when the AirLink Management Service drop-down menu is set to Disable.)
	 [ALEOS] Waiting for connectivity — This transitory status appears when the device is in Connect-on-traffic mode and is trying to connect to the network fo an ALMS check-in. (See Always on connection on page 94.) When the device connects to the network, the ALMS check-in is sent and the status changes to Success or an error message, if there is a problem with the connection.
	For a list of MSCI error messages, see page 572.
	For LWM2M:
	 Bootstrap: In Progress [(n)] - date—Gateway is contacting the ALMS bootstra server to get the ALMS server address and corresponding credentials.
	 Bootstrap: Success [(n)] - date—The ALMS server address and credentials has been provisioned.
	Bootstrap: Failure [(n)] - date—Failed to contact the bootstrap server
	 Registration: In Progress [(n)] - date—Gateway is contacting the ALMS serve to register.
	 Registration: Success [(n)] - date—Gateway has successfully registered on the ALMS server.
	 Registration: Failure [(n)] - date—Gateway failed to register on the ALMS server.
	 Registration Update: In Progress [(n)] - date—Gateway is contacting the ALM server to refresh its registration.
	 Registration Update: Success [(n)] - date—Registration has been successfull refreshed.
	• Registration Update: Failure [(n)] - date—Failed to refresh registration
	 Authentication: In Progress [(n)] - date—Gateway is authenticating (ALMS or ALMS bootstrap).
	 Authentication: Success [(n)] - date—Authentication is complete (ALMS or ALMS bootstrap).
	 Authentication: Failure [(n)] - date—Gateway failed to authenticate (ALMS or ALMS bootstrap).
	 Notify: Sent - date—Gateway has successfully sent notifications to the ALMS server.
	Notify: Failure - date—Gateway failed to send notifications to the ALMS server
	In this case the gateway retries to send the notifications following an exponential back-off algorithm.
	 Notify: Rejected - date—The ALMS server has rejected the latest notifications sent by the device.
	In this case the device renews its registration at the next opportunity:
	 At the next expected registration update time
	or
	• If the registration update is requested using the Connect button.
	(n): is optional and represents the retry attempt number. n is between 1 and 5
	date: is the Greenwich Mean Time of the last status update.

Field	Description
Connect	The Connect button enables you to manually connect an AirLink gateway to ALMS. This may be useful for troubleshooting the connection between the platform and the remote device and confirming that AAF scripts or jobs created are executing as expected on ALMS.
MSCI	
Server URL	The ALMS server URL address. By default, this is: https://na.m2mop.net/device/msci/com, which encrypts network traffic from ALEOS to ALMS.
	Using an HTTPS URL enables Transport Layer Security (TLS). When TLS is enabled and the TLS Verify Peer Certificate field is set to Enable, the validity of the server certificate is checked. For more information, see TLS Verify Peer Certificate on page 221.
	Note: The URL from earlier ALEOS versions, http://na.m2mop.net/device/msci, is still valid, but does not use TLS.
Auto Synchronize Configuration	 This field allows you to choose when changes to the configuration are propagated to ALMS. Enable—Changes to the configuration are propagated as soon as possible and do not wait for the next communication period (as configured in the Device Initiated Interval field). This may result in more frequent communication with ALMS. (default)
	• Disable—Changes to the configuration are propagated to ALMS at the device initiated interval rate.
TLS Verify Peer Certificate	 This field has no effect unless an HTTPS URL is used for the Server URL. Using an HTTPS URL (for example, https://na.m2mop.net/device/msci/com) as the server URL enables Transport Layer Security (TLS). When TLS is enabled, use this field to set the TLS certificate validation. Enable—The validity of the server certificate is checked during the TLS negotiation. (default) If the certificate is not valid, communication with the ALMS server is terminated. For more information, see [HTTP] SSL peer certificate or SSH remote key was not OK on page 573. Disable—The validity of the server certificate is not checked during the TLS
	negotiation. The TLS communication proceeds even if the server presents a non-validated certificate.

Field	Description
HTTP Server And ACEview Services	 Allows you to activate the: MSCI server—enables you to configure the gateway remotely using MSCI over HTTP ACEview service—enables the gateway to communicate with the ACEview Windows utility Options are: Disable—Both services are disabled. LAN Only—The MSCI HTTP server and ACEview service are only accessible through a LAN connection. (Default) Both WAN And LAN—The MSCI HTTP server and ACEview service are accessible through both WAN and LAN connections. Note: In order to use MSCI server-initiated communication from ALMS, HTTP Server And ACEview Services must be set to Both WAN And LAN.
AMM Management Tunnel	Appears when the ALMS Protocol is set to MSCI. Enables the RV55 to establish an OpenVPN connection to the AMM server. This OpenVPN connection enables remote SSH and remote ACEmanager access from AMM.
AMM Management Tunnel Port	 Appears when AMM Management Tunnel is enabled. This field sets the port used for the OpenVPN connection to AMM. Options are: 1-65535 (default is 1190) Note: In most cases, you should leave this setting at default. The port number must match the port used for the MSCI OpenVPN management tunnel on the AMM, which is also 1190 by default.
LWM2M Keep Alive Interval (seconds)	Use this field to configure how frequently the gateway pings ALMS to confirm an IP connection. Options are: • 1–3600 • 0—Disabled (Default)

Field	Description
Always Register on Startup	 Use this field to set the gateway's registration behavior on startup: Disable—The gateway performs a registration update. It signals ALMS that it is up and running and refreshes its registration. A registration update consumes far less bandwidth than a registration. (Default) Enable—The gateway performs a LWM2M registration on startup. The gateway declares its capabilities to ALMS and synchronizes its configuration.
AAF	
ALEOS Application Framework	AAF status: Enabled or Disabled. To enable AAF, see ALEOS Application Framework on page 358.
M3DA Protocol Password	M3DA Protocol Password This password must be configured on the AirLink device and on ALMS. The default M3DA password is the default ACEmanager password as shown on the device label.
	Note: This password is reset to default when the device is reset to factory defaults using the hardware Reset button, or using the Reset to Factory Default command in ACEmanager (when the Reset Mode is Preserve Only User Password or Reset All). See Reset to Factory Default on page 379 and Reset Configuration on page 380.
Manual Connection Status	Displays the current manual connection status if AAF is enabled.
Connect	The Connect button enables you to manually connect an AirLink device to ALMS. This may be useful for troubleshooting the connection between the platform and the remote device and confirming that AAF scripts or jobs created are executing as expected on ALMS.

ACEmanager

katas VAN/Colladar	WLEI LAW WYN Decomy Services	Location Events Reporting Tailad Applications 00 Admin
Carried Intel Security	1010 ¹ PB	COMPANY AND TANK COM
LMS.		
(Imanage	[1] General	
T. C.	Remate Access	Death
Aver Mangement	Local Access	Bob HTTP are HTTPS
Ipname: IPAS	WOF AP ACTES	Safe as Local 14
	HTTP Part	0101
DMI15	HITTPS Port	8445
T (Teinet 5-34)	Session title Trescol (minutes)	15
mail (SMTP)	Maximum Linger Alternate	1
	LakAcce Trave (percende)	120
betagerowst (18897)		
mm (1877)	() second	
	Custore Centricate	Draffe -
attentication.	Load Caston Catholia	A new Coloures Common Add.
Jevice Statut Screen	Custors Certificate Name	
	Load Custore Private Kas	E and Country Private Pary
	Conforty Private Key Narry	

Figure 9-2: ACEmanager: Services > ACEmanager

Field	Description
General	
Remote Access	Configure ACEmanager remote access (over the WAN link) Options are: Disable (default) HTTPS Only Both HTTP and HTTPS
Local Access	Configure ACEmanager local access (Ethernet, USBnet, or Serial/DUN) Options are: • HTTPS Only • Both HTTP and HTTPS (default)
Wi-Fi AP Access	Configure ACEmanager Wi-Fi network access (for clients connected to the gateway) Options are: • Same as Local (default) • Disabled
HTTP Port	Configure the HTTP port for ACEmanager access. Reboot the device after applying the port change. Default value is 9191.
HTTPS Port	Configure the HTTPS port for ACEmanager access. Reboot the device after applying the port change. Default is 9443.

Field	Description
Session Idle Timeout (minutes)	 If ACEmanager is idle for the configured timeout, it automatically logs out and returns you to the Login screen. Options are: 0-60 (default is 15) If you set the Session Idle Timeout to zero (0), the session remains active until you manually log out.
Maximum Login Attempts	 Number of failed login attempts allowed before the user account is temporarily locked Options are: 0—The account lock-out feature is disabled. 1–5—Maximum number of failed login attempts before the user account is locked for the length of time specified in the Unlock Time (seconds) field. Default is 3
Unlock Time (seconds)	 The length of time (in seconds) that the user account is locked after the maximum number of failed login attempts (configured in Maximum Login Attempts) Options are: 1–3600 (1 hour) (default is 120 [2 minutes])
Advanced	1
Custom Certificate	 Enabling this feature allows you to load a custom SSL certificate. (Some restrictions apply; see Note below for details.) Options are: Enable—Additional fields appear that allow you to load a custom SSL certificate and a custom private key. The ACEmanager web server uses this custom certificate for authentication during HTTPS communication, instead of the default certificate. Disable—The ACEmanager web server uses the default SSL certificate for authentication during HTTPS communication. (default)
	 Note: The custom certificate and private key must meet the following conditions: The certificate must be an X.509 certificate The certificate and the private key must be in .pem format, and they must be in separate files. There is no limit to the size of the private key, but the larger the key, the more the performance is affected. Sierra Wireless recommends that the key does not exceed 2048 bits. Note: The RV55 supports pre-defined cipher suites using 128-bit cipher algorithms.
Load Custom Certificate	 This field only appears when the Custom Certificate field is set to Enable. To load a custom SSL certificate: Click Load Custom Certificate. Click Browse and navigate to the SSL certificate file. Click Upload file to device. Once you have uploaded the custom certificate and the custom private key, click Apply and reboot the device.

Field	Description	
Custom Certificate Name	This field only appears when the Custom Certificate field is set to Enable. Displays the name of the custom certificate.	
Load Custom Private Key	 This field only appears when the Custom Certificate field is set to Enable. Allows you to enter a custom private key (Some restrictions apply; see Custom Certificate for details.) To load a custom private key: Click Load Private Key. Click Browse and navigate to the private key file. Click Upload file to device. Once you have uploaded the custom certificate and the custom private key, click Apply and reboot the device. 	
Custom Private Key Name	This field only appears when the Custom Certificate field is set to Enable. Displays the name of the private key.	

Power Management

The AirLink RV55 gives you a number of options for managing power usage, depending on your application and hardware configuration. For example, you can use the Services > Power Management screen to configure the RV55 to automatically enter standby mode based on the state of the ignition switch, an I/O input, low voltage input to the RV55, or time of day.

inene .	WWWCallatat	WH	MN	979	Security	Services	Location	Events Gagarding	Sutter	Applications	- 611	Addison
-	airine langes								- 1	Tiggent H	3 (6	11) Se
84.875												
ACE manager			11101	e (Astitive)	Delte							
			Studdave Data; sharigation of cancores).			2						
inter I	(fangeres)											
Dynami	<1H1		litawa									
BACK .			LOWIN	Rage (Sard)	a binate			Automatic ~				
1000			3948	u holtage (10	in maintainin			80				
K7 (3m	eat/22344		Set	Outflicates	n Period (sela	(18)		-31				
0=+410	(ANTER)		Reactes Investately al Voltage (100 millionity)				100					
Manage	most (SMP)		Hand									
Time (1	MTP9		Lise 31	andly Mode				Dada -	5			
Autore 1	Color		110mgm									
Deveca :	States Screek		Expe		Wage Lavel (tób reilliuitho		0				
			tra	10 HOLKS 1998	Bur Erstille			Diverse =				
			WT END	or Health Ville	e marti			0.				
			11Pres	LED Conta	enter.							
			Ame	ation				(in w				
			LED TO	age to the second	(altrophile)			0				

Figure 9-3: ACEmanager: Services > Power Management

Field	Description
Ignition Shutdown Dela	ау
Shutdown Delay after Ignition off (seconds)	Set the delay (in seconds) between the time the ignition input goes low and the RV55 shuts down.
	• Range: 2–65535 (18 hours) (default is 2)
	The timer is reset if the ignition comes on during the delay period.

Field	Description		
Low Voltage			
-			the new values are not permanently first reboot may take longer than usual.
field, ensure that you h not available when the If you have inadvertent	ave a power source readi gateway is in standby mo	ly available that can supply the de, so you cannot use it to rese e too high, follow the instruction	tting the Resume immediately at Voltage configured voltage. The reset button is at the gateway to factory default settings as in How do I get my RV55 out of Low
[] Low Voluge			
Low Vollage Standby Node	20	anda 🗸	
Standby Vollage (100 m Volla)	90		
Standby Qualification Pariod (secu			
Basima inmediately at Voltage (1	00 m (Alm) 105		
Low Voltage Stand Mode	 the option to config Custom—Allo more informati Standby Quali milliVolts). Wh Standby Volta, be greater tha example, if yo number you ca Automatic—T Off—The gate 	jure custom values. ws you to configure the values ion on the configurable fields, s fication Period (seconds), and en configuring these fields, the ge field and the number in the R n 5, with the smaller number in u enter 120 in the Resume imm an enter in the Low Voltage Sta he gateway uses preset values	. (default) preset values for low voltage standby
Table 9-1: Low V	oltage Standby Mod	le Configurable Ranges	and Preset Values
Low Voltage Standby Mode	Standby Voltage (100 milliVolts)	Standby Qualification Period (seconds)	Resume immediately at Voltage (100 milliVolts)
Custom	58-294 (default is 90)	30–3600 (default is 30)	68-300 (default is 105)

Automatic

Off

Field	Description
Standby Voltage (100 milliVolts)	If the incoming voltage to the gateway is below the value set in this field for the period of time set in the Standby Qualification Period (seconds) field, the gateway goes into standby mode. This field is read-only if the Low Voltage Standby Mode is set to Automatic or Off. If Low Voltage Standby Mode is set to Custom, the valid range is:
	 58–294 hundreds of milliVolts Default value depends on the setting in the Low Voltage Standby Mode field. See Table 9-1. Enter the value in tenths of Volts. For example, for 11.5 V, enter 115. The difference between the number in the Standby Voltage field and the number in the Resume immediately at Voltage (100 milliVolts) field must be greater than 5, with the smaller number in the Low Voltage Standby Mode field. For example, if you enter 120 in the Resume immediately at Voltage field, the highest number you can enter in the Low Voltage Standby mode field is 114.
Standby Qualification Period (seconds)	 Set the time period (in seconds) that the voltage to the gateway is below the value set in the Standby Voltage (100 milliVolts) field before the gateway goes into standby mode. This field is read-only if the Low Voltage Standby Mode is set to Automatic or Off. If Low Voltage Standby Mode is set to Custom, the valid range is: 30-3600 seconds (default is 30)
Resume immediately at Voltage (100 milliVolts)	 Set the voltage at which the gateway exits standby mode and resumes normal operation. This field is read-only if the Low Voltage Standby Mode is set to Automatic or Off. If Low Voltage Standby Mode is set to Custom, the valid range is: 68–300 hundreds of milliVolts Default value depends on the setting in the Low Voltage Standby Mode field. See Table 9-1. Enter the value in tenths of Volts. For example, for 12.5 V, enter 125. The difference between the number in the Standby Voltage (100 milliVolts) field and the number in the Resume immediately at Voltage field must be greater than 5, with the smaller number in the Low Voltage Standby Mode field. For example, if you enter 120 in the Resume immediately at Voltage field, the highest number you can enter in the Low Voltage Standby mode field is 114.
Standby	
Use Standby Mode	 Select the type of Standby mode you want to configure Options are: Disable (default) Timed I/O I/O + Timed Changes take effect when you click Apply. No reboot is required. Note: You cannot set this field to I/O or I/O + Timed if the I/O line is already being used by the Relay Output or by the Pull-up for I/O.

Field	Description
Timed	
[] Sheet y	
Der Kinstlick Meter	Te days
Vide	TRUE 2
Were the per SNs and har shelds	na di Calif
Patricia Standay (11) Which at learnsh	Let at see s) D tol
Mode	 Select the Mode: Hourly—Wake Time (HH:MM offset from start of period) and Return to Standby (HH:MM offset from start of period) operate on an hourly basis Daily—Wake Time (HH:MM offset from start of period) and Return to Standby (HH:MM offset from start of period) operate on an daily basis
	 Custom—Provides the option set a test period to repeat the Wake/Standby cycle
Wake Time (HH:MM offset from start of period)	Set the time (hours:minutes on a 24 hour clock) at which the gateway wakes up. If you selected Hourly in the Mode field, set the minutes (the hour portion is ignored) and the gateway wakes up every hour at the configured time. If you selected Daily in the Mode field, the gateway wakes up every day at the configured time.
Return to Standby (HH:MM offset from start of period)	Set the time (hours:minutes on a 24 hour clock) at which the gateway goes into standby mode. If you selected Hourly in the Mode field, set the minutes (the hour portion is ignored) and the gateway goes into standby mode every hour at the configured time. If you selected Daily in the Mode field, the gateway goes into standby mode every day at the configured time.
	Note: There must be at least 5 minutes between the Wake Time (HH:MM offset from start of period) and the Return to Standby time.
Repeat Period	This field only appears if you select Custom in the Mode field. Use this field to configure how often the Wake Time (HH:MM offset from start of period)/ Return to Standby (HH:MM offset from start of period) cycle is repeated. The options are: 2 Hours (default) 3 Hours 4 Hours 6 Hours 8 Hours 12 Hours

Field	Description	
1/0		
L Issanow		
Dec Manufag Marke	P2 -	
Water of a set Whee	He I w	
Determination Standars (second s)	1	
Wake when I/O is	Select the I/O state that causes the gateway to wake. Options are:High (default)Low	
	Note: If the I /O line is already configured for another purpose, this I/O option is not available.	
Delay return to Standby (seconds)	 Select the delay (in seconds) between the I/O state change and the gateway entering Standby mode. Range is 1–43200 (12 hours) (default is 1 second) 	

Field	Description	
I/O + Timed		
I/O + TImea		
[] Senadoy		
Use Standby Mode	WE COMPACE -	
Weaks	(Here);	
Wake Thread III Mini office item and of peri-	0.10	
Celon in Manifey per Mitadaet lase and	en et (253)	
Water of an INC is	Hart A	
Deby secondo Dandby (seconds)	1	
To configure the fields for I/C	+ Timed, see Timed on page 230 and I/O o	on page 231.
standby mode are met. The I/O (or both) conditions for st Example: The following example:	ateway exits standby and returns to the nor ndby are no longer met. ole is based on the default settings. 0 minutes after the hour and return to stand	only when both I/O and Timed conditions for rmal operating mode when either the Timed or dby 50 minutes after the hour.
Timed		
		Wake
1:10 1:50 2:10	2:50 3:10 3:50 4:10 4:4	50 5:10 Time Standby
I/O		I/O High (Wake)
		I/O Low (Standby)
Gateway power mode		
		Wake
		Standby

Field	Description
 Voltage on power con State (High/Low) of p If you configure both fields, I For more information on the gateway. 	S can start and stop counting engine hours based on: nnector Pin 1 (Power pin) from the vehicle battery (Engine Hours On Voltage Level) power connector Pin 3 (Ignition Sense pin) (Engine Hours Ignition Enable) poth conditions must be met before the device begins counting engine hours. power connector pins, refer to the Hardware Configuration User Guide for your AirLink
H Dayling Hours	
L OPTIME FOR DAVID MORAPHE FAMILY 201	namesonation and a second s
 All trapper parts vitres contra; 	i in a constanti in a
Engine Hours On Voltage Level (100 millivolt)	If you want to use this field to trigger counting engine hours, the AirLink gateway must be using the vehicle battery as a power source (i.e. Pin 1 [VCC] and Pin 2 [ground] on the AirLink gateway's power connector are connected to the vehicle battery). Enter the voltage level above which the AirLink gateway starts counting engine hours. When the voltage from the vehicle battery falls below that value, the device stops counting engine hours. Enter the desired value of the ignition in millivolts. For example, to set the voltage level at 13.0 volts, enter 130. The default value is 0, which means the feature is disabled. Engine hours are not incremented based on the power pin voltage level.
Engine Hours Ignition Enable	If Pin 3 (the ignition sense pin) on the AirLink gateway's power connector is wired to the vehicle's ignition switch, oil pressure switch, or some other digital input, you can use this field to trigger counting engine hours. The device starts counting engine hours when the voltage on Pin 3 is high and stops counting when the voltage is low (Ground or 0 volts). For more information on the power connector pins, refer to the Hardware User Guide for your AirLink gateway. Options are: Disable (default)—Engine hours are not incremented based on changes to Pin 3.
Engine Hours Value (hours)	Displays an estimate of the number of hours the engine has been running, based on either the input voltage from the vehicle battery or the voltage on the ignition sense pin, depending on which of the two previous fields you configured. For more information on the power connector pins, refer to the Hardware User Guide for your AirLink gateway. You can also set the engine hours value to an initial value. The default value is 0. The maximum allowed value is 65535. You can also use an AT Command to set this value. For more information, see *ENGHRS on page 516. Note: You can configure Events Reporting to send reports based on this value. For more information, see Events Reporting Configuration on page 304.

Field	Description			
Power LED Config	Power LED Configuration			
LED Pattern	You can configure the Power LED to flash or turn off when the device is in Low Power Mode, which saves power. For more information about RV55 power consumption, see the RV55 Hardware Guide.			
	Options are:			
	 On (default)—During Low Power Mode, the Power LED behaves according to the LED Toggle Interval 			
	Off—LED is off during Low Power Mode			
LED Toggle Interv (seconds)	al Appears when LED Pattern is set to On. Sets the flashing interval, in seconds, for the Power LED during Low Power Mode.			
	Options are:			
	• 0 (default—LED is always on) to 5 (LED flashes once every 5 seconds).			

Dynamic DNS

Dynamic DNS allows an AirLink gateway's WAN IP address to be published either to a proprietary Sierra Wireless dynamic DNS service called IP Manager, or to a 3rd party DNS service.

Whether you have one Sierra Wireless AirLink gateway or multiple devices, it can be difficult to keep track of the current IP addresses especially if the addresses are not static but change every time the devices connect to the mobile network. If you need to connect to a specific gateway, or the device behind it, it is much easier when you have a domain name (mypage.mydomain.com).

Reasons to Contact or Connect to a Device:

- Requesting a location update from a delivery truck
- Contacting a surveillance camera to download logs or survey a specific area
- Triggering an oil derrick to begin pumping
- Sending text to be displayed by a road sign
- Updating the songs to be played on a juke box
- Updating advertisements to be displayed in a cab
- Remote accessing a computer, a PLC, an RTU, or other system
- Monitoring and troubleshooting the status of the gateway itself without needing to bring it in or go out to it.

A dynamic IP address is suitable for many Internet activities such as web browsing, looking up data on another computer system, for data only being sent out, or for data only being received after an initial request (also called Mobile Originated). However, if you need to contact the AirLink gateway directly, a device connected to the AirLink gateway, or a host system using your AirLink gateway (also called Mobile Terminated), a dynamic IP will not give you a reliable address to contact (since it may have changed since the last time it was assigned).

Domain names are often only connected to static IP addresses because of the way most domain name (DNS) servers are set-up. Dynamic DNS servers require notification of IP Address changes so they can update their DNS records and link a dynamic IP address to the correct name.

- Dynamic IP addresses are granted only when your AirLink gateway is connected and can change each time the gateway reconnects to the network.
- Static IP addresses are granted the same address every time your AirLink gateway is connected and are not in use when your gateway is not connected.

Since many mobile network operators, such as wire-based ISPs, do not offer static IP addresses or static address accounts (which can cost a premium as opposed to dynamic accounts), Sierra Wireless AirLink Solutions developed IP Manager. IP Manager works with a Dynamic DNS server to receive notification from Sierra Wireless AirLink gateways to translate the dynamic IP address to a fully qualified domain name. Thus, you can contact your AirLink gateway directly from the Internet using a domain name.

Senar WHATedalar 2.5		Licenses Course Reporting Dark Seried Applications 20 Adv				
ALMS .	Horemated					
Press Natagement	Deterric Onli Janete	Thesis and the second s				
New 1971		rog ton registron registron d'Annage				
Mill Al (Sener 158)						
Edward (SMVP)						
Time Linking						
Auffertitration Denice Halina Scream						

Figure 9-4: ACEmanager: Services > Dynamic DNS

Field	Description
Service	 Allows you to select a Dynamic DNS service. Options are: Disable (default) dyndns.org noip.com regfish.com IP Manager

Third Party Dynamic DNS Services

Using a third party dynamic DNS service requires an account with Internet access and an account with the third party service.

Note that third party Dynamic DNS services typically update the domain name to point to the source IP in the update packet. If the gateway has a NATed WAN IP address the domain name points to the network device performing NAT.

Note: Using a Dynamic DNS service does not change the gateway's Internet accessibility. If the gateway cannot be accessed remotely using the WAN IP address, it cannot be accessed using the associated FQDN.

ana ana amin'ny faritr'i San	(Jarrié	Tunning (way) Small	1000
ALM3	((Dynamic bhilt		
K/3makager	Detarts: Otil Server	Aprilla.org	
Prever their spectra of	Dename OND Update	Dris on Damas -	
Tabana test	Pub Comun Name		
	Loge		
IMS.	Papaword		
H (hemosci 144)	Update Interval (Invent)		
Crewall (BATTY)			
Reagrant (MBP)			
Inex (2017)			
advents atom			
Devils Plates Screen			

Figure 9-5: ACEmanager: Services > Dynamic DNS Third Party Services

The third party service selected from the Service drop-down menu in this example is "dyndns.org." These same fields are displayed for all Service selections other than IP Manager and Disable.

Field	Description	
Service Dynamic DNS Update	Allows you to select a Dynamic DNS Mobile Network Operator. Options are: Disable (default) dyndns.org noip.com regfish.com IP Manager Options are: Only on Change (default)—Sends an update whenever the IF	
	 Only on Change (default)—Sends an update whenever the IP address changes Periodically Update (Not recommended)—Sends an update at the interval set in Update Interval (hours). Note that data usage charges may be incurred. 	
Full Domain Name	The name of a specific AirLink gateway or device	
Login	Shows the login name	
Password	Shows the password in encrypted format	
Update Interval (hours)	Indicates the time (in hours) between checks for service updates from the selected third party service when Periodically Update is selected.	

IP Manager

You can use the Sierra Wireless IP Manager Dynamic DNS service if:

- The gateway has Internet access and uses the Sierra Wireless-hosted IP Manager server (eairlink.com domain)
- The gateway is on a private network without Internet access and a self-hosted IP Manager server is on the same private network. If you want to self-host an IP Manager server on your private network, contact your authorized Sierra Wireless distributor for more information.

With IP Manager, the gateway's WAN IP is included in the update packet sent to the IP Manager server, so IP Manager always links the gateway's WAN IP address to the domain name configured on the gateway.

Note: Using a Dynamic DNS service does not change the gateway's remote accessibility. If the gateway cannot be accessed remotely using the WAN IP address, it cannot be accessed using the associated FQDN.

stypements and and an	0.00.7%		Constitute (Specific Descent (Con-
ALM'S			
	[[] the what to the		
ACE in an agen	Dysamic DNS Senior	Winner -	
Novel Management			
Senation (1815	11Dram P		
de la calla (calla) ?	# Dects Name	2990240015010307	
Ref E.	4f Domain		
(Temet154)			
	ef Britanager Denar 1	and the second	
mail (SATTR)	# Managet Daner 11/pilate	Grap on Drange	
Reasonant (19887)	AT # Manager Server 1 Updam (mendes)	268	
	AT # Manager Sener 1 Ner		
literer (308/197)	Af P Marager Dense 2		
Autoantic action	#"Mahager Server 2 Optitele	Thy to Desp	
And a state of the	#7 Pharage Sever 2 (pitale (minutes)	265	
femile Malas Screen	AT d' Managas Tanas 2 Mar		

Figure 9-6: ACEmanager: Services > Dynamic DNS > IP Manager

Field	Description	
Device Name	The name you want for the device (up to 20 characters) If you want to use the current device phone number as part of the FQDN (for example, 6175551234.eairlink.com) enter #NETPHONE in this field. #NETPHONE is displayed in this field and everywhere else the device name is used, including on the Home > Status page, in SMS messages, in Event reports, as the PPPoE station name, etc. Using #NETPHONE as the device name is recommended if the account phone number may change and you want the device to continue to use the current phone number as part of the FQDN, or if you are creating a template that will be applied to multiple devices. If you are not using #NETPHONE, the Device Name is limited to alpha-numeric characters, plus – (dash). You cannot include other special characters or spaces. To use this feature, you must have IP Manager selected in the Service field.	
Domain	The domain name to be used by the device This is the domain name of the server configured for *IPMANAGER1. <i>Note: As a service, Sierra Wireless maintains IP Manager servers</i> <i>that can be used with any AirLink gateway. To use one of the free IP</i> <i>Manager servers, enter eairlink.com in this field.</i>	
IP Manager Server 1	1 The IP address or domain name of the dynamic DNS server that is running IP Manager Note: To use the Sierra Wireless IP Manager server, enter: edns1.eairlink.com	
IP Manager Server 1 Update	 Options are: Only on Change (default)—Sends an update whenever the IP address changes Periodically Update (Not recommended)—Sends an update at the interval set in IP Manager Server 1 Update (minutes). Note that data usage charges may be incurred. 	
IP Manager Server 1 Update (minutes)	How often, in minutes, the address sent to the IP Manager Options are: 5–255	
IP Manager Server 1 Key	User-defined password key used instead of the AirLink secret key when using an IP Manager server other than the one provided by Sierra Wireless	
IP Manager Server 2	The IP address or domain name of the dynamic DNS server that is running IP Manager. Note: To use the Sierra Wireless IP Manager server, enter: edns2.eairlink.com	

Field	Description	
IP Manager Server 2 Update	 2 Options are: Only on Change (default)—Sends an update whenever the IF address changes Periodically Update (Not recommended)—Sends an update a the interval set in IP Manager Server 2 Update (minutes). Not that data usage charges may be incurred. 	
IP Manager Server 2 Update (minutes)	How often, in minutes, the address sent to the IP Manager Options are: 5–255	
IP Manager Server 2 Key	User-defined password key used instead of the AirLink secret key when using an IP Manager server other than the one provided by Sierra Wireless.	

Tip: Some PPPoE connections can use a Service Name to differentiate PPPoE devices. Use the device name to set a Station Name for the PPPoE connection.

Understanding Domain Names

A domain name is a name of a server or device on the Internet associated with an IP address. Similar to how the street address of your house or your phone number are ways to contact you, both the IP address and the domain name can be used to contact a server or device on the Internet. While contacting you at your house address or with your phone number employ different methods, using a domain name instead of the IP address uses the same method, just as a word based name is easier for most people to remember than a string of numbers.

Understanding the parts of a domain name can help to understand how IP Manager works and what you need to be able to configure the device. A fully qualified domain name (FQDN) generally has several parts.

- **Top Level Domain** (TLD): The TLD is the ending suffix for a domain name (.com, .net, .org, etc.)
- **Country Code Top Level Domain** (ccTLD): This suffix is often used after the TLD for most countries except the US (.ca, .uk, .au, etc.)
- **Domain name**: This is the name registered with ICANN (Internet Corporation for Assigned Names and Numbers) or the registry for a the country of the ccTLD (i.e., if a domain is part of the .ca TLD, it would be registered with the Canadian domain registry). A name must be registered before it can be used.
- Sub-domain or server name: A domain name can have many sub-domain or server names associated with it. Sub-domains need to be registered with the domain, but do not need to be registered with ICANN or any other registry. It is the responsibility of a domain to keep track of its own subs.

mypage.mydomain.com

- .com is the TLD
- mydomain is the domain (usually noted as mydomain.com since the domain is specific to the TLD)
- *mypage* is the subdomain or server name associated with the device, computer, or device registered with mydomain.com

mypage.mydomain.ca

This would be the same as above, but with the addition of the country code. In this example, the country code (.ca) is for Canada.

Tip: A URL (Universal Resource Locator) is different from a domain name in that it also provides information on the protocol used by a web browser to contact that address such as http://www.sierrawireless.com. www.sierrawireless.com is a fully qualified domain name, but http://, the protocol identifier, is what makes the whole thing a URL.

Dynamic Names

When an IP address is not expected to change, the DNS server can indicate to all queries that the address can be cached and not looked up for a long period of time. Dynamic DNS servers, conversely, have a short caching period for the domain information to prevent other Internet sites or queries from using the old information. Since the IP address of a device with a dynamic account can change frequently, if the old information was used (e.g., with a DNS server that indicates the address can be cached for a long period of time) when the IP address changed, the domain would no longer point to the new and correct IP address of the device.

If your AirLink gateway is configured for Dynamic IP when it first connects to the Internet, it sends an IP change notification to the IP Manager. The IP Manager acknowledges the change and updates the Dynamic DNS server. The new IP address is then the address for your device's configured name.

When your device IP address has been updated in IP Manager, it can be contacted by name. If the IP address is needed, use the domain name to determine the IP address.

Note: The fully qualified domain name of your AirLink gateway will be a subdomain of the domain used by the IP Manager server.

SMS

Note: The RV55 uses the cellular network to send SMS. To use SMS with the RV55, you must have a data subscription from a Mobile Network Operator. Your account may need to have SMS enabled if it is not included with your service.

SMS Overview

AirLink gateways can:

- Receive commands via SMS message and send responses, even when the device does not have a full data connection. For example, you can provision a device via SMS without having a data connection (a basic attachment to the cellular network is still required)
- Act as an SMS gateway for a device connected to a local interface

ACEmanager has four SMS modes. Table 9-2 summarizes the capabilities of each mode.

Table 9-2: SMS Mode Capabilities


Mode	SMS Command with password	SMS Command without password	SMS Gateway
Password Only	Yes	No	No
Control Only	Yes	Yes*	No
Gateway Only	Yes	No	Yes*
Control & Gateway	Yes	Yes*	Yes*

* Provided either:

- Trusted Phone Number List is disabled.
- Trusted Phone Number List is enabled and the device's phone number is in the Trusted Phone Number List.

For more information on Trusted Phone Number List, see Inbound SMS Messages on page 254.

Sending SMS Commands to an AirLink Gateway



The format for sending an SMS command varies depending on the mode. See Table 9-3 for details.

 Table 9-3:
 SMS Command Formats

Mode	SMS Command Format	
Password Only	PW [Password] [Prefix][Command]	
Control Only (from a number on the Trusted Phone Number list)[Prefix][Command] or PW [Password] [Prefix][Command]		
Control Only (from a number not on the Trusted Phone Number list) PW [Password] [Prefix][Comma		
Gateway Only PW [Password] [Prefix][Comman		
Note: Insert a space before and after [Password]; no space between [Prefix] and [Command].		

Examples:

[Prefix][Command]

"&&&reset", where:

&&& is the prefix

If the ALEOS Command Prefix field in ACEmanager (Services > SMS) is blank, the prefix is not required.

· reset is the command

PW [Password] [Prefix][Command]

"PW 1234 &&&reset", where:

- 1234 is the password
 - For more information, see SMS Password Security on page 256.
- &&& is the prefix
- If the ALEOS Command Prefix field in ACEmanager (Services > SMS) is blank, the prefix is not required.
- · reset is the command

For information on sending SMS commands and a list of available commands, see page 556.

Note: The maximum length of the ALEOS Command Prefix is 3 characters (alphanumeric or special characters).

SMS Modes

The first step in configuring SMS is to select the SMS mode from the following options:

- Password Only—See page 244.
- Control Only—See page 245.
- Gateway Only—See page 246.
- Control and Gateway—See page 252.
- Outbound Only—See page 252.

For a list of available SMS commands, see page 557. For a list of SMS-related AT commands, see SMS on page 518.

Password Only

In Password Only mode, you can send SMS commands to a device, provided you use the password. Gateway SMS messaging is not supported in this mode.

Note: In Password Only mode, the password is always required. The Trusted Phone Number List is not available.

To configure Password Only mode:

1. In ACEmanager, go to Services > SMS.

ad granne) (even) (#1000.00.00	2.325.644	Enterthe Party Council State
alas Athenapy	(100E Mode	
w. Country	2003 Model	Passent Drie +
Poest Danagerouri	Int ALBOR Command Placement	
Dynamic 2005	ALEOS Command Phete	884
8495	111000 Parises	
AT (Temper 2016)	DHD Walking Tripper	Fasters Dearest
Front (188119)	[11AWarded	
Management (\$8882)	DHS-Autoria Type	Statistica *
Three control	2003 Applexics Harmbering Pran	IDN/mphon +
insthemiscation .	47-CEDME	the betterg
an ann an ann an an an an an an an an an	Gardy Test	Contract Sources
Dentis Nation Scimen.	Gales Text Dealtrative:	

Figure 9-7: ACEmanager: Services > SMS (Password Only)

- 2. In the SMS Mode field, select Password Only.
- **3.** Enter the desired password in the ALEOS Command Password field or leave the field blank to use the default password.

The password you enter can be any alphanumeric string between 1 and 255 characters long.

For more information see SMS Password Security on page 256.

- 4. If desired, configure SMS Wakeup (see SMS Wakeup on page 253) and Advanced options (see SMS > Advanced on page 258).
- 5. Click Apply.

For information on the message format, see Sending SMS Commands to an AirLink Gateway on page 242.

Control Only

In Control Only mode, you can send SMS commands to an AirLink gateway, but you cannot send non-command (gateway) SMS messages.

You can send an SMS command without a password if:

- Trusted Phone Number is disabled.
- Trusted Phone Number is enabled and your phone number is on the Trusted Phone Number List.

If Trusted Phone Number is enabled and your number is not on the Trusted Phone Number List, you can still send an SMS command provided you use the password.

Configure ALEOS for Control Only mode

Contraction (Contraction)	LID-AT PM	Increase Annual Contract of Contract	
		Numbered Strength Lines	
AM5			
(I manager	11. 1949 Hindu		
an and Character	3M2 90 49	damethin -	
reekt Malagement	All ALEIDS Command Password		
sturies 1985	4.606 Commune Prefix	845	
##	111 MALWARE		
(Tamat 5 Sec	(SKS Warway Tropper	Particle Destinat	
mail (548749)	1 (100 Security - Antopol DIG Research)		
anagement (SMR)	Trusted Phone National	Dama -	
tion (30ATOP)	Last tracenting Phane Nominan		
ultramits where	Last Norming Wessage		
	Turnley Phase Humber (111		
mule Marine Scrimen	Passe Nutifier		
	And Some		
	Transfeld Phone Hardware (an only be montow) on an Phone Hardwar Hald addres - Countying 1 (2011) + 000000 (212 checkederg head - Countying 2 (212) + 000000 (212 checkederg head - Countying 2 (212) + 000000 (212) (2010) - Countying 2 (212) + 000000 (212) (212) (212) - Countying 2 (212) + 000000 (212) (212) (212) (212) - Countying 2 (212) + 000000 (212)	t, webuth area code)	
	[1] Abunad		
	TAMI AND THE TIME	Installant () +	
	SMU-states internet Plat	attraction +	
	el-cuints	the lasting w	
		an owned where the second	
	Gauce Test	Canada Total	

1. In ACEmanager, go to Services > SMS.

Figure 9-8: ACEmanager: Services > SMS (Control Only)

- **2.** In the SMS Mode field, select Control Only.
- **3.** Enter the desired password in the ALEOS Command Password field or leave the field as is to use the default password.

The password you enter can be any alphanumeric string between 1 and 255 characters long.

For more information see SMS Password Security on page 256.

Note: If all the SMS commands you send in Control Only mode are from a trusted number, you do not need to include a password when you send the command.

4. If desired, change the ALEOS Command Prefix or use the default prefix, &&&.

Note: The maximum length of the ALEOS Command Prefix is 3 characters (alphanumeric or special characters). If you leave the ALEOS Command Prefix field blank, no prefix is required when you send the SMS command. The option to omit the prefix is only available in Control Only mode.

- If desired, configure SMS Security options (see SMS Security on page 254), SMS Wakeup (see SMS Wakeup on page 253), and Advanced options (see SMS > Advanced on page 258).
- 6. Click Apply.

For information on the message format, see Sending SMS Commands to an AirLink Gateway on page 242.

Gateway Only

In Gateway Only mode you can send and receive SMS gateway messages through the AirLink gateway to a local device. SMS messages received by the AirLink gateway (inbound) are sent on to the configured local device. Messages sent by the local device to a configured port on the AirLink gateway are sent out as SMSs (outbound) to a remote destination. Essentially, the AirLink gateway sends SMS messages between the cellular radio and the connected device.

In Gateway Only mode, you can also send SMS commands provided you include a password. For more information, see Sending SMS Commands to an AirLink Gateway on page 242.

To configure ALEOS for Gateway Only mode and format a Gateway message:

1. In ACEmanager, go to Services > SMS.

distantivis want (\$2.4	d.al.thi	Constant Constant Constant Constant	
		Number Oracle Strength Strength Strength	
4.365	111 MAR Marian		
ACD Including and	1 I I I I I I I I I I I I I I I I I I I		
and the second sec	AMD Muth	Samony Cong -	
Power Management	AT 4,000 Comman Passant		
Apricational COVIS	46.839 Continued Prefs	444	
any.	IMD Cevilination	(* · · · ·	
	molume Phone Number (In Secur	Frank -	
V7 (Temer 1.5%)	Included Heat Interface Configuration		
Cenal (DATO)	Thread and the second		
1990 - 1990 - 1990 - 1990 - 1990 - 1990 - 1990 - 1990 - 1990 - 1990 - 1990 - 1990 - 1990 - 1990 - 1990 - 1990 -	Local Heat IF		
Gravitaneed ((date)	Local Heat Part	19	
Time (SRDP)	ALCOPH		
Automic size	((The easy Premial Configuration		
Develop Hatlack Screene	Root Fletz	and	
termine (termine)	Fedibionital		
	Entries	100	
	ACKINE	ACR	
	Meanings Doly Format	(ADDITION (P))	
	11 INR Weind		
	test were hope	(Partice Destine)	
	11/1000 Danuelly - Indocend DNII Necessary		
	Trashed Phote Increter	Dame -	
	Last Excensity Phane Inviting		
	Last Hoursey Message		
	Tracked Phone Standar Lint		
	Plante Sumber		
	An Inc.		
	Trusted Phone Numbers sam anty be increases the spaces or other characteris. The tot must include phone numbers as they appear in Lastonamin		
	Phane Number feld Alone Complete 1 6:05: 1008/051212 (molusteg leading: 1 and area code) Comple 2 7:05: 408/051212 (grave leading: 1 include area code) Comple 2 7:05: 408/051212 (grave leading: 1 include area code) Comple 2 7:05: 408/05111717 (flamowe leading: 1 and address code)		
	1. Advantació		
	EME address Total	Manakan e	
	BME Address Figer	Handone -	
	KT-COSHE	Database +	
	Guide The	Entrang -	
	Outor feed Deetstation		

Figure 9-9: ACEmanager: Services > SMS (Gateway Only)

- 2. In the SMS Mode field, select Gateway Only.
- **3.** Enter the desired password in the ALEOS Command Password field or leave the field blank to use the default password.

The password you configure can be any alphanumeric string between 1 and 255 characters long.

For more information see SMS Password Security on page 256.

4. The SMS destination is the local interface where ALEOS forwards an SMS from the mobile network.

In the SMS destination field, select from the following options:

· Serial—Messages are forwarded to the Serial port on the destination device.

If you want to include the phone number as part of the information sent to the serial port, select Yes in the Include Phone Number on Serial field. Proceed to step 13.

• IP—Messages are sent using UDP over IP to a designated LAN or Wi-Fi device. Proceed to step 5.

Local Device Interface Configuration (Applies to inbound [to the local device] gateway messages when IP is the SMS destination and outbound [from the local device])

Inbound

5. Enter the Local Host IP address.

This is the IP address of the LAN or Wi-Fi device that is used as the destination for all incoming Gateway messages.

6. Enter the Local Host Port.

This is the UDP port the destination device listens to for incoming messages.

Outbound

7. Enter the ALEOS port.

This is the UDP port on which the AirLink gateway listens for outbound Gateway messages sent from any local device.

Message Format Configuration (Only applies if you selected IP in the SMS destination field)

- 8. In the Start field, enter the start of message delimiter, or use the default (<<<).
- **9.** In the Field Delimiter field, enter the delimiter to be used between fields in the SMS message, or use the default (,).
- **10.** In the End field, enter the end of message delimiter, or use the default (>>>).
- In the ACK field, enter the desired acknowledgment message, or use the default (ACK). The acknowledgment is sent to the device as a UDP packet on the same port as the device used to send the message.

ALEOS provides a message acknowledgment for every SMS message when it is passed to the radio. If ALEOS does not send an ACK, wait for 30 seconds, and then retry.


Security

- If desired, configure SMS Security options (see SMS Security on page 254), SMS Wakeup (see SMS Wakeup on page 253), and Advanced options (see SMS > Advanced on page 258).
- 13. Click Apply.

If you are using IP as the destination and you have changed the IPs or port numbers, reboot the device.

For information on the message format for an SMS Command, see Sending SMS Commands to an AirLink Gateway on page 242.

Sending a gateway message from a local IP device to a remote destination



The AirLink gateway acts as a gateway to send SMS messages from an IP connected device using AirLink SMS Protocol. The IP device sends a UDP packet to the AirLink gateway, which then sends the SMS to its destination.

Note: Outgoing SMS messages are limited to 140 characters.

To use AirLink SMS Protocol to send an SMS message from a connected device:

- **1.** Begin with the start field.
- **2.** Follow with the destination phone number. This number must be in the same format as the phone numbers in the Trusted Phone Number List.

Note: There is no space between the start number and the destination phone number or between any delimiter and the data fields.

- 3. Add the field delimiter.
- 4. Add the data type for the message:

For:	Enter:	
ASCII	ASCII	
8-bit	8BIT	
Unicode	UCS-2	
Data types are case sensitive.		

- 5. Add another field delimiter.
- 6. Add the number of ASCII characters in your original message (before it is converted to ASCII hex format).
- 7. Add another field delimiter.
- 8. Add the message to be sent in ASCII hex format. ASCII is case sensitive. Do not use any punctuation, such as a colon, or characters between hex pairs.
- 9. Finish with the end field.

Example: You want to send the following message: "Test message" to phone number (510) 555-4200. To use this feature, convert the message to

hex:54657374206d657373616765. Then format the message as follows:

<<<15105554200,ASCII,12,54657374206d657373616765>>>

where:


- "<<<" is the start delimiter
- "15105554200" is the phone number
- · "," is the delimiter between fields
- · "ASCII" is the data type
- "12" is the number of characters in the original message (before it is converted to ASCII hex format)
- · "54657374206d657373616765" is the message itself
- · ">>>" is the end delimiter
- **10.** Send the UDP packet to the configured ALEOS port.

After your message is sent, you receive an ACK message in the format ACK Field acknowledgment Code ACK Field. For example, if your message was successfully queued to be sent, you receive the message: ACK0ACK.

If you receive an error message, see SMS on page 571 for details.

Note: You can also use AT*SMSM2M to send an SMS message to the remote device. For more information, see SMSM2M on page 260.

Sending a gateway message to the connected device using IP address and port as the SMS destination



Messages from a remote device can be sent to the AirLink gateway. The AirLink gateway encapsulates the message in a UDP packet using AirLink SMS Protocol, and sends it to the configured Local Host IP and Local Host Port on the connected device.

Message example:

Example:

- 1. An SMS is sent from phone number (640) 555-4200 to the device: "Test message"
- 2. The AirLink gateway receives the SMS and determines it is a gateway message.
- **3.** The AirLink gateway converts the message into a UDP packet using the AirLink SMS Protocol and sends it to the configured Local Host IP at Local Host Port. The message as follows:

<<<16045554200,ASCII,12,54657374206d657373616765>>>


where:

- "<<<" is the start delimiter
- "16045554200" is the phone number
- · "," is the delimiter between fields
- "ASCII" is the message type"
- + "12" is the number of characters in the message
- "54657374206d657373616765" is the message itself
- · ">>>" is the end delimiter


* In this example the message is in ASCII, but it could also be in 8-bit or Unicode format:

For:	Enter:	
ASCII	ASCII	
8-bit	8BIT	
Unicode	UCS-2	
Data types are case sensitive.		

Sending a gateway message to the connected device using Serial or USB Serial as the SMS destination



A message can be sent from a remote device to the AirLink gateway. The AirLink gateway sends the body of the message in ASCII text to the connected device. If the Include Phone Number on Serial field is set to Yes, the AirLink gateway prepends the phone number to the message.



Control and Gateway

In Control and Gateway mode you can do both—send commands to the device and send gateway messages to the connected device. When the Trusted Phone Number List is enabled, all SMS messages from trusted devices that do not begin with the password indicator (PW) or the command prefix are sent to the connected device as a gateway message.

For more information, see Trusted Phone Number on page 256.

Configure ALEOS for Control and Gateway mode

- 1. In ACEmanager, go to Services > SMS.
- **2.** Select Control and Gateway.

Inter WEBCriteiter	Description 1.48 VPN Security Services	Location Counter Deal Social Applications 10 Admin
and the second s	pt al Per	Trank and Taken Taken
ii.MT	1/1/1/1/1/1/	
A manager	[1] Mill Moine	A STREET, STRE
	INIT Mode	Candid and Safering. 14
foreit the sponter of	#F ALEDE Command Payment	
phane 285	ALZOD Command Phalls	888
THE Destruction	3HD Destination	(e
pane.	Instate Phone Normal On Sector	tyata -

Figure 9-10: ACEmanager: SMS (Control and Gateway)

For more information, see Control Only on page 245 and Gateway Only on page 246.

Outbound Only

Select this mode if you plan to use +CMGD or +CMGL AT commands to manage SMS messages. When you choose this mode, inbound messages are stored on the radio module until another mode is chosen. Note that inbound messages could be lost if the storage becomes full.

Note: MC74xx devices do not support AT+CGML and AT+CGMD commands used for reading and deleting messages for carriers that use CDMA SMS message format.

Applied the Alterna 1.6	13574	Example rank frankling frankling
		Reported Record Research Research
ic.015		
S. Comment	11 1001-000	
of Alternational Street Street	Tatti Mode	Tailaani Org -
Sumar Abarragerment		
an condi-	12 Addit Warning	
Uppermit (ML)		
wirk.	SMS Wakeur Titgger	Avy SAS meaning
	Connection transitioners)	2
AT (Tallant 1584		
Consult of Chartery	[][Absord	
	1865-4±00xx 7yp#	Marialization at the second se
HARAN CONTRACTOR	1921 Address Handwing Plan	NORTHING IN
Terre (MATTR)	47-COBMS	In lating w
	Gaute Teel	Count Test
Authorshumber:	Guest Text Desitration	
Dente Males Scotes	Translate 30PPC Coloniando	Dears -

Figure 9-11: ACEmanager: SMS (Outbound Only)

SMS Wakeup

This feature is supported on International AirLink gateways on the Vodafone network.

When the AirLink gateway is in Connect on traffic mode (for details, see Always on connection on page 94), you can configure the AirLink gateway to also initiate a mobile network data connection on receipt of an SMS. After the connection is established, it remains active until the configured timeout expires. The mobile network data connection closes after the specified timeout period. Outgoing traffic sent after the timer is triggered does not reset the timer.

To configure SMS Wakeup:

1. In ACEmanager go to WAN/Cellular > Advanced and ensure that the Always on connection field is set to Disabled - Connect on traffic.

Matura VikhoCentular LAR	VPN Decorty Services Location	Events Reporting Serial Applications IO Admin
Last optimised in the 1917/02/00 2018-8	114	Zunnith Auto Anton Canal
AL.075	11 DATE Marke	1
ACEromoger	1948 Made	(Perswirt Dity +)
Power Management	M ALEOS Command Pacaword	
Dynamic DMS	ALEOS Command Prefix	665
SHS	(1) thits Wateriage	
Tedrami S.S.H	SMS Wahnup Troppe	Feature Decaster 4

2. Go to Services > SMS.

Figure 9-12: ACEmanager: Services > SMS

3. In the SMS Wakeup Trigger field, select the type of SMS that should wake up the device. The options are:

- Feature Disabled
- Any Class 0 message
- Class 0 Wake Command
- · Any SMS message
- · Wake Command

Note: "Class 0 Wake Command" and "Wake Command" are SMS commands.

- 4. Click Apply.
- In the Connection timeout (minutes) field, enter the number of minutes the mobile network data connection remains active after SMS Wakeup Trigger is received. Accepted values for this field are 2–65535. The default value is 2.

You can also set the Connection timeout using an AT command. For more information, see ***SMSWUPTOUT** on page 520.

6. If you selected Class 0 Wake Command or Wake Command in step 3, you can specify the SMS command name in the Wake Command field or use the default value, WAKEUP. Sending this SMS to the device will wake it up. Example: &&&WAKEUP (&&& is the SMS command prefix.)

Dynamic DNS	[] BVS Wakcup	
SMS	SM3 Wakeup Trigger	Class 0 Wale Command Le
Teinet/SSH	All Connection Impout (minutes)	2
Eres all / S MITEA	Water Command	WAKEUP

Figure 9-13: ACEmanager: Services > SMS > SMS Wakeup > Wake Command

7. Click Apply.

SMS Security

Inbound SMS Messages

Incoming SMS messages are received as UDP packets, and forwarded to the local device IP address and port. The UDP packets are in the same format as sent messages.

When Trusted Phone Number security is enabled, incoming messages coming from the phone numbers in the Trusted Phone Number list are the only ones for which commands will be performed (relay, response etc.) or gateway messages forwarded. Incoming messages from all other phone numbers will be ignored. Commands sent to the device with the correct password are always treated as coming from a trusted number.

All non-alphanumeric characters except a space will be replaced by a dot in ACEmanager.

of opening these (with the first	100 PM	Constant (see) Second (S
4.555	and the second sec	
Climanagan	[PCMD 0am	
iwe: Management	(351.4cal Host History Configuration)	
yhere: INIS	Willesson Farral Certainana	
es.	When Economic and	
(Summet 5.50)	19:000 Waterge	
must (SATONY	() MD locarty-mount INT Messages	
And the supervised in the supe	Tranket Prove Namber	Taute +
	Last Incoming Plane Aumber	
after that a face	Last techning thesauge	
COLUMN AND	Trasted Picse Hutday Ltd	
entos Diatino Screwe	2	Plate Number
	Trusted Phone Northers san only be number: you Phone Number field access • Example 1 (201) 14480951212 (producing to • Scample 2 (201) addition to the papers and • Scample 2 (201) 447168.111717 (Bernarie In	rg 1, include alwa codel
	[H] Advanced	

Figure 9-14: ACEmanager: Services > SMS > Security

Field	Description
SMS Security - Inbound	d SMS Messages
Trusted Phone Number	Allows you to Enable or Disable a trusted phone number
Last Incoming Phone Number	The last inbound phone number is displayed here. This will only be erased with a reset to defaults.
Last Incoming Message	The last incoming message is the last inbound SMS from the phone number. This will only be erased with a reset to defaults.
Trusted Phone Number List	Trusted phone numbers are listed here

Trusted Phone Number

Follow the instructions below to add a Trusted Phone Number on the SMS page.

- 1. Send an SMS command to the device, and hit Refresh. If Trusted Phone Number is enabled, and the phone number is not in the Trusted Phone Number List, no action is performed on the message.
- 2. Once you have the Last Incoming Phone Number that shows up on the SMS window in ACEmanager, note the exact phone number displayed.
- Click Add More to add the Trusted Phone Number. The Last Phone Number will continue to display. Additions to the Trusted Phone Number become effective immediately. You do not need to reboot the device.

Note: The Trusted Phone number can be up to 15 characters long and must be comprised of numbers only.

Note: Phone Numbers (both trusted and not trusted) will be displayed in the Last Incoming Phone Number field.

- 4. Enter the Last Incoming Phone Number as the Trusted Phone Number.
- 5. Click Apply.

Note: Do not enter any extra digits, and use the Last Incoming display as a guide to type the phone number. Use "1" only if it is used in the beginning of the Last Incoming Phone Number.

With Trusted Phone Number enabled, only those SMS messages from Trusted Phone Numbers will receive responses to commands or messages acted on as applicable.

SMS Password Security

The SMS Password feature enables you to use a password to send a command at any time to the device. Even if Trusted Phone Number is enabled, you can send an SMS command from a non-trusted number, provided you include the password.

A default SMS password is generated from the last four characters of the SIM ID (for all SIM-based devices) or you can configure your own SMS password.

Tip: If you do not know the SIM ID or ESN number you can find it in ACEmanager (Status > WAN/Cellular).

Note: The SMS password is not the same as the ALEOS password used to access ACEmanager or Telnet/SSH.

To configure the SMS password:

1. Go to Services > SMS > SMS Mode.

ad an inclusion of the local sector	D.1.47%	Contract Street St.	Contract Contract
al tes	[H 365 Mode		
	Sett them	Parrent Dig. +	
Power Kenigertent	AT ALERE Command Password		
Dynamic DHD	ALEGE Command Prefs	455	
W4:	(14 mm warang		
If ChimarCESTE			
imail 1941175	[]+] Marriel		
Annuprenant (19887)			
1000 20007F9			
ebetti alué			
Devition Tableco Division			

Figure 9-15: ACEmanager: Services > SMS > Password

- **2.** Enter the desired SMS password in the ALEOS Command Password field. The password can be any alphanumeric string 1 to 255 characters long.
- 3. Click Apply.

Note:

- The SMS password is not displayed in plain text in ACEmanager. If you want to query it, use the AT command. See *SMS_PASSWORD on page 520.
- The SMS password is not cleared by a configuration reset.
- If an SMS command is sent with the wrong SMS password, the device replies with a "Wrong Password" message, and the command is dropped.

Using the Default SMS Password

You can use the default SMS password (last 4 characters of either the SIM ID number for SIM-based devices, or the ESN for devices without a SIM) with no prior configuration.

Note: The default password:

- Works with all SMS commands
- Is not displayed in ACEmanager (If the ALEOS Command Password field is blank, the default password is used.)
- Is overridden by a user-defined password
- Changes if the SIM is changed, if no user-defined password is configured

SMS > Advanced

[]Advanced	
SM3 Address Type	International V
SMS Address Numbering Plan	ECH/Telephone v
AT-CCSM3	Do Holling 🔍
SM3 Mossage Format	Default w
Duck feet	Buck bod
Quick Test Destination	

Figure 9-16: ACEmanager: Services > SMS > Advanced

- Arboniced	
SVS Address Type	imenational v
8V8 Address Numbering Plan	150% teleptone - M
ALCORDUS	De Natiling V
Ornek Test	Quick leaf
Quick Test Destination	
Translate 36112 Commands	Disable v

Figure 9-17: ACEmanager: Services > SMS > Advanced (Outbound Only mode)

Field	Description
SMS Address Type	For most networks, use the default setting (International). The address type of the phone number used to send outgoing messages and command responses. Options are: International (default) National Network Specific Subscriber Abbreviated
SMS Address Numbering Plan	For most networks, use the default setting (ISDN/Telephone). The address numbering plan of the phone number used to send outgoing messages and command responses. Options are: Unknown ISDN/Telephone (default) Date Numbering Telex National Private ERMES
AT+CGSMS	 Allows you to choose the technology used to send SMS messages. For most networks, use the default setting (Do nothing). Options are: Do Nothing (default) Set AT+CGSMS=0—GPRS Set AT+CGSMS=1—Circuit switched Set AT+CGSMS=2—GPRS Preferred (Uses circuit switched if GPRS is not available) Set AT+CGSMS=3—Circuit Switched Preferred (Uses GPRS if circuit switched is not available)
	Note: If your gateway is able to receive SMS messages, but is unable to send them, try changing this field to Set AT+CGSMS=1.
SMS Message Format	 This setting appears in all SMS modes except Outbound Only. If the gateway does not send or receive SMS messages, you may need to select the SMS message format. This situation may arise when an unrecognized SIM prompts the gateway to use Generic radio module firmware, but service is actually provided by Sprint, Verizon, or AT&T. Options are: Default (default)—ALEOS uses the message format configured for the carrier's radio module firmware. 3GPP—ALEOS uses 3GPP message format (compatible with AT&T service). CDMA—ALEOS uses CDMA/3GPP2 message format (compatible with Sprint and Verizon).
Quick Test	Allows you to send a test message to the destination entered in the Quick Test Destination field.

Field	Description	
Quick Test Destination	Enter the phone number to use for the test message. Click Apply before clicking the Qu Test button. This field is cleared on reboot.	
Translate 3GPP2 Commands	 This setting appears in Outbound Only mode. In some instances, for MC74xx devices on CDMA networks, the 3GPP AT commands +CMGD and +CMGL must be translated to 3GPP2 in order to work. In such cases, enable this setting. Options are: Enable Disable (default) 	

SMSM2M

SMS messages can be sent from the serial command interface. Enter AT*SMSM2M="[phone] [message]". The phone number needs to be in the same format as numbers entered in the Trusted Phone Number List.

The message must not exceed 140 characters. To send several messages back to back, you must wait for the OK before sending the next message.

Command	Description
*SMSM2M *SMSM2M_8 *SMSM2M_u	 *SMSM2M is the command for ASCII text. *SMSM2M_8 is the command for 8-bit data. *SMSM2M_u is the command for unicode. Format: *smsm2m="[phone][ascii message]" *smsm2m_8="[phone][hex message]" *smsm2m_u="[phone][hex message]" The phone number can only consist of numbers (NO spaces or other characters). The phone number should be as it appears in the Last Incoming Phone Number field. Example 1 (US): 14085551212 (including leading 1 and area code) Example 2 (US): 4085551212 (including leading 1, include area code) Example 3 (UK): 447786111717 (remove leading 0 and add country code) Command Examples: *smsm2m_8="17604053757 5448495320495320412054455354" sends the message "THIS IS A TEST" as 8-bit data. *smsm2m_u="17604053757 000102030405060708090a0b0c0d0e0f808182838485868788898A8b8c8d8e8f" sends the bytes: 00 01 02 03 04 05 06 07 08 09 0a 0b 0c 0d 0e 0f 80 81 82 83 84 85 86 87 88 89 8a 8b 8c 8d 8e 8f Note: Not all cellular carriers support 8-bit or unicode SMS messages.

AT (Telnet/SSH)

Use the Telnet or SSH protocol to connect to any AirLink gateway and send AT commands.

A secure mechanism to connect remote clients is a requirement for many users. In ACEmanager, Secure Shell (SSH) is supported to ensure confidentiality of the information and make the communication less susceptible to snooping and man-in-the-middle attacks. SSH also provides for mutual authentication of the data connection.

Sietre WebCetteler	heat Thi FI 1.224 MVH hermity Services Location	Forem Reporting Deal Second Applications 207 Advice
ad general data (a terral da te	2(4) (%)	(max) (herein) (herein)
4185	AF Recents Lager Series Multe	(366.0)
attomore	41 Default Tanvettiane	Non II
Press Management	AT Rockale Logis Balver Teleastible Past	2332
	Transmittani Access Polity	148
Synamic 2015	47 Hernde Lopin Server Telmet SDH Pret Trimoud (minules)	1
EMS.	AF Taxaattoon Edw	Trate -
all themes fields (All Disuttis 472 Report	100 C
Contraction of the second	Mate 201 Keye	Bale Litt bays
(real (DECE)	CD+ TMiss	
Management (1988/PV		
Tama (MATPS		
adhantication .		
Senice Balan Science		

Figure 9-18: ACEmanager: Services >Telnet / SSH

Field	Description	
Remote Login Server Mode	Select either Telnet (default) or SSH mode.	
Default Telnet User	 Select a default Telnet User name Options are: None—When you log into a Telnet session, you are prompted for a user name and password. user—When you log into a Telnet session, you are prompted only for a password. Telnet uses the default user name (user). Note: The default user name is only for Telnet; not SSH. 	
Remote Login Server Telnet/SSH Port	Note: The default user name is only for Telnet; not SSH. Sets or queries the port used for the AT Telnet/SSH server. Default: 2332 Tip: Many networks have the ports below 1024 blocked. We recommend that you use a higher numbered port.	

Field	Description
Telnet/SSH Access Policy	Restricts access to Telnet/SSH Options are: • LAN+WAN • LAN (default) • Disabled
Remote Login Server Telnet/SSH Port Timeout (mins)	Telnet/SSH port inactivity timeout. Default: 2 (minutes)
Telnet/SSH Echo	Enable (default) or disable AT command echo mode.
Make SSH Keys	Creates keys for SSH session applications
SSH Status	Provides the status of the SSH session

Note: When you are connected to SSH locally, you cannot have OTA SSH connected.

Email (SMTP)

For some functions, the device needs to be able to send email. Since it does not have an embedded email server, you need to specify the settings for a relay server for the device to use.

A reboot is required after configuring the email settings.

Note: The SMTP function will only work with a mail server that will allow relay email from the ALEOS device's Net IP.

10000000000000000000000000000000000000	3.33.PM	Emerical Appr. Ramon (Do
ALMS.		
Titler -	TCRAME.	
ACE Invaluegely	AT MATE Dates	smb grief com
Power Management	Per	15
Sylvenia 1945	AT From Ernal Adminis	me@prival.com
Lan a.	#F User Rame (optional)	me@proal.com
	AT Passwirt continues	
NT (Terrent's Sile)	AT Meanings Duripert	Artum Test
(mail (SMTP)	Quest Text	Count Test
Passagement (Maran)	Queb Test Dealtration	
Cau	Text alphas	
Time (Address	Tagenumum.	
Authoritication		
Designed Deletered Buckeyers	Georgebon	india +
Bentos Mater Screep	Nextly Peer Cartificate	lines w
	Last Truned Ox Zenticate	Added Transland I'A Contribution
	Trunket C4. Det/floaks Name	

Figure 9-19: ACEmanager: Services > Email (SMTP)

Field	Description		
General			
SMTP Server	 Specify the IP address or Fully Qualified Domain Name (FQDN) of the SMTP server to use. d.d.d.d = IP Address name = domain name (maximum: 40 characters) 		
Port	Server port (Default is 25.)		
	Encryption method Default port		
	SSL 465		
	StartTLS 587		
From Email Addres	Sets the email address from which the SMTP message is being sent.		
	 email = email address (maximum: 30 characters) 		

Field	Description
User Name (optional)	Specifies the username to use when authenticating with the server
Password (optional)	Sets the password to use when authenticating the email account (*SMTPFROM) with the server (*SMTPADDR). • pw = password
	Note: The email server used for the relay may require a user name or password.
Message Subject	 Allows configuration of the default Subject to use if one is not specified in the message by providing a "Subject: xxx" line as the initial message line. subject = message subject
Quick Test	After completing the other fields on this screen, click the Quick Test button to send a test email. The status of the test appears in the Test status field.
Quick Test Destination	Enter the email address you want the test email sent to.
Test status	After you press the Quick Test button, the status of the email test appears in this field.
SSL/TLS	
Encryption	 Choose the encryption method: None—No encryption is used (default) SSL—Use a secure connection directly StartTLS—Transforms an non-secure connection to a secure one For SSL and StartTLS default ports, see Port on page 263.
Verify Peer Certificate	Choose whether or not to use a peer certificate Disable—No certificate is used (default) Enable—Verifies that the server name used for the connection matches the name and alternative names in the certificate loaded using the Load Trusted CA Certificate field.

Field	Description
Load Trusted CA Certificate	To load a certificate:1. Click the Load Trusted CA Certificate button.2. Click browse and navigate to the certificate you want to load.
	Load Trusted CA Certificate Close UpLoad Certificate
	3. Click Upload File to Device. Note: Because the starting and expiration dates of the certificate are checked, the date used by the device must be correct. Sierra Wireless strongly recommends that you enable Network Time Protocol (NTP) on the Services > Time (SNTP) tab.
Trusted CA Certificate Name	The name of the loaded certificate appears in this field.

Management (SNMP)

The Simple Network Management Protocol (SNMP) is designed to allow for remote management and monitoring of a variety of devices from a central location. It is generally used to monitor conditions that may require attention.

The SNMP management system is composed of:

- One or more managers (administrative computers)
- SNMP-compliant devices (such as your AirLink gateway, a router, a UPS, a web server, a file server, or other computer equipment)
- An agent (data collection software running on the SNMP-compliant devices)
- A Network Management System (NMS) that monitors all the agents on a specific network.

The agent stores information about the device in a Management Information Base (MIB). The manager can send messages to this database to configure and query the status of the device. In addition, the agent running on the device can send traps (unsolicited messages) to the manager on startup, on status change, or when an error condition occurs.

AirLink gateways supports configuring SNMPv2 and SNMPv3 as SNMP agents.

Authentication ensures SNMP messages coming from the AirLink gateway have not been modified and the device cannot be queried by unauthorized users. SNMPv3 uses a User-Based Security Model (USM) to authenticate and, if desired or supported, message encryption. USM uses a user name and password specific to each device.

A reboot is required after configuring SNMP.

Anne WMAICellister I	lead Wil Fill State Security Services	Location Events Veporting Illust Series Apple	store N1 Adult
al genille (1973) (1973) (1973)	n Jan juda	Elite	3 (23 (22) (2)
ALMES	H INNY Configuration		
Charapy	SHAP Ageni	ban -	
Power Danagement	1040 ² million	Second 2 -	
lynamic 2015	STAP Put	141	
045	Intel® Contract Unde® Name		
A7 (Tellect 1344)	Inder Lucières		
Trend (188711)	0444" Scale > Description	BV96	
Consequences (198444)	11 Next Drie WAM Low		
forme starting	Carround Name	public	
Bathandri allon	Li Basellinia Dalle Li set		
Omite Balat Scine	Community Name	provite	
	11 TMM* Server Gam		
	TRAP Sweet PSPGDV	0.000	
	TRUP Serve: Poll	102	
	Conviously Name		

SNMPv2

Figure 9-20: ACEmanager: Services > Management (SNMP) (Version 2)

Field	Description
SNMP Configuration	
Enable SNMP	Allows you to enable/disable SNMP Default: Disable
SNMP Version	Allows you to select either SNMP protocol Version 2 (default) or Version 3 communications.
SNMP Port	Controls which port the SNMP Agent listens on: • 1–65535 (default is 161)
SNMP Contact	This is a personal identifier of the contact person you want to address queries to. This is a customer defined field.
SNMP Name	This is the name of the device you want to refer to. This is a customer defined field.
SNMP System Description	Use this field to enter a system description, if desired. The default value, which appears after the SNMP agent is enabled and the gateway rebooted, is the product name.

Field	Description
Read Only SNMP User	
Community Name	The community name is a text string that acts as a password. It is used to authenticate messages that are sent between the management station and the device. Default is public.
Read/Write SNMP User	
Community Name	The community name is a text string that acts as a password. It is used to authenticate messages that are sent between the management station and the device. Default is private.
TRAP Server User	
TRAP Server IP/FQDN	Identifies the IP address or fully qualified domain name (FQDN) of the trap server that the AirLink gateway sends SNMP traps to
TRAP Server Port	Identifies the specific port the trap server is on • 1–65535 (default is 162)
Community Name	The community name is a text string that acts as a password. It is used to authenticate messages that are sent between the management station and the device. There is no default value.

el spanistore, le tato (C.C.)	0.034	Energy (such Energy (sta
44.08.S	()) SNM Configuration	
Cimensor'	These conditions	
	DAMP Agent	Dana
www.theospenset	STAFF WORK	Merand 3 w
aniers: INI	Driff Put	101
	MARP Contact	
Hel.	Shidd ^a faartee	
(Sematters)	ShiddP Location	
mant ((MATEP)	MART System Description	RVID
PRODUCT DATA	Lifead (ne 2089 Use	
en clatin	Utilet Norte	
	Westande Lawer	19000 11
chertication		
erten Statum Screen	11 Head Tride (1989) (pair	
and when being	Char Barte	
	Security Level	1966 M
	(1) TRAP Server User	
	Their Anne Philad	0.0.0.0
	THAP bener Post.	162
	Grane ID	
	Uner Norte	
	Hanada Lavar	Deet. El

SNMPv3

Figure 9-21: ACEmanager: Management (SNMP) (Version 3)

Field	Description
SNMP Configuration	
Enable SNMP	Allows you to enable/disable SNMP Default is Disable.
SNMP Version	Allows you to select either SNMP protocol Version 2 (default) or Version 3 communications.
SNMP Port	Controls which port the SNMP Agent listens on: • 1–65535 (default 161)
SNMP Contact	This is a personal identifier of the contact person you want to address queries to. This is a customer defined field.
SNMP Name	This is the name of the device you want to refer to. This is a customer defined field.
SNMP Location	Location of where your device is stored. This is a customer defined field.
SNMP System Description	Use this field to enter a system description, if desired. The default value, which appears after the SNMP agent is enabled and the gateway rebooted, is the product name.

Field	Description
Read Only SNMP	
User Name	Allows these SNMP users to view, but not change the network configuration
Security Level	Security types available: None, Authentication Only, and Authentication and Privacy.
Authentication Type	Authentication types available: MD5 or SHA
	Note: This field is only available when you select either Authenti- cation and Privacy, or Authentication Only in the Security Level field.
Authentication Key	 This key authenticates SNMP requests for SNMPv3. Minimum length: 8 ASCII characters Maximum length: 255 ASCII characters Example: My Key_1234
	Note: This field is only available when you select either Authenti- cation and Privacy, or Authentication Only in the Security Level field.
Privacy Type	Privacy types available: AES or DES
	Note: This field is only available when you select Authentication and Privacy in the Security Level field.
Privacy Key	 This key ensures the confidentiality of SNMP messages via encryption Minimum length: 8 ASCII characters Maximum length: 255 ASCII characters Example: My Key_56789
	Note: This field is only available when you select Authentication and Privacy in the Security Level field.
Read/Write SNMP For a description of the Read.	/Write SNMP fields, see Read Only SNMP on page 269.
TRAP Server User	
TRAP Server IP/FQDN	Identifies the IP address or fully qualified domain name (FQDN) of the trap server that the AirLink gateway sends SNMP traps to
TRAP Server Port	Identifies the specific port the trap server is on • 1–65535 (default is 162)

Field	Description
Engine ID	The Engine ID is a mandatory field that uniquely identifies the SNMPv3 agent in the device to the server.
	The Engine ID is 5–32 octets long (1 octet is 2 hex characters). That is:
	Minimum length: 10 hex characters
	Maximum length: 64 hex characters
	Create the engine ID by entering hex characters only, with no leading 0x. For example, ABCDEF1020
User Name	See User Name on page 269.
Security Level	See Security Level on page 269.
Authentication Type	See Authentication Type on page 269.
Authentication Key	See Authentication Key on page 269.
Privacy Type	See Privacy Type on page 269.
Privacy Key	See Privacy Key on page 270.

Time (NTP)

The device can be configured to synchronize its internal clock with a time server on the Internet using the Network Time Protocol (NTP). If NTP or GPS is not enabled, the RV55 synchronizes with mobile network. If both GPS and NTP are enabled, NTP time will be used.

Area and a second s	0.176		Country Inc.	
6. MT				
	[Intel Cheve			
Clahanagur	WT have NWT to update inve	Dame W.		
www.Management				
	WTP Server Address Lod			
enmin (MS	1	NTP Server Address		
M6.		booyudb red		
Telest Links				And Many
nul (SMTH)	A (ALTO SHEER)			
And appropriate Challeng	. AT ATTP Samer Made	Team (*)		
1111 1111				
diversity allow				
ienia Italia farres				

Figure 9-22: ACEmanager: Services > Time (NTP)

Field	Description
NTP Client	
Use NTP to update time	Enables daily NTP update of the system time. Default: Disable
NTP Server Address List	 NTP Server IP address, or fully qualified domain name, to use if *NTP=1. If blank, time.nist.gov is used. d.d.d.d=IP address name=domain name Click Add More to add another NTP Server Address. You can add up to two additional NTP Servers. The additional NTP servers will provide backup if the primary server connection fails.
NTP Server	
NTP Server Mode	Enables the RV55 to act as an NTP server bound on port 123. If the NTP Client is not enabled, time from the cellular network or GPS will be used. Default: Disable

Authentication

ALEOS supports ACEmanager login using secure LDAP, RADIUS, and TACACS+ authentication schemes. This enables enterprise IT managers to centrally manage access to AirLink gateways and produce an audit trail showing which users logged into specific devices and when.

Note the following:

- You can configure any or all of these schemes at the same time. When more than
 one scheme is configured, the authentication is successful if at least one of the
 schemes authenticates the user.
- Successful authentication can take time. For example, if you have all three authentication schemes enabled, ALEOS first attempts to reach the LDAP server. If it is unable to reach the LDAP server in the configured timeout period, it abandons the attempt and tries to reach the RADIUS server. If that server is unreachable after the timeout period, it then tries to reach the TACACS+ server. If none of the servers are reachable in the configured timeout periods, ALEOS falls back to ACEmanager user name and password authentication.
- LDAP, RADIUS, and TACACS+ provide authentication (checks the user's credentials) but do not check authorization (account expiration date, user rights, etc.) All users authenticated using the LDAP, RADIUS, and TACACS+ servers have administrative rights (i.e. a user account) and can modify the AirLink gateway settings. Ensure that LDAP, RADIUS, and TACACS+ users are authorized to modify device settings.
- LDAP, RADIUS, and TACACS+ are supported for ACEmanager logins, but are not supported by other AirLink gateway services such as Telnet, SSH, PPPoE, etc.

For instructions on configuring these authentication schemes, see:

- LDAP Authentication on page 272
- RADIUS Authentication on page 275
- TACACS+ Authentication on page 276

LDAP Authentication

Lightweight Directory Access Protocol (LDAP) is a network protocol for accessing and manipulating information stored in a directory. It is suitable for using with information that must be easily available and accessible, and does not change frequently. AirLink gateways support LDAP version 3.

To configure LDAP:

- **1.** Go to Services > Authentication.
- 2. In the LDAP Client field, select Enable.

ar arrest \$140, 101222 (144)	to an Pier	Departure (marked (Amager) (224)
atms	(LLDAP	
ACD manager	SDN ⁴ -Clevel	Traine
Front Nanoperium	LEAP Barrow	
Tytamic DES	PM	309
	Tenand (another)	30
SM15.	Emilyphia	North -
FT (Tailend: 1154)	Hate (20	
Constitution of Constitution	BedDA	Annyment of
hanagement (\$3444)	PERSON	
Tarine (Children)	(HOHOR-	
All		
Sentre Bales Screee		

Figure 9-23: ACEmanager: Services > Authentication > LDAP

- 3. Enter:
 - The LDAP server IP address or resolvable domain name
 - The Port number (default is TCP port 389)
- Ensure that the LDAP server IP address/port is reachable not only from outside the company, but also from inside the mobile network your gateway is on.
 You can use a utility such as netcat to test this. If netcat is available try: nc -z <IP> <port>; echo \$?
 0 means success; 1 means failure.
- 5. Configure the other fields as described in the following table.

Field	Description
Timeout (seconds)	 The time limit for the server to respond 1-60 seconds (default is 30)
	Note: If the server does not respond during the timeout (no route to host, server down, network too slow etc.), the authentication fails and the next enabled authentication mechanism checks the credentials.
Encryption	 Select the encryption type Options are: None SSL—Secure Sockets Layer protocol—Non-standard legacy (pre-LDAPv3) encryption type StartTLS—Secure mechanism integrated into the LDAPv3 protocol (default)
Base DN	The Base DN is the path in the LDAP tree to the list of users (example shown is dc=sierrawireless,dc=com). This is where the LDAP protocol searches for a matching user to authenticate.

Field	Description	
Bind DN	Choose how the LDAP search is done Options are:	
	 Anonymous—A password is not required to perform requests in the database (default) 	
	• Explicit—A password is required to perform requests in the database	
Bind DN User	This field only appears if you selected Explicit in the Bind DN field The full path of the user authorized to perform requests in the LDAP database (example shown is cn=admin,dc=sierrawireless,dc=com)	
Bind on Password	This field only appears if you selected Explicit in the Bind DN field Password associated with the Bind DN user	

6. Click Apply.

RADIUS Authentication

Remote Authentication Dial In User Service (RADIUS) uses UDP and checks authentication credentials, using a shared key.

To configure RADIUS:

- **1.** Go to Services > Authentication.
- 2. In the RADIUS Client field, select Enable.

1.4-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-	cou PM	Second to Second	1 (COURS (CC)
		Recorded to the	
A.M.S.	Indigent.		
CI manager	(14mm		
North Ministernia	(10440x36		
Sylventeri 1915	R4DUILDeet	Tom -	
	RADUS Sever		
Get.	Post .	1012	
F (Tempt 1544)	Tanenud (sarumata)	30	
answer (1944-1979)	(hereit		
Reiningermann (195887)	(HINGACE+		
line (XM77)			
attention (
Annual Status Screen			

Figure 9-24: ACEmanager: Services > Authentication > RADIUS

3. Configure the other fields as described in the following table.

Field	Description
RADIUS Server	RADIUS server IP address or resolvable domain name
Port	By default, RADIUS uses UDP port 1812
Timeout (seconds)	 The time limit for the server to respond 1-60 seconds (default is 30)
	Note: If the server does not respond during the timeout (no route to host, server down, network too slow etc.), the authentication fails and the next enabled authentication mechanism checks the credentials.
Secret	Shared secret for configured server

4. Click Apply.

TACACS+ Authentication

Terminal Access Controller Access-Control System Plus (TACACS+) uses TCP protocol and encrypts the entire packet, except the header.

To configure TACACS+:

- **1.** Go to Services > Authentication.
- 2. In the TACACS+ Client field, select Enable.

4.400031010-0102010-01	110 PM	Duration (such States)	1
ALIES ACLINIANAGON Promet Managonismi Nykanna 1983	PLD#P PLADUS To NORDE		
SMS. 67 (Tailant 1154)	TROACH Olant TROACH Clant	(Date - +	
innan (SUITT)	Toreaut (provide) Authoritization contrin	- 69 - 30 - 56	
Name address	Incel		
Autoritation			

Figure 9-25: ACEmanager: Services > Authentication > TACACS+

- 3. Enter:
 - The TACACS+ server IP address or resolvable domain name
 - The Port number (default is TCP port 49)
- 4. Ensure that the TACACS+ server IP address/port is reachable not only from outside the company, but also from inside the mobile network your gateway is on.

You can use a utility such as netcat to test this. If netcat is available try:

nc -z <IP> <port>; echo \$? 0 means success; 1 means failure.

Field	Description
Timeout (seconds)	 The time limit for the server to respond 1-60 seconds (default is 30)
	Note: If the server does not respond during the timeout (no route to host, server down, network too slow etc.), the authentication fails and the next enabled authentication mechanism checks the credentials.
Authentication service	 The type of bind used for authentication Options are: PAP—Password Authentication Protocol (default) CHAP—Challenge Handshake Authentication Protocol The stronger of the two protocols. Recommended, provided it is supported by all the client devices. Login—User name and password
Secret	Shared secret for configured server

5. Configure the other fields as described in the following table.

6. Click Apply.

Device Status Screen

The Device Status Screen feature, when enabled, allows you to add Location and network status parameters to the ACEmanager Login screen. Once enabled, subsequent log ins to ACEmanager display whatever status parameters have been previously checked on the Device Status Screen.

		family parents (com
41.845	Disate Deits States on Logs foreen	Jase -
ACCOUNTER!	Thutus to Migliny	
Power Management	Location Status	Network Matwo
www.garafia.en	 Locator Fe 	Citedeon Date
Pyromia: DNS	Citatette Coart	Charlest Charnel
INTE	Clatters	Cases
	Linguise	Chatternet.Banaca
it (heads to b)		Citation #
inval (200179)		Coston
farming an owned of the state in		Cette
		CTE Signal Iteraph (R28P)
1909 (1919-1975)		Cutt Open Overle (RDRO)
attestication .		CLTE Dignal Interference (2014)

Figure 9-26: ACEmanager: Services > Device Status Screen

Field	Description
Enable Device Status on Login Screen	Enables device status parameters on the Login screen Options are: Disable or Enable (default)
Status to display	Select the location and network status parameters to display on the Login screen

>> 10: Location

Most AirLink devices are equipped with location tracking to ascertain their position and track the movements of a vehicle or other devices that move. The AirLink RV55 relays the information of its location as well as other data for use with tracking applications.

Common Uses for Location

- Driver navigation—The AirLink gateway provides real time location data via the serial or Ethernet port to a local application, including applications that provide mapping and navigation support.
- Automatic Vehicle Location (AVL)—The AirLink gateway provides real time location data to the server that tracks the location and other variables of the vehicle or asset.

ALEOS Supported Location Report Protocols

• Remote Access Protocol (RAP)

RAP is a proprietary binary message format developed and maintained by Sierra Wireless and used by many 3rd party applications. Because it is designed and maintained by Sierra Wireless, RAP supports more ALEOS features than other location protocols. It is a low-byte-usage protocol that can be used to develop low cost AVL solutions.

The RAP messages are in hex and are referred to by their message ID. Reports can include location data alone, as well as location data with the date and time, radio frequency data, radio status information, and I/O state changes, and power state changes. For an example, see Location RAP Report Sequence Example on page 296. For more information, contact your Sierra Wireless Sales representative for information on how to obtain a copy of the RAP Protocol Guide.

National Marine Electronics Association (NMEA[®])

NMEA is an ASCII protocol used by many location tracking applications.

• Trimble[®] ASCII Interface Protocol (TAIP)

TAIP is a digital communication interface based on printable ASCII characters over a serial data link. TAIP was designed specifically for vehicle tracking applications but has become common in a number of other applications, such as data terminals and portable computers, because of its ease of use.

• Xora[®]

Protocol specific to Xora asset management and tracking applications

Before Configuring Location

To decide what configuration you need for your AirLink gateway, there are some fundamental considerations you should determine:

- **Protocol**—What is the location protocol used by your tracking application and what type of reports will you need? (See Location Report Type on page 291.)
- **Dynamic IP Address**—Does your device have a dynamic IP address and you need to track the specific asset? (See Device ID in Local Reports on page 303.) You can also associate your device with a dynamic DNS configuration. (See Dynamic DNS on page 235.)
- Server location and type of connection—Will you be using a local server, a remote server, or both? Will you need a serial or local IP connection?
- Multiple Location servers—Will you need to have location data sent to more than one location server?




Figure 10-1: Server location and connection type

Note: Most Global settings (described on page 281) apply to remote and local servers. All location configuration changes go into effect immediately. No reboot of the AirLink gateway is necessary. After you configure any settings there is a short pause in receiving location reports while the device is re-initialized with the new configuration.

Enable Location Service

To enable Location Service:

1. In ACEmanager, go to Location.

Stream WAR'de Islam LAN	VPN Security Services Uscalion Diverse R	aporting Sertal Applications IVO Admin
Loding date there: 2.2 A ANR 2.37 1993.	1	Ferrar M. T. Apply T. Generic T. Sand
Chinal Reflexy.] Institut Scillings	
	Louidon Savite	Diase -

Figure 10-2: ACEmanager: Location

- **2.** In the Location Service field, select Enable.
- 3. Click Apply.
- 4. Reboot the gateway.

Global Settings

Note: Most of the Global settings apply to all location server and local reports. These screens are only visible when Location is enabled. See Location Service on page 282.

	Deal Will LLB VPD Security Services Local					
Aug. (1999) (1999)	11.30.00.00	Transfer (and the first				
and Latings						
	Huruma beinge					
armai 1	Locator Sense	lines +				
error 2						
errort 2.	Tap General .					
	47 Statuments' status (chalters)	0				
arrest 4	W THE D					
and Descening	AT Send for Bully statements to paid	Taxes +				
	47 Use Device D in Location Reports	(Dates -				
	Adoptiant					
	AT TOP Location Plat.	9494				
	Location For Moda	Sandation				
	Heading Decolutio	Anna -				
	QNEER Redword Weiktholog	inam -				
	Environ NAMES Longung (SVALE Including)	fram -				
	Einweitood friktick Films	Numerical INTA Place				
	Crittii www.mailkee	inan -				
	(271 He Dignal Hakhding (mm.Ava)	Desen +				

Figure 10-3: ACEmanager: Location > Global Settings

Field	Description				
Location Settings					
Location Service	 Sierra Wireless recommends that you disable Location if you are not using location reporting. Options are: Enable (default) Disable The change takes effect after you reboot the gateway. 				
General — These fields	only appear if Location Service is enabled.				
Odometer Value (meters)	The odometer value increments based on the location distance traveled. You can include this value in RAP location reports. (See Location Report Type on page 291.) You can set the odometer value to an initial value in meters (kilometers × 1000 or miles × 1609.344). Maximum value is 4 294 967 295 meters (4,294,967 kilometers or 2,668,769 miles). Default: 0				
	Note: The RAP report displays the odometer value in 100s of meters.				
	You can also use an AT Command to set this value. For more information, see *PPODOMVAL on page 530.				
TAIP ID	The four character alphanumeric ID used in all TAIP reports You can also use an AT Command to set this value. For more information, see *PPTAIPID on page 531.				
Send SnF Buffer immediately on input	 If this feature is enabled, any pending stored reports are sent if the I/O input changes, a stationary vehicle is moved, or a maximum speed is exceeded, provided those events are enabled on the Location > Server > Events screen. Options are: Disable (default) Enable You can also use an AT Command to set this value. For more information, see *PPFLUSHONEVT on page 527. 				

Table 10-1: Location: Global Settings

Table 10-1: Locat	ion: Global	Settings
-------------------	-------------	----------

Field	Description					
Use Device ID in Location Reports	 Allows use of the IMEI/ESN or phone number in RAP and NMEA reports configured for Servers 1–4 to identify a device/vehicle. Options are: None (default) Phone Number ESN/IMEI You can also use an AT Command to set this value. For more information, see *PPDEVID on page 527. 					
	Tip: Including the device ID is especially useful when your devices have dynamic IP addresses.					
	Note: The device ID in RAP and NMEA reports is in hex, not plain text.					
	Note: This option does not apply to Local IP reports. If you want the device ID included in local IP location reports, see Device ID in Local Reports on page 303.					
	Note: If you want this Device ID included in the TCP PAD connections, enable the Include Device ID on TCP Connect field on the Serial screen (Serial > Port Configuration > TCP). See Port Configuration on page 289.					
Advanced — These field	ds only appear is Location Service is enabled.					
TCP Location Port	 You can obtain a single location snapshot from the device via a TCP session using the AirLink gateway's IP address and the device port configured in this field. 1-65535 (default 9494) 0 = Disable You can also use an AT Command to set this value. For more information, see *PPTCPPOLL on page 531. 					
	Note: Access is restricted to the IP address defined for server 1. (See Report Server IP Address on page 292.)					
Location Fix Mode	 Specifies the location fix mode. Options are: Standalone (default) MS Based—(Mobile Station Based fix) Uses assistance location data from a remote server over the WAN interface 					
Heading Sensitivity	 Sets the sensitivity of the location heading reading Normal (default) High It is recommended that you leave the field set to Normal to avoid showing misleading heading values from poor location signal (poor sky view, reflections in urban canyon, etc.), but if your location application has its own location heading sensitivity algorithms, try changing this setting to High. 					

Field	Description
GNSS Reboot Watchdog	 Enables or disables automatic GNSS-related reboots. Disabling the GNSS Reboot Watchdog helps maintain data connectivity if GNSS-related errors occur. Errors that might prompt a reboot include: GNSS fix loss GNSS tracking restarts NMEA data stream loss Options: Enable (default)—The RV55 reboots after GNSS-related errors Disable
Enable NMEA Logging (GNSS debugging)	 Enables or disables writing NMEA (and proprietary debug) sentences to a log file for troubleshooting purposes. To download the NMEA log file, see Download NMEA Files. Options: Enable—starts compiling the log file Disable (default)

 Table 10-1:
 Location:
 Global
 Settings

 Table 10-1: Location: Global Settings

Field	Description
Download NMEA Files	As part of the troubleshooting process, you may be asked to download NMEA sentences before sending them to Sierra Wireless or your distributor. If asked to do so, first enable NMEA logging (see Enable NMEA Logging (GNSS debugging)), and then: 1. Click the Download NMEA Files button. The following window appears.
	Generate NMEA Files Package Keep MMEA. Hea after downbud
	2. If you are instructed to do so by Sierra Wireless Tech Support, select the check box beside "Keep NMEA files after download". Otherwise, leave the check box unselected.
	3. Click Generate NMEA Files Package.
	Download NMEA Files Close
	Ceserate NMEA Files Package
	4. Once you see the message that the NMEA Files Package has been successfully generated, click Download NMEA Files Package, select Save File and click OK.
	Comming review INDEX DOTING Days From here channels to comm
	5. Navigate to where you want to save the file.

Field	Description					
GNSS Antenna Bias	Configure the GNSS antenna bias Options are: Enable—Use this setting if you are using an active GNSS antenna. (Default) Disable—Use setting if you are using a passive GNSS antenna.					
GPS No Signal Watchdog (minutes)	 This field is used by TechSupport to troubleshoot Location problems. Otherwise it is best to leave the default setting. If the GPS receiver does not receive any GPS signals for the period of time (in minutes) configured in this field, the gateway reboots. Options are: Disable (default) 10 20 30 40 50 60 					

 Table 10-1: Location: Global Settings

Servers 1 to 4

You can configure up to four servers as report destinations. Each server is configured independently and can be configured to report the same or different information. This enables you to simultaneously receive location and other information at more than one location, either local or remote.

The configuration fields are the same for each of the four servers, except that Server 1 has the option to configure one or two redundant servers.

Note: These side tabs only appear if Location Service (on the Global Settings side tab) is Enabled.

Note: These screens are only visible when Location is enabled. See Location Service on page 282.

To configure one of the servers:

- 1. In ACEmanager, go to Location.
- 2. From the menu on the left side of the screen, select the Server you want to configure.

Ratay WAWCellular	WH	LAN	Abili .	Security	Services	Location	Evenue Reporting	Seriel	Applications	30.1	Admin
elliptical and a second second	120422-04							8	(mm1)10 (mm	-	
Skobel Settings											
		HELEN									
Server 1		AT Report	Drianal Tim	e (seconits)			0				
Sarver 2		AT mapon	THREW Dra	tance oneters			0				
Server 3		AT statute	way webicts	Interval Time (renalieux		0				
		Maure	um Speec B	vent Report to	-	Ю.	0				
Server 4		Station	way Mehicle	Event threathold	(abnockes)		0				
ocal Stroaning		AT Data	InputErent				Drate v				
		History	type:								
		Lacat	on Report Fa	ternat.			Wederhed				
		WI LINE	in Report T	5+			Location Data				
		Howers									
		AT Report Server 1 IP Address									
		AT Report Server 1 Part Number					22335				
		Hetur	start Sever	1 P ADDess							
		Setur	dant Server	1PortNumbe			0				
		Redu	daki berver	218 400495							
		Reter	dant Derver	2 Port Number	e		0				
		AT Minimum Report Time (records)					0				
		Hiteese	oti Dire e	et Ferward							
		AT 3HE for Unreliable Mode					Saula +				
		AT that Photos Muda					GFT (developm thate)				
		Af Shif Single Relate Hannani Rebies					10				
		AT Shift broote Hariaste Baskoff Time (seconds)					10				
		HAdda	ar Cuta								
		AT Report Goometer					Deather w				
		AT Gapor	Cigital Inpu	41			Dade +				

Figure 10-4: ACEmanager: Location > Server 1

Field	Description					
Events — Configure wi	nen the location reports are sent					
Report Interval Time (seconds)	 Location Report Time Interval The amount of time between location reports (in seconds) Options are: 1-65535 0 = Disables location reporting based on a time interval (default) With this option disabled, you can still receive reports based on distance traveled or the vehicle being stationary for a configured time. (See Report Interval Distance (meters) on page 288 and Stationary Vehicle Timer (minutes) on page 289.) You can also use an AT Command to set this value. For more information, see *PPTIME on page 531. Note: Your cellular carrier may impose a minimum transmit time. 					
Report Interval Distance (meters)	 Location Report Distance Interval in meters The distance (in meters) that the vehicle (or device) travels between sending location reports Options are: 40–65535 Note that setting the resolution near the low end of the range may result in incorrect reports as a result of location jitter (i.e. apparent motion caused by the inherent inaccuracy in location measurements). 0 = Disables sending location reports based on a distance interval (default) With this option disabled, you can still receive reports based on time passed or the vehicle being stationary for a configured time. (See Report Interval Time (seconds) on page 288 and Stationary Vehicle Timer (minutes) on page 289.) You can also use the AT Command, *PPDISTM, to set this value. For more information, see page 527. 					
	Note: An an additional AT Command, *PPDIST, allows you to configure the location report distance interval in 100 meter units. This option is only available through AT Commands. For more information, see page 527. Note: If the report interval time and report interval distance fields are both set, location reports are sent when either interval is reached. For example, if the time interval is reached, a location report is sent even if the distance is not reached. Conversely, if the vehicle travels the specified distance, a location report is sent even if the time interval was not reached.					

Table 10-2: Location: Servers 1-4

Table 10-2: Location: Servers 1-4

Field	Description	
Stationary Vehicle Timer (minutes)	 You can use this field if you want to receive less frequent reports when the vehicle is stationary. A location report is sent every x minutes the vehicle (or device) is stationary, where x is the value configured in this field. When the vehicle is stationary, this value overrides the value configured in the Report Interval Time field. Options are: 1-255 0 = Disables location reporting based on a vehicle being stationary (default) You can also use an AT Command to set this value. For more information, see *PPTSV on page 531. 	
Maximum Speed Event Report (km/h)	 A location report is sent if the speed (in kilometers per hour) configured in this field is exceeded, and again when the speed goes back down below the configured value. 0 = Disable (default) 1-255 	
	 Note: If you are using one of the RAP location report types (see Location Report Type on page 291) the location report triggered by this feature includes: A marker to indicate that it was triggered by the configured speed being exceeded and when the speed is goes back down below the configured value. The standard location information for the configured report type For more information, refer to the RAP Protocol Guide. If you are not using a RAP location report, a standard report is sent. 	
Send Stationary Vehicle Event in Seconds	 A location report is sent if the vehicle (or device) has been in one location for more than the specified time (in seconds) and again when the vehicle (or device) moves from that location. Options are: 1-255 0 = Disables sending location reports based on a vehicle being stationary (default) Note: If you are using one of the RAP location report types (see Location Report Type on page 291) the location report triggered by this feature includes: 	
	 A marker to indicate that it was triggered by the vehicle either being stationary or starting to move again The standard location information for the configured report type For more information, refer to the RAP Protocol Guide. If you are not using a RAP location report, a standard report is sent. You can configure Stationary Vehicle Event in Seconds and Stationary Vehicle Timer together to receive a special report when the device is stationary longer than x seconds, a normal report every x minutes it is stationary (instead of the Report Interval Time) and a special report when the vehicle begins moving again. 	

Field	Description		
Enable Digital Input Event	 A location report is sent if the configured digital input changes. For example, this could be used to trigger a report being sent when an emergency light or siren is turned on or off, or when a door is opened or closed. The location data in the report informs you of where the event took place. Options are: Disable (default) Enable 		
	Note: If you are using one of the RAP location report types (see Location Report Type on page 291) the location report triggered by this feature includes:		
	• A marker to indicate that it was triggered by a change in status of the configured digital input		
	The standard location information for the configured report type		
	For more information, refer to the RAP Protocol Guide.		
	If you are not using a RAP location report, a standard report is sent.		
	You can also use an AT Command to set this value. For more information, see *PPINPUTEVT on page 528.		
Report Type			
Location Report Format	 Configures the format of location reports. Options are: Predefined (default)—When selected, the reports contain TAIP and NMEA GPS strings. If Predefined is selected, you can select Location Report Type. See Location Report Type on page 291. User-defined NMEA—You can enable or disable GGA, RMC, VTG, GSA, and GSV sentences individually. 		
	VIG Deble v		
	161A Thomas J		
	CSV Death v		

Table 10-2: Location: Servers 1-4

Table 10-2: Location: Servers 1-4

Field	Description
Field Location Report Type	 If the Location Report Format is Predefined, sets the type of location report. Options are: RAP Location Data—RAP location report that contains only location data Location+Date—RAP location report that contains location data with the UTC time and date (default) Location+Date+RF—RAP location report that contains location data, the UTC time and date, and radio frequency information for the cellular connection Location+Date+RF+EIO—RAP location report that contains location data, the UTC time and date, radio frequency information for the cellular connection Location+Date+RF+EIO—RAP location report that contains location data, the UTC time and date, radio frequency information for the cellular connection, and the current I/O state Note: The maximum satellite count for RAP reports is 15. If there are more than 15 satellites visible, RAP reports 15 satellites. To see the actual number of satellites, go to Status > Location. NMEA NMEA GGA+VTG—NMEA location report that contains fix information, vector track, and speed over ground NMEA GGA+VTG+RMC—NMEA location report that contains fix information, vector track, and speed over ground, and recommended minimum location data NMEA GGA+VTG+RMC+GSA+GSV—NMEA location report that contains fix information.
	Note: Only RAP location reports can be configured to include odometer and digital I/O information. Note: You can also use an AT Command to set this value. For more information, see *PPGPSR on page 528.

Field	Description	
Servers—Configure where the reports are sent		
Report Server IP Address	IP address or FQDN (fully qualified domain name) of the server where location reports are sent	
	Example: 192.100.100.100	
	The IP address can be for a local host or a remote server that is accessed over-the-air or via a VPN tunnel.	
	If an IP with the last octet of 255 is configured (i.e. 192.168.13.255), a report would be broadcast to all IPs on that subnet. When configured to a local host subnet, any connected device would receive the report.	
	Note: If you want to use it as a LAN device, it must have a private IP address. If you want to use a public IP address, use a Local IP report. (See Local/Streaming—Local IP Report on page 300.)	
	You can also use an AT Command to set this value. For more information, see *PPIP on page 528.	

Table 10-2: Location: Servers 1–4

Field	Description			
Report Server Port Number	 Destination port on the server where location reports are sent The destination port can be the same for all servers or you can configure a different destination port for each server. Options are: 1–65535 Defaults: Server 1 destination port: 22335 Server 2 destination port: 22336 Server 3 destination port: 22337 Server 4 destination port: 22338 You can also use an AT Command to set these values. For more information, see *PPPORT on page 530. Note: If the account is behind a firewall (for example, an account that is not Internet-routable), the report may be redirected to come from a different source port when it arrives 			
	at the server. The source ports on the device are not configurable. The following source ports are used: Protocol Server Port			
	RAP/NMEA	1	17335	
		2	17345	
		3	17346	
		4	17347	
	ТАІР	1	21000	
		2	21001	
		3	21002	-
		4	21003	-
	XORA	1	9494	
		2	9495	
		3	9496	
		4	9497	

Table 10-2: Location: Servers 1-4

Field	Description	
Redundant Servers — Only available for Server 1		
redundant server(s). Transpo	nfigured, whenever a report is sent to server 1, an identical report is sent to any configured ort/SNF configuration settings do not apply to redundant servers. Commands from redundant originate from port 17335. The redundant servers can be a local host or a remote server or via a VPN tunnel.	
Redundant Server 1 IP Address	IP address or FQDN of the first redundant server	
Redundant Server 1	Port number of the first redundant server	
Port Number	The port number can be the same as or different from that of other servers.	
Redundant Server 2 IP Address	IP address or FQDN of the second redundant server	
Redundant Server 2	Port number of the second redundant server	
Port Number	The port number can be the same as or different from that of other servers.	
Minimum Report Time (secs)	Specifies the minimum time (in seconds) between partial reports or grouped packets being sent	
	You can also use an AT Command to set this value. For more information, see *PPMINTIME on page 529.	
when the device is again abl There are four Location serv maximum of 395 reports. The	e to reach the report server. Reports are stored and then "forwarded" in a combined packet e to contact the server. ers and five Events Reporting servers. Each server has its own buffer and can store a e maximum length of each report is 255 bytes. Note that this is separate from any SNF done of the AirLink Vehicle Telemetry Application (AVTA).	
SNF for Unreliable Mode	Store and Forward causes location reports to be stored if the AirLink gateway goes out of network coverage. Once the device/vehicle is in coverage the stored location reports are sent to the server. Options are:	
	 Disable (default)—If there is no mobile network coverage, reports are not stored. Enable—If there is no mobile network coverage, reports are stored until the AirLink gateway can access the server. 	
	Note: When you are using location and Wi-Fi Client mode: If the Wi-Fi client is connected, reports are sent over the Wi-Fi WAN connection rather than the mobile network. With SNF for Unreliable Mode enabled, if the Wi-Fi WAN connection is active and the cellular connection is not (i.e. out of the cellular coverage area) reports continue to be sent over Wi-Fi. Only if both networks are down are the reports stored and forwarded later when either network is back up.	
	Note: You can also use an AT Command to set this value. For more information, see *PPSNF on page 530.	

Table 10-2: Location: Servers 1-4

Field	Description	
SNF Reliable Mode	 Store and Forward Reliability: location reports are retransmitted if not acknowledged by the server. Options are: OFF (Unreliable Mode) (default)—If this field is Off, the device does not expect acknowledgment to any location report sent to the server. Reliable Mode—A sequence number (1–127) is added to each packet (page). The server acknowledges every 8th packet. If there is no ACK from the server, ALEOS pings the server and re-sends the packets when the server responds. If the server receives packets out of sequence, the server NAKs the first and last missed packets. ALEOS retransmits the missing packets. Note: Reliable mode is valid only when a RAP report is selected as the Location Report Type. Simple Reliable Mode—ALEOS attempts to contact the server the configured number of times, after which it stops attempting to contact the server and discards messages that cannot be transmitted or received after the configured number of tries. When contacted, the server responds with the ASCII string UDPACK. For information on configuring the maximum number of retries see SNF Simple Reliable Max Retries on page 295. For information on configuring the backoff time, see SNF Simple Reliable Backoff Time (secs) on page 295.) UDP Sequence Mode—A hex sequence number (30–7f) is prepended to the packet. The server responds with SEQACK and the sequence number. The sequence number is not stored and is re-initialized when the AirLink gateway is reset or power cycled. Unacknowledged packets are dropped after the configured number of retries. TCP Listen Mode—This mode is the same as UDP Sequence Mode, except that the server initiates the connection using TCP. Use this mode if your server is behind a firewall. If you are using this mode, the AirLink gateway must have a mobile terminated/Internet routable IP address. TCP—By default, location reports are sent over UDP. Select this option if you want the location reports sent over TCP. Because	
SNF Simple Reliable Max Retries	 When the AirLink gateway is configured to use Simple Reliable Mode, use this field to set the maximum number of retries when a report is sent and there is no response. Use the SNF Simple Reliable Backoff Time (secs) field to set the interval between retries. Options are: Disabled 1–255 retries (Default is 10.) You can also use an AT Command to set this value. For more information, see *PPMAXRETRIES on page 529. 	
SNF Simple Reliable Backoff Time (secs)	 When the AirLink gateway is configured to use Simple Reliable Mode, use this field to set the interval for the retries. (Use the SNF Simple Reliable Max Retries field to set the maximum number of retries.) 0-255 (Default is 10.) You can also use an AT Command to set this value. For more information, see *PPSIMPLETO on page 530. 	

Table 10-2: Location: Servers 1-4

Field	Description		
	Additional Data When configured, these options add additional data to RAP reports (see Location Report Type on page 291) sent in response to any trigger.		
Report Odometer	 Enables odometer reporting. Options are: Disable (default) Enable You can also use an AT Command to set this value. For more information, see *PPODOM on page 530. 		
Report Digital Inputs	 Enables digital input reporting. Options are: Disable (default) Enable You can also use an AT Command to set this value. For more information, see *PPREPORTINPUTS on page 530. 		

Redundant Servers

When one or two redundant servers are enabled, each time a message is sent out to the main server a second identical message is sent to the redundant server(s).

The redundant servers can be running the same or different application than the primary server. The messages to the redundant server are independent of the primary server settings or state.

You can configure one or both redundant servers. The messages are sent independently to either or both.

Note: Messages are sent whether or not the server is available and do not use any reliable mode format. Receipt of a message is not acknowledged nor is any message resent. Messages to redundant servers are in UDP only.

Location RAP Report Sequence Example

In this example:

The AirLink gateway is installed in a police car.

- Digital input 2 is connected to the switch that controls the siren.
- Digital input 3 is connected to the laptop docking station.

ACEmanager has the following configuration:

- Report Interval Time: 30 seconds
- Report Interval Distance: 150 meters
- Stationary Vehicle Timer: 5 minutes
- Send Stationary Vehicle Event in Seconds: 6 seconds
- Maximum Speed Event: 100 km/h
- Enable Digital Input Event: Enable
- Report Type: Location + Date (RAP location report type 0x12)
- Low Voltage Standby Mode: Automatic

digeneerse driftperis	angere.	Tarnet Arry Reiner Co		
Juliet Settings				
))Eem			
iarout 1	All Report Internet Turns (Seconda)	30		
Writer 2	M Record advance of Production International	150		
	Af Itakoury where intend from immuted	5		
C revisi	Maximum Speed Every Report Resolution (crists)	100		
Getwee 4	Badavar, telette Event Brechnit (karanik)	4		
Local Streaming	All Graphic Input Dorrel	Enates -		
	L (Asped Type	Concerta F		
	Location Report Format	Provided T		
	WT custom Report Type	Lanamon Dada w		
	() Denore			
	In Datapart. Item and Fernant	1-1 Trainant- Itan and Farward		
	1+) AND INVESTIGATION			

Figure 10-5: ACEmanager: Location > Server 1—Example

The following table provides a sample scenario for this ALEOS configuration.

Event / Action	Location RAP report sent to the server
The AirLink gateway in the police car is connected to power for the first time.	A 0x10 (power up) report is sent.
The police car is driving around the patrol area.	A 0x12 (Location + Date) report is sent every 150 meters or every 30 seconds, whichever is less.
The police officer spots a speeding vehicle, switches on the siren, and pursues the vehicle.	Digital input 2 which is connected to the siren switch is triggered and a 0x27 (DIN 2 changes to 1) report is sent.
The vehicle speeds up, with the police car in pursuit.	When the police car exceeds 100 km/h, a 0x2e (maximum speed exceeded) report is sent. A 0x12 (Location + Date) report is sent every 150 meters.
The vehicle being pursued and the police car slow down.	When the police car's speed goes below 100 km/h, a 0x2f (return to normal speed) report is sent.
The speeding vehicle pulls over and stops at the side of the road. The police car pulls in behind it. The officer turns off the siren, leaves the engine idling, gets out of the car, and walks over to the other vehicle.	Digital input 2 which is connected to the siren switch is triggered, and a 0x26 (DIN 2 changes to 0) report is sent. Six seconds after the police car comes to a stop, a 0x2c (stationary vehicle event) report is sent. While the car remains stopped with the engine idling, a 0x12 (Location + Date) report is sent every 5 minutes.
The officer issues a ticket, returns to the police car and drives away.	When the police car is back in motion, a 0x2d (started moving event) report is sent. A 0x12 (Location + Date) report is sent every 150 meters or 30 seconds, whichever is less.
The police car stops in front of the police station.	Six seconds after the car stops, a 0x2c (stationary vehicle event) report is sent.

Event / Action	Location RAP report sent to the server
The officer disconnects the laptop from the dock.	Digital input 3 connected to the docking station is triggered. A 0x28 (DIN 3 changes to 0) report is sent.
The officer turns off the ignition.	Before the AirLink gateway goes into Low Power Standby mode, it sends a 0x30 (entering Low Power mode) report.
The officer on the next shift gets into the car and turns on the ignition.	When the AirLink gateway wakes up from Low Power Standby mode, it sends a 0x31 (Wake up from Low Power mode event) report.

Local/Streaming

Some in-vehicle/navigation applications accept location reports via a serial connection, generally using either NMEA or TAIP. To configure serial streaming for DB-9 (RS-232) ports and/or USB Serial ports, go to Location > Local/Streaming. Reports are sent as ASCII text.

Note: These screens are only visible when Location is enabled. See Location Service on page 282.

argenterters scatter-	12.22.43.44	Canada Santa Antonio Can
Rhited Settings		
benar 1	11 Bartal	
Derver 1	At Location Reports port	404
Barrettr 3	Location Reports Format	Protectional and
Leiver 1	WT Location Reports Type	WEA SCALVTD-RMC -
	#T Location Reports Frequency (Instantis)	0
Server 4	AT Lucation Coverage	468878
Actal Streaming	AT Locator Reports Delay (seconds)	0
	Dettantal P. Beand	

Figure 10-6: ACEmanager: Location > Local/Streaming > Serial

Field	Description				
Serial					
Location Reports port	 t The serial port or USB serial link that reports are sent to. Options are: NONE (default) DB9 Serial USB Serial DB9 and USB You can also use an AT Command to set this value. For more information, see *PGPS on page 525. Note: If you want to stream location data to a USB port, the USB port must be configured on the LAN > USB page to act as a serial port. See USB Device Mode on page 157. 				
Location Reports Format	 Configures the format of location reports to send using the serial link. Options are: Predefined (default)—When selected, the reports contain TAIP and NMEA GPS strings. If Predefined is selected, you can select Location Reports Type for serial streaming. See Location Reports Type on page 299. User-defined NMEA—You can enable or disable GGA, RMC, VTG, GSA, and GSV sentences individually. 				
Location Reports Type	 If Location Reports Format is Predefined, select the ASCII text location report type to send via the serial link: NMEA GGA+VTG+RMC—NMEA location report that contains fix information and vector track and speed over ground, and recommended minimum location data (default) NMEA GGA+VTG+RMC+GSA+GSV—NMEA location report that contains fix information and vector track and speed over ground, the recommended minimum location data, overall satellite data, and detailed satellite data TAIP data—TAIP location report that contains the compact position TAIP LN report—TAIP location report that contains a long navigation message TAIP TM report—TAIP location report that contains the time and date You can also use an AT Command to set this value. For more information, see *PGPSR on page 526. 				
Location Reports Frequency (secs)	 page 526. How frequently (in seconds) the location report is sent to the serial link. Options are: 1-65535—(up to 18.2 hours) You can also use an AT Command to set this value. For more information, see *PGPSF on page 526. 				

Table 10-3: Location: Local/Streaming

Field	Description			
Location Coverage	This field refers to the mobile network coverage.			
	Options are:			
	ALWAYS (default)—Location reports are always streamed to the serial link.			
	 Out of Coverage—Location reports are only streamed to the serial link when the device has no cellular connection. 			
	You can also use an AT Command to set this value. For more information, see *PGPSC on page 526.			
	Tip: The Out of Coverage option enables you to use a backup in-vehicle mapping application that does not rely on mobile network access.			
Location Reports Delay (secs)The delay (in seconds) before the out of the coverage stream begins. This applies if the location coverage field is set to "Out of Coverage".				
	• 0 (default)			
	• 1-255			
	You can also use an AT Command to set this value. For more information, see *PGPSD on page 526.			

 Table 10-3:
 Location:
 Local/Streaming

Local/Streaming—Local IP Report

Local IP reports are limited to tethered IP-based LAN devices (Ethernet, USB/net, DUN, PPPoE). Local IP reports do not have any transport/SNF options. The reports are always sent regardless of cellular coverage. Reports are sent over UDP.

The destination IP cannot be configured directly. The first connected LAN device is used. If multiple devices are connected, the priority is the device using the Public IP address, or if all devices are using Private IP addresses, the priority is:

- Ethernet
- USB
- DUN

Note: These screens are only visible when Location is enabled. See Location Service on page 282.

natus VAASCalluter W	Lan very security services Locat	en Events Reporting Secul Applications EE Ac	ann -
elaborite terminant	al ma	Thursday The	0 62
Solial Sellinge	[ref.berm		
kervert 2	Distance of the Management		
Karner T	Of Local Reporting Tens Internal (seconds)	0	
Server 4	Location Reports Format	Productional in	
	AT Local Report Type	Taxantee-Dele w	
ALL DEVENING	Tarling Destination Part	0	
	AT Number of Edge Deallmation Polys	.0	
	Denne El a Lucal Reporte	late w	
	Local Report Distance Mode	Treatment 🔍	
	Local Report Deathation (P	182.168.14.139	
	Wag of Dolorader	Date w	
	Report Digital Installe	Deem w	

Figure 10-7: ACEmanager: Location > Local/Streaming > Local IP Report

Table 10-4: Location: Local/Streaming—Local IP Report

Field	Description				
Local Reporting Time Interval (seconds)	 The frequency (in seconds) of the reports Options are: 0 = Disable (default) 1-255 You can also use an AT Command to set this value. For more information, see *PPLATS on page 528. 				
	Note: If the Local Reporting Time Interval is set to 1 second, there may be some variation in the report interval, with the report interval sometimes being less than 1 second and sometimes more than 1 second. Other settings for this field are accurate.				
Location Reports Format	If Predefined is selected, you can select Report Type on page 302.	end using IP streaming. the reports contain TAIP and NMEA GPS strings. Local Report Type for IP streaming. See Local for disable GGA, RMC, VTG, GSA, and GSV			
	C3V	Could v			

Field	Description
Field Local Report Type	Description If the Location Reports Format is Predefined, sets one of the following Local Report types: RAP Location Data—RAP location report that contains only location data Location+Date—RAP location report that contains location data with the UTC time and date (default) Location+Date+RF—RAP location report that contains location data, the UTC time and date, and radio frequency information for the cellular connection Location+Date+RF+EIO—RAP location report that contains location data, the UTC time and date, radio frequency information for the cellular connection, and the current I/O state NMEA NMEA GGA+VTG—NMEA location report that contains fix information, vector track, and speed over ground NMEA GGA+VTG+RMC—NMEA location report that contains fix information, vector track, speed over ground, and recommended minimum location data NMEA GGA+VTG+RMC+GSA+GSV—NMEA location report that contains fix infor- mation, vector track, speed over ground, the recommended minimum location data, overall satellite data, and detailed satellite data TAIP TAIP data—TAIP location report that contains position and velocity Compact TAIP location report that contains a long navigation message TAIP TM report—TAIP location report that contains the time and date.
Starting Destination	Note: You can also use an AT Command to set this value. For more information, see *PPLATSR on page 529. Note: Local IP Report does not have an option for Xora reports. The primary port that reports are sent to
Port	The Local IP report source port is 17335. This is not configurable.
Number of Extra Destination Ports	You can send the report to up to 7 additional consecutive ports. For example, if the starting port is 12351 and you set this field to 5, reports are sent to ports 12351, 12352, 12353, 12354, 12355, and 12356. The default is 0, which means only the starting port is used. You can also use an AT Command to set this value. For more information, see *PPLATSEXTRA on page 529.

Table 10-4: Location: Local/Streaming—Local IP Report

Field	Description
Device ID in Local Reports	 Allows use of the IMEI/ESN or phone number in local IP RAP and NMEA reports to identify a device/vehicle. Options are: None (default) Phone Number ESN/IMEI
	Tip: Including the device ID is especially useful when your devices have dynamic IP addresses.
	Note: If you want the device ID included in all other RAP and NMEA location reports, see Use Device ID in Location Reports on page 283.
Local Report Destination Mode	 Configures the target IP address for the local reports. Options are: First Host (default)—Use the IP of the first host to connect to the device on any network interface
	 IP Passthrough—Use the radio IP. This should be used in conjunction with IP passthrough mode USBNET Ethernet
Local Report Destination Sub Mode	 When Local Report Destination Mode is set to USBNET or Ethernet, this setting configures the target IP address for the local reports. Options are: First Host (default)—First host to connect to the device on the interface specified in Local Report Destination Mode (USB or Ethernet) IP Address—Enter an IP address MAC Address—Enter a MAC address
Local Report Destination IP	This read-only field shows the IP address of the destination that Local IP reports are sent to. Through its use of DHCP, ALEOS detects if there is a connected device and designates that device's IP as the local IP destination. When no device is connected at startup, ALEOS uses the first IP address in the Ethernet DHCP pool as the destination. When using Public mode for an interface, that interface will be the local IP destination even if it's not the first device connected.
Report Odometer	 Enables odometer reporting. Options are: Disable (default) Enable Note: Only applies for RAP report types.
Report Digital Inputs	Enables digital input reporting. Options are: Disable (default) Enable
	Note: Only applies for RAP report types.

 Table 10-4:
 Location:
 Local/Streaming
 Local
 IP
 Report

>> 11: Events Reporting Configuration

Introduction

You can configure the AirLink RV55 to generate reports or initiate actions based on specified events. Events can either be generated internally, such as a change in location fix status or a signal quality indicator crossing a specified threshold, or by external devices attached to the analog or digital inputs.

Events that can trigger reports or actions include:

- A switch on connected equipment opens or closes (digital input)
- A pulse accumulation crosses a configured threshold
- An analog meter on connected equipment crosses a configured threshold (Analog input is reported in volts or transformed to meaningful units.)
- Changes to location information such as a location fix obtained or lost, changes in vehicle speed or heading, engine hours threshold crossed
- Changes to network status such as signal strength, network state, and network service
- The gateway's power supply (in volts) crosses a configured threshold
- The AirLink gateway board or radio temperature crosses a configured threshold
- A configured threshold for daily or monthly data usage is crossed

Depending on the type of report, reports can be sent to a local or remote report server, or an email address, or by SMS to a cell phone.

The occurrence of a configured event can also turn on or off a relay link.

Figure 11-1 summarizes how Event reporting works.




Figure 11-1: Events Reporting

Events/Actions are not one-shot activities. After an Action is performed, the Event is still active and will trigger an Action the next time the state change or threshold crossing occurs.

A single Event may activate one or more Actions. For example, if RSSI is below threshold, you can send an email (Action 1) and send an SMS message (Action 2).

A single Action may be activated by one or more Events. For example, if either the network state changes to Network Ready or the RSSI crosses a configured threshold, the same Action is performed.

Configuring Events Reporting

Before you begin

If you plan to use either of the following, configure that feature in ACEmanager before configuring Events Reporting:

- Email (Email (SMTP) on page 263)
- SNMP Trap (Management (SNMP) on page 265)

Configuring Events Reporting

When configuring Events Reporting, first configure the Action (that is, how you want to be notified when the Event occurs). Then configure the Event you want reported, and finally, link the Event to the Action.

Note: All Events Reporting configuration changes take effect after a short delay (about one minute). No reboot of the AirLink gateway is necessary.

Configuring the Action

Note: You can define a maximum of 5 Actions.

If an Action requires an IP connection, the following source ports are used. These are not configurable.

Actions (in the order configured)	Source port
Action 1	17348
Action 2	17349
Action 3	17351
Action 4	17352
Action 5	17353

Click the appropriate link for instructions on configuring the desired Action. Once the Action is configured, proceed to Event Types on page 319.

- Email
- SMS
- Relay Link
- SNMP TRAP
- Location Reports
 - Location RAP Report 13

- ∙ NMEA GGA+VTG
- · NMEA GGA+VTG+RMC
- NMEA GGA+VTG+RMC+GSA+GSV
- TAIP data
- Compact TAIP data
- TAIP LN report
- TAIP TM report
- XORA report
- Events Protocol Reports
 - · Type, Length, Value
 - Binary
 - · CSV- ASCII
 - · XML
- Turn Off Services

Email

Note: Sending an email report is limited to SMTP servers that are open and do not require a secure login.

To configure ALEOS to send an email report:

- 1. Ensure that email is configured on the Services > Email (SMTP) screen. (See *Email* (*SMTP*) on page 263.)
- 2. On the Events Reporting tab, select Actions from the menu on the left.
- 3. Enter the desired Action Name.
- 4. From the drop-down menu in the Action Type field, select Email.

1940 - 1940 - 1940 - 1940 - 1940 - 1940 - 1940 - 1940 - 1940 - 1940 - 1940 - 1940 - 1940 - 1940 - 1940 - 1940 -	61.11 <i>/%</i>				Same and Same	and a little	
tyents.							
1111	1 (Adres Datate						
Add lines	Action Name	Monthly Clata Urcag	Monthly Data Usage				
Contraction of the local division of the loc	Action Type			(Two +			
monthly franciscope	(Disa Minata						
Add Note:	Emailto			100000000000000000000000000000000000000			
	Enarthduart			myemak@ep.com Data Usage SM 1			
	Email Weissage			The data usage for	Sale 1		
	Built Tape			All the -			
	Sale report			Continuents			
	Constantine and Constantine an			and the second second			
	(1) Earls Group						
	Tata Group						
	Orgital and Analog 101	80.	Omica Info	Herwork Date	Dafia	Minutesteat	
	Orgital transf.1	Citatelle fo	Desix 0	Towner Sale	Distantion .	Permit	
	Ophilophit	Classes .	Porelation	Timbert Davier	Citates Tensore	Board Tyriget Share	
	Cityles Accumulator 1	Clargest	Desetate	C Hote	Frank Brites Save	Head Corner Bala	
		Dataite Doot	MAC ACTIVAT			Rado Tampentere	
				Radio Technology		0.1	
		unce speed	386.63	Network Device	P Faitek Sec	COMPARING VALUES	
		White Healths	-M9	Tophysik (P	. IP Factols Record	CENNECKE	
		Exposition	SPRS Cavestor	Daty Strage SHIP	Simil If Packets Sert	GINECH	
		Counter	Citre .	C Hothir Usage 2001	Internet Proceeds Nacasivest	Cettre	
		THE	A24 101	Others strange merc			
			Privac 100	Marthir Usuge SAL			
			Carendar III	Des Unage RDC + DH			
			Terrar IM	Differitive Ounge RDC 4584			
			SHOW 1				
			1001002				
			R20 y880				
	Chromophysel 1.						
	Transformed Assaing Input 1						

Figure 11-2: ACEmanager: Events Reporting > Actions > Action Type > Email

- 5. Complete the Email Information section with the recipient's email address, the subject line, and the desired message.
- **6.** In the Body Type field, select the desired format for the Data Group information included in the report.
- 7. In the Data Group section, select the data to be included in the email report. For more information on the options, see Report Data Group on page 316.
- 8. Click Apply.

The name you assigned to the Action appears under Actions. You can click on this any time to modify the settings.

9. Optional—If desired, after you have updated all the fields and clicked the Apply button, wait about 1 minute, and then click the Test report button to send a test email to verify that the destination and format are correct.

10. Click Events on the menu on the left and follow the instructions on Event Types on page 319 to configure the Event you want associated with this Action and to link the Action to the Event.

SMS

Note: You can only send SMS from your AirLink gateway if your cellular account allows SMS. You may need to have SMS added to the account. SMS from data accounts is blocked on some mobile networks. Outgoing SMS messages are limited to 140 characters. If the selected data exceeds 140 characters, the message is truncated.

To configure ALEOS to send an SMS message:

- 1. On the Events Reporting tab, select Actions from the menu on the left.
- 2. Enter the desired Action Name.
- 3. From the drop-down menu in the Action Type field, select SMS.

a annual free "10"102010 a 10 24 24				100-110-02011111111	and the second se	interested in succession
e waard to be a state of the st					2000 (100 (ALC)	County (con
uerts .						
Sec. 1	HARDON ELABORE					
Anthre	A REAL PROPERTY.			Workfrig Data Usag		
				tats	-	
and the second second	Contract of the local division of the local			100		
Barring lode Enge	11 OAD antornation					
Auto Diares	more termine			16045551234		
	DHD Ressage			Data over limit		
	Testinger.			Textester		
	() D.Mu. Group					
	Data Group					
		1	415252		6123	54.502.115.115
	Digital and Analog IO	JA:	Device Mile	Network Date	Taffe	Receipenn
	- Digital spin s	Todality Fo	Some D	Network Bulle	- Antes Dank	Print It
	Dune Output 1	Clather.	2 maps that the	Chathrolt Chainet	C Brites Received	Buent Terreparature
	Pulse Accumulation 1	Clarghost	Course tiste	Case	Circuit Breu See	Citied Centre State
		Balatte Court	MACAGENER	Ratio Technology	Chantibles Received	Hado Temperature
		Overage Speed	ZIMD	Chattaux Sanas	Officientied	COMPARE INVIOL
		Wennestang	-	These and P	P Parters Research	COMMENT
		Digestieurs	EPHI Overator	Della futurge 1989	Litted IF Factory Sect.	CON ILCIO
		CODIMNS.	Title	Monthly Longe 1997	Hut P Parent Received	Create
		0.144-10	CARADA	C Didy line pr 1982		
			Citerary SN	Wareho Usaga (MID		
			Cisconday (MI)	C.Duistinage Rid with		
			Tetter	Martin Lings RDC with		
			Contrast.	CONTRACTOR STATE		
			101013			
			322.404			
	in an an op in an all the					
	Transformed Assessment 4					

Figure 11-3: ACEmanager: Events Reporting > Actions > Action Type > SMS

- **4.** Complete the SMS Information section with the recipient's phone number and the desired message to be included with the information from the Data Groups. The combined message and Data Group information cannot exceed 140 characters.
- 5. In the Data Group section, select any data you would like to be included in the SMS. For more information on the options, see Report Data Group on page 316.
- 6. Click Apply.

The name you assigned to the Action appears under Actions. You can click on this any time to modify the settings.

7. Optional—If desired, after you have updated all the fields and clicked the Apply button, wait until the progress circle disappears (about 30 seconds), and then click the Test report button to send a test SMS.

1643 estumation	
hone Hutber	18945651234
ti Message	Airt sik has low signal
list report	Test report
list report	land report

8. Click Events on the menu on the left and follow the instructions on Event Types on page 319 to configure the Event you want associated with this Action and to link the Action to the Event.

Relay Link

When an event occurs, you can signal or control connected devices using the gateway's relay outputs. The power connector has one relay.

Note: The relays are capable of switching small loads. If you need to switch a larger load, such as to open a door lock, connect the AirLink gateway's relay to an externally powered switch.

To configure ALEOS to turn a relay link on or off:

- 1. On the Events Reporting tab, select Actions from the menu on the left.
- 2. Enter the desired Action Name.
- 3. From the drop-down menu in the Action Type field, select Relay Link.

lianan WWWCadadad Dear WLF1	12N VPN Security Services Location E	seem Reporting Tool Social Applications 101 Apple
ed address from the state of the state of the		Transfeld (Sales Apple Maked) Canad
Even	(Actus Datate	
aathee	Action Nares	Switch
Autom Source	Autom Type	Hatactan v
Addition	[]] Being Information	
AACHIVE	Helay Tupe	Refer 1

Figure 11-4: ACEmanager: Events Reporting > Actions > Action Type > Relay Link

- 4. In the Relay Type drop-down menu, select the desired Action:
 - · Relay 1—Open
 - Relay 1, Inverted—Close
- 5. Click Apply.

The name you assigned to the Action appears under Actions. You can click on this anytime to modify the settings.

6. Click Events on the menu on the left and follow the instructions on Event Types on page 319 to configure the Event you want associated with this Action and to link the Action to the Event.

SNMP TRAP

To configure ALEOS to send an SNMP TRAP notification:

- 1. Ensure that SNMP is configured on the Services > Management (SNMP) page. See Management (SNMP) on page 265.
- 2. On the Events Reporting tab, select Actions from the menu on the left.
- **3.** Enter the desired Action Name.
- 4. From the drop-down menu in the Action Type field, select SNMP TRAP.

Tratus WWWCellular Wi-	P) 1,441 9999	Security Se	enlare Location	Events Reporting	Seria)	Applicatione	10	Admin
and approximation of the state	20.7%			(There		1100 June	1.111	6) (Con
Evente	(1Actum Outwite							
Juli live	Acton Name			Monthly De	ita Usage			
Actions	Actor Type			INSP TRAP		•		
Meanbly State Unage								
Ault live								

Figure 11-5: ACEmanager: Event Reporting > Actions > Action Type > SNMP TRAP

5. Click Apply.

The name you assigned to the Action appears under Actions. You can click on this any time to modify the settings.

6. Click Events on the menu on the left and follow the instructions on Event Types on page 319 to configure the Event you want associated with this Action and to link the Action to the Event.

If you have more than one event or action configured, the trap indicates which Event triggered which Action.

Location Reports

Location reports can be sent using:

- Standard NMEA, TAIP, and XORA
- Sierra Wireless' Remote Application Protocol (RAP)
 RAP reports are very small and conserve over-the-air bandwidth. They can include vehicle odometer and digital input information.

To configure ALEOS to send a location report:

- 1. On the Events Reporting tab, select Actions from the menu on the left.
- 2. Enter the desired Action Name.
- **3.** From the drop-down menu in the Action Type field, select the desired type of location report.

Note: For more information on location report types, see Location Report Type on page 291.

an updated time (2006)2010 21	20102 PM	Egged N Dank App Druck Car
Eventa	[] Action Datase	
dald llow	Actor Name	Monthly Data Usage
Autors Monthly Tata Hage	Action Type	14P data •
under the second	114 Server information	
dated Henry	Report Server IP Address	
	Server Port	22330
	Minimum Report Time(securuls)	0
	1999" Kar Linvestaatsie Milodas	Daatie •
	(INF Reliable Wode	Disados Girostatos Model -
	Diff. Simple Reliable Maintury Reliable	10
	UNF Simple Reliable Backoft Time(seconds)	10

Figure 11-6: ACEmanager: Events Reporting > Actions > Action Type > TAIP data

4. Enter the server information and if desired, the store and forward SNF parameters.

Note: The Reliable, Simple Reliable, and UDP Sequence SNF modes apply only to RAP reports. For more information on SNF, see page 294.

- 5. Optional (location RAP Report 13 only)—Enable Report Odometer and/or Report Digital Inputs.
- 6. Click Apply.

The name you assigned to the Action appears under Actions. You can click on this at any time to modify the settings.

7. Click Events on the menu on the left and follow the instructions on Event Types on page 319 to configure the Event you want associated with this Action and to link the Action to the Event.

Events Protocol Reports

Sierra Wireless' Events Reporting protocol allows for messages to be sent to the report server in four formats:

- **1 Type, Length, Value** (TLV)—The TLV message consists of the MSCI ID as the type, the length of the data, and the actual data.
- 2 Binary—A binary condensed form of the TLV message
- 3 CSV-ASCII—An ASCII condensed and comma-delimited form of the TLV message
- 4 XML—An XML form of the data

Tip: Because of its flexibility and robustness, the TLV message type is recommended for most reports using the Events Protocol. The Binary and ASCII forms do not contain a "type field" which can result in misinterpretation of data. Since the TLV and XML forms always include the type as well as the data, an unintentional type can be identified much easier.

To configure an Events protocol report:

- 1. On the Events Reporting tab, select Actions from the menu on the left.
- 2. Enter the desired Action Name.
- **3.** From the drop-down menu in the Action Type field, select the desired Events protocol report format.

1 (d)					and the second se	Courses of Course		
					summer and the state	Chinese Street		
weeks .								
Add lines	Li Adren Dakata							
and less	Adlochame			Monthly Data Usage				
ALC: NOT A	AUROY 7(84			Type, Langth, Velice	-			
monthly fints (mage				1111111201100				
	11 Derver Information							
Add Term	Report Garrer IF Address			192 168 1 1				
	Server Part			22339				
	Murrury Report Tormissionals	1		0				
	THE for classicate time			Dame v				
	Staf Halanta Bock			Death (Scotland Nam)				
	BIE Schute Heispite Macham-	Faller		10				
	SHP Single Reliable Sociof To			10				
	. The second reaction and the			10				
	E Elada Gauca							
	10.000 M							
	Data Group							
	Digital and Analog VD	AR	Destine Indo	Hetwork Date	Delta	Mocateboost		
	OUNTINE!	Tabarra To.	- Dema C	Instances Table	Three Tard	Tuesda.		
	Orgital Output 1	Line	2 Phone Harmer	Inducer Dramal	Elline Received	Start femperature		
	Public Apparation 1	Lorpha	of Owner Spree		. Indiat Styles Source	Hist Coron Bale		
		Salatile Dount	MAC Address	Rade Technology	I mut bytes that aread	Radia Temperature		
		Conce Speed	2.000	Citomorebena	SP Partiels Derit	COMATTEL WANTER		
		Cance Heating	0.005	Contract P	TIP Partner Retained	COMARCHE		
			OTHE COMMON	Des Mage 1997	Creat P Particle Test	CONTON		
		199 Brown and			and the second s			
		Conver	line	14" Munitry Lorage SM1	Heat IF Packets Received	Cellinte		
		CINPID	Adve 188	Date Unage 1000				
			Press IN	Intertify Lings S42				
			Secondary SNI	Com Unage R2C 404				
			Terrian Stat					
			CIMING					
			COMPACT.					
			N2C +SH					
	Champtest 1							
	and the second sec							

Figure 11-7: ACEmanager: Events Reporting > Actions > Action Type > Type, Length, Value

- 4. Enter the server information and if desired, the store and forward parameters.
- 5. In the Data Group section, select any data you would like to be included in the report. For more information on the options, see Report Data Group on page 316.
- 6. Click Apply.

The name you assigned to the Action appears under Actions. You can click on this at any time to modify the settings.

7. Click Events on the menu on the left and follow the instructions on Event Types on page 319 to configure the Event you want associated with this Action and to link the Action to the Event.

Turn Off Services

This setting limits services and is primarily used in conjunction with monitoring data usage. For example, you could set the AirLink gateway to limit network service when data usage exceeds a configured threshold. For more information, see Data Usage on page 347.

Teter WHIChilde W	N-F1 LAW VPU Security Services Location Events Reporting Securit Application (6) A	dren
artigener/1416 (0212018-0	Taxet at Lane and	inere and
t swatte		
Additional	11 Admit Delate	
	Adout Name Monthly Data Usage	
ACTION 1	Adon Tex	
Brooks fait faith		
Anches		

Figure 11-8: ACEmanager: Events Reporting > Actions > Action Type > Turn Off Services

Turn Off Services does not turn off all network use. Reports are still sent and over-the-air access to the device is allowed. You can still access the AirLink gateway locally, but Ethernet, USBnet, and Wi-Fi host access to the mobile network is blocked.

After Turn Off Services is triggered, serial communication that originates from the gateway continues to be sent out over the WAN port. This includes PAD and MODBUS data.

Serial communication that originates from a dial-up networking host is blocked by Turn Off Services. This includes PPP and SLIP data.

Report Data Group

For email, SMS, and Events Protocol (TLV, Binary, CSV-ASCII, and XML) messages, you can select the data you want to be included in the report. Check the box corresponding to the data displayed. By default, all the boxes are clear.

Data Group					
Deptational Analog ICI	m	Device Into	Network Data	LaiRa	Macalanema
Digital input 1	Balalite Fix	Device ID	Network State	Bytes Sent	Powerin
Digital Output 1	Lattude	Phone Number	Network Channel	Bytes Received	Board Temperature
Pulse Accumulator 1	Longitude	Device Name	E R33	Host Bytes Sent	Hosi Comm State
	Batelite Count	NAC Address	E Radio Technology	Host Bytes Received	🗆 Radio Temperatur
	Vehicle Speed	Памір	Network Service	IP Packets Sent	CDNA PRL Version
	El Volicio Heading	INSI	Notwork IP	FIP Packets Received	CDNAEG/0
	El Engine Hours	CFRS Operator	Daily Usage SIV1	Host IP Packets Sent	CSM EC/ID
	El Odometer	Elfime	✓ Monthly Datage SIV1	El Host IP Packets Received	Cellinio
	Ebarrio	Adve SM	Daty Datage SIV2		
		Printing SIM	Monthly Datage SIV2		
		Secondary SIM	Daty Daage R2C eSM		
		Livebary SIM	Monthly Datage R2C eCIM		
		Estate state 1			
		E SIM SIM 2			
		□ reze verv			
Austog Input 1					
E Lonstormed Austra Input 1					

Figure 11-9: ACEmanager: Events Reporting > Actions > Data Group

The reports attributes are:

• Digital and Analog I/O

Options are to include:

- Digital Input 1—The status of the digital input
- Digital Output 1—The status of the digital output
- Pulse Accumulator 1—The pulse count for the digital input
- Analog Input 1—The status of the analog input (reported in volts)
- Transformed Analog Input 1—The status of the analog input (reported in units configured in ACEmanager I/O > Configuration—see Configuration on page 365)
- AVL

Options are to include:

- Satellite Fix—Whether or not there is a usable location satellite fix
- · Latitude—The latitude reported by the location fix
- · Longitude—The longitude reported by the location fix
- Satellite Count—The number of satellites the location technology is using to get a satellite fix
- · Vehicle Speed—The speed of the vehicle reported by the location fix
- · Vehicle Heading—The direction the vehicle is traveling reported by the location fix
- Engine Hours—The number of hours the engine has been on, based on either Power In or Ignition Sense
- · Odometer—The number of miles reported by the location fix
- · TAIP ID—The TAIP ID for the AirLink gateway

Device Info

Options are to include:

- Device ID—The device ID (serial number) for the AirLink gateway
- Phone Number—The phone number of the AirLink gateway
- Device Name—The name of the AirLink gateway
- MAC Address—The MAC Address of the Ethernet port of the AirLink gateway
- SIM ID—The SIM ID of the AirLink gateway
- IMSI—The IMSI of the SIM installed in the AirLink gateway
- GPRS Operator—The wireless Mobile Network Operator the SIM card is associated with
- · Time—The time the AirLink gateway is active
- Active SIM—The SIM card slot that contains the SIM card currently being used for the network connection
- Primary SIM—The SIM card slot that contains the Primary SIM card (the primary one is used for network connections if two SIM cards are installed)
- Secondary SIM—The SIM card slot that contains the Secondary SIM card (the Secondary one is used for network connections if two SIM cards are installed)
- Tertiary SIM—The SIM card slot that contains the Tertiary SIM card (the Tertiary one is used for network connections if two SIM cards and R2C eSIM are installed)
- SIM Slot 1—Whether or not a SIM card is present in SIM slot 1 (the upper SIM slot)
- · SIM Slot 2—Whether or not a SIM card is present in SIM slot 2 (the lower SIM slot)
- · R2C eSIM—Whether or not a Ready to Connect eSIM is present
- Network Data

Options are to include:

- Network State—The network state for the AirLink gateway
- · Network Channel—The network channel to which the AirLink gateway is connected
- RSSI—The signal strength for the AirLink gateway
- Radio Technology—Type of service being used by the device (e.g. HSPA, LTE)
- Network Service—The network service for the AirLink gateway
- Network IP—The IP address given by the mobile network
- Daily Usage SIM 1—The daily usage of the SIM card in slot 1 (Units as configured on the Applications > Data Usage screen)
- Daily Usage SIM 2—The daily usage of the SIM card in slot 2 (Units as configured on the Applications > Data Usage screen)
- Daily Usage R2C eSIM—The daily usage of the Ready to Connect eSIM, if available (Units as configured on the Applications > Data Usage screen)
- Monthly Usage SIM 1—The monthly usage of the SIM card in slot 1 (Units as configured on the Applications > Data Usage screen)
- Monthly Usage SIM 2—The monthly usage of the SIM card in slot 2 (Units as configured on the Applications > Data Usage screen)
- Monthly Usage R2C eSIM—The monthly usage of the R2C eSIM card, if available (Units as configured on the Applications > Data Usage screen)
- Tx/Rx

The Network Traffic in this group relates to the mobile network and the network between the AirLink gateway and any directly connected device(s). Options are to include:

- Bytes Sent—The number of bytes sent on the mobile network since last reset
- Bytes Received—The number of bytes received from the mobile network since last reset

- Host Bytes Sent—The number of bytes sent from the network between the AirLink gateway and the connected device(s) since last reset
- Host Bytes Received—The number of bytes received from the network between the AirLink gateway and the connected device(s) since last reset
- IP Packets Sent—The number of IP packets sent on the mobile network since last reset
- IP Packets Received—The number of IP packets received from the mobile network since last reset
- Host IP Packets Sent—The number of IP packets sent from the network between
 the AirLink gateway and the connected device(s) since last reset
- Host IP Packets Received—The number of IP packets received from the network
 between the AirLink gateway and the connected device(s) since last reset
- Misc Data

Options are to include:

- Power In—The voltage level of the power coming in to the AirLink gateway at the time of the report
- Board Temperature—The temperature of the internal hardware of the AirLink gateway at the time of the report
- Host Comm State—The signal level between the AirLink gateway and the connected device(s)
- · Radio Temperature—The temperature of the internal radio module
- · CDMA PRL Version—PRL version used by the AirLink gateway
- $\cdot\,$ CDMA EC/IO—The quality of the signal from the cellular CDMA network
- GSM EC/IO—The quality of the signal from the cellular GSM network
- · Cell Info-The mobile network cell information for the AirLink gateway

Event Types

Note: You can define a maximum of 5 Events.

To define an Event:

1. On the Event Reporting tab, select Events > Add New from the menu on the left.

an anime the 229/2011 1	1.10.090	Tunchi Dem App Artes Co
Evente.		
Bigh the later	[] Ewort Dailans	
Birthly Sinta (funger	Event mane	
Aski blow	Event Type	Digital liquid 1 .
Actions	Event Operator	Douine +
Monthly Date Usage	(Action Description	
Achd Meen	Action Description	
	Ác	ction Name
	C Monthly Cata Gauge	

Figure 11-10: ACEmanager: Events Reporting > Events > Add New

- 2. Enter the desired name for the Event.
- 3. Select the Event type from the drop-down menu.
- 4. Select the Event Operator and the Value to Compare. The options available depend on the Event type you choose. See Table 11-1 on page 320 for a list of options for each Event type.
- **5.** All the configured Actions appear at the bottom of the screen. Select the check box beside the Action you want to associate this Event with.
- 6. Click Apply.

Itatus	WHITCellular	201-0-1	LAR	0.640	Decirrity	Services	Turagrau	Events Reporting	Sensi	Applications	50	Addess
id speci	atow 205079	12 12 24	rha .					Farm	(7) E	ALL 1		21 E.C.
Events												
			- Hitsen	t Details								
Marry	Heen Divegor		Eveni					Mothly De	a l'hearte			
Aren	-											
			Event	200				Monthly Data	Usage	•		
Actions			Event	SIM				Stat t .				
			Event	Operator				Cityethe		•		
Month	te Data Usage		Value	To Corgany	(% of Lmit)			62% +				
AUN			Pettill									
			HAR	e Descriptio	ł							
			Action	Descriptio	a -							
			8					Action Name				
			1994	offy Data U	anie -							

Figure 11-11: ACEmanager: Events Reporting > Events

Table 11-1: Event Types

Event Name	Event Type	Event Operator Options	Values to Compare
Digital Inputs			
Digital Input See Figure 11-12 for switch configuration	State Change	 Disable When Switch Closed (I/O high-to-low falling edge) When Switch Opened (I/O low-to-high rising edge) On any change 	N/A
		Pin 4 (power connector) Protection Circuitry Figure 11-12: Digital input switch configuration	Vin Internal pull-up resistor (10K)
Pulse Accumulator	Threshold Crossing	DisableWhen Changed By	Pulse Accumulator DeltaStarting Trigger Value
Analog Input (volts)	Threshold Crossing	 Disable When Above Threshold When Below Threshold When Cross Threshold 	Value To Compare (Threshold (volts))

Transformed Analog	Threshold Crossing	 Disable When Above Threshold When Below Threshold When Cross Threshold 	Value To Compare (Units configured on the I/O screen) See Transformed Analog on page 367.
AVL			
Location Fix	State Change	 Disable Fix Lost Fix Obtained On any change 	N/A
Vehicle Speed	Threshold Crossing	 Disable When Above Threshold When Below Threshold When Cross Threshold 	Value To Compare (Vehicle Speed (KM/h))
Heading Change	Threshold Crossing	DisableChange in Direction	Value To Compare (Heading Change (degrees))
Engine Hours	Threshold Crossing	DisableWhen Changed By	Value To Compare (Engine Hours)
Network			
RSSI	Threshold Crossing	 Disable When Above Threshold When Below Threshold When Cross Threshold 	Value To Compare (Signal Power (-dBm))
Network State	State Change	 Disable When Cellular is Ready (Triggered when a cellular connection is established) When Wi-Fi is Ready (Triggered when a Wi-Fi connection is established) When either is Ready (Triggered when the gateway establishes either a cellular or Wi-Fi connection or when it switches between a cellular or Wi-Fi connection) Note: the last two options require a RV55 that supports Wi-Fi. 	N/A
Network Service	State Change	 Disable On Service On No Service On Change 	Value To Compare (Network Service): • Roaming • 2G Service • Rev A or HSUPA • Any Data Service

Table 11-1: Event Types

Other Report Types	Γ	Γ	
Periodic Reports	Threshold Crossing (Time)	DisablePeriodically	Value To Compare: Report Period (secs)
			Note: The minimum interval between periodic reports is 3 seconds. Setting an interva less than 3 seconds results in only one report being sent.
Power In	Threshold Crossing	 Disable When Above Threshold When Below Threshold When Cross Threshold 	Value To Compare (Power In Threshold (volts))
Board Temperature	Threshold Crossing	 Disable When Above Threshold When Below Threshold When Cross Threshold 	Value To Compare (Temperature Threshold (°C)
Radio Temperature	Threshold Crossing	 Disable When Above Threshold When Below Threshold When Cross Threshold 	Value To Compare (Temperature Threshold (°C)
Data Usage Note: Depending on your slot 1, slot 2 or Ready to C		iter model, you can choose whether	r the Event is for the SIM card in
Daily Data Usage	Threshold Crossing	DisableWhen Above Threshold	Value To Compare (% of Limit)
Monthly Data Usage	Threshold Crossing	DisableWhen Above Threshold	Value To Compare (% of Limit)
more than one, for examp	le, a trigger when the L hes a certain percentag	Daily Data Usage reaches a certain ge, only the last threshold configure	d is used.

Table 11-1: Event Types

Operator. SIERRA WIRELESS IS NOT RESPONSIBLE FOR DATA OVERAGES.

>> 12: Serial Configuration

Use the serial port to connect devices or computers using a DB9/RS232 connection. RS232 connections can be configured on the Serial tab.

Note: These commands are specific to the RS232 port and generally do not apply to USB/serial.

RS232 Configuration

RS232 Configuration consists of the following categories of configurable parameters:

- General configuration, including Startup Mode and RS232 Port Configuration
- PAD settings, including TCP on page 329 and UDP on page 331
- Reverse Telnet/SSH
- PPP
- SLIP
- MODBUS

General

Ad (2001010) - 101010 10101	I AND	Santal Lago Salar Con					
Base 19222 Configuration	(1) HERE						
lateral lateral	111						
	10.5252 Pwt	Endow V					
same -	R5235 Deal Flat Made	(Deater +					
Streeting Spinst	47 Tracture Music Default	fairing of unintent -					
-	1140202.Poil Cedigration						
2.0	AT Configure REDIT Post	115250.6941					
ARABIT &	AF Place Central	1000 -					
LED belicate	AT DEB Danie Echs	(Dalls -					
	11 Advanced						
	All Accest STSM	(Awaya v)					
	AF Asset DCD	te Data Moto +					
	AT LITH Mark	(generation -					
	All Qual Mole	Zalata -					
	Enable Stantial OK-response	(Enable,					
	All All Verlage Marie	(metana)					
	AF Call Property Result Made	Enister +					
	Connett 12 digit Nurrisol to IP Address	Usa az füzhe 🖛					
	AT Dualde ATZ Renet	(a •					
	Send Weining	Charle -					
	Itenal Watching Delay (minutes)	10					

Figure 12-1: ACEmanager: Serial > RS232 Configuration > General

Table 12-1: R	S232 Configuration	ı > General
---------------	--------------------	-------------

Field	Description	
RS232		
RS232 Port	Enable or disable the RS232 port. Default is Enable.	
RS232 Dual Port Mode	Enable or disable RS232 dual port mode. Default is Disable. When dual port mode is enabled, you can configure the general and PAD settings for each port separately. See Configure RS232 Port on page 326, Advanced on page 326 and PAD settings, including TCP on page 329 and UDP on page 331.	
	Match Statistical Data (Section 1) Lat. UNIX Matchine Description 10 Matchine Matchine	
Startup Mode Default	 Default power-up mode for the RS232 port. When the AirLink RV55 is power-cycled, the RS232 port enters the communication mode specified. Note: It can take up to 5 minutes to establish a connection. Normal (AT command) (default) SLIP PPP UDP TCP Reverse Telnet/SSH—Allows you to telnet or SSH into a router or other device connected to the AirLink gateway via RS232. For information on configuring reverse telnet, see Reverse Telnet/SSH on page 333. Modbus ASCII Modbus RTU (Binary) BSAP—Bristol Standard Asynchronous Protocol Variable Modbus UDP Multiple Unicast—Data from the RS232 port is packed into UDP packets and sent to multiple IP addresses (for example, multiple AirLink gateways). For more information, see UDP Multiple Unicast for RS232 on page 333. Note: In dual port mode, the Startup Mode Default settings are under RS232 Port 1 Configuration > General and RS232 Port 2 Configuration > General. Only Normal (AT command), UDP, and TCP are available. 	
	You can also use an AT command to configure this field. See MD on page 534.	

Field	Description
RS232 Port Configurati	on
Configure RS232 Port	Format: [speed][data bits][parity][stop bits] Valid speeds are 300–115200, data bits: 7 or 8, parity: O,E,N,M, stop bits: 1,1.5. Default is 115200,8N1. You can also use an AT command to configure this field. See S23 on page 545.
Flow Control	 RS232 port flow control setting None—No flow control is being used (default) Hardware—RTS/CTS hardware flow control is being used Transparent SW—Transparent software flow control. Uses escaped XON and XOFF for flow control. XON and XOFF characters in data stream are escaped with the @ character (0x40). @ in data is sent as @@. You can also use an AT command to configure this field. See \Q on page 543.
DB9 Serial Echo	 AT command echo mode Enable—Text is visible as you type (default) Disable—Text you type is not visible You can also use an AT command to configure this field. See E on page 542.
Advanced	
Assert DSR	 Assert DSR always when the device is in a data mode (UDP, TCP, etc.), or when the device is in network coverage. Options are: Always (default) In Data Mode In Coverage
	Note: This setting is not available in dual port mode.
	You can also use an AT command to configure this field. See &S on page 543.
Assert DCD	 Assert DCD always, or when the device is in a data mode (UDP, TCP, etc.) or when the device is in network coverage. Options are: Always In Data Mode (default) In Coverage
	Note: This setting is not available in dual port mode.
	You can also use an AT command to configure this field. See &C on page 540.
DTR Mode	 Use DTR from the serial device, or ignore DTR (same as S211 on page 546). Options are: Use DTR Ignore DTR (default)
	Note: This setting is not available in dual port mode.

 Table 12-1:
 RS232 Configuration > General

Field	Description	
Quiet Mode	 Disable or enable display of device responses. Options are: Disable (default) Enable You can also use an AT command to configure this field. See Q on page 543. 	
Enable Startup OK response	 Disable or enable sending an "OK" message from the serial port after the gateway boots. Options are: Disable—Suppresses the startup "OK" message Enable (default) 	
AT Verbose Mode Call Progress Result Mode	Sets the level of information returned for AT commands Options are: • Verbose (default) • Numeric You can also use an AT command to configure this field. See V on page 546. When enabled adds 19200 to CONNECT messages Options are: • Disable (default) • Enable You can also use an AT command to configure this field. See X on page 547.	
Convert 12 digit Number to IP Address	 Choose whether a 12-digit number is converted to an IP address (eg. 111222333444 to 111.222.333.444). Options are: Use as Name (default) Use as IP You can also use an AT command to configure this field. See *NUMTOIP on page 536 	
Disable ATZ Reset	 The value set in this field determines whether or not issuing an ATZ Command resets the RV55. Options are: On: Block is enabled—ATZ does not reset the device. Off: Block is disabled—ATZ resets the device. (default) You can also use an AT command to configure this field. See *DATZ on page 542. 	
Serial Watchdog	 When this feature is enabled, the AirLink RV55 reboots if there is no traffic for longer than the period configured in the Serial Watchdog Delay field. <i>Note: This setting is not available in dual port mode.</i> Options are: Disable (default) Enable 	
Serial Watchdog Delay (minutes)	When Serial Watchdog is enabled, use this field to set the delay (in minutes) before the AirLink RV55 reboots if there is no traffic on the RS232 port. Note: This setting is not available in dual port mode. Accepted values: • 10-65535 (default is 10)	

Table 12-1: RS232 Configuration > General

AN ADDRESS . 1992209 111	int alls AM	Converse Street, Street,
		Including Quarter Included
Past R5212 Configuration	110mm#	
(internet)		
16.0	AT Dames Put	12345
the second s	Af Senar MIS	1304
National States	41 Destantion Plat	0
200	AP Destruitor Adhese	0000
ALIP	All Default Dial Made	149 ×
	M Data Perivarding Tennand (, 1 ancost)	(4)
MINNER	-67 Data Preventing Character	0
12D Indicated	11109	
	AT TOP Anto Avanam	These -
	TEP Percelant Connection	(black +
	AT 32P Canimit Termsel (second)	30
	47 TEP dis Termini	5
	AT TOP alle Torrenad Unit	Andre v
	MTTOP Careerst Response Delay (seconds)	0
	Include Design ID on 10P General	Duare +
	(11+00-	
	M USP Ago Anner	Dates -
	40 LIOP Centreck Last	(Denst mage 195 -
	All Allow key technolog #1	(Addison (and a 1815) (2)
	AF Alias Al UDP	Provident -
	AF 120P Auto Annane Response	In Response -

0

0000

PAD

Figure 12-2: ACEmanager: Serial > RS232 Configuration > PAD

10P Raspyline (seconds)

100P Recently Prog.

Table 12-2: RS232 Configuration > PAD

Field	Description
General	
Device Port	The port on the AirLink gateway used for incoming TCP/UDP communication (Default is 12345)
	If either, or both, of the UDP Answer or TCP Answer parameters are enabled, when the AirLink gateway receives incoming TCP or UDP packets that are destined for this port, it strips off the IP header and send the packet payload out its serial port.
	You can also use an AT command to configure this field. See *DPORT on page 532.

Field	Description
Serial MTU	 The serial maximum transmit unit (PAD payload) Valid range: 256–4096 bytes (Default is 1304) Recommended settings if you want to prevent packet fragmentation: UDP PAD—less than 1472 bytes TCP PAD—less than 1460 bytes You can also use an AT command to configure this field. See *UDPPADMTU on page 539.
Destination Port	The destination port that TCP/UDP communication is sent to You can also use an AT command to configure this field. See S53 on page 537.
Destination Address	IP address TCP/UDP communication is sent to You can also use an AT command to configure this field. See S53 on page 537.
Default Dial Mode	 Protocol used to send messages Options are: TCP UDP (default) You can also use an AT command to configure this field. See S53 on page 537.
Data Forwarding Timeout (.1 second)	The Data Forwarding Timeout feature causes ALEOS to wait until no data has been received on the serial port for the specified period of time beyond the built-in delay of 100 ms before sending a new PAD packet.
	Acceptable values are: 0-255. (Unit is 0.1 second; default is 1.)
	If the field is set to 0 or 1, the feature is disabled. ALEOS sends the new PAD packet after the built-in 100 ms delay.
	Data Forwarding Timeout is not applicable to AT and PPP modes.
Data Forwarding Character	PAD data forwarding character. ASCII code of character that causes data to be forwarded. Used in UDP or TCP PAD mode
	Default is 0 (No forwarding character).
	You can also use an AT command to configure this field. See S51 on page 536.
ТСР	
TCP Auto Answer	This determines how the AirLink gateway responds to an incoming TCP connection request. The AirLink gateway remains in AT Command mode until a connection request is received. The AirLink gateway sends a "RING" string to the host. A "CONNECT" sent to the host indicates acknowledgment of the connection request and the TCP session is established.
	Disable (default)
	• Enable
	You can also use an AT command to configure this field. See S0 on page 544.

 Table 12-2:
 RS232 Configuration > PAD

Field	Description	
TCP Persistent Connection	 This feature assists the RV55 to maintain a TCP connection to the remote server. Options are: Disable (default) Enable—TCP Persistent Connection attempts to maintain the TCP connection by: Automatically reconnecting after the connection to the server is closed for any reason. A back-off mechanism will try to reconnect with an increased waiting period between each retry (maximum wait time is 30 minutes). Using TCP keepalive probe packets, which the device sends when the connection is idle (no traffic). You can configure a Keepalive Time, Keepalive Interval and the number of Keepalive Probes. 	
Keepalive Time (seconds)	 Sets the interval between the last data packet sent and the first keepalive probe. Appears when TCP Persistent Connection is enabled. Options are: 0-65535 (Default is 30) 	
Keepalive Interval (seconds)	Sets the interval between keepalive probes. Appears when TCP Persistent Connection is enabled. Options are: • 0-65535 (Default is 10)	
Keepalive Probes (seconds)	Sets the number of unacknowledged probes to send before considering the TCP connection dead. Appears when TCP Persistent Connection is enabled. Options are: • 0-65535 (Default is 3)	
TCP Connect Timeout (seconds)	Specifies the number of seconds to wait for a TCP connection to be established when dialing out (default is 30). You can also use an AT command to configure this field. See S7 on page 544.	
TCP Idle Timeout	TCP idle time-out in the configured units (See TCP Idle Timeout Unit on page 330). Specifies a time interval upon which if there is no in or outbound traffic through a TCP connection, the connection is terminated. Default is 5. You can also use an AT command to configure this field. See TCPT on page 538.	
TCP Idle Timeout Unit	 Units used for the TCP Idle Timeout Interval. Options are: Minutes (default) Seconds You can also use an AT command to configure this field. See TCPS on page 538. 	
TCP Connect Response Delay (seconds)	 The number of seconds to delay the "CONNECT' response upon establishing a TCP connection, or the number of tenths of seconds to delay before outputting ENQ on the serial port after the CONNECT when the ENQ feature is enabled. 0-255 (Default is 0.) You can also use an AT command to configure this field. See S221 on page 546. 	

 Table 12-2:
 RS232 Configuration > PAD

Field	Description	
Include Device ID on TCP Connect	If this option is enabled, after a TCP connection is established, ALEOS sends a packet that contains the device ID (and optionally a prefix, suffix, and CRLF). Options are: Disable (default) Enable	
	Note: To use this feature, ensure that the Device ID is configured in the Use Device ID in Location Reports field on the Location screen (Location > Global Settings > General). See Global Settings on page 281.	
Device ID Prefix	If Include Device ID on TCP Connect is enabled, sets the Prefix DID in the device identification packet upon TCP connection. Maximum length of the prefix is 80 characters.	
Device ID Suffix	If Include Device ID on TCP Connect is enabled, sets the Suffix DID in the device identification packet upon TCP connection. Maximum length of the suffix is 80 characters.	
Send CR LF after Device ID	 If Include Device ID on TCP Connect is enabled, enables a carriage return to be inserted in the device identification packet after the Suffix DID. Options are: no CR LF send CR send CR LF (carriage return, line feed) Default 	
UDP		
UDP Auto Answer	 Whether the AirLink gateway answers and incoming UDP connection request Options are: Disable (default) Enable You can also use an AT command to configure this field. See S82 on page 537. 	
UDP Idle Timeout (seconds)	 UDP Idle Timeout in seconds Specifies a time interval upon which if there is no in or outbound traffic through a UDP connection, the connection is terminated. 0—No idle time-out 1–255 Timeout in seconds (Default is 50.) You can also use an AT command to configure this field. See S83 on page 538. 	
	Note: UDP Idle Timeout only takes effect if the UDP Auto Answer is set to Enable.	
UDP Connect Last	 Allows you to choose to use the last accepted IP address and port number as the default settings, instead of using S53 (destination address) Options are: Do not change S53 (default) Set S53 to last IP 	
	Note: Resetting the device restores the configured S53 (destination address).	
	You can also use an AT command to configure this field. See *UDPLAST on page 539.	

 Table 12-2:
 RS232 Configuration > PAD

Field	Description
Allow Any Incoming IP	 When UDP answer is enabled, use this field to select whether to allow any incoming IP address to connect or to only allow the configured destination IP address to connect. Options are: Allow only S53 (default) Allow any IP address If you select Allow only S53, the Destination Port and Destination Address fields under RS232 Configuration > PAD > General must be configured. (See Table 12-2 on page 328.) You can also use an AT command to configure this field. See AIP on page 532.
Allow All UDP	 Accepts UDP packets from all IP addresses when a UDP session is active. If there is no UDP session active, an incoming UDP packet is treated according to the UDP answer and AIP settings. Options are: No effect (default) Allow all—The AirLink gateway accepts all UDP traffic from any IP address during a UDP session. You can also use an AT command to configure this field. See *UALL on page 539.
UDP Auto Answer Response	 Half-Open Response—In UDP answer (half-open) mode. Options are: No Response—No Response codes when UDP session is initiated (default) RING CONNECT—RING CONNECT response codes sent out serial link before the data from the first UDP packet Note: Quiet Mode must be Off.
Dial UDP Always	You can also use an AT command to configure this field. See HOR on page 542. The dial command always uses UDP, even when using ATDT. Options are: Disable—Dial using the means specified (default) Enable—Dial UDP always, even when using ATDT
	Note: When this parameter is set you cannot establish a TCP PAD connection. You can also use an AT command to configure this field. See *DU on page 533.
UDP Serial Delay (.1 second)	 Waits the specified delay before sending the first received UDP packet and the subsequent UDP packets out to the serial port (in 100 ms units). No UDP packet delay (default) 1-255—Delay in 100 ms units, from 100 ms to 25.5 sec. You can also use an AT command to configure this field. See *USD on page 539.

 Table 12-2:
 RS232 Configuration > PAD

 Table 12-2:
 RS232 Configuration > PAD

Field	Description
UDP Keepalive (seconds)	Use this field to configure the time interval (in seconds) for sending UDP keepalive packets. Options are:
	 1-65535—ALEOS sends a UDP packet, containing the AirLink gateway's IMEI (in little endian) to the configured Destination IP Address:Destination Port when the UDP connection is first established and then at the configured interval.
	If the AirLink gateways WAN IP address changes, a UDP packet is sent and the timer is reset.
	O—UDP Keepalive is disabled. (default)
UDP Recovery Ping	If an IP is provided in this field and no UDP packets are received from the server for the UDP Idle Timeout period, the gateway sends a single ping to this IP.
	This functionality is designed to resolve a known issue where a Verizon Wireless GX440 becomes temporarily unreachable from the mobile network after a period of time in which no data is sent or received.

UDP Multiple Unicast for RS232

With UDP Multiple Unicast, data from the serial port is packed into UDP packets and sent to multiple IP addresses. To configure UDP Multiple Unicast:

- 1. Go to Serial > RS232 Configuration > General.
- 2. In the Startup Mode Default field, select UDP Multiple Unicast.
- 3. Click Apply.
- 4. Under RS232 Configuration > PAD > General, in the Destination Port field, enter the remote port to be used.
- 5. Click Apply.
- Go to RS232 Configuration > MODBUS > General > Address List and enter the index numbers and IP addresses of the devices you want the data sent to. (See MODBUS Address List on page 341.)
- 7. Click Apply.
- 8. Reboot the device.

Note: To avoid flooding the network, there is a 20 millisecond pause between sending the UDP packet to each destination.

Reverse Telnet/SSH

The Reverse Telnet/SSH feature allows you to connect to and configure a router or other device that has a serial connection to your AirLink gateway.

You can have only one Reverse Telnet session open at a time. If a new Reverse Telnet session is started, any existing Reverse Telnet connection will be closed.

However, you can simultaneously have:

 One Telnet session for Reverse Telnet (using the port configured in the Device Port field on the RS232 Configuration > Reverse Telnet page) • One Telnet session for AT Commands (using the port configured in the Remote Login Server Telnet/SSH Port field on the Services > AT (Telnet/SSH) page)

Note: If you are using Reverse Telnet and you have VPNs, the more VPN tunnels in use, the greater the CPU load. This may result in lower throughput or greater delays.

To configure Reverse Telnet/SSH:

- 1. Log into ACEmanager and go to Serial > RS232 Configuration > General.
- 2. In the Startup Mode Default field, select Reverse Telnet/SSH.
- **3.** In the Configure Serial Port field, set the speed, data bits, parity, and stop bits. (The serial port configuration depends on the router you want to connect to. For example, to connect to a Cisco router that has a default baud rate of 9600, enter 9600,8N1 in the Configure Serial Port field.)

al added from 1002211 101211	ALC .	Conversion (Append (Statistic)) (Con
Book H1222 Configuration /	[114050]	
140	REZIE Post REZIE Post Made	Inste + Inste +
Receive National	43 Storage Mindes Tarlautt	Reverse Tetrattititi e
	11PS212 Per Certipation	
ancourd 27%	41 Cooligans REELE Part	115200.001
(20 lastle prov	41 000 Senal Cutu	Enns -
	34 Advanced	

- 4. Optional—If you are planning to use telnet (rather than SSH), you can be automatically logged in when you telnet to the AirLink gateway without having to enter a user name and password. Log in is not supported with SSH. To set up automatic login:
 - a. Go to RS232 Configuration > Reverse Telnet.
 - **b.** In the Autologin Reverse Telnet field, select Enable.
 - c. Click Apply.

Allarministen 12222018-4	4157.00		MIN RATAL
REED Configuration	AT Device Purt	12345	
Genne	Autotogin Reverse Tetset	frame -	
FAE			
Hereise Tower			
11.00			
No. of Concession, Name			
10 ballcalar			

- **5.** Go to Services > AT (Telnet/SSH).
- 6. In the Remote Login Server Mode field, select:
 - · Telnet—if you want to Telnet into the connected device
 - · SSH—if you want to SSH into the connected device

Note: If you enabled login, select Telnet.

allippendare patients a				
to desire and a second a s	12/18		(Control of the second s	Tables Care
ALXEL	All Riemande Logen Server Mipde.	Ternet: v		
ACExemager	AF Default Televillator	fare v		
Power Management	47 Wernste Login Server Tetrat/SISH Part	2332		
	Tetret00H Access Patay	LAN		
Dyvenic Dirb	41 Remote Login Server Teinet/SSR Port Teneout (menutes)	2		
4144	AT Taksattilib Kutu	Dute +		
585	Mate 35H Keyn	Make Littleys.		
AT (Terrett 5321)	30H Bares			
Firmail (588779)				
Makeperioni (SMMP)				
Time (SHTP)				
Adhenication				
Device Status Screen				

- 7. Click Apply.
- **8.** Reboot the AirLink gateway.
- **9.** Use a Telnet or SSH terminal client such as Putty or Teraterm to connect to the appropriate port:
 - If you are using login, Telnet to the port specified in the Device Port field (default is 12345). SSH is not available with login.
 - If you are not using login, you can Telnet or SSH into the port specified in the Remote Login Server Telnet/SSH Port field (default is 2332).

- **10.** If prompted, log in with the following credentials:
 - User name: sconsole
 - Password: 12345 (default)

No. of Concession, Name of Street, or other	Putte	he in the set
login art ecos	iole .	
addmatole0144.1	40.2DY.42*# passworth	
picolom. #1.8		
port is	: /#ev/111950:	
flowcont.nil.	1-11110	
beadrane 1s	1.9600	
partty is	1 0.110 00	
databits are		
escape 18	r. C-s	
local acts in	t ná	
poinit is	E VHR	
DECEMPT 18	F (50)	
molock is	: 10	
ei hen bese	1 22	
receive and is	1 22 -07	
imap is		
Omme: 1.H		
emap: in	r crarlf, delbs,	

For information on changing the default reverse telnet password, see Change Password on page 369.

ALEOS redirects you to the router or other device connected to the AirLink gateway serial port. You can use this connection to configure connected device.

Note: You may be required to enter a user name and password to access the router or other device.

PPP

Use Point-to-Point Protocol (PPP) to establish a connection between a host PC serial port and the AirLink gateway, as shown in Figure 12-3.




Figure 12-3: PPP connection

and agreement were well to the state	a.50.7%		Total Colores (Colores
ILLING Contegeration	Dence PPP #	192 168 15.31	
there al	matere p	192 168 15 100	
	Heat Authentication Mode	INP and OKAP +	
Will PPP Liber ID			
Records Tained	PPP Passwet		
100			
AL# .			
MORELE			
LED Automatic			


Figure 12-4: ACEmanager: Serial > RS232 Configuration > PPP

Table 12-3: RS232 Configuration > PPP

Field	Description	
Device PPP IP	Sets the device IP address (in private mode) Default is 192.168.15.31	
Host PPP IP	Sets the host IP address (in private mode) Default is 192.168.15.100	
Host Authentication Mode	 Sets the authentication method the host uses for PPP. Options are: None (default) CHAP—The stronger of the two protocols. Recommended, provided it is supported by all the client devices PAP and CHAP—If CHAP is not supported by the client, the host reverts to PAP. 	
PPP User ID	Sets the User ID for authentication	
PPP Password	Sets the User Password for authentication	

SLIP

Use Serial Line Internet Protocol (SLIP) to establish a connection between a host PC serial port and the AirLink gateway, as shown in Figure 12-5.



diameters, internet of	in a d fine		one property property
		15	all Louised Vestal
TS20 Configuration	SUP Protocol	Adapter SLP	
(Incomental)	SLP Flow Control	Dastin -	
	Deets PPP P	192.168.15.31	
PAUL	Head PVP IF	192 168 15 100	
Secure land			
10.00			
automa .			
LTD Indiator			

Figure 12-6: ACEmanager: Serial > RS232 Configuration > SLIP

Table 12-4: Serial Port Configuration > SLIP

Field	Description
SLIP Protocol	 Select the type of Serial Line Internet Protocol (SLIP) to use Options are: Adaptive SLIP—Allows the gateway to determine the SLIP implementation (default) SLIP—Traditional SLIP encapsulation CSLIP—SLIP encapsulation with Van Jacobsen header compression SLIP6—SLIP encapsulation with six-bit encoding CSLIP6—SLIP encapsulation with Van Jacobsen header compression and 6-bit encoding
SLIP Flow Control	 Choose the SLIP data flow control setting. Options are: Disable (default) Enable Flow control enables the receiving device to control the data flow. This is useful if the receiving device has a heaver traffic load or less processing power than the sending computer.

Field	Description	
Device PPP IP	Sets the device IP address (in private mode) Default is 192.168.15.31	
Host PPP IP	Sets the host IP address (in private mode) Default is 192.168.15.100	

Table 12-4: Serial Port Configuration > SLIP

MODBUS

Alambaken, tipppus ks	6.57.946		Treasure Network Course
HEED Configuration	[]EGeneral		
German	ef in ListDaa	Date: -	
	Andrees List		
Revenue Towert	Address Line		
	Address Detty		
11.00	Add Hitty		
NUMBER .	() - Sprouve McCBICK		
10 million	AT Vatable Time	Printy	
CO BERGARD	MT MODBUE ID Official	0	
	AT Vanazie Length	(1.2)	
	#7 Vanuthe Mash (Nex)	0	
	AT Radio Keynig Enabled	Deakie +	

Figure 12-7: ACEmanager: Serial > RS232 Configuration > MODBUS

Table 12-5: RS232 Configuration > MODBUS

Field	Description	
General		
IP List Dial	 This allows access to the Modbus IP Address using the first two digits of the dial string. For example, ATDT1234567 would imply ID index 12 on the Modbus Address list and use the associated IP Address as the destination. Options are: Disable (default) Enable You can also use an AT command to configure this field. See IPL on page 536. 	
Address List	Add Modbus IP addresses. See MODBUS Address List on page 341.	
Variable MODBUS		
Variable Type	Sets the Modbus Variant type (RTU ID data-type in a modbus-variant protocol). This parameter is used when the Mode Default (see MD on page 534) is set to 63. It defines the data-type of the RTU ID in Modbus-like protocol data packets.	

Field	Description
MODBUS ID Offset	Sets the Modbus (Variable mode) offset in the data of where the Modbus ID starts. Options are 0 (default)–255
Variable Length	Sets the length (in bytes) of the RTU ID in a Modbus Variant protocol. Options are 1 (default)–5
Variable Mask (hex)	Sets the Modbus Variant ID Mask. This is the 16-bit hex mask to use when extracting the ID. This parameter is used when the Mode Default (see MD on page 534) is set to hex 63.
Radio Keying Enabled	 Enable MDS Radio transceiver keying. Radio keying is designed to assert CTS when a packet is received, delay the time as specified, send the data out of the serial port, wait the same amount of time, drop CTS. This way the CTS signal can be used to key a transmitter on and give it time to reach its power level before data is sent to it. Delay interval is specified in S221. Options are: Enable Disable (default)

Table 12-5: RS232 Configuration > MODBUS

MODBUS Address List

To add a Modbus Address:

- 1. In ACEmanager, go to Serial > RS232 Configuration > MODBUS.
- 2. Under Address List, click Add More.
- **3.** Enter the Index number, an equal sign, and the IP address. For example: 10=123.123.123.123 (decimal)

0xA=123.123.123.123 (hex) Prefix 0x to hex numbers.

Note: The range for index numbers is 0-255 (decimal) or 0x0-0xFF (hex). The Modbus address list accepts up to 100 entries.

Including the port number after the IP address is optional. If you include the port number, separate the port number and IP address by a colon. For example:

10=123.123.123.123:11223 0xA=123.123.123.123:11223

Hambelink Withdow	4.517.10.0700	Tapers A. Aven Battan Service	
		- Newcounty through the con-	
01232 Configuration	The second se		
Canada	(3.General.		
	AT IP Liel Dia	Duality +	
PME .	At Address List		
Reserve Total	Address List		
		Address Entry	
		10=124 108 30 29 1234	
11.00		11=124 124 124 124 56	
MORENT		12=123 123 123 123 48	
10 Million		13=192 168 39 49 5674	

Figure 12-8: Serial > MODBUS Address List

- 4. Click Apply.
- 5. Reboot.

To delete an address from the list, click the X beside it.

Note: You can also use the AT Commands MLIST and MLISTX to add address entries and MLIST? or MLISTX? to query the entries on the list. See MLIST on page 534, and MLISTX on page 535.

Configuring IP to Serial with Answer and Serial to IP

You can configure the AirLink gateway to:

- Answer incoming TCP/IP or UDP/IP connections and send the packet payload out the AirLink gateway's serial port to a connected device
- Create and send TCP/IP or UDP/IP packets containing payload data that the AirLink gateway receives over its serial port from a connected device
- Both receive and send TCP/IP or UDP/IP packets (that is, both of the above functionalities)




Figure 12-9: TCP and UDP Answer

To configure the AirLink RV55 for TCP/UDP answer, sending IP packets or both:

- **1.** In ACEmanager, go to Serial > RS232 Configuration > General.
- 2. Use Table 12-6 and Step 5 onwards to configure the desired options for this feature.

Table 12-6: (Quick Guide to	Configuring IP t	o Serial with	Answer and Serial to IP
---------------	----------------	------------------	---------------	-------------------------

Field	To receive packets and send data payload out over serial	To receive data payloads over serial and send out packets	Both (to receive packets - send out data payload AND receive data payload and send out packets)
Startup Mode Default See step Step 5.	N/A	UDP or TCP	UDP or TCP
Configure Serial Port See Step 6.	115200,8N1	115200,8N1	115200,8N1
Flow Control See Step 7.	None	None	None

ual M1232 Configuration		
	114020	
Andered .	H11232 Peek	Cratte +
140	85202 Dual Port Male	Onace +
Receive Terror	All Startup Viele Detault	(40%
	11 HTZ22 Peri Configuration	
n.#	AT Configure R5233 First	115200.001
NOTION OF	AT How Control	/Hare -
ED Inellicenter	AT CED Secol Date:	Cryste
	[14] Advantage	

Figure 12-10: ACEmanager: Serial > RS232 Configuration > General

- **3.** Go to Serial > RS232 Configuration > PAD
- 4. Use Table 12-7 and Step 5 onwards to configure the desired options for this feature.

Table 12-7: Quick Guide to Configuring IP to Serial with Answer and Serial to IP

Field	To receive packets and send data payload out over serial	To receive data payloads over serial and send out packets	Both (to receive packets - send out data payload AND receive data payload and send out packets)
Device Port See Step 8.	12345	N/A	12345
Destination Port See Step 9.	N/A	Required	Required
Destination Address See Step 10.	N/A	Required	Required

anugentables injajir	1000070		Daniel Aren Bebert Care
RS210 Configuration			
Table 1	11: General		
	aT Depice Past	12345	
and .	AT Serial MTU	1394	
Incoming Terrori	#7 Destination Part	0	
	42 Destination Address	0.0.0.0	
PPP .	47 Default Digi Mode	VDF +	
10.00	Cola Paraseting Timeout (1 excertd)	1	
MORRO D	RT Data Forwarding Character	0	
LED bullcaber	(Jr)TOP		
	[19]143P		

Required field for receiving IP packets and sending out data payloads over serial

Required fields for receiving data payloads over serial, creating IP packets to send Figure 12-11: ACEmanager: Serial > RS232 Configuration > PAD

- 5. Startup Default Mode—When the Startup Mode is set to UDP or TCP, the AirLink gateway takes any data sent to its serial port by a connected device and encapsulates it into a TCP/IP or UDP/IP packet.
- 6. Configure Serial Port—Set the baud rate of the serial port on the AirLink gateway so that it matches the baud rate of the serial port on the connected device. (The default baud rate is 115200 bps.) You can also use this field to set the framing characteristics for the serial port communication on those rare occasions when the default value of 8N1 does not apply.
- 7. Flow Control—This field can usually be left at the default value (None) as most serial devices use only a 3-wire connection (Tx, RX, and Gnd). However, if the serial device uses the RTS and CTS pins on the serial connection to control data flow between the two devices, set this field to Hardware.
- **8.** Device Port—Data received on a TCP/IP or UDP/IP connection to the configured Device Port is sent out the serial port. The default value for the port is 12345.
- **9.** Destination Port—The AirLink gateway uses the port value specified in this field to determine which port it sends the IP packet containing the data payload to. The AirLink gateway enters the value in the Destination Port field in the header of the IP packet it creates.
- 10. Destination Address—The AirLink gateway uses the IP address specified in this field to determine the IP address to send the packet it creates to. The AirLink gateway enters this IP address in the header of the IP packet it creates.
- 11. If you are configuring the AirLink gateway to:
 - Create and send packets only, go to step Step 12.
 - Receive TCP/UDP packets, complete the following instructions.

For Receiving TCP/IP Packets:

a. Expand the +TCP section of the screen.

H tch	
⁵¹ Foreign te answer	In the second
²¹ K.F. Son Rest, Lineaut (Second).	10
^{AT} INFIDE INFOR	*
AT INFORMATION OF	Maria
All Level contract semponase tearty (secondar)	d

Figure 12-12: ACEmanager: Serial > RS232 Configuration > PAD > TCP

b. Set the TCP Auto Answer field to Enable.

For Receiving UDP/IP Packets:

a. Expand the +UDP section of the screen.

Hate.	
11 112 Anio Anton	
With the formula (second) (<u>20</u>
W 102 Comme David	Terrari dang 28% -
📅 Allow Ang haranang D	Alian Jan, 12 🖉
67 Alles All 199	No. Cel -
🖉 1109 Anto Ansaro Despinisar	Malk appression w
Without the Association of the A	Transfer -
Wind Service (Community)	0

Figure 12-13: ACEmanager: Serial > RS232 Configuration > PAD > UDP

- **b.** Set the UDP Auto Answer field to Enable.
- **c.** Set the Allow Any Incoming IP field to Allow Any IP. (If this field is left at the default value, the AirLink gateway only accepts incoming UDP/IP packets from the IP address specified in the Destination Address field in the Port Configuration section of the screen.
- **12.** For information on the other parameters, see RS232 Configuration on page 324.
- **13.** Click Apply.
- 14. Click Reboot (in the upper right of the screen).
- **15.** Once the reboot is complete, this feature is enabled.

If the packet contents are not being sent to the connected device, see the troubleshooting information in TCP/IP and UDP/IP Auto Answer on page 576.

LED Indicator

You can configure the Activity LED on the AirLink gateway to flash red when traffic is being transmitted or received over the serial port.

Ratue Well-Certurar Dua	Rather PW Alan geomatic	Services. Location Events Reporting Dual Series	Applications 50 Admin
ad ophical inter-straight at its 1	1.460		April Colors Course
Dual R1212 Coefigentian	4 Doptay	Date +	
General	H Sand Port	Put 1 -	
(MR)			
Review Steel			
2119			
3120			
MODBUT			
LED facilitation			

Figure 12-14: ACEmanager: Serial > LED Indicator

Table 12-8: Serial > LED Indicator

Field	Description		
Display	Options are: • Disable (default) • Enable If this field is set to Enable, the traffic is being transmitted/re	he Activity LED (≝) on the AirLink gateway flashes red when eceived on the serial port.	
	Activity LED	Traffic	
	Off	No traffic	
	Flashing Green	Traffic on WAN interface	
	Flashing Red	Traffic on selected serial port	
	Flashing Yellow	Traffic on both the WAN interface and selected serial port	
		mand to configure this field. See *SERIALLEDDISPLAY on t of LED behavior, refer to the Hardware User Guide for your	
Serial Port	devices are connected to the	ort Mode, sets the port that the Activity LED indicates. If two e serial port using a split cable, and Port 1 is selected, the here is data on UART1. If Port 2 is selected, the activity LED on UART5.	

>> 13: Applications Configuration

The Applications tab consists of a Data Usage section, a Garmin application, and an ALEOS Application Framework section.

Data Usage

Note: Before configuring Data Usage, ensure that the AirLink gateway receives date and time information from the mobile network, or from GNSS in the case of a gateway using Location technology. You can also use the ACEmanager SNTP client to receive time from an SNTP server. (See Time (NTP) on page 271.) If necessary, contact your Mobile Network Operator to confirm that the mobile network provides date and time information to connected devices.

The Data Usage feature on the Applications tab in conjunction with Events Reporting provides you with a way to actively monitor cellular data usage.

Once data usage is configured, you can use event reporting to:

- Actively monitor the cellular data usage by configuring monthly and/or daily usage level thresholds that result in notifications being sent to you (e.g. email, SMS, or SNMP Trap) when the threshold is reached.
- Limit mobile network communication until the end of the billing period when the data limit is reached by blocking connected LAN devices from using the mobile network. Traffic sent to and from the AirLink gateway is not blocked. Over-the-air access to ACEmanager and the Telnet/SSH AT interface is still available.

Note: You can configure Events Reporting to notify you when the threshold set in Data Usage is reached, but ALEOS does not block further access to the mobile network unless you also create a second action to Turn Off Services.

Note: ALEOS Data Usage is approximate and should not be compared with data usage recorded by the Mobile Network Operator.

Sierra Wireless is NOT responsible for data overages.

Step 1—Configure Data Usage

- 1. In ACEmanager, go to Applications > Data Usage.
- 2. In the Usage Monitoring field, select Enable.
- **3.** In the side menu, select the SIM slot you want to configure: Data Usage Slot 1 or Data Usage Slot 2 or Data Usage R2C eSIM (if available).

Note: If R2C eSIM is available, an additional Data Usage page appears.



Figure 13-1: Applications > Data Usage (R2C eSIM available)

Data usage monitors the slot. If you change the SIM card in the slot being monitored, the data usage tracked is the accumulative data usage for all SIM cards placed in that slot.

- 4. Enter the desired values in the Daily or Monthly Limit fields (in GB or MB), and the day of the month that the billing cycle starts. For more details, see the table starting on page 349.
- 5. Click Apply.

states with a cit	11	Employ And		
Name (Ausgar Start %				
	H SRAWA			
Hels Unage Sint 2				
Data Unique XOC & SAM	Decisioner: Data Urage is well interceded to be an cleaning institute to the card humber of cards types being reported by your institute carbie on their monthly will. The data stage hadees provided to your Arcan being is interceded to prende an approximate time of bela scage over a period of time to allow cashs to data many of their favora to going over larger formal data scage.			
Garman	AP strage blockeng	(Dame -		
ALED& Application Frankwork:	Data Sanica Australia antier usage limit.			
	AT the Units	(HK.+)		
	() One Line			
	Detricine (MD)	0		
	Carrent Daily Visage (MB)	8.		
	Typesen, Link .			
	Microlity-Carlot (Junio	MD +		
	Marthly Lond (to units as specified above)			
	Carteri Moritini Usuage (ME)	*		
	Bain Of Billing Cubs (Day Of Menth)	18		
	[11Previous Day			
	Predma Calv Usage Sills			

Figure 13-2: ACEmanager: Applications > Data Usage Slot 1

Field	Description			
General				
Usage Monitoring	Use this field to enable or disable data usage monitoring. Options are:Disable (default)Enable			
Data Service	This field is intended for use in conjunction with Events Reporting, specifically a Data Usage Event with Turn Off Services as the configured action. For more information and instructions on configuring the appropriate Event Reporting settings, see Stopping Service when the Event Reporting Threshold is Reached on page 354.			
	Data Usage	Turn Off Services Events Reporting action configured	Data Service displays	
	Over threshold configured in Events Reporting	No	Available (under usage limit)	
	Under threshold configured in Events Reporting	Yes	Available (under usage limit)	
	Over threshold configured in Events Reporting	Yes	Blocked (usage limit exceeded)	
	not actually stopped when this have also configured Event R See Stopping Service when th	s field reads "Blocked (usag eporting to Turn Off Service he Event Reporting Thresh		
Plan Units	 Select the units used for your data plan. The options are: MB—Megabytes (default) KB—Kilobytes 			
	Note: When you change the Monthly Limit fields are not co		for values in the Daily Limit and ted manually.	

Field	Description
Daily Limit	
Daily Limit (MB)	This is the user-specified daily (24 hour) data usage limit (in MB or KB, depending on the value in the Plan Units field). You can specify data usage limits on a daily basis. A limit is essentially a threshold that can trigger the software to take a user-specified action if the usage goes above the threshold. See Events Reporting Configuration on page 304.
	Note: The Daily Limit value MUST be expressed as an integer (i.e., a whole number) and NOT as a fraction (e.g., "3.5").
	Note: Daily usage is cleared at midnight, UTC.
	Caution: Data usage limits are approximate and based on reporting conditions in ALEOS. Data usage may run over the amount set in this field before the action specified for the threshold trigger takes effect.
	Tip: ALEOS reads the data usage every 3 to 5 minutes. If you are using an application that requires high data usage, you can set an alert to warn you when data usage reaches a safe limit that takes into account the amount of data expected over the 3 to 5 minutes between data usage readings. For information on how to set an alert or other action, see Events Reporting Configuration on page 304.
Current Daily Usage (MB)	Displays the current daily data usage (in MB or KB, depending on the option selected in the Plan Units field)
	Note: Data usage includes data sent and data received.

Field	Description
Monthly Limit	
Monthly Limit Units	Select the units used for your monthly data plan. This option does not appear if KB is selected for Plan Units. The options are: MB—Megabytes (default) GB—Gigabytes
Monthly Limit	This is the user-specified monthly data usage limit (in KB, MB or GB, depending on the option selected in the Plan Units and Monthly Limit Units field). Data usage accumulates on a monthly basis and on the date you specified (the "rolling month"). Data usage accumulates during the month until the end of the next billing period, at which point the data usage totals are reset.
	Note: The Monthly Limit value MUST be expressed as an integer (i.e., a whole number) and NOT as a fraction (e.g., "3.5")
	Note: Monthly usage is cleared at midnight, UTC on the last day of the billing cycle.
	Caution: Data usage limits are approximate and based on reporting conditions in ALEOS. Data usage may run over the amount set in this field before the action specified for the threshold trigger takes effect.
Current Monthly Usage	Displays the current monthly data usage (in MB or KB, depending on the value configured in Plan Units on page 349.)
	Note: Data usage includes data sent and data received.
Start of Billing Cycle (Day of Month)	Enter the desired start of the billing cycle. For example, 3 (Day 3 of every month) Changing the value in this field resets the Current Monthly Usage field to zero.
Previous Day	
Previous Daily Usage	Shows the data usage for the previous day (in MB or KB, depending on the value configured in Plan Units on page 349.)
	Note: Data usage includes data sent and data received.

Step 2—Configure Event Reporting

1. In ACEmanager, go to Events Reporting > Actions.

NUMPCARatar 2 1.04	and a second second second second second	and the second se	vents Reporting		6 00 Advin	
				8.3	and faile feet	1000 Cer
	State Contra					
Add New	-information and			Monthly Data Uni	age St	
Ben .	Autor Tare			Free		
Bandhig Said Straight D	(Charlefornites					
and the w	Kinal To			myernal@iep ca		
	Erval Subject			Data those Still	1	
	Dreat Message			The data usage i	tor SM 1	
	Relly Type			ATCE Not in		
	Testreput			Terroport		
	Hittata Group					
	Data Drog.					
	Digital and Awarog I/D		General Inde	Network Date	falla	Macadamous
	Diploment	C taxable Fis	∉ (tenn t)	Classical State	Cityles Sect.	Develo
	Citighe Deput 1	Dumie	Promiterier	C Yebert Charnel	C Syme Respond	D Brant Temperature
	Public Accomulator 1	Olimpine	Demainante	Classe	Creating and	C mattere bas
		Cinately Card	THICARDON	Trades Technology		The Martin Territorial
		Ciencia Surrett	2100	Cristeen Sense	C P Pastata Gant	COMAPRE MAN
		Oversta Haading	D en	Change	C IP Pastata Bacariad	COMABLE
		Dunerture	C arres Geneter		Courses wanted	Cases
		Course	Citre		Creat # Pacieto Nacavad	Cores
		Covera:	(1) age 200	CONVINCE INT		
			Diverse las	County Linese Start		
			Danset	Ci Delle Visige BAZ		
			Cimenat	Citoretro Unique 1842		
	Changingset		22.9.191.947 S			
	1 12:23					

Figure 13-3: ACEmanager: Events Reporting > Actions

- 2. Select the desired Action to be performed when the Event is triggered, such as SNMP Trap or Email, and enter the appropriate information in the related fields. For detailed instructions, see Configuring Events Reporting on page 305.
- **3.** Some reports give you the option to include additional information. If applicable, select the check box(es) in the Data Group section of the screen to indicate the information to be included in the report.

Note: You can have more than one Action for a single Event, but you can only have one Daily Usage and one Monthly Usage Event.

4. Click Apply.

5. Go to Events Reporting > Events and configure a data usage threshold.

The threshold is specified as a percentage of the monthly or daily limit. For example, if you have a monthly limit of 5 GB, and the threshold is set at 80%, then threshold is reached at 4 GB of data. For detailed instructions, see Configuring Events Reporting on page 305.

ALCONFICTATION CONTRACT	NUMBER AND	10					10000	Winds Streets	C LOWING	S (Internet Street	
							Statute of	and there	e (has	di Chanadi Chan	
Evente											
		(14Evint)	Details								
Take Garge		Dyert	servi .				Date Use	20			
Auto Dava		Event Type					Monthly Data Usage 🔹				
Actions		Event IIM				Bat 1 -					
		Event	operator				Disable				
Data Ukaya		Value To Company (% of Umit)				875 -					
Add New			Onciption								
			Description								
		-				Action 1	lama				
		Read	a Usager								

Figure 13-4: ACEmanager: Events Reporting > Events

- 6. At the bottom of the screen, select the check box beside the Action you want to associate the Event with.
- 7. Click Apply.

Stopping Service when the Event Reporting Threshold is Reached

When you are approaching the data plan limit, you may want to turn off cellular communication to any LAN connected user devices until the next billing cycle starts.

To turn off services on the data plan when the limit is reached:

- 1. In ACEmanager, go to Events Reporting and select Actions Add New on the left menu.
- 2. Enter the desired name for the action.
- 3. In the Action Type field, select Turn Off Services.

When triggered, this action prevents cellular communication to all LAN connected devices. Traffic sent from the AirLink gateway is not blocked. Over-the-air access to ACEmanager and the Telnet/SSH AT interface is still available.

Itatus 10	UIICettuler	1,411	VPN	Berartig	Services	Location	Events Reporting	Ferial	Appleations	10	Adam
	m 224203		10					1000	4.44 (Sette	1000	Refer Carry
Everts.			(je Actor								
Add Street			Action				±1	Deta Usaj	29		
Actions Republican			Active	Type				fuir Of Sen		•	
Add New											

Figure 13-5: ACEmanager: Events Reporting

- 4. Click Apply.
- 5. Select Events on the left menu.
- 6. Enter the desired Event Name.
- 7. In the Event Type field, select either Daily Data Usage or Monthly Data Usage.
- 8. In the Event Operator field, select When Above Threshold.
- 9. Set the desired Value to Compare (% of limit).
- **10.** At the bottom of the screen, select the check box beside the Action you want to associate the Event with.

He Lander Intel 2000	10.31.017.40.7%	Anna Anna Anna Anna
Reatty		
	14Esimit Detaile	
Date Olegar	Dyort liam	Data Usage
Auto News	Event Type	Monthly Data Usage -
Actons	Event IBM	Det -
	Event Operator	Deadler •
Data Ukaya	Value To Compare (% of Umit)	875 -
Add New		
	(1) Active Omeration	
	Action Description	
		Action Name
	R Data Usage	

Figure 13-6: ACEmanager: Events Reporting > Events

11. Click Apply.

Note: When the configured threshold is crossed, all traffic between connected devices and the cellular network is blocked. This helps to reduce data usage, but it does not completely stop it. Traffic to and from the AirLink gateway is not blocked, and over-the-air access to ACEmanager and the Telnet/SSH AT interface is still available.

Setting the "Turn Off Services" threshold at a level below 100% of the data plan helps to reduce data usage before the data plan limits are exceeded.

Garmin

Garmin provides navigation devices for versatile fleet monitoring solutions. AirLink gateways provide Internet access to Garmin devices and a mechanism to enable via cellular. ALEOS also monitors links to the Garmin device and communication between the Garmin device and the server.

To configure Garmin in ACEmanager:

1. Under the Applications > Garmin, set the Garmin Device Attached feature to Enabled.

tetus WHICettular Litt	59% 34	eautity Services	Louffer	Evens Reporting	Setu:	Applications	10	Aban
at opposited from the property of the							Auri	fields. Easter
Data Usage Slot 1	al Game Dev	ele Attached			Even +			
Data Usage Het 3	All Garner Ska	All Garren Status						
Lamter								
ALGOS Application Frameword								

Figure 13-7: ACEmanager: Applications > Garmin

2. Go to Serial > RS232 Configuration > General and set the Startup Mode Default field to TCP.

Note: Ensure that Dual Port Mode is disabled. AirLink RV55 supports a connection to a Garmin device only in Single Serial Mode.

- 3. Configure the serial port. To communicate with Garmin:
 - · Set Configure Serial Port to 9600, 8N1
 - Set Flow Control to None
 - Set DTR Mode to Ignore DTR.
- 4. Go to Serial > RS232 Configuration > PAD and set the Destination Port and the Destination Address to the port and address of the AVL server that the TCP application will be communicating with.

al sublicities (bitter) (rates	12.444	Description (Second Second Second Second					
Real B1222 Configuration							
internal distances	Harten						
	#5232 Pwn	to ever +					
PRO .	RE212 Qual Flat: Mark	Disation +					
Name of Street	41 Islands Mute Default	(TDP +					
	HURSTER Post Configuration						
11.1P	47 Cardigan Hill212 Part	115200.0N1					
and the second s	47 Hew Control	None					
LED Inelicator	47 (20) Seriel Exher	bate -					
	[] Adarcal						
	at Arrest 1159	Alantyy					
	47 Asset DOD	(+ Data Hole +					
	47 STR Made	sphere (178)					
	47 Gunt Mole	Daama -					
	Exate Status Of insume	Anatie +					
	43 AF Verland Mede	Terbury .*					
	47 Eati Progress Result Maile	Daabe -					
	49 Canet 12 day Nevier to P. Addess	And at fairing or					
	AT Duates ATT Recat	ia -					
	Bear Westing	Diados -					
	Tanat Watcholog Delay (nerutaa)	10					

Figure 13-8: ACEmanager: Serial > Port Configuration > General

of sphere loss. Internet 11.00.0			Constant Provide Constant (Second
Prot ADUTE Conferences	1		
And a second second second	Hillerand		
	47 Device Pert	12345	
182	All Decid MIG	1304	
Approximity Talanti	AT Destination Pur	0	
	AT Destination Address	0.0.0.0	
	All Debuilt Dail Marte	(00) =	
11.00	47 Data Parametry Treast (1 access).	1	
NUMBER OF STREET	AT Data Pavanding Diamater	0	
ED health mine			
	(HTC)		
	AT TOP Auto Acover	Department of	
	TEP Percelet Consider	Cheater -	
	AT TEP Execut Trend (second)	30	
	AP TCP Min Televani	5	
	47 TOP dis Timenal 1/68	atrutes	
	AT TCP Connect Responds Delay (accurds)	0	
	Heliate Device 10 on TCP Connect.	Teaster -	
	(j+jupe		

Figure 13-9: ACEmanager: Serial > RS232 Configuration > PAD

- **5.** Check the Garmin's communications status under the Status > Applications tab. Garmin data service states are:
 - Not Enabled—Not acknowledged by the AVL server
 - Enabled—Acknowledged by the AVL server.

ALEOS 4.14.0 Software Configuration User Guide for AirLink RV55

ny dampine (2003) (1)	U M AR	rate failant fan
Home	Af Garret Status	Not Enabled
Celbiar	Data Serata	Available partie usage brid)
Ethional	Available (LAM (KII))	100004
Enternal	Available Flash (KD)	1
Doar WOFF	CPU Line (set 16 minutes)	IR 140900
LAX (PMAC Table	ALECE Application Francesonk	Deathel
	Inna Part Reserved	Deathed
ultu Security Securities Location Dual Series	GCOM DM Pert Researce Reserve	Dueter
and allow		
Publicy Basetting		
ksa		
PATH		
Abund		

Figure 13-10: ACEmanager: Status > Applications > Garmin Status

6. Reboot the AirLink gateway to apply the changes. The "Garmin Status" now appears:
Enabled—Acknowledged by the AVL server.

Note: The Garmin Status field appears **only** if the Garmin application is Connected.

ALEOS Application Framework

ALEOS Application Framework (AAF) allows you to develop your own applications to run inside an AirLink gateway and leverage the ALEOS Application Platform (source.sierrawireless.com/resources/airlink/aleos_af/aleos_af_home/) or a customer-developed server platform.

Sierra Wireless gateways come without an AAF user password. Before using AAF, select a password and go to Admin > Change Password to enter it. See AAF User Password on page 370. The AAF Development Studio (DevStudio) application uses this password to communicate with the gateway.

Once the AAF user password is set up, embedded and server application developers can start using AAF by accessing the ALEOS Application Platform (source.sierrawireless.com/ resources/airlink/aleos_af/aleos_af_home/).

You may want to reserve the serial port for an AAF application. To do so, select Enable in Applications > ALEOS Application Framework > Serial Port Reserved.

It is not necessary to reserve the serial port before activating AAF.

Reserving the serial port is mandatory only if the AAF application will be using the serial port.

Note: When you reserve the serial port for AAF, it cannot be used for any other serial-related ALEOS features.

upped are structure and	kig .	and the second sec						
		Example Auto	Heren Care					
de Usage Stol 1								
	H General							
da Usage Stot 2	Available RAM (KE)	294000						
177990	Available Flach (SE)	222840						
101 Application Framework	CPU Load (last 15 minutes)	6.410000						
Trevenue-caralleritization	4LEOS Application Framework	frate -						
	Sertal Port Reparced	bute -						
	UARE CENT	Draftad w						
	UNRT Result Time-Window (seconds)	4						
	GOOM DN Port Resource Reserve	(frame -						
	ELAW Applications							
	No. ANY application multiplied							
	Browse No N	selected. Install AM Approxim						

Figure 13-11: ACEmanager: Applications >ALEOS Application Framework (no applications installed)

a retaining and a strategy of a lar	STAT					Course of the		Halten Carts			
Isla Ilsage Set 1											
	1.1 Centers:										
Data Usage Shit 2	Austable RAM (KE)				201656						
Autroin .	Available Flagh (KB)				0						
ALETIN Application Trademonth	CPU Load dast 15 min	(when			0.088000						
ALEO'S Application Tratements	ALECS Application Fra	ALECS Application Framework					Dealer w				
	Settal Port Reserved				tome -						
	LINRT Check				Delet v						
	UART Reset Time into	dow (seconds)			4						
	GCCN CNI Port Rases				Deaths with						
	(1) ANP Applications										
	Applituders Hares	Automat	Neslag	Teres		Actions	- 11				
	(matter#	Test.	- ak (Tag Surray						
	moved.	Test o	-0	-mapped	Test Streets	1 Designed					
	aureed.	100-0	(4)		Theil Monated	Treasure .					

Figure 13-12: ACEmanager: Applications > ALEOS Application Framework (applications installed)

Field	Description
General	
Available RAM (KB)	Available RAM in kilobytes (1000 bytes), updated every 30 seconds
Available Flash (KB)	Available Flash on the user partition in kilobytes (1024 bytes), updated every 30 seconds
CPU Load (Last 15 minutes)	CPU load, averaged over the last 15 minutes and updated every 30 seconds The CPU load relates to how many applications are attempting to execute in parallel over the 15-minute period. If the load is greater than 1, some applications are waiting for CPU capacity to become available and may be delayed in launching.
ALEOS Application Framework	Enable or disable (default) the ALEOS Application Framework (ALEOS AF). If enabled, ALEOS AF starts at boot time. When the Reset to Factory default button on the Admin > Advanced page is pressed, ALEOS AF is disabled.
Serial Port Reserved	 Select Enable to reserve the serial port for ALEOS AF. When this field is set to Enable, the serial port cannot be used for any other serial-related ALEOS features. The options are: Disable (default) Enable
UART Check	 This setting appears when Serial Port Reserved is enabled. The UART Check setting checks for UART errors and resets UART if an error occurs. The options are: Disabled (default) Enabled
UART Reset Time- Window (seconds)	This setting appears when UART Check is enabled. The UART Reset Time-Window setting configures when a UART reset will occur. After a baud rate change, if ALEOS detects a UART error within the time window, it triggers a UART reset. Options are: 1–60, 4 default
QCOM DM Port Resource Reserve	Reserves the QCOM DM port for ALEOS AF applications. Options are: Enable (Reserve access for ALEOS AF) or Disable (Reserve access for ALEOS). Default: Disable
AAF Applications	
Application Name Autostart Version Status Actions	If there are no AAF applications enabled and started, one of the following messages is displayed: "AAF not activated"—AAF is not enabled "AAF not started"—AAF is not yet started "No AAF Application installed" When AAF is enabled and started, you can install an application. To install an application: Click Browse and navigate to the application you want to install. Click the Install AAF Application button. For installed applications, the table shows the: Application name Autostart—true or false Version Status—started or stopped Use the Stop/Start, Uninstall, and Details buttons to manage your applications. For more information on the Details button, refer to AAF—Customizing UI Elements on source.sierrawireless.com.

>> 14: I/O Configuration

The I/O tab in ACEmanager applies to all Sierra Wireless AirLink gateways or routers that feature I/O ports.

You can use the input/outputs on AirLink gateways to generate reports based on a threshold being crossed, a switch being opened or closed, or the number of times a switch has changed state.

Use the Events Reporting screen to configure reports. (See Events Reporting Configuration on page 304.) Use the I/O screen to view the current state of the analog and digital inputs, to turn the relays on and off, and to configure the units you want used in the reports based on analog inputs.

The AirLink RV55 has:

- One pin (Pin 4 on the power connector) that can be configured as a digital input/ output, relay output, or analog input.
- Pull-up is available for digital input.

More information

For more information, refer to the Hardware User Guide for the AirLink RV55.

Analog inputs

Analog inputs monitor a voltage range in small increments. This allows you to monitor equipment that reports status as an analog voltage. Examples include:

- Power supply voltage
- Temperature, weight, volume, flow represented as voltage
- An incremental gauge with a voltage output
- Vehicle battery voltage

The raw data for the changes being monitored is in volts, but you can use the I/O Configuration screen in ACEmanager to convert voltage to the desired units of measurement. See Transformed Analog on page 367.

Digital inputs

Digital inputs monitor contact closures on a switch. This allows you to monitor changes such as:

- When a door or latch is open or closed
- When a container is full or empty
- When a switch or valve is opened or closed
- The level of fuel in a vehicle (connected to an on/off sensor)
- When the trunk of a vehicle is opened or closed

You can use Events Reporting to generate reports and actions based on the digital input values.

Volts	Interpreted as
≤ 1.0	Digital 0
≥ 2.7	Digital 1

For more information on setting up reports, see Events Reporting Configuration on page 304.

Relay outputs

You can use relay outputs to trigger an intermediary switch and change the state of equipment.

Current State

The Current State screen allows you to view the current values (as of the last refresh) of analog and digital inputs, pulse counts for digital inputs, and raw and transformed values for analog inputs. You can also use this screen to change the current values for Relay outputs. This change occurs immediately without a reboot.

re undered from 107012246-4.3	D IT PY		(Carrow)	(hereit) Dett	
Survent State					
and the second se	Olgital Input				
Configuration	Number	Value (0 = Low, 1 = High		e Count	
		0		0	
	Analog Input				
	Kunber	Value (Volta)	Transfor	med Analog	
		0.01		100	
	Relay Output				
	Hambe	M	Value (0 + relay open, 1 + rel	ay (tobed)	
			017 .		

Figure 14-1: ACEmanager: I/O > Current State

Table 14-1: I/O: Current State

Command	Description				
Digital Input					
Number	Displays the number	of digital inputs. The corresponding hardware pins are:			
	Digital Input	Corresponding hardware pin			
	1 P	in 4 on Power connector			
Value	• 0 —Low • 1 —High	value for the digital input: AT command to read these values. See *DIGITALIN[n]? on			
Pulse Count	The pulse count increments when the input value changes from high to low.				
	Note: To reset the pulse count to zero, reset the device to the factory defaults.				
Analog Input					
Number	Displays the number of analog inputs. The corresponding hardware pins are:				
	Analog Input	Corresponding hardware pin			
	1	Pin 4 on Power connector			
Value (Volts)	Shows the current state of the analog input The analog inputs report the voltage in volts. Range is 0–30 volts. You can also use an AT command to read these values. See *ANALOGIN[n]? on page 547.				
Transformed Analog	The analog input exp page 367.	pressed in the configured units. See Transformed Analog on			
Relay Output		current sink that you can use to drive a relay or for other use vitchable low side current sink is required. For more details refer to uide.			

Command	Description				
Number	Displays the number of relay outputs. The corresponding hardware pins are:				
	Relay Output Corresponding hardware pin				
	1 Pin 4 on Power connector				
Value	Options are: • OFF (default)—Relay open. • Drive Active Low—Relay closed.				
	Note: You cannot set this field to Drive Action Low if the I/O line is already being used for Standby mode.				
	You can also use an AT command (see *RELAYOUT1 on page 547), an SMS command (see [prefix]relay x y on page 557), or a RAP command (refer to the Remote Application Protocol User Guide) to configure this field.				
	Note: Changes to this field go into effect immediately. No reboot of the AirLink gateway is necessary.				

Table 14-1: I/O: Current State

Pulse Count

Pulse Count details:

- Pulses are counted on falling edge (high to low).
- Repeated pulses cannot be counted when the device is powered off, or being reset. However, a single change in state while the device is powered off or being reset is counted properly.
- To reset the pulse count to zero, reset the device to the factory defaults.

Configuration

This screen allows you to configure the initial relay settings and to transform units of measurement for the analog inputs from volts to a more appropriate unit, if applicable. Generated reports use the transformed value configured on this screen.

For more information, refer to the Hardware Configuration User Guide for your AirLink gateway.

e sprinke inte 1757	256-4.20-36,794				Alle Rotten Cal			
Current Itlate	12,02712	1002						
Genfiguration .	Puli-up t		Number	Value (Deschied a)	ov Enabled = Minki			
And the second s			4	Cina	Value (Disabled = Low, Enabled = High) Coulds =			
	Analog			10. 	a anal			
		Number	Ecefficient	Offset	Unite			
		1	1	0				
	Relay Se	ttinga	increased.					
			Number	initial	Setting			
			(d).	017	•			

Figure 14-2: ACEmanager: I/O > Configuration

Field	Description	Description			
Pull-up for I/O					
Number	Displays the nur	mber of pull-ups. The corresponding hardware pins are:			
	Pull-up	Pull-up Corresponding hardware pin			
	1	Pin 4 on Power connector			

Field	Description				
Value	Disable—The pull- Enable—The pull- The pull-up voltage is b Note: You cannot enable Standby mode. Note: During bootup, th resistor is disabled, and	he I/O settings remain in their default state: the internal pull-up do output current sink switch is open. After bootup, any custom I/O his may take approximately 30 seconds after the gateway is			
Analog					
Number	Displays the number of	analog inputs. The corresponding hardware pins are:			
	Analog Input	Corresponding hardware pin			
	1	Pin 4 on Power connector			
Coefficient Offset	 This value may be found in the user guide for the equipment you want to monitor, or you can calculate it from information in the user guide. If this information is not available in the documentation that came with the equipment you want to monitor, contact the manufacturer. For an example of how to calculate the coefficient, see Transformed Analog on page 367 The offset (difference) between 0 volts and the equivalent value for the desired unit of 				
Units	The unit of measurement used in event reporting for the parameter being monitored by the analog input For example: degrees Celsius, degrees Fahrenheit, liters, mm, etc.				
Relay Settings					
Number		relay outputs. The corresponding hardware pins are:			
	Relay Output	Corresponding hardware pin			
	1	Pin 4 on Power connector			
Initial Setting	 Options are: ON OFF (default) Last Value (The var powered down). 	e current sink when the AirLink gateway is powered on Ilue remains the same as it was before the AirLink gateway was field, the corresponding digital input value on this screen reflects			

Transformed Analog

The raw analog data is displayed in volts. However, that is not always the most convenient unit of measurement to view the data. The I/O Configuration screen enables you to transform the voltage readings to a more convenient unit of measurement, for example degrees Celsius or Fahrenheit for temperature, liters for volume, etc.

Step 1—Coefficient and Offset

Before you configure ACEmanager, you need to locate or calculate the coefficient and the offset values.

Consult the user documentation for the equipment you want to monitor. It should provide you with the coefficient to convert volts to the appropriate unit of measurement and the offset value (the difference between the equivalent value for 0 volts and 0), or provide information on equivalent values for voltage readings from which you can calculate the coefficient and offset. (If this information is not available in the user documentation, contact the manufacturer.)

For example, if the equipment monitors temperature, and has a scale from 0 volts to 30 volts, the equipment specifications should provide information similar to the following:

0 V is equivalent to -20°C

30 V is equivalent to 100°C

This is expressed algebraically as follows:

 $a \times 0V + b = -20C$

 $a \times 30V + b = 100C$

where:

a = coefficient

b = offset

For this example, you can calculate a as follows:

 $(a \times 30V + b) - (a \times 0V + b) = 100C - (-20)$

 $a \times 30 V = 120 V$

a=4

To calculate b, substitute a into the first equation above:

 $4 \times 0V + b = -20$

b = -20

Step 2—Configure ACEmanager

For each of the analog inputs you want to configure:

1. In ACEmanager, go to I/O > Configuration.

- 2. Enter the values for the coefficient and offset. (In this example, the coefficient is 4 and the offset is –20.)
- **3.** Enter the desired unit of measurement. (In this example, the unit of measurement is C, for degrees Celsius).

ACEmanager shows the value of the transformed analog input as temperature in C.

Note: A reboot is required after configuring the transformed analog values.

>>> 15: Admin

Change Password

For system security reasons, ensure that you change the default password of the RV55.

Mature WANCellular Wi	PS LAN VPH	Security	Services	Location	Events Report	ng Senel	Applications	10.	Admin
an animphree all states of \$1.	5.44						(Association)	-	
Ourge Process #	Til Claugh Passand								
Advanced	(Iterasy comment								
Revent				100		4			
Radio Tarm									
ing.				The second second					
Configure Lagging						Fairment			
Revenue Linguing									
From Log.	1-2-844" Lines: Statut								
Analis Madda Domain's	AAF User blacks				Death				

Figure 15-1: ACEmanager: Admin > Change Password

To change the default password:

1. Select the User Name associated with the password you want to change: user or sconsole.

(To create an AAF user password, see AAF User Password on page 370.)

- 2. Enter the old password.
- 3. Enter the new password twice.

The new password must be 8 to 32 characters long and can contain a mixture of letters, numbers, and/or special characters. The password is case sensitive.

Note: If the password is lost, the only way to recover access to the AirLink gateway is to press the hardware Reset button to reset all device settings to factory default. After resetting to factory defaults, the user password will be reset to the default password. If the gateway supports unique default passwords, the default password will be printed on the device label. Note that using the Reset button also resets the M3DA password to the default password.

To reset all settings to factory default, press the hardware Reset button for between 7 and 20 seconds (release the button when the Power LED flashes red).

If the Reset button has been disabled (using the Reset Button Configuration field on the Admin > Advanced screen) prior to the password being lost, the only way to recover access to the AirLink gateway is through AirLink Management Services, for which an account is required.

4. Click Change Password.

If you want to confirm that the password has been changed, log out and then log in with the new password.

AAF User Password

An AAF user password is required if you want to use ALEOS Application Framework (AAF) to develop your own applications to run inside an AirLink gateway. This password is used when installing an AAF application from DevStudio onto the gateway.

To enter an AAF user password:

- 1. In ACEmanager, go to Admin > Change Password.
- 2. From the User Name drop-down menu, select AAF user.

elanderikan, kantar 1991	The second se	Mervices 2 Location 2 Event	s Reporting 🗧 Serial	ETTER ETTER	Advan
Sampa Parament	- Charge Passent				
laboration of the second se	VERMING Devices configured with an A main in a plote subattle for production as	AF user are not isolable for production is, herein the AFF user using the ballo	use. The AMF user should r berow	uniji be ubechte kaf lievetopm	ed facette per
faile from		Distances of the second	Mar v		
Configurat Laggrag		Sector Planning 1	Change Ferrenzel		
Nario Long	() ANT UNIT THREE				
Salis Stellus Firman's	ANF User Status		Dearer		

Figure 15-2: ACEmanager > Change Password (AAF user)

3. Enter the new password twice and click Change Password.

The password can be 4 to 100 characters long and can contain a mixture of letters, numbers, and/or special characters. The password is case sensitive.

4. Reboot the gateway.

For more information on using ALEOS Application Framework, see page 358.

Advanced

The Advanced screen presents features that should be rarely changed and will affect the operation of the device.

simplements fillenting	1176	State State	-				
		Bault County	_				
Charge Passant	#T Carls and Turse	07/05/0400 01-10-14					
Advanced.	Cause Labora	O dates, D Rossen, 12 Holyadan					
finant.	41 titleuk Lipidale Activery	0.0.0.00					
	#1 Data Upmak Parted (accord)	0					
Faato here	47 Power land inflage (velts)	44					
time :	** Board Temperature (Celence)	2					
Conference on the	M. Nado Molan Mental Temperature (Calibra)	28					
	Number of ours Surges present						
Hermidia Lulgarroy	Deventual Care Durige	Formerinand Care Design	Firmmond Care Design				
Name Logi	tait temper Disable	28 b					
Radio Bachelo Commune	Minimum 70,8 Vestaur	THERE W.					
PERCHARGE TERMINE	PH0	[194]					
	# LogPre	#FLiggmid					
	Ellenind Active	Emerated Arctimet					
	Cooperate atteit access	(deate or)					

Figure 15-3: ACEmanager: Admin > Advanced

Field	Description
General	
Date and Time	 Queries the internal clock. The date and time are always specified in 24-hour notation (UTC). mm/dd/yyyy=date in month/day/year notation hh:mm:ss=time in 24-hour notation
Device Uptime	Length of time since the gateway was last rebooted (in days, hours and minutes)
Status Update Address	Enter the device Name/Port. Name is the domain name or IP address, and Port is the port of the device where the device status updates (in XML format) will be sent. This report can be sent to a LAN connected device (e.g., 192.168.13.100/1122) or a remote location (e.g., newb.eairlink.com/17000).
Status Update Period (seconds)	The time interval (in seconds) when a status update should be sent
Power Input Voltage (volts)	Displays the power input voltage in volts. If the input voltage ground is connected to the AirLink gateway case (without serial connection), this value reads .3 V (approx.) less; if ground is connected (with serial connection), the value reads .3 V (approx.) more.
Board Temperature (Celsius)	Displays the board temperature in degrees (Celsius)
Radio Module Internal Temperature (Celsius)	Displays the temperature of the internal radio module in degrees (Celsius).

Field	Description
Number of core dumps present	Shows the number of core dumps stored on the system A core dump is produced if a software component on the gateway crashes, leading to a restart of the component or reboot of the system.
Download Core Dumps	 As part of the troubleshooting process, you may be asked to download the core dumps and send them to Sierra Wireless or your distributor. If asked to do so: 1. Click the Download Core Dumps button. The following window appears.
	Download Core Dumps Close Generate Core Dump Package Keep were dang package on device after download
	 If you are instructed to do so by Sierra Wireless Tech Support, select the check box beside "Keep core dump package on device after download". Otherwise, leave the check box unselected.
	3. Click Generate Core Dump Package. Download Core Dumps Close Generate Core Dump Package Keep core dump package on device after download
	Successfully Generated Core Dump Package Covenkad Core Dump Package Once you see the message that the Core Dump Package has been successfully generated click Download Core Dump Package select Save File and click OK
	generated, click Download Core Dump Package, select Save File and click OK.
	Severil Compose, MRETER, MARTINA Ager which instage File (MELTER, MARTINA Ager which instage File (MELTER, MELTER, MELTER

Field	Description			
NAT Helper Disable	 The NAT helper functions are used to parse traffic on well-known protocols/port combinations. In most cases, leave the default setting. However, if you are running a protocol on one of the well-known port that is not normally associated with that port, traffic may not be parsed properly, or may be dropped completely. In that case, use this field to disable the NAT helper functions. The NAT helper functions are used to enable IP services that create temporary TCP or UDP ports. For example, FTP (TCP 21), SIP (UDP 5060) and SNMP (UDP 161). If you are running non-standard protocols on these ports, you may need to disable the NAT helper functions are used to enable IP services that create temporary TCP or UDP ports. For example, FTP (TCP 21), SIP (UDP 5060) and SNMP (UDP 161). If you are running non-standard protocols on these ports, you may need to disable the NAT helper functions are used to enable IP services that create temporary TCP or UDP ports. For example, FTP (TCP 21), SIP (UDP 5060) and SNMP (UDP 161). If you are running non-standard protocols on ports that use the NAT helper functions, you may need to disable the NAT helper functions in order for the firewall to operate. Options are: Off—NAT helper functions are operational (default) 			
	On—NAT helper functions are disabled. Sets the minimum TLS version that can be used for secure connections. When set to TLS			
Minimum TLS Version	 Sets the minimum TLS version that can be used for secure connections, when set to TLS 1.3, for example, connection attempts using a lower version will be blocked. By default (when set to TLS 1.0) the RV55 will make outbound connection attempts using the most secure layer (TLS 1.3) and fall back to other layers if the remote host does not support it. Options are: TLS 1.0 (default) TLS 1.1 TLS 1.2 TLS 1.3 			
Ping	Use this button to confirm that a connected device is responding. 1. Click Ping. 2. In the pop-up window, enter the device IP address or DNS name and click Ping Now. Figs Clust Hind IPIENS : 05216010.51 Image for the figst of the figst o			

Field	Description
IP Logging	IP Logging is used to troubleshoot issues such as:
	 Problems with the LAN or WAN connection to an AirLink gateway
	Uncertainty about where a packet is coming from
	 Issues with port forwarding not working properly
	IP Logging enables you to log network traffic and save it in a form that can be analyzed b Sierra Wireless engineers. Before using IP Logging, contact your authorized AirLink reseller or Sierra Wireless representative to discuss the issue you are observing and obtai a .cmd file to capture the appropriate related IP traffic. When you receive the file, save it to your computer's hard drive.
	To use IP logging:
	1. Obtain a command (.cmd) file from Sierra Wireless.
	2. In ACEmanager, go to Admin > Advanced and click IP Logging.
	 In the pop-up window, click Browse and navigate to the command file you received from Sierra Wireless.
	4. Click Open.
	The file name appears in the field beside the Browse button.
	IP Logging <u>Close</u>
	Select your IP logging command file (eg. iplogging cmd): Browse IPlogger_sample.cmd Upload File
	5. Click Upload File.

Field	Description
IP Logging (continued)	6. Once you see a message at the bottom of the window saying that the file has been successfully uploaded, select a command from the drop-down menu, as advised by your support contact. Image: Cost and Cost an
	7. Click the Start button. <i>Note: If you are running more than one command, run each command sequentially and</i>
	save the results before selecting the next command to run. Running a new command or re- running the same command wipes out the results from the previous run.
	When the logging is complete, the log shows the number of packets captured, received, and dropped.
	Note: If the log shows only "Got 0", no logs were captured. Contact Sierra Wireless.

Field	Description			
IP Logging (continued)	IP Legging		Close	
(,	Select your IP logging current file (Browner, F*logger_semp		Tapacad Pile	
	topdurip -wireUG any	×.	Clark.	
	Luce 577 Get 587 Out 588 Get 658 Get 658 Get 659 Get 650 Get 650 Get 650 Get 750 Get 714 Get 756 Get 7		nload IP Logging File button at the I	ootto

Field	Description		
Extended Archiver	 Extended Archiver is a troubleshooting tool that enables you to collect logs covering an extended period of time. Before using it, contact your authorized AirLink reseller or Sierra Wireless representative to discuss the problem. To start the process: Click Extended Archiver. Select the following options, as advised by Sierra Wireless: The number of times to run the archiver (1–25; default is 16) The interval between runs (30 minutes, 1 hour, 1.5 hours, 2 hours, 2.5 hours, 3 hours, 3.5 hours, 4 hours, 4.5 hours, 5 hours, 5.5 hours, 6 hours, or 6.5 hours; default is 1.5 hours) 		
	Extended Archiver Close Number of times to run the Archiver. 15 • Time interval between each run: 15 Hauss • Start Start		
	 Click Start. Click Start. The Extended Archiver saves the current set of logs. It waits for the configured interval and then collects another set of logs, which are saved to the same file. This process continues for the number of times the Archiver is configured to run. 		
	At any time, you can click Save Archive. The logs collected to that point are saved and the process continues. Extended Archiver Close		
	Number of times to run the Archiver. 16 • Time Interval between each run: 1.5 House • Extended Archiver is in progress Stop Save Archive Save Archive		
	 Once the process is complete, click Save Archive, save the tarred gzip file (file extension .tgz) to your computer, and email it to your support contact. 		
	 Stopping and Restarting the Extended Archiver After you click the Start button, it changes to Stop. To stop the process: Click Save Archive if you want to save the logs already collected. Click Stop. Logs not already saved will be lost. If desired, you can change the settings and restart the process. 		
	Note: The Extended Archiver settings and the collected logs persist over reboots. Once the reboot is complete, the process resumes.		
Diagnostic shell access	When enabled, this field allows Sierra Wireless Tech Support personnel to locally access the diagnostic shell on your gateway. It should be left at the default setting unless Sierra Wireless TechSupport asks you to change it.		

Reset

41 4 million 70,000 (10,00	hi mi			strengt of	Country (Country)
					_
Change Parconet	······································	92			
Advanced	Periods: Radical Timer (hours)	0			
Annual .	Time of Day (Tell) Reboot Result planar (Auto)	0			
Acres 1	Tel: the seat Tane Zane Office them until	1			
Rate Tiots	Told Report insur of the when Report scours	(i)			
Log	www.mic Petterseg a filoarto Factor Detaut configured as	"Name" will arrange all planters or publication	etter an		
	ell Hererto Factory Datasit	Report to College Instan	3		
Configura (pipping	# Receit Carligeration	Presence Care Selfage			
Remote Loging	M Rest Butter Configuration	Name Add	- Q		
Week Long					
Natio Modulo Fremenico					

Figure 15-4: ACEmanager > Admin > Reset

Field	Description
Number of System Reboots	Count of the number of system reboots over the life of the device or since the last device reboot
Periodic Reboot	Reboots the gateway after the specified number of hours.
Timer (hours)	0 = Disabled
Time of Day (ToD)	Number of days between reboots
Reboot: Reboot	0 = Disabled
Interval (days)	Example: If this field is set to 3, the gateway reboots every third day.
ToD Reboot: Time	Time zone adjustment (Offset in easterly direction from UTC Time)
Zone Offset from	Possible values are -1212
UTC	Example: Pacific Standard Time would be -7

Field	Description		
ToD Reboot: Hour of day when Reboot occurs	The local hour of the day when the reboot occurs Possible values are 0–23 Example: 4 is 4:00 am		
Reset to Factory Default	Resets the RV55 and its settings according to the Reset Configuration (see Reset Configuration on page 380. After clicking Reset to Factory Default, a confirmation message indicates which settings are affected as part of the reset. And you sum you want to Nexet to Factory defaults? Only core settings will be preserved CR Cancel		
Note: After resetting the device to full factory defaults (the Reset Configuration Reset All or Preserve Only User Password), if you are using a management so ALMS or AMM, Sierra Wireless recommends synchronizing the device again management service. The re-synchronization enables the management tunne establish itself.			

Reset Configuration The Reset Configuration lets you select how the ACEmanager Reset to Factory Default button behaves. The different options determine the types of settings that are preserved after the RVS5 resets. Options are: • Reset All—All settings, including network settings and passwords, are returned to the factory default values on Reset to Factory Default. After clicking Reset to Factory Default, a confirming that you want to continue, a warning appears, notifying you that passwords will be reset. • Preserve Only User Password—All settings except the ACEmanager (user) password are returned to the factory default values on Reset to Factory Default. • Preserve Only User Password—All settings except the ACEmanager (user) password are returned to the factory default values on Reset to Factory Default. • Preserve Only User Password—All settings except the ACEmanager (user) password are returned to the factory default values on Reset to Factory Default. • Preserve Core Settings—(default) Setting the Reset Configuration to Preserve Core Settings preserves some predetermined settings that are preserved after a Reset to Factory Default. • User Password • Watwork Nuser ID (SIM 1, SIM 2 and R2C eSIM) • Network Vuser ID (SIM 1, SIM 2 and R2C eSIM) • Network Authentication Mode (SIM 1, SIM 2 and R2C eSIM) • APN Type (SIM 1, SIM 2 and R2C eSIM) • Select from the List (APN value) (SIM 1, SIM 2 and R2C eSIM) • Settory Detwork Authentication Mode (SIM 1, SIM 2 and R2C eSIM) • Backup Network Authentication Mode (SIM 1, SIM 2 and R2C eSIM) • Backup Network Ox U
 LTE Cat-M1 Operation LTE NB-IOT Operation ALMS Enabled/Disabled status ALMS Name (Device name in ALMS) ALMS Device Initiated Interval

Field	Description
Reset Configuration (continued)	 ALMS LWM2M Keep Alive Interval ALMS LWM2M Register On Startup HTTP Server and ACEview Services Reset Mode Network Operator Switching Enabled/Disabled Default radio module firmware carrier ACEmanager Remote Access Low Voltage Standby Mode Standby Qualification Period (seconds) Standby Voltage (100 milliVolts)
	 Resume Immediately at Voltage (100 milliVolts) Ethernet Mode (Port 2) Ethernet WAN Mode (Port 2) Static WAN IP (Port 2) Static WAN Netmask (Port 2) Static WAN Gateway (Port 2) Static WAN DNS1 (Port 2) Static WAN DNS1 (Port 2) Static WAN DNS2 (Port 2) Reset to Custom Configuration—Allows you to reset the device to a custom configuration file, with the option to preserve AAF Apps. For more information, see Reset to Custom Configuration on page 382.
Reset Button Configuration	 Configures the functionality of the hardware Reset button. When not set to Disabled, pressing the hardware Reset button for 7–20 seconds reboots the RV55 and resets it according to the selected Reset button configuration. (When resetting the device to its reset configuration, release the Reset button when the power LED flashes red.) Disabled—Pressing the hardware Reset button reboots the RV55, but does not reset any of its settings. Reset All—All settings, including network settings and passwords, are returned to the factory default values. Preserve Core Settings—(default) Setting the Reset Button Configuration to Preserve Core Settings preserves some predetermined settings that enable the RV55 to stay online after a Reset to Factory Default (for a list of settings, see Reset Configuration on page 380). Reset to Custom Configuration—Allows you to reset the device to a custom configuration, with the option to preserve AAF Apps. For more information, see Reset to Custom Configuration on page 382.
	Note: This field only affects the hardware Reset button on the device. You can always use the "Reset to Factory Default" button in ACEmanager to reset the device. Note: If this field is set to "Reset All" and the default login password is subsequently lost, the only way to regain access to the AirLink gateway is through AirLink Management Service (account required).

Reset to Custom Configuration

The Reset Configuration and Reset Button Configuration settings have an option for Reset to Custom Configuration. The Reset to Custom Configuration option allows you to use the Reset to Factory Default button (either in ACEmanager or using the hardware Reset button) to reset the RV55 to a reset configuration stored on the device. The reset configuration can be either a template (see Saving a Custom Configuration as a Template on page 20) or a database backup uploaded to the device or generated by the device and saved as the reset configuration.

Setting the Reset Configuration and Reset Button Configuration to Preserve Core Settings preserves some predetermined settings that enable the RV55 to stay online after a reset to factory default. Setting the Reset Configuration to Reset to Custom Configuration allows the full configuration of a working router to be preserved.

The additional settings for configuring the Custom Reset settings are shown in Figure 15-5.

MT Reset Conliguistion	Preserve Core Settings 🛛 🗸
All Resel Button Configuration	React to Caston Configuration - M
Configure Custom Reset	Configure Custom Reset
AT Create Custom Reset Contiguation on next both	Noodie 🗠
Preserve AAF Apps	Deadle M
Receil Conliguistion Name	My Costom Receillemptate

Figure 15-5: Custom Reset Configuration settings

The additional settings are:

- Configure Custom Reset—Click this button to add a custom reset configuration file to the non-volatile memory of the RV55 (see the procedure below).
- Create Custom Reset Configuration on next boot—Enable the RV55 to back up its configuration the next time it reboots. This creates a "restore point" that the RV55 uses for Reset to Factory Default when the Reset Configuration is set to Reset to Custom Configuration.

Note: Sierra Wireless recommends using this method, as it is the easiest way to create a reset configuration.

 Preserve AAF Apps—Set to Enable to preserve AAF applications on the RV55 during a reset to custom configuration.

Note: Because user passwords are not stored in device configuration files, user passwords are reset to default after resetting the RV55 to a custom configuration. Please ensure you change the default passwords afterwards.

The Reset Configuration Name (shown as a status field in Figure 15-5) appears after you have uploaded a custom reset configuration file.

To upload a custom reset configuration file:

 Click Configure Custom Reset. The Reset Configuration screen appears.

Reset Configuration	Close
Upload Reset Configuration	
Browse No file selected.	Upload
Download Reset Configuration	
Current Reset Configuration File:	
	Download

Figure 15-6: Reset Configuration screen

- **2.** Click Browse... to locate your file, and then click Open. The file can either be a template or custom reset configuration backup file.
- 3. Click Upload.

The custom reset configuration file uploads to your device and the file name appears on the Reset Configuration screen and the Reset Configuration Name field shown in Figure 15-5.

Radio Tools

tatus WEAKCellular B	VPI LES VPN Becump Services Lo	alon Events Reporting Satur Approations 1/2 Advan				
er antere (transfer 2 (transfer 2 (tr	(E.P.W.	Electric Front Electric (Con-				
Change Parament						
	10 General					
Advance)	The second					
Recent	straid only be pointed if you are proposally converted in Parallele model and all const in proposally read for their	is device the Radii Paudhuu mude which will encours all reprode actions is the device. This suffice the device, and should not be sensibled if you are accessing the device rememby Onco in Radio to observate presents the fixed balls, on the basis of the sense in some to get basis to thermal				
Tardin Tardin	Minde					
	Audo Pasitina	Radio Facebra				
ALC: NO	Radio Minlano Desag Mermathan	Paulos Radius Debug information				
Configured Longong	Washin Manhala Aylineey	Wanter Westmite in Survey				
	AT Pado Robre Los Tower Handing	45000 Herman Reference V				
Revision Langeing	Alther Outbrand Default Traffic	bare v				
Marine Lines	1 Marti Dogrocht Sellings					
Radio Medulo Firmeneo	production of the second se					
	Veramers. Custom band settings should unly be enable certification, advectate effect service and to not recomment	I for disprotely purposed. Excluding or swatching table bands may imakilate network operation of for general loss				
	Bands Avetable					
	Centerd Grahted Custom Radio Bande					
	Bild Bolt 1 Casture Band Setting Mode	Date v				
	1994 Skiel J Cautom Band Setting Wode	Charles M				

Figure 15-7: ACEmanager > Advanced > Radio Tools

Field	Description
General	
Radio Passthru	See Radio Passthru on page 386.
Radio Module Debug Information	For radio module debug information:1. Click the Radio Module Debug Information button. The following screen appears:
	Refresh Now Close
	2. Click Refresh Now.
	Radio Module Debug Information Close Refresh Now AFI Manufacturer: Sierra Wireless, Incorporated Medel: SC7455 Mevision: SWISK200_01.08.07.00 I3713 CANND-EV-FRMAK2 2015/08/13 23:07:36 MEID: S5907206000375 MEN: I2802769576, 802A12A8 INFI: S59072060003759 INFI: S59072060003759 INFI: S5907400430402 +OCAP: +CC80
	OK ATICSTATOS: ICSTATOS: Carrent Vinc: S9Temperature: 20 Sectup Time: OMede: ONLINE System mode: LDE PS state: Attached LTE band: B7 LTE bw: 20 MHz LTE band: B7 LTE bw: 20 MHz LTE two chain: 3050LDE Twochain: 21050 LTE CA state: INACTIVE EXH state: INACTIVE EXH state: INCCommeted INE state: INC Commeted INE state: No Siv PCC Ham HSSI: -76HERP (dEm): -101 PCC HAM HSSI: -76HERP (dEm): -120 Var Force: OVAC: 8980 (35200) HSHQ (dE): -70011 ID: 015FADOS (23047433) SIRM (dE): 20.2
	σĸ

Field	Description
Radio Module Actions	This feature only applies to radio modules running on the Sprint Network. Use this button only if advised to do so by Sprint representative.1. Click the Radio Module Actions button.
	Radio Module Actions Close
	C RTN Reset D Update PRI C Update Data Porite Perform Action
	 2. Select the desired option: RTN Reset—Resets the radio module to pre-activated state
	Update PRL—Updates the Preferred Roaming List
	Update Data Profile—Updates the data profile
	3. Click Perform Action.
Radio Module Low Power Handling	 Controls how ALEOS handles device operation when the radio module is in Low Power mode. This feature is intended for testing and diagnostic purposes, not as part of normal device operation. Options are: ALEOS Normal Behavior (default) ALEOS does nothing
Allow Outbound Cellular Traffic	 Enables or disables outgoing traffic on the cellular interface. This feature is intended for testing and diagnostic purposes, not as part of normal device operation. Options are: Enable (default) Disable
Band Diagnostic Settin	lgs
Sierra Wireless or your servi	are intended for diagnostic purposes and should only be modified under the guidance of ice provider. Excluding or restricting radio bands may invalidate network operator certifi- ice and is not recommended for general use.
The Diagnostic Settings allo RV55 to using the bands you	w you to select which bands to use, either by excluding certain bands, or by restricting the u specify.
Note: Specifying settings for settings on the WAN/Cellula	r Band 26 and/or Band 41 in the Diagnostic Settings overrides the Band 26 and Band 41 r tab (see page 91).
Bands Available	Available radio bands based on the selected Setting for Band. See WAN/Cellular > Cellular > General > Band Setting on page 91 and Setting for Band on page 567.
Current Enabled Custom Radio Bands	 This status field displays the custom band settings for the active SIM card. Not Enabled—Custom band setting mode is disabled. All bands excluding bands [x, y]—Bands affected when the mode is set to Exclude.
	 Bands restricted to [x, y]—Bands affected when the mode is set to Restrict.

Field	Description
SIM Slot 1 Custom Band Setting Mode	 Select the type of custom band settings for SIM slot 1. Options are: Disable (default) Exclude—Exclude specified bands from operating. After selecting Exclude, an Exclude Bands field appears, in which you can enter a comma-separated list of bands. Restrict—Limit the RV55 to using specified bands. After selecting Restrict, a Restrict Bands field appears, in which you can enter a comma-separated list of bands.
SIM Slot 2 Custom Band Setting Mode	 Select the type of custom band settings for SIM slot 2. Options are: Disable (default) Exclude—Exclude specified bands from operating. After selecting Exclude, an Exclude Bands field appears, in which you can enter a comma-separated list of bands. Restrict—Limit the RV55 to using specified bands. After selecting Restrict, a Restrict Bands field appears, in which you can enter a comma-separated list of bands.
R2C eSIM Custom Band Setting Mode	 Select the type of custom band settings for the R2C eSIM (if enabled). Options are: Disable (default) Exclude—Exclude specified bands from operating. After selecting Exclude, an Exclude Bands field appears, in which you can enter a comma-separated list of bands. Restrict—Limit the RV55 to using specified bands. After selecting Restrict, a Restrict Bands field appears, in which you can enter a comma-separated list of bands.

Radio Passthru

Radio Passthru allows a direct connection, using USB, to the internal radio. Normal cellular radio operation is suspended while Radio Passthru is enabled.

Radio Passthru is generally used only in certain troubleshooting scenarios.

The hardware bypass remains in effect until the gateway is rebooted.

Note: Because Radio Passthru is not USB/net or USB/serial, a different set of drivers is required to connect to the radio installed inside an AirLink gateway. Additionally, while it is possible to send AT commands to the radio using a terminal connection, there are software applications designed to communicate with the radio directly. If you need to use Radio Passthru, contact your Sierra Wireless AirLink representative to obtain the needed drivers and/or software application.

To start and end a Radio Passthru session:

- 1. Connect your computer to the gateway through the gateway USB port.
- 2. Ensure the Network Watchdog and Cellular Watchdog are disabled to prevent the gateway rebooting while in Radio Passthru mode. See Network Watchdog on page 77 and Cellular Watchdog on page 91.
- 3. Reboot the gateway.
- 4. On the Admin > Radio Tools page, click Radio Passthru.
- 5. To finish the Radio Passthru session, reboot the gateway.

Log

The Log file is a system log of the AirLink RV55.

The Logging configuration screen enables you to configure log verbosity and display filtering. The View Log screen enables you to view and save logs. The logs are in plain text.

You can configure logging for every major router function, as well as for activity on the following interfaces:

- RS232 Serial
- USB Serial (only available when configured to use AT mode for USB Serial. See USB Device Mode and USB Serial Mode on page 157.)
- Wi-Fi (only available for Wi-Fi models)

Configure Logs

To configure what you want to include in the logs:

1. In ACEmanager, go to Admin > Log.

11 (1 (1 (1 (1 (1 (1 (1 (1 (1	od ma	Eleventity (mendlement)						
		Resources and the second second	state transmit throat terminal terms					
Champe Plazoment	Logare							
Advanced .	Sub System	Venturity	Singalog on Long?					
Amuel	Calhda	Tonice	(998.391)					
	LHE	None (w	Tas w					
Radia: Tanta	VPN	Notice 1	(144					
	Searth	hits	(19.14)					
Configure Longitu	Berites.	Toma Y	1946 (47)					
Servery Linguistic	Events ReportingLandon	NEW Y	(108.14)					
	Apple plane	tutue w	100 -					
View Land	34	Inite ((ins. in)					
Ratto Modulo Firmenario	44.940	Inter V	las. w					
	1000	Inter I v	(16.9)					
	fisilem	hater of	799. 4					
	Helenit Device	Inter-w	(100 W)					
	Sofware and Fernance Update	hite w	1799.191					
	Vois	term v	(100.14)					
	Convection Operage ment	(hates	(http://t.)					
	Lab Wanggiment	Name w	(Ver 9)					
	Logging Mitchaiu							
	Sub System	Vertiensity	Bingstop in Long?					
	PERSONAL PROPERTY AND INCOME.	Taker, w	299.30					
	Logging (Musicia)							
	Lab Against	Verbandg	Simpley in Log?					
	nih	lone v	Tee w					
	Linux Dutting	(Nilbury, M)						

Figure 15-8: ACEmanager: Admin > Log > Configure Logging

- **2.** For each subsystem listed:
 - **a.** Select whether or not to display it in the log.

Separate filters, based on subsystem and severity, are applied when the messages are generated and when the messages are displayed. The following severity levels are supported for filtering in the drop-down lists for verbosity:

- Error
- Warning
- · Notice (default)
- · Info (information)
- · Debug
- **b.** Select the verbosity level.

Note: Some log messages are only displayed if you display Linux Syslog. For example, If you are debugging a VPN or LAN setup, the relevant information is only displayed in the Linux Syslog.

- 3. Optional: To display Linux Syslog in the View Logs screen:
 - a. Ensure that Display is selected in the drop-down menu beside Linux Syslog.

Day day.

Time sympt

Note: At any point, you can click the buttons on the upper right portion of the screen to:

- Download logs to your computer
- Download a compressed version of the logs to your computer
- Refresh the screen
- Cancel the selected settings
- Return the screen to the Default settings.
- 4. Click Apply.
- 5. If you have changed any of the verbosity levels or the Linux syslog setting:
 - a. Reboot the AirLink gateway.
 - **b.** Log into ACEmanager, go to Admin > Log.

Trace Level Logging

Use this option only if you are specifically asked to do so by Sierra Wireless or an authorized distributor.

To enable trace level logging:

1. In the Trace level logging field at the bottom of the page, select Enable.

Trace level logging

brubic i y

- 2. Click Apply.
- **3.** On the left menu, click View Log.

Remote Logging

Remote logging enables you to send logs to a remote server.

To configure remote logging¹:

- 1. In ACEmanager, go to Admin and from the menu on the left, select Remote Logging.
- 2. In the Remote Syslog field, select Enable.

Manua materialar Bos		eaters Events Reporting Doub Sama Applications 40 Appen
1.00 (additional "Internet of 17)	115	Tourist Constitution (and State)
Ounge Parenett	Renate Statig	tan v
Amazart	Samp Farriel	49
	Tupthe Protocol	(sec.9)
Name Turns	late	
Anamic Turks	2	514
top.		
Configure Lossenia		
Constants		
Time I vit		
Name Roman Concern		

Figure 15-9: ACEmanager: Admin > Remote Logging (enabled)

- 3. In the Syslog Format field, select either:
 - · IETF (default)
 - BSD
- 4. In the Transfer Protocol field, select either:
 - · UDP (default)
 - TCP

If you select TCP, you'll be given encryption options.

- 5. In the Server field, enter the IP address of the remote server you want the logs to go to.
- 6. In the Port field, enter the server port number. Default is 514.
- If you select TCP in the Transfer Protocol field, you'll be given the option to enable TLS Encryption and then to enable Client Authentication and/or Verify Peer Certificate.

^{1.} You can also use an AT command to configure remote logging. See *REMOTELOG on page 555.

of the production of the local distance of the	15.50	[Trend of Concentration (And)	
Samp Page mill	Renate Systep	(hate w)	
American	Salafana	(10 - +)	
	Transfectiveness	328 9	
fer tout.	lace .		
tam have	m	514	
ing (Monghole	15 v	
-	Out information	(Inter., w)	
Configure Leaserin	Last Cherry Prove Page	Street Classes Presently New 2	
Report Landson	Chief Photo Ray Remark		
Burnette Longiture	Last Cheve Cartellate	Charl Street Statements	
from 1 day	cover Centrale name		
Name Bachara Photosowa	Welly Please California	(been (w)	
NAME BACKIE FEMILIARE	Last Tuateg CA Defilium	Loss Provid LA Cardinan	

- **8.** Click the appropriate red button to:
 - · Load a Client Private Key.
 - · Load a Client Certificate.
 - Load a server Trusted CA Certificate.

Once it is uploaded the file name appears on the screen.

Note: When enabled, this functionality persists over a reboot/power cycle.

View Logs

To view the logs:

1. Select View Logs from the menu on the left side of the page.

	al law	interest in the second s		the summer of	
	917 ·	Contractions (Second	111-1		
Damps Parenter					
	Last quantizative, we will be the	Advision 1997	Balling S Deer	and a	
Side and					a
u and	Old III 23:21 44 earning ALEOS_ALMS_SWW2M_Content Old 22:23:21 44 earling ALEOS_ALMS_SWW2M_Contents				
Concern and the second s	Orit 22 23 21 44 er ALEOR AUM UTWOM resolve fats Orit 22 23 21 44 er ALEOR AUM UTWOM fated tricter				
adle Tasky	Del 22 23/21 44 set ALEON_ALMS_LHM2N_Need to con	eect to heathing server			
	Ort 22 23:21 44 element ALEOS ALMS, UNIVER Faller Ort 22 23:21 44 element ALEOS ALMS, UNIVER Faller				
	Did SE 20:21 44 warning ALEOS_ALMS_UWW2N_spanns	Restart reviait alloweds in progr			
Contractor & country	OI3 22 25 27 31 minting ALEOS_ALMS_LIMMON_Connel OI2 22 25 27 91 notice NLEOS_ALMS_COMON_Connelth				
	Oct 22 23:27 91 en ALECII ACMI LINADA recover tall Oct 22 23:27 91 en ALECII ALMI LINADA failed to con				
Records Langered	Oct 22 23 27 01 ert ALEOS, ALMS, CAMON Reled to con	ment to boolisihas server.			
View Line	Oct 22 20:27 81 warning ALEOS ALMS UMM2N Falled Oct 22 23:27 81 warning ALEOS ALMS UMM2N Falled	booferoup. retrying in 147 second booferoup, retrying in 167 second	ods. 7 kft		
	Oct 22 23 37 91 warning ALEOS_ALMS_LIVM2N_spared	Resiliant revolut already in progr	1018		
alter Minholte Pitresandere	Oct 22 23 31 18 notice ALEOS_UNMONT_Internor. Cur Oct 23 23 12 47 mining ALEOS_ALMS_LOWARM Column		State-140 States		
	Oct 22 27 32 47 relice & 500 AMB UMENT connects Oct 22 23 32 47 en 4LEOS AUES LEM2H residue fais	eg til tvi. almærlage (valt 5664			
	Okt 22 23 32 47 etr ALEOS_ALMS_UNM2M_famid to con	vect to be arvariage init 5654			
	Oct 22 33:32 47 err ALEOS AUMS, UNV2N failed to col Oct 22 23:32 47 earning ALEOS AUMS, UNV2N Failed		the C size		
	Oct 22 23 52 47 warring ALEOS_ALMS_UNM2N: Failed	ob of the prvitorr, partitiood			
	OKI 20 23:52.47 minting ALEOS_ALMS_LIMM2M_spatiet	Restart, restart already in progr	1000		
	Ox1 02 23 16 19 Jillet ALEOS SYSTEM				-

Figure 15-10: ACEmanager: Admin > Log, View Log (AirLink RV55 shown)


Note: VPN info and debug information uses the term racoon (rather than VPN).

Note: If you toggle the "Display in Log?" field, clear and refresh the View Log page. (You do not need to reboot the device.)

Tip: Use View Log for troubleshooting purposes (e.g., when setting up the IPsec configuration). The Log page allows you to establish the tunnel connection and monitor the results directly. To change the intervals at which the log is displayed, you can change the settings in Auto Refresh.

Actions on the View Log screen include:

- Auto Refresh—The drop-down menu allows you to set up an automatic log page refresh, and the interval between refreshes: 30 secs, 1 minute, or 2 minutes.
- Refresh button—Clears the screen, reloads the log file, and display the point in the log file you were viewing immediately prior to clicking Refresh. Any new log information is added to the bottom of the log.
- Clear button—Clears the screen
- Mark button—Marks the start of a section in the device log and is typically used for troubleshooting
- Download Logs button—downloads the logs to your computer
- The Download Compressed Logs button—downloads a compressed version of the logs.



Note: The logs you obtain using the Download Logs or the Download Compressed Logs buttons always include the Linux Syslog. The Linux Syslog setting on the Configure Logs page does not affect the contents of the downloaded logs.

If asked to do so:

- 1. Click the Mark button and enter the text you want to appear in the log file.
 - Alphanumeric characters, spaces, periods, commas, dashes, colons and semi-colons are allowed.

Mare	Cinse
Text: Begin configuration char	Mark How

- 2. Click Mark Now.
- 3. Click Refresh.

The mark appears at the end of the log.

11 pp. 100 (11/1) - 11/11/2010 (11/1)	COPPE 2					-	-	385
Junge Pantement								
	(D) Garrent P	dering fige						
harry of	7.0+			EMITTI				
-	fillbourn ()	ipetatot:		GENERC.				
the Tranta	Abrowant.	-		terminor, price	ina no manhata	eine otte	W21214811	
	2011/07/07	CT and Marston						
		TID and Version		9907259 GENER		0		
and good & suggress	(S)Parmana	n an		Anno Anno Anno Anno Anno Anno Anno Anno				
Recent Lights	in first	Beinruck Case and	Second .		The Ton Addance		dame.	
(the integration of the integrat		ALT	"01.07.02.00_ATT_002.000_002"		100	Manager 1	Country of	(Change)
		MARK	101.00.04.00_OENERIC_002.012_000	9 C	1985	Married Woman	1	filmer.
me House Commons		WHITE A	101 26 54 59, VERIDON, 002 815, 000		50	Territor.	Courses of	1000
							111-22	-
	(1) Optimal							
	Helecon D	and when a		(148. v)				
	of Mrt. Sec.	to Molinia Formaria U	unitate .	Index Cornet of	2021			

Radio Module Firmware

Figure 15-12: ACEmanager: Admin > Radio Module Firmware

AirLink gateways come preloaded with multiple versions of radio module firmware (For details, see Table 15-1). When the RV55 is powered on, it checks the stored radio module firmware versions and automatically loads the appropriate version for the installed primary SIM card onto the radio module.

This feature, which is intended for North American products, makes it easy to provision the gateway for a particular mobile network. To provision the RV55:

- 1. Obtain an account and SIM card for the mobile network you want to run the RV55 on.
- 2. Insert the SIM card into the primary SIM card slot. (For instructions on installing the SIM card, refer to the RV55 Hardware User Guide.)
- **3.** Power on the RV55. It chooses the appropriate radio module firmware to use for the installed SIM card, provided it is stored on the RV55.

The following table indicates the pre-installed radio module firmware, based on the SKU:

Table 15-1: AirLink RV55 Pre-installed Radio Module Firmware based on SKU

SKU	Verizon Wireless	AT&T	Sprint	Generic	Telstra	Sierra	Bell
North America LTE	~	~		~		~	
North America LTE-A Pro	~	~	v	✓		~	~
APAC				~	~		
EMEA				~		>	

SKU	Verizon Wireless	AT&T	Sprint	Generic	Telstra	Sierra	Bell
Global	~	~		~	~	~	
Global LTE-M/NB-IOT	~	~		~			

Table 15-1: AirLink RV55 Pre-installed Radio Module Firmware based on SKU

If the appropriate firmware is not stored on the gateway, you can download it from source.sierrawireless.com and install it on the gateway. You can also:

- Check which version of radio module firmware is currently active
- Remove radio module firmware from the gateway
- Update the radio module firmware stored on the gateway
- Override the automatic function and manually select the radio module firmware to be used

Note: You can store a maximum of six radio module firmware versions on the gateway.

Note: If you select Preserve Cellular Authentication Settings in the Reset Configuration field before rebooting the gateway, the configuration and the stored radio module firmware are preserved when you reset the gateway to the factory default settings.

To manage radio module firmware:

1. In ACEmanager, go to Admin > Radio Module Firmware.

TEChernette							
1 I I I Charlenge In							
Tet			887519				
Network	antalar.		anese:				
Formation formation			WWW.000C_81.08.04.00-0008.00 (whites 201800821.21 #8.11				
SKU FRED and Version			9998373, 002 001				
Carrier PHI (Cand Writish			AMOTOSIA, GRINERAC, DEZ DITZ, SHI				
Third							
. I.L.							
and the second	Better P Operator	We want		Cates of all		Access 1	
	WITE:	"91.07.02.05_ATT_002.088_002"		865	Description	Sec. 1	and the second
	CENERIC.	101.08.04.00_GENERAC_002.012_00	0"	Tes	Lineses.	-	Sec. 2
	strends.	101.00.01.00_VERIDON_002.015_00	P	50	18.844	Batton .	£11.00
							(Sectors)
							2.1
[]]] Ignord							
Hitest C	and whether		Director Cold				
	Holeston Reveaue Saturent Canter PR Saturent Sat	Notest Operator Perseas Verses SAU POLID and Verses Career POLID and verses	Network Operator Network Writes Security PRI Di and Wester Cantor PRI Di and Wester Infference Cantor PRI Di and Wester Infference Cantor PRI Di and Wester Infference Cantor PRI Di and Wester Infference Infferen	National Operator Mathematic National Operator Mathematic National Operator Mathematic Statisfield and Weator Mathematic	National Operator National Operator National Operator Statement State PRI Di and Version Westerline, Doi: 100, 000, 000, 000, 000, 000, 000, 000	National Operator National Operator National Operator Statement State PRI D1 and Version WHERE C1 and Version	National Operator National Operator National Operator Science Operator Secure PRE Di and Wester Wester Operator Cannor PRE Di and Wester Wester Operator Information Wester Operator

Figure 15-13: ACEmanager: Admin > Radio Module Firmware

2. Use the information in the following table to install, update, or remove radio module firmware.

Field	Description					
Current Information						
Туре	Shows the gateway's radio module					
Network Operator	Shows the network operator associated with the radio module firmware					
Firmware Version	Shows the firmware version for the radio module firmware in use					
SKU PRI ID and Version	Shows the device Product Release Instructions ID number and hardware version. This ID specifies which radio modules the device supports, among other hardware parameters.					
Carrier PRI ID and Version	Shows the Carrier Product Release Instructions ID number and version. This ID determines the bands available for use by the carrier, among other radio module parameters.					
Firmware						
Active?	Indicates whether or not the radio module firmware is currently in use					
Network Operator	Indicates the Mobile Network Operator associated with the radio module firmware					
Version	Indicates the version number of the radio module firmware					
Up to date?	Indicates if the firmware in use matches the ALEOS-referenced radio module firmware					
Actions	 Action buttons beside each radio module firmware listed, enable you to: Update—Click to update the radio module firmware for that RMID. Updating the active radio module firmware updates the version in storage and also updates the firmware on the radio module at the next reboot. To reboot, click the Activate button or the reboot button on the top right side of the screen. Image free free free free free free free fr					
	 Install—Click to add an additional radio module firmware image to the gateway storage. When the maximum number of radio module firmware versions are stored on the gateway, the Install button is not available. To free up space to add another version, first remove one of the firmware versions on the gateway. 					

Field	Description
Network Operator Switching	 Enable or disable Network Operator Switching Enable—When the gateway powers on or reboots, it automatically selects and uses the appropriate radio module firmware for the installed primary SIM card, if it is stored on the gateway. If there is no SIM card installed in the primary SIM card slot, the gateway switches to the SIM card in the secondary SIM card slot. (default) Disable—The gateway does not automatically select the appropriate radio module firmware when it is powered on or rebooted. You can manually select the firmware to use. See Manually Selecting the Radio Module Firmware.
ALMS Radio Module Firmware Update	 Enables you to choose which radio module firmware ALMS will update when you update ALEOS: Update Current Only—Only the radio module firmware in use is updated, if required (default) Update All—All the radio module firmware stored on the gateway is updated, if required

Manually Selecting the Radio Module Firmware

To manually select the radio module firmware to use:

1. In ACEmanager, go to Admin > Radio Module Firmware.


Auguster and and	111.11199								-
							unitation of the	hund) Gree	and Ameri
Sunge Passenge									
	((Oatte	(selfermalise							
uhoes and	Type				697111				
iner in the second	in Philappi	Constant			GENERIC				
		ne Version				00.04 00 minhet	antini 2018.0	11-04-12 120	
latin Talifs		t D and Velace			9908373, F02.0				
14	0.00000	Carlie PR(E) and Version			MAITINA GENERAL DAZUTO ANA				
						100000			
Certain Loans	110mm	11							
Nortochi Litageng	Active?	Amount Care and				to to one?		Armen	
TWO INC		TTA		00_ATT_002.008_0	02 ⁻	ND.	(Instate)	Barrisse?	1.1.1.1.1
		OFHERIC	101.00.04	00_GENERIC_002.0	112_090*	Ves	(Lantana)	1	-
talic Budgle Processie		VERIOR	10105.04	00_VERIZON_002.0	15 000"	ND	Country of	Thursday.	-
				07702000.000					
									hale
	11/38	8							
	National	Operator Switching			State w				

Figure 15-14: ACEmanager: Admin > Radio Module Firmware

- 2. Under Options > Network Operator Switching, select Disable.
- 3. Under Firmware, click Activate beside the firmware you want the gateway to use.
- 4. Click Apply.
- 5. Click Reboot or press and release the reset button on the gateway.

A: Windows Dial-up Networking (DUN)

Dial-up Networking (DUN) enables you to use Point-to-Point Protocol (PPP) to establish a connection between a host PC serial port and the AirLink gateway.



Caution: To install any driver on your computer, you may need to be logged in as Administrator or have Administrator privileges for your login.

Microsoft Windows 7 is used in the examples below. The device driver installation and DUN setup and configuration is similar in other Microsoft Windows operating systems, including Windows XP and Windows CE.

Note: If your device is new, or has recently been reset to factory default settings, ensure that the device has been on air at least once before being used with a DUN connection.

Installing a Device Driver

Connect the AirLink gateway

- 1. Connect the device to the computer with a DB-9 cable from one RS-232 port to the other.
- 2. Log in to ACEmanager.
- **3.** Go to Serial > Port Configuration.
- 4. Set the DB9 Serial Echo field to Disable.
- 5. Reboot.

Note: You need to set the DB9 Serial Echo field echo to Disable any time you want to set up a PPP connection.

Install the driver

1. Select Start > Control Panel > Phone and Modem Options.

The listb location b	elow displays the locatio rom which you are dialing	ns you have specifi J	ed Selectifie
Location.		Area Co	de
Detuut			-
	New_	Edit.	Date:

Figure A-2: Phone and Modem Options

2. Select the Modems tab.




Figure A-3: Phone and Modem Options: devices

3. Click Add.

and the second se
ws to detect your modem?
Windows will now try to detect your modern. Before continuing, you should:
 If the modern is attached to your computer, make sure it is turned on.
Quit any programs that may be using the modem.
Click Next when you are ready to continue.
Don't detect my modem; I will select it from a list.
<back next=""> Cancel</back>

Figure A-4: Add Hardware Wizard

- 4. Select Don't detect my modem; I will select it from a list.
- 5. Click Next.

	er and model of your modern. If your modern is n disk, click Have Disk.	not listed, or if
Manufacturer	Models	
(Standard Modern Types)	Standard 14400 bps Modem	
200 B 100 C 100	Standard 19200 bps Modern	
	Standard 28800 bps Modem	=
	Contraction of the Contraction of the Contraction	
	Standard 55000 bps Modern	

Figure A-5: Add Hardware Wizard: Install New Modem

- 6. Under Manufacturer, select (Standard Modem Types).
- 7. Under Models, select Standard 33600 bps Modem.

Tip: If you have the speed for your device configured as something other than the default, use the Standard device that matches the speed you configured.

8. Click Next.

	You have selected the following moders: Standard 33600 bps Modern On which ports do you want to install #? C All ports Selected ports Selected ports
--	---

Figure A-6: Add Hardware Wizard: Select Ports

- **9.** Select Selected Ports.
- 10. Select the COM port the device is connected to (commonly COM1).
- 11. Click Next.

Add Hardware Wizard	- an and and
Install New Modem Modem installation is fi	nished
	Your modem has been set up successfully.
	If you want to change these settings, double-click the Phone and Modem Options icon in Control Panel, click the Modems tab, select this modem, and then click Properties.
	<back cancel<="" finish="" td=""></back>

Figure A-7: Add Hardware Wizard: Finish

12. Once the device driver is installed, click Finish.

When you return to the Phone and Modem Options page, you should see the newly installed device "attached to" the correct COM port.

-	Modems Ad			
43 T	he tollowing mo	odems are instal	led.	
Modern			Attached	To
C Illenter	o 13650 tope M	olarmi	CONT	

Figure A-8: Phone and Modem Options > Modems

13. Highlight the modem, and click Properties. The following window appears:

Seneral	Modern	Disgnostice	Advanced	Detvor	Getails	
1	Standa	rd 33600 bps	Modem			
	Device	type	Moderns			
	Manufa	clurer	(Standard M	odem T	ypes)	
	Locatio	π	Unknown			
Devic	e statue					
This	device is	working prop	erty.			*
- 9	Charge a	allings				
- 9	Change a	etings				

Figure A-9: Modem Properties

14. Select the Modem tab.

General	Modern Diagnostice Ad	Ivanced Driver Gatalla	
Port	004/481		
Speak	ar volume		
	ur I	raga	
Master	uin Port Speed		
	115200		
Dial C	pringi		
	2 Waithr dial time be	dow stalog	

Figure A-10: Modem Properties > Modem

- 15. Confirm that the Maximum Port Speed is set to 115200 (default).
- 16. Click OK to exit.
- **17.** Click OK again to exit out of the Phone and Modem Options.
- **18.** Go to Start > Control Panel > Device Manager.

S Device Manager		X
File Action View Help ♦ ♦ [10] [2] [2] [2] [2] [2] [3] [5]		
 carmd-1-001392 Batteries Biuetooth Radios Computer Disk drives Disk drives Disk drives DVD/CD-ROM drives DVD/CD-ROM drives File 1394 Bus host controllers EEE 1394 Bus host controllers EEE 1394 Bus host controllers Mice and other pointing devices Modems 		
Standard 33600 bps Modern Comparison ThinkPad Modern Adapter Monitors Monitors Ports (COM & LPT) Processors	Update Driver Software Disable Uninstall Scan for hardware changes Properties	-

Figure A-11: Device Manager

19. Under Modems, highlight Standard 33600 bps Modem. Right-click and select Update Driver Software....




Figure A-12: Update Driver Software—Browse

20. Select Browse my computer for driver software.



Figure A-13: Update Driver Software—Let me pick...

21. Select Let me pick from a list of device drivers on my computer.




Figure A-14: Update Driver Software—Select Standard Modem

- **22.** Deselect Show compatible hardware.
- 23. Under Manufacturer, select (Standard Modem Types).
- 24. Under Models, select Standard Modem.
- 25. Click Next.

If you see an Update Driver Warning, click Yes.



Figure A-15: Update Driver Software—Warning

The software driver updates and the following window appears:



Figure A-16: Update Driver Software—Success

26. Click Close.

Creating a Dial-Up Networking (PPP) Connection

Once you have the driver for the modem installed on your computer, you can set up and configure Dial Up Networking (DUN).

Note: No other device or program can use the COM port (serial port) configured for the modem driver while the DUN session is active.

Caution: If you have an existing LAN connection, installing DUN for the AirLink gateway may interfere with the LAN connection. We recommend disconnecting your LAN connection before using a PPP connection with your AirLink gateway.

Once you have configured the DUN connection on your computer:

- The DUN connection may be set as the default connection.
- The computer may be configured to dial the DUN connection when it cannot detect any network connection.

For instructions on changing these options, see Connection settings on page 416.

If you are using a DUN connection with any other network connection (such as Ethernet or Wi-Fi), you may need to use the route command in Windows to set up a static route through the device to access the location remotely over the PPP link and the mobile network. This guide does not provide information on the route command. Consult your network administrator for information on properly configuring routing.

Create a new network connection.

1. Select Start > Control Panel > Network and Sharing Center.

di Yes Took Hels	an and and and a second second		e souther that has to	
e folfard fore	View your basis network inf	lonnation and set	up cornections	
lange verskere overe	M.	()	<u> </u>	See fuil mad
langs spaper tolarge Langs specified that g	CADNOL: 002.82 (The constant)	sensere en col	a smel	
d cons	View your active her works			onnea profotonnea
	Sama san di sa hadi Di na matika di		koussiyosa unkanel Kannashonsi V ^{ar} iska basa (Jili Mankasha Jili Mankasha	week and the second
	Change you'n diworking setungs			
	Set up a new connections Set up a second set for all		2 Water new long on we report	nden av en son en s
inden Konzelanden († 1945) Konzelanden († 1945)	Somether reveal	ware every worself discus	, oo VEM a terake oo a shaac	
na a tao an An 2019 State a tao an Ang	Of the sector regression of a An exciting and procession		kanna da yana kana sikan	e set negs
Construction New York Construction New York Construction	Contention of the second secon	ant problems, an pebb	nisk-skool og ocherendene	

Figure A-17: Network and Sharing Center Window

2. Select Set up a new connection or network.




Figure A-18: Set up a Connection or Network

- **3.** Select Set up a dial-up connection.
- 4. Click Next.

If you are asked which modem you want to use, select Standard Modem.

🌀 👙 Create a Dial-up Conn	ection O	
Type the information	from your Internet service prov	ider (ISP)
Dial up phone number	4 777	Dialing Rules
User name:	(Name your ISP gave you)	
Password:	(Password your ISP gave you)	
	Show characters	
	Remember this password	
Connection name:	ALEOS Dial-up Connection	
😵 🥅 Allow other people t This option allows ar	to use this connection wone with access to this computer to use	this connection.
Lidon't have an ISP		
		Connect Cancel

Figure 1-19: Create a Dial up Connection

- 5. In the Dial-up phone number field, type "#777".
- 6. Ignore the User name and Password fields.
- 7. In the Connection name field, type "ALEOS Dial-up Connection" or other desired name.
- 8. Click Connect.

Alternatively, to connect to the ALEOS Dial-up network:

- **a.** Click the network connection icon¹ in the system tray.
- b. Select ALEOS Dial-up Connection.
- c. Click Connect.

Configure the DUN connection

After you complete the New Connection Wizard:

1. Click the network connection icon, select ALEOS Dial-up Connection, and click Connect.

Connect /	LEOS Dial-up Connection	
Ubername Passeord	Ĩ	
Met	s user name and password for the follow my masshe uses the computer	wing users
Diel	#777	-
Dal	Cancel Properties	Hep

Figure A-20: DUN Connection

- 2. If you have a user name and password configured in ACEmanager for PPP connections, enter them in the User name and Password fields. Otherwise, leave these fields blank.
- 3. Click Properties.

^{1.} The appearance of the connection icon varies depending on the type of connections available. For example, It may appear as , , , or .

Modem - Thrik Pad Modem Adapa	
Al devices call fee same watches	Configure.
Phone number Area mole Phone number 	Atematics
Use dialing rules	Dialog Riden

Figure A-21: DUN Properties

- 4. Confirm that the check box beside Use dialing rules is not selected.
- 5. Click Configure... (below the Connect using box).

Standard Modern	(COM40)	
Maximum speed (bps))	115200	•
Modem protocol		-
Hardware features		
Enable hardware flow	control	
Enable modern error o	ontrol	
Enable modern comp	easion	
Enable modern speaker		
		Cancel

Figure A-22: Modem Configuration

- 6. Confirm that the Maximum speed (bps) is set to 115200.
- **7.** Confirm that Enable hardware flow control is selected. Do not select any other options.
- 8. Click OK.

9. In the main properties window, select the Options tab.

Prompt for name and passeend, certificate, etc. Include Windows logon domain Prompt for phone number Redial attempts: Time between redial attempts: Idle time before hanging op Idle time before hanging op Idle timeshold * Redial if line is dropped	Drating options		
Prompt for phone number Redialing options Redial attempts: 3 + Time between redial attempts: 1 minute + Idle time before hanging op: 20 minutes + Idle timeshold +	- 프로그램 문제, 이상 이상 이상 방법 방법 영		
Recisil attempts: 3 + Time between recisil attempts: 1 minute + Idle Sine before hanging op: 20 minutes + Idle threshold +			
Recisil attempts: 3 + Time between recisil attempts: 1 minute + Idle Sine before hanging op: 20 minutes + Idle threshold +			
Time between redial attempts: 1 minute • Idle Sme before hanging op: 20 minutes • Idle Threshold •	Redialing options		
idie Sme before hanging op: 20 minutes • Idie threatiold •	Redial attempts:	3	*
ide freshold *	Time between redial attempts:	1 minute	
	Idle time before hanging op:	20 minutus	٠
Redial # Ine is dropped	ide friestold		
	Redal fine is dropped		
	High Stighter		
PROT D	PPP Settings.		

Figure A-23: Networking

10. Click PPP Settings.



Figure A-24: PPP Settings

- **11.** Clear the check boxes beside all three PPP settings.
- 12. Click OK.
- **13.** Select the Networking tab.

eneral Options Secu		
This connection uses th	a following items	
	Version 6 (TCP/Pv6)	
Peter al Peter al	Sharing for Microsoft Nets	and the second se
Strenat.	S Literatal	Properties
Description		
Transmission Control	I Protocol/Internet Protoco I that provute's communic	

Figure A-25: DUN Connection > Networking tab

14. Select Internet Protocol Version 4 (TCP/IPv4) and then select Properties.

Tip: For most configurations, getting the IP address and the DNS server address are automatic.

emet Protocol Version 4 (TCP/IPv4) Properties	
General	
You can get IP settings assigned automatically if your this capability. Otherwise, you need to ask your networ the appropriate IP settings.	
Obtain an IP address automatically	
. O Use the following IP address	
Padaese	
Obtain DNS server address automatically	
Oute the following DNS server addresses	
Plataned 014E awaie	
Administre DAIS non-sec	10.10
	Advanced
	OK Cancel

Figure A-26: TCP/IP Properties

15. Click Advanced.

P Settings DNS WINS	
This checkbox only applies when you are con and a dial-up network sensitianeously. When be sent on the local network is forwarded to the	checked, data that cannot
😰 Use default gateway on remote network	
Deable class based mile addition	
V Automatic metric	
bischer mehre	
PPP lek	
[V] Use IP header compression	

Figure A-27: Advanced TCP/IP

- 16. Select Use default gateway on remote network.
- 17. Click OK.

Tip: You may want to check the Options tab and change the settings for applications you use. The default options are generally applicable for most uses.

Caution: Unless specifically directed to do so by Support or your network administrator, you do not need to make any changes to the options on the Security tab.

- 18. Click OK until you return to the Connect window.
- **19.** Log in to ACEmanager and go to Serial > Port Configuration.
- **20.** Under Port Configuration:
 - a. Set the Flow Control field to Hardware.
 - **b.** Set the DB9 Serial Echo field to Disable.
- 21. Click Apply and reboot the device.

Connection settings

- **1.** To set the default connection:
- 2. Go to Start > Control Panel > Network and Sharing Center.
- 3. Select Change adapter settings.
- 4. Right-click the icon for the DUN connection.

If you want this to be your default connection, select Set as Default Connection. If it is already the default connection and you do not want it as your default connection, select Cancel as Default Connection.

If you do not want the DUN connection to be dialed when there is no other connection:

- 1. Go to Start > Control Panel > Internet Options.
- 2. Select the Connections tab.
- 3. Highlight the DUN connection and select Never dial a connection.
- 4. Click Apply.
- 5. Click OK.

B: Modbus/BSAP Configuration

The AirLink router supports Modbus ASCII, Modbus RTU, and BSAP, and can also emulate other protocols (like DF1) using the Modbus Variable feature.

Modbus Overview

The Modbus Protocol provides for client-server (i.e., master-slave) communications between intelligent devices. As a de facto standard, it is the most widely used network protocol in the industrial manufacturing environment to transfer discrete/analog I/O and register data between control devices. Modbus, BSAP, and other Modbus variations are often used in conjunction with telemetry devices.

Tip: This section is just a brief overview of Modbus. For more information, refer to your Modbus equipment distributor or manufacturer or www.modbus.org.

Telemetry

Telemetry is an automated communications process by which data is collected from instruments located at remote or inaccessible points and transmitted to receiving equipment for measurement, monitoring, display, and recording. Transmission of the information may be over physical pairs of wires, telecommunication circuits, radios, or satellites.

Remote Terminal Unit (RTU)

Modbus was originally designed to be used in a radio environment where packets were broadcast from a central station (i.e., master or host) to a group of remote units. Each remote unit, or Remote Terminal Unit (RTU), has a hexadecimal identification number (ID). The first part of the broadcast packet contains an RTU ID which corresponds to the ID of one of the remote units. The Modbus host looks for the ID and only sends to the unit with the matching ID; the RTU then replies back to the central station.

The RTU connects to such physical equipment as switches, pumps, and other devices, and monitors and controls these devices. The RTU can be part of a network set up for Supervisory Control and Data Acquisition.

Supervisory Control and Data Acquisition (SCADA)

Supervisory Control and Data Acquisition (SCADA) describes solutions across a large variety of industries and is used in industrial and engineering applications to monitor and control distributed systems from a master location. SCADA encompasses multiple RTUs, a central control room with a host computer (or network), and some sort of communication infrastructure.

SCADA allows for "supervisory" control of remote devices as well as acquiring data from the remote locations. Programmable Logic Controllers allow for a higher degree of automated SCADA.

Programmable Logic Controller (PLC)

A Programmable Logic Controller (PLC) is a small industrial computer which generally monitors several connected sensor inputs and controls attached devices (motor starters, solenoids, pilot lights/displays, speed drives, valves, etc.) according to a user-created program stored in its memory. Containing inputs and outputs similar to an RTU, PLCs are frequently used for typical relay control, sophisticated motion control, process control, Distributed Control System and complex networking.

Modbus TCP/IP

Modbus TCP/IP simply takes the Modbus instruction set and wraps TCP/IP around it. Since TCP/IP is the communications standard for the Internet and most networked computers, this provides a simpler installation. Modbus TCP/IP uses standard Ethernet equipment.

Modbus on UDP

When Sierra Wireless AirLink routers are used in place of radios, a AirLink router is connected to the central station (host) and an AirLink router is connected to each remote unit. When the AirLink router is configured for Modbus with UDP, the AirLink router connected to the host can store a list of IP addresses or names with matching IDs. When the host at the central station sends serial data as a poll request, the AirLink router at the host matches the RTU ID to a corresponding IP of a AirLink router at a remote unit. A UDP packet is assembled encapsulating the RTU ID and serial data transmitted from the host. The UDP packet is then transmitted to the specific AirLink router at the remote unit matching the RTU ID. The remote AirLink router then disassembles the packet before transmitting the RTU ID and serial data to the remote unit. The remote units operate in normal UDP mode and their data is sent to the host via the remote AirLink router and host AirLink router.

Configuring AirLink routers at the Polling Host for Modbus on UDP

This section covers a Polling Host with standard Modbus, variations may need additional AT commands.

1. Configure the ports.

The destination port for the device at the host needs to match the device port (*DPORT) in use on all the modems at the remote sites. For example, if the remote device's device port (*DPORT) is "12345", then the Modbus host device's *S53* destination port should be set to "12345".

Take note of (or set) the Device Port setting in *DPORT to configure the destination port on the remote modems.

In ACEmanager, select *UDP* in the side menu. Select the appropriate *MD* mode from the drop down menu.

- MD13: Modbus ASCII
- MD23: Modbus RTU (Binary)

- MD33: BSAP
- **MD63**: Variable Modbus individual parameters are set up manually.

If you do not have a static IP, the host device should be configured to report its current IP to a Dynamic DNS (DDNS) server with Dynamic DNS.

In the Host device's configuration, instead of an IP address for the Addr List (ATMLIST or ATMLISTX), substitute a single unique name for each device, i.e. remote1, remote2, etc.

When you configure Dynamic DNS for the host device, make note of your device name and domain setting in ACEmanager in the menu selection *Dynamic IP* to be used with the remote modems.

With names instead of IP addresses for the Address List, the host device queries the DNS server for the current IP address assigned to the specific name of a remote device to send a message corresponding to the ID.

When you use names instead of IP addresses, to ensure your modems are updated quickly with the correct IP addresses for the names, set the DNS settings as well. In ACEmanager, select *DNS*.

Configure *DNSUSER to the same IP address as the Dynamic DNS (*IPMANAGER1). If your modems have dynamic IP addresses and not static (the IP address can change when it is powered up), configure *DNSUPDATE to a low interval to allow frequent updates.

Configuring Remote AirLink routers for Modbus with UDP

This section covers standard Modbus settings for the AirLink router at the remote unit; variations may need additional commands.

1. Configure the ports

In ACEmanager, select Port Configuration in the side menu.

The destination port for the device at the host needs to match the device port in use on all the devices at the remote sites. For example, if the remote device's device port (see below) is "12345", then the Modbus host device's *S53* destination port should be set to "12345".

Set the destination port (S53) to match the device port of the host device (*DPORT). Make sure the device port of the remote device (*DPORT) matches the destination port of the host device (S53).

Configure IP Addresses for the Host

If the Host device has a static IP address, enter it in the Destination Address for S53.

Note: With a name instead of IPs for the host device, the remote devices query the DNS server for the current IP assigned to the host device before sending data back to the host.

If the device at the host has a dynamic IP and is using Dynamic DNS, instead of an IP address for S53, specify the name of the host device (**). If the remote devices are using a different DDNS than the host device, you need to specify the fully qualified domain name (**+*DOMAIN).

Note: Setting the Host device IP address as the S53 Destination Address provides a low level security. The device does not forward UDP traffic unless the source IP/port matches what is in S53. However, if you set *AIP=1, the device forwards UDP traffic from any source IP address as long as it is accessing the device on the configured *DPORT.

1. Configure the default mode for start-up.

Each device at the remote locations needs to be configured to communicate with the device at the host. In ACEmanager, select *UDP* in the side menu.

- a. Enable S82, UDP answer.
- **b.** Set *S83* to the idle time-out applicable to your application, commonly 20.
- **2.** Configure other RTU settings.

Other parameters may need to be changed, but this is dependent on the RTU type being used. At a minimum, this typically involves setting the proper serial settings to match your RTU.

3. Optional: Dynamic IP Address

If you do not have a static IP, the host device should be configured to report its current IP to a Dynamic DNS (DDNS) server with Dynamic DNS.

Match the name of the device to the names specified in the host device's MLIST or MLISTX for the connected RTU.

When you configure Dynamic DNS for the host device, note your device name and domain setting in ACEmanager in the menu selection *Dynamic IP* to be used with the remote devices.

When you use names instead of IP addresses, to ensure your devices are updated quickly with the correct IP addresses for the names, set the DNS settings as well.

Configure *DNSUSER to the same IP address as the Dynamic DNS (*IPMANAGER1). If your devices have dynamic IP addresses and not static (the IP address can change when it is powered up), configure *DNSUPDATE to a low interval to allow frequent updates.

C: SNMP: Simple Network Management Protocol

Management Information Base (MIB)

ALEOS includes a Management Information Base (MIB) that contains information specific to the AirLink RV55. Reports based on this database are sent in a form designed to be parsed by the NMS. The data is hierarchical with entries addressed through object identifiers.

The MIB complies with:

- RFC 1213 and MIB-II
- RFC 2665 Ethernet-Like Interface Types
- RFC 2863 The Interfaces Group MIB

SNMP Traps

SNMP traps are alerts that can be sent from the managed device to the Network Management System when an event happens. Your AirLink RV55 is capable of sending traps when the network connection becomes available.

To send SNMP traps:

- 1. In ACEmanager, go to Services > Management (SNMP).
- 2. Configure the fields under Trap Server User. (For more information, see Management (SNMP) on page 265.)
- **3.** Go to Events Reporting > Actions.
- 4. In the Action Type field select SNMP trap. (For more information, see SNMP TRAP on page 311.)
- Go Events Reporting > Events and configure monitoring for the event type that will trigger the SNMP trap. For example, the event type could be RSSI, thresholds, network state, hardware temperature, etc.

Sierra Wireless MIB

This section shows the contents of the Sierra Wireless MIB file. When this file is loaded onto a remote SNMP client, you can query the Sierra Wireless specific objects listed in this file.

For a text copy of this MIB file, go to source.sierrawireless.com, and select your AirLink RV55.

```
SIERRA-MIB DEFINITIONS ::= BEGIN
IMPORTS
    OBJECT-TYPE, NOTIFICATION-TYPE, MODULE-IDENTITY, IPAddress,
    Integer32, Opaque, enterprises, Counter32, Unsigned32
        FROM SNMPv2-SMI
    TEXTUAL-CONVENTION, DisplayString, TruthValue
FROM SNMPv2-TC;
sierrawireless MODULE-IDENTITY
   LAST-UPDATED "201202290000Z"
   ORGANIZATION "Sierra Wireless Inc"
   CONTACT-INFO
"Sierra Wirelss Inc
        ...
    DESCRIPTION
11 II
   REVISION "201202290000Z"
    DESCRIPTION
"This file defines the private Sierra MIB extensions."
    ::= { enterprises 20542 }
sharks OBJECT IDENTIFIER ::= { sierrawireless 9}
-- MIB versions
mibversion1 OBJECT IDENTIFIER ::= { sharks 1}
-- GUI Tabs for Sharks
statustab OBJECT IDENTIFIER ::= { mibversion1 1}
```

```
cellulartab OBJECT IDENTIFIER ::= { mibversion1 2}
lantab OBJECT IDENTIFIER ::= { mibversion1 3}
vpntab OBJECT IDENTIFIER ::= { mibversion1 4}
securitytab OBJECT IDENTIFIER ::= { mibversion1 5}
servicestab OBJECT IDENTIFIER ::= { mibversion1 6}
gpstab OBJECT IDENTIFIER ::= { mibversion1 7}
eventsreportingtab OBJECT IDENTIFIER ::= { mibversion1 8}
serialtab OBJECT IDENTIFIER ::= { mibversion1 9}
iotab OBJECT IDENTIFIER ::= { mibversion1 10}
admintab OBJECT IDENTIFIER ::= { mibversion1 11}
snmpconfig OBJECT IDENTIFIER ::= { mibversion1 12}
```

-- status elements

```
home OBJECT IDENTIFIER ::= { statustab 1}
cellular OBJECT IDENTIFIER ::= { statustab 2}
lan OBJECT IDENTIFIER ::= { statustab 3}
vpn OBJECT IDENTIFIER ::= { statustab 4}
security OBJECT IDENTIFIER ::= { statustab 5}
services OBJECT IDENTIFIER ::= { statustab 6}
gps OBJECT IDENTIFIER ::= { statustab 7}
serial OBJECT IDENTIFIER ::= { statustab 8}
about OBJECT IDENTIFIER ::= { statustab 9}
```

-- io elements currentstate OBJECT IDENTIFIER ::= { iotab 1} configuration OBJECT IDENTIFIER ::= { iotab 2}

-- home status elements

```
phoneNumber OBJECT-TYPE
SYNTAX DisplayString (SIZE (10))
MAX-ACCESS read-only
STATUS current
```

```
DESCRIPTION ""
::= { home 17 }
ipAddress OBJECT-TYPE
SYNTAX IpAddress
MAX-ACCESS read-only
STATUS current
  DESCRIPTION ""
::= { home 301 }
networkState OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
  DESCRIPTION ""
::= { home 259 }
rssi OBJECT-TYPE
SYNTAX INTEGER (-125..-50)
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { home 261 }
gprsnetworkOperator OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { home 770 }
cdmanetworkOperator OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
```

STATUS current

```
DESCRIPTION ""

::= { home 644 }

gprsECIO OBJECT-TYPE

SYNTAX DisplayString

MAX-ACCESS read-only

STATUS current

DESCRIPTION ""

::= { home 772 }
```

```
cdmaECIO OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION ""
::= { home 643 }
```

powerIn OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION ""
::= { home 266 }

```
boardTemprature OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
    DESCRIPTION ""
::= { home 267 }
```

```
networkServiceType OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
```

```
DESCRIPTION ""
::= { home 264 }
aleosSWVer OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { home 4 }
netChannel OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { home 260 }
cellularBytesSent OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { home 283 }
cellularBytesRecvd OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
```

STATUS current

DESCRIPTION ""

::= { home 284 }

```
deviceName OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
```

```
STATUS current
   DESCRIPTION ""
::= { home 1154 }
-- cellular status elements
wanIP OBJECT-TYPE
SYNTAX IpAddress
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 301 }
electronicID OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 10 }
iccid OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 771 }
cellid OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 773 }
```

lac OBJECT-TYPE

```
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 774 }
imsi OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 785 }
keepAliveIpAddress OBJECT-TYPE
SYNTAX IpAddress
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 1105 }
keepAlivePingTime OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 1104 }
dnsServer1 OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 1082 }
```

```
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 1083 }
cellBand OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 2056 }
apn OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 2151 }
wanUseTime OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 5046 }
rscp OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 10249 }
```

```
errorRate OBJECT-TYPE
```

```
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 263 }
bytesSent OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 283 }
bytesRecvd OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 284 }
packetsSent OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 281 }
packetsRecvd OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 282 }
```

prlVersion OBJECT-TYPE

```
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 642 }
prlUpdateStatus OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 646 }
sid OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 648 }
nid OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 649 }
pnOffset OBJECT-TYPE
SYNTAX DisplayString
```

```
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
    DESCRIPTION ""
::= { cellular 650 }
```

```
baseClass OBJECT-TYPE
```

SYNTAX DisplayString

```
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 651 }
rsrq OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 10209 }
rsrp OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 10210 }
sinr OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { cellular 10211 }
-- LAN status elements
usbMode OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { lan 1130 }
```

```
vrrpEnabled OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION ""
::= { lan 9001 }
```

lanpacketsSent OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
 DESCRIPTION ""
::= { lan 279 }

lanpacketsRecvd OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
 DESCRIPTION ""
::= { lan 280 }

```
wifipacketsSent OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
DESCRIPTION ""
::= { lan 10405 }
```

wifipacketsRecvd OBJECT-TYPE SYNTAX INTEGER MAX-ACCESS read-only STATUS current DESCRIPTION ""

```
::= { lan 10406 }
wifiBridgeEnabled OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
    DESCRIPTION ""
::= { lan 10401 }
```

wifiSecurityType OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION ""
::= { lan 4509 }

wifiAPStatus OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
 DESCRIPTION ""
::= { lan 4506 }

```
wifiSSID OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION ""
::= { lan 4507 }
```

wifiChannel OBJECT-TYPE SYNTAX INTEGER MAX-ACCESS read-only STATUS current DESCRIPTION ""

```
::= { lan 4508 }
-- VPN status elements
incomingOOB OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { vpn 3177 }
outgoingOOB OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { vpn 3178 }
outgoingHostOOB OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
```

```
vpn1Status OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION ""
::= { vpn 3176 }
```

::= { vpn 3179 }

vpn2Status OBJECT-TYPE

```
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { vpn 3205 }
vpn3Status OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { vpn 3231 }
vpn4Status OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
    DESCRIPTION ""
::= { vpn 3257 }
vpn5Status OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { vpn 3283 }
-- Security status elements
dmz OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
```

```
portForwarding OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION ""
::= { security 5112 }
```

```
portFilteringIn OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
    DESCRIPTION ""
::= { security 3505 }
```

```
portFilteringOut OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION ""
::= { security 3506 }
```

```
trustedHosts OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION ""
::= { security 1062 }
```

```
macFiltering OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION ""
::= { security 3509 }
```

```
badPasswdCount OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
DESCRIPTION ""
::= { security 385 }
```

ipRejectCount OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
 DESCRIPTION ""
::= { security 386 }

ipRejectLog OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
 DESCRIPTION ""
::= { security 387 }

-- Services status elements

```
aceNet OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION ""
::= { services 5026 }
```

aceManager OBJECT-TYPE SYNTAX DisplayString MAX-ACCESS read-only STATUS current

```
DESCRIPTION ""
::= { services 1149 }
dynamicDnsService OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { services 5011 }
fullDomainName OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { services 5007 }
-- GPS status elements
gpsFix OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
```

STATUS current
 DESCRIPTION ""
::= { gps 900 }

```
satelliteCount OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
    DESCRIPTION ""
::= { gps 901 }
```

```
latitude OBJECT-TYPE
SYNTAX DisplayString
```

MAX-ACCESS read-only

```
STATUS current
   DESCRIPTION ""
::= { gps 902 }
longitude OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { gps 903 }
heading OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { gps 904 }
speed OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
::= { gps 905 }
engineHours OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
   DESCRIPTION ""
```

```
::= { gps 906 }
```

```
-- Serial status elements
```

```
serialPortMode OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
    DESCRIPTION ""
::= { serial 1043 }
```

```
tcpAutoAnswer OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
    DESCRIPTION ""
::= { serial 1048 }
```

```
udpAutoAnswer OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
    DESCRIPTION ""
::= { serial 1054 }
```

```
serialPacketsSent OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
    DESCRIPTION ""
::= { serial 273 }
```

```
serialPacketsRecvd OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-only
STATUS current
    DESCRIPTION ""
::= { serial 274 }
-- About status elements
```

```
deviceModel OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION ""
::= { about 7 }
```

```
radioModelType OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION ""
::= { about 9 }
```

```
radioFirmwareVersion OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
    DESCRIPTION ""
::= { about 8 }
```

```
deviceID OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION ""
::= { about 25 }
```

```
macAddress OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION ""
```

```
::= { about 66 }
aleosSWVersion OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
    DESCRIPTION ""
::= { about 4 }
```

deviceHwConfiguration OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION ""
::= { about 5 }

```
msciVersion OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-only
STATUS current
DESCRIPTION ""
::= { about 3 }
```

-- Read Write values

```
snmpversion OBJECT-TYPE
```

snmpport OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-write
STATUS current
DESCRIPTION ""
::= { snmpconfig 10042 }

```
snmpContact OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
DESCRIPTION ""
::= { snmpconfig 2730 }
```

```
snmpName OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
DESCRIPTION ""
::= { snmpconfig 2731 }
```

```
snmpLocation OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
DESCRIPTION ""
::= { snmpconfig 2732 }
```

```
rocommunity OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
    DESCRIPTION ""
::= { snmpconfig 10063 }
rouser OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
   DESCRIPTION ""
::= { snmpconfig 10045 }
rosecuritylvl OBJECT-TYPE
SYNTAX INTEGER {
           noauthnopriv(0),
           authnopriv(1),
           authpriv(2) }
MAX-ACCESS read-write
STATUS current
   DESCRIPTION ""
::= { snmpconfig 10046 }
roauthtype OBJECT-TYPE
SYNTAX INTEGER {
           md5(0),
           sha(1) }
MAX-ACCESS read-write
STATUS current
    DESCRIPTION ""
::= { snmpconfig 10047 }
```

roauthkey OBJECT-TYPE

```
SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
DESCRIPTION ""
::= { snmpconfig 10048 }
roprivtype OBJECT-TYPE
SYNTAX INTEGER {
aes(0),
des(1) }
MAX-ACCESS read-write
STATUS current
DESCRIPTION ""
::= { snmpconfig 10049 }
roprivkey OBJECT-TYPE
SYNTAX DisplayString
```

```
MAX-ACCESS read-write
STATUS current
DESCRIPTION ""
```

::= { snmpconfig 10050 }

```
rwcommunity OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
DESCRIPTION ""
::= { snmpconfig 10064 }
```

rwuser OBJECT-TYPE SYNTAX DisplayString MAX-ACCESS read-write STATUS current DESCRIPTION ""

```
::= { snmpconfig 10051 }
rwsecuritylvl OBJECT-TYPE
SYNTAX INTEGER {
           noauthnopriv(0),
           authnopriv(1),
           authpriv(2) }
MAX-ACCESS read-write
STATUS current
   DESCRIPTION ""
::= { snmpconfig 10052 }
rwauthtype OBJECT-TYPE
SYNTAX INTEGER {
           md5(0),
           sha(1) }
MAX-ACCESS read-write
STATUS current
   DESCRIPTION ""
::= { snmpconfig 10053 }
rwauthkey OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
   DESCRIPTION ""
::= { snmpconfig 10054 }
rwprivtype OBJECT-TYPE
SYNTAX INTEGER {
           aes(0),
           des(1) }
MAX-ACCESS read-write
STATUS current
```

```
DESCRIPTION ""
::= { snmpconfig 10055 }
rwprivkey OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
   DESCRIPTION ""
::= { snmpconfig 10056 }
trapipAddress OBJECT-TYPE
SYNTAX IpAddress
MAX-ACCESS read-write
STATUS current
   DESCRIPTION ""
::= { snmpconfig 1166 }
trapport OBJECT-TYPE
SYNTAX INTEGER
MAX-ACCESS read-write
STATUS current
    DESCRIPTION ""
::= { snmpconfig 10043 }
engineid OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
   DESCRIPTION ""
::= { snmpconfig 10044 }
trapcommunity OBJECT-TYPE
SYNTAX DisplayString
```

MAX-ACCESS read-write

```
STATUS current
   DESCRIPTION ""
::= { snmpconfig 10065 }
trapuser OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
   DESCRIPTION ""
::= { snmpconfig 10057 }
trapsecuritylvl OBJECT-TYPE
SYNTAX INTEGER {
           noauthnopriv(0),
           authnopriv(1),
           authpriv(2) }
MAX-ACCESS read-write
STATUS current
   DESCRIPTION ""
::= { snmpconfig 10058 }
trapauthtype OBJECT-TYPE
SYNTAX INTEGER {
           md5(0),
           sha(1) }
MAX-ACCESS read-write
STATUS current
   DESCRIPTION ""
::= { snmpconfig 10059 }
trapauthkey OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
    DESCRIPTION ""
```

```
::= { snmpconfig 10060 }
trapprivtype OBJECT-TYPE
SYNTAX INTEGER {
          aes(0),
          des(1) }
MAX-ACCESS read-write
STATUS current
   DESCRIPTION ""
::= { snmpconfig 10061 }
trapprivkey OBJECT-TYPE
SYNTAX DisplayString
MAX-ACCESS read-write
STATUS current
   DESCRIPTION ""
::= { snmpconfig 10062 }
rebootmodem OBJECT-TYPE
SYNTAX INTEGER {
           nop(0),
          reboot(1) }
MAX-ACCESS read-write
STATUS current
   DESCRIPTION ""
::= { snmpconfig 65001 }
digitalInput1 OBJECT-TYPE
    SYNTAX DisplayString
    STATUS current
    DESCRIPTION "Digital Input 1 MSCIID 851"
    ::= { currentstate 851 }
```

```
digitalInput2 OBJECT-TYPE
    SYNTAX DisplayString
   STATUS
               current
    DESCRIPTION "Digital Input 2 MSCIID 852"
    ::= { currentstate 852 }
digitalInput3 OBJECT-TYPE
    SYNTAX DisplayString
   STATUS
               current
    DESCRIPTION "Digital Input 3 MSCIID 853"
    ::= { currentstate 853 }
digitalInput4 OBJECT-TYPE
   SYNTAX DisplayString
    STATUS
              current
    DESCRIPTION "Digital Input 4 MSCIID 854"
    ::= { currentstate 854 }
digitalInput5 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
                current
    DESCRIPTION "Digital Input 5 MSCIID 867"
    ::= { currentstate 867 }
digitalInput6 OBJECT-TYPE
    SYNTAX DisplayString
   STATUS
               current
    DESCRIPTION "Digital Input 6 MSCIID 868"
    ::= { currentstate 868 }
digitalOutput1 OBJECT-TYPE
    SYNTAX DisplayString
   STATUS
               current
   DESCRIPTION "Digital Output 1 MSCIID 859"
    ::= { currentstate 859 }
```

```
digitalOutput2 OBJECT-TYPE
    SYNTAX DisplayString
   STATUS
               current
    DESCRIPTION "Digital Output 2 MSCIID 860"
    ::= { currentstate 860 }
digitalOutput3 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
              current
    DESCRIPTION "Digital Output 3 MSCIID 863"
    ::= { currentstate 863 }
digitalOutput4 OBJECT-TYPE
    SYNTAX DisplayString
   STATUS
              current
   DESCRIPTION "Digital Output 4 MSCIID 864"
    ::= { currentstate 864 }
digitalOutput5 OBJECT-TYPE
   SYNTAX DisplayString
    STATUS
              current
    DESCRIPTION "Digital Output 5 MSCIID 865"
    ::= { currentstate 865 }
digitalOutput6 OBJECT-TYPE
   SYNTAX DisplayString
    STATUS
              current
    DESCRIPTION "Digital Output 6 MSCIID 866"
    ::= { currentstate 866 }
digitalConfig1 OBJECT-TYPE
   SYNTAX DisplayString
    STATUS
              current
    DESCRIPTION "Digital Configuration 1 MSCIID 861"
```

```
::= { configuration 861 }
digitalConfig2 OBJECT-TYPE
    SYNTAX DisplayString
               current
    STATUS
    DESCRIPTION "Digital Configuration 2 MSCIID 862"
    ::= { configuration 862 }
digitalConfig3 OBJECT-TYPE
    SYNTAX DisplayString
    STATUS
                current
    DESCRIPTION "Digital Configuration 3 MSCIID 869"
    ::= { configuration 869 }
digitalConfig4 OBJECT-TYPE
    SYNTAX DisplayString
    STATUS
               current
    DESCRIPTION "Digital Configuration 4 MSCIID 870"
    ::= { configuration 870 }
digitalConfig5 OBJECT-TYPE
    SYNTAX DisplayString
    STATUS
               current
    DESCRIPTION "Digital Configuration 5 MSCIID 871"
    ::= { configuration 871 }
digitalConfig6 OBJECT-TYPE
    SYNTAX DisplayString
    STATUS
                current
    DESCRIPTION "Digital Configuration 6 MSCIID 872"
    ::= { configuration 872 }
pulseAccumulator1 OBJECT-TYPE
    SYNTAX DisplayString
```

```
STATUS
               current
    DESCRIPTION "Pulse Accumulator 1 MSCIID 4002"
    ::= { currentstate 4002 }
pulseAccumulator2 OBJECT-TYPE
    SYNTAX DisplayString
    STATUS
               current
    DESCRIPTION "Pulse Accumulator 2 MSCIID 4003"
    ::= { currentstate 4003 }
pulseAccumulator3 OBJECT-TYPE
    SYNTAX DisplayString
    STATUS current
    DESCRIPTION "Pulse Accumulator 3 MSCIID 4004"
    ::= { currentstate 4004 }
pulseAccumulator4 OBJECT-TYPE
    SYNTAX DisplayString
    STATUS
           current
    DESCRIPTION "Pulse Accumulator 4 MSCIID 4005"
    ::= { currentstate 4005 }
pulseAccumulator5 OBJECT-TYPE
    SYNTAX DisplayString
    STATUS
               current
    DESCRIPTION "Pulse Accumulator 5 MSCIID 4006"
    ::= { currentstate 4006 }
pulseAccumulator6 OBJECT-TYPE
    SYNTAX DisplayString
    STATUS
               current
    DESCRIPTION "Pulse Accumulator 6 MSCIID 4007"
    ::= { currentstate 4007 }
```

```
analogInput1 OBJECT-TYPE
```

```
SYNTAX DisplayString
               current
    STATUS
    DESCRIPTION "Analog Input 1 MSCIID 855"
    ::= { currentstate 855 }
analogInput2 OBJECT-TYPE
    SYNTAX DisplayString
   STATUS
               current
   DESCRIPTION "Analog Input 2 MSCIID 856"
    ::= { currentstate 856 }
analogInput3 OBJECT-TYPE
   SYNTAX DisplayString
    STATUS
              current
    DESCRIPTION "Analog Input 3 MSCIID 857"
    ::= { currentstate 857 }
analogInput4 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
               current
    DESCRIPTION "Analog Input 4 MSCIID 858"
    ::= { currentstate 858 }
analogInput5 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
              current
    DESCRIPTION "Analog Input 5 MSCIID 873"
    ::= { currentstate 873 }
analogInput6 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
              current
   DESCRIPTION "Analog Input 6 MSCIID 874"
    ::= { currentstate 874 }
```

```
analogInput7 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
              current
   DESCRIPTION "Analog Input 7 MSCIID 875"
   ::= { currentstate 875 }
analogInput8 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
              current
   DESCRIPTION "Analog Input 8 MSCIID 876"
   ::= { currentstate 876 }
coefficientAnalogInput1 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
              current
   DESCRIPTION "Coefficient Analog Input 1 MSCIID 4011"
   ::= { currentstate 4011 }
coefficientAnalogInput2 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
              current
   DESCRIPTION "Coefficient Analog Input 2 MSCIID 4012"
    ::= { currentstate 4012 }
coefficientAnalogInput3 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
              current
   DESCRIPTION "Coefficient Analog Input 3 MSCIID 4013"
    ::= { currentstate 4013 }
coefficientAnalogInput4 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
              current
   DESCRIPTION "Coefficient Analog Input 4 MSCIID 4014"
```

```
::= { currentstate 4014 }
coefficientAnalogInput5 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS current
   DESCRIPTION "Coefficient Analog Input 5 MSCIID 4015"
    ::= { currentstate 4015 }
coefficientAnalogInput6 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
              current
   DESCRIPTION "Coefficient Analog Input 6 MSCIID 4016"
    ::= { currentstate 4016 }
coefficientAnalogInput7 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
              current
    DESCRIPTION "Coefficient Analog Input 7 MSCIID 4017"
    ::= { currentstate 4017 }
coefficientAnalogInput8 OBJECT-TYPE
   SYNTAX DisplayString
    STATUS current
   DESCRIPTION "Coefficient Analog Input 8 MSCIID 4018"
    ::= { currentstate 4018 }
offsetAnalogInput1 OBJECT-TYPE
   SYNTAX DisplayString
    STATUS current
    DESCRIPTION "Offset Analog Input 1 MSCIID 4021"
    ::= { currentstate 4021 }
offsetAnalogInput2 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS current
```

```
DESCRIPTION "Offset Analog Input 2 MSCIID 4022"
   ::= { currentstate 4022 }
offsetAnalogInput3 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS current
   DESCRIPTION "Offset Analog Input 3 MSCIID 4023"
    ::= { currentstate 4023 }
offsetAnalogInput4 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS current
    DESCRIPTION "Offset Analog Input 4 MSCIID 4024"
    ::= { currentstate 4024 }
offsetAnalogInput5 OBJECT-TYPE
   SYNTAX DisplayString
    STATUS
              current
    DESCRIPTION "Offset Analog Input 5 MSCIID 4025"
    ::= { currentstate 4025 }
offsetAnalogInput6 OBJECT-TYPE
    SYNTAX DisplayString
   STATUS
               current
    DESCRIPTION "Offset Analog Input 6 MSCIID 4026"
    ::= { currentstate 4026 }
offsetAnalogInput7 OBJECT-TYPE
    SYNTAX DisplayString
   STATUS
              current
   DESCRIPTION "Offset Analog Input 7 MSCIID 4027"
    ::= { currentstate 4027 }
offsetAnalogInput8 OBJECT-TYPE
    SYNTAX DisplayString
```

```
STATUS
              current
    DESCRIPTION "Offset Analog Input 8 MSCIID 4028"
    ::= { currentstate 4028 }
unitsAnalogInput1 OBJECT-TYPE
    SYNTAX DisplayString
   STATUS
              current
    DESCRIPTION "Units Analog Input 1 MSCIID 4031"
    ::= { currentstate 4031 }
unitsAnalogInput2 OBJECT-TYPE
    SYNTAX DisplayString
   STATUS current
   DESCRIPTION "Units Analog Input 2 MSCIID 4032"
    ::= { currentstate 4032 }
unitsAnalogInput3 OBJECT-TYPE
    SYNTAX DisplayString
   STATUS current
   DESCRIPTION "Units Analog Input 3 MSCIID 4033"
    ::= { currentstate 4033 }
unitsAnalogInput4 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
              current
   DESCRIPTION "Units Analog Input 4 MSCIID 4034"
    ::= { currentstate 4034 }
unitsAnalogInput5 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
              current
   DESCRIPTION "Units Analog Input 5 MSCIID 4035"
    ::= { currentstate 4035 }
```

Rev. 2 March 2021

unitsAnalogInput6 OBJECT-TYPE

```
SYNTAX DisplayString
              current
    STATUS
    DESCRIPTION "Units Analog Input 6 MSCIID 4036"
    ::= { currentstate 4036 }
unitsAnalogInput7 OBJECT-TYPE
    SYNTAX DisplayString
   STATUS
              current
    DESCRIPTION "Units Analog Input 7 MSCIID 4037"
    ::= { currentstate 4037 }
unitsAnalogInput8 OBJECT-TYPE
    SYNTAX DisplayString
   STATUS
              current
    DESCRIPTION "Units Analog Input 8 MSCIID 4038"
    ::= { currentstate 4038 }
scaledAnalogInput1 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
              current
   DESCRIPTION "Scaled Analog Input 1 MSCIID 4041"
    ::= { currentstate 4041 }
scaledAnalogInput2 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS current
   DESCRIPTION "Scaled Analog Input 2 MSCIID 4042"
    ::= { currentstate 4042 }
scaledAnalogInput3 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
              current
   DESCRIPTION "Scaled Analog Input 3 MSCIID 4043"
    ::= { currentstate 4043 }
```

```
scaledAnalogInput4 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
              current
   DESCRIPTION "Scaled Analog Input 4 MSCIID 4044"
   ::= { currentstate 4044 }
scaledAnalogInput5 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
              current
   DESCRIPTION "Scaled Analog Input 5 MSCIID 4045"
   ::= { currentstate 4045 }
scaledAnalogInput6 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
              current
   DESCRIPTION "Scaled Analog Input 6 MSCIID 4046"
    ::= { currentstate 4046 }
scaledAnalogInput7 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
              current
   DESCRIPTION "Scaled Analog Input 7 MSCIID 4047"
    ::= { currentstate 4047 }
scaledAnalogInput8 OBJECT-TYPE
   SYNTAX DisplayString
   STATUS
              current
   DESCRIPTION "Scaled Analog Input 8 MSCIID 4048"
   ::= { currentstate 4048 }
```

-- Notifications starting at 1000

```
modemNotifications OBJECT IDENTIFIER ::= { mibversion1 1000 }
value OBJECT-TYPE
   SYNTAX DisplayString
   MAX-ACCESS accessible-for-notify
   STATUS
              current
   DESCRIPTION "value of MSCIID that triggered this event"
    ::= { modemNotifications 500 }
gpsFixNotification NOTIFICATION-TYPE
   OBJECTS { value }
   STATUS current
   DESCRIPTION
       "GPS Fix MSCIID 900"
::= { modemNotifications 17 }
vehicleSpeed NOTIFICATION-TYPE
   OBJECTS { value }
   STATUS current
   DESCRIPTION
       "Vehicle Speed MSCIID 905"
::= { modemNotifications 18 }
engineHoursNotification NOTIFICATION-TYPE
   OBJECTS { value }
   STATUS current
   DESCRIPTION
       "Engine Hours MSCIID 906"
::= { modemNotifications 19 }
headingChange NOTIFICATION-TYPE
   OBJECTS { value }
   STATUS current
   DESCRIPTION
```

```
"Heading Change MSCIID 904"
::= { modemNotifications 20 }
rssiNotification NOTIFICATION-TYPE
   OBJECTS { value }
   STATUS current
   DESCRIPTION
       "RSSI MSCIID 261"
::= { modemNotifications 21 }
networkStateNotification NOTIFICATION-TYPE
   OBJECTS { value }
   STATUS current
   DESCRIPTION
       "Network State MSCIID 259"
::= { modemNotifications 22 }
networkService NOTIFICATION-TYPE
   OBJECTS { value }
   STATUS current
   DESCRIPTION
       "Network Service 264"
::= { modemNotifications 23 }
networkErrorRate NOTIFICATION-TYPE
   OBJECTS { value }
   STATUS current
   DESCRIPTION
       "Network Error Rate MSCIID 263"
::= { modemNotifications 24 }
periodicReports NOTIFICATION-TYPE
   OBJECTS { value }
   STATUS current
   DESCRIPTION
```

```
"Periodic Reports MSCIID 270"
::= { modemNotifications 25 }
powerInNotification NOTIFICATION-TYPE
   OBJECTS { value }
   STATUS current
   DESCRIPTION
       "Power In MSCIID 266"
::= { modemNotifications 26 }
boardTemp NOTIFICATION-TYPE
   OBJECTS { value }
   STATUS current
   DESCRIPTION
       "Board Temperature MSCIID 267"
::= { modemNotifications 27 }
cdmaTemp NOTIFICATION-TYPE
   OBJECTS { value }
   STATUS current
   DESCRIPTION
       "CDMA Temperature MSCIID 641"
::= { modemNotifications 28 }
dailyDataUsage NOTIFICATION-TYPE
   OBJECTS
              { value }
   STATUS
              current
   DESCRIPTION
       "Daily Data Usage MSCIID 25001"
::= { modemNotifications 29 }
monthlyDataUsage NOTIFICATION-TYPE
   OBJECTS
              { value }
   STATUS
              current
```

```
DESCRIPTION
    "Monthly Data Usage MSCIID 25002"
    ::= { modemNotifications 30 }
```

END

>>> D: AT Commands

AT Command Set Summary

Note: If you are writing software to parse AT command responses, Sierra Wireless recommends that you design the software to be independent of the amount of whitespace. Whitespace is defined as ASCII space, tab, carriage return and linefeed characters and may appear in any combination, not necessarily containing all of the above.

Note: When using AT commands to change passwords or passphrases, the special character comma ',' cannot be used in the new password or passphrase.

Using a terminal connection (Telnet) or SSH protocol, you can send AT commands to configure the device, command it to do something, or query a setting.

- AT commands must always be terminated by a carriage return <CR> (ASCII character 0x0D), i.e., pressing Enter on the keyboard. Some may also include a new line or line feed <LF>.
- If E=1 (Echo On), the AT command (including the terminating <carriage return>) is displayed (output) before any responses.
- Two settings affect the format of AT command output: V (Verbose) and Q (Quiet).
- If Q=1 (Quiet On), no result codes are output whatsoever, so there is no response generated by a (non-query) command.
- If Q=0 (Quiet Off), result codes are output. The format of this output is then affected by the Verbose setting.

If Quiet mode is off, the result code is affected as follows:

For V=1 (Verbose mode), the textual result code is surrounded by a carriage return and new line. Any AT query response is also surrounded by a carriage return and new line.

For V=0 (Terse mode), a numeric result code is output with a single trailing carriage return (no new line is output), while any AT query response is followed by a carriage return and new line (there is no preceding output).

• For example, possible output to the AT command "AT" with carriage return (assuming quiet mode is not on) is:

```
carriage return-if V=0
```

carriage return and new line OK another carriage return and new line-if V=1

Note: AT commands work for the port on which they are executed. For example, if the user types ATE1 and then AT&W using a USB/serial port connection, it sets the USB/serial port to Echo On, but not the telnet connection or the RS232 serial port.

If you need to change the port for Telnet (for example, you have the default port blocked on your firewall), the option is on the Services > Telnet/SSH tab. The default Telnet port is 2332. You can also change the Telnet timeout; if the connection is idle, default timeout is 2 minutes. This is the internal Telnet on the device to pass AT commands and not TCP PAD.

AT commands are shown in upper case, but they are not case sensitive.

This appendix organizes the commands into functional groups to allow you to more quickly locate a desired command when you know the operation but not the command. Commands under each topic are listed alphabetically.

Note: Some of the configuration commands listed here are only available as AT commands.

Reference Tables

Result codes are not shown in the command tables unless special conditions apply. Generally the result code OK is returned when the command has been executed. ERROR may be returned if parameters are out of range, and is returned if the command is not recognized or is not permitted in the current state or condition of the AirLink RV55.

Note: Unless otherwise stated, all commands are accessible locally and remotely.

AT command topics in this appendix:

- Device Updates on page 468
- Status on page 470
- WAN/Cellular on page 476
- LAN on page 497
- Wi-Fi on page 499
- VPN on page 508
- Security on page 514
- Services on page 515
- Location on page 525
- Serial on page 532
- Standard (Hayes) commands on page 540
- I/O on page 547
- Applications on page 548
- Admin on page 553

Device Updates

Table D-1:	Device	Update AT	Commands
	201100	e paate / ti	•••••••

Command	Description
*FWRMUPDATE	This AT command updates the ALEOS software remotely. The ALEOS software file must be on an ftp server. The command parameters are: AT*FWRMUPDATE= <ftp ip="" server="">,<ftp server="" username="">,<ftp server<br="">password>,<aleos filename=""> Example: AT*FWRMUPDATE=192.168.17.111,MyUserName,v3yieo,GX_4.3.4.001v0.bin Error message: Firmware update failed: could not get file from FTP server—Firmware file does not exist; check that the file name was spelled correctly</aleos></ftp></ftp></ftp>
14	Query the Recovery version installed on the RV55 Example: ATI4? returns 2.0 - 31934
*RMSTORE	This AT command remotely loads the radio module firmware file using ftp, verifies and then copies the file in the radio module firmware store location. The radio module firmware file must be on an FTP server, and the file name must have the suffix .iso The command parameters are: AT*RMSTORE= <ftp hostname="" ip="" or="" server="">,<user>,<password>,<filepath> Where: <ftp hostname="" ip="" or="" server=""> is the resolvable hostname or IP address of the FTP server</ftp> <user> is the user name used to access the FTP server</user> <filepath> is the password used to access the FTP server</filepath> <filepath> is the full path to the file on the FTP server.</filepath> Example: AT*RMSTORE=192.168.17.111,MyUserName,password,MC7354_VZW004_55581.iso To query the list of files in storage: AT*RMSTORE? Example: AT*RMSTORE? MC7354_ATT004_55580.iso MC7354_SPT004_55581.iso MC7354_VZW004_55581.iso OK </filepath></password></user></ftp>

Command	Description
*RMFWSWITCH	This AT command switches the current radio module firmware to the radio module firmware specified by the AT command.
	The radio module firmware file must be stored on the RV55. For more information, see Radio Module Firmware on page 393.
	The command parameters are:
	AT*RMFWSWITCH= <network operator=""></network>
	Where:
	• <network operator=""> is the network operator associated with the radio module firmware to which you want to switch. For example, att, generic, etc. (case insensitive).</network>
	Example:
	AT*RMFWSWITCH=att
*TPLUPDATE	This AT command updates the template (configuration file) remotely.
	The template file must be accessible on an FTP server.
	The command parameters are:
	AT*TPLUPDATE= <server_ip>,<user_name>,<password>,<file_name></file_name></password></user_name></server_ip>
	where:
	• SERVER_IP is the IP address of the FTP server.
	USER_NAME is the user name used to access the FTP server.
	PASSWORD is the password used to access the FTP server.
	• FILE_NAME is the name of the template file on the FTP server that you want to apply to the AirLink RV55. The template file must be stored on the FTP User_Name home, not in a sub-folder.
	Example:
	AT*TPLUPDATE=192.168.17.111,MyUserName,MyPassword,NewTemplate.xml
	When the template is successfully applied, the message displayed is:
	Template applied successfully
	OK
	Note: Configure the FTP server:
	As passive mode (not active mode)
	To listen to port 21
	· · · · · · · · · · · · · · · · · · ·

 Table D-1: Device Update AT Commands

Status

Table D-2: Status AT Commands

Command	Description
*BAND?	Query the current radio module band. To set or query the setting for RF band range or technology, see .
*CELLINFO?	Query cellular connection information.
*CELLINFO2?	Query in depth cell information.
+CIMI?	HSPA and LTE only. Query the IMSI.
*DEVICEID?	When the device is configured to use the device ID with Location reports, this command displays the 64-bit device ID created from the ESN/IMEI or phone, preceded by the hex delimiter (0x). For example: at*deviceid? 0x010112DE140B5A32
	Note: If the device is not configured to use the device ID with Location reports, the command returns "NOT SET".
*DNS1? *DNS2?	Query the primary DNS (*DNS1) and secondary (*DNS2) IP addresses. AT*DNS1? to query DNS1 AT*DNS2? to query DNS2
+ECIO?	Query the signal quality.
*ESIMICCID?	Query the ICCID of the R2C eSIM (if present).
*ETHMAC?	 Query the MAC address of the Ethernet port. AT*ETHMAC? or AT*ETHMAC?1—Returns the MAC address of the main Ethernet port
*ETHSTATE?	 Query the connection state (speed and duplex) of the Ethernet port. AT*ETHSTATE? or AT*ETHSTATE?1—Returns the speed and duplex state of the main Ethernet port (e.g. 100Mb/s Full Duplex)
*SERIALNUM?	Query the serial number used by ALMS to identify the device.
*HOSTCOMMLVL?	Query the serial host signal level. Response example: DCD:LOW; DTR:LOW; DSR:HIGH; CTS:HIGH; RTS:LOW
+HWTEMP?	Query the internal temperature of the radio module (in degrees Celsius).
l[n]	Query device information. n omitted—device model n=0—device model n=1—ALEOS software version, hardware revision, boot version n=2—Radio module firmware version n=3—Radio module's unique ID (ESN, IMIEI, or EID)

Command	Description
+ICCID?	HSPA and LTE only. Query the SIM ID.
*INTSTATE?	Query the WAN connection status for a particular interface AT*INSTATE? <interface> interface=1—Cellular network interface=2—Wi-Fi network interface=3—Ethernet WAN network Returns the WAN connection status: Connected Not Connected No Service If no interface is specified, the command queries the cellular network.</interface>

 Table D-2:
 Status AT Commands

 Table D-2:
 Status AT Commands

 Table D-2:
 Status AT Commands

Command	Description
*LISTIP?	Query the IP/MAC address information for connected LAN devices. This AT command retrieves the information available on the IP/MAC table on the Status > LAN screen. AT*LISTIP? The response lists the IP address, the MAC address, and the status. Fields are separated by semi-colons. Example: 192.168.14.100;0e:c6:ff:b2:61:8f;active
*LTERSRQ?	LTE only. Query the LTE signal quality (in dB). For more information, see LTE Signal Quality (RSRQ) on page 45.
*LTERSRP?	LTE only. Query the LTE signal strength (in dBm). For more information, see LTE Signal Quality (RSRQ) on page 45.
*NETCHAN?	Query the current mobile network channel.
*NETCONNTYPE?	Query the current IP address type. AT*NETCONNTYPE? • 0—None • 1—IPv4 • 3—IPv4 and IPv6 Gateway Note: To set the IP address type preference, see *NETIPPREF on page 485.
NETIP?	Query the current WAN IP address of the device reported by the internal module (generally obtained from your Mobile Network Operator). If the device is connected in Wi-Fi Client mode, the Wi-Fi IP address is returned.If you have an Internet-routable IP address, you can use this address to contact devices from the Internet. If your device uses a different WAN (such as a Wi-Fi client) or is on a private mobile network, you can use this address to contact the device from another host on the same WAN network. If required, use AT*NETALLOWZEROIP to allow displaying an IP address ending in a zero.
*NETIPV6?	Query the current IPv6 network IP address of the device reported by the internal module (generally obtained from your Mobile Network Operator). If you have an Internet-routable IP address, you can use this address to contact devices from the Internet. If your device is on a private mobile network, you can use this address to contact the device from another host on the same WAN network. Note: If there is no current network IPv6 address, "::" (two colons) is returned.
*NETIPV6PREFIXLEN?	Query the length of the network IPv6 prefix. AT*NETIPV6PREFIXLEN? If there is no IPv6 connection, 0 is returned.

Command	Description
*NETOP?	Query the Mobile Network Operator of the active connection. If you are roaming, the roaming operator is returned, if the home operator allows this.
*NETPHONE?	Query the device's cellular phone number, if applicable or obtainable.
*NETRSSI?	Query the current RSSI (Receive Signal Strength Indicator) for non-LTE cellular connections, as a negative dBm value.
*NETSERV?	Query the current connection type (e.g., LTE, HSPA+, etc.).
*NETSERVICE_RAW?	Query the numeric value for the network service type. • 8—2G (GPRS) • 10—2G roaming • 16—3G (HSPA, HSPA+, UMTS) • 18—3G roaming • 64—4G
*NETSTATE?	 Query the network state of the current WAN connection. AT*NETSTATE? returns: Network Ready—The RV55 is connected to the WAN network and ready to send data. Network Ready - Wi-Fi—The RV55 is connected to a Wi-Fi network in client mode. Network Ready - Ethernet—The RV55 is connected to an Ethernet WAN network. Network Ready - Ethernet (Auto DHCP)—The RV55 has an Auto DHCP WAN Ethernet connection. Network Ready - eSIM Not Activated—The R2C eSIM has not been activated in ALMS. Network Ready - eSIM Activation State Unknown—The activation state is unknown. For more information, see Network State on page 37. Network Link Down — The network link is not available. No Service—There is no mobile network detected.
*NETSTATE_RAW?	 Query the network state of the current WAN connection. AT*NETSTATE_RAW? returns: 5—Network Ready (The RV55 is connected to the WAN network and ready to send data.) 29—Network Ready - Wi-Fi (The RV55 is connected to a Wi-Fi network in client mode.) 34—Network Ready - Ethernet (The RV55 is connected to an Ethernet WAN network.) 0—Network Link Down (The network link is not available.) 7—No Service (There is no mobile network detected.)
*SRVPLMN?	Query the PLMN of the currently attached network. AT*SRVPLMN?

 Table D-2:
 Status AT Commands

Command	Description
*USBNETSTATE?	 Query the status of the USB connection. AT*USBNETSTATE? returns: None—There are no USB connections to the AirLink RV55. 8 MB/s Half Duplex—There is a USB connection to the device.
*WANUPTIME?	Query the time in minutes from which the cellular IP is obtained from the mobile network. AT*WANUPTIME?

 Table D-2:
 Status AT Commands

WAN/Cellular

A reboot is required before the WAN/Cellular AT Commands described in the following table take effect.

For a complete alphabetical list of WAN/Cellular AT Commands, see Table D-4. The following table provides a summary of SIM-card-related AT Commands for gateways with more than one SIM card slot. Click the AT Command for a detailed description.

Command	What it does
*NBSIMPRESENT?	Queries the number of SIMs present
*SIM1PRESENT?	Queries whether or not there is a SIM card in slot 1 (upper slot)
*SIM2PRESENT?	Queries whether or not there is a SIM card in slot 2 (lower slot)
*ESIMPRESENT?	Queries whether or not there is an R2C eSIM card enabled
*ALLOWESIM	Queries or sets whether the RV55 is allowed to use the Ready to Connect eSIM for network connections.
*PRIMARYSIM	Queries or sets which slot contains the Primary SIM card
*SECONDARYSIM	Queries or sets which slot contains the Secondary SIM card
*ACTIVESIM?	Queries which slot contains the Active SIM
*SWITCHSIM	Switches the Active SIM to the one in the Target SIM slot
*TARGETSIM	For manual SIM switching, queries or sets the SIM slot that will become the Active SIM
*NETPW	Queries or sets the network password for the Active SIM
*NETPWSIM1	Queries or sets the network password for the SIM card in slot 1
*NETPWSIM2	Queries or sets the network password for the SIM card in slot 2
*NETPWESIM	Queries or sets the network password for the R2C eSIM
*NETUID	Queries or sets the network user ID for the Active SIM
*NETUIDSIM1	Queries or sets the network user ID for the SIM card in slot 1
*NETUIDSIM2	Queries or sets the network user ID for the SIM card in slot 2
*NETUIDESIM	Queries or sets the network user ID for the R2C eSIM
*NETAPN	Queries or sets the user-entered APN for the Active SIM
*SIM1NETAPN	Queries or sets the user-entered APN for the SIM card in slot 1
*SIM2NETAPN	Queries or sets the user-entered APN for the SIM card in slot 2
*ESIMNETAPN	Queries or sets the user-entered APN for the R2C eSIM
*SIMPINENABLE	Queries, enables, or disables the ALEOS SIM PIN feature for the Active SIM. When enabled, ALEOS automatically enters the SIM PIN requested by the SIM card when the gateway starts up.

Table D-3: Summary of SIM Card AT Commands

Command	What it does
*SIM1PINENABLE	Queries, enables, or disables the ALEOS SIM PIN feature for the SIM card in slot 1. When enabled, ALEOS automatically enters the SIM PIN requested by the SIM card when the gateway starts up.
*SIM2PINENABLE	Queries, enables, or disables the ALEOS SIM PIN feature for the SIM card in slot 2. When enabled, ALEOS automatically enters the SIM PIN requested by the SIM card when the gateway starts up.
*SIMPIN	Sets the SIM PIN that ALEOS automatically enters for the Active SIM if the ALEOS SIM PIN feature is enabled. This should match the SIM PIN set on the SIM card, either by the mobile network operator or by using *CHGSIMPIN.
*SIM1PIN	Sets the SIM PIN that ALEOS automatically enters for the SIM card in slot 1 if the ALEOS SIM PIN feature is enabled. This should match the SIM PIN set on the SIM card, either by the mobile network operator or by using *CHGSIMPIN.
*SIM2PIN	Sets the SIM PIN that ALEOS automatically enters for the SIM card in slot 2 if the ALEOS SIM PIN feature is enabled. This should match the SIM PIN set on the SIM card, either by the mobile network operator or by using *CHGSIMPIN.
*ENASIMPIN	Queries, enables, or disables the PIN lock on the Active SIM card.
*CHGSIMPIN	Changes the PIN on the Active SIM card if the PIN lock is enabled

Table D-3: Summary of SIM Card AT Commands

Table D-4: WAN/Cellular AT Commands

Command	Description
*ACTIVESIM?	 Query the Active SIM card, i.e., which SIM card is currently being used for the data connection. AT*ACTIVESIM? to query 1—The SIM card in slot 1 (upper slot) is the Active SIM. 2—The SIM card in slot 2 (lower slot) is the Active SIM. 3—The R2C eSIM is the Active SIM
!BAND	Query or set the RF band range or technology. AT!BAND? to query the current setting AT!BAND=n to set at the next reboot. • n=00—All Bands • n=01—Europe 3G • n=02—North America 3G • n=06—Europe • n=07—North America • n=08—WCDMA ALL • n=09—LTE ALL For a list of bands supported in each group, see Setting for Band on page 567.

Command	Description
*BANDMODE	Query or set the Bandwidth Throttle mode. AT*BANDMODE? to query AT*BANDMODE=n to set • n=0—Disable • n=1—Enable
+CGDCONT	 HSPA only. Query or set the PDP context, APN, and other information required to establish a connection to o an HSPA network. You only need to configure this once. The parameters are saved and used each time a connection is made to the HSPA network. AT+CGDCONT? to query AT+CGDCONT = PID,PDP_TYPE,APN [,IPADDR] to set PID = PDP context identifier PDP_TYPE = numeric parameter that specifies a PDP context definition APN = Access Point Name IPADDR = IP address Examples: AT+CGDCONT=1,IP,proxy AT+CGDCONT=1,IP,internet
	Note: When using the APN-related optons in ACEmanager, you generally do not need to configure +CGDCONT.
*CHGSIMPIN	This command changes the SIM PIN on the Active SIM card. To change the SIM PIN ALEOS requests as part of the ALEOS SIM PIN feature, see *SIMPIN on page 492. AT*CHGSIMPIN= <old pin="">,<newpin> Note: To enable or disable the SIM PIN lock, see *ENASIMPIN on page 482. For more information, see SIM PIN on page 100.</newpin></old>
*CIOTWBEN	WP7702-equipped devices only. Query or set LTE Wideband Operation. AT*CIOTWBEN? to query AT*CIOTWBEN=n to set • n=0—Disable • n=1—Enable
*CIOTM1EN	WP7702-equipped devices only. Query or set LTE Cat-M1 Operation. AT*CIOTM1EN? to query AT*CIOTM1EN=n to set • n=0—Disable • n=1—Enable

Table D-4: WAN/Cellular AT Commands

Command	Description
*CIOTNBEN	WP7702-equipped devices only. Query or set LTE NB-IoT Operation. AT*CIOTNBEN? to query AT*CIOTNBEN=n to set • n=0—Disable • n=1—Enable
*CLIENT_PPP_AUTH	Query or set the Force Network Authentication mode. AT*CLIENT_PPP_AUTH? to query AT*CLIENT_PPP_AUTH=n to set • n=0—None • n=1—PAP • n=2—CHAP Examples: *ATCLIENT_PPP_AUTH? 1 OK *ATCLIENT_PPP_AUTH=2 OKIf this command is used with an AirLink RV55, the query or set applies to the Active SIM. Use *CLIENT_PPP_AUTHSIM1 or *CLIENT_PPP_AUTHSIM2 to query or set a specific SIM card, based on the slot it is installed in.
*CLIENT_PPP_AUTHSIM1	Query or set the Force Network Authentication mode for the SIM card in Slot 1 (upper slot). AT*CLIENT_PPP_AUTHSIM1? to query AT*CLIENT_PPP_AUTHSIM1=n to set • n=0None • n=1PAP • n=2CHAP Examples: *ATCLIENT_PPP_AUTHSIM1? 1 OK *ATCLIENT_PPP_AUTHSIM1=2 OK

Command	Description
*CLIENT_PPP_AUTHSIM2	Query or set the Force Network Authentication mode for the SIM card in Slot 2 (lower slot). AT*CLIENT_PPP_AUTHSIM2? to query AT*CLIENT_PPP_AUTHSIM2=n to set • n=0—None • n=1—PAP • n=2—CHAP Examples: *ATCLIENT_PPP_AUTHSIM2? 1 OK *ATCLIENT_PPP_AUTHSIM2=0 OK
*CLIENT_PPP_AUTHESIM	Query or set the Force Network Authentication mode for the R2C eSIM (if available). AT*CLIENT_PPP_AUTHESIM? to query AT*CLIENT_PPP_AUTHESIM=n to set • n=0—None • n=1—PAP • n=2—CHAP Examples: *ATCLIENT_PPP_AUTHESIM? 1 OK *ATCLIENT_PPP_AUTHESIM=0 OK

 Table D-4:
 WAN/Cellular AT Commands

Command	Description
+COPS	HSPA only. Query or set the network operator and the connection mode. AT+COPS? to query AT+COPS=? to retrieve a list of operators available to the radio AT+COPS=MODE[,FORMAT[,OPER]] to set MODE • MODE=0—Automatic (default) • MODE=1—Manual • MODE=4—Manual/Automatic; if manual failed, it defaults to automatic FORMAT • FORMAT=0—Alphanumeric ("Name") • FORMAT=2—Numeric OPER • OPER= the operator numeric code Example, AT+COPS=1,2,302610 Manual mode, numeric format, operator code 302610
	Note: On some mobile networks, explicit use of +COPS allows you to select the roaming Mobile Network Operator to use.
*DOWNBAND	 Query or set the maximum downlink bandwidth. AT*DOWNBAND? to query AT*DOWNBAND=n to set n = 0—Bandwidth Throttle is disabled for downlink traffic n=1-512000—Maximum downlink bandwidth in Kilobits per second (Kbps). This is the long-term bandwidth limit. Default value is 25600.
*DOWNBURST	 Query or set the maximum size for bursts of downlink traffic. AT*DOWNBURST? to query AT*DOWNBURST=n to set n=64-512000—Maximum size for bursts of downlink traffic in Kilobits (Kb). This allows the RV55 to handle temporary bursts of traffic without dropping packets. When the actual downlink traffic is less than the value configured in *DOWNBAND, ALEOS collects credits that can be used for bursty traffic. The value configured here is the maximum amount of credit that can be collected. Default value is 51200.
	Note: Sierra Wireless recommends that the Maximum Downlink Burst Size be set at 2× the value configured in the *DOWNBAND field. If the Maximum Downlink Burst Size is set at more than 60× the value configured in the *DOWNBAND field, the bandwidth throttle feature is disabled for downlink traffic.
*DOWNBYTES?	Query the number of downlink bytes received. AT*DOWNBYTES? The value is updated every 30 seconds, and is reset to zero on RV55 reboot or reset to factory default settings.

Command	Description
*DOWNDROPPED?	Query the number of downlink packets dropped because the limit set in *DOWNBAND and *DOWNBURST have been exceeded.
	AT*DOWNDROPPED?
	The value is updated every 30 seconds, and is reset to zero on RV55 reboot or reset to factory default settings.
*DOWNPACKETS?	Query the number of downlink packets received. AT*DOWNPACKETS?
	The value is updated every 30 seconds, and is reset to zero on RV55 reboot or reset to factory default settings.
*EDRXEN	WP7702-equipped devices only.
	Query or set the Extended Discontinuous Reception (extended sleep mode or eDRX) setting.
	AT*EDRXEN? to query
	AT*EDRXEN=n to set
	• n=0—Disable
	n=1—Enable
*ENASIMPIN	Query, enables or disables the SIM PIN lock on the Active SIM card, When enabled, the SIM card requests this PIN when the RV55 boots up. (If the ALEOS SIM PIN feature is also enabled, the PIN will be entered automatically. This is useful if the RV55 is at a location where no one is available to enter the PIN. For more information see Enable the SIM PIN on page 100 and *SIMPINENABLE on page 493.)
	AT*ENASIMPIN? to query
	• 0—SIM PIN is not required at boot.
	1—SIM PIN Is required at boot.
	AT*ENASIMPIN= <lock>,<pin> to set, where:</pin></lock>
	• <lock> = 0—SIM PIN is not required at boot.</lock>
	 <lock> = 1—SIM PIN Is required at boot.</lock>
	<pin> = The current PIN</pin>
*ETHWAN_IPMODE	Query or set the Ethernet WAN IP mode
	AT*ETHWAN_IPMODE? to query
	AT*ETHWAN_IPMODE=n to set
	• 0—Dynamic
	• 1—Static
*ETHWAN_STATICDNS1 *ETHWAN_STATICDNS2	Query or set the static IP address for the primary or secondary Ethernet WAN DNS server
_	AT*ETHWAN_STATICDNS1? to query the IP address for the primary DNS server AT*ETHWAN_STATICDNS2? to query the IP address for the secondary DNS server AT*ETHWAN_STATICDNS1=n.n.n.n to set the IP address for the primary DNS server
	AT*ETHWAN_STATICDNS2=n.n.n.n to set the IP address for the secondary DNS server
	AT*ETHWAN_STATICDNS1=208.67.222.222

Table D-4: WAN/Cellular AT Commands

Command	Description
*ETHWAN_STATICGTWY	Query or set the static IP address for the Ethernet WAN router AT*ETHWAN_STATICGTWY? to query AT*ETHWAN_STATICGTWY=n.n.n.n to set Example: AT*ETHWAN_STATICGTWY=208.81.123.254
*ETHWAN_STATICIP	Query or set the static IP address for the AirLink RV55 AT*ETHWAN_STATICIP? to query AT*ETHWAN_STATICIP=n.n.n.n to set Example: AT*ETHWAN_STATICIP=208.81.123.34
*ETHWAN_STATICMASK	Query or set the subnet mask for the AirLink RV55 static IP address AT*ETHWAN_STATICMASK? to query AT*ETHWAN_STATICMASK=n.n.n.n to set Example: AT*ETHWAN_STATICMASK=255.255.255.0
*IPPINGSEC	Query or set the ping monitor test interval (in seconds) for an interface. AT*IPPINGSEC? <interface> to query the ping monitor test interval interface=1—Cellular network interface=2—Wi-Fi network interface=3—Ethernet WAN network AT*IPPINGSEC=<interface>,n to set the ping monitor test interval for an interface interface=1—Cellular network interface=2—Wi-Fi network interface=3—Ethernet WAN network network interface=3—Ethernet WAN network Interface=3—Ethernet WAN network If no interface is specified, the command applies to the cellular network.</interface></interface>
*IPPINGADDR	Query or set the ping monitor IP address or FQDN for an interface when the ping monitor test interval (*IPPINGSEC) is set. AT*IPPINGADDR? <interface> to query interface=1—Cellular network interface=2—Wi-Fi network interface=3—Ethernet WAN network AT*IPPINGADDR=<interface>,d.d.d.d or n to set interface=1—Cellular network interface=2—Wi-Fi network interface=3—Ethernet WAN network interface=3—Ethernet WAN network d.d.d.d=IP address n=domain name If no interface is specified, the command applies to the cellular network. <i>Note: AT*IPPINGSEC must to be set to a value other than 0 to enable pinging.</i></interface></interface>

Command	Description
*MONITORTYPE	Query or set the monitor type that is enabled on each interface. AT*MONITORTYPE? <interface> to query interface=1—Cellular network interface=2—Wi-Fi network interface=3—Ethernet WAN network AT*MONITORTYPE=<interface>,n to set interface=1—Cellular network interface=2—Wi-Fi network interface=3—Ethernet WAN network n=0—Disable n=1—Enable If no interface is specified, the command applies to the cellular network.</interface></interface>
*MSNOSERVICETOUT	Query or set the time in minute before switching to the inactive SIM card if there is no longer service on the current SIM card. AT*MSNOSERVICETOUT? to query AT*MSNOSERVICETOUT= <n> to set • <n>=10-255• <n>=0—feature is disabled (default)</n></n></n>
*MSSECONDARYTOUT	Query or set the time in minute before switching to the primary SIM card if the gateway is connected to the network using the secondary SIM card. AT*MSSECONDARYTOUT? to query AT*MSSECONDARYTOUT= <n> to set <n>=10-255</n> <n>=0—feature is disabled (default)</n> </n>
*MSROAMINGTOUT	Query or set the time in minute before switching to the inactive SIM card if active SIM card if active SIM card is roaming. AT*MSROAMINGTOUT? to query AT*MSROAMINGTOUT= <n> to set <n>=10-255</n> <n>=0—feature is disabled (default)</n> </n>
*MSSCANTOUT	Query or set the time in minute before switching to the inactive SIM if the gateway is unable to connect to the network. AT*MSSCANTOUT? to query AT*MSSCANTOUT= <n> to set <n>=10-255<n>=0—feature is disabled (default)</n></n></n>

Command	Description
*NBSIMPRESENT?	Query the number of SIM cards installed in the gateway. AT*NBSIMPRESENT? to query Example: AT*NBSIMPRESENT? <number cards="" of="" present="" sim=""> OK</number>
	Response: • 1—One SIM card installed • 2—Two SIM cards installed • 3—Two SIM cards installed, and R2C eSIM present
*NETALLOWZEROIP	Query or set allowing the device to get an IP address from the mobile network that has the last octet as 0 (zero). AT*NETALLOWZEROIP? to query AT*NETALLOWZEROIP=n to set • n=0—Do not allow • n=1—Allow Allows the device to use a WAN IP address that ends in zero (e.g. 192.168.1.0).
*NETAPN	Query or set the user entered APN. AT*NETAPN? to query AT*NETAPN= <apn> to set (up to 80 characters) Examples: AT*NETAPN? <apn> OK AT*NETAPN=<apn> OK When you set this command, the APN type is automatically set to User Entry so that the APN you enter with this AT command is used on reboot. If this command is used</apn></apn></apn>
*NETIPPREF	with an AirLink RV55, the query or set applies to the Active SIM. Use *SIM1NETAPN or *SIM2NETAPN to query or set a specific SIM card, based on the slot it is installed in. Query or set the IP Address Preference.
	Note: To use IPv6, it must be supported by your Mobile Network Operators and your account (SIM and APN). AT*NETIPPREF? to query AT*NETIPPREF=n to set • n=0—IPv4 • n=1—IPv4 and IPv6 Gateway To determine the current network IP type, see *NETCONNTYPE? on page 473.

Command	Description
*NETPW	Query or set the mobile network account password. AT*NETPW? to query AT*NETPW= <password> to set (up to 128 characters)</password>
	Note: AT*NETPW? returns asterisks (****) for privacy.
	Examples: ATNETPW? ******
	OK AT*NETPW= <password> OKIf this command is used with an AirLink RV55, the query or set applies to the Active SIM. Use *NETPWSIM1 or *NETPWSIM2 to query or set a specific SIM card, based on the slot it is installed in.</password>
*NETPWSIM1	Query or set the mobile network account password for the SIM card in Slot 1 (upper slot). AT*NETPWSIM1? to query AT*NETPWSIM1= <password> to set (up to 128 characters)</password>
	Note: AT*NETPWSIM1? returns asterisks (****) for privacy.
	Examples: ATNETPWSIM1? ******
	OK AT*NETPWSIM1= <password> OK</password>
*NETPWSIM2	Query or set the mobile network account password for the SIM card in Slot 2 (lower slot). AT*NETPWSIM2? to query AT*NETPWSIM2= <password> to set (up to 128 characters)</password>
	Note: AT*NETPW? returns asterisks (****) for privacy.
	Examples: ATNETPWSIM2? *****
	OK AT*NETPWSIM2= <password> OK</password>

Table D-4: WAN/Cellular AT Commands

Table D-4:	WAN/Cellular	AT Commands
------------	--------------	-------------

Command	Description
*NETPWESIM	Query or set the mobile network account password for the R2C eSIM (if available). AT*NETPWESIM? to query AT*NETPWESIM= <password> to set (up to 128 characters)</password>
	Note: AT*NETPW? returns asterisks (****) for privacy.
	Examples: ATNETPWESIM? ******
	OK AT*NETPWESIM= <password> OK</password>
*NETUID	Query or set the mobile network account user ID, if required. AT*NETUID? to query • AT*NETUID= <uid>(up to 128 characters) AT*NETUID? <uid> OK AT*NETUID=<uid> OKIf this command is used with an AirLink RV55, the query or set applies to the</uid></uid></uid>
	Active SIM. Use *NETUIDSIM1 or *NETUIDSIM2 to query or set a specific SIM card, based on the slot it is installed in.
*NETUIDSIM1	Query or set the mobile network account user ID for the SIM card in Slot 1 (upper slot). AT*NETUIDSIM1? to query AT*NETUIDSIM1= <uid> (up to 128 characters) Examples: AT*NETUIDSIM1? <uid></uid></uid>
	OK AT*NETUIDSIM1= <uid> OK</uid>

Command	Description	
*NETUIDSIM2	Query or set the mobile network account user ID for the SIM card in Slot 2 (lower slot). AT*NETUIDSIM2? to query AT*NETUIDSIM2= <uid> (up to 128 characters) Examples: AT*NETUIDSIM2? <uid> OK AT*NETUIDSIM2=<uid> OK</uid></uid></uid>	
*NETUIDESIM	Query or set the mobile network account user ID for the R2C eSIM (if available). AT*NETUIDESIM? to query AT*NETUIDESIM= <uid> (up to 128 characters) Examples: AT*NETUIDESIM? <uid> OK AT*NETUIDESIM=<uid> OK</uid></uid></uid>	
*NWDOGTIME	Query or set the interval that the network connection watchdog waits for a cellular or W-Fi WAN connection. If no connection is established within this interval, the device resets. AT*NWDOGTIME? to query AT*NWDOGTIME=n to set Accepted values: • n=0—Disable • n=5—5 Minutes • n=15—15 Minutes • n=15—15 Minutes • n=30—30 Minutes • n=45—45 Minutes • n=60—1 Hour • n=120—2 Hours (default) • n=180—3 Hours • n=240—4 Hours <i>Note: This AT Command replaces AT*NETWDOG.</i>	

 Table D-4:
 WAN/Cellular AT Commands

Command	Description
PING	Sends 5 PING to a single address. Returns OK if there is a response: ERROR if there is no response. ATPING[ip address or FQDN]
	Note: Do not use an equal sign (=) when issuing the command.
	Example: ATPINGsierrawireless.com
*PRIMARYSIM	Query or set which SIM slot contains the primary SIM card. If multiple SIM cards are installed, the Primary SIM card is used for network connections.*PRIMARYSIM? to query*PRIMARYSIM= <slot number=""> to set• <slot number="">=1—Primary SIM card is in slot 1 (upper slot)• <slot number="">=2—Primary SIM card is in slot 2 (lower slot)• <slot number="">=3—Primary SIM card is R2C eSIMExamples: AT*PRIMARYSIM? <slot number="">OK AT*PRIMARYSIM=<slot number="">OK</slot></br></slot></slot></slot></slot></slot>
	The change takes effect after a reboot.
*SECONDARYSIM	Query or set which SIM slot contains the secondary SIM card. If multiple SIM cards are installed, the secondary SIM card is the second choice to use for network connections. *SECONDARYSIM? to query *SECONDARYSIM= <slot number=""> to set • <slot number="">=1—Secondary SIM card is in slot 1 (upper slot) • <slot number="">=2—Secondary SIM card is in slot 2 (lower slot) • <slot number="">=3—Secondary SIM card is R2C eSIM Examples: AT*SECONDARYSIM? <slot number=""></slot></slot></slot></slot></slot>
	OK AT*SECONDARYSIM= <slot number=""></slot>
	OK The change takes effect after a reboot.

Command	Description
*RADIO_CONNECT	 This AT Command applies only to International devices on the Vodafone network. Query or set the wireless connection setting. AT*RADIO_CONNECT? to query AT*RADIO_CONNECT=n to set n=0—Disables data traffic. The only way to change this mode is to issue a radio_connect=1 or radio_connect=2 AT command. n=1—Enables Always on connection. n=2—Disables Always on connection. The device listens for outgoing traffic and establishes a mobile network data connection for a specified time: When there is outgoing traffic or When it receives a Wakeup SMS, provided Wakeup SMS is configured. (Use *TRAFWUPTOUT on page 495 to set the timeout period.)
	Note: This command is not persistent over device resets. Note: You can only send this command locally over a serial, serial USB, or local telnet/SSH connection.
*RADIO_CONNECT_ STARTUP	 This AT Command applies only to International devices on the Vodafone network. You can query this command remotely or locally, but it can only be set locally. This command is the same as *RADIO_CONNECT, except The change does not take effect until the next reboot. The setting is persistent over subsequent reboots.
*RXDIVERSITY (3G Only)	Query or set the RX Diversity setting. Rx Diversity allows you to use two antennas to provide a more reliable connection. If you are not using a diversity antenna, Rx Diversity should be disabled. AT*RXDIVERSITY? to query AT*RXDIVERSITY=n to set • n=0—Disable • n=1—Enable Note: Two antennas are required when connecting to an LTE network.
	Note: This AT Command is not available for all AirLink RV55s.

Table D-4:	WAN	/ Cellular	AT	Commands
------------	-----	------------	----	----------

Command	Description
*SIM1NETAPN	Query or set the override APN for the SIM card in SIM slot 1 (upper slot). *SIM1NETAPN? to query *SIM1NETAPN= <apn> to set the APN (up to 80 characters) Examples: AT*SIM1NETAPN? <apn></apn></apn>
	OK AT*SIM1NETAPN= <apn> OK Note: When you set this command, the APN type is automatically set to Override</apn>
*SIM2NETADN	APN so that the APN you enter with this AT command is used on reboot.
*SIM2NETAPN	Query or set the override APN for the SIM card in SIM slot 2 (lower slot). *SIM2NETAPN? to query *SIM2NETAPN= <apn> to set the APN (up to 80 characters) Examples: AT*SIM2NETAPN? <apn> OK AT*SIM2NETAPN=<apn> OK</apn></apn></apn>
	Note: When you set this command, the APN type is automatically set to Override APN so that the APN you enter with this AT command is used on reboot.
*ESIMNETAPN	Query or set the override APN for the R2C eSIM (if available). *ESIMNETAPN? to query *ESIMNETAPN= <apn> to set the APN (up to 80 characters) Examples: AT*ESIMNETAPN? <apn></apn></apn>
	OK AT*ESIMNETAPN= <apn> OK</apn>
	Note: When you set this command, the APN type is automatically set to Override APN so that the APN you enter with this AT command is used on reboot.

Command	Description
*SIM1NETBLANKAPN	Query or set the Blank APN setting for SIM slot 1 (upper slot). Enabling blank APN allows the RV55 to connect to a network using a blank APN. AT*SIM1NETBLANKAPN? to query AT*SIM1NETBLANKAPN=n to set • n=0—Disable • n=1—Enable
*SIM2NETBLANKAPN	Query or set the Blank APN setting for SIM slot 2 (lower slot). Enabling blank APN allows the RV55 to connect to a network using a blank APN. AT*SIM2NETBLANKAPN? to query AT*SIM2NETBLANKAPN=n to set • n=0—Disable • n=1—Enable
*ESIMNETBLANKAPN	Query or set the Blank APN setting for R2C eSIM (if available). Enabling blank APN allows the RV55 to connect to a network using a blank APN. AT*ESIMNETBLANKAPN? to query AT*ESIMNETBLANKAPN=n to set • n=0—Disable • n=1—Enable
*SIMPIN	Sets the SIM PIN that ALEOS automatically entered if the ALEOS SIM PIN feature is enabled. This should match the SIM PIN set on the SIM card, either by the mobile network operator or by using *CHGSIMPIN. See *CHGSIMPIN on page 478. AT*SIMPIN= <pin> to enter the SIM pin Example: AT*SIMPIN=<pin> OKFor the AirLink RV55, this command sets the Active SIM. Use *SIM1PIN or *SIM2PIN to set a specific SIM card, based on the slot it is installed in.</pin></pin>
*SIM1PIN	Sets the SIM PIN that ALEOS automatically entered for the SIM in slot 1 if the ALEOS SIM PIN feature is enabled (and if R2C eSIM is available). This should match the SIM PIN set on the Active SIM card, either by the mobile network operator or by using *CHGSIMPIN. See *CHGSIMPIN on page 478. *SIM1PIN= <pin> to enter the SIM PIN Example: AT*SIM1PIN=<pin> OK</pin></pin>
*SIM2PIN	Sets the SIM PIN that ALEOS automatically entered for the SIM in slot 2 if the ALEOS SIM PIN feature is enabled. This should match the SIM PIN set on the Active SIM card, either by the mobile network operator or by using *CHGSIMPIN. See *CHGSIMPIN on page 478. *SIM2PIN= <pin> to enter the SIM PIN Example: AT*SIM2PIN=<pin> OK</pin></pin>

Table D-4: WAN/Cellular AT Commands

Command	Description
*SIMPINENABLE	Query, enable, or disable the ALEOS SIM PIN feature. When enabled, ALEOS automatically enters the SIM PIN requested by the SIM card on boot up. This is useful if the RV55 is at a location where no one is available to enter the PIN. AT*SIMPINENABLE? to query AT*SIMPINENABLE= <setting> to set • <setting>=0—Don't change • <setting>=1—Enable (SIM pin required on startup) • <setting>=2—Disable AT*SIMPINENABLE? <setting> OK AT*SIMPINENABLE=<setting> OK If this command is used with an AirLink RV55, the query or set applies to the Active SIM. Use *SIMPINENABLE or *SIM2PINENABLE to query or set a specific SIM</setting></setting></setting></setting></setting></setting>
	card, based on the slot it is installed in. To enable or disable the SIM PIN lock on the SIM card, see *ENASIMPIN on page 482.
*SIM1PINENABLE	Query, enable, or disable the ALEOS SIM PIN feature for the SIM card in SIM slot 1 (upper slot). When enabled, ALEOS automatically enters the SIM PIN requested by the SIM card on boot up. This is useful if the gateway is at a location where no one is available to enter the PIN. AT*SIM1PINENABLE? to query AT*SIM1PINENABLE= <setting> to set • <setting>=0—Don't change • <setting>=1—Enable (SIM pin required on startup) • <setting>=2—Disable AT*SIM1PINENABLE? <setting></setting></setting></setting></setting></setting>
	OK AT*SIM1PINENABLE= <setting> OK</setting>

Command	Description
*SIM2PINENABLE	Query, enable, or disable the ALEOS SIM PIN feature for the SIM card in SIM slot 2 (lower slot). When enabled, ALEOS automatically enters the SIM PIN requested by the SIM card on boot up. This is useful if the gateway is at a location where no one is available to enter the PIN. AT*SIM2PINENABLE? to query AT*SIM2PINENABLE= <setting> to set • <setting>=0—Don't change • <setting>=1—Enable (SIM pin required on startup) • <setting>=2—Disable AT*SIM2PINENABLE? <setting> OK</setting></setting></setting></setting></setting>
*SIM1PRESENT?	Query whether or not there is a SIM card installed in SIM slot 1.
	AT*SIM1PRESENT? to query • 0—No SIM card in slot 1 • 1—SIM card present in slot 1 Examples: AT*SIM1PRESENT? <slot 1="" sim="" status=""> OK</slot>
*SIM2PRESENT?	
SIMZPRESENT	Query whether or not there is a SIM card installed in SIM slot 2. AT*SIM2PRESENT? to query • 0—No SIM card in slot 2 • 1—SIM card present in slot 2 Examples: AT*SIM2PRESENT? <slot 2="" sim="" status=""></slot>
	OK
*ESIMPRESENT?	Query whether or not there is an R2C eSIM present. AT*ESIMPRESENT? to query • 0—No R2C eSIM present • 1—R2C eSIM present Examples: AT*ESIMPRESENT? <r2c esim="" status=""></r2c>
	OK

Table D-4:	WAN/Cellular	AT Commands
------------	--------------	-------------

Command	Description
*ALLOWESIM	Query or set whether the RV55 is allowed to use the Ready to Connect eSIM for network connections (if supported). AT*ALLOWESIM? to query • 0—R2C eSIM disabled • 1—R2C eSIM enabled AT*ALLOWESIM=n to set • n=0—Disable R2C eSIM (default) • n=1—Enable R2C eSIM
*TARGETSIM	Query or set which inactive SIM will be the active SIM card after the *SWITCHSIM command. AT*TARGETSIM? to query 1—SIM Slot 1 2—SIM Slot 2 3—R2C eSIM AT*TARGETSIM=n to set n=1—SIM Slot 1 n=2—SIM Slot 2 n=3—R2C eSIM
*SWITCHSIM	Change which SIM card slot contains the active SIM card. If there is no SIM card in the inactive SIM card slot, an error message ("SIM Switching impossible, no SIM in inactive slot") is returned. A reboot is not required. AT*SWITCHSIM switches the active SIM to the Target SIM card slot To determine whether or not there is a SIM card in the inactive SIM card slot, use *SIM2PRESENT?, *SIM1PRESENT? or *ESIMPRESENT?.
*TRAFWUPTOUT	This AT Command applies only to International devices on the Vodafone network. Query or set the timeout period after which, if there is no outgoing WAN traffic, the connection is terminated. The timeout period only takes effect if *RADIO_CONNECT or *RADIO_CONNECT_ STARTUP is set to 1, or Always on connection is disabled in ACEmanager. (See Always on connection on page 94). AT*TRAFWUPTOUT? to query AT*TRAFWUPTOUT=n to set • n=2-65535 minutes (default is 2) Note: This timer is reset to zero each time a WAN packet goes out.
*UPBAND	 Query or set the maximum uplink bandwidth. AT*UPBAND? to query AT*UPBAND=n to set n=0—Bandwidth Throttle is disabled for uplink traffic n=1-204800—Maximum uplink bandwidth in Kilobits per second (Kbps). This is the long-term bandwidth limit. Default value is 12288.

Command Description	
*UPBURST	 Query or set the maximum size for bursts of uplink traffic. AT*UPBURST? to query AT*UPBURST=n to set n=32-204800—Maximum size for bursts of uplink traffic in Kilobits (Kb). This allows the RV55 to handle temporary bursts of traffic without dropping packets. When the actual uplink traffic is less than the value configured in *UPBAND, ALEOS collects credits that can be used for bursty traffic. The value configured here is the maximum amount of credit that can be collected. Default value is 24576.
	Note: Sierra Wireless recommends that the Maximum Uplink Burst Size be set at 2× the value configured in the *UPBAND field. If the Maximum Uplink Burst Size is set at more than 60× the value configured in the *UPBAND field, the bandwidth throttle feature is disabled for uplink traffic.
*UPBYTES?	Query the number of uplink bytes sent. AT*UPBYTES? The value is updated every 30 seconds, and is reset to zero on RV55 reboot or reset to factory default settings.
*UPDROPPED?	Query the number of uplink packets dropped because the limit set for Bandwidth Throttle in *UPBAND and *UPBURST have been exceeded. AT*UPDROPPED? The value is updated every 30 seconds, and is reset to zero on RV55 reboot or reset to factory default settings.
*UPPACKETS?	Query the number of uplink packets sent. AT*UPPACKETS? The value is updated every 30 seconds, and is reset to zero on RV55 reboot or reset to factory default settings.

 Table D-4:
 WAN/Cellular AT Commands

LAN

Note: A reboot is required before these commands take effect.

Table D-5: LAN AT Commands

Command	Description
*DHCPHOSTEND	Query or set the ending IP address for the Ethernet DHCP pool. AT*DHCPHOSTEND? to query AT*DHCPHOSTEND=d.d.d.d to set • d.d.d.d=last IP address in Ethernet DHCP pool
*DHCPNETMASK	Query or set the Ethernet DHCP subnet mask. AT*DHCPNETMASK? to query AT*DHCPNETMASK=d.d.d.d to set • d.d.d.d=Ethernet DHCP subnet mask
*DHCPSERVER	Query or set the Ethernet DHCP server. AT*DHCPSERVER? to query AT*DHCPSERVER=n to set the DHCP server mode • n=0—Disable • n=1—Server • n=2—Auto For a description of the settings, see DHCP Mode on page 154.
*DNS1? *DNS2?	Query the primary DNS (*DNS1) and secondary (*DNS2) IP addresses. AT*DNS1? to query DNS1 AT*DNS2? to query DNS2
*DNSUSER	Query or set the first alternate server for DNS override. (Applies only to primary DNS.) AT*DNSUSER? to query AT*DNSUSER=d.d.d.d • d.d.d.d=IP address of domain server
*ETHMODE	Query or set the Ethernet port mode AT*ETHMODE? to query AT*ETHMODE=n to set • n = 0—Auto • n = 1—LAN • n = 2—WAN
*HOSTAUTH	Query or set the Host Authentication mode for PPPoE only. (It does not set host authentication for PPP/DUN.) AT*HOSTAUTH? to query AT*HOSTAUTH=n to set • n=0—None/Disables authentication for PPPoE (default). • n=1—Authentication through PAP • n=2—Authentication through PAP & CHAP

Command	Description
*HOSTPEERIP	Query or set the IP address of the device's Ethernet port. By default this is 192.168.13.31.
	Note: Any connected LAN device can access this IP addresses, whether using a private or public IP address. This IP address must be in the same subnet as the Ethernet DHCP pool.
	AT*HOSTPEERIP? to query AT*HOSTPEERIP=d.d.d.d to set • d.d.d.d=local or peer IP address of the device
*HOSTPRIVIP	Query or set the starting IP for the Ethernet DHCP pool. AT*HOSTPRIVIP? to query AT*HOSTPRIVIP=d.d.d.d to set • d.d.d.d=IP Address
*HOSTPRIVMODE	 Activate IP passthrough to the selected interface or query the IP passthrough setting. AT*HOSTPRIVMODE? to query AT*HOSTPRIMODE=n to activate IP Passthrough to the selected interface n=0—IP passthrough on Ethernet n=1—IP passthrough is disabled n=2—IP passthrough on USB n=3—IP passthrough on main serial port using DUN
*HOSTPW	Query or set the host password for PPPoE only. (It does not set the password for PPP/DUN.) AT*HOSTPW? to query AT*HOSTPW=PASSWORD to set Note: PASSWORD cannot be "password".
*HOSTUID	Query or set the Host user ID for PPPoE only. (It does not set the user ID for PPP/DUN.) AT*HOSTUID? to query AT*HOSTUID=USER ID to set (up to 64 bytes)
	Note: USER ID cannot be "user".
*USBDEVICE	Query or set the startup mode for the USB port. AT*USBDEVICE? to query AT*USBDEVICE=n to set • n=0—USB Serial • n=1—USBNET • n=2—Disabled

Table D-5: LAN AT Commands

Wi-Fi

Note: You need to configure Client Mode in ACEmanager. There is no AT Command for Wi-Fi Client mode. See General on page 124.

Note: A reboot is required before these commands take effect.

Table	D-6.	Wi-Fi AT	Commands
Iable	D-0.		Commanus

Command	Description
*APBRIDGED	Query or set the Bridge Wi-Fi A Access Point to Ethernet feature. AT*APBRIDGED? to query AT*APBRIDGED=n to set • n=0—Disable • n=1—Enable
*APBRIDGEDB	Query or set the Bridge Wi-Fi B Access Point to Ethernet feature. AT*APBRIDGEDB? to query AT*APBRIDGEDB=n to set • n=0—Disable • n=1—Enable
*APCHANNEL	Query or set the Wi-Fi A Access Point channel to use (2.4 GHz channels only). AT*APCHANNEL? to query AT*APCHANNEL=n to set • n=1–11 (available channels) Note: Enter only channels that the RV55 supports. These channels are listed under the Channel, Frequency, Width and Channel and Frequency settings. If you enter unsupported channels or channels that are excluded by your Country Code settings, these channels will not take effect. See also The Wi-Fi channel I selected is not working.
*APCHANNELB	Query or set the Wi-Fi B Access Point channel to use (2.4 GHz channels only). AT*APCHANNELB? to query AT*APCHANNELB=n to set • n=1-11 (available channels) Note: Enter only channels that the RV55 supports. These channels are listed under the Channel, Frequency, Width and Channel and Frequency settings. If you enter unsupported channels or channels that are excluded by your Country Code settings, these channels will not take effect. See also The Wi-Fi channel I selected is not working.

Command	Description		
*APEN	Query or set the Wi-Fi A Access Point mode. AT*APEN? to query AT*APEN=n to set • n=2—b/g Enabled • n=3—b/g/n Enabled		
*APENB	Query or set the Wi-Fi B Access Point mode. AT*APENB ? to query AT*APENB=n to set • n=2—b/g Enabled • n=3—b/g/n Enabled		
*APENDIP	Query or set the ending IP address for the Wi-Fi A Access Point DHCP pool. AT*APENDIP? to query AT*APENDIP=d.d.d.d to set • d.d.d.d=IP Address		
*APENDIPB	Query or set the ending IP address for the Wi-Fi B Access Point DHCP pool. AT*APENDIPB? to query AT*APENDIPB=d.d.d.d to set • d.d.d.d=IP Address		
*APHOSTIP	Query or set the Host Wi-Fi A Access Point device IP address. AT*APHOSTIP? to query AT*APHOSTIP=d.d.d.d to set • d.d.d.d=IP Address		
*APHOSTIPB	Query or set the Host Wi-Fi B Access Point device IP address. AT*APHOSTIPB? to query AT*APHOSTIPB=d.d.d.d to set • d.d.d.d=IP Address		
*APMAXCLIENT	Query or set the maximum number of Wi-Fi A Access Point clients. AT*APMAXCLIENT? to query AT*APMAXCLIENT=n to set • n=0-10		
*APMAXCLIENTB	Query or set the maximum number of Wi-Fi B Access Point clients. AT*APMAXCLIENTB? to query AT*APMAXCLIENTB=n to set • n=0-10		
*APNETMASK	Query or set the Wi-Fi A DHCP subnet mask. AT*APNETMASK? to query AT*APNETMASK=d.d.d.d to set • d.d.d.d=IP Address		

Table D-6: Wi-Fi AT Commands

Command	Description
*APNETMASKB	Query or set the Wi-Fi B DHCP subnet mask. AT*APNETMASKB? to query AT*APNETMASKB=d.d.d.d to set • d.d.d.d=IP Address
*APSECURITYTYPE?	Query the Wi-Fi A Access Point Security Encryption type. AT*APSECURITYTYPE? • n=0—Open • n=1—WEP • n=2—WPA Personal • n=3—WPA2 Personal • n=4—WPA2 Enterprise
	Note: WEP is not a recommended Wi-Fi Security protocol because of its vulnerabil- ities and because only alphanumeric characters can be used for the passphrase. Use WPA/WPA2 instead.
*APSECURITYTYPEB?	Query the Wi-Fi B Access Point Security Encryption type. AT*APSECURITYTYPEB? n=0—Open n=1—WEP n=2—WPA Personal n=3—WPA2 Personal n=4—WPA2 Enterprise Note: WEP is not a recommended Wi-Fi Security protocol because of its vulnerabil- ities and because only alphanumeric characters can be used for the passphrase. Use WPA/WPA2 instead.
*APSSIDBCAST	Query or set the broadcast Wi-Fi A Access Point SSID. AT*APSSIDBCAST? to query AT*APSSIDBCAST=n to set • n=0—Disable • n=1—Enable
*APSSIDBCASTB	Query or set the broadcast Wi-Fi B Access Point SSID. AT*APSSIDBCASTB? to query AT*APSSIDBCASTB=n to set • n=0—Disable • n=1—Enable
*APSSIDVAL	Query or set the Access Point SSID/Network name for Wi-Fi A. AT*APSSIDVAL? to query AT*APSSIDVAL=n to set • n=ASCII SSID STRING

Table D-6: Wi-Fi AT Commands

Command	Description		
*APSSIDVALB	Query or set the Access Point SSID/Network name for Wi-Fi B. AT*APSSIDVALB? to query AT*APSSIDVALB=n to set • n=ASCII SSID STRING		
*APSTARTIP	Query or set the Query or set the Access Point DHCP start of IP address pool for Wi- Fi A. AT*APSTARTIP? to query AT*APSTARTIP=d.d.d.d to set • d.d.d.d=IP Address		
*APSTARTIPB	Query or set the Query or set the Access Point DHCP start of IP address pool for Wi-Fi B. AT*APSTARTIPB? to query AT*APSTARTIPB=d.d.d.d to set • d.d.d.d=IP Address		
*APTXPWR	Query or set the maximum transmit power (in dBm) going to the Wi-Fi A antenna when the router is in Access Point (LAN) mode. AT*APTXPWR? to query AT*APTXPWR=n to set • n=1-30		
*APTXPWRB	Query or set the maximum transmit power (in dBm) going to the Wi-Fi B antenna when the router is in Access Point (LAN) mode. AT*APTXPWRB? to query AT*APTXPWRB=n to set • n=1-30		
*APWEPENCTYPE?	Query the Wi-Fi A Access Point WEP encryption type. AT*APWEPENCTYPE? • n=0—Disabled (Open) • n=1—WEP		
	Note: WEP is not a recommended Wi-Fi Security protocol because of its vulnerabil- ities and because only alphanumeric characters can be used for the passphrase. Use WPA/WPA2 instead.		
*APWEPENCTYPEB?	Query the Wi-Fi B Access Point WEP encryption type. AT*APWEPENCTYPEB? • n=0—Disabled (Open) • n=1—WEP		
	Note: WEP is not a recommended Wi-Fi Security protocol because of its vulnerabil- ities and because only alphanumeric characters can be used for the passphrase. Use WPA/WPA2 instead.		

Command	Description		
*APWEPKEY?	Query the Wi-Fi A Access Point WEB key generated at boot from the WEP passphrase. AT*APWEPKEY?		
*APWEPKEYB?	Query the Wi-Fi B Access Point WEB key generated at boot from the WEP passphrase. AT*APWEPKEYB?		
*APWEPKEYLEN?	Query the length of the Wi-Fi A Access Point WEP key. AT*APWEPKEYLEN? • n=064-bit • n=1128-bit • n=2Custom		
*APWEPKEYLENB?	Query the length of the Wi-Fi B Access Point WEP key. AT*APWEPKEYLENB? • n=0—64-bit • n=1—128-bit • n=2—Custom		
*APWPACRYPT?	Query the Wi-Fi A Access Point WPA/WPA2 encryption type. AT*APWPACRYPT? • n=0—TKIP • n=1—AES Note: If you are using WPA2, only AES is allowed.		
*APWPACRYPTB?	Query the Wi-Fi B Access Point WPA/WPA2 encryption type. AT*APWPACRYPTB? • n=0—TKIP • n=1—AES		
*CP_ENABLE	Note: If you are using WPA2, only AES is allowed. Query or set enable/disable the captive portal feature for Wi-Fi A. AT*CP_ENABLE? to query AT*CP_ENABLE=n to set • n=0—Disable • n=1—Enable		
*CP_ENABLEB	Query or set enable/disable the captive portal feature for Wi-Fi B. AT*CP_ENABLEB? to query AT*CP_ENABLEB=n to set • n=0—Disable • n=1—Enable		

Table D-6: Wi-Fi AT Commands

Table D-6: Wi-Fi AT Commands	Table D	-6: Wi-Fi	AT Com	mands
--------------------------------------	---------	-----------	--------	-------

Command	Description
*CP_MACAUTHMODE	Query or set the MAC address authorization mode for Wi-Fi A for the captive portal feature AT*CP_MACAUTHMODE? to query AT*CP_MACAUTHMODE=n to set • n=0—Local MAC authentication • n=1—Server MAC authentication
*CP_MACAUTHMODEB	Query or set the MAC address authorization mode for Wi-Fi B for the captive portal feature AT*CP_MACAUTHMODEB? to query AT*CP_MACAUTHMODEB=n to set • n=0—Local MAC authentication • n=1—Server MAC authentication
*CP_RADIUSAUTHPORT	Query or set the UDP port used for RADIUS authentication traffic for Wi-Fi A *CP_RADIUSAUTHPORT? to query *CP_RADIUSAUTHPORT= <port> to set Default port is 1812.</port>
*CP_RADIUSAUTHPORTB	Query or set the UDP port used for RADIUS authentication traffic for Wi-Fi B *CP_RADIUSAUTHPORT? to query *CP_RADIUSAUTHPORT= <port> to set Default port is 1812.</port>
*CP_RADIUSACCTPORT	Query or set the UDP port used for RADIUS accounting traffic for Wi-Fi A *CP_RADIUSACCTPORT? to query *CP_RADIUSACCTPORT= <port> to set Default port is 1813.</port>
*CP_RADIUSACCTPORTB	Query or set the UDP port used for RADIUS accounting traffic for Wi-Fi B *CP_RADIUSACCTPORT? to query *CP_RADIUSACCTPORT= <port> to set Default port is 1813.</port>
*CP_STATUS?	Query the current status of the captive portal feature for Wi-Fi A AT*CP_STATUS? Possible responses: Inactive Disable Idle Initializing Running Stopped Error

Command	Description
*CP_STATUSB?	Query the current status of the captive portal feature for Wi-Fi B AT*CP_STATUSB? Possible responses: Inactive Disable Idle Initializing Running Stopped Error
*CP_START	Restarts captive portal on Wi-Fi A with the current configuration AT*CP_START=1 Automatically resets to zero when the order is processed
*CP_STARTB	Restarts captive portal on Wi-Fi B with the current configuration AT*CP_STARTB=1 Automatically resets to zero when the order is processed
*CP_UAMSERVER	Query or set the URL of the server you want to redirect clients to for Wi-Fi A AT*CP_UAMSERVER? to query AT*CP_UAMSERVER= <url> to set</url>
*CP_UAMSERVERB	Query or set the URL of the server you want to redirect clients to for Wi-Fi B AT*CP_UAMSERVERB? to query AT*CP_UAMSERVERB= <url> to set</url>
*CP_UAMSECRET	Query or set the shared secret between the router and the portal for Wi-Fi A AT*CP_UAMSECRET? to query AT*CP_UAMSECRET= <shared secret=""> to set</shared>
*CP_UAMSECRETB	Query or set the shared secret between the router and the portal for Wi-Fi B AT*CP_UAMSECRETB? to query AT*CP_UAMSECRETB= <shared secret=""> to set</shared>
*CP_DNSMODE	Query or set the DNS method for Wi-Fi A (Auto, Any DNS, User Defined) AT*CP_DNSMODE? to query AT*CP_DNSMODE=n to set • n=0—Auto • n=1—Any DNS • n=2—User Defined
*CP_DNSMODEB	Query or set the DNS method for Wi-Fi B (Auto, Any DNS, User Defined) AT*CP_DNSMODEB? to query AT*CP_DNSMODEB=n to set • n=0—Auto • n=1—Any DNS • n=2—User Defined

Command	Description
*CP_DNSIP1	If the DNS mode for Wi-Fi A is set to User Defined (*CP_DNSMODE), use this AT Command to query or set the IP address for DNS 1. AT*CP_DNSIP1? to query AT*CP_DNSIP1= <ip> to set</ip>
*CP_DNSIP1B	If the DNS mode for Wi-Fi B is set to User Defined (*CP_DNSMODEB), use this AT Command to query or set the IP address for DNS 1. AT*CP_DNSIP1B? to query AT*CP_DNSIP1B= <ip> to set</ip>
*CP_DNSIP2	If the DNS mode for Wi-Fi A is set to User Defined (*CP_DNSMODE), use this AT Command to query or set the IP address for DNS 2 AT*CP_DNSIP2? to query AT*CP_DNSIP2= <ip> to set</ip>
*CP_DNSIP2B	If the DNS mode for Wi-Fi B is set to User Defined (*CP_DNSMODEB), use this AT Command to query or set the IP address for DNS 2 AT*CP_DNSIP2B? to query AT*CP_DNSIP2B= <ip> to set</ip>
*CP_NASID	Query or set the RADIUS NAS Identifier for Wi-Fi A for each device accessing a portal AT*CP_NASID? to query AT*CP_NASID= <id> to set</id>
*CP_NASIDB	Query or set the RADIUS NAS Identifier for Wi-Fi B for each device accessing a portal AT*CP_NASIDB? to query AT*CP_NASIDB= <id> to set</id>
*CP_RADIUSIP	Query or set the IP address of the RADIUS server for Wi-Fi A AT*CP_RADIUSIP? to query AT*CP_RADIUSIP= <ip> to set</ip>
*CP_RADIUSIPB	Query or set the IP address of the RADIUS server for Wi-Fi B AT*CP_RADIUSIPB? to query AT*CP_RADIUSIPB= <ip> to set</ip>
*CP_RADIUSSECRET	Query or set the shared secret with the RADIUS server for Wi-Fi A AT*CP_RADIUSSECRET? to query AT*CP_RADIUSSECRET= <secret> to set</secret>
*CP_RADIUSSECRETB	Query or set the shared secret with the RADIUS server for Wi-Fi B AT*CP_RADIUSSECRETB? to query AT*CP_RADIUSSECRETB= <secret> to set</secret>
*CP_RADIUSAUTHPORT	Query or set the RADIUS authentication port for Wi-Fi A AT*CP_RADIUSAUTHPORT? to query AT*CP_RADIUSAUTHPORT= <port> to set</port>

Table D-6: Wi-Fi AT Commands

Command	Description
*CP_RADIUSAUTHPORTB	Query or set the RADIUS authentication port for Wi-Fi B AT*CP_RADIUSAUTHPORTB? to query AT*CP_RADIUSAUTHPORTB= <port> to set</port>
*CP_RADIUSACCTPORT	Query or set the RADIUS accounting port for Wi-Fi A AT*CP_RADIUSACCTPORT? to query AT*CP_RADIUSACCTPORT= <port> to set</port>
*CP_RADIUSACCTPORTB	Query or set the RADIUS accounting port for Wi-Fi B AT*CP_RADIUSACCTPORTB? to query AT*CP_RADIUSACCTPORTB= <port> to set</port>
WCC?	Query the Wi-Fi country code.
*WIFIMAC?	Query the MAC address of the Wi-Fi A Access Point.
	Note: Wi-Fi Client uses a different MAC address.
*WIFIMACB?	Query the MAC address of the Wi-Fi B Access Point.
	Note: Wi-Fi Client uses a different MAC address.
*WIFIMODE	Query or set the WI-Fi A Mode. AT*WIFIMODE? to query AT*WIFIMODE=n to set • n=0—Disabled • n=1—AP (Access Point) • n=2—Client For more information, see Global DNS on page 163.
*WIFIMODEB	Query or set the WI-Fi B Mode. AT*WIFIMODEB? to query AT*WIFIMODEB=n to set • n=0—Disabled • n=1—AP (Access Point) • n=2—Client
	Note: Both Wi-Fi A and Wi-Fi B cannot be set to Client mode.
	For more information, see Global DNS on page 163.

VPN

Table D-7: VPN Commands

Command	Description
*IPSEC_INBOUND	 Query or set the incoming public Internet traffic. AT*IPSEC_INBOUND? to query AT*IPSEC_INBOUND=n to set n=0—Blocked (Incoming public Internet traffic is blocked. Only traffic through the VPN tunnel is allowed.) Default n=1—Allowed (Incoming public Internet traffic is allowed.)
*IPSEC_OB_ALEOS	 Query or set outgoing traffic from the AirLink RV55. AT*IPSEC_OB_ALEOS? to query AT*IPSEC_OB_ALEOS=n to set n=0—Blocked (Outgoing traffic from the AirLink RV55 to the public Internet is blocked. Only traffic through the VPN tunnel is allowed.) n=1—Allowed (Outgoing traffic from the AirLink RV55 to the public Internet is allowed.) Default
*IPSEC_OB_HOST	Query or set the outgoing Host out of band traffic. AT*IPSEC_OB_HOST? to query AT*IPSEC_OB_HOST=n to set • n=0—Blocked (Public Internet traffic from the host device is blocked. Only traffic through the VPN tunnel is allowed.) Default • n=1—Allowed (Public Internet traffic from the host device is allowed.)
*IPSEC1_AUTH *IPSEC2_AUTH *IPSEC3_AUTH *IPSEC4_AUTH *IPSEC5_AUTH	Query or set the authentication type for # VPN. AT*IPSEC[VPN number]_AUTH? to query AT*IPSEC[VPN number]_AUTH=n to set • n=0—None • n=1—MD5 • n=2—SHA1 (default)
	<i>Note: MD5</i> is an algorithm that produces a 128-bit digest for authentication. <i>SHA is a more secure algorithm that produces a 160-bit digest.</i>
*IPSEC1_DH *IPSEC2_DH *IPSEC3_DH *IPSEC4_DH *IPSEC5_DH	Query or set how the AirLink RV55 VPN creates an SA with the VPN server. The DH (Diffie-Hellman) key exchange protocol establishes pre-shared keys during the phase 1 authentication. The AirLink RV55 supports three prime key lengths, including Group 1 (768 bits), Group 2 (1,024 bits), and Group 5 (1,536 bits). AT*IPSEC[VPN number]_DH? to query AT*IPSEC[VPN number]_DH=n to set • n=0—None • n=1—DH1 • n=2—DH2 (default) • n=5—DH5

Table D-7: VPN Commands

Command	Description
*IPSEC1_ENCRYPT *IPSEC2_ENCRYPT *IPSEC3_ENCRYPT *IPSEC4_ENCRYPT *IPSEC5_ENCRYPT	Query or set the type/length of encryption key used to encrypt/decrypt ESP (Encapsulating Security Payload) packets for # VPN. AT*IPSEC[VPN number]_ENCRYPT? to query AT*IPSEC[VPN number]_ENCRYPT=n to set • n=0—None • n=1—DES • n=2—3DES • n=3—AES-128 (default) • n=7—AES-256 Note: 3DES supports 168-bit encryption. AES (Advanced Encryption Standard) supports both 128-bit and 256-bit encryption.
*IPSEC1_GATEWAY *IPSEC2_GATEWAY *IPSEC3_GATEWAY *IPSEC4_GATEWAY *IPSEC5_GATEWAY	Query or set the IP address of the server that # VPN client connects to. AT*IPSEC[VPN number]_GATEWAY? to query AT*IPSEC[VPN number]_GATEWAY=[IP address] to set
*IPSEC1_IKE_AUTH *IPSEC2_IKE_AUTH *IPSEC3_IKE_AUTH *IPSEC4_IKE_AUTH *IPSEC5_IKE_AUTH	Query or set the IKE authentication type for # VPN. AT*IPSEC[VPN number]_IKE_AUTH? to query AT*IPSEC[VPN number]_IKE_AUTH=n to set • n=1—MD5 • n=2—SHA1
	Note: MD5 is an algorithm that produces a 128-bit digest for authentication. SHA is a more secure algorithm that produces a 160-bit digest.
*IPSEC1_IKE_DH *IPSEC2_IKE_DH *IPSEC3_IKE_DH *IPSEC4_IKE_DH *IPSEC5_IKE_DH	Query or set how the AirLink RV55 VPN creates an SA with the VPN server. The DH (Diffie-Hellman) key exchange protocol establishes pre-shared keys during the phase 1 authentication. The AirLink RV55 supports three prime key lengths, including Group 1 (768 bits), Group 2 (1,024 bits), and Group 5 (1,536 bits). AT*IPSEC[VPN number]_IKE_DH? to query AT*IPSEC[VPN number]_IKE_DH=n to set • n=1DH1 • n=2DH2 (default) • n=5DH5

Command	Description
*IPSEC1_IKE_DPD *IPSEC2_IKE_DPD *IPSEC3_IKE_DPD *IPSEC4_IKE_DPD *IPSEC5_IKE_DPD	 Query or set Dead Peer Detection (DPD). AT*IPSEC[VPN number]_IKE_DPD? to query AT*IPSEC[VPN number]_IKE_DPD=n to set n=0—Disabled (default) n=1—Enabled (When DPD is enabled, the AirLink RV55 checks to see if the server is still present if there has been no traffic for a configured interval. If it does not receive an acknowledgment, it retries at 5 second intervals. If there is no acknowledgment after 5 retries, the status of the VPN is set to Not Connected and the device attempts to renegotiate IPSEC security parameters with its peer.)
	Note: Sierra Wireless recommends that you Enable IKE DPD. Otherwise the AirLink RV55 has no way of detecting that the connection to the VPN server is still available.
*IPSEC1_IKE_DPD_INTERVAL *IPSEC2_IKE_DPD_INTERVAL *IPSEC3_IKE_DPD_INTERVAL *IPSEC4_IKE_DPD_INTERVAL *IPSEC5_IKE_DPD_INTERVAL	Query or set the DPD interval (in seconds). If there has been no traffic for the period of time set in this field, the AirLink RV55 retries checking with the server, as described in *IPSEC[VPN Number]_IKE_DPD. AT*IPSEC[VPN number]_IKE_DPD_INTERVAL? to query AT*IPSEC[VPN number]_IKE_DPD_INTERVAL=n to set • n=0-3600 (default is 1200) If n=0, DPD monitoring is turned off (disabled), but the AirLink RV55 still responds to DPD requests from the server.
*IPSEC1_IKE_ENCRYPT *IPSEC2_IKE_ENCRYPT *IPSEC3_IKE_ENCRYPT *IPSEC4_IKE_ENCRYPT *IPSEC5_IKE_ENCRYPT	Query or set the type/length of IKE encryption key used to encrypt/decrypt ESP (Encapsulating Security Payload) packets for # VPN. AT*IPSEC[VPN number]_IKE_ENCRYPT? to query AT*IPSEC[VPN number]_IKE_ENCRYPT=n to set • n=1—DES • n=5—3DES • n=7—AES-128 (default) • n=9—AES-256 Note: 3DES supports 168-bit encryption. AES (Advanced Encryption Standard) supports both 128-bit and 256-bit encryption.
*IPSEC1_IKE_LIFETIME *IPSEC2_IKE_LIFETIME *IPSEC3_IKE_LIFETIME *IPSEC4_IKE_LIFETIME *IPSEC5_IKE_LIFETIME	Query or set how long the # VPN tunnel is active (in seconds). AT*IPSEC[VPN number]_IKE_LIFETIME? to query AT*IPSEC[VPN number]_IKE_LIFETIME=n to set • n=180-86400 (default is 7200)
*IPSEC1_LIFETIME *IPSEC2_LIFETIME *IPSEC3_LIFETIME *IPSEC4_LIFETIME *IPSEC5_LIFETIME	Query or set how long the # VPN tunnel is active (in seconds). AT*IPSEC[VPN number]_LIFETIME? to query AT*IPSEC[VPN number]_LIFETIME=n to set • n=180-86400 (default is 7200)

Command	Description
*IPSEC1_LOCAL_ADDR *IPSEC2_LOCAL_ADDR *IPSEC3_LOCAL_ADDR *IPSEC4_LOCAL_ADDR *IPSEC5_LOCAL_ADDR	Query or set the device subnet address for # VPN. AT*IPSEC[VPN number]_LOCAL_ADDR? returns the device subnet address AT*IPSEC[VPN number]_LOCAL_ADDR=[subnet address] to set
*IPSEC1_LOCAL_ADDR_MASK *IPSEC2_LOCAL_ADDR_MASK *IPSEC3_LOCAL_ADDR_MASK *IPSEC4_LOCAL_ADDR_MASK *IPSEC5_LOCAL_ADDR_MASK	Query or set the device subnet mask information (24-bit netmask). AT*IPSEC[VPN number]_LOCAL_ADDR_MASK? to query AT*IPSEC[VPN number]_LOCAL_ADDR_MASK =[subnet mask] to set Default is 255.255.255.0
*IPSEC1_LOCAL_ADDR_TYPE *IPSEC2_LOCAL_ADDR_TYPE *IPSEC3_LOCAL_ADDR_TYPE *IPSEC4_LOCAL_ADDR_TYPE *IPSEC5_LOCAL_ADDR_TYPE	Query or set the network address type for # VPN. AT*IPSEC[VPN number]_LOCAL_ADDR_TYPE? to query AT*IPSEC[VPN number]_LOCAL_ADDR_TYPE=n to set • n=1—Use the Host Subnet • n=5—Single Address • n=17—Subnet Address (default)
*IPSEC1_LOCAL_ID *IPSEC2_LOCAL_ID *IPSEC3_LOCAL_ID *IPSEC4_LOCAL_ID *IPSEC5_LOCAL_ID	 Query or set the local (My Identity) ID for the # VPN. If IP is selected as the local (My Identity) type, AT*IPSEC[VPN number]_LOCAL_ID? returns the WAN IP address assigned by the Mobile Network Operator If FQDN or User FQDN is selected as the local (My Identity) type, AT*IPSEC[VPN number]_LOCAL_ID? returns the FQDN (for example me@mycompany.com) To set the local ID: AT*IPSEC[VPN number]_LOCAL_ID=[IP address] or [FQDN], depending on the setting for Local ID (My Identity) type.
*IPSEC1_LOCAL_ID_TYPE *IPSEC2_LOCAL_ID_TYPE *IPSEC3_LOCAL_ID_TYPE *IPSEC4_LOCAL_ID_TYPE *IPSEC5_LOCAL_ID_TYPE	 Query or set the local (My Identity) ID type for the # VPN. AT*IPSEC[VPN number]_LOCAL_ID_TYPE? to query AT*IPSEC[VPN number]_LOCAL_ID_TYPE=n to set n=1—IP n=2—FQDN n=3—User FQDN Note: IP (default) allows you to use an IP address FQDN allows you to use a fully qualified domain name (FQDN) e. g., modemname.domainname.com User FQDN allows you to use a user FQDN whose values should include a username (e.g. user@domain.com)

Command	Description
*IPSEC1_NEG_MODE *IPSEC2_NEG_MODE *IPSEC3_NEG_MODE *IPSEC4_NEG_MODE *IPSEC5_NEG_MODE	Query or set the negotiation mode for # VPN. AT*IPSEC[VPN number]_NEG_MODE? returns AT*IPSEC[VPN number]_NEG_MODE=n to set • n=1—Main • n=2—Aggressive Note: Aggressive mode offers increased performance at the expense of security.
*IPSEC1_PFS *IPSEC2_PFS *IPSEC3_PFS *IPSEC4_PFS *IPSEC5_PFS	Query or set the Perfect Forward Secrecy (PFS) setting for # VPN. PFS provides additional security through a DH shared secret value. When this feature is enabled, one key cannot be derived from another. This ensures previous and subsequent encryption keys are secure even if one key is compromised. AT*IPSEC[VPN number]_PFS? to query PFS AT*IPSEC[VPN number]_PFS=n to set PFS • n=0—Yes (default) • n=1—No
*IPSEC1_REMOTE_ADDR *IPSEC2_REMOTE_ADDR *IPSEC3_REMOTE_ADDR *IPSEC4_REMOTE_ADDR *IPSEC5_REMOTE_ADDR	Query or set the IP address of the device behind the RV55 for # VPN. AT*IPSEC[VPN number]_REMOTE_ADDR? to query AT*IPSEC[VPN number]_REMOTE_ADDR=[IP address] to set
*IPSEC1_REMOTE_ADDR_MASK *IPSEC2_REMOTE_ADDR_MASK *IPSEC3_REMOTE_ADDR_MASK *IPSEC4_REMOTE_ADDR_MASK *IPSEC5_REMOTE_ADDR_MASK	Query or set the remote subnet mask information (24-bit netmask). AT*IPSEC[VPN number]_REMOTE_ADDR_MASK? to query AT*IPSEC[VPN number]_REMOTE_ADDR_MASK =[subnet mask] to set Default is 255.255.255.0
*IPSEC1_REMOTE_ADDR_TYPE *IPSEC2_REMOTE_ADDR_TYPE *IPSEC3_REMOTE_ADDR_TYPE *IPSEC4_REMOTE_ADDR_TYPE *IPSEC5_REMOTE_ADDR_TYPE	Query or set network information of the IPsec server behind the IPsec RV55 for # VPN. AT*IPSEC[VPN number]_REMOTE_ADDR_TYPE? to query AT*IPSEC[VPN number]_REMOTE_ADDR_TYPE=n to set • n=5—Single Address • n=17—Subnet Address (default)
*IPSEC1_REMOTE_ID *IPSEC2_REMOTE_ID *IPSEC3_REMOTE_ID *IPSEC4_REMOTE_ID *IPSEC5_REMOTE_ID	 Query or set the remote (Peer Identity) ID for the # VPN. If IP is selected as the remote (Peer Identity) type, AT*IPSEC[VPN number]_REMOTE_ID? returns the WAN IP address assigned by the Mobile Network Operator If FQDN or User FQDN is selected as the remote (Peer Identity) type, AT*IPSEC[VPN number]_REMOTE_ID? returns the FQDN (for example me@mycompany.com) To set the remote ID: AT*IPSEC[VPN number]_REMOTE_ID=[IP address] or [FQDN], depending on the setting for remote ID (Peer Identity) type.

Command	Description
*IPSEC1_REMOTE_ID_TYPE *IPSEC2_REMOTE_ID_TYPE *IPSEC3_REMOTE_ID_TYPE *IPSEC4_REMOTE_ID_TYPE *IPSEC5_REMOTE_ID_TYPE	Query or set the remote (Peer Identity) ID type for the # VPN. AT*IPSEC[VPN number]_REMOTE_ID_TYPE? to query AT*IPSEC[VPN number]_REMOTE_ID_TYPE=n to set • n=1—IP • n=2—FQDN • n=3—User FQDN
	 Note: FQDN allows you to use a fully qualified domain name (FQDN) e. g., modemname.domainname.com User FQDN allows you to use a user FQDN whose values should include a username (e.g. user@domain.com)
*IPSEC1_SHARED_KEY1 *IPSEC2_SHARED_KEY1 *IPSEC3_SHARED_KEY1 *IPSEC4_SHARED_KEY1 *IPSEC5_SHARED_KEY1	Query the pre-shared Key (PSK) used to initiate the # VPN tunnel. AT*IPSEC[n]_SHARED_KEY1? [n]=server number
*IPSEC1_STATUS? *IPSEC2_STATUS? *IPSEC3_STATUS? *IPSEC4_STATUS? *IPSEC5_STATUS?	Query the VPN # connection status. AT*IPSEC[VPN number]_STATUS? to query • Disabled • Not Connected • Connected
	Note: Use this when troubleshooting a VPN # connection.
*IPSEC1_TUNNEL_TYPE *IPSEC2_TUNNEL_TYPE *IPSEC3_TUNNEL_TYPE *IPSEC4_TUNNEL_TYPE *IPSEC5_TUNNEL_TYPE	Query or set the VPN # tunnel type. AT*IPSEC[VPN number]_TUNNEL_TYPE? to query AT*IPSEC[VPN number]_TUNNEL_TYPE=n to set • n=0—Disable the tunnel (default) • n=1—IPsec Tunnel • n=2—GRE Tunnel • n=3—SSL Tunnel
	Note: For a successful configuration, all settings for the VPN tunnel must be identical between the AirLink RV55 VPN and the enterprise VPN server.

Security

Table D-8: Security AT Commands

Command	Description
F0 (F1, F2, F9)	Query or set the Inbound Trusted IP List. ATF? to query the list ATF[n]=d.d.d.d to set • n=0-9 Trusted IP list index number • d.d.d.d = IP Address Using 255 in the IP address will allow any number Example: 166.129.2.255 allows access by all IPs in the range 166.129.2.0–166.129.2.255. Example: atf? 0=192.32.32.21 1=192.32.32.22 2=192.32.32.23 3=0.0.0 4=0.0.0 5=0.0.0 6=0.0.0 7=0.0.0 8=0.0.0 9=0.0.0 OK If the index number does not have an IP address associated with it, the query returns 0.0.0.0 for that index number.
FM	Note: You can only query or configure the first nine Inbound Trusted IP addresses with this AT Command. You cannot query or configure Trusted range entries with this AT Command. Query or set the Inbound Trusted IP mode (Friends List)—Only allow specified IPs to access the device. ATFM? to query the setting ATFM=n to set
	 n=0—Disable Trusted IP mode n=1—Enable Trusted IP mode—Only packets from IP addresses in the Trusted IP list are allowed. Packets from other IP addresses are ignored.

Services

Table D-9: Services AT Commands

Command	Description
AirLink Management Syste	m
*AVMS_CONNECT	Query or set the ALMS connection. Running AT*AVMS_CONNECT=1 has the same functionality as clicking Connect in Services > ALMS > AirLink Management Service. AT*AVMS_CONNECT? to query AT*AVMS_CONNECT=n to set • n=0—No functionality • n=1—Connect to ALMS
*AVMS_ENABLE	 Query or set the ALMS activation status. AT*AVMS_ENABLE? to query AT*AVMS_ENABLE=n to set n=0—Disable device initiated ALMS management n=1—Enable MSCI protocol for ALMS management n=2—Enable LWM2M protocol for ALMS management n=3—Enable LWM2M protocol for ALMS management, with an automatic Fallback to MSCI if communication fails
*AVMS_INTERVAL	Query or set the ALMS communication (heartbeat) interval in minutes. AT*AVMS_INTERVAL? to query AT*AVMS_INTERVAL= n to set • n=INTERVAL (in minutes)
*AVMS_NAME	Assigns or queries the name to the AirLink RV55 as it appears in ALMS. AT*AVMS_NAME? to query AT*AVMS_NAME=n to set • n=ALMS NAME
*AVMS_SERVER	Query or set the ALMS server IP address or FQDN. AT*AVMS_SERVER? to query AT*AVMS_SERVER=n to set • n=IP Address or FQDN of ALMS server
*AVMS_STATUS?	Query the ALMS connection status.
*AVMS_AUTOSYNC	Query or set ALMS autosynchronization of configuration parameters.AT*AVMS_AUTOSYNC? to queryAT**AVMS_AUTOSYNC=n to setn=0—Disable ALMS autosynchronizationn=1—Enable ALMS autosynchronization
*AVMS_VERIFYPEER	Query or set peer certificate verification during SSL handshake. AT*AVMS_VERIFYPEER? to query AT*AVMS_VERIFYPEER=n to set • n=0—Disable peer certificate verification during SSL handshake • n=1—Enable peer certificate verification during SSL handshake

Command	Description
Low Power	
*ENGHRS	Query or set the number of hours the engine has been running. AT*ENGHRS? to query AT*ENGHRS=n to set • n=HOURS Maximum value is 65535.
*MSCISERVER	Set or query the MSCI server setting AT*MSCISERVER? to query AT*MSCISERVER=n to set • n=0—Access is disabled • n=1—Access is LAN only • n=2—Access is WAN and LAN
Dynamic DNS	
*DOMAIN	Query or set the domain name used for the IP Manager Dynamic DNS configuration.AT*DOMAIN? to queryAT*DOMAIN=DOMAIN to set (up to 20 characters)Example: AT*DOMAIN=eairlink.comTip: Only letters, numbers, hyphens, and periods can be used in a domain name.Note: This AT command is only usable if the Dynamic DNS Service type is set to IP
	Manager.
*DYNDNS	Query or set the Dynamic DNS Service type to use. AT*DYNDNS? to query AT*DYNDNS=n to set • n=0—Disable (default) • n=2—dyndns.org • n=5—noip.com • n=8—regfish.com • n=10—IP Manager
	Note: Only IP Manager can be fully configured using AT Commands.

Table D-9:	Services	AT	Commands
------------	----------	----	----------

Table D-9:	Services A	T Commands
------------	------------	------------

Description
Note: This AT command is only usable if the Dynamic DNS Service type is set to IP Manager.
Query or set a FQDN or IP address of the IP server to send IP change notifications to. You can configure two independent IP Manager servers. AT*IPMANAGER[n]? to query AT*IPMANAGER[n]=SERVER to set. • n=1—First IP Manager server • n=2—Second IP Manager server • SERVER=Server FQDN or IP address
Note: You can disable updates to a server by setting blank entry (e.g., "AT*IPMANAGER1=").
Note: This AT command is only usable if the Dynamic DNS Service type is set to IP Manager.
Query or set the 128-bit password/key used to authenticate the IP update notifications. If the key's value is all zeros, a default key is used. If all the bytes in the key are set to FF, then no key is used (i.e., the IP change notifications will not be authenticated). AT*IPMGRKEY[n]? to query AT*IPMANAGER[n]=KEY to set • n=1—First IP Manager server • n=2—Second IP Manager server • KEY=128-bit key in hexadecimal [32 hex characters]
Note: This AT command is only usable if the Dynamic DNS Service type is set to IP Manager.
Query or set the interval (in minutes) to send an IP update notification to the corresponding server. This occurs even if the IP address of the device does not change. If the value is set to 0, then periodic updates are not issued (i.e., IP change notifications is only be sent when the IP actually changes). AT*IPMGRUPDATE[n] to query AT*IPMGRUPDATE[n]=INTERVAL to set • n=0—Disables the update interval (updates only on changes) • n=1—First IP Manager server • n=2—Second IP Manager server • INTERVAL=1–255—interval (in minutes) to send an update

Command	Description
*MODEMNAME	
	Note: This AT command is only usable if AT*DYNDNS is set to 10 (IP Manager).
	Query or set the device name used by IP Manager. (This name is displayed on the Status > Home page.) AT*MODEMNAME? to query
	AT*MODEMNAME=NAME to set (up to 20 characters long)
	 NAME=device name (for example, mydevice)
	The value in *DOMAIN provides the domain zone to add to this name.
	Example: If *MODEMNAME=mydevice and *DOMAIN=eairlink.com, the device's fully qualified domain name is mydevice.eairlink.com.
	Tip: Each device using IP Manager needs a unique name. I.e., two devices cannot both be called "mydevice". One could be named "mydevice1" while the other could be named "mydevice2".
SMS	
+CMGD	This command and AT+CMGL enable you to manage incoming SMS messages. To use these commands, the SMS mode must be set to Outbound Only. (See SMS Modes on page 243.)
	Use AT+CMGD to delete SMS messages.
	AT+CMGD= <index>[,flag]</index>
	where:
	<index> is the index number of the message</index>
	<flag> is:</flag>
	 0=Delete stored SMS messages with the indicated index number(s). This is the default value.
	 1=Ignore the value of the index and delete all SMS messages whose status is "received read".
	 2=Ignore the value of the index and delete all SMS messages whose status is: received read
	stored unsent
	 3=Ignore the value of the index and delete all SMS messages whose status is: received read
	stored unsent
	stored sent
	 4=Ignore the value of the index and delete all SMS messages.

Command	Description
+CMGL	Use this command to list/read SMS messages. To use this command, the SMS mode must be set to Outbound Only. (See SMS Modes on page 243.)
	AT+CMGL= <status> where <status> is: • ALL • REC UNREAD—Received, unread • REC READ—Received, read</status></status>
*SMSM2M *SMSM2M_8 *SMSM2M_u	 You can only use these commands locally. AT*SMSM2M sends an SMS in ASCII text (requires quotation marks; maximum 140 characters) AT*SMSM2M_8 sends an 8-bit SMS (requires quotation marks; maximum 140 characters)
	 AT*SMSM2M_U sends a unicode (UCS-2) SMS (requires quotation marks; maximum 140 characters) Format:
	AT*SMSM2M="[phone] [ascii message]" AT*SMSM2M 8="[phone] [hex message]"
	AT*SMSM2M_U="[phone] [unicode message]"
	 The phone number can only consist of numbers (NO spaces or other characters). The phone number should be as it appears in the Last Incoming Phone Number field.
	 Example 1 (US): 14085551212 (including leading 1 and area code) Example 2 (US): 4085551212 (ignore leading 1, include area code)
	 Example 2 (US): 4005551212 (ignore leading 1, include area code) Example 3 (UK): 447786111717 (remove leading 0 and add country code)
	Command Examples:
	AT*SMSM2M="18005551212 THIS IS A TEST" sends in ASCII.
	AT*SMSM2M_8="17604053757 5448495320495320412054455354" sends the message "THIS IS A TEST" as 8-bit data.
	AT*SMSM2M_U="17604053757 00540048004900530020004900530020004100200054004500530054" sends the message "THIS IS A TEST" as 2-byte unicode data.
	Note: Not all cellular Mobile Network Operators support 8-bit or unicode SMS messages.

Command	Description
*SMS_PASSWORD	Query or set the SMS password. AT*SMS_PASSWORD? to query AT*SMS_PASSWORD=n n=SMS password
	Note: To use this command, you must first enter your user password at AT*ENTERCND="user password"
	If no password has ever been configured, a default password is created from the last four characters of the SIM ID (for all SIM-based devices).
	Note: The configured password remains in place, even when the device is reset to factory default settings.
*SMSWUPTOUT	 This AT Command only to International devices on the Vodafone network. Query or set the connection timeout for the SMS Wakeup feature. When this feature is enabled, an IP connection is initiated on receipt of a specific type of SMS (For information on choosing the type of SMS, see Services > SMS > SMS Wakeup > SMS Wakeup Trigger described in step 3 on page 253). The IP connection closes after the timeout period specified in this AT command. Outgoing traffic sent after the timer is set does not reset the timer. AT*SMSWUPTOUT? to query AT*SMSWUPTOUT=n to set n=2-65535 minutes (default is 2) See also *RADIO CONNECT on page 490.
Telnet/SSH	See also RADIO_CONNECT OIL page 430.
*DEFAULTTELNETUSER	 Query or set the Telnet default user name. AT*DEFAULTTELNETUSER? to query AT*DEFAULTTELNETUSER=n to set n=None—Prompted for a user name and password when logging into a Telnet session (default) n=user—Prompted for a password only when logging into a Telnet session (User name is "user".) Note: The default user name is only for Telnet; not SSH.
*TELNETTIMEOUT	Query or set the Telnet/SSH idle time out. By default, this value is set to close the telnet/SSH connection if no data is received for 2 minutes. AT*TELNETTIMEOUT? to query AT*TELNETTIMEOUT=n to set • n=1-255 minutes (default is 2)

 Table D-9:
 Services AT Commands

Command	Description
*TSSH	Query or set the remote login server mode. AT*TSSH? to query AT*TSSH=n to set • n=0—Telnet (default) • n=1—SSH
*TPORT	Query or set the Telnet/SSH port. AT*PORT? to query AT*PORT=n to set • n=1-65535 (default is 2332) Many networks have the ports below 1024 blocked. It is recommended to use a higher numbered port.
*TQUIT	AT*TQUIT which will kill an open telnet session.
Management (SNMP)	
SNMP General Configuratio	n
*SNMP	Query or set the SNMP option. AT*SNMP? to query AT*SNMP=n to set • n=0—Disable • n=1—Enable
*SNMPCONTACT	Add string contact information in SNMPv2 and SNMPv3. AT*SNMPCONTACT=string • string=email address (Example: admin@sierrawireless.com)
*SNMPLOCATION	Add string location information in SNMPv2 and SNMPv3. AT*SNMPLOCATION=string • string=location information (Example: Building 19–67B)
*SNMPNAME	Add string name in SNMPv2 and SNMPv3. AT*SNMPNAME=STRING • STRING=name (Example: John Doe)
*SNMPPORT	Query or set the port number in SNMPv2 and SNMPv3. AT*SNMPPORT? to query AT*SNMPPORT=n to set • n=1-65535 (default is 161)
*SNMPVERSION	Query or set the SNMP version. AT*SNMPVERSION? to query AT*SNMPVERSION=n to set • n=2—version 2 • n=3—version 3
SNMP Read Only Configura	tion
*SNMPROCOMMUNITY	Read-only community string in SNMPv2 and SNMPv3. (SNMP equivalent of a password; for example: public)

Command	Description
*SNMPROUSER	Query or set a read only SNMP username string in SNMPv3.
*SNMPROUSERAUTHTYPE	Query or set the read only authentication type in SNMPv3. AT*SNMPROUSERAUTHTYPE? to query AT*SNMPROUSERAUTHTYPE=n • n=0—MD5 • n=1—SHA
*SNMPROUSERSECLVL	Query or set the read only security level in SNMPv3. AT*SNMPROUSERSECLVL? to query AT*SNMPROUSERSECLVL=n to set • n=0—none • n=1—authentication only • n=2—authentication + privacy
SNMP Read/Write Configurati	on
*SNMPRWCOMMUNITY	Read/write community string in SNMPv2 and SNMPv3. (SNMP equivalent of a password; for example: private)
*SNMPRWUSER	Query or set a read/write SNMP username string in SNMPv2 and SNMPv3.
*SNMPRWUSERAUTHTYPE	Query or set the read/write authentication type in SNMPv3. AT*SNMPRWUSERAUTHTYPE? to query AT*SNMPRWUSERAUTHTYPE=n to set • n=0—MD5 • n=1—SHA
*SNMPRWUSERSECLVL	Query or set the read/write security level in SNMPv3. AT*SNMPRWUSERSECLVL? to query AT*SNMPRWUSERSECLVL=n to set • n=0—none • n=1—authentication only • n=2—authentication + privacy
*SNMPRWUSERPRIVTYPE	Query or set the read/write privacy type in SNMPv3. AT*SNMPRWUSERPRIVTYPE? to query AT*SNMPRWUSERPRIVTYPE=n to set • n=0—DES • n=1—AES
SNMP TRAP Configuration	·
*SNMPENGINEID	Specify an identification name string for a SNMP engine in SNMPv3. (For example: Shark-0012E8)
*SNMPTRAPAUTHTYPE	Query or set the SNMP TRAP authentication type in SNMPv3. AT*SNMPTRAPAUTHTYPE? to query AT*SNMPTRAPAUTHTYPE=n to set • n=0—MD5 • n=1—SHA

 Table D-9: Services AT Commands

Command	Description
*SNMPTRAPCOMMUNITY	SNMP TRAP community string in SNMPv2 and SNMPv3. (SNMP equivalent of a password)
*SNMPTRAPDEST	Query or set the SNMP TRAP destination in SNMPv2 and SNMPv3. (for example: 192.168.13.33)
*SNMPTRAPPORT	Query or set the SNMP TRAP port in SNMPv2 and SNMPv3. • 1–65535 (default is 162)
*SNMPTRAPPRIVTYPE	Query or set the SNMP TRAP privacy type in SNMPv3. AT*SNMPTRAPPRIVTYPE? to query AT*SNMPTRAPPRIVTYPE=n to set • n=0—DES • n=1—AES
*SNMPTRAPSECLVL	Query or set the SNMP TRAP security level in SNMPv3. AT*SNMPTRAPSECLVL? to query AT*SNMPTRAPSECLVL=n to set • n=0—none • n=1—authentication only • n=2—authentication + privacy
*SNMPTRAPUSER	Query or set a SNMP TRAP username string in SNMPv3.
Email (SMTP) Commands	
*SMTPADDR	Query or set the mail server IP address or FQDN. AT*SMTPADDR? to query AT*SMTPADDR=[d.d.d.] or [NAME] to set d.d.d.d=IP Address NAME=domain name (maximum: 40 characters)
*SMTPFROM	Query or set the email address from which the SMTP message is being sent (required by some mail servers). AT*SMTPFROM? to query AT*SMTPFROM=EMAIL to set • EMAIL=email address (maximum: 30 characters)
*SMTPSUBJ	Query or set the email subject line to use for sending emails. AT*SMTPSUBJ? to query AT*SMTPSUBJ=STRING to set
*SMTPPW	Query or set the email server password (required by some mail servers). AT*SMTPPW? to query AT*SMTPPW=PASSWORD to set
*SMTPUSER	Query or set the email account username (required by some mail servers). AT*SMTPUSER? to query AT*SMTPUSER=USER to set (maximum: 40 characters)

Command	Description	
Time (SNTP) Commands		
*SNTP	Query or set daily SNTP updates of the system time. AT*SNTP? to query AT*SNTP=n to set • n=0—Off • n=1—On	
*SNTPADDR	 SNTP Server IP address, or fully-qualified domain name, to use if *SNTP=1. AT*SNTPADDR? to query AT*SNTPADDR=[d.d.d.d] or [NAME] d.d.d.d=IP Address NAME=FQDN 	

Table D-9	Services	AT	Commands
-----------	----------	----	----------

Location

Table D-10: Location AT Commands

Command	Description
*GNSSSTATUS?	Queries the GNSS receiver inside the router and provides more robust information than *GPSDATA? It is independent of all location configuration. You don't need to have a server configured or any specific report type selected, and location reporting does need to be enabled.
	The response to this command lists the fix status, satellite count, and latitude and longitude in decimal degrees, time (UTC), and time to first fix (TTFF).
	For example:
	AT*GNSSSTATUS? returns:
	Location Fix=1 Satellite Count=14
	Latitude=+49.17081
	Longitude=-123.06970 Date=2016/02/29
	Time=18:55:28
	TTFF=9449 milliSeconds
	Location Fix=1—fix acquired
	 Location Fix=2—Differential Location fix acquired
*GPSDATA?	Queries ALEOS and provides a snap-shot of the current location data used for reports.
	This command is independent of all location configuration. You don't need to have a server configured or any specific report type selected, and location reporting does need to be enabled. The response to this command lists the fix status, satellite count, and latitude and longitude in decimal degrees. It is not formatted as a Location report.
	For example:
	AT*GPSDATA? returns:
	Location Fix=1
	Satellite Count=8 Latitude=+49.17081
	Longitude=-123.06970
	Location Fix=1—Location fix acquired
	 Location Fix=1 — Differential location fix acquired
*0000	· · · · · · · · · · · · · · · · · · ·
*PGPS	Query or set the serial streaming interface ports that the reports are sent to. AT*PGPS? to guery
	AT*PGPS=n to set
	• n=0—None
	• n=1—DB9 Serial
	• n=2—USB Serial
	• n=3—DB9 and USB

Command	Description
*PGPSC	 Query or set the out-of-coverage setting. This setting enables you to configure the AirLink RV55 to stream Location reports to the serial port only when the device has no cellular coverage. (This enables you to use a back-up in-vehicle mapping application that does not rely on mobile network coverage.) AT*PGPSC? to query AT*PGPSC=n to set n=0: ALWAYS (default) Location reports are always streamed to the serial port n=1: Out of Coverage—reports are only streamed to the serial port when the AirLink RV55 has no mobile network connection. Note: The two persistent Location report parameters, *PGPSR and *PGPSF, control the report type and message frequency of reports sent out the serial port when the AirLink RV55 is out of mobile network coverage.
*PGPSD	Query or set the delay (in seconds) before the out-of-coverage stream begins sending the messages out the serial port and not into SnF. AT*PGPSD? to query AT*PGPSD=n to set • n=0 (default) • n=1-255
	Note: Any messages put into SnF during this switch-over delay period are sent over the air when coverage is re-acquired. Note: The two persistent Location report parameters, *PGPSR and *PGPSF, control the report type and message frequency of reports sent out the serial port when the AirLink RV55 is out of mobile network coverage.
*PGPSF	Query or set how frequently (in seconds) the Location report is sent to the serial link. AT*PGPSF? to query AT*PGPSF=n to set • n=0-65535
*PGPSR	Query or set the Location report type. AT*PGPSR? to query AT*PGPSR=n to set NMEA reports: • n=E0—NMEA GGA + VTG • n=E1—NMEA GGA+VTG+RMC • n=E2—NMEA GGA+VTG+RMC+GSA+GSV TAIP reports: • n=F0—TAIP data • n=F1—TAIP compact data • n=F2—TAIP LN report • n=F3—TAIP TM report

 Table D-10:
 Location AT Commands

Command	Description
*PPDIST *PP2DIST *PP3DIST *PP4DIST	 Query or set the Location report distance interval in 100 meter units. For example, if you entered a value of 635, it would translate to 63,500 meters (63.5 kilometers). AT*PP[Server number if other than server 1]DIST? to query AT*PP[Server number if other than server 1]DIST=n to set n=0—Disabled n=1–65535—Distance in 100 meter units that the device moves before sending a Location report
*PPDISTM *PP2DISTM *PP3DISTM *PP4DISTM	 Query or set the Location report distance Interval in meters. AT*PP[Server number if other than server 1]DISTM? to query AT*PP[Server number if other than server 1]DISTM=n to set n=0—Disabled n=40-65535—Distance in meters that the device moves before sending a Location report
	Note: If you enter a value greater than zero, but less than 40, ALEOS rounds it up to 40.
*PPDEVID	Query or set whether or not the RAP Location report includes device ID and if so, which type of device ID is included. AT*PPDEVID? to query AT*PPDEVID=n to set • n=0—None • n=1—Phone number • n=2—ESN/IMEI
	Note: The device ID in the RAP report is in hex, not plain text.
*PPFLUSHONEVT	Query or set Send SnF Buffer Immediately on input. If this feature is enabled, any pending stored reports are sent if the I/O input changes, a stationary vehicle is moved, or a maximum speed is exceeded. AT*PPFLUSHONEVT? to query AT*PPFLUSHONEVT=n to set • n=0—Disable • n=1—Enable

 Table D-10:
 Location AT Commands

Command	Description
*PPGPSR *PP3GPSR *PP4GPSR	Query or set the Location report type. AT*PP[Server number if other than server 1]GPSR? to query AT*PP[Server number if other than server 1]GPSR=n to set RAP reports: • n=0—Use legacy reports specified in *MF value. Note: Must also have *PPDEVID=0. • n=11—Standard Location Report • n=12—Standard Location Report + UTC Date • n=13—Standard Location Report + UTC Date + RF data • n=14—Standard Location report + Location + Date + RF + EIO Xora reports • n=DO—Xora NMEA reports • n=E1—GGA, VTG and RMC NMEA reports • n=E2—GGA, VTG, RMC, GSA and GSV NMEA reports • n=F0—TAIP data—TAIP Location report that contains position and velocity • n=F1—TAIP Location report that contains the time and date
*PPINPUTEVT *PP2INPUTEVT *PP3INPUTEVT *PP4INPUTEVT	Query or set ability to send a special report for digital input changes. AT*PP[Server number if other than server 1]INPUTEVT? to query AT*PP[Server number if other than server 1]INPUTEVT=n to set • n=0—Disable • n=1—Enable
*PPIP *PP2IP *PP3IP *PP4IP	Query or set the IP address where Location reports are sent. See also *PPPORT on page 530. AT*PP[Server number if other than server 1]IP? to query AT*PP[Server number if other than server 1]IP=d.d.d.d to set • d.d.d.d=IP address Example: AT*PPIP=192.100.100.100
*PPLATS	Query or set the local reporting interval (in seconds). AT*PPLATS? to query AT*PPLATS=n to set • n=0—Disable (default) • n=1–255 (seconds)

 Table D-10:
 Location AT Commands

Table D-10: Location AT Comm

Command	Description
*PPLATSEXTRA	 Query or set the number of additional consecutive ports that the local Location report is sent to. AT*PPLATSEXTRA? to query AT*PPLATSEXTRA=n to set n=0—Just the original report is sent (default). n=1-7—Send Location report copies to that number of ports. Example: If AT*PPLATSEXTRA=7 and the port in S53 is 1000, then Location reports will be sent to ports 1000–1008.
*PPLATSR	Query or set the Location report type that is sent to the local client (Ethernet, USB/net, or PPP). AT*PPLATSR? to query AT*PPLATSR=n to set RAP reports: • n=11—Data • n=12—+ Date • n=13—+ UTC + RF • n=14—+ Date + RF + EIO NMEA reports: • n=E0—NMEA GGA + VTG • n=E2—NMEA GGA + VTG + RMC • n=E2—NMEA GGA + VTG + RMC + GSA + GSV TAIP reports: • n=F0—TAIP data—TAIP Location report that contains position and velocity • n=F1—TAIP Location report that contains a long navigation message • n=F3—TAIP TM report—TAIP Location report that contains the time and date
*PPMAXRETRIES *PP2MAXRETRIES *PP3MAXRETRIES *PP4MAXRETRIES	Query or set maximum number retries when in Simple Reliable mode, UDP Sequence mode, and TCP transports. AT*PP[Server number if other than server 1]MAXRETRIES? to query AT*PP[Server number if other than server 1]MAXRETRIES? to set • n=0—Disabled • n=1–255 retries (Maximum is 10.)
*PPMINTIME *PP2MINTIME *PP3MINTIME *PP4MINTIME	Query or set the minimum amount of time between report packets. Each packet can contain multiple reports. This is useful to limit network traffic and make more efficient use of bandwidth. You can also use it in conjunction with store and forward. The minimum value depends on the policies of the Mobile Network Operator.AT*PP[Server number if other than server 1]MINTIME? to query AT*PP[Server number if other than server 1]MINTIME=n to set• n=0—Disable • n=1-65535 seconds

Command	Description Query or set including the current odometer reading in the RAP report. AT*PP[Server number if other than server 1]ODOM? to query AT*PP[Server number if other than server 1]ODOM=n to set • n=0—Disabled (default) Do not include odometer reading in report. • n=1—Enabled Include odometer reading in report.	
*PPODOM *PP2ODOM *PP3ODOM *PP4ODOM		
*PPODOMVAL	Query or set the odometer value (in meters). Maximum value is approximately 4.3 billion meters (2.7 million miles). AT*PPODOMVAL? to query AT*PPODOMVAL=n to set • n=0-4294967295 meters	
*PPPORT *PP2PORT *PP3PORT *PP4PORT	Query or set the port Location reports are sent to. AT*PP[Server number if other than server 1]PORT? to query AT*PP[Server number if other than server 1]PORT=n to set • n=0—Disable • n=1–65535	
*PPREPORTINPUTS *PP2REPORTINPUTS *PP3REPORTINPUTS *PP4REPORTINPUTS	 Query or set input reporting and including the current digital input value in RAP reports. AT*PP[Server number if other than server 1]REPORTINPUTS? to query AT*PP[Server number if other than server 1]REPORTINPUTS=n to set n=0—Disabled n=1—Enabled 	
*PPSIMPLETO *PP2SIMPLETO *PP3SIMPLETO *PP4SIMPLETO	Query or set the first retry interval for Simple Reliable, UDP Sequence mode, and TCP transports (in seconds).AT*PP[Server number if other than server 1]SIMPLETO? to queryAT*PP[Server number if other than server 1]SIMPLETO=n to set• n=0—Disable• n=1-255 (default is 10)	
*PPSNF *PP2SNF *PP3SNF *PP4SNF	Query or set the Store and Forward (SNF) setting. SNF causes Location reports to be stored if the device/vehicle goes outside the area of network coverage. Once the vehicle is in the coverage area, the Location reports are sent en masse to the server. AT*PP[Server number if other than server 1]SNF? to query AT*PP[Server number if other than server 1]SNF=n to set • n=0—Disabled • n=1—Enabled (default)	
*PPSNFR *PP2SNFR *PP3SNFR *PP4SNFR	Query or set Transport /SNF mode. Location reports are retransmitted if not acknowledged by the server. AT*PP[Server number if other than server 1]SNFR? to query AT*PP[Server number if other than server 1]SNFR=n to set • n=0—Disabled • n=1—Reliable mode • n=2—Simple Reliable mode • n=3—UDP Sequence • n=4—TCP Listen • n=5—TCP	

 Table D-10:
 Location AT Commands

Command	Description
*PPTAIPID	Query or set the four character alphanumeric TAIP ID. AT*PPTAIPID? to query AT*PPTAIPID=nnnn to set • nnnn=alphnumeric characters
*PPTIME *PP2TIME *PP3TIME *PP4TIME	Query or set the Location report time interval (in seconds). AT*PP[Server number if other than server 1]TIME? to query AT*PP[Server number if other than server 1]TIME=n to set • n=0-65535 seconds
	Note: Your cellular Mobile Network Operator may impose a minimum transmit time.
	See also *PPMINTIME, *PPTSV, +CTA.
	Note: A report time of less than 30 seconds may keep an RF link up continuously, tying up an RF resource to transfer small amounts of data. Generally, the RF channel is released and goes dormant in 10–20 seconds if no data is sent or received.
*PPTCPPOLL	Query or set the port to listen on for TCP Location report polling.
	Note: The request to this port needs to come from the same IP address in *PPIP on page 528 and uses the report type configured for server 1.
	AT*PPTCPPOLL? to query AT*PPTCPPOLL=n to set • n=0—Disabled • n=1–65535 (default is 9494)
*PPTSV *PP2TSV *PP3TSV *PP4TSV	Query or set the time interval in minutes that the device sends in reports when it is stationary (Stationary vehicle timer). AT*PP[Server number if other than server 1]TSV? to query AT*PP[Server number if other than server 1]TSV=n to set • n=0—Disabled • n=1-255 minutes For example, if *PPTIME=10, the device sends Location reports at least once every 10 seconds while it is moving; however, once it stops moving, it slows the reports down to this *PPTSV value.
	Note: In order for the PPTSV (Stationary Vehicle timer) to take effect, the PPTIME value must be set to a value greater than 0 and less than the PPTSV value. The PPTSV timer checks for vehicle movement at the PPTIME interval, so if PPTIME is disabled, then PPTSV will also be disabled.

 Table D-10:
 Location AT Commands

Serial

Note: When the RV55 is in dual serial port mode, you can direct AT commands to query or set a specific port. Without specifying a port in the command, commands are applied to port 1 by default. Use AT<command>?,2 to query port 2 or AT<command>=[n],2 to set port 2. You can also use AT<command>?,0 to query port 1 or AT<command>=[n],0 to set port 1. The commands that may apply to dual serial mode settings are described in Table D-11.

Table D-11: Serial AT Commands

Command	Description
AIP	Query or set the option to allow IP addresses to communicate on UDP over serial.
	Note: In dual serial port mode, use AIP,0 for port 1 and AIP,2 for port 2. For example, AT*AIP?,0 to query port 1, or AT*AIP=1,2 to set port 2.
	AT*AIP? to query AT*AIP=n to set
	 n=0—Allow only the IP address specified in S53 to connect when UDP auto answer is enabled (S82=2) n=1—Allow any incoming IP address to connect when UDP auto answer is enabled (S82=2)
	Always subject to any security filters that may be defined. (See Security on page 514.)
\APPP	Initiates a PPP connection on serial terminal. You can also initiate a PPP connection using the ADT command and one of the supported phone numbers.
*CTSE	Query or set asserting Clear To Send (CTS) when there is a network coverage. AT*CTSE? to query AT*CTSE=n to set • n=0—Disabled (default) • n=1—Enable assertion of CTS when there is network coverage
DAE	Query or set AT Escape Sequence detection. ATDAE? to query ATDAE=n to set • n=0—Enable • n=1—Disable (The escape sequence (+++) is ignored.)
*DPORT	Query or set the device port that the device listens on for inbound packets/data/polls.
	Note: In dual serial port mode, use *DPORT,0 for port 1 and *DPORT,2 for port 2 For example, AT*DPORT?,2 to query port 2, or AT*DPORT=12345,2 to set port 2.
	AT*DPORT? to query AT*DPORT=n to set • n=1-65535

Table D-11:	Serial AT	Commands

Command	Description
*DU	Query or set the dial command to only use UDP.
	Note: In dual serial port mode, use *DU,0 for port 1 and *DU,2 for port 2. For example, AT*DU?,0 to query port 1, or AT*DU=1,2 to set port 2.
	 AT*DU? to query AT*DU=n to set n=0—Dial using the means specified (default) n=1—Dial UDP always, even when using ATDT When this parameter is set you cannot establish a TCP PAD connection by using the Dial command.
*ENQ	Query or set the option to output an ENQ [0x05] after the TCP CONNECT, delayed by the Delay Connect Response time (S221). AT*ENQ? to query AT*ENQ=n to set • n=0—Disable (default) • n=1—Enable ENQ on TCP CONNECT
*HOSTMODE?	Query the current host mode. AT*HOSTMODE? returns: AT PPP TCP UDP Note: If the device is not in AT mode, Telnet into the device to execute this command.

Command	Description
MD	
	<i>Note:</i> Query or set the default startup mode for the serial port. When the device is power- cycled, the serial port enters the mode specified by this command after 5 seconds. On startup, typing ATMD0 within 5 seconds changes the mode to normal (AT command) mode. <i>In dual serial port mode, use MD,0 for port 1 and MD,2 for port 2. For example,</i> <i>ATMD?,0 to query port 1, or ATMD<hh>,2 to set port 2. In dual serial port mode, startup</hh></i> <i>mode can only be set to Normal, UDP, and TCP.</i>
	ATMD? to query ATMD <hh> (hex byte) to set • <hh>=00—Normal (AT Command mode) • <hh>=02—PPP • <hh>=03—UDP • <hh>=04—TCP • <hh>=04—TCP • <hh>=08—reverse telnet/ssh</hh></hh></hh></hh></hh></hh></hh>
	 <hh>=13—Modbus ASCII</hh> <hh>=23—Modbus RTU (Binary)</hh> <hh>=33—BSAP</hh>
	 <hh>=63—Variable Modbus</hh> <hh>=83—UDP Multiple Unicast</hh>
MLIST	 Add IP addresses to the Modbus address list or query the Modbus address list, using decimal index values. Format is MLISTIndex(decimal)=IP address Example: ATMLIST10=123.123.123.123, where: 10 is the Index 123.123.123.123 is the IP address MLISTIndex=IP to add an IP address to the list Including the port number after the IP address by a colon. For example: 10=123.123.123.123.11223 MLIST? to query the Modbus address list; returns the addresses in the list in the format Index=IP. For example: 10=123.123.123.123 11=124.124.124.124 12=125.125.125.125
	13=126.126.126.126 Range for index numbers is 0–255. The Modbus address list accepts up to 100 entries.

Table D	-11: S	erial AT	Commands
---------	--------	----------	----------

Table	D-11:	Serial AT	Commands
-------	-------	-----------	----------

Command	Description
MLISTX	Add IP addresses to the Modbus address list or query the Modbus address list, using hexadecimal index values.
	Format is MLISTXIndex(hex)=IP address
	Example: ATMLISTX000A=123.123.123.123, where:
	000A is the Index
	• 123.123.123 is the IP address
	MLISTXIndex=IP to add an IP address to the list
	Including the port number after the IP address is optional. If you include the port number, separate the port number and IP address by a colon.
	For example: 0xA=123.123.123.123:11223
	MLISTX? to query the Modbus address list returns; returns the addresses in the list in the format Index=IP.
	For example:
	000A=123.123.123.123
	000B=124.124.124.124
	000C=125.125.125.125
	000D=126.126.126.126
	Range for index numbers is 0x0–0xFF. The Modbus address list accepts up to 100 entries.
MVLEN	Query or set the length of the Modbus Variant ID.
	ATMVLEN? to query
	ATMVLEN=[length of the RTU ID in bytes] to set
MVMSK	Query or set the Modbus Variant ID Mask (byte hex mask to use when extracting the ID). This parameter is used when the when the Mode Default (MD on page 534) is set to hex 63.
	ATMVMSK? to query
	ATMVMSK=[byte hex mask] to set
MVOFF	Query or set the Modbus (Variable mode) offset in the data where the Modbus ID starts.
	ATMVOFF? to query
	ATMOFF=n to set
	• n= 0-255
Μντγρ	Query or set the Modbus Variant type (RTU ID data-type in a modbus-variant protocol). This parameter is used when MD on page 534 is set to 63. It defines the data-type of the RTU ID in Modbus-like protocol data packets.
	ATMVTYP? to query
	ATMVTYP=n to set
	• n=0—Binary
	• n=1—ASCII hex
	n=2—ASCII decimal

Command	Description
IPL	Query or set the IP list dial. AT*IPL? to query AT*IPL=n to set • n=0—Disable • n=1—Enable This allows you to access to the Modbus IP address list using the first two digits of the dial string. Example: ATDT1234567 would go to ID "12" on the Modbus list and use the associated IP as the destination.
*NUMTOIP	Query or set the option to convert a 12-digit number to an IP address. For example, converts 192168254000 to 192.168.254.000 Note: In dual serial port mode, use *NUMTOIP,0 for port 1 and *NUMTOIP,2 for port 2. For example, AT*NUMTOIP?,0 to query port 1, or AT*NUMTOIP=1,2 to set port 2. AT*NUMTOIP? to query AT*NUMTOIP=n to set • n=0—Disable
S50	n=1—Enable Query or set the data forwarding idle timeout. Note: In dual serial port mode, use \$50,0 for port 1 and \$50,2 for port 2. For example,
	ATS50?,0 to query port 1, or ATS50=12345,2 to set port 2. ATS50? to query ATS50=n to set • n=0—a forwarding timeout of 10 ms is used. • n=tenths of a second
S51	Query or set the PAD data forwarding character. ASCII code of character that causes data to be forwarded. Used in UDP or TCP PAD mode. <i>Note: In dual serial port mode, use S51,0 for port 1 and S51,2 for port 2. For example,</i> <i>ATS51?,0 to query port 1, or ATS51=12345,2 to set port 2.</i> ATS51? to query
	AT51=CHARACTER to set • n=0—No forwarding character • n=CHARACTER

 Table D-11:
 Serial AT Commands

Table D-11: Serial AT Commands

Command	Description		
S53	Query or set the method (dial mode), destination IP address, and port used as defaults for the D (Dial) AT command.		
	Note: In dual serial port mode, use S53,0 for port 1 and S53,2 for port 2. For example, ATS53?,0 to query port 1, or ATS53=[method][d.d.d.d][/ppppp],2 to set port 2.		
	ATS53? to query ATS53=[method][d.d.d.d][/ppppp] to set [method] can be:		
	 P—UDP T—TCP [d.d.d] is the destination IP address [pppp] is the port number. 		
	Example: ATS53=P111.22.33.44/5555 where:		
	 The first character is the dial mode (P in this example) Followed by destination IP address (111.22.33.44 in this example) A slash Followed by the destination port (5555 in this example) You can also use this command to set only the port. For example, AT53=/7777. 		
S60	Query or set the Telnet Client Echo Mode. ATS60? to query ATS60=n to set • n=0—No Echo • n=1—Local Echo (default) • n=2—Remote Echo		
S82	Query or set UDP auto answer.		
	Note: In dual serial port mode, use S82,0 for port 1 and S82,2 for port 2. For example, ATS82?,0 to query port 1, or ATS82=1,2 to set port 2.		
	ATS82? to query ATS82=n to set • n=0—Disable • n=1—Enable		

Command	Description
S83	Query or set the UDP auto answer idle timeout. If no data is sent or received before the timeout occurs, the current UDP session is terminated. While a session is active, packets from other IP addresses are discarded (unless *UALL is set). ATS83? to query ATS83=n to set • n=0—No idle timeout (default) • n=1-255—Timeout in seconds Note: This AT command only takes effect if the UDP Auto Answer (S82) is set to Enable.
*SERIALLEDDISPLAY	Query or set whether or not the Activity LED on the AirLink RV55 indicates traffic on the selected serial port. AT*SERIALLEDDISPLAY? to query AT*SERIALLEDDISPLAY=n to set • n=0—LED display of serial traffic disabled (default) • n=1—LED display of serial traffic enabled For a description of the Activity LED when this parameter is enabled, see Display on page 346.
*SERIALLEDPORT	Query or set the port for which the Activity LED will indicate traffic. AT*SERIALLEDPORT? to query AT*SERIALLEDPORT=n to set • n=0—Primary serial port (default) • n=1—I/O port, when configured for RS-485
TCPS	Query or set the TCP connection timeout (TCPS) units. If there is no traffic through the TCP connection for the specified interval, the connection is terminated. Note: In dual serial port mode, use TCPS,0 for port 1 and TCPS,2 for port 2. For
	example, ATTCPS?,0 to query port 1, or ATTCPS=1,2 to set port 2. ATTCPS? to query ATTCPS=n to set • n=0—minutes • n=1—seconds
ТСРТ	Query or set the interval to terminate a TCP connection when there is no traffic. This value affects only the TCP connection in TCP PAD mode. <i>Note: In dual serial port mode, use TCPT,0 for port 1 and TCPT,2 for port 2. For example, ATTCPT?,0 to query port 1, or ATTCPT=1,2 to set port 2.</i>
	ATTCPT? to query ATTCPT=n to set • n=0-255

 Table D-11:
 Serial AT Commands

Table	D-11:	Serial AT	Commands
-------	-------	-----------	----------

Command	Description
*UALL	Query or set the ability to accept UDP packets from any IP address when a UDP session is active. If there is no UDP session active, an incoming UDP packet will be treated according to the UDP auto answer and AIP settings.
	Note: In dual serial port mode, use *UALL,0 for port 1 and *UALL,2 for port 2. For example, AT*UALL?,0 to query port 1, or AT*UALL=1,2 to set port 2.
	AT*UALL? to query AT*UALL=n to set • n=0—No effect (default) • n=1—Accept UDP data from all IP addresses when in a UDP session
*UDPLAST	Query or set the option to set S53 to the last accepted IP address through UDP auto answer. This can be used in conjunction with MD3 so that when there is no UDP session, new Ethernet host data will cause a connection to be restored to the last IP accepted through UDP auto answer.
	Note: In dual serial port mode, use *UDPLAST,0 for port 1 and *UDPLAST,2 for port 2. For example, AT*UDPLAST?,0 to query port 1, or AT*UDPLAST=1,2 to set port 2.
	AT*UDPLAST? to query AT*UDPLAST=n to set
	 n=0—Does not change destination IP (default) n=1—Change destination IP to last received
*UDPPADMTU	Query or set the size of serial MTU (PAD payload). AT*UDPPADMTU? to query AT*UDPPADMTU=n to set • n=256-4096
*USD	Query or set the specified delay before sending the UDP packets out the serial port.
	Note: In dual serial port mode, use *USD,0 for port 1 and *USD,2 for port 2. For example, AT*USD?,0 to query port 1, or AT*USD=1,2 to set port 2.
	AT*USD? to query AT*USD=n to set • n=0—No UDP packet delay (default) • n=1-255—Delay in 100 ms units, from 100 ms to 25.5 sec.

Standard (Hayes) commands

The following table contains Hayes commands supported on the AirLink RV55.

Table D-12: Standard (Hayes) AT Commands

Command	Description
+++	AT escape sequence (not preceded by AT)
	If a serial terminal is in a data mode, typing this sequence on that serial terminal causes the terminal to re-enter AT command mode. There must be an idle time on the serial port before and after the sequence. The idle time is set by the value in S50.
	After you type the AT escape sequence, the terminal remains in AT command mode for 15 seconds before it automatically leaves AT command mode and returns to the previous data mode.
	Note: The "+" is ASCII character 0x2B.
	Note: The detection of this sequence is disabled if DAE=1.
&C	Query or set Data Carrier Detect (DCD) mode.
	DCD is a hardware signal that notifies the software that the device is communicating with another device.
	AT&C? to query
	AT&Cn to set
	n=0—Always assert DCD
	n=1—Assert DCD enable when network is ready (default)
	Note: Do not use an equal sign (=) when issuing the command.

Command	Description
D[method] [d.d.d.d] [/ppppp] or D[method] [[@]name] [/ppppp]	 Dial a connection to a remote IP and Port using either UDP, TCP, or Telnet. You can only use ATD#19788 and ATDT#19788 locally. <i>method</i> = P—Establish a UDP connection T—Establish a TCP connection N—Establish a TCP connection <i>d.d.d.d</i> = IP address to establish connection to <i>name</i> = Domain name to establish connection to <i>pppp</i> = IP port to establish connection per S53 ATDP-Dial (establish) default connection per S53 ATDPnnn.nnn.nnn[/pppp]—Dial (establish) UDP session to the specified IP address/ port. If the method, IP address, or port is omitted, the values from S53 are used. If a Telnet connection is requested (N) and the port is not supplied, port 23 will be used instead of the value from S53. Several special dialing numbers exist to make it easy to establish a PPP connection with the device. ATD#19788 or ATDT#19788 will establish a PPP connection (see VAPPP on page 532). If a domain name is specified, the '@' symbol can be used to explicitly indicate the start of the name. For example, if "ATDPHONY" is issued, this will be interpreted as dial a UDP connection to "HONY". To dial using the default method to host "PHONY", one would issue "ATD@PHONY". To end the connection, issue the +++ escape sequence or drop the DTR line (if Ignore DTR S211=0 or &D2).
&D	 Query or set Data Terminal Ready (DTR) mode. AT&D? to query AT&Dn to set n=0—Devices ignores DTR, same effect as HW DTR always asserted (same as S211=1); DTD is assumed to be on. n=1—DRT drop causes the device to switch to AT command mode, but does not drop the connection. n=2—DTR drop causes the connection to drop. n=3—DTR drop causes the connection to reinitialize. Note: Do not use an equal sign (=) when issuing the command.

Table D-12: Standard (Hayes) AT Commands

Command	Description
*DATZ	Query or set the option, on any serial interface, to block device reset using ATZ. AT*DATZ?[comm port] to query AT*DATZ=[comm port], n to set [comm port]=0—RS232 Serial Port [comm port]=1—RS485 Serial Port [comm port]=2—Dual Serial Port (relating to host on second serial port) [comm port]=3—USB Serial [comm port]=4—Telnet/SSH [comm port]=99—ALL Ports (not valid for query; use only for setting)
	Note: Specifying a [comm port] is optional. When no [comm port] is included in the command—AT*DATZ? or AT*DATZ=1, for example—the command applies to the serial interface being used to send the command.
	 n=0—Off. Block is disabled—ATZ resets the device. (default) n=1—On. Block is enabled—ATZ does not reset the device.
E	Toggle AT command echo mode.
	Note: In dual serial port mode, use E,0 for port 1 and E,2 for port 2. For example, ATE?,0 to query port 1, or ATE1,2 to set port 2.
	 ATE? to query ATEn to set n=0—Echo Off; does not echo commands to the computer n=1—Echo On; echoes commands to the computer (so you can see what you type)
	Note: Do not use an equal sign (=) when issuing the command.
Н	ATH hangs up, immediately terminates the session (PAD or PPP).
HOR	Half-Open Response—In UDP auto answer (half-open) mode.
	Note: In dual serial port mode, use HOR,0 for port 1 and HOR,2 for port 2. For example, ATHOR?,0 to query port 1, or ATHOR=1,2 to set port 2.
	 ATHOR? to query ATHOR=n to set n=0—No response codes when UDP session is initiated n=1—RING CONNECT response codes sent out serial link before the data from the first UDP packet
	Note: Quiet Mode must be Off.

Table D-12: Standard (Hayes) AT Commands

Command	Description
Q	Query or set AT quiet mode. If quiet mode is set, there are no responses to AT commands except for data queried.
	Note: In dual serial port mode, use Q,0 for port 1 and Q,2 for port 2. For example, ATQ?,0 to query port 1, or ATQ1,2 to set port 2.
	ATQ? to query ATQn to set • n=0—Off (default) • n=1—Quiet mode on
	Note: Do not use an equal sign (=) when issuing the command.
\Q	Query or set the serial port flow control.
	Note: In dual serial port mode, use $Q,0$ for port 1 and $Q,2$ for port 2. For example, $ATQ?,0$ to query port 1, or $ATQ1,2$ to set port 2.
	AT\Q? to query AT\Qn to set
	 n=0—No flow control n=1—Hardware flow control
	 n=1—Hardware flow control n=4—Transparent software flow control
	Note: Do not use an equal sign (=) when issuing the command.
&S	Query or set DSR. AT&S? to query AT&Sn to set • n=0—Always assert • n=1—Assert DSR while in data mode (UDP, TCP, PPP)
	Note: Do not use an equal sign (=) when issuing the command.

Table D-12: Standard (Hayes) AT Commands

Command	Description
S0	Query or set TCP auto answer (the number of rings required before the device automatically answers a call).
	Note: In dual serial port mode, use S0,0 for port 1 and S0,2 for port 2. For example, ATS0?,0 to query port 1, or ATS01,2 to set port 2.
	ATS0? to query ATS0n to set • n=0—Disable • n=1—Enable
	Note: Do not use an equal sign (=) when issuing the command.
S7	Query or set the number or seconds to wait for connection completion.
	Note: In dual serial port mode, use S7,0 for port 1 and S7,2 for port 2. For example, ATS7?,0 to query port 1, or ATS71,2 to set port 2.
	ATS7? to query ATS7n to set • n=0-255

Table D-12: Standard (Hayes) AT Commands

 Table D-12:
 Standard (Hayes)
 AT Commands

Command	Description
S23	Query or set the Serial port configuration.
	Note: In dual serial port mode, use S23,0 for port 1 and S23,2 for port 2. For example, ATS23?,0 to query port 1, or ATS23=[Baud,][Data bits, Parity, Stop Bits],2 to set port 2.
	ATS23? to query. ATS23=[Baud,][Data bits, Parity, Stop Bits] to set
	Note: Setting data bits, parity, and stop bits is supported with or without commas. For example, either ATS23=115200,8,N,2 or ATS23=115200,8N2 will produce the same result.
	ATS23=[Baud] to set the baud rate for the default port (or port 1 for dual serial ports). Baud: • 300 • 1200 • 2400 • 4800 • 9600 • 19200 • 38400 • 57600 • 115200 Data bits: • 7 • 8 Parity: • O=Odd • E=Even • N=None • M=Mark Stop Bits: • 1 • 2 Example: ATS23=115200,8,N,2 (Sets the device to 115200, etc.) The settings take effect after reboot.
	Note: Must be 8 data bits for PPP mode.

Command	Description
S211	For applications or situations where hardware control of the DTR signal is not possible, the device can be configured to ignore DTR. When Ignore DTR is enabled, the device operates as if the DTR signal is always asserted. ATS211? to query ATS211=n to set • n=0—Use hardware DTR (default) • n=1—Ignore DTR • n=3—Ignore DTR and assert DSR.
S221	Query or set the Connect Delay—the number of seconds to delay the connect response when establishing a TCP connection. <i>Note: In dual serial port mode, use S221,0 for port 1 and S221,2 for port 2. For example, ATS221?,0 to guery port 1, or ATS221=1,2 to set port 2.</i>
	ATS221? to query ATS221=n to set • n=0-255
V	Query or set the AT command responses (verbosity).
	Note: In dual serial port mode, use V,0 for port 1 and V,2 for port 2. For example, ATV?,0 to query port 1, or ATV1,2 to set port 2.
	 ATV? to query ATVn to set n=0—Numeric (terse) command responses (The numeric responses follow the Hayes Standards for commands.) n=1—Text string (verbose) command responses (default)
	Note: Do not use an equal sign (=) when issuing the command.
&V	Lists most AT commands and their current values. If the parameter is not configured, the AT command returns "Not Set".
&W	Saves the settings for parameters that are temporarily set without being permanently written to the memory. This command does not apply to ALEOS because once you issue an AT command or change a setting in ACEmanager and click Apply, the changes are saved in non-volatile memory and are persist across reboots.

Table D-12: Standard (Hayes) AT Commands

Table D-12: Standard (Hayes) AT Commands

Command	Description
x	Query or set the Extended Call Progress Result mode.
	Note: In dual serial port mode, use X,0 for port 1 and X,2 for port 2. For example, ATX?,0 to query port 1, or ATX1,2 to set port 2.
	ATX? to query ATXn to set • n=0—No extended code (default) • n=1—Adds the text 19200 to the connect response
Z	Reboots the AirLink RV55.
	Note: If *DATZ is set to 1, Z is blocked. See *DATZ on page 542.

I/O

Table D-13: Input/Output AT Commands

Command	Description
*ANALOGIN[n]?	Query individual analog input values (in volts). AT*ANALOGIN[n]? • n=1
*DIGITALIN[n]?	Query individual digital inputs. The digital inputs report either a 0 (open) or 1 (closed). AT*DIGITALIN[n]? • n=1
*PULSECNT1?	Query the I/O pulse counts for digital in. AT*PULSECNT1?
*RELAYOUT1	Query or set the relay status. AT*RELAYOUT1? to query AT*RELAYOUT1=n to set • n=0—OFF • n=1—Drive Active Low

Applications

Command	Description
*DATACURDAY?	Display data usage for the current day (in kB). Example: AT*DATACURDAY? <value> OK If this command is used with an AirLink RV55, the query or set applies to the Active SIM. Use *DATACURDAYSIM1? or *DATACURDAYSIM2? to query or set a specific SIM card, based on the slot it is installed in.</value>
*DATACURDAYSIM1?	Display data usage for the current day (in kB) for the SIM card in Slot 1 (upper slot). Example: AT*DATACURDAYSIM1? <value> OK</value>
*DATACURDAYSIM2?	Display data usage for the current day (in kB) for the SIM card in Slot 2 (lower slot). Example: AT*DATACURDAYSIM2? <value> OK</value>
*DATAPLANUNITS	Query or set the units for the data usage report. AT*DATAPLANUNITS? to query AT*DATAPLANUNITS= <unit> to set • <unit>=1—Sets the units to Megabytes (MB) • <unit>=2—Sets the units to Kilobytes (kB) Examples: AT*DATAPLANUNITS? <unit> OK AT*DATAPLANUNITS=<units> OKThe query or set applies to the Active SIM. Use *DATAPLANUNITSSIM1 or *DATAPLANUNITSSIM2 or *DATAPLANUNITSESIM to query or set a specific SIM card, based on the slot it is installed in.</units></unit></unit></unit></unit>

Table D-14: Applications > Data Usage Commands

Command	Description
*DATAPLANUNITSSIM1	Query or set the units for the data usage report for the SIM card in Slot 1 (upper slot). AT*DATAPLANUNITSSIM1? to query AT*DATAPLANUNITSSIM1= <unit> to set • <unit>=1—Sets the units to Megabytes (MB) • <unit>=2—Sets the units to Kilobytes (kB) Examples: AT*DATAPLANUNITSSIM1? <unit> OK AT*DATAPLANUNITSSIM1=<units> OK</units></unit></unit></unit></unit>
*DATAPLANUNITSSIM2	Query or set the units for the data usage report for the SIM card in Slot 2 (lower slot). AT*DATAPLANUNITSSIM2? to query AT*DATAPLANUNITSSIM2= <unit> to set • <unit>=1—Sets the units to Megabytes (MB) • <unit>=2—Sets the units to Kilobytes (kB) Examples: AT*DATAPLANUNITSSIM2? <unit> OK AT*DATAPLANUNITSSIM2=<units> OK</units></unit></unit></unit></unit>
*DATAPLANUNITSESIM	Query or set the units for the data usage report for the R2C eSIM (if available). AT*DATAPLANUNITSESIM? to query AT*DATAPLANUNITSESIM= <unit> to set • <unit>=1—Sets the units to Megabytes (MB) • <unit>=2—Sets the units to Kilobytes (kB) Examples: AT*DATAPLANUNITSESIM? <unit> OK AT*DATAPLANUNITSESIM=<units> OK</units></unit></unit></unit></unit>

 Table D-14: Applications > Data Usage Commands

Command	Description
*DATAPREVDAY?	Query the data usage for the previous day (in kB). Example: AT*DATAPREVDAY? <value> OKIf this command is used with an AirLink RV55, the query or set applies to the Active SIM. Use *DATAPREVDAYSIM1? or *DATAPREVDAYSIM2? to query or set a specific SIM card, based on the slot it is installed in.</value>
*DATAPREVDAYSIM1?	Query the data usage for the previous day (in kB) for the SIM card in Slot 1 (upper slot). Example: AT*DATAPREVDAYSIM1? <value></value>
	ок
*DATAPREVDAYSIM2?	Query the data usage for the previous day (in kB) for the SIM card in Slot 2 (lower slot). Example: AT*DATAPREVDAYSIM2? <value> OK</value>
*DATAUSAGEENABLE	Query or set enabling Data Usage. AT*DATAUSAGEENABLE? to query AT*DATAUSAGEENABLE= <status> to set • <status>=0—Data Usage disabled • <status>=1—Data Usage enabled Example: AT*DATAUSAGEENABLE? <status> OK AT*DATAUSAGEENABLE=<status> OKThe query or set applies to the Active SIM. Use *DATAUSAGEENABLESIM1 or *DATAUSAGEENABLESIM2 or *DATAUSAGEENABLESIM1 or guery or set a specific SIM card, based on the slot it is installed in.</status></status></status></status></status>

Table D-14: Applications > Data Usage Commands

Command	Description
*DATAUSAGEENABLESIM1	Query or set enabling Data Usage for the SIM card in Slot 1 (upper slot). AT*DATAUSAGEENABLESIM1? to query AT*DATAUSAGEENABLESIM1= <status> to set • <status>=0—Data Usage disabled • <status>=1—Data Usage enabled Example: AT*DATAUSAGEENABLESIM1? <status></status></status></status></status>
	OK AT*DATAUSAGEENABLESIM1= <status> OK</status>
*DATAUSAGEENABLESIM2	Query or set enabling Data Usage for the SIM card in Slot 2 (lower slot). AT*DATAUSAGEENABLESIM2? to query AT*DATAUSAGEENABLESIM2= <status> to set • <status>=0—Data Usage disabled • <status>=1—Data Usage enabled Example: AT*DATAUSAGEENABLESIM2? <status> OK AT*DATAUSAGEENABLESIM2=<status> OK</status></status></status></status></status>
*DATAUSAGEENABLEESIM	Query or set enabling Data Usage for the R2C eSIM (if available). AT*DATAUSAGEENABLEESIM? to query AT*DATAUSAGEENABLEESIM= <status> to set • <status>=0—Data Usage disabled • <status>=1—Data Usage enabled Example: AT*DATAUSAGEENABLEESIM? <status> OK AT*DATAUSAGEENABLEESIM=<status> OK</status></status></status></status></status>

Table D-14: Applications > Data Usage Commands

Command	Description
*GARMINATTACH	Query or set the ability to connect a Garmin device to the serial port (so the Garmin device can communicate with a remote server). For more information, see Garmin on page 355. AT*GARMINATTACH? to query AT*GARMINATTACH=n to set • n=0—Disable • n=1—Enable
*GARMINSTATUS?	Query Garmin device attachment status.

Table D-14: Applications > Data Usage Commands

Table D-15: Applications > ALEOS Application Framework (AAF)

Command	Description
*AAFINSTALL	 Query installed AAF applications and their status and install new AAF applications. AT*AAFINSTALL? returns the installation status of the last installed application, and list of installed AAF applications and the status of each application. AT*AAFINSTALL?<application name=""> returns the status of the specified AAF application.</application> AT*AAFINSTALL=<hostname>,<user>,<password>,<application filename=""> downloads and installs the specified AAF application from the FTP server at <hostname> using <user> <password> credentials.</password></user></hostname></application></password></user></hostname>
*AAFUNINSTALL	Install an AAF application. AT*AAFUNINSTALL= <application name=""> uninstalls the specified AAF application.</application>
*AAFLIST?	Queries AAF apps installed on device and their version number. AT*AAFLIST? Example: AT*AAFLIST? Name: ammer, Version: 1.0.3.003 Name: BWMSTest, Version: 1.0.0 OK

Admin

Table D-16: Admin > Advanced Commands

Command	Description
\ACEPW	Set the ACEmanager user password remotely. AT\ACEPW= <password> to set • <password>=character string The password can be 8 to 32 characters long and can contain a mixture of letters, numbers, and/or special characters. The password is case sensitive.</password></password>
	Note: The special character comma ',' cannot be used. To change the password, send the AT Command. You will not be asked to re-enter or confirm the new password.
	Note: If the password is lost, the only way to recover access to the AirLink gateway is to press the hardware Reset button to reset all device settings to factory default. After resetting to factory defaults, the user password will be reset to the default password. If the gateway supports unique default passwords, the default password will be printed on the device label. Note that using the Reset button also resets the M3DA password to the default password. For more information, see Change Password on page 369.
*ALEOSRMLPM	Query or set how ALEOS handles device operation when the radio module is in Low Power mode. This feature is intended for testing and diagnostic purposes, not as part of normal device operation. AT*ALEOSRMLPM? to query AT*ALEOSRMLPM=n to set • n=0—ALEOS does nothing • n=1—ALEOS Normal Behavior (default)
*BLOCK_RESET_CONFIG	 Query or set the ability to block resetting the device to factory default settings using the hardware Reset button. AT*BLOCK_RESET_CONFIG? to query AT*BLOCK_RESET_CONFIG=n to set n=0—Reset button can be used to reset the device to factory default settings. (default). n=1—Device cannot be reset to factory default settings using the Reset button on the device. Note: This command only blocks the ability to reset to defaults using the Reset button on the device. You can still reset the device to the factory default settings
*BOARDTEMP?	button on the device. You can still reset the device to the factory default settings using the "Reset to Factory Default" button in ACEmanager or the *RESETCFG AT command. Query the temperature of the internal hardware, in degrees Celsius.

Table D-16:	Admin	n > Advanced (Commands
-------------	-------	----------------	----------

Command	Description
*MSCIUPDADDR	Query or set the IP address or FQDN and port that periodic device status updates are sent to. AT*MSCIUPDADDR? to query AT*MSCIUPDADDR=[IP address or FQDN][/port] to set Examples: 192.168.14.100/3333 MyDevice.com/3333
*MSCIUPDPERIOD	Query or set the device status update interval (in seconds). This specifies how frequently the device status update is sent to the port configured in *MSCIUPDADDR. AT*MSCIUPDPERIOD? to query AT*MSCIUPDPERIOD=n to set • n=0—Disabled • n=1–255 seconds
NSLOOKUP	Immediately performs an NSLookup on the supplied FQDN. ATNSLOOKUP=[FQDN]
*POWERIN?	Query the voltage input to the internal hardware.
*RESETBTNCONFIG	Query and set Reset Button Configuration setting in Admin > Reset. AT*RESETBTNCONFIG? to query AT*RESETBTNCONFIG=n to set • n=0—Disabled • n=1—Reset All • n=2—Reset to Custom Configuration
*RESETCFG	AT*RESTCFG resets the device to factory default settings according to the Reset Mode configured on the Admin > Advanced page. See Reset Configuration on page 380. Important: There is no confirmation requested. The AT command takes effect immediately.
*RESETCONFIG	Query or set Reset Configuration setting in Admin > Reset. AT*RESETCONFIG? to query AT*RESETCONFIG=n to set • n=0—Reset All • n=1—Preserve Core Settings • n=2—Preserve Only User Password • n=3—Reset to Custom Configuration
*RESETTPL?	Queries the existence of a reset template on a device. If a reset template does not exist, NOTSET will be returned. Otherwise, the query returns the name of the template.

 Table D-16:
 Admin > Advanced Commands

Command	Description
*REMOTELOG	Exports the log file to a remote destination (Syslog Server). AT*REMOTELOG= <server>[,<port>,<format>,<protocol>,<encrypt>] where: parameters between brackets are optional. If the port is not specified, the default port, 514, is used.</encrypt></protocol></format></port></server>
	Note: This AT command is backwardly compatible with the existing AT command AT*REMOTELOG= <server>,<port>.</port></server>
*RSTTPLUPDATE	Uploads a reset template on device using FTP server. AT*RSTTPLUPDATE= <ftp ip="" server="">,<user>,<password>,<reset template<br="">Name></reset></password></user></ftp>
*SECUREMODE	 Query or set the secure mode that blocks most ports (and ICMP) for over-the-air (OTA) or OTA and local to prevent unwanted access to the device. AT*SECUREMODE? to query AT*SECUREMODE=n to set n=0 Off; normal behavior n=1 Disables: Web management ports (ACEmanager and ALMS access) from the OTA interface Internet Control Message Protocol (ICMP), used for PING, for OTA and Wi-Fi n=2 Disables: Web management ports from the Over-the-air (OTA) interface Internet Control Message Protocol (ICMP) for OTA and Wi-Fi Net: Telnet and SSH ALEOS ports remain open regardless of the secure mode setting. This enables you to connect an AT console to manage the device. DHCP and DNS ports also remain open to allow the device to provide IP addresses to hosts and relay the DNS service.
*SYSRESETS?	Query the number of resets since the device was reset to factory default settings.
*USBBYPASS	Query or set Radio Passthru mode. AT*USBBYPASS? to query AT*USBBYPASS=n to set • n=0—Disable • n=1—Enable

E: SMS Commands

SMS Command format

PW [Password] [Prefix][Command or Command parameter1] [Command parameter2 (if applicable)] [Command parameter n]

Note: There is no space between the prefix and the command (or the 1st command parameter in the case of multi-parameter commands). There must be a single space between all other fields to act as a delimiter.

The default password is the last 4 digits of the SIM ID number (for SIM-based devices) and the last 4 digits of the ESN (for non-SIM devices). If you do not know the SIM ID or ESN number, you can find it in ACEmanager on the Status > WAN/Cellular page.

The default prefix is "&&&".

Whether or not a password and prefix are required varies depending on the SMS mode selected in ACEmanager.

SMS mode	Password (configurable in all modes)	Prefix
Password Only	Always required	Required Use default (not configurable)
Control Only	Required when sending from a non-trusted phone number	Prefix is configurable. The prefix can be omitted if the ALEOS Command Prefix field in ACEmanager (Services > SMS) is configured to be blank.
Gateway Only	Always required	Required Use default (not configurable)
Control and Gateway	Required when sending from a non-trusted phone number	Required Configurable, but cannot be blank

When an SMS command is received, the AirLink RV55 performs the action requested and sends a response back to the phone number from which it received the SMS.

For more examples and detailed instructions, see SMS on page 242.

List of SMS Commands

Command	Action	Result
Note: Some responses start with "re and Provision commands.	ply from [device name]:" However, this	s feature is currently unavailable for the Enable
[prefix]enable <value></value>	Enable/disable the device(s) being managed by ALMS.	"AVMS enable set to status:" <value> <value>=0 Disable <value>=1 MSCI <value>=2 LWM2M <value>=3 Try LWM2M, Fallback to MSCI</value></value></value></value></value>
[prefix]status	None	status IP [Network IP] [Network Status]: [technology type] RSS signaled Lat = [Latitude] Long = [Longitude] Time = [hh:mm:ss]
		Note: Location Service must be enabled to obtain Lat and Long data.
[prefix]reset	Resets the device 30 seconds after the first response message is sent.	First message: Reset in 30 seconds Second message: Status message when back up.
[prefix]relay x y	Sets the I/O relay to the desired setting.	relay x set to y x can be 1 y can be 0 or 1 (Off or Drive active low)
[prefix]relay x ?	Queries the current value of the I/O relay.	relay x set at y x can be 1 y is the current value of the I/O relay. (0 = Off; 1 = Drive active low)
[prefix]gps	The device replies with its current location.	The device sends a link to a map showing its location. You can copy the link into a browser to view the location, or if the SMS is sent from a smartphone, you can click the link to view the map.
		Note: Location Service must be enabled.

Command	Action	Result	
[prefix]Provision <apn> <network User ID> <network password=""> <network authentication="" mode=""></network></network></network </apn>	After the unit is installed and the SIM card inserted, you can use this command to provision the account.	"provision" "apn:" <apn> "user ID" <network id="" user=""></network></apn>	
 Note: You can omit any of the above parameters. To omit a parameter before the one you want to change, use a period (.) in place of the omitted parameter. Example: &&&provision . user@carrier.com . chap changes only the user ID and authentication mode. If you want to omit any parameters after the one you want to change, simply omit them. Example: &&&provision access.apn changes only the apn. 	 Network Authentication Mode is optional. If used, enter one of the following: None PAP CHAP These are not case sensitive. If an unknown mode is entered or the field is omitted, None is used. 	"PW" <network password=""> "auth mode" <network authentication="" mode=""> Note: If a parameter is omitted, the response displays "Not Set" for that parameter.</network></network>	
[prefix]AVMS <server> <interval> Note: All of the above must be on a single line. The interval must be greater than 0. Omitting any field results in a response of "not set" and the configuration parameter does not change.</interval></server>	Modifies the ALMS server's URL and ALMS communication period (interval in minutes)	"AVMS" "srv:" <server> "interval:" <interval></interval></server>	
[prefix]AVMSCHECKIN	Prompts the device to communicate with the ALMS server. Once AirLink Management Service receives the heartbeat message, it can respond and send an MSCI command to the device (i.e Write/Read/ Firmware Update).	"AVMS connection requested"	

F: Q & A and Troubleshooting

ACEmanager Web UI

The ACEmanager page is not displaying properly.

- 1. Ensure the you are using a supported browser. See page 16 for a list of supported browsers.
- 2. Hold the Shift key + click the Refresh button. This reloads the page, while ignoring what is in the cache.

If the problem persists:

- Clear the cache. The procedure varies, depending on the browser.
- Restart the browser.
- Restart your computer.

Templates

The template does not upload properly when I use Internet Explorer 9.

To resolve the problem:

- 1. In Internet Explorer 9, go to Tools > Internet Options.
- 2. Select the Security tab.



Figure F-1: Internet Explorer 9: Tools > Internet Options > Security tab

- 3. Click Custom level....
- 4. Scroll down until you see "Include local directory path when uploading files to a server".

5. Select Disable.

Settinge .			
	Dreatle Brothe Propriet		1
1.75	adie XME Solling Datein Etwin		
	clude lectel directory path leften upl Entitie Fradie	10.000 (10.000) 13	
1.58	karching applications and unsafe the) braidte) Gradie (hot secure)	NR.	100
28) Prompt (tecommended) uniting programs and Nea is an 2) Dealer	TARE	
	Enable (not secure)) Prompt (reconcended)		
14	The second secon		
"Tains e	Net other yes remert Internet Explo	ne .	
	eri witinga		
formed the i	Mail.en high (default)		Feed.

Figure F-2: Internet Explorer 9: Security Settings

6. Click OK.

Updating the ALEOS Software and Radio Module Firmware

I am unable to update the ALEOS software and radio module firmware using ACEmanager.

Note: For LTE-M/NB-IoT AirLink gateways: Due to the lower data rates supported by LTE-M/NB-IoT networks, over-the-air software updates can take an extended period of time. When using a Windows PC and ACEmanager to update ALEOS software over-the-air, please ensure that sleep and low power states are disabled on the PC so that the file transfer is not disrupted. Under these conditions, the ALEOS upgrade may take between 3 to 5 hours.

Sierra Wireless recommends using ALMS or AMM for remote software upgrades.

If you are having trouble updating the ALEOS software or radio module firmware, especially if you are updating from an older version of ALEOS:

- 1. Try using a different browser. (ACEmanager supports the latest versions of Internet Explorer and Firefox.)
- 2. Delete the browser cookies/cache before logging into ACEmanager. (The Web browser short-cut is Control + Shift + Delete.)
- **3.** Backup your device settings by downloading and saving the template. See Saving a Custom Configuration as a Template on page 20.
- 4. Reset the device to factory default settings. (See Reset to Factory Default on page 379 or press and hold the reset button on the device for 7 to 10 seconds.)

- 5. Begin the update process (see Update the ALEOS Software and Radio Module Firmware on page 25) and follow the prompts.
- 6. If after 30 minutes the WebUI is frozen, log in using a different browser and confirm whether or not the ALEOS software and radio module firmware has been updated correctly.
- 7. If you are still having problems, contact your Sierra Wireless distributor.

When I try to update ALEOS using ACEmanager, I see the following message: "... Check that your package is compatible with the device".

Software and Firmware			clase
Seenth Installed Tystem Informatio ALEOS Software Version: Device Model Radio Module Type Radio Fernivare Version: SW0	4.5.0 0X450 MC7954	ALEOS Build number: Radio Module Identifier 5.55.00 (27038 carmó fivibul)	201505183432 ATT m 20150364 21:30:23
Select: # ALSON Se Browse	o file selec		ļ
Suprading			Cetter
S. Appropring Country in an Austri the device	u altri ci consi	det. Check thet plut pickage is to	mpalba witi
4. Rebinning			

This message also appears if you are only updating the radio module firmware and you have the Update ALEOS radio button selected.

To correct the problem:

- 1. Close the Update page.
- 2. Retry the radio firmware update, being careful to select the Radio Module Firmware that is appropriate for your RV55.

When I try to update ALEOS using ACEmanager, I see the following message: "Please select a firmware for xxxx".

This message appears and you are blocked from continuing with the update if you are only updating the radio module and you select a radio module firmware file designed for a different radio module.

To correct the problem:

1. Click OK.

2. Select a radio module firmware file for the radio module in the AirLink RV55 you are updating and click update. (To check which radio module is in your device, in ACEmanager, go to Status > About.)

Poor Wireless Network Connection

ACE manager indicates that my AirLink RV55 has a poor wireless connection. What can I do to improve it?

For GSM networks:

- 1. Check the RSSI value. If ACEmanager (Status screen) indicates a good RSSI value, go to step 2. If it indicates a poor RSSI value:
 - Check the antenna connection.
 - Make sure you have the correct antenna for the device.
 - You may be in an area with poor coverage. Check with your Mobile Network Operator, or if possible, try moving the AirLink RV55 to a new location.
- 2. Check the Ec/lo value. If ACEmanager (Status screen) indicates a poor Ec/lo value:
 - This may be a temporary network problem caused by local interference.
 - A nearby laptop or other electronic equipment may be interfering with the signal. Try moving the AirLink RV55 to a different location.

For LTE networks:

- 1. Check the RSSI value. If ACEmanager (Status screen) indicates a good RSSI value, go to step 2. If it indicates a poor RSSI value:
 - · Check the antenna connection.
 - Make sure you have the correct antenna for the device.
 - Try moving the AirLink RV55 to a different location.
- 2. Check the RSRP value. If ACEmanager (Status screen) indicates a good RSRP value, go to step 3. If it indicates a poor RSRP value:
 - This may be a temporary network problem caused by local interference.
 - Check the antenna connection.
 - Make sure you have the correct antenna for the device.
 - You may be in an area with poor coverage. Check with your Mobile Network Operator, or if possible, try moving the AirLink RV55 to a new location.
- **3.** Check the RSRQ value. If ACEmanager (Status screen) indicates a poor RSRQ value:
 - A nearby laptop or other electronic equipment may be interfering with the signal. Try
 moving the AirLink RV55 to a different location.

Connection not working

My RV55 appears to be connected to the host, but no data is being transferred.

- 1. Check to see if MAC filtering is enabled (Security > MAC Filtering).
- **2.** If MAC filtering is enabled:
 - Ensure that the MAC Address for the host in question is on the Allowed List.
 - Ensure that there are no typos in the MAC Address.

```
– Or –
```

• If it is not required, disable MAC Filtering and reboot the device.

My host device is unable to connect to the Internet, even when there is good mobile network coverage and ALEOS can Ping an external IP address.

1. Check the DNS proxy setting described on page 164.

You may need to change this setting to Disable so that all connected devices acquire the Mobile Network Operator-defined DNS server as the first DNS server. The AirLink RV55 is not used as the DNS resolver.

Wi-Fi

The Wi-Fi channel I selected is not working.

Each country controls which Wi-Fi channels are allowed in that country. If the Wi-Fi channel you selected is not working:

- 1. In ACEmanager, go to Wi-Fi > General > Country Code, and ensure that it is set to the country in which the router is operating.
- Go to Wi-Fi > Access Point (LAN) > Channel and Frequency (or Channel, Frequency, Width, depending on the Access Point Mode selected), and ensure that the channel you selected is permitted in the country selected.

If you are not sure:

a. Go to Admin > Log > View Log to generate a log file. If the Wi-Fi channel selected is not permitted in the country selected in the Country Code, you will see messages similar to the following in the log file:

```
Apr 26 01:10:40 info ALEOS WIFI_CRD: hostapd: uap0: IEEE 802.11 Configured channel (149) not found from the channel list
of current mode (2) IEEE 802.11a
Apr 26 01:10:40 info ALEOS WIFI CRD: hostapd: uap0: IEEE 802.11 Hardware does not support configured channel
```

 If you see this in the log, select a channel that is permitted in the country the router is operating in. (If necessary, check online resources such as https://en.wikipedia.org/ wiki/List_of_WLAN_channels/ to determine the permitted channels.)

Note: The Country Code settings configure a subset of the channels available in the default setting (United States). You cannot enable any channels beyond those available in the default setting.

4. Reboot the router.

LTE Networks

How do I obtain and interpret SINR values for LTE networks?

You can use the AT*CELLINFO? command to obtain an SINR (Signal to Interference plus Noise Ratio) value. (See *CELLINFO2? on page 470.)

The values vary depending on the network characteristics and the AirLink RV55, but in general, a positive value provides usable throughput. The following table provides guidelines for interpreting SINR values.

SINR Value	Throughput
< 0	Poor
0 to 5	Fair
6 to 10	Good
> 10	Excellent

If the SINR value indicates poor throughput:

- Move the antenna away from noisy equipment.
- Move closer to the nearest cell tower line of sight, or further away from the interfering cell tower.

SIM Card is Blocked

My SIM card has a PIN number. I've entered the wrong PIN several times and now the SIM card is blocked.

AirLink products do not support Personal Unlocking Key (PUK) entry. However, if you need to unblock the SIM card:

- 1. Contact your Mobile Network Operator to obtain the PUK.
- 2. Remove the SIM card from the AirLink RV55 and insert it in a cell phone that accommodates a MiniSIM (2FF) card.
- **3.** Enter the PUK to unblock the SIM card and then return the SIM card to the AirLink RV55.

Note: Be careful when entering the PUK. You have a limited number of attempts to enter the correct PUK (generally 10) before the SIM card is permanently disabled and a new SIM card is required. If the PUK does not unblock the SIM card after the first few attempts, contact your Mobile Network Operator.

Remote connections

I cannot connect to the AirLink RV55 remotely over the Mobile Network Operator's Private Network via the Web UI, although I can connect to it locally.

Some Mobile Network Operators' private networks have restrictions on the maximum transmission unit (MTU) size. This is more prevalent with LTE networks.

Possible solutions:

Use your Mobile Network Operator's public network.

• Ask your Mobile Network Operator to reduce the MTU size on the router or other equipment at their end of the private network. Setting the MTU value below 1500 bytes (for example 1326 bytes) has resolved the problem on some private networks.

Radio Band Selection

I set the radio band in the UI (WAN/Cellular > Setting the Band) or by using the AT!BAND AT command, but after I reboot the band setting reverts to its former value.

For some SIM cards, you need to set the band before inserting the SIM card.

To resolve this problem:

- **1.** Remove the SIM card.
- 2. Set the band to the desired value.
- **3.** Reboot the device.
- 4. Insert the SIM card.

Low Voltage Standby Mode

How do I get my RV55 out of Low Voltage Standby mode?

The problem: While configuring Low Voltage Standby mode, I inadvertently set the Resume Immediately Voltage too high (i.e. higher than the voltage available where the RV55 is installed). Now the RV55 is stuck in standby mode.

I connected the RV55 to a higher voltage source, and it resumed normal operation. I reset the Low Voltage Standby values, but the RV55 returned to Standby mode as soon as it was reconnected to the lower voltage source, even though the lower voltage source provided a higher voltage than the new value I just set in the Resume immediately at Voltage field.

The solution: Low Voltage Standby mode settings take effect as soon as you click Apply, but they are not permanently stored until the RV55 is rebooted. To bring a RV55 out of Low Voltage Standby mode if the Resume immediately at Voltage field is set too high:

- 1. Connect the RV55 to a power source and supply voltage that is greater than the value configured in the Resume immediately at Voltage field.
- 2. When the RV55 resumes normal operation, launch ACEmanager and reset the values in the Services > Power Management > Low Voltage Standby fields.
- **3.** While still using the voltage applied in step 1, Click the Reboot button in ACEmanager to reboot the RV55.

The RV55 reboots.

4. Wait until the RV55 reboots itself a second time, or for at least 3 minutes, if you are not sure if the RV55 has done its automatic reboot.

Once the second reboot is complete, it is safe to disconnect the RV55 from the higher power source and return it to the original installation and power source.

Reliable Static Routing (RSR)

I launched ACEmanager with Internet Explorer 9. I configured RSR, but after I enabled RSR and clicked Apply, all the values reverted to the defaults.

There is a known issue. If you configure and enable RSR with ACEmanager in Internet Explorer 9, and then click Apply, the values in the ACEmanager screen appear as default values.

This is an ACEmanager display issue only. The configuration is applied properly, but the configured values are not displayed. Click Refresh to view the configured values.

Inbound Ports Used by ALEOS

When I configure ports for an application on a LAN client such as a router or laptop, I want to ensure that the ports I use do not conflict with the inbound ports that ALEOS uses. Which ports does ALEOS use?

Table F-1 shows the inbound ports that are set in ALEOS and cannot be configured. Table F-2 show the default setting for ports you can configure and where to change the ports in ACEmanager.

Port	Use
9494 – 9497 17335 17345 – 17353 21000 – 21003	Used internally for Location and Events Reports
500 4500	Used internally for IPSec VPN
8088	Used internally for ALMS

Table F-1: ALEOS Non-configurable Inbound Ports

Default Port	Feature	ACEmanager location
161	SNMP Port	Services > Management (SNMP)
2332	SSH/Telnet Remote Login Server Port	Services > Telnet/SSH
9191	ACEmanager Port	Services > ACEmanager
9300	SSL tunnel Port	VPN > SSL Tunnel
9443	ACEmanager SSL Port	Services > ACEmanager

Default Port	Feature	ACEmanager location
9494	Poll Port	> Global Settings
12345 Device Port used for incoming TCP/ UDP traffic		Serial > Port Configuration

Table F-2: ALEOS Configurable Inbound Ports

Setting for Band

The options available in the WAN/Cellular > Cellular > General > Setting for Band field depend on your region or your Mobile Network Operator. (To check your Mobile Network Operator, in ACEmanager, go to Status > About > Radio Module Identifier field.)

Setting for Band Option	Technology	Bands Available
All Bands	LTE	Band 1
		Band 2
		Band 3
		Band 4
		Band 5
		Band 7
		Band 8
		Band 9
		Band 12
		Band 13
		Band 14
		Band 18
		Band 19
		Band 20
		Band 26
		Band 29
		Band 32
		Band 41
		Band 42 ^a
		Band 43 ^a
		Band 46
		Band 48 ^a
		Band 66
	HSPA	Band 1
		Band 2
		Band 4
		Band 5
		Band 6
		Band 8
		Band 9
		Band 19

Table 6-3: RV55 Radio Module EM7511 North America

a. Bands 42/43/48 are disabled as of publication date; support is pending regulatory approval

Ethernet Ports

What do the LEDs above the Ethernet port mean?

There are two LEDs at the top of the Ethernet port. The green one is lit when a cable is connected to the host and the connection is running at 100baseT. The amber (activity) LED blinks when traffic is passing through the port.

LAN Networks

The server on my LAN network is receiving data from some hosts on the network, but not others. What's wrong?

If you have a network with multiple LAN devices that are sending data to the same server and the server is not receiving data from one (or more) of the devices, it may be because the Mobile Network Operator has a WAN firewall that is blocking the ports used by the NAT for over-the-air (OTA) destinations.

To correct this problem:

- 1. Launch ACEmanager.
- 2. Go to the LAN tab.
- 3. Select Ethernet.
- 4. Refer to the instructions for setting the Starting Ephemeral Port on page 95.

Wi-Fi

My is configured to act as an access point, but I don't see an option to use WEP encryption.

- 1. Launch ACEmanager.
- **2.** Go to the LAN/Wi-Fi tab.
- 3. Select Wi-Fi.
- 4. In the Enable Access Point field, change the value from "b/g/n Enabled" to "b/g Enabled".

Once this change is made, an "Open WEP" section appears below the Wi-Fi Configuration section.

WEP encryption is only supported on 802.11b and 802.11g. It is not supported on 802.11n.

VPN

My VPN connection is not working. When I try to debug it using the logs on the Admin page, VPN information does not show up in the log.

VPN information is collected in the Linux logs. To view this information:

- 1. Log into ACEmanager as User and go to Admin > Log.
- **2.** In the drop-down menu beside Linux Syslog, ensure that Display is selected. If you change the setting:
 - a. Click Apply.
 - b. Reboot the device.
- 3. Click View Log.
- 4. On the View Log page, click Clear and then click Refresh.

VPN Troubleshooting

If you see the following lines in the log, it means the VPN Server is not answering.

notice openvpn[9199]: [UNDEF] Inactivity timeout (--ping-restart), restarting notice openvpn[9199]: TCP/UDP: Closing socket

Check the VPN Server status.

When I configure a VPN, my Internet connection stops working.

When you configure a VPN, outgoing traffic from the host to the public Internet is blocked by default, as a security measure. If you want to enable public Internet traffic from the host:

- 1. In ACEmanager, go to VPN > Split Tunnel.
- 2. Change the Outgoing Host Out of Band field to Allowed.
- 3. Click Apply.

Port Forwarding

I set up port forwarding rules. I did not receive an error message, but it seems that data is not being forwarded.

If the Public Start Port and Public End Port fields are not set up correctly, data is not forwarded.

- 1. In ACEmanager, go to Security > Port Forwarding.
- If you are forwarding data to a single port:
 - Ensure that the value in the Public Start Port field is **not** 0.
 - Ensure that the value in the Public End Port field is 0.
 - Ensure that the value in the Private Port start field is **not** 0.
- If you are forwarding data to a range of ports:
 - Ensure that the value in the Public Start Port field is not 0.
 - Ensure that the value in the Public End Port field is greater than the value in Public Start Port field.
 - Ensure that the value in the Private Port Start field is not 0.

For complete instructions, see Port Forwarding on page 206.

SMS

I tried to send an SMS message, and received an error code. What does the error code mean?

The following acknowledgment error codes may appear if your message was not successfully sent:

Code	Explanation	
100	Not in coverage (no cellular service)	
201	Parse Error on field #1 (Start Field)	
202	Parse Error on field #2 (Phone number and separator)	
203	Parse Error on field #3 (Data type and separator)	
204	Parse Error on field #4 (Payload length and separator)	
205	Parse Error on field #5 (Message and End Field)	
301	301 No buffers available	
302	SMS queue full	

 Table 6-4:
 SMS error codes

Supported SMS data types are ASCII, 8-bit, and Unicode, and are all case-sensitive. SMS messages being sent MUST be in ASCII hex format.

I tried to send an SMS command and received the error "not set". The parameter was not changed.

Check the format of the SMS command. There should be no space between the prefix and the command (or the 1st command parameter in the case of multi-parameter commands), and a single space between all other fields to act as a delimiter. For more information, see SMS Commands on page 556 and SMS on page 242.

AirLink Management Service

I don't understand the message that appears in the Status field in the Services > ALMS page.

The error messages in the Services > ALMS > Status field can be due to a communication failure, a problem with the ALMS server, or a failure when parsing a valid ALMS server response. The following table describes the error messages and the corrective action.

Error message	Meaning	Corrective action
Communication Failure Errors		
[HTTP] Initialization error	The transfer object could not be initialized.	Contact ALMS support.
[HTTP] Unsupported protocol	The ALMS server URL protocol is not supported.	In ACEmanager, check the ALMS URL in the Service > ALMS > Server URL field. The default value is https://na.m2mop.net/device/msci/com.
[HTTP] Failed initialization	The transfer library could not be initialized.	Contact ALMS support.
[HTTP] URL using bad/illegal format or missing URL	The ALMS server URL is missing or not properly formatted.	In ACEmanager, check the ALMS URL in the Service > ALMS > Server URL field. The default value is https://na.m2mop.net/device/msci/com.
[HTTP] Couldn't resolve host name	The ALMS server URL could not be resolved.	In ACEmanager, check the ALMS URL in the Service > ALMS > Server URL field. The default value is https://na.m2mop.net/device/msci/com. Also check the cellular connectivity.
[HTTP] Couldn't connect to server	Connection to the ALMS server URL failed.	In ACEmanager, check the ALMS URL in the Service > ALMS > Server URL field. The default value is https://na.m2mop.net/device/msci/com. Also check the cellular connectivity.
[HTTP] Timeout was reached	The transfer timeout (equal to the communication period if defined or 5 minutes) expired.	Check cellular connectivity.
[HTTP] Server returned nothing (no headers, no data)	No data was received from the ALMS server.	Check cellular connectivity.
[HTTP] Unrecognized or bad HTTP Content or Transfer- Encoding	The ALMS server HTTP response contains a malformed content or transfer-encoding header field.	Contact ALMS support.
[HTTP] Out of memory	A memory allocation problem occurred.	Contact ALMS support.

Error message	Meaning	Corrective action
[HTTP] SSL peer certificate or SSH remote key was not OK	This message appears if you are using an HTTPS server URL, the TLS Verify Peer Certificate field is set to Enable, and the server SSL certificate validation fails. If this happens, communication with the ALMS server is terminated.	 If you see this error message: Check to see that you have a valid URL in the Server URL field. In ACEmanager, go to Admin > Advanced and check the Date and Time field to confirm that the values are correct.^a The SSL certificates have a start and end date. If the device has a date and time outside of this interval, the certification check will fail. Contact your IT Administrator, or if you want the traffic to go through without verifying the server certificate, change the setting in the Services > ALMS > TLS Verify Peer Certificate field (described on page 221) to Disable.
ALMS Server Errors		
[AVMS] HTTP error '500'	ALMS server reported error 500 in the HTTP response.	Refer to the available ALMS server documentation for a list of all possible error codes and their significance.
Error message indicating	a failure when parsing a valid AL	MS server response
XML processing error	The content of a valid ALMS server response cannot be parsed.	ALMS server responses are malformatted. Contact ALMS support.

a. If the values are not correct and the device is not receiving date and time from the Mobile Network Operator or go to Services > Time (SNTP), and enable time update. For the SNTP Server, use the same service as the authenticating server.

When I try to update the radio module using ALMS, I receive an error message.

The following table provides a brief explanation of the firmware update error messages.

Error message	Meaning	Corrective action
Cannot Install Firmware	The system has encountered errors from which it cannot recover and requires at least a reboot before trying to update again.	 Reboot the device. If the problem persists, press the reset button for 7–10 seconds to reset the device to the factory default settings (release the reset button when all four LEDs turn from red to yellow) and try again. If it still does not work, contact ALMS support.
Link not up in 3 minutesExiting	The radio module was not able to establish the connection in 3 minutes. The update has been aborted, but can be relaunched as soon as the connection is OK.	Wait for network connectivity and then try again.
Unable to download JUD file from <url></url>	The URL is wrong, or the download failed (interruption, no space left).	Contact ALMS support.

Error message	Meaning	Corrective action
Core version not found in JUD file	JUD file is not valid. Core Version is a mandatory field.	There is a problem with the package on the ALMS server. Contact ALMS support.
Required information (URL, Size or MD5) is missing from JUD file	JUD file is not valid. URL, Size, and MD5 sum of the firmware package are mandatory fields.	There is a problem with the package on the ALMS server. Contact ALMS support.
Cannot perform upgrade — No space left on device	Firmware is larger than available space for the download.	Contact ALMS support. The support team will need to access the device to clear space, or you can return the device to Sierra Wireless under an RMA.
Unable to download ALEOS firmware from <url></url>	Firmware URL is not valid, or the download failed.	Retry. If the download fails several times, contact ALMS support. The support team will need a log from the device.
Undefined ALEOS firmware URL	ALEOS firmware URL not specified, so firmware cannot be retrieved.	Contact ALMS support to confirm that there is not a problem with the service.
ALEOS firmware MD5 check failed	The downloaded firmware package failed the integrity check. The update is aborted.	There is a problem with the package on the device or the download may have failed. Restart the firmware download. If the problem persists, contact ALMS support. There may be a problem with the package on the ALMS server.
Unable to apply ALEOS firmware and Unable to apply ALEOS firmware (retry)	ALEOS firmware could not be applied. Check the ALEOS log messages to determine exactly why the update failed.	Retry. If the problem persists, contact ALMS support and provide them with the log messages.
Radio Module URL is missing from JUD file	JUD file is not valid. The Radio Module Firmware URL is a mandatory field.	There is a problem with the package on the ALMS server. Contact ALMS support.
Radio Module package MD5 sum is missing from JUD file	JUD file is not valid. The Radio Module Firmware MD5 sum is a mandatory field.	There is a problem with the package on the ALMS server. Contact ALMS support ^a .
Radio Module firmware MD5 check failed	The downloaded firmware package failed the integrity check. The update is aborted.	There is a problem with the package on the device or the download may have failed. Try downloading the file again. If the problem persists, contact ALMS support ^a . There may be a problem with the package on the ALMS server.
Radio Module backup failed	The radio module was saved to prevent a power failure. If the firmware cannot be backed-up on persistent storage, the firmware update will not proceed because of the risk that the radio module update will not be able to finish if interrupted.	Contact ALMS support ^a . The support team will need to access the device to clear space, or you can return the device to Sierra Wireless under an RMA.
Radio Module firmware download failed	Firmware URL is not valid, or download failed.	Retry several times. If the problem persists, contact ALMS support ^a . The support team will need a log from the device.

Error message	Meaning	Corrective action
Undefined Radio Module firmware URL	The URL cannot be retrieved. The update is aborted.	Retry. If the problem persists, contact ALMS support.
Radio Module firmware update failed	Radio module firmware could not be applied. Check the ALEOS log messages to determine exactly why the update failed.	Retry. If the problem persists, contact ALMS support.

Location

I set the Location Reports Port field on the Location > Local Streaming page to stream Location data to a USB port, but I don't see Location data on the USB port.

The Location streaming feature works with serial devices. To stream data to a USB port, you must first configure the USB port to act as a serial device.

- 1. In ACEmanager, go to the LAN > USB tab.
- 2. In the USB Device Mode field, select USB Serial.
- 3. Click Apply.

If you have not already done so:

- **1.** Go to Location > Local Streaming.
- In the Location Reports port field, select one of the following:
 USB Serial
 - DB9 and USB
- **3.** Click Apply.
- 4. After you have made all the configuration changes, reboot the device.

Event Reporting

I set up ACEmanager to send an email/SMS report, but when I clicked the Test report button no report was sent.

After you set up the event reporting fields and click Apply, wait about a minute before you click the Test report button. The AirLink RV55 needs this time to apply the new configuration.

I configured event reporting, but I did not receive a report when I should have.

- If the Action Type for the Event Reporting is Email or SNMP TRAP, be sure that these services are also configured on the Services tab.
 - To configure email, go to Services > Email (SMTP).
- To configure SNMP TRAP, go the Services > Management (SNMP). If the Action Type is SMS, you may need to change the default settings in the Advanced section of the Services > SMS page.

TCP Connections

I went to the TCP section of the Serial screen and configured ALEOS to include the Device ID in TCP connections, but I get the message "Device ID Not Set".

Setting the TCP connection to include the Device ID is a two step process:

 In ACEmanager, go to Serial > TCP and ensure that the Include Device ID on TCP Connect field is set to Enable.

(See Port Configuration on page 289.)

2. Go to Location > Global Settings > General and configure the Use Device ID in Location Reports field. (See Global Settings on page 281.)

To confirm that the Device ID is configured, check the Status > About screen. The Device ID, if set, appears in the /RAP Device ID field.

TCP/IP and UDP/IP Auto Answer

I configured TCP/UDP auto answer, but the packet contents are not being streamed over the serial port to the connected device.

1. Try polling the device connected to the AirLink RV55's serial port.

If you do not receive a response, confirm that the fields described in Configuring IP to Serial with Answer and Serial to IP on page 310 are set correctly.

 In ACEmanager, go to Status > Serial and check the RS232 bytes sent field to confirm that packets are reaching the AirLink RV55 from the mobile network and the packet contents are being sent out the AirLink RV55's serial port.

ant applicable to the DEED 11 5-6210	Prod.	amounted analysis provides and
		Council Opera Marcell Council
fireive.		
	1195232 23466	
Cellular	REZER Post	English
Different	R1213 Guar Part Marie	Daatteet
LAIR BYRINE Today	PS212 Reserved by External Application	Englished
	44 REZE Post Made	Normal (AT contrary)
1979	AT 183232 TEP Auto Answer	Doubled
Samarity	R8232 TCP Parasterit Convertion	Evalue
	AT BEZTE UOP Auto Arcoant	Doubled
Services:	HS232 tyles sell	
Location	RIS232 Aytes relation	1
Sama	RS212 Host signal level	OCD: HEGH DTH: LOW DOM, HEGH CT3: HEGH BT3; LOW
Applications		
Pulicy Runting		
RSA		
8.04		
P11114		
Advant		

Figure F-3: ACEmanager: Status > Serial

When you poll the AirLink RV55/connected device:

- If the Serial bytes sent counter increases, the IP packets have reached the AirLink RV55 from the mobile network, the AirLink RV55 has removed the header and sent the packet contents out its serial port to the connected device.
- If the Serial bytes sent counter does not increase, either:
 - The IP packet has not made it across the mobile network to the AirLink RV55.
 - The destination port for the TCP/IP or UDP/IP connection does not match the configured Device Port on the ACEmanager Serial tab.
- **3.** Once you have confirmed that the Serial bytes sent counter is increasing, check the Serial bytes received counter (also on the Status > Serial screen).
 - If the Serial bytes received counter is increasing, the connected device is responding to the poll request and sending its response back to the AirLink RV55 across the serial connection.
 - If the Serial bytes received counter is not increasing, the connected device is not responding to the poll request. Ensure that the serial cable is fully seated and properly connected to the AirLink RV55 and the host. Check that you have the correct type of serial cable connecting the AirLink RV55 to the connected device. The AirLink RV55 is a DCE device. If the connected device is also a DCE device, use a null modem serial cable. If the connected device is a DTE device, use a straight through serial cable.
- 4. If you have confirmed that both the Serial bytes sent and Serial bytes received counters are increasing when you send a poll to the connected device, but you are still not receiving the response back on your original sending application, the most common reason is that the incoming packets from the AirLink RV55 to your application are being blocked by a firewall on your network. The firewall may be blocking all traffic except packets destined for particular ports or arriving from particular ports.

Check with your firewall administrator. Ask the administrator to monitor the firewall when you poll the AirLink/connected device to see if any return packets from the AirLink RV55 hit the firewall.

If you are still having problems, contact your Sierra Wireless distributor.

ALEOS Application Framework (AAF)

I'm unable to load an application from AAF.

- 1. In ACEmanager, go to Services > Telnet/SSH.
- 2. In the AT Server Mode field, select Telnet.
- 3. Click Apply.
- 4. Re-try loading the application from AAF.

Network Operator Switching

What happens to my Radio Module Firmware settings (Admin > Radio Module Firmware) when I reset the RV55 to the factory default settings?

If the Reset Mode field on the Admin > Advanced screen is set to "Preserve Cellular Authentication Settings" (default setting), the Radio Module settings on the Admin > Radio Module Firmware screen are preserved over the reset, i.e. there is no change to the settings.

If the Reset Mode field on the Admin > Advanced screen is set to "Reset All", then the settings on the Admin > Radio Module Firmware screen revert are reset. The Automatic option is reset to "Automatic" and the ALMS option is reset to "Update Current Only". If you have previously selected a radio module firmware version manually that does not match the SIM card, "Reset All" may change the radio module firmware because once the RV55 reverts to "Automatic", which SIM card is installed in the RV55 determines which radio module firmware is used. This could override a previous manual selection.

->>> G:Glossary of Terms

Acronym or Term	Definition
3GPP	3 rd Generation Partnership Project 3GPP unites 6 telecommunications standard development organizations (ARIB, ATIS, CCSA, ETSI, TTA, TTC), and provides their members with a stable environment to produce Reports and Specifications that define 3GPP technologies.
API	Programming Interface A protocol intended to be used as an interface by software components to communicate with each other.
AT	A set of device commands, preceded by "AT" originally developed by Hayes, Inc. for their devices. The structure (but not the specific commands, which vary greatly from manufacturer to manufacturer) is a de facto device industry standard.
CE, CE Label	The CE label is a mandatory conformity marking for products placed on the market in the European Economic Area (EEA). With the CE marking on a product, the manufacturer declares that the product conforms with the essential requirements of the applicable EC directives.
CnS	Sierra Wireless' proprietary Control and Status protocol interface
DCE	Data Communications Equipment A device that sits between the data terminal equipment (DTE) and a data transmission circuit. Usually the DCE is a modem.
Diversity	Antenna diversity, also called space diversity, is a scheme that uses two or more antennas to improve the quality and reliability of a wireless link. Often, especially in urban and indoor environments, there is no clear line-of-sight (LOS) between transmitter and receiver. Instead the signal is reflected along multiple paths before finally being received. Each bounce can introduce phase shifts, time delays, attenuations, and distortions that can destructively interfere with one another at the aperture of the receiving antenna.
DMNR	Dynamic Mobile Network Routing
EIA	Electronics Industry Association EIA was a standards and trade organization composed as an alliance of trade associations for electronics manufacturers in the United States. They developed standards to ensure the equipment of different manufacturers was compatible and interchangeable. The EIA ceased operations on February 11, 2011, but the former sectors continue to serve the constituencies of EIA.
EMC	Electromagnetic Compatibility The branch of electrical science which studies the unintentional generation, propagation and reception of electromagnetic energy with reference to the unwanted effects (Electromagnetic interference, or EMI) that such energy may induce.
EMI	Electromagnetic Interference The disturbance that affects an electrical circuit due to either electromagnetic induction or electromagnetic radiation emitted from an external source
ERP	Effective Radiated Power A standardized theoretical measurement of radio frequency (RF) energy. It is determined by subtracting system losses and adding system gains.

Acronym or Term	Definition
ESN	Electronic Serial Number The unique first-generation serial number assigned to the Air Link devices for use on the
	wireless network. Compare to MEID.
Ethernet	Computer networking technologies for local area networks (LANs).
EU	The European Union Organization of European countries.
FCC	Federal Communications Commission The U.S. federal agency responsible for interstate and foreign communications. The FCC regulates commercial and private radio spectrum management, sets rates for communications services, determines standards for equipment, and controls broadcast licensing.
FW	Firmware Software stored in ROM or EEPROM; essential programs that remains even when the system is turned off. Firmware is easier to change than hardware but more permanent than software stored on disk.
GPRS	General Packet Radio Service A packet-oriented mobile data service on 2G and 3G cellular communication systems. GPRS was originally standardized by European Telecommunications Standards Institute (ETSI) in response to the earlier CDPD and i-mode packet-switched cellular technologies. It is now maintained by the 3rd Generation Partnership Project (3GPP).
GPS	Global Positioning System A system that uses a series of 24 satellites to provide navigational data.
GSM	Global System for Mobile Communications (originally Groupe Spécial Mobile) GSM is a standard developed by the European Telecommunications Standards Institute (ETSI) to describe protocols for second generation (2G) digital mobile networks used by mobile phones
HSPA	High Speed Packet Access An amalgamation of two mobile telephony protocols: High Speed Downlink Packet Access (HSDPA) and High Speed Uplink Packet Access (HSUPA). This extends and improves the performance of existing 3rd generation mobile telecommunication networks utilizing the WCDMA protocols.
HSPA+	Also called evolved HSPA This allows bit-rates to reach as high as 168 Mbit/s in the downlink and 22 Mbit/s in the uplink. An improved 3GPP standard.
IC	Industry Canada The government department responsible for overseeing and regulating wireless and communication technologies in Canada.
IEC	International Electrotechnical Commission A non-governmental international standards organization that prepares and publishes International Standards for all electrical, electronic and related technologies—collectively known as "electro technology."
IS	Interim Standard After receiving industry consensus, the TIA/EIA forwards the standard to ANSI for approval.
ISAKMP	Internet Security Association and Key Management Protocol A security protocol defined by RFC 2408 for establishing Security Associations (SA) and cryptographic keys in an Internet environment. ISAKMP only provides a framework for authentication and key exchange and is designed to be key exchange independent.

Acronym or Term	Definition
ITU	International Telecommunication Union A specialized agency of the United Nations responsible for issues that concern information and communication technologies. The ITU coordinates the shared global use of the radio spectrum, promotes international cooperation in assigning satellite orbits, and assists in the development and coordination of worldwide technical standards.
kbps	Kilobits per second 1000, not 1024, as used in computer memory size measurements of kilobytes.
LED	Light Emitting Diode A semiconductor diode that emits visible or infrared light.
LTE	Long Term Evolution High performance air interface for cellular mobile communication systems.
Mbps	Millions of bits per second, or Megabits per second.
MEID	Mobile Equipment IDentifier The unique second-generation serial number assigned to the device for use on the wireless network. <i>Compare to</i> ESN.
MSCI	Modem Status Configuration Interface ALEOS internal configuration database
NAM	Number Assignment Module Semi-permanent information stored in the device's non-volatile memory, including the device's Mobile Identification Number, the station class mark, Mobile Network Operator code, and other cellular identifiers. Essentially the phone number, it should be treated as confidential information and should not be disclosed to anyone other than the cellular service provider.
NV	Non-Volatile (memory)
OEM	Original Equipment Manufacturer A company that manufactures a product and sells it to a reseller.
ΟΤΑΡΑ	Over the Air Parameter Administration A way of distributing new software updates or configuration settings to devices like cellphones and set-top boxes.
OTASP	Over the Air Service Provisioning. Also see OTAPA.
PAD	Packet Assembly/Disassembly
PCS	Personal Communications Services A cellular communication infrastructure that uses a different frequency range than AMPS.
PPP	Point to Point Protocol An alternative communications protocol used between computers, or between computers and routers on the Internet. PPP is an enhanced SLIP. Also see SLIP.
PRI	Product Release Instructions A file containing the settings used to configure devices for a particular service provider, customer, or purpose.
RF	Radio Frequency

ALEOS 4.14.0 Software Configuration User Guide for AirLink RV55

Acronym or Term	Definition
RoHS	Restriction of use of Hazardous Substances mandated by EU Directive 2002/95.
RS-232	A series of standards for serial binary single-ended data and control signals connecting between a DTE (Data Terminal Equipment) and a DCE (Data Circuit-terminating Equipment). It is commonly used in computer serial ports.
Rx	Receive
SIM, SIM Card	Subscriber identity module or subscriber identification module. An integrated circuit which securely stores the international mobile subscriber identity (IMSI) and the related key used to identify and authenticate subscribers on mobile telephony devices (such as mobile phones and computers).
SINR	Signal to Interference plus Noise Ratio (SINR) is an RF parameter that is directly proportional to throughput (the higher the number, the higher the throughput). It can help LTE radio installers gauge the signal quality between the cell tower and the radio module. For more information on interpreting the SINR values, see How do I obtain and interpret SINR values for LTE networks? on page 563.
SKU	Stock Keeping Unit Identifies an inventory item: a unique code, consisting of numbers or letters and numbers, assigned to a product by a retailer for purposes of identification and inventory control.
SLIP	Serial Line Internet (or Interface) Protocol An Internet Protocol designed to work over serial ports and modem connections. On personal computers, SLIP has been largely replaced by the Point-to-Point Protocol (PPP), which has more features and does not require its IP address configuration to be set before it is established. On microcontrollers SLIP is still the preferred way of encapsulating IP packets due to its very small overhead. Also see PPP.
SMS	Short Message Service A feature which allows users of a wireless device on a wireless network to receive or transmit short electronic alphanumeric messages (up to 160 characters, depending on the service provider).
тсн	Traffic Channel
TIA/EIA	Telecommunications Industry Association / Electronics Industry Association A standards setting trade organization, whose members provide communications and information technology products, systems, distribution services and professional services in the United States and around the world.
Тх	Transmit
UMTS	Universal Mobile Telecommunications System (UMTS). A third generation mobile cellular system for networks based on the GSM standard. Developed and maintained by the 3GPP (3rd Generation Partnership Project), UMTS is a component of the International Telecommunications Union IMT-2000 standard set.
USB	Universal Serial Bus An industry standard defining the cables, connectors and communications protocols used in a bus for connection, communication and power supply between computers and electronic devices.

Acronym or Term	Definition
VRRP	Virtual Router Redundancy Protocol
X.509	A Public Key Infrastructure (PKI) and Privilege Management Infrastructure (PMI) are standards that specify formats for public key certificates, certificate revocation lists, attribute certificates, a certification path validation algorithm, etc.

Index

A

Access points, maximum number configurable, 137 ACEmanager, 224 Configuring, 19 Description, 14 Idle timeout, set, 225 Login, 16 Overview, 14 Active SIM, 84 Admin Advanced, 371 Change AAF password, 370 Change ALEOS password, 369 Logs, 387 Radio Module Firmware, 393 Radio passthru, 386 AirLink Management Service See ALMS. **ALEOS Application Framework** Troubleshooting, 577 Unable to load application from, 577 Using, 358 ALEOS software update, 25 ALMS Auto synchronize, 221 Configuration, 218 Error messages, 573 Always on connect, 94, 253 Analog inputs Channel configuration, 470 Transformed values, 367 Uses. 361 APN SIM 1, 99 Applications, 347 ALEOS Application Framework, 358 Data usage, 347 Garmin, 355 Status, 68 AT Commands Applications > Data Usage, 548, 552 I/O > Current State, 547 LAN/Wi-Fi > DHCP/Addressing, 497 Location, 525 Security > Trusted IPs - Inbound, 508, 514 Serial > Port Configuration, 532 Services > Low Power, 515 Status > Home, 468, 470, 540 summary, 466 Using, 466 Wi-Fi, 499 Authentication General information, 272 LDAP, 272 RADIUS, 275 TACACS+, 276 Auto DHCP, 154 Automatic SIM Switching, 86

В

Bandwidth Throttle, 78 Browser support, 16

С

Configuration Application, 347 LAN, 144 Logging, 387 saving a custom configuration, 20 Serial, 324 Services, 218 VPN, 178 Configuring the AirLink gateway, 19 Connection not working, 562 Core dump, 372 Custom SSL certificate, 225

D

Data usage, 347 Dead Peer Detection, 188, 194, 510 Device status (about), 72 Device Status Screen, configuring, 278 DHCP Options, 148, 151 DHCP/Addressing, 144 Dial-up Networking, 398 **Digital inputs** RV50, 361 Uses, 361 DMNR, 115 DMZ, 211 DNS Alternate port, 164 Dynamic, 235 Global, 163 Override, 164 DNS proxy Configure, 164 Documentation, 14 Domain name, 240 Dual SIM, 84 DUN Operating systems supported, 398 Setting up, 398 Dynamic Mobile Network Routing See DMNR

Ε

EC/IO, 43 Email (SMTP), 263 Email test, 260 Engine hours, 233, 321 Ethernet Static IP, 105 Ethernet ports, 153 Troubleshooting, 568 Events Reporting Data groups, 316 Email, 306 Event types, 319 Introduction, 304 Location Reports, 312 Protocol Reports, 313 Relay Link, 310 SMS, 308 SNMP TRAP, 311 Turn Off Services, 315 Extended Archiver, 377

F

Firmware update, 25

G

Garmin, 355 Global DNS, 163 Glossary, 579 GPS *See* Location GRE, 199

Η

Host Interface Watchdog, 176 Host port routing, 33, 160

I

I/O Configuration, 361 Current state, 362
Idle timeout, ACEmanager, 225
Inbound ports used by ALEOS, 566
Interface Priority, 76
IP Logging, 374
IP Manager, 238
IPsec, 183, 184, 190
IPv6 Configuring support for, 90 Support, 97

L

LAN Configuration, 144 Ethernet, 153 Management, 33 Status, 56 LDAP authentication, 272 LED indicator for serial traffic, 324 LEDs, above Ethernet port, 568 Load Root Certificate, 204 Location, 575 Global settings, 281 Local IP report, 300, 303 Status, 64 Streaming, 575 Troubleshooting, 575 Logging Configuration, 387 Extended Archiver, 377 IP logging, 374 Low Voltage Standby mode, 228 LWM2M, 219

Μ

MAC filtering, 217, 562 MIB (Management Information Base), 421 Modbus Address list, 341 Details, 417 TCP/IP, 418 Monitor Cellular connection, 103 Ethernet connection, 106 WAN connections (overview), 74 Wi-Fi, 127

Ν

Network connection, poor, 562 Network credentials, 99 Network Operator Switching, 396 Network settings, retain over reset, 380 Network State, 37 NMEA, 279

0

Over the Air (OTA) connections, 34

Ρ

Password Change AAF user password, 370 Change ACEmanager password, 369 PCI compliance, 34 Ping Response, 81 Ping, on demand, 373 PNTM configuration, 121 Policy Routing, 112 Port filtering Inbound, 212 Outbound, 213 Port forwarding, 206 Error message, 571 Troubleshooting, 571 Power management, 227 PPP connection, configuring, 337 PPPoE, 165 Primary SIM, 85 Programmable Logic Controller, 418 Pulse count, 365

R

Radio band, selecting, 565 Radio module firmware Install, update, remove, 393 Select manually, 397 Radio module firmware update, 25 Radio passthru, 386 RADIUS authentication, 275 RAP, 279 Recovery mode, 18 Redundant server, 296 Relay outputs, 362 Reliable Static Routing (RSR), 108 Remote Terminal Unit, 417 Reset device, retain network settings, 380 Reset, periodic and time of day, 378 Reverse telnet/SSH, 333 RSCP, 44 RSRP, 45 RSRQ, 45 RSSI, 43

S

Security Configuration, 206 DMZ, 211 MAC filtering, 217 Port filtering, inbound, 212 Port filtering, outbound, 213 Port forwarding, 206 Solicited vs. Unsolicited, 206 Status, 61 Trusted IPs, inbound, 215 Trusted IPs, outbound, 216 Serial Configuration, 324 LED indicator, 346 Modbus address list, 341 MTU, 329 PPP. 337 Status, 66 Serial port Disable, 325 Port configuration, 325 TCP, 329 UDP, 331

Services ACEmanager, 224 ALMS, 218 Authentication, 272 Configuration, 218 Device Status Screen, 278 Dynamic DNS, 235 Email (SMTP), 263 IP Manager, 238 Management (SNMP), 265 Power Management, 227 SMS. 242 Status, 62 Telnet/SSH, 261 Time (SNTP), 271 Shutdown Delay after Ignition off, 227 SIM PIN, 100 SIM PIN, unblocking, 102 SIM switching, automatic, 86 SIM, active, 84 SIM, Primary, 85 Simple Network Management Protocol (SNMP), 265 SINR, 563 SLIP, 338 SMS, 242 Advanced, 258 Commands, 556 Control Only mode, 245 Error message, 572 Gateway Only mode, 246 M2M. 260 Message error, 571 Password, 256 Password Only mode, 244 Password, default, 258 Quick Test, 259 Security, 254 Test, 260 Troubleshooting, 571 Trusted phone number, 256 Wakeup, 253 SNMP traps, 421 SNTP, 271 SSH, 261 SSL tunnel, 201 Standby Mode, 229 Status About, 72 Applications, 68 Cellular, 39 Ethernet, 50 GPS, 64 Home, 36 Location. 64 PNTM, 71 Policy Routing, 69 **RSR**, 70 RSR (Reliable Static Routing), 70 Security, 61 Serial. 66 Services, 62 VPN, 58 Wi-Fi, 53

Т

TACACS+ authentication, 276 TAIP, 279 TCP connection Device ID Not Set, 576 Troubleshooting, 573 Telemetry, 417 Telnet, 261 Template Applying, 22 Saving a custom configuration as, 20 Test button, SMS/email, 260 Third party services, 236 Time (SNTP), 271 Troubleshooting ALEOS AF, 577 ALMS error messages, 573 AVMS status messages, 572 Ethernet ports, 568 GPS, 575 LAN network, 569 Location, 575 Port forwarding, 571 Radio module firmware update, 560 RSR, 566 SMS, 571 Software and radio firmware updates, 560 TCP connections, 576 VPN, 570 Wi-Fi, 570 Wireless connection, 562 Trusted IPs Inbound, 215 Outbound, 216 Trusted Phone Number, 256

U

UDP Multiple Unicast, 333 Update ALEOS software, 25 Radio module firmware, 25 USB Disable, 157 Drivers, installing, 157 Port, 156

V

VLAN, 170 VPN Configuration, 178 Failover, 181 GRE, 199 IPsec, 184 OpenVPN tunnel, 201 Status, 58 Troubleshooting, 570 VRRP, 171

W

WAN connections, monitor, 74 WEP, 135 WEP encryption, troubleshooting, 570 Wi-Fi Access Point Mode, 128 Captive portal, 132 Client Mode, 137 Country Code, 126 General, 124 Modes, 124 Troubleshooting, 570 WPA / WPA2 Personal, 136 WPA2 Enterprise, 137