



tinyAVR 1-series Training

Getting Started with the tinyAVR® 1-series

Prerequisites

- **Hardware Prerequisites**
 - Microchip ATtiny817 Xplained Pro board
 - Micro-USB cable (Type-A/Micro-B)
 - One female-to-female wire
 - Internet connection
- **Software Prerequisites**
 - Atmel Studio 7.0
 - Atmel Studio ATtiny_DFP version 1.2.112 or above
 - A list of supported browsers can be found here: <http://start.atmel.com/static/help/> → Requirements and Compatibility → Supported Web Browsers.
- **Estimated Completion Time: 120 minutes**

Introduction

This hands-on training will demonstrate how to develop AVR® applications in Atmel Studio and Atmel START along with the rich user interface and other great development tools that they provide.

Atmel START helps to get started with Microchip microcontroller development. It allows you to select MCU, configure software components, drivers, middleware, and example projects to the embedded application in a usable and optimized manner. Once the configuration is complete, the project can be generated in Atmel Studio or another third-party development tool. An IDE is used to develop the code required to extend the functionality of the project into the final product, as well as compile, program, and debug the downloaded code.

With Atmel START:


- Get help selecting the MCU based on both software and hardware requirements
- Find and develop examples
- Configure drivers, middleware, and example projects
- Get help with setting up a valid PINMUX layout
- Configure system clock settings

The ATtiny817 Xplained Pro evaluation kit is a hardware platform for evaluating the ATtiny817 microcontroller. A fully integrated embedded debugger is included in the kit, which provides seamless integration with Atmel Studio. Easy access to the features of the ATtiny817 is enabled by the kit, facilitating easy integration of the device in a customer design.

This training module demonstrates how to configure the application in Atmel START, reconfigure the Atmel START project, and continue the implementation in Atmel Studio 7.

The peripherals used to create applications are GPIO, timers TCA and TCB, Event System, USART, CCL (Configurable Custom Logic), and PIT (Periodic Interrupt Interval).

Figure 1. ATtiny817 Xplained Pro



The following topics are covered:

- Driver Configuration in Atmel START
- PINMUX driver configuration and check LED toggle on button press
- Generate a PWM by using timer counter A (TCA) and implement Variable-Pulse-Width by using the RTC interrupt
- Duty cycle and frequency measurement using input capture mode of TCB
- USART configuration
- Use the Data Visualizer tool to send data to the serial terminal
- CCL (Configurable Custom Logic): A programmable logic peripheral, which can be connected to the device pins, events, or peripherals, which allows the user to eliminate external logic gates for simple glue logic functions. Here, configure CCL to generate the specific signal using the event from GPIO and two PWM signals.

Note: Solution projects for this training can be found in Atmel START → BROWSE EXAMPLES: 'Getting Started with the tinyAVR® 1-series'

Table of Contents

Prerequisites.....	1
Introduction.....	1
1. Relevant Devices.....	5
1.1. tinyAVR 1-Series.....	5
2. Icon Key Identifiers.....	6
3. Assignment 1: LED TOGGLE Application.....	7
3.1. Atmel START Project Creation	7
3.2. Atmel START Project Overview.....	11
3.3. Code Development	13
3.4. Debug Application.....	14
4. Assignment 2: Generate PWM, Measure Duty Cycle and Frequency.....	19
4.1. TCA Driver.....	19
4.2. RTC Driver.....	25
4.3. TCB Driver.....	27
4.4. Event System Driver.....	29
4.5. USART Driver.....	31
4.6. Generate Project, Code Development.....	32
5. Assignment 3: Basis of a Binary Frequency-Shift Keying Scheme.....	41
5.1. CCL Driver.....	42
5.2. Event System Driver.....	44
5.3. PIT Driver.....	46
5.4. Generate Project, Run Code.....	46
6. Conclusion.....	49
7. Get Source Code from Atmel START.....	50
8. Revision History.....	51
The Microchip Web Site.....	52
Customer Change Notification Service.....	52
Customer Support.....	52
Microchip Devices Code Protection Feature.....	52
Legal Notice.....	53
Trademarks.....	53

Quality Management System Certified by DNV.....54

Worldwide Sales and Service.....55

1. Relevant Devices


This chapter lists the relevant devices for this document.

1.1 tinyAVR 1-Series

The figure below shows the tinyAVR 1-series devices, illustrating pin count variants and memory sizes.

- Vertical migration upwards is possible without code modification, as these devices are pin compatible and provide the same or more features. Downward migration may require code modification due to fewer available instances of some peripherals.
- Horizontal migration to the left reduces the pin count and therefore the available features.

Figure 1-1. tinyAVR® 1-Series Device Overview



Devices with different Flash memory size typically also have different SRAM and EEPROM.

2. Icon Key Identifiers

The following icons are used in this document to identify the different assignment sections and to reduce the complexity.



Info: Delivers contextual information about a specific topic.



Tip: Highlights useful tips and techniques.



To do: Highlights objectives to be completed.



Result: Highlights the expected result of an assignment step.



Indicates important information.



Execute: Highlights actions to be executed out of the target when necessary.

3. Assignment 1: LED TOGGLE Application

An application will be developed that controls the LED using the push-button on the board. The LED will be OFF on pressing the button, default state is LED ON.

A project will be configured in Atmel START using PINMUX driver configuration and clock configuration, followed by generation of the corresponding Atmel Studio 7 project.

The code will be developed in Atmel Studio 7 using PINMUX driver functions generated by Atmel START configuration.

On the ATtiny817 Xplained Pro board, LED0 is connected to pin PB4, and the push-button (SW0) is connected to pin PB5.

For application:

- Peripherals used: GPIO (PB4, PB5).
- Clock: 3.33 MHz.

3.1 Atmel START Project Creation


Configure the PINMUX driver and CLOCK in Atmel START and create the project.



To do: Create a new Atmel START Project.

1. Open **Atmel Studio**.
2. Select **File** → **New** → **Atmel Start Project**.
3. The **CREATE NEW PROJECT** window appears within Atmel Studio 7. In the "Filter on device..." text box, enter **817X**, then select ATtiny817 Xplained Pro from the list and verify that **ATtiny817 Xplained Pro** is highlighted, then click on **CREATE NEW PROJECT**, as shown below.


Figure 3-1. CREATE NEW PROJECT



Info: Now the **MY SOFTWARE COMPONENTS** window appears.

4. In **MY SOFTWARE COMPONENTS** window:
 - 1. Click on **MY PROJECT**.
 - 2. Select **Rename Component**.

Figure 3-2. Rename Component



Info: Now the **RENAME COMPONENT** window will be displayed.

5. In the **RENAME COMPONENT** window specify the new project name as "Assignment_ATtiny817" and select **Rename**.



6. Now, for PINMUX configuration, click on , the navigation tab on the left side of the window.



Info: The PINMUX configurator displays an illustration of the device package selected. It shows which pins are currently used by different peripherals. The GPIO pins can be configured here.



Info: Here PB4 is configured as LED0 and PB5 as SW0. Configuration is shown with four steps (the red markings numbered 1, 2, 3, and 4 in the figure below).


7. **Configuration of PB4:**
 - 1. Click on **PB4**.
 - 2. Enter "User label:" as **LED0**.

tinyAVR 1-series Training

Assignment 1: LED TOGGLE Application

- 3. Enter "Pin mode:" as **Digital output**.
- 4. Select "Initial level:" as **Low**.


Figure 3-3. PINMUX Configuration LED0



8. Configuration of PB5:

- 1. Click on **PB5**.
- 2. Enter "User label:" as **SW0**.
- 3. Enter "Pin mode:" as **Digital input**.
- 4. Select "Initial level:" as **Pull-up**.

Figure 3-4. PINMUX Configuration SW0



Info: Technical documents related to the ATtiny817 Xplained Pro can be downloaded from within Atmel Studio, from the page **ATtiny817 Xplained Pro** → **Technical Documentation**. The **ATtiny817 Xplained Pro** page is displayed once the ATtiny817 Xplained Pro board is connected to the computer.

tinyAVR 1-series Training

Assignment 1: LED TOGGLE Application



9. **CLOCK CONFIGURATOR:** Now, for clock configuration, click on , the navigation tab on the left side of the window.




Info: Now the **CLOCK CONFIGURATOR** window will be displayed. It consists of oscillators and clock sources of different types. The required clock source can be selected and the calculated output frequency will be displayed.

- The **OSCILLATORS** section displays the oscillators available for the selected device. The oscillator parameters can be configured by selecting "Settings Dialog" (cog wheel icon).
 - The **SOURCES** section is used to configure the clock frequency by selecting input signal and changing the multiplier.
10. Click on the "Settings Dialog" (cog wheel icon) to view the default **Main clock** settings from **SOURCES**, as shown in the figure below.



Info: The **CLOCK SETTING** window will be displayed.


Figure 3-5. CLOCK SETTING



Info: For this application the default clock settings are kept as they are. Here, the Main Clock source is 20 MHz OSC, the prescaler is divided by 6. The resulting CPU clock frequency is 3.33 MHz. The click on the "question mark" next to each configuration: , will be directed to the data sheet description of individual bit settings.

11. Click **Close** in the **CLOCK SETTING** window.
12. Now, click on the **GENERATE PROJECT** button .
13. Select the desired path where the project should be stored, as shown in the figure below, and then click OK.

Figure 3-6. Project Importer Window



The screenshot shows the 'Atmel Start Importer' window titled 'New Atmel Start Project'. It contains the following fields and controls:

- Project Name:** A text box containing 'Assignment_ATtiny817'.
- Location:** A text box containing 'C:\workspace\MicrochipMASTERS\Hands_on_ATtiny817'. This field and its 'Browse' button are circled in red.
- Solution:** A dropdown menu with 'Create New Solution' selected.
- Solution Name:** A text box containing 'Assignment_ATtiny817'.
- Buttons:** At the bottom right, there are 'OK' and 'Cancel' buttons. The 'OK' button is circled in red.
- Link:** A link labeled 'View Project Summary' is located below the Solution Name field.



Result: An Atmel START project has been created.

3.2 Atmel START Project Overview


The project configured in Atmel START generates peripheral driver functions and files, as well as a `main()` function that initializes all the drivers.

About folders and files generated by Atmel START:

- The **Config** folder contains clock configuration. `F_CPU` is defined in `clock_config.h`.
- The driver header and source files are to be found in the **src** and **include** folders
- The **atmel_start_pins.h** file in the **include** folder contains the PINMUX driver functions
- The **utils** folder contains files that define some functions to be commonly used by the drivers and application
- In the **atmel_start.c** file, the function `atmel_start_init()` initializes the MCU, the drivers, and the middleware in the project
- The **driver_isr.c** file contains ISR if the interrupts are enabled in the configuration of the project

tinyAVR 1-series Training

Assignment 1: LED TOGGLE Application



To do: Get an overview of the Atmel START project.

1. In the **Assignment_ATtiny817** project, double-click the main.c file from the **Solution Explorer** window.
2. Select the `atmel_start_init` function, then **RIGHT CLICK** → **Goto Implementation**. Repeat the procedure for the `system_init()` function to direct to the function definition.



Info: The `mcu_init()` function enables the internal pull-up resistor on all pins to reduce the power consumption. All driver initialization functions are called from the `system_init()` function. Also, the LED0 and SW0 port pins are configured to output and input mode with initial pin status.

3. Go to the implementation of `CLKCTRL_init()` and observe that the default clock settings are commented out.



Tip: `driver_init.c` → `system_init()` → `CLKCTRL_init()`


tinyAVR 1-series Training

Assignment 1: LED TOGGLE Application



Info: If the non-default clock settings are selected in Atmel START, it will be reflected in `CLKCTRL_init()`.

4. Open `atmel_start_pins.h` and click on the down arrow as shown in the figure below to open the list of functions defined in this file. Observe that many useful GPIO functions have been generated.



Result: The Atmel START project overview is completed.

3.3 Code Development

On the ATtiny817 Xplained Pro board, the behavior of the pins associated with LED0 and SW0 is as follows:

Table 3-1. Behavior of the Pins Associated with LED0 and SW0

SW0/LED0	Status	Pin Level
SW0	Button depressed	PB5: LOW
SW0	Button released (default status)	PB5: HIGH
LED0	ON	PB4: LOW
LED0	OFF	PB4: HIGH



To do: Write a code that turns the LED OFF when the button is depressed and turns it back to ON when it is released.

1. Open the `main.c` file in the **Assignment_ATtiny817** project.
2. Insert the code in `while(1)` to read the SW0 status and to configure LED0 status as mentioned below.
 - When the button (SW0) is depressed, LED0 is OFF, (LED0 pin level = high)

tinyAVR 1-series Training

Assignment 1: LED TOGGLE Application

- When the button (SW0) is released, LED0 is ON, (LED0 pin level = low)

```
if(!SW0_get_level())           // (SW0)button pressed. PB5 is low
{
    LED0_set_level(true);       //LED0 is turned OFF : PB4 is high
    while(!SW0_get_level());    //wait till (SW0)button release.
    LED0_set_level(false);      // (SW0)button released. LED0 is turned ON: PB4 is low
}
```



Info: The `SW0_get_level()` function returns the SW0 pin status. The `LED0_set_level(true)` function sets the LED0 level high.

3. After the code completion, press F7 to build the solution. The build should finish successfully with no errors.



Result: The code should look like the image shown below.

Figure 3-7. Assignment 1 Code

```
#include <atmel_start.h>

int main(void)
{
    /* Initializes MCU, drivers and middleware */
    atmel_start_init();

    /* Replace with your application code */
    while (1)
    {
        if(!SW0_get_level())    // (SW0)button pressed. PB5 is low
        {
            LED0_set_level(true); //LED0 is turned OFF : PB4 is high
            while(!SW0_get_level()); //wait till (SW0)button release.
            LED0_set_level(false); // (SW0)button released. LED0 is turned ON : PB4 is low
        }
    }
}
```

3.4 Debug Application




To do: Debug the application 'Assignment1: LED Toggle'.

1. Power the ATtiny817 Xplained Pro board by connecting it with Micro-USB cable to the computer.
2. Select **Debug** → **Start Debugging and Break** (or Alt + F5). Follow the prompts to select the ATtiny817 Xplained Pro EDBG as programmer/debugger, and press Alt + F5 again.

tinyAVR 1-series Training


Assignment 1: LED TOGGLE Application

Figure 3-8. Debug Menu



Info: If the firmware version of the on-board debugger is older than the one in the Atmel Studio installation, it will be asked to upgrade the firmware.

Figure 3-9. Firmware Upgrade




Select **Upgrade**. When the progress bar is complete, select **Close**. Now, start the debugging by selecting **Debug** → **Start Debugging and Break**. (Alternative: Alt+F5).



Result: The debugger is started and breaks in `main()`. Debugging can now be started.

- Click on the margin to insert the breakpoint as shown in the figure below.

Figure 3-10. Breakpoint Inserted



- Run to breakpoint by clicking **Debug** → **Continue**.

tinyAVR 1-series Training

Assignment 1: LED TOGGLE Application




Tip: The play button, , located on the toolbar close to the top of the Atmel Studio 7 window can be used to start or continue debugging. Keyboard shortcut F5 can also be used.

5. Press the push button SW0 and observe that execution stops at the breakpoint.
6. To check the status of all the PORTB pins, open the I/O view window by selecting **Debug** → **Windows** → **I/O** and click on the PORTB register group as shown in the image below.



Info: In the I/O view, the status of all the peripherals can be observed. Pin status is indicated for PB0 to PB7 from right to left under the **Bits** column in the **OUT** register. As shown in the image below, the level of pin PB4 (LED0) is high, as a filled square corresponds to bit status 1. An empty square corresponds to bit status 0.

Figure 3-11. I/O View



tinyAVR 1-series Training

Assignment 1: LED TOGGLE Application

7. Do single step debugging by pressing F10 and observe the status of PB4.



Info: PB7 is the left most bit and PB0 is the right most bit.

8. Remove a breakpoint by clicking on it and run the code by clicking **Debug** → **Continue** or select .
9. Stop debugging by selecting .
10. Press the push-button SW0 and observe the LED0 toggle.



Info: The application is programmed successfully to the ATtiny817 Xplained Pro board.

4. Assignment 2: Generate PWM, Measure Duty Cycle and Frequency

The ATtiny817 has two 16-bit Timer/Counter instances, TCA and TCB, and one 12-bit Timer/Counter, TCD.

Here, an application will be developed to generate the PWM using the TCA. The RTC interrupt will be used to vary the duty cycle of the PWM.

The TCA waveform output will be used as input to the TCB through the Event System, and the input capture mode of the TCB will be used to measure the duty cycle and the frequency of the waveform. The measured data will be sent to the terminal through the USART.

Single-Slope PWM Generation mode will be used for TCA. Here, the period is controlled by the PER register, while the values of the CMPn compare register controls the duty cycle of the waveform generated (WG) output, the WOn. The counter value is compared to the CMPx registers and the PER register to set the waveform period or pulse width.

The Atmel START project from **Assignment1: LED TOGGLE (Assignment_ATtiny817)** will be reconfigured to add drivers for TCA, TCB, Event System, RTC, and USART.

For the application the peripherals used are:

- TCA (waveform output WO0 on PB0)
- TCB
- Event System (event input from pin PA5)
- RTC
- USART

Clock:

- 3.33 MHz main clock
- 1 kHz RTC clock

4.1 TCA Driver




To do: Add TCA driver to generate PWM signal.

1. Open the "Assignment1:LED TOGGLE" project **Assignment_ATtiny817**.
2. In the **Solution Explorer** window, click on the project name **Assignment_ATtiny817** and then **Right Click** → **Re-Configure Atmel Start Project** as shown below.


tinyAVR 1-series Training

Assignment 2: Generate PWM, Measure Duty Cycle...

Figure 4-1. Re-Configure Menu




Info: "Atmel | START" window will appear.

3. Click the  box and then expand **Drivers** from the **ADD SOFTWARE COMPONENTS** window.
4. Search for the **Timer** driver, select it and then click the **Add Component(s)**, as shown in the figure below.

tinyAVR 1-series Training

Assignment 2: Generate PWM, Measure Duty Cycle...


Figure 4-2. ADD SOFTWARE COMPONENT



Info: The **Timer_0** driver will be added to the project.

5. Click the **TIMER_0** and then click on **Rename component**, as shown in the figure below.

Figure 4-3. Rename TCA



6. Specify the new name as **TCA_PWM** and click **Rename**.



Info: Now the TCA peripheral configuration needs to be done to generate the PWM signal. This is shown below.



To do: Configure the TCA driver to generate PWM (W0) on pin PB0, frequency: 32 kHz, initial duty cycle: 10.



Info: The configuration is shown with red markings numbered 1 to 8 in [Figure 4-4](#).

1. Select "Driver" as "TCA:Init" and mode as "TCA Normal Mode".



Info: Here, by default "Driver" is selected as "TCA:init" and mode is selected as "Normal mode". This timer has two modes; "Normal mode" (one 16-bit timer/counter) and "Split Mode". In the "Split Mode" the 16-bit timer/counter acts as two separate 8-bit timers, each with three compare channels for PWM generation.

2. Select waveform output WO/0 on pin PB0.

tinyAVR 1-series Training

Assignment 2: Generate PWM, Measure Duty Cycle...



tip: To verify the WO/0 output pin of the TCA, refer the data sheet section "I/O Multiplexing and Considerations". Click on the "question mark" next to any configuration, , and go to section "I/O Multiplexing and Considerations" to check the TCA WO/0 pin.

3. Enable the peripheral by selecting the check-mark of "ENABLE: Module Enable".
 4. Select clock frequency for the timer/counter as "System Clock".
-



Info: Here, by default it has been selected as "System Clock" (with no prescaler).

5. Enter the "PER: Period" register value as 100 (or 0x64).
-



Info: It contains 16-bit TOP value in the timer/counter. It decides the PWM frequency.

6. Select the check-mark CMP0EN to get the PORT output settings for WO0 output.
 7. Enter "CMP0: Compare Register 0" value as 10 (or 0xa).
-



Info: This register is continuously compared to the counter value of the timer. Normally, the outputs from the comparators are then used for generating waveforms. This register decides the duty cycle of PWM. Initial duty cycle has been selected as 10 (0xa). Waveform output WO/0 is required so Compare Channel 0 is configured here.

8. Select "WGMMODE: waveform generation mode" as "Single Slope PWM".
-



Info: The waveform generation mode controls the counting sequence of the counter, TOP value, UPDATE condition, interrupt condition, and type of waveform that is generated. In this Single Slope PWM mode, the period is controlled by TCA.PER, while the values of TCA.CMPn control the duty cycle of the WG output. The single-slope PWM frequency ($f_{\text{PWM_SS}}$) depends on the period setting (TCA.PER), the system's peripheral clock frequency $f_{\text{CLK_PER}}$ and the TCA clock prescaler (CLKSEL :clock selection). It is calculated by the following equation: $f_{\text{PWM_SS}} = \frac{f_{\text{CLK_PER}}}{N \cdot (\text{PER} + 1)}$. Here $N = 1$, $\text{PER} = 100$, and $(f_{\text{PWM_SS}}) = 3.3 \text{ MHz}$.

tinyAVR 1-series Training

Assignment 2: Generate PWM, Measure Duty Cycle...

Figure 4-4. TCA Configuration

The screenshot shows the 'TCA_PWM' configuration window in 'TCA Normal Mode'. The interface is divided into several sections: GENERAL, COMPONENT SETTINGS, SIGNALS, CONFIGURATION, INTERRUPT CONFIGURATION, EVENT CONFIGURATION, COMPARE CHANNEL CONFIGURATION, and WAVEFORM GENERATION. Eight specific settings are highlighted with red circles and numbered 1 through 8:

- 1. COMPONENT SETTINGS: Driver: Drivers:TCA:Init, Mode: TCA Normal Mode
- 2. SIGNALS: WO/0: PB0
- 3. CONFIGURATION: ENABLE: Module Enable: ☒
- 4. CONFIGURATION: CLKSEL: Clock Selection: System Clock
- 5. CONFIGURATION: PER: Period: 0x64
- 6. COMPARE CHANNEL CONFIGURATION: CMP0EN: Compare 0 Enable: ☒
- 7. COMPARE CHANNEL CONFIGURATION: CMP0: Compare Register 0: 0xa
- 8. WAVEFORM GENERATION: WGMODE: Waveform generation mode: Single Slope PWM



Result: The TCA configuration is completed.

4.2 RTC Driver



To do: Add RTC driver to generate overflow interrupt.

1. Click the **Add software component** box.
2. Expand **Drivers** from the **ADD SOFTWARE COMPONENT** window. Search for the **RTC** driver, select it and then click the **Add Component(s)**. (Refer steps 3 and 4 from the [TCA driver](#).)

Note: Add the **RTC** driver here.



Info: The **RTC_0** driver will be added to the **Assignment_ATtiny817** project. Now the RTC peripheral configuration needs to be done as shown below.



To do: Click the **RTC_0** box and configure the RTC driver to generate overflow interrupt every 500 milliseconds.



Info: The configuration is showed with red markings numbered 1 to 5 in [Figure 4-5](#).

1. Enable peripheral by selecting checkbox "RTCCEN: Enable".
2. Select "RTC Clock Source Selection" as "32 kHz Internal Ultra-Low Power oscillator (OSCULP32K)".
3. Select "PRESCALER: Prescaling Factor" as "32".



Tip: Resulting RTC clock can be verified by selecting navigation button (on the right side of the window) **CLOCKS**. Select **DASHBOARD** to return to the driver configuration.

4. Select "PER: Period" register value as 500 (or 0x1f4).



Info: This is the 16-bit Period Register: When the counter register reaches this value, the overflow interrupt is set and the counter register is reset.

5. Generate ISR code in driver_isr.c by selecting checkbox "Include ISR harness in driver_isr.c".
6. Enable overflow interrupt by selecting checkbox "OVF: Overflow Interrupt enable".

tinyAVR 1-series Training

Assignment 2: Generate PWM, Measure Duty Cycle...

Figure 4-5. RTC Configuration



Info: To generate the interrupt it is required to enable the **Global Interrupt Enable bit** in the **Status Register**. This is described below.

- Click on the small circle from the **Show system drivers** to the right side, as shown in the figure below.

Figure 4-6. Show System Drivers



tinyAVR 1-series Training

Assignment 2: Generate PWM, Measure Duty Cycle...

- Click the **CPUINT** and then select the checkbox, **CPU_SREG: Global Interrupt Enable**, as shown in the figure below.

Figure 4-7. Enable CPU_SREG

The screenshot shows the configuration window for the CPUINT component. At the top, there are tabs for BOD, CLKCTRL, SLPCTRL, and CPUINT (selected). Below the tabs, the title is 'CPUINT' with 'CPUINT' underneath. There are three tabs: 'GENERAL', 'COMPONENT SETTINGS', and 'SIGNALS'. The 'GENERAL' tab is active, showing a 'User guide' button. Below this, the 'DRIVERS:CPUINT:INIT (CPUINT) CONFIGURATION ON CPUINT' section is visible. It contains two sub-sections: 'GLOBAL INTERRUPT CONFIGURATION' and 'INTERRUPT SCHEDULING CONFIGURATION'. In the 'GLOBAL INTERRUPT CONFIGURATION' section, the 'CPU_SREG: Global Interrupt Enable' checkbox is checked and circled in red. In the 'INTERRUPT SCHEDULING CONFIGURATION' section, the 'LVL0RR: Round-robin Scheduling Enable' checkbox is unchecked. Below these, there is a 'PRIORITY CONFIGURATION' section with 'LVL0PRI: Interrupt Level Priority' set to '0x0' and 'LVL1VEC: Interrupt Vector with High' set to '0x0'.



Result: The RTC configuration is completed.

4.3 TCB Driver

The peripheral TCB will be configured to capture the PWM signal to test the capture functionality.



To do: Add TCB driver.

- Click the **Add software component** box.
- Expand **Drivers** from the **ADD SOFTWARE COMPONENT** window.
- Search for the **Timer** driver, select it and then click on the **Add Component(s)**. (Refer steps 3 and 4 from the [TCA driver](#).)



Info: The **TIMER_0** driver will be added to the **Assignment_ATtiny817** project.

- Click the **TIMER_0** and then click **Rename component**. Specify the new name as **TCB_Duty_Frequency_Measure** and click **Rename**. (Refer steps 5 and 6 from the [TCA driver](#).)

tinyAVR 1-series Training

Assignment 2: Generate PWM, Measure Duty Cycle...



Info: Now the TCB peripheral configuration needs to be done for input capture mode.



To do: Configure the TCB driver with input capture mode to measure the duty cycle and frequency of the given input PWM.



Info: The configuration is shown with red markings numbered 1 to 5 in the [Figure 4-8](#).

1. Select **Driver** as **TCB:Init**.
-



Info: Here, by default "Driver" is selected as "TCB:init".

2. Enable peripheral by selecting checkbox **ENABLE: Enable**.
 3. Select the **CLKSEL: Clock select** as **CLK_PER (No Prescaling)**.
-



Info: Here, clock source for this peripheral is selected without prescaling. This peripheral uses the system's peripheral clock CLK_PER.

4. Select **CNTMODE: Timer mode** as **Input Capture Frequency and Pulse-Width measurement**.
 5. Select the checkbox **CAPTEI: Event Input Enable**.
-



Info: Event Input is enabled as the PWM signal will be given as event input to TCB. In the "EVENT CONFIGURATION", EDGE is NOT selected (unchecked) so the timer will start counting when a positive edge is detected on the event input signal. On the following falling edge, the count value is captured. The counter stops when the second rising edge of the event input signal is detected. If EDGE is selected (checked) the timer will start counting when a negative edge is detected.

Note: The Event System configuration will be shown in the next section.

tinyAVR 1-series Training

Assignment 2: Generate PWM, Measure Duty Cycle...

Figure 4-8. TCB Configuration

TCB_DUTY_FREQUENCY_MEASURE
TCB driver

GENERAL

User guide
Rename component
Remove component

COMPONENT SETTINGS

Driver: Drivers:TCB:Init

DRIVERS:TCB:INIT (TCB) CONFIGURATION ON TCB0

CONFIGURATION

ENABLE: Enable: ☒
RUNSTDBY: Run Standby: ☐
SYNCUPD: Synchronize Update: ☐
ASYNCR: Asynchronous Enable: ☐
DBGUN: Debug Run: ☐
CLKSEL: Clock Select: CLK_PER (No Prescaling)
CNTMODE: Timer Mode: Input Capture Frequency and Pulse-Width

INTERRUPT CONFIGURATION

CAPT: Capture or Timeout: ☐

EVENT CONFIGURATION

EDGE: Event Edge: Rising
CAPTEI: Event Input Enable: ☒
FILTER: Input Capture Noise Cancellation Filter: Off

COUNT AND COMPARE/CAPTURE

CCMP: Compare or Capture: 0
CNT: Count: 0



Result: The TCB configuration is completed.

4.4 Event System Driver

The Event System (EVSYS) enables direct peripheral-to-peripheral signaling. It allows a change in one peripheral (the Event Generator) to trigger actions in other peripherals (the Event Users) through Event channels, without using the CPU. A channel path can be either asynchronous or synchronous to the main clock. The mode must be selected based on the requirements of the application.

Here the PWM signal from TCA will be connected to pin PA5 and be used as event input.



To do: Add Event System driver.

1. Click on the **Add software component** box.
2. Expand **Drivers** from the **ADD SOFTWARE COMPONENT** window.
3. Search for the **Event System** driver, select it and then click the **Add Component(s)**. (Refer steps 3 and 4 from the [TCA driver](#).)

tinyAVR 1-series Training

Assignment 2: Generate PWM, Measure Duty Cycle...



Info: The **EVENT_SYSTEM_0** driver will be added to the **Assignment_ATtiny817** project. Now the EVENT_SYSTEM peripheral configuration needs to be done.



To do: Configure the Event System driver with event input at pin PA5 and event user as TCB.



Info: The EVENT_SYSTEM configuration is shown with red markings numbered 1 and 2 in the [Figure 4-9](#).

1. Click the **EVENT_SYSTEM_0** box.
2. Select "ASYNCCH0: Asynchronous Multiplexer Channel 0" as "Asynchronous Event from pin PA5".
3. Select "ASYNCUSER0: Asynchronous User Selection Ch0 -TCB0" as "Asynchronous Event Channel 0".



Info: The Event User is TCB0 and the event input is routed through ASYNCCH0 so EVENT SYSTEM USER CONFIGURATION is selected as **Asynchronous Event Channel 0**.

Figure 4-9. EVENT SYSTEM Configuration

EVENT_SYSTEM_0
Event System

GENERAL

- User guide
- Rename component
- Remove component

COMPONENT SETTINGS

Driver: Drivers:EVSYS:Init

SIGNALS

EVOUT/0: ☐ PA2
EVOUT/1: ☐ PB2 (USART_0/TXD)
EVOUT/2: ☐ PC2

DRIVERS:EVSYS:INIT (EVSYS) CONFIGURATION ON EVSYS

EVSYS ASYNCHRONOUS CHANNEL CONFIGURATION 1		EVENT SYSTEM ASYNCHRONOUS USER CONFIGURATION 2	
ASYNCCH0: Asynchronous Multiplexer Channel 0:	Asynchronous Event from Pin PA5	ASYNCUSER0: Asynchronous User Selection Ch 0 - TCB0:	Asynchronous Event Channel 0
ASYNCCH1: Asynchronous Multiplexer Channel 1:	Off	ASYNCUSER1: Asynchronous User Selection Ch 1 - ADC0:	Off
ASYNCCH2: Asynchronous Multiplexer Channel 2:	Off	ASYNCUSER2: Asynchronous User Selection Ch 2 - CCL LUT0 Event 0:	Off



Result: The EVENT SYSTEM configuration is completed.

4.5 USART Driver

The peripheral USART will be configured to send the calculated duty cycle and frequency of the given input PWM signal.

The ATtiny817 Xplained Pro contains the Embedded Debugger (EDBG), composite USB device with Virtual COM Port interface. The Virtual COM Port is connected to a UART on the ATtiny817 and provides an easy way to communicate with the target application through the terminal software. It offers variable baud rate, parity, and stop bit settings. Note that the settings on the ATtiny817 must match the settings given in the terminal software.

Virtual COM port connection: PB2 UART TXD (ATtiny817 TX line), PB3 UART RXD (ATtiny817 RX line).



To do: Add the USART driver.

1. Click the **Add software component** box.
2. Expand **Drivers** from the **ADD SOFTWARE COMPONENT** window.
3. Search for the **USART** driver, select it and then click the **Add Component(s)**. (Refer steps 3 and 4 from the [TCA driver](#).)

Note: Add the **USART** driver here.



Info: The **USART_0** driver will be added to the **Assignment_ATtiny817** project. Now the USART peripheral configuration needs to be done.



To do: Configure the USART driver for baud rate 9600, PB2:TXD, PB3:RXD.



Info: The configuration is shown with red markings numbered 1 to 3 in the [Figure 4-10](#).

1. Under **COMPONENT SETTINGS**, set **Driver:** as **Drivers:USART_Basic** and **Mode:** as **Async Polled Mode**.
2. Under **SIGNALS**, select **RXD = PB3** and **TXD = PB2**
3. Enable Transmitter by selecting checkbox **TXEN: Transmitter Enable**. If **RXEN: Receiver enable** is checked, uncheck it
4. Select **baud rate** to **9600**.



Info: Here, by default the baud rate is 9600.

tinyAVR 1-series Training

Assignment 2: Generate PWM, Measure Duty Cycle...

Figure 4-10. USART Configuration

USART_0
UART driver in polled mode

GENERAL

- User guide
- Rename component
- Remove component

COMPONENT SETTINGS 1

Driver: Drivers:USART:Basic
Mode: Async Polled Mode

CLOCKS

USART: Main Clock (CLK_MAIN) (3.33 MHz)

SIGNALS 2

RXD: PB3
TXD: PB2

DRIVERS:USART: BASIC (ASYNC POLLED MODE) CONFIGURATION ON USART0

DRIVER CONFIGURATION

Printf support: ☐

BASIC CONFIGURATION

RXEN: Receiver enable: ☒ 3
TXEN: Transmitter Enable: ☒ 3
PMODE: Parity Mode: No Parity
SBMODE: Stop Bit Mode: 1 stop bit
CHSIZE: Character Size: Character size: 8 bit
Baud Rate: 9600 4

ADVANCED CONFIGURATION

LBME: Loop-back Mode Enable: ☐
DBGRUN: Debug Run: ☐



Result: The USART configuration is completed.

4.6 Generate Project, Code Development

All the drivers needed have been added. The project will now be generated and code will be added to:

- Vary duty cycle of PWM in RTC ISR
- Calculate duty cycle and frequency of given PWM signal
- Send calculated duty cycle and frequency through USART



To do: Generate the project.

1. Click the  **GENERATE PROJECT** box (at the bottom of the window).



Info: The "Project Summary" window lists files modified and files added to this reconfigured project. All the new and configured driver files will be listed here.

2. Select the main.c file and then click **OK**.

tinyAVR 1-series Training

Assignment 2: Generate PWM, Measure Duty Cycle...



Info: Selecting the main.c file will create a new and empty main.c file.

3. Verify that all the configured drivers are initialized in the generated project, in the `system_init()` function.



Tip: `src` → `driver_init.c` → `system_init()`



Result: The project with configured drivers is generated.



To do: Add code to the vary duty cycle of the PWM, generated by TCA in the RTC ISR.

1. Open the `driver_isr.c` file.
2. Define a variable *above* the ISR, which will be changed in the ISR and initialized to 10 as initial duty cycle is configured as 10%.

```
volatile uint8_t change_duty_cycle=10;
```

3. Add the code below *inside* the ISR to vary the duty cycle by 10% and roll over to 10% after reaching 100% in ISR.


```
change_duty_cycle+=10;
if (change_duty_cycle >100)
{
    change_duty_cycle =10;
}
TCA0.SINGLE.CMP0 = change_duty_cycle;
```



Info: The CMP0 register decides the duty cycle of TCA PWM.

4. Press 'F7' to build the project. (Build should finish successfully with no errors.)
5. Program the updated code to the device by pressing the Ctrl + Alt + F5 keys.
6. Connect the wire from PB0 to PB4 on the ATtiny Xplained Pro board as shown in the figure below.

Figure 4-11. HW Connection



Note: On the EXT1 connector, column '1' (top) corresponds to the left side PINs column and column '2' (bottom) corresponds to the right side PINs column so PB0 is at column 1 (top) and PB4 is at column 2 (bottom).



Info: The TCA PWM output is generated on pin PB0 and the LED is connected to pin PB4 on the ATtiny Xplained Pro board. So, connecting PB0 and PB4 will vary the LED intensity with the generated PWM.



Result: The LED is observed with varied intensity as the PWM duty cycle varies.



To do: Add code to calculate the duty cycle and frequency of the given PWM.

The mode in TCB is configured as 'Input Capture Frequency and Pulse Width Measurement Mode'.

In this mode, the timer will start counting when a positive edge is detected on the event input signal. On the following falling edge, the count value is captured. The counter stops when the second rising edge of

tinyAVR 1-series Training

Assignment 2: Generate PWM, Measure Duty Cycle...

the event input signal is detected. This will also set the interrupt flag. Reading the capture will clear the interrupt flag. When the capture register is read or the interrupt flag is cleared the TC is ready for a new capture sequence.

1. Open the main.c file.
2. Define variables to read the timer registers and store the calculated duty cycle and frequency above `main()`, as shown below:

```
volatile uint16_t period_after_capture = 0;
volatile uint16_t pulse_width_after_capture = 0;

volatile uint8_t capture_duty = 0;
volatile uint16_t capture_frequency = 0;
```

3. Add the code below in `while(1)` to calculate the duty cycle and frequency.

```
if(TCB0.INTFLAGS)
{
    TCB0.INTFLAGS=1;

    period_after_capture = TCB0.CNT;
    pulse_width_after_capture = TCB0.CCMP;

    capture_duty = ((pulse_width_after_capture * 100 )/period_after_capture);
    if (capture_duty>100)
    {
        capture_duty=0;
    }
    capture_frequency = F_CPU /period_after_capture;
}
```



Info: `TCB0.INTFLAGS` is set when captured values are available. This flag is cleared by writing 1 to it. The period is read through `TCB0.CNT`, the pulse width is read through the `TCB0.CCMP` register, and the duty cycle is calculated in %. The capture frequency is in Hz.



To do: Add code to send the calculated duty cycle and frequency of the given PWM through the USART.

As the RTC interrupt is generated every 500 ms and the duty cycle is varied every 500 ms, the code will be added to send the calculated duty cycle and frequency after every 500 ms.

1. Open the main.c file.
2. Define a variable to set the flag at every 500 ms and define the transmit buffer string, as shown below, above `main()`.

```
volatile uint8_t rtc_500ms_flg=0;
const char tx_buf[]={"\ncaptured data:"};
```

3. Open `driver_isr.c`. Define the `rtc_500ms_flg` as extern in the `driver_isr.c` file above ISR.

```
extern uint8_t rtc_500ms_flg;
```

4. Set the `rtc_500ms_flg` in RTC ISR in `driver_isr.c`.

```
rtc_500ms_flg=1;
```

tinyAVR 1-series Training

Assignment 2: Generate PWM, Measure Duty Cycle...

5. In the main.c file, define function `send_data()` above `main()`, to convert the calculated duty cycle and frequency to string and send it through the USART, as shown below.

```
void send_data()
{
    uint8_t i=0;
    char duty_str[4]={0},freq_str[10]={0},tx_data[30]={0};

    itoa(capture_duty, duty_str, 10);    //duty cycle to ASCII
    ltoa(capture_frequency, freq_str, 10); //frequency to ASCII

    strcat(tx_data,tx_buf);              //tx_data=tx_buf+duty cycle string+frequency string
    strcat(tx_data,duty_str);
    strcat(tx_data,"% ");
    strcat(tx_data,freq_str);
    strcat(tx_data,"Hz");

    while(tx_data[i] !=0)                //check for null character
    {
        USART_0_write(tx_data[i]);      // send data
        i++;
    }
}
```

6. Include the file `string.h` at the top of the file.

```
#include <string.h>
```




Info: The `itoa` and `ltoa` functions defined in `string.h` converts the duty cycle and frequency to ASCII. The `strcat` function concatenates the `tx_buf`, the duty cycle string, the frequency string, and the resulting string with the `tx_data` string will be sent to the terminal. The `USART_0_putc` function writes data to the TXDATA USART register. TXDATA can only be written when the Data Register Empty Flag (DREIF in `USART.STATUS`) is set, indicating that the register is empty and ready for new data.

7. Add code in `while(1)` to call the `send_data()` function after every 500 ms.

```
if (rtc_500ms_flg==1)
{
    rtc_500ms_flg=0;
    send_data();
}
```

8. Press 'F7' to build the project. (Build should finish successfully with zero errors.)
9. Program the device with the updated code by selecting **Debug** → **Start without Debugging**. (Alternative Ctrl + Alt + F5.)
10. Connect the wire from PB0 to PA5 on the ATtiny Xplained Pro board as shown in the figure below.

Figure 4-12. HW Connection PB0 to PA5




Info: TCB has been configured to capture the PWM signal at PA5, and TCA PWM is generated at PB0.

11. In Atmel Studio 7, from the menu, select **Tools** → **Data Visualizer**.

tinyAVR 1-series Training

Assignment 2: Generate PWM, Measure Duty Cycle...

12. In the Data Visualizer window, click the **Configuration** tab and then double click the **Serial Port**.



13. In the "Serial Port Control Panel" select the **EDBG Virtual COM Port** number listed and set **Baud rate** to **9600**. Click the **Open Terminal** button then **Connect**.



Tip: The EDBG Virtual COM Port number of the connected ATtiny Xplained Pro board is also listed in **Start** → **Control Panel** → **Device Manager** → **Ports**.



Result: The captured duty cycle and frequency of the given PWM signal is displayed in the terminal window.

tinyAVR 1-series Training

Assignment 2: Generate PWM, Measure Duty Cycle...

```
captured data:49% 33333Hz
captured data:59% 33333Hz
captured data:69% 33333Hz
captured data:79% 33333Hz
captured data:89% 33333Hz
captured data:99% 33333Hz
captured data:9% 33333Hz
captured data:19% 33333Hz
captured data:29% 33333Hz
captured data:39% 33333Hz
captured data:49% 33333Hz
captured data:59% 33333Hz
captured data:69% 33333Hz
captured data:79% 33333Hz
captured data:89% 33333Hz
captured data:99% 33333Hz
captured data:9% 33333Hz
```

The final code should look as shown below.

```
#include <string.h>
#include <atmel_start.h>

volatile uint16_t period_after_capture = 0;
volatile uint16_t pulse_width_after_capture = 0;
volatile uint8_t capture_duty = 0;
volatile uint16_t capture_frequency = 0;

volatile uint8_t rtc_500ms_flg=0;
const char tx_buf[]={"\ncaptured data:"};

void send_data()
{
    uint8_t i=0;
    char duty_str[4]={0},freq_str[10]={0},tx_data[30]={0};
    itoa(capture_duty, duty_str, 10); //duty cycle to ASCII
    ltoa(capture_frequency, freq_str, 10); //frequency to ASCII
    strcat(tx_data,tx_buf); //tx_data=tx_buf+duty cycle string+frequency string
    strcat(tx_data,duty_str);
    strcat(tx_data,"% ");
    strcat(tx_data,freq_str);
    strcat(tx_data,"Hz");
    while(tx_data[i] !=0) //check for null character
    {
        USART_0_write(tx_data[i]); // send data
        i++;
    }
}

int main(void)
{
    /* Initializes MCU, drivers and middleware */
    atmel_start_init();

    /* Replace with your application code */
    while (1) {
        if(TCB0.INTFLAGS)
        {
            TCB0.INTFLAGS=1;
            period_after_capture = TCB0.CNT;
            pulse_width_after_capture = TCB0.CCMP;
            capture_duty = ((pulse_width_after_capture * 100 )/period_after_capture);
            if (capture_duty>100)
            {
                capture_duty=0;
            }
            capture_frequency = F_CPU /period_after_capture;
        }
        if (rtc_500ms_flg==1)
        {

```

tinyAVR 1-series Training

Assignment 2: Generate PWM, Measure Duty Cycle...


```
        rtc_500ms_flg=0;
        send_data();
    }
}
```

5. Assignment 3: Basis of a Binary Frequency-Shift Keying Scheme

The CCL (Configurable Custom Logic) module is a programmable logic peripheral, which can be connected to the pins, events, or peripherals on the device. It allows the user to eliminate external logic gates for simple glue logic functions.

In this assignment, a small CCL-based application will be developed. It will blink an LED at two different frequencies depending on whether a button is depressed or not. Two pulse trains of different frequencies will be generated and routed to the CCL. The CCL will be configured to select which of the pulse trains to pass on to the output based on the state of a third input signal as shown in the figure below.

Figure 5-1. CCL Input/Output Waveform



Here, output = input1 when input3 is LOW, and output = input2 when input3 is HIGH.

The application can be the basis of a binary frequency-shift keying scheme that encodes binary data as discrete shifts between two frequencies.

So, in this application:

- "input1" is the PWM signal generated using TCA in Assignment 2
- "input2" event output from PIT
- "input3" is button state (SW0)
- "output" is CCL output on pin PA7

The LED will be connected to PA7 and blink with different frequencies on button press and button release.

The RTC peripheral offers two timing functions; the Real-Time Counter (RTC) and a Periodic Interrupt Timer (PIT). The PIT functionality can be enabled independent of the RTC functionality.

By using the same clock source as the RTC function, the PIT can request an interrupt or trigger an output event on every n^{th} clock period. n can be selected from {4, 8, 16,... 32768}. Here the Event System will be configured to output events from the PIT. The event signals from the PIT has the form of clock signals with periods corresponding to the respective number of the RTC clock periods. This application uses the event signal corresponding to 8192 RTC clock periods. The event signal from the PIT has a frequency of $32 \text{ kHz}/8192 = 3.9 \text{ Hz}$ (period approximately 250 ms).

The **Assignment_ATtiny817** project will be reconfigured to add the CCL driver and edit the Event System and RTC driver.

For this application, the peripherals used are:

- TCA (waveform output WO0 on PB0)
- PIT (event output)
- CCL (output PA7)

- Event System
- PB5 (SW0)

Clock details:

- 3.33 MHz main clock
- PIT 32 kHz

5.1 CCL Driver

The Configurable Custom Logic (CCL) is a programmable logic peripheral, which can be connected to the device pins, to events, or to other internal peripherals. The CCL can serve as "glue logic" between the device peripherals and external devices.

The CCL peripheral has one pair of Lookup Tables (LUT). Each LUT consists of three inputs, a truth table, and a filter/edge detector. Each LUT can generate an output as a user programmable logic expression with three inputs. The output can be generated from the inputs with different combinations.

In this application LUT1 will be used.

- "input1" is PWM generated using TCA: (WO0 of TCA)
- "input2" is event output from PIT: Event Source 1
- "input3" is button press (SW0): Event Source 0
- "output" is CCL output on pin PA7

The Truth Table for the needed combination is shown in the table below. IN[2] is button (SW0):

when IN[2] = 0, OUTPUT = IN[1] and when IN[2] = 1, OUTPUT = IN[0].

So, OUT = 0xAC.

Table 5-1. Truth Table of LUT

IN[2]	IN[1]	IN[0]	OUT
0	0	0	0 (LSB)
0	0	1	0
0	1	0	1
0	1	1	1
1	0	0	0
1	0	1	1
1	1	0	0
1	1	1	1



To do: Add the CCL driver.

1. Open the **Assignment_ATtiny817** project.
2. In the **Solution Explorer** window, click on the project name **Assignment_ATtiny817** and then **Right Click** → **Re-Configure Atmel Start Project**.

tinyAVR 1-series Training

Assignment 3: Basis of a Binary Frequency-Shif...

3. In the "Atmel | START" window, click on the  box and then expand **Drivers** from the **ADD SOFTWARE COMPONENT** window.
4. Search for the **Digital Glue Logic (CCL)** driver, select it and then click on the **Add Component(s)**. (Refer steps 3 and 4 from the [TCA driver](#).)



Info: The **DIGITAL_GLUE_LOGIC_0** driver will be added to the **Assignment_ATtiny817** project. Now the CCL configuration needs to be done as below.



To do: Configure the CCL driver to use with IN[2] = Event Source 0, IN[1]= Event Source 1, IN[0] = WO0 TCA and output on PA7.



Info: The configuration is shown with red markings numbered 1 to 6 in the [Figure 5-2](#).

1. Select **LUT1_OUT/0** on pin **PA7**.
2. Enable peripheral by selecting check-mark **ENABLE: Enable**.
3. Select checkbox **LUTEN: LUT Enable** under **LOOKUP TABLE 1 CONFIGURATION**.
4. Select checkbox **OUTEN: Output Enable** under **LOOKUP TABLE 1 CONFIGURATION**.
5. Select Input as:
 - **INSEL0:LUT input 0 source selection: = TCA WO0 input source**
 - **INSEL1:LUT input 1 source selection: = Event input source 1**
 - **INSEL2:LUT input 2 source selection: = Event input source 0**
6. Enter truth table value **TRUTH1: Truth 1** as **172** (or 0xAC). (Check OUT column from [Table 5-1](#).)

Figure 5-2. CCL Configuration

DIGITAL_GLUE_LOGIC_0
Configurable Custom Logic

GENERAL

User guide

Rename component

Remove component

COMPONENT SETTINGS

Driver: Drivers:CCL:Init

SIGNALS

LUT0_IN/0: ☐ PA0

LUT0_IN/1: ☐ PA1

LUT0_IN/2: ☐ PA2

LUT0_OUT/0: ----

LUT1_IN/0: ☐ PC3

LUT1_IN/1: ☐ PC4

LUT1_IN/2: ☐ PC5

LUT1_OUT/0: PA7 1

DRIVERS:CCL:INIT (CCL) CONFIGURATION ON CCL

BASIC CONFIGURATION

ENABLE: Enable: ☒ 2

RUNSTDBY: Run in Standby: ☐

SEQSEL: Sequential Selection: Sequential logic disable

LOOKUP TABLE 1 CONFIGURATION

LUTEN: LUT Enable: ☒ 3

OUTEN: Output Enable: ☒ 4

CLKSRC: Clock Source Selection: ☐

EDGEDET: Edge Detection Enable: Edge detector is disable

FILTSEL: Filter Selection: Filter disabled

INSEL0: LUT Input 0 Source Selection: TCA0 W00 input source

INSEL1: LUT Input 1 Source Selection: Event input source 1 5

INSEL2: LUT Input 2 Source Selection: Event input source 0

TRUTH1: Truth 1: 172 6

LOOKUP TABLE 0 CONFIGURATION

LUTEN: LUT Enable: ☐

OUTEN: Output Enable: ☐

CLKSRC: Clock Source Selection: ☐

EDGEDET: Edge Detection Enable: Edge detector is disable

FILTSEL: Filter Selection: Filter disabled

INSEL0: LUT Input 0 Source Selection: Masked input

INSEL1: LUT Input 1 Source Selection: Masked input

INSEL2: LUT Input 2 Source Selection: Masked input

TRUTH0: Truth 0: 0



Result: The CCL configuration is completed.

5.2 Event System Driver

The Event System (EVSYS) enables direct peripheral-to-peripheral signaling. It allows a change in one peripheral (the Event Generator) to trigger actions in other peripherals (the Event Users) through Event channels, without using the CPU.

Here the event signal will be generated from the SW0 (PB5) push button and the PIT (Periodic Interrupt Timer).

tinyAVR 1-series Training

Assignment 3: Basis of a Binary Frequency-Shif...

Table 5-2. Event User and Generator

Event User	Event Generator
CCL LUT1 Event 0	Event from PB5
CCL LUT1 Event 1	Event from PIT : 8192 RTC clock periods interval.



To do: Click the **EVENT_SYSTEM_0** box and configure the EVENT_SYSTEM as per the [Table 5-2](#).



Info: The configuration is shown with red markings numbered 1 to 4 in the [Figure 5-3](#).

1. Select "ASYNCCH1: Asynchronous Multiplexer Channel 1" as "Asynchronous Event from pin PB5".
2. Select "ASYNCCH3: Asynchronous Multiplexer Channel 3" as "Periodic Interrupt CLK_RTC div 8192".
3. ASYNCUSER3: Asynchronous User Selection Ch3 -CCL LUT1 Event 0" as "Asynchronous Event Channel 1".



Info: Event User is **CCL LUT1 Event 0** so the ASYNCUSER3 user configuration is through ASYNCCH1.

4. "ASYNCUSER5: Asynchronous User Selection Ch5 - CCL LUT1 Event 1" as "Asynchronous Event Channel 3".



Info: Event User is **CCL LUT1 Event 1** so the ASYNCUSER5 user configuration is through ASYNCCH3.

tinyAVR 1-series Training

Assignment 3: Basis of a Binary Frequency-Shif...

Figure 5-3. EVENT SYSTEM Configuration

EVENT_SYSTEM_0
Event System

GENERAL

User guide
Rename component
Remove component

COMPONENT SETTINGS

Driver: Drivers:EVSYS:Init

SIGNALS

EVOUT/0: ☐ PA2
EVOUT/1: ☐ PB2 (USART_0/TXD)
EVOUT/2: ☐ PC2

DRIVERS:EVSYS:INIT (EVSYS) CONFIGURATION ON EVSYS

EVSYS ASYNCHRONOUS CHANNEL CONFIGURATION

ASYNCH0: Asynchronous Multiplexer Channel 0: 1 Asynchronous Event from Pin PA5
ASYNCH1: Asynchronous Multiplexer Channel 1: Asynchronous Event from Pin PB5
ASYNCH2: Asynchronous Multiplexer Channel 2: Off
ASYNCH3: Asynchronous Multiplexer Channel 3: Periodic Interrupt CLK_RTC div 8192

EVENT SYSTEM ASYNCHRONOUS USER CONFIGURATION

ASYNCHUSER0: Asynchronous User Selection Ch 0 - TCB0: Asynchronous Event Channel 0
ASYNCHUSER1: Asynchronous User Selection Ch 1 - ADC0: Off
ASYNCHUSER2: Asynchronous User Selection Ch 2 - CCL LUT0 Event 0: 3 Off
ASYNCHUSER3: Asynchronous User Selection Ch 3 - CCL LUT1 Event 0: Asynchronous Event Channel 1
ASYNCHUSER4: Asynchronous User Selection Ch 4 - CCL LUT0 Event 1: Off
ASYNCHUSER5: Asynchronous User Selection Ch 5 - CCL LUT1 Event 1: Asynchronous Event Channel 3
ASYNCHUSER6: Asynchronous User Selection Ch 6 - TCD0 Event 0: 4 Off

EVSYS SYNCHRONOUS CHANNEL CONFIGURATION

SYNCH0: Asynchronous User Selection Ch 0: Off
SYNCH1: Synchronous Multiplexer Channel 1: Off



Result: The EVENT SYSTEM configuration is completed.

5.3 PIT Driver

The RTC peripheral offers two timing functions; the Real-Time Counter (RTC) and a Periodic Interrupt Timer (PIT). The PIT functionality can be enabled independent of the RTC functionality.



To do: Edit the RTC driver to enable PIT.

1. Click **RTC_0**.
2. Scroll down and configure RTC to enable PIT. Check the box next to PITEN.



Result: PIT is enabled.

5.4 Generate Project, Run Code

All the needed drivers have been added and the project can now be generated.

tinyAVR 1-series Training

Assignment 3: Basis of a Binary Frequency-Shif...



To do: Generate the project.

1. Click the  box (at the bottom of the window).



Info: A "Project Summary" window lists files modified and files added on this reconfigured project. All the new and configured driver files will be listed here.

2. In the "Project Summary" window, click **OK**.



Info: If the main.c and driver_isr.c files are selected, any earlier code will be overwritten and these two files will be created as empty files.

3. Verify that all the configured drivers are initialized in the generated project in folder 'src', file 'driver_init.c', in function `system_init()`.




Result: The project with the configured drivers is generated.



To do: Run the code.

1. Press 'F7' to build the project. (Build should finish successfully with no errors.)
2. Program the updated code to the device by selecting **Debug** → **Start without Debugging**.
3. Connect the wire from PA7 to PB4 on the ATtiny Xplained Pro board, as shown in the figure below.

Figure 5-4. HW Connection



Note: On the EXT1, column '1' (top) corresponds to the left side PINs column and column '2' (bottom) corresponds to the right side PINs column so PA7 and PB4 both are in column 2 (bottom).



Info: The CCL output is generated on pin PA7 and the LED is connected to pin PB4 on the ATtiny Xplained Pro board. The LED blinking with different frequencies can be observed by connecting PB4 and PA7.

4. Press the push button SW0 and observe the LED, release the push button and observe the LED.



Result: When the push button is released the LED blinks with TCA PWM that is the duty cycle is changing after every 500 ms and LED intensity varies. When the push button is pressed the LED blinks with a PIT RTC_clock /8192 period interval.



Info: This application can be made core independent if the RTC OVF interrupt is disabled. To view the LED blinking, edit the TCA driver to generate the PWM signal such that the LED blinking is visible. (E.g. 12 Hz signal with 50% duty cycle.)

6. Conclusion

This training demonstrated:

- The driver configuration through Atmel START
- The use of automatically generated driver functions in the code development
- Re-configuration of the project to edit and add drivers

You also learned:

- The different peripherals of tinyAVR 1-series
- How to use Event System to generate Event
- How to use CCL to generate output

With Atmel Studio it is easy to run real-time debugging of an application and use the I/O view, which provides register view capability and allows modifying the microcontroller registers in real-time. It is possible to debug the application using various debugging methods such as:

- Breakpoints
- Single Stepping
- I/O view

7. Get Source Code from Atmel | START

The example code is available through Atmel | START, which is a web-based tool that enables configuration of application code through a Graphical User Interface (GUI). The code can be downloaded for both Atmel Studio 7.0 and IAR Embedded Workbench® via the direct example code-link(s) below or the *BROWSE EXAMPLES* button on the Atmel | START front page.

Atmel | START web page: <http://microchip.com/start>

Example Code

- Getting Started with the tinyAVR 1-series:
 - http://start.atmel.com/#example/Atmel:getting_started_with_the_tinyavr_1_series:1.0.0::Application:Getting_Started_with_the_tinyAVR_1-series:

Press *User guide* in Atmel | START for details and information about example projects. The *User guide* button can be found in the example browser, and by clicking the project name in the dashboard view within the Atmel | START project configurator.

Atmel Studio

Download the code as an .atzip file for Atmel Studio from the example browser in Atmel | START, by clicking *DOWNLOAD SELECTED EXAMPLE*. To download the file from within Atmel | START, click *EXPORT PROJECT* followed by *DOWNLOAD PACK*.

Double-click the downloaded .atzip file and the project will be imported to Atmel Studio 7.0.

IAR Embedded Workbench

For information on how to import the project in IAR Embedded Workbench, open the Atmel | START user guide, select *Using Atmel Start Output in External Tools*, and *IAR Embedded Workbench*. A link to the Atmel | START user guide can be found by clicking *About* from the Atmel | START front page or *Help And Support* within the project configurator, both located in the upper right corner of the page.

8. Revision History

Doc. Rev.	Date	Comments
B	02/2018	Added Chapter "Relevant Devices" and section "Get code from START" into the example's readme
A	08/2017	Initial document release

The Microchip Web Site

Microchip provides online support via our web site at <http://www.microchip.com/>. This web site is used as a means to make files and information easily available to customers. Accessible by using your favorite Internet browser, the web site contains the following information:

- **Product Support** – Data sheets and errata, application notes and sample programs, design resources, user's guides and hardware support documents, latest software releases and archived software
- **General Technical Support** – Frequently Asked Questions (FAQ), technical support requests, online discussion groups, Microchip consultant program member listing
- **Business of Microchip** – Product selector and ordering guides, latest Microchip press releases, listing of seminars and events, listings of Microchip sales offices, distributors and factory representatives

Customer Change Notification Service

Microchip's customer notification service helps keep customers current on Microchip products. Subscribers will receive e-mail notification whenever there are changes, updates, revisions or errata related to a specified product family or development tool of interest.

To register, access the Microchip web site at <http://www.microchip.com/>. Under "Support", click on "Customer Change Notification" and follow the registration instructions.

Customer Support

Users of Microchip products can receive assistance through several channels:

- Distributor or Representative
- Local Sales Office
- Field Application Engineer (FAE)
- Technical Support

Customers should contact their distributor, representative or Field Application Engineer (FAE) for support. Local sales offices are also available to help customers. A listing of sales offices and locations is included in the back of this document.

Technical support is available through the web site at: <http://www.microchip.com/support>

Microchip Devices Code Protection Feature

Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.

- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as “unbreakable.”

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip’s code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Legal Notice

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer’s risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights unless otherwise stated.

Trademarks

The Microchip name and logo, the Microchip logo, AnyRate, AVR, AVR logo, AVR Freaks, BeaconThings, BitCloud, CryptoMemory, CryptoRF, dsPIC, FlashFlex, flexPWR, Helder, JukeBlox, KeeLoq, KeeLoq logo, Kleer, LANCheck, LINK MD, maXStylus, maXTouch, MediaLB, megaAVR, MOST, MOST logo, MPLAB, OptoLyzer, PIC, picoPower, PICSTART, PIC32 logo, Prochip Designer, QTouch, RightTouch, SAM-BA, SpyNIC, SST, SST Logo, SuperFlash, tinyAVR, UNI/O, and XMEGA are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

ClockWorks, The Embedded Control Solutions Company, EtherSynch, Hyper Speed Control, HyperLight Load, IntelliMOS, mTouch, Precision Edge, and Quiet-Wire are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Adjacent Key Suppression, AKS, Analog-for-the-Digital Age, Any Capacitor, AnyIn, AnyOut, BodyCom, chipKIT, chipKIT logo, CodeGuard, CryptoAuthentication, CryptoCompanion, CryptoController, dsPICDEM, dsPICDEM.net, Dynamic Average Matching, DAM, ECAN, EtherGREEN, In-Circuit Serial Programming, ICSP, Inter-Chip Connectivity, JitterBlocker, KleerNet, KleerNet logo, Mindi, MiWi, motorBench, MPASM, MPF, MPLAB Certified logo, MPLIB, MPLINK, MultiTRAK, NetDetach, Omniscient Code Generation, PICDEM, PICDEM.net, PICkit, PICtail, PureSilicon, QMatrix, RightTouch logo, REAL ICE, Ripple Blocker, SAM-ICE, Serial Quad I/O, SMART-I.S., SQI, SuperSwitcher, SuperSwitcher II, Total Endurance, TSHARC, USBCheck, VariSense, ViewSpan, WiperLock, Wireless DNA, and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

Silicon Storage Technology is a registered trademark of Microchip Technology Inc. in other countries.

GestIC is a registered trademark of Microchip Technology Germany II GmbH & Co. KG, a subsidiary of Microchip Technology Inc., in other countries.

All other trademarks mentioned herein are property of their respective companies.

© 2018, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

ISBN: 978-1-5224-2459-8

Quality Management System Certified by DNV

ISO/TS 16949

Microchip received ISO/TS-16949:2009 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC[®] MCUs and dsPIC[®] DSCs, KEELOQ[®] code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.

Worldwide Sales and Service

AMERICAS	ASIA/PACIFIC	ASIA/PACIFIC	EUROPE
Corporate Office 2355 West Chandler Blvd. Chandler, AZ 85224-6199 Tel: 480-792-7200 Fax: 480-792-7277 Technical Support: http://www.microchip.com/support Web Address: www.microchip.com	Australia - Sydney Tel: 61-2-9868-6733 China - Beijing Tel: 86-10-8569-7000 China - Chengdu Tel: 86-28-8665-5511 China - Chongqing Tel: 86-23-8980-9588 China - Dongguan Tel: 86-769-8702-9880 China - Guangzhou Tel: 86-20-8755-8029 China - Hangzhou Tel: 86-571-8792-8115 China - Hong Kong SAR Tel: 852-2943-5100 China - Nanjing Tel: 86-25-8473-2460 China - Qingdao Tel: 86-532-8502-7355 China - Shanghai Tel: 86-21-3326-8000 China - Shenyang Tel: 86-24-2334-2829 China - Shenzhen Tel: 86-755-8864-2200 China - Suzhou Tel: 86-186-6233-1526 China - Wuhan Tel: 86-27-5980-5300 China - Xian Tel: 86-29-8833-7252 China - Xiamen Tel: 86-592-2388138 China - Zhuhai Tel: 86-756-3210040	India - Bangalore Tel: 91-80-3090-4444 India - New Delhi Tel: 91-11-4160-8631 India - Pune Tel: 91-20-4121-0141 Japan - Osaka Tel: 81-6-6152-7160 Japan - Tokyo Tel: 81-3-6880-3770 Korea - Daegu Tel: 82-53-744-4301 Korea - Seoul Tel: 82-2-554-7200 Malaysia - Kuala Lumpur Tel: 60-3-7651-7906 Malaysia - Penang Tel: 60-4-227-8870 Philippines - Manila Tel: 63-2-634-9065 Singapore Tel: 65-6334-8870 Taiwan - Hsin Chu Tel: 886-3-577-8366 Taiwan - Kaohsiung Tel: 886-7-213-7830 Taiwan - Taipei Tel: 886-2-2508-8600 Thailand - Bangkok Tel: 66-2-694-1351 Vietnam - Ho Chi Minh Tel: 84-28-5448-2100	Austria - Wels Tel: 43-7242-2244-39 Fax: 43-7242-2244-393 Denmark - Copenhagen Tel: 45-4450-2828 Fax: 45-4485-2829 Finland - Espoo Tel: 358-9-4520-820 France - Paris Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79 Germany - Garching Tel: 49-8931-9700 Germany - Haan Tel: 49-2129-3766400 Germany - Heilbronn Tel: 49-7131-67-3636 Germany - Karlsruhe Tel: 49-721-625370 Germany - Munich Tel: 49-89-627-144-0 Fax: 49-89-627-144-44 Germany - Rosenheim Tel: 49-8031-354-560 Israel - Ra'anana Tel: 972-9-744-7705 Italy - Milan Tel: 39-0331-742611 Fax: 39-0331-466781 Italy - Padova Tel: 39-049-7625286 Netherlands - Drunen Tel: 31-416-690399 Fax: 31-416-690340 Norway - Trondheim Tel: 47-7289-7561 Poland - Warsaw Tel: 48-22-3325737 Romania - Bucharest Tel: 40-21-407-87-50 Spain - Madrid Tel: 34-91-708-08-90 Fax: 34-91-708-08-91 Sweden - Gothenberg Tel: 46-31-704-60-40 Sweden - Stockholm Tel: 46-8-5090-4654 UK - Wokingham Tel: 44-118-921-5800 Fax: 44-118-921-5820