


Genie®

A TEREX COMPANY

OPERATOR HANDBOOK

Code 57.0004.7200 - 05/2004

Handler with telescopic boom GTH-3713 SX




	GTH-3713sx
From s/n	11321
To s/n	15943

English
Version



**CAUTION: THOROUGHLY READ AND UNDERSTAND THIS HANDBOOK BEFORE OPERATING THE MACHINE
CAUTION: KEEP THIS HANDBOOK IN THE MACHINE AT ALL TIMES**



Genie®

EUROPEAN TECHNICAL SERVICES

GENIE FRANCE

10 Z.A. de la Croix Saint-Mathieu
28320 Gallardon
France
Tél. : 0033 (0)2 37 26 09 99
Fax : 0033 (0)2 37 26 09 98

GENIE GERMANY

Finienweg 3
28832 Achim/Bremen
Germany
Tel. : 0049 (0)4202 8852 0
Fax : 0049 (0)4202 8852 20

GENIE IBÉRICA

Gaià 31
Poligono Industrial Pla d'en Coll
08110 Montcada i Reixac
Barcelona
Spain
Tel. : 0034 93 579 5090
Fax : 0034 93 579 5091

GENIE SCANDINAVIA

Tagenevägen 72
425 37 Hisings Kärra
Sweden
Tel. : 0046 315 751 00
Fax : 0046 315 790 20

GENIE UK

The Maltings
Wharf Road
Grantham
Lincs NG31 6BH
United Kingdom
Tel. : 0044 (0)1476 584333
Fax : 0044 (0)1476 58433

Operator handbook **57.0004.7200 - GTH-3713**

No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form or by any means without prior written permission from TEREXLIFT srl.

In pursuing a policy of constant quality improvement, TEREXLIFT srl reserves the right to make changes at any time and without undertaking to give prior notice; therefore, also this publication may be subject to modifications.

Some photos or drawings have been used to illustrate a specific function; as a result, they may not refer to the machine treated in this manual.


© Copyright 2004 **TEREXLIFT srl** - All rights reserved.

Produced by:  vega



LIST OF REVISED PAGES

No.	Revision date	Revised pages	Notes	Issued by
1				
2				
3				
4				
5				
6				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				



INTRODUCTION

■ INTRODUCTION

This handbook provides information for a safe and proper operation and maintenance of the machine.

STRICTLY COMPLY WITH THE INSTRUCTIONS GIVEN IN THIS HANDBOOK! READ AND UNDERSTAND THIS HANDBOOK BEFORE STARTING, USING AND CARRYING OUT ANY OPERATION WITH AND ON THE MACHINE.

The handbook is divided into seven sections:

- Sect. **A** GENERAL INFORMATION
- Sect. **B** SAFETY
- Sect. **C** OPERATING INSTRUCTIONS
- Sect. **D** MAINTENANCE
- Sect. **E** TROUBLESHOOTING
- Sect. **F** OPTIONAL ATTACHMENTS
- Sect. **G** TABLES AND ENCLOSURES

Section **A** contains general concepts that are decisive for the knowledge of the main parts of the machine. It also contains all necessary data for a correct identification of the machine, the technical features of the machine, etc.

Section **B** is especially addressed to the personnel, who shall operate, repair and service the machine, and, in case of companies with a wide fleet of machines, to the safety responsible.

It describes the essential compulsory qualities of the personnel in charge and other important information for the safety of persons and things.

Section **C** is mainly addressed to the operators who operate the machine. This section illustrates all control devices.

Additionally, it contains the main use instructions -i.e. engine starting, machine parking, machine storing.

Section **D** is addressed to the maintenance responsible and the servicemen.

The section describes the maintenance schedule and the relevant intervals.

Section **E** deals with the failure diagnostics.

Section **F** makes a list of the main interchangeable attachments that can be coupled to the machine: dimensions, weight, application field and limits of use.

Section **G** contains tables and various enclosed documents like load charts, wiring diagrams, hydraulic schemes, torque wrench setting table, etc.

Sections are subdivided into chapters and paragraphs that are numbered progressively.

The quickest way to look for an information is the reference to the general index or the titles of the single chapters and paragraphs that represent keys for an easy consultation.


Take care of this handbook and keep it in an accessible place within the machine, even after its reading, so that it will always be within reach if in doubt.

If you are unsure about anything, please address to GENIE Assistance Service or to your agent/dealer: addresses, phone and fax numbers are printed in the cover and in the title-page of this manual.

IMPORTANT

Any difference between the contents of this manual and the real functional character of the machine can be attributed to either a machine manufactured before the issue of this manual or to a manual going to be updated after some changed effected on the machine.

Always contact Genie Assistance Service for any updated version of this manual and any additional information.



INTRODUCTION

■ SYMBOLS

When using the machine, operators could have to face some situations requiring special care and particular knowledge.

When these situations involve the safety of operators or bystanders, the machine efficiency and proper utilisation, this handbook stresses these specific instructions by means of **SPECIAL SYMBOLS**.

There are six special (or safety) symbols in this manual, always combined with keywords that class the situations according to their danger degree.

The symbols are always followed by a text explaining the situation taken into account, the attention to be paid to such situation, the method and the behaviour to be adopted. When necessary, it stresses prohibitions or supplies instructions to prevent dangers.

Sometimes, it can be followed by illustrations.

We list below the special (or safety) symbols according to the relative seriousness of the hazard situation:



Draws the attention to situations that involve your own as well as the others' safety and that can result in serious or lethal injury.



Draws the attention to situations that involve your own as well as the others' safety and that can result in serious injury or lethal injury.



Draws the attention either to situations that involve your own as well as the others' safety and that can result in minor or moderate injury or to situations that involve the machine efficiency.

ATTENTION

Draws the attention to situations that involve the machine efficiency.

IMPORTANT

Draws the attention to important technical information or practical advice that allows for a safer and more efficient use of the machine.




PROTECT THE ENVIRONMENT


Draws the attention to important environment-related information.

WHEN READING THIS MANUAL, PAY THE GREATEST ATTENTION TO THESE SPECIAL SYMBOLS AND THE EXPLANATION OF THE SITUATIONS THEY EMPHASIZE.

The manual in electronic format also contains the following symbol:




which enables the user to return to the table of contents

**GENERAL INDEX****GENERAL INDEX**

GENERAL INFORMATION	Sect.	A
SAFETY	Sect.	B
OPERATING INSTRUCTIONS	Sect.	C
MAINTENANCE	Sect.	D
TROUBLESHOOTING	Sect.	E
OPTIONAL ATTACHMENTS	Sect.	F
TABLES AND DOCUMENTS ENCLOSED	Sect.	G



Intentionally blank page




GENERAL INFORMATION

Section A

GENERAL INFORMATION

TABLE OF CONTENTS


A-1	CONVENTIONAL REFERENCES	A-2
A-1.1	Machine position	A-2
A-1.2	Labels and warning plates applied on the machine	A-3
A-1.3	Explanation of the different symbols used on the machine	A-8
A-2	MACHINE IDENTIFICATION	A-10
A-2.1	Machine model and type	A-10
A-2.2	Manufacturer	A-10
A-2.3	Machine identification plates	A-11
A-2.4	CE marking	A-11
A-2.5	Chassis serial number	A-11
A-2.6	Identification plates of the main parts	A-11
A-3	ALLOWED USE	A-12
A-3.1	Allowed use	A-12
A-3.2	Improper use	A-12
A-3.3	Residual hazards	A-12
A-3.4	Standards of reference	A-13
A-3.5	Safety devices	A-14
A-4	GENERAL DESCRIPTION	A-17
A-4.1	List of the main components	A-17
A-4.2	Description of the main components	A-18
A-4.3	Optional accessories	A-18
A-5	TECHNICAL DATA AND PERFORMANCE	A-19
A-5.1	Main dimensions	A-19
A-5.2	Limits of use	A-19
A-5.3	Weight	A-19
A-5.4	Speed	A-20
A-5.5	Payload and reach	A-20
A-5.6	Forks	A-20
A-5.7	Diesel engine	A-20
A-5.8	Electrical system	A-20
A-5.9	Machine sound levels	A-20
A-5.10	Vibration levels	A-21
A-6	LIFETIME	A-21


**GENERAL INFORMATION****■ A-1 CONVENTIONAL REFERENCES****■ A-1.1 MACHINE POSITION**

Conventionally the machine should be considered positioned as shown in the figure.

This convention is necessary to make any reference of this handbook to different machine parts (front, rear, etc.) clear and unmistakable.

Any exception to this rule will always be specified.





GENERAL INFORMATION

■ A-1.2 LABELS AND WARNING PLATES APPLIED ON THE MACHINE

This paragraph lists the labels and warning plates normally applied on standard machines or on special attachments coupled to the machine.

IMPORTANT

The familiarisation with these labels is never a waste of time. Make sure they are easy to read. For this purpose, clean them or replace those that become unreadable (either graphic or text). To clean labels, use of a soft cloth, water and soap. Never use solvents, petrol, etc. When a label is applied on a part to be replaced, make sure that the replaced part is already labelled as required or apply a new label.

Description:

Quick user guide printed on PVC with the main functions of the handler.

Meaning:

Taken from the operator's handbook, it illustrates:

- control lever,
- machine start control,
- overload warning system,
- main safety precautions.

It also contains the load capacity ratings of the forks with or without use of the outriggers.

Location:

in the cab, fixed to the strut by a magnet.

GUIDA RAPIDA PER L'USO

AVVIAMENTO DELLA MACCHINA

- Posizionare il selettore marce in folle.
- Inserire il freno di stazionamento e controllare che la spia sia accesa.
- Avviare il motore ruotando il commutatore di avviamento in posizione (P) rilasciandolo non appena il motore si sarà avviato. Qualora, dopo circa 20 secondi, l'avviamento del motore non avesse luogo, rilasciare la chiave ed attendere circa due minuti prima di tentare un nuovo avviamento.
- Con climi freddi ruotare il commutatore in posizione di preriscaldamento ed attendere circa 10 secondi prima di procedere all'avviamento.

LIMITATORE DI CARICO (DLE)

Durante il lavoro mantenere sotto controllo l'indicatore di stabilità. Gli 8 LED indicano:

- LED verdi 1-2-3-4 Macchina stabile
- LED gialli 5-6 Macchina instabile. Spia rossa lampeggiante ed allarme acustico intermittente
- LED rossi 7-8 Macchina in allarme. Pericolo di ribaltamento. Spia rossa accesa ed allarme acustico continuo. Eseguire il rientro in condizioni di sicurezza.

USO DELLE LEVE DI COMANDO


Premere sempre il pulsante di comando intenzionale (P) prima di eseguire un comando

- Abbassamento/ sollevamento del braccio azionare la leva in direzione (A) - (B)
- Brandeggio indietro/avanti dell'attrezzo terminale azionare la leva in direzione (C) - (D)
- Richiamo/sfido del braccio telescopico premere il pulsante sulla leva ed azionare la leva di comando in direzione (E) - (F)
- Livellamento macchina **OPZIONALE** azionare la leva (G) in direzione (H) abbassare il lato destro, in direzione (I) abbassare il lato sinistro
- Blocco/sblocco attrezzi **OPZIONALE** azionare la leva (J) in direzione (K) per sbloccare gli attrezzi, in direzione (L) per bloccarli
- Stabilizzatore sinistro azionare la leva (M) in direzione (N) per abbassare lo stabilizzatore, in direzione (O) per sollevarlo
- Stabilizzatore destro azionare la leva (P) in direzione (Q) per abbassare lo stabilizzatore, in direzione (R) per sollevarlo


ATTENZIONE

E' vietato utilizzare la macchina e gli accessori senza prima aver letto e compreso le norme di utilizzo e di sicurezza contenute nel manuale di istruzioni. Il mancato rispetto delle norme di utilizzo e di sicurezza puo' causare pericolo grave all'operatore e a terzi. Le istruzioni sono consegnate con la macchina e copie aggiuntive possono essere richieste al rivenditore o direttamente a Terexlift. L'operatore è responsabile del rispetto delle norme sopra riportate non sollevare carichi se la macchina appoggia su terreno instabile o inclinato. Non sollevare mai carichi superiori a quelli indicati in tabella. Non sono ammesse manovre di sollevamento con macchina in movimento. Prima di abbandonare il posto di manovra: - abbassare eventuali carichi sospesi - portare in posizione di riposo gli organi di comando del braccio - posizionare la leva marcia avanti-indietro in folle, inserire il freno a mano e arrestare il motore. Norme per l'utilizzo di macchine dotate di stabilizzatori E' vietato utilizzare gli stabilizzatori se il carico è già sollevato: gli stabilizzatori servono solamente ad aumentare la stabilità della macchina. L'uso scorretto degli stabilizzatori può causare il ribaltamento della macchina. Una apposita spia sul cruscotto indica che gli stabilizzatori sono abbassati: accertarsi che la spia sia accesa. Prima di sollevare il carico livellare la macchina controllando l'apposito indicatore di livello.

3713



GENERAL INFORMATION

**Description:**

label with yellow background and black inscription showing the “**Guaranteed sound power level**”.

Meaning:

it indicates the guaranteed sound power level measured in accordance with the Directive **2000/14/EC**

Location:

in the cab, on the rear glass, left.

DANGER**ELECTRIC CABLES AND POWER LINES**

KEEP EVERY PART OF THE MACHINE, LOADS AND ACCESSORIES AT LEAST 6 METERS FROM OVERHEAD POWER LINES

Description:

label with transparent background “**Use limits close to electric lines**”.

Meaning:

it defines the minimum distance to be kept when the machine is used close to aerial electric lines.

Location:

in the cab, on the windscreen, to the left of the driving place.

**Description:**

red/white label “**Keep out of the working range of the machine**”.

Meaning:

when the machine is running, entering the working range of the machine is prohibited.

Location:

on the telescopic boom, on the left.

**Description:**


label with white background “**Keep out of the working range of the machine**”.

Meaning:



when the machine is running, entering the working range of the machine is prohibited.

Location:

right and left on the machine



GENERAL INFORMATION



Description:

label with transparent background “**Load chart for operations with outriggers down**”.

Meaning:

it defines the exact working limits of the machine (in terms of **payload** and **reach**) to be strictly respected by the operator when using the machine with lowered outriggers.

Location:

in the cab, fixed to the strut by a magnet.

Description:

label with transparent background “**Load chart for operations without outriggers**” (or with outriggers up).

Meaning:


it defines the exact working limits of the machine (in terms of **payload** and **reach**) to be strictly respected by the operator when using the machine without outriggers (or with retracted outriggers).

Location:


in the cab, fixed to the strut by a magnet.

IMPORTANT

The load charts shown in these pages are supplied as a mere example. For the load capacity ratings, see the load charts referring to the specific machine model.



GENERAL INFORMATION

**Description:**

label on yellow background "Do not open while engine is running".

Meaning:

do not open the engine bonnet when engine is running, since this may result in serious injury due to moving parts or hot components.

Location:

on the engine bonnet.

**Description:**


label on yellow background with black drawing "Hot surfaces. Risk of burns".

Meaning:

Applied on those surfaces which during operation can become hot and cause burns.

Location:

In all parts involved such as exhaust silencer, thermal engine, heat exchanger.

**Description:**


label on yellow background with black drawing "Unscrew the plug with extreme caution: hot water. Risk of burns!".

Meaning:

Warns the operator of the risk of burns when unscrewing the plug of the compensation tank of the heat exchanger.

Location:

Applied on the compensation tank of the fluid of the heat exchanger.

**GENERAL INFORMATION**

Description:
label with transparent background
"Maximum pressure on the
ground".

Meaning:

the value indicates the maximum pressure on the ground of the outriggers to prevent the machine from sinking into the ground and avoid instability.

Location:

near each outrigger.



Description:
sticker with black inscription on
yellow background warning of the
presence of **moving parts**.


Meaning:

Use extreme caution when moving the outriggers.

Presence of moving parts.

Location:

near each outrigger.



Description:
sticker with black inscription on
yellow background warning of the
**risk of crushing injury to the
hands**.


Meaning:

Use extreme caution when moving the outriggers.

**Presence of moving gears and risk of crushing
injury to your hands.**

Location:

near each outrigger.



GENERAL INFORMATION

■ A-1.3 EXPLANATION OF THE DIFFERENT SYMBOLS USED ON THE MACHINE


This paragraph illustrates those symbols that are normally applied on the main control devices and instruments of a standard machine, and those that can be applied on accessories or special attachments. They are mainly (ISO) standardised symbols that are now part of the common life. But we consider useful to explain them once again.

IMPORTANT











Spend the necessary time to become familiar with these symbols and to learn their meaning.


Symbol	Description
	Hazard warning lights
	Windscreen wiper
	Windscreen washer
	Cab ventilation fan
	Diesel engine water temperature
	Lights switch
	Position lights
	High beam
	Fog lamp
	Turn signals
	Parking brake
	Battery charge
	Attachment pushbutton
	Steering mode switch

Symbol	Description
	Brake pressure
	Engine oil pressure
	Battery charge
	Boom up
	Boom down
	Boom out
	Boom in
	Attachment locked
	Attachment unlocked
	Fork pitching forward
	Fork pitching back



GENERAL INFORMATION

Symbol	Description	Symbol	Description
	Selector road/jobsite switching		
	Oil filter soiled		
	Air filter soiled		
	Lifting point		
	Sway right		
	Sway left		
	Right outrigger down		
	Right outrigger up		
	Left outrigger down		
	Left outrigger up		

**GENERAL INFORMATION****A-2 MACHINE IDENTIFICATION****IMPORTANT**

Check that the operator handbook refers to the delivered machine.

When asking for information or technical assistance, always specify model, type and serial number of the machine.

A-2.1 MACHINE MODEL AND TYPE

Handler with telescopic boom:

model **GTH-3713**

A-2.2 MANUFACTURER


TEREXLIFT srl

Zona Industriale (Ind. Estate) - I-06019 UMBERTIDE
(PG) - ITALY

Enrolled in the register of companies at the Court of
Perugia under no. 4823

C.C.I.A.A. n° 102886

Fiscal Code/V.A.T. no. 00249210543



GENERAL INFORMATION

■ A-2.3 MACHINE IDENTIFICATION PLATES

Two identification plates are applied on the machine.
They are:

Ⓐ **Machine and Road traffic data plate.**

Placed at the front, on the right side of the chassis.

The identification plate contains the main identification data of the machine like model, serial number and year of manufacture.

On the machines destined for the Italian market, this plate also contains the road traffic related data and the weights of the specific model of the machine.

TEREXLIFT s.r.l.	
ZONA INDUSTRIALE - 06019 UMBERTIDE (PG) - ITALY Tel. +39 075 941.811 Fax +39 075 941.53.82	
MODELLO - MODEL - MODELE - TYP - MODELO	
ANNO DI COSTRUZIONE - YEAR OF CONSTRUCTION - ANNEE DE CONSTRUCTION BAUJAHR - AÑO DE FABRICACION	200
MATRICOLA - SERIAL N. - N. DE SERIE - FZ-IDENT NR. - NO. DE SERIE	
PESO MAX ASSALE ANT. - MAX FRONT AXLE WEIGHT - POIDS MAX ESSIEU AVANT ZUL. ACHSLAST VO. N. ST VZO - PESO MAX EJE ANTERIOR	kg
PESO MAX ASSALE POST. - MAX REAR AXLE WEIGHT - POIDS MAX ESSIEU ARRIERE ZUL. ACHSLAST HI. N. ST VZO - PESO MAX EJE POSTERIOR	kg
PESO TOTALE - TOTAL WEIGHT - POIDS TOTAL - ZUL. GESAMTGEWICHT N. ST VZO PESO TOTAL	kg
MATRICOLA MOTORE TERMICO - ENGINE SERIAL N. - N. MOTEUR THERMIQUE FABRIK NR. DIESEL MOTOR - NO. DE SERIE MOTOR TERMICO	
POTENZA MOTORE TERMICO - ENGINE POWER - PUISSANCE MOTEUR MOTORLEISTUNG - POTENCIA MOTOR	kW
CARICO STATICO VERT. GANCIO DI TRAIANO-MAX. VERTICAL LOAD ON THE COUPLING HOOK-EFFORT VERTICAL MAXIMAL SUR LE CROCHET D'ATTACHE MAXIMALE STUTZLASTBEANSPRUCHUNG DES ZUGHAKENS IN VERTIKALER RICHTUNG- ESFUERZO VERTICAL SOBRE EL GANCHO DE TRACCION	kg
MASSA MAX. RIMORCHIABILE - MAX. DRAWBAR PULL AT THE COUPLING HOOK EFFORT THE TRACTION - MAXI AU CROCHET D'ATTACHE-MAXIMALE ZUGBEANSPRUCHUNG AM ZUGHAKEN-MAXIMO ESFUERZO DE TRACCION EN EL GANCHO DE TRACCION	kg
OMOLOGAZIONE	
FABBRICATO IN ITALIA - MADE IN ITALY	


Ⓑ **ROPS-FOPS type-approval plate.**

Placed on the top strut, at the back of the cab.

■ A-2.4 CE MARKING

This machine fulfils the safety requirements of the Machinery Directive. The conformity has been certified and the placing of the **CE** marking on the machine demonstrates compliance with the regulatory requirements.

The **CE** mark is printed directly on the machine data plate **Ⓐ** of the machine.





■ A-2.5 CHASSIS SERIAL NUMBER

The chassis serial number **Ⓓ** is punched on the front left part of the chassis side member.

■ A-2.6 IDENTIFICATION PLATES OF THE MAIN PARTS

The plates of the main components, not directly manufactured by **TEREXLIFT srl** (for instance, engines, pumps, etc.), are located where originally applied by the manufacturers.





GENERAL INFORMATION

■ A-3 ALLOWED USE

■ A-3.1 ALLOWED USE

The handlers have been designed and manufactured for lifting, handling and transporting agricultural or industrial products by means of specific attachments (see section F) manufactured by TEREXLIFT srl.

Any other use is considered contrary to that established and, therefore, improper.

The compliance with and the strict respect of the operation, maintenance and repair conditions, indicated by the Manufacturer, represent an essential part of the allowed use.

The handler must be used and serviced only by operators knowing its characteristics and the safety procedures in depth.

It is also essential to comply with the safety at work legislation, the precautions concerning safety and industrial medicine as well as the local and national road traffic regulations.

ATTENTION

Effecting changes or carrying out interventions on the machine other than those of routine maintenance is expressly forbidden. Any modification of the machine not carried out by GENIE or an authorised assistance centre involves the automatic invalidation of the conformity of the machine to the Directive 98/37/EC.

■ A-3.2 IMPROPER USE

Improper use means a utilisation of the handler following working criteria that do not comply with the instructions of this manual, and that, in general, may result in risks for both operators and bystanders.



DANGER


We list below some of the most frequent and hazardous situations of improper use:

- ***Carrying passengers on the machine***
- ***Not strictly complying with the operation and maintenance instructions of this handbook***
- ***Working beyond the handler working limits***
- ***Working on unstable edges of ditches***
- ***Driving crosswise on slopes or hills***
- ***Working during a storm***
- ***Working on steep slopes***
- ***Using attachments other than those recommended***
- ***Using attachments not approved or directly manufactured by Terexlift***
- ***Working in potentially explosive areas***
- ***Working in confined and non-ventilated environments.***

■ A-3.3 RESIDUAL HAZARDS

Although the machine has been designed and manufactured according to the latest technology and all expected hazards have been eliminated, some operations performed by the machine operator can result in potentially hazardous situations. Among them:

- Hazards deriving from a too high work or transfer speed in relation to the load handled or the ground condition of the jobsite.
- Hazards deriving from work procedures adopted during the check or replacement of a block valve (residual pressure - uncontrolled movements).
- Hazards deriving from work procedures adopted while disassembling parts of the machine -e.g. the cylinders, without supporting mobile parts suitably (risk of uncontrolled fall of the mobile part).
- Hazard deriving from an accidental overturning of the machine in the event the operator has not fastened the safety belts.



GENERAL INFORMATION


■ A-3.4 APPLICABLE STANDARDS

For the operator's safety, the following standards were obeyed during the risk assessment of the handler fitted with telescopic boom:

Directive	Title
98/37/CE	Machinery Directive
89/336/CEE	Electromagnetic compatibility
2000/14/CE	Environment Acoustic Emissions

Standard	Title
EN 1459:1988	Harmonised standard. Safety of industrial trucks - Self-propelled variable reach trucks.
EN 281:1988	Self-propelled industrial trucks sit-down rider-controlled. Rules for the construction and layout of pedals.
EN 1175-2:1998	Electrical requirements - General requirements of internal combustion engine powered trucks
prEN ISO 13564:1996	Test method for measuring visibility from self-propelled trucks.
ISO 2330:1995	Fork-lift trucks - Fork arms - Technical characteristics and testing.
ISO/DIS 3287	Powered industrial trucks. Pictorial signs. Control symbols.
ISO 3449:1992	Earth-moving machinery - Falling-object protective structures - Laboratory tests and performance requirements.
EN 13510: 2002	Earth-moving machinery - Roll-over protective structures - Laboratory tests and performance requirements.
ISO 3776:1989	Tractors for agriculture - Seat belt anchorages.
ISO 3795:1989	Road vehicles, tractors and machinery for agriculture and forestry - Determination of burning behaviour of interior materials.
ISO 5053:1987	Powered industrial trucks - Terminology.
ISO 6292:1996	Powered industrial trucks and tractors - Brake performance and component strength.
EN 13059:2002	Safety of industrial trucks - Test methods for measuring vibration



EN 50081-1: 1997	Electromagnetic compatibility – Generic requirements on emissions - Part 1
EN 50082-1: 1997	Electromagnetic compatibility – Generic requirements on immunity - Part 1
EN 60204-1:1998	Safety of machinery - Electrical equipment of machines - Part 1



GENERAL INFORMATION


■ A-3.5 SAFETY DEVICES

- **Load limiting device.** A load cell is placed on the rear axle. The cab display with 8 LEDs (4 green, 2 yellow and 2 red ones) enables the operator to check the stability variation of the machine.




- **Emergency stop button:** when pressed down, it stops the engine and blocks the machine movements.

Before starting work again, find and rectify the fault that caused the emergency stop, then reset the button to neutral position turning it clockwise.




- **Outrigger limit switch**

When the outriggers are lowered to the ground, the speed switch is deactivated.









- **Safety pushbutton on joystick** (deadman button). This button must be pressed and held down when the control lever is operated. If the button is released, the movement is blocked.



**GENERAL INFORMATION****• Block valves fitted to all cylinders**

- A** Block valve on attachment coupling cylinder (if present; the hydraulic cylinder is supplied as optional part)
- B** Block valve on lifting cylinder
- C** Block valve on compensation cylinder
- D** Block valve on boom extension cylinder
- E** Block valve on attachment frame pitching cylinder



**GENERAL INFORMATION**





F Block valve on outrigger cylinder



G Block valve on machine sway cylinders (if present - optional)

• **Proximity switches:**


H Proximity switch on the boom. This switch blocks the outriggers and the sway movement when the boom is raised more than 2 metres above the ground.

L Proximity switch on the parking brake. This switch does'nt allow to engage the drive system.



**GENERAL INFORMATION****A-4 GENERAL DESCRIPTION****A-4.1 LIST OF THE MAIN COMPONENTS**

- 1 - 3rd boom section
- 2 - 2nd boom section
- 3 - 1st boom section
- 4 - Driving cab according to ROPS-FOPS provisions
- 5 - Rear view mirror, left side
- 6 - Chassis
- 7 - Forks
- 8 - Attachment holding frame
- 9 - Left stabilizer
- 10 - Left sway cylinder
- 11 - Front axle
- 12 - Fuel tank
- 13 - Access step
- 14 - Hydraulic oil tank
- 15 - Rear axle



GENERAL INFORMATION

■ A-4.2 DESCRIPTION OF THE MAIN COMPONENTS

Hydrostatic transmission unit

This unit consists of parts which drive the machine shifting, and namely:

- a variable displacement pump connected to the thermal engine by an elastic joint
- a motor with variable displacement and automatic adjustment in relation to the torque required, directly applied on the axle by the power divider
- a hydraulic oil filter, placed on the discharge line to the tank
- a water/oil heat exchanger to cool the circuit down.

Steering axles/(front and rear) differential gears

The differential axles transmit the motion to the wheels. The locking device acting on the rear axle enables the machine to move also on low grip grounds. Both axles are steering; the rear axle is also of sprung type.

Tyres

The machine is equipped with tyres suitably sized for the maximum load allowed on the handler. When worn, they shall be replaced with new ones having the same dimensions and loading capacity.

Overload warning system

The overload warning system installed on the vehicle enables the operator to work under absolute safety conditions. A eight-LED display shows the stability variation. When the seventh red LED lights up, all machine movements are stopped, but for the boom retraction under safe conditions.

Boom hydraulic circuit

It consists of a pump connected to the thermal engine which, through a valve, distributes oil to the hydraulic drive and an actuator for the following functions:

- boom lifting/lowering
- telescopic boom extension/retraction
- attachment rotation
- outrigger up/down-movement
- attachment locking (if present)
- machine sway (if present)

It also feeds the following cylinders (supplied as optional parts):

- attachment locking cylinder
- machine sway cylinders.

Service hydraulic circuit

It consists of a pump connected to the thermal engine and dispensing oil to the brake pump and the hydraulic motor driving the heat exchanger fan.

Driving cab


Type-approved driving cab in compliance with standards ISO 3449 and EN 13510 (ROPS and FOPS).

■ A-4.3 OPTIONAL ACCESSORIES

The machine can be fitted with a wide range of optional accessories: please address to **Genie** sales network.


IMPORTANT

Please check the accessories available for your machine.



GENERAL INFORMATION

A-5 TECHNICAL DATA AND PERFORMANCE



A-5.1 MAIN DIMENSIONS

GTH-3713


A	Overall height	mm	2560
B	Height to the steering wheel	mm	1920
C	Overall width	mm	2330
D	Cab width	mm	910
E	Track	mm	1920
F	Wheel-base	mm	2850
G	Length to the front tyres	mm	3910
H	Length to the attachment holding plate	mm	5610
I	Ground clearance	mm	460
J	Max width with extended outriggers	mm	2930
	• Internal steering radius	mm	1300
	• External steering radius	mm	3990

A-5.2 LIMITS OF USE

•	Angle of approach	90°
•	Departure angle	45°
•	Ambient temperature	°C -20°/+40°

A-5.3 WEIGHT

•	Weight in working order	kg	9900
---	-------------------------	----	------



GENERAL INFORMATION

■ A-5.4 SPEED

- Working speed (*)	km/h	0÷8
- Travel speed (*)	km/h	0÷30
- Max. slope with full load	%	54

(*) = either forward or reverse motion.

■ A-5.5 PAYLOAD AND REACH

- Max lifting height: with outriggers	mm	12640
without outriggers	mm	12470
- Reach at max height (without outriggers)	mm	1290
- Max reach forward	mm	8740
- Attachment holding plate rotation		145°
- Maximum payload (with outriggers)	kg	3700
- Payload at max height (with outriggers)	kg	3000
- Payload at max reach (with outriggers)	kg	1000

Overturning factor according to FEM 4.001 F stability regulations

■ A-5.6 FORKS

		Floating type	Fixed type
- Dimensions	mm	1200x130x50	1200x130x50
- Weight	kg	70	70
- Fork holding frame - class		FEM III	FEM III

■ A-5.7 DIESEL ENGINE


		Aspirated version	Turbo version
- Make		PERKINS	PERKINS
- Model/Type		1104C-44	1104C-44T
- Features:		Diesel	Diesel
		4 cylinders in line	4 cylinders in line
		4 strokes	4 strokes
		direct injection	direct injection
- Bore x Stroke	mm	103 x 127	105 x 127
- Total displacement	cc	4232	4400
- Power at 2300 rpm	kW	63,5	74,4

■ A-5.8 ELECTRICAL SYSTEM

- Voltage		V	12
- Starter (power)		kW	3
- Battery		Ah	110

■ A-5.9 MACHINE SOUND LEVELS

- Guaranteed sound power level (in accordance with the Directive 2000/14/CE)	dB	Lwa =	Aspirated version 104	Turbo version 106
- Measured sound pressure level (in accordance with the Directive 98/37/CE)	dB	Lpa =	93	84

**GENERAL INFORMATION****■ A-5.10 VIBRATION LEVELS**

- Mean assessed vibration level transmitted to arms $\text{m/s}^2 < 2.5$
- Mean assessed vibration level transmitted to body $\text{m/s}^2 < 0.5$

IMPORTANT


This is a Class A device. In a residential environment, such device can cause radio disturbance. In such cases, the operator is required to take suitable measures.

■ A-6 LIFETIME

The lifetime of the machine is 10 000 hours provided all checks, service jobs and overhauls are done at the times scheduled.


**DANGER**

After this time, the machine must compulsorily be inspected and tested by the Manufacturer before being used again.



GENERAL INFORMATION

Intentionally blank page




SAFETY

Section B

SAFETY

TABLE OF CONTENTS

B-1	GENERAL REMARKS	B-2
B-2	REQUISITES OF THE PERSONNEL IN CHARGE	B-2
B-2.1	Requisites of the machine operators	B-2
B-2.2	Requisites of the servicemen	B-3
B-2.3	Working clothes	B-3
B-2.4	Personal protective equipment	B-3
B-3	SAFETY PRECAUTIONS	B-4
B-3.1	Job site	B-4
B-3.2	Getting ready to work	B-5
B-3.3	During work or maintenance	B-5
B-3.4	Safety devices	B-7
B-3.5	Load limiting device	B-7



SAFETY

■ B-1 GENERAL REMARKS

Most accidents occurring while working, repairing or maintaining operation machines, are caused by not complying with the basic safety precautions. Therefore, it is necessary to pay steady attention to the potential hazards and the effects that may come of operations carried out on the machine.

IMPORTANT

If you recognise hazardous situations, you can prevent accidents!

For instance, this handbook makes use of special **safety symbols** to stress any potentially hazardous situation.



CAUTION

The instructions given in this handbook are the ones established by GENIE. They do not exclude other safe and most convenient ways for the machine installation, operation and maintenance that take into account the available spaces and means.

If you decide to follow instructions other than those given in this manual, you shall absolutely:

- be sure that the operations you are going to carry out are not explicitly forbidden;
- be sure that the methods are safe, say, in compliance with the rules and provisions given in this section;
- be sure that the methods cannot damage the machine directly or indirectly or make it unsafe;
- contact GENIE Assistance Service for any suggestion and the necessary written permission.

IMPORTANT

If in doubt, it is always better to ask! For this purpose, contact GENIE: the assistance service is at your disposal. Addresses, phone and fax numbers are given in the cover and in the title-page of this manual.

■ B-2 REQUISITES OF THE PERSONNEL IN CHARGE

■ B-2.1 REQUISITES OF THE MACHINE OPERATORS

The operators who use the machine regularly or occasionally (i.e. for transport reasons) shall have the following requisites:

health:

before and during any operation, operators shall never take alcoholic beverages, medicines or other substances that may alter their psycho-physical conditions and, consequently, their working abilities.

physical:

good eyesight, acute hearing, good co-ordination and ability to carry out all required operations in a safe way, according to the instructions of this manual.

mental:

ability to understand and apply the enforced rules, regulations and safety precautions. They shall be careful and sensible for their own as well as for the others' safety and shall desire to carry out the work correctly and in a responsible way.

emotional:


they shall keep calm and always be able to evaluate their own physical and mental conditions.

training:

they shall read and familiarise with this handbook, its enclosed graphs and diagrams, the identification and hazard warning plates. They shall be skilled and trained about the machine use.

IMPORTANT

The operator shall have a licence (or a driving licence) when provided for by the laws enforced in the country where the machine works. Please, ask the competent bodies. In Italy the operator must be at least 18 year old.



SAFETY

■ B-2.2 REQUISITES OF THE SERVICEMEN

The personnel charged with the machine maintenance shall be qualified, specialised in the maintenance of earth-moving machines, and shall have the following requisites:

physical:

good eyesight, acute hearing, good co-ordination and ability to carry out all required maintenance operations in a safe way, according to this manual.

mental:

ability to understand and apply the enforced rules, regulations and safety precautions. They shall be careful and sensible for their own as well as for the others' safety and shall desire to carry out the work correctly and in a responsible way

training:

they shall read and familiarise with this handbook, its enclosed graphs and diagrams, the identification and warning plates. They shall be skilled and trained about the machine functioning.

IMPORTANT

From a technical point of view, the ordinary maintenance of the machine is not a complex intervention and can be carried out by the machine operator, too, provided he has a basic knowledge of mechanics.

■ B-2.3 WORKING CLOTHES

During work, but especially when maintaining or repairing the machine, operators must wear suitable protective clothing:

- Overalls or any other comfortable garments. Operators should wear neither clothes with large sleeves nor objects that can get stuck in moving parts of the machine
- Protective helmet
- Protective gloves
- Working shoes

IMPORTANT

Use only type-approved working clothing in good condition.


■ B-2.4 PERSONAL PROTECTIVE EQUIPMENT


Under special working conditions, the following personal protective equipment should be used:

- Breathing set (or dust mask)
- Ear-protectors or equivalent equipment
- Goggles or facial masks.

IMPORTANT

Use only type-approved working clothing in good condition.





SAFETY

B-3 SAFETY PRECAUTIONS

B-3.1 JOB SITE

Always take into account the features of the job site where you are going to work:


- Always examine the working area and compare it with the machine dimensions in the different configurations.

- Look for the best route to the job site.
- When the machine is running, nobody can enter its working range.
- While working, keep the working area in order. Never leave objects scattered: they could hinder the machine movements and represent a danger for personnel.
- In presence of trenches, space the wheels to keep at a safe distance from the trench edge.



Pay the greatest attention to overhead electric lines.

Always keep at a minimum safe distance from the telescopic boom and the lifted load. Electrical hazards!



DANGER

DEATH OR INJURY CAN RESULT FROM CONTACTING ELECTRIC POWER LINES.

ALWAYS CONTACT THE ELECTRIC POWER LINES OWNER. THE ELECTRIC POWER SHALL BE DISCONNECTED OR THE POWER LINES MOVED OR INSULATED BEFORE MACHINE OPERATIONS BEGIN

POWER LINE VOLTAGE		REQUIRED CLEARANCE	
0 a	50 kV	10 ft	3.00 m
50 a	200 kV	15 ft	4.60 m
200 a	350 kV	20 ft	6.10 m
350 a	500 kV	25 ft	7.62 m
500 a	750 kV	35 ft	10.67 m
750 a	1000 kV	45 ft	13.72 m




Do not at any time use the machine during a storm.



Make sure the machine (wheels and stabilisers) rests on a firm ground to prevent hazardous unstable conditions.

If the ground is not firm enough, position some supporting planks under the stabilisers or the wheels. These plates must grant a specific pressure of 1.2 to 1.5 kg/cm² (500x500mm plates are sufficient).



SAFETY

■ B-3.2 GETTING READY TO WORK

Before any operation, following precautions should be taken:

- First of all, make sure that the maintenance interventions have been carried out with care according to the established schedule (see section **D - Maintenance**).



Set the machine to working configuration and sway it. Use the special inclinometer to the right of the driving place to check that the machine is level before operating it.

- Ensure you have enough fuel to avoid a sudden stop of the engine, especially during a crucial manoeuvre.
- Clean instruments, data plates, lights and the cab windscreen thoroughly.
- Check the correct functioning of all the safety devices installed on the machine and in the job site.
- In case of troubles or difficulties, inform the foreman at once. Never start working under unsafe conditions.
- Do not carry out any repair work in a makeshift way to start working!


■ B-3.3 DURING WORK OR MAINTENANCE

During work, and especially maintenance, always pay the greatest attention:

- Do not walk or stop under raised loads or machine parts supported by hydraulic cylinders or ropes only.
- Keep the machine handholds and access steps always clean from oil, grease or dirt to prevent falls or slips.




- When entering/leaving the cab or other raised parts, always face the machine; never turn the back.
- When carrying out operations at hazardous heights (over **1.5 meters** from the ground), always use type-approved safety belts or fall preventing devices.



- Do not enter/leave the machine while it is running.
- Do not leave the driving place when the machine is running.
- Neither stop nor carry out interventions under or between the machine wheels when engine is running. When maintenance in this area is required, stop the engine.



- Do not carry out maintenance or repair works without a sufficient lighting.
- When using the machine lights, the beam should be oriented in order not to blind the personnel at work.
- Before applying voltage to electric cables or components, check their connection and proper functioning.
- Do not carry out interventions on electric components with voltage over **48V**.
- Do not connect wet plugs or sockets.
- Plates and hazard warning stickers shall never be removed, hidden or become unreadable.



SAFETY

- Except for maintenance purposes, do not remove safety devices, shields, protection cases, etc. Should their removal be necessary, stop the engine, remove them with the greatest care and always remember to refit them before starting the engine and using the machine again.
- Before any maintenance or repair work, stop the engine and disconnect the batteries.
- Do not lubricate, clean or adjust moving parts.
- Do not carry out operations manually when specific tools are provided for this purpose.
- Absolutely avoid to use tools in bad conditions or in an improper way i.e. pliers instead of adjustable wrenches, etc.
- Before carrying out operations on hydraulic lines under pressure or disconnecting hydraulic components, ensure the relevant line has been previously depressurised and does not contain any hot fluid.


**DANGER**


Any intervention on the hydraulic circuit must be carried out by authorised personnel.

The hydraulic circuit of this machine is fitted with pressure accumulators. You and others could be seriously injured if accumulators are not completely depressurised.

For this purpose, shut the engine down and step on the brake pedal 8÷10 times.

- Neither smoke nor use open flames in areas subject to fire dangers and in presence of fuel, oil or batteries.






SAFETY

- Do not leave fuel cans or bottles in unsuitable places.
- Do not empty catalytic mufflers or other vessels containing burning materials without taking the necessary precautions.
- Carefully handle all flammable or dangerous substances.



- Do not tamper with fire-extinguishers or pressure accumulators: **explosion hazard!**
- After any maintenance or repair work, make sure that no tool, cloth or other object has been left within machine compartments, fitted with moving parts, or where suction and cooling air circulates.
- When working, do not give instructions or signs to several people at the same time. Instructions and signs must be given by one person only.
- Always pay the due attention to the instructions given by the foreman.
- Never distract the operator during working phases or crucial manoeuvres.
- Do not call an operator suddenly, if unnecessary.
- Do not frighten an operator or throw objects by no means.
- After work, never leave the machine under potentially dangerous conditions.



■ B-3.4 Safety devices



DANGER

Several safety devices have been fitted to the machine. They must never be tampered with or removed (see chap. A-3.5).

Regularly check the efficiency of such devices (see check card, chap. G-5).


In case of faults, stop working immediately and proceed in replacing the defective device.

For the checking procedures, read chap. D-3.16.

■ B-3.5 LOAD LIMITING DEVICE


The load limiting system, developed to help the operator use the machine in safety conditions, alerts with visual and sound alarms when the machine is nearing a danger zone.

However this device cannot replace the experience of the Operator. It is up to the user to adopt the necessary safety measures to work in safety conditions.



SAFETY

Intentionally blank page




OPERATING INSTRUCTIONS

Section C

OPERATING INSTRUCTIONS

TABLE OF CONTENTS

C-1	BEFORE ENTERING THE MACHINE	C-2	C-3.4.8	Machine sway	C-22
C-2	ENTERING THE MACHINE	C-3	C-3.4.9	Outrigger movements	C-23
C-2.1	Entering the cab	C-3	C-4	PLACING INTO OPERATION	C-24
C-2.1.1	Emergency exit-way	C-3	C-4.1	Before starting the engine	C-24
C-2.2	Adjusting the seat	C-4	C-4.1.1	Checks at the machine start-up	C-24
C-2.3	Fastening the seat belts	C-4	C-4.2	Starting the engine	C-24
C-2.4	Adjusting the steering column	C-5	C-4.3	Jump-starting the engine	C-25
C-2.5	Adjusting the rear view mirrors	C-5	C-4.4	Disconnecting the battery	C-26
C-2.6	Switching on the cab lights	C-5	C-4.5	Starting the machine	C-26
C-3	DRIVING PLACE	C-6	C-4.6	Stopping and parking the machine	C-27
C-3.1	Controls and instruments	C-6	C-5	USING THE HANDLER	C-27
C-3.2	Engine controls and instruments	C-8	C-5.1	Using the load charts	C-28
C-3.2.1	Ignition switch	C-8	C-5.2	Load limiting system	C-29
C-3.2.2	Forward/reverse gear switch	C-8	C-5.2.1	Description of the controls	C-29
C-3.2.3	Turn signals - windscreen wiper - lights - horn switch	C-9	C-5.2.2	Use	C-29
C-3.2.4	Brakes	C-10	C-5.2.3	Alarm codes and resetting	C-30
C-3.2.5	Accelerator control	C-10	C-5.3	Handling loads	C-30
C-3.2.6	Steering mode selection	C-11	C-5.3.1	Adjusting the forks	C-30
C-3.2.7	Road/Jobsite switch	C-11	C-5.3.2	Working phases	C-31
C-3.2.8	Optional attachment control	C-11	C-5.4	Changing the optional attachment	C-32
C-3.2.9	Auxiliary drive controls	C-12	C-6	TRANSPORTING THE MACHINE	C-34
C-3.3	Instruments and light indicators	C-13	C-6.1	Moving a disabled machine	C-34
C-3.3.1	Instruments	C-13	C-6.2	Road transfer	C-34
C-3.3.2	Light indicators	C-13	C-6.3	Lifting the machine	C-35
C-3.4	Control lever	C-15	C-6.4	Transporting the machine on other vehicles	C-35
C-3.4.1	Function selection	C-16	C-6.5	Parking and storage	C-36
C-3.4.2	Emergency stop	C-17	C-6.5.1	Short inactivity	C-36
C-3.4.3	Disabling the overload warning system ..	C-17	C-6.5.2	Machine storage	C-36
C-3.4.4	Lifting/lowering the boom	C-18	C-6.6	Cleaning and washing the machine	C-38
C-3.4.5	Pitching the attachment holding frame forward/back	C-19	C-6.6.1	Cleaning instructions	C-38
C-3.4.6	Extending/retracting the boom	C-20	C-6.6.2	Washing instructions	C-38
C-3.4.7	Quick-coupling the attachments	C-21	C-6.6	Machine disposal	C-37
			C-6.6.1	Disposal of batteries	C-37

**OPERATING INSTRUCTIONS****INTRODUCTION**

This section provides the operator a practical guide for the gradual learning of the machine use.

The operator should get into the driving cab and carry out the preliminary adjustments, then memorise the position of the different controls and instruments.

The familiarisation with the controls ensures not only a correct use during the working phases, but also a prompt and timely intervention of the operator, when he shall carry out sudden manoeuvres to safeguard his safety and the machine integrity.

It is necessary to learn how to use and foresee the machine reactions. Learn how to operate the machine controls in a safe and open place, without obstacles and anybody standing around. Do not ram the controls. Operate them slowly to understand their effect on the machine.

C-1 BEFORE ENTERING THE MACHINE**Checks and cleaning**


- Clean glasses, lights and rear view mirrors.
- Check that pins, joints and bolts are well tightened in position.
- Check for oil, fuel or coolant leaks.

Checking the tyres

- Check the correct inflation of the tyres; see par. "**Tyre inflation**" in the Maintenance section.
- Make sure that the tyre plies are not cut or worn.

**DANGER**

A tyre burst may result in serious injury; never use the machine if tyres are worn, wrongly inflated or damaged.



OPERATING INSTRUCTIONS

C-2 ENTERING THE MACHINE

C-2.1 ENTERING THE CAB





CAUTION

Always make sure that your hands and shoe soles are clean and dry before getting into the driving cab. Always face the machine when entering and leaving it and hold to the suitable handles.

The handler cab is equipped with an access door on the left-hand side.

Door opening from outside:

- Insert the key and release lock **1**.
- Push the lock **1** and open the door.



Door closing from inside:

- Pull the door with force: it locks automatically.

Door opening from inside:

- Lower lever **2** and release the lock to open the door completely.
- Rotate handle **3** to open and lock the upper door section against the catch located outside the driving cab.

Unlatching the door in open position:

- Press button **4** to free the door from the latch.
- Once released, re-close the upper section of the door by means of handle **3**.



CAUTION


The upper section of the door must be secured to the rear part of the driving cab or latched to the lower section of the same door.

C-2.1.1 Leaving the cab in an emergency

In an emergency, use the rear window of the cab as safety exit-way.

This window has special locking handles with plastic pins **5** easy to pull out when you need to fully open the glass.






OPERATING INSTRUCTIONS

■ C-2.2 ADJUSTING THE SEAT

A correct adjustment of the seat ensures the operator a safe and comfortable driving. The handler seat is fitted with devices allowing for the adjustment of the seat springing, height and distance from the controls, and the backrest inclination.

- **Adjusting the seat distance from the controls**
To slide the seat forward or back, rotate lever **A** and push the seat to the desired direction. Then release the lever and make sure that the seat locks in position.
- **Adjusting seat height and springing**
Free the lever of knob **B** and turn clockwise or counter-clockwise until reaching the desired springing. Once you are correctly seated in the seat check that the yellow indicator **C** is in the green field.
- **Adjusting the backrest angle**
Operate lever **D**, press your back firmly against the backrest and put the backrest at the angle you wish, then release the lever.
- **Adjusting the armrest height**
Raise armrest **E** and turn wheel **F** to put the armrest at the height you want.




■ C-2.3 FASTENING THE SEAT BELTS


Sit correctly in the driving seat; then:

- Check that belts are not tangled, then push tab **1** into buckle **2** until it latches.
- To release the belt, push button **3** and remove the tab from the buckle.
- Make sure that belts lay on the hips and not on the stomach.
- The two ends of the buckle can be adjusted separately, by keeping the buckle in central position.



- **The seat is for one person only.**
- **Don't adjust the seat when the machine is moving.**





OPERATING INSTRUCTIONS

■ C-2.4 ADJUSTING THE STEERING COLUMN

The steering column can be set to a different angle. To adjust the angle of the steering wheel, unlock lever **1**, pull or push the steering wheel to the required position, then re-lock lever **1**.



Before driving the machine, ensure the steering wheel is perfectly clamped.


■ C-2.5 ADJUSTING THE REAR VIEW MIRRORS


The machine is fitted with two rear view mirrors:

- The right rear view mirror is located on a special supporting bracket in advanced position and allows checking the area behind the machine, on the right-hand side. To adjust its position, manually rotate the joint it is fitted with.
- The left rear view mirror is placed on the left upper post of the windscreen and allows checking the area behind the machine, on the left-hand side. To adjust its position, manually rotate the joint it is fitted with.


■ C-2.6 SWITCHING ON THE CAB LIGHTS

The ceiling light fixture is fixed to the rear top strut of the cab. The relevant lamp is switched on/off by switch **A**.





**OPERATING INSTRUCTIONS****C-3 DRIVING PLACE****C-3.1 CONTROLS AND INSTRUMENTS**

- 1 Fresh air flap
- 2 Road/Jobsite switch
- 3 Locking lever - steering column angle adjustment
- 4 Switch: turn signals - windscreen washer - horn
- 5 Ignition switch
- 6 Water temperature indicator
- 7 Warning lights and light indicators
- 8 Hydraulic oil temperature indicator
- 9 Fuel gauge
- 10 Steering selector switch
- 11 Hourmeter
- 12 Hazard warning lights switch
- 13 Air conditioning fan switch
- 14 Road lights switch
- 15 Fog lamp switch
- 16 Emergency stop pushbutton
- 17 Load limiter disabling key
- 18 Inclinometer
- 19 Gas pedal
- 20 Brake pedal
- 21 Multipurpose control lever
- 22 Machine sway control lever (optional)
- 23 Attachment locking/unlocking lever (optional)
- 24 Left outrigger control lever
- 25 Right outrigger control lever
- 26 Manual accelerator
- 27 Glove compartment
- 28 Windscreen washer water tank
- 29 Adjustable seat
- 30 Parking brake
- 31 Fuse and relay box
- 32 Cab heater control cock
- 33 Forward/reverse gear selector switch
- 34 Load moment indicator control panel



OPERATING INSTRUCTIONS






OPERATING INSTRUCTIONS

C-3.2 ENGINE CONTROLS AND INSTRUMENTS

■ C-3.2.1 Ignition switch

Four-position switch:


- No circuit under voltage, key can be removed and engine is stopped
- I Circuits under voltage, presetting for the engine starting. Board controls and instruments are on.
- ⊖ Thermostarter for cold climates. Turn the key to this position and hold it for 10÷15 seconds, then turn it to pos. I to start the engine
- ⊕ Engine starting; when released, key springs back to pos. I automatically.




■ C-3.2.2 Forward/reverse gear selector switch

Three-position switch with lock in neutral position:

- 0 Neutral position; no gear engaged
- 1 Shift lever to pos. 1 to select the forward gear
- 2 Shift lever to pos. 2 to select the reverse gear






OPERATING INSTRUCTIONS

■ **C-3.2.3 Turn signals - Windscreen wiper - Horn - Lights**


■ **Horn function:**

When sliding the lever along its axis, horn switches on, independently from other pre-set functions.



■ **Windscreen washer function:**


Push the second stage of the lever along its axis to direct a jet of water onto the cab windscreen.



■ **Windscreen wiper function:**

To operate the windscreen wiper, rotate the lever tip to one of the four positions:


- 0 Wiper OFF
- J Rear wiper (if any)
- 1 Low speed



■ **Lights function:**


To switch the handler lights, lever can be set to three different positions along its vertical axis:


- 0 low beam ON, stable condition
- 1 high beam ON, stable condition
- 2 high beam used for intermittent signalling; when released, the lever springs back to position 0.



■ **Turn signals function:**

Set lever to pos. 1 to indicate a turn leftwards or to pos. 2 to indicate a turn rightwards.



**OPERATING INSTRUCTIONS****■ C-3.2.4 Brakes****20 Service brake pedal**

Gradually step on the brake pedal to decelerate and stop the machine. The pedal operates on the axle shafts of both axles.

30 Parking brake

To engage the parking brake, pull the lever upward while holding the locking button pressed down. Release the button when reaching the required braking tension. It operates on the axle shafts of the rear axle and, when engaged, it cuts both forward and reverse gear off.

■ C-3.2.5 Accelerator control**19 Gas pedal**

Its pressure controls the engine rpm and, coupled to the gearbox, the machine speed. It is fitted with an adjustable stop in the lower part


26 Gas lever


By pulling the lever up, the engine rpm increases gradually.

To reduce the rpm, set the lever down



Never use the parking brake to slow down the machine, unless in an emergency. It may reduce the brake efficiency.






OPERATING INSTRUCTIONS

■ **C-3.2.6 Steering mode selection**

10 Steering mode switch

1 0 2 Three-position switch for the selection of the steering mode:



- 1 Crab steering
- 0 Two-wheel steering
- 2 Four-wheel steering

■ **C-3.2.7 Road/Jobsite switch**



Switch **2** has two positions and is fitted with a position locking device:

- 1 The switch is on and the jobsite mode is enabled.
- 2 The switch is off and the machine is set to road transfer mode.


The selector has a safety block to avoid any accidental switching. Before switching the selector to another position, unlock control **B** at the top of the selector.


In **Jobsite** mode:

- all the machine functions are enabled.

In **Road** transfer mode:

- the boom movement is disabled
- only the two-wheel steering mode is enabled.





OPERATING INSTRUCTIONS


■ **C-3.2.8 Auxiliary drive controls**

12 Hazard warning lights switch



Fitted with on-off position, it switches on the turn signals simultaneously. When the hazard warning light is on, the switch flashes.

13 Air conditioning fan switch



Three-position switch:
0 OFF
1 Low speed
2 High speed

14 Road lights switch



Two-position switch placed on the right side of the dashboard over the ignition switch:
0 Lights OFF
1 Position lights ON (the switch indicator lights up partially)
2 Low beam ON (the switch indicator fully lights up).

15 Fog lamp switch






Two-position switch placed on the right side of the dashboard over the ignition switch:
0 Fog lamp OFF
1 Fog lamp ON (the switch indicator lights up).

32 Cab heater control cock

Located on the left side of the driving seat base.

- Rotate clockwise for fresh air
- Rotate anticlockwise for warm air
- Adjust the flow of warm air within the cab by the air conditioning fan switch **13**.





OPERATING INSTRUCTIONS

■ C-3.3 INSTRUMENTS AND LIGHT INDICATORS

■ C-3.3.1 Instruments

6 **Engine coolant temperature indicator**

Signals the engine coolant temperature. If the finger is in the red zone and the warning light comes on, you must stop the machine and find and rectify the problem.

8 **Hydraulic oil temperature indicator**


Signals the temperature of the hydraulic oil within the reservoir. If the temperature rises above the permissible value or the red warning light comes on, you must stop the machine and find and rectify the problem.


9 **Fuel gauge**

Signals the fuel level within the tank.
if the fuel level is low (reserve), the relevant warning light comes on.

11 **Hour-meter**

Signals the total operating hours of the machine.
Use the hour-meter to gauge the routine maintenance jobs.





OPERATING INSTRUCTIONS

■ C-3.3.2 Light indicators (ref. 7)

7.1 Indicator light - low battery charge

Signals a low charge by the alternator.

7.2 Indicator light - hydraulic oil filter clogged

When this lamp sets to on, immediately change the oil filter on the suction line from the tank.

7.3 Indicator light - air filter clogged

When this lamp sets to on, clean or change the filter elements.

7.4 Indicator light - low engine oil pressure

It lights when the engine oil pressure is too low.

7.5 Indicator light - parking brake engaged

When ON, this light indicates that the parking brake is not in its rest position (it is engaged).

7.6 Indicator light - low brake pressure

It lights when the pressure of the braking circuit is too low for a correct functioning

7.7 Indicator light - high beam

Blue indicator light that signals when high beam is ON.

7.8 Indicator light - turn signals

Green indicator light that signals when turn signals are ON

7.9 Indicator light - position lights


Green indicator light that signals when position lights are ON.


7.10 Indicator light - General alarm

This red light comes on to warn of a problem of the machine. Contact the GENIE Service Centre.

7.11 Indicator light - Glow plug pre-heating

This orange light comes on during the pre-heating of the engine glow plugs. Before starting the engine wait until this light goes off.





OPERATING INSTRUCTIONS


C-3.4 CONTROL LEVER

The handlers are equipped with a joystick with servo-assisted hydraulic control for the boom lifting/lowering movements and the attachment frame forward/back pitching. Pressing the red button **1** on the joystick switches the pitching movement to telescope out/in-movement.

The control lever has an intentional control button **4** that must be pressed and held in position till the end of the movement.

If the button is not pressed down, the lever, though operated, does not perform any function.

Four additional levers are installed on the dashboard for the independent operation of the following functions: machine sway control (optional), attachment locking/unlocking (optional), left and right outrigger movement.



IMPORTANT

Seize the control lever correctly and move it gently. The motion speed of the actuators depends on the lever position: a small motion results in a slow motion of the actuators; vice versa, a full range motion of the lever corresponds to the max. speed of the actuator.



CAUTION


The control lever shall be operated only when correctly seated in the driving place.



CAUTION

Before operating the control lever, make sure that nobody is within the working range of the machine.





OPERATING INSTRUCTIONS

■ **C-3.4.1 Function selection**

After pressing the intentional control pushbutton **4**, the lever **21** is enabled to carry out the following functions:

Without pressing button **1**:


- **Boom lifting/lowering**
shift the control lever to **A** or **B**
- **Attachment frame forward/back pitching**
shift the control lever to **C** or **D**

Pressing button **1**:

- **Boom lifting/lowering**
shift the control lever to **A** or **B**
- **Boom extension/retraction**
shift the control lever to **C** or **D**

The four levers control the following functions in an independent way:


- 1 Machine sway function (optional)
- 2 Attachment locking/unlocking (optional)
- 3 Left outrigger movement
- 4 Right outrigger movement



*If the intentional control button **4** is pressed with the lever not correctly set to central position, the control of the selected actuator is operated immediately.*

<p>3713</p>		

OPTIONAL

**OPERATING INSTRUCTIONS****■ C-3.4.2 Emergency stop**

The operated functions can be stopped at any time by pressing the emergency stop button **16**.

By pressing this button, the engine of the machine is shut down.

Before restarting the machine, it is necessary to reset the pushbutton by rotating it clockwise.




Before restarting the machine, find and rectify the faults that caused the emergency


■ C-3.4.3 Disabling the load limiting system

The load limiter can be deactivated operating the key-selector placed under the protection cover **17**.



WORKING WITH THE LOAD LIMITING SYSTEM CUT OUT CAN RESULT IN A MACHINE OVERTURNING AND IN SERIOUS INJURY.







**OPERATING INSTRUCTIONS****■ C-3.4.4 Lifting/lowering the boom**

Before operating the boom, make sure that nobody is within the working range of the machine.

To lift or lower the boom:

- Set the control lever to central position and press button **4**
- Smoothly shift the lever to position **B** to lift the boom or to position **A** to lower it.






**OPERATING INSTRUCTIONS****■ C-3.4.5 Pitching the attachment holding frame forward/back**

Before operating the boom, make sure that nobody is within the working range of the machine.

To tilt forward/back the attachment holding frame:

- Set the control lever to central position and press button **4**
- Smoothly shift the lever to position **D** to pitch the holding frame forward
- Smoothly shift the lever to position **C** to pitch the holding frame back






**OPERATING INSTRUCTIONS****■ C-3.4.6 Extending/retracting the boom**

Before operating the boom, make sure that nobody is within the working range of the machine.

To extend or retract the telescopic elements of the boom:

- Set the control lever to central position and press button **4**
- Press the **Red** pushbutton and smoothly shift the lever to position **D** to extend the boom or to position **C** to retract it.




**OPERATING INSTRUCTIONS****■ C-3.4.7 Quick-coupling the attachments (optional)**


Before operating the boom, make sure that nobody is within the working range of the machine.


To lock/unlock the attachments:

- Shift the second lever toward the cab windscreen to release the attachment
- Shift the lever toward the operator's seat to lock the attachment



Before using the machine, visually check the attachment is correctly coupled.




**OPERATING INSTRUCTIONS****■ C-3.4.8 Machine sway control (optional)****IMPORTANT**


Do not operate the sway control, when boom is raised beyond the horizontal position.

To sway the machine:

- Shift the first lever toward the cab windscreen to sway the machine by lowering the right side
- Shift the lever toward the operator's seat to sway the machine by lowering the left side

**CAUTION**

Check that the machine is level on inclinometer 18. The water level must be right in the middle of the instrument.


**OPERATING INSTRUCTIONS****■ C-3.4.9 Outrigger movements****CAUTION**

Before lowering the outriggers, make sure that nobody is within the working range of the machine.


To operate the outriggers:


Left outrigger

- Shift the third lever toward the cab windscreen to lower the left outrigger
- Shift the lever toward the operator's seat to raise the left outrigger

**Right outrigger**

- Shift the fourth lever toward the cab windscreen to lower the right outrigger
- Shift the lever toward the operator's seat to raise the right outrigger





OPERATING INSTRUCTIONS

C-4 PLACING INTO OPERATION

C-4.1 BEFORE STARTING THE ENGINE

- To ensure safe conditions to the operators and the bystanders, and a longer life to your machine, perform a walk-around inspection before starting the engine.
- Remove any dirt or rubbish from the cab interior, and especially from pedals and control levers.
- Remove oil, grease and mud from pedals and control levers.
- Make sure that your hands and shoe soles are clean and dry.
- Check the seat belts can be fastened properly.
- Check that lights, indicators, side/tail lights, hazard indicator lights, wipers and horn are in working order.
- Adjust the driving seat so that you can reach all control levers comfortably and fully depress the brake pedal without moving your back from the driving seat.
- Adjust the rear view mirrors to give you a good view close behind the machine when you are correctly seated.
- Check the parking brake is engaged.

C-4.1.1 Checks at the machine start-up


When power is turned on, the load limiting system activates automatically. If the power supplied is correct, the green light above the Terex logo comes on, the display remains off and the system runs a self-test. After that, the display shows **1** or **0** depending on the attachment selected (1 = platform; 0 = forks or any other attachment).


If during the test phase, the load limiting system finds a fault, it enters the safety mode automatically blocking any dangerous manoeuvres and an error code will start flashing on the display. For any further information, refer to [chap. C-5.2](#).

Also check the efficiency of the safety devices as described in [chap. D-3.16](#), namely:

- overload warning system
- joystick pushbutton
- parking brake proximity switch
- machine start-up control
- emergency pushbutton

C-4.2 STARTING THE ENGINE

- Put the mechanical gear lever to neutral.
- Step on the gas pedal.
- To start the engine, rotate the ignition switch to position , and release when the engine starts. If the engine does not start within 20 seconds, release the key and wait at least 2 minutes before attempting again.
- After the engine starting, slow down the rpm and wait some seconds before engaging a gear; this allows for a gradual warm up of the engine oil and a better lubrication.
- In case of engine jump-starting, remove the connecting cables (see following chapter).



ATTENTION

If the light indicators do not switch off/on when engine is running, immediately stop the machine and find and rectify the fault.


IMPORTANT

Engine cannot be started if the gear lever is not in neutral position.



DANGER

After the start-up, when leaving the driving place, the engine continues to run. DO NOT LEAVE THE DRIVING PLACE BEFORE HAVING SHUT THE ENGINE DOWN, LOWERED THE BOOM TO THE GROUND AND ENGAGED THE PARKING BRAKE.

**OPERATING INSTRUCTIONS****■ C-4.3 JUMP-STARTING THE ENGINE**

When jump-starting the engine through the battery of another machine, make sure that the two vehicles cannot collide to prevent formation of sparks. Batteries give off a flammable gas and sparks may burn it and cause an explosion


Do not smoke when checking the electrolyte level.

Keep any metal object like buckles, watch straps, etc. clear of the battery positive (+) terminal. These elements can short between the terminal and nearby metal work and the operator can get burned.


The booster supply must have the same rated voltage and output of the battery installed on the handler.

To jump-start the engine:


- Turn any users off by the special control levers.
- Put the gear lever to neutral and engage the parking brake.
- Ensure the machine battery **A** is connected to the frame earth, the terminals are well tightened and the electrolyte level is regular.
- Connect the two batteries as shown in the figure. Connect first the positive terminals of the two batteries, then the negative terminal of the booster supply **B** to the machine frame earth.
- If the booster supply is installed on a second vehicle, make sure that the latter does not touch the handler; then start the vehicle and reach an rpm corresponding to 1/4 of full throttle.
- Turn the ignition key and start the handler, then follow the procedure explained in chapter C-4.2 "Starting the engine".
- Disconnect the cables. Remove first the negative terminal from the frame earth, then from the booster supply. Disconnect the positive terminal from the machine battery, then from the booster supply.



Use only a 12V battery; other devices like battery chargers, etc. may cause an explosion of the battery or result in damage to the electrical system.

**OPERATING INSTRUCTIONS****■ C-4.4 DISCONNECTING THE BATTERY**

During maintenance or repair works, and especially while welding, turn off the battery main switch **A** placed in the rear right wheel compartment.


**■ C-4.5 STARTING THE MACHINE**

When the engine reaches the running temperature, ensure all parts are in transfer position and the gearbox lever is in neutral. Then, proceed as follows:

- Select the required steering mode.
- Select the required gear (forward or reverse).
- Release the parking brake.
- Slowly step on the gas pedal to start moving off.

**CAUTION**

Do not operate the forward/reverse gear lever when the machine is running. The machine would reverse the running direction abruptly and you could seriously be injured.

**OPERATING INSTRUCTIONS****■ C-4.6 STOPPING AND PARKING THE MACHINE**

When possible, stop the machine on a dry, level and solid ground. Then:

- Bring the machine to a smooth stop by easing up the gas pedal and stepping down on the brake pedal.
- Set the forward/back speed lever to neutral position.
- Engage the parking brake and ensure its indicator light switches on.
- Release the service brake pedal.
- Rest the attachment coupled to the boom flat on the ground.
- Rotate the ignition key to “0” and remove the key.
- Leave the driving cab and lock the cab door.
- Set the battery cut-out switch to **OFF** position.



Always face the machine when getting off the driving cab; make sure that your hands and shoe soles are clean and dry, and hold to the handholds to prevent falls or slips.



Always engage the parking brake after stopping the machine to prevent possible accidental motions of the vehicle.



Leaving the battery connected can cause a short-circuit posing a fire hazard.

■ C-5 USING THE HANDLER

This chapter describes some techniques and provides instructions for a safe use of the machine fitted with standard forks. Before using different attachments, thoroughly read the chapter “Optional attachments”.




Before using the machine, inspect the job site and check for possible hazardous conditions. Make sure that there are no holes, moving banks or debris that may cause you to lose the control of the machine.



Pay the greatest attention when working close to electric lines. Check their position and ensure that no part of the machine operates at less than 6 meters from the power lines.



For a safe use of the machine, always check the weight of the loads going to be handled. Always refer to the load charts applied on the cab windscreen.



OPERATING INSTRUCTIONS

■ C-5.1 USING THE LOAD CHARTS


On the cab windscreen, there are the charts indicating the maximum permissible load in relation to the boom extension and the type of attachment used. Always use these charts as a reference to operate under safe conditions.




The load charts illustrated in this manual are given only as a mere example. To define the payload limits, refer to the load charts applied within the cab of your machine.



The load charts applied on the cab windscreen refer to a stationary machine standing on a solid and level ground. Raise the load some centimetres and check its stability before raising it completely.






OPERATING INSTRUCTIONS

■ **C-5.2 LOAD LIMITING SYSTEM**

On the front top strut of the cab, there is the load limiter **34** which warns the operator of the variation of stability of the machine and blocks any manoeuvre of the same before reaching a critical condition.

■ **C-5.2.1 Description of the controls**

- 1 Calibration selection button
- 2 Display
- 3 Overload warning system LED-bar
- 4 Green light – power OK
- 5 Yellow light – calibration mode
- 6 Calibration confirmation button
- 7 Not used
- 8 Yellow light – outrigger position
- 9 Buzzer ON/OFF pushbutton
- 10 Red light – overload pre-alarm – alarm



The digit on display **2** shows the selected attachment. The user can choose among:

- 0: Generic**
- 1: Platform**

■ **C-5.2.2 Operation**

When power is turned on, light **4** comes on. The display **2** remains off while the system runs a self-test before displaying the digit corresponding to the selected attachment on display **2**. At this time, the system is activated.


During operation, the led-bar **3** lights up gradually depending on the variation of stability.


Green LED's: during normal operation when the percentage of overturning moment is between 0 and 89, these LED's are ON. The machine is stable.

Yellow LED's: they light up when the machine tends to overturn and the percentage of overturning moment with respect to the threshold value is between 90 and 100. The system enters the **pre-alarm** mode, light **10** flashes and the buzzer sounds with an intermittent sound.

Red LED's: risk of overturning: the percentage of overturning moment is above 100 with respect to the threshold value. The machine enters the **alarm mode**: light **10** is lit, the buzzer sounds continuously and any dangerous manoeuvre is blocked. The operator can only retract the load within safety limits.

Example of use of the load limiting system



**OPERATING INSTRUCTIONS****DANGER**

The overload warning system must not be used to check the load to be handled: it has only been designed to signal possible unbalances of the machine.


Such unbalances may also be caused by an abrupt operation of the levers during the load handling. If, during work, several indicators light up, try to operate the levers more smoothly.


■ C-5.2.3 Alarm codes and resetting

The limiter has diagnostic facilities to aid in the identification of faults of the transducers, breakages of the cables or defects of the electronic system.

When a fault is detected, the limiter enters the safety mode blocking any dangerous manoeuvres. Lights **5**, **8** and **10** start flashing, the buzzer starts sounding and an error code is shown on the display.

The meaning of the error messages is shown in Section **E** “**Faults and Troubleshooting**”.





OPERATING INSTRUCTIONS


■ C-5.3 HANDLING LOADS

■ C-5.3.1 Adjusting the forks

With FEM forks

Forks shall be spaced to suit the load going to be handled. For this purpose:


- Lift the clamping lever of the forks.
- Slide the forks to the desired position, then re-lock the lever.



With floating forks


In the case of floating forks:

- Loosen the nut of the locking screws.
- Raise the forks and slide them on the pivot until correct spacing.
- Lock the screws re-tightening the nut.



CAUTION

- **The centre of gravity of the load must always be halfway between the forks.**
- **Ensure you exactly know the weight of the load before handling it.**
- **When extending the boom, do not exceed the payload limit.**
- **Refer to the payload limits given in the load chart applied on the cab windscreen or in the quick user's guide.**
- **Space the forks as wide as possible to suit the load being handled.**



OPERATING INSTRUCTIONS

■ C-5.3.2 Working phases

When forks are correctly spaced, the handler is ready to use.

Work can be subdivided into three different phases: loading, transfer and unloading.

Loading phase

- Approach the load to the handler perpendicularly and check that the machine is level on the inclinometer.
- Insert the forks under the load and raise the load some centimetres.
- Pitch the forks back and make sure that the overload warning system LEDs are in limits.

Transfer phase

- Do not start or brake abruptly.
- Drive to the unloading point cautiously and keep the load 20÷30 cm from the ground.
- Suit the machine speed to the ground conditions to avoid dangerous jumps, side skids of the vehicle and possible load falls.
- When driving on slopes or ramps, hold the load uphill.



Do not drive on slopes sideways; this wrong manoeuvre is one of the main reasons for accidents due to vehicle overturning.





Unloading phase


- Drive to the unloading point with straight wheels and bring the machine to a smooth stop leaving enough space to operate the boom.
- Put the parking brake and set the transmission to neutral.
- Position the load some centimetres above the desired position and set the forks level.
- Lower the load and make sure it is level.
- Carefully withdraw the forks by operating the boom retraction control and, if necessary, raise or lower the boom as forks come out.
- When the forks are clear of the load, set them to transfer position.

- Release the parking brake and start a new working cycle.



Do not move off when the load is raised 20÷30 cm above the ground. Risk of machine overturning or load fall.





OPERATING INSTRUCTIONS

■ C-5.4 CHANGING THE ATTACHMENT


ATTENTION

Use only attachments directly manufactured or recommended by Terexlift and detailed in the “Optional attachments” section.

Version with hydraulic locking (optional)

To change an attachment, operate as follows:

- Drive to the place where you will release the mounted attachment (when possible, a solid and sheltered site).
- Disconnect the quick connectors of the attachment (if any), and connect the hydraulic locking pipes of the attachments to couplings **A**.









- Rest the attachment flat on the ground.
- Free the attachment operating the control of the attachment locking/unlocking cylinder
- Pitch the attachment holding frame forward and lower the boom to release the attachment upper lock.
- Move back with the machine and drive to the new attachment to be coupled.
- Hold the frame pitched forward and hook the upper lock of the new attachment.
- Retract and raise the attachment some centimetres. It will centre automatically on the quick coupling frame.
- Operate the (optional) control lever to lock the attachment.
- Couple the connectors of the attachment, if any, to the quick couplings of the frame.



CAUTION

After substitution, visually check the attachment is correctly coupled to the boom, before operating the machine. A wrongly coupled attachment may result in damage to persons or things.






OPERATING INSTRUCTIONS

Version with mechanical locking

To change an attachment, operate as follows:

- Drive to the place where you will release the mounted attachment (when possible, a solid and sheltered site).
- Disconnect the quick connectors of the attachment (if any).
- Pull out pin **B** locking the attachment after removing the safety split-pin at its end.
- Rest the attachment flat on the ground.
- Pitch the attachment holding frame forward and lower the boom to release the attachment upper lock.
- Move back with the machine and drive to the new attachment to be coupled.
- Hold the frame pitched forward and hook the upper lock of the new attachment.
- Retract and raise the attachment some centimetres. It will centre automatically on the quick coupling frame.
- Refit pin **B** fixing it with its safety split-pin.
- Re-couple the connectors of the attachment (if any).



CAUTION

After substitution, visually check the attachment is correctly coupled to the boom, before operating the machine. A wrongly coupled attachment may result in damage to persons or things.



OPERATING INSTRUCTIONS

■ C-6 TRANSPORTING THE MACHINE

■ C-6.1 MOVING A DISABLED MACHINE

Tow the machine only when no alternative is possible, since this operation may result in serious damage to the transmission. When possible, repair the machine on site.

When the machine shall absolutely be towed:

- Tow the machine for short distances and at a low speed only.
- Use a rigid drawbar.
- Select the two-wheel steer.
- When possible, start the engine and use the hydraulic drive and the braking system.

■ C-6.2 ROAD TRANSFER

When travelling on public roads, strictly obey the local or national road traffic regulations.

Besides, take into account the following general precautions:


- Set the ROAD/JOBSITE switch to "ROAD".
- The steering switch will switch to the two-wheel steering mode automatically.
- Lock the machine as indicated in the Registration Card:
Lock the boom sections, the lifting cylinder, and the attachment rotation cylinder (see photo).
- Lock the rear wheel steering using the special pins (if any).
- Cover the teeth of the conventional forks with the special guard; or withdraw the floating forks.
- Retract boom and attachment to transfer position.
- Make sure that lights, horn and turn signals are in working order.
- Engage the gear.
- The transfer speed of the vehicle will depend on the engine rpm and the position of the control lever.




CAUTION

Public road circulation is allowed only for transferring an unloaded machine.

Do not use the machine to tow trailers.






OPERATING INSTRUCTIONS

■ C-6.3 LIFTING THE MACHINE

When the machine shall be lifted, use only means having a suitable capacity. The characteristic data are detailed in the relevant chapter of this manual and on the identification plate.


For the machine lifting, anchor the chains to the special lugs on the machine.




■ C-6.4 TRANSPORTING THE MACHINE ON OTHER VEHICLES

To transport the machine on another vehicle, follow the steps below:

- Put chocks at the transporting vehicle wheels.
- Ensure ramps are correctly positioned.
- Retract the boom to transfer position.
- Carefully drive the machine onto the transporting vehicle.
- Put the parking brake and rest the attachment flat on the vehicle platform.
- Ensure the overall dimensions do not exceed the allowed limits.
- Shut the engine down and close the driving cab of the machine.
- Secure the machine to the vehicle platform by wheel-chocks.
- Anchor the machine to the transporting vehicle with suitable chains.



**OPERATING INSTRUCTIONS****■ C-6.5 PARKING AND STORAGE****■ C-6.5.1 Short inactivity**

Always park the machine in a safe way after a working day, a shift and at night.

Take all precautions to prevent damage to those persons who will approach the machine while stationary:

- Park the machine so that it does not hinder other operations.
- Lower the boom fitted with attachment on the ground.
- Disengage the transmission and put the parking brake.
- Remove the key from the ignition switch and lock the cab door.
- Disconnect the battery by the appropriate switch ("Battery cut-out switch").

ATTENTION

Leaving the battery connected can cause a short-circuit posing a fire hazard.


■ C-6.5.2 Machine storage

In case of extended inactivity of the machine, follow the above precautions. Additionally:

- Wash the machine thoroughly. For a better cleaning, remove grills and protection casings
- Carefully dry all machine parts by blowing some compressed air.
- Lubricate the machine thoroughly.
- Do a walk-around inspection and replace any worn or damaged part.
- Re-paint any worn or damaged part.
- Remove the battery, smear its terminals with vaseline and store it in a dry place. Battery can be used for other purposes. Otherwise, periodically check its charge level.
- Refuel the tank to prevent internal oxidation.
- Store the machine in a sheltered and well-ventilated place.
- Start the engine for about 10 minutes at least once a month.
- When weather is particularly cold, empty the radiator.

IMPORTANT

Always remember that the ordinary maintenance must be carried out even during the machine inactivity. Pay particular attention to the fluid levels and to those parts subject to ageing. Before re-starting the machine, carry out an extraordinary maintenance and carefully check all mechanical, hydraulic and electrical components.



OPERATING INSTRUCTIONS

■ C-6.6 CLEANING AND WASHING THE MACHINE

■ C-6.6.1 Cleaning instructions

Clean the machine in accordance with the following instructions:

- Remove any oil or grease traces with a dry solvent or a volatile mineral alcohol
- Before assembling a new part, remove any protection product (rust-preventer, grease, wax etc.).
- Remove any trace of rust from metal parts with some emery cloth before smearing the part with a protection product (rust-preventer, paint, oil etc.).

■ C-6.6.2 Washing instructions

IMPORTANT

Do not use water at high pressure for washing the machine and especially the distributor, the solenoid valves and electrical parts.

External washing

Before washing the machine, check that the engine is shut down and the doors and windows are closed. Do not, at any times, use fuel to clean the machine. Use water or some steam. In cold climates, dry the locks after washing or smear them with an antifreeze. Before using the machine again, check its conditions.

Internal washing

Wash the machine interior with some water and a sponge. Do not use water at high pressure. After washing, dry with a clean cloth.

Washing the engine

Before washing the engine, protect the air intake filter from water.

■ C-6.6 MACHINE DISPOSAL



At the end of the machine life, call in a specialised firm to dispose of it in compliance with the local or national regulations.


■ C-6.6.1 BATTERY DISPOSAL



Used lead-acid batteries cannot be disposed of as normal industrial solid wastes. Because of the presence of harmful substances, they must be collected, eliminated and/or recycled in accordance with the laws of the UE.

In Italy, used or discarded batteries have been classified as "Toxic wastes" in accordance with Presidential decree n. 397 of 09/09/1988 and Law n. 475 O.G. n. 18 of 09/11/1988 because they contain lead and sulphuric acid. Their disposal through recycling must be done only through companies authorised and belonging to the "Consorzio Obbligatorio Batterie Esauste e dei rifiuti piombosi" (Cobat) which collect and dispose of used lead-acid batteries throughout the national territory.

Used batteries must be kept in a dry and confined place. Make sure the battery is dry and the cell plugs are tight. Place a sign on the battery to warn of not using it. If before disposal the battery is left in the open air, it will be necessary to dry, smear the box and the elements with a coat of grease and tighten the plugs. Do not rest the battery on the ground; it is always advisable to rest it on a pallet and cover it. The disposal of batteries shall be as rapid as possible.




MAINTENANCE

Section **D**

MAINTENANCE

TABLE OF CONTENTS

D-1	LUBRICANTS - HEALTH AND SAFETY PRECAUTIONS	D-2
D-2	ORDINARY MAINTENANCE	D-3
D-2.1	Oil change schedule	D-4
D-3	MAINTENANCE INTERVENTIONS	D-5
D-3.1	Disconnecting the battery	D-6
D-3.2	Access to the engine compartment	D-6
D-3.3	Greasing	D-7
D-3.4	Tyres and wheels	D-8
D-3.5	Brakes	D-8
D-3.6	Engine air filter	D-9
D-3.6.1	Cab air filter	D-10
D-3.7	Engine cooling system	D-10
D-3.8	Checking the oil level in the tank	D-11
D-3.9	Changing the canisters of the oil filter	D-12
D-3.9.1	Transmission oil filter	D-12
D-3.9.2	Auxiliary circuit oil filter	D-13
D-3.10	Oil level in the differential gears	D-13
D-3.11	Oil level in the (front/rear) wheel reduction gears	D-14
D-3.12	Oil level in the power divider	D-14
D-3.13	Shafting alignment	D-15
D-3.14	Adjusting the sensor distance	D-16
D-3.15	Adjusting the sliding pads of the boom sections	D-17
D-3.16	Checking the safety devices	D-18
D-3.17	Re-sequencing the telescopic boom	D-24
D-4	ELECTRICAL SYSTEM	D-22
D-4.1	Battery	D-22
D-4.2	Fuses and relays	D-23
D-4.3	12V DC lamps	D-25
D-5	REFUELLING	D-26
D-5.1	Refuelling	D-26
D-5.2	Product specifications	D-26
D-5.2.1	Engine oil	D-26
D-5.2.2	Lubrication oils and relevant filtering elements	D-26
D-5.2.3	Fuel	D-27
D-5.2.4	Grease	D-27
D-5.2.5	Engine coolant	D-27

**MAINTENANCE****INTRODUCTION**

A thorough and regular maintenance keeps the machine in a safe and efficient working condition.

For this reason, it is advisable to wash, grease and service the machine properly, especially after having worked under particular conditions (muddy or dusty environments, heavy operations, etc.).

Always ensure all machine components are in good condition. Check for oil leaks or loosening of guards, and make sure that the safety devices are efficient. In case of defects, find and rectify them before using the machine again.

The maintenance interventions are based on the machine working hours. Regularly check the hour-meter and keep it in good condition to define the maintenance intervals correctly.

Not respecting the ordinary maintenance schedule of this manual automatically voids GENIE warranty.

IMPORTANT

For the engine maintenance, please refer to the specific Operator handbook supplied with the machine.

D-1 LUBRICANTS - HEALTH AND SAFETY PRECAUTIONS**Health**

A prolonged skin contact with oil can cause irritation. Use rubber gloves and protective goggles. After handling oil, carefully wash your hands with soap and water.

Storage

Always keep lubricants in a closed place, out of the children's reach. Never store lubricants on the open air and without a label indicating their contents.

Disposal

New or exhausted oil is always polluting! Never drain oil on the ground. Store new oil in a suitable warehouse. Pour exhausted oil into cans and deliver them to specialised firms for disposal.

Oil leaks

In case of accidental oil leaks, cover with sand or type-approved granulate. Then scrape off and dispose of it as chemical waste.

First aid**Eyes:**

In case of accidental contact with the eyes, wash with fresh water. If the irritation persists, seek medical advice.

Intake:


In case of oil intake, do not induce vomiting, but seek medical advice.

Skin:

In case of a prolonged contact, wash with soap and water

Fire

In case of fire, use carbon dioxide, dry chemical or foam extinguishers. Do not use water.



MAINTENANCE

D-2 ORDINARY MAINTENANCE

A wrong or neglected maintenance can result in possible risks for both operator and bystanders. Make sure maintenance and lubrication are carried out according to the manufacturer's instructions to keep the machine safe and efficient.

The maintenance interventions are based on the machine working hours. Regularly check the hour-meter and keep it in good conditions to define the maintenance intervals correctly. Make sure any defect detected during the maintenance is promptly rectified before using the machine.

ATTENTION

All "▲" marked operations must be carried out by a skilled technician.

During the first 10 working hours

- 1 Check the oil level within reduction gears, power divider and differential gears
- 2 Regularly check the tightening of the wheel bolts
- 3 Check the tightening of all bolts and nuts
- 4 Check the couplings for oil leaks

Within the first 50 working hours

- 1 Change the oil for the first time

Every 10 working hours or daily

- 1 Check the engine oil level
- 2 Clean the air suction filter
- 3 Check the engine coolant level
- 4 Clean the radiator, if necessary
- 5 Check the hydraulic oil level in the tank
- 6 Check the greasing of the boom section pads
- 7 Grease the attachment holding frame
- 8 Grease all joints of the boom, the rear axle shaft joint, the transmission shafts, the front and rear axles and any equipment of the machine
- 9 Check the efficiency of the overload warning system
- 10 Check the efficiency of the lighting electric system

- 11 Check the efficiency of braking system and parking brake
- 12 Check the efficiency of the steering selection system
- 13 Check the efficiency of the fork balancing system.
- 14 Make sure the safety devices installed are in efficient working order - see procedure in **chap. D-3.16.**
- 15 Check or re-sequence the boom telescopes as indicated in **chap. D-3.17.**

Every 50 working hours or weekly


Jobs to be done in addition to those above

- 1 Check the tension of the alternator belt
- 2 Check the tyre inflation
- 3 Check the tightening of the wheel nuts
- 4 Check the tightening of the Cardan shaft screws
- 5 Check the tightening of the sliding pads of the telescope.

Every 250 working hours or monthly

Jobs to be done in addition to those above

- 1 Change the engine oil and relevant filter
- 2 Check the oil level in the front and rear differential gears
- 3 Check the oil level in the four wheel reduction gears
- 4 Check the main filtering element of the engine air filter. Replace, if necessary
- 5 Check the clamping of the cableheads to the battery terminals
- 6 Check the air suction hose between engine and filter
- 7 Check the cylinder chromium-plated rods
- 8 Check the hydraulic lines are not worn because of rubbing against the frame or other mechanical components
- 9 Check the electric cables do not rub against the frame or other mechanical components
- 10 ▲ Check the wear of the sliding pads of the boom sections
- 11 ▲ Adjust the play of the sliding pads of the boom sections
- 12 Remove any grease from the boom, then re-grease the sliding parts of the boom sections
- 13 Check the level of the battery electrolyte



MAINTENANCE

Every 3 working months

- 1 Check the efficiency of the block valves - see [chap. D-3.16](#)

Every 500 working hours or every six months

Jobs to be done in addition to those above.

- 1 Visually check the smoke quantity evacuated from the engine exhaust
- 2 Check the tightening of the engine fixing screws
- 3 Check the tightening of the cab fixing screws
- 4 Check the backlash between pins and bushings in all joints
- 5 Change the hydraulic oil filter of the transmission
- 6 Change the hydraulic oil filter in the tank
- 7 Have the hydraulic system checked by a skilled technician
- 8 Change the main cartridge of the engine air filter

Every 1000 working hours or yearly

Jobs to be done in addition to those above

- 1 Change the safety element of engine air filter
- 2 Change the oil in the front and rear differential gears and in the power divider
- 3 Change the oil in the four wheel reduction gears
- 4 Change the hydraulic oil

Every 2000 working hours or every two years


Jobs to be done in addition to those above

- 1 Change the engine coolant

■ D-2.1 OIL CHANGE SCHEDULE

	Job	operating hours*	service interval*	Oil type
Engine	Oil level check	10	daily	SHELL RIMULA 15W-40 (API CH-4/CG-4/CF-4/CF; ACEA E3; MB228.3)
	First change	50	-	
	Subsequent changes	250	monthly	
Axles and power divider	Oil level check	250	monthly	FUCHS TITAN GEAR LS 85 W-90 API GL-5 LS / GL-5
	First change	-	-	
	Subsequent changes	1000	yearly	
Hydraulic oil	Oil level check	10	daily	SHELL TELLUS T 46 DENISON HF-1, DIN 51524 part 2 & 3
	First change	-	-	
	Subsequent changes	1000	yearly	

* whichever occurs first

**MAINTENANCE****D-3 MAINTENANCE INTERVENTIONS****DANGER**

All maintenance interventions must be carried out with engine stopped, parking brake engaged, working attachments flat on the ground and gear lever in neutral.

ATTENTION

*High pressure lines must be replaced by qualified personnel only.
Any foreign matters entering the closed circuit may result in a sudden deterioration of the transmission.*

**CAUTION**

When raising a component for maintenance purposes, secure it in a safe way before any maintenance intervention.

ATTENTION

The qualified staff charged with the maintenance of the hydraulic circuit must clean all areas around with care before any intervention.

**CAUTION**


*Any intervention on the hydraulic circuit must be carried out by skilled personnel.
The hydraulic circuit of this machine is fitted with pressure accumulators. You and others could be seriously injured if accumulators are not completely depressurised.
For this purpose, shut the engine down and step on the brake pedal 8÷10 times.*

**PROTECT THE ENVIRONMENT**

The handling and disposing of used oils can be ruled by local or national regulations. Address to authorised centres.

**CAUTION**

Before any operation on hydraulic lines or components, make sure there is no residual pressure. For this purpose, stop the engine, engage the parking brake and operate the control levers of the distributors in both working directions (alternately) to depressurise the hydraulic circuit.



MAINTENANCE

■ D-3.1 DISCONNECTING THE BATTERY

During maintenance or repair works, and while welding, turn off the battery main switch, located behind the rear right wheel compartment (C-4.4, p. C-26).



■ D-3.2 ACCESS TO THE ENGINE COMPARTMENT

For any operation within the engine compartment, open the protection bonnet.


The bonnet is equipped with pneumatic shock absorbers which unburdens and hold the bonnet in raised position. To open the bonnet:


- Shut the engine down and put the parking brake.
- Turn the key to unlock and open the bonnet.



DANGER

Take all precautions when approaching the engine compartment. Some parts of the engine may be very hot. Always use protective gloves.






MAINTENANCE

■ D-3.3 GREASING

ATTENTION

Before injecting grease into the greasers, thoroughly clean them to avoid that mud, dust or other matters can mix with the lubricant and reduce or annihilate the lubrication effect.

Remove any old grease with a degreaser from the telescopes before smearing them with new grease.





Regularly grease the machine to grant it efficient conditions and a long life.

By means of a pump, inject grease into the special greasers.

As the fresh grease comes out, stop the operation.

The greasing points are shown in the following figures:


- the symbol  represents the points to be greased by a pump
- the symbol  represents the points to be greased by a brush




SERVICE INTERVAL

Running-in _____ None

Ordinary _____ Every **10** hours





MAINTENANCE

■ **D-3.4 TYRES AND WHEELS**




Over-inflated or overheated tyres can burst. Do not flame-cut or weld the wheel rims. For any repair work, call in a qualified technician.


■ **D-3.5 BRAKES**

- For any intervention on the braking system (adjustment and/or substitution of the brake discs) address to the Genie Technical Assistance Service or the nearest Genie authorised workshop.

YES



NO



For the tyre inflation or substitution, please refer to the table below:

	Standard	Optional
Dimensions (front and rear)	405/70-20	405/70-24
P.R. (or load index)	14	14
Rim	13x20	13x24
Wheel disc	8 holes DIN 70361	
Pressure bar/Psi	5.5/80	4.5/65

On new machines, and when a wheel has been disassembled or replaced, check the nut torque of the wheels every 2 hours until they stay correct.




Always use tyres having the dimensions indicated in the vehicle registration card.

SERVICE INTERVAL

Running-in _____ **Within the first 10 hours**

Ordinary _____ **Every 250 hours**






MAINTENANCE

■ D-3.6 ENGINE AIR FILTER

Clean the engine air filter every 10 hours; replace the filtering element, if necessary.

1 Cleaning and changing the external element:

- Stop the engine and engage the parking brake.
- Unscrew wingnut **A** and remove cover **B**.
- Unscrew wingnut **C** and remove the outer element **D**.
- Clean the filter bowl.
- Clean the cartridge by beating it some times on the ground paying attention not to damage the filtering element.
Do not dry-clean the filtering element.
- Check for cracks in the filtering element by introducing a lamp inside.
- Smear the seal with grease, then refit the element.
- Tighten wingnut **C**, close cover **B** and tighten with wingnut **A**.



ATTENTION

As soon as the warning lamp 7.3 on the cab dashboard switches on, replace the outer element.

2 Changing the internal element:

- See step 1 for removing the outer element.
- Loosen wing nut **E** and remove the inner element **F**.
- Clean the filter bowl.
- Smear the seal with grease, then mount the new element and make sure it is correctly positioned.
- Refit the outer element and the cover (see step 1).

ATTENTION


The inner element should be replaced every two times the outer element is replaced

Daily remove any dust collected in the filter by pressing the rubber cap G.



SERVICE INTERVAL

Running-in	_____	None
Cleaning	_____	Every 10 hours
Outer element change	_____	Every 500 hours
Inner element change	_____	Every 1000 hours

**MAINTENANCE****■ D-3.6.1 CAB AIR FILTER**



Every six months clean the air filter in the cab. Replace the cartridge if the filtering cloth is damaged.


1 Cleaning and changing the cartridge:

- Shut the engine down and engage the parking brake.
- Pull out filter **A** located to the left of the driving place.
- Clean the filter bowl.
- Do not dry-clean the filtering cartridge.

ATTENTION

Do not, at any times, dry-clean the filters. Use some water and/or solvent.





MAINTENANCE

■ **D-3.7 ENGINE COOLING SYSTEM**





When the coolant is hot, the cooling system is under pressure. With warm engine, loosen the radiator plug slowly and carefully, without removing it, to drain the pressure. Use protection gloves and keep your face at a safe distance.

- Weekly check the coolant level within pan **A** before starting working (when coolant is cold).
- When necessary, add clean water or an antifreeze mixture through cap **B**.
- Change the antifreeze mixture every two years.

To drain the antifreeze:


- Let the engine cool down
- Unscrew the plug at the bottom of the radiator or disconnect the rubber hose, if no plug is present. Allow the coolant to flow out into a special container.
- Refit the hose and pour new antifreeze (50% water-antifreeze). This proportion will provide protection up to -38°C.
- Daily clean the radiator grille.



 **SERVICE INTERVAL**

Running-in _____ None

Ordinary _____ **Every 50 hours**



MAINTENANCE


■ D-3.8 CHECKING THE OIL LEVEL IN THE TANK



Fine jets of hydraulic oil under pressure can penetrate the skin. Do not use your fingers, but a piece of cardboard to detect oil leaks.

Check the hydraulic oil level (visually) through the special level **C** fitted into the tank.

When necessary, add new oil through filler **D**.



 **SERVICE INTERVAL**

Running-in _____ **Within the first 10 hours**

Ordinary _____ **Every 50 hours**

To change the oil:

- 1 Stop the machine on a level ground and make sure the parking brake is engaged.
- 2 Release the pressure from the hydraulic circuit.
- 3 Place a container of suitable size under the drain plug, placed in the lower part of the reservoir, and collect any oil leaks.
- 4 Remove the drain plug and allow oil to flow out into the container.
- 5 Remove the inspection cover of tank **E**.
- 6 Carefully wash the tank with Diesel oil and blow a jet of compressed air.
- 7 Refit the drain plug and the inspection cover.
- 8 Add new oil by making sure that it matches the recommended type indicated in paragraph D-5.2.2. until it is level with **C**.




The handling and disposing of used oils can be ruled by local or national regulations. Address to authorised centres

 **SERVICE INTERVAL**

Running-in _____ **None**

Ordinary _____ **Every 1000 hours**




MAINTENANCE

■ D-3.9 CHANGING THE CANISTERS OF THE OIL FILTER IN THE INJECTION LINE

■ D-3.9.1 Transmission oil filter

To change the hydraulic oil filter of the transmission, proceed as follows:

- 1 Stop the machine on a level ground and engage the parking brake.
- 2 Place a container of suitable size under the filter to collect any oil leaks, then close cock **A**.
- 3 Remove the filter canister **B** with the special wrench provided.
- 4 Renew the canister. Before fitting a new canister, thoroughly clean and grease both bowl and gasket.
- 5 Hand-tighten and re-open cock **A**.



IMPORTANT

Hydraulic oil filter canisters cannot be cleaned or washed and refitted.

They must be replaced with new ones of the type recommended by the manufacturer (see par. D-5.2.2).



SERVICE INTERVAL

Running-in _____ None

Ordinary _____ Every **500** hours

When indicator 7.2 switches on




PROTECT THE ENVIRONMENT

The handling and disposing of used oils may be ruled by local or national regulations. Address to authorised centres.

IMPORTANT

When changing the oil, drain it when it is still hot and the polluting substances are in suspension.



MAINTENANCE

■ **D-3.9.2 Auxiliary circuits oil filter**

To change the hydraulic oil filter cartridge of the service circuits, proceed as follows:

- 1 Stop the machine on a level ground and engage the parking brake.
- 2 Place a container of suitable size under the tank, then allow oil to flow out until its level is under the inspection hatch **E** (90 litres approx).
- 3 Remove the inspection hatch and unscrew the oil filter fitted inside the tank.
- 4 Check the tank is clean, then fit a new filtering element and refit the inspection hatch.
- 5 Check the oil level within the tank. Add new oil, if necessary.



 **SERVICE INTERVAL**

Running-in _____ None

Ordinary _____ **Every 1000 hours**


■ **D-3.10 OIL LEVEL IN THE DIFFERENTIAL GEARS**


To check the oil level in the front and rear differential gears:

- Stop the machine on a level ground and engage the parking brake.
- Loosen level plug **A** and check if oil is level with the hole.
- If necessary, top-up through hole **B** until oil comes out from hole **A**.
- Refit and tighten plugs **A** and **B**.

To change the oil:


- Place a container of suitable size under drain plug **C**.
- Loosen the drain plug, the level plug **A** and the filler **B** and allow oil to flow out from the reduction gear.
- Refit and tighten drain plug **C**.
- Add new oil through the filler until it is level with hole **B**.
- Refit and tighten plugs **A** and **B**.



 **SERVICE INTERVAL**

Running-in _____ **Within the first 10 hours**

Ordinary _____ **Every 250 hours**



MAINTENANCE

■ D-3.11 OIL LEVEL IN THE (front/rear) WHEEL REDUCTION GEARS

To check the oil level in the wheel reduction gears:

- Stop the machine on a level ground and ensure the parking brake is engaged and plug **A** finds on the horizontal axis.
- Clean the plug all around, then remove it and check if oil is level with the hole.
- If necessary, add new oil through hole **A** until it is level.
- Refit the plug.

To change the oil:

- Stop the machine and ensure the plug is oriented along the vertical axis.
- Place a container of suitable size under the reduction gear plug.
- Unscrew plug **A** and drain any oil from the reduction gear.
- Rotate the wheel by 90° until the plug finds again on the horizontal axis.
- Add new oil through hole **A**.
- Refit and tighten plug **A**.

■ D-3.12 OIL LEVEL IN THE POWER DIVIDER

To check the oil level in the power divider:

- Stop the machine on a level ground and make sure the parking brake is engaged.
- Clean level plug **A** all around.
- Remove the plug and check if oil is level with the hole.
- When necessary, add new oil through plug **A** until it is level with the hole.
- Refit and tighten the plug.

To change the oil:

- Place a container of suitable size under the drain plug.
- Remove the level plug **A** and the filler.
- Remove the drain plug **B** and empty the gearbox.
- Refit and tighten the drain plug **B**.
- Add new oil through the filler until it is level with hole **A**.
- Refit and tighten filler/level plug **A**.



SERVICE INTERVAL

Running-in _____ **Within the first 10 hours**



Ordinary _____ **Every 250 hours**




SERVICE INTERVAL

Running-in _____ **Within the first 10 hours**

Ordinary _____ **Every 250 hours**





MAINTENANCE



■ D-3.13 SHAFTING ALIGNMENT

During operation, the alignment of the front and rear axles of the machine can be subject to variations. This can depend on an oil blow-by from the steering control circuit, or on a steering of both axles when front and rear wheels are not perfectly aligned.

To fix this problem, rather than checking the alignment visually, follow the procedure below:

- 1) Move to a solid and level ground
- 2) Set the steering selection switch **10** to “**four-wheel steer**” (pos. **2**)
- 3) Rotate the steering up to its stop (either to the right or to the left)
- 4) Set the steering selection switch to “**two-wheel steer**” (pos. **0**)
- 5) Rotate the steering up to its stop (turn in the same direction as above)
- 6) Reset the steering selection switch to “**four-wheel steer**” (pos. **2**)
- 7) Rotate the steering (to the side opposite to point 3) so that the rear axle reaches its stop
- 8) Reset the steering selection switch to “**two-wheel steer**” (pos. **0**)
- 9) Rotate the steering (to the same side as in point 7) so that the front axle reaches its stop
- 10) Reset the steering selection switch to “**four-wheel steer**” (pos. **2**)


Now the wheels should be re-aligned.



SERVICE INTERVAL

Running-in _____ None

Ordinary _____ When necessary



MAINTENANCE


■ D-3.14 ADJUSTING THE SENSOR DISTANCE

In case of a failure or complete malfunctioning of the sensors due to a loosening of their fixing ring nuts, re-adjust their position:


- 1 Loosen nuts **A** fixing sensor **B**.
- 2 Set the mobile part **C** of the machine, controlled by the sensor, as close as possible to it.
Near the sensor to the component until the LED indicator **D** lights up.
- 3 Further near the sensor by 1÷2 mm. Smoothly tighten the sensor fixing nut and the relevant lock nut.


The machine has two different sensors:

- A** N° 1 sensor preventing any machine starting when the parking brake is not engaged
- B** N° 1 sensor disabling the use of the sway control and the outriggers when the boom is raised 2 metres above the ground



	SERVICE INTERVAL
Running-in _____	None
Ordinary _____	When necessary





MAINTENANCE



■ D-3.15 ADJUSTING THE SLIDING PADS OF THE BOOM SECTIONS

Any boom section is fitted with adjustable pads located on the four sides of the profile. These pads are secured to both fixed and mobile part of every section.

All pads can be adjusted by the special shims supplied by GENIE upon demand.

Adjusting the pads:

- Remove or loosen the screws fixing the pads in relation to type of shims used (with or without slots).
- Fit the necessary amount of shims.
- If the residual thickness of the pad is insufficient or near the maximum wearing limit, renew the pad.
- Tighten the screws fixing the pads at the recommended torque (see below). Use a dynamometric wrench.




Tightening torques of the pad screws in relation to the screw diameter

Screws M10	Nm 30
Screws M14	Nm 50

Tightening torques higher than those recommended can cause the break of the pad or of the locking threaded bush.

ATTENTION


Pads must compulsorily be replaced if the residual thickness of the plastic layer with respect to the iron bush fixing the block is equal or inferior to 1 mm.



 **SERVICE INTERVAL**

Running-in _____ **None**

Ordinary _____ **When necessary**




MAINTENANCE

■ **D-3.16 CHECKING THE SAFETY DEVICES**

■ **Checking the emergency stop button**

(before any use)

To check the efficiency of this pushbutton, simply press it down during a movement. The pressure of the pushbutton shall cause the movement to stop and the engine to shut down. Should this not be the case, contact the Genie Technical Service.



■ **Checking the joystick pushbutton** *(before any use)*

To check if the pushbutton on the control lever is in efficient working order, it will be enough to attempt to operate the lever without pressing this button. In this condition, the lever shall not operate any movement. Should that not be the case, contact the Genie Technical Service.




■ **Checking the load limiting system**


(before any use)

When power is turned on, the load limiting system runs a self-test. In the case of troubles LED's **5**, **8** and **10** start flashing, the buzzer sounds and an error message is shown on the display; the machine enters in alarm and cannot be operated.

The meaning of the error messages is shown in section **E "Faults and Troubleshooting"**.

To do a manual check, it will be enough to load a weight exceeding the maximum permissible with the boom fully out and attempt to lift it. An alarm message shall be displayed; should that not be the case, contact the Genie Technical Service.









**MAINTENANCE****■ Checking the block valves** *(every 3 months)*

The piloted blocking valves allow to held the load in position in case of burst of a flexible hose.

To check the efficiency of a valve, proceed as follows:

- Load a weight near the maximum payload (3500 kg roughly) onto the boom.
- Raise the load some centimetres above the ground (max 10 cm). To check the valve on the telescope extension cylinder move the boom to maximum height and extend it some centimetres.
- Loosen the oil hoses to the cylinder of which you are checking the valve with caution.





MAINTENANCE

- To check the efficiency of the block valves of the outriggers, lower them to the ground and unload the weight of the tyres without raising them. Loosen the cylinder hoses to check the efficiency of the valve.

During the check, the oil will flow out of the hoses and the load shall remain blocked in position.

Should that not be the case, the valve must be replaced. Contact Genie Technical Service.






Do the check of the valves taking all the possible precautionary measures:

- **Wear safety glasses**
- **Wear safety gloves**
- **Wear safety shoes**
- **Wear suitable working clothes**
- **Use guards against leaks of oil at high pressure**
- **Do the check in a free space with barriers all around to keep non-authorized people away**
- **Ensure that the part to be checked is in safe condition and that the action generated does not result in an uncontrolled movement of the machine.**

TO REMOVE THE BLOCK VALVES OR THE CYLINDERS

- **Lower the boom to the ground in a firm way since the removal of the block valve or the cylinder can cause an uncontrolled down-movement.**
- **After refitting the valve or the cylinder, replenish the circuit and eliminate any air before starting working. To eliminate the air from the circuit, move the involved cylinders to end-of-stroke in the two directions (opening/closing. To eliminate the air from the fork balance cylinder, move the boom up and down and tilt the fork plate forwards/back.**





**MAINTENANCE****■ Checking the limit switches of the outriggers**

(before any use)

To check the limit switches **L** of the outriggers:

- Lower the outriggers to the ground and attempt to engage a gear.
If the gear can be engaged, contact the Genie Technical Service.
- With the outriggers up, light **8** on the load limiter panel must be off; with the outriggers down to the ground, the same light must be on. Should it not be the case, contact the Genie Technical Service.


**■ Checking the machine start-up control**

(before any use)

Attempt to start the engine with the forward or reverse gear put.

Engine must not start. Should it not be the case, contact the Genie Technical Service.

Put first in forward gear, then in reverse gear.

**MAINTENANCE****■ Checking the proximity switches** (*before any use*)**Sensor M on the boom**



- Raise the boom beyond the horizontal and ensure the sway control and the outrigger control are blocked.
Should this not be the case, contact the Genie Technical Assistance Service.


Sensor N on the parking brake

- To check the efficiency of the parking brake micro-switch, simply sit in the driving place, start the engine and attempt to put a speed with selector **33** without engaging the brake. The machine must not move. Should this not be the case, adjust or replace the proximity sensor on the parking brake.

For the adjustment of the proximity switches, read **chap. D-3.14**

If the trouble does not depend on the sensor adjustment, contact the Genie Technical Assistance Service.





MAINTENANCE

■ D-3.17 RE-SEQUENCING THE TELESCOPIC BOOM

If, during normal operation, a change in the boom extended lengths of 150 mm or more is noticed when the boom is retracted, proceed as follows:

- 1 Fully retract the telescope cylinder and hold the system over relief (approx. 15 seconds); the boom sections should become equal.

If after performing this procedure the boom still remains out of sequence, proceed with the steps below.

- 2 Move the boom to the zero position, fully retract the boom and hold the retract system over relief for approx. 20 seconds.
- 3 Raise the boom to approx. 60° and operate the retract function over relief for approx. 20 seconds.
- 4 Lower the fully retracted boom to the lowest angle possible without striking the ground and hold the retract system over relief for approx. 20 seconds.

If, despite these procedures, the boom does not return in sequence, raise the boom to approx. 60°, fully extend and retract it to full stroke and hold the system over relief (approx. 20 seconds) in each direction.


By following these procedures the boom re-sequencing should be correct.



SERVICE INTERVAL

Running-in _____ **None**

Ordinary _____ **When necessary**



MAINTENANCE

D-4 ELECTRICAL SYSTEM



DANGER

All maintenance interventions must be carried out with engine stopped, parking brake engaged, working attachments on the ground and gearbox lever in neutral.



DANGER

When raising a component for maintenance purposes, secure it in a safe way before carrying out any maintenance.



DANGER

Before any operation on hydraulic lines or components, make sure there is no residual pressure. For this purpose, stop the engine, engage the parking brake and operate the control levers of the distributors (in both working directions alternately) to release the pressure from the hydraulic circuit.

D-4.1 BATTERY

- Check the electrolyte level every 250 working hours; if necessary, add distilled water.
- Ensure the fluid is 5÷6 mm above the plates and the cell levels are correct.
- Check the cable clips are well secured to the battery terminals. To tighten the clips, always use a box wrench, never pliers.
- Protect the terminals smearing them with pure vaseline.
- Remove the battery and store it in a dry place, when the machine is not used for a long time.



DANGER

- *Battery electrolyte contains sulphuric acid. It can burn you if it touches your skin and eyes. Always wear goggles and protective gloves, and handle the battery with caution to prevent spillage. Keep metal objects (watch straps, rings, necklaces) clear of the battery leads, since they can short the terminals and burn you.*
- *Before disconnecting the battery, set all switches within the cab to OFF.*
- *To disconnect the battery, disconnect the negative (-) lead from the frame earth first.*
- *To connect the battery, connect the positive (+) lead first.*
- *Recharge the battery far from the machine, in a well-ventilated place.*
- *Keep out of items which can produce sparks, or naked flames or lit cigarettes.*
- *Do not rest metal objects onto the battery. This can result in a dangerous short especially during a recharge.*
- *Because the electrolyte is highly corrosive, it must never come in contact with the frame of the handler or electric/electronic parts. If the electrolyte comes in contact with these parts, contact the nearest authorised assistance centre.*




DANGER

Risk of explosion or shorts. During the recharge, an explosive mixture with release of hydrogen gas forms.



DANGER

Do not add sulphuric acid




MAINTENANCE


D-4.2 FUSES AND RELAYS

The electrical system is protected by fuses placed in the driving cab, on the left. Before replacing a blown fuse with a new one having the same amperage, find out and rectify the fault.

Fuses

Ref.	Amp.	Circuit
F1	10	Power supply: light switch and front wiper/washer motor
F2	15	A/C system and heater switch
F3	5	Stop light switch
F4	7.5	Power supply: rear wiper/washer motor
F5	10	Steer selector
F6	15	Right low beam
F7	3	Front right, rear right, front left position light; position light indicator
F8	3	Rear left position light, instrument backlight
F9	7.5	Power supply: instruments and warning lights
F10	7.5	Hazard warning lights
F11	7.5	Beacon power supply
F12	10	Blank for optional accessories
F13	10	Extension jib and winch line switch (optional)
F14	10	Power supply: K9, K5, K6 relays, speed selector, K24 relay pickup
F15	10	High beam indicator, right/left high beam
F16	15	Hazard warning light switch
F17	10	Position light and signal function switch
F18	10	Outrigger down limit switch
F19	10	Hydraulic operation switch
F20	10	Power supply: relay K13
F21	15	Horn
F22	15	Blank for optional accessories
F23	10	Cab ceiling fixture
F24	10	Power supply: mushroom-head emergency stop button
F25	10	Power supply: load limiting system cutout switch
F26	10	Power supply: K14 relay
F27	10	Blank for optional accessories






MAINTENANCE


■ **Engine compartment fuses and relays**

Ref.	Amp.	Circuit
F30	50	Fuse
F31	50	Fuse
F32	15	Fuse
F33	50	Fuse
R25	70	Relay
R26	70	Relay
R27	40	Relay




■ **Relays**

Ref.	Circuit
K1	High beam indicator
K2	Right high beam
K3	Horn
K4	blank
K5	blank
K6	blank
K7	Forward speed solenoid valve
K8	Reverse speed solenoid valve
K9	K7, K8 relay power supply enabling cmd
K10	K7, K8 relay power supply enabling cmd
K11	Engine start-up enabling cmd with gear in neutral
K12	blank
K13	blank
K14	blank
K15	blank
K16	blank
K17	blank
K18	Outrigger and sway function cutout
K19	Control block sensor power supply
K20	blank
K21	DFE solenoid valve power supply
K22	blank
K23	Turn signal flashing
K24	blank



ATTENTION

- **Do not use fuses having a higher amperage than that recommended, since they can damage the electric system seriously.**
- **If the fuse blows after a short time, look for the fault source by checking the electric system.**
- **Always keep some spare fuses for an emergency.**
- **Never try to repair or short blown fuses.**
- **Make sure the contacts of fuses and fuse-sockets ensure a good electric connection and are not oxidised.**



MAINTENANCE

■ **D-4.3 12V DC LAMPS**


Use	Voltage	Mount type	Power
• Front low/high beam	12 V	P45t	45/40 W
• Front position lights	12 V	BA 9s	3 W
• Side/tail turn signals	12 V	BA 15s	21 W
• Stop lights and rear position lights	12 V	BAY 15d	21/5 W
• Beacon - Work lights (OPTIONAL)	12 V	H3	55 W
• Dashboard indicators and cab lighting	12 V	W 2x4,6d	1,2 W
• Interior lamp	12 V	SV 8,5-8	5 W
• License plate lights	12 V	BA 15s	5 W
• Back-up lamps	12 V	BA 15s	21W



When switched on, lamps get hot. Before touching a lamp with your fingers, let it cool down.



Never touch the bulb of halogen lamps (mount type H3) with your fingers: this may damage the lamp (use of a clean cloth or a paper tissue). If you touch it accidentally, thoroughly clean with a paper tissue and some ethyl alcohol.



MAINTENANCE

■ D-5 REFUELLING

■ D-5.1 REFUELLING

<i>Part</i>	<i>Product</i>	<i>Capacity (litres)</i>	<i>Product specifications see par.</i>
Diesel engine	Engine oil	11.5	D-5.2.1
Engine cooling system	Water+antifreeze	15	D-5.2.5
Fuel tank	Diesel fuel	135	D-5.2.3
Hydraulic system tank	Hydraulic oil	150	D-5.2.2
Gearbox	Oil	1.5	D-5.2.2
Differential gears	Oil	8,7	D-5.2.2
Wheel reduction gears	Oil	0,75	D-5.2.2

■ D-5.2 PRODUCT SPECIFICATIONS

■ D-5.2.1 Engine oil

Use the oil recommended by the Diesel engine Manufacturer (*see the relevant handbook delivered with the machine*).

At the delivery, the machine is refilled with:

SHELL RIMULA SAE 15W-40 (API CH-4/ CG-4/ CF-4/CF, ACEA E3, MB 228.3)

■ D-5.2.2 Lubrication oils and relevant filtering elements

Refill the machine with following lubricants:

<i>Use</i>	<i>Product</i>	<i>Definition</i>
Power divider-Differential gears-Reduction gears	FUCHS TITAN GEAR LS 85 W-90	API GL-5 LS / GL-5
Hydraulic system and brakes	SHELL TELLUS T 46	DENISON HF-1 DIN 51524 part. 2 e 3

ATTENTION


Never mix different oils: this may result in troubles and component breaks.

Oils for hydraulic system:

Arctic climates: Temperatures below -10°C	Use SHELL Tellus T22
Mild climates: Temperatures from -15°C to + 45°C	Use SHELL Tellus T46
Tropical climates: Temperatures above + 30°C	Use SHELL Tellus T68

The machine is fitted with the following filtering elements:

<i>Filter</i>	<i>Flow rate l/1'</i>	<i>Filtering</i>	<i>Coupling</i>
Transmission oil filter	150	10 µ	1"1/4 BSP
Auxiliary circuit oil filter (inside the tank)	100	60 µ	2" NPT



MAINTENANCE

■ D-5.2.3 Fuel

Use only Diesel fuel with less than 0.5% sulphur content, according to the specifications of the diesel engine operation handbook.

ATTENTION

In cold climates (temperature under -20 °C) use only "Arctic" type Diesel fuel, or oil-diesel fuel, or oil-diesel fuel mixtures. The composition of the latter can vary in relation to the ambient temperature up to max. 80% oil.

■ D-5.2.4 Grease

For the machine greasing, use:

- **Lithium-based** When greasing by pump.
Vanguard LIKO type
EP2 grease

- **Graphitized SHELL** When greasing by brush.
grease, type GR NG 3

- **Grease INTERFLON** For the telescopic boom
FIN GREASE LS 2 sliding blocks

ATTENTION

Avoid mixing greases of different type or features and do not use greases of lower quality.

■ D-5.2.5 Engine coolant

It is advisable to use an antifreeze mixture (50% water-50% antifreeze). At the delivery, the machine is refilled with:


TEREX PRO COOL by VALVOLINE

The use of this product guarantees protection of the circuit for 3 years or 7000 hours without any need to add a dry coolant additive.

TEREX PRO COOL Boiling/freezing protection		
Product %	Freezing point	Boiling point
33	-17 °C	123 °C
40	-24 °C	126 °C
50	-36 °C	128 °C
70	-67 °C	135 °C

ATTENTION

Use an antifreeze mixture in the proportions recommended by the manufacturer in relation to the ambient temperature of the jobsite.




FAULTS AND TROUBLESHOOTING

Section E

**FAULTS AND
TROUBLESHOOTING**

TABLE OF CONTENTS

E-6	FAULTS AND TROUBLESHOOTING	E-2
E-6.1	Faults - Causes - Solutions	E-2



FAULTS AND TROUBLESHOOTING

E-6 FAULTS AND TROUBLESHOOTING

This chapter represents a practical guide for the operator for fixing the most common failures and, at the same time, detecting those interventions that must be carried out by qualified technical engineers.


If you are unsure about anything, do not carry out operations on the machine, but call in a skilled technician.



Any repair work, maintenance or troubleshooting must be carried out with machine stopped, boom in rest position or laid on the ground, parking brake engaged and ignition key removed.


E-6.1 Faults - Causes - Solutions

FAULT	CAUSES	SOLUTIONS
<p>THE DASHBOARD DOES NOT TURN ON</p>	<ul style="list-style-type: none"> • Battery disconnected • Battery down • Fuse blown (F26 - 50 A) 	<ul style="list-style-type: none"> • Connect the battery using the relevant switch • Recharge or replace the battery • Check the main fuse in the engine compartment and replace if necessary
<p>THE ENGINE DOES NOT START <i>The starter does not run</i></p>	<ul style="list-style-type: none"> • Forward/reverse gear selector not in neutral position • Battery down • Battery cut-out switch ON 	<ul style="list-style-type: none"> • Set the switch to 0 • Recharge or replace the battery • Connect the battery
<p>THE ENGINE DOES NOT START <i>The starter runs, but the engine does not start</i></p>	<ul style="list-style-type: none"> • Fuse blown (F56) • No fuel • Fuel filter clogged • Fuel hose empty (fuel used up) 	<ul style="list-style-type: none"> • Check the fuse and replace if necessary • Refuel • See Perkins operator handbook • Refuel, then refer to Perkins operator handbook
<p>THE MACHINE DOES NOT MOVE</p>	<ul style="list-style-type: none"> • Changeover switch in neutral • Parking brake engaged • Fuse blown (F14) • Outrigger limit switch activated • Drive system pump defective 	<ul style="list-style-type: none"> • Set the gear switch to correct position • Disengage • Check the fuse and replace if necessary • Check the efficiency of the outrigger limit switches and replace if necessary • Check the efficiency of the control spools and replace if necessary




FAULTS AND TROUBLESHOOTING

FAULT	CAUSES	SOLUTIONS
THE MACHINE DRIVE IS NOT ENOUGH	<ul style="list-style-type: none"> Hydraulic oil filter clogged 	<ul style="list-style-type: none"> Replace the filter
THE LOAD LIMITING SYSTEM DOES NOT CHANGE WORK SCALE	<ul style="list-style-type: none"> Outrigger limit switches defective 	<ul style="list-style-type: none"> Check the efficiency of the outrigger limit switches and replace if necessary
NO SELECTION OF THE STEERING MODE	<ul style="list-style-type: none"> “ROAD/JOBSITE” switch set to “ROAD” Fuse blown (F5 - 10 A) 	<ul style="list-style-type: none"> Switch to “JOBSITE” Check the fuse and replace if necessary
LOW PARKING BRAKE ACTION	<ul style="list-style-type: none"> Insufficient cable tensioning. 	<ul style="list-style-type: none"> Check and adjust the cable tension by means of the hollow screws Check and adjust the lead tightening on the cable heads
NO BOOM LOWERING AND EXTENSION, NO HOLDING FRAME PITCHING	<ul style="list-style-type: none"> Fuse blown (F25 - 10 A) 	<ul style="list-style-type: none"> Check the fuse and replace if necessary
THE LOAD LIMITING SYSTEM IS BLOCKED (red LED's ON)	<ul style="list-style-type: none"> Low stability condition 	<ul style="list-style-type: none"> Retract the load within safety limits If the error message is still shown, retract the boom to rest condition using the cutout key of the load limiting system and address to your nearest authorised workshop.
THE HYDRAULIC OIL THERMOMETER DOES NOT WORK	<ul style="list-style-type: none"> This is normal, when the outside temperature is low and/or the machine is used for short periods, since the hydraulic oil cannot warm up over 40÷50°C Fuse blown (F9 - 7,5 A) 	<ul style="list-style-type: none"> Check the fuse and replace if necessary
THE BOOM DOES NOT MOVE	<ul style="list-style-type: none"> Fuse blown (F19 - 10 A) “ROAD/JOBSITE” switch set to “ROAD” 	<ul style="list-style-type: none"> Check the fuse and replace if necessary Switch to “JOBSITE”



FAULTS AND TROUBLESHOOTING

FAULT	CAUSES	SOLUTIONS
<p>CHECKING THE MICRO-SWITCHES WHEN THE DLE IS IN ALARM, THE BOOM IN/OUT MOVEMENTS, THE OUTRIGGER UP-MOVEMENT AND THE MACHINE SWAY FUNCTION REMAIN ACTIVATED</p>	<ul style="list-style-type: none"> • Check that the connectors are correctly plugged in the actuator 	<ul style="list-style-type: none"> • If the connectors are plugged in correctly, contact the GENIE Technical Assistance.
<p>CHECKING THE MICRO-SWITCHES WITH THE BOOM RAISED 2 METRES ABOVE THE GROUND THE OUTRIGGER UP-MOVEMENT AND THE MACHINE SWAY FUNCTION REMAIN ACTIVATED</p>	<ul style="list-style-type: none"> • Check that the connectors are correctly plugged in the actuator 	<ul style="list-style-type: none"> • If the connectors are plugged in correctly, contact the GENIE Technical Assistance.
<p>THE DLE LOAD LIMITING SYSTEM IS IN ALARM</p>	<ul style="list-style-type: none"> • Fuse blown (F25 - 10 A) • System fault 	<ul style="list-style-type: none"> • Check the fuse and replace if necessary.
<p>ALARM MESSAGES OF THE DLE LOAD LIMITING SYSTEM SHOWN ON THE DISPLAY</p>	<ol style="list-style-type: none"> 1 E2PROM error 2 Value read from CELL 1 higher than the maximum permissible 3 Value read from CELL 2 higher than the maximum permissible 	<ul style="list-style-type: none"> • Turn power off and on and RESET the system. If the error message is still shown, contact GENIE to re-calibrate the unit. • Check the wiring between control panel and load cell • Check that the load cell is fixed correctly • Check the connecting cable or the connectors is/are not shorted • If the error message is still shown, contact the GENIE Service Centre and have the load cell be checked. • Check the wiring between control panel and load cell • Check that the load cell is fixed correctly • Check the connecting cable or the connectors is/are not shorted • If the error message is still shown, contact the GENIE Service Centre and have the load cell be checked.




FAULTS AND TROUBLESHOOTING

FAULT	CAUSES	SOLUTIONS
<p>ALARM MESSAGES OF THE DLE LOAD LIMITING SYSTEM SHOWN ON THE DISPLAY</p>	<p>4 Block relay error during operation</p>	<ul style="list-style-type: none"> • Check the efficiency of relay and wiring • Stop and restart the machine and run a complete test to check the outputs. If the error message is still shown, contact the GENIE service centre to replace the DLE unit.
	<p>5-6-7-8 Block relay error when power is turned on</p>	<ul style="list-style-type: none"> • Check the efficiency of relay and wiring • Stop and restart the machine and run a new test. If the error message is still shown, contact the GENIE service centre to replace the DLE unit.
	<p>9 CELL 1 and CELL 2 reading incongruence. The values read from the two cells are different.</p>	<ul style="list-style-type: none"> • Check that the cells are intact and fixed correctly. If the error message is still shown, contact the GENIE service centre to replace the load cell and re-calibrate the unit.
	<p>A Data error in RAM</p>	<ul style="list-style-type: none"> • Stop and restart the machine. If the error message is still shown, contact the GENIE service centre.
	<p>B Outrigger incongruence</p>	<ul style="list-style-type: none"> • An input is not read. Check the wiring, the power cord and the connector of the DLE. If the alarm persists, contact the GENIE service centre.
		<p>C Error during check of A.D.C. reading</p> <ul style="list-style-type: none"> • Stop and restart the machine. If the error message is still shown, contact the GENIE service centre.

ATTENTION

In case of faults not listed in this chapter, address to the GENIE Technical Service, your nearest authorised workshop or dealer.




OPTIONAL ATTACHMENTS

Section F

OPTIONAL ATTACHMENTS

TABLE OF CONTENTS

F-1.1	Shovel	F-3
F-1.2	Concrete skip	F-4
F-1.3	Mixing bucket	F-5
F-1.4	Fixed hook on plate	F-6
F-1.5	Hydraulic winch	F-7
F-1.6	Extension jib	F-7
F-1.7	Forks with hydraulic side-shift	F-8



OPTIONAL ATTACHMENTS

INTRODUCTION

This section provides information on the optional interchangeable attachments, especially manufactured for the handlers.

Use only genuine attachments, described in this section, after having read their features thoroughly and understood their use.

To install and remove the attachments, follow the instructions supplied in the "OPERATION" section, par. C-5.4.



DANGER

When replacing interchangeable attachments, keep any person clear of the working area.





DANGER


Mounting optional attachments, and especially the extension jib, can change the centre of gravity of the machine. Before handling a load, check its weight and compare it with the values on the load charts. The weight of the used attachment must always be deducted from the rated payload.

■ Procedure to connect hydraulic lines:

- Couple the new attachment
- Disconnect the quick couplings **A** of the attachment locking cylinder and connect them to the false connectors **B** to prevent them from getting dirty.
- Connect the feeding hoses of the new attachment to the quick couplings previously set free.

When the new attachment has two hydraulic motions like, for instance, the pole and pipe planter, a flow selecting valve **C** shall be installed on the machine or the attachment and operated from the cab by means of switch **35**.






OPTIONAL ATTACHMENTS

■ F-1.1 SHOVEL

Code	GTH-3713
Litres 800	59.0400.2000



Application

Quick-coupling fitted attachment for moving soil, sand, debris, cereals, etc.

Safety

Strictly obey the general safety precautions given in section **B** "SAFETY".

Operation

ATTENTION

When using a shovel, load the material only when the boom is completely retracted and push against the heap with straight wheels.

To load/unload the material, operate the rotation lever of the attachment holding plate.

Maintenance

Visually check the shovel for damage before using it.

Technical data


	Litres	800
Width	mm	2250
Length	mm	1000
Height	mm	940
Weight	kg	380
SAE capacity	m ³	0,8

Application

Litres	GTH-3713
800	•

ATTENTION


Attachment suitable for moving loose material. Do not use for digging operations.



OPTIONAL ATTACHMENTS

■ **F-1.2 CONCRETE SKIP**

Code	Man. unloading	Hydr. unloading
Litres 500	59.0400.0000	59.0400.1000
Litres 800	59.0400.2000	59.0400.3000



Application

Attachment coupled to the standard forks of the handler and fixed by the special chains with shackles provided.

Safety

Strictly obey the general safety precautions given in section **B** "SAFETY".

Operation

Fork the skip taking into account the product unloading side.

Fix the skip to the forks with the special chains provided.

To unload the concrete, manually operate the gate opening lever if the skip opening is done by hand.

If the skip is equipped with hydraulic cylinder for the gate opening, operate the attachment locking lever after connecting the feeding lines of the new attachment to the quick couplings (see page F-2).

Maintenance

Visually check the skip for damage before using it. Wash with water after use or in case of prolonged inactivity to prevent the mix or residues from hardening. Check for oil leaks from hoses and connectors. Carefully protect the quick connectors once disconnected to prevent impurities from entering the circuit.


At every use, check the condition of the fixing chains; replace if they are worn or deformed.


Technical data

	Litres	500	800
Width	mm	1200	1200
Length	mm	1200	1200
Height	mm	1270	1520
Weight	kg	220	260
SAE capacity	m ³	0,5	0,8

Application

Litres	GTH-3713
500	•
800	•






OPTIONAL ATTACHMENTS

■ **F-1.3 MIXING BUCKET**

Code	GTH-3713
Litres 500	59.0400.5000



Application

Quick-coupling fitted attachment for mixing and distributing concrete.

Safety

Strictly obey the general safety precautions given in section **B** "SAFETY".

Operation

To load/unload the material, operate the rotation lever of the attachment holding plate.

To start the mixing auger, operate the attachment locking lever after connecting the feeding lines of the new attachment to the quick couplings (see page F-2).

Maintenance



Before any maintenance, rest the bucket on the ground, stop the machine, remove the starter key and lock the cab door to prevent anybody from gaining access to the control panel.

Visually check the bucket for damage before using it. Wash thoroughly with water after use or in case of prolonged inactivity to prevent the mix or residues from hardening.


Check for oil leaks from hoses and connectors. Carefully protect the quick connectors once disconnected to prevent impurities from entering the circuit.

Technical data

	Litres	500
Width	mm	1850
Length	mm	900
Height	mm	1000
Weight	kg	340
SAE capacity	m ³	0,35

Application


Litres	GTH-3713
500	•



OPTIONAL ATTACHMENTS

■ F-1.4 FIXED HOOK ON PLATE

Code	GTH-3713
3700 kg	59.0700.8000



Application

Quick-coupling fitted attachment for lifting loads by means of special slings.

Safety

Strictly obey the general safety precautions given in section **B** "SAFETY".

Do not oscillate the load.

Do not drag hooked loads.

Lift the load before extending the boom.

Operation

Fork the hook and hold it in position by means of the locking cylinder.

All loads must be bridled with special textile slings or chains in compliance with all pertinent regulations.

To handle the load, raise and rotate the telescopic boom of the handler.

Maintenance

Visually check the hook for damage before using it.

Check the safety catch is in good working order.

Technical data

	kg	4000
Width	mm	600
Length	mm	300
Height	mm	400
Weight	kg	50


Application

kg	GTH-3713
3700	•

IMPORTANT

Make sure this attachment can be used in the destination country of the machine. In Italy, this attachment must be enrolled at ISPESL and submitted to yearly test.


Application must be submitted directly by the user.



OPTIONAL ATTACHMENTS

■ **F-1.5 HYDRAULIC WINCH**

Code	GTH-3713
3700 kg	59.0900.8000




Technical data

	kg	3000
Width	mm	960
Length	mm	880
Height	mm	1650
Weight	kg	280

For the use of this attachment, read the specific manual supplied - code: 57.0300.9200

■ **F-1.6 EXTENSION JIB**



Code	mechanical	hydraulic
GTH-3713		

Technical data

Length		4000
Width	mm	970
Height	mm	600
Weight	kg	360
Payload	kg	900


For the use of this attachment, read the specific manual supplied - code: 57.0300.9200

IMPORTANT

Make sure this attachment can be used in the destination country of the machine. In Italy, this attachment must be enrolled at ISPESL and submitted to yearly test. Application must be submitted directly by the user.


IMPORTANT

Make sure this attachment can be used in the destination country of the machine. In Italy, this attachment must be enrolled at ISPESL and submitted to yearly test. Application must be submitted directly by the user.



OPTIONAL ATTACHMENTS

■ **F-1.7 FORKS WITH HYDRAULIC SIDE-SHIFT**



Application

Quick-coupling fitted attachment for handling palletised loads.

Safety

Strictly obey the general safety precautions given in section **B** "SAFETY".

- Do not load loose materials
- Do not move stacked pallets

Operation

To adjust the tilting, operate the rotation lever of the attachment holding plate.
To side-shift, operate the attachment locking lever after connecting the feeding lines of the new attachment to the quick couplings (see page F-2).

Maintenance

Visually check the attachment for damage before using it.
Check for hydraulic oil leaks.
Daily grease the joints using a greasing gun, and smear the sliding guides with graphitized grease.


Code	
GTH-3713	59.0600.1000

Technical data

Payload kg		3700
Width	mm	1400
Length	mm	1600
Height (with protection)	mm	1140
Weight	kg	180
Stroke	mm	± 150
Fork attachments		FEM 3

Application

Payload kg	GTH-3713
3700	•




TABLES AND DOCUMENTS ENCLOSED

Section G

TABLES AND DOCUMENTS ENCLOSED

TABLE OF CONTENTS


G-1	Tightening torques	G-2
G-2.1	Load Chart with forks - machine with outriggers	G-4
G-2.2	Load Chart with forks - machine without outriggers - with chassis levelling	G-5
G-3.1.1	Load limiting system wiring diagram - external connections	G-6
G-3.1.2	Load limiting system wiring diagram - internal connections	G-7
G-3.2	Wiring diagram - Fuses and relays	G-8
G-3.3.1	Wiring diagram 1/10	G-10
G-3.3.2	Wiring diagram 2/10	G-11
G-3.3.3	Wiring diagram 3/10	G-12
G-3.3.4	Wiring diagram 4/10	G-13
G-3.3.5	Wiring diagram 5/10	G-14
G-3.3.6	Wiring diagram 6/10	G-15
G-3.3.7	Wiring diagram 7/10	G-16
G-3.3.8	Wiring diagram 8/10	G-17
G-3.3.9	Wiring diagram 9/10	G-18
G-3.3.10	Wiring diagram - Description of the parts	G-19
G-4.1	GTH-3713 hydraulic scheme (up to serial no. 14845)	G-21
G-4.2	GTH-3713 hydraulic scheme (from serial no. 14846)	G-22
G-4.3	Description of the hydraulic components - GTH-3713	G-23
G-5	Routine check schedule-Safety devices	G-24


TABLES AND DOCUMENTS ENCLOSED
G-1 TIGHTENING TORQUES

D x p	Pre-loading (N)				Tightening torque (Nm)			
	4.8	8.8	10.9	12.9	4.8	8.8	10.9	12.9
M 4 x 0,7	1970	3930	5530	6640	1,5	3,1	4,3	5,2
M 5 x 0,8	3180	6360	8950	10700	3	6	8,5	10,1
M 6 x 1	4500	9000	12700	15200	5,2	10,4	14,6	17,5
M 8 x 1,25	8200	16400	23100	27700	12,3	24,6	34,7	41,6
M 8 x 1	8780	17600	24700	29600	13	26	36,6	43,9
M 10 x 1,5	13000	26000	36500	43900	25,1	50,1	70,5	84,6
M 10 x 1,25	13700	27400	38500	46300	26,2	52,4	73,6	88,4
M 12 x 1,75	18900	37800	53000	63700	42,4	84,8	119	143
M 12 x 1,25	20600	41300	58000	69600	45,3	90,6	127	153
M 14 x 2	25800	51500	72500	86900	67,4	135	190	228
M 14 x 1,5	28000	56000	78800	94500	71,7	143	202	242
M 16 x 2	35200	70300	98900	119000	102	205	288	346
M 16 x 1,5	37400	74800	105000	126000	107	214	302	362
M 18 x 2,5	43000	86000	121000	145000	142	283	398	478
M 18 x 1,5	48400	96800	136000	163000	154	308	434	520
M 20 x 2,5	54900	110000	154000	185000	200	400	562	674
M 20 x 1,5	60900	122000	171000	206000	216	431	607	728
M 22 x 2,5	67900	136000	191000	229000	266	532	748	897
M 22 x 1,5	74600	149000	210000	252000	286	571	803	964
M 24 x 3	79100	158000	222000	267000	345	691	971	1170
M 24 x 2	86000	172000	242000	290000	365	731	1030	1230
M 27 x 3	103000	206000	289000	347000	505	1010	1420	1700
M 27 x 2	111000	222000	312000	375000	534	1070	1500	1800
M 30 x 3,5	126000	251000	353000	424000	686	1370	1930	2310
M 30 x 2	139000	278000	391000	469000	738	1480	2080	2490


IMPORTANT

Sensor maximum driving torque: 15 Nm.




TABLES AND DOCUMENTS ENCLOSED


Page left intentionally blank



TABLES AND DOCUMENTS ENCLOSED


G-2.1 LOAD CHART WITH FORKS - WITH OUTRIGGERS






TABLES AND DOCUMENTS ENCLOSED


■ G-2.2 LOAD CHART WITH FORKS - WITHOUT OUTRIGGERS - WITH CHASSIS LEVELLING






TABLES AND DOCUMENTS ENCLOSED


■ G-3.1.1 LOAD LIMITING SYSTEM WIRING DIAGRAM - EXTERNAL CONNECTIONS






TABLES AND DOCUMENTS ENCLOSED

G-3.1.2. LOAD LIMITING SYSTEM WIRING DIAGRAM - INTERNAL CONNECTIONS





X2	COLOUR	SIGNAL
1	BROWN	+VB
2	WHITE	-VB
3	GREEN	CUTOFF
4	YELLOW	OUTRIGGERS
5	PINK	SPARE
6	YELLOW	SPARE
7	PINK	SPARE
8	RED	SPARE


CONN. INR.	DESCRIPTION	CODE
X1	AMP CONNECTOR 23 C. FEMALE	MV 770680-1
X2	DEUTSCH CONNECTOR	
X3A	SUPER SEAL MALE	MV 282107-1
X3B	SUPER SEAL FEMALE	MV 282089-1



TABLES AND DOCUMENTS ENCLOSED


G-3.2 WIRING DIAGRAM - FUSES AND RELAYS






TABLES AND DOCUMENTS ENCLOSED


Ref.	Description
1	12V flashing
2	Printed circuit
3	Relay card support
4	1N 4007 diodes, black
5	3 A 1N5408 diodes
6	Power terminal M6
7	Power terminal M5
8	Board relay micro-switch connector
9	Board fuse-box connector
10	Board fuse-box connector
11	5-way MARK II connector - boards
12	11-way MARK II connector - boards
13	13-way MARK.II connector - boards
14	13-way MARK.II connector - light blue
15	13-way MARK.II connector - red
16	13-way MARK.II connector - green
17	9-way MARK II connector - boards
18	17-way MARK II connector - boards
19	17-way MARK II connector - yellow
20	Micro-switch relay with 12V diode
21	7.5A knife-blade fuse
22	15A knife-blade fuse
23	10A knife-blade fuse
24	3A knife-blade fuse
25	5A 257005 knife-blade fuse
26	Washer \varnothing .3x8.9x1.2 UNI1751 Stainless steel
27	Washer \varnothing 6.4x11.3x1.6 UNI1751 Stainless steel
28	Nut M5 UNI 5588-65 Stainless steel
29	Nut M6 UNI 5588 Stainless steel
30	Nut M4 UNI 7473 Stainless steel
31	Washer 3.5x13.6x2 Certene
32	Washer 4.4x10x1.1 Nylon
33	Vibration-proof pad M4x10 Stainless steel



TABLES AND DOCUMENTS ENCLOSED


G-3.3.1 WIRING DIAGRAM 1/10






TABLES AND DOCUMENTS ENCLOSED


G-3.3.2 WIRING DIAGRAM 2/10






TABLES AND DOCUMENTS ENCLOSED


■ G-3.3.3 WIRING DIAGRAM 3/10






TABLES AND DOCUMENTS ENCLOSED


G-3.3.4 WIRING DIAGRAM 4/10






TABLES AND DOCUMENTS ENCLOSED


G-3.3.5 WIRING DIAGRAM 5/10






TABLES AND DOCUMENTS ENCLOSED


■ G-3.3.6 WIRING DIAGRAM 6/10






TABLES AND DOCUMENTS ENCLOSED


G-3.3.7 WIRING DIAGRAM 7/10






TABLES AND DOCUMENTS ENCLOSED


■ G-3.3.8 WIRING DIAGRAM 8/10






TABLES AND DOCUMENTS ENCLOSED

G-3.3.9 WIRING DIAGRAM 9/10






TABLES AND DOCUMENTS ENCLOSED

■ G-3.3.10 WIRING DIAGRAM - Component description

<i>Ref</i>	<i>Description</i>	<i>Sheet</i>	<i>Ref</i>	<i>Description</i>	<i>Sheet</i>
A1	ALTERNATOR	1	H24	LICENCE PLATE LIGHT	4
B1	BATTERY	1	H25	BACK-UP HORN	3
B11	PRESSURE SWITCH - ENGINE OIL FILTER	1	H26	REAR RIGHT LIGHT	4
B12	FUEL GAUGE	4	K01	RELAY - START-UP	1
B12A	FUEL RESERVE	4	K02	RELAY - PRE-HEATING	1
B13	THERMOSTAT - HIGH ENGINE WATER TEMPERATURE	1	K03	RELAY - ENGINE STOP	1
B14	THERMOMETER - HIGH ENGINE WATER TEMPERATURE	1	K1	RELAY - HIGH BEAM	4
B15	MICRO-SWITCH - AIR FILTER CLOGGED	1	K10	RELAY - TRANSMISSION DISCONNECTED	3
B16	THERMOMETER - HIGH HYDRAULIC OIL TEMPERATURE	4	K11	RELAY - START-UP ENABLING COMMAND	1
B38	BOOM LIFTING SENSOR	7	K14	RELAY - DEADMAN	8
B54	SWITCH - SPEED NOT ENGAGED	6	K18	RELAY - LOW BOOM SENSOR	7
F1	FUSE - HAZARD WARNING LIGHTS 10A	5	K19	RELAY - OVERLOAD WARNING SYSTEM	10
F10	FUSE - LIGHTS SWITCH 7.5A	4	K2	RELAY - LOW BEAM	4
F11	FUSE - BEACON 7.5A	6	K21	RELAY - D.F.E.	10
F12	FUSE - WORK LIGHTS 10A	4	K23	INTERMITTENCE	5
F13	FUSE - WALVOIL CONTROL UNIT 10A	10	K3	RELAY - HORN	4
F14	FUSE - SPEED SWITCH 10A	3	K4	RELAY - OPTIONAL	4
F15	FUSE - HIGH BEAM 10A	4	K7	RELAY - FORWARD SPEED	3
F16	FUSE - EMERGENCY 15A	5	K8	RELAY - REVERSE SPEED	3
F17	FUSE - LIGHTS AND FLASHING 0A	4	K9	RELAY - TRANSMISSION DISCONNECTED	3
F18	FUSE - OUTRIGGERS 10A	7	M1	STARTING MOTOR	1
F19	FUSE - WORK MODE SELECTOR 10A	8	M13	WINDSCREEN WIPER/WASHER MOTOR	5
F1G	MAIN FUSE 50A	1	M3	REAR WINDSCREEN WIPER/WASHER	6
F2	FUSE - HEATING 15A	6	M5	HEATING FAN	6
F20	FUSE - PLATFORM EMERGENCY BUTTON 10A	2	M18	A/C SYSTEM	6
F21	FUSE - HORN 15A	4	M91	PUMP MOTOR	5
F22	FUSE - OPTIONAL 15A	1	P1	ENGINE WATER THERMOSTAT	1
F23	FUSE - CAB LIGHTS 10A	6	P2	HYDRAULIC OIL TEMPERATURE	4
F24	FUSE - EMERGENCY STOP 10A	2	P3	FUEL GAUGE	4
F25	FUSE - 3B6 CONTROL UNIT 10A	10	P4	HOUR-METER	1
F26	FUSE - OPTIONAL 10A	8	R0	GLOW PLUGS	1
F27	FUSE - OPTIONAL 10A	5	S0	COLD STARTING TEMPERATURE SENSOR	1
F2G	MAIN FUSE 50A	1	S01	START-UP PANEL	1
F3	FUSE - STOP LIGHT MICRO-SWITCH 5A	4	S10	OVERLOAD CUTOFF	10
F3G	MAIN FUSE 0A	1	SX12	SPEED SWITCH	3
F4	FUSE - REAR WIPER 7.5A	6	SX11	SWITCH - LIGHTS -WIPERS-HORN	5
F5	FUSE - HYDRAULIC ACTIVATION 10A	8	S6A	PARKING BRAKE MICRO-SWITCH	7
F5G	MAIN FUSE 15A	1	S6B	PARKING BRAKE MICRO-SWITCH	7
F6	FUSE - LOW BEAM 15A	4	S13	EMERGENCY MUSHROOM-HEAD PUSHBUTTON	2
F7	FUSE - RIGHT POSITION LIGHTS 3A	4	S14	SWITCH - MECHANICAL GEARBOX	3
F8	FUSE - INSTRUMENT LIGHTING 3A	4	S16	SWITCH - HAZARD WARNING LIGHT	5
F9	FUSE - INDICATOR LIGHTS POWER SUPPLY 7.5A	6	S17	SWITCH - EMERGENCY PUMP	2
H20	HORN	4	S18	SWITCH - BACK-UP LAMP	4
H21	FRONT LEFT LIGHT	4	S19	SWITCH - LIGHTS	4
H22	FRONT RIGHT LIGHT	4	S2	SWITCH - HYDRAULIC ACTIVATION	8
H23	REAR LEFT LIGHT	4	S20	SWITCH - HEATER	6
			S21	BATTERY CUTOFF	1
			S1	SWITCH - OPT. AIR CONDITIONER	6
			S22	SWITCH - STEERING	8




TABLES AND DOCUMENTS ENCLOSED

Ref	Description	Sheet	Ref	Description	Sheet
S3	SWITCH - JIB	9	XP3	6-WAY CONNECTOR	
S30	HYDROSTOP	4	XV1	3-WAY CONNECTOR	
S4	START-UP PANEL	8	Y53	SOLENOID VALVE - REAR AXLE LOCKING (OPT.)	10
S53	MOVEMENT SIGNAL	3	Y54	SOLENOID VALVE - REAR AXLE UNLOCKING (OPT.)	10
S7	SWITCH - A/C SYSTEM	6	R1	LOAD RESISTANCE	1
SX12	SWITCH - SPEEDS	3	B30	MICRO-SWITCH - EXTENSION	8
X101	BEACON	6	B31	MICRO-SWITCH - DOWN-MOVEMENT	8
X102	CAB LIGHTS	6	B32	MICRO-SWITCH - SWAY	8
Y01	SOLENOID VALVE - FORWARD SPEED	3	B33	MICRO-SWITCH - RIGHT OUTRIGGER	8
Y02	SOLENOID VALVE - REVERSE SPEED	3	B34	MICRO-SWITCH - LEFT OUTRIGGE	8
Y20	SOLENOID VALVE - FOUR-WHEEL STEER	8	S50	DEADMAN BUTTON	7
Y21	SOLENOID VALVE - CRAB STEER	8	S51	DEADMAN BUTTON	7
Y0	SOLENOID VALVE - COLD STARTING	1	S52	DEADMAN BUTTON	7
Y00	SOLENOID VALVE - ENGINE STOP	1	S53	DEADMAN BUTTON	7
X1	CONNECTOR INDICATOR LIGHTS		S54	DEADMAN BUTTON	7
X11	13-WAY MARK CONNECTOR		XB30	2-WAY DT CONNECTOR	8
X12	5-WAY MARK CONNECTOR		XB31	2-WAY DT CONNECTOR	8
X13	6-WAY CONNECTOR		XB32	2-WAY DT CONNECTOR	8
X16	13-WAY MARK CONNECTOR		XB33	2-WAY DT CONNECTOR	8
X17	17-WAY MARK CONNECTOR		XB34	2-WAY DT CONNECTOR	8
X18	13-WAY MARK CONNECTOR		X27	2-WAY CONNECTOR	8
X19	21-WAY MARK CONNECTOR				
X2	CONNECTOR INDICATOR LIGHTS				
X20	17-WAY MARK CONNECTOR				
X21	40-WAY DEUTSCH CONNECTOR - TYPE B				
X22	12-WAY DEUTSCH CONNECTOR				
X25	8-WAY CONNECTOR				
X26	17-WAY MARK CONNECTOR				
X28	4-WAY DEUTSCH CONNECTOR				
X29	24-WAY DEUTSCH CONNECTOR				
X30	2-WAY CONNECTOR				
X34	2-WAY 90° CONNECTOR				
X4	9-WAY MARK CONNECTOR				
X5	11-WAY MARK CONNECTOR				
X51	4-WAY DEUTSCH CONNECTOR				
X52	4-WAY DEUTSCH CONNECTOR				
X53	3-WAY DEUTSCH CONNECTOR				
X6	17-WAY MARK CONNECTOR				
X7	9-WAY MARK CONNECTOR				
X8	5-WAY MARK CONNECTOR				
X9	13-WAY MARK CONNECTOR				
X91	2-WAY 90° CONNECTOR				
XH21	6-WAY DEUTSCH CONNECTOR				
XH22	6-WAY DEUTSCH CONNECTOR				
XH23	6-WAY DEUTSCH CONNECTOR				
XH26	6-WAY DEUTSCH CONNECTOR				
XM3	2-WAY CONNECTOR				
XM5	4-WAY CONNECTOR				
XP1	6-WAY CONNECTOR				
XP2	6-WAY CONNECTOR				

WIRING COLOUR	
A	LIGHT BLUE
B	WHITE
C	ORANGE
G	YELLOW
H	GREY
L	BLUE
M	BROWN
N	BLACK
R	RED
S	PINK
V	GREEN
Z	PURPLE

REMARK: FOR BICOLOR WIRES, THE INITIALS ABOVE ARE USED IN CONJUNCTION - EXAMPLE:


G/V -> YELLOW/GREEN (CROSSWISE COLOURING)
G-V -> YELLOW/GREEN (LENGTHWISE COLOURING)




TABLES AND DOCUMENTS ENCLOSED

G-4.1 GTH-3713 HYDRAULIC SCHEME

GTH-3713
 From serial no. **xxxxx**
 To serial no. **14845**







TABLES AND DOCUMENTS ENCLOSED


G-4.2 GTH-3713 HYDRAULIC SCHEME

GTH-3713
From serial no. 14846
To serial no. xxxxx




TABLES AND DOCUMENTS ENCLOSED
■ G-4.3 GTH-3713 DESCRIPTION OF THE HYDRAULIC COMPONENTS


Ref.	Description
1	Diesel engine
2	Transmission hydraulic pump
3	Transmission hydraulic motor
4	Main hydraulic pump
5	Second hydraulic pump
6	Intake filter (150 p10)
7	Submersed intake filter
8	Thermal exchanger fan motor
9	Thermal exchanger
10	One-way valve
11	Hydraulic oil tank
12	One-way valve
13	Load sensing priority valve
14	Power steering
15	Front axle steering cylinder
16	Rear axle steering cylinder
17	Steering selection solenoid valve
18	Servo-assisted brake pump
19	Accumulator
20	Axle
21	6-elements monolithic distributor
22	Flow divider
23	Pressure relief valve
24	Outrigger cylinder
25	Block valve
26	Outrigger cylinder
27	Block valve
28	Block valve for lifting cylinder
29	Lifting cylinder
30	One-way valve
31	Block valve for sway cylinder
32	Sway cylinder
33	Block valve for fork motion cylinder
34	Fork motion cylinder
35	Block valve for 2 nd telescope extension cylinder
36	2 nd telescope extension cylinder
37	Block valve for 3 rd telescope extension cylinder
38	3 rd telescope extension cylinder
39	Block valve
40	Attachment locking cylinder
41	Machine levelling cylinder
42	Machine levelling cylinder block valve




TABLES AND DOCUMENTS ENCLOSED

G-5 ROUTINE CHECK SCHEDULE - SAFETY DEVICES

Date	COMPONENT																Result/Notes		Signature					
	Block.Valve 1	Block.Valve 2	Block.Valve 3	Block.Valve 4	Block.Valve 5	Block.Valve 6	Block.Valve 7	Block.Valve 8	Block.Valve 9				Micro 1	Micro 2	Micro 3	Micro 4	Micro 5	ARB + Display		EMERGENCY	Puls. Joystick	Positive	Negative	
																					<input type="checkbox"/>	<input type="checkbox"/>		
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	
																						<input type="checkbox"/>	<input type="checkbox"/>	


TABLES AND DOCUMENTS ENCLOSED
Table key explanation:

Block valve 1	Block valve on lifting cylinder
Block valve 2	Block valve on fork compensation cylinder
Block valve 3	Block valve on telescope extension cylinder
Block valve 4	Block valve on attachment moving cylinder
Block valve 5	Block valve on attachment locking cylinder
Block valve 6	
Block valve 7	
Block valve 8	
Block valve 9	
Micro Stab 1	
Micro Stab 2	
Micro Stab 3	
Micro Stab 4	
Micro 1	Presence micro-switch in driving seat
Micro 2	Presence micro-switch on parking brake
Micro 3	
Micro 4	
Micro 5	
ARB + Display	Solenoid valve - overload warning system - Electronic card and display
EMERGENCY	Emergency stop pushbutton
Joystick button	Dead man pushbutton on control lever



TABLES AND DOCUMENTS ENCLOSED

Intentionally blank page