IMPORTANT SAFETY RULES

Read, understand, and follow all instructions carefully before installing and using this product.

Krystal Clear™ Saltwater System

Model CS8220 220 - 230 V~, Model CS8230 230 - 240 V~



Don't forget to try these other fine Intex products: pools, pool accessories, inflatable pools and in-home toys, airbeds and boats available at fine retailers or visit our website. Due to a policy of continuous product improvement, Intex reserves the right to change specifications and appearance, which may result in updates to the instruction manual without notice.

©2013 Intex Marketing Ltd. - Intex Development Co. Ltd. - Intex Trading Ltd.

©2013 Intex Marketing Ltd. - Intex Development Co. Ltd. - Intex Trading Ltd.
- Intex Recreation Corp.
All rights reserved/Tous droits réservés/Todos los derechos reservados/Alle Rechte vorbehalten. Printed in China/Imprimé en Chine/Impreso en China/
Gedruckt in China. ®™ Trademarks used in some countries of the world under license from/®™ Marques utilisées dans certains pays sous licence de/Marcas registradas utilizadas en algunos países del mundo bajo licencia de/Warenzeichen verwendet in einigen Ländern der Welt in Lizenz von/Intex Marketing Ltd. to/à/a/an Intex Trading Ltd., Intex Development Co. Ltd., G.P.O Box 28829, Hong Kong & Intex Recreation Corp., P.O. Box 1440, Long Beach, CA 90801 • Distributed in the European Union by/Distribué dans l'Union Européenne par/Distribuido en la unión Europea por/ Vertrieb in der Europäischen Union durch/Intex Trading B.V., Venneveld 9, 4705 RR Roosendaal – The Netherlands www.intexcorp.com www.intexcorp.com

TABLE OF CONTENTS

Warnings	3	
Parts References	4	
Product Information & Specifications	5	
Setup Instructions	6-10	
Salt & Pool Water Volumes	11	
Intex Pools Salt Table	12	
Intex Pools Cyanuric Acid Table	13	
Intex Pools Operating Time Table	14	
Non-Intex Pools Salt Table	15	
Non-Intex Pools Cyanuric Acid Table	15	
Non-Intex Pools Operating Time Table	15	
Operating Instructions	16-17	7
LED Code Chart	18	
Stationary Mounting	19	
Maintenance	20-22	<u>}</u>
Long Term Storage		
	22	
Long Term Storage	22 23	;
Long Term Storage Pool Maintenance and Chemical Definitions	22 23 24-25	5

h 132

English

IMPORTANT SAFETY RULES

Read, Understand and Follow All Instructions Carefully Before Installing and Using this Product.

READ AND FOLLOW ALL INSTRUCTIONS

A WARNING

- To reduce the risk of injury, do not permit children to use this product. Always supervise children and those with disabilities.
- Children must stay away from this product and electrical cord(s).
- Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- · Assembly and disassembly by adults only.
- Risk of electric shock. Connect this product only to a grounding type receptacle protected by a ground-fault circuit interrupter (GFCI) or residual current device (RCD). Contact a qualified electrician if you cannot verify that the receptacle is protected by a GFCI/RCD. Use a qualified electrician to install the GFCI/RCD, which has a maximum rate of 30mA. Do not use a portable residual current device (PRCD).
- Always unplug this product from the electrical outlet before removing, cleaning, servicing or making any adjustment to the product.
- The plug must be accessible after product is installed.
- Do not bury the electrical cord. Locate the cord where it will not be damaged by lawn mowers, hedge trimmers and other equipment.
- The supply cord cannot be replaced. If the cord is damaged the appliance should be scrapped.
- To reduce the risk of electric shock, do not use extension cords, timers, plug adaptors or converter plugs to connect unit to electric supply, provide a properly located outlet.
- Do not attempt to plug in or unplug this product while standing in water or when your hands are wet.
- Keep this product more than 2m away from the pool.
- Keep the plug of this product more than 3.5m away from the pool.
- Position this product away from the pool, so as to prevent children from climbing on it and accessing the pool.
- Do not operate this product when the pool is occupied.
- This product is for use with storable pools only. Do not use with permanently installed pools. A storable pool is constructed so that it may be readily disassembled for storage and reassembled to its original configuration.
- This product is intended to be used only for the purposes described in the manual!


FAILURE TO FOLLOW THESE WARNINGS MAY RESULT IN PROPERTY DAMAGE, ELECTRIC SHOCK, ENTANGLEMENT OR OTHER SERIOUS INJURY OR DEATH.

These product warnings, instructions and safety rules provided with the product represent some common risks of water recreation devices and do not cover all instances of risk and danger. Please use common sense and good judgement when enjoying any water activity.

For portable Above-Ground-Pools only

PARTS REFERENCE

Before assembling your product, please take a few minutes to check the contents and become familiar with all the parts.



NOTE: Drawings for illustration purpose only. Actual product may vary. Not to scale.

R	EF. NO.			SPARE
COMMON PARTS	PARTS FOR CONNECTION TO FILTER PUMPS WITH 1-1/4" (32MM) HOSE SIZE	DESCRIPTION	QTY.	PART NO.
	1*	ADAPTOR A WITH THREADED COLLAR	1	10849
2		O-RING A	1	10712
3		SCREW	2	11519
4		ELECTROLYTIC CELL (O-RING A INCLUDED)	1	11433
5		COPPER ELECTRODE	1	11234
6		TITANIUM ELECTRODE	1	11374
7		FLOW SENSOR	1	11460
8		CONNECTOR HOSE WITH THREADED FITTINGS	1	10720
	9*	THREADED ADAPTOR B	1	10722
10		CELL COVER	2	11131
11		ELECTROLYTIC CELL NUT	1	11432
12		L-SHAPE O-RING	1	11228
13		COPPER ELECTRODE NUT	1	11488
14		CHLORINE TEST STRIPS	1	19635
15		COPPER TEST STRIPS	1	11254
16		TITANIUM ELECTRODE O-RING	1	11515
17		COPPER ELECTRODE O-RING	1	11440
18		CONTROL STATION	1	11680

[&]quot; * ": Optional.

When ordering parts, be sure to quote the model number and part numbers.

HOW THE CHLORINE IS GENERATED

This product is specially designed for above ground pools. It will destroy the bacteria, oxidize bather organics and control algae, which provide a safe, clean and comfortable swimming pool.

Common salt (sodium chloride) is made up of two elements, sodium and chloride. During the installation of your Saltwater System, a measured quantity of salt is dissolved in the pool water to make it slightly salty. The pool water flows through the Saltwater System 's electrolytic cell to produce chlorine. The chlorine dissolves in the water and instantly starts destroying bacteria and algae. It also oxidizes all other organic materials.

HOW COPPER IONS ARE GENERATED

Low voltage direct current is applied to the copper electrode, and copper ions are generated and dissolved instantly in the water. Copper is an effective algaecide, which will prevent algae from growing in the pool.

PRODUCT SPECIFICATIONS

Wattage: 125W


Ideal Salt Level: 3000 ppm (parts per million)

Maximum Chlorine Output/hour: 12 grams/hour

Copper Ionizer Output Current: 175 mA

Filter pump minimum flow rate: 700 ~ 4000 gallons/hour (2650 - 15140 liters/hour)

Limited Warranty: see "Limited Warranty"




SETUP INSTRUCTIONS

IMPORTANT

- The Saltwater System requires a separate filter pump [700~4000 gph (2650~15140 lph)] to drive the water and function properly.
- The Saltwater System must be installed as the last piece of pool equipment in the water return line to the pool as displayed in Drawing #1. This location extends the life of the titanium plates.
- Assemble the above-ground-pool (AGP) and its filter pump according to their installation instructions.
- 2. Take the Saltwater System and its accessories out of the packaging.
- 3. Place the Saltwater System in line after the filter pump.
- 4. Connect the connector hose (8) to the Saltwater System inlet.


Connecting the system to pump and pool with 1-1/4" (32mm) connections/hoses: The saltwater system features 1-1/2" (38mm) connections. It is accordingly supplied with adaptors A (1) and B (9) for connecting to the small 1-1/4" (32mm) diameter connections/ hoses. Install as follows:

Drawing #1




SETUP INSTRUCTIONS (continued)


- 1. Go directly to step 2 if your pool is empty. If your above-ground-pool is filled with water, unscrew the strainer grids from the strainer connectors and insert the black hat-like plugs into the connectors, before installing the saltwater pool system.
- 2. Connect the adaptor A (1) to the electrolytic cell (4) outlet as shown in Drawing #1. Tighten securely.



- 3. Disconnect the water return hose from the filter pump connection and connect it to the adaptor A (1) on the Saltwater System with a hose clamp. (see Drawing #1)
- 4. Connect adaptor B (9) to the connector hose (8). Tighten securely. (see Drawing #1)



5. Connect adaptor B (9) to filter pump outlet (lower connection). Tighten securely.




6. Remove the black hat-like plugs that prevent water from flowing out of the pool. Now, return the strainer grids to the strainer connectors.

SETUP INSTRUCTIONS (continued)

Connecting the system to pump and pool with 1-1/2" (38mm) connections/hoses: Pump and pool with 1-1/2" (38mm) connections do not require the adaptors A (1) or B (9). Install as follows:

Drawing #2




- 1. Go directly to step 2 if your pool is empty. If your above-ground-pool is filled with water, close the plunger valves before installing the Saltwater System.
- 2. Disconnect the water return hose from the filter pump connection and connect it to the Saltwater System outlet.
- 3. Connect the connector hose (8) to the filter pump outlet connection.
- 4. Open the plunger valves to allow the water to flow.

SETUP INSTRUCTIONS (continued)

Connecting the system to other types of pump (with different type of thread or no thread):


The Saltwater System can also be adapted to other filter pumps with different thread or those without a thread on the connection.

Connection to 1-1/4" (32mm) hose:



- 1. Connect one end of adaptor B (9) to the connector hose (8). Tighten securely.
- 2. Now, connect the other end of adaptor B (9) to the filter pump outlet. Tighten securely.

Connection to 1-1/2" (38mm) hose with clamp:



1. Connect the connector hose (8) to the filter pump outlet connection with a large hose clamp. Tighten securely.


SETUP INSTRUCTIONS (continued)

Connecting the system to other types of pool

After you have connected the Saltwater System to the pump, connect it to the pool. This is depicted in Drawings #1 and #2.


Following are the common connection types:

Connection to 1-1/4" (32mm) connectors:



- 1. Connect the adaptor A (1) to the electrolytic cell (4) outlet. Tighten securely.
- **2.** The adapter A **(1)** is now fitted to the Saltwater System. The following step is to connect the water return hose to the adaptor A **(1)** with a hose clamp.

Connection to 1-1/2" (38mm) connectors without thread:



- 1. Connect the adaptor A (1) to the electrolytic cell (4) outlet. Tighten securely.
- 2. With the adaptor A (1) fixed to the Saltwater System, connect the water return hose to the adaptor, using a large hose clamp.

SALT & POOL WATER VOLUMES

· Which kind of salt to use:

Use only Sodium Chloride Salts

Use only sodium chloride (NaCl) salt that is at least 99.8% pure. It is also acceptable to use water conditioning salt pellets (the compressed forms of evaporated salt). However, it will take a longer time for them to dissolve. **Do not use iodized or yellow (yellow prussiate of soda) colored salt**. Salt is added to the pool water and the electrolytic cell uses the salt to create chlorine. The purer the salt the better the performance of the electrolytic cell.

Optimum Salt Levels

The ideal salt level in the pool water is between 2500-3500 ppm (parts per million). The optimal level is 3000 ppm.

A too low salt level will reduce the efficiency of the Saltwater System and result in low chlorine production. A high salt level may generate a salty taste to the pool water (this may occur at a salt level above 3500-4000ppm). Too high a salt level may damage the power supply and cause corrosion to the pool metal fixtures and accessories. The Salt Table page of this manual, shows the correct dosage of salt needed. The salt in the pool is constantly recycled. The loss of salt is due only to pool water being physically removed from the pool. Salt is not lost due to evaporation.

Adding Salt

- 1. Switch the filter pump on to start the water circulation.
- 2. Keep the Saltwater System turned off.
- 3. Determine the amount of salt to be added (see "Salt Table").
- 4. Evenly spread the proper amount of salt around the inside perimeter of the pool.
- **5**. Avoid clogging the filter. Do not add salt through the skimmer.
- **6**. Brush the pool bottom to speed up the dissolving process. Do not allow salt to pile up on the bottom of the pool. Run the filter pump 24 consecutive hours to thoroughly dissolve the salt.
- 7. After 24 hours and if all the salt is dissolved, turn on the Saltwater System, press button until you hear a "beep", code "00" flashing and set the saltwater pool system to desired operating time (see "Operating Time Table").

Removing Salt

If too much salt has been added, the unit will beep and display "Code 92" (see "Alarm Codes"). You will need to lower the salt concentration. The only way to do so, is to partially drain the pool and refill it with fresh water. Drain and refill approximately 20% of the pool's water until the "Code 92" disappears.

Pool Volume Calculation

Types of Pool	Gallons (pool size in feet)	Cubic Meters (pool size in meters)
Rectangular	Length x Width x Average Depth x 7.5	Length x Width x Average Depth
Circular	Length x Width x Average Depth x 5.9	Length x Width x Average Depth x 0.79
Oval	Length x Width x Average Depth x 6.0	Length x Width x Average Depth x 0.80

132A

English

INTEX POOLS SALT TABLE

This table shows the amount of salt needed to achieve and maintain the optimal 3000 ppm salt level.

	Pool Size	90% for Frame	y (Calculated at Pool and 80% & Oval Pool)	Sta	eded for rtup 8000ppm)	Low Salt	ded when Detected E "91")
		(Gals)	(Liters)	(Lbs)	(Kgs)	(Lbs)	(Kgs)
INTEX ABOVE	GROUND POOLS (AGP's)		,				
	15' x 33" (457cm x 84cm)	2587	9792	65	30	20	10
	15' x 36" (457cm x 91cm)	2822	10681	65	30	20	10
	15' x 42" (457cm x 107cm)	3284	12430	80	35	20	10
FACY OFT®	15' x 48" (457cm x 122cm)	3736	14141	95	45	25	10
EASY SET [®] POOL	16' x 42" (488cm x 107cm)	3754	14209	95	45	25	10
	16' x 48" (488cm x 122cm)	4273	16173	110	50	30	15
	16' x 52" (488cm x 132cm)	4614	17464	115	50	30	15
	18' x 42" (549cm x 107cm)	4786	18115	120	55	30	15
	18' x 48" (549cm x 122cm)	5455	20647	135	60	35	15
	15' x 36" (457cm x 91cm)	3282	12422	80	35	20	10
	15' x 42" (457cm x 107cm)	3861	14614	100	45	25	10
CIRCULAR	15' x 48" (457cm x 122cm)	4440	16805	110	50	30	15
METAL	16' x 48" (488cm x 122cm)	5061	19156	125	55	35	15
FRAME POOL	18' x 48" (549cm x 122cm)	6423	24311	160	75	40	20
	21' x 52" (640cm x 132cm)	9533	36082	240	110	60	30
	24' x 52" (732cm x 132cm)	12481	47241	310	140	80	35
	16' x 48" (488cm x 122cm)	5061	19156	125	55	35	15
	18' x 48" (549cm x 122cm)	6423	24311	160	75	40	20
ULTRA	18' x 52" (549cm x 132cm)	6981	26423	175	80	45	20
FRAME®	20' x 48" (610cm x 122cm)	7947	30079	210	90	50	25
POOL	22' x 52" (671cm x 132cm)	10472	39637	260	120	65	30
	24' x 52" (732cm x 132cm)	12481	47241	310	140	80	35
	26' x 52" (792cm x 132cm)	14667	55515	365	165	90	40
SEQUOIA	15'8" x 49" (478cm x 124cm)	4440	16805	110	50	30	15
SPIRIT [®]	16'8" x 49" (508cm x 124cm)	5061	19156	125	55	35	15
POOL SET	18'8" x 53" (569cm x 135cm)	6981	26423	175	80	45	20
OVAL FRAME	18' x 10' x 42" (549cm x 305cm x 107cm)	2885	10920	70	30	20	10
POOL	20' x 12' x 48" (610cm x 366cm x 122cm)	4393	16628	110	50	30	15
	15' x 9' x 48" (457cm x 274cm x 122cm)	3484	13187	90	40	25	10
	18' x 9' x 52" (549cm x 274cm x 132cm)	4545	17203	115	50	30	15
RECT. ULTRA FRAME POOL	20 x 10' x 52" (610cm x 305cm x 132cm)	5835	22085	145	65	40	20
I RAIVIE FOOL	24' x 12' x 52" (732cm x 366cm x 132cm)	8403	31805	210	95	55	25
	32' x 16' x 52" (975cm x 488cm x 132cm)	14364	54368	360	165	90	40

INTEX POOLS CYANURIC ACID TABLE

Cyanuric acid is a chemical that reduces the loss of chlorine in water due to ultraviolet rays. To maintain the pool water clear and clean, and to maximize the performance of the device, add cyanuric acid to the pool. We recommend that the cyanuric acid level be maintained at approximately 1% of the salt, i.e. 100 Lbs (45 Kgs) salt x1% = 1 Lbs (0.45 Kgs) cyanuric acid. If the pool water is dirty, filthy or grimy, DO NOT add chlorine stabilizer (cyanuric acid) as this will slowdown the sanitation time of the device. Under this condition you must BOOST your pool water, refer to BOOST cycle steps. Once the pool water has been restored to clear and clean conditions you may add cyanuric acid.

	Pool Size	90% for Frame for Easy Set	y (Calculated at e Pool and 80% t & Oval Pool)	Cyanuric Aci Staı 0.03g/L	
		(Gals)	(Liters)	(Lbs)	(Kgs)
INTEX ABOVE	GROUND POOLS (AGP's)				
	15' x 33" (457cm x 84cm)	2587	9792	0.6	0.3
	15' x 36" (457cm x 91cm)	2822	10681	0.7	0.3
	15' x 42" (457cm x 107cm)	3284	12430	8.0	0.4
EASY SET®	15' x 48" (457cm x 122cm)	3736	14141	0.9	0.4
POOL	16' x 42" (488cm x 107cm)	3754	14209	0.9	0.4
FOOL	16' x 48" (488cm x 122cm)	4273	16173	1.1	0.5
	16' x 52" (488cm x 132cm)	4614	17464	1.2	0.5
	18' x 42" (549cm x 107cm)	4786	18115	1.2	0.5
	18' x 48" (549cm x 122cm)	5455	20647	1.4	0.6
	15' x 36" (457cm x 91cm)	3282	12422	0.8	0.4
	15' x 42" (457cm x 107cm)	3861	14614	1.0	0.4
CIRCULAR	15' x 48" (457cm x 122cm)	4440	16805	1.1	0.5
METAL	16' x 48" (488cm x 122cm)	5061	19156	1.3	0.6
FRAME POOL	18' x 48" (549cm x 122cm)	6423	24311	1.6	0.7
	21' x 52" (640cm x 132cm)	9533	36082	2.4	1.1
	24' x 52" (732cm x 132cm)	12481	47241	3.1	1.4
	16' x 48" (488cm x 122cm)	5061	19156	1.3	0.6
	18' x 48" (549cm x 122cm)	6423	24311	1.6	0.7
ULTRA	18' x 52" (549cm x 132cm)	6981	26423	1.7	0.8
FRAME®	20' x 48" (610cm x 122cm)	7947	30079	2.0	0.9
POOL	22' x 52" (671cm x 132cm)	10472	39637	2.6	1.2
	24' x 52" (732cm x 132cm)	12481	47241	3.1	1.4
	26' x 52" (792cm x 132cm)	14667	55515	3.7	1.7
SEQUOIA	15'8" x 49" (478cm x 124cm)	4440	16805	1.1	0.5
SPIRIT®	16'8" x 49" (508cm x 124cm)	5061	19156	1.3	0.6
POOL SET	18'8" x 53" (569cm x 135cm)	6981	26423	1.7	0.8
OVAL FRAME	18' x 10' x 42" (549cm x 305cm x 107cm)	2885	10920	0.7	0.3
POOL	20' x 12' x 48" (610cm x 366cm x 122cm)	4393	16628	1.1	0.5
	15' x 9' x 48" (457cm x 274cm x 122cm)	3484	13187	0.9	0.4
	18' x 9' x 52" (549cm x 274cm x 132cm)	4545	17203	1.1	0.5
RECT. ULTRA	20 x 10' x 52" (610cm x 305cm x 132cm)	5835	22085	1.5	0.7
FRAME POOL	24' x 12' x 52" (732cm x 366cm x 132cm)	8403	31805	2.1	1.0
	32' x 16' x 52" (975cm x 488cm x 132cm)	14364	54368	3.6	1.6

INTEX POOLS OPERATING TIME TABLE (WITH CYANURIC ACID)

		90% for Frame	y (Calculated at Pool and 80% & Oval Pool)	at diffe	ng Time rent amb nperatur	ient/air	Intex Filter pump Operating
		(Gals)	(Liters)	10 - 19°C (50 - 66°F)	20 - 28°C (68 - 82°F)	29 - 36°C (84 - 97°F)	Time (hours)
INTEX ABOVE	INTEX ABOVE GROUND POOLS (AGP's)						
	15' x 33" (457cm x 84cm)	2587	9792	1	1	2	4
	15' x 36" (457cm x 91cm)	2822	10681	1	1	2	4
	15' x 42" (457cm x 107cm)	3284	12430	1	2	3	4
	15' x 48" (457cm x 122cm)	3736	14141	1	2	3	4
EASY SET [®] POOL	16' x 42" (488cm x 107cm)	3754	14209	1	2	3	4
1002	16' x 48" (488cm x 122cm)	4273	16173	2	2	3	4
	16' x 52" (488cm x 132cm)	4614	17464	2	2	3	4
	18' x 42" (549cm x 107cm)	4786	18115	2	2	3	4
	18' x 48" (549cm x 122cm)	5455	20647	2	3	4	6
	15' x 36" (457cm x 91cm)	3282	12422	1	2	3	4
	15' x 42" (457cm x 107cm)	3861	14614	1	2	3	4
CIRCULAR	15' x 48" (457cm x 122cm)	4440	16805	2	2	3	4
METAL	16' x 48" (488cm x 122cm)	5061	19156	2	2	3	4
FRAME POOL	18' x 48" (549cm x 122cm)	6423	24311	3	3	4	6
	21' x 52" (640cm x 132cm)	9533	36082	4	5	6	8
	24' x 52" (732cm x 132cm)	12481	47241	5	6	7	8
	16' x 48" (488cm x 122cm)	5061	19156	2	2	3	4
	18' x 48" (549cm x 122cm)	6423	24311	3	3	4	6
ULTRA	18' x 52" (549cm x 132cm)	6981	26423	3	3	4	6
FRAME®	20' x 48" (610cm x 122cm)	7947	30079	3	4	5	6
POOL	22' x 52" (671cm x 132cm)	10472	39637	4	5	6	8
	24' x 52" (732cm x 132cm)	12481	47241	5	6	7	8
	26' x 52" (792cm x 132cm)	14667	55515	6	7	8	12
SEQUOIA	15'8" x 49" (478cm x 124cm)	4440	16805	2	2	3	4
SPIRIT [®]	16'8" x 49" (508cm x 124cm)	5061	19156	2	2	3	4
POOL SET	18'8" x 53" (569cm x 135cm)	6981	26423	3	3	4	6
	18' x 10' x 42" (549cm x 305cm x 107cm)	2885	10920	1	1	2	4
POOL	20' x 12' x 48" (610cm x 366cm x 122cm)	4393	16628	2	2	3	4
	15' x 9' x 48" (457cm x 274cm x 122cm)	3484	13187	1	2	3	4
DEGT III TO	18' x 9' x 52" (549cm x 274cm x 132cm)	4545	17203	2	2	3	4
RECT. ULTRA FRAME POOL	20 x 10' x 52" (610cm x 305cm x 132cm)	5835	22085	2	3	4	6
	24' x 12' x 52" (732cm x 366cm x 132cm)	8403	31805	3	4	5	6
	32' x 16' x 52" (975cm x 488cm x 132cm)	14364	54368	6	7	8	12

The filter pump running time should be 1 hour longer than the required operating time of the Saltwater System.

SAVE THESE INSTRUCTIONS

Page 14

SALT CALCULATION FORMULA FOR ALL POOLS

Salt Needed for Startup (Lbs)			Salt Needed when Low Salt Detected (Kgs)
Water Capacity (Gals) x 0.025	Water Capacity (Liters) x 0.003	Water Capacity (Gals) x 0.0067	Water Capacity (Liters) x 0.0008

SALT TABLE FOR COMMON NON-INTEX POOLS

Water	Capacity	Salt Needed for Startup		Low Salt	ded when Detected E "91")
(Gals)	(Liters)	(Lbs)	(Kgs)	(Lbs)	(Kgs)
2000	7500	50	20	10	5
4000	15000	100	45	25	10
6000	22500	150	65	40	20
8000	30000	200	90	55	25
10000	37500	250	110	70	30
12000	45500	300	135	80	35
14000	53000	350	160	95	45

CYANURIC ACID TABLE FOR COMMON NON-INTEX POOLS

Water Capacity		Cyanuric Acid Ne 0.03g/L	eeded for Startup (30ppm)
(Gals)	(Liters)	(Lbs)	(Kgs)
2000	7500	0.5	0.23
4000	15000	1.0	0.45
6000	22500	1.5	0.68
8000	30000	2.0	0.90
10000	37500	2.5	1.13
12000	45500	3.0	1.37
14000	53000	3.5	1.59

OPERATING TIME TABLE FOR COMMON NON-INTEX POOLS (WITH CYANURIC ACID)

Water	Capacity	Operating Time (hours) at different ambient/air temperatures		
(Gals)	(Liters)	10 - 19°C (50 - 66°F)	20 - 28°C (68 - 82°F)	29 - 36°C (84 - 97°F)
2000	7500	1	1	2
4000	15000	1	2	3
6000	22500	2	3	4
8000	30000	3	4	5
10000	37500	4	5	6
12000	45500	5	6	7
14000	53000	6	7	8

SAVE THESE INSTRUCTIONS

OPERATION INSTRUCTIONS

1. Turn on the filter pump.

2. Start up the unit:


Plug the power cord into the electrical outlet and test the GFCI/RCD (circuit breaker). Switch on the unit. Flashing code "00" appears on the electronic control station's LED, indicating that the unit is ready to be programmed.





3. Set operating hours for Saltwater system:

With code "00" flashing, press button to set the desired operating hours. See the "Operating Time Table" for the required operating hours related to each pool size. Pressing will increase the time from 01 to 12 hours maximum. If you have selected too many hours keep pressing to repeat the cycle. The built-in timer will now activate your Saltwater System, at the same time each day, for the number of hours you have




(1 to 12 hours max per cycle)

NOTE: The Saltwater System will not operate if the filter pump is not operating. Make sure to program your filter pump (or start it manually) for operation beginning 5 minutes before the saltwater system and finishing 15 minutes after the saltwater system.

4. Lock keypad controls:

With the desired hour value showing, press button until you hear a "beep". A green "WORKING" indicator on the control panel will light up within a few seconds to indicate that the saltwater system has started chlorine production. Locking the control buttons into this setting prevents unauthorized changing of the operating cycle.






5. Readjust operating time if necessary:

The operating hours can be re-adjusted if necessary. Press button until you hear a "beep" to unlock the keypad and the current programmed time will flash. Repeat steps 3 to 4.



6. Test the copper concentration in the pool water.

The Saltwater System recommends a copper level of 0.1 to 0.2 ppm. This is easily tested by the copper ion test strips provided. If the test result is 0.1~0.2ppm, go directly to step 8.



OPERATION INSTRUCTIONS (continued)

7. Boost cycle

If the test result is below 0.1ppm, press and hold "BOOST" button for 5 seconds until the indicator lights up and the LED display shows "80". This indicates that the saltwater system has started copper ion and more chlorine sanitizer production. You can press and hold the "BOOST" button for another 5 seconds until the indicator is off, which will cancel the Boost cycle.



Note: Once the system has started copper ion and more chlorine sanitizer production, the boost button can't be re-set until the power switch is off.

- The boost operating hours is 8 times the amount of time programmed into the system, i.e. if your saltwater system operating time is 2 hours, the boost procedure will run 8 x 2 = 16 hours. After boost procedure has been completed, the system will automatically switch to the normal working mode.
- Once the boost is operating, check whether the filter pump operating hours have been set properly. For example, the boost operating time is 8 hours, the filter pump should be set to run for 8 hours at least. Increase the filter pump operating time if necessary.
 Note: If an Intex filter pump is attached to the system, set the pump switch to on "I" position.
- After a heavy rain or if the pool is dirty, press the "BOOST" button to shock the pool again.

8. Test pool water regularly:

Once the copper level appears to be balanced, test the pool water every week to maintain the proper sanitizer level.

It's very important that the free chlorine is between 0.5-3.0 ppm and copper ion concentration is between 0.1~0.2 ppm. When the copper level is below 0.1 ppm, repeat step 7.

NOTE: A High copper ion concentration may cause blonde hair to exhibit a green hair. To prevent this, wear a swimming cap during swimming, and wash hair with special shampoo

9. Stand-by/power saving mode:

after using the pool. See "Troubleshooting Guide".

- When the cycle ends, the green "SLEEP" indicator on the control panel lights up and the LED display flashes "93". The system is now in Stand-By mode. After a while, it shuts down and sets itself in a Power Saving mode. The system will automatically turn itself back on in 24 hours, starting its daily cycle of chlorine production.
- WORKING
 WORKIN
- The "SLEEP" indicator stays on, while the system is in the Power Saving mode. The LED display however, goes blank after 5 minutes. Press any button (or in) to view the last LED code.



LED CODE CHART

LED Reading	Definitions
80	Boost Mode
00	Stand-By Mode (Start-up)
01	Minimum Operating Hour (1 hour remaining)
02	Operating Hours (2 hours remaining)
03	Operating Hours (3 hours remaining)
04	Operating Hours (4 hours remaining)
05	Operating Hours (5 hours remaining)
06	Operating Hours (6 hours remaining)
07	Operating Hours (7 hours remaining)
08	Operating Hours (8 hours remaining)
09	Operating Hours (9 hours remaining)
10	Operating Hours (10 hours remaining)
11	Operating Hours (11 hours remaining)
12	Maximum Operating Hours (12 hours remaining)
90	Alarm Code (Low Pump Flow / No Flow)
91	Alarm Code (Low Salt Level)
92	Alarm Code (High Salt Level)
93	Stand-By Mode (Operating Process finished)
"BLANK"	No Power or "Power Saving Mode" waiting to start next Saltwater System cycle.

IMPORTANT


When Code "90" alarm is shown, ensure the timer of the filter pump is set one (1) hour longer than the Saltwater System.

If the filter pump does not have a built-in timer, the filter pump needs to be turned on/off manually every day.

SALTWATER SYSTEM STATIONARY MOUNTING

Some countries, especially in the European community, require the product to be secured to the ground or to a base in a permanent upright position. Check with your local authorities to determine if there is a regulation in your area regarding above-the-ground swimming pool filter pumps. If yes, then the product can be mounted to a platform using the two holes located in the base. See drawing below.

The product can be mounted on a cement base or onto a wooden platform to prevent accidental tipping. Total assembly must exceed 18kg.



- 1. The mounting holes are 6.4 mm in diameter and spaced 97 mm apart.
- 2. Use two bolts and lock nuts with a maximum of 6.4 mm in diameter.

MAINTENANCE

IMPORTANT

Unplug the power cord before cleaning your system. Also close the plunger valves on your pool or insert the black hat-like plugs in the strainer opening to prevent water spillage. After completing all maintenance tasks, you must plug the power cord back in and open the plunger valves or remove the plugs.

Flow Sensor Cleaning

- 1. In a counter-clockwise motion unscrew the collar of the flow sensor (7) and remove it from the electrolytic cell conduit. See "Part Reference".
- If deposits and debris are seen on the surface of the flow sensor, then use a garden hose to wash it off.



Connection Ridge

- 3. If flushing with water does not remove the deposits, use a plastic brush to clean the surface and the hinge if necessary. Do not use a metal brush.
- **4**. After the flow sensor has been inspected and cleaned, align the locator notch on the flow sensor to the connection ridge in the conduit. Now turn the collar in a clockwise motion, tightening the sensor back into its position. Do not overtighten.

Electrolytic Cell Cleaning

The electrolytic cell **(4)** has a self cleaning function incorporated into the electronic control's programming. In most cases this self cleaning action will keep the cell working at optimum efficiency. If the pool water is hard (high mineral content) the cell may require periodic manual cleaning. To maintain maximum performance, we recommend that you open and visually inspect the electrolytic cell **(4)** monthly.

The following steps provide instructions on how to clean your cell.

Inspection and cleaning:

- 1. Switch off the unit, unplug the power cord from the electrical socket.
- 2. For filter pumps with 1-1/4" (32mm) hose size To prevent water from flowing out of the pool, unscrew the strainer grids from the strainer connectors and insert the hat-like plugs into the strainer connectors.


For filter pumps with 1-1/2" (38mm) hose size - Turn both plunger valve handles fully clockwise until they stop. This closes the valve, prevents the water from flowing out of the pool.

MAINTENANCE (continued)


3. Disconnect the 2 hoses from the Saltwater System, and assemble the cell cover (10) at each side of the cell.



4. In a counter-clockwise motion, unscrew the collar of the copper electrode **(5)** and remove it from the electrolytic cell **(4)**. Lift up the copper electrode.



5. Pour kitchen grade vinegar into the cell to immerse the titanium plates. Then put the copper electrode back in the cell, soak them for about one hour until no colored areas remain.



6. Open one side of the cell cover **(10)**, drain and properly dispose of the vinegar. Connect the hose which goes from the pool to the cell. Flush the cell with the pool water.



7. Reverse steps 3, 4, 5 and 6 to reconnect the electrolytic cell.

132

English

MAINTENANCE (continued)

INTEX® COPPER ION TEST STRIPS (PACKED WITH THE PRODUCT)

The Copper Ion Test Strips can be used to test the copper ion concentration in the water.

Directions and Use

- 1. Dip the entire strip into the water for 3 seconds, then remove it.
- 2. Hold the strip level for 15 seconds. Do not shake excess water from the strip.
- 3. Now compare the copper ion strip pad to the color chart on the packaging label.

INTEX® 3-WAY TEST STRIPS (PACKED WITH THE PRODUCT)

The 3-Way Test Strips can test the "Free Chlorine", "pH", and "Total Alkalinity" levels at the same time. We recommend that you test the water chemistry weekly, and maintain the chlorine concentration at 0.5-3.0 ppm.

Directions and Use

- 1. Dip the entire strip into the water and remove immediately.
- 2. Hold the strip level for 15 seconds. Do not shake excess water from the strip.
- 3. Now compare the strip pad to the color chart on the packaging label. If necessary, adjust the chemical level in the pool water. It is very important, to use the proper technique when testing the water's chemical level. Read and follow the written strip instructions carefully.

LONG TERM STORAGE

- 1. Disconnect the power cord from the electrical outlet.
- **2**. After the pool is completely empty, disconnect the Saltwater System from the hoses by reversing the installation instructions.
- 3. Air-dry the unit before you store it. This might be a good time to visually inspect and clean the electrolytic cell.
- **4**. Store the unit and accessories in a dry place. The temperature should be controlled, between 32 degrees Fahrenheit (0 degrees Celsius) and 97 degrees Fahrenheit (36 degrees Celsius).
- **5**. The original package can be used for storage.

POOL MAINTENANCE & CHEMICAL DEFINITIONS

Preferred Water Chemistry Reading						
Minimum Ideal Maximum						
Copper Ions	0	0.1 - 0.2 ppm	0.2 ppm			
Free Chlorine	0	0.5 - 3.0 ppm	5.0 ppm			
Combined Chlorine	0	0 ppm	0.2 ppm			
рН	7.2	7.4 - 7.6	7.8			
Total Alkalinity	100 ppm	100 - 140 ppm	140 ppm			
Calcium Hardness	150 ppm	200 - 400 ppm	500 - 1000 ppm			
Stabilizer (Cyanuric Acid)	10 ppm	20 - 40 ppm	50 ppm			

Consult with local swimming pool dealer for water treatment.

Free Chlorine - Is the chlorine residual present in pool water.

Combined Chlorine - Is formed by the reaction of free chlorine with ammonia wastes. Result if too high - Sharp chlorinous odor, eye irritation.

pH - A value that indicates how acidic or basic a solution is.

Result if too low - Corroded metals, eye & skin irritation, destruction of

total alkalinity.

Result if too high - Scale formation, cloudy water, shorter filter runs,

eye & skin irritation, poor chlorine efficiency.

Total Alkalinity - Indicates the degree of the water's resistance to change in pH. It determines the speed and ease of pH change, so always adjust total

alkalinity before adjusting the pH level.

Result if too low - Corroded metals, eye & skin irritation. Low alkalinity will cause the pH to be unstable. Any chemical

added to the water will have an affect on pH.

Result if too high - Scale formation, cloudy water, eye & skin irritation, poor chlorine efficiency.

Calcium Hardness - Refers to the amount of calcium and magnesium dissolved in the water.

Result if too high - Scale will form and will cause the water to become

cloudy.

Stabilizer - Stabilizers extend the life of chlorine in swimming pools. **(Cyanuric Acid)**

- Do not add pool chemicals directly to the skimmer. This may damage the cell.
- Maintaining a salt and sanitizer level above the recommended range can contribute to the corrosion of the pool equipment.
- Check the expiry date of the test kit as the test results may be inaccurate if the kit is used after that date.
- If, due to heavy pool usage, it is required to increase the sanitizer level, then use a chemical based on trichlor, TCCA or dichloro.

132A

Englis

TROUBLESHOOTING GUIDE		
PROBLEM	CAUSE	SOLUTION
INSUFFICIENT CHLORINE	 Insufficient operating hours of the Saltwater System. The salt level in the pool water is less than 2000ppm. This is insufficient. Chlorine loss due to intense sunlight exposure. The bather load has increased. Clogged or dirty electrolytic cell. High UV level exposure. 	 Increase the daily Saltwater System operating time. See "Operating Instructions". Check the salt level with the Test Kit. Adjust as needed. See "Salt & Pool Water Volumes". Use a pool cover when the pool is not in use and/or when the unit is operating. Increase the daily Saltwater System operating time. See "Operating Instructions". Remove the cell for inspection, clean it if necessary. See "Maintenance". Cover the pool with a pool cover for 2 days with the device running and then test the water using the test strips. If the pool is clean and clear, add stabilizer to the water and then test the water with the device running.
INSUFFICIENT COPPER ION LEVEL	 Insufficient operating hours. The PH is too high. The bather load has increased. Clogged or dirty copper electrode. Copper electrode defective. 	 Increase operating time per day. See "Operating Instructions". Use PH decrease chemical to adjust, contact your local pool chemical store. Increase the operating time per day. See "Operating Instructions". Remove the cell for inspection, clean it if necessary. See "Maintenance". Contact Intex Service Center.
POOL IS STAINED	High copper ion concentration.	Drain about 20% of the pool water and add fresh water to decrease the copper ion concentration below 0.2ppm. Add aluminum sulfate: 1000 liters water need around 2g (1000 gals need 0.27 ounce) or aluminum potassium sulfate: 1000 liters water need around 3g (1000 gals need 0.4 ounce) to pool. Use a lemon based cleaning product (preferably containing citric acid). Don't scrub with aggressive cleaning products because this might etch the underlying surface.
WHITE FLAKES IN THE WATER	Excessive calcium hardness is present in pool water.	Drain about 20 to 25% of the pool water and add fresh water to decrease the calcium hardness. Inspect the electrolytic cell for scale buildup. Clean the electrolytic cell if necessary.
NO LED DISPLAY	No power supply.RCD/GFCI has not reseted.A power fuse has blown.LED failure.	Plug the cell cord firmly into the cell housing receptacle. Find out the switch and turn on. Reset the RCD/GFCI. Contact Intex Service Center.
GREEN HAIR	High copper ion concentration.	Drain about 20% of the pool water and add fresh water to decrease the copper ion concentration below 0.2ppm. Add aluminum sulfate: 1000 liters water need around 2g (1000 gals need 0.27 ounce) or aluminum potassium sulfate: 1000 liters water need around 3g (1000 gals need 0.4 ounce) to pool. Use 'Ultra-Swim' shampoo, or shampoo containing chelating agents.

132*F*

English

TROUBLESHOOTING GUIDE (continued)

LED PANEL PROBLEM SOLUTION CODE LED Panel Code Flash & Alarm On (NOTE: Always turn off the power before cleaning and servicing). 1. Filter pump not attached to Ensure filter pump is attached and system and/or switch on. operating. See "Setup Instruction". 2. Circulation line is blocked. If your unit has plunger valves, ensure that they are open. Clear your filter cartridge and cell from debris and dirt. See "Maintenance". Release all trapped air in the circulation line. See the filter pump manual. 3. Incorrect inlet and outlet hose Check the direction of the inlet and the direction. outlet hose. Reverse the hoses if necessary. See "Set Up Instructions". Scale on the flow sensor. Clean the flow sensor, paying special attention to the hinge. See "Maintenance". 5. Flow sensor cord is loose. Plug the flow sensor firmly into the flow sensor receptacle. 6. Inner timer conflict between Reset both timers on the filter pump and filter pump and saltwater system. saltwater system. See "Boost Cycle". Flow sensor failure. Contact Intex Service Center. Remove the electrolytic cell for 1. Dirt or scale on titanium plates. inspection. Clean it if necessary. See "Maintenance". 2. Low salt level / No salt. Add salt. See "Salt & Pool Water Volumes". 3. Electrolytic cell cord is loose. Ensure that the cell cord is plugged firmly into the cell housing receptacle. 4. Possible electrolytic cell failure. Contact Intex Service Center. Replace the cell if needed. Partially drain the pool and refill it with fresh water. See "Salt & Pool Water 1. High salt level. Volumes". Household voltage is too high or too low 1. Display and all lights are off - the (± 20%). Check the voltage is within the system does not power up. range stated on the device housing. Contact Intex Service Center.

IMPORTANT

If you continue to experience difficulty, please contact our Consumer Service Department for assistance. See separate "Authorized Service Centers" sheet.

GENERAL AQUATIC SAFETY

Water recreation is both fun and therapeutic. However, it involves inherent risks of injury and death. To reduce your risk of injury, read and follow all product, package and package insert warnings and instructions. Remember, however, that product warnings, instructions and safety guidelines cover some common risks of water recreation, but do not cover all risks and dangers.

For additional safeguards, also familiarize yourself with the following general guidelines as well as guidelines provided by nationally recognized Safety Organizations:

- Demand constant supervision. A competent adult should be appointed as a "lifeguard" or water watcher, especially when children are in and around the pool.
- Learn to swim.
- · Take the time to learn CPR and first aid.
- Instruct anyone who is supervising pool users about potential pool hazards and about the use of protective devices such as locked doors, barriers, etc.
- Instruct all pool users, including children what to do in case of an emergency.
- Always use common sense and good judgement when enjoying any water activity.
- Supervise, supervise, supervise.

132

English

LIMITED WARRANTY

Your Krystal Clear[™] Saltwater System has been manufactured using the highest quality materials and workmanship. All Intex products have been inspected and found free of defects prior to leaving the factory. This Limited Warranty applies only to the Krystal Clear[™] Saltwater System and accessories listed below. The following provision is only valid within the European member states countries: The legal regulation of Directive 1999/44/EC will not be effected by this Intex warranty.

The provisions of this Limited Warranty apply only to the original purchaser and is not transferable. This Limited Warranty is valid for the period noted below from the date of the initial retail purchase. Keep your original sales receipt with this manual, as proof of purchase will be required and must accompany warranty claims or the Limited Warranty is invalid.

Krystal Člear[™] Saltwater System Warranty – 2 Years Titanium electrode Warranty – 1 Year Hoses, Plunger Valves & Fittings Warranty – 180 days

If a manufacturing defect is found within the periods noted above, please contact the appropriate Intex Service Center listed in the separate "Authorized Service Centers" sheet. The Service Center will determine the validity of the claim.

IMPLIED WARRANTIES ARE LIMITED TO THE TERMS OF THIS WARRANTY AND IN NO EVENT SHALL INTEX, THEIR AUTHORIZED AGENTS OR EMPLOYEES BE LIABLE TO THE BUYER OR ANY OTHER PARTY FOR DIRECT OR CONSEQUENTIAL DAMAGES OR LIABILITIES. Some countries, or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This Limited Warranty does not apply if the products are subject to negligence, abnormal use or operation, accident, improper operation, improper voltage or current contrary to operating instructions, or to damage by circumstances beyond Intex's control, including but not limited to, ordinary wear and tear and damage caused by exposure to fire, flood, freezing, rain, or other external environmental forces. This Limited Warranty applies only to those parts and components sold by Intex. The Limited Warranty does not cover unauthorized alterations, repairs or disassembly by anyone other than Intex Service Center personnel.

The costs associated with the loss of pool water, chemicals or water damage are not covered by this warranty. Injury or damage to any property or person is not covered by this warranty.