


ABB Drives

Modbus Protocol Manual RS-485 Adapter Module FSCA-01



RS-485 Adapter Module
FSCA-01

Modbus Protocol Manual

3AUA0000044530 REV A
EN
EFFECTIVE: 17.11.2008

Safety instructions

Overview

This chapter states the general safety instructions that must be followed when installing and operating the FSCA-01 RS-485 Adapter Module.

The material in this chapter must be studied before attempting any work on, or with, the unit.

In addition to the safety instructions given below, read the complete safety instructions of the specific drive you are working on.

General safety instructions



WARNING! All electrical installation and maintenance work on the drive should be carried out by qualified electricians.

The drive and adjoining equipment must be properly earthed.

Do not attempt any work on a powered drive. After switching off the mains, always allow the intermediate circuit capacitors 5 minutes to discharge before working on the frequency converter, the motor or the motor cable. It is good practice to check (with a voltage indicating instrument) that the drive is in fact discharged before beginning work.

The motor cable terminals of the drive are at a dangerously high voltage when mains power is applied, regardless of motor operation.

There can be dangerous voltages inside the drive from external control circuits even when the drive mains power is shut off. Exercise appropriate care when working on the unit. Neglecting these instructions can cause physical injury or death.

Table of contents

Safety instructions	5
Overview	5
General safety instructions	5
 Table of contents	 7
 Introduction	 9
Intended audience	9
Before you start	9
What this manual contains	9
Further information	10
 Overview	 11
Overview	11
Modbus/RTU	11
Modbus/RTU on FSCA-01 RS-485 Adapter Module	11
Compatibility	12
 Drive configuration	 13
Overview	13
Modbus connection configuration	13
Control locations	21
 Master configuration	 23
Overview	23
Configuring the system	23
Modbus register maps	23

Communication profiles	25
Overview	25
Communication profiles	25
ABB Drives communication profile	27
Control Word and Status Word	27
References	27
Actual values	29
Communication	35
Overview	35
Register addressing	35
Function codes	36
Encapsulated interface transport / Read device identification	37
Exception codes	38
Communication profiles	39
ABB Drives Profile - Classic	39
ABB Drives Profile - Enhanced	40
Transparent 16-bit	42
Transparent 32-bit	44
Diagnostics	47
LED indications	47
Internal error code registers	48
Definitions	49

Introduction

Intended audience

The manual is intended for people responsible for installing, commissioning and using an FSCA-01 RS-485 Adapter Module for Modbus/RTU communication. The reader is expected to have basic knowledge of electrical fundamentals, electrical wiring practices and operating of the drive.

Before you start

It is assumed that the drive is installed and ready to operate before starting the installation of the extension module.

In addition to conventional installation tools, have the drive manuals available during the installation as they contain important information not included in this manual. The drive manuals are referred to at various points of this document.

What this manual contains

This manual contains information on the configuration and use of the FSCA-01 RS-485 Adapter Module with the Modbus/RTU protocol.

Safety instructions are featured in the first few pages of this manual.

Overview contains short descriptions of the Modbus/RTU protocol and the adapter module.

Drive configuration explains how to program the drive before the communication through the adapter module can be started.

Master configuration explains how to program the Modbus/RTU master before communication through the adapter module can be started.

Communication profiles describes the communication profiles used in the communication between the Modbus/RTU master, the adapter module and the drive.

Communication contains a description of the Modbus/RTU functionality supported by the adapter module.

Diagnostics explains how to trace faults with the status LEDs on the adapter module.

Definitions explains definitions and abbreviations concerning Modbus/RTU on the adapter module.

Further information

Further information on the Modbus/RTU protocol is available on the world wide web from www.modbus.org.

Overview

Overview

The FSCA-01 RS-485 Adapter Module supports the Modbus/RTU network protocol. This chapter contains a short description of Modbus/RTU and the adapter module.

For information on RS-485 standard, see *FSCA-01 RS-485 Adapter Module Hardware Manual* (3AUA0000044521 Rev A [English]).

Modbus/RTU

Modbus/RTU is a variant of the Modbus family of simple, vendor-neutral communication protocols intended for supervision and control of automation equipment. The Modbus/RTU implementation in the FSCA-01 RS-485 Adapter Module is done according to *Modbus Application Protocol Specification v1.1b*.

You can find more information on the RTU transmission mode and cabling in *MODBUS over serial line specification and implementation guide V1.02* in www.modbus.org.

The supported Modbus commands are listed in chapter [Communication](#).

Modbus/RTU on FSCA-01 RS-485 Adapter Module

The FSCA-01 RS-485 Adapter Module is an optional device for ABB Drives which enables the connection of the drive to an RS-485 network. The module supports a variety of higher-level communications protocols, including Modbus/RTU.

Through the FSCA-01 RS-485 Adapter Module it is possible to:

- give control commands to the drive (Start, Stop, Run enable, etc.)
- feed a motor speed or torque reference to the drive

- give a process actual value or a process reference to the PID controller of the drive
- read status information and actual values from the drive
- change drive parameter values
- reset a drive fault.

The adapter module acts as a Modbus/RTU slave with support for ABB Drives and Transparent profiles. The Modbus commands that the FSCA-01 RS-485 Adapter Module supports are discussed in chapter [Communication](#).

The adapter module is mounted into an option slot on the motor control board of the drive. See the drive documentation for module placement options.

Compatibility

The FSCA-01 RS-485 Adapter Module is compatible with all Modbus/RTU masters that support *Modbus Application Protocol Specification v1.1b*.

Drive configuration

Overview

This chapter gives information on configuring the FSCA-01 RS-485 Adapter Module for use with Modbus/RTU.

Modbus connection configuration

After the adapter module has been mechanically and electrically installed according to the *FSCA-01 RS-485 Adapter Module Hardware Manual* (3AUA0000044521 Rev A [English]), you must prepare the drive for communication with the module.

The detailed procedure of activating the module for Modbus communication with the drive depends on the drive type. Normally, you must adjust a parameter to activate the communication (see the drive documentation).

As communication between the drive and the adapter module is established, several configuration parameters are copied to the drive. You must first check the parameters listed in the following parameter tables and adjust them where necessary. The alternative selections for these parameters are discussed in more detail below the tables.

Note: The new settings take effect only when the module is powered up the next time or when a Fieldbus Adapter parameter refresh command is given (see the drive documentation).

Table 1. FSCA-01 configuration parameters - group A *

Par. no.	Parameter name	Alternative settings	Default setting
1	FBA TYPE	(Read-only)	RS-485
2	PROTOCOL/ PROFILE	Modbus: (0) ABB Drives Classic (1) ABB Drives Enhanced (2) Transparent 16-bit (3) Transparent 32-bit	Modbus: (0) ABB Drives Classic
3	STATION ID	1...247	1
4	BAUD RATE	(0) 9.6 kbit/s (1) 19.2 kbit/s (2) 38.4 kbit/s (3) 57.6 kbit/s (4) 115.2 kbit/s	(0) 9.6 kbit/s
5	PARITY	(0) 8 NONE 1 (1) 8 NONE 2 (2) 8 EVEN 1 (3) 8 ODD 1	(0) 8 NONE 1
6	MODBUS TIMEOUT	0...65535	0
7	TIMEOUT MODE	(0) NONE (1) ANY MESSAGE (2) CONTROL WRITE	0
8	OK MESSAGES	0...65535	
9	CRC ERRORS	0...65535	
10	UART ERRORS	0...65535	
11... 26	Reserved		

* Actual parameter group number depends on the drive type. Eg, group A equals to parameter group 51 in ACS350 and ACSM1.

1 FBA TYPE

This parameter shows the fieldbus adapter type as detected by the drive.

If this parameter is undefined, the communication between the drive and the module has not been established.

2 PROTOCOL/PROFILE

Selects the application protocol and communication profile for the network connection.

- (0) Modbus protocol with ABB Drives Classic profile
- (1) Modbus protocol with ABB Drives Enhanced profile
- (2) Modbus protocol with Transparent 16-bit profile
- (3) Modbus protocol with Transparent 32-bit profile

3 STATION ID

Defines the address of the device. Two units with the same address are not allowed on-line.

4 BAUD RATE

Defines the baud rate of the link.

- (0) 9.6 kbit/s
- (1) 19.2 kbit/s
- (2) 38.4 kbit/s
- (3) 57.6 kbit/s
- (4) 115.2 kbit/s

5 PARITY

Defines the use of parity and stop bit(s) and the data length. The same settings must be used in all on-line stations.

- (0) 8 NONE 1 No parity bit, one stop bit, 8 data bits
- (1) 8 NONE 2 No parity bit, two stop bits, 8 data bits
- (2) 8 EVEN 1 Even parity indication bit, one stop bit, 8 data bits
- (3) 8 ODD 1 Odd parity indication bit, one stop bit, 8 data bits

6 MODBUS TIMEOUT

The Modbus protocol does not specify a timeout mechanism for the application layer. ABB Drives and the FSCA-01 RS-485 Adapter Module provide a Modbus timeout method as it may be desired for drive control.

The timeout is

MODBUS TIMEOUT value * 100 milliseconds.

For example, a MODBUS TIMEOUT value of 22 would result in a timeout of

$22 * 100 \text{ milliseconds} = 2.2 \text{ seconds}$

TIMEOUT MODE is used to define which Modbus register accesses reset the timeout counter. See configuration parameters group A, parameter 7 for defining the TIMEOUT MODE.

When a Modbus timeout occurs, the adapter module signals the drive that communication with the master has been lost. The drive configuration determines how it responds. For example, if you configure the MODBUS TIMEOUT as 250 ms and the drive is configured to fault on a communication failure with a delay of 500 ms, then the drive faults 750 ms after the communication is lost.

7 TIMEOUT MODE

Defines which Modbus register accesses reset the timeout counter.

- (0) NONE Modbus timeout feature is disabled.
- (1) ANY MESSAGE Timeout counter is reset when any Modbus register of the drive is accessed.
- (2) CONTROL WRITE Timeout counter is reset when the drive receives either a new Control Word or new Reference value (REF1 or REF2) from the Modbus master.

8 OK MESSAGES

Number of valid messages that the drive has received.

9 CRC ERRORS

Number of messages with a Cyclic Redundancy Check (CRC) error that the drive has received. If the number is high, check the CRC calculation for possible errors.

Note: High electromagnetic noise levels may generate errors.

10 UART ERRORS

Number of messages that the drive has received with other communication errors.

11...20 Reserved

Table 2. FSCA-01 configuration parameters - group B*

Par. no. **	Parameter name	Alternative settings	Default setting
1	DATA OUT 1 (master to drive)	0 to 9999 Format: xyy , where xx = parameter group and yy = parameter index	0
2	DATA OUT 2	See DATA OUT 1 above.	0
3	DATA OUT 3	See DATA OUT 1 above.	0
4	DATA OUT 4	See DATA OUT 1 above.	0
5	DATA OUT 5	See DATA OUT 1 above.	0
6	DATA OUT 6	See DATA OUT 1 above.	0
7	DATA OUT 7	See DATA OUT 1 above.	0
8	DATA OUT 8	See DATA OUT 1 above.	0
9	DATA OUT 9	See DATA OUT 1 above.	0
10	DATA OUT 10	See DATA OUT 1 above.	0
11	DATA OUT 11	See DATA OUT 1 above.	0
12	DATA OUT 12	See DATA OUT 1 above.	0

* Actual parameter group number depends on the drive type. Eg, group B equals to parameter group 55 in ACS350 and group 53 in ACSM1.

** Number of parameters in this group may vary by drive.

1 DATA OUT 1

For Modbus register maps that include drive parameters, this parameter specifies which parameter's value is written to when the register corresponding to DATA OUT 1 is written by the Modbus master. A decimal number specifies the content as follows.

0	Not used
1 - 99	Virtual address area of the drive
101 - 9999	Parameter area of the drive

Parameter numbers are formatted as xxyy, where xx is the parameter group number (1 to 99) and yy is the parameter index within that group (01 to 99). For example, enter parameter 99.02 as 9902.

2...10 DATA OUT 2 to DATA OUT 10

See DATA OUT 1 above.

Table 3. FSCA-01 configuration parameters - group C*

Par. no. **	Parameter name	Alternative settings	Default setting
1	DATA IN 1 (drive to master)	0 to 9999 Format: xyyy , where xx = parameter group and yy = parameter index	0
2	DATA IN 2	See DATA IN 1 above.	0
3	DATA IN 3	See DATA IN 1 above.	0
4	DATA IN 4	See DATA IN 1 above.	0
5	DATA IN 5	See DATA IN 1 above.	0
6	DATA IN 6	See DATA IN 1 above.	0
7	DATA IN 7	See DATA IN 1 above.	0
8	DATA IN 8	See DATA IN 1 above.	0
9	DATA IN 9	See DATA IN 1 above.	0
10	DATA IN 10	See DATA IN 1 above.	0
11	DATA IN 11	See DATA IN 1 above.	0
12	DATA IN 12	See DATA IN 2 above.	0

*Actual parameter group number depends on the drive type. Eg, group C equals to parameter group 54 in ACS350 and group 52 in ACSM1.

** Number of parameters in this group may vary by drive.

1 DATA IN 1

For Modbus register maps that include drive parameters, this parameter specifies which parameter's value is read from when the register corresponding to DATA IN 1 is read by the Modbus master. For the content, see configuration parameter group B table, parameter 1 (DATA OUT 1).

2...10 DATA IN 2 to DATA IN 10

See DATA IN 1 above.

Control locations

ABB Drives can receive control information from multiple sources including digital inputs, analogue inputs, the drive control panel and a communication module (eg, the FSCA-01 RS-485 Adapter Module). ABB Drives allow you to separately determine the source for each type of control information (Start, Stop, Direction, Reference, Fault Reset, etc). To give the fieldbus master the most complete control over the drive, the communication module must be selected as source for this information. See the user documentation of the drive for information on the selection parameters.

Master configuration

Overview

This chapter gives information on configuring the Modbus/RTU master for communication through the FSCA-01 RS-485 Adapter Module.

Configuring the system

After the adapter module has been mechanically and electrically installed according to the instructions in the *FSCA-01 RS-485 Adapter Module Hardware Manual* (3AUA0000044521 Rev A [English]) and has been initialized by the drive, the master must be prepared for communication with the module.

Please refer to the master documentation for information on configuring the system for communication with the adapter module.

Modbus register maps

The PROFILE configuration parameter selects the Modbus register map that the adapter module presents to the Modbus master. For more information on the parameter, see chapter [Drive configuration](#).

For the Modbus register map definitions, see chapter [Communication](#).

For the definitions of Control Word, Status Word, References and Actual values for a given communication profile, see chapter [Communication profiles](#).

Communication profiles


Overview

This chapter describes the communication profiles used in the communication between the Modbus/RTU master, the FSCA-01 RS-485 Adapter Module and the drive.

Communication profiles

The communication profiles are ways of conveying control commands (Control Word, Status Word, References and Actual values) between the Modbus master and the drive.

You can configure the FSCA-01 RS-485 Adapter Module to provide either the ABB Drives Profile or one of the two Transparent modes for 16 and 32 bit words respectively. For the ABB Drives Profile, the adapter module converts the data to the DCU profile. For detailed information, see the drive documentation. For the Transparent modes, no data conversion takes place.



*To be used if the drive does not support the speed control mode of the DCU communication profile or if the ABB Drives profile does not cover all needed functionality like the position control.

Figure 4. Communication profiles of the FSCA-01 RS-485 Adapter Module

ABB Drives communication profile

Control Word and Status Word

The Control Word is the principal means for controlling the drive from a fieldbus system. The fieldbus client station sends the Control Word to the drive through the adapter module. The drive switches between its states according to the bit-coded instructions of the Control Word and returns status information to the client in the Status Word.

The contents of the Control Word and the Status Word are detailed in Tables 7 and 8 respectively. The drive states are presented in the ABB Drives profile state machine (Figure 9).

References


References are 16-bit words containing a sign bit and a 15-bit integer. A negative reference (indicating reversed direction of rotation) is formed by calculating the two's complement from the corresponding positive reference.

ABB Drives can receive control information from multiple sources including analogue and digital inputs, the drive control panel and a communication module (eg, the FSCA-01 RS-485 Adapter Module). To have the drive controlled through the fieldbus, the module must be defined as the source for control information, eg, Reference.

Scaling

References are scaled as shown below.

Note: The values of REF1 MAX* and REF2 MAX are set by drive parameters. See the drive documentation for further information.



*) SPEED SCALING in ACSM1

Figure 5. Reference scaling

Actual values

Actual values are 16-bit words containing information on the operation of the drive. A drive parameter selects the monitored functions.

Scaling

The actual values are scaled as shown below.

Note: The values of REF1 MAX and REF2 MAX are set by drive parameters. See the drive documentation for further information.




Figure 6. Actual value scaling

Table 7. The Control Word for the ABB Drives communication profile. The upper case boldface text refers to the states shown in Figure 9.

Bit	Name	Value	STATE/Description
0	OFF1_ CONTROL	1	Proceed to READY TO OPERATE .
		0	Stop along currently active deceleration ramp. Proceed to OFF1 ACTIVE ; proceed to READY TO SWITCH ON unless other interlocks (OFF2, OFF3) are active.
1	OFF2_ CONTROL	1	Continue operation (OFF2 inactive).
		0	Emergency OFF, coast to stop. Proceed to OFF2 ACTIVE , proceed to SWITCH-ON INHIBITED .
2	OFF3_ CONTROL	1	Continue operation (OFF3 inactive).
		0	Emergency stop, stop within time defined by drive parameter. Proceed to OFF3 ACTIVE ; proceed to SWITCH-ON INHIBITED . Warning: Ensure motor and driven machine can be stopped using this stop mode.
3	INHIBIT_ OPERATION	1	Proceed to OPERATION ENABLED . Note: Run enable signal must be active; see the drive documentation. If the drive is set to receive the Run enable signal from the fieldbus, this bit activates the signal.
		0	Inhibit operation. Proceed to OPERATION INHIBITED .
4	RAMP_OUT_ ZERO	1	Normal operation. Proceed to RAMP FUNCTION GENERATOR: OUTPUT ENABLED .
		0	Force Ramp Function Generator output to zero. Drive ramps to stop (current and DC voltage limits in force).

Bit	Name	Value	STATE/Description
5	RAMP_HOLD	1	Enable ramp function. Proceed to RAMP FUNCTION GENERATOR: ACCELERATOR ENABLED .
		0	Halt ramping (Ramp Function Generator output held).
6	RAMP_IN_ZERO	1	Normal operation. Proceed to OPERATING . Note: This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.
		0	Force Ramp Function Generator input to zero.
7	RESET	0=>1	Fault reset if an active fault exists. Proceed to SWITCH-ON INHIBITED . Note: This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.
		0	Continue normal operation.
8 to 9	Reserved.		
10	REMOTE_CMD	1	Fieldbus control enabled.
		0	Control Word <> 0 or Reference <> 0: Retain last Control Word and Reference. Control Word = 0 and Reference = 0: Fieldbus control enabled. Reference and deceleration/acceleration ramp are locked.
11	EXT_CTRL_LOC	1	Select External Control Location EXT2. Effective if control location parameterised to be selected from fieldbus.
		0	Select External Control Location EXT1. Effective if control location parameterised to be selected from fieldbus.
12 to 15	Drive-specific (For information, see the drive documentation.)		

Table 8. The Status Word for the ABB Drives communication profile. The upper case boldface text refers to the states shown in Figure 9.

Bit	Name	Value	STATE/Description
0	RDY_ON	1	READY TO SWITCH ON.
		0	NOT READY TO SWITCH ON.
1	RDY_RUN	1	READY TO OPERATE.
		0	OFF1 ACTIVE.
2	RDY_REF	1	OPERATION ENABLED.
		0	OPERATION INHIBITED.
3	TRIPPED	1	FAULT.
		0	No fault.
4	OFF_2_STA	1	OFF2 inactive.
		0	OFF2 ACTIVE.
5	OFF_3_STA	1	OFF3 inactive.
		0	OFF3 ACTIVE.
6	SWC_ON_INHIB	1	SWITCH-ON INHIBITED.
		0	–
7	ALARM	1	Warning/Alarm.
		0	No warning/alarm.
8	AT_SETPOINT	1	OPERATING. Actual value equals Reference = is within tolerance limits, i.e. in speed control, speed error is 10% max. of nominal motor speed.
		0	Actual value differs from Reference = is outside tolerance limits.
9	REMOTE	1	Drive control location: REMOTE (EXT1 or EXT2).
		0	Drive control location: LOCAL.

Bit	Name	Value	STATE/Description
10	ABOVE_ LIMIT	1	Actual frequency or speed equals or exceeds supervision limit (set by drive parameter). Valid in both directions of rotation.
		0	Actual frequency or speed within supervision limit.
11	EXT_CTRL_ LOC	1	External Control Location EXT2 selected.
		0	External Control Location EXT1 selected.
12	EXT_RUN_ ENABLE	1	External Run Enable signal received.
		0	No External Run Enable signal received.
13 to 14	Drive-specific (For information, see the drive documentation.)		
15		1	Communication error detected by fieldbus adapter module.
		0	Fieldbus adapter communication OK.




Figure 9. ABB State Transition Diagram

Communication

Overview

This chapter describes the Modbus communication protocol for the FSCA-01 RS-485 Adapter Module. For detailed information on Modbus communication, refer to *Modbus Application Protocol Specification v1.1b*.

Register addressing

The address field of Modbus requests for accessing holding registers is 16 bits. This allows the Modbus protocol to support addressing of 65536 holding registers

Historically, Modbus master devices used 5-digit decimal addresses from 40001 to 49999 to represent holding register addresses. The 5-digit decimal addressing limited to 9999 the number of holding registers that could be addressed.

Modern Modbus master devices typically provide a means to access the full range of 65536 Modbus holding registers. One of these methods is to use 6-digit decimal addresses from 400001 to 465536. This manual uses 6-digit decimal addressing to represent Modbus holding register addresses.

Modbus master devices that are limited to the 5-digit decimal addressing, may still access registers 400001 to 409999 by using 5-digit decimal addresses 40001 to 49999. Registers 410000-465536 are inaccessible to these masters.

Note: Register addresses of the 32-bit parameters cannot be accessed by using 5-digit register numbers.

Function codes

The FSCA-01 RS-485 Adapter Module supports the Modbus function codes shown below.

Function code	Name	Description
03h	Read Holding Registers	Reads the contents of a contiguous block of holding registers in a server device.
06h	Write Single Register	Writes a single holding register in a server device.
08h	Diagnostics	<p>Provides a series of tests for checking the communication between the master and the slave devices, or for checking various internal error conditions within the slave.</p> <p>The following subcodes are supported:</p> <p>00 Return Query Data: The data passed in the request data field is to be returned in the response. The entire response message should be identical to the request.</p> <p>01 Restart Communications Option: The serial line port of the slave device must be initialized and restarted, and all of its communication event counters cleared. If the port is in the Listen Only mode, no response is returned. If the port is not in the Listen Only mode, a normal response is returned before the restart.</p> <p>04 Force Listen Only Mode: Forces the addressed slave device to the Listen Only mode. This isolates it from the other devices on the network, allowing them to continue communicating without interruption from the addressed remote device. No response is returned. The only function that will be processed after this mode is entered is the Restart Communications Option function (subcode 01).</p>
10h	Write Multiple Registers	Writes the contents of a contiguous block of holding registers in a server device.
17h	Read/Write Multiple Registers	Writes the contents of a contiguous block of holding registers in a server device, then reads the contents of a contiguous block of holding registers (same or different than those written) in a server device.

Function code	Name	Description
2Bh/0Eh	Encapsulated Interface Transport / Read Device Identification	Allows reading identification and other information of the server. Parameter "Read Device ID code" allows to define three access types: 01: Request to get the basic device identification (stream access) 02: Request to get the regular device identification (stream access) 04: Request to get one specific identification object (individual access)

Encapsulated interface transport / Read device identification

The FSCA-01 RS-485 Adapter Module supports the Modbus EIT/RDI objects shown below.

Object ID	Name
00h	Vendor Name
01h	Product Code
02h	Major/Minor Revision
03h	Vendor URL
04h	Product Name

Exception codes

The FSCA-01 RS-485 Adapter Module supports the Modbus exception codes shown below.

Exception code	Name	Description
01h	ILLEGAL FUNCTION	The function code received in the query is not an allowable action for the server.
02h	ILLEGAL DATA ADDRESS	The data address received in the query is not an allowable address for the server.
03h	ILLEGAL DATA VALUE	A value contained in the query data field is not an allowable value for the server.
04h	SLAVE DEVICE FAILURE	An unrecoverable error occurred while the server was attempting to perform the requested action.
06h	SLAVE DEVICE BUSY	The slave is engaged in processing a long-duration command. The master should retransmit the message later when the server is free.

Communication profiles

Modbus is an application layer messaging protocol. It describes how data is transferred between a master and a slave, but not the meaning of the data. Communication profiles define the meaning of the data.

ABB Drives Profile - Classic

The ABB Drives Profile - Classic communication profile provides register mapped access to the Control, Status, Reference and Actual values of the ABB Drives Profile in the classic format for backward compatibility.

Register Address*, **	Register Data (16-bit)
400001	ABB Drives Profile Control
400002	ABB Drives Profile Reference 1
400003	ABB Drives Profile Reference 2
400004	ABB Drives Profile Status
400005	ABB Drive Profile Actual 1
400006	ABB Drive Profile Actual 2
400101-409999	Drive Parameter Access (16-bit) Register Address = $400000 + 100 \times \text{Group} + \text{Index}$ Example for Drive Parameter 3.18 $400000 + 100 \times 3 + 18 = 400318$ Register addressing of the 32-bit parameters (not supported with ACS350): $420000 + 200 \times \text{Group} + 2 \times \text{Index}$ Example for Drive Parameter 1.27 $420000 + 200 \times 1 + 2 \times 27 = 420254$

* 6-digit register addressing (400001) is used instead of 5-digit register addressing (40001) to describe register map. See section [Register addressing](#) for additional information.

** Register addresses of the 32-bit parameters cannot be accessed by using 5-digit register numbers.

ABB Drives Profile - Enhanced

The ABB Drives Profile - Enhanced communication profile provides register mapped access to the Control, Status, Reference and Actual values of the ABB Drives Profile. The mapping of the registers has been enhanced to allow writing of Control and reading of Status in a single Read/Write Multiple Register request.

Note: If 32-bit parameters are mapped to DATA IN or DATA OUT, adjust the length of the request message to fit both words of the parameter.

Register Address*, **	Register Data (16-bit)
400001	ABB Drives Profile Control
400002	ABB Drives Profile Reference 1
400003	ABB Drives Profile Reference 2
400004	DATA OUT 1
400005	DATA OUT 2
400006	DATA OUT 3
400007	DATA OUT 4
400008	DATA OUT 5
400009	DATA OUT 6
400010	DATA OUT 7
400011	DATA OUT 8
400012	DATA OUT 9
400013	DATA OUT 10
400014	DATA OUT 11
400015	DATA OUT 12
400051	ABB Drives Profile Status
400052	ABB Drive Profile Actual 1
400053	ABB Drive Profile Actual 2
400054	DATA IN 1
400055	DATA IN 2
400056	DATA IN 3
400057	DATA IN 4
400058	DATA IN 5
400059	DATA IN 6

Register Address*, **	Register Data (16-bit)
400060	DATA IN 7
400061	DATA IN 8
400062	DATA IN 9
400063	DATA IN 10
400064	DATA IN 11
400065	DATA IN 12
400101-409999	<p>Drive Parameter Access (16-bit)</p> <p>Register Address = $400000 + 100 \times \text{Group} + \text{Index}$</p> <p>Example for Drive Parameter 3.18 $400000 + 100 \times 3 + 18 = 400318$</p> <p>Register addressing of the 32-bit parameters (not supported with ACS350):</p> <p>$420000 + 200 \times \text{Group} + 2 \times \text{Index}$</p> <p>Example for Drive Parameter 1.27 $420000 + 200 \times 1 + 2 \times 27 = 420254$</p>

* 6-digit register addressing (400001) is used instead of 5-digit register addressing (40001) to describe register map. See section [Register addressing](#) for additional information.

** Register addresses of the 32-bit parameters cannot be accessed by using 5-digit register numbers.

Transparent 16-bit

The Transparent 16-bit communication profile provides unaltered 16-bit access to the configured drive profile.

Register Address*, **	Register Data (16-bit)
400001	Native Drive Profile Control
400002	Native Drive Profile Reference 1
400003	Native Drive Profile Reference 2
400004	DATA OUT 1
400005	DATA OUT 2
400006	DATA OUT 3
400007	DATA OUT 4
400008	DATA OUT 5
400009	DATA OUT 6
400010	DATA OUT 7
400011	DATA OUT 8
400012	DATA OUT 9
400013	DATA OUT 10
400014	DATA OUT 11
400015	DATA OUT 12
400051	Native Drive Profile Status
400052	Native Drive Profile Actual 1
400053	Native Drive Profile Actual 2
400054	DATA IN 1
400055	DATA IN 2
400056	DATA IN 3
400057	DATA IN 4
400058	DATA IN 5
400059	DATA IN 6
400060	DATA IN 7
400061	DATA IN 8
400062	DATA IN 9
400063	DATA IN 10
400064	DATA IN 11
400065	DATA IN 12

Register Address*, **	Register Data (16-bit)
400101-409999	Drive Parameter Access (16-bit) Register Address = 400000 + 100 x Group + Index Example for Drive Parameter 3.18 $400000 + 100 \times 3 + 18 = 400318$ Register addressing of the 32-bit parameters (not supported with ACS350): $420000 + 200 \times \text{Group} + 2 \times \text{Index}$ Example for Drive Parameter 1.27 $420000 + 200 \times 1 + 2 \times 27 = 420254$

* 6-digit register addressing (400001) is used instead of 5-digit register addressing (40001) to describe register map. See section [Register addressing](#) for additional information.

** Register addresses of the 32-bit parameters cannot be accessed by using 5-digit register numbers.

Transparent 32-bit

The Transparent 32-bit communication profile provides unaltered 32-bit access to the configured drive profile.

Register Address*,**	Register Data (16-bit)
400001	Native Drive Profile Control - Least Significant 16-bits
400002	Native Drive Profile Control - Most Significant 16-bits
400003	Native Drive Profile Reference 1 - Least Significant 16-bits
400004	Native Drive Profile Reference 1 - Most Significant 16-bits
400005	Native Drive Profile Reference 2 - Least Significant 16-bits
400006	Native Drive Profile Reference 2 - Most Significant 16-bits
400007	DATA OUT 1
400008	DATA OUT 2
400009	DATA OUT 3
400010	DATA OUT 4
400011	DATA OUT 5
400012	DATA OUT 6
400013	DATA OUT 7
400014	DATA OUT 8
400015	DATA OUT 9
400016	DATA OUT 10
400017	DATA OUT 11
400018	DATA OUT 12
400051	Native Drive Profile Status - Least Significant 16-bits
400052	Native Drive Profile Status - Most Significant 16-bits
400053	Native Drive Profile Actual 1 - Least Significant 16-bits
400054	Native Drive Profile Actual 1 - Most Significant 16-bits
400055	Native Drive Profile Actual 2 - Least Significant 16-bits
400056	Native Drive Profile Actual 2 - Most Significant 16-bits
400057	DATA IN 1
400058	DATA IN 2
400059	DATA IN 3
400060	DATA IN 4
400061	DATA IN 5
400062	DATA IN 6
400063	DATA IN 7
400064	DATA IN 8
400065	DATA IN 9
400066	DATA IN 10
400067	DATA IN 11

Register Address*,**	Register Data (16-bit)
400068	DATA IN 12
400101-409999	Drive Parameter Access (16-bit) Register Address = $400000 + 100 \times \text{Group} + \text{Index}$ Example for Drive Parameter 3.18 $400000 + 100 \times 3 + 18 = 400318$ Register addressing of the 32-bit parameters (not supported with ACS350): $420000 + 200 \times \text{Group} + 2 \times \text{Index}$ Example for Drive Parameter 1.27 $420000 + 200 \times 1 + 2 \times 27 = 420254$


* 6-digit register addressing (400001) is used instead of 5-digit register addressing (40001) to describe register map. See section [Register addressing](#) for additional information.

** Register addresses of the 32-bit parameters cannot be accessed by using 5-digit register numbers.

Diagnostics

LED indications

The FSCA-01 RS-485 Adapter Module is equipped with three tricolor diagnostic LEDs. The LEDs are described below.



Name	Color	Function/State
HOST	Flashing green	Establishing communication to host
	Green	Connection to host OK
	Flashing red	Communication to host lost temporarily
	Orange	Configuration error
MODULE	Green	The device is operating in a normal condition
	Off	Communication to host lost temporarily (or no power applied to the device)
	Flashing red	Start-up initialization
	Orange	Configuration error
NETWORK	Off	No communication
	Flashing green	Communication activity on the interface
	Orange	Configuration error

Internal error code registers

A Modbus query can fail in many ways in the drive. The Modbus standard does not specify detailed error descriptions. The standard error codes are too generic. That is why the FSCA-01 RS-485 Adapter Module has an internal error register area.

The internal error register area is used if Modbus error code 0x04 occurs. The registers contain information about the last query. You can figure out the reason of the failure by reading the registers. The internal error register is cleared when a query has finished successfully.

Address	Registers (16-bit word)
(4)00090	Reset internal error registers (0 = do nothing, 1 = reset)
(4)00091	Function code of the failed query
(4)00092	Internal error code, see the error No.
(4)00093	Failed register
(4)00094	Last register that was written successfully
(4)00095	Last register that was read successfully

Error code	Description	Situation
0x00	No error	Used when a modbus query was successful.
0x02	Low or high limit exceeded	Change access with a value outside the value limits
0x03	Faulty subindex	Access to an unavailable subindex of an array parameter
0x05	Incorrect data type	Change access with a value that does not match the data type of the parameter
0x65	General error in drive communication	Undefined error when handling a Modbus query
0x66	Timeout	Timeout in drive communication when handling a Modbus query
0x70	Read-only	An attempt to write a non-zero value to a read-only drive parameter
0x71	Parameter group ended	An attempt to write to multiple parameter groups
0x72	MSB is not zero	An attempt to write a 16-bit parameter with a 32-register address and the MSB bytes are not zero
0x73	LSB query start	An attempt to access only the LSB register of the 32-bit parameter
0x74	MSB query end	An attempt to access only the MSB register of the 32-bit parameter

Definitions

Communication Module

Communication Module is a name for a device (eg, a fieldbus adapter) through which the drive is connected to an external serial communication network (eg, a fieldbus). A drive parameter activates the communication with the communication module.

Parameter

A parameter is an operating instruction for the drive. Parameters can be read and programmed using the drive control panel, or through the FSCA-01 RS-485 Adapter Module.



ABB Oy

AC Drives
P.O. Box 184

FI-00381 HELSINKI
FINLAND

Telephone +358 10 22 11

Fax +358 10 22 22681

Internet <http://www.abb.com>

ABB Inc.

Automation Technologies
Drives & Motors
16250 West Glendale Drive
New Berlin, WI 53151
USA

Telephone 262 785-3200

800-HELP-365

Fax 262 780-5135

3AUA0000044530 REV A EN
EFFECTIVE: 17.11.2008