# Micro Motion<sup>®</sup> Model 1700 Transmitters with Analog Outputs

Configuration and Use Manual





#### Safety messages

Safety messages are provided throughout this manual to protect personnel and equipment. Read each safety message carefully before proceeding to the next step.

#### Other information

Full product specifications can be found in the product data sheet. Troubleshooting information can be found in the configuration manual. Product data sheets and manuals are available from the Micro Motion web site at <a href="https://www.emerson.com">www.emerson.com</a>.

#### **Return policy**

Follow Micro Motion procedures when returning equipment. These procedures ensure legal compliance with government transportation agencies and help provide a safe working environment for Micro Motion employees. Micro Motion will not accept your returned equipment if you fail to follow Micro Motion procedures.

Return procedures and forms are available on our web support site at <a href="https://www.emerson.com">www.emerson.com</a>, or by phoning the Micro Motion Customer Service department.

#### **Emerson Flow customer service**

#### Email:

Worldwide: flow.support@emerson.com

Asia-Pacific: APflow.support@emerson.com

#### Telephone:

North and South America		Europe and Middle E	ast	Asia Pacific	
United States	800-522-6277	U.K.	0870 240 1978	Australia	800 158 727
Canada	+1 303-527-5200	The Netherlands	+31 (0) 704 136 666	New Zealand	099 128 804
Mexico	+41 (0) 41 7686 111	France	0800 917 901	India	800 440 1468
Argentina	+54 11 4837 7000	Germany	0800 182 5347	Pakistan	888 550 2682
Brazil	+55 15 3413 8000	Italy	8008 77334	China	+86 21 2892 9000
		Central & Eastern	+41 (0) 41 7686 111	Japan	+81 3 5769 6803
		Russia/CIS	+7 495 981 9811	South Korea	+82 2 3438 4600
		Egypt	0800 000 0015	Singapore	+65 6 777 8211
		Oman	800 70101	Thailand	001 800 441 6426
		Qatar	431 0044	Malaysia	800 814 008
		Kuwait	663 299 01		
		South Africa	800 991 390		
		Saudi Arabia	800 844 9564		
		UAE	800 0444 0684		

## Contents

Part I	Ge	tting started	
Chapter 1	Befo	re you begin	3
	1.1	About this manual	3
	1.2	Transmitter model code	3
	1.3	Communications tools and protocols	4
	1.4	Additional documentation and resources	4
Chapter 2	Quic	k start	5
	2.1	Power up the transmitter	5
	2.2	Check meter status	6
		2.2.1 Transmitter status reported by LED	6
	2.3	Make a startup connection to the transmitter	7
	2.4	(Optional) Adjust digital communications settings	7
	2.5	Verify mass flow measurement	7
	2.6	Verify the zero	
		2.6.1 Terminology used with zero verification and zero calibration	9
Daut II	<b>C</b> -	nfiguration and commissioning	
Part II		nfiguration and commissioning	
Chapter 3	Intro	duction to configuration and commissioning	
	3.1	Configuration flowchart	13
	3.2	Default values and ranges	15
	3.3	Enable access to the off-line menu of the display	15
	3.4	Disable write-protection on the transmitter configuration	15
	3.5	Restore the factory configuration	16
Chapter 4	Conf	igure process measurement	17
-	4.1	Configure mass flow measurement	
		4.1.1 Configure Mass Flow Measurement Unit	17
		4.1.2 Configure Flow Damping	20
		4.1.3 Configure Mass Flow Cutoff	
	4.2	Configure volume flow measurement for liquid applications	22
		4.2.1 Configure Volume Flow Type for liquid applications	
		4.2.2 Configure Volume Flow Measurement Unit for liquid applications	23
		4.2.3 Configure Volume Flow Cutoff	
	4.3	Configure GSV flow measurement	
		4.3.1 Configure Volume Flow Type for gas applications	
		4.3.2 Configure Standard Density of Gas	
		4.3.3 Configure Gas Standard Volume Flow Unit	
		4.3.4 Configure Gas Standard Volume Flow Cutoff	
	4.4	Configure Flow Direction	
		4.4.1 Options for Flow Direction	
	4.5	Configure density measurement	
		4.5.1 Configure Density Measurement Unit	39

		4.5.2 Configure two-phase flow parameters	40
		4.5.3 Configure Density Damping	42
		4.5.4 Configure Density Cutoff	43
	4.6	Configure temperature measurement	44
		4.6.1 Configure Temperature Measurement Unit	44
		4.6.2 Configure Temperature Damping	44
		4.6.3 Effect of Temperature Damping on process measurement	45
		4.6.4 Configure Temperature Input	45
	4.7	Configure pressure compensation	46
		4.7.1 Configure pressure compensation using ProLink III	46
		4.7.2 Configure pressure compensation using the Field Communicator	47
		4.7.3 Options for Pressure Measurement Unit	49
Chapter 5	Conf	igure device options and preferences	51
	5.1	Configure the transmitter display	51
		5.1.1 Configure the language used for the display	51
		5.1.2 Configure the process variables and diagnostic variables shown on the display	51
		5.1.3 Configure the number of decimal places (precision) shown on the display	53
		5.1.4 Configure the refresh rate of data shown on the display	54
		5.1.5 Enable or disable automatic scrolling through the display variables	54
		5.1.6 Enable or disable the display backlight	55
		5.1.7 Enable or disable Status LED Blinking	55
	5.2	Enable or disable operator actions from the display	56
		5.2.1 Enable or disable Totalizer Start/Stop from the display	56
		5.2.2 Enable or disable Totalizer Reset from the display	57
		5.2.3 Enable or disable the Acknowledge All Alerts display command	57
	5.3	Configure security for the display menus	58
	5.4	Configure response time parameters	59
		5.4.1 Configure Update Rate	60
		5.4.2 Configure Response Time	61
	5.5	Configure alert handling	62
		5.5.1 Configure Fault Timeout	62
		5.5.2 Configure Status Alert Severity	63
	5.6	Configure informational parameters	67
		5.6.1 Configure Sensor Serial Number	
		5.6.2 Configure Sensor Material	67
		5.6.3 Configure Sensor Liner Material	68
		5.6.4 Configure Sensor Flange Type	68
		5.6.5 Configure Descriptor	69
		5.6.6 Configure Message	69
		5.6.7 Configure Date	69
Chapter 6	Inte	grate the meter with the control system	71
•	6.1	Configure the transmitter channels	
	6.2	Configure the mA Output	
		6.2.1 Configure mA Output Process Variable	
		6.2.2 Configure Lower Range Value (LRV) and Upper Range Value (URV)	
		6.2.3 Configure AO Cutoff	
		6.2.4 Configure Added Damping	
		6.2.5 Configure mA Output Fault Action and mA Output Fault Level	
	6.3	Configure the Frequency Output	
		6.3.1 Configure Frequency Output Polarity	

		6.3.2 Configure Frequency Output Scaling Method	81
		6.3.3 Configure Frequency Output Fault Action and Frequency Output Fault Level	82
	6.4	Configure the Discrete Output	
		6.4.1 Configure Discrete Output Source	84
		6.4.2 Configure Discrete Output Polarity	86
		6.4.3 Configure Discrete Output Fault Action	86
	6.5	Configure events	87
		6.5.1 Configure a basic event	88
		6.5.2 Configure an enhanced event	88
	6.6	Configure digital communications	90
		6.6.1 Configure HART/Bell 202 communications	90
		6.6.2 Configure HART/RS-485 communications	
		6.6.3 Configure Modbus/RS-485 communications	
		6.6.4 Configure Digital Communications Fault Action	98
Chapter 7	Com	nplete the configuration	101
	7.1	Test or tune the system using sensor simulation	
		7.1.1 Sensor simulation	
	7.2	Back up transmitter configuration	
	7.3	Enable write-protection on the transmitter configuration	
Part III	Op	perations, maintenance, and troubleshoot	ting
Chapter 8	Tran	nsmitter operation	107
	8.1	Record the process variables	107
	8.2	View process variables	108
		8.2.1 View process variables using the display	108
		8.2.2 View process variables and other data using ProLink III	
		8.2.3 View process variables using the Field Communicator	109
	8.3	View transmitter status using the status LED	110
	8.4	View and acknowledge status alerts	
		8.4.1 View and acknowledge alerts using the display	
		8.4.2 View and acknowledge alerts using ProLink III	
		8.4.3 View alerts using the Field Communicator	
	8.5	Read totalizer and inventory values	
	8.6	Start and stop totalizers and inventories	
		8.6.1 Start and stop totalizers and inventories using the display	
	8.7	Reset totalizers	
		8.7.1 Reset totalizers using the display	
	8.8	Reset inventories	118
Chapter 9	Meas	surement support	
	9.1	Options for measurement support	
	9.2	Use Smart Meter Verification (SMV)	120
		9.2.1 SMV requirements	120
		9.2.2 SMV test preparation	
		9.2.3 Run SMV	
		9.2.4 View test data	
		9.2.5 Schedule automatic execution of the SMV test	
	9.3	Use PVR, TBR, and TMR	
		9.3.1 PVR, TBR, and TMR applications	
	94	Piecewise linearization (PWL) for calibrating gas meters	134

	9.5 9.6	Zero the meter	
	3.0	9.6.1 Alternate method for calculating the meter factor for volume flow	
	9.7	Perform a (standard) D1 and D2 density calibration	
		9.7.1 Perform a D1 and D2 density calibration using ProLink III	
		9.7.2 Perform a D1 and D2 density calibration using the Field Communicator	
	9.8	Perform a D3 and D4 density calibration (T-Series sensors only)	
		9.8.1 Perform a D3 or D3 and D4 density calibration using ProLink III	
		9.8.2 Perform a D3 or D3 and D4 density calibration using the Field Communicator	
	9.9	Perform temperature calibration	142
		9.9.1 Perform temperature calibration using the display	143
		9.9.2 Perform temperature calibration using ProLink III	143
		9.9.3 Perform temperature calibration using the Field Communicator	145
Chapter 10	Troub	oleshooting	147
	10.1	Status LED states	
	10.2	Status alerts, causes, and recommendations	
	10.3	Flow measurement problems	
	10.4	Density measurement problems	
	10.5	Temperature measurement problems	
	10.6	Milliamp output problems	
	10.7	Frequency Output problems	
	10.8	Using sensor simulation for troubleshooting	
	10.9	Check power supply wiring	
	10.10	Check sensor-to-transmitter wiring	
		Check grounding	
		Perform loop tests	
		10.12.1 Perform loop tests using the display	
		10.12.2 Perform loop tests using ProLink III	
		10.12.3 Perform loop tests using the Field Communicator	170
	10.13	Check the HART communication loop	171
	10.14	Check HART Address and mA Output Action	172
	10.15	Check HART burst mode	173
	10.16	Check the trimming of the mA Output	173
	10.17	Check Lower Range Value and Upper Range Value	173
	10.18	Check mA Output Fault Action	173
	10.19	Check for radio frequency interference (RFI)	174
	10.20	Check Frequency Output Scaling Method	174
	10.21	Check Frequency Output Fault Action	174
	10.22	Check Flow Direction	175
		Check the cutoffs	
	10.24	Check for two-phase flow (slug flow)	175
	10.25	Check the drive gain	
		10.25.1 Collect drive gain data	
	10.26	Check the pickoff voltage	
		10.26.1 Collect pickoff voltage data	
	10.27	Check for internal electrical problems	
		10.27.1 Check the sensor coils	
	10.28	Check the core processor LED	
		10.28.1 Core processor LED states	
	10 29	Perform a 700 core processor resistance test	186

## Appendices and reference

189
189
190
191
192
195
196
201
201
202
202
203
204
209
212
217
217
218
221
221
227
227
230
231
233
233

# Part I Getting started

### Chapters covered in this part:

- Before you begin
- Quick start

## 1 Before you begin

#### Topics covered in this chapter:

- About this manual
- Transmitter model code
- Communications tools and protocols
- Additional documentation and resources

### 1.1 About this manual

This manual helps you configure, commission, use, maintain, and troubleshoot Micro Motion Model 1700 transmitters with analog outputs.

#### **Important**

This manual assumes that the following conditions apply:

- The transmitter has been installed correctly and completely according to the instructions in the transmitter installation manual
- The installation complies with all applicable safety requirements
- The user is trained in local and corporate safety standards

## 1.2 Transmitter model code

You can verify that this manual pertains to your transmitter by ensuring the model code on the transmitter tag matches the format.

#### Example:

The transmitter has a model number of the following form:  $1700(R/I/E/B/C/M/P)^*A^{*****}$ 

- **R** 4-wire remote-mount with aluminum housing
- I Integral mount
- **E** 4-wire remote mount transmitter with 9-wire remote enhanced core processor
- **B** 4-wire remote mount transmitter with 9-wire remote core processor
- **C** 9-wire remote-mount with integral core processor and aluminum housing
- **M** 4-wire remote mount with stainless steel housing
- **P** 9-wire remote mount transmitter with integral core processor and stainless steel housing
- A Analog outputs option board

## 1.3 Communications tools and protocols

You can use several different communications tools and protocols to interface with the transmitter, use different tools in different locations, or use different tools for different tasks.

Tool	Supported protocols
ProLink III	<ul><li>HART/RS-485</li><li>HART/Bell 202</li><li>Modbus/RS-485</li><li>Service port</li></ul>
Field Communicator	HART/Bell 202

For information about how to use the communication tools, see the appendices in this manual.

#### Tip

You may be able to use other communications tools, such as AMS Suite: Intelligent Device Manager, or the Smart Wireless THUM<sup>™</sup> Adapter. Use of AMS or the Smart Wireless THUM Adapter is not discussed in this manual. For more information on the Smart Wireless THUM Adapter, refer to the documentation available at <a href="https://www.emerson.com">www.emerson.com</a>.

### 1.4 Additional documentation and resources

Topic	Document
Hazardous area installa- tion	See the approval documentation shipped with the transmitter, or download the appropriate documentation at <a href="https://www.emerson.com">www.emerson.com</a> .
Product Data Sheet	Micro Motion Series 1000 and Series 2000 Transmitters with MVD <sup>™</sup> Technology Product Data Sheet
Sensor	Sensor documentation
Transmitter installation	Micro Motion <sup>®</sup> Model 1700 and 2700 Installation Manual

All documentation resources are available at www.emerson.com or on the user documentation DVD.

## 2 Quick start

#### Topics covered in this chapter:

- Power up the transmitter
- Check meter status
- Make a startup connection to the transmitter
- (Optional) Adjust digital communications settings
- Verify mass flow measurement
- Verify the zero

## 2.1 Power up the transmitter

The transmitter must be powered up for all configuration and commissioning tasks, or for process measurement.

1. Ensure that all transmitter and sensor covers and seals are closed.

#### **A** DANGER!

To prevent ignition of flammable or combustible atmospheres, ensure that all covers and seals are tightly closed. For hazardous area installations, applying power while housing covers are removed or loose can cause an explosion.

2. Turn on the electrical power at the power supply.

The transmitter will automatically perform diagnostic routines. The transmitter is self-switching and will automatically detect the supply voltage. When using DC power, a minimum of 1.5 amps of startup current is required. During this period, Alert 009 is active. The diagnostic routines should complete in approximately 30 seconds. For transmitters with a display, the status LED will turn green and begin to flash when the startup diagnostics are complete. If the status LED exhibits different behavior, an alert is active.

#### **Postrequisites**

Although the sensor is ready to receive process fluid shortly after power-up, the electronics can take up to 10 minutes to reach thermal equilibrium. Therefore, if this is the initial startup, or if power has been off long enough to allow components to reach ambient temperature, allow the electronics to warm up for approximately 10 minutes before relying on process measurements. During this warm-up period, you may observe minor measurement instability or inaccuracy.

### 2.2 Check meter status

Check the meter for any error conditions that require user action or that affect measurement accuracy.

- Wait approximately 10 seconds for the power-up sequence to complete.
   Immediately after power-up, the transmitter runs through diagnostic routines and checks for error conditions. During the power-up sequence, Alert A009 is active.
   This alert should clear automatically when the power-up sequence is complete.
- 2. Check the status LED on the transmitter.

#### **Related information**

View and acknowledge status alerts

## 2.2.1 Transmitter status reported by LED

Table 2-1: Transmitter status reported by status LED

LED state	Description	Recommendation
Solid green	No alerts are active.	Continue with configuration or process measurement.
Flashing green (if enabled)	Unacknowledged corrected condition (no alert)	Continue with configuration or process measurement. Acknowledge the alert if you choose.
Solid yellow	One or more low-severity alerts are active.	A low-severity alert condition does not affect measurement accuracy or output behavior. You can continue with configuration or process measurement, but Micro Motion still recommends identifying and resolving the alert condition.
Flashing yellow (if enabled)	Calibration in progress, or Known Density Verification in progress.  One or more low-severity alerts are active and have not been acknowledged.	A low-severity alert condition does not affect measurement accuracy or output behavior. You can continue with configuration or process measurement, but Micro Motion still recommends identifying and resolving the alert condition.
Solid red	One or more high-severity alerts are active.	A high-severity alert condition affects measurement accuracy and output behavior. Resolve the alert condition before continuing.
Flashing red (if ena- bled)	One or more high-severity alerts are active and have not been acknowledged.	A high-severity alert condition affects measurement accuracy and output behavior. Resolve the alert condition before continuing. Acknowledge the alert if you choose.

If **Status LED Blinking** is disabled, all LEDs will show a solid color rather than flashing.

## 2.3 Make a startup connection to the transmitter

For all configuration tools except the display, you must have an active connection to the transmitter to configure the transmitter. Follow this procedure to make your first connection to the transmitter.

Identify the connection type to use, and follow the instructions for that connection type in the appropriate appendix. Use the default communications parameters shown in the appendix.

Communications tool	Connection type to use	Instructions
ProLink III	HART/RS-485	Appendix B
	Modbus/RS-485	
	Service port	
Field Communicator	HART/Bell 202	Appendix C

## 2.4 (Optional) Adjust digital communications settings

Change the communications parameters to site-specific values.

#### **Important**

If you are changing communications parameters for the connection type that you are using, you will lose the connection when you write the parameters to the transmitter. Reconnect using the new parameters.

#### **Procedure**

- To change the communications parameters using ProLink III, choose Device Tools >
   Configuration > Communications.
- 2. To change the communications parameters using the Field Communicator, choose On-Line Menu > Configure > Manual Setup > Inputs/Outputs > Communications.

## 2.5 Verify mass flow measurement

Check to see that the mass flow rate reported by the transmitter is accurate. You can use any available method.

- Read the value for Mass Flow Rate on the transmitter display.
- Connect to the transmitter with ProLink III and read the value for **Mass Flow Rate** in the Process Variables panel.
- Connect to the transmitter with the Field Communicator and read the value for Mass Flow Rate.

#### On-Line Menu > Overview > Primary Purpose Variables

#### **Postrequisites**

If the reported mass flow rate is not accurate:

- Check the characterization parameters.
- Review the troubleshooting suggestions for flow measurement issues.

## 2.6 Verify the zero

Verifying the zero helps you determine if the stored zero value is appropriate to your installation, or if a field zero can improve measurement accuracy.

The zero verification procedure analyzes the Live Zero value under conditions of zero flow, and compares it to the Zero Stability range for the sensor. If the average Live Zero value is within a reasonable range, the zero value stored in the transmitter is valid. Performing a field calibration will not improve measurement accuracy.

#### **Important**

In most cases, the factory zero is more accurate than the field zero. Do not zero the meter unless one of the following is true:

- The zero is required by site procedures.
- The stored zero value fails the zero verification procedure.

#### **Procedure**

- 1. Allow the flowmeter to warm up for at least 20 minutes after applying power.
- 2. Run the process fluid through the sensor until the sensor temperature reaches the normal process operating temperature.
- 3. Stop flow through the sensor by shutting the downstream valve, and then the upstream valve if available.
- 4. Verify that the sensor is blocked in, that flow has stopped, and that the sensor is completely full of process fluid.
- 5. From ProLink III, choose **Device Tools** > **Calibration** > **Zero Verification and Calibration** > **Verify Zero** and wait until the procedure completes.
- 6. Observe the drive gain, temperature, and density readings. If they are stable, check the **Live Zero** or **Field Verification Zero** value. If the average value is close to 0, you should not need to zero the meter.
- 7. If the zero verification procedure fails:
  - a. Confirm that the sensor is completely blocked in, that flow has stopped, and that the sensor is completely full of process fluid.
  - b. Verify that the process fluid is not flashing or condensing, and that it does not contain particles that can settle out.
  - c. Remove or reduce sources of electromechanical noise if appropriate.

- d. Repeat the zero verification procedure.
- e. If it fails again, zero the meter.

#### **Postrequisites**

Restore normal flow through the sensor by opening the valves.

#### **Related information**

Zero the meter

## 2.6.1 Terminology used with zero verification and zero calibration

Term	Definition
Zero	In general, the offset required to synchronize the left pickoff and the right pickoff under conditions of zero flow. Unit = microseconds.
Factory Zero	The zero value obtained at the factory, under laboratory conditions.
Field Zero	The zero value obtained by performing a zero calibration outside the factory.
Prior Zero	The zero value stored in the transmitter at the time a field zero calibration is begun. May be the factory zero or a previous field zero.
Manual Zero	The zero value stored in the transmitter, typically obtained from a zero calibration procedure. It may also be configured manually. Also called "mechanical zero" or "stored zero".
Live Zero	The real-time bidirectional mass flow rate with no flow damping or mass flow cutoff applied. An adaptive damping value is applied only when the mass flow rate changes dramatically over a very short interval. Unit = configured mass flow measurement unit.
Zero Stability	A laboratory-derived value used to calculate the expected accuracy for a sensor. Under laboratory conditions at zero flow, the average flow rate is expected to fall within the range defined by the Zero Stability value (0 $\pm$ Zero Stability). Each sensor size and model has a unique Zero Stability value. Statistically, 95% of all data points should fall within the range defined by the Zero Stability value.
Zero Calibration	The procedure used to determine the zero value.
Zero Time	The time period over which the Zero Calibration procedure is performed. Unit = seconds.
Field Verification Zero	A 3-minute running average of the Live Zero value, calculated by the transmitter. Unit = configured mass flow measurement unit.
Zero Verification	A procedure used to evaluate the stored zero and determine whether or not a field zero can improve measurement accuracy.

# Part II Configuration and commissioning

### Chapters covered in this part:

- Introduction to configuration and commissioning
- Configure process measurement
- Configure device options and preferences
- Integrate the meter with the control system
- Complete the configuration

# Introduction to configuration and commissioning

#### Topics covered in this chapter:

- Configuration flowchart
- Default values and ranges
- Enable access to the off-line menu of the display
- Disable write-protection on the transmitter configuration
- Restore the factory configuration

## 3.1 Configuration flowchart

Use the following flowchart as a general guide to the configuration and commissioning process.

Some options may not apply to your installation. Detailed information is provided in the remainder of this manual. If you are using the Weights & Measures application, additional configuration and setup are required.

Configure device options and Test and move to production Configure process measurement Configure mass flow Test or tune transmitter Configure display using sensor simulation parameters Configure volume flow meaurement Configure fault handling Back up transmitter parameters configuration Volume flow type Configure sensor Enable write-protection on parameters Liquid Gas transmitter configuration Define gas properties Configure device parameters Done Configure flow direction Integrate device with control system Configure density measurement Configure the channel(s) Configure temperature measurement Configure the mA output(s) Configure pressure compensation (optional) Configure the frequency output(s) Configure PVR, TMR, or TBR (if available) Configure the discrete output(s) Configure events Configure digital communications

Figure 3-1: Configuration flowchart

## 3.2 Default values and ranges

See Section D.1 to view the default values and ranges for the most commonly used parameters.

## 3.3 Enable access to the off-line menu of the display

Display	OFF-LINE MAINT > OFF-LINE CONFG > DISPLAY
ProLink III	Device Tools > Configuration > Transmitter Display > Display Security
Field Communicator	Configure > Manual Setup > Display > Offline Variable Menu Features

#### **Overview**

By default, access to the off-line menu of the display is enabled. If it is disabled, you must enable it if you want to use the display to configure the transmitter.

#### Restriction

You cannot use the display to enable access to the off-line menu. You must make a connection from another tool.

## 3.4 Disable write-protection on the transmitter configuration

Display	OFF-LINE MAINT > CONFG > LOCK	
ProLink III	Device Tools > Configuration > Write-Protection	
Field Communicator	Configure > Manual Setup > Info Parameters > Transmitter Info > Write Protect	

#### **Overview**

If the transmitter is write-protected, the configuration is locked and you must unlock it before you can change any configuration parameters. By default, the transmitter is not write-protected.

#### Tip

Write-protecting the transmitter prevents accidental changes to configuration. It does not prevent normal operational use. You can always disable write-protection, perform any required configuration changes, then re-enable write-protection.

## 3.5 Restore the factory configuration

Display	Not available
ProLink III	Device Tools > Configuration Transfer > Restore Factory Configuration
Field Communicator	Service Tools > Maintenance > Reset/Restore > Restore Factory Configuration

#### **Overview**

Restoring the factory configuration returns the transmitter to a known operational configuration. This may be useful if you experience problems during configuration.

#### **Important**

You cannot restore factory configurations with a 700 core.

#### Tip

Restoring the factory configuration is not a common action. You may want to contact customer support to see if there is a preferred method to resolve any issues.

## 4 Configure process measurement

#### Topics covered in this chapter:

- Configure mass flow measurement
- Configure volume flow measurement for liquid applications
- Configure GSV flow measurement
- Configure Flow Direction
- Configure density measurement
- Configure temperature measurement
- Configure pressure compensation

## 4.1 Configure mass flow measurement

The mass flow measurement parameters control how mass flow is measured and reported.

## 4.1.1 Configure Mass Flow Measurement Unit

Display	OFF-LINE MAINT > OFF-LINE CONFG > UNITS > MASS	
ProLink III	Device Tools > Configuration > Process Measurement > Flow	
Field Communicator	Configure > Manual Setup > Measurements > Flow > Mass Flow Unit	

#### **Overview**

**Mass Flow Measurement Unit** specifies the unit of measure that will be used for the mass flow rate. The unit used for mass total and mass inventory is derived from this unit.

Any selected measurement unit, (mass, volume or gas standard volume), is automatically applied to both the mA and Frequency Outputs.

#### **Procedure**

Set Mass Flow Measurement Unit to the unit you want to use.

The default setting for **Mass Flow Measurement Unit** is g/sec (grams per second).

#### Tip

If the measurement unit you want to use is not available, you can define a special measurement unit.

## **Options for Mass Flow Measurement Unit**

The transmitter provides a standard set of measurement units for **Mass Flow Measurement Unit**, plus one user-defined special measurement unit. Different communications tools may use different labels for the units.

	Label		
Unit description	Display	ProLink III	Field Communica- tor
Grams per second	G/S	g/sec	g/s
Grams per minute	G/MIN	g/min	g/min
Grams per hour	G/H	g/hr	g/h
Kilograms per second	KG/S	kg/sec	kg/s
Kilograms per minute	KG/MIN	kg/min	kg/min
Kilograms per hour	KG/H	kg/hr	kg/h
Kilograms per day	KG/D	kg/day	kg/d
Metric tons per minute	T/MIN	mTon/min	MetTon/min
Metric tons per hour	T/H	mTon/hr	MetTon/h
Metric tons per day	T/D	mTon/day	MetTon/d
Pounds per second	LB/S	lbs/sec	lb/s
Pounds per minute	LB/MIN	lbs/min	lb/min
Pounds per hour	LB/H	lbs/hr	lb/h
Pounds per day	LB/D	lbs/day	lb/d
Short tons (2000 pounds) per minute	ST/MIN	sTon/min	STon/min
Short tons (2000 pounds) per hour	ST/H	sTon/hr	STon/h
Short tons (2000 pounds) per day	ST/D	sTon/day	STon/d
Long tons (2240 pounds) per hour	LT/H	ITon/hr	LTon/h
Long tons (2240 pounds) per day	LT/D	ITon/day	LTon/d
Special unit	SPECL	special	Spcl

### Define a special measurement unit for mass flow

Display	Not available
ProLink III	Device Tools > Configuration > Process Measurement > Flow > Special Units
Field Communicator	Configure > Manual Setup > Measurements > Special Units > Mass Special Units

#### **Overview**

A special measurement unit is a user-defined unit of measure that allows you to report process data, totalizer data, and inventory data in a unit that is not available in the transmitter. A special measurement unit is calculated from an existing measurement unit using a conversion factor.

#### Note

Although you cannot define a special measurement unit using the display, you can use the display to select an existing special measurement unit, and to view process data using the special measurement unit.

#### **Procedure**

1. Specify **Base Mass Unit**.

**Base Mass Unit** is the existing mass unit that the special unit will be based on.

Specify Base Time Unit.

**Base Time Unit** is the existing time unit that the special unit will be based on.

- 3. Calculate Mass Flow Conversion Factor as follows:
  - a. x base units = y special units
  - b. Mass Flow Conversion Factor =  $x \div y$

The original mass flow rate value is divided by this value.

- Enter Mass Flow Conversion Factor.
- 5. Set **Mass Flow Label** to the name you want to use for the mass flow unit.
- 6. Set **Mass Total Label** to the name you want to use for the mass total and mass inventory unit.

The special measurement unit is stored in the transmitter. You can configure the transmitter to use the special measurement unit at any time.

#### Example: Defining a special measurement unit for mass flow

You want to measure mass flow in ounces per second (oz/sec).

- 1. Set **Base Mass Unit** to Pounds (lb).
- 2. Set Base Time Unit to Seconds (sec).
- 3. Calculate **Mass Flow Conversion Factor**:

- a. 1 lb/sec = 16 oz/sec
- b. Mass Flow Conversion Factor =  $1 \div 16 = 0.0625$
- 4. Set Mass Flow Conversion Factor to 0.0625.
- 5. Set Mass Flow Label to oz/sec.
- 6. Set Mass Total Label to oz.

## 4.1.2 Configure Flow Damping

Display	Not available
ProLink III	Device Tools > Configuration > Process Measurement > Flow
Field Communicator	Configure > Manual Setup > Measurements > Flow > Flow Damping

#### **Overview**

Damping is used to smooth out small, rapid fluctuations in process measurement. **Damping Value** specifies the time period (in seconds) over which the transmitter will spread changes in the process variable. At the end of the interval, the internal value will reflect 63% of the change in the actual measured value.

#### **Procedure**

Set **Flow Damping** to the value you want to use.

The default value is 0.8 seconds. The range depends on the core processor type and the setting of **Update Rate**, as shown in the following table.

Update Rate setting	Damping range
Normal	0 to 51.2 seconds
Special	0 to 40.96 seconds

The value you enter is automatically rounded off to the nearest valid value. For example, if the damping is currently set to 0.8 seconds, any value entered up to 1.2 seconds will be rounded down to 0.8 seconds, and any value entered from 1.21 to 1.59 seconds will be rounded up to 1.6 seconds.

Update Rate setting	Valid damping values	
Normal	0.0, 0.2, 0.4, 0.8, 1.6, 3.2, 6.4, 12.8, 25.6, 51.2	
Special	0.0, 0.04, 0.08, 0.16, 0.32, 0.64, 1.28, 2.56, 5.12, 10.24, 20.48, 40.96	

### Effect of flow damping on volume measurement

Flow damping affects volume measurement for liquid volume data. Flow damping also affects volume measurement for gas standard volume data. The transmitter calculates volume data from the damped mass flow data.

## Interaction between Flow Damping and mA Output Damping

In some circumstances, both **Flow Damping** and **mA Output Damping** are applied to the reported mass flow value.

Flow Damping controls the rate of change in flow process variables. mA Output Damping controls the rate of change reported via the mA Output. If mA Output Process Variable is set to Mass Flow Rate, and both Flow Damping and mA Output Damping are set to non-zero values, flow damping is applied first, and the added damping calculation is applied to the result of the first calculation.

## 4.1.3 Configure Mass Flow Cutoff

Display	Not available
ProLink III	Device Tools > Configuration > Process Measurement > Flow
Field Communicator	Configure > Manual Setup > Measurements > Flow > Mass Flow Cutoff

#### **Overview**

**Mass Flow Cutoff** specifies the lowest mass flow rate that will be reported as measured. All mass flow rates below this cutoff will be reported as 0.

#### **Procedure**

Set Mass Flow Cutoff to the value you want to use.

The default value for **Mass Flow Cutoff** is 0.0 g/sec or a sensor-specific value set at the factory. The recommended value is 0.5% of the nominal flow rate of the attached sensor. See the sensor specifications. Leaving **Mass Flow Cutoff** at 0.0 g/sec is not recommended.

#### Effect of Mass Flow Cutoff on volume measurement

**Mass Flow Cutoff** does not affect volume measurement. Volume data is calculated from the actual mass data rather than the reported value.

Volume flow has a separate Volume Flow Cutoff that is not affected by the Mass Flow Cutoff value.

### Interaction between Mass Flow Cutoff and mA Output Cutoff

**Mass Flow Cutoff** defines the lowest mass flow value that the transmitter will report as measured. **mA Output Cutoff** defines the lowest flow rate that will be reported via the mA output. If **mA Output Process Variable** is set to Mass Flow Rate, the mass flow rate reported via the mA Output is controlled by the higher of the two cutoff values.

**Mass Flow Cutoff** affects all reported values and values used in other transmitter behavior (e.g., events defined on mass flow).

**mA Output Cutoff** affects only mass flow values reported via the mA Output.

#### Example: Cutoff interaction with mA Output Cutoff lower than Mass Flow Cutoff

#### Configuration:

mA Output Process Variable: Mass Flow Rate

Frequency Output Process Variable: Mass Flow Rate

mA Output Cutoff: 10 g/sec

Mass Flow Cutoff: 15 g/sec

Result: If the mass flow rate drops below 15 g/sec, mass flow will be reported as 0, and 0 will be used in all internal processing.

#### Example: Cutoff interaction with mA Output Cutoff higher than Mass Flow Cutoff

#### Configuration:

mA Output Process Variable: Mass Flow Rate

Frequency Output Process Variable: Mass Flow Rate

mA Output Cutoff: 15 g/sec
 Mass Flow Cutoff: 10 g/sec

#### Result:

- If the mass flow rate drops below 15 g/sec but not below 10 g/sec:
  - The mA Output will report zero flow.
  - The Frequency Output will report the actual flow rate, and the actual flow rate will be used in all internal processing.
- If the mass flow rate drops below 10 g/sec, both outputs will report zero flow, and 0 will be used in all internal processing.

## 4.2 Configure volume flow measurement for liquid applications

The volume flow measurement parameters control how liquid volume flow is measured and reported.

#### Restriction

You cannot implement both liquid volume flow and gas standard volume flow at the same time. Choose one or the other.

#### Note

If you need to switch from gas standard volume to liquid volume, polling for base density will automatically be disabled.

## 4.2.1 Configure Volume Flow Type for liquid applications

Display	Not available
ProLink III	Device Tools > Configuration > Process Measurement > Flow
Field Communicator	Configure > Manual Setup > Measurements > GSV > Volume Flow Type > Liquid

#### **Overview**

**Volume Flow Type** controls whether liquid or gas standard volume flow measurement will be used.

#### Restriction

Gas standard volume measurement is incompatible with some applications. Set **Volume Flow Type** to Liquid if you are using any of the following applications:

Production Volume Reconciliation (PVR)

#### **Procedure**

Set Volume Flow Type to Liquid.

## 4.2.2 Configure Volume Flow Measurement Unit for liquid applications

Display	OFF-LINE MAINT > OFF-LINE CONFG > UNITS > VOL	
ProLink III	Device Tools > Configuration > Process Measurement > Flow	
Field Communicator	Configure > Manual Setup > Measurements > Flow > Volume Flow Unit	

#### **Overview**

**Volume Flow Measurement Unit** specifies the unit of measurement that will be displayed for the volume flow rate. The unit used for the volume total and volume inventory is based on this unit.

#### **Prerequisites**

Before you configure **Volume Flow Measurement Unit**, be sure that **Volume Flow Type** is set to Liquid.

#### **Procedure**

Set **Volume Flow Measurement Unit** to the unit you want to use.

The default setting for **Volume Flow Measurement Unit** is I/sec (liters per second).

#### Tip

If the measurement unit you want to use is not available, you can define a special measurement unit.

## Options for Volume Flow Measurement Unit for liquid applications

The transmitter provides a standard set of measurement units for **Volume Flow Measurement Unit**, plus one user-defined measurement unit. Different communications tools may use different labels for the units.

	Label		
Unit description	Display	ProLink III	Field Communicator
Cubic feet per second	CUFT/S	ft3/sec	Cuft/s
Cubic feet per minute	CUF/MN	ft3/min	Cuft/min
Cubic feet per hour	CUFT/H	ft3/hr	Cuft/h
Cubic feet per day	CUFT/D	ft3/day	Cuft/d
Cubic meters per second	M3/S	m3/sec	Cum/s
Cubic meters per minute	M3/MIN	m3/min	Cum/min
Cubic meters per hour	М3/Н	m3/hr	Cum/h
Cubic meters per day	M3/D	m3/day	Cum/d
U.S. gallons per second	USGPS	US gal/sec	gal/s
U.S. gallons per minute	USGPM	US gal/min	gal/min
U.S. gallons per hour	USGPH	US gal/hr	gal/h
U.S. gallons per day	USGPD	US gal/day	gal/d
Million U.S. gallons per day	MILG/D	mil US gal/day	MMgal/d
Liters per second	L/S	I/sec	L/s
Liters per minute	L/MIN	l/min	L/min
Liters per hour	L/H	l/hr	L/h
Million liters per day	MILL/D	mil I/day	ML/d
Imperial gallons per second	UKGPS	Imp gal/sec	Impgal/s
Imperial gallons per minute	UKGPM	Imp gal/min	Impgal/min

		Label		
Unit description	Display	ProLink III	Field Communicator	
Imperial gallons per hour	UKGPH	Imp gal/hr	Impgal/h	
Imperial gallons per day	UKGPD	Imp gal/day	Impgal/d	
Barrels per second <sup>(1)</sup>	BBL/S	barrels/sec	bbl/s	
Barrels per minute <sup>(1)</sup>	BBL/MN	barrels/min	bbl/min	
Barrels per hour <sup>(1)</sup>	BBL/H	barrels/hr	bbl/h	
Barrels per day <sup>(1)</sup>	BBL/D	barrels/day	bbl/d	
Beer barrels per second <sup>(2)</sup>	BBBL/S	Beer barrels/sec	bbbl/s	
Beer barrels per minute <sup>(2)</sup>	BBBL/MN	Beer barrels/min	bbbl/min	
Beer barrels per hour <sup>(2)</sup>	BBBL/H	Beer barrels/hr	bbbl/h	
Beer barrels per day <sup>(2)</sup>	BBBL/D	Beer barrels/day	bbbl/d	
Special unit	SPECL	special	Spcl	

<sup>(1)</sup> Unit based on oil barrels (42 U.S. gallons).

## Define a special measurement unit for volume flow

Display	Not available
ProLink III	Device Tools > Configuration > Process Measurement > Flow > Special Units
Field Communicator	Configure > Manual Setup > Measurements > Special Units > Volume Special Units

#### **Overview**

A special measurement unit is a user-defined unit of measure that allows you to report process data, totalizer data, and inventory data in a unit that is not available in the transmitter. A special measurement unit is calculated from an existing measurement unit using a conversion factor.

#### Note

Although you cannot define a special measurement unit using the display, you can use the display to select an existing special measurement unit, and to view process data using the special measurement unit.

#### **Procedure**

1. Specify **Base Volume Unit**.

**Base Volume Unit** is the existing volume unit that the special unit will be based on.

2. Specify **Base Time Unit**.

**Base Time Unit** is the existing time unit that the special unit will be based on.

<sup>(2)</sup> Unit based on U.S. beer barrels (31 U.S. gallons).

- 3. Calculate **Volume Flow Conversion Factor** as follows:
  - a. x base units = y special units
  - b. Volume Flow Conversion Factor =  $x \div y$
- 4. Enter Volume Flow Conversion Factor.

The original volume flow rate value is divided by this conversion factor.

- 5. Set **Volume Flow Label** to the name you want to use for the volume flow unit.
- 6. Set **Volume Total Label** to the name you want to use for the volume total and volume inventory unit.

The special measurement unit is stored in the transmitter. You can configure the transmitter to use the special measurement unit at any time.

#### Example: Defining a special measurement unit for volume flow

You want to measure volume flow in pints per second (pints/sec).

- 1. Set **Base Volume Unit** to Gallons (gal).
- 2. Set **Base Time Unit** to Seconds (sec).
- 3. Calculate the conversion factor:
  - a. 1 gal/sec = 8 pints/sec
  - b. Volume Flow Conversion Factor =  $1 \div 8 = 0.1250$
- 4. Set Volume Flow Conversion Factor to 0.1250.
- 5. Set Volume Flow Label to pints/sec.
- 6. Set Volume Total Label to pints.

## 4.2.3 Configure Volume Flow Cutoff

Display	Not available
ProLink III	Device Tools > Configuration > Process Measurement > Flow
Field Communicator	Configure > Manual Setup > Measurements > Flow > Volume Flow Cutoff

#### **Overview**

**Volume Flow Cutoff** specifies the lowest volume flow rate that will be reported as measured. All volume flow rates below this cutoff are reported as 0.

#### **Procedure**

Set **Volume Flow Cutoff** to the value you want to use.

The default value for **Volume Flow Cutoff** is 0.0 l/sec (liters per second). The lower limit is 0.

#### Interaction between Volume Flow Cutoff and mAO Cutoff

**Volume Flow Cutoff** defines the lowest liquid volume flow value that the transmitter will report as measured. **mAO Cutoff** defines the lowest flow rate that will be reported via the mA Output. If **mA Output Process Variable** is set to Volume Flow Rate, the volume flow rate reported via the mA Output is controlled by the higher of the two cutoff values.

**Volume Flow Cutoff** affects both the volume flow values reported via the outputs and the volume flow values used in other transmitter behavior (e.g., events defined on the volume flow).

mAO Cutoff affects only flow values reported via the mA Output.

#### Example: Cutoff interaction with mAO Cutoff lower than Volume Flow Cutoff

#### Configuration:

- mA Output Process Variable: Volume Flow Rate
- Frequency Output Process Variable: Volume Flow Rate
- AO Cutoff: 10 l/sec
- Volume Flow Cutoff: 15 l/sec

Result: If the volume flow rate drops below 15 l/sec, volume flow will be reported as 0, and 0 will be used in all internal processing.

#### Example: Cutoff interaction with mAO Cutoff higher than Volume Flow Cutoff

#### Configuration:

- mA Output Process Variable: Volume Flow Rate
- Frequency Output Process Variable: Volume Flow Rate
- AO Cutoff: 15 l/sec
- Volume Flow Cutoff: 10 l/sec

#### Result:

- If the volume flow rate drops below 15 l/sec but not below 10 l/sec:
  - The mA Output will report zero flow.
  - The Frequency Output will report the actual flow rate, and the actual flow rate will be used in all internal processing.
- If the volume flow rate drops below 10 l/sec, both outputs will report zero flow, and 0 will be used in all internal processing.

## 4.3 Configure GSV flow measurement

The gas standard volume (GSV) flow measurement parameters control how volume flow is measured and reported in a gas application.

#### Restriction

You cannot implement both liquid volume flow and gas standard volume flow at the same time. Choose one or the other.

## 4.3.1 Configure Volume Flow Type for gas applications

Display	Not available
ProLink III	Device Tools > Configuration > Process Measurement > Flow
Field Communicator	Configure > Manual Setup > Measurements > GSV > Volume Flow Type > Standard Gas Volume

#### **Overview**

**Volume Flow Type** controls whether liquid or gas standard volume flow measurement is used.

#### Restriction

Gas standard volume measurement is incompatible with some applications. Set **Volume Flow Type** to Liquid if you are using any of the following applications:

Production Volume Reconciliation (PVR)

#### **Procedure**

Set **Volume Flow Type** to Gas Standard Volume.

## 4.3.2 Configure Standard Density of Gas

Display	Not available
ProLink III	Device Tools > Configuration > Process Measurement > Flow
Field Communicator	Configure > Manual Setup > Measurements > GSV > Gas Ref Density

#### **Overview**

The **Standard Density of Gas** value is the gas density at standard reference conditions. Use it to convert the measured mass flow data to volume flow at reference conditions.

#### **Prerequisites**

Ensure that **Density Measurement Unit** is set to the measurement unit you want to use for **Standard Density of Gas**.

#### **Procedure**

From the **Source** field, choose the method to supply gas base density data and perform the required setup.

Option	Description
Fixed Value or Digital Communications	A host writes gas base density data to the meter at appropriate intervals. Continue to Configure fixed value or digital communications.
Poll for external value	The meter polls an external HART device for gas base density data in order to then compute gas standard volume from the mass flow and gas base density.  Continue to <i>Poll for external value</i> .

# Configure fixed value or digital communications

# **Prerequisites**

Section 4.3.2

## **Procedure**

1. Set **Standard Density of Gas** to the standard reference density of the gas you are measuring.

#### Note

ProLink III provides a guided method that you can use to calculate your gas base density, if you do not know it.

2. Continue to Section 4.3.3.

# Poll for external value

# **Prerequisites**

Section 4.3.2

## **Procedure**

- 1. Set **Polling Slot** to an available slot.
- 2. Set **Polling Control** *n* as one of the following options:

The *n* is the value you selected in the **Polling Slot** field.

If there is another master, and if that master is primary, then set this field to secondary. If the other master is secondary, then set this field to primary.

Option	Description
Poll as Primary	No other HART masters will be on the network.
Poll as Secondary	Other HART masters will be on the network.

3. Set **External Device Tag** *n* to the HART tag of the device being polled.

The *n* is the value you selected in the **Polling Slot** field.

The device being polled (slave) cannot have special units set for density.
 Otherwise, the master will reject the base density and report the following alarm:

```
A115: No External Input or Polled Data Alert
```

- On the slave side, setup the HART Primary Variable for Base Density. The master will reject anything other than Base Density for the HART Primary Variable and trigger an A115 alarm.
- The density units on the transmitter and the polled device can be different as long as they can be classified as density units; for example, kg/m³ and g/cm³.
   The transmitter converts the polled units into compatible specified units.

For wiring and setup instructions for a polled device, refer to the *Micro Motion Gas Density Meters (GDM) Installation manual* or the *Micro Motion Specific Gravity Meters (SGM) Installation manual*.

4. Continue to Section 4.3.3.

# 4.3.3 Configure Gas Standard Volume Flow Unit

Display	OFF-LINE MAINT > OFF-LINE CONFG > UNITS > GSV	
ProLink III	Device Tools > Configuration > Process Measurement > Flow	
Field Communicator	Configure > Manual Setup > Measurements > GSV > GSV Flow Unit	

#### **Overview**

**Gas Standard Volume Flow Unit** specifies the unit of measure that will be displayed for the gas standard volume flow. The measurement unit used for the gas volume total and the gas volume inventory is derived from this unit.

## **Prerequisites**

Before you configure **Gas Standard Volume Flow Unit**, be sure that **Volume Flow Type** is set to Gas Standard Volume.

For polling, the first transmitter (master) requests density from a second transmitter (slave) via HART communications. Special units for GSV are allowed on the master side, but the device being polled (slave) cannot have special units set for density, otherwise the master will reject the base density and report an A115: No External Input or Polled Data Alert.

### **Procedure**

Set **Gas Standard Volume Flow Unit** to the unit you want to use.

The default setting for **Gas Standard Volume Flow Unit** is SCFM (Standard Cubic Feet per Minute).

### Tip

If the measurement unit you want to use is not available, you can define a special measurement unit.

# **Options for Gas Standard Volume Flow Unit**

The transmitter provides a standard set of measurement units for **Gas Standard Volume Flow Unit**, plus one user-defined special measurement unit. Different communications tools may use different labels for the units.

	Label		
Unit description	Display	ProLink III	Field Communicator
Normal cubic meters per second	NM3/S	Nm3/sec	Nm3/sec
Normal cubic meters per minute	NM3/MN	Nm3/sec	Nm3/min
Normal cubic meters per hour	NM3/H	Nm3/hr	Nm3/hr
Normal cubic meters per day	NM3/D	Nm3/day	Nm3/day
Normal liters per second	NLPS	NLPS	NLPS
Normal liters per minute	NLPM	NLPM	NLPM
Normal liters per hour	NLPH	NLPH	NLPH
Normal liters per day	NLPD	NLPD	NLPD
Standard cubic feet per second	SCFS	SCFS	SCFS
Standard cubic feet per minute	SCFM	SCFM	SCFM
Standard cubic feet per hour	SCFH	SCFH	SCFH
Standard cubic feet per day	SCFD	SCFD	SCFD
Standard cubic meters per second	SM3/S	Sm3/sec	Sm3/sec
Standard cubic meters per minute	SM3/MN	Sm3/min	Sm3/min
Standard cubic meters per hour	SM3/H	Sm3/hr	Sm3/hr
Standard cubic meters per day	SM3/D	Sm3/day	Sm3/day
Standard liters per second	SLPS	SLPS	SLPS
Standard liters per minute	SLPM	SLPM	SLPM
Standard liters per hour	SLPH	SLPH	SLPH
Standard liters per day	SLPD	SLPD	SLPD
Special measurement unit	SPECL	special	Special

# Define a special measurement unit for gas standard volume flow

Display	Not available
ProLink III	Device Tools > Configuration > Process Measurement > Flow > Special Units
Field Communicator	Configure > Manual Setup > Measurements > Special Units > Special GSV Units

#### **Overview**

A special measurement unit is a user-defined unit of measure that allows you to report process data, totalizer data, and inventory data in a unit that is not available in the transmitter. A special measurement unit is calculated from an existing measurement unit using a conversion factor.

#### Note

Although you cannot define a special measurement unit using the display, you can use the display to select an existing special measurement unit, and to view process data using the special measurement unit.

## **Procedure**

Specify Base Gas Standard Volume Unit.

**Base Gas Standard Volume Unit** is the existing gas standard volume unit that the special unit will be based on.

2. Specify **Base Time Unit**.

**Base Time Unit** is the existing time unit that the special unit will be based on.

- 3. Calculate **Gas Standard Volume Flow Conversion Factor** as follows:
  - a. x base units = y special units
  - b. Gas Standard Volume Flow Conversion Factor = x ÷ y
- Enter the Gas Standard Volume Flow Conversion Factor.

The original gas standard volume flow value is divided by this conversion factor.

- 5. Set **Gas Standard Volume Flow Label** to the name you want to use for the gas standard volume flow unit.
- 6. Set **Gas Standard Volume Total Label** to the name you want to use for the gas standard volume total and gas standard volume inventory unit.

The special measurement unit is stored in the transmitter. You can configure the transmitter to use the special measurement unit at any time.

## Example: Defining a special measurement unit for gas standard volume flow

You want to measure gas standard volume flow in thousands of standard cubic feet per minute.

- 1. Set **Base Gas Standard Volume Unit** to SCF.
- 2. Set **Base Time Unit** to minutes (min).
- 3. Calculate the conversion factor:
  - a. 1 thousands of standard cubic feet per minute = 1000 cubic feet per minute
  - b. Gas Standard Volume Flow Conversion Factor = 1 ÷ 1000 = 0.001 standard
- 4. Set Gas Standard Volume Flow Conversion Factor to 0.001.
- 5. Set **Gas Standard Volume Flow Label** to MSCFM.

### 6. Set **Gas Standard Volume Total Label** to MSCF.

# 4.3.4 Configure Gas Standard Volume Flow Cutoff

Display	Not available	
ProLink III	Device Tools > Configuration > Process Measurement > Flow	
Field Communicator	Configure > Manual Setup > Measurements > GSV > GSV Cutoff	

#### **Overview**

**Gas Standard Volume Flow Cutoff** specifies the lowest gas standard volume flow rate that will reported as measured. All gas standard volume flow rates below this cutoff will be reported as 0.

## **Procedure**

Set **Gas Standard Volume Flow Cutoff** to the value you want to use.

The default value for **Gas Standard Volume Flow Cutoff** is 0.0. The lower limit is 0.0. There is no upper limit.

# Interaction between Gas Standard Volume Flow Cutoff and mA Output Cutoff

**Gas Standard Volume Flow Cutoff** defines the lowest Gas Standard Volume flow value that the transmitter will report as measured. **mA Output Cutoff** defines the lowest flow rate that will be reported via the mA Output. If **mA Output Process Variable** is set to Gas Standard Volume Flow Rate, the volume flow rate reported via the mA Output is controlled by the higher of the two cutoff values.

**Gas Standard Volume Flow Cutoff** affects both the gas standard volume flow values reported via outputs and the gas standard volume flow values used in other transmitter behavior (e.g., events defined on gas standard volume flow).

mA Output Cutoff affects only flow values reported via the mA Output.

# Example: Cutoff interaction with mA Output Cutoff lower than Gas Standard Volume Flow Cutoff

## Configuration:

- mA Output Process Variable for the primary mA Output: Gas Standard Volume Flow Rate
- Frequency Output Process Variable: Gas Standard Volume Flow Rate
- mA Output Cutoff for the primary mA Output: 10 SLPM (standard liters per minute)
- Gas Standard Volume Flow Cutoff: 15 SLPM

Result: If the gas standard volume flow rate drops below 15 SLPM, the volume flow will be reported as 0, and 0 will be used in all internal processing.

# Example: Cutoff interaction with mA Output Cutoff higher than Gas Standard Volume Flow Cutoff

## Configuration:

- mA Output Process Variable for the primary mA Output: Gas Standard Volume Flow Rate
- Frequency Output Process Variable: Gas Standard Volume Flow Rate
- mA Output Cutoff for the primary mA Output: 15 SLPM (standard liters per minute)
- Gas Standard Volume Flow Cutoff: 10 SLPM

## Result:

- If the gas standard volume flow rate drops below 15 SLPM but not below 10 SLPM:
  - The primary mA Output will report zero flow.
  - The Frequency Output will report the actual flow rate, and the actual flow rate will be used in all internal processing.
- If the gas standard volume flow rate drops below 10 SLPM, both outputs will report zero flow, and 0 will be used in all internal processing.

# 4.4 Configure Flow Direction

Display	Not available
ProLink III	Device Tools > Configuration > Process Measurement > Flow
Field Communicator	Configure > Manual Setup > Measurements > Flow > Flow Direction

### **Overview**

**Flow Direction** controls how forward flow and reverse flow affect flow measurement and reporting.

**Flow Direction** is defined with respect to the flow arrow on the sensor:

- Forward flow (positive flow) moves in the direction of the flow arrow on the sensor.
- Reverse flow (negative flow) moves in the direction opposite to the flow arrow on the sensor.

## Tip

Micro Motion sensors are bidirectional. Measurement accuracy is not affected by actual flow direction or the setting of the **Flow Direction** parameter.

## **Procedure**

Set Flow Direction to the value you want to use.

The default setting is Forward.

# 4.4.1 Options for Flow Direction

Flow Direction setting		Relationship to Flow Direction arrow	
ProLink III	Field Communicator	on sensor	
Forward	Forward	Appropriate when the Flow Direction arrow is in the same direction as the majority of flow.	
Reverse	Reverse	Appropriate when the Flow Direction arrow is in the opposite direction from the majority of flow.	
Absolute Value	Absolute Value	Flow Direction arrow is not relevant.	
Bidirectional	Bi directional	Appropriate when both forward and reverse flow are expected, and forward flow will dominate, but the amount of reverse flow will be significant.	
Negate Forward	Negate/Forward Only	Appropriate when the Flow Direction arrow is in the opposite direction from the majority of flow.	
Negate Bidirectional	Negate/Bi-directional	Appropriate when both forward and reverse flow are expected, and reverse flow will dominate, but the amount of forward flow will be significant.	

# **Effect of Flow Direction on mA Outputs**


**Flow Direction** affects how the transmitter reports flow values via the mA Outputs. The mA Outputs are affected by **Flow Direction** only if **mA Output Process Variable** is set to a flow variable.

# Flow Direction and mA Outputs

The effect of Flow Direction on the mA Outputs depends on Lower Range Value configured for the mA Output:


- If Lower Range Value is set to 0, see Figure 4-1.
- If Lower Range Value is set to a negative value, see *Figure 4-2*.

Figure 4-1: Effect of Flow Direction on the mA Output: Lower Range Value = 0



- Lower Range Value = 0
- Upper Range Value = x

Figure 4-2: Effect of Flow Direction on the mA Output: Lower Range Value < 0



- Lower Range Value = -x
- Upper Range Value = x

# Example: Flow Direction = Forward and Lower Range Value = 0

# Configuration:

- Flow Direction = Forward
- Lower Range Value = 0 g/sec
- Upper Range Value = 100 g/sec

#### Result:

- Under conditions of zero flow, the mA Output is 4 mA.
- Under conditions of forward flow, up to a flow rate of 100 g/sec, the mA Output varies between 4 mA and 20 mA in proportion to the flow rate.
- Under conditions of forward flow, if the flow rate equals or exceeds 100 g/sec, the mA Output will be proportional to the flow rate up to 20.5 mA, and will be level at 20.5 mA at higher flow rates.

## Example: Flow Direction = Forward and Lower Range Value < 0

## Configuration:

- Flow Direction = Forward
- Lower Range Value = −100 g/sec
- Upper Range Value = +100 g/sec

## Result:

- Under conditions of zero flow, the mA Output is 12 mA.
- Under conditions of forward flow, for flow rates between 0 and +100 g/sec, the mA Output varies between 12 mA and 20 mA in proportion to (the absolute value of) the flow rate.
- Under conditions of forward flow, if (the absolute value of) the flow rate equals or exceeds 100 g/sec, the mA Output is proportional to the flow rate up to 20.5 mA, and will be level at 20.5 mA at higher flow rates.
- Under conditions of reverse flow, for flow rates between 0 and -100 g/sec, the mA
   Output varies between 4 mA and 12 mA in inverse proportion to the absolute value
   of the flow rate.
- Under conditions of reverse flow, if the absolute value of the flow rate equals or exceeds 100 g/sec, the mA Output is inversely proportional to the flow rate down to 3.8 mA, and will be level at 3.8 mA at higher absolute values.

## Example: Flow Direction = Reverse

## Configuration:

- Flow Direction = Reverse
- Lower Range Value = 0 g/sec
- Upper Range Value = 100 g/sec

# Result:

- Under conditions of zero flow, the mA Output is 4 mA.
- Under conditions of reverse flow, for flow rates between 0 and +100 g/sec, the mA
   Output level varies between 4 mA and 20 mA in proportion to the absolute value of the flow rate.
- Under conditions of reverse flow, if the absolute value of the flow rate equals or exceeds 100 g/sec, the mA Output will be proportional to the absolute value of the flow rate up to 20.5 mA, and will be level at 20.5 mA at higher absolute values.

# **Effect of flow direction on Frequency Outputs**

Flow direction affects how the transmitter reports flow values via the Frequency Outputs. The Frequency Outputs are affected by flow direction only if **Frequency Output Process Variable** is set to a flow variable.

Table 4-1: Effect of the flow direction parameter and actual flow direction on Frequency Outputs

		Actual flow direction		
Flow Direction setting	Forward	Zero flow	Reverse	
Forward	Hz > 0	0 Hz	0 Hz	
Reverse	0 Hz	0 Hz	Hz > 0	
Bidirectional	Hz > 0	0 Hz	Hz > 0	
Absolute Value	Hz > 0	0 Hz	Hz > 0	
Negate Forward	0 Hz	0 Hz	Hz > 0	
Negate Bidirectional	Hz > 0	0 Hz	Hz > 0	

# **Effect of flow direction on Discrete Outputs**

The flow direction parameter affects the Discrete Output behavior only if **Discrete Output Source** is set to Flow Direction.

Table 4-2: Effect of the flow direction parameter and actual flow direction on Discrete Outputs

-		Actual flow direction		
Flow Direction setting	Forward	Zero flow	Reverse	
Forward	OFF	OFF	ON	
Reverse	OFF	OFF	ON	
Bidirectional	OFF	OFF	ON	
Absolute Value	OFF	OFF	ON	
Negate Forward	ON	OFF	OFF	
Negate Bidirectional	ON	OFF	OFF	

# Effect of flow direction on digital communications

Flow direction affects how flow values are reported via digital communications. The following table describes the effect of the flow direction parameter and actual flow direction on flow values reported via digital communications.

Table 4-3: Effect of the flow direction on flow values

		Actual flow direction		
Flow Direction setting	Forward	Zero flow	Reverse	
Forward	Positive	0	Negative	
Reverse	Positive	0	Negative	
Bidirectional	Positive	0	Negative	
Absolute Value	Positive <sup>(1)</sup>	0	Positive <sup>(1)</sup>	
Negate Forward	Negative	0	Positive	
Negate Bidirectional	Negative	0	Positive	

<sup>(1)</sup> Refer to the digital communications status bits for an indication of whether flow is positive or negative.

# Effect of flow direction on flow totals

Flow direction affects how flow totals and inventories are calculated.

	Actual flow direction		
Flow Direction setting	Forward	Zero flow	Reverse
Forward	Totals increase	Totals do not change	Totals do not change
Reverse	Totals do not change	Totals do not change	Totals increase
Bidirectional	Totals increase	Totals do not change	Totals decrease
Absolute Value	Totals increase	Totals do not change	Totals increase
Negate Forward	Totals do not change	Totals do not change	Totals increase
Negate Bidirectional	Totals decrease	Totals do not change	Totals increase

# 4.5 Configure density measurement

The density measurement parameters control how density is measured and reported.

# 4.5.1 Configure Density Measurement Unit

Display	OFF-LINE MAINT > OFF-LINE CONFG > UNITS > DENS
ProLink III	Device Tools > Configuration > Process Measurement > Density
Field Communicator	Configure > Manual Setup > Measurements > Density > Density Unit

#### **Overview**

**Density Measurement Unit** controls the measurement units that will be used in density calculations and reporting.

#### **Procedure**

Set **Density Measurement Unit** to the option you want to use.

The default setting for **Density Measurement Unit** is g/cm3 (grams per cubic centimeter).

# **Options for Density Measurement Unit**

The transmitter provides a standard set of measurement units for **Density Measurement Unit**. Different communications tools may use different labels.

	Label		
Unit description	Display	ProLink III	Field Communicator
Specific gravity <sup>(1)</sup>	SGU	SGU	SGU
Grams per cubic centimeter	G/CM3	g/cm3	g/Cucm
Grams per liter	G/L	g/l	g/L
Grams per milliliter	G/mL	g/ml	g/mL
Kilograms per liter	KG/L	kg/l	kg/L
Kilograms per cubic meter	KG/M3	kg/m3	kg/Cum
Pounds per U.S. gallon	LB/GAL	lbs/Usgal	lb/gal
Pounds per cubic foot	LB/CUF	lbs/ft3	lb/Cuft
Pounds per cubic inch	LB/CUI	lbs/in3	lb/CuIn
Degrees API	D API	degAPI	degAPI
Short ton per cubic yard	ST/CUY	sT/yd3	STon/Cuyd

<sup>(1)</sup> Non-standard calculation. This value represents line density divided by the density of water at 60 °F.

# 4.5.2 Configure two-phase flow parameters

Display	Not available
ProLink III	Device Tools > Configuration > Process Measurement > Density
Field Communicator	<ul> <li>Configure &gt; Manual Setup &gt; Measurements &gt; Density &gt; Slug Low Limit</li> <li>Configure &gt; Manual Setup &gt; Measurements &gt; Density &gt; Slug High Limit</li> <li>Configure &gt; Manual Setup &gt; Measurements &gt; Density &gt; Slug Duration</li> </ul>

### **Overview**

The two-phase flow parameters control how the transmitter detects and reports two-phase flow (gas in a liquid process or liquid in a gas process).

#### Note

Two-phase flow is also referred to as slug flow.

#### **Procedure**

1. Set **Two-Phase Flow Low Limit** to the lowest density value that is considered normal in your process.

Values below this will cause the transmitter to post Alert A105 (Two-Phase Flow).

#### Tip

Gas entrainment can cause your process density to drop temporarily. To reduce the occurrence of two-phase flow alerts that are not significant to your process, set **Two-Phase Flow Low Limit** slightly below your expected lowest process density.

You must enter **Two-Phase Flow Low Limit** in g/cm<sup>3</sup>, even if you configured another unit for density measurement.

The default value for **Two-Phase Flow Low Limit** is 0.0 g/cm<sup>3</sup>. The range is 0.0 to 10.0 g/cm<sup>3</sup>.

2. Set **Two-Phase Flow High Limit** to the highest density value that is considered normal in your process.

Micro Motion recommends leaving **Two-Phase Flow High Limit** at the default value.

Values above this will cause the transmitter to post Alert A105 (Two-Phase Flow).

You must enter **Two-Phase Flow High Limit** in g/cm<sup>3</sup>, even if you configured another unit for density measurement.

The default value for **Two-Phase Flow High Limit** is 5.0 g/cm<sup>3</sup>. The range is 0.0 to 10.0 g/cm<sup>3</sup>.

3. Set **Two-Phase Flow Timeout** to the number of seconds that the transmitter will wait for a two-phase flow condition to clear before posting the alert.

The default value for **Two-Phase Flow Timeout** is 0.0 seconds, meaning that the alert will be posted immediately. The range is 0.0 to 60.0 seconds.

# Detecting and reporting two-phase flow

Two-phase flow (gas in a liquid process or liquid in a gas process) can cause a variety of process control issues. By configuring the two-phase flow parameters appropriately for your application, you can detect process conditions that require correction.

Micro Motion recommends leaving **Two-Phase Flow High Limit** at the default value.

A two-phase flow condition occurs whenever the measured density goes below **Two-Phase Flow Low Limit** or above **Two-Phase Flow High Limit**. If this occurs:

- A two-phase flow alert is posted to the active alert log.
- All outputs that are configured to represent flow rate hold their last *pre-alert* value for the number of seconds configured in **Two-Phase Flow Timeout**.

If the two-phase flow condition clears before **Two-Phase Flow Timeout** expires:

Outputs that represent flow rate revert to reporting actual flow.

The two-phase flow alert is deactivated, but remains in the active alert log until it is acknowledged.

If the two-phase flow condition does not clear before **Two-Phase Flow Timeout** expires, the outputs that represent flow rate report a flow rate of 0.

If **Two-Phase Flow Timeout** is set to 0.0 seconds, the outputs that represent flow rate will report a flow rate of 0 as soon as two-phase flow is detected.

# 4.5.3 Configure Density Damping

Display	Not available
ProLink III	Device Tools > Configuration > Process Measurement > Density
Field Communicator	Configure > Manual Setup > Measurements > Density > Density Damping

#### **Overview**

**Density Damping** controls the amount of damping that will be applied to the line density value.

Damping is used to smooth out small, rapid fluctuations in process measurement. **Damping Value** specifies the time period (in seconds) over which the transmitter will spread changes in the process variable. At the end of the interval, the internal value will reflect 63% of the change in the actual measured value.

## Tip

Density damping affects all process variables that are calculated from line density.

### **Procedure**

Set **Density Damping** to the value you want to use.

The default value is 1.6 seconds. The range depends on the core processor type and the setting of **Update Rate**, as shown in the following table:

Update Rate setting	Damping range
Normal	0 to 51.2 seconds
Special	0 to 40.96 seconds

# Tips

- A high damping value makes the process variable appear smoother because the reported value changes slowly.
- A low damping value makes the process variable appear more erratic because the reported value changes more quickly.

- Whenever the damping value is non-zero, the reported measurement will lag the actual measurement because the reported value is being averaged over time.
- In general, lower damping values are preferable because there is less chance of data loss, and less lag time between the actual measurement and the reported value.

The value you enter is automatically rounded off to the nearest valid value. The valid values for **Density Damping** depend on the setting of **Update Rate**.

Update Rate setting	Valid damping values
Normal	0.0, 0.2, 0.4, 0.8, 1.6, 3.2, 6.4, 12.8, 25.6, 51.2
Special	0.0, 0.04, 0.08, 0.16, 0.32, 0.64, 1.28, 2.56, 5.12, 10.24, 20.48, 40.96

# **Effect of Density Damping on volume measurement**

**Density Damping** affects liquid volume measurement. Liquid volume values are calculated from the damped density value rather than the measured density value. **Density Damping** does not affect gas standard volume measurement.

# 4.5.4 Configure Density Cutoff

Display	Not available
ProLink III	Device Tools > Configuration > Process Measurement > Density
Field Communicator	Configure > Manual Setup > Measurements > Density > Density Cutoff

#### **Overview**

**Density Cutoff** specifies the lowest density value that will be reported as measured. All density values below this cutoff will be reported as 0.

#### **Procedure**

Set **Density Cutoff** to the value you want to use.

For most applications, the default setting  $(0.2 \text{ g/cm}^3)$  is sufficient. The range is  $0.0 \text{ g/cm}^3$  to  $0.5 \text{ g/cm}^3$ .

# **Effect of Density Cutoff on volume measurement**

**Density Cutoff** affects liquid volume measurement. If the density value goes below **Density Cutoff**, the volume flow rate is reported as 0. **Density Cutoff** does not affect gas standard volume measurement. Gas standard volume values are always calculated from the value configured for **Standard Gas Density** or polled value if configured for polled base density.

# 4.6 Configure temperature measurement

The temperature measurement parameters control how temperature data from the sensor is reported.

# 4.6.1 Configure Temperature Measurement Unit

Display	OFF-LINE MAINT > OFF-LINE CONFG > UNITS > TEMP
ProLink III	Device Tools > Configuration > Process Measurement > Temperature
Field Communicator	Configure > Manual Setup > Measurements > Temperature > Temperature Unit

#### **Overview**

**Temperature Measurement Unit** specifies the unit that will be used for temperature measurement.

## **Procedure**

Set **Temperature Measurement Unit** to the option you want to use.

The default setting is Degrees Celsius.

# **Options for Temperature Measurement Unit**

The transmitter provides a standard set of units for **Temperature Measurement Unit**. Different communications tools may use different labels for the units.

	Label		
Unit description	Display	ProLink III	Field Communica- tor
Degrees Celsius	°C	°C	degC
Degrees Fahrenheit	°F	°F	degF
Degrees Rankine	°R	°R	degR
Kelvin	°K	°K	Kelvin

# 4.6.2 Configure Temperature Damping

Display	Not available
ProLink III	Device Tools > Configuration > Process Measurement > Temperature
Field Communicator	Configure > Manual Setup > Measurements > Temperature > Temp Damping

#### **Overview**

**Temperature Damping** controls the amount of damping that will be applied to the line temperature value, when the on-board temperature data is used (RTD).

Damping is used to smooth out small, rapid fluctuations in process measurement. **Damping Value** specifies the time period (in seconds) over which the transmitter will spread changes in the process variable. At the end of the interval, the internal value will reflect 63% of the change in the actual measured value.

### Tip

**Temperature Damping** affects all process variables, compensations, and corrections that use temperature data from the sensor.

#### **Procedure**

Enter the value you want to use for **Temperature Damping**.

The default value is 4.8 seconds. The range is 0.0 to 38.4 seconds.

## **Tips**

- A high damping value makes the process variable appear smoother because the reported value changes slowly.
- A low damping value makes the process variable appear more erratic because the reported value changes more quickly.
- Whenever the damping value is non-zero, the reported measurement will lag the actual measurement because the reported value is being averaged over time.
- In general, lower damping values are preferable because there is less chance of data loss, and less lag time between the actual measurement and the reported value.

The value you enter is automatically rounded off to the nearest valid value. Valid values for **Temperature Damping** are 0, 0.6, 1.2, 2.4, 4.8, ... 38.4.

# 4.6.3 Effect of Temperature Damping on process measurement

**Temperature Damping** affects all processes and algorithms that use temperature data from the internal sensor RTD.

## Temperature compensation

Temperature compensation adjusts process measurement to compensate for the effect of temperature on the sensor tubes.

# 4.6.4 Configure Temperature Input

Temperature data from the on-board temperature sensor (RTD) is always available. Optionally, you can set up an external temperature device and use external temperature data.

Choose Device Tools > Configuration > Process Measurement > Temperature > Source.

# 4.7 Configure pressure compensation

Pressure compensation adjusts process measurement to compensate for the pressure effect on the sensor. The pressure effect is the change in the sensor's sensitivity to flow and density caused by the difference between the calibration pressure and the process pressure.

#### Tip

Not all sensors or applications require pressure compensation. The pressure effect for a specific sensor model can be found in the product data sheet located at <a href="https://www.emerson.com">www.emerson.com</a>. If you are uncertain about implementing pressure compensation, contact customer service.

## **Prerequisites**

You will need the flow factor, density factor, and calibration pressure values for your sensor.

- For the flow factor and density factor, see the product data sheet for your sensor.
- For the calibration pressure, see the calibration sheet for your sensor. If the data is unavailable, use 20 PSI.

# 4.7.1 Configure pressure compensation using ProLink III

- Choose Device Tools > Configuration > Process Measurement > Pressure Compensation.
- 2. Set **Pressure Compensation Status** to Enabled.
- 3. Set **Pressure Unit** to the appropriate unit.

If you will use an external pressure value, set **Pressure Unit** to match the pressure unit used by the external pressure device.

4. Enter **Flow Calibration Pressure** for your sensor.

The calibration pressure is the pressure at which your sensor was calibrated, and defines the pressure at which there is no pressure effect. If the data is unavailable, enter 20 PSI.

5. Enter **Flow Factor** for your sensor.

The flow factor is the percent change in the flow rate per PSI. When entering the value, reverse the sign.

Example: If the flow factor is 0.000004 % per PSI, enter -0.000004 % per PSI.

6. Enter **Density Factor** for your sensor.

The density factor is the change in fluid density, in  $g/cm^3/PSI$ . When entering the value, reverse the sign.

## Example:

If the density factor is 0.000006 g/cm<sup>3</sup>/PSI, enter -0.000006g/cm<sup>3</sup>/PSI.

7. Set **Pressure Source** to the method that the transmitter will use to obtain pressure data.

Option	Description
Poll for external value	The transmitter will poll an external pressure device, using HART protocol over the primary mA Output.
Fixed Value or Digital Communications	<ul> <li>The transmitter will use the pressure value that it reads from memory.</li> <li>Fixed Value: The configured value is used.</li> <li>Digital Communications: A host writes transmitter data to transmitter memory.</li> </ul>

- 8. If you chose to poll for pressure data:
  - a. Select the **Polling Slot** to use.
  - b. Set **Polling Control** to Poll as Primary or Poll as Secondary, and click **Apply**.

## Tip

- Poll as Primary: No other HART masters will be on the network.
- Poll as Secondary: Other HART masters will be on the network. The Field Communicator is not a HART master.
- c. Set **External Device Tag** to the HART tag of the external pressure device, and click **Apply**.
- d. Ensure that the primary mA Output is wired to support HART communications with the external pressure device.
- 9. If you chose to use a fixed pressure value:
  - a. Set Fixed Value to the value to use, and click Apply
- 10. If you want to use digital communications, click **Apply**, then perform the necessary host programming and communications setup to write pressure data to the transmitter at appropriate intervals.

# **Postrequisites**

If you are using an external pressure value, verify the setup by checking the **External Pressure** value displayed in the Inputs area of the main window.

# 4.7.2 Configure pressure compensation using the Field Communicator

 Choose Online > Configure > Manual Setup > Measurements > External Pressure/ Temperature > Pressure.

- 2. Set **Pressure Compensation** to Enabled.
- 3. Enter Flow Cal Pressure for your sensor.

The calibration pressure is the pressure at which your sensor was calibrated, and defines the pressure at which there is no pressure effect. If the data is unavailable, enter 20 PSI.

4. Enter **Flow Press Factor** for your sensor.

The flow factor is the percent change in the flow rate per PSI. When entering the value, reverse the sign.

## Example:

If the flow factor is 0.000004 % per PSI, enter -0.000004 % per PSI.

5. Enter **Dens Press Factor** for your sensor.

The density factor is the change in fluid density, in  $g/cm^3/PSI$ . When entering the value, reverse the sign.

# Example:

If the density factor is 0.000006 g/cm<sup>3</sup>/PSI, enter -0.000006g/cm<sup>3</sup>/PSI.

6. Determine how the transmitter will obtain pressure data, and perform the required setup.

Option	Setup
A user-configured static pressure value	<ul><li>a. Set Pressure Unit to the desired unit.</li><li>b. Set Compensation Pressure to the desired value.</li></ul>
Polling for pressure	<ul> <li>a. Ensure that the primary mA Output has been wired to support HART polling.</li> <li>b. Choose Online &gt; Configure &gt; Manual Setup &gt; Measurements &gt; External Pressure/Temperature &gt; External Polling.</li> <li>c. Set Poll Control to Poll As Primary Host or Poll as Secondary Host.</li> <li>d. Choose an unused polling slot.</li> <li>e. Set External Tag to the HART tag of the external pressure device.</li> <li>f. Set Polled Variable to Pressure.</li> </ul>
	<ul> <li>Poll as Primary: No other HART masters will be on the network.</li> <li>Poll as Secondary: Other HART masters will be on the network. The Field Communicator is not a HART master.</li> </ul>
A value written by digital communications	<ul> <li>a. Set Pressure Unit to the desired unit.</li> <li>b. Perform the necessary host programming and communications setup to write pressure data to the transmitter at appropriate intervals.</li> </ul>

# **Postrequisites**

If you are using an external pressure value, verify the setup by choosing **Service Tools > Variables > External Variables** and checking the value displayed for **External Pressure**.

# 4.7.3 Options for Pressure Measurement Unit

The transmitter provides a standard set of measurement units for **Pressure Measurement Unit**. Different communications tools may use different labels for the units. In most applications, **Pressure Measurement Unit** should be set to match the pressure measurement unit used by the remote device.

		Label	
Unit description	Display	ProLink III	Field Communicator
Feet water @ 68 °F	FTH2O	Ft Water @ 68°F	ftH2O
Inches water @ 4 °C	INW4C	In Water @ 4°C	inH2O @4DegC
Inches water @ 60 °F	INW60	In Water @ 60°F	inH2O @60DegF
Inches water @ 68 °F	INH2O	In Water @ 68°F	inH2O
Millimeters water @ 4 °C	mmW4C	mm Water @ 4°C	mmH2O @4DegC
Millimeters water @ 68 °F	mmH2O	mm Water @ 68°F	mmH2O
Millimeters mercury @ 0 °C	mmHG	mm Mercury @ 0°C	mmHg
Inches mercury @ 0 °C	INHG	In Mercury @ 0°C	inHG
Pounds per square inch	PSI	PSI	psi
Bar	BAR	bar	bar
Millibar	mBAR	millibar	mbar
Grams per square centimeter	G/SCM	g/cm2	g/Sqcm
Kilograms per square centimeter	KG/SCM	kg/cm2	kg/Sqcm
Pascals	PA	pascals	Pa
Kilopascals	KPA	Kilopascals	kPa
Megapascals	MPA	Megapascals	MPa
Torr@0°C	TORR	Torr @ 0°C	torr
Atmospheres	ATM	atms	atms

# 5 Configure device options and preferences

# Topics covered in this chapter:

- Configure the transmitter display
- Enable or disable operator actions from the display
- Configure security for the display menus
- Configure response time parameters
- Configure alert handling
- Configure informational parameters

# 5.1 Configure the transmitter display

You can control the process variables shown on the display and a variety of display behaviors.

# 5.1.1 Configure the language used for the display

Display	OFF-LINE MAINT > OFF-LINE CONFG > DISPLAY > LANG
ProLink III	Device Tools > Configuration > Transmitter Display > General
Field Communicator	Configure > Manual Setup > Display > Language

# **Overview**

**Display Language** controls the language used for process data and menus on the display.

#### **Procedure**

Select the language you want to use.

The languages available depend on your transmitter model and version.

# 5.1.2 Configure the process variables and diagnostic variables shown on the display

Display	Not available
ProLink III	Device Tools > Configuration > Transmitter Display > Display Variables
Field Communicator	Configure > Manual Setup > Display > Display Variables

#### Overview

You can control the process variables and diagnostic variables shown on the display, and the order in which they appear. The display can scroll through up to 15 variables in any order you choose. In addition, you can repeat variables or leave slots unassigned.

#### Restrictions

- You cannot set Display Variable 1 to None or to a diagnostic variable. Display Variable 1 must be set to a process variable.
- If you have configured Display Variable 1 to track the primary mA Output, you cannot change
  the setting of Display Variable 1 using this procedure. To change the setting of Display
  Variable 1, you must change the configuration of mA Output Process Variable for the primary
  mA Output.

#### Note

If you configure a display variable as a volume process variable and then change **Volume Flow Type**, the display variable is automatically changed to the equivalent process variable. For example, Volume Flow Rate would be changed to Gas Standard Volume Flow Rate.

#### **Procedure**

For each display variable you want to change, assign the process variable you want to use.

## **Example: Default display variable configuration**

Display variable	Process variable assignment
Display Variable 1	Mass flow
Display Variable 2	Mass total
Display Variable 3	Volume flow
Display Variable 4	Volume total
Display Variable 5	Density
Display Variable 6	Temperature
Display Variable 7	External pressure
Display Variable 8	Mass flow
Display Variable 9	None
Display Variable 10	None
Display Variable 11	None
Display Variable 12	None
Display Variable 13	None
Display Variable 14	None
Display Variable 15	None

# Configure Display Variable 1 to track the primary mA Output

Display	OFF-LINE MAINT > OFF-LINE CONFG > DISPLY > VAR 1
ProLink III	Device Tools > Configuration > Transmitter Display > Display Security
Field Communicator	Configure > Manual Setup > Display > Display Variables

#### **Overview**

You can configure **Display Variable 1** to track **mA Output Process Variable** for the primary mA Output. When tracking is enabled, you can control **Display Variable 1** from the display menu.

#### Tip

This feature is the only way to configure a display variable from the display menus, and it applies only to **Display Variable 1**.

#### **Procedure**

Configure **Display Variable 1** to track the primary mA Output.

**Display Variable 1** will automatically be set to match **mA Output Process Variable** for the primary mA Output. If you change the configuration of **mA Output Process Variable**, **Display Variable 1** will be updated automatically.

# 5.1.3 Configure the number of decimal places (precision) shown on the display

Display	Not available
ProLink III	Device Tools > Configuration > Transmitter Display > Display Variables
Field Communicator	Configure > Manual Setup > Display > Decimal Places

## **Overview**

You can specify the number of decimal places (precision) that are shown on the display for each process variable or diagnostic variable. You can set the precision independently for each variable.

The display precision does not affect the actual value of the variable or the value used in calculations.

# **Procedure**

- 1. Select a variable.
- 2. Set **Number of Decimal Places** to the number of decimal places you want shown when the process variable or diagnostic variable appears on the display.

For temperature and density process variables, the default value is 2 decimal places. For all other variables, the default value is 4 decimal places. The range is 0 to 5.

#### Tip

The lower the precision, the greater the change must be for it to be reflected on the display. Do not set the precision too low or too high to be useful.

# 5.1.4 Configure the refresh rate of data shown on the display

Display	OFF-LINE MAINT > OFF-LINE CONFG > DISPLAY > RATE
ProLink III	Device Tools > Configuration > Transmitter Display > Display Variables
Field Communicator	Configure > Manual Setup > Display > Display Variable Menu Features > Refresh Rate

## **Overview**

You can set **Refresh Rate** to control how frequently data is refreshed on the display.

## **Procedure**

Set Refresh Rate to the desired value.

The default value is 200 milliseconds. The range is 100 milliseconds to 10,000 milliseconds (10 seconds).

# 5.1.5 Enable or disable automatic scrolling through the display variables

Display	OFF-LINE MAINT > OFF-LINE CONFG > DISPLAY > AUTO SCRLL
ProLink III	Device Tools > Configuration > Transmitter Display > General
Field Communicator	Configure > Manual Setup > Display > Display Variable Menu Features > Auto Scroll

#### Overview

You can configure the display to automatically scroll through the configured display variables or to show a single display variable until the operator activates **Scroll**. When you set automatic scrolling, you can also configure the length of time each display variable is displayed.

## **Procedure**

1. Enable or disable **Auto Scroll** as desired.

Option	Description
Enabled	The display automatically scrolls through each display variable as specified by <b>Scroll Rate</b> . The operator can move to the next display variable at any time using <b>Scroll</b> .
Disabled (de- fault)	The display shows <b>Display Variable 1</b> and does not scroll automatically. The operator can move to the next display variable at any time using <b>Scroll</b> .

2. If you enabled **Auto Scroll**, set **Scroll Rate** as desired.

The default value is 10 seconds.

## Tip

Scroll Rate may not be available until you apply Auto Scroll.

# 5.1.6 Enable or disable the display backlight

Display	OFF-LINE MAINT > OFF-LINE CONFG > DISPLAY > BKLT
ProLink III	Device Tools > Configuration > Transmitter Display > General
Field Communicator	Configure > Manual Setup > Display > Backlight

## **Overview**

You can enable or disable the display backlight.

## **Procedure**

Enable or disable Backlight.

The default setting is Enabled.

# 5.1.7 Enable or disable Status LED Blinking

Display	Not available
ProLink III	Device Tools > Configuration > Transmitter Display > General
Field Communicator	Configure > Manual Setup > Display > Display Variable Menu Features > Status LED Blink-
	ing

# **Overview**

By default, the status LED blinks (flashes) to indicate unacknowledged alarms. If you disable **Status LED Blinking**, the status LED does not blink, whether alarms are acknowledged or not. It still changes color to indicate active alarms.

## **Procedure**

Enable or disable **Status LED Blinking**.

The default setting is Enabled.

# 5.2 Enable or disable operator actions from the display

You can configure the transmitter to let the operator perform specific actions using the display.

- Enable or disable Totalizer Start/Stop from the display (Section 5.2.1)
- Enable or disable Totalizer Reset from the display (Section 5.2.2)
- Enable or disable the Acknowledge All Alerts display command (Section 5.2.3)

# 5.2.1 Enable or disable Totalizer Start/Stop from the display

Display	OFF-LINE MAINT > OFF-LINE CONFG > DISPLAY > TOTALS STOP
ProLink III	Device Tools > Configuration > Totalizer Control Methods
Field Communicator	Configure > Manual Setup > Display > Display Variable Menu Features > Start/Stop Totalizers

#### **Overview**

You can control whether or not the operator is able to start and stop totalizers and inventories from the display.

### Restrictions

- You cannot start and stop totalizers individually from the display. All totalizers are started or stopped together.
- You cannot start or stop inventories separately from totalizers. When a totalizer is started or stopped, the associated inventory is also started or stopped.
- If the petroleum measurement application is installed, the operator must enter the off-line password to perform this function, even if the off-line password is not enabled.

### **Procedure**

- 1. Ensure that at least one totalizer is configured as a display variable.
- Enable or disable Totalizer Reset as desired.

Option	Description
Enabled	Operators can start and stop totalizers and inventories from the display, if at least one totalizer is configured as a display variable.
Disabled (default)	Operators cannot start and stop totalizers and inventories from the display.

# 5.2.2 Enable or disable Totalizer Reset from the display

Display	OFF-LINE MAINT > OFF-LINE CONFG > DISPLAY > TOTALS RESET
ProLink III	Device Tools > Configuration > Totalizer Control Methods
Field Communicator	Configure > Manual Setup > Display > Display Variable Menu Features > Totalizer Reset

#### **Overview**

You can configure whether or not the operator is able to reset totalizers from the display.

## Restrictions

- This parameter does not apply to inventories. You cannot reset inventories from the display.
- You cannot use the display to reset all totalizers as a group. You must reset totalizers individually.
- If the petroleum measurement application is installed, the operator must enter the off-line password to perform this function, even if the off-line password is not enabled.

#### **Procedure**

1. Ensure that the totalizers you want to reset have been configured as display variables.

If the totalizer is not configured as a display variable, the operator will not be able to reset it.

2. Enable or disable resetting the totalizer as desired.

Option	Description
Enabled	Operators can reset a totalizer from the display, if the totalizer is configured as a display variable.
Disabled (default)	Operators cannot reset totalizers from the display.

# 5.2.3 Enable or disable the Acknowledge All Alerts display command

Display	OFF-LINE MAINT > OFF-LINE CONFG > DISPLAY > ALARM
ProLink III	Device Tools > Configuration > Transmitter Display > Ack All
Field Communicator	Configure > Manual Setup > Display > Offline Variable Menu Features > Acknowledge All

#### **Overview**

You can configure whether or not the operator can use a single command to acknowledge all alerts from the display.

## **Procedure**

1. Ensure that the alert menu is accessible from the display.

To acknowledge alerts from the display, operators must have access to the alert menu.

2. Enable or disable **Acknowledge All Alerts** as desired.

Option	Description
Enabled (default)	Operators can use a single display command to acknowledge all alerts at once.
Disabled	Operators cannot acknowledge all alerts at once. Each alert must be acknowledged separately.

# 5.3 Configure security for the display menus

Display	OFF-LINE MAINT > OFF-LINE CONFG > DISPLAY
ProLink III	Device Tools > Configuration > Transmitter Display > Display Security
Field Communicator	Configure > Manual Setup > Display > Offline Variable Menu Features

# **Overview**

You can control operator access to different sections of the display off-line menu. You can also configure a password to control access.

## **Procedure**

1. To control operator access to the maintenance section of the off-line menu, enable or disable **Off-Line Menu**.

Option	Description
Enabled (de- fault)	Operator can access the maintenance section of the off-line menu. This access is required for configuration and calibration, but is not required to view alerts or to access Smart Meter Verification (if applicable).
Disabled	Operator cannot access the maintenance section of the off-line menu.

2. To control operator access to the alert menu, enable or disable **Alert Menu**.

(	Option	Description
E	Enabled (default)	Operator can access the alert menu. This access is required to view and acknowledge alerts, but is not required for Smart Meter Verification (if applicable), configuration, or calibration.

Option	Description
Disabled	Operator cannot access the alert menu.

#### Note

The transmitter status LED changes color to indicate that there are active alerts, but does not show specific alerts.

3. To require a password for access to the maintenance section of the off-line menu and the Smart Meter Verification menu, enable or disable **Off-Line Password**.

Option	Description
Enabled	Operator is prompted for the off-line password at entry to the Smart Meter Verification menu (if applicable) or entry to the maintenance section of the off-line menu.
Disabled (de- fault)	No password is required for entry to the Smart Meter Verification menu (if applicable) or entry to the maintenance section of the off-line menu.

4. To require a password to access the alert menu, enable or disable **Alert Password**.

Option	Description
Enabled	Operator is prompted for the off-line password at entry to the alert menu.
Disabled (default)	No password is required for entry to the alert menu.

If both **Off-Line Password** and **Alert Password** are enabled, the operator is prompted for the off-line password to access the off-line menu, but is not prompted thereafter.

5. Set **Off-Line Password** to the desired value.

The default value is 1234. The range is 0000 to 9999.

The same value is used for both the off-line password and the alert password.

## Tip

Record your password for future reference.

# 5.4 Configure response time parameters

You can configure the rate at which process data is polled and process variables are calculated.

# 5.4.1 Configure Update Rate

Display	Not available
ProLink III	Device Tools > Configuration > Process Measurement > Response > Update Rate
Field Communicator	Configure > Manual Setup > Measurements > Update Rate

#### **Overview**

**Update Rate** controls the rate at which process data is polled and process variables are calculated. **Update Rate** = Special produces faster and "noisier" response to changes in the process. Do not use Special mode unless required by your application.

## Tip

For systems with a standard core processor, Special mode can improve performance for applications with entrained air or Empty-Full-Empty conditions. This does not apply to systems with an enhanced core processor.

# **Prerequisites**

Before setting **Update Rate** to Special:

- Check the effects of Special mode on specific process variables.
- Contact customer support.

## **Procedure**

1. Set **Update Rate** as desired.

Option	Description
Normal	All process data is polled at the rate of 20 times per second (20 Hz). All process variables are calculated at 20 Hz. This option is appropriate for most applications.
Special	A single, user-specified process variable is polled at the rate of 100 times per second (100 Hz). Other process data is polled at 6.25 Hz. Some process, diagnostic, and calibration data is not polled.  All available process variables are calculated at 100 Hz.
	Use this option only if required by your application.

If you change **Update Rate**, the settings for **Flow Damping**, **Density Damping**, and **Temperature Damping** are automatically adjusted.

2. If you set **Update Rate** to Special, select the process variable to be polled at 100 Hz.

# Effects of Update Rate = Special

# Incompatible features and functions

Special mode is not compatible with the following features and functions:

- Enhanced events. Use basic events instead.
- All calibration procedures.
- Zero verification.
- Restoring the factory zero or the prior zero.

If required, you can switch to Normal mode, perform the desired procedures, and then return to Special mode.

## **Process variable updates**

Some process variables are not updated when Special mode is enabled.

Table 5-1: Special mode and process variable updates

Always polled and updated	Updated only when the petroleum measurement application is disabled	Never updated
<ul> <li>Mass flow</li> <li>Volume flow</li> <li>Gas standard volume flow</li> <li>Density</li> <li>Temperature</li> <li>Drive gain</li> <li>LPO amplitude</li> <li>Status [contains Event 1 and Event 2 (basic events)]</li> <li>Mass total</li> <li>Volume total</li> <li>Live zero</li> <li>Gas standard volume total</li> </ul>	<ul> <li>RPO amplitude</li> <li>Core input voltage</li> <li>Mass inventory</li> <li>Volume inventory</li> <li>Gas standard volume inventory</li> </ul>	All other process variables and calibration data. They retain the values held at the time you enabled Special mode.

# 5.4.2 Configure Response Time

Display	Not available
ProLink III	Device Tools > Configuration > Process Measurement > Response > Response Time
Field Communicator	Not available

## **Overview**

**Response Time** is used to apply a different algorithm to the calculation of process variables from the raw process data.

## Restriction

**Response Time** is available only on systems with the enhanced core processor.

## **Procedure**

Set **Response Time** as desired.

Option	Description
Normal (Legacy)	Transmitter calculates process variables at the standard speed. This option is selected if this parameter was configured on an earlier version of ProLink III software.
Special (Legacy)	Transmitter calculates process variables at a faster speed. This option is selected if this parameter was configured on an earlier version of ProLink III software.
Normal - Optimal Filtering	Transmitter calculates process variables at standard filtering and speed.
Low Filtering - Fastest Response	Transmitter calculates process variables at the fastest speed.
High Filtering - Smoothest Output	Transmitter calculates process variables at the smoothest (least noisy) response to changes in the process.
Service	For factory use only.

# 5.5 Configure alert handling

The alert handling parameters control the transmitter's response to process and device conditions.

# 5.5.1 Configure Fault Timeout

Display	Not available	
ProLink III	Device Tools > Configuration > Fault Processing	
Field Communicator	Configure > Alert Setup > Alert Severity > Fault Timeout	

#### **Overview**

**Fault Timeout** controls the delay before fault actions are performed.

## Restriction

**Fault Timeout** is applied only to the following alerts (listed by Status Alert Code): A003, A004, A005, A008, A016, A017, A033. For all other alerts, fault actions are performed as soon as the alert is detected.

## **Procedure**

Set Fault Timeout as desired.

The default value is 0 seconds. The range is 0 to 60 seconds.

If you set **Fault Timeout** to 0, fault actions are performed as soon as the alert condition is detected.

The fault timeout period begins when the transmitter detects an alert condition. During the fault timeout period, the transmitter continues to report its last valid measurements.

If the fault timeout period expires while the alert is still active, the fault actions are performed. If the alert condition clears before the fault timeout expires, no fault actions are performed.

# 5.5.2 Configure Status Alert Severity

Display	Not available
ProLink III	Device Tools > Configuration > Alert Severity
Field Communicator	Configure > Alert Setup > Alert Severity > Set Alert Severity

## **Overview**

Use **Status Alert Severity** to control the fault actions that the transmitter performs when it detects an alert condition.

### Restrictions

- For some alerts, Status Alert Severity is not configurable.
- For some alerts, **Status Alert Severity** can be set only to two of the three options.

## Tip

Use the default settings for **Status Alert Severity** unless you have a specific requirement to change them.

## **Procedure**

- 1. Select a status alert.
- 2. For the selected status alert, set **Status Alert Severity** as desired.

Option	Description
Fault	<ul> <li>Actions when fault is detected:</li> <li>The alert is posted to the Alert List.</li> <li>Outputs go to the configured fault action (after Fault Timeout has expired, if applicable).</li> <li>Digital communications go to the configured fault action (after Fault Timeout has expired, if applicable).</li> <li>The status LED (if available) changes to red or yellow (depending on alert severity).</li> <li>Actions when alert clears:</li> <li>Outputs return to normal behavior.</li> <li>Digital communications return to normal behavior.</li> <li>The status LED (if available) returns to green and may or may not flash.</li> </ul>
Informa- tional	<ul> <li>Actions when fault is detected:</li> <li>The alert is posted to the Alert List.</li> <li>The status LED (if available) changes to red or yellow (depending on alert severity).</li> <li>Actions when alert clears:</li> <li>The status LED (if available) returns to green and may or may not flash.</li> </ul>
Ignore	No action

# Status alerts and options for Status Alert Severity

Table 5-2: Status alerts and Status Alert Severity

Alert code	Status message	Default severity	Notes	Configurable?
A001	EEPROM Error (Core Processor)	Fault		No
A002	RAM Error (Core Processor)	Fault		No
A003	No Sensor Response	Fault		Yes
A004	Temperature Overrange	Fault		No
A005	Mass Flow Rate Overrange	Fault		Yes
A006	Characterization Required	Fault		Yes
A008	Density Overrange	Fault		Yes
A009	Transmitter Initializing/ Warming Up	Fault		Yes
A010	Calibration Failure	Fault		No
A011	Zero Calibration Failed: Low	Fault		Yes
A012	Zero Calibration Failed: High	Fault		Yes
A013	Zero Calibration Failed: Unstable	Fault		Yes

 Table 5-2: Status alerts and Status Alert Severity (continued)

Alert code	Status message	Default severity	Notes	Configurable?
A014	Transmitter Failure	Fault		No
A016	Sensor RTD Failure	Fault		Yes
A017 T-Series RTD Failure		Fault		Yes
A018	EEPROM Error (Transmit- ter)	Fault		No
A019	RAM Error (Transmitter)	Fault		No
A020	No Flow Cal Value	Fault		Yes
A021	Incorrect Sensor Type (K1)	Fault		No
A022	Configuration Database Corrupt (Core Processor)	Fault	Applies only to flowmeters with the standard core processor.	No
A023	Internal Totals Corrupt (Core Processor)	Fault	Applies only to flowmeters with the standard core processor.	No
A024	Program Corrupt (Core Processor)	Fault	Applies only to flowmeters with the standard core processor.	No
A025	Boot Sector Fault (Core Processor)	Fault	Applies only to flowmeters with the standard core processor.	No
A026	Sensor/Transmitter Communications Failure	Fault		No
A028	Core Processor Write Failure	Fault		No
A031	Low Power	Fault	Applies only to flowmeters with the enhanced core processor.	No
A032	Meter Verification in Progress: Outputs to Fault	Varies	Applies only to transmitters with Smart Meter Verification. If outputs are set to Last Measured Value, severity is Info. If outputs are set to Fault, severity is Fault.	No
A033	Insufficient Right/Left Pick- off Signal	Fault	Applies only to flowmeters with the enhanced core processor.	Yes
A034	Meter Verification Failed	Fault	Applies only to transmitters with Smart Meter Verification.	Yes
A035	Meter Verification Aborted	Fault	Applies only to transmitters with Smart Meter Verification.	Yes
A100	mA Output 1 Saturated	Informational	Can be set to either Informational or Ignore, but cannot be set to Fault.	Yes
A101	mA Output 1 Fixed	Informational	Can be set to either Informational or Ignore, but cannot be set to Fault.	Yes
A102	Drive Overrange	Informational		Yes

 Table 5-2: Status alerts and Status Alert Severity (continued)

Alert code	Status message	Default severity	Notes	Configurable?
A103	Data Loss Possible (Totals and Inventories)	Informational	Applies only to flowmeters with the enhanced core processor.  Can be set to either Informational or	Yes
			Ignore, but cannot be set to Fault.	
A104	Calibration in Progress	Informational	Can be set to either Informational or Ignore, but cannot be set to Fault.	Yes
A105	Slug Flow	Informational		Yes
A106	Burst Mode Enabled	Informational	Can be set to either Informational or Ignore, but cannot be set to Fault.	Yes
A107	Power Reset Occurred	Informational	Normal transmitter behavior; occurs after every power cycle.	Yes
A108	Basic Event 1 On	Informational	Applies only to basic events.	Yes
A109	Basic Event 2 On	Informational	Applies only to basic events.	Yes
A110	Frequency Output Saturated	Informational	Can be set to either Informational or Ignore, but cannot be set to Fault.	Yes
A111	Frequency Output Fixed	Informational	Can be set to either Informational or Ignore, but cannot be set to Fault.	Yes
A112	Upgrade Transmitter Software	Informational	Applies only to systems with transmitter software earlier than v5.0.	Yes
A113	mA Output 2 Saturated	Informational	Can be set to either Informational or Ignore, but cannot be set to Fault.	Yes
A114	mA Output 2 Fixed	Informational	Can be set to either Informational or Ignore, but cannot be set to Fault.	Yes
A115	No External Input or Polled Data	Informational		Yes
A118	Discrete Output 1 Fixed	Informational	Can be set to either Informational or Ignore, but cannot be set to Fault.	Yes
A119	Discrete Output 2 Fixed	Informational	Can be set to either Informational or Ignore, but cannot be set to Fault.	Yes
A131	Meter Verification in Pro- gress: Outputs to Last Measured Value	Informational	Applies only to transmitters with Smart Meter Verification.	Yes
A132	Sensor Simulation Active	Informational	Applies only to flowmeters with the enhanced core processor.  Can be set to either Informational or Ignore, but cannot be set to Fault.	To Informational or Ignore only

Table 5-2: Status alerts and Status Alert Severity (continued)

Alert code	Status message	Default severity	Notes	Configurable?
A141	DDC trigger(s) have completed	Informational	Applies only to flowmeters with the enhanced core processor.  Can be set to either Informational or Ignore, but cannot be set to Fault.	Yes

# 5.6 Configure informational parameters

The informational parameters can be used to identify or describe your meter. They are not used in process measurement and they are not required.

# 5.6.1 Configure Sensor Serial Number

Display	Not available
ProLink III	Device Tools > Configuration > Informational Parameters > Sensor
Field Communicator	Configure > Manual Setup > Info Parameters > Sensor Information > Sensor Serial Num-
	ber

#### **Overview**

**Sensor Serial Number** lets you store the serial number of the sensor component of your flowmeter in transmitter memory. This parameter is not used in processing and is not required.

#### **Procedure**

- 1. Obtain the sensor serial number from your sensor tag.
- 2. Enter the serial number in the **Sensor Serial Number** field.

## 5.6.2 Configure Sensor Material

Display	Not available
ProLink III	Device Tools > Configuration > Informational Parameters > Sensor
Field Communicator	Configure > Manual Setup > Info Parameters > Sensor Information > Tube Wetted Material

#### **Overview**

**Sensor Material** lets you store the type of material used for your sensor's wetted parts in transmitter memory. This parameter is not used in processing and is not required.

#### **Procedure**

1. Obtain the material used for your sensor's wetted parts from the documents shipped with your sensor, or from a code in the sensor model number.

To interpret the model number, refer to the product data sheet for your sensor.

2. Set **Sensor Material** to the appropriate option.

## 5.6.3 Configure Sensor Liner Material

Display	Not available
ProLink III	Device Tools > Configuration > Informational Parameters > Sensor
Field Communicator	Configure > Manual Setup > Info Parameters > Sensor Information > Tube Lining

#### **Overview**

**Sensor Liner Material** lets you store the type of material used for your sensor liner in transmitter memory. This parameter is not used in processing and is not required.

#### **Procedure**

1. Obtain your sensor's liner material from the documents shipped with your sensor, or from a code in the sensor model number.

To interpret the model number, refer to the product data sheet for your sensor.

2. Set **Sensor Liner Material** to the appropriate option.

## 5.6.4 Configure Sensor Flange Type

Display	Not available
ProLink III	Device Tools > Configuration > Informational Parameters > Sensor
Field Communicator	Configure > Manual Setup > Info Parameters > Sensor Information > Sensor Flange

#### **Overview**

**Sensor Flange Type** lets you store your sensor's flange type in transmitter memory. This parameter is not used in processing and is not required.

#### **Procedure**

1. Obtain your sensor's flange type from the documents shipped with your sensor, or from a code in the sensor model number.

To interpret the model number, refer to the product data sheet for your sensor.

2. Set **Sensor Flange Type** to the appropriate option.

# 5.6.5 Configure Descriptor

Display	Not available
ProLink III	Device Tools > Configuration > Informational Parameters > Transmitter
Field Communicator	Configure > Manual Setup > Info Parameters > Transmitter Info > Descriptor

#### **Overview**

**Descriptor** lets you store a description in transmitter memory. The description is not used in processing and is not required.

#### **Procedure**

Enter a description for the transmitter or device

You can use up to 16 characters for the description.

# 5.6.6 Configure Message

Display	Not available
ProLink III	Device Tools > Configuration > Informational Parameters > Transmitter
Field Communicator	Configure > Manual Setup > Info Parameters > Transmitter Info > Message

#### **Overview**

**Message** lets you store a short message in transmitter memory. This parameter is not used in processing and is not required.

#### **Procedure**

Enter a short message for the transmitter or device.

Your message can be up to 32 characters long.

# 5.6.7 Configure Date

Display	Not available
ProLink III	Device Tools > Configuration > Informational Parameters > Transmitter
Field Communicator	Configure > Manual Setup > Info Parameters > Transmitter Info > Date

#### **Overview**

**Date** lets you store a static date (not updated by the transmitter) in transmitter memory. This parameter is not used in processing and is not required.

#### **Procedure**

Enter the date you want to use, in the form *mm/dd/yyyy*.

#### Tip

ProLink III provides a calendar tool to help you select the date.

# 6 Integrate the meter with the control system

#### **Topics covered in this chapter:**

- Configure the transmitter channels
- Configure the mA Output
- Configure the Frequency Output
- Configure the Discrete Output
- Configure events
- Configure digital communications

# 6.1 Configure the transmitter channels

Display	OFF-LINE MAINT > OFF-LINE CONFG > IO > CH B
ProLink III	Device Tools > Configuration > I/O > Outputs
Field Communicator	Configure > Manual Setup > Inputs/Outputs > Channels > Channel B

#### **Overview**

You can configure Channel B on your transmitter to operate as a Frequency Output or a Discrete Output. The channel configuration must match the wiring at the transmitter terminals.

#### Prerequisites

To avoid causing process errors:

- Configure the channels before configuring the outputs.
- Before changing the channel configuration, ensure that all control loops affected by the channel are under manual control.

#### **Procedure**

Set Channel B as desired.

Option	Description
Frequency Output	Channel B will operate as a Frequency Output.
Discrete Output	Channel B will operate as a Discrete Output.

#### **Postrequisites**

For each channel that you configured, perform or verify the corresponding input or output configuration. When the configuration of a channel is changed, the channel's behavior will be controlled by the configuration that is stored for the selected input or output type, and the stored configuration may not be appropriate for your process.

After verifying channel and output configuration, return the control loop to automatic control.

# 6.2 Configure the mA Output

The mA Output is used to report the configured process variable. The mA Output parameters control how the process variable is reported.

Your transmitter has one mA Output: Channel A.

#### Restriction

The process variable assigned to the primary mA Output is automatically assigned to the Frequency Output. You cannot assign a different process variable.

#### **Important**

Whenever you change an mA Output parameter, verify all other mA Output parameters before returning the meter to service. In some situations, the transmitter automatically loads a set of stored values, and these values may not be appropriate for your application.

## 6.2.1 Configure mA Output Process Variable

Display	OFF-LINE MAINT > OFF-LINE CONFG > IO > CH A > AO
ProLink III	Device Tools > Configuration > I/O > Outputs > mA Output
Field Communicator	Configure > Manual Setup > Inputs/Outputs > mA Output

#### **Overview**

Use **mA Output Process Variable** to select the variable that is reported over the mA Output. This variable is applied automatically to the Frequency Output.

#### **Prerequisites**

- If you plan to configure the output to report volume flow, ensure that you have set **Volume Flow Type** as desired: Liquid or Gas Standard Volume.
- If you are using the HART variables, be aware that changing the configuration of mA
   Output Process Variable will change the configuration of the HART Primary Variable
   (PV) and the HART Tertiary Variable (TV).

• If you have configured **Display Variable 1** to track **mA Output Process Variable**, be aware that changing the configuration of **mA Output Process Variable** will change the contents of **Display Variable 1**.

#### **Procedure**

Set mA Output Process Variable as desired.

The default setting is Mass Flow Rate.

#### **Postrequisites**

If you changed the setting of **mA Output Process Variable**, verify the settings of **Lower Range Value** (LRV) and **Upper Range Value** (URV).

## **Options for mA Output Process Variable**

The transmitter provides a basic set of options for **mA Output Process Variable**, plus several application-specific options. Different communications tools may use different labels for the options.

Table 6-1: Standard mA Output process variables

	Label			
Process variable	Display ProLink III Field Communicator			
Gas standard volume flow rate	GSV F	Gas Standard Volume Flow Rate	Gas vol flo	
Mass flow rate	MFLOW	Mass Flow Rate	Mass flo	
Volume flow rate	VFLOW	Volume Flow Rate	Vol flo	

Table 6-2: PVR mA Output process variables

	Label		
Process variable	Display	ProLink III	Field Communicator
Uncorrected oil flow	OIL	Oil Flow Rate At Line	Oil Flow Rate at Line
Uncorrected water cut	WATER%	Water Cut At Line	Water Cut at Line
Uncorrected water flow	WATER	Water Flow Rate At Line	Water Flow Rate at Line
Corrected oil flow	OIL60	Oil Flow Rate At Reference	Oil Flow Rate at Reference
Corrected water cut	WCT60%	Water Cut At Reference	Water Cut at Reference
Corrected water flow	WTR60	Water Flow Rate At Reference	Water Flow Rate at Reference
Shrinkage factor corrected net oil at line	SFOIL	SF Oil Flow Rate At Line	Shrinkage Factor Oil Flow Rate at Line
Shrinkage factor corrected net oil at 60F	SF060	SF Oil Flow Rate At Reference	Shrinkage Factor Oil Flow Rate at Reference

Table 6-2: PVR mA Output process variables (continued)

	Label		
Process variable	Display	ProLink III	Field Communicator
Shrinkage factor corrected volume of mix at 60F	SFM60	SF Volume Flow Rate At Reference	Shrinkage Factor Volume Flow Rate at Reference

# 6.2.2 Configure Lower Range Value (LRV) and Upper Range Value (URV)

Display	<ul> <li>OFF-LINE MAINT &gt; OFF-LINE CONFG &gt; IO &gt; CH A &gt; 4 mA</li> <li>OFF-LINE MAINT &gt; OFF-LINE CONFG &gt; IO &gt; CH A &gt; 20 mA</li> </ul>
ProLink III	Device Tools > Configuration > I/O > Outputs > mA Output
Field Communicator	<ul> <li>Configure &gt; Manual Setup &gt; Inputs/Outputs &gt; mA Output &gt; mA Output Settings &gt; PV LRV</li> <li>Configure &gt; Manual Setup &gt; Inputs/Outputs &gt; mA Output &gt; mA Output Settings &gt; PV URV</li> </ul>

#### **Overview**

The Lower Range Value (LRV) and Upper Range Value (URV) are used to scale the mA Output, that is, to define the relationship between mA Output Process Variable and the mA Output level.

#### Note

For transmitter software v5.0 and later, if you change **LRV** and **URV** from the factory default values, and you later change **mA Output Process Variable**, **LRV** and **URV** will not reset to the default values.

#### **Prerequisites**

Ensure that **mA** Output Process Variable is set to the desired process variable. Each process variable has its own set of LRV and URV values. When you change the values of LRV and URV, you are configuring values for the currently assigned mA Output process variable.

Ensure that the measurement unit for the configured process variable has been set as desired.

#### **Procedure**

Set LRV and URV as desired.

LRVis the value of mA Output Process Variable represented by an output of 4 mA. The
default value for LRV depends on the setting of mA Output Process Variable. Enter LRV
in the measurement units that are configured for mA Output Process Variable.

URV is the value of mA Output Process Variable represented by an output of 20 mA.
 The default value for URV depends on the setting of mA Output Process Variable. Enter URV in the measurement units that are configured for mA Output Process Variable.

#### Tip

For best performance:

- Set LRV ≥ LSL (lower sensor limit).
- Set URV ≤ USL (upper sensor limit).
- Set these values so that the difference between URV and LRV is ≥ Min Span (minimum span).

Defining **URV** and **LRV** within the recommended values for **Min Span**, **LSL**, and **USL** ensures that the resolution of the mA Output signal is within the range of the bit precision of the D/A converter.

The mA Output uses a range of 4–20 mA to represent **mA Output Process Variable**. Between **LRV** and **URV**, the mA Output is linear with the process variable. If the process variable drops below **LRV** or rises above **URV**, the transmitter posts an output saturation alert.

# Default values for Lower Range Value (LRV) and Upper Range Value (URV)

Each option for **mA Output Process Variable** has its own **LRV** and **URV**. If you change the configuration of **mA Output Process Variable**, the corresponding **LRV** and **URV** are loaded and used.

Table 6-3: Default values for Lower Range Value (LRV) and Upper Range Value (URV)

Process variable	LRV	URV
All mass flow variables	-200.000 g/sec	200.000 g/sec
All liquid volume flow variables	-0.200 l/sec	0.200 l/sec
Gas standard volume flow	-423.78 SCFM	423.78 SCFM

## 6.2.3 Configure AO Cutoff

Display	Not available
ProLink III	Device Tools > Configuration > I/O > Outputs > mA Output
Field Communicator	Configure > Manual Setup > Inputs/Outputs > mA Output > mA Output Settings > PV MAO Cutoff

**AO Cutoff** (Analog Output Cutoff) specifies the lowest mass flow rate, volume flow rate, or gas standard volume flow rate that will be reported through the mA Output. Any flow rates below **AO Cutoff** will be reported as 0.

#### Restriction

**AO Cutoff** is applied only if **mA Output Process Variable** is set to Mass Flow Rate, Volume Flow Rate, or Gas Standard Volume Flow Rate. If **mA Output Process Variable** is set to a different process variable, **AO Cutoff** is not configurable, and the transmitter does not implement the AO cutoff function.

#### **Procedure**

Set **AO Cutoff** as desired.

The default value for **AO Cutoff** is 0.0 g/sec.

#### Tip

For most applications, the default value of **AO Cutoff** should be used. Contact customer service before changing **AO Cutoff**.

## Interaction between AO Cutoff and process variable cutoffs

When **mA Output Process Variable** is set to a flow variable (for example, mass flow rate or volume flow rate), **AO Cutoff** interacts with **Mass Flow Cutoff** or **Volume Flow Cutoff**. The transmitter puts the cutoff into effect at the highest flow rate at which a cutoff is applicable.

#### **Example: Cutoff interaction**

#### Configuration:

- mA Output Process Variable = Mass Flow Rate
- Frequency Output Process Variable = Mass Flow Rate
- AO Cutoff = 10 q/sec
- Mass Flow Cutoff = 15 q/sec

Result: If the mass flow rate drops below 15 g/sec, all outputs representing mass flow will report zero flow.

#### **Example: Cutoff interaction**

#### Configuration:

- mA Output Process Variable = Mass Flow Rate
- Frequency Output Process Variable = Mass Flow Rate
- AO Cutoff = 15 q/sec
- Mass Flow Cutoff = 10 g/sec

#### Result:

- If the mass flow rate drops below 15 q/sec but not below 10 q/sec:
  - The mA Output will report zero flow.
  - The Frequency Output will report the actual flow rate.
- If the mass flow rate drops below 10 q/sec, both outputs will report zero flow.

## 6.2.4 Configure Added Damping

Display	Not available
ProLink III	Device Tools > Configuration > I/O > Outputs > mA Output
Field Communicator	Configure > Manual Setup > Inputs/Outputs > mA Output > mA Output Settings > PV Added Damping

#### **Overview**

**Added Damping** controls the amount of damping that will be applied to the mA Output.

Damping is used to smooth out small, rapid fluctuations in process measurement. **Damping Value** specifies the time period (in seconds) over which the transmitter will spread changes in the process variable. At the end of the interval, the internal value will reflect 63% of the change in the actual measured value.

**Added Damping** affects the reporting of **mA Output Process Variable** through the mA Output only. It does not affect the reporting of that process variable via any other method (e.g., a Frequency Output or digital communications), or the value of the process variable used in calculations.

#### Note

**Added Damping** is not applied if the mA Output is fixed (for example, during loop testing) or if the mA Output is reporting a fault. **Added Damping** is applied while sensor simulation is active.

#### **Procedure**

Set **Added Damping** to the desired value.

The default value is 0.0 seconds. The range is 0.0 to 440 seconds.

When you specify a value for **Added Damping**, the transmitter automatically rounds the value down to the nearest valid value.

#### Note

Added Damping values are affected by the setting of Update Rate and 100 Hz Variable.

Table 6-4: Valid values for Added Damping

Setting of <b>Update Rate</b>	Process variable	Update rate in effect	Valid values for <b>Added Damping</b>
Normal	N/A	20 Hz	0.0, 0.1, 0.3, 0.75, 1.6, 3.3, 6.5, 13.5, 27.5, 55, 110, 220, 440
Special	100 Hz variable (if assigned to the mA Output)	100 Hz	0.0, 0.04, 0.12, 0.30, 0.64, 1.32, 2.6, 5.4, 11, 22, 44, 88, 176, 350

Table 6-4: Valid values for Added Damping (continued)

Setting of <b>Update Rate</b>	Process variable	Update rate in effect	Valid values for <b>Added Damping</b>
	100 Hz variable (if not assigned to the mA Output) All other process variables	6.25 Hz	0.0, 0.32, 0.96, 2.40, 5.12, 10.56, 20.8, 43.2, 88, 176, 352

# Interaction between mA Output Damping and process variable damping

When **mA** Output Source is set to a flow rate variable, **mA** Output Damping interacts with Flow Damping. If multiple damping parameters are applicable, the effect of damping the process variable is calculated first, and the mA output damping calculation is applied to the result of that calculation.

#### **Example: Damping interaction**

#### Configuration:

- Flow Damping = 1 second
- mA Output Source = Mass Flow Rate
- mA Output Damping = 2 seconds

Result: A change in the mass flow rate will be reflected in the mA Output over a time period that is greater than 3 seconds. The exact time period is calculated by the transmitter according to internal algorithms which are not configurable.

# 6.2.5 Configure mA Output Fault Action and mA Output Fault Level

Display	Not available
ProLink III	Device Tools > Configuration > Fault Processing
Field Communicator	Configure > Manual Setup > Inputs/Outputs > mA Output > MA0 Fault Settings

#### **Overview**

**mA** Output Fault Action controls the behavior of the mA Output if the transmitter encounters an internal fault condition.

#### Note

For some faults only: If **Fault Timeout** is set to a non-zero value, the transmitter will not implement the fault action until the timeout has elapsed.

#### **Procedure**

1. Set **mA Output Fault Action** to the desired value.

The default setting is Downscale.

#### Restriction

If **Digital Communications Fault Action** is set to NAN (not a number), you cannot set **mA Output Fault Action** or **Frequency Output Fault Action** to None. If you try to do this, the transmitter will not accept the configuration.

2. If you set **mA Output Fault Action** to Upscale or Downscale, set **mA Output Fault Level** as desired.

#### **Postrequisites**



If you set mA Output Fault Action or Frequency Output Fault Action to None, be sure to set Digital Communications Fault Action to None. If you do not, the output will not report actual process data, and this may result in measurement errors or unintended consequences for your process.

# Options for mA Output Fault Action and mA Output Fault Level

Option	mA Output behavior	mA Output Fault Level
Upscale	Goes to the configured fault level	Default: 22.0 mA
		Range: 21.0 to 24.0 mA
Downscale (default)	Goes to the configured fault level	Default: 2.0 mA
		Range: 1.0 to 3.6 mA
Internal Zero	Goes to the mA Output level associated with a process variable value of 0 (zero), as determined by <b>Lower Range Value</b> and <b>Upper Range Value</b> settings	Not applicable
None	Tracks data for the assigned process variable; no fault action	Not applicable

# 6.3 Configure the Frequency Output

The Frequency Output is used to report a process variable. The Frequency Output parameters control how the process variable is reported. Your transmitter may have zero or one Frequency Output: Channel B can be configured as a Frequency Output or a Discrete Output. The default assignment for Channel B is Frequency Output.

#### Restriction

The process variable assigned to the primary mA Output is automatically assigned to the Frequency Output. You cannot assign a different process variable.

#### **Important**

Whenever you change a Frequency Output parameter, verify all other Frequency Output parameters before returning the flowmeter to service. In some situations, the transmitter automatically loads a set of stored values, and these values may not be appropriate for your application.

## 6.3.1 Configure Frequency Output Polarity

Display	OFF-LINE MAINT > OFF-LINE CONFG > IO > CH B > SET FO > FO POLAR	
ProLink III	Device Tools > Configuration > I/O > Outputs > Frequency Output	
Field Communicator	Configure > Manual Setup > Inputs/Outputs > Frequency Output > FO Settings > FO Polarity	

#### **Overview**

**Frequency Output Polarity** controls how the output indicates the ON (active) state. The default value, Active High, is appropriate for most applications. Your receiving device might require an Active Low setting.

#### **Procedure**

Set Frequency Output Polarity as desired.

The default setting is Active High.

## **Options for Frequency Output Polarity**

Polarity option		Reference voltage (OFF)	Pulse voltage (ON)
Active High		0	As determined by power supply, pull-up resistor, and load. See the installation manual for your transmitter.
Active Low		As determined by power supply, pull-up resistor, and load. See the installation manual for your transmitter.	0

# 6.3.2 Configure Frequency Output Scaling Method

Display	OFF-LINE MAINT > OFF-LINE CONFG > IO > CH B > SET FO > FO SCALE	
ProLink III	Device Tools > Configuration > I/O > Outputs > Frequency Output	
Field Communicator	Configure > Manual Setup > Inputs/Outputs > Frequency Output > FO Scaling	

#### **Overview**

**Frequency Output Scaling Method** defines the relationship between output pulse and flow units. Set **Frequency Output Scaling Method** as required by your frequency receiving device.

#### **Procedure**

Set Frequency Output Scaling Method.

Option	Description
Frequency=Flow (default)	Frequency calculated from flow rate
Pulses/Unit	A user-specified number of pulses represents one flow unit
Units/Pulse	A pulse represents a user-specified number of flow units

- 2. Set additional required parameters.
  - If you set **Frequency Output Scaling Method** to Frequency=Flow, set **Rate Factor** and **Frequency Factor**.
  - If you set Frequency Output Scaling Method to Pulses/Unit, define the number of pulses that will represent one flow unit.
  - If you set **Frequency Output Scaling Method** to Units/Pulse, define the number of units that each pulse will indicate.

For all scaling methods, the transmitter puts out a fixed number of pulses per unit, and at the same time, the Frequency Output signal varies in proportion to flowrate.

## Calculate frequency from flow rate

The Frequency=Flow option is used to customize the Frequency Output for your application when you do not know appropriate values for Units/Pulse or Pulses/Unit.

If you specify Frequency=Flow, you must provide values for **Rate Factor** and **Frequency Factor**:

Rate FactorThe maximum flow rate that you want the Frequency Output to report.FrequencyA value calculated as follows:FrequencyFactor =RateFactorx NWhere:

- T Factor to convert selected time base to seconds
- **N** Number of pulses per flow unit, as configured in the receiving device

The resulting **Frequency Factor** must be within the range of the Frequency Output (0 to 10,000 Hz:

- If Frequency Factor is less than 1 Hz, reconfigure the receiving device for a higher pulses/unit setting.
- If **Frequency Factor** is greater than 10,000 Hz, reconfigure the receiving device for a lower pulses/unit setting.

# 6.3.3 Configure Frequency Output Fault Action and Frequency Output Fault Level

Display	Not available	
ProLink III	Device Tools > Configuration > Fault Processing	
Field Communicator	<ul> <li>Configure &gt; Manual Setup &gt; Inputs/Outputs &gt; Frequency Output &gt; FO Fault Parameters &gt; FO Fault Action</li> <li>Configure &gt; Manual Setup &gt; Inputs/Outputs &gt; Frequency Output &gt; FO Fault Parameters &gt; FO Fault Level</li> </ul>	

#### **Overview**

**Frequency Output Fault Action** controls the behavior of the Frequency Output if the transmitter encounters an internal fault condition.

#### Note

For some faults only: If **Fault Timeout** is set to a non-zero value, the transmitter will not implement the fault action until the timeout has elapsed.

#### **Procedure**

1. Set **Frequency Output Fault Action** as desired.

The default value is Downscale (0 Hz).

2. If you set **Frequency Output Fault Action** to Upscale, set **Frequency Fault Level** to the desired value.

The default value is 15000 Hz. The range is 10 to 15000 Hz.

## **Options for Frequency Output Fault Action**

**Table 6-5: Options for Frequency Output Fault Action** 

Label	Frequency Output behavior	
Upscale	Goes to configured Upscale value: Range: 10 Hz to 15000 Hz Default: 15000 Hz	
Downscale	0 Hz	
Internal Zero	0 Hz	
None (default)	Tracks data for the assigned process variable; no fault action	

#### **A** CAUTION!

If you set mA Output Fault Action or Frequency Output Fault Action to None, be sure to set Digital Communications Fault Action to None. If you do not, the output will not report actual process data, and this may result in measurement errors or unintended consequences for your process.

#### Restriction

If Digital Communications Fault Action is set to NAN (not a number), you cannot set mA Output Fault Action or Frequency Output Fault Action to None. If you try to do this, the transmitter will not accept the configuration.

#### 6.4 Configure the Discrete Output

The Discrete Output is used to report specific meter or process conditions. The Discrete Output parameters control which condition is reported and how it is reported. Your transmitter may have zero or one Discrete Output: Channel B can be configured as a Frequency Output or a Discrete Output.

#### Restriction

Before you can configure the Discrete Output, you must configure a channel to operate as a Discrete Output.

#### **Important**

Whenever you change a Discrete Output parameter, verify all other Discrete Output parameters before returning the meter to service. In some situations, the transmitter automatically loads a set of stored values, and these values may not be appropriate for your application.

# 6.4.1 Configure Discrete Output Source

Display	OFF-LINE MAINT > OFF-LINE CONFG > IO > CH B > SET DO > DO SRC	
ProLink III	Device Tools > Configuration > I/O > Outputs > Discrete Output	
Field Communicator	Configure > Manual Setup > Inputs/Outputs > Discrete Output > DO Assignment	

#### **Overview**

**Discrete Output Source** controls which device condition or process condition is reported via the Discrete Output.

#### **Procedure**

Set **Discrete Output Source** to the desired option.

The default setting for **Discrete Output Source** is Flow Direction.

## **Options for Discrete Output Source**

	Label				
Option	Display	ProLink III	Field Communi- cator	State	Discrete Output voltage
Discrete Event 1–5 (1)	D EV x	Enhanced Event 1	Discrete Event x	ON	Site-specific
		Enhanced Event 2 Enhanced Event 3 Enhanced Event 4 Enhanced Event 5		OFF	0 V
Event 1–2 (2)	EVNT1	Event 1	Event 1	ON	Site-specific
	EVNT2	Event 2	Event 2	OFF	0 V
	E1OR2	Event 1 or Event 2 Status	Event 1 or Event 2		
Flow Switch	FL SW	Flow Switch Indicator	Flow Switch	ON	Site-specific
				OFF	0 V
Flow Direction	FLDIR	Forward Reverse In-	Forward/Reverse	Forward flow	0 V
		dicator		Reverse flow	Site-specific
Calibration in Pro-	ZERO	Calibration in Pro-	Calibration in Pro-	ON	Site-specific
gress	gress	gress	OFF	0 V	
Fault	FAULT	Fault Indication	Fault	ON	Site-specific
				OFF	0 V

<sup>(1)</sup> Events configured using the enhanced event model.

<sup>(2)</sup> Events configured using the basic event model.

#### **Important**

If you assign Flow Switch to the Discrete Output, you should also configure Flow Switch Variable, Flow Switch Setpoint, and Hysteresis.

#### **Related information**

Configure an enhanced event Fault indication with the Discrete Output

### **Configure Flow Switch parameters**

Display	OFF-LINE MAINT > OFF-LINE CONFG > IO > CH B > SET DO > CONFIG FL SW	
ProLink III	Device Tools > Configuration > I/O > Outputs > Discrete Output	
Field Communicator	<ul> <li>Configure &gt; Manual Setup &gt; Inputs/Outputs &gt; Discrete Output &gt; Flow Switch Source</li> <li>Configure &gt; Manual Setup &gt; Inputs/Outputs &gt; Discrete Output &gt; Flow Switch Setpoint</li> <li>Configure &gt; Manual Setup &gt; Inputs/Outputs &gt; Discrete Output &gt; Hysteresis</li> </ul>	

#### Overview

Flow Switch is used to indicate that the flow rate (measured by the configured flow variable) has moved past the configured setpoint, in either direction. The flow switch is implemented with a user-configurable hysteresis.

#### **Procedure**

- 1. Set **Discrete Output Source** to Flow Switch, if you have not already done so.
- 2. Set **Flow Switch Variable** to the flow variable that you want to use to control the flow switch.
- 3. Set **Flow Switch Setpoint** to the value at which the flow switch will be triggered (after **Hysteresis** is applied).
  - If the flow rate is below this value, the Discrete Output is ON.
  - If the flow rate is above this value, the Discrete Output is OFF.
- 4. Set **Hysteresis** to the percentage of variation above and below the setpoint that will operate as a deadband.

**Hysteresis** defines a range around the setpoint within which the flow switch will not change. The default is 5%. The valid range is 0.1% to 10%.

Example: If **Flow Switch Setpoint** = 100 g/sec and **Hysteresis** = 5%, and the first measured flow rate is above 100 g/sec, the Discrete Output is OFF. It will remain OFF unless the flow rate drops below 95 g/sec. If this happens, the Discrete Output will turn ON, and remain ON until the flow rate rises above 105 g/sec. At this point it turns OFF and will remain OFF until the flow rate drops below 95 g/sec.

# 6.4.2 Configure Discrete Output Polarity

Display	OFF-LINE MAINT > OFF-LINE CONFG > IO > CH B > DO > POLAR	
ProLink III	Device Tools > Configuration > I/O > Outputs > Discrete Output	
Field Communicator	Configure > Manual Setup > Inputs/Outputs > Discrete Output > DO Polarity	

#### **Overview**

Discrete Outputs have two states: ON (active) and OFF (inactive). Two different voltage levels are used to represent these states. **Discrete Output Polarity** controls which voltage level represents which state.

#### **Procedure**

Set Discrete Output Polarity as desired.

The default setting is Active High.

## **Options for Discrete Output Polarity**

Polarity option		Description	
Active High		<ul> <li>When asserted (condition tied to DO is true), the circuit provides a pull-up to 24 V.</li> <li>When not asserted (condition tied to DO is false), the circuit provides 0 V.</li> </ul>	
Active Low		<ul> <li>When asserted (condition tied to DO is true), the circuit provides 0 V.</li> <li>When not asserted (condition tied to DO is false), the circuit provides a pull-up to 24 V.</li> </ul>	

# 6.4.3 Configure Discrete Output Fault Action

Display	Not available	
ProLink III	Device Tools > Configuration > Fault Processing	
Field Communicator	Configure > Manual Setup > Inputs/Outputs > Discrete Output > DO Fault Action	

#### **Overview**

**Discrete Output Fault Action** controls the behavior of the Discrete Output if the transmitter encounters an internal fault condition.

#### Note

For some faults only: If Fault Timeout is set to a non-zero value, the transmitter will not implement the fault action until the timeout has elapsed.

#### **A** CAUTION!

Do not use Discrete Output Fault Action as a fault indicator. If you do, you may not be able to distinguish a fault condition from a normal operating condition. If you want to use the Discrete Output as a fault indicator, set Discrete Output Source to Fault and set Discrete Output Fault Action to None.

#### **Procedure**

Set **Discrete Output Fault Action** as desired.

The default setting is None.

#### **Related information**

Fault indication with the Discrete Output

## **Options for Discrete Output Fault Action**

Label	Discrete Output behavior
Upscale	<ul> <li>Fault: Discrete Output is ON (site-specific voltage)</li> <li>No fault: Discrete Output is controlled by its assignment</li> </ul>
Downscale	<ul> <li>Fault: Discrete Output is OFF (0 V)</li> <li>No fault: Discrete Output is controlled by its assignment</li> </ul>
None (default)	Discrete Output is controlled by its assignment

## **Fault indication with the Discrete Output**

To indicate faults via the Discrete Output, set Discrete Output Source to Fault. Then, if a fault occurs, the Discrete Output is always ON and the setting of **Discrete Output Fault Action** is ignored.

#### 6.5 **Configure events**

An event occurs when the real-time value of a user-specified process variable moves past a user-defined setpoint. Events are used to provide notification of process changes or to perform specific transmitter actions if a process change occurs.

Your transmitter supports two event models:

Basic event model

Enhanced event model

# 6.5.1 Configure a basic event

Display	Not available		
ProLink III	Device Tools > Configuration > Events > Basic Events		
Field Communicator	Not available		

#### **Overview**

A basic event is used to provide notification of process changes. A basic event occurs (is ON) if the real-time value of a user-specified process variable moves above (HI) or below (LO) a user-defined setpoint. You can define up to two basic events. Event status can be queried via digital communications, and a Discrete Output can be configured to report event status.

#### **Procedure**

- 1. Select the event that you want to configure.
- 2. Specify **Event Type**.

Option	Description
Н	<ul> <li>x &gt; A</li> <li>The event occurs when the value of the assigned process variable (x) is greater than the setpoint (Setpoint A), endpoint not included.</li> </ul>
LO	<i>x</i> < A  The event occurs when the value of the assigned process variable ( <i>x</i> ) is less than the setpoint ( <b>Setpoint A</b> ), endpoint not included.

- 3. Assign a process variable to the event.
- 4. Set a value for **Setpoint A**.
- 5. (Optional) Configure a Discrete Output to switch states in response to the event status.

# 6.5.2 Configure an enhanced event

Display	Not available		
ProLink III	Device Tools > Configuration > Events > Enhanced Events		
Field Communicator	Configure > Alert Setup > Discrete Events		

#### **Overview**

An enhanced event is used to provide notification of process changes and, optionally, to perform specific transmitter actions if the event occurs. An enhanced event occurs (is ON) if the real-time value of a user-specified process variable moves above (HI) or below (LO) a user-defined setpoint, or in range (IN) or out of range (OUT) with respect to two user-defined setpoints. You can define up to five enhanced events.

#### **Procedure**

- 1. Select the event that you want to configure.
- 2. Specify **Event Type**.

Option	Description
HI	<ul> <li>x &gt; A</li> <li>The event occurs when the value of the assigned process variable (x) is greater than the setpoint (Setpoint A), endpoint not included.</li> </ul>
LO	<ul> <li>x &lt; A</li> <li>The event occurs when the value of the assigned process variable (x) is less than the setpoint (Setpoint A), endpoint not included.</li> </ul>
IN	$A \le x \le B$ The event occurs when the value of the assigned process variable $(x)$ is <i>in range</i> , that is, between <b>Setpoint A</b> and <b>Setpoint B</b> , endpoints included.
OUT	$x \le A$ or $x \ge B$ The event occurs when the value of the assigned process variable $(x)$ is out of range, that is, less than <b>Setpoint A</b> or greater than <b>Setpoint B</b> , endpoints included.

- 3. Assign a process variable to the event.
- 4. Set values for the required setpoints.
  - For HI and LO events, set **Setpoint A**.
  - For IN and OUT events, set **Setpoint A** and **Setpoint B**.
- 5. (Optional) Configure a Discrete Output to switch states in response to the event status.
- 6. (Optional) Specify the action or actions that the transmitter will perform when the event occurs.
  - With the display: OFF-LINE MAINT > OFF-LINE CONFG > IO > CH C > SET DI > DI ACT
  - With ProLink III: Device Tools > Configuration > I/O > Action Assignment
  - With the Field Communicator: **Configure** > **Alert Setup** > **Discrete Events** > **Assign Discrete Action**

## **Options for Enhanced Event Action**

	Label				
Action	Display ProLink III		Field Communicator		
Standard					
None (default)	NONE	None	None		
Start sensor zero	START ZERO	Start Sensor Zero	Perform auto zero		
Start/stop all totalizers	START STOP	Start/Stop All Totalization	ation Start/stop totals		
Reset mass total	RESET MASS	Reset Mass Total	Reset mass total		
Reset volume total	RESET VOL	Reset Volume Total	Reset volume total		
Reset gas standard volume total	RESET GSVT	Reset Gas Std Volume Total	Total Reset gas standard volume total		
Reset all totals	RESET ALL	Reset All Totals	Reset totals		
Meter verification					
Start meter verification test	START VERFY	Start Meter Verification	Not available		

#### Note

Before assigning actions to an enhanced event, check the status of the event. If it is ON, all assigned actions will be performed when the new configuration is implemented. If this is not accepatable, wait until an appropriate time to assign actions to the event.

# 6.6 Configure digital communications

The digital communications parameters control how the transmitter will communicate using digital communications.

Your transmitter supports the following types of digital communications:

- HART/Bell 202 over the primary mA terminals
- HART/RS-485 over the RS-485 terminals
- Modbus/RS-485 over the RS-485 terminals
- Modbus RTU via the service port

#### Note

The service port responds automatically to a wide range of connection requests. It is not configurable.

## 6.6.1 Configure HART/Bell 202 communications

HART/Bell 202 communications parameters support HART communications with the transmitter's primary mA terminals over a HART/Bell 202 network.

## **Configure basic HART parameters**

Display	OFF-LINE MAINT > OFF-LINE CONFG > COMM
ProLink III	Device Tools > Configuration > Communications > Communications (HART)
Field Communicator	Configure > Manual Setup > Inputs/Outputs > Communications > HART Communica-
	tions

#### **Overview**

Basic HART parameters include the HART address, HART tags, and the operation of the primary mA Output.

HART/Bell 202 communications parameters support HART communication with the transmitter's primary mA terminals over a HART/Bell 202 network. The HART/Bell 202 communications parameters include:

- HART Address (Polling Address)
- mA Output Action
- Burst Parameters (optional)
- HART Variables (optional)

#### **Procedure**

1. Set **HART Address** to a value that is unique on your network.

Default: 0Range: 0 to 15

#### **Tips**

- The default address is typically used unless you are in a multidrop environment.
- Devices using HART protocol to communicate with the transmitter may use either HART Address or HART Tag (Software Tag) to identify the transmitter. Configure either or both, as required by your other HART devices.
- 2. Ensure that **mA Output Action** is configured appropriately.

Option	Description
Enabled (Live)	The primary mA Output reports process data as configured.
Disabled (Fixed)	The primary mA Output is fixed at 4 mA and does not report process data.

#### **Important**

If you use ProLink III to set **HART Address** to 0, the program automatically enables **mA Output Action**. If you use ProLink III to set **HART Address** to any other value, the program automatically disables **mA Output Action**. This is designed to make it easier to configure the transmitter for legacy behavior. Always verify **mA Output Action** after setting **HART Address**.

## **Configure burst parameters**

Display	Not available
ProLink III	Device Tools > Configuration > Communications > Communications (HART)
Field Communicator	Configure > Manual Setup > Inputs/Outputs > Communications > Set Up Burst Mode

#### **Overview**

Burst mode is a mode of communication during which the transmitter regularly broadcasts HART digital information over the mA Output. The burst parameters control the information that is broadcast when burst mode is enabled.

#### Tip

In typical installations, burst mode is disabled. Enable burst mode only if you are using a HART Triloop.

#### **Procedure**

- 1. Enable **Burst Mode**.
- 2. Set **Burst Mode Output** as desired.

Label			
ProLink III Field Communicator		Description	
Source (Primary Variable)	PV	The transmitter sends the primary variable (PV) in the configured measurement units in each burst (e.g., 14.0 g/sec, 13.5 g/sec, 12.0 g/sec.	
Primary Variable (Percent Range/Current)	% range/current	The transmitter sends the PV's percent of range and the PV's actual mA level in each burst (e.g., 25%, 11.0 mA.	
Process Variables/Current	Process variables/current	The transmitter sends PV, SV, TV, and QV values in measurement units and the PV's actual milliamp reading in each burst (e.g., 50 g/sec, 23 °C, 50 g/sec, 0.0023 g/cm3, 11.8 mA.	
Transmitter variables	Fld dev var	The transmitter sends four user-specified process variables in each burst.	

3. Ensure that the burst output variables are set appropriately.

- If you set **Burst Mode Output** to send four user-specified variables, set the four process variables to be sent in each burst.
- If you set **Burst Mode Output** to any other option, ensure that the HART variables are set as desired.

## Configure HART variables (PV, SV, TV, QV)

Display	Not available
ProLink III	Device Tools > Configuration > Communications > Communications (HART)
Field Communicator	Configure > Manual Setup > Inputs/Outputs > Variable Mapping

#### Overview

The HART variables are a set of four variables predefined for HART use. The HART variables include the Primary Variable (PV), Secondary Variable (SV), Tertiary Variable (TV), and Quaternary Variable (QV). You can assign specific process variables to the HART variables, and then use standard HART methods to read or broadcast the assigned process data.

#### Restriction

The TV is automatically set to match the PV and cannot be configured independently.

#### Tip

The Tertiary Variable and Quaternary Variable are also called the Third Variable (TV) and Fourth Variable (FV).

## **Options for HART variables**

Table 6-6: Standard HART process variables

Process variable	Primary Varia- ble (PV)	Secondary Variable (SV)	Third Variable (TV)	Fourth Varia- ble (QV )
Gas Standard Volume Flow Rate	✓	✓	✓	✓
Gas Standard Volume Inventory				✓
Gas Standard Volume Total				✓
Line (Gross) Volume Flow Rate	✓	✓	✓	✓
Line (Gross) Volume Inventory				✓
Line (Gross) Volume Total				✓
Mass Flow Rate	✓	✓	✓	✓
Mass Inventory				✓
Mass Total				✓

Table 6-7: PVR-only HART process variables

Process variable	Primary Varia- ble (PV)	Secondary Variable (SV)	Third Variable (TV)	Fourth Varia- ble (QV )
Corrected Oil Flow	✓	✓		✓
Corrected Oil Total				✓
Corrected Water Cut				✓
Corrected Water Flow	✓	✓		✓
Corrected Water Total				✓
Density of Oil @ Line Fixd degAPI				✓
Density of Oil @ Line Fixd SGU				✓
Oil Total @ Line				✓
Shrinkage Factor Corrected Oil Flow @ 60F	✓	✓		✓
Shrinkage Factor Corrected Oil Flow @ Line	✓	✓		✓
Shrinkage Factor Corrected Oil Total @ 60F				✓
Shrinkage Factor Corrected Oil Total @ Line				✓
Shrinkage Factor Corrected Total of Mix @ 60F				✓
Shrinkage Factor Corrected Volume Of Mix @ 60F	✓	✓		✓
Uncorrected Oil Flow	✓	✓		✓
Uncorrected Water Cut				✓
Uncorrected Water Flow	✓	✓		1
Volume Flow of Mix at Line	1	<b>√</b>		✓
Volume Total Of Mix @ Line				✓
Water Total @ Line				✓

### Table 6-8: TMR-only HART process variables

Process variable	Primary Varia- ble (PV)	Secondary Variable (SV)	Third Variable (TV)	Fourth Varia- ble (QV )
Remediated Mass Flow	✓	✓		✓
Remediated Mass Total				✓
Remediated Mass Inventory				✓

### Table 6-9: PVR- and TBR-only HART process variables

Process variable	Primary Varia- ble (PV)	Secondary Variable (SV)	Third Variable (TV)	Fourth Varia- ble (QV )
Unremediated Density				✓

Table 6-10: PVR, TBR, and TMR HART process variables

Process variable	Primary Varia- ble (PV)	Secondary Variable (SV)	Third Variable (TV)	Fourth Varia- ble (QV )
Total Remediated Time				✓

## Interaction of HART variables and transmitter outputs

The HART variables are automatically reported through specific transmitter outputs. They may also be reported through HART burst mode, if enabled on your transmitter.

Table 6-11: HART variables and transmitter outputs

HART variable	Reported via	Comments
Primary Variable (PV)	Primary mA output	If one assignment is changed, the other is changed automatically, and vice versa.
Secondary Variable (SV)	Not associated with an output	The SV must be configured directly, and the value of the SV is available only via digital communications.
Tertiary Variable (TV)	Frequency Output (if present on your transmitter)	If one assignment is changed, the other is changed automatically, and vice versa. If your transmitter does not have a Frequency Output, the TV must be configured directly, and the value of the TV is available only via digital communications.
Quaternary Variable (QV)	Not associated with an output	The QV must be configured directly, and the value of the QV is available only via digital communications.

# 6.6.2 Configure HART/RS-485 communications

Display	OFF-LINE MAINT > OFF-LINE CONFG > COMM
ProLink III	Device Tools > Configuration > Communications > Communications (HART)
Field Communicator	Configure > Manual Setup > Inputs/Outputs > Communications > HART Communica-
	tions

#### **Overview**

HART/RS-485 communications parameters support HART communication with the transmitter's RS-485 terminals.

HART/RS-485 communication parameters include:

- Protocol
- HART Address (Polling Address)
- Parity, Stop Bits, and Baud Rate

#### Restriction

The transmitter uses the same RS-485 terminals for HART/RS-485, Modbus RTU, and Modbus ASCII communications. All RS-485 connection requests must use the same protocol and connection parameters that are configured in the transmitter.

#### **Procedure**

- 1. Set **Protocol** to HART RS-485.
- 2. Set **Baud Rate** to match the baud rate that will be used by your HART master.
- 3. Set **Parity** to match the parity that will be used by your HART master.
- 4. Set **Stop Bits** to match the stop bits setting that will be used by your HART master.
- 5. Set **HART Address** to a unique value on your network.

Valid address values are between 0 and 15. The default address (0) is typically used unless you are in a multidrop environment.

#### Tip

Devices using HART protocol to communicate with the transmitter may use either **HART Address** or **HART Tag** (**Software Tag**) to identify the transmitter. Configure either or both, as required by your other HART devices.

## 6.6.3 Configure Modbus/RS-485 communications

Display	OFF-LINE MAINT > OFF-LINE CONFG > COMM
ProLink III	Device Tools > Configuration > Communications > RS-485 Terminals
Field Communicator	Configure > Manual Setup > Inputs/Outputs > Communications > Set Up RS-485 Port

#### **Overview**

Modbus/RS-485 communications parameters control Modbus communication with the transmitter's RS-485 terminals.

#### **Procedure**

Set Disable Modbus ASCII as desired.

Support for Modbus ASCII limits the set of addresses that are available for the transmitter's Modbus address.

Modbus ASCII support	Available Modbus addresses
Disabled	1–127, excluding 111 (111 is reserved to the service port)
Enabled	1–15, 32–47, 64–79, and 96–110

2. Set **Protocol** to match the protocol used by your Modbus/RS-485 host.

Option	Description
Modbus RTU (default)	8-bit communications
Modbus ASCII	7-bit communications

If support for Modbus ASCII is disabled, you must use Modbus RTU.

- 3. Set **Modbus Address** to a unique value on the network.
- 4. Set **Parity**, **Stop Bits**, and **Baud Rate** as appropriate for your network.
- 5. Set **Floating-Point Byte Order** to match the byte order used by your Modbus host.

Code	Byte order
0	1–2 3–4
1	3-4 1-2
2	2–1 4–3
3	4–3 2–1

See the following table for the bit structure of bytes 1 through 7.

Table 6-12: Bit structure of floating-point bytes

Byte	Bits	Definition
1	SEEEEEE	S=Sign
		E=Exponent
2	ЕММММММ	E=Exponent
		M=Mantissa
3	МММММММ	M=Mantissa
4	MMMMMMM	M=Mantissa

6. (Optional) Set **Additional Communications Response Delay** in *delay units*.

A delay unit is 2/3 of the time required to transmit one character, as calculated for the port currently in use and the character transmission parameters. Valid values range from 1 to 255.

**Additional Communications Response Delay** is used to synchronize Modbus communications with hosts that operate at a slower speed than the transmitter. The value specified here will be added to each response the transmitter sends to the host.

#### Tip

Do not set Additional Communications Response Delay unless required by your Modbus host.

# 6.6.4 Configure Digital Communications Fault Action

Display	Not available
ProLink III	Device Tools > Configuration > Fault Processing
Field Communicator	Configure > Alert Setup > I/O Fault Actions > Comm Fault Action

#### **Overview**

**Digital Communications Fault Action**specifies the values that will be reported via digital communications if the device encounters an internal fault condition.

#### **Procedure**

Set **Digital Communications Fault Action** as desired.

The default setting is None.

#### Restrictions

- If mA Output Fault Action or Frequency Output Fault Action is set to None, Digital
   Communications Fault Action should also be set to None. If you do not, the output will not report
   actual process data, and this may result in measurement errors or unintended consequences for
   your process.
- If you set Digital Communications Fault Action to NAN, you cannot set mA Output Fault Action or Frequency Output Fault Action to None. If you try to do this, the transmitter will not accept the configuration.

## **Options for Digital Communications Fault Action**

Label		
ProLink III	Field Communicator	Description
Upscale	Upscale	<ul> <li>Process variable values indicate that the value is greater than the upper sensor limit.</li> <li>Totalizers stop incrementing.</li> </ul>
Downscale	Downscale	<ul> <li>Process variable values indicate that the value is lower than the lower sensor limit.</li> <li>Totalizers stop incrementing.</li> </ul>
Zero	IntZero-All 0	<ul> <li>Flow rate variables go to the value that represents a flow rate of 0 (zero).</li> <li>Density is reported as 0.</li> <li>Temperature is reported as 0 °C, or the equivalent if other units are used (e.g., 32 °F.</li> <li>Drive gain is reported as measured.</li> <li>Totalizers stop incrementing.</li> </ul>

Label		
ProLink III	Field Communicator	Description
Not a Number	Not-a-Number	<ul> <li>Process variables are reported as IEEE NAN.</li> <li>Drive gain is reported as measured.</li> <li>Modbus scaled integers are reported as Max Int.</li> <li>Totalizers stop incrementing.</li> </ul>
Flow to Zero	IntZero-Flow 0	<ul> <li>Flow rates are reported as 0.</li> <li>Other process variables are reported as measured.</li> <li>Totalizers stop incrementing.</li> </ul>
None	None (default)	<ul> <li>All process variables are reported as measured.</li> <li>Totalizers increment if they are running.</li> </ul>

#### **A** CAUTION!

If you set mA Output Fault Action or Frequency Output Fault Action to None, be sure to set Digital Communications Fault Action to None. If you do not, the output will not report actual process data, and this may result in measurement errors or unintended consequences for your process.

#### Restriction

If Digital Communications Fault Action is set to NAN (not a number), you cannot set mA Output Fault Action or Frequency Output Fault Action to None. If you try to do this, the transmitter will not accept the configuration.

## 7 Complete the configuration

#### Topics covered in this chapter:

- Test or tune the system using sensor simulation
- Back up transmitter configuration
- Enable write-protection on the transmitter configuration

# 7.1 Test or tune the system using sensor simulation

Use sensor simulation to test the system's response to a variety of process conditions, including boundary conditions, problem conditions, or alert conditions, or to tune the loop.

#### Restriction

Sensor simulation is available only on flowmeters with the enhanced core processor.

#### **Prerequisites**

Before enabling sensor simulation, ensure that your process can tolerate the effects of the simulated process values.

#### **Procedure**

1. Navigate to the sensor simulation menu.

Communications tool	Menu path
Display	Not available
ProLink III	Device Tools > Diagnostics > Testing > Sensor Simulation
Field Communicator	Service Tools > Simulate > Simulate Sensor

- 2. Enable sensor simulation.
- 3. For mass flow, set **Wave Form** as desired and enter the required values.

Option	Required values
Fixed	Fixed Value
Sawtooth	Period
	Minimum
	Maximum

Option	Required values
Sine	Period
	Minimum
	Maximum

4. For density, set **Wave Form** as desired and enter the required values.

Option	Required values
Fixed	Fixed Value
Sawtooth	Period Minimum Maximum
Sine	Period Minimum Maximum

5. For temperature, set **Wave Form** as desired and enter the required values.

Option	Required values
Fixed	Fixed Value
Sawtooth	Period Minimum Maximum
Sine	Period Minimum Maximum

- 6. Observe the system response to the simulated values and make any appropriate changes to the transmitter configuration or to the system.
- 7. Modify the simulated values and repeat.
- 8. When you have finished testing or tuning, disable sensor simulation.

## 7.1.1 Sensor simulation

Sensor simulation allows you to test the system or tune the loop without having to create the test conditions in your process. When sensor simulation is enabled, the transmitter reports the simulated values for mass flow, density, and temperature, and takes all appropriate actions. For example, the transmitter might apply a cutoff, activate an event, or post an alert.

When sensor simulation is enabled, the simulated values are stored in the same memory locations used for process data from the sensor. The simulated values are then used throughout transmitter functioning. For example, sensor simulation will affect:

- All mass flow rate, temperature, and density values displayed or reported via outputs or digital communications
- The mass total and mass inventory values
- All volume calculations and data, including reported values, volume totals, and volume inventories
- All mass, temperature, density, or volume values logged to Data Logger

Sensor simulation does not affect any diagnostic values.

Unlike actual mass flow rate and density values, the simulated values are not temperature-compensated (adjusted for the effect of temperature on the sensor's flow tubes).

## 7.2 Back up transmitter configuration

ProLink III provides a configuration upload/download function which allows you to save configuration sets to your PC. This allows you to back up and restore your transmitter configuration. This is also a convenient way to replicate a configuration across multiple devices.

#### Restriction

This function is not available with any other communications tools.

#### **Procedure**

To back up the transmitter configuration using ProLink III:

- 1. Choose Device Tools > Configuration Transfer > Save or Load Configuration Data.
- 2. In the Configuration groupbox, select the configuration data you want to save.
- 3. Click **Save**, then specify a file name and location on your computer.
- 4. Click Start Save.

The backup file is saved to the specified name and location. It is saved as a text file and can be read using any text editor.

# 7.3 Enable write-protection on the transmitter configuration

Display	OFF-LINE MAINT > CONFIG > LOCK
ProLink III	Device Tools > Configuration > Write-Protection
Field Communicator	Configure > Manual Setup > Info Parameters > Transmitter Info > Write Protect

#### **Overview**

If the transmitter is write-protected, the configuration is locked and nobody can change it until it is unlocked. This prevents accidental or unauthorized changes to the transmitter configuration parameters.

# Part III Operations, maintenance, and troubleshooting

#### Chapters covered in this part:

- Transmitter operation
- Measurement support
- Troubleshooting

## 8 Transmitter operation

#### Topics covered in this chapter:

- Record the process variables
- View process variables
- View transmitter status using the status LED
- View and acknowledge status alerts
- Read totalizer and inventory values
- Start and stop totalizers and inventories
- Reset totalizers
- Reset inventories

## 8.1 Record the process variables

Micro Motion suggests that you make a record of specific process variable measurements, including the acceptable range of measurements, under normal operating conditions. This data will help you recognize when the process or diagnostic variables are unusually high or low, and may help you diagnose and troubleshoot application issues.

#### **Procedure**

Record the following process and diagnostic variables, under normal operating conditions.

	Measurement		
Variable	Typical average	Typical high	Typical low
Flow rate			
Density			
Temperature			
Tube frequency			
Pickoff voltage			
Drive gain			

## 8.2 View process variables

Display	Scroll to the desired process variable. If <b>AutoScroll</b> is enabled, you can wait until the process variable is displayed. See <i>Section 8.2.1</i> for more information.
ProLink III	View the desired variable on the main screen under <b>Process Variables</b> . See <i>Section 8.2.2</i> for more information.
Field Communicator	Overview > Shortcuts > Variables > Process Variables

#### **Overview**

Process variables provide information about the state of the process fluid, such as flow rate, density, and temperature, as well as running totals. Process variables can also provide data about flowmeter operation, such as drive gain and pickoff voltage. This information can be used to understand and troubleshoot your process.

## 8.2.1 View process variables using the display

View the desired process variables.

The display shows the configured display variables. For each display variable, the display reports the abbreviated name of the process variable (for example, DENS for density), the current value of that process variable, and the associated unit of measure (for example, G/CM3).

If **Auto Scroll** is enabled, the display cycles through the display variables, showing each display variable for a user-specified number of seconds. Whether or not **Auto Scroll** is enabled, you can activate **Select** to move to the next display variable.




Figure 8-1: Transmitter display features

- A. Status LED
- B. Display (LCD panel)
- C. Process variable
- D. Scroll optical switch
- E. Optical switch indicator: turns red when either **Scroll** or **Select** is activated
- F. **Select** optical switch
- G. Unit of measure for process variable
- H. Current value of process variable

## 8.2.2 View process variables and other data using ProLink III

Monitor process variables, diagnostic variables, and other data to maintain process quality.

ProLink III automatically displays process variables, diagnostic variables, and other data on the main screen.

#### Tip

ProLink III allows you to choose the process variables that appear on the main screen. You can also choose whether to view data in Analog Gauge view or digital view, and you can customize the gauge settings. For more information, see the ProLink III user manual.

## 8.2.3 View process variables using the Field Communicator

Monitor process variables to maintain process quality.

To view current values of basic process variables, choose Overview.

 To view a more complete set of process variables, plus the current state of the outputs, choose Service Tools > Variables.

## 8.3 View transmitter status using the status LED

The status LED shows the current alert condition of the transmitter. The status LED is located on the face of the transmitter.

Observe the status LED.

- If your transmitter has a display, you can view the status LED with the transmitter housing cover in place.
- If your transmitter does not have a display, it does not have a status LED. This option is not available.

To interpret the status LED, see the following table.

#### Restriction

If **LED Blinking** is disabled, the status LED will flash only during calibration. It will not flash to indicate an unacknowledged alarm.

Table 8-1: Transmitter status reported by status LED

LED state	Description	Recommendation
Solid green	No alerts are active.	Continue with configuration or process measurement.
Flashing green (if enabled)	Unacknowledged corrected condition (no alert)	Continue with configuration or process measurement. Acknowledge the alert if you choose.
Solid yellow	One or more low-severity alerts are active.	A low-severity alert condition does not affect measurement accuracy or output behavior. You can continue with configuration or process measurement, but Micro Motion still recommends identifying and resolving the alert condition.
Flashing yellow (if enabled)	Calibration in progress, or Known Density Verification in progress.  One or more low-severity alerts are active and have not been acknowledged.	A low-severity alert condition does not affect measurement accuracy or output behavior. You can continue with configuration or process measurement, but Micro Motion still recommends identifying and resolving the alert condition.
Solid red	One or more high-severity alerts are active.	A high-severity alert condition affects measurement accuracy and output behavior. Resolve the alert condition before continuing.

**Table 8-1: Transmitter status reported by status LED (continued)** 

LED state	Description	Recommendation
Flashing red (if enabled)	One or more high-severity alerts are active and have not been acknowledged.	A high-severity alert condition affects measurement accuracy and output behavior. Resolve the alert condition before continuing. Acknowledge the alert if you choose.

## 8.4 View and acknowledge status alerts

The transmitter posts status alerts whenever a process variable exceeds its defined limits or the transmitter detects a fault condition. You can view active alerts, and you can acknowledge alerts. Acknowledging alerts is not required.

## 8.4.1 View and acknowledge alerts using the display

You can view a list containing all alerts that are active, or inactive but unacknowledged. From this list, you can acknowledge individual alerts.

#### Note

Only Fault and Informational alerts are listed. The transmitter automatically filters out alerts with **Status Alert Severity** set to Ignore.

#### **Prerequisites**

Operator access to the alert menu must be enabled (default setting). If operator access to the alert menu is disabled, you must use another method to view or acknowledge status alerts.

#### **Procedure**

See Figure 8-2.




Figure 8-2: Using the display to view and acknowledge the status alerts

#### **Postrequisites**

- To clear the following alerts, you must correct the problem, acknowledge the alert, then power-cycle the transmitter: A001, A002, A010, A011, A012, A013, A018, A019, A022, A023, A024, A025, A028, A029, A031.
- For all other alerts:
  - If the alert is inactive when it is acknowledged, it will be removed from the list.
  - If the alert is active when it is acknowledged, it will be removed from the list when the alert condition clears.

## 8.4.2 View and acknowledge alerts using ProLink III

You can view a list containing all alerts that are active, or inactive but unacknowledged. From this list, you can acknowledge individual alerts or choose to acknowledge all alerts at once.

1. View alerts on the ProLink III main screen under **Alerts**.

All active or unacknowledged alerts are listed, and displayed according to the following categories:

Category	Description	
Failed: Fix Now	A meter failure has occurred and must be addressed immediately.	
Maintenance: Fix Soon	A condition has occurred that can be fixed at a later time.	
Advisory: Informational	A condition has occurred, but requires no maintenance from you.	

#### Notes

- All fault alerts are displayed in the **Failed: Fix Now** category.
- All information alerts are displayed in either the Maintenance: Fix Soon category or the Advisory: Informational category. The category assignment is hard-coded.
- The transmitter automatically filters out alerts with Alert Severity set to Ignore.
- 2. To acknowledge a single alert, check the **Ack** checkbox for that alert. To acknowledge all alerts at once, click **Ack All**.

#### **Postrequisites**

- To clear the following alerts, you must correct the problem, acknowledge the alert, then power-cycle the transmitter: A001, A002, A010, A011, A012, A013, A018, A019, A022, A023, A024, A025, A028, A029, A031.
- For all other alerts:
  - If the alert is inactive when it is acknowledged, it will be removed from the list.
  - If the alert is active when it is acknowledged, it will be removed from the list when the alert condition clears.

## 8.4.3 View alerts using the Field Communicator

You can view a list containing all alerts that are active, or inactive but unacknowledged.

To view active or unacknowledged alerts, choose Service Tools > Alerts.

All active alerts and unacknowledged alerts are listed.

#### Note

Only Fault and Informational alerts are listed. The transmitter automatically filters out alerts with **Status Alert Severity** set to Ignore.

To refresh the list, choose Service Tools > Alerts > Refresh Alerts.

## 8.5 Read totalizer and inventory values

Display	To read a totalizer or inventory value from the display, it must be configured as a display variable.
ProLink III	View the desired variable on the main screen under <b>Process Variables</b> .
Field Communicator	Service Tools > Variables > Totalizer Control

#### **Overview**

Totalizers keep track of the total amount of mass or volume measured by the transmitter since the last totalizer reset. Inventories keep track of the total amount of mass or volume measured by the transmitter since the last inventory reset.

#### Tip

You can use the inventories to keep a running total of mass or volume across multiple totalizer resets.

## 8.6 Start and stop totalizers and inventories

Display	See Section 8.6.1.	
ProLink III	Device Tools > Totalizer Control > Totalizer and Inventories > Start All Totals	
	Device Tools > Totalizer Control > Totalizer and Inventories > Stop All Totals	
Field Communicator	Service Tools > Variables > Totalizer Control > All Totalizers > Start Totalizers	
	Service Tools > Variables > Totalizer Control > All Totalizers > Stop Totalizers	

#### **Overview**

When you start a totalizer, it tracks process measurement. In a typical application, its value increases with flow. When you stop a totalizer, it stops tracking process measurement and its value does not change with flow. Inventories are started and stopped automatically, when totalizers are started and stopped.

#### **Important**

Totalizers and inventories are started or stopped as a group. When you start any totalizer, all other totalizers and all inventories are started simultaneously. When you stop any totalizer, all other totalizers and all inventories are stopped simultaneously. You cannot start or stop inventories directly.

# 8.6.1 Start and stop totalizers and inventories using the display

#### **Prerequisites**

The Totalizer Start/Stop display function must be enabled.

At least one totalizer must be configured as a display variable.

#### **Procedure**

- To start all totalizers and inventories using the display:
  - 1. **Scroll** until the word TOTAL appears in the lower left corner of the display.

#### **Important**

Because all totalizers are started or stopped together, it does not matter which total you use.

- 2. Select.
- 3. Scroll until START appears beneath the current totalizer value.

Exit displays beneath the current totalizer value.

- 4. Select.
- 5. **Select** again to confirm.
- 6. Scroll to EXIT.
- To stop all totalizers and inventories using the display:
  - 1. **Scroll** until the word TOTAL appears in the lower left corner of the display.

#### **Important**

Because all totalizers are started or stopped together, it does not matter which total you use.

2. Select.

- 3. **Scroll** until STOP appears beneath the current totalizer value.
- 4. Select.
- 5. **Select** again to confirm.
- 6. Scroll to EXIT.

## 8.7 Reset totalizers

Display	See Section 8.7.1.	
ProLink III	Device Tools > Totalizer Control > Totalizer and Inventories > Reset Mass Total	
	Device Tools > Totalizer Control > Totalizer and Inventories > Reset Volume Total	
	Device Tools > Totalizer Control > Totalizer and Inventories > Reset Gas Total	
	Device Tools > Totalizer Control > Totalizer and Inventories > Reset All Totals	
Field Communicator	Service Tools > Variables > Totalizer Control > Mass > Mass Total	
	Service Tools > Variables > Totalizer Control > Gas Standard Volume > Volume Total	
	Service Tools > Variables > Totalizer Control > Gas Standard Volume > GSV Total	
	Service Tools > Variables > Totalizer Control > All Totalizers > Reset All Totals	

#### **Overview**

When you reset a totalizer, the transmitter sets its value to 0. It does not matter whether the totalizer is started or stopped. If the totalizer is started, it continues to track process measurement.

#### Tip

When you reset a single totalizer, the values of other totalizers are not reset. Inventory values are not reset.

## 8.7.1 Reset totalizers using the display

#### **Prerequisites**

The Totalizer Reset display function must be enabled.

The totalizer that you want to reset must be configured as a display variable. For example:

- If you want to reset the mass totalizer, **Mass Total** must be configured as a display variable.
- If you want to reset the volume totalizer, Volume Total must be configured as a display variable.

#### **Procedure**

- To reset the mass totalizer:
  - 1. **Scroll** until the mass totalizer value appears.

#### 2. Select.

Exit displays beneath the current totalizer value.

- 3. Scroll until Reset displays beneath the current totalizer value.
- 4. Select.

Reset and Yes? alternately flash beneath the current totalizer value.

- 5. **Select** again to confirm.
- 6. **Scroll** to EXIT.
- 7. Select.
- To reset the volume totalizer:
  - 1. **Scroll** until the volume totalizer value appears.
  - 2. Select.

Exit displays beneath the current totalizer value.

- 3. Scroll until Reset displays beneath the current totalizer value.
- 4. Select.

Reset and Yes? alternately flash beneath the current totalizer value.

- 5. **Select** again to confirm.
- 6. Scroll to EXIT.
- 7. Select.
- To reset the gas standard volume totalizer:
  - 1. **Scroll** until the gas standard volume totalizer value appears.
  - 2. Select.

Exit displays beneath the current totalizer value.

- 3. Scroll until Reset displays beneath the current totalizer value.
- 4. Select.

Reset and Yes? alternately flash beneath the current totalizer value.

- 5. **Select** again to confirm.
- 6. Scroll to EXIT.
- 7. Select.

## 8.8 Reset inventories

ProLink III	Device Tools > Totalizer Control > Totalizer and Inventories > Reset Mass Inventory
	Device Tools > Totalizer Control > Totalizer and Inventories > Reset Volume Inventory
	Device Tools > Totalizer Control > Totalizer and Inventories > Reset Gas Inventory
	Device Tools > Totalizer Control > Totalizer and Inventories > Reset All Inventories

#### **Overview**

When you reset an inventory, the transmitter sets its value to 0. It does not matter whether the inventory is started or stopped. If the inventory is started, it continues to track process measurement.

#### Tip

When you reset a single inventory, the values of other inventories are not reset. Totalizer values are not reset.

#### **Prerequisites**

To use ProLink III to reset the inventories, the feature must be enabled.

- To enable inventory reset in ProLink III:
  - 1. Choose **Tools > Options**.
  - 2. Select Reset Inventories from ProLink III.
  - 3. Select OK.

Once enabled, this feature remains enabled until it is disabled.

## 9 Measurement support

#### Topics covered in this chapter:

- Options for measurement support
- Use Smart Meter Verification (SMV)
- Use PVR, TBR, and TMR
- Piecewise linearization (PWL) for calibrating gas meters
- Zero the meter
- Validate the meter
- Perform a (standard) D1 and D2 density calibration
- Perform a D3 and D4 density calibration (T-Series sensors only)
- Perform temperature calibration

## 9.1 Options for measurement support

Micro Motion provides several measurement support procedures to help you evaluate and maintain your flowmeter's accuracy.

The following methods are available:

- Smart Meter Verification (SMV) evaluates the structural integrity of the sensor tubes by comparing current tube stiffness to the stiffness measured at the factory.
   Stiffness is defined as the load per unit deflection, or force divided by displacement.
   Because a change in structural integrity changes the sensor's response to mass and density, this value can be used as an indicator of measurement performance.
- Meter validation compares flowmeter measurements reported by the transmitter to an external measurement standard. Meter validation requires one data point.
- Calibration establishes the relationship between a process variable and the signal produced at the sensor. You can calibrate the flowmeter for zero, density, and temperature. Density and temperature calibration require two data points (low and high) and an external measurement for each.

#### Tips

- Perform SMV at regular intervals to get the best data on your meter's performance.
- To prove the meter against a regulatory standard, or to correct measurement error, use meter validation and meter factors.
- Before performing a field calibration, contact customer support to see if there is an alternative. In many cases, field calibrations have a negative effect on measurement accuracy.

## 9.2 Use Smart Meter Verification (SMV)

You can run an SMV test, view and interpret the results, and set up automatic execution.

## 9.2.1 SMV requirements

To use SMV, the transmitter must be paired with an enhanced core processor.

See *Table 9-1* for the minimum version of the transmitter, enhanced core processor, and communication tool needed to support SMV. (If you are going to perform SMV using the display, only the transmitter and enhanced core processor versions apply.)

Table 9-1: Minimum SMV version

Item	Minimum version (legacy)	Minimum basic SMV trans- mitter
Transmitter	6.0	8.0
Enhanced core processor	3.6	4.4
ProLink III	1.0	4.0
Field Communicator	HART device description: device rev 6, DD rev 2	HART device description: device rev 8, DD rev 1

If your devices or tools do not meet the minimum version requirements for SMV, you still may have access to an older version of meter verification if the option was ordered for your transmitter. See *Table 9-2* for a description of the major differences between the older meter verification and the newer SMV.

Table 9-2: Major differences between meter verification and SMV

Feature	Meter verification (older)	SMV (newer)
Measurement inter- ruption	Suspended during the test (3 minutes)	No interruption necessary
Result storage	No results stored in the transmitter	Last 20 results stored in the transmitter (licensed SMV)
Results reporting	Pass/fail/abort	Pass/fail/abort comparison tables and graphs for stored test results <sup>(1)</sup>
Test start methods	Manual only	Manual, scheduled, event-based

<sup>(1)</sup> Detailed test analyses such as comparison graphs are not available on the local display.

## 9.2.2 SMV test preparation

Although it is not necessary to match factory conditions or change the transmitter's configuration during an SMV test, the test will run more smoothly when conditions are stable.

SMV has an output mode called Continuous Measurement that allows the transmitter to keep measuring while the test is in progress. If you choose to run the test in Last Measured Value or Fault modes instead, the transmitter outputs will be held constant for the two minute duration of the test. If control loops depend on transmitter outputs, take appropriate action.

Avoid process instability during the test. If conditions are too unstable, the SMV test will abort. To maximize process stability:

- Maintain a constant fluid pressure and temperature.
- Avoid changes to fluid composition, e.g., two-phase flow or settling.
- Maintain a constant flow rate.

#### **Tips**


- The SMV test runs best when flow is stopped through the sensor.
- SMV is not affected by any configured transmitter parameters for flow, density, or temperature.

#### 9.2.3 Run SMV

## Run an SMV test using the display

1. Navigate to the Smart Meter Verification menu.

Figure 9-1: SMV - Top-level menu



- 2. Choose **Run Verify**.
- 3. Choose **Outputs** and select the desired output behavior.

Option	Description
Continue Measr	During the test, all outputs will continue to report their assigned process variable. The test will run for approximately 90 seconds.
Fault	During the test, all outputs will go to their configured fault action. The test will run for approximately 140 seconds.

Option	Description	
Last Value	During the test, all outputs will report the last measured value of their assigned process variable. The test will run for approximately 140 seconds.	

While the test is in progress, dots traverse the display and test progress is shown.

#### **Postrequisites**

View the test results and take any appropriate actions.

#### SMV flowchart: Running a test using the display

**RUN VERFY** Select OUTPUTS EXIT Select **CONTINUE MEASR FAULT** LAST VALUE **EXIT** Select Select Select ARE YOU SURE/YES? Select .....**x**% Select SENSOR ABORT/YES? Select Scroll Test result Fail PASS VERFY CAUTION VERFY ABORTED VERFY Scroll Scroll Scroll RESULTS VIEW/YES? Abort Type Scroll Scroll Select RERUN/YES? To Runcount (see Results Read) Scroll Correct condition — To Enter Meter Verfy· — → Select

Figure 9-2: Running an SMV test using the display

## Run an SMV test using ProLink III

1. Choose **Device Tools > Diagnostics > Meter Verification > Run Test**.

You may need to wait a few seconds while ProLink III synchronizes its database with the transmitter data.

2. Enter any desired information on the Test Definition screen, and click **Next**.

All information on this screen is optional.

3. Choose the desired output behavior.

Option	Description
Continue Measur- ing	During the test, all outputs will continue to report their assigned process variable. The test will run for approximately 90 seconds.
Held at Last Value	During the test, all outputs will report the last measured value of their assigned process variable. The test will run for approximately 140 seconds.
Held at Fault	During the test, all outputs will go to their configured fault action. The test will run for approximately 140 seconds.

#### 4. Press **Start**.

Test progress is displayed on the screen.

#### **Postrequisites**

View the test results and take any appropriate actions. You can also print the report.

## Run an SMV test using the Field Communicator

- 1. Navigate to the Smart Meter Verification menu:
  - Overview > Shortcuts > Meter Verification
  - Service Tools > Maintenance > Routine Maintenance > Meter Verification
- 2. Choose Manual Verification.
- 3. Choose **Start**.
- 4. Set output behavior as desired, and press **OK** if prompted.

Option	Description
Continue Measuring	During the test, all outputs will continue to report their assigned process variable. The test will run for approximately 90 seconds.
Outputs Held at Last Value	During the test, all outputs will report the last measured value of their assigned process variable. The test will run for approximately 140 seconds.
Outputs Held at Fault	During the test, all outputs will go to their configured fault action. The test will run for approximately 140 seconds.

Test progress is displayed on the screen.

#### **Postrequisites**

View the test results and take any appropriate actions.

#### 9.2.4 View test data

You can view the results of the current test. You can also view results from previous tests. You must use ProLink III to view test results.

#### **Important**

You can view previous test results and see detailed test reports only if SMV is licensed.

The transmitter stores the following information about the previous twenty SMV tests:

- Powered-on hours at the time of the test.
- Test result (Pass, Fail, Abort).
- Abort code, if applicable.

In addition, ProLink III provides a detailed test reporting and analysis framework. This information is stored on the PC where ProLink III is installed for tests that were run only on that PC. It includes:


- Timestamp from the PC clock
- Current flowmeter identification data
- Current flow and density configuration parameters
- Current zero values
- Current process values for mass flow rate, volume flow rate, density, temperature, and external pressure
- Customer and test descriptions (if entered by the user)

You can use ProLink III to run a test that displays a test result chart and a test report at the completion of the test. On-screen directions are provided to manipulate the test data or export the data to a CSV file for offline analysis.

## View test result data using the display

- If you have just run a test, results are displayed automatically at the end of the test.
- 2. If SMV is licensed, and you want to view results from previous tests:
  - a. Navigate to the Smart Meter Verification menu.

Figure 9-3: SMV – Top-level menu



b. Scroll to **Results Read** and press **Select**.

The runcount of the most recent test is displayed.

- c. To view data for this test, press **Select**, then press **Scroll** to scroll through test data.
- d. To select a different test, press **Scroll**, then press **Select** when the transmitter displays **Results More?**. When the desired test appears, as identified by runcount, press **Select**.

#### SMV flowchart: Viewing test results using the display

**RESULTS READ** Select RUNCOUNT x Select Scroll Result type Fail xx HOURS xx HOURS xx HOURS Select Select PASS FAIL Abort Type Select Select Select RESULTS MORE? Select Scroll - To Run Verfy - → To Runcount x-1

Figure 9-4: Viewing SMV test results using the display

#### Note

If you have a basic (unlicensed version) of SMV, you will not be prompted for RESULTS MORE?.

## View test result data using ProLink III

#### **Prerequisites**

You can view test result data only if your SMV is licensed and only for tests that were run on the PC you are currently using.

#### **Procedure**

 Choose Device Tools > Diagnostics > Meter Verification and click Previous Test Results.

The chart shows test results for all tests stored in the ProLink III database.

- 2. (Optional) Click **Next** to view and print a test report.
- 3. (Optional) Click **Export Data to CSV File** to save the data to a file on your PC.

## View test result data using the Field Communicator

#### **Prerequisites**

You can view test result data only if your SMV is licensed.

#### **Procedure**

- 1. Navigate to the Smart Meter Verification menu:
  - Overview > Shortcuts > Meter Verification
  - Service Tools > Maintenance > Routine Maintenance > Meter Verification
- 2. (Optional) If the Field Communicator database is out of date, choose **Upload Results**Data from Device.
- 3. To view data from the most recent test, choose **Most Recent Test Results**.
- 4. To view data for all tests in the Field Communicator database:
  - a. Press Show Results Table.

Data from the most recent test is displayed.

- b. Press **OK** to scroll through data from previous tests.
- c. To exit the results table, press **Abort**.

## **Understanding SMV results**

When the SMV test is completed, the result is reported as Pass, Fail, or Abort. (Some tools report the Fail result as Advisory instead.)

**Pass** Smart Meter Verification does a statistical check between the factory baseline value and the current Smart Meter Verification result. Pass indicates that the two values are statistically the same.

**Fail** The current SMV value is statistically different than the factory baseline value.

- If the meter passes the second test, the first result can be ignored.
- If the meter fails the second test, the flow tubes may be damaged. Call customer support.

**Abort** A problem occurred with the meter verification test (such as process instability) or you stopped the test manually. See *Table 9-3* for a list of abort codes, a description of each code, and possible actions you can take in response.

Table 9-3: SMV abort codes

Code	Description	Recommended actions
1	User-initiated abort	None required. Wait 15 seconds before starting another test.
3	Frequency drift	Ensure that temperature, flow, and density are stable, and rerun the test.
5	High drive gain	Ensure that flow is stable, minimize entrained gas, and rerun the test.
8	Unstable flow	<ul> <li>Check factors that could cause process instability, then rerun the test. To maximize process stability:</li> <li>Maintain a constant fluid pressure and temperature.</li> <li>Avoid changes to fluid composition, such as two-phase flow or settling.</li> <li>Maintain a constant flow rate.</li> </ul>
12	There is a fault present and SMV cannot run	View the Alerts present on the device and take any necessary actions to clear them.
13	No factory reference data for meter verification test per- formed on air	Contact customer service.
14	No factory reference data for meter verification test per- formed on water	Contact customer service.
15	No configuration data for meter verification	Contact customer service.
Other	General abort	Repeat the test. If the test aborts again, contact customer service.


## 9.2.5 Schedule automatic execution of the SMV test

You can set up and run a single test at a user-defined future time. You can also set up and run tests on a regular schedule.

## Manage scheduled test execution using the display

1. Navigate to the Smart Meter Verification menu.

Figure 9-5: SMV – Top-level menu



- 2. Scroll to **Schedule Verfy** and press **Select**.
- 3. To schedule a single test or the first test in recurring execution:
  - a. Scroll to **Set Next** and press **Select**.
  - b. Enter the number of hours that the transmitter will wait before beginning the test.
- 4. To schedule recurring execution:
  - a. Scroll to **Set Recur** and press **Select**.
  - b. Enter the number of hours that will elapse between tests.
- 5. To disable scheduled execution:
  - To disable execution of a single scheduled test, set **Set Next** to 0.
  - To disable recurring execution, set **Set Recur** to 0.
  - To disable all scheduled execution, choose **Turn Off Sched** when you enter the Smart Meter Verification menu.

#### SMV flowchart: Scheduling test execution using the display

SCHEDULE VERFY Select Schedule set? SCHED IS OFF TURN OFF SCHED/YES? Scroll Scroll Select Schedule deleted **HOURS LEFT** Scroll Select **xx HOURS** Select SET NEXT SET RECUR EXIT Scroll Scroll Select Select **xx HOURS xx HOURS** SAVE/YES? SAVE/YES? Scroll Select Scroll Select

Figure 9-6: Scheduling SMV test execution using the display

## Manage scheduled test execution using ProLink III

- 1. Choose Device Tools > Diagnostics > Meter Verification > Schedule Meter Verification.
- 2. To schedule a single test or the first test in recurring execution, specify a value for **Hours Until Next Run**.

- To schedule recurring execution, specify a value for Hours Between Recurring Runs.
- To disable scheduled execution:
  - To disable execution of a single scheduled test, set **Hours Until Next Run** to 0.
  - To disable recurring execution, set **Hours Between Recurring Runs** to 0.
  - To disable all scheduled execution, click Disable Scheduled Execution.

## Manage scheduled test execution using the Field Communicator

- 1. Navigate to the Smart Meter Verification menu:
  - Overview > Shortcuts > Meter Verification
  - Service Tools > Maintenance > Routine Maintenance > Meter Verification
- 2. Choose **Automatic Verification**.
- To schedule a single test or the first test in recurring execution, specify a value for Hrs Until Next Run.
- 4. To schedule recurring execution, specify a value for **Set Recurring Hours**.
- 5. To disable scheduled execution:
  - To disable execution of a single scheduled test, set **Hrs Until Next Run** to 0.
  - To disable recurring execution, set Set Recurring Hours to 0.
  - To disable all scheduled execution, choose Turn Off Schedule.

## 9.3 Use PVR, TBR, and TMR

For detailed information about Production Volume Reconciliation (PVR), Transient Mist Remediation (TMR), and Transient Bubble Remediation (TBR), see the *Micro Motion* Oil and Gas Production Applications manual.

#### Restriction

PVR, TBR, and TMR are available only with a transmitter that is ordered with one of these software options:

- An 800 Enhanced Core Processor version 4.4 and later
- HART with HART 7 enabled in order to view process variables over HART (default)

#### Restriction

PVR, TBR, and TMR process variables are available only over HART with HART 7 enabled (default). PVR, TBR, and TMR parameters cannot be configured with HART.

## 9.3.1 PVR, TBR, and TMR applications

PVR, TBR, and TMR are applications designed to provide more accurate process data in the presence of multiple phases. For example, if bubbles are present in the process fluid, or the process fluid is flashing, the volume measurements are often incorrect.

#### **Production Volume Reconciliation (PVR)**

- Provides oil and water volumes through density-based calculations for both line and reference conditions
- Detects bubble entrainment or flashing in the sensor, and can correct volumes accordingly
- Best for undersized three-phase separators that frequently have intermittent gas or water contamination in the oil leg
- Offers a simple, low-cost solution for net oil and net water measurement for twophase separators

#### **Transient Bubble Remediation (TBR)**

- Used with single-component liquid streams that may experience intermittent low levels of gas entrainment, that is, gas carryunder
- Enables accurate measurement of a single fluid during periods of entrained gas by providing a substitute density value based on the immediately preceding process density (standard configuration)
- Tracks total time of aerated flow to assist in diagnosing process issues that may cause aeration

#### Transient Mist Remediation (TMR)

- Used with gas streams that may experience intermittent low levels of liquid entrainment, i.e., liquid carry-over
- Allows gas measurement to continue during periods of entrained liquid (mist) by providing a substitute flow rate value based on the immediately preceding process flow rate
- Returns to reporting the measured flow rate when the mist interval is over, increased or decreased by a maximum of 10%, until flow totals are appropriately adjusted for the unmeasured flow
- Provides an indication of the amount of time that liquid was present in the stream —
  identifying process improvements to reduce gas stream contamination

# 9.4 Piecewise linearization (PWL) for calibrating gas meters

Piecewise linearization (PWL) can linearize the measurements of flow meters for greater accuracy in order to measure gas over a wide range of flow rates. PWL does not apply when measuring liquid flow. When better accuracy is required over the published gas measurement specifications, an Emerson-approved independent gas laboratory can calibrate gas up to 10 PWL adjustment points.

PWL configuration and calibration information is not available through HART.

For more information, see the white paper, *The Practical Application of Multi-Point Piecewise Linear Interpolation (PWL) and Other Developing Trends with Coriolis Meters for Natural Gas Custody Transfer Applications*, available at <a href="https://www.emerson.com">www.emerson.com</a>.

The PWL feature is available in ProLink III, so you can view the points that are stored and capture them in the uploaded and downloaded configuration files.

## 9.5 Zero the meter

Zeroing the meter establishes a baseline for process measurement by analyzing the sensor's output when there is no flow through the sensor tubes.

#### **Prerequisites**

Verify the zero and prepare the meter using the procedures in Section 2.6.

#### **Procedure**

Zero the meter.

Tool	Path	
Display	OFFLINE MAINT > ZERO > CAL ZERO > CAL/YES?	
	To restore the zero value set at the factory: <b>OFFLINE MAINT &gt; ZERO &gt; RESTORE ZERO &gt; RESTORE/YES?</b> This function requires the enhanced core processor.	
ProLink III	Device Tools > Calibration > Zero Verification and Calibration > Calibrate Zero	
Field Communicator	Service Tools > Maintenance > Zero Calibration > Perform Auto Zero	

If necessary, modify **Zero Time**. **Zero Time** controls the amount of time the transmitter takes to determine its zero-flow reference point. The default **Zero Time** is 20 seconds. For most applications, the default **Zero Time** is appropriate.

#### **Postrequisites**

Restore normal flow through the sensor by opening the valves. Verify that the sensor tubes are full.

**Need help?** If the zero fails:

- Verify that there is no flow through the sensor, then retry.
- Remove or reduce sources of electromechanical noise, then retry.
- Set Zero Time to a lower value, then retry.
- If the zero continues to fail, contact customer service.

## 9.6 Validate the meter

Display	OFF-LINE MAINT > CONFG > UNITS > MTR F	
ProLink III	Device Tools > Configuration > Process Measurement > Flow	
	Device Tools > Configuration > Process Measurement > Density	
Field Communicator	Configure > Manual Setup > Measurements > Flow	
	Configure > Manual Setup > Measurements > Density	

#### **Overview**

Meter validation compares flowmeter measurements reported by the transmitter to an external measurement standard. If the transmitter value for mass flow, volume flow, or density measurement is significantly different from the external measurement standard, you may want to adjust the corresponding meter factor. The flowmeter's actual measurement is multiplied by the meter factor, and the resulting value is reported and used in further processing.

#### **Prerequisites**

Identify the meter factor(s) that you will calculate and set. You may set any combination of the three meter factors: mass flow, volume flow, and density. Note that all three meter factors are independent:

- The meter factor for mass flow affects only the value reported for mass flow.
- The meter factor for density affects only the value reported for density.
- The meter factor for volume flow affects only the value reported for volume flow or gas standard volume flow.

#### **Important**

To adjust volume flow, you must set the meter factor for volume flow. Setting a meter factor for mass flow and a meter factor for density will not produce the desired result. The volume flow calculations are based on original mass flow and density values, before the corresponding meter factors have been applied.

If you plan to calculate the meter factor for volume flow, be aware that validating volume in the field may be expensive, and the procedure may be hazardous for some process fluids. Therefore, because volume is inversely proportional to density, an alternative to direct measurement is to calculate the meter factor for volume flow from the meter factor for density. See *Section 9.6.1* for instructions on this method.

Obtain a reference device (external measurement device) for the appropriate process variable.

#### **Important**

For good results, the reference device must be highly accurate.

#### **Procedure**

- 1. Determine the meter factor as follows:
  - a. Set the meter factor to 1 to take a sample measurement.
  - b. Measure the same sample using the reference device.
  - c. Calculate the meter factor using the following formula:

NewMeterFactor = ConfiguredMeterFactor 
$$\mathbf{x}$$
  $\left(\frac{\text{ReferenceMeasurement}}{\text{FlowmeterMeasurement}}\right)$ 

- 2. Ensure that the calculated meter factor does not fall outside 0.98 and 1.02. If the meter factor is outside these limits, contact customer service.
- 3. Configure the meter factor in the transmitter.

#### Example: Calculating the meter factor for mass flow

The flowmeter is installed and validated for the first time. The mass flow measurement from the transmitter is 250.27 lb. The mass flow measurement from the reference device is 250 lb. The mass flow meter factor is calculated as follows:

MeterFactor<sub>MassFlow</sub> = 1 
$$\mathbf{x}$$
  $\left(\frac{250}{250.27}\right)$  = 0.9989

The first meter factor for mass flow is 0.9989.

One year later, the flowmeter is validated again. The mass flow measurement from the transmitter is 250.07 lb. The mass flow measurement from the reference device is 250.25 lb. The new mass flow meter factor is calculated as follows:

MeterFactor<sub>MassFlow</sub> = 0.9989 
$$\mathbf{x}$$
  $\left(\frac{250.25}{250.07}\right)$  = 0.9996

The new meter factor for mass flow is 0.9996.

# 9.6.1 Alternate method for calculating the meter factor for volume flow

The alternate method for calculating the meter factor for volume flow is used to avoid the difficulties that may be associated with the standard method.

This alternate method is based on the fact that volume is inversely proportional to density. It provides partial correction of the volume flow measurement by adjusting for the portion of the total offset that is caused by the density measurement offset. Use this method only when a volume flow reference is not available, but a density reference is available.

#### **Procedure**

- 1. Calculate the meter factor for density, using the standard method (see Section 9.6).
- 2. Calculate the meter factor for volume flow from the meter factor for density:

$$MeterFactor_{Volume} = \left(\frac{1}{MeterFactor_{Density}}\right)$$

#### Note

The following equation is mathematically equivalent to the first equation. You may use whichever version you prefer.

$$MeterFactor_{Volume} = ConfiguredMeterFactor_{Density} \quad \textbf{X} \quad \left( \begin{array}{c} Density_{Flowmeter} \\ \hline Density_{Reference\ Device} \end{array} \right)$$

- 3. Ensure that the calculated meter factor does not fall outside 0.98 and 1.02. If the meter factor is outside these limits, contact customer service.
- 4. Configure the meter factor for volume flow in the transmitter.

# 9.7 Perform a (standard) D1 and D2 density calibration

Density calibration establishes the relationship between the density of the calibration fluids and the signal produced at the sensor. Density calibration includes the calibration of the D1 (low-density) and D2 (high-density) calibration points.

#### **Important**

Micro Motion flowmeters are calibrated at the factory, and normally do not need to be calibrated in the field. Calibrate the flowmeter only if you must do so to meet regulatory requirements. Contact customer support before calibrating the flowmeter.

#### Tip

Use meter validation and meter factors, rather than calibration, to prove the meter against a regulatory standard or to correct measurement error.

#### **Prerequisites**

- During density calibration, the sensor must be completely filled with the calibration fluid, and flow through the sensor must be at the lowest rate allowed by your application. This is usually accomplished by closing the shutoff valve downstream from the sensor, then filling the sensor with the appropriate fluid.
- D1 and D2 density calibration require a D1 (low-density) fluid and a D2 (high-density) fluid. You may use air and water.


- If LD Optimization is enabled on your meter, disable it. To do this, choose Configure > Manual Setup > Measurements > LD Optimization. LD Optimization is used only with large sensors in hydrocarbon applications. In some installations, only customer service has access to this parameter. If this is the case, contact customer service before continuing.
- The calibrations must be performed without interruption, in the order shown. Make sure that you are prepared to complete the process without interruption.
- Before performing the calibration, record your current calibration parameters. You
  can do this by saving the current configuration to a file on the PC. If the calibration
  fails, restore the known values.

#### Restriction

For T-Series sensors, the D1 calibration must be performed on air and the D2 calibration must be performed on water.

## 9.7.1 Perform a D1 and D2 density calibration using ProLink III

- 1. Read the Prerequisites on *page 137* if you have not already done so.
- 2. See the following figure.




#### **Postrequisites**

If you disabled **LD Optimization** before the calibration procedure, re-enable it.

# 9.7.2 Perform a D1 and D2 density calibration using the Field Communicator

- 1. Read the Prerequistes on *page 137* if you have not already done so.
- 2. See the following figure.



#### **Postrequisites**

If you disabled **LD Optimization** before the calibration procedure, re-enable it.

# 9.8 Perform a D3 and D4 density calibration (T-Series sensors only)

For T-Series sensors, the optional D3 and D4 calibration could improve the accuracy of the density measurement if the density of your process fluid is less than  $0.8 \text{ g/cm}^3$  or greater than  $1.2 \text{ g/cm}^3$ .

If you perform the D3 and D4 calibration, note the following:

- Do not perform the D1 and D2 calibration.
- Perform the D3 calibration if you have one calibrated fluid.
- Perform both the D3 and D4 calibrations if you have two calibrated fluids (other than air and water). The calibrations must be performed without interruption, in the order shown. Make sure that you are prepared to complete the process without interruption.

#### **Prerequisites**

- During density calibration, the sensor must be completely filled with the calibration fluid, and flow through the sensor must be at the lowest rate allowed by your application. This is usually accomplished by closing the shutoff valve downstream from the sensor, then filling the sensor with the appropriate fluid.
- For D3 density calibration, the D3 fluid must meet the following requirements:
  - Minimum density of 0.6 g/cm<sup>3</sup>
  - Minimum difference of 0.1 g/cm<sup>3</sup> between the density of the D3 fluid and the density of water. The density of the D3 fluid may be either greater or less than the density of water.
- For D4 density calibration, the D4 fluid must meet the following requirements:
  - Minimum density of 0.6 g/cm<sup>3</sup>
  - Minimum difference of 0.1 g/cm<sup>3</sup> between the density of the D4 fluid and the density of the D3 fluid. The density of the D4 fluid must be greater than the density of the D3 fluid.
  - Minimum difference of 0.1 g/cm<sup>3</sup> between the density of the D4 fluid and the density of water. The density of the D4 fluid may be either greater or less than the density of water.
- Before performing the calibration, record your current calibration parameters. You can do this by saving the current configuration to a file on the PC. If the calibration fails, restore the known values.

# 9.8.1 Perform a D3 or D3 and D4 density calibration using ProLink III

See Figure 9-7.




Figure 9-7: D3 or D3 and D4 density calibration using ProLink III

# 9.8.2 Perform a D3 or D3 and D4 density calibration using the Field Communicator

See the following flowchart.




Figure 9-8: D3 or D3 and D4 density calibration using the Field Communicator

# 9.9 Perform temperature calibration

Temperature calibration establishes the relationship between the temperature of the calibration fluids and the signal produced by the sensor.

#### **Prerequisites**

The temperature calibration is a two-part procedure: temperature offset calibration and temperature slope calibration. The two parts must be performed without interruption, in the order shown. Ensure that you are prepared to complete the process without interruption. You will need a low-temperature calibration fluid and a high-temperature calibration fluid. You will not see the effect of the calibration until both the temperature offset calibration and the temperature slope calibration are complete.

#### **Important**


Consult customer support before performing a temperature calibration. Under normal circumstances, the temperature circuit is stable and should not need an adjustment.

## 9.9.1 Perform temperature calibration using the display


- 1. Fill the sensor with the low-temperature fluid.
- 2. Wait until the sensor achieves thermal equilibrium.
- 3. Navigate to the calibration menu and enter it.
  - a. Activate Scroll and Select simultaneously.
  - b. Scroll to OFF-LINE MAINTand activate Select.
  - c. Scroll to OFF-LINE CAL and activate Select.
  - d. Scroll to **CAL TEMP** and activate **Select**.
- 4. Enter the temperature of the low-temperature fluid.
  - a. When **CAL OFFSET TEMP** is flashing, activate **Select**.
  - b. Enter the temperature value and save it.
- 5. Fill the sensor with the high-temperature fluid.
- 6. Wait until the sensor achieves thermal equilibrium.
- 7. Enter the temperature of the high-temperature fluid.
  - a. When CAL SLOPE TEMP is flashing, activate Select.
  - b. Enter the temperature value and save it.
- 8. Activate **Scroll** to view the new offset and slope values.
- 9. Activate **Select** to exit.

## 9.9.2 Perform temperature calibration using ProLink III

See the following figure.



# 9.9.3 Perform temperature calibration using the Field Communicator



# 10 Troubleshooting

#### Topics covered in this chapter:

- Status LED states
- Status alerts, causes, and recommendations
- Flow measurement problems
- Density measurement problems
- Temperature measurement problems
- Milliamp output problems
- Frequency Output problems
- Using sensor simulation for troubleshooting
- Check power supply wiring
- Check sensor-to-transmitter wiring
- Check grounding
- Perform loop tests
- Check the HART communication loop
- Check HART Address and mA Output Action
- Check HART burst mode
- Check the trimming of the mA Output
- Check Lower Range Value and Upper Range Value
- Check mA Output Fault Action
- Check for radio frequency interference (RFI)
- Check Frequency Output Scaling Method
- Check Frequency Output Fault Action
- Check Flow Direction
- Check the cutoffs
- Check for two-phase flow (slug flow)
- Check the drive gain
- Check the pickoff voltage
- Check for internal electrical problems
- Check the core processor LED
- Perform a 700 core processor resistance test

### 10.1 Status LED states

The status LED on the transmitter indicates whether or not alerts are active. If alerts are active, view the alert list to identify the alerts, then take appropriate action to correct the alert condition.

Your transmitter has a status LED only if it has a display.

If the transmitter has a display and **LED Blinking** is disabled, the status LED does not flash to indicate an unacknowledged alert.

Table 10-1: Transmitter status reported by status LED

LED state	Description	Recommendation
Solid green	No alerts are active.	Continue with configuration or process measurement.
Flashing green (if enabled)	Unacknowledged corrected condition (no alert)	Continue with configuration or process measurement. Acknowledge the alert if you choose.
Solid yellow	One or more low-severity alerts are active.	A low-severity alert condition does not affect measurement accuracy or output behavior. You can continue with configuration or process measurement, but Micro Motion still recommends identifying and resolving the alert condition.
Flashing yellow (if enabled)	Calibration in progress, or Known Density Verification in progress.  One or more low-severity alerts are active and have not been acknowledged.	A low-severity alert condition does not affect measurement accuracy or output behavior. You can continue with configuration or process measurement, but Micro Motion still recommends identifying and resolving the alert condition.
Solid red	One or more high-severity alerts are active.	A high-severity alert condition affects measurement accuracy and output behavior. Resolve the alert condition before continuing.
Flashing red (if ena- bled)	One or more high-severity alerts are active and have not been acknowledged.	A high-severity alert condition affects measurement accuracy and output behavior. Resolve the alert condition before continuing. Acknowledge the alert if you choose.

## 10.2 Status alerts, causes, and recommendations

Alert num- ber	Alert title	Possible cause	Recommended actions
A001	EEPROM Error (Core Processor)	The core processor has experienced a memory error.	<ul><li>Cycle power to the meter.</li><li>Replace the core processor.</li><li>Contact customer support.</li></ul>

Alert num- ber	Alert title	Possible cause	Recommended actions
A002	RAM Error (Core Processor)	The core processor has experienced a memory error.	<ul><li>Cycle power to the meter.</li><li>Replace the core processor.</li><li>Contact customer support.</li></ul>
A003	No Sensor Response	The transmitter is not receiving one or more basic electrical signals from the sensor. This alert often occurs in conjunction with Alert 102.	<ul> <li>Check the drive gain and the pickoff voltage.</li> <li>Check the wiring between the sensor and the transmitter.</li> <li>Verify that internal wiring is secure and that there are no internal electrical problems.</li> <li>Check the integrity of the sensor tubes.</li> <li>Perform sensor coil resistance checks.</li> </ul>
A004	Temperature Over- range	The RTD resistance is out of range for the sensor. The tube RTD resistance is out of range for the sensor.	<ul> <li>Check your process conditions against the values reported by the device.</li> <li>Verify temperature characterization or calibration parameters.</li> <li>Verify that internal wiring is secure and that there are no internal electrical problems.</li> <li>Check the wiring between the sensor and the transmitter.</li> <li>Contact customer support.</li> </ul>
A005	Mass Flow Rate Overrange	The measured flow rate is greater than the maximum flow rate of the sensor ( $\Delta T$ greater than 200 $\mu s$ ).	<ul> <li>If other alerts are present, resolve those alert conditions first. If the current alert persists, continue with the recommended actions.</li> <li>Check your process conditions against the values reported by the device.</li> <li>Check for two-phase flow.</li> </ul>
A006	Characterization Required	Calibration factors have not been entered, or the sensor type is incorrect, or the calibration factors are incorrect for the sensor type.	<ul> <li>Verify all of the characterization or calibration parameters. See the sensor tag or the calibration sheet for your meter.</li> <li>Verify the setting of the Sensor Type parameter.</li> <li>If Sensor Type=Curved Tube, ensure that no parameters specific to Straight Tube have been set.</li> <li>Verify that internal wiring is secure and that there are no internal electrical problems.</li> <li>Replace the core processor.</li> <li>Contact customer support.</li> </ul>

Alert num- ber	Alert title	Possible cause	Recommended actions
A008	Density Overrange	The line density is greater than 10 g/cm <sup>3</sup> (10000 kg/m <sup>3</sup> ).	<ul> <li>If other alerts are present, resolve those alert conditions first. If the current alert persists, continue with the recommended actions.</li> <li>Check for air in the flow tubes, tubes not filled, foreign material in the tubes, coating in the tubes, or other process problems.</li> <li>Check for two-phase flow.</li> <li>Verify all of the characterization or calibration parameters. See the sensor tag or the calibration sheet for your meter.</li> <li>Check the drive gain and the pickoff voltage.</li> <li>Perform density calibration.</li> <li>Contact customer support.</li> </ul>
A009	Transmitter Initializ- ing/Warming Up	Transmitter is in power-up mode. This alert often occurs in conjunction with Alerts 14 and 26.	<ul> <li>Allow the meter to complete its power-up sequence. The alert should clear automatically.</li> <li>If other alerts are present, resolve those alert conditions first. If the current alert persists, continue with the recommended actions.</li> <li>Verify that the tubes are full of process fluid.</li> <li>Check the wiring between the sensor and the transmitter.</li> <li>Verify that the transmitter is receiving sufficient power.</li> <li>If it is not, correct the problem and cycle power to the meter.</li> <li>If it is, this suggests that the transmitter has an internal power issue. Replace the transmitter.</li> <li>Ensure that the process fluid is stable. Check for two-phase flow, high process noise, or a fast transition between two fluids of different densities.</li> </ul>
A010	Calibration Failure	Many possible causes. This alert will not clear until you cycle power to the meter.	<ul> <li>Ensure that your calibration procedure meets the documented requirements, cycle power to the meter, then retry the procedure.</li> <li>If this alert appears during zeroing, verify that there is no flow through the sensor, cycle power to the meter, then retry the procedure.</li> </ul>

Alert num- ber	Alert title	Possible cause	Recommended actions
A011	Zero Calibration Failed: Low	Many possible causes, such as too much flow, especially reverse flow, through the sensor during a calibration procedure, or a zero result that is too low. This alert is accompanied by A010.  This alert will not clear until you cycle power to the meter.	Verify that there is no flow through the sensor, cycle power to the meter, then retry the procedure.
A012	Zero Calibration Failed: High	Many possible causes, such as too much flow, especially forward flow, through the sensor during a calibration procedure, or a zero result that is too high. This alert is accompanied by A010.  This alert will not clear until you cycle power to the meter.	Verify that there is no flow through the sensor, cycle power to the meter, then retry the procedure.
A013	Zero Calibration Failed: Unstable	There was too much process instability during the calibration procedure.  This alert will not clear until you cycle power to the meter.	Remove or reduce sources of electro- mechanical noise (e.g., pumps, vibra- tion, pipe stress), cycle power to the meter, then retry the procedure.
A014	Transmitter Failure	Many possible causes. This alert often occurs in conjunction with alerts A9 and A26.	<ul> <li>Ensure that all wiring compartment covers are installed correctly.</li> <li>Ensure that all transmitter wiring meets specifications and that all cable shields are properly terminated.</li> <li>Check the grounding of all components.</li> <li>Evaluate the environment for sources of high electromagnetic interference (EMI) and relocate the transmitter or wiring as necessary.</li> <li>Contact customer support.</li> </ul>
A016	Sensor Temperature (RTD) Failure	The value computed for the resistance of the line RTD is outside limits.	<ul> <li>Check your process conditions against the values reported by the device.</li> <li>Check the wiring between the sensor and the transmitter.</li> <li>Verify that internal wiring is secure and that there are no internal electrical problems.</li> <li>Contact customer support.</li> </ul>

Alert num- ber	Alert title	Possible cause	Recommended actions
A017	Sensor Case Temperature (RTD) Failure	The values computed for the resistance of the meter and case RTDs are outside limits.	<ul> <li>Check your process conditions against the values reported by the device. Temperature should be between -200 °F and +400 °F.</li> <li>Verify all of the characterization or calibration parameters. See the sensor tag or the calibration sheet for your meter.</li> <li>Check the wiring between the sensor and the transmitter.</li> <li>Verify that internal wiring is secure and that there are no internal electrical problems.</li> <li>Contact customer support.</li> </ul>
A018	EEPROM Error (Transmitter)	The transmitter has experienced a memory error. This alert will not clear until you cycle power to the meter.	<ul> <li>Ensure that all wiring compartment covers are installed correctly.</li> <li>Ensure that all transmitter wiring meets specifications and that all cable shields are properly terminated.</li> <li>Check the grounding of all components.</li> <li>Evaluate the environment for sources of high electromagnetic interference (EMI) and relocate the transmitter or wiring as necessary.</li> <li>Cycle power to the meter.</li> <li>If the alert persists, replace the transmitter.</li> <li>Contact customer support.</li> </ul>
A019	RAM Error (Trans-mitter)	The transmitter has experienced a memory error. This alert will not clear until you cycle power to the meter.	<ul> <li>Ensure that all wiring compartment covers are installed correctly.</li> <li>Ensure that all transmitter wiring meets specifications and that all cable shields are properly terminated.</li> <li>Check the grounding of all components.</li> <li>Evaluate the environment for sources of high electromagnetic interference (EMI) and relocate the transmitter or wiring as necessary.</li> <li>Cycle power to the meter.</li> <li>If the alert persists, replace the transmitter.</li> <li>Contact customer support.</li> </ul>

Alert num- ber	Alert title	Possible cause	Recommended actions
A020	Calibration Factors Missing	Some calibration factors have not been entered or are incorrect.	<ul> <li>Verify all of the characterization or calibration parameters. See the sensor tag or the calibration sheet for your meter.</li> <li>Verify the setting of the Sensor Type parameter.</li> <li>If Sensor Type=Curved Tube, ensure that no parameters specific to Straight Tube have been set.</li> </ul>
A021	Transmitter/Sensor/ Software Mismatch	The configured board type does not match the physical board, or the configured sensor type does not match the physical sensor.	<ul> <li>Verify all of the characterization or calibration parameters. See the sensor tag or the calibration sheet for your meter.</li> <li>Ensure that the correct board is installed.</li> <li>Verify the setting of the Sensor Type parameter.</li> <li>If Sensor Type=Curved Tube, ensure that no parameters specific to Straight Tube have been set.</li> </ul>
A022	Configuration Data- base Corrupt (Core Processor)	Internal electronics failure.	<ul><li>Cycle power to the meter.</li><li>Contact customer support.</li></ul>
A023	Internal Totals Corrupt (Core Processor)	Internal electronics failure.	<ul><li>Cycle power to the meter.</li><li>Contact customer support.</li></ul>
A024	Program Corrupt (Core Processor)	Internal electronics failure.	<ul><li>Cycle power to the meter.</li><li>Contact customer support.</li></ul>
A025	Boot Sector Fault (Core Processor)	Internal electronics failure.	<ul><li>Cycle power to the meter.</li><li>Contact customer support.</li></ul>

Alert num- ber	Alert title	Possible cause	Recommended actions
A026	Sensor/Transmitter Communications Failure	The transmitter has lost communication with the core processor. There may be a problem with the wiring or with either component. This alert often occurs in conjunction with alerts A9 and A14.	<ul> <li>Check the wiring between the sensor and the transmitter.</li> <li>Check for noise in the wiring or in the transmitter environment.</li> <li>Verify that internal wiring is secure and that there are no internal electrical problems.</li> <li>Check the status LED on the core processor.</li> <li>Check the resistance across core processor terminals.</li> <li>If the alert persists: <ul> <li>Replace the core processor.</li> <li>If that does not solve the problem, restore the original core processor and replace the transmitter.</li> <li>If that does not solve the problem, replace both the transmitter and the core processor.</li> </ul> </li> </ul>
A028	Core Processor Write Failure	Internal electronics failure.	<ul><li>Cycle power to the meter.</li><li>Contact customer support.</li></ul>
A029	Internal Electronics Failure	This can indicate a loss of communication between the transmitter and the display module.	<ul><li>Cycle power to the meter.</li><li>Replace the display module.</li><li>Contact customer support.</li></ul>
A030	Incorrect Board Type	The loaded software is not compatible with the programmed board type.	Contact customer support.
A031	Low Power	The core processor or transmitter is not receiving enough power.  This alert will not clear until you cycle power to the meter.	<ul> <li>Check the wiring between the transmitter and the core processor, then cycle power to the meter.</li> <li>Check the wiring of the transmitter, then cycle power to the meter.</li> <li>Verify that the transmitter is receiving sufficient power.</li> <li>If it is not, correct the problem and cycle power to the meter.</li> <li>If it is, this suggests that the transmitter has an internal power issue. Replace the transmitter.</li> </ul>
A032	Meter Verification in Progress: Outputs to Fault	A meter verification test is in progress, with outputs set to Fault.	Allow the procedure to complete.

Alert num- ber	Alert title	Possible cause	Recommended actions
A033	Insufficient Pickoff Signal	The signal from the sensor pick-off(s) is insufficient. This suggests that the sensor tubes or vibrating elements are not vibrating. This alert often occurs in conjunction with Alert 102.	<ul> <li>Check for air in the flow tubes, tubes not filled, foreign material in the tubes, coating in the tubes, or other process problems.</li> <li>Check for foreign material in the process gas or fluid, coating, or other process problems.</li> <li>Check for fluid separation by monitoring the density value and comparing the results against expected density values.</li> <li>Ensure that the sensor orientation is appropriate for your application. Settling from a two-phase or three-phase fluid can cause this alert even if the flow tubes are full.</li> </ul>
A035	Meter Verification Aborted	The meter verification test did not complete, possibly because of a manual abort.	<ul><li>Verify that process conditions are stable, then retry the test.</li><li>Contact customer support.</li></ul>
A100	mA Output 1 Satura- ted	The calculated mA Output value is outside the configured range.	<ul> <li>Check the settings of Upper Range Value and Lower Range Value.</li> <li>Check process conditions. Actual conditions may be outside the normal conditions for which the output is configured.</li> <li>Check for air in the flow tubes, tubes not filled, foreign material in the tubes, coating in the tubes, or other process problems.</li> <li>Verify that the measurement units are configured correctly for your application.</li> <li>Purge the sensor tubes.</li> </ul>
A101	mA Output 1 Fixed	The HART address is set to a non- zero value, or the mA Output is con- figured to send a constant value.	<ul> <li>Check whether the output is in loop test mode. If it is, unfix the output.</li> <li>Exit mA Output trim, if applicable.</li> <li>Check the HART address. If the HART address is non-zero, you may need to change the setting of mA Output Action.</li> <li>Check whether the output has been set to a constant value via digital communication.</li> </ul>

Alert num- ber	Alert title	Possible cause	Recommended actions
A102	Drive Overrange	The drive power (current/voltage) is at its maximum.	<ul> <li>Check the drive gain and the pickoff voltage.</li> <li>Check the wiring between the sensor and the transmitter.</li> <li>Verify that internal wiring is secure and that there are no internal electrical problems.</li> <li>Check for air in the flow tubes, tubes not filled, foreign material in the tubes, coating in the tubes, or other process problems.</li> <li>Check for fluid separation by monitoring the density value and comparing the results against expected density values.</li> <li>Ensure that the sensor orientation is appropriate for your application. Settling from a two-phase or three-phase fluid can cause this alert even if the flow tubes are full.</li> </ul>
A103	Data Loss Possible (Totals and Invento- ries)	Totalizers are not properly saved. The device was unable to store the totalizers during the last powerdown, and must rely on the saved totals. The saved totals can be as much as two hours out of date.	<ul> <li>Check the wiring between the transmitter and the core processor, then cycle power to the meter.</li> <li>Verify that the transmitter is receiving sufficient power.</li> <li>If it is not, correct the problem and cycle power to the meter.</li> <li>If it is, this suggests that the transmitter has an internal power issue. Replace the transmitter.</li> </ul>
A104	Calibration in Progress	A calibration procedure is in process.	<ul> <li>Allow the procedure to complete.</li> <li>For zero calibration, you may abort the calibration, set <b>Zero Time</b> to a lower value, and restart the calibration.</li> </ul>
A105	Two-Phase Flow	The line density is outside the user-defined two-phase flow limits.	<ul> <li>Check for two-phase flow.</li> <li>Check the live density reading against the upper and lower two-phase flow limit settings.</li> </ul>
A106	Burst Mode Enabled	HART burst mode is enabled.	<ul> <li>No action required.</li> <li>If desired, you can set Alert Severity Level to Ignore.</li> </ul>
A107	Power Reset Occur- red	The transmitter has been restarted.	<ul> <li>No action required.</li> <li>If desired, you can set Alert Severity Level to Ignore.</li> </ul>

Alert num- ber	Alert title	Possible cause	Recommended actions
A108	Basic Event 1 On	The process has triggered Basic Event 1.	<ul> <li>No action required.</li> <li>Review event configuration if you believe the event was triggered erroneously.</li> </ul>
A109	Basic Event 2 On	The process has triggered Basic Event 2.	<ul> <li>No action required.</li> <li>Review event configuration if you believe the event was triggered erroneously.</li> </ul>
A110	Frequency Output Saturated	The calculated Frequency Output is outside the configured range.	<ul> <li>Check the Frequency Output scaling.</li> <li>Check process conditions. Actual conditions may be outside the normal conditions for which the output is configured.</li> <li>Check for air in the flow tubes, tubes not filled, foreign material in the tubes, coating in the tubes, or other process problems.</li> <li>Verify that the measurement units are configured correctly for your application.</li> <li>Purge the sensor tubes.</li> </ul>
A111	Frequency Output Fixed	The Frequency Output has been configured to send a constant value.	<ul> <li>Cycling power to the meter or restarting totalizers will restore the Frequency Output to normal operation.</li> <li>Check whether the output is in loop test mode. If it is, unfix the output.</li> <li>Check whether the output has been set to a constant value via digital communication.</li> </ul>
A112	Upgrade Transmit- ter Software	The transmitter software is down- level from the core processor soft- ware.	Contact customer support.
A113	mA Output 2 Saturated	The calculated mA Output value is outside the configured range.	<ul> <li>Check the settings of Upper Range Value and Lower Range Value.</li> <li>Check process conditions. Actual conditions may be outside the normal conditions for which the output is configured.</li> <li>Check for air in the flow tubes, tubes not filled, foreign material in the tubes, coating in the tubes, or other process problems.</li> <li>Verify that the measurement units are configured correctly for your application.</li> <li>Purge the sensor tubes.</li> </ul>

Alert num- ber	Alert title	Possible cause	Recommended actions
A114	mA Output 2 Fixed	The mA Output is configured to send a constant value.	<ul> <li>Check whether the output is in loop test mode. If it is, unfix the output.</li> <li>Exit mA Output trim, if applicable.</li> <li>Check whether the output has been set to a constant value via digital communication.</li> </ul>
A115	No External Input or Polled Data	The connection to an external measurement device has failed. No external data is available.	<ul> <li>Verify that the external device is operating correctly.</li> <li>Verify the wiring between the transmitter and the external device.</li> <li>Verify the HART polling configuration.</li> </ul>
A118	Discrete Output 1 Fixed	The Discrete Output has been configured to send a constant value.	Check whether the output is in loop test mode. If it is, unfix the output.
A131	Meter Verification in Progress: Outputs to Last Measured Value	A meter verification test is in progress, with outputs set to Last Measured Value.	Allow the procedure to complete.
A132	Sensor Simulation Active	Sensor simulation is enabled.	Disable sensor simulation.
N/A	Density FD Calibra- tion in Progress	A flowing density calibration is in progress.	No action required.
N/A	Density D1 Calibration in Progress	A D1 density calibration is in progress.	No action required.
N/A	Density D2 Calibration in Progress	A D2 density calibration is in progress.	No action required.
N/A	Density D3 Calibration in Progress	A D3 density calibration is in progress.	No action required.
N/A	Density D4 Calibration in Progress	A D4 density calibration is in progress.	No action required.
N/A	Zero Calibration in Progress	A zero calibration is in progress.	No action required.
N/A	Reverse Flow	Flow through the device is in the reverse direction (against the flow arrow).	No action required.

# 10.3 Flow measurement problems

Problem	Possible causes	Recommended actions
Non-zero flow reading at no-flow conditions or at zero offset	<ul> <li>Misaligned piping (especially in new installations)</li> <li>Open or leaking valve</li> <li>Incorrect sensor zero</li> </ul>	<ul> <li>If the reading is not excessively high, review the live zero. You may need to restore the factory zero.</li> <li>Check for open or leaking valves or seals.</li> <li>Check for mounting stress on the sensor (e.g., sensor being used to support piping, misaligned piping).</li> <li>Contact customer support.</li> </ul>
Erratic non-zero flow rate at no-flow conditions	<ul> <li>Leaking valve or seal</li> <li>Two-phase flow</li> <li>Plugged or coated sensor tube</li> <li>Incorrect sensor orientation</li> <li>Wiring problem</li> <li>Vibration in pipeline at rate close to sensor tube frequency</li> <li>Damping value too low</li> <li>Mounting stress on sensor</li> </ul>	<ul> <li>Verify that the sensor orientation is appropriate for your application (refer to the sensor installation manual).</li> <li>Check the drive gain and the pickoff voltage.</li> <li>If the wiring between the sensor and the transmitter includes a 9-wire segment, verify that the 9-wire cable shields are correctly grounded.</li> <li>Check the wiring between the sensor and the transmitter.</li> <li>For sensors with a junction box, check for moisture in the junction box.</li> <li>Purge the sensor tubes.</li> <li>Check for open or leaking valves or seals.</li> <li>Check for sources of vibration.</li> <li>Verify damping configuration.</li> <li>Verify that the measurement units are configured correctly for your application.</li> <li>Check for two-phase flow.</li> <li>Check for radio frequency interference.</li> <li>Contact customer support.</li> </ul>

Problem	Possible causes	Recommended actions
Erratic non-zero flow rate when flow is steady	<ul> <li>Two-phase flow</li> <li>Damping value too low</li> <li>Plugged or coated sensor tube</li> <li>Output wiring problem</li> <li>Problem with receiving device</li> <li>Wiring problem</li> </ul>	<ul> <li>Verify that the sensor orientation is appropriate for your application (refer to the sensor installation manual).</li> <li>Check the drive gain and the pickoff voltage.</li> <li>If the wiring between the sensor and the transmitter includes a 9-wire segment, verify that the 9-wire cable shields are correctly grounded.</li> <li>Check for air entrainment, tube fouling, flashing, or tube damage.</li> <li>Check the wiring between the sensor and the transmitter.</li> <li>For sensors with a junction box, check for moisture in the junction box.</li> <li>Purge the sensor tubes.</li> <li>Check for open or leaking valves or seals.</li> <li>Check for sources of vibration.</li> <li>Verify damping configuration.</li> <li>Verify that the measurement units are configured correctly for your application.</li> <li>Check for two-phase flow.</li> <li>Check for radio frequency interference.</li> <li>Contact customer support.</li> </ul>
Inaccurate flow rate or batch total	<ul> <li>Wiring problem</li> <li>Inappropriate measurement unit</li> <li>Incorrect flow calibration factor</li> <li>Incorrect meter factor</li> <li>Incorrect density calibration factors</li> <li>Incorrect grounding</li> <li>Two-phase flow</li> <li>Problem with receiving device</li> <li>Incorrect sensor zero</li> </ul>	<ul> <li>Check the wiring between the sensor and the transmitter.</li> <li>Verify that the measurement units are configured correctly for your application.</li> <li>Verify all of the characterization or calibration parameters. See the sensor tag or the calibration sheet for your meter.</li> <li>Perform a bucket test to verify batch totals.</li> <li>Zero the meter.</li> <li>Check the grounding of all components.</li> <li>Check for two-phase flow.</li> <li>Verify the receiving device, and the wiring between the transmitter and the receiving device.</li> <li>Check sensor coil resistance and for shorts to case.</li> <li>Replace the core processor or transmitter.</li> </ul>

# 10.4 Density measurement problems

Problem	Possible causes	Recommended actions
Inaccurate density reading	<ul> <li>Problem with process fluid</li> <li>Incorrect density calibration factors</li> <li>Wiring problem</li> <li>Incorrect grounding</li> <li>Two-phase flow</li> <li>Plugged or coated sensor tube</li> <li>Incorrect sensor orientation</li> <li>RTD failure</li> <li>Physical characteristics of sensor have changed</li> </ul>	<ul> <li>Check your process conditions against the values reported by the device.</li> <li>Ensure that all of the calibration parameters have been entered correctly. See the sensor tag or the calibration sheet for your meter.</li> <li>Check the wiring between the sensor and the transmitter.</li> <li>Check the grounding of all components.</li> <li>Verify all of the characterization or calibration parameters. See the sensor tag or the calibration sheet for your meter.</li> <li>Check for two-phase flow.</li> <li>If two sensors with similar frequency are too near each other, separate them.</li> <li>Purge the sensor tubes.</li> </ul>
Unusually high density reading	<ul> <li>Plugged or coated sensor tube</li> <li>Incorrect density calibration factors</li> <li>Incorrect temperature measurement</li> <li>RTD problem</li> <li>In high-frequency meters, this can indicate erosion or corrosion</li> <li>In low-frequency meters, this can indicate tube fouling</li> </ul>	<ul> <li>Ensure that all of the calibration parameters have been entered correctly. See the sensor tag or the calibration sheet for your meter.</li> <li>Verify all of the characterization or calibration parameters. See the sensor tag or the calibration sheet for your meter.</li> <li>Purge the sensor tubes.</li> <li>Check for coating in the flow tubes.</li> </ul>
Unusually low density reading	<ul> <li>Two-phase flow</li> <li>Ensure that all of the calibration parameters have been entered correctly. See the sensor tag or the calibration sheet for your meter.</li> <li>In low-frequency meters, this can indicate erosion or corrosion</li> </ul>	<ul> <li>Check your process conditions against the values reported by the device.</li> <li>Check for two-phase flow.</li> <li>Verify all of the characterization or calibration parameters. See the sensor tag or the calibration sheet for your meter.</li> <li>Check the wiring between the sensor and the transmitter.</li> <li>Check for tube erosion, especially if the process fluid is abrasive.</li> </ul>

# 10.5 Temperature measurement problems

Problem	Possible causes	Recommended actions
Temperature reading significantly different from process temperature	<ul> <li>RTD failure</li> <li>Incorrect compensation factors</li> <li>Line temperature in bypass does not match temperature in main line</li> </ul>	<ul> <li>Check junction box for moisture or verdigris.</li> <li>Perform RTD resistance checks and check for shorts to case (see Section 10.27.1).</li> <li>Verify that the temperature compensation factors match the value on the sensor tag or calibration sheet.</li> <li>If Alert A004, A016, or A017 is active, perform the actions recommended for that alert.</li> </ul>
Temperature reading slightly different from process temperature	Sensor temperature not yet equalized     Sensor leaking heat	<ul> <li>If the error is within the temperature specification for the sensor, there is no problem. If the temperature measurement is outside the specification, contact customer support.</li> <li>The temperature of the fluid may be changing rapidly. Allow sufficient time for the sensor to equalize with the process fluid.</li> <li>Perform RTD resistance checks and check for shorts to case (see Section 10.27.1).</li> <li>The electrical connection between the RTD and the sensor may be damaged. This may require replacing the sensor.</li> </ul>
Inaccurate tempera- ture data from exter- nal device	<ul> <li>Wiring problem</li> <li>Problem with input configuration</li> <li>Problem with external device</li> <li>Problem with input configuration</li> </ul>	<ul> <li>Verify the wiring between the transmitter and the external device.</li> <li>Verify that the external device is operating correctly.</li> <li>Verify the configuration of the temperature input.</li> <li>Ensure that both devices are using the same measurement unit.</li> </ul>

# 10.6 Milliamp output problems

Table 10-2: Milliamp output problems and recommended actions

Problem	Possible causes	Recommended actions
No mA Output	<ul> <li>Wiring problem</li> <li>Circuit failure</li> <li>Channel not configured for desired output</li> </ul>	<ul> <li>Check the power supply and power supply wiring.</li> <li>Verify the output wiring.</li> <li>Check the Fault Action settings.</li> <li>Contact customer support.</li> </ul>
Loop test failed	<ul> <li>Power supply problem</li> <li>Wiring problem</li> <li>Circuit failure</li> <li>Channel not configured for desired output</li> <li>Incorrect internal/external power configuration</li> </ul>	<ul> <li>Check the power supply and power supply wiring.</li> <li>Verify the output wiring.</li> <li>Check the Fault Action settings.</li> <li>Verify channel configuration for the affected mA Output.</li> <li>Contact customer support.</li> </ul>
mA Output below 4 mA	<ul> <li>Open in wiring</li> <li>Bad output circuit</li> <li>Process condition below LRV</li> <li>LRV and URV are not set correctly</li> <li>Fault condition if Fault Action is set to Internal Zero or Downscale</li> <li>Bad mA receiving device</li> </ul>	<ul> <li>Check your process conditions against the values reported by the device.</li> <li>Verify the receiving device, and the wiring between the transmitter and the receiving device.</li> <li>Check the settings of Upper Range Value and Lower Range Value.</li> <li>Check the Fault Action settings.</li> </ul>
Constant mA Output	<ul> <li>Incorrect process variable assigned to the output</li> <li>Fault condition exists</li> <li>Non-zero HART address (mA Output 1)</li> <li>Output is configured for loop test mode</li> <li>Zero calibration failure</li> <li>Output is configured for a range that is far in excess of intended range. Reconfigure output.</li> <li>The process condition is below cutoff.</li> </ul>	<ul> <li>Verify the output variable assignments.</li> <li>View and resolve any existing alert conditions.</li> <li>Check the HART address. If the HART address is non-zero, you may need to change the setting of mA Output Action.</li> <li>Check to see if a loop test is in process (the output is fixed).</li> <li>Check HART burst mode configuration.</li> <li>If related to a zero calibration failure, cycle power to the meter and retry the zeroing procedure.</li> <li>Process condition is below cutoff. Check and adjust the cutoff setting.</li> </ul>
mA Output consis- tently out of range	<ul> <li>Incorrect process variable or units assigned to output</li> <li>Fault condition if Fault Action is set to Upscale or Downscale</li> <li>LRV and URV are not set correctly</li> </ul>	<ul> <li>Verify the output variable assignments.</li> <li>Verify the measurement units configured for the output.</li> <li>Check the Fault Action settings.</li> <li>Check the settings of Upper Range Value and Lower Range Value.</li> <li>Check the mA Output trim.</li> </ul>

Table 10-2: Milliamp output problems and recommended actions (continued)

Problem	Possible causes	Recommended actions
Consistently incorrect mA measurement	<ul> <li>Loop problem</li> <li>Output not trimmed correctly</li> <li>Incorrect measurement unit configured for process variable</li> <li>Incorrect process variable configured</li> <li>LRV and URV are not set correctly</li> </ul>	<ul> <li>Check the mA Output trim.</li> <li>Verify that the measurement units are configured correctly for your application.</li> <li>Verify the process variable assigned to the mA Output.</li> <li>Check the settings of Upper Range Value and Lower Range Value.</li> </ul>
mA Output correct at lower current, but in- correct at higher cur- rent	mA loop resistance may be set too high	<ul> <li>Verify that the mA Output load resistance is below the maximum supported load (see the installation manual for your transmitter).</li> </ul>

# 10.7 Frequency Output problems

Table 10-3: Frequency Output problems and recommended actions

Table 10-5: Frequency Output problems and recommended actions		
Problem	Possible causes	Recommended actions
No Frequency Output	<ul> <li>Stopped totalizer</li> <li>Process condition below cutoff</li> <li>Fault condition if Fault Action is set to Internal Zero or Downscale</li> <li>Two-phase flow</li> <li>Flow in reverse direction from configured flow direction parameter</li> <li>Bad frequency receiving device</li> <li>Output level not compatible with receiving device</li> <li>Bad output circuit</li> <li>Incorrect internal/external power configuration</li> <li>Wiring problem</li> </ul>	<ul> <li>Verify that the process conditions are below the low-flow cutoff. Reconfigure the low-flow cutoff if necessary.</li> <li>Check the Fault Action settings.</li> <li>Verify that the totalizers are not stopped. A stopped totalizer will cause the Frequency Output to be locked.</li> <li>Check for two-phase flow.</li> <li>Check flow direction.</li> <li>Verify the receiving device, and the wiring between the transmitter and the receiving device.</li> <li>Verify that the channel is wired and configured as a Frequency Output.</li> <li>Perform a loop test.</li> </ul>
Consistently incorrect frequency measurement	<ul> <li>Output not scaled correctly</li> <li>Incorrect measurement unit configured for process variable</li> </ul>	<ul><li>Check the Frequency Output scaling.</li><li>Verify that the measurement units are configured correctly for your application.</li></ul>
Erratic Frequency Output	Radio frequency interference (RFI) from environment	Check for radio frequency interference.

## 10.8 Using sensor simulation for troubleshooting

When sensor simulation is enabled, the transmitter reports user-specified values for basic process variables. This allows you to reproduce various process conditions or to test the system.

You can use sensor simulation to help distinguish between legitimate process noise and externally caused variation. For example, consider a receiving device that reports an unexpectedly erratic density value. If sensor simulation is enabled and the observed density value does not match the simulated value, the source of the problem is likely to be somewhere between the transmitter and the receiving device.

Sensor simulation requires an Enhanced Core and a communication device.

#### **Important**

When sensor simulation is active, the simulated value is used in all transmitter outputs and calculations, including totals and inventories, volume flow calculations, and concentration calculations. Disable all automatic functions related to the transmitter outputs and place the loop in manual operation. Do not enable simulation mode unless your application can tolerate these effects, and be sure to disable simulation mode when you have finished testing.

# 10.9 Check power supply wiring

If the power supply wiring is damaged or improperly connected, the transmitter may not receive enough power to operate properly.

#### **Prerequisites**

- You will need the installation manual for your transmitter.
- When using DC power, a minimum of 1.5 amps of startup current is required.

#### **Procedure**

- Use a voltmeter to test the voltage at the transmitter's power supply terminals.
  - If the voltage is within the specified range, you do not have a power supply problem.
  - If the voltage is low, ensure that the power supply is adequate at the source, the
    power cable is sized correctly, there is no damage to the power cable, and an
    appropriate fuse is installed.
  - If there is no power, continue with this procedure.
- 2. Before inspecting the power supply wiring, disconnect the power source.

#### **A** CAUTION!

If the transmitter is in a hazardous area, wait five minutes after disconnecting the power.

3. Ensure that the terminals, wires, and wiring compartment are clean and dry.

- 4. Ensure that the power supply wires are connected to the correct terminals.
- 5. Ensure that the power supply wires are making good contact, and are not clamped to the wire insulation.
- 6. Inspect the voltage label inside the wiring compartment.

The voltage supplied to the transmitter should match the voltage specified on the label.

7. Reapply power to the transmitter.

#### **A** CAUTION!

If the transmitter is in a hazardous area, do not reapply power to the transmitter with the housing cover removed. Reapplying power to the transmitter while the housing cover is removed could cause an explosion.

8. Test the voltage at the terminals.

If there is no power, contact customer service.

## 10.10 Check sensor-to-transmitter wiring

A number of power-supply and output problems may occur if the wiring between the sensor and the transmitter is improperly connected, or if the wiring becomes damaged.

Be sure to check all wiring segments:

- If you have a 4-wire transmitter, check the wiring between the transmitter and the core processor.
- If you have a 9-wire transmitter, check the wiring between the transmitter and the sensor junction box.
- If you have a remote transmitter with remote core processor, check the wiring between the transmitter and the core processor and the wiring between the core processor and the sensor junction box.

#### **Prerequisites**

You will need the installation manual for your transmitter.

#### **Procedure**

1. Before opening the wiring compartments, disconnect the power source.

#### **A** DANGER!

If the transmitter is in a hazardous area, wait five minutes after disconnecting the power.

2. Verify that the transmitter is connected to the sensor according to the information provided in your transmitter installation manual.

- 3. Verify that the wires are making good contact with the terminals.
- 4. Check the continuity of all wires from the transmitter to the sensor.

## 10.11 Check grounding

A sensor and the transmitter must be grounded. If the core processor is installed as part of the transmitter or the sensor, it is grounded automatically. If the core processor is installed separately, it must be grounded separately.

#### **Prerequisites**

You will need an:

- Installation manual for your sensor
- Installation manual for your transmitter (remote-mount installations only)

#### **Procedure**

Refer to the sensor and transmitter installation manuals for grounding requirements and instructions.

# 10.12 Perform loop tests

A loop test is a way to verify that the transmitter and the remote device are communicating properly. A loop test also helps you know whether you need to trim mA Outputs.

#### **Prerequisites**

• Follow appropriate procedures to ensure that loop testing will not interfere with existing measurement and control loops.

### 10.12.1 Perform loop tests using the display

#### **Prerequisites**

Before performing a loop test, configure the channels for the transmitter inputs and outputs that will be used in your application.

Follow appropriate procedures to ensure that loop testing will not interfere with existing measurement and control loops.

#### **Procedure**

- Test the mA Output(s).
  - a. Choose and select a low value, e.g., 4 mA.

Dots traverse the display while the output is fixed.

b. Read the mA current at the receiving device and compare it to the transmitter output.

The readings do not need to match exactly. If the values are slightly different, you can correct the discrepancy by trimming the output.

- c. At the transmitter, activate **Select**.
- d. Scroll to and select a high value, e.g., 20 mA.

Dots traverse the display while the output is fixed.

e. Read the mA current at the receiving device and compare it to the transmitter output.

The readings do not need to match exactly. If the values are slightly different, you can correct the discrepancy by trimming the output.

- f. At the transmitter, activate **Select**.
- 2. Test the Frequency Output(s).
  - a. Choose **OFFLINE MAINT > SIM > FO SIM**, and select the Frequency Output value.

The Frequency Output can be set to 1, 10, or 15 kHz.

#### Note

If the Weights & Measures application with NTEP approval is enabled on the transmitter, it is not possible to perform a loop test of the Frequency Output, even when the transmitter is unsecured.

Dots traverse the display while the output is fixed.

- b. Read the frequency signal at the receiving device and compare it to the transmitter output.
- c. At the transmitter, activate **Select**.
- 3. Test the Discrete Output(s).
  - a. Choose OFFLINE MAINT > SIM > DO SIM, and select SET ON.

Dots traverse the display while the output is fixed.

- b. Verify the signal at the receiving device.
- c. At the transmitter, activate Select.
- d. Scroll to and select SET OFF.
- e. Verify the signal at the receiving device.
- f. At the transmitter, activate **Select**.

#### **Postrequisites**

- If the mA Output readings are within 20 microamps of the expected values, you can correct this discrepancy by trimming the output.
- If the discrepancy between the mA Output readings is greater than 20 microamps, or if at any step the reading was faulty, verify the wiring between the transmitter and the remote device, and try again.

### 10.12.2 Perform loop tests using ProLink III

#### **Prerequisites**

Before performing a loop test, configure the channels for the transmitter inputs and outputs that will be used in your application.

Follow appropriate procedures to ensure that loop testing will not interfere with existing measurement and control loops.

#### **Procedure**

- 1. Test the mA Output(s).
  - a. Choose Device Tools > Diagnostics > Testing > mA Output Test.
  - b. Enter 4 in **Fix to:**.
  - c. Click Fix mA.
  - d. Read the mA current at the receiving device and compare it to the transmitter output.

The readings do not need to match exactly. If the values are slightly different, you can correct the discrepancy by trimming the output.

- e. Click **UnFix mA**.
- f. Enter 20 in Fix to:.
- g. Click **Fix mA**.
- h. Read the mA current at the receiving device and compare it to the transmitter output.

The readings do not need to match exactly. If the values are slightly different, you can correct the discrepancy by trimming the output.

- i. Click UnFix mA.
- 2. Test the Frequency Output(s).
  - a. Choose Device Tools > Diagnostics > Testing > Frequency Output Test.
  - b. Enter the Frequency Output value in Fix to.
  - c. Click Fix FO.
  - d. Read the frequency signal at the receiving device and compare it to the transmitter output.

- e. Click UnFix FO.
- 3. Test the Discrete Output(s).
  - a. Choose Device Tools > Diagnostics > Testing > Discrete Output Test.
  - b. Set **Fix To:** to ON.
  - c. Verify the signal at the receiving device.
  - d. Set Fix To: to OFF.
  - e. Verify the signal at the receiving device.
  - f. Click UnFix.

#### **Postrequisites**

- If the mA Output readings are within 20 microamps of the expected values, you can correct this discrepancy by trimming the output.
- If the discrepancy between the mA Output readings is greater than 20 microamps, or if at any step the reading was faulty, verify the wiring between the transmitter and the remote device, and try again.

### 10.12.3 Perform loop tests using the Field Communicator

#### **Prerequisites**

Before performing a loop test, configure the channels for the transmitter inputs and outputs that will be used in your application.

Follow appropriate procedures to ensure that loop testing will not interfere with existing measurement and control loops.

#### **Procedure**

- 1. Test the mA Output(s).
  - a. Choose Service Tools > Simulate > Simulate Outputs > mA Output Loop Test and select 4 mA.
  - b. Read the mA current at the receiving device and compare it to the transmitter output.

The readings do not need to match exactly. If the values are slightly different, you can correct the discrepancy by trimming the output.

- c. Press OK.
- d. Select 20 mA.
- e. Read the mA current at the receiving device and compare it to the transmitter output.

The readings do not need to match exactly. If the values are slightly different, you can correct the discrepancy by trimming the output.

f. Press OK.

- q. Choose **End**.
- 2. Test the Frequency Output(s).

#### Note

If the Weights & Measures application with NTEP approval is enabled on the transmitter, it is not possible to perform a loop test of the Frequency Output, even when the transmitter is unsecured.

- a. Press Service Tools > Simulate > Simulate Outputs > Frequency Output Test, and choose the Frequency Output level.
- b. Read the frequency signal at the receiving device and compare it to the transmitter output.
- c. Choose **End**.
- 3. Test the Discrete Output(s).
  - a. Press Service Tools > Simulate > Simulate Outputs > Discrete Output Test.
  - b. Choose Off.
  - c. Verify the signal at the receiving device.
  - d. Press OK.
  - e. Choose **On**.
  - f. Verify the signal at the receiving device.
  - g. Press OK.
  - h. Choose End.

#### **Postrequisites**

- If the mA Output readings are within 20 microamps of the expected values, you can correct this discrepancy by trimming the output.
- If the discrepancy between the mA Output readings is greater than 20 microamps, or if at any step the reading was faulty, verify the wiring between the transmitter and the remote device, and try again.

## 10.13 Check the HART communication loop

If you cannot establish or maintain HART communications, the HART loop may be wired incorrectly.

#### **Prerequisites**

You will need:

- A copy of your transmitter installation manual
- A 250–600 Ω resistor
- A Field Communicator

Optional: the HART Application Guide, available at www.hartcomm.org

#### **Procedure**

1. Verify that the loop wires are connected as shown in the wiring diagrams in the transmitter installation manual.

If your HART network is more complex than the wiring diagrams in the transmitter installation manual, contact either customer service or the HART Communication Foundation.

- 2. Disconnect the primary mA Output wiring from the transmitter.
- 3. Install a 250–600  $\Omega$  resistor across the transmitter's primary mA Output terminals.
- 4. Check the voltage drop across the resistor (4–20 mA = 1–5 VDC for a 250  $\Omega$  resistor).

If voltage drop is less than 1 VDC, add resistance to achieve a voltage drop of greater than 1 VDC .

5. Connect a Field Communicator directly across the resistor and attempt to communicate (poll).

If communication with the transmitter cannot be established, the transmitter may need service. Contact customer service.

# 10.14 Check HART Address and mA Output Action

If the transmitter is producing a fixed current from the mA Output, the **mA Output Action** parameter may be set incorrectly.

When the **mA** Output Action parameter is set to Fixed, the mA Output produces a fixed value, and does not report process data or implement its fault action.

When **HART Address** is changed, some configuration tools will automatically change **mA Output Action**.

#### Tip

Always verify **mA Output Action** after setting or changing **HART Address**.

#### **Procedure**

1. Set **HART Address** as appropriate for your HART network.

The default address is 0. This is the recommended value unless the transmitter is in a multidrop network.

2. Set **mA Output Action** to Live.

## 10.15 Check HART burst mode

HART burst mode is normally disabled, and should be enabled only if a HART Triloop is being used.

- 1. Check to see if burst mode is enabled or disabled.
- 2. If burst mode is enabled, disable it.

## 10.16 Check the trimming of the mA Output

If the trim values for the mA Output are inaccurate, the transmitter will under-compensate or over-compensate the output.

- 1. Trim the output, following the standard procedure.
- 2. If this does not correct the problem, contact customer support.

## 10.17 Check Lower Range Value and Upper Range Value

If the process variable assigned to the mA Output falls below the configured **Lower Range Value** (LRV) or rises above the configured **Upper Range Value** (URV), the meter will post a saturation alert (A100), then perform the configured fault action.

- 1. Record your current process conditions.
- 2. Check the configuration of the LRV and URV.

## 10.18 Check mA Output Fault Action

**mA** Output Fault Action controls the behavior of the mA Output if the transmitter encounters an internal fault condition. If the mA Output is reporting a constant value below 4 mA or above 20 mA, the transmitter may be in a fault condition.

- 1. Check the status alerts for active fault conditions.
- 2. If there are active fault conditions, the transmitter is performing correctly. If you want to change its behavior, consider the following options:
  - Change the setting of mA Output Fault Action.
  - For the relevant status alerts, change the setting of Alert Severity to Ignore.

#### Restriction

For some status alerts, **Alert Severity** is not configurable.

3. If there are no active fault conditions, continue troubleshooting.

## 10.19 Check for radio frequency interference (RFI)

The transmitter's Frequency Output or Discrete Output can be affected by radio frequency interference (RFI). Possible sources of RFI include a source of radio emissions, or a large transformer, pump, or motor that can generate a strong electromagnetic field. Several methods to reduce RFI are available. Use one or more of the following suggestions, as appropriate to your installation.

#### **Procedure**

- Use shielded cable between the output and the receiving device.
  - Terminate the shielding at the receiving device. If this is impossible, terminate the shielding at the cable gland or conduit fitting.
  - Do not terminate the shielding inside the wiring compartment.
  - 360-degree termination of shielding is unnecessary.
- Eliminate the RFI source.
- Move the transmitter.

## 10.20 Check Frequency Output Scaling Method

If **Frequency Output Scaling Method** is set incorrectly, the Frequency Output may report an incorrect value.

- 1. Verify the configuration of the Frequency Output.
- 2. If you changed the setting of **Frequency Output Scaling Method**, check the settings of all other Frequency Output parameters.

## 10.21 Check Frequency Output Fault Action

The **Frequency Output Fault Action** controls the behavior of the Frequency Output if the transmitter encounters an internal fault condition. If the Frequency Output is reporting a constant value, the transmitter may be in a fault condition.

- 1. Check the status alerts for active fault conditions.
- 2. If there are active fault conditions, the transmitter is performing correctly. If you want to change its behavior, consider the following options:
  - Change the setting of Frequency Output Fault Action.
  - For the relevant status alerts, change the setting of Alert Severity to Ignore.

#### Restriction

For some status alerts, **Alert Severity** is not configurable.

3. If there are no active fault conditions, continue troubleshooting.

## 10.22 Check Flow Direction

If **Flow Direction** is set inappropriately for your process, the transmitter may report flow data that is not appropriate for your requirements.

The **Flow Direction** parameter interacts with actual flow direction to affect flow values, flow totals and inventories, and output behavior. For the simplest operation, actual process flow should match the flow arrow that is on the side of the sensor case.

#### **Procedure**

- 1. Verify the actual direction of process flow through the sensor.
- 2. Verify the configuration of Flow Direction.

## 10.23 Check the cutoffs

If the transmitter cutoffs are configured incorrectly, the transmitter may report zero flow when flow is present, or very small amounts of flow under no-flow conditions.

There are separate cutoff parameters for mass flow rate, volume flow rate, gas standard volume flow rate (if applicable), and density. There is an independent cutoff for the mA Output on your transmitter. The interaction between cutoffs sometimes produces unexpected results.

#### **Procedure**

Verify the configuration of all cutoffs.

#### Tip

For typical applications, set **Mass Flow Cutoff** to 0.5% of the nominal flow rate of the attached sensor. See the sensor specifications for nominal flow rate data.

## 10.24 Check for two-phase flow (slug flow)

Two-phase flow can cause rapid changes in the drive gain. This can cause a variety of measurement issues.

1. Check for two-phase flow alerts (e.g., A105).

If the transmitter is not generating two-phase flow alerts, verify that two-phase flow limits have been set. If limits are set, two-phase flow is not the source of your problem.

- 2. Check the process for cavitation, flashing, or leaks.
- 3. Monitor the density of your process fluid output under normal process conditions.
- 4. Check the settings of **Two-Phase Flow Low Limit**, **Two-Phase Flow High Limit**, and **Two-Phase Flow Timeout**.

#### Tip

You can reduce the occurrence of two-phase flow alerts by setting **Two-Phase Flow Low Limit** to a lower value, **Two-Phase Flow High Limit** to a higher value, or **Two-Phase Flow Timeout** to a higher value. Micro Motion recommends leaving the **Two-Phase Flow High Limit** at the default value.

## 10.25 Check the drive gain

Excessive or erratic drive gain may indicate any of a variety of process conditions or sensor problems.

To know whether your drive gain is excessive or erratic, you must collect drive gain data during the problem condition and compare it to drive gain data from a period of normal operation.

#### Excessive (saturated) drive gain

Table 10-4: Possible causes and recommended actions for excessive (saturated) drive gain

Possible cause	Recommended actions
Bent sensor tube	Check the pickoff voltages (see Section 10.26). If either of them are close to zero (but neither is zero), the sensor tubes may be bent. The sensor will need to be replaced.
Cavitation or flash- ing; settling of two- phase or three-phase fluids	<ul> <li>Increase the inlet or back pressure at the sensor.</li> <li>If a pump is located upstream from the sensor, increase the distance between the pump and sensor.</li> <li>The sensor may need to be reoriented or repositioned. Consult the installation manual for your sensor.</li> </ul>
Cracked sensor tube	Replace the sensor.
Core processor or module failure	Contact customer support.
Flow rate out of range	Ensure that the flow rate is within sensor limits.
Incorrect sensor characterization	Verify the characterization or calibration parameters.
Open drive or pickoff sensor coil	Contact customer support.
Over-pressurized tubes	Contact customer support.
Plugged sensor tube	Check the pickoff voltages (see Section 10.26). If either of them are close to zero (but neither is zero), plugged tubes may be the source of your problem. Purge the tubes. In extreme cases, you may need to replace the sensor.
Sensor case full of process fluid	Replace the sensor.

Table 10-4: Possible causes and recommended actions for excessive (saturated) drive gain (continued)

Possible cause	Recommended actions
Sensor imbalance	Contact customer support.
Sensor tubes not completely full	Correct process conditions so that the sensor tubes are full.
Two-phase flow	Check for two-phase flow. See Section 10.24.
Vibrating element not free to vibrate	Ensure that the vibrating element is free to vibrate.

#### **Erratic drive gain**

Table 10-5: Possible causes and recommended actions for erratic drive gain

Possible cause	Recommended actions	
Two-phase flow	Check for two-phase flow. See Section 10.24.	
Polarity of pick-off reversed or polarity of drive reversed	Applicable for a 9-wire sensor. Check the wiring between the sensor and the transmitter.	
Foreign material caught in sensor tubes	<ul><li>Purge the sensor tubes.</li><li>Replace the sensor.</li></ul>	

## 10.25.1 Collect drive gain data

Drive gain data can be used to diagnose a variety of process and equipment conditions. Collect drive gain data from a period of normal operation, and use this data as a baseline for troubleshooting.

#### **Procedure**

- 1. Navigate to the drive gain data.
- 2. Observe and record drive gain data over an appropriate period of time, under a variety of process conditions.

## 10.26 Check the pickoff voltage

If the pickoff voltage readings are unusually low, you may have any of a variety of process or equipment problems.

To know whether your pickoff voltage is unusually low, you must collect pickoff voltage data during the problem condition and compare it to pickoff voltage data from a period of normal operation.

Drive gain and pickoff voltage are inversely proportional. As drive gain increases, pickoff voltages decrease and vice versa.

Table 10-6: Possible causes and recommended actions for low pickoff voltage

B 41		
Possible cause	Recommended actions	
Cavitation or flashing; settling of two-phase or three-phase fluids	<ul> <li>Increase the inlet or back pressure at the sensor. Increasing back pressure is recommended. Applying back pressure downstream from the sensor can prevent flashing inside the sensor tubes. That way, if the process fluid is going to flash, it will do so downstream from the sensor after it has been measured.</li> <li>If a pump is located upstream from the sensor, increase the distance between the pump and sensor.</li> <li>The sensor may need to be reoriented or repositioned. Consult the installation manual for your sensor.</li> </ul>	
Faulty wiring runs between the sensor and transmitter	Verify wiring between sensor and transmitter.	
Process flow rate beyond the limits of the sensor	Verify that the process flow rate is not out of range of the sensor.	
Two-phase flow	Check for two-phase flow. See Section 10.24.	
The vibrating element is not vibrating	<ul> <li>Check for plugging or deposition.</li> <li>Ensure that the vibrating element is free to vibrate (no mechanical binding).</li> <li>Verify wiring.</li> <li>Test coils at sensor. See Section 10.27.1.</li> </ul>	
Moisture in the sensor electronics	Eliminate the moisture in the sensor electronics.	
The sensor is damaged, or sensor magnets may have become demagnetized	Replace the sensor.	

## 10.26.1 Collect pickoff voltage data

Pickoff voltage data can be used to diagnose a variety of process and equipment conditions. Collect pickoff voltage data from a period of normal operation, and use this data as a baseline for troubleshooting.

#### **Procedure**

- 1. Navigate to the pickoff voltage data.
- 2. Observe and record data for both the left pickoff and the right pickoff, over an appropriate period of time, under a variety of process conditions.

## 10.27 Check for internal electrical problems

Shorts between sensor terminals or between the sensor terminals and the sensor case can cause the sensor to stop working.

Possible cause	Recommended action	
Moisture inside the sensor junction box	Ensure that the junction box is dry and no corrosion is present.	
Liquid or moisture inside the sensor case	Contact customer support.	
Internally shorted feedthrough	Contact customer support.	
Faulty cable	Replace the cable.	
Improper wire termination	Verify wire terminations inside the sensor junction box. See the Micro Motion document titled, 9-Wire Flowmeter Cable Preparation and Installation Guide.	

## 10.27.1 Check the sensor coils

Checking the sensor coils can identify a cause for a no sensor response alert.

#### Restriction

This procedure applies only to 9-wire remote-mount transmitters and remote transmitters with remote core processors.

#### **Procedure**

1. Disconnect power to the transmitter.

#### **A** DANGER!

If the transmitter is in a hazardous area, wait 5 minutes before continuing.

- 2. Remove the end-cap from the core processor housing.
- 3. Unplug the terminal blocks from the terminal board on the core processor.
- 4. Using a digital multimeter (DMM), check the pickoff coils by placing the DMM leads on the unplugged terminal blocks for each terminal pair. See the following table for a list of the coils. Record the values.

Table 10-7: Coils and test terminal pairs

Coil	Sensor model	Terminal colors
Drive coil	All	Brown to red
Left pickoff coil (LPO)	All	Green to white
Right pickoff coil (RPO)	All	Blue to gray
Resistance temperature detector (RTD)	All	Yellow to violet
Lead length compensator (LLC)	All except T-Series and CMF400 (see note)	Yellow to orange

Table 10-7: Coils and test terminal pairs (continued)

Coil	Sensor model	Terminal colors
Composite RTD	All CMFSs, T-Series, H300, and F300	Yellow to orange
Fixed resistor (see note)	CMFS007, CMFS010, CMFS015, CMF400, and F300	Yellow to orange

#### Note

The F300/H300/CMF400 fixed resistor applies to only certain specific sensor releases. Contact customer support for more information.

There should be no open circuits, that is, no infinite resistance readings. The left pickoff and right pickoff readings should be the same or very close ( $\pm 5~\Omega$ ). If there are any unusual readings, repeat the coil resistance tests at the sensor junction box to eliminate the possibility of faulty cable. The readings for each coil pair should match at both ends.

5. Test the terminals in the sensor junction box for shorts to case.

Test results will be inconclusive with nonconductive process fluids such as hydrocarbons.

- a. Leave the terminal blocks disconnected.
- b. Remove the lid of the junction box.
- c. Testing one terminal at a time, place a DMM lead on the terminal and the other lead on the sensor case.

With the DMM set to its highest range, there should be infinite resistance on each lead. If there is any resistance at all, there is a short to case.

- 6. Test the resistance of junction box terminal pairs.
  - a. Test the brown terminal against all other terminals except the red one.
  - b. Test the red terminal against all other terminals except the brown one.
  - c. Test the green terminal against all other terminals except the white one.
  - d. Test the white terminal against all other terminals except the green one.
  - e. Test the blue terminal against all other terminals except the gray one.
  - f. Test the gray terminal against all other terminals except the blue one.
  - g. Test the orange terminal against all other terminals except the yellow and violet ones.
  - h. Test the yellow terminal against all other terminals except the orange and violet ones.
  - i. Test the violet terminal against all other terminals except the yellow and orange ones.

There should be infinite resistance for each pair. If there is any resistance at all, there is a short between terminals.

#### **Postrequisites**

To return to normal operation:

- 1. Plug the terminal blocks into the terminal board.
- 2. Replace the end-cap on the core processor housing.
- 3. Replace the lid on the sensor junction box.

#### **Important**

When reassembling the meter components, be sure to grease all O-rings.

## 10.28 Check the core processor LED

The core processor has an LED that indicates different meter conditions.

- 1. Maintain power to the transmitter.
- 2. If you have a 4-wire remote installation or a remote core processor with remote transmitter installation:
  - a. Remove the core processor lid. The core processor is intrinsically safe and can be opened in all environments.
  - b. Check the state of the core processor LED.
- 3. If you have an integral installation:
  - a. Loosen the four cap screws that fasten the transmitter to the base.




Figure 10-1: Integral installation components

- A. Transmitter
- B. Transition ring
- C. 4 x cap screws (4 mm)
- D. Base
- E. Core processor
- b. Rotate the transmitter counter-clockwise so that the cap screws are in the unlocked position.
- c. Gently lift the transmitter straight up, disengaging it from the cap screws.

#### **Important**

Do not disconnect or damage the wires that connect the transmitter to the core processor.

- d. Check the state of the core processor LED.
- 4. If you have a 9-wire remote installation:
  - a. Remove the end-cap.




Figure 10-2: 9-wire remote installation components

- A. Transmitter
- B. Core processor
- C. 4 x cap screws (4 mm)
- D. End cap
- b. Inside the core processor housing, loosen the three screws that hold the core processor mounting plate in place.
  - Do not remove the screws.
- c. Rotate the mounting plate so that the screws are in the unlocked position.
- d. Holding the tab on the mounting plate, slowly lower the mounting plate so that the top of the core processor is visible.

#### **Important**

Do not disconnect or damage the wires that connect the transmitter to the core processor.

e. Check the state of the core processor LED.

#### **Postrequisites**

To return to normal operation:

- For a 4-wire remote installation or a remote core processor with remote transmitter installation, replace the core processor lid.
- For an integral installation:
  - 1. Without pinching or stretching the wires, lower the transmitter onto the base, inserting the cap screws into the slots.
  - 2. Rotate the transmitter clockwise so that the cap screws are in the locked position.
  - 3. Tighten the cap screws, torquing to 20 to 30 in-lbs (2.3 to 3.4 N-m.
- For a 9-wire remote installation:
  - 1. Without pinching or stressing the wires, slide the mounting plate into place.
  - 2. Rotate the mounting plate so that the screws are in the locked position.
  - 3. Tighten the screws, torquing to 6 to 8 in-lbs (0.7 to 0.9 N-m.
  - 4. Replace the end-cap.

#### **Important**

When reassembling the meter components, be sure to grease all O-rings.

## 10.28.1 Core processor LED states

**Table 10-8: Standard core processor LED states** 

LED state	Description	Recommended actions
1 flash per second (ON 25%, OFF 75%)	Normal operation	No action required.
1 flash per second (ON 75%, OFF 25%)	Slug flow (two-phase flow)	See Section 10.24.
Solid ON	Zero or calibration in progress	No action required.
	Core processor receiving between 11.5 and 5 volts	Check power supply to transmitter.
3 rapid flashes, followed by	Sensor not recognized	Check wiring between transmitter and sensor.
pause	Improper configuration	Check sensor characterization parameters.
	Broken pin between sensor and core processor	The meter requires factory service.
4 flashes per second	Fault condition	Check alert status.

**Table 10-8: Standard core processor LED states (continued)** 

LED state	Description	Recommended actions
OFF	Core processor receiving less than 5 volts	<ul> <li>Verify power supply wiring to core processor.</li> <li>If transmitter status LED is lit, transmitter is receiving power. Check voltage across terminals 1 (VDC+) and 2 (VDC-) in core processor. If reading is less than 1 VDC, verify power supply wiring to core processor. Wires may be switched.</li> <li>If transmitter status LED is not lit, transmitter is not receiving power. Check power supply. If power supply is operational, internal transmitter, display, or LED failure is possible – the meter may require factory service.</li> </ul>
	Core processor internal failure	The meter requires factory service.

Table 10-9: Enhanced core processor LED states

LED state	Description	Recommended action
Solid green	Normal operation	No action required.
Flashing yellow	Zero in progress	No action required.
Solid yellow	Low-severity alert	Check alert status.
Solid red	High-severity alert	Check alert status.
Flashing red (80% on, 20% off)	Tubes not full	<ul> <li>If alert A105 (slug flow) is active, refer to the recommended actions for that alert.</li> <li>If alert A033 (tubes not full) is active, verify process. Check for air in the flow tubes, tubes not filled, foreign material in tubes, or coating in tubes.</li> </ul>
Flashing red (50% on, 50% off)	Electronics failed	The meter requires factory service.
Flashing red (50% on, 50% off, skips every 4th)	Sensor failed	The meter requires factory service.
OFF	Core processor receiving less than 5 volts	<ul> <li>Verify power supply wiring to core processor.</li> <li>If transmitter status LED is lit, transmitter is receiving power. Check voltage across terminals 1 (VDC+) and 2 (VDC-) in core processor. If reading is less than 1 VDC, verify power supply wiring to core processor. Wires may be switched.</li> <li>If transmitter status LED is not lit, transmitter is not receiving power. Check power supply. If power supply is operational, internal transmitter, display, or LED failure is possible – the meter may require factory service.</li> </ul>

**Table 10-9: Enhanced core processor LED states (continued)** 

LED state	Description	Recommended action
	Core processor internal failure	The meter requires factory service.


## 10.29 Perform a 700 core processor resistance test

#### Note

You can perform a resistance test only on a 700 core processor.

#### **Procedure**


- 1. Power down the transmitter.
- 2. If you have a 4-wire remote installation or a remote core processor with remote transmitter installation, remove the core processor lid.
- 3. If you have an integral installation:
  - a. Loosen the four cap screws that fasten the transmitter to the base.



- A. Transmitter
- B. Transition ring
- C. 4x cap screws (4 mm)
- D. Base
- E. Core processor
- b. Rotate the transmitter counter-clockwise so that the cap screws are in the unlocked position.

- c. Gently lift the transmitter straight up, disengaging it from the cap screws.
- 4. If you have a 9-wire remote installation:
  - a. Remove the end-cap.

Figure 10-3: 9-wire remote installation components



- A. Transmitter
- B. Core processor
- C. 4 x cap screws (4 mm)
- D. End-cap
- b. Inside the core processor housing, loosen the three screws that hold the core processor mounting plate in place.
  - Do not remove the screws.
- c. Rotate the mounting plate so that the screws are in the unlocked position.
- d. Holding the tab on the mounting plate, slowly lower the mounting plate so that the top of the core processor is visible.
- 5. At the core processor, disconnect the 4-wire cable between the core processor and the transmitter.

6. Measure the resistance between core processor terminal pairs 3–4, 2–3, and 2–4.

Terminal pair	Function	Expected resistance
3–4	RS-485/A and RS-485/B	$40 \text{ k}\Omega$ to $50 \text{ k}\Omega$
2–3	VDC– and RS-485/A	20 kΩ to 25 kΩ
2–4	VDC– and RS-485/B	20 kΩ to 25 kΩ

7. If any resistance measurements are lower than specified, the core processor may not be able to communicate with a transmitter or a remote host. The meter may need factory service.

#### **Postrequisites**

To return to normal operation:

- For a 4-wire remote installation or a remote core processor with remote transmitter installation:
  - 1. Reconnect the 4-wire cable between the core processor and the transmitter.
  - 2. Replace the core processor lid.
  - 3. Restore power to the transmitter.
- For an integral installation:
  - 1. Reconnect the 4-wire cable between the core processor and the transmitter.
  - 2. Without pinching or stretching the wires, lower the transmitter onto the base, inserting the cap screws into the slots.
  - 3. Rotate the transmitter clockwise so that the cap screws are in the locked position.
  - 4. Tighten the cap screws, torquing to 20 to 30 in-lbs (2.3 to 3.4 N-m.
  - 5. Restore power to the transmitter.
- For a 9-wire remote installation:
  - 1. Reconnect the 4-wire cable between the core processor and the transmitter.
  - 2. Without pinching or stressing the wires, slide the mounting plate into place.
  - 3. Rotate the mounting plate so that the screws are in the locked position.
  - 4. Tighten the screws, torquing to 6 to 8 in-lbs (0.7 to 0.9 N-m.
  - 5. Replace the end-cap.
  - 6. Restore power to the transmitter.

#### **Important**

When reassembling the meter components, be sure to grease all O-rings.

# Appendix A Using the transmitter display

#### Topics covered in this appendix:

- Components of the transmitter interface
- Use the optical switches
- Access and use the display menu system
- Display codes for process variables
- Codes and abbreviations used in display menus

## A.1 Components of the transmitter interface

The transmitter interface includes the status LED, the display (LCD panel), and two optical switches.

Figure A-1: Transmitter interface

- A. Status LED
- B. Display (LCD panel)
- C. Process variable
- D. **Scroll** optical switch
- E. Optical switch indicator
- F. **Select** optical switch
- G. Unit of measure for process variable
- H. Current value of process variable

## A.2 Use the optical switches

Use the optical switches on the transmitter interface to control the transmitter display. The transmitter has two optical switches: **Scroll** and **Select**.

#### **Procedure**

To activate an optical switch, block the light by holding your thumb or finger in front of the opening.

#### Tip

You can activate the optical switch through the lens. Do not remove the transmitter housing cover.

The optical switch indicator lights up when the transmitter senses that an optical switch has been activated.

Table A-1: Optical switch indicator and optical switch states

Optical switch indicator State of optical switches	
Solid red	One optical switch is activated.
Flickering red	Both optical switches are activated.

## A.3 Access and use the display menu system

The display menu system is used to perform various configuration, administrative, and maintenance tasks.

#### Tip

The display menu system does not provide complete configuration, administrative, or maintenance functions. For complete transmitter management, you must use another communications tool.

#### **Prerequisites**

To access the display menu system, operator access to either the Off-Line menu or the Alert menu must be enabled. To access the complete menu system, operator access must be enabled for both the Off-Line menu and the Alert menu.

#### **Procedure**

1. At the transmitter display, activate the **Scroll** and **Select** optical switches simultaneously until the display changes.

You will enter the Off-Line menu at any of several locations, depending on several factors.

- If an alert is active and access to the Alert menu is enabled, you will see SEE ALARM.
- If no alert is active and Smart Meter Verification is enabled on the transmitter, you will see ENTER METER VERFY.
- If no alert is active and Smart Meter Verification is not enabled on the transmitter, you will see OFF-LINE MAINT.
- 2. If **CODE?** appears on the display when you make a choice, enter the value that is configured for **Off-Line Password**.
  - a. With the cursor flashing on the first digit, activate **Scroll** until the correct digit is displayed, then activate **Select**.
  - b. Repeat this process for the second, third, and fourth digits.

#### Tip

If you do not know the correct value for **Off-Line Password**, wait 30 seconds. The password screen will time out automatically and you will be returned to the previous screen.

- 3. Use the **Scroll** and **Select** optical switches to navigate to your destination in the display menu system.
  - Use **Scroll** to move through a list of options.
  - Use **Select** to choose the current option.
- 4. If **Scroll** flashes on the display, activate the **Scroll** optical switch, then the **Select** optical switch, and then the **Scroll** optical switch again.

The display will prompt you through this sequence. The **Scroll-Select-Scroll** sequence is designed to guard against accidental activation of the off-line menu. It is not designed as a security measure.

- 5. To exit a display menu and return to a higher-level menu:
  - Activate Scroll until the EXIT option is displayed, then activate Select.
  - If the **EXIT** option is not available, activate **Scroll** and **Select** simultaneously and hold until the screen returns to the previous display.
- 6. To exit the display menu system, you can use either of the following methods:
  - Exit each menu separately, working your way back to the top of the menu system.
  - Wait until the display times out and returns to displaying process variable data.

## A.3.1 Enter a floating-point value using the display

Certain configuration values (for example, **Lower Range Value** and **Upper Range Value**) are entered as floating-point values. The display supports both decimal notation and exponential notation for floating-point values.

The display allows you to enter a maximum of 8 characters, including the sign. The decimal point is not counted as a character. Exponential notation is used to enter values that require more than 8 characters.

### Enter a floating-point value using decimal notation

Decimal notation allows you to enter values between –9999999 and 99999999. You can use the decimal point to enter values with a precision of 0 through 4 (4 characters to the right of the decimal point).

Decimal values entered via the display must meet the following requirements:

- They can contain a maximum of 8 digits, or 7 digits plus a minus sign (–) to indicate a negative number.
- They can contain a decimal point. The decimal point does not count as a digit. The
  decimal point must be positioned so that the precision of the value does not exceed
  4.

When you first enter the configuration screen, the current configuration value is displayed in decimal notation, and the active character is flashing. If the value is positive, no sign is displayed. If the value is negative, a minus sign is displayed.

#### **Procedure**

- To change the value:
  - 1. Activate **Select** until the digit you want to change is active (flashing).

**Select** moves the cursor one position to the left. From the leftmost position, **Select** moves the cursor to the rightmost digit.

- 2. Activate **Scroll** to change the value of the active digit.
- 3. Repeat until all digits are set as desired.
- To change the sign of the value:
  - If the current value is negative, activate **Select** until the minus sign is flashing, then activate **Scroll** until the space is blank.
  - If the current value is positive and there is a blank space at the left of the value, activate Select until the cursor is flashing under the blank space, then activate Scroll until the minus sign appears.
  - If the current value is positive and there is no blank space at the left of the value, activate **Select** until the cursor is flashing under the leftmost digit, then activate **Scroll** until the minus sign appears.
- To move the decimal point:
  - 1. Activate **Select** until the decimal point is flashing.
  - 2. Activate Scroll.

The decimal point is removed from its current position.

3. Activate **Select** and watch the position of the decimal point.

As the cursor moves to the left, the decimal point will flash between each pair of digits, up to a maximum precision of four (four digits to the right of the decimal point).

#### Tip

If the position is not valid, the decimal point is not displayed. Continue to activate **Select** until the decimal point appears at the right of the displayed value.

4. When the decimal point is in the desired position, activate **Scroll**.

The decimal point is inserted at its current position.

- To save the displayed value to transmitter memory, activate Scroll and Select simultaneously and hold until the display changes.
  - If the displayed value is the same as the value in transmitter memory, you will be returned to the previous screen.
  - If the displayed value is not the same as the value in transmitter memory, **SAVE/YES?** flashes on the display. Activate **Select**.
- To exit the menu without saving the displayed value to transmitter memory, activate Scroll and Select simultaneously and hold until the display changes.

- If the displayed value is the same as the value in transmitter memory, you will be returned to the previous screen.
- If the displayed value is not the same as the value in transmitter memory, **SAVE/YES?** flashes on the display. Activate **Scroll**.

### Enter a floating-point value using exponential notation

Exponential notation is used to enter values that are larger than 99999999 or smaller than -9999999.

Exponential values entered via the display must be in the following form: SX.XXXEYY. In this string:

- S = Sign. A minus sign (-) indicates a negative number. A blank indicates a positive number.
- X.XXX = The 4-digit mantissa.
- E = The exponent indicator.
- YY = The 2-digit exponent.

#### **Procedure**

- 1. Switch from decimal notation to exponential notation.
  - a. Activate **Select** as required until the rightmost digit is flashing.
  - b. Activate **Scroll** until  $\mathbb{E}$  is displayed.
  - c. Activate Select.

#### Tip

If you have modified the value in decimal notation without saving the changes to transmitter memory, the changes will be lost when you switch to exponential notation. Save the decimal value before switching to exponential notation.

2. Enter the exponent.

The first character may be a minus sign or any digit between 0 and 3. The second character may be any digit between 0 and 9.

- a. Activate **Select** to move the cursor to the rightmost character on the display.
- b. Activate **Scroll** until the desired character is displayed.
- c. Activate **Select** to move the cursor one position to the left.
- d. Activate **Scroll** until the desired character is displayed.
- 3. Enter the mantissa.

The mantissa must be a 4-digit value with a precision of 3 (that is, all values between 0.000 and 9.999).

- a. Activate **Select** to move the cursor to the rightmost digit in the mantissa.
- b. Activate **Scroll** until the desired character is displayed.
- c. Activate **Select** to move the cursor one digit to the left.

- d. Activate **Scroll** until the desired character is displayed.
- e. Activate **Select** to move the cursor one digit to the left.
- f. Activate **Scroll** until the desired character is displayed.
- q. Activate **Select** to move the cursor one digit to the left.
- h. Activate **Scroll** until the desired character is displayed.
- 4. Enter the sign.
  - a. Activate **Select** to move the cursor one digit to the left.
  - b. Activate **Scroll** until the desired character is displayed.

For positive numbers, select a blank space.

- 5. To save the displayed value to transmitter memory, activate **Scroll** and **Select** simultaneously and hold until the display changes.
  - If the displayed value is the same as the value in transmitter memory, you will be returned to the previous screen.
  - If the displayed value is not the same as the value in transmitter memory, SAVE/ YES? flashes on the display. Activate Select.
- 6. Switch back from exponential notation to decimal notation.
  - a. Activate **Select** until the  $\mathbb{E}$  is flashing.
  - b. Activate **Select** until d is displayed.
  - c. Activate Select.

## A.4 Display codes for process variables

Table A-2: Display codes for process variables

Code	Definition	Comment or reference
Couc		Comment of reference
AVE_D	Average density	Petroleum measurement application only
AVE_T	Average temperature	Petroleum measurement application only
BRD_T	Board temperature	
CONC	Concentration	Concentration measurement application only
DRIVE%	Drive gain	
EXT_P	External pressure	
EXT_T	External temperature	
FVZ	Field verification zero	Weights & Measures application only
GSV F	Gas standard volume flow	
GSVI	Gas standard volume inventory	
GSV T	Gas standard volume total	
LPO_A	Left pickoff amplitude	

Table A-2: Display codes for process variables (continued)

Code	Definition	Comment or reference
LVOLI	Volume inventory	
LZERO	Live zero flow	
MASSI	Mass inventory	
MTR_T	Case temperature (T-Series sensors only)	
NET M	Net mass flow rate	Concentration measurement application only
NET V	Net volume flow rate	Concentration measurement application only
NETMI	Net mass inventory	Concentration measurement application only
NETVI	Net volume inventory	Concentration measurement application only
PWRIN	Input voltage	Refers to power input to the core processor
RDENS	Density at reference temperature	Concentration measurement application only
RPO_A	Right pickoff amplitude	
SGU	Specific gravity units	
STD V	Standard volume flow rate	Concentration measurement application only
STDVI	Standard volume inventory	Concentration measurement application only
TCDENS	Temperature-corrected density	Petroleum measurement application only
TCORI	Temperature-corrected inventory	Petroleum measurement application only
TCORR	Temperature-corrected total	Petroleum measurement application only
TCVOL	Temperature-corrected volume	Petroleum measurement application only
TUBEF	Raw tube frequency	
WTAVE	Weighted average	

## A.5 Codes and abbreviations used in display menus

Table A-3: Codes and abbreviations used in display menus

Code or abbrevia- tion	Definition	Comment or reference
ACK ALARM	Acknowledge alarm	
ACK ALL	Acknowledge all alarms	
ACT	Action	
ADDR	Address	
AO1	Analog output 1 (primary mA Output)	
AO 1 SRC	Fixed to the process variable assigned to the primary output	

Table A-3: Codes and abbreviations used in display menus (continued)

Code or abbrevia-	Definition	Comment or reference
		Comment of reference
AO2	Analog output 2 (secondary mA Output)	
AUTO SCRLL	Auto Scroll	
BKLT B LIGHT	Backlight	
CAL	Calibrate	
CH A	Channel A	
CHANGE PASSW CHANGE CODE	Change password or passcode	Change the password or passcode required for access to display functions
CH B	Channel B	
CHC	Channel C	
CONFG	Configuration	
CORE	Core processor	
CUR Z	Current zero	
CUSTODY XFER	Custody transfer	
DENS	Density	
D EV	Discrete event	Events configured using the enhanced event model
DGAIN, DRIVE %	Drive gain	
DISBL	Disable	Select to disable
DO1	Discrete Output 1	
DO2	Discrete Output 2	
DSPLY	Display	
E1OR2	Event 1 or Event 2	Events configured using the basic event model
ENABL	Enable	Select to enable
ENABLE ACK	Enable acknowledge all	Enable or disable the ACK ALL function
ENABLE ALARM	Enable alarm menu	Access to alarm menu from display
ENABLE AUTO	Enable Auto Scroll	Enable or disable the Auto Scroll function
ENABLE OFFLN	Enable off-line	Access to off-line menu from display
ENABLE PASSW	Enable password	Enable or disable password protection for display functions
ENABLE RESET	Enable totalizer reset	Enable or disable totalizer reset from display
ENABLE START	Enable totalizer start	Enable or disable totalizer start/stop from display
EVNT1	Event 1	Event configured using the basic event model on ly
EVNT2	Event 2	Event configured using the basic event model on ly

Table A-3: Codes and abbreviations used in display menus (continued)

Code or abbrevia-	Definition	Comment or reference
EXTRN	External	
FAC Z	Factory zero	
FCF	Flow calibration factor	
FLDIR	Flow direction	
FL SW FLSWT	Flow switch	
FO	Frequency Output	
FO FREQ	Frequency factor	
FO RATE	Rate factor	
FREQ	Frequency	
FR FL	Frequency=Flow	
GSV	Gas standard volume	
HYSTRSIS	Hysteresis	
INTERN	Internal	
10	Input/output	
LANG	Language	
LOCK	Write-protect	
LOOP CUR	Loop current	
M_ASC	Modbus ASCII	
M_RTU	Modbus RTU	
MAO1	mA Output 1 (primary mA Output)	
MAO2	mA Output 2 (secondary mA Output)	
MASS	Mass flow	
MBUS	Modbus	
MFLOW	Mass flow	
MSMT	Measurement	
MTR F	Meter factor	
OFF-LINE MAINT	Off-line maintenance	
OFFLN	Off-line	
OIL	Uncorrected oil flow	PVR applications only
OIL60	Corrected Net Oil Flow	PVR applications only
P/UNT	Pulses/unit	
POLAR	Polarity	
PRESS	Pressure	

Table A-3: Codes and abbreviations used in display menus (continued)

Code or abbrevia- tion	Definition	Comment or reference
QUAD	Quadrature	
r.	Revision	
SCALE	Scaling method	
SFM60	Shrinkage factor corrected volume of mix at 60F	PVR applications only
SFO60	Shrinkage Fac Corr Net Oil Total at Reference	PVR applications only
SIM	Simulation	Used for loop testing, not simulation mode. Simulation mode is not accessible through the display.
SPECL	Special	
SRC	Source	Variable assignment
TEMP, TEMPR	Temperature	
UNT/P	Units/pulse	
VAR 1	Display Variable 1	
VER	Version	
VERFY	Verify	
VFLOW	Volume flow	
VOL	Volume, volume flow	
WATER	Uncorrected Net Water Flow Rate	PVR applications only
WATER%	Uncorrected Water Cut	PVR applications only
WCT60%	Water Cut 60F	PVR applications only
WRPRO	Write protect	PVR applications only
WTR60	Corrected Net Water Flow	PVR applications only
XMTR	Transmitter	

# Appendix B Using ProLink III with the transmitter

#### Topics covered in this appendix:

- Basic information about ProLink III
- Connect with ProLink III

## B.1 Basic information about ProLink III

ProLink III is a configuration and service tool available from Micro Motion. ProLink III runs on a Windows platform and provides complete access to transmitter functions and data.

#### **Version requirements**

To support all the latest firmware features, device firmware v8.0, ProLink III v4.0 or later is required. For details about ProLink III device support, refer to the ProLink III ChangeLog.txt file.

#### **ProLink III requirements**

To install ProLink III, you must have:

- The ProLink III installation media
- The ProLink III installation kit for your connection type:

To obtain ProLink III and the appropriate installation kit, contact customer support.

#### **ProLink III documentation**

Most of the instructions in this manual assume that you are already familiar with ProLink III or that you have a general familiarity with Windows programs. If you need more information than this manual provides, see the ProLink® III Configuration and Service Tool for Micro Motion® Transmitters: User Manual.

In most ProLink III installations, the manual is installed with the ProLink III program. Additionally, the ProLink III manual is available on the documentation CD or at <a href="https://www.emerson.com">www.emerson.com</a>.

#### **ProLink III features and functions**

ProLink III offers complete transmitter configuration and operation functions. ProLink III also offers a number of additional features and functions, including:

- A Professional version with expanded features not available on the Basic version.
- The ability to save the transmitter configuration set to a file on the PC, and reload it or propagate it to other transmitters
- The ability to log specific types of data to a file on the PC
- The ability to view performance trends for various types of data on the PC

- The ability to connect to and view information for more than one device
- A guided connection wizard

These features are documented in the ProLink III manual. They are not documented in the current manual.

#### **ProLink III messages**

As you use ProLink III with a Micro Motion transmitter, you will see a number of messages and notes. This manual does not document all of these messages and notes.

#### **Important**

The user is responsible for responding to messages and notes and complying with all safety messages.

## B.2 Connect with ProLink III

A connection from ProLink III to your transmitter allows you to read process data, configure the transmitter, and perform maintenance and troubleshooting tasks.

## B.2.1 Connection types supported by ProLink III

Different connection types are available for connecting from ProLink III to the transmitter. Choose the connection type appropriate to your network and the tasks you intend to perform.

The transmitter supports the following ProLink III connection types:

- Service port connections
- HART/Bell 202 connections
- HART/RS-485 connections
- Modbus/RS-485 8-bit connections (Modbus RTU)
- Modbus/RS-485 7-bit connections (Modbus ASCII)

When selecting a connection type, consider the following:

- Service port connections are specialized Modbus/RS-485 connections that use standard connection parameters and a standard address that are already defined in ProLink III. A service port connection is the preferred connection.
- HART/Bell 202 connections use standard HART connection parameters that are already defined in ProLink III. The only parameter you must configure is the transmitter address.
- Some connection types require opening the wiring compartment or the power supply compartment. These connection types should be used only for temporary connections, and may require extra safety precautions.
- When you are using a HART connection, ProLink III will not allow you to open more than one window at a time. This is done to manage network traffic and optimize speed.

 You cannot make concurrent Modbus connections if the connections use the same terminals. You can make concurrent Modbus connections if the connections use different terminals.

## B.2.2 Connect with ProLink III to the service port

#### **A** CAUTION!

If the transmitter is in a hazardous area, do not use a service port connection. Service port connections require opening the wiring compartment, and opening the wiring compartment while the transmitter is powered up could cause an explosion. To connect to the transmitter in a hazardous environment, use a connection method that does not require removing the transmitter housing cover.

#### **Prerequisites**

- ProLink III is installed and licensed on your PC
- One of the following:
  - RS-232 to RS-485 signal converter
  - USB to RS-485 signal converter
- An available serial port or USB port
- Adapters as required (for example, 9-pin to 25-pin)


#### **Procedure**

- 1. Attach the signal converter to the serial port or USB port on your PC.
- 2. Access the service port terminals:
  - a. Remove the transmitter end-cap to access the wiring compartment.
  - b. Loosen the screw on the Warning flap and open the power supply compartment.
- 3. Connect the leads from the signal converter to the service port, terminals 7 (RS-485/A) and 8 (RS-485/B).

#### Tip

Usually, but not always, the red lead is RS-485/A and the black lead is RS-485/B.

Figure B-1: Connection to service port



- A. PC
- B. Signal converter
- C. Service port terminal 7 (RS-485/A)
- D. Service port terminal 8 (RS-485/B)
- E. Transmitter, with wiring compartment and power supply compartment opened

#### Note

This figure shows a serial port connection. USB connections are also supported.

- 4. Start ProLink III.
- 5. Choose Connect to Physical Device.
- 6. Set **Protocol** to Service Port.

#### Tip

Service port connections use standard connection parameters and a standard address. You do not need to configure them here.

- 7. Set the **PC Port** value to the PC COM port that you are using for this connection.
- 8. Click Connect.

**Need help?** If an error message appears:

- Switch the leads and try again.
- Ensure that you have specified the correct port on your PC.
- Check the wiring between the PC and the transmitter.

## B.2.3 Make a HART/Bell 202 connection

You can connect directly to the mA terminals on the transmitter, to any point in a local HART loop, or to any point in a HART multidrop network.

#### **A** CAUTION!

If the transmitter is in a hazardous area, do not connect directly to the transmitter terminals. Connecting directly to the transmitter terminals requires opening the wiring compartment, and opening the wiring compartment while the transmitter is powered up could cause an explosion. To connect to the transmitter in a hazardous environment, use a connection method that does not require opening the wiring compartment.

#### **A** CAUTION!

If you connect directly to the mA terminals, the transmitter's mA Output may be affected. If you are using the mA Output for process control, set devices for manual control before connecting directly to the mA terminals.

#### **Prerequisites**

- ProLink III is installed and licensed on your PC
- One of the following:
  - RS-232 to Bell 202 signal converter
  - USB to Bell 202 signal converter
- An available serial port or USB port
- Adapters as required (for example, 9-pin to 25-pin)

#### **Procedure**

- 1. Attach the signal converter to the serial port or USB port on your PC.
- 2. To connect directly to the transmitter terminals:
  - a. Remove the transmitter end-cap to access the wiring compartment.
  - b. Connect the leads from the signal converter to terminals 1 and 2.

#### Tip


HART connections are not polarity-sensitive. It does not matter which lead you attach to which terminal.

c. Add resistance as necessary to achieve at least one volt across the connection points.

#### **Important**

HART/Bell 202 connections require a voltage drop of 1 VDC. To achieve this, add resistance of 250–600  $\Omega$  to the connection.

Figure B-2: Connection to transmitter terminals



- A. Computer
- B. Signal converter
- C. Transmitter

#### Note


This figure shows a serial port connection. USB connections are also supported.

- 3. To connect to a point in the local HART loop:
  - a. Attach the leads from the signal converter to any point in the loop.
  - b. Add resistance as necessary to achieve at least one volt across the connection points.

#### **Important**

HART/Bell 202 connections require a voltage drop of 1 VDC. To achieve this, add resistance of 250–600  $\Omega$  to the connection.

Figure B-3: Connection over local loop



- A. PC
- B. Signal converter
- C. Any combination of resistors R1, R2, and R3 as necessary to meet HART communication resistance requirements
- D. DCS or PLC
- E. Transmitter, with wiring compartment and power supply compartment opened

#### Note


This figure shows a serial port connection. USB connections are also supported.

- 4. To connect over a HART multidrop network:
  - a. Attach the leads from the signal converter to any point on the network.
  - b. Add resistance as necessary to achieve at least one volt across the connection points.

#### **Important**

HART/Bell 202 connections require a voltage drop of 1 VDC. To achieve this, add resistance of 250–600  $\Omega$  to the connection.

Figure B-4: Connection over multidrop network



- A. Signal converter
- B.  $250-600 \Omega$  resistance
- C. Devices on the network
- D. Master device
- 5. Start ProLink III.
- 6. Choose Connect to Physical Device.
- 7. Set **Protocol** to HART Bell 202.

#### Tip

HART/Bell 202 connections use standard connection parameters. You do not need to configure them here.

- 8. If you are using a USB signal converter, enable **Toggle RTS**.
- 9. Set **Address/Tag** to the HART polling address configured in the transmitter.

#### **Tips**

- If this is the first time you are connecting to the transmitter, use the default address: 0.
- If you are not in a HART multidrop environment, the HART polling address is typically left at the default value.
- If you are unsure of the transmitter's address, click Poll. The program will search the
  network and return a list of the transmitters that it detects.
- 10. Set the **PC Port** value to the PC COM port that you are using for this connection.
- 11. Set **Master** as appropriate.

Option	Description
Secondary	Use this setting if a primary HART host such as a DCS is on the network.

Option	Description
Primary	Use this setting if no other primary host is on the network. The Field Communicator is a secondary host.

#### 12. Click Connect.

#### **Need help?** If an error message appears:

- Verify the HART address of the transmitter, or poll HART addresses 1–15.
- Ensure that you have specified the correct port on your PC.
- Check the wiring between the PC and the transmitter.
- Increase or decrease resistance.
- Ensure that there is no conflict with another HART master. If any other host (DCS or PLC) is connected to the mA Output, temporarily disconnect the DCS or PLC wiring.

#### B.2.4 Make a HART/RS-485 connection

Use a Modbus connection instead of a HART protocol whenever possible, as a Modbus connection is faster.

You can connect directly to the RS-485 terminals on the transmitter or to any point on the network.

#### **A** CAUTION!

If the transmitter is in a hazardous area, do not connect directly to the transmitter terminals. Connecting directly to the transmitter terminals requires opening the wiring compartment, and opening the wiring compartment while the transmitter is powered up could cause an explosion. To connect to the transmitter in a hazardous environment, use a connection method that does not require opening the wiring compartment.

#### **Prerequisites**

- ProLink III installed and licensed on your PC
- One of the following:
  - RS-232 to RS-485 signal converter
  - USB to RS-485 signal converter
- An available serial port or USB port
- Adapters as required (for example, 9-pin to 25-pin)


#### **Procedure**

- 1. Attach the signal converter to the serial port or USB port on your PC.
- 2. To connect directly to the transmitter terminals:
  - a. Remove the transmitter end-cap to access the wiring compartment.
  - b. Connect the leads from the signal converter to terminals 5 (RS-485/A) and 6 (RS-485/B).

#### Tip

HART connections are not polarity-sensitive, but RS-485 connections are.

Figure B-5: Connection to transmitter terminals




- A. PC
- B. Signal converter
- C. Transmitter, with wiring compartment and power supply compartment opened

#### Note

This figure shows a serial port connection. USB connections are also supported.

- 3. To connect over the RS-485 network:
  - a. Attach the leads from the signal converter to any point on the network.
  - b. Add resistance as necessary to achieve at least one volt across the connection points.

Figure B-6: Connection over network



- A. PC
- B. Adapter, if necessary
- C. Signal converter
- D.  $120-\Omega$ , 1/2-watt resistors at both ends of the segment, if necessary for noise suppression
- E. DCS or PLC
- F. Transmitter, with wiring compartment and power supply compartment opened

#### Note

This figure shows a serial port connection. USB connections are also supported.

- 4. Start ProLink III.
- 5. Choose Connect to Physical Device.
- 6. Set the connection parameters to the values configured in the transmitter.

If your transmitter has not been configured, use the default values shown here.

Table B-1: Default HART/RS-485 connection parameters

Parameter	Default values	
Protocol	HART (default factory setting on the RS-485 channel)	
Baud	1200	
Parity	Odd	
Stop Bits	1	
Address	0	

#### Tip

If you do not know the transmitter's RS-485 communication settings, you can connect through the service port, which always uses default settings, or use another communications tool to view or change the settings.

7. Set the **PC Port** value to the PC COM port that you are using for this connection.

#### 8. Set **Master** as appropriate.

Option	Description
Secondary	Use this setting if a primary HART host such as a DCS is on the network.
Primary	Use this setting if no other primary host is on the network. The Field Communicator is a secondary host.

#### 9. Click Connect.

**Need help?** If an error message appears:

- Verify the HART address of the transmitter, or poll HART addresses 1–15.
- Ensure that you have specified the correct port on your PC.
- Check the wiring between the PC and the transmitter.
- Ensure that there is no conflict with another HART master. If any other host (DCS or PLC) is connected to the mA output, temporarily disconnect the DCS or PLC wiring.
- For long-distance communication, or if noise from an external source interferes with the signal, install 120- $\Omega$  ½-W terminating resistors in parallel with the output at both ends of the communication segment.

#### B.2.5 Connect with ProLink III to the RS-485 port

You can connect directly to the RS-485 terminals on the transmitter or to any point on the network.

#### **A** CAUTION!

If the transmitter is in a hazardous area, do not connect directly to the transmitter terminals. Connecting directly to the transmitter terminals requires opening the wiring compartment, and opening the wiring compartment while the transmitter is powered up could cause an explosion. To connect to the transmitter in a hazardous environment, use a connection method that does not require opening the wiring compartment.

#### **Prerequisites**

- ProLink III is installed and licensed on your PC.
- One of the following:
  - RS-232 to RS-485 signal converter
  - USB to RS-485 signal converter
- An available serial port or USB port
- Adapters as required (for example, 9-pin to 25-pin)

#### **Procedure**


- 1. Attach the signal converter to the serial port or USB port on your PC.
- 2. To connect directly to the transmitter terminals:

- a. Remove the transmitter end-cap to access the wiring compartment.
- b. Connect the leads from the signal converter to terminals 5 (RS-485/A) and 6 (RS-485/B).

#### Tip

Usually, but not always, the black lead is RS-485/A and the red lead is RS-485/B.

Figure B-7: Connection to transmitter terminals




- A. Computer
- B. Signal converter
- C. Transmitter, with wiring compartment and power supply compartment opened

#### Note

This figure shows a serial port connection. USB connections are also supported.

- 3. To connect over the RS-485 network:
  - a. Attach the leads from the signal converter to any point on the network.

Figure B-8: Connection over network



- A. Computer
- B. Signal converter
- C.  $120-\Omega$ , 1/2-watt resistors at both ends of the segment, if necessary for noise suppression
- D. DCS or PLC
- E. Transmitter, with wiring compartment and power supply compartment opened

#### Note

This figure shows a serial port connection. USB connections are also supported.

- 4. Start ProLink III.
- 5. Choose **Connect to Physical Device**.
- 6. Set the connection parameters to the values configured in the transmitter.

If your transmitter has not been configured, use the default values shown here.

Table B-2: Default Modbus/RS-485 connection parameters

Parameter	Default value
Protocol	Modbus RTU
Baud	9600
Parity	Odd
Stop Bits	1
Address	1

#### Tip

If you do not know the transmitter's RS-485 communication settings, you can connect through the service port, which always uses default settings, or use another communications tool to view or change the settings.

7. Set the **PC Port** value to the PC COM port that you are using for this connection.

#### 8. Select **Connect**.

#### **Need help?** If an error message appears:

- Verify the Modbus address of the transmitter.
- Ensure that you have specified the correct port on your PC.
- Check the wiring between the PC and the transmitter.
- Increase or decrease resistance.
- For long-distance communication, or if noise from an external source interferes with the signal, install 120- $\Omega$  ½-W terminating resistors in parallel with the output at both ends of the communication segment.
- Ensure that there is no concurrent Modbus communication to the transmitter.

# Appendix C Using a Field Communicator with the transmitter

#### Topics covered in this appendix:

- Basic information about the Field Communicator
- Connect with the Field Communicator

## C.1 Basic information about the Field Communicator

The Field Communicator is a handheld configuration and management tool that can be used with a variety of devices, including Micro Motion transmitters. It provides complete access to transmitter functions and data.

#### **Field Communicator documentation**

Most of the instructions in this manual assume that you are already familiar with the Field Communicator and can perform the following tasks:

- Turn on the Field Communicator
- Navigate the Field Communicator menus
- Send configuration data to the device
- Use the alpha keys to enter information

If you are unable to perform these tasks, consult the Field Communicator manual before attempting to use the Field Communicator. The Field Communicator manual is available on the documentation CD or at <a href="https://www.emerson.com">www.emerson.com</a>.

#### Device descriptions (DDs)

In order for the Field Communicator to work with your device, the appropriate device description (DD) must be installed: 1000 Mass flo, Dev v8, DD v1

To view the device descriptions that are installed on your Field Communicator:

- 1. At the HART application menu, press **Utility > Available Device Descriptions**.
- Scroll the list of manufacturers and select Micro Motion, then scroll the list of installed device descriptions.

If **Micro Motion** is not listed, or you do not see the required device description, use the Field Communicator Easy Upgrade Utility to install the device description, or contact customer support.

#### Field Communicator menus and messages

Many of the menus in this manual start with the On-Line menu. Ensure that you are able to navigate to the On-Line menu.

As you use the Field Communicator with a Micro Motion transmitter, you will see a number of messages and notes. This manual does not document all of these messages and notes.

#### **Important**

The user is responsible for responding to messages and notes and complying with all safety messages.

#### Field Communicator with PVR, TBR, and TMR applications

Production Volume Reconciliation (PVR), Transient Bubble Remediation (TBR), and Transient Mist Remediation (TMR) are available only over HART with HART 7 enabled (default).

#### C.2 Connect with the Field Communicator

A connection from the Field Communicator to your transmitter allows you to read process data, configure the transmitter, and perform maintenance and troubleshooting tasks.

You can connect the Field Communicator to the mA terminals on the transmitter, to any point in a local HART loop, or to any point in a HART multidrop network.

#### **A** CAUTION!

If the transmitter is in a hazardous area, do not connect the Field Communicator to the mA terminals on the transmitter. This connection requires opening the wiring compartment, and opening the wiring compartment in a hazardous area can cause an explosion.

#### **Prerequisites**

The following HART device description (DD) must be installed on the Field Communicator: 1000 Mass flo, Dev v8, DD v1.

#### **Procedure**


- 1. To connect to the transmitter terminals:
  - a. Remove the cover from the wiring compartment.
  - b. Attach the leads from the Field Communicator to terminals 1 and 2 on the transmitter and add resistance as required.

The Field Communicator must be connected across a resistance of 250–600  $\Omega$ .

#### Tip

HART connections are not polarity-sensitive. It does not matter which lead you attach to which terminal.


Figure C-1: Field Communicator connection to transmitter terminals



- A. Field Communicator
- B.  $250-600 \Omega$  resistance
- C. Transmitter, with wiring compartment and power supply compartment opened
- 2. To connect to a point in the local HART loop, attach the leads from the Field Communicator to any point in the loop and add resistance as necessary.

The Field Communicator must be connected across a resistance of 250–600  $\Omega$ .

Figure C-2: Field Communicator connection to local HART loop



- A. Field Communicator
- B.  $250-600 \Omega$  resistance
- C. Transmitter, with wiring compartment and power supply compartment opened
- 3. To connect to a point in the HART multidrop network, attach the leads from the Field Communicator to any point on the network.

D B

Figure C-3: Field Communicator connection to multidrop network

- A. Field Communicator
- B.  $250-600 \Omega$  resistance
- C. Devices on the network
- D. Master device
- 4. Turn on the Field Communicator and wait until the main menu is displayed.
- 5. If you are connecting across a multidrop network:
  - Set the Field Communicator to poll. The device returns all valid addresses.
  - Enter the HART address of the transmitter. The default HART address is 0. However, in a multidrop network, the HART address has probably been set to a different, unique value.

#### **Postrequisites**

To navigate to the Online menu, choose **HART Application > Online**. Most configuration, maintenance, and troubleshooting tasks are performed from the Online menu.

#### Tip

You may see messages related to the DD or active alerts. Press the appropriate buttons to ignore the message and continue.

#### **Need help?**

The Field Communicator requires a minimum of 1 VDC across the connection leads to communicate. If necessary, increase the resistance at the connection point until 1 VDC is achieved.

## Appendix D Default values and ranges

### D.1 Default values and ranges

The default values and ranges represent the typical factory transmitter configuration. Depending on how the transmitter was ordered, certain values may have been configured at the factory and are not represented in the default values and ranges.

Table D-1: Transmitter default values and ranges

Туре	Parameter	Default	Range	Comments
Flow	Flow direction	Forward		
	Flow damping	0.8 sec <sup>(1)</sup>	0.0 – 51.2 sec	User-entered value is corrected to the nearest valid value in list of preset values. In Special mode, the preset values are 1/5 normal. For gas applications, a minimum value of 2.56 is recommended. The 2.56 value will be automatically rounded up to 3.2 seconds.
	Flow calibration factor	1.00005.13		For sensors, this value represents the FCF and FT factors concatenated.
	Mass flow units	g/s		
	Mass flow cutoff	Sensor-specific value set at factory		For most sensors, the typical setting is 0.05% to 0.10% of the sensor's rated maximum flow rate. For some sensors, the setting may be higher. For some applications, such as empty-full-empty batching, a higher value is recommended. Contact MMI customer service for assistance.
	Volume flow type	Liquid		
	Volume flow units	L/s		
	Volume flow cutoff	0/0 L/s	0.0 – x L/s	x is obtained by multiplying the flow calibration factor by 0.2, using units of L/s.
Meter factors	Mass factor	1		
	Density factor	1		

 Table D-1: Transmitter default values and ranges (continued)

Туре	Parameter	Default	Range	Comments
	Volume factor	1		
Density	Density damping	1.6 sec	0.0 – 51.2 sec	User-entered value is corrected to nearest valid value in a list of preset values.
	Density units	g/cm <sup>3</sup>		
	Density cutoff	0.2 g/cm <sup>3</sup>	$0.0 - 0.5 \mathrm{g/cm^3}$	
	D1	0 g/cm <sup>3</sup>		
	D2	1 g/cm <sup>3</sup>		
	K1	1000 μsec	1000 – 50,000 μsec	
	K2	50,000 μsec	1000 – 50,000 μsec	
	FD	0		
	Temp Coefficient	4.44		
Two-phase flow	Two-phase flow low limit	0.0 g/cm <sup>3</sup>	0.0 – 10.0 g/cm <sup>3</sup>	
	Two-phase flow high limit	5.0 g/cm <sup>3</sup>	0. 0 – 10.0 g/cm <sup>3</sup>	
	Two-phase duration	0.0 sec	0.0 – 60.0 sec	
Temperature	Temperature damping	4.8 sec	0.0 – 38.4 sec	User-entered value is corrected to nearest valid value in a list of preset values.
	Temperature units	Deg C		
	Temperature calibration factor	1.00000T0.00 00		
Pressure	Pressure units	PSI		
	Flow factor	0		
	Density factor	0		
	Cal pressure	0		
T-Series sensor	D3	0 g/cm <sup>3</sup>		
	D4	0 g/cm <sup>3</sup>		
	K3	0 μsec		
	K4	0 μsec		
	FTG	0		
	FFQ	0		
	DTG	0		
	DFQ1	0		
	DFQ2	0		

Table D-1: Transmitter default values and ranges (continued)

Туре	Parameter	Default	Range	Comments
Special units	Base mass unit	g		
	Base mass time	sec		
	Mass flow conversion factor	1		
	Base volume unit	L		
	Base volume time	sec		
	Volume flow conversion factor	1		
Variable map-	Primary variable	Mass flow		
ping	Secondary variable	Volume flow		
	Tertiary variable	Mass flow		
	Quaternary variable	Volume flow		
mA Output 1	Primary variable	Mass flow		
	LRV	-200.00000 g/s		
	URV	200.00000 g/s		
	AO cutoff	0.00000 g/s		
	AO added damping	0.00000 sec		The user-entered value is corrected down to the nearest lower value in a list of preset values.
	LSL	-200 g/s		Read-only. LSL is calculated based on the sensor size and characterization parameters.
	USL	200 g/s		Read only. USL is calculated based on the sensor size and characterization parameters.
	MinSpan	0.3 g/s		Read-only.
	Fault action	Downscale		
	AO fault level – downscale	2.0 mA	1.0 – 3.6 mA	
	AO fault level – upscale	22 mA	21.0 – 24.0 mA	
	Last measured value timeout	0.00 sec		
mA Output 2	Secondary variable	Density		
	LRV	0.00 g/cm3		
	URV	10.00 g/cm3		
	AO cutoff	Not-A-Number		
	AO added damping	0.00000 sec		

 Table D-1: Transmitter default values and ranges (continued)

Туре	Parameter	Default	Range	Comments
	LSL	0.00 g/cm <sup>3</sup>		Read-only. LSL is calculated based on the sensor size and characterization parameters.
	USL	10.00 g/cm <sup>3</sup>		Read only. USL is calculated based on the sensor size and characterization parameters.
	MinSpan	$0.05  g/cm^3$		Read-only.
	Fault action	Downscale		
	AO fault level – downscale	2.0 mA	1.0 – 3.6 mA	
	AO fault level – upscale	22 mA	21.0 – 24.0 mA	
	Last measured value timeout	0.00 sec		
LRV	Mass flow rate	-200.000 g/s		
	Volume flow rate	-0.200 L/s		
	Density	0.000 g/cm <sup>3</sup>		
	Temperature	−240.000 °C		
	Drive gain	0.000%		
	Gas standard volume flow rate	-423.78SCFM		
	External temperature	−240.000 °C		
	External pressure	0.000 psi		
URV	Mass flow rate	200.000 g/s		
	Volume flow rate	0.200 L/s		
	Density	10.000 g/cm <sup>3</sup>		
	Temperature	450.000 °C		
	Drive gain	100.000%		
	Gas standard volume flow rate	423.78 SCFM		
	External temperature	450.000 °C		
	External pressure	100.000 psi		
Frequency	Tertiary variable	Mass flow		
Output	Frequency factor	1,000.00 Hz	0.001 – 10,000 Hz	
	Flow rate factor	1000 kg/min		
	Scaling method	Freq=Flow	0 or 0.5 – 277.5 ms	
	Frequency fault action	Downscale		
	Frequency fault level – upscale	15,000 Hz	10.0 – 15,000 Hz	

Table D-1: Transmitter default values and ranges (continued)

Туре	Parameter	Default	Range	Comments
	Frequency Output polarity	Active high		
	Last measured value timeout	0.0 seconds	0.0 – 60.0 sec	
Discrete Out-	Source	Flow direction		
put	Fault Indicator	None		
	Power	Internal		
	Polarity	Active high		
Display	Backlight on/off	On		
	Refresh rate	200 millisec- onds	100 – 10,000 milliseconds	
	Variable 1	Mass flow rate		
	Variable 2	Mass total		
	Variable 3	Volume flow rate		
	Variable 4	Volume total		
	Variable 5	Density		
	Variable 6	Temperature		
	Variable 7	Drive gain		
	Variable 8–15	None		
	Display totalizer start/stop	Disabled		
	Display totalizer reset	Disabled		
	Display auto scroll	Disabled		
	Display offline menu	Enabled		
	Display offline password	Disabled		
	Display alarm menu	Enabled		
	Display acknowledge all alarms	Enabled		
	Offline password	1234		
	Auto scroll rate	10 sec		
Digital com-	Fault action	None		
munications	Fault timeout	0 seconds	0.0 – 60.0 sec	
	Modbus address	1		
	Modbus ASCII support	Enabled		
	Floating-point byte order	3-4-1-2		
	Double-precision byte order	1-2-3-4-5-6-7- 8		

<sup>(1)</sup> In Special mode, the default value is 0.64 sec.

## Appendix E Transmitter components and installation wiring

#### Topics covered in this appendix:


- Installation types
- Power supply terminals and ground
- Input/output (I/O) wiring terminals

## **E.1** Installation types

The transmitter was ordered and shipped to be installed in one of several possible configurations.

#### Figure E-1: Integral installation


The transmitter is mounted directly to the sensor. Integral installations do not require separate transmitter installation. Power supply and I/O must be field wired to the transmitter.



- A. Transmitter
- B. Sensor

#### Figure E-2: High-temperature meters with factory connection


The transmitter is shipped with a flexible connection factory installed between the sensor and the transmitter. The transmitter must be dismounted from its shipping location (spot-welded to the sensor case) and then mounted separately. Power supply and I/O must be field wired to the transmitter.



- A. Sensor
- B. Transmitter or core processor
- C. Factory-installed flexible connection

Figure E-3: 4-wire remote installation for Coriolis meters


The transmitter is installed remotely from the sensor. The 4-wire connection between the sensor and transmitter must be field wired. Power supply and I/O must be field wired to the transmitter.



- A. Transmitter
- B. Field-wired 4-wire connection
- C. Core processor
- D. Sensor

#### Figure E-4: Remote core processor with remote sensor installation


The transmitter, core processor, and sensor are all mounted separately. The 4-wire connection between the transmitter and core processor must be field wired. The 9-wire connection between the core processor and the sensor must be field wired. Power supply and I/O must be field wired to the transmitter. This configuration is sometimes called double-hop.



- A. Junction box
- B. Sensor
- C. Transmitter
- D. Field-wired 4-wire connection
- E. Core processor
- F. Field-wired 9-wire connection

## **E.2** Power supply terminals and ground


Figure E-5: Power supply wiring terminals



- A. Warning flap
- B. Equipment ground
- C. Power supply wiring terminals (9 and 10)

## E.3 Input/output (I/O) wiring terminals

Figure E-6: I/O wiring terminals



- A. mA/HART
- B. Frequency Output or Discrete Output
- C. RS-485

## Appendix F NE 53 history

## F.1 NE 53 history

#### **Important**

Not all features and capabilities described in this section may apply to your transmitter or configuration.

#### August 2000, Version 1.x

Modification type	Change
Expansion	Added writing of the device tag using Modbus
Adjustment	Improved communication handling with the HART Tri-Loop product
Feature	Indication of outputs option board type appears on display at power-up

#### May 2001, version 2.x

Modification type	Change
Expansion	<ul> <li>Added alarm A106 to indicate that HART burst mode is enabled</li> <li>Indication of outputs option board type appears on display at power-up</li> <li>Added alarm A106 to indicate that HART burst mode is enabled</li> <li>Control of HART burst mode now available via Modbus</li> <li>Added support for the Model 1700 transmitter</li> <li>Added support for the intrinsically safe transmitter option</li> <li>Added support to configure the process variable units for mass flow, volume flow, density and temperature from the display</li> <li>Added support for assigning process variables to the mA and Frequency Output from the display</li> </ul>
Adjustment	Clarified the interaction of the digital fault setting and the fault timeout (last measured value timeout)
Feature	<ul> <li>Drive gain can be assigned to mA Output</li> <li>Pressure compensation added via HART</li> <li>Channel B can be configured as a Discrete Output</li> </ul>

#### December 2001, version 3.x

Modification type	Change
Expansion	<ul> <li>Added support for the configurable I/O option board</li> <li>Software version information available via the display or Modbus</li> <li>Configurable density cutoff</li> <li>Additional HART variables can be assigned to QV</li> <li>The display start/stop totalizers function can be enabled or disabled</li> <li>Petroleum measurement application improvements</li> <li>Live zero available as display variable</li> <li>Increased options for fault output settings</li> <li>New cryogenic application temperature algorithms</li> </ul>
Adjustment	<ul> <li>Improved Frequency Output stability and unit conversions</li> <li>Improved the handling of volume flow rate when two-phase flow is detected</li> <li>Improved handling of density values and calibrations during fault conditions</li> <li>Display configuration, screen flow and optical switch changes</li> <li>HART communication and burst mode improvements</li> </ul>
Feature	<ul> <li>Petroleum measurement application added</li> <li>Custody transfer option added to the configurable I/O option board</li> <li>HART polling for external pressure/temperature added</li> </ul>

#### June 2003, version 4.x

Modification type	Change
Expansion	<ul> <li>Added support for the Model 1500 transmitter</li> <li>Additional variables displayed by the Model 1700 transmitter</li> </ul>
Adjustment	<ul> <li>Improved the handling of certain alarm conditions</li> <li>Clarified the behavior of certain Modbus calibration coils</li> <li>Clarified the interaction between certain density measurement units and density cutoff values</li> <li>Improved the handling of the mA source setting via the display</li> <li>Improvements to pressure and temperature polling</li> <li>HART Tri-Loop and other communication improvements</li> <li>Clarified the value returned by Modbus scaled integer registers during a fault condition</li> </ul>
Feature	Discrete values now available through Modbus

#### September 2006, version 5.x

Modification type	Change
Expansion	<ul> <li>Discrete Output assignable as a flow switch</li> <li>Discrete Output fault indication configurability</li> <li>Discrete Input support for multiple action assignments</li> <li>Added support for querying the display LED status via Modbus</li> <li>Additional HART and Modbus commands</li> <li>Process comparator expanded to five configurable events</li> <li>Factory configuration restore function</li> <li>Factory zero restore function</li> <li>Alarm history expanded</li> <li>Selectable write protection for configuration data</li> <li>Expanded selection of source assignments for mA Output</li> <li>Expanded storage of mA range values</li> <li>Expanded custody transfer application for independent implementation of NTEP and OIML compliance</li> </ul>
Adjustment	Display improvements for floating-point data
Feature	<ul> <li>Configurable alarm severity</li> <li>Gas standard volume functionality</li> <li>Meter verification availability as an option</li> <li>Multiple display language selections</li> </ul>

#### September 2009, version 6.x

Modification type	Change
Expansion	<ul> <li>Frequency Output configurable as Discrete Output on Series 1000 transmitters</li> <li>Discrete Output assignable as flow switch on Series 1000 transmitters</li> <li>Display Variable 1 optionally fixed to process variable assigned to primary mA Output</li> <li>Frequency Output scaling method and related parameters configurable from display</li> <li>For enhanced density and petroeum measurement process variables, display cycles among variable name, current value and unit, and reference temperature</li> </ul>
Adjustment	<ul> <li>mA Output Fault Action = None and Digital Communications         Fault Action = NAN is no longer allowed</li> <li>Frequency Output Fault Action = None and Digital Communications Fault Action = NAN is no longer allowed</li> <li>Display variables set to a volume process variable automatically switch between liquid and GSV, according to current setting of Volume Flow Type</li> </ul>

Modification type	Change
Feature	<ul> <li>Configurable hysteresis for flow switch</li> <li>Field Verification Zero added to support Weights &amp; Measures application</li> <li>Transmitter firmware checksum and core processor firmware checksum assignable as display variables and viewable in Pro-Link</li> </ul>

#### February 2018, version 8.x

Modification type	Change
Expansion	<ul> <li>Polling an external device for base density Gas Standard Volume (GSV)</li> <li>NE 53 version added to the display and accessed using Modbus and HART</li> <li>Improved data update rate for Advanced Zero Check using ProLink III</li> <li>Byte order configuration for double totals</li> <li>Modbus Funtion 43 basic objects for FDI identification</li> <li>Fast access to Live Zero in 100 Hz mode</li> <li>Display used to disable user access to the Smart Meter Verification menu. Once disabled, access can only be enabled using ProLink III or a HART device</li> </ul>

Modification type	Change
Adjustment	<ul> <li>Sensors that are not straight tube sensors are now correctly identified</li> <li>The MA Output fixed alert is now set</li> <li>The Factory Configuration Invalid status bit is now set correctly when connected to a 700 core processor — as the 700 core processor does not support saving and restoring the factory configuration</li> <li>Enabling a new feature on a flow-only device does not reset the output configuration to factory defaults</li> <li>Polled variables are now converted to the transmitter units before being used</li> <li>HART Primary, Secondary, and Tertiary Variables can be changed using HART when the transmitter is configured for gas standard volume</li> <li>Petroleum measurement variables are removed from the display when petroleum measurement is disabled</li> <li>The mA Output can be fixed when assigned to a concentration measurement, petroleum measurement, or GSV variable when the transmitter is not connected to a core processor</li> <li>The units for concentration curve data are correctly converted when the data is entered using HART</li> <li>Meter verification failed and aborted alerts are now reflected in the HART More Status flag</li> <li>The HART Squawk command is functional when the HART write protect is enabled</li> <li>Locking the transmitter, unlocking the transmitter, or changing write protection does not set the HART Configuration Changed flag</li> <li>If connected to a 700 core processor with software version 3.1 or earlier, there is no longer a core processor write failed alert when setting volume flow units to beer barrels per time unit</li> <li>The factory zero value is immediately updated from the core processor after running a zero calibration and saving the factory configuration</li> <li>A firmware upgrade done without clearing non-volatile memory no longer causes an EEPROM Failure alert</li> <li>The status bit for the undefined A141 alert (Device Data Capture Triggered) no longer appears in the Modbus status register</li> <li>When using AMS to configure the transmitter: &lt;</li></ul>

Modification type	Change
	<ul> <li>An AMS Field Device did not respond message no longer displays when the concentration offset is configured even though the value was changed</li> <li>When the volume flow type is changed, the new setting is updated from the transmitter without having to rescan the device</li> </ul>
Feature	<ul> <li>Basic meter verification</li> <li>Production Volume Reconciliation (PVR)</li> <li>Transient Mist Remediation (TMR)</li> <li>Transient Bubble Remediation (TBR)</li> <li>Piecewise Linearization for Gas</li> <li>Fuel consumption</li> <li>Support for Micro Load</li> </ul>



MMI-20019028 Rev AB 2018

#### Micro Motion Inc. USA

Worldwide Headquarters 7070 Winchester Circle Boulder, Colorado USA 80301 T+1 303-527-5200 T+1 800-522-6277 F+1 303-530-8459 www.emerson.com

#### Micro Motion Asia

Emerson Automation Solutions 1 Pandan Crescent Singapore 128461 Republic of Singapore T +65 6777-8211 F +65 6770-8003

#### Micro Motion Europe

Emerson Automation Solutions Neonstraat 1 6718 WX Ede The Netherlands T+31 (0) 70 413 6666 F+31 (0) 318 495 556 www.micromotion.nl

#### Micro Motion United Kingdom

Emerson Automation Solutions Emerson Process Management Limited Horsfield Way Bredbury Industrial Estate Stockport SK6 2SU U.K. T +44 0870 240 1978 F +44 0800 966 181

#### Micro Motion Japan

Emerson Automation Solutions 1-2-5, Higashi Shinagawa Shinagawa-ku Tokyo 140-0002 Japan T +81 3 5769-6803 F +81 3 5769-6844

©2018 Micro Motion, Inc. All rights reserved.

The Emerson logo is a trademark and service mark of Emerson Electric Co. Micro Motion, ELITE, ProLink, MVD and MVD Direct Connect marks are marks of one of the Emerson Automation Solutions family of companies. All other marks are property of their respective owners.

