


# MT-RX-3

## AIS, 406 + 121.5 ALERTING RECEIVER



## User Manual

## Table of Contents

<b>Introduction.....</b>	<b>4</b>	DF Sub Menu.....	30
<b>Key Features.....</b>	<b>5</b>	WAYPOINT TARGET.....	30
<b>Safety Information.....</b>	<b>6</b>	WAYPOINT LAT.....	30
<b>Operation.....</b>	<b>9</b>	WAYPOINT LONG.....	30
<b>Buttons.....</b>	<b>10</b>	VOICE REPEAT.....	30
MENU/BACK:.....	10	BEARING.....	30
UP:.....	10	DEF POSITION.....	31
DOWN:.....	10	DEF LAT.....	31
RIGHT:.....	10	DEF LONG.....	31
ENTER:.....	10	DEF HEADING.....	31
<b>Icon Bar.....</b>	<b>11</b>	NMEA OUT Sub Menu.....	32
<b>Summary Screen.....</b>	<b>12</b>	OUTPUT.....	32
<b>406 Decode Screens.....</b>	<b>13</b>	TYPE.....	32
<b>RSS Screen.....</b>	<b>14</b>	TEST.....	33
<b>AIS Screens.....</b>	<b>15</b>	TEST LAT.....	33
<b>GPS Screen.....</b>	<b>17</b>	TEST LONG.....	33
<b>DF Screen.....</b>	<b>18</b>	AIS Sub Menu.....	34
<b>Alert Operation.....</b>	<b>19</b>	COLLISION.....	34
Sequence of events when an alert is		PROX ALERT.....	34
processed:.....	20	PROX WARN.....	34
<b>Spectrum Analyser.....</b>	<b>21</b>	DISPLAY.....	34
<b>MT-RX-3 Configuration.....</b>	<b>22</b>	RS232 OUT.....	34
SPECTRUM Menu.....	23	RSS Sub Menu.....	35
Alerts Sub Menu.....	24	FREQUENCY.....	35
406.....	24	SQUELCH.....	35
AIS-SART.....	24	SQUELCH DELAY.....	35
AIS PROXIMITY.....	25	SWEEP DETECT.....	35
AIS COLLISION.....	25	SCAN RATE.....	36
GPS ANCHOR.....	25	SERIAL OUT.....	36
RSS.....	25	406 Selective DB Sub Menu.....	37
RELAY TIME.....	25	<b>AIS Collision Avoidance.....</b>	<b>38</b>
SOUNDER TIME.....	25	<b>AIS SART Transmission Logging.....</b>	<b>40</b>
DUP REJECT TIME.....	26	<b>GPS Anchor.....</b>	<b>41</b>
System Sub Menu.....	27	<b>406 Beacon Transmission Logging.....</b>	<b>42</b>
LANGUAGE.....	27	<b>Decoded 406 Message Serial Output...43</b>	
BACKLIGHT.....	27	MT Serial Out Packet Format.....	43
TIME.....	27	Raw Data Serial Out Packet Format.....	44
SOUND.....	27	Checksum Calculation.....	44
RS232 BAUD.....	27	<b>AIS Serial Messages.....</b>	<b>45</b>
RS422 BAUD.....	28	<b>Target Setting.....</b>	<b>46</b>
MAIN SCREEN.....	28	<b>406 Selective Decode.....</b>	<b>49</b>
ANTENNA POS.....	28	406 Selective Decode Applications.....	49
FACTORY.....	28	<b>Installation.....</b>	<b>51</b>
SET DEFAULTS.....	28	Connecting to the MT-RX-3.....	51
TEST.....	28	<b>Configuration Methods.....</b>	<b>52</b>

Web Browser Configuration.....	53	RS-422/RS-485.....	77
<b>Serial Command Configuration.....</b>	<b>55</b>	RS-485/RS-422 Point To Point.....	78
*USERPASS.....	55	RS-485/RS-422 Multi-Point.....	78
MT-RX-3 Firmware Upgrade.....	56	RS-485 Multi-Point – 2 Wire.....	79
Firmware Upgrade Utility.....	56	Bus Terminating Resistor.....	79
Upgrade Process.....	57	<b>RF Connections.....</b>	<b>81</b>
Support for Portable and Battery Powered		<b>Power Connections.....</b>	<b>82</b>
Applications.....	58	<b>Ethernet Interface.....</b>	<b>83</b>
<b>AIS OpenCPN Support.....</b>	<b>59</b>	<b>Omni or Directional Antenna.....</b>	<b>84</b>
<b>406 Decoder PC Application.....</b>	<b>60</b>	Omni antenna.....	84
Location of Application Modified Files....	61	Directional antenna.....	84
Report Generation.....	63	<b>Antenna Elevation.....</b>	<b>85</b>
Serial Port Configuration.....	64	<b>Physical Dimensions.....</b>	<b>87</b>
Integrated Mapping.....	64	<b>Mounting Hardware.....</b>	<b>88</b>
Live Map Updates.....	64	DIN Rail.....	88
Static Map Button.....	65	Mounting Channels.....	89
Email Notification.....	66	TOP Mount.....	90
Testing Email Notification.....	67	SIDE Mount.....	90
<b>MT-RX-3 Customisation.....</b>	<b>68</b>	Bottom Mount.....	92
<b>Installation.....</b>	<b>69</b>	Mount Bolts Dimensions.....	93
Cables Supplied.....	69	Top and Bottom Drilling Template.....	94
Connecting to the MT-RX-3.....	70	Side Drilling Template.....	95
Connector Pin descriptions.....	71	Optional Mounting Inserts.....	96
RHS (Right Panel).....	71	<b>Disclaimer.....</b>	<b>99</b>
LHS (Left Panel).....	72	<b>Manufacturing marking and labels...100</b>	
<b>Output Hardware Connection.....</b>	<b>74</b>	<b>Maintenance.....</b>	<b>100</b>
Open Collector Outputs.....	74	<b>Product End Of Life.....</b>	<b>101</b>
Internal Relay.....	75	<b>Product Warranty.....</b>	<b>102</b>
External Speaker.....	75	<b>Abbreviations and Glossary.....</b>	<b>103</b>
<b>Serial Connections.....</b>	<b>76</b>	<b>Specification.....</b>	<b>104</b>
RS-232.....	76		

## Introduction

---

Thank you for choosing the MT-RX-3.

The MT-RX-3 is an Ethernet, Serial (RS232 plus RS485/RS422) and USB capable multi-band receiver. The MT-RX-3 has been designed to decode emergency signals and then provide an alert to locate the source of the transmission for the purposes of early rescue or monitoring.

The MT-RX-3 performs equally well as a standard 2 channel AIS receiver, making available AIS data available via its serial ports. The monitoring and alerting capability of the MT-RX-3 makes the receiver more feature rich and configurable than most other AIS receivers available on the market.

The MT-RX-3 operates multiple independent DSP (Digital Signal Processing) receivers concurrently allowing the simultaneous decoding and alerting of several distress signal types over many different frequencies.

The MT-RX-3 has been developed to provide an alert and simple GPS based direction indicating capability for:

- 406MHz EPIRBs, PLBs and ELT beacons operating across the frequencies 406.020 to 406.045 MHz.
- AIS based SART alerting devices operating on both 161.975MHz and 162.025MHz.
- 121.5MHz or 243MHz man-overboard devices and emergency homing transmitters with the use of directional antennas.

Each of these receiving technologies operate concurrently to provide excellent coverage over many emerging and existing distress devices. The receiver technologies used take advantage of DSP techniques for high sensitivity and high rejection of unwanted interfering signals.

AIS receiving and processing features include:

- Dual -115dBm receivers.
- Clear man-overboard alerts, and time stamped logging to SD card.
- Graphical and text based local vessel display.
- Proximity alerts and warnings.
- Configurable collision avoidance alerts.
- GPS anchor alerts.
- TCP, RS232, RS422, RS485 Serial output for connection to PC based mapping tools.
- Compatible with OpenCPN free mapping software.

406 and AIS alerts can be logged to internal memory storage, and provide a time-stamped history of alert location and activity. The file history can be viewed on the MT-RX-3 and any logged transmission can be set as a target that provides a bearing and distance to the transmission source.

The outputs or on-board relay can be connected to external alerting devices, and the internal/external speaker provides alerts and voice prompts for “voice only” guidance to selected

targets.

The high visibility graphic display provides clear details relating to the alert and when GPS information is available provides a clear bearing and distance to the distress transmission source.

The patented selective database allows 406 test transmissions to be used to provide a secure locally managed rescue system for 406 PLBs.

A simple top level display provides at a glance a summary of the activity on all monitored distress channels over the previous several minutes.

Logged information can be viewed on the MT-RX-3 itself and retrieved by connecting to the USB port (of the MT-RX-3), or by removing the SD card with care and inserting into a micro SD card reader.

NMEA output can be configured to allow integration with chart plotters and PC based mapping tools.

The MT-RX-3 can be used as part of another system with minimal processing requirements through a simple serial interface.

## Key Features

---

- Multiple receivers for simultaneous decoding of AIS, 406 (all used frequencies) and 121.5MHz (and optionally others).
- Logging of alerts.
- Multiple connection options – RS232, RS422, RS485 and USB. Ethernet supports use via web browser, TCP server or TCP client.
- Integration with PC software and NMEA devices for indication and use of GPS data.
- Configurable on the device itself, USB or via Ethernet.
- Can raise distress alerts for AIS, 406 and 121.5MHz (or optional other frequencies).
- Standard AIS features such as graphical display of ships, list of closest vessels and collision avoidance alerts.
- GPS anchor and alerts.
- Optional software controllable antenna inputs (up to 4).
- Optional low cost spectrum analyser providing huge visibility of transmitting signals, either to assist search and rescue or for direction finding.
- Can be connected to WTE transmitters for high power radio transmissions to notify users/crew within a very large area via paging (messages can be received with WTE receivers or on standard belt pagers). WTE transceivers can also operate remote alerts.

## Safety Information

---

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, or maintain it.

The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



This is the safety alert symbol. It is used to alert you to a potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

### **⚠WARNING**

**WARNING** indicates a hazardous situation which, if not avoided, could result in death or serious injury.

### **⚠CAUTION**

**CAUTION** indicates a hazardous situation which, if not avoided, could result in minor or moderate injury

### **NOTICE**

**NOTICE** is used to address practices not related to physical injury.

## **⚠WARNING**

### **THIS EQUIPMENT IS NOT INTENDED FOR MAINS VOLTAGES**

- MT-RX-3 was **NOT** designed to operate and/or be connected directly to live main voltages. The MT-RX-3 must be connected to a certified, suitably rated low voltage DC supply.

**Failure to follow these instructions can result in death or serious injury**

## **NOTICE**

### **HAZARD OF EQUIPMENT DAMAGE**

- This product is not chemical resistant. Detergent, alcohol, aerosol sprays, and/or petroleum products may damage the front panel. Clean using a soft cloth moistened in water.
- The radio can be damaged if there is any potential difference between the chassis-ground, Serial signal ground, power (-) input, or antenna coaxial shield. Before connecting any wiring, ensure that all components are earthed to a common ground point.
- The antenna port can be damaged if signals greater than 13 dBm are injected/received. Do not directly connect any other transmitter to the RF connector.
- Extreme Heat or High temperatures can damage MT-RX-3 components. DO NOT expose or operate the unit in extreme heat (above 70 degrees Celsius) or leave in direct sunlight or any other UV source.
- Although this product is designed to be rugged, it will not survive excessive shock or vibration abuse. The MT-RX-3 is intended to be mounted permanently either in a land based location or in a vehicle. When fitting in a vehicle, vibration damping mounts may be required.
- The MT-RX-3 IP rating is IP-51. MT-RX-3 is not waterproof or dustproof. DO NOT directly expose to rain or use in a condensation forming environment.
- When antennas are co-located on a community (shared) site the correct site engineering must be performed to ensure that RF exposure limits are met.

## FCC NOTICE

This device complies with Part 15.247 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference and
2. This device must accept any interference received, including interference that may cause undesired operation.

This device must be operated as supplied by the equipment supplier. Any changes or modifications made to the device without the written consent of the equipment supplier may void the user's authority to operate the device.

## NOTICE



This symbol on the product or its packaging indicates that this product must not be disposed of with other waste.

Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment.

The separate collection and recycling of your waste equipment at the time of disposal will help conserve natural resources and help ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, contact the dealer from whom you originally purchased the product.



## Operation

---

Once a power source has been connected to the power connector the MT-RX-3 start-up status is displayed on the LCD.

When the MT-RX-3 is operating normally, the two green status LEDs flash briefly once every second.

On start-up under normal operation there is a message sent out the serial port. The message indicates the firmware revision, serial number other software related information.

For all electrical wire connections please look the “**Installation**” Section in this manual

## Buttons

---



### **MENU/BACK:**

When on the MAIN SCREENS used to enter the MENU. When inside the MENU, used to return back one level from within the MENU, until returning back to the MAIN SCREENS.



### **UP:**

When on the MAIN SCREENS used to cycle between sub-screens. When in the MENU used to navigate or alter selected configuration items.



### **DOWN:**

When on file related screens of the MAIN SCREENS shifts between entries. When in the MENU used to navigate or alter selected configuration items.



### **RIGHT:**

When on the MAIN SCREENS used to cycle between main screen. Within the MENU used to enter sub MENU items or select items for configuration.



### **ENTER:**

Used to select file related items from within the MAIN SCREENS.


## Icon Bar









The MT-RX-3 top icon bar provides information about the display screen and operating status.

On this screen the battery condition, quality of GPS signal, alert indication and system time (auto set from a GPS source) can be monitored at a glance.

The far right text indicates the selected main screen. This is either “ALL”, “406”, “RSS”, “AIS”, “GPS” or “DF”. Pressing the RIGHT button cycles through these screens.

Each screen can have sub screens. When these are available, there is a small UP arrow next to the sub-screen number (shown as “1” on the example below). These screens can be accessed by pressing the “UP” button.




Icon	Description
	The far left battery icon indicates system voltage. When connected to an external supply, this icon displays always as a full battery.
	Indicates that there is no valid GPS signal.
	Indicates that there is a valid GPS signal. Flashes between this icon and a large BOLD number. This is the number of satellites used in the GPS fix solution.
	The alert shown on the screen is a distress message, and NOT a test.
	The alert shown is a TEST message.
	There currently is a signal present that has opened the squelch (better viewed on the RSS screen), that has been present for at least the configured TRIG period of time. This could be any signal that exceeds the configured squelch setting.
	A valid emergency homing signal has been detected for at least the configured TRIG period of time. This is the sweep signal that is present on 121.5MHz or 243MHz transmitted by 406 beacons and used for search and rescue final location. This icon takes priority over the “S” icon. The signal strength of the homing signal must also exceed the squelch setting.
	An alert has been raised based on the current ALERT configuration within the last 60 seconds.

## Summary Screen

This screen provides the best indication of recent activity on distress channels of interest. If the user has shifted from the main screen, after several minutes of inactivity the MT-RX-3 will automatically return to this screen.

The start up and main returning screen can be altered by the user to any screen (MENU->SYSTEM->MAIN SCREEN), e.g. to primarily display AIS vessel transmissions.



Activity on each distress channel is shown by the number of messages received on each channel within a 30 second time slot. On AIS channels, large numbers of transmission can be expected when SART AIS messages have not been filtered and in proximity to shipping channels. The AIS display can be configured to display only SART AIS messages.

On the top line of the screen shown there is “406” shown with a “01” then on the same line another “01”. Each dotted vertical line is used to mark the passing of one minute, allowing the activity of the last 5 minutes to be seen. On the 406 line it can be seen that there was a 406 transmission decoded approximately 20 seconds ago, and other nearly 2 minutes ago. If the number displayed “04” - then 4 messages have been decoded in that particular 30 second time slot.

From this top level screen, pressing the right button cycles through each technology specific summary screen. While on each screen, pressing the up button cycles through sub screens for each, providing access to logged results, live data as received and additional parameters.


## 406 Decode Screens

---

The 406 main screen provides several decode sub screens that display details regarding the 406 message processed. Recent database files stored on internal SD card provide translations from country ID to country name and also provide details of beacon model and manufacturer.



The decode history sub screen provides a means to view time-stamped entries, and also allows the entries to be selected to be used with the direction finding screen (see Target Setting).



## RSS Screen

The RSS “Received Signal Strength” and sweep detection screen provides a clear indication of signal strength, rapidly updated, and if connected to a directional aerial aids in final location of common man-overboard transmitters, 406 beacons and voice transmissions from many common transmitters. The RSS screen can be configured to display and provide an alert for any frequency from 120MHz to 470MHz, but particularly useful for the distress homing signals transmitted on 121.5MHz and 243MHz.

Alerts can be raised when the signal level has increased above a configured squelch level for the set trigger period. Optionally, and more usefully, an alert can be raised only when the 121.5MHz downwards sweep on the channel that will greatly decrease the probability of false alerts.



As shown above, when a signal level increases above -100 dBm for 3 seconds the RSS receiver begins to look for a valid sweep signal. The 'S' icon will now be displayed indicating that the RSS squelch is open.




If the downwards sweep is present for 3 seconds an alert will be raised (if RSS alerts are enabled) and the 'S' icon will change to the 'H' icon (to indicate that a homing signal has been detected). Any squelch level, squelch trigger period and sweep trigger period can be configured. Sweep detection can be disabled if required.

## AIS Screens

The top level AIS screen defaults to the graphical vessel summary, providing details of vessels within the area and direction of travel. AIS target and collision avoidance status can be viewed on this screen.

The vessels shown on the top level AIS screen are as follows:



Stationary vessel



Moving vessel, indicating direction.



Vessel expected to collide based on collision alert configuration (flashing).



Vessel set as a target (for direction finding using the DF screen).



Vessel that has not transmitted data in the last minute.



The AIS vessel list screen provides an ordered list of the closest vessels, updated as new transmissions are decoded. The last transmission from each vessel can be selected to provide additional information such as current location. Any vessel on this screen can be selected as a target by pressing the square button, allowing the Direction Finding (DF) screen to be used.


20:27:29		2 AIS	
DIST	BRG	SPD	MMSI/NAME
1.76	351	0.0	512161000
1.77	356	0.0	BLACKADDER
LAT	LONG	HDG	T
-43.60543	172.71969	075	0

The SART (Search and Rescue Transponder) screen provides information relating to AIS distress type transmitters operating on both 161.975MHz and 162.025MHz. These transponders are commonly used as man-overboard transmitters.


Information decoded on this screen is logged directly to SD card, and can be used to set as a target for direction finding to.



The AIS raw data screen displays decoded AIS packets from both channels in real time. The MT-RX-3 can be configured to output this data out the serial ports, that can then be used by PC based AIS mapping tools. All AIS single and double sentence messages are decoded. Variable length AIS messages are decoded up to a length of 2 sentences (AIS transmissions greater than 2 sentences are rare).



The decode history sub screen provides a means to view time-stamped entries, and also allows the entries to be selected to used with the direction finding screen (see Target Setting). Only AIS-SART messages are listed in the history.






## GPS Screen

The GPS screen provides details of the GPS data that is provided to the MT-RX-3 for direction finding. If the GPS anchor feature is currently in use, the distance from the anchor set location is shown – see “GPS Anchor”.



GPS	
LAT	S SPEED
43°40.238'	5.0
LONG	E HEADING
172°51.000'	0.0
GPS ANCHOR	GPS TIME
185 M	13:33:05

The GPS raw data sub screen provides real time updates of provided GPGGA and GPRMC NMEA sentences that are used to determine the current location, quality of fix and time.



```

GPS
GPGGA,123519.4,807.038,N,01131
.000,E,1.08,0.9,S,4S.4,M,46.9,M,
#47
GPRMC,123519.4,A,4307.038,S,172
31.000,E,0.00,0.084.4,230394.00
3.1,W#7C
GPGGA,123519.4,807.038,N,01131
.000,E,1.08,0.9,S,4S.4,M,46.9,M,
#47

```

## DF Screen

The GPS DF (GPS direction finding to target) provides an indication of the current target that has been selected, bearing and distance to that target. The operation and use of the DF screen is better described in the “Target Setting” section. While in this screen voice prompts can be enabled to allow direction finding to the target without the need to look at the screen.

The DF screen allows direction finding to 406 and AIS transmissions, and also to manually entered waypoints.

*Note: This screen relies on the connection of a GPS signal (or for a position to be manually entered), and for the alerting device to be transmitting its position.*



## Alert Operation

The MT-RX-3 can be configured to raise an alert through the on-board relay or sounder under a variety of conditions. The duration of sounder operation and relay operation can be independently configured via the alert menu system.



406 alerts can be raised for transmissions that are:

- General Distress.
- General Distress plus any test transmission.
- General Distress plus any ID matching the 406 IDs stored in the 406 Selective Database.

AIS alerts can be raised for transmissions that are:

- Type 1 messages, status 14 (SART active)
- Type 1 messages, status 14 plus status 15 (SART test).
- Within a configured distance, providing a simple proximity alert. Separate “warning” and “alert” distances can be configured.
- Determined to be on a collision course, based on direction of travel, speed and safe area distances configured – see “Collision Avoidance”.

RSS (Received Signal Strength) alerts can be raised for transmissions that are:

- Within a configured frequency of 120MHz and 470MHz.
- Above a configured signal strength threshold.
- Above a signal strength for a configured period of time or determined to contain a valid downwards sweep signal for a period of time.

GPS Anchor alerts can be raised when moving outside the safe anchor radius for a set location.

Upon reception of a configured alert message type, the relay is closed for the configured period of

time (set via the alert menu system) and the sounder operates independently for a configured period of time (heard through internal speaker).

### **Sequence of events when an alert is processed:**

1. Relay Operates (for configured period of time).
2. Sounder Operates (for configured period of time).
3. The display shifts to either the 406, 121 or AIS decode screen as appropriate (except if already on the DF (direction find to target) screen).
4. An alert pop-up to indicate a new alert is displayed (if this is a new alert).

If there is an ID and location available for the alert (not applicable for 121.5 alerts) :


5. The decoded alert message is logged to SD Card.
6. The ID of the alert (406 hex 15 ID or AIS MMSI) is stored.
7. The configurable duplicate reject timer is started (preventing the same ID raising another alert until a period of inactivity has elapsed).
8. If not already on the DF screen, the ID and location of the alert ID is automatically set to the active tracking target ID (but will not automatically shift to this screen).

When any key is pressed the sounder will cease and the relay will open.

## Spectrum Analyser

The optional spectrum analyser is a very simple to use tool that provides a span of either 120kHz or 3MHz around a configured test frequency. The receive bandwidth of 1kHz is suitable for inspection of potentially interfering adjacent channel signals. The analyser can display signals as low as -125dBm. Use for site inspection or to view a large range of frequencies, hugely simplifying search and rescue efforts looking for a channel that someone is talking on, or can be used to direction find to with a directional antenna.


This is a low cost optional feature, that requires a feature key to be purchased.



## MT-RX-3 Configuration

---


At any time the “MENU” button can be pressed that will enter the configuration menu. The receivers continue to operate normally and can raise alerts while in the menu system.



At any time the active buttons that may be pressed are shown on the screen, such as the “MENU”, “UP”, “DOWN” and “RIGHT” buttons. Using the above screen as an example, pressing the “RIGHT” button will enter the “ALERTS” sub menu. When reaching any configuration item, pressing the “RIGHT” button again will highlight the item to change.

Once inside the menu, pressing the “MENU” button again will go back up one level until the menu mode is exited. All configuration changes are written to file only when leaving menu mode.

## SPECTRUM Menu



### SPECTRUM

Displays the radio spectrum using the settings in this menu. Signals between -128dBm and 0dBm can be displayed. **Power levels above 17dBm (50mW) will destroy the receiver input.**

### CENTRE

Displays the centre frequency to be displayed on the screen.

### HZ/DIV

Either 10kHz or 250kHz. The screen is 6 divisions wide in 120 steps.

When on the 10kHz setting the RBW (receiver bandwidth) is set to 1kHz. The span on this setting is 120kHz, allowing for adjacent channel power to be observed.

When on the 250kHz setting the RBW is set to 25kHz. The span on this setting is 3 MHz.

### SAMPLE

When set to CONT the spectrum analyser screen will be updated with new values approximately twice a second. When set to PEAK only higher values will be written to the screen. At any time, the ENTER button can be pressed on the SCREEN to clear the screen and load new PEAK values.


### BASE

Defines the base signal level on the screen. When set to -100, only signals with a strength greater than -100 dBm will be displayed. Range is -130 dBm to -60 dBm.

### dB/DIV

Scales the signal level displayed. Either 10 dB/DIV or 20 dB/DIV can be set. When 20 is set a dynamic range of 120 dB is possible.

## Alerts Sub Menu



### 406

Items ACTIVE ONLY, ACTIVE+TEST and ACTIVE+DB can be selected.

ACTIVE ONLY:

Only distress transmissions will activate an alert and close the relay. All test transmissions are logged and displayed, but will not raise an alert.

ACTIVE+TEST:

Both distress AND test transmission will result in an alert being raised.

ACTIVE+DB:

All distress transmissions AND any test transmission that matches an ID in the 406 selective database will result in an alert being raised.

### AIS-SART

Items ACTIVE ONLY and ACTIVE+TEST can be selected.

ACTIVE ONLY:

Only AIS type 1 messages status 14 transmissions will activate an alert and close the relay. All test transmissions are logged and displayed, but will not raise an alert.

ACTIVE+TEST:

Both AIS type 1 messages status 14 transmissions AND status 15 test transmissions will result in an alert being raised.



## AIS PROXIMITY

Allow generation of warnings and alerts for the distances configured in the AIS menu.

Items ENABLED+WARN, WARN ONLY, DISABLED and ENABLED can be selected.

**ENABLED:**

When selected, when any AIS transmission that is determined to be less than the configured PROX ALERT DIST will result the relay and sounder operating.

**ENABLED+WARN:**

In addition to the same functionality as the ENABLED setting, this setting also provides an short duration audible warning and screen pop-up when any AIS transmission that is less than the configured PROX WARN DIST distance.

**WARN ONLY:**

When selected, upon reception of any AIS transmission that is less than the configured PROX WARN DIST will result in a short duration audible warning and screen pop-up. This setting will result in the relay NOT closing.

**DISABLED:**

No AIS proximity alerts or warnings will be generated.

## AIS COLLISION

Allows the generation of collision alerts based on the settings configured in MENU->AIS->COLLISION.

Items ENABLED and DISABLED can be selected. See “AIS Collision Avoidance”

## GPS ANCHOR

Sets the allowed travel distance before raising an alert. Distances from 5 – 500 meters can be set. The GPS Anchor feature is set from the GPS main screen, not in the menu – see “GPS Anchor”

## RSS

The RSS (Received Signal Strength) alert when enabled will operate the relay and sounder as configured. Disabling will result in no alert being raised.

## RELAY TIME

The time in seconds that the relay will close for when an alert is raised. Pressing any button after an alert is raised will result in the relay opening again. The relay will be able to operate again after the source of the alert has been absent for the DUP REJECT TIME.



## SOUNDER TIME

The time in seconds that the on-board sounder will operate for when an alert is raised. Pressing any button after an alert is raised will result in sounder operation ceasing.

## DUP REJECT TIME

The duplicate reject feature determines the period of time that must pass before an alert of the same ID or type will raise an alert again. Typically alert transmissions are sent every minute. Raising a new alert that needs cancelling again every minute when tracking an alert is not typically desirable. When the feature is set to a non-zero value a duplicate reject timer is restarted each time the same ID is received. If the transmission source was to cease for this period of time, then restart, a new alert would be raised. When set to 0, the feature is disabled and a new alert is raised for each transmission. The duplicate reject applies to AIS, 406, RSS and PROXIMITY alerts. Once an RSS alert has been raised, the signal level must decrease below the trigger threshold for the duplicate reject time before a new RSS alert can be raised.

## System Sub Menu



### LANGUAGE

The currently used language. Currently only English and Spanish are included. Please advise if you require translations for another language.

### BACKLIGHT

This is the time in seconds that the backlight stays on for after each key press. The backlight may be set between values of 0 and 30. A value of 0 results in the backlight being disabled, a value of 30 results in the backlight being permanently on.

### TIME

Setting of the internal real time clock. This is automatically updated from a GPS source if present.

### SOUND

Setting to OFF prevents the sounder from operating and disables all system sounds except when an alert is raised.

### RS232 BAUD

Sets the baud rate of the RS232 port to either 2400, 4800, 9600 or 38400 N:8:1. Equipment can be connected to either the RS232 or RS422 ports, or to both simultaneously.

## RS422 BAUD

Configuration of baud rate of the RS422/RS485 port. The port is configured to N:8:1

## MAIN SCREEN

This allows any page on any main screen to be set as the default main screen. This results in this screen being the screen that is first seen when powering up the unit, or after a period of inactivity the MT-RX-3 will automatically revert to this screen.

Setting to DEFAULT will unset the last custom set screen and will return to the factory default main screen. Setting to USER SET will set the screen to be the screen that was last used before entering the menu.

## ANTENNA POS

Selects the antenna to use. 0 is right lower, 1 is left lower, 2 is left upper and 3 is right upper. During normal operation the antenna can be switched using the command serial command \*C40=x<CR>. Defaults to right lower on factory reset.

## FACTORY

Tools for factory calibration and testing purposes only.

## SET DEFAULTS

Allows all configuration items to be reverted to the default factory new state. When the confirm pop-up is selected, pressing the RIGHT button will allow the tick to be selected. Pressing the square ENTER button will now allow defaults to be set. Default settings will only be applied when leaving the menu.



## TEST

Allows testing of the unit by generating test messages as if they had been decoded by the unit under normal operating conditions. If a “406-TEST” test is performed, and the unit has been configured to ignore test transmissions, then there will be no change to the unit behaviour. The same applies for AIS SOS and TEST options.

Pressing the RELAY option provides a simple method to check relay operation.

Pressing WAVE allows playback testing of wave files from the SD card.

## **REGULATORY**

Regulatory items such as FCC-ID\*. The MT-RX-3 does not transmit any radio signals.

\*Note: Publication number 784748-D01, FCC-Part 90 allows for devices with integrated display to not require a printed label on the device holding this information.

## DF Sub Menu



DF	
WAYPOINT TARGET	DISABLED
WAYPOINT LAT	43.550 S
WAYPOINT LONG	172.300 E
VOICE REPEAT	60 S
BEARING	RELATIVE
DEF POSITION	DISABLED

### WAYPOINT TARGET

When enabled the DF screen uses the WAYPOINT LAT and WAYPOINT LONG settings to navigate to. It is not possible to permanently enable this setting and is reset after being activated. Reset of this option is to ensure that normal preference on startup is to set a target to a new 406 or AIS alert, not a previously set waypoint that may not longer be current.

### WAYPOINT LAT

Waypoint latitude to use when the WAYPOINT TARGET is enabled. This setting is stored with other configuration data, but not actively used unless the WAYPOINT TARGET has been enabled.

### WAYPOINT LONG

Waypoint longitude to use when the WAYPOINT TARGET is enabled. This setting is stored with other configuration data, but not actively used unless the WAYPOINT TARGET has been enabled.

### VOICE REPEAT

This setting controls how frequently the voice prompt operates that provides a bearing and distance to the selected target. If the system sound is disabled, then the voice prompt will not be heard.

Setting to 0 disables the voice repeat frequency.

### BEARING

Items RELATIVE and TRUE can be selected. The relative setting will generate the “Relative Bearing to Target...” voice prompt. The bearing is expressed as 0-360 degrees relative to the current direction of travel.

The TRUE setting provides the “True Bearing to Target...” voice prompt. This bearing is relative to true north.

## **DEF POSITION**

When ENABLED the MT-RX-3 will use the configured default latitude, longitude and heading until an externally provided GPS position has been provided. This means that if the MT-RX-3 is used in a fixed position, such as in a building or oil rig, the heading and distance to an alert can be determined without the need to connect an external GPS source.

## **DEF LAT**

Default Latitude for use when the default position is enabled.


## **DEF LONG**

Default Longitude for use when the default position is enabled.

## **DEF HEADING**

Default heading for use when the default position is enabled.

## NMEA OUT Sub Menu



### OUTPUT

When ENABLED the configured NMEA output sentence will be sent out the serial port once every second only after a 406 message with a valid position has been decoded. The NMEA output will be at the rate configured in the SYSTEM sub menu. Typically the NMEA output should be configured to be 4800 baud which is the default rate for NMEA 0813 compatible equipment.

The MT-RX-3 has both RS232 and RS422/485 serial interfaces for connection to a variety of NMEA systems.

### TYPE

Items WPL, RMB, BWC and GLL can be selected. This is the NMEA sentence type that will be used when there is valid information to display. The type WPL or BWC should be used when possible, since these sentence types when used with the MT-RX-3 allow not only the position of the alert to be displayed, but also the nature of the alert in the form of a way-point, such as 406-SOS.

Activating Alert	WPL and BWC Waypoint Tag Used
406 Beacon Distress Transmission	406-SOS
406 Beacon Test Transmission	406-TEST
406 Beacon Transmission in Database	MOB-1, MOB-2, MOB-3... indicating entry in database.
NMEA Test Output	TEST



NMEA Sentence Type	Typical NMEA Output
WPL	\$GPWPL,3751.65,S,14507.36,E, <b>406-SOS</b> *77
RMB	\$GPRMB,A,,,001,MOB,3751.65,S,14507.36,E,,,V*88
BWC	\$GPBWC,,3751.65,S,14507.36,E,,,,,, <b>406-SOS</b> *99
GLL	\$GPGLL,3751.65,S,14507.36,E,*93

## TEST

When ENABLED the NMEA output test feature is enabled, using the TEST LAT and TEST LONG settings. This allows testing of a navigation system without the need to activate an actual 406 beacon. For this feature to operate the OUTPUT must be ENABLED. The configured TYPE will be used for the duration of the NMEA output test. This setting is not persistent; cycling power to the MT-RX-3 will always result in the feature being disabled. If the feature is enabled and an actual 406 message is decoded, the test setting will be automatically disabled.

## TEST LAT

Latitude for use when the NMEA output TEST is ENABLED.

## TEST LONG

Longitude for use when the NMEA output TEST is ENABLED.

## AIS Sub Menu



### COLLISION

Allows all collision avoidance parameters to be set – see “Collision Avoidance”

### PROX ALERT

Defines a vessel “safe distance” from the current position before raising an alert (note that proximity alerts must also be enabled in the ALERTS menu).

### PROX WARN

Defines a vessel “safe distance” from the current position before raising a warning. A warning is a lesser audible alert and does not operate the relay. (note that proximity alerts must also be enabled in the ALERTS menu).


### DISPLAY

Setting to SART ONLY will result in ONLY AIS type 1 status 14 and 15 messages being displayed on the summary screen. Setting to ALL displays all AIS messages on the summary screen. This setting does not affect the ability to raise an alert or use any AIS feature.

### RS232 OUT

Setting to ENABLED outputs all SINGLE sentence AIS messages out the RS232 port at the rate configured by the SYSTEM baud rate. This output can be used by navigation equipment that can accept standard “!AIVDM” NMEA style messages. The system baud rate typically should be configured to be 38400 baud if this feature is used.

## RSS Sub Menu



### FREQUENCY

This is the frequency used by the Received Signal Strength alert and RSS screen. The FREQUENCY parameter can be set between 120MHz and 470MHz. By default 121.5MHz is configured.

### SQUELCH

This is the signal level that the received signal must exceed (for the SQUELCH DELAY period) in order to raise an alert.

### SQUELCH DELAY

This is the time in seconds that the measured signal must have exceeded the configured SQUELCH level before an alert is raised. Each time the signal drops below the SQUELCH level the SQUELCH TRIG (as shown on the RSS screen) is reset and the full delay period must elapse again before an alert can be triggered.

If under normal operation the “S” icon is seen frequently (due to interfering signals in proximity), the SQUELCH level should be increased until the “S” icon is no longer seen under normal operation.

### SWEEP DETECT

This item can be set to DISABLED or a value between 1 and 20. When DISABLED, an alert can be raised without the need to detect a valid sweep. When set to between 1 and 20, the sweep signal

must be present for this period of time before an alert can be raised.

## SCAN RATE

This option is used in conjunction with the SERIAL OUT option. This item can be set to DISABLED when set to 0 or to a value between 0.1 and 3.0 seconds. When setting to DISABLED there is no signal strength scanning of the set frequency. The user may wish to alter this setting in particular when sending the RSS value to the serial port in an application that requires a relatively high rate of signal strength reporting. The SCAN RATE option increases internal noise, and results in a degradation to AIS receiver sensitivity. This option would not normally be used unless the MT-RX-3 is under external software control, and used for a short duration of time. A setting of 1.0 would result in no noticeable degradation in performance.

## SERIAL OUT

This item can be set to DISABLED or ENABLED. Setting to ENABLED will result in a signal strength sentence to be sent to the serial port at the SCAN RATE configured above. There will be no periodic serial output if the SCAN RATE is DISABLED. If SCAN RATE is DISABLED and SERIAL OUT is ENABLED, there will be serial output only when the signal strength is above the configured SQUELCH level.

The serial output format for the RSS frequency is:

SS,1,NNN<CR>


where NNN is a value between 0 and 255. This value is not calibrated, but is approximately:  
 $-130 + (NNN / 2)$  dBm.

When an RSS is above the SQUELCH level the following serial output is generated, regardless of the alert setting.

SS,A,NNN<CR>

NOTE: An RSS alert can only be raised when RSS alerts have been enabled in the ALERTS menu.

## 406 Selective DB Sub Menu



This sub menu allows 406 hex 15 beacon IDS to be manually entered. Entries in this menu will take no effect unless the 406 alerts option ACTIVE+DB has been selected.

## AIS Collision Avoidance


The collision avoidance system is a highly configurable feature that allows alerts to be raised should a collision condition arise.

If a vessel that is transmitting AIS data remains stationary and the MT-RX-3 is moving towards the vessel or the vessel continues on a collision course, then an alert can be raised.

In order to use the collision avoidance system:

1. Enable the collision avoidance alert from the ALERTS menu.
2. Configure the collision avoidance system found in MENU->AIS->COLLISION.
3. Set the TEST RADIUS. This is how far from the current location that vessels are evaluated for a collision condition. Setting the TEST RADIUS to a very large value such as 20 KM may not add any value and would result in unnecessary false alerts – unless perhaps if accidentally anchoring in a shipping lane.
4. Set the SAFE RADIUS (also described as CPA, or Closest Point of Arrival). Should a vessel be allowed to continue on its current course (or the vessel that the MT-RX-3 is part of) and the vessels may intersect within the SAFE RADIUS, then an alert may be raised.
5. Set the WARN TIME (also described as TCPA, or Time to Closest Point of Arrival) to define how long in advance an alert should be given. Having considered the speed and direction of the vessels, this is the prior notice that will be given before a vessel enters the SAFE RADIUS. NOTE: if the TEST RADIUS is very small, and the speed of the vessel is very high, then the full configured WARN TIME may not be possible.

As with the TEST RADIUS, setting WARN TIME to a very large value, such as 60 minutes, may result in many unnecessary false alerts.



When a collision alert is notified via pop-up the collision alert can be cleared by either:

- Turning away from the object of likely impact (shown as the flashing “collision” icon).
- Or acknowledging the collision alert by pressing any button.

If the collision alert is cleared, turning away from the collision source, then turning back to a potential collision condition will result in the collision alert being raised again.

When a collision alert has been acknowledged, approaching a vessel without further alerts is possible. After acknowledging an alert, collision alerts from other vessels will still be raised.

## AIS SART Transmission Logging

---

All message type 1 status 14 and 15 messages are logged to SD card. Logging is performed for all messages of the configured alert type regardless of whether they are duplicates.

All AIS data is stored to the file AIS-DAT.CSV and logged in the format:

```
#16:25 00/00,548206000,-43.6050 172.7154,!AIVDM,1,1,,2,18:kmd>000<F`>IW38j:06522000t0,4*57
```

where each entry begins with the '#' character, followed by time and date, SART ID (usually MMSI), position and full legal AIS type 1 message that generated the alert.



## GPS Anchor

---

The GPS Anchor allows for an alert to be raised when a GPS position has been set and then the vessel drifts from that set location.



To use the GPS Anchor:

1. In MENU->ALERTS->GPS ANCHOR set how far the MT-RX-3 is allowed to “drift” before raising an alert. This setting is saved, and needs only to be configured once.
2. Enable the GPS Anchor. This can only be performed from the GPS screen and if there is a current GPS fix available. From the GPS screen press the square button.

Pressing the square button again will unset the GPS anchor, and allow a new position to be set when the square button is pressed again.

The GPS ANCHOR field on the GPS screen will now display the distance in meters from the set position and confirms that the GPS anchor feature is active. Removing power to the MT-RX-3, then applying power again will result in the GPS anchor alert being cleared.

## 406 Beacon Transmission Logging

---

All COSPAS-SARSAT 406 messages are logged to SD card. Logging is performed for all messages of the configured alert type regardless of whether they are duplicates.

All 406 data is stored to the file 406-DAT.CSV and logged in the format:

```
*10:10 16/01,C00B19F875940D1,-43.6050 172.7154,FFFED060058CFC3ACA068FABCF9C8F14CDBC
```

where each entry begins with the '\*' character, followed by time and date, 406 Hex 15 ID, position and full binary content of the transmission.

## Decoded 406 Message Serial Output

---

### MT Serial Out Packet Format

Data provided from the MT-RX via serial ports/TCP is in the following format:

**MT1UUUNNTFHHHHHHHHHHHHHHSS112233N4445566WYYYY**

Where:

**MT1** is fixed and actually “MT1”

**UUU-** is a 3 character MT-RX configurable ID – by default this is “001”

**NNN** - is a 3 decimal digit cycling packet sequence number from 000 to 511. This sequence number increments after each new test or distress message is received. After 511 the sequence cycles to 000 and begins again.

**T** – is a single character message type 'T' or 'A' (test or distress alert)

**F** – is a single character format flag 'S' or 'L' (short or long) – this relates to the 406 beacon transmission specification.

**HHHHHHHHHHHHHHHHHH** – is a 15 character hex code used to define beacon owner and beacon capabilities as per the 406 beacon specification.

**SS** – is a 2 character signal strength indication – “00” if not used.

**11** – is a 2 decimal character latitude degrees

**22** – is a 2 decimal character latitude minutes

**33** – is a 2 decimal character latitude seconds

**N** – is 'N' or 'S'

**444** – is a 3 decimal character longitude degrees

**22** – is a 2 decimal character longitude minutes

**55** – is a 2 decimal character longitude seconds

**W** – is 'W' or 'E'

**YYYY** – is a 4 character checksum (calculated from M – the first character)

If all location characters are '-' then there is no location information available.

Legitimate example packet:

**MT1001000AL400C592753572B323433212S1723756E4706**

From firmware revision v1.88 the raw data output packet is supported.

**MT6UUUNNNRRYYY**

**MT6** is fixed and actually “MT6”

**UUU-** is a 3 character MT-RX configurable ID – by default this is “001”

NNN -is a 3 decimal digit cycling packet sequence number from 000 to 511. This sequence number increments after each new test or distress message is received. After 511 the sequence cycles to 000 and begins again.

RRR.. is 36 characters of raw data in a hex format.

**YYYY** – is a 4 character checksum (calculated from R – the first raw data character)

Legitimate example packets:

MT6001001FFFE2FA00E0000CBAB959DB0903788C71B79F84B

MT6001001FFFE2FA0062C93A9AB959E55EE7788C71B791131

The 4 character rolling left checksum, starting at position 9 (start of the raw data payload).

**Example Usage:**

```
if (calculateChecksum(36, "FFFE2FA00E0000CBAB959DB0903788C71B79") == 0xf84b) {
```

```
        return CHECKSUM_GOOD;  
    } else {  
        return CHECKSUM_BAD;  
    }
```

## AIS Serial Messages

---

All AIS serial messages are provided in a standard raw format such as:

**!AIVDM,1,1,,B,13PRrB0000OvbS@NhA9=oPbr0<0u,0\*58**

This output format is suitable for the connection to many PC based AIS mapping applications. This is a standard output format for most AIS receivers – please consult internet resources for further information regarding these messages.

If there is a need to be provided with fully decoded AIS sentences via the serial port, such as MMSI, vessel name etc, please contact [info@wte.co.nz](mailto:info@wte.co.nz)

All messages of all types are decoded up a length of 2 AIS sentences – for further information regarding the decoding of AIS messages consult the AIS specifications that are available on the internet.

## Target Setting


The MT-RX-3, when a GPS position is presented via internal or externally supplied NMEA sentence, can provide a bearing and distance to a specified target. When the MT-RX-3 is first powered on, the target is unset. Viewing the “DF” screen (direction find to target) the status “NO TARGET” will be shown.



If the current location is unknown through the absence of a NMEA RMC sentence, then determination of distance and bearing to target is not possible (unless a DF default position has been configured through the menu). When a distress message (406 or AIS) that matches the alert configuration settings for the MT-RX-3 (that would result in an alert being raised) is received the target and the target is currently unset, the target will automatically be set to the ID of that alert (even if the alert does not provide a position). When an alert is activated the “ALERT” pop-up is shown, and the active screen moves to either the top level 406 or AIS screen as appropriate.

Manually moving to the “DF” screen will show the bearing and distance to the target only if the current location is known AND the 406 or AIS transmission has provided a valid position.

Optionally a waypoint can be manually entered through the menu system (MENU->DF). Any waypoint can be entered that will then be shown as a DF target of “WAYPOINT”.



When a new alert message is decoded, the target will **NOT** be updated if the target has a different ID (but an alert will still be raised). If a new message has the same ID the location of the target will be updated.

To set a new target the square “ENTER” button must be pressed while on the top level 406 or AIS screen. Using this method it is possible to browse through the file history of decoded 406 or AIS messages and set any of those messages as a new target.

To Set a Target To Last 406 or AIS transmission:


1. Move to either the 406 or AIS screens.
2. To set this entry as the target now press the “ENTER” button.
3. The pop-up “TARGET SET” will be displayed.
4. The DF screen will now show bearing and distance to this new target.

To Set a Target From File:

1. Move to either the 406 or AIS screens.
2. Press the “UP” button until the log screen is shown.
3. Press the “DOWN” button to select the ID of the transmission to VIEW (target has not been set yet).
4. Press the square “ENTER” button.
5. The screen will automatically move to the top level display screen and show details for that file entry (showing the record number at the top instead of the current time).
6. To set this entry as the target press the “ENTER” button.
7. The pop-up “TARGET SET” will be displayed.
8. The DF screen will now show bearing and distance to this new target.



While on the target screen periodic voice messages will be announced indicating the distance and required bearing to target.





## 406 Selective Decode

---

The WTE patented selective decode feature allows a database to be built of beacon hex ID codes within the decoder.

This means that the decoder will only activate the alert output when a 406 transmission has been received by beacons with the matching unique ID.

Using this technology, new systems can be developed using powerful 406 beacons to instantly provide a distress alert, either using the test button or fully activating the beacon. In many cases immediate assistance can be provided without the need to notify search and rescue.

These systems are secure, and will not result in a false activation from beacons being tested or that have been activated in the wider surrounding area.

Because the MT-RX-3 can lock to a 406 signal anywhere in the 406 band extremely quickly (due to its DSP architecture), only a single transmission is required to operate the MT-RX-3 relay – this means that only a single “Test” transmission is required in order to operate.

## 406 Selective Decode Applications

### **Man-Overboard Alarm**

The MT-RX-3 is perfectly suited as the foundation of a marine 406 man overboard system, providing an instant alert, with very high range capability.

A vessel for example may have 20 crew, all with PLB devices fitted to life jackets. Each of the PLB hex codes can be programmed into the MT-RX-3 decoder. This means that the decoder on a vessel can be alerted by the press of the test button from any of the crew members, or by full activation of the beacon. The MT-RX-3 will not produce any false alarms from other beacons in the wider surrounding area.

A PLB has a much higher power output than most other man overboard systems, so can have a higher range from the vessel. PLBs are also becoming increasingly more affordable, and are now a similar price to traditional Man-Overboard transmitters. The decoder when used for this application can still provide position information to crew members on the vessel, that can then be processed by a connected mapping tool. All activations would be logged normally.

### **Diver Resurfacing Alert**

The MT-RX-3 is well suited to provide a diver resurfacing alert. A resurfacing diver, if carrying a PLB, can in distress press the test button on a beacon and signal for assistance from the dive boat with or without notifying the emergency services.

There is no chance of false alerts from beacons being tested or activated in the wider surrounding area, messages are all logged and notification is instant. If a beacon is fully activated, the position can be provided by the decoder allowing early diver location in an emergency situation.

### **Yacht Club Distress Monitor**

A shore-based MT-RX-3 receiver can be programmed with the 406 PLB or EPIRB hex codes assigned to yacht club boats or assigned to individuals.

In a distress situation, an alarm can be raised before a situation escalates to a point that would require the involvement of the emergency services. The test button can be pressed on the 406 beacon, or a full emergency alert raised. Notification to the MT-RX-3 receiver is instant. The MT-RX-3 can be configured to control a siren, light or if connected to the supplied PC application display the beacon hex ID or alert position.

The MT-RX-3 will not suffer from false alerts from other beacons being tested or activation in the wider surrounding area.

### **Anti Theft Vessel Control**

A PLB programmed into the selective database can provide a method to disable a vessel or active a tracking device from a considerable distance from a vessel.

Any standard 406 beacon of any kind can be used.

**Note: Alert position is not provided by the test button press of all 406 beacons. Typically 406 transmitters that support sending of location information in the test transmission require a different mode of activation, such as holding the test button for 5 seconds.**

## Installation

---

The MT-RX-3 should be situated away from direct sunlight, extreme vibration and heat sources, and high power transmission sources.

An external aerial correctly designed to operate at 406MHz will result in best performance (if 406 is of primary importance), otherwise use an aerial that best suits such as 162MHz (for AIS) – performance will be degraded at other frequencies but will still operate acceptably in most cases.

Do not situate the aerial immediately next to the aerial of a high power transmission source – position greater than 2 M from any other aerial. Mount the external aerial with as much elevation as possible for best results (see “Aerial Elevation” below).

Maximum tolerated input power into the decoder BNC connector is 17dBm. Connecting directly to a 406 beacon will result in certain damage. Signal strength measurements are accurate to within 0.5dB, but are relative and not calibrated. Power strength recording can be performed by using a reference beacon and comparing results against the tested or calibrated reference.

## Connecting to the MT-RX-3

The minimum required connections for a usable system:

1. Connection to an aerial.
2. Connection to a 12V supply.

**Optionally** the MT-RX-3 may also connect to:

- An external GPS source.
- A chart plotter or navigation system (that can also be a GPS source).
- A PC based mapping system.
- External sounder controlled via the on-board relay.
- A network through the Ethernet port.

## Configuration Methods

---


There are several methods to configure the MT-RX-3 unit, such as:

- Directly from the front panel
- Via a web browser (mirrors the LCD and buttons).
- Via Serial terminal over the RS232, RS422 and or RS485.
- Via a TCP terminal or socket (either client or server)
- USB connection and editing of the WTE\_CONF.INI configuration file.

## Web Browser Configuration

For web browser configuration to be possible (using “Chrome”), the Ethernet/IP must be **ENABLED** via the menu (**ENABLED** by default). This is located in **SYSTEM->IP**. In this menu section network parameters can be configured such as the IP, Mask and gateway.


Only a single connection to the MT-RX-3 should be allowed. Multiple connections will result in impaired responsiveness.



TCP-IP	
TCP-IP	WEB+SERVER
HOST	
LOCAL IP	192.168.001.021
REMOTE IP	192.168.001.002
MASK	255.255.255.000
GATE	192.168.001.001

After the unit has been enabled to be use over the web, a web browser address matching the configured IP should be used. e.g.

<http://192.168.1.21>



## Serial Command Configuration

---

Most items that can be changed via the MENU can also be changed through serial commands or through direct modification of SD card configuration items.

Refer to the application note MT-RX-AN003.pdf for a full list of serial commands.

There are some additional commands that make the MT-RX-3 more usable when being managed via a serial connection. These are listed immediately below.

### **\*USERPASS**

Sets the web and TCP user and password. User must be at least 3 letters and password must be at least 4 letters. These credentials are requested for each new web and TCP connection.

*\*USERPASS=admin:MT-RX-3<CR>*

When prompted for a login when using a TCP connection (not through web browser), login with the full user and password together.

e.g. in response to “login:”

enter

*“admin:MT-RX-3”*

The MT-RX-3 will immediately report if successfully logged in.

To completely disable all web and TCP connection user and passwords, enter

*\*USERPASS=none:none<CR>*

*\*SAVE<CR>*

*By default the user and password is set to “none:none”*

## MT-RX-3 Firmware Upgrade

---


In order to update the MT-RX-3 primary firmware you will need:

1. The WTE Firmware Update Tool (available from <http://www.wte.co.nz> or provided if required from [info@wte.co.nz](mailto:info@wte.co.nz)).
2. One USB mini B cable.
3. An appropriate encrypted hex file supplied by WTE Limited.

*Note: Attempting to load a hex file not intended for use with the MT-RX-3 will render the MT-RX-3 inoperable. Uploading firmware should only be performed if instructed to do so by WTE Limited or an authorised agent.*

### Firmware Upgrade Utility


This bootloader software has been customised by WTE to simplify the firmware replacement process for the MT-RX-3. This application automatically handles erasing and verifying of uploaded firmware. This utility does not perform any decryption function (decryption is carried out by the MT-RX-3 itself).





## Upgrade Process

1. Run the application WTE-UBL.exe – this is the WTE Firmware Update Tool as shown above.
2. **BEFORE** applying power to the MT-RX-3, press the “UP” button, and **HOLD** the button down.
3. Apply power to the MT-RX-3.
4. The MT-RX-3 backlight will flash on and off (approximately once every second) – **keep the “UP” button pressed**. You now have 10 seconds to press the PC application “Connect” button on the WTE Firmware Update Tool before the MT-RX-3 exits the bootloader mode of operation.
5. Press the WTE Firmware Update Tool “Connect” button. If connected, the PC application will display the message saying “Device Connected”. The MT-RX-3 backlight will now stay constantly on.
6. You can now **RELEASE** the MT-RX-3 “UP” button.
7. On the PC application press the “Load Hex File” button.
8. Select the supplied MT-RX-3 hex file. NOTE: the firmware used must **MATCH** the MT-RX-3 receiver variant. A MT-RX-3 can only be used with MT-RX-3 encrypted firmware. Failure to comply will leave the device inoperable.
9. Press the WTE Firmware Update Tool “Program” button.
10. Wait for the WTE Firmware Update Tool to indicate that programming has been completed.



11. When programming is complete press the “Run” Button, or remove power to the MT-RX-3 and apply power again.
12. If successful the MT-RX-3 will start normally when power is applied. If the MT-RX-3 does not correctly start, then repeat the procedure.

## Support for Portable and Battery Powered Applications

The MT-RX-3 is very light and well suited for applications that rely on low weight. The MT-RX-3 has been supplied for portable search and rescue, and small aircraft applications.

The unit can be powered from a 6-9 volt battery source through connection to the external power terminals. Power to the unit can be controlled via a simple external switch. A power supply voltage of above 9 volts is required for audio alerting.


Optionally, and at a small additional cost, the MT-RX-3 can be supplied with low power shutdown capability. When this option is selected, an external power switch is not required (only connection is a direct connection to battery). The MT-RX-3 can then be configured to auto shutdown after a period of inactivity.

## AIS OpenCPN Support

The MT-RX-3 has been tested with the free OpenCPN mapping PC application. In many cases free maritime maps are available, such as is the case for New Zealand.


In order to use OpenCPN, ensure that AIS serial output has been enabled (MENU->AIS->RS232 OUT) and the RS232 baud rate has been set to a suitable rate for the application (MENU->SYSTEM->BAUD). Typically a baudrate of 38400 would be used for AIS receivers.

By default the MT-RX-3 is supplied with RS232 support, but can be provided with an optional RS422 internal module that may provide improved compatibility with some NMEA navigation systems.




## 406 Decoder PC Application

When connected to the optional 406 Decoder PC application (purchased separately), remote real-time notification of 406 transmissions is possible, decoding and displaying all beacon protocol parameters. Time-stamped messages are additionally stored on the PC that is integrated with both on-line OR off-line maps from many map providers to display the location of the alert when available. The 406 Decoder application, provides visual and audible alerts of 406 distress transmissions.



Through the configuration of a simple external language file, the application can be configured to operate in any language. Assistance can be provided for language translation if required.



Distress and test messages can be clearly differentiated. Distress messages are marked in red, test messages in green. New, incoming distress messages provide an audible alert until acknowledged.

When a history entry is highlighted that contains a valid position, a “Map” button is visible that when pressed, shows the location of the beacon transmission using the user selected integrated map. Coma separated results are logged directly to file.

All information available in the history list is written to file, and time-stamped with the time written.

On application start-up the results file is loaded to allow browsing of entries and viewing of historical entry beacon parameters.

When a beacon certificate number has been decoded, the beacon model and manufacturer is displayed (produced from COSPAS-SARSAT registration reports).

The new beacon checksum is displayed (introduced in July 2012) that allows a more robust beacon registration method. This checksum is being adopted by some countries to ensure that the hex id is entered correctly during registration (there have been many cases of registration against the wrong ID).

## Location of Application Modified Files

All files that are modified by the 406 Decoder PC application are stored in the local application data directory.

These files are:

**results.csv** (all beacon decoded data)

**config.xml** (all application and 406-SD-1 settings).

These files are ALSO located in the application directory, but are only used as default files for when the application is run for the first time. Changes to these files in the application directory will have no effect.

When the PC application is upgraded, the configuration and results files in the location shown below will not be overwritten.

### On a Windows XP PC:

C:\Documents and Settings\All Users\Application Data\MicroTechnologies\406 SD-1


### On a Windows 7 PC:

You will first need to make sure these folders are not hidden.

1. Start->Control Panel->Appearance and Personalisation->Folder Options.
2. Click View
3. Advanced Settings->Show hidden Files, folders and drives.

The path to the common application data can be found by entering:

%ProgramData% path into Windows File Explorer.




Files that are not modified by the application are stored in the application directory, such as:

**Langstrings.xml**


**CountryStrings.xml**

## Report Generation

Any entry in the history list can be selected and used to generate a test report. The company name and location of the reports folder can be set under **Config->General**.



HTML Reports can be viewed in any web browser and printed if required.





## Serial Port Configuration

Once the correct COM port has been selected, and the port has been opened, the status message will change from “Not Connected” to “Connected” when physically connected to the receiver. When the application is started again, the application will attempt to automatically connect using the last opened COM port. For PCs that lack RS232 COM ports, a USB to RS232 converter can be used.


## Integrated Mapping

The 406 Decoder PC application supports two modes of integrated mapping. These modes are either “Live”, where the map updates automatically when new messages are received, or static, by selecting any location message in the history list. Many map providers can be selected (such as “OpenStreetMap”, “ArcGIS”, “Bing” etc.), allowing map information to be switched rapidly to show information such as:

- Satellite Imagery.
- Topological details.
- Street information.

Depending on the map provider's conditions of acceptable use, some of these maps can be automatically stored on the computer by the PC application, allowing rapid screen updating and map updates without an internet connection being required.

## Live Map Updates



When the “Live Map” option is selected through the “Config” menu the integrated map window is opened. This map window is automatically updated and displays the position of the most recent received 406 transmissions containing a valid location. Details for each transmission can be viewed by “hovering” over the red map marker.




## Static Map Button

When the “Map” button is pressed (only visible when an entry in the history list contains a valid location) the position is displayed using the selected map system.


By default the 406 Decoder PC application is configured to use “OpenStreetMaps”, which can be used without an internet connection free of charge.

NOTE: In order to use off-line maps (when there is not an internet connection available), the PC application must have previously viewed the area at the current zoom level WITH an internet connection. Once the area has been viewed, the map data will be stored for later retrieval.

Many map systems have been integrated and can be used to provide many differing useful views of the location decoded. These maps provide worldwide coverage.




Shown below is an example of the integrated ArcGIS Topological map system.



## Email Notification

The 406 Decoder PC application can be configured to automatically send email notifications when 406 messages are received or communication to the receiver is lost (either direct connection or if the receiver is being monitored remotely).



Emailing can be disabled completely or provide notification when communication to the unit has been lost and restored . Filtering can also be configured to not send self test messages.


The Min RSSI Level should normally be configured to be -130dBm. A low value (such as -130) means that all packets of even a very low signal strength are logged and emailed. Increasing the level may be preferable if there is an interest only in signals from closer beacons.

Obtaining a gmail account for the PC application is a simple way to send out email messages, and also keep a separate record of all emails sent by the application. The host and port settings shown will work well for gmail. Alternatively other SMTP email hosts can be used.

## Testing Email Notification

Pressing the small button in the bottom right hand side of the bottom status bar generates a test distress message for demonstration purposes and confirming that email settings are correctly configured.

Typical email notifications appear as:



## MT-RX-3 Customisation

---

The MT-RX-3 has been developed by WTE Limited, and therefore if a specific requirement exists, customisation of WTE products may be possible (at additional cost).

Examples of possible customisation:

- Changes to enclosure.
- Changes to serial output to better suit specific navigation equipment.
- Decryption of data parameters (e.g. for military use).
- Support of additional protocols.
- Support for different Languages.

## Installation

---

The MT-RX-3 should be situated away from direct sunlight, extreme vibration and heat sources, and high power transmission sources.

An external antenna correctly designed to operate at your intended frequency of operation will result in best performance. Dual VHF/UHF antennas may operate acceptably for your requirements. Do not situate the antenna immediately next to the antenna of a high power transmission source – position greater than 2 M from any other antenna. Mount the external antenna with as much elevation as possible for best results (see “Antenna Elevation” below).

Maximum tolerated input power into the RF connector is 13 dBm. Levels above this will destroy the receiver RF input and invalidate the unit warranty.

## Cables Supplied

---

By default NO cables are supplied on purchase. Because there are so many possible frequencies and variations in installation an antenna is NOT supplied by default. If an antenna is supplied, it will be a generic variety that will not perform as well as an antenna produced for the intended frequency of operation, or a high gain externally mounted type.

If cables are to be supplied, this must be ordered at time of purchase.

## Connecting to the MT-RX-3


---

The minimum required connections for a usable system:

1. Connection to an antenna.
2. 12V, 1A supply connected to the power terminals

## Connector Pin descriptions

### RHS (Right Panel)



#### RF

BNC connector (50 ohms)


#### USB

Mini type B connector

### Output Connector

Outputs Pin Number	Description
1	Digital Output 2
2	Digital Output 1
3	Speaker
4	Ground
5	Relay Normally Connected (NC)
6	Relay Normally Open (NO)
7	Relay Common (CM)

## LHS (Left Panel)



### Serial Connector:


Serial Connector Pin Number	Description
1	RS422 RX+ (IN+)
2	RS422 RX- (IN-)
3	RS422 TX- (OUT-)
4	RS422 TX+ (OUT+)
5	RS232 TX
6	RS232 RX
7	Ground (GND)

### Power Connector:

Power Connector Pin Number	Description
1	Ground (GND)
2	+12V
3	Not Connected (N.C.)



## Ethernet Connector:



Connector Pin Number	Description
1	TX+
2	TX-
3	RX+
4	NC
5	NC
6	RX-
7	NC
8	NC

**Note:** pins: 4 and 5 are connected to ground via a 75R resistor  
7 and 8 are connected to ground via a 75R resistor

**Note:** Do not connect a Power over Ethernet (PoE) connection to the MT-RX-3 Ethernet port as this will result in damage.



## Output Hardware Connection

Examples of how to connect external devices to the MT-RX-3 output pins.

The MT-RX-3 contains 3 outputs, where 2 are open collector and one is a clean contact to an internal relay.


Care must be taken to ensure the sinking output current does not exceed 30mA. When using inductive loads, such as relay coils, flyback diodes must be fitted to prevent damage to the MT-RX-3.

### Open Collector Outputs




## Internal Relay

MT-RX-3 provides a relay clean contact in the output connector, these contact are not designed for high voltages and currents. The maximum voltage in these contacts should not exceed 50V and 500mA.





## External Speaker

A small 8 Ohms 50mW speaker can be connected directly into the output connector, this line can be used to connect to an audio amplifier if higher volume is required.



## Serial Connections

### RS-232



## **RS-422/RS-485**


RS-422 and RS-485 use a differential electrical signal, as opposed to unbalanced signals referenced to ground as used by RS-232. Differential transmission uses two lines each for transmit and receive signals which results in greater noise immunity and longer distances between devices. These advantages make RS-422/RS-485 a better fit for industrial applications.

RS-422 is point to point interface that allows for up to 10 receivers but only a single transmitter. This would be a common serial interface for NMEA devices all sharing GPS data from a single GPS receiver for example.


RS-485 is a multipoint interface that allows each device to be a transmitter and also a receiver. This interface also allows for more devices to be connected on a common serial bus. Because each device on the same bus can transmit, each device must be capable of setting all transmit lines to a high impedance state when not in use to ensure that all devices have the ability to transmit. RS-485 interfaces can be presented as 4 or 2 wires. When there are 2 wires required, the RS-485 device must also be able to isolate its own receiver when transmitting to prevent looping data back to itself.

The MT-RX-3 satisfies the requirements for both 4 and 2 wire RS-485 communications. The MT-RX-3 will also be able to operate on a RS-422 bus.

## RS-485/RS-422 Point To Point



## RS-485/RS-422 Multi-Point



**Note:** this configuration only applies if driving less than 10 listeners/receivers when using RS-422 devices or less than 32 devices for RS-485 devices.

## RS-485 Multi-Point – 2 Wire




Illustration 5: MT-RX-3 RS-485 2 Wire Multi-Point

**Note:** the MT-RX-3 must have wire links fitted as shown in order to operate correctly in this configuration.

## Bus Terminating Resistor

RS422/RS485 may require the fitting of a terminating resistor. The purpose of termination is to match the impedance of a transmission line to the hardware impedance of the interface it is connected to. There is more than one way to add termination to an RS485/422 serial connection. The most commonly used is DC Termination, accomplished by attaching a resistor between the signal lines on the extreme ends of the transmission line.

The rule of thumb for termination is:

- If the propagation delay of the data line is much less than one bit (pulse) width, termination is not needed.

This assumes reflections will damp out in several trips back and forth on the data line.

Typically for slow speeds of 9600bps or below, no termination resistor is required.

If termination is required a resistor value of  $120\Omega$  or greater should be used, and no more than 2 termination resistors should be used, one at each end of the RS422 transmission line.

Do not use termination resistors with a value of less than  $90\Omega$ .

There are many online references available to calculate these resistors if required.



## RF Connections

---

A 50 ohm matched load must be fitted to the MT-RX-3 antenna port.

Note: Earth the antenna tower, feeders and lightning protection devices in accordance with the appropriate local and national standards. Use grounding kits as specified or supplied by the coaxial cable manufacturer to properly ground or bond the cable outer.

### **⚠CAUTION**

Lightning will destroy electronic equipment.

To avoid this risk, install primary lightning protection devices on any interfaces that are reticulated in the local cable network.

You should also install a coaxial surge suppressor on the radio antenna port. If required, please consult your local antenna specialist.

## Power Connections

---

Power to the MT-RX-3 is achieved via the power connector as described in the section **Installation** in this manual.

### **⚠ WARNING**

#### **EXPLOSION HAZARD**

MT-RX-3 was **NOT** designed to operate and/or be connected to a supply voltage exceeding the specified maximum for this unit.

**Failure to follow these instructions can result in death or serious injury**

## Ethernet Interface

The MT-RX-3 supports a 10/100 Base-T Ethernet connection.

To simplify network setup, the MT-RX-3 supports auto-negotiation and auto-sensing MDI/MDIX crossover.

General	Interface	RJ45
	Cabling	CAT-5/6 UTP, supports auto MDIX (Standard Ethernet)
	Bandwidth allocation	The Ethernet capacity maximum is determined by the available radio link capacity.
	Ethernet mode	10Base-T or 100Base-TX Full duplex or half duplex (Auto-negotiating and auto-sensing)
Diagnostics	Green LED	Off: No data present on the interface. On: Data present on the interface.
	Orange LED	Off: no Ethernet connection On: Ethernet signal received

## Omni or Directional Antenna

---

It is common in radio systems to consider an omni or directional antenna. Both have their advantages and disadvantages as follows.

If in doubt, consult a local antenna specialist who will be able to advise and construct an antenna best suited to your application.

### Omni antenna

Omni antenna have the advantage of transmitting and receiving signals equally well in all horizontal directions. This means that if the transmitter or the receiver moves, the antenna will not need to be changed/adjusted to compensate.

This is the common antenna used in cellular phones and handhelds radios.

### Directional antenna

Directional antenna have the ability to focus energy in a particular direction. This advantage increasing the maximum distance between transmitter and receiver units. Since the signals are focused/concentrated into a direction it also increase the overall performance of the system.

This is mainly used for fixed transmitter and receiver locations.

## Antenna Elevation

---

As with any radio receiver, raising the height of either the transmitter or receiver antenna will result in dramatic improvements to the maximum possible receive distance. Although a high power transmission will increase distance, the installed height of the receiver antenna is the key to a high performing system.

When close to the ground the major obstacle to overcome, since radio signals are mainly “line of sight”, is the curvature of the earth. The typical distance to expect can be approximately calculated as follows:

$$D = \sqrt{\frac{2r_0 h_f}{6076.1 \beta_0}}$$

Where:

- $D$  is the distance to the horizon in NM,
- $r_0$  is the mean radius of the earth (3440.1 NM),
- $h_f$  is the height of your antenna,
- $\beta_0$  (0.8279) accounts for terrestrial refraction.

This formula can be simplified to:

$$d = 1.17 * \sqrt{h_f}$$

Where:

- $d$  = range in nautical miles,
- $h_f$  = the height of your antenna in feet.

Working with metric units this formula becomes:

$$km = 2.17 * \sqrt{0.305 * h_m}$$

Where:

- $km$  = range in kilometres,
- $h_m$  = the height of your antenna in metres.

Therefore:

<b>Antenna Elevation (metres)</b>	<b>Clear Line of Sight Distance (km)</b>
1	1.2
5	2.7
100	12

The Antenna Elevation is the combined elevation of both the transmitter and the receiver (transmitter at 1m and receiver at 9m will behave similarly as the transmitter at 5m and receiver at 5m).

Changes in power level will help to address a less than ideal antenna or poor line of sight conditions.

When line of sight or elevation is poor, the range can also be approximately doubled with every 6dB increase in link budget (either increase in TX power, or increase in RX sensitivity).

From testing, these ranges can be expected from a 20dBm transmitter at the indicated elevation.


(credit to [www.offshoreblue.com](http://www.offshoreblue.com) for some range calculation details)

## Physical Dimensions

---

MT-RX-3 physical dimensions are 104mm x 130.5mm x 40mm (Length x Width x Height)

Weight: 550 grams



## Mounting Hardware

---


The MT-RX-3 enclosure was designed to be mounted via:

- DIN Rails
- Left or Right M4 nuts and bolts channels
- Top or Bottom M4 nuts and bolts channels

Please look the following images and descriptions to correctly mount the MT-RX-3

### DIN Rail

Inbuilt into the MT-RX-3 custom extrusion there is a DIN rail slot (patent pending) for easy snap fit DIN rail mounting.






## Mounting Channels

The MT-RX-3 has channel strips on the front, rear, top and bottom. In order to access the front, top and bottom channels (less common mounting option) the end plate on the power cable side will need first to be removed using a hex key. Mounting from the rear does not require the removal of the end plate.

The mounting channel allows an **M4 bolt** head or **M4 nut** to lock inside, as shown bellow.

**If an M4 nut is used inside the channels (instead of a M4 bolt head) attention must be taken to NOT use a bolt or screw longer than the channels depth. Not paying attention to this detail may result in damage to the MT-RX-3 and invalidate the product warranty.**




## TOP Mount


The flush mount option is suitable for an installation such as onto the front panel of a case or cabinet.



## SIDE Mount



## Bottom Mount




## Mount Bolts Dimensions

Both top and bottom are symmetric as are the left and right sides of the MT-RX-3 radio, this allows a wide range of mounting configurations.


The channels space from centre to centre in the top and bottom of the radio is 117.40mm

Dimension are in millimetres



## Top and Bottom Drilling Template


# TOP



### Note:

- All dimensions are in millimetres.
- The drilling template may not be to scale depending on your printer settings.

## Side Drilling Template




### Note:


- All dimensions are in millimetres.
- The drilling template may not be to scale depending on the printing settings.
- Depending on installation, not all mounting points may be required.

## Optional Mounting Inserts



The optional mount inserts, provided with the MT-RX, can be used to mount the MT-RX to a panel/ enclosure using M4 Screws as shown bellow.





Remove all the insert mounts from the panel in order to use.







Optionally two mounting inserts can be used for extra strength.



## Disclaimer

---

THE RESPONSIBILITY LIES COMPLETELY ON THE USER TO ENSURE THAT THIS DEVICE IS TESTED, THROUGH METHODS THAT ARE APPROPRIATE, TO CONFIRM THAT ALL SYSTEM COMPONENTS (THAT THIS DEVICE AND PC SOFTWARE MAY BE PART OF) ARE WORKING CORRECTLY.

THIS DEVICE AND SOFTWARE ARE NOT INTENDED TO BE USED AS A PRIMARY LIFE SAVING TOOL, BUT MAY BE USED TO STRONGLY COMPLEMENT OTHER EMERGENCY DETECTION TOOLS ONLY WHEN CORRECTLY CONFIGURED AND TESTED.

THE PRIMARY LIFESAVING MECHANISM FOR 406 BEACONS SHOULD ALWAYS BE CONSIDERED TO BE THE 406 SATELLITE NETWORK, FOR WHICH THE 406 BEACON HAS BEEN DEVELOPED.

The default enclosure is NOT waterproof, however this device may be fitted inside any enclosure to achieve the degree of water protection required.

This document has been prepared in good faith and produced to assist in the use of this product, however WTE Limited reserves the right to modify, add or remove features without notice.

When product is supplied, it is the user who is responsible for payment of any customs fees/taxes that are imposed on importation.

No User-Serviceable Components. There are no user-serviceable components within the radio

### RoHS and WEEE Compliance

MT-RX-3 is fully compliant with the European Commission's RoHS (Restriction of Certain Hazardous Substances in Electrical and Electronic Equipment) and WEEE (Waste Electrical and Electronic Equipment) environmental directives.

### Restriction of hazardous substances (RoHS)

The RoHS Directive prohibits the sale in the European Union of electronic equipment containing these hazardous substances: lead, cadmium, mercury, hexavalent chromium, polybrominated biphenyls (PBBs), and polybrominated diphenyl ethers (PBDEs).

### End-of-life recycling programme (WEEE)

The WEEE Directive concerns the recovery, reuse, and recycling of electronic and electrical equipment. Under the Directive, used equipment must be marked, collected separately, and disposed of properly.

## Manufacturing marking and labels

---

MT-RX-3 serial number can found on the unit, also serial number and model information are displayed on start-up or accessible via:

MENU->SYSTEM->FACTORY.

FCC Regulations allow for electronic labelling.

FCC details can be found via:

MENU->SYSTEM->REGULATORY

\*Note: Publication number 784748-D01, FCC-Part 90 allows for devices with integrated display to not require a printed label on the device holding this information.

## Maintenance

---

No User-Serviceable Components. Servicing is only to be performed by WTE Limited, or agent appointed by WTE Limited. Servicing outside of the warranty period is at the discretion of WTE Limited.

## Product End Of Life

---



It is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help conserve natural resources and help ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling contact your local dealer or city council



Please recycle this device responsibly. The MT-RX-3 has a residual scrap value that includes 400g of Aluminium.

## Product Warranty

---

WTE Limited products are warranted for a period of 12 months after purchase date against faulty workmanship or materials. Return the product, all freight paid by the customer and the product will be repaired or replaced.

The product warranty will be invalidated through evidence of:

- Unauthorised work carried out.
- Tampering, including evidence of removal of internal electronics from the case.
- Installation in wet or corrosive environments.
- Exposure to impact or excessive vibration.
- Use or installation outside of the specified operating parameters.

## Abbreviations and Glossary

---

<b>CAP (CAPCODE)</b> - Channel Access Protocol (CAP) code	<b>LAN</b> Local Area Network
<b>RIC -(Radio Identification Code)</b> - an address used in the POCSAG protocol for pagers	<b>LED</b> Light Emitting Diode
<b>POCSAG (Post Office Code Standardisation Advisory Group)</b> - A standard set of code and signaling formats for radio paging.	<b>mA</b> Milliamps
<b>USB (Universal Serial Bus)</b> - A common interface that enables communication between devices and a host controller such as a personal computer (PC).	<b>MAC</b> Media Access Control
<b>AES</b> Advanced Encryption Standard	<b>Mbit/s</b> Megabits per second
<b>AGC</b> Automatic Gain Control	<b>MHz</b> Megahertz
<b>ASCII</b> American Standard Code for Information Interchange	<b>ms</b> milliseconds
<b>BER</b> Bit Error Rate	<b>PC</b> Personal Computer
<b>CBC</b> Cipher Block Chaining	<b>PLL</b> Phase Locked Loop
<b>CCM</b> Counter with CBC-MAC integrity	<b>ppm</b> Parts Per Million
<b>DCE</b> Data Communications Equipment	<b>PMR</b> Public Mobile Radio
<b>DTE</b> Data Radio Equipment	<b>RF</b> Radio Frequency
<b>EMC</b> Electro-Magnetic Compatibility	<b>RoHS</b> Restriction of Hazardous Substances
<b>EMI</b> Electro-Magnetic Interference	<b>RSSI</b> Received Signal Strength Indication
<b>ESD</b> Electro-Static Discharge	<b>RX</b> Receiver
<b>ETSI</b> European Telecommunications Standards Institute	<b>SCADA</b> Supervisory Control and Data Acquisition
<b>FW</b> Firmware	<b>SNMP</b> Simple Network Management Protocol
<b>HW</b> Hardware	<b>SNR</b> Signal to Noise Ratio
<b>IF</b> Intermediate Frequency	<b>SWR</b> Standing Wave Ratio
<b>IP</b> Internet Protocol	<b>TCP/IP</b> Transmission Control Protocol/Internet Protocol
<b>I/O</b> Input/Output	<b>TCXO</b> Temperature Compensated Crystal Oscillator
<b>ISP</b> Internet Service Provider	<b>TFTP</b> Trivial File Transfer Protocol
<b>kbit/s</b> Kilobits per second	<b>TMR</b> Trunk Mobile Radio
<b>kHz</b> Kilohertz	<b>TX</b> Transmitter
	<b>UTP</b> Unshielded Twisted Pair
	<b>VAC</b> Volts AC
	<b>VCO</b> Voltage Controlled Oscillator
	<b>VDC</b> Volts DC
	<b>WEEE</b> Waste Electrical and Electronic Equipment

## Specification

Frequency Range	All used 406 Beacon frequencies 406.020MHz – 406.045MHz (concurrently)
Mechanical	Length: 104mm or 125mm including BNC connector Width: 131mm Height: 41mm Weight: 550grams
Supply Voltage	8-15 VDC Internally fused at 500mA.
Relay Contacts	1A . Maximum voltage 24V. Externally connected inductive loads (such as contactor coils) should use flyback diodes or snubber circuits.
Relay Closure	<ul style="list-style-type: none"> <li>On any 406 message, distress burst only or on reception of a specific beacon hex ID.</li> <li>On AIS type 1 SART status message 14 or 15.</li> <li>On RSS signal strength.</li> <li>On 121.5MHz/243 MHz sweep detection.</li> <li>On AIS vessel proximity.</li> <li>On AIS vessel collision alert.</li> <li>On GPS Anchor drift alert.</li> </ul>
Temperature Limits	-30 to + 70 degrees Celsius.
Max Input Power	0dBm. Connecting a 406 beacon directly to the aerial input will result in certain damage.
121.5MHz Receiver Sensitivity	-110 dBm.
406 MHz Receiver Sensitivity	-118 dBm
AIS (A) MHz Receiver Sensitivity	-113 dBm
AIS (B) MHz Receiver Sensitivity	-113 dBm
Receiver Absolute Maximum Input Power	+13dBm. Do NOT connect directly to a 406 beacon.
RSSI Range	-125dBm to 0dBm (not calibrated)
RSSI Resolution	0.5 dB
Aerial Connector	BNC
Operating Current	130mA plus: 18mA when relay energised. 50mA when sounder operating (typical) 40mA when backlight enabled.
Firmware	Field upgradable.
SD Storage Capacity	2GB
406 Error Correction	Correction of up to 5 bit errors per 406 packet.
Serial Output	406 decoded messages as MT protocol, configurable



	data rate. NMEA position information and AIS sentences output as RS-232. RS-422 (for direct integration with NMEA equipment) support through internal optional module.
AIS Decode Support	Both 161.975MHz and 162.025MHz. Decoding of all single and double AIS sentences. Alert only on type 1 SART status 14 or 15 as configured. Serial output (as RS232, or RS422 with optional module) of all single and double sentence AIS messages. Configurable AIS vessel proximity and collision alert.
406 Location Protocol Support	All COSPAS SARSAT C/S T001 Issue 3 Rev 12 Location protocols. <ul style="list-style-type: none"> <li>- User Location Protocol</li> <li>- Standard Location Protocol</li> <li>- Standard Test Location Protocol</li> <li>- National Location Protocol</li> <li>- National Test Location Protocol</li> <li>- RSL Location Protocol</li> </ul>
Spectrum Analyser (optional)	Frequency range: 142-175, 350 - 499 MHz RBW: 1kHz/25kHz Span: 120kHz/3MHz Continual or peak display. Min signal -120dBm, max signal -10dBm. Input Power accuracy: 421-480MHz +/-8 dB, 120-175MHz -2dB.
Compliance with Standards:	EN 301 489-3, EN 60950-1 satisfying the CE directives R&TTE 1999/5/EC, EMC 2004/108/EC and LVD 2006/95/EC. FCC part 15 Subpart A + B.
IP Rating	IP51.