

KW2M-A/KW2M-X Eco-POWER METER User's Manual

Cautions for Your Safety

Read the manual carefully before installing, running and maintenance for proper operation. Before using, master the knowledge of the equipment, safety information and all of other notes. This manual uses two safety flags to indicate different levels of danger.



WARNING

A handling error could cause serious physical injury to an operator and in the worst case could even be fatal.

- Apply appropriate personal protective equipment (PPE) and follow safe electrical work practices. In the USA, see NFPA 70E.
- Always take precautions to ensure the overall safety of your system, so that the whole system remains safe in the event of failure of this product or other external factor.
- Do not use this product in areas with inflammable gas. It could lead to an explosion.
- Exposing this product to excessive heat or open flames could cause damage to the lithium battery or other electronic parts.
- Do not open the secondary side of CT during power on the primary side current. It might cause electric shock or CT breakdown.



CAUTION

A handling error could cause serious physical injury to an operator or damage to the equipment.

- To prevent abnormal exothermic heat or smoke generation, use this product at the values less than the maximum of the characteristics and performance that are assured in these specifications.
- Do not dismantle or remodel the product. It could lead to abnormal exothermic heat or smoke generation.
- Do not touch the terminal while turning on electricity. It could lead to an electric shock.
- Use the external devices to function the emergency stop and interlock circuit.
- Connect the wires or connectors securely. The loose connection might cause abnormal exothermic heat or smoke generation.
- Do not allow foreign matters such as liquid, flammable materials, metals to go into the inside of the product. It might cause exothermic heat or smoke generation.
- Do not undertake construction (such as connection and disconnection) while the power supply is on.
- Never remove the terminal block under applying current to load. It might cause electric shock or CT breakdown.
- Do not use at secondary side circuit of inverter. It might cause exothermic heat or damage.

Copyright and trademark

- Panasonic Industrial Devices SUNX Co., Ltd. owns the copyright of this manual.
- We stiffly refuse the reproduction of without permission from this manual.
- Modbus Protocol is a communication protocol that the Modicon Inc. developed for PLC and Modbus is the registered trademark of Schneider Electric.
- Windows is the trademark of Microsoft Corporation in USA and other companies.
- Ethernet is the trademark of Xerox of USA.
- Firefox is the trademarks of Mozilla Foundation in USA and other companies.
- Google Chrome and Android are the trademarks of Google Inc.
- Other company names and the product names are the trademarks or registered trademarks of each company.

Introduction

Thank you very much indeed for purchasing
KW2M Eco-POWER METER.

In this manual, we explain the usage of KW2M
Eco-POWER METER in detail.

Please use it correctly after understanding the content
enough.

Table of Contents

Cautions before using	i
Chapter 1 Unit's Outline	1
1.1 Model Number	1
1.2 Firmware	1
1.3 Measurement outline	2
1.4 Measurement items	3
Chapter 2 Parts Name and Working	6
2.1 Parts Names	6
2.2 Key's functions	7
Chapter 3 Wiring	8
3.1 Main unit terminal arrangement	8
3.2 Expansion unit terminal arrangement	8
3.3 Measured-circuit	10
3.4 Connection between the Main unit and the Expansion unit	11
3.5 Wiring Diagrams	12
3.6 How to attach the Current Transformer (CT)	14
3.7 For Input Connection	16
3.8 For Output Connection	16
3.9 For Analog Input Connection (Expansion unit (Multi analog unit))	17
3.10 For RTD Input Connection (Expansion unit (Multi analog unit))	17
3.11 RS485 Communication	18
3.12 Backup Battery for Clock	18
3.13 Low Voltage Directive	19
3.14 Symbol List	20
Chapter 4 Settings	21
4.1 Setting Flow	30
4.2 Password Entry	35
4.3 Password Initialize	36
4.4 How to Set by Keys	37
4.4.1 Settings for power measurement	37
4.4.2 Settings for leakage current measurement	38
4.4.3 Settings for analog measurement *Only for Expansion unit (Multi analog input)	39
4.4.4 Settings for communication (RS485) *Only for Main unit	40
4.4.5 Settings for communication (Ethernet) *Only for Main unit	42
4.4.6 Settings for optional functions	44
4.4.7 Settings for calendar timer (only KW2M-X)	48
4.4.8 Password setting	49
4.4.9 Confirmation window	50
4.5 How to Set by Web Browser (System Web)	51
4.5.1 Setting item	51
4.5.2 Settings for power measurement	53
4.5.3 Setting for leakage current measurement	55
4.5.4 Settings for AD conversion	56
4.5.5 Settings for RTD measurement	57
4.5.6 Settings for demand and power rates	58
4.5.7 Settings for log (only KW2M-X)	62
4.5.8 Settings for pulse input (only Main unit and Expansion unit (Digital I/O))	64
4.5.9 Settings for pulse output (only Main unit and Expansion unit (Digital I/O))	65
4.5.10 Settings for Ethernet and RS485 communication	74
4.5.11 System setup	77
Chapter 5 Various Functions	80
5.1 Power Quality Measurement and Logging Function	80
5.2 Pulse Output Function	80
5.2.1 Output depends on integral electric power	80
5.2.2 Stand-by alarm	80
5.2.3 Under voltage alarm	80
5.2.4 Over voltage alarm	80
5.2.5 Power interruption alarm	81
5.2.6 Under current alarm	81
5.2.7 Current alarm	81
5.2.8 Power alarm	81

5.2.9 Other alarms.....	81
5.2.10 Output depends on count value	81
5.2.11 Time Control (only KW2M-X)	81
5.2.12 Level output.....	81
5.3 Counter Function	82
5.4 Clock Correction Function (only KW2M-X)	82
5.5 Hour Meter Function	83
5.6 Demand Function.....	84
5.6.1 Block interval demand	84
5.6.2 Current demand	85
5.6.3 Max. demand value	85
5.6.4 Demand alarm output.....	85
5.6.5 Working at power failure and at recovery.....	85
5.6.6 Totaling the demand.....	85
5.7 Logging Data Writing Function (only KW2M-X).....	86
5.7.1 File creating	86
5.7.2 Format for written files	87
5.7.3 File name and saved folder	94
Chapter 6 Display of Each Value	97
6.1 Working of Monitor Display	97
6.2 Working of Monitor Display (Main unit, Expansion unit (Power measurement))	98
6.2.1 Single-phase two-wire system.....	98
6.2.2 Single-phase three-wire system	100
6.2.3 Three-phase three-wire system.....	102
6.2.4 Three-phase four-wire system.....	104
6.2.5 Instantaneous power	106
6.2.6 Total integral power	107
6.2.7 Total integral export power.....	108
6.2.8 Current.....	109
6.2.9 Voltage	109
6.2.10 Power factor	110
6.2.11 Frequency.....	110
6.2.12 Current unbalance	110
6.2.13 Voltage unbalancing.....	110
6.2.14 Current THD	111
6.2.15 Voltage THD	111
6.2.16 Current n-order harmonics	111
6.2.17 Voltage n-order harmonics	111
6.2.18 Pulse input value	112
6.2.19 Conversion value for integral active power	112
6.2.20 Conversion value for integral export power.....	112
6.2.21 Hour meter.....	113
6.2.22 Clock (only KW2M-X).....	113
6.3 Working of Monitor Display (Expansion unit (Leak measurement))	114
6.3.1 Leakage current	114
6.4 Working of Monitor Display (Expansion unit (Multi analog input))	115
6.4.1 Analog measured value.....	115
6.4.2 Temperature	115
6.5 Working of Monitor Display (Expansion unit (Digital I/O))	116
6.5.1 Pulse input value	116
6.6 Working of Logging Mode	117
6.6.1 Max. demand value	118
6.7 Working of Demand Mode	119
6.7.1 Block interval demand (Sliding block, fixed block)	119
Chapter 7 Monitoring Measured Value via Web Browser (Monitor Web).....	122
Chapter 8 Creating Web Contents (Customer Web)	123
8.1 How to Upload Web Contents	124
8.2 How to Download Web Contents.....	125
Chapter 9 How to Update the Firmware	127
Chapter 10 How to Update the Web Contents.....	129
Chapter 11 Specifications	132
11.1 General Specification (Main unit, Expansion unit).....	132
11.2 Measurement Specifications.....	133

11.3 Output Specifications (Main unit and Expansion unit (Digital I/O)).....	135
11.4 Input Specifications.....	136
11.5 Demand Monitor and Control Specifications (common to 9, 10).....	138
11.6 Communication Specifications.....	138
11.7 Web Server Specifications (common to Main unit and Expansion unit)	139
11.8 Main Unit Memory Specifications (only KW2M-X).....	140
11.9 Self-diagnostic	142
Chapter 12 Mounting.....	143
12.1 Dimensions	143
12.1.1 Main unit (KW2M-A/KW2M-X).....	143
12.1.2 Expansion unit.....	143

Cautions before using

■ About this product

Eco-POWER METER is designed chiefly to manage saving energy.
It is neither nor can it be legally used for billing.

■ Installation environment

◇Do not use the Unit in the following environments.

- Where the unit will be exposed to direct sunlight and where the ambient temperature is outside the range of -10 to 50 °C.
- Where the ambient humidity is outside the range of 30 to 85 % RH (at 20°C), non-condensing and where condensation might occur by sudden temperature changes
- Where inflammable or corrosive gas might be produced
- Where the unit will be exposed to excessive airborne dust or metal particles
- Where the unit will be exposed to water, oil or chemicals
- Where organic solvents such as benzene, paint thinner, alcohol, or strong alkaline solutions such as ammonia or caustic soda might adhere to the product
- Where direct vibration or shock might be transmitted to the product, and where water might wet the product
- Where the place near high-voltage cable, high-voltage device, power line, power device.
- Where the place near a machinery with transmission function such as amateur radio.
- Where the place near a machinery which occurs the big switching surge

◇Please use the Unit according to the specifications described in this manual. Otherwise, it may malfunction or cause fire and an electric shock.

- Connect to the power supply in compliance with the rating.
- Refer to the wiring diagram to ensure proper wiring for the power supply, input and output.
- Use the wire that conforms to the rated current.
- Do not perform wiring or installation with a live line. It may also lead to circuit burnout or fire by way of the secondary CT side opening.

■ Installation

- Eco-POWER METER is designed to be used in a control panel.
- If the additional noise affects the power supply line, incorrect measurements may result.
- Installation and wiring must be performed by expert personnel for electrical work or electric piping.
- Do not add an excess power to the display. It might break the inner liquid crystal.
- Although the case is made from fireproof resin, do not mount it next to flammable materials. Also, avoid placing it directly on top of materials that catch fire easily.

■ As to measurement

- If there is some distortion by harmonic or waveform, it may not measure correctly.
Please check with the actual system before adopting it.
- It might not measure an instantaneous current such as an inrush current or an welding machine.
- When measuring the below loads, it might not satisfy with the accuracy guarantee.
Out of rating current, Load with low power factor,
Load with winding current, Load with ferromagnetic field
- Power factor operation is a method assuming balanced load. The error might be big when it measures unbalanced load.
- If the voltage to be measured is not the rated frequency (commercial frequency), it may take time to stabilize THD (total harmonic distortion).

■ Static electricity

- Discharge static electricity touching the grounded metal etc. when you touch the unit.
- Excessive static electricity might be generated especially in a dry place.

■ Cleaning

- Wipe dirt of the main unit with soft cloth etc. When thinner is used, the unit might deform or be discolored.

■ Power supply

- Connect a breaker to the voltage input part for safety reasons and to protect the device.
The breaker that connects to the voltage input part must arrange at the position easily reached, and display shows it is the breaker of the equipment.
- Do not turn on the power supply or input until all wiring is completed.

■ Before power on

Please note the following points when turning on power at the first time.

- Confirm there are neither wiring rubbish nor especially an electrical conduction when installed.
- Confirm neither the power supply wiring, the I/O wiring nor the power-supply voltage are wrong.
- Tighten the installation screw and the terminal screw surely.
- Use an electric wire applicable to the rated current.

■ Before change the setup

Set the password carefully.

In order to avoid unexpected change the settings, it can set password. However, if you forget the password you can't change the settings.

We recommend you to note the password when you set and change the password.

■ Precautions on using networks

This product supports various network connections therefore it is likely to be subject to the following security risks.

1. Leakage and outflow of information via this product
2. Illegal operation by third party with malicious acts
3. Interference and shut down by third party with malicious acts

It is recommended to take network security measures such as below for protecting against these risks under your responsibility.

- Use this product on the network that has been ensuring safety by using firewall
- Check and extermination against the infection of computer viruses and unauthorized program are you make sure that you have performed regularly
- To protect against unauthorized attacks, set the user name and password, and to limit the users who can log in.
- Restrict access by user authentication so that authentication information (user name, password) and network configuration information and equipment inside information is not leak on the network.
- Before you access this product via browser, close other windows.
- After you access this product via browser, close all browsers.
- Change password regularly.
- Do not install the place where it can be disassembled or remodeled easily.

We do not accept liability for the following cases.

- 1) Guarantee for any kind of damages to the things/products, caused by physical defects of the product.
- 2) When the other conditions than the ones specified in these specifications exist for handling, storage and transportation of the product after the delivery.
- 3) When damage is caused by the unpredictable phenomena with the technique that was practiced before the product delivery.
- 4) When damage is caused by natural disasters such as an earthquake, flood, fire, war and artificial disasters.
- 5) When necessary countermeasures are not taken to establish a system despite the precautions described in this specifications.

Chapter 1 Unit's Outline

With KW2M Eco-POWER METER, electrical power (voltage, current, etc.), power factor, frequency, etc. are measured using AC voltage and AC current input via one of the following systems: single-phase two-wire system, single-phase three-wire system, three-phase three-wire system or three-phase four-wire system.

In addition, it measures harmonics and THD for power quality measurement.

Connecting the expansion unit to the main unit can measure up to 8-circuit (up to 24-circuit of single-phase 2-wire system). One unit can measure 2-circuit.

■Eco-POWER METER is designed chiefly to manage saving energy. It is neither intended nor can it be legally used for billing.

1.1 Model Number

Model name	Model number
KW2M-A Eco-POWER METER Main unit (Standard type)	AKW263100A
KW2M-X Eco-POWER METER Main unit (Memory type)	AKW264100A
KW2M Eco-POWER METER Expansion unit (Power measurement)	AKW272100A
KW2M Eco-POWER METER Expansion unit (Multi analog input)	AKW273230A
KW2M Eco-POWER METER Expansion unit (Digital I/O)	AKW274240A

* It can't measure with only the Expansion unit. Be sure to use with connecting to main unit.

1.2 Firmware

●Combination software using the Expansion unit

Expansion unit	AKW263100A firmware	AKW264100A firmware
AKW272100A (Power measurement)	Ver.1.00 or more	Ver.1.00 or more
AKW272100A Ver1.20 or more (with leakage current measurement)	Ver.1.10 or more	Ver.1.10 or more
AKW273230A	Ver.1.10 or more	Ver.1.10 or more
AKW274240A	Ver.1.10 or more	Ver.1.10 or more

●For using the additional functions

Functions	-Power quality logging	-Custom logging -Leakage current measurement
Model Number		
AKW263100A	Ver.1.00 or more	—
AKW264100A	Ver.1.01 or more	Ver.1.10 or more
AKW272100A	Ver.1.10 or more	Ver.1.20 or more
AKW273230A	Ver.1.20 or more	Ver.1.20 or more
AKW274240A	Ver.1.20 or more	Ver.1.20 or more

* You can't use the expansion units or additional functions if the firmware doesn't support to each. Check beforehand to use them and upgrade the firmware.

1.3 Measurement outline

●Main unit, Expansion unit (Power measurement)

Phase/Wire system	Single-phase two-wire (1P2W) Single-phase three-wire (1P3W) Three-phase three-wire (3P3W) Three-phase four-wire (3P4W) (common)	
Applicable power system	100V system, 200V system, 400V system	
Measurement circuit	Main unit	1-system 2-circuit (when measuring 1P2W: 1-system 6-circuit)
	Expansion unit (Power measurement)	1-system 2-circuit (when measuring 1P2W: 1-system 6-circuit)
Input measurement voltage	0 to 690VAC *0 to 300V for UL61010-1	
Input measurement current	1 to 65,535A	
Applicable current sensor	Secondary side output: 1A or 5A	

●Expansion unit (Multi analog input)

Analog input (Voltage / Current)	3-channel
Temperature measuring resistor input	2-channel

●Expansion unit (Digital I/O)

Pulse input	2-channel
Pulse output	4-channel

1.4 Measurement items

•Main unit, Expansion unit (Power measurement)

Item		Unit	Display data range	
Instantaneous power	Active	W	-999.99P to 999.99P	Present value Max. value Min. value
	Reactive	var		
	Apparent	VA	0.000k to 999.99P	
Total integral power (import)	Active	Wh	0.000k to 9999.9P	Present value
	Reactive	varh		
	Apparent	VAh		
Total integral power (export)	Active	Wh	0.000k to 9999.9P	Present value
	Reactive	varh		
Current		A	0.000 to 999.99k	Present value Max. value Min. value
Voltage		V	0.00 to 9999.9k	
Power factor			-1.000 to 0.000 to 1.000	
Frequency		Hz	0.00 to 99.99	
Pulse count value			0.000 to 999999	Present value
Power conversion value		Wh	0.000k to 9999.9P	Present value
Leakage current		A	0.0000 to 99999.9999	Present value

* 'Display data range' is the range to be able to indicate with the main unit display, it is not a range that can be measured.

•Power Quality

Power Quality		Display data range	
Item			
Unbalanced current	Each phase	0.00 to 300.00 %	Present value
Unbalanced voltage	Each phase		Max. value
		Min. value	
Current THD (total harmonic distortion)	Each phase	0.00 to 400.00 %	Present value
Voltage THD (total harmonic distortion)	Each phase		
Current harmonics (2 nd to 31 st)	Each phase		
Voltage harmonics (2 nd to 31 st)	Phase		
	Line		
Hour Meter	ON-time	0.0 to 99999.9 h	
	OFF-time		
	Stand-by time		
	Maintenance time		

* If the voltage to be measured is not the rated frequency (commercial frequency), it may take time to stabilize THD (total harmonic distortion).

•Demand

Item		Unit	Display data range	
Present demand	*1	Active	W	0.000k to 999.99M
		Reactive	var	
		Apparent	VA	
		Active (export)	W	
		Reactive (export)	var	
		Current	A	0.000k to 999.99k
		Present value Max. value Monthly max. value (latest 13 months) *2		

*1 Please use this demand function as your standard.

The demand value calculated with this function is not guaranteed.

*2 only KW2M-X

●Expansion unit (Multi analog input)

Item	Display data range
Digital conversion value	-999999999 to 999999999
Temperature	-200.0 to +200.0°C

*Digit of digital conversion value differs according to the setting scaling value.

●Expansion unit (Digital I/O)

Item	Display data range
Pulse count value	0.000 to 999999

*Digit of pulse count value differs according to the setting pre-scale value.

<Glossary>


Eco-POWER METER defines as below.

THD (total harmonic distortion)	Ratio of harmonic distortion (voltage or current) for the fundamental frequency. Lower the value shows that the distortion is less.
Harmonics	Sinusoidal wave other than fundamental frequency. It has frequency that is whole-number multiple of the fundamental frequency. The frequency that has 2 times frequency (half wavelength) is called 2 nd -order harmonics.
Voltage unbalancing	The different between each phase-voltage due to the load unbalancing. It is calculated as below. $\frac{ \text{Max. (Min.) voltage of all phase} - \text{average voltage} }{\text{Average voltage}} \times 100 (\%)$
Current unbalancing	The difference between each-phase current due to the load unbalancing. It is calculated as below. $\frac{ \text{Max. (Min.) current of all phase} - \text{average current} }{\text{Average current}} \times 100 (\%)$
Power interruption	Voltage under 5% of rating is kept 5ms or more.
Under voltage	Set the ratio for the rated voltage and it is used for threshold. Voltage under the set ratio is kept 5ms or more, it will judge as under voltage.
Under current	Set the ratio for the rated current and it is used for threshold. Current under the set ratio is kept 5ms or more, it will judge as under current.
Over current	Set the ratio for the rated current and it is used for threshold. Current over the set ratio is kept 5ms or more, it will judge as over current.
Demand by IEC61557-12	Based on IEC61557-12 Performance measuring and monitoring devices (PMD)
Sliding block interval demand	It calculates by measured power via CT with setting interval. Set power interval by 1 to 60(min.) (every 1-min.). It calculates demand during latest finished interval and displays. One interval is started every setting time.
fixed block interval demand	It calculates by measured power via CT with setting interval. Set power interval by 1 to 60 (min.) (every 1-min.) It calculates demand during latest finished interval and displays. After one interval finishes, the next interval starts.
Current demand	It calculates based on a thermal demand meter. It measures an average current (current demand) within setting interval and the max. value is considered as max. current demand.

Chapter 2 Parts Name and Working


2.1 Parts Names

●Main Unit <Front>




<Bottom view>


Ethernet port
Left: port 1
Right: port 2




●Expansion Unit (Power measurement)



●Expansion Unit (Multi analog input)



●Expansion Unit (Digital I/O)



2.2 Key's functions

Key	Functions	
<MODE>	Measuring mode	Shift to setting mode
	Setting mode	Shift to setting confirmation mode and measuring mode
<SET>	Setting mode	Set setting items and setting values
<SET> (continuous 3-sec)	Measuring mode Demand mode	All keys locked
	Lock mode	Release the lock mode
<SHIFT/Λ> <ITEM/>>	Measuring mode	Select measuring item to display
	Setting mode	Select a setting value
	Demand mode	Select demand item to display
<MODE>+<SET>	Measuring mode Demand mode	Select unit to display
<MODE>+<SHIFT/Λ>	Measuring mode	Shift to demand mode
	Demand mode	Shift to measuring mode

●Lock mode

It is the mode makes all keys unable. In this mode, you can't input by any keys.
 When you press <SET> continuously for about 3sec., lock mark is displayed.
 Press <SET> continuously for about 3sec. again to release Lock mode.

Chapter 3 Wiring

Be sure to wire correctly according to the terminal arrangement and wiring diagrams.

Please connect a fuse or a breaker to power supply part for safety reasons and to protect the device.

This has no built-in power switch, circuit breaker or fuse for measured voltage input parts.

Therefore it is necessary to install them in the circuit near this unit.

Do not turn on the power supply or input until all wiring is completed.

3.1 Main unit terminal arrangement

Power supply terminals

Terminal number	1	2
Functions	L +	N -
	Power supply	

Voltage input terminals

Terminal number	1	2	3	4	5	6	7
Functions	V1	NC	V2	NC	V3	NC	Vn
	Measured voltage	vacant	Measured voltage	vacant	Measured voltage	vacant	Measured voltage

*Do not use NC (vacant) terminals in any purpose.

Current input terminals

Terminal number	1	2	3	4	5	6	7	8	9	10	11	12
Functions	K	L	K	L	K	L	K	L	K	L	K	L
	CH1(CT1)		CH1(CT2)		CH1(CT3)		CH2(CT1)		CH2(CT2)		CH2(CT3)	
	Measured current (CH1)						Measured current (CH2)					

RS485 communication terminals

Terminal number	1	2	3	4	5	6
Functions	+	+	-	-	END	END

*Each terminal is connected internally.

Pulse I/O terminals

Terminal number	1	2	3	4	5	6
Functions	+	-	+	-	+	-
	Pulse input		Pulse output (OUT1)		Pulse output (OUT2)	

*It is insulated between OUT1 and OUT2.

3.2 Expansion unit terminal arrangement

●Power

Current input terminals (Upper)

Terminal number	1	2	3	4	5	6
Functions	K	L	K	L	K	L
	CH1(CT1)		CH1(CT2)		CH1(CT3)	
	Measured current (CH1)					

Current input terminals (Lower)

Terminal number	1	2	3	4	5	6
Functions	K	L	K	L	K	L
	CH2(CT1)		CH2(CT2)		CH2(CT3)	
	Measured current (leak)(CH2)					

●Multi analog input

Analog input terminals (Upper)

Terminal number	1	2	3	4	5	6
Functions	V/I	COM	V/I	COM	V/I	COM
	CH1		CH2		CH3	
	Voltage / Current input					

RTD input terminals (Lower)

Terminal number	1	2	3	4	5	6
Functions	A	B	b	A	B	b
	CH1			CH2		
	RTD					

●Digital I/O

Pulse output terminals (Upper)

Terminal number	1	2	3	4	5	6
Functions	+	-	+	-	+	-
	Pulse output (OUT1)		Pulse output (OUT2)		Pulse output (OUT3)	

Pulse output terminals (Lower)

Terminal number	1	2	3	4	5	6
Functions	+	-	+	-	+	-
	Pulse output (OUT4)		Pulse input (IN1)		Pulse input (IN2)	



The input voltage to each terminal is as follows.

The input voltage to each terminal is as follows.

Terminal	Phase and wire system	Terminal No.	Input voltage
Power supply	Single-phase two-wire	1 - 2 (L+ - N-)	100-240V AC [100-240V ~]
Voltage input terminals			
Measured voltage input	Single-phase two-wire	1 - 7 (V1-Vn)	0-690VAC [0-690V ~] (L-L)
	Single-phase three-wire	1 - 5 - 7 (V1-V3-Vn)	0-690VAC [0-690V ~ :3W] (L-L) 0-345VAC [0-345V ~ :3W] (L-N)
	Three-phase three-wire	1 - 5 - 7 (V1-V3-Vn)	0-690VAC [0-690V 3 ~] (L-L)
	Three-phase four-wire	1 - 3 - 5 - 7 (V1-V2-V3-Vn)	0-690VAC [0-690V 3 ~] (L-L) 0-398VAC [0-398V 3N ~] (L-N)

◆Applicable wire (Crimp-type terminal is recommended.)

•Stripping length: 7 to 8mm

•Power supply/Measured voltage

Screw type: M3

Tightening torque: 0.5 to 0.6N·m

Sectional area: single /stranded wire 0.13 to 3.3mm²(AWG26 to12)

•for 2pcs.

single/stranded wire 2pcs.×0.5 to 2.5mm² (AWG20 to 12)

•Measured current (CT input)

Screw size: Push IN type

Sectional area: single /stranded wire 0.13 to 1.5mm²(AWG24 to16)

*Use applicable wire according to the measured current.

•RS485 communication

Screw size: Push IN type

Sectional area: single /stranded wire 0.13 to 1.5mm²(AWG24 to16)

•Output/Input

Screw size: Push IN type

Sectional area: single /stranded wire 0.13 to 1.5mm²(AWG24 to16)

•Analog input/RTD

Screw size: Push IN type

Sectional area: single /stranded wire 0.13 to 1.5mm²(AWG24 to16)

3.3 Measured-circuit

•It is not impossible to use to measure several loads by different strain power supply. (2-circuit of same system for 1 unit)

•Each unit (main unit, expansion unit (power measurement, power measurement + pulse output)) can measure 2-circuit of single-phase two-wire system, and 1-circuit of single-phase three-wire system or three-phase three-wire system. Each unit can be used with different phase and wire system. However be sure to check the wiring carefully.

•It is impossible to measure by only the expansion unit. Connect expansion units to main unit.
Up to 3 expansion units are connected to 1 main unit.

*Power source system

• Power source system is the electrical power system from one power source (normally one transformer).

•KW2M can measure 1-system max. 24-circuit of 1P2W system and 1-system max. 8-circuit of 1P3W and 3P3W system by connecting a main unit and expansion units.


•In order to measure several systems, it is necessary to use one main unit for each system.

3.4 Connection between the Main unit and the Expansion unit

•Turn off the power of main unit when connecting expansion units.

- Peel off connector label on the side before connecting.
(Do not peel off connector labels when not connecting.)
- It expands by connecting each male connector to female connector. Female connector is on the other side of male connector.
- After connecting, push the hooks into the unit to fix the expansion unit.
- Up to 3 expansion units can be connected per one main unit.

Note) Communication will be stopped or the measurement data will be lost when the units are removed or connected while turn on power.



3.5 Wiring Diagrams

Please connect a breaker or a fuse to the power supply and voltage input part for safety reasons and to protect the device.

- Recommended breaker: 3 to 15A (IEC approved or UL Listed)
- Recommended fuse : Time-lag fuse rated current 2A (IEC approved or UL Listed)


Grounding the secondary side of VT (Voltage transformer) and CT (Current transformer) is not necessary with low-voltage circuit.

*When using several CTs, set each CT approximately 1m apart. If the two CTs are set too close each other, it may not measure accurately due to magnetic field interference.

◆When measuring a load with rated input voltage


Single-phase two-wire system

- *One CT is needed to measure single-phase two-wire system.
- *2 CTs are needed to measure 2-circuit and 3 CTs are needed to measure 3-circuit.
- *To measure 2-circuit, wire 1 and 3. To measure 3-circuit, wire 1 and 3 and 5.



Single-phase three-wire/Three-phase three-wire


- *2 CTs are needed to measure single-phase three-wire system, three-phase three-wire system.
- *4 CTs are needed to measure 2-circuit.



Three-phase four-wire system


*3 CTs are needed to measure three-phase four-wire system.

*6 CTs are needed to measure 2-circuit.




Vn terminal should be connected to N-phase which is grounded.

- ◆When measuring a load with exceed input voltage
Voltage transformer (VT) is needed when you measure a load with over input voltage.
Use a VT, those secondary voltage rating is 110V.
Grounding the secondary side of VT and CT is not necessary with low-voltage circuit.



- ◆When measuring leak current (Only Expansion unit CH2)



By inputting the ground line of the equipment to CT input or direct current input, it is possible to measure the leakage current of the ground, and it can be used as equipment maintenance.

3.6 How to attach the Current Transformer (CT)




DANGER

- Never open the secondary circuit of CT under applying current to load.

- Use CT that the secondary side current is 5A or 1A.
- One CT is needed when measuring 1-circuit of 1P2W. Two CTs are needed when measuring 1P3W/3P3W (4 CTs for 2-circuit). Three CTs are needed when measuring 3P4W (6 CTs for 2-circuit). Using all CTs for one unit should be the same.
- Use the applicable wire, or it might cause a breakdown, burnout or electric shock.
- When connecting CT, connect the secondary side to the terminal of the main unit first, and after that wire the primary side to a load electric wire. **Incorrect order might cause an electric shock or break CT.**
- The CT has polarity. Wire correctly according to the K and L marks. **Wrong direction can't measure correctly.**
- If there is some distortion by harmonic or waveform, it may not measure correctly. Please check with the actual system before adopts it.
- Separate the wiring (strong electric part) of the measured voltage input terminal (operating power supply terminal) from the CT cable. It may not satisfy the accuracy due to noise.

(Connection example)



◆How to set the parameters for CT

- (1) Select CT type (CT-T) according to the using CT.
(Select '5A' if secondary side current of using CT is 5A. Select '1A' if secondary side current of using CT is 1A.)
- (2) Set the primary current of measured CT at primary side current of CT setting mode (CT-1).
< ex > If the measured CT is 400A/1A or 400A/5A, set to '400'.
- (3) Connect CT according to the CT direction, power side (K) to load side (L).


3.7 For Input Connection

- Pulse input
- Contact input

Use highly reliable metal plated contacts. Since the contact's bounce time leads directly to error in the count value, use contacts with as short a bounce time as possible. In general, select 30Hz for max.counting speed.
- Non-contact input (Transistor input)

Connect with an open collector. Use the transistor with the following specifications.
 $V_{CEO}=20V$ min. $I_C=20mA$ min. $I_{CBO}=6\mu A$ max
 Use transistors with a residual voltage of less than 3V when the transistor is ON.
 *Short-circuit impedance should be less than $1k\Omega$.
 Open-circuit impedance should be more than $100k\Omega$.
 (When the impedance is 0Ω , drain current is approx. 10mA.)
- Input wiring


Please wire as short as possible by using a shielded wire or a metallic electric wire tube individually.



3.8 For Output Connection


- PhotoMOS relay output

It adopts PhotoMOS relay output, there is no polarity.
 Output: Rated capacity 30V AC/DC, 0.1A



- Do not connect devices that voltage or load exceeds the rated capacity (30V AC/DC,0.1A)
- Please wire less than 100m for output.
 If it is long, it may not work correctly due to floating capacitance.


3.9 For Analog Input Connection (Expansion unit (Multi analog unit))



Note)

- Use double-core twisted-pair shielded wires. It is recommended to ground them. However, depending on the conditions of the external noise, it may be better not to ground the shielding.
- Do not have the analog input wiring close to AC wires, power wires, or load.
- Digital conversion value is not stable when it is not wired.

3.10 For RTD Input Connection (Expansion unit (Multi analog unit))




Note)


- For copper wires for wiring, use thick wires having insulation performance of IEC 60227-3 or equivalents to prevent a large increase in the electric resistance. (It is recommended to use shielded wires and to ground the shielding.)
- Do not have the resistance temperature detectors input wiring close to AC wires, power wires, or load.

3.11 RS485 Communication

- When using shielded cable for the RS485 transmission line, ground one end. Use a class D dedicated earth for grounding. Do not share a ground with other earth lines.
- Be sure to connect with daisy chain the RS485 transmission line between each unit. Do not use a splitter.
- To avoid noise, separate the transmission line from high-voltage line (power supply, voltage line).



◆How to connect KW2M (2-wire) and KW9M (3-wire)





3.12 Backup Battery for Clock

It is possible to back up the clock with backup battery for 1-month. In order to charge full, it is necessary to turn on the power for 2 days. If it turns off within 2 days from first installation, it may not back up the clock for 1-month.

Recommended Cable

Use the transmission cables shown below for Eco-POWER METER RS485 communication system.

Cable	Conductor		Insulator		Cable diameter	Applicable cable
	Size	Resistance (at 20°C)	Material	Thickness		
Twisted-pair with shield	1.25 mm ² (AWG16) or more	Max.16.8Ω/km	Polyethylene	Max. 0.5 mm	Approx. 8.5 mm	HITACHI KPEV-S 1.25 mm ² ×1P Belden Inc. 9860
	0.5 mm ² (AWG20) or more	Max.33.4Ω/km	Polyethylene	Max. 0.5 mm	Approx. 7.8 mm	HITACHI KPEV-S 0.5 mm ² ×1P Belden Inc. 9207
VCTF	0.75 mm ² (AWG18) or more	Max.25.1Ω/km	PVC	Max. 0.6 mm	Approx. 6.6 mm	VCTF 0.75 mm ² ×2C (JIS)

Cable	Section
Twisted-pair with shield	
VCTF	

Notes

- 1) Use shielded type twist cables.
- 2) Use only one type of the transmission cables.
- 3) Do not mix different types of the cables.
- 4) Use twisted-pair cables under a bad noise environment.

3.13 Low Voltage Directive

For using under the measurement category III, install varistors or SPD between the lines of power supply and the measured voltage input. Use the varistors or SPD which is complied with European standard and specifications to meet power supply and added current.

When using in the application conforming to EN61010-1/IEC61010-1, make sure to satisfy the following conditions.

- 1) RS485 communication part and pulse input part secure only basic insulation. In order to secure reinforced (double) insulation demanded by EN 61010-1/ IEC61010-1, secure basic insulation or more with load side and reinforced (double) insulation with RS485 communication system side.
- 2) Provide the voltage input part with an EN60947-1 or EN60947-3 compliant circuit breaker.
- 3) Use a wire with basic insulation or more for a wire cramped (or connected) CT
- 4) Vn terminal should be connected to N-phase which is grounded.

【Environmental conditions】

- Overvoltage category III, Pollution degree 2
- Indoor use
- An ambient temperature of -10 to +50°C
- An ambient non-condensing humidity of 30 to 85%RH (at 20°C)
- Altitude of 2000m or less

【Mount the product in a place with】

- A minimum of dust, and an absence of corrosive gases
- No flammable, explosive gasses
- Few mechanical vibrations or shocks
- No exposure to direct sunlight
- No large capacity electromagnetic switches or cables through which large current is flowing

3.14 Symbol List

Symbol	Explanation
	AC Voltage
	DC Voltage
	CE Mark Confirmation of conformity of the product with the applicable EU directives and compliance with the essential requirements contained in these directives
	Protective insulation, device with protection class II
	Products with this mark comply with both the Canadian and the American requirements

Chapter 4 Settings

You can set basic parameters for measuring using the keys on Eco-POWER METER. For the parameters for other functions, use Web browser to set.

(URL: <http://xxx.xxx.xxx.xxx/setup/index.htm> Input the setting IP address to 'xxx.xxx.xxx.xxx')

After wiring Eco-POWER METER and CT, power on and set the parameters for power measurement, Eco-POWER METER can measure the electric power. In order to use the other functions, set other parameters according to your use.

◆Keys' functions at setting mode

<MODE>	Shift to setting mode
<SET>	Set the items and values
<SHIFT/Λ>, <ITEM/>>	Select items and change values
<MODE>+<SET>	Select channels and units

◆Parameters for power measurement (for Main unit and Expansion unit (Power measurement))

○: Available —: Not available

Item		Range	Initial value	Setting	
				Keys	Web
Phase/Wire system		1P2W, 1P3W, 3P3W 3P4W	1P2W	○	
CT type		1, 5 [A]	5A		
Primary side current of CT		1 to 65535 [A]	5A		
VT secondary side voltage		100 to 690 [V]	230V		
VT primary side voltage		100 to 500000 [V]	230V		
Over voltage (ON threshold)		0.0 to 120.0 [%]	0.0%	—	○
Over voltage (OFF threshold)					
Under voltage (ON threshold)					
Under voltage (OFF threshold)					
Over current (ON threshold)					
Over current (OFF threshold)					
Under current (ON threshold)					
Under current (OFF threshold)					
Conversion rate (P) total		0.00 to 99.99/1kWh	10.00		
Conversion rate (P) time-zone1 *1					
Conversion rate (P) time-zone2 *1					
Conversion rate (P) time-zone3 *1					
Conversion rate (P) time-zone4 *1					
Conversion rate (-P) total					
Conversion rate (-P) time-zone1 *1					
Conversion rate (-P) time-zone2 *1					
Conversion rate (-P) time-zone3 *1					
Conversion rate (-P) time-zone4 *1					
Hour meter threshold (ON-time)		0.1 to 100.0 [%]	10.0%		
Hour meter threshold (Standby-time) *1		0.1 to 100.0 [%]	0.1%		
Power OFF time*1		Yes, No	No		
Target phase for hour meter		Phase1, Phase2, Phase3, All	All		
Cut-off current		0.1 to 50.0%	0.1%		
Simple-measurement	Setup	OFF, Fixed voltage/PF, Measure one CT	OFF		
	Voltage	0.0 to 500000.0 [V]	230V		
	PF	0.000 to 1.000	1.000		
Measurement mode *2		Power, Leak	Power	○	—

*1 only KW2M-X

*2 only expansion unit (power measurement)

◆Parameters for leakage current measurement (Expansion unit (Power measurement))

○: Available —: Not available

Item		Range	Initial value	Setting	
				Keys	Web
CT type(CT1/CT2/CT3)		1, 5 [A]	5A	○	○
Primary side current of CT (CT1/CT2/CT3)		1 to 65535 [A]	5A		
Leakage measurement	Threshold	0.01 to 100.00[%]	100.00%		
	Detect time	0.1 to 20.0[s]	20.0s		
Measurement mode *2		Power, Leak	Power	○	—

◆Parameters for demand measurement (Main unit, Expansion unit (Power measurement))

○: Available —: Not available

Item		Range	Initial value	Setting	
				Keys	Web
Power demand type		Sliding block, Fixed block	Sliding block	—	○
Power demand interval 1		1 to 60 [min.]	15		
Power demand interval 2		1 to 60 [min.]	1		
Power input		CT (CT input), Pulse(Pulse input)	CT		
Pulse unit		kWh (electric power), PLS (pulse constant)	kWh		
Pulse rate (convert to electric power)		0.001 to 100.000 [kWh]	1.000		
Pulse constant number		1000 to 99000[pulse/kWh]	50000		
Current demand interval		1 to 60 [min.]	15		
Total demand	Use	Available, Not available	Not available		
	Measured target *1	Main unitCH1 Main unitCH2 Expansion unit1 CH1 Expansion unit1 CH2 Expansion unit2 CH1 Expansion unit2 CH2 Expansion unit3 CH1 Expansion unit3 CH2	None		

*1 Can be selected several items.

◆Parameters for leakage measurement

Item		Range	Initial value	Setting	
				Keys	Web
CT type (CT1/CT2/CT3)		1, 5 [A]	5	○	○
Primary side current of CT (CT1/CT2/CT3)		1 to 65535 [A]	5		
Leakage threshold (CT1/CT2/CT3)		0.01 to 100.00 [%]	100.00		
Leakage delay time (CT1/CT2/CT3)		0.1 to 20.0 [s]	20.0		

◆Parameters for analog measurement

Item	Range	Initial value	Setting	
			Keys	Web
Input range (CH1/CH2/CH3)	0-60[V], 0-20[mA], 4-20[mA]	0-60	○	○
Scaling (min/max) (CH1/CH2/CH3)	-999999999 to 999999999	min:0 max:4000		
Point position (CH1/CH2/CH3)	0.0001, 0.001, 0.01, 0.1, 1	1		
Shift average frequency (CH1/CH2/CH3)	0, 2, 4, 8, 16	8		
RTD setting (CH1/CH2)	PT100, PT1000	PT100		

◆Parameters for pulse input and output (Main unit, Expansion unit (Digital I/O))

○: Available —: Not available

Item		Range	Initial value	Setting			
				Keys	Web		
Pulse input		30, 2000	30	—	○		
Pre-scale		0.001 to 100.000	1.000				
Target unit to monitor measurement value		Main unit CH1 Main unit CH2 Expansion unit 1 CH1 Expansion unit 1 CH2 Expansion unit 2 CH1 Expansion unit 2 CH2 Expansion unit 3 CH1 Expansion unit 3 CH2 Total demand	Main unit CH1				
Unit for pulse output (OUT1,OUT2,OUT3,OUT4)	kWh	0.001, 0.01, 0.1, 1, 10, 100 (kWh/1pulse)	0.001				
	alarm	Stand-by power, Active power, Reactive power, Apparent power, Over current, Under current, Power interruption, Power factor, Over voltage, Under voltage, Over frequency, Under frequency, Current THD, Voltage THD, Current harmonics, Voltage harmonics, Current unbalancing, Voltage unbalancing, Power demand, Current demand, Digital conversion value upper limit alarm, Digital conversion value lower limit alarm, Temperature upper limit alarm, Temperature lower limit alarm, Leak alarm					
	General-purpose	General output					
	Time Control*1	Start				0:00 to 24:00	0:00
		End				0:00 to 24:00	0:00
Target phase for pulse output (OUT1,OUT2,OUT3,OUT4)		Total, Phase1, Phase2, Phase3	total				
Target phase for alarm output (OUT1,OUT2,OUT3,OUT4)	electric power	Total, All, Phase1, Phase2, Phase3	total				
	current	All, Phase1, Phase2, Phase3, Phase N	All				
	Power interruption Over voltage Under voltage	All, Phase1, Phase2, Phase3, Line 1-2, Line 2-3, Line 3-1	All				
Integral direction (OUT1,OUT2,OUT3,OUT4)		P, -P	P				
Output pulse width		1 to 100 [ms]	1				
Stand-by alarm (threshold) (OUT1,OUT2,OUT3,OUT4)		0.1 to 100.0 [%]	100.0				
Stand-by alarm (start time) (OUT1,OUT2,OUT3,OUT4)		0 to 9999 [sec.]	0				
Stand-by alarm (phase) (OUT1,OUT2,OUT3,OUT4)		Phase1, Phase2, Phase3, All	All				

*1 only KW2M-X

Item	Range	Initial value	Setting	
			Keys	Web
Power alarm (active/reactive/apparent) threshold (ON/OFF) (OUT1,OUT2,OUT3,OUT4)	0.00 to 999999999.999 [kW/kvar/kVA]	999999999.999	—	○
PF alarm threshold (ON/OFF) (OUT1,OUT2,OUT3,OUT4)	0.000 to 1.000	0.000		
Over frequency alarm threshold (ON/OFF) (OUT1,OUT2,OUT3,OUT4)	0.00 to 100.00 [Hz]	100.00		
Under frequency alarm threshold (ON/OFF) (OUT1,OUT2,OUT3,OUT4)		0.00		
Voltage harmonics alarm threshold (ON/OFF) (OUT1,OUT2,OUT3,OUT4)	0.00 to 400.0 [%]	400.00		
Current harmonics alarm threshold (ON/OFF) (OUT1,OUT2,OUT3,OUT4)				
Current THD alarm threshold (ON/OFF) (OUT1,OUT2,OUT3,OUT4)				
Voltage THD alarm threshold (ON/OFF) (OUT1,OUT2,OUT3,OUT4)				
Voltage unbalancing alarm threshold (ON/OFF) (OUT1,OUT2,OUT3,OUT4)	0.00 to 300.00 [%]	300.00		
Current unbalancing alarm threshold (ON/OFF) (OUT1,OUT2,OUT3,OUT4)				
Power demand alarm power type (ON/OFF) (OUT1,OUT2,OUT3,OUT4)	Active, Reactive, Apparent, Active(Export), Reactive(Export)	Active		
Power demand alarm threshold(ON/OFF) (OUT1,OUT2,OUT3,OUT4)	0.000 to 99999.999 [kW/kvar/kVA]	0		
Current demand alarm threshold (OUT1,OUT2,OUT3,OUT4)	0.0 to 120.0 [%]	0		
Preset value (OUT1,OUT2,OUT3,OUT4)	0 to 999999	0		
Digital conversion value upper limit alarm threshold (ON/OFF) (OUT1,OUT2,OUT3,OUT4) *1	-999999999 to 999999999	999999999		
Digital conversion value lower limit alarm threshold (ON/OFF) (OUT1,OUT2,OUT3,OUT4) *1	-999999999 to 999999999	999999999		
Temperature upper limit alarm threshold (ON/OFF) (OUT1,OUT2,OUT3,OUT4)	-200.0 to 200.0[°C]	200.0		
Temperature lower limit alarm threshold(ON/OFF) (OUT1,OUT2,OUT3,OUT4)	-200.0 to 200.0[°C]	-200.0		

*1 Decimal point differs according to setting of AD setup.

◆Parameters for communication (RS485)

○: Available —: Not available

Item		Range		Initial value	Setting	
					Keys	Web
Protocol		MEWTOCOL, MODBUS(RTU),		MEWTOCOL	○	○
Device number	MEWTOCOL	1 to 99		1		
	MODBUS(RTU)	1 to 247				
Transmission speed		38400, 19200, 9600,4800, 2400, 57600, 115200 [bps]		19200		
Transmission format		8b-o(8bit odd), 8b-n(8bit none), 8bit-E(8bit even)		8b-o		
Stop bit		1,2		1		
Response time		1 to 99 [ms]		5		

◆Parameters for communication (Ethernet)

○: Available —: Not available

Item		Range	Initial value	Setting	
				Keys	Web
MEWTOCOL	Use	Available, Not available	Available	—	○
	Protocol	TCP,UDP	TCP		
	Port number	1024 to 65535	9094		
MODBUS(TCP)	Use	Available, Not available	Available	—	
	Protocol	TCP,UDP	TCP		
	Port number	502,1024 to 65535	502		
IP address	DHCP	Yes (available), No (not available)	No	○	
	Fixed IP address	1.0.0.0 to 255.255.255.255	192.168.1.5		
	Subnet mask		255.255.255.0		
	Default gateway		192.168.1.1		
DNS server	Acquisition method	Auto-setting, Manual-setting	Auto-setting	—	
	DNS server	0.0.0.0 to 255.255.255.255	0.0.0.0		
FTP Server *1	Use	Available, Not available	Available	—	
	Port number	21,1024 to 65535	21	—	
	Administrator name	half-width alphanumeric (64-letter)	admin	—	
	Password	half-width alphanumeric (16-letter)	admin	—	
Web server	Web server settings	Yes (available), No (not available)	Yes	○	
	User name (administrator)	half-width alphanumeric (64-letter)	admin	—	
	Password (administrator)	half-width alphanumeric (16-letter)	admin	—	
	Use Password (standard user)	Yes (available), No (not available)	Yes		
	User name (standard user)	half-width alphanumeric (64-letter)	user	—	
	Password (standard user)	half-width alphanumeric (16-letter)	user	—	
	Customer Web settings	Yes (available), No (not available)	Yes	—	

*1 only KW2M-X

◆Parameters for logging (only KW2M-X)

○: Available —: Not available

Item		Range		Initial value	Setting	
					Keys	Web
Save measurement log		Available, Not available		Not available	—	○
Save demand log		Available, Not available		Not available		
FTP Client	Use	Available, Not available		Not available		
	Server	0.0.0.0 to 255.255.255.255 or domain name(64-letter)		192.168.1.5		
	Access folder	half-width alphanumeric (64-letter)		/Log		
	User name	half-width alphanumeric (64-letter)		ftpcuser		
	Password	half-width alphanumeric (16-letter)		ftpcuser		
	Upload time	00:00:00 to 23:59:59		00:00:00		
	Retry interval	0 to 60[min]		10		
	Retry	0 to 10[times]		3		
	Connection time out	1 to 75[sec]		10		
	Upload data	Measurement log	Yes, No	No		
Demand log		Yes, No				
Customized logging data select	Use	Available, Not available		Not available		
	Item	Integral active power(1), (2), (3), Total integral active power, Integral reactive power(1), (2), (3), Total integral reactive power, Integral apparent power(1), (2), (3), Total integral apparent power, Export active power(1), (2), (3), Total export active power, Export reactive power(1), (2), (3), Total export reactive power, Instantaneous active power(1), (2), (3), Total instantaneous active power, Instantaneous reactive power(1), (2), (3), Total instantaneous reactive power, Instantaneous apparent power(1), (2), (3), Total instantaneous apparent power, R-current, S-current, T-current, N-current, Average of current, R-voltage (L1-N), S-voltage (L2-N), T-voltage (L3-N), Average of phase-voltage, RS-voltage (L1-L2), ST-voltage (L2-L3), TR-voltage (L3-L1), Average of line-voltage, Power factor(1), (2), (3), Average of power factor, Frequency(1), (2), (3), Average of frequency, Current THD(1), (2), (3), Average of current THD, Phase-voltage THD(1), (2), (3), Average of phase-voltage THD, Line-voltage THD(1), (2), (3), Average of line-voltage THD, ON-time, OFF-time, Stand-by time, Maintenance-time, Pulse count value		—		

		Digital conversion value1, Digital conversion value2, Digital conversion value3, Temperature1, Temperature2 Pulse count 1, Pulse count 2, Leakage current 1, Leakage current 2, Leakage current 3	—	—	○
--	--	--	---	---	---

◆Parameters for time program (only KW2M-X)

○: Available —: Not available

Item		Range	Initial value	Setting	
				Keys	Web
Program 1	time-zone	T1, T2, T3, T4, OFF	T4	—	○
	start-time	00:00 to 23:59	00:00		
Program 2	time-zone	T1, T2, T3, T4, OFF	T3		
	start-time	00:00 to 23:59	6:00		
Program 3	time-zone	T1, T2, T3, T4, OFF	T2		
	start-time	00:00 to 23:59	8:00		
Program 4	time-zone	T1, T2, T3, T4, OFF	T1		
	start-time	00:00 to 23:59	10:00		
Program 5	time-zone	T1, T2, T3, T4, OFF	T2		
	start-time	00:00 to 23:59	12:00		
Program 6	time-zone	T1, T2, T3, T4, OFF	T1		
	start-time	00:00 to 23:59	14:00		
Program 7	time-zone	T1, T2, T3, T4, OFF	T2		
	start-time	00:00 to 23:59	16:00		
Program 8	time-zone	T1, T2, T3, T4, OFF	T3		
	start-time	00:00 to 23:59	22:00		
Program 9	time-zone	T1, T2, T3, T4, OFF	OFF		
	start-time	00:00 to 23:59	—		
Program 10	time-zone	T1, T2, T3, T4, OFF	OFF		
	start-time	00:00 to 23:59	—		

<Initial setting for time program >

	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
T1													4-term(PG-4)			6-term(PG-6)									
T2													3-term(PG-3)			5-term(PG-5)				7-term(PG-7)					
T3																									8-term(PG-8)
T4																									

◆Parameters for Calendar timer (only KW2M-X)

○: Available —: Not available

Item		Range	Initial value	Setting	
				Keys	Web
Calendar timer		January 1 st , 2015 00:00:00 to December 31 st , 2099 23:59:59		○	
Time-zone		UTC-12:00 to UTC+14:00	UTC+9:00		
SNTP	Use	Available, Not available	Not available	—	○
	Port Number	123, 1204 to 65535	123		
	Access Time	00:00:00 to 23:59:59	00:00:00		
	Server	0.0.0.0 to 255.255.255.255 or half-width alphanumeric (32-letter)	192.168.1.5		
	Retry interval	0 to 60[min]	10		
	Retry times	0 to 10[times]	3		

◆Parameters for optional functions

○: Available —: Not available

Item		Range	Initial value	Setting	
				Keys	Web
Auto-off		0 to 99 [min.]	1	○	○
Display update cycle		0.5, 1.0, 2.0, 3.0 [sec.]	1.0 sec		
Reset all integral value		Yes, No	No		
Reset integral value 1		Yes, No	No		
Reset integral value 2		Yes, No	No		
Reset integral value 3		Yes, No	No		
Reset hour meter		Yes, No	No		
Reset count value		Yes, No	No		
Reset logging data		Yes, No	No		
Reset Memory *1		Yes, No	No	○	○
Version					

*1 only KW2M-X

◆Password

○: Available —: Not available

Item		Range	Initial value	Setting	
				Keys	Web
Password change		0000 to 9999	0000	○	—

4.1 Setting Flow


Arrow mark means press each key

.....> <MODE>
 → <SET>

⇒ <ITEM/>>
 ➡ <SHIFT/Λ>

◆ Main unit, Expansion unit (Power measurement)


Items with * are only for Main unit-CH1.



*1 'Voltage setting' is common to main unit CH1, CH2, expansion unit (power measurement) CH1, CH2.

*2 'IP address' and 'Subnet mask' are skipped when 'DHCP setting' is set to available.

*3 Only for expansion unit (power measurement) CH2




Press <SET> during each item is displayed to change the setting value.

Press <MODE> to display the confirmation window. Select [Yes] and press <SET> to decide the setting value. However no value is changed, the confirmation window is skipped and it displays the measuring value display.

*1 only KW2M-X


◆Expansion unit (Power measurement)) *Only when 'Unit type' is set to 'LEAK'.



Press <SET> during each item is displayed to change the setting value.

Press <MODE> to display the confirmation window. Select [Yes] and press <SET> to decide the setting value. However no value is changed, the confirmation window is skipped and it displays the measuring value display.


◆Expansion unit (Multi analog input)



Press <SET> during each item is displayed to change the setting value.

Press <MODE> to display the confirmation window. Select [Yes] and press <SET> to decide the setting value. However no value is changed, the confirmation window is skipped and it displays the measuring value display.

◆Expansion unit (Digital I/O)



Press <SET> during each item is displayed to change the setting value.

Press <MODE> to display the confirmation window. Select [Yes] and press <SET> to decide the setting value. However no value is changed, the confirmation window is skipped and it displays the measuring value display.

4.2 Password Entry

It is necessary to enter password to shift to setting mode.

Enter [0000] and shift to password setting mode when you set password at the first time.

*When setting password, be careful for handling and note it.

Measuring value display

↓<MODE>

M - 1	P a s s w o r d
0 - - -	

↓<SET>

M - 1	P o w e r

Press <MODE> and it shifts to password entry window.

Enter password from left to right using <ITEM/>>, <SHIFT/Λ>.

<SHIFT/Λ> Increase

<ITEM/>> Shift entered digit to the right

Press <SET> after enter the password.

If the password is correct, it shift to setting mode of power measurement.


If the password is wrong, [FAIL] is displayed and it returns to the password entry window.

*If you make wrong password 5 times, you can't set 1-hour after.

M - 1	P a s s w o r d
F a i l	

4.3 Password Initialize

When you forget the password, initialize it in the following procedures. (Initial: [0000])
It is impossible to decode the set password.



4.4 How to Set by Keys

■Set before measuring.

Select setting item with <ITEM/>> and press <SET>, and the value will be blinking.

Set with <ITEM/>> and <SHIFT/Λ>.

When you select [Yes] with the confirmation window and press <SET>, the setting values are settled.

Setting items with (※) can be set to each CH and each unit.

4.4.1 Settings for power measurement

*Only for Main unit and Expansion unit (Power measurement)

Phase/Wire system (※)

Select phase/wire system to measure.

M - 1	Power System
	1 P 2 W

Press <ITEM/>>, <SHIFT/Λ> to select.

[Set list]

1P2W, 1P3W, 3P3W, 3P4W (initial: 1P2W)

*When the system is not matched with the measure system, it doesn't measure correctly.

CT setting (※)

Select using CT type.

M - 1	Power CT
Primary	5 A
Secondary	5 A

Press <SET>, to select primary or secondary.

Press <ITEM/>>, <SHIFT/Λ> to set.

[Set range]

Primary side : 1 to 65535 (initial:5)

Secondary side: 5 (5A), 1 (1A) (initial: 5)



Increase



decrease

To use CT with secondary side current 5A: [5]

To use CT with secondary side current 1A: [1]

Voltage setting

Set the rated voltage to measure.

M - 1	Power VT
Primary	230 V
Secondary	230 V

Press <SET>, to select primary or secondary.

Press <ITEM/>>, <SHIFT/Λ> to set the voltage.

[Set range]

Primary side : 100 to 500000 (initial:230)

Secondary side: 100 to 690 (initial:230)

*Set the rated voltage when it doesn't use VT.



Increase



decrease

Unit type

*Only Expansion unit (Power measurement) CH2

Select the measured type.

1 - 1	Power
	Unit Type
	Power

Press <ITEM/>>, <SHIFT/Λ> to select.

[Set list]

Power, Leak (initial: Power)

4.4.2 Settings for leakage current measurement

*It is only when 'LEAK' is selected on Unit type.

CT setting**Select using CT type.**

1 - 2	Leak
	CH1 CT
Primary	65535A
Secondary	5A

Press <SET>, to select primary or secondary.

Press <ITEM/>>, <SHIFT/Λ> to set.

[Set range]

Primary side : 1 to 65535 (initial:5)

Secondary side: 5 (5A), 1 (1A) (initial: 5)



Increase



decrease

To use CT with secondary side current 5A: [5]

To use CT with secondary side current 1A: [1]

Leak measurement**Set conditions to detect leakage current.**

1 - 2	Leak
CH1 Leak measure	
Threshold	0.01%
Delay time	0.1s

Press <SET>, to select threshold or delay time.

Press <ITEM/>>, <SHIFT/Λ> to set.

[Set range]

Threshold: 0.01 to 100.00[%] (initial: 100%)

Delay time:0.1 to 20.0[s] (initial:20.0s)



Increase



decrease

Unit type

*Only for expansion unit (power measurement) CH2

Select measuring mode.

1 - 1	Leak
	Unit Type
	Leak

Press <ITEM/>>, <SHIFT/Λ> to select.

[Set list]

Power, Leak (initial: Power)

4.4.3 Settings for analog measurement

*Only for Expansion unit (Multi analog input)

Input range

Select input range.

1 - 1	Analog
CH1	Input range
	0 - 60 V

Press <ITEM/>>, <SHIFT/Λ> to select.

[Set list]

0-60V, 0-20mA, 4-20mA (initial: 0-60V)

Scaling value

Set max. value and min. value for scaling.

1 - 1	Analog
	CH1 Scaling
Min	0
Max	4000

Press <SET>, to select minimum or maximum.

Press <ITEM/>>, <SHIFT/Λ> to set.

[Set range]

Minimum: -999999999 to 999999999 (initial:0)

Maximum: -999999999 to 999999999 (initial:4000)



Increase



decrease

Point position

Select the decimal point position for measurement value display.

1 - 1	Analog
CH1	point position
	1

Press <ITEM/>>, <SHIFT/Λ> to select.

[Set list]

0.0001, 0.001, 0.01, 0.1, 1 (initial: 1)

Shift average frequency

Select shift average frequency.

1 - 1	Analog
CH1	Average
	0

Press <ITEM/>>, <SHIFT/Λ> to select.

[Set list]

0, 2, 4, 8, 16 (initial: 8)

RTD type

Select RTD type.

1 - 1	Analog
	RTD
	PT100

Press <ITEM/>>, <SHIFT/Λ> to select.

[Set list]

PT100, PT1000 (initial: PT100)

4.4.4 Settings for communication (RS485) *Only for Main unit

Protocol

Select protocol of main unit via serial communication (RS485).

*When protocol is changed, device number, transmission speed (baud rate), transmission format, stop bit and response time will be initialized.

M - 1	COM RS485
	Protocol
	MEWTOCOL

Press <ITEM/>>, <SHIFT/Λ> to select.

[Set list]

MEWTOCOL, MODBUS(RTU)
(initial: MEWTOCOL)

Device number

Set an individual device number for each unit when two or more units are connected to communicate via serial communication (RS485).

M - 1	COM RS485
	No
	99

Press <ITEM/>>, <SHIFT/Λ> to set.

The setting range differs according to the protocol.

[Set range] MEWTOCOL: 1 to 99
MODBUS(RTU): 1 to 247



increase



decrease

Transmission speed (Baud rate)

Select the serial communication (RS485) transmission speed.

Define the transmission speed according to the master's (PLC etc.).

M - 1	COM RS485
	Speed
	38400 bps

Press <ITEM/>>, <SHIFT/Λ> to select.

[Set list]

2400, 4800, 9600, 19200, 38400, 57600, 115200 [bps]
(initial: 19200)

Transmission format

Select serial communication (RS485) transmission format (Data length, Parity).
Define the transmission format according to the master's (PLC etc.).

M - 1	COM RS485
	Format
	8 b i t - o

Press <ITEM/>>, <SHIFT/Λ> to select.

[Set list]

8b-o (8bit odd), 8b-n (8bit none), 8b-E (8bit even)

(initial: 8b-o)

Stop bit

Select serial communication (RS485) stop bit.

M - 1	COM RS485
	Stop bit
	1 b i t

Press <ITEM/>>, <SHIFT/Λ> to select.

[Set list] 1, 2 (initial: 1)

Response time

Set serial communication (RS485) response time of main unit.

When command is received, it sends response after setting response time passes.

M - 1	COM RS485
	Response Time
	5 m s

Press <ITEM/>>, <SHIFT/Λ> to set.

[Set range] 1 to 99 ms (initial: 5)



increase



decrease

* If Data Logger Unit (DLU) or Data Logger Light (DLL) is used as a master, set the response time to 5ms or more because DLU or DLL send the response after 1.1ms or less from receive a command when transmission speed is set to 19200bps.

4.4.5 Settings for communication (Ethernet) *Only for Main unit

DHCP setting

Select DHCP for Ethernet communication.

M - 1	COM Ethernet
	DHCP
	No

Press <ITEM/>>, <SHIFT/Λ> to select.

[Set list] Yes (available), No (not available) (initial: No)

IP address

*It skips this item when [Yes] is set for DHCP setting.

Set IP address for Ethernet communication.

M - 1	COM Ethernet
	IP Address
	192.168.001.005

Press <ITEM/>>, <SHIFT/Λ> to set.

[Set range] 0. 0. 0. 0 to 255. 255. 255. 255
(initial: 192.168.1.5)



increase



decrease

Subnet mask

*It skips this item when [Yes] is set for DHCP setting.

Set subnet mask for Ethernet communication.

M - 1	COM Ethernet
	Subnet mask
	255.255.255.000

Press <ITEM/>>, <SHIFT/Λ> to set.

[Set range] 128. 000. 000. 000 to 255. 255. 255. 255
(initial: 255.255.255.0)



increase



decrease

Default Gateway

*It skips this item when [Yes] is set for DHCP setting.

Set default gateway for Ethernet communication.

```

M - 1      C O M   E t h e r n e t
           D e f u a l t   G a t e w a y
           1 9 2 . 1 6 8 . 0 0 1 . 0 0 1

```

Press <ITEM/>>, <SHIFT/Λ> to set.

[Set range] 0. 0. 0. 0 to 255. 255. 255.255
 (initial: 192.168.1.1)



increase



decrease

Web server setting**Select Web server setting for Ethernet communication.**

```

M - 1      C O M   E t h e r n e t
           w e b   S e r v e r
           Y e s

```

Press <ITEM/>>, <SHIFT/Λ> to select.

[Set list]

Yes (available), No (not available) (initial: Yes)

4.4.6 Settings for optional functions

Auto-off

*Only for Main unit

Display backlight turns off automatically when there is no key operation for a long time.
After it passes the setting time, backlight will turn off.

M - 1	Option
	Auto OFF
	5 min

Press <ITEM/>>, <SHIFT/Λ> to set.

[Set range] 0 to 99 min. (initial:5)



increase



decrease

Always turn on : [0]

Turn off after setting time: [1 to 99]

After turns off the backlight, any key operation makes it turns on.

Update cycle

*Only for Main unit

Select update cycle for measuring window.

It updates the display of measured values every setting time.

M - 1	Option
	Display update
	0.5 s

Press <ITEM/>>, <SHIFT/Λ> to select.

[Set list] 0.5, 1.0, 2.0, 3.0 [s] (initial:1.0)

Reset all integral value

*Only for Main unit and Expansion unit (Power measurement)

Integral power (active, reactive, apparent) can be reset at one time.

M - 1	Option
	All Reset
	Yes

Press <ITEM/>>, <SHIFT/Λ> to select.

[Set list] Yes, No (initial: No)

Reset all : [Yes]

Not reset : [No]

Reset integral value 1

*Only for Main unit and Expansion unit (Power measurement)

*It skips this item when [Yes] is selected for reset all integral value.

Reset the integral power of 1CH/1-phase (active, reactive, apparent) and integral export power of 1CH/1-phase (active, reactive).

M - 1	Option
	Reset 1
	Yes

Press <ITEM/>>, <SHIFT/Λ> to select.

[Set list] Yes, No (initial: No)

Reset : [Yes]

Not reset : [No]

Reset integral value 2

*Only for Main unit and Expansion unit (Power measurement)

*It skips this item when [Yes] is selected for reset all integral value.

Reset the integral power of 2CH/2-phase (active, reactive, apparent) and integral export power of 2CH/2-phase (active, reactive).

M - 1	Option
	Reset 2
	Yes

Press <ITEM/>>, <SHIFT/Λ> to select.

[Set list] Yes, No (initial: No)

Reset : [Yes]

Not reset : [No]

Reset integral value 3

*Only for Main unit and Expansion unit (Power measurement)

*It skips this item when [Yes] is selected for reset all integral value.

Reset the integral power of 3CH/3-phase (active, reactive, apparent) and integral export power of 3CH/3-phase (active, reactive).

M - 1	Option
	Reset 3
	Yes

Press <ITEM/>>, <SHIFT/Λ> to select.

[Set list] Yes, No (initial: No)

Reset : [Yes]

Not reset : [No]

Reset count value

*Only for Main unit and Expansion unit (Power measurement)

*It skips this item when [Yes] is selected for reset all integral value.

Reset the count value.

M - 1	Option
	Reset Count
	Yes

Press <ITEM/>>, <SHIFT/Λ> to select.

[Set list] Yes, No (initial: No)

Reset : [Yes]

Not reset : [No]

Reset count value 1

*Only for Expansion unit (Digital I/O)

Reset the count value 1 of expansion unit (digital I/O).

Press <ITEM/>>, <SHIFT/Λ> to select.

1 - 1	Option
	Reset Count 1
	Yes

[Set list] Yes, No (initial: No)

Reset : [Yes]

Not reset : [No]

Reset count value 2

*Only for Expansion unit (Digital I/O)

Reset the count value 2 of expansion unit (digital I/O).

Press <ITEM/>>, <SHIFT/Λ> to select.

1 - 1	Option
Reset Count 2	
Yes	

[Set list] Yes, No (initial: No)

Reset : [Yes]

Not reset : [No]

Reset hour meter

*Only for Main unit and Expansion unit (Power measurement)

*It skips this item when [Yes] is selected for reset all integral value.

Reset the values of measured by hour meter, ON-time, OFF-time, Stand-by-time, and Maintenance-time.

Press <ITEM/>>, <SHIFT/Λ> to select.

M - 1	Option
Reset Hour Meter	
Yes	

[Set list] Yes, No (initial: No)

Reset : [Yes]

Not reset : [No]

Reset log data

*Only for Main unit and Expansion unit (Power measurement)

*It skips this item when [Yes] is selected for reset all integral value.

Reset all log data.

Press <ITEM/>>, <SHIFT/Λ> to select.

M - 1	Option
Reset Log	
Yes	

[Set list] Yes, No (initial: No)

Reset : [Yes]

Not reset : [No]

Reset Memory (only KW2M-X)**Delete logging data (CSV file).**

Press <ITEM/>>, <SHIFT/Λ> to select.

M - 1	Option
Reset Memory	
Yes	

[Set list] Yes, No (initial: No)

Reset : [Yes]

Not reset : [No]

Version

You can check the software version.

M - 1	V e r s i o n
B a s e	
0 . 1 7	

It displays the software version.

4.4.7 Settings for calendar timer (only KW2M-X)

Time-zone

Set time-zone based on UTC standard.

Press <ITEM/>>, <SHIFT/Λ> to select.

M - 1	C l o c k
	T i m e z o n e
	U T C + 0 8 : 3 0

[Set list] UTC-12:00 to UTC+14:00(initial: UTC+9:00)

Clock

Set year, month, day and time.

Set the date and time to use logging function.

Press <SET> and year, month, date, time are blinking in turn.

With blinking the setting item and press <ITEM/>> and <SHIFT/Λ>.

M - 1	C l o c k
	2 0 1 5 / 0 1 / 0 1
	0 0 : 0 0 : 3 0

[Setting range]

January 1st, 2015 00:00:00

to December 31st, 2099 23:59:59

Caution;

The timing when the calendar timer is settled to the unit is the timing when you select [YES] with the confirmation window and press <SET>.

It doesn't set the calendar timer to the unit when you press <SET> with calendar timer setting window.

Give your attention when you set time by second.

4.4.8 Password setting

Password setting

You can set password for changing the settings.

It is necessary to enter the password before moving the setting mode.

We recommend you to set password to avoid unexpected change.

M - 2	P a s s w o r d
0 0 0 0	

Press <SET> and [0] on the left is blinking.
Set password using <ITEM/>>, <SHIFT/^>.



Increase



Shift entered digit to the right

Set from left to right. Make the digit to set blink.


[Set range] 0000 to 9999 (initial: 0000)

M - 2	P a s s w o r d
2 3 4 5	

Set 4-digit password and press <SET>
After that the confirm window is displayed.

↓ <SET>

M - 2	P a s s w o r d
N o	
2 3 4 5	



M - 2	P a s s w o r d
Y e s	
2 3 4 5	


[Set list] Yes, No (initial: NO)

Confirm: [Yes]

Not confirm: [No]

4.4.9 Confirmation window

Press <MODE> at any setting window and it shifts to confirmation window.



4.5 How to Set by Web Browser (System Web)

You can set by using Web browser.

Access to 'http://xxx.xxx.xxx.xxx/setup/index.htm'. Put the setting IP address to 'xxx.xxx.xxx.xxx'.

It is necessary to enter user name and password to access the website.

(Initial user name: admin, initial password: admin)

It may take time to get the website according to the communication environment.

4.5.1 Setting item

Select item from tabs to set

The image displays two screenshots of the KW2M Eco-POWER METER System Web interface. The top screenshot shows the main configuration page with numbered arrows 1-6 pointing to tabs: 1. Measurement, 2. Demand Power Rates, 3. Log, 4. Input, 5. Output, 6. Interface. The bottom screenshot shows the same page with an additional 'System setup' menu on the right, with numbered arrows 7-10 pointing to its items: 7. System setup, 8. Version, 9. Write to KW2M, 10. Read from KW2M. The interface includes various configuration sections like Main Unit, Power Measurement, Digitl IO, Multi Analog Input, VT Primary/Side, Over/Under voltage, CT Primary/Side, Over/Under current, and Cutoff current.

Item	Description
1 Measurement	Set parameters related to power measurement
2 Demand / Power Rates	Set parameters related to demand, conversion rate
3 Log *1	Set parameters related to log
4 Input	Set parameters related to pulse input
5 Output	Set parameters related to pulse output
6 Interface	Set parameters related to Ethernet and RS485 communication
7 System setup	Set parameters related to system
8 Version	Confirm version information
9 Write→KW2M	Write parameters to Eco-POWER METER
10 Read←KW2M	Read out parameters from Eco-POWER METER

*1 only KW2M-X

4.5.2 Settings for power measurement

Item	Description
1 Select unit and CH	Select unit and CH to set.
2 Phase/Wire system	Select phase and wire system to power measurement. <List> 1P2W, 1P3W, 3P3W, 3P4W (initial: 1P2W)
3 Cutoff current	Set a ratio of current for rated current used for cutoff that is not measured. <Range> 0.1 to 50.0% (initial:0.1)
4 Hour meter	Set target phase, ratio for rated current use to measure ON-time and standby time. Check box of [Power OFF Time], it measures as OFF-time when Eco-POWER METER turns off. *only KW2M-X supports standby time and power off time. <List> Target phase : Phase1, Phase2, Phase3, ALL (initial:Phase1) Threshold(ON Threshold) : 0.1 to 100.0% (initial:10.0) Standby Threshold *1 : 0.1 to 100.0% (initial:0.1) Power OFF Time *1 : Yes, No (initial: No)
5 Simple measuring	Select mode and set parameters for simple measuring. <List & Range> Type: OFF (no use) VLT/PF Fixed (Use actual current with fixed voltage and PF) Single CT (Use phase 1 current and all voltage) (initial: OFF) VLT* : 0.0 to 500000.0V (initial:230V) PF* : 0.000 to 1.000 (initial:1.000) * VLT and PF can be set when 'VLT/PF Fixed' is selected.

6	CT	Set parameters of CT. <Range> Primary side : 1 to 65535 (initial:5) Secondary side: 5 (5A), 1 (1A) (initial: 5)
7	VT*2	Set parameters of VT when VT is used. When VT is not used, set parameters of rated voltage to measure. <Range> Primary side : 100 to 500000 (initial:230) Secondary side: 100 to 690 (initial:230)
8	Over current*3	Set a ratio of current for rated current used for threshold to judge over current. <Range> 0.0 to 120.0% (initial:0.0)
9	Under current*3	
10	Over Voltage*3	
11	Under Voltage*3	< Range > 0.0 to 120.0% (initial:0.0)

*1 only KW2M-X

*2 Common to unit and CH.

*3 For KW2M-A, it is common to unit and CH. For KW2M-X, it set for unit and each CH.

4.5.3 Setting for leakage current measurement

Item	Description
1 CT	Set parameters of CT. <Range> Primary side : 1 to 65535 (initial:5) Secondary side: 5 (5A), 1 (1A) (initial: 5)
2 Leak measurement	Set a ratio for rated value used for threshold to judge leakage. <Range> 0.01 to 100.00% (initial:100.0)
3 Delay time	Set on delay time, from the time it exceeds the threshold to it output alarm. <Range> 0.1 to 20.0s (initial:20.0)

4.5.4 Settings for AD conversion

The screenshot shows the 'Multi Analog Input' configuration page for the KW2M Eco-POWER METER. The 'AD' sub-tab is selected under the 'Multi Analog Input' category. The settings for three channels (CH1, CH2, CH3) are displayed. A red dashed box highlights the settings for CH1, which are numbered 1 through 4:

- 1 Input range:** Radio buttons for 0-60V (selected), 0-20mA, and 4-20mA.
- 2 Scaling:** Min value set to 0 and Max value set to 4000.
- 3 Point position:** Radio buttons for 1, 0.1, 0.01, 0.001, and 0.0001 (selected).
- 4 Shift average frequency:** Radio buttons for 0 (selected), 2, 4, 8, and 16.

Item	Description
1 Input range	Select input range <List> 0-60V, 0-20mA, 4-20mA (initial: 0-60V)
2 Scaling	Set scaling for analog conversion <Range> Min : -999999999 to 999999999 (initial:0) Max : -999999999 to 999999999 (initial:4000)
3 Point position	Select the decimal point for measurement value display It effects to digital conversion value, scaling max. value and scaling min. value. <List> 1, 0.1, 0.01, 0.001, 0.0001 (initial:0.0001)
4 Shift average frequency	Select shift average frequency for measurement value When you select the bigger average frequency, you can suppress the unevenness. <List> 0, 2, 4, 8, 16 (initial: 8)

4.5.5 Settings for RTD measurement

Item	Description
1 Sensor type	Select sensor type for temperature measurement <List> PT100, PT1000 (initial: PT100)

4.5.6 Settings for demand and power rates

Click '◀ ▶' to shift window of 'Demand Setup' and 'Conversion rate Setup'.

[Demand Setup]

The screenshot displays the 'Demand Setup' interface of the KW2M Eco-POWER METER SystemWeb. The interface includes a top navigation bar with tabs for Measurement, Demand Power Rates (active), Log, Input, Output, and Interface. Below this, there are sections for Main Unit (CH1, CH2), Leak Measurement (CH1, LEAK), Digital IO (CH1, CH2), and Multi Analog Input (AD, RTD). The main 'Demand Setup' area is divided into two columns. The left column contains settings for 'Power demand' (1. Power demand type: Sliding block, 2. Power demand interval 1: 15 min, 3. Power input source: CT, 4. Pulse-power conversion method: Pulse constant, 50000 pulse/kWh) and 'Current demand' (5. Current demand interval: 15 min). The right column features a 'Sliding block demand conceptual diagram' showing power demand intervals over time.

Item	Description
1 Power demand type	Select type of power demand measurement. <List> Sliding block, Fixed block (initial: Sliding block)
2 Power demand interval	Set interval time to use for power demand measurement. <Range> Power demand interval 1 : 1 to 60min (initial:15) Power demand interval 2 : 1 to 60min (initial:1)
3 Power input source *1	Select input type to use for demand measurement, current measurement or pulse input. <List> CT, Pulse (initial: CT)
4 Pulse-Power Conversion Method *2	Select and set electric power value per 1-pulse or pulse constant value input by an outer pulse detector. <Range> Pulse rate : 0.001 to 100.000 kWh/pulse(initial:0.001) Pulse constant : 1000 to 99000 pulse/kWh(initial:50000)
5 Current demand interval	Set interval to use for current demand calculation. < Range > 1 to 60min(initial:15)

*1 Power input source is setting for main unit CH1.

*2 Pulse-Power Conversion Method is available when [Pulse] is selected for 'Power input source'.

[Combination Demand]

KW2M Eco-POWER METER SystemWeb

Measurement

Demand Power Rates

Log

Input

Output

Interface

Main Unit

CH1

CH2

Leak Measurement

CH1

LEAK

Digitl IO

CH1

CH2

Multi Analog Input

AD

RTD

Combination Demand

CH1

CH2

1

Main Unit

☒

☐

Leak Measurement

☐

☐

Digitl IO

☐

☐

Multi Analog Input

☐

☐

Item		Description
1	Combination Demand	Select channel to use for totalizing demand

[Conversion Rate Setup]

KW2M Eco-POWER METER SystemWeb

Menu

Measurement

Demand Power Rates

Log

Input

Output

Interface

Main Unit

CH1CH2

Expansion Unit 1

CH1CH2

Expansion Unit 2

CH1CH2

Expansion Unit 3

CH1CH2

1

Conversion Rate Setup

[Rate]	T1	T2	T3	T4	T	
[P/kWh]	10.00	10.00	10.00	10.00	10.00	(0.01~99.99)
[-P/kWh]	10.00	10.00	10.00	10.00	10.00	(0.01~99.99)

Time Program Setup

Rate	T	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Start-time	HH:MM	HH:MM	HH:MM	HH:MM	HH:MM	HH:MM	HH:MM	HH:MM	HH:MM
Time zone classification	00:00 06:00 12:00 18:00 00:00								

Image of KW2M-A

KW2M Eco-POWER METER SystemWeb

Menu

Measurement

Demand Power Rates

Log

Input

Output

Interface

Main Unit

CH1CH2

Leak Detection

CH1LEAK

Pulse IO

CH1CH2

Multi Measurement

ADRTD

1

Conversion Rate Setup

[Rate]	T1	T2	T3	T4	T	
[P/kWh]	10.00	10.00	10.00	10.00	10.00	(0.01~99.99)
[-P/kWh]	10.00	10.00	10.00	10.00	10.00	(0.01~99.99)

2

Time Program Setup

Rate	T4	T3	T2	T1	T2	T1	T2	T3	OFF	OFF
Start-time	00:00	06:00	08:00	10:00	12:00	14:00	16:00	22:00	HH:MM	HH:MM
Time zone classification	00:00 06:00 12:00 18:00 00:00									

Image of KW2M-X

60

Item	Description
1 Conversion rate Setup	Set the conversion rate per integral active power (import and export) 1 kWh. < Range > P/kWh : 0.01 to 99.99 (initial:10.00) -P/kWh : 0.01 to 99.99 (initial:10.00)
2 Time Program Setup*1	You can set 10-type time program. Set start time for each time zone, and use it link with conversion rate. Refer to 5.2 in detail. <List & Range> Rate:T1, T2, T3, T4, OFF Start-Time: 00:00 to 23:59

*1 only KW2M-X

4.5.7 Settings for log (only KW2M-X)

[Log Setup]

	Upload data	Measurement log	Demand log
Main Unit	CH1	☐	☐
	CH2	☐	☐
Leak Measurement	CH1	☐	☐
	CH2	☐	☐
Digitl IO	CH1	☐	☐
	CH2	☐	☐
Multi Analog Input	CH1	☐	☐
	CH2	☐	☐

Item	Description
1 Log item	Select log item to save with .csv. For measurement log, it saves the instantaneous value of every 5-min and every 15-min. For demand log, it saves demand value. Save measurement log : Yes, No(initial: No) Save demand log : Yes, No(initial: No)
2 FTP Client	Set items related to upload log file to FTP server. Log files are uploaded once a day at the designated time. You can test to upload using [Transmission test]. <List & Range> Transmit log data to FTP server : Yes, No(initial: No) Port number : 21, 1024 to 65535(initial:21) Server name : 0.0.0.0 to 255.255.255.255 or domain name(64-letter) Access folder : half-width alphanumeric(64-letter) User name : half-width alphanumeric(64-letter) Password : half-width alphanumeric(16-letter) Upload time : 00:00:00 to 23:59:59 (initial:00:00:00) Retry interval : 0 to 60[min](initial:10) Retry : 0 to 10[times](initial :3) Connection time-out : 1 to 300(initial:10)
3 Upload data	Select files to upload to FTP server. You can select the target log files of each unit and CH.

[Customized log Setup] *1

KW2M Eco-POWER METER SystemWeb

Measurement Demand Power Rates **Log** Input Output Interface

Main Unit: CH1 CH2 Leak Measurement: CH1 LEAK Digital IO: CH1 CH2 Multi Analog Input: AD RTD

Logging Data Select

Item	Phase/CH
☒ Integral active power	Phase1
☒ Integral reactive power	Phase1
☒ Integral apparent power	Phase1
☒ Integral regenerative active power	Phase1
☒ Integral regenerative reactive power	Phase1
☒ Instantaneous active power	Phase1
☒ Instantaneous reactive power	Phase1
☒ Instantaneous apparent power	Phase1

Item	Description
1 Logging Data Select	Select items to be logged in one csv file, up to 8 items. <List> Integral active power(1), (2), (3), Total integral active power, Integral reactive power(1), (2), (3), Total integral reactive power, Integral apparent power(1), (2), (3), Total integral apparent power, Export active power(1), (2), (3), Total export active power, Export reactive power(1), (2), (3), Total export reactive power, Instantaneous active power(1), (2), (3), Total instantaneous active power, Instantaneous reactive power(1), (2), (3), Total instantaneous reactive power, Instantaneous apparent power(1), (2), (3), Total instantaneous apparent power, R-current, S-current, T-current, N-current, Average of current, R-voltage (L1-N), S-voltage (L2-N), T-voltage (L3-N), Average of phase-voltage, RS-voltage (L1-L2), ST-voltage (L2-L3), TR-voltage (L3-L1), Average of line-voltage, Power factor(1), (2), (3), Average of power factor, Frequency(1), (2), (3), Average of frequency, Current THD(1), (2), (3), Average of current THD, Phase-voltage THD(1), (2), (3), Average of phase-voltage THD, Line-voltage THD(1), (2), (3), Average of line-voltage THD, ON-time, OFF-time, Stand-by time, Maintenance-time, Pulse count value, Digital conversion value1, Digital conversion value2, Digital conversion value3, Temperature1, Temperature2 Pulse count 1, Pulse count 2, Leakage current 1, Leakage current 2, Leakage current 3

*1 only KW2M-X main unit

4.5.8 Settings for pulse input (only Main unit and Expansion unit (Digital I/O))

1 Main Unit CH1 CH2

2 Input type

3 Max. counting speed

4 Pre-scale

5 Synchronize time

Select 'Hour meter maintenance' for Input type

Item	Description
1 Select CH	Select CH to set.
2 Input type	Select usage of input <List> Pulse count, Clock sync.*1, Hour meter maintenance*1 (initial : Pulse count)
3 Max counting speed	Select pulse input max. counting speed. < List > 30Hz, 2kHz (initial:30Hz)
4 Pre-scale	Set pre-scale value used to convert count value of pulse input. < Range > 0.001 to 100.00 (initial:1.000)
5 Synchronize time *1	Set time to synchronize when pulse is input. *The clock is different 1-hour or more from the setting time, it doesn't synchronize. <Range> 00:00 to 23:59(initial:00:00)

*1 only KW2M-X main unit

4.5.9 Settings for pulse output (only Main unit and Expansion unit (Digital I/O))

You can select the unit and CH to be measured for each CH of pulse output.

[Integral power pulse]

Item	Description
1 Select CH	Select CH to set.
2 Output type	Select pulse output type. < List > Integral power pulse, Alarm, Time control*1, General output (initial: Integral power pulse)
3 Measured target	Select unit and CH to measure. < List > Main Unit CH1, Main Unit CH2, Power Measurement CH1, Power Measurement CH2*2 (initial: Main Unit CH1)
4 Unit for output	Set unit used for pulse output. < List > 0.001, 0.01, 0.1, 1, 10, 100kWh (initial: 0.001)
5 Direction	Select the direction of power (import or export) for using as a threshold for pulse output. < List > P, -P (initial: P)
6 Target phase	Select phase to monitor in order to judge the output. * Select 'Total' when it measures 3P3W. < List > Phase1, Phase2, Phase3, Total (initial: Total)
7 Pulse width	Set pulse width. < Range > 1 to 100ms (initial: 1)

*1 only KW2M-X

*2 only when CH2 of expansion unit (power measurement) is set to measure power

[Alarm]

It differs the display according to the selected unit and CH.

- When you select main unit CH1, main unit CH2, expansion unit (power measurement) CH1 or expansion unit (power measurement) CH2, set to power measurement.

With checks to several boxes, it output alarm when it meets one of these conditions.

Item	Description
1 Select CH	Select CH to set.
2 Output type	Select pulse output type. < List > Integral power pulse, Alarm, General output (initial: Integral power pulse)
3 Measured target	Select unit and CH to measure. It differs the display according to the selected item. < List > Main Unit CH1, Main Unit CH2, Power Measurement CH1, Power Measurement (Leak Measurement) CH2, Pulse IO, Multi Measurement, Combination Demand (initial:Main Unit CH1)
4 Stand-by power	Select phase to monitor and set threshold to use for output. <List & Range> Target phase : Phase1, Phase2, Phase3, ALL (initial: ALL) Threshold: 0.1 to 100.0% (initial: 0.1%) Elapsed: 0 to 9999min (initial: 0)

Item	Description
5 Active power	Select phase to monitor and set threshold to use for output. *Select 'Total' when measuring 3P3W.
6 Reactive power	<List & Range> Target phase:Phase1, Phase2, Phase3, ALL, Total (initial: Total) OFF threshold : 0.00 to 9999999999.99 (initial: 9999999999.99) ON threshold : 0.00 to 9999999999.99 (initial: 9999999999.99)
7 Apparent power	
8 Over current	
9 Under current	Select phase to monitor. *The threshold is the ratio that is set at 'Setting for Power Measurement'.
10 Power interruption	
11 Power factor	< List > Target phase:Phase1, Phase2, Phase3, ALL (initial: ALL)
12 Count value	Select phase to monitor and set threshold to use for output. *Select 'All' when measuring 3P3W. < List & Range > Target phase:Phase1, Phase2, Phase3, ALL (initial: ALL) OFF threshold : 0.00 to 9999999999.99 (initial: 9999999999.99) ON threshold : 0.00 to 9999999999.99 (initial: 9999999999.99)
13 Over Voltage	Set a value of count to use for alarm output. <Range> 0 to 999999 (initial: 0)
14 Under Voltage	
15 Over frequency	Select phase to monitor. *The threshold is the ratio that is set at 'Setting for Power Measurement'. < List > Target phase:Phase1, Phase2, Phase3, ALL (initial: ALL)
16 Under frequency	
17 Current THD	Select phase to monitor and set threshold to use for output. < List & Range > Target phase:Phase1, Phase2, Phase3, ALL (initial: ALL) OFF threshold : 0.00 to 100.00Hz (initial:100.00) ON threshold : 0.00 to 100.00Hz (initial:100.00)
18 Voltage THD	
19 Current harmonics	Select phase to monitor and set threshold to use for output. < List & Range > Target phase:Phase1, Phase2, Phase3, ALL (initial: ALL) OFF threshold : 0.00 to 400.00% (initial:400.00) ON threshold : 0.00 to 400.00% (initial:400.00)
20 Voltage harmonics	
21 Current unbalancing	Select phase to monitor and set threshold to use for output. < Range > OFF threshold : 0.00 to 300.00% (initial:300.00) ON threshold : 0.00 to 300.00% (initial:300.00)
22 Voltage unbalancing	

Item	Description
23 Power demand	Select demand type to monitor and set threshold to use for output. < List & Range > Power Type : Active, Reactive, Apparent, Active(Export), Reactive(Export) (initial: Active) OFF threshold : 0.000 to 999999999.999 (initial:999999999.999) ON threshold : 0.000 to 999999999.999 (initial:999999999.999)
24 Current demand	Select phase to monitor and set threshold to use for output. < List & Range > Target phase:Phase1, Phase2, Phase3, ALL (initial: ALL) OFF threshold : 0.00 to 120.00% (initial:0.00) ON threshold : 0.00 to 120.00% (initial:0.00)

- When 'Leak measurement CH2' is selected with unit type

Item	Description
1 Select CH *	Select CH to set.
2 Output type	Select pulse output type. < List > Integral power pulse, Alarm, Time control*1, General output (initial: Integral power pulse)
3 Measured target	Select unit and CH to measure. <List> Main Unit CH1, Main Unit CH2, Power Measurement CH1, Power Measurement (Leak Measurement) CH2, Pulse IO, Multi Measurement, Combination Demand (initial:Main Unit CH1)
4 Monitor target	Select circuit to monitor.

*1 only KW2M-X

- When 'Pulse I/O' is selected for measured target

Item	Description
1 Select CH *	Select CH to set.
2 Output type	Select pulse output type. < List > Integral power pulse, Alarm, Time control*1, General output (initial: Integral power pulse)
3 Measured target	Select unit and CH to measure. <List> Main Unit CH1, Main Unit CH2, Power Measurement CH1, Power Measurement (Leak Measurement) CH2, Pulse IO, Multi Measurement, Combination Demand (initial:Main Unit CH1)
4 Monitor target	Select circuit to monitor.

*1 only KW2M-X

- When 'Multi measurement' is selected for measured target

Item	Description
1 Select CH	Select CH to set.
2 Output type	Select pulse output type. <List> Integral power pulse, Alarm, Time control*1, General output (initial: integral power pulse)
3 Measured target	Select unit and CH to measure. <List> Main Unit CH1, Main Unit CH2, Power Measurement CH1, Power Measurement (Leak Measurement) CH2, Pulse IO, Multi Measurement, Combination Demand (initial:Main Unit CH1)
4 AD upper limit	Select CH to monitor and set threshold to use for output
5 AD lower limit	<Range> OFF threshold : -999999999 to 999999999 (initial: 999999999) ON threshold : -999999999 to 999999999 (initial: 999999999)
6 Temperature upper limit	Select CH to monitor and set threshold to use for output
7 Temperature lower limit	<Range> OFF threshold : -200.0 to 200.0 (initial: 200) ON threshold : -200.0 to 200.0 (initial: 200)

*1 only KW2M-X

- When 'Combination Demand' is selected for measured target

Item	Description
1 Select CH	Select CH to set.
2 Output type	Select pulse output type. <List> Integral power pulse, Alarm, Time control*1, General output (initial: integral power pulse)
3 Measured target	Select unit and CH to measure. <List> Main Unit CH1, Main Unit CH2, Power Measurement CH1, Power Measurement (Leak Measurement) CH2, Pulse IO, Multi Measurement, Combination Demand (initial:Main Unit CH1)
4 Power demand	Select demand type to monitor and set threshold to use for output. < List & Range > Power Type : Active, Reactive, Apparent, Active(Export), Reactive(Export) (initial: Active) OFF threshold : 0.000 to 999999999.999 (initial:999999999.999) ON threshold : 0.000 to 999999999.999 (initial:999999999.999)

*1 only KW2M-X

[Time control] (only KW2M-X)

The screenshot shows the 'Output' menu of the KW2M Eco-POWER METER SystemWeb. The 'Output type' is set to 'Time control'. Below this, the 'Output-ON period' is configured for each day of the week. The 'Start' and 'End' times are both set to 00:00. The 'Output Test' button is visible in the top right corner of the configuration panel.

Day	Start	End
Sunday	00 : 00	00 : 00
Monday	00 : 00	00 : 00
Tuesday	00 : 00	00 : 00
Wednesday	00 : 00	00 : 00
Thursday	00 : 00	00 : 00
Friday	00 : 00	00 : 00
Saturday	00 : 00	00 : 00

Item	Description
1 Output-ON period	Set time to output ON and OFF for each day. <Range> Start : 00:00 to 24:00 (initial:00:00) End : 00:00 to 24:00 (initial:00:00)

4.5.10 Settings for Ethernet and RS485 communication

Click '◀ ▶' to shift window of 'Ethernet Setup' and 'RS485 Setup'.

[Ethernet Setup]

KW2M Eco-POWER METER SystemWeb

Measurement Demand Power Rates Log Input Output Interface

Main Unit CH1 CH2 Leak Measurement CH1 LEAK Digital IO CH1 CH2 Multi Analog Input AD RTD

1 ☐ Obtain an IP address automatically
☒ Use the following IP address
 IP address 192.168.1.5
 Subnet mask 255.255.0.0
 Default gateway 192.168.1.1

2 ☐ Obtain DNS server address automatically
☒ Use the following DNS server addresses
 Preferred DNS 0.0.0.0
 Alternate DNS 0.0.0.0

Ethernet Setup

3 ☒ Use MEWTOCOL-COM Port number 9094
 Protocol ☒ TCP ☐ UDP

4 ☒ Use MODBUS-TCP Port number 502
 Protocol ☒ TCP ☐ UDP

5 ☒ Use FTP server Port number 21
 Change password

Item	Description
1 IP address	Select setting method of IP address. When you set manually, IP address, subnet mask and default gateway can be set by yourself. < Range > Setting IP address: Obtain an IP address automatically, Use the following IP address IP address: 001. 000. 000. 000 to 255. 255. 255. 255 (initial: 192.168.1.5) Subnet mask: 128. 000. 000. 000 to 255. 255. 255. 255 (initial: 255.255.255.0) Default gateway: 001. 000. 000. 000 to 255. 255. 255.255 (initial: 192.168.1.1)
2 DNS Server	Select setting method of DNS server When you set manually, IP address of Preferred DNS and Alternate DNS can be set by yourself. <Range> Setting DNS server: Obtain DNS server address automatically Use the following DNS server addresses Preferred DNS: 0.0.0.0 to 255.255.255.255(initial:0.0.0.0) Alternate DNS: 0.0.0.0 to 255.255.255.255(initial:0.0.0.0)
3 MEWTOCOL-COM	Set protocol and port number. < List & Range > Protocol: TCP, UDP (initial: TCP) Port number: 1024 to 65535 (initial:9094)

Item	Description
4 MODBUS-TCP	Set protocol and port number. < List & Range > Protocol: TCP, UDP (initial: TCP) Port number: 502, 1024 to 65535 (initial:502)
5 FTP Server	Set FTP server. <Range> Port number:21, 1024 to 65535(initial:21) Administrator name : half-width alphanumeric (64-letter) (initial: admin) Password : half-width alphanumeric(16-letter)(initial: admin)

[RS485 Setup]

KW2M Eco-POWER METER SystemWeb

Measurement Demand Power Rates Log Input Output Interface

Main Unit CH1 CH2 Leak Measurement CH1 LEAK Digital IO CH1 CH2 Multi Analog Input AD RTD

RS485 Setup

Protocol ☒ MEWTOCOL ☐ MODBUS RTU

Device number 1

Transmission speed 19200bps

Transmission format

Data length (8bit fixed)

Parity odd

Stop bit 1bit

Response time 5 [ms] (1~99)

Item	Description
1 Protocol	Select communication protocol < List > MEWTOCOL, MODBUS RTU (initial: MEWTOCOL)
2 Device number	Set device number. < Range > MEWTOCOL:1 to 99 MODBUS RTU:1 to 247
3 Transmission speed	Select transmission speed. < List > 2400, 4800, 9600, 19200, 38400, 57600, 115200bps (initial:19200)
4 Transmission format	Select transmission format. < List > Parity: none, odd, even (initial: odd) Stop bit:1bit, 2bit (initial:1bit)
5 Response time	Set response time. < Range > 1 to 99ms (initial:5)

4.5.11 System setup

[System setup]

Item	Description
1 Current time *1	Set year, month, day, time and time-zone to Eco-POWER METER. Click [Change time] to write the settings. Even if you click [Write→KW2M], current time is not set. <Range> Set time : January 1st, 2015 00:00:00 to December 31st, 2099 23:59:59 Time zone : UTC-12:00 to UTC+14:00 (initial:UTC+9:00)
2 Setting File	It saves setup conditions of Eco-POWER METER to your PC and it writes setup conditions, which are saved in PC, to Eco-POWER METER. <Item> Export: Save setup conditions of Eco-POWER METER to PC. Import: Read out setup conditions saved in PC. Browse: Select setup file which are saved in PC.
3 System Web Password	Set password to access Web page.
4 Setting Customer Web *1	Check the box to upload and download web contents that is created by Control Web Creator. When you check the box, you can upload and download. 6<List> Yes, No (initial: Yes)
5 Monitor Web/Customer Web Password*1	Set password to access Monitor Web and Customer Web. <Range> User Name : half-width alphanumeric (64-letter)(initial: user) Password : half-width alphanumeric (16-letter)(initial: user)

6	SNTP setting *1	Set items to adjust time by SNTP. Click [Sync now] to synchronize by SNTP server. <Range> Port number : 123, 1024 to 65535(initial:123) Server : 0.0.0.0 to 255.255.255.255 or half-width alphanumeric (32-letter) Access Time : 00:00:00 to 23:59:59(initial:00:00:00) Retry interval : 0 to 60[min](initial:10) Retry : 0 to 10[times](initial:3)
7	Backlight auto-off	Display backlight turns off automatically when there is no key operation for a long time. After it passes the setting time, backlight will turn off. < Range > 0 to 99min (initial:5)
8	Screen refresh interval	Select refresh interval for measuring window. It updates the display of measured values every setting time. < List > 0.5, 1.0, 2.0, 3.0s (initial:1.0)

*1 only KW2M-X

[Reset Data]




Image of KW2M-X

Item		Description
1	Select unit and CH	Select unit and CH to reset.
2	Select item	Select data item to reset. After selecting item, click 'Reset' to reset.
3	Delete log(CSV file)*1	Click to delete log files.

*1 only KW2M-X

Chapter 5 Various Functions

5.1 Power Quality Measurement and Logging Function

KW2M Eco-POWER METER can measure harmonics and THD for power quality measurement; therefore it is helpful to improve the power quality.

[Max. demand]

Maximum value of measured demand value (active, reactive, apparent, active (export), reactive (export), current)) are considered to the max. demand value. And it records the max. demand value.

5.2 Pulse Output Function

<Main unit>

You can use 2-type pulse output, OUT1 and OUT2.

Refer to 4.5.9 Settings for pulse output.


[OUT1][OUT2] are blinking when it output pulse.

<Expansion unit (Digital I/O)>

You can use 4-type pulse output.

Refer to 4.5.9 Settings for pulse output.

[OUT1][OUT2][OUT3][OUT4] are blinking when it output pulse on the expansion unit display.



5.2.1 Output depends on integral electric power

Set the unit for pulse output of integral power value and pulse output turns on every time when integral electric power reaches the unit. (Pulse width: about 100ms)

It judges at the same time of sampling cycle.

5.2.2 Stand-by alarm


When it detects stand-by power (current) of the measured load, pulse output turns on in order to notice.

Set threshold (current) (C) and stand-by time (T) to judge stand-by power.

When the measured load is satisfied the setting conditions, pulse putout turns on in order to notice.

When it exceeds the setting threshold, it turns off and reset it.

(Working flow chart)



5.2.3 Under voltage alarm

When it falls below the setting voltage, pulse output turns on in order to notice.

When it exceeds, the output turns off.

5.2.4 Over voltage alarm

When it exceeds the setting voltage, pulse output turns on in order to notice.

When it falls below, the output turns off.

5.2.5 Power interruption alarm

When it detects the voltage under 5% of rated voltage for 5ms or more, pulse output turns on in order to notice.

5.2.6 Under current alarm

When it falls below the setting current, pulse output turns on in order to notice.
When it exceeds, the output turns off.

5.2.7 Current alarm

When it exceeds the setting current, pulse output turns on in order to notice.
When it falls below, the output turns off.

5.2.8 Power alarm

When it exceeds the setting instantaneous electric power (active, reactive, apparent, active (export), reactive (export)), pulse output turns on in order to notice.
When it falls below, the output turns off.

5.2.9 Other alarms

Output turns on or off according to each alarm setting.

PF alarm, over frequency alarm, under frequency alarm, voltage harmonics alarm, current harmonics alarm, voltage THD alarm, current THD alarm, voltage unbalancing alarm, current unbalancing alarm, power demand alarm, current demand alarm, Digital conversion value upper limit alarm, Digital conversion value lower limit alarm, Temperature upper limit alarm, Temperature lower limit alarm, Leak alarm

5.2.10 Output depends on count value

Set the preset value and pulse output turns on the time when count value reaches the preset value.
Refer to the next in detail.

5.2.11 Time Control (only KW2M-X)

Output turns on or off according to the setting time for each day.

5.2.12 Level output


It runs on or off the output by writing 0 (OFF) or 1 (ON) to the designated data register (OUT1: DT50294, OUT2: DT50295) via communication by external control.

5.3 Counter Function

●Operation mode

Maintain output hold count **HOLD**

[Output] OFF ON



- (1) Output control is maintained after count-up completion and until reset. However counting is possible despite of count-up completion.
- (2) It reverts "0" after counting up full scale, but output control is maintained. However output is OFF if count value or preset value is changed.

●Change the Preset Value

It is possible to change the preset value even during counting. However note the following points.

◇When the pre-scale value is "1.000". (PSCL=1.000)

- (1) If the preset value is changed to the value less than the count value, counting will continue until it reaches full scale, returns to "0" and then reaches the new preset value.
- (2) If the preset value is changed to "0", it will not count up at start with "0". It counts up when the counting value comes to "0" again (after reach to full scale). However output is OFF if count value or preset value is changed.
- (3) When the count value is fixed, output is changed according to the changing of preset value as below.
 - ① If the preset value is changed to the value less than the count value or same as count value, output is ON.
(Count value $\geq$ Preset value)
 - ② If the preset value is changed to the value more than the count value, output is OFF.
(Count value $<$ Preset value)

◇When the pre-scale is not "1.000". (PSCL $\neq$ 1.000)

Even if the preset value is changed after counting to full scale, output is not changed.

5.4 Clock Correction Function (only KW2M-X)

This is the function that it corrects the clock of Eco-POWER METER by selecting 'Clock sync.' for pulse input type. However, the setting time is different from Eco-POWER METER time one-hour or more, it doesn't synchronize.

Ex.) When you set [00:00] for synchronize time

Input pulse 1 makes clock April 2, 2015 00:00:00 when it was April 1, 2015 23:59:00.

5.5 Hour Meter Function

This is the function that it measures several types of hours.

- When load current is over the setting current for time measurement (ON threshold), it measures as ON-time.

For KW2M-A, when load current is in the range of 0.001A to ON threshold, it measures as Standby-time. When load current is 0.000A, it measures OFF-time.

For KW2M-X, when load current is in the range of stand-by threshold to ON threshold, it measures as Standby-time. When load current is under stand-by threshold, it measures as OFF-time.

- It measures as maintenance-time as the below conditions.

Write '1' to DT5(N)(C)28

*1

Input ON with the input type set to 'Hour meter maintenance' *2


- *1 (N) and (C) are the value according to the unit and CH as below.

(N) unit number main unit: 0, expansion unit1: 1, expansion unit2: 2, expansion unit3: 3

(C) CH number CH1: 0, CH2: 5

- *2 only KW2M-X

Load current



5.6 Demand Function

You can select demand calculation methods for KW2M Eco-POWER METER from the bellows.

- According to IEC61557-12
 1. Sliding block interval demand
 2. Fixed block interval demand
 3. Current demand

Please use this simple demand function as your standard. The value is not guaranteed.

Caution

Definition of Demand

It is demand measurement in order to use by yourself as your standard.

5.6.1 Block interval demand

It calculates demand by setting interval and displays.

You can select sliding block or fixed block for interval.


It output demand alarm according to the setting conditions.

Sliding block

Set power interval by 1 to 60(min.) (every 1-min.). It calculates demand during latest finished interval and displays.


One interval is started every time that set for 'power demand interval 2'.

Ex.) Power demand interval: 15 min. Power demand interval 2: 1 min.



Fixed block

Set power interval by 1 to 60 (min.) (every 1-min.) It calculates demand during latest finished interval and displays. After one interval finishes, the next interval starts.




5.6.2 Current demand

Current demand calculates the demand based on a thermal demand meter.

Current demand =

(Average of current – last current demand value) × 90%(fixed) + Last current demand value

In case of that a stable current flows for interval time, 90% of current value is displayed.



5.6.3 Max. demand value

Maximum value of measured demand value (active, reactive, apparent, active (export), reactive (export), current)) are considered to the max. demand value. And it records the max. demand value.

5.6.4 Demand alarm output

- It output with pulse output terminal. (open collector)
- It output only when [alarm] is set for unit for pulse output.
- It doesn't output alarm if power demand alarm threshold is set to '0.000'kW.

5.6.5 Working at power failure and at recovery

<At power failure>

- It stops the demand measurement.
- It records monthly max. demand log, max. demand value in the internal memory.

<At recovery>

- It stops the demand measuring until next span starts. When the next span starts, it will start demand measuring.

5.6.6 Totaling the demand

- It totals the demand values that are measured with each channel and displays.
You can read out with DT register.

5.7 Logging Data Writing Function (only KW2M-X)

This is the function that it writes the measurement data to the internal memory.
You can read out the log files by PC from Eco-POWER METER via FTP communication.

There are 4 kinds of file to write.

- 5-min. instantaneous value (Save cycle: 5 minutes fixed)
- 15-min. instantaneous value (Save cycle: 15 minutes fixed)
- Demand (Save cycle: 1 minute fixed)
- Power quality (When event is occurred.)

5.7.1 File creating

<Timing of creating files>

It writes the measurement data to temporary file at the below designated time.

5-min. instantaneous value	Every hour xx:05
15-min. instantaneous value	Every hour xx:15
Demand	Every hour xx:25
Power quality	Every hour xx:35

* When the capacity of the internal memory (temporary) reaches upper limit except the times, it will write too.

<Timing of confirming files>

It renames the temporary files at the below designated time.

5-min. instantaneous value	Every day 00:05
15-min. instantaneous value	Every month 1 st 00:15
Demand	Every day 00:25
Power quality	When logging 1000-record

<Timing of deleting saved files>

It deletes log files after the below designated time has passed.

5-min. instantaneous value	60 days after creating file
15-min. instantaneous value	24 months after creating file
Demand	60 days after creating file
Power quality	It reaches 100 files

<Indication during writing>

Writing indication is appeared during writing.

Do not turn off the main unit during the indication is appeared, it may break the log files.

Writing indication

M - 1		1	1	2	3	.	4	5	k W
P		2	1	2	3	.	4	5	k W
		3	1	2	3	.	4	5	k W
		Σ	1	2	3	.	4	5	k W

5.7.2 Format for written files

Log files written in the internal memory is saved with the below format as csv file.

<5-min. instantaneous value >

4

	A	B	1	D	E	F	G	H	I	J
1	Date	Time	1	2	3	4	5	6	7	8
2			KW2M-X	KW2M-X	KW2M-X	KW2M-X	KW2M-X	KW2M-X	KW2M-X	KW2M-X
3			COM1[Unit	COM1[Unit	COM1[Unit	COM1[Unit	COM1[Unit	COM1[Unit	COM1[Unit	COM1[Unit
4			DT278	DT280	DT282	DT284	DT286	DT262	DT264	DT266
5			MOMENT	MOMENT	MOMENT	MOMENT	MOMENT	MOMENT	MOMENT	MOMENT
6			US32->FL	US32->FL	US32->FL	US32->FL	US32->FL	US32->FL	US32->FL	US32->FL
7			A	A	A	A	A	V	V	V
8	2015/11/27	14:15:00								
9	2015/11/27	14:20:00								
10	2015/11/27	16:20:00								
11	2015/11/27	16:25:00								
12	2015/11/27	16:30:00								
13	2015/11/27	16:35:00								
14	2015/11/27	16:40:00								
15	2015/11/27	16:45:00								
16	2015/11/27	16:50:00								
17	2015/11/27	16:55:00								
18	2015/11/27	17:00:00								

2

3

1 Device information	(row 1)	Logging data number
	(row 2)	KW2M-X : Model name
	(row 3)	COM1[Unit No.1] : Device number (based on the unit setting)
	(row 4)	DT278 : Target address (main/expansion unit)
	(row 5)	MOMENT : Shows 'instantaneous value'
	(row 6)	US32 -> FLT : Unsigned integer 32 bit S32 -> FLT : Signed integer 32 bit US16 -> FLT : Unsigned integer 16 bit S16 -> FLT : Signed integer 16 bit
	(row 7)	Unit (based on the target address)
2 Logging trigger	Timing to log data: 5 minutes fixed (00,05,10,15,20,25,30,35,40,45,50,55 of each hour)	
3 Record number	Record number for 1 file 288 records fixed Timing of creating file 5-minute every hour Timing of confirming file 00:05 every day	
4 Logging data	Record '—' for items not measured <Main unit, Expansion unit (Power measurement)> Logging data of the same timing: 14 data (fixed) From column C to P R-current, S-current, T-current, N-current, Average of current R-voltage (L1-N), S-voltage (L2-N), T-voltage (L3-N), Average of phase-voltage, RS-voltage (L1-L2), ST-voltage (L2-L3), TR-voltage (L3-L1) Average of line-voltage Pulse count value <Expansion unit (Multi Analog Input)> Logging data of the same timing: 5 data (fixed) From column C to G Digital conversion value1, Digital conversion value2, Digital conversion value3 Temperature1, Temperature2 <Expansion unit (Digital I/O)> Logging data of the same timing: 2 data (fixed) From column C to D Pulse count 1, Pulse count 2	

<15-min. instantaneous value >

	A	B	C	D	E	F	G	H	I	J
1	Date	Time	1	2	3	4	5	6	7	8
2			KW2M-X	KW2M-X	KW2M-X	KW2M-X	KW2M-X	KW2M-X	KW2M-X	KW2M-X
3			COM1[Unit	COM1[Unit	COM1[Unit	COM1[Unit	COM1[Unit	COM1[Unit	COM1[Unit	COM1[Unit
4			DT100	DT104	DT108	DT112	DT116	DT120	DT124	DT128
5			MOMENT	MOMENT	MOMENT	MOMENT	MOMENT	MOMENT	MOMENT	MOMENT
6			US64->FL	US64->FL	US64->FL	US64->FL	US64->FL	US64->FL	US64->FL	US64->FL
7			kWh	kWh	kWh	kWh	kvarh	kvarh	kvarh	kvarh
8	2015/11/27	14:15:00								
9	2015/11/27	16:30:00								
10	2015/11/27	16:45:00								
11	2015/11/27	17:00:00								
12	2015/11/28	2:15:00								
13	2015/11/28	2:30:00								
14	2015/11/28	2:45:00								
15	2015/11/28	3:00:00								
16	2015/11/28	3:15:00								
17	2015/11/28	3:30:00								
18	2015/11/28	3:45:00								

1 Device information	(row 1)	Logging data number
	(row 2)	KW2M-X : Model name
	(row 3)	COM1[Unit No.1] : Device number (based on the unit setting)
	(row 4)	DT100 : Target address (main/expansion unit)
	(row 5)	MOMENT : Shows 'instantaneous value'
	(row 6)	US64 -> FLT : Unsigned integer 64 bit S64 -> FLT : Signed integer 64 bit US32 -> FLT : Unsigned integer 32 bit S32 -> FLT : Signed integer 32 bit US16 -> FLT : Unsigned integer 16 bit S16 -> FLT : Signed integer 16 bit
	(row 7)	Unit (based on the target address)
2 Logging trigger	Timing to log data: 15 minutes fixed (00,15,30,45 of each hour)	
3 Record number	Record number for 1 file	2976 records fixed
	Timing of creating file	15-minute every hour
	Timing of confirming file	1 st 00:15 every month

4 Logging data	Record '—' for items not measured <Main unit, Expansion unit (Power measurement)> Logging data of the same timing: 67 data (fixed) From column C to BT Integral active power(1), (2), (3), Total integral active power, Integral reactive power(1), (2), (3), Total integral reactive power, Integral apparent power(1), (2), (3), Total integral apparent power, Export active power(1), (2), (3), Total export active power, Export reactive power(1), (2), (3), Total export reactive power, Instantaneous active power(1), (2), (3), Total instantaneous active power, Instantaneous reactive power(1), (2), (3), Total instantaneous reactive power, Instantaneous apparent power(1), (2), (3), Total instantaneous apparent power, R-current, S-current, T-current, N-current, Average of current, R-voltage (L1-N), S-voltage (L2-N), T-voltage (L3-N), Average of phase-voltage, RS-voltage (L1-L2), ST-voltage (L2-L3), TR-voltage (L3-L1), Average of line-voltage, Power factor(1), (2), (3), Average of power factor, Frequency(1), (2), (3), Average of frequency, Current THD(1), (2), (3), Average of current THD, Phase-voltage THD(1), (2), (3), Average of phase-voltage THD, Line-voltage THD(1), (2), (3), Average of line-voltage THD, ON-time, OFF-time, Stand-by time, Maintenance-time, Pulse count value <Expansion unit (Multi analog input)> Logging data of the same timing: 5 data (fixed) From column C to G Digital conversion value1, Digital conversion value2, Digital conversion value3 Temperature1, Temperature2 <Expansion unit (Digital I/O)> Logging data of the same timing: 2 data (fixed) From column C to D Pulse count 1, Pulse count 2
----------------	---

<Custom log>

	A	B	C	D	E	F	G	H	I	J
1	Date	Time	1	2	3	4	5	6	7	8
2			KW2M-X	KW2M-X	KW2M-X	KW2M-X	KW2M-X	KW2M-X	KW2M-X	KW2M-X
3			COM1 [Unit	COM1 [Unit	COM1 [Unit	COM1 [Unit	COM1 [Unit	COM1 [Unit	COM1 [Unit	COM1 [Unit
4			DT100	DT120	DT140	DT148	DT168	DT208	DT228	DT244
5			MOMENT	MOMENT	MOMENT	MOMENT	MOMENT	MOMENT	MOMENT	MOMENT
6			US64->FLT	US64->FLT	US64->FLT	US64->FLT	US64->FLT	US64->FLT	S64->FLT	S64->FLT
7			kWh	kvarh	kVAh	kWh	kvarh	kW	kvar	kVA
8	2017/5/11	0:30:00								
9	2017/5/11	0:45:00								
10	2017/5/11	1:00:00								
11	2017/5/11	1:15:00								
12	2017/5/11	1:30:00								
13	2017/5/11	1:45:00								
14	2017/5/11	2:00:00								
15	2017/5/11	2:15:00								
16	2017/5/11	2:30:00								
17	2017/5/11	2:45:00								
18	2017/5/11	3:00:00								
19	2017/5/11	3:15:00								
20	2017/5/11	3:30:00								

1 Device information	(row 1)	Logging data number
	(row 2)	KW2M-X : Model name
	(row 3)	COM1[Unit No.1] : Device number (based on the unit setting)
	(row 4)	DT100 : Target address (main/expansion unit)
	(row 5)	MOMENT : Shows 'instantaneous value'
	(row 6)	US64 -> FLT : Unsigned integer 64 bit
		S64 -> FLT : Signed integer 64 bit
		US32 -> FLT : Unsigned integer 32 bit
		S32 -> FLT : Signed integer 32 bit
US16 -> FLT : Unsigned integer 16 bit		
(row 7)	S16 -> FLT : Signed integer 16 bit	
	Unit (based on the target address)	
2 Logging trigger	Timing to log data: 15 minutes fixed (00,15,30,45 of each hour)	
3 Record number	Record number for 1 file	2976 records fixed
	Timing of creating file	15-minute every hour
	Timing of confirming file	1 st 00:15 every month

4 Logging data	Record '—' for items not measured Select up to 8 items Integral active power(1), (2), (3), Total integral active power, Integral reactive power(1), (2), (3), Total integral reactive power, Integral apparent power(1), (2), (3), Total integral apparent power, Export active power(1), (2), (3), Total export active power, Export reactive power(1), (2), (3), Total export reactive power, Instantaneous active power(1), (2), (3), Total instantaneous active power, Instantaneous reactive power(1), (2), (3), Total instantaneous reactive power, Instantaneous apparent power(1), (2), (3), Total instantaneous apparent power, R-current, S-current, T-current, N-current, Average of current, R-voltage (L1-N), S-voltage (L2-N), T-voltage (L3-N), Average of phase-voltage, RS-voltage (L1-L2), ST-voltage (L2-L3), TR-voltage (L3-L1), Average of line-voltage, Power factor(1), (2), (3), Average of power factor, Frequency(1), (2), (3), Average of frequency, Current THD(1), (2), (3), Average of current THD, Phase-voltage THD(1), (2), (3), Average of phase-voltage THD, Line-voltage THD(1), (2), (3), Average of line-voltage THD, ON-time, OFF-time, Stand-by time, Maintenance-time, Pulse count value Digital conversion value1, Digital conversion value2, Digital conversion value3, Temperature1, Temperature2 Pulse count 1, Pulse count 2, Leakage current 1, Leakage current 2, Leakage current 3
----------------	--

<Demand> (Main unit, Expansion unit (Power measurement))

	A	B	C	D	E	F	G	H	I	J
1	Date	Time	1	2	3	4	5	6	7	8
2			KW2M-X	KW2M-X	KW2M-X	KW2M-X	KW2M-X	KW2M-X	KW2M-X	KW2M-X
3			COM1[Unit	COM1[Unit	COM1[Unit	COM1[Unit	COM1[Unit	COM1[Unit	COM1[Unit	COM1[Unit
4			DT305	DT307	DT309	DT311	DT313	DT325	DT315	DT317
5			DEMAND	DEMAND	DEMAND	DEMAND	DEMAND	DEMAND	DEMAND	DEMAND
6			US32->FL	US32->FL	US32->FL	US32->FL	US32->FL	US64->FL	US32->FL	US32->FL
7			kW	kvar	kVA	kW	kvar	kWh	A	A
8	2015/11/27	14:11:00								
9	2015/11/27	14:12:00								
10	2015/11/27	14:13:00								
11	2015/11/27	14:14:00								
12	2015/11/27	14:15:00								
13	2015/11/27	14:16:00								
14	2015/11/27	14:17:00								
15	2015/11/27	14:18:00								
16	2015/11/27	14:19:00								
17	2015/11/27	14:20:00								
18	2015/11/27	14:21:00								

1 Device information	(row 1)	Logging data number
	(row 2)	KW2M-X : Model name
	(row 3)	COM1[Unit No.1] : Device number (based on the unit setting)
	(row 4)	DT305 : Target address (main/expansion unit)
	(row 5)	DEMAND : Shows 'demand value'
	(row 6)	US64 -> FLT : Unsigned integer 64 bit S64 -> FLT : Signed integer 64 bit US32 -> FLT : Unsigned integer 32 bit S32 -> FLT : Signed integer 32 bit US16 -> FLT : Unsigned integer 16 bit S16 -> FLT : Signed integer 16 bit
	(row 7)	Unit (based on the target address)
2 Logging trigger	Timing to log data: 1 minutes fixed (00 of each minute)	
3 Record number	Record number for 1 file	1440 records fixed
	Timing of creating file	25-minute every hour
	Timing of confirming file	00:25 every day
4 Logging data	Record '—' for items not measured	
	Logging data of the same timing: 9 data (fixed)	
	From column C to K Present demand (active power, reactive power, apparent power, active power(export), reactive power(export)) Pulse conversion value for integral power, Present current demand (1), (2), (3)	

<Power quality> (Main unit, Expansion unit (Power measurement))

4

	A	B	C	D	E	F
1	Date	Time	Status	Type	Phase	Data
2	2015/12/4	11:01:01	Start	Under current	Phase 3	-
3	2015/12/4	11:04:00	End	Under current	Phase 3	129ms
4	2015/12/4	11:04:00	Start	Over current	Phase 3	-
5	2015/12/4	11:11:02	End	Over current	Phase 3	412ms
6	2015/12/4	11:11:02	Start	Under Voltage	Phase 3	-
7	2015/12/4	11:11:03	End	Under Voltage	Phase 3	827ms

Diagram annotations: 1 points to the first column (row numbers). 2 points to the first row (headers). 3 points to the last column (Data). 4 points to the header of column C (Status).

1 Device information	(row1) Measured data item (fixed)
2 Logging trigger	Timing to log data: at the time when an event is occurred
3 Record number	Record number for 1 file 1000 records fixed Timing of creating file 35-minute every hour Timing of confirming file When logging 1000-record
4 Logging data	Record '—' for items not measured (row C) Status of event (row D) Event type •Over Voltage •Under Voltage •Over Current •Under Current •Power interruption (row E) Phase that the event has occurred (row F) Time that the event has occurred

[Folder]

[Folder name]

[File name]

Condition of saved file

hour/minute/second (00:15:00)

year/month/day (January 1st, 2016)

<Demand>

[Folder]

[Folder name]



Circuit number (1: CH1, 2: CH2)
 Unit number (0: main unit, 1 to 3: expansion)

[File name]


Diagram illustrating the structure of a saved file:

- Condition of saved file
- hour/minute/second (00:15:00)
- year/month/day (January 1st, 2016)
- circuit number (1: CH1, 2: CH2)
- unit number (0: main unit, 1 to 3: expansion)

95

<power quality>


[Folder]



[Folder name]


LOG -> fixed

quality_u0_1



[File name]

quality_u0_1(160101_001500_SET).csv



year/month/day, hour/minute/second in file name is the date of the beginning record.

Condition of saved file	Recorded letter
'File write trigger' occurs.	TRG
Record number reaches upper limit	SET


Chapter 6 Display of Each Value

6.1 Working of Monitor Display

【Shift the display mode】


Press <SHIFT/Λ> during pressing <MODE>, it shifts measuring mode, logging mode and demand mode.

Press <MODE> to shift the setting mode.



*1 only main unit and expansion unit (power measurement), set CH2 to power measurement

Press <SET> during pressing <MODE>, it shifts display channel and unit.



*2 only expansion unit (power measurement)


*3 only when it set to available the total demand function

6.2 Working of Monitor Display (Main unit, Expansion unit (Power measurement))


6.2.1 Single-phase two-wire system

Arrow mark shows to press each key.

➡ <ITEM/>> ⇨ <SHIFT/▽> ➡ <SET>



From the previous page




*1 only KW2M-X


6.2.2 Single-phase three-wire system

Arrow mark shows to press each key.

➡ <ITEM/>> ⇨ <SHIFT/▽> ⇨ <SET>



From the previous page





*1 only KW2M-X

6.2.3 Three-phase three-wire system

Arrow mark shows to press each key.

➡ <ITEM/>> ⇨ <SHIFT/▽> ⇨ <SET>







*1 only KW2M-X

6.2.4 Three-phase four-wire system

Arrow mark shows to press each key.

➡ <ITEM/>> ⇨ <SHIFT/▽> ➡ <SET>






*1 only KW2M-X


6.2.5 Instantaneous power

- The present instantaneous power of all phases or all circuits is displayed.
- Press <SHIFT/Λ> to change active, reactive and apparent.



• Eco-POWER METER displays the power as below.

Display	1P2W	1P3W	3P4W
1	1 st circuit	R-phase	R-phase
2	2 nd circuit	---	S-phase
3	3 rd circuit	T-phase	T-phase
Σ	Total (1+2+3)	Total (R+T)	Total (R+S+T)



6.2.6 Total integral power

- The present total integral power is displayed.
- Press <SHIFT/Λ> to change active, reactive and apparent.
- Press <SET> to change the display with each time-zone. *1

After changing, press <SET> to change displayed time-zone.

time-zone1(T1) -> time-zone2(T2) -> time-zone3(T3) -> time-zone4(T4) -> All time-zone

*Time-zone without setting for any time program is not displayed.

All time-zone

Active

M - 1	1	k w h
P	2	k w h
	3	k w h
	Σ	k w h

Reactive

M - 1	1	k v a r h
Q	2	k v a r h
	3	k v a r h
	Σ	M v a r h

Apparent

M - 1	1	k V A h
S	2	k V A h
	3	k V A h
	Σ	k V A h

Time-zone1

M - 1	1	k w h
P	2	k w h
T 1	3	k w h
	Σ	k w h


M - 1	1	k v a r h
Q	2	k v a r h
T 1	3	k v a r h
	Σ	M v a r h

M - 1	1	k V A h
S	2	k V A h
T 1	3	k V A h
	Σ	k V A h

time-zone2, time-zone3, time-zone4 and all time-zone are changed in turn.

*It doesn't light [Σ] with 3P3W system.

- Total integral power is measured and displayed from 0.000 (kWh/kvarh/kVAh) to 9999.9 (PWh/Pvar/PVA).
- The decimal point is changed automatically.




(After reach the full scale, 9999.9PWh, the value reverts to 0.000 but continues to measure.)

*1 only KW2M-X

6.2.7 Total integral export power

- The present total export power is displayed.
- Press <SHIFT/Λ> to change active, reactive and apparent.
- Press <SET> to change the display with each time-zone. *1
After changing, press <SET> to change displayed time-zone.
time-zone1(T1) -> time-zone2(T2) -> time-zone3(T3) -> time-zone4(T4) -> All time-zone
- *Time-zone without setting for any time program is not displayed.


All time-zone



time-zone2, time-zone3, time-zone4 and all time-zone are changed in turn.

*It doesn't light [Σ] with 3P3W system.

- Total integral power is measured and displayed from 0.000 (kWh/kvarh/kVAh) to 9999.9 (PWh/Pvar/PVA).
- The decimal point is changed automatically.




(After reach the full scale, 9999.9PWh, the value reverts to 0.000 but continues to measure.)

*1 only KW2M-X

6.2.8 Current

- The present current value is displayed. (N-phase current is displayed for 3P4W.)




- It measures from 0.1% of CT secondary current.
- When input current exceeds 200% or the display range, it displays '- - - -'. Check and confirm the measurement environment.
- Current measuring points Eco-POWER METER measures the current as below.

Display	1P2W	1P3W	3P3W 3P4W
1	1 st circuit R-current	R-current	R-current
2	2 nd circuit R-current	N-current	S-current
3	3 rd circuit R-current	T-current	T-current
A	Average	Average of R and T	Average
N	—	—	N-current *only 3P4W

6.2.9 Voltage

- The present voltage is displayed.
- Press <SHIFT/Λ> to change phase voltage and line voltage.
(Line voltage is not displayed for 1P2W system. Phase voltage is not displayed for 3P3W system.)



- When input voltage is under 3V (when VT ratio is 1.), it displays '0.00' and doesn't measure.
- When input voltage exceeds 828V or the display range, it displays '- - - -'. Check and confirm the measurement environment.
- Voltage measuring points Eco-POWER METER measures the voltage as below.

Display	1P2W	1P3W	3P3W	3P4W
1	R-voltage (L1-N) or 1 st circuit R-voltage	R-voltage (L1-N)	No display	R-voltage (L1-N)
2	None or 2 nd circuit R-voltage	None		S-voltage (L2-N)
3	None or 3 rd circuit R-voltage	T-voltage (L3-N)		T-voltage (L3-N)
A	Average	Average of R and T		Average
1 2	No display	R-voltage (L1-N)	RS-voltage (L1-L2)	RS-voltage (L1-L2)
2 3		T-voltage (L3-N)	ST-voltage (L2-L3)	ST-voltage (L2-L3)
3 1		TR-voltage (L3-L1)	TR-voltage (L3-L1)	TR-voltage (L3-L1)
A		Average of R and T	Average	Average

6.2.10 Power factor

- The present power factor of the load is displayed.

<1P2W/1P3W/3P4W>

M - 1	1
P F	2
	3
	A

<3P3W>

M - 1	
P F	
	1 2 3

*Power factor operation is a method assuming balanced load. The error might be big when it measures unbalanced load.

6.2.11 Frequency

- The present frequency is displayed.

<1P2W/1P3W/3P4W>

M - 1	1	H Z
F	2	H Z
	3	H Z
	A	H Z

<3P3W>

M - 1	
F	
	H Z

6.2.12 Current unbalance

- The present current unbalance is displayed. (No display for 1P2W.)

M - 1	
I	
	1 0 0 . 0 0 %

6.2.13 Voltage unbalancing

- The present voltage unbalancing is displayed. (No display for 1P2W.)

M - 1	
U	
	1 0 0 . 0 0 %

6.2.14 Current THD

- The present THD for current is displayed.

M - 1	1	%
T H D i	2	%
	3	%
	A	%

6.2.15 Voltage THD

- The present THD for voltage displayed.

M - 1	1	%
T H D u	2	%
	3	%
	A	%

M - 1	1 2	%
T H D u	2 3	%
	3 1	%
	A	%

6.2.16 Current n-order harmonics

- The present current n-order harmonics is displayed.
- Press <SHIFT/Λ> to change display.
2nd order, 3rd order, 4th order up to 31st order

M - 1	1	%
H - I 2	2	%
	3	%
	A	%

6.2.17 Voltage n-order harmonics

- The present voltage n-order harmonics is displayed.
- Press <SHIFT/Λ> to change display.
2nd order, 3rd order, 4th order up to 31st order

M - 1	1	%
H - U 2	2	%
	3	%
	A	%

6.2.18 Pulse input value

- The present pulse input value is displayed.
- Pulse input status (ON or OFF) is confirmed via communication. (MEWTOCOL and MODBUS)

Pulse input

M - 1	
C N T	
	1 2 3 4 5 6 7 8 9 0 1

*Turn on the unit during IN1 is shorted, first 1-pulse is not counted. After that, when pulse is input pulse it count the pulse.

6.2.19 Conversion value for integral active power

- The conversion value for the present integral active power (P) is displayed.
(Only total conversion value is displayed for 3P3W system.)
- Press <SHIFT/Λ> to change total, phase 1 (1st circuit), phase 2 (2nd circuit) and phase 3 (3rd circuit).

<1P2W/1P3W/3P4W>

Total

M - 1	1
C H G	2
	3
	Σ 1 2 3 4 5 6 7 8 9 0 1

<3P3W>

Total

M - 1	1
C H G	2
	3
	Σ 1 2 3 4 5 6 7 8 9 0 1

*The conversion value exceeds '99999999',
[— — — — —] is displayed.
Check and confirm the measurement environment.

6.2.20 Conversion value for integral export power

- The conversion value for the present integral export active power (-P) is displayed.
(Only total conversion value is displayed for 3P3W.)
- Press <SHIFT/Λ> to change total, phase 1 (1st circuit), phase 2 (2nd circuit) and phase 3 (3rd circuit).


<1P2W/1P3W/3P4W>

Total

M - 1	1
C H G -	2
	3
	Σ


6.2.21 Hour meter

- ON-time, Standby-time, OFF-time and Maintenance-time of setting phase are displayed.
- Press <SHIFT/Λ> to change ON-time, Standby-time, OFF-time and Maintenance time.



6.2.22 Clock (only KW2M-X)

- It displays the present time.



6.3 Working of Monitor Display (Expansion unit (Leak measurement))

Leakage current

6.3.1 Leakage current

- The present leakage current is displayed.

1 - 2	1	1	2	3	4	5	.	6	7	8	9	A
L e a k	2	1	2	3	4	5	.	6	7	8	9	A
	3	1	2	3	4	5	.	6	7	8	9	A

- After measured leakage current value exceeds the threshold and it passes the delay time, and the measured value still exceeds the threshold, it will judge it is the leakage current and display alarm.


Press <ITEM/> and '←' is displayed. Point CH to reset alarm with '←' and press <SET>
It will reset the alarm.

1 - 2	!	1	←	1	2	3	4	5	.	6	7	8	9	A
L e a k	!	2	1	2	3	4	5	.	6	7	8	9	A	
	!	3	1	2	3	4	5	.	6	7	8	9	A	

6.4 Working of Monitor Display (Expansion unit (Multi analog input))

Arrow mark shows to press each key.

➡ <ITEM/>



6.4.1 Analog measured value

- It displays the present analog measured value.
- Continuous press <SHIFT/▽> to shift display with raw data.

1 - 1	1	1	2	3	4	5	6	.	7	8	9	
A n a l o g	2	-	1	2	3	4	5	6	.	7	8	9
	3		1	2	3	4	5	6	.	7	8	9

6.4.2 Temperature

- It displays the present temperature calculated by resistance value.
- (Numerical value of shift average of samplings data during 5 sec.)

1 - 1	1	1	2	3	.	4	°	C	
T E M P	2	-	1	2	3	.	4	°	C

6.5 Working of Monitor Display (Expansion unit (Digital I/O))

Pulse input value

6.5.1 Pulse input value

- The present pulse input value is displayed.
- Pulse input status (ON or OFF) is confirmed via communication. (MEWTOCOL and MODBUS)


1 - 1	1	1	2	3	4	5	6	.	7	8	9
C N T	2	1	2	3	4	5	6	.	7	8	9

*Turn on the unit during IN1 is shorted, first 1-pulse is not counted. After that, when pulse is input pulse it count the pulse.

6.6 Working of Logging Mode

Each measured value is displayed as below. It differs according to the selected phase/wire system.
Arrow mark shows to press each key.

 <ITEM/>>
  <SHIFT/Λ>
  <SET>
  <SET>+<ITEM/>>




*1 only KW2M-X


6.6.1 Max. demand value

- Log data of peak demand is displayed.
- Press <SHIFT/Λ> to change displayed time-zone. *1
All time-zone -> time-zone1(T1) -> time-zone2(T2) -> time-zone3(T3) -> time-zone4(T4)
- Press <SET> to change the display with each month.
1-month before -> 2-month before -> 3-month before ->.....(12-month before)
- *Time-zone without setting for any time program is not displayed.
- *When you change the setting of phase/wire system, max. demand value will be reset.

Power demand



Current demand



- Press <ITEM/>> to change items to display.

Item	Display	
	Indicator	unit
Active power Peak demand	P	kW
Reactive power Peak demand	Q	kvar
Apparent power Peak demand	S	kVA
Active power (export) Peak demand	-P	kW
Reactive power (export) Peak demand	-Q	kvar
Current Peak demand	I	A

*1 only KW2M-X

6.7 Working of Demand Mode

Each measured value is displayed as below. It differs according to the selected demand type.


Press <MODE> and <SET> to change CH.

When total demand function is set to available, press <MODE> and <SET>, and it displays total demand at the last window.

6.7.1 Block interval demand (Sliding block, fixed block)

Arrow mark shows to press each key.

 <ITEM/>>
  <SHIFT/Λ>
  <SET>
  <SET>+<ITEM/>



*1 only 'CT' is selected with 'Power input source'

*2 only 'Pulse' is selected with 'Power input source'

Present power demand

- Each demand value is displayed.
- Press <SHIFT/Λ> to change active power, reactive power, apparent power.
- Measuring date and time is displayed on the middle lines. (only KW2M-X)

Active power present demand

M - 1	
P	2 0 1 5 / 0 1 / 0 1
D E M	0 0 : 0 0 : 0 0
P v	1 2 3 . 4 5 k w



Reactive power present demand

M - 2	
Q	2 0 1 5 / 0 1 / 0 1
D E M	0 0 : 0 0 : 0 0
P v	1 2 3 . 4 5 k v a r

Apparent power present demand



M - 1	
S	2 0 1 5 / 0 1 / 0 1
D E M	0 0 : 0 0 : 0 0
P v	1 2 3 . 4 5 k V A

* [-----] is displayed during the following cases.

- Until passing the setting time to start monitoring demand
- Demand value exceeds the display range
- Clock is changed between demand time span
- Until starting next time span at power failure

Present export power demand

- Each demand value is displayed.
- Press <SHIFT/Λ> to change active power (export), reactive power (export).
- Measuring date and time is displayed on the middle lines. (only KW2M-X)

Active power (export)
present demand

M - 1	
- P	2 0 1 5 / 0 1 / 0 1
D E M	0 0 : 0 0 : 0 0
P v	1 2 3 . 4 5 k w

Reactive power (export)
present demand

M - 2	
- Q	2 0 1 5 / 0 1 / 0 1
D E M	0 0 : 0 0 : 0 0
P v	1 2 3 . 4 5 k v a r

* [-----] is displayed during the following cases.

- Until passing 1 minute after starting monitoring demand
- Demand value exceeds the display range

Pulse conversion value for integral power

- Present value of pulse conversion value for integral power.

M - 1	
P L S	
	1 2 3 . 4 5 k w h

Present current demand

- Present value of current demand is displayed.

M - 1	1	1 2 . 3 4 5 A
I	2	1 2 . 3 4 5 A
D E M	3	1 2 . 3 4 5 A
P V		

Total demand

- Total of demand value measured with each CH is displayed.

S U M	
P	
D E M	
P V	1 2 3 . 4 5 k w

Chapter 7 Monitoring Measured Value via Web Browser (Monitor Web) (only KW2M-X)

You can monitor the measured value of Eco-POWER METER via Web browser.

Access to <http://xxx.xxx.xxx.xxx/monitor/index.htm> by web browser.*1*2

It may take time to display according to the communication conditions.

*1 Input setting IP address to 'xxx.xxx.xxx.xxx'

*2 When you select 'use' password for Monitor Web and Customer Web, password is necessary to access it. <Initial user name: user> <Initial password: user>

KW2M Eco-POWER METER Monitor Web

Realtime Monitor Realtime Graph Max Demand

Main Unit Expansion Unit 1 Expansion Unit 2 Expansion Unit 3

CH1 CH2 CH1 CH2 CH1 CH2 CH1 CH2

Main Unit - CH1

	Phase 1	Phase 2	Phase 3	Total / Average	Phase N
Active power	28.296kW	28.296kW	27.570kW	Σ 84.162kW	
Reactive power	10.355kvar	8.226kvar	7.409kvar	Σ 25.990kvar	
Apparent power	30.110kVA	29.747kVA	28.659kVA	Σ 88.516kVA	
Integral active power	10.592kWh	10.032kWh	10.385kWh	Σ 31.011kWh	
Integral reactive power	5.645kvarh	4.401kvarh	4.467kvarh	Σ 14.513kvarh	
Integral apparent power	13.144kVAh	12.162kVAh	12.539kVAh	Σ 37.845kVAh	
Integral export reactive power	0.000kWh	0.000kWh	0.000kWh	Σ 0.000kWh	
Integral export apparent power	0.024kvarh	0.189kvarh	0.042kvarh	Σ 0.255kvarh	
Current	125.753A	124.965A	119.343A	Avg. 123.353A	80.895A
Phase voltage	24.500V	24.082V	24.279V	Avg. 24.287V	
Line voltage	42.073V	41.881V	42.243V	Avg. 42.065V	

Item	Description
1 Real time Monitor	Display measured instantaneous values
2 Real time Graph	Display graph of measured instantaneous values
3 Max Demand	Display max demand

Chapter 8 Creating Web Contents (Customer Web) (only KW2M-X)

You can upload your designed screen (contents) created by Control Web Creator to Eco-POWER METER and you can monitor the information of web server in Eco-POWER METER by browser.

Access to <http://xxx.xxx.xxx.xxx/cu/index.htm> by web browser. *2 *3

It may take time to display according to the communication conditions.

*1 Refer to [FP7 Web Server Function Manual] about [Control Web Creator].

*2 Input setting IP address to 'xxx.xxx.xxx.xxx'

*3 When you select 'use' password for Monitor Web and Customer Web, password is necessary to access it. <Initial user name: user> <Initial password: user>





Image of Control Web Creator


8.1 How to Upload Web Contents

Upload the web contents that are created by Control Web Creator to Eco-POWER METER.

1) Click [Operations] – [Upload] of Control Web Creator.




2) Set IP address, Port number, User ID and Password and click [Upload].
Upload window is appeared.



<Setting values>

Item	Contents
IP address	IP address of Eco-POWER METER (initial:192.168.1.5)
Port number	32769 (fixed)
User ID	1 (fixed)
Password	Password of System Web (initial: admin)


3) After complete the upload of Web contents, the complete window is appeared.




8.2 How to Download Web Contents

Download the web contents that are uploaded to Eco-POWER METER.

1) Click [Operations] – [Download] of Control Web Creator.




- 2) Set IP address, Port number, User ID and Password and click [Download].
Download window is appeared.



<Setting values>

Item	Contents
IP address	IP address of Eco-POWER METER (initial:192.168.1.5)
Port number	32769 (fixed)
User ID	1 (fixed)
Password	Password of System Web (initial: admin)

- 3) After complete the download of Web contents, the complete window is appeared.




Chapter 9 How to Update the Firmware


You can update the firmware by System Web.

Expansion units that connect to the main unit are updated at the same time.

- 1) Access to <http://xxx.xxx.xxx.xxx/setup/index.htm> by web browser.
- 2) Click [System setup] at System Web.



- 3) Click [Browse] and it opens the window to select firmware.
Select file to update 'kw2maverxxx_verup.kw2m' / 'kw2mxverxxx_verup.kw2m' and click [Open].
*You can download from our website the latest firmware.




- 4) When selected file name is displayed, click [Update].



5) When it starts updating, the indicator is appeared on web browser and Eco-POWER METER.




Web browser



Eco-POWER METER

6) When it completes updating the firmware, the complete window will be appeared and Eco-POWER METER has restarted automatically.



When it fails updating the firmware, error window will be appeared.
Check and confirm the communication conditions and update again.



7) Click [OK] to exit System Web.
You can use Eco-POWER METER as it is.


Chapter 10 How to Update the Web Contents

You can update System Web contents with using KW Version Upgrade Tool.
Refer to the manual of KW Version Upgrade Tool regard to use it.

1) Start KW Version Upgrade Tool.exe


C:\Program Files\Panasonic-EW SUNX Control\KW Version Upgrade Tool

When the warning about user account control is displayed, click [Yes].




*Use KW Version Upgrade Tool version 1.60 or more.


2) Select 'KW2M' with Type.




3) Click [Communication Settings] with [Setting].




4) Register destination IP address.




5) Click [Refer] to select contents to update.




6) Click [Update].




- 7) Login window will appear and input 'User name' and 'Password' to log in Web contents.
After that, click [Login].




- 8) It starts uploading and the indicator will appear.



- 9) When it completes updating the web contents, the complete window will appear and restart Eco-POWER METER automatically.



- 10) After complete the update, the new version is displayed at the display.



Chapter 11 Specifications

11.1 General Specification (Main unit, Expansion unit)

Supply voltage range		100 to 240V AC
Rated frequency		50/60Hz
Nominal power consumption		Approx. 15VA (240V AC at 25°C)
Inrush current		30A or less (240V AC/DC at 25°C)
Allowable momentary power-off time		10ms
Ambient temperature		Operation -10 to + 50°C
		Storage -25 to + 70°C
Ambient humidity		30 to 85%RH (at 20°C) non-condensing
Breakdown voltage (initial)		Between the isolated circuits: 2,000V/1min
		a) enclosure ⇔ all terminals
		b) primary insulated circuits ⇔ secondary insulated circuits (Double insulation)
		• power supply terminals ⇔ other terminals • voltage input terminals ⇔ other terminals
Insulation resistance (initial)		Between the isolated circuits: 100 MΩ or more
Vibration resistance		10 to 150Hz (7.5 minutes/cycle) single amplitude:0.075mm (1h on 3 axes)
		10 to 55Hz (1 minute/cycle) single amplitude:0.375mm (1h on 3 axes)
Shock resistance		Min. 294m/s ² (5 times on 3 axes)
Noise immunity		1500V[p-p] Pulse width 50ns, 1μs (noise simulator)
Serge immunity		IEC61000-4-5 1kV
Display method		LCD with backlight
Display updated cycle		500, 1000, 2000, 3000 ms (set with setting mode)
Power failure memory method (when power is off)		Internal memory
Sea level altitude		Under 2,000m
Overvoltage category		III
Pollution degree		2
Dimensions H/W/D		Main unit 85 x 140 x 65 mm
		Expansion unit 85 x 70 x 65 mm
Weight		Main unit Approx. 450g
		Expansion unit (Power measurement) Approx. 200g
		Expansion unit (Multi analog input, Digital I/O) Approx. 140g
Calendar timer *1	Range	January 1, 2015 00:00:00 to December 31, 2099 23:59:59 (leap year supported)
	Time accuracy	Monthly accuracy max. 15 sec. (at 25°C)
	Back up period	About 1 month (by secondary battery *When power off after 48-hour or more of power on time, at 23°C)

*1 only KW2M-X

11.2 Measurement Specifications

●Power measurement (Main unit and Expansion unit (Power measurement))

Measured circuit number		Main unit		2-circuit of 1-system (6-circuit of 1-system for 1P2W)	
		Expansion unit		2-circuit of 1-system (6-circuit of 1-system for 1P2W)	
Max. measured circuit number		8-circuit of 1-system (24-circuit of 1-system for 1P2W) (3 Expansion units are connected to main unit.)			
Measured data		AC sine			
Phase/wire system		Single-phase two-wire (1P2W) (max.3-circuit) Single-phase three-wire (1P3W) Three-phase three-wire (3P3W) Three-phase four-wire (3P4W) (common)			
Applicable power system		100V system, 200V system, 400V system			
Measured frequency		50/60Hz			
Sampling rate		Sampling		1.024MHz (approx.1.0μs)	
		Data update		100ms 22.5s for Harmonics (2 nd to 31 st except THD)	
Voltage	Direct input voltage	1P2W	L-L	0-690V AC *0-300V AC for UL standard	
		1P3W	L-L	0-690V AC *0-300V AC for UL standard	
			L-N	0-350V AC *0-152V AC for UL standard	
		3P3W	L-L	0-690V AC *0-300V AC for UL standard	
		3P4W	L-L	0-690V AC *0-300V AC for UL standard	
			L-N	0-398V AC *0-173V AC for UL standard	
	Impedance	2 MΩ or more (L-N; V1/V2/V3/Vn)			
	Resolution	0.01V			
	Power consumption	Approx. 0.2VA (L-N; V1/V2/V3 - Vn)			
	Accuracy *1	±0.2% *±0.5% for 2-phase of 1P3W, 3-1 voltage of 3P3W and line voltage of 3P4W.			
Input voltage with VT	Primary voltage *3 100 to 500000V Secondary voltage *3 100 to 690V				
Current	Input current (with CT)	Primary current	65,535A or less		
		Secondary current	1A or 5A (set with setting mode)		
	Max. current	10A (200% of the rating)			
	Overload capacity	1000% of the rating for 3s			
	Resolution	0.001A			
	Power consumption	Approx. 0.2VA (between K and L of CT)			
Accuracy *1	±0.2% *2 *±0.5% for 2(N)-phase of 1P3W and 2(S)-phase of 3P3W.				
Power	Accuracy *1	±0.5%			
		Active power	Class 0.5S (IEC 62053-22)		
		Reactive power	Class 2 (IEC 62053-23)		

*1 Without error of current transformers (CT) and voltage transformers (VT)

*2 When it measures current under 5% of rating, it may not satisfy the accuracy according to setting of CT. (Max.error 0.5%)

*3 When it input direct, set primary voltage and secondary voltage to the same value.

●Leakage current measurement (Expansion unit (Power measurement))

Measured circuit number *1		1-circuit of 1-system (3-circuit of 1-system for 1P2W)	
Max. measured circuit number		3-circuit	
Measured frequency		50/60Hz	
Sampling rate		Sampling	1.024MHz (approx. 1.0μs)
		Data update	100ms
Leakage Current	Input leakage current (with CT)	Primary current	65,535A or less
		Secondary current	1A or 5A (set with setting mode)
	Max. current	5A (100% of the rating)	
	Overload capacity	1000% of the rating for 3s	
	Resolution	0.0001A (0.1mA) *2	
	Power consumption	Approx. 0.2VA (between K and L of CT)	
	Accuracy	±2.5%	
Leakage monitor	Leakage period	0.1 to 20.0s	
	Accuracy	±0.2s	
	Reset method	Key operation, RS485 communication or Ethernet communication	

*1 When it set to leak measurement, it can measure power only 1-circuit, CH1.


*2 It doesn't measure under 0.1% of rating current.

11.3 Output Specifications (Main unit and Expansion unit (Digital I/O))

Number of output point	Main unit	2 points *Insulate between output terminals
	Expansion unit (Digital I/O)	4 points *Insulate between output terminals
Insulation method		MOSFET relay
Output type		1a
Output capacity		100mA, 30V AC/DC
Output mode (OUT1/OUT2)		•Pulse by integral power •Output by alarm or events (set with setting mode)
Pulse by integral power	Pulse width	1 to 100ms (set with setting mode)
	Pulse output unit	0.001kWh/ 0.01kWh/ 0.1kWh/ 1kWh/ 10kWh/ 100kWh
Alarm Event	Type	Stand-by alarm/ Under voltage alarm/ Over voltage alarm/ Power interruption alarm/ Under current alarm/ Over current alarm/ Active power alarm/ Reactive power alarm/ Apparent power alarm/ PF alarm/ Over frequency alarm/ Under frequency alarm/ Voltage harmonics alarm/ Current harmonics alarm/ Voltage THD alarm/ Current THD alarm/ Unbalanced voltage alarm/ Unbalanced current alarm/ Power demand alarm/ Current demand alarm/ counter output/ Leakage alarm/ Digital conversion value upper limit alarm/ Digital conversion value lower limit alarm/ Temperature upper limit alarm/ Temperature lower limit alarm/ Level output (external control) / Time control *1
	Alarm reset	Self-reset (according to the setting) / Manual-reset
Protection element		Varistor
Alarm output	Indicator	Lighting alarm mark and blinking backlight
	Output signal	2 points (can set separately) Normal; OFF Alarm; ON
	Output capacity	100mA, 30V AC/DC

*1 only KW2M-X

<Internal output circuit>




11.4 Input Specifications

●Pulse input (Main unit and Expansion unit (Digital I/O))

Number of input point	Main unit	1 point		
	Expansion unit (Digital I/O)	2 points		
Insulation method		Designated insulation for input (insulate to the other functions)		
Input method		Contact/ non-voltage a contact or open-collector		
Input signal		Non-voltage • Impedance; Max. 1kΩ (when short-circuit current: Max. 10mA) • Residual voltage when shorted; Max. 3V • Impedance when open: Min. 100kΩ		
Input mode		Pulse input Synchronized with input from outer device *1 Measure maintenance time *1		
Max. counting speed		2000Hz (when 2000Hz is set) / 30Hz (when 30Hz is set)		
Min. input signal width		0.25ms (when 2000Hz is set) / 16.7ms(when 30Hz is set) ON:OFF ratio=1:1		
Pre-scale	Decimal point	Under 3-digit		
	Range	0.001 to 100.000 (set with setting mode)		
Output mode (when pulse output is selected)		HOLD		
Protective elements		Zener diode		
Pulse input	Input signal	1,000 to 99,000 pulse/kWh (set with setting mode) (External pulse converter is necessary.)		
	Pulse rate	0.001 to 100.000 kWh/pulse		
	Input condition	2000Hz	Pulse width	0.25ms or more
			Pulse interval	0.5ms or more (OFF time 0.25ms or more)
		30Hz	Pulse width	16.7ms or more
			Pulse interval	33.4ms or more (OFF time 16.7ms or more)
	Operation voltage/current	5VDC 10mA		

*1 only KW2M-X

<Internal input circuit>



●Analog input (Expansion unit (Multi analog input))

Input channel		3-channel
Insulation system		Exclusive insulation for input (Not insulated between channels)
Input range (select with setting mode)	Voltage	0 to 60V
	Current	0 to 20mA / 4 to 20mA (set with setting mode)
Digital conversion value		-999999999 to 999999999 *1
Resolution	Voltage	24bit
	Current	
Total accuracy		Within $\pm 0.1\%$ F.S. (at 25°C) Within $\pm 0.3\%$ F.S. (-10 to +50°C)
Conversion rate (Data update)		100ms
Input impedance	Voltage	265k Ω
	Current	80 Ω
Absolute maximum rating	Voltage	-0.3 to +65V
	Current	-2 to +28mA*2
Input protection		Diode

*1 Digital conversion value differs according to the setting scaling value.

When analog input value exceeds the upper or lower limit, it keeps the limit value for digital conversion value.


*2 When it detects input of 28 mA or more, the protection circuit works and it switches to voltage measurement.

●RTD input (Expansion unit (Multi analog input))

Input channel		2-channel
Insulation system		Exclusive insulation for input (Not insulated between channels)
Input range	Pt 100	-200.0~+200.0°C
	Pt 1000	-200.0~+200.0°C
Resolution (24bit)		0.1°C
Total accuracy	CH1	Within $\pm 0.3\%$ F.S. (at 25°C) Within $\pm 0.5\%$ F.S.(at-10 to +50°C)
	CH2	Within $\pm 0.5\%$ F.S. (at 25°C) Within $\pm 1.0\%$ F.S.(at+10 to +40°C) Within $\pm 1.5\%$ F.S. (at-10 to +50°C)
Conversion rate (Data update)*1		500ms
Input protection		Diode

*1 It displays the numerical value of shift average of sampling data during 5 sec.

<Internal input circuit>



11.5 Demand Monitor and Control Specifications (common to 9, 10)

Demand type	IEC61557-12 demand 1. Sliding block interval 2. Fixed block interval 3. Current demand
Power input type	Current transformer input Pulse input *1 (set with setting mode)
Demand span	1 to 60 min. (set with setting mode)
Measurement item	Present demand
Data update cycle	1 min.
Display	Present demand (active/ reactive/ apparent/ active(export)/ reactive(export)/ current)
Saved data	Max.demand, Monthly max. demand (Latest 13 months)*2

*1 Only CH1 of main unit is available.

Only current transformer input is available for CH2 of Main unit and Expansion unit (power measurement).

*2 only KW2M-X

11.6 Communication Specifications

<RS485>

Interface		Conforming to RS485
Communication method		Half-duplex
Synchronous system		Synchronous communication method
Isolation status		Isolated with the internal circuits
Protocol		MEWTOCOL, MODBUS(RTU) (select with setting mode)
Number of connected unit		99 (max.) *1
Transmission distance		1200m *2
Transmission speed		115200,57600,38400,19200,9600,4800,2400bps (select with setting mode)
Transmission format	Data length	8bit (fixed)
	Parity	Not available / odd number / even number (select with setting mode)
	Stop bit	1bit, 2bit (select with setting mode)

*1 For RS485 converter on the computer side, we recommend SI-35 and SI-35USB (from LINE EYE Co.,Ltd.). When using SI-35, SI-35USB or PLC from our company (which can be connected up to 99 units), up to 99 can be connected. In case using this system with the other devices, up to 31 can be connected.

*2 Please check with the actual devices when some commercial devices with RS485 interface are connected. The number of connected devices, transmission distance, and transmission speed may be different according to using transmission line.

< Ethernet >

Ethernet		
Port number		2 port
Interface		IEEE802.3u,100BASE-T/10BASE-TX
Connector shape		RJ45
Transmission	Transmission speed	100Mbps / 10Mbps
	Transmission method	Base band
	Max. segment length	100m
Transmission cable		UTP (Category 5)
Protocol (DNS, DHCP)		TCP/IP, UDP / IP
Web server		Setting, Monitoring measured values*3, Web customization *2*3
Functions		Auto-negotiation *1 MDI / MDI-X Auto-crossover
Dedicated communication		MEWTOCOL, MODBUS(TCP) (2 session for each)

*Ethernet is the trademark of Xerox of USA.

*This product has the software developed by OpenSSL Project in order to use OpenSSL Toolkit.
(<http://www.openssl.org/>)

*1 It changes the transmission speed automatically with auto-negotiation function.

*2 Control Web Creator is necessary to customize the web.

*3 only KW2M-X

11.7 Web Server Specifications (common to Main unit and Expansion unit)

Simultaneous access number	6 sessions
Web browser *1	Windows Google Chrome Mozilla Firefox iOS *2 Safari Google Chrome Android *2 Google Chrome

* Windows is the trademark of Microsoft Corporation in USA and other companies.

Google Chrome and Android are the trademarks of Google Inc.

Firefox is the trademark of Mozilla Foundation in USA and the other companies.

Safari and OS X are the trademark or the registered trademark of Apple Inc. of USA.

iOS is the trademark or the registered trademark of Cisco in USA and the other companies.

*1 Use OS and browser with the latest version.

*2 System Web is not supported.

11.8 Main Unit Memory Specifications (only KW2M-X)

Logging Function

5-min. instantaneous value	Save cycle	5 minutes
	Saved data	R-current, S-current, T-current, N-current, Average of current R-voltage (L1-N), S-voltage (L2-N), T-voltage (L3-N), Average of phase-voltage, RS-voltage (L1-L2), ST-voltage (L2-L3), TR-voltage (L3-L1) Average of line-voltage Pulse count value Digital conversion value(1), Digital conversion value(2), Digital conversion value(3), Temperature(1), Temperature(2), Count value(1), Count value(2), Leakage current(1), Leakage current(2), Leakage current(3)
	Write timing	Every hour xx:05:05 (fixed)
	Saved data amount	96 records for 1 file (for one-day) (Max. 60 days)
15-min. instantaneous value	Save cycle	15 minutes
	Saved data	Integral active power(1), (2), (3), Total integral active power, Integral reactive power(1), (2), (3), Total integral reactive power, Integral apparent power(1), (2), (3), Total integral apparent power, Export active power(1), (2), (3), Total export active power, Export reactive power(1), (2), (3), Total export reactive power, Instantaneous active power(1), (2), (3), Total instantaneous active power, Instantaneous reactive power(1), (2), (3), Total instantaneous reactive power, Instantaneous apparent power(1), (2), (3), Total instantaneous apparent power, R-current, S-current, T-current, N-current, Average of current R-voltage (L1-N), S-voltage (L2-N), T-voltage (L3-N), Average of phase-voltage, RS-voltage (L1-L2), ST-voltage (L2-L3), TR-voltage (L3-L1) Average of line-voltage Power factor(1), (2), (3), Average of power factor Frequency(1), (2), (3), Average of frequency Current THD(1), (2), (3), Average of current THD Phase-voltage THD(1), (2), (3), Average of phase-voltage THD Line-voltage THD(1), (2), (3), Average of line-voltage THD ON-time, OFF-time, Stand-by time, Maintenance-time, Pulse count value Digital conversion value(1), Digital conversion value(2), Digital conversion value(3), Temperature(1), Temperature(2), Count value(1), Count value(2), Leakage current(1), Leakage current(2), Leakage current(3)
	Write timing	Every hour xx:15:05 (fixed)
	Saved data amount	2976 records for 1 file (for one-month) (Max. 24 months)

Customized log	Save cycle	15 minutes
	Saved data	Select items below max. 8-item Integral active power(1), (2), (3), Total integral active power, Integral reactive power(1), (2), (3), Total integral reactive power, Integral apparent power(1), (2), (3), Total integral apparent power, Export active power(1), (2), (3), Total export active power, Export reactive power(1), (2), (3), Total export reactive power, Instantaneous active power(1), (2), (3), Total instantaneous active power, Instantaneous reactive power(1), (2), (3), Total instantaneous reactive power, Instantaneous apparent power(1), (2), (3), Total instantaneous apparent power, R-current, S-current, T-current, N-current, Average of current R-voltage (L1-N), S-voltage (L2-N), T-voltage (L3-N), Average of phase-voltage, RS-voltage (L1-L2), ST-voltage (L2-L3), TR-voltage (L3-L1) Average of line-voltage Power factor(1), (2), (3), Average of power factor Frequency(1), (2), (3), Average of frequency Current THD(1), (2), (3), Average of current THD Phase-voltage THD(1), (2), (3), Average of phase-voltage THD Line-voltage THD(1), (2), (3), Average of line-voltage THD ON-time, OFF-time, Stand-by time, Maintenance-time, Pulse count value Digital conversion value(1), Digital conversion value(2), Digital conversion value(3), Temperature(1), Temperature(2), Count value(1), Count value(2), Leakage current(1), Leakage current(2), Leakage current(3)
	Write timing	Every hour xx:15:05 (fixed)
	Saved data amount	2976 records for 1 file (for one-month) (Max. 24 months)
Demand	Save cycle	1 minute
	Saved data	Present demand (active power, reactive power, apparent power, active power(export), reactive power(export)) Pulse conversion value for integral power, Present current demand (1), (2), (3)
	Write timing	Every hour xx:25:05 (fixed)
	Saved data amount	1000 records for 1 file (Max. 100 files)
Power quality	Saved data	Power interruption, Over voltage, Under voltage, Over current, Under current (with time stamp of event occurrence and occurrence period)
	Write timing	Every hour xx:35:00 (fixed)
	Saved data amount	1000 records for 1 file (Max. 100 files)

11.9 Self-diagnostic

When error is happened, error code will be indicated.

List of Error Code


No.	Name	Action to take
W0001	DHCP server access error	Connect to DHCP server.
W0002	Obtain the illegal IP address by DHCP server	Confirm DHCP server.
W0003	IP address duplication	Change IP address.
W0004	SNTP server access error	Confirm the access to SNTP server
W0005	SNTP server domain name error	Confirm SNTP server domain name
W0006	FTP server access error	Confirm the access to FTP server
W0007	FTP server domain name error	Confirm FTP server domain name
W0008	FTP server log in error	Confirm user name and password of FTP server
W0009	No directory of FTP server	Confirm the directory in FTP server
W0013	During lock out web server according to authentication failure	Leave it 10 minutes
E0042	Remove the expansion units	Turn off power and connect the expansion unit
E0049	Hard ware error	Turn on power again When it doesn't recovery, change main unit because of the life is short.
E0091	Internal memory error 1	Turn on power again When it doesn't recovery, change main unit because of the life is short
E0096	Internal memory error 2	Turn on power again When it doesn't recovery, change main unit because of the life is short

Chapter 12 Mounting


12.1 Dimensions

12.1.1 Main unit (KW2M-A/KW2M-X)

(Unit: mm)
(Clearance: ± 1.0)



12.1.2 Expansion unit



Revision History

Issue Date	Manual No.	Content of revision
June, 2015	WUME-KW2MA-01	First edition
January, 2016	WUME-KW2MA-02	2 nd edition Add series (KW2M-X Eco-POWER METER)
January, 2018	WUME-KW2MA-03	3 rd edition Add series, Expansion unit (Multi analog input) and Expansion unit (Digital I/O) [Add functions] -Customized logging function for KW2M-X -Leakage current measurement mode for Expansion unit (Power measurement) -Combination Demand function
May, 2019	WUME-KW2MA-04	4 th edition [Correct errors] - Delete note for 5.7 Logging Data Writing Function

Please contact

Panasonic Industrial Devices SUNX Co., Ltd.

■ Overseas Sales Division (Head Office): 2431-1 Ushiyama-cho, Kasugai-shi, Aichi, 486-0901, Japan

■ Telephone: +81-568-33-7861 ■ Facsimile: +81-568-33-8591

panasonic.net/id/pidsx/global

About our sales network, please visit our website.

© Panasonic Industrial Devices SUNX Co., Ltd. 2015-2019

Specifications are subject to change without notice.

WUME-KW2MA-04