

Toshiba G9 ASD inverter user manual

ACE-tronics G9 ASD Installation and Operation Manual

ACE-tronics G9 Adjustable Speed Drive

TOSHIBA
Leading Innovation >>>

Document Number: 62078-000

Date: October, 2009



ACE-tronics G9 ASD Installation and Operation Manual

Document Number: 62078-000

Date: October, 2009



Introduction

Congratulations on the purchase of the new **G9 True Torque Control² Adjustable Speed Drive!**

The G9 True Torque Control² Adjustable Speed Drive (ASD) is a solid-state AC drive that features True Torque Control². Toshiba's Vector Control Algorithm enables the motor to develop high starting torque and provide compensation for motor slip, which results in smooth, quick starts and highly efficient operation. The ACE-tronics G9 ASD uses digitally-controlled pulse width modulation. The programmable functions may be accessed via the easy-to-use menu selections or via the **Direct Access Numbers** (see [page 79](#)). This feature, combined with Toshiba's high-performance software, delivers unparalleled motor control and reliability.

The ACE-tronics G9 ASD is a very powerful tool, yet surprisingly simple to operate. The user-friendly **Electronic Operator Interface (EOI)** of the ASD has an easy-to-read LCD screen. There is also a read-only LED screen with enhanced visibility that can be read from a greater distance. The **EOI** provides easy access to the many monitoring and programming features of the ASD.

The motor control software is menu-driven, which allows for easy access to the motor control parameters and quick changes when required.

To maximize the abilities of your new ACE-tronics G9 ASD, a working familiarity with this manual will be required. This manual has been prepared for the ASD installer, user, and maintenance personnel. This manual may also be used as a reference guide or for training. With this in mind, use this manual to develop a system familiarity before attempting to install or operate the device.

Important Notice

The instructions contained in this manual are not intended to cover all details or variations in equipment types, nor may it provide for every possible contingency concerning the installation, operation, or maintenance of this equipment. Should additional information be required contact your ACE World Companies Customer Support Center.

The contents of this manual shall not become a part of or modify any prior or existing agreement, commitment, or relationship. The sales contract contains the entire obligation of ACE World Companies. The warranty contained in the contract between the parties is the sole warranty of ACE World Companies and any statements contained herein do not create new warranties or modify the existing warranty.

Any electrical or mechanical modifications to this equipment without prior written consent of ACE World Companies may void all warranties and may void the UL/CUL listing or other safety certifications. Unauthorized modifications may also result in a safety hazard or equipment damage.

Misuse of this equipment could result in equipment damage or injury to personnel. In no event will ACE World Companies be responsible or liable for direct, indirect, special, or consequential damage or injury that may result from the misuse of this equipment.

About This Manual

This manual was written by the **ACE World Companies** Technical Publications Group. This group is tasked with providing technical documentation for the **G9 Adjustable Speed Drive**. Every effort has been made to provide accurate and concise information to you, our customer.

At **ACE World Companies** we're continuously searching for better ways to meet the constantly changing needs of our customers. E-mail your comments, questions, or concerns about this publication to mperkins@aceworldcompanies.com.

Manual's Purpose and Scope

This manual provides information on how to safely install, operate, maintain, and dispose of your **G9 Adjustable Speed Drive**. The information provided in this manual is applicable to the **G9 Adjustable Speed Drive** only.

This manual provides information on the various features and functions of this powerful cost-saving device, including

- Installation,
- System operation,
- Configuration and menu options, and
- Mechanical and electrical specifications.

Included is a section on general safety instructions that describe the warning labels and symbols that are used throughout the manual. Read the manual completely before installing, operating, performing maintenance, or disposing of this equipment.

This manual and the accompanying drawings should be considered a permanent part of the equipment and should be readily available for reference and review. Dimensions shown in the manual are in metric and/or the English equivalent.

Because of our commitment to continuous improvement, **ACE World Companies** reserves the right, without prior notice, to update information, make product changes, or to discontinue any product or service identified in this publication.

ACE World Companies shall not be liable for direct, indirect, special, or consequential damages resulting from the use of the information contained within this manual.

This manual is copyrighted. No part of this manual may be photocopied or reproduced in any form without the prior written consent of **ACE World Companies**.

© Copyright 2009 **ACE World Companies**.

ACE World Companies[®] is a registered trademark of **ACE World Companies**.

ACE-tronics[®] is a registered trademark of **ACE World Companies**. All other product or trade references appearing in this manual are registered trademarks of their respective owners.

TOSHIBA Leading Innovation[®] is a registered trademark of Toshiba International Corporation.

TOSHIBA[®] is a registered trademark of Toshiba Corporation.

All rights reserved.

Printed in the U.S.A.

Contacting ACE World Companies Customer Support Center

ACE World Companies Customer Support Center can be contacted to obtain help in resolving any **Adjustable Speed Drive** system problem that you may experience or to provide setup information.

The center is open from 8 a.m. to 5 p.m. (CST), Monday through Friday. The Support Center's toll free number is (800) 431-4223 / Local (817) 237-7700 / Fax (817) 237-2777.

You may also contact **ACE World Companies** by writing to:

ACE World Companies

10200 Jacksboro Highway

Fort Worth, Texas 76135

Attn: Mike Perkins

Or send an e-mail to E-mail: mperkins@aceworldcompanies.com.

For additional information on **ACE World Companies'** products and services, please visit our web site at www.aceworldcompanies.com.

ACE World Companies Corporation

ACE-tronics G9 Adjustable Speed Drive

Please complete the Warranty Card supplied with the ACE-tronics G9 ASD and return it to **ACE World Companies** by prepaid mail. This will activate the 12 month warranty from the date of installation; but, shall not exceed 18 months from the shipping date.

Complete the following information and retain for your records.

Model Number: _____

Serial Number: _____

Project Number (if applicable): _____

Date of Installation: _____

Inspected By: _____

Name of Application: _____

Table of Contents

General Safety Information	1
Safety Alert Symbol	1
Signal Words	1
Special Symbols	2
Equipment Warning Labels	2
Qualified Personnel	2
Equipment Inspection	3
Handling and Storage	3
Disposal	3
Installation Precautions	4
Location and Ambient Requirements	4
Mounting Requirements	4
Conductor Routing and Grounding	5
Power Connections	6
Protection	6
System Integration Precautions	7
Personnel Protection	7
System Setup Requirements	8
Operational and Maintenance Precautions	9
Motor Characteristics	10
Motor Autotuning	10
Pulse Width Modulation Operation	10
Low-Speed Operation	10
Overload Protection Adjustment	10
Operation Above 60 Hz	10
Power Factor Correction	11
Light Load Conditions	11
Motor/Load Combinations	11
Load-Produced Negative Torque	12
Motor Braking	12
ASD Characteristics	13
Over-Current Protection	13
ASD Capacity	13
Using Vector Control	13

Installation and Connections	14
Installation Notes	14
Mounting the ASD	15
Connecting the ASD	16
ACE G9-120V-PCB	21
ACE G9-120V-PCB Precautions	21
Terminal Functions	22
Communications	23
Alternate I/O Terminal Board	23
ACE G9-120V-PCB Specifications/Layout	24
Electronic Operator Interface	32
EOI Operation	32
EOI Remote Mounting	32
EOI Features	33
EOI Remote Mounting	37
System Operation	40
Operation (Local)	40
Default Setting Changes	40
Save User Settings	41
Startup Wizard Requirements	42
ASD Control Configuration	45
Autotune Enable	46
Speed Control (F986)	46
Accel/Decel Times	46
Special Functions	46
Command and Frequency Mode Control	47
Command Control (F003)	47
Frequency Control (F004)	48
Override Operation	49
System Configuration and Menu Options	52
Root Menus	52
Direct Access Information	79
Direct Access Parameters/Numbers	79
Alarms, Trips, and Troubleshooting	248
Alarms and Trips	248
Alarms	249
Trips/Faults	254
Enclosure Dimensions and Conduit Plate Information	261
Enclosure Dimensions	262
Current/Voltage Specifications	270

Cable/Terminal/Torque Specifications	272
Dynamic Braking Resistor Specifications	274
Short Circuit Protection Recommendations	276
ACE-tronics G9 ASD Optional Devices	277

General Safety Information

DO NOT attempt to install, operate, maintain, or dispose of this equipment until you have read and understood all of the product safety information and directions that are contained in this manual.

Safety Alert Symbol

The **Safety Alert Symbol** is comprised of an equilateral triangle enclosing an exclamation mark. This indicates that a potential personal injury hazard exists.



Signal Words

Listed below are the signal words that are used throughout this manual followed by their descriptions and associated symbols. When the words **DANGER**, **WARNING**, or **CAUTION** are used in this manual they will be followed by important safety information that must be carefully adhered to.

The word **DANGER** preceded by the safety alert symbol indicates that an imminently hazardous situation exists that, if not avoided, will result in serious injury to personnel or loss of life.



The word **WARNING** preceded by the safety alert symbol indicates that a potentially hazardous situation exists that, if not avoided, could result in serious injury to personnel or loss of life.



The word **CAUTION** preceded by the safety alert symbol indicates that a potentially hazardous situation exists that, if not avoided, may result in minor or moderate injury.



The word **CAUTION** without the safety alert symbol indicates a potentially hazardous situation exists that, if not avoided, may result in equipment and property damage.

CAUTION

Special Symbols

To identify special hazards, other symbols may appear in conjunction with the **DANGER**, **WARNING**, or **CAUTION** signal words. These symbols indicate areas that require special and/or strict adherence to the procedures to prevent serious injury to personnel or loss of life.

Electrical Hazard Symbol

A symbol that is comprised of an equilateral triangle enclosing a lightning bolt that indicates a hazard of injury from electrical shock or burn.



Explosion Hazard Symbol

A symbol that is comprised of an equilateral triangle enclosing an explosion that indicates a hazard of injury from exploding parts.



Equipment Warning Labels

DO NOT attempt to install, operate, perform maintenance, or dispose of this equipment until you have read and understood all of the user directions that are contained in this manual.

Warning labels that are attached to the equipment will include the exclamation mark within a triangle. **DO NOT** remove or cover any of these labels. If the labels are damaged or if additional labels are required, contact your ACE World Companies Customer Support Center.

Labels attached to the equipment are there to provide useful information or to indicate an imminently hazardous situation that may result in property or equipment damage, serious injury, or loss of life if safe procedures or methods are not followed as outlined in this manual.

Qualified Personnel

Installation, operation, and maintenance shall be performed by **Qualified Personnel Only**. A Qualified Person is one that has the skills and knowledge relating to the construction, installation, operation, and maintenance of the electrical equipment and has received safety training on the hazards involved (Refer to the latest edition of NFPA 70E for additional safety requirements).

Qualified Personnel shall:

- Have carefully read the entire operation manual.
- Be familiar with the construction and function of the ACE-tronics G9 ASD, the equipment being driven, and the hazards involved.
- Be able to recognize and properly address hazards associated with the application of motor-driven equipment.
- Be trained and authorized to safely energize, de-energize, ground, lockout/tagout circuits and equipment, and clear faults in accordance with established safety practices.
- Be trained in the proper care and use of protective equipment such as safety shoes, rubber gloves, hard hats, safety glasses, face shields, flash clothing, etc., in accordance with established safety practices.

For additional information on workplace safety visit www.osha.gov.

Equipment Inspection

- Upon receipt of the equipment inspect the packaging and equipment for shipping damage.
- Carefully unpack the equipment and check for damaged parts, missing parts, or concealed damage that may have occurred during shipping. If any discrepancies are discovered, it should be noted with the carrier prior to accepting the shipment, if possible. File a claim with the carrier if necessary and immediately notify your ACE World Companies Customer Support Center.
- Ensure that the rated capacity and the model number specified on the nameplate conform to the order specifications.
- Modification of this equipment is dangerous and are to be performed by factory-trained representatives. When modifications are required contact your ACE World Companies Customer Support Center.
- **DO NOT** install the ASD if it is damaged or if it is missing any component(s).
- Inspections may be required after moving the equipment.
- Contact your ACE World Companies Customer Support Center to report discrepancies or for assistance if required.

Handling and Storage

- Use proper lifting techniques when moving the ACE-tronics G9 ASD; including properly sizing up the load, getting assistance, and using a forklift if required.
- Store in a well-ventilated location and preferably in the original carton if the equipment will not be used upon receipt.
- Store in a cool, clean, and dry location. Avoid storage locations with extreme temperatures, rapid temperature changes, high humidity, moisture, dust, corrosive gases, or metal particles.
- The storage temperature range of the ACE-tronics G9 ASD is -14° to 104° F (-10° to 40° C).
- **DO NOT** store the unit in places that are exposed to outside weather conditions (i.e., wind, rain, snow, etc.).
- Store in an upright position.

Disposal

Never dispose of electrical components via incineration. Contact your state environmental agency for details on disposal of electrical components and packaging in your area.

Installation Precautions

Location and Ambient Requirements

- The ACE-tronics G9 ASD is intended for permanent installations only.
- Installation should conform to the **2008 National Electrical Code — Article 110** (NEC) (*Requirements For Electrical Installations*), all regulations of the **Occupational Safety and Health Administration**, and any other applicable national, regional, or industry codes and standards.
- Select a mounting location that is easily accessible, has adequate personnel working space, and adequate illumination for adjustment, inspection, and maintenance of the equipment (refer to 2008 NEC Article 110-13).
- **DO NOT** mount the ASD in a location that would produce catastrophic results if it were to fall from its mounting location (equipment damage or injury).
- **DO NOT** mount the ASD in a location that would allow it to be exposed to flammable chemicals or gases, water, solvents, or other fluids.
- Avoid installation in areas where vibration, heat, humidity, dust, fibers, metal particles, explosive/corrosive mists or gases, or sources of electrical noise are present.
- The installation location shall not be exposed to direct sunlight.
- Allow proper clearance spaces for installation. Do not obstruct the ventilation openings. Refer to the section titled [Installation and Connections](#) on [pg. 14](#) for additional information on ventilation requirements.
- The ambient operating temperature range of the ACE-tronics G9 ASD is 14° to 104° F (-10° to 40° C).

Mounting Requirements

- Only **Qualified Personnel** should install this equipment.
- Install the unit in a secure and upright position in a well-ventilated area.
- As a minimum, the installation of the equipment should conform to the **2008 National Electrical Code — Article 110** (NEC), OSHA, as well as any other applicable national, regional, or industry codes and standards.
- Installation practices shall conform to the latest revision of NFPA 70E Electrical Safety Requirements for Employee Workplaces.
- It is the responsibility of the ASD installer/maintenance personnel to ensure that the unit is installed into an enclosure that will protect personnel against electric shock.

Conductor Routing and Grounding



- Use separate metal conduits for routing the input power, output power, and control circuits.
- A separate ground cable shall be run inside of the conduit with the input power, output power, and control circuits.
- **DO NOT** connect **CC** to earth ground.
- **ONLY** use the **IICC** terminal as the return for the **V/I** input.
- Always ground the unit to prevent electrical shock and to help reduce electrical noise.
- It is the responsibility of the ASD installer/maintenance personnel to provide proper grounding and branch circuit protection in accordance with the **2008 NEC** and any other applicable national, regional, or industry codes and standards.

— **The Metal Of Conduit Is Not An Acceptable Ground** —

Grounding Capacitor Switch

The ACE-tronics G9 ASD is equipped with noise reduction capacitors which are used to reduce the EMI leakage via the 3-phase power-input circuit and for compliance with the **Electromagnetic Compatibility Directive** (EMC).

The effective value of the capacitor may be increased, reduced, or removed entirely via the **Selector Switch**, **Switching Bar**, or the **Switching Screw** — the type used is typeform-specific.

The **Grounding Capacitor Switch** allows the user to quickly change the value of the leakage-reduction capacitance of the 3-phase input circuit without the use of tools.

See the section titled [System Grounding on pg. 18](#) for more on the [Grounding Capacitor](#).

See figures [4](#), [5](#), [6](#), and [7](#) on [pg. 19](#) for an electrical depiction of the leakage-reduction functionality of the [Grounding Capacitor](#) and the methods used to set the capacitance value.

Power Connections



Contact With Energized Wiring Will Cause Severe Injury Or Loss Of Life.

- Turn off, lockout, and tag out all power sources before proceeding to connect the power wiring to the equipment.
- After ensuring that all power sources are turned off and isolated in accordance with established lockout/tag out procedures, connect the 3-phase power source wiring of the correct voltage to the correct input terminals and connect the output terminals to a motor of the correct voltage and type for the application (refer to NEC Article 300 – Wiring Methods and Article 310 – Conductors For General Wiring). Size the branch circuit conductors in accordance with NEC Table 310.16.
- Ensure that the 3-phase input power is **NOT** connected to the output of the ACE-tronics G9 ASD. This will damage the ASD and may cause injury to personnel.
- **DO NOT** connect resistors across terminals PA – PC or PO – PC. This may cause a fire.
- Ensure the correct phase sequence and the desired direction of motor rotation in the **Bypass** mode (if applicable).
- Turn the power on only after attaching and/or securing the front cover.

Protection

- Ensure that primary protection exists for the input wiring to the equipment. This protection must be able to interrupt the available fault current from the power line. The equipment may or may not be equipped with an input disconnect (option).
- All cable entry openings must be sealed to reduce the risk of entry by vermin and to allow for maximum cooling efficiency.
- External dynamic braking resistors must be thermally protected.
- It is the responsibility of the ASD installer/maintenance personnel to setup the **Emergency Off** braking system of the ASD. The function of the **Emergency Off** braking function is to remove output power from the drive in the event of an emergency. A supplemental braking system should also be engaged in the event of an emergency. For additional information on braking systems see parameters [F250](#) and [F304](#).

***Note:** A supplemental emergency stopping system should be used with the ASD. Emergency stopping should not be a task of the ASD alone.*

- Follow all warnings and precautions and do not exceed equipment ratings.

System Integration Precautions

The following precautions are provided as general guidelines for the setup of the ACE-tronics G9 ASD within the system.

- The ACE-tronics G9 ASD is a general-purpose product. It is a system component only and the system design should take this into consideration. Please contact your ACE World Companies Customer Support Center for application-specific information or for training support.
- The ACE-tronics G9 ASD is part of a larger system and the safe operation of the ASD will depend upon observing certain precautions and performing proper system integration.
- Improperly designed or improperly installed system interlocks may render the motor unable to start or stop on command.
- The failure of external or ancillary components may cause intermittent system operation (i.e., the system may start the motor without warning).
- A detailed system analysis and job safety analysis should be performed by the systems designer and/or systems integrator before the installation of the ASD component. Contact your ACE World Companies Customer Support Center for options availability and for application-specific system integration information if required.

Personnel Protection

- Installation, operation, and maintenance shall be performed by **Qualified Personnel Only**.
- A thorough understanding of the ACE-tronics G9 ASD will be required before the installation, operation, or maintenance of the ASD.



- Rotating machinery and live conductors can be hazardous and shall not come into contact with personnel. Personnel should be protected from all rotating machinery and electrical hazards at all times.
- Insulators, machine guards, and electrical safeguards may fail or be defeated by the purposeful or inadvertent actions of workers. Insulators, machine guards, and electrical safeguards are to be inspected (and tested where possible) at installation and periodically after installation for potential hazardous conditions.
- **DO NOT** allow personnel near rotating machinery. Warning signs to this effect shall be posted at or near the machinery.
- **DO NOT** allow personnel near electrical conductors. Contact with electrical conductors can be fatal. Warning signs to this effect shall be posted at or near the hazard.
- Personal protection equipment shall be provided and used to protect employees from any hazards inherent to system operation.

System Setup Requirements

- When using the ACE-tronics G9 ASD as an integral part of a larger system, it is the responsibility of the ASD installer/maintenance personnel to ensure that there is a fail-safe in place (i.e., an arrangement designed to switch the system to a safe condition if there is a fault or failure).
- System safety features should be employed and designed into the integrated system in a manner such that system operation, even in the event of system failure, will not cause harm or result in system damage or injury to personnel (i.e., E-Off, Auto-Restart settings, System Interlocks, etc.).
- The programming setup and system configuration of the ASD may allow it to start the motor unexpectedly. A familiarity with the Auto-Restart settings are a requirement to use this product.
- Power factor improvement/correction capacitors or surge absorbers **MUST NOT** be installed on the output of the ACE-tronics G9 ASD.
- Use of the built-in system protective features is highly recommended (i.e., E-Off, Overload Protection, etc.).
- The operating controls and system status indicators should be clearly readable and positioned where the operator can see them without obstruction.
- Additional warnings and notifications shall be posted at the equipment installation location as deemed required by **Qualified Personnel**.



CAUTION

- There may be thermal or physical properties, or ancillary devices integrated into the overall system that may allow for the ACE-tronics G9 ASD to start the motor without warning. Signs to this effect must be posted at the equipment installation location.
- If a secondary magnetic contactor (MC) or an ASD output disconnect is used between the ASD and the load, it should be interlocked to halt the ASD before the secondary contact opens. If the output contactor is used for bypass operation, it must be interlocked such that commercial power is never applied to the ASD output terminals (U, V, W).
- When using an ASD output disconnect, the ASD and the motor must be stopped before the disconnect is either opened or closed. Closing the output disconnect while the 3-phase output of the ASD is active may result in equipment damage or injury to personnel.

Operational and Maintenance Precautions

WARNING

- Turn off, lockout, and tag out the main power, the control power, and instrumentation connections before proceeding to connect/disconnect the power wiring, inspecting or servicing the drive, or opening the door of the enclosure.
- The capacitors of the ACE-tronics G9 ASD maintain a residual charge for a period of time after turning off the ASD. The required time for each ASD typeform is indicated with a cabinet label and a **Charge LED** (shown for smaller ASDs in [Figure 2 on pg. 16](#); LED is located on the front panel of larger ASDs). Wait at least the minimum time indicated on the enclosure-mounted label and ensure that the **Charge LED** has gone out before opening the door of the ASD once the ASD power has been turned off.
- Turn the power on only after attaching (or closing) the front cover and **DO NOT** remove or open the front cover of the ACE-tronics G9 ASD when the power is on.
- **DO NOT** attempt to disassemble, modify, or repair the ACE-tronics G9 ASD. Contact your ACE World Companies Customer Support Center for repair information.
- **DO NOT** place any objects inside of the ACE-tronics G9 ASD.
- If the ASD should emit smoke, or an unusual odor or sound, turn the power off immediately.
- The heat sink and other components may become extremely hot to the touch. Allow the unit to cool before coming in contact with these items.
- Remove power from the ASD during extended periods of non-use.
- The system should be inspected periodically for damaged or improperly functioning parts, cleanliness, and to ensure that the connectors are tightened securely.

Motor Characteristics

Listed below are some variable speed AC motor control concepts with which the user of the **G9 Adjustable Speed Drive** should become familiar.

Motor Autotuning

Motor production methods may cause minor differences in motor operation. The negative effects of these differences may be minimized by using the **Autotune** feature of the ACE-tronics G9 ASD. **Autotuning** is a function of the ASD that measures several parameters of the connected motor and places these readings in a stored table. The software uses the information in the table to help optimize the response of the ASD to application-specific load and operational requirements. The **Autotuning** function may be enabled for automatic tuning, configured manually at **F400**, or disabled.

The measured parameters include the rotor resistance, the stator resistance, the required excitation inductance, rotational inertia values, and leakage inductance values.

Pulse Width Modulation Operation

The ACE-tronics G9 ASD uses sinusoidal **Pulse Width Modulation** (PWM) control. The output current waveform generated by the ASD approaches that of a perfect sine wave; however, the output waveform is slightly distorted. For this reason, the motor may produce more heat, noise, and vibration when operated by an ASD, rather than directly from commercial power.

Low-Speed Operation

Operating a general-purpose motor at lower speeds may cause a decrease in the cooling ability of the motor. Reducing the torque requirement of the motor at lower speeds will decrease the generated heat at lower speeds.

When the motor is to be operated at low speed (less than 50% of full speed) and at the rated torque continuously, a Toshiba VF motor (designed for use in conjunction with an ASD) is recommended.

Overload Protection Adjustment

The ACE-tronics G9 ASD software monitors the output current of the system and determines when an overload condition occurs. The overload current level is a percentage of the rating of the motor. This function protects the motor from overload.

The default setting for the overload detection circuit is set to the maximum rated current of the ASD at the factory. This setting will have to be adjusted to match the rating of the motor with which the ASD is to be used. To change the overload reference level, see [Motor Overload Protection Level 1 on pg. 175](#).

Operation Above 60 Hz

A motor produces more noise and vibration when it is operated at frequencies above 60 Hz. Also, when operating a motor above 60 Hz, the rated limit of the motor or its bearings may be exceeded; this may void the motor warranty.

Contact the motor manufacturer for additional information before operating the motor above 60 Hz.

Power Factor Correction

DO NOT connect a power factor correction capacitor or surge absorber to the output of the ACE-tronics G9 ASD.

If the ASD is used with a motor that is equipped with a capacitor for power factor correction, remove the capacitor from the motor.

Connecting either of these devices to the output of the ASD may cause the ASD to malfunction and trip, or the output device may cause an over-current condition resulting in damage to the device or the ASD.

Light Load Conditions

When a motor is operated under a continuous light load (i.e., at a load of less than 50% of its rated capacity) or it drives a load which produces a very small amount of inertia, it may become unstable and produce abnormal vibration or trips because of an over-current condition. In such a case, the carrier frequency may be lowered to compensate for this undesirable condition (see Program ⇒ Special ⇒ Carrier Frequency ⇒ [PWM Carrier Frequency](#)).

Note: When operating in the **Vector Control** mode the carrier frequency should be set to 2.2 kHz or above.

Motor/Load Combinations

When the ACE-tronics G9 ASD is used in combination with one of the following motors or loads, it may result in unstable operation.

- A motor with a rated capacity that exceeds the motor capacity recommended for the ASD.
- An explosion-proof motor.

When using the ASD with an explosion-proof motor or other special motor types, lower the carrier frequency to stabilize the operation. **DO NOT** set the carrier frequency below 2.2 kHz if operating the system in the vector control mode.

Note: When operating in the **Vector Control** mode the carrier frequency should be set to 2.2 kHz or above.

If the motor that is coupled to a load that has a large backlash or a reciprocating load, use one of the following procedures to stabilize its operation.

- Adjust the **S-Pattern** acceleration/deceleration setting,
- If operating in the **Vector** control mode, adjust the response time, or
- Switch to the **Constant Torque** control mode.

Load-Produced Negative Torque

When the ACE-tronics G9 ASD is used with a load that produces negative torque (an overhauling load), the over-voltage or over-current protective functions of the ASD may cause nuisance tripping.

To minimize the undesirable effects of negative torque the dynamic braking system may be used. The dynamic braking system converts the regenerated energy into heat that is dissipated using a braking resistor. The braking resistor must be suitably matched to the load. Dynamic braking is also effective in reducing the DC bus voltage during a momentary over-voltage condition.



CAUTION

If under extreme conditions the dynamic braking system or a component of this system were to fail, the dynamic braking resistor may experience an extended over-current condition. The DBR circuit was designed to dissipate excessive amounts of heat and if the extended over-current condition were allowed to exceed the circuit parameters, this condition could result in a fire hazard.

To combat this condition, the 3-phase input may be connected using contactors that are configured to open in the event of an extended DBR over-current condition or an internal circuit failure. Using a thermal sensor and/or overload protection as the 3-phase input contactor drive signal, the contactors will open and remove the 3-phase input power in the event of an extended DBR over-current or system over-voltage condition. See [Dynamic Braking Enable on pg. 140](#) for more information using Dynamic Braking with the ASD.

Motor Braking

The motor may continue to rotate and coast to a stop after being shut off due to the inertia of the load. If an immediate stop is required, a braking system should be used. The two most common types of motor braking systems used with the ACE-tronics G9 ASD are **DC Injection Braking** and **Dynamic Braking**. For additional information on braking systems, see [DC Injection Braking on pg. 127](#) and [Dynamic Braking Enable on pg. 140](#).

ASD Characteristics

Over-Current Protection

Each ACE-tronics G9 ASD is designed for a specified operating power range. The ASD will incur a trip if the design specifications are exceeded.

However, the ASD may be operated at 115% of the specified output-current range continuously (or 110% continuously if ≥ 60 HP for the 230-volt system or if ≥ 125 HP for the 460-volt system) or at 150% for a limited amount of time as indicated in the section titled [Current/Voltage Specifications on pg. 270](#). Also, the [Stall Prevention Level](#) may be adjusted to help with nuisance over-current trips (see [F601](#)).

When using the ASD for an application to control a motor that is rated significantly less than the maximum current rating of the ASD, the over-current limit (Thermal Overload Protection) setting will have to be changed to match the FLA of the motor. For additional information on this parameter, see [Motor Overload Protection Level 1 on pg. 175](#).

ASD Capacity

The ACE-tronics G9 ASD must not be used with a motor that has a larger capacity than the ASD, even if the motor is operated under a small load. An ASD being used in this way will be susceptible to a high-output peak current which may result in nuisance tripping.

Do not apply a level of input voltage to an ASD that is beyond that which the ASD is rated. The input voltage may be stepped down when required with the use of a step-down transformer or some other type of voltage-reduction system.

Using Vector Control

Using **Vector Control** enables the system to produce very high torque over the entire operating range even at extremely low speeds. **Vector Control** may be used with or without feedback. However, using feedback increases the speed accuracy for applications requiring precise speed control.

See [F015 on pg. 85](#) for additional information on using **Vector Control**.

Installation and Connections

The ACE-tronics G9 ASD may be set up initially by performing a few simple configuration settings. To operate properly, the ASD must be securely mounted and connected to a power source (3-phase AC input at the R/L1, S/L2, and T/L3 terminals). The control terminals of the ASD may be used by connecting the terminals of the **ACE G9-120V-PCB** to the proper sensors or signal input sources (see the section titled [ACE G9-120V-PCB on pg. 21](#) and [Figure 8 on pg. 24](#)).

System performance may be further enhanced by assigning a function to the output terminals of the **ACE G9-120V-PCB** and connecting the terminals to the proper indicators or actuators (LEDs, relays, contactors, etc.).

***Note:** The optional ACE-tronics G9 ASD interface boards may be used to expand the I/O functionality of the ASD.*

Installation Notes



CAUTION

When a brake-equipped motor is connected to the ASD, it is possible that the brake may not release at startup because of insufficient voltage. To avoid this, **DO NOT** connect the brake or the brake contactor to the output of the ASD.

If an output contactor is used for bypass operation, it must be interlocked such that commercial power is never applied to the output terminals of the ASD (U/T1, V/T2, and W/T3).

DO NOT apply commercial power to the ASD output terminals **U/T1**, **V/T2**, and **W/T3**.

Though the default settings of the ASD do not include the use of a physical discrete input terminal being programmed to the **ST** function, the system may be configured to use a physical discrete input terminal set to **ST**. When configured properly, the externally-activated **ST** terminal acts as a permissive in allowing for normal system operation. See parameter [F110](#) for more information on the use of the **ST** terminal.

If a secondary magnetic contactor (MC) is used between the output of the ASD and the motor, it should be interlocked such that the **ST** terminal activation is deactivated before the output contactor is opened.

DO NOT open and then close a secondary magnetic contactor between the ASD and the motor unless the ASD is off and the motor is not rotating.

***Note:** Re-application of power via a secondary contact while the ASD is on or while the motor is still turning may cause ASD damage.*

The ASD input voltage should remain within 10% of the specified input voltage range. Input voltages approaching the upper or lower limit settings may require that the over-voltage and under-voltage stall protection level parameters be adjusted. Voltages outside of the permissible tolerance should be avoided.

The frequency of the input power should be ± 2 Hz of the specified input frequency.

DO NOT use an ASD with a motor that has a power rating higher than the rated output of the ASD.

The ACE-tronics G9 ASD is designed to operate NEMA B motors. Consult with the ACE World Companies Customer Support Center before using the ASD for special applications such as with an explosion-proof motor or applications with a piston load.


Disconnect the ASD from the motor before megging or applying a bypass voltage to the motor.

Interface problems may occur when an ASD is used in conjunction with some types of process controllers. Signal isolation may be required to prevent controller and/or ASD malfunction (contact your ACE World Companies Customer Support Center or the process controller manufacturer for additional information about compatibility and signal isolation).

Use caution when setting the output frequency. Over speeding a motor decreases its ability to deliver torque and may result in damage to the motor and/or the driven equipment.

Not all ACE-tronics G9 ASDs are equipped with internal primary power input fuses (typeform-dependent). When connecting two or more drives that have no internal fuse to the same power line as shown in [Figure 1](#), it will be necessary to select a circuit-breaking configuration that will ensure that if a short circuit occurs in ASD 1, only MCCB2 trips, not MCCB1. If it is not feasible to use this configuration, insert a fuse between MCCB2 and ASD 1.

Figure 1. Circuit Breaker Configuration.



Mounting the ASD

CAUTION

— The following thermal specifications apply to the 230- and the 460-Volt ASDs ONLY —

Install the unit securely in a well ventilated area that is out of direct sunlight.

The process of converting AC to DC, and then back to AC produces heat. During normal ASD operation, up to 5% of the input energy to the ASD may be dissipated as heat. If installing the ASD in a cabinet, ensure that there is adequate ventilation.

DO NOT operate the ASD with the enclosure door open.

The ambient operating temperature rating of the ACE-tronics G9 ASD is 14° to 104° F (-10° to 40° C).

When installing adjacent ASDs horizontally ACE World Companies recommends at least 5 cm of space between adjacent units. However, horizontally mounted ASDs may be installed side-by-side with no space between the adjacent units — side-by-side installations require that the top cover be removed from each ASD.

For 150 HP ASDs and above, a minimum of 50 cm of space is required above and below adjacent units and any obstruction. This space is the recommended minimum space requirement for the ASD and ensures that adequate ventilation is provided for each unit. More space will provide a better environment for cooling (see the section titled [Enclosure Dimensions and Conduit Plate Information on pg. 261](#) for additional information on mounting space requirements).

Note: *Ensure that the ventilation openings are not obstructed.*

Connecting the ASD



Refer to the section titled [Installation Precautions](#) on pg. 4 and the section titled [Lead Length Specifications](#) on pg. 20 before attempting to connect the ASD and the motor to electrical power.

Power Connections



Contact With Energized Wiring Will Cause Severe Injury Or Loss Of Life.

See [Figure 20](#) on pg. 30 for a system I/O connectivity schematic.

An inductor (DCL) may be connected across the **PO** and **PA/+** terminals to provide additional filtering. When not used, a jumper must be connected across these terminals.

PA/+ and **PB** are used for the DBR connection if using a braking resistor.


PC/- is the negative terminal of the DC bus.

R/L1, **S/L2**, and **T/L3** are the 3-phase input supply terminals for the ASD.

U/T1, **V/T2**, and **W/T3** are the output terminals of the ASD that connect to the motor.

The location of the **Charge LED** for the smaller typeform ASD is provided in [Figure 2](#). The **Charge LED** is located on the front door of the enclosure of the larger ASDs.

Figure 2. Typical ASD Input/Output Terminals and the [Grounding Capacitor Switch](#).



Grounding Capacitor Switch — Pull for **Small** capacitance/push for **Large** capacitance.

Power Connection Requirements

Connect the 3-phase input power to the input terminals of the ASD at **R/L1**, **S/L2**, and **T/L3** (see [Figure 3](#) for the typical electrical connection scheme). Connect the output of the ASD to the motor from the ASD terminals **U/T1**, **V/T2**, and **W/T3**. The input and output conductors and terminal lugs used shall be in accordance with the requirements listed in the section titled [Current/Voltage Specifications](#) on pg. 270.

If multiple conductors are used in parallel for the input or output power and it is necessary to use separate conduits, each parallel set shall have its own conduit and not share its conduit with other parallel sets (i.e., place U1, V1, W1, and a ground wire in one conduit and U2, V2, and W2, and a ground wire in another; refer to NEC Article 300.20 and Article 310.4). National, regional, and industry electrical codes should be referenced if three or more power conductors are run in the same conduit (refer to 2008 NEC Article 310 adjustment factors).

Note: *Local and national codes should be referenced when running more than three conductors in the same conduit.*


Install a molded case circuit breaker (MCCB) or fuse between the 3-phase power source and the ASD in accordance with the fault current setting of the ASD and **2008 NEC Article 430**.

The ACE-tronics G9 ASD is designed and tested to comply with UL Standard 508C. Modifications to the ASD system or failure to comply with the short circuit protection requirements outlined in this manual may disqualify the UL rating. See [Table 23](#) on pg. 276 for typeform-specific short circuit protection recommendations.

As a minimum, the installation of the ASD shall conform to **2008 NEC Article 110**, the **Occupational Safety and Health Administration** requirements, and to any other local and regional industry codes and standards.

Note: *In the event that the motor rotates in the wrong direction when powered up, reverse any two of the three ASD output power leads (U, V, or W) connected to the motor.*

Figure 3. G9 ASD/Motor Typical Connection Diagram.



System Grounding

Proper grounding helps to prevent electrical shock and to reduce electrical noise. The ACE-tronics G9 ASD is designed to be grounded in accordance with **Article 250** of the **2008 NEC** or **Section 10/Part One** of the **Canadian Electrical Code (CEC)**.

The grounding conductor shall be sized in accordance with **Article 250-122** of the **NEC** or **Part One-Table 6** of the **CEC**.

— The Metal Of Conduit Is Not An Acceptable Ground —

The input, output, and control lines of the system shall be run in separate metal conduits and each shall have its own ground conductor.

ASDs produce high-frequency noise — steps must be taken during installation to avoid the negative effects of noise. Listed below are some examples of measures that will help to combat noise problems.

- **DO NOT** install the input power wires and output power wires in the same duct or in parallel with each other, and do not bind them together.
- **DO NOT** install the input power wires, output power wires, and the wires of the control circuit in the same duct or in parallel with each other, and do not bind them together.
- Use shielded wires or twisted wires for the control circuits.
- Ensure that the grounding terminals (G/E) of the ASD are securely connected to ground.
- Connect a surge suppressor to every electromagnetic contactor and every relay installed near the ASD.
- Install noise filters as required.

Grounding Capacitor

The **Grounding Capacitor** plays a role in minimizing the effects of leakage current through the ASD system and through ground paths to other systems. Leakage current may cause the improper operation of earth-leakage current breakers, leakage-current relays, ground relays, fire alarms, and other sensors — and it may cause superimposed noise on CRT screens.

The **Grounding Capacitor Switch** allows the user to quickly change the value of the leakage-reduction capacitance of the 3-phase input circuit. See figures 4, 5, 6, and 7 on pg. 19 for an electrical depiction of the leakage-reduction functionality and the methods used to change the capacitance value. The method used is typeform-specific.

If using a 460-Volt 5 HP ASD or a 460-Volt ASD that is in the range of 7.5 HP to 25 HP, and the **U/T1**, **V/T2**, and **W/T3** connections to the motor are 100 meters or more in length, the ASD **Carrier Frequency** must be set to 4 kHz or less when activating or deactivating the **Grounding Capacitor Switch**. ASD overheating may occur if the **Carrier Frequency** is set above 4 kHz when activating or deactivating the **Grounding Capacitor Switch**.

See pg. 5 for more information on the **Grounding Capacitor Switch** and pg. 16 for the location of the switch.

Figure 4. The Grounding Capacitor Switch is used on typeforms **230-volt** 0.5 HP to 10 HP and the 25 and 30 HP/**460-Volt** 1.0 HP to 250 HP.

The value may be set to **Maximum** (default setting) or to **Zero** by pushing or pulling the switch actuator, respectively.

Figure 5. The Grounding Capacitor Switch is used on typeforms **230-volt** 15 HP to 20 HP and the 40 HP to 60 HP/**460-Volt** 30 HP to 100 HP.

The value may be set to **Large** (default setting) or **Small** by pushing or pulling the switch actuator, respectively.

Figure 6. The Grounding Capacitor Bar is used on typeforms **230-volt** 75 HP and the 100 HP/**460-Volt** 125 HP and the 150 HP.

The value may be set to **Small** (default setting) or **Large** by connecting or disconnecting the switching bar, respectively.

Figure 7. The Grounding Capacitor Screw is used on typeforms **460-volt** 175 HP and above.

The value may be set to **Small** (default setting) or **Large** by placing the screw in the **A** position or by placing the screw in the **B** position, respectively.

Lead Length Specifications

Adhere to the NEC and any local codes during the installation of ASD/motor systems. Excessive lead lengths may adversely effect the performance of the motor. Special cables are not required. Lead lengths from the ASD to the motor in excess of those listed in [Table 1](#) may require filters to be added to the output of the ASD. [Table 1](#) lists the suggested maximum lead lengths for the listed motor voltages.

All Toshiba **CT** motors incorporate an insulation system that is in compliance with **NEMA MG1 Part 30**.

All Toshiba **XT** motors incorporate an insulation system that is in compliance with **NEMA MG1 Part 31**.

Table 1. Lead Length Recommendations.

Model	PWM Carrier Frequency	NEMA MG-1 Part 30 Compliant Motors	NEMA MG-1 Part 31 Compliant Motors
230-Volt	All	450 feet	1000 feet
460-Volt	< 5 kHz	200 feet	600 feet
	≥ 5 kHz	100 feet	300 feet
575-Volt	< 5 kHz	75 feet	200 feet
	≥ 5 kHz	50 feet	100 feet

Note: *Contact the **ACE World Companies** Customer Support Center for application assistance when using lead lengths in excess of those listed.*

Exceeding the peak voltage rating or the allowable thermal rise time of the motor insulation will reduce the life expectancy of the motor.

*When operating in the **Vector Control** mode the carrier frequency should be set to 2.2 kHz or above.*

ACE G9-120V-PCB

The ACE-tronics G9 ASD can be controlled by several input types and combinations thereof, as well as operate within a wide range of output frequency and voltage levels. This is accomplished with the use of the **ACE G9-120V-PCB** (shown in [Figure 8 on pg. 24](#)).

The **ACE G9-120V-PCB** is designed to allow for a discrete or analog signal to control the speed and/or torque of the motor.

A 120 VAC On/Off input signal may be used to activate and deactivate the discrete input terminals (i.e., F, R, Jog, etc.), or an analog voltage or current may be used to vary the speed or torque of the motor. The gain and bias of the analog control signal may be adjusted for application-specific suitability by the user.

The analog and discrete outputs of the **ACE G9-120V-PCB** may be used to annunciate an active condition or to activate an ancillary device (e.g., brake, LED, etc.).

No special programming or program changes are required to use the **ACE G9-120V-PCB**. However, application-specific setup programming may be required.

[Table 4 on pg. 25](#) lists the names, descriptions, and the default settings (of programmable terminals) of the input and output terminals of the **ACE G9-120V-PCB**.

***Note:** To use the input lines of the **ACE G9-120V-PCB** to provide **Run** commands the **Command Mode** setting must be set to **Terminal Board**.*

[Figure 20 on pg. 30](#) shows a typical connection diagram for the ASD system.

ACE G9-120V-PCB Precautions



- The ASD contains high voltage parts. Contact with live circuits will result in electric shock.
- Ensure that the ASD system is tagged out before attempting to perform maintenance or when making adjustments to the ASD system.
- Ensure that all system/ASD power is off and that the **Charge** LED of the ASD is off.
- **DO NOT** open the door of the ASD when the ASD power is on. **DO NOT** attempt to operate the ASD with the door open. Failure to do so can lead to electric shock and may result in serious injury or loss of life.
- The **ACE G9-120V-PCB** uses 120 VAC and may cause serious injury if it is used improperly or if it comes into contact with personnel.
- PCB-mounted LEDs are active-signal indicators and are not to be used for system troubleshooting.
- **ONLY** use the **X2** terminal(s) of the **CN2** connector as the return for the discrete 120 VAC inputs.
- **DO NOT** use the **CC** terminals of the **ACE G9-120V-PCB** as a return for the 120 VAC signal. The **CC** terminals are to be used as the return lines for the DC I/O signals of the **ACE G9-120V-PCB ONLY**.
- When connecting stranded wires to the terminals of the **ACE G9-120V-PCB** ensure that there are no stray or unsecured wire strands at the terminal connection.
- Shielded cables are recommended for control line cabling.
- **DO NOT** run the control cabling within the same conduit as the power cables.

- Electrical connections, wire types, and layouts that are external to the ASD shall adhere to all local and regional codes and standards.
- Ensure that the system is properly grounded and that all grounds are secure.
- This system is to be configured and operated by **Qualified Personnel** only.

Terminal Functions

The input and output terminals of the **ACE G9-120V-PCB** are used to control and monitor the functions of the ASD.

See the **Direct Access Information on pg. 79** for an in-depth description of the functionality and application-specific setup requirements of the input and output terminals.

Input Terminals

Analog Inputs

The analog input terminals include the **V/I**, **RX**, and the **RR** terminals.

The **V/I** terminal is an isolated input that accepts a 0–10 VDC input voltage or 0–20 mA input current as determined by the setting of **SW2**. Only **IIC** is to be used as the return for the **V/I** input terminal.

The **RX** terminal accepts a ± 10 VDC input voltage.

The **RR** terminal accepts a 0–10 VDC input voltage.

Either analog input may be used to control the speed or torque of the motor.

Discrete Inputs

The 120 VAC discrete inputs include the **F**, **R**, **I1**, **I2**, **I3**, **I4**, **I5**, and **I6** terminals. The discrete input terminals accept a 120 VAC discrete input signal that is used to activate the terminal and the assigned function.

Discrete terminals that have a function assigned are activated for the duration of the activation. Discrete terminals with no function assigned will not respond to an input signal.

Unused discrete terminals may be assigned any of the functions listed in **Table 7 on pg. 236**. Duplicate terminal assignments will be OR'd (either will be used to activate the assigned function).

Terminals labeled **X2** of **CN2** are the neutral return connections for the 120 VAC discrete inputs. No other terminals of the **ACE G9-120V-PCB** are to be used for the neutral return of the 120 VAC input.

CAUTION: DO NOT use the CC terminals of the ACE G9-120V-PCB as a return for the 120 VAC input signals.

Output Terminals

Analog Outputs

Analog outputs include the **AM**, **FM**, and **FP** output terminals. To use the output terminals a function must be assigned to the terminal.

The **AM** terminal must be further defined by parameter settings **F670**, **F671**, **F685**, and **F686**.

The **FM** terminal must be further defined by parameter settings **F005**, **F006**, **F681**, **F682**, and **F683**.

The **FP** terminal must be further defined by parameter settings **F676** and **F677**.

Discrete Outputs

The form-A output contacts of **OUT1** (A and C), **OUT2** (A and C), and the form-C output contacts **BRAKE** (A, B, and C) comprise the list of discrete output terminals. The output terminals are rated for 1 A/125 VAC.

All discrete output terminals are programmable and may be set to change state upon the occurrence of a user-selected event.

10 VDC

PP is a 10 VDC/10 mA max. output for customer use.

24 VDC

P24 is a 24 VDC/200 mA max. output for customer use.

Communications

CN4 is the 2-Wire or 4-Wire serial communications port as selected by the setting of **SW1**.

See Program ⇒ **Communications** for more information on the requirements for setting up the ASD for ASD-to-ASD communications and for ASD-to-host (i.e., PC, PLC, etc.) communications.

Alternate I/O Terminal Board

The ACE-tronics G9 ASD may also be controlled using the 24-Volt I/O Terminal Board (optional).

The 24-Volt I/O Terminal Board (P/N 3D658344_G901) control functions operate the same as the 120-Volt I/O Terminal Board with the exception that the discrete terminal activation is carried out using a **Sink** or **Source** method of terminal activation.

In the **Sink** operating mode the **CC** terminal is connected to a discrete input terminal to activate the assigned function — in the **Source** mode a 24 VDC signal is input to a discrete input terminal to activate the assigned function.

There are no software changes required to use the 24-Volt I/O Terminal Board.

ACE G9-120V-PCB Specifications/Layout

Table 2. Ratings Information.

Parameter	Rating
Isolation Voltage	850 V _{rms}
Input Voltage	0 – 120 VAC +10% — Hysteresis 60/90 ±10 VAC
Input Current (Terminal)	4.8 mA ±2.5 mA
Operating Temperature	14° to 104° F (-10° to 40° C)
Input Impedance	36 kΩ

Table 3. Connector Pin Assignments.

Connector	Pin Assignments									
	1	2	3	4	5	6	7	8	9	10
CN2	X2	F	R	I1	I2	I3	I4	I5	I6	X2
CN3	AM	FM	CC	V/I	IICC	FP				
CN5	BRAKE-A	BRAKE-B	BRAKE-C	OUT1-A	OUT1-C	OUT2-A	OUT2-C			
CN6	PP	CC	RR	RX	P24					

Figure 8. ACE G9-120V-PCB Layout.




Table 4. ACE G9-120V-PCB Default Assignment Terminal Names and Functions.

Terminal Name	Input/Output	Default Function (Also See Terminal Descriptions on pg. 26)	Circuit Config.
F	Discrete Input Apply 120 VAC to activate.	Forward Run Command — Multifunctional programmable discrete input.	Figure 10 on pg. 29.
R		Reverse Run Command — Multifunctional programmable discrete input.	
I1		Input 1 — Multifunctional programmable discrete input.	
I2		Input 2 — Multifunctional programmable discrete input.	
I3		Input 3 — Multifunctional programmable discrete input.	
I4		Input 4 — Multifunctional programmable discrete input.	
I5		Stop Limit-Switch Forward — Multifunctional programmable discrete input.	
I6		Stop Limit-Switch Reverse — Multifunctional programmable discrete input.	
OUT1	Switched Output	Brake Failure — Multifunctional programmable discrete output.	Figure 16 on pg. 29.
OUT2		Brake Release — Multifunctional programmable discrete output.	
BRAKE-A		BRAKE relay (N.O.).	Figure 19 on pg. 29.
BRAKE-B		BRAKE relay (N.C.).	
BRAKE-C		BRAKE relay (Common).	
RR	Analog Input	Multifunctional programmable analog input. (0.0 to 10 VDC input).	Figure 11 on pg. 29.
RX		Multifunctional programmable analog input (± 10 VDC input).	Figure 12 on pg. 29.
V/I (Select V or I via SW2)		V — Multifunctional programmable isolated analog voltage input (0 to 10 VDC input).	Figure 13 on pg. 29.
		Frequency Mode 2 (Default Setting) — I — Multifunctional programmable isolated analog current input (4 [0] to 20 mAADC input — 0 Hz to Maximum Frequency).	
AM	Analog Output	Output Current — <u>Voltage</u> output that is proportional to the output current of the ASD or to the magnitude of the function assigned to this terminal (see Table 8 on pg. 240 for assignment listing).	Figure 18 on pg. 29
FM		Output Frequency — <u>Current</u> or <u>Voltage</u> output that is proportional to the output frequency of the ASD or to the magnitude of the function assigned to this terminal (see Table 8 on pg. 240). Select Current or Voltage at F681.	
P24	DC Output	24 VDC output (200 mA max.).	Figure 14 on pg. 29.
PP		10.0 VDC/10 mA voltage source for the external use (e.g., potentiometer).	Figure 15 on pg. 29.
FP	Pulsed Output	Frequency Pulse — Multifunctional programmable output pulse train of a frequency based on the output frequency of the ASD (see Table 8 on pg. 240).	Figure 17 on pg. 29.
IICC	—	Return for the isolated V/I input terminal.	Do Not connect to Earth Gnd or to each other.
CC	—	Return for the AM , FM , RR , RX , P24 , and the PP analog terminals.	

Terminal Descriptions

The programmable terminal assignments may be accessed and changed from their default settings as mapped on [pg. 57](#) or via the **Direct Access** method: Program ⇒ Direct Access ⇒ **Applicable Parameter Number**. See the section titled [Program Mode Menu Navigation on pg. 57](#) for the applicable **Direct Access** parameter numbers.

For additional information on terminal assignments and default setting changes, see the sections titled [Default Setting Changes on pg. 40](#) and [Terminal on pg. 60](#).

See the section titled [Cable/Terminal/Torque Specifications on pg. 272](#) for information on the proper cable/terminal sizes and torque specifications when making **ACE G9-120V-PCB** connections.

F — The default setting for this terminal is **Forward** run command. The **F** input terminal is activated by applying 120 VAC to this terminal. This terminal may be programmed to any of the functions listed in [Table 7 on pg. 236](#) (see [F111](#)).

R — The default setting for this terminal is **Reverse** run command. The **R** input terminal is activated by applying 120 VAC to this terminal. This terminal may be programmed to any of the functions listed in [Table 7 on pg. 236](#) (see [F112](#)).

I1 — The default setting for this terminal is **Preset Speed 1** (see [Preset Speed 1 on pg. 87](#)). The **I1** input terminal is activated by applying 120 VAC to this terminal. This terminal may be programmed to any of the functions listed in [Table 7 on pg. 236](#) (see [F115](#)).

I2 — This input terminal may be programmed to any of the functions listed in [Table 7 on pg. 236](#) (see [F112](#)).

I3 — This input terminal may be programmed to any of the functions listed in [Table 7 on pg. 236](#) (see [F115](#)).

I4 — This input terminal may be programmed to any of the functions listed in [Table 7 on pg. 236](#) (see [F116](#)).

I5 — The default function assigned to this input terminal is **Stop Limit-Switch Forward**. Activating this terminal applies the **Stop** command and may be used to indicate the end-of-travel on any axis via a limit switch. The **Stop** command stopping method is selected at the [Limit-Switch Stopping Method](#) parameter. This input terminal may be programmed to any of the functions listed in [Table 7 on pg. 236](#) (see [F117](#)).

I6 — The default function assigned to this input terminal is **Stop Limit-Switch Reverse**. Activating this terminal applies the **Stop** command and may be used to indicate the end-of-travel on any axis via a limit switch. The **Stop** command stopping method is selected at the [Limit-Switch Stopping Method](#) parameter. This input terminal may be programmed to any of the functions listed in [Table 7 on pg. 236](#) (see [F118](#)).

RR — The default function to which this analog input terminal is assigned is [Frequency Mode 1](#) setting. The **RR** terminal accepts a 0 – 10 VDC input signal that is used to control the function to which this terminal is assigned. This input terminal may be programmed to control the speed or torque of the motor via an amplitude setting or regulate by setting a limit. The gain and bias of this terminal may be adjusted for application-specific suitability (see [F210 – F215](#)).

RX — The default function to which this analog input terminal is assigned is [Torque Command](#) setting. The **RX** terminal accepts a ±10 VDC input signal that is used to control the function to which this terminal is assigned. This input terminal may be programmed to raise or lower the speed or torque of the motor via an amplitude setting. This terminal may also be used to regulate the speed or torque of

a motor by setting a limit. The gain and bias of this terminal may be adjusted for application-specific suitability (see F216 – F221). See Figure 20 on pg. 30 for an electrical depiction of the **RX** terminal.

V/I — The **V/I** terminal has the dual function of being able to receive an input voltage or current. The function as a voltage input is to receive a 0 – 10 VDC input signal. The function as a current input is to receive a 0 – 20 mA input signal. Using either input type, the function is to control the 0.0 – Maximum Frequency output or the 0.0 to 250% torque output of the ASD. This is an isolated input terminal. This terminal may be programmed to control the speed or torque of the motor and cannot process both input types simultaneously. **SW2** must be set to **V** or **I** to receive a voltage or current, respectively (see Figure 8 on pg. 24). Terminal scaling is accomplished via F201 – F206. The gain and bias of this terminal may be adjusted for application-specific suitability (see F470 and F471).

P24 — +24 VDC at 200 mA power supply for customer use.

PP — The function of output **PP** is to provide a 10 VDC/10 mADC max. output that may be divided using a potentiometer or other transducer. The tapped voltage is applied to the **RR** input to provide manual control of the **RR** programmed function.

OUT1 — The default function assigned to this terminal is **Output Low Speed**. This output may be programmed to provide an indication (open or closed) that any one of the functions listed in Table 10 on pg. 242 has occurred or is active. This function may be used to signal external equipment or to activate the brake (see F130). The **OUT1** terminal is rated at 2 A/120 VAC and 2 A/30 VDC.

OUT2 — The default function assigned to this terminal is **ACC/DEC Complete**. This output may be programmed to provide an indication (open or closed) that any one of the functions listed in Table 10 on pg. 242 has occurred or is active. This function may be used to signal external equipment or to activate the brake (see F131). The **OUT2** terminal is rated at 2 A/120 VAC and 2 A/30 VDC.

FP — The default function of this output terminal is to output a series of pulses at a rate that is a function of the output frequency of the ASD (50 mA max. at 1.0 kHz to 43.3 kHz). As the output frequency of the ASD goes up so does the **FP** output pulse rate. This terminal may be programmed to provide an output pulse rate that is proportional to the magnitude of any of the user-selected items from Table 8 on pg. 240. For additional information on this terminal see F676 on pg. 188.

AM — This output terminal produces an output voltage that is proportional to the output frequency of the ASD or of the magnitude of the function assigned to this terminal. This terminal may be programmed to provide an output voltage that is proportional to the magnitude of any of the user-selected items from Table 8 on pg. 240. For additional information on this terminal see F670 on pg. 186.

FM — This output terminal produces an output current or voltage that is proportional to the output frequency of the ASD or of the magnitude of the function assigned to this terminal. This terminal may be programmed to provide an output current or voltage that is proportional to the magnitude of any of the user-selected items from Table 8 on pg. 240. For additional information on this terminal see F005 on pg. 81. The Voltage/Current output selection is performed at F681.


BRAKE-A — One of two normally open contacts that, under user-defined conditions, connect to **BRAKE-C**.

BRAKE-B — One of two normally closed contacts that, under user-defined conditions, connect to **BRAKE-C**.


BRAKE-C — **BRAKE-C** is the common leg of a single-pole double-throw form-C relay. The **BRAKE** relay is the **Fault Relay** by default, but may be programmed to any of the selections of Table 10 on pg. 242. For additional information on this terminal see F132 and Figure 9 on pg. 28.

Note: The **BRAKE-A**, **BRAKE-B**, and **BRAKE-C** contacts are rated at 2 A/120 VAC and 2 A/30 VDC.

Figure 9. BRAKE Switching Contacts.




I/O Circuit Configurations



Typical Connection Diagram

Figure 20. The ACE-tronics G9 ASD Typical Connection Diagram.

Note: When connecting multiple wires to any of ASD terminals, do not connect a solid wire and a stranded wire to the same terminal.



Note: The AM, FM, PP, RR, RX, and the P24 analog terminals are referenced to CC. The isolated V/I analog terminal referenced to IICC. F, R, I1, I2, I3, I4, I5, and I6 referenced to X2.

Startup and Test

Before turning on the ASD ensure that:

- **R/L1, S/L2, and T/L3** are connected to the 3-phase input power.
- **U/T1, V/T2, and W/T3** are connected to the motor.
- The 3-phase input voltage is within the specified tolerance.
- There are no shorts and all grounds are secure.
- All personnel are at a safe distance from the motor and the motor-driven equipment.

Electronic Operator Interface

The ACE-tronics G9 ASD **Electronic Operator Interface** (EOI) is comprised of an LED screen, an LCD screen, two LEDs, a rotary encoder, and five keys. These items are shown and described on [pg. 33](#).

EOI Operation

The **EOI** is the primary input/output device for the user. The **EOI** may be used to monitor system functions, input data into the system, perform diagnostics, and view performance data (e.g., motor frequency, bus voltage, torque, etc.).


The software used with the ASD is menu driven; thus, making it a select-and-click environment. The operating parameters of a motor may be selected and viewed or changed using the **EOI** (or via communications).

EOI Remote Mounting

The **EOI** may be mounted remotely using the optional **ASD-MTG-KIT9**. The kit contains all of the hardware required to mount the **EOI** of the 9-Series ASD remotely.

System operation and **EOI** operation while using the remotely-mounted **EOI** are the same as with the ASD-mounted configuration.

Figure 21. The ACE-tronics G9 ASD Electronic Operator Interface Features.



EOI Features

LED Screen — Displays the running frequency, active **Fault**, or active **Alarm** information.

Rotary Encoder — Used to access the ASD menu selections, change the value of a displayed parameter, and performs the **Enter** key function. Turn the **Rotary Encoder** either clockwise or counterclockwise to perform the **Up** or **Down** functions of the displayed menu selection. Press the **Rotary Encoder** to perform the **Enter** (select) function.

LCD Screen — Displays configuration information, performance data (e.g., output frequency, bus voltage, torque, etc.), diagnostic information, and **LED** screen information in expanded text.

Local/Remote Key — Toggles the system to and from the **Local** and **Remote** modes. The **Local/Remote** key is disabled while the **Fault** screen is displayed. The LED is on when the system is in the **Local Command** mode. The **Local** mode allows the **Command** and **Frequency** control functions to be carried out via the **EOI**.

The **Remote** mode enables the **Command** and **Frequency** control functions to be carried out via the **ACE G9-120V-PCB, RS485, Communication Card, Pulse Input**, or the settings of **F003/F004**. The selection may be made via **Program** ⇒ **Fundamental** ⇒ **Standard Mode Settings** ⇒ **Command Mode** or **Frequency Mode 1**, respectively.

The availability of **Local** mode control (Command and Frequency control) may be disabled via **Program** ⇒ **Utilities** ⇒ **Prohibition** ⇒ **Local/Remote Key Command Override** or **Local/Remote Key Frequency Override**. The availability of the **Local** mode of operation may be reinstated by changing this setting or performing a **Reset** (see **F007**).

ESC Key — Returns the system to the previous level of the menu, toggles between the **EOI Command** screen and the **Frequency Command** screen, or cancels changes made to a field if pressed while still in the reverse video mode (dark background/light text). The three functions are menu-specific.

Run Key — Issues the **Run** command while in the **Local** mode. The **Run** key LED illuminates green while stopped or red while running to alert personnel.

Mode Key — Provides a means to access the three root menus. Pressing the **Mode** key repeatedly loops the system through the three root menus (see [Figure 29 on pg. 52](#)). While looping through the root menus, the **Program** menu will display the root menu screen or the **Program** sub-menu item being accessed prior to pressing the **Mode** key.

Stop-Reset Key — This key has three functions.

1. Issues the **Off** command (decelerates to **Stop** at the programmed rate) if pressed once while in the **Local** mode in accordance with the setting of **F721**.
2. Initiates an **Emergency Off Fault** if pressed twice quickly from the **Local** or **Remote** modes. The **Emergency Off** function terminates the ASD output and stops the motor in accordance with the setting of **F603**.
3. Resets active **Faults** if pressed twice quickly. The source of the **Faults** must be determined and corrected before normal ASD operation can resume.

LED/LCD Screen

The LED screen is used to display the output frequency, active alarms and active faults, or Off.

If there are no active alarms or faults, the output frequency is displayed.

During an active alarm, the display toggles to and from the running frequency and the active alarm.

During an active fault, the fault is displayed.

Loss of the **ST** terminal activation (if so configured; see **F110**) flashes **Off**.

LED Character/Font Information

Characters displayed on the LED screen will be of the seven-segment format. Not all alpha-numeric characters are used.

Shown to the right are the seven-segment characters used on the LED screen along with the same characters as they are displayed on the LCD screen.

LCD Character Information

All alpha-numeric characters are used.

LED/LCD Screen Information			
LED	LCD	LED	LCD
Ⓐ	A	1	1
Ⓑ	b	2	2
Ⓒ	C	3	3
Ⓓ	d	4	4
Ⓔ	E	5	5
Ⓕ	F	6	6
Ⓖ	G	7	7
Ⓗ	H	8	8
Ⓘ	I	9	9
Ⓙ	J	0	0
Ⓛ	L		
Ⓜ	M		
Ⓝ	n		
Ⓞ	O		
Ⓟ	P		
Ⓠ	q		
Ⓡ	r		
Ⓢ	S		
Ⓣ	t		
Ⓤ	U		
Ⓥ	v		
Ⓨ	y		
-	-		

LCD Screen

The **LCD** screen is the primary user input/output information center. Parameter settings may be viewed or changed using the LCD screen module of the **EOI**. To view or change a parameter setting using the LCD screen, press the **Mode** key until the **Program** menu is displayed. Turn the **Rotary Encoder** until the desired **Primary Menu** item (see pg. 57) is within the cursor block. Press the **Rotary Encoder** to select the item from the **Primary Menu** (repeat the press-to-select function for sub-menu items).

See the section titled **Default Setting Changes** on pg. 40 for more information on changing parameter settings.

Upon reaching the desired parameter selection the current setting may be viewed, or selected and changed by pressing the **Rotary Encoder** — the setting will take on the reverse video format (dark background/light text). Turn the **Rotary Encoder** to change the parameter setting. Press the **ESC** key while the new parameter setting is in the reverse video mode to exit the selection without saving the change or press the **Rotary Encoder** while the parameter setting is in the reverse video mode to accept the new setting.

Repeated **ESC** key entries at any time takes the menu back one level each time the **ESC** key is pressed until the **Frequency Command** screen is reached. Further **ESC** entries will toggle the system to and from the **Frequency Command** screen and the **EOI Command** menu.

Note: Changes carried out from the **EOI Command** screen will be effective for **EOI**-controlled **ASD** operation only. See the section titled **EOI Command Mode** on pg. 53 for additional information on **EOI Command Mode** operations.

Primary Menus of the LCD Screen

The three primary LCD screens are displayed while accessing the associated operating modes: the **Frequency Command**, **Monitor**, and **Program Menu** screens.

Figure 22. **Frequency Command Screen.**




Figure 23. **Monitor Screen** (see pg. 54 for more on the Monitor Screen).





Figure 24. **Program Menu Screen** (see pg. 57 for more on the Program Menu Screen).



LED/LCD Screen Installation Note

When installing the LED/LCD display module of the **EOI** ensure that the left side of the display is inserted first with the top and bottom catches (see Phillips screws at underside of display) securely in place. This ensures the proper alignment and electrical connection of the CNX connector of the **LED/LCD** display module PCB. Gently hold the display in place while securing the Phillips mounting screw.

If improperly seated, the periphery of the **LED/LCD** display module will not be flush with the front panel surface and the unit will not function properly.

EOI Remote Mounting

The ASD may be controlled from a remotely-mounted **EOI**. For safety and application-specific reasons, some ASD installations will warrant that the operator not be in the vicinity during operation or that the **EOI** not be attached to the ASD housing. The **EOI** may be mounted either with or without the optional **Remote Mounting Kit** (P/N ASD-MTG-KIT). The ease of installation is enhanced by the **Remote Mounting Kit** (P/N 58333) which allows for **EOI** placement and easier cable routing.

Remote mounting will also allow for multiple **EOI** mountings at one location if controlling and monitoring several ASDs from a central location is required.

The **EOI** can operate up to nine feet away from the ASD. A **EOI** extender cable is required for remote mounting. The **EOI** extender cable is available in a nine-foot length and may be ordered through the ACE World Companies Customer Support Center.

The optional dust cover (P/N ASD-BPC) may be used to cover the front panel opening of the ASD housing after removing the **EOI**.

Remote EOI Required Hardware

EOI Mounting Hardware

- EOI Remote-Mount Housing — P/N 58333 (included with 230-volt 40-HP and above; and with the 460-volt 75 HP and above)
- 6-32 x 5/16" Pan Head Screw — P/N 50595 (4 ea.)
- #6 Split-Lock Washer — P/N 01884 (4 ea.)
- #6 Flat Washer — P/N 01885 (4 ea.)

Bezel Plate Mounting Hardware

- Bezel Plate — P/N 52291
- 10-32 Hex Nut — P/N 01922 (4 ea.)
- #10 Split-Lock Washer — P/N 01923 (4 ea.)
- #10 Flat Washer — P/N 01924 (4 ea.)
- Dust Cover — P/N ASD-BPC (Optional)

Extender Cable

- ASD-CAB10F: Cable, 9 ft.

EOI Installation Precautions

Install the unit securely in a well ventilated area that is out of direct sunlight using the four mounting holes at the rear of the **EOI**. The ambient temperature rating for the **EOI** is 14° to 104° F (-10° to 40° C).

- Select a mounting location that is easily accessible by the user.
- Avoid installation in areas where vibration, heat, humidity, dust, metal particles, or high levels of electrical noise (EMI) are present.
- Do not install the **EOI** where it may be exposed to flammable chemicals or gases, water, solvents, or other fluids.
- Turn on the power only after securing the front cover of the ASD.


EOI Remote Mounting w/o the ASD-MTG-KIT

Note: See *Figure 25* for the dimensions and the item locations referenced in steps 1 through 5.

1. At the **EOI** mounting location, mark the 3.80" by 3.56" hole and the four 7/32" screw holes.
2. Cut the 3.80" by 3.56" rectangular hole.
3. Drill the four 7/32" screw holes.
4. Attach and secure the **EOI** to the front side of the mounting location using the four 6-32 x 5/16" pan head screws, the #6 split lock washers, and the #6 flat washers.
5. Connect the extension cable.

EOI Mounting Dimensions

Figure 25. EOI Mounting Dimensions.




EOI Remote Mounting Using the ASD-MTG-KIT

Note: See [Figure 26](#) for the dimensions and the item locations referenced in steps 1 through 6.

1. At the **EOI** mounting location, mark the 4.60" by 4.50" hole and the four 11/32" screw holes.
2. Cut the 4.60" by 4.50" rectangular hole.
3. Drill the four 11/32" holes for the Bezel Plate mount.
4. Attach and secure the Bezel Plate to the front side of the mounting location using the four 10-32 hex nuts, #10 split lock washers, and the #10 flat washers.
5. Attach and secure the **EOI** to the front side of the Bezel Plate using the four 6-32 x 5/16" pan head screws, #6 split lock washers, and the #6 flat washers.
6. Connect the extension cable.

EOI ASD-MTG-KIT Mounting Dimensions

Figure 26. EOI Bezel Plate Mounting Dimensions.



System Operation


Operation (Local)

Note: See the section titled *EOI Features* on pg. 33 for information on **Remote** operation.

To turn the motor on perform the following:

1. Press the **Mode** key until the **Frequency Command** screen is displayed.
2. Press the **Local/Remote** key to enter the **Local** mode (green **Local** LED illuminates).
3. Turn the **Rotary Encoder** clockwise until the desired **Frequency Command** value is displayed in the **SET** field of the LCD screen.
4. Press the **Run** key and the motor runs at the **Frequency Command** value.

Frequency Command Screen

0 ————— ————— ————— 100%	
SET:	0.00 Hz 
DC Voltage:	0.00%
Output Current:	0.00%
F R I1 I2 I3 I4 I5 I6 OUT1 OUT2 BRAKE	

Note: The speed of the motor may be changed while the motor is running by using the **Rotary Encoder** to change the **Frequency Command** value.

5. Press the **Stop-Reset** key to stop the motor.

Default Setting Changes

To change a default parameter setting go to the root level of the **Program** menu. Turn the **Rotary Encoder** until the desired parameter group is within the cursor block. Press the **Rotary Encoder** to select an item or to access a subgroup (repeat if required until reaching the parameter to be changed).

Press the **Rotary Encoder** to enter the **Edit** mode and the value/setting takes on the reverse video format (dark background/light text). Turn the **Rotary Encoder** to change the parameter value/setting.

Press the **Rotary Encoder** while the parameter setting is in the reverse video mode to accept the new setting or press the **ESC** key while the new parameter setting is in the reverse video mode to exit the menu without saving the change.

For a complete listing of the **Program** mode menu selections, see the section titled [Program Mode Menu Navigation](#) on pg. 57. **Program** menu items are listed and mapped for convenience. The **Direct Access Numbers** are listed where applicable.

The default settings may also be changed by entering the **Parameter Number** of the setting to be changed at the **Direct Access** menu (Program ⇒ Direct Access ⇒ *Applicable Parameter Number*). A listing of the **Direct Access Numbers** and a description of the associated parameter may be found in the section titled [Direct Access Information](#) on pg. 79.

A listing of all parameters that have been changed from the default setting may be viewed sequentially by accessing the **Changed From Default** screen (Program ⇒ Utilities ⇒ Changed From Default).

The **Changed From Default** feature allows the user to quickly access the parameters that are different from the factory default settings or the post-reset settings. Once the **Changed From Default** screen is displayed, the system scrolls through all of the system parameters automatically and halts once reaching a changed parameter.

Once stopped at a changed parameter, the **Rotary Encoder** may be clicked once clockwise to continue scrolling forward or clicked once counterclockwise to begin scrolling in reverse. With each click of the **Rotary Encoder** from a stop, the system scrolls through the parameters and stops at the next parameter that has been changed.

Press the **Rotary Encoder** while stopped at a changed parameter to display the settings of the changed parameter. Press the **Rotary Encoder** to enter the **Edit** mode — the parameter value/setting takes on the reverse video format (dark background/light text). Turn the **Rotary Encoder** to change the parameter setting.


Press the **ESC** key while the setting is in the reverse video format to exit the **Edit** mode without saving the change and to resume the **Changed From Default** search. Or press the **Rotary Encoder** while the setting is in the reverse video format to save the change. Press **ESC** to return to the **Changed From Default** search.

Pressing **ESC** while the system is performing a **Changed From Default** search terminates the search. Pressing **ESC** when finished searching (or halted at a changed parameter) takes the menu back one level.

Note: *Communications setting changes will require that the ASD power be removed and then re-applied for the changes to take affect.*

Note: *Parameter F201 was changed to create the example shown in Figure 27.*

Figure 27. Changed From Default Screen.



Save User Settings

A profile of an existing setup may be saved and re-applied when required by using the **Save User Setup** feature. This function is carried out via Program ⇒ Utilities ⇒ Type Reset ⇒ **Save User Settings**.

With the initial setup saved, troubleshooting and diagnostics may be performed and the starting setup may be re-applied when finished via Program ⇒ Utilities ⇒ Type Reset ⇒ **Restore User Settings**.

Note: *EOI settings are not stored using the **Save User Settings** or using the **Restore User Settings** features (i.e., contrast setting, voltage/current units, display gradient characteristics, etc.).*

Startup Wizard Requirements



In the event of a power loss while programming the system using the Startup Wizard the parameter entries completed before the power loss will be retained and used by the system upon system startup. Confirm that all settings are as required for the application before system startup.

The **Startup Wizard** is used to quickly setup the commonly used parameters of the ACE-tronics G9 ASD — it queries the user for information on **Motion Control** settings and on the input and output signal parameters. The ASD may also be setup by directly accessing each of the control settings via the **Program** menu (see [pg. 57](#)) or the **Direct Access Numbers** (see [pg. 79](#)).

To run the **Startup Wizard**, go to the **Program** menu and click **Startup Wizard**.

At the subsequent screen either click **Exit** to end the **Startup Wizard** or click **Next** to continue with the wizard.

Click **Next** at each parameter screen to accept the setting and to go to the next screen.


Upon completion of the **Startup Wizard** click **Exit** to return the system to the [Frequency Command Screen](#).

***Note:** The **Startup Wizard** is disabled during an active **Run** command. Remove the **Run** command (deactivate *F* and/or *R*) to enable the **Startup Wizard** function.*

The **Startup Wizard** queries the user for the parameter settings listed below.

- [Startup Wizard Introduction Screen](#)
- [Motor Capacity](#)
- [Motor RPM](#)
- [Motor Current](#)
- [ASD Control Configuration](#)
 - [Standard Hoist Control](#)
 - [Standard Traverse Control](#)
 - [Custom](#)
 - [Hoist](#)
 - [Traverse](#)
- [Autotune Enable](#)
- [Speed Control \(F986\)](#)
- [Accel/Decel Times](#)
- [Special Functions](#)

Figure 28. Startup Wizard Flow Chart.



See F986 on pg. 231 for specifics on the setup and functional descriptions of the associated discrete input terminals for a given **Speed Control** mode selection.

Startup Wizard Introduction Screen

The introduction screen provides an opportunity to exit the wizard before launching. Once started, the wizard must be completed to exit the program.

Select **Exit** to terminate the wizard and configure manually. Go to the **Program** screen and select the parameters to be configured.

To continue with the wizard click **Next**.

ACE Wizard		
Back	Next >	Exit
Select Exit to manually configure. Otherwise the Wizard must complete once started.		

Motor Capacity

This parameter is used to set the (Nameplate) rated capacity of the motor being used.

ACE Wizard		
Back	Next >	Exit
[F405] What is the motor rated capacity (nameplate)?		
1.00 HP		

Motor RPM

This parameter is used to set the (Nameplate) RPM of the motor being used.

ACE Wizard		
Back	Next >	Exit
[F407] What is the rated RPM (nameplate) of the motor?		
1690 RPM		

Motor Current

This parameter is used to set the (Nameplate) rated current of the motor being used.

ACE Wizard		
Back	Next >	Exit
[F406] What is the MOTOR rated current (nameplate)?		
3.4 A		

ASD Control Configuration

This parameter is used to set the operating mode of the ASD. Selections are **Standard Hoist Control**, **Standard Traverse Control**, and **Custom Control**.

ACE Wizard		
Back	Next >	Exit
Select control configuration:		
Standard Hoist Control		

Select **Standard Hoist Control** to use the ASD for **Hoist Control** and to place the following settings in effect:

- Closed-Loop Vector Control.
- PG Feedback = On.
- Torque Proving = Enabled.
- 1024 PG Pulse/Rotation.
- PG Encoder Phase = 2.
- PG Disconnection Detection = Enabled.
- Control = 2-Step Variable.
- I2 – I6 = Unassigned.
- OUT1 = Brake Failure (154), N.O.
- OUT2 = Brake Release (68), N.O.
- BRAKE = Brake Release (68), N.O.
- Express Stop = Disabled.
- Plugging = Disabled.
- Accel Time 1 = 3 Seconds.
- Decel Time 1 = 1.5 Seconds.

Next = Go to [Autotune Enable on pg. 46](#).

Select **Standard Traverse Control** to use the ASD for **Traverse Control** and to place the following settings in effect:

- Constant Torque Control.
- PG Feedback = Off.
- Torque Proving = Disabled.
- Control = 2-Step Variable.
- I2 – I6 = Unassigned.
- OUT1 = Fault All (10), N.C.
- OUT2 = Always Off (254), N.O.
- BRAKE = Brake Release (68), N.O.
- Express Stop = Disabled.
- Plugging = Disabled.
- Accel Time 1 = 6 Seconds.
- Decel Time 1 = 6 Seconds.

Next = Go to [Autotune Enable on pg. 46](#).

Select **Custom** to use the ASD for application-specific **Hoist Control** or **Traverse Control** and to place the following associated settings in effect:

Select **Yes** or **No** at **Encoder Being Used?**

Hoist Control ————— **Next** →

- Torque Proving = Enabled.
- OUT1 = Brake Failure (154), N.O.
- OUT2 = Brake Release (68), N.O.
- BRAKE = Brake Release (68), N.O.

Traverse Control

- Constant Torque.
- Torque Proving = Disabled.
- OUT1 = Fault All (10), N.C.
- OUT2 = Always Off (254), N.O.
- BRAKE = Brake Release (68), N.O.
- Express Stop = Disabled.

Encoder Being Used?	No	Yes
Speed Sense	Sensorless Vector	Closed Loop
PG Feedback	Off	On
Autotune	Enabled	Enabled
Pulses/Rotation	N/A	1024
Encoder Phases	N/A	2
Disconnect Detection	N/A	Enabled
Go to Speed Control (F986) on pg. 46.		

Autotune Enable

This parameter is used to enable/disable the **Autotune** function.

Autotune 1 = Autotune **Disabled** or **Enabled**
Autotune on Run Command.

ACE Wizard		
Back	Next >	Exit
(F400) Autotune on Run command selection:		
Autotune Disabled		

Speed Control (F986)

2-Step Variable — **F, R,** and **I1.**

3-Step Variable — **F, R, I3** and **I4.**

5-Speed — **F, R,** and **Preset Speeds 1 – 4.**

2-Speed and 3-Speed — Same as **5-Speed** using
only the required number of **Preset Speed** settings.

Unipolar Analog (**RR**).

Bi-Polar Analog (**RX**).

ACE Wizard		
Back	Next >	Exit
(F986) What kind of speed control do you need?		
> 2-Step Variable		

Accel/Decel Times

Accel Time 1 = 10.0 S

Decel Time 1 = 10.0 S

ACE Wizard		
Back	Next >	Exit
(F010) Set deceleration time:		
> 10.0 seconds		

Special Functions

Enable **Slow-Speed Limit-Switch** — Sets **I3** and **I4** to **Slow-Speed Limit Switch Forward** and **Slow-Speed Limit Switch Reverse**, respectively.

Enable **Stop Limit-Switch** for **F** and **R** — Sets **I5** and **I6** to **Stop Limit-Switch Forward** and **Stop Limit-Switch Reverse**, respectively.

Enable Express Speed (**F328**).

Enable (Plugging **F494**).

Creep Speed LL (**F492**) — Sets **I4** to **Creep Speed 1 Command**.

Enable **Super Creep** — Sets **I4** to **Super Creep**.

Enable Slack Rope Detection (**F867**).

Speed Reference — Sets **I4** to **Frequency Reference Priority Switching**.

Enable Autotune On Run Command (**F400**).

Note: *Enabling any of the above functions will overwrite the previous function assigned to the associated discrete input terminal.*

Command and Frequency Mode Control

Command control includes instructions such as **Stop, Run, Jog**, etc. The source of the **Command** signal must be established for normal operation.

Frequency commands control the output speed of the ASD. The source of the frequency control signal must be established for normal operation.

The source of the command control and frequency control may be either internal or external. Once the source signal is selected for either function, the system may be configured to use the selected signal all of the time or switch under user-defined conditions.

Command and **Frequency** control may be carried out using any one of several control methods (signal sources) or combinations thereof. In the event that multiple control commands are received, the signal sources are assigned priority levels. The primary control method for **Command** and **Frequency** control uses the settings of **F003** and **F004**, respectively.

Command Control (F003)

The **Command Mode** selection of **F003** establishes the primary source of the command input for the ASD. However, the **Override** feature may supersede the **F003** setting as indicated in [Table 5](#).

[Table 5 on pg. 49](#) shows the hierarchy of the control sources managed by the **Override** function. The level of the control item of the hierarchy is listed from left to right, most to least, respectively. As indicated in the table, the **Override** setting may supersede the **F003** setting.

01:06
Standard Mode Selection
(F003) Command Mode Selection
Terminal Block

Placing the **EOI** in the **Local** mode selects the **RS485 2-Wire** as the **Command Mode** control source. **Local** mode operation may be superseded by other **Override** settings.

Example: With the **EOI** set to **Local**, **Communication Board** input or **RS485 4-Wire** input will supersede **EOI** control input.

The remaining control sources may be placed into the **Override** mode using communications.

The source of the **Command** control signal may be selected by:

- The **F003** setting,
- Placing an item from the **Command** signal source selections in the **Override** mode via communications, or
- Placing the **EOI** in the **Local** mode (places only the RS485 [2-Wire] or the RS485 [4-Wire] in the **Override** mode).

Possible **Command** signal source selections include the following:

- Terminal Board (default),
- EOI Keypad,
- RS485,
- Communication Option Board, or
- **F003** setting (is used if no signal sources are in the **Override** mode).

Note: *The **Terminal Board** is placed in the **Override** mode for **Command** functions by assigning a discrete terminal to **Command Terminal Board Priority** and activating the terminal by applying 120 VAC. Once activated (Run command required), the **Terminal Board** settings will be used for **Override Command** control (F, R, Preset Speeds, etc.).*

Frequency Control (F004)

The **Frequency Mode 1** (or the Frequency Mode 2) setting establishes the user-selected source of the frequency-control input for the ASD. The signal source selected here is used for frequency control unless the **Reference Priority Selection** parameter is configured to switch this setting automatically (see F200) or if the **Override** feature is enabled.

Table 5 on pg. 49 shows the hierarchy of the control sources managed by the **Override** function. The level of the control item of the hierarchy is listed from left to right, most to least, respectively. As indicated in the table, the **Override** setting may supersede the selection at F004.

Placing the **EOI** in the **Local** mode selects the **RS485 2-Wire** as the **Frequency Mode 1** control source. **Local** mode operation may be superseded by other **Override** settings.

Example: With the **EOI** set to **Local**, the **Communication Board** input or the **RS485 4-Wire** input will supersede **EOI** control input.

The remaining control sources may be placed into the **Override** mode using communications.

The source of the **Frequency** control signal may be selected by:

- The F004 setting,
- Placing an item from the **Frequency** control source selections in the **Override** mode via communications, or
- Placing the **EOI** in the **Local** mode (places only the RS485 [2-Wire] in the Override mode).

Possible **Frequency** control source selections include the following:

- Communication Board,
- RS485,
- EOI Keypad,
- Terminal Board (the default setting), or
- F004 setting (used if no other items are in the Override mode).

Note: The **Terminal Board** is placed in the **Override** mode for frequency control functions by assigning a discrete terminal to **V/I Terminal Priority** and activating the terminal by applying 120 VAC to the terminal. Once the discrete terminal is activated, **V/I** is used as the **Terminal Board Override** control item.

Command and Frequency Control Selections

The user may select only one **Command** source and only one source for **Frequency** control. The default settings for **Command** and **Frequency** control are **Terminal Board** and **RR**, respectively.

The ASD has a command register for each item listed as a **Command** or **Frequency** source. The registers store the **Override** setting for each control source. The registers are continuously scanned to determine if any of the listed items are in the **Override** mode.

For each scan cycle, the command registers of the control sources are scanned for the **Override** setting in the order that they are listed in Table 5. The first item of the **Command** section and the first item of the **Frequency** section detected as being in the **Override** mode will be used for **Command** and **Frequency**

02:06
Standard Mode Selection
(F004) Frequency Mode 1
RR

control, respectively. If no items are detected as being in the **Override** mode, the settings of **F003** and **F004** will be used for **Command** and **Frequency** control, respectively.

Any or all of the **Command** and **Frequency** control input sources may be placed in the **Override** mode.

Placing the ASD in the **Local** mode (Local/Remote LED on) via the **EOI** places the **RS485 2-Wire** control selection in the **Override** mode for **Command** and **Frequency** input (see the section titled **Override Operation** on pg. 49 for the proper setting). The **Local/Remote** control **Override** feature for **Command** and **Frequency** (or either) may be enabled/disabled at Program ⇒ Utilities ⇒ Prohibition ⇒ **Local/Remote** key (Command or Frequency) **Override**.

Communications may be used to place the remaining **Command** and eligible **Frequency** control input sources in the **Override** mode. Once placed in the **Override** mode this setting is valid until it is cancelled, the power supply is turned off, or the ASD is reset.

Override Operation

The signal sources of **Table 5** are scanned from left to right in the order that they are listed to determine which input sources are in the **Override** mode (active Command or Frequency command present). The first item detected as having the **Override** function turned on is the selection that is used for **Command** or **Frequency** control input.

The **Override** control setting supersedes the setting of the **Command** mode setting (**F003**) and the **Frequency** mode setting (**F004**). However, the **F003** and **F004** settings will be used in the event that the register scan returns the condition that none of the listed items have the **Override** feature turned on or a discrete input terminal is set to **Serial/Local Switch** and is activated.

Command and Frequency-Control Override Hierarchy

Table 5 lists the input conditions and the resulting output control source selections for **Command** and **Frequency** control **Override** operation.

The ASD software reads the memory locations of the listed control sources from the left to the right.

The first item to be read that has the **Override** feature turned on will be used for **Command** or **Frequency** control.

Table 5. Command and Frequency Control Hierarchy.

1	2	3	4	5	6	Priority Level
Forced F003/ F004 by I/P Terminal (Assign to Serial/ Local Switch)	Comm. Board	RS485	EOI Keypad	Terminal Board (Binary/BCD Input)	F003/F004	Command/ Frequency Mode
1	X	X	X	X	X	F003/F004 Setting
0	1	X	X	X	X	Communication Board
0	0	1	X	X	X	RS485
0	0	0	1	X	X	EOI Keypad
0	0	0	0	1	X	Terminal Board
0	0	0	0	0	F003/F004 Setting	F003/F004 Setting

Note: 1 = Override feature is turned on for that control input source; 0 = Override Off; X = Don't Care.

Command Control Selections

The following is a listing with descriptions of the Command Mode (F003) selections (Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ **Command Mode Selection**).

Settings:

0 — Terminal Board

Allows for **Command** control input via the **Terminal Board**.

1 — Not Used

Unused.

2 — EOI Keypad

Used for EOI command control.

3 — RS485

Used to transfer commands to the ASD via **RS485 4-Wire**.

4 — Communication Option Board

Use this setting if using the optional **Communication Board** for command control.

01:06
Standard Mode Selection
(F003) Command Mode Selection
Terminal Block ← (Default)

Frequency Control Selections

The following is a listing with descriptions of the **Frequency Mode (F004)** selections (Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1).

Settings:

1 — V/I

Used when a 0 to 10 VDC analog input or a 0 – 20 mA DC current input is used as the frequency control input. Only one input signal type may be used at a time. Set **SW2** to the desired signal type.

2 — RR

Used for a 0 to 10 VDC analog input signal.

3 — RX

Used for a ±10 VDC analog input signal.

4 — Not Used

Unused.

5 — EOI Keypad

Used for EOI frequency control.

6 — RS485

Used to transfer speed commands to the ASD via **RS485 4-Wire**.

02:06
Standard Mode Selection
(F004) Frequency Mode 1
RR ← (Default)

7 — Communication Option Board

Use this setting if using the optional **Communication Board** for frequency control.

8 — RX2 Option (AI1)

Used for a ± 10 VDC analog input signal.

9 — Option V/I

Allows for the use of the optional voltage/current frequency-control interface.

10 — UP/DOWN Frequency

A discrete terminal may be configured to increase or decrease the speed of the motor by momentarily activating the terminal by applying 120 VAC to the terminal. See [F264 on pg. 131](#) for additional information on this feature.

11 — Pulse Input Option

Used to allow the system to use a pulsed input for frequency control. See [PG Input Point 1 Setting on pg. 125](#) for additional information on this feature.

12 — Pulse Input (Motor CPU)

Used to allow the system to use a pulsed input for frequency control. See [PG Input Point 1 Setting on pg. 125](#) for additional information on this feature.

13 — Binary/BCD Input Option

Allows for discrete terminal to be used for frequency-control input.

System Configuration and Menu Options


Root Menus

The **Mode** key accesses the three primary modes of the ACE-tronics G9 ASD: the **Frequency Command** mode, the **Monitor** mode, and the **Program** mode. From either mode, press the **Mode** key to loop through to the other two modes (see Figure 29). While in the **Frequency Command** mode, pressing the **ESC** key toggles the menu to and from the **EOI Command** mode and the **Frequency Command** mode.

The **Alarm** or **Fault** information will be displayed in the event of an active **Alarm** or **Fault**. **Alarm** text will be displayed on the **Frequency Command** screen and on the LED screen when active. **Fault** information will be displayed via the **Fault** screen. See [Alarms and Trips on pg. 248](#) for more information on **Alarms** and **Trips**.

Note: EOI Command mode changes are effective for EOI control Only.

Figure 29. ACE-tronics G9 ASD Root Menu Navigation.



Frequency Command Mode

Frequency Setting

While operating in the **Local** mode (Local LED is illuminated on the front panel), the running frequency of the motor may be set from the **Frequency Command** screen. Using the **Rotary Encoder**, enter the **Frequency Command** value, provide a **Run** command (F and/or R), and then press the **Run** key. The motor will run at the **Frequency Command** speed and may be changed while running. See [Figure 22. on pg. 35](#) and [Operation \(Local\) on pg. 40](#) for more information on the **Frequency Command** mode.

EOI Command Mode

The **EOI Command** mode is accessed by pressing the **ESC** key from the **Frequency Command** screen.

The control settings of the **EOI Command** menu are effective for **EOI** control only.

The **EOI Command** mode provides quick access to the following menu parameters:

Direction — **Forward** or **Reverse**.

Stop Pattern — The **Decel Stop** or **Coast Stop** settings determines the method used to stop the motor when using the **Stop-Reset** key of the **EOI**. The **Decel Stop** setting enables the **Dynamic Braking** system setup at [F304](#) or the **DC Injection Braking** system setup at [F250](#), [F251](#), and [F252](#). The **Coast Stop** setting allows the motor to stop at the rate allowed by the inertia of the load.

Note: The **Stop Pattern** setting has no effect on the **Emergency Off** settings of [F603](#).

V/f Group — One of four **V/f** profiles may be selected and run. Each **V/f** profile is comprised of 4 user settings: **Base Frequency**, **Base Frequency Voltage**, **Manual Torque Boost**, and **Electronic Thermal Protection**. Expanded descriptions of these parameters may be found in the section titled [Direct Access Information on pg. 79](#).

Accel/Decel Group — One of four **Accel/Decel** profiles may be selected and run. Each of the **Accel/Decel** profiles is comprised of three user settings: **Acceleration**, **Deceleration**, and **Pattern**. Expanded descriptions of these parameters may be found in the section titled [Direct Access Information on pg. 79](#).

Feedback in Panel Mode — Enables or disables the **PID** feedback function.

Torque Limit Group — Used to select one of four preset positive torque limits to apply to the active motor (of a multiple motor configuration). The settings of profiles 1 – 4 may be setup at [F441](#), [F444](#), [F446](#), and [F448](#), respectively.

Monitor Mode

The **Monitor** mode allows the user to monitor motor performance variables, control settings, and configuration data during motor operation. The items that are viewable from this mode are listed and described below.

Note: The **Monitor** mode is a read-only mode. The settings **cannot** be changed from the **Monitor** mode. For information on how to change the values, see the section titled *Default Setting Changes on pg. 40*.

Note: Any two of the Underlined monitored items may be selected for display at the **Frequency Command** screen while running via Program ⇒ Utilities ⇒ *Main Monitor Selections* (see pg. 56 for information on using the *Main Monitor Selections* feature).

Note: The **F701** setting will determine if the **Current** and **Voltage** values displayed appear as **A (Amps)** and **V (Voltage)**, or if the value is shown as a **% (percentage)** of the **ASD** rating.

Frequency at Trip — Displays the at-trip frequency.

Frequency Reference — Displays the **Frequency Setpoint**.

Output Current — Displays the **Output Current** as a percentage of the rated capacity of the ASD.

DC (Bus) Voltage — Displays the **Bus Voltage** as a percentage of the rated capacity of the ASD.

Output Voltage — Displays the **Output Voltage** as a percentage of the rated capacity of the ASD.

AM Output — Displays the **AM** output terminal value for the function assigned to the **AM** terminal.

FM Output — Displays the **FM** output terminal value for the function assigned to the **FM** terminal.

Motor OL (Overload) Real — Displays the real-time **Motor Overload** value as a percentage of the rated capacity of the motor.

Motor OL (Overload) Trip — Displays the **Motor Overload Trip** value as a percentage of the rated capacity of the motor.

Motor Load — Displays the real-time **Motor Load** as a percentage of the rated capacity of the motor.

ASD OL (Overload) Real — Displays the real-time **ASD Overload** as a percentage of the rated capacity of the ASD.

ASD OL (Overload) Trip — Displays the **ASD Overload Trip** value as a percentage of the rated capacity of the ASD.

ASD Load — Displays the **ASD Load** as a percentage of the rated capacity of the ASD.

Run Time — Displays the **Cumulative Run Time** in hours. Set to zero by selecting **Clear Run Timer** at parameter **F007**.

Compensation Frequency — Displays the **Output Frequency** after the application of the slip compensation correction value (Post Compensation Frequency).

DBR OL (Overload) Real — Displays the real-time **DBR Overload** value as a percentage of the **Dynamic Braking Resistor** capacity.

DBR OL (Overload) Trip — Displays the **DBR Overload Trip** value as a percentage of the **Dynamic Braking Resistor** capacity.

DBR Load — Displays the **DBR Load** as a percentage of the **Dynamic Braking Resistor** capacity.

Feedback (Inst) — Provides a status of the **Real Time Feedback** in Hz.

Feedback (1 Second) — Provides a status of the **1-Second Averaging** feedback in Hz.

Torque — Displays the **Output Torque** as a percentage of the rated capacity of the ASD.

Torque Reference — Displays the **Torque Reference** as a percentage of the maximum torque available.

Torque Current — Displays the torque-producing current value.

Excitation Current — Displays the current value required to produce the excitation field.

PID Feedback — Provides a status of the **PID Real Time Feedback** in Hz.

Input Power — Displays the **Input Power** in Kilowatts (kW).

Output Power — Displays the **Output Power** in Kilowatts (kW).

Pattern Group Number — Displays the active **Pattern Run Group Number**.

Pattern Cycle Number — Displays the cycle number of the active **Pattern Run Group**.

Pattern Preset — Displays the active **Preset Speed** being run of the active **Pattern Run Group**.

Pattern Time — Displays the remaining time for the active **Pattern Run Group**.

RR — Displays the **RR** input value as a percentage of the full range of the **RR** value (potentiometer input).

V/I — Displays the **V/I** input setting as a percentage of the full range of the **V/I** value.

Note: *The isolated V/I input terminal may receive **Current** or **Voltage** to control the output speed or the output torque. The input signal type must be selected at **SW2** on the **ACE G9-120V-PCB**.*

*The **V** input setting of **SW2** is used for the 0 – 10 VDC analog input signal and the **I** input setting of **SW2** is used for the 0 – 20 mA analog input signal. Either may be used as a frequency or torque command source. See parameter **F201** for more information on the setup of this terminal.*

RX — Displays the **RX** input setting as a percentage of the full range of the **RX** value (± 10 VDC input).

RX2 Option (AI1) — Displays the **RX2** input setting as a percentage of the full range of the **RX2** value.

Note: *The **RX2** function is available on the **Expansion IO Card Option 1** option board (P/N ETB003Z) only.*

Trip Code — Displays **None** if there are no errors, or displays one of the associated **Fault Codes** listed in [Table 15 on page 254](#) if there is an active **Fault** (e.g., E = Emergency Off).

Past Trip 1 — This function records and displays the last trip incurred. Subsequent trips will replace **Past Trip 1**. As trip records are replaced they are shifted to the next level of the **Past Trip** locations until being deleted (i.e., Past Trip 1 is moved to Past Trip 2 and then to Past Trip 3 until being shifted out of Past Trip 4). Once shifted out of **Past Trip 4** the record is deleted. If no trips have occurred since the last reset, **None** is displayed for each trip record.

Past Trip 2 — Past trip information or **None**.

Past Trip 3 — Past trip information or **None**.

Past Trip 4 — Past trip information or **None**.

Note: An improper ASD setup may cause some trips — reset the ASD to the **Factory Default** settings before pursuing a systemic malfunction (Program ⇒ Utilities ⇒ Type Reset ⇒ Reset to Factory Settings).

Direction — Displays the **Direction** command (forward/reverse).

Discrete Input Terminals — Displays the status (activated = reverse video) of the discrete input terminals of the **ACE G9-120V-PCB**.

Discrete Output Terminals — Displays the status (activated = reverse video) of the discrete output lines of the **ACE G9-120V-PCB**.

Main Monitor Selections

Two (2) **Monitor Mode** items may be selected from the **Main Monitor Selections** screen to be displayed on the **Frequency Command** screen while the ASD is running.

The selected items, along with their real-time values, are displayed on the **Frequency Command** screen while running. Not all **Monitor Mode** items are available for display on the **Frequency Command** screen. The available items are underlined on [pg. 54](#) and [pg. 55](#).

Any two of the underlined items may be selected from the listing at Program ⇒ Utilities ⇒ **Main Monitor Selections**. Select an item from the **Monitor 1** listing and another item from the **Monitor 2** listing to be displayed as shown in [Figure 22. on pg. 35](#).

Program Mode Menu Navigation

The following table lists the menu items of the **Program** mode and maps the flow of the menu selections. The **Parameter Numbers** for the listed functions are provided where applicable.

The functions listed may be viewed, or selected and changed as mapped below or via the **Direct Access** method: Program ⇒ Direct Access ⇒ *Applicable Parameter Number*.

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
STARUP WIZARD	See the section titled Startup Wizard Requirements on pg. 42 for Startup Wizard setup information.		
CRANE / HOIST	Motion Control	Motion Control	F985
	Speed Control	Speed Control	F986
		Preset Speed 1	F018
		Preset Speed 2	F019
		Preset Speed 3	F020
		Preset Speed 4	F021
	Express Stop	Express Stop Enable	F493
		Express Stop Deceleration Time	F511
	Plugging	Plugging Enable	F494
		Plugging Acceleration Time	F514
		Plugging Deceleration Time	F515
	Creep Control	Creep Multiplier 1	F490
		Creep Multiplier 2	F491
		Creep Speed Lower Limit	F492
	Super Creep Control	Super Creep Pulse Count	F863
		Super Creep Repeat Delay	F864
		Super Creep Speed	F865
	Limit-Switch Control	Upper-Limit Speed at Slow-Speed Limit-Switch UP	F294
		Deceleration Time at Slow-Speed Limit-Switch UP	F283
		Stopping Time at Stop Limit-Switch UP	F284
		Upper-Limit Speed at Slow-Speed Limit-Switch DOWN	F293
Deceleration Time at Slow-Speed Limit-Switch DOWN		F285	
Stopping Time at Stop Limit-Switch DOWN		F286	
Limit-Switch Stopping Method		F282	

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
CRANE / HOIST	Express Speed	Express Speed Selection	F328
		Express Speed Switching Frequency	F330
		Express Speed Operation Switching Lower-Limit Frequency	F331
		Express Speed Waiting Time	F332
		Express Speed Detection Time	F333
		Switching Load Torque During Power Run	F335
		Express Speed Operation Heavy-Load Detection Time	F334
		Heavy-Load Torque During Power Run	F336
		Heavy-Load Torque During Fixed-Speed Power Run	F337
		Switching Load Torque During Dynamic Braking	F338
	Closed Loop Hoist Control	Brake-Failure Pulse Count	F994
		Brake-Release Torque Reference	F987
		Brake-Release Torque (Proving) Time	F988
		Brake-Release Mechanical Delay Time	F990
		Brake-Set Mechanical Delay Time	F991
		Brake-Seized Pulse Check	F993
		Load Hover Time	F997
		Brake-Failure Continual Monitoring Pulse Count	F995
		Drooping Pulses Allowed	F998
		Brake-Release Torque Stabilization Time	F989
		Brake-Seized Pulse Time	F992
		Brake-Failure Maximum Speed UP	F996
		Encoder Error Detection Time	F999
	Timed-Run	Timed-Run Run Time	F861
		Timed-Run Repeat Delay	F862
	Slack Rope	Slack Rope Detection	F867
		No Load Torque	F868
		No Load Detection Time	F869
	Bearing Greaser	Bearing Greaser (Alarm) Time	F621
		Bearing Greaser Speed Multiplier	F489

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
CRANE / HOIST	External Fault	External Fault Stopping Method	F280
		Emergency Lift	Emergency-Lift Selection
	Emergency-Lift Maximum Speed		F657
	Emergency-Lift Lower-Limit Reference		F658
	Emergency-Lift Torque Proving Time		F659
	Speed Reference	Speed Reference	F116
		Frequency Mode 2	F207
FUNDAMENTAL	Acc/Dec 1	Automatic Acceleration/Deceleration	F000
		Acceleration Time 1 — UP/DOWN Frequency Accel Time	F009
		Deceleration Time 1 — UP/DOWN Frequency Decel Time	F010
		Acceleration/Deceleration Suspended Function	F349
		Acceleration Suspend Frequency	F350
		Acceleration Suspend Time	F351
		Deceleration Suspend Frequency	F352
		Deceleration Suspend Time	F353
	Frequency	Maximum Frequency	F011
		Upper-Limit Frequency	F012
		Lower-Limit Frequency	F013
		V/f Pattern	F015
		Time Limit for Lower-Limit Frequency Operation	F256
	Motor Set 1	Automatic Torque Boost	F001
		Base Frequency 1	F014
		Manual Torque Boost 1	F016
		Motor Overload Protection Level 1	F600
	Standard Mode Selection	Command Mode	F003
		Frequency Mode 1	F004
		Forward/Reverse Run	F008
		Frequency Priority	F200
		Frequency Mode 2	F207
		Frequency Mode Priority Switching Frequency	F208

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
TERMINAL	Analog Output Terminals	FM Output Terminal Function	F005
		FM Output Terminal Adjustment	F006
		FM Output Gradient Characteristic	F682
		FM Bias Adjustment	F683
		FM Voltage/Current Output Switching	F681
		AM Output Terminal Function	F670
		AM Output Terminal Adjustment	F671
		AM Output Gradient Characteristic	F685
		AM Bias Adjustment	F686
		MON 1 Terminal Meter Selection	F672
		MON 1 Terminal Meter Adjustment	F673
		MON 1 Output Gradient Characteristic	F689
		MON 1 Bias Adjustment	F690
		MON 1 Voltage/Current Output Switching	F688
		MON 2 Terminal Meter Selection	F674
		MON 2 Terminal Meter Adjustment	F675
		MON 2 Output Gradient Characteristic	F692
		MON 2 Bias Adjustment	F693
		MON 2 Voltage/Current Output Switching	F691
		Pulse Output Function	F676
		Pulse Output Frequency	F677
	Input Special Functions	Input Terminal Priority	F106
		16-Bit Binary/BCD Input	F107
		V/I Analog Input Breakage Detection Level	F633
	Input Terminal Delays	Input Terminal 1 (F) Response Time	F140
		Input Terminal 2 (R) Response Time	F141
		Input Terminal 3 (I1) Response Time	F142
		Input Terminal 4 (I2) Response Time	F143
		Input Terminal 5–12 Response Time	F144
		Input Terminal 13–20 Response Time	F145

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
TERMINAL	Input Terminals	Always ON Terminal Function	F110
		Input Terminal 1 (F) Function	F111
		Input Terminal 2 (R) Function	F112
		Input Terminal 3 (I1) Function	F113
		Input Terminal 4 (I2) Function	F114
		Input Terminal 5 (I3) Function	F115
		Input Terminal 6 (I4) Function	F116
		Input Terminal 7 (I5) Function	F117
		Input Terminal 8 (I6) Function	F118
		Input Terminal 9 (LI1) Function	F119
		Input Terminal 10 (LI2) Function	F120
		Input Terminal 11 (LI3) Function	F121
		Input Terminal 12 (LI4) Function	F122
		Input Terminal 13 (LI5) Function	F123
		Input Terminal 14 (LI6) Function	F124
		Input Terminal 15 (LI7) Function	F125
		Input Terminal 16 (LI8) Function	F126
		Input Terminal 17 (B12) Function	F164
		Input Terminal 18 (B13) Function	F165
		Input Terminal 19 (B14) Function	F166
		Input Terminal 20 (B15) Function	F167
		Virtual Input Terminal Selection 1	F973
		Virtual Input Terminal Selection 2	F974
	Virtual Input Terminal Selection 3	F975	
	Virtual Input Terminal Selection 4	F976	
	Line Power Switching	Commercial Power/ASD Switching Output	F354
		Commercial Power/ASD Switching Frequency	F355
ASD-Side Switching Waiting Time		F356	
Commercial Power-Side Switching Waiting Time		F357	
Commercial Power Switching Frequency Holding Time		F358	

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
TERMINAL	Output Terminals	Output Terminal 1 (OUT1) Function	F130
		Output Terminal 2 (OUT2) Function	F131
		Output Terminal 3 (BRAKE) Function	F132
		Output Terminal 4 (OUT3) Function	F133
		Output Terminal 5 (OUT4) Function	F134
		Output Terminal 6 (R1) Function	F135
		Output Terminal 7 (OUT5) Function	F136
		Output Terminal 8 (OUT6) Function	F137
		Output Terminal 9 (R2) Function	F138
		Output Terminal 10 (R3) Function	F168
	Output Terminal 11 (R4) Function	F169	
	Reach	Low Speed Signal Output Frequency	F100
		Speed Reach Frequency	F101
Speed Reach Detection Band		F102	
DIRECT ACCESS	Parameter Number	N/A	
	Unknown Numbers Displayed		
UTILITIES	Display Parameters	Automatic Function Selection	F040
		Current/Voltage Units Setup	F701
		Free Unit Multiplication Factor	F702
		Free Unit	F703
		Free Unit Display Gradient Characteristic	F705
		Free Unit Display Bias	F706
		Change Step Selection 1	F707
		Change Step Selection 2	F708
	Prohibition	Parameter Write Lockout	F700
		Command Mode/Frequency Mode Change Lockout	F736
		Lockout All Keys	F737
		Local/Remote Key Command Override	N/A
		Local/Remote Key Frequency Override	
		Skip Changed-From-Default Uninitialized Parameters	

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
UTILITIES	Trace	Trace Selection	F740
		Trace Cycle	F741
		Trace Data 1	F742
		Trace Data 2	F743
		Trace Data 3	F744
		Trace Data 4	F745
	Alarm Prohibition (Prohibits an EOI alarm display ONLY — alarm still activated)	Over-Current Alarm	N/A
		ASD Overload Alarm	
		Motor Overload Alarm	
		Over-Heat Alarm	
		Over-Voltage Alarm	
		Under-Voltage of Main Power Alarm	
		Reserved (POFF) Alarm	
		Under-Current Alarm	
		Over-Torque Alarm	
		Dynamic Braking Resistor Overload Alarm	
		Bearing Greaser Alarm	
		DeviceNet/Profibus/CC-Link Alarm	
		RS485 Communications	
		Stop After Instantaneous Power-Off Alarm	
		Stop After Lower-Limit Continuous Time	
		Switch Out of Sequence	
		Heavy-Load Alarm	
		Maintenance Timer Alarm	
	Over-Torque Alarm		
	Soft Stall Alarm		
	Type Reset	Reset	F007
	Real-Time Clock Setup	Set Real-Time Clock	N/A
Trip History (Read-Only)	Trip Number	N/A	
	Trip Type		

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
UTILITIES	Trip History (Read-Only)	Frequency at Trip	N/A
		Output Current	
		Output Voltage	
		Direction	
		Frequency Reference	
		DC Voltage	
		Discrete Input Terminals	
		Discrete Output Terminals	
		Run Timer	
		Post Compensation Frequency	
		Speed Feedback (Real-Time)	
		Speed Feedback (1 Second)	
		Torque Feedback	
		Torque Reference	
		Torque Current	
		Excitation Current	
		PID Feedback	
		Motor Overload Ratio	
		ASD Overload Ratio	
		DBR Overload Ratio	
		Motor Load	
		ASD Load	
		DBR Load	
	Input Power		
	Output Power		
	Changed From Default	Changed Parameters	N/A
	Contrast	Contrast Adjustment	N/A
Version (Read-Only)	G9 EOI (Ver:DB)	N/A	
	ASD Type		
	CPU Code Version		

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
UTILITIES	Version (Read-Only)	CPU Code Revision	N/A
		MC Version	
		MC Revision	
		Main Board EEPROM Version	
	Main Monitor Selections	Monitor 1	
Monitor 2			
PROTECTION	Abnormal Speed	Abnormal Speed Detection Time	F622
		Over-Speed Detection Frequency Upper Band	F623
		Over-Speed Detection Frequency Lower Band	F624
	Base Frequency Voltage	Supply Voltage Correction	F307
	DC (Injection) Braking	DC (Injection) Braking Start Frequency	F250
		DC (Injection) Braking Current	F251
		DC (Injection) Braking Time	F252
		Forward/Reverse DC (Injection) Braking Priority	F253
		Motor Shaft Fixing Control	F254
	Dynamic Braking	Dynamic Braking Enable	F304
		Dynamic Braking Resistance	F308
		Continuous Dynamic Braking Capacity	F309
		Braking Resistance Overload Time (10x Rated Torque)	F639
	Emergency Off	Emergency Off	F603
		Emergency DC Braking Control Time	F604
	Low-Current	Low-Current Trip	F610
		Low-Current Detection Current	F611
		Low-Current Detection Time	F612
		Low-Current Detection Hysteresis Width	F609
	Overload	Motor Overload Protection Configuration	F017
		Overload Reduction Start Frequency	F606
		Motor 150% Overload Time Limit	F607
		ASD Overload	F631

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
PROTECTION	Over-Torque	Over-Torque Trip	F615
		Over-Torque Detection Level During Power Running	F616
		Over-Torque Detection Level During Dynamic Braking	F617
		Over-Torque Detection Time	F618
		Over-Torque Detection Hysteresis	F619
	Phase Loss	ASD Output Phase Failure Detection	F605
		ASD Input Phase Failure Detection	F608
	Retry/Restart	Auto Restart Enable	F301
		Number of Times to Retry	F303
		Ridethrough Time	F310
		Random Mode	F312
	Stall	Over-Voltage Limit Operation	F305
		Stall Prevention Factor 1	F416
		Power Running Stall Continuous Trip Detection Time	F452
		Dynamic Braking Stall Prevention Mode	F453
		Stall Prevention Level	F601
		Over-Voltage Limit Operation Level	F626
	Trip	Retain Trip Record at Power Down	F602
	Under-Voltage/ Ridethrough	Regenerative Power Ridethrough	F302
		Synchronized Deceleration Time	F317
		Synchronized Acceleration Time	F318
		Under-Voltage Trip	F627
		Under-Voltage Detection Time	F628
		Regenerative Power Ridethrough Control Level	F629
	Special Protection Parameters	Short Circuit Detection at Start	F613
		Cooling Fan Control	F620
		Bearing Greaser (Alarm) Time	F621
Brake Answer Wait Time		F630	
FREQUENCY	Analog Filter	Analog Input Filter	F209

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
FREQUENCY	Forward/Reverse Disable	Forward/Reverse Disable	F311
	Jog	Jog Frequency	F260
		Jog Stop Pattern	F261
		Panel Operation Jog Mode	F262
	UP/DOWN Frequency Functions	UP/DOWN Up Response Time	F264
		UP/DOWN Up Frequency Step	F265
		UP/DOWN Down Response Time	F266
		UP/DOWN Down Frequency Step	F267
		Initial UP/DOWN Frequency	F268
		Initial UP/DOWN Frequency Rewriting	F269
	V/I	Option V/I Terminal Voltage/Current Selection (AI2 Option Board Input)	F109
	Preset Speeds	Preset Speed 1	F018
		Preset Speed 2	F019
		Preset Speed 3	F020
		Preset Speed 4	F021
		Preset Speed 5	F022
		Preset Speed 6	F023
		Preset Speed 7	F024
		Preset Speed 8	F287
		Preset Speed 9	F288
		Preset Speed 10	F289
		Preset Speed 11	F290
		Preset Speed 12	F291
		Preset Speed 13	F292
		Preset Speed 14/Lower-Limit Slow Speed	F293
		Preset Speed 15/Upper-Limit Slow Speed	F294
	Speed Reference Setpoints	V/I Input Point 1 Setting	F201
		V/I Input Point 1 Frequency	F202
		V/I Input Point 2 Setting	F203

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
FREQUENCY	Speed Reference Setpoints	V/I Input Point 2 Frequency	F204
		RR Input Point 1 Setting	F210
		RR Input Point 1 Frequency	F211
		RR Input Point 2 Setting	F212
		RR Input Point 2 Frequency	F213
		RX Input Point 1 Setting	F216
		RX Input Point 1 Frequency	F217
		RX Input Point 2 Setting	F218
		RX Input Point 2 Frequency	F219
		RX2 Option (AI1) Input Point 1 Setting	F222
		RX2 Option (AI1) Input Point 1 Frequency	F223
		RX2 Option (AI1) Input Point 2 Setting	F224
		RX2 Option (AI1) Input Point 2 Frequency	F225
		BIN Input Point 1 Setting	F228
		BIN Input Point 1 Frequency	F229
		BIN Input Point 2 Setting	F230
		BIN Input Point 2 Frequency	F231
		PG Input Point 1 Setting	F234
		PG Input Point 1 Frequency	F235
		PG Input Point 2 Setting	F236
		PG Input Point 2 Frequency	F237
		V/I Input Bias	F470
		V/I Input Gain	F471
		RR Input Bias	F472
		RR Input Gain	F473
		RX Input Bias	F474
		RX Input Gain	F475
		RX2 Option (AI1) Input Bias	F476
RX2 Option (AI1) Input Gain	F477		
V/I Input Bias (AI2 Option Board Input)	F478		
V/I Input Gain (AI2 Option Board Input)	F479		

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
SPECIAL	Acc/Dec 1 – 4	Acceleration Time 2	F500
		Deceleration Time 2	F501
		Acc/Dec Pattern 1	F502
		Acc/Dec Pattern 2	F503
		Acceleration Time 3	F510
		Express Stop Time	F511
		Express Stop Acceleration/Deceleration Pattern	F512
		Plugging Acceleration Time	F514
		Plugging Deceleration Time	F515
		Plugging Acceleration/Deceleration Pattern	F516
	Acc/Dec Special	Acc/Dec Pattern 1 – 4	F504
		Acc/Dec Switching Frequency 1	F505
		S-Pattern Acceleration Lower-Limit Adjustment	F506
		S-Pattern Acceleration Upper-Limit Adjustment	F507
		S-Pattern Deceleration Lower-Limit Adjustment	F508
		S-Pattern Deceleration Upper-Limit Adjustment	F509
		Acc/Dec Switching Frequency 2	F513
		Acc/Dec Switching Frequency 3	F517
	Carrier Frequency	PWM Carrier Frequency	F300
		Carrier Frequency Control Mode	F316
	Crane/Hoist	Express Speed Operation	F328
		Express Speed Learning Function	F329
		Automatic Express Speed Operation Frequency	F330
		Express Speed Operation Switching Lower-Limit Frequency	F331
		Express Speed Operation Load Wait Time	F332
		Express Speed Operation Detection Time	F333
		Express Speed Heavy-Load Detection Time	F334
		Switching Load Torque During Power Running	F335
		Heavy-Load Torque During Power Running	F336
		Heavy-Load Torque During Constant Power Running	F337

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
SPECIAL	Crane/Hoist	Switching Load Torque During Dynamic Braking	F338
	V/f 5-Point Setting	V/f 5-Point Setting Frequency 1	F190
		V/f 5-Point Setting Voltage 1	F191
		V/f 5-Point Setting Frequency 2	F192
		V/f 5-Point Setting Voltage 2	F193
		V/f 5-Point Setting Frequency 3	F194
		V/f 5-Point Setting Voltage 3	F195
		V/f 5-Point Setting Frequency 4	F196
		V/f 5-Point Setting Voltage 4	F197
		V/f 5-Point Setting Frequency 5	F198
		V/f 5-Point Setting Voltage 5	F199
	Frequency Control	Start Frequency	F240
		Run Frequency	F241
		Run Frequency Hysteresis	F242
		End Frequency	F243
	Special Parameters	0 Hz Dead Band Signal	F244
		0 Hz Command Output	F255
		Exciting Strengthening Coefficient	F415
		Annual Average Ambient Temperature	F634
		Rush Current Suppression Relay Activation Time	F635
		PTC 1 Thermal Selection	F637
	Jump Frequencies	PTC 2 Thermal Selection	F638
		Jump Frequency 1	F270
		Jump Frequency 1 Bandwidth	F271
		Jump Frequency 2	F272
		Jump Frequency 2 Bandwidth	F273
		Jump Frequency 3	F274
	Operation Panel Parameters	Jump Frequency 3 Bandwidth	F275
		Operation Command Clear Selection With Standby Terminal Deactivated	F719
		Panel Stop Pattern	F721

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
SPECIAL	Operation Panel Parameters	Panel Torque Command	F725
		Panel Tension Torque Bias	F727
		Panel Load Sharing Gain	F728
		Panel Override Multiplication Gain	F729
		Panel Frequency Lockout	F730
		Panel Emergency Off Lockout	F734
		Panel Reset Lockout	F735
MOTOR	Motor Set 2	Base Frequency 2	F170
		Base Frequency Voltage 2	F171
		Manual Torque Boost 2	F172
		Overload Protection Level 2	F173
	Motor Set 3	Base Frequency 3	F174
		Base Frequency Voltage 3	F175
		Manual Torque Boost 3	F176
		Overload Protection Level 3	F177
	Motor Set 4	Base Frequency 4	F178
		Base Frequency Voltage 4	F179
		Manual Torque Boost 4	F180
		Overload Protection Level 4	F181
	PM Motor	PM Motor Constant 1 (D-Axis Inductance)	F498
		PM Motor Constant 2 (Q-Axis Inductance)	F499
		Step-Out Detection-Current Level (For PM Motors)	F640
		Step-Out Detection-Current Time (For PM Motors)	F641
	Vector Motor Model	Autotune 1	F400
		Slip Frequency Gain	F401
		Autotune 2	F402
	Vector Motor Model	Motor Rated Capacity (Nameplate)	F405
Motor Rated Current (Nameplate)		F406	
Motor Rated RPM (Nameplate)		F407	
Base Frequency Voltage 1		F409	
Motor Constant 1 (Torque Boost)		F410	

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
MOTOR	Vector Motor Model	Motor Constant 2 (No Load Current)	F411
		Motor Constant 3 (Leak Inductance)	F412
		Motor Constant 4 (Rated Slip)	F413
TORQUE	Manual Torque Limit	Power Running Torque Limit 2 Level	F444
		Dynamic Braking Torque Limit 2 Level	F445
		Power Running Torque Limit 3 Level	F446
		Dynamic Braking Torque Limit 3 Level	F447
		Power Running Torque Limit 4 Level	F448
		Dynamic Braking Torque Limit 4 Level	F449
	Setpoints	V/I Input Point 1 Rate	F205
		V/I Input Point 2 Rate	F206
		RR Input Point 1 Rate	F214
		RR Input Point 2 Rate	F215
		RX Input Point 1 Rate	F220
		RX Input Point 2 Rate	F221
		RX2 Option (AI1) Input Point 1 Rate	F226
		RX2 Option (AI1) Input Point 2 Rate	F227
	Torque Control	Torque Command	F420
		Tension Torque Bias Input (Torque Control)	F423
		Load Sharing Gain Input	F424
		Forward Speed Limit Input	F425
		Forward Speed Limit Input Level	F426
		Reverse Speed Limit Input	F427
		Reverse Speed Limit Input Level	F428
		Power Running Torque Limit 1	F440
		Power Running Torque Limit 1 Level	F441
	Torque Limit	Dynamic Braking Torque Limit 1	F442
		Dynamic Braking Torque Limit 1 Level	F443
		Acceleration/Deceleration Operation After Torque Limit	F451
	Torque Speed Limiting	Speed Limit (Torque = 0) Center Value Reference	F430

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
TORQUE	Torque Speed Limiting	Speed Limit (Torque = 0) Center Value	F431
		Speed Limit (Torque = 0) Band	F432
		Allow Specified Direction ONLY	F435
FEEDBACK	Drooping Control	Drooping Gain	F320
		Speed at 0% Drooping Gain	F321
		Speed at F320 Drooping Gain	F322
		Drooping Insensitive Torque	F323
		Drooping Output Filter	F324
	Feedback	PID Control Switching	F359
		PID Feedback Signal	F360
		PID Feedback Delay Filter	F361
		PID Feedback Proportional Gain	F362
		PID Feedback Integral Gain	F363
		PID Deviation Upper Limit	F364
		PID Deviation Lower Limit	F365
		PID Feedback Differential Gain	F366
		Process Upper Limit	F367
		Process Lower Limit	F368
		PID Control Wait Time	F369
		PID Output Upper Limit	F370
		PID Output Lower Limit	F371
		Process Increasing Rate	F372
		Process Decreasing Rate	F373
	Speed PI Switching Frequency	F466	
	Override Control	Adding Input Selection	F660
		Multiplying Input Selection	F661
	PG	Number of PG Input Pulses	F375
		Number of PG Input Phases	F376
		PG Disconnection Detection	F377
		Simple Positioning Completion Range	F381

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
FEEDBACK	PG	Current Control Proportional Gain	F458
		Speed Loop Proportional Gain	F460
		Speed Loop Stabilization Coefficient	F461
		Load Moment of Inertia 1	F462
		Second Speed Loop Proportional Gain	F463
		Second Speed Loop Stabilization Coefficient	F464
		Load Moment of Inertia 2	F465
MY FUNCTION	My Function Selection	My Function Operating Mode	F977
	My Function Unit 1	Input Function Target 1	F900
		Input Function Command 1	F901
		Input Function Target 2	F902
		Input Function Command 2	F903
		Input Function Target 3	F904
		Output Function Assigned	F905
	My Function Unit 2	Input Function Target 1	F906
		Input Function Command 1	F907
		Input Function Target 2	F908
		Input Function Command 2	F909
		Input Function Target 3	F910
		Output Function Assigned	F911
	My Function Unit 3	Input Function Target 1	F912
		Input Function Command 1	F913
		Input Function Target 2	F914
		Input Function Command 2	F915
		Input Function Target 3	F916
		Output Function Assigned	F917
	My Function Unit 4	Input Function Target 1	F935
		Input Function Command 1	F936
		Input Function Target 2	F937
		Input Function Command 2	F938

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
MY FUNCTION	My Function Unit 4	Input Function Target 3	F939
		Output Function Assigned	F940
	My Function Unit 5	Input Function Target 1	F941
		Input Function Command 1	F942
		Input Function Target 2	F943
		Input Function Command 2	F944
		Input Function Target 3	F945
		Output Function Assigned	F946
		My Function Unit 6	Input Function Target 1
	Input Function Command 1		F948
	Input Function Target 2		F949
	Input Function Command 2		F950
	Input Function Target 3		F951
	Output Function Assigned		F952
	My Function Unit 7	Input Function Target 1	F953
		Input Function Command 1	F954
		Input Function Target 2	F955
		Input Function Command 2	F956
		Input Function Target 3	F957
		Output Function Assigned	F958
	My Function Data	My Function Percent Data 1	F918
		My Function Percent Data 2	F919
		My Function Percent Data 3	F920
		My Function Percent Data 4	F921
		My Function Percent Data 5	F922
		My Function Frequency Data 1	F923
		My Function Frequency Data 2	F924
		My Function Frequency Data 3	F925
		My Function Frequency Data 4	F926
		My Function Frequency Data 5	F927

Program Mode Menu Navigation				
Primary Menu	Sub Menu	Parameter Name	Parameter Number	
MY FUNCTION	My Function Data	My Function Time Data 1	F928	
		My Function Time Data 2	F929	
		My Function Time Data 3	F930	
		My Function Time Data 4	F931	
		My Function Time Data 5	F932	
		My Function Count Data 1	F933	
		My Function Count Data 2	F934	
	My Function Analog	Analog Input Function Target 11	F959	
		Analog Function Assigned Object 11	F961	
		Analog Input Function Target 21	F962	
		Analog Function Assigned Object 21	F964	
	My Function Monitor	Monitor Output Function 11	F965	
		Monitor Output Function Command 11	F966	
		Monitor Output Function 21	F967	
		Monitor Output Function Command 21	F968	
		Monitor Output Function 31	F969	
		Monitor Output Function Command 31	F970	
		Monitor Output Function 41	F971	
		Monitor Output Function Command 41	F972	
	COMMUNICATIONS	Communications Adjustments	Frequency Point Selection	F810
			Point 1 Setting	F811
Point 1 Frequency			F812	
Point 2 Setting			F813	
Point 2 Frequency			F814	
Communications		RS485 2-Wire Baud Rate	F800	
		RS485 2-Wire and 4-Wire Parity	F801	
		ASD Number	F802	
		RS485 2-Wire and 4-Wire Communications Time-Out	F803	
		RS485 2-Wire and 4-Wire Communications Time-Out Action	F804	

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
COMMUNICATIONS	Communications	RS485 2-Wire Send Wait Time	F805
		RS485 2-Wire ASD-to-ASD Communications	F806
		RS485 4-Wire Baud Rate	F820
		RS485 Send Wait Time	F825
		RS485 4-Wire ASD-to-ASD Communications	F826
		RS485 4-Wire Protocol (TSB/MODBUS)	F829
		Communication Option (DeviceNet/Profibus) Setting 1	F830
		Communication Option (DeviceNet/Profibus) Setting 2	F831
		Communication Option (DeviceNet/Profibus) Setting 3	F832
		Communication Option (DeviceNet/Profibus) Setting 4	F833
		Communication Option (DeviceNet/Profibus) Setting 5	F834
		Communication Option (DeviceNet/Profibus) Setting 6	F835
		Communication Option (DeviceNet/Profibus) Setting 7	F836
		Communication Option (DeviceNet/Profibus) Setting 8	F841
		Communication Option (DeviceNet/Profibus) Setting 9	F842
		Communication Option (DeviceNet/Profibus) Setting 10	F843
		Communication Option (DeviceNet/Profibus) Setting 11	F844
		Communication Option (DeviceNet/Profibus) Setting 12	F845
		Communication Option (DeviceNet/Profibus) Setting 13	F846
		Disconnection Detection Extended Time	F850
		ASD Disposition at Disconnection	F851
		Preset Speed Operation	F852
		Communication Option Station Address Monitor	F853
		Communication Option Speed Switch Monitor DeviceNet/CC-Link	F854
		Block Write Data 1	F870
		Block Write Data 2	F871
		Block Read Data 1	F875
Block Read Data 2	F876		
Block Read Data 3	F877		
Block Read Data 4	F878		

Program Mode Menu Navigation			
Primary Menu	Sub Menu	Parameter Name	Parameter Number
COMMUNICATIONS	Communications	Block Read Data 5	F879
		Free Notes	F880
		Network Option Reset Setting	F899
	Ethernet	IP	N/A
		Sub Net	
		Gateway	
		DHCP Mode	
		MAC ID	
	PASSWORD AND LOCKOUT	Enter Password	
Change Password		Enter New Password	N/A
Lockouts		Reset From Trip	N/A
		Local/Remote	
		Run/Stop from EOI	
		Frequency Change From EOI	
		Monitor Screen	
		Parameter Access	
Parameter Write			

Direct Access Information

The ACE-tronics G9 ASD has the ability to allow the user direct access to the motor control functions. There are two ways in which the motor control parameters may be accessed for modification: Program ⇒ Direct Access ⇒ *Applicable Parameter Number* or Program ⇒ *Applicable Menu Path*. Both methods access the parameter via the **Program** mode. Once accessed, the parameter may be viewed or changed.

The **Program** mode allows the user to develop an application-specific motor-control profile. Motor control functions may be set to accommodate application-specific power and timing requirements.

The configurable parameters of the **Program** mode that have user-accessible **Parameter Numbers** are listed and described below. The parameters that do not have a Direct Access number and are accessible via the **Program** mode menu hierarchy only are listed and described on [pg. 57](#).

Note: *The setup procedures included within this section may require a **Reset** before performing the procedure. Application-specific settings may then be performed. The pre-reset conditions may be saved (see [F007](#)).*

Note: *Communications setting changes will require that the power be removed and then re-applied for the changes to take effect.*

Direct Access Parameters/Numbers

<p>Automatic Acceleration/Deceleration</p> <p>Program ⇒ Fundamental ⇒ Acc/Dec 1</p> <p>This parameter is used to enable automatic acceleration and deceleration rates in accordance with the applied load.</p> <p>The adjusted acceleration and deceleration times range from 12.5% to 800% of the programmed values for Acceleration Time 1 — UP/DOWN Frequency Accel Time (F009) and Deceleration Time 1 — UP/DOWN Frequency Decel Time (F010).</p> <p>Settings:</p> <ul style="list-style-type: none"> Manual Automatic ACC/DEC Automatic ACC Only <p>Note: <i>The motor and the load must be connected prior to selecting Automatic Acceleration/Deceleration.</i></p>	<p>Direct Access Number — F000</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Manual</p> <p>Changeable During Run — No</p>
<p>Automatic Torque Boost</p> <p>Program ⇒ Fundamental ⇒ Motor Set 1</p> <p>This parameter allows the ASD to adjust the output torque in accordance with the applied load automatically. When enabled, an Autotune is performed — the motor should be connected before performing an Autotune.</p> <p>Settings:</p> <ul style="list-style-type: none"> Disabled Automatic Torque Boost + Autotuning Sensorless Vector Control + Autotuning 	<p>Direct Access Number — F001</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Disabled</p> <p>Changeable During Run — No</p>

F003**F004****Command Mode**

Program ⇒ Fundamental ⇒ Standard Mode Selection

The **Command Mode Selection** establishes the source of the command input for the ASD. **Command** inputs include **Run**, **Stop**, **Forward**, etc. The **Override** feature may supersede the **Command Mode Selection** setting (see [Command and Frequency Mode Control on pg. 47](#)).

Settings:

Terminal Board
EOI Keypad
RS485
Communication Option Board

Direct Access Number — F003

Parameter Type — **Selection List**

Factory Default — **Terminal Board**

Changeable During Run — **No**

Frequency Mode 1

Program ⇒ Fundamental ⇒ Standard Mode Selection

The **Frequency Mode 1** setting establishes the source of the frequency-control input for the ASD. The **Frequency Mode 2** setting or the **Override** feature may supersede the **Frequency Mode 1** setting (see [Command and Frequency Mode Control on pg. 47](#) and [F200](#) for additional information on this feature).

***Note:** Only **bolded** items from the **Settings** list below may be placed in the **Override** mode.*

Settings:

V/I
RR
RX
EOI Keypad
RS485
Communication Option Board
RX2 Option (AI1)
Option V/I
UP/DOWN Frequency
Pulse Input (Option)
Pulse Input (Motor CPU)
Binary/BCD Input (Option)

Direct Access Number — F004

Parameter Type — **Selection List**

Factory Default — **RR**

Changeable During Run — **No**

F005**F006****FM Output Terminal Function**

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to set the output function of the **FM** analog output terminal. The **FM** output terminal produces an output current or voltage that is proportional to the magnitude of the function assigned to this terminal (select current or voltage at **F681**). The available assignments for this output terminal are listed in [Table 8 on pg. 240](#).

***Note:** To read **voltage** at this terminal connect a 100 – 500Ω resistor from the **FM** (+) terminal to the **CC** (-) terminal. Using a voltmeter read the voltage across the 100 – 500Ω resistor.*

*To read **current** at this terminal connect a 100 – 500Ω resistor from the **FM** (+) terminal through a series Ammeter to the **CC** (-) terminal.*

*The **FM** analog output has a maximum resolution of 1/1024 and a maximum load rating of 500 ohms.*

FM Terminal Setup Parameters

- F005** — FM Output Terminal Function
- F006** — FM Output Terminal Adjustment
- F681** — FM Voltage/Current Output Switching
- F682** — FM Output Gradient Characteristic
- F683** — FM Bias Adjustment

FM Output Terminal Adjustment

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to calibrate the **FM** analog output.

To calibrate the **FM** analog output, connect a meter (current or voltage) as described at [F005](#).

With the ASD running at a known value (e.g., output frequency), adjust this parameter until the assigned function produces the desired DC level output at the **FM** output terminal.

See [F005](#) for additional information on this setting.

Direct Access Number — **F005**

Parameter Type — **Selection List**

Factory Default — **Signed Speed Feedback (Realtime)**

Changeable During Run — **Yes**

Direct Access Number — **F006**

Parameter Type — **Numerical**

Factory Default — **493**

Changeable During Run — **Yes**

Minimum — 1

Maximum — 1280

F007**F008****Reset**

Program ⇒ Utilities ⇒ Type Reset

This feature assists the user when performing fault analysis or by allowing a quick system setup change when required. Performing a **Type Reset** results in one of the following user-selected post-reset configurations.

Settings:

- None
- 50 Hz Setting
- 60 Hz Setting
- Reset to Factory Settings
- Clear Past Trips
- Clear Run Timer (Bearing Greaser)
- Initialize Typeform
- *Save User Settings
- Restore User Settings
- Clear Cumulative Fan Timer (FE79)
- Accel/Decel Time Setting 0.01 – 600.0 Seconds
- Accel/Decel Time Setting 0.1 – 6000.0 Seconds
- Update EOI Firmware
- Set EOI Memory to Default

*Note: User settings that are stored in the memory of the **EOI** are not saved via the **Save User Settings** selection.*

Direct Access Number — F007

Parameter Type — **Selection List**

Factory Default — **None**

Changeable During Run — **No**

Forward/Reverse Run

Program ⇒ Fundamental ⇒ Standard Mode Selection

While operating in the **Local** mode, this parameter sets the direction of motor rotation.

From the **Frequency Command** screen press the **ESC** key. At the subsequent **EOI Command** screen select the **Direction** field and change the setting. Press the **Rotary Encoder** and the new setting will be in effect.

This setting will not override parameter **F311 (Forward/Reverse Disable)**.

If either direction is disabled via parameter **F311**, the disabled direction will not be recognized if commanded by the **EOI**. If both directions are disabled via parameter **F311**, the direction command from the **EOI** will determine the direction of the motor rotation.

Settings:

- Forward
- Reverse
- Switchable F/R by EOI (Forward)
- Switchable F/R by EOI (Reverse)

Direct Access Number — F008

Parameter Type — **Selection List**

Factory Default — **Forward**

Changeable During Run — **Yes**

F009

F010

Acceleration Time 1 — UP/DOWN Frequency Accel Time

Program ⇒ Fundamental ⇒ Acc/Decel 1

This is a dual-function parameter. The two functions are described below.

- 1) This parameter specifies the time in seconds for the output of the ASD to go from 0.0 Hz to the **Maximum Frequency** for the **#1 Acceleration** profile.
- 2) This parameter specifies the time in seconds for the output of the ASD to go from 0.0 Hz to the **Maximum Frequency** during the **UP/DOWN Frequency Functions**. See [F264](#) for additional information on the **UP/DOWN Frequency Functions**.

The Accel/Decel pattern may be set using [F502](#). This parameter may be further defined by the settings of [F506 – F509](#).

Note: *An acceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. **Automatic Accel/Decel, Stall, and Ridethrough** settings may lengthen the actual acceleration times.*

Acceleration

The acceleration rate of a motor is determined by several factors: applied power, applied load, and the physical properties of the motor (winding parameters, motor size, etc.). The ASD will control the first of these factors: input power. The settings of the ASD will control the frequency and amplitude of the applied voltage to the motor.

Under most operating conditions, as the output frequency of the ASD goes up so does the output voltage (linear acceleration). The ASD has the ability to modify the relationship between frequency and voltage automatically to produce smoother operation or increased (starting) torque (see [F502](#)).

Deceleration Time 1 — UP/DOWN Frequency Decel Time

Program ⇒ Fundamental ⇒ Acc/Decel 1

This is a dual-function parameter. The two functions are described below.

- 1) This parameter specifies the time in seconds for the output of the ASD to go from the **Maximum Frequency** to 0.0 Hz for the **#1 Deceleration** profile.
- 2) This parameter specifies the time in seconds for the output of the ASD to go from the **Maximum Frequency** to 0.0 Hz during the **UP/DOWN Frequency Functions**. See [F264](#) for additional information on the **UP/DOWN Frequency Functions**.

The Accel/Decel pattern may be set using [F502](#). This parameter may be further defined by the settings of [F506 – F509](#).

Note: *A deceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. **Automatic Accel/Decel, Stall, and Ridethrough** settings may lengthen the actual deceleration times.*

Direct Access Number — F009

Parameter Type — **Numerical**

Factory Default — **3.0**

Changeable During Run — **Yes**

Minimum — 0.1

Maximum — 6000

Units — Seconds

Direct Access Number — F010

Parameter Type — **Numerical**

Factory Default — **1.5**

Changeable During Run — **Yes**

Minimum — 0.1

Maximum — 6000

Units — Seconds

F011

F014

<p>Maximum Frequency</p> <p>Program ⇒ Fundamental ⇒ Frequency</p> <p>This setting determines the absolute maximum frequency that the ASD can output.</p> <p>Accel/Decel times are calculated based on the Maximum Frequency setting.</p> <p>The Maximum Frequency is not limited by this setting while operating in the Drooping Control mode (see F320 for additional information on this setting).</p> <p><i>Note:</i> This setting may not be lower than the Upper-Limit Frequency setting (F012).</p>	<p>Direct Access Number — F011</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 65.0</p> <p>Changeable During Run — No</p> <p>Minimum — 30.0</p> <p>Maximum — 299.0</p> <p>Units — Hz</p>
<p>Upper-Limit Frequency</p> <p>Program ⇒ Fundamental ⇒ Frequency</p> <p>This parameter sets the highest frequency that the ASD will accept as a frequency command or frequency setpoint. The ASD may output frequencies higher than the Upper-Limit Frequency (but, lower than the Maximum Frequency) when operating in the PID Control mode, Torque Control mode, or the Vector Control modes (sensorless or feedback).</p> <p><i>Note:</i> This setting may not be higher than the Maximum Frequency (F011) setting.</p>	<p>Direct Access Number — F012</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 60.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>Lower-Limit Frequency</p> <p>Program ⇒ Fundamental ⇒ Frequency</p> <p>This parameter sets the lowest frequency that the ASD will accept as a frequency command or frequency setpoint. The ASD will output frequencies lower than the Lower-Limit Frequency when accelerating to the lower limit or decelerating to a stop. Frequencies below the Lower Limit may also be output when operating in the PID Control mode, Torque Control mode, or the Vector Control modes (sensorless or feedback).</p>	<p>Direct Access Number — F013</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 13.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>
<p>Base Frequency 1</p> <p>Program ⇒ Fundamental ⇒ Motor Set 1</p> <p>The Base Frequency 1 setting is the frequency at which the output voltage of the ASD reaches its maximum setting. The Base Frequency Voltage 1 parameter is set at F409.</p> <p>For proper motor operation, the Base Frequency should be set for the nameplate frequency of the motor.</p>	<p>Direct Access Number — F014</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 60.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>

F015

F016

V/f Pattern

Program ⇒ Fundamental ⇒ Frequency

This function establishes the relationship between the output frequency and the output voltage.

Bolded selections use the motor tuning parameters of the ASD to properly configure the ASD for the motor being used. If **Load Reactors** or **Long Lead Filters** are used, or if the capacity of the ASD is greater than the motor, manual tuning of the motor parameters may be required for optimum performance.

Settings:

Constant Torque

Voltage Decrease Curve

Automatic Torque Boost

Sensorless Vector Control (Speed)

Sensorless Vector Control (Speed/Torque Switching)

V/f 5-Point Curve (Go to F190 to configure the V/f 5-point settings)

PM Drive (Permanent Magnet)

PG Feedback Vector Control (Speed)

PG Feedback Vector Control (Speed/Torque Switching)

Note: When operating in the **Vector Control** mode the carrier frequency should be set to 2.2 kHz or above.

Direct Access Number — F015

Parameter Type — **Selection List**

Factory Default — **PG Feedback Vector Control (Speed/Torque Switching)**

Changeable During Run — **No**

Manual Torque Boost 1

Program ⇒ Fundamental ⇒ Motor Set 1

The **Manual Torque Boost 1** function is used to increase the low frequency torque for high-inertia loads by increasing the output voltage at frequencies below ½ of the **Base Frequency 1 (F014)** setting.

The value programmed as a boost percentage establishes an output voltage vs. output frequency relationship to be used to start the motor or to provide smoother operation.

Direct Access Number — F016

Parameter Type — **Numerical**


Factory Default — (ASD-Dependent)

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 30.0

Units — %



Note: Setting an excessive **Torque Boost** level may cause nuisance tripping and mechanical stress to loads.

Motor Overload Protection Configuration

Program ⇒ Protection ⇒ Overload

This parameter is used to protect the motor from an over-current condition. The type of motor being used and the **Overload/Stall** setting is selected here to better match the application.

This parameter setting may extend the **Over-Voltage Stall** time settings.

This parameter may be affected by the setting of the **Power Running Stall Continuous Trip Detection Time** (F452).

Settings:

- Overload Trip without Stall
- Overload Trip with Stall
- No Overload without Stall
- Stall Only
- V/f Motor-Overload without Stall
- V/f Motor-Overload with Stall
- V/f Motor-No Overload without Stall
- V/f Motor-Stall Only

Direct Access Number — F017

Parameter Type — **Selection List**

Factory Default — **Overload Trip Without Stall**

Changeable During Run — **Yes**

F018

F019

Preset Speed 1

Program ⇒ Frequency ⇒ Preset Speeds

Up to fifteen (15) output frequency values that fall within the **Lower-Limit** and the **Upper-Limit** range may be programmed into the ASD and output as a **Preset Speed**. This parameter assigns an output frequency to binary number 0001 and is identified as **Preset Speed 1**. The binary number is applied to **I1 – I4** of the **ACE G9-120V-PCB** to output the **Preset Speed**.

Perform the following setup to allow the system to receive **Preset Speed** control input at the **I1 – I4** terminals:

1. Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Board**.
2. Program ⇒ Terminal ⇒ Input Terminals ⇒ **I1** (set to **Preset Speed 1**; LSB of 4-bit count). Repeat for **I2 – I4** (MSB of 4-bit count) as **Preset Speed 2 – 4**, respectively (all Normally Open).
3. Program ⇒ Frequency ⇒ Preset Speeds ⇒ **Preset Speed 1** (set an output frequency as **Preset Speed 1**; repeat for **Preset Speeds 2 – 15** as required).
4. Program ⇒ Pattern Run ⇒ Operation Mode ⇒ Preset Speed Operation Mode ⇒ **Enabled/Disabled**.

Select **Enable** to use the direction, accel/decel, and torque settings of the **Preset Speed** being run. The torque settings used will be as defined in **F170 – F181** and as selected via the associated discrete input terminals **V/f Switching 1 and 2** in **Table 7** on pg. 236.

Select **Disabled** to use the speed setting only of the **Preset Speed** being run.

5. Place the system in the **Remote** mode (Local/Remote LED Off).
6. Provide a **Run** command (activate F and/or R).

Activate **I1** to run **Preset Speed 1** (120 VAC to I1 = 0001 binary).

With **I1 – I4** configured to output **Preset Speeds (F115 – F118)**, 0001 – 1111 may be applied to **I1 – I4** of the **ACE G9-120V-PCB** to run the associated **Preset Speed**. If bidirectional operation is required **F** and **R** must be activated.

With **I1** being the least significant bit of a binary count, the **I1 – I4** settings will produce the programmed speed settings as indicated in the **Preset Speed Truth Table** to the right.

Preset Speeds are also used in the **Pattern Run** mode.

Direct Access Number — F018

Parameter Type — **Numerical**

Factory Default — **60.0**

Changeable During Run — **Yes**

Minimum — **Lower Limit (F013)**

Maximum — **Upper Limit (F012)**

Units — Hz

Preset Speed Truth Table

Preset	I4 MSB	I3	I2	I1 LSB	Output
1	0	0	0	1	F018
2	0	0	1	0	F019
3	0	0	1	1	F020
4	0	1	0	0	F021
5	0	1	0	1	F022
6	0	1	1	0	F023
7	0	1	1	1	F024
8	1	0	0	0	F287
9	1	0	0	1	F288
10	1	0	1	0	F289
11	1	0	1	1	F290
12	1	1	0	0	F291
13	1	1	0	1	F292
14	1	1	1	0	F293
15	1	1	1	1	F294

Note: 1 = Terminal activated.

Preset Speed 2

Program ⇒ Frequency ⇒ Preset Speeds

This parameter assigns an output frequency to binary number 0010 and is identified as **Preset Speed 2**. The binary number is applied to **I1 – I4** of the **ACE G9-120V-PCB** to output the **Preset Speed** (see **F018** for additional information on this parameter).

Direct Access Number — F019

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — **Lower Limit (F013)**

Maximum — **Upper Limit (F012)**

Units — Hz

F020

F024

<p>Preset Speed 3</p> <p>Program ⇒ Frequency ⇒ Preset Speeds</p> <p>This parameter assigns an output frequency to binary number 0011 and is identified as Preset Speed 3. The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).</p>	<p>Direct Access Number — F020</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — Lower Limit (F013)</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>
<p>Preset Speed 4</p> <p>Program ⇒ Frequency ⇒ Preset Speeds</p> <p>This parameter assigns an output frequency to binary number 0100 and is identified as Preset Speed 4. The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).</p>	<p>Direct Access Number — F021</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — Lower Limit (F013)</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>
<p>Preset Speed 5</p> <p>Program ⇒ Frequency ⇒ Preset Speeds</p> <p>This parameter assigns an output frequency to binary number 0101 and is identified as Preset Speed 5. The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).</p>	<p>Direct Access Number — F022</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — Lower Limit (F013)</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>
<p>Preset Speed 6</p> <p>Program ⇒ Frequency ⇒ Preset Speeds</p> <p>This parameter assigns an output frequency to binary number 0110 and is identified as Preset Speed 6. The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).</p>	<p>Direct Access Number — F023</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — Lower Limit (F013)</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>
<p>Preset Speed 7</p> <p>Program ⇒ Frequency ⇒ Preset Speeds</p> <p>This parameter assigns an output frequency to binary number 0111 and is identified as Preset Speed 7. The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).</p>	<p>Direct Access Number — F024</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — Lower Limit (F013)</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>

Automatic Function Selection

Program ⇒ Utilities ⇒ Display Parameters

This parameter setting is used to configure multiple parameters with the setting of only one parameter. From the selection below multiple parameters may be set as indicated in the table.

Once set, the selected configuration is placed in effect and remains in effect until this parameter is changed or the individual settings are changed.

Set this parameter to **Disable** to set these parameters individually.

*Note: After performing the desired selection the **EOI** display returns to **Disabled** though the selected function has been carried out (i.e., without this, if selection **1** is performed, **F004** and **F207** would hold the RR terminal setting regardless of attempts to change the settings individually).*

Settings:

- Disabled
- RR
- V/I
- RR or V/I Switched via Terminal Board (ACE G9-120V-PCB)
- Keypad Frequency/Terminal Board Command (ACE G9-120V-PCB)
- Keypad Frequency and Command

Direct Access Number — F040

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **No**

Related Params	Default Settings	User Settings					
		0-Disable	1-RR	2-V/I	3-RR or V/I via TB	4-Keypad/ Freq. CMD/TB	5-Keypad Freq/CMD
Command Mode F003	Terminal Board	N/C				Terminal Board	*Keypad
Frequency Mode 1 F004	RR	N/C	RR	N/C	RR	*Keypad	
I3 Terminal F117	Preset Speed 3	N/C			Freq. Ref. Priority	N/C	
Freq. Priority F200	Terminal Board	N/C	Terminal Board				
V/I Setup F201	0.0%	N/C		20.0%	N/C		
Frequency Mode 2 F207	V/I	N/C	RR	V/I	*Keypad		

N/C = No Change — the setting remains as it was before setting parameter F040.

*Note: *Go to **F003** and/or **F004** and select **EOI Keypad** to use the **EOI** for control.*

F100

F106

Low-Speed Signal Output Frequency

Program ⇒ Terminal ⇒ Reach

The **Low-Speed Signal Output Frequency** parameter sets a frequency threshold that activates the assigned output terminal for the duration that the ASD output is equal to or above this setting (see [Table 10 on pg. 242](#) for the available output assignments).

Direct Access Number — F100Parameter Type — **Numerical**Factory Default — **0.00**Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

Speed Reach Frequency

Program ⇒ Terminal ⇒ Reach

The **Speed Reach Frequency** sets a frequency threshold that, when reached or is within the bandwidth specified by parameter [F102](#), activates the assigned output terminal for the duration that the ASD output is within the bandwidth specified (see [Table 10 on pg. 242](#) for the available output assignments).

This setting is also a permissive when using the **Express Speed** function.

Direct Access Number — F101Parameter Type — **Numerical**Factory Default — **0.00**Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

Speed Reach Detection Band

Program ⇒ Terminal ⇒ Reach

This parameter sets the bandwidth of the **Speed Reach Frequency (F101)** setting.

Direct Access Number — F102Parameter Type — **Numerical**Factory Default — **2.50**Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

Input Terminal Priority

Program ⇒ Terminal ⇒ Input Special Functions

This parameter is used to allow the **Jog** and **DC Injection Braking** input signals to control the ASD when received via the **ACE G9-120V-PCB** even though the system is in the **Local** mode.

With this parameter enabled, a **Jog** command or a **DC Injection Braking** command received from the **ACE G9-120V-PCB** will receive priority over commands from the **EOI**.

See [F260](#) for additional information on using the **Jog** function.

See [F250 – F252](#) for additional information on **DC Injection Braking**.

Settings:

Disabled

Enabled

Direct Access Number — F106Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **No**

16-Bit Binary/BCD Input

Program ⇒ Terminal ⇒ Input Special Functions

The extended terminal function is used with the **Expansion IO Card Option** (P/N ETB004Z).

This parameter defines the format of the binary or BCD data when using the option card.

Note: *The Expansion IO Card Option 2 option board is required to use this terminal.*

See the **Expansion IO Card Option 1 Instruction Manual** (P/N 58685) for additional information on the function of this terminal.

Settings:

- None
- 12-Bit Binary
- 16-Bit Binary
- 3-Digit BCD
- 4-Digit BCD
- Inverted 12-Bit Binary
- Inverted 16-Bit Binary
- Inverted 3-Digit BCD
- Inverted 4-Digit BCD

Selections using 16-bit binary or 4-digit BCD will require the configuration of terminals I1-I4 on the **ACE G9-120V-PCB** as binary bits 0 – 3 (**F115 – F118**). The **Frequency Mode 1 (F004)** parameter must be set to **Binary/BCD**.

For proper scaling of the binary or BCD input, parameters **F228 – F231** must be configured.

Option V/I Terminal Voltage/Current Selection

Program ⇒ Frequency ⇒ V/I

This parameter is used to set the **AI2** input terminal to receive either current or voltage as a control signal.

Note: *The Expansion IO Card Option 2 option board (P/N ETB004Z) is required to use this terminal.*

See the **Expansion IO Card Option 2 Instruction Manual** (P/N 58686) for additional information on the function of this terminal.

Settings:

- Voltage Input
- Current Input

Direct Access Number — F107

Parameter Type — Selection List

Factory Default — None

Changeable During Run — No

Direct Access Number — F109

Parameter Type — Selection List

Factory Default — Voltage Input

Changeable During Run — No

F110

F114

Always ON Terminal Function

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the virtual discrete input terminal **ON**. As a virtual terminal, the **ON** control terminal exists only in memory and is considered to always be in its **True** (activated) state.

It is often practical to assign a function to this terminal that the user desires to be maintained regardless of external conditions or operations.

This parameter sets the programmable **ON** terminal to any one of the user-selectable functions listed in [Table 7 on pg. 236](#).

This terminal is set to **ST** (Standby) to allow for ready-to-run operation and allows for the use of the discrete input terminals for other functions.

Direct Access Number — F110

Parameter Type — **Selection List**

Factory Default — **ST**

Changeable During Run — **No**

Input Terminal 1 (F) Function

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **F** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **F** terminal to any one of the user-selectable functions listed in [Table 7 on pg. 236](#).

Direct Access Number — F111

Parameter Type — **Selection List**

Factory Default — **Forward**

Changeable During Run — **No**

Input Terminal 2 (R) Function

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **R** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **R** terminal to any one of the user-selectable functions listed in [Table 7 on pg. 236](#).

Direct Access Number — F112

Parameter Type — **Selection List**

Factory Default — **Reverse**

Changeable During Run — **No**

Input Terminal 3 (I1) Function

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **I1** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **I1** terminal to any one of the user-selectable functions listed in [Table 7 on pg. 236](#).

Direct Access Number — F113

Parameter Type — **Selection List**

Factory Default — **Preset Speed 1**

Changeable During Run — **No**

Input Terminal 4 (I2) Function

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **I2** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **I2** terminal to any one of the user-selectable functions listed in [Table 7 on pg. 236](#).

Direct Access Number — F114

Parameter Type — **Selection List**

Factory Default — **Unassigned**

Changeable During Run — **No**

<p>Input Terminal 5 (I3) Function</p> <p>Program ⇒ Terminal ⇒ Input Terminals</p> <p>This parameter is used to set the functionality of the I3 discrete input terminal.</p> <p>In addition, this input terminal must be specified as Normally Open or Normally Closed.</p> <p>This setting assigns the function of the programmable I3 terminal to any one of the user-selectable functions listed in Table 7 on pg. 236.</p>	<p>Direct Access Number — F115</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Unassigned</p> <p>Changeable During Run — No</p>
<p>Input Terminal 6 (I4) Function</p> <p>Program ⇒ Terminal ⇒ Input Terminals</p> <p>This parameter is used to set the functionality of the I4 discrete input terminal.</p> <p>In addition, this input terminal must be specified as Normally Open or Normally Closed.</p> <p>This setting assigns the function of the programmable I4 terminal to any one of the user-selectable functions listed in Table 7 on pg. 236.</p>	<p>Direct Access Number — F116</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Unassigned</p> <p>Changeable During Run — No</p>
<p>Input Terminal 7 (I5) Function</p> <p>Program ⇒ Terminal ⇒ Input Terminals</p> <p>This parameter is used to set the functionality of the I5 discrete input terminal.</p> <p>In addition, this input terminal must be specified as Normally Open or Normally Closed.</p> <p>This setting assigns the function of the programmable I5 terminal to any one of the user-selectable functions listed in Table 7 on pg. 236.</p>	<p>Direct Access Number — F117</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Unassigned</p> <p>Changeable During Run — No</p>
<p>Input Terminal 8 (I6) Function</p> <p>Program ⇒ Terminal ⇒ Input Terminals</p> <p>This parameter is used to set the functionality of the I6 discrete input terminal.</p> <p>In addition, this input terminal must be specified as Normally Open or Normally Closed.</p> <p>This setting assigns the function of the programmable I6 terminal to any one of the user-selectable functions listed in Table 7 on pg. 236.</p>	<p>Direct Access Number — F118</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Unassigned</p> <p>Changeable During Run — No</p>
<p>Input Terminal 9 (LI1) Function</p> <p>Program ⇒ Terminal ⇒ Input Terminals</p> <p>This parameter is used to set the functionality of the LI1 discrete input terminal.</p> <p>In addition, this input terminal must be specified as Normally Open or Normally Closed.</p> <p>This setting assigns the function of the programmable LI1 terminal to any one of the user-selectable functions listed in Table 7 on pg. 236.</p> <p><i>Note: The Expansion IO Card Option 1 option board (P/N ETB003Z) is required to use this terminal.</i></p> <p>See the <i>Expansion IO Card Option 1 Instruction Manual</i> (P/N 58685) for additional information on the function of this terminal.</p>	<p>Direct Access Number — F119</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Unassigned</p> <p>Changeable During Run — No</p>

F120

F122

Input Terminal 10 (LI2) Function

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI2** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI2** terminal to any one of the user-selectable functions listed in [Table 7 on pg. 236](#).

Note: *The Expansion IO Card Option 1 option board (P/N ETB003Z) is required to use this terminal.*

See the *Expansion IO Card Option 1 Instruction Manual* (P/N 58685) for additional information on the function of this terminal.

Direct Access Number — F120

Parameter Type — **Selection List**

Factory Default — **Unassigned**

Changeable During Run — **No**

Input Terminal 11 (LI3) Function

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI3** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI3** terminal to any one of the user-selectable functions listed in [Table 7 on pg. 236](#).

Note: *The Expansion IO Card Option 1 option board (P/N ETB003Z) is required to use this terminal.*

See the *Expansion IO Card Option 1 Instruction Manual* (P/N 58685) for additional information on the function of this terminal.

Direct Access Number — F121

Parameter Type — **Selection List**

Factory Default — **Unassigned**

Changeable During Run — **No**

Input Terminal 12 (LI4) Function

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI4** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI4** terminal to any one of the user-selectable functions listed in [Table 7 on pg. 236](#).

Note: *The Expansion IO Card Option 1 option board (P/N ETB003Z) is required to use this terminal.*

See the *Expansion IO Card Option 1 Instruction Manual* (P/N 58685) for additional information on the function of this terminal.

Direct Access Number — F122

Parameter Type — **Selection List**

Factory Default — **Unassigned**

Changeable During Run — **No**

F123

F125

Input Terminal 13 (LI5) Function

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI5** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI5** terminal to any one of the user-selectable functions listed in [Table 7 on pg. 236](#).

Note: *The Expansion IO Card Option 2 option board (P/N ETB004Z) is required to use this terminal.*

See the *Expansion IO Card Option 2 Instruction Manual* (P/N 58686) for additional information on the function of this terminal.

Direct Access Number — F123

Parameter Type — **Selection List**

Factory Default — **Unassigned**

Changeable During Run — **No**

Input Terminal 14 (LI6) Function

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI6** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI6** terminal to any one of the user-selectable functions listed in [Table 7 on pg. 236](#).

Note: *The Expansion IO Card Option 2 option board (P/N ETB004Z) is required to use this terminal.*

See the *Expansion IO Card Option 2 Instruction Manual* (P/N 58686) for additional information on the function of this terminal.

Direct Access Number — F124

Parameter Type — **Selection List**

Factory Default — **Unassigned**

Changeable During Run — **No**

Input Terminal 15 (LI7) Function

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI7** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI7** terminal to any one of the user-selectable functions listed in [Table 7 on pg. 236](#).

Note: *The Expansion IO Card Option 2 option board (P/N ETB004Z) is required to use this terminal.*

See the *Expansion IO Card Option 2 Instruction Manual* (P/N 58686) for additional information on the function of this terminal.

Direct Access Number — F125

Parameter Type — **Selection List**

Factory Default — **Unassigned**

Changeable During Run — **No**

F126

F132

Input Terminal 16 (LI8) Function

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **LI8** discrete input terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **LI8** terminal to any one of the user-selectable functions listed in [Table 7 on pg. 236](#).

Note: The **Expansion IO Card Option 2** option board (P/N ETB004Z) is required to use this terminal.

See the **Expansion IO Card Option 2 Instruction Manual** (P/N 58686) for additional information on the function of this terminal.

Direct Access Number — F126

Parameter Type — Selection List

Factory Default — Unassigned

Changeable During Run — No

Output Terminal 1 (OUT1) Function

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **OUT1** discrete output terminals **OUT1-A** and **OUT1-C**.

The **OUT1-A** to **OUT1-C** output terminals change states (open or close) as a function of a user-selected event. See [Table 10 on pg. 242](#) for listing the possible assignments for the **OUT1** terminals.

In addition, the output terminals must be specified as **Normally Open** or **Normally Closed**.

Direct Access Number — F130

Parameter Type — Selection List

Factory Default — Brake Failure

Changeable During Run — No

Output Terminal 2 (OUT2) Function

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **OUT2** discrete output terminals **OUT2-A** and **OUT2-C**.

The **OUT2-A** to **OUT2-C** output terminals change states (open or close) as a function of a user-selected event. See [Table 10 on pg. 242](#) for listing the possible assignments for the **OUT2** terminals.

In addition, the output terminals must be specified as **Normally Open** or **Normally Closed**.

Direct Access Number — F131

Parameter Type — Selection List

Factory Default — Brake Release

Changeable During Run — No


Output Terminal 3 (BRAKE) Function

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **BRAKE** output terminals (A, B, and C) to one of the functions listed in [Table 10 on pg. 242](#).

In addition, the output terminals must be specified as **Normally Open** or **Normally Closed**.

BRAKE Relay is shown in the de-energized state.



Direct Access Number — F132

Parameter Type — Selection List

Factory Default — Brake Release

Changeable During Run — No

Output Terminal 4 (OUT3) Function

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **OUT3** discrete output terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **OUT3** terminal to any one of the user-selectable functions listed in [Table 10 on pg. 242](#).

Note: The **Expansion IO Card Option 1** option board (P/N ETB003Z) is required to use this terminal.

See the **Expansion IO Card Option 1 Instruction Manual** (P/N 58685) for additional information on the function of this terminal.

Output Terminal 5 (OUT4) Function

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **OUT4** discrete output terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **OUT4** terminal to any one of the user-selectable functions listed in [Table 10 on pg. 242](#).

Note: The **Expansion IO Card Option 1** option board (P/N ETB003Z) is required to use this terminal.

See the **Expansion IO Card Option 1 Instruction Manual** (P/N 58685) for additional information on the function of this terminal.

Output Terminal 6 (R1) Function

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **R1** discrete output terminal.

In addition, this input terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **R1** terminal to any one of the user-selectable functions listed in [Table 10 on pg. 242](#).

Note: The **Expansion IO Card Option 1** option board (P/N ETB003Z) is required to use this terminal.

See the **Expansion IO Card Option 1 Instruction Manual** (P/N 58685) for additional information on the function of this terminal.

Direct Access Number — F133Parameter Type — **Selection List**Factory Default — **Always Off**Changeable During Run — **No****Direct Access Number — F134**Parameter Type — **Selection List**Factory Default — **Always Off**Changeable During Run — **No****Direct Access Number — F135**Parameter Type — **Selection List**Factory Default — **Always Off**Changeable During Run — **No**

F136

F138

Output Terminal 7 (OUT5) Function

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **OUT5** discrete output terminal.

In addition, this output terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **OUT5** terminal to any one of the user-selectable functions listed in [Table 10 on pg. 242](#).

Note: The **Expansion IO Card Option 2** option board (P/N ETB004Z) is required to use this terminal.

See the **Expansion IO Card Option 2 Instruction Manual** (P/N 58686) for additional information on the function of this terminal.

Direct Access Number — F136

Parameter Type — Selection List

Factory Default — Always Off

Changeable During Run — No

Output Terminal 8 (OUT6) Function

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **OUT6** discrete output terminal.

In addition, this output terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **OUT6** terminal to any one of the user-selectable functions listed in [Table 10 on pg. 242](#).

Note: The **Expansion IO Card Option 2** option board (P/N ETB004Z) is required to use this terminal.

See the **Expansion IO Card Option 2 Instruction Manual** (P/N 58686) for additional information on the function of this terminal.

Direct Access Number — F137

Parameter Type — Selection List

Factory Default — Always Off

Changeable During Run — No

Output Terminal 9 (R2) Function

Program ⇒ Terminal ⇒ Output Terminals

This parameter is used to set the functionality of the **R2** discrete output terminal.

In addition, this output terminal must be specified as **Normally Open** or **Normally Closed**.

This setting assigns the function of the programmable **R2** terminal to any one of the user-selectable functions listed in [Table 10 on pg. 242](#).

Note: The **Expansion IO Card Option 2** option board (P/N ETB004Z) is required to use this terminal.

See the **Expansion IO Card Option 2 Instruction Manual** (P/N 58686) for additional information on the function of this terminal.

Direct Access Number — F138

Parameter Type — Selection List

Factory Default — Always Off

Changeable During Run — No


F140

F144

Input Terminal 1 (F) Response Time

Program ⇒ Terminal ⇒ Input Terminal Delays

This parameter delays the response of the ASD to any change in the **F** terminal input by the programmed value.



The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.

Direct Access Number — F140Parameter Type — **Numerical**Factory Default — **8.0**Changeable During Run — **No**

Minimum — 2.0

Maximum — 200.0

Units — mS

Input Terminal 2 (R) Response Time

Program ⇒ Terminal ⇒ Input Terminal Delays

This parameter delays the response of the ASD to any change in the **R** terminal input by the programmed value (see waveforms at F140).

The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.

Direct Access Number — F141Parameter Type — **Numerical**Factory Default — **8.0**Changeable During Run — **No**

Minimum — 2.0

Maximum — 200.0

Units — mS

Input Terminal 3 (I1) Response Time

Program ⇒ Terminal ⇒ Input Terminal Delays

This parameter delays the response of the ASD to any change in the **I1** terminal input by the programmed value (see waveforms at F140).

The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.

Direct Access Number — F142Parameter Type — **Numerical**Factory Default — **8.0**Changeable During Run — **No**

Minimum — 2.0

Maximum — 200.0

Units — mS

Input Terminal 4 (I2) Response Time

Program ⇒ Terminal ⇒ Input Terminal Delays

This parameter delays the response of the ASD to any change in the **I2** terminal input by the programmed value (see waveforms at F140).

The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.

Direct Access Number — F143Parameter Type — **Numerical**Factory Default — **8.0**Changeable During Run — **No**

Minimum — 2.0

Maximum — 200.0

Units — mS

Input Terminal 5 – 12 Response Time

Program ⇒ Terminal ⇒ Input Terminal Delays

This parameter delays the response of the ASD to any change in the **5 – 12** terminal inputs by the programmed value (see waveforms at F140).

The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.

Direct Access Number — F144Parameter Type — **Numerical**Factory Default — **8.0**Changeable During Run — **No**

Minimum — 2.0

Maximum — 200.0

Units — mS

<p>Input Terminal 13 – 20 Response Time</p> <p>Program ⇒ Terminal ⇒ Input Terminal Delays</p> <p>This parameter delays the response of the ASD to any change in the 13 – 20 terminal inputs by the programmed value (see waveforms at F140).</p> <p>The delay may be increased to provide additional electrical noise immunity or to prevent the ASD from responding to contact bounce or chatter.</p>	<p>Direct Access Number — F145</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 8.0</p> <p>Changeable During Run — No</p> <p>Minimum — 2.0</p> <p>Maximum — 200.0</p> <p>Units — mS</p>
<p>Input Terminal 17 (B12) Function</p> <p>Program ⇒ Terminal ⇒ Input Terminals</p> <p>This parameter is used to set the functionality of the B12 discrete input terminal.</p> <p>In addition, this input terminal must be specified as Normally Open or Normally Closed.</p> <p>This setting assigns the function of the programmable B12 terminal to any one of the user-selectable functions listed in Table 7 on pg. 236.</p>	<p>Direct Access Number — F164</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Unassigned</p> <p>Changeable During Run — No</p>
<p>Input Terminal 18 (B13) Function</p> <p>Program ⇒ Terminal ⇒ Input Terminals</p> <p>This parameter is used to set the functionality of the B13 discrete input terminal.</p> <p>In addition, this input terminal must be specified as Normally Open or Normally Closed.</p> <p>This setting assigns the function of the programmable B13 terminal to any one of the user-selectable functions listed in Table 7 on pg. 236.</p>	<p>Direct Access Number — F165</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Unassigned</p> <p>Changeable During Run — No</p>
<p>Input Terminal 19 (B14) Function</p> <p>Program ⇒ Terminal ⇒ Input Terminals</p> <p>This parameter is used to set the functionality of the B14 discrete input terminal.</p> <p>In addition, this input terminal must be specified as Normally Open or Normally Closed.</p> <p>This setting assigns the function of the programmable B14 terminal to any one of the user-selectable functions listed in Table 7 on pg. 236.</p>	<p>Direct Access Number — F166</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Unassigned</p> <p>Changeable During Run — No</p>
<p>Input Terminal 20 (B15) Function</p> <p>Program ⇒ Terminal ⇒ Input Terminals</p> <p>This parameter is used to set the functionality of the B15 discrete input terminal.</p> <p>In addition, this input terminal must be specified as Normally Open or Normally Closed.</p> <p>This setting assigns the function of the programmable B15 terminal to any one of the user-selectable functions listed in Table 7 on pg. 236.</p>	<p>Direct Access Number — F167</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Unassigned</p> <p>Changeable During Run — No</p>

F168

F172

<p>Output Terminal 10 (R3) Function</p> <p>Program ⇒ Terminal ⇒ Output Terminals</p> <p>This parameter is used to set the functionality of the R3 discrete output terminal.</p> <p>In addition, this input terminal must be specified as Normally Open or Normally Closed.</p> <p>This setting assigns the function of the programmable R3 terminal to any one of the user-selectable functions listed in Table 10 on pg. 242.</p>	<p>Direct Access Number — F168</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Off</p> <p>Changeable During Run — No</p>
<p>Output Terminal 11 (R4) Function</p> <p>Program ⇒ Terminal ⇒ Output Terminals</p> <p>This parameter is used to set the functionality of the R4 discrete output terminal.</p> <p>In addition, this input terminal must be specified as Normally Open or Normally Closed.</p> <p>This setting assigns the function of the programmable R4 terminal to any one of the user-selectable functions listed in Table 10 on pg. 242.</p>	<p>Direct Access Number — F169</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Off</p> <p>Changeable During Run — No</p>
<p>Base Frequency 2</p> <p>Program ⇒ Motor ⇒ Motor Set 2</p> <p>The Base Frequency 2 setting is the frequency at which the output voltage of the ASD reaches its maximum setting. The Base Frequency Voltage 2 parameter is set at F171.</p> <p>This parameter is used only when the parameters for motor set 2 are configured and selected. Motor set 2 may be selected by a properly configured input terminal (see Table 7 on pg. 236).</p> <p>For proper motor operation, the Base Frequency should be set for the nameplate frequency of the motor.</p>	<p>Direct Access Number — F170</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 60.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 25.0</p> <p>Maximum — 299.0</p> <p>Units — Hz</p>
<p>Base Frequency Voltage 2</p> <p>Program ⇒ Motor ⇒ Motor Set 2</p> <p>The Base Frequency Voltage 2 setting is the Motor #2 output voltage at the Base Frequency (F170). Regardless of the programmed value, the output voltage cannot be higher than the input voltage.</p> <p>The actual output voltage will be influenced by the input voltage of the ASD and the Supply Voltage Compensation setting (F307).</p> <p>This parameter is used only when the parameters for motor set 2 are configured and selected. Motor set 2 may be selected by a properly configured input terminal (see Table 7 on pg. 236).</p>	<p>Direct Access Number — F171</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 50.0</p> <p>Maximum — 660.0</p> <p>Units — Volts</p>
<p>Manual Torque Boost 2</p> <p>Program ⇒ Motor ⇒ Motor Set 2</p> <p>The Manual Torque Boost 2 function is used to increase the low frequency torque for high inertia loads by increasing the output voltage at frequencies below ½ of the Base Frequency 2 setting (F170).</p> <p>See parameter F016 (Manual Torque Boost 1) for an explanation of torque boost.</p> <p>This parameter is used only when the parameters for motor set 2 are configured and selected. Motor set 2 may be selected by a properly configured input terminal (see Table 7 on pg. 236).</p>	<p>Direct Access Number — F172</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — 30.0</p> <p>Units — %</p>

F173

F176

Motor Overload Protection Level 2

Program ⇒ Motor ⇒ Motor Set 2

The **Motor Overload Protection Level 2** parameter specifies the motor overload current level for motor set 2. This value is entered as either a percentage of the full-load rating of the ASD or as the FLA of the motor.

The unit of measurement for this parameter may be set to **Amps** (A/V) or it may be set as a percentage of the ASD rating. The nameplate FLA of the motor may be entered directly when **Amps** is selected as the unit of measurement (see F701 to change the display unit).

The **Motor 2 Overload Protection Level** setting will be displayed in **Amps** if the **EOI** display units are set to **A/V** rather than **%**.

Direct Access Number — F173

Parameter Type — **Numerical**

Factory Default — **100**

Changeable During Run — **Yes**

Minimum — 10

Maximum — 100

Units — %

Base Frequency 3

Program ⇒ Motor ⇒ Motor Set 3

The **Base Frequency 3** setting is the frequency at which the output voltage of the ASD reaches its maximum setting. The **Base Frequency Voltage 3** parameter is set at F175.

This parameter is used only when the parameters for motor set 3 are configured and selected. Motor set 3 may be selected by a properly configured input terminal (see Table 7 on pg. 236).

For proper motor operation, the **Base Frequency** should be set for the nameplate frequency of the motor.

Direct Access Number — F174

Parameter Type — **Numerical**

Factory Default — **60.0**

Changeable During Run — **Yes**

Minimum — 25.0

Maximum — 299.0

Units — Hz

Base Frequency Voltage 3

Program ⇒ Motor ⇒ Motor Set 3

The **Base Frequency Voltage 3** setting is the **Motor #3** output voltage at the **Base Frequency** (F174). Regardless of the programmed value, the output voltage cannot be higher than the input voltage.

The actual output voltage will be influenced by the input voltage of the ASD and the **Supply Voltage Compensation** setting (F307).

This parameter is used only when the parameters for motor set 3 are configured and selected. Motor set 3 may be selected by a properly configured input terminal (see Table 7 on pg. 236).

Direct Access Number — F175

Parameter Type — **Numerical**

Factory Default — (ASD-Dependent)

Changeable During Run — **Yes**

Minimum — 50.0

Maximum — 660.0

Units — Volts

Manual Torque Boost 3

Program ⇒ Motor ⇒ Motor Set 3

The **Manual Torque Boost 3** function is used to increase the low frequency torque for high inertia loads by increasing the output voltage at frequencies below ½ of the **Base Frequency 3** setting (F174).

See parameter F016 (**Manual Torque Boost 1**) for an explanation of torque boost.

This parameter is used only when the parameters for motor set 3 are configured and selected. Motor set 3 may be selected by a properly configured input terminal (see Table 7 on pg. 236).

Direct Access Number — F176

Parameter Type — **Numerical**

Factory Default — (ASD-Dependent)

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 30.0

Units — %

F177

F180

<p>Motor Overload Protection Level 3</p> <p>Program ⇒ Motor ⇒ Motor Set 3</p> <p>The Motor Overload Protection Level 3 parameter specifies the motor overload current level for motor set 3. This value is entered as either a percentage of the full-load rating of the ASD or as the FLA of the motor.</p> <p>The unit of measurement for this parameter may be set to Amps (A/V) or it may be set as a percentage of the ASD rating. The nameplate FLA of the motor may be entered directly when Amps is selected as the unit of measurement (see F701 to change the display unit).</p> <p>The Motor Overload Protection Level 3 setting will be displayed in Amps if the EOI display units are set to A/V rather than %.</p>	<p>Direct Access Number — F177</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 100.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 10</p> <p>Maximum — 100</p> <p>Units — %</p>
<p>Base Frequency 4</p> <p>Program ⇒ Motor ⇒ Motor Set 4</p> <p>The Base Frequency 4 setting is the frequency at which the output voltage of the ASD reaches its maximum setting. The Base Frequency Voltage 4 parameter is set at F179.</p> <p>This parameter is used only when the parameters for motor set 4 are configured and selected. Motor set 4 may be selected by a properly configured input terminal (see Table 7 on pg. 236).</p> <p>For proper motor operation, the Base Frequency should be set for the nameplate frequency of the motor.</p>	<p>Direct Access Number — F178</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 60.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 25.00</p> <p>Maximum — 299.0</p> <p>Units — Hz</p>
<p>Base Frequency Voltage 4</p> <p>Program ⇒ Motor ⇒ Motor Set 4</p> <p>The Base Frequency Voltage 4 is the Motor 4 output voltage at the Base Frequency (F178). Regardless of the programmed value, the output voltage cannot be higher than the input voltage.</p> <p>The actual output voltage will be influenced by the input voltage of the ASD and the Supply Voltage Compensation setting (F307).</p> <p>This parameter is used only when the parameters for motor set 4 are configured and selected. Motor set 4 may be selected by a properly configured input terminal (see Table 7 on pg. 236).</p>	<p>Direct Access Number — F179</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 50.0</p> <p>Maximum — 660.0</p> <p>Units — Volts</p>
<p>Manual Torque Boost 4</p> <p>Program ⇒ Motor ⇒ Motor Set 4</p> <p>The Manual Torque Boost 4 function is used to increase the low frequency torque for high inertia loads by increasing the output voltage at frequencies below ½ of the Base Frequency 4 setting (F178).</p> <p>See parameter F016 (Manual Torque Boost 1) for an explanation of torque boost.</p> <p>This parameter is used only when the parameters for motor set 4 are configured and selected. Motor set 4 may be selected by a properly configured input terminal (see Table 7 on pg. 236).</p>	<p>Direct Access Number — F180</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — 30.0</p> <p>Units — %</p>

F181

F190

Overload Protection Level 4

Program ⇒ Motor ⇒ Motor Set 4

The **Motor 4 Overload Protection Level** parameter specifies the motor overload current level for motor set 4. This value is entered as either a percentage of the full-load rating of the ASD or as the FLA of the motor.

The unit of measurement for this parameter may be set to **Amps** (A/V) or it may be set as a percentage of the ASD rating. The nameplate FLA of the motor may be entered directly when **Amps** is selected as the unit of measurement (see F701 to change the display unit).

The **Motor 4 Overload Protection Level** setting will be displayed in **Amps** if the EOI display units are set to **A/V** rather than **%**.

Direct Access Number — F181Parameter Type — **Numerical**Factory Default — **100.0**Changeable During Run — **Yes**

Minimum — 10

Maximum — 100

Units — %

V/f 5-Point Setting Frequency 1

Program ⇒ Special ⇒ V/f 5-Point Setting

The **V/f 5-Point Setting Frequency 1** setting establishes the frequency that is to be associated with the voltage setting of F191 (V/f 5-Point Setting Voltage 1).

The **V/f 5-Point** settings define a custom volts per hertz relationship for the startup output of the ASD.

To enable this function, set the **V/f Pattern** (F015) selection to the **V/f 5-Point Curve** setting.


Custom **V/f Curves** may be useful in starting high inertia loads such as rotary drum vacuum filters.

Direct Access Number — F190Parameter Type — **Numerical**Factory Default — **0.00**Changeable During Run — **No**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz



F191

F192

V/f 5-Point Setting Voltage 1

Program ⇒ Special ⇒ V/f 5-Point Setting

The **V/f 5-Point Setting Voltage 1** establishes the output voltage level that is to be associated with the frequency setting of **F190** (V/f 5-Point Setting Frequency 1).


The **F701** parameter setting will determine if the on-screen selection for this parameter appears in the form of a voltage (V) or as a percentage (%) of the ASD rating.

If using **Voltage** as a unit of measure and with no voltage correction (**F307** Disabled), the limit of the on-screen display value for this parameter is 200 volts for the 230-volt ASD and 400 Volts for the 460-volt ASD.

The actual output voltage is scaled to the maximum **EOI** display values (e.g., a 100-volt **EOI** display corresponds to a 115-volt actual output for the 230-volt ASD — ½ of the full display range).

If using **%** as a unit of measure and with no voltage correction (**F307** Disabled), the ASD output voltage will be the percentage setting times 230 for the 230-volt unit (or % times 460 Volts for the 460-volt unit).

See **F190** for additional information on this setting.



Direct Access Number — F191

Parameter Type — Numerical

Factory Default — 0.0

Changeable During Run — No

Minimum — 0.0

Maximum — 100.0

Units — V or % (F701)

V/f 5-Point Setting Frequency 2

Program ⇒ Special ⇒ V/f 5-Point Setting

The **Custom V/f 5-Point Setting Frequency 2** sets the frequency to be associated with the voltage setting of parameter **F193** (V/f 5-Point Setting Voltage 2).

See **F190** and **F191** for additional information on this setting.

Direct Access Number — F192

Parameter Type — Numerical

Factory Default — 0.00

Changeable During Run — No

Minimum — 0.00

Maximum — Max. Freq. (F011)

Units — Hz

F193

F197

<p>V/f 5-Point Setting Voltage 2</p> <p>Program ⇒ Special ⇒ V/f 5-Point Setting</p> <p>The V/f 5-Point Setting Voltage 2 establishes the output voltage level that is to be associated with the frequency setting of F192 (V/f 5-Point Setting Frequency 2).</p> <p>The F701 parameter setting will determine if the selection for this parameter appears in the form of a Voltage (V) or as a Percentage (%) of the ASD rating. The default setting is %.</p> <p>See F190 and F191 for additional information on this setting.</p>	<p>Direct Access Number — F193</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.0</p> <p>Changeable During Run — No</p> <p>Minimum — 0.0</p> <p>Maximum — 100.0</p> <p>Units — V or % (F701)</p>
<p>V/f 5-Point Setting Frequency 3</p> <p>Program ⇒ Special ⇒ V/f 5-Point Setting</p> <p>The Custom V/f 5-Point Setting Frequency 3 sets the frequency to be associated with the voltage setting of parameter F195 (V/f 5-Point Setting Voltage 3).</p> <p>See F190 and F191 for additional information on this setting.</p>	<p>Direct Access Number — F194</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — No</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>V/f 5-Point Setting Voltage 3</p> <p>Program ⇒ Special ⇒ V/f 5-Point Setting</p> <p>The V/f 5-Point Setting Voltage 3 establishes the output voltage level that is to be associated with the frequency setting of F194 (V/f 5-Point Setting Frequency 3).</p> <p>The F701 parameter setting will determine if the selection for this parameter appears in the form of a Voltage (V) or as a Percentage (%) of the ASD rating. The default setting is %.</p> <p>See F190 and F191 for additional information on this setting.</p>	<p>Direct Access Number — F195</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.0</p> <p>Changeable During Run — No</p> <p>Minimum — 0.0</p> <p>Maximum — 100.0</p> <p>Units — V or % (F701)</p>
<p>V/f 5-Point Setting Frequency 4</p> <p>Program ⇒ Special ⇒ V/f 5-Point Setting</p> <p>The Custom V/f 5-Point Setting Frequency 4 sets the frequency to be associated with the voltage setting of parameter F197 (V/f 5-Point Setting Voltage 4).</p> <p>See F190 and F191 for additional information on this setting.</p>	<p>Direct Access Number — F196</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — No</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>V/f 5-Point Setting Voltage 4</p> <p>Program ⇒ Special ⇒ V/f 5-Point Setting</p> <p>The V/f 5-Point Setting Voltage 4 establishes the output voltage level that is to be associated with the frequency setting of F196 (V/f 5-Point Setting Frequency 4).</p> <p>The F701 parameter setting will determine if the selection for this parameter appears in the form of a Voltage (V) or as a Percentage (%) of the ASD rating. The default setting is %.</p> <p>See F190 and F191 for additional information on this setting.</p>	<p>Direct Access Number — F197</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.0</p> <p>Changeable During Run — No</p> <p>Minimum — 0.0</p> <p>Maximum — 100.0</p> <p>Units — V or % (F701)</p>

F198

F200

V/f 5-Point Setting Frequency 5

Program ⇒ Special ⇒ V/f 5-Point Setting

The **Custom V/f 5-Point Setting Frequency 5** sets the frequency to be associated with the voltage setting of parameter **F199** (V/f 5-Point Setting Voltage 5).

See **F190** and **F191** for additional information on this setting.

V/f 5-Point Setting Voltage 5

Program ⇒ Special ⇒ V/f 5-Point Setting

The **V/f 5-Point Setting Voltage 5** establishes the output voltage level that is to be associated with the frequency setting of **F198** (V/f 5-Point Setting Frequency 5).

The **F701** parameter setting will determine if the selection for this parameter appears in the form of a Voltage (V) or as a Percentage (%) of the ASD rating.

The default setting is %.

See **F190** and **F191** for additional information on this setting.

Frequency Priority Selection

Program ⇒ Fundamental ⇒ Standard Mode Selection

Either **Frequency Mode 1** or **Frequency Mode 2** may control the output frequency of the ASD. This parameter determines which of the two will control the output frequency and the conditions in which control will be switched from one to the other.

Note: *Frequency Mode is abbreviated as FMOD.*

Settings:

- FMOD changed by Terminal Board (ACE G9-120V-PCB)
- FMOD (**F208**)

The **Frequency Mode 1** or **Frequency Mode 2** selection specifies the source of the input frequency command signal. These selections are performed at **F004** and **F207**, respectively.

If **FMOD changed by Terminal Board** is selected here, the ASD will follow the control of the discrete input terminal assigned the function of **Frequency Priority**. The discrete terminal **Frequency Priority** will toggle control to and from **Frequency Mode 1** and **Frequency Mode 2** with each activation/deactivation.

If **FMOD (F208)** is selected here, the ASD will follow the control of the **Frequency Mode 1** setting for the duration that the commanded frequency of the **Frequency Mode 1** setting is greater than the setting of **F208**.

If the commanded frequency of the **Frequency Mode 1** setting is less than or equal to the setting of **F208** the ASD will follow the setting of **Frequency Mode 2**.

Direct Access Number — F198

Parameter Type — Numerical

Factory Default — 0.00

Changeable During Run — No

Minimum — 0.00

Maximum — Max. Freq. (F011)

Units — Hz

Direct Access Number — F199

Parameter Type — Numerical

Factory Default — 0.0

Changeable During Run — No

Minimum — 0.0

Maximum — 100.0


Units — V or % (F701)

Direct Access Number — F200

Parameter Type — Selection List

Factory Default — FMOD (changed by TB)

Changeable During Run — Yes



If the frequency command of Frequency Mode 1 is greater than the F208 setting, Frequency Mode 1 has priority over Frequency Mode 2. If the frequency command of Frequency Mode 1 is equal to or less than the F208 setting, Frequency Mode 2 has priority.

V/I Input Point 1 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the isolated V/I input terminal when the V/I terminal is used as the control input while operating in the **Speed Control** mode or the **Torque Control** mode.

This parameter sets the V/I input level that is associated with the **V/I Input Point 1 Frequency (F202)** setting when operating in the **Speed** control mode or is associated with the **V/I Input Point 1 Rate (F205)** setting when operating in the **Torque Control** mode.

Note: See note on pg. 55 for additional information on the V/I terminal.

V/I Input Speed Control Setup

Perform the following setup to allow the system to receive **Speed** control input at the V/I input terminal:

- Set SW2 of the ACE G9-120V-PCB to **Voltage** or **Current** (see Figure 8 on pg. 24).
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ V/I.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Board**.

Speed Control

Perform the following setup to allow the system to perform **Speed** control from the V/I input terminal:

- Set **V/I Input Point 1 Frequency (F202)**.
- Set **V/I Input Point 1 Setting (F201)** — the input analog signal level that corresponds to the frequency setting at **V/I Input Point 1 Frequency**.
- Set **V/I Input Point 2 Frequency (F204)**.
- Set **V/I Input Point 2 Setting (F203)** — the input analog signal level that corresponds to the frequency setting at **V/I Input Point 2 Frequency**.
- Provide a **Run** command (F and/or R).

Once set, as the V/I input voltage or current changes, the output frequency of the ASD will vary in accordance with the above settings.

This parameter value is entered as 0% to 100% of the V/I input signal range.

The V/I input is commonly used for a 4 – 20 mA current loop signal where 4 mA equals 20% of a 20 mA signal. Set this parameter to 20% for 4 – 20 mA current loop signal applications.

Note: When using the isolated V/I input terminal the **IICC** terminal must be used as the return (negative) connection.

Direct Access Number — F201

Parameter Type — Numerical

Factory Default — 0


Changeable During Run — Yes

Minimum — 0

Maximum — 100

Units — %

Frequency Settings



F202

F204

<p>V/I Input Point 1 Frequency</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to set the gain and bias of the V/I input terminal when the V/I terminal is used as the control input while operating in the Speed Control mode.</p> <p>This parameter sets V/I Input Point 1 Frequency (F202) and is the frequency that is associated with the setting of V/I Input Point 1 Setting (F201) when operating in the Speed Control mode.</p> <p>See V/I Input Point 1 Setting (F201) for additional information on this setting.</p>	<p>Direct Access Number — F202</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>V/I Input Point 2 Setting</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to set the gain and bias of the V/I input terminal when the V/I terminal is used as the control input while operating in the Speed Control mode or the Torque Control mode.</p> <p>This parameter sets the V/I input level that is associated with V/I Input Point 2 Frequency (F204) when operating in the Speed control mode or is associated with the V/I Input Point 1 Rate (F205) when operating in the Torque Control mode.</p> <p>This value is entered as 0% to 100% of the V/I input signal range.</p> <p>See V/I Input Point 1 Setting (F201) for additional information on this setting when used for Speed control.</p> <p>See V/I Input Point 1 Rate (F205) for additional information on this setting when used for Torque Control.</p>	<p>Direct Access Number — F203</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 100</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 100</p> <p>Units — %</p>
<p>V/I Input Point 2 Frequency</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to set the gain and bias of the V/I input terminal when the V/I terminal is used as the control input while operating in the Speed Control mode.</p> <p>This parameter sets V/I Input Point 2 Frequency and is the frequency that is associated with the setting of V/I Input Point 2 Setting (F203) when operating in the Speed Control mode.</p> <p>See V/I Input Point 1 Setting (F201) for additional information on this setting.</p>	<p>Direct Access Number — F204</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 60.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>

V/I Input Point 1 Rate

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the isolated V/I input terminal when the V/I terminal is used as the control input while operating in the **Torque Control** mode.

V/I Input Torque Control Setup

Perform the following setup to allow the system to receive **Torque Control** input at the V/I input terminal:

- Set **SW2** of the **ACE G9-120V-PCB** to **Voltage** or **Current** (see [Figure 8](#) on [pg. 24](#)).
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ **V/I**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Board**.

Torque Control

Perform the following setup to allow the system to perform **Torque Control** from the V/I input terminal:

- Set **V/I Input Point 1 Rate (F205)**.
- Set **V/I Input Point 1 Setting (F201)** — the input analog signal level that corresponds to the torque setting at **V/I Input Point 1 Rate**.
- Set **V/I Input Point 2 Rate (F206)**.
- Set **V/I Input Point 2 Setting (F203)** — the input analog signal level that corresponds to the torque setting at **V/I Input Point 2 Rate**.
- Provide a **Run** command (F and/or R).

Torque Control is accomplished by establishing an associated **V/f** output pattern for a given V/I input level.

Once set, as the V/I input voltage changes or the V/I current changes, the output torque of the ASD will vary in accordance with the above settings.

This parameter sets **V/I Input Point 1 Rate** and is the output torque value that is associated with the setting of **V/I Input Point 1 Setting** when operating in the **Torque Control** mode.

This value is entered as 0% to 250% of the rated torque.

Note: When using the isolated V/I input terminal the **IICC** terminal must be used as the return (negative) connection.

Direct Access Number — **F205**

Parameter Type — **Numerical**


Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 250.00

Units — %



F206

F208

V/I Input Point 2 Rate

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **V/I** input terminal when the **V/I** terminal is used as the control input while operating in the **Torque Control** mode.

Torque Control is accomplished by establishing an associated **V/f** output pattern for a given **V/I** input level.

This parameter sets **V/I Input Point 2 Rate** and is the output torque value that is associated with the setting of **V/I Input Point 2 Setting (F203)** when operating in the **Torque Control** mode.

This value is entered as 0% to 250% of the rated torque.

See **V/I Input Point 1 Rate (F205)** for additional information on this setting.

Direct Access Number — F206

Parameter Type — **Numerical**

Factory Default — **100.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 250.00

Units — %

Frequency Mode 2

Program ⇒ Fundamental ⇒ Standard Mode Selection

This parameter is used to set the source of the frequency command signal to be used as **Frequency Mode 2** in the event that **Frequency Mode 1** is disabled or if **Frequency Mode 2** is set up as the primary control parameter.

See **F004** and **F200** for additional information on this setting.

Settings:

V/I

RR

RX

EOI Keypad

RS485

Communication Option Board

RX2 Option (AI1)

Option V/I

UP/DOWN Frequency (ACE G9-120V-PCB)

Pulse Input (Option)

Pulse Input (Motor CPU)

Binary/BCD Input (Option)

Direct Access Number — F207

Parameter Type — **Selection List**

Factory Default — **V/I**

Changeable During Run — **Yes**

Frequency Mode Priority Switching Frequency

Program ⇒ Fundamental ⇒ Standard Mode Selection

This parameter establishes a threshold frequency that will be used as a reference when determining when to switch the output frequency control source from the **Frequency Mode 1** setting to the **Frequency Mode 2** setting.

See **F200** for additional information on this setting.

Direct Access Number — F208

Parameter Type — **Numerical**

Factory Default — **0.10**

Changeable During Run — **Yes**

Minimum — 0.10

Maximum — **Max. Freq. (F011)**

Units — Hz

Analog Input Filter

Program ⇒ Frequency ⇒ Analog Filter

Analog filtering is applied after the analog reference signal is converted to a digital signal. The type of filtering used is **Rolling Average** over time.

Settings:

- None (1 mS)
- Small (8 mS)
- Medium (16 mS)
- Large (32 mS)
- Huge (64 mS)

The analog input signal is sampled and converted to a digital signal. With no filtering applied, the resulting digital value is scaled for use by the microprocessor of the ASD.

If the filtering selection **Small** is selected, the ASD averages the last **8 mS** of sampled signal and converted (digital) values. The rolling average is updated (every 4 μ S) and scaled for use by the microprocessor.

This holds true for the **Medium**, **Large**, and **Huge** selections providing a larger sample to produce the average for use by the microprocessor.

False responses to electrical noise are eliminated with no loss in bandwidth because the value used by the ASD is the average value of several samples.

Direct Access Number — F209Parameter Type — **Selection List**Factory Default — **None**Changeable During Run — **Yes**

F210

F211

RR Input Point 1 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Speed Control** mode or the **Torque Control** mode.

This parameter sets the **RR** input level that is associated with the **RR Input Point 1 Frequency** setting when operating in the **Speed** control mode or is associated with the **RR Input Point 1 Rate** (F214) setting when operating in the **Torque Control** mode.

Speed Control

Perform the following setup to allow the system to perform **Speed** control from the **RR** input terminal:

- Set **RR Input Point 1 Frequency** (F211).
- Set **RR Input Point 1 Setting** (F210) — the input analog signal level that corresponds to the frequency setting at **RR Input Point 1 Frequency**.
- Set **RR Input Point 2 Frequency** (F213).
- Set **RR Input Point 2 Setting** (F212) — the input analog signal level that corresponds to the frequency setting at **RR Input Point 2 Frequency**.

RR Input Speed Control Setup

Perform the following setup to allow the system to receive **Speed** control input at the **RR** input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ **RR**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Board**.
- Provide a **Run** command (F and/or R).

Once set, as the **RR** input voltage changes, the output frequency of the ASD will vary in accordance with the above settings.

This parameter value is entered as 0% to 100% of the **RR** input signal range.

RR Input Point 1 Frequency

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Speed Control** mode.

This parameter sets **RR Input Point 1 Frequency** and is the frequency that is associated with the setting of **RR Input Point 1 Setting** (F210) when operating in the **Speed Control** mode.

See **RR Input Point 1 Setting** (F210) for additional information on this setting.

Direct Access Number — F210

Parameter Type — Numerical


Factory Default — 0

Changeable During Run — Yes

Minimum — 0

Maximum — 100

Units — %

Frequency Settings

Direct Access Number — F211

Parameter Type — Numerical

Factory Default — 0.00

Changeable During Run — Yes

Minimum — 0.00

Maximum — **Max. Freq.** (F011)

Units — Hz

F212**F213****RR Input Point 2 Setting**

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Speed Control** mode or the **Torque Control** mode.

This parameter sets the **RR** input level that is associated with **RR Input Point 2 Frequency (F213)** when operating in the **Speed** control mode or is associated with the **RR Input Point 1 Rate (F214)** when operating in the **Torque Control** mode.

This value is entered as 0% to 100% of the **RR** input signal range.

See **RR Input Point 1 Setting (F210)** for additional information on this setting when used for **Speed** control.

See **RR Input Point 1 Rate (F214)** for additional information on this setting when used for **Torque Control**.

Direct Access Number — F212

Parameter Type — **Numerical**

Factory Default — **100**

Changeable During Run — **Yes**

Minimum — 0

Maximum — 100

Units — %

RR Input Point 2 Frequency

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Speed Control** mode.

This parameter sets **RR Input Point 2 Frequency** and is the frequency that is associated with the setting of **RR Input Point 2 Setting (F212)** when operating in the **Speed Control** mode.

See **RR Input Point 1 Setting (F210)** for additional information on this setting.

Direct Access Number — F213

Parameter Type — **Numerical**

Factory Default — **60.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

F214

F215

RR Input Point 1 Rate

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Torque Control** mode.

RR Input Torque Control Setup

Perform the following setup to allow the system to receive **Torque Control** input at the **RR** input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode ⇒ **RR**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Board**.

Torque Control

Perform the following setup to allow the system to perform **Torque Control** from the **RR** input terminal:

- Set **RR Input Point 1 Rate** (F214).
- Set **RR Input Point 1 Setting** (F210) — the input analog signal level that corresponds to the torque setting at **RR Input Point 1 Rate**.
- Set **RR Input Point 2 Rate** (F215).
- Set **RR Input Point 2 Setting** (F212) — the input analog signal level that corresponds to the frequency setting at **RR Input Point 2 Rate**.
- Provide a **Run** command (F and/or R).

Torque Control is accomplished by establishing an associated **V/f** output pattern for a given **RR** input level.

Once set, as the **RR** input voltage changes, the output torque of the ASD will vary in accordance with the above settings.

This parameter sets **RR Input Point 1 Rate** and is the output torque value that is associated with the setting of **RR Input Point 1 Setting** when operating in the **Torque Control** mode.

This value is entered as 0% to 250% of the rated torque.

RR Input Point 2 Rate

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **RR** input terminal when the **RR** terminal is used as the control input while operating in the **Torque Control** mode.

Torque Control is accomplished by establishing an associated **V/f** output pattern for a given **RR** input level.

This parameter sets **RR Input Point 2 Rate** and is the output torque value that is associated with the setting of **RR Input Point 2 Setting** (F212) when operating in the **Torque Control** mode.

This value is entered as 0% to 250% of the rated torque.


See **RR Input Point 1 Rate** (F214) for additional information on this setting.

Direct Access Number — F214Parameter Type — **Numerical**Factory Default — **0.00**Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 250.00

Units — %

**Direct Access Number — F215**Parameter Type — **Numerical**Factory Default — **100.00**Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 250.00

Units — %

F216

F217

RX Input Point 1 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Speed Control** mode or the **Torque Control** mode.

This parameter sets the **RX** input level that is associated with **RX Input Point 1 Frequency** when operating in the **Speed Control** mode or is associated with the **RX Input Point 1 Rate (F220)** when operating in the **Torque Control** mode.

RX Input Speed Control Setup

Perform the following setup to allow the system to receive **Speed** control input at the **RX** input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ **RX**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Board**.

Speed Control

Perform the following setup to allow the system to perform **Speed** control from the **RX** input terminal:

- Set **RX Input Point 1 Frequency (F217)**.
- Set **RX Input Point 1 Setting (F216)** — the input analog signal level that corresponds to the speed setting at **RX Input Point 1 Frequency**.
- Set **RX Input Point 2 Frequency (F219)**.
- Set **RX Input Point 2 Setting (F218)** — the input analog signal level that corresponds to the speed setting at **RX Input Point 2 Frequency**.
- Provide a **Run** command (F and/or R).

Once set, as the **RX** input voltage changes, the ASD output speed and/or torque will vary in accordance with the above settings.

This parameter value is entered as -100% to +100% of the **RX** input signal range.

See parameter [F474](#) and [F475](#) for information on fine-tuning this terminal response.

RX Input Point 1 Frequency

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Speed Control** mode.

This parameter sets **RX Input Point 1 Frequency** and is the frequency that is associated with the setting of **RX Input Point 1 Setting (F216)** when operating in the **Speed Control** mode.

See **RX Input Point 1 Setting (F216)** for additional information on this setting.

Direct Access Number — F216

Parameter Type — Numerical


Factory Default — 0

Changeable During Run — Yes

Minimum — -100

Maximum — +100

Units — %



Direct Access Number — F217

Parameter Type — Numerical

Factory Default — 0.00

Changeable During Run — Yes

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

F218**F219****RX Input Point 2 Setting**

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Speed Control** mode or the **Torque Control** mode.

This parameter sets the **RX** input level that is associated with **RX Input Point 2 Frequency (F219)** when operating in the **Speed** control mode or is associated with the **RX Input Point 2 Rate (F221)** when operating in the **Torque Control** mode.

This value is entered as -100% to +100% of the **RX** input signal range.

See **RX Input Point 1 Setting (F216)** for additional information on this setting when used for **Speed** control.

See **RX Input Point 1 Rate (F220)** for additional information on this setting when used for **Torque Control**.

Direct Access Number — F218

Parameter Type — **Numerical**

Factory Default — **+100**

Changeable During Run — **Yes**

Minimum — -100.0

Maximum — +100.0

Units — %

RX Input Point 2 Frequency

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Speed Control** mode.

This parameter sets **RX Input Point 2 Frequency** and is the frequency that is associated with the setting of **RX Input Point 2 Setting (F218)** when operating in the **Speed Control** mode.

See **RX Input Point 1 Setting (F216)** for additional information on this setting.

Direct Access Number — F219

Parameter Type — **Numerical**

Factory Default — **60.00**

Changeable During Run — **Yes**

Minimum — 0.00.

Maximum — **Max. Freq. (F011)**

Units — Hz

F220

RX Input Point 1 Rate

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Torque Control** mode.

RX Input Torque Control Setup

Perform the following setup to allow the system to receive **Torque Control** input at the **RX** input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode ⇒ **RX**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Board**.

Torque Control

Perform the following setup to allow the system to perform **Torque Control** from the **RX** input terminal:

- Set **RX Input Point 1 Rate** (F220).
- Set **RX Input Point 1 Setting** (F216) — the input analog signal level that corresponds to the torque setting at **RX Input Point 1 Rate**.
- Set **RX Input Point 2 Rate** (F221).
- Set **RX Input Point 2 Setting** (F218) — the input analog signal level that corresponds to the speed setting at **RX Input Point 2 Rate** (F221).
- Provide a **Run** command (F and/or R).

Torque Control is accomplished by establishing an associated **V/f** output pattern for a given **RX** input level.

Once set, as the **RX** input voltage changes, the ASD output speed and/or torque will vary in accordance with the above settings.

This parameter sets **RX Input Point 1 Rate** and is the output torque value that is associated with the setting of **RX Input Point 1 Setting** when operating in the **Torque Control** mode.

This value is entered as -250% to +250% of the rated torque.

RX Input Point 2 Rate

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **RX** input terminal when the **RX** terminal is used as the control input while operating in the **Torque Control** mode.

Torque Control is accomplished by establishing an associated **V/f** output pattern for a given **RX** input level.

This parameter sets **RX Input Point 2 Rate** and is the output torque value that is associated with the setting of **RX Input Point 2 Setting** (F218) when operating in the **Torque Control** mode.

This value is entered as -250% to +250% of the rated torque.

See **RX Input Point 1 Rate** (F220) for additional information on this setting.

Direct Access Number — F220

Parameter Type — Numerical


Factory Default — 0.00

Changeable During Run — Yes

Minimum — -250.00

Maximum — +250.00

Units — %



Direct Access Number — F221

Parameter Type — Numerical

Factory Default — 100.00

Changeable During Run — Yes

Minimum — -250.00

Maximum — +250.00

Units — %

RX2 Option (AI1) Input Point 1 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **RX2** (AI1) input terminal when the **RX2** (AI1) terminal is used as the control input while operating in the **Speed Control** mode or the **Torque Control** mode.

Note: *The Expansion IO Card Option 1 option board (P/N ETB003Z) is required to use this terminal.*

This parameter sets the **RX2** (AI1) input level that is associated with **RX2** (AI1) **Input Point 1 Frequency** when operating in the **Speed Control** mode or is associated with the **RX2** (AI1) **Input Point 1 Rate** when operating in the **Torque Control** mode.

RX2 (AI1) Input Speed Control Setup

Perform the following setup to allow the system to receive **Speed** control input at the **RX2** (AI1) input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ **RX2**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Board**.

Speed Control

Perform the following setup to allow the system to perform **Speed** control from the **RX2** (AI1) input terminal:

- Set **RX2** (AI1) **Input Point 1 Frequency** (F223).
- Set **RX2** (AI1) **Input Point 1 Setting** (F222) — the input analog signal level that corresponds to the speed setting at **RX2** (AI1) **Input Point 1 Frequency**.
- Set **RX2** (AI1) **Input Point 2 Frequency** (F225).
- Set **RX2** (AI1) **Input Point 2 Setting** (F224) — the input analog signal level that corresponds to the speed setting at **RX2** **Input Point 2 Frequency**.
- Provide a **Run** command (F and/or R).

Once set, as the **RX2** (AI1) input voltage changes, the ASD output speed and/or torque will vary in accordance with the above settings.

This parameter value is entered as -100% to +100% of the **RX2** (AI1) input signal range.

See the *Expansion IO Card Option 1 Instruction Manual* (P/N 58685) for additional information on the function of this terminal.

See parameter **F476** and **F477** for information on fine-tuning the responsiveness of this terminal.

Direct Access Number — F222

Parameter Type — Numerical


Factory Default — 0

Changeable During Run — Yes

Minimum — -100

Maximum — +100

Units — %



F223

F225

<p>RX2 Option (AI1) Input Point 1 Frequency</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to set the gain and bias of the RX2 (AI1) input terminal when the RX2 (AI1) terminal is used as the control input while operating in the Speed Control mode.</p> <p>This parameter sets RX2 (AI1) Input Point 1 Frequency and is the frequency that is associated with the setting of RX2 (AI1) Input Point 1 Setting (F222) when operating in the Speed Control mode.</p> <p>See RX2 (AI1) Input Point 1 Setting (F222) for additional information on this setting.</p>	<p>Direct Access Number — F223</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>RX2 Option (AI1) Input Point 2 Setting</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to set the gain and bias of the RX2 (AI1) input terminal when the RX2 (AI1) terminal is used as the control input while operating in the Speed Control mode or the Torque Control mode.</p> <p>This parameter sets the RX2 (AI1) input level that is associated with RX2 (AI1) Input Point 2 Frequency when operating in the Speed control mode or is associated with the RX2 (AI1) Input Point 2 Rate (F227) when operating in the Torque Control mode.</p> <p>This value is entered as -100% to +100% of the RX2 (AI1) input signal range.</p> <p>See RX2 (AI1) Input Point 1 Setting (F222) for additional information on this setting when used for Speed control.</p> <p>See RX2 (AI1) Input Point 1 Rate (F226) for additional information on this setting when used for Torque Control.</p>	<p>Direct Access Number — F224</p> <p>Parameter Type — Numerical</p> <p>Factory Default — +100</p> <p>Changeable During Run — Yes</p> <p>Minimum — -100</p> <p>Maximum — +100</p> <p>Units — %</p>
<p>RX2 Option (AI1) Input Point 2 Frequency</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to set the gain and bias of the RX2 (AI1) input terminal when the RX2 (AI1) terminal is used as the control input while operating in the Speed Control mode.</p> <p>This parameter sets RX2 (AI1) Input Point 2 Frequency and is the frequency that is associated with the setting of RX2 (AI1) Input Point 2 Setting (F224) when operating in the Speed Control mode.</p> <p>See RX2 (AI1) Input Point 1 Setting (F222) for additional information on this setting.</p>	<p>Direct Access Number — F225</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 60.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>

RX2 Option (AI1) Input Point 1 Rate

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **RX2** (AI1) input terminal when the **RX2** (AI1) terminal is used as the control input while operating in the **Torque Control** mode.

Note: *The Expansion IO Card Option 1 option board (P/N ETB003Z) is required to use this terminal.*

RX2 (AI1) Input Torque Control Setup

Perform the following setup to allow the system to receive **Torque Control** input at the **RX2** (AI1) input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode ⇒ **RX2**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Board**.
- Provide a **Run** command (F and/or R).

Torque Control

Perform the following setup to allow the system to perform **Torque Control** from the **RX2** (AI1) input terminal:

- Set **RX2** (AI1) **Input Point 1 Rate** (F226).
- Set **RX2** (AI1) **Input Point 1 Setting** (F222) — the input analog signal level that corresponds to the speed setting at **RX2** (AI1) **Input Point 1 Rate**.
- Set **RX2** (AI1) **Input Point 2 Rate** (F227).
- Set **RX2** (AI1) **Input Point 2 Setting** (F224) — the input analog signal level that corresponds to the speed setting at **RX Input Point 2 Rate** (F221).
- Provide a **Run** command (F and/or R).

Torque Control is accomplished by establishing an associated **V/f** output pattern for a given **RX2** (AI1) input level.

Once set, as the **RX2** (AI1) input voltage changes, the ASD output speed and/or torque will vary in accordance with the above settings.

This parameter sets **RX2** (AI1) **Input Point 1 Rate** and is the output torque value that is associated with the setting of **RX2** (AI1) **Input Point 1 Setting** when operating in the **Torque Control** mode.

This value is entered as -250% to +250% of the rated torque.

See the *Expansion IO Card Option 1 Instruction Manual* (P/N 58685) for additional information on the function of this terminal.

Direct Access Number — F226

Parameter Type — Numerical


Factory Default — 0.00

Changeable During Run — Yes

Minimum — -250.00

Maximum — +250.00

Units — %



F227**F227****RX2 Option (AI1) Input Point 2 Rate**

Program ⇒ Torque ⇒ Setpoints

This parameter is used to set the gain and bias of the **RX2** (AI1) input terminal when the **RX2** (AI1) terminal is used as the control input while operating in the **Torque Control** mode.

Torque Control is accomplished by establishing an associated **V/f** output pattern for a given **RX2** (AI1) input level.

This parameter sets **RX2** (AI1) **Input Point 2 Rate** and is the output torque value that is associated with the setting of **RX2** (AI1) **Input Point 2 Setting** (F224) when operating in the **Torque Control** mode.

This value is entered as -250% to +250% of the rated torque.

See **RX2** (AI1) **Input Point 1 Rate** (F226) for additional information on this setting.

Direct Access Number — F227

Parameter Type — Numerical

Factory Default — 100.00

Changeable During Run — Yes

Minimum — -250.00

Maximum — +250.00

Units — %

BIN Input Point 1 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **BIN** input terminals when the **BIN** terminals are used as the control input while operating in the **Speed Control** mode.

The discrete input terminals of the **ACE G9-120V-PCB** are used as the **BIN** terminals.

BIN Input Speed Control Setup

Perform the following setup to allow the system to receive **Speed** control input at the **BIN** input terminals:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ **Binary/BCD**.
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Command Mode Selection ⇒ **Terminal Board**.
- Program ⇒ Terminal ⇒ **Input Terminals**; select and set the desired discrete input terminals to **Binary Bit(s) 0 – 7** (or 0 – MSB). The binary input byte will control the speed of the motor.
- Program ⇒ Terminal ⇒ **Input Terminals**; select and set a discrete input terminal to **Binary Data Write**. Activation of the **Binary Data Write** terminal will transfer the status of the **Binary Bit(s) 0 – 7** (or 0 – MSB) to the control board for speed control.

Speed Control

Perform the following setup to allow the system to perform **Speed** control from the **BIN** input terminals:

- Set **BIN Input Point 1 Frequency (F229)**.
- Set the **BIN** input value (% of 255_D) (**F228**) that represents **BIN Input Point 1 Frequency**.
- Set **BIN Input Point 2 Frequency (F231)**.
- Set the **BIN** input value (% of 255_D) (**F230**) that represents **BIN Input Point 2 Frequency**.
- Provide a **Run** command (F and/or R).

Note: 255_D is the decimal equivalent of the 8-bit **BIN** byte with all input terminals set to 1 (255 decimal = 11111111 binary).

Once set, as the **BIN** input signal changes are transferred to the control board, the output frequency of the ASD will vary in accordance with the above settings.

This parameter sets **BIN Input Point 1 Setting (F228)** and is entered as 0% to 100% of the of the range represented by the **BIN** binary input byte 11111111 (255_D) or the binary bit(s) 0 – MSB.

Direct Access Number — **F228**

Parameter Type — **Numerical**


Factory Default — **0**

Changeable During Run — **Yes**

Minimum — **0**

Maximum — **100**

Units — **%**



F229**F231****BIN Input Point 1 Frequency**

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the speed of the **BIN** input terminals when the **BIN** terminals are used as the control input.

This parameter sets **BIN Input Point 1 Frequency** and is the frequency that is associated with the setting of **BIN Input Point 1 Setting** (F228).

See **BIN Input Point 1 Setting** (F228) for additional information on this setting.

Direct Access Number — F229

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0

Maximum — **Max. Freq. (F011)**

Units — Hz

BIN Input Point 2 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the speed of the **BIN** input terminals when the **BIN** terminals are used as the control input.

This parameter sets the **BIN** input signal that is associated with **BIN Input Point 2 Frequency** (F231).

This value is entered as 0% to +100% of the **BIN** input signal range.

See **BIN Input Point 1 Setting** (F228) for additional information on this setting.

Direct Access Number — F230

Parameter Type — **Numerical**

Factory Default — **100**

Changeable During Run — **Yes**

Minimum — 0

Maximum — 100

Units — %

BIN Input Point 2 Frequency

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the speed of the **BIN** input terminals when the **BIN** terminal are used as the control input.

This parameter sets **BIN Input Point 2 Frequency** and is the frequency that is associated with the setting of **BIN Input Point 2 Setting** (F230).

See **BIN Input Point 1 Setting** (F228) for additional information on this setting.

Direct Access Number — F231

Parameter Type — **Numerical**

Factory Default — **60.00**

Changeable During Run — **Yes**

Maximum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

F234

F235

PG Input Point 1 Setting

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the gain and bias of the **PG** input terminal of the option board when a shaft-mounted encoder is used as the control input while operating in the **Speed Control** mode.

Note: See *Instruction Manual P/N 58687* for additional information on the **PG Option Board**.

PG Input Speed Control Setup

Perform the following setup to allow the system to receive **Speed** control input at the **PG** input terminal:

- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ Frequency Mode 1 ⇒ **Pulse Input** (option).
- Program ⇒ Fundamental ⇒ Standard Mode Selection ⇒ **Command Mode Selection** ⇒ (Any Setting).
- Provide a **Run** command (F and/or R).

Speed Control

Perform the following setup to allow the system to perform **Speed** control from the **PG** input terminals:

- Set **PG Point 1 Frequency (F235)**.
- Set the **PG** input value (F234) that represents **PG Point 1 Frequency**.
- Set **PG Point 2 Frequency (F237)**.
- Set the **PG** input value (F236) that represents **PG Point 2 Frequency**.

Once set, as the **PG** input pulse count rate changes, the output frequency of the ASD will vary in accordance with the above settings.

This parameter sets the **PG** input pulse count that represents **PG Point 1 Frequency**. The range of values for this parameter is 0% to 100% of the **PG** input pulse count range.

Note: Additional application-specific **PG** settings may be performed from the following path: Program ⇒ Feedback ⇒ **PG Settings**.

PG Input Point 1 Frequency

Program ⇒ Frequency ⇒ Speed Reference Setpoints

This parameter is used to set the speed of the **PG** input terminals when the **PG** terminal is used as the control input.

This parameter sets **PG Point 1 Frequency** and is the frequency that is associated with the setting of **PG Point 1 Setting (F234)**.

See **PG Point 1 Setting (F234)** for additional information on this setting.

Direct Access Number — F234

Parameter Type — Numerical


Factory Default — 0.0

Changeable During Run — Yes

Minimum — 0

Maximum — 100.0

Units — %



Direct Access Number — F235

Parameter Type — Numerical

Factory Default — 0.00

Changeable During Run — Yes

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

F236

F241

<p>PG Input Point 2 Setting</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to set the direction and speed of the PG input terminals when the PG terminals are used as the control input.</p> <p>This parameter sets the PG input signal that is associated with PG Point 2 Frequency (F237).</p> <p>This value is entered as 0% to 100% of the PG input signal range.</p> <p>See PG Point 1 Setting (F234) for additional information on this setting.</p>	<p>Direct Access Number — F236</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 100</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 100</p> <p>Units — %</p>
<p>PG Input Point 2 Frequency</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to set the direction and speed of the PG input terminals when the PG terminal are used as the control input.</p> <p>This parameter sets PG Point 2 Frequency (F237) and is the frequency that is associated with the setting of PG Point 2 Setting.</p> <p>See PG Point 1 Setting (F234) for additional information on this setting.</p>	<p>Direct Access Number — F237</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 60.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>Start Frequency</p> <p>Program ⇒ Special ⇒ Frequency Control</p> <p>The output of the ASD will remain at 0.0 Hz until the programmed speed value exceeds this setting during startup. Once exceeded during startup, the output frequency of the ASD will accelerate to the programmed setting.</p> <p>Output frequencies below the Start Frequency will not be output from the ASD during startup. However, once reaching the Start Frequency, speed values below the Start Frequency may be output from the ASD.</p> <p>If the setting of this parameter results in an over-current condition at startup, reduce the setting of this parameter to a value less than the rated slippage of the motor.</p> <p>If zero-speed torque is required, set this parameter and F243 to 0.0 Hz.</p> <p>This setting will override the setting of F244 if this setting has a higher value.</p> <p>This parameter setting is used during a Jog as the Lower-Limit frequency (see F260).</p>	<p>Direct Access Number — F240</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.10</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>Run Frequency</p> <p>Program ⇒ Special ⇒ Frequency Control</p> <p>This parameter establishes a center frequency (Run Frequency) of a frequency band.</p> <p>Parameter F242 provides a plus-or-minus value for the Run Frequency; thus, establishing a frequency band.</p> <p>During acceleration, the ASD will not output a signal to the motor until the lower level of the band is reached.</p> <p>During deceleration, the ASD will continue to output the programmed deceleration signal to the motor until the lower level of the band is reached; at which time the output will go to 0.0 Hz.</p>	<p>Direct Access Number — F241</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>

F242

F251

<p>Run Frequency Hysteresis</p> <p>Program ⇒ Special ⇒ Frequency Control</p> <p>This parameter provides a plus-or-minus value for the Run Frequency (F241) setting.</p>	<p>Direct Access Number — F242</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 30.0</p> <p>Units — Hz</p>
<p>End Frequency</p> <p>Program ⇒ Special ⇒ Frequency Control</p> <p>This parameter sets the lowest frequency that the ASD will recognize during deceleration before the ASD goes to 0.00 Hz.</p>	<p>Direct Access Number — F243</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 30.0</p> <p>Units — Hz</p>
<p>0 Hz Dead Band Signal</p> <p>Program ⇒ Special ⇒ Special Parameters</p> <p>This parameter sets an output frequency threshold that, until the commanded frequency surpasses this setting, the ASD will output 0.00 Hz to the motor.</p> <p>This setting will override the Start Frequency (F240) setting if this setting has a higher value.</p>	<p>Direct Access Number — F244</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 5.00</p> <p>Units — Hz</p>
<p>DC (Injection) Braking Start Frequency</p> <p>Program ⇒ Protection ⇒ DC Braking</p> <p>During deceleration this is the frequency at which DC Injection Braking will start.</p> <p>DC Injection Braking</p> <p>DC Injection Braking is a braking system used with 3-phase motors. Unlike conventional brakes, there is no physical contact between the rotating shaft and a stationary brake pad or drum. When braking is required, the ASD outputs a DC current that is applied to the windings of the motor to quickly brake the motor. The braking current stops when the time entered in F252 times out.</p> <p>The intensity of the DC current used while braking determines how fast the motor will come to a stop and may be set at F251. The intensity setting is entered as a percentage of the full-load current of the ASD.</p> <p>DC Injection Braking is also used to preheat the motor or to keep the rotor from spinning freely when the motor is off by providing a pulsating DC current into the motor at the Carrier Frequency. This feature may be enabled at F254.</p>	<p>Direct Access Number — F250</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 120.00</p> <p>Units — Hz</p>
<p>DC (Injection) Braking Current</p> <p>Program ⇒ Protection ⇒ DC Braking</p> <p>This parameter sets the percentage of the rated current of the ASD that will be used for DC Injection Braking. A larger load will require a higher setting.</p>	<p>Direct Access Number — F251</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 50</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 100</p> <p>Units — %</p>

F252

F256

<p>DC (Injection) Braking Time</p> <p>Program ⇒ Protection ⇒ DC Braking</p> <p>This parameter setting is used to set the on-time duration of the DC Injection Braking.</p>	<p>Direct Access Number — F252</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — 20.0</p> <p>Units — Seconds</p>
<p>Forward/Reverse DC (Injection) Braking Priority</p> <p>Program ⇒ Protection ⇒ DC Braking</p> <p>This parameter setting determines if DC Injection Braking is to be used during a change in the direction of the motor.</p> <p>Settings:</p> <ul style="list-style-type: none"> Disabled Enabled 	<p>Direct Access Number — F253</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Disabled</p> <p>Changeable During Run — Yes</p>
<p>Motor Shaft Fixing Control</p> <p>Program ⇒ Protection ⇒ DC Braking</p> <p>This parameter Enables/Disables a continuous DC injection at half of the amperage setting of F251 into a stopped motor. This feature is useful in preheating the motor or to keep the rotor from spinning freely.</p> <p>Motor Shaft Stationary Control starts after the DC injection brake stops the motor and continues until the ST activation ceases (if so configured; see F110), power is turned off, an Emergency Off command is received, or this parameter is changed.</p> <p>Enabling this feature will also require a non-zero entry at F250.</p> <p>Settings:</p> <ul style="list-style-type: none"> Disabled Enabled 	<p>Direct Access Number — F254</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Disabled</p> <p>Changeable During Run — Yes</p>
<p>0 Hz Command Output</p> <p>Program ⇒ Special ⇒ Special Parameters</p> <p>This parameter is used to set the go-to-zero method to be used by the ASD in the event that the ASD is commanded to go to 0 Hz.</p> <p>Settings:</p> <ul style="list-style-type: none"> Standard (DC Injection Braking) 0 Hz Command 	<p>Direct Access Number — F255</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Standard (DC Injection Braking)</p> <p>Changeable During Run — No</p>
<p>Time Limit For Lower-Limit Frequency Operation</p> <p>Program ⇒ Fundamental ⇒ Frequency</p> <p>This parameter sets the time that the ASD is allowed to operate below the Lower-Limit setting before an alarm and subsequent fault is incurred.</p>	<p>Direct Access Number — F256</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — 600.0</p> <p>Units — Seconds</p>

Jog Run Frequency

Program ⇒ Frequency ⇒ Jog

This parameter sets the output frequency of the ASD during a **Jog**. **Jog** is the term used to describe turning the motor on for small increments of time and is used when precise positioning of motor-driven equipment is required.

The **Jog** function may be initiated from the **EOI**, remotely via the **ACE G9-120V-PCB**, or using **Communications** (for additional information on using Communications for Jogging, see the Communications manual P/N 53840).

The **Jog** function can be activated from zero Hz or from any frequency below the **Jog Run** frequency (Jog can only increase the speed). A **Jog** command will not be recognized when the running frequency is above the **Jog Run** frequency setting. The **Jog** command has priority over other **Run** commands and is not limited by the **Upper Limit** setting of parameter **F012**.

Jog commands received while running for the opposite direction will follow the programmed stopping method of **F261** until reaching zero Hz and will then ramp to the programmed **Jog Frequency** and direction.

Jog Setup and Execution

To initiate a **Jog Run** from the **EOI** perform the following:

1. Enable the **Jog** function at **F262**.
2. Set the **Command Mode Selection (F003)** to **EOI Keypad**.
3. Assign the **Jog Run** setting to a discrete input terminal (see [Table 7 on pg. 236](#)).

*Note: Any unused discrete input terminal may be used for the **Jog Run** setting.*

4. Set up a **Jog Run Frequency** at **F260**.
5. Set up a **Jog Stop Pattern** at **F261**.
6. Set the **Input Terminal Priority (F106)** function to **Disable** to receive **Jog** commands from the **EOI**.
7. Set the **Local/Remote** key to **Local**.
8. Activate the **Jog Run** terminal (from step 3) and provide a **Run** command (F or R).
9. Press the **Run** key and the ASD will output the frequency setting of **F260** for the duration of the activation.

To initiate a **Jog Run** from the **ACE G9-120V-PCB** perform the following:

1. Using the setup above, set the **Input Terminal Priority (F106)** function (from step 6) to **Enable** to receive **Jog** commands from the **ACE G9-120V-PCB** using the **Jog Run** terminal without regard to the **Local/Remote** setting.
2. Use the **Jog Run** terminal of step 3 above to activate the **Jog** function.

Direct Access Number — **F260**

Parameter Type — **Numerical**

Factory Default — **5.00**

Changeable During Run — **Yes**

Minimum — **F240** Setting

Maximum — 20.00

Units — Hz

F261**F262****Jog Stop Pattern**

Program ⇒ Frequency ⇒ Jog

This parameter sets the stopping method used while operating in the **Jog** mode.

***Note:** This parameter setting is used for the **Jog** operation only. The **Emergency Off** stopping method setting of parameter **F603** has priority over this setting and changes made here do not affect the function or setting of parameter **F603**.*

Settings:

- Deceleration Stop
- Coast Stop
- DC Injection Braking Stop

Direct Access Number — F261

Parameter Type — **Selection List**

Factory Default — **Deceleration Stop**

Changeable During Run — **Yes**

Panel Operation Jog Mode

Program ⇒ Frequency ⇒ Jog

This parameter enables the **Jog** command to be received from the **EOI**. When disabled the **Jog** command received from the **EOI** is ignored.

Jog commands may also be received from the **ACE G9-120V-PCB**. Priority as to which is allowed to override the other is selected at **F106**.

The priority selection at **F106** enables the selected source for **Jog** control and disables the other. The **F106** setting overrides this parameter setting.

Settings:

- Disabled
- Enabled

Direct Access Number — F262

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **Yes**

UP/DOWN Frequency (UP) Response Time

Program ⇒ Frequency ⇒ UP/DOWN Frequency Functions

This parameter functions in conjunction with the parameter settings of **F265**, **F266**, **F267**, **F268**, and **F269**. The purpose of these settings is to setup the ASD to allow an externally-supplied discrete input signal to control the output frequency of the ASD.

This method uses the discrete input terminal settings **UP/DOWN Frequency (UP)** and **UP/DOWN Frequency (DOWN)** to change the ASD speed. Activation of either terminal increases or decreases the output frequency at the **Accel 1** or **Decel 1** rates, respectively.

Depending on the **Delay** setting, the **UP/DOWN Frequency (UP/DOWN)** terminal may perform **1)** the increase/decrease function for the duration of activation or **2)** the **UP/DOWN Frequency (UP/DOWN)** terminal may act as a momentary contact that loads a new commanded frequency upon activation.

In either case, to activate-and-hold will continue the up or down function until reaching the **Upper-Limit Frequency** or the **Lower-Limit Frequency**, respectively. At which point further activation will be ignored.

See **Figure 30** on pg. 133 for additional information on the **UP/DOWN Frequency** function.

Setup Requirements

F003 — Selects the **Command** control source; set to **Terminal Board**.

F004 — Selects the **Frequency Control Mode 1** control source; set to **UP/DOWN Frequency**.

F207 — Selects the **Frequency Control Mode 2** control source; set to **UP/DOWN Frequency** if used.

Set one unused discrete input terminal to **UP/DOWN Frequency (UP)** and one unused discrete input terminal to **UP/DOWN Frequency (DOWN)**.

F264 — Sets the system-response delay to the initial activation of the discrete input terminal **UP/DOWN Frequency (UP)**. Also sets the response delay of subsequent terminal activations of the **UP/DOWN Frequency (UP)** terminal during an activate-and-hold.

F265 — Sets the frequency increase amount for each activation of the **UP/DOWN Frequency (UP)** terminal activation. The rate of the frequency increase is set at **Acceleration Time 1 — UP/DOWN Frequency Accel Time (F009)**.

F266 — Sets the system-response delay to the initial activation of the discrete input terminal **UP/DOWN Frequency (DOWN)**. Also sets the activation delay of subsequent terminal activations of the **UP/DOWN Frequency (DOWN)** terminal during an activate-and-hold.

F267 — Sets the frequency decrease amount for each activation of the **UP/DOWN Frequency (DOWN)** terminal activation. The rate of the frequency decrease is set at **Deceleration Time 1 — UP/DOWN Frequency Decel Time (F010)**.

F268 — At power up or after a reset, this parameter setting is used to provide a starting frequency for the **UP/DOWN Frequency** function.

F269 — At power down while running, and when enabled, this parameter writes the running frequency into the **F268** location and, upon a system restart, uses this setting as the startup frequency.

Provide a **Run** command (F or R). The motor will run at the **F268** setting.

Direct Access Number — **F264**

Parameter Type — **Numerical**



Factory Default — **0.1**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 10.0


Units — Seconds



F265

F269

<p>UP/DOWN Frequency (UP) Frequency Step</p> <p>Program ⇒ Frequency ⇒ UP/DOWN Frequency Functions</p> <p>This parameter sets the frequency increase amount for each activation of the UP/DOWN Frequency (UP) terminal activation. The rate of the frequency increase is set at Acceleration Time 1 — UP/DOWN Frequency Accel Time (F009).</p> <p>See F264 for additional information on this parameter.</p>	<p>Direct Access Number — F265</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.10</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>UP/DOWN Frequency (DOWN) Response Time</p> <p>Program ⇒ Frequency ⇒ UP/DOWN Frequency Functions</p> <p>This parameter sets the system-response delay to the initial activation of the discrete input terminal UP/DOWN Frequency (DOWN). Also sets the activation delay of subsequent terminal activations of the UP/DOWN Frequency (DOWN) terminal during an activate-and-hold.</p> <p>See F264 for additional information on this parameter.</p>	<p>Direct Access Number — F266</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.1</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — 10.0</p> <p>Units — Seconds</p>
<p>UP/DOWN Frequency (DOWN) Frequency Step</p> <p>Program ⇒ Frequency ⇒ UP/DOWN Frequency Functions</p> <p>This parameter sets the frequency decrease amount for each activation of the UP/DOWN Frequency (DOWN) terminal activation. The rate of the frequency decrease is set at Deceleration Time 1 — UP/DOWN Frequency Decel Time (F010).</p> <p>See F264 for additional information on this parameter.</p>	<p>Direct Access Number — F267</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.10</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>Initial UP/DOWN Frequency</p> <p>Program ⇒ Frequency ⇒ UP/DOWN Frequency Functions</p> <p>At power up or after a reset, this parameter setting is used to provide a starting frequency for the UP/DOWN Frequency function.</p> <p>See F269 for additional information on this parameter setting.</p>	<p>Direct Access Number — F268</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — Lower Limit (F013)</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>
<p>Initial UP/DOWN Frequency Rewriting</p> <p>Program ⇒ Frequency ⇒ UP/DOWN Frequency Functions</p> <p>At power down, and when enabled, this parameter writes the running frequency into the F268 location and, upon a system restart, uses this setting as the startup frequency.</p> <p>Disable this parameter and set parameter F268 to the desired startup frequency if the same starting frequency is required at each startup.</p> <p><i>Note: This parameter setting may be different at each startup when enabled.</i></p> <p>Settings:</p> <ul style="list-style-type: none"> Disabled Enabled (Overwrite F268 at Power Off or Reset) 	<p>Direct Access Number — F269</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Enabled</p> <p>Changeable During Run — Yes</p>

Figure 30. UP/DOWN Frequency Operation Control Timing Diagram.**Jump Frequency 1**

Program ⇒ Special ⇒ Jump Frequencies

In conjunction with parameter **F271**, this parameter establishes a user-defined frequency range: the **Jump Frequency** and a plus-or-minus value.

During acceleration, the output frequency of the ASD will hold at the lower level of the **Jump Frequency** range until the programmed acceleration ramp reaches the upper level of the **Jump Frequency** range. At which time the output frequency of the ASD will accelerate to the upper level of the **Jump Frequency** range and continue upward as programmed.

During deceleration, the output frequency of the ASD will hold at the upper level of the **Jump Frequency** range until the programmed deceleration ramp reaches the lower level of the **Jump Frequency** range. At which time the output frequency of the ASD will decelerate to the lower level of the **Jump Frequency** range and continue downward as programmed.

Once set up and enabled, it is on in all control modes.

User-selected frequencies may be jumped to avoid the negative effects of mechanical resonance.

Direct Access Number — F270

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

F271**F275**

<p>Jump Frequency 1 Bandwidth</p> <p>Program ⇒ Special ⇒ Jump Frequencies</p> <p>This parameter establishes a plus-or-minus value for Jump Frequency 1 (see F270).</p>	<p>Direct Access Number — F271</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 30.00</p> <p>Units — Hz</p>
<p>Jump Frequency 2</p> <p>Program ⇒ Special ⇒ Jump Frequencies</p> <p>Same as Jump Frequency 1 (F270) and is used when multiple frequencies are to be jumped (see the plus-or-minus value setting at F273). When multiple jump frequencies overlap, the system will recognize the lowest and the highest frequencies as one jump range.</p>	<p>Direct Access Number — F272</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>Jump Frequency 2 Bandwidth</p> <p>Program ⇒ Special ⇒ Jump Frequencies</p> <p>This parameter establishes a plus-or-minus value for Jump Frequency 2 (F272).</p>	<p>Direct Access Number — F273</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 30.0</p> <p>Units — Hz</p>
<p>Jump Frequency 3</p> <p>Program ⇒ Special ⇒ Jump Frequencies</p> <p>Same as Jump Frequency 1 (F270) and is used when multiple frequencies are to be jumped (see the plus-or-minus value setting at F275).</p> <p>When multiple jump frequencies overlap, the system will recognize the lowest and the highest frequencies as one jump range.</p>	<p>Direct Access Number — F274</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>Jump Frequency 3 Bandwidth</p> <p>Program ⇒ Special ⇒ Jump Frequencies</p> <p>This parameter establishes a plus-or-minus value for Jump Frequency 3 (F274).</p>	<p>Direct Access Number — F275</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 30.0</p> <p>Units — Hz</p>

F280

F285

<p>External Fault Stopping Method</p> <p>Program ⇒ Crane/Hoist ⇒ External Fault</p> <p>In a multiple ASD configuration a faulted ASD signals the remaining ASDs, via a discrete input terminal, that a fault has occurred and shuts down the non-faulted ASDs. The non-faulted ASDs experience an External Fault.</p> <p>This parameter selects the stopping method in the event that a External Fault is incurred.</p> <p>Settings:</p> <ul style="list-style-type: none"> Coast Stop Deceleration Stop DC Injection Braking Stop 	<p>Direct Access Number — F280</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Coast Stop</p> <p>Changeable During Run — No</p>
<p>Limit-Switch Stopping Method</p> <p>Program ⇒ Crane/Hoist ⇒ Limit Switch Control</p> <p>This parameter determines the method used to stop the motor if the Stop command is initiated via a limit switch.</p> <p>Settings:</p> <ul style="list-style-type: none"> Coast Stop Deceleration Stop DC Injection Braking Stop 	<p>Direct Access Number — F282</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Deceleration Stop</p> <p>Changeable During Run — No</p>
<p>Deceleration Time at Slow-Speed-Limit UP</p> <p>Program ⇒ Crane/Hoist ⇒ Limit Switch Control</p> <p>Closure of the Upper-Limit Slow-Speed Limit-Switch implements the modified Upper-Limit Speed (F294) and Deceleration Time (F283) settings.</p> <p>This parameter sets the time to reach the modified Lower-Limit Slow Speed.</p>	<p>Direct Access Number — F283</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1.5</p> <p>Changeable During Run — No</p> <p>Minimum — 0.1</p> <p>Maximum — 1.5</p> <p>Units — Seconds</p>
<p>Stopping Time at Stop Limit-Switch UP</p> <p>Program ⇒ Crane/Hoist ⇒ Limit Switch Control</p> <p>A Stop command is initiated upon activation of the Upper-Limit Stop Limit-Switch.</p> <p>This parameter sets the Decel rate to be used upon activation of the Upper-Limit Stop Limit-Switch.</p>	<p>Direct Access Number — F284</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1.5</p> <p>Changeable During Run — No</p> <p>Minimum — 0.0</p> <p>Maximum — 25.0</p> <p>Units — Seconds</p>
<p>Deceleration Time At Slow-Speed Limit-Switch DOWN</p> <p>Program ⇒ Crane/Hoist ⇒ Limit Switch Control</p> <p>Closure of the Lower-Limit Slow-Speed Limit-Switch implements the modified Lower-Limit Slow Speed (F293) and Deceleration Time (F285) settings.</p> <p>This parameter sets the time to reach the modified Lower-Limit Slow Speed.</p>	<p>Direct Access Number — F285</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1.5</p> <p>Changeable During Run — No</p> <p>Minimum — 0.0</p> <p>Maximum — 25.0</p> <p>Units — Seconds</p>

F286

F291

<p>Stopping Time at Stop Limit-Switch DOWN</p> <p>Program ⇒ Crane/Hoist ⇒ Limit Switch Control</p> <p>A Stop command is initiated upon activation of the Lower-Limit Stop Limit-Switch.</p> <p>This parameter sets the Decel rate to be used upon activation of the Lower-Limit Stop Limit-Switch.</p>	<p>Direct Access Number — F286</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1.5</p> <p>Changeable During Run — No</p> <p>Minimum — 0.0</p> <p>Maximum — 25.0</p> <p>Units — Seconds</p>
<p>Preset Speed 8</p> <p>Program ⇒ Frequency ⇒ Preset Speeds</p> <p>This parameter assigns an output frequency to binary number 1000 and is identified as Preset Speed 8. The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).</p>	<p>Direct Access Number — F287</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — Lower Limit (F013)</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>
<p>Preset Speed 9</p> <p>Program ⇒ Frequency ⇒ Preset Speeds</p> <p>This parameter assigns an output frequency to binary number 1001 and is identified as Preset Speed 9. The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).</p>	<p>Direct Access Number — F288</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — Lower Limit (F013)</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>
<p>Preset Speed 10</p> <p>Program ⇒ Frequency ⇒ Preset Speeds</p> <p>This parameter assigns an output frequency to binary number 1010 and is identified as Preset Speed 10. The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).</p>	<p>Direct Access Number — F289</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — Lower Limit (F013)</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>
<p>Preset Speed 11</p> <p>Program ⇒ Frequency ⇒ Preset Speeds</p> <p>This parameter assigns an output frequency to binary number 1011 and is identified as Preset Speed 11. The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).</p>	<p>Direct Access Number — F290</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — Lower Limit (F013)</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>
<p>Preset Speed 12</p> <p>Program ⇒ Frequency ⇒ Preset Speeds</p> <p>This parameter assigns an output frequency to binary number 1100 and is identified as Preset Speed 12. The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).</p>	<p>Direct Access Number — F291</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — Lower Limit (F013)</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>

F292

F300

<p>Preset Speed 13</p> <p>Program ⇒ Frequency ⇒ Preset Speeds</p> <p>This parameter assigns an output frequency to binary number 1101 and is identified as Preset Speed 13. The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).</p>	<p>Direct Access Number — F292</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — Lower Limit (F013)</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>
<p>Preset Speed 14/Lower-Limit Slow Speed</p> <p>Program ⇒ Frequency ⇒ Preset Speeds</p> <p>This is a dual-function parameter. The two functions are described below.</p> <p>1) This parameter assigns an output frequency to binary number 1110 and is identified as Preset Speed 14. The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).</p> <p>2) The Lower-Limit speed and Deceleration time settings are changed once the crane approaches the end of its range (hoist or traverse). Upon approaching the end-of-range, as detected by the closure of the Lower-Limit Slow-Speed Limit-Switch, the implementation of the modified Lower-Limit Slow Speed (F293) and Deceleration Time At Slow-Speed Limit-Switch DOWN (F285) settings take effect.</p>	<p>Direct Access Number — F293</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 6.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — Lower Limit (F013)</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>
<p>Preset Speed 15/Upper-Limit Slow Speed</p> <p>Program ⇒ Frequency ⇒ Preset Speeds</p> <p>This is a dual-function parameter. The two functions are described below.</p> <p>1) This parameter assigns an output frequency to binary number 1111 and is identified as Preset Speed 15. The binary number is applied to I1 – I4 of the ACE G9-120V-PCB to output the Preset Speed (see F018 for additional information on this parameter).</p> <p>2) The Upper-Limit speed and Deceleration time settings are changed once the crane approaches the end of its range (hoist or traverse). Upon approaching the end-of-range, as detected by the closure of the Upper-Limit Slow-Speed Limit-Switch, the implementation of the modified Upper-Limit Slow Speed (F294) and Deceleration Time at Slow-Speed-Limit UP (F283) settings take effect.</p>	<p>Direct Access Number — F294</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 6.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — Lower Limit (F013)</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>
<p>PWM Carrier Frequency</p> <p>Program ⇒ Special ⇒ Carrier Frequency</p> <p>This parameter sets the frequency of the Pulse Width Modulation (PWM) signal applied to the motor.</p> <p>Note: <i>When operating in the Vector Control mode the carrier frequency should be set to 2.2 kHz or above.</i></p> <p>Note: <i>If the PWM carrier frequency is set at 2.0 kHz or above, it cannot be decreased below 2.0 kHz while running. If the PWM carrier frequency is set at 1.9 kHz or below, it cannot be increased above 2.0 kHz while running. Either change requires that the ASD be stopped and restarted for the changes to take effect.</i></p>	<p>Direct Access Number — F300</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 2.5</p> <p>Changeable During Run — No</p> <p>Minimum — 1.0</p> <p>Maximum — (ASD-Dependent)</p> <p>Units — kHz</p>

F301

F302

Auto Restart Selection

Program ⇒ Protection ⇒ Retry/Restart

This parameter **Enables/Disables** the ability of the ASD to start into a spinning motor when the **ST** activation ceases (if so configured; see [F110](#)) momentarily and is then reactivated (ST deactivation/ST activation) or after a power interruption (momentary power failure).

Settings:

- Off
- Enabled (at Power Failure)
- Enabled (at ST Activate/Deactivate)
- Enabled (at ST Activate/Deactivate or Power Failure)
- Enabled (at Run)

Direct Access Number — F301

Parameter Type — **Selection List**

Factory Default — **Off**

Changeable During Run — **No**

Regenerative Power Ridethrough

Program ⇒ Protection ⇒ Under-Voltage/Ridethrough

This parameter determines the motor-control response of the ASD in the event of a momentary power outage or under-voltage condition.

During a **Ridethrough**, regenerative energy is used to maintain the control circuitry settings for the duration of the **Ridethrough**; it is not used to drive the motor. The motor(s) of the system are stopped and then restarted automatically if so configured.

In a multiple-motor application, there will be a requirement to synchronize the stopping and restarting of the motors as not to cause breakage in the product being processed by the motors stopping/starting at different times (e.g., wire spools, bobbin winder for textile machines, etc.). Parameters [F317](#) and [F318](#) must be setup to synchronize motor operation as to avoid breakage in these types of applications.

Note: *If used to restart the motors, the Retry setup of [F301](#) is required.*

Note: *The Jog function will not operate while in the Synchronized Decel/Accel mode.*

Settings:

- Off
- Ridethrough On
- Decel Stop
- Synchronized ACC/DEC (TB)
- Synchronized ACC/DEC (TB + Power Off)

Direct Access Number — F302

Parameter Type — **Selection List**

Factory Default — **Off**

Changeable During Run — **Yes**

Ridethrough Setup Requirements

1. Select the **Ridethrough Mode** at [F302](#).
2. Select the **Ridethrough Time** at [F310](#).
3. Select the **Synchronized Stop/Start Times** at [F317/F318](#) (if required).

Note: *F317 and F318 are not functional while operating in the Torque or Position control modes, or for the Jog Run function (F260).*

4. Set a discrete input terminal to **Power Failure Synchronized Signal** and activate the terminal to enable the **Synchronized Accel/Decel** function.
5. Select the **Ridethrough Control Level** at [F629](#).

Number of Times to Retry

Program ⇒ Protection ⇒ Retry/Restart

After a trip has occurred, this parameter sets the number of times that an automatic system restart is attempted for a qualified trip.

The trip conditions listed below will not initiate the automatic **Retry/Restart** function:

- Input Phase Loss (Input Phase Failure)
- Output Phase Loss (Output Phase Failure)
- Output Current Protection Fault
- Output Current Detector Error
- Load Side Over-Current at Start
- Earth Fault (Ground Fault)
- Over-Current During Acceleration
- Arm Over-Current at Start-Up
- DBR Resistor Over-Current
- Low-Current
- Voltage Drop In Main Circuit
- EEPROM Data Fault (EEPROM Fault)
- Flash Memory/Gate Array/RAM-ROM Fault
- CPU Fault
- Emergency Off (EMG)
- Communication Error
- Option Fault
- Sink/Source Setting Error (not used with the ACE-tronics G9 ASD)
- Over-Speed Error
- Over-Torque
- Key Error
- External Thermal Error
- Externally-Controlled Interrupt

See the section titled [System Setup Requirements](#) on pg. 8 for additional information on this setting.

Direct Access Number — F303

Parameter Type — **Numerical**

Factory Default — **00**

Changeable During Run — **Yes**

Minimum — 00

Maximum — 10

Dynamic Braking Enable

Program ⇒ Protection ⇒ Dynamic Braking

This parameter **Enables/Disables** the **Dynamic Braking** system.

Settings:

- Off
- Enabled with Overload Detection
- Enabled without Overload Detection

Dynamic Braking uses the transistor **IGBT7** to dissipate the bus voltage when required.

IGBT7 is a standard item on the 25 HP and below ACE-tronics G9 ASD 230-volt systems and is standard on the 400 HP and below for the for the 460-volt systems. **IGBT7** is optional for all remaining systems.

Dynamic Braking

Dynamic Braking is used to prevent over-voltage faults during rapid deceleration or constant speed run on cyclic overhauling applications.

Dynamic Braking dissipates regenerated energy in the form of heat. When using a DBR use thermal protection.

The resistive load is connected across terminals **PA** and **PB** (non-polarized). Using a low-value, high-wattage resistance as a load for the generated current, the resistive load dissipates the induced energy.

Dynamic Braking helps to slow the load quickly; it cannot act as a holding brake.

The **Dynamic Braking** function may be setup and enabled by connecting a braking resistor from terminal **PA** to **PB** of the ASD and providing the proper information at [F304](#), [F308](#), and [F309](#).

See the section titled [Dynamic Braking Resistor Specifications on pg. 274](#) for additional information on using the DBR system and for assistance in selecting the appropriate resistor for a given application.

Direct Access Number — F304Parameter Type — **Selection List**Factory Default — **Enabled without Overload Detection**Changeable During Run — **No**

Over-Voltage Limit Operation

Program ⇒ Protection ⇒ Stall

This parameter enables the **Over-Voltage Limit** function. This feature is used to set the upper DC bus voltage threshold that, once exceeded, will cause an **Over-Voltage Stall**.

An **Over-Voltage Stall** increases the output frequency of the ASD during deceleration for a specified time in an attempt to prevent an **Over-Voltage Trip**.

If the over-voltage threshold level setting of parameter [F626](#) is exceeded for over 4 mS, an **Over-Voltage Trip** will be incurred.

***Note:** This parameter setting may increase deceleration times.*

Settings:

- Enabled (Over-Voltage Stall)
- Disabled
- Enabled (Forced Shorted Deceleration)
- Enabled (Forced Dynamic Braking Deceleration)

Direct Access Number — F305Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **Yes**

F307

F310

Supply Voltage Correction

Program ⇒ Protection ⇒ Base Frequency Voltage

This parameter **Enables/Disables** the **Voltage Compensation** function.

When **Enabled**, this function provides a constant V/f ratio during periods of input voltage fluctuations.

Settings:

- Disabled (Output Voltage Unlimited)
- Enabled (Supply Voltage Compensation)
- Disabled (Output Voltage Limited)
- Enabled (Supply Voltage Compensation w/Output Voltage Limited)

Dynamic Braking Resistance

Program ⇒ Protection ⇒ Dynamic Braking

This parameter is used to input the resistive value of the **Dynamic Braking Resistor** being used.

Light-duty and heavy-duty resistors vary from a few ohms to several hundred ohms. The appropriate resistance size will be typeform- and application-specific.

See the section titled [Dynamic Braking Resistor Specifications on pg. 274](#) for additional information on using the DBR system and for assistance in selecting the appropriate resistor for a given application.

Note: *Using a resistor value that is too low may result in system damage.*

Continuous Dynamic Braking Capacity

Program ⇒ Protection ⇒ Dynamic Braking

This parameter is used to input the wattage of the **Dynamic Braking Resistor**.

See the section titled [Dynamic Braking Resistor Specifications on pg. 274](#) for additional information on using the DBR system.

Note: *Using a resistor with a wattage rating that is too low may result in system damage.*

Ridethrough Time

Program ⇒ Protection ⇒ Retry/Restart

In the event of a momentary power outage, this parameter determines the length of the **Ridethrough** time.

The **Ridethrough** will be maintained for the number of seconds set using this parameter.

See parameter [F302](#) for additional information on the Ridethrough function.

Note: *The actual **Ridethrough Time** is load-dependent.*

Direct Access Number — F307

Parameter Type — Selection List

Factory Default — Disabled

Changeable During Run — No

Direct Access Number — F308

Parameter Type — Numerical

Factory Default — (ASD-Dependent)

Changeable During Run — No

Minimum — 0.5

Maximum — 1000.0

Units — Ω

Direct Access Number — F309

Parameter Type — Numerical

Factory Default — (ASD-Dependent)

Changeable During Run — No

Minimum — 0.01

Maximum — 600.00

Units — kW

Direct Access Number — F310

Parameter Type — Numerical

Factory Default — 2.0

Changeable During Run — Yes

Minimum — 0.1

Maximum — 320.0

Units — Seconds

F311

F317

Forward Reverse Disable

Program ⇒ Frequency ⇒ Forward/Reverse Disable

This parameter **Enables/Disables** the **Forward Run** or **Reverse Run** mode.

If either direction is disabled, commands received for the disabled direction will not be recognized.

If both directions are disabled, the received direction command will determine the direction of the motor rotation.

Settings:

- Off
- Disable Reverse Run
- Disable Forward Run

Direct Access Number — F311

Parameter Type — **Selection List**

Factory Default — **Off**

Changeable During Run — **No**

Random Mode

Program ⇒ Protection ⇒ Retry/Restart

This parameter adjusts the carrier frequency randomly. This feature is effective in minimizing the negative effects of mechanical resonance.

Settings:

- Disabled
- Enabled

Direct Access Number — F312

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **No**

Carrier Frequency Control Mode

Program ⇒ Special ⇒ Carrier Frequency

This parameter provides for the automatic decrease of the carrier frequency.

Select **1** to decrease the **Carrier Frequency** setting as a function of an increased current requirement.

Selection **2** or **3** may also include an output voltage drop as a function of an increased current requirement. The **Carrier Frequency** should be set below 4 kHz.

Settings:

- No Decrease and No Limit
- Valid Decrease and No Limit
- No Decrease and Limit Small Pulse
- Valid Decrease and Limit Small Pulse

Direct Access Number — F316

Parameter Type — **Selection List**

Factory Default — **Valid Decrease and No Limit**

Changeable During Run — **Yes**

Synchronized Deceleration Time

Program ⇒ Protection ⇒ Under-Voltage/Ridethrough

In the event that the **Ridethrough** function activates in a multiple-motor application it will be necessary to manage the stopping motors synchronously as not to damage the product being processed (e.g., wire spools, bobbin winder for textile machines, etc.).

This parameter is used to minimize the product breakage during a momentary power outage. This function stops multiple machines simultaneously or makes them reach their respective command frequencies simultaneously by regulating their deceleration times.

See parameter [F302](#) for additional information on this setting.

Direct Access Number — F317

Parameter Type — **Numerical**

Factory Default — **2.0**

Changeable During Run — **Yes**

Minimum — 0.1

Maximum — 6000.0

Units — Seconds

F318

F322

Synchronized Acceleration Time

Program ⇒ Protection ⇒ Under-Voltage/Ridethrough

In the event that the **Ridethrough** function activates in a multiple-motor application it will be necessary to manage the accelerating motors synchronously as not to damage the product being processed (e.g., wire spools, bobbin winder for textile machines, etc.).

This parameter is used to minimize the product breakage during a momentary power outage. This function orchestrates the acceleration of multiple machines simultaneously or makes them reach their respective command frequencies simultaneously by regulating their acceleration times.

See parameter **F302** for additional information on this setting.

Direct Access Number — F318

Parameter Type — **Numerical**

Factory Default — **2.0**

Changeable During Run — **Yes**

Minimum — 0.10

Maximum — 6000.0

Units — Seconds

Drooping Gain

Program ⇒ Feedback ⇒ Drooping Control

This parameter sets the effective 100% output torque level while operating in the **Drooping Control** mode. This value is the upper torque limit of the motor being driven by a given ASD while operating in the **Drooping Control** mode.

Note: The maximum frequency output is not limited by the setting of **F011** while operating in the **Drooping Control** mode.

Drooping

Drooping Control, also called **Load Share**, is used to share the load among two or more mechanically coupled motors. Unlike **Stall**, which reduces the output frequency in order to limit the load once the load reaches a preset level, **Drooping** can decrease or increase the V/f setting of a motor to maintain a balance between the output torque levels of mechanically coupled motors.

Because of variances in gearboxes, sheaves, belts, motors, and since the speed of the motor is constrained by the mechanical system, one motor may experience more load than its counterpart and may become overloaded.

Drooping Control allows the overloaded motor to slow down, thus shedding load and encouraging a lightly-loaded motor to pick up the slack. The goal of **Drooping Control** is to have the same torque ratios for mechanically coupled motors.

Direct Access Number — F320

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 100.0

Units — %

Speed at 0% Drooping Gain

Program ⇒ Feedback ⇒ Drooping Control

This parameter sets the motor speed when at the 0% output torque gain while operating in the **Drooping Control** mode. This function determines the lowest speed that **Drooping** will be in effect for motors that share the same load.

Direct Access Number — F321

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 320.0

Units — Hz

Speed at F320 Drooping Gain

Program ⇒ Feedback ⇒ Drooping Control

This parameter sets the motor speed when at the 100% output torque gain while operating in the **Drooping Control** mode. This function determines the speed of the individual motors at the 100% **Drooping Gain** setting for motors that share the same load.

Direct Access Number — F322

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 320.0

Units — Hz

F323

F328

Drooping Insensitive Torque

Program ⇒ Feedback ⇒ Drooping Control

This parameter defines a torque range in which the **Drooping Control** settings will be ignored and the programmed torque settings will be followed.

Direct Access Number — F323

Parameter Type — **Numerical**

Factory Default — **10.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 100.0

Units — %

Drooping Output Filter

Program ⇒ Feedback ⇒ Drooping Control

This parameter is used to set the rate of output change allowed when operating in the **Drooping Control** mode.

Jerky operation may be reduced by increasing this setting.

Direct Access Number — F324

Parameter Type — **Numerical**

Factory Default — **100.0**

Changeable During Run — **Yes**

Minimum — 0.1

Maximum — 200.0

Units — Radians/Second

Express-Speed Selection

Program⇒ Crane/Hoist ⇒ Express Speed

This parameter enables the **Express Speed** function by selecting an operating mode. The **Express Speed** function accelerates the output frequency of the ASD from the programmed speed to the setting established in F330.

Select **Off** to disable the **Express Speed** feature.

Enabling the **Express Speed** function requires that an operating mode be selected here, and that the criteria of parameters F331 – F333 be met.

Settings:

Off

Auto Speed (F-Motor: Up, R-Generator:Down)

Auto Speed (F-Generator: Down, R-Motor:Up)

F330 Setting (F-Motor: Up, R-Generator:Down)

F330 Setting (F-Generator: Down, R-Motor:Up)

Direct Access Number — F328

Parameter Type — **Selection List**

Factory Default — **Off**

Changeable During Run — **Yes**

Express Speed Setup and Run Criteria.

F328 = Off or Enabled.

If enabled, the following criteria must be met for **Express Speed** operation:

ASD output speed > F331 setting.

ASD output torque < F335 setting.

F331 and F335 condition exists for longer than F333 setting.

F329

F332

Express-Speed Learning Function

Program ⇒ Crane/Hoist

The **Express Speed** function accelerates the output frequency of the ASD from the programmed speed to the setting established in [F330](#) and is primarily used with **Crane/Hoist** functions.

The **Express-Speed Learning Function** is to be run with the maximum load that will allow for the **Express Speed** (Auto Speed ONLY) function to be engaged. During the execution of the **Express-Speed Learning Function** parameters [F335](#), [F336](#), [F337](#), and [F338](#) are automatically adjusted and set as a function of the load.

Application-specific adjustments may be required.

Note: This function should be setup with a light load only.

Settings:

- Off
- Forward/Reverse
- Forward Only

Direct Access Number — [F329](#)

Parameter Type — **Selection List**

Factory Default — **Off**

Changeable During Run — **No**

Automatic Express-Speed Operation Frequency

Program ⇒ Crane/Hoist ⇒ Express Speed

This parameter establishes the speed to which the ASD will ramp when operating in the **Express Speed** mode.

Direct Access Number — [F330](#)

Parameter Type — **Numerical**

Factory Default — **60.00**

Changeable During Run — **No**

Minimum — 30.00

Maximum — **Upper Limit (F012)**

Units — Hz

Express-Speed Operation Switching Lower-Limit Frequency

Program ⇒ Crane/Hoist ⇒ Express Speed

This parameter sets an output frequency threshold that, once surpassed, allows the **Express Speed** function to be used.

The **Express Speed** function may be used if the frequency threshold set at this parameter and the following conditions are met:

- 1) **Express-Speed Operation Enable** is configured at [F328](#).
- 2) The output torque is less than the setting established in [F335](#) when reaching the frequency setting here.

Direct Access Number — [F331](#)

Parameter Type — **Numerical**

Factory Default — **60.00**

Changeable During Run — **Yes**

Minimum — 30.0

Maximum — **Upper Limit (F012)**

Units — Hz

Express-Speed Operation Load Wait Time

Program ⇒ Crane/Hoist ⇒ Express Speed

This parameter determines the length of time that the load requirement must meet the **Express Speed** criteria before the **Express-Speed Enable (F328)** is recognized.

Once recognized, the timer setting of [F333](#) must expire to engage the **Express Speed** function.

Direct Access Number — [F332](#)

Parameter Type — **Numerical**

Factory Default — **0.5**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 10.0

Units — Seconds

<p>Express-Speed Operation Detection Time</p> <p>Program⇒ Crane/Hoist ⇒ Express Speed</p> <p>After the time setting of F332 times out, this parameter determines the length of time that the Express Speed criteria must be met until the Express Speed function engages.</p>	<p>Direct Access Number — F333</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — 10.0</p> <p>Units — Seconds</p>
<p>Express-Speed Operation Heavy-Load Detection Time</p> <p>Program⇒ Crane/Hoist ⇒ Express Speed</p> <p>While operating in the Express Speed mode, this parameter determines the length of time that a load exceeding the Express Speed operation criteria may exist before the Express Speed mode is terminated and normal operation resumes.</p>	<p>Direct Access Number — F334</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.5</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — 10.0</p> <p>Units — Seconds</p>
<p>Switching Load Torque During Power Running</p> <p>Program⇒ Crane/Hoist ⇒ Express Speed</p> <p>During power running, this parameter establishes the threshold torque level that is used to determine if the Express Speed (F328) operation may engage or remain engaged if active.</p> <p>This parameter is automatically adjusted during Express-Speed Learning.</p> <p>If the Express Speed operation is terminated normal operation resumes.</p> <p><i>Note: Power running may be during forward, reverse, acceleration, or deceleration, but not during regeneration.</i></p>	<p>Direct Access Number — F335</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 40.00</p> <p>Changeable During Run — No</p> <p>Minimum — -250.00</p> <p>Maximum — +250.00</p> <p>Units — %</p>
<p>Heavy-Load Torque During Power Running</p> <p>Program⇒ Crane/Hoist ⇒ Express Speed</p> <p>During power running, this parameter establishes the threshold torque level that is used to determine if the Express Speed (F328) operation may engage or remain engaged if active.</p> <p>If the Express Speed operation is terminated normal operation resumes.</p>	<p>Direct Access Number — F336</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 150.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — -250.00</p> <p>Maximum — +250.00</p> <p>Units — %</p>
<p>Heavy-Load Torque During Fixed-Speed Power Running</p> <p>Program⇒ Crane/Hoist ⇒ Express Speed</p> <p>During constant power running, this parameter establishes the threshold torque level that is used to determine if the Express Speed (F328) operation may engage or remain engaged if active.</p> <p>If the Express Speed operation is terminated normal operation resumes.</p>	<p>Direct Access Number — F337</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 150.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — -250.00</p> <p>Maximum — +250.00</p> <p>Units — %</p>

F338

F351

Switching Load Torque During Dynamic Braking

Program ⇒ Crane/Hoist ⇒ Express Speed

During dynamic braking, this parameter establishes the threshold torque level that is used to determine if the **Express Speed (F328)** operation may engage or remain engaged if active.

If the **Express Speed** operation is terminated normal operation resumes.

Direct Access Number — F338

Parameter Type — Numerical

Factory Default — 30.00

Changeable During Run — Yes

Minimum — -250.00

Maximum — +250.00

Units — %

Accel/Decel Suspended Function

Program ⇒ Fundamental ⇒ Acc/Dec 1

To maintain a constant speed setting while running, this parameter may be used to suspend speed changes for a user-set length of time.

The **Accel/Decel Suspend** function is enabled by setting this parameter to either **Terminal Board Input** or to F350 – F353.

Selecting **Terminal Board Input** at this parameter requires that a discrete input terminal be set to **Dwell Signal** (see Table 7 on pg. 236 for a listing of available settings). Upon activation of the **Dwell Signal** terminal the output frequency remains at the at-activation speed for the duration of the activation. When deactivated the programmed accel or decel ramp resumes.

Selecting F350 – F353 at this parameter requires that the acceleration and/or the deceleration **Suspend Frequency** and **Suspend Time** settings be completed at F350, F351, F352, and F353. Upon reaching the frequency setting of F350 (Accel) or F352 (Decel), the Accel/Decel ramp will cease and the output frequency will hold at the threshold frequency setting for the time setting of F351 for acceleration or F353 for deceleration.

Settings:

Off

F350 – F353 Settings

Terminal Board Input (ACE G9-120V-PCB)

Direct Access Number — F349

Parameter Type — Selection List

Factory Default — Off

Changeable During Run — Yes

Acceleration Suspend Frequency

Program ⇒ Fundamental ⇒ Acc/Dec 1

When **Enabled** at F349, this parameter is used to set the frequency at which the **Acceleration Suspend** function will activate.

During acceleration, this parameter sets the frequency at which acceleration will stop and the motor will run at the setting of this parameter for the time setting of F351.

Direct Access Number — F350

Parameter Type — Numerical

Factory Default — 0.00

Changeable During Run — Yes

Minimum — 0.00

Maximum — Max. Freq. (F011)

Units — Hz

Acceleration Suspend Time

Program ⇒ Fundamental ⇒ Acc/Dec 1

When **Enabled** at F349, this parameter is used to set the duration of activation of the **Acceleration Suspend** function when initiated by reaching the **Acceleration Suspend Frequency** setting (F350).

Once this parameter times out the acceleration rate will resume from the point of suspension.

Direct Access Number — F351

Parameter Type — Numerical

Factory Default — 0.0

Changeable During Run — Yes

Minimum — 0.0

Maximum — 10.0

Units — Seconds

F352**F353****Deceleration Suspend Frequency**

Program ⇒ Fundamental ⇒ Acc/Dec 1

When **Enabled** at **F349**, this parameter is used to set the frequency at which the **Deceleration Suspend** function will activate.

During deceleration, this parameter sets the frequency at which deceleration will stop and the motor will run at the setting of this parameter for the time setting of **F353**.

Direct Access Number — F352

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

Deceleration Suspend Time

Program ⇒ Fundamental ⇒ Acc/Dec 1

When **Enabled** at **F349**, this parameter is used to set the duration of activation of the **Deceleration Suspend** function when initiated by reaching the **Deceleration Suspend Frequency** setting (**F352**).

Once this parameter times out the deceleration rate will resume from the point of suspension.

Direct Access Number — F353

Parameter Type — **Numerical**

Factory Default — **0.0**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 10.0

Units — Seconds

Commercial Power/ASD Output Switching

Program ⇒ Terminal ⇒ Line Power Switching

This parameter **Enables/Disables** the **Commercial Power/ASD Output Switching** function.

When enabled, the system may be set up to discontinue using the output of the ASD and to switch to the commercial power in the event that 1) a trip is incurred, 2) a user-set frequency is reached, or 3) if initiated by a discrete input terminal.

Once set up with the proper switching frequency and hold times, the system will switch to commercial power upon reaching the **F355** frequency criterion.

Switching may also be accomplished manually by activating the discrete input terminal **Commercial Power ASD Switching**. Terminal activation forces the ASD output speed to accelerate to the **F355** switching frequency, resulting in the ASD-to-commercial power switching.

Deactivation of the discrete input terminal starts the hold-time counter setting (**F356**) for ASD-to-commercial power switching. Once timed out the motor resumes normal commercial power operation.

Settings:

- Off
- Switch at Signal Input and Trip
- Switch at Signal Input with Switching Frequency
- Switch at Signal Input and Trip with Switching Frequency

Switching Setup Requirements

F354 — Enable the switching function.

F355 — Set the switching frequency.

F356 — (Speed) Hold -time before applying ASD output after the switching criteria has been met.

F357 — (Speed) Hold -time before applying commercial power after the switching criteria has been met.


F358 — (Speed) Hold -time of applying commercial power after the switching criteria has been met.

Set a discrete input terminal to **Commercial Power ASD Switching**.

Set **OUT1** and **OUT2** to **Commercial Power/ASD Switching 1** and **2**, respectively.

Note: Ensure that the switching directions are the same and that **F311** is set to **Permit All**.

Note: The **OUT1** and **OUT2** outputs assigned to **Commercial Power/ASD Switching Output** are used to actuate the re-routing contactors.



Direct Access Number — **F354**

Parameter Type — **Selection List**

Factory Default — **Off**

Changeable During Run — **No**

<p>Commercial Power/ASD Switching Frequency</p> <p>Program ⇒ Terminal ⇒ Line Power Switching</p> <p>When enabled at F354 and with a properly configured discrete output terminal, this parameter sets the frequency at which the At Frequency Powerline Switching function engages.</p> <p>The At Frequency Powerline Switching function commands the system to discontinue using the output of the ASD and to switch to commercial power once reaching the frequency set here.</p> <p>See parameter F354 for additional information on this setting.</p>	<p>Direct Access Number — F355</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 60.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>ASD-Side Switching Waiting Time</p> <p>Program ⇒ Terminal ⇒ Line Power Switching</p> <p>This parameter determines the amount of time that the ASD will wait before outputting a signal to the motor once the switch-to-ASD-output criteria has been met.</p> <p>See parameter F354 for additional information on this setting.</p>	<p>Direct Access Number — F356</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.10</p> <p>Maximum — 10.00</p> <p>Units — Seconds</p>
<p>Commercial Power Side Switching Waiting Time</p> <p>Program ⇒ Terminal ⇒ Line Power Switching</p> <p>This parameter determines the amount of time that the ASD will wait before allowing commercial power to be applied to the motor once the switch-to-commercial-power criteria has been met.</p> <p>See parameter F354 for additional information on this setting.</p>	<p>Direct Access Number — F357</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.62</p> <p>Changeable During Run — Yes</p> <p>Minimum — (ASD-Dependent)</p> <p>Maximum — 10.00</p> <p>Units — Seconds</p>
<p>Commercial Power Switching Freq. Holding Time</p> <p>Program ⇒ Terminal ⇒ Line Power Switching</p> <p>This parameter determines the amount of time that the connection to commercial power is maintained once the switch-to-ASD-output criteria has been met.</p> <p>See parameter F354 for additional information on this setting.</p>	<p>Direct Access Number — F358</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 2.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.10</p> <p>Maximum — 10.00</p> <p>Units — Seconds</p>
<p>PID Control Switching</p> <p>Program ⇒ Feedback ⇒ Feedback</p> <p>This parameter is used to set the PID control mode.</p> <p>Selecting Process PID uses the upper- and lower-limit settings of parameters F367 and F368.</p> <p>Selecting Speed PID uses the upper- and lower-limit settings of parameters F370 and F371.</p> <p>Settings:</p> <ul style="list-style-type: none"> PID Off Process PID Speed PID Easy Positioning PID (Not Used) 	<p>Direct Access Number — F359</p> <p>Parameter Type — Selection List</p> <p>Factory Default — PID Off</p> <p>Changeable During Run — No</p>

F360

F364

<p>PID Feedback Signal</p> <p>Program ⇒ Feedback ⇒ Feedback</p> <p>This parameter Enables/Disables PID feedback control. When enabled, this parameter determines the source of the motor-control feedback.</p> <p>Settings:</p> <ul style="list-style-type: none"> PID Control Disabled V/I RR RX RX2 (AI1) Option V/I PG Feedback Option <p>Proportional-Integral-Derivative (PID) — A closed-loop control technique that seeks error minimization by reacting to three values: One that is proportional to the error, one that is representative of the error, and one that is representative of the rate of change of the error.</p>	<p>Direct Access Number — F360</p> <p>Parameter Type — Selection List</p> <p>Factory Default — PID Control Disabled</p> <p>Changeable During Run — Yes</p>
<p>PID Feedback Delay Filter</p> <p>Program ⇒ Feedback ⇒ Feedback</p> <p>This parameter determines the delay in the ASD output response to the motor-control feedback signal (signal source is selected at F360).</p>	<p>Direct Access Number — F361</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.1</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — 25.0</p>
<p>PID Feedback Proportional Gain</p> <p>Program ⇒ Feedback ⇒ Feedback</p> <p>This parameter determines the degree that the Proportional function affects the output signal. The larger the value entered here, the quicker the ASD responds to changes in feedback.</p>	<p>Direct Access Number — F362</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.10</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.01</p> <p>Maximum — 100.0</p>
<p>PID Feedback Integral Gain</p> <p>Program ⇒ Feedback ⇒ Feedback</p> <p>This parameter determines the degree that the Integral function affects the output signal. The smaller the value here, the more pronounced the effect of the integral function on the output signal.</p>	<p>Direct Access Number — F363</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.10</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.01</p> <p>Maximum — 100.00</p>
<p>PID Deviation Upper Limit</p> <p>Program ⇒ Feedback ⇒ Feedback</p> <p>This parameter determines the maximum amount that the feedback may increase the output signal.</p>	<p>Direct Access Number — F364</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 60.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 60.00</p> <p>Units — Hz</p>

F365

F370

<p>PID Deviation Lower Limit</p> <p>Program ⇒ Feedback ⇒ Feedback</p> <p>This parameter determines the maximum amount that the feedback may decrease the output signal.</p>	<p>Direct Access Number — F365</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 60.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 60.00</p> <p>Units — Hz</p>
<p>PID Feedback Differential Gain</p> <p>Program ⇒ Feedback ⇒ Feedback</p> <p>This parameter determines the degree that the Differential function affects the output signal. The larger the value entered here, the more pronounced the effect of the differential function for a given feedback signal level.</p>	<p>Direct Access Number — F366</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 2.55</p>
<p>Process Upper Limit</p> <p>Program ⇒ Feedback ⇒ Feedback</p> <p>Selecting Process PID at parameter F359 allows for this parameter setting to function as the Upper Limit while operating in the PID Control mode.</p>	<p>Direct Access Number — F367</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 60.00</p> <p>Changeable During Run — No</p> <p>Minimum — Lower Limit (F013)</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>
<p>Process Lower Limit</p> <p>Program ⇒ Feedback ⇒ Feedback</p> <p>Selecting Process PID at parameter F359 allows for this parameter setting to function as the Lower Limit while operating in the PID Control mode.</p>	<p>Direct Access Number — F368</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — No</p> <p>Minimum — Lower Limit (F013)</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>
<p>PID Control Wait Time</p> <p>Program ⇒ Feedback ⇒ Feedback</p> <p>This parameter is used to delay the start of PID control at start up. During the wait time set here, the ASD will follow the frequency control input of the process value and the feedback input will be ignored until this setting times out. At which time the PID setup assumes control.</p>	<p>Direct Access Number — F369</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 2400</p> <p>Units — Seconds</p>
<p>PID Output Upper Limit</p> <p>Program ⇒ Feedback ⇒ Feedback</p> <p>Selecting Speed PID at parameter F359 allows for this parameter setting to function as the Upper Limit while operating in the PID Control mode.</p>	<p>Direct Access Number — F370</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 60.00</p> <p>Changeable During Run — No</p> <p>Minimum — Lower Limit (F013)</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>

F371

F376

<p>PID Output Lower Limit</p> <p>Program ⇒ Feedback ⇒ Feedback</p> <p>Selecting Speed PID at parameter F359 allows for this parameter setting to function as the Lower Limit while operating in the PID Control mode.</p>	<p>Direct Access Number — F371</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 4.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — Lower Limit (F013)</p> <p>Maximum — Upper Limit (F012)</p> <p>Units — Hz</p>
<p>Process Increasing Rate</p> <p>Program ⇒ Feedback ⇒ Feedback</p> <p>This parameter is used to limit the rate that the output of the ASD may increase for a given difference in the speed reference and the PID feedback value.</p>	<p>Direct Access Number — F372</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 10.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.1</p> <p>Maximum — 600.0</p> <p>Units — Seconds</p>
<p>Process Decreasing Rate</p> <p>Program ⇒ Feedback ⇒ Feedback</p> <p>This parameter is used to limit the rate that the output of the ASD may decrease for a given difference in the speed reference and the PID feedback value.</p>	<p>Direct Access Number — F373</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 10.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.1</p> <p>Maximum — 600.0</p> <p>Units — Seconds</p>
<p>Number of PG Input Pulses</p> <p>Program ⇒ Feedback ⇒ PG</p> <p>This parameter is used to set the number of pulses output from a shaft-mounted encoder that is used to indicate one revolution of rotation (360°) of the motor or of the motor-driven equipment.</p>	<p>Direct Access Number — F375</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1024</p> <p>Changeable During Run — No</p> <p>Minimum — 12</p> <p>Maximum — 9999</p>
<p>Number of PG Input Phases</p> <p>Program ⇒ Feedback ⇒ PG</p> <p>This parameter determines the type of information that is supplied by the phase encoder.</p> <p>Settings:</p> <ul style="list-style-type: none"> Single Phase Two Phase 	<p>Direct Access Number — F376</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Two Phase</p> <p>Changeable During Run — Yes</p>

F377

F401

PG Disconnection Detection

Program ⇒ Feedback ⇒ PG

This parameter **Enables/Disables** the system's monitoring of the PG connection status when using encoders with line driver outputs.

Note: *The PG Vector Feedback Board option is required to use this feature.*

Settings:

- Disabled
- Enabled with Filter
- Enabled (Detect Momentary Power Failure)

Simple Positioning Completion Range

Program ⇒ Feedback ⇒ PG

While operating in the **Positioning Control** mode, this parameter sets the range of accuracy for a **Stop** command initiated via the **ACE G9-120V-PCB**.

If the setting is too low the stop may be too abrupt.

Autotune 1

Program ⇒ Motor ⇒ Vector Motor Model

This parameter sets the **Autotune** command status.

Selecting **Reset Motor Defaults** for this parameter sets parameters **F410**, **F411**, **F412**, and **F413** to the factory default settings.

If selecting **Autotune on Run Command**, **Autotune Initiated by Input Terminal**, or **Autotune of Detail Parameters** for this parameter set the **Base Frequency**, **Base Frequency Voltage**, and the **Motor Rated Revolutions** to the nameplate values of the motor to achieve the best possible **Autotune** precision.

Settings:

- Autotune Disabled
- Reset Motor Defaults
- Enable Autotune on Run Command
- Autotuning by Input Terminal Signal (see [Table 7 on pg. 236](#))
- Motor Constant Auto Calculation

Slip Frequency Gain

Program ⇒ Motor ⇒ Vector Motor Model

This parameter provides a degree of slip compensation for a given load. A higher setting here decreases the slip allowed for a given load/ASD output ratio.

Direct Access Number — F377Parameter Type — **Selection List**Factory Default — **Enabled (Detect Momentary Power Failure)**Changeable During Run — **Yes****Direct Access Number — F381**Parameter Type — **Numerical**Factory Default — **100**Changeable During Run — **Yes**Minimum — **1**Maximum — **4000****Direct Access Number — F400**Parameter Type — **Selection List**Factory Default — **Autotune Disabled**Changeable During Run — **No****Direct Access Number — F401**Parameter Type — **Numerical**Factory Default — **70**Changeable During Run — **Yes**Minimum — **0**Maximum — **150**Units — **%**

F402

F409

<p>Autotune 2</p> <p>Program ⇒ Motor ⇒ Vector Motor Model</p> <p>This parameter introduces a thermal element into the autotuning equation and is used to automatically adjust the Autotune parameter values as a function of increases in the temperature of the motor.</p> <p>Settings:</p> <ul style="list-style-type: none"> Off Self-Cooled Motor Tuning Forced Air Cooled Motor Tuning 	<p>Direct Access Number — F402</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Off</p> <p>Changeable During Run — No</p>
<p>Motor Rated Capacity</p> <p>Program ⇒ Motor ⇒ Vector Motor Model</p> <p>This parameter is used to set the (Nameplate) rated capacity of the motor being used.</p>	<p>Direct Access Number — F405</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 11.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.1</p> <p>Maximum — 500.00</p> <p>Units — HP</p>
<p>Motor Rated Current</p> <p>Program ⇒ Motor ⇒ Vector Motor Model</p> <p>This parameter is used to set the (Nameplate) current rating of the motor being used.</p>	<p>Direct Access Number — F406</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 20.3</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.1</p> <p>Maximum — 2000.0</p> <p>Units — Amps</p>
<p>Motor Rated RPM</p> <p>Program ⇒ Motor ⇒ Vector Motor Model</p> <p>This parameter is used input the (Nameplate) rated speed of the motor.</p>	<p>Direct Access Number — F407</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1730</p> <p>Changeable During Run — Yes</p> <p>Minimum — 100</p> <p>Maximum — 60000</p> <p>Units — RPM</p>
<p>Base Frequency Voltage 1</p> <p>Program ⇒ Vector ⇒ Vector Motor Model</p> <p>The Motor Base Frequency Voltage 1 is the Motor 1 output voltage at the Base Frequency (F014). Regardless of the programmed value, the output voltage cannot be higher than the input voltage.</p> <p>The actual output voltage will be influenced by the input voltage of the ASD and the Supply Voltage Correction setting (F307).</p>	<p>Direct Access Number — F409</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 50.0</p> <p>Maximum — 660.0</p> <p>Units — Volts</p>

F410**F415**

<p>Motor Constant 1 (Torque Boost)</p> <p>Program ⇒ Motor ⇒ Vector Motor Model</p> <p>This parameter sets the primary resistance of the motor. Increasing this value can prevent a drop in the torque of the motor at low speeds. Increasing this value excessively can result in nuisance overload tripping.</p>	<p>Direct Access Number — F410</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — 30.0</p> <p>Units — %</p>
<p>Motor Constant 2 (No-Load Current)</p> <p>Program ⇒ Motor ⇒ Vector Motor Model</p> <p>This parameter is used to set the current level required to excite the motor. Specifying a value that is too high for this parameter may result in hunting (erratic motor operation).</p>	<p>Direct Access Number — F411</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — No</p> <p>Minimum — 10</p> <p>Maximum — 90</p> <p>Units — %</p>
<p>Motor Constant 3 (Leak Inductance)</p> <p>Program ⇒ Motor ⇒ Vector Motor Model</p> <p>This parameter is used to set the leakage inductance of the motor. A larger setting here results in higher output torque at high speeds.</p>	<p>Direct Access Number — F412</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 200</p> <p>Units — %</p>
<p>Motor Constant 4 (Rated Slip)</p> <p>Program ⇒ Motor ⇒ Vector Motor Model</p> <p>This parameter is used to set the secondary resistance of the motor. An increase in this parameter setting results in an increase of compensation for motor slip.</p>	<p>Direct Access Number — F413</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.01</p> <p>Minimum — 25.00</p> <p>Units — %</p>
<p>Exciting Strengthening Coefficient</p> <p>Program ⇒ Special ⇒ Special Parameters</p> <p>This parameter is used to increase the magnetic flux of the motor at low-speed. This feature is useful when increased torque at low speeds is required.</p>	<p>Direct Access Number — F415</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 100</p> <p>Changeable During Run — Yes</p> <p>Minimum — 100</p> <p>Maximum — 130</p> <p>Units — %</p>

F416**F423****Stall Prevention Factor 1**

Program ⇒ Protection ⇒ Stall

This parameter is to be adjusted in the event that the motor stalls when operated above the base frequency.

If a momentary heavy load occurs the motor may stall before the load current reaches the stall prevention level setting of **F601**.

A drop in the supply voltage may cause fluctuations of the load current or may cause motor vibration. A gradual adjustment of this parameter may alleviate this condition.

Start with a setting of 85 at these parameters and gradually adjust them from there one at a time until the desired results are produced.

Adjustments to this parameter may increase the load current of the motor and subsequently warrant an adjustment at the **Motor Overload Protection Level** setting.

Direct Access Number — F416Parameter Type — **Numerical**Factory Default — **100**Changeable During Run — **No**

Minimum — 10

Maximum — 250

Torque Command

Program ⇒ Torque ⇒ Torque Control

When operating in the **Torque Control** mode, this parameter allows the user to select the source of the torque command signal.

Settings:

V/I

RR

RX

Panel Keypad (**F725** Setting)

RS485 2-Wire

RS485 4-Wire

Communication Option Board

RX2 Option (AI1)

Direct Access Number — F420Parameter Type — **Selection List**Factory Default — **Panel Keypad (**F725** Setting)**Changeable During Run — **Yes****Tension Torque Bias Input**

Program ⇒ Torque ⇒ Torque Control

This parameter **Enables/Disables** the **Tension Torque Bias** input function.

This feature is enabled by selecting a **Tension Torque Bias** input signal source.

Settings:

Disabled

V/I

RR

RX

Panel Keypad (Not Used)

RS485 2-Wire

RS485 4-Wire

Communication Option Board

RX2 Option (AI1)

Direct Access Number — F423Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **Yes**

F424

F426

Load Sharing Gain Input

Program ⇒ Torque ⇒ Torque Control

This parameter **Enables/Disables** the **Load Sharing Gain** input function.

This feature is enabled by selecting a **Load Sharing Gain** input signal source.

Settings:

- Disabled
- V/I
- RR
- RX
- Panel Keypad
- RS485 2-Wire
- RS485 4-Wire
- Communication Option Board
- RX2 Option (A11)

Direct Access Number — F424

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **Yes**

Forward Speed Limit Input

Program ⇒ Torque ⇒ Torque Speed Limiting

This parameter **Enables/Disables** the **Forward Speed Limit Input** control function. When enabled and operating in the **Torque Control** mode, the forward speed limit is controlled by the input selected here.

If **Setting** is selected, the value set at [F426](#) is used as the **Forward Speed Limit** input.

Settings:

- Disabled
- V/I
- RR
- RX
- [F426 Setting](#)

Direct Access Number — F425

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **Yes**

Forward Speed Limit Level

Program ⇒ Torque ⇒ Torque Control

This parameter provides a value to be used as the **Forward Speed Limit** setting if [F426 Setting](#) is selected at [F425](#).

Direct Access Number — F426

Parameter Type — **Numerical**

Factory Default — **60.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Upper Limit (F012)**

Units — Hz

F427

F431

Reverse Speed Limit Input

Program ⇒ Torque ⇒ Torque Control

This parameter **Enables/Disables** the **Reverse Speed Limit Input** control function. When enabled and operating in the **Torque Control** mode, the reverse speed limit is controlled by the terminal selected here. If **Setting** is selected, the value set at **F428** is used as the **Reverse Speed Limit** input.

Settings:

Disabled
V/I
RR
RX
[F428 Setting](#)

Direct Access Number — F427Parameter Type — **Selection List**Factory Default — **F428 Setting**Changeable During Run — **Yes****Reverse Speed Limit Input Level**

Program ⇒ Torque ⇒ Torque Control

This parameter provides a value to be used as the **Reverse Speed Limit** setting if **Setting** is selected at **F427**.

Direct Access Number — F428Parameter Type — **Numerical**Factory Default — **60.00**Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Upper Limit (F012)**

Units — Hz

Speed Limit (Torque=0) Center Value Reference

Program ⇒ Torque ⇒ Torque Speed Limiting

The system has the ability to limit the amount that the speed may vary as a function of a changing load while operating in the **Torque Control** mode. This parameter sets the input terminal that will be used to control the allowable speed variance.

Settings:

Disabled
V/I
RR
RX
[F431 Setting](#)

Direct Access Number — F430Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **Yes****Speed Limit (Torque=0) Center Value**

Program ⇒ Torque ⇒ Torque Speed Limiting

The system has the ability to limit the amount that the speed may vary as a function of a changing load while operating in the **Torque Control** mode. This parameter sets the targeted speed. The plus-or-minus value (range) for this setting may be set at **F432**.

Direct Access Number — F431Parameter Type — **Numerical**Factory Default — **0.00**Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

F432

F441

<p>Speed Limit (Torque=0) Band</p> <p>Program ⇒ Torque ⇒ Torque Speed Limiting</p> <p>The system has the ability to limit the amount that the speed may vary as a function of a changing load while operating in the Torque Control mode. This parameter sets a plus-or-minus value (range) for the Speed Limit Torque Level (F431).</p>	<p>Direct Access Number — F432</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>Allow Specified Direction ONLY</p> <p>Program ⇒ Torque ⇒ Torque Speed Limiting</p> <p>This parameter Enables/Disables the Forward Run or Reverse Run mode.</p> <p>If either direction is disabled, commands received for the disabled direction will not be recognized.</p> <p>If both directions are disabled, the received direction command will determine the direction of the motor rotation.</p> <p>Settings</p> <ul style="list-style-type: none"> Disabled Enabled 	<p>Direct Access Number — F435</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Disabled</p> <p>Changeable During Run — No</p>
<p>Power Running Torque Limit 1</p> <p>Program ⇒ Torque ⇒ Torque Limit</p> <p>This parameter determines the source of the control signal for the positive torque limit setting.</p> <p>If Setting is selected, the value set at F441 is used as the Power Running Torque Limit 1 input.</p> <p>Settings:</p> <ul style="list-style-type: none"> V/I RR RX F441 Setting 	<p>Direct Access Number — F440</p> <p>Parameter Type — Selection List</p> <p>Factory Default — F441 Setting</p> <p>Changeable During Run — Yes</p>
<p>Power Running Torque Limit 1 Level</p> <p>Program ⇒ Torque ⇒ Torque Limit</p> <p>This parameter provides a value for the Power Running Torque Limit 1 setting if F441 Setting is selected at parameter F440.</p> <p>This value provides the positive torque upper limit for the #1 motor.</p>	<p>Direct Access Number — F441</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 250.0 (Disabled)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 250.0 (Disabled)</p> <p>Units — %</p>

F442

F446

<p>Dynamic Braking Torque Limit 1</p> <p>Program ⇒ Torque ⇒ Torque Limit</p> <p>This parameter determines the source of the Regenerative Torque Limit control signal.</p> <p>If Setting is selected, the value set at F443 is used for this parameter.</p> <p>Settings:</p> <ul style="list-style-type: none"> V/I RR RX F443 Setting 	<p>Direct Access Number — F442</p> <p>Parameter Type — Selection List</p> <p>Factory Default — F443 Setting</p> <p>Changeable During Run — Yes</p>
<p>Dynamic Braking Torque Limit 1 Level</p> <p>Program ⇒ Torque ⇒ Torque Limit</p> <p>This parameter provides a value to be used as the Regeneration Torque Limit 1 if F443 Setting is selected at parameter F442.</p> <p>Set this parameter to 250% to disable this function.</p>	<p>Direct Access Number — F443</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 250.0 (Disabled)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 249.9</p> <p>Units — %</p>
<p>Power Running Torque Limit 2 Level</p> <p>Program ⇒ Torque ⇒ Manual Torque Limit</p> <p>This parameter is used to set the positive torque upper limit for the #2 motor profile when multiple motors are controlled by a single ASD or when a single motor is to be controlled by multiple profiles.</p>	<p>Direct Access Number — F444</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 250.0 (Disabled)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 250.0 (Disabled)</p> <p>Units — %</p>
<p>Dynamic Braking Torque Limit 2 Level</p> <p>Program ⇒ Torque ⇒ Manual Torque Limit</p> <p>This parameter is used to set the negative torque upper limit for the #2 motor profile when multiple motors are controlled by a single ASD or when a single motor is to be controlled by multiple profiles.</p>	<p>Direct Access Number — F445</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 250.0 (Disabled)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 250.0 (Disabled)</p> <p>Units — %</p>
<p>Power Running Torque Limit 3 Level</p> <p>Program ⇒ Torque ⇒ Manual Torque Limit</p> <p>This parameter is used to set the positive torque upper limit for the #3 motor profile when multiple motors are controlled by a single ASD or when a single motor is to be controlled by multiple profiles.</p>	<p>Direct Access Number — F446</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 250.0 (Disabled)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 250.0 (Disabled)</p> <p>Units — %</p>

F447

F452

<p>Dynamic Braking Torque Limit 3 Level</p> <p>Program ⇒ Torque ⇒ Manual Torque Limit</p> <p>This parameter is used to set the negative torque upper limit for the #3 motor profile when multiple motors are controlled by a single ASD or when a single motor is to be controlled by multiple profiles.</p>	<p>Direct Access Number — F447</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 250.0 (Disabled)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 250.0 (Disabled)</p> <p>Units — %</p>
<p>Power Running Torque Limit 4 Level</p> <p>Program ⇒ Torque ⇒ Manual Torque Limit</p> <p>This parameter is used to set the positive torque upper limit for the #4 motor profile when multiple motors are controlled by a single ASD or when a single motor is to be controlled by multiple profiles.</p>	<p>Direct Access Number — F448</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 250.0 (Disabled)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 250.0 (Disabled)</p> <p>Units — %</p>
<p>Dynamic Braking Torque Limit 4 Level</p> <p>Program ⇒ Torque ⇒ Manual Torque Limit</p> <p>This parameter is used to set the negative torque upper limit for the #4 motor profile when multiple motors are controlled by a single ASD or when a single motor is to be controlled by multiple profiles.</p>	<p>Direct Access Number — F449</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 250.0 (Disabled)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 250.0 (Disabled)</p> <p>Units — %</p>
<p>Accel/Decel Operation After Torque Limit</p> <p>Program ⇒ Torque ⇒ Torque Limit</p> <p>In a Crane/Hoist application that is operating using a mechanical brake, this parameter is used to minimize the delay between the brake release and the output torque reaching a level that can sustain the load.</p> <p>This setting may reference time or the operating speed of the motor.</p> <p>Settings:</p> <ul style="list-style-type: none"> In Sync with Accel/Decel In Sync with Minimum Time 	<p>Direct Access Number — F451</p> <p>Parameter Type — Selection List</p> <p>Factory Default — In Sync with Accel/Decel</p> <p>Changeable During Run — Yes</p>
<p>Power Running Stall Continuous Trip Detection Time</p> <p>Program ⇒ Protection ⇒ Stall</p> <p>This parameter is used to extend the Over-Voltage Stall (F305) and the Over-Current Stall (F017) time settings.</p>	<p>Direct Access Number — F452</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — 1.0</p> <p>Units — Seconds</p>

<p>Dynamic Braking Stall Prevention Mode</p> <p>Program ⇒ Protection ⇒ Stall</p> <p>The function of this parameter is to disable the Over-Voltage Stall (F305) and the Over-Current Stall (F017) function during regeneration <u>only</u>.</p> <p>Application-specific conditions may occur that warrant disabling the Stall function during regeneration.</p> <p>Settings:</p> <ul style="list-style-type: none"> Disabled (Stall During Dynamic Braking) Enabled (No Stall During Dynamic Braking) 	<p>Direct Access Number — F453</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Enabled</p> <p>Changeable During Run — Yes</p>
<p>Current Control Proportional Gain</p> <p>Program ⇒ Feedback ⇒ PG</p> <p>This parameter sets the sensitivity of the ASD when monitoring the output current to control speed.</p> <p>The larger the value entered here, the more sensitive the ASD is to changes in the received feedback.</p>	<p>Direct Access Number — F458</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — No</p> <p>Minimum — 0.0</p> <p>Maximum — 100.0</p>
<p>Speed Loop Proportional Gain</p> <p>Program ⇒ Feedback ⇒ PG</p> <p>During closed-loop operation, this parameter sets the response sensitivity of the ASD when monitoring the output speed for control.</p> <p>The larger the value entered here, the larger the change in the output speed for a given received feedback signal.</p>	<p>Direct Access Number — F460</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — No</p> <p>Minimum — 1</p> <p>Maximum — 9999</p>
<p>Speed Loop Stabilization Coefficient</p> <p>Program ⇒ Feedback ⇒ PG</p> <p>During closed-loop operation, this parameter sets the response sensitivity of the ASD when monitoring the output speed for control.</p> <p>The larger the value entered here, the quicker the response to changes in the received feedback.</p>	<p>Direct Access Number — F461</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 100</p> <p>Changeable During Run — Yes</p> <p>Minimum — 1</p> <p>Maximum — 9999</p>
<p>Load Moment of Inertia 1</p> <p>Program ⇒ Feedback ⇒ PG</p> <p>This parameter is used for calculating accel/decel torque when compensating for load inertia while operating in the Drooping Control mode.</p>	<p>Direct Access Number — F462</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 35</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 100</p>
<p>Second Speed Loop Proportional Gain</p> <p>Program ⇒ Feedback ⇒ PG</p> <p>During closed-loop operation, this parameter sets the sensitivity of the ASD when monitoring the output speed for control.</p> <p>The larger the value entered here, the more sensitive the ASD is to changes in the received feedback.</p>	<p>Direct Access Number — F463</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — No</p> <p>Minimum — 1</p> <p>Maximum — 9999</p>

F464

F471

<p>Second Speed Loop Stabilization Coefficient</p> <p>Program ⇒ Feedback ⇒ PG</p> <p>During closed-loop operation, this parameter sets the response sensitivity of the ASD when monitoring the output speed for control.</p> <p>The larger the value entered here, the quicker the response to changes in the received feedback.</p>	<p>Direct Access Number — F464</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1</p> <p>Changeable During Run — Yes</p> <p>Minimum — 1</p> <p>Maximum — 9999</p>
<p>Load Moment of Inertia 2</p> <p>Program ⇒ Feedback ⇒ PG</p> <p>This parameter is used for calculating accel/decel torque when compensating for load inertia while operating in the Drooping Control mode.</p>	<p>Direct Access Number — F465</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 35</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 100</p>
<p>Speed PID Switching Frequency</p> <p>Program ⇒ Feedback ⇒ Feedback</p> <p>While running, this parameter establishes the threshold speed setting that is used to determine if PID control may engage or remain engaged if active.</p>	<p>Direct Access Number — F466</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>V/I Input Bias</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to fine-tune the bias of the V/I input terminals.</p> <p><i>Note:</i> See note on pg. 55 for additional information on the V/I terminal.</p> <p>This setting may be used to ensure that the zero level of the input source (pot, pressure transducer, flow meter, etc.) is also the zero level setting of the ASD system.</p> <p>This is accomplished by setting the input source to zero and adjusting this setting to provide an output of zero from the ASD.</p>	<p>Direct Access Number — F470</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 127</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 255</p>
<p>V/I Input Gain</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to fine tune the gain of the V/I input terminals.</p> <p><i>Note:</i> See note on pg. 55 for additional information on the V/I terminal.</p> <p>This setting may be used to ensure that the 100% level of the input source (pot, pressure transducer, flow meter, etc.) is also the 100% level setting of the ASD system.</p> <p>This is accomplished by setting the input source to 100% and adjusting this setting to provide an output of 100% from the ASD.</p>	<p>Direct Access Number — F471</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 129</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 255</p>

F472

F475

<p>RR Input Bias</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to fine tune the bias of the RR input terminal when this terminal is used as the control input while operating in the Speed Control mode or the Torque Control mode.</p> <p>This setting may be used to ensure that the zero level of the input source (pot, pressure transducer, flow meter, etc.) is also the zero level setting of the ASD system.</p> <p>This is accomplished by setting the input source to zero and adjusting this setting to provide an output of zero from the ASD.</p>	<p>Direct Access Number — F472</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 128</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 255</p>
<p>RR Input Gain</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to fine tune the gain of the RR input terminal when this terminal is used as the control input while operating in the Speed Control mode or the Torque Control mode.</p> <p>This setting may be used to ensure that the 100% level of the input source (pot, pressure transducer, flow meter, etc.) is also the 100% level setting of the ASD system.</p> <p>This is accomplished by setting the input source to 100% and adjusting this setting to provide an output of 100% from the ASD.</p>	<p>Direct Access Number — F473</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 154</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 255</p>
<p>RX Input Bias</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to fine tune the bias of the RX input terminal when this terminal is used as the control input while operating in the Speed Control mode or the Torque Control mode.</p> <p>This setting may be used to ensure that the zero level of the input source (pot, pressure transducer, flow meter, etc.) is also the zero level setting of the ASD system.</p> <p>This is accomplished by setting the input source to zero and adjusting this setting to provide an output of zero from the ASD.</p>	<p>Direct Access Number — F474</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 127</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 255</p>
<p>RX Input Gain</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to fine tune the gain of the RX input terminal when this terminal is used as the control input while operating in the Speed Control mode or the Torque Control mode.</p> <p>This setting may be used to ensure that the 100% level of the input source (pot, pressure transducer, flow meter, etc.) is also the 100% level setting of the ASD system.</p> <p>This is accomplished by setting the input source to 100% and adjusting this setting to provide an output of 100% from the ASD.</p>	<p>Direct Access Number — F475</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 127</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 255</p>

F476

F479

<p>RX2 Option (AI1) Input Bias</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to fine tune the bias of the RX2 (AI1) input terminal when this terminal is used as the control input while operating in the Speed Control mode or the Torque Control mode.</p> <p>This setting may be used to ensure that the zero level of the input source (pot, pressure transducer, flow meter, etc.) is also the zero level setting of the ASD system.</p> <p>This is accomplished by setting the input source to zero and adjusting this setting to provide a zero output from the ASD.</p>	<p>Direct Access Number — F476</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 128</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 255</p>
<p>RX2 Option (AI1) Input Gain</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to fine tune the gain of the RX2 (AI1) input terminal when this terminal is used as the control input while operating in the Speed Control mode or the Torque Control mode.</p> <p>This setting may be used to ensure that the 100% level of the input source (pot, pressure transducer, flow meter, etc.) is also the 100% level setting of the ASD system.</p> <p>This is accomplished by setting the input source to 100% and adjusting this setting to provide an output of 100% from the ASD.</p>	<p>Direct Access Number — F477</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 128</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 255</p>
<p>V/I Input Bias (AI2 Option Board Input)</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to fine tune the bias of the Optional AI2 input terminal when this terminal is used as the control input while operating in the Speed Control mode or the Torque Control mode.</p> <p>This setting may be used to ensure that the zero level of the input source (pot, pressure transducer, flow meter, etc.) is also the zero level setting of the ASD system.</p> <p>This is accomplished by setting the input source to zero and adjusting this setting to provide a zero output from the ASD.</p>	<p>Direct Access Number — F478</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 128</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 255</p>
<p>V/I Input Gain (AI2 Option Board Input)</p> <p>Program ⇒ Frequency ⇒ Speed Reference Setpoints</p> <p>This parameter is used to fine tune the gain of the Optional AI2 input terminal when this terminal is used as the control input while operating in the Speed Control mode or the Torque Control mode.</p> <p>This setting may be used to ensure that the 100% level of the input source (pot, pressure transducer, flow meter, etc.) is also the 100% level setting of the ASD system.</p> <p>This is accomplished by setting the input source to 100% and adjusting this setting to provide an output of 100% from the ASD.</p>	<p>Direct Access Number — F479</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 128</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 255</p>

F489

F493

<p>Bearing Greaser Speed Multiplier</p> <p>Program ⇒ Crane/Hoist</p> <p>This parameter is used to reduce the motor speed once the Bearing Greaser (Alarm) Time (F621) setting has expired.</p> <p>Upon expiration of the Bearing Greaser (Alarm) Time setting, the commanded speed is multiplied by the factor set at this parameter to modify the speed of the motor.</p>	<p>Direct Access Number — F489</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.50</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 1.00</p>
<p>Creep Multiplier 1</p> <p>Program ⇒ Crane/Hoist ⇒ Creep Control</p> <p>This parameter provides a modifier for the output frequency of the ASD that multiplies the commanded frequency by the value set at this parameter.</p> <p>The Creep Multiplier 1 function may be activated via the EOI or a discrete input terminal on the ACE G9-120V-PCB (Creep Speed 1).</p> <p>This parameter setting has priority over the Creep Multiplier 2 (F491) setting.</p>	<p>Direct Access Number — F490</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.10</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 1.00</p>
<p>Creep Multiplier 2</p> <p>Program ⇒ Crane/Hoist ⇒ Creep Control</p> <p>This parameter provides a modifier for the output frequency of the ASD that multiplies the commanded frequency by the value set at this parameter.</p> <p>The Creep Multiplier 2 function may be activated via the EOI or a discrete input terminal on the ACE G9-120V-PCB (Creep Speed 2).</p> <p>The Creep Multiplier 2 function is ignored if the Creep Multiplier 1 (F490) function is active.</p>	<p>Direct Access Number — F491</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.10</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 1.00</p>
<p>Creep Speed Lower Limit</p> <p>Program ⇒ Crane/Hoist ⇒ Creep Control</p> <p>This parameter sets the lower limit while operating in the Creep mode.</p> <p>This setting supersedes the Lower-Limit Frequency setting of F013.</p>	<p>Direct Access Number — F492</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.60</p> <p>Changeable During Run — No</p> <p>Minimum — 0.00</p> <p>Maximum — 30.0</p> <p>Units — Hz</p>
<p>Express Stop</p> <p>Program ⇒ Crane/Hoist</p> <p>This parameter Enables/Disables the ability of the ASD to use an alternate Decel rate when a Stop command is received.</p> <p>The Express-Stop Deceleration Time is set at F511.</p> <p>Settings:</p> <ul style="list-style-type: none"> Disabled Enabled 	<p>Direct Access Number — F493</p> <p>Parameter Type — Selection</p> <p>Factory Default — Disabled</p> <p>Changeable During Run — Yes</p>

F494

F500

<p>Plugging</p> <p>Program ⇒ Crane/Hoist</p> <p>This parameter Enables/Disables the Plugging feature of the ASD. Plugging assigns alternate Acceleration and Deceleration time settings to be used during a direction change only.</p> <p>The Plugging acceleration and deceleration times are set at parameters F514 and F515, respectively.</p> <p>This parameter is further defined by the ACC/DEC Pattern selection of F516.</p> <p>Settings:</p> <ul style="list-style-type: none"> Disabled Enabled 	<p>Direct Access Number — F494</p> <p>Parameter Type — Selection</p> <p>Factory Default — Disabled</p> <p>Changeable During Run — Yes</p>
<p>PM Motor Constant 1 (D Axis Inductance)</p> <p>Program ⇒ Motor ⇒ PM Motor</p> <p>This parameter is used with synchronous motor applications only.</p> <p>Contact ACE World Companies Customer Support Center for information on this parameter.</p>	<p>Direct Access Number — F498</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 100</p> <p>Units — %</p>
<p>PM Motor Constant 2 (Q Axis Inductance)</p> <p>Program ⇒ Motor ⇒ PM Motor</p> <p>This parameter is used with synchronous motor applications only.</p> <p>Contact ACE World Companies Customer Support Center for information on this parameter.</p>	<p>Direct Access Number — F499</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 100</p> <p>Units — %</p>
<p>Acceleration Time 2</p> <p>Program ⇒ Special ⇒ Acc/Dec 1 – 4</p> <p>This parameter specifies the time in seconds for the output of the ASD to go from 0.0 Hz to the Maximum Frequency for the #2 Deceleration profile.</p> <p>The Accel/Decel pattern may be set using F503. This parameter may be further defined by the settings of F506 – F509.</p> <p>Note: <i>An acceleration time shorter than that which the load will allow may cause nuisance tripping and mechanical stress to loads. Automatic Accel/Decel, Stall, and Ridethrough settings may lengthen the actual acceleration times.</i></p>	<p>Direct Access Number — F500</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.1</p> <p>Maximum — 6000.0</p> <p>Units — Seconds</p>

F501**F501****Deceleration Time 2**

Program ⇒ Fundamental ⇒ Acc/Dec 1

This parameter specifies the time in seconds for the output of the ASD to go from the **Maximum Frequency** to 0.0 Hz for the **#2 Deceleration** profile.

The Accel/Decel pattern may be set using **F503**. This parameter may be further defined by the settings of **F506 – F509**.

Note: *A deceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. **Automatic Accel/Decel, Stall, and Ridethrough** settings may lengthen the actual deceleration times.*

Direct Access Number — F501

Parameter Type — **Numerical**

Factory Default — (ASD-Dependent)

Changeable During Run — **Yes**

Minimum — 0.1

Maximum — 6000

Units — Seconds

Acc/Dec Pattern 1

Program ⇒ Special ⇒ Accel/Decel 1 – 4


This parameter enables a user-selected preprogrammed output profile that controls the acceleration and deceleration pattern for the #1 **Accel/Decel** profile.

Settings:


- Linear
- S-Pattern 1
- S-Pattern 2

The figures below provide a profile of the available accel/decel patterns.


Linear acceleration and deceleration is the default pattern and is used on most applications.



S-Pattern 1 is used for applications that require quick acceleration and deceleration. This setting is also popular for applications that require shock absorption at the start of acceleration or deceleration.



S-Pattern 2 decreases the rate of change above the base frequency for acceleration and deceleration.



F503

F503

Acc/Dec Pattern 2

Program ⇒ Special ⇒ Accel/Decel 1 – 4

This parameter enables a user-selected preprogrammed output profile that controls the acceleration and deceleration pattern for the #2 **Accel/Decel** profile.

See [F502](#) for additional information on this parameter.

Settings:

- Linear
- S-Pattern 1
- S-Pattern 2

Direct Access Number — F503

Parameter Type — **Selection List**

Factory Default — **Linear**

Changeable During Run — **Yes**

F504

F505

Acc/Dec Pattern 1 – 4

Program ⇒ Special ⇒ Acc/Dec Special

Four acceleration times and four deceleration times may be set up and run individually. One of four accel/decel times may be selected by 1) using this parameter selection, 2) by discrete input terminal, or 3) switched via user-set threshold frequencies.

This parameter is used to select one of the four configured accel/decel profiles to be used.

Settings:

- Acc/Dec 1 (F009/F010)
- Acc/Dec 2 (F500/F501)
- Acc/Dec 3 (F510/F511)
- Acc/Dec 4 (F514/F515)

Each Accel/Decel selection is comprised of an **Acceleration Time**, **Deceleration Time**, and a **Pattern** selection. Selection 1, 2, and 3 have a **Switching Frequency** setting. The **Switching Frequency** is used as a threshold frequency that, once reached, the ASD switches to the next **Acc/Dec** selection. **Switching Frequency** settings are used during acceleration and deceleration. A switching frequency setting is not required for **Acc/Dec 4**.

Acc/Dec 1 is set up using parameters **F009** (Acc Time), **F010** (Dec Time), **F502** (Pattern), and **F505** (Switching Frequency).

Acc/Dec 2 is set up using parameters **F500** (Acc Time), **F501** (Dec Time), **F503** (Pattern), and **F513** (Switching Frequency).

Acc/Dec 3 is set up using parameters **F510** (Acc Time), **F511** (Dec Time), **F512** (Pattern), and **F517** (Switching Frequency).

Acc/Dec 4 is set up using parameters **F514** (Acc Time), and **F515** (Dec Time), **F516** (Pattern).

This parameter (**F504**) is used to manually select **Acc/Dec 1 – 4**.

To switch using the **ACE G9-120V-PCB**, assign the functions **Acc/Dec Switching 1** and **Acc/Dec Switching 2** to two discrete input terminals. Activation combinations of the two terminals result in the **Acc/Dec 1 – 4** selections as shown in **Table 6**.

Figure 31 shows the setup requirements and the resulting output frequency response when using **Switching Frequency** settings to control the **Acc/Dec** response of the ASD output.

While operating using **S-Pattern 1** the system performance may be further defined by the adjustment of parameters **F506 – F509**. These settings provide for upper and lower **Acc/Dec** limit adjustments. These settings are used to extend or shorten the upper or lower **Acc/Dec** curve.

Note: If operating from the Local mode, press Esc from the Frequency Command screen to access this parameter (ACC/DEC Group).

Accel/Decel Switching Frequency 1

Program ⇒ Special ⇒ Accel/Decel Special

This parameter sets the frequency at which the acceleration control is switched from the **Accel 1** profile to the **Accel 2** profile during a multiple-acceleration profile configuration.

Direct Access Number — **F504**

Parameter Type — **Selection List**

Factory Default — **1**


Changeable During Run — **Yes**

Table 6.

Using combinations of discrete terminal activations Accel/Decel profiles 1–4 may be selected.

Acc/Dec Switching Truth		
A/D SW 1	A/D SW 2	Acc/Dec # Out
0	0	1
0	1	2
1	0	3
1	1	4
1 = Discrete terminal activation.		

Figure 31. Using Acc/Dec Switching.



- 1 — Accel Time 1 (F009 Setting)
- 2 — Accel Time 2 (F500 Setting)
- 3 — Accel Time 3 (F510 Setting)
- 4 — Accel Time 4 (F514 Setting)
- 5 — Decel Time 4 (F515 Setting)
- 6 — Decel Time 3 (F511 Setting)
- 7 — Decel Time 2 (F501 Setting)
- 8 — Decel Time 1 (F510 Setting)

Direct Access Number — **F505**

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — **0.00**

Maximum — **Max. Freq. (F011)**

Units — **Hz**

F506

F510

<p>S-Pattern Acceleration Lower-Limit Adjustment</p> <p>Program ⇒ Special ⇒ Accel/Decel Special</p> <p>During an S-Pattern 1 or 2 sequence, this parameter setting modifies the acceleration rate for the lower part of the acceleration curve by the percentage set here.</p> <p>This function is commonly used with transportation and lifting applications.</p> <p>See parameter F502 on pg. 170 for additional information on this setting.</p>	<p>Direct Access Number — F506</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 10</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 50</p> <p>Units — %</p>
<p>S-Pattern Acceleration Upper-Limit Adjustment</p> <p>Program ⇒ Special ⇒ Accel/Decel Special</p> <p>During an S-Pattern 1 or 2 sequence, this parameter setting modifies the acceleration rate for the upper part of the acceleration curve by the percentage set here.</p> <p>This function is commonly used with transportation and lifting applications.</p> <p>See parameter F502 on pg. 170 for additional information on this setting.</p>	<p>Direct Access Number — F507</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 10</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 50</p> <p>Units — %</p>
<p>S-Pattern Deceleration Lower-Limit Adjustment</p> <p>Program ⇒ Special ⇒ Accel/Decel Special</p> <p>During an S-Pattern 1 or 2 sequence, this parameter setting modifies the deceleration rate for the lower part of the deceleration curve by the percentage set here.</p> <p>This function is commonly used with transportation and lifting applications.</p> <p>See parameter F502 on pg. 170 for additional information on this setting.</p>	<p>Direct Access Number — F508</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 10</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 50</p> <p>Units — %</p>
<p>S-Pattern Deceleration Upper-Limit Adjustment</p> <p>Program ⇒ Special ⇒ Accel/Decel Special</p> <p>During an S-Pattern 1 or 2 sequence, this parameter setting modifies the deceleration rate for the upper part of the deceleration curve by the percentage set here.</p> <p>This function is commonly used with transportation and lifting applications.</p> <p>See parameter F502 on pg. 170 for additional information on this setting.</p>	<p>Direct Access Number — F509</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 10</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 50</p> <p>Units — %</p>
<p>Acceleration Time 3</p> <p>Program ⇒ Special ⇒ Accel/Decel 1 – 4</p> <p>This parameter specifies the time in seconds for the output of the ASD to go from 0.0 Hz to the Maximum Frequency for the #3 Acceleration profile. The Accel/Decel pattern may be set using F502. The minimum Accel/Decel time may be set using F508.</p> <p><i>Note: An acceleration time shorter than that which the load will allow may cause nuisance tripping and mechanical stress to loads. Automatic Accel/Decel, Stall, and Ridethrough settings may lengthen the actual acceleration times.</i></p>	<p>Direct Access Number — F510</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.1</p> <p>Maximum — 6000</p> <p>Units — Seconds</p>

F511

F514

<p>Express Stop Decel Time</p> <p>Program ⇒ Special ⇒ Accel/Decel 1 – 4</p> <p>This parameter specifies the time in seconds for the output of the ASD to go from the Maximum Frequency to 0.0 Hz during an Express Stop. When enabled at F493, this setting is used as an alternate deceleration time.</p> <p>The Accel/Decel Pattern may be set using F512.</p> <p>This parameter may be further defined by the settings of F506 – F509.</p> <p><i>Note: A deceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. Automatic Accel/Decel, Stall, and Ridethrough settings may lengthen the actual deceleration times.</i></p>	<p>Direct Access Number — F511</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1.5</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.1</p> <p>Maximum — 6000</p> <p>Units — Seconds</p>
<p>Express Stop Acceleration/Deceleration Pattern</p> <p>Program ⇒ Special ⇒ Accel/Decel 1 – 4</p> <p>This parameter enables a user-selected preprogrammed output profile that controls the acceleration and deceleration pattern during an Express Stop.</p> <p>See F502 for additional information on this parameter.</p> <p>Settings:</p> <ul style="list-style-type: none"> Linear S-Pattern 1 S-Pattern 2 	<p>Direct Access Number — F512</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Linear</p> <p>Changeable During Run — Yes</p>
<p>Acceleration/Deceleration Switching Frequency 2</p> <p>Program ⇒ Special ⇒ Accel/Decel Special</p> <p>This parameter sets the frequency at which the acceleration control is switched from the Accel #2 profile to the Accel #3 profile during a multiple-acceleration profile configuration.</p>	<p>Direct Access Number — F513</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>Plugging Acceleration Time</p> <p>Program ⇒ Special ⇒ Accel/Decel 1 – 4</p> <p>This parameter specifies the time in seconds for the output of the ASD to go from 0.0 Hz to the Maximum Frequency during Plugging. When enabled at F494, this setting is used as an alternate acceleration time.</p> <p>The Plugging Acc/Dec Pattern may be selected at F516.</p> <p>This parameter may be further defined by the settings of F506 – F509.</p> <p>See F494 for additional information on the Plugging function.</p> <p><i>Note: An acceleration time shorter than that which the load will allow may cause nuisance tripping and mechanical stress to loads. Automatic Accel/Decel, Stall, and Ridethrough settings may lengthen the actual acceleration times.</i></p>	<p>Direct Access Number — F514</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1.5</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.1</p> <p>Maximum — 6000</p> <p>Units — Seconds</p>

F515

F600

<p>Plugging Deceleration Time</p> <p>Program ⇒ Special ⇒ Accel/Decel 1 – 4</p> <p>This parameter specifies the time in seconds for the output of the ASD to go from the Maximum Frequency to 0.0 Hz during Plugging. When enabled at F494, this setting is used as an alternate deceleration time.</p> <p>The Plugging Acc/Dec Pattern may be selected at F516.</p> <p>This parameter may be further defined by the settings of F506 – F509.</p> <p>See F494 for additional information on the Plugging function.</p> <p><i>Note:</i> A deceleration time shorter than the load will allow may cause nuisance tripping and mechanical stress to loads. Automatic Accel/Decel, Stall, and Ridethrough settings may lengthen the actual deceleration times.</p>	<p>Direct Access Number — F515</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1.5</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.1</p> <p>Maximum — 6000</p> <p>Units — Seconds</p>
<p>Plugging Acceleration/Deceleration Pattern</p> <p>Program ⇒ Special ⇒ Accel/Decel 1 – 4</p> <p>This parameter enables a user-selected preprogrammed output profile that controls the acceleration and deceleration pattern while Plugging.</p> <p>See F502 for additional information on this parameter.</p> <p>Settings:</p> <ul style="list-style-type: none"> Linear S-Pattern 1 S-Pattern 2 	<p>Direct Access Number — F516</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Linear</p> <p>Changeable During Run — Yes</p>
<p>Acceleration/Deceleration Switching Frequency 3</p> <p>Program ⇒ Special ⇒ Accel/Decel Special</p> <p>This parameter sets the frequency at which the acceleration control is switched from the Accel #3 profile to the Accel #4 profile during a multiple-acceleration profile configuration.</p>	<p>Direct Access Number — F517</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>Motor Overload Protection Level 1</p> <p>Program ⇒ Fundamental ⇒ Motor Set 1</p> <p>This parameter specifies the motor overload current level for motor set 1. This value is entered as either a percentage of the full-load rating of the ASD or as a percentage of the FLA of the motor.</p> <p>The unit of measurement for this parameter may be set to A/V (Amps) or it may be set as a percentage of the ASD rating. The nameplate FLA of the motor may be entered directly when Amps is selected as the unit of measurement (see F701 to change the display unit).</p> <p>Motor Overload Protection Level 1 settings will be displayed in Amps if the EOI display units are set to A/V rather than %.</p>	<p>Direct Access Number — F600</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 100</p> <p>Changeable During Run — Yes</p> <p>Minimum — 10</p> <p>Maximum — 100.0</p> <p>Units — %</p>

F601

F604

Stall Prevention Level

Program ⇒ Protection ⇒ Stall

This parameter specifies the output current level at which the output frequency is reduced in an attempt to prevent a trip. The over-current level is entered as a percentage of the maximum rating of the ASD.

Note: The **Motor Overload Protection** parameter must be enabled at **F017** to use this feature.

Direct Access Number — F601Parameter Type — **Numerical**Factory Default — **150**Changeable During Run — **Yes**

Minimum — 10

Maximum — 165

Units — % (or **A**; see **F701** setting)**Retain Trip Record at Power Down**

Program ⇒ Protection ⇒ Trip

This parameter **Enables/Disables** the **Trip Record Retention** setting. When enabled, this feature logs the trip event and retains the trip information when the system powers down. The trip information may be viewed from the (Program ⇒ Utilities ⇒) **Trip History** screen or the **Monitor** screen.

When disabled, the trip information will be cleared when the system powers down.

Settings:

Disabled

Enabled

Direct Access Number — F602Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **Yes****Emergency Off Mode**

Program ⇒ Protection ⇒ Emergency Off

This parameter determines the method used to stop the motor in the event that an **Emergency Off** command is received and the system is configured to use this feature.

This setting may also be associated with the **BRAKE** terminals to allow the **BRAKE** relay to change states when an **EOFF** condition occurs by setting the **BRAKE** output to **Emergency Off Active** (see **F132**).

Note: A supplemental emergency stopping system should be used with the ASD. Emergency stopping should not be a task of the ASD alone.

Settings:

Coast Stop

Deceleration Stop

DC Injection Braking Stop

Deceleration Stop (Decel 4 setting; **F515**)**Direct Access Number — F603**Parameter Type — **Selection List**Factory Default — **Coast Stop**Changeable During Run — **No****Emergency Off DC Braking Control Time**

Program ⇒ Protection ⇒ Emergency Off

When **DC Injection** is selected at **F603** this parameter determines the time that the **DC Injection** braking is applied to the motor.

Direct Access Number — F604Parameter Type — **Numerical**Factory Default — **1.0**Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 20.0

Units — Seconds

F605

F608

ASD Output Phase Failure Detection

Program ⇒ Protection ⇒ Phase Loss

This parameter **Enables/Disables** the monitoring of each phase of the 3-phase output signal (U, V, or W) of the ASD. If either line is missing, inactive, or not of the specified level for one second or more, the ASD incurs a trip.

Note: Autotune checks for phase failures regardless of this setting.

Settings:

- Disabled (No Detection)
- Enabled (Run at Startup and Retry)
- Enabled (Every Run Command and Retry)
- Enabled (During Run)
- Enabled (At Startup and During Run)
- Enabled (Detects an ALL-PHASE Failure ONLY - Will Not Trip, Restarts at Reconnect)

Direct Access Number — F605Parameter Type — **Selection List**Factory Default — **Disabled**Changeable During Run — **No****Overload Reduction Start Frequency**

Program ⇒ Protection ⇒ Overload

This parameter is primarily used with V/f motors. It is used to reduce the starting frequency at which the **Overload Reduction** function begins and is useful during extremely low-speed motor operation.

During very low-speed operation the cooling efficiency of the motor decreases. Lowering the start frequency of the **Overload Reduction** function aides in minimizing the generated heat and precluding an **Overload** trip.

This function is useful in loads such as fans, pumps, and blowers that have the square reduction torque characteristic.

Set parameter [F607](#) to the desired **Overload Time Limit**.

Direct Access Number — F606Parameter Type — **Numerical**Factory Default — **6.00**Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 30.00

Units — Hz

Motor 150% Overload Time Limit

Program ⇒ Protection ⇒ Overload

This parameter establishes a time that the motor may operate at 150% of its rated current before tripping. This setting applies the time/150% reference to the individual settings of each motor (e.g., this setting references 150% of the [F600](#) setting for the #1 motor).

The unit will trip sooner than the time entered here if the overload is greater than 150%.

Direct Access Number — F607Parameter Type — **Numerical**Factory Default — **300**Changeable During Run — **Yes**

Minimum — 10

Maximum — 2400

Units — Seconds

ASD Input Phase Failure Detection

Program ⇒ Protection ⇒ Phase Loss

This parameter enables the 3-phase input power phase loss detection feature. A loss of either input phase (R, S, or T) results in a trip.

Settings:

- Disabled
- Enabled

Direct Access Number — F608Parameter Type — **Selection List**Factory Default — **Enabled**Changeable During Run — **No**

F609

F613

<p>Low-Current Detection Hysteresis Width</p> <p>Program ⇒ Protection ⇒ Low Current</p> <p>During a momentary low-current condition, this parameter provides a current threshold level to which the low-current condition must return within the time setting of F612 or a Low-Current Trip will be incurred.</p>	<p>Direct Access Number — F609</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 10</p> <p>Changeable During Run — Yes</p> <p>Minimum — 1</p> <p>Maximum — 20</p> <p>Units — %</p>
<p>Low-Current Trip</p> <p>Program ⇒ Protection ⇒ Low Current</p> <p>This parameter Enables/Disables the low-current trip feature.</p> <p>When enabled, the ASD will trip on a low-current fault if the output current of the ASD falls below the level defined at F611 and remains there for the time set at F612.</p> <p>Settings:</p> <ul style="list-style-type: none"> Disabled Enabled 	<p>Direct Access Number — F610</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Disabled</p> <p>Changeable During Run — No</p>
<p>Low-Current Detection Current</p> <p>Program ⇒ Protection ⇒ Low Current</p> <p>With the Low-Current Trip (F610) parameter enabled, this function sets the low-current trip threshold.</p> <p>The threshold value is entered as a percentage of the maximum rating of the ASD.</p>	<p>Direct Access Number — F611</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 100</p> <p>Units — % (or A; see F701 setting)</p>
<p>Low-Current Detection Time</p> <p>Program ⇒ Protection ⇒ Low Current</p> <p>With the Low-Current Trip (F610) parameter enabled, this function sets the time that the low-current condition must exist to cause a trip.</p>	<p>Direct Access Number — F612</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 255</p> <p>Units — Seconds</p>
<p>Short Circuit Detection At Start</p> <p>Program ⇒ Protection ⇒ Special Protection Parameters</p> <p>This parameter determines when the system will perform an Output Short Circuit test.</p> <p><i>Note: Selection 3 is recommended for high-speed motor applications. Because of the low impedance of high-speed motors the standard-pulse setting may result in a motor malfunction.</i></p> <p>Settings:</p> <ul style="list-style-type: none"> Every Start (Standard Pulse) Power On or Reset (Standard Pulse) Every Start (Short Pulse) Power On or Reset (Short Pulse) 	<p>Direct Access Number — F613</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Every Start (standard pulse)</p> <p>Changeable During Run — No</p>

F615

F619

<p>Over-Torque Trip</p> <p>Program ⇒ Protection ⇒ Over-Torque Parameters</p> <p>This parameter Enables/Disables the Over-Torque Tripping function.</p> <p>When enabled, the ASD trips if an output torque value greater than the setting of F616 or F617 exists for a time longer than the setting of F618.</p> <p>When disabled, the ASD does not trip due to over-torque conditions.</p> <p><i>Note:</i> A discrete output terminal may be activated when an over-torque alarm occurs if so configured (see F130).</p> <p>Settings:</p> <ul style="list-style-type: none"> Disabled Enabled 	<p>Direct Access Number — F615</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Enabled</p> <p>Changeable During Run — No</p>
<p>Over-Torque Detection Level During Power Running</p> <p>Program ⇒ Protection ⇒ Over-Torque Parameters</p> <p>This parameter sets the torque threshold level that is used as a setpoint for over-torque tripping during positive torque. This setting is a percentage of the maximum rated torque of the ASD.</p> <p>This function is enabled at F615.</p>	<p>Direct Access Number — F616</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 150.00</p> <p>Changeable During Run — No</p> <p>Minimum — 0.00</p> <p>Maximum — 250.00</p> <p>Units — %</p>
<p>Over-Torque Detection Level During Dynamic Braking</p> <p>Program ⇒ Protection ⇒ Over-Torque Parameters</p> <p>This parameter sets the torque threshold level that is used as a setpoint for over-torque tripping during negative torque (regen). This setting is a percentage of the maximum rated torque of the ASD.</p> <p>This function is enabled at F615.</p>	<p>Direct Access Number — F617</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 180.00</p> <p>Changeable During Run — No</p> <p>Minimum — 0.00</p> <p>Maximum — 250.00</p> <p>Units — %</p>
<p>Over-Torque Detection Time</p> <p>Program ⇒ Protection ⇒ Over-Torque Parameters</p> <p>This parameter sets the amount of time that the over-torque condition may exceed the tripping threshold level set at F616 and F617 before a trip occurs.</p> <p>This function is enabled at F615.</p>	<p>Direct Access Number — F618</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 2.50</p> <p>Changeable During Run — No</p> <p>Minimum — 0.00</p> <p>Maximum — 10.0</p> <p>Units — Seconds</p>
<p>Over-Torque Detection Hysteresis</p> <p>Program ⇒ Protection ⇒ Over-Torque Parameters</p> <p>During a momentary over-torque condition, this parameter provides a torque threshold level to which the over-torque condition must return within the time setting of F618 or an Over-Torque Trip will be incurred.</p>	<p>Direct Access Number — F619</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 10.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 100.00</p> <p>Units — %</p>

F620

F624

<p>Cooling Fan Control</p> <p>Program ⇒ Protection ⇒ Special Protection Parameters</p> <p>This parameter sets the cooling fan run-time command.</p> <p>Settings:</p> <ul style="list-style-type: none"> Automatic Always On 	<p>Direct Access Number — F620</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Always On</p> <p>Changeable During Run — Yes</p>
<p>Bearing Greaser (Alarm) Time</p> <p>Program ⇒ Protection ⇒ Special Protection Parameters</p> <p>This parameter Enables/Disables the Maintenance Timer Alarm. The timer sets a run-time value in hours that, once exceeded, initiates the Maintenance Timer Alarm.</p> <p>This setting, in conjunction with the setting of F489, may also affect the commanded speed of the motor by providing a value for the Bearing Greaser Speed Multiplier, if so configured.</p> <p>A discrete output contactor may be set to Total-Operation-Hours Alarm to control ancillary equipment (e.g., engage a brake) upon activation of the discrete output contactor.</p> <p>This feature is disabled by setting this parameter to Zero.</p> <p>See Table 10 on pg. 242 for additional information on output terminal selections.</p>	<p>Direct Access Number — F621</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 65535</p> <p>Units — Hour</p>
<p>Abnormal Speed Detection Time</p> <p>Program ⇒ Protection ⇒ Abnormal Speed</p> <p>This parameter sets the time that an over-speed condition must exist to cause a trip.</p> <p>This parameter functions in conjunction with the settings of F623 and F624.</p>	<p>Direct Access Number — F622</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.01</p> <p>Maximum — 100.00</p> <p>Units — Seconds</p>
<p>Over-Speed Detection Frequency Upper Band</p> <p>Program ⇒ Protection ⇒ Abnormal Speed</p> <p>This parameter sets the upper level of the Base Frequency range that, once exceeded, will cause an Over-Speed Detected alarm.</p> <p>This parameter functions in conjunction with the settings of F622 and F624.</p>	<p>Direct Access Number — F623</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 5.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0 (Disabled)</p> <p>Maximum — 30.00</p> <p>Units — Hz</p>
<p>Over-Speed Detection Frequency Lower Band</p> <p>Program ⇒ Protection ⇒ Abnormal Speed</p> <p>This parameter sets the lower level of the Base Frequency range that, once the output speed falls below this setting, will cause a Speed Drop Detected alarm.</p> <p>This parameter functions in conjunction with the settings of F622 and F623.</p>	<p>Direct Access Number — F624</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 5.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00 (Disabled)</p> <p>Maximum — 30.00</p> <p>Units — Hz</p>

F626

F629

<p>Over-Voltage Limit Operation Level</p> <p>Program ⇒ Protection ⇒ Stall</p> <p>This parameter sets the upper DC bus voltage threshold that, once exceeded, will cause an Over-Voltage Stall. An Over-Voltage Stall increases the output frequency of the ASD during deceleration for a specified time in an attempt to prevent an Over-Voltage Trip.</p> <p>If the over-voltage condition persists for over 4 mS, an Over-Voltage Trip will be incurred.</p> <p>This parameter is enabled at F305.</p> <p><i>Note: This parameter setting may increase deceleration times.</i></p>	<p>Direct Access Number — F626</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 100</p> <p>Maximum — 150</p> <p>Units — %</p>
<p>Under-Voltage Trip</p> <p>Program ⇒ Protection ⇒ Under-Voltage/Ridethrough</p> <p>This parameter Enables/Disables the Under-Voltage Trip function.</p> <p>With this parameter Enabled, the ASD will trip if the under-voltage condition persists for a time greater than the F628 setting.</p> <p>A user-selected contact may be actuated if so configured.</p> <p>If Disabled the ASD will stop and not trip; the BRAKE contacts are not affected.</p> <p>Settings:</p> <ul style="list-style-type: none"> Disabled Enabled 	<p>Direct Access Number — F627</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Enabled</p> <p>Changeable During Run — No</p>
<p>Under-Voltage (Trip Alarm) Detection Time</p> <p>Program ⇒ Protection ⇒ Under-Voltage/Ridethrough</p> <p>This parameter sets the time that the under-voltage condition must exist to cause an Under-Voltage Trip.</p> <p>This parameter is enabled at F627.</p>	<p>Direct Access Number — F628</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.03</p> <p>Changeable During Run — No</p> <p>Minimum — 0.01</p> <p>Maximum — 10.00</p> <p>Units — Seconds</p>
<p>Regenerative Power Ridethrough Control Level</p> <p>Program ⇒ Protection ⇒ Under-Voltage/Ridethrough</p> <p>This parameter is activated during regeneration. It is used to set the low end of the DC bus voltage threshold that, once the bus voltage drops below this setting, activates the setting of F302 (Ridethrough Mode).</p> <p>Activation may be the result of a momentary power loss or an excessive load on the bus voltage.</p> <p>During a Ridethrough, regenerative energy is used to maintain the control circuitry settings for the duration of the Ridethrough; it is not used to drive the motor.</p> <p>The motor(s) of the system are stopped and then restarted automatically or may continue seamlessly if so configured.</p> <p>See F302 for additional information on this parameter.</p> <p><i>Note: This parameter setting may increase deceleration times.</i></p>	<p>Direct Access Number — F629</p> <p>Parameter Type — Numerical</p> <p>Factory Default — (ASD-Dependent)</p> <p>Changeable During Run — No</p> <p>Minimum — 55</p> <p>Maximum — 100</p> <p>Units — %</p>

F630

F633

Brake Answer Wait Time

Program ⇒ Protection ⇒ Special Protection Parameters

This parameter is used in conjunction with the discrete input terminal setting **Brake Answerback Input** (see [Table 7 on pg. 236](#) for additional information on this feature).

After activating the discrete input terminal **Braking Request**, the setting of this parameter starts a count-down timer in which 1) a **Brake Answerback Input** response must be received or 2) the brake must release before the timer expires.

Should this timer setting expire before the **Brake Answerback Input** is returned or the brake releases, a **Brake Sequence Response Error** (E-11) is incurred. Otherwise, the brake releases and normal motor operations resume.

ASD Overload

Program ⇒ Protection ⇒ Overload

This parameter is used to protect the ASD from an over-current condition. The standard overload rating of the ACE-tronics G9 ASD is 150% operation for 60 seconds.

This setting allows for the overload protection to be switched from the standard overload detection means (Thermal Detection and Overload) to thermal detection only.

Settings:

- Thermal Detection + Overload
- Thermal Detection Only

The **Thermal Detection Only** selection is used when multiple devices are installed horizontally as described on [pg. 15](#).

V/I Analog Input Breakage Detection Level

Program ⇒ Terminal ⇒ Input Special Functions

This parameter is enabled by providing a non-zero value here. This function monitors the **V/I** input signal and if the **V/I** input signal falls below the level specified here and remains there for a period of 0.3 seconds or more a trip will be incurred (E-18).

This value is entered as 0% to 100% of the **V/I** input signal range.

Direct Access Number — F630

Parameter Type — **Numerical**

Factory Default — **0.0 (Disabled)**

Changeable During Run — **Yes**

Minimum — 0.0 (Disabled)

Maximum — 10.0

Units — Seconds

Direct Access Number — F631

Parameter Type — **Selection List**

Factory Default — **Thermal Detection + Overload**

Changeable During Run — **No**

Direct Access Number — F633

Parameter Type — **Numerical**

Factory Default — **0 (Disabled)**

Changeable During Run — **No**

Minimum — 1

Maximum — 100

Units — %

F634

F637

Annual Average Ambient Temperature

Program ⇒ Special ⇒ Special Parameters

This parameter is used in conjunction with a discrete output terminal setting to notify the operator of the remaining useful life of critical components of the ASD system.

With a discrete output terminal set to **Part Replacement Alarm** (see [Table 10 on pg. 242](#)) and the calculation derived from the parameter setting, maintenance scheduling may be enhanced.

Settings:

Under 10° C (50° F) — 60,000 Hours

Under 20° C (68° F) — 60,000 Hours

Under 30° C (86° F) — 60,000 Hours

Under 40° C (104° F) — 60,000 Hours

Under 50° C (122° F) — 40,000 Hours

Under 60° C (140° F) — 2,666 Hours

Direct Access Number — F634

Parameter Type — Selection List

Factory Default — Under 30°

Changeable During Run — No

Rush Current Suppression Replay Activation Time

Program ⇒ Special ⇒ Special Parameters ⇒ Rush Relay Current Activation Time

At system startup, this parameter sets a time-delay for the start of the **Rush Relay** activation in an attempt to allow the DC bus voltage to reach the normal operating level before outputting a signal to the motor.

Direct Access Number — F635

Parameter Type — Numerical

Factory Default — 0.0

Changeable During Run — No

Minimum — 0.0

Maximum — 2.5

Units — Seconds

PTC1 Thermal Selection

Program ⇒ Special ⇒ Special Parameters ⇒ PTC1 Thermal Selection

This parameter **Enables/Disables** the optional external thermal detection circuit of the **Expansion IO Card Option 1**. A thermistor is connected from **TH1+** to **TH1-** of **TB3** on the **Expansion IO Card Option 1**.

Should the thermistor resistance reading fall below 50Ω because of an over-temperature condition or exceed 3000Ω because of an open circuit an **External Thermal Fault** (OH2) will be incurred.

Note: While this parameter is **Enabled**, the system cannot be restarted until the thermistor value recovers to the level of 1.8 kΩ from an over-temperature condition. An **Auto-Restart** will not be initiated subsequent to an **External Thermal Trip** (OH2). A manual restart will be required in the event of an **OH2** trip.

Settings:

Disabled

Detect Disconnect

Direct Access Number — F637

Parameter Type — Selection List

Factory Default — Disabled

Changeable During Run — No

F638

F641

PTC2 Thermal Selection

Program ⇒ Special ⇒ Special Parameters⇒ PTC2 Thermal Selection

This parameter **Enables/Disables** the optional external thermal detection circuit of the **Expansion IO Card Option 2**. A thermistor is connected from **TH1+** to **TH1-** of **TB4** on the **Expansion IO Card Option 2**.

Should the thermistor resistance reading fall below 50Ω because of an over-temperature condition or exceed 3000Ω because of an open circuit an **External Thermal Fault** (OH2) will be incurred.

***Note:** While this parameter is **Enabled**, the system cannot be restarted until the thermistor value recovers to the level of 1.8kΩ from an over-temperature condition. An **Auto-Restart** will not be initiated subsequent to an **External Thermal Trip** (OH2). A manual restart will be required in the event of an **OH2** trip.*

Settings:

Disabled
Detect Disconnect

Direct Access Number — F638

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **No**

Braking Resistance Overload Time (10x rated torque)

Program ⇒ Protection ⇒ Dynamic Braking

This parameter sets the time that the braking resistor is allowed to sustain and overload condition before a trip is incurred.

This feature is useful for applications that have a fluctuating load or for loads that require a long deceleration time.

Direct Access Number — F639

Parameter Type — **Numerical**

Factory Default — **5.0**

Changeable During Run — **No**

Minimum — 0.1

Maximum — 600.0

Units — Seconds

Step-Out Detection Current Level

Program ⇒ Motor ⇒ PM Motor

This parameter is used with synchronous motor applications only.

Contact ACE World Companies Customer Support Center for information on this parameter.

Direct Access Number — F640

Parameter Type — **Numerical**

Factory Default — **100**

Changeable During Run — **Yes**

Minimum — 10

Maximum — 150

Units — % (or A; see [F701](#) setting)

Step-Out Detection Current Time

Program ⇒ Motor ⇒ PM Motor

This parameter is used with synchronous motor applications only.

Contact ACE World Companies Customer Support Center for information on this parameter.

Direct Access Number — F641

Parameter Type — **Numerical**

Factory Default — **00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 25.0

Units — Seconds

F656

F659

Emergency-Lift

Program ⇒ Emergency Lift

In the event of an encoder malfunction, this parameter may be used to **Enable/Disable** the **Emergency Lift** mode of operation.

In the **Emergency Lift** mode of operation, the hoist-control function switches from closed-loop operation to open-loop operation and does not require or use an encoder feedback signal.

This parameter may be enabled via the **EOI** (set this parameter to Enabled) or via a discrete input terminal (see [Table 7 on pg. 236](#)).

Settings:

- Disabled
- Enabled

Direct Access Number — F656

Parameter Type — **Selection**

Factory Default — **Disabled**

Changeable During Run — **Yes**

Emergency-Lift Maximum Speed

Program ⇒ Emergency Lift

While operating in the **Emergency Lift** mode, this parameter setting determines the maximum commanded speed allowed.

Direct Access Number — F657

Parameter Type — **Numerical**

Factory Default — **30.00**

Changeable During Run — **No**

Minimum — 0.00

Maximum — 30.00

Units — Hz

Emergency-Lift Lower Speed Limit

Program ⇒ Emergency Lift

When operating in the **Emergency Lift** mode, this parameter sets the lowest frequency that the ASD will accept as a frequency command or frequency setpoint.

Direct Access Number — F658

Parameter Type — **Numerical**

Factory Default — **6.00**

Changeable During Run — **No**

Minimum — 0.00

Maximum — 30.0

Units — Hz

Emergency-Lift Torque Compare Time

Program ⇒ Emergency Lift

When operating in the **Emergency Lift** mode, the output-torque level requirement for the brake-release function must be met before the brake can release.

This parameter is used to set a time in which the required brake-release torque criteria must be achieved. If this time setting is too short the brake will not release.

Direct Access Number — F659

Parameter Type — **Numerical**

Factory Default — **1.0**

Changeable During Run — **Yes**

Minimum — 0.0

Maximum — 1000.0

Units — Seconds

F660**F670****Adding Input Selection**

Program ⇒ Feedback ⇒ Override Control

This parameter **Enables/Disables** the feature that allows for the external adjustment of the **Output Frequency**.

Selecting either of the input methods listed enables this feature. The selected input is used as a modifier of the programmed **Output Frequency**.

Settings:

- Disabled
- V/I
- RR
- RX
- Panel Keypad
- RS485 2-Wire
- RS485 4-Wire
- Communication Option Board
- RX2 Option (A11)
- Option V/I
- UP/DOWN Frequency (ACE G9-120V-PCB)
- Pulse Input (Option)
- Pulse Input (Motor CPU)
- Binary/BCD Input (Option)

Direct Access Number — F660

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **Yes**

Multiplying Input Selection

Program ⇒ Feedback ⇒ Override Control

This parameter **Enables/Disables** the feature that allows for the external adjustment of the commanded frequency.

Selecting either of the input methods listed enables this feature. The selected input is used as a multiplier of the commanded frequency.

If **Setting (F729)** is selected, the % value entered at parameter **F729** is used as the multiplier of the commanded frequency.

Settings:

- Disabled
- V/I
- RR
- RX
- Setting (F729)
- RX2 Option (A11)

Direct Access Number — F661

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **No**

AM Output Terminal Function

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to set the output function of the **AM** analog output terminal. The **AM** analog output terminal produces an output current that is proportional to the magnitude of the function assigned to this terminal. The available assignments for this output terminal are listed in [Table 8 on pg. 240](#).

AM Terminal Setup Parameters

- F670** — Set AM Function
- F671** — Calibrate AM Terminal
- F685** — Output Response Polarity Selection
- F686** — Bias Adjustment

Direct Access Number — F670

Parameter Type — **Selection List**

Factory Default — **Output Current**

Changeable During Run — **Yes**

F671**F673****AM Output Terminal Adjustment**

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to calibrate the **AM** analog output.

To calibrate the **AM** analog output connect a voltmeter to the **AM** and **CC** terminals.

With the ASD is running at a known value (e.g., output frequency), adjust this parameter until the associated function of parameter **F670** produces the desired DC level output at the **AM** output terminal.

See **F670** for additional information on this setting.

Direct Access Number — **F671**

Parameter Type — **Numerical**

Factory Default — **512**

Changeable During Run — **Yes**

Minimum — 1

Maximum — 1280

MON1 Terminal Meter Selection

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to set the output function of the **MON1** analog output terminal. The available assignments for this output terminal are listed in [Table 8 on pg. 240](#).

The **MON1** analog output terminal produces an output voltage or current that is proportional to the magnitude of the function assigned to this terminal.

Note: *The **Expansion IO Card Option 2** option board (P/N ETB004Z) is required to use this terminal.*

See the ***Expansion IO Card Option 2 Instruction Manual*** (P/N 58686) for additional information on the function of this terminal.

Direct Access Number — **F672**

Parameter Type — **Selection List**

Factory Default — **Output Voltage**

Changeable During Run — **Yes**

MON1 Terminal Setup Parameters

F672 — MON1 Output Function

F673 — MON1 Terminal Meter Adjustment

F688 — MON1 Voltage/Current Output Switching

F689 — MON1 Output Gradient Characteristic

F690 — MON1 Bias Adjustment Set Zero Level

MON1 Terminal Meter Adjustment

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to set the gain of the **MON1** output terminal and is used in conjunction with the settings of parameter **F672**.

See parameter **F672** for additional information on this setting.

Direct Access Number — **F673**

Parameter Type — **Numerical**

Factory Default — **512**

Changeable During Run — **Yes**

Minimum — 1

Maximum — 1280

MON2 Terminal Meter Selection

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to set the output function of the **MON2** analog output terminal. The available assignments for this output terminal are listed in [Table 8 on pg. 240](#).

The **MON2** analog output terminal produces an output voltage or current that is proportional to the magnitude of the function assigned to this terminal.

Note: *The Expansion IO Card Option 2 option board (P/N ETB004Z) is required to use this terminal.*

See the *Expansion IO Card Option 2 Instruction Manual* (P/N 58686) for additional information on the function of this terminal.

MON2 Terminal Setup Parameters

- F674** — MON2 Output Function
- F675** — MON2 Terminal Meter Adjustment
- F691** — MON2 Voltage/Current Output Switching
- F692** — MON2 Output Gradient Characteristic
- F693** — MON2 Bias Adjustment Set Zero Level

MON2 Terminal Meter Adjustment

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter is used to set the gain of the **MON2** output terminal and is used in conjunction with the settings of parameter [F674](#).

See parameter [F674](#) for additional information on this setting.

FP Terminal Pulse Output Function

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter sets the functionality of the **FP** output terminal to any one of the user-selectable functions listed in [Table 10 on pg. 242](#).

As the assigned function changes in magnitude or frequency, the pulse count of the **FP** output terminal pulse train changes in direct proportion to changes in the assigned function.

Note: *The duty cycle of the output pulse train remains at 65 ±5.0 μS.*

This parameter is used in conjunction with parameter [F677](#).

Pulse Output Frequency (FP)

Program ⇒ Terminal ⇒ Analog Output Terminals

This parameter scales the **FP** output terminal by setting the pulses-per-second output signal of the **FP** terminal.

See [F676](#) for additional information on this parameter.

Direct Access Number — **F674**

Parameter Type — **Selection List**

Factory Default — **Output Frequency**

Changeable During Run — **Yes**

Direct Access Number — **F675**

Parameter Type — **Numerical**

Factory Default — **512**

Changeable During Run — **Yes**

Minimum — 1

Maximum — 1280

Direct Access Number — **F676**

Parameter Type — **Selection List**

Factory Default — **Output Frequency**

Changeable During Run — **Yes**

Direct Access Number — **F677**

Parameter Type — **Numerical**

Factory Default — **3.84**

Changeable During Run — **Yes**

Minimum — 1.00

Maximum — 43.20

Units — Pulses/Second

F681

F686

<p>FM Voltage/Current Output Switching</p> <p>Program ⇒ Terminal ⇒ Analog Output Terminals</p> <p>This parameter is used to select the type of output signal provided at the FM terminal (i.e., voltage or current).</p> <p>The output voltage and current range is 0 – 10 VDC and 0 – 20 mA, respectively.</p> <p>See F005 for additional information on this setting.</p> <p>Settings:</p> <ul style="list-style-type: none"> 0 – 10 V 0 – 20 mA 	<p>Direct Access Number — F681</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0–10V</p> <p>Changeable During Run — No</p>
<p>FM Output Gradient Characteristic</p> <p>Program ⇒ Terminal ⇒ Analog Output Terminals</p> <p>This parameter sets the output response polarity of the FM output terminal. The FM output terminal response may be set to respond inversely (-) or directly (+) to the input signal.</p> <p>See F005 for additional information on this setting.</p> <p>Settings:</p> <ul style="list-style-type: none"> Minus (Negative Gradient) Plus (Positive Gradient) 	<p>Direct Access Number — F682</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Plus</p> <p>Changeable During Run — Yes</p>
<p>FM Bias Adjustment</p> <p>Program ⇒ Terminal ⇒ Analog Output Terminals</p> <p>This parameter setting is used to ensure that a zero-level input signal produces a zero-level output at the FM terminal.</p> <p>Set the function of F005 to zero and then set this parameter to zero for proper operation.</p> <p>See F005 for additional information on this setting.</p>	<p>Direct Access Number — F683</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — -10.0</p> <p>Maximum — +100.0</p> <p>Units — %</p>
<p>AM Output Gradient Characteristic</p> <p>Program ⇒ Terminal ⇒ Analog Output Terminals</p> <p>This parameter sets the output response polarity of the AM output terminal. The AM output terminal response may be set to respond inversely (-) or directly (+) to the input signal.</p> <p>See F670 for additional information on this setting.</p> <p>Settings:</p> <ul style="list-style-type: none"> Minus (Negative Gradient) Plus (Positive Gradient) 	<p>Direct Access Number — F685</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Plus</p> <p>Changeable During Run — Yes</p>
<p>AM Bias Adjustment</p> <p>Program ⇒ Terminal ⇒ Analog Output Terminals</p> <p>This parameter setting is used to ensure that a zero-level input signal produces a zero-level output at the AM terminal.</p> <p>Set the function set at F670 to zero and then set this parameter to zero for proper operation.</p> <p>See F670 for additional information on this setting.</p>	<p>Direct Access Number — F686</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — -10.0</p> <p>Maximum — +100.0</p> <p>Units — %</p>

F688

F692

<p>MON 1 Voltage/Current Output Switching</p> <p>Program ⇒ Terminal ⇒ Analog Output Terminals</p> <p>This parameter is used to set the output signal type of the MON1 output terminal.</p> <p>Settings</p> <ul style="list-style-type: none"> -10 V – +10 V 0 – 10 V 0 – 20 mA 	<p>Direct Access Number — F688</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 – 10V</p> <p>Changeable During Run — Yes</p>
<p>MON 1 Output Gradient Characteristic</p> <p>Program ⇒ Terminal ⇒ Analog Output Terminals</p> <p>This parameter sets the output response polarity of the MON1 output terminal. The MON1 output terminal response may be set to respond inversely (-) or directly (+) to the input signal.</p> <p>See parameter F672 for additional information on this setting.</p> <p>Settings:</p> <ul style="list-style-type: none"> Minus (Negative Gradient) Plus (Positive Gradient) 	<p>Direct Access Number — F689</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Plus</p> <p>Changeable During Run — Yes</p>
<p>MON 1 Bias Adjustment</p> <p>Program ⇒ Terminal ⇒ Analog Output Terminals</p> <p>This parameter setting is used to ensure that a zero-level input signal produces a zero-level output at the MON1 terminal.</p> <p>Set the assigned function of parameter F672 to zero and then set this parameter to a zero output.</p> <p>See parameter F672 for additional information on this setting.</p>	<p>Direct Access Number — F690</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — -10.0</p> <p>Maximum — 100.0</p> <p>Units — %</p>
<p>MON 2 Voltage/Current Output Switching</p> <p>Program ⇒ Terminal ⇒ Analog Output Terminals</p> <p>This parameter is used to set the output signal type of the MON2 output terminal.</p> <p>See parameter F674 for additional information on this setting.</p> <p>Settings</p> <ul style="list-style-type: none"> -10 V – +10 V 0 – 10 V 0 – 20 mA 	<p>Direct Access Number — F691</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 – 10V</p> <p>Changeable During Run — Yes</p>
<p>MON 2 Output Gradient Characteristic</p> <p>Program ⇒ Terminal ⇒ Analog Output Terminals</p> <p>This parameter sets the output response polarity of the MON2 output terminal. The MON2 output terminal response may be set to respond inversely (-) or directly (+) to the input signal.</p> <p>See parameter F672 for additional information on this setting.</p> <p>Settings:</p> <ul style="list-style-type: none"> Minus (Negative Gradient) Plus (Positive Gradient) 	<p>Direct Access Number — F692</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Plus</p> <p>Changeable During Run — Yes</p>

F693

F703

<p>MON 2 Bias Adjustment</p> <p>Program ⇒ Terminal ⇒ Analog Output Terminals</p> <p>This parameter setting is used to ensure that a zero-level input signal produces a zero-level output at the MON2 terminal.</p> <p>Set the assigned function of parameter F674 to zero and then set this parameter to a zero output.</p> <p>See parameter F674 for additional information on this setting.</p>	<p>Direct Access Number — F693</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — -10.0</p> <p>Maximum — 100.0</p> <p>Units — %</p>
<p>Parameter Write Lockout</p> <p>Program ⇒ Utilities ⇒ Prohibition</p> <p>This parameter Enables/Disables the Run and Stop keys.</p> <p>Settings:</p> <ul style="list-style-type: none"> Enabled Disabled 	<p>Direct Access Number — F700</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Enabled</p> <p>Changeable During Run — Yes</p>
<p>Current/Voltage Units Setup</p> <p>Program ⇒ Utilities ⇒ Display Parameters</p> <p>This parameter sets the unit of measurement for current and voltage values displayed on the EOI.</p> <p>Settings:</p> <ul style="list-style-type: none"> % A/V 	<p>Direct Access Number — F701</p> <p>Parameter Type — Selection List</p> <p>Factory Default — %</p> <p>Changeable During Run — Yes</p>
<p>Free Unit Multiplication Factor</p> <p>Program ⇒ Utilities ⇒ Display Parameters</p> <p>This parameter provides a multiplier for the displayed speed value shown on the front panel screen of the ASD.</p> <p>This parameter may be used to display the rate that a commodity is being processed by the driven load in process units (i.e., units/time).</p> <p><i>Example: An output frequency of 100 Hz would be displayed as 50 Hz if using a multiplier of 0.5 for this parameter.</i></p> <p><i>Note: PID frequency-limiting parameters are not affected by this setting (i.e., F364, F365, F367, and F368).</i></p>	<p>Direct Access Number — F702</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00 (Off)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 200.00</p>
<p>Free Unit</p> <p>Program ⇒ Utilities ⇒ Display Parameters</p> <p>This parameter is used in conjunction with F702 to set the method in which the frequency is displayed on the front panel.</p> <p>The multiplier setting of F702 will be applied to the display of all frequencies if All Frequencies are selected at this parameter.</p> <p>The multiplier setting of F702 will be applied to parameters F364, F365, F367, and F368 ONLY if PID Process Data is selected at this parameter.</p> <p>Settings:</p> <ul style="list-style-type: none"> All Frequencies PID Process Data 	<p>Direct Access Number — F703</p> <p>Parameter Type — Selection List</p> <p>Factory Default — All Frequencies</p> <p>Changeable During Run — Yes</p>

F705

F708

<p>Free Unit Display Gradient Characteristic</p> <p>Program ⇒ Utilities ⇒ Display Parameters</p> <p>The ASD-displayed response to output speed changes will be displayed as directly proportional or inversely proportional as a function of this parameter setting.</p> <p>Selecting Negative Gradient displays an increased output speed as going more negative.</p> <p>Selecting Positive Gradient displays an increased output speed as going more positive.</p> <p>Settings:</p> <p>Minus (Negative Gradient) Plus (Positive Gradient)</p>	<p>Direct Access Number — F705</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Plus</p> <p>Changeable During Run — Yes</p>
<p>Free Display Bias</p> <p>Program ⇒ Utilities ⇒ Display Parameters</p> <p>In conjunction with the setting of F702, this parameter sets the bias of the front panel speed display.</p> <p>The frequency entered here will be multiplied by the setting of F702 and then displayed as the zero value on the front panel screen.</p>	<p>Direct Access Number — F706</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>Change Step Selection 1</p> <p>Program ⇒ Utilities ⇒ Display Parameters</p> <p>In conjunction with the parameter setting of F708, this parameter sets the amount that the output speed will increase or decrease for each speed command change entered from the front panel using the Rotary Encoder.</p>	<p>Direct Access Number — F707</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — Max. Freq. (F011)</p> <p>Units — Hz</p>
<p>Change Step Selection 2</p> <p>Program ⇒ Utilities ⇒ Display Parameters</p> <p>The parameter is used to modify the degree that the setting of F707 affects the output speed changes that are input from the front panel using the Rotary Encoder.</p> <p>Selecting a zero value here disables this parameter and the resulting non-zero value of parameter setting F707 is output from the ASD.</p> <p>Selecting a non-zero value here provides a dividend that will be used in the following equation resulting in the actual output frequency applied to the motor.</p> $OutputFrequencyDisplayed = InternallyCommandedFrequency \times \frac{F708}{F707}$	<p>Direct Access Number — F708</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 255</p>

F719

F725

ASD Disposition at ST Deactivation

Program ⇒ Special ⇒ Operation Panel Parameters

Upon deactivation of the **ST** terminal (if so configured; see F110) while operating in the **Local** mode, the ASD output to the motor will cease — this parameter setting is used to allow for the restart of the motor (ASD output) without user intervention upon the reactivation of the **ST** terminal.

Upon reactivation of the **ST** terminal in this condition the ASD will resume the Run condition and the motor will start (Retain Panel Run Command).

This feature may be **Disabled** and the Run command must be re-initiated by the user for ASD operation (Clear Panel Run Command).

**DANGER**

WHEN ENABLED THE ASD WILL RESUME THE RUN CONDITION WHEN THE ST TERMINAL IS REACTIVATED.

Settings:

Clear Panel Run Command
Retain Panel Run Command

Direct Access Number — F719

Parameter Type — **Selection List**

Factory Default — **Retain Panel Run Command**

Changeable During Run — **Yes**

Panel Stop Pattern

Program ⇒ Special ⇒ Operation Panel Parameters

While operating in the **Local** mode this parameter determines the method used to stop the motor when the stop command is issued via the **EOI**.

The **Decel Stop** setting enables the **Dynamic Braking** system that is setup at F304 or the **DC Injection Braking** system that is setup at F250, F251, and F252.

The **Coast Stop** setting allows the motor to stop at the rate allowed by the inertia of the load.

Settings:

Deceleration Stop
Coast Stop

***Note:** The **Stop Pattern** setting has no effect on the **Emergency Off** settings of F603. This parameter may also be accessed by pressing the **ESC** key from the **Frequency Command** screen.*

Direct Access Number — F721

Parameter Type — **Selection List**

Factory Default — **Deceleration Stop**

Changeable During Run — **Yes**

Panel Torque Command

Program ⇒ Special ⇒ Operation Panel Parameters

This parameter provides a torque value to be used in the event that **Panel Keypad (F725 Setting)** is selected at parameter F420.

Direct Access Number — F725

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — -250.00

Maximum — +250.00

F727

F735

<p>Panel Tension Torque Bias</p> <p>Program ⇒ Special ⇒ Operation Panel Parameters</p> <p>This function is not used with the ACE-tronics G9 ASD. The Tension Torque Bias selection is performed at F423.</p>	<p>Direct Access Number — F727</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — -250.00</p> <p>Maximum — +250.00</p> <p>Units — %</p>
<p>Panel Load Sharing Gain</p> <p>Program ⇒ Special ⇒ Operation Panel Parameters</p> <p>This function is not used with the ACE-tronics G9 ASD. The Load Sharing Gain selection is performed at F424.</p>	<p>Direct Access Number — F728</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 100.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 250.00</p> <p>Units — %</p>
<p>Panel Override Multiplication Gain</p> <p>Program ⇒ Special ⇒ Operation Panel Parameters</p> <p>This parameter provides a value to be used in the event that Setting (F729) is selected for the Frequency Override Multiplying Input (F661).</p>	<p>Direct Access Number — F729</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — -100.00</p> <p>Maximum — 100.00</p> <p>Units — %</p>
<p>Panel Frequency Lockout</p> <p>Program ⇒ Special ⇒ Operation Panel Parameters</p> <p>This function is not used with the ACE-tronics G9 ASD.</p> <p>Settings:</p> <ul style="list-style-type: none"> Unlocked Locked 	<p>Direct Access Number — F730</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Unlocked</p> <p>Changeable During Run — Yes</p>
<p>Panel Emergency Off Lockout</p> <p>Program ⇒ Special ⇒ Operation Panel Parameters</p> <p>This function is not used with the ACE-tronics G9 ASD.</p> <p>Settings:</p> <ul style="list-style-type: none"> Unlocked Locked 	<p>Direct Access Number — F734</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Unlocked</p> <p>Changeable During Run — No</p>
<p>Panel Reset Lockout</p> <p>Program ⇒ Special ⇒ Operation Panel Parameters</p> <p>This function is not used with the ACE-tronics G9 ASD.</p> <p>Settings:</p> <ul style="list-style-type: none"> Unlocked Locked 	<p>Direct Access Number — F735</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Unlocked</p> <p>Changeable During Run — Yes</p>

F736

F740

<p>Command Mode/Frequency Mode Change Lockout</p> <p>Program ⇒ Utilities ⇒ Prohibition</p> <p>This function is not used with the ACE-tronics G9 ASD.</p> <p>Settings:</p> <ul style="list-style-type: none"> Unlocked Locked 	<p>Direct Access Number — F736</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Locked</p> <p>Changeable During Run — Yes</p>
<p>Lockout All Keys</p> <p>Program ⇒ Utilities ⇒ Prohibition</p> <p>This function is not used with the ACE-tronics G9 ASD.</p> <p>Settings:</p> <ul style="list-style-type: none"> Unlocked Locked 	<p>Direct Access Number — F737</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Unlocked</p> <p>Changeable During Run — Yes</p>
<p>Trace Selection</p> <p>Program ⇒ Utilities ⇒ Trace</p> <p>In conjunction with parameter F741 – F745, this parameter is used to monitor and store 4 ASD output waveform data points. The data may be read and stored as a function of a trip (At Trip) or it may be initiated by the activation of a discrete terminal activation (At Trigger).</p> <p>Set a discrete input terminal to Trace Back Trigger Signal and activate the terminal to initiate the At Trigger read/store function.</p> <p>Table 12 on pg. 245 lists the items that may be selected for the data read/store function along with the associated communication number for each selection.</p> <p>The duration of the read/store cycle for the selected items is set at parameter F741.</p> <p>To acquire and store the data a communications device and a PC are required. The ACE-tronics G9 ASD supports the following communications protocols: RS485 (MODBUS-RTU) Toshiba Protocol, USB Toshiba Protocol, CC-Link, ProfiBus, and DeviceNet (Refer to the manual of each protocol type for additional information).</p> <p>Trace data may be viewed graphically via Program ⇒ Utilities ⇒ View Trace Data.</p> <p>Settings:</p> <ul style="list-style-type: none"> None (Disabled) At Trip At Trigger 	<p>Direct Access Number — F740</p> <p>Parameter Type — Selection List</p> <p>Factory Default — At Trip</p> <p>Changeable During Run — Yes</p>

F741

F745

<p>Trace Cycle</p> <p>Program ⇒ Utilities ⇒ Trace</p> <p>This parameter sets the record time for the Trace Data events selected at F742 – F745.</p> <p>See F740 for additional information on this parameter setting.</p> <p>Settings:</p> <ul style="list-style-type: none"> 4 mS 20 mS 100 mS 1 Second 10 Seconds 	<p>Direct Access Number — F741</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 100 mS</p> <p>Changeable During Run — Yes</p>
<p>Trace Data 1</p> <p>Program ⇒ Utilities ⇒ Trace Data 1</p> <p>This parameter is used to select the Trace Data 1 item from Table 11 on pg. 244 to be read and stored in accordance with the setup of parameters F740 and F741.</p> <p>See F740 for additional information on this parameter setting.</p>	<p>Direct Access Number — F742</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Output Frequency</p> <p>Changeable During Run — Yes</p>
<p>Trace Data 2</p> <p>Program ⇒ Utilities ⇒ Trace Data 2</p> <p>This parameter is used to select the Trace Data 2 item from Table 11 on pg. 244 to be read and stored in accordance with the setup of parameters F740 and F741.</p> <p>See F740 for additional information on this parameter setting.</p>	<p>Direct Access Number — F743</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Freq. Reference</p> <p>Changeable During Run — Yes</p>
<p>Trace Data 3</p> <p>Program ⇒ Utilities ⇒ Trace Data 3</p> <p>This parameter is used to select the Trace Data 3 item from Table 11 on pg. 244 to be read and stored in accordance with the setup of parameters F740 and F741.</p> <p>See F740 for additional information on this parameter setting.</p>	<p>Direct Access Number — F744</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Output Current</p> <p>Changeable During Run — Yes</p>
<p>Trace Data 4</p> <p>Program ⇒ Utilities ⇒ Trace Data 4</p> <p>This parameter is used to select the Trace Data 4 item from Table 11 on pg. 244 to be read and stored in accordance with the setup of parameters F740 and F741.</p> <p>See F740 for additional information on this parameter setting.</p>	<p>Direct Access Number — F745</p> <p>Parameter Type — Selection List</p> <p>Factory Default — DC Voltage</p> <p>Changeable During Run — Yes</p>

<p>RS485 2-Wire Baud Rate</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>This parameter plays a role in the setup of the communications network by establishing the Baud Rate of the communications link.</p> <p>The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.</p> <p>Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.</p> <p>Settings:</p> <ul style="list-style-type: none"> 9600 19200 38400 	<p>Direct Access Number — F800</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 19200</p> <p>Changeable During Run — Yes</p> <p>Units — bps</p>
<p>RS485 2-Wire and 4-Wire Parity</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>This parameter plays a role in the setup of the communications network by establishing the Parity setting of the communications link.</p> <p>The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.</p> <p>Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.</p> <p>Settings:</p> <ul style="list-style-type: none"> No Parity Even Parity Odd Parity 	<p>Direct Access Number — F801</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Even Parity</p> <p>Changeable During Run — Yes</p>
<p>ASD Number</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>This parameter plays a role in the setup of the communications network by assigning an identification (ID) number to each ASD in the communications network.</p> <p>The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.</p> <p>Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.</p>	<p>Direct Access Number — F802</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 247</p>
<p>RS485 2-Wire and 4-Wire Communications Time Out</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>This parameter plays a role in the setup of the communications network by setting the time that no activity may exist over the communications link before the link is severed (Time Out).</p> <p>The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.</p> <p>Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.</p>	<p>Direct Access Number — F803</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0 (Off)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0 (Off)</p> <p>Maximum — 100</p> <p>Units — Seconds</p>

F804**F805****RS485 2-Wire and 4-Wire Communications Time-Out Action**

Program ⇒ Communications ⇒ Communication

This parameter plays a role in the setup of the communications network by determining the action to be taken in the event of a time-out (Time-Out Action).

The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

No Action/No Action
 Alarm/No Action
 Trip/No Action
 No Action/Alarm
 Alarm/Alarm
 Trip/Alarm
 No Action/Trip
 Alarm/Trip
 Trip/Trip

Direct Access Number — F804

Parameter Type — **Selection List**

Factory Default — **Trip/Trip**

Changeable During Run — **Yes**

RS485 2-Wire Send Wait Time

Program ⇒ Communications ⇒ Communication

This parameter sets the RS485 2-Wire response delay time.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Direct Access Number — F805

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 2.00

Units — Seconds

F806**F810****RS485 2-Wire ASD-to-ASD Communications**

Program ⇒ Communications ⇒ Communication

The function of this parameter is 2-fold:

1) In a Master/Follower configuration and while communicating via RS485 2-Wire, this parameter sets the ASD as the Master or the Follower.

2) This parameter determines the function of the ASD while operating as the Master or the Follower. If operating as the Master ASD, an output parameter of the Master ASD is used to control the Follower ASDs and is set here. If operating as a Follower ASD, the ASD response if an error is incurred is set here.

Note: *Select a Follower function here if **F826** is configured as a **Master Output** controller for any other ASD in the system. Otherwise, an **EOI** failure will result.*

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

- Follower (Decel Stop If Error Detected)
- Follower (Continues Operation If Error Detected)
- Follower (Emergency Off If Error Detected)
- Master (Frequency Command)
- Master (Output Frequency)
- Master (Torque Reference)
- Master (Torque Command)

Direct Access Number — F806

Parameter Type — **Selection List**

Factory Default — **Follower (Decel Stop)**

Changeable During Run — **Yes**

Frequency Point Selection

Program ⇒ Communications ⇒ Communication Reference Adjust

This parameter is used to set the communications reference for scaling.

See **F811 — F814** for additional information on this setting.

Note: *Scaling the communications signal is not required for all applications.*

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

- Disabled
- RS485 (2-Wire — NOT USED)
- RS485 4-Wire
- Communication Card

Direct Access Number — F810

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **Yes**

F811

F813

Point 1 Setting

Program ⇒ Communications ⇒ Communication Reference Adjust

When enabled at F810, this parameter is used to allow the user to set the gain and bias of the speed control input to the ASD when the speed control signal is received via the source selected at F810 (Communications).

Gain and Bias Settings

When operating in the **Speed Control** mode and using one of the control sources from parameter F810, the settings that determine the gain and bias of the input signal are:

- **Point 1 Frequency (F812)**,
- the communications input signal value that represents **Point 1 Frequency**: (Point 1 Setting) F811,
- **Point 2 Frequency (F814)**, and
- the communications input signal value that represents **Point 2 Frequency**: (Point 2 Setting) F813.

Once set, as the input signal value changes, the output frequency of the ASD will vary in accordance with the above settings.

This parameter sets the **Reference** input value (Point 1 Setting) that represents **Point 1 Frequency**. This value is entered as 0 to 100% of the **Reference** input value range.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Direct Access Number — F811

Parameter Type — **Numerical**


Factory Default — **0**

Changeable During Run — **Yes**

Minimum — 0

Maximum — 100

Units — %

**Point 1 Frequency**

Program ⇒ Communications ⇒ Communication Reference Adjust

This parameter is used to set the gain and bias of the **Reference** speed control input.

This parameter sets **Point 1 Frequency**.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

See F811 for additional information on this setting.

Direct Access Number — F812

Parameter Type — **Numerical**

Factory Default — **0.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

Point 2 Setting

Program ⇒ Communications ⇒ Communication Reference Adjust

This parameter is used to set the gain and bias of the **Reference** speed control input.

This parameter sets the **Reference** input value (Point 2 Setting) that represents **Point 2 Frequency**. This value is entered as 0 to 100% of the **Reference** input value range.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

See F811 for additional information on this setting.

Direct Access Number — F813

Parameter Type — **Numerical**

Factory Default — **100**

Changeable During Run — **Yes**

Minimum — 0

Maximum — 100

Units — %

F814**F825****Point 2 Frequency**

Program ⇒ Communications ⇒ Communication Reference Adjust

This parameter is used to set the gain and bias of the **Reference** speed control input.

This parameter sets the **Point 2 Frequency**.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

See **F811** for additional information on this setting.

Direct Access Number — F814

Parameter Type — **Numerical**

Factory Default — **60.00**

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — **Max. Freq. (F011)**

Units — Hz

RS485 4-Wire Baud Rate

Program ⇒ Communications ⇒ Communication

This parameter sets the RS485 baud rate.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

9600 bps

19200 bps

38400 bps

Direct Access Number — F820

Parameter Type — **Selection List**

Factory Default — **19200**

Changeable During Run — **Yes**

RS485 Send Wait Time

Program ⇒ Communications ⇒ Communication

This parameter sets the RS485 response delay time.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Direct Access Number — F825

Parameter Type — **Numerical**

Factory Default — 0.00

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 2.00

Units — Seconds

F826**F830****RS485 4-Wire ASD-to-ASD Communications**

Program ⇒ Communications ⇒ Communication

The function of this parameter is 2-fold:

1) In a Master/Follower configuration and while communicating via RS485 4-Wire, this parameter sets the ASD as the Master or the Follower.

2) This parameter determines the function of the ASD while operating as the Master or the Follower. If operating as the Master ASD, an output parameter of the Master ASD is used to control the Follower ASDs and is set here. If operating as a Follower ASD, the ASD response if an error is incurred is set here.

Note: *Select a Follower function here if **F806** is configured as a **Master Output** controller for any other ASD in the system. Otherwise, an **EOI** failure will result.*

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

- Follower (Decel Stop If Error Detected)
- Follower (Continues Operation If Error Detected)
- Follower (Emergency Off If Error Detected)
- Master (Frequency Command)
- Master (Output Frequency)
- Master (Torque Reference)
- Master (Output Torque)

Direct Access Number — F826Parameter Type — **Selection List**Factory Default — **Follower (Decel Stop)**Changeable During Run — **Yes****RS485 4-Wire Protocol Selection (TSB/ModBus)**

Program ⇒ Communications ⇒ Communication

This parameter sets the communications protocol for ASD-to-ASD communications.

Settings:

- Toshiba
- Modbus

Direct Access Number — F829Parameter Type — **Selection List**Factory Default — **Toshiba**Changeable During Run — **Yes****Communications Option (DeviceNet/Profibus) Setting 1**

Program ⇒ Communications ⇒ Communication

While using the DeviceNet/Profibus communications protocol, this parameter allows the user to select the read and write information communicated between the ASD and the Host.

Read information may include the ASD fault status, ASD speed, ASD MAC ID, etc. Write information may include Enable/Disable DeviceNet commands, Forward run, ACC/DEC command, etc.

See the **DeviceNet Option Instruction Manual** (P/N 58683) for additional information on this parameter.

Settings:

- 0 – 7

Direct Access Number — F830Parameter Type — **Selection List**Factory Default — **0**Changeable During Run — **Yes**

F831

F836

<p>Communications Option (DeviceNet/Profibus) Setting 2</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>While using the DeviceNet/Profibus communications protocol, parameters F831 – F836 allow the user to select the ASD memory location that holds the Command/Frequency/Monitoring instructions to be applied to the ASD for Communications Option Settings 2 – 7, respectively.</p> <p>See the DeviceNet Option Instruction Manual (P/N 58683) for additional information on this parameter.</p> <p>Settings:</p> <ul style="list-style-type: none"> Disabled FA06 (ALCAN Command 1) FA23 (ALCAN Command 2) FA07 (ALCAN Frequency Command, 0.01 Hz) FA33 (Torque Command, 0.01%) FA50 (Terminal Output) FA51 (Analog Output Data from Comm. [FM]) FA52 (Analog Output Data from Comm. [AM]) F601 (Stall Prevention Level, %) F441 (Power Running Torque Limit 1 Level, 0.01%) F443 (Dynamic Braking Torque Limit 1 Level, 0.01%) F460 (Speed Loop Proportional Gain) F461 (Speed Loop Stabilization Coefficient) 	<p>Direct Access Number — F831</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0000h</p> <p>Changeable During Run — Yes</p>
<p>Communications Option (DeviceNet/Profibus) Setting 3</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>Same as F831. See F831 for information on this parameter</p>	<p>Direct Access Number — F832</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0000h</p> <p>Changeable During Run — Yes</p>
<p>Communications Option (DeviceNet/Profibus) Setting 4</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>Same as F831. See F831 for information on this parameter</p>	<p>Direct Access Number — F833</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0000h</p> <p>Changeable During Run — Yes</p>
<p>Communications Option (DeviceNet/Profibus) Setting 5</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>Same as F831. See F831 for information on this parameter</p>	<p>Direct Access Number — F834</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0000h</p> <p>Changeable During Run — Yes</p>
<p>Communications Option (DeviceNet/Profibus) Setting 6</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>Same as F831. See F831 for information on this parameter</p>	<p>Direct Access Number — F835</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0000h</p> <p>Changeable During Run — Yes</p>
<p>Communications Option (DeviceNet/Profibus) Setting 7</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>Same as F831. See F831 for information on this parameter</p>	<p>Direct Access Number — F836</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0000h</p> <p>Changeable During Run — Yes</p>

F841**F844****Communications Option (DeviceNet/Profibus) Setting 8**

Program ⇒ Communications ⇒ Communication

While using the DeviceNet/Profibus communications protocol, parameters **F841 – F846** allow the user to select the ASD memory location that holds the Command/Frequency/Monitoring instructions to be applied to the ASD for **Communications Option Settings 8 – 13**, respectively.

See the **DeviceNet Option Instruction Manual** (P/N 58683) for additional information on this parameter.

Settings:

Disabled
 FD01 (ASD Status 1)
 FD00 (Output Frequency, 0.01 Hz)
 FD03 (Output Current, 0.01%)
 FD05 (Output Voltage, 0.01%)
 FC91 (ASD Alarm)
 FD22 (PID Feedback Value, 0.01 Hz)
 FD06 (Input Terminal Status)
 FD07 (Output Terminal Status)
 FE36 (V/I)
 FE35 (RR Input)
 FE37 (RX Input)
 FD04 (Input Voltage [DC Detection], 0.01%)
 FD16 (Realtime Speed Feedback
 FD18 (Torque, 0.01%)
 FE60 (My Monitor)
 FE61 (My Monitor)
 FE62 (My Monitor)
 FE63 (My Monitor)
 F880 (Free Notes)
 FD29 (Input Power, 0.01 kW)
 FD30 (Output Power, 0.01 kW)
 FE14 (Cumulative Operation Time, 0.01=1 Hour)
 FE40 (FM Terminal Output Monitor)
 FE41 (AM Terminal Output Monitor)

Direct Access Number — F841

Parameter Type — **Selection List**

Factory Default — **0000h**

Changeable During Run — **Yes**

Communications Option (DeviceNet/Profibus) Setting 9

Program ⇒ Communications ⇒ Communication

Same as **F841**. See **F841** for information on this parameter

Direct Access Number — F842

Parameter Type — **Selection List**

Factory Default — **0000h**

Changeable During Run — **Yes**

Communications Option (DeviceNet/Profibus) Setting 10

Program ⇒ Communications ⇒ Communication

Same as **F841**. See **F841** for information on this parameter

Direct Access Number — F843

Parameter Type — **Selection List**

Factory Default — **0000h**

Changeable During Run — **Yes**

Communications Option (DeviceNet/Profibus) Setting 11

Program ⇒ Communications ⇒ Communication

Same as **F841**. See **F841** for information on this parameter

Direct Access Number — F844

Parameter Type — **Selection List**

Factory Default — **0000h**

Changeable During Run — **Yes**

<p>Communications Option (DeviceNet/Profibus) Setting 12</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>Same as F841. See F841 for information on this parameter</p>	<p>Direct Access Number — F845</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0000h</p> <p>Changeable During Run — Yes</p>
<p>Communications Option (DeviceNet/Profibus) Setting 13</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>Same as F841. See F841 for information on this parameter</p>	<p>Direct Access Number — F846</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0000h</p> <p>Changeable During Run — Yes</p>
<p>Disconnection Detection Extended Time</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>This parameter is used to set the length of time that no communications activity may exist before the communications link is disconnected.</p>	<p>Direct Access Number — F850</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — 100.0</p> <p>Units — Seconds</p>
<p>ASD Operation at Disconnection</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>This parameter is used to set the ASD action to be carried out in the event of the loss of communications.</p> <p>Settings:</p> <ul style="list-style-type: none"> Stop and Terminate Communications Do Nothing (Continue Programmed Operation) Deceleration Stop Coast Stop Emergency Off Preset Speed (Setting of F852) 	<p>Direct Access Number — F851</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Stop, Communication Release</p> <p>Changeable During Run — Yes</p>
<p>Preset Speed Operation</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>This parameter is used in conjunction with parameter F806.</p> <p>This parameter setting is used to set the Preset Speed selection to be used if Preset Speed is selected at parameter F851.</p> <p>Settings:</p> <ul style="list-style-type: none"> 0 — Disabled 1 – 15 — Preset Speed Number 	<p>Direct Access Number — F852</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>
<p>Communications Option Station Address Monitor</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>This parameter is used in the setup of the communications network by reading the Media Access Code (MAC) address of the ASD that is connected to a node of the communications system.</p> <p>The MAC Address is set via DIP switches of the optional device.</p> <p>See the DeviceNet Option Instruction Manual (P/N 58683) for additional information on this parameter.</p>	<p>Direct Access Number — F853</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 255</p>

F854

F864

<p>Communications Option Speed Switch Monitor DeviceNet/CC-Link</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>This parameter is used in the setup of the communications network by reading the hardware-specific settings of the option card being used with the ASD.</p> <p>If using the DEV002Z Devicenet card, this parameter reads the hardware switch SW300 setting of the Devicenet card. SW300 sets the baud rate and the MAC address of the option card that is connected to a node of the communications system.</p>	<p>Direct Access Number — F854</p> <p>Parameter Type — Hardware Selectable</p> <p>Factory Default — Option-Specific</p> <p>Changeable During Run — No</p> <p>Minimum — 0</p> <p>Maximum — 255</p>
<p>Timed-Run Run-Time</p> <p>Program ⇒ Crane/Hoist ⇒ Timed-Run</p> <p>This parameter sets the amount of time that the ASD outputs the commanded speed (from RR, Communications, etc.). The Timed Run is activated by assigning a discrete terminal to Timed Run and momentarily activating the assigned terminal.</p> <p>If activated longer than this time setting, the Timed Run will repeat at the rate setting of F862.</p>	<p>Direct Access Number — F861</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — 5.0</p> <p>Units — Seconds</p>
<p>Timed-Run Repeat Delay</p> <p>Program ⇒ Crane/Hoist ⇒ Timed-Run</p> <p>If the Timed Run input terminal remains activated past the Timed Run duration setting (F861), this parameter setting will determine the wait-time before restarting the Timed Run sequence.</p>	<p>Direct Access Number — F862</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1.0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.0</p> <p>Maximum — 5.0</p> <p>Units — Seconds</p>
<p>Super Creep Pulse Count</p> <p>Program ⇒ Crane/Hoist ⇒ Super Creep Control</p> <p>This parameter requires that a discrete input terminal be set to Super Creep for activation (see Table 7 on pg. 236). Any unused discrete input terminal may be assigned to the Super Creep function.</p> <p>Activating the Super Creep terminal rotates the motor for the amount of encoder pulses set at this parameter at the frequency setting of F865.</p> <p><i>Note: Available in closed-loop operation only.</i></p>	<p>Direct Access Number — F863</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1024</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 16383</p> <p>Units — Pulses</p>
<p>Super Creep Speed Repeat Delay</p> <p>Program ⇒ Crane/Hoist ⇒ Super Creep Control</p> <p>If the Super Creep Pulse Count (F863) discrete input terminal remains activated past the Super Creep Pulse Count setting, this parameter setting will determine the wait-time before restarting the Super Creep Pulse Count sequence.</p>	<p>Direct Access Number — F864</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 2.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 60.0</p> <p>Units — Seconds</p>

F865

F869

Super Creep Speed

Program ⇒ Crane/Hoist ⇒ Super Creep Control

This parameter sets the **Super Creep Speed**.

Direct Access Number — F865

Parameter Type — **Numerical**

Factory Default — **0.60**

Changeable During Run — **Yes**

Minimum — 0.02

Maximum — 20.00

Units — Hz

Slack Rope Detection

Program ⇒ Crane/Hoist ⇒ Slack Rope

This parameter **Enables/Disables** the **Slack Rope Detection** function. **Slack Rope Detection** is used while lowering the load to determine if the load has reached the end of its travel (hit the floor, truck bed, etc.).

With this parameter enabled during hoist lowering, should the load torque reach or fall below the **No-Load Torque** setting (F868) for the **No-Load (Torque) Detection Time** setting (F869), the ASD will stop automatically.

Settings:

Disabled

Enabled

Direct Access Number — F867

Parameter Type — **Selection List**

Factory Default — **Disabled**

Changeable During Run — **No**

Minimum — 0

Maximum — 1

No-Load Torque

Program ⇒ Crane/Hoist ⇒ Slack Rope

With the **Slack Rope Detection** (F867) feature enabled during hoist lowering, should the load torque reach or fall below this setting (F868) for the **No-Load (Torque) Detection Time** setting (F869), the ASD will stop automatically.

If the load torque falls below this setting and returns to a value above this setting within the time of F869, normal operations will resume.

Direct Access Number — F868

Parameter Type — **Numerical**

Factory Default — **20.00**

Changeable During Run — **No**

Minimum — 0.00

Maximum — 100.0

Units — %

No-Load (Torque) Detection Time

Program ⇒ Crane/Hoist ⇒ Slack Rope

With the **Slack Rope Detection** (F867) feature enabled during hoist lowering, should the load torque reach or fall below the **No-Load Torque** setting (F868) for the **No-load (Torque) Detection Time** setting (F869), the ASD will stop automatically.

Direct Access Number — F869

Parameter Type — **Numerical**

Factory Default — **0.10**

Changeable During Run — **No**

Minimum — 0.01

Maximum — 2.00

Units — Seconds

F870**F871****Block Write Data 1**

Program ⇒ Communications ⇒ Communication

This parameter plays a role in the setup of the communications network by establishing the type of data to be written to the ASD of the communications link.

The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

- None
- FA00 (Command 1)
- FA20 (Command 2)
- FA01 (Frequency)
- FA50 (TB Output)
- FA51 (Analog Output)

Direct Access Number — F870

Parameter Type — **Selection List**

Factory Default — **None**

Changeable During Run — **Yes**

Block Write Data 2

Program ⇒ Communications ⇒ Communication

This parameter plays a role in the setup of the communications network by establishing the type of data to be written to the ASD of the communications link.

The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

- None
- FA00 (Command 1)
- FA20 (Command 2)
- FA01 (Frequency)
- FA50 (TB Output)
- FA51 (Analog Output)

Direct Access Number — F871

Parameter Type — **Selection List**

Factory Default — **None**

Changeable During Run — **Yes**

Block Read Data 1

Program ⇒ Communications ⇒ Communication

This parameter plays a role in the setup of the communications network by establishing the type of data to be read from the ASD using the communications link.

The communications network includes other ASDs and Host/Control computers that monitor the status of the ASD(s), transfers commands, and loads or modifies the parameter settings of the ASD.

Changes made to this parameter require that the power be cycled (off then on) for the changes to take effect.

Settings:

- None
- Status Information
- Output Frequency
- Output Current
- Output Voltage
- Alarm Information
- PID Feedback Value
- Input Terminal Status
- Output Terminal Status
- V/I
- RR
- RX
- DC Voltage
- PG Feedback
- Torque
- My Monitor 1
- My Monitor 2
- My Monitor 3
- My Monitor 4
- Free Memo

Direct Access Number — F875

Parameter Type — **Selection List**

Factory Default — 0 (None)

Changeable During Run — **Yes**

Block Read Data 2

Program ⇒ Communications ⇒ Communication

This parameter plays a role in the setup of the communications network by establishing the type of data to be read from the ASD of the communications link.

See parameter [F875](#) for additional information on this setting.

Direct Access Number — F876

Parameter Type — **Selection List**

Factory Default — None

Changeable During Run — **Yes**

Block Read Data 3

Program ⇒ Communications ⇒ Communication

This parameter plays a role in the setup of the communications network by establishing the type of data to be read from the ASD of the communications link.

See parameter [F875](#) for additional information on this setting.

Direct Access Number — F877

Parameter Type — **Selection List**

Factory Default — None

Changeable During Run — **Yes**

F878

F901

<p>Block Read Data 4</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>This parameter plays a role in the setup of the communications network by establishing the type of data to be read from the ASD of the communications link.</p> <p>See parameter F875 for additional information on this setting.</p>	<p>Direct Access Number — F878</p> <p>Parameter Type — Selection List</p> <p>Factory Default — None</p> <p>Changeable During Run — Yes</p>
<p>Block Read Data 5</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>This parameter plays a role in the setup of the communications network by establishing the type of data to be read from the ASD of the communications link.</p> <p>See parameter F875 for additional information on this setting.</p>	<p>Direct Access Number — F879</p> <p>Parameter Type — Selection List</p> <p>Factory Default — None</p> <p>Changeable During Run — Yes</p>
<p>Free Notes</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>This is an unused parameter that has allocated memory space.</p> <p>The space may be used at the discretion of the user. This space may be used to store information or a note to be transferred using communications.</p>	<p>Direct Access Number — F880</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 65534</p>
<p>Network Option Reset</p> <p>Program ⇒ Communications ⇒ Communication</p> <p>This parameter plays a role in the setup of the communications network by establishing the targets of a Reset command received via the communications link.</p> <p>Settings:</p> <ul style="list-style-type: none"> Reset ASD only Reset Option Board and ASD 	<p>Direct Access Number — F899</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Reset ASD only</p> <p>Changeable During Run — Yes</p>
<p>Input Function Target 1</p> <p>Program ⇒ My Function ⇒ My Function Unit 1</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 1 terminal.</p> <p>This setting assigns the function of the programmable Input Function Target 1 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241, Table 10 on pg. 242, or Table 12 on pg. 245.</p> <p>See F977 for additional information on this parameter.</p>	<p>Direct Access Number — F900</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>
<p>Input Function Command 1</p> <p>Program ⇒ My Function ⇒ My Function Unit 1</p> <p>This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function.</p> <p>Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977.</p>	<p>Direct Access Number — F901</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (NOP)</p>

<p>Input Function Target 2</p> <p>Program ⇒ My Function ⇒ My Function Unit 1</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 2 terminal.</p> <p>This setting assigns the function of the programmable Input Function Target 2 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241, Table 10 on pg. 242, or Table 12 on pg. 245.</p> <p>See F977 for additional information on this parameter.</p>	<p>Direct Access Number — F902</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>
<p>Input Function Command 2</p> <p>Program ⇒ My Function ⇒ My Function Unit 1</p> <p>This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function.</p> <p>Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977.</p>	<p>Direct Access Number — F903</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (NOP)</p>
<p>Input Function Target 3</p> <p>Program ⇒ My Function ⇒ My Function Unit 1</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 3 terminal.</p> <p>This setting assigns the function of the programmable Input Function Target 3 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241, Table 10 on pg. 242, or Table 12 on pg. 245.</p> <p>See F977 for additional information on this parameter.</p>	<p>Direct Access Number — F904</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>
<p>Output Function Assigned</p> <p>Program ⇒ My Function ⇒ My Function Unit 1</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the Output Function Assigned terminal.</p> <p>This setting assigns the function of the programmable Output Function Assigned data location to one of the functions listed in the Input Setting field of Table 9 on pg. 241.</p> <p>Settings:</p> <p>0 – 3099</p> <p>See the F977 for additional information on this parameter.</p>	<p>Direct Access Number — F905</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>

F906

F910

<p>Input Function Target 1</p> <p>Program ⇒ My Function ⇒ My Function Unit 2</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 1 terminal.</p> <p>This setting assigns the function of the programmable Input Function Target 1 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241, Table 10 on pg. 242, or Table 12 on pg. 245.</p> <p>See F977 for additional information on this parameter.</p>	<p>Direct Access Number — F906</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>
<p>Input Function Command 1</p> <p>Program ⇒ My Function ⇒ My Function Unit 2</p> <p>This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function.</p> <p>Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977.</p>	<p>Direct Access Number — F907</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (NOP)</p>
<p>Input Function Target 2</p> <p>Program ⇒ My Function ⇒ My Function Unit 2</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 2 terminal.</p> <p>This setting assigns the function of the programmable Input Function Target 2 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241, Table 10 on pg. 242, or Table 12 on pg. 245.</p> <p>See F977 for additional information on this parameter.</p>	<p>Direct Access Number — F908</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>
<p>Input Function Command 2</p> <p>Program ⇒ My Function ⇒ My Function Unit 2</p> <p>This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function.</p> <p>Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977.</p>	<p>Direct Access Number — F909</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (NOP)</p>
<p>Input Function Target 3</p> <p>Program ⇒ My Function ⇒ My Function Unit 2</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 3 terminal.</p> <p>This setting assigns the function of the programmable Input Function Target 3 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241, Table 10 on pg. 242, or Table 12 on pg. 245.</p> <p>See F977 for additional information on this parameter.</p>	<p>Direct Access Number — F910</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>

F911

F915

Output Function Assigned

Program ⇒ My Function ⇒ My Function Unit 2

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the **Output Function Assigned** terminal.

This setting assigns the function of the programmable **Output Function Assigned** data location to one of the functions listed in the **Input Setting** field of [Table 10 on pg. 242](#).

Settings:

0 – 3099

See [F977](#) for additional information on this parameter.

Direct Access Number — F911

Parameter Type — **Selection List**

Factory Default — **0 (Disabled)**

Changeable During Run — **Yes**

Input Function Target 1

Program ⇒ My Function ⇒ My Function Unit 3

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the programmable **Input Function Target 1** terminal.

This setting assigns the function of the programmable **Input Function Target 1** terminal to any one of the user-selectable functions listed in [Table 9 on pg. 241](#), [Table 10 on pg. 242](#), or [Table 12 on pg. 245](#).

See [F977](#) for additional information on this parameter.

Direct Access Number — F912

Parameter Type — **Selection List**

Factory Default — **0 (Disabled)**

Changeable During Run — **Yes**

Input Function Command 1

Program ⇒ My Function ⇒ My Function Unit 3

This parameter is used to assign a user-selected logical operator to two user-selected **Input Function Target** variables, enable a counter/timer function, or perform a hold/Reset function.

[Table 13 on pg. 247](#) lists the available selections. Their use and selection requirements are described in an example at [F977](#).

Direct Access Number — F913

Parameter Type — **Selection List**

Factory Default — 0 (NOP)

Input Function Target 2

Program ⇒ My Function ⇒ My Function Unit 3

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the programmable **Input Function Target 2** terminal.

This setting assigns the function of the programmable **Input Function Target 2** terminal to any one of the user-selectable functions listed in [Table 9 on pg. 241](#), [Table 10 on pg. 242](#), or [Table 12 on pg. 245](#).

See [F977](#) for additional information on this parameter.

Direct Access Number — F914

Parameter Type — **Selection List**

Factory Default — **0 (Disabled)**

Changeable During Run — **Yes**

Input Function Command 2

Program ⇒ My Function ⇒ My Function Unit 3

This parameter is used to assign a user-selected logical operator to two user-selected **Input Function Target** variables, enable a counter/timer function, or perform a hold/Reset function.

[Table 13 on pg. 247](#) lists the available selections. Their use and selection requirements are described in an example at [F977](#).

Direct Access Number — F915

Parameter Type — **Selection List**

Factory Default — 0 (NOP)

F916

F920

Input Function Target 3

Program ⇒ My Function ⇒ My Function Unit 3

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the programmable **Input Function Target 3** terminal.

This setting assigns the function of the programmable **Input Function Target 3** terminal to any one of the user-selectable functions listed in [Table 9 on pg. 241](#), [Table 10 on pg. 242](#), or [Table 12 on pg. 245](#).

See [F977](#) for additional information on this parameter.

Direct Access Number — F916

Parameter Type — **Selection List**

Factory Default — **0 (Disabled)**

Changeable During Run — **Yes**

Output Function Assigned

Program ⇒ My Function ⇒ My Function Unit 3

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the **Output Function Assigned** terminal.

This setting assigns the function of the programmable **Output Function Assigned** data location to one of the functions listed in the **Input Setting** field of [Table 10 on pg. 242](#).

Settings:

0 – 3099

See [F977](#) for additional information on this parameter.

Direct Access Number — F917

Parameter Type — **Selection List**

Factory Default — **0 (Disabled)**

Changeable During Run — **Yes**

My Function Percent Data 1

Program ⇒ My Function ⇒ My Function Data

This parameter is used to set the trigger threshold level of the analog signal of the **My Function Percent Data 1**.

The analog signal is selected using the **Input Setting** number from [Table 10 on pg. 242](#).

Once the assigned output value reaches the threshold setting of this parameter the output value is transferred to **My Function Out 1**.

See [F977](#) for additional information on this parameter.

Direct Access Number — F918

Parameter Type — **Numerical**

Factory Default — 0.00

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 200.00

Units — %

My Function Percent Data 2

Program ⇒ My Function ⇒ My Function Data

This parameter is used to set the trigger threshold level of the analog signal of the **My Function Percent Data 2**.

The analog signal is selected using the **Input Setting** number from [Table 10 on pg. 242](#).

Direct Access Number — F919

Parameter Type — **Numerical**

Factory Default — 0.00

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 200.00

Units — %

My Function Percent Data 3

Program ⇒ My Function ⇒ My Function Data

This parameter is used to set the trigger threshold level of the analog signal of the **My Function Percent Data 3**.

The analog signal is selected using the **Input Setting** number from [Table 10 on pg. 242](#).

Direct Access Number — F920

Parameter Type — **Numerical**

Factory Default — 0.00

Changeable During Run — **Yes**

Minimum — 0.00

Maximum — 200.00

Units — %

F921

F926

<p>My Function Percent Data 4</p> <p>Program ⇒ My Function ⇒ My Function Data</p> <p>This parameter is used to set the trigger threshold level of the analog signal of the My Function Percent Data 4.</p> <p>The analog signal is selected using the Input Setting number from Table 10 on pg. 242.</p>	<p>Direct Access Number — F921</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 200.00</p> <p>Units — %</p>
<p>My Function Percent Data 5</p> <p>Program ⇒ My Function ⇒ My Function Data</p> <p>This parameter is used to set the trigger threshold level of the analog signal of the My Function Percent Data 5.</p> <p>The analog signal is selected using the Input Setting number from Table 10 on pg. 242.</p>	<p>Direct Access Number — F922</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 200.00</p> <p>Units — %</p>
<p>My Function Frequency Data 1</p> <p>Program ⇒ My Function ⇒ My Function Data</p> <p>This parameter is used to set the trigger threshold level of the analog signal of the My Function Frequency Data 1.</p> <p>The analog signal is selected using the Input Setting number from Table 10 on pg. 242.</p>	<p>Direct Access Number — F923</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 200.00</p> <p>Units — %</p>
<p>My Function Frequency Data 2</p> <p>Program ⇒ My Function ⇒ My Function Data</p> <p>This parameter is used to set the trigger threshold level of the analog signal of the My Function Frequency Data 2.</p> <p>The analog signal is selected using the Input Setting number from Table 10 on pg. 242.</p>	<p>Direct Access Number — F924</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 200.00</p> <p>Units — %</p>
<p>My Function Frequency Data 3</p> <p>Program ⇒ My Function ⇒ My Function Data</p> <p>This parameter is used to set the trigger threshold level of the analog signal of the My Function Frequency Data 3.</p> <p>The analog signal is selected using the Input Setting number from Table 10 on pg. 242.</p>	<p>Direct Access Number — F925</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 200.00</p> <p>Units — %</p>
<p>My Function Frequency Data 4</p> <p>Program ⇒ My Function ⇒ My Function Data</p> <p>This parameter is used to set the trigger threshold level of the analog signal of the My Function Frequency Data 4.</p> <p>The analog signal is selected using the Input Setting number from Table 10 on pg. 242.</p>	<p>Direct Access Number — F926</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 200.00</p> <p>Units — %</p>

<p>My Function Frequency Data 5</p> <p>Program ⇒ My Function ⇒ My Function Data</p> <p>This parameter is used to set the trigger threshold level of the analog signal of the My Function Frequency Data 5.</p> <p>The analog signal is selected using the Input Setting number from Table 10 on pg. 242.</p>	<p>Direct Access Number — F927</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 200.00</p> <p>Units — %</p>
<p>My Function Time Data 1</p> <p>Program ⇒ My Function ⇒ My Function Data</p> <p>This parameter is used to set the response delay of the My Function Time Data 1 terminal.</p> <p>The applied discrete input signal must be present at the input terminal of the ASD for the time setting here for a system response.</p> <p>Discrete terminal input activation that does not equal or exceed this setting will be ignored.</p>	<p>Direct Access Number — F928</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.01</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.01</p> <p>Maximum — 600.00</p> <p>Units — Seconds</p>
<p>My Function Time Data 2</p> <p>Program ⇒ My Function ⇒ My Function Data</p> <p>This parameter is used to set the response delay of the My Function Time Data 2 terminal.</p> <p>The applied discrete input signal must be present at the input terminal of the ASD for the time setting here for a system response.</p> <p>Discrete terminal input activation that does not equal or exceed this setting will be ignored.</p>	<p>Direct Access Number — F929</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.01</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.01</p> <p>Maximum — 600.00</p> <p>Units — Seconds</p>
<p>My Function Time Data 3</p> <p>Program ⇒ My Function ⇒ My Function Data</p> <p>This parameter is used to set the response delay of the My Function Time Data 3 terminal.</p> <p>The applied discrete input signal must be present at the input terminal of the ASD for the time setting here for a system response.</p> <p>Discrete terminal input activation that does not equal or exceed this setting will be ignored.</p>	<p>Direct Access Number — F930</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.01</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.01</p> <p>Maximum — 600.00</p> <p>Units — Seconds</p>
<p>My Function Time Data 4</p> <p>Program ⇒ My Function ⇒ My Function Data</p> <p>This parameter is used to set the response delay of the My Function Time Data 4 terminal.</p> <p>The applied discrete input signal must be present at the input terminal of the ASD for the time setting here for a system response.</p> <p>Discrete terminal input activation that does not equal or exceed this setting will be ignored.</p>	<p>Direct Access Number — F931</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.01</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.01</p> <p>Maximum — 600.00</p> <p>Units — Seconds</p>

<p>My Function Time Data 5</p> <p>Program ⇒ My Function ⇒ My Function Data</p> <p>This parameter is used to set the response delay of the My Function Time Data 5 terminal.</p> <p>The applied discrete input signal must be present at the input terminal of the ASD for the time setting here for a system response.</p> <p>Discrete terminal input activation that does not equal or exceed this setting will be ignored.</p>	<p>Direct Access Number — F932</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.01</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.01</p> <p>Maximum — 600.00</p> <p>Units — Seconds</p>
<p>My Function Count Data 1</p> <p>Program ⇒ My Function ⇒ My Function Data</p> <p>This parameter is used to set the pulse-count threshold value used to trigger the discrete output COUNT1 (ON Timer).</p> <p>COUNT1 (ON Timer) outputs a 1 upon reaching the threshold setting of this parameter.</p>	<p>Direct Access Number — F933</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 9999</p> <p>Units — Pulses</p>
<p>My Function Count Data 2</p> <p>Program ⇒ My Function ⇒ My Function Data</p> <p>This parameter is used to set the pulse-count threshold value used to trigger the discrete output COUNT2 (ON Timer).</p> <p>COUNT2 (ON Timer) outputs a 1 upon reaching the threshold setting at this parameter.</p>	<p>Direct Access Number — F934</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0</p> <p>Maximum — 9999</p> <p>Units — Pulses</p>
<p>Input Function Target 1</p> <p>Program ⇒ My Function ⇒ My Function Unit 4</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 1 terminal.</p> <p>This setting assigns the function of the programmable Input Function Target 1 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241, Table 10 on pg. 242, or Table 12 on pg. 245.</p> <p>See F977 for additional information on this parameter.</p>	<p>Direct Access Number — F935</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>
<p>Input Function Command 1</p> <p>Program ⇒ My Function ⇒ My Function Unit 4</p> <p>This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function.</p> <p>Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977.</p>	<p>Direct Access Number — F936</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (NOP)</p>

<p>Input Function Target 2</p> <p>Program ⇒ My Function ⇒ My Function Unit 4</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 2 terminal.</p> <p>This setting assigns the function of the programmable Input Function Target 2 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241, Table 10 on pg. 242, or Table 12 on pg. 245.</p> <p>See F977 for additional information on this parameter.</p>	<p>Direct Access Number — F937</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>
<p>Input Function Command 2</p> <p>Program ⇒ My Function ⇒ My Function Unit 4</p> <p>This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function.</p> <p>Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977.</p>	<p>Direct Access Number — F938</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (NOP)</p>
<p>Input Function Target 3</p> <p>Program ⇒ My Function ⇒ My Function Unit 4</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 3 terminal.</p> <p>This setting assigns the function of the programmable Input Function Target 3 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241, Table 10 on pg. 242, or Table 12 on pg. 245.</p> <p>See F977 for additional information on this parameter.</p>	<p>Direct Access Number — F939</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>
<p>Output Function Assigned</p> <p>Program ⇒ My Function ⇒ My Function Unit 4</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the Output Function Assigned terminal.</p> <p>This setting assigns the function of the programmable Output Function Assigned data location to one of the functions listed in the Input Setting field of Table 10 on pg. 242.</p> <p>Settings:</p> <p>0 – 3099</p> <p>See F977 for additional information on this parameter.</p>	<p>Direct Access Number — F940</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>
<p>Input Function Target 1</p> <p>Program ⇒ My Function ⇒ My Function Unit 5</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 1 terminal.</p> <p>This setting assigns the function of the programmable Input Function Target 1 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241, Table 10 on pg. 242, or Table 12 on pg. 245.</p> <p>See F977 for additional information on this parameter.</p>	<p>Direct Access Number — F941</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>

F942

F946

<p>Input Function Command 1</p> <p>Program ⇒ My Function ⇒ My Function Unit 5</p> <p>This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function.</p> <p>Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977.</p>	<p>Direct Access Number — F942</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (NOP)</p>
<p>Input Function Target 2</p> <p>Program ⇒ My Function ⇒ My Function Unit 5</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 2 terminal.</p> <p>This setting assigns the function of the programmable Input Function Target 2 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241, Table 10 on pg. 242, or Table 12 on pg. 245.</p> <p>See F977 for additional information on this parameter.</p>	<p>Direct Access Number — F943</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>
<p>Input Function Command 2</p> <p>Program ⇒ My Function ⇒ My Function Unit 5</p> <p>This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function.</p> <p>Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977.</p>	<p>Direct Access Number — F944</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (NOP)</p>
<p>Input Function Target 3</p> <p>Program ⇒ My Function ⇒ My Function Unit 5</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 3 terminal.</p> <p>This setting assigns the function of the programmable Input Function Target 3 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241, Table 10 on pg. 242, or Table 12 on pg. 245.</p> <p>See F977 for additional information on this parameter.</p>	<p>Direct Access Number — F945</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>
<p>Output Function Assigned</p> <p>Program ⇒ My Function ⇒ My Function Unit 5</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the Output Function Assigned terminal.</p> <p>This setting assigns the function of the programmable Output Function Assigned data location to one of the functions listed in the Input Setting field of Table 10 on pg. 242.</p> <p>Settings:</p> <p>0 – 3099</p> <p>See F977 for additional information on this parameter.</p>	<p>Direct Access Number — F946</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>

<p>Input Function Target 1</p> <p>Program ⇒ My Function ⇒ My Function Unit 6</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 1 terminal.</p> <p>This setting assigns the function of the programmable Input Function Target 1 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241, Table 10 on pg. 242, or Table 12 on pg. 245.</p> <p>See F977 for additional information on this parameter.</p>	<p>Direct Access Number — F947</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>
<p>Input Function Command 1</p> <p>Program ⇒ My Function ⇒ My Function Unit 6</p> <p>This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function.</p> <p>Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977.</p>	<p>Direct Access Number — F948</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (NOP)</p>
<p>Input Function Target 2</p> <p>Program ⇒ My Function ⇒ My Function Unit 6</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 2 terminal.</p> <p>This setting assigns the function of the programmable Input Function Target 2 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241, Table 10 on pg. 242, or Table 12 on pg. 245.</p> <p>See F977 for additional information on this parameter.</p>	<p>Direct Access Number — F949</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>
<p>Input Function Command 2</p> <p>Program ⇒ My Function ⇒ My Function Unit 6</p> <p>This parameter is used to assign a user-selected logical operator to two user-selected Input Function Target variables, enable a counter/timer function, or perform a hold/Reset function.</p> <p>Table 13 on pg. 247 lists the available selections. Their use and selection requirements are described in an example at F977.</p>	<p>Direct Access Number — F950</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (NOP)</p>
<p>Input Function Target 3</p> <p>Program ⇒ My Function ⇒ My Function Unit 6</p> <p>This parameter plays a role in the setup of the My Function feature by selecting the functionality of the programmable Input Function Target 3 terminal.</p> <p>This setting assigns the function of the programmable Input Function Target 3 terminal to any one of the user-selectable functions listed in Table 9 on pg. 241, Table 10 on pg. 242, or Table 12 on pg. 245.</p> <p>See F977 for additional information on this parameter.</p>	<p>Direct Access Number — F951</p> <p>Parameter Type — Selection List</p> <p>Factory Default — 0 (Disabled)</p> <p>Changeable During Run — Yes</p>

F952

F956

Output Function Assigned

Program ⇒ My Function ⇒ My Function Unit 6

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the **Output Function Assigned** terminal.

This setting assigns the function of the programmable **Output Function Assigned** data location to one of the functions listed in the **Input Setting** field of [Table 10 on pg. 242](#).

Settings:

0 – 3099

See [F977](#) for additional information on this parameter.

Direct Access Number — F952

Parameter Type — **Selection List**

Factory Default — **0 (Disabled)**

Changeable During Run — **Yes**

Input Function Target 1

Program ⇒ My Function ⇒ My Function Unit 7

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the programmable **Input Function Target 1** terminal.

This setting assigns the function of the programmable **Input Function Target 1** terminal to any one of the user-selectable functions listed in [Table 9 on pg. 241](#), [Table 10 on pg. 242](#), or [Table 12 on pg. 245](#).

See [F977](#) for additional information on this parameter.

Direct Access Number — F953

Parameter Type — **Selection List**

Factory Default — **0 (Disabled)**

Changeable During Run — **Yes**

Input Function Command 1

Program ⇒ My Function ⇒ My Function Unit 7

This parameter is used to assign a user-selected logical operator to two user-selected **Input Function Target** variables, enable a counter/timer function, or perform a hold/Reset function.

[Table 13 on pg. 247](#) lists the available selections. Their use and selection requirements are described in an example at [F977](#).

Direct Access Number — F954

Parameter Type — **Selection List**

Factory Default — 0 (NOP)

Input Function Target 2

Program ⇒ My Function ⇒ My Function Unit 7

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the programmable **Input Function Target 2** terminal.

This setting assigns the function of the programmable **Input Function Target 2** terminal to any one of the user-selectable functions listed in [Table 9 on pg. 241](#), [Table 10 on pg. 242](#), or [Table 12 on pg. 245](#).

See [F977](#) for additional information on this parameter.

Direct Access Number — F955

Parameter Type — **Selection List**

Factory Default — **0 (Disabled)**

Changeable During Run — **Yes**

Input Function Command 2

Program ⇒ My Function ⇒ My Function Unit 7

This parameter is used to assign a user-selected logical operator to two user-selected **Input Function Target** variables, enable a counter/timer function, or perform a hold/Reset function.

[Table 13 on pg. 247](#) lists the available selections. Their use and selection requirements are described in an example at [F977](#).

Direct Access Number — F956

Parameter Type — **Selection List**

Factory Default — 0 (NOP)

Input Function Target 3

Program ⇒ My Function ⇒ My Function Unit 7

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the programmable **Input Function Target 3** terminal.

This setting assigns the function of the programmable **Input Function Target 3** terminal to any one of the user-selectable functions listed in [Table 9 on pg. 241](#), [Table 10 on pg. 242](#), or [Table 12 on pg. 245](#).

See [F977](#) for additional information on this parameter.

Direct Access Number — F957Parameter Type — **Selection List**Factory Default — **0 (Disabled)**Changeable During Run — **Yes**

Output Function Assigned

Program ⇒ My Function ⇒ My Function Unit 7

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the **Output Function Assigned** terminal.

This setting assigns the function of the programmable **Output Function Assigned** data location to one of the functions listed in the **Input Setting** field of [Table 10 on pg. 242](#).

Settings:

0 – 3099

See [F977](#) for additional information on this parameter.

Direct Access Number — F958Parameter Type — **Selection List**Factory Default — **0 (Disabled)**Changeable During Run — **Yes**

Analog Input Function Target 11

Program ⇒ My Function ⇒ My Function Analog

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the programmable **Analog Input Function Target 11** terminal.

The function selected at [F961](#) may be adjusted using the input analog control signal selected here.

Settings:

- Disabled (None)
- V/I
- RR
- RX
- Optional RX2+, RX2-
- Optional V/I

Direct Access Number — F959Parameter Type — **Selection List**Factory Default — **0 (Disabled)**Changeable During Run — **Yes**

F961

F964

Analog Function Assigned Object 11

Program ⇒ My Function ⇒ My Function Analog

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality to which the adjustment of F959 is applied.

Settings:

- Disabled (None)
- Acceleration Rate
- Upper-Limit Frequency
- Acceleration Multiplication Factor
- Deceleration Multiplication Factor
- Manual Torque Boost
- Over-Current Stall (F601)
- Thermal Protection (F600)
- Speed Loop Proportional Gain (F460)
- Drooping Gain (F320)
- PID Proportional Gain (F362)

Direct Access Number — F961

Parameter Type — **Selection List**

Factory Default — 0 (Disabled)

Changeable During Run — **Yes**

Analog Input Function Target 21

Program ⇒ My Function ⇒ My Function Analog

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality of the programmable **Analog Input Function Target 21** terminal.

The function selected at F964 may be adjusted using the input analog control signal selected here.

Settings:

- Disabled (None)
- V/I
- RR
- RX
- Optional RX2+, RX2-
- Optional V/I

Direct Access Number — F962

Parameter Type — **Selection List**

Factory Default — 0 (Disabled)

Changeable During Run — **Yes**

Analog Function Assigned Object 21

Program ⇒ My Function ⇒ My Function Analog

This parameter plays a role in the setup of the **My Function** feature by selecting the functionality to which the adjustment of F962 is applied.

Settings:

- Disabled (None)
- Acceleration Rate
- Upper-Limit Frequency
- Acceleration Multiplication Factor
- Deceleration Multiplication Factor
- Manual Torque Boost
- Over-Current Stall (F601)
- Thermal Protection (F600)
- Speed Loop Proportional Gain (F460)
- Drooping Gain (F320)
- PID Proportional Gain (F362)

Direct Access Number — F964

Parameter Type — **Selection List**

Factory Default — 0 (Disabled)

Changeable During Run — **Yes**

Monitor Output Function 11

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by establishing the function that is to be recorded and output as the **Peak**, **Minimum**, or **Normal** (Avg.) value as selected at parameter Proportional.

Select the **Monitor Display Input Setting** number from [Table 12 on pg. 245](#) to output the corresponding function.

Use the Communication Number if operating using communications.

Direct Access Number — F965

Parameter Type — **Selection List**

Factory Default — 2000

Changeable During Run — **Yes**

Monitor Output Function Command 11

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by allowing the user to select the **Peak**, **Minimum**, or **Normal** (Avg.) value of the parameter [F965](#) selection to be recorded and output as a monitored function.

Settings:

Normal

Peak

Minimum

Direct Access Number — F966

Parameter Type — **Selection List**

Factory Default — Normal

Changeable During Run — **Yes**

Monitor Output Function 21

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by establishing the function that is to be recorded and output as the **Peak**, **Minimum**, or **Normal** (Avg.) value as selected at parameter [F968](#).

Select the **Monitor Display Input Setting** number from [Table 12 on pg. 245](#) to output the corresponding function.

Use the Communication Number if operating using communications.

Direct Access Number — F967

Parameter Type — **Selection List**

Factory Default — 2000

Changeable During Run — **Yes**

Monitor Output Function Command 21

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by allowing the user to select the **Peak**, **Minimum**, or **Normal** (Avg.) value of the parameter [F967](#) selection to be recorded and output as a monitored function.

Settings:

Normal

Peak

Minimum

Direct Access Number — F968

Parameter Type — **Selection List**

Factory Default — Normal

Changeable During Run — **Yes**

F969

F972

Monitor Output Function 31

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by establishing the function that is to be recorded and output as the **Peak**, **Minimum**, or **Normal** (Avg.) value as selected at parameter F970.

Select the **Monitor Display Input Setting** number from [Table 12 on pg. 245](#) to output the corresponding function.

Use the Communication Number if operating using communications.

Direct Access Number — F969

Parameter Type — **Selection List**

Factory Default — 2000

Changeable During Run — **Yes**

Monitor Output Function Command 31

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by allowing the user to select the **Peak**, **Minimum**, or **Normal** (Avg.) value of the parameter F969 selection to be recorded and output as a monitored function.

Settings:

Normal

Peak

Minimum

Direct Access Number — F970

Parameter Type — **Selection List**

Factory Default — Normal

Changeable During Run — **Yes**

Monitor Output Function 41

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by establishing the function that is to be recorded and output as the **Peak**, **Minimum**, or **Normal** (Avg.) value as selected at parameter F972.

Select the **Monitor Display Input Setting** number from [Table 12 on pg. 245](#) to output the corresponding function.

Use the Communication Number if operating using communications.

Direct Access Number — F971

Parameter Type — **Selection List**

Factory Default — 2000

Changeable During Run — **Yes**

Monitor Output Function Command 41

Program ⇒ My Function ⇒ My Function Monitor

This parameter plays a role in the setup of the **My Function** feature by allowing the user to select the **Peak**, **Minimum**, or **Normal** (Avg.) value of the parameter F971 selection to be recorded and output as a monitored function.

Settings:

Normal

Peak

Minimum

Direct Access Number — F972

Parameter Type — **Selection List**

Factory Default — Normal

Changeable During Run — **Yes**

F973

F976

Virtual Input Terminal Selection 1

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **Virtual Input Terminal 1**. As a virtual terminal, it exists only in memory and is considered to always be in its **True** state (activated).

It is often practical to assign a function to this terminal that the user desires to be maintained regardless of external conditions or operations.

This parameter sets the programmable **Virtual Input Terminal 1** terminal to one of the functions that are listed in [Table 7 on pg. 236](#).

In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.

Direct Access Number — F973

Parameter Type — **Selection List**

Factory Default — **Unassigned**

Changeable During Run — **No**

Virtual Input Terminal Selection 2

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **Virtual Input Terminal 2**. As a virtual terminal, it exists only in memory and is considered to always be in its **True** state (activated).

It is often practical to assign a function to this terminal that the user desires to be maintained regardless of external conditions or operations.

This parameter sets the programmable **Virtual Input Terminal 2** terminal to one of the functions that are listed in [Table 7 on pg. 236](#).

In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.

Direct Access Number — F974

Parameter Type — **Selection List**

Factory Default — **Unassigned**

Changeable During Run — **No**

Virtual Input Terminal Selection 3

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **Virtual Input Terminal 3**. As a virtual terminal, it exists only in memory and is considered to always be in its **True** state (activated).

It is often practical to assign a function to this terminal that the user desires to be maintained regardless of external conditions or operations.

This parameter sets the programmable **Virtual Input Terminal 3** terminal to one of the functions that are listed in [Table 7 on pg. 236](#).

In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.

Direct Access Number — F975

Parameter Type — **Selection List**

Factory Default — **Unassigned**

Changeable During Run — **No**

Virtual Input Terminal Selection 4

Program ⇒ Terminal ⇒ Input Terminals

This parameter is used to set the functionality of the **Virtual Input Terminal 4**. As a virtual terminal, it exists only in memory and is considered to always be in its **True** state (activated).

It is often practical to assign a function to this terminal that the user desires to be maintained regardless of external conditions or operations.

This parameter sets the programmable **Virtual Input Terminal 4** terminal to one of the functions that are listed in [Table 7 on pg. 236](#).

In addition, the input terminal must be specified as **Normally Open** or **Normally Closed**.

Direct Access Number — F976

Parameter Type — **Selection List**

Factory Default — **Unassigned**

Changeable During Run — **No**

My Function Operating Mode

Program ⇒ My Function Selection

This parameter **Enables/Disables** the configured **My Function** feature of the ACE-tronics G9 ASD.

Settings:

- None (Disabled)
- My Function with Terminal Board Signal (ACE G9-120V-PCB)
- My Function Always On

My Function

The **My Function** feature is configured using the settings of **F900** to **F977** and is used to enhance the programmability of the ASD by performing two programmable functions: 1) the Combined Terminal Function, and 2) Logic Operations.

Combined Input Terminal Function

Assigning more than one function to a discrete input terminal provides two advantages: it effectively expands the number of input terminals, and reduces the number of cables required to support the input/output functions (e.g., assigning **Accel/Decel Switching** selections to one terminal). Using **Virtual Terminals 1 – 4** (**F973 – F976**) are required to use this function.

In the example below, the **Accel/Decel Switching 1** terminal assignment and the **Accel/Decel Switching 2** terminal assignment will be combined as one terminal to illustrate this feature. However, any two of the discrete input terminal assignments listed in **Table 7** on **pg. 236** may be combined in this manner.

***Note:** Accel/Decel Switching requires the use of two discrete input terminals to select the user-configured Accel/Decel profiles identified with the binary numbers 1 – 4 (i.e., 00=1_B, 01=2_B, 10=3_B, and 11=4_B).*

Setup (Input Terminal Example)

1. Disable the **My Function** parameter at **F977** to prevent the system from starting upon completion of the setup.
2. Assign the **Accel/Decel Switching 1** function to the **I1** terminal (**F113**).
3. Assign the **Accel/Decel Switching 2** function to **Virtual Input Terminal 1** (**F973**).
4. Set **Input Function Target 1** to **5** (**F900**). This setting assigns **I1** as the control input terminal.
5. Set **Output Function Assigned** to **21** (**F905**). This setting is a command that writes the **F113** selection (I1) to **Virtual Input Terminal 1**, activating both.

(Continued on **pg. 228**)

Direct Access Number — F977

Parameter Type — Selection List

Factory Default — None (Disabled)

Changeable During Run — No



This parameter must always be set to **None** at the start of the **My Function** setup and remain set to **None** until all of the **My Function** parameter settings have been confirmed as being correct.

If enabled for normal operation using settings **1** or **2**, the motor may start and engage the driven equipment unexpectedly upon receiving a **Run** signal during the **My Function** setup.

Combined Input Terminal Function (Cont.)

6. Enable the **My Function** parameter at [F977](#) by selecting **My Function Always On** or selecting **My Function With TB Signal**.

If set to **My Function Always On**, the combination of **Accel/Decel Switching 1** and **Accel/Decel Switching 2** are always On (both are activated during the I1 activation).

If set to **My Function With TB Signal**, set a discrete input terminal to **My Function Run Signal** and activate it to enable **My Function**. Activate **I1** to activate the **Accel/Decel Switching 1** and **Accel/Decel Switching 2** functions. A disconnection at either terminal will terminate the **My Function** programming (discrete input terminal **My Function Run Signal** is Anded with discrete input terminal **I1**).

Activate **I1** and the **Accel/Decel Switching 1** and **Accel/Decel Switching 2** functions will be carried out using only **I1**.

With the aforementioned setup completed, provide a **Frequency Command (F004)** and the motor will run at the commanded frequency.

Combined Output Terminal Function

Output terminals may also be combined to produce one output response to multiple conditions using the computational operators of [Table 13 on pg. 247](#). Assigning more than one function to a discrete output terminal provides two advantages: it effectively expands the number of input terminals, and reduces the number of cables required to support the input/output functions (e.g., assigning Low-Speed Detection and Low-Current Detection to one output terminal). Using **Virtual Terminals 1 – 4 (F973 – F976)** are required to use this function.

In the example below, the **Low Speed Signal** (detection) terminal assignment and the **Low-Current Detection** terminal assignment will be combined as one terminal output to illustrate this feature. However, any two of the discrete output terminal assignments may listed in [Table 10 on pg. 242](#) may be combined in this manner.

Setup (Output Terminal Example)

1. Disable the **My Function** parameter at [F977](#) to prevent the system from starting upon completion of the setup.
2. From Program ⇒ Direct Access ⇒ Unknown Numbers, select **Enabled**.
3. Set the **OUT1** terminal ([F130](#)) to **My Function Output 1 (222)**.
4. Set **Input Function Target 1 (F900)** to **1004** (Low Speed Signal detection). See [Table 10 on pg. 242](#) for a complete listing of available settings.
5. Set **Input Function Target 2 (F902)** to **1026** (Low-Current Alarm). See [Table 10 on pg. 242](#) for a complete listing of available settings.
6. Set **Input Function Command 1 (F901)** to **AND (3)**. This setting assigns an operator to the **Input Function Target 1** and the **Input Function Target 2** settings.
7. Set **Output Function Assigned (F905)** to **1222**. This setting will transfer the results of the logical AND to **My Function Output 1 (OUT1)**.
8. Enable the **My Function** parameter at [F977](#) by selecting **My Function Always On**.

With the aforementioned setup completed in the example, once the **Low Speed Signal** AND the **Low-Current Alarm** are active, the **OUT1** terminal is activated for the duration of the **Low-Speed/Low-Current** condition.

Direct Access Number — F977

Parameter Type — Selection List

Factory Default — None (Disabled)

Changeable During Run — No

**DANGER**

This parameter must always be set to **None** at the start of the **My Function** setup and remain set to **None** until all of the **My Function** parameter settings have been confirmed as being correct.

If enabled for normal operation using settings **1** or **2**, the motor may start and engage the driven equipment unexpectedly upon receiving a **Run** signal during the **My Function** setup.

<p>Traverse Selection (Not Used With the ACE-tronics G9 ASD)</p> <p>Program ⇒ Special ⇒ Traverse</p> <p>This parameter setting is used in the setup of the Traverse control mode of operation and is used in conjunction with the discrete terminal activation of the Traverse Permission Signal.</p> <p>This parameter is used to enable the Traverse function. The Traverse function is activated via the discrete input terminal (see Table 7 on pg. 236).</p> <p>See the <i>Traverse Control Instruction Manual</i> (P/N E6581337) for additional information on this feature.</p> <p>Settings:</p> <ul style="list-style-type: none"> Disabled Enabled 	<p>Direct Access Number — F980</p> <p>Parameter Type — Selection List</p> <p>Factory Default — Disabled</p> <p>Changeable During Run — No</p>
<p>Traverse Acceleration Time (Not Used With the ACE-tronics G9 ASD)</p> <p>Program ⇒ Special ⇒ Traverse</p> <p>This parameter setting is used in the setup of the Traverse control mode of operation. This setting establishes the acceleration rate used during the Traverse function.</p> <p>See the <i>Traverse Control Instruction Manual</i> (P/N E6581337) for additional information on this feature.</p>	<p>Direct Access Number — F981</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 25.0</p> <p>Changeable During Run — No</p> <p>Minimum — 0.1</p> <p>Maximum — 120.0</p> <p>Units — Seconds</p>
<p>Traverse Deceleration Time (Not Used With the ACE-tronics G9 ASD)</p> <p>Program ⇒ Special ⇒ Traverse</p> <p>This parameter setting is used in the setup of the Traverse control mode of operation. This setting establishes the deceleration rate used during the Traverse function.</p> <p>See the <i>Traverse Control Instruction Manual</i> (P/N E6581337) for additional information on this feature.</p>	<p>Direct Access Number — F982</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 25.0</p> <p>Changeable During Run — No</p> <p>Minimum — 0.1</p> <p>Maximum — 120.0</p> <p>Units — Seconds</p>
<p>Traverse Step (Not Used With the ACE-tronics G9 ASD)</p> <p>Program ⇒ Special ⇒ Traverse</p> <p>This parameter setting is used in the setup of the Traverse control mode of operation. This setting is used as a multiplier to establish the amount that the frequency is increased or decreased while using the Traverse function.</p> <p>See the <i>Traverse Control Instruction Manual</i> (P/N E6581337) for additional information on this feature.</p>	<p>Direct Access Number — F983</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 10.0</p> <p>Changeable During Run — No</p> <p>Minimum — 0.0</p> <p>Maximum — 25.0</p> <p>Units — %</p>

F984**F985****Traverse Jump Step (Not Used With the ACE-tronics G9 ASD)**

Program ⇒ Special ⇒ Traverse

This parameter setting is used in the setup of the **Traverse** control mode of operation. This setting is used as a multiplier to establish the amount that the frequency is increased or decreased while using the **Traverse** function when a short burst of rapid speed change is required.

See the *Traverse Control Instruction Manual* (P/N E6581337) for additional information on this feature.

Direct Access Number — F984

Parameter Type — **Numerical**

Factory Default — **10.0**

Changeable During Run — **No**

Minimum — 0.0

Maximum — 50.0

Units — %

Motion Control

Program ⇒ Crane/Hoist ⇒ Motion Control

This parameter sets the axis of motion to be controlled by the ASD.

Settings:

Closed Loop Hoist

Open Loop Hoist (Used During Emergency Lift ONLY)

Main Hoist

Bridge

Rotate

Direct Access Number — F985

Parameter Type — **Selection List**

Factory Default — **Closed Loop Hoist**

Changeable During Run — **No**

Speed Control Mode

Program ⇒ Crane/Hoist ⇒ Speed Control

This parameter setting determines the speed-control method to be used for motor control.

Settings:

Standard (ACE G9) — Normal ASD default settings and operation.

2-Step Variable

Required inputs — **F**, **R**, and **I1** (default via Startup Wizard).

F or **R** — Provides a **Run** command and outputs 6 Hz when activated. Decelerates to zero when deactivated or when both are on.

I1 — Provides a command to accel toward the **Upper-Limit** setting when activated. **Holds** (frequency) when deactivated.

3-Step Variable

Required inputs — **F**, **R**, **I3** (default), and **I4** (default).

F or **R** — Provides a **Run** command and outputs 6 Hz when activated. Decelerates to zero when deactivated or when both are on.

I3 — Provides a command to accel toward the **Upper-Limit** setting when activated.

I4 — Holds the **Run** frequency when activated. Returns to the **Run** command (6 Hz or stop) when deactivated.

5-Speed

Required inputs — **F**, **R**, and **Preset Speeds 1 – 4**.

F or **R** — Provides a **Run** command and outputs 6 Hz when activated. Decelerates to zero when deactivated or when both are on.

I3 – I6 — Sequentially activates **Preset Speeds 1 – 4**. All of the preceding **Preset Speeds** must be active for a given **Preset Speed** to be output from the ASD (i.e., PS1 = PS1, PS1 & PS2 = PS2, PS1 & PS2 & PS3 = PS3, etc.). If not all of the preceding **Preset Speeds** are active, the highest **Preset Speed** number with all of the preceding **Preset Speeds** active will be output from the ASD (i.e., PS1 & PS2 & PS4 = PS2).

2- and 3-Speed

Same as **5-Speed** using only the required number of **Preset Speed** settings.

Unipolar Analog

Required inputs — **F**, **R**, and **RR** input.

F or **R** — Provides a **Run** command and outputs 6 Hz when activated. Decelerates to zero when deactivated or when both are on.

RR — Controls the output speed from the **Lower Limit** to the **Upper Limit**.

Bi-Polar Analog

Required inputs — **F**, **R**, and **RX** input.

F or **R** — Provides a **Run** command and outputs 6 Hz when activated. Decelerates to zero when deactivated or when both are on.

RX — Controls the output speed from the **Lower Limit** to the **Upper Limit** (Forward or Reverse).


Direct Access Number — **F986**

Parameter Type — **Selection List**


Factory Default — **2-Step Variable**

Changeable During Run — **N**

2-Step Variable operation



3-Step Variable operation



Note: *Incorrectly activated discrete input terminals will result in a **Switch Out Of Order Alarm** halting the ASD (e.g., **F** and **R** activated simultaneously when not required).*

To clear this condition, deactivate all discrete input terminals.

F987

F991

<p>Brake-Release Torque Reference</p> <p>Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control</p> <p>This parameter sets the output torque level threshold that must be reached within the time setting of the Brake-Release Torque (Proving) Time (F988) to initiate the Brake Release during normal operation.</p> <p>This setting is also used as a reference during the count-down of the Brake-Release Torque Stable Time.</p> <p>See Figure 32 on pg. 235 for additional information on this parameter.</p>	<p>Direct Access Number — F987</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 100.00</p> <p>Changeable During Run — Yes</p> <p>Minimum — 10.00</p> <p>Maximum — 250.0</p> <p>Units — %</p>
<p>Brake-Release Torque (Proving) Time</p> <p>Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control</p> <p>The output-torque level requirement for the brake-release function must be met before the brake can release.</p> <p>This parameter is used to set a time in which the Brake-Release Torque Reference (F988) criteria must be achieved.</p> <p>See Figure 32 on pg. 235 for additional information on this parameter.</p>	<p>Direct Access Number — F988</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1.0</p> <p>Changeable During Run — No</p> <p>Minimum — 0.5</p> <p>Maximum — 10.0</p> <p>Units — Seconds</p>
<p>Brake-Release Torque Stable Time</p> <p>Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control</p> <p>Once the brake signal is initiated this parameter sets the time that the output torque level must remain at or above the torque level set at F987 before the brake is released.</p> <p>See Figure 32 on pg. 235 for additional information on this parameter.</p>	<p>Direct Access Number — F989</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.20</p> <p>Changeable During Run — Yes</p> <p>Minimum — 0.00</p> <p>Maximum — 2.55</p> <p>Units — Seconds</p>
<p>Brake-Release Mechanical (Delay) Time</p> <p>Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control</p> <p>This parameter sets the time for completing the Brake-Seized Pulse Check (F992).</p> <p>See Figure 32 on pg. 235 for additional information on this parameter.</p>	<p>Direct Access Number — F990</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.75</p> <p>Changeable During Run — No</p> <p>Minimum — 0.00</p> <p>Maximum — 2.50</p> <p>Units — Seconds</p>
<p>Brake-Set Mechanical (Delay) Time</p> <p>Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control</p> <p>Once the brake signal is initiated this parameter sets the time that must elapse before the brake engages.</p> <p>See Figure 32 on pg. 235 for additional information on this parameter.</p>	<p>Direct Access Number — F991</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 0.50</p> <p>Changeable During Run — No</p> <p>Minimum — 0.00</p> <p>Maximum — 2.50</p> <p>Units — Seconds</p>

<p>Brake-Seized Pulse Check Time</p> <p>Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control</p> <p>This parameter sets the time for completing the Brake-Seized Pulse Check. With a forward or reverse signal applied to the motor, a brake that is seized closed will not allow the motor to rotate. To check for this condition, this parameter sets the minimum number of encoder pulses that are expected to occur within the time setting of F990.</p> <p>See Figure 32 on pg. 235 for additional information on this parameter.</p>	<p>Direct Access Number — F992</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 1.00</p> <p>Changeable During Run — No</p> <p>Minimum — 0.00</p> <p>Maximum — 2.50</p> <p>Units — Seconds</p>
<p>Brake-Seized Pulse Check</p> <p>Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control</p> <p>With a forward or reverse signal applied to the motor, a brake that is seized closed will not allow the motor to rotate.</p> <p>To check for this condition, this parameter sets the minimum number of encoder pulses that are expected to occur within the time setting of the Brake-Release Mechanical (Delay) Time (F990) parameter.</p>	<p>Direct Access Number — F993</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 20</p> <p>Changeable During Run — No</p> <p>Minimum — 0</p> <p>Maximum — 1024</p> <p>Units — Pulse</p>
<p>Brake-Failure Pulse Count</p> <p>Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control</p> <p>If while the brake is applied the encoder pulse count reaches this setting within the time setting of the Brake-Release Torque (Proving) Time (F988) setting the system will incur a Brake Failure fault.</p> <p>See Figure 32 on pg. 235 for additional information on this parameter.</p>	<p>Direct Access Number — F994</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 100</p> <p>Changeable During Run — No</p> <p>Minimum — 5</p> <p>Maximum — 100</p> <p>Units — Pulses</p>
<p>Continuous Monitoring Brake-Fail Pulse-Count</p> <p>Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control</p> <p>During normal operation this parameter establishes the maximum number of encoder pulses allowed after the brake is applied before a Brake Failure fault is incurred.</p>	<p>Direct Access Number — F995</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 200</p> <p>Changeable During Run — No</p> <p>Minimum — 0</p> <p>Maximum — 1024</p> <p>Units — Pulses</p>
<p>Maximum Up Speed At Brake Fail</p> <p>Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control</p> <p>In the event of a brake failure this parameter setting is used as the hoist-up speed limit.</p>	<p>Direct Access Number — F996</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 6.00</p> <p>Changeable During Run — No</p> <p>Minimum — 0.00</p> <p>Maximum — 60.0</p> <p>Units — Hz</p>
<p>Load Hover Time</p> <p>Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control</p> <p>This parameter sets the time that the system will hold the load before the brake is applied during a normal stop.</p> <p>See Figure 32 on pg. 235 for additional information on this parameter.</p>	<p>Direct Access Number — F997</p> <p>Parameter Type — Numerical</p> <p>Factory Default — 5.0</p> <p>Changeable During Run — No</p> <p>Minimum — 0.0</p> <p>Maximum — 300.0</p> <p>Units — Seconds</p>

F998**F999****Drooping Pulses Allowed**

Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control

This parameter sets the number of encoder pulses allowed in the opposite direction of the commanded direction before a **Load Drooping** fault occurs.

If commanded to lift (forward) and the load is dropping (reverse or falling), this condition is annunciated via the **Load Drooping** fault and indicates that the requirements of the load are in excess of the capability of the motor.

Direct Access Number — F998

Parameter Type — **Numerical**

Factory Default — **350**

Changeable During Run — **Yes**

Minimum — 2

Maximum — 1024

Units — Pulses

Encoder Error Detection Time

Program ⇒ Crane/Hoist ⇒ Closed Loop Hoist Control

Upon receiving a frequency command, should the motor response be anything other than the commanded frequency for longer than the time set at this parameter, an encoder error is incurred.

See **Figure 32 on pg. 235** for additional information on this parameter.

Direct Access Number — F999

Parameter Type — **Numerical**

Factory Default — **0.50**

Changeable During Run — **No**

Minimum — 0.00

Maximum — 2.55

Units — Seconds

Figure 32. Closed-Loop Hoist Start and Stop Timing Diagrams.




Table 7. Discrete Input Terminal Assignment Selections and Descriptions.

Sel. No.		Terminal Selection Descriptions																					
NO	NC																						
0	1	Unassigned — No operation.																					
2	3	Forward — Provides a Forward run command.																					
4	5	Reverse — Provides a Reverse run command.																					
6	7	Standby — Enables the Forward and Reverse operation commands.																					
8	9	Reset — Resets the device and any active faults.																					
10	11	Preset Speed 1 — Preset Speed 1 is used as the LSB of the 4-bit nibble that is used to select a Preset Speed .																					
12	13	Preset Speed 2 — Preset Speed 2 is used as the second bit of the 4-bit nibble that is used to select a Preset Speed .																					
14	15	Preset Speed 3 — Preset Speed 3 is used as the third bit of the 4-bit nibble that is used to select a Preset Speed .																					
16	17	Preset Speed 4 — Preset Speed 4 is used as the MSB of the 4-bit nibble that is used to select a Preset Speed .																					
18	19	Jog Run — This terminal activates a Jog for the duration of the activation. The Jog settings may be configured at F260 – F262 .																					
20	21	Emergency Off — Terminates the output signal from the ASD and may apply a brake if so configured. The braking method may be selected at F603 .																					
22	23	DC Braking — Upon activation the ASD outputs a DC current that is injected into the windings of the motor to quickly brake the motor.																					
24	25	<p>Accel/Decel Switching 1/Accel/Decel Switching 2 — Activating combinations of discrete input terminals Accel/Decel Switching 1 and 2 allow for the selection of Accel/Decel profiles 1 – 4 as shown below. See F504 for additional information on this terminal setting.</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="2">A/D SW Terminal</th> <th rowspan="2">A/D Profile Selection</th> </tr> <tr> <th>#1</th> <th>#2</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>1</td> </tr> <tr> <td>0</td> <td>1</td> <td>2</td> </tr> <tr> <td>1</td> <td>0</td> <td>3</td> </tr> <tr> <td>1</td> <td>1</td> <td>4</td> </tr> <tr> <td colspan="2">1=Terminal Activated</td> <td></td> </tr> </tbody> </table> <p>The settings of the A/D selections 1 – 4 are performed at F009/F010, F500/F501, F510/F511, and F514/F515, respectively.</p> <p>Accel/Decel profiles are comprised of the Accel/Decel settings, Pattern, and Switching Frequency.</p>		A/D SW Terminal		A/D Profile Selection	#1	#2	0	0	1	0	1	2	1	0	3	1	1	4	1=Terminal Activated		
A/D SW Terminal		A/D Profile Selection																					
#1	#2																						
0	0	1																					
0	1	2																					
1	0	3																					
1	1	4																					
1=Terminal Activated																							
26	27	<p>V/f Switching 1/V/f Switching 2 — Activating combinations of discrete input terminals V/f Switching 1 and 2 allow for the selection of a V/f switching profile as listed below.</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="2">V/f Switching Terminal</th> <th rowspan="2">V/f Selection</th> </tr> <tr> <th>#1</th> <th>#2</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>1</td> </tr> <tr> <td>0</td> <td>1</td> <td>2</td> </tr> <tr> <td>1</td> <td>0</td> <td>3</td> </tr> <tr> <td>1</td> <td>1</td> <td>4</td> </tr> <tr> <td colspan="2">1=Terminal Activated</td> <td></td> </tr> </tbody> </table> <p>The 1–4 settings of the V/f Switching selections are performed at parameters F170 – F181.</p>		V/f Switching Terminal		V/f Selection	#1	#2	0	0	1	0	1	2	1	0	3	1	1	4	1=Terminal Activated		
V/f Switching Terminal		V/f Selection																					
#1	#2																						
0	0	1																					
0	1	2																					
1	0	3																					
1	1	4																					
1=Terminal Activated																							
30	31	<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="2">V/f Switching Terminal</th> <th rowspan="2">V/f Selection</th> </tr> <tr> <th>#1</th> <th>#2</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>1</td> </tr> <tr> <td>0</td> <td>1</td> <td>2</td> </tr> <tr> <td>1</td> <td>0</td> <td>3</td> </tr> <tr> <td>1</td> <td>1</td> <td>4</td> </tr> <tr> <td colspan="2">1=Terminal Activated</td> <td></td> </tr> </tbody> </table>		V/f Switching Terminal		V/f Selection	#1	#2	0	0	1	0	1	2	1	0	3	1	1	4	1=Terminal Activated		
V/f Switching Terminal		V/f Selection																					
#1	#2																						
0	0	1																					
0	1	2																					
1	0	3																					
1	1	4																					
1=Terminal Activated																							
<p><i>Note: NO/NC = Normally Open/Normally Closed. Selection numbers are used when selecting using communications.</i></p>																							

Table 7. (Continued) Discrete Input Terminal Assignment Selections and Descriptions.

Sel. No.		Terminal Selection Descriptions																	
NO	NC																		
32	33	Torque Limit Switching 1/Torque Limit Switching 2 — Activating combinations of discrete input terminals Torque Limit Switching 1 and 2 allow for the selection of a torque limit switching profile as listed below.																	
		<table border="1"> <thead> <tr> <th colspan="2">Torque Limit Switching Terminal</th> <th rowspan="2">Torque Limit Selection</th> </tr> <tr> <th>#1</th> <th>#2</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>1</td> </tr> <tr> <td>0</td> <td>1</td> <td>2</td> </tr> <tr> <td>1</td> <td>0</td> <td>3</td> </tr> <tr> <td>1</td> <td>1</td> <td>4</td> </tr> </tbody> </table>		Torque Limit Switching Terminal		Torque Limit Selection	#1	#2	0	0	1	0	1	2	1	0	3	1	1
Torque Limit Switching Terminal		Torque Limit Selection																	
#1	#2																		
0	0	1																	
0	1	2																	
1	0	3																	
1	1	4																	
34	35	1=Terminal Activated																	
36	37	PID Off — Turns off PID control.																	
38	39	Pattern Operation Group 1 — Initiates the Pattern #1 Pattern Run .																	
40	41	Pattern Operation Group 2 — Initiates the Pattern #2 Pattern Run .																	
42	43	Pattern Operation Continuation — Initiates a continuation of the last Pattern Run from its stopping point.																	
44	45	Pattern Operation Trigger — Initiates the first Preset Speed of a Pattern Run and initiates each subsequent enabled Preset Speed with continued activations.																	
46	47	External Overheat — Causes an Overheat Trip (OH) .																	
48	49	Local Priority (Cancels Serial Priority) — Activation overrides all active serial control and returns the Command and Frequency control to the settings of F003 and F004 for the duration of the activation.																	
50	51	Hold (3-Wire Stop) — Decelerates the motor to a stop.																	
52	53	PID Differentiation/Integration Clear — Clears the PID value.																	
54	55	PID Forward/Reverse Switching — Toggles the gradient characteristic of the feedback response of the V/I terminal during PID -controlled operation.																	
56	57	Forced Continuous Operation — Ignore PID control settings for the duration of activation.																	
58	59	Specified Speed Operation — Runs speed as commanded by the Frequency Mode setting.																	
60	61	Dwell Signal — Used in conjunction with the Acceleration/Deceleration Suspend function (F349) — suspends the Accel/Decel function for the duration of the activation.																	
62	63	Power Failure Synchronized Signal — Activates the Synchronized Accel/Decel function of the Regenerative Power Ridethrough feature. See F302 for additional information on this terminal setting.																	
64	65	My Function Run — Activates the configured My Function feature. See F977 for additional information on this parameter.																	
66	67	Autotuning Signal — Initiates the Autotune function. Set F400 to Autotuning by Input Terminal Signal .																	
68	69	Speed Gain Switching — Toggles the ASD operating mode from and to Speed Control and Torque Control . Speed Control operation references parameter settings F460 and F461 . Torque Control operation references parameter settings F462 and F463 .																	
70	71	Servo Lock — Holds the motor at 0 Hz until a Run command is received.																	
72	73	Simple Positioning — While operating in the Positioning Control mode, activation initiates the Stop command. See F381 for additional information on this terminal setting.																	
74	75	kWH Display Clear — Clears the kWH meter display.																	
76	77	Trace Back Trigger — Initiates the data Read/Store function of the Trace Selection parameter. See F740 for additional information on this feature.																	
78	79	Express-Speed Disable — Terminates the Express Speed operation.																	
<p><i>Note: NO/NC = Normally Open/Normally Closed. Selection numbers are used when selecting using communications.</i></p>																			

Table 7. (Continued) Discrete Input Terminal Assignment Selections and Descriptions.

Sel. No.		Terminal Selection Descriptions
NO	NC	
86	87	Binary Write — Writes the status of the discrete input terminals to the control board during binary input speed control.
88	89	UP/DOWN Frequency (UP) — Increases the speed of the motor for the duration of activation until reaching the Upper-Limit setting or increases the speed of the motor in steps (see F264 for additional information on this feature).
90	91	UP/DOWN Frequency (DOWN) — Decreases the speed of the motor for the duration of activation until reaching the Lower-Limit (F013) setting or decreases the speed of the motor in steps (see F264 for additional information on this feature).
92	93	UP/DOWN Frequency (Clear) — While operating in the UP/DOWN Frequency speed control mode this terminal initiates a 0 Hz output command. If operating with an activated UP/DOWN Frequency (up or down) terminal, the output goes to the Lower-Limit (F013) setting.
98	99	Forward/Reverse — This setting operates in conjunction with another terminal being set to the Run/Stop function. When configured to Run (Run/Stop activated), the activation/deactivation of this terminal changes the direction of the motor.
100	101	Run/Stop — This terminal enables the motor to run when activated and disables the motor when deactivated.
102	103	Commercial Power/ASD Switching — Initiates the ASD-to-Commercial Power switching function. See parameter F354 for additional information on this feature.
104	105	Frequency Reference Priority Switching — Toggles frequency control to and from the settings of F004 and F207.
106	107	V/I Terminal Priority — Assigns Speed control to the V/I Terminal and overrides the F004 setting.
108	109	Command Terminal Board Priority — Assigns Command control to the ACE G9-120V-PCB and overrides the F003 setting.
110	111	Edit Enable — Allows for the override of the lockout parameter setting (F700) allowing for parameter editing.
112	113	Control Switching — Toggles the system to and from the speed control and the torque control modes.
122	123	Fast Deceleration — Using dynamic braking (if enabled and supported), stops the motor at the fastest rate allowed by the load.
124	125	Preliminary Excitation — Applies an excitation current to the motor (holds shaft stationary) for the duration of the activation.
126	127	Brake Request — Initiates the Brake-Release command. This setting requires that another discrete input terminal be set to Brake Answerback Input to complete the Brake-Release command and to convey the status of the braking system to the user or to a dependent subsystem. Once the braking release function is initiated, the Trouble Internal Timer begins to count down (Trouble Internal Timer value is set at F630). Should the count-down timer expire before the brake releases or before the Brake Answerback Input is returned, fault E-11 will occur. Otherwise, the brake releases the motor and normal motor operations resume. The Braking Release function is primarily used at startup; but, may be used when the brake is applied while the motor is running.
130	131	Brake Answerback Input — This setting is required when the Braking Request function is used. The function of this input terminal is to receive the returned the status of the braking system. The returned status is either Released or Not Released . If Released is returned within the time setting of F630, normal system function resumes. If Not Released is returned or if the F630 time setting times out before either signal is returned, then fault E-11 occurs. The returned signal may also be used to notify the user or control a dependent subsystem.
132	133	3-Step-Variable Speed Hold — Holds the run frequency for the duration of the activation.
134	135	Traverse Permission Signal — This feature is not used with the ACE-tronics G9 ASD.
136	137	Slow-Speed Limit-Switch Forward — Activating this terminal applies the modified Upper-Limit Slow Speed setting of F294 and the modified Deceleration setting of parameter F283 for the duration of the activation.
<i>Note: NO/NC = Normally Open/Normally Closed. Selection numbers are used when selecting using communications.</i>		

Table 7. (Continued) Discrete Input Terminal Assignment Selections and Descriptions.

Sel. No.		Terminal Selection Descriptions
NO	NC	
138	139	Stop Limit-Switch Forward — Activating this terminal applies the Stop command. The deceleration rate is set at parameter F284 .
140	141	Slow-Speed Limit-Switch Reverse — Activating this terminal applies the modified Upper-Limit Slow Speed setting of F293 and the modified Deceleration setting of parameter F285 for the duration of the activation.
142	143	Stop Limit-Switch Reverse — Activating this terminal applies the Stop command. The deceleration rate is set at parameter F286 .
144	145	Emergency Lift — Activating this terminal initiates the Emergency-Lift function and continues for the duration of the activation. This feature requires that the Emergency-Lift function be enabled at F656 .
146	147	Timed Run — Activating this terminal outputs the commanded speed (from RR, Communications, etc.) for the duration of the Timed-Run Run-Time setting.
148	149	External Fault — In a multiple ASD configuration a faulted ASD signals the remaining ASDs that a fault has occurred and shuts down the non-faulted ASDs. The non-faulted ASDs receive an External Fault signal via this terminal from the faulted ASD.
150	151	Creep Speed 1 Command — Activating this terminal modifies the output frequency of the ASD by multiplying the commanded frequency by the setting at the Creep Multiplier 1 parameter. The modified output is allowed to run for the number of pulse counts of the Super Creep Pulse Count parameter.
152	153	Creep Speed 2 Command — Activating this terminal modifies the output frequency of the ASD by multiplying the commanded frequency by the setting at the parameter. The modified output is allowed to run for the number of pulse counts of the Super Creep Pulse Count parameter. This setting is ignored if Creep Multiplier #1 is active.
154	155	Brake Failure — This terminal is activated via a transducer in the event that, during closed-loop operation, encoder pulses are detected while the brake is applied.
156	157	Super Creep — Terminal activation rotates the motor for the amount of encoder pulses set at the Super Creep Pulse Count parameter at the frequency setting of Super Creep Speed parameter. Available in closed-loop operation only.
<i>Note: NO/NC = Normally Open/Normally Closed. Selection numbers are used when selecting using communications.</i>		

Table 8. Output Terminal Assignments for the FP, AM, FM, MON1, and MON2 Output Terminals.

Output Meter Terminal Assignments and Display Item Selections			
Selection/ Comm Number	Terminal Assignment Name	Selection/ Comm Number	Terminal Assignment Name
0	Output Frequency	30	100% Meter Adjust Value
1	Frequency Reference	31	Data from Communications
2	Output Current	32	185% Meter Adjust Value
3	DC Bus Voltage	33	250% Meter Adjust Value
4	Output Voltage	34	Input Watt Hour
5	Compensated Frequency	35	Output Watt Hour
6	Speed Feedback (Realtime)	45	Gain Display
7	Speed Feedback (1 Sec Filter)	46	My Function Monitor 1 Without Sign
8	Torque	47	My Function Monitor 2 Without Sign
9	Torque Command	48	My Function Monitor 3 With Sign
11	Torque Current	49	My Function Monitor 4 With Sign (FP End)
12	Excitation Current	50	Signed Output Frequency
13	PID Feedback Value	51	Signed Frequency Reference (Before PI)
14	Motor Overload Ratio	52	Signed Compensated Frequency
15	ASD Overload Ratio	53	Signed Speed Feedback (Realtime)
16	DBR Overload Ratio	54	Signed Speed Feedback (1 Sec Filter)
17	DBR Load Ratio	55	Signed Torque
18	Input Power	56	Signed Torque Command
19	Output Power	58	Signed Torque Current
23	Option V/I Input	59	Signed PID Feedback Value
24	RR Input	60	Signed RX Input
25	V/I Input	61	Signed RX2 Option (AI1) Input
26	RX Input	62	Signed 100% Meter Adjust Value
27	RX2 Option (AI1) Input	63	Signed 185% Meter Adjust Value
28	FM Output	64	Signed 250% Meter Adjust Value
29	AM Output		

Table 9. **My Function** Input Function Target Selections.

Selection/ Communications Number	Terminal Assignment (Physical Terminals Or Memory Locations Where Virtual/Internal)	Selection/ Communications Number	Terminal Assignment (Physical Terminals Or Memory Locations Where Virtual/Internal)
0	Unassigned	17	B12
1	Forward	18	B13
2	Reverse	19	B14
3	Standby	20	B15
4	Reset	21	Virtual Input Terminal 1
5	I1	22	Virtual Input Terminal 2
6	I2	23	Virtual Input Terminal 3
7	I3	24	Virtual Input Terminal 4
8	I4	25	Internal Terminal 1
9	LI1	26	Internal Terminal 2
10	LI2	27	Internal Terminal 3
11	LI3	28	Internal Terminal 4
12	LI4	29	Internal Terminal 5
13	LI5	30	Internal Terminal 6
14	LI6	31	Internal Terminal 7
15	LI7	32	Internal Terminal 8
16	LI8		

Table 10. **My Function** Input Setting (Input Function Target) Assignments, and Parameter/Input Setting Numbers for the **BRAKE-A/B/C, OUT1, OUT2, OUT3–OUT6, and R1–R4** Terminals.

Discrete Output Terminal Assignment Selections (Positive Logic)					
Input Setting	Param. Setting	Function	Input Setting	Param. Setting	Function
1000	0	Lower-Limit Frequency	1074	74	Reverse Speed Limit (Torque Control)
1002	2	Upper-Limit Frequency	1076	76	ASD Healthy Output
1004	4	Low Speed Signal	1078	78	RS485 Communication Error
1006	6	Acceleration/Deceleration Completion	1080	80	Error Code Output 1
1008	8	Speed Reach Signal	1082	82	Error Code Output 2
1010	10	Failure BRAKE (All Trips)	1084	84	Error Code Output 3
1012	12	Failure BRAKE (Except EF, OCL, EPHO, OL2)	1086	86	Error Code Output 4
1014	14	Over-Current (OC) Alarm	1088	88	Error Code Output 5
1016	16	ASD Overload (OL1) Alarm	1090	90	Error Code Output 6
1018	18	Motor Overload (OL2) Alarm	1092	92	Specified Data Output 1
1020	20	Overheat Alarm	1094	94	Specified Data Output 2
1022	22	Over-Voltage Alarm	1096	96	Specified Data Output 3
1024	24	Main Circuit (MOFF) Under-Voltage Alarm	1098	98	Specified Data Output 4
1026	26	Low-Current Alarm	1100	100	Specified Data Output 5
1028	28	Over-Torque Alarm	1102	102	Specified Data Output 6
1030	30	DBR Overload Alarm	1104	104	Specified Data Output 7
1032	32	Emergency Off Active	1106	106	Switch Out Of Sequence
1034	34	Retry Active	1108	108	Heavy Load
1036	36	Pattern Operation Switching Output	1110	110	Positive Torque Limit
1038	38	PID Deviation Limit	1112	112	Negative Torque Limit
1040	40	Run/Stop	1114	114	External Rush Suppression Relay Activated
1042	42	Serious Failure (OCA, OCL, EF, Phase Failure, etc.)	1118	118	Completion of Stop Positioning
1044	44	Light Failure (OL, OC1, 2, 3, OP)	1120	120	L-STOP
1046	46	Commercial Power/ASD Switching Output 1	1122	122	Power Failure Synchronized Operation
1048	48	Commercial Power/ASD Switching Output 2	1124	124	Traverse Active
1050	50	Cooling Fan On/Off	1126	126	Traverse Deceleration Active
1052	52	Jogging Operation Active (Jog Run Active)	1128	128	Part Replacement Alarm
1054	54	Panel/Terminal (Board) Operation Switching	1130	130	Over-Torque Alarm
1056	56	Bearing Greaser Run-Time Alarm	1132	132	Frequency Command ½ Selection
1058	58	ProfiBus/DeviceNet/CC-Link Communication Error	1134	134	Failure BRAKE (Non-Emergency Off)
1060	60	Forward/Reverse Switching	1136	136	External Fault
1062	62	Ready for Operation 1	1138	138	Drooping Fault
1064	64	Ready for Operation 2	1140	140	Run Before Ready
1068	68	Brake Release (BR)	1142	142	Slow-Speed Limit Switch
1070	70	Alarm Status Active	1144	144	Stop Limit-Switch Forward
1072	72	Forward Speed Limit (Torque Control)	1146	146	Slow-Speed Limit Switch

Table 10. (Continued) **My Function** Input Setting (Input Function Target) Assignments, and Parameter/Input Setting Numbers for the **BRAKE-A/B/C**, **OUT1**, **OUT2**, **OUT3–OUT6**, and **R1–R4** Terminals.

Discrete Output Terminal Assignment Selections (Positive Logic)					
1148	148	Stop Speed-Limit Switch	1232	232	My Function Output 6
1150	150	Emergency Lift	1234	234	My Function Output 7
1152	152	Timed Run	1236	236	My Function Output 8
1154	154	Brake Failure	1238	238	My Function Output 9
1156	156	Brake Seized	1240	240	My Function Output 10
1158	158	Slack Rope	1242	242	My Function Output 11
1160	160	Encoder Loss	1244	244	My Function Output 12
1162	162	Fault Stop	1246	246	My Function Output 13
1222	222	My Function Output 1	1248	248	My Function Output 14
1224	224	My Function Output 2	1250	250	My Function Output 15
1226	226	My Function Output 3	1252	252	My Function Output 16
1228	228	My Function Output 4	1254	254	Always Off
1230	230	My Function Output 5			

Table 11. Trace Back Data Selections.

Selection Number	Comm. Number	Trace (Monitor) Function	Resolution/ Unit
0	FD00	Output Frequency	0.01 Hz
1	FD02	Frequency Reference	0.01 Hz
2	FD03	Output Current	0.01%
3	FD04	DC Bus Voltage	0.01%
4	FD05	Output Voltage	0.01%
5	FD15	Compensated Frequency	0.01 Hz
6	FD16	Speed Feedback (Realtime)	0.01 Hz
7	FD17	Speed Feedback (1 Sec Filter)	0.01 Hz
8	FD18	Torque	0.01%
9	FD19	Torque Command	0.01%
11	FD20	Torque Current	0.01%
12	FD21	Excitation Current	0.01%
13	FD22	PID Feedback Value	0.01 Hz
14	FD23	Motor Overload Ratio	0.01%
15	FD24	ASD Overload Ratio	0.01%
16	FD25	DBR Overload Ratio	1%
17	FD28	DBR Load Ratio	1%
18	FD29	Input Power	0.01 kW
19	FD30	Output Power	0.01 kW
23	FE39	V/I Option (AI2)	1%
24	FE35	RR Input	0.01%
25	FE36	V/I Input	0.01%
26	FE37	RX Input	0.01%
27	FE38	RX2 Option (AI1)	1%
28	FE40	FM Output	0.01%
29	FE41	AM Output	0.01%
30	FE51	Signed 100% Meter Adjust Value	1%
31	FA51	Communication Data	N/A
32	FE50	Signed 185% Meter Adjust Value	1%
33	FE67	Signed 250% Meter Adjust Value	1%
34	FE76	Input Watt-Hour	0.01 kWhr
35	FE77	Output Watt-Hour	0.01 kWhr
45	0006/0671	AM/FM Gain Display	1
46	FE60	My Function Monitor 1 (Unsigned Value)	1
47	FE61	My Function Monitor 2 (Unsigned Value)	1
48	FE62	My Function Monitor 3 (Signed Value)	1
49	FE63	My Function Monitor 4 (Signed Value)	1

Table 12. Input Function Target Selections and the Associated Communications Numbers.

Input Setting/Communication Number				Function	Resolution /Unit
AM/FM/FP Input Setting	Comm. Number	Monitor Display Input Setting	Comm. Number		
2000	FD00	3000	FE00	Output Frequency	0.01 Hz
2002	FD02	3002	FE02	Frequency Reference	0.01 Hz
2003	FD03	3003	FE03	Output Current	0.01%
2004	FD04	3004	FE04	DC Bus Voltage	0.01%
2005	FD05	3005	FE05	Output Voltage	0.01%
2015	FD15	3015	FE15	Compensated Frequency	0.01 Hz
2016	FD16	3016	FE16	Speed Feedback (Realtime) <i>(See Note 1)</i>	0.01 Hz
2017	FD17	3017	FE17	Speed Feedback (1 Sec Filter) <i>(See Note 1)</i>	0.01 Hz
2018	FD18	3018	FE18	Torque <i>(See Note 2)</i>	0.01%
2019	FD19	3019	FE19	Torque Command <i>(See Note 2)</i>	0.01%
2020	FD20	3020	FE20	Torque Current <i>(See Note 2)</i>	0.01%
2021	FD21	3021	FE21	Excitation Current	0.01%
2022	FD22	3022	FE22	PID Feedback Value	0.01 Hz
2023	FD23	3023	FE23	Motor Overload Ratio	0.01%
2024	FD24	3024	FE24	ASD Overload Ratio	0.01%
2025	FD25	3025	FE25	DBR Overload Ratio	1%
2028	FD28	3028	FE28	DBR Load Ratio	1%
2029	FD29	3029	FE29	Input Power	0.01 kW
2030	FD30	3030	FE30	Output Power	0.01 kW
		3031	FE31	Pattern Operation Group Number	0.1
		3032	FE32	Pattern Operation Cycles Remaining	1
		3033	FE33	Pattern Operation Preset Speed Number	1
		3034	FE34	Pattern Operation Preset Speed Time Remaining	0.1
2050	FD50			Express-Speed Load Torque Monitor 1	0.01%
2051	FD51			Express-Speed Load Torque Monitor 2	0.01%
		3035	FE35	RR Input	1%
		3036	FE36	V/I Input	1%
		3037	FE37	RX Input <i>(See Note 2)</i>	1%
		3038	FE38	RX2 Option (AI1) Input <i>(See Note 2)</i>	1%
		3039	FE39	RX2 Option (AI1) Input	1%
		3040	FE40	FM Output	1
		3041	FE41	AM Output	1

Note 1: If no PG feedback is used an estimated speed value is displayed.

Note 2: My Function cannot process negative values — A negative value is processed by **My Function** as an absolute value.

Table 12. (Continued) **Input Function Target** Selections and the Associated Communications Numbers.

Input Setting/Communication Number				Function	Resolution /Unit
AM/FM/FP Input Setting	Comm. Number	Monitor Display Input Setting	Comm. Number		
3050	FE50			Communication Data Output 2	
3051	FE51			Communication Data Output 1	
3052	FE52			Communication Data Output 3	
3060	FE60			My Function Monitor 1 (Output of Unsigned Value)	
3061	FE61			My Function Monitor 2 (Output of Unsigned Value)	
3062	FE62			My Function Monitor 3 (Output of Signed Value)	
3063	FE63			My Function Monitor 4 (Output of Signed Value)	
				3066	
		3067	FE67	Expansion I/O Card 2 CPU Version	
		3076	FE76	Integral Input Power	0.01 kW
		3077	FE77	Integral Output Power	0.01 kW
		3084	FE84	16-Bit BIN/BCD Input Value	1
<p>Note 1: If no PG feedback is used an estimated speed value is displayed.</p> <p>Note 2: My Function cannot process negative values — A negative value is processed by My Function as an absolute value.</p>					

Table 13. My Function Operator Selections.

My Function Computational Selections		
Input Function Command	Function Name	Function Description
0	NOP (No Operation)	Disables the My Function feature.
1	ST	Execute data read/transfer.
2	STN	Execute inverted data read/transfer.
3	AND	Logical product of A AND B.
4	ANDN	Logical product of A AND \bar{B} .
5	OR	Logical sum of A OR B.
6	ORN	Logical sum of A OR \bar{B} .
7	EQ	Compares data — Outputs 1 if Equal; 0 if not Equal.
8	NE	Compares data — Outputs 0 if Equal; 1 if not Equal.
9	GT	Compares data — Outputs 1 if $A > B$; 0 if $A \leq B$.
10	GE	Compares data — Outputs 1 if $A \geq B$; 0 if $A < B$.
11	LT	Compares data — Outputs 1 if $A < B$; 0 if $A \geq B$.
12	LE	Compares data — Outputs 1 if $A \leq B$; 0 if $A > B$.
13	ASUB	Outputs absolute difference between A and B — $ A - B $.
14	ON (Timer)	Enables the On response time delay settings of My Function Time Data 1 – 5 (F928 – F932) for My Function Data .
15	Off (Timer)	Enables the Off response time delay settings of My Function Time Data 1 – 5 (F928 – F932) for My Function Data .
16	COUNT1 (Timer)	Outputs a 1 upon reaching the pulse count setting of F933.
17	COUNT2 (Timer)	Outputs a 1 upon reaching the pulse count setting of F934.
18	HOLD	Outputs the peak output value since powering up or since the last reset.
19	SET	Sets data.
20	RESET	Resets data.

Alarms, Trips, and Troubleshooting

Alarms and Trips

This section provides information that assists the user in the event that a **Fault** is incurred.

If a user setting or a ASD parameter has been exceeded, or if a data transfer function produces an unexpected result, a condition that is referred to as a **Fault** is incurred.

An **Alarm** is an indication that a **Fault** is imminent if existing operating conditions continue unchanged. An **Alarm** may be associated with an output terminal to notify the operator of the condition remotely, close a contact, or engage a brake. At the least, an **Alarm** will cause an alarm code to appear on the EOI screen. [Table 14 on pg. 249](#) lists the **Alarm** codes that may be displayed during operation of the ASD.

In the event that the condition that caused the **Alarm** does not return to its normal operating level within a specified time, the ASD **Faults** and a **Trip** is incurred (**Fault** and **Trip** are sometimes used interchangeably).

A **Trip** is a safety feature (the result of a **Fault**) that disables the ASD system and removes the 3-phase power to the motor in the event that a subsystem of the ASD is malfunctioning, or one or more of the variables listed below exceeds its normal range (time and/or magnitude).

- Current,
- Voltage,
- Speed,
- Temperature,
- Torque, or
- Load.

See [Table 15 on pg. 254](#) for a listing of the potential **Trips** and the associated probable causes.

The operating conditions at the time of the trip may be used to help determine the cause of the trip. Listed below are operating conditions that may be used to assist the operator in correcting the problem or that the ASD operator should be prepared to discuss when contacting ACE World Companies Customer Support Center for assistance.

- What trip information is displayed?
- Is this a new installation?
- Has the system ever worked properly and what are the recent modifications (if any)?
- What is the ASD and motor size?
- What is the CPU version and revision level?
- What is the EOI version?
- Does the ASD trip when accelerating, running, decelerating, or when not running?
- Does the ASD reach the commanded frequency?
- Does the ASD trip without the motor attached?
- Does ASD trip with an unloaded motor?

Alarms

Table 14 lists the alarm codes that may be displayed during operation of the ASD. Each alarm code listed is accompanied by a description and a possible cause. In the event that the source of the malfunction cannot be determined, contact your ACE World Companies Customer Support Center for additional information on the condition and for an appropriate course of action.


Table 14. ACE-tronics G9 ASD Alarms.

LCD Screen	LED Screen	Description	Possible Causes
*ASD Overload	OL I	Load requirement in excess of the capability of the ASD.	<ul style="list-style-type: none"> The carrier frequency is too high. An excessive load. Acceleration time is too short. DC damping rate is set too high. The motor is starting into a spinning load after a momentary power failure. The ASD is improperly matched to the application.
Autotuning	Atn	Autotune active.	<ul style="list-style-type: none"> Autotune active.
Brake Failure	brKF	Encoder pulses greater than F994 setting detected while brake is set or during normal operation more pulses than the F995 setting occurred after applying the brake.	<ul style="list-style-type: none"> Brake Failure.
Brake Fault	brF	Encoder pulses received with brake on during torque proving or during continuous brake load-hold.	<ul style="list-style-type: none"> Pulses received from encoder during torque proving. Closed-loop Hoist Mode operation, brake is on with no Run command and encoder pulses are received.
*Brake Resistor Overload	OLr	Excessive current at the Dynamic Braking Resistor .	<ul style="list-style-type: none"> Deceleration time is too short. DBR configuration improperly set.
Brake Seized	brS	No encoder pulses received after brake release with active Run command.	<ul style="list-style-type: none"> Closed-loop Hoist Mode operation, encoder pulses less than the F993 setting received after brake release with an active Run command.
Comm1 Error	EN I	Internal communications error.	<ul style="list-style-type: none"> DeviceNet/Profibus/CC-Link Failure. Improperly programmed ASD. Improper communications settings. Improperly connected cables.
* Reset ignored if active.			

LCD Screen	LED Screen	Description	Possible Causes
Comm2 Error	☐☐☐	External communications error.	<ul style="list-style-type: none"> • RS485 Failure. • Improperly programmed ASD. • Improper communications settings. • Improperly connected cables.
*Control Under-Voltage	☐☐☐☐	Under-voltage condition at the 5, 15, or the 24 VDC supply.	<ul style="list-style-type: none"> • Defective Control board. • Excessive load on power supply. • Low input voltage.
Drooping	☐☐☐☐	Encoder pulses received in excess of F998 setting of the opposite direction of the commanded frequency.	<ul style="list-style-type: none"> • Requirements of the load are in excess of the capability of the motor. • Falling load.
Emergency Lift	☐ ☐☐☐	Hoist-control function switches from closed-loop operation to open-loop operation. Max speed UP = F657. Max speed DOWN = F656.	<ul style="list-style-type: none"> • Encoder feedback signal has been lost and discrete input terminal #144 is activated or F867 is set to Enabled.
External Fault	☐☐☐☐	Non-faulted ASD in a multiple ASD system.	<ul style="list-style-type: none"> • ASD of a multiple ASD system has faulted — the non-faulted ASD(s) incur an External Fault.
Forward Limit Switch	☐☐☐	Forward Limit Switch Activated.	<ul style="list-style-type: none"> • Crane has approached the end-of-travel for the selected operating plane as indicated by the limit switch.
Heavy Load	☐☐☐	Output torque requirement has exceeded the setting of F337.	<ul style="list-style-type: none"> • Load too heavy for motor. • Resets when output torque requirement drops below the setting of F337
Main Under-Voltage	☐☐☐☐	Under-voltage condition at the 3-phase AC input to the ASD.	<ul style="list-style-type: none"> • Low 3-phase utility voltage.
Maintenance Timer	☐☐☐☐	Bearing Greaser Time has expired.	<ul style="list-style-type: none"> • Bearing Greaser Alarm Time setting has expired (F621). • Ambient Average Temperature Time setting has expired (F634).
Motor Overload	☐☐☐☐	Load requirement in excess of the capability of the motor.	<ul style="list-style-type: none"> • V/f parameter improperly set. • Motor is locked. • Continuous operation at low speed. • Load too heavy for motor.
* Reset ignored if active.			

LCD Screen	LED Screen	Description	Possible Causes
MS Relay Off/Soft Start Alarm	⏏FF	Under-voltage condition at the 3-phase AC input to the ASD.	<ul style="list-style-type: none"> • Low 3-phase utility voltage.
Over-Current	⏏	ASD output current greater than F601 setting.	<ul style="list-style-type: none"> • Defective IGBT (U, V, or W). • ASD output to the motor is connected incorrectly. • ASD output phase-to-phase short. • The ASD is starting into a spinning motor. • Motor/machine jammed. • Mechanical brake engaged while the ASD is starting or while running. • Accel/Decel time is too short. • Voltage Boost setting is too high. • Load fluctuations. • ASD operating at an elevated temperature.
*Over-Heat	⏏H	ASD ambient temperature excessive.	<ul style="list-style-type: none"> • ASD is operating at an elevated temperature. • ASD is too close to heat-generating equipment. • Cooling fan vent is obstructed (see Mounting the ASD on pg. 15). • Cooling fan is inoperative. • Internal thermistor is disconnected.
Over-Torque	⏏t	Torque requirement in excess of the setting of F616 or F617 for a time longer than the setting of F618.	<ul style="list-style-type: none"> • ASD is not correctly matched to the application. • F616 or F617 setting is too low. • Obstructed load.
* Reset ignored if active.			

LCD Screen	LED Screen	Description	Possible Causes
*Over-Voltage	OP	DC bus voltage exceeds specifications.	<ul style="list-style-type: none"> ASD attempting to start into a spinning motor after a momentary power loss. Incoming utility power is above the specified range. Decel time is too short. Voltage spikes at the 3-phase input. Inductive filter required. DBR required. DBR resistance value is too high. DBR function is turned off. Over-Voltage Stall feature is turned off. System is regenerating. Load instability. Disable the Ridethrough function (F302).
Pre Over-Torque	POE	Output torque of ASD is greater than 70% of parameter F616 setting.	<ul style="list-style-type: none"> Parameter F616 requires an adjustment. Load requirement exceeds ability of the motor.
Reverse Limit Switch	rLS	Reverse Limit Switch Activated.	<ul style="list-style-type: none"> Crane has approached the end-of-travel for the selected operating plane as indicated by the limit switch.
Run Before Ready	rbr	Run command received at power up or Reset activated while running.	<ul style="list-style-type: none"> F or R terminal on during application of power or system receives a Reset while running.
Slack Rope	SLR	Output torque level is too low.	<ul style="list-style-type: none"> Closed-loop Hoist Mode operation in the reverse direction with F867 enabled, output torque is less than F868 setting for F869 time.
Switch Out Of Sequence	SOF	Run command active during power up or Reset activated while running.	<ul style="list-style-type: none"> Run command active during power up or Reset activated while running.
Timed Run	TRN	Timed Run Active.	<ul style="list-style-type: none"> Timed Run Activated via discrete input terminal. F861 set to a non-zero value.
Cumulative Run Time	CT	Run-time counter exceeded.	<ul style="list-style-type: none"> Type Reset required; select Clear Run Timer.
Torque Proving	TPF	Output torque level is too low.	<ul style="list-style-type: none"> Closed-loop Hoist Mode operation, within F988 time setting the ASD output torque level has not reached the F987 setting or is unable to maintain the F987 setting for F989 time setting during active Run command.
* Reset ignored if active.			

LCD Screen	LED Screen	Description	Possible Causes
Under-Current		With the Low-Current Trip (F610) parameter enabled, the output current of the ASD is below the level defined at F611 and remains there for a time longer than the setting of F612 .	<ul style="list-style-type: none"> • The ASD is improperly matched to the application. • Motor lead disconnected.

Trips/Faults

A **Trip** is an ASD response to a **Fault** (though Fault and Trip are sometimes used interchangeably). A **Trip** is a safety feature that disables the ASD system in the event that a subsystem of the ASD is malfunctioning or a parameter setting has been exceeded.

Listed in [Table 15](#) are the **Faults** that may result in a **Trip** and the possible causes. When a **Trip** is incurred the LCD screen shows the **Fault** screen and the LED screen displays the active **Fault** code.

Table 15. ACE-tronics G9 ASD Fault Listing.

LCD Screen	LED Screen	Possible Causes
Analog Input Loss	E-18	<ul style="list-style-type: none"> V/I signal loss. ACE G9-120V-PCB failure. P24 over-current condition. F633 setting is too high.
Analog Input Over-Voltage	E-19	<ul style="list-style-type: none"> Over-voltage at the V/I, RX, or RR input(s).
ASD Overload	OL1	<ul style="list-style-type: none"> Acceleration time is too short. DC Injection current is too high. Improper V/f setting. Motor running during restart. ASD or the motor is improperly matched to the application.
Autotune Error	EEn	<ul style="list-style-type: none"> Autotune readings that are significantly inconsistent with the configuration information. A non-3-phase motor is being used. Incorrect settings at F400 or F413. Using a motor that has a significantly smaller rating than the ASD. ASD output cabling is too small, too long, or is being housed in a cable tray with other cables that are producing an interfering EMF. Motor is running during the Autotune function.
	EEn1	<ul style="list-style-type: none"> F402 adjustment required (Motor temperature is too high). F410 adjustment required (Motor Constant 1 improperly set).
	EEn2	<ul style="list-style-type: none"> F412 adjustment required (Motor Constant 3 improperly set).
	EEn3	<ul style="list-style-type: none"> Autotune setting F400 is set to Auto Calculation and there is a problem with the Motor Constant readings; F405, F406, and F407.
Brake Sequence Response Error	E-11	<ul style="list-style-type: none"> F630 is set to a non-zero value. Braking sequence discrete input and output terminals are not setup properly.
Communication Error	Err5	<ul style="list-style-type: none"> Communication time out error. Communication malfunction. Improper or loose connection. Improper system settings.

LCD Screen	LED Screen	Possible Causes
Control Power Under-Voltage	UP2	<ul style="list-style-type: none"> This fault is caused by an under-voltage condition at the 5, 15, or the 24 VDC supply. 3-phase input voltage low.
CPU2 Fault	E-26	<ul style="list-style-type: none"> CPU malfunction. Control board malfunction.
CPU Communication Error	E-19	<ul style="list-style-type: none"> CPU data Transmit/Receive error.
CPU Fault	Err4	<ul style="list-style-type: none"> CPU malfunction. Control board malfunction.
CPU Processing Error	E-21	<ul style="list-style-type: none"> Software processed incorrectly. Make service call.
Dynamic Braking Resistor Over-Current	OLr	<ul style="list-style-type: none"> ASD inability to discharge the bus voltage during regeneration. No Dynamic Braking Resistor (DBR) installed. DBR value is too low. Deceleration time is too short. Improper DBR setup information. Defective IGBT7 (or IGBT7 ckt.). 3-phase input voltage is above specification.
Dynamic Braking Resistor Overload	OLr	<ul style="list-style-type: none"> Deceleration time is too short. Improper DBR setup information. Improper Stall setup information.
EEPROM Fault	EEP1	<ul style="list-style-type: none"> EEPROM write malfunction.
EEPROM Read Error	EEP2/EEP3	<ul style="list-style-type: none"> EEPROM read malfunction.
Emergency Off	E	<ul style="list-style-type: none"> Output signal from the ASD is terminated and a brake may be applied if so configured. Stop-Reset pressed twice at the EOI. EOff command received remotely. ASD reset required.
Encoder Signal-Loss Error	E-12	<ul style="list-style-type: none"> ASD is configured to receive a signal from a shaft-mounted encoder and no signal is being received while running. Disconnection at the Encoder circuit. Motor is stopped and is generating torque via torque limit control. ASD is not configured properly.
External Fault	EFLt	<ul style="list-style-type: none"> In a multiple-ASD configuration, this is the fault screen display of an ASD that is not the cause of the fault, but is unable to continue with normal operations.

LCD Screen	LED Screen	Possible Causes
External Overheat	OH2	<ul style="list-style-type: none"> Excessive-heat signature received at the TB3 – TH1(+) and TH1(-) terminals. See F637 for setup information.
Flash Memory Fault	Err9	<ul style="list-style-type: none"> Flash memory malfunction.
Gate Array Fault	Err6	<ul style="list-style-type: none"> Main Gate Array is defective.
Ground Fault	EF 1/EF2	<ul style="list-style-type: none"> Ground fault at the motor. Ground fault at the output of the ASD. Current leakage to Earth Ground.
Input Phase Failure	EPH 1	<ul style="list-style-type: none"> 3-phase input to the ASD is low or missing at the R, S, or T input terminals.
Key Failure	E- 17	<ul style="list-style-type: none"> Same key input for 20 seconds or more.
Logic Input Voltage Error	E-22	<ul style="list-style-type: none"> Incorrect voltage applied to the discrete input terminals.
Low Current	Err 7	<ul style="list-style-type: none"> Improper Low-Current Detection level settings at F609 – F612.
Main Power Under-Voltage	UP 1	<ul style="list-style-type: none"> Input 3-phase voltage is too low. Momentary power failure longer than the time setting of F628.
Motor Overload	OL2	<ul style="list-style-type: none"> Improper V/f setting. Motor is locked. Continuous operation at low speed. Load requirement exceeds ability of the motor. Startup frequency setting adjustment required.
No Errors	nonE	<ul style="list-style-type: none"> No active faults.
Optional Expansion Input Terminal Board 1 Error	E-23	<ul style="list-style-type: none"> Optional Expansion Input Terminal Board 1 is defective.
Optional Expansion Input Terminal Board 2 Error	E-24	<ul style="list-style-type: none"> Optional Expansion Input Terminal Board 2 is defective.
Option Device Fault	Err8	<ul style="list-style-type: none"> Check installation, connections, and option device manual.
Output Phase Failure	EPHO	<ul style="list-style-type: none"> 3-phase output from the ASD is low or missing at the U, V, or W output terminals or at the input to the motor.

LCD Screen	LED Screen	Possible Causes
Over-Current During Acceleration	OC1	<ul style="list-style-type: none"> • Improper V/f setting. • Restart from a momentary power outage. • The ASD is starting into a rotating motor. • ASD/Motor not properly matched. • Phase-to-phase short (U, V, or W). • Accel time too short. • Voltage Boost setting is too high. • Motor/machine jammed. • Mechanical brake engaged while the ASD is running. • ASD current exceeds 340% of the rated FLA on ASDs that are 100 HP or less during acceleration. On ASDs that are greater than 100 HP, this fault occurs when the ASD current exceeds 320% of the rated FLA during acceleration.
Over-Current During Deceleration	OC2	<ul style="list-style-type: none"> • Phase-to-phase short (U, V, or W). • Deceleration time is too short. • Motor/machine jammed. • Mechanical brake engaged while the ASD is running. • ASD current exceeds 340% of the rated FLA on ASDs that are 100 HP or less during deceleration. On ASDs that are greater than 100 HP, it occurs when the ASD current exceeds 320% of the rated FLA during deceleration.
Over-Current During Run	OC3	<ul style="list-style-type: none"> • Load fluctuations. • ASD is operating at an elevated temperature. • ASD current exceeds 340% of the rated FLA on ASDs that are 100 HP or less during a fixed-speed run or if during a fixed-speed run the ASD overheats. On ASDs that are greater than 100 HP, it occurs when the ASD current exceeds 320% of the rated FLA on a fixed-speed run.
Over-Heat	OH	<ul style="list-style-type: none"> • Cooling fan inoperative. • Ventilation openings are obstructed. • Internal thermistor is disconnected.
Overheat During Acceleration	OH IP	<ul style="list-style-type: none"> • Cooling fan inoperative. • Ventilation openings are obstructed. • Internal thermistor is disconnected. • Acceleration time is too short. • Improper V/f setting. • ASD or the motor is improperly matched to the application.

LCD Screen	LED Screen	Possible Causes
Overheat During Deceleration	OC2P	<ul style="list-style-type: none"> Cooling fan inoperative. Ventilation openings are obstructed. Internal thermistor is disconnected. Deceleration time is too short. DC Injection current is too high. ASD or the motor is improperly matched to the application.
Overheat During Run	OC3P	<ul style="list-style-type: none"> Cooling fan inoperative. Ventilation openings are obstructed. Internal thermistor is disconnected. Improper V/f setting. ASD or the motor is improperly matched to the application.
Over-Torque	OT	<ul style="list-style-type: none"> A torque requirement by the load in excess of the setting of F616 or F617 for a time longer than the setting of F618. The ASD is improperly matched to the application. The load is obstructed.
Over-Voltage During Acceleration	OP1	<ul style="list-style-type: none"> Motor running during restart.
Over-Voltage During Deceleration	OP2	<ul style="list-style-type: none"> Deceleration time is too short. DBR value is too high. DBR required (DBR setup required). Stall protection is disabled. 3-phase input voltage is out of specification. Input reactance required.
Over-Voltage During Run	OP3	<ul style="list-style-type: none"> Load fluctuations. 3-Phase input voltage out of specification. DBR required or DBR setup is incomplete.
RAM Fault	Err2	<ul style="list-style-type: none"> Internal RAM malfunction.
ROM Fault	Err3	<ul style="list-style-type: none"> Internal ROM malfunction.
Speed Error	E-13	<ul style="list-style-type: none"> Result of a motor speed that is greater than the commanded speed when using an encoder for speed control. Improper encoder connection or setup information. Defective encoder.
Step Out (for PM Motor Only)	SOUE	<ul style="list-style-type: none"> Motor shaft is locked. Output phase is open. Operating a reciprocating load.

LCD Screen	LED Screen	Possible Causes
Stop Position Retaining Error	E-25	<ul style="list-style-type: none"> • Load movement while stopped. • F381 setting is too low. • Encoder malfunction. • Creep speed is too high.
Torque Proving	EPF	<ul style="list-style-type: none"> • The output torque level setting of F987 was not reached in the time setting of F988 to allow for the brake release.
Typeform Error	EEYP	<ul style="list-style-type: none"> • Firmware information (typeform) loaded into the Gate Driver board is inconsistent with the device in which the firmware is being used. • The Gate Driver board has been replaced. • The Gate Driver board is defective.
U-Phase Over-Current	OCRA1	<ul style="list-style-type: none"> • Internal low impedance at the U lead of the ASD.
U, V, or W Over-Current	OCCL	<ul style="list-style-type: none"> • External low impedance at the U, V, or W lead of the ASD output.
V/f Control Error	E-20	<ul style="list-style-type: none"> • Torque processing error. • Make service call.
V-Phase Over-Current	OCRA2	<ul style="list-style-type: none"> • Internal low impedance at the V lead of the ASD.
W-Phase Over-Current	OCRA3	<ul style="list-style-type: none"> • Internal low impedance at the W lead of the ASD.

Viewing Trip Information

In the event that the condition causing an **Alarm** does not return to the normal operating level within a specified time, the ASD **Faults** and a **Trip** is incurred.

When a **Trip** occurs, the resultant error information may be viewed either from the LED screen, LCD **Fault** screen (Table 15 on pg. 254), **Monitor** screen, or the **Trip History** screen (Program ⇒ Utilities ⇒ **Trip History**).

Trip Record at Monitor Screen

The at-trip condition of the last four incurred trips may be viewed on the **Monitor** screen. The **Monitor** screen displays the records of up to four trips and catalogs each trip as **Past Trip #1** through **Past Trip #4** (see pg. 56). Once reset (Type Reset), the trip records are erased. If no trips have occurred since being powered up or since the last reset, **None** is displayed for each trip record.

The **Monitor** screen at-trip record is erased when the ASD is reset.

***Note:** An improper ASD setup may cause some trips — reset the ASD to the **Factory Default** settings before pursuing a systemic malfunction (Program ⇒ Utilities ⇒ Type Reset ⇒ Reset to Factory Settings).*

Trip History

The **Trip History** screen records the system parameters for up to 20 trips. The recorded trips are numbered from zero to 19. Once the **Trip History** record reaches trip number 19, the oldest recorded trip will be deleted with each new record stored (first-in first-out). The **Trip #** field may be selected and scrolled through to view the recorded trip information for a given trip number. The monitored parameters are listed in Table 16 as **At-Trip Recorded Parameters** (parameter readings at the time that the trip occurred).

Table 16. Trip History Record Parameters.

At-trip Recorded Parameters			
1) Trip Number	8) Frequency Reference	15) Feedback (1 sec.)	22) ASD Overload
2) Trip Type	9) Bus Voltage	16) Torque	23) DBR Overload
3) Time and Date	10) Discrete Input Status	17) Torque Reference	24) Motor Load
4) Frequency at Trip	11) OUT1/OUT2/BRAKE Status	18) Torque Current	25) ASD Load
5) Output Current	12) Timer	19) Excitation Current	26) DBR Load
6) Output Voltage	13) Post Compensation Frequency	20) PID Value	27) Input Power
7) Direction	14) Feedback (inst.)	21) Motor Overload	28) Output Power
Trip records are comprised of the full list of monitored parameters (28).			

Clearing a Trip

Once the cause of the trip has been corrected, performing a **Reset** re-enables the ASD for normal operation.

The trip may also be cleared using either of the following methods:


- Cycling power (trip info may be saved via **F602** if desired),
- Pressing the **Stop-Reset** key twice,
- Remotely via the communications channel,
- Momentarily activating the **RES** terminal of the **ACE G9-120V-PCB**, or
- Via Program ⇒ Utilities ⇒ Type Reset ⇒ **Clear Past Trip** (clears Monitor screen records only).

Enclosure Dimensions and Conduit Plate Information

The part numbering convention is shown below. Use this information for ordering and to identify the ASD typeform.

The enclosure dimensions for the available models (typeforms) are listed in [Tables 17](#) and [18](#). The conduit plates referenced are shown in [Figures 36](#), [37](#), and [38](#).

G9 Part Numbering Convention.



Note: *The Type 1 enclosed versions of these drives meet or exceed the specification **UL 50- 1995, the Standard for Heating and Cooling Equipment**, and complies with the applicable requirements for installation in a compartment handling conditioned air.*

Note: *All ACE-tronics ASD enclosures carry an IP20 rating.*

Enclosure Dimensions

Table 17. 230-Volt ACE-tronics G9 ASD Systems.

Frame	Model Number	Enclosure Figure Number	A Width (in/mm)	B Height (in/mm)	C Depth (in/mm)	Mounting Hole Dimensions (in/mm)				Conduit Plate
						D	E	R1	R2	
2	ACEG92000	Figure 33	5.2/132	11.2/285	6.1/155	8.7/220	4.5/114	0.098/2.5	0.217/5.5	Figure 36-A
	ACEG92001									
	ACEG92002									
3	ACEG92003		6.1/155	12.4/315	6.6/168	9.8/249	5.4/138	0.118/3.0	0.276/7.0	
	ACEG92005									
4	ACEG92007		6.9/175	15.0/381	7.6/193	11.1/283	6.2/158	0.118/3.0	0.276/7.0	
5A	ACEG92010		8.3/211	15.1/384		11.1/283	7.5/190			Figure 36-C
5B	ACEG92015		9.1/231	19.3/490	7.6/193	15.2/386	8.3/210	0.118/3.0	0.276/7.0	Figure 36-D
	ACEG92020									
6	ACEG92025		Figure 34	11.1/283	25.9/658	13.2/335	25.0/635	8.0/203	0.188/4.8	0.375/9.5
7B	ACEG92030	Figure 34	14.3/363	33.1/841	15.0/381	32.3/820	8.0/203	0.188/4.8	0.375/9.5	Figure 37-G
	ACEG92040									
	ACEG92050									
	ACEG92060									
9	ACEG92075	Figure 35	14.6/371	51.7/1313	17.6/447	50.2/1275	9.2/234	0.344/8.7	0.670/17.0	Figure 37-I
10	ACEG92100		15.7/399	53.1/1349		51.7/1313	9.9/252			Figure 37-J

Table 18. 460-Volt ACE-tronics G9 ASD Systems.

Frame	Model Number	Enclosure Figure Number	A Width (in/mm)	B Height (in/mm)	C Depth (in/mm)	Mounting Hole Dimensions (in/mm)				Conduit Plate
						D	E	R1	R2	
2	ACEG94001	Figure 33	5.2/132	11.2/285	6.1/155	8.7/220	4.5/114	0.098/2.5	0.217/5.5	Figure 36-A
	ACEG94002									
	ACEG94003									
3	ACEG94005		6.1/155	12.4/315	6.6/168	9.8/249	5.4/138	0.236/6.0	Figure 36-B	
4	ACEG94007		6.9/175	15.0/381		11.1/283	6.2/158			
	ACEG94010									
5A	ACEG94015		8.3/211	15.1/384	7.6/193		7.5/190	0.118/3.0	0.276/7.0	Figure 36-C
5B	ACEG94020		9.1/231	19.3/490		15.2/386	8.3/210			Figure 36-D
			ACEG94025							
6	ACEG94030		Figure 34	11.1/283	25.9/658	13.2/335	25.0/635	8.0/203	0.188/4.8	0.375/9.5
7A	ACEG94040	30.8/782			14.3/363	29.7/754	Figure 36-F			
	ACEG94050									
8	ACEG94060	Figure 34	14.3/363	36.1/917	15.3/389	35.3/897	8.0/203	0.188/4.8	0.375/9.5	Figure 37-H
	ACEG94075									
	ACEG94100									
9	ACEG94120	Figure 35	14.6/371	51.7/1313	17.6/447	50.2/1275	9.2/234	0.344/8.7	0.670/17	Figure 37-I
10	ACEG94150		15.7/399	53.1/1349		51.7/1313	9.9/252			Figure 37-J
11	ACEG94200		15.0/381	63.1/1603		61.6/1565				Figure 37-K
12	ACEG94250		18.9/480	68.5/1740		67.0/1701	13.8/351			Figure 37-L
13	ACEG94300		25.6/650	70.0/1778		68.5/1740	21.3/541			Figure 38-M
	ACEG94350									

Figure 33. See Table 17 and Table 18 for Actual Dimensions.




Figure 34. See Table 17 and Table 18 for Actual Dimensions.




Figure 35. See Table 17 and Table 18 for Actual Dimensions.




Figure 36. See Table 17 and Table 18 for the Associated Device. Dimensions are in in/cm.

ØX = Concentric Knockouts for Diameter Sizes 0.5", 0.75", and 1.0" Conduit.




Figure 37. See Table 17 and Table 18 for the Associated Device. Dimensions are in in/cm.





Figure 38. See Table 17 and Table 18 for the Associated Device. Dimensions are in in/cm.



Conduit \varnothing = Same as I

M

Current/Voltage Specifications

Table 19. 230-Volt UL Type-1/IP-20 Chassis Standard Ratings Table.

Model Number	Output Current 100/115% Cont. (110% Cont. ≥ 60 HP)	Overload Current 150% for 60 Seconds	Overload Current 150% for 120 Seconds	Input Voltage 3-Ph 50/60 ±2 Hz	Output Voltage 3-Ph Variable Frequency	Typical Motor HP
ACEG92000	3.5/4.0 A	N/A	5.3 A	200–240 VAC (±10%)	Input Voltage Level (Max.)	0.75
ACEG92001	4.2/4.8 A		6.3 A			1.0
ACEG92002	6.9/7.9 A		10.4 A			2.0
ACEG92003	10.0/11.5 A		15.0 A			3.0
ACEG92005	15.2/17.5 A		22.8 A			5.0
ACEG92007	23.8/27.4 A		35.7 A			7.5
ACEG92010	28.6/32.9 A		42.9 A			10
ACEG92015	46.8/53.8 A		70.2 A			15
ACEG92020	57.2/65.8 A		85.8 A			20
ACEG92025	76.3/87.8 A		114.5 A			25
ACEG92030	90.0/103.5 A		135.0 A			30
ACEG92040	104.0/119.6 A		156.0 A			40
ACEG92050	152.5/175.4 A		228.8 A			50
ACEG92060	176.0/193.6 A	264.0 A	N/A	60		
ACEG92075	221.0/243.1 A	331.5 A		75		
ACEG92100	285.0/313.5 A	427.5 A		100		

Table 20. 460-Volt UL Type-1/IP-20 Chassis Standard Ratings Table.

Model Number	Output Current 100/115% Cont. (110% Cont. ≥ 125 HP)	Overload Current 150% for 60 Seconds	Overload Current 150% for 120 Seconds	Input Voltage 3-Ph 50/60 ±2 Hz	Output Voltage 3-Ph Variable Frequency	Typical Motor HP
ACEG94001	2.7/3.1 A	N/A	4.1 A	380 – 480 VAC (±10%)	Input Voltage Level (Max.)	1.0
ACEG94002	3.6/4.1 A		5.4 A			2.0
ACEG94003	5.0/5.8 A		7.5 A			3.0
ACEG94005	9.1/10.5 A		13.7 A			5.0
ACEG94007	12.4/14.3 A		18.6 A			7.5
ACEG94010	15.3/17.6 A		23.0 A			10
ACEG94015	24.0/27.6 A		36.0 A			15
ACEG94020	28.6/32.9 A		42.9 A			20
ACEG94025	35.7/41.1 A		53.6 A			25
ACEG94030	42.0/48.3 A		63.0 A			30
ACEG94040	57.2/65.8 A		85.8 A			40
ACEG94050	68.5/78.8 A		102.8 A			50
ACEG94060	81.5/93.7 A		122.3 A			60
ACEG94075	100.8/115.9 A		151.2 A			75
ACEG94100	138.7/159.5 A	208.1 A	100			
ACEG94120	179/196.9 A	268.5 A	N/A	125		
ACEG94150	215/236.5 A	322.5 A		150		
ACEG94200	259/284.9 A	388.5 A		200		
ACEG94250	314/345.4 A	471.0 A		250		
ACEG94300	387/425.7 A	580.5 A		300		
ACEG94350	427/469.7 A	640.5 A		350		

Cable/Terminal/Torque Specifications

Installation should conform to the 2008 **National Electrical Code Article 110** (NEC) (Requirements for Electrical Installations), all regulations of the Occupational Safety and Health Administration, and any other applicable national, regional, or industry codes and standards.

Note: The following ratings are guidelines and shall not be the sole determining factor of the lug or wire size used with the ACE-tronics G9 ASD. Application-specific applicables, wire insulation type, conductor material, and local and regional regulations are but a few of the considerations when selecting the actual lug and wire type to be used with the ASD.

Note: Cable/Terminal specifications are based on the rated current of the ASD. The specifications **Do Not** include the 10% Service Factor.

Note: Use only 75° C copper wire/cable for motor and power connections.

For additional installation information see the section titled [Installation and Connections](#) on pg. 14.

Table 21. 230-Volt ACE-tronics G9 ASD Cable/Terminal/Torque Specifications.

Model Number	MCP Rating (Amps)	Typical Wire/Cable Size		Lug Size Range		Terminal Board	Torque		
		AWG or kcmil						3Ø-Input	3Ø-Output
		Input/Output Power		Wire-Size/Lug-Capacity for Input/Output Power		TB1 – 4 Terminals			
		Recommended	Maximum	3Ø-Input	3Ø-Output	In-Lbs./Nm			
ACEG92000	15	14	10	14 to 8		20 (3-core shield) 5.3/0.6	11.5/1.3		
ACEG92001									
ACEG92002									
ACEG92003	30	12	8	12 to 8			17.7/2.0		
ACEG92005		10							
ACEG92007	50	8	8	12 to 8			21/2.4		
ACEG92010		6	4	10 to 4					
ACEG92015			75	3	8 to 3				
ACEG92020	100	4	4/0	6 to 250	2 to 300		50/5.7 53/6		
ACEG92025	125	2					2	12 to 1/0 4 to 1/0	
ACEG92030	150	1				6 to 250 2 to 300		275/31 168/19	
ACEG92040	175	1/0							
ACEG92050	200	3/0							
ACEG92060	250	4/0	6 to 250		275/31				
ACEG92075	300	*3/0					*4/0		
ACEG92100	400	*250	*250						

Note: (*) Indicates that the item is one of a set of two parallel cables.

Table 22. 460-Volt ACE-tronics G9 ASD Cable/Terminal/Torque Specifications.

Model Number	MCP Rating (Amps)	Typical Wire/Cable Size		Lug Size Range		Terminal Board	Torque		
		AWG or kcmil						3Ø-Input	3Ø-Output
		Input/Output Power		Wire-Size/Lug-Capacity for Input/Output Power		TB1 – 4 Terminals			
		Recommended	Maximum	3Ø-Input	3Ø-Output	In-Lbs./Nm			
ACEG94001	15	14	10	14 to 8		20 (3-core shield) 5.3/0.6	11.5/1.3		
ACEG94002									
ACEG94003									
ACEG94005									
ACEG94007	20	12	8	12 to 8			17.7/2.0		
ACEG94010		10							
ACEG94015	30	8	4	10 to 4			21/2.4		
ACEG94020		50	6	3	8 to 3				
ACEG94025	75								
ACEG94030	75	4	2	12 to 1/0	4 to 1/0				50/5.7
ACEG94040	100								
ACEG94050		3							
ACEG94060	125	1	4/0	6 to 250	1 to 300		275/31	168/19	
ACEG94075	175	1/0							
ACEG94100	200	3/0							
ACEG94120	250	*1/0	*4/0	6 to 250			275/31		
ACEG94150	300	*2/0	*250						
ACEG94200	400	*4/0							
ACEG94250	500	*250	*350	4 to 350		375/42.4			
ACEG94300	600	**3/0	**350	0 to 500	6 to 350				
ACEG94350	700	**4/0							

Note: (*) Indicates that the item is one of a set of two parallel cables.

Note: (**) Indicates that the item is one of a set of three parallel cables.

Dynamic Braking Resistor Specifications

Thermal protection for the DBR circuit (see [Figure 39. on pg. 275](#)) or an input contactor that will open the 3-phase power input circuit (see [Figure 40. on pg. 275](#)) to the ASD in the event that a DBR over-temperature condition occurs is a requirement. If a DBR failure occurs or should a power source over-voltage condition occur the DBR thermal protection circuitry will prevent hazardous DBR temperatures.

To use the **Dynamic Braking** function the following requirements must be met:

- **Enable** the DBR function.
- Select a **Resistance Value**.
- Set the **Continuous Braking Wattage** value at [F304](#), [F308](#), and [F309](#), respectively.

Set the **Braking Resistance Overload Time** at parameter [F639](#) to establish how long the braking resistor is allowed to sustain the overload condition before a trip is incurred (the factory default setting is 5 seconds).

Light-duty and heavy-duty resistors vary from a few ohms to several hundred ohms. The appropriate resistance size will be typeform-specific and application-specific. Contact the ACE World Companies Customer Support Center for more information on your specific DBR requirements.

Heavy-duty DBRs should be wired using the same gauge wire as the motor leads. Light-duty DBRs may use one wire size smaller (AWG or kcmil) than the motor leads.

Because the heat generated by the DBR will affect the cooling capacity of the heat sink, the resistor pack should be mounted above or to the side of the ASD — **Never below the ASD**. Maintain a minimum of six inches between the resistor pack and the ASD.

The total wire length from the ASD to the DBR should not exceed 10 feet.

The wiring from the ASD to the DBR should be twisted approximately two twists per foot throughout the length of the wire.

If EMI/RFI noise is of concern, the DBR wiring should be 3-core screened cable. The screen should connect to the ASD enclosure and the resistor enclosure.

CAUTION

Though the in-line DBR fuse and the thermal relay are designed into the system to prevent a catastrophic DBR over-current condition, they are both intended to be used as backup protection **ONLY**.

A proper typeform-specific and application-specific system setup that includes using the appropriate **Dynamic Braking Resistor and Overload** settings will be required.

Figure 39. DBR Configurations.





Figure 40. Shown below is a typical connection diagram using an MCCB with a Trip Coil (TC) in lieu of an input contactor. A control transformer is required for 400-Volt models only. The primary MC is opened in the event of a DBR over-current detection. With no power supplied to the ASD the failure will not be displayed on the **EOI**; see the Trip History for failure information once restarted.



Short Circuit Protection Recommendations

Table 23. 230/240 and 400/480-Volt ASD Recommended Circuit Breaker Selection.

Model Number	HP	Continuous Output Current (Amps)	Circuit Breaker Part Number
ACEG92000	0.75	3.5	HLL36015
ACEG92001	1	4.8	HLL36015
ACEG92002	2	8.0	HLL36015
ACEG92003	3	10.0	HLL36025
ACEG92005	5	17.5	HLL36025
ACEG92007	7.5	27.5	HLL36040
ACEG92010	10	33	HLL36050
ACEG92015	15	54	HLL36070
ACEG92020	20	66	HLL36090
ACEG92025	25	76	HLL36100
ACEG92030	30	90	HLL36100
ACEG92040	40	120	HLL36125
ACEG92050	50	152	HLL36150
ACEG92060	60	176	JLL36200
ACEG92075	75	221	JLL36250
ACEG92100	100	285	LIL36300
ACEG94001	1	2.7	Consult NEC
ACEG94002	2	4.1	HLL36015
ACEG94003	3	5.8	HLL36015
ACEG94005	5	10.5	HLL36025
ACEG94007	7.5	14.3	HLL36040
ACEG94010	10	17.6	HLL36050
ACEG94015	15	27.7	HLL36070
ACEG94020	20	33	HLL36090
ACEG94025	25	41	HLL36100
ACEG94030	30	48	HLL36100
ACEG94040	40	66	HLL36125
ACEG94050	50	79	HLL36150
ACEG94060	60	94	JLL36200
ACEG94075	75	116	JLL36225
ACEG94100	100	160	JLL36250
ACEG94120	125	179	LIL36300
ACEG94150	150	215	LIL36300
ACEG94200	200	259	LIL36400
ACEG94250	250	314	LIL36400
ACEG94300	300	387	LIL36450
ACEG94350	350	434	LIL36500

ACE-tronics G9 ASD Optional Devices

The ASD may be equipped with several options which are used to expand the functionality. [Table 24](#) lists the available options and their functions.

Table 24. G9 ASD Optional Devices and Functions.

Part Identifier	Device Name	Device Function
ASD-CAB-USB	G9/G7 USB Communication Cable	Used to connect the ASD to a PC via the PC USB port.
ASD-EOI-HH-G9	Display Module Docking Station	Used to flash the 9-Series display module.
ASD-MTG-KIT9	9-Series EOI Remote Mounting Kit	Hardware used to mount 9-Series ASD EOI remotely.
ASD-TB1-SIM9	ASD Input/Output Signal Simulator	Used to simulate the ASD I/O monitor and control signals.
DEV002Z	DeviceNet Module	Allows the ASD to communicate via DeviceNet with other DeviceNet-supported equipment including a host computer.
ETB003Z	Expansion I/O Board 1	Expands the Input/Output functionality of the ASD.
ETB004Z	Expansion I/O Board 2	Expands the Input/Output functionality of the ASD.
PDP002Z	ProfiBus DP Module	Allows the ASD to communicate via ProfiBus with other ProfiBus-supported equipment including a host computer.
USB001Z	USB-to-Serial Converter	Allows for the USB port of a computer to be used as a communications port for monitoring and controlling the ASD.
VEC007Z	PG Vector Feedback Board	Allows for the use of Vector Control using a sensor (for use with a 5-Volt encoder).
VEC004Z	PG Vector Feedback Board	Allows for the use of Vector Control using a sensor (for use with a 12-Volt encoder).
VEC005Z	PG Vector Feedback Board	Allows for the use of Vector Control using a sensor (for use with a 15-Volt encoder).
VEC006Z	PG Vector Feedback Board	Allows for the use of Vector Control using a sensor (for use with a 24-Volt encoder).
Note: See the user manual of the applicable option for additional information on each item.		

Index

Numerics

0 Hz Command Output, 128
 0 Hz Dead Band Signal, 127
 16-Bit Binary/BCD Input, 91
 24-Volt I/O Terminal Board, 23

A

Abnormal Speed Detection Time, 180
 Abnormal Speed Settings, 65
 Acc/Dec #1 – #4 Settings, 69
 Acc/Dec Pattern 1, 170
 Acc/Dec Pattern 1 – 4, 172
 Acc/Dec Pattern 2, 171
 Acc/Dec Special, 69
 Accel/Decel #1 Settings, 59
 Accel/Decel Operation After Torque Limit, 162
 Accel/Decel Suspend, 147
 Accel/Decel Switching Frequency 1, 172
 Acceleration, 83
 Acceleration Suspend Frequency, 147
 Acceleration Suspend Time, 147
 Acceleration Time 1, 83
 Acceleration Time 2, 168
 Acceleration Time 3, 173
 Acceleration/Deceleration Switching Frequency 2, 174
 Acceleration/Deceleration Switching Frequency 3, 175
 Adding Input Selection, 186
 Add-on Option 1 Error, 256
 AI2, 91
 AI2 (Option V/I) Input Bias, 166
 Alarm Prohibition, 63
 Alarms, 248, 249
 Alternate I/O Terminal Board, 23
 Always ON 1 Terminal 1, 92
 AM, 25, 27
 AM Bias Adjustment, 189
 AM Output, 54
 AM Output Gradient Characteristic, 189
 AM Output Terminal Adjustment, 187
 AM Output Terminal Function, 186
 AM/FM Output, 29
 Analog Filter, 66
 Analog Function Assigned Object 11, 223
 Analog Function Assigned Object 21, 223
 Analog Input, 25
 Analog Input Filter, 112
 Analog Input Function Target 11, 222
 Analog Input Function Target 21, 223

Analog Input Loss, 254
 Analog Input Over-Voltage, 254
 Analog Output, 25
 Analog Output Terminals, 60
 Annual Average Ambient Temperature, 183
 ASD Capacity, 13
 ASD Characteristics, 13
 ASD Disposition at ST Deactivation, 193
 ASD Input Phase Failure Detection, 177
 ASD Load, 54
 ASD Number, 197
 ASD OL (Overload) Trip, 54
 ASD Operation at Disconnect, 205
 ASD Output Phase Failure Detection, 177
 ASD Overload, 54, 182, 254
 ASD/Motor connection diagram, 17
 ASD-side Switching Wait Time, 150
 At-trip Recorded Parameters, 260
 Auto Restart, 138
 Automatic Acceleration/Deceleration, 79
 Automatic Express-Speed Operation Frequency, 145
 Automatic Function Selection, 89
 Automatic Torque Boost, 79
 Autotune Error, 254
 Autotuning, 10
 Autotuning 1, 154
 Autotuning 2, 155

B

Base Frequency 1, 84
 Base Frequency 2, 101
 Base Frequency 3, 102
 Base Frequency 4, 103
 Base Frequency Voltage, 65
 Base Frequency Voltage 1, 155
 Base Frequency Voltage 2, 101
 Base Frequency Voltage 3, 102
 Base Frequency Voltage 4, 103
 Bearing Greaser, 58
 Bearing Greaser (Alarm) Time, 180
 Bearing Greaser Speed Multiplier, 167
 Bezel Mounting Hardware, 37
 BIN Input Point 1 Frequency, 124
 BIN Input Point 1 Setting, 123
 BIN Input Point 2 Frequency, 124
 BIN Input Point 2 Setting, 124
 Block Read Data 1, 209
 Block Read Data 2, 209
 Block Read Data 3, 209

Block Read Data 4, 210
 Block Read Data 5, 210
 Block Write Data 1, 208
 Block Write Data 2, 208
 BRAKE A, B, and C switching relationship, 28
 Brake Answer Wait Time, 182
 BRAKE Output, 29
 Brake Release Mechanical (Delay) Time, 232
 Brake Sequence Response Error, 254
 Brake-Release Torque (Proving) Time, 232
 Brake-Release Torque Reference, 232
 Brake-Release Torque Stable Time, 232
 Brake-Seized Pulse Check Time, 233
 Brake-Set Mechanical (Delay) Time, 232
 Braking Resistance Overload Time (10x rated torque),
 184

C

Cable/Terminal Specifications, 272
 Carrier Frequency, 69
 Carrier Frequency Control Mode, 142
 CC, 25
 Change Password, 78
 Change Step Selection 1, 192
 Change Step Selection 2, 192
 Changed From Default, 40, 64
 Changed From Default screen, 41
 Charge LED, 9, 16
 Circuit breaker configuration, 15
 Circuit Breaker Part Number, 276
 Clearing a Trip, 260
 Clock Setup, 63
 Closed Loop Hoist Control, 58
 CM1, 249
 CM2, 250
 Command Control Selections, 50
 Command Mode, 80
 Command Mode and Frequency Mode Control, 47
 Commercial Power Switching Freq. Hold Time, 150
 Commercial Power Switching Wait Time, 150
 Commercial Power/ASD Output Switching, 149
 Commercial Power/ASD Switching Frequency, 150
 Communication Adjustments, 76
 Communication Error, 254
 Communication Settings, 76
 Communications, 76
 Communications Option (DeviceNet/Profibus) Setting
 1, 202
 Communications Option (DeviceNet/Profibus) Setting
 2, 203
 Communications Option (DeviceNet/Profibus) Setting
 8, 204

Communications Option Speed Switch Monitor
 DeviceNet/CC-Link, 206
 Communications Option Station Address Monitor, 205
 Communications setting changes, 41
 Compensation Frequency, 54
 Conduit Plate Information, 261
 Connecting the ASD, 16
 Connection Diagram, 30
 Continuous Dynamic Braking Capacity, 141
 Continuous Monitoring Brake-Fail Pulse-Count, 233
 Contrast, 64
 Control Power Under-Voltage, 255
 Cooling Fan Control, 180
 CPU Fault, 255
 CRANE / HOIST, 57
 Crane/Hoist Settings, 69
 Creep Control, 57
 Creep Multiplier 1, 167
 Creep Multiplier 2, 167
 Creep Speed Lower Limit, 167
 Current Control Proportional Gain, 163
 Current/Voltage Specifications, 270
 Current/Voltage Units Setup, 191

D

DBR Load, 55
 DBR OL (Overload) Trip, 55
 DBR over-current, 275
 DBR Overload, 54
 DC (Injection) Braking Current, 127
 DC (Injection) Braking Start Frequency, 127
 DC (Injection) Braking Time, 128
 DC Bus Voltage, 54
 DC Injection Braking, 65
 DC Output, 25
 Deceleration Suspend Frequency, 148
 Deceleration Suspend Time, 148
 Deceleration Time 1, 83
 Deceleration Time 2, 169
 Default Setting Changes, 40
 Direct Access, 62
 Disconnection Detection Extended Time, 205
 Discrete Input, 25, 29
 Discrete Input Terminal Assignment, 236
 Discrete Input Terminals, 56
 Discrete Output, 25
 Display Bias, 192
 Display Parameters, 62
 Disposal, 3
 Drooping, 143
 Drooping Control, 73
 Drooping Gain, 143

Drooping Insensitive Torque, 144
 Drooping Output Filter, 144
 Drooping Pulses Allowed, 234
 Dynamic, 161
 Dynamic Braking, 65, 140, 161
 Dynamic Braking Resistance, 141
 Dynamic Braking Resistor Over-Current, 255
 Dynamic Braking Resistor Overload, 255
 Dynamic Braking Stall Prevention Mode, 163
 Dynamic Braking Torque Limit 1, 161
 Dynamic Braking Torque Limit 1 Level, 161
 Dynamic Braking Torque Limit 2 Level, 161
 Dynamic Braking Torque Limit 3 Level, 162
 Dynamic Braking Torque Limit 4 Level, 162

E

E, 255
 E-11, 254
 E-12, 255
 E-13, 258
 E-17, 256
 E-18, 254
 E-19, 255
 E-20, 259
 E-21, 255
 E-22, 256
 E-23, 256
 E-24, 256
 E-25, 259
 E-26, 255
 EEP1, 255
 EEP2, 255
 EEP3, 255
 EEPROM Data Fault, 255
 EEPROM Fault, 255
 EF1, 256
 EF2, 256
 Electronic Operator Interface, 32
 Electronic Operator Interface features, 33
 Emergency Lift, 59, 185
 Emergency Off, 34
 Emergency Off DC Injection Application Time, 176
 Emergency Off Mode Settings, 176
 Emergency Off Settings, 65
 Emergency-Lift Lower Speed Limit, 185
 Emergency-Lift Maximum Speed, 185
 Emergency-Lift Torque Compare Time, 185
 Enclosure Dimensions, 261
 Encoder Error Detection Time, 234
 End Frequency, 127
 EOI Command Mode, 53
 EOI Installation Precautions, 37
 EOI Operation, 32
 EOI Remote Mounting, 32, 37
 EOI Remote Mounting using the ASD-MTG-KIT, 39
 EOI Remote Mounting w/o the ASD-MTG-KIT, 38
 EPHI, 256
 EPHO, 256
 Equipment Inspection, 3
 ERR2, 258
 ERR3, 258
 ERR4, 255
 ERR5, 254
 ERR6, 256
 ERR7, 256
 ERR8, 256
 ERR9, 256
 ESC Key, 33
 Ethernet, 78
 ETN, 254
 ETN1, 254
 ETN2, 254
 ETN3, 254
 ETYP, 259
 Excitation Current, 55
 Exciting Strengthening Coefficient, 156
 Express Speed, 58
 Express Stop, 57, 167
 Express Stop Acceleration/Deceleration Pattern, 174
 Express Stop Decel Time, 174
 Express-Speed Learning Function, 145
 Express-Speed Operation Detection Time, 146
 Express-Speed Operation Heavy-Load Detection Time, 146
 Express-Speed Operation Load Wait Time, 145
 Express-Speed Operation Switching Lower-Limit Frequency, 145
 Express-Speed Selection, 144
 Extender Cables, 37
 External Fault, 59
 External Fault Stopping Method, 135
 External Over-Heat, 256

F

F, 26
 Fan Control, 180
 Fault, 248
 Faults, 248

Feedback, 73
 Feedback (1 second), 55
 Feedback (inst), 55
 Feedback Settings, 73
 FLA, 27
 Flash Memory Fault, 256
 FM, 25, 27
 FM Bias Adjustment, 189
 FM Output, 54
 FM Output Gradient Characteristic, 189
 FM Output Terminal Adjustment, 81
 FM Output Terminal Function, 81
 FM Voltage/Current Output Switching, 189
 FMOD, 107
 Forward Run/Reverse Run Disable, 142
 Forward Speed Limit Input, 158
 Forward Speed Limit Level, 158
 Forward/Reverse DC Injection Braking Priority, 128
 Forward/Reverse Disable, 67
 Forward/Reverse Run Selection, 82
 FP, 25, 27
 FP Output, 29
 FP Terminal Pulse Output Function, 188
 Free Notes, 210
 Free Unit, 191
 Free Unit Display Gradient Characteristic, 192
 Free Unit Multiplication Factor, 191
 Frequency, 66
 Frequency at Trip, 54
 Frequency Command Mode, 52
 Frequency Command Screen, 35, 40
 Frequency Control, 70
 Frequency Control Selections, 50
 Frequency Mode 1, 80
 Frequency Mode 2, 111
 Frequency Mode Control, 47
 Frequency Mode Priority Switching Frequency, 111
 Frequency Point Selection, 199
 Frequency Priority Selection, 107
 Frequency Reference, 54
 Frequency Setting, 52
 Frequency Settings, 59
 Fundamental, 59

G

G9 Optional Devices, 277
 G9 Part Numbering Convention, 261
 Gate Array Fault, 256
 General Safety Information, 1
 Grounding Capacitor Switch, 5

H

Handling and Storage, 3
 Heavy-Load Torque During Fixed-Speed Power Running, 146
 Heavy-Load Torque During Power Running, 146

I

I/O Circuit Configurations, 29
 I1, 26
 I2, 26
 I3, 26
 I4, 26
 I5, 26
 I6, 26
 II function, 110
 IICC, 25, 30, 108, 110
 Initial UP/DOWN Frequency, 132
 Initial UP/DOWN Frequency Rewriting, 132
 Input Function Command 1, 210, 212, 213, 217, 219, 220, 221
 Input Function Command 2, 211, 212, 213, 218, 219, 220, 221
 Input Function Target 1, 210, 212, 213, 217, 218, 220, 221
 Input Function Target 2, 211, 212, 213, 218, 219, 220, 221
 Input Function Target 3, 211, 212, 214, 218, 219, 220, 222
 Input Phase Failure, 256
 Input Phase Failure Detection, 177
 Input Power, 55
 Input Special Functions, 60
 Input Terminal 1 (F) Function, 92
 Input Terminal 1 (F) Response Time, 99
 Input Terminal 10 (LI2) Function, 94
 Input Terminal 11 (LI3) Function, 94
 Input Terminal 12 (LI4) Function, 94
 Input Terminal 13 – 20 Response Time, 100
 Input Terminal 13 (LI5) Function, 95
 Input Terminal 14 (LI6) Function, 95
 Input Terminal 15 (LI7) Function, 95
 Input Terminal 16 (LI8) Function, 96
 Input Terminal 17 (B12) Function, 100
 Input Terminal 18 (B13) Function, 100
 Input Terminal 19 (B14) Function, 100
 Input Terminal 2 (R) Function, 92
 Input Terminal 2 (R) Response Time, 99
 Input Terminal 20 (B15) Function, 100
 Input Terminal 3 (I1) Function, 92
 Input Terminal 3 (ST) Response Time, 99
 Input Terminal 4 (I2) Function, 92

Input Terminal 4 (RES) Response Time, 99
 Input Terminal 5 – 12 Response Time, 99
 Input Terminal 5 (I3) Function, 93
 Input Terminal 6 (I4) Function, 93
 Input Terminal 7 (I5) Function, 93
 Input Terminal 8 (I6) Function, 93
 Input Terminal 9 (LI1) Function, 93
 Input Terminal Delays, 60
 Input Terminal Priority, 90
 Input Terminals, 61
 Installation and Connections, 14
 Installation Notes, 14
 Installation Precautions, 4
 isolated V/I input, 108

J

Jog Run Frequency, 129
 Jog Settings, 67
 Jog Stop Pattern, 130
 Jump Frequencies, 70
 Jump Frequency 1, 133
 Jump Frequency 1 Bandwidth, 134
 Jump Frequency 2, 134
 Jump Frequency 2 Bandwidth, 134
 Jump Frequency 3, 134
 Jump Frequency 3 Bandwidth, 134, 231, 233

K

Key Failure, 256
 Keypad ASD-MTG-KIT Dimensions (mounting), 39

L

L1, 17
 L2, 17
 L3, 17
 LCD Character Information, 34
 LCD Display, 33
 LCD Screen, 34, 35
 LCD Screen Installation Note, 36
 Lead Length Specifications, 20
 LED Character/Font Information, 34
 LED Display, 33
 LED Screen, 34
 LED/LCD Screen Information, 34
 LED/LCD Screen Installation Note, 36
 Light Load Conditions, 11

Limit-Switch Control, 57
 Limit-Switch Stopping Method, 135
 Line Power Switching, 61
 Linear acceleration, 170
 Load Hover Time, 233
 Load Moment of Inertia 1, 163
 Load Moment of Inertia 2, 164
 Load Sharing Gain Input, 158
 Load-produced Negative Torque, 12
 Local mode, 33
 Local|Remote Key, 33
 Lockouts, 78
 Low Current, 256
 Low Current Settings, 65
 Low-Current Detection Current Hysteresis Width, 178
 Low-Current Detection Threshold, 178
 Low-Current Trip, 178
 Low-Current Trip Threshold Time, 178
 Lower-Limit Frequency, 84
 Lower-Limit Slow Speed, 137
 Low-Speed Operation, 10
 Low-Speed Signal Output Frequency, 90
 Lug Size, 272

M

Main Monitor Selections, 56, 65
 Main Power Under-Voltage, 256
 Manual Torque Boost 1, 85
 Manual Torque Boost 2, 101
 Manual Torque Boost 3, 102
 Manual Torque Boost 4, 103
 Manual Torque Limit Settings, 72
 Maximum Frequency, 84
 Maximum Up Speed At Brake Fail, 233
 MCP Rating, 272
 Mode Key, 33
 MOFF, 250
 MON 1 Bias Adjustment, 190
 MON 1 Output Gradient Characteristic, 190
 MON 1 Voltage/Current Output Switching, 190
 MON 2 Bias Adjustment, 191
 MON 2 Output Gradient Characteristic, 190
 MON 2 Voltage/Current Output Switching, 190
 MON1 Terminal Adjustment, 187
 MON1 Terminal Meter Selection, 187
 MON2 Terminal Adjustment, 188
 MON2 Terminal Meter Selection, 188
 Monitor Mode, 54
 Monitor Output Function 11, 224

Monitor Output Function 21, 224
 Monitor Output Function 31, 225
 Monitor Output Function 41, 225
 Monitor Output Function Command 11, 224
 Monitor Output Function Command 21, 224
 Monitor Output Function Command 31, 225
 Monitor Output Function Command 41, 225
 Monitor Screen, 35
 Motion Control, 57, 230
 Motor, 71
 Motor 150% Overload Time Limit, 177
 Motor Braking, 12
 Motor Capacity, 44
 Motor Characteristics, 10
 Motor connection diagram, 17
 Motor Constant 1, 156
 Motor Constant 2, 156
 Motor Constant 3, 156
 Motor Constant 4, 156
 Motor Load, 54
 Motor OL (Overload) Trip, 54
 Motor Overload, 256
 Motor Overload Protection Configuration, 86
 Motor Overload Protection Level 1, 175
 Motor Overload Protection Level 2, 102
 Motor Overload Protection Level 3, 103
 Motor Overload Protection Level 4, 104
 Motor Overload Real, 54
 Motor Rated Capacity, 155
 Motor Rated Current, 155
 Motor Rated RPM, 155
 Motor Set #1, 59
 Motor Set #2, 71
 Motor Set #3, 71
 Motor Set #4, 71
 Motor Shaft Fixing Control, 128
 Motor/Load Combinations, 11
 Mounting the ASD, 15
 Multiplying Input Selection, 186
 My Function, 74
 My Function Analog, 76
 My Function Count Data 1, 217
 My Function Count Data 2, 217
 My Function Data, 75
 My Function Frequency Data 1, 215
 My Function Frequency Data 2, 215
 My Function Frequency Data 3, 215
 My Function Frequency Data 4, 215
 My Function Frequency Data 5, 216
 My Function Monitor, 76
 My Function Percent Data 1, 214
 My Function Percent Data 3, 214
 My Function Percent Data 4, 215
 My Function Percent Data 5, 215

My Function Selection, 74, 227
 My Function Time Data 1, 216
 My Function Time Data 2, 216
 My Function Time Data 3, 216
 My Function Time Data 4, 216
 My Function Time Data 5, 217
 My Function Unit 1, 74

N

Network Option Reset Settings, 210
 No-Load (Torque) Detection Time, 207
 No-Load Torque, 207
 NONE, 256
 Number of PG Input Phases, 153
 Number of PG Input Pulses, 153
 Number of Times to Retry, 139

O

OC, 251
 OC1, 257
 OC1P, 257
 OC2, 257
 OC2P, 258
 OC3, 257
 OC3P, 258
 OCA1, 259
 OCA2, 259
 OCA3, 259
 OCR, 255
 OH, 251, 257
 OH2, 256
 OJ, 252
 OL1, 254
 OL2, 256
 OLI, 249
 OLM, 250
 OLR, 249, 255
 OP, 252
 OP1, 258
 OP2, 258
 OP3, 258
 Operation (Local), 40
 Operation Above 60 Hz, 10
 Operation Panel Parameters, 70
 Operational and Maintenance Precautions, 9
 Option V/I Terminal Voltage/Current Selection, 91
 Options, 277
 OT, 251, 258
 OUT1, 27
 Out1 Out2 BRAKE, 56

OUT1/OUT2 Output, 29
 OUT2, 27
 Output Current, 54
 output disconnect, 8
 Output Function Assigned, 211, 213, 214, 218, 219, 221, 222
 Output Phase Failure, 256
 Output Phase Failure Detection, 177
 Output Power, 55
 Output Terminal 1 (OUT1) Function, 96
 Output Terminal 10 (R3) Function, 101
 Output Terminal 11 (R4) Function, 101
 Output Terminal 2 (OUT2) Function, 96
 Output Terminal 3 (BRAKE) Function, 96
 Output Terminal 4 (OUT3) Function, 97
 Output Terminal 5 (OUT4) Function, 97
 Output Terminal 6 (R1) Function, 97
 Output Terminal 7 (OUT5) Function, 98
 Output Terminal 8 (OUT6) Function, 98
 Output Terminal 9 (R2) Function, 98
 Output Terminals, 62
 Output Voltage, 54
 Over-Current, 251
 Over-Current During Acceleration, 257
 Over-Current During Deceleration, 257
 Over-Current During Run, 257
 Over-Current Protection, 13
 Over-Heat, 251, 257
 Over-Heat During Acceleration, 257
 Over-Heat During Deceleration, 258
 Over-Heat During Run, 258
 Overload, 65
 Overload Protection, 10
 Overload Reduction Starting Frequency, 177
 Override Control, 73
 Override mode, 49
 Override Operation, 49
 Over-Speed Detection Frequency Lower Band, 180
 Over-Speed Detection Frequency Upper Band, 180
 Over-Torque, 251, 258
 Over-Torque Detection Hysteresis, 179
 Over-Torque Detection Level (Negative Torque), 179
 Over-Torque Detection Level (Positive Torque), 179
 Over-Torque Detection Time, 179
 Over-Torque Parameters, 66
 Over-Torque Trip, 179
 Over-Voltage, 252
 Over-Voltage During Acceleration, 258
 Over-Voltage During Deceleration, 258
 Over-Voltage During Run, 258
 Over-Voltage Limit Operation, 140

Over-Voltage Limit Operation Level, 181

P

P24, 27
 P24 Output, 29
 PA/+, 16
 Panel Load Sharing Gain, 194
 Panel Operation Jog Mode, 130
 Panel Override Multiplication Gain, 194
 Panel Stop Pattern, 193
 Panel Tension Torque Bias, 194
 Panel Torque Command, 193
 Parameter Write Lockout, 191
 Password, 78
 Password and Lockout, 78
 Past Trip #1, 56
 Past Trip #2, 56
 Past Trip #3, 56
 Past Trip #4, 56
 Pattern Cycle Number, 55
 Pattern Group Number, 55
 Pattern Preset, 55
 Pattern Time, 55
 PC/-, 16
 Permanent Magnet (PM) Motor Constant 2, 168
 PG Disconnection Detection, 154
 PG Input Point 1 Frequency, 125
 PG Input Point 1 Setting, 125
 PG Input Point 2 Frequency, 126
 PG Input Point 2 Setting, 126
 PG Settings, 73
 Phase Loss, 66
 PID Control Switching, 150
 PID Control Wait Time, 152
 PID Deviation Lower Limit, 152
 PID Deviation Upper Limit, 151
 PID Feedback, 55
 PID Feedback Delay Filter, 151
 PID Feedback Differential (D) Gain, 152
 PID Feedback Integral (I) Gain, 151
 PID Feedback Proportional (P) Gain, 151
 PID Feedback Signal, 151
 PID Output Lower Limit, 153
 PID Output Upper Limit, 152
 Plugging, 57, 168
 Plugging Acceleration Time, 174
 Plugging Acceleration/Deceleration Pattern, 175
 Plugging Deceleration Time, 175
 PM Motor, 71, 168

PM Motor Constant 1, 168
 PO, 16
 POFF, 250
 Point 1 Frequency, 200
 Point 1 Setting, 200
 Point 2 Frequency, 201
 Point 2 Setting, 200
 Power Connections, 16
 Power Factor Correction, 11
 Power running, 146
 Power Running Stall Continuous Trip Detection Time, 162
 Power Running Torque Limit 1, 160
 Power Running Torque Limit 1 Level, 160
 Power Running Torque Limit 2 Level, 161
 Power Running Torque Limit 3 Level, 161
 Power Running Torque Limit 4 Level, 162
 PP, 25, 27
 PP Output, 29
 Preset Speed 1, 87
 Preset Speed 10, 136
 Preset Speed 11, 136
 Preset Speed 12, 136
 Preset Speed 13, 137
 Preset Speed 14, 137
 Preset Speed 15, 137
 Preset Speed 2, 87
 Preset Speed 3, 88
 Preset Speed 4, 88
 Preset Speed 5, 88
 Preset Speed 6, 88
 Preset Speed 7, 88
 Preset Speed 8, 136
 Preset Speed 9, 136
 Preset Speed Operation Selection, 205
 Preset Speeds, 67
 Primary Menus, 35
 Process Decreasing Rate, 153
 Process Increasing Rate, 153
 Process Lower Limit, 152
 Process Upper Limit, 152
 Program Menu, 35
 Program Mode Menu Navigation, 57
 Prohibition, 62
 Protection, 65
 PTC1 Thermal Selection, 183
 PTC2 Thermal Selection, 184
 Pulse Output Frequency (FP), 188
 Pulse Width Modulation, 10
 Pulsed Output, 25
 PWM Carrier Frequency, 137

Q

Qualified Personnel, 2

R

R, 26
 R/L1, 16, 17
 RAM Fault, 258
 Random Mode, 142
 Reach Settings, 62
 Read Error, 255
 Real-time Clock Setup, 63
 Regenerative Power Ridethrough Control Level, 181
 Regenerative Power Ridethrough Mode, 138
 Remote EOI Required Hardware, 37
 Remote mode, 33
 Reset, 63, 82
 Restore User Settings, 41
 Retain Trip Record at Power Down, 176
 Retry, 139
 Retry/Restart, 66
 Reverse Speed Limit Input, 159
 Reverse Speed Limit Input Level, 159
 Ridethrough Time, 141
 ROM Fault, 258
 Root menu mapping, 52
 Root Menus, 52
 Rotary Encoder, 33
 Rotation in Specified Direction ONLY, 160
 RR, 25, 26, 55
 RR Input, 29
 RR Input Bias, 165
 RR Input Gain, 165
 RR Input Point 1 Frequency, 113
 RR Input Point 1 Rate, 115
 RR Input Point 1 Setting, 113
 RR Input Point 2 Frequency, 114
 RR Input Point 2 Rate, 115
 RR Input Point 2 Setting, 114
 RS485 2- and 4-wire Communications Time-Out Action, 198
 RS485 2- and 4-wire Parity, 197
 RS485 2-Wire and 4-Wire Communications Time Out, 197
 RS485 2-wire ASD-to-ASD Communications, 199
 RS485 2-Wire Baud Rate, 197
 RS485 2-wire Send Wait Time, 198
 RS485 4-Wire Baud Rate, 201
 RS485 ASD-to-ASD Communications, 202
 RS485 Protocol Selection (TSB/ModBus), 202
 RS485 Send Wait Time, 201
 Run Frequency, 126

Run Frequency Hysteresis, 127
 Run Key, 33
 Run Time, 54
 Rush Relay Current Activation Time, 183
 RX, 25, 26, 55
 RX Input, 29
 RX Input Bias, 165
 RX Input Gain, 165
 RX Input Point 1 Frequency, 116
 RX Input Point 1 Rate, 118
 RX Input Point 1 Setting, 116
 RX Input Point 2 Frequency, 117
 RX Input Point 2 Rate, 118
 RX Input Point 2 Setting, 117
 RX2, 55
 RX2 (AI1) Input Bias, 166
 RX2 (AI1) Input Gain, 166
 RX2 (AI1) Input Point 1 Frequency, 120
 RX2 (AI1) Input Point 1 Rate, 121
 RX2 (AI1) Input Point 1 Setting, 119
 RX2 (AI1) Input Point 2 Frequency, 120
 RX2 (AI1) Input Point 2 Rate, 122
 RX2 (AI1) Input Point 2 Setting, 120

S

S/L2, 16, 17
 Save User Settings, 41
 Second Speed Loop Proportional Gain, 163
 Second Speed Loop Stabilization Coefficient, 164
 Setpoints, 72
 Short Circuit Detection At Start, 178
 Short Circuit Protection, 276
 Simple Positioning Completion Range, 154
 Slack Rope, 58
 Slack Rope Detection, 207
 Slip Frequency Gain, 154
 SOUT, 258
 S-Pattern 1, 170
 S-Pattern 2, 170
 S-Pattern Acceleration Lower Limit Adjustment, 173
 S-Pattern Acceleration Upper Limit Adjustment, 173
 S-Pattern Deceleration Lower Limit Adjustment, 173
 S-Pattern Deceleration Upper Limit Adjustment, 173
 Special, 69
 Special Functions, 46
 Special Parameters, 70
 Special Protection Parameters, 66
 Speed at 0% Drooping Gain, 143
 Speed at F320 Drooping Gain, 143

Speed Control, 57
 Speed Error, 258
 Speed Limit (torque=0) Band, 160
 Speed Limit (torque=0) Center Value, 159
 Speed Limit (torque=0) Center Value Reference, 159
 Speed Loop Proportional Gain, 163
 Speed Loop Stabilization Coefficient, 163
 Speed PID Switching Frequency, 164
 Speed Reach Detection Band, 90
 Speed Reach Frequency, 90
 Speed Reference Setpoints, 67
 ST (Standby), 92
 Stall, 66
 Stall Prevention Factor 1, 157
 Stall Prevention Level, 176
 Standard Mode Selection, 59
 Start Frequency, 126
 Startup Wizard Requirements, 42
 Step Out, 258
 Stepout Current Detection Level, 184
 Stepout Current Detection Time, 184
 Stopping Time at Stop Limit Switch UP, 135
 Stop-Reset Key, 34
 Super Creep Control, 57
 Supply Voltage Correction, 141
 SW2, 27
 Switching Load Torque During Dynamic Braking, 147
 Switching Load Torque During Power Running, 146
 Synchronized Acceleration Time, 143
 Synchronized Deceleration Time, 142
 System Configuration and Menu Options, 52
 System Grounding, 18
 System Integration Precautions, 7
 System Operation, 40

T

T/L3, 16, 17
 T1, 17
 T2, 17
 T3, 17
 Tension Torque Bias Input, 157
 Terminal, 60
 Terminal Descriptions, 26
 Time Limit For Lower-Limit Frequency Operation, 128
 Timed-Run, 58
 Torque, 55, 72
 Torque Command Selection, 157
 Torque Control, 72
 Torque Current, 55

Torque Limit Settings, 72
 Torque Reference, 55
 Torque Speed Limiting, 72, 73
 Trace, 63
 Trace Cycle, 196
 Trace Data 1, 196
 Trace Data 2, 196
 Trace Data 3, 196
 Trace Data 4, 196
 Trace Selection, 195
 Traverse Acceleration Time, 229
 Traverse Deceleration Time, 229
 Traverse Jump Step, 230
 Traverse Selection, 229
 Traverse Step, 229
 Trip Code, 55
 Trip History, 260
 Trip History (read-only), 63
 Trip Record at Monitor Screen, 260
 Trip Settings, 66
 Trouble Shooting, 248
 Type Error, 259
 Type Reset, 63

U

U/T1, 16, 17
 UC, 253
 UL 1995, 261
 Under-Voltage Trip, 181
 Under-Voltage Trip Detection Time, 181
 Under-Voltage/Ridethrough, 66
 Unused discrete terminals, 22
 UP/DOWN Frequency (down) Frequency Step, 132
 UP/DOWN Frequency (down) Response Time, 132
 UP/DOWN Frequency (up) Frequency Step, 132
 UP/DOWN Frequency (up) Response Time, 131
 UP/DOWN Frequency Accel Time, 83
 UP/DOWN Frequency Decel Time, 83
 UP/DOWN Frequency Functions, 67
 Up/Down Frequency Operation, 133
 UP1, 256
 UP2, 255
 U-Phase Over-Current, 259
 Upper Limit Frequency, 84
 Upper-Limit Slow Speed, 137

Utilities, 62

V

V/f 5-Point Setting, 70
 V/f 5-Point Setting Frequency 1, 104
 V/f 5-Point Setting Frequency 2, 105
 V/f 5-Point Setting Frequency 3, 106
 V/f 5-Point Setting Frequency 4, 106
 V/f 5-Point Setting Frequency 5, 107
 V/f 5-Point Setting Voltage 1, 105
 V/f 5-Point Setting Voltage 2, 106
 V/f 5-Point Setting Voltage 3, 106
 V/f 5-Point Setting Voltage 4, 106
 V/f 5-Point Setting Voltage 5, 107
 V/f Control Error, 259
 V/f Pattern, 85
 V/I, 25, 55, 67
 V/I Analog Input Broken Wire Detection Level, 182
 V/I Input, 29
 V/I Input Bias, 164
 V/I Input Gain, 164
 V/I Input Gain (AI2 Option Board Input), 166
 V/I Input Point 1 Frequency, 109
 V/I Input Point 1 Rate, 110
 V/I Input Point 1 Setting, 108
 V/I Input Point 2 Frequency, 109
 V/I Input Point 2 Rate, 111
 V/I Input Point 2 Setting, 109
 V/T2, 16, 17
 Vector Control, 13
 Vector Motor Model, 71
 Version (read-only), 64
 Viewing Trip Information, 260
 Virtual Input Terminal 1 Selection, 226
 Virtual Input Terminal 2 Selection, 226
 Virtual Input Terminal 3 Selection, 226
 Virtual Input Terminal 4 Selection, 226
 V-Phase Over-Current, 259

W

W/T3, 16, 17
 Warranty Card, 2
 W-Phase Over-Current, 259

ACE-tronics

ACE World Companies Corporation

10200 Jacksboro Highway, Fort Worth, TX 76135

TEL: (817) 237-7700 — FAX: (817) 237-2777

Toll Free: (800) 431-4223

Printed in the U.S.A.