



PL1911M LCD Monitor

USER'S GUIDE

www.planar.com

Contents

Preface.....	2
Installation.....	4
Unpacking	4
Connecting the LCD Monitor and Base.....	5
Tilt, Swivel and Pivot Rotation.....	5
Connecting the Display.....	6
Connecting the AC Power.....	6
Connecting the Audio Cable.....	6
Setting Up the LCD Monitor.....	6
Power Management System	6
Optional Mounting Alternatives	7
Detaching LCD Monitor from Its Stand.....	7
Interface for Arm Applications	7
Display Controls.....	8
User Controls	8
Adjusting the Monitor's Display.....	8
Function Description.....	9
OSD Lock Out Function	10
Technical Information	11
Specifications	11
Standard Timing Table	13
Troubleshooting	14
Product Registration and Technical Support.....	15

Preface

This manual is designed to assist users in setting up and using the LCD Monitor. Information in this document has been carefully checked for accuracy; however, no guarantee is given to the correctness of the contents. The information in this document is subject to change without notice. This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic or other means, in any form, without prior written permission of the manufacturer. Windows is a registered trademark of Microsoft Inc. Other brand or product names are trademarks of their respective holders.

FCC Statement Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reposition or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced monitor technician for help.

Warning

Use only shielded signal cables to connect I/O devices to this equipment. You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This device complies with part 15FCC Rules. Operation is subject to the following two conditions(1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation.

Canadian DOC Notice



This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Important Safety Instructions

Please read the following instructions carefully. This manual should be retained for future use.

1. To clean the LCD Monitor screen:
 - Power off the LCD Monitor and unplug the AC Cord.
 - Spray a non-solvent cleaning solution onto a rag.
 - Gently clean the screen with dampened rag.
2. Do not place the LCD Monitor near a window. Exposing the monitor to rain water, moisture or sunlight can severely damage it.
3. Do not apply pressure to the LCD screen. Excess pressure may cause permanent damage to the display.
4. Do not remove the cover or attempt to service this unit by yourself. Servicing of any nature should be performed by an authorized technician.
5. Store the LCD Monitor in a room with a room temperature of -20° ~ 60°C (or -4° ~ 140°F). Storing the LCD Monitor outside this range could result in permanent damage.
6. If any of the following occurs, immediately unplug your monitor and call an authorized technician.
 - * Monitor to PC signal cable is frayed or damaged.
 - * Liquid spilled into LCD Monitor or the monitor has been exposed to rain.
 - * LCD Monitor or the case is damaged.
7. Only use the supplied main lead to connect the monitor. For a nominal current up to 6A and a device weight above 3 kg, a line not lighter than H05VV-F, 3G, 0.75 mm² must be used.

Important Recycle Instruction:



Lamp(s) inside this product contain mercury. This product may contain other electronic waste that can be hazardous if not disposed of properly. Recycle or dispose in accordance with local, state, or federal Laws. For more information, contact the Electronic Industries Alliance at WWW.EIAE.ORG. For lamp specific disposal information check WWW.LAMPRECYCLE.ORG.

Contains Mercury, Dispose of Properly



Installation

Unpacking

Before unpacking the LCD Monitor, prepare a suitable workspace for your Monitor and computer. You need a stable and clean surface near a wall power outlet. Make sure that LCD Monitor has enough space around it for sufficient airflow. Though the LCD Monitor uses very little power, some ventilation is needed to ensure that the Monitor does not become too hot.

After you unpack the LCD Monitor, make sure that the following items were included in the box:

- | | | |
|-----------------------------|---------------------------|--------|
| * LCD Monitor | * User's Manual | * Base |
| * Monitor-to-PC VGA Cable | * Stereo Jack Audio Cable | |
| * Monitor-to-PC DVI-D Cable | * Power Cord | |

Connecting the LCD Monitor and Base

When you open the box, place the monitor and put on the desk first. (See fig. 1-1)

- ❶ Connect the LCD monitor and base.
- ❷ Using your hand, lock the base and neck by screwing the thread clockwise.
- ❸ To unlock the height adjustment feature of the stand, locate the pin on the back of the stand column and turn the pin knob counterclockwise.
- ❹ Mount the cable clip for cable management.




Figure 1-1

Tilt, Swivel and Pivot Rotation

The LCD Monitor is designed to have a tilt range of -5° to $+20^{\circ}$, a swivel range of -35° to $+35^{\circ}$, and a 90° pivot rotation. (See fig. 1-2)




Figure 1-2

Warning

Do not force the LCD Monitor over its maximum viewing angle settings as stated above. Attempting this will result in damaging the Monitor and Monitor stand. The monitor stand base may forcefully extend and cause injury. Raise the monitor to its "Full Up" position before removing the monitor stand.

Connecting the Display

1. Power off your computer.
2. Connect one end of the signal cable to the LCD Monitor's VGA port or DVI port. (See Fig 1-3)
3. Connect the other end of the signal cable to the VGA port or DVI port on your PC.
4. Make sure connections are secure.




Figure 1-3

Connecting the AC Power

1. Connect the power cord to the LCD Monitor. (See Fig. 1-4)
- Connect the power cord to an AC power source.




Figure 1-4

Connecting the Audio Cable

1. Connect the audio cable to the "LINE OUT" jack on your PC's audio card or to the front panel's "AUDIO OUT" jack of your CD ROM drive. (See Fig. 1-5)
2. Connect the other end of the audio cable to the LCD Monitor's "LINE IN" jack.




Figure 1-5

Setting Up the LCD Monitor

1. Make sure the AC power cord is connected to the LCD Monitor.
2. Turn on the LCD Monitor's power switch, located on the bezel of the monitor.

Power Management System

This LCD Monitor complies with the VESA DPMS (version 1.0) Power Management guidelines. The VESA DPMS provides four power saving modes through detecting a horizontal or vertical sync. signal.

When the LCD Monitor is in power saving mode, the monitor screen will be blank and the power LED indicator will light yellow.

Optional Mounting Alternatives

Warning: The monitor stand base may forcefully extend and cause injury. Raise the monitor to its "Full Up" position before removing the monitor stand.

Detaching LCD Monitor from Its Stand

Unscrew screws ❶ the swivel base support column and pull down ❷ the hinge to release.
❸ Cable management ring.




Figure 1-6

Interface for Arm Applications

Before installing to mounting device, please refer to Fig.1-3. The rear of this LCD display has four integrated 4 mm, 0.7 pitches threaded nuts, as well as four 5 mm access holes in the plastic covering as illustrated in Figure 1-7. These specifications meet the VESA Flat Panel Monitor Physical Mounting Interface Standard (paragraphs 2.1 and 2.1.3, version 1, dated 13 November 1997).
Note :Please use M 4mm x 100m (L) screws for this application.




Figure 1-7

Display Controls

User Controls

A brief description and the location of all LCD Monitor functions controls and indicators:




Figure 2-1

1		Power LED will be Green when the monitor is on, Yellow when in power saving mode, and Dark when the monitor is off. Press this button to turn on and turn off the monitor.
2		Function select (clockwise)
3		Function select (counter-clockwise) / Input source select (When OSD control and Volume OSD are not activated)
4		Audio Volume increase / Adjust increase
5		Auto adjust (When OSD/Volume control is not activated) / Audio Volume decrease / Adjust decrease
6		External Headphone Jack. The monitor speakers will be disabled when using an external headphone or external speakers.

Adjusting the Monitor's Display

The monitor has four function control buttons to select among functions shown on OSD menu, designed for easy user-viewing environments.

OSD Function Menu

To access OSD Main menu, simply press . Function Select control buttons, and the menu diagram will pop up on the screen as shown on Fig. 2-2:

Continue pressing the Function Select buttons to scroll through the entire menu items, then press Adjustment Control buttons to adjust content of selected item.



Figure 2-2

Attention

Firmware revision may have been updated into a latest version while the version number shown on all OSD menus in this manual will stay as Ver. 1.00

Function Description

Icon	Function	Function Description
	Brightness	101 scales of brightness are available to choose from (0 to 100).
	Contrast	101 scales of contrast are available to choose from (0 to 100).
	H. Position	This function let's you adjust the display's horizontal position. (Only support analog input)
	V. Position	This function let's you adjust the display's vertical position. (Only support analog input)
	OSD Transparency	This function let's you set the transparency of the OSD menu. The transparency is adjustable from 0 to 10. 11 scales are available.
	Phase	A total of 101 scales (0 to 100) are available to adjust the focus and clarity of the display. (Only support analog input)
	Clock	This function carries a frequency-tracking feature that offers users better stability and clarity. 101 scales (from -50 to +50) are available on the mode that is currently running. The adjustable range can be variable in different modes. This function records the deviated number of clock period between input timing and supported timing. The clock value may not be "0" after Auto Adjustment when the input timing is different from supported timing. (Only support analog input)
	Color Temperature	Push the  or  button to select a different color temperature. Please see the diagram below for function and description.
	OSD H. Position	This function moves the OSD menu window horizontally.
	OSD V. Position	This function moves the OSD menu window vertically.
	Graph / Text	Because the H and V-Frequencies of both 640 x 400 70Hz, and 720 x 400 70Hz, are the same, this function let's you manually select either 640 x 400 (graphics mode), or 720 x 400 (text mode).
	Recall	The recall function will return all adjusted parameters to factory preset values.
	Language	Nine OSD language options are available: English, German, French, Spanish, Italian, Japan, Russian, Simplified Chinese and Traditional Chinese. Press the  or  adjustment control button to select other language.
	Auto and Input Select	The Auto Adjustment function let you adjust the display size, clock and phase to obtain the best viewing settings. This process will take 3 ~ 5 seconds to complete. Attention: After Auto Adjustment, the display might display wrong position or size, if it has received a pattern which has no screen border.
	Exit	Saves the values of this setting and exits the OSD menu function.

Icon	Function	Description
9300	CIE coordinated Color Temperature of 9300°K	Sets the CIE coordinate color temperature to 9300°K
7500	CIE coordinated Color Temperature of 7500°K	Sets the CIE coordinate color temperature to 7500°K
6500	CIE coordinated Color Temperature of 6500°K	Sets the CIE coordinate color temperature to 6500°K
User	Three colors (Red, Green, Blue) can be adjusted from the OSD menu	Sets the settings to a user defined CIE Temperature.

OSD Lock Out Function

When the monitor is in normal display, you can enable the “OSD Lock Out” function.

Option 1: OSD lock – all 4 buttons are locked except the “POWER” button.

Press and hold the   and  buttons at the same time for 3 seconds to lock the buttons.

The monitor will show an “OSD Lock Out” message for 5~10 seconds and the message will disappear automatically.



Repeat this step to unlock.

Option 2: OSD & Power button lock – all 5 buttons including the “POWER” button are locked.

Press and hold the  and  buttons for same time 3 seconds to lock all 5 buttons.

The monitor will show an “Lock Out” message for 5~10 seconds and the message will disappear automatically.



Repeat this step to unlock.

Technical Information

Specifications

LCD Panel	
Size	19"
Display Type	Active matrix color TFT LCD
Resolution	1280 x 1024
Display Dot	1280 x (RGB) x 1024
Display Area (mm)	376.32 x 301.056 (H x V)
Display Color	16.7M (RGB 6 bit+FRC)
Lamp Voltage (typical)	660 Vrms
Lamp Current (typical)	7.5 mA rms.

Video	
Input Signal	Analogue RGB 0.7Vp-p
Input Impedance	75 Ohm $\pm$ 2%
Polarity	Positive, Negative
Amplitude	0 - 0.7 $\pm$ 0.05 Vp
Multi-mode Supported	Horizontal Frequency: 30 ~ 80 kHz Vertical Frequency: 56 ~ 75 Hz

Control	
Power switch	On/Off switch with LED indicator

Audio	
Input	500mVrms
Output	1W+1W

OSD	
Brightness	Digital
Contrast	Digital
Horizontal Position	Digital
Vertical Position	Digital
Phase	Digital
Clock	Digital
Display Mode Setup	Use EEPROM to save settings in memory
OSD Format	26 characters x 15 rows

Power Management

Mode	Power Consumption*	AC Input	LED Color
DPM ON	28W maximum	240 VAC	Green
DPM OFF	2W maximum	240 VAC	Yellow
DC switch off	1W maximum	240 VAC	Dark
Disconnected	2W maximum	240 VAC	Yellow

Meeting VESA DPM requirements measured from AC Input end of AC power cord.

Sync Input	Analogue
Signal	Separate TTL compatible horizontal and vertical synchronization
Polarity	Positive and negative

Plug & Play	Supports VESA DDC2B functions	
External Connection		
Power Input (AC input)	AC socket	
Video Cable	15-pin D-sub connector	
Audio Cable	Stereo Jack	
Environment		
Operating Condition:	Temperature	5°C to 40°C/41°F to 104°F
	Relative Humidity	20% to 80%
Storage Condition:	Humidity	-20°C to 60° C/-4°F to 140° F
	Temperature	5% to 85%
	Relative Humidity	
Power Supply (AC Input)		
Input Voltage	Single phase, 100 ~ 240VAC, 50 / 60 Hz	
Input Current	1.2 A maximum	
Size and Weight		
Dimensions	412.6 (W) x 436.6 (H) x 219.17(D) mm	
Net Weight	7.7 ± 0.3 kg	
Gross Weight	10.1 ± 0.3 kg	

Standard Timing Table

If the selected timing is NOT included in the table below, this LCD monitor will use the most suitable available timing.

TIMING	FH(KHZ) FV(HZ)	SYNC	TOTAL	ACTIVE	SYNC	FRONT	BACK	PIXEL FOREQ (MHZ)
		POLARITY	(DOT/ LINE)	(DOT/ LINE)	WIDTH (DOT/LINE)	PORCH (DOT/LINE)	PORCH (DOT/LINE)	
640x350	31.469	+	800	640	96	16	48	25.175
VGA-350	70.087	-	449	350	2	37	60	
640x400	24.83	-	848	640	64	64	80	21.05
NEC PC9801	56.42	-	440	400	8	7	25	
640x400	31.469	-	800	640	96	16	48	25.175
VGA-GRAPH	70.087	+	449	400	2	12	35	
640x400	31.5	-	800	640	64	16	80	25.197
NEC PC9821	70.15	-	449	400	2	13	34	
640x480	31.469	-	800	640	96	16	48	25.175
VESA-PAL	50.030	-	629	480	2	62	85	
640x480	31.469	-	800	640	96	16	48	25.175
VGA-480	59.94	-	525	480	2	10	33	
640x480	35.00	-	864	640	64	64	96	30.24
APPLE MAC-480	66.67	-	525	480	3	3	39	
640x480	37.861	-	832	640	40	16	120	31.5
VESA-480-72Hz	72.809	-	520	480	3	1	20	
640x480	37.5	-	840	640	64	16	120	31.5
VESA-480-75Hz	75	-	500	480	3	1	16	
720x400	31.469	-	900	720	108	18	54	28.322
VGA-400-TEXT	70.087	+	449	400	2	12	35	
832x624 APPLE	49.725	-	1152	832	64	32	224	57.2832
MAC-800	74.55	-	667	624	3	1	39	
800x600	35.156	+	1024	800	72	24	128	36
SVGA	56.25	+	625	600	2	1	22	
800x600	37.879	+	1056	800	128	40	88	40
VESA-600-60Hz	60.317	+	628	600	4	1	23	
800x600	48.077	+	1040	800	120	56	64	50
VESA-600-72Hz	72.188	+	666	600	6	37	23	
800x600	46.875	+	1056	800	80	16	160	49.5
VESA-600-75Hz	75	+	625	600	3	1	21	
1024x768	48.363	-	1344	1024	136	24	160	65
XGA	60.004	-	806	768	6	3	29	
1024x768	53.964	+	1328	1024	176	16	112	71.664
COMPAQ-XGA	66.132	+	816	768	4	8	36	
1024x768	56.476	-	1328	1024	136	24	144	75
VESA-768-70Hz	70.069	-	806	768	6	3	29	
1024x768	60.023	+	1312	1024	96	16	176	78.75
VESA-768-75Hz	75.029	+	800	768	3	1	28	
1024x768	60.24	-	1328	1024	96	32	176	80
APPLE MAC-768	75.02	-	803	768	3	3	29	
1152x864	54.054	+	1480	1152	96	40	192	80
(60Hz)	59.270	+	912	864	3	13	32	
1152x864	63.851	+	1480	1152	96	32	200	94.499
(70Hz)	70.012	+	912	864	3	1	44	
1152x864	67.50	+	1600	1152	128	64	256	108.00
(75Hz)	75.00	+	900	864	2	2	32	
1280x960	60.00	+	1800	1280	112	96	312	108.00
(60Hz)	60.00	+	1000	960	3	1	36	
1280x960	70.00	+	1800	1280	112	96	312	126.00
(70Hz)	70.00	+	1000	960	3	1	36	
1280x960	75.00	+	1800	1280	112	96	312	135.00
(75Hz)	75.00	+	1000	960	3	1	36	
1280x1024VESA-1	64	+	1688	1280	112	48	248	108
024-60Hz	60	+	1066	1024	3	1	38	
1280x1024VESA-1	80	+	1688	1280	144	16	248	135
024-75Hz	75	+	1066	1024	3	1	38	

Note: Mode 640x350, 640x400 and 720x400 is centered in the middle of the display and can not be expanded to full screen.

Troubleshooting

This LCD Monitor has pre-adjusted using factory standard VGA timings. Due to the output timing differences among various VGA cards in the market, users may initially experience an unstable or unclear display whenever a new display mode or new VGA card is selected.

Attention

This LCD Monitor Supports Multiple VGA Modes.

Refer to the Standard Timing Table for a listing of modes supported by this LCD Monitor.

PROBLEM Picture is unclear and unstable

The picture is unclear and unstable, please perform the following steps:

1. Enter PC to "Shut Down Windows" status while you're in MS-Windows environment.
2. Check the screen to see if there's any black vertical stripes appear. If there are, take advantage of the "Clock" function in OSD menu and adjust (by increment or decrement numbers) until those bars disappear.
3. Move to "Phase" function in OSD menu again and adjust the monitor screen to its most clear display.
4. Click "No" on "Shut Down Windows" and back to the normal PC operating environment.

PROBLEM There is no picture on LCD Monitor

If there's no picture on the LCD Monitor, please perform the following steps:

1. Make sure the power indicator on the LCD Monitor is ON, all connections are secured, and the system is running on the correct timing. Refer to Chapter 3 for information on timing.
2. Turn off the LCD Monitor and then turn it back on again. If there is still no picture, press the Adjustment Control button several times.
3. If step 2 doesn't work, connect your PC system to another external CRT. If your PC system Functions properly with a CRT Monitor but it does not function with the LCD Monitor, the output timing of the VGA card may be out of the LCD's synchronous range. Please change to an alternative mode listed in the Standard Timing Table or replace the VGA card, and then repeat steps 1 and 2.

PROBLEM There is no picture on LCD Monitor

If you have chosen an output timing that is outside of the LCD Monitor's synchronous range (Horizontal: 30 ~ 80 kHz and Vertical: 56 ~ 75 Hz), the OSD will display a "Out of Range" message. Choose a mode that is supported by your LCD Monitor.

Also, if the signal cable is not connected to LCD monitor at all or properly, the monitor screen will display a message "No Input Signal".

Product Registration and Technical Support

Register Your Planar Products Today

Thank you choosing Planar. To assure you receive all the benefits of your Planar product and services, register your Planar product today.

Visit our website to register your product at

http://www.planar.com/support/product_registration.html

Cables, Replacement Lamps, Accessories

To find cables, replacement lamps and accessories for your Planar projector, LCD monitor, touch screen or other Planar products visit our online store at www.PlanarOnline.com or find other stores who carry Planar products at <http://www.planar.com/howtobuy>

Technical Support

Visit Planar at <http://www.planar.com/support> for product registration, operations manuals, touch screen drivers, warranty information and access to Planar's Technical Library for online troubleshooting.

To speak with Planar Customer Support please have you model and serial number available and dial:

Planar Support

Tel: 1-866-PLANAR1 (866-752-6271) or +1 503-748-5799 outside the US.

Hours: 24 hours a day, 7 days a week.

Toll or long distance charges may apply.

Planar Systems, Inc.

Customer Service

24x7 Online Technical Support: <http://www.planar.com/support>

1195 NW Compton Drive

Beaverton, OR 97006-1992

Tel: 1-866-PLANAR1 (866-752-6271), or +1 503-748-5799 outside the United States,

Hours: 24 hours a day, 7 days a week

©2010 Planar Systems, Inc.

Planar is a registered trademark of Planar Systems, Inc. Other brands and names are the property of their respective owners. Technical information in this document is subject to change without notice.

HDPNRTH920I