

User Manual

Original Instructions



**Allen-Bradley**

# Kinetix 6000M Integrated Drive-Motor System

Catalog Numbers 2094-SEPM-B24-S, MDF-SB1003P, MDF-SB1153H, MDF-SB1304F



## Important User Information

Read this document and the documents listed in the additional resources section about installation, configuration, and operation of this equipment before you install, configure, operate, or maintain this product. Users are required to familiarize themselves with installation and wiring instructions in addition to requirements of all applicable codes, laws, and standards.

Activities including installation, adjustments, putting into service, use, assembly, disassembly, and maintenance are required to be carried out by suitably trained personnel in accordance with applicable code of practice.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.



**WARNING:** Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.



**ATTENTION:** Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence.

---

**IMPORTANT**

Identifies information that is critical for successful application and understanding of the product.

Labels may also be on or inside the equipment to provide specific precautions.



**SHOCK HAZARD:** Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.



**BURN HAZARD:** Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.



**ARC FLASH HAZARD:** Labels may be on or inside the equipment, for example, a motor control center, to alert people to potential Arc Flash. Arc Flash will cause severe injury or death. Wear proper Personal Protective Equipment (PPE). Follow ALL Regulatory requirements for safe work practices and for Personal Protective Equipment (PPE).

<b>Preface</b>	
Summary of Changes .....	9
Conventions Used in This Manual .....	9
Additional Resources .....	10
<b>Chapter 1</b>	
<b>Start</b>	
About the Kinetix 6000M System .....	11
Typical Hardware Configurations .....	13
Typical Communication Configurations .....	18
Catalog Number Explanations .....	19
Component Compatibility .....	20
Agency Compliance .....	21
CE Requirements (system without LIM module) .....	21
CE Requirements (system with LIM module) .....	21
<b>Chapter 2</b>	
<b>Plan the Kinetix 6000M System Installation</b>	
Cable Length Restrictions and System Sizing .....	23
IPIM Module Design Guidelines .....	24
System Mounting Requirements .....	24
Circuit Breaker/Fuse Options .....	25
Enclosure Selection .....	26
Minimum Clearance Requirements .....	27
IDM Unit Design Guidelines .....	28
Electrical Noise Reduction .....	29
Cable Categories for Kinetix 6000M System .....	30
<b>Chapter 3</b>	
<b>Mount the Kinetix 6000M System</b>	
Mount the IPIM Module .....	32
Using the 2094 Mounting Brackets .....	32
Install the 2094 Power Rail .....	32
Determine Mounting Order .....	32
Mount the IPIM Module .....	34
Install the IDM Unit .....	35
Align the IDM Unit .....	36
Mount and Connect the IDM Unit .....	36

## **Kinetix 6000M System Connector Data**

<b>Chapter 4</b>	
IPIM Module Connectors and Indicators .....	40
IPIM Module Connector and Signal Descriptions .....	41
Hybrid Cable DC Bus Connector .....	41
Hybrid Cable Communication Signals Connector .....	41
Safe Torque-off Connector .....	42
Sercos Fiber-optic Connectors .....	43
Enable Input .....	43
EtherNet/IP Connectors .....	44
IPIM Module Network Connector Pinouts .....	44
IDM Unit Connectors and Indicators .....	45
IDM Unit Connector and Signal Descriptions .....	46
Hybrid Cable Connector .....	46
IDM Network Input and Output Connector Pinouts .....	47
Digital Input Connectors .....	47
Power Specifications .....	52
Brake Override Input .....	52
Peak Duty Cycle .....	52
Feedback Specifications .....	54
Absolute Position .....	54

## **Connect the Kinetix 6000M System**

<b>Chapter 5</b>	
Basic Wiring Requirements .....	55
Routing the Power and Signal Cables .....	56
Ground the IDM System .....	56
Apply the Cable Shield Clamp .....	57
General IDM System Wiring .....	58
Hybrid Cable .....	58
Network Cable .....	60
How to Bypass an IDM Unit .....	60
The Sercos Fiber-optic Ring .....	61
Ethernet Cable Connections .....	65

## **Configure the Kinetix 6000M System**

<b>Chapter 6</b>	
Configure the Kinetix 6000M Integrated Drive-motor System .....	67
Understand the IPIM Module Display .....	68
Startup Sequence .....	69
Information Display .....	69
Tools Menu .....	70
Configure the IPIM Module .....	71
Set the IPIM Module Network Address .....	71
Configure the IDM Unit .....	72
Set the Node Address .....	72
Add-on Profiles .....	75
Configure the Logix Sercos Interface Module .....	75
Configure the Logix Controller .....	75

Configure the Logix Module .....	77
Configure the IDM Units .....	79
Configure the Motion Group .....	81
Configure Axis Properties .....	82
Download the Program .....	83
Apply Power to the System .....	84
Test and Tune the Axes .....	85
Test the Axes .....	85
Tune the Axes .....	87

## Chapter 7

### Troubleshoot the Kinetix 6000M System

Safety Precautions .....	89
IDM System Error Codes .....	90
Read the Fault Status of the IPIM Module .....	90
Interpret Status Indicators .....	92
IPIM Module Display and Status Indicators .....	92
IDM Unit Status Indicators .....	93
General System Anomalies .....	94
IPIM Module Fault Diagnosis .....	95
IPIM Module Fault Types .....	96
IDM Unit Fault Diagnosis .....	97
Logix Controller/IDM Unit Fault Behavior .....	97
Use a Web Browser to Monitor System Status .....	100

## Chapter 8

### Remove and Replace the Kinetix 6000M IPIM Module

Before You Begin .....	103
Remove the IPIM Module .....	104
Replace the IPIM Module .....	105

## Appendix A

### Kinetix 6000M Safe Torque-off Feature

Certification .....	107
Important Safety Considerations .....	107
Category 3 Requirements According to EN ISO 13849-1 .....	108
Stop Category Definition .....	108
Performance Level (PL) and Safety Integrity Level (SIL) .....	108
Description of Operation .....	108
Troubleshoot the Safe Torque-off Function .....	109
PFD, PFH, and MTTFd Definitions .....	111
PFD, PFH, and MTTFd Data .....	111
Wire Your Safe Torque-off Circuit .....	111
European Union Directives .....	112
IDM Safe Torque-off Feature .....	112
Safe Torque-off Feature Bypass .....	113
IDM System Safe Torque-off Example .....	113
Cascade the Safe Torque-off Signal .....	115
Safe Torque-off Signal Specifications .....	115

## Interconnect Diagram

### Appendix B

IPIM Module and IDM Unit Wiring Example .....	117
---	-----

## Upgrade the Kinetix 6000M System Firmware

### Appendix C

Before You Begin.....	119
Configure Logix Communication .....	120
IPIM Module Firmware Upgrade.....	121
IDM Unit Firmware Upgrade.....	126
Verify the Firmware Upgrade .....	130

## Kinetix 6000M System Sizing

### Appendix D

Definitions .....	131
Manually Size the Kinetix 6000M System .....	132

## Kinetix 6000M System Product Specifications

### Appendix E

Kinetix 6000M System Features and Indicators .....	143
Kinetix 6000M Integrated Drive-Motor High Resolution Encoders .....	144
Kinetix 6000M Integrated Drive-Motor System Cables.....	145
Digital Input Cables .....	145
Kinetix 6000M Integrated Drive-Motor Options .....	146
Technical Specifications - Kinetix 6000M Integrated Drive-Motor System.....	146
Kinetix 6000M IPIM Module Specifications.....	147
Maximum System Cable Lengths .....	148
Kinetix 6000M Integrated Drive-Motor Load Force Ratings ..	149
Dimensions - Kinetix 6000M Integrated Drive-Motor System ...	150
Environmental Specifications - Kinetix 6000M IPIM Module ...	152
Certifications - Kinetix 6000M IDM System .....	152

## Kinetix 6000M Drive Systems

### Appendix F

Kinetix 6000M Integrated Drive-Motor Systems.....	154
Kinetix 6000M Integrated Drive-Motor System Example ....	154
Determine What You Need .....	155
Kinetix 6000M Integrated Drive-Motor System Performance....	160
Kinetix 6000M Integrated Drive-Motor (400V-class) Performance Curves .....	161

**Kinetix 6000M System Cable  
Specifications****Appendix G**

Kinetix 6000M Hybrid Cables .....	163
Catalog Numbers - Kinetix 6000M Hybrid Cables .....	164
Kinetix 6000M Network Cables .....	165
Catalog Numbers - Kinetix 6000M Network Cables .....	166
Kinetix 6000M Replacement Parts .....	166
Kinetix 6000M Digital Input Cables .....	167
Technical Specifications - Kinetix 6000M Cables .....	168
Dimensions - Kinetix 6000M Hybrid Cables .....	169
Dimensions - Kinetix 6000M Network Cables .....	170
Dimensions - Kinetix 6000M Network Bulkhead Adapter .....	170
<b>Index .....</b>	<b>171</b>

**Notes:**

This manual provides detailed installation instructions for mounting, wiring, and troubleshooting the Kinetix® 6000M Integrated Drive-Motor (IDM) system including the IDM Power Interface Module (IPIM).

For information on wiring and troubleshooting the safe-off feature on your integrated drive-motor system, refer to [Appendix A](#).

This manual is intended for engineers or technicians that are directly involved in the installation, wiring, and programming of the Kinetix 6000M integrated drive-motor system.

If you do not have a basic understanding of the Kinetix drives, contact your local Rockwell Automation sales representative for information on available training courses.

## Summary of Changes

This manual contains new and updated information as indicated in the following table.

Topic	Page
The Kinetix 6000M integrated drive-motor system is discontinued and all product specifications are archived in this publication.	–
Added Kinetix 6000M System Product Specifications (Appendix E) that were removed from Kinetix Rotary Motion Specifications Technical Data, publication <a href="#">KNX-TD001</a> .	143
Added Kinetix 6000M Drive Systems (Appendix F) that were removed from Kinetix 6000 and Kinetix 6200/6500 Drive Systems Design Guide, publication <a href="#">KNX-RM003</a> .	153
Added Kinetix 6000M System Cable Specifications (Appendix G) that were removed from Kinetix Motion Accessories Specifications Technical Data, publication <a href="#">KNX-TD004</a> .	163

## Conventions Used in This Manual

The following conventions are used throughout this manual:

- Bulleted lists such as this one provide information, not procedural steps.
- Numbered lists provide sequential steps or hierarchical information.
- Acronyms for the Kinetix 6000 and Kinetix 6200 system components and Kinetix 6000M integrated drive-motor are shown in the following table and are used throughout this manual.

Acronym	Kinetix Modules	Cat. No.
IDM	Integrated drive-motor	MDF-SBxxxx-Qx8xA-S
IPIM	IDM power interface module	2094-SEPM-B24-S
IAM	Integrated axis module	2094-BCxx-Mxx-x
AM	Axis module	2094-BMxx-x
LIM	Line interface module	2094-BLxx and 2094-BLxxS-xx

## Additional Resources

These documents contain additional information concerning related Rockwell Automation products.

Resource	Description
Kinetix Rotary Motion Specifications Technical Data, publication <a href="#">KNX-TD001</a>	Provides product specifications for Kinetix VP (Bulletin VPL, VPC, VPF, and VPS), MP-Series™ (Bulletin MPL, MPM, MPF, and MPS), and HPK-Series™ rotary motors.
Kinetix Motion Accessories Specifications Technical Data, publication <a href="#">KNX-TD004</a>	Provides product specifications for Bulletin 2090 motor and interface cables, low-profile connector kits, drive power components, and other servo drive accessory items.
Kinetix 6000 Multi-axis Servo Drives User Manual, publication <a href="#">2094-UM001</a>	Provides detailed information about the Kinetix 6000 drives.
Kinetix 6200 and Kinetix 6500 Modular Multi-axis Servo Drives User Manual, publication <a href="#">2094-UM002</a>	Provides detailed information about the Kinetix 6200 drives.
Kinetix 6000M Integrated Drive-Motor Installation Instructions, publication <a href="#">MDF-IN001</a>	Provides installation information for the IDM unit.
Kinetix 6000M Integrated Drive-Motor Power Interface Module Installation Instructions, publication <a href="#">2094-IN016</a>	Provides information on the installation of the IPIM module.
Kinetix 6000M IPIM-to-IDM Hybrid Cable Installation Instructions, publication <a href="#">2090-IN031</a>	Provides detailed cable information.
Kinetix 6000M IDM-to-IDM Hybrid Cable Installation Instructions, publication <a href="#">2090-IN032</a>	
Kinetix 6000M IDM Network Cable Installation Instructions, publication <a href="#">2090-IN034</a>	
Kinetix 6000M Manual Brake Release Cable Installation Instructions, publication <a href="#">2090-IN037</a>	
Kinetix 6000M IPIM Hybrid Terminator Installation Instructions, publication <a href="#">2090-IN035</a>	Provides detailed terminator information.
Kinetix 6000M Network Terminator Installation Instructions, publication <a href="#">2090-IN036</a>	Provides installation information for the Hybrid Power Coupler.
Kinetix 6000M Hybrid Power Coupler Installation Instructions, publication <a href="#">2090-IN038</a>	Provides installation information for the Bulkhead Cable Adapter.
Kinetix 6000M Bulkhead Cable Adapter Kit Installation Instructions, publication <a href="#">2090-IN039</a>	Provides installation information for the Bulkhead Cable Adapter.
Fiber-optic Cable Installation and Handling Instructions, publication <a href="#">2090-IN010</a>	Provides information on proper handling, installing, testing, and troubleshooting fiber-optic cables.
System Design for Control of Electrical Noise Reference Manual, publication <a href="#">GMC-RM001</a>	Provides information, examples, and techniques designed to minimize system malfunctions caused by electrical noise.
Kinetix Safe-off Feature Safety Reference Manual, publication <a href="#">GMC-RM002</a>	Provides information on wiring and troubleshooting your Kinetix 6000 servo drives with the safe-off feature.
Kinetix Motion Control Selection Guide, publication <a href="#">KNX-SG001</a>	Overview of Kinetix servo drives, motors, actuators, and motion accessories designed to help make initial decisions for the motion control products best suited for your system requirements.
Sercos and Analog Motion Configuration User Manual, publication <a href="#">MOTION-UM001</a>	Provides information on configuring and troubleshooting your ControllLogix®, CompactLogix™, and SoftLogix™ sercos interface modules.
Motion Coordinate System User Manual, publication <a href="#">MOTION-UM002</a>	Provides information to create a motion coordinate system with sercos or analog motion modules.
SoftLogix Motion Card Setup and Configuration Manual, publication <a href="#">1784-UM003</a>	Provides information on configuring and troubleshooting SoftLogix PCI cards.
Rockwell Automation Product Selection website <a href="http://www.rockwellautomation.com/global/support/selection.page">http://www.rockwellautomation.com/global/support/selection.page</a>	Online product selection and system configuration tools, including AutoCAD (DXF) drawings.
Motion Analyzer System Sizing and Selection Tool website <a href="https://motionanalyzer.rockwellautomation.com/">https://motionanalyzer.rockwellautomation.com/</a>	Comprehensive motion application sizing tool used for analysis, optimization, selection, and validation of your Kinetix Motion Control system.
Product Certifications website, <a href="http://rok.auto/certifications">rok.auto/certifications</a>	Provides declarations of conformity, certificates, and other certification details.
Rockwell Automation Industrial Automation Glossary, publication <a href="#">AG-7.1</a>	A glossary of industrial automation terms and abbreviations.
Industrial Automation Wiring and Grounding Guidelines, publication <a href="#">1770-4.1</a>	Provides general guidelines for installing a Rockwell Automation industrial system.

You can view or download publications at  
<http://www.rockwellautomation.com/global/literature-library/overview.page>.

# Start

Use this chapter to become familiar with the design and installation requirements for the Kinetix® 6000M integrated drive-motor system.

Topic	Page
About the Kinetix 6000M System	11
Typical Hardware Configurations	13
Typical Communication Configurations	18
Catalog Number Explanations	19
Component Compatibility	20
Agency Compliance	21

## About the Kinetix 6000M System

The Kinetix 6000M integrated drive-motor system is designed to provide a Kinetix integrated motion solution for your applications. [Table 1](#) lists the components that can be used to build an integrated solution.

**Table 1 - System Component Overview**

System Component	Cat. No.	Description
IDM Unit	MDF-SBxxxx-Qx8xA-S	Integrated drive-motor (IDM) unit with the safe-off feature. The unit contains a servo drive and motor.
IDM Power Interface Module (IPIM)	2094-SEPM-B24-S	460V AC integrated drive-motor power interface module that resides on the power rail and provides power and communications to the IDM units. The module also monitors power output and provides overload protection.
IDM Hybrid Cables	From the IPIM module to the first IDM unit: 2090-CHBIFS8-12AAxx	Hybrid cable provides power and inter-module communication to each IDM unit via daisy chain.
	From IDM unit to IDM unit: 2090-CHBP8S8-12AAxx	
IDM Network Cables	From the IPIM module to the first IDM unit: 2090-CNNSPRS-AAxx, 2090-CNNSPSS-AAxx	Required to daisy chain the Kinetix 6000M network.
	From IDM unit to IDM unit: 2090-CNNSPRS-AAxx, 2090-CNNSPSS-AAxx, 2090-CNSRPSS-AAxx, 2090-CNSRPRS-AAxx	
Integrated Axis Module	2094-BCxx-Mxx-S (Kinetix 6000) 2094-BCxx-Mxx-M (Kinetix 6200)	460V Integrated Axis Modules (IAM) contains an inverter and converter section.
Axis Module	2094-BMxx-S (Kinetix 6000) 2094-BMxx-M (Kinetix 6200)	Axis Modules (AM) are a shared DC-bus inverter rated for 460V input power. The AM module must be used with an IAM module.
Shunt Module	2094-BSP2	The Bulletin 2094 shunt module mounts to the power rail and provides additional shunting capability in regenerative applications.

**Table 1 - System Component Overview (continued)**

System Component	Cat. No.	Description
Power Rail	2094-PRSx	The Bulletin 2094 power rail consists of copper bus bars and a circuit board with connectors for each module. The power rail provides power and control signals from the converter section to adjacent inverters. The IPIM, IAM, and AM power modules, shunt module, slot-filler modules mount to the power rail.
Power Rail Slot-filler Module	2094-PRF	The Bulletin 2094 slot-filler module is used when one or more slots on the power rail are empty after all other power rail modules are installed. One slot-filler module is required for each empty slot.
Logix Controller Platform	1756-MxxSE CompactLogix™ module 1768-M04SE ControlLogix® module 1784-PM16SE PCI option card	The network interface module/PCI card serves as a link between the ControlLogix/CompactLogix/SoftLogix™ platform and the Kinetix 6000 drive system. The communication link uses the IEC 61491 Serial Real-time Communication System (sercos) protocol over a fiber-optic cable.
RSLogix 5000® Software	9324-RLD300ENE	RSLogix 5000 software provides support for programming, commissioning, and maintaining the Logix family of controllers. Version 20.000 or later is required when using the Kinetix 6000M integrated drive-motor system.
Line Interface Modules	2094-BLxxS 2094-XL75S-Cx	Line interface modules (LIM) include the circuit breakers, AC line filter (catalog number 2094-BL02 only), power supplies, and safety contactor required for Kinetix 6000 operation. The LIM module does not mount to the power rail. You can purchase individual components separately in place of the LIM module.
IDM Unit Digital Input Cables	889D DC Micro	Allows use of sensors (see <a href="#">Digital Input Connectors on page 47</a> ). For Bulletin 889D patchcord specifications, refer <a href="#">Cordsets and Field Attachables Technical Data</a> , publication <a href="#">889-TD002</a> .
Safe-Off Wiring Headers <sup>(1)</sup>	For first drive in multiple safety drive configurations: 2090-XNSM-W  Middle header for drive-to-drive connections in multiple safety drive configurations with three or more drives: 2090-XNSM-M  Safe-off terminating header for the last drive in multiple safety drive configurations: 2090-XNSM-T	Required for various installations of the IPIM module into the Kinetix 6000 servo drive systems.
Sercos Interface Cables	Network fiber-optic plastic cables, regular duty: 2090-SCEPx-x 2090-SCVPx-x 2090-SCNPx-x (harsh duty) Network fiber-optic glass cables: 2090-SCVGx-x Network fiber-optic cable bulkhead adapter: 2090-S-BLHD (2 per pack)	Required for various installations of the IPIM module into the Kinetix 6000 and Kinetix 6200 servo drive systems.
EtherNet/IP™ Interface Cables	RJ45-to-RJ45: 1585J-M8CBJM-xx: RJ45 Insulation Displacement Connector: 1585J-M8CC-H Cable, shielded: 1585-C8CB-Sxxx	Required for various installations of the IPIM module into the Kinetix 6200 servo drive systems.
Cascaded Safety Cables	1202-Cxx (xx = length)	Required accessory to support cascaded safety wiring across multiple modules on the 2094 power rail.
Bulkhead Adapter Kits	Network cable: 2090-CBUSPSS	Provides wall-mount connectors for hybrid and network cables. The connector kit allows signals to pass through a cabinet wall or other physical barrier.
	Hybrid cable: 2090-KPB47-12CF	

(1) See [Appendix A](#) for safety information.

## Typical Hardware Configurations



**SHOCK HAZARD:** To avoid personal injury due to electrical shock, place a 2094-PRF slot-filler module in all empty slots on the power rail. Any power rail connector without a module installed disables three-phase power, however, control power is still present.

Figure 1 - Typical Kinetix 6000M Integrated Drive-motor System





Figure 2 - Typical 2094 Power Rail with Kinetix 6000M System (with LIM)



**Figure 3 - Typical 2094 Power Rail with Kinetix 6000M System (without LIM)**





Figure 4 - Typical Kinetix 6000 with Kinetix 6000M System Common Bus



---

In the following example, the leader IAM module is connected to the follower IAM module via the DC common-bus. When planning your panel layout, you must calculate the total bus capacitance of your DC common-bus system to be sure that the leader IAM module is sized sufficiently to pre-charge the entire system.

See the Kinetix 6000 Multi-axis Servo Drives User Manual, publication [2094-UM001](#), or the Kinetix 6200 and Kinetix 6500 Modular Multi-axis Servo Drives User Manual, publication [2094-UM002](#), for more information.

---

**IMPORTANT** If total bus capacitance of your system exceeds the leader IAM module pre-charge rating and input power is applied, the IAM module status indicator displays an error code.


To correct this condition, you must replace the leader IAM module with a larger module or decrease the total bus capacitance by removing AM or IPIM modules.

---

## Typical Communication Configurations

The Kinetix 6000M IPIM module uses the EtherNet/IP network to report diagnostics to the controller and for firmware upgrades via ControlFLASH™ software. For more information on Ethernet cables, refer to the Industrial Ethernet Media Brochure, publication [1585-BR001](#).

**Figure 5 - Typical Kinetix 6000M, Kinetix 6000 and Kinetix 6200 Network Configuration**



## Catalog Number Explanations

Kinetix 6000M catalog numbers and descriptions are listed in the following tables.

**Table 3 - Power Interface Module (IPIM)**

Cat. No.	Description
2094-SEPM-B24-S	460V IDM Power Interface Module (IPIM) w/Safe-off

**Table 4 - Integrated Drive-motor (IDM)**

Cat. No. (No Brake)	Cat. No. (with Brake)	Description
MDF-SB1003P-QJ82B-S	MDF-SB1003P-QJ84B-S	460V, IEC 100 mm, 5000 rpm, Keyed
MDF-SB1003P-QK82B-S	MDF-SB1003P-QK84B-S	460V, IEC 100 mm, 5000 rpm, Smooth
MDF-SB1153H-QJ82B-S	MDF-SB1153H-QJ84B-S	460V, IEC 115 mm, 3500 rpm, Keyed
MDF-SB1153H-QK82B-S	MDF-SB1153H-QK84B-S	460V, IEC 115 mm, 3500 rpm, Smooth
MDF-SB1304F-QJ82B-S	MDF-SB1304F-QJ84B-S	460V, IEC 130 mm, 3000 rpm, Keyed
MDF-SB1304F-QK82B-S	MDF-SB1304F-QK84B-S	460V, IEC 130 mm, 3000 rpm, Smooth

**Table 5 - Replacement Parts**

Cat. No.	Description
MPF-SST-A3B3 MPF-SST-A4B4 MPF-SST-A45B45	Shaft seal kit for: MDF-SB1003 MDF-SB1153 MDF-SB1304
2094-XNIPIM	IPIM module connectors; includes hybrid DC bus, hybrid communication, safe-off, and enable.
2094-SEPM-FUSE	Fuses for IPIM module, 6 each.
MDF-SB-NODECVR	IDM unit node address switch covers.
1485-M12	IDM unit digital input connector covers.
2090-CTHP8 2090-CTSRP	Terminator: Hybrid Network

**Table 6 - Accessories**

Cat. No.	Description
MPS-AIR-PURGE	Positive air pressure kit.

## Component Compatibility

The Kinetix 6000M integrated drive-motor system is compatible with:

- 400V-class Series B Kinetix 6000 drive systems
- 400V-class Kinetix 6200 drive systems

---

**IMPORTANT** Kinetix 6500 EtherNet/IP control modules (catalog numbers 2094-EN02D-M01-Sx) are not compatible with the Kinetix 6000M IPIM or Kinetix 6000/Kinetix 6200 IAM and AM modules on the same Bulletin 2094 power rail.

---

**IMPORTANT** The IDM system cannot be accessed with DriveExplorer™ or a human interface module (HIM). However, all IDM units respond to a Stop command from a HIM.

---

**Table 7 - IDM System Compatibility**

Component	Requires
RSLinx® software version	RSLinx version 2.590 or greater will fully support the IPIM module after installation of an appropriate EDS file
RSLogix 5000 software	20.010 <sup>(1)</sup> or later
IPIM AOP (Add-on Profile)	1.x
Kinetix 6000 drive firmware	1.123 or later
Kinetix 6200 drive firmware	1.045 or later
ControlLogix EtherNet/IP modules	All 1756 Ethernet modules; 1756-ENBT, 1756-EN2T

(1) Version 20.000 can be used if the motion database is updated to version 8.120. For detailed information about updating the motion database, refer to [RA Knowledgebase](#) article 490160.

## Agency Compliance

If this product is installed within the European Union and has the CE mark, the following regulations apply.



**ATTENTION:** Meeting CE requires a grounded system, and the method of grounding the AC line filter and IDM must match. Failure to do so renders the filter ineffective and can damage the filter.

See [Ground the IDM System](#) on [page 56](#).

For more information on electrical noise reduction, refer to the System Design for Control of Electrical Noise Reference Manual, publication [GMC-RM001](#).

### CE Requirements (system without LIM module)

To meet CE requirements when your system excludes the LIM module, these requirements apply:

- Install an AC line filter (catalog number 2090-XXLF-xxxx) as close to the IAM module as possible.
- Use line filters for 3-phase input power and single-phase control power.
- Use 2090 series cables.
- Use 889 series sensor cables.
- Combined motor power cable length for all axes on the same power rail must not exceed 240 m (787 ft).
- Combined cable length for all IDM units that are connected to one IPIM module is 100 m (328 ft).
- Install the Kinetix 6x00 system inside an enclosure. Run input power wiring in conduit (grounded to the enclosure) outside of the enclosure. Separate signal and power cables.

See the Kinetix 6000 Multi-axis Servo Drives User Manual, publication [2094-UM001](#), or the Kinetix 6200 and Kinetix 6500 Modular Multi-axis Servo Drives User Manual, publication [2094-UM002](#), for interconnect diagrams, including input power wiring.

### CE Requirements (system with LIM module)

To meet CE requirements when your system includes the LIM module, follow the requirements as stated in [CE Requirements \(system without LIM module\)](#) and these additional requirements as they apply to the AC line filter.

- Install the LIM module (catalog numbers 2094-BL02) as close to the IAM module as possible.
- Install the LIM module (catalog numbers 2094-BLxxS, or 2094-XL75S-Cx) with line filter (catalog number 2090-XXLF-xxxx) as close to the IAM module as possible.

When the LIM module (catalog numbers 2094-BLxxS, or 2094-XL75S-Cx) supports two IAM modules, each IAM module requires an AC line filter that is installed as close to the IAM module as possible.

**Notes:**

## Plan the Kinetix 6000M System Installation

This chapter describes system installation guidelines that are used in preparation for mounting your Kinetix® 6000M components.

Topic	Page
Cable Length Restrictions and System Sizing	23
IPIM Module Design Guidelines	24
IDM Unit Design Guidelines	28
Electrical Noise Reduction	29



**ATTENTION:** Plan the installation of your system so that you perform all cutting, drilling, tapping, and welding with the system removed from the enclosure. Because the system is of the open type construction, be careful to keep any metal debris from falling into it. Metal debris or other foreign matter can become lodged in the circuitry, which can result in damage to components.

### Cable Length Restrictions and System Sizing

This section provides guidelines for sizing an IDM system. For accurate, detailed sizing, use Motion Analyzer software version 6.000 or later. For more information and a sizing estimation method, refer to [Kinetix 6000M System Sizing on page 131](#).

When sizing your system, note the following:

- Motion Analyzer software (version 6.000 or later), should be used for sizing your system.
- Maximum cable length between IDM units is 25 m (82 ft).
- Combined cable length for all IDM units that are connected to one IPIM module is 100 m (328 ft).
- Combined motor power and hybrid cable length for all axes on the same power rail must not exceed 240 m (787 ft).
- The number of IDM units also depends on the use of the safe-off function. See [Kinetix 6000M Safe Torque-off Feature on page 107](#) for details.

The following items limit the number of IDM units that can be used in a system.

1. The IDM unit control power load, which consists of three load sources:
  - internal load (constant)
  - parking brake load
  - digital input loading.These items also affect the total control power load:
  - The cable lengths between IDM units
  - IDM units with brakes and their location in the daisy chain
  - IDM units that use digital inputs.
2. The continuous and intermittent load on the DC bus of all AM modules and IDM units.

**IMPORTANT** The Kinetix 6000 or Kinetix 6200 IAM module supplying DC bus power to the IDM units should be sized to support all IDM units that are connected to the power rail. Motion Analyzer software (version 6.000 or later) sizing analysis accounts for control power and DC bus power.

---

3. The total number of axes that are connected in the safe-off circuit.

## IPIM Module Design Guidelines

Use the information in this section when designing your enclosure and planning to mount your system components.

For online product selection and system configuration tools, including AutoCAD (DXF) drawings of the product, refer to website <http://www.rockwellautomation.com/global/support/selection.page>

### System Mounting Requirements

- To comply with UL and CE requirements, the Kinetix 6000M power interface module must be part of a Kinetix 6000 or Kinetix 6200 system that is enclosed in a grounded conductive enclosure offering protection as defined in standard EN 60529 (IEC 529) to IP2X such that they are not accessible to an operator or unskilled person. A NEMA 4X enclosure exceeds these requirements providing protection to IP66.
- The panel that you install inside the enclosure for mounting your system components must be on a flat, rigid, vertical surface that is not subjected to shock, vibration, moisture, oil mist, dust, or corrosive vapors.
- Size the enclosure so as not to exceed the maximum ambient temperature rating. Consider heat dissipation specifications for all components.
- Use high-frequency (HF) bonding techniques to connect the modules, enclosure, machine frame, and motor housing, and to provide a low-impedance return path for high-frequency (HF) energy and reduce electrical noise.

- Combined motor power cable lengths for all axes and hybrid cable lengths for all IDM units on the same DC bus must not exceed 240 m (787 ft) with 400V-class systems. Drive-to-motor power cables must not exceed 90 m (295.5 ft).

---

**IMPORTANT** System performance was tested at these cable length specifications. These limitations also apply when meeting CE requirements.

---

See the System Design for Control of Electrical Noise Reference Manual, publication [GMC-RM001](#), to better understand the concept of electrical noise reduction.

## Circuit Breaker/Fuse Options

The 2094-SEPM-B24-S IPIM module and the MDF-SBxxxx IDM units use internal solid-state motor short-circuit protection and when protected by suitable branch circuit protection, are rated for use on a circuit capable of delivering up to 200,000 A. Fuses or circuit breakers, with adequate withstand and interrupt ratings, as defined in NEC or applicable local codes, are permitted.


The 2094-BL02 LIM module contains supplementary protection devices and, when protected by suitable branch circuit protection, are rated for use on a circuit capable of delivering up to 5000 A. When these modules are used, protection on the line side of the LIM module is required. Fuses must be class J or CC only.

The 2094-BLxxS, and 2094-XL75S-Cx LIM modules contain branch circuit rated devices suitable for use on a circuit capable of delivering up to 65,000 A (400V-class).

See the Line Interface Module Installation Instructions, publication [2094-IN005](#), for power specifications and more information on using the LIM module.

### *Fuse Location and Replacement*

The IPIM module uses internal fuses (see [Figure 6](#)) for short-circuit protection of the DC bus. The recommended fuse is Bussmann FWP-50A14Fa. A fuse replacement kit (catalog number 2094-SEPM-FUSE) is also available.

**Figure 6 - IPIM Fuse Location**

**ATTENTION:** Capacitors on the DC bus can retain hazardous voltages after input power has been removed. Before working on the IDM system, wait the full time interval as indicated in the warning on the IPIM module. Failure to observe this precaution could result in severe bodily injury or loss of life.

To replace the fuses, follow these steps.

1. Make sure that all power to the power rail has been removed.
2. Wait the full time interval as indicated in the warning on the IPIM module.
3. Loosen the captive screws.
4. Grasp the top and bottom edges of the fuse holder and pull straight out.
5. Replace the fuses.

## Enclosure Selection

Heat dissipation of the IPIM module is shown in [Table 8](#) and [Table 9](#). To size the enclosure you need heat dissipation data from all equipment inside the enclosure (such as the Logix controller, LIM module, IAM). Once the total amount of heat dissipation (in watts) is known, you can calculate the minimum enclosure size.

See the Kinetix 6000 Multi-axis Servo Drives User Manual, publication [2094-UM001](#), or the Kinetix 6200 and Kinetix 6500 Modular Multi-axis Servo Drives User Manual, publication [2094-UM002](#), for further information.

**Table 8 - Power Dissipation Specifications - Percent of DC Bus Current**

Power Dissipation as % of DC Bus Current Output Rating Watts					Heat Dissipation Formula <sup>(1)</sup>
20%	40%	60%	80%	100%	
2	7	14	25	38	$Y = 33.95x^2 + 3.18x$

(1)  $x$  is percent of DC bus current output rating: any value from 0.0 to 1.0.**Table 9 - Power Dissipation Specifications - Percent of IPIM Module Control Power**

Control Power Input		Power Dissipation as % of IPIM Module Control Power Output Rating Watts					Heat Dissipation Formulas <sup>(1)</sup>
Frequency Hz	Voltage AC	20%	40%	60%	80%	100%	
50	120V	22	29	38	48	61	$Y = 23.76x^2 + 20.73x + 16.54$
	240V	34	42	52	63	76	$Y = 18.56x^2 + 30.19x + 27.41$
60	120V	23	27	32	39	46	$Y = 14.57x^2 + 11.40x + 20.01$
	240V	38	49	62	76	92	$Y = 19.63x^2 + 43.22x + 28.75$

(1)  $x$  is percent of IPIM module control power output rating: any value from 0.0 to 1.0.

## Minimum Clearance Requirements


This section provides information to assist you in sizing your cabinet and positioning your IPIM module.

[Figure 7](#) illustrates minimum clearance requirements for proper airflow and installation:

- More clearance is required for the cables and wires that are connected to the top and front of the module.
- More clearance that is left and right of the power rail is required when the module is mounted near noise sensitive equipment or clean wireways.

**Table 10 - Minimum Cabinet Depth**

Cat. No.	Cabinet Depth, Min
2094-SEPM-B24-S	272 mm (10.7 in.)

**Figure 7 - Minimum IPIM Module Clearance Requirements**

(1) The power rail (slim), catalog number 2094-PRSx, extends left and right of the first and last module 5.0 mm (0.20 in.). The Bulletin 2094-PRx power rail extends approximately 25.4 mm (1.0 in.) left of the IAM module and right of the last module that is mounted on the rail.

(2) Dimension applies to the following modules:

IPIM module 2094-SEPM-B24-S

IAM module (Series B) 2094-BC01-Mxx-x and 2094-BC02-M02-x

AM module (Series B) 2094-BMP5-x, 2094-BM01-x, 2094-BM02-x

## IDM Unit Design Guidelines

[Figure 8](#) illustrates minimum IDM unit clearance requirements for proper airflow and installation.




**BURN HAZARD:** Outer surfaces of the motor can reach high temperatures, 125 °C (275 °F), during motor operation.

Take precautions to prevent accidental contact with hot surfaces. Consider IDM unit surface temperature when selecting motor mating connections and cables.

Failure to observe these safety procedures could result in personal injury or damage to equipment.

Additionally, consider the following items:

- Obtain the specified motor thermal rating by mounting the motor on a surface with heat dissipation equivalent to a 304.8 x 304.8 x 12.7 mm (12 x 12 x 0.5 in.) aluminum heatsink.
- Do not install the motor in an area with restricted airflow, and keep other devices that produce heat away from the motor.

**Figure 8 - Minimum IDM Unit Clearance Requirements**

## Electrical Noise Reduction


See the Kinetix 6000 Multi-axis Servo Drives User Manual, publication [2094-UM001](#), or the Kinetix 6200 and Kinetix 6500 Modular Multi-axis Servo Drives User Manual, publication [2094-UM002](#), for information on best practices that minimize the possibility of noise-related failures as they apply specifically to Kinetix 6000 system installations. For more information on the concept of high-frequency (HF) bonding, the ground plane principle, and electrical noise reduction, refer to the System Design for Control of Electrical Noise Reference Manual, publication [GMC-RM001](#).

Observe these guidelines when your system includes the 2094-SEPM-B24-S IPIM module. In this example, a 2094-BL02 LIM module is used in the Bulletin 2094 system and mounted left of the IAM module:

- Establish clean (C) and dirty zones (D) similar to other Bulletin 2094 drive systems.
- The sercos fiber-optic cables are immune to electrical noise, but due to their delicate nature, route them in the clean zone.
- IPIM communication wires are noise sensitive and belong with the fiber-optic cables in the clean zone.
- Ethernet cables are noise sensitive and belong in the clean zone.
- IDM network cables, although noise sensitive by nature, are shielded and designed to be routed with the hybrid cable outside of the enclosure.
- The Bulletin 2090 hybrid cable is dirty and belongs in the dirty zone.

This layout is preferred due to the reduced size of the very dirty zone.

Figure 9 - Noise Zones (Bulletin 2094 power rail with IPIM module)



(1) If drive system I/O cable contains (dirty) relay wires, route cable with LIM module I/O cable in dirty wireway.  
 (2) When space does not permit the 150 mm (6.0 in.) segregation, use a grounded steel shield instead. For examples, refer to the System Design for Control of Electrical Noise Reference Manual, publication [GMC-RM001](#).

## Cable Categories for Kinetix 6000M System

Zoning requirements of cables connecting to the IDM system components are shown in [Table 11](#).

Table 11 - IPIM Module Zoning Requirements

Wire/Cable	Zone			Method	
	Very Dirty	Dirty	Clean	Ferrite Sleeve	Shielded Cable
Hybrid DC bus power, control power, inter-module communication, and safe-off <sup>(1)</sup>		X			X
		X			X
		X			
Enable input			X		X
Fiber-optic	No restrictions				
Ethernet network			X		X
IDM network <sup>(1)</sup>			X		X

(1) Making your own hybrid or IDM network cables is not an option.

## **Mount the Kinetix 6000M System**

This chapter provides the system installation procedures for mounting your Kinetix® 6000M integrated drive-motor (IDM) unit and your power interface module (IPIM).

<b>Topic</b>	<b>Page</b>
Mount the IPIM Module	32
Install the IDM Unit	35

This procedure assumes that you have prepared your panel, mounted your Bulletin 2094 power rail, and understand how to bond your system. For installation instructions regarding equipment and accessories that are not included here, refer to the instructions that came with those products.



**SHOCK HAZARD:** To avoid hazard of electrical shock, perform all mounting and wiring of the Bulletin 2094 power rail and modules before applying power. Once power is applied, connector terminals can have voltage present even when not in use.



**ATTENTION:** Plan the installation of your system so that you can perform all cutting, drilling, tapping, and welding with the system removed from the enclosure. Because the system is of the open type construction, be careful to keep any metal debris from falling into it. Metal debris or other foreign matter can become lodged in the circuitry, which can result in damage to components.

## Mount the IPIM Module

## Using the 2094 Mounting Brackets

You can use Bulletin 2094 mounting brackets to mount the power rail or LIM module over the AC line filter. See the 2094 Mounting Brackets Installation Instructions, publication [2094-IN008](#), when using mounting brackets with your system.

### Install the 2094 Power Rail

The Bulletin 2094 power rail comes in lengths to support one IAM module and up to seven additional modules. A maximum of four IPIM modules can be mounted to one power rail. The connector pins for each slot are covered by a protective cover. The cover is designed to help protect the pins from damage and make sure that no foreign objects lodge between the pins during installation. See the Kinetix 6000 Power Rail Installation Instructions, publication [2094-IN003](#), when installing your power rail.



**ATTENTION:** To avoid damage to the power rail during installation, do not remove the protective covers until the module for each slot is ready for mounting.

### Determine Mounting Order


See the [Module Mounting Order Example](#) diagram on [page 33](#) and mount the modules in the order (left to right) shown. Install modules according to power utilization (highest to lowest) from left to right starting with the highest power utilization. If power utilization is unknown, position modules (highest to lowest) from the left to the right based on the IPIM or AM continuous power rating (kW).

Power utilization is the average power (kW) consumed by a servo axis. If the servo axis has been sized by using Motion Analyzer software, version 6.000 or later, the calculated axis power required can be used for power utilization. If the servo axis has not been sized in Motion Analyzer, use [Table 12](#), showing the maximum continuous power for IPIM and AM modules, to determine the desired location on a power rail.

**Table 12 - Module Type and Continuous Power Output**

2094-BM05-S Axis Module	2094-SEPM-B24-S IPIM Module	2094-BM03-S Axis Module	2094-BM02-S Axis Module	2094-BM01-S Axis Module	2094-BMP5-S Axis Module
22.0 kW	15.0 kW	13.5 kW	6.6 kW	3.9 kW	1.8 kW

The IPIM module can be installed on a power rail with an IAM module configured as a common bus follower, but you will be responsible for configuring the leader for the appropriate additional capacitance in the follower power rail, including the IPIM module.

**Figure 10 - Module Mounting Order Example**

**IMPORTANT** The IAM must be positioned in the leftmost slot of the power rail. Position your other modules to the right of the IAM module.

Mount modules according to power utilization (highest to lowest) from left to right starting with the highest power utilization. If power utilization is unknown, position modules (highest to lowest) from left to right based on continuous power rating (kW). See [page 32](#).

The shunt module must be installed to the right of the last module. Only slot-filler modules can be installed to the right of the shunt module.

Do not mount the shunt module on power rails with a follower IAM module. Common bus follower IAM modules disable the internal, rail mounted, and external shunt modules.



**SHOCK HAZARD:** To avoid personal injury due to electrical shock, place a 2094-PRF slot-filler module in all empty slots on the power rail. Any power rail connector without a module installed will disable the drive system; however, control power will still be present.

## Mount the IPIM Module

All modules mount to the power rail using the same technique.


1. Determine the next available slot and module for mounting. See [Determine Mounting Order](#) on [page 32](#).
2. Remove the protective covers from the power rail connectors.
3. Inspect the module connector pins and power rail connectors and remove any foreign objects.




**ATTENTION:** To avoid damage to the pins on the back of each module and to make sure that module pins mate properly with the power rail, hang modules as explained below.

The power rail must be mounted vertically on the panel before hanging modules on the power rail.

4. Hang the module mounting bracket from the slot on the power rail.




5. Pivot module downward and align the guide pin on the power rail with the guide pin hole in the back of the module.



6. Gently push the module against the power rail connectors and into the final mounting position.

---

7. Tighten the mounting screws.



8. Repeat the previous steps for each module being installed.

## Install the IDM Unit



**ATTENTION:** Do not attempt to open or modify the IDM unit. This manual describes modifications that you can perform in the field. Do not attempt other changes. Only a qualified Allen-Bradley® employee can service an IDM unit.

Failure to observe these safety procedures could result in personal injury or damage to equipment.



**ATTENTION:** Damage can occur to the bearings and the feedback device if a sharp impact is applied to the shaft during installation of couplings and pulleys, or to remove the shaft key. Damage to the feedback device can also result from applying leverage from the faceplate to remove devices mounted on the shaft.

Do not strike the shaft, key, couplings, or pulleys with tools during installation or removal. Use a wheel puller to apply pressure from the user end of the shaft to remove any friction fit or stuck device from the shaft.

Failure to observe these safety procedures could result in damage to the IDM unit.

## Align the IDM Unit

The IDM unit can be mounted in any position and has a mounting pilot that aids in aligning the unit on a machine. A shaft seal that helps protect the motor against fine dust and fluids is factory installed and should be replaced at regular intervals.

Preferred fasteners are stainless steel. The installation must comply with all local regulations. The installer also must use equipment and installation practices that promote electromagnetic compatibility and safety.



**ATTENTION:** Unmounted IDM units, disconnected mechanical couplings, loose shaft keys, and disconnected cables are dangerous, if power is applied. Disassembled equipment should be appropriately identified (tagged-out) and access to electrical power restricted (locked-out). Before applying power, remove the shaft key and other mechanical couplings that could be thrown from the shaft. Failure to observe these safety procedures could result in personal injury or damage to equipment.

## Mount and Connect the IDM Unit

To install the IDM unit, follow these procedures and recommendations.



**ATTENTION:** Arcing or unexpected motion can occur if cables are connected or disconnected while power is applied to the IDM system. Before working on the system, disconnect power and wait the full time interval indicated on the IPIM module warning label or verify the DC bus voltage at the IPIM module measures less than 50V DC. Failure to observe this precaution could result in severe bodily injury or loss of life, and damage to the product will occur.



**ATTENTION:** Do not strike the shaft, couplings, or pulleys with tools during installation or removal. Damage can occur to the motor bearings and the feedback device if you apply a sharp impact to the shaft during installation of couplings and pulleys, or a shaft key. Failure to observe these safety procedures could result in damage to the motor and its components.



**ATTENTION:** The IDM unit is not for direct connection to an AC power line. IDM units are designed for connection to an IPIM module that controls the application of power. Failure to observe these safety precautions could result in damage to the motor and equipment.

1. Allow sufficient clearances around the IDM unit for it to stay within its specified operating temperature range. See [page 29](#) for details.



**BURN HAZARD:** Outer surfaces of the IDM unit can reach high temperatures, 125 °C (275 °F), during motor operation.

Take precautions to prevent accidental contact with hot surfaces. Consider IDM unit surface temperature when selecting motor mating connections and cables.

Failure to observe these safety procedures could result in personal injury or damage to equipment.

2. Determine the radial and axial shaft load limitations of your motor. See the Kinetix Rotary Motion Specifications Technical Data, publication [KNX-TD001](#), for specifications.
3. Set the node address for the IDM unit. See [Set the Node Address](#) on [page 72](#).
4. If sufficient mounting clearance is provided, rotate the hybrid cable connectors into position prior to installing. If the mounting clearance is restricted, rotate after installing.



**ATTENTION:** Connectors are designed to be rotated into a fixed position during motor installation, and remain in that position without further adjustment. Strictly limit the applied forces and the number of times the connector is rotated to make sure that connectors meet the specified IP ratings.

Apply force only to the connector and cable plug. Do not apply force to the cable extending from the cable plug. No tools, for example pliers or vise-grips, should be used to assist with the rotation of the connector.

Failure to observe safety precautions could result in damage to the IDM unit and its components.

5. Position the IDM unit on the machine in any position.

**TIP** IDM units with a brake may require use of the manual brake release cable to release the brake prior to rotating the shaft so the IDM unit will align with the machine mounts.

See the Manual Brake Release Cable Installation Instructions, publication [2090-IN037](#), for details on using this cable.

6. Properly mount and align the IDM unit using stainless steel bolts. See the Kinetix Rotary Motion Specifications Technical Data, publication [KNX-TD001](#), for dimensions.

**Notes:**


## Kinetix 6000M System Connector Data

This chapter provides connector locations and signal descriptions for your Kinetix® 6000M integrated drive-motor system.

Topic	Page
IPIM Module Connectors and Indicators	40
IPIM Module Connector and Signal Descriptions	41
IDM Unit Connectors and Indicators	45
IDM Unit Connector and Signal Descriptions	46
Power Specifications	52
Feedback Specifications	54

## IPIM Module Connectors and Indicators

Figure 11 - Module Connectors and Indicators




Item	Description	Page
①	Hybrid cable DC bus connector	Termination point for +/- DC and PE
②	Hybrid cable communication signals connector	Connection point for IDM unit power and communication
③	Safe-off connector	Termination point for safety signals
④	Enable connector	Enable input to the IDM system
⑤	Sercos fiber-optic connectors	Transmit and receive fiber-optic connectors
⑥	LCD display	Allows Ethernet configuration and system status
⑦	Navigation buttons	Four buttons provide access and navigation when using the LCD display
⑧	Status indicators DC Bus Control Bus Port 1 and Port 2 Module Status Network Status	DC bus status Control bus status (present, faulted) Communication status of the EtherNet/IP™ ports IPIM module status (operating, standby, faulted) Indicates IDM system network status
⑨	EtherNet/IP ports	Two Ethernet ports are provided
⑩	IDM network cable connector	Connection point for network cable to first IDM unit

## IPIM Module Connector and Signal Descriptions

### Hybrid Cable DC Bus Connector


This connector supplies the DC bus voltage. Three wires from the hybrid power and communication cable (catalog number 2090-CHBIFS8-12AAxx) are used to extend this voltage to the first IDM unit.



Terminal	Description	Signal		Strip Length mm (in.)	Torque N·m (lb·in)
1	DC bus supply (-)	DC-	DC-	9.7 (0.38)	0.75 (6.6)
2	Chassis ground	$\frac{1}{-}$	$\frac{1}{-}$		
3	DC bus supply (+)	DC+	DC+		

### Hybrid Cable Communication Signals Connector


The hybrid communication connector extends control power, communication, and safety signals to the first IDM unit. The 2090-CHBIFS8-12AAxx cable interfaces with this connector.



Terminal	Description	Signal		Strip Length mm (in.)	Torque N·m (lb·in)
1	Shield	-	SH1	6.4 (0.25)	0.235 (2.0)
2	Control Power +42V DC	42V +	42+		
3	Control Power -42V DC	42V COM	42-		
4	CAN Bus Shield	IDM CAN SHIELD	SH2		
5	IDM CAN Bus Lo	IDM CAN LO	CN-		
6	IDM CAN Bus Hi	IDM CAN HI	CN+		
7	System OK out to IDMs	IDM SYSOKOUT	OUT		
8	System OK return from IDMs	IDM SYSOKRTN	RTN		
9	Safety Shield	SAFETY SHIELD	SH3		
10	Safety Enable Input 1	SAFETY ENABLE 1+	SE1		
11	Safety Enable Common	SAFETY ENABLE-	SE-		
12	Safety Enable Input 2	SAFETY ENABLE 2+	SE2		

## Safe Torque-off Connector

This connector provides a termination point for connecting safety devices such as: emergency stop switches, light curtains, and floor mats. The redundant safety device outputs should be connected to Safety Enable Input 1 and 2 with reference to Safety Enable Common.



Each IPIM module ships with the wiring-plug header and motion-allowed jumper installed in the safe torque-off connector.

**IMPORTANT** With the motion-allowed jumper installed, the safe torque-off function is defeated.

**IMPORTANT** Pins 8 and 9 (24V+) are used only by the motion-allowed jumper. When wiring to the wiring-plug header, **the 24V supply** (for an external safety device that triggers the safe torque-off request) **must come from an external source**, otherwise system performance will be jeopardized.

This connector extends the safe-off signals for use in wiring single and multiple safe torque-off configurations, or to bypass (not use) the safe torque-off function. See [page 111](#) for further information.

Terminal	Description	Signal		Strip Length mm (in.)	Torque N·m (lb·in)	Min/Max Wire Size <sup>(3)</sup> mm <sup>2</sup> (AWG)
1	Feedback Monitoring 2+	FDBK2+ <sup>(1)</sup>	F2+	7.0 (0.275)	0.235 (2.0)	0.14...1.5 (30...14)
2	Feedback Monitoring 2-	FDBK2- <sup>(1)</sup>	F2-			
3	Feedback Monitoring 1+	FDBK1+ <sup>(1)</sup>	F1+			
4	Feedback Monitoring 1-	FDBK1- <sup>(1)</sup>	F1-			
5	Safety Enable Input 2	SAFETY ENABLE 2+	SE2			
6	Safety Enable Common	SAFETY ENABLE-	SE-			
7	Safety Enable Input 1	SAFETY ENABLE 1+	SE1			
8	Safety Bypass Supply, +24V DC, 320 mA max	24+ <sup>(2)</sup>	24+			
9	Safety Bypass supply, Common	24V COM <sup>(2)</sup>	24-			


(1) Feedback monitoring terminals are provided for compatibility with the Kinetix 6000 safety connector only.

(2) See [page 111](#) for information on the proper use of these terminals.

(3) Maximum/minimum that the connector will accept—these are not recommendations.

## Sercos Fiber-optic Connectors

The sercos fiber-optic ring is connected by using the sercos receive (RX) and transmit (TX) connectors.




**ATTENTION:** To avoid damage to the sercos RX and TX connectors use only finger-tight torque when attaching the fiber-optic cables. Do not use a wrench or any other mechanical assistance. For more information, see Fiber Optic Cable Installation and Handling Instructions, publication [2090-IN010](#).

**Table 13 - Sercos Specifications**

Attribute	Value
Data rates	8 Mbps (fixed)
Light intensity	Adjustable, low or high power, selectable via the keypad/LCD display (see <a href="#">page 70</a> ).
Cyclic update period	500 µs, minimum
Node addresses	Assigned on each IDM unit, see <a href="#">page 72</a> . The IPIM module does not have a sercos address since it is not a sercos device.

## Enable Input



One digital input is supplied to enable all connected IDM units. The enable status is transmitted to all of the IDM units.

Terminal	Description	Signal		Strip Length mm (in.)	Torque N·m (lb·in)	Min/Max Wire Size <sup>(1)</sup> mm <sup>2</sup> (AWG)
1	+24V DC Enable Supply	ENABLE 24V+	+	7.0 (0.275)	0.235 (2.0)	0.14...1.5 (30...14)
2	Enable Input	ENABLE INPUT	EN			
3	24V DC Common	ENABLE 24V COM	-			


(1) Maximum/minimum wire size that the connector accepts (not recommendations).

**Table 14 - Enable Input Specifications**


Signal	Description	IDM Unit Reaction Time	Edge/Level Sensitive
ENABLE	Optically isolated, single-ended active high signal. Current loading is nominally 10 mA. A 24V DC input is applied to this terminal to enable all modules. The reaction time for all IDM units connected to the IPIM is 30 ms, maximum.	30 ms	Level

## EtherNet/IP Connectors

Two connectors are provided for firmware upgrades, troubleshooting, and integration with Logix. The Ethernet ports also support a web browser interface to provide access to status information for the IPIM module and IDM units.





8-pin Control Module Ethernet Connector



Pin	Signal Description	Signal Name
1	Transmit+	TD+
2	Transmit-	TD-
3	Receive+	RD+
4	Reserved	—
5	Reserved	—
6	Receive-	RD-
7	Reserved	—
8	Reserved	—

## IPIM Module Network Connector Pinouts


The IDM system network is routed by using 2090-CNSxPxS-AAxx cables. A 2090-CNSSPRS-AAxx or 2090-CNSSPSS-AAxx cable is required for connection to the IPIM module. The connector type is B-coded M12.

Pin	Signal Description	Signal Name
1	Transmit (TX+) to IDM unit	TX+
2	Return (RX-) from IDM unit	RTN RX-
3	Return (RX+) from IDM unit	RTN RX+
4	Transmit (TX-) to IDM unit	TX-
5	Reference signal	REF

## IDM Unit Connectors and Indicators

Figure 12 - Integrated Drive-motor Unit Features, Connectors, and Indicators




Item	Description	Page	
❶	Hybrid cable input connector (from IPIM module or previous IDM unit)	Input and output connecting points for the Hybrid Power and Communication cables.	41
❷	Hybrid cable output connector (to IDM unit)		
❸	IDM network output connector (to IDM unit)	Input and output connecting points for the IDM network cables.	41
❹	IDM network input connector (from IPIM module or previous IDM unit)		
❺	Drive status indicator	Provides communication status for the IDM unit.	93
❻	Network status indicator	Provides general status for the IDM unit.	93
❼	HOME Digital Input (connector 3)	Digital input for home.	47
⽿	REG1/OT+ Digital Input (connector 2)	Registration1/positive overtravel digital input.	47
⽻	REG2/OT- Digital Input (connector 1)	Registration2/negative overtravel digital input.	47
⽾	Node address switch S10 – 10's digit (most significant)	Sets the IDM network node address.	72
⽿	Node address switch S1 – 1's digit (least significant)		


## IDM Unit Connector and Signal Descriptions

The following information provides connector pinouts for the IDM unit connectors.

### Hybrid Cable Connector


		Input Connector	Output Connector
Pin	Description	Signal Name	Signal Name
A	DC Bus +	DC +	DC +
B	DC Bus -	DC -	DC -
C	Control Power +42V DC	42V +	42V +
D	Control Power -42V DC	42V COM	42V COM
E	Chassis Ground	$\underline{\underline{}}_{\underline{\underline{}}}$	$\underline{\underline{}}_{\underline{\underline{}}}$
1	Reserved	Reserved	Reserved
2	Brake Override 24V Supply	BRAKE +24V	
3	Brake Override Supply Common	BRAKE 24V COM	
4	Safety Enable Input 1	SAFETY ENABLE 1+	SAFETY ENABLE 1+
5	Safety Enable Common	SAFETY ENABLE-	SAFETY ENABLE-
6	Safety Enable Input 2	SAFETY ENABLE 2+	SAFETY ENABLE 2+
7	IDM CAN Bus Hi	IDM CAN HI	IDM CAN HI
8	IDM CAN Bus Lo	IDM CAN LO	IDM CAN LO
9	System OK from IPIM or prior IDM	IDM SYSOKIN	IDM SYSOKOUT
10	System OK return to IPIM	IDM SYSOKRTN	IDM SYSOKRTN

## IDM Network Input and Output Connector Pinouts

		Input Connector	Output Connector
Pin	Signal Name	Signal Name	Signal Name
1	RX+	TX+	
2	RTN TX-	RTN RX+	
3	RTN TX+	RTN RX-	
4	RX-	TX-	
5	REF	REF	

## Digital Input Connectors

Three digital input connectors allow sensors to be easily connected to the system without the need to route cables back to the control enclosure.



The connectors accommodate common input functions, including the following:

- Home, negative overtravel and positive overtravel inputs
- Two registration inputs

If the digital inputs are not being used for their assigned functions, they can also be used as general-purpose inputs by reading the status of their tags in the application program.

24V DC is supplied at each input for the purpose of registration, home, enable, overtravel positive, and overtravel negative inputs. These are sinking inputs that require a sourcing device. A 24V DC power and common connection is provided for each input. A total of 200 mA is supplied for all three input connectors.




IDM units have three 5-pin, M12, digital input connectors. Allen-Bradley® (Bulletin 889D) DC micro-style patchcords, splitters, and V-cables are available with straight and right-angle connectors for making connections from the IDM unit to input sensors.

For Bulletin 889D patchcord specifications, refer Cordsets and Field Attachables Technical Data, publication [889-TD002](#).

**IMPORTANT** Unused input connectors must have protective covers installed to maintain the IDM IP rating. Torque each cover to 0.6 N·m (5 lb·in) to help ensure a tight seal.

**IMPORTANT** To improve registration input EMC performance, refer to the System Design for Control of Electrical Noise Reference Manual, publication [GMC-RM001](#).

**IMPORTANT** Overtravel limit input devices must be normally closed.


	Digital Input Connector 1 Overtravel -/Registration 2	Digital Input Connector 2 Overtravel +/Registration 1	Digital Input Connector 3 Home
			
Pin	Signal Name	Signal Name	Signal Name
1	24V +	24V+	24V+
2	Overtravel -	Overtravel +	Reserved
3	24V COM	24V COM	24V COM
4	Registration 2	Registration 1	HOME
5	Shield/Chassis Ground	Shield/Chassis Ground	Shield/Chassis Ground

The IDM unit only supports PNP (active high or sourcing) inputs.

#### *Single Normally Closed (NC) Sensor Connection*


Normally closed sensors are used for limit (overtravel) switches on the IDM unit. Any 4-pin or 5-pin, M12, A-code, 1-1 pass through cable can be used to connect a normally closed sensor. See [Figure 13](#).

**Figure 13 - Single NC Sensor Connection Example**




#### *Single Normally Open (NO) Sensor Connection*

Normally open sensors are used for registration or home switches on the IDM unit. Any 4-pin or 5-pin, M12, A-code, 1-1 pass through cable can be used to connect a normally open sensor. See [Figure 14](#).

**Figure 14 - Single NO Sensor Connection Example***Combined NC & NO Sensor Connection*


There may be applications where two sensors must be connected to a one input connector. Typically, a limit switch (NC) is connected to pin 2 and a registration switch (NO) to pin 4 of the connector.

In the figure below the 889D-x4ACDx-xx patchcord swaps the NC signal from pin 2 to pin 4. The micro splitter then swaps it back for proper connection to pin 2 of the IDM input connector. The NO sensor goes straight through on pin 4.


**Figure 15 - Combined NO & NC Sensor Connection Using a Micro Splitter**

*Digital Input Cable Examples*

**Figure 16 - Digital Inputs Used for Home and Overtravel Functions**



**Figure 17 - Digital Inputs Used for Home, Overtravel, and Registration Functions**




**Table 15 - Understanding the Digital Inputs**


Pin	Connector	Signal	Description	Capture Time	Edge/Level Sensitive
4	3	HOME	Optically isolated, single-ended active high signal. Current loading is nominally 10 mA. Home switch (normally open contact) inputs for each axis require 24V DC (nominal).	30 ms	Level
4	1/2	REG1 REG2	Fast registration inputs are required to inform the motor interface to capture the positional information with less than 4 $\mu$ s uncertainty. Optically isolated, single-ended active high signal. Current loading is nominally 10 mA. A 24V DC input is applied to this terminal.	500 ns	Edge
2	1/2	OT+ OT-	Overtravel detection is available as an optically isolated, single-ended active high signal. Current loading is nominally 10 mA per input. The pos/neg limit switch (normally closed contact) inputs for each axis require 24V DC (nominal).	30 ms	Level

**Table 16 - Digital Input Specifications**

Parameter	Description	Min	Max
On-state voltage	Voltage applied to the input, with respect to Iocom, to assure an on-state.	21.6V	26.4V
	REG1 and REG2	21.6V	26.4V
On-state current	Current flow to guarantee an on-state.	3.0 mA	10.0 mA
Off-state voltage	Voltage applied to the input, with respect to Iocom, to assure an off-state.	-1.0V	3.0V

**Figure 18 - Standard Digital Input Circuits**

(1) 24V DC source (range) = 21.6V - 26.4V (supplied by IPIM, not to exceed 250 mA total). Maximum current input = 10 mA.

**Figure 19 - High-Speed Digital Input Circuits**

## Power Specifications



**ATTENTION:** To guard against personal injury and/or component damage, the brake override must only be used for machine assembly when the IPIM module is **not** connected to the IDM unit.

### Brake Override Input

The brake override connection is made on two dedicated pins of the hybrid input connector. The hybrid cable has no connection on those pins.

The brake override may only be activated when the hybrid input cable is not connected. A brake override cable is attached at the location where the hybrid input cable would normally be attached.

Two connections are required for the motor/brake override input power. Connections are rated for +24V and current as shown in the following table. An active signal releases the motor brake.

**Table 17 - Brake Specification**




Specification	Value
Nominal brake voltage	24 V DC
Minimum voltage	21.6 V DC
Maximum voltage	27.6 V DC
Maximum brake current	650 mA

### Peak Duty Cycle

**Table 18 - Peak Duty Cycle Definition of Terms**

Term	Definition <sup>(1)</sup>
Continuous Current Rating ( $I_{\text{Cont}}$ )	The maximum value of current that can be output continuously.
Peak Current Rating ( $I_{\text{PKmax}}$ )	The maximum value of peak current that the drive can output. This rating is valid only for overload times less than $T_{\text{PKmax}}$ .
Duty Cycle (D)	The ratio of time at peak to the Application Period and is defined as: $D = \frac{T_{\text{PK}}}{T} \times 100\%$
Time at Peak ( $T_{\text{PK}}$ )	The time at peak current ( $I_{\text{PK}}$ ) for a given loading profile. Must be less than or equal to $T_{\text{PKmax}}$ .
Peak Current ( $I_{\text{PK}}$ )	The level of peak current for a given loading profile. $I_{\text{PK}}$ must be less than or equal to the Peak Current Rating ( $T_{\text{PKMAX}}$ ) of the drive.
Base Current ( $I_{\text{Base}}$ )	The level of current between the pulses of peak current for a given loading profile. $I_{\text{Base}}$ must be less than or equal to the continuous current rating ( $I_{\text{Cont}}$ ) of the drive.
Loading Profile	The loading profile is comprised of $I_{\text{PK}}$ , $I_{\text{Base}}$ , $T_{\text{PK}}$ , and D (or T) values and completely specify the operation of the drive in an overload situation. These values are collectively defined as the Loading Profile of the drive.
Application Period (T)	The sum of the times at $I_{\text{PK}}$ ( $T_{\text{PK}}$ ) and $I_{\text{Base}}$ .

(1) All current values are specified as rms.

**MDF-1003 Peak Inverter Overload ( $T_{PK} < 2.0$  s)****MDF-1153 Peak Inverter Overload ( $T_{PK} < 2.0$  s)****MDF-1304 Peak Inverter Overload ( $T_{PK} < 2.0$  s)**

## Feedback Specifications

Kinetix 6000M integrated drive-motors are available with high performance digital encoders with multi-turn high-resolution feedback:

- 524,288 counts per revolution
- High-resolution absolute position feedback within 4096 turns.

The IDM unit does not support an auxiliary feedback device.


## Absolute Position

The drive's absolute position feature tracks the position of the motor, within the multi-turn retention limits, while the drive is powered off. The absolute position feature is available on all IDM units.

**Table 19 - Absolute Position Designator Examples**

Encoder Type	Motor Cat. No. Designator	Motor Cat. No. Example
Hengstler BISS	-Q	MDF-SB1003P-Q

**Figure 20 - Absolute Position Retention Limits**



## Connect the Kinetix 6000M System

This chapter provides procedures for wiring the integrated drive-motor system components.

Topic	Page
Basic Wiring Requirements	55
Ground the IDM System	56
General IDM System Wiring	58
How to Bypass an IDM Unit	60
The Sercos Fiber-optic Ring	61
Ethernet Cable Connections	65

### Basic Wiring Requirements

This section contains basic wiring information for the Kinetix® 6000M integrated drive-motor system. See the Kinetix 6000 user manual, publication [2094-UM001](#), or the Kinetix 6200 user manual, publication [2094-UM002](#), for specific wiring information.



**ATTENTION:** Plan the installation of your system so that you can perform all cutting, drilling, tapping, and welding with the system removed from the enclosure. Because the system is of the open type construction, be careful to keep any metal debris from falling into it. Metal debris or other foreign matter can become lodged in the circuitry, which can result in damage to components.



**SHOCK HAZARD:** To avoid hazard of electrical shock, perform all mounting and wiring of the Bulletin 2094 power rail and IPIM modules prior to applying power. Once power is applied, connector terminals may have voltage present even when not in use.

**IMPORTANT**

IDM system wiring differs from common PWM servo system wiring configurations in the following ways:

- Hybrid and network cables can be tie-wrapped together and occupy the same cable run
- Hybrid and network cables do not require physical segregation as a result of more effective wire shielding and improved grounding techniques.

This exception applies only to the hybrid and network cables that connect to an IPIM module or between IDM units, and does not apply to cabling elsewhere in a Kinetix drive system. Refer to the System Design for Control of Electrical Noise Reference Manual, publication [GMC-RM001](#), for more information.

National Electrical Code, local electrical codes, special operating temperature, duty cycles, or system configurations take precedence over the information presented above and the values and methods provided in the document referenced above.

---

## Routing the Power and Signal Cables

Be aware that when you route power and signal wiring on a machine or system, radiated noise from nearby relays, transformers, and other electronic devices can be induced into I/O communication, or other sensitive low voltage signals. This can cause system faults and communication anomalies.

The hybrid cables and network cables are UL Listed with 1000V and 105 °C (221 °F) insulation ratings, and can be routed in a common wireway.

**IMPORTANT**

Building your own cables is not an option for the hybrid and network cables used in the IDM system.

---

See [Electrical Noise Reduction](#) on [page 29](#) for examples of routing high and low voltage cables in wireways. See the System Design for Control of Electrical Noise Reference Manual, publication [GMC-RM001](#), for more information.

## Ground the IDM System

All equipment and components of a machine or process system should have a common earth ground point connected to chassis. A grounded system provides a ground path for short circuit protection. Grounding your modules and panels minimize shock hazard to personnel and damage to equipment caused by short circuits, transient overvoltages, and accidental connection of energized conductors to the equipment chassis.



**ATTENTION:** The National Electrical Code contains grounding requirements, conventions, and definitions. Follow all applicable local codes and regulations to safely ground your system.

For CE grounding requirements, refer to [Agency Compliance](#) on [page 21](#).

---




**ATTENTION:** High voltage can build up on the shields of a hybrid cable, if the shield is not grounded. Verify that there is a connection to ground for all shields in the hybrid cable. Failure to observe these safety procedures could result in personal injury or damage to equipment.

Signal integrity is very important for successful operation of an integrated drive-motor system. You must be sure that all cables are properly grounded through the IPIM module to the ground plane of the Kinetix drive system.

- Verify that every cable shield directly connects to chassis ground.
- Clamp the exposed section of the hybrid cable shield in the cable (chassis) ground connection on the drive. See [Apply the Cable Shield Clamp](#).


**Figure 21 - Hybrid Cable Shields**




## Apply the Cable Shield Clamp

The cable shield clamp assures a solid bond to the shield and secures the cable.

1. Depress the spring loaded clamp.



2. Position the exposed portion of the cable braid directly in line with the clamp.
3. Release the spring, making sure the cable and cable braid are held secure by the clamp.



## General IDM System Wiring



**ATTENTION:** Arcing or unexpected motion can occur if cables are connected or disconnected while power is applied to the IDM system. Before working on the system, disconnect power and wait the full time interval indicated on the IPIM module warning label or verify the DC bus voltage at the IPIM module measures less than 50V DC.

Failure to observe this precaution could result in severe bodily injury or loss of life, and damage to the product will occur.



**ATTENTION:** Be sure that installed cables are restrained to prevent uneven tension or flexing at the cable connectors. Provide support at 3 m (10 ft) intervals throughout the cable run.

Excessive and uneven lateral force at the cable connectors may result in the connector's environmental seal opening and closing as the cable flexes, or wires separating at the cable gland.

Failure to observe these safety procedures could result in damage to the motor and its components.

**IMPORTANT** Building your own cables is not an option for the hybrid and network cables used in the IDM system.

Always form a drip loop in the cables directly before each cable enters and exits the IDM unit. A drip loop is a low spot in the cable that lets liquids gather and drip off the cable rather than flow along the cable to an electrical connection or the motor.

Connect the network and hybrid cables only after the IDM unit is mounted.




**ATTENTION:** Cable connectors must be properly aligned before the connection is secured with the recommended degrees of turn or torque value. Improper connector alignment is indicated by the need for excessive force, such as the use of tools, to fully seat connectors. Failure to observe these safety procedures could result in damage to the IDM unit, cables, and connector components.

### Hybrid Cable

A hybrid cable, catalog number 2090-CHBIFS8-12AAxx, transfers DC bus power and inter-module communication signals from the IPIM module to the first IDM unit. Additional IDM units are daisy chained by using a 2090-CHBP8S8-12AAxx cable as shown in [Figure 22](#).



**ATTENTION:** Verify that all connections are correct when wiring the connector plugs and that the plugs are fully engaged in the module connectors. Incorrect wiring/polarity or loose wiring can cause explosion or damage to equipment.


**Figure 22 - IDM System Wiring**

The colored rings on the hybrid cable connector and the mating cable must match: red-to-red or green-to-green.


Hand-tighten the knurled collar on a hybrid cable approximately 45 degrees to fully seat and lock the connector.

#### *Wire the Connectors*

Use these guidelines as a reference when wiring the hybrid cable to the IPIM module.


**Figure 23 - 2090-CHBIFS8-12AAxx Hybrid Cable**

1. Route the cable/wires to the module.
2. Insert wires into connector plugs.
3. Tighten the connector screws.
4. Gently pull on each wire to make sure it does not come out of its terminal; reinsert and tighten any loose wires.
5. Insert the connector plug into the module connector.

**Figure 24 - Hybrid Cable Installed**

## Network Cable

The IDM system network is routed by using 2090-CNSxPxS-AAxx cables. A 2090-CNSSPRS-AAxx or 2090-CNNSPSS-AAxx cable is required for connection to the IPIM module.



(1) Not for connection to an IPIM module.

When installing network cables, torque the connector plug to 0.8...1.2 N•m (7.1...10.6 lb•in) to fully seat the contacts and secure the connection.

## How to Bypass an IDM Unit

A 2090-CCPPS8S coupler cable joins two hybrid cables to bypass an IDM unit or extend the length of a cable. This can be desired when performing maintenance on a unit or to simply extend a hybrid cable. IDM to IDM cable lengths should not exceed 25 m (82.0 ft) during normal operation when a coupling cable is used.

The IDM network cables can be joined to together without the need of a coupler to bypass an IDM unit or extend network cables.

## The Sercos Fiber-optic Ring

The sercos fiber-optic ring is connected by using the sercos receive (RX) and transmit (TX) connectors. See [Sercos Fiber-optic Connectors](#) on page 43 for details. See the documentation supplied with your Logix sercos interface module or PCI card for connector locations.

Plastic cable is available in lengths up to 32 m (105.0 ft). Glass cable is available in lengths between 50 m (164.2 ft) and 200 m (656.7 ft).

Connect the cable from transmit on the Logix module to receive on the first IPIM module, then transmit to receive (module to module), and from transmit on the last module back to receive on the Logix module.



**ATTENTION:** To avoid damage to the sercos RX and TX connectors use only finger-tight torque when attaching the fiber-optic cables. Do not use a wrench or any other mechanical assistance. For more information, see Fiber Optic Cable Installation and Handling Instructions, publication [2090-IN010](#).


### IMPORTANT

Clean the fiber-optic cable connectors before installation. Dust in the connectors can reduce signal strength. For more information, see Fiber Optic Cable Installation and Handling Instructions, publication [2090-IN010](#).

The IPIM module has fiber-optic cable connectors positioned identical to the Kinetix 6000 (2094-BMxx-S) drives, the IPIM module uses the same fiber-optic cable lengths as the drive modules.

In the following example ([Figure 25](#)), all of the drive modules and the IPIM module are on the same sercos ring. The ring begins and ends at the 1756-M16SE sercos module. IDM units connected to the IPIM module (not shown for simplicity) are also part of this sercos ring.

**Figure 25 - Fiber-optic Cable Example - Logix Platform with IPIM Module**




In this five-axis Bulletin 2094 power rail configuration, the IAM module and two AM modules power three of the axes and two IPIM modules are each connected to four IDM units. All eleven axes are on the same sercos ring.

**IMPORTANT**

It is not required that all Kinetix 6000 drives be on the same sercos ring; however, it is required that all IDM units be on the same sercos ring as the IPIM module they are connected to.

**Figure 26 - Kinetix 6000M Network Cable Example - IPIM Module to IDM Units (1 sercos ring)**




This configuration has the same drive modules and IPIM modules as shown in [Figure 26](#), except the five modules are split between two sercos rings. Each ring has its own 1756-M08SE sercos module in the ControlLogix controller chassis.

**IMPORTANT**

It is not required that all Kinetix 6000 drives be on the same sercos ring; however, it is required that all IDM units be on the same sercos ring as the IPIM module they are connected to.

**Figure 27 - Kinetix 6000M Network Cable Example - IPIM Module to IDM Units (2 sercos rings)**




In this configuration, the 8-axis Bulletin 2094 power rail has four drive modules and four IPIM modules. Each IPIM module is connected to four IDM units. There are five sercos rings and each ring has its own 1756-M08SE sercos module in the ControlLogix controller chassis.

**IMPORTANT**

It is not required that all Kinetix 6000 drives be on the same sercos ring; however, it is required that all IDM units be on the same sercos ring as the IPIM module they are connected to.

**Figure 28 - Kinetix 6000M Network Cable Example - IPIM Module to IDM Units (5 sercos rings)**




## Ethernet Cable Connections

This procedure assumes you have your ControlLogix or CompactLogix™ EtherNet/IP™ module and Bulletin 2094 control modules mounted and are ready to connect the Ethernet network cables.

The EtherNet/IP network is connected by using the PORT 1 and/or PORT 2 connectors. The IPIM module uses the EtherNet/IP network only for configuring the Logix program. See [page 44](#) to locate the Ethernet connector on your IPIM module.

See the [Figure 29](#) to locate the connector on your EtherNet/IP controller module.

**Figure 29 - ControlLogix and CompactLogix Ethernet Port Locations**



**Notes:**

## Configure the Kinetix 6000M System

This chapter provides procedures for configuring your Kinetix® 6000M system components with your Logix sercos module.

Topic	Page
Understand the IPIM Module Display	68
Configure the IPIM Module	71
Configure the IDM Unit	72
Add-on Profiles	75
Configure the Logix Sercos Interface Module	75
Apply Power to the System	84
Test and Tune the Axes	85

**TIP** Before you begin, make sure you know the catalog number for each IDM unit, IPIM module, and the Logix module in your motion control application.

### Configure the Kinetix 6000M Integrated Drive-motor System

Configuration for the Kinetix 6000M integrated drive-motor system follows a procedure similar to what is described in the Kinetix 6000 Multi-axis Servo Drives User Manual and Kinetix 6200 and Kinetix 6500 Modular Multi-axis Servo Drives User Manual. You will assign each IDM unit a node address and configure the IDM system in RSLogix 5000® software.


The IPIM module does not require configuration for your IDM units to be configured in the sercos ring. However, you can include the IPIM module in your RSLogix 5000 project by connecting it to a configured Ethernet module in the Logix chassis and adding it under the Ethernet module in the I/O configuration tree. An Add-on Profile is also needed to use the IPIM module in the RSLogix 5000 project, and as a result you can view IPIM module status information in RSLogix 5000 software and use it in your Logix program. The Ethernet connection is also used to upgrade the IPIM module firmware by using ControlFLASH software.

**TIP** The factory default communication rate for all Kinetix 6000 modules is 4 Mbps. The modules must be changed to 8 Mbps to be compatible with the Kinetix 6000M.

## Understand the IPIM Module Display

The IPIM module has six status indicators (see [Interpret Status Indicators](#) on [page 92](#)) and a four-line LCD display. The indicators and display are used to monitor the system status, set network parameters, and troubleshoot faults. Four navigation buttons are located directly below the display and are used to select items from a soft menu.

**Figure 30 - IPIM Module LCD Display**




The soft menu provides a changing selection that will correspond to the current display. Use the navigation buttons to perform the following actions.

« »	Selecting either arrow will move the selection to the next (or previous) item or value. Depending on the menu displayed, both arrows may not be shown.
^ V	Selecting either arrow will move the selection to the next menu item. It will also change a selected value. Depending on the menu or item displayed, both arrows may not be shown.
back	Discards changes and returns to the previous screen or home.
cancel	Discards any changes and returns to the home display.
enter	Accepts current selection/value.
info	Selects the Information display for the IPIM or a selected IDM unit.
home	Selecting "home" will discard changes and return to the home display.
tools	Displays the tools menu.
save	Accepts the current selection/value.

## Startup Sequence

On initial powerup, the IPIM module performs a self-test of the system. Upon successful completion, the following confirmation is displayed, followed by the firmware version and IP address.




Next, the home screen displays the address of each connected IDM unit.




If an IDM unit is reporting a fault, the IDM address is either underlined or outlined. It is outlined for severe faults and underlined for less severe faults.

## Information Display

Use the arrows to select “IPIM” or a specific IDM unit.



Pressing “info” displays a new screen with detailed information about the IPIM module or selected IDM unit.




The following information is displayed.


IPIM Information		IDM Information	
Module Status:	<ul style="list-style-type: none"> <li>- IP Address</li> <li>- OK</li> <li>-Standby (OK, but no CIP™ connection)</li> <li>-Faulted</li> <li>-Init Fault (Requires reboot)</li> </ul>	Status:	Displays IDM status values.
Bus Reg Cap	Percent of shunt capacity being used.	Safety:	“Motion-allowed” or “Safe-off.”
Active Faults:	Active faults (one per line) will be displayed.	Sercos Phase:	Current sercos phase of the IDM: 0 - 5.
Utilization:	Percent of continuous DC bus current.	Active Faults:	Active faults (one per line) will be displayed.

## Tools Menu

The tools menu provides network setup, sercos light intensity adjustment and fault help.



To edit a menu item or value, use the arrow keys to select the desired item, then press “enter.” The up arrow lets you increment the value that is highlighted. Values will roll over when reaching the end of the list.



The tools menu provides viewing/editing of the following.

Selection	Description	
Network configuration	Mode	Select Static or DHCP configuration.
	IP Address	Edits the IP address.
	Subnet mask	Edits the subnet mask.
	Gateway address	Edits gateway address.
	Primary address	Edits primary name server IP address.
	Secondary Name Server	Edit the secondary name server IP address.
Sercos light intensity	Selects high or low intensity. Changes to the light intensity will take effect immediately and be stored in nonvolatile memory. The default setting is “High.”	
IPIM fault help	Displays help text for the selected IPIM fault.	
IDM fault help	Displays help text for the selected IDM fault.	

## Configure the IPIM Module

You can include the IPIM module in your RSLogix 5000 project by connecting it to a configured Ethernet module in the Logix chassis and adding it under the Ethernet module in the I/O configuration tree. As a result, you can view the IPIM module status information in RSLogix 5000 software and use it in your Logix program. To select the IPIM module in RSLogix 5000 software, version 20, you must load an Add-on Profile (see [page 75](#)).

### Set the IPIM Module Network Address

To perform monitoring, diagnostics, and upgrade firmware, it is necessary to program the following using the LCD display:

- Mode - Static or DHCP
- IP address
- Gateway
- Subnet mask

Settings are stored in nonvolatile memory. You can select a static address, or enable DHCP. IP addressing may also be changed through the Module Configuration dialog in RSLinx® software. Changes to the IP addressing take effect immediately. The default configuration of the IP address is the static address 192.168.1.1. See [Understand the IPIM Module Display](#) on [page 68](#) for programming guidelines.

Follow these steps to program the network settings:

1. Apply control power.
2. After initialization is complete and the home screen is displayed, select: tools>Network configuration>Net mode.
3. Use the arrow keys to select Static or DHCP.
4. Press “save.”
5. Select tools>Network configuration>Net mode>Static IP.
6. Use the right arrow to select the first digit to change.
7. Use the up arrow to increment the value until the desire value is displayed. Then use the right arrow to select the next digit and so on. Continue until the IP address is correct.
8. Press “save.”
9. Repeat [step 1](#) through [step 8](#) to set the subnet mask and gateway address.
10. Save your settings and remove control power.


## Configure the IDM Unit

### Set the Node Address

The node address is set by switches on each IDM unit. This address is the actual sercos node address, not an offset from the IAM module. The address is read at power up, so if the switch settings are changed while power is applied, the changes do not take effect until the next power cycle.

See [Figure 31](#) and remove the two protective covers to gain access to the switches. Using a small screwdriver, rotate the switches to the proper setting. Replace covers and torque to 0.6 N•m (5 lb•in), repeat for any other units.

**Figure 31 - Node Address Switches**




In the following example (Figure 32), the Kinetix 6000 power rail contains two single-wide axis modules and one IDM system. A sercos node address is not assigned to the slot-filler or the IPIM module. However, the system identifies both modules with slot locations.

Node addresses 02 and 05 are available for any of the IDM units, but to avoid confusion, the node addressing for the IDM units was started at 20. Unlike axis modules, each IDM unit has switches that determine its node address. In example 1, the IDM unit node addressing is sequential, but it does not have to be.

**IMPORTANT** Creating a duplicate node address between the axis modules mounted on the power rail and the IDM system generates error code E50. Each node address on the sercos ring must be unique within the range of 01...99.

**IMPORTANT** Slot-filler modules must be used to fill any unoccupied slot on the power rail. However, you can replace slot-filler modules with AM modules or the 2094-BSP2 shunt module (maximum one 2094-BSP2 shunt module per power rail).

**Figure 32 - Node Addressing Example 1**




In example 2 (Figure 33), the Kinetix 6000 power rail contains two single-wide axis modules and two IDM systems. A sercos node address is not assigned to the slot-filler or the IPIM module, but the system identifies both with slot locations.

Node addressing for the IDM system example 2 is similar to the first. Each IDM unit has switches that determine its node address. In this example, the IDM unit node addressing starts at 30 and is sequential.

**IMPORTANT** Creating a duplicate node address between the axis modules mounted on the power rail and the IDM system generates error code E50. Each node address on the sercos ring must be unique within the range of 01...99.

**Figure 33 - Node Addressing Example 2**



## Add-on Profiles

To select the IPIM module in RSLogix 5000 software, version 20, you must load an Add-on Profile from [www.ab.com](http://www.ab.com).

To navigate to the Add-on Profiles, follow this path:

- Technical Support
- Software Updates, Firmware and Other Downloads
- RSLogix 5000 I/O Modules Add-on Profiles

You will be required to establish a login and provide the serial number of your drive to access the download file.

## Configure the Logix Sercos Interface Module

This procedure assumes that you have wired your Kinetix drive system and have configured the communication rate and optical power switches.

For help using RSLogix 5000 software as it applies to configuring the ControlLogix, CompactLogix, or SoftLogix™ sercos modules, refer to [Additional Resources on page 10](#).


**IMPORTANT** RSLogix 5000 software, version 20.000 or later, is required.

## Configure the Logix Controller

Follow these steps to configure the Logix controller.

1. Apply power to your Logix chassis containing the sercos interface module/PCI card and open your RSLogix 5000 software.
2. From the File menu, choose New.

The New Controller dialog box opens.




3. Configure the new controller.

- a. From the Type pull-down menu, choose the controller type.
- b. From the Revision pull-down menu, choose the revision (V20).
- c. Type the file Name.
- d. From the Chassis Type pull-down menu, choose the chassis.
- e. Enter the Logix processor slot.

4. Click OK.
5. From the Edit menu, choose Controller Properties.

The Controller Properties dialog box opens.



6. Click the Date/Time tab.
7. Check Enable Time Synchronization.

This assigns the controller as the Grandmaster clock. The motion modules set their clocks to the module you assign as the Grandmaster.

**IMPORTANT** You can assign only one module in the Logix chassis as the Grandmaster clock.


8. Click OK.

## Configure the Logix Module

Follow these steps to configure the Logix module.

1. Right-click I/O Configuration in the Controller Organizer and choose New Module.

The Select Module dialog box opens.




2. Scroll to select the sercos module as appropriate for your actual hardware configuration.

In this example, the 1756-M16SE module is selected.

3. Click Create.

The New Module dialog box opens.



4. Configure the new module.


- Type the module Name.
- Enter the Logix sercos module slot (leftmost slot = 0).
- Check Open Module Properties.

5. Click OK.

Your new module appears under the I/O Configuration folder in the Controller Organizer and the Module Properties dialog box opens.

**TIP** The IDM system data rate is fixed at 8 Mbps.

6. Verify that the data rate DIP switches on the IAM module and any AM modules on the same sercos ring are set to 8 Mbps.
7. Click the SERCOS Interface tab.



8. From the Data Rate pull-down menu, choose 8 Mb or choose the Auto Detect setting.
9. From the Cycle Time pull-down menu, choose the Cycle Time according to the following table.

Data Rate	Number of Axes	Cycle Time
8 Mbps <sup>(1)</sup>	Up to 4	0.5 ms
	Up to 8	1 ms
	Up to 16	2 ms

(1) The Kinetix 6000M system supports only 8 Mbps.

**TIP** The factory default data rate setting for all Kinetix 6000 modules is 4 Mbps.

**TIP** The number of axes/module is limited to the number of axes as shown in the following table.


Logix Serco Module	Number of Axes	Data Rate
1756-M03SE or 1756-L60M03SE	Up to 3	8 Mbps
1756-M08SE	Up to 8	
1756-M16SE or 1784-PM16SE	Up to 16	
1768-M04SE	Up to 4	

10. From the Transmit Power pull-down menu, choose High. The default setting is High; however, this setting is dependent on the cable length (distance to next receiver) and cable type (glass or plastic).
11. Enter the Transition to Phase setting. The Transition to Phase default setting is 4 (phase 4). The Transition to Phase setting stops the ring in the phase specified.
12. Click OK.
13. Repeat [step 1](#) through [step 12](#) for each Logix module.

## Configure the IDM Units

Follow these steps to configure the IDM units.

1. Right-click the Logix module you just created and choose New Module. The Select Module dialog box opens.




2. Scroll to select the IDM unit appropriate for your actual hardware configuration.

**IMPORTANT** To configure IDM units (catalog numbers MDF-SBxxxx) you must be using RSLogix 5000 software, version 20.010 or later. Version 20.000 can be used if the motion database has been updated.

3. Click Create.

The New Module dialog box opens.



4. Configure the new module.


- a. Type the module Name.
- b. Enter the Node address.

Set the node address in the software to match the node setting on the IDM unit. See [Set the Node Address](#) on page 72.

- c. Check Open Module Properties.


5. Click OK.

6. Click the Associated Axes tab.



7. Click New Axis.

The New Tag dialog box opens.




8. Type the axis Name.

AXIS\_SERVO\_DRIVE is the default Data Type.

9. Click Create.

The axis appears under the Ungrouped Axes folder in the Controller Organizer.

10. Assign your axis to Node 1.



**TIP** Auxiliary feedback is not supported by the IDM units.


11. Click OK.

12. Repeat [step 1](#) through [step 11](#) for each IDM unit.

## Configure the Motion Group

Follow these steps to configure the motion group.


1. Right-click Motion Groups in the Controller Organizer and choose New Motion Group.  
The New Tag dialog box opens.



2. Type the new motion group Name.
3. Click OK.

The new motion group appears under the Motion Groups folder.

4. Right-click the new motion group and choose Properties.  
The Motion Group Properties dialog box opens.




5. Click the Axis Assignment tab and move your axes (created earlier) from Unassigned to Assigned.
6. Click the Attribute tab and edit the default values as appropriate for your application.
7. Click OK.

## Configure Axis Properties

Follow these steps to configure the Axis properties.


1. Right-click an axis in the Controller Organizer and choose Properties. The Axis Properties dialog box opens.



2. On the Drive/Motor tab, check Drive Enable Input Checking. When checked (default), means a hard drive-enable input signal is required. Uncheck to remove that requirement.


**TIP** The drive-enable input signal is located on the IPIM module.

3. Click Apply.
4. Click the Units tab and edit default values as appropriate for your application.
5. Click the Conversion tab and edit default values as appropriate for your application.



6. From the Positioning Mode pull-down menu and choose Rotary.
7. Click Apply.

8. Click the Fault Actions tab.



9. Click Set Custom Stop Action.

The Custom Stop Action Attributes dialog box opens and lets you set delay times for IDM units.

10. Configure the delay times.

- Type the Brake Engage Delay Time.
- Type the Brake Release Delay Time.

Cat. No.	Brake Engage Delay ms	Brake Release Delay ms
MDF-SB1003	20	50
MDF-SB1153		
MDF-SB1304	25	110

- Click Close.

- Click OK.

- Repeat [step 1](#) through [step 11](#) for each IDM unit.

- Verify your Logix program and save the file.

## Download the Program

After completing the Logix configuration you must download your program to the Logix processor.

## Apply Power to the System

This procedure assumes that you have wired and configured your Kinetix drive system (with or without the LIM module) and your sercos interface module.



**ATTENTION:** Capacitors on the DC bus may retain hazardous voltages after input power has been removed. Before working on the IPIM module or disconnecting/connecting any IDM unit, wait the full time interval as indicated in the warning on the front of the drive. Failure to observe this precaution could result in severe bodily injury or loss of life.

See the [Chapter 4](#) for connector locations and [Chapter 7](#) when troubleshooting the IPIM module and IDM unit status indicators.

Follow these steps to apply power to the Kinetix 6000M system.

1. Disconnect the load to the IDM units.



**ATTENTION:** To avoid personal injury or damage to equipment, disconnect the load to the IDM units. Make sure each IDM unit is free of all linkages when initially applying power to the system.

2. Apply control power and 3-phase power to your Kinetix drive system and observe the status indicators on your Kinetix 6000 or Kinetix 6200 drive modules.

See the user manual for your Kinetix 6000 or Kinetix 6200 drive system for the proper status indicator response. When the drive system is powered up and has reached sercos phase 4, continue to [step 3](#).

3. Observe the IDM unit drive status indicator and verify with the following table.

Indication	Status	Do This
Alternating green/red	Module is performing self-test	Wait for steady green.
Flashing green	Module is in standby mode	Go to <a href="#">Test and Tune the Axes on page 85</a> .
Solid green	Module is operating	
Solid or flashing red	Fault has occurred	Refer to <a href="#">Chapter 7</a> .

4. Verify the Hardware Enable Input signal is at 0 volts.

The Hardware Enable input for the IDM system is on the IPIM module (see [page 43](#)).

5. Remove the Hardware Enable Input connection, if one exists.
6. Observe the three sercos indicators on the Logix sercos module.

Three Sercos Indicators	Status	Do This
Flashing green and red	Establishing communication	Wait for steady green on all three indicators.
Steady green	Communication ready	Go to <a href="#">Test and Tune the Axes on page 85</a> .
Not flashing green and red/ not steady green	Sercos module is faulted	Go to the appropriate Logix manual for specific instructions and troubleshooting.

## Test and Tune the Axes

This procedure assumes that you have configured your Kinetix 6000M system, your Logix sercos interface module, and applied power to the system.


For help using RSLogix 5000 software as it applies to testing and tuning your axes with ControlLogix, CompactLogix, or SoftLogix sercos modules, refer to [Additional Resources](#) on [page 10](#).

### Test the Axes

Follow these steps to test the axes.

1. Verify the load was removed from each axis.
2. Right-click an axis in your Motion Group folder and choose Properties.

The Axis Properties dialog box opens.



3. Click the Hookup tab.
4. Type 2.0 as the number of revolutions for the test or another number more appropriate for your application.


This Test	Performs this Test
Test Marker	Verifies marker detection capability as you rotate the motor shaft.
Test Feedback	Verifies feedback connections are wired correctly as you rotate the motor shaft.
Test Command & Feedback	Verifies motor power and feedback connections are wired correctly as you command the motor to rotate.

5. Apply Hardware Enable Input signal for the axis you are testing.

**IMPORTANT** Hardware Enable input for IDM units is on the IPIM module.


6. Select the desired Test (Marker/Feedback/Command & Feedback) to verify connections.

The Online Command dialog box opens. Follow the on-screen test instructions. When the test completes, the Command Status changes from Executing to Command Complete.



7. Click OK.

The Online Command - Apply Test dialog box opens (Feedback and Command & Feedback tests only). When the test completes, the Command Status changes from Executing to Command Complete.



8. Click OK.

9. Determine if your test completed successfully.

If	Then
Your test completes successfully, this dialog box opens.	<p>1. Click OK.</p> <p>2. Remove Hardware Enable Input signal <sup>(1)</sup>.</p> <p>3. Go to Tune the Axes on <a href="#">page 87</a>.</p>
Your test failed, this dialog box opens.	<p>1. Click OK.</p> <p>2. Verify the Bus status indicator turned solid green during the test.</p> <p>3. Verify that the Hardware Enable Input signal is applied to the axis you are testing.</p> <p>4. Verify conversion constant entered in the Conversion tab.</p> <p>5. Return to main <a href="#">step 6</a> and run the test again.</p>

(1) The hardware enable input for IDM units is on the IPIM module.

## Tune the Axes


Follow these steps to tune the axes.

1. Verify the load is still removed from the axis being tuned.



**ATTENTION:** To reduce the possibility of unpredictable motor response, tune your motor with the load removed first, then re-attach the load and perform the tuning procedure again to provide an accurate operational response.

2. Click the Tune tab.



3. Type values for Travel Limit and Speed.

In this example, Travel Limit = 5 and Speed = 10. The actual values of programmed units depend on your application.

4. From the Direction pull-down menu, choose a setting.


Forward Uni-directional is default.

5. Check Tune boxes as appropriate for your application.
6. Apply Hardware Enable Input signal for the axis you are tuning.

**IMPORTANT** Hardware Enable input for IDM units is on the IPIM module.


7. Click Start Tuning to autotune your axis.

The Online Command - Tune Servo dialog box opens. When the test completes, the Command Status changes from Executing to Command Complete.



8. Click OK.

The Tune Bandwidth dialog box opens.




Actual bandwidth values (Hz) depend on your application and may require adjustment once motor and load are connected.

9. Record your bandwidth data for future reference.

10. Click OK.

The Online Command - Apply Tune dialog box opens. When the test completes, the Command Status changes from Executing to Command Complete.



11. Click OK.

12. Determine if your test completed successfully.

If	Then
Your test completes successfully, this dialog box opens.	<p>1. Click OK.</p> <p>2. Remove the Hardware Enable Input signal applied earlier<sup>(1)</sup>.</p> <p>3. Go to <a href="#">step 13</a>.</p>
Your test failed, this dialog box opens.	<p>1. Click OK.</p> <p>2. Make an adjustment to motor velocity.</p> <p>3. See the appropriate Logix motion module user manual for more information.</p> <p>4. Return to <a href="#">step 7</a> and run the test again.</p>

(1) The hardware enable input for IDM units is on the IPIM module.

13. Repeat [Test and Tune the Axes](#) for each axis.

## Troubleshoot the Kinetix 6000M System

This chapter provides troubleshooting tables and related information for your Kinetix® 6000M integrated drive-motor system.

Topic	Page
Safety Precautions	89
IDM System Error Codes	90
Interpret Status Indicators	92
General System Anomalies	94
IPIM Module Fault Diagnosis	95
IDM Unit Fault Diagnosis	97
Use a Web Browser to Monitor System Status	100

### Safety Precautions



**ATTENTION:** Capacitors on the DC bus may retain hazardous voltages after input power has been removed. Before working on the IDM system, wait the full time interval as indicated in the warning on the front of the IPIM module. Failure to observe this precaution could result in severe bodily injury or loss of life.



**ATTENTION:** Do not attempt to defeat or override the fault circuits. You must determine the cause of a fault and correct it before you attempt to operate the system. Failure to correct the fault could result in personal injury and/or damage to equipment as a result of uncontrolled machine operation.



**ATTENTION:** Provide an earth ground for test equipment (oscilloscope) used in troubleshooting. Failure to ground the test equipment could result in personal injury.

## IDM System Error Codes

The IAM module reports a single, generic IPIM fault whenever a fault occurs on any IPIM module in the same backplane as the IAM module. All IPIM faults result in an open contactor. The Logix Axis Tag for this fault is IPIMFault.

The IPIM module is not a sercos device, so the IAM module reports any IPIM faults to the Logix motion subsystem. IPIM faults are reset by performing a fault reset on the IAM module. Issuing a fault reset command to the IAM module also generates a fault reset to all the IPIM modules in the same backplane as the IAM. Detailed information about the IPIM fault status may be obtained by messaging to the IAM.

Connecting the IPIM module into the Logix environment as an EtherNet/IP™ device does not disable fault reporting through the IAM module. Only the IAM fault reporting lets the Logix motion subsystem take action based on the IPIM module fault status. IPIM faults are also reported to Logix over the Ethernet connection. However, IPIM faults must be reset by applying a fault reset instruction to the IAM module. The integration of the IPIM module into the Logix environment through the EtherNet/IP network provides additional capabilities you may choose to take advantage of in your Logix program.

### Read the Fault Status of the IPIM Module


The IAM module supports two IDNs to allow reading the fault status from the IPIM, P-0-113 and P-0-114. Both of these IDNs have a data type of INT. To read the fault status from an IPIM module, first write the slot number of the IPIM module you want to read to IDN P-0-114. The left-most slot (the slot occupied by the IAM module) is slot 1, and the slot numbers increment as you move to the right. After the slot number has been written, the IPIM module fault status can be obtained by reading IDN P-0-113. The 16-bit value returned is a bitfield representing the state of the IPIM faults, as follows:

- Value: IPIM diagnostics: (1 = active, 0 = inactive)
- Bit 0: Backplane Communication error
- Bit 1: IDM Communication error
- Bit 2: Bus Overload (excessive current usage by IDMs)
- Bit 3: DC+ Fuse open
- Bit 4: DC- Fuse open
- Bit 5: Control Power Overload
- Bit 6: DC Bus Overcurrent Error (instantaneous overcurrent)
- Bit 7: Shunt Overload
- Bit 8: Overtemp Error
- Bit 9: Open DC Bus Error
- Bits 10-15: Reserved/Not Used

### Set the Message Configuration Parameters

Set the write message configuration parameters as shown in [Figure 34](#).

**Figure 34 - Message Configuration - Write**




1. Set the Source field to a tag that contains the slot location for the IPIM module.

The slot location valid range is 2 - 8, (assuming an 8 slot power rail). The IAM module is always in slot 1.

2. Set the path field on the communication tab to the IAM module on the power rail where the IPIM module is located.

Set the read message configuration parameters as shown [Figure 35](#).

**Figure 35 - Message Configuration - Read**



1. Set the Source field to a tag where the IPIM module status will be stored.
2. Set the path field on the communication tab to the IAM module on the power rail where the IPIM module is located.


See the user manual for your Kinetix 6000 or Kinetix 6200 drive system for further information on reading and writing IDNs.

## Interpret Status Indicators

When a fault condition is detected, the appropriate status indicator will illuminate (IDM unit or IPIM module) and the IPIM module will annunciate the fault on its front panel display.

### IPIM Module Display and Status Indicators

IPIM module fault descriptions, types and actions start on [page 95](#).



**Table 20 - IPIM Display and Status Indicators**

Indicator		Indication	Description
Control Bus	Status of the Control Bus	Off	Control bus is not present
		Solid Green	Control bus is present
		Solid Red	A fault has occurred
Module Status	IPIM Module Status	Off	Power is not applied to the module
		Flashing Green	Module is in standby mode - configuration may be required
		Solid Green	Module is operating correctly
		Flashing Red	A recoverable fault has occurred <sup>(1)</sup>
		Solid Red	An unrecoverable fault has occurred <sup>(1)</sup>
		Alternating Green/Red	Self-test mode during powerup
Network Status	Network Status	Off	Not powered or no IP address
		Flashing Green	No connections, but an IP address has been obtained
		Solid Green	An established connection exists
		Flashing Red	A connection has timed out
		Solid Red	Duplicate IP is present
		Alternating Green/Red	Self-test mode during powerup
DC Bus	Status of the DC Bus	Off	DC Bus is not present
		Flashing Green	DC bus is present and all IDM units are disabled
		Solid Green	DC bus is present and at least one IDM unit is enabled


**Table 20 - IPIM Display and Status Indicators (continued)**

Indicator		Indication	Description
Port 1 Port 2	Status of the EtherNet/IP ports	Off	Port is not connected
		Flashing Green	Port is connected and communication is occurring
		Solid Green	Port is connected, but no communication is not occurring

(1) A reset or cycling the power may clear a recoverable fault (depending on the state of the IDM). An unrecoverable fault will require power cycling and/or modifying the hardware configuration while unpowered to clear the fault.

## IDM Unit Status Indicators

IDM unit fault descriptions and actions start on [page 95](#).

**Table 21 - IDM Unit Indicators**

Indicator		Indication	Description
Network Status (N)	Provides communication status for the IDM unit.	Off	Communication is not active
		Flashing green (1 s interval)	Communication is being established
		Solid green	Communication has been established
		Solid red	A duplicate address exists
		Fast flashing green (0.5 s interval)	Firmware update in process
		Slow flashing green (2 s interval)	Firmware update in process on another IDM
Drive Status (D)	Provides general status for the IDM unit.	Off	Power is not applied
		Flashing green	Module is in standby mode
		Solid green	Module is operating
		Flashing red	Recoverable fault has occurred <sup>(1)</sup>
		Solid red	Unrecoverable (or hardware) fault has occurred <sup>(1)</sup>

(1) A reset or cycling the power may clear a recoverable fault (depending on the state of the IDM). An unrecoverable fault will require power cycling and/or modifying the hardware configuration while unpowered to clear the fault.

## General System Anomalies

These anomalies do not always result in a fault code, but may require troubleshooting to improve performance.

**Table 22 - General System Anomalies**

Condition	Potential Cause	Possible Solution
Axis or system is unstable.	Unintentionally in Torque mode.	Check to see what primary operation mode was programmed.
	IDM unit tuning limits are set too high.	Run Tune in RSLogix 5000® software.
	Position loop gain or position controller accel/decel rate is improperly set.	Run Tune in RSLogix 5000 software.
	Mechanical resonance.	Notch filter or output filter may be required (refer to Axis Properties dialog box, Output tab in RSLogix 5000 software).
You cannot obtain the acceleration/ deceleration that you want.	Torque Limit limits are set too low.	Verify that current limits are set properly.
	The system inertia is excessive.	<ul style="list-style-type: none"> <li>Check IDM unit size versus application need.</li> <li>Review servo system sizing.</li> </ul>
	The system friction torque is excessive.	Check IDM unit size versus application need.
	Available current is insufficient to supply the correct accel/decel rate.	<ul style="list-style-type: none"> <li>Check IDM size versus application need.</li> <li>Review servo system sizing.</li> </ul>
	Acceleration limit is incorrect.	Verify limit settings and correct them, as necessary.
IDM unit does not respond to a velocity command.	Velocity Limit limits are incorrect.	Verify limit settings and correct them, as necessary.
	The axis cannot be enabled for 1.5 seconds after disabling.	Disable the axis, wait for 1.5 seconds, and enable the axis.
	The IDM wiring is open.	Replace the IDM unit.
	The IDM thermal switch has tripped.	<ul style="list-style-type: none"> <li>Check for a fault.</li> <li>Check the wiring.</li> </ul>
	The IDM unit has malfunctioned.	Replace the IDM unit.
	The coupling between IDM unit and machine has broken (for example, the IDM unit moves, but the load/machine does not).	Check and correct the mechanics.
	Primary operation mode is set incorrectly.	Check and properly set the limit.
Presence of noise on wires/cables.	Velocity or current limits are set incorrectly.	Check and properly set the limits.
	Recommended grounding per installation instructions have not been followed.	<ul style="list-style-type: none"> <li>Verify grounding.</li> <li>Route wire away from noise sources.</li> <li>Refer to System Design for Control of Electrical Noise, publication <a href="#">GMC-RM001</a>.</li> </ul>
Sercos ring not phasing up.	Line frequency may be present.	<ul style="list-style-type: none"> <li>Verify grounding.</li> <li>Route wire away from noise sources.</li> </ul>
	Duplicate node settings.	Change the node address.
	Incompatible data rates.	Verify that the data rate is set to 8 Mbps for all Kinetix 6000 modules.

**Table 22 - General System Anomalies (continued)**

Condition	Potential Cause	Possible Solution
No rotation	The IDM unit connections are loose or open.	Check IDM unit wiring and connections.
	Foreign matter is lodged in the IDM unit.	Remove foreign matter.
	The IDM unit load is excessive.	Verify the servo system sizing.
	The bearings are worn.	Return the IDM unit for repair.
	The IDM unit brake is engaged (if supplied).	<ul style="list-style-type: none"> <li>Check brake wiring and function.</li> <li>Return the IDM unit for repair.</li> </ul>
	The IDM unit is not connected to the load.	Check coupling.
IDM unit overheating	The duty cycle is excessive.	Change the command profile to reduce accel/decel or increase time.
	The rotor is partially demagnetized causing excessive IDM unit current.	Return the IDM unit for repair.
Abnormal noise	IDM unit tuning limits are set too high.	Run Tune in RSLogix 5000 software.
	Loose parts are present in the IDM unit.	<ul style="list-style-type: none"> <li>Remove the loose parts.</li> <li>Return IDM unit for repair.</li> <li>Replace IDM unit.</li> </ul>
	Through bolts or coupling is loose.	Tighten bolts.
	The bearings are worn.	Return IDM unit for repair.
	Mechanical resonance.	Notch filter may be required (refer to Axis Properties dialog box, Output tab in RSLogix 5000 software).

## IPIM Module Fault Diagnosis

When a fault condition is detected, it is added to a fault log, opens the power rail SYSOK and reports the fault to the IAM module. This causes a loss of bus power to all modules on the Bulletin 2094 power rail and associated IDM units. If an IPIM module fault is detected, the fault will be displayed on the IPIM module. In addition, the IPIM module will display IDM unit faults.

The IAM module generates a fault whenever an IPIM module fault occurs, regardless of the state of the contactor. IDM unit faults are not displayed by the IAM module.

Issuing a fault reset command to the IAM module will also send a fault reset command to the IPIM module.

The IPIM module maintains a log of the last 50 faults reported by the IPIM module or any of the connected IDM units. Each fault contains the source of the fault (IDM unit number or IPIM module), the fault number, and a time stamp with the cumulative power-on time of the IPIM module.

## IPIM Module Fault Types

The IPIM has two fault types: resettable and non-resettable.

When an IPIM module fault occurs, the fault is reported to the IAM module. The IAM module reports an IPIM fault to the Logix controller.

Resettable faults - when the IPIM module fault is cleared from the IAM module, the fault is removed from its display (if the condition has been removed).

Non-resettable faults - the control power must be cycled and the fault may be cleared if the condition that created the fault has been removed.

**Table 23 - IPIM Fault Types, Descriptions and Actions**

Fault	Type	Description	Potential Cause	Possible Solution
IPIM FLT 01	Resettable	Backplane Comm	Lost backplane communication with IAM module.	Verify control power to IAM module.
IPIM FLT 02	Resettable	IDM Comm	Lost communication with IDM unit.	Verify control power to IDM units.
IPIM FLT 03	Resettable	DC Bus Overload	Excessive RMS current usage by IDM units.	Reduce the amount of current required by the IDM units or add an additional IPIM module to the Kinetix 6000 rail.
IPIM FLT 04	Resettable	DC+ Fuse Blown	Wiring error or DC bus short.	Check wiring and IDM units for DC bus integrity. Once the wiring issue or damaged IDM unit has been removed and replaced, change the DC+ fuse.
IPIM FLT 05	Resettable	DC- Fuse Blown	Wiring error or DC bus short.	Check wiring and IDM units for DC bus integrity. Once the wiring issue or damaged IDM unit has been removed and replaced, change the DC- fuse.
IPIM FLT 06	Not Resettable	Control Power Overcurrent	Excessive control power usage by the IDM units.	Check for control power wiring shorts. Reduce number of ID units. Reduce the number of power cycles.
IPIM FLT 07	Resettable	DC Bus Overcurrent	Excessive instantaneous current usage by IDM units.	Reduce number of IDM units per IPIM module or modify motion profiles to reduce current draw.
IPIM FLT 08	Resettable	Bus Regulator Thermal Overload	Thermal model of IPIM shunt indicates overheating due to excessive current regeneration.	Modify the IDM unit or Kinetix 6000 motion profiles and/or applications to reduce the regenerative energy. Add external shunt modules.
IPIM FLT 09	Resettable	Overtemp	Excessive temperature measured in the IPIM module.	Verify ambient operating conditions. Replace the IPIM module.
IPIM FLT 10	Resettable	Open DC Bus	IDM unit hybrid cable disconnected.	Check hybrid cable connections at the IPIM module and each IDM unit.
IPIM FLT 11	Not Resettable	Runtime Error	Unexpected firmware error.	Reboot.
–	Not Resettable	Display is blank and Module Status is Solid Red	Corrupted Main Firmware.	Replace IPIM module.

**Table 24 - IPIM Initialization Fault Types, Descriptions and Actions**

Fault	Type	Description	Potential Cause	Possible Solution
IPIM INIT FLT 03	Resettable	IAM Version	IAM module firmware version does not support IPIM modules.	Update IAM module firmware.
IPIM INIT FLT 05	Not Resettable	Custom Logic Watchdog	Main firmware has lost communication.	Cycle power on the IPIM module. Check for firmware updates. Contact Allen-Bradley® Technical Support.

## IDM Unit Fault Diagnosis

## Logix Controller/IDM Unit Fault Behavior


These RSLogix 5000 fault actions are configurable from the Axis Properties dialog box, Fault Actions tab.

**Table 25 - Fault Action Definitions**

Fault Action	Definition
Shutdown	Axis is disabled as defined in <a href="#">Table 26</a> . In addition, the axis in Logix enters the Shutdown state, which disables any axes that are using this axis as a camming or gearing master. The AxisHomedStatus tag for the faulted axis is cleared. Shutdown is the most severe action to a fault and it is usually reserved for faults that could endanger the machine or operator if power is not removed as quickly as possible.
Disable Drive	The axis is disabled as defined in the <a href="#">Table 26</a> .
Stop Motion	The axis decelerates at the maximum deceleration rate (set in RSLogix 5000 software>Axis Properties>Dynamics tab). Once the axis has come to a stop, the servo loops remain enabled but no further motion can be generated until the fault is reset. This is the gentlest stopping mechanism in response to a fault. It is usually used for less severe faults.
Status Only	System continues to operate. Status is displayed on the IPIM module.

Only selected faults are programmable. [Table 26](#) indicates which faults have a programmable RSLogix Fault Action. Faults that do not have a programmable fault action will have the Shutdown action described in [Table 25](#).

**Figure 36 - RSLogix 5000 Axis Properties - Fault Actions Tab**



**Table 26 - Exception and Fault Behavior**

IPIM Display (RSLogix Drive Fault)	IDM Status Indicator	Potential Cause	Possible Solution	RSLogix Programmable Fault Action	Fault Behavior
E04 – Motor Overtemp (MotorOvertempFault)	Flashing Red	Excessive IDM unit temperature.	<ul style="list-style-type: none"> <li>Lower ambient temperature, increase IDM unit cooling.</li> </ul>	Yes	Decel/Disable
E05 – Power Fault (DriveOvercurrentFault)	Flashing Red	Operation above the IGBT instantaneous current rating or IPIM module power supply undervoltage.	<ul style="list-style-type: none"> <li>Operate within the instantaneous power rating.</li> <li>Reduce acceleration rates.</li> <li>If fault persists, replace IDM unit.</li> </ul>	No	Coast/Disable/ Open Contactor Enable
E06 – Positive/Negative Hard Overtravel (Pos/NegHardOvertravelFault)	Flashing Red	Axis moved beyond the physical travel limits in the positive/negative direction.	<ul style="list-style-type: none"> <li>Verify motion profile.</li> <li>Verify axis configuration in software.</li> </ul>	Yes	Decel/Disable

**Table 26 - Exception and Fault Behavior (continued)**

IPIM Display (RSLogix Drive Fault)	IDM Status Indicator	Potential Cause	Possible Solution	RSLogix Programmable Fault Action	Fault Behavior
<b>E09</b> – Bus Under Voltage (DriveUndervoltageFault)	Flashing Red	DC bus voltage fell below the undervoltage limit while the axis was enabled.	<ul style="list-style-type: none"> <li>Disable prior to removing power.</li> <li>Check wiring.</li> </ul>	No	Coast/Disable/ Open Contactor Enable
<b>E10</b> – Bus Over Voltage (DriveOvervoltageFault)	Flashing Red	The DC bus voltage is above limits.	<ul style="list-style-type: none"> <li>Change the deceleration or motion profile.</li> <li>Use a larger IDM unit.</li> <li>Install shunt module.</li> </ul>	No	Coast/Disable/ Open Contactor Enable
<b>E16</b> – Positive/Negative Soft Overtravel (Pos/NegSoftOvertravelFault)	Flashing Red	Positive/Negative software overtravel limit exceeded.	<ul style="list-style-type: none"> <li>Verify motion profile.</li> <li>Verify overtravel settings are appropriate.</li> </ul>	Yes	Decel/Disable
<b>E18</b> – Over Speed (OverspeedFault)	Flashing Red	Excessive IDM unit speed.	<ul style="list-style-type: none"> <li>Check tuning.</li> <li>Verify user limit.</li> </ul>	No	Coast/Disable
<b>E19</b> – Follow Error (PositionErrorFault)	Flashing Red	Excessive position error.	<ul style="list-style-type: none"> <li>Increase the feed forward gain.</li> <li>Increase following error limit or time.</li> <li>Check position loop tuning.</li> <li>Verify sizing of system.</li> <li>Verify mechanical integrity of system within specification limits.</li> </ul>	Yes	Coast/Disable
<b>E30</b> – Motor Feedback Comm (MotFeedbackFault)	Flashing Red	Error communicating with position feedback device.	<ul style="list-style-type: none"> <li>Cycle power.</li> <li>If fault persists, replace IDM unit.</li> </ul>	No	Decel/Disable
<b>E37</b> – Phase Loss (PowerPhaseLossFault)	Flashing Red	Problem with the AC power connection on IAM module.	<ul style="list-style-type: none"> <li>Check IAM input AC voltage on all phases.</li> <li>Disable the IDM unit before removing power.</li> </ul>	No	Decel/Disable
<b>E38</b> – Sercos Ring Flt (SercosFault)	Flashing Red	Lost sercos communications.	<ul style="list-style-type: none"> <li>Check that sercos cable is present and connected properly.</li> </ul>	No	Decel/Disable
<b>E43</b> – Drive Enable Flt (DriveEnableInputFault)	Flashing Red	Missing IPIM module Enable input signal.	<ul style="list-style-type: none"> <li>Disable the IPIM module Enable hardware input fault.</li> <li>Verify that IPIM module Enable hardware input is active whenever the IPIM module is enabled.</li> </ul>	Yes	Decel/Disable
<b>E48</b> – Internal Communications Fault (DriveHardFault)	Solid Red	Noise or hardware failure on the I2C or SPI bus.	<ul style="list-style-type: none"> <li>Power Cycle.</li> <li>If fault persists, replace IDM unit.</li> </ul>	No	Coast/Disable/ Open Contactor Enable
<b>E49</b> – Safety Fault (DriveHardFault)	Flashing Red	Safe-off input timing mismatch.	<ul style="list-style-type: none"> <li>Verify wire terminations, cable/header connections, and +24V.</li> <li>Reset error and run proof test.</li> <li>If fault persists, replace module.</li> </ul>	No	Coast/Disable/ Open Contactor Enable
<b>E50</b> – Sercos Same Addr (SercosRingFault)	Solid Red	Duplicate node address detected on sercos ring.	<ul style="list-style-type: none"> <li>Verify that each sercos module is assigned a unique node address.</li> </ul>	No	Decel/Disable
<b>E54</b> – Current Feedback Hardware Fault (DriveHardFault)	Solid Red	Excessive feedback current was detected.	<ul style="list-style-type: none"> <li>Power Cycle.</li> <li>If fault persists, replace IDM unit.</li> </ul>	No	Coast/Disable/ Open Contactor Enable
<b>E65</b> – Hookup (DriveHardFault)	Flashing Red	Hookup procedure failed.	<ul style="list-style-type: none"> <li>Check IDM unit power/feedback wiring.</li> <li>Refer to RSLogix 5000 on-screen message for resolution.</li> </ul>	No	Coast/Disable
<b>E66</b> – Autotune (DriveHardFault)	Flashing Red	Autotune procedure failed.	<ul style="list-style-type: none"> <li>Check IDM unit power/feedback wiring.</li> <li>Refer to RSLogix 5000 on-screen message for resolution.</li> <li>Perform Hookup Test in RSLogix 5000 software.</li> <li>Consult RSLogix 5000 help screen.</li> </ul>	No	Coast/Disable
<b>E67</b> – Task Init (DriveHardFault)	Solid Red	Operating system failed.	<ul style="list-style-type: none"> <li>Cycle power.</li> <li>If fault persists, replace module.</li> </ul>	No	Coast/Disable/ Open Contactor Enable

**Table 26 - Exception and Fault Behavior (continued)**

IPIM Display (RSLogix Drive Fault)	IDM Status Indicator	Potential Cause	Possible Solution	RSLogix Programmable Fault Action	Fault Behavior
<b>E09</b> – Bus Under Voltage (DriveUndervoltageFault)	Flashing Red	DC bus voltage fell below the undervoltage limit while the axis was enabled.	<ul style="list-style-type: none"> <li>Disable prior to removing power.</li> <li>Check wiring.</li> </ul>	No	Coast/Disable/ Open Contactor Enable
<b>E10</b> – Bus Over Voltage (DriveOvervoltageFault)	Flashing Red	The DC bus voltage is above limits.	<ul style="list-style-type: none"> <li>Change the deceleration or motion profile.</li> <li>Use a larger IDM unit.</li> <li>Install shunt module.</li> </ul>	No	Coast/Disable/ Open Contactor Enable
<b>E16</b> – Positive/Negative Soft Overtravel (Pos/NegSoftOvertravelFault)	Flashing Red	Positive/Negative software overtravel limit exceeded.	<ul style="list-style-type: none"> <li>Verify motion profile.</li> <li>Verify overtravel settings are appropriate.</li> </ul>	Yes	Decel/Disable
<b>E18</b> – Over Speed (OverspeedFault)	Flashing Red	Excessive IDM unit speed.	<ul style="list-style-type: none"> <li>Check tuning.</li> <li>Verify user limit.</li> </ul>	No	Coast/Disable
<b>E19</b> – Follow Error (PositionErrorFault)	Flashing Red	Excessive position error.	<ul style="list-style-type: none"> <li>Increase the feed forward gain.</li> <li>Increase following error limit or time.</li> <li>Check position loop tuning.</li> <li>Verify sizing of system.</li> <li>Verify mechanical integrity of system within specification limits.</li> </ul>	Yes	Coast/Disable
<b>E30</b> – Motor Feedback Comm (MotFeedbackFault)	Flashing Red	Error communicating with position feedback device.	<ul style="list-style-type: none"> <li>Cycle power.</li> <li>If fault persists, replace IDM unit.</li> </ul>	No	Decel/Disable
<b>E37</b> – Phase Loss (PowerPhaseLossFault)	Flashing Red	Problem with the AC power connection on IAM module.	<ul style="list-style-type: none"> <li>Check IAM input AC voltage on all phases.</li> <li>Disable the IDM unit before removing power.</li> </ul>	No	Decel/Disable
<b>E38</b> – Sercos Ring Flt (SercosFault)	Flashing Red	Lost sercos communications.	<ul style="list-style-type: none"> <li>Check that sercos cable is present and connected properly.</li> </ul>	No	Decel/Disable
<b>E43</b> – Drive Enable Flt (DriveEnableInputFault)	Flashing Red	Missing IPIM module Enable input signal.	<ul style="list-style-type: none"> <li>Disable the IPIM module Enable hardware input fault.</li> <li>Verify that IPIM module Enable hardware input is active whenever the IPIM module is enabled.</li> </ul>	Yes	Decel/Disable
<b>E48</b> – Internal Communications Fault (DriveHardFault)	Solid Red	Noise or hardware failure on the I2C or SPI bus.	<ul style="list-style-type: none"> <li>Power Cycle.</li> <li>If fault persists, replace IDM unit.</li> </ul>	No	Coast/Disable/ Open Contactor Enable
<b>E49</b> – Safety Fault (DriveHardFault)	Flashing Red	Safe-off input timing mismatch.	<ul style="list-style-type: none"> <li>Verify wire terminations, cable/header connections, and +24V.</li> <li>Reset error and run proof test.</li> <li>If fault persists, replace module.</li> </ul>	No	Coast/Disable/ Open Contactor Enable
<b>E50</b> – Sercos Same Addr (SercosRingFault)	Solid Red	Duplicate node address detected on sercos ring.	<ul style="list-style-type: none"> <li>Verify that each sercos module is assigned a unique node address.</li> </ul>	No	Decel/Disable
<b>E54</b> – Current Feedback Hardware Fault (DriveHardFault)	Solid Red	Excessive feedback current was detected.	<ul style="list-style-type: none"> <li>Power Cycle.</li> <li>If fault persists, replace IDM unit.</li> </ul>	No	Coast/Disable/ Open Contactor Enable
<b>E65</b> – Hookup (DriveHardFault)	Flashing Red	Hookup procedure failed.	<ul style="list-style-type: none"> <li>Check IDM unit power/feedback wiring.</li> <li>Refer to RSLogix 5000 on-screen message for resolution.</li> </ul>	No	Coast/Disable
<b>E66</b> – Autotune (DriveHardFault)	Flashing Red	Autotune procedure failed.	<ul style="list-style-type: none"> <li>Check IDM unit power/feedback wiring.</li> <li>Refer to RSLogix 5000 on-screen message for resolution.</li> <li>Perform Hookup Test in RSLogix 5000 software.</li> <li>Consult RSLogix 5000 help screen.</li> </ul>	No	Coast/Disable
<b>E67</b> – Task Init (DriveHardFault)	Solid Red	Operating system failed.	<ul style="list-style-type: none"> <li>Cycle power.</li> <li>If fault persists, replace module.</li> </ul>	No	Coast/Disable/ Open Contactor Enable

**Table 26 - Exception and Fault Behavior (continued)**

IPIM Display (RSLogix Drive Fault)	IDM Status Indicator	Potential Cause	Possible Solution	RSLogix Programmable Fault Action	Fault Behavior
<b>E69</b> – Objects Init (DriveHardFault)	Solid Red	Nonvolatile memory is corrupt due to control board hardware failure.	• Load default parameters, save to nonvolatile memory, and recycle power or reset the IPIM module.	No	Coast/Disable/ Open Contactor Enable
<b>E70</b> – NV Mem Init (DriveHardFault)	Solid Red	Nonvolatile memory is corrupt due to control board software error.	• Load default parameters, save to nonvolatile memory, and recycle power or reset the IPIM module.	No	Coast/Disable/ Open Contactor Enable
<b>E71</b> – Memory Init (DriveHardFault)	Solid Red	RAM or nonvolatile memory validation failure.	• Cycle power. • If fault persists, replace module.	No	Coast/Disable/ Open Contactor Enable
<b>E72</b> – Drive Overtemperature (DriveOvertempFault)	Flashing Red	Excessive heat in the circuitry.	• Replace the failed module. • Check the ambient temperature. • Change the command profile to reduce speed or increase time. • Check the mounting clearance.	Yes	Decel/Disable
<b>E76</b> – CAN Init (DriveHardFault)	Solid Red	CAN hardware initialization fault detected.	• Reset System. • If fault persists, replace system module.	No	Coast/Disable/ Open Contactor Enable
<b>E78</b> – Sercos Init (DriveHardFault)	Solid Red	Sercos hardware fault detected.	• Cycle power. • If fault persists, replace module.	No	Coast/Disable/ Open Contactor Enable
<b>E109</b> – IGBT Over-temperature (DriveOvertempFault)	Flashing Red	Excessive IGBT temperature.	• Lower ambient temperature. • Reduce motion profile.	No	Coast/Disable/ Open Contactor Enable

## Use a Web Browser to Monitor System Status


The IPIM module supports a basic web interface for common status reporting and network configuration attributes, including:

- Diagnostics
- IPIM Indicators
- IPIM Information
- Network Settings
- Ethernet Statistics
- CIP™ Statistics
- Monitor Signals
- Fault Log
- Browse IDMs
- IDM Indicators
- Monitor IDM Signals

To access the web interface:

1. Using an Ethernet cable, connect your computer to one of the Ethernet ports on the IPIM module (refer to [Figure 11](#) on [page 40](#) for location).
2. Open a web browser program<sup>(1)</sup> and enter the IP address of the IPIM module.


The Home screen will be displayed.



3. Selecting IPIM Indicators provides indicator status.



4. Network settings displays a summary of the various parameters.



(1) Internet Explorer version 6.0 (or greater) or Mozilla Firefox version 4.0 (or greater) is required.

**Notes:**

## Remove and Replace the Kinetix 6000M IPIM Module

This chapter provides removal and replacement procedures for your Kinetix® 6000M IPIM module.

Refer to your Kinetix 6000 Multi-axis Servo Drives User Manual, publication [2094-UM001](#), or Kinetix 6200 and Kinetix 6500 Modular Multi-axis Servo Drives User Manual, publication [2094-UM002](#), for other replacement procedures.

Topic	Page
Before You Begin	103
Remove the IPIM Module	104
Replace the IPIM Module	105



**ATTENTION:** This drive contains electrostatic discharge (ESD) sensitive parts and assemblies. You are required to follow static-control precautions when you install, test, service, or repair this assembly. If you do not follow ESD control procedures, components can be damaged. If you are not familiar with static control procedures, refer to *Guarding Against Electrostatic Damage*, publication [8000-4.5.2](#), or any other applicable ESD awareness handbook.

### Before You Begin

You will need these tools available before you begin removal and replacement procedures:

- A small screwdriver, 3.5 mm (0.14 in.)
- Voltmeter

## Remove the IPIM Module

Follow these steps to remove your IPIM module from the Bulletin 2094 power rail.

1. Verify that all control and input power has been removed from the system.



**ATTENTION:** To avoid shock hazard or personal injury, assure that all power has been removed before proceeding. This system may have multiple sources of power. More than one disconnect switch may be required to de-energize the system.

2. Wait five minutes for the DC bus to discharge completely before proceeding.




**ATTENTION:** This product contains stored energy devices. To avoid hazard of electrical shock, verify that all voltage on capacitors has been discharged before attempting to service, repair, or remove this unit. You should attempt the procedures in this document only if you are qualified to do so and are familiar with solid-state control equipment and the safety procedures in publication NFPA 70E.

3. Label and remove all connectors from the IPIM module you are removing.


To identify each connector, refer to [page 40](#).

4. Remove the hybrid cable from the cable shield clamp, as shown.



5. Loosen the mounting screw (bottom center of module).
6. Grasp the top and bottom of the module with both hands and gently pull the module away from the connectors enough to clear the guide pins (module will pivot on top bracket).

7. Lift the bracket out of the power rail slot and remove the module from the power rail.



## Replace the IPIM Module

Follow these steps to replace the IPIM module on the Bulletin 2094 power rail.

1. Inspect the module connector pins and power rail connectors and remove any foreign objects.
2. Hang the module mounting bracket from the slot on the power rail.

**IMPORTANT** Power rails must be in vertical orientation before replacing drive modules or pins may not seat properly.

3. Pivot module downward and align the guide pin on the power rail with the guide pin hole in the back of the module (refer to the figure above).
4. Gently push the module against the power rail connectors and into the final mounting position.
5. Use 2.26 N•m (20 lb•in) torque to tighten the mounting screw.
6. Reconnect the module connectors.
7. Reapply power to the system.
8. Verify that the system is operating properly.

**Notes:**

## Kinetix 6000M Safe Torque-off Feature

This appendix introduces you to how the safe torque-off feature meets the requirements of Performance Level d (PLd) and Category 3 (Cat3) per EN ISO 13849-1 and SIL CL 2 per IEC EN 61508, EN 61800-5-2 and EN 62061.

Topic	Page
Certification	107
Description of Operation	108
PFD, PFH, and MTTFd Definitions	111
PFD, PFH, and MTTFd Data	111
Wire Your Safe Torque-off Circuit	111
IDM Safe Torque-off Feature	112
IDM System Safe Torque-off Example	113
Cascade the Safe Torque-off Signal	115
Safe Torque-off Signal Specifications	115

### Certification

The TÜV Rheinland group has approved the Kinetix® 6000M integrated drive-motor system for use in safety-related applications up to EN ISO 13849-1 performance level d (PLd) and category 3, SIL CL 2 per IEC EN 61508, EN 61800-5-2 and EN 62061, in which removing the motion producing power is considered to be the safe state.

### Important Safety Considerations

The system user is responsible for the following:

- Validation of any sensors or actuators connected to the system
- Completing a machine-level risk assessment
- Certification of the machine to the desired EN ISO 13849-1 performance level or EN 62061 SIL level
- Project management and proof testing

## Category 3 Requirements According to EN ISO 13849-1

Safety-related parts are designed with these attributes:

- A single fault in any of these parts does not lead to the loss of the safety function
- A single fault is detected whenever reasonably practicable
- Accumulation of undetected faults can lead to the loss of the safety function, which results in failure to remove motion producing power from the motor.

### Stop Category Definition

Stop category 0 as defined in EN 60204 or Safe Torque Off as defined by EN 61800-5-2 is achieved with immediate removal of motion producing power to the actuator.

**IMPORTANT** In the event of a malfunction, the most likely stop category is category 0. When designing the machine application, timing and distance should be considered for a coast to stop. For more information regarding stop categories, refer to EN 60204-1.

### Performance Level (PL) and Safety Integrity Level (SIL)

For safety-related control systems, Performance Level (PL), according to EN ISO 13849-1, and SIL levels, according to EN 61508 and EN 62061, include a rating of the systems ability to perform its safety functions. All of the safety-related components of the control system must be included in both a risk assessment and the determination of the achieved levels. Refer to the EN ISO 13849-1, EN 61508, and EN 62061 standards for complete information on requirements for PL and SIL determination.

## Description of Operation

The safe torque-off feature provides a method, with sufficiently low probability of failure, to force the power-transistor control signals to a disabled state. When disabled, or any time power is removed from the safety enable inputs, all of the IDM output-power transistors are released from the On-state. This effectively removes power generated by each IDM unit connected to a single IPIM module and using connections to an external safety device (E-stop, light curtains, and so on). This results in a condition where the IDM unit is coasting (stop category 0). Disabling the power transistor output does not provide mechanical isolation of the electrical output, which may be required for some applications.

Under normal operation, the safe torque-off inputs are energized. If either of the safety enable inputs are de-energized, then all of the output power transistors will turn off. The safe torque-off response time is less than 12 ms.




**ATTENTION:** Permanent magnet motors may, in the event of two simultaneous faults in the IGBT circuit, result in a rotation of up to 180 electrical degrees.



**ATTENTION:** If any of the safety enable inputs de-energize, then the SafeOffModeActiveStatus bit of the drive status word in the Axis Tag structure will be set to 1. It will reset to 0 when both safety enable inputs are energized within 1 second (see [Figure 37](#)). The safety fault occurs after 1 second.

**Figure 37 - System Operation when Inputs are Meeting Timing Requirements**




Item	Description
①	At least one input is switched-off. SafeOffModeActiveStatus bit is set to 1.
②	Second input is switched-off within 1 second.
③	First input is switched-on.
④	Second input is switched-on within 1 second of the first input.
⑤	Both inputs change state within 1 second, therefore DriveHardFault is not posted.
⑥	SafeOffModeActiveStatus bit set back to 0 if events 3 and 4 occur within a 1 second time interval.

## Troubleshoot the Safe Torque-off Function

Error Code	Fault Message RSLogix (HIM)	Anomaly	Potential Cause	Possible Resolution
E49	DriveHardFault (safe torque-off HW Flt)	Safe torque-off function mismatch. System will not allow motion. Safe torque-off mismatch is detected when safety inputs are in a different state for more than 1 second.	<ul style="list-style-type: none"> <li>Loose wiring at safe torque-off connector.</li> <li>Miswiring of the safe torque-off connector.</li> <li>Cable/header not seated properly in safe torque-off connector.</li> <li>Safe torque-off circuit missing +24V DC.</li> </ul>	<ul style="list-style-type: none"> <li>Verify wire terminations, cable/header connections, and +24V.</li> <li>Reset error and run proof test.</li> <li>If error persists, return the module to Rockwell Automation.</li> </ul>


[Figure 38](#) demonstrates when the safe torque-off mismatch is detected and a DriveHardFault is posted.

**Figure 38 - System Operation in the Event that the Safety Enable Inputs Mismatch**



When one safety input is turned off, the second input must also be turned off, otherwise a fault is asserted (see [Figure 39](#)). The fault is asserted even if the first safety input is turned on again.

**Figure 39 - System Operation in the Event that the Safety Enable Inputs Mismatch Momentarily**



**ATTENTION:** The safe torque-off fault (E49) is detected upon demand of the safe torque-off function. After troubleshooting, a safety function must be executed to verify correct operation.

**IMPORTANT** The Safe Torque Off fault (E49) can be reset only if both inputs are in the off state for more than 1 second. After the E49 reset requirement is satisfied, an MCSR command in RSLogix software should be issued to reset the DriveHardFault.

## PFD, PFH, and MTTFd Definitions

Safety-related systems can be classified as operating in either a Low Demand mode, or in a High Demand/Continuous mode:

- Low Demand mode: where the frequency of demands for operation made on a safety-related system is no greater than one per year or no greater than twice the proof-test frequency.
- High Demand/Continuous mode: where the frequency of demands for operation made on a safety-related system is greater than once per year.

The SIL value for a low demand safety-related system is directly related to order-of-magnitude ranges of its average probability of failure to satisfactorily perform its safety function on demand or, simply, average probability of failure on demand (PFD). The SIL value for a High Demand/Continuous mode safety-related system is directly related to the probability of a dangerous failure occurring per hour (PFH).

## PFD, PFH, and MTTFd Data

These PFD and PFH calculations are based on the equations from EN 61508 and show worst-case values.

This table provides data for a 20-year proof test interval and demonstrates the worst-case effect of various configuration changes on the data.

Determination of safety parameters is based on the assumption that the system operates in high demand mode and that the safety function will be requested at least once a year.

**Table 27 - PFD and PFH for 20-year Proof Test Interval**

Attribute	Value
PFH (1e-9)	0.35
PFD (1e-3)	0.062
Proof test (years)	20

## Wire Your Safe Torque-off Circuit

Refer to [Safe Torque-off Connector](#) on [page 42](#) for wiring details.

**IMPORTANT** The National Electrical Code and local electrical codes take precedence over the values and methods provided.

**IMPORTANT** To be sure of system performance, run wires and cables in the wireways as established in the user manual.

**IMPORTANT** Pins 8 and 9 (24V+) are used only by the motion-allowed jumper. When wiring to the wiring-plug header, **the 24V supply** (for an external safety device that triggers the safe torque-off request) **must come from an external source**, otherwise system performance will be jeopardized.

## European Union Directives

If this product is installed within the European Union or EEC regions and has the CE mark, the following regulations apply.

### *CE Conformity*

Conformity with the Low Voltage Directive and Electromagnetic Compatibility (EMC) Directive is demonstrated by using harmonized European Norm (EN) standards published in the Official Journal of the European Communities. The safe torque-off circuit complies with the EN standards when installed according to instructions found in this manual.

### *EMC Directive*

This unit is tested to meet Council Directive 2004/108/EC Electromagnetic Compatibility (EMC) by using these standards, in whole or in part:

- EN 61800-3 - Adjustable Speed Electrical Power Drive Systems, Part 3 - EMC Product Standard including specific test methods
- EN 61326-2-1 EMC - Immunity requirements for safety-related systems

The product described in this manual is intended for use in an industrial environment.

CE Declarations of Conformity are available online at [rok.auto/certifications](http://rok.auto/certifications).

### *Low Voltage Directive*

These units are tested to meet Council Directive 2006/95/EC Low Voltage Directive. The EN 60204-1 Safety of Machinery-Electrical Equipment of Machines, Part 1-Specification for General Requirements standard applies in whole or in part. Additionally, the standard EN 50178 Electronic Equipment for use in Power Installations apply in whole or in part.

Refer to the Kinetix Rotary Motion Specifications Technical Data, publication [KNX-TD001](#), for environmental and mechanical specifications.

## IDM Safe Torque-off Feature

The safe torque-off circuit, when used with suitable safety components, provides protection according to EN ISO 13849-1 (PLd), Cat3 or according to EN 62061 (SIL2). The safe torque-off option is just one safety control system. All components in the system must be chosen and applied correctly to achieve the desired level of operator safeguarding.

The safe torque-off circuit is designed to safely turn off all of the output-power transistors.

You can use the safe torque-off circuit in combination with other safety devices to achieve the stop and protection-against-restart as specified in IEC 60204-1.

Refer to the Kinetix Safe-off Feature Safety Reference Manual, publication [GMC-RM002](#), for wiring examples.




**ATTENTION:** This option may be suitable for performing mechanical work on the drive system or affected area of a machine only. It does not provide electrical safety.



**SHOCK HAZARD:** In Safe Torque-off mode, hazardous voltages may still be present at the IDM unit. To avoid an electric shock hazard, disconnect power to the system and verify that the voltage is zero before performing any work on the IDM unit.

## Safe Torque-off Feature Bypass

Each IPIM module ships with the (9-pin) wiring-plug header and motion-allowed jumper installed in the safe-off connector. With the motion-allowed jumper installed, the safe-off feature is not used.




## IDM System Safe Torque-off Example

[Figure 40](#) shows a typical safe torque-off configuration. Refer to Kinetix Safe-off Feature Safety Reference Manual, publication [GMC-RM002](#), for further information and wiring diagrams.

For additional information regarding Allen-Bradley® safety products, including safety relays, light curtain, and gate interlock applications, refer to the Safety Products Catalog, website <http://www.ab.com/catalogs>.

Figure 40 - Typical Kinetix 6000M and Kinetix 6000 Safe-off Configuration



**IMPORTANT** When using the Kinetix 6000M system in a cascaded system with Kinetix 6000 drives, the IPIM module only forwards the safety feedback monitoring signals. Additionally, it is absolutely necessary that the safety feedback connections be cascaded through each drive on the power rail so that any safety device can recognize when the Kinetix 6000 drive opens the feedback contactor in the cascaded safety string.

## Cascade the Safe Torque-off Signal

The total number of IAM, AM, and IPIM modules in a single cascaded safety circuit is limited due to the current carrying capacity of the cascaded safety wiring.

Use the following equation to calculate the number of IDM units that can be added to a cascaded safety chain if Kinetix 6000-S safety accessories are used.

$$m = (16-n) \times 3 \quad \text{where:}$$

$m$  = maximum number of IDM units

$n$  = number of Kinetix 6000-S modules in the safety chain.

---

**EXAMPLE** Using [Figure 40](#),  $n$  equals 5 since there are 5 Kinetix 6000-S modules in the system. The maximum number of IDM units that can be connected to the cascaded safety circuit through one or more IPIM modules is:

$$m = (16-5) \times 3 = 33.$$


---

## Safe Torque-off Signal Specifications

This table provides specifications for the safe torque-off signals used.

Attribute	Value
Safety inputs	Input current
	less than 10 mA
	Input ON voltage range
	18...26.4 V DC
	Maximum input OFF voltage
	5V DC
	Input OFF current
2 mA @ $V_{in}$ less than 5V DC	
Pulse rejection width	
700 $\mu$ s	
External power supply	
SELV/PELV	
Input type	
Optically isolated and reverse voltage protected	


**Notes:**

## Interconnect Diagram

This appendix provides a wiring example for the Kinetix® 6000M integrated drive-motor system.

Topic	Page
IPIM Module and IDM Unit Wiring Example	118

Figure 41 - IPIM Module and IDM Unit Wiring Example



## Upgrade the Kinetix 6000M System Firmware

This appendix provides procedures for upgrading firmware for the Kinetix® 6000M integrated drive-motor (IDM) units and IDM power interface modules (IPIM).

Topic	Page
Before You Begin	119
Configure Logix Communication	120
IPIM Module Firmware Upgrade	121
IDM Unit Firmware Upgrade	126
Verify the Firmware Upgrade	130

Upgrading firmware for the Kinetix 6000M system is done by using ControlFLASH software. The procedure for upgrading the IDM units uses the sercos interface, similar to axis modules. However, upgrading firmware on the IPIM module is accomplished over the EtherNet/IP™ network.

### Before You Begin

You need the following software and information before you begin.

Description	Cat. No.	Firmware Revision or Software Version
RSLogix 5000® software	9324-RLD300NE	20.010 <sup>(2)</sup> or later
ControlLogix® sercos module	1756-MxxSE	20.007 or later
CompactLogix™ sercos module	1768-M04SE	20.007 or later
SoftLogix™ sercos PCI card	1784-PM16SE	20.007 or later
RSLinx® software		2.590 or later
ControlFLASH™ software kit <sup>(1)</sup>		From website

Catalog number of the targeted IPIM module and IDM unit you want to upgrade

Network path to the targeted IPIM module and IDM unit.

(1) Download the ControlFLASH kit from <http://support.rockwellautomation.com/controlflash>. Contact Rockwell Automation Technical Support at (440) 646-5800 for assistance. For more ControlFLASH information (not drive specific), refer to the ControlFLASH Firmware Upgrade Kit Quick Start, publication [1756-QS105](#).

(2) Version 20.000 may be used if the motion database has been updated.

**IMPORTANT** Control power must be present prior to upgrading your IPIM module or IDM units.



**ATTENTION:** To avoid personal injury or damage to equipment during the firmware upgrade due to unpredictable motor activity, do not apply 3-phase AC or common-bus DC input power to the IAM module.

## Configure Logix Communication


This procedure assumes that your communication method to the Logix controller is using the Ethernet protocol. It is also assumed that your Logix Ethernet module has already been configured.

For more information, refer to the ControlLogix System User Manual, publication [1756-UM001](#).

Follow these steps to configure Logix communication.

1. Open your RSLinx Classic software.
2. From the Communications pull-down menu, choose Configure Drivers.

The Configure Drivers dialog box opens.



3. From the Available Drive Types pull-down menu, choose Ethernet devices.
4. Click Add New.


The Add New RSLinx Classic Driver dialog box opens.

5. Type the new driver name.



6. Click OK.

The Configure driver dialog box opens.




7. Type the IP address of your Logix Ethernet module.

The IP address shown is an example. Yours will be different.

8. Click OK.

The new Ethernet driver appears under Configured Drivers.



9. Click Close.


10. Minimize the RSLinx application dialog box.

## IPIM Module Firmware Upgrade

**IMPORTANT** The IPIM module **does not** accept a firmware upgrade request when it has an active CIP™ I/O connection.

An active CIP I/O connection exists when the IPIM module has been integrated into the I/O configuration tree in RSLogix 5000 software. The IPIM module only accepts a firmware upgrade request when the connection is inhibited. The connection can be inhibited from I/O Configuration>Enet Module>IPIM Module Properties>Connection tab (see below). The IPIM module always accepts a firmware upgrade request if it is connected to a Logix Ethernet module, but has not been integrated in the I/O configuration tree.

Additionally, the firmware upgrade can be accomplished by disconnecting the IPIM module from the Logix Ethernet module and establishing a direct connection to a computer with ControlFLASH software.




Follow these steps to select the IPIM module to upgrade.

1. Make sure the IPIM module will accept a firmware request prior to attempting the firmware upgrade (see [page 121](#)).
2. Open your ControlFLASH software.

You can access the ControlFLASH software by either of these methods:


- From the Tools menu in RSLogix 5000 software, choose ControlFLASH.
- Choose Start>Programs>FLASH Programming Tools>ControlFLASH.

The Welcome to ControlFLASH dialog box opens.




3. Click Next.

The Catalog Number dialog box opens.




4. Select your IPIM module.
5. Click Next.

The Select Device to Update dialog box opens.




6. Expand your Ethernet node and EtherNet/IP network module.
7. Select the IPIM module to upgrade.
8. Click OK.

The Firmware Revision dialog box opens.



9. Select the firmware revision to upgrade.
10. Click Next.

The Summary dialog box opens.




11. Confirm the IPIM module catalog number and firmware revision.
12. Click Finish.

This ControlFLASH warning dialog box opens.




13. Click Yes (only if you are ready).

This ControlFLASH warning dialog box opens.




14. Acknowledge the warning and click OK.

The Progress dialog box opens and upgrading begins.



After the upgrade information is sent to the IPIM module, the module resets and performs diagnostic checking.




15. Wait for the Progress dialog box to timeout.

It is normal for this process to take several minutes.

**IMPORTANT** Do not cycle power to the drive during this process or the firmware upgrade will not complete successfully.

16. The Update Status dialog box opens and indicates success or failure as described below

Upgrading Status	If
Success	<ul style="list-style-type: none"> <li>1. Update complete appears in a GREEN Status dialog box.</li> <li>2. Go to <a href="#">step 17</a>.</li> </ul>
Failure	<ul style="list-style-type: none"> <li>1. Update failure appears in a RED Status dialog box.</li> <li>2. Refer to ControlFLASH Firmware Upgrade Kit Quick Start, publication <a href="#">1756-QS105</a>, for troubleshooting information.</li> </ul>



17. Click OK.

## IDM Unit Firmware Upgrade


Follow these steps to select the IDM unit to upgrade.

1. Open your ControlFLASH software.

You can access the ControlFLASH software by either of these methods:


- From the Tools menu in RSLogix 5000 software, choose ControlFLASH.
- Choose Start>Programs>FLASH Programming Tools>ControlFLASH.

The Welcome to ControlFLASH dialog box opens.



2. Click Next.


The Catalog Number dialog box opens.



3. Select your IDM unit.


4. Click Next.

The Select Device to Update dialog box opens.




5. Expand your Ethernet node, Logix backplane, and EtherNet/IP network module.
6. Select the IDM unit to upgrade.
7. Click OK.

The Firmware Revision dialog box opens.



8. Select the firmware revision to upgrade.
9. Click Next.

The Summary dialog box opens.




10. Confirm the IDM unit catalog number and firmware revision.
11. Click Finish.

This ControlFLASH warning dialog box opens.




12. Click Yes (only if you are ready).

This ControlFLASH warning dialog box opens.




13. Acknowledge the warning and click OK.

The Progress dialog box opens and upgrading begins.



After the upgrade information is sent to the IDM unit, the unit resets and performs diagnostic checking.



14. Wait for the Progress dialog box to time out.

It is normal for this process to take several minutes.

**IMPORTANT** Do not cycle power to the drive during this process or the firmware upgrade will not complete successfully.

15. The Update Status dialog box opens and indicates success or failure as described below.

Upgrading Status	If
Success	<ol style="list-style-type: none"> <li>1. Update complete appears in a GREEN Status dialog box.</li> <li>2. Go to <a href="#">step 16</a>.</li> </ol>
Failure	<ol style="list-style-type: none"> <li>1. Update failure appears in a RED Status dialog box.</li> <li>2. Refer to ControlFLASH Firmware Upgrade Kit Quick Start, publication <a href="#">1756-QS105</a>, for troubleshooting information.</li> </ol>




16. Click OK.

## Verify the Firmware Upgrade

Follow these steps to verify your firmware upgrade was successful. This procedure uses an IDM unit as an example, but applies to IPIM modules too.


**TIP** Verifying the firmware upgrade is optional.

1. Open your RSLinx software.
2. From the Communications pull-down menu, choose RSWho.



3. Expand your Ethernet node, Logix backplane, and EtherNet/IP network module.
4. Right-click the device (IPIM or IDM) and choose Device Properties.

The Device Properties dialog box opens.



5. Verify the new firmware revision level.
6. Click Close.

## **Kinetix 6000M System Sizing**

It is recommended that Motion Analyzer (version 6.000 or greater), be used for sizing your Kinetix® 6000M integrated drive-motor system. If manual calculation is desired, the following procedure can be used.

Topic	Page
Definitions	131
Manually Size the Kinetix 6000M System	132

### **Definitions**

The following definitions apply:

- Control power = 120/240 single-phase AC voltage connected to the IAM unit.
- IDM system control power = 42V DC (nominal) voltage from the IPIM module that is connected to all IDM units.
- IDM system control power load current = IDM unit control power current consumed by any single IDM unit.
- Total IDM system control power load current = Total IDM unit control power current consumed by all IDM units and connected to a single IPIM module.
- IPIM module control power load current = Total IDM unit control power load current (same as above).

## Manually Size the Kinetix 6000M System

### Step 1: Calculate the IDM unit control power load current for each IDM unit.

There are three components to the control power load current for each IDM unit:

- Constant power load
- Digital input loads
- Brake loads

Refer to the IDM unit constant load, brake load, and control power load specifications shown below.

IDM Unit Cat. No.	with Brake	Constant Control Power Load (W)	Brake Control Power Load (W)	Output Power Rating (kW)
MDF-SB1003	No	8	0	1.10
MDF-SB1003	Yes	8	15	1.02
MDF-SB1153	No	8	0	1.15
MDF-SB1153	Yes	8	19.5	1.00
MDF-SB1304	No	8	0	1.39
MDF-SB1304	Yes	8	19.5	1.24

The digital input load is calculated as follows:

$$\text{Digital Input Watts} = \sum I_{\text{inputs}} * V * \eta$$

Where:

$\sum I_{\text{inputs}}$  = The sum of all load currents on the digital input power supply to power the sensor and/or the sensor input current

V = 24V

$\eta$  = power supply efficiency = 80%

---

**IMPORTANT** Confirm that the total IDM unit control power load is less than the specified limit for the IPIM module output rating (270 W). See the Kinetix Rotary Motion Specifications Technical Data, publication [KNX-TD001](#).

---



---

**IMPORTANT** Confirm that the  $\sum I_{\text{inputs}}$  value is less than the specified limit (200 mA). See the Kinetix Rotary Motion Specifications Technical Data, publication [KNX-TD001](#).

---

*Example*

## Example System:

- Common bus leader IAM module
- Two AM modules
- One IPIM module
- Six IDM units (shown below)
- 72 total meters of hybrid cable
- Control power = 120V AC, 60 Hz
- Main power = 480V AC => 675V DC

For this example, assume that each digital input uses 50 mA at 24V DC.

IDM Unit Cat. No.	Digital Inputs	with Brake	Constant Load (W)	Dig Input Load (W)	Brake Load (W)	Total Load (W)
MDF-SB1153	2	Yes	8	3.0	19.5	30.5
MDF-SB1003	0	No	8	0	0	8
MDF-SB1304	3	No	8	4.5	0	12.5
MDF-SB1304	0	Yes	8	0	19.5	27.5
MDF-SB1003	0	No	8	0	0	8
MDF-SB1153	2	No	8	3.0	0	11
<b>Total IDM Unit Control Power Load</b>						<b>97.5</b>

The total IDM control power load is less than the specified limit for the IPIM so this is a valid system configuration.

**Step 2: Estimate the IDM system control power load current for all IDM units connected to each IPIM module.**

Estimating the load current for each IDM depends on the IDM control power voltage applied to each IDM. The loads calculated in step 1 are specified in watts, so the load current is estimated as:

$$I_i = \frac{W_i}{V_i}$$

Where:

$$I_L = \sum I_i$$

$I_i$  = IDM unit control power load current for IDM i

$W_i$  = load watts for IDM i


$V_i$  = voltage applied to IDM i

$I_L$  = Total IDM unit control power load current out of the IPIM

It is important to understand that each IDM unit passes the load current for all IDM units farther down the daisy chain. The voltage applied at each IDM unit is dependent on voltage drop in the IDM unit control power conductors of the hybrid cable. Therefore, the total cable length between an IDM unit and the IPIM module affect the voltage applied to that IDM unit. Also, the number of IDM units between an IDM unit and the IPIM module, and the cable length between each IDM unit also affects the voltage applied to the IDM unit. An accurate calculation requires modeling the system.

**IMPORTANT** Motion Analyzer version 6.000 or later contains a detailed model and accurately predicts the IDM unit control power load current and the minimum IDM unit control power voltage at the last IDM unit connected to each IDM unit.

This example illustrates a simplified load estimation method. The simplifying assumption is that all the IDM units are connected at the end of the hybrid cable so the entire cable length supports the total IDM unit control power current. This also means that the voltage applied at each IDM unit is the same and all IDM units experience the maximum voltage drop. The figure below illustrates a real system vs. the simplified system.



The specified voltage range for the IDM units is (32...44V DC). The IPIM module output voltage specification is (40.4...41.7V DC). See the Kinetix Rotary Motion Specifications Technical Data, publication [KNX-TD001](#). The equations below illustrate three options for estimating the IDM unit control power load current assuming a range of 32...42V DC using the simplified system. Steps 2 and 3 should be applied iteratively to get the best estimate, (see next step).

- Dividing the total IDM unit load power by 32V DC assumes that all the IDM units are at the end of the total cable length, and the load current is sufficiently high to result in the maximum allowable voltage drop at the end of the cable. This is a very conservative method that always results in an overestimate of the load current.

- Dividing the total IDM unit load power by 42V DC assumes that all the IDM units are at the IPIM module and experience no voltage drop from the hybrid cable. This is a very liberal method that always results in an underestimate of the load current.
- Dividing the total IDM unit load power by 37V DC represents more of an average situation where all the IDM units experience half the maximum voltage drop. This is a reasonable compromise between the other two extremes.

$$I_L = \frac{\sum W_i}{V_{32}} \quad I_L = \frac{\sum W_i}{V_{37}} \quad I_L = \frac{\sum W_i}{V_{42}}$$

---

**IMPORTANT** Confirm that the IDM control power current load is less than the specified limit for the IPIM module (6.5 A). See the Kinetix Rotary Motion Specifications Technical Data, publication [KNX-TD001](#).

---

Repeat this procedure for all IPIM modules connected to the power rail.

*Example*

Using the three equations from this step, the following IDM unit control power load currents are calculated.

IDM Unit Control Power Voltage Estimate (V DC)	IDM Unit Control Power Load Current (A)
32	3.05
37	2.64
42	2.32

The IDM unit control power current load is less than the specified limit for the IPIM module for all the load current estimates, so this is a valid system configuration.

### Step 3: Confirm that all IDM units connected to each IPIM module will have sufficient control power voltage.

This is a complicated calculation to do accurately for the same reasons stated in step 2. The purpose of this step is to confirm that the last IDM unit in the daisy chain has sufficient voltage to operate. An estimate of the applied voltage assuming all the IDM units are at the end of the total cable length can be calculated as shown below. This calculation results in a very conservative estimate. It is conservative because it assumes the load current for all IDM units is carried by the total cable length, which overestimates the voltage drop on the cable significantly.

$$V_N = 42 - I_L * L_t * R_C$$

Where:

$V_N$  = voltage at the last ( $N$ th) IDM unit (actually at all IDM units in the simplified system)

$I_L$  = load current calculated in step 2

$L_t$  = total hybrid cable length out to IDM unit  $N$  in meters

$R_C$  = resistance of the hybrid cable control power conductors in ohms/meter (0.0274275)

---

**IMPORTANT** Confirm that  $V_N$  is greater than the minimum voltage specification for the IDM (32V DC). See the Kinetix Rotary Motion Specifications Technical Data, publication [KNX-TD001](#).

---

A better result may be obtained if step 2 and step 3 are repeated iteratively. The voltage determined for step 3 should be equal to the voltage value used in step 2. This gives the most accurate value for the simplified system.

*Example*

The equations in step 3 are applied to augment the table from the previous step (shown below). The estimate of the voltage assuming all IDM units are at the end of the total cable length is included in the last column.

Average IDM Unit Control Power Voltage Estimate (VDC)	IDM Unit Control Power Load Current (A)	Voltage Estimate at Last (all) IDM Unit(s)
32	3.05	36.0
37	2.64	36.8
42	2.32	37.4

This illustrates how the 32V average voltage estimate is a poor choice for this system configuration. Using 32V as the applied IDM unit voltage for the load current calculation results in a calculated voltage at end of the total cable length of 36V, so the 32V estimate is obviously too small. Using 37V as the applied IDM unit voltage for the load current calculation results in a calculated voltage at the end of the total cable length of 36.8V. Therefore 37V is close to the best possible value and a load current value of 2.64 A will be used for the remainder of this example. The total IDM unit load current as a percentage is  $2.64/6.5 = 40.6\%$ .

The voltage at the end of the total cable length is greater than the minimum voltage specification for the IDM unit, so this is a valid system configuration.

Using a more sophisticated model, the IDM unit control power load current was calculated to be 2.42 A and the voltage at the last IDM unit to be 40.15V. The total IDM unit control power usage was 103 W, compared to 97.5 W calculated in step 1. The additional 5.5 W are losses in the hybrid cable. This illustrates how using the simplified system for sizing overestimates the total IDM unit control power current and the voltage drop along the hybrid cable.

[Table 28](#) and [Table 29](#) show the maximum cable length per IPIM module using Motion Analyzer.



The following is assumed:

- All IDM units are MDF-SB1304 (highest brake load).
- Cable length is identical between all IDM units.
- Minimum cable length is 1 m (3.3 ft).
- Every other IDM unit includes a brake, starting with #2.
- When the number of brake IDM units are greater than 1/2 the total units, they are placed at the end of the daisy chain.

---

**IMPORTANT** When using the simplified system to calculate cable length, the resulting maximum cable lengths will be much shorter.

---

**Table 28 - Max Cable Length per IPIM Module using Motion Analyzer (no digital inputs)****Table 29 - Max Cable Length per IPIM Module using Motion Analyzer (Digital Input Load = 50%)**

## **Step 4: Estimate the IAM control power load current and the power dissipation for each IPIM module based on the total IDM unit control power load.**

See the Kinetix Rotary Motion Specifications Technical Data, publication [KNX-TD001](#), for specifications on IPIM module dissipation and IPIM module control power loading. This information is also shown below. The table below contains equations that can be used to calculate the IAM control power load for each IPIM module and the heat dissipation for each IPIM module. The input value (x) is the total IDM unit control power load current (as a percentage) provided by the IPIM module. This value (in amps) was calculated in step 2. The value from step 2 must be divided by the rated IPIM module control power load current, (6.5 A).

<b>IAM Control Power Interface</b>	<b>IAM Control Power Current <sup>(1)</sup></b>	<b>IPIM Heat Dissipation <sup>(2)</sup></b>
120V AC, 50 Hz	$Y = 3.91x + 0.77$	$Y = 23.76x^2 + 20.73x + 16.54$
240V AC, 50 Hz	$Y = 2.39x + 0.60$	$Y = 18.56x^2 + 30.19x + 27.41$
120V AC, 60 Hz	$Y = 3.72x + 0.83$	$Y = 14.57x^2 + 11.40x + 20.01$
240V AC, 60 Hz	$Y = 2.45x + 0.61$	$Y = 19.63x^2 + 43.22x + 28.75$

(1)  $Y$  = IAM control power current;  $x$  = Total IDM unit control power load current percentage (value from step 2).

(2)  $Y$  = IPIM module heat dissipation from control power load;  $x$  = Total IDM unit control power load current percentage (value from step 2).

Make these calculations for all IPIM modules connected to the power rail. The control power load current values will be used to confirm the system sizing for the IAM, power rail and LIM in a later step.

### *Example*

Using the equations provided, determine values for:

- Control power = 120V AC, 60 Hz
- IDM control power load current = 2.64 A or 40.6%

Result is an IAM control power load current of 2.32 A and an IPIM module heat dissipation value of 29 W.

**Step 5: Sum the IAM control power load current for all devices on the power rail and confirm that the total IAM control power load current is less than the specified IAM and power rail limit.**

- Calculate the total IAM control power load current by summing the load current calculated in step 4 for all IPIM modules.
- Use the “Control Power Current Requirements” table in the Kinetix 6000 Multi-axis Servo Drives User Manual, publication [2094-UM001](#) or the Kinetix 6200 and Kinetix 6500 Modular Multi-axis Servo Drives User Manual, publication [2094-UM002](#), to select the control power current requirements for the IAM and any AMs on the power rail.
- Sum these two values for the total control power current requirement.

The control power load current calculated in step 5 must be less than the values in “Control Power Input Power Specifications” table in the Kinetix 6000 Multi-axis Servo Drives User Manual, publication [2094-UM001](#) or the Kinetix 6200 and Kinetix 6500 Modular Multi-axis Servo Drives User Manual, publication [2094-UM002](#).

*Example*

From the “Control Power Input Power Specifications” table in the Kinetix 6000 Multi-axis Servo Drives User Manual, publication [2094-UM001](#) or the Kinetix 6200 and Kinetix 6500 Modular Multi-axis Servo Drives User Manual, publication [2094-UM002](#), the total control power load current for the IAM and AMs is 2.25 A. The value calculated in the previous step for the IPIM is 2.32 A, resulting in a total control power load current of 4.57 A.

The control power load current is less than the maximum current specification for the IAM and power rail, 6.0 A, so this is a valid system configuration.

## Step 6: Determine if a LIM can be used to supply the IAM control power load current, or if individual discrete components must be used.

In order to use a LIM for the control power interface to the IAM, the control power load current calculated in step 5 must be less than the values listed in the Line Interface Module (LIM) Installation Instructions, publication [2094-IN005](#). If control power load current exceeds the LIM rating, separate discrete components must be used for filtering, fusing and disconnection of control power. Refer to the Kinetix 6000 Multi-axis Servo Drives User Manual, publication [2094-UM001](#) or the Kinetix 6200 and Kinetix 6500 Modular Multi-axis Servo Drives User Manual, publication [2094-UM002](#) for further information,

## Step 7: Estimate the DC bus load current for each IPIM.

One method to estimate the DC bus load current is to analyze the motion profile of each IDM unit axis and estimate the RMS power per motion cycle. Motion Analyzer performs this analysis, and it can be challenging for complex motion profiles. Another option is to use the continuous output power specification for each IDM unit. Once an output power value is determined for each IDM unit, use the equation below to calculate a DC bus load current value for each IDM unit. This equation neglects the effect of voltage drop over the hybrid cable DC bus. However this affect is much less significant compared to the IDM control power voltage drop so ignoring it does not have a large impact on the estimation.

$$I_{bus} = \frac{P_{out}}{\eta * V_{bus}}$$

Where:

$I_{bus}$  = IDM unit DC bus current load

$P_{out}$  = IDM unit average shaft output power

$\eta$  = efficiency, 80% (average)

$V_{bus}$  = DC bus voltage at the IPIM nodule

Calculate the total bus current by summing the  $I_{bus}$  current values for all the IDM units connected to an IPIM module.

---

**IMPORTANT** The total bus current must be less than the maximum current specification for the IPIM module (24 A rms). See the Kinetix Rotary Motion Specifications Technical Data, publication [KNX-TD001](#).

---

*Example*

The six IDM units in this example are listed below with the corresponding output power. The equation for bus current is used to calculate the bus current values for each IDM unit. The DC bus voltage is 675V DC. The DC bus current as a percentage of the IPIM module rating is  $12.93 / 24 = 53.9\%$ .

IDM Unit Cat. No.	with Brake	Output Power Rating (kW)	Estimated Bus Current (A rms)
MDF-SB1153	Yes	1.00	1.85
MDF-SB1003	No	1.10	2.04
MDF-SB1304	No	1.39	2.57
MDF-SB1304	Yes	1.24	2.30
MDF-SB1003	No	1.10	2.04
MDF-SB1153	No	1.15	2.13
Total			12.93

The DC bus current is less than the continuous current specification for the IPIM module, so this is a valid system configuration.

**Step 8: Estimate the IPIM module dissipation for the DC bus load current and the total IPIM module dissipation from the IDM unit control power and DC bus load current.**

See the Kinetix Rotary Motion Specifications Technical Data, publication [KNX-TD001](#) for specifications on IPIM module dissipation. This information is also shown in the equation below. This equation can be used to estimate the dissipation, in watts, of the IPIM module as a function of the DC bus load current, expressed as a percentage of the maximum rating (24 A rms).

$$\text{Dissipation} = 33.95x^2 + 3.18x$$

Combine the dissipation value calculated from this equation with the dissipation from the total IDM system control power load current value from step 4. This is the total dissipation for the IPIM module.

Repeat for each IPIM module.

*Example*

The DC bus current was calculated as 12.93 A, or 53.9% of the IPIM rating. The dissipation for this DC bus current value is 11.7 W. The dissipation calculated for the total IDM control power (step 4) is 29 W. Therefore the total dissipation for the IPIM is 40.7 W.

## Kinetix 6000M System Product Specifications


This appendix provides product specifications for Kinetix® 6000M integrated drive-motor system components.

Topic	Page
Kinetix 6000M System Features and Indicators	143
Kinetix 6000M Integrated Drive-Motor High Resolution Encoders	144
Kinetix 6000M Integrated Drive-Motor System Cables	145
Kinetix 6000M Integrated Drive-Motor Options	146
Technical Specifications - Kinetix 6000M Integrated Drive-Motor System	146
Dimensions - Kinetix 6000M Integrated Drive-Motor System	150
Environmental Specifications - Kinetix 6000M IPIM Module	152
Certifications - Kinetix 6000M IDM System	152

### Kinetix 6000M System Features and Indicators

Use these illustrations to identify the features and indicators for the Kinetix 6000M system components.


**Figure 42 - Kinetix 6000M IDM Units**



Item	Description
1	Hybrid output connector
2	Hybrid input connector
3	Network output connector
4	Network input connector

Item	Description
1, 2, 3	Digital input connectors (M12)
S1	Network node address switch (least significant digit)
S10	Network node address switch (most significant digit)
D, N	Status indicators

Figure 43 - Kinetix 6000M IPIM Modules



## Kinetix 6000M Integrated Drive-Motor High Resolution Encoders


Kinetix 6000M integrated drive-motors are available with high performance digital encoders with multi-turn high resolution feedback:

- 524,288 counts per revolution for smooth performance
- High-resolution multi-turn absolute position feedback within 4096 turns

## Kinetix 6000M Integrated Drive-Motor System Cables

Kinetix 6000M integrated drive-motor (IDM) system is compatible with Kinetix 6000 and Kinetix 6200 (400V-class) power rail configurations. The Kinetix 6000M IDM system includes one 2094-SEPM-B24-S IPIM power interface module (IPIM), as many as 16 MDF-SBxxxx IDM units, and cables and terminators as illustrated below.

**Figure 44 - Kinetix 6000M Hybrid and Network Cables**



Cat. No.	Cable Type	Description	Quantity
2090-CHBFS8-12AAxx <sup>(1)</sup>	Hybrid (SpeedTec)	Connects IPIM module (flying-leads) with the first IDM unit	1 required per system
2090-CHBFS8-12AAxx <sup>(2)</sup>		Connects from IDM unit-to-unit	1 required for each downstream IDM unit
20990-CBKS8-16AA03		Manual brake release cable	Optional
2090-CHTP8		Hybrid bus terminator, install on the last IDM unit	1 required per system (included with IPIM module)
2090-CNSSPSS-AAxx <sup>(2)</sup>	Network	Straight (pin) connector and straight (socket) connector	1 required per system <sup>(3)</sup> (IPIM module to first IDM unit) Plus, 1 required for the second IDM unit and each additional downstream IDM unit
2090-CNMRPRS-AAxx <sup>(2)</sup>		Right-angle (pin) connector and right-angle (socket) connector	
2090-CNMRPRS-AAxx <sup>(2)</sup>		Right-angle (pin) connector and straight (socket) connector	
2090-CNMRPRS-AAxx <sup>(2)</sup>		Straight (pin) connector and right-angle (socket) connector	
2090-CTSRP		Network bus terminator, right-angle (pin), to the last IDM unit	1 required per system (included with IPIM module)

(1) Cables are available in standard lengths of 1, 2, 3, 4, 5, 7, 9, 12, 15, 20, and 25 m (3.2, 6.6, 9.8, 13.1, 16.4, 22.9, 29.5, 39.3, 49.2, 65.5, and 82.0 ft).

(2) Cables are available in standard lengths of 0.5, 1, 2, 3, 4, 5, 7, 9, 12, 15, 20, and 25 m (1.6, 3.2, 6.6, 9.8, 13.1, 16.4, 22.9, 29.5, 39.3, 49.2, 65.5, and 82.0 ft).

(3) Use of straight or right-angle connectors depends on application. Right-angle (pin) connectors are not compatible for connection to the IPIM module. Only straight (pin) connectors fit properly.

## Digital Input Cables

Kinetix 6000M IDM units have three 5-pin, M12, digital input connectors. Allen-Bradley® (Bulletin 889D) DC micro-style patchcords, splitters, and V-cables are available with straight and right-angle connectors for making connections from the IDM unit to input sensors.

Refer to the Kinetix 6000 and Kinetix 6200/6500 Drive Systems Design Guide, publication [KNX-RM003](#), for catalog numbers and example diagrams.

## Kinetix 6000M Integrated Drive-Motor Options

Kinetix 6000M integrated drive-motor units are available with these options:

- Holding brake.
- Choice of keyed or keyless shaft. Replacement shaft seal kits are available for field installation. Shaft seals are made of PTFE and kits include a lubricant to reduce wear.

**IMPORTANT** Shaft seals are subject to wear and require periodic inspection and replacement. Replacement is recommended every 3 months, not to exceed 12 months, depending on use.

**Table 30 - Shaft Seal Kit Catalog Numbers**

Motor Cat. No.	Shaft Seal Cat. No.
MDF-SB1003	MPF-SST-A3B3
MDF-SB1153	MPF-SST-A4B4
MDF-SB1304	MPF-SST-A45B45

- The positive air-pressure kit (catalog number MPS-AIR-PURGE) is mounted on the rear of the IDM unit to provide positive air pressure to further reduce the chance of contamination inside the motor.

Refer to the Kinetix 6000M Integrated Drive-Motor Installation Instructions, publication [MDF-IN001](#), for motor accessory information.

## Technical Specifications - Kinetix 6000M Integrated Drive-Motor System

**Table 31 - Kinetix 6000M Integrated Drive-Motor Unit (400V-class) Performance Specifications**

Attribute	Units	MDF-SB1003P		MDF-SB1153H		MDF-SB1304F	
		No Brake	Brake	No Brake	Brake	No Brake	Brake
Bandwidth <sup>(1)</sup> Velocity loop Current loop	Hz Hz	500 1300		500 1300		500 1300	
PWM frequency	kHz	4		4		4	
Nominal bus input voltage	V DC	650		650		650	
Control power Input voltage Power on load Digital input load	V DC W W	32...44 8 0...6		32...44 8 0...6		32...44 8 0...6	
Brake load	W	N/A	15.0	N/A	19.2	N/A	19.2
Digital inputs Supply voltage Supply voltage current	V DC mA	21.6...26.4 200		21.6...26.4 200		21.6...26.4 200	
Rated speed	rpm	5000		3500		3000	
Speed, max	rpm	5000		3500		3000	
Continuous stall torque	N·m (lb·in)	3.0 (26.5)		4.8 (42.5)		7.25 (64.2)	
Peak stall torque	N·m (lb·in)	10.5 (92.9)		18.5 (164)		21.75 (192)	
Rated output power	kW	1.10	1.02	1.15	1.0	1.39	1.24
Rated input power	kVA	1.27	1.28	1.36	1.26	1.61	1.44
Rotor inertia	kg·m <sup>2</sup> (lb·in·s <sup>2</sup> )	0.00012 (0.0010)	0.00013 (0.0011)	0.00038 (0.0033)	0.00042 (0.0038)	0.00052 (0.0046)	0.00056 (0.0050)
Bus overvoltage	V DC	825		825		825	
Bus undervoltage	V DC	275		275		275	
Weight	kg (lb)	7.2 (15.9)	8.4 (18.5)	8.1 (17.9)	9.9 (21.9)	11.3 (25.0)	13.6 (30.1)

(1) Bandwidth values vary based on tuning parameters and mechanical components.

**Table 32 - Kinetix 6000M Integrated Drive-Motor Unit Brake Specifications**

IDM Cat. No.	Backlash, max (brake engaged) arc minutes	Holding Torque N·m (lb·in)	Coil Current at 24V DC A	Brake Response Time		Brake Rotor Inertia kg·m <sup>2</sup> (lb·in·s <sup>2</sup> )	Brake Motor Weight, approx kg (lb)
				Release ms	Engage ms		
MDF-SB1003	45	4.18 (37)	0.45...0.55	100	40	0.00013 (0.0011)	8.4 (18.5)
MDF-SB1153	48	10.2 (90)	0.576...0.704	120	65	0.00042 (0.0038)	9.9 (21.9)
MDF-SB1304						0.00056 (0.0050)	13.6 (30.1)

## Kinetix 6000M IPIM Module Specifications

The Kinetix 6000M integrated drive-motor (IDM) power interface module (IPIM), catalog number 2094-SEPM-B24-S, is compatible with Kinetix 6000 and Kinetix 6200 (400V-class) drive families and mounts to the 2094 power rail.

**IMPORTANT** The 2094-SEPM-B24-S IPIM module is compatible with only 400V-class drive systems.

**Table 33 - DC Bus Power Specifications**

Attribute	Value
Bus output voltage, nom	650V DC
Bus continuous output current	24 A, rms
Instantaneous output current, max	60 A
Intermittent current duration	400 ms
Intermittent current duty cycle	16%
Continuous power output, nom	15 kW
Internal shunt	
Continuous power	200 W
Peak power	22.5 kW
Internal shunt resistor	28.75 Ω
Capacitance	840 μF
Short circuit current rating	200,000 A (rms) symmetrical

**Table 34 - Control Power Specifications**

Attribute	Value
Control power output	
Voltage	40.4...41.7V DC
Power	270 W
Current	6.5 A
24V output voltage	21.6...26.4V DC
24V output current, max	
Enable input	50 mA
Safety bypass	320 mA

Control power line-loss ride-through is used to determine how long you can remove control power without causing the system to shut down and reset. For the IPIM module, it is highly dependent on the load current and applied voltage. For an example of these calculations, refer to Kinetix 6000M Integrated Drive-Motor User Manual, publication [2094-UM003](#).

**Table 35 - Control Power Line-loss Ride-through Specifications**

Control Power Input Voltage	Control Power Line-loss Ride-through as % of IPIM Module Control Power Current Output Rating					
	ms					
AC	20%	40%	60%	80%	100%	
120V	67	34	23	18	14	
240V	448	246	173	135	112	

You can calculate power (heat) dissipation as it applies to sizing the enclosure for the 2094 power rail that includes your IPIM module by using these tables. For an example, refer to Kinetix 6000M Integrated Drive-Motor User Manual, publication [2094-UM003](#).

**Table 36 - Power Dissipation Specifications**

Power Dissipation as % of DC Bus Current Output Rating Watts					Heat Dissipation Formula <sup>(1)</sup>
20%	40%	60%	80%	100%	
2	7	14	25	38	$Y = 33.95x^2 + 3.18x$


(1)  $x$  = percent of DC bus current output rating: any value between 0.0 and 1.0.

Control Power Input		Power Dissipation as % of IPIM Module Control Power Output Rating Watts					Heat Dissipation Formulas <sup>(1)</sup>
Frequency Hz	Voltage AC	20%	40%	60%	80%	100%	
50	120V	22	29	38	48	61	$Y = 23.76x^2 + 20.73x + 16.54$
	240V	34	42	52	63	76	$Y = 18.56x^2 + 30.19x + 27.41$
60	120V	23	27	32	39	46	$Y = 14.57x^2 + 11.40x + 20.01$
	240V	38	49	62	76	92	$Y = 19.63x^2 + 43.22x + 28.75$

(1)  $x$  = percent of IPIM module control power output rating: any value between 0.0 and 1.0.

## Maximum System Cable Lengths

The maximum length for hybrid and network cables is 25 m (82 ft). The maximum combined cable length for all axes daisy-chained from the same IPIM module is 100 m (328 ft).



For example, in this Kinetix 6000M system, if each cable length is the maximum 25 m (82 ft), the combined cable length is 75 m (246 ft).


## Kinetix 6000M Integrated Drive-Motor Load Force Ratings

Bulletin MDF motors are capable of operating with the maximum radial or maximum axial shaft loads listed in the following tables. Radial loads listed are applied in the middle of the shaft extension. These tables represent an L<sub>10</sub> bearing fatigue life of 20,000 hours. This 20,000-hour life does not account for possible application-specific life reduction that can occur due to bearing grease contamination from external sources. Maximum operating speed is limited by motor winding.

**Table 37 - Radial Load Force Ratings**

Motor Cat. No.	500 rpm kg (lb)	1000 rpm kg (lb)	2000 rpm kg (lb)	3000 rpm kg (lb)	3500 rpm kg (lb)	5000 rpm kg (lb)
MDF-SB1003	–	74 (163)	59 (129)	–	49 (107)	43 (95)
MDF-SB1153	106 (234)	84 (185)	67 (148)	–	55 (121)	–
MDF-SB1304	140 (309)	111 (245)	89 (195)	77 (170)	–	–

**Figure 45 - Load Forces on Shaft**



**Table 38 - Axial Load Force Ratings (maximum radial load)**


Motor Cat. No.	500 rpm kg (lb)	1000 rpm kg (lb)	2000 rpm kg (lb)	3000 rpm kg (lb)	3500 rpm kg (lb)	5000 rpm kg (lb)
MDF-SB1003	–	27 (59)	20 (44)	–	16 (35)	13 (29)
MDF-SB1153	52 (115)	39 (86)	29 (64)	–	22 (49)	–
MDF-SB1304	49 (107)	36 (80)	27 (60)	22 (49)	–	–

**Table 39 - Axial Load Force Ratings (zero radial load)**

Motor Cat. No.	500 rpm kg (lb)	1000 rpm kg (lb)	2000 rpm kg (lb)	3000 rpm kg (lb)	3500 rpm kg (lb)	5000 rpm kg (lb)
MDF-SB1003	–	36 (80)	27 (59)	–	21 (47)	18 (40)
MDF-SB1153	69 (152)	51 (112)	38 (83)	–	30 (66)	–
MDF-SB1304	69 (152)	51 (112)	38 (83)	31 (69)	–	–

## Dimensions - Kinetix 6000M Integrated Drive-Motor System

Figure 46 - MDF-SB1003, MDF-SB1153, MDF-SB1304 IDM Unit Dimensions




**Table 40 - MDF-SB1003, MDF-SB1153, MDF-SB1304 IDM Unit Dimensions**

IDM Unit Cat. No.	AD mm (in.)	HD mm (in.)	LA mm (in.)	LD <sup>(1)</sup> mm (in.)	LF <sup>(1)</sup> mm (in.)	L <sup>(1)</sup> mm (in.)	LB <sup>(1)</sup> mm (in.)	L-LB <sup>(2)</sup> mm (in.)	D <sup>(3)</sup> mm (in.)	M mm (in.)	S <sup>(4)</sup> mm (in.)	N <sup>(3)</sup> mm (in.)	P mm (in.)	P1 mm (in.)	G <sup>(3)</sup> mm (in.)	F <sup>(3)</sup> mm (in.)
MDF-SB1003	173.8 (6.84)	221.0 (8.70)	9.90 (0.39)	183.0 (7.21)	126.3 (4.97)	271.3 (10.68)	231.3 (9.11)	40.0 (1.575)	16.0 (0.629)	100.0 (3.937)	7.0 (0.283)	80.0 (3.15)	89.4 (3.52)	94.4 (3.72)	12.95 (0.510)	5.0 (0.197)
MDF-SB1153	178.2 (7.02)	229.0 (9.02)	10.20 (0.40)	183.3 (7.22)	126.5 (4.98)	271.2 (10.67)	231.2 (9.10)	40.0 (1.575)	19.0 (0.740)	115.0 (4.528)	10.0 (0.401)	95.0 (3.74)	98.3 (3.87)	101.6 (4.0)	15.40 (0.606)	6.0 (0.236)
MDF-SB1304	185.8 (7.31)	244.7 (9.63)	12.20 (0.48)	212.0 (8.35)	155.2 (6.11)	310.6 (12.23)	260.6 (10.26)	50.0 (1.969)	24.0 (0.945)	130.0 (5.118)	10.0 (0.433)	110.0 (4.33)	113.7 (4.48)	117.7 (4.63)	19.82 (0.780)	8.0 (0.315)

- (1) If ordering an MDF-SB1003 IDM unit with brake, add 34.5 mm (1.36 in.) to dimensions L, LB, LD, and LE.
- If ordering an MDF-SB1153 IDM unit with brake, add 48 mm (1.91 in.) to dimensions L, LB, LD, and LE.
- If ordering an MDF-SB1304 IDM unit with brake, add 48.5 mm (1.91 in.) to dimensions L, LB, LD, and LE.
- (2) Tolerance for this dimension is  $\pm 0.7$  mm ( $\pm 0.028$  in.).
- (3) For keyway, shaft diameter, and pilot diameter tolerances, refer to [Page 150](#).
- (4) Tolerance for this dimension is  $+0.36$  mm ( $\pm 0.007$  in.).

IDM units are designed to metric dimensions. Inch dimensions are approximate conversions from millimeters. Dimensions without tolerances are for reference.

**Figure 47 - 2094-SEPM-B24-S IPIM Module Dimensions**

Modules are shown mounted to the 2094 power rail and the dimensions reflect that.

## Environmental Specifications - Kinetix 6000M IPIM Module

Attribute	Operational Range	Storage Range (nonoperating)
Temperature, ambient	0...50 °C (32...122 °F)	-40...70 °C (-40...158 °F)
Relative humidity	5...95% noncondensing	5...95% noncondensing
Altitude	1000 m (3281 ft) 3000 m (9843 ft) with derating	3000 m (9843 ft) during transport
Vibration	5...55 Hz @ 0.35 mm (0.014 in.) double amplitude, continuous displacement; 55...500 Hz @ 2.0 g peak constant acceleration (10 sweeps in each of 3 mutually perpendicular directions)	
Shock	15 g, 11 ms half-sine pulse (3 pulses in each direction of 3 mutually perpendicular directions)	
Weight	3.5 kg (7.8 lb)	

## Certifications - Kinetix 6000M IDM System

Agency Certification <sup>(1)</sup>	Standards
c-UL-us <sup>(2)</sup>	UL Listed to U.S. and Canadian safety standards (UL 508C File E59272).
	Solid-state motor overload protection provides dynamic fold-back of motor current when 110% of the motor rating is reached with a peak current limit based on the peak rating of the motor as investigated by UL to comply with UL 508C (UL File E59272, volume 1, section 22).
CE	European Union 2004/108/EC EMC Directive compliant with EN 61800-3:2004: Adjustable Speed Electrical Power Drive Systems - Part 3; EMC requirements and specific test methods.
	European Union 2006/95/EC Low Voltage Directive compliant with: <ul style="list-style-type: none"> <li>EN 61800-5-1:2007 - Adjustable speed electrical power drive systems.</li> <li>EN 50178:1997 - Electronic Equipment for use in Power Installations.</li> </ul>
Functional Safety	TÜV Certified for Functional Safety: up to SIL CL2, according to EN 61800-5-2, EN 61508, and EN 62061; up to Performance Level PLd and Category 3, according to EN ISO 13849-1; when used as described in this publication.
C-Tick	Australian Radio Communications Act, compliant with: <ul style="list-style-type: none"> <li>AS/NZS CISPR 11; Industrial Emissions</li> <li>Radio Communications Act; 1992</li> <li>Radio Communications (Electromagnetic Compatibility) Standard; 1998</li> <li>Radio Communications (Compliance Labelling - Incidental Emissions) Notice; 1998</li> <li>AS/NZS CISPR 11: 2003 (Group 2, Class A)</li> </ul>
KC	Korean Registration of Broadcasting and Communications Equipment, compliant with: <ul style="list-style-type: none"> <li>Article 58-2 of Radio Waves Act, Clause 3</li> <li>IDM unit registration number, KCC-REM-RAA-MDF</li> <li>IPIM module registration number, KCC-REM-RAA-2094</li> </ul>
ODVA	EtherNet/IP conformance tested (applies to IPIM module).

(1) When product is marked, refer to website, [rok.auto/certifications](http://rok.auto/certifications) for Declarations of Conformity Certificates.

(2) Underwriters Laboratories Inc. has not evaluated the safe-off, safe torque-off, or safe speed-monitoring options in these products.

## **Kinetix 6000M Drive Systems**

This appendix helps you choose Kinetix® 6000M integrated drive-motor system components and provides performance specifications.

<b>Topic</b>	<b>Page</b>
Kinetix 6000M Integrated Drive-Motor Systems	154
Kinetix 6000M Integrated Drive-Motor System Performance	160

## Kinetix 6000M Integrated Drive-Motor Systems

For each Kinetix 6000M integrated drive-motor system, you need to know the integrated drive-motor (IDM) unit and IDM power interface module (IPIM) catalog numbers. The IPIM module is compatible with the Bulletin 2094 power rail in any configuration with Kinetix 6000 or Kinetix 6200 (400V-class) drive systems.


**IMPORTANT** Kinetix 6000 drives must be series B or series C.

You also need hybrid cables, network cables, and terminators. Optional equipment includes digital input cables, the hybrid coupler cable, bulkhead adapter kits, the holding brake manual release cable, and Bulletin 2090 safe-off headers and 1202-Cxx safety cables.

### Kinetix 6000M Integrated Drive-Motor System Example

This configuration illustrates the components needed to add Kinetix 6000M IDM units to a 400V-class Kinetix 6000 or Kinetix 6200 multi-axis servo drive system. The IDM power interface module (IPIM) is mounted to the Bulletin 2094 power rail and connects to the sercos fiber-optic ring. The IDM units are wired to the IPIM module.

**Figure 48 - Typical Kinetix 6000M Integrated Drive-Motor System**



## Determine What You Need

These tables list the system components and accessory items available for the Kinetix 6000M IDM drive systems.

**Table 41 - Kinetix 6000M Integrated Drive-Motor (IDM) Units**

Cat. No.	Speed	Continuous Torque	Peak Torque	Features	Quantity
MDF-SB1003P	5000 rpm	3.0 N·m (26.5 lb·in)	10.5 N·m (92.9 lb·in)	<ul style="list-style-type: none"> <li>USDA compliant food-grade paint</li> <li>400V-class</li> <li>Safe-off</li> </ul>	Up to 16 on each IPIM module <sup>(1)</sup>
MDF-SB1153H	3500 rpm	4.8 N·m (42.5 lb·in)	18.5 N·m (164 lb·in)		
MDF-SB1304F	3000 rpm	7.25 N·m (64.2 lb·in)	21.75 N·m (192 lb·in)		

(1) Use Motion Analyzer software, version 6.00 or later, to determine the maximum number of IDM units to daisy-chain on each IPIM module.

**Table 42 - Kinetix 6000M IDM Power Interface Module (IPIM)**

Cat. No.	Output Bus Voltage	Continuous Output	Peak Output	Slot Usage	Quantity
2094-SEPM-B24-S	650V DC	15 kW, 24 A, rms	60 A	1	Up to 4 on each power rail <sup>(1)</sup>

(1) Use Motion Analyzer software, version 6.00 or later, to determine the maximum number of IPIM modules on a single power rail.

See the Kinetix Rotary Motion Technical Data, publication [KNX-TD001](#), for detailed descriptions and additional specifications for the Kinetix 6000M integrated drive-motor (IDM) units and IPIM module.

**Table 43 - Required Hybrid Cables**

Cat. No.	Description	Cable Configuration		Quantity
		Flying-lead/Pin	Socket	
2090-CHBIFS8-12AAxx <sup>(1)</sup>	From IPIM module (flying-leads) to the first IDM unit <ul style="list-style-type: none"> <li>IPIM-end flying-leads (IF)</li> <li>SpeedTec connector, socket (S8)</li> </ul>			1 required per system (IPIM module to first IDM unit)
2090-CHBPS8-12AAxx <sup>(2)</sup>	IDM unit-to-unit connections <ul style="list-style-type: none"> <li>SpeedTec connector, pin (P8)</li> <li>SpeedTec connector, socket (S8)</li> </ul>			1 required for the second IDM unit and each additional downstream IDM unit
2090-CTHP8	Hybrid (SpeedTec) terminator <ul style="list-style-type: none"> <li>Required on last IDM unit, pin (P8)</li> <li>Included with each IPIM module</li> </ul>			1 required per system

(1) Cables are available in standard lengths of 1, 2, 3, 4, 5, 7, 9, 12, 15, 20, and 25 m (3.2, 6.6, 9.8, 13.1, 16.4, 22.9, 29.5, 39.3, 49.2, 65.5, and 82.0 ft).

(2) Cables are available in standard lengths of 0.5, 1, 2, 3, 4, 5, 7, 9, 12, 15, 20, and 25 m (1.6, 3.2, 6.6, 9.8, 13.1, 16.4, 22.9, 29.5, 39.3, 49.2, 65.5, and 82.0 ft).

See the Kinetix Motion Accessories Technical Data, publication [KNX-TD004](#), for detailed descriptions and specifications of these required accessories.

**Table 44 - Required Network Cables**

Cat. No.	Description	Cable Configuration		Quantity
		Pin	Socket	
2090-CNNSPSS-AAxx <sup>(1)</sup>	<ul style="list-style-type: none"> <li>Straight connector, pin (SP)</li> <li>Straight connector, socket (SS)</li> </ul>			
2090-CNNSPRS-AAxx <sup>(1)</sup>	<ul style="list-style-type: none"> <li>Right-angle connector, pin (RP)</li> <li>Right-angle connector, socket (RS)</li> <li>Not compatible for connection to the IPIM module</li> </ul>			1 required per system (IPIM module to first IDM unit) <sup>(2)</sup>
2090-CNNSRPSS-AAxx <sup>(1)</sup>	<ul style="list-style-type: none"> <li>Right-angle connector, pin (RP)</li> <li>Straight connector, socket (SS)</li> <li>Not compatible for connection to the IPIM module</li> </ul>			Plus, 1 required for the second IDM unit and each additional downstream IDM unit <sup>(3)</sup>
2090-CNNSPRS-AAxx <sup>(1)</sup>	<ul style="list-style-type: none"> <li>Straight connector, pin (SP)</li> <li>Right-angle connector, socket (RS)</li> </ul>			
2090-CTSRP	Network terminator <ul style="list-style-type: none"> <li>Required on last IDM unit, right-angle, pin (RP)</li> <li>Included with each IPIM module</li> </ul>			1 required per system

(1) Cables are available in standard lengths of 0.5, 1, 2, 3, 4, 5, 7, 9, 12, 15, 20, and 25 m (1.6, 3.2, 6.6, 9.8, 13.1, 16.4, 22.9, 29.5, 39.3, 49.2, 65.5, and 82.0 ft).

(2) This cable must be either 2090-CNNSPSS-AAxx or 2090-CNNSPRS-AAxx. Only straight, pin (SP) connectors fit properly at the IPIM module.

(3) Use of straight or right-angle connectors depends on application.

**IMPORTANT** Right-angle (pin) connectors are not compatible for connection to the IPIM module. Only straight (pin) connectors fit properly.

See the Kinetix Motion Accessories Technical Data, publication [KNX-TD004](#), for detailed descriptions and specifications of these required accessories.

**Table 45 - Optional Accessories**

Cat. No.	Accessory Item	Description
2090-CBKS8-16AA03	Manual brake release cable <ul style="list-style-type: none"> <li>Brake release wires (BK)</li> <li>SpeedTec connector, socket (S8)</li> </ul>	
2090-CCPP8S8	Hybrid coupler cable connects between two hybrid cables to bypass an IDM unit <ul style="list-style-type: none"> <li>SpeedTec connector, pin (P8)</li> <li>SpeedTec connector, socket (S8)</li> </ul>	
2090-KPB47-12CF	<ul style="list-style-type: none"> <li>The hybrid bulkhead adapter secures cables as they pass through the cabinet</li> <li>Mating cable attaches on the other side</li> </ul>	
2090-CBUSPSS	<ul style="list-style-type: none"> <li>The network cable bulkhead adapter feeds signals through the cabinet wall</li> <li>Network cables attach on either side</li> </ul>	
2090-XNSM-x	Safe-off headers	Cascading safe-off connections from drive-to-drive (applies to Kinetix 6000 drive systems)
1202-Cxx	Safety cables	
Bulletin 889D and 879D	DC micro-style patchcords, V-cables, and splitters for digital input connections	See Digital Input Cable Examples on <a href="#">page 157</a>
2094-XNIPIM-1	Connector set	Includes hybrid power (DC bus), hybrid communication, safe-off, and enable input replacement connectors for the IPIM module
2094-SEPM-FUSE	Replacement fuses for the IPIM module, 6 each	Bussmann part number FWP-50A14Fa
MDF-SB-NODECVR	Replacement covers for the node address switches on the IDM units	
1485A-M12	Replacement covers for the digital input connectors on the IDM units	


See the Kinetix Motion Accessories Technical Data, publication [KNX-TD004](#), for detailed descriptions and specifications of these optional accessories.

## Digital Input Cable Examples

Kinetix 6000M IDM units have three 5-pin, M12, digital input connectors. Allen-Bradley® (Bulletin 889D and 879D) DC micro-style patchcords, splitters, and V-cables are available with straight and right-angle connectors for making connections from the IDM unit to input sensors.

For patchcord cable specifications see Cordsets and Field Attachables Technical Data, publication [889-TD002](#).


**Figure 49 - Digital Inputs Used for Home and Overtravel Functions**



**Table 46 - Digital Input Accessories Items**

Cat. No.	Item Type	Description	Cable Configuration	
			Socket	Pin (IDM unit)
889D-F4ACDM-x	Digital input patchcords <sup>(1)</sup> (IDM unit to NC and NO sensors)	• Straight connector, socket (F) • Straight connector, pin (M)		
889D-R4ACDM-x		• Right-angle connector, socket (R) • Straight connector, pin (M)		
889D-F4ACDE-x		• Straight connector, socket (F) • Right-angle connector, pin (E)		
889D-R4ACDE-x		• Right-angle connector, socket (R) • Right-angle connector, pin (E)		
871TS-N12BP18-D4	Sensor (example)	Proximity	N/A	

(1) Patchcords are available in standard lengths of 2, 5, and 10 m (6.6, 16.4, and 32.8 ft).

**Figure 50 - Digital Inputs Used for Home, Overtravel, and Registration Functions****Table 47 - Digital Input Accessories Items**


Cat. No.	Item Type	Description	Cable Configuration	
			Socket	Pin (IDM unit)
889D-F4ACDM-x	Digital input patchcords <sup>(1)</sup> • IDM unit to NC and NO sensors • IDM unit to V-cable • V-cable to NO sensors	• Straight connector, socket (F) • Straight connector, pin (M)		
889D-R4ACDM-x		• Right-angle connector, socket (R) • Straight connector, pin (M)		
889D-F4ACDE-x		• Straight connector, socket (F) • Right-angle connector, pin (E)		
889D-R4ACDE-x		• Right-angle connector, socket (R) • Right-angle connector, pin (E)		
889D-F4ACDM-Vx	Digital input patchcords <sup>(1)</sup> (V-cable to NC sensor)	• Straight connector, socket (F) • Straight connector, pin (M)		
889D-R4ACDM-Vx		• Right-angle connector, socket (R) • Straight connector, pin (M)		
889D-F4ACDE-Vx		• Straight connector, socket (F) • Right-angle connector, pin (E)		
889D-R4ACDE-Vx		• Right-angle connector, socket (R) • Right-angle connector, pin (E)		
879D-F4ACDM-x	V-cables <sup>(2)</sup>	• Straight connectors, socket (F) • Straight connector, pin (M)		
879D-R4ACDM-x		• Right-angle connectors, socket (R) • Straight connector, pin (M)		
879D-F4DM	Splitter <sup>(3)</sup>	• Straight connectors, socket (F) • Straight connector, pin (M)		N/A
871TS-N12BP18-D4	Sensor (example)	Proximity		

(1) Patchcords are available in standard lengths of 2, 5, and 10 m (6.6, 16.4, and 32.8 ft).


(2) V-cables are available in standard lengths of 0.3, 1, 2, and 5 m (1.0, 3.2, 6.6, and 16.4 ft).

(3) Splitter can be used in place of the V-cable.

## Bulkhead Adapter Examples



## Hybrid Coupler Cable Example



See the Kinetix Motion Accessories Technical Data, publication [KNX-TD004](#), for detailed descriptions and specifications of these optional accessories.

## Kinetix 6000M Integrated Drive-Motor System Performance

This section provides system performance information for the Bulletin MDF integrated drive-motor units. Included are hybrid power and network cable catalog numbers, system performance specifications, and the optimum torque/speed curves.

**IMPORTANT** The Kinetix 6000M integrated drive-motor systems are compatible with Kinetix 6000 and Kinetix 6200 (400V-class) power rail configurations. Kinetix 6000 drives must be series B or series C.

**Table 48 - Kinetix 6000M (Bulletin MDF) Integrated Drive-Motor Cable Combinations**

IDM Drive-Motor (400V-class) Cat. No.	Hybrid Cables <sup>(1)</sup>	Network Cables <sup>(2)</sup>
MDF-SB1003P		
MDF-SB1153H	2090-CHBIFS8-12AAxx and 2090-CHBP8S8-12AAxx	2090-CNSxPxS-AAxx
MDF-SB1304F		

(1) Hybrid terminator (catalog number 2090-CHP8) is included with the IPIM module.

(2) Network terminator (catalog number 2090-CTSRP) is included with the IPIM module.

For cable configuration illustrations and feature descriptions, by catalog number, see the [Kinetix 6000M Integrated Drive-Motor System Example](#) on page 154.

Cable length xx is in meters. See the Kinetix Motion Accessories Technical Data, publication [KNX-TD004](#), for standard cable lengths.

**Table 49 - Performance Specifications with Kinetix 6000M (non-brake) Motors**

IDM Drive-Motor Cat. No.	Speed, max rpm	System Continuous Stall Current A 0-pk	System Continuous Stall Torque N·m (lb·in)	System Peak Stall Current A 0-pk	System Peak Stall Torque N·m (lb·in)	Motor Rated Output kW	Kinetix 6000M IPIM Module
MDF-SB1003P-xxx2x-S	5000	4.03	3.00 (26.5)	19.0	10.50 (92.9)	1.10	2094-SEPM-B24-S
MDF-SB1153H-xxx2x-S	3500	4.50	4.80 (42.5)	20.0	18.50 (164)	1.15	
MDF-SB1304F-xxx2x-S	3000	5.80	7.25 (64.2)	20.0	21.75 (192)	1.39	







Performance specification data and curves reflect nominal system performance of a typical system at 40 °C (104 °F) ambient and rated line voltage. For additional information on ambient and line conditions, see Motion Analyzer software.

**Table 50 - Performance Specifications with Kinetix 6000M (brake) Motors**

IDM Drive-Motor Cat. No.	Speed, max rpm	System Continuous Stall Current A 0-pk	System Continuous Stall Torque N·m (lb·in)	System Peak Stall Current A 0-pk	System Peak Stall Torque N·m (lb·in)	Motor Rated Output kW	Kinetix 6000M IPIM Module
MDF-SB1003P-xxx4x-S	5000	4.03	3.00 (26.5)	19.0	10.50 (92.9)	1.02	2094-SEPM-B24-S
MDF-SB1153H-xxx4x-S	3500	4.50	4.80 (42.5)	20.0	18.50 (164)	1.00	
MDF-SB1304F-xxx4x-S	3000	5.80	7.25 (64.2)	20.0	21.75 (192)	1.24	

Performance specification data and curves reflect nominal system performance of a typical system at 40 °C (104 °F) ambient and rated line voltage. For additional information on ambient and line conditions, see Motion Analyzer software.

## Kinetix 6000M Integrated Drive-Motor (400V-class) Performance Curves



= Intermittent operating region  
 = Continuous operating region  
 = Drive operation with 400V AC rms input voltage

**Notes:**

## Kinetix 6000M System Cable Specifications


This appendix provides hybrid, network, and digital input cable specifications for Kinetix® 6000M integrated drive-motor systems.

Topic	Page
Kinetix 6000M Hybrid Cables	163
Kinetix 6000M Network Cables	165
Kinetix 6000M Digital Input Cables	167
Technical Specifications - Kinetix 6000M Cables	168
Dimensions - Kinetix 6000M Hybrid Cables	169
Dimensions - Kinetix 6000M Network Cables	170
Dimensions - Kinetix 6000M Network Bulkhead Adapter	170

### Kinetix 6000M Hybrid Cables





Kinetix 6000M hybrid cables provide power, control, and communication between the IDM power interface module (IPIM) and the integrated drive-motor (IDM) units. Kinetix 6000M hybrid cables are available in lengths up to 25 m (82 ft). The maximum combined cable length for all axes daisy-chained from the same IPIM module is 100 m (328 ft). Maximum length for daisy chain is reduced by IDM units with holding brakes and number of IDM inputs used. Refer to Motion Analyzer software, version 6.00 or later, to verify that maximum daisy-chain length is not exceeded. The last IDM unit requires a 2090-CTHP8 hybrid bus terminator (included with each IPIM module).

#### Typical Hybrid Cable Application



For example, in this Kinetix 6000M system, if each cable length was the maximum 25 m (82 ft), the combined cable length would be 75 m (246 ft).

**Kinetix 6000M Hybrid Cable Descriptions**

Cable Cat. No.	Description	Cable Configuration	
		Flying-lead/Pin	Socket
2090-CHBIFS8-12AAxx <sup>(1)</sup>	From IPIM module (flying-leads) to the first IDM unit <ul style="list-style-type: none"> <li>IPIM-end flying-leads (IF)</li> <li>SpeedTec connector, socket (S8)</li> </ul>		
2090-CHBP8S8-12AAxx <sup>(2)</sup>	IDM unit-to-unit <ul style="list-style-type: none"> <li>SpeedTec connector, pin (P8)</li> <li>SpeedTec connector, socket (S8)</li> </ul>		
2090-CBKS8-16AA03	Manual brake release <ul style="list-style-type: none"> <li>Brake release wires (BK)</li> <li>SpeedTec connector, socket (S8)</li> </ul>		
2090-CCPP8S8	Coupler cable that connects between two hybrid cables to bypass an IDM unit <ul style="list-style-type: none"> <li>SpeedTec connector, pin (P8)</li> <li>SpeedTec connector, socket (S8)</li> </ul>		
2090-KPB47-12CF <sup>(3)</sup>	<ul style="list-style-type: none"> <li>The hybrid bulkhead adapter secures cables as they pass through the cabinet</li> <li>Mating cable attaches on the other side</li> </ul>		
2090-CTHP8	Hybrid (SpeedTec) terminator <ul style="list-style-type: none"> <li>Required on last IDM unit, pin (P8)</li> <li>Included with each IPIM module</li> </ul>		

(1) Cables are available in standard lengths of 1, 2, 3, 4, 5, 7, 9, 12, 15, 20, and 25 m (3.2, 6.6, 9.8, 13.1, 16.4, 22.9, 29.5, 39.3, 49.2, 65.5, and 82.0 ft).


(2) Cables are available in standard lengths of 0.5, 1, 2, 3, 4, 5, 7, 9, 12, 15, 20, and 25 m (1.6, 3.2, 6.6, 9.8, 13.1, 16.4, 22.9, 29.5, 39.3, 49.2, 65.5, and 82.0 ft).

(3) For 2090-KPB47-12CF bulkhead adapter dimensions and specifications, refer to Kinetix Motion Accessories Specifications Technical Data, publication [KNX-TD004](#).

**Catalog Numbers - Kinetix 6000M Hybrid Cables**

Catalog numbers consist of various characters, each of which identifies a specific option for that component. Use the catalog numbering charts below to understand the configuration of your component.


**2090 - C HB xx S8 - 12 AA xx**



## Kinetix 6000M Network Cables

Kinetix 6000M network cables provide motion commands to the IDM units. Kinetix 6000M network cables are available in lengths up to 25 m (82 ft). The maximum combined cable length for all axes daisy-chained from the same IPIM module is 100 m (328 ft).

### Typical Kinetix 6000M Network Cable Application



For example, in this Kinetix 6000M system, if each cable length was the maximum 25 m (82 ft), the combined cable length would be 75 m (246 ft). The last IDM unit requires a 2090-CTSRP network terminator.

### Kinetix 6000M Network Cables


Cat. No.	Description	Cable Configuration	
		Pin	Socket
2090-CNSSPSS-AAxx <sup>(1)</sup>	<ul style="list-style-type: none"> <li>Straight connector, pin (SP)</li> <li>Straight connector, socket (SS)</li> </ul>		
2090-CNSRPRS-AAxx <sup>(1)</sup>	<ul style="list-style-type: none"> <li>Right-angle connector, socket (RP)</li> <li>Right-angle connector, socket (RS)</li> <li>Not compatible for connection to the IPIM module</li> </ul>		
2090-CNSRPSS-AAxx <sup>(1)</sup>	<ul style="list-style-type: none"> <li>Right-angle connector, socket (RP)</li> <li>Straight connector, socket (SS)</li> <li>Not compatible for connection to the IPIM module</li> </ul>		
2090-CNSSPRS-AAxx <sup>(1)</sup>	<ul style="list-style-type: none"> <li>Straight connector, pin (SP)</li> <li>Right-angle connector, socket (RS)</li> </ul>		
2090-CBUPSS	<ul style="list-style-type: none"> <li>The network cable bulkhead adapter feeds signals through the cabinet wall</li> <li>Network cables attach on either side</li> </ul>		
2090-CTSRP	<ul style="list-style-type: none"> <li>Network terminator</li> <li>Required on last IDM unit, right-angle, socket (RP)</li> <li>Included with each IPIM module</li> </ul>		

(1) Cables are available in standard lengths of 0.5, 1, 2, 3, 4, 5, 7, 9, 12, 15, 20, and 25 m (1.6, 3.2, 6.6, 9.8, 13.1, 16.4, 22.9, 29.5, 39.3, 49.2, 65.5, and 82.0 ft).

**IMPORTANT** Right-angle (pin) connectors are not compatible for connection to the IPIM module. Only straight (pin) connectors fit properly.

## Catalog Numbers - Kinetix 6000M Network Cables

Catalog numbers consist of various characters, each of which identifies a specific option for that component. Use the catalog numbering charts below to understand the configuration of your component.



## Kinetix 6000M Replacement Parts

Cat. No.	Description
2094-XNIPIM-1	Replacement connectors for the IPIM module, includes hybrid DC bus, hybrid communication, safe-off, and enable input
2094-SEPM-FUSE	Replacement fuses for the IPIM module, 6 each, Bussmann part number FWP-50A14Fa
MDF-SB-NODECVR	Replacement covers for the node address switches on the IDM units
1485-M12	Replacement covers for the digital input connectors on the IDM units
2090-CTHP8	Replacement hybrid terminator (hybrid terminator is included with each Kinetix 6000M IPIM module)
2090-CTSRP	Replacement network terminator (network terminator is included with each Kinetix 6000M IPIM module)

## Kinetix 6000M Digital Input Cables

Kinetix 6000M IDM units have three 5-pin, M12, digital input connectors. Allen-Bradley® (Bulletin 889D and 879D) DC micro-style patchcords, splitters, and V-cables are available with straight and right-angle connectors for making connections from the IDM unit to input sensors. Refer to [Kinetix 6000M Integrated Drive-Motor Systems](#) beginning on [page 154](#) for examples.

### Digital Input Accessories Items

Cat. No.	Item Type	Description	Cable Configuration	
			Socket	Pin (IDM unit)
889D-F4ACDM-x	Digital input patchcords <sup>(1)</sup> • IDM unit to NC and NO sensors • IDM unit to V-cable • V-cable to NO sensors	• Straight connector, socket (F) • Straight connector, pin (M)		
889D-R4ACDM-x		• Right-angle connector, socket (R) • Straight connector, pin (M)		
889D-F4ACDE-x		• Straight connector, socket (F) • Right-angle connector, pin (E)		
889D-R4ACDE-x		• Right-angle connector, socket (R) • Right-angle connector, pin (E)		
889D-F4ACDM-Vx	Digital input patchcords <sup>(1)</sup> (V-cable to NC sensor)	• Straight connector, socket (F) • Straight connector, pin (M)		
889D-R4ACDM-Vx		• Right-angle connector, socket (R) • Straight connector, pin (M)		
889D-F4ACDE-Vx		• Straight connector, socket (F) • Right-angle connector, pin (E)		
889D-R4ACDE-Vx		• Right-angle connector, socket (R) • Right-angle connector, pin (E)		
879D-F4ACDM-x	V-cables <sup>(2)</sup>	• Straight connectors, socket (F) • Straight connector, pin (M)		
879D-R4ACDM-x		• Right-angle connectors, socket (R) • Straight connector, pin (M)		
879D-F4DM	Splitter <sup>(3)</sup>	• Straight connectors, socket (F) • Straight connector, pin (M)		

(1) Patchcords are available in standard lengths of 2, 5, and 10 m (6.6, 16.4, and 32.8 ft).

(2) V-cables are available in standard lengths of 0.3, 1, 2, and 5 m (1.0, 3.2, 6.6, and 16.4 ft).

(3) Splitter can be used in place of the V-cable.

For patchcord cable specifications see Cord Sets and Field Attachables Technical Data, publication [889-TD002](#).

## Technical Specifications - Kinetix 6000M Cables

### Hybrid Cable Specifications

Cable Cat. No.	Cable Type/ Jacket Color	Description	Wire Size AWG	Weight, approx kg/m (lb/ft)	Standard Cable Lengths m (ft)
2090-CHBIFS8-12AAxx <sup>(1)</sup>	Hybrid cable, Industrial, Orange (DESINA, RAL 2003)	<ul style="list-style-type: none"> <li>Power/signal/communication composite cable, shielded</li> <li>(UL) PLTC-ER</li> <li>FT4 flame rating</li> <li>AWM, 1000V, 105 °C</li> <li>Sun resistant, oil and water resistant</li> </ul>	12, 16, 22	0.36 (0.25)	P5 = 0.5 (1.6) 01 = 1.0 (3.2) 02 = 2.0 (6.5) 03 = 3.0 (9.8) 04 = 4.0 (13.1) 05 = 5.0 (16.4)
2090-CHBIFS8-12AAxx					09 = 9.0 (29.5) 12 = 12 (39.4) 15 = 15 (49.2) 20 = 20 (65.6) 25 = 25 (82.0)
2090-CCPP8S8					01 = 1.0 (3.2)
2090-CBKS8-16AA03		Two conductor, 600V, cable for motor brake	18	0.12 (0.08)	03 = 3.0 (9.8)

(1) Not available in 0.5 (1.6) cable length (2090-CHBIFS8-12AAP5 is not a valid catalog number).

### Network Cable Specifications

Cable Cat. No.	Cable Type/ Jacket Color	Description	Wire Size AWG	Weight, approx kg/m (lb/ft)	Standard Cable Lengths m (ft)
2090-CNSSPSS-AAxx	Network cable, Industrial, Violet (DESINA, RAL 4001)	<ul style="list-style-type: none"> <li>Industrial network cable, shielded</li> <li>(UL) PLTC-ER,</li> <li>Meets or exceeds Data Master/Category 5e Patch Cable electrical characteristics</li> <li>VW-1 flame rating</li> <li>AWM, 1000V, 80 °C, Type CMR, c(UL) Type CMG</li> <li>Sun resistant, oil resistant</li> </ul>	22	0.10 (0.068)	P5 = 0.5 (1.6) 01 = 1.0 (3.2) 02 = 2.0 (6.5) 03 = 3.0 (9.8) 04 = 4.0 (13.1) 05 = 5.0 (16.4)
2090-CNSRPRS-AAxx					09 = 9.0 (29.5) 12 = 12 (39.4) 15 = 15 (49.2) 20 = 20 (65.6) 25 = 25 (82.0)
2090-CNSSPRS-AAxx					
2090-CNSRPRS-AAxx					


## Dimensions - Kinetix 6000M Hybrid Cables

When installing hybrid cable runs, be careful not to stress the cable by making bends too sharp. Refer to the table below for bend radius definitions and the dimension diagrams that follow when routing cables during system installation.

### Hybrid and Network Cable Bend Radius Definitions

Type of Bend Radius	Type of Cable	Description
Static bend radius	Standard (non-flex)	<p>The static (installation) bend radius and dimension B are 7 times the cable diameter:</p> <ul style="list-style-type: none"> <li>Do not begin a static bend inside dimension B.</li> <li>Use this measurement when routing the cable in a non-flex application between IDM units (the bend area).</li> <li>The bend area is where standard (non-flex) cables can be bent to their specified bend radius.</li> </ul>

### Hybrid Cable Dimensions




### Hybrid Cable Dimensions


Hybrid Cable Cat. No.	A mm (in.)	B <sup>(1)</sup> mm (in.)	C mm (in.)	D mm (in.)
2090-CHBIFS8-12AAxx				
2090-CHBPS8-12AAxx	76.0 (3.0)	99.4 (3.9)	25.4 (1.0)	14.2 (0.5)
2090-CCPP8S8				
2090-CBKS8-16AA03		56.7 (2.2)		8.1 (0.3)

(1) Dimension B is based on the cable diameter.

## Dimensions - Kinetix 6000M Network Cables



## Dimensions - Kinetix 6000M Network Bulkhead Adapter



## Numerics

**2090-Series motor cables**  
specifications 168

## A

**about this publication** 9  
**absolute position** 54  
**accel/decel anomalies** 94  
**accessories**  
catalog number explanation 19  
digital input cables 157  
motor cables  
specifications 168  
optional 156  
**acronyms** 9  
**additional resources** 10  
**add-on profiles** 75  
**agency compliance** 21  
**align the IDM unit** 36  
**applying power** 84  
**axis module**  
axis properties 82  
**axis unstable** 94

## B

**bandwidth** 88  
**brake override input** 52  
**brake specifications**  
IDM units 147  
**bulkhead adapter examples** 159  
**bypass, IDM unit** 60

## C

**cable length**  
IDM units 21  
restrictions 23  
**cable shield clamp** 57  
**cable specifications** 163  
**cables**  
categories 30  
digital input 167  
fiber-optic cable length 61  
hybrid 163  
motor cables  
specifications 168  
network 165  
specifications 168  
motor power 168

## catalog number

accessories 19  
explanations 19  
hybrid cables 164  
IDM unit 19  
IPIM module 19  
network cables 166  
replacement parts 19  
shaft seal kits 146

## categories, cable

### category 3

requirements 108  
stop category definitions 108

## CE

comply with CE 112  
conformity 112  
meet requirements 112  
requirements 21

## certification

PL and SIL 108  
TÜV Rheinland 107  
user responsibilities 107  
website 10

## clamp

cable shield 57

## clearance requirements

IDM unit 28  
IPIM module 27

## communication configurations

typical 18

## CompactLogix sercos module

119

## compatibility

component 20  
DriveExplorer 20  
human interface module (HIM) 20  
software 20

## compliance

agency 21  
CE 21

## configuring

axis properties 82  
delay times 83  
drive modules 79  
logix controller 75  
node address 72  
sercos 75, 77

## configuring the IDM system

### 67

## connecting

Ethernet cables 65

## connector descriptions

DC bus 41  
enable 43  
EtherNet/IP 44  
hybrid 41  
network 44  
safe torque-off 42  
sercos 43

**ControlFLASH**

firmware upgrade 119  
software kit 119  
troubleshooting 125, 129  
verify upgrade 130

**controller properties** 76**ControlLogix sercos module** 119  
**conventions used in this manual** 9**conversion tab** 82**cycle time** 78**D****data rate** 78**data type** 80**date/time tab** 76**DC bus connector** 41**DC bus status indicator** 92**DC common bus**

follower IAM 17  
leader IAM 17  
pre-charge 17  
total bus capacitance 17

**delay times** 83**digital input**

cable examples 50  
connectors 47  
sensor connections 48  
specifications 51

**digital input cables** 167

IDM units 145

**dimensions**

hybrid cables 169  
IDM unit 150  
IPIM module 151  
network bulkhead adapters 170  
network cables 170

**disable drive** 97**display**

information 69  
startup 69  
tools 70

**download program** 83**drive status (D) indicator** 93**DriveExplorer** 20**E****electrical noise reduction** 29**EMC**

directive 112

**EN 61508** 108**EN 61508-5-2** 152**EN 62061** 108**enable connector** 43**enable time synchronization** 76**enclosure**

requirements 24  
selection 26

**encoder features**

IDM unit 144

**error codes, IDM system** 90**EtherNet/IP**

connecting cables 65

connector 44

PORT1 and PORT2 connectors 65

**F****fault action**

tab 83

**fault diagnosis** 95**fault reset** 95**fault status, reading** 90**features and indicators**

IPIM module 144

**feedback specifications** 54**fiber-optic**

RX and TX connectors 43, 61

**fiber-optic cables**

example 61, 62, 63, 64

**firmware upgrade** 119

verify upgrade 130

**follower IAM** 17**fuse**

catalog number 25

location 25

replacement 26

type 25

**G****grounding the IDM system** 56**H****hardware configurations**

typical 13

**hardware enable input** 85, 87**headers**

motion-allowed jumper 42

**heat dissipation** 26**hookup tab** 85**human interface compatibility** 20**hybrid and network cables**

IDM unit 145

**hybrid cable**

catalog numbers 164

dimensions 169

specifications 155

**hybrid cable connectors** 46**hybrid cables**

system example 163

**hybrid connector** 41**hybrid coupler example** 159

**I**

**IDM fault diagnosis** 97

**IDM system**

- bulkhead adapter examples 159
- cable specifications 163
- connector data 39
- digital input cables 157
- firmware upgrade 119
- hybrid cables 155
- hybrid coupler example 159
- maximum cable length 148
- network cables 156
- optional accessories 156
- replacement parts 166
- system example 154
- system performance 153

**IDM unit**

- align 36
- brake specifications 147
- cable length 21
- catalog number explanation 19
- connectors 45
- digital input cables 145
- digital input connectors 47
- dimensions 150
- encoder features 144
- hybrid and network cables 145
- hybrid cable connectors 46
- indicators 45, 93
- install 35
- load force ratings 149
- mount 36
- network cable connectors 47
- options 146
- overheating 95
- sensor connections 48
- specifications 146, 155
- system performance 160

**information display** 69

**install your IDM system** 23, 35

**installing your IDM system**

- clearance requirements 27, 28
- enclosure selection 26
- mounting requirements 24

**integrated axis module**

- axis properties 82

**interconnect diagram, IDM system** 117

**interpreting status indicators** 92

**IPIM module**

- catalog number explanation 19
- connectors 40
- dimensions 151
- display 68
- fault diagnosis 95
- features and indicators 144
- indicators 40
- network address, setting 71
- power dissipation 148
- replacement 104
- specifications 147, 155
- system performance 160

**ISO 13849-1** 152

**ISO 13849-1 CAT 3**

- requirements 108
- stop category definitions 108

**L**

**leader IAM** 17

**load force ratings**

- IDM units 149

**low voltage directive** 112

**M**

**manually sizing the IDM system** 132

**maximum cable length**

- IDM system 148

**module mounting order** 32

**module properties**

- drive modules 79
- sercos 77

**module status indicator** 92

**Motion Analyzer website** 10

**motion group properties** 81

**motion-allowed jumper** 42, 113

**motor cables**

- specifications 168

**mount the IPIM module** 32 . . . 34

- module mounting order 32
- mount brackets 32
- power rail 32

**N**

**network address**

- IPIM 71

**network bulkhead adapters**

- dimensions 170

**network cable**

- catalog numbers 166
- dimensions 170

**network cable connector**

- IDM unit 47
- IPIM module 44

**network cables** 60, 145, 156

- system example 165

**network status (N) indicator** 93

**network status indicator, IPIM module** 92

**node address** 79

- example 73, 74

**noise** 94, 95

**O**

**options, IDM units** 146

**P**

**panel requirements** 24

**parts, replacement**  
IDM system 166

**peak duty cycle** 52

**PFD, PFH and MTTFd definition** 111

**plan your installation** 23

**PLd** 152

**port status indicator** 93

**power rail** 32

**power specifications** 52

**power up** 84

**pre-charge** 17

**product selection website** 10

**product specifications** 143

**publications, related** 10

**R**

**related publications** 10

**replacement parts** 166  
catalog number explanation 19

**replacing the IPIM module** 104

**routing power and signal wiring** 56

**RSLinx software** 119

**RSLogix 5000 software** 75, 119

**S**

**safe torque-off**  
bypass 113  
connector 42  
feature, IDM unit 112  
motion-allowed jumper 113  
operation 108  
PFD, PFH and MTTFd 111  
specifications 115  
troubleshooting 109  
wiring 111

**safety products catalog** 113

**sensor connections** 48

**sercos connectors** 43

**sercos module** 75, 77

**shaft seal kit catalog numbers** 146

**shutdown** 97

**SIL CL2** 152

**SoftLogix sercos PCI card** 119

**software**  
RSLogix 5000 75

**software compatibility** 20

**specifications**  
brake override input 52  
digital input 51  
duty cycle 52  
feedback 54  
IDM system cables 168  
IDM unit 146  
IDM units 155  
IPIM module 147, 155  
motor cables 168  
motor power cables 168  
power dissipation  
IPIM module 148  
safe torque-off 115

**startup sequence** 69

**status indicators**  
DC bus, IPIM 92  
drive status (D), IDM 93  
IPIM 92  
module, IPIM 92  
network (N), IDM 93  
network, IPIM 92  
port, IPIM 93

**status only** 97

**stop motion** 97

**summary of changes** 9

**system components** 11

**system mounting requirements** 24

**system overview**  
common bus 16  
with LIM 14  
without LIM 15

**system performance** 153  
IDM unit and IPIM module 160  
torque/speed curves 161

**system sizing** 23, 131

**T**

**testing and tuning** 85

**testing axes**  
hookup tab 85

**tools menu** 70

**torque/speed curves** 161

**total bus capacitance** 17

**training** 9

**troubleshooting**  
ControlFLASH 125, 129  
disable drive 97  
error code E49 109  
general system anomalies 94  
abnormal noise 95  
accel/decel 94  
axis unstable 94  
IDM unit overheating 95  
no rotation 95  
noise 94  
sercos 94

velocity 94  
Logix/drive fault behavior 97  
safe torque-off 109  
safety precautions 89  
shutdown 97  
status only 97  
stop motion 97  
**tuning axes**  
bandwidth 88  
tune tab 87  
**typical communication configurations** 18  
**typical hardware configurations** 13  
**typical installation**  
common bus 16  
with LIM 14  
without LIM 15

## U

**units tab** 82

## W

**web browser, viewing status** 100  
**website**  
certifications 10  
Motion Analyzer 10  
product selection 10  
**wiring**  
Ethernet cables 65  
general system 58  
grounding 56  
hybrid connector 59  
network cables 60  
requirements 55  
routing power and signal wiring 56  
safe torque-off circuit 111

**Notes:**



# Rockwell Automation Support

Use the following resources to access support information.

<b>Technical Support Center</b>	Knowledgebase Articles, How-to Videos, FAQs, Chat, User Forums, and Product Notification Updates.	<a href="https://rockwellautomation.custhelp.com/">https://rockwellautomation.custhelp.com/</a>
<b>Local Technical Support Phone Numbers</b>	Locate the phone number for your country.	<a href="http://www.rockwellautomation.com/global/support/get-support-now.page">http://www.rockwellautomation.com/global/support/get-support-now.page</a>
<b>Direct Dial Codes</b>	Find the Direct Dial Code for your product. Use the code to route your call directly to a technical support engineer.	<a href="http://www.rockwellautomation.com/global/support/direct-dial.page">http://www.rockwellautomation.com/global/support/direct-dial.page</a>
<b>Literature Library</b>	Installation Instructions, Manuals, Brochures, and Technical Data.	<a href="http://www.rockwellautomation.com/global/literature-library/overview.page">http://www.rockwellautomation.com/global/literature-library/overview.page</a>
<b>Product Compatibility and Download Center (PCDC)</b>	Get help determining how products interact, check features and capabilities, and find associated firmware.	<a href="http://www.rockwellautomation.com/global/support/pcdc.page">http://www.rockwellautomation.com/global/support/pcdc.page</a>

## Documentation Feedback

Your comments will help us serve your documentation needs better. If you have any suggestions on how to improve this document, complete the How Are We Doing? form at

[http://literature.rockwellautomation.com/idc/groups/literature/documents/du/ra-du002\\_en-e.pdf](http://literature.rockwellautomation.com/idc/groups/literature/documents/du/ra-du002_en-e.pdf).



At the end of its life, this equipment should be collected separately from any unsorted municipal waste.

Rockwell Automation maintains current product environmental information on its website at <http://www.rockwellautomation.com/rockwellautomation/about-us/sustainability-ethics/product-environmental-compliance.page>.

Allen-Bradley, CompactLogix, ControlFLASH, ControlLogix, DriveExplorer, HPK-Series, Kinetix, MP-Series, Rockwell Automation, Rockwell Software, RSLinx, RSLogix 5000, SoftLogix are trademarks of Rockwell Automation, Inc. EtherNet/IP and CIP are trademarks of ODVA, Inc.

Trademarks not belonging to Rockwell Automation are property of their respective companies.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat:6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

**[www.rockwellautomation.com](http://www.rockwellautomation.com)**

### Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication 2094-UM003C-EN-P - March 2019

Supersedes Publication 2094-UM003B-EN-P - February 2015

Copyright © 2019 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.