

READ BEFORE USE

Visit www.hamiltonbeachappliances.co.uk for our complete line of products and Use and Care Guides – as well as delicious recipes, tips, and other useful information!

Questions?
Please call us – our friendly associates are ready to help.
0808-234-4688

Hamilton Beach®

Breakfast Sandwich Maker



IMPORTANT SAFEGUARDS

This product is intended for household use only.

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

1. Read all instructions.
2. This appliance is not intended for use, cleaning, or maintenance by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they are closely supervised and instructed concerning the use of the appliance by a person responsible for their safety. Children should be supervised to ensure they do not play with the appliance.
3. Keep the appliance and its cord out of reach of children.
4. Do not touch hot surfaces. Use handles or knobs.
5. To protect against risk of electrical shock, do not immerse cord, plug, or cooking unit in water or other liquid.
6. Unplug from socket when not in use and before cleaning. Allow to cool before putting on or taking off parts and before cleaning.

- 7.** Do not operate any appliance with a damaged supply cord, or after the appliance malfunctions or has been dropped or damaged in any manner. Supply cord replacement and repairs must be conducted by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.
- 8.** The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- 9.** Do not use outdoors.
- 10.** Do not let cord hang over edge of table or counter or touch hot surfaces, including the stove.
- 11.** Do not place on or near a hot gas or electric burner, or in a heated oven.
- 12.** Do not use appliance for other than intended use.
- 13.** Do not use appliance unattended.
- 14.** During use, provide 10 to 15 cm air space above, behind, and on both sides for air circulation.
- 15.** Never remove the food with any kind of cutting device or other metallic kitchen utensil.
- 16.** Always allow the appliance to cool before putting it away, and never wrap the cord around the appliance while it is still hot.
- 17.** This appliance is not intended to be operated by means of an external timer or separate remote-control system.

- 18.**  **CAUTION: HOT SURFACES.**
The temperature of accessible surfaces are hot when the appliance is operating. Always use oven mitt to protect hand when moving heating and cooking plates and ring assemblies.
- 19. UK Models ONLY: The UK plug**
is provided with a 13-amp fuse

approved by ASTA to B.S. 1362. If you need a replacement fuse carrier, it must be replaced with the same colour-coded carrier with the same markings. Fuse covers and carriers can be obtained from approved service agents.

SAVE THESE INSTRUCTIONS!





Recycling the Product at the End of Its Service Life

The wheeled bin symbol marked on this appliance signifies that it must be taken over by a selective collection system conforming to the WEEE Directive so that it can be either recycled or dismantled in order to reduce any impact to the environment. The user is responsible for returning the product to the appropriate collection facility, as specified by your local code. For additional information regarding applicable local laws, please contact the municipal facility and/or local distributor.

Parts and Features


BEFORE FIRST USE: Lift cover to remove ring assembly. Wash removable ring assembly in dishwasher or in hot, soapy water. Rinse and dry. Wipe top and bottom heating plates with a damp, soapy cloth. Remove soap with a damp cloth; dry thoroughly. Spray rings with nonstick cooking spray or wipe or brush with vegetable oil.




How to Use

⚠ CAUTION Burn Hazard.


Always use an oven mitt to protect hand when opening cover. Hot surfaces and escaping steam can burn.



1 Plug cord into wall socket. The red **POWER** light will glow. Lightly spray rings with nonstick cooking spray before each use. Let unit preheat with cover closed and cooking plate rotated in between rings.




2 **NOTE:** Green **PREHEAT** light will come on when unit is heated to the correct temperature and will cycle on and off during cooking. It is **NOT** an indicator when sandwich is ready. Red **POWER** light stays on.



3 Use handles to lift cover, top ring, and cooking plate.



4 Place bottom half of bread (such as a muffin, small bagel, or bread) onto bottom plate. Top bread with ingredients such as precooked meats, vegetables, and cheese. Do not overfill breakfast sandwich maker. Overfilling will cause food to spill over rings and get stuck in the hinges.



5 Move top ring and cooking plate down. Make sure cooking plate is rotated securely to back of ring as far as it will go to prevent leaking of egg. Crack an egg onto cooking plate. Pierce yolk with a fork or toothpick. (You can use a whole large egg, egg white, or a scrambled egg.)


How to Use (cont.)




8 Top with the other half of bread.




9 Close cover. Cook sandwich for 4 to 5 minutes. **NOTE:** Do not push lid all the way down when loaded with ingredients or when using a jumbo egg. Lid may rise as scrambled egg cooks.




12 Remove breakfast sandwich with plastic or wooden utensil. Never use metal.



10 When finished cooking, rotate cooking plate handle clockwise until it stops.



11 Using an oven mitt, lift ring assembly and cover by holding bottom handle to open. Some sandwiches are easier to remove if rings are lifted individually.




13 Unplug when through cooking. Let cool.

TIPS:


- Get your ingredients together before cooking your sandwich.
- Always keep cover closed with rings and cooking plate in place when preheating.
- Check to make sure the cooking plate is in place before preheating and when adding food.

Care and Cleaning


⚠ WARNING Electrical Shock Hazard.
Disconnect power before cleaning. Do not immerse cord, plug, or base in any liquid.



1
Unplug unit when through cooking. Let cool.



2
To remove ring assembly for cleaning, hold bottom handle to open, and then lift straight up.





3
Do not use steel wool, scouring pads, or abrasive cleansers on any part of the unit. Never use sharp or pointed objects for cleaning.



DO NOT use the high-temperature sanitizing setting when washing in the dishwasher. "SANI" cycle temperatures could damage your product.



4
Wipe top and bottom heating plates with a damp, soapy cloth. Remove soap with a damp cloth; dry thoroughly. To replace ring assembly, align tabs on the ring assembly with the openings on the hinge of the base, and lower. Wipe outside of unit with a damp, soapy cloth.



6

Troubleshooting

PROBLEM	PROBABLE CAUSE/SOLUTION
Low, poor, or slow heating.	• Breakfast sandwich maker wasn't preheated until PREHEAT light was illuminated. Green PREHEAT light will come on in about 5 to 7 minutes indicating unit is heated to the correct temperature. Light will cycle and does not indicate sandwich is ready. • Allow 2 minutes between making sandwiches for breakfast sandwich maker to heat to the correct temperature. • Overfilled. Reduce amount of ingredients in your sandwich. • Unit needs to be preheated with the cover closed with rings and cooking plate in place. • Make sure cooking plate is rotated securely to back of ring as far as it will go, to prevent leaking of egg, and cover is closed when preheating.
Egg undercooked, bread not done.	• Extra large eggs, frozen, or very cold ingredients may lengthen cooking time. Add additional cooking time.
Egg overcooked.	• Cooking time is about 5 minutes. Cooking time may vary if you are using small eggs, scrambled or egg whites. Reduce cooking time for future recipes.
Ingredients stick to rings or nonstick cooking plate.	• Use a plastic or wooden utensil to loosen any baked-on ingredients. Lightly spray with nonstick cooking spray before preheating for next use.
Eggs leak out of rings.	• Unit is overfilled. Only use large eggs and reduce amount or size of ingredients. Do not press down on the cover. • Cooking plate may not have been in the correct position. Make sure cooking plate is rotated securely to back of ring as far as it will go to prevent leaking of egg. • Used very thin purchased egg whites. Use fresh egg white or try a different brand of egg whites.
Cover rises when cooking my sandwich.	• The air whisked into a large scrambled egg may cause the cover to rise while the egg is cooking. Do not press down on the cover.
Bread too brown.	• Higher fat contents and sugars may cause breads too darken. Cook egg for several minutes without bread and cover down. Then add bread to finish cooking your sandwich.

Recipes

Egg, Ham, and Cheese Breakfast Sandwich

1 muffin, split
1 slice cheese
1 slice precooked bacon or ham
1 large egg

Directions

1. Preheat Breakfast Sandwich Maker until green **PREHEAT** light comes on. Lift cover, top ring, and cooking plate.
2. Place half of muffin, split-side up, in bottom ring of Breakfast Sandwich Maker. Top with cheese and bacon.
3. Lower cooking plate and top ring. Add egg to cooking plate. Pierce yolk with a fork or toothpick.
4. Top with remaining muffin half, split-side down.
5. Close cover. Cook 4 to 5 minutes. Rotate cooking plate handle clockwise until it stops. Lift cover and rings and carefully remove sandwich with plastic spatula.

Serves: 1

Recipes (cont.)

Cheddar, Apple, Bacon, and Egg Croissant Sandwich

- 1 small croissant, halved
- 2 Tablespoons (40 ml) shredded Cheddar cheese
- 4 thin slices green apple
- 1 slice precooked bacon, cut in half
- 1 large egg

Directions

1. Preheat Breakfast Sandwich Maker until green **PREHEAT** light comes on. Lift cover, top ring, and cooking plate.
2. Place half of croissant, cut-side up, in bottom ring of Breakfast Sandwich Maker. Top with cheese, apple slices, and bacon.
3. Lower cooking plate and top ring. Add egg to cooking plate. Pierce yolk with a fork or toothpick.
4. Top with remaining croissant half, cut-side down.
5. Close cover. Cook 4 to 5 minutes. Rotate cooking plate handle clockwise until it stops. Lift cover and rings and carefully remove sandwich with plastic spatula.

Serves: 1

Southwestern Breakfast Muffin

- 1 whole wheat muffin, split
- 1 slice Monterey Jack cheese
- 3 thin slices avocado
- 1 large egg white
- 1 Tablespoon (20 ml) salsa

Directions

1. Preheat Breakfast Sandwich Maker until green **PREHEAT** light comes on. Lift cover, top ring, and cooking plate.
2. Place half of muffin, split-side up, in bottom ring of Breakfast Sandwich Maker. Top with cheese and avocado.
3. Lower cooking plate and top ring. Add egg white to cooking plate.
4. Top with remaining muffin half, split-side down.
5. Close cover. Cook 4 to 5 minutes. Rotate cooking plate handle clockwise until it stops. Lift cover and rings and carefully remove sandwich with plastic spatula. Serve with salsa.

Serves: 1

Recipes (cont.)

Cheesy Egg and Sausage Bagel

- 1 small bagel, halved
- 1 slice Jarlsberg cheese
- 1 precooked thin meat, like cooked ham
- 1 thin slice red pepper ring
- 1 large egg

Directions

1. Preheat Breakfast Sandwich Maker until green **PREHEAT** light comes on. Lift cover, top ring, and cooking plate.
2. Place half of bagel, split-side up, in bottom ring of Breakfast Sandwich Maker. Top with cheese, sausage, and red pepper ring.
3. Lower cooking plate and top ring. Add egg to cooking plate. Pierce yolk with a fork or toothpick.
4. Top with remaining bagel half, split-side down.
5. Close cover. Cook 4 to 5 minutes. Rotate cooking plate handle clockwise until it stops. Lift cover and rings and carefully remove sandwich with plastic spatula.

Serves: 1

Herb Goat Cheese, Spinach, and Tomato Egg Muffin

- 1 whole wheat muffin, split
- 1 Tablespoon (20 ml) herb goat cheese
- 1 thin slice tomato
- 4 spinach leaves
- 1 thin slice red pepper ring
- 1 large egg white

Directions

1. Preheat Breakfast Sandwich Maker until green **PREHEAT** light comes on. Spread goat cheese over bottom half of muffin. Lift cover, top ring, and cooking plate.
2. Place half of muffin, goat cheese side up, in bottom of Breakfast Sandwich Maker. Top with tomato, spinach, and red pepper ring.
3. Lower cooking plate and top ring. Add egg white to cooking plate.
4. Top with remaining muffin half, split-side down.
5. Close cover. Cook 4 to 5 minutes. Move cooking plate handle clockwise until it stops. Lift cover and rings and carefully remove sandwich with plastic spatula.

Serves: 1

Notes

Notes

Notes

Hamilton Beach 1-Year Guarantee

This guarantee applies to products purchased and used in the United Kingdom. This is the only express guarantee for this product and is in lieu of any other guarantee or warranty.

This product is guaranteed to be free from defects in material and workmanship for a period of one (1) year from the date of original purchase. During this period, your exclusive remedy is repair or replacement of this product or any component found to be defective, at our option; however, you are responsible for all costs associated with returning the product to us and our returning a product or component under this guarantee to you. If the product or component is no longer available, we will replace with a similar one of equal or greater value.

This guarantee does not cover glass, filters, wear from normal use, use not in conformity with the printed directions, or damage to the product resulting from accident, alteration, abuse, or misuse. This guarantee extends only to the original consumer purchaser or gift recipient. Keep the original sales receipt, as proof of purchase is required to make a guarantee claim. This guarantee is void if the product is used for other than single-family household use or subjected to any voltage and waveform other than as specified on the rating label (e.g., 220–240 V 50/60 Hz).

We exclude all claims for special, incidental, and consequential damages caused by breach of express or implied guarantee or warranty. All liability is limited to the amount of the purchase price. **Every implied guarantee or warranty, including any statutory guarantee or warranty of merchantability or fitness for a particular purpose, is disclaimed except to the extent prohibited by law, in which case such guarantee or warranty is limited to the duration of this written guarantee.** This guarantee gives you specific legal rights. You may have other legal rights that vary depending on where you live. Some countries do not allow limitations on guarantees or warranties or special, incidental, or consequential damages, so the foregoing limitations may not apply to you.

To make a claim under this guarantee, do not return this appliance to the store. Please contact us by email at customer.service@hamiltonbeachappliances.co.uk or by phone at 0808-234-4688.

Hamilton Beach Brands, Inc.
4421 Waterfront Drive
Glen Allen
Virginia 23060
USA

840256400

3/15