

MB-GATEWAY

Hardware User Manual



⚡ WARNING ⚡

Thank you for purchasing automation equipment from **AutomationDirect.com®**, doing business as, **AutomationDirect**. We want your new automation equipment to operate safely. Anyone who installs or uses this equipment should read this publication (and any other relevant publications) before installing or operating the equipment.

To minimize the risk of potential safety problems, you should follow all applicable local and national codes that regulate the installation and operation of your equipment. These codes vary from area to area and usually change with time. It is your responsibility to determine which codes should be followed, and to verify that the equipment, installation, and operation is in compliance with the latest revision of these codes.

At a minimum, you should follow all applicable sections of the National Fire Code, National Electrical Code, and the codes of the National Electrical Manufacturer's Association (NEMA). There may be local regulatory or government offices that can also help determine which codes and standards are necessary for safe installation and operation.

Equipment damage or serious injury to personnel can result from the failure to follow all applicable codes and standards. We do not guarantee the products described in this publication are suitable for your particular application, nor do we assume any responsibility for your product design, installation, or operation.

Our products are not fault-tolerant and are not designed, manufactured or intended for use or resale as on-line control equipment in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, direct life support machines, or weapons systems, in which the failure of the product could lead directly to death, personal injury, or severe physical or environmental damage ("High Risk Activities"). **AutomationDirect** specifically disclaims any expressed or implied warranty of fitness for High Risk Activities.

For additional warranty and safety information, see the Terms and Conditions section of our catalog. If you have any questions concerning the installation or operation of this equipment, or if you need additional information, please call us at 770-844-4200.

This publication is based on information that was available at the time it was printed. At **AutomationDirect** we constantly strive to improve our products and services, so we reserve the right to make changes to the products and/or publications at any time without notice and without any obligation. This publication may also discuss features that may not be available in certain revisions of the product.

Trademarks

This publication may contain references to products produced and/or offered by other companies. The product and company names may be trademarked and are the sole property of their respective owners. **AutomationDirect** disclaims any proprietary interest in the marks and names of others.

Copyright 2011-2020, **AutomationDirect.com® Incorporated**
All Rights Reserved

No part of this manual shall be copied, reproduced, or transmitted in any way without the prior, written consent of **AutomationDirect.com® Incorporated**. **AutomationDirect** retains the exclusive rights to all information included in this document.

⚡ ADVERTENCIA ⚡

Gracias por comprar equipo de automatización de **Automationdirect.com®**. Deseamos que su nuevo equipo de automatización opere de manera segura. Cualquier persona que instale o use este equipo debe leer esta publicación (y cualquier otra publicación pertinente) antes de instalar u operar el equipo.

Para reducir al mínimo el riesgo debido a problemas de seguridad, debe seguir todos los códigos de seguridad locales o nacionales aplicables que regulan la instalación y operación de su equipo. Estos códigos varían de área en área y usualmente cambian con el tiempo. Es su responsabilidad determinar cuales códigos deben ser seguidos y verificar que el equipo, instalación y operación estén en cumplimiento con la revisión mas reciente de estos códigos.

Como mínimo, debe seguir las secciones aplicables del Código Nacional de Incendio, Código Nacional Eléctrico, y los códigos de (NEMA) la Asociación Nacional de Fabricantes Eléctricos de USA. Puede haber oficinas de normas locales o del gobierno que pueden ayudar a determinar cuales códigos y normas son necesarios para una instalación y operación segura.

Si no se siguen todos los códigos y normas aplicables, puede resultar en daños al equipo o lesiones serias a personas. No garantizamos los productos descritos en esta publicación para ser adecuados para su aplicación en particular, ni asumimos ninguna responsabilidad por el diseño de su producto, la instalación u operación.

Nuestros productos no son tolerantes a fallas y no han sido diseñados, fabricados o intencionados para uso o reventa como equipo de control en línea en ambientes peligrosos que requieren una ejecución sin fallas, tales como operación en instalaciones nucleares, sistemas de navegación aérea, o de comunicación, control de tráfico aéreo, máquinas de soporte de vida o sistemas de armamentos en las cuales la falla del producto puede resultar directamente en muerte, heridas personales, o daños físicos o ambientales severos (“Actividades de Alto Riesgo”). **Automationdirect.com** específicamente rechaza cualquier garantía ya sea expresada o implicada para actividades de alto riesgo.

Para información adicional acerca de garantía e información de seguridad, vea la sección de Términos y Condiciones de nuestro catálogo. Si tiene alguna pregunta sobre instalación u operación de este equipo, o si necesita información adicional, por favor llámenos al número 770-844-4200 en Estados Unidos.

Esta publicación está basada en la información disponible al momento de impresión. En **Automationdirect.com** nos esforzamos constantemente para mejorar nuestros productos y servicios, así que nos reservamos el derecho de hacer cambios al producto y/o a las publicaciones en cualquier momento sin notificación y sin ninguna obligación. Esta publicación también puede discutir características que no estén disponibles en ciertas revisiones del producto.

Marcas Registradas

Esta publicación puede contener referencias a productos producidos y/u ofrecidos por otras compañías. Los nombres de las compañías y productos pueden tener marcas registradas y son propiedad única de sus respectivos dueños. Automationdirect.com, renuncia cualquier interés propietario en las marcas y nombres de otros.

PROPIEDAD LITERARIA 2011-2020, AUTOMATIONDIRECT.COM® INCORPORATED

Todos los derechos reservados

No se permite copiar, reproducir, o transmitir de ninguna forma ninguna parte de este manual sin previo consentimiento por escrito de **Automationdirect.com® Incorporated**. **Automationdirect.com** retiene los derechos exclusivos a toda la información incluida en este documento. Los usuarios de este equipo pueden copiar este documento solamente para instalar, configurar y mantener el equipo correspondiente. También las instituciones de enseñanza pueden usar este manual para propósitos educativos.

⚡ AVERTISSEMENT ⚡

Nous vous remercions d'avoir acheté l'équipement d'automatisation de **Automationdirect.com®**, en faisant des affaires comme, **AutomationDirect**. Nous tenons à ce que votre nouvel équipement d'automatisation fonctionne en toute sécurité. Toute personne qui installe ou utilise cet équipement doit lire la présente publication (et toutes les autres publications pertinentes) avant de l'installer ou de l'utiliser.

Afin de réduire au minimum le risque d'éventuels problèmes de sécurité, vous devez respecter tous les codes locaux et nationaux applicables régissant l'installation et le fonctionnement de votre équipement. Ces codes diffèrent d'une région à l'autre et, habituellement, évoluent au fil du temps. Il vous incombe de déterminer les codes à respecter et de vous assurer que l'équipement, l'installation et le fonctionnement sont conformes aux exigences de la version la plus récente de ces codes.

Vous devez, à tout le moins, respecter toutes les sections applicables du Code national de prévention des incendies, du Code national de l'électricité et des codes de la National Electrical Manufacturer's Association (NEMA). Des organismes de réglementation ou des services gouvernementaux locaux peuvent également vous aider à déterminer les codes ainsi que les normes à respecter pour assurer une installation et un fonctionnement sûrs.

L'omission de respecter la totalité des codes et des normes applicables peut entraîner des dommages à l'équipement ou causer de graves blessures au personnel. Nous ne garantissons pas que les produits décrits dans cette publication conviennent à votre application particulière et nous n'assumons aucune responsabilité à l'égard de la conception, de l'installation ou du fonctionnement de votre produit.

Nos produits ne sont pas insensibles aux défaillances et ne sont ni conçus ni fabriqués pour l'utilisation ou la revente en tant qu'équipement de commande en ligne dans des environnements dangereux nécessitant une sécurité absolue, par exemple, l'exploitation d'installations nucléaires, les systèmes de navigation aérienne ou de communication, le contrôle de la circulation aérienne, les équipements de survie ou les systèmes d'armes, pour lesquels la défaillance du produit peut provoquer la mort, des blessures corporelles ou de graves dommages matériels ou environnementaux («activités à risque élevé»). La société **AutomationDirect** nie toute garantie expresse ou implicite d'aptitude à l'emploi en ce qui a trait aux activités à risque élevé.

Pour des renseignements additionnels touchant la garantie et la sécurité, veuillez consulter la section Modalités et conditions de notre documentation. Si vous avez des questions au sujet de l'installation ou du fonctionnement de cet équipement, ou encore si vous avez besoin de renseignements supplémentaires, n'hésitez pas à nous téléphoner au 770-844-4200.

Cette publication s'appuie sur l'information qui était disponible au moment de l'impression. À la société **AutomationDirect**, nous nous efforçons constamment d'améliorer nos produits et services. C'est pourquoi nous nous réservons le droit d'apporter des modifications aux produits ou aux publications en tout temps, sans préavis ni quelque obligation que ce soit. La présente publication peut aussi porter sur des caractéristiques susceptibles de ne pas être offertes dans certaines versions révisées du produit.

Marques de commerce

La présente publication peut contenir des références à des produits fabriqués ou offerts par d'autres entreprises. Les désignations des produits et des entreprises peuvent être des marques de commerce et appartiennent exclusivement à leurs propriétaires respectifs. **AutomationDirect** nie tout intérêt dans les autres marques et désignations.

Copyright 2011-2020, Automationdirect.com® Incorporated
Tous droits réservés

Nulle partie de ce manuel ne doit être copiée, reproduite ou transmise de quelque façon que ce soit sans le consentement préalable écrit de la société **Automationdirect.com® Incorporated**. **AutomationDirect** conserve les droits exclusifs à l'égard de tous les renseignements contenus dans le présent document.

MB-GATEWAY

HARDWARE USER MANUAL



Please include the Manual Number and the Manual Issue, both shown below, when communicating with Technical Support regarding this publication.

Manual Number: MB-GATEWAY-USER-M

Issue: 1st Edition Rev. H

Issue Date: 02/2021

Publication History		
Issue	Date	Description of Changes
1st Edition	06/11	Original issue
Rev. A	01/12	Added Example 4 to Appendix
Rev. B	07/12	Added IP address reset note.
Rev. C	10/13	Added Autodetection notes. Added TCP to RTU diagrams.
Rev. D	02/16	Revised product photo
Rev E	09/17	Several minor revisions
Rev F	10/18	Minor revision to Appendix A, Application Examples
Rev G	02/20	Added Appendix C, Security Considerations for Control Systems Networks
Rev H	02/21	Added failsafe receiver to feature list

TABLE OF CONTENTS



Chapter 1: Getting Started

Introduction	1-2
Overview of this Publication	1-2
Who Should Read This Manual	1-3
Technical Support	1-3
Conventions Used	1-4
Key Topics for Each Chapter	1-4
Product Overview	1-5
What's in the Box	1-6
Mounting / Clearance Information	1-6
Direct Mounting	1-6
DIN Rail Mounting	1-7
Agency Approvals	1-7

Chapter 2: Specifications

Specifications	2-2
LED Indicators	2-3
STA	2-3
SPD	2-3
TXD	2-3
ERR	2-3
LK/A	2-4
RXD	2-4
Dip Switch Information	2-5
Dimensional Drawing	2-6
Inches [mm]	2-6

Chapter 3: Installation, Wiring and Configuration

Safety Guidelines	3-2
Plan for Safety	3-2
Security Considerations	3-2
Wiring Diagrams	3-3
MB-GATEWAY Configuration	3-4
NetEdit Configuration	3-5
Function Codes Supported	3-6
Log Modbus/TCP and/or RTU requests to SMTPViewer	3-6

Chapter 4: Parameters

Home Page	4-2
Gateway Modbus ID	4-3
Module Name and Module Description	4-4
IP Setup Configuration Page	4-5
Serial Port Configuration Page	4-6
Set Up Slave Timeout / Retries Page	4-7
Gateway Device Status Page	4-8
❶ Automatic Reads	4-9
❷ Last Modbus TCP Request	4-9
❸ Last Modbus RTU Request	4-10
❹ Status Information	4-10
Setup Automatic Read Page	4-10
Firmware Updates	4-11

Chapter 5: Automatic Read Feature

Automatic Read Feature	5-2
Situation 1:	5-3
Situation 2:	5-6
Additional Optimization	5-8
Automatic Read Status Data	5-9

Appendix A: Application Examples

Example 1:

Using Modbus Poll to MB-GATEWAY with DL06 Slave..... A-2

Items needed for this example: A-2

Step 1: Connect the MB-GATEWAY serial port to the DL06 secondary communications port..... A-2

Step 2: Configure the DL06 PLC serial port and MB-GATEWAY serial port. A-3

Step 3: Connect to the MB-GATEWAY using the Modbus Poll simulator software. A-7

Example 2:

Using Modbus Poll to MB-GATEWAY with CLICK Slave A-11

Items needed for this example: A-11

Step 1: Connect the MB-GATEWAY serial port to Port 3 of the CLICK PLC..... A-11

Step 2: Configure the CLICK serial port and MB-GATEWAY serial port. A-12

Step 3: Connect to the MB-GATEWAY using the Modbus Poll simulator software. .. A-18

Example 3:

Using P3000 as Master (Client) to MB-GATEWAY with CLICK Slave. A-24

Step 1: Connect CLICK to the MB-GATEWAY as shown in example 2. A-24

Step 2: Connect P3000 CPU (P3-550) to MB-GATEWAY via Ethernet Switch and Two Ethernet Cables. A-24

Step 3: Configure the MRX instruction to read data from the MB-GATEWAY. A-28

Example 4:

DirectLogic 06 (H0-ECOM100) as Master (Client) to

MB-GATEWAY with Multiple GS Drives as Slaves. A-29

Step 1: Set up Peer to Peer Configuration A-30

Step 2: Set the Serial Port Configuration A-31

Step 3: Set the Communication Parameters A-31

Step 4: Using Automatic Reads..... A-32

Step 5: Access the Automatic Read Data A-33

Step 6: Read and Write from the DL06 A-36

Appendix B: Modbus Error Codes

Modbus Error Codes..... B-2

Appendix C: Security Considerations for Control Systems Networks

Security Considerations for Control Systems Networks..... C-2

Index

GETTING STARTED



CHAPTER 1

In this Chapter...


Introduction	1-2
Overview of this Publication	1-2
Who Should Read This Manual.....	1-3
Technical Support	1-3
Conventions Used	1-4
Key Topics for Each Chapter	1-4
Product Overview	1-5
What's in the Box	1-6
Mounting / Clearance Information	1-6
Direct Mounting.....	1-6
DIN Rail Mounting	1-7
Agency Approvals	1-7

Introduction

Overview of this Publication

Modbus is one of the most popular communication protocols in the automation industry because it supports both traditional RS-232/422/485 devices and newly developed industrial Ethernet devices. Many industrial devices, such as PLCs, HMIs, instruments and meters use Modbus as their standard communication protocol. However, the Modbus protocols running over serial and Ethernet are so different that a communication gateway is needed as a bridge for integrating devices from these two networks. The MB-GATEWAY is a Modbus TCP (Ethernet) to Modbus RTU (Serial) Gateway which provides the necessary bridge to connect Modbus RTU (Serial) products to Ethernet LANs.

The Modbus TCP side of the Gateway functions as a TCP Server (slave) while the Modbus RTU side functions as a serial Client (master). The serial side physical interface is RS-422/485 2 or 4 wire so up to 128 Modbus RTU devices can be accessed by a Modbus TCP Client device (up to 12 simultaneous connections). The actual number of Modbus RTU slaves will depend on their individual transceiver loads.



The MB-GATEWAY User Manual describes the installation, configuration, and methods of operation of the MB-GATEWAY Module.

Who Should Read This Manual

This manual contains important information for those who will install, maintain, and/or operate The MB-GATEWAY Module.

Technical Support

We strive to make our manuals the best in the industry. We rely on your feedback to let us know if we are reaching our goal. If you cannot find the solution to your particular application, or, if for any reason you need technical assistance, please call us at:

770-844-4200

Our technical support group will work with you to answer your questions. They are available Monday through Friday from 9:00 A.M. to 6:00 P.M. Eastern Time. We also encourage you to visit our web site where you can find technical and non-technical information about our products and our company.

<http://www.automationdirect.com>

Conventions Used



When you see the “notepad” icon in the left-hand margin, the paragraph to its immediate right will be a special note. The word **NOTE:** in boldface will mark the beginning of the text.



When you see the “exclamation mark” icon in the left-hand margin, the paragraph to its immediate right will be a warning. This information could prevent injury, loss of property, or even death (in extreme cases). The word **WARNING:** in boldface will mark the beginning of the text.

Key Topics for Each Chapter

The beginning of each chapter will list the key topics that can be found in that chapter.

Getting Started

CHAPTER

1

In This Chapter...

General Information1-2

Specifications1-4

Product Overview




AutomationDirect's MB-GATEWAY is a single port Modbus Gateway module that converts Modbus TCP to Modbus RTU. It supports up to 12 simultaneous Modbus TCP Client (master) Ethernet connections, and up to 128 RTU Server (slave) Serial connections. MB-GATEWAY requires 10VDC to 36VDC from an external power supply. Each module has one RJ45 10/100 Mbps Ethernet port and one RS-422/485 2 or 4 wire Serial Port. It supports NetEdit (Ver 3.8 and later) or Web Browser based configuration tools.

Key features include:

- Automatic Read Function
- RJ45 10/100 Mbps Ethernet Port
- RS-422/485 2 or 4 wire Serial Port
- True failsafe receiver while maintaining EIA/TIA-485 compatibility
- Supports NetEdit and Web Browser configuration tools
- Autodetects Ethernet cable types (MDI/MDX)
- 35mm DIN rail mount

What's in the Box




Mounting / Clearance Information

There are two options for mounting the MB-GATEWAY module.

Direct Mounting

The MB-GATEWAY module can be mounted in either a low-profile orientation or a slim-mount orientation using screw holes on the provided mounting adapter. Screws are not provided



DIN Rail Mounting


The MB-GATEWAY module can be snapped onto a standard 35 mm x 7.5 mm height DIN rail (Standard: CENELEC EN50022). They can be mounted either vertically or horizontally. Refer to the mechanical drawings that follow for proper mounting.

DIN rail mounting steps:

1. Hook bottom back of unit over the DIN rail.
2. Push top back onto the DIN rail until it snaps into place.

DIN rail removal steps:

- A. Pull up on tab at the top of the mounting adapter with a screwdriver.
- B. Rotate the bottom of the unit away from the DIN rail.
- C. Pull unit down and away from DIN rail.



Agency Approvals

UL/CUL/CE Certification Numbers			
Name	UL/CUL	UL508	CE
MB-GATEWAY	E185989	E185989	Yes



SPECIFICATIONS



CHAPTER 2


In this Chapter...

Specifications	2-2
LED Indicators	2-3
Dip Switch Information	2-4
Dimensional Drawing	2-5

Specifications

Specifications		
Ethernet Interface	Port	RJ-45
	Speed	10/100 Mbps
	Protection	Built-in 1.5 KV magnetic isolation
	Protocol Supported	Modbus TCP/IP Server (Slave)
	Clients (Masters) Supported	12 simultaneous Modbus TCP connections
	Cable Type	Autodetects Ethernet cable types (MDI/MDX)
Serial Interface	Port	6-position terminal strip (Phoenix #1863194) provided
	Supported Signal Lines	RS-422 (5-wire) Signals: TX+, TX-, RX-, RX+, GND RS-485 (3-wire) Signals: Data+, Data -, GND
	Supported Baud Rates	300*, 600*, 1200*, 2400, 4800, 9600, 14.4k, 19.2k, 38.4k, 57.6k, 115.2k <i>* Cannot be set with DIP switches. Must be set via web browser configuration.</i>
	Parity	Odd, Even, None
	Data Bits	8
	Stop Bits	1, 2
	Protocol Supported	Modbus RTU Client (Master)
	Servers (Slaves) Supported	128
	Termination	Permanently installed 120ΩΩ resistor between Data+ and Data -
Power Consumption		2W Use Class 2 power supply Use conductors rated 60/75 °C 3-position terminal strip (Phoenix #1863165) provided
Wire Range		16 - 28 AWG Solid or Stranded Conductor (1.5 mm ²)
Wire Strip Length		0.24 - 0.27 in (6 - 7 mm)
Screw Torque		1.7 lb-in (0.2 Nm)
Operating Temperature Range		0 to 60 °C (32 to 140 °F)
Storage Temperature Range		-20 to 70 °C (-4 to 158 °F)
Humidity		5 to 95% RH (non-condensing)
Environmental Air		For use in Pollution Degree 2 Environment. No corrosive gases
Vibration		MIL STD 810C 514.2
Shock		MIL STD 810C 516.2
Weight		0.2 lbs (0.09 kg)

LED Indicators



STA

The STA or STATUS LED is steady ON when the MB-GATEWAY has passed power-up diagnostics and is ready for use.

SPD

The SPD or SPEED LED is used to represent the Ethernet speed. The LED will be ON when the Ethernet speed is 100Mbps and OFF when the speed is 10Mbps.

TXD

The TXD or TRANSMIT DATA LED flashes to indicate that the MB-GATEWAY is sending data through the serial port.

ERR

If the MB-GATEWAY's ERR (ERROR) indicator is:

- ON - a critical error has occurred. The error may be in the card itself, or the result of a network problem. The ERROR indication can be caused by a faulty ground, an electrical spike or other types of electrical disturbances. Cycle power to the system to attempt clearing the error.
- Flashing once per second - a firmware update is in progress.
- Flashing randomly - a Modbus/RTU error. This could be a timeout or an actual error response. Check the Gateway Device Status page on the MB-GATEWAY configuration web page to see the quantity of Request Errors and the description of the Last Request Error.

A CRC error for an Automatic Reads table entry will flash the ERROR LED and set the Last Request Error to: MODBUS_ERROR_MEMORY_PARITY_ERROR.

For a direct request from a Modbus TCP server, a Modbus RTU parity error will return the error MODBUS_ERROR_MEMORY_PARITY_ERROR to the Modbus TCP server.


LK/A

The LK/A or LINK GOOD/ACTIVITY LED flashes to indicate that the card sees data traveling on the Ethernet network. If any network device is sending or receiving data, the LK/A LED will be flashing. During heavy communication loads, this indicator will be steady ON. If the LED is OFF, then a problem with the Ethernet connection has been detected.

RXD

The RXD or RECEIVE DATA LED flashes to indicate that the MB-GATEWAY is receiving data through the serial port.

Dip Switch Information




S7	S6	S5	S4	S3	S2	S1	S0	Switch setting	
					0	0	0	Software Config	Baud Rate
					0	0	1	4800	
					0	1	0	9600	
					0	1	1	14400	
					1	0	0	19200	
					1	0	1	38400	
					1	1	0	57600	
					1	1	1	115200	
					0	0		None	Parity
					0	1		Odd	
					1	0		Even	
					1	1		Reserved	
					0			1 Bit	Stop Bits
					1			2 Bits	
								*	Reset IP
Reserved								S7 reserved	

* Setting S6 to on will, on power cycle, set the IP address, subnet mask and gateway address in the MB-GATEWAY to 0.0.0.0

Dimensional Drawing

Inches [mm]



INSTALLATION, WIRING AND CONFIGURATION



CHAPTER 3

In this Chapter...

Safety Guidelines	3-2
Plan for Safety	3-2
Security Considerations	3-2
Wiring Diagrams.....	3-3
MB-GATEWAY Configuration.....	3-4
NetEdit Configuration	3-5
Function Codes Supported	3-6
Log Modbus/TCP and/or RTU requests to SMTPViewer.....	3-6

Safety Guidelines



WARNING: Providing a safe operating environment for personnel and equipment is your responsibility and should be your primary goal during system planning and installation. Automation systems can fail and may result in situations that can cause serious injury to personnel or damage to equipment. Do not rely on the automation system alone to provide a safe operating environment. You should use external electromechanical devices, such as relays or limit switches, that are independent of the PLC application to provide protection for any part of the system that may cause personal injury or damage. Every automation application is different, so there may be special requirements for your particular application. Make sure you follow all national, state, and local government requirements for the proper installation and use of your equipment.

3

Plan for Safety

The best way to provide a safe operating environment is to make personnel and equipment safety part of the planning process. You should examine every aspect of the system to determine which areas are critical to operator or machine safety. If you are not familiar with control system installation practices, or your company does not have established installation guidelines, you should obtain additional information from the following sources.

- NEMA — The National Electrical Manufacturers Association, located in Washington, D.C. publishes many different documents that discuss standards for industrial control systems. You can order these publications directly from NEMA. Some of these include:

ICS 1, General Standards for Industrial Control and Systems

ICS 3, Industrial Systems

ICS 6, Enclosures for Industrial Control Systems



- NEC — The National Electrical Code provides regulations concerning the installation and use of various types of electrical equipment. Copies of the NEC Handbook can often be obtained from your local electrical equipment distributor or your local library.
- Local and State Agencies — many local governments and state governments have additional requirements above and beyond those described in the NEC Handbook. Check with your local Electrical Inspector or Fire Marshall office for information.

Security Considerations

When implementing any method of remote access to your equipment, you need to consider the security exposure in order to minimize the risks to your processes and your equipment. Security should always be carefully evaluated for each installation. Refer to “Appendix C: Security Considerations for Control Systems Networks” for more information.

Wiring Diagrams

The MB-GATEWAY module can be wired in either 4-wire or 2-wire mode.



MB-GATEWAY Configuration

The MB-GATEWAY supports 128 Modbus RTU nodes on the serial side. The RS-485 specification supports up to 32 devices before a repeater device is required. Proper cabling and termination is required. For RS-485 4-wire installations, a cable with the proper shielding and impedance should be used such as a Belden model 9843. For RS-485 2 wire installations, a cable such as the Belden model 9842 should be used. A 120 ohm resistor should be used for termination on each end of the network as shown in the previous wiring diagrams. The GATEWAY module has a termination resistor pre-installed so only one resistor needs to be added to the opposite end of the network away from the Gateway module.

The MB-GATEWAY module supports up to 12 simultaneous Modbus TCP connections. The MB-GATEWAY's TCP listening port is the standard Modbus TCP port 502 (not configurable).

One of the major features of the MB-GATEWAY module is the "Automatic Read" function. This feature utilizes the 'idle' time of the module while it is waiting for Ethernet requests. The Automatic Read function can be configured to poll specific Modbus data points of the serial nodes and place that data into a local 'data buffer'. If a Modbus Ethernet request comes in for one of those data points, the MB-GATEWAY module will immediately respond with the data from local buffer and thereby respond much faster than it would if it had to generate a new serial request. See Chapter 5 for more information.

The factory IP setting of the MB-GATEWAY module is to retrieve an IP address via DHCP. In order to see what IP address has been assigned and/or to change that setting the NetEdit software tool will be required to discover and configure the MB-GATEWAY TCP/IP settings. NetEdit is a free tool that is accessible at AutomationDirect's website or HOST engineering's website (http://www.hosteng.com/SW-Products/SP_Demo_Utilites.htm#NetEdit3).



NOTE: NetEdit version 3.8 or later is required to support MB-GATEWAY

MB-GATEWAY Configuration continued on the next page

NetEdit Configuration


Using NetEdit is very simple. Once the software has been installed, follow the steps below to configure the settings of your MB-GATEWAY module.

- Start the software. It will scan automatically when you start it but if your MB-GATEWAY is inaccessible at the point of starting the software, you can press the “Scan Network” button at the top to make it scan again once the MB-GATEWAY has become accessible.




NOTE: If you are unable to see the MB-GATEWAY...

- 1) If your PC has more than one NIC (Network Interface Card), e.g. a wireless and a wired, then you may need to either disable the NIC(s) you are not using, or re-prioritize them such that the NIC you are using is top priority.
- 2) Verify the Network Interface on your PC is functioning properly
- 3) Verify all connections between the PC and the MB-GATEWAY are properly made
- 4) Disable your firewall or open TCP port 28787 to allow NetEdit.
- 5) NetEdit version 3.8 or later is required to support MB-GATEWAY.



- In the Main window, double click on the MB-GATEWAY module that you want to configure.



- Select “Use the following IP settings”.
- Type in the settings that are compatible with your network and press the OK button and the MB-GATEWAY module’s IP settings are now configured.

After the MB-GATEWAY module's IP settings have been configured to be compatible with the subnet of your PC, you can open Internet Explorer (or the Web browser of your choice) and continue the configuration for your application. You can also right click on the MB-GATEWAY in the main NetEdit window and choose "Start Web based config..." to start your default Web browser with the correct IP address pre-configured for you.

Function Codes Supported

The function codes supported by the MB-GATEWAY differ based upon whether the target from the Modbus Client is the MB-GATEWAY directly by utilizing the Gateway Modbus ID and the Automatic Read function or direct access to a Modbus serial slave by specifying the Unit ID of the Modbus Slave node itself.

Target = MB-GATEWAY Module (using Gateway Modbus ID and Automatic Read Function):

- Function Code 1 (Read Coils 0xxxxx)
- Function Code 2 (Read Input Bits 1xxxxx)
- Function Code 3 (Read Holding Registers 4xxxxx)
- Function Code 4 (Read Input Registers 3xxxxx)
- Function Code 8 (Read Diagnostics <Read Query Data Function>)

Target = MB-GATEWAY Modbus Slave Node (using Unit ID of Slave Node):

- Any function code supported by the Modbus Slave device

Log Modbus/TCP and/or RTU requests to SMTPViewer

Available in firmware 1.0.679 and later

Using the SMTPViewer (download from HostEng.com and install it in the \HAPTools folder), you can see the TCP and RTU requests that are being processed by the MB-GATEWAY. This logging feature will only send packets to the PC that requested the logging; therefore it is not using broadcast packets, and each Gateway can only log data to 1 PC at a time.

To use logging, connect to MB_GATEWAY with SMTPViewer (UDP only; port 0x7272) and issue the following command:

`'Log [req] [rsp] [rtu] [tcp] [dev #] [raw]'`

req = Log requests
rsp = Log responses
rtu = Log RTU transactions
tcp = Log TCP transactions
raw = Show raw bytes instead of decoding transactions
dev # = Ex 'dev 1' would show only transactions for device 1

For example, to see all Modbus/RTU transactions (requests and responses) to/from device 1 in a decoded form, the command is: `'Log rtu req rsp dev 1'`

The command 'log' by itself defaults to 'log req rsp rtu tcp' which will show all requests and responses for all devices in a decoded form. All forms of the log command toggle from on to off, so you can issue the same command again to turn logging off.

PARAMETERS




CHAPTER 4

In this Chapter...

Home Page	4-2
Gateway Modbus ID	4-3
Module Name and Module Description	4-4
IP Setup Configuration Page.....	4-5
Serial Port Configuration Page	4-6
Set Up Slave Timeout / Retries Page	4-7
Gateway Device Status Page.....	4-8
❶ Automatic Reads.....	4-9
❷ Last Modbus TCP Request	4-9
❸ Last Modbus RTU Request	4-10
❹ Status Information	4-10
Setup Automatic Read Page	4-10
Firmware Updates	4-11

Home Page

The configuration of the MB-GATEWAY is accessed through a web browser at the well-known HTTP port 80 (not configurable). The image below shows the home page that will be displayed when the web server of the MB-GATEWAY module is accessed. From this page, all of the different setup screens can be accessed.




Gateway Modbus ID

The Gateway Modbus ID is used with the Automatic Read function. This is how the local data buffer is accessed by the Modbus Client device. The usage of this field will be explained in more detail in the Automatic Read Function section.



The Modbus ID used in this field should be unique to the serial network and not assigned to any real Modbus RTU device.



The Back, Send and Reset buttons that appear on these pages have the following behavior:


The Back button will browse back to the previous page viewed without saving any changes made on the current page.

The Send button will Send any changes made on this page to the MB-GATEWAY, effectively saving those changes.


The Reset button will undo any changes made on this page, back to the values that have been Sent to the MB-GATEWAY previously.

Module Name and Module Description

These fields are used only for reference and identification when managing several different MB-GATEWAY modules on a network.



The screenshot shows a Windows Internet Explorer browser window titled "Get Module Name - Windows Internet Explorer". The address bar displays "http://192.168.15.47/setname.html". The page content features the heading "Setup Module Name" in a large, bold, serif font. Below the heading is a text input field labeled "Module Name:" containing the text "Modbus Gateway 1". Underneath the input field are three buttons: "Back", "Send", and "Reset". The browser's status bar at the bottom shows "Done" and "Internet".




The screenshot shows a Windows Internet Explorer browser window titled "Get Module Description - Windows Internet Explorer". The address bar displays "http://192.168.15.47/setdesc.html". The page content features the heading "Setup Module Description" in a large, bold, serif font. Below the heading is a text input field labeled "Module Description:" containing the text "Modbus Gateway.". Underneath the input field are three buttons: "Back", "Send", and "Reset". The browser's status bar at the bottom shows "Done" and "Internet".

IP Setup Configuration Page

The IP address, Subnet Mask and Default Gateway address can be configured on this page.



You may lose communications with the MB-GATEWAY module if you configure an IP address and/or Subnet Mask that is not compatible with the subnet of your PC's Network Interface Card. You may be required to change the subnet settings of your PC or use the NetEdit tool to regain communications in this situation.

A screenshot of a web browser window titled "Get IP Configuration - Windows Internet Explorer". The address bar shows "http://192.168.15.47/setup.html". The browser's menu bar includes "File", "Edit", "View", "Favorites", "Tools", and "Help". The page content is titled "Setup IP Configuration" and contains a form with the following fields: "Mode:" with two radio buttons, "IP Address:" with a text box containing "192.168.15.47", "Subnet Mask:" with a text box containing "255.255.0.0", and "Gateway:" with a text box containing "192.168.1.10". Below the form are three buttons: "Back", "Send", and "Reset". The browser's status bar at the bottom shows "Done" and "Internet".

Mode:	<input type="radio"/> Obtain an IP address automatically <input checked="" type="radio"/> Use the following IP address
IP Address:	192.168.15.47
Subnet Mask:	255.255.0.0
Gateway:	192.168.1.10

Back Send Reset

Serial Port Configuration Page

This page is used to configure the serial port parameters if you do not want to use the dipswitch settings or if baud rates different than the dipswitch settings range are desired. The serial port settings should match the settings of the Modbus RTU serial nodes connected to the MB-GATEWAY module. In some situations, such as a high amount of electrical noise, poor cabling, etc., it may be necessary to reduce the baud rate on the MB-GATEWAY module AND serial devices on the network.



In order to use the software based configuration, switches S0, S1, and S2 must be turned OFF.

4

Get Serial Port Setup - Windows Internet Explorer

http://192.168.15.47/SetModSerial.html

File Edit View Favorites Tools Help

Get Serial Port Setup

Serial Port Configuration

Baud Rate:	<input type="radio"/> 115200 <input type="radio"/> 57600 <input checked="" type="radio"/> 38400 <input type="radio"/> 19200 <input type="radio"/> 14400 <input type="radio"/> 9600 <input type="radio"/> 4800 <input type="radio"/> 2400 <input type="radio"/> 1200 <input type="radio"/> 600 <input type="radio"/> 300
Parity:	<input type="radio"/> Even <input checked="" type="radio"/> Odd <input type="radio"/> None
Stop Bits:	<input checked="" type="radio"/> 1 <input type="radio"/> 2

Back Send Reset

Done Internet 100%

Set Up Slave Timeout / Retries Page

The “Set Up Slave Timeout/Retries” page is used to configure the timing on the serial side of the MB-GATEWAY module. By default, all serial requests will use the “Default Timeout” value and “Default Retries” value. If there are devices on the serial network that require different timing adjustments, those exception cases can be added to the table below. Simply specify the node ID, the timing value and retry count necessary for that device.

The way that the timeout and retry field is utilized is:

The MB-GATEWAY will send a request to the serial device, if there is no reply from the device within the Timeout value specified, the MB-GATEWAY will send another request and wait again. It will do this for the number of times specified in the Retry field. Once the MB-GATEWAY has attempted to access the device for the number of retry counts specified and no reply is forthcoming, the MB-GATEWAY will respond with an exception error: 04 (Slave device failure).

The “Inter-packet TX Delay” field specifies how long between serial requests the MB-GATEWAY module should wait. This applies to all serial requests to all serial devices on the serial side of the module.

Setup Timeouts / Retries - Windows Internet Explorer

http://192.168.15.47/settimeouts.html

File Edit View Favorites Tools Help

Setup Timeouts / Retries

Setup Slave Timeout / Retries

Default Timeout (ms): 1000

Default Retries: 2

Inter-packet Tx Delay (ms): 20

Exceptions		
Device	Timeout (ms)	Retries
0	0	0
0	0	0
0	0	0
0	0	0
0	0	0
0	0	0
0	0	0
0	0	0

Back Send Reset

Done

Internet 100%

Gateway Device Status Page

The Gateway Device Status page contains statistical information about the MB-GATEWAY module that can be used to gauge the performance of the communications and to troubleshoot communications.

Gateway Device Status

1 Automatic Reads

Table Item	Error Count	Last Error	Retries	Timeouts	Number Completed
01	0		0	0	0
02	0		0	0	0
03	0		0	0	0
04	0		0	0	0
05	0		0	0	0
06	0		0	0	0
07	0		0	0	0
08	0		0	0	0
09	0		0	0	0
10	0		0	0	0
11	0		0	0	0
12	0		0	0	0
13	0		0	0	0
14	0		0	0	0
15	0		0	0	0
16	0		0	0	0

2 Last Modbus TCP Request

Slave Number	0
Function	
Reference	0
Count	0
Data	
Status	
Return	

3 Last Modbus RTU Request

Slave Number	0
Function	
Reference	0
Count	0
Data	
Status	
Return	

4 Status Information

Status Page Updates	13
Modbus TCP Requests	0
Modbus TCP Cache Hits	0
Modbus RTU Requests	0
Request Errors	0
Last Request Error	
Request Retries	0
Request Timeouts	0

Stop Updates Clear Values Back

1 Automatic Reads

This table shows statistical information about the requests being sent when the Automatic Read function is being utilized. This information can help to indicate whether this table has been configured correctly or not.

Table Item: Corresponds to the position in the table of the “Set Up Automatic Reads” page.

Error Count: Indicates how many error requests have occurred for that table item. This could be a timeout error or an exception response.

Last Error: Indicates the error code from the last error request. If the device fails to respond (Timeout), the error “Slave Device Failure” will be shown in this field.

Retries: Indicates how many retries have occurred. It is a cumulative value and does not reset unless the module has been power cycled or the “Clear Values” button at the bottom has been pressed.

Timeout: Indicates how many times a request has not received a reply within the specified timeout period. It is a cumulative value and does not reset unless the module has been power cycled or the “Clear Values” button at the bottom has been pressed.

Number Completed: Indicates how many requests have been sent for that table item.

2 Last Modbus TCP Request

This table shows statistical information about the last request that was received on the Modbus TCP side from a Modbus TCP Client device.

Slave Number: Indicates the “Unit ID” number within the Modbus TCP header of the Modbus TCP request.

Function: Indicates the Modbus function requested within the Modbus TCP request.

Reference: Indicates the starting address requested within the Modbus TCP request. The “Reference” value is the offset from 0. More information will be explained in the Automatic Read Function section as to how this Reference value corresponds to a Modicon style address that is found in many Modbus devices.

Count: Indicates the number of Registers, Coils or Bits requested within the Modbus TCP request.

Data: This field indicates the Data values written to the MB-GATEWAY module when a Write function has been sent from the Modbus TCP Client device.

Status: Indicates the action taken by the MB-GATEWAY module upon receiving the Modbus TCP Client request.

Found in cache = If the Modbus TCP Client request is targeted to the MB-GATEWAY Module’s Modbus ID and the request corresponds with an address mapped in the Automatic Read Function, the MB-GATEWAY module will respond with the data from its local cache. The MB-GATEWAY module will also return the data from its local cache if the TCP Client request corresponds with a node number and address that has been configured in the Automatic Read function table.

Completed = If the request does not meet the criteria explained above, a serial request is created.

Return: This field will indicate whether an error has occurred or not. If this field displays “No Error”, the request was successful. Otherwise, the Modbus error text will be shown. Refer to the Modbus specifications error code lists for detailed explanations of each error code.

3 Last Modbus RTU Request

This table shows the last Modbus RTU request formed by the MB-GATEWAY module based upon the Modbus TCP Client request received on the Ethernet side.

Slave Number: This is the Node number that was targeted in the last Modbus RTU serial request.

Function: Indicates the Function Code sent to the Modbus serial device in the last request.

Reference: Indicates the starting address requested within the Modbus RTU request. The “Reference” value is the offset from 0. More information will be explained in the Automatic Read Function section as to how this Reference value corresponds to a Modicon style address that is found in many Modbus devices.

Count: Indicates the number of Registers, Coils or Bits requested within the Modbus RTU request.

Data: This field indicates the Data values written to the Modbus RTU device when a Write function has been sent.

Status: Indicates the action taken by the MB-GATEWAY module on the Modbus RTU side.

Waiting for Header = This indicates that the MB-GATEWAY module has sent a request and is waiting for the Reply.

Timeout = If a request was sent to a Modbus RTU device and no reply is received, this message will appear.

Completed = If the request was sent and a reply was received, this message will show in the Status field.

Return: This field will indicate whether an error has occurred or not. If this field displays “No Error”, the request was successful. Otherwise, the Modbus error text will be shown. Refer to the Modbus specifications error code lists for detailed explanations of each error code.

4 Status Information

This table shows a summary of the current session (since power cycle or Clear Values button selected). Comparing Requests to Cache Hits can help indicate whether the Automatic Reads are configured to maximize efficient communications. And total Error, Retry and Timeout data can indicate health of communications.

A CRC error for an Automatic Reads table entry will flash the ERRor LED and set the Last Request Error to: MODBUS_ERROR_MEMORY_PARITY_ERROR.

For a direct request from a Modbus TCP server, a Modbus RTU parity error will return the error MODBUS_ERROR_MEMORY_PARITY_ERROR to the Modbus TCP server.

Setup Automatic Read Page


The Automatic Read Feature is explained in detail in **Chapter 5: Automatic Read Feature**.

Firmware Updates

This link sends you to Host Engineering's website to retrieve the latest firmware for the MB-GATEWAY module. The NetEdit tool is required to upgrade firmware in the MB-GATEWAY module. The steps are shown below:


Open the NetEdit software. You may allow the NetEdit software to download the latest firmware for the MB-GATEWAY module by clicking on File-> Live Update.

Once you have the firmware file to load into the MB-GATEWAY module, click on the Scan Network button at the top left to browse for the MB-GATEWAY module that is in the subnet of the PC.




Click on the GATEWAY module that you wish to upgrade and then select the “General Settings” tab at the bottom of the screen. Click on the “Update Firmware” button in the “General Settings” tab. You will get a dialog box to select the firmware file that you wish to upgrade to. Select the correct file and click on the “Open” button.

Firmware Updates continued on the next page.



Confirm that you wish to perform the upgrade by clicking on the “Yes” button.



Once the process is complete, you will receive a dialog confirming success.

AUTOMATIC READ FEATURE



In this Chapter...

Automatic Read Feature	5-2
Situation 1:.....	5-3
Situation 2:.....	5-6
Additional Optimization.....	5-8
Automatic Read Status Data	5-9

Automatic Read Feature

The Automatic Read Feature allows the MB-GATEWAY module to utilize some of the idle time that usually occurs between Modbus TCP requests from the Client device. Note that this feature only allows the reading of data from the serial devices and not writing to them. Up to 16 automatic read requests can be configured.

Setup Automatic Reads - Windows Internet Explorer

http://192.168.15.47/settable.html

File Edit View Favorites Tools Help

Setup Automatic Reads

Set up Automatic Reads

Gateway Modbus Address = 120

☒ Auto Assign Gateway Addresses

Memory To Read	Slave Number	RTU Start Address	Number of Elements	Gateway Memory Address
2-Discrete Inputs ▼	7	466	1	0
0-Unused Entry ▼	8	455	1	0
0-Unused Entry ▼	0	0	0	0
2-Discrete Inputs ▼	1	21	16	1
3-Holding Regs ▼	1	100	16	0
0-Unused Entry ▼	0	0	0	0
0-Unused Entry ▼	0	0	0	0
0-Unused Entry ▼	0	0	0	0
0-Unused Entry ▼	0	0	0	0
0-Unused Entry ▼	0	0	0	0
0-Unused Entry ▼	0	0	0	0
0-Unused Entry ▼	0	0	0	0
0-Unused Entry ▼	0	0	0	0
0-Unused Entry ▼	0	0	0	0
0-Unused Entry ▼	0	0	0	0
0-Unused Entry ▼	0	0	0	0
0-Unused Entry ▼	0	0	0	0

Status Data (Holding Register) Address: 4001

[show status data format](#)


Back Send Reset

Done Internet 100%


The MB-GATEWAY module can be assigned a Modbus Node address that corresponds with the “Unit ID” number that is sent within the Modbus TCP header that is typically used to target a Modbus RTU node that is on the serial side of the MB-GATEWAY. Therefore, the Node number that is assigned to the MB-GATEWAY module should be unique from any Modbus RTU nodes on the serial network. The Automatic Read function reads the specified registers, bits or coils from the Modbus RTU nodes and places that data into the specified MB-GATEWAY addresses that can be retrieved on the Ethernet side by specifying the MB-GATEWAY’s Modbus address in the Unit ID field of the Modbus TCP client request. An example is shown below:

Situation 1:

Modbus TCP Client device sends a request for a device not configured in the Automatic Read table. This will, in turn, generate a fresh new request on the serial side of the MB-GATEWAY module.




Step 1: Modbus TCP request is generated to Serial Slave Num 5 at Starting Address 10, size 1




5

Step 2: Request is then generated on the Serial side of the MB-GATEWAY.




Step 3: Serial Node replies with data




Step 4: Gateway generates TCP reply and sends back to Client device.

Situation 2:


In this example, the Modbus TCP Client device is sending a request directly to the MB-GATEWAY itself that spans multiple entries in the Automatic Read table.



Step 1: Before a request even comes in on the Ethernet side, the MB-GATEWAY is reading data from the serial slaves at the “Inter-packet TX Delay” rate and placing that data into its local cache.



Step 2: Modbus TCP Request is generated to Serial Slave Num 255 at Starting Address 0, size 2.



Step 3: MB-GATEWAY immediately generates TCP reply and sends back to Client device from local cache without generating a new serial request.

The response time for the TCP request will be significantly faster when the request is targeted at an address in the Automatic Read table. This can be advantageous if the Modbus TCP Client is a device that is busy doing numerous other tasks, such as a PLC.

Additional Optimization

An additional method of optimization is used in the MB-GATEWAY. If a request is sent to the MB-GATEWAY from the Modbus TCP Client targeted at a Node number and starting address that is equivalent to an entry in the Automatic Read table, the MB-GATEWAY will treat the request as if it had been targeted at the MB-GATEWAY Modbus address and will respond from its local data cache since the data is the same.

Shown below are some more detailed explanations of the different fields that can be configured in the Automatic Read Function table.

Memory to Read:

There are 5 options:

- 0 – **Unused Entry** = Disables this entry in the table.
- 1 – **Coils** = Configures this entry to read “Modbus Coils” (Read/Write bits).
- 2 – **Discrete Inputs** = Configures this entry to read “Modbus Input Bits” (Read Only bits).
- 3 – **Holding Regs** = Configures this entry to read “Modbus Holding Registers” (Read/Write 16 bit registers).
- 4 – **Input Regs** = Configures this entry to read “Modbus Input Registers” (Read Only 16 bit registers).

Slave Number:

The network address of the Modbus RTU device to be read on the serial network.

RTU Start Address:

The starting address (based at 0) to be read in the targeted Modbus RTU device on the serial network.

Number of Elements:

The Number of elements to read from the targeted Modbus RTU device on the serial network. If the Read is from Coils or Discrete Inputs, the number specified will be the number of bits from 1 - 2000. If the Read is from Holding or Input Registers, the number specified will be the number of words (16 bit) from 1 - 125.

Gateway Memory Address:

The starting address in the GATEWAY module’s local data cache to place the data that has been read from the Modbus RTU device on the serial network.

Gateway Modbus Address:

Displays the Modbus address that the GATEWAY module has been configured for (done in the “Gateway Modbus ID” section of the home page).

Auto Assign Gateway Addresses:

Selecting this option will allow the configuration software to automatically choose the best local addresses to place the data that has been read from the Modbus RTU devices.

When the Auto Assign Gateway Addresses option is NOT selected, care must be taken so the data from different Automatic Reads doesn’t overlap in the Gateway’s internal memory. If you specify an Automatic Read that will create overlapping data, the value in the Gateway Memory Address field for that Read will be red.

By default the Gateway will store the data from the individual automatic reads for the same memory types in consecutive locations in the Gateway’s internal memory. Storing this data in consecutive data locations in the Gateway’s internal memory allows reads to be optimized into as few requests as possible.

There are several different ways of addressing when communicating to Modbus devices. The method of specifying a Function Code and offset that is utilized in the Automatic Read function is a very common way. Another way that is very common and is seen often in AutomationDirect products is the use of the Modicon style addressing. This method employs a PLC style address that contains a Modbus memory type in the highest digit of the address followed by the offset from 1. A table is provided below that shows comparable addresses for both of these addressing styles.

*Modbus Function Type		Address Range	Equivalent Modicon Style Addressing	Number of Elements
1.	Coils	0 - 65535	00001 - 065536	1 - 2000
2.	Discrete Inputs	0 - 65535	100001 - 165536	1 - 2000
3.	Holding Regs	0 - 65535	400001 - 465536	1 - 125
4.	Input Regs	0 - 65535	300001 - 365536	1 - 125

** NOTE: "Memory to Read" column on Setup Automatic Reads web page*

Automatic Read Status Data

Available in firmware 1.0.679 and later

The final selection on this page is the Status Data (Holding Register) Address which allows the user to map a data area into the Gateway's Modbus Holding Register memory which will report the health of each of the automatic read operations. These 17 consecutive Holding Registers area can then be read from the Modbus Gateway (using the Gateway Modbus Address as Unit ID in the MRX instruction) to monitor the Automatic reads by the Modbus/TCP Client.

Status Data (Holding Register) Address: 4000

[show status data format](#)

Back

Send

Reset

Click the "show status data format" link to display a page that explains the layout of the data. The first register contains 1 Bit for each of the possible 16 Automatic Reads. Bit 0 = 1st Automatic Read Operation, Bit 1 = 2nd Automatic Read Operation, ... Bit 15 = 16th Automatic Read Operation.

A value of 1 in a Bit location means the last Automatic Read operation that corresponds to that Bit worked and the resulting data is valid.

A Value of 0 in a Bit location means the last Automatic Read operation that corresponds to that Bit DID NOT work, and the Error Count for that Read Operation was incremented.

For example, if the Status Data Address is set to 4000, the data layout will be:

Holding Register	Description	
4000	Bit 0	If set, 1st auto read entry is valid and communicating.
	Bit 1	If set, 2nd auto read entry is valid and communicating.

	Bit 15	If set, 16th auto read entry is valid and communicating.
4001	Error count for 1st auto read entry	
4002	Error count for 2nd auto read entry	
...	...	
4016	Error count for 16th auto read entry	

APPLICATION EXAMPLES



In this Appendix...

Example 1: Using Modbus Poll to MB-GATEWAY with DL06 Slave.....	A-2
Items needed for this example:	A-2
Step 1: Connect the MB-GATEWAY serial port to the DL06 secondary communications port.	A-2
Step 2: Configure the DL06 PLC serial port and MB-GATEWAY serial port.	A-3
Step 3: Connect to the MB-GATEWAY using the Modbus Poll simulator software.	A-7
Example 2: Using Modbus Poll to MB-GATEWAY with CLICK Slave	A-11
Items needed for this example:	A-11
Step 1: Connect the MB-GATEWAY serial port to Port 3 of the CLICK PLC.....	A-11
Step 2: Configure the CLICK serial port and MB-GATEWAY serial port.	A-12
Step 3: Connect to the MB-GATEWAY using the Modbus Poll simulator software.	A-18
Example 3: Using P3000 as Master (Client) to MB-GATEWAY with CLICK Slave. ...	A-24
Step 1: Connect CLICK to the MB-GATEWAY as shown in example 2.	A-24
Step 2: Connect P3000 CPU (P3-550) to MB-GATEWAY via Ethernet Switch and Two Ethernet Cables.	A-24
Step 3: Configure the MRX instruction to read data from the MB-GATEWAY.	A-28
Example 4: DirectLogic 06 (H0-ECOM100) as Master (Client) to MB-GATEWAY with Multiple GS Drives as Slaves.	A-29
Step 1: Set up Peer to Peer Configuration	A-30
Step 2: Set the Serial Port Configuration	A-31
Step 3: Set the Communication Parameters	A-31
Step 4: Using Automatic Reads.....	A-32
Step 5: Access the Automatic Read Data	A-33
Step 6: Read and Write from the DL06	A-36

Example 1:

Using Modbus Poll to MB-GATEWAY with DL06 Slave


This example will illustrate how to use Modbus Poll, which is a PC based Modbus Master simulator tool, to connect through the MB-GATEWAY to a DL06 PLC via 2 wire RS-485.

Items needed for this example:

- MB-GATEWAY
- DirectLogic 06 PLC (any model)
- PC with Modbus Poll installed (free demo is available at www.modbustools.com)
- Small length of Belden 9842 or equivalent cable
- ZL-CMA15 ZipLink communication port adapter, 15-pin high density female to terminal block
- Ethernet switch and cables to connect from the PC to MB-GATEWAY


Step 1: Connect the MB-GATEWAY serial port to the DL06 secondary communications port.

Using the short length of Belden 9842, connect the MB-GATEWAY to the DL06 Port 2 as shown:



Step 2: Configure the DL06 PLC serial port and MB-GATEWAY serial port.

Connect to the DL06 PLC with DirectSoft. Go to the PLC pulldown and select Setup > Setup Secondary Comm. Port as shown:



Setup the port as shown for Modbus protocol, 38400 baud rate, Odd parity, 1 Stop bit and Station Number 1. Match everything else as shown. Note the Station Number configured in the PLC. Once this has been done, click on the icon on the upper right hand side with the arrow pointing to the PLC to save the settings in the PLC.

Setup Communication Ports

Port: Port 2

Protocol: ☐ K-Sequence ☐ DirectNET ☒ MODBUS ☐ Non-Seq(ASCII) ☐ Remote I/O

Base Timeout: 800 ms

Time-out: Base Timeout x 1

RTS on delay time: 0 ms

RTS off delay time: 0 ms

Station Number: 1

Baud rate: 38400

Stop bits: 1


Parity: Odd

Echo Suppression: ☐ RS-422/485 (4-wire) ☐ RS-232C (2-wire) ☒ RS-485 (2-wire)

Port 2: 15 Pin

In order to match the serial port settings of the DL06 to the MB-GATEWAY open up a web browser, such as Internet Explorer, and enter in the IP address of the MB-GATEWAY to access the main screen as shown:

A



For instructions on connecting with a web browser see NetEdit Configuration section in Chapter 3.

Click on the link to the right of “Serial Port Configuration” and set up the window to match the DL06 PLC port and then click on the Send button to save the settings:

A

The screenshot shows a Windows Internet Explorer window titled "Get Serial Port Setup - Windows Internet Explorer". The address bar displays "http://192.168.15.47/SetModSerial.html". The page content is titled "Serial Port Configuration". Below the title, there is a form with the following fields:


Baud Rate:	<input type="radio"/> 115200 <input type="radio"/> 57600 <input checked="" type="radio"/> 38400 <input type="radio"/> 19200 <input type="radio"/> 14400 <input type="radio"/> 9600 <input type="radio"/> 4800 <input type="radio"/> 2400 <input type="radio"/> 1200
Parity:	<input type="radio"/> Even <input checked="" type="radio"/> Odd <input type="radio"/> None
Stop Bits:	<input checked="" type="radio"/> 1 <input type="radio"/> 2

Below the form, there are three buttons: "Back", "Send", and "Reset". The status bar at the bottom of the browser window shows "Done" and "Internet".

Step 3: Connect to the MB-GATEWAY using the Modbus Poll simulator software.


Once the software has been obtained from www.modbustools.com and installed according to the directions provided from their website, open up the Modbus Poll software.

Click on the Setup pulldown menu and select Read/Write Definition as shown:



Configure the Read/Write definition for a simple read of the register 400001, which equates to V0 in the DirectLogic PLCs.
(see http://support.automationdirect.com/docs/Modbus_xref.pdf for more information on Modbus addressing to DirectLogic PLC addressing equivalents).

A



The 'Read/Write Definition' dialog box is shown with the following settings:

- Slave ID: 1
- Function: 03 Read Holding Registers (4x)
- Address: 1
- Quantity: 1
- Scan Rate: 1000 ms
- Buttons: OK, Cancel, Apply
- Disable section:
 - ☒ Read/Write Disabled
 - ☐ Disable on error
- View section:
 - Rows: 10 (selected), 20, 50, 100
 - Hide Alias Columns: ☐
 - Address in Cell: ☐
 - PLC Addresses (Base 1): ☒
- Display: Signed




Enter in 1 for the Slave ID. This matches the Unit ID in the protocol that will determine which Modbus Serial Slave will be targeted on the serial side of the MB-GATEWAY. Entering 1 here will match up to the Station Number configured above in DirectSoft for the DL06 PLC.



Choosing Function 3 sets up the read for 4xxxx registers. Checking the "PLC Addresses (Base 1)" in the lower right corner matches the addressing to the cross reference chart mentioned above. Once this windows has been configured as shown above, click on OK.

Now click on the Connection pulldown menu and select Connect:



The 'Modbus Poll - Mbpoll1' window is shown with the 'Connection' menu open. The menu options are: Connect... (F3), Disconnect (F4), Auto Connect, and Quick Connect (F5). The status bar at the bottom shows 'Port 1: 9600-8-E-1'.

	Alias	4x0000
1		0
2		
3		
4		
5		
6		
7		
8		
9		
10		

In the Connection Setup window, choose the Modbus TCP/IP connection type. Enter the IP address of your MB-GATEWAY module in the lower left hand corner. Match everything else as shown:

The Connection Setup dialog box is shown with the following settings:

- Connection:** Modbus TCP/IP
- Serial Settings:**
 - Communications Port (COM1)
 - 9600 Baud
 - 8 Data bits
 - Even Parity
 - 1 Stop Bit
- Mode:** RTU (selected), ASCII
- Response Timeout:** 1000 [ms]
- Delay Between Polls:** 10 [ms]
- Remote Server:**
 - IP Address: 192.168.15.47
 - Port: 502
 - Connect Timeout: 3000 [ms]

Click on OK to connect to the MB-GATEWAY.

If everything has been configured correctly, the counter next to “TX =” will increment rapidly and the counter next to “Err =” will not increment. If the Error counter is incrementing, go back and verify that all the steps prior to this one have been followed. If you get an error that says, “Modbus TCP connection failed”, verify that the IP address of the PC and the IP address of the GATEWAY are in compatible subnets and can communicate.


The Modbus Poll - Mbpoll1 window shows the following status and data:

Status: Tx = 60: Err = 0: ID = 1: F = 03: SR = 100ms

	Alias	4x0000
1		0
2		
3		
4		
5		
6		
7		
8		
9		
10		

For Help, press F1. 192.168.15.47: 502

Once Modbus Poll is communicating to the PLC, go into DirectSoft, open up a Data View window and enter in V0 and change the display type to “Decimal” to match the Modbus Poll software:



Change the value in data view for V0 to various values and watch the value change in Modbus Poll to match.

Example 2:

Using Modbus Poll to MB-GATEWAY with CLICK Slave


This example will illustrate how to use Modbus Poll, which is a PC based Modbus Master simulator tool, to connect through the MB-GATEWAY to a CLICK PLC via 2 wire RS-485.

Items needed for this example:

- MB-GATEWAY
- CLICK PLC (any C0-01xx-x or C0-02xx-x PLC with 3 pin terminal RS-485 port)
- PC with Modbus Poll installed (free demo is available at www.modbustools.com)
- Small length of Belden 9842 or equivalent cable
- Ethernet switch and cables to connect from the PC to MB-GATEWAY


Step 1: Connect the MB-GATEWAY serial port to Port 3 of the CLICK PLC.

Using the short length of Belden 9842, connect the MB-GATEWAY to CLICK's Port 3 as shown:




Step 2: Configure the CLICK serial port and MB-GATEWAY serial port.


Connect to the CLICK PLC with CLICK programming software. Go to the Setup pulldown and select Com Port Setup... as shown:




Click the Port 3: Setup... button to configure Port 3 of the PLC.




Configure the port for 38400 baud rate, Odd parity, 1 Stop Bit and Node Address 1. Leave the other settings as shown below. Note the Node Address number configured here. Once the settings are configured, Click on the Ok button.



Next, transfer the project to the PLC for the Port 3 settings to take effect. Select the PLC pulldown menu and choose Write Project into PLC...




Choose Ok and follow the steps when prompted to transfer the project to the PLC.



Now go into the MB-GATEWAY configuration and match the serial port settings to the PLC Port 3 settings.

Open up a web browser, such as Internet Explorer, and enter in the IP address of the MB-GATEWAY to access the main screen as shown.

A



Click on the link to the right of “Serial Port Configuration” and set up the window to match the CLICK PLC port and then click on the Send button to save the settings:

A

The screenshot shows a Windows Internet Explorer window titled "Get Serial Port Setup - Windows Internet Explorer". The address bar displays "http://192.168.15.47/SetModSerial.html". The page content is titled "Serial Port Configuration". Below the title, there is a form with three sections: "Baud Rate:" with radio buttons for 115200, 57600, 38400 (selected), 19200, 14400, 9600, 4800, 2400, and 1200; "Parity:" with radio buttons for Even, Odd (selected), and None; and "Stop Bits:" with radio buttons for 1 (selected) and 2. Below the form are three buttons: "Back", "Send", and "Reset". The status bar at the bottom shows "Done" and "Internet".

Get Serial Port Setup - Windows Internet Explorer

http://192.168.15.47/SetModSerial.html

File Edit View Favorites Tools Help

Get Serial Port Setup

Serial Port Configuration

Baud Rate: ☐ 115200 ☐ 57600 ☒ 38400 ☐ 19200 ☐ 14400 ☐ 9600 ☐ 4800 ☐ 2400 ☐ 1200
☐ 600 ☐ 300

Parity: ☐ Even ☒ Odd ☐ None

Stop Bits: ☒ 1 ☐ 2


Back Send Reset

Done Internet 100%


Step 3: Connect to the MB-GATEWAY using the Modbus Poll simulator software.

Once the software has been obtained from www.modbustools.com and installed according to the directions provided from their website, open up the Modbus Poll software.

Click on the Setup pulldown menu and select Read/Write Definition as shown:



Configure the Read/Write definition for a simple read of the register 400001, which equates to DS1 in the CLICK PLC as shown.



Address Picker : Edit Mode

Fill Down (Nickname) Find: ☒ Exact Match

	Address	Data Type	MODBUS Address (Function code)	Nickname	Used	Initial Value	Retentive	Address Comment
All	D51	INT	400001 (03,06,16)		No	Disable	Yes	
X	D52	INT	400002 (03,06,16)		No	Disable	Yes	
Y	D53	INT	400003 (03,06,16)		No	Disable	Yes	
C	D54	INT	400004 (03,06,16)		No	Disable	Yes	
T	D55	INT	400005 (03,06,16)		No	Disable	Yes	
CT	D56	INT	400006 (03,06,16)		No	Disable	Yes	
SC	D57	INT	400007 (03,06,16)		No	Disable	Yes	
	D58	INT	400008 (03,06,16)		No	Disable	Yes	
	D59	INT	400009 (03,06,16)		No	Disable	Yes	
DS	D510	INT	400010 (03,06,16)		No	Disable	Yes	
DD	D511	INT	400011 (03,06,16)		No	Disable	Yes	
DH	D512	INT	400012 (03,06,16)		No	Disable	Yes	
DF	D513	INT	400013 (03,06,16)		No	Disable	Yes	
	D514	INT	400014 (03,06,16)		No	Disable	Yes	
XD	D515	INT	400015 (03,06,16)		No	Disable	Yes	
YD	D516	INT	400016 (03,06,16)		No	Disable	Yes	
TD	D517	INT	400017 (03,06,16)		No	Disable	Yes	
CTD	D518	INT	400018 (03,06,16)		No	Disable	Yes	
SD	D519	INT	400019 (03,06,16)		No	Disable	Yes	
	D520	INT	400020 (03,06,16)		No	Disable	Yes	
TXT	D521	INT	400021 (03,06,16)		No	Disable	Yes	

Data Type Filter

☒ Display All Data Types

☒ Integer ☒ Integer (2Words)

☒ HEX ☒ Floating Point

☒ Bit ☒ Text

Used/Unused Address

☒ Display both used and unused

☐ Display only used

☐ Display only unused

☒ Display MODBUS Address

☒ MODBUS 984 Addressing

☐ MODBUS HEX Addressing



Enter in 1 for the Slave ID. This matches the Unit ID in the protocol that will determine which Modbus Serial Slave will be targeted on the serial side of the MB-GATEWAY. Entering 1 here will match up to the Node Address configured above in the CLICK programming software for Port 3.

A

The 'Read/Write Definition' dialog box is shown with the following settings:

- Slave ID: 1
- Function: 03 Read Holding Registers (4x)
- Address: 1
- Quantity: 1
- Scan Rate: 1000 ms
- Read/Write Once: (button)
- Disable section:
 - ☒ Read/Write Disabled
 - ☐ Disable on error
- View section:
 - Rows: 10 (selected), 20, 50, 100
 - Hide Alias Columns: ☐
 - Address in Cell: ☐
 - Display: Signed
 - PLC Addresses (Base 1): ☒



Enter in 1 for the Slave ID. This matches the Unit ID in the protocol that will determine which Modbus Serial Slave will be targeted on the serial side of the MB-GATEWAY. Entering 1 here will match up to the Station Number configured above in the CLICK software.



Choosing Function 3 sets up the read for 4xxxx registers. Checking the "PLC Addresses (Base 1)" in the lower right corner matches the addressing to the cross reference chart mentioned above. Once this window has been configured as shown above, click on OK.

Now click on the Connection pulldown menu and select Connect:

The screenshot shows the 'Modbus Poll - Mbpoll1' application window. The 'Connection' menu is open, showing options: 'Connect...' (F3), 'Disconnect' (F4), 'Auto Connect', and 'Quick Connect' (F5). The status bar at the bottom indicates 'Port 1: 9600-8-E-1'. The main display area shows 'No Connection' and a table with columns 'Alias' and '4x0000'.

	Alias	4x0000
1		0
2		
3		
4		
5		
6		
7		
8		
9		
10		

In the Connection Setup window, choose the Modbus TCP/IP connection type. Enter the IP address of your MB-GATEWAY module in the lower left hand corner. Match everything else as shown:

The Connection Setup dialog box is shown with the following settings:

- Connection:** Modbus TCP/IP
- Serial Settings:**
 - Communications Port (COM1)
 - 9600 Baud
 - 8 Data bits
 - Even Parity
 - 1 Stop Bit
- Mode:** RTU (selected), ASCII
- Response Timeout:** 1000 [ms]
- Delay Between Polls:** 10 [ms]
- Remote Server:**
 - IP Address: 192.168.15.47
 - Port: 502
 - Connect Timeout: 3000 [ms]

Click on OK to connect to the MB-GATEWAY.

If everything has been configured correctly, the counter next to “TX =” will increment rapidly and the counter next to “Err =” will not increment. If the Error counter is incrementing, go back and verify that all the steps prior to this one have been followed. If you get an error that says, “Modbus TCP connection failed”, verify that the IP address of the PC and the IP address of the GATEWAY are in compatible subnets and can communicate.


The Modbus Poll - Mbpoll1 window shows the following status and data:

Tx = 60: Err = 0: ID = 1: F = 03: SR = 100ms

	Alias	4x0000
1		0
2		
3		
4		
5		
6		
7		
8		
9		
10		

For Help, press F1. 192.168.15.47: 502

Once Modbus Poll is communicating to the PLC, go into the CLICK programming software, open up a Data View window and enter in DS1 as shown.



Change the value in data view for DS1 to various values and watch the value change in Modbus Poll to match.


Example 3: Using P3000 as Master (Client) to MB-GATEWAY with CLICK Slave.

Step 1: Connect CLICK to the MB-GATEWAY as shown in example 2.


Step 2: Connect P3000 CPU (P3-550) to MB-GATEWAY via Ethernet Switch and Two Ethernet Cables.

Configure the IP address of the P3 CPU and the MB-GATEWAY to be compatible subnets. Steps to configure the IP address of the P3-550 CPU areas follows:

Click on Setup on the top menu bar and choose “Hardware Configuration”.




Double click on the image of the P3-550 in the center of the hardware configuration.



A

Click on the “Ethernet Ports” tab and configure the IP address in the “Use the Following:” IP address field. Once the correct IP address and Subnet Mask is entered, click on the OK button and close the hardware configuration window.



The screenshot shows the 'P3-550' hardware configuration window with the 'Ethernet Ports' tab selected. On the left is a vertical image of the P3-550 CPU module. The main area contains two sections: 'External Ethernet Port' and 'Local Ethernet Port'.

External Ethernet Port


- Port Name: CPU-ETH-Ext
- Port Security Option: ☐ Read Only, ☒ Read/Write
- TCP/IP Settings:
 - ☐ Use current settings (with 'Show Current Settings' button)
 - ☐ Use DHCP
 - ☒ Use the following:
 - IP Address: 192.168.15.53
 - Subnet Mask: 255.255.0.0
 - Default Gateway: 0.0.0.0
- Timeout between data query and response (100-30,000 msec): 5 x100 msec
- Modbus TCP Port (1-65535): 502
- Comm Heartbeat Value (2-1,000 sec): [] sec

Local Ethernet Port

- Timeout between data query and response (20-20,000 msec): 100 x10 msec
- Comm Heartbeat Value (200-10,000 msec): 20 x100 msec

At the bottom, there is a 'Module Info' button on the left and 'OK', 'Cancel', and 'Help' buttons on the right.

Transfer the project to the PAC in order to have the new settings take effect. To do this, select File from the pulldown menu and then Transfer Project >To PAC...



Step 3: Configure the MRX instruction to read data from the MB-GATEWAY.

Double click on the instruction MRX Read to configure the MRX instruction as shown.

IP Address: address of the GATEWAY.

TCP Port Number: Leave at default 502.

Slave Node Number: This should match the Node address of Port 3 of the CLICK PLC.
Leave at 1 in this case.


Slave Modbus Starting Address: Set to 1 to read address DS1 in the CLICK PLC.

Tag Name Mapping: Create a Tag called CLICK_DS1 as an Signed Int 16 Tag to read in DS1 from the CLICK PLC.

Use the status bits and Exception Response String to verify whether communications were successful or not. If the Error bit comes on, look at the Exception Response String to see which error occurred. If the Timeout Bit comes on, check the IP address settings of the P3-550 and the GATEWAY and make sure that they are in compatible subnets.

If the Successful Status bit comes on, add the CLICK_DS1 tag to the Data View at the bottom of the Productivity Suite Programming Software and check the values. Change the values in the CLICK data view for DS1 and verify that the CLICK_DS1 tag matches.

Example 4: DirectLogic 06 (H0-ECOM100) as Master (Client) to MB-GATEWAY with Multiple GS Drives as Slaves.



Step 1: Set up Peer to Peer Configuration

In NetEdit, Scan Network to find your H0-ECOM100.

Set the Module ID, IP address and Subnet Mask as appropriate for your network. In our example, we use 7, 10.11.0.221 and 255.255.255.0 respectively.

The screenshot shows the 'General Settings' dialog box for the H0-ECOM100 module. The dialog has a blue title bar with the text 'General Settings' and a red 'X' icon in the top right corner. The main area has a light beige background. On the left, there are three labels: 'Module ID:', 'Name:', and 'Description:'. The 'Module ID' field contains the number '7'. The 'Name' field contains 'H0-ECOM100'. The 'Description' field contains 'H0-ECOM100 Ethernet Communications Module'. On the right, there are two radio buttons. The first is 'Obtain an IP address automatically' and is unselected. The second is 'Use the following IP settings' and is selected. Below these radio buttons are three input fields: 'IP Address:' containing '10 . 11 . 0 . 221', 'Subnet mask:' containing '255 . 255 . 255 . 0', and 'Gateway:' containing '0 . 0 . 0 . 0'. At the bottom, there are two buttons: 'OK' and 'Cancel'.

General Settings

Module ID: 7

Name: H0-ECOM100

Description: H0-ECOM100 Ethernet Communications Module

☐ Obtain an IP address automatically
☒ Use the following IP settings

IP Address: 10 . 11 . 0 . 221

Subnet mask: 255 . 255 . 255 . 0

Gateway: 0 . 0 . 0 . 0

OK Cancel

In the ECOM Settings tab, click the Peer to Peer Config button. Add the Devices appropriate for your project.

The screenshot shows a software window titled "Peer to Peer Configuration". It features a table with three columns: "Device", "Protocol", and "Configuration". The table contains three rows of data:

Device	Protocol	Configuration
1	Modbus/TCP	IP = 10.11.0.233, Port = 502, Unit ID = 1
2	Modbus/TCP	IP = 10.11.0.233, Port = 502, Unit ID = 2
3	Modbus/TCP	IP = 10.11.0.233, Port = 502, Unit ID = 3

To the right of the table are five buttons: "Add...", "Edit...", "Delete", "Delete All", and "OK". At the bottom right is a "Cancel" button.

In our example we have added three devices that are the MB-GATEWAY:

Device 1 is the Automatic Reads table that resides in the MB-GATEWAY, so it is configured with the MB-GATEWAY IP address and the MB-GAEWAY Unit ID.

Device 2 is the first drive. It is configured with the MB-GATEWAY IP address and the first drive Unit ID.

Device 3 is the second drive. It is configured with the MB-GATEWAY IP address and the second drive Unit ID.

Step 2: Set the Serial Port Configuration

In the NetEdit Module List, select your MB-GATEWAY. Set the IP address and subnet mask as appropriate for your network. In our example, we use 10.11.0.233 and 255.255.255.0.

Click Start Web Based Config... To set the Gateway Modbus ID as appropriate for your network. In our example, we use 1.

Set the Serial Port Configuration as appropriate for your network. For our example, we use:

Baud rate = 19200

Parity = Odd

Stop bit = 1

Step 3: Set the Communication Parameters

Set the communication parameters in the drives as appropriate for your network.

In our example:

Parameter Number	Parameter Description	First Drive	Second Drive
P9.00	Drive ID	02	03
P9.01	Baud Rate	02	02
P9.02	Modbus RTU, 8-Odd-1	05	05
P3.00	RS-485 interface, Keypad STOP disabled	04	04
P4.00	Frequency determined by RS-485 interface	05	05

Step 4: Using Automatic Reads

In the MB-GATEWAY browser configuration utility, click the Automatic Reads link. Slave number 2 is the first drive and Slave number 3 is the second drive in our example. Configure the lines as appropriate.

For our example, we will read the status registers for each drive:

Setup Automatic Reads - Windows Internet Explorer

http://10.11.0.233/settable.html

File Edit View Favorites Tools Help

Setup Automatic Reads

Setup Automatic Reads

Gateway Modbus Address = 1

☒ Auto Assign Gateway Addresses


Memory To Read	Slave Number	RTU Start Address	Number of Elements	Gateway Memory Address
3-Holding Regs	2	8448	4	0
3-Holding Regs	3	8448	6	4
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0

Back Send Reset


Done Internet 100%

Step 5: Access the Automatic Read Data

The ECRX iBox is used since the data will be read by the ECOM100, rather than a serial connection



ECOM100 RX Network Read	
ECRX	IB-740
ECOM100 #	K7
Workspace	V503
Slave ID	K2
From Slave Element (Src)	V20400
Number Of Bytes	K6
To Master Element (Dest)	V2000
Success	C100
Error	C101



ECOM100# = defined for this DL program in the ECOM100 iBox in our Rung 1

Workspace = an internal, private register used by this iBox and MUST BE UNIQUE in this one instruction and MUST NOT be used anywhere else in your program.

Slave ID = The MB-GATEWAY Modbus Gateway ID, 1, since we are reading the Automatic Read data stored in the MB-GATEWAY

From Slave Element (Src) = the Gateway Memory Address identified on the MB-GATEWAY Setup Automatic Reads config page. Note that the address in the MB-GATEWAY, “0” should be entered here as “V0” and DirectSoft software will change the name to TA0. This is a naming convention for addresses internal to the PLC and will not

affect either the targeted address or the use of Timer 0 in the DL program.

Number of Bytes = 20. Since our addresses for both example drives are contiguous, we can read all 10 elements with one iBox. Each element is a word, 2 bytes, so we want to read 20 bytes to get all 10 elements.


To Master Element (Dest) = the location where the slave data will be placed in the master ECOM100 PLC

Success = a bit that will turn on once the request is completed successfully


Error = a bit that will turn on if the instruction is not successfully completed

Step 6: Read and Write from the DL06

To Read data from a drive instead of using of the Automatic Read feature of the MB-GATEWAY, and to Write data to the drive, the Slave ID in the ECRX and/or ECWX iBoxes will be the Drive ID. The From Slave Element and/or To Slave Element values will be the addresses in the drive



continued



ECOM100 RX Network Read	
ECRX	IB-740
ECOM100 #	K7
Workspace	V503
Slave ID	K2
From Slave Element (Src)	V20400
Number Of Bytes	K6
To Master Element (Dest)	V2000
Success	C100
Error	C101

In our example ECRX boxes:

ECOM100# = defined for this DL program in the ECOM100 iBox in our Rung 1.

Workspace = an internal, private register used by this iBox and MUST BE UNIQUE in this one instruction and MUST NOT be used anywhere else in your program.

Slave ID = The GS Drive Node ID, 2 or 3, depending on which drive we target

From Slave Element (Src) = V20400 equates to Status Monitor 1 in the GS Drive (Hex 2100 and Modbus Decimal 48449). See GS Drive manual for details.

Number of Bytes = Each Modbus register (element) that we want to read is a word, 2 bytes; in our example we will read 3 status registers.

To Master Element (Dest) = the location where the slave data will be placed in the master ECOM100 PLC

Success = a bit that will turn on once the request is completed successfully

Error = a bit that will turn on if the instruction is not successfully completed

ECOM100 VXX Network Write	
ECWX	IB-741
ECOM100 #	K7
Workspace	V504
Slave ID	K2
From Master Element (Src)	V2100
Number Of Bytes	K4
To Slave Element (Dest)	V4432
Success	C102
Error	C103

In our example ECWX boxes:

ECOM100# = Module ID, set in NetEdit and defined for the DL program in the ECOM100 iBox in our Rung 1

Workspace = an internal, private register used by this iBox and MUST BE UNIQUE in this one instruction and MUST NOT be used anywhere else in your program.

Slave ID = The GS Drive Node ID, 2 or 3, depending on which drive we target

From Master Element (Src) = the location of data in the Master PLC that will be written to the drive

Number of Bytes = 4. In our example, we will write the speed (2 bytes) to the Comm Speed Reference register and set the next register to RUN (2 bytes)

To Slave Element (Dest) = the Modbus register where the data will be written in the drive. In this case, V4432 equates to P9.26 Comm Speed Reference. See GS Drive manual for more details.

Success = a bit that will turn on once the instruction is completed successfully

Error = a bit that will turn on if the instruction is not successfully completed

MODBUS ERROR CODES



In this Appendix...

Modbus Error Codes.....	B-2
-------------------------	-----

Modbus Error Codes

MB-GATEWAY Modbus Error Codes		
Error Code	Name	Explanation
01	ILLEGAL FUNCTION	The function code received in the query is not an allowable action for the slave. If a Poll Program Complete command was issued, this code indicates that no program function preceded it.
02	ILLEGAL DATA ADDRESS	The data address received in the query is not an allowable address for the slave.
03	ILLEGAL DATA VALUE	A value contained in the query data field is not an allowable value for the slave.
04	SLAVE DEVICE FAILURE	An unrecoverable error occurred while the slave was attempting to perform the requested action.
05	ACKNOWLEDGE	The slave has accepted the request and is processing it, but a long duration of time will be required to do so. This response is returned to prevent a timeout error from occurring in the master. The master can next issue a Poll Program Complete message to determine if processing is completed.
06	SLAVE DEVICE BUSY	The slave is engaged in processing a long-duration program command. The master should retransmit the message later when the slave is free.
07	NEGATIVE ACKNOWLEDGE	The slave cannot perform the program function received in the query. This code is returned for an unsuccessful programming request using function code 13 or 14 decimal. The master should request diagnostic or error information from the slave.
08	MEMORY PARITY ERROR	The slave attempted to read extended memory, but detected a parity error in the memory. The master can retry the request, but service may be required on the slave device.

B

SECURITY CONSIDERATIONS FOR CONTROL SYSTEMS NETWORKS



In this Appendix...

Security Considerations for Control Systems Networks..... C-2

Security Considerations for Control Systems Networks

Manufacturers are realizing that to stay competitive, their Automation and Control Systems need to be more integrated within their plant. The systems often need to be integrated with upstream Enterprise Data Systems, and even further integrated to allow information to be accessible across multiple plants, or even through the Internet. This convergence of the IT world with the Automation World creates challenges in maintaining secure systems and protecting your investments in processes, personnel, data and intellectual property.

While Automation Networks and Systems have built-in password protection schemes, this is only one very small step in securing your systems. Automation Control System Networks need to incorporate data protection and security measures that are at least as robust as a typical business computer system. We recommend that users of PLCs, HMI products and SCADA systems perform your own network security analysis to determine the proper level of security required for your application. However, the Department of Homeland Security's National Cybersecurity and Communications Integration Center (NCCIC) and Industrial Control Systems Cyber Emergency Response Team (ICS-CERT) has provided direction related to network security and safety under an approach described as "Defense in Depth", which is published at [https://www.us-cert.gov/sites/default/files/recommended_practices/NCCIC ICS-CERT Defense in Depth 2016 S508C.pdf](https://www.us-cert.gov/sites/default/files/recommended_practices/NCCIC%20ICS-CERT%20Defense%20in%20Depth%202016%20S508C.pdf).

This comprehensive security strategy involves physical protection methods, as well as process and policy methods. This approach creates multiple layers and levels of security for industrial automation systems. Such safeguards include the location of control system networks behind firewalls, their isolation from business networks, the use of intrusion detection systems, and the use of secure methods for remote access such as Virtual Private Networks (VPNs). Further, users should minimize network exposure for all control system devices and such control systems and these systems should not directly face the internet. Following these procedures should significantly reduce your risks both from external sources as well as internal sources, and provide a more secure system.

It is the user's responsibility to protect such systems, just as you would protect your computer and business systems. AutomationDirect recommends using one or more of these resources in putting together a secure system:

- ICS-CERT's Control Systems recommended practices at the following web address:
<https://ics-cert.us-cert.gov/Recommended-Practices>
- Special Publication 800-82 of the National Institute of Standards and Technology – Guide to Industrial Control Systems (ICS) Security
<https://csrc.nist.gov/publications/detail/sp/800-82/rev-2/final>
- ISA99, Industrial Automation and Control Systems Security
<http://www.isa.org/MSTemplate.cfm?MicrositeID=988&CommitteeID=6821>
(please note this is a summary and these standards have to be purchased from ISA)

The above set of resources provides a comprehensive approach to securing a control system network and reducing risk and exposure from security breaches. Given the nature of any system that accesses the internet, it is incumbent upon each user to assess the needs and requirements of Security Considerations for Control Systems Networks their application, and take steps to mitigate the particular security risks inherent in their control system.

INDEX



A

Additional Optimization, 5–8

Agency Approvals, 1–7

Automatic Read Feature, 5–2

for a device not configured in the Automatic Read table, 5–3

for a device within the Automatic Read table, 5–6

C

Conventions Used, 1–4

D

Dimensional Drawing, 2–5

Dip Switch Information, 2–4

F

Firmware Updates, 4–11

Function Codes Supported, 3–6

I

Introduction, 1–2

M

MB-GATEWAY Configuration, 3–4

Modbus Error Codes, B–2

Mounting / Clearance Information, 1–6

DIN Rail Mounting, 1–7

Direct Mounting, 1–6

N

NetEdit Configuration, 3–5

P

Parameters, 4–2

Gateway Device Status Page, 4–8

Automatic Reads, 4–9

Last Modbus RTU Request, 4–10

Last Modbus TCP Request, 4–9

Status Information, 4–10

Gateway Modbus ID, 4–3

Home Page, 4–2

IP Setup Configuration Page, 4–5

Module Name and Module Description, 4–4

Serial Port Configuration Page, 4–6

Setup Slave Timeout / Retries Page, 4–7

Product Overview, 1–5

S

Safety Guidelines, 3–2

Security Considerations for Control Systems Networks, C–2

Specifications, 2–2

T

Technical Support, 1–3

U

Using Modbus Poll to MB-GATEWAY with CLICK Slave, A–11

Step 1: Connect the MB-GATEWAY serial port to Port 3 of the CLICK PLC., A–11

Step 2: Configure the CLICK serial port and MB-GATEWAY serial port., A–12

Step 3: Connect to the MB-GATEWAY using the Modbus Poll simulator software., A–18

Using Modbus Poll to MB-GATEWAY with DL06 Slave, A–2

Step 1: Connect the MB-GATEWAY serial port to the DL06 secondary communications port., A–2

Step 2: Configure the DL06 PLC serial port and MB-GATEWAY serial port., A–3

Step 3: Connect to the MB-GATEWAY using the Modbus Poll simulator software., A–7

Using P3000 as Master (Client) to MB-GATEWAY with CLICK Slave, A-24

Step 1: Connect CLICK to the MB-GATEWAY as shown in example 2., A-24

Step 2: Connect P3000 CPU (P3-550) to MB-GATEWAY via Ethernet Switch and Two Ethernet Cables., A-24

Step 3: Configure the MRX instruction to read data from the MB-GATEWAY., A-28

W

What's in the Box, 1-6

Wiring Diagrams, 3-3