# Nikon

DIGITAL CAMERA

# COOLPIX S6600 User's Manual







# **Highlight Feature of the COOLPIX S6600**

# Gesture control - Easily Take Self-portraits



The direction and angle of the monitor on this camera can be adjusted.

You can easily take self-portrait images in combination with **Gesture control**.

 When you open the monitor and face it forward in the same direction as the camera lens, you can take images without pressing the shutter-release button, simply by moving your hand toward an icon displayed on the monitor.



- The shooting functions listed below are available.
  - D: Start recording a movie
- 🖸: Take a still image
  - **1** Zoom out (wide-angle)
- **1**: Zoom in (telephoto)

For detailed operating instructions, see page  $\square$ 46.

Introduction

Parts of the Camera

The Basics of Shooting and Playback

**Shooting Features** 

**Playback Features** 

**Recording and Playing Back Movies** 

**General Camera Setup** 

Using the Wi-Fi (Wireless LAN) Function

Connecting the Camera to a TV, Computer, or Printer

**Technical Notes and Index** 


# Introduction

### **Read This First**

Thank you for purchasing the Nikon COOLPIX S6600 digital camera. Before using the camera, please read the information in "For Your Safety" (\(\subseteq\) viii-x) and familiarize yourself with the information provided in this manual. After reading, please keep this manual handy and refer to it to enhance your enjoyment of your new camera.

#### **Confirming the Package Contents**

In the event that any items are missing, please contact the store where you purchased the camera.



- User's Manual (this manual)
- Warranty
- \* A plug adapter is included if the camera was purchased in a country or region that requires a plug adapter. The shape of the plug adapter varies with the country or region of purchase (QQ12).

NOTE: A memory card is not included with the camera.

#### **About This Manual**

If you want to start using the camera right away, see "The Basics of Shooting and Playback" ( $\square$ 10).

To learn about the parts of the camera and information that is displayed in the monitor, see "Parts of the Camera" ( $\square$ 1).

#### About the Included "Reference Manual CD"

A PDF version of the COOLPIX S6600 *Reference Manual* can be found on the included CD. Refer to it for more detailed information.

Viewing the "Reference Manual CD"

The Reference Manual can be viewed using Adobe Reader, available for free download from the Adobe website.

- 1 Start the computer and insert the "Reference Manual CD".
- 2 Double-click the CD (COOLPIX S6600) icon in Computer or My Computer (Windows) or on the desktop (Mac OS).
- 3 Double-click the **INDEX.pdf** icon to display the language selection screen. Click a language and follow the links to view the *Reference Manual*.

#### Other Information

· Symbols and Conventions

To make it easier to find the information you need, the following symbols and conventions are used in this manual:

Symbol	Description
V	This icon indicates cautions and information that should be read before using the camera.
Ø	This icon indicates notes and information that should be read before using the camera.
□/ <b>&gt;</b> / <b>Ö</b> -	These icons indicate other pages containing relevant information;  *"."Reference Section", **: "Technical Notes and Index."

\*Refer to the Reference Manual for pages indicated with ...

- SD and SDHC/SDXC memory cards are referred to as "memory cards" in this manual.
- The setting at the time of purchase is referred to as the "default setting."
- The names of menu items displayed in the camera monitor, and the names of buttons or messages displayed on a computer monitor appear in bold.
- In this manual, images are sometimes omitted from monitor display samples so that monitor indicators can be more clearly shown.
- Illustrations and monitor content shown in this manual may differ from the actual product.

#### Information and Precautions

#### **Life-Long Learning**

As part of Nikon's "Life-Long Learning" commitment to ongoing product support and education, continually updated information is available online at the following sites:

- For users in the U.S.A.: http://www.nikonusa.com/
- For users in Europe and Africa: http://www.europe-nikon.com/support/
- For users in Asia, Oceania, and the Middle East: http://www.nikon-asia.com/

Visit these sites to keep up-to-date with the latest product information, tips, answers to frequently asked questions (FAQs), and general advice on digital imaging and photography. Additional information may be available from the Nikon representative in your area. Visit the site below for contact information:

http://imaging.nikon.com/

#### **Use Only Nikon Brand Electronic Accessories**

Nikon COOLPIX cameras are designed to the highest standards and include complex electronic circuitry. Only Nikon brand electronic accessories (including battery chargers, batteries, Charging AC adapters) certified by Nikon specifically for use with this Nikon digital camera are engineered and proven to operate within the operational and safety requirements of this electronic circuitry.

The use of non-Nikon electronic accessories could damage the camera and may void your Nikon warranty.

The use of third-party rechargeable Li-ion batteries not bearing the Nikon holographic seal could interfere with normal operation of the camera or result in the batteries overheating, igniting, rupturing, or leaking.

For more information about Nikon brand accessories, contact a local authorized Nikon dealer.

**Holographic seal:** Identifies this device as an authentic Nikon product.



#### **Before Taking Important Pictures**

Before taking pictures on important occasions (such as at weddings or before taking the camera on a trip), take a test shot to ensure that the camera is functioning normally. Nikon will not be held liable for damages or lost profits that may result from product malfunction.

#### **About the Manuals**

- No part of the manuals included with this product may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form, by any means, without Nikon's prior written permission.
- Nikon reserves the right to change the specifications of the hardware and software described in these manuals at any time and without prior notice.
- Nikon will not be held liable for any damages resulting from the use of this product.
- While every effort was made to ensure that the information in these manuals is accurate and complete, we would appreciate it were you to bring any errors or omissions to the attention of the Nikon representative in your area (address provided separately).

#### **Notice Concerning Prohibition of Copying or Reproduction**

Note that simply being in possession of material that was digitally copied or reproduced by means of a scanner, digital camera or other device may be punishable by law.

#### • Items prohibited by law from being copied or reproduced

Do not copy or reproduce paper money, coins, securities, government bonds or local government bonds, even if such copies or reproductions are stamped "Sample." The copying or reproduction of paper money, coins, or securities which are circulated in a foreign country is prohibited. Unless the prior permission of the government was obtained, the copying or reproduction of unused postage stamps or post cards issued by the government is prohibited.

The copying or reproduction of stamps issued by the government and of certified documents stipulated by law is prohibited.

#### · Cautions on certain copies and reproductions

The government has issued cautions on copies or reproductions of securities issued by private companies (shares, bills, checks, gift certificates, etc.), commuter passes, or coupon tickets, except when a minimum of necessary copies are to be provided for business use by a company. Also, do not copy or reproduce passports issued by the government, licenses issued by public agencies and private groups, ID cards and tickets, such as passes and meal coupons.

#### · Comply with copyright notices

The copying or reproduction of copyrighted creative works such as books, music, paintings, woodcut prints, maps, drawings, movies, and photographs is governed by national and international copyright laws. Do not use this product for the purpose of making illegal copies or to infringe copyright laws.

#### **Disposing of Data Storage Devices**

Please note that deleting images or formatting data storage devices such as memory cards or built-in camera memory does not completely erase the original image data. Deleted files can sometimes be recovered from discarded storage devices using commercially available software, potentially resulting in the malicious use of personal image data. Ensuring the privacy of such data is the user's responsibility.

Before discarding a data storage device or transferring ownership to another person, erase all data using commercial deletion software, or format the device and then completely refill it with images containing no private information (for example, pictures of empty sky). Be sure to also replace any pictures selected for the **Select an image** option in the **Welcome screen** setting (\$\subseteq\$78). Care should be taken to avoid injury or damage to property when physically destroying data storage devices.

# **For Your Safety**

To prevent damage to your Nikon product or injury to yourself or to others, read the following safety precautions in their entirety before using this equipment. Keep these safety instructions where all those who use the product will read them.

The consequences that could result from failure to observe the precautions listed in this section are indicated by the following symbol:



This icon marks warnings, information that should be read before using this Nikon product, to prevent possible injury.

#### WARNINGS



#### Turn off in the event of malfunction

Should you notice smoke or an unusual smell coming from the camera or Charging AC Adapter, unplug the Charging AC Adapter and remove the battery immediately, taking care to avoid burns. Continued operation could result in injury. After removing or disconnecting the power source, take the equipment to a Nikonauthorized service representative for inspection.



#### Do not disassemble

Touching the internal parts of the camera or Charging AC Adapter could result in injury. Repairs should be performed only by qualified technicians. Should the camera or Charging AC Adapter break open as the result of a fall or other accident, take the product to a Nikon-authorized service

representative for inspection, after unplugging the product and/or removing the battery.



#### ♠ Do not use the camera or Charging AC Adapter in the presence of flammable gas

Do not use electronic equipment in the presence of flammable gas, as this could result in explosion or fire.



#### Handle the camera strap with care

Never place the strap around the neck of an infant or child



#### Keep out of reach of children

Particular care should be taken to prevent infants from putting the battery or other small parts into their mouths.



# Do not remain in contact with the camera, battery charger, or AC adapter for extended periods while the devices are on or in use

Parts of the devices become hot. Leaving the devices in direct contact with the skin for extended periods may result in low-temperature burns.



# Do not leave the product where it will be exposed to extremely high temperatures, such as in an enclosed automobile or in direct sunlight

Failure to observe this precaution could cause damage or fire.



# Observe caution when handling the battery

The battery may leak, overheat, or explode if improperly handled. Observe the following precautions when handling the battery for use in this product:

- Before replacing the battery, turn the product off. If you are using the Charging AC Adapter/AC adapter, be sure it is unplugged.
- Use only a Rechargeable Li-ion Battery EN-EL19 (included). Charge the battery by using a camera that supports battery charging or by using a Battery Charger MH-66 (available separately). To charge the battery with the camera, use either Charging AC Adapter EH-70P (included) or the **Charge by computer** function.

- When inserting the battery, do not attempt to insert it upside down or backwards.
- Do not short or disassemble the battery or attempt to remove or break the battery insulation or casing.
- Do not expose the battery to flame or to excessive heat.
- Do not immerse in or expose to water.
- Put the battery in the battery case before transporting it. Do not transport or store with metal objects such as necklaces or hairpins.
- The battery is prone to leakage when fully discharged. To avoid damage to the product, be sure to remove the battery when no charge remains.
- Discontinue use immediately should you notice any change in the battery, such as discoloration or deformation.
- If liquid from the damaged battery comes in contact with clothing or skin, rinse immediately with plenty of water.



#### 

- Keep dry. Failure to observe this precaution could result in fire or electric shock.
- Dust on or near the metal parts of the plug should be removed with a dry cloth.
   Continued use could result in fire.
- Do not handle the plug or go near the Charging AC Adapter during lightning storms. Failure to observe this precaution could result in electric shock.

- Do not damage, modify, forcibly tug or bend the USB cable, place it under heavy objects, or expose it to heat or flames.
   Should the insulation be damaged and the wires become exposed, take it to a Nikon-authorized service representative for inspection. Failure to observe these precautions could result in fire or electric shock.
- Do not handle the plug or Charging AC Adapter with wet hands. Failure to observe this precaution could result in electric shock.
- Do not use with travel converters or adapters designed to convert from one voltage to another or with DC-to-AC inverters. Failure to observe this precaution could damage the product or cause overheating or fire.

#### ↑ Use appropriate cables

When connecting cables to the input and output jacks, use only the cables provided or sold by Nikon for the purpose, to maintain compliance with product regulations.

#### Mandle moving parts with care

Be careful that your fingers or other objects are not pinched by the lens cover or other moving parts.

#### CD-ROMs

The CD-ROMs included with this device should not be played back on audio CD equipment. Playing CD-ROMs on an audio CD player could cause hearing loss or damage the equipment.



#### Using the flash close to your subject's eyes could cause temporary visual impairment.

The flash should be no less than 1 meter (3 ft 4 in.) from the subject.

Particular care should be observed when photographing infants.



# Do not operate the flash with the flash window touching a person or object

Failure to observe this precaution could result in burns or fire.

#### $\Delta$

#### Avoid contact with liquid crystal

Should the monitor break, care should be taken to avoid injury caused by broken glass and to prevent liquid crystal from the monitor touching the skin or entering the eyes or mouth.



# Turn the power off when using inside an airplane or the hospital

Turn the power off while inside the airplane during take off or landing. Do not use wireless network functions while in the air. Follow the instructions of the hospital when using while in a hospital. The electromagnetic waves emitted by this camera may disrupt the electronic systems of the airplane or the instruments of the hospital. If you are using an Eye-Fi card, remove it from the camera before boarding an aircraft or entering a hospital.

#### **Notices**

# Notices for Customers in the U.S.A.

# IMPORTANT SAFETY INSTRUCTIONS -

#### SAVE THESE INSTRUCTIONS.

# DANGER - TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS

For connection to a supply not in the U.S.A., use an attachment plug adapter of the proper configuration for the power outlet if needed.

The power supply unit is intended to be correctly orientated in a vertical or floor mount position.

#### Federal Communications Commission (FCC) Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.



#### **CAUTIONS**

#### Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Nikon Corporation may void the user's authority to operate the equipment.

#### Interface Cables

Use the interface cables sold or provided by Nikon for your equipment. Using other interface cables may exceed the limits of Class B Part 15 of the FCC rules.

# Notice for customers in the State of California WARNING

Handling the cord on this product will expose you to lead, a chemical known to the State of California to cause birth defects or other reproductive harm.

#### Wash hands after handling.

Nikon Inc.,

1300 Walt Whitman Road Melville, New York 11747-3064 USA

Tel: 631-547-4200

#### Notice for customers in Canada

CAN ICES-3 B / NMB-3 B

#### **Notices for customers in Europe**

#### **CAUTIONS**

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

This symbol indicates that electrical and electronic equipment is to be collected separately.



The following apply only to users in European countries:

- This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- Separate collection and recycling helps conserve natural resources and prevent negative consequences for human health and the environment that might result from incorrect disposal.
- For more information, contact the retailer or the local authorities in charge of waste management.

This symbol on the battery indicates that the battery is to be collected separately. The following apply only to users in European countries:



- All batteries, whether marked with this symbol or not, are designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- For more information, contact the retailer or the local authorities in charge of waste management.

# Wi-Fi (Wireless LAN Network)

This product is controlled by the United States Export Administration Regulations, and you are required to obtain permission from the United States government if you export or reexport this product to any country to which the United States embargoes goods. The following countries were subject to embargo: Cuba, Iran, North Korea, Sudan, and Syria. Since the target countries are subject to change, please contact the United States Department of Commerce for the latest information.

#### **Restrictions on Wireless Devices**

The wireless transceiver included in this product conforms to wireless regulations in the country of sale and is not for use in other countries (products purchased in the EU or EFTA can be used anywhere within the EU and EFTA). Nikon does not accept liability for use in other countries. Users who are unsure as to the original country of sale should consult with their local Nikon service center or Nikon-authorized service representative. This restriction applies to wireless operation only and not to any other use of the product.

#### Notice for Customers in the U.S.A. and Canada

#### Federal Communications Commission (FCC) and Industry of Canada (IC)

#### **Declaration of Conformity**

This device complies with Part 15 of FCC Rules and Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device.

#### **FCC/IC RF Exposure Statement**

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

The available scientific evidence does not show that any health problems are associated with using low power wireless devices. There is no proof, however, that these low power wireless devices are absolutely safe. Low power wireless devices emit low levels of radio frequency energy (RF) in the microwave range while being used. Whereas high levels of RF can produce health effects (by heating tissue), exposure of low-level RF that does not produce heating effects causes no known adverse health effects. Many studies of low-level RF exposures have not found any biological effects. Some studies have suggested that some biological effects might occur, but such findings have not been confirmed by additional research.

COOLPIX S6600 (FCC ID:CGJ1150EB/IC ID:4634A-1150EB) has been tested and found to comply with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65 and RSS-102 of the IC radio frequency (RF) Exposure rules. Please refer to the SAR test report that was uploaded to FCC website.

#### **Declaration of Conformity (Europe)**

Hereby, Nikon Corporation, declares that COOLPIX S6600 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The declaration of conformity may be consulted at http://imaging.nikon.com/support/pdf/DoC\_S6600.pdf.

#### **Notice for Customers in Singapore**

This device complies with radio-frequency regulations.

Complies with IDA Standards DA103423

#### **Precautions when Using Radio Transmissions**

- Always keep in mind that radio transmission or reception of data is subject to interception
  by third parties. Note that Nikon is not responsible for data or information leaks that may
  occur during data transfer.
- The operating frequency band of this equipment is used by industrial, scientific, consumer and medical equipment including microwave ovens, premises radio stations for identifying mobile units used in the manufacturing lines of plants (radio stations requiring no license), and amateur radio stations (hereinafter referred to as "another station"). 1. Before using this equipment, confirm that another station is not being operated nearby. 2. In the event of this equipment causing harmful radio wave interference with another station, promptly change the operating frequency or stop radio wave emission by turning off the power, etc. 3. If you have further questions, contact a Nikon service center or Nikon authorized service representative.

#### **Personal Information Management and Disclaimer**

- User information registered and configured on the product, including wireless LAN
  connection settings and other personal information, is susceptible to alteration and loss
  resulting from operational error, static electricity, accident, malfunction, repair or other
  handling. Always keep separate copies of important information. Nikon is not responsible
  for any direct or indirect damages or lost profits resulting from alteration or loss of content
  that is not attributable to Nikon.
- Before discarding this product or transferring it to another owner, perform Reset all in the setup menu (□79) to delete all user information registered and configured with the product, including wireless LAN connection settings and other personal information.

# **Table of Contents**

Introduction	ii
Read This First	ii
Confirming the Package C	ontentsii
About This Manual	iii
Information and Precautio	ns v
For Your Safety	viii
WARNINGS	viii
Notices	xi
Wi-Fi (Wireless LAN Networ	k) xiii
Parts of the Camera	1
The Camera Body	1
Attaching the Camera Stra	ıp 3
Opening and Adjusting th	e Angle of the
Monitor	3
Using Menus (the MENU Butt	on) 4
The Monitor	6
Shooting Mode	6
Playback Mode	8
The Basics of Shooting and	d Playback
	10
Preparation 1 Insert the Bat	tery 10
Preparation 2 Charge the Ba	attery 12
Preparation 3 Insert a Memo	ory Card 14
Internal Memory and Mem	nory Cards 15

	Preparation 4 Setting the Display Language	ge,
	Date, and Time	16
	Step 1 Turn the Camera On	20
	Step 2 Select a Shooting Mode	22
	Available Shooting Modes	23
	Step 3 Frame a Picture	24
	Using the Zoom	25
	Step 4 Focus and Shoot	26
	The Shutter-release Button	27
	Step 5 Play Back Images	28
	Step 6 Delete Images	30
SI	nooting Features	32
	(Scene Auto Selector) Mode	
	Scene Mode (Shooting Suited to Scenes)	52
		2/
	Tips and Notes	
	Special Effects Mode (Applying Effects	)_
	When Shooting)	40
	3,	
	Smart Portrait Mode (Capturing Images o	
	Smiling Faces)	
	(Auto) Mode	
	Using Quick Effects	
	Using the Self-timer with Gesture Control	
	Functions That Can Be Set Using the Mult	
	Selector	
	Using the Flash	
	Using the Self-timer	51

Llain a Ada ana Ada ala	
Using Macro Mode53 Adjusting Brightness (Exposure	Using the Wi-Fi (Wireless LAN) Function
Compensation)	80
Default Settings55	
Functions That Can Be Set with the MENU	Wi-Fi 80
Button (Shooting Menu) 57	Take Photos80
Options Available in the Shooting Menu	View Photos80
58	Installing the Software on the Smart Device
Functions That Cannot Be Used	
Simultaneously60	Connecting the Smart Device to the Camera
Focusing 63	
Using Target Finding AF 63	
Using Face Detection 64	Connecting the Camera to a TV,
Using Skin Softening65	
Subjects Not Suitable for Autofocus 66	Connection Methods 83
Focus Lock 67	Using ViewNX 2 85
	Installing ViewNX 285
Playback Features 68	Transferring Images to the Computer 88
Playback Zoom 68	Viewing Images 90
Thumbnail Playback, Calendar Display 69	
Functions That Can Be Set with the MENU	Reference Section 5
Button (Playback Menu)70	Using Easy Panorama (Shooting and
	Playback) 6-2
Recording and Playing Back Movies 72	Shooting with Easy Panorama
Recording Movies72	Viewing Images Captured with Easy
Functions That Can Be Set with the MENU	Panorama 6 5
Button (Movie Menu)75	Favorite Pictures Mode 5
Playing Back Movies 76	Adding Images to Albums 🏍6
	Playing Back Images in Albums 🖰7
General Camera Setup 78	
Functions That Can Be Set with the MENU	Changing the Favorites Album Icon 🗪 9
Button (Setup Menu) 78	Auto Sort Mode 🗪 10
•	

List by Date Mode	write balance (Aujusting nue)
Viewing and Deleting Images Captured	Continuous Shooting 🗝 39
Continuously (Sequence)	ISO Sensitivity 6-642
Viewing Images in a Sequence ♣ 12	Color Options 6-643
Deleting Images in a Sequence	AF Area Mode
Editing Still Images 5—314	Autofocus Mode 6-648
Before Editing Images 📤 14	Quick Effects 6-648
Quick Effects: Changing Hue or Mood	The Smart Portrait Menu 5-49
	Skin Softening 6-649
Quick Retouch: Enhancing Contrast and	Smile Timer 6-50
Saturation 6 16	Blink Proof
D-Lighting: Enhancing Brightness and	The Playback Menu 5-52
Contrast <b>◆</b> 16	Print Order (Creating a DPOF Print Order)
Red-eye Correction: Correcting Red-eye	<b>~</b> 52
When Shooting with the Flash 🟍 17	Slide Show 6-56
Glamour Retouch: Enhancing Human Faces	Protect
	Rotate Image <b>6-6</b> 59
Small Picture: Reducing the Size of an	Voice Memo 560
Image 6-20	Copy (Copy Between Internal Memory and
Crop: Creating a Cropped Copy 🟍21	Memory Card) 6-61
Connecting the Camera to a TV (Viewing	Sequence Display Options 🗝 63
Images on a TV) 5-22	Choose Key Picture 663
Connecting the Camera to a Printer (Direct	The Movie Menu 5-64
Print) 6-624	Movie Options
Connecting the Camera to a Printer	Open with HS Footage 🗝 68
<b> ♣0</b> 25	Autofocus Mode 6468
Printing Individual Images 🟍 27	Wind Noise Reduction 🗝 69
Printing Multiple Images 🟍 29	The Setup Menu 🗝 70
Editing Movies 5-32	Welcome Screen ♣ 70
The Shooting Menu (for 🗖 (Auto) Mode)	Time Zone and Date 🗝71
<b></b>	Monitor Settings 6-673
Image Mode Settings (Image Size and	Print Date (Imprinting Date and Time)
Quality) 6—634	

Gesture Control	<b>6–6</b> 76
Vibration Reduction	<b>6–6</b> 77
Motion Detection	<b>6–6</b> 78
AF Assist	<b>6–6</b> 79
Digital Zoom	<b>6–6</b> 79
Sound Settings	6480
Auto Off	6480
Format Memory/Format Card	<b>6–6</b> 81
Language	<b>6–6</b> 82
TV Settings	<b>6–6</b> 82
Charge by Computer	<b>6–6</b> 83
Blink Warning	<b>6–6</b> 84
Wi-Fi Options	<b>6–6</b> 85
Eye-Fi Upload	<b>6–6</b> 87
Reset All	<b>6–6</b> 88
Firmware Version	<b>6–6</b> 88
Error Messages	5—89
File Names	5 94
Optional Accessories	<del>6-0</del> 95
Technical Notes and Index	🌣 1
Caring for the Product	
The Camera	<b>;</b> -2
The Battery	<b>;</b>
Charging AC Adapter	<b>;</b> 4
Memory Cards	<b>;</b> 5
Cleaning and Storage	
Cleaning	<b>;</b> 6
Storage	<b>&amp;</b> -6
Troubleshooting	
Specifications	🙋 17
Approved Memory Cards	<b>☆</b> ->>

 <b>5−6</b> 76
 <b>∂=</b> 077
 <b>5−6</b> 78
 <b>∂=</b> 079
 <b>∂=</b> 079
 <b>6</b> 80
 <b>6−6</b> 80
 <b>6−6</b> 81
 <b>6−6</b> 82
 <b>6−6</b> 82
 <b>6</b> €83
 <b>6-6</b> 84
 <b>6−6</b> 85
 <b>6−6</b> 87
 <b>6−6</b> 88
 <b>6−6</b> 88
 <b>∂−</b> 095
 . 💢 1
 💸 2
 💸-2
 🙋 7
 . <b>⊘</b> -17



# **Parts of the Camera**

# **The Camera Body**



1	Flash	49
2	Shutter-release button	26
3	Zoom control	25 25 69
4	Power switch/power-on lamp	20
5	▶ (playback) button	28
6	(shooting mode) button	22

7	Self-timer lampAF-assist illuminator	
8	Microphone (stereo)	
9	Lens	
10	Lens cover	
11	Eyelet for camera strap	3
12	Connector cover	8
13	HDMI micro connector (Type D)	8
14	USB/audio/video output connector	8





1	Charge lamp
2	• (*\(\mathbf{T}\) movie-record) button72
3	Multi selector4
4	<b>®</b> (apply selection) button4
5	<b>1</b> (delete) button30, <b>◆◆</b> 61
6	MENU (menu) button 4, 57, 70, 75, 78

7	Battery-chamber/ memory card slot cover10, 14
8	Power connector cover (for connection with optional AC adapter)
9	Tripod socket
10	Speaker
	l., .

### **Attaching the Camera Strap**








### Opening and Adjusting the Angle of the Monitor

The direction and angle of the monitor on this camera can be adjusted. This is useful when shooting with the camera in a high or low position. In addition, using this feature with **Gesture control** (2246) makes it easy to take self-portrait images.



For normal shooting, fold the monitor against the back of the camera, facing rearward (3).

To protect the monitor from scratches and dirt while you are carrying or not using the camera, close the monitor so that it is facing inward against the back of the camera.





#### Notes About the Monitor

When moving the monitor, do not apply excessive force and make sure to turn it slowly within the adjustable range.

# **Using Menus (the MENU Button)**

Use the multi selector and **66** button to navigate the menus.

#### Press the MENU button.

• The menu is displayed.



# **2** Press the multi selector **◄**.

• The current menu icon is displayed in yellow.





Menu icons

- **3** Select the desired menu icon.
  - The menu is changed.





# 4 Press the ® button.

• The menu options become selectable.





### **5** Select a menu option.





### **7** Select a setting.





#### 6 Press the (%) button.

 The settings for the option you selected are displayed.





# **8** Press the **®** button.

- The setting you selected is applied.
- When you are finished using the menu, press the MENU button.



### Notes About Setting Menu Options


- Certain menu options cannot be set depending on the current shooting mode or the state of the camera. Unavailable options are displayed in gray and cannot be selected.
- When a menu is displayed, you can switch to shooting mode by pressing the shutter-release button, (shooting mode) button, or (√ movie-record) button.

#### **The Monitor**

The information that is displayed in the monitor during shooting and playback changes depending on the camera's settings and state of use.

By default, information is displayed when the camera is first turned on and when you operate the camera, and turns off after a few seconds (when **Photo info** is set to **Auto info** in **Monitor settings** (\$\subset\$78)).


### **Shooting Mode**



1	Shooting mode22, 23
2	Flash mode49
3	Macro mode53
4	Zoom indicator25, 53
5	Focus indicator26
6	Movie options (normal speed movies)75, 6-64
7	Movie options (HS movies)75, €€65
8	Image mode58, 6-34
9	Easy panorama38
10	Vibration reduction icon78
11	Motion detection icon79
12	Wind noise reduction75
13	Exposure compensation value54
14	Movie recording time remaining72
15	Number of exposures remaining (still images)20
16	Internal memory indicator20
17	Aperture value27
18	Focus area (target finding AF)26, 58, 63
19	Focus area (for manual or center) 58, 67
20	Focus area (face detection, pet detection) 39 42 58 64

21	Focus area (subject tracking) 58, 🏕	<b>0</b> 47
22	Shutter speed	27
23	ISO sensitivity	58
24	Battery level indicator	20
25	Print date	78
26	Travel destination icon	<b>0</b> 71
27	"Date not set" indicator	16
28	Eye-Fi communication indicator	79
29	Wi-Fi communication indicator	79
30	Gesture control4	5, 78
31	White balance mode	58
32	Skin softening	59
33	Color options	58
34	Quick effects icon4	5, 58
35	Continuous shooting mode	58
36	Blink proof icon	59
37	Hand-held/tripod3	5, 36
38	Backlighting (HDR)	37
39	Self-timer indicator	51
40	Smile timer	59
41	Pet portrait auto release	30

# **Playback Mode**




1	Album icon in favorite pictures mode
2	Category icon in auto sort mode 610
3	List by date icon <b>6-6</b> 11
4	Protect icon70, <b>6-6</b> 57
5	Sequence display (when <b>Individual pictures</b> is selected)
6	Print order icon70, <b>5</b>
7	Voice memo indicator70, 60
8	Glamour retouch icon70, 🏍 18
9	Quick effects icon29, 45, 6615
10	D-Lighting icon70, 6-16
11	Quick retouch icon70, 6
12	Red-eye correction70, <b>6</b>
13	Internal memory indicator20

14	<ul><li>(a) Current image number/ total number of images</li><li>(b) Movie length</li></ul>	
15	Image mode58, 🗪	<b>3</b> 34
16	Easy panorama	38
17	Movie options75, 🗪	<b>3</b> 64
18	Crop icon68,	<b>3</b> 21
19	Small picture icon70,	<b>3</b> 20
20	Volume indicator76,	<b>3</b> 60
21	Quick effects guide	29
22	Easy panorama playback guide38, o Sequence playback guide71, o Movie playback guide	<b>3</b> 12
23	Time of recording	
24	Date of recording	
25	Battery level indicator	20
26	File number and type	<b>3</b> 94
27	Eye-Fi communication indicator	<b>3</b> 87

# The Basics of Shooting and Playback


# **Preparation 1 Insert the Battery**

Open the battery-chamber/memory card slot cover.



- **2** Insert the battery.
  - Push the orange battery latch in the direction indicated by the arrow (1), and fully insert the battery (2).
  - The battery locks into place when inserted correctly.

Battery latch




Be Careful to Insert the Battery in Correct Direction

Inserting the battery upside down or backwards could damage the camera.




# 3 Close the battery-chamber/memory card slot cover.



#### Removing the Battery

Turn the camera off and make sure that the power-on lamp and the monitor have turned off, and then open the batterychamber/memory card slot cover.

Move the battery latch in the direction indicated by the arrow  $(\widehat{1})$  to eject the battery  $(\widehat{2})$ .



## High Temperature Caution

The camera, battery, and memory card may be hot immediately after using the camera.

### **Preparation 2 Charge the Battery**

# **1** Prepare the included Charging AC Adapter.


If a plug adapter\* is included with your camera, attach the plug adapter to the plug on the Charging AC Adapter. Push the plug adapter firmly until it is securely held in place. Once the two are connected, attempting to forcibly remove the plug adapter could damage the product.

\* The shape of the plug adapter varies according to the country or region in which the camera was purchased. The Charging AC Adapter comes with the plug adapter attached in Argentina and Korea.



# **2** Make sure the battery is installed in the camera, and then connect the camera to the Charging AC Adapter in order of ① to ③.

- · Keep the camera turned off.
- Make sure that the plugs are properly oriented. Do not insert or remove the plugs at an
  angle when connecting or disconnecting them.



- The charge lamp slowly flashes green to indicate that the battery is charging.
- Shooting is not possible while the camera is connected to the Charging AC Adapter.

Charge lamp	Description
Flashes slowly (green)	The battery is charging.
Off	When charging is complete, the charge lamp stops flashing green and turns off. About 3 hours are required to charge a fully exhausted battery.
Flashes quickly (green)	The ambient temperature is not suited to charging. Charge the battery indoors with an ambient temperature of 5°C to 35°C (41°F to 95°F).  The USB cable or Charging AC Adapter is not properly connected, or there is a problem with the battery. Disconnect the USB cable or unplug the Charging AC Adapter and correctly connect it again, or change the battery.


3 Disconnect the Charging AC Adapter from the electrical outlet and then disconnect the USB cable.

# Charging Using a Computer or Battery Charger

- You can also charge the battery by connecting the camera to a computer (\$\square\$83, \$\square\$83).
- You can use the Battery Charger MH-66 (available separately; \$\infty\$95) to charge the battery without using the camera.

# **Preparation 3 Insert a Memory Card**

1 Turn off the camera and open the batterychamber/memory card slot cover.



- **2** Insert the memory card.
  - Slide the memory card in until it clicks into place.






- Be Careful to Insert the Memory Card in Correct Direction
- Inserting the memory card upside down or backwards could damage the camera and the memory card.



3 Close the battery-chamber/memory card slot cover.




# Formatting Memory Cards

The first time you insert a memory card that has been used in another device into this camera, make sure to format it with this camera. Insert the card into the camera, press the **MENU** button, and select **Format card** in the setup menu.

#### **Removing Memory Cards**

Turn the camera off and make sure that the power-on lamp and the monitor have turned off, and then open the batterychamber/memory card slot cover.

Gently push the memory card into the camera (1) to partially eject the card (2).



## High Temperature Caution

The camera, battery, and memory card may be hot immediately after using the camera.


# **Internal Memory and Memory Cards**

Camera data, including images and movies, can be saved either in the camera's internal memory or on a memory card. To use the camera's internal memory, first remove the memory card.

# Preparation 4 Setting the Display Language, Date, and Time

When the camera is turned on for the first time, the language-selection screen and the date and time setting screen for the camera clock are displayed.

- If you exit without setting the date and time, will flash when the shooting screen is displayed.
- **1** Press the power switch to turn on the camera.



2 Use the multi selector ▲▼ to select the desired language and press the ® button.





**3** Select **Yes** and press the **®** button.



# 4 Select your home time zone and press the (8) button.

To enable daylight saving time, press A.
When the daylight saving time function is
enabled, % is displayed above the map.
To turn off the daylight saving time
function, press V.






**5** Select the date format and press the **6** button.



- **6** Set the date and time, and press the ® button

  - Edit the date and time: Press ▲▼.
  - Confirm the setting: Select the minute field and press the 

    button.



- **7** Select **Yes** and press the **®** button.
  - When settings are finished, the lens extends and the camera switches to shooting mode.



## Changing the Language Setting and the Date and Time Setting

- You can change these settings using the **Language** and **Time zone and date** settings in the **∀** setup menu (□78).

# The Clock Battery


- The camera's clock is powered by a built-in backup battery.
   The backup battery charges when the main battery is inserted into the camera or when the camera is connected to an optional AC adapter, and it can run the clock for several days after about ten hours of charging.
- If the camera's backup battery becomes exhausted, the date and time setting screen is displayed
  when the camera is turned on. Set the date and time again. See step 3 (\(\sum\_{16}\)) of "Preparation 4
  Setting the Display Language, Date, and Time" for more information.

# Imprinting the Shooting Date on Printed Images

- You can permanently imprint the shooting date on images as they are captured by setting **Print**date in the setup menu (278).
- If you want the shooting date to be printed without using the **Print date** setting, print using the ViewNX 2 software (\$\subset\$85).


# Step 1 Turn the Camera On

- **1** Press the power switch.
  - · The monitor turns on.
  - To turn the camera off, press the power switch again.



2 Check the battery level indicator and the number of exposures remaining.

#### Battery level indicator

Display	Description		
	The battery level is high.		
	The battery level is low.		
<b>1</b> Battery exhausted.	The camera cannot capture images. Recharge the battery.		

Number of exposures remaining




Battery level indicator

#### **Number of Exposures Remaining**

The number of images that can be taken is displayed.

 It is displayed when no memory card is inserted in the camera, and images are saved in the internal memory.

# The Auto Off Function



- The time that elapses before the camera enters standby mode is about one minute. The time can be changed using the **Auto off** setting in the setup menu (□78).
- While the camera is in standby mode, the monitor turns back on if you perform any of the following operations or open the monitor:
  - → Press the power switch, shutter-release button, 


    (shooting mode) button, 

    (playback) button, or 

    (\*★ movie-record) button

# **Step 2 Select a Shooting Mode**

1 Press the D button.



- 2 Use the multi selector ▲▼ to select a shooting mode and press the ® button.
  - (auto) mode is used in this example.
  - The shooting mode setting is saved even after the camera is turned off.





# **Available Shooting Modes**


the type of shot you want to capture.

#### SCENE □32 Scene auto selector The camera automatically selects the optimum scene mode when you frame an image. making it even easier to take images using settings that suit the scene. % □134 Scene mode Camera settings are optimized according to the scene that you select. S<sub>0</sub> **1**40 Special effects Effects can be applied to images during shooting. ₩. **1**342 Smart portrait When the camera detects a smiling face, you can take an image automatically without pressing the shutter-release button (smile timer). You can also use the skin softening option to smooth the skin tones of human faces. Ō □144 Auto mode Used for general shooting. Settings can be adjusted to suit the shooting conditions and

# **Step 3 Frame a Picture**

#### **1** Hold the camera steady.

 Keep fingers and other objects away from the lens, flash, AF assist-illuminator, microphone, and speaker.



 When taking pictures in portrait ("tall") orientation, turn the camera so that the flash is above the lens.



**2** Frame the picture.



## When Using a Tripod

- We recommend using a tripod to stabilize the camera in the following situations.
  - When shooting in dim lighting
  - When shooting with the flash mode (QQ50) set to (3) (off)
  - When using the telephoto setting
- When using a tripod to stabilize the camera during shooting, set Vibration reduction to Off in the setup menu (\$\sum 78\$) to prevent potential errors caused by this function.

## **Using the Zoom**


When you move the zoom control, the zoom lens position changes.

- To zoom in closer to the subject: Move toward **T** (telephoto)

When you turn the camera on, the zoom moves to the maximum wide-angle position.

- A zoom indicator is displayed at the top of the monitor when the zoom control is moved.
- Digital zoom, which allows you to further magnify the subject up to approximately 4x the maximum optical zoom ratio, can be activated by moving and holding the

zoom control toward  ${\bf T}$  when the camera is zoomed in to the maximum optical zoom position.






# Digital Zoom and Interpolation

While using digital zoom, the image quality decreases due to interpolation when the zoom is increased beyond the position. The position of moves to the right as the size of an image decreases.



# **Step 4 Focus and Shoot**

- **1** Press the shutter-release button halfway.
  - When the subject is in focus, the focus area glows green (multiple focus areas can glow green).
  - When you are using digital zoom, the camera focuses on the subject in the center of the frame and the focus area is not displayed. When the camera has focused, the focus indicator (\$\superscript{\supe
  - If the focus area or focus indicator flashes red, the camera is unable to focus. Modify the composition and try pressing the shutter-release button halfway again.





**2** Without lifting your finger, press the shutter-release button the rest of the way down.



- **3** To apply an effect to the captured image, press the **(%)** button.
  - The screen for selecting an effect is displayed.
     See "Using Quick Effects" (□45) for more information.
  - When you press the MENU button or when no operations are performed for about five seconds, the monitor display returns to the shooting screen.
  - To not display the screen shown on the right, set Quick effects to Off in the shooting menu (□57).



#### The Shutter-release Button

Press halfway



To set focus and exposure (shutter speed and aperture value). press the shutter-release button lightly until you feel a slight resistance. Focus and exposure remain locked while the shutterrelease button is pressed halfway.

Press all the wav



Press the shutter-release button all the way to release the shutter and take an image.


Do not use force when pressing the shutter-release button, as this may result in camera shake and blurred images. Press the button aently.

# Notes About Saving Images and Recording Movies

The indicator showing the number of exposures remaining or the indicator showing the maximum movie length flashes while images are being saved or while a movie is being recorded. **Do not open** the battery-chamber/memory card slot cover or remove the battery or memory card while an indicator is flashing. Doing this could result in loss of data, or in damage to the camera or the memory card.

# **Step 5 Play Back Images**

- **1** Press the **▶** (playback) button.
  - If you press and hold down the (playback) button while the camera is turned off, the camera turns on in playback mode.



- Use the multi selector to select an image to display.
  - Press and hold down ▲▼◀► to scroll through the images quickly.

 To return to shooting mode, press the button or shutter-release button.



Display the next image



#### Notes About the Quick Effects Function

- When **OK**: is displayed in full-frame playback mode, you can press 60 button to apply an effect to the image.
- When the effect selection screen is displayed, use the multi selector  $\triangle \nabla \blacktriangleleft \triangleright$  to select an effect, press the 🚯 button, and then select **Yes** in the confirmation dialog and press the 🙉 button to save the image as a separate file. See "Quick Effects: Changing Hue or Mood" ( 15) for more information



# **Step 6 Delete Images**

1 Press the button to delete the image currently displayed in the monitor.



- 2 Use the multi selector ▲▼ to select the desired deletion method and press the ® button.
  - To exit without deleting, press the MENU button.



- **3** Select **Yes** and press the **®** button.
  - · Deleted images cannot be recovered.
  - To cancel, select **No** and press the **®** button.



#### **Operating the Erase Selected Images Screen**

- Use the multi selector ◆ to select an image to be deleted, and then use ▲ to display m.
  - To undo the selection, press ▼ to remove 🗑.
  - Move the zoom control (□1) toward T (९) to switch to full-frame playback or W (□1) to switch to thumbnail playback.



- 2 Add fix to all images that you want to delete and then press the ® button to confirm the selection.
  - A confirmation dialog is displayed. Follow the instructions displayed in the monitor.

# Deleting Images in a Sequence

- If you press the m button and delete a key picture while only key pictures are displayed for sequences of images (\$\sum 71\$), all images in the sequence, including the key picture, are deleted.
- To delete individual images in a sequence, press the 🚳 button to display them one at a time and press the 🛍 button.

# Deleting the Last Image Captured While in Shooting Mode

When using shooting mode, press the **t** button to delete the last image that was saved.

# **Shooting Features**

# (Scene Auto Selector) Mode

The camera automatically selects the optimum scene mode when you frame an image, making it even easier to take images using settings that suit the scene.

Enter shooting mode → 🗖 (shooting mode) button → 🚟 (scene auto selector) mode → 🔞 button

 When you point the camera at the subject, the camera automatically selects the optimum scene mode from the list below and adjusts the shooting settings accordingly.

<b>2</b> *	Portrait (for taking close-up portraits of one or two people)
Źį	Portrait (for taking portraits of three or more people, or framing images with a large background size)
	Landscape
<b>2</b> 7°	Night portrait (for taking close-up portraits of one or two people)
	Night portrait (for taking portraits of three or more people, or framing images with a large background size)
E *	Night landscape
32*	Close-up
<b>7</b> 9¥	Backlighting (for taking images of subjects other than people)
<b>72</b> 1	Backlighting (for taking portrait images)
50E*	Other scenes

 The focus area depends on the composition of the image. When the camera detects a human face, it focuses on that face (\$\sum 64\$).

# Selecting Scene Modes

- When using digital zoom, **a** is selected as the shooting scene mode.
- In some shooting conditions, the camera may not select the appropriate scene mode that you intended. If this happens, switch to (auto) mode or select the scene mode that you want to use when taking images (22).

#### Functions Available in **(Scene Auto Selector)** Mode

- Flash mode (QQ49)
- Self-timer (\$\overline{\Omega}51\$)
- Exposure compensation (\$\sum\_54\$)

# **Scene Mode (Shooting Suited to Scenes)**

When a scene is selected, camera settings are automatically optimized for the selected scene.

\* The icon of the last scene selected is displayed.

2 Portrait (default setting)	■ Landscape <sup>1</sup>	❖ Sports <sup>2</sup> (◯◯35)	Night portrait (\$\square\$35)
Party/indoor <sup>2</sup> (CC) 35)	<b>₽</b> Beach <sup>2</sup>	<b>8</b> Snow <sup>2</sup>	Sunset <sup>2, 3</sup>
<b>≜</b> Dusk/dawn <sup>1, 3</sup>	■ Night landscape <sup>1</sup> (□36)	Close-up (QQ36)	<b>₹¶</b> Food (◯◯36)
<u>■</u> Museum <sup>2</sup> (◯◯37)	Fireworks show <sup>1, 3</sup> ( $\square$ 37)	Black and white copy <sup>2</sup> (QQ37)	■ Backlighting <sup>2</sup> (□37)
Easy panorama (C)38)	Pet portrait (CC) 39)		

The camera focuses at infinity.

#### To View a Description (Help Display) of Each Scene

Select a scene and move the zoom control ( $\square$ 1) toward T (?) to view a description of that scene. To return to the original screen, move the zoom control toward T (?) again.



The camera focuses on the area in the center of the frame.

<sup>&</sup>lt;sup>3</sup> Use of a tripod is recommended, because the shutter speed is slow. Set Vibration reduction to Off in the setup menu (□78) when using a tripod to stabilize the camera during shooting.

#### **Tips and Notes**

#### Sports

- While the shutter-release button is held all the way down, the camera shoots up to about 6 images continuously at a rate of about 2 fps (when image mode is set to 16...).
- The frame rate for continuous shooting may vary depending upon the current image mode setting, the memory card used, or shooting condition.
- Focus, exposure, and hue are fixed at the values determined with the first image in each series.

#### ■ Night portrait

- From the screen displayed after **Might portrait** is selected, select **Hand-held** or **Tripod**.
- Hand-held (default setting):
  - When the ☑ icon at the top left of the monitor glows green, press the shutter-release button all the way to capture a series of images which are combined into a single image and saved.
  - Once the shutter-release button is pressed all the way, hold the camera still until a still image is displayed. After taking an image, do not turn the camera off before the monitor switches to the shooting screen.
  - If the subject moves while the camera is shooting continuously, the image may be distorted, overlapped, or blurred.

#### • Tripod:

- One image is captured at a slow shutter speed when the shutter-release button is pressed all the way.
- Vibration reduction is disabled even when Vibration reduction (□78) in the setup menu is set to On.

## XX Party/indoor

 To avoid the effects of camera shake, hold the camera steady. Set Vibration reduction to Off in the setup menu (\$\sum\_78\$) when using a tripod to stabilize the camera during shooting.

#### ■ Night landscape

- From the screen displayed after Might landscape is selected, select Hand-held or Tripod.
- Hand-held (default setting):
  - When the  $\blacksquare$  icon at the top left of the monitor glows green, press the shutter-release button all the way to capture a series of images which are combined into a single image and saved.
  - Once the shutter-release button is pressed all the way, hold the camera still until a still image is displayed. After taking an image, do not turn the camera off before the monitor switches to the shooting screen.
  - The angle of view (i.e., the area visible in the frame) seen in the saved image is narrower than that seen in the monitor at the time of shooting.

#### • Tripod:

- One image is captured at a slow shutter speed when the shutter-release button is pressed all the way.
- Vibration reduction is disabled even when Vibration reduction (\$\infty\$78) in the setup menu is set to On.

#### Close-up

- Macro mode (\$\sum\_5\$3) is enabled and the camera automatically zooms to the closest position at
  which it can focus.

#### ¶¶ Food

- Macro mode (\$\sum\_{2}\$5) is enabled and the camera automatically zooms to the closest position at
  which it can focus.
- You can adjust hue by using the multi selector ▲▼. The hue setting is saved in the camera's memory even after the camera is turned off.



#### m Museum

- The camera captures a series of up to ten images while the shutter-release button is held all the
  way down, and the sharpest image in the series is automatically selected and saved (BSS (Best
  Shot Selector)).
- The flash does not fire.

#### Fireworks show

- The shutter speed is fixed at about four seconds.
- The zoom is restricted to four fixed positions.

#### ☐ Black and white copy

• Use together with macro mode (\$\sum\_{53}\$) when shooting subjects that are close to the camera.

#### Backlighting

- From the screen displayed after **El Backlighting** is selected, select **On** or **Off** to enable or disable the high dynamic range (HDR) function based on the type of image you want to take.
- Off (default setting): The flash fires to prevent the subject from being hidden in shadow.
- When the shutter-release button is pressed all the way down, one image is captured.
- $\bullet\,$   $\,$  On: Use when taking images with very bright and dark areas in the same frame.
  - When the shutter-release button is pressed all the way, the camera shoots images continuously at high speed, and saves the following two images.
    - A non-HDR composite image
    - An HDR composite image in which the loss of details in highlights or shadows is minimized
  - If there is only enough memory to save one image, an image processed by D-Lighting (\$\times\$70) at the time of shooting, in which dark areas of the image are corrected, is the only image saved.
  - Once the shutter-release button is pressed all the way, hold the camera still until a still image is displayed. After taking an image, do not turn the camera off before the monitor switches to the shooting screen.
  - The angle of view (i.e., the area visible in the frame) seen in the saved image is narrower than that seen in the monitor at the time of shooting.

#### Easy panorama

- From the screen displayed after 
   \sum Easy panorama is selected, select the shooting range from Normal (180°) or Wide (360°).
- The zoom position is fixed at wide-angle.
- Press the shutter-release button all the way down, remove your finger from the button, and then slowly pan the camera horizontally. Shooting ends when the camera captures the specified shooting range.
- Focus and exposure are locked when shooting starts.
- If you press the 
   Button when a captured image is displayed in full-frame playback mode, the
   image scrolls automatically.
- The images cannot be edited on this camera.

See "Using Easy Panorama (Shooting and Playback)" (��2) for more information.

# Notes About Printing Panorama Images

The entire image may not be able to be printed depending on the printer's settings. Additionally, printing may not be possible depending on the printer.

#### 😽 Pet portrait


- When you point the camera at a dog or cat, the camera detects the pet's face and focuses on it. By default, the shutter is automatically released when focus is acquired (pet portrait auto release).
- From the screen displayed after 😽 Pet portrait is selected, select Single or Continuous.
  - **Single**: Whenever the detected face is in focus, the camera captures one image.
  - Continuous: Whenever the detected face is in focus, the camera captures three images continuously.

#### Pet Portrait Auto Release

- - **\overline**: The camera detects a dog or cat face and automatically releases the shutter when the detected face is in focus.
  - OFF: The camera does not release the shutter automatically, even if a dog or cat face is detected.
     Press the shutter-release button. The camera also detects human faces when OFF is selected.
- Pet portrait auto release is set to OFF after five bursts have been taken.
- Shooting is also possible by pressing the shutter-release button, regardless of the Pet portrait
  auto release setting. When Continuous is selected, you can take images continuously while
  holding down the shutter-release button all the way.

#### Focus Area

- When the camera detects a face, the face is displayed inside a
  yellow border. When the camera acquires focus on a face
  displayed inside a double border (focus area), the double border
  turns green. If no faces are detected, the camera focuses on the
  subject in the center of the frame.
- In some shooting conditions, the pet face may not be detected and other subjects may be displayed inside a border.



# **Special Effects Mode (Applying Effects When Shooting)**

Effects can be applied to images during shooting.

Enter shooting mode  $\rightarrow \square$  (shooting mode) button  $\rightarrow S0$  (third icon from the top\*)  $\rightarrow \square$   $\rightarrow \square$   $\rightarrow \square$  select an effect  $\rightarrow \square$  button

\* The icon of the last effect selected is displayed.

Category	Description	
<b>\$0</b> Soft* (default setting)	Softens the image by adding a slight blur to the entire image.	
<b>SE</b> Nostalgic sepia*	Adds a sepia tone and reduces the contrast to simulate the qualities of an old photograph.	
☐ High-contrast monochrome	Changes the image to black and white and gives it sharp contrast.	
III High key	Gives the entire image a bright tone.	
Low key	Gives the entire image a dark tone.	
Selective color	Creates a black and white image in which only the specified color remains.	
POP Pop	Increases the color saturation of the entire image to create a bright look.	
VI Super vivid	Increases the color saturation of the entire image and sharpens the contrast.	
🛱 Painting	Gives the image a painting-like appearance.	
<b>♣1</b> Toy camera effect 1	Gives the entire image a yellowish hue and darkens the image periphery.	
₩2 Toy camera effect 2	eases the color saturation of the entire image and darkens the image shery.	
<b>३</b> Cross process	Gives the image a mysterious appearance based on a specific color.	
Iİ̀ū Mirror*	Creates a bilaterally symmetric image whose right half is an inverted mirror image of the left half.	

<sup>\*</sup> Some effects are not available when using certain **Movie options** (QQ75) settings.

- The camera focuses on the area in the center of the frame
- When **Selective color** or **Cross process** is selected, use the multi selector  $\blacktriangle \nabla$  to select the desired color from the slider

To change settings for any of the following functions, press the (R) button to cancel color selection.

- Flash mode (□□49)
- Self-timer (QQ51)
- Macro mode (CD53)
- Exposure compensation (\$\square\$54)

To return to the color selection screen, press the **®** button again.



# **Smart Portrait Mode (Capturing Images of Smiling Faces)**

When the camera detects a smiling face, you can take an image automatically without pressing the shutter-release button (smile timer ( $\square$ 59)). You can use the skin softening option to smooth the skin tones of human faces.

Enter shooting mode  $\Rightarrow \Box$  (shooting mode) button  $\Rightarrow \Box$  Smart portrait mode  $\Rightarrow$   $\bigcirc$  button

- **1** Frame the picture.
  - Point the camera at a human face.
- **2** Without pressing the shutter-release button, wait for the subject to smile.
  - If the camera detects that the face framed by the double border is smiling, the shutter is automatically released.
  - Whenever the camera detects a smiling face, it automatically releases the shutter.
- **3** End automatic shooting.
  - · Perform one of the operations listed below to end shooting.
    - Set Smile timer to Off.
    - Press the D button and select a different shooting mode.
- Notes About Smart Portrait Mode

Under some shooting conditions, the camera may be unable to detect faces or detect smiles ( $\square$ 64). The shutter-release button can also be used for shooting.



#### When the Self-timer Lamp Flashes

When using smile timer, the self-timer lamp flashes when the camera detects a face and flashes quickly immediately after the shutter is released.

#### **Functions Available in Smart Portrait Mode**

- Flash mode (□□49)
- Self-timer (QQ51)
- Exposure compensation (QQ 54)
- Smart portrait menu (\$\square\$57)

# (Auto) Mode

Used for general shooting. Settings can be adjusted to suit the shooting conditions and the type of shot you want to capture.

Enter shooting mode  $\Rightarrow$   $\square$  (shooting mode) button  $\Rightarrow$   $\square$  (auto) mode  $\Rightarrow$   $\square$  button

• You can change how the camera selects the area of the frame to focus on by changing the **AF area mode** setting (\$\subset\$58).

The default setting is **Target finding AF** ( $\square$ 63).

#### Functions Available in 🗖 (Auto) Mode

- Flash mode (QQ49)
- Self-timer (\$\omega\$51)
- Macro mode (□53)
- Exposure compensation (\$\square\$54)
- Shooting menu (\$\sum\_57\$)

## **Using Quick Effects**

When in (auto) mode, you can apply effects to images immediately after releasing the shutter.

- The edited image is saved as a separate file with a different name.
- Press the ® button when the image is displayed after it is taken in a (auto) mode.
  - When you press the MENU button or when no operations are performed for about five seconds, the monitor display returns to the shooting screen.
  - To not display the screen shown on the right, set Quick effects to Off in the shooting menu (□57).



- 2 Use the multi selector ▲▼◀▶ to select the desired effect and press the <sup>®</sup> button.
  - Move the zoom control (□1) toward T (९) to switch to full-frame playback or W (□1) to switch to thumbnail playback.
  - To exit without saving the edited image, press the MENU button. When a confirmation screen is displayed, select Yes and press the W button.
  - See "Ouick Effects: Changing Hue or Mood" ( 15) for information about the effect types.
- **3** Select **Yes** and press the **®** button.



# **Using the Self-timer with Gesture Control**

When you position the monitor facing forward in the same direction as the camera lens and move your hand toward an icon displayed on the monitor, the shutter is released after a countdown. You can also move your hand toward the other icons to control the zoom position or record a movie. This function is useful when taking self-portrait images or shooting from a short distance.

This function is available in **Portrait** and **Night portrait** scene modes, smart portrait mode, and (auto) mode.

- 1 Open the monitor and face it forward in the same direction as the camera lens ( $\square$ 3).
  - A message is displayed for about five seconds, and then
     (palm detection) is displayed in the center of the frame.



**2** Hold up your hand and align it with **1** in the center of the frame.



- When the camera detects your palm, 

   changes to 

   and the icons listed below are displayed in the four corners
   of the frame.
  - @: The camera captures a still image.
  - D: The camera starts recording a movie.
  - **1** The camera zooms out (wide-angle).
  - 1: The camera zooms in (telephoto).



# **3** Frame the picture.

- To adjust the zoom position, move your hand toward
   (wide-angle) or (telephoto). The zoom position changes one step at a time.
- If the camera is unable to detect your palm, try step 2 again.



# **4** Take the picture.

- When you move your hand toward to take a still image) or to to record a movie), the camera releases the shutter after a countdown (about three seconds).
- To end movie recording, press the 
   ( ™ movie-record) button on the camera body.
   See " Cutting Unwanted Scenes from Recorded Movies" ( ( ¬ ) 7 ).
- When shooting ends, the screen shown in step 2 is displayed again.





#### Notes About Gesture Control

- The camera may not detect your palm or hand movement in some shooting conditions.
- When moving your hand, hold up your palm vertically facing the camera, and maintain the same hand shape as you move it.
- Some functions are not available when using the gesture control function (\$\infty\$76).

# **Functions That Can Be Set Using the Multi Selector**

The functions that are available vary with the shooting mode, as shown below.



		(scene auto selector)	Scene	Special effects	Smart portrait	(auto)
1	<b>‡</b> Flash mode (□ 49)	✓*		~	✓*	~
2	♦ Self-timer (□151)	~		~	✓*	~
3	₩ Macro (🎞 53)	-	*	~	-	~
4	Exposure compensation (\$\sum_54\$)	~		~	~	~

<sup>\*</sup> Availability depends on the setting.

#### **Using the Flash**

You can select the flash mode to match the shooting conditions.

1 Press the multi selector ▲ (♣).




- 2 Select the desired flash mode (\$\sum\_50\$) and press the \( \mathbb{O} \) button.
  - If a setting is not applied by pressing the button within a few seconds, the selection will be canceled.



# The Flash Lamp

- The status of the flash can be confirmed by pressing the shutterrelease button halfway.
  - On: The flash fires when you press the shutter-release button all the way down.
  - Flashing: The flash is charging. The camera cannot shoot images.
  - Off: The flash does not fire when an image is taken.
- If the battery level is low, the monitor turns off while the flash is charging.



#### **Available Flash Modes**

#### \$ AllTI Auto

The flash fires when necessary, such as in dim lighting.

 The flash mode icon on the shooting screen is displayed only immediately after the setting is made.

#### 4 Auto with red-eye reduction

Reduce "red-eye" in portraits caused by the flash.

#### Off

The flash does not fire.

 We recommend using a tripod to stabilize the camera when shooting in dark surroundings.

#### 5 Fill flash

The flash fires whenever an image is taken. Use to "fill-in" (illuminate) shadows and backlit subjects.

#### \$∫∫₩ Slow sync

Suited to evening and night portraits that include background scenery.

The flash fires when necessary to illuminate the main subject; slow shutter speeds are used to capture background at night or under dim lighting.

## The Flash Mode Setting

- The setting may not be available with some shooting modes.
- The setting applied in (auto) mode is saved in the camera's memory even after the camera is turned off.

## Red-eye Reduction

If the camera detects red eye while saving an image, the affected area is processed to reduce red-eye before the image is saved.

Note the following when shooting:

- More time than usual is required to save images.
- Red-eye reduction may not produce the desired results in all situations.
- In some rare cases, red-eye reduction may be applied unnecessarily to other areas of the image. In these cases, select another flash mode and take the image again.

⊗10s

0FF

#### **Using the Self-timer**

The camera is equipped with a self-timer that releases the shutter about ten seconds or two seconds after you press the shutter-release button.

Set **Vibration reduction** to **Off** in the setup menu ( $\square$ 78) when using a tripod to stabilize the camera during shooting.

**1** Press the multi selector **◄** (**७**).



Self-timer

- 2 Select **3 10s** or **3 2s**, and press the **b**utton.
  - **© 10s** (ten seconds): Use on important occasions, such as weddings.
  - (\*) 2s (two seconds): Use to prevent camera shake.
  - If a setting is not applied by pressing the button within a few seconds, the selection will be canceled.
  - When the shooting mode is **Pet portrait** scene mode,

     (pet portrait auto release) is displayed (□39). The self-timer cannot be used.



· Focus and exposure are set.






# **4** Press the shutter-release button the rest of the way down.

- Countdown starts. The self-timer lamp flashes and then glows steadily about one second before the shutter is released.
- When the shutter is released, the self-timer is set to OFF.
- To stop the countdown, press the shutterrelease button again.







#### **Using Macro Mode**

Use macro mode when taking close-up images.

1 Press the multi selector ▼ (❤).



- **2** Select **ON** and press the **®** button.
  - If a setting is not applied by pressing the **®** button within a few seconds, the selection will be canceled.



3 Move the zoom control to set the zoom ratio to a position where ☑ and the zoom indicator glow green.



When the zoom ratio is set to a position where the zoom indicator glows green, the camera
can focus on subjects as close as approximately 10 cm (4 in.) from the lens.
 When the zoom is at the position where △ is displayed, the camera can focus on subjects
as close as approximately 2 cm (0.8 in.) from the lens.

#### Notes About Using the Flash

The flash may be unable to light the entire subject at distances of less than 50 cm (1 ft 8 in.).

#### The Macro Mode Setting

- The setting may not be available with some shooting modes.
- The setting applied in (auto) mode is saved in the camera's memory even after the camera is turned off.


#### **Adjusting Brightness (Exposure Compensation)**

You can adjust overall image brightness.

1 Press the multi selector ▶ (☑).



- 2 Select a compensation value and press the ® button.
  - To brighten the image, set a positive (+) value.
  - To darken the image, set a negative (-) value.
  - The compensation value is applied, even without pressing the 
     Button.



#### Exposure Compensation Value

The setting applied in  $\blacksquare$  (auto) mode is saved in the camera's memory even after the camera is turned off.

## **Default Settings**

Default settings for each shooting mode are described below.

	Flash (QQ49)	Self-timer (ДБ1)	Macro (◯◯53)	Exposure compensation (ДД54)
(scene auto selector)	\$ AUTO <sup>1</sup>	Off	Off <sup>2</sup>	0.0
Scene				
🙎 (portrait)	\$⊚	Off	Off <sup>3</sup>	0.0
(landscape)	<b>③</b> <sup>3</sup>	Off	Off <sup>3</sup>	0.0
❖ (sports)	<b>③</b> <sup>3</sup>	Off <sup>3</sup>	Off <sup>3</sup>	0.0
(night portrait)	<b>\$®</b> <sup>4</sup>	Off	Off <sup>3</sup>	0.0
(party/indoor)	<b>\$®</b> <sup>5</sup>	Off	Off <sup>3</sup>	0.0
(beach)	<b>\$</b> AUTO	Off	Off <sup>3</sup>	0.0
(snow)	<b>\$</b> AUTO	Off	Off <sup>3</sup>	0.0
👛 (sunset)	<b>③</b> <sup>3</sup>	Off	Off <sup>3</sup>	0.0
👛 (dusk/dawn)	<b>③</b> <sup>3</sup>	Off	Off <sup>3</sup>	0.0
★ (night landscape)	<b>3</b> 3	Off	Off <sup>3</sup>	0.0
🗱 (close-up)	<b>③</b>	Off	On <sup>3</sup>	0.0
¶¶ (food)	<b>③</b> <sup>3</sup>	Off	On <sup>3</sup>	0.0
<u></u> (museum)	<b>③</b> <sup>3</sup>	Off	Off	0.0
(fireworks show)	<b>③</b> <sup>3</sup>	Off <sup>3</sup>	Off <sup>3</sup>	0.03
(black and white copy)	3	Off	Off	0.0

	Flash (ДД49)	Self-timer (ДБ1)	Macro (◯◯53)	Exposure compensation (\$\square\$54)
(backlighting)	<b>\$</b> / <b>3</b> <sup>6</sup>	Off	Off <sup>3</sup>	0.0
🗖 (easy panorama)	<b>③</b> <sup>3</sup>	Off <sup>3</sup>	Off <sup>3</sup>	0.0
😽 (pet portrait)	<b>③</b> <sup>3</sup>	<b>5</b>	Off	0.0
<b>SO</b> (special effects)	<b>③</b>	Off	Off	0.0
(smart portrait)	\$AUTO <sup>8</sup>	Off <sup>9</sup>	Off <sup>3</sup>	0.0
(auto)	<b>\$</b> AUTO	Off	Off	0.0

The camera automatically selects the flash mode appropriate for the scene it has selected. (3) (off) can be selected manually.

<sup>&</sup>lt;sup>2</sup> Cannot be changed. The camera enters macro mode when **33** is selected.

<sup>&</sup>lt;sup>3</sup> The setting cannot be changed.

<sup>&</sup>lt;sup>4</sup> The setting cannot be changed. The flash mode setting is fixed at fill flash with red-eye reduction.

<sup>&</sup>lt;sup>5</sup> Slow sync with red-eye reduction flash mode may be used.

<sup>&</sup>lt;sup>6</sup> Flash is fixed at **\$** (fill flash) when **HDR** is set to **Off**, and is fixed at **\$** (off) when **HDR** is set to **On**.

<sup>&</sup>lt;sup>7</sup> Self-timer cannot be used. Pet portrait auto release can be turned on or off ( $\square$ 39).

<sup>8</sup> Cannot be used when Blink proof is set to On or when Smile timer is set to On (continuous) or On (BSS).

<sup>&</sup>lt;sup>9</sup> Can be set when **Smile timer** is set to **Off**.

## Functions That Can Be Set with the MENU Button (Shooting Menu)

The settings listed below can be changed by pressing the **MENU** button during shooting  $(\Box 4)$ .



The settings that can be changed vary depending on the shooting mode, as shown below.

	Scene auto selector	Scene <sup>2</sup>	Special effects	Smart portrait	Auto mode
Image mode <sup>1</sup>	~	~	~	~	~
White balance	-	-	-	-	~
Continuous	-	-	-	-	~
ISO sensitivity	-	-	-	-	~
Color options	-	-	-	-	~
AF area mode	-	-	-	-	~
Autofocus mode	-	-	-	-	~
Quick effects	-	-	-	-	~
Skin softening	-	-	-	~	-
Smile timer	-	-	-	~	-
Blink proof	-	-	-	~	-

<sup>&</sup>lt;sup>1</sup> The setting is also applied to other shooting modes.

Additional settings are available for some scene modes. See "Tips and Notes" (\$\sum\_35\$) for more information.

# **Options Available in the Shooting Menu**

Option	Description	m
Image mode	Allows you to set the combination of image size and image quality used when saving images.  • Default setting: 15. 4608×3456	<b>∂=</b> 034
White balance	Allows you to adjust white balance to suit the weather conditions or light source in order to make the colors in images match what you see with your eyes.  • Default setting: <b>Auto</b>	<b>≈</b> 36
Continuous	Allows you to select single or continuous shooting.  • Default setting: <b>Single</b>	<b>⇔</b> 39
ISO sensitivity	Allows you to control the camera's sensitivity to light.  • Default setting: <b>Auto</b> When <b>Auto</b> is selected, [S0] is displayed in the monitor while shooting if ISO sensitivity increases.	<b>6−</b> 642
Color options	Allows you to change the color tones of images.  • Default setting: <b>Standard color</b>	<b>6–6</b> 43
AF area mode	Allows you to determine how the camera selects the focus area that is used for autofocus.  ■ Default setting: <b>Target finding AF</b> (□63)	<b>6–6</b> 44
Autofocus mode	Allows you to select either <b>Single AF</b> , which focuses only when the shutter-release button is pressed halfway, or <b>Full-time AF</b> , which continues focusing even when the shutter-release button is not pressed halfway.  • Default setting: <b>Single AF</b>	<b>∂−0</b> 48
Quick effects	Allows you to enable or disable the quick effects function (\$\sum_45\$).  • Default setting: <b>On</b>	<b>6−6</b> 48

Option	Description	
Skin softening	Allows you to select the skin softening level for human faces.  • Default setting: <b>Normal</b>	<b>6-6</b> 49
Smile timer	Allows you to select whether or not the camera automatically releases the shutter when it detects a human smiling face.  Default setting: <b>On (BSS)</b>	<b>⇔</b> 50
Blink proof	The camera automatically releases the shutter twice with every shot and saves one image in which the subject's eyes are open.  • Default setting: <b>Off</b>	<b>6−6</b> 51

# **Functions That Cannot Be Used Simultaneously**

Some functions cannot be used with other menu options.

Restricted function	Option	Description
	Continuous (🎞 58)	When a setting other than <b>Single</b> is selected, the flash cannot be used.
Flash mode	Blink proof (QQ59)	When <b>Blink proof</b> is set to <b>On</b> , the flash cannot be used.
	Smile timer (🎞 59)	When <b>On (continuous)</b> or <b>On (BSS)</b> is selected, the flash cannot be used.
Self-timer	Smile timer (🎞 59)	When <b>Smile timer</b> is selected, the self-timer cannot be used.
sen-umer	AF area mode (\$\implies58\$)	When <b>Subject tracking</b> is selected, the self-timer cannot be used.
Macro mode	mode AF area mode (\$\iii58\$) When <b>Subject tracking</b> is sel mode cannot be used.	
Image mode	Continuous (\$\implies\$58)	Image mode is set as follows depending on the continuous shooting setting:  • Continuous H: 120 fps: ((i) (image size: 640 × 480 pixels)  • Continuous H: 60 fps: ((i) (image size: 1280 × 960 pixels)  • Multi-shot 16: (image size: 2560 × 1920 pixels)
White balance Color options (\$\square\$58\$) <b>Cyanotype</b> is selected		When Black-and-white, Sepia, or Cyanotype is selected, the White balance setting is fixed at Auto.

Restricted function	Option	Description
Continuous	Self-timer (◯◯ 51)	If the self-timer is used when <b>Pre-shooting cache</b> is selected, the setting changes to <b>Single</b> .
ISO sensitivity Continuous (\$\subset\$58) 120 fps, Continuous H: 60 fps, or N shot 16 is selected, the ISO sensitiv		When Pre-shooting cache, Continuous H: 120 fps, Continuous H: 60 fps, or Multi-shot 16 is selected, the ISO sensitivity setting is automatically specified according to the brightness.
AF area mode	AF area mode White balance (\$\square\$58\$) When a setting other than <b>Auto</b> is <b>White balance</b> in <b>Target findin</b> the camera does not detect the m	
Quick effects	uick effects Continuous (\$\sum_58\$) The quick effects function cannot be uimages with continuous shooting.	
		When Blink proof is set to On, Smile timer is fixed at On (single) if On (continuous) or On (BSS) is set.
Rlink proof Smile timer (L. 150)		When Smile timer is set to On (continuous) or On (BSS), Blink proof is fixed at Off.
Monitor settings Quick effects (\$\subseteq\$58) When Quick effects is set to review is fixed at On.		When <b>Quick effects</b> is set to <b>On</b> , <b>Image review</b> is fixed at <b>On</b> .
Print date Continuous (QQ 58) 120 fps, or Continuous H: 60 f		When <b>Pre-shooting cache, Continuous H: 120 fps</b> , or <b>Continuous H: 60 fps</b> is selected, date and time cannot be imprinted on images.

Restricted function	Option	Description
	Continuous (\$\sum_58\$)	When a setting other than <b>Single</b> is selected, <b>Motion detection</b> is disabled.
Motion detection	ISO sensitivity (🎞 58)	When the ISO sensitivity is set to any setting other than <b>Auto</b> , <b>Motion detection</b> is disabled.
	AF area mode (\$\imp\u00e458\$)	When <b>Subject tracking</b> is selected, <b>Motion detection</b> is disabled.
	Smile timer (🎞 59)	When <b>On (continuous)</b> or <b>On (BSS)</b> is selected, <b>Motion detection</b> is disabled.
Blink warning	Continuous (\$\sum_58\$)	When a setting other than <b>Single</b> is selected, <b>Blink warning</b> is disabled.
Digital zoom	Continuous (\$\sum_58\$)	When <b>Multi-shot 16</b> is selected, digital zoom cannot be used.
	AF area mode (\$\implies58\$)	When <b>Subject tracking</b> is selected, digital zoom cannot be used.
		When a setting other than <b>Single</b> is selected, the shutter sound is disabled.

# Notes About Digital Zoom

- Depending on the shooting mode or the current settings, digital zoom may not be available (��79).
- When digital zoom is in effect, the camera focuses in the center of the frame.


# **Focusing**

The focus area varies depending on the shooting mode.

#### **Using Target Finding AF**


When **AF area mode** ( $\square$ 58) in  $\square$  (auto) mode is set to **Target finding AF**, the camera focuses in the manner described below when you press the shutter-release button halfway.

 The camera detects the main subject and focuses on it.
 When the subject is in focus, the focus area glows green. If a human face is detected, the camera automatically sets focus priority on it.



Focus areas

 If no main subject is detected, the camera automatically selects one or more of the nine focus areas containing the subject closest to the camera. When the subject is in focus, the focus areas that are in focus glow green.



Focus areas


## Notes About Target Finding AF

- Depending on shooting conditions, the subject that the camera determines to be the main subject may vary.
- $\bullet\,$  The main subject may not be detected when using certain  $\boldsymbol{White}$   $\boldsymbol{balance}$  settings.
- The camera may not detect the main subject appropriately in the following situations:
  - When the subject is very dark or bright
  - When the main subject lacks clearly defined colors
  - When the shot is framed so that the main subject is at the edge of the monitor
  - When the main subject is composed of a repeating pattern

#### **Using Face Detection**

In the following shooting modes, the camera uses face detection to automatically focus on human faces.

- (scene auto selector) mode (QQ32)
- Portrait or Night portrait scene mode (QQ34)
- Smart portrait mode (□ 42)
- When AF area mode (□58) in (auto) mode (□44) is set to Face priority.



Ó

**25**m 0s

If the shutter button is pressed halfway when no faces are detected:

- In **(scene auto selector)** mode, the focus area changes depending on the scene.
- In **Portrait** and **Night portrait** scene modes or in smart portrait mode, the camera focuses on the area in the center of the frame.
- In a (auto) mode, the camera selects the focus area containing the subject closest to the camera.

#### Notes About Face Detection

- The camera's ability to detect faces depends on a variety of factors, including the direction in which the faces are looking.
- The camera may be unable to detect faces in the following situations:
  - When faces are partially hidden by sunglasses or otherwise obstructed
  - When faces take up too much or too little of the frame

#### **Using Skin Softening**

When the shutter is released while using one of the shooting modes listed below, the camera detects human faces and processes the image to soften facial skin tones (up to three faces).

- Smart portrait mode ( 42)
  - The skin softening level can be adjusted.
- M (scene auto selector) mode (M32)
- Portrait or Night portrait scene mode (QQ34)

Editing functions such as **Skin softening** can be applied to saved images by using **Glamour retouch** ( $\bigcirc$ 70) even after shooting.

#### Notes About Skin Softening

- It may take more time than usual to save images after shooting.
- Under some shooting conditions, the desired skin softening results may not be achieved, and skin softening may be applied to areas of the image where there are no faces.

#### **Subjects Not Suitable for Autofocus**

The camera may not focus as expected in the following situations. In some rare cases, the subject may not be in focus despite the fact that the focus area or the focus indicator glows green:

- · Subject is very dark
- Objects of sharply differing brightness are included in the scene (e.g. the sun behind the subject makes that subject appear very dark)
- No contrast between the subject and surroundings (e.g. a portrait subject wearing a white shirt is standing in front of a white wall)
- Several objects are at different distances from the camera (e.g. the subject is inside a cage)
- Subjects with repeating patterns (window blinds, buildings with multiple rows of similarly shaped windows, etc.)
- · Subject is moving rapidly

In the situations noted above, try pressing the shutter-release button halfway to refocus several times, or focus on another subject positioned at the same distance from the camera as the actual desired subject, and use focus lock ( $\square$ 67).

#### **Focus Lock**

Focus lock shooting is recommended when the camera does not activate the focus area that contains the desired subject.

- 1 Set **AF area mode** to **Center** in **(auto)** mode ((()57)).
- **2** Position the subject in the center of the frame and press the shutter-release button halfway.
  - Confirm that the focus area glows green.
  - Focus and exposure are locked.





- Without lifting your finger, recompose the picture.
  - Make sure to maintain the same distance between the camera and the subject.




**4** Press the shutter-release button the rest of the way down to take the picture.



# **Playback Features**

## **Playback Zoom**

Moving the zoom control toward  $\mathbf{T}(\mathbf{Q})$  in full-frame playback mode ( $\square$ 28) zooms in on the image.



- You can change the zoom ratio by moving the zoom control toward W (►) or T (?).
- To view a different area of the image, press the multi selector ▲▼◀▶.
- When a zoomed image is displayed, press the button to return to full-frame playback mode.

# Cropping Images

When a zoomed image is displayed, you can press the **MENU** button to crop the image to include only the visible portion and save it as a separate file ( $\clubsuit$ 21).

# Thumbnail Playback, Calendar Display

Moving the zoom control toward  $\mathbf{W}$  ( $\blacksquare$ ) in full-frame playback mode ( $\square$ 28) displays images as thumbnails.



- You can change the number of thumbnails displayed by moving the zoom control toward
   W ( ) or T (Q).
- While using thumbnail playback mode, press the multi selector ▲▼◀▶ to select an image and then press the ® button to display that image in full-frame playback mode.
- While using calendar display mode, press ▲ ▼ ◆ to select a date and then press the who button to display the images captured on that day.

# **C**alendar Display

Images captured when the camera's date is not set are treated as images captured on January 1, 2013.

# Functions That Can Be Set with the MENU Button (Playback Menu)

When viewing images in full-frame playback mode or thumbnail playback mode, you can configure the menu operations listed below by pressing the **MENU** button ( $\square$ 4).

Option	Description	Ш
Quick retouch*	Allows you to create retouched copies in which contrast and saturation have been enhanced.	<b>≈</b> 16
D-Lighting*	Allows you to create copies with enhanced brightness and contrast, brightening dark portions of an image.	<b>6</b> €16
Red-eye correction*	Corrects "red-eye" that may occur in images when shooting with a flash.	<b>6−6</b> 17
Glamour retouch*	Detects faces in images and retouches the detected faces glamorously.	<b>≈</b> 18
Print order	Allows you to select which images are printed, and how many copies of each image are printed, prior to printing.	<b>6−6</b> 52
Slide show	Allows you to view images in an automatic slide show.	<b>6</b> 56
Protect	Protects selected images from accidental deletion.	<b>6-6</b> 57
Rotate image	Allows you to rotate the displayed image to portrait or landscape orientation.	<b>6-6</b> 59
Small picture*	Creates a small copy of images.	<b>6→</b> 20
Voice memo	Allows you to use the camera's microphone to record voice memos and attach them to images.	<b>6</b> 0

Option	Description	Φ
Сору	Allows you to copy images between the internal memory and a memory card.	<b>6</b> 61
Sequence display options	Allows you to select whether to display only the key picture for a sequence of images captured continuously or to display the sequence as individual images.  • When only the key picture is displayed for a sequence, press the   • button to display each image in the sequence. Press the multi selector   • to return to the key picture display.	<b>6</b> €63
Choose key picture	Allows you to change the key picture for images captured in sequence.	<b>6</b> 63
Favorite pictures	Allows you to add images to an album. This option is not displayed in favorite pictures mode.	<b>6</b> €6
Remove from favorites	Allows you to remove images from an album. This option is displayed only in favorite pictures mode.	<b>≈</b> 8

<sup>\*</sup> Edited images are saved as separate files. Some images may not be edited.

# **Recording and Playing Back Movies**

## **Recording Movies**

- **1** Display the shooting screen.
  - · Check the remaining amount of movie recording time.
  - If Photo info in the Monitor settings (☐78) in the setup menu is set to Movie frame+auto info, the area that will be visible in the movie can be confirmed before movie recording starts.



Movie recording time remaining

- 2 Press the ( make movie-record) button to start movie recording.
  - The camera focuses on the subject in the center of the frame





3 Press the ● (ト਼ movie-record) button again to end recording.

#### Maximum Movie Length

Individual movie files cannot exceed 4 GB in size or 29 minutes in length, even when there is sufficient free space on the memory card for longer recording.

- The maximum movie length for a single movie is displayed on the shooting screen.
- Recording may end before either limit is reached if camera temperature becomes elevated.
- The actual movie length may vary depending on the movie content, subject movement, or type of memory card.

#### Notes About Saving Images and Recording Movies

The indicator showing the number of exposures remaining or the indicator showing the maximum movie length flashes while images are being saved or while a movie is being recorded. **Do not open the battery-chamber/memory card slot cover or remove the battery or memory card** while an indicator is flashing. Doing this could result in loss of data, or in damage to the camera or the memory card.

#### Notes About Movie Recording

- Memory cards with an SD Speed Class rating of 6 or faster are recommended when recording
  movies (22). Movie recording may stop unexpectedly when memory cards with a lower Speed
  Class rating are used.
- There may be some degradation in image quality when digital zoom is used.
- The sounds of zoom control operation, zoom, autofocus lens drive movement, vibration reduction, and aperture operation when brightness changes may be recorded.
- The following phenomena may be seen in the monitor while recording movies. These
  phenomena are saved in the recorded movies.
  - Banding may occur in images under fluorescent, mercury-vapor, or sodium-vapor lighting.
  - Subjects that move quickly from one side of the frame to the other, such as a moving train or car, may appear skewed.
  - The entire movie image may be skewed when the camera is panned.
  - Lighting or other bright areas may leave residual images when the camera is moved.
- Depending on the distance to the subject or the amount of zoom applied, subjects with repeating
  patterns (fabrics, lattice windows, etc.) may have colored stripes (interference patterns, moire, etc.)
  in them during movie recording and playback. This occurs when the pattern in the subject and the
  layout of the image sensor interfere with each other; it is not a malfunction.

#### Camera Temperature

- The camera may become warm when shooting movies for an extended period of time or when the camera is used in a hot area.
- If the inside of the camera becomes extremely hot when recording movies, the camera will automatically stop recording.
  - The amount of time remaining until the camera stops recording (  ${}^{\textcircled{\mbox{\it d}}}$  10s) is displayed. After the camera stops recording, it turns itself off.
- Leave the camera off until the inside of the camera has cooled.

#### Notes About Autofocus

Autofocus may not perform as expected (QQ66). Should this occur, try the following:

- Set Autofocus mode in the movie menu to Single AF (default setting) before starting movie recording.
- 2. Frame another subject—positioned at the same distance from the camera as the intended subject—in the center of the frame, press the (\*★ movie-record) button to start recording, and then modify the composition.

# Functions That Can Be Set with the MENU Button (Movie Menu)

Enter shooting mode → MENU button → 🐂 menu icon → 👀 button

The settings of the menu options listed below can be configured.



Option	Description	Ф
Movie options	Select the movie type. Select normal speed to record movies at normal speed, or HS (high speed) to record movies that play in slow or fast motion.  Default setting: ⋯ 1080★/30p (⋯ 1080★/25p)	<b>6</b> €64
Open with HS footage	Set whether to start recording at high speed or normal speed when recording HS movies.  • Default setting: <b>On</b>	<b>6</b> 68
Autofocus mode	Select either <b>Single AF</b> , which locks focus when movie recording begins, or <b>Full-time AF</b> , which continues focusing during movie recording.  • Default setting: <b>Single AF</b>	<b>6</b> 68
Wind noise reduction	Set whether or not to reduce wind noise during movie recording.  • Default setting: <b>Off</b>	<b>6</b> 69

# **Playing Back Movies**

Press the ▶ button to enter playback mode. Movies are indicated by the movie options icon (△75). Press the ❸ button to play back movies.

• To adjust the volume, move the zoom control (\(\simple 1\)).



Movie options



Volume indicator

#### **Functions Available During Playback**

Playback controls are displayed at the bottom of the monitor. The operations listed below can be performed by using the multi selector **P** to select a control and then pressing the **B** button



Function	lcon		Description		
Rewind	*	Hold d	Hold down the 🚳 button to rewind the movie.		
Advance	*	Hold d	Hold down the 🕦 button to advance the movie.		
	Pause playback. The operations listed below can be performed while				
		<b>4</b> II	Rewind the movie one frame. Hold down the <b>®</b> button for continuous rewinding.		
Pause		⊪	Advance the movie one frame. Hold down the 🔞 button for continuous advancing.		
			Resume playback.		
	×	×	Extract the desired portion of a movie and save it as a separate file.		
End		Return	Return to full-frame playback mode.		

#### Cutting Unwanted Scenes from Recorded Movies

If a movie recorded using the gesture control function contains an unwanted scene of you stopping the recording (\(\sum47\)), pause the movie during playback and follow the steps below to edit it.

- 1. Select 🔣 in the playback controls, and then press the 🚳 button.
- 2. Select  $\mbox{\em X}\mbox{\em C}$  (choose end point) in the editing controls.
- 3. Select 🗂 (save) and press the 🔞 button.

#### **Deleting movies**

To delete a movie, select the desired movie in full-frame playback mode ( $\square$ 28) or thumbnail playback mode ( $\square$ 69) and press the  $\stackrel{\leftarrow}{\mathbf{m}}$  button ( $\square$ 30).

# **General Camera Setup**

# Functions That Can Be Set with the MENU Button (Setup Menu)

Press the MENU button  $\rightarrow \Upsilon$  (setup) menu icon  $\rightarrow \Re$  button

The settings of the menu options listed below can be configured.



Option	Description	TIP TIP
Welcome screen	Allows you to select whether or not the welcome screen is displayed when the camera is turned on.	<b>≈</b> 70
Time zone and date	Allows you to set the camera clock.	<b>∂−6</b> 71
Monitor settings	Allows you to adjust photo information display, post-shooting image review, and monitor brightness settings.	<b>6−6</b> 73
Print date	Allows you to imprint the shooting date and time on images.	<b>∂−6</b> 75
Gesture control	Allows you to set whether or not the gesture control function (\$\sum 46\$) is enabled when you position the monitor facing forward in the same direction as the camera lens.	<b>≈</b> 76
Vibration reduction	Allows you to select the vibration reduction setting used when shooting.	<b>6-6</b> 77

Option	Description	
Motion detection	Allows you to set whether or not the camera automatically increases the shutter speed to reduce blurring caused by camera shake if motion is detected when shooting still images.	<b>6−6</b> 78
AF assist	Allows you to enable or disable the AF-assist illuminator.	<b>∂=</b> 079
Digital zoom	Allows you to enable and disable digital zoom.	<b>∂=</b> 079
Sound settings	Allows you to adjust sound settings.	<b>≈</b> 80
Auto off	Allows you to set the amount of time that passes before the monitor turns off to save power.	<b>≈</b> 80
Format memory/ Format card	Allows you to format the internal memory or the memory card.	<b>≎</b> 81
Language	Allows you to change the camera's display language.	<b>6−6</b> 82
TV settings	Allows you to adjust TV-connection settings.	<b>6−6</b> 82
Charge by computer	Allows you to set whether or not the battery in the camera is charged when the camera is connected to a computer.	<b>⇔</b> 83
Blink warning	Allows you to set whether or not closed eyes are detected when taking images of people using face detection.	<b>6</b> 84
Wi-Fi options	Allows you to configure the Wi-Fi (wireless LAN) settings to connect the camera and a smart device.  See "Using the Wi-Fi (Wireless LAN) Function" (\$\square\$180) for more information.	<b>6</b> 85
Eye-Fi upload	Allows you to set whether or not to enable the function for sending images to a computer using a commercially available Eye-Fi card.	<b>≈</b> 87
Reset all	Allows you to reset the camera's settings to their default values.	<b>≈</b> 88
Firmware version	View the current camera firmware version.	<b>∂=</b> 088

# Using the Wi-Fi (Wireless LAN) Function

# **Functions That Can Be Performed Using Wi-Fi**

You can perform the following functions if you install the dedicated software "Wireless Mobile Utility" on your smart device that runs on Android OS or iOS, and connect it to the camera.

#### **Take Photos**

You can take still images using the two methods described below.

- Release the shutter on the camera and save the captured images to a smart device.
- Use a smart device to remotely\* release the camera shutter and save images to the smart device.
  - \* Operations cannot be performed on the camera during remote control operation.

#### **View Photos**

You can copy the pictures saved in the camera's memory card to your smart device.

# Installing the Software on the Smart Device

- 1 Use your smart device to connect to Google Play Store, App Store or other online apps marketplace and search for "Wireless Mobile Utility."
  - Check the user's manual provided with your smart device for further details.
- **2** Check the description and other information and install the software.
  - For more information about how to operate the software, download the user's manual from the website below.
    - Android OS: http://nikonimglib.com/ManDL/WMAU/
    - iOS: http://nikonimglib.com/ManDL/WMAU-ios/

# **Connecting the Smart Device to the Camera**

Press the MENU button → 🕆 menu icon → Wi-Fi options → 🚳 button

1 Use the multi selector ▲▼ to select the Wi-Fi network and press the ® button.



2 Select **On** and press the **®** button.



- SSID and the password are displayed.
- If no connection confirmation is received from the smart device within 3 minutes, the setting returns to Off.



# **3** Set the Wi-Fi setting on the smart device to On.

- Check the user's manual provided with your smart device for further details.
- After the network name (SSID) that can be used for the smart device is displayed, select the SSID displayed on the camera.
- When the message for entering a password is displayed, enter the password that is displayed on the camera.
- When the camera is successfully connected to a Wi-Fi network, the shooting screen is displayed with the Wi-Fi icon (\(\infty\)7).

#### 4 Start the dedicated software installed on the smart device.

- The screen for selecting "Take photos" or "View photos" is displayed.
- When the message "Cannot connect to camera." is displayed, retry the Wi-Fi network setting.

#### To Terminate the Wi-Fi Connection

- Turn off the camera.
- Set the Wi-Fi setting on the smart device to Off.

#### Notes About Wi-Fi Connection

- Set the Wi-Fi network to Off in a place where the use of radio waves is prohibited.
- When a memory card is not inserted in the camera, the Wi-Fi function cannot be used. When Eye-Fi card (♠87) is inserted in the camera, the Wi-Fi function cannot be used.
- When Wi-Fi is connected, Auto off is disabled.
- When the Wi-Fi network is set to On, the battery drains faster than normal.

Use **Wi-Fi options** of the setup menu  $(\square 79)$  to perform the security settings.

The Wi-Fi network cannot be selected when the battery level indicator in the monitor indicates
 In addition, if the battery level indicator indicates
 while a Wi-Fi connection is established, the connection is terminated.


## Notes About Security Settings

If the camera is installed with the Wi-Fi function without proper security settings (encryption and password), unauthorized third parties may access the network and cause harm. We strongly recommend performing the required security settings before using the Wi-Fi function.

# Connecting the Camera to a TV, Computer, or Printer

#### **Connection Methods**

You can enhance your enjoyment of images and movies by connecting the camera to a TV, computer, or printer.



- Before connecting the camera to an external device, make sure the remaining battery level is sufficient and turn the camera off. Before disconnecting, make sure to turn the camera off.
- If the AC Adapter EH-62G (available separately) is used, this camera can be powered from an electrical outlet. Do not use any other make or model of AC adapter as it may cause the camera to heat up or malfunction.
- For information about the connection methods and subsequent operations, refer to the documentation included with the device in addition to this document.



Images and movies captured with the camera can be viewed on a TV. Connection method: Connect the video and audio plugs of an optional audio video cable to the TV's input jacks. Alternatively, connect a commercially available HDMI cable to the TV's HDMI input jack.

#### Viewing and organizing images on a computer





You can transfer images to a computer to perform simple retouching and manage image data.

Connection method: Connect the camera to the computer's USB port with the USB cable.

- Before connecting to a computer, install ViewNX 2 on the computer (□85). For information about using the ViewNX 2 CD-ROM and transferring images to a computer, see page □85.
- If any USB devices that draw the power from the computer are connected, disconnect them from the computer before you connect the camera to it. Connecting the camera and other USB-powered devices to the same computer simultaneously may cause a camera malfunction or excessive power supply from the computer, which could damage the camera or memory card.

#### Printing images without using a computer





If you connect the camera to a PictBridge-compatible printer, you can print images without using a computer.

Connection method: Connect the camera directly to the printer's USB port with the USB cable.

# **Using ViewNX 2**

ViewNX 2 is an all-in-one software package which enables you to transfer, view, edit and share images. Install ViewNX 2 using the included ViewNX 2 CD-ROM.



#### **Installing ViewNX 2**

• An Internet connection is required.

#### **Compatible Operating Systems**

#### Windows

Windows 8, Windows 7, Windows Vista, Windows XP

#### Macintosh

Mac OS X10.6, 10.7, 10.8

Refer to the Nikon website for details on system requirements, including the latest information on operating system compatibility.

# Start the computer and insert the ViewNX 2 CD-ROM into the CD-ROM drive.

- Windows: If instructions for operating the CD-ROM are displayed in the window, follow the instructions to proceed to the installation window.
- Mac OS: When the ViewNX 2 window is displayed, double-click the Welcome icon.

# 2 Select a language in the language selection dialog to open the installation window

- If the desired language is not available, click Region Selection to choose a different region
  and then choose the desired language (the Region Selection button is not available in the
  European release).
- Click Next to display the installation window.



#### **3** Start the installer.

- We recommend clicking Installation Guide in the installation window to check the installation help information and system requirements before installing ViewNX 2.
- Click **Typical Installation (Recommended)** in the installation window.

#### **4** Download the software.

- When the **Software Download** screen is displayed, click **I agree Begin download**.
- Follow the on-screen instructions to install the software.

## **5** Exit the installer when the installation completion screen is displayed.

- Windows: Click Yes.
- Mac OS: Click OK.

#### The following software is installed:

- ViewNX 2 (consisting of the three modules below)
  - Nikon Transfer 2: For transferring images to the computer
  - ViewNX 2: For viewing, editing, and printing transferred images
  - Nikon Movie Editor: For basic editing of transferred movies
- Panorama Maker (for creating a single panorama image of a landscape, etc. from a series of images that each capture a separate portion of the subject)
- **6** Remove the ViewNX 2 CD-ROM from the CD-ROM drive.


## **Transferring Images to the Computer**

#### 1 Choose how images will be copied to the computer.

Choose one of the following methods:

Direct USB connection: Turn the camera off and ensure that the memory card is inserted
in the camera. Connect the camera to the computer using the USB cable. The camera
automatically turns on.

To transfer images that are saved in the camera's internal memory, remove the memory card from the camera before connecting it to the computer.



- SD card slot: If your computer is equipped with an SD card slot, the card can be inserted directly in the slot.
- **SD card reader**: Connect a card reader (available separately from third-party suppliers) to the computer and insert the memory card.

If a message is displayed prompting you to choose a program, select Nikon Transfer 2.

#### • When using Windows 7

If the dialog shown at right is displayed, follow the steps below to select Nikon Transfer 2.

1 Under Import pictures and videos, click Change program. A program selection dialog will be displayed; select Import File using Nikon Transfer 2 and click OK.



2 Double-click Import File.

If the memory card contains a large number of images, it may take a while for Nikon Transfer 2 to start. Wait until Nikon Transfer 2 starts.

# Connecting the USB Cable

The connection may not be recognized if the camera is connected to the computer via a USB hub.

# **2** Transfer images to the computer.

- Confirm that the name of the connected camera or removable disk is displayed as the "Source" on the "Options" title bar of Nikon Transfer 2 (1).
- Click Start Transfer (2).



• At default settings, all the images on the memory card will be copied to the computer.

#### 3 Terminate the connection.

If the camera is connected to the computer, turn the camera off and disconnect the USB
cable. If you are using a card reader or card slot, choose the appropriate option in the
computer operating system to eject the removable disk corresponding to the memory card
and then remove the card from the card reader or card slot.

## **Viewing Images**

#### Start ViewNX 2

- Images are displayed in ViewNX 2 when transfer is complete.
- Consult online help for more information on using ViewNX 2.



# Starting ViewNX 2 Manually

- Windows: Double-click the ViewNX 2 shortcut on the desktop.
- Mac OS: Click the ViewNX 2 icon in the Dock.



# Technical Notes and Index

Caring for the Product	b-2
The Camera	
The Battery	<b>&amp;</b> -3
Charging AC Adapter	<i>\tilde\ta</i> -4
Memory Cards	<i>\</i> \$-5
Cleaning and Storage	b-6
Cleaning	
Storage	<i>\tilda_</i> -6
Troubleshooting	b-7
Specifications	ఏ-17
Approved Memory Cards	
Index	

# **Caring for the Product**

#### The Camera

To ensure continued enjoyment of this Nikon product, observe the precautions described below in addition to the warnings in "For Your Safety" (\(\subseteq\) viii-x) when using or storing the device.

# Do Not Drop

The product may malfunction if subjected to strong shock or vibration.

## Handle the Lens and All Moving Parts with Care

Do not apply force to the lens, lens cover, monitor, memory card slot, or battery chamber. These parts are easily damaged. Applying force to the lens cover could result in camera malfunction or damage to the lens. Should the monitor break, care should be taken to avoid injury caused by broken glass and to prevent the liquid crystal from the display touching the skin or entering the eyes or mouth.

# Keep Dry

The device will be damaged if immersed in water or subjected to high humidity.

# Avoid Sudden Changes in Temperature

Sudden changes in temperature, such as when entering or leaving a heated building on a cold day, can cause condensation to form inside the device. To prevent condensation, place the device in a carrying case or a plastic bag before exposing it to sudden changes in temperature.

# Keep away from Strong Magnetic Fields

Do not use or store this device in the vicinity of equipment that generates strong electromagnetic radiation or magnetic fields. Strong static charge or the magnetic fields produced by equipment such as radio transmitters could interfere with the monitor, damage data saved on the memory card, or affect the product's internal circuitry.

# Do Not Point the Lens at Strong Light Sources for Extended Periods

Avoid pointing the lens at the sun or other strong light sources for extended periods when using or storing the camera. Intense light may cause deterioration of the image sensor, producing a white blur effect in photographs.

# Turn the Product off Before Removing or Disconnecting the Power Source

Do not remove the battery while the product is on, or while images are being saved or deleted. Forcibly cutting power in these circumstances could result in loss of data or in damage to product memory or internal circuitry.

#### Notes About the Monitor

- Monitors and electronic viewfinders are constructed with extremely high precision; at least 99.99%
  of pixels are effective, with no more than 0.01% being missing or defective. Hence while these
  displays may contain pixels that are always lit (white, red, blue, or green) or always off (black), this is
  not a malfunction and has no effect on images recorded with the device.
- Images in the monitor may be difficult to see under bright lighting.
- The monitor is lit by an LED backlight. Should the monitor begin to dim or flicker, contact your Nikon-authorized service representative.

## **The Battery**

Be sure to read and follow the warnings in "For Your Safety" (QQviii-x) before use.

- Check the battery level before using the camera and replace or charge the battery if necessary. Do
  not continue charging once the battery is fully charged as this will result in reduced battery
  performance. Whenever possible, carry a fully charged spare battery when taking images on
  important occasions.
- Do not use the battery at ambient temperatures below 0°C (32°F) or above 40°C (104°F).
- Charge the battery indoors with an ambient temperature of 5°C to 35°C (41°F to 95°F) before use.
- When charging the battery inserted into this camera using the Charging AC Adapter or a computer, the battery is not charged at battery temperatures below 0°C (32°F) or above 45°C (113°F).

- Note that the battery may become hot during use; wait for the battery to cool before charging. Failure to observe these precautions could damage the battery, impair its performance, or prevent it from charging normally.
- On cold days, the capacity of batteries tends to decrease. If an exhausted battery is used at a low
  temperature, the camera will not turn on. Be sure that the battery is fully charged before heading
  outside to take images in cold weather. Keep spare batteries in a warm place and exchange as
  necessary. Once warmed, a cold battery may recover some of its charge.
- Dirt on the battery terminals can prevent the camera from functioning. Should the battery terminals become dirty, wipe them off with a clean, dry cloth before use.
- If the battery will not be used for some time, insert it in the camera and completely exhaust it
  before removing it for storage. The battery should be stored in a cool location with an ambient
  temperature of 15°C to 25°C (59°F to 77°F). Do not store the battery in hot or extremely cold
  locations.
- Always remove the battery from the camera or optional battery charger when it is not being used.
   When inserted, minute amounts of current are drawn from the battery even when not in use. This may result in excessive draining of the battery and complete loss of function. Turning the camera on or off while the battery is exhausted can result in reduced battery life.
- Recharge the battery at least once every six months and completely exhaust it before returning it to storage.
- After removing the battery from the camera or optional battery charger, put the battery in the included battery case and store it in a cool place.
- A marked drop in the time a fully-charged battery retains its charge, when used at room temperature, indicates that the battery needs to be replaced. Purchase a new EN-EL19 battery.
- Replace the battery when it no longer holds a charge. Used batteries are a valuable resource.
   Please recycle used batteries in accordance with local regulations.

## **Charging AC Adapter**

Be sure to read and follow the warnings in "For Your Safety" (QQviii-x) before use.

- The Charging AC Adapter EH-70P is for use only with compatible devices. Do not use with another
  make or model of device.
- The EH-70P is compatible with AC 100-240 V, 50/60 Hz electrical outlets. When using in other
  countries, use a plug adapter (commercially available) as necessary. For more information about
  plug adapters, consult your travel agency.



 Do not, under any circumstances, use another make or model of AC adapter other than Charging AC Adapter EH-70P or USB-AC adapter. Failure to observe this precaution could result in overheating or in damage to the camera.

## **Memory Cards**

- Use only Secure Digital memory cards. See "Approved Memory Cards" ( 22) for recommended memory cards.
- Observe the precautions noted in the documentation included with your memory card.
- Do not affix labels or stickers to the memory card.
- Do not format the memory card using a computer.
- The first time you insert a memory card that has been used in another device into this camera, be sure to format it with this camera. We recommend formatting new memory cards with this camera before using them with this camera.
- Note that formatting a memory card permanently deletes all images and other data on the memory card. If there is data saved on the memory card that you wish to keep, copy that data to a computer before formatting.
- If the message Card is not formatted. Format card? is displayed when the camera is turned on, the memory card must be formatted. If there is data on the memory card that you do not want to delete, select No and press the button. Copy that data to a computer before formatting. To format the memory card, select Yes.
- Observe the following precautions while formatting the memory card, saving and deleting images, and copying images to a computer, otherwise data or the memory card itself may be damaged.
  - Do not open the battery-chamber/memory card slot cover or remove the memory card or battery.
  - Do not turn off the camera.
  - Do not disconnect the AC adapter.

# **Cleaning and Storage**

## Cleaning

Do not use alcohol, thinner, or other volatile chemicals.

Lens	Avoid touching glass parts with your fingers. Remove dust or lint with a blower (typically a small device with a rubber bulb attached to one end that is pumped to produce a stream of air out the other end). To remove fingerprints or other stains that cannot be removed with a blower, wipe the lens with a soft cloth, using a spiral motion that starts at the center of them and working toward the edges. If this fails, clean the lens using a cloth lightly dampened with commercial lens cleaner.
Monitor	Remove dust or lint with a blower. To remove fingerprints and other stains, clean the monitor with a soft, dry cloth, being careful not to apply pressure.
Body	Use a blower to remove dust, dirt, or sand, then wipe gently with a soft, dry cloth. After using the camera at the beach or other sandy or dusty environment, wipe off any sand, dust, or salt with a dry cloth lightly dampened with fresh water and dry thoroughly. Note that foreign matter inside the camera could cause damage not covered by the warranty.

## Storage

Turn the camera off when not in use. Be sure that the power-on lamp is off before putting the camera away. Remove the battery if the camera will not be used for an extended period. Do not store the camera with naphtha or camphor moth balls, or in any of the following locations:

- Next to equipment that produces strong electromagnetic fields, such as televisions or radios
- Exposed to temperatures below –10°C (14°F) or above 50°C (122°F)
- Places that are poorly ventilated or subject to humidity of over 60%

To prevent mold or mildew, take the camera out of storage at least once a month. Turn the camera on and release the shutter a few times before putting the camera away again. For storing the battery, follow the precautions in "The Battery" (2:3) in "Caring for the Product" (2:2).



# **Troubleshooting**

If the camera fails to function as expected, check the list of common problems below before consulting your retailer or Nikon-authorized service representative.

#### **Power, Display, Settings Issues**

Problem	Cause/Solution	Φ
The camera is on but does not respond.	Wait for recording to end. If the problem persists, turn the camera off. If the camera does not turn off, remove and reinsert the battery or batteries or, if you are using an AC adapter, disconnect and reconnect the AC adapter. Note that although any data currently being recorded will be lost, data that have already been recorded will not be affected by removing or disconnecting the power source.	20, <b>~</b> 95
Battery inserted in the camera cannot be charged.	Confirm all connections.  When connected to a computer, the camera may not charge for any of the reasons described below.  Off is selected for Charge by computer in the setup menu.  Battery charging stops if the camera is turned off.  Battery charging is not possible if the camera's display language and date and time have not been set, or the date and time were reset after the camera's clock battery was exhausted. Use the Charging AC Adapter to charge the battery.  Battery charging may stop if the computer is in sleep mode.  Depending upon the computer specifications, settings, and status, battery charging may not be possible.	79, <b>◆</b> 83  - 16, 18
Camera cannot be turned on.	The battery is exhausted.	20

Problem	Cause/Solution	TI TI
Camera turns off without warning.	The camera automatically turns off to save power (auto off function). The camera or battery have become too cold and cannot operate properly. The inside of the camera has become hot. Leave the camera off until the inside of the camera has cooled, and then try turning it on again. The camera turns off if the USB cable connecting it to a computer or printer is disconnected. Reconnect the USB cable.	21 <b>☼</b> :3  -  83, 88, <b>♣</b> 25
Monitor is blank.	The camera is off. The camera has entered standby mode to save power. Press the power switch, shutter-release button,  button,  button,  button,  button,  while the flash is charging. Wait for the flash to charge. The camera and computer are connected via the USB cable. The camera and TV are connected via an audio/ video cable or HDMI cable.	20 1,21 49 83,88 83, 6 22
Monitor is hard to read.	<ul><li>Adjust the monitor brightness.</li><li>The monitor is dirty. Clean the monitor.</li></ul>	78, <b>6-6</b> 73
Date and time of recording are not correct.	If the camera clock has not been set, the "Date not set" indicator flashes during shooting and movie recording. Images and movies saved before the clock is set are dated "00/00/0000 00:00" or "01/01/2013 00:00" respectively. Set the correct time and date from the Time zone and date option in the setup menu. The camera clock is not as accurate as ordinary watches or clocks. Periodically compare the time of the camera clock with that of a more accurate timepiece and reset as required.	16,78, <b>♣</b> 071



Problem	Cause/Solution	Ф
No indicators displayed in monitor.	<b>Hide info</b> is selected for <b>Photo info</b> in <b>Monitor settings</b> in the setup menu.	78, <b>6-6</b> 73
Print date not available.	<b>Time zone and date</b> has not been set in the setup menu.	16, 78, <b>6−6</b> 71
Date not imprinted on images even when <b>Print date</b> is enabled.	The current shooting mode does not support Print date. The date cannot be imprinted on movies.	78, <b>6-6</b> 75
Screen for setting time zone and date is displayed when camera is turned on.	The clock battery is exhausted; all settings were restored to their default values.	16, 18
Camera settings reset.		
Monitor turns off, and the power-on lamp flashes quickly.	The battery temperature is high. Turn off the camera and allow the battery to cool down before resuming use. After the lamp flashes for three minutes, the camera turns off automatically. Pressing the power switch also turns off the camera.	-
Camera becomes hot.	The camera may become hot when used for an extended period of time to shoot movies or send images using an Eye-Fi card, or when used in a hot environment; this is not a malfunction.	-
Camera makes sound.	When <b>Autofocus mode</b> is set to <b>Full-time AF</b> or while in some shooting modes, the camera may produce an audible focusing sound.	58, 75

# **Shooting Issues**

Problem	Cause/Solution	Ф
Cannot switch to shooting mode.	<ul> <li>Disconnect the HDMI cable or USB cable.</li> <li>The camera cannot be switched to shooting mode while connected to a power outlet via the Charging AC Adapter.</li> </ul>	83, 88, •••22, •••25 12
No image captured when the shutter-release button is pressed.	When the camera is in playback mode, press the button, the shutter-release button, or the (*\overline{\Pi}\) movie-record) button.      When menus are displayed, press the MENU button.      The battery is exhausted.      When the flash lamp is flashing, the flash is charging.	1, 28 4 20 49
Camera cannot focus.	The subject is too close. Try shooting using scene auto selector mode, Close-up scene mode, or macro mode. The subject is hard to focus on. Set AF assist in the setup menu to Auto. Turn the camera off and then on again.	32, 36, 53 66 79, <b>~</b> 79
Images are blurred.	Use the flash. Increase the ISO sensitivity value. Enable vibration reduction or motion detection. Use BSS (Best Shot Selector).  Use a tripod to stabilize the camera when shooting (using the self-timer at the same time is more effective).	49 58 78 37, 58, →39 51

Problem	Cause/Solution	THE COLUMN TWO IN THE COLUMN T
Bright specks appear in images captured with flash.	The flash is reflecting off particles in the air. Set the flash mode setting to <b>③</b> (off).	50
Flash does not fire.	<ul> <li>The flash mode is set to ③ (off).</li> <li>A scene mode that restricts the flash is selected.</li> <li>On is selected for Blink proof in the smart portrait menu.</li> <li>On (continuous) or On (BSS) is selected for Smile timer in the smart portrait menu.</li> <li>A function that restricts the flash is enabled.</li> </ul>	49 55 59 59 60
Digital zoom cannot be used.	Digital zoom is set to Off in the setup menu.     Digital zoom cannot be used in the following situations.     When Portrait, Night portrait, Night landscape, Backlighting (when HDR is set to On), Easy panorama, or Pet portrait is selected in scene mode     When smart portrait mode is selected     When Continuous in the shooting menu is set	79, <b>4</b> 2 58, <b>6</b> 39
	to Multi-shot 16  - When AF area mode in the shooting menu is set to Subject tracking  • The gesture control function is in use.	58, <b>4</b> 4
Image mode not available.	A function that restricts the <b>Image mode</b> option is enabled.	60
No sound when shutter is released.	<b>Off</b> is selected for <b>Sound settings</b> > <b>Shutter sound</b> in the setup menu. No sound is produced with some shooting modes and settings, even when <b>On</b> is selected.	79, <b>~</b> 80

Problem	Cause/Solution	Щ
AF-assist illuminator does not light.	Off is selected for the AF assist option in the setup menu. AF-assist illuminator may not light depending on the position of the focus area or the current scene mode, even when Auto is selected. The gesture control function is in use.	79, <b>6-6</b> 79 46, <b>6-6</b> 76
Images appear smeared.	The lens is dirty. Clean the lens.	<b>\$</b> -6
Colors are unnatural.	White balance or hue is not adjusted properly.	36, 58, <b>6-6</b> 36
Randomly spaced bright pixels ("noise") appear in image.	The subject is dark, and the shutter speed is too slow or ISO sensitivity is too high. Noise can be reduced by:  Using the flash.  Specifying a lower ISO sensitivity setting.	49 58, <b>6</b>
Images are too dark (underexposed).	The flash mode is set to (3) (off). The flash window is blocked. The subject is beyond the range of the flash. Adjust exposure compensation. Increase ISO sensitivity. The subject is backlit. Select <b>Backlighting</b> scene mode or set the flash mode setting to (7) (fill flash).	49 24 49 54 58, <b>6</b> •• 42 37, 49
Images are too bright (overexposed).	Adjust exposure compensation.	54
Unexpected results when flash set to \$ (auto with red-eye reduction).	When taking images with �� (auto with red-eye reduction), scene auto selector mode, or fill flash with slow sync and red-eye reduction in <b>Night portrait</b> scene mode, In-Camera Red Eye Fix may be applied to areas not affected by red-eye in rare cases. Use any scene mode other than <b>Night portrait</b> , and change the flash mode to any setting other than �� (auto with red-eye reduction) and try taking an image again.	32, 35, 49

Problem	Cause/Solution	
Skin tones are not softened.	In some shooting conditions, facial skin tones may not be softened. For images containing four or more faces, try using the <b>Skin softening</b> effect in <b>Glamour retouch</b> in the playback menu.	42 70, <b>♣</b> 18
Saving images takes time.	It may take more time to save images in the following situations.  • When the noise reduction function is in operation, such as when shooting in a dark environment.  • When the flash mode is set to * (auto with redeye reduction).  • When shooting in Night landscape, Night portrait, or Backlighting (when HDR is set to On) scene mode.  • When the skin softening function is applied while shooting.  • When using continuous shooting mode.	- 50 35, 36, 37 59 58, ••39
A ring-shaped belt or rainbow-colored stripe appears in the monitor or images.	When shooting with backlighting or when a very strong light source (such as sunlight) is in the frame, a ring-shaped belt or rainbow-colored stripe (ghosting) may occur. Change the position of the light source, or frame the image so that the light source does not enter the frame, and try again.	-

# **Playback Issues**

Problem	Cause/Solution	Ш
File cannot be played back.	This camera may not be able to play back images saved with another make or model of digital camera. This camera cannot play back movies recorded with another make or model of digital camera. This camera may not be able to play back data edited on a computer.	-
Cannot zoom in on image.	Playback zoom cannot be used with movies, small pictures, or images that have been cropped to a size of 320 × 240 or smaller. This camera may not be able to zoom in on images captured with another make or model of digital camera.	-
Cannot record voice memos.	Voice memos cannot be attached to movies. Voice memos cannot be attached to images captured with other cameras. Voice memos attached to images using another camera cannot be played back on this camera.	_ 70, <b>♣</b> 60
Cannot edit image.	Some images cannot be edited. Images that have already been edited may not be edited again. There is not enough free space in the internal memory or on the memory card. This camera is unable to edit images captured with other cameras. Editing functions used for images are not available for movies.	38, <b>००</b> 14 - 70, <b>००</b> 14 -

Problem	Cause/Solution	Image: control of the
Cannot rotate image.	This camera cannot rotate images captured with another make or model of digital camera.	-
Images are not displayed on TV.	Video mode or HDMI is not correctly set in the TV settings setup menu.     The cables are connected to the HDMI micro connector (Type D) and to the USB/audio/video output connector simultaneously.     The memory card contains no images. Replace the memory card. Remove the memory card to play back images from the internal memory.	79, <b>6-6</b> 82 83, 88, <b>6-6</b> 22, <b>6-6</b> 25 15
Nikon Transfer 2 does not start when camera is connected to a computer.	The camera is off. The battery is exhausted. The USB cable is not correctly connected. The camera is not recognized by the computer. Confirm system requirements. The computer is not set to start Nikon Transfer 2 automatically. For more information about Nikon Transfer 2, refer to help information contained in ViewNX 2.	20 20 83, 88 - 85 90
The PictBridge startup screen is not displayed when the camera is connected to a printer.	With some PictBridge-compatible printers, the PictBridge startup screen may not be displayed and it may be impossible to print images when <b>Auto</b> is selected for the <b>Charge by computer</b> option in the setup menu. Set the <b>Charge by computer</b> option to <b>Off</b> and reconnect the camera to the printer.	79, <b>6=0</b> 83

Problem	Cause/Solution	Ψ
Images to be printed are not displayed.	The memory card contains no images. Replace the memory card. Remove the memory card to print images from the internal memory.	14 15
Cannot select paper size with camera.	The camera cannot be used to select the paper size in the following situations, even when printing from a PictBridge-compatible printer. Use the printer to select the paper size.  • The printer does not support the paper sizes specified by the camera.  • The printer automatically selects the paper size.	83, <b>6-6</b> 28, <b>6-6</b> 29

# **Specifications**

Nikon COOLPIX S6600 Digital Camera

Type	Compact digital camera		
Number of effective pixels	16.0 million		
Image sensor	<sup>1</sup> /2.3-in. type CMOS; approx. 16.79 million total pixels		
Lens	NIKKOR lens with 12× optical zoom		
Focal length	4.5-54.0 mm (angle of view equivalent to that of 25-300 mm lens in 35mm [135] format)		
f/-number	f/3.3-6.3		
Construction	9 elements in 7 groups (1 ED lens element)		
Digital zoom magnification	Up to 4x (angle of view equivalent to that of approx. 1200 mm lens in 35mm [135] format)		
Vibration reduction	Lens shift		
Motion blur reduction	Motion detection (still pictures)		
Autofocus (AF)	Contrast-detect AF		
Focus range	[W]: Approx. 50 cm (1 ft 8 in.) – ∞, [T]: Approx. 1.5 m (5 ft) – ∞     Macro mode: Approx. 2 cm (0.8 in.) – ∞ (wide-angle position) (All distances measured from center of front surface of lens)		
Focus-area selection	Face priority, manual with 99 focus areas, center, subject tracking, target finding AF		
Monitor	6.7 cm (2.7-in.), approx. 460k-dot, TFT LCD with anti-reflection coating and 5-level brightness adjustment		
Frame coverage (shooting mode)	Approx. 97% horizontal and 97% vertical (compared to actual picture)		
Frame coverage (playback mode)	Approx. 99% horizontal and 99% vertical (compared to actual picture)		

St	orage	
	Media	Internal memory (approx. 25 MB), SD/SDHC/SDXC memory card
	File system	DCF, Exif 2.3, and DPOF compliant
	File formats	Still pictures: JPEG Sound files (Voice Memo): WAV Movies: MOV (Video: H.264/MPEG-4 AVC, Audio: LPCM stereo)
Image size (pixels)		16M (High) [4608 × 3456★]     16M [4608 × 3456]     8M [3264 × 2448]     4M [2272 × 1704]     2M [1600 × 1200]     VGA [640 × 480]     16:9 [4608 × 2592]     1:1 [3456 × 3456]
ISO sensitivity (Standard output sensitivity)		ISO 125-1600     ISO 3200, Hi 1 (equivalent to ISO 6400) (available when using Auto mode)
E	kposure kposure	
	Metering mode	Matrix, center-weighted (digital zoom less than 2x), spot (digital zoom 2x or more)
	Exposure control	Programmed auto exposure and exposure compensation $(-2.0 - +2.0 \text{ EV})$ in steps of $^{1}/3 \text{ EV})$
Sł	nutter	Mechanical and CMOS electronic shutter
	Speed	1/2000-1 s     1/4000 s (maximum speed during high-speed continuous shooting)     4 s ( <b>Fireworks show</b> scene mode)
Α	perture	Electronically-controlled ND filter (–2 AV) selection
	Range	2 steps (f/3.3 and f/6.6 [W])
Se	elf-timer	Can be selected from 10 s and 2 s



[W]: 0.5–3.0 m (1 ft 8 in.–9 ft 10 in.) [T]: 1.5–1.8 m (5 ft–5 ft 10 in.)
TTL auto flash with monitor preflashes
Hi-Speed USB
MTP, PTP
Can be selected from NTSC and PAL
Can be selected from Auto, 480p, 720p, and 1080i
Audio/video (A/V) output; digital I/O (USB) HDMI micro connector (Type D) (HDMI output)
Arabic, Bengali, Bulgarian, Chinese (Simplified and Traditional), Czech, Danish, Dutch, English, Finnish, French, German, Greek, Hindi, Hungarian, Indonesian, Italian, Japanese, Korean, Marathi, Norwegian, Persian, Polish, Portuguese (European and Brazilian), Romanian, Russian, Serbian, Spanish, Swedish, Tamil, Telugu, Thai, Turkish, Ukrainian, Vietnamese
One Rechargeable Li-ion Battery EN-EL19 (included) AC Adapter EH-62G (available separately)
Approx. 3 h (when using Charging AC Adapter EH-70P and when no charge remains)
Approx. 150 shots when using EN-EL19
Approx. 25 min when using EN-EL19
1/4 (ISO 1222)
Approx. 96.9 $\times$ 57.1 $\times$ 27.2 mm (3.9 $\times$ 2.3 $\times$ 1.1 in.) (excluding projections)
Approx. 165 g (5.9 oz) (including battery and SD memory card)

O	perating environment	
	Temperature	0°C−40°C (32°F−104°F)
	Humidity	85% or less (no condensation)
W	'i-Fi (Wireless LAN)	
	Standards	IEEE 802.11b/g/n (standard wireless LAN protocol)
	Communications protocols	IEEE 802.11b: DBPSK/DQPSK/CCK IEEE 802.11g: OFDM IEEE 802.11n: OFDM
	Range (line of sight)	Approx. 10 m (11 yd)
	Operating frequency	2412-2462 MHz (1-11 channels)
	Data rates (actual measured values)	IEEE 802.11b: 5 Mbps IEEE 802.11g: 20 Mbps IEEE 802.11n: 20 Mbps
	Security	WPA2
	Access protocols	Infrastructure

 Unless otherwise stated, all figures assume a fully-charged battery and an ambient temperature of 23 ±3°C (73.4 ±5.4°F) as specified by the Camera and Imaging Products Association (CIPA).

Battery life may vary depending on conditions of use, such as the interval between shots or the length of time that menus and images are displayed.

Individual movie files cannot exceed 4 GB in size or 29 minutes in length. Recording may end before this limit is reached if camera temperature becomes elevated.

# **Rechargeable Li-ion Battery EN-EL19**

Туре	Rechargeable lithium-ion battery
Rated capacity	DC 3.7 V, 700 mAh
Operating temperature	0°C-40°C (32°F-104°F)
Dimensions (W $\times$ H $\times$ D)	Approx. $31.5 \times 39.5 \times 6 \text{ mm} (1.3 \times 1.6 \times 0.3 \text{ in.})$
Weight	Approx. 14.5 g (0.5 oz) (excluding battery case)

#### **Charging AC Adapter EH-70P**

Rated input	AC 100-240 V, 50/60 Hz, 0.07-0.044 A		
Rated output	DC 5.0 V, 550 mA		
Operating temperature	0°C-40°C (32°F-104°F)		
Dimensions (W $\times$ H $\times$ D)	Approx. $55 \times 22 \times 54$ mm ( $2.2 \times 0.9 \times 2.2$ in.) (excluding plug adapter) For Argentina: Approx. $55 \times 59 \times 63$ mm ( $2.2 \times 2.4 \times 2.5$ in.) For Korea: Approx. $55 \times 59 \times 66.5$ mm ( $2.2 \times 2.4 \times 2.7$ in.)		
Weight	Approx. 47 g (1.7 oz) (excluding plug adapter) For Argentina and Korea: Approx. 72 g (2.6 oz)		

# **Specifications**

- Nikon will not be held liable for any errors this manual may contain.
- The appearance of this product and its specifications are subject to change without notice.

## **Approved Memory Cards**

The following Secure Digital (SD) memory cards have been tested and approved for use in this camera.

 Memory cards with an SD Speed Class rating of 6 or faster are recommended for recording movies. When using a memory card with a lower Speed Class rating, movie recording may stop unexpectedly.

	SD memory card	SDHC memory card <sup>2</sup>	SDXC memory card <sup>3</sup>
SanDisk	2 GB <sup>1</sup>	4 GB, 8 GB, 16 GB, 32 GB	64 GB, 128 GB
TOSHIBA	-	4 GB, 8 GB, 16 GB, 32 GB	64 GB
Panasonic	2 GB <sup>1</sup>	4 GB, 8 GB, 16 GB, 32 GB	64 GB
Lexar	-	4 GB, 8 GB, 16 GB, 32 GB	64 GB, 128 GB

If the memory card will be used with a card reader or similar device, make sure that the device supports 2 GB cards.

<sup>2</sup> SDHC compliant.

If the memory card will be used with a card reader or similar device, make sure that the device supports SDHC.

SDXC compliant. If the memory card will be used with a card reader or similar device, make sure that the device supports SDXC.



Contact the manufacturer for details on the above cards. We cannot guarantee camera
performance when using memory cards made by other manufacturers.

#### **AVC Patent Portfolio License**

This product is licensed under the AVC Patent Portfolio License for the personal and non-commercial use of a consumer to (i) encode video in compliance with the AVC standard ("AVC video") and/or (ii) decode AVC video that was encoded by a consumer engaged in a personal and non-commercial activity and/or was obtained from a video provider licensed to provide AVC video. No license is granted or shall be implied for any other use. Additional information may be obtained from MPEG LA, L.L.C.

See http://www.mpegla.com.

#### **Trademark Information**

- Microsoft, Windows and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Macintosh and Mac OS are trademarks of Apple Inc., registered in the U.S. and other countries. The iFrame logo and the iFrame symbol are trademarks of Apple Inc.
- Adobe and Acrobat are registered trademarks of Adobe Systems Inc.
- SDXC, SDHC and SD Logos are trademarks of SD-3C, LLC.
- PictBridge is a trademark.
- HDMI, HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.

#### HDMI

- Wi-Fi and the Wi-Fi logo are trademarks or registered trademarks of the Wi-Fi Alliance.
- Android and Google Play are trademarks or registered trademarks of Google, Inc.
- All other trade names mentioned in this manual or the other documentation provided with your Nikon product are trademarks or registered trademarks of their respective holders.

#### FreeType License (FreeType2)

 Portions of this software are copyright © 2013 The FreeType Project (http://www.freetype.org). All rights reserved.

#### MIT License (HarfBuzz)

 Portions of this software are copyright © 2013 The HarfBuzz Project (http://www.freedesktop.org/wiki/Software/HarfBuzz). All rights reserved.

# Index

<u>Symbols</u>	<u>A</u>
Scene auto selector	AC adapter
<b>2</b> Scene mode	AF area mode
<b>\$0</b> Special effects mode	AF assist 1,
Smart portrait mode42	Album
Auto mode 22, 44	Aperture value
Playback mode 28	Audio/video cable
₹ Favorite pictures mode ♣ 6	Audio/video-in jack
Auto sort mode 6—610	Auto flash
12 List by date mode	Auto mode
<b>Y</b> Setup menu	Auto off 21,
<b>T</b> (Telephoto)	Auto sort mode
<b>W</b> (Wide-angle)	Autofocus 58, 75, 60
Playback zoom 68	<u>B</u>
Thumbnail playback69	Backlighting 🖺
<b>?</b> Help	Battery charger
Shooting mode button	Battery latch
Playback button 1, 28	Battery level indicator
● (► movie-record) button	Battery-chamber/memory car
MENU button 4, 57, 70, 75, 78	
<b>1</b> Delete button	Beach 🗣
<b>\$</b> Flash mode	Best Shot Selector
<b>Š</b> Self-timer	Black and white copy 🗖
Macro mode 53	Black-and-white
Exposure compensation 54	Blink proof
	Blink warning

<u>A</u>			
AC adapter	83,	<b>∂−</b> 09	5
AF area mode	58,	<b>∂=</b> 04	4
AF assist 1,	79,	<b>∂−</b> 07	9
Album		🏍	9
Aperture value		2	7
Audio/video cable		8	4
Audio/video-in jack		8	4
Auto flash		5	0
Auto mode		22, 4	4
Auto off 21,			
Auto sort mode		🏍 1	0
Autofocus 58, 75, 60	48,	<b>∂</b> 6	8
_			
<u>B</u>			
<u>B</u> Backlighting <b>☑</b>		34, 3	7
Backlighting 🖺			
_	. 13,	<b>∂</b> •69	5
Backlighting 🖺 Battery charger Battery latch	. 13,	<b>∂−6</b> 9 1	5 0
Battery latch	. 13,	<b>6−6</b> 9 1 2	5 0 0
Backlighting 🖺 Battery charger Battery latch	. <b>13,</b>	<b>6−</b> 69 1 2 ot cove	5 0 0 er
Backlighting	. 13,  rd slo	6-69 1 2 ot cove 10, 1	5 0 0 er 4
Battery charger	. 13, rd slo 2,	1 2 ot cove 10, 1	5 0 er 4
Backlighting Battery charger	. 13, rd slo 2, 	1 2 ot cove 10, 1 3	5 0 er 4 0
Backlighting	. 13,rd slo 2,	6-69 	5 0 0 er 4 4 0 7
Backlighting Battery charger Battery latch Battery level indicator Battery-chamber/memory ca Beach Back Selector Bets Shot Selector Black and white copy	. 13,rd slo	6-69 	5 0 0 er 4 4 0 7 3
Backlighting Battery charger Battery latch Battery level indicator Battery-chamber/memory ca Beach Back Selector Black and white copy I	. 13,rd slo	6-69 	5 0 0 er 4 4 0 7 3 1

Brightness	78, 🏍73	DSCN	6→694
BSS	37, 🏍 40	E	
Button sound	€ 80	Easy panorama 🞞	34, 38, 🏍2
<u>C</u>		Easy panorama playback	38, 🏍5
Charge by computer	79, 🏍83	Exposure compensation	54
Charge lamp	2, 13	Extension	<i>6</i> 94
Charger	13, 🏍 95	Eye-Fi upload	79, 🏍87
Charging AC Adapter	12	Eyelet for camera strap	1
Choose key picture 71,	<b>61</b> 2, <b>66</b> 3	<u>E</u>	
Close-up <b>\$</b>	34, 36	Face detection	64
Color options	58, 🏍 43	Face priority	
Compression ratio	<b>6–6</b> 34	Favorite pictures	71, <del>60</del> 6
Computer	84, 88	Favorite pictures mode	€€6
Connector cover	1	File name	<i>6</i> 94
Continuous	58, 🏍 39	Fill flash	50
Copying images	71, 🏍61	Fireworks show 🏶	34, 37
Crop		Firmware version	79, 🏍88
Cross process 💸	40	Fixed range auto	6 42
Cyanotype	<b>6–6</b> 43	Flash	1, 49
<u>D</u>		Flash lamp	2, 49
Date and time	16, 78, 🏍71	Flash mode	49, 50
Date format	17, 🏍71	Flash off	50
Daylight saving time	. 17, 18, 🏍71	Focus 2	6, 58, 🏍 44
Delete 30,	, <del>6-0</del> 13, <del>6-0</del> 61	Focus area	26
Digital zoom	25, 79, 🏍79	Focus indicator	7
Direct print	84, 🏍 24	Focus lock	67
D-Lighting	70, 🏍 16	Food ¶¶	34, 36
DPOF print	<i>6</i> <b>-6</b> 31	Format internal memory	79, 🏍81

Refer to the *Reference Manual* for pages indicated with ...



ormat memory cards 15, 79, 6€81	ISO sensitivity	58, 🏍 42
Formatting 15, 79, 🗪81	Ţ	
FSCN	JPG	<i>6</i> •694
full-frame playback	<u>L</u>	
Full-time AF 58, 75, 📤 48, 📤 68	Landscape	34
<u> </u>	Language	79, <del>6-6</del> 82
Gesture control 46, 78, 6676	Lens	1, 🌣 17
Glamour retouch	Lens cover	-
<u>1</u>	List by date mode	🖰 11
HDMI <i>6</i> →82	Low key Lo	40
HDMI cable	<u>M</u>	
HDMI device control 682	Macro mode	53
HDMI micro connector 1	Memory capacity	20
HDR	Memory card	14
Help34	Memory card slot	14
High key 🚻 40	Microphone	1
High-contrast monochrome 🔲	Mirror <b>∮</b> 0	40
High-speed continuous	Monitor	2, 3, 6, 🛱 6
+S movie <b>75, ♣65, ♣66</b>	Monitor settings	78, 🏍73
	Motion detection	79, 🏍78
dentifier 6-694	MOV	6
mage copy 6–61	Movie editing	77, 🏍32
mage mode 58, 6-34	Movie length	72, 73
mage review	Movie menu	75, 🏍64
mage size 58, 6-34	Movie options	
mprinting date and time 18, 🦰 75	Movie playback	
nternal memory 15, 20	Movie recording	
nternal memory indicator	Multi selector	2, 4

Multi-shot 16	6→340	Portrait 🙎		34
Museum <u> </u>	34, 37	Power		
<u>N</u>		Power switch		1, 20
Night landscape 🖼	34, 36	Power-on lamp		1, 20
Night portrait 🗹		Preset manual		<b>∂-</b> 037
Nikon Transfer 2		Pre-shooting cache	<b>5</b> 39,	<b>6-6</b> 4′
Nostalgic sepia <b>SE</b>	40	Pressing halfway		27
Number of exposures remaining		Print 70, 84, 🗪 27, 8	<b>→</b> 29,	<b>∂-</b> 052
2	0, <b>6–6</b> 35	Print date18	8, 78,	<b>6−</b> 675
<u>o</u>		Print order	70,	<b>∂-</b> 052
Open with HS footage		Print order date option		
75, 6	6, 6	18, 6	<b>5</b> 53,	<b>6-6</b> 55
 Optical zoom		Printer		
Optional accessories		Protect	70,	<b>∂=</b> 057
P <sup>'</sup>		Q		
<u></u> Painting 🛱	40	Quick effects 29, 45, 6	<b>3−</b> 015,	<b>6-6</b> 48
Panorama Maker		Quick retouch	70,	<b>∂</b> 16
Paper size 6—32		<u>R</u>		
Party/indoor 🎇		Recording movies		72
Pet portrait auto release		Recording slow motion mo		
Pet portrait 🦋		75, 6	<b>→</b> 65,	<b>6</b> €66
Photo info		Red-eye correction	70,	<b>∂−</b> 017
PictBridge84		Red-eye reduction		50
Playback 28, 68, 7		Remove from favorites		
Playback menu		Reset all	79,	<b>∂=</b> 088
Playback mode		Rotate image		
Playback zoom		RSCN		
Pop <b>POP</b>				

Refer to the *Reference Manual* for pages indicated with 🗪.



<u>S</u>		Special effects mode		40
Scene mode	34, 35	Sports 🔾	34,	35
Selective color 🧨	40	SSCN		
Self-timer	51	Standard color 58	3, 🖰	43
Self-timer lamp	1, 52	Strap		
Sepia	<b>6–6</b> 43	Subject tracking 6-645		
Sequence display options		Sunset 🚢		
71, 6	<b>→</b> 12, <b>→</b> 63	Super vivid <b>VI</b>	4	40
Setup menu	78	I		
Shooting	22, 24, 26	Target finding AF 58, 63	3, 🏍	46
Shooting menu	58, 🏍34	Time difference	<del>6-6</del>	71
Shooting mode	22	Time zone 1	8, 🏍	71
Shutter sound	€€80	Time zone and date 16, 7	8, 🏍	71
Shutter speed	27	Toy camera effect 1 🐶 1	4	40
Shutter-release button	1, 26	Toy camera effect 2 👯		40
Single	58, 🏍 39	Tripod socket	2, 💢	19
Single AF 58, 75, 8	<b>-</b> 048, <i>6</i> <b>-</b> 068	TV84	<b>1</b> , 🗪	22
Skin softening 59	9, 65, 🏍 49	TV settings 79	), 🏍	82
Slide show	70, 🏍 56	<u>U</u>		
Slow sync		USB cable 83, 88	3, 🏍	25
Small picture	70, 🏍20	USB/audio/video output connec	ctor	
Smart portrait menu	57, 🏍 49		83, 8	88
Smart portrait mode	42	<u>V</u>		
Smile timer	59, 🏍 50	Vibration reduction	3, 🏍	77
Snow 8	34	Video mode		
Soft <b>\$0</b>	40	ViewNX 2		
Sound settings	79, 🏍80	Vivid color		
Speaker	2	Voice memo70		

Volume 77,	<b>6</b> 60
W	
WAV	<b>∂−</b> 094
Welcome screen 78,	<b>∂−</b> 070
White balance 58,	<b>∂</b> 36
Wi-Fi options 79, 80,	<b>∂</b> 85
Wind noise reduction	<b>∂</b> 69
Wireless LAN 79, 80,	<b>∂</b> •085
<u>Z</u>	
Zoom	25
Zoom control	1, 25
Zoom in	25
700m out	25

No reproduction in any form of this manual, in whole or in part (except for brief quotation in critical articles or reviews), may be made without written authorization from NIKON CORPORATION.

6MN26011-02