



OM-224 690M

2010-06

Processes



Stick (SMAW) Welding



TIG (GTAW) Welding



Flux Cored (FCAW) Welding



Air Carbon Arc (CAC-A)
Cutting and Gouging


Description



Engine Driven Welding Generator

D502DX 5+4

CC DC Diesel Welder



OWNER'S MANUAL

File: Engine Drive



www.red-d-arc.com

TABLE OF CONTENTS

| | |
|---|-----------|
| SECTION 1 – SAFETY PRECAUTIONS – READ BEFORE USING | 1 |
| 1-1. Symbol Usage | 1 |
| 1-2. Arc Welding Hazards | 1 |
| 1-3. Engine Hazards | 3 |
| 1-4. Hydraulic Hazards | 4 |
| 1-5. Compressed Air Hazards | 4 |
| 1-6. Additional Symbols For Installation, Operation, And Maintenance | 5 |
| 1-7. California Proposition 65 Warnings | 6 |
| 1-8. Principal Safety Standards | 7 |
| 1-9. EMF Information | 7 |
| SECTION 2 – CONSIGNES DE SÉCURITÉ – LIRE AVANT UTILISATION | 8 |
| 2-1. Signification des symboles | 8 |
| 2-2. Dangers relatifs au soudage à l'arc | 8 |
| 2-3. Dangers existant en relation avec le moteur | 10 |
| 2-4. Dangers liés à l'hydraulique | 11 |
| 2-5. Dangers liés à l'air comprimé | 12 |
| 2-6. Dangers supplémentaires en relation avec l'installation, le fonctionnement et la maintenance | 13 |
| 2-7. Proposition californienne 65 Avertissements | 14 |
| 2-8. Principales normes de sécurité | 15 |
| 2-9. Informations relatives aux CEM | 15 |
| SECTION 3 – DEFINITIONS | 16 |
| 3-1. Warning Label Definitions (For Wordless Labels) | 16 |
| 3-2. Symbols And Definitions | 17 |
| SECTION 4 – SPECIFICATIONS | 18 |
| 4-1. Weld, Power, And Engine Specifications | 18 |
| 4-2. Dimensions, Weights, And Operating Angles | 18 |
| 4-3. Volt-Ampere Curves | 19 |
| 4-4. Fuel Consumption | 19 |
| 4-5. Duty Cycle And Overheating | 20 |
| 4-6. AC Generator Power Curve | 20 |
| SECTION 5 – INSTALLATION | 21 |
| 5-1. Serial Number And Rating Label Location | 21 |
| 5-2. Installing Welding Generator | 21 |
| 5-3. Mounting Welding Generator | 22 |
| 5-4. Grounding Generator To Truck Or Trailer Frame | 23 |
| 5-5. Using Lifting Eye | 23 |
| 5-6. Installing Exhaust Pipe | 24 |
| 5-7. Activating The Dry Charge Battery (If Applicable) | 25 |
| 5-8. Connecting The Battery | 25 |
| 5-9. Engine Prestart Checks | 26 |
| 5-10. Connecting To Weld Output Terminals | 27 |
| 5-11. Selecting Weld Cable Sizes* | 28 |
| 5-12. Connecting To Remote Amperage Adjust Receptacle RC13 | 28 |
| SECTION 6 – OPERATING WELDING GENERATOR | 30 |
| 6-1. Front Panel Controls (See Section 6-2) | 30 |
| 6-2. Description Of Front Panel Controls (See Section 6-1) | 31 |
| 6-3. Remote Amperage Control (Optional) | 32 |
| 6-4. Weld Control/Arc Condition Information Label | 32 |
| 6-5. Fuel/Hour Gauge Descriptions | 33 |
| SECTION 7 – OPERATING AUXILIARY EQUIPMENT | 34 |
| 7-1. 120 Volt And 240 Volt Receptacles | 34 |

TABLE OF CONTENTS

| | |
|--|-----------|
| SECTION 8 – MAINTENANCE & TROUBLESHOOTING | 35 |
| 8-1. Maintenance Label | 35 |
| 8-2. Routine Maintenance | 36 |
| 8-3. Servicing Air Cleaner | 37 |
| 8-4. Inspecting And Cleaning Optional Spark Arrestor Muffler | 38 |
| 8-5. Checking Generator Brushes | 38 |
| 8-6. Adjusting Engine Speed | 39 |
| 8-7. Servicing Fuel And Lubrication Systems | 40 |
| 8-8. Overload Protection | 41 |
| 8-9. Troubleshooting | 42 |
| SECTION 9 – ELECTRICAL DIAGRAMS | 46 |
| SECTION 10 – RUN-IN PROCEDURE | 48 |
| 10-1. Wetstacking | 48 |
| 10-2. Run-In Procedure Using Load Bank | 49 |
| 10-3. Run-In Procedure Using Resistance Grid | 50 |
| SECTION 11 – GENERATOR POWER GUIDELINES | 51 |
| SECTION 12 – PARTS LIST | 58 |
| WARRANTY | |

SECTION 1 – SAFETY PRECAUTIONS – READ BEFORE USING

rom_2010-03

 Protect yourself and others from injury — read, follow, and save these important safety precautions and operating instructions.

1-1. Symbol Usage



DANGER! – Indicates a hazardous situation which, if not avoided, will result in death or serious injury. The possible hazards are shown in the adjoining symbols or explained in the text.



Indicates a hazardous situation which, if not avoided, could result in death or serious injury. The possible hazards are shown in the adjoining symbols or explained in the text.

NOTICE – Indicates statements not related to personal injury.

 Indicates special instructions.



This group of symbols means Warning! Watch Out! ELECTRIC SHOCK, MOVING PARTS, and HOT PARTS hazards. Consult symbols and related instructions below for necessary actions to avoid the hazards.

1-2. Arc Welding Hazards



The symbols shown below are used throughout this manual to call attention to and identify possible hazards. When you see the symbol, watch out, and follow the related instructions to avoid the hazard. The safety information given below is only a summary of the more complete safety information found in the Safety Standards listed in Section 1-8. Read and follow all Safety Standards.



Only qualified persons should install, operate, maintain, and repair this unit.



During operation, keep everybody, especially children, away.



ELECTRIC SHOCK can kill.

Touching live electrical parts can cause fatal shocks or severe burns. The electrode and work circuit is electrically live whenever the output is on. The input power circuit and machine internal circuits are also live when power is on. In semiautomatic or automatic wire welding, the wire, wire reel, drive roll housing, and all metal parts touching the welding wire are electrically live. Incorrectly installed or improperly grounded equipment is a hazard.

- Do not touch live electrical parts.
- Wear dry, hole-free insulating gloves and body protection.
- Insulate yourself from work and ground using dry insulating mats or covers big enough to prevent any physical contact with the work or ground.
- Do not use AC output in damp areas, if movement is confined, or if there is a danger of falling.
- Use AC output ONLY if required for the welding process.
- If AC output is required, use remote output control if present on unit.
- Additional safety precautions are required when any of the following electrically hazardous conditions are present: in damp locations or while wearing wet clothing; on metal structures such as floors, gratings, or scaffolds; when in cramped positions such as sitting, kneeling, or lying; or when there is a high risk of unavoidable or accidental contact with the workpiece or ground. For these conditions, use the following equipment in order presented: 1) a semiautomatic DC constant voltage (wire) welder, 2) a DC manual (stick) welder, or 3) an AC welder with reduced open-circuit voltage. In most situations, use of a DC, constant voltage wire welder is recommended. And, do not work alone!
- Disconnect input power or stop engine before installing or servicing this equipment. Lockout/tagout input power according to OSHA 29 CFR 1910.147 (see Safety Standards).
- Properly install and ground this equipment according to its Owner's Manual and national, state, and local codes.

- Always verify the supply ground — check and be sure that input power cord ground wire is properly connected to ground terminal in disconnect box or that cord plug is connected to a properly grounded receptacle outlet.
- When making input connections, attach proper grounding conductor first – double-check connections.
- Keep cords dry, free of oil and grease, and protected from hot metal and sparks.
- Frequently inspect input power cord for damage or bare wiring — replace cord immediately if damaged — bare wiring can kill.
- Turn off all equipment when not in use.
- Do not use worn, damaged, undersized, or poorly spliced cables.
- Do not drape cables over your body.
- If earth grounding of the workpiece is required, ground it directly with a separate cable.
- Do not touch electrode if you are in contact with the work, ground, or another electrode from a different machine.
- Use only well-maintained equipment. Repair or replace damaged parts at once. Maintain unit according to manual.
- Do not touch electrode holders connected to two welding machines at the same time since double open-circuit voltage will be present.
- Wear a safety harness if working above floor level.
- Keep all panels and covers securely in place.
- Clamp work cable with good metal-to-metal contact to workpiece or worktable as near the weld as practical.
- Insulate work clamp when not connected to workpiece to prevent contact with any metal object.
- Do not connect more than one electrode or work cable to any single weld output terminal.


SIGNIFICANT DC VOLTAGE exists in inverter power sources AFTER stopping engine.

- Stop engine on inverter and discharge input capacitors according to instructions in Maintenance Section before touching any parts.



HOT PARTS can burn.

- Do not touch hot parts bare handed.
- Allow cooling period before working on equipment.
- To handle hot parts, use proper tools and/or wear heavy, insulated welding gloves and clothing to prevent burns.



FLYING METAL or DIRT can injure eyes.

- Welding, chipping, wire brushing, and grinding cause sparks and flying metal. As welds cool, they can throw off slag.
- Wear approved safety glasses with side shields even under your welding helmet.



FUMES AND GASES can be hazardous.

Welding produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.

- Keep your head out of the fumes. Do not breathe the fumes.
- If inside, ventilate the area and/or use local forced ventilation at the arc to remove welding fumes and gases.
- If ventilation is poor, wear an approved air-supplied respirator.
- Read and understand the Material Safety Data Sheets (MSDSs) and the manufacturer's instructions for metals, consumables, coatings, cleaners, and degreasers.
- Work in a confined space only if it is well ventilated, or while wearing an air-supplied respirator. Always have a trained watch-person nearby. Welding fumes and gases can displace air and lower the oxygen level causing injury or death. Be sure the breathing air is safe.
- Do not weld in locations near degreasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapors to form highly toxic and irritating gases.
- Do not weld on coated metals, such as galvanized, lead, or cadmium plated steel, unless the coating is removed from the weld area, the area is well ventilated, and while wearing an air-supplied respirator. The coatings and any metals containing these elements can give off toxic fumes if welded.



BUILDUP OF GAS can injure or kill.

- Shut off shielding gas supply when not in use.
- Always ventilate confined spaces or use approved air-supplied respirator.



ARC RAYS can burn eyes and skin.

Arc rays from the welding process produce intense visible and invisible (ultraviolet and infrared) rays that can burn eyes and skin. Sparks fly off from the weld.

- Wear an approved welding helmet fitted with a proper shade of filter lenses to protect your face and eyes from arc rays and sparks when welding or watching (see ANSI Z49.1 and Z87.1 listed in Safety Standards).
- Wear approved safety glasses with side shields under your helmet.
- Use protective screens or barriers to protect others from flash, glare, and sparks; warn others not to watch the arc.
- Wear protective clothing made from durable, flame-resistant material (leather, heavy cotton, or wool) and foot protection.



WELDING can cause fire or explosion.

Welding on closed containers, such as tanks, drums, or pipes, can cause them to blow up. Sparks can fly off from the welding arc. The flying sparks, hot workpiece, and hot equipment can cause fires and burns. Accidental contact of electrode to metal objects can cause sparks, explosion, overheating, or fire. Check and be sure the area is safe before doing any welding.

- Remove all flammables within 35 ft (10.7 m) of the welding arc. If this is not possible, tightly cover them with approved covers.
- Do not weld where flying sparks can strike flammable material.
- Protect yourself and others from flying sparks and hot metal.
- Be alert that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas.
- Watch for fire, and keep a fire extinguisher nearby.
- Be aware that welding on a ceiling, floor, bulkhead, or partition can cause fire on the hidden side.

- Do not weld on closed containers such as tanks, drums, or pipes, unless they are properly prepared according to AWS F4.1 (see Safety Standards).
- Do not weld where the atmosphere may contain flammable dust, gas, or liquid vapors (such as gasoline).
- Connect work cable to the work as close to the welding area as practical to prevent welding current from traveling long, possibly unknown paths and causing electric shock, sparks, and fire hazards.
- Do not use welder to thaw frozen pipes.
- Remove stick electrode from holder or cut off welding wire at contact tip when not in use.
- Wear oil-free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes, and a cap.
- Remove any combustibles, such as a butane lighter or matches, from your person before doing any welding.
- After completion of work, inspect area to ensure it is free of sparks, glowing embers, and flames.
- Use only correct fuses or circuit breakers. Do not oversize or bypass them.
- Follow requirements in OSHA 1910.252 (a) (2) (iv) and NFPA 51B for hot work and have a fire watcher and extinguisher nearby.



NOISE can damage hearing.


Noise from some processes or equipment can damage hearing.

- Wear approved ear protection if noise level is high.



ELECTRIC AND MAGNETIC FIELDS (EMF) can affect Implanted Medical Devices.

- Wearers of Pacemakers and other Implanted Medical Devices should keep away.
- Implanted Medical Device wearers should consult their doctor and the device manufacturer before going near arc welding, spot welding, gouging, plasma arc cutting, or induction heating operations.



CYLINDERS can explode if damaged.

Shielding gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Since gas cylinders are normally part of the welding process, be sure to treat them carefully.

- Protect compressed gas cylinders from excessive heat, mechanical shocks, physical damage, slag, open flames, sparks, and arcs.
- Install cylinders in an upright position by securing to a stationary support or cylinder rack to prevent falling or tipping.
- Keep cylinders away from any welding or other electrical circuits.
- Never drape a welding torch over a gas cylinder.
- Never allow a welding electrode to touch any cylinder.
- Never weld on a pressurized cylinder — explosion will result.
- Use only correct shielding gas cylinders, regulators, hoses, and fittings designed for the specific application; maintain them and associated parts in good condition.
- Turn face away from valve outlet when opening cylinder valve.
- Keep protective cap in place over valve except when cylinder is in use or connected for use.
- Use the right equipment, correct procedures, and sufficient number of persons to lift and move cylinders.
- Read and follow instructions on compressed gas cylinders, associated equipment, and Compressed Gas Association (CGA) publication P-1 listed in Safety Standards.

1-3. Engine Hazards



BATTERY EXPLOSION can injure.

- Always wear a face shield, rubber gloves, and protective clothing when working on a battery.
- Stop engine before disconnecting or connecting battery cables, battery charging cables (if applicable), or servicing battery.
- Do not allow tools to cause sparks when working on a battery.
- Do not use welder to charge batteries or jump start vehicles unless the unit has a battery charging feature designed for this purpose.
- Observe correct polarity (+ and -) on batteries.
- Disconnect negative (-) cable first and connect it last.
- Keep sparks, flames, cigarettes, and other ignition sources away from batteries. Batteries produce explosive gases during normal operation and when being charged.
- Follow battery manufacturer's instructions when working on or near a battery.

BATTERY CHARGING OUTPUT can injure. (Battery charging feature not present on all models.)

- Have only qualified persons do battery charging work.
- Charge lead-acid batteries only. Do not use battery charger to supply power to an extra-low-voltage electrical system or to charge dry cell batteries.
- Do not charge a frozen battery.
- Do not use damaged charging cables.
- Do not charge a battery that has loose terminals or one showing damage such as a cracked case or cover.
- Before charging battery, select correct charger voltage to match battery voltage.
- Set battery charging controls to the Off position before connecting to battery. Do not allow battery charging clips to touch each other.
- Keep charging cables away from vehicle hood, door, or moving parts.



FUEL can cause fire or explosion.

- Stop engine and let it cool off before checking or adding fuel.
- Do not add fuel while smoking or if unit is near any sparks or open flames.
- Do not overfill tank — allow room for fuel to expand.
- Do not spill fuel. If fuel is spilled, clean up before starting engine.
- Dispose of rags in a fireproof container.
- Always keep nozzle in contact with tank when fueling.



MOVING PARTS can injure.

- Keep away from moving parts such as fans, belts, and rotors.
- Keep all doors, panels, covers, and guards closed and securely in place.
- Stop engine before installing or connecting unit.
- Have only qualified persons remove doors, panels, covers, or guards for maintenance and troubleshooting as necessary.
- To prevent accidental starting during servicing, disconnect negative (-) battery cable from battery.
- Keep hands, hair, loose clothing, and tools away from moving parts.
- Reinstall doors, panels, covers, or guards when servicing is finished and before starting engine.
- Before working on generator, remove spark plugs or injectors to keep engine from kicking back or starting.
- Block flywheel so that it will not turn while working on generator components.




EXHAUST SPARKS can cause fire.

- Do not let engine exhaust sparks cause fire.
- Use approved engine exhaust spark arrestor in required areas — see applicable codes.




HOT PARTS can burn.

- Do not touch hot parts bare handed.
- Allow cooling period before working on equipment.
- To handle hot parts, use proper tools and/or wear heavy, insulated welding gloves and clothing to prevent burns.




STEAM AND HOT COOLANT can burn.

- If possible, check coolant level when engine is cold to avoid scalding.
- Always check coolant level at overflow tank, if present on unit, instead of radiator (unless told otherwise in maintenance section or engine manual).
- If the engine is warm, checking is needed, and there is no overflow tank, follow the next two statements.
- Wear safety glasses and gloves and put a rag over radiator cap.
- Turn cap slightly and let pressure escape slowly before completely removing cap.



Using a generator indoors CAN KILL YOU IN MINUTES.

- Generator exhaust contains carbon monoxide. This is a poison you cannot see or smell.
- NEVER use inside a home or garage, EVEN IF doors and windows are open.
- Only use OUTSIDE and far away from windows, doors, and vents.



BATTERY ACID can BURN SKIN and EYES.

- Do not tip battery.
- Replace damaged battery.
- Flush eyes and skin immediately with water.



ENGINE HEAT can cause fire.

- Do not locate unit on, over, or near combustible surfaces or flammables.
- Keep exhaust and exhaust pipes way from flammables.

1-4. Hydraulic Hazards



HYDRAULIC EQUIPMENT can injure or kill.

- Incorrect installation or operation of this unit could result in equipment failure and personal injury. Only qualified persons should install, operate, and service this unit according to its Owner's Manual, industry standards, and national, state, and local codes.
- Do not exceed the rated output or capacity of the hydraulic pump or any equipment in the hydraulic system. Design hydraulic system so failure of any hydraulic component will not put people or property at risk.
- Before working on hydraulic system, turn off and lockout/tagout unit, release pressure, and be sure hydraulic pressure cannot be accidentally applied.
- Do not work on hydraulic system with unit running unless you are a qualified person and following the manufacturer's instructions.
- Do not modify or alter hydraulic pump or manufacturer-supplied equipment. Do not disconnect, disable, or override any safety equipment in the hydraulic system.
- Use only components/accessories approved by the manufacturer.
- Keep away from potential pinch points or crush points created by equipment connected to the hydraulic system.
- Do not work under or around any equipment that is supported only by hydraulic pressure. Properly support equipment by mechanical means.



HYDRAULIC FLUID can injure or kill.

- Before working on hydraulic system, turn off and lockout/tagout unit, release pressure, and be sure hydraulic pressure cannot be accidentally applied.
- Relieve pressure before disconnecting or connecting hydraulic lines.
- Check hydraulic system components and all connections and hoses for damage, leaks, and wear before operating unit.
- Wear protective equipment such as safety glasses, leather gloves, heavy shirt and trousers, high shoes, and a cap when working on hydraulic system.

- Use a piece of paper or cardboard to search for leaks—never use bare hands. Do not use equipment if leaks are found.



1-5. Compressed Air Hazards



COMPRESSED AIR EQUIPMENT can injure or kill.

- Incorrect installation or operation of this unit could result in equipment failure and personal injury. Only qualified persons should install, operate, and service this unit according to its Owner's Manual, industry standards, and national, state, and local codes.
- Do not exceed the rated output or capacity of the compressor or any equipment in the compressed air system. Design compressed air system so failure of any component will not put people or property at risk.
- Before working on compressed air system, turn off and lockout/tagout unit, release pressure, and be sure air pressure cannot be accidentally applied.

- HYDRAULIC FLUID is FLAMMABLE—do not work on hydraulics near sparks or flames; do not smoke near hydraulic fluid.
- Reinstall doors, panels, covers, or guards when servicing is finished and before starting unit.
- If ANY fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type of injury or gangrene may result.




MOVING PARTS can injure.

- Keep away from moving parts such as fans, belts and rotors.
- Keep all doors, panels, covers, and guards closed and securely in place.
- Keep hands, hair, loose clothing, and tools away from moving parts.
- Before working on hydraulic system, turn off and lockout/tagout unit, release pressure, and be sure hydraulic pressure cannot be accidentally applied.
- Have only qualified people remove guards or covers for maintenance and troubleshooting as necessary.
- Reinstall doors, panels, covers, or guards when servicing is finished and before starting engine.



HOT PARTS AND FLUID can burn.

- Do not touch hot parts bare handed or allow hot fluid to contact skin.
- Allow cooling period before working on equipment.
- To handle hot parts, use proper tools and/or wear heavy, insulated welding gloves and clothing to prevent burns.



READ INSTRUCTIONS.


- Read and follow all labels and the Owner's Manual carefully before installing, operating, or servicing unit. Read the safety information at the beginning of the manual and in each section.
- Use only genuine replacement parts from the manufacturer.
- Perform maintenance and service according to the Owner's Manuals, industry standards, and national, state, and local codes.

- Do not work on compressed air system with unit running unless you are a qualified person and following the manufacturer's instructions.
- Do not modify or alter compressor or manufacturer-supplied equipment. Do not disconnect, disable, or override any safety equipment in the compressed air system.
- Use only components and accessories approved by the manufacturer.
- Keep away from potential pinch points or crush points created by equipment connected to the compressed air system.
- Do not work under or around any equipment that is supported only by air pressure. Properly support equipment by mechanical means.



HOT METAL from air arc cutting and gouging can cause fire or explosion.

- Do not cut or gouge near flammables.
- Watch for fire; keep extinguisher nearby.



COMPRESSED AIR can injure or kill.

- Before working on compressed air system, turn off and lockout/tagout unit, release pressure, and be sure air pressure cannot be accidentally applied.
- Relieve pressure before disconnecting or connecting air lines.
- Check compressed air system components and all connections and hoses for damage, leaks, and wear before operating unit.

- Do not direct air stream toward self or others.
- Wear protective equipment such as safety glasses, hearing protection, leather gloves, heavy shirt and trousers, high shoes, and a cap when working on compressed air system.
- Use soapy water or an ultrasonic detector to search for leaks—never use bare hands. Do not use equipment if leaks are found.
- Reinstall doors, panels, covers, or guards when servicing is finished and before starting unit.
- If ANY air is injected into the skin or body seek medical help immediately.



BREATHING COMPRESSED AIR can injure or kill.

- Do not use compressed air for breathing.
- Use only for cutting, gouging, and tools.



TRAPPED AIR PRESSURE AND WHIPPING HOSES can injure.

- Release air pressure from tools and system before servicing, adding or changing attachments, or opening compressor oil drain or oil fill cap.




MOVING PARTS can injure.

- Keep away from moving parts such as fans, belts and rotors.
- Keep all doors, panels, covers, and guards closed and securely in place.
- Keep hands, hair, loose clothing, and tools away from moving parts.
- Before working on compressed air system, turn off and lockout/tagout unit, release pressure, and be sure air pressure cannot be accidentally applied.
- Have only qualified people remove guards or covers for maintenance and troubleshooting as necessary.
- Reinstall doors, panels, covers, or guards when servicing is finished and before starting engine.



HOT PARTS can burn.

- Do not touch hot compressor or air system parts.
- Allow cooling period before working on equipment.
- To handle hot parts, use proper tools and/or wear heavy, insulated welding gloves and clothing to prevent burns.



READ INSTRUCTIONS.

- Read and follow all labels and the Owner's Manual carefully before installing, operating, or servicing unit. Read the safety information at the beginning of the manual and in each section.
- Use only genuine replacement parts from the manufacturer.
- Perform maintenance and service according to the Owner's Manuals, industry standards, and national, state, and local codes.

1-6. Additional Symbols For Installation, Operation, And Maintenance




FIRE OR EXPLOSION hazard.

- Do not install or place unit on, over, or near combustible surfaces.
- Do not install unit near flammables.
- Do not overload building wiring – be sure power supply system is properly sized, rated, and protected to handle this unit.




FALLING EQUIPMENT can injure.

- Use lifting eye to lift unit and properly installed accessories only, NOT gas cylinders. Do not exceed maximum lift eye weight rating (see Specifications).
- Use equipment of adequate capacity to lift and support unit.
- If using lift forks to move unit, be sure forks are long enough to extend beyond opposite side of unit.
- Keep equipment (cables and cords) away from moving vehicles when working from an aerial location.
- Follow the guidelines in the Applications Manual for the Revised NIOSH Lifting Equation (Publication No. 94-110) when manually lifting heavy parts or equipment.




OVERHEATING can damage motors.

- Turn off or unplug equipment before starting or stopping engine.
- Do not let low voltage and frequency caused by low engine speed damage electric motors.
- Do not connect 50 or 60 Hertz motors to the 100 Hertz receptacle where applicable.




FLYING SPARKS can injure.

- Wear a face shield to protect eyes and face.
- Shape tungsten electrode only on grinder with proper guards in a safe location wearing proper face, hand, and body protection.
- Sparks can cause fires — keep flammables away.




MOVING PARTS can injure.

- Keep away from moving parts.
- Keep away from pinch points such as drive rolls.




WELDING WIRE can injure.

- Do not press gun trigger until instructed to do so.
- Do not point gun toward any part of the body, other people, or any metal when threading welding wire.



OVERUSE can cause OVERHEATING.

- Allow cooling period; follow rated duty cycle.
- Reduce current or reduce duty cycle before starting to weld again.
- Do not block or filter airflow to unit.




STATIC (ESD) can damage PC boards.

- Put on grounded wrist strap BEFORE handling boards or parts.
- Use proper static-proof bags and boxes to store, move, or ship PC boards.




TILTING OF TRAILER can injure.

- Use tongue jack or blocks to support weight.
- Properly install welding generator onto trailer according to instructions supplied with trailer.




READ INSTRUCTIONS.

- Read and follow all labels and the Owner's Manual carefully before installing, operating, or servicing unit. Read the safety information at the beginning of the manual and in each section.
- Use only genuine replacement parts from the manufacturer.
- Perform maintenance and service according to the Owner's Manuals, industry standards, and national, state, and local codes.



H.F. RADIATION can cause interference.

- High-frequency (H.F.) can interfere with radio navigation, safety services, computers, and communications equipment.
- Have only qualified persons familiar with electronic equipment perform this installation.
- The user is responsible for having a qualified electrician promptly correct any interference problem resulting from the installation.
- If notified by the FCC about interference, stop using the equipment at once.
- Have the installation regularly checked and maintained.
- Keep high-frequency source doors and panels tightly shut, keep spark gaps at correct setting, and use grounding and shielding to minimize the possibility of interference.



ARC WELDING can cause interference.

- Electromagnetic energy can interfere with sensitive electronic equipment such as micro-processors, computers, and computer-driven equipment such as robots.
- Be sure all equipment in the welding area is electromagnetically compatible.
- To reduce possible interference, keep weld cables as short as possible, close together, and down low, such as on the floor.
- Locate welding operation 100 meters from any sensitive electronic equipment.
- Be sure this welding machine is installed and grounded according to this manual.
- If interference still occurs, the user must take extra measures such as moving the welding machine, using shielded cables, using line filters, or shielding the work area.

1-7. California Proposition 65 Warnings

- ⚠ **Welding or cutting equipment produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code Section 25249.5 et seq.)**
- ⚠ **Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. *Wash hands after handling.***
- ⚠ **This product contains chemicals, including lead, known to the state of California to cause cancer, birth defects, or other reproductive harm. *Wash hands after use.***

For Gasoline Engines:

- ⚠ **Engine exhaust contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.**

For Diesel Engines:

- ⚠ **Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.**

1-8. Principal Safety Standards

Safety in Welding, Cutting, and Allied Processes, ANSI Standard Z49.1, from Global Engineering Documents (phone: 1-877-413-5184, website: www.global.ihs.com).

Safe Practices for the Preparation of Containers and Piping for Welding and Cutting, American Welding Society Standard AWS F4.1, from Global Engineering Documents (phone: 1-877-413-5184, website: www.global.ihs.com).

National Electrical Code, NFPA Standard 70, from National Fire Protection Association, Quincy, MA 02269 (phone: 1-800-344-3555, website: www.nfpa.org and www.sparky.org).

Safe Handling of Compressed Gases in Cylinders, CGA Pamphlet P-1, from Compressed Gas Association, 4221 Walney Road, 5th Floor, Chantilly, VA 20151 (phone: 703-788-2700, website: www.cganet.com).

Safety in Welding, Cutting, and Allied Processes, CSA Standard W117.2, from Canadian Standards Association, Standards Sales, 5060 Spectrum Way, Suite 100, Ontario, Canada L4W 5NS (phone: 800-463-6727, website: www.csa-international.org).

Battery Chargers, CSA Standard C22.2 NO 107.2-01, from Canadian Standards Association, Standards Sales, 5060 Spectrum Way, Suite 100, Ontario, Canada L4W 5NS (phone: 800-463-6727, website: www.csa-international.org).

Safe Practice For Occupational And Educational Eye And Face Protection, ANSI Standard Z87.1, from American National Standards Institute,

25 West 43rd Street, New York, NY 10036 (phone: 212-642-4900, website: www.ansi.org).

Standard for Fire Prevention During Welding, Cutting, and Other Hot Work, NFPA Standard 51B, from National Fire Protection Association, Quincy, MA 02269 (phone: 1-800-344-3555, website: www.nfpa.org).

For Standards about hydraulic systems, contact the National Fluid Power Association, Publications Department, 3333 North Mayfair Road, Suite 211, Milwaukee, WI 53222-3219 (phone: (414) 778-3344, website: www.nfpa.com).

OSHA, Occupational Safety and Health Standards for General Industry, Title 29, Code of Federal Regulations (CFR), Part 1910, Subpart Q, and Part 1926, Subpart J, from U.S. Government Printing Office, Superintendent of Documents, P.O. Box 371954, Pittsburgh, PA 15250-7954 (phone: 1-866-512-1800) (there are 10 OSHA Regional Offices—phone for Region 5, Chicago, is 312-353-2220, website: www.osha.gov).

U.S. Consumer Product Safety Commission (CPSC), 4330 East West Highway, Bethesda, MD 20814 (phone: 301-504-7923, website: www.cpsc.gov).

Applications Manual for the Revised NIOSH Lifting Equation, The National Institute for Occupational Safety and Health (NIOSH), 1600 Clifton Rd, Atlanta, GA 30333 (phone: 1-800-232-4636, website: www.cdc.gov/NIOSH).

1-9. EMF Information

Electric current flowing through any conductor causes localized electric and magnetic fields (EMF). Welding current creates an EMF field around the welding circuit and welding equipment. EMF fields may interfere with some medical implants, e.g. pacemakers. Protective measures for persons wearing medical implants have to be taken. For example, access restrictions for passers-by or individual risk assessment for welders. All welders should use the following procedures in order to minimize exposure to EMF fields from the welding circuit:

1. Keep cables close together by twisting or taping them, or using a cable cover.
2. Do not place your body between welding cables. Arrange cables to one side and away from the operator.
3. Do not coil or drape cables around your body.

4. Keep head and trunk as far away from the equipment in the welding circuit as possible.
5. Connect work clamp to workpiece as close to the weld as possible.
6. Do not work next to, sit or lean on the welding power source.
7. Do not weld whilst carrying the welding power source or wire feeder.

About Implanted Medical Devices:

Implanted Medical Device wearers should consult their doctor and the device manufacturer before performing or going near arc welding, spot welding, gouging, plasma arc cutting, or induction heating operations. If cleared by your doctor, then following the above procedures is recommended.

SECTION 2 – CONSIGNES DE SÉCURITÉ – LIRE AVANT UTILISATION

fre_rom_2010-03

! Pour écarter les risques de blessure pour vous-même et pour autrui — lire, appliquer et ranger en lieu sûr ces consignes relatives aux précautions de sécurité et au mode opératoire.

2-1. Signification des symboles



DANGER! – Indique une situation dangereuse qui si on l'évite pas peut donner la mort ou des blessures graves. Les dangers possibles sont montrés par les symboles joints ou sont expliqués dans le texte.



Indique une situation dangereuse qui si on l'évite pas peut donner la mort ou des blessures graves. Les dangers possibles sont montrés par les symboles joints ou sont expliqués dans le texte.

NOTE – Indique des déclarations pas en relation avec des blessures personnelles.

Indique des instructions spécifiques.



Ce groupe de symboles veut dire Avertissement! Attention! DANGER DE CHOC ELECTRIQUE, PIECES EN MOUVEMENT, et PIECES CHAUDES. Consulter les symboles et les instructions ci-dessous y afférant pour les actions nécessaires afin d'éviter le danger.

2-2. Dangers relatifs au soudage à l'arc



Les symboles présentés ci-après sont utilisés tout au long du présent manuel pour attirer votre attention et identifier les risques de danger. Lorsque vous voyez un symbole, soyez vigilant et suivez les directives mentionnées afin d'éviter tout danger. Les consignes de sécurité présentées ci-après ne font que résumer l'information contenue dans les normes de sécurité énumérées à la section 2-8. Veuillez lire et respecter toutes ces normes de sécurité.



L'installation, l'utilisation, l'entretien et les réparations ne doivent être confiés qu'à des personnes qualifiées.



Au cours de l'utilisation, tenir toute personne à l'écart et plus particulièrement les enfants.



UN CHOC ÉLECTRIQUE peut tuer.

Un simple contact avec des pièces électriques peut provoquer une électrocution ou des blessures graves. L'électrode et le circuit de soudage sont sous tension dès que l'appareil est sur ON. Le circuit d'entrée et les circuits internes de l'appareil sont également sous tension à ce moment-là. En soudage semi-automatique ou automatique, le fil, le dévidoir, le logement des galets d'entraînement et les pièces métalliques en contact avec le fil de soudage sont sous tension. Des matériels mal installés ou mal mis à la terre présentent un danger.

- Ne jamais toucher les pièces électriques sous tension.
- Porter des gants et des vêtements de protection secs ne comportant pas de trous.
- S'isoler de la pièce et de la terre au moyen de tapis ou d'autres moyens isolants suffisamment grands pour empêcher le contact physique éventuel avec la pièce ou la terre.
- Ne pas se servir de source électrique à courant électrique dans les zones humides, dans les endroits confinés ou là où on risque de tomber.
- Se servir d'une source électrique à courant électrique UNIQUEMENT si le procédé de soudage le demande.
- Si l'utilisation d'une source électrique à courant électrique s'avère nécessaire, se servir de la fonction de télécommande si l'appareil en est équipé.
- Des précautions de sécurité supplémentaires sont requises dans des environnements à risque comme: les endroits humides ou lorsque l'on porte des vêtements mouillés; sur des structures métalliques au sol, grillages et échafaudages; dans des positions assises, à genoux et allongées; ou quand il y a un risque important de contact accidentel avec la pièce ou le sol. Dans ces cas utiliser les appareils suivants dans l'ordre de préférence: 1) un poste à

souder DC semi-automatique de type CV (MIG/MAG), 2) un poste à souder manuel (électrode enrobée) DC, 3) un poste à souder manuel AC avec tension à vide réduite. Dans la plupart des cas, un poste courant continu de type CV est recommandé. Et, ne pas travailler seul!

- Couper l'alimentation ou arrêter le moteur avant de procéder à l'installation, à la réparation ou à l'entretien de l'appareil. Déverrouiller l'alimentation selon la norme OSHA 29 CFR 1910.147 (voir normes de sécurité).
- Installer et mettre à la terre correctement cet appareil conformément à son manuel d'utilisation et aux codes nationaux, provinciaux et municipaux.
- Toujours vérifier la terre du cordon d'alimentation – Vérifier et s'assurer que le fil de terre du cordon d'alimentation est bien raccordé à la borne de terre du sectionneur ou que la fiche du cordon est raccordée à une prise correctement mise à la terre.
- En effectuant les raccordements d'entrée fixer d'abord le conducteur de mise à la terre approprié et contre-vérifier les connexions.
- Les câbles doivent être exempts d'humidité, d'huile et de graisse; protégez-les contre les étincelles et les pièces métalliques chaudes.
- Vérifier fréquemment le cordon d'alimentation pour voir s'il n'est pas endommagé ou dénudé – remplacer le cordon immédiatement s'il est endommagé – un câble dénudé peut provoquer une électrocution.
- Mettre l'appareil hors tension quand on ne l'utilise pas.
- Ne pas utiliser des câbles usés, endommagés, de grosseur insuffisante ou mal épissés.
- Ne pas enrôler les câbles autour du corps.
- Si la pièce soudée doit être mise à la terre, la faire directement avec un câble distinct – ne pas utiliser le connecteur de pièce ou le câble de retour.
- Ne pas toucher l'électrode quand on est en contact avec la pièce, la terre ou une électrode provenant d'une autre machine.
- Ne pas toucher des porte électrodes connectés à deux machines en même temps à cause de la présence d'une tension à vide doublée.
- N'utiliser qu'un matériel en bon état. Réparer ou remplacer sur-le-champ les pièces endommagées. Entretien l'appareil conformément à ce manuel.
- Porter un harnais de sécurité quand on travaille en hauteur.
- Maintenir solidement en place tous les panneaux et capots.
- Fixer le câble de retour de façon à obtenir un bon contact métal-métal avec la pièce à souder ou la table de travail, le plus près possible de la soudure.
- Isoler la pince de masse quand pas mis à la pièce pour éviter le contact avec tout objet métallique.


Il reste une TENSION DC NON NÉGLIGEABLE dans les sources de soudage onduleur UNE FOIS le moteur coupé.

- Couper l'alimentation du poste et décharger les condensateurs d'entrée comme indiqué dans la Section Maintenance avant de toucher des composants.



LES PIÈCES CHAUDES peuvent provoquer des brûlures.

- Ne pas toucher à mains nues les parties chaudes.
- Prévoir une période de refroidissement avant de travailler à l'équipement.
- Ne pas toucher aux pièces chaudes, utiliser les outils recommandés et porter des gants de soudage et des vêtements épais pour éviter les brûlures.



DES PIÈCES DE METAL ou DES SALETES peuvent provoquer des blessures dans les yeux.

- Le soudage, l'écaillage, le passage de la pièce à la brosse en fil de fer, et le meulage génèrent des étincelles et des particules métalliques volantes. Pendant la période de refroidissement des soudures, elles risquent de projeter du laitier.
- Porter des lunettes de sécurité avec écrans latéraux ou un écran facial.



LES FUMÉES ET LES GAZ peuvent être dangereux.


Le soudage génère des fumées et des gaz. Leur inhalation peut être dangereux pour votre santé.

- Eloigner votre tête des fumées. Ne pas respirer les fumées.
- À l'intérieur, ventiler la zone et/ou utiliser une ventilation forcée au niveau de l'arc pour l'évacuation des fumées et des gaz de soudage.
- Si la ventilation est médiocre, porter un respirateur anti-vapeurs approuvé.
- Lire et comprendre les spécifications de sécurité des matériaux (MSDS) et les instructions du fabricant concernant les métaux, les consommables, les revêtements, les nettoyants et les dégraissateurs.
- Travailler dans un espace fermé seulement s'il est bien ventilé ou en portant un respirateur à alimentation d'air. Demander toujours à un surveillant dûment formé de se tenir à proximité. Des fumées et des gaz de soudage peuvent déplacer l'air et abaisser le niveau d'oxygène provoquant des blessures ou des accidents mortels. S'assurer que l'air de respiration ne présente aucun danger.
- Ne pas souder dans des endroits situés à proximité d'opérations de dégraissage, de nettoyage ou de pulvérisation. La chaleur et les rayons de l'arc peuvent réagir en présence de vapeurs et former des gaz hautement toxiques et irritants.
- Ne pas souder des métaux munis d'un revêtement, tels que l'acier galvanisé, plaqué en plomb ou au cadmium à moins que le revêtement n'ait été enlevé dans la zone de soudure, que l'endroit soit bien ventilé, et en portant un respirateur à alimentation d'air. Les revêtements et tous les métaux renfermant ces éléments peuvent dégager des fumées toxiques en cas de soudage.



LES ACCUMULATIONS DE GAZ risquent de provoquer des blessures ou même la mort.


- Fermer l'alimentation du gaz protecteur en cas de non utilisation.
- Veiller toujours à bien aérer les espaces confinés ou se servir d'un respirateur d'adduction d'air homologué.



LES RAYONS DE L'ARC peuvent provoquer des brûlures dans les yeux et sur la peau.

Le rayonnement de l'arc du procédé de soudage génère des rayons visibles et invisibles intenses (ultraviolets et infrarouges) susceptibles de provoquer des brûlures dans les yeux et sur la peau. Des étincelles sont projetées pendant le soudage.


- Porter un casque de soudage approuvé muni de verres filtrants appropriés pour protéger visage et yeux pour protéger votre visage et vos yeux pendant le soudage ou pour regarder (voir ANSI Z49.1 et Z87.1 énuméré dans les normes de sécurité).
- Porter des lunettes de sécurité avec écrans latéraux même sous votre casque.
- Avoir recours à des écrans protecteurs ou à des rideaux pour protéger les autres contre les rayonnements les éblouissements et les étincelles ; prévenir toute personne sur les lieux de ne pas regarder l'arc.
- Porter des vêtements confectionnés avec des matières résistantes et ignifuges (cuir, coton lourd ou laine) et des bottes de protection.



LE SOUDAGE peut provoquer un incendie ou une explosion.

Le soudage effectué sur des conteneurs fermés tels que des réservoirs, tambours ou des conduites peut provoquer leur éclatement. Des étincelles peuvent être projetées de l'arc de soudure. La projection d'étincelles, des pièces chaudes et des équipements chauds peut provoquer des incendies et des brûlures. Le contact accidentel de l'électrode avec des objets métalliques peut provoquer des étincelles, une explosion, un surchauffement ou un incendie. Avant de commencer le soudage, vérifier et s'assurer que l'endroit ne présente pas de danger.

- Déplacer toutes les substances inflammables à une distance de 10,7 m de l'arc de soudage. En cas d'impossibilité les recouvrir soigneusement avec des protections homologués.
- Ne pas souder dans un endroit où des étincelles peuvent tomber sur des substances inflammables.
- Se protéger et d'autres personnes de la projection d'étincelles et de métal chaud.
- Des étincelles et des matériaux chauds du soudage peuvent facilement passer dans d'autres zones en traversant de petites fissures et des ouvertures.
- Surveiller tout déclenchement d'incendie et tenir un extincteur à proximité.
- Le soudage effectué sur un plafond, plancher, paroi ou séparation peut déclencher un incendie de l'autre côté.
- Ne pas effectuer le soudage sur des conteneurs fermés tels que des réservoirs, tambours, ou conduites, à moins qu'ils n'aient été préparés correctement conformément à AWS F4.1 (voir les normes de sécurité).
- Ne soudez pas si l'air ambiant est chargé de particules, gaz, ou vapeurs inflammables (vapeur d'essence, par exemple).
- Brancher le câble de masse sur la pièce le plus près possible de la zone de soudage pour éviter le transport du courant sur une longue distance par des chemins inconnus éventuels en provoquant des risques d'électrocution, d'étincelles et d'incendie.
- Ne pas utiliser le poste de soudage pour dégeler des conduites gelées.
- En cas de non utilisation, enlever la baguette d'électrode du porte-électrode ou couper le fil à la pointe de contact.
- Porter des vêtements de protection dépourvus d'huile tels que des gants en cuir, une chemise en matériau lourd, des pantalons sans revers, des chaussures hautes et un couvre chef.
- Avant de souder, retirer toute substance combustible de vos poches telles qu'un allumeur au butane ou des allumettes.
- Une fois le travail achevé, assurez-vous qu'il ne reste aucune trace d'étincelles incandescentes ni de flammes.
- Utiliser exclusivement des fusibles ou coupe-circuits appropriés. Ne pas augmenter leur puissance; ne pas les ponter.
- Suivre les recommandations dans OSHA 1910.252(a)(2)(iv) et NFPA 51B pour les travaux à chaud et avoir de la surveillance et un extincteur à proximité.



LE BRUIT peut affecter l'ouïe.


Le bruit des processus et des équipements peut affecter l'ouïe.

- Porter des protections approuvés pour les oreilles si le niveau sonore est trop élevé.



Les CHAMPS ÉLECTROMAGNÉTIQUES (CEM) peuvent affecter les implants médicaux.

- Les porteurs de stimulateurs cardiaques et autres implants médicaux doivent rester à distance.
- Les porteurs d'implants médicaux doivent consulter leur médecin et le fabricant du dispositif avant de s'approcher de la zone où se déroule du soudage à l'arc, du soudage par points, du gougeage, de la découpe plasma ou une opération de chauffage par induction.




Si des BOUTEILLES sont endommagées, elles pourront exploser.

Des bouteilles de gaz protecteur contiennent du gaz sous haute pression. Si une bouteille est endommagée, elle peut exploser. Du fait que les bouteilles de gaz sont normalement parties du procédé de soudage, les manipuler avec précaution.

- Protéger les bouteilles de gaz comprimé d'une chaleur excessive, des chocs mécaniques, des dommages physiques, du laitier, des flammes ouvertes, des étincelles et des arcs.

- Placer les bouteilles debout en les fixant dans un support stationnaire ou dans un porte-bouteilles pour les empêcher de tomber ou de se renverser.
- Tenir les bouteilles éloignées des circuits de soudage ou autres circuits électriques.
- Ne jamais placer une torche de soudage sur une bouteille à gaz.
- Une électrode de soudage ne doit jamais entrer en contact avec une bouteille.
- Ne jamais souder une bouteille pressurisée – risque d'explosion.
- Utiliser seulement des bouteilles de gaz protecteur, régulateurs, tuyaux et raccords convenables pour cette application spécifique; les maintenir ainsi que les éléments associés en bon état.
- Ne pas tenir la tête en face de la sortie en ouvrant la soupape de la bouteille.
- Maintenir le chapeau de protection sur la soupape, sauf en cas d'utilisation ou de branchement de la bouteille.
- Utiliser les équipements corrects, les bonnes procédures et suffisamment de personnes pour soulever et déplacer les bouteilles.
- Lire et suivre les instructions sur les bouteilles de gaz comprimé, l'équipement connexe et le dépliant P-1 de la CGA (Compressed Gas Association) mentionné dans les principales normes de sécurité.

2-3. Dangers existant en relation avec le moteur



L'EXPLOSION DE LA BATTERIE peut provoquer des blessures.

- Toujours porter une protection faciale, des gants en caoutchouc et vêtements de protection lors d'une intervention sur la batterie.
- Arrêter le moteur avant de débrancher ou de brancher des câbles de batterie, des câbles de chargeur de batterie (le cas échéant) ou de batterie d'entretien.
- Éviter de provoquer des étincelles avec les outils en travaillant sur la batterie.
- Ne pas utiliser l'appareil de soudage pour charger des batteries ou faire démarrer des véhicules à l'aide de câbles de démarrage, sauf si l'appareil dispose d'une fonctionnalité de charge de batterie destinée à cet usage.
- Observer la polarité correcte (+ et -) sur les batteries.
- Débrancher le câble négatif (-) en premier lieu. Le rebrancher en dernier lieu.
- Les sources d'étincelles, flammes nues, cigarettes et autres sources d'inflammation doivent être maintenues à l'écart des batteries. Ces dernières produisent des gaz explosifs en fonctionnement normal et en cours de charge.
- Respecter les consignes du fabricant de la batterie pour travailler sur une batterie ou à proximité.

Le COURANT DE CHARGE DE BATTERIE peut provoquer des blessures (la fonctionnalité de charge de batterie n'est pas disponible sur tous les modèles).

- Les opérations de charge de batterie ne doivent être effectuées que par des personnes qualifiées.
- Ne charger que des batteries plomb-acide. Ne pas utiliser le chargeur de batterie pour alimenter un autre circuit électrique basse tension ou pour charger des batteries sèches.
- Ne pas charger une batterie gelée.
- Ne pas utiliser de câbles de charge endommagés.
- Ne pas charger une batterie dont les bornes sont desserrées ou présentant une détérioration comme par exemple un boîtier ou un couvercle fissuré.
- Avant de charger une batterie, sélectionner la tension de charge correspondant à la tension de la batterie.
- Régler les commandes de charge de batterie sur la position d'arrêt avant de brancher la batterie. Veiller à ce que les pinces de charge ne se touchent pas.

- Ranger les câbles de charge à distance du capot, des portes et des pièces mobiles du véhicule.



LE CARBURANT MOTEUR peut provoquer un incendie ou une explosion.

- Arrêter le moteur avant de vérifier le niveau de carburant ou de faire le plein.
- Ne pas faire le plein en fumant ou proche d'une source d'étincelles ou d'une flamme nue.
- Ne pas faire le plein de carburant à ras bord; prévoir de l'espace pour son expansion.
- Faire attention de ne pas renverser de carburant. Nettoyer tout carburant renversé avant de faire démarrer le moteur.
- Jeter les chiffons dans un récipient ignifuge.
- Toujours garder le pistolet en contact avec le réservoir lors du remplissage.



Les PIÈCES MOBILES peuvent causer des blessures.

- S'abstenir de toucher des parties mobiles telles que des ventilateurs, courroies et rotors.
- Maintenir fermés et verrouillés les portes, panneaux, recouvrements et dispositifs de protection.
- Arrêter le moteur avant d'installer ou brancher l'appareil.
- Lorsque cela est nécessaire pour des travaux d'entretien et de dépannage, faire retirer les portes, panneaux, recouvrements ou dispositifs de protection uniquement par du personnel qualifié.
- Pour empêcher tout démarrage accidentel pendant les travaux d'entretien, débrancher le câble négatif (-) de batterie de la borne.
- Ne pas approcher les mains, cheveux, vêtements lâches et outils des organes mobiles.
- Remettre en place les portes, panneaux, recouvrements ou dispositifs de protection à la fin des travaux d'entretien et avant de mettre le moteur en marche.
- Avant d'intervenir, déposer les bougies ou injecteurs pour éviter la mise en route accidentelle du moteur.
- Bloquer le volant moteur pour éviter sa rotation lors d'une intervention sur le générateur.



LES ÉTINCELLES À L'ÉCHAPPEMENT peuvent provoquer un incendie.

- Empêcher les étincelles d'échappement du moteur de provoquer un incendie.
- Utiliser uniquement un pare-étincelles approuvé – voir codes en vigueur.



LES PIÈCES CHAUDES peuvent provoquer des brûlures.


- Ne pas toucher des parties chaudes à mains nues.
- Prévoir une période de refroidissement avant de travailler à l'équipement.
- Ne pas toucher aux pièces chaudes, utiliser les outils recommandés et porter des gants de soudage et des vêtements épais pour éviter les brûlures.



LA VAPEUR ET LE LIQUIDE DE REFROIDISSEMENT CHAUD peuvent provoquer des brûlures.

- Il est préférable de vérifier le liquide de refroidissement une fois le moteur refroidi pour éviter de se brûler.
- Toujours vérifier le niveau de liquide de refroidissement dans le vase d'expansion (si présent), et non dans le radiateur (sauf si précisé autrement dans la section maintenance du manuel du moteur).
- Si le moteur est chaud et que le liquide doit être vérifié, opérer comme suivant.


2-4. Dangers liés à l'hydraulique



Les ÉQUIPEMENTS HYDRAULIQUES peuvent provoquer des blessures ou même la mort.


- Une installation ou une utilisation incorrecte de cet appareil pourrait conduire à des dégâts matériels ou corporels. Seul un personnel qualifié est autorisé à installer, faire fonctionner et réparer cet appareil conformément à son manuel d'utilisation, aux normes industrielles et aux codes nationaux, d'état ou locaux.
- Ne pas dépasser le débit nominal ou la capacité de la pompe hydraulique ou de tout équipement du circuit hydraulique. Concevoir le circuit hydraulique de telle sorte que la défaillance d'un composant hydraulique ne risque pas de provoquer un accident matériel ou corporel.
- Avant d'intervenir sur le circuit hydraulique, couper l'alimentation électrique, verrouiller et étiqueter l'appareil, détendre la pression et s'assurer que le circuit hydraulique ne peut être remis sous pression par inadvertance.
- Ne pas intervenir sur le circuit hydraulique lorsque l'appareil fonctionne. Seul un personnel qualifié et appliquant les consignes du fabricant est autorisé à le faire.
- Ne pas modifier ou altérer la pompe hydraulique ou les équipements fournis par le fabricant. Ne pas débrancher, désactiver ou neutraliser les équipements de sécurité du circuit hydraulique.
- Utiliser uniquement des composants et accessoires homologués par le fabricant.
- Se tenir à l'écart de tout point présentant un danger de pincement ou d'écrasement créé par l'équipement raccordé au circuit hydraulique.

- Mettre des lunettes de sécurité et des gants, placer un torchon sur le bouchon du radiateur.
- Dévisser le bouchon légèrement et laisser la vapeur s'échapper avant d'enlever le bouchon.



L'utilisation d'un groupe autonome à l'intérieur PEUT VOUS TUER EN QUELQUES MINUTES.

- Les fumées d'un groupe autonome contient du monoxyde de carbone. C'est un poison invisible et inodore.
- JAMAIS utiliser dans une maison ou garage, même avec les portes et fenêtres ouvertes.
- Uniquement utiliser à l'EXTERIEUR, loin des portes, fenêtres et bouches aération.



L'ACIDE DE LA BATTERIE peut provoquer des brûlures dans les YEUX et sur la PEAU.

- Ne pas renverser la batterie.
- Remplacer une batterie endommagée.
- Rincer immédiatement les yeux et la peau à l'eau.




LA CHALEUR DU MOTEUR peut provoquer un incendie.

- Ne pas placer l'appareil sur, au-dessus ou à proximité de surfaces inflammables.
- Tenir à distance les produits inflammables de l'échappement.



Le LIQUIDE HYDRAULIQUE risque de provoquer des blessures ou même la mort.



- Avant d'intervenir sur le circuit hydraulique, couper l'alimentation électrique, verrouiller et étiqueter l'appareil, détendre la pression et s'assurer que le circuit hydraulique ne peut être remis sous pression par inadvertance.
- Détendre la pression avant de débrancher ou de brancher des canalisations hydrauliques.
- Avant d'utiliser l'appareil, contrôler les composants du circuit hydraulique, les branchements et les flexibles en recherchant tout signe de détérioration, de fuite et d'usure.
- Pour intervenir sur un circuit hydraulique, porter un équipement de protection tel que des lunettes de sécurité, des gants de cuir, une chemise et un pantalon en tissu résistant, des chaussures montantes et une coiffe.
- Pour rechercher des fuites, utiliser un morceau de papier ou de carton, jamais les mains nues. En cas de détection de fuite, ne pas utiliser l'équipement.
- Le LIQUIDE HYDRAULIQUE est INFLAMMABLE. Ne pas intervenir sur des composants hydrauliques à proximité d'étincelles ou de flammes; ne pas fumer à proximité de liquide hydraulique.
- Remettre les portes, panneaux, recouvrements ou dispositifs de protection quand l'entretien est terminé et avant de mettre en marche l'appareil.
- En cas de pénétration d'un QUELCONQUE liquide dans la peau, celui-ci doit être retiré chirurgicalement sous quelques heures par

un médecin familiarisé avec ce type de blessure, faute de quoi la gangrène pourrait apparaître.




Les PIÈCES MOBILES peuvent causer des blessures.

- S'abstenir de toucher des parties mobiles telles que des ventilateurs, courroies et rotors.
- Maintenir fermés et verrouillés les portes, panneaux, recouvrements et dispositifs de protection.
- Ne pas approcher les mains, cheveux, vêtements lâches et outils des organes mobiles.
- Avant d'intervenir sur le circuit hydraulique, couper l'alimentation électrique, verrouiller et étiqueter l'appareil, détendre la pression et s'assurer que le circuit hydraulique ne peut être remis sous pression par inadvertance.
- Demander seulement à un personnel qualifié d'enlever les dispositifs de sécurité ou les recouvrements pour effectuer, s'il y a lieu, des travaux d'entretien et de dépannage.
- Remettre en place les portes, panneaux, recouvrements ou dispositifs de protection à la fin des travaux d'entretien et avant de mettre le moteur en marche.



LES PIÈCES ET LIQUIDES CHAUDS peuvent provoquer des brûlures.


- Ne pas toucher les pièces chaudes à main nue ni laisser des liquides chauds entrer en contact avec la peau.
- Prévoir une période de refroidissement avant d'intervenir sur l'équipement.
- Ne pas toucher aux pièces chaudes, utiliser les outils recommandés et porter des gants de soudage et des vêtements épais pour éviter les brûlures.



LIRE LES INSTRUCTIONS.


- Lire et appliquer les instructions sur les étiquettes et le Mode d'emploi avant l'installation, l'utilisation ou l'entretien de l'appareil. Lire les informations de sécurité au début du manuel et dans chaque section.
- N'utiliser que les pièces de rechange recommandées par le constructeur.
- Effectuer l'entretien en respectant les manuels d'utilisation, les normes industrielles et les codes nationaux, d'état et locaux.

2-5. Dangers liés à l'air comprimé



Un ÉQUIPEMENT PNEUMATIQUE risque de provoquer des blessures ou même la mort.

- Une installation ou une utilisation incorrecte de cet appareil pourrait conduire à des dégâts matériels ou corporels. Seul un personnel qualifié est autorisé à installer, utiliser et entretenir cet appareil conformément à son manuel d'utilisation, aux normes industrielles et aux codes nationaux, d'état ou locaux.
- Ne pas dépasser le débit nominal ou la capacité du compresseur ou de tout équipement du circuit d'air comprimé. Concevoir le circuit d'air comprimé de telle sorte que la défaillance d'un composant ne risque pas de provoquer un accident matériel ou corporel.
- Avant d'intervenir sur le circuit d'air comprimé, couper l'alimentation électrique, verrouiller et étiqueter l'appareil, détendre la pression et s'assurer que le circuit d'air ne peut être mis sous pression par inadvertance.
- Ne pas intervenir sur le circuit d'air comprimé lorsque l'appareil fonctionne. Seul un personnel qualifié est autorisé, et appliquant les consignes du fabricant.
- Ne pas modifier ou altérer le compresseur ou les équipements fournis par le fabricant. Ne pas débrancher, désactiver ou neutraliser les équipements de sécurité du circuit d'air comprimé.
- Utiliser uniquement des composants et accessoires homologués par le fabricant.
- Se tenir à l'écart de tout point présentant un danger de pincement ou d'écrasement créé par l'équipement raccordé au circuit d'air comprimé.
- Ne pas intervenir sous ou autour d'un équipement qui n'est soutenu que par la pression pneumatique. Soutenir l'équipement de façon appropriée par un moyen mécanique.



L'AIR COMPRIMÉ risque de provoquer des blessures ou même la mort.

- Avant d'intervenir sur le circuit d'air comprimé, couper l'alimentation électrique, verrouiller et étiqueter l'appareil, détendre la pression et s'assurer que le circuit d'air ne peut être mis sous pression par inadvertance.
- Détendre la pression avant de débrancher ou de brancher des canalisations d'air.
- Avant d'utiliser l'appareil, contrôler les composants du circuit d'air comprimé, les branchements et les flexibles en recherchant tout signe de détérioration, de fuite et d'usure.
- Ne pas diriger un jet d'air vers soi-même ou vers autrui.
- Pour intervenir sur un circuit d'air comprimé, porter un équipement de protection tel que des lunettes de sécurité, des gants de cuir, une chemise et un pantalon en tissu résistant, des chaussures montantes et une coiffe.
- Pour rechercher des fuites, utiliser de l'eau savonneuse ou un détecteur à ultrasons, jamais les mains nues. En cas de détection de fuite, ne pas utiliser l'équipement.
- Remettre les portes, panneaux, recouvrements ou dispositifs de protection quand l'entretien est terminé et avant de mettre en marche l'appareil.
- En cas d'injection d'air dans la peau ou le corps, demander immédiatement une assistance médicale.



MÉTAL CHAUD provenant du découpage ou du gougeage à l'arc risque de provoquer un incendie ou une explosion.

- Ne pas découper ou gouger à proximité de produits inflammables.
- Attention aux risques d'incendie: tenir un extincteur à proximité.



L'INHALATION D'AIR COMPRIMÉ risque de provoquer des blessures ou même la mort.

- Ne pas inhaler d'air comprimé.
- Utiliser l'air comprimé uniquement pour découper ou gouger ainsi que pour l'outillage pneumatique.



Une **PRESSION D'AIR RÉSIDUELLE** ET DES **FLEXIBLES QUI FOUETTENT** risquent de provoquer des blessures.

- Détendre la pression pneumatique des outils et circuits avant d'entretenir, ajouter ou changer des accessoires et avant d'ouvrir le bouchon de vidange ou de remplissage d'huile du compresseur.



Les **PIÈCES MOBILES** peuvent causer des blessures.

- S'abstenir de toucher des parties mobiles telles que des ventilateurs, courroies et rotors.
- Maintenir fermés et verrouillés les portes, panneaux, recouvrements et dispositifs de protection.


- Ne pas approcher les mains, cheveux, vêtements lâches et outils des organes mobiles.
- Avant d'intervenir sur le circuit d'air comprimé, couper l'alimentation électrique, verrouiller et étiqueter l'appareil, détendre la pression et s'assurer que le circuit d'air ne peut être mis sous pression par inadvertance.
- Demander seulement à un personnel qualifié d'enlever les dispositifs de sécurité ou les recouvrements pour effectuer, s'il y a lieu, des travaux d'entretien et de dépannage.

- Remettre en place les portes, panneaux, recouvrements ou dispositifs de protection à la fin des travaux d'entretien et avant de mettre le moteur en marche.



DES **PIÈCES CHAUDES** peuvent provoquer des brûlures graves.

- Ne pas toucher de pièces chaudes du compresseur ou du circuit d'air.
- Prévoir une période de refroidissement avant d'intervenir sur l'équipement.
- Ne pas toucher aux pièces chaudes, utiliser les outils recommandés et porter des gants de soudage et des vêtements épais pour éviter les brûlures.



LIRE LES INSTRUCTIONS.


- Lire et appliquer les instructions sur les étiquettes et le Mode d'emploi avant l'installation, l'utilisation ou l'entretien de l'appareil. Lire les informations de sécurité au début du manuel et dans chaque section.
- N'utiliser que les pièces de rechange recommandées par le constructeur.
- Effectuer l'entretien en respectant les manuels d'utilisation, les normes industrielles et les codes nationaux, d'état et locaux.

2-6. Dangers supplémentaires en relation avec l'installation, le fonctionnement et la maintenance



Risque D'INCENDIE OU D'EXPLOSION.

- Ne pas placer l'appareil sur, au-dessus ou à proximité de surfaces inflammables.
- Ne pas installer l'appareil à proximité de produits inflammables.
- Ne pas surcharger l'installation électrique – s'assurer que l'alimentation est correctement dimensionnée et protégée avant de mettre l'appareil en service.



LES **ÉTINCELLES PROJETÉES** peuvent provoquer des blessures.

- Porter un écran facial pour protéger le visage et les yeux.
- Affûter l'électrode au tungstène uniquement à la meuleuse dotée de protecteurs. Cette manœuvre est à exécuter dans un endroit sûr lorsque l'on porte l'équipement homologué de protection du visage, des mains et du corps.
- Les étincelles risquent de causer un incendie – éloigner toute substance inflammable.




LA **CHUTE DE L'ÉQUIPEMENT** peut provoquer des blessures.

- Utiliser l'anneau de levage pour lever l'appareil et les accessoires correctement installés seuls, PAS les bouteilles de gaz. Ne pas dépasser le poids nominal maximal de l'ocillon (voir les spécifications).
- Utiliser un équipement de levage de capacité suffisante pour lever l'appareil.
- En utilisant des fourches de levage pour déplacer l'unité, s'assurer que les fourches sont suffisamment longues pour dépasser du côté opposé de l'appareil.
- Tenir l'équipement (câbles et cordons) à distance des véhicules mobiles lors de toute opération en hauteur.
- Suivre les consignes du Manuel des applications pour l'équation de levage NIOSH révisée (Publication N°94-110) lors du levage manuel de pièces ou équipements lourds.




Les **PIÈCES MOBILES** peuvent causer des blessures.

- Ne pas s'approcher des organes mobiles.
- Ne pas s'approcher des points de coincement tels que des rouleaux de commande.




LES **FILS DE SOUDAGE** peuvent provoquer des blessures.

- Ne pas appuyer sur la gâchette avant d'en avoir reçu l'instruction.
- Ne pas diriger le pistolet vers soi, d'autres personnes ou toute pièce mécanique en engageant le fil de soudage.




LE **SURCHAUFFEMENT** peut endommager le moteur électrique.

- Arrêter ou déconnecter l'équipement avant de démarrer ou d'arrêter le moteur.
- Ne pas laisser tourner le moteur trop lentement sous risque d'endommager le moteur électrique à cause d'une tension et d'une fréquence trop faibles.
- Ne pas brancher de moteur de 50 ou de 60 Hz à la prise de 100 Hz, s'il y a lieu.



L'EMPLOI EXCESSIF peut SURCHAUFFER L'ÉQUIPEMENT.

- Laisser l'équipement refroidir ; respecter le facteur de marche nominal.
- Réduire le courant ou le facteur de marche avant de poursuivre le soudage.
- Ne pas obstruer les passages d'air du poste.




LES CHARGES ÉLECTROSTATIQUES peuvent endommager les circuits imprimés.

- Établir la connexion avec la barrette de terre avant de manipuler des cartes ou des pièces.
- Utiliser des pochettes et des boîtes antistatiques pour stocker, déplacer ou expédier des cartes de circuits imprimés.




UNE REMORQUE QUI BASCULE peut provoquer des blessures.

- Utiliser les supports de la remorque ou des blocs pour soutenir le poids.
- Installer convenablement le poste sur la remorque comme indiqué dans le manuel s'y rapportant.



LIRE LES INSTRUCTIONS.


- Lire et appliquer les instructions sur les étiquettes et le Mode d'emploi avant l'installation, l'utilisation ou l'entretien de l'appareil. Lire les informations de sécurité au début du manuel et dans chaque section.
- N'utiliser que les pièces de rechange recommandées par le constructeur.
- Effectuer l'entretien en respectant les manuels d'utilisation, les normes industrielles et les codes nationaux, d'état et locaux.



LE RAYONNEMENT HAUTE FRÉQUENCE (H.F.) risque de provoquer des interférences.

- Le rayonnement haute fréquence (H.F.) peut provoquer des interférences avec les équipements de radio-navigation et de communication, les services de sécurité et les ordinateurs.

- Demander seulement à des personnes qualifiées familiarisées avec des équipements électroniques de faire fonctionner l'installation.
- L'utilisateur est tenu de faire corriger rapidement par un électricien qualifié les interférences résultant de l'installation.
- Si le FCC signale des interférences, arrêter immédiatement l'appareil.
- Effectuer régulièrement le contrôle et l'entretien de l'installation.
- Maintenir soigneusement fermés les portes et les panneaux des sources de haute fréquence, maintenir les éclateurs à une distance correcte et utiliser une terre et un blindage pour réduire les interférences éventuelles.



LE SOUDAGE À L'ARC risque de provoquer des interférences.

- L'énergie électromagnétique risque de provoquer des interférences pour l'équipement électronique sensible tel que les ordinateurs et l'équipement commandé par ordinateur tel que les robots.
- Veiller à ce que tout l'équipement de la zone de soudage soit compatible électromagnétiquement.
- Pour réduire la possibilité d'interférence, maintenir les câbles de soudage aussi courts que possible, les grouper, et les poser aussi bas que possible (ex. par terre).
- Veiller à souder à une distance de 100 mètres de tout équipement électronique sensible.
- Veiller à ce que ce poste de soudage soit posé et mis à la terre conformément à ce mode d'emploi.
- En cas d'interférences après avoir pris les mesures précédentes, il incombe à l'utilisateur de prendre des mesures supplémentaires telles que le déplacement du poste, l'utilisation de câbles blindés, l'utilisation de filtres de ligne ou la pose de protecteurs dans la zone de travail.

2-7. Proposition californienne 65 Avertissements

! Les équipements de soudage et de coupage produisent des fumées et des gaz qui contiennent des produits chimiques dont l'État de Californie reconnaît qu'ils provoquent des malformations congénitales et, dans certains cas, des cancers. (Code de santé et de sécurité de Californie, chapitre 25249.5 et suivants)

! Les batteries, les bornes et autres accessoires contiennent du plomb et des composés à base de plomb, produits chimiques dont l'État de Californie reconnaît qu'ils provoquent des cancers et des malformations congénitales ou autres problèmes de procréation. *Se laver les mains après manipulation.*

! Ce produit contient des éléments chimiques, dont le plomb, reconnus par l'État de Californie pour leur caractère

cancérogène ainsi que provoquant des malformations congénitales ou autres problèmes de procréation. *Se laver les mains après toute manipulation.*

Pour les moteurs à essence :

! Les gaz d'échappement des moteurs contiennent des produits chimiques dont l'État de Californie reconnaît qu'ils provoquent des cancers et des malformations congénitales ou autres problèmes de procréation.

Pour les moteurs diesel :

! Les gaz d'échappement des moteurs diesel et certains de leurs composants sont reconnus par l'État de Californie comme provoquant des cancers et des malformations congénitales ou autres problèmes de procréation.

2-8. Principales normes de sécurité

Safety in Welding, Cutting, and Allied Processes, ANSI Standard Z49.1, from Global Engineering Documents (phone: 1-877-413-5184, website: www.global.ihs.com).

Safe Practices for the Preparation of Containers and Piping for Welding and Cutting, American Welding Society Standard AWS F4.1, from Global Engineering Documents (phone: 1-877-413-5184, website: www.global.ihs.com).

National Electrical Code, NFPA Standard 70, from National Fire Protection Association, Quincy, MA 02269 (phone: 1-800-344-3555, website: www.nfpa.org and www.sparky.org).

Safe Handling of Compressed Gases in Cylinders, CGA Pamphlet P-1, from Compressed Gas Association, 4221 Walney Road, 5th Floor, Chantilly, VA 20151 (phone: 703-788-2700, website: www.cganet.com).

Safety in Welding, Cutting, and Allied Processes, CSA Standard W117.2, from Canadian Standards Association, Standards Sales, 5060 Spectrum Way, Suite 100, Ontario, Canada L4W 5N5 (phone: 800-463-6727, website: www.csa-international.org).

Battery Chargers, CSA Standard C22.2 NO 107.2-01, from Canadian Standards Association, Standards Sales, 5060 Spectrum Way, Suite 100, Ontario, Canada L4W 5N5 (phone: 800-463-6727, website: www.csa-international.org).

Safe Practice For Occupational And Educational Eye And Face Protection, ANSI Standard Z87.1, from American National Standards Institute,

25 West 43rd Street, New York, NY 10036 (phone: 212-642-4900, website: www.ansi.org).

Standard for Fire Prevention During Welding, Cutting, and Other Hot Work, NFPA Standard 51B, from National Fire Protection Association, Quincy, MA 02269 (phone: 1-800-344-3555, website: www.nfpa.org).

For Standards about hydraulic systems, contact the National Fluid Power Association, Publications Department, 3333 North Mayfair Road, Suite 211, Milwaukee, WI 53222-3219 (phone: (414) 778-3344, website: www.nfpa.com).

OSHA, Occupational Safety and Health Standards for General Industry, Title 29, Code of Federal Regulations (CFR), Part 1910, Subpart Q, and Part 1926, Subpart J, from U.S. Government Printing Office, Superintendent of Documents, P.O. Box 371954, Pittsburgh, PA 15250-7954 (phone: 1-866-512-1800) (there are 10 OSHA Regional Offices—phone for Region 5, Chicago, is 312-353-2220, website: www.osha.gov).

U.S. Consumer Product Safety Commission (CPSC), 4330 East West Highway, Bethesda, MD 20814 (phone: 301-504-7923, website: www.cpsc.gov).

Applications Manual for the Revised NIOSH Lifting Equation, The National Institute for Occupational Safety and Health (NIOSH), 1600 Clifton Rd, Atlanta, GA 30333 (phone: 1-800-232-4636, website: www.cdc.gov/NIOSH).

2-9. Informations relatives aux CEM

Le courant électrique qui traverse tout conducteur génère des champs électromagnétiques (CEM) à certains endroits. Le courant de soudage crée un CEM autour du circuit et du matériel de soudage. Les CEM peuvent créer des interférences avec certains implants médicaux comme des stimulateurs cardiaques. Des mesures de protection pour les porteurs d'implants médicaux doivent être prises: par exemple, des restrictions d'accès pour les passants ou une évaluation individuelle des risques pour les soudeurs. Tous les soudeurs doivent appliquer les procédures suivantes pour minimiser l'exposition aux CEM provenant du circuit de soudage:


1. Rassembler les câbles en les torsadant ou en les attachant avec du ruban adhésif ou avec une housse.
2. Ne pas se tenir au milieu des câbles de soudage. Disposer les câbles d'un côté et à distance de l'opérateur.
3. Ne pas courber et ne pas entourer les câbles autour de votre corps.



































4. Maintenir la tête et le torse aussi loin que possible du matériel du circuit de soudage.
5. Connecter la pince sur la pièce aussi près que possible de la soudure.
6. Ne pas travailler à proximité d'une source de soudage, ni s'asseoir ou se pencher dessus.
7. Ne pas souder tout en portant la source de soudage ou le dévidoir.

En ce qui concerne les implants médicaux :

Les porteurs d'implants doivent d'abord consulter leur médecin avant de s'approcher des opérations de soudage à l'arc, de soudage par points, de gougeage, du coupage plasma ou de chauffage par induction. Si le médecin approuve, il est recommandé de suivre les procédures précédentes.


3-2. Symbols And Definitions

 Some symbols are found only on CE products.

| | | | | | | | |
|---|----------------------|---|---------------------------------------|---|--|---|-----------------------------|
|  | Stop Engine |  | Fast (Run, Weld/Power) |  | Slow (Idle) |  | Start Engine |
|  | Starting Aid |  | Battery (Engine) |  | Engine Oil Pressure |  | Engine Oil |
|  | Check Injectors/Pump |  | Check Valve Clearance |  | Fuel |  | Protective Earth (Ground) |
| + | Positive | - | Negative |  | Certified/Trained Mechanic |  | Welding Arc |
| A | Amperes | V | Volts |  | Panel/Local |  | Remote |
|  | Engine |  | Air Temperature Or Engine Temperature |  | Output |  | Alternating Current |
|  | Stick (SMAW) Welding |  | Constant Current (CC) |  | MIG (GMAW) Welding |  | TIG (GTAW) |
|  | Time | h | Hours | s | Seconds |  | Single Phase |
|  | Three Phase |  | Read Operator's Manual |  | Circuit Protector |  | Do Not Switch While Welding |
|  | Electrode Connection |  | Work Connection |  | Engine-Driven, Three-Phase Alternator With Rectifier | Hz | Hertz |
| X | Duty Cycle | U₀ | Rated No Load Voltage (Average) | U₂ | Conventional Load Voltage | n | Rated Load Speed |
| n₁ | Rated Idle Speed | n₀ | Rated No Load Speed | I | Current | I₂ | Rated Welding Current |
|  | Contactor On | | | | | | |


SECTION 4 – SPECIFICATIONS

4-1. Weld, Power, And Engine Specifications



| Welding Mode | Weld Output Range | Rated Welding Output | Maximum Open-Circuit Voltage | Generator Power Rating | Engine | Fuel Capacity |
|--------------|-------------------|---|------------------------------|--|---|------------------|
| CC/DC | 55 – 500 A | 500 A, 30 Volts DC 40% Duty Cycle IEC Rating 400 A, 36 Volts DC, 100% Duty Cycle 450 A, 38 Volts DC, 60% Duty Cycle | 95 | Single-Phase, 4 kVA/kW, 34/17 A, 120/240 V AC, 50/60 Hz |  DEUTZ Deutz D2011L03i Air/Oil-Cooled, Three Cylinder, 31.9 HP Diesel Engine | 25 gal (95 L) |

4-2. Dimensions, Weights, And Operating Angles

| Dimensions | |
|--|--|
| Height | 60 in (1524 mm) (to top of muffler) |
| Width | 28-1/2 in (724 mm) (mtg. brackets turned in) |
| | 30-3/4 in (781 mm) (mtg. brackets turned out) |
| Depth | 65-1/8 in (1654 mm) |
| A | 65-1/8 in (1654 mm) |
| B* | 56 in (1422 mm) |
| C* | 46-1/2 in (1181) |
| D* | 9-5/8 in (244 mm) |
| E | 27-1/2 in (699 mm) |
| F | 1 in (25 mm) |
| G | 29-13/16 in (757 mm) |
| H | 9/16 in (14 mm) Dia. 4 Holes |
| * With mounting brackets in center position. Dimensions vary with location of mounting brackets. | |
| Weight | |
| No fuel: 1600 lb (726 kg) w/fuel: 1775 lb (805 kg) | |
| Lifting Eye Weight Rating: 2500 lb (1134 kg) Maximum | |




802 161-A


Do not exceed tilt angles or engine could be damaged or unit could tip.

Do not move or operate unit where it could tip.



4-3. Volt-Ampere Curves


The volt-ampere curve shows the minimum and maximum voltage and amperage output capabilities of the welding generator. Curves of all other settings fall between the curves shown.



215 081-A

4-4. Fuel Consumption

The curve shows typical fuel use under weld or power loads.




199 032

4-5. Duty Cycle And Overheating




100% Duty Cycle At 400 Amperes



Continuous Welding


Duty Cycle is percentage of 10 minutes that unit can weld at rated load without overheating.

NOTICE – Exceeding duty cycle can damage unit and void warranty.



215 084-A

4-6. AC Generator Power Curve



The ac power curve shows the generator power in amperes available at the 120 and 240 volt receptacles.

193 018

SECTION 5 – INSTALLATION

5-1. Serial Number And Rating Label Location


The serial number and rating information for this product is located on the front. Use rating label to determine input power requirements and/or rated output. For future reference, write serial number in space provided on back cover of this manual.

5-2. Installing Welding Generator



- Do not move or operate unit where it could tip.
- Always securely fasten welding generator onto transport vehicle or trailer and comply with all DOT and other applicable codes.




Movement



NOTICE – Do not install unit where air flow is restricted or engine may overheat.

- See Section 4-2 for lifting eye rating.
- See Section 5-3 for mounting information.

Location/Airflow Clearance





install3 2008-01 – Ref. 800 652 / Ref. 800 477-A / 803 274 / 804 712

5-3. Mounting Welding Generator



Supporting The Unit



⚠ Do not weld on base. Welding on base can cause fuel tank fire or explosion. Weld only on the four mounting brackets or bolt unit down.

NOTICE – Do not mount unit by supporting the base only at the four mounting brackets. Use cross-supports to adequately support unit and prevent damage to base.

Mounting Surface:

1 Cross-Supports
2 Mounting Brackets (Supplied)
Mount unit on flat surface or use cross-supports to support base. Secure unit with mounting brackets.

3 1/2 in Bolt And Washer (Minimum – Not Supplied)
4 3/8-16 x 1 in Screws (Supplied)

To Bolt Unit In Place:



Remove hardware securing the four mounting brackets to the base. Reverse brackets and reattach to base with original hardware.


Mount unit to truck or trailer with 1/2 in (12 mm) or larger hardware (not supplied).

To Weld Unit In Place:

Weld unit to truck or trailer only at the four mounting brackets.




Using Mounting Brackets



Tools Needed:
 9/16 in

install3 2008--01 803 274 / 200 864-A / 803 231

5-4. Grounding Generator To Truck Or Trailer Frame



⚠ Always ground generator frame to vehicle frame to prevent electric shock and static electricity hazards.

⚠ Also see AWS Safety & Health Fact Sheet No. 29, Grounding of Portable And Vehicle Mounted Welding Generators.

⚠ Bed liners, shipping skids, and some running gear insulate the welding generator from the vehicle frame. Always connect a ground wire from the generator equipment grounding terminal to bare metal on the vehicle frame as shown.

⚠ If unit does not have GFCI receptacles, use GFCI-protected extension cord.




- 1 Equipment Grounding Terminal (On Front Panel)
- 2 Grounding Cable (Not Supplied)
- 3 Metal Vehicle Frame

Connect cable from equipment ground terminal to metal vehicle frame. Use #8 AWG or larger insulated copper wire.

☞ Electrically bond generator frame to vehicle frame by metal-to-metal contact.

rot_grnd1 2010-04 - 800 652-D

5-5. Using Lifting Eye




- 1 Lifting Eye
- 2 Nut
- 3 Carriage Bolt

Raise lifting eye until it snaps in place. Lower lifting eye when not needed.



To lock the lifting eye in the upright position, insert a 3/8-16 x 1-1/2 in carriage bolt through slot in bracket and secure with nut (bolt and nut not supplied).

Tools Needed:



Lift1 2008-01 804 712

5-7. Activating The Dry Charge Battery (If Applicable)



⚠ Always wear a face shield, rubber gloves and protective clothing when working on a battery.

Remove battery from unit.

- 1 Vent Caps
- 2 Sulfuric Acid Electrolyte (1.265 Specific Gravity)
- 3 Well

Fill each cell with electrolyte to **bottom** of well (maximum).

⚠ Do not overfill battery cells.

Wait ten minutes and check electrolyte level. If necessary, add electrolyte to raise to proper level. Reinstall vent caps.

- 4 Battery Charger

⚠ Read and follow all instructions supplied with battery charger.

- 5 5 Amperes For 30 Minutes Charge Time
- 6 30 Amperes For 12 Minutes Charge Time

Charge battery. Disconnect charging cables and install battery.


☞ When electrolyte is low, add only distilled water to cells to maintain proper level.

Tools Needed:




drybatt1 2008-01 - S-0886

5-8. Connecting The Battery



Tools Needed:




⚠ Connect negative (-) battery cable last.

☞ Reinstall cover after connecting battery.

Conn_batt1 2008-02 802 168-E / Ref. 202 705 / 802 313 / S-0756-C

5-9. Engine Prestart Checks



☞ Engine stops when fuel level is low.

Full

804 169

☞ Check all engine fluids daily.

Engine must be cold and on a level surface. Automatic shutdown system stops engine if oil pressure is too low or engine temperature is too high.

☞ This unit has a low oil pressure shutdown switch. However, some conditions may cause engine damage before the engine shuts down. Check oil level often and do not use the oil pressure shutdown system to monitor oil level.

Follow run-in procedure in engine manual. If unburned fuel and oil collect in exhaust pipe during run-in, see Section 10.

Fuel

NOTICE – Do not use gasoline. Gasoline will damage engine.

The unit is shipped with enough fuel to prevent air from entering fuel system. Add fresh diesel fuel before starting (see engine maintenance label for fuel specifications). Leave filler neck empty to allow room for expansion.

☞ Engine stops when fuel level is low.

Oil

After fueling, check oil with unit on level surface. If oil is not up to full mark on dipstick, add oil (see maintenance label).






☞ To improve cold weather starting:

Keep battery in good condition. Store battery in warm area.

Use fuel formulated for cold weather (diesel fuel can gel in cold weather). Contact local fuel supplier for fuel information.

Use correct grade oil for cold weather (see Section 8-1).

5-10. Connecting To Weld Output Terminals



⚠ Stop engine.

⚠ Failure to properly connect weld cables may cause excessive heat and start a fire, or damage your machine.

📄 Do not place anything between weld cable terminal and copper bar. Make sure that the surfaces of the weld cable terminal and copper bar are clean.

- 1 Correct Weld Cable Connection
- 2 Incorrect Weld Cable Connection
- 3 Weld Output Terminal
- 4 Supplied Weld Output Terminal Nut
- 5 Weld Cable Terminal
- 6 Copper Bar

Remove supplied nut from weld output terminal. Slide weld cable terminal onto weld output terminal and secure with nut so that weld cable terminal is tight against copper bar.


- 7 Positive (+) Weld Output Terminal
- 8 Negative (-) Weld Output Terminal

Stick and TIG Welding

For Stick and TIG welding Direct Current Electrode Positive (DCEP), connect electrode holder cable to Positive (+) terminal on left and work cable to Negative (-) terminal on right.

For Direct Current Electrode Negative (DCEN), reverse cable connections.


Tools Needed:



Ref. 224 610-A / 804 168 / 803 778-B

5-11. Selecting Weld Cable Sizes*

NOTICE – The Total Cable Length in Weld Circuit (see table below) is the combined length of both weld cables. For example, if the power source is 100 ft (30 m) from the workpiece, the total cable length in the weld circuit is 200 ft (2 cables x 100 ft). Use the 200 ft (60 m) column to determine cable size.

|  <p>Weld Output Terminals</p> <p>⚠ Stop engine before connecting to weld output terminals.</p> <p>⚠ Do not use worn, damaged, undersized, or poorly spliced cables.</p> | Weld Cable Size** and Total Cable (Copper) Length in Weld Circuit Not Exceeding*** | | | | | | | | | | |
|---|--|---------------------|----------------------|----------------------|------------------|-------------------|-------------------|-------------------|--|--|--|
| | 100 ft (30 m) or Less | | 150 ft (45 m) | 200 ft (60 m) | 250 ft (70 m) | 300 ft (90 m) | 350 ft (105 m) | 400 ft (120 m) | | | |
| | Welding Amperes | 10 – 60% Duty Cycle | 60 – 100% Duty Cycle | 10 – 100% Duty Cycle | | | | | | | |
| 100 | 4 (20) | 4 (20) | 4 (20) | 3 (30) | 2 (35) | 1 (50) | 1/0 (60) | 1/0 (60) | | | |
| 150 | 3 (30) | 3 (30) | 2 (35) | 1 (50) | 1/0 (60) | 2/0 (70) | 3/0 (95) | 3/0 (95) | | | |
| 200 | 3 (30) | 2 (35) | 1 (50) | 1/0 (60) | 2/0 (70) | 3/0 (95) | 4/0 (120) | 4/0 (120) | | | |
| 250 | 2 (35) | 1 (50) | 1/0 (60) | 2/0 (70) | 3/0 (95) | 4/0 (120) | 2 ea. 2/0 (2x70) | 2 ea. 2/0 (2x70) | | | |
| 300 | 1 (50) | 1/0 (60) | 2/0 (70) | 3/0 (95) | 4/0 (120) | 2 ea. 2/0 (2x70) | 2 ea. 3/0 (2x95) | 2 ea. 3/0 (2x95) | | | |
| 350 | 1/0 (60) | 2/0 (70) | 3/0 (95) | 4/0 (120) | 2 ea. 2/0 (2x70) | 2 ea. 3/0 (2x95) | 2 ea. 3/0 (2x95) | 2 ea. 4/0 (2x120) | | | |
| 400 | 1/0 (60) | 2/0 (70) | 3/0 (95) | 4/0 (120) | 2 ea. 2/0 (2x70) | 2 ea. 3/0 (2x95) | 2 ea. 4/0 (2x120) | 2 ea. 4/0 (2x120) | | | |
| 500 | 2/0 (70) | 3/0 (95) | 4/0 (120) | 2 ea. 2/0 (2x70) | 2 ea. 3/0 (2x95) | 2 ea. 4/0 (2x120) | 3 ea. 3/0 (3x95) | 3 ea. 3/0 (3x95) | | | |


*Chart is a general guideline and may not suit all applications. If cables overheat, use next size larger cable.

**Weld cable size (AWG) is based on either a 4 volts or less drop or a current density of at least 300 circular mils per ampere.
() = mm² for metric use


***For distances longer than those shown in this guide, call a factory applications representative at 920-735-4505.

S-0007-F

5-12. Connecting To Remote Amperage Adjust Receptacle RC13




Notes



MATERIAL THICKNESS GAUGE

SECTION 6 – OPERATING WELDING GENERATOR


6-1. Front Panel Controls (See Section 6-2)



6-2. Description Of Front Panel Controls (See Section 6-1)


| <p>Engine Starting Controls</p> <p>1 Engine Control Switch</p> <p>Use switch to start and stop engine.</p> <p>To Start:</p> <p>NOTICE – Do not use ether. Using ether voids warranty.</p> <p> If engine does not start within 15 seconds, release switch and let engine come to a complete stop before attempting re-start.</p> <p>Turn Engine Control switch to Start. Release Engine Control switch when engine starts.</p> <p>To Stop: turn Engine Control switch to Off position.</p> <p>Engine Gauges And Meters</p> <p> To read gauges with engine off, turn Start/Preheat switch to Preheat position.</p> <p>2 Engine Fuel/Hour Gauge</p> <p>Use meter to monitor engine running time for scheduling maintenance.</p> <p>Use gauge to check fuel level. Engine stops if fuel level is low.</p> <p>To check fuel level when engine is not running place Engine Control switch in Preheat position then default back to neutral position.</p> <p>See Section 6-5 for complete fuel/hour gauge information.</p> <p>3 Engine Temperature Gauge</p> <p>Normal temperature is 180 - 203° F (82 - 95° C). Engine stops if temperature exceeds 220° F (104° C).</p> | <p>4 Engine Oil Pressure Gauge</p> <p>Normal pressure is 30 – 60 psi (207 – 414 kPa). Engine stops if pressure is below 10 psi (69 kPa).</p> <p>Weld Controls</p> <p> Max OCV Control Circuit: This unit has a max OCV control circuit that resets Amperage Adjust control R1 to maximum when the arc breaks. When an arc is struck, weld output control returns to the R1 front panel or combination front panel/remote control setting. The Amperage Adjust control adjusts amperage only when welding and does not adjust open-circuit voltage.</p> <p><i>The max OCV circuit is disabled when the Stick/TIG Selection switch is in Scratch Start TIG position (see item 7).</i></p> <p>5 Ampere Range Switch</p> <p>NOTICE – Do not switch under load.</p> <p>Use switch to select weld amperage range. For most welding applications, use lowest amperage range possible to help prevent arc outages.</p> <p>6 Amperage Adjust Control</p> <p>Control adjusts amperage within range selected by Ampere Range switch. Weld output would be about 168 A DC with controls set as shown (50% of 110 to 225 A).</p> <p> The numbers around the control are for reference only and do not represent an actual percentage value.</p> | | | | | | | | | <p>7 Stick/TIG Selection Switch</p> <p>Use switch to disable the max OCV circuit and the arc drive (dig) circuit for scratch start TIG welding (see max OCV note under Weld Controls).</p> <p>When switch is in the Stick position, the max OCV circuit resets Amperage Adjust Control R1 to maximum when the arc breaks.</p> <p>Also in the Stick position, the arc drive (dig) circuit provides additional amperage during low voltage (short arc length conditions) to prevent “sticking” electrodes.</p> <p>When switch is in Scratch Start TIG position, the max OCV and arc drive (dig) circuits are disabled and OCV changes when the control is adjusted.</p> <p>8 Amperage Adjust Switch And Remote Amperage Adjust Receptacle</p> <p>Connect optional remote control to RC13 (See Section 5-12). Use switch to select front panel or remote amperage control. For remote control, place switch in Remote position and connect remote control to Remote Amperage Adjust receptacle RC13 (see Sections 5-12 and 6-3).</p> <p>Weld Meters</p> <p>9 AC/DC Voltmeter</p> <p>Voltmeter displays voltage at the weld output terminals, but not necessarily the welding arc due to resistance of cable and connections.</p> <p>10 AC/DC Ammeter</p> <p>Ammeter displays amperage output of the unit.</p> |
|---|---|--|--|--|--|--|--|--|--|---|

6-3. Remote Amperage Control (Optional)



Example: Combination Remote Amperage Control (Stick)

In Example:
Range = 110 to 225 A DC
Percentage Of Range = 50%
Max = About 168 A DC (50% of 110 to 225)



6-4. Weld Control/Arc Condition Information Label













☞ Set weld controls as shown to achieve softer or stiffer arc conditions for different applications.

SOFTER ARC
A softer arc condition can be achieved by selecting the **lowest usable range** for the electrode with a **higher fine amperage** setting preferably above 50%. This improves 6010 for uphill pipe welding by reducing Arc outages/Popouts and reduces spatter with 7018.

STIFFER ARC
A stiffer arc condition can be achieved by selecting the **highest usable range** for the electrode with a **lower fine amperage** setting preferably below 50%. This improves 6010 for downhill stick welding and 7018 for out of position welding by increasing dig.


212 944-B

6-5. Fuel/Hour Gauge Descriptions

| FUEL/HOUR GAUGE DESCRIPTIONS | |
|---|---|
|  | <p>ENGINE HOURS: Gauge will display engine hours while engine is running. To display engine hours while the engine is off, place Engine Control switch in position "1" then default back to position "2".</p>  |
|  | <p>OIL CHANGE INTERVAL: Gauge will display hours remaining before oil change is due with Engine Control switch held in position "1" (with engine off).</p>  |
|  | <p>OIL CHANGE DUE: Gauge will display blinking wrench when oil change is due (0 to -99 hours).</p> <p>To Reset: Toggle Engine Control switch between position "1" and "2" three times within 5 seconds (engine off).</p>  |
|  | <p>LOW FUEL PREWARNING: Fault indicator flashes when fuel level reaches 2 bars. Flashing rate increases as fuel level drops.</p> <p>LOW FUEL: Fuel level low when fuel icon and last bar in fuel gauge blink.</p> <p>To Reset: Refuel.</p> |
|  | <p>NO FUEL: Engine shuts down before fuel runs out. Display shows "noFuel", and fuel icon and fault indicator flash.</p> <p>To Reset: Refuel.</p> |
|  | <p>LOW OIL PRESSURE: Engine shuts down when oil pressure is low. Display shows "LO OIL", fault indicator flashes and wrench is displayed.</p> <p>To Reset: Push Down on Engine Shutdown switch.</p>  |
|  | <p>HIGH COOLANT TEMP: Engine shuts down when coolant temperature is high. Display shows "HI H2O" and fault indicator flashes.</p> <p>To Reset: Push Down on Engine Shutdown switch.</p>  |
| <p>Note: Switch positions are numbered to illustrate that there are three switch positions. Actual graphics on front panel will vary. 237 278-B</p> | |

SECTION 7 – OPERATING AUXILIARY EQUIPMENT

7-1. 120 Volt And 240 Volt Receptacles



- 1 120 V 20 A AC GFCI Receptacle GFCI1
- 2 240 V 16 A AC Receptacle RC1

Receptacles supply 60 Hz single-phase power at weld/power speed.

If a ground fault is detected, GFCI Reset button pops out and receptacle does not work. Check for faulty tools plugged in receptacle. Press button to reset GFCI1.

☞ *At least once a month, run engine at weld/power speed and press test button to verify GFCI is working properly.*

- 3 Supplementary Protector CB1
- 4 Supplementary Protector CB2

CB1 protects RC1 and the generator winding from overload. If CB1 opens, RC1 and GFCI1 do not work. Place switch in On position to reset

CB2 protects GFCI1 from overload. If CB2 opens, GFCI1 does not work. Press button to reset.

☞ *If a supplementary protector continues to open, contact Factory Authorized Service Agent.*

☞ *Generator power is not affected by weld output.*

Maximum output is 2.4 kVA/kW from GFCI1 and 4 kVA/kW from RC1. Maximum output from all receptacles is 4 kVA/kW.





EXAMPLE: If 13 A is drawn from RC1, only 7 A is available at GFCI1:
 $(240\text{ V} \times 13\text{ A}) + (120\text{ V} \times 7\text{ A}) = 4.0\text{ kVA/kW}$

8-2. Routine Maintenance

| | | | | | | | |
|--|--|--|--|--|--|------------------------|---|
| | | | | | | | |
| | | | | | | Recycle engine fluids. | Stop engine before maintaining. See Engine Manual and Maintenance Label for important start-up, service, and storage information. Service engine more often if used in severe conditions. |

| | ✓ = Check ◇ = Change ● = Clean * To be done by Factory Authorized Service Agent | | | | ☆ = Replace | Reference |
|-----------------------------|---|---|---------------------------|------------------------|-------------|---------------------------------|
| Every 8 Hours | ✓ Fuel/Water Separator | ✓ Fuel Level | ✓ Oil Level | ● Oil, Fuel Spills | | Section 5-9, 8-7 |
| Every 100 Hours | ● Battery Terminals | ✓ Air Cleaner Hoses | ● Air Cleaner Element | ● Weld Terminals | | Section 8-3 |
| Every 250 Hours | ☆ Unreadable Labels | 1/2 in. (13 mm) ✓ Fan Belt Tension | ● Cooling System | ✓ ● Spark Arrestor | | Engine Manual, Section 8-4 |
| Every 500 Hours | ✓ ☆ Weld Cables | | | | | |
| Every 1000 Hours | <p>NOTICE – Change engine oil and filter after initial 50 to 75 hours of use.</p> ◇ Oil ◇ Oil Filter | ◇ Fuel Filter | | | | Section 8-5, 8-7, Engine Manual |
| | ✓ ● Slip Rings* ✓ ☆ Brushes* | ● Inside Unit | ✓ Valve Clearance* | ● Drain Sludge | | |
| Every 3000 Hours | ● Injectors* | | | | | |
| Every 6000 Hours or 5 Years | ✓ ☆ Engine Timing Belt | | | | | |

8-3. Servicing Air Cleaner



⚠ Stop engine.

NOTICE – Do not run engine without air cleaner or with dirty element. Engine damage caused by using a damaged element is not covered by the warranty.

☞ The air cleaner primary element can be cleaned but the dirt holding capacity of the filter is reduced with each cleaning. The chance of dirt reaching the clean side of the filter while cleaning and the possibility of filter damage makes cleaning a risk. Consider the risk of unwarrantable equipment damage when determining whether to clean or replace the primary element.

If you decide to clean the primary element, we strongly recommend installing an optional safety element to provide additional engine protection. **Never clean a safety element.** Replace the safety element after servicing the primary element three times.

- 1 Intake Manifold
- 2 Service Indicator (Optional)
- 3 Window
- 4 Reset Button

Service air cleaner element if red band appears in window. A green band means air cleaner is okay. Press button to reset indicator.

Clean or replace primary element if dirty (see note above before cleaning). **Replace** primary element if damaged. Replace primary element yearly or after six cleanings.

- 5 Housing
- 6 Safety Element (Optional)
- 7 Primary Element
- 8 Cover
- 9 Dust Ejector

To clean air filter:

Wipe off cover and housing. Remove cover and dump out dust. Remove element(s). Wipe dust from inside cover and housing with damp cloth. Reinstall safety element (if present). Reinstall cover.





NOTICE – Do not clean housing with air hose.

Clean primary element with compressed air only.

Air pressure must not exceed 100 psi (690 kPa). Use 1/8 in (3 mm) nozzle and keep nozzle at least 2 in (51 mm) from inside of element. Replace primary element if it has holes or damaged gaskets.

Reinstall primary element and cover (dust ejector down).

8-4. Inspecting And Cleaning Optional Spark Arrestor Muffler

⚠ Stop engine and let cool.

- Spark Arrestor Muffler
- Cleanout Plug


Remove plug and remove any dirt covering cleanout hole.

Start engine and run at idle speed to blow out cleanout hole. If nothing blows out of hole, briefly cover end of exhaust pipe with fireproof material.

⚠ Stop engine and let cool.




Reinstall cleanout plug.

Tools Needed:

 3/8 in

Ref. 803 656 / Ref. 224 610

8-5. Checking Generator Brushes

⚠ Stop engine and let cool.

- Generator Brush

Mark and disconnect leads at brush holder cap. Remove brushes.

Replace brushes if damaged or if brush material is at or near minimum length.

Minimum Length: 5/8 in (16 mm)


New Length: 1-1/4 in (32 mm)

Replace Damaged Brushes



1

Ref 215 158

8-6. Adjusting Engine Speed



| | |
|--|----------------------------|
| | |
| | 1850 rpm Max. (61.6 Hz) |



Stop engine and let cool.

Engine speed is factory set and should not require adjustment. After tuning engine, check engine no load speed with a tachometer or frequency meter (see table for no load speeds). If necessary, adjust speed as follows:

Start engine and run until warm.

Place Stick/TIG switch in Stick position.

Standard Models:

- 1 Engine Speed Adjustment Screw
- 2 Locking Nut


Loosen nut. Turn screw until engine runs at weld/power speed. Tighten nut.

Do not set engine speed higher than specified.


Stop engine.

Close door.

Tools Needed:



8-7. Servicing Fuel And Lubrication Systems



⚠ Stop engine and let cool.

⚠ After servicing, start engine and check for fuel leaks. Stop engine, tighten connections as necessary, and wipe up spilled fuel.

- 1 Oil Filter
- 2 Oil Drain Valve And Hose
- 3 Oil Fill Cap
- 4 Primary Fuel Filter (Fuel/Water Separator)
- 5 Petcock
- 6 Secondary Fuel Filter
- 7 Fuel Tank Sludge Drain Valve

To change oil and filter:

Route oil drain hose and valve through hole

in base. See engine manual and engine maintenance label for oil/filter change information.

To drain water from fuel system:

Open primary fuel filter petcock and drain water into metal container. Close petcock when water-free fuel flows.

To replace primary fuel filter:

Turn filter counterclockwise. Remove filter.

Apply thin coat of fuel to gasket on new filter. Fill filter with fuel. Install filter and turn clockwise. Bleed air from fuel system according to engine manual.

Inspect fuel line, and replace if cracked or worn.

To replace secondary fuel filter:

See engine manual.

Close doors.

To drain sludge from fuel tank:




⚠ Beware of fire. Do not smoke and keep sparks and flames away from drained fuel. Dispose of drained fuel in an environmentally-safe manner. Do not leave unit unattended while draining fuel tank.

⚠ Properly lift unit and secure in a level position. Use adequate blocks or stands to support unit while draining fuel tank.


Attach 1/2 ID hose to drain valve. Put metal container under drain, and use screwdriver to open sludge drain valve. Close valve when sludge has drained. Remove hose.

804 169 / Ref. 800 159

8-8. Overload Protection



Stop engine.

 When a circuit breaker, supplementary protector, or fuse opens, it usually indicates a more serious problem exists. Contact Factory Authorized Service Agent.

- 1 Fuse F1
- 2 Fuse F2

F1 and F2 protect the stator exciter winding from overload. If F1 opens, weld and generator power is low or stops entirely. If F2 opens, weld output is low or stops entirely. 4 kVA/kW generator power is still available.

- 3 Circuit Breaker CB4 (Not Shown)
- 4 Circuit Breaker CB10 (Not Shown)
- 5 Supplementary Protector CB11
- 6 Supplementary Protector CB12
- 7 Supplementary Protector CB13
- 8 Circuit Breaker CB14 (Not Shown)

CB4 protects the welding arc drive (dig) circuit. If CB4 opens, electrode may stick to the workpiece more frequently during low voltage (short arc length) conditions. CB4 automatically resets when the fault is corrected.

CB10 protects the engine battery circuit. If CB10 opens, the engine will not crank. CB10 automatically resets when the fault is corrected.

CB11 protects the engine weld control circuit. If CB11 opens the max OCV circuit does not work and open circuit voltage is variable at all times (see max OCV note under Weld Controls in Section 6-2).


CB12 protects the field flashing circuit. If CB12 opens, the generator may not excite at start-up and weld and generator power output may not be available.

CB13 protects the engine control circuit. If CB13 opens, the engine does not crank.

CB14 protects throttle solenoid TS1 on units with auto idle option. If CB14 opens, the engine does not run at idle speed. CB14 automatically resets when the fault is corrected.

Press button to reset supplementary protector.

8-9. Troubleshooting



A. Welding – CC Models

| Trouble | Remedy |
|---|--|
| No weld output; generator power output okay at ac receptacles. | Check position of Ampere Range switch. |
| | Place Amperage Adjust switch in Panel position, or place switch in Remote position and connect remote control to Remote Amperage Adjust receptacle RC13 (see Sections 5-12 and 6-1). |
| | Check and secure connections to Remote Amperage Adjust receptacle RC13 (see Section 5-12). |
| | Check fuse F2, and replace if open (see Section 8-8). Have Factory Authorized Service Agent check integrated rectifier SR2 and the rotor. |
| Have Factory Authorized Service Agent check brushes and slip rings, and weld excitation circuit. | |
| No weld output or generator power output at ac receptacles. | Disconnect equipment from generator power receptacles during start-up. |
| | Check fuses F1 and F2, and replace if open (see Section 8-8). Have Factory Authorized Service Agent check integrated rectifier SR1, capacitor C9, integrated rectifier SR2, and the rotor. |
| | Reset supplementary protector CB12. Have Factory Authorized Service Agent check diode D1 (see Section 8-8). |
| | Have Factory Authorized Service Agent check brushes and slip rings, and field excitation circuit. |
| Erratic weld output. | Check and tighten connections inside and outside unit. |
| | Be sure connection to work piece is clean and tight. |
| | Use dry, properly stored electrodes. |
| | Remove excessive coils from weld cables. |
| | Have Factory Authorized Service Agent check brushes and slip rings. |
| High weld output. | Check engine speed, and adjust if necessary. |
| | Have Factory Authorized Service Agent check OCV control circuit. |
| Low weld output. | Check engine speed, and adjust if necessary. |
| | Check fuses F1 and F2, and replace if open (see Section 8-8). Have Factory Authorized Service Agent check integrated rectifier SR1, capacitor C9, integrated rectifier SR2, and the rotor. |
| Electrode sticks to the workpiece more frequently during low voltage (short arc length) conditions. | Circuit breaker CB4 may be open. CB4 automatically resets when the fault is corrected (see Section 8-8). Have Factory Authorized Service Agent check transformer T1 and integrated rectifiers SR4 and SR5. |
| Low open-circuit voltage. | Check engine speed, and adjust if necessary. |
| Maximum weld output only in each ampere range (with Stick/TIG Selection switch in Stick position). | Have Factory Authorized Service Agent check control relay CR7. |
| No remote fine amperage control. | Place Amperage Adjust switch in Remote position. |
| | Check and secure connections to Remote Amperage Adjust receptacle RC13 (see Section 5-12). |
| | Reset supplementary protector CB11 (see Section 8-8). Have Factory Authorized Service Agent check control relay CR7. |
| | Repair or replace remote control device. |

B. Standard Generator Power

| Trouble | Remedy |
|--|--|
| No generator power output at ac receptacles; weld output okay. | Reset receptacle supplementary protectors. |
| | Reset GFCI receptacle. |
| No generator power or weld output. | Disconnect equipment from generator power receptacles during start-up. |
| | Check fuses F1 and F2, and replace if open (see Section 8-8). Have Factory Authorized Service Agent check integrated rectifier SR1, capacitor C9, and the rotor. |
| | Reset supplementary protector. Have Factory Authorized Service Agent check diode D1 . |
| | Have Factory Authorized Service Agent check brushes and slip rings, and field excitation circuit. |
| High output at generator power ac receptacles. | Check engine speed, and adjust if necessary. |
| | Have Factory Authorized Service Agent adjust generator power field current resistor R3. |
| Low output at generator power ac receptacles. | Check engine speed, and adjust if necessary. |
| | Check fuse F1, and replace if open (see Section 8-8). Have Factory Authorized Service Agent check integrated rectifier SR1, resistor R3, and capacitor C9. |

C. Engine

| Trouble | Remedy |
|--|---|
| Engine will not crank. | Check battery, and replace if necessary. |
| | Check battery connections and tighten if necessary. |
| | Circuit breaker CB10 may be open. CB10 automatically resets when fault is corrected (see Section 8-8). Have Factory Authorized Service Agent check engine wiring harness and components. |
| | Check engine wiring harness plug connections. |
| | Have Factory Authorized Service Agent check control relay CR1 and Engine Control switch S1. |
| Engine cranks but does not start. | Check fuel level. |
| | Check battery and replace if necessary. Check engine charging system according to engine manual. |
| | Have Factory Authorized Service Agent check fuel/hourmeter gauge, control relay CR5, fuel pump, and fuel solenoid FS1. |
| | Air in fuel system. See engine manual. |
| Engine starts, but stops when Engine Control switch is released. | Check oil level. Automatic shutdown system stops engine if oil pressure is too low or engine temperature is too high (see Section 5-9). Automatic shutdown system is inhibited for 30 seconds after start-up. |
| | Have Factory Authorized Service Agent check fuel/hourmeter gauge, and control relay CR5. |
| Engine hard to start in cold weather. | Keep battery in good condition. Store battery in warm area off cold surface. |
| | Use fuel formulated for cold weather (diesel fuel can gel in cold weather). Contact local fuel supplier for fuel information. |
| | Use correct grade oil for cold weather (see Section 8-1). |
| Engine suddenly stops. | Check oil level. Automatic shutdown system stops engine if oil pressure is too low or engine temperature is too high (see Section 5-9). Automatic shutdown system is inhibited for 30 seconds after start-up. |
| | See engine manual. |
| Engine slowly stopped and cannot be restarted. | Check fuel level. |
| | Check engine air and fuel filters (see Section 8-7). |
| | See engine manual. |
| Battery discharges between uses. | Turn Engine Control switch off when unit is not running. |
| | Clean top of battery with baking soda and water solution; rinse with clear water. |

| Trouble | Remedy |
|--|--|
| | Recharge or replace battery if necessary. |
| | Periodically recharge battery (approximately every 3 months). |
| Engine idles, but does not come up to weld speed (models with idle option only). | Have Factory Authorized Service Agent check idle module PC7 and current transformer CT1. |
| | Check for obstructed throttle solenoid. |
| Engine does not run at idle speed (models with idle option only). | Place Stick/TIG Selection switch in Stick position. |
| | Check for obstructed throttle solenoid. |
| | Have Factory Authorized Service Agent check idle module PC7, and control relays CR3 and CR6. |
| Engine uses oil during run-in period; wetstacking occurs. | Dry engine according to run-in procedure (see Section 10). |

SECTION 9 - ELECTRICAL DIAGRAMS

⚠ WARNING

- Do not touch live electrical parts.
- Disconnect input power or stop engine before servicing.
- Do not operate with covers removed.
- Have only qualified persons install, use, or service this unit.

ELECTRIC SHOCK HAZARD





Figure 9-1. Circuit Diagram For CC Welding Generator




| S1 | OFF | RUN | RUN/IDLE | START |
|----|-----|-----|----------|-------|
| A | | X | X | |
| B | | X | | |
| C | | | | X |
| D | | | X | |

X = CLOSED TO "A" TERMINAL

SECTION 10 – RUN-IN PROCEDURE

run_in1 2007-04

10-1. Wetstacking



NOTICE – Do not perform run-in procedure at less than 20 volts weld output and do not exceed duty cycle or equipment damage may occur.

1 Welding Generator

Run diesel engines near rated voltage and current during run-in period to properly seat piston rings and prevent wetstacking. See nameplate, rating label, or specifications section in this manual to find rated voltage and current.

NOTICE – Do not idle engine longer than necessary. Piston rings seat faster if engine runs at weld/power rpm, and the welding generator is kept loaded during run-in.


2 Engine Exhaust Pipe

Wetstacking is unburned fuel and oil in the exhaust pipe and occurs during run-in if the engine is run too long at light load or idle rpm.

If exhaust pipe is coated with a wet, black, tar-like substance, dry the engine using one of the following run-in procedures.

See the engine manual for additional engine run-in information.

10-2. Run-In Procedure Using Load Bank



- Stop engine.**
- Do not touch hot exhaust pipe, engine parts, or load bank/grid.**
- Keep exhaust and pipe away from flammables.**

NOTICE – Do not perform run-in procedure at less than 20 volts weld output and do not exceed duty cycle or equipment damage may occur.

1 Load Bank

Turn all load bank switches Off. If needed, connect load bank to 115 volts ac wall receptacle or generator auxiliary power receptacle.

2 Welding Generator

Place A/V range switch in maximum position, A/V control in minimum position, and Output Selector switch (if present) in either DC position.

3 Weld Cables

Connect load bank to generator weld output terminals using proper size weld cables with correct connectors. Observe correct polarity.

Start engine and run for several minutes.

Set load bank switches and then adjust generator A/V control so load equals rated voltage and current of generator (see nameplate, rating label, or the specifications section in this manual).

Check generator and load bank meters after first five minutes then every fifteen minutes to be sure generator is loaded properly.

NOTICE – Check oil level frequently during run-in; add oil if needed.


It is recommended to run the welding generator for two hours minimum and up to four hours under load. Place A/V control in minimum position, then turn off load bank to remove load. Run engine several minutes at no load.

- Stop engine and let cool.**

4 Engine Exhaust Pipe

Repeat procedure if wetstacking is present.

10-3. Run-In Procedure Using Resistance Grid



- Stop engine.**
- Do not touch hot exhaust pipe, engine parts, or load bank/grid.**
- Keep exhaust and pipe away from flammables.**

NOTICE – Do not perform run-in procedure at less than 20 volts weld output and do not exceed duty cycle or equipment damage may occur.

1 Resistance Grid

Use grid sized for generator rated output.

Turn Off grid.

2 Welding Generator

Place A/V range switch in maximum position, A/V control in minimum position, and Output Selector switch (if present) in either DC position.

3 Weld Cables

Connect grid to generator weld output terminals using proper size weld cables with correct connectors (polarity is not important).

4 Voltmeter

5 Clamp-On Ammeter

Connect voltmeter and ammeter as shown, if not provided on generator.

Start engine and run for several minutes.

Set grid switches and then adjust generator A/V control so load equals rated voltage and current of the generator (see nameplate, rating label, or the specifications section in this manual).

Check generator and meters after first five minutes then every fifteen minutes to be sure generator is loaded properly.

NOTICE – Check oil level frequently during run-in; add oil if needed.


It is recommended to run the welding generator for two hours minimum and up to four hours under load. Place A/V control in minimum position, then shut down grid to remove load. Run engine several minutes at no load.

- Stop engine and let cool.**



6 Engine Exhaust Pipe


Repeat procedure if wetstacking is present.

SECTION 11 – GENERATOR POWER GUIDELINES


 The views in this section are intended to be representative of all engine-driven welding generators. Your unit may differ from those shown.


11-1. Selecting Equipment





- 1 Generator Power Receptacles – Neutral Bonded To Frame
- 2 3-Prong Plug From Case Grounded Equipment
- 3 2-Prong Plug From Double Insulated Equipment


 Be sure equipment has double insulated symbol and/or wording on it.


 **Do not use 2-prong plug unless equipment is double insulated.**


gen_pwr 2010-04 – ST-800 577

11-2. Grounding Generator To Truck Or Trailer Frame





 **Always ground generator frame to vehicle frame to prevent electric shock and static electricity hazards.**


 **Also see AWS Safety & Health Fact Sheet No. 29, Grounding of Portable And Vehicle Mounted Welding Generators.**

- 1 Equipment Grounding Terminal (On Front Panel)
- 2 Grounding Cable (Not Supplied)
- 3 Metal Vehicle Frame

Connect cable from equipment ground terminal to metal vehicle frame. Use #8 AWG or larger insulated copper wire.


 Electrically bond generator frame to vehicle frame by metal-to-metal contact.

 **Bed liners, shipping skids, and some running gear insulate the welding generator from the vehicle frame. Always connect a ground wire from the generator equipment grounding terminal to bare metal on the vehicle frame as shown.**

 **If unit does not have GFCI receptacles, use GFCI-protected extension cord.**

800 652-D

11-3. Grounding When Supplying Building Systems



1 Equipment Grounding Terminal

2 Grounding Cable

Use #8 AWG or larger insulated copper wire.

3 Ground Device


Use ground device as stated in electrical codes.

Ground generator to system earth ground if supplying power to a premises (home, shop, farm) wiring system.

Also see AWS Safety & Health Fact Sheet No. 29, Grounding of Portable And Vehicle Mounted Welding Generators.

ST-800 576-B

11-4. How Much Power Does Equipment Require?



1 Resistive Load

A light bulb is a resistive load and requires a constant amount of power.

2 Non-Resistive Load

Equipment with a motor is a non-resistive load and requires approximately six times more power while starting the motor than when running (see Section 11-8).

3 Rating Data

Rating shows volts and amperes, or watts required to run equipment.

Amperes x Volts = Watts

Example 1: If a drill uses 4.5 amperes at 115 volts, calculate its running power requirement in watts.

$$4.5 \text{ A} \times 115 \text{ V} = 520 \text{ W}$$

The load applied by the drill is 520 watts.

Example 2: If three 200 watt flood lamps are used with the drill from Example 1, add the individual loads to calculate total load.

$$(3 \times 200\text{W}) + 520 \text{ W} = 1120 \text{ W}$$

The total load applied by the three flood lamps and drill is 1120 watts.

S-0623

11-5. Approximate Power Requirements For Industrial Motors

| Industrial Motors | Rating | Starting Watts | Running Watts |
|-------------------------------|----------|----------------|---------------|
| Split Phase | 1/8 HP | 800 | 300 |
| | 1/6 HP | 1225 | 500 |
| | 1/4 HP | 1600 | 600 |
| | 1/3 HP | 2100 | 700 |
| | 1/2 HP | 3175 | 875 |
| Capacitor Start-Induction Run | 1/3 HP | 2020 | 720 |
| | 1/2 HP | 3075 | 975 |
| | 3/4 HP | 4500 | 1400 |
| | 1 HP | 6100 | 1600 |
| | 1-1/2 HP | 8200 | 2200 |
| | 2 HP | 10550 | 2850 |
| | 3 HP | 15900 | 3900 |
| Capacitor Start-Capacitor Run | 5 HP | 23300 | 6800 |
| | 1-1/2 HP | 8100 | 2000 |
| | 5 HP | 23300 | 6000 |
| | 7-1/2 HP | 35000 | 8000 |
| | 10 HP | 46700 | 10700 |
| Fan Duty | 1/8 HP | 1000 | 400 |
| | 1/6 HP | 1400 | 550 |
| | 1/4 HP | 1850 | 650 |
| | 1/3 HP | 2400 | 800 |
| | 1/2 HP | 3500 | 1100 |

11-6. Approximate Power Requirements For Farm/Home Equipment


| Farm/Home Equipment | Rating | Starting Watts | Running Watts |
|----------------------------|----------|----------------|---------------|
| Stock Tank De-Icer | | 1000 | 1000 |
| Grain Cleaner | 1/4 HP | 1650 | 650 |
| Portable Conveyor | 1/2 HP | 3400 | 1000 |
| Grain Elevator | 3/4 HP | 4400 | 1400 |
| Milk Cooler | | 2900 | 1100 |
| Milker (Vacuum Pump) | 2 HP | 10500 | 2800 |
| FARM DUTY MOTORS | 1/3 HP | 1720 | 720 |
| Std. (e.g. Conveyors, | 1/2 HP | 2575 | 975 |
| Feed Augers, Air | 3/4 HP | 4500 | 1400 |
| Compressors) | 1 HP | 6100 | 1600 |
| | 1-1/2 HP | 8200 | 2200 |
| | 2 HP | 10550 | 2850 |
| | 3 HP | 15900 | 3900 |
| | 5 HP | 23300 | 6800 |
| High Torque (e.g. Barn | 1-1/2 HP | 8100 | 2000 |
| Cleaners, Silo Unloaders, | 5 HP | 23300 | 6000 |
| Silo Hoists, Bunk Feeders) | 7-1/2 HP | 35000 | 8000 |
| | 10 HP | 46700 | 10700 |
| 3-1/2 cu. ft. Mixer | 1/2 HP | 3300 | 1000 |
| High Pressure 1.8 Gal/Min | 500 PSI | 3150 | 950 |
| Washer 2 gal/min | 550 PSI | 4500 | 1400 |
| 2 gal/min | 700 PSI | 6100 | 1600 |
| Refrigerator or Freezer | | 3100 | 800 |
| Shallow Well Pump | 1/3 HP | 2150 | 750 |
| | 1/2 HP | 3100 | 1000 |
| Sump Pump | 1/3 HP | 2100 | 800 |
| | 1/2 HP | 3200 | 1050 |

11-7. Approximate Power Requirements For Contractor Equipment

| Contractor | Rating | Starting Watts | Running Watts |
|----------------------|------------------|----------------|---------------|
| Hand Drill | 1/4 in | 350 | 350 |
| | 3/8 in | 400 | 400 |
| | 1/2 in | 600 | 600 |
| Circular Saw | 6-1/2 in | 500 | 500 |
| | 7-1/4 in | 900 | 900 |
| | 8-1/4 in | 1400 | 1400 |
| Table Saw | 9 in | 4500 | 1500 |
| | 10 in | 6300 | 1800 |
| Band Saw | 14 in | 2500 | 1100 |
| Bench Grinder | 6 in | 1720 | 720 |
| | 8 in | 3900 | 1400 |
| | 10 in | 5200 | 1600 |
| Air Compressor | 1/2 HP | 3000 | 1000 |
| | 1 HP | 6000 | 1500 |
| | 1-1/2 HP | 8200 | 2200 |
| | 2 HP | 10500 | 2800 |
| Electric Chain Saw | 1-1/2 HP, 12 in | 1100 | 1100 |
| | 2 HP, 14 in | 1100 | 1100 |
| Electric Trimmer | Standard 9 in | 350 | 350 |
| | Heavy Duty 12 in | 500 | 500 |
| Electric Cultivator | 1/3 HP | 2100 | 700 |
| Elec. Hedge Trimmer | 18 in | 400 | 400 |
| Flood Lights | HID | 125 | 100 |
| | Metal Halide | 313 | 250 |
| | Mercury | 1000 | |
| | Sodium | 1400 | |
| Submersible Pump | Vapor | 1250 | 1000 |
| | 400 gph | 600 | 200 |
| Centrifugal Pump | 900 gph | 900 | 500 |
| Floor Polisher | 3/4 HP, 16 in | 4500 | 1400 |
| | 1 HP, 20 in | 6100 | 1600 |
| High Pressure Washer | 1/2 HP | 3150 | 950 |
| | 3/4 HP | 4500 | 1400 |
| | 1 HP | 6100 | 1600 |
| 55 gal Drum Mixer | 1/4 HP | 1900 | 700 |
| Wet & Dry Vac | 1.7 HP | 900 | 900 |
| | 2-1/2 HP | 1300 | 1300 |

11-8. Power Required To Start Motor

| Single-Phase Induction Motor Starting Requirements | | | | | | | | |
|--|-----|-----|-----|-----|------|------|------|------|
| Motor Start Code | G | H | J | K | L | M | N | P |
| KVA/HP | 6.3 | 7.1 | 8.0 | 9.0 | 10.0 | 11.2 | 12.5 | 14.0 |



- 1 Motor Start Code
- 2 Running Amperage
- 3 Motor HP
- 4 Motor Voltage

To find starting amperage:

Step 1: Find code and use table to find kVA/HP. If code is not listed, multiply running amperage by six to find starting amperage.

Step 2: Find Motor HP and Volts.

Step 3: Determine starting amperage (see example).

Welding generator amperage output must be at least twice the motor's running amperage.

$$\frac{(kVA/HP \times HP \times 1000)}{\text{Volts}} = \text{Starting Amperage}$$

Example: Calculate starting amperage required for a 230 V, 1/4 HP motor with a motor start code of M.


$$\text{Volts} = 230, \text{HP} = 1/4, \text{kVA/HP} = 11.2$$

$$(11.2 \times 1/4 \times 1000) / 230 = 12.2A$$

Starting the motor requires 12.2 amperes.

S-0624

11-9. How Much Power Can Generator Supply?



- 1 Limit Load To 90% Of Generator Output


Always start non-resistive (motor) loads in order from largest to smallest, and add resistive loads last.

- 2 5 Second Rule

If motor does not start within 5 seconds, turn off power to prevent motor damage. Motor requires more power than generator can supply.

Ref. ST-800 396-A / S-0625

11-10. Typical Connections To Supply Standby Power



⚠ Have only qualified persons perform these connections according to all applicable codes and safety practices.

⚠ Properly install and ground this equipment according to its Owner's Manual and national, state, and local codes.

📖 *Customer-supplied equipment is required if generator will supply standby power during emergencies or power outages.*

1 Utility Electrical Service

2 Transfer Switch (Double-Throw)

Switch transfers the electrical load from electric utility service to the generator. Transfer load back to electric utility when service is restored.

Install correct switch (customer-supplied). Switch rating must be same as or greater than the branch overcurrent protection.

3 Fused Disconnect Switch

Install correct switch (customer-supplied) if required by electrical code.

4 Welding Generator Output

Generator output voltage and wiring must be consistent with regular (utility) system voltage and wiring.


Connect generator with temporary or permanent wiring suitable for the installation.

Turn off or unplug all equipment connected to generator before starting or stopping engine. When starting or stopping, the engine has low speed which causes low voltage and frequency.


5 Essential Loads

Generator output may not meet the electrical requirements of the premises. If generator does not produce enough output to meet all requirements, connect only essential loads (pumps, freezers, heaters, etc. – See Section 11-4).

11-11. Selecting Extension Cord (Use Shortest Cord Possible)

| Cord Lengths for 120 Volt Loads | | | | | | | |
|---|--------------|---|-----------|-----------|----------|----------|----------|
|  | | | | | | | |
| ⚠ If unit does not have GFCI receptacles, use GFCI-protected extension cord. | | | | | | | |
| Current (Amperes) | Load (Watts) | Maximum Allowable Cord Length in ft (m) for Conductor Size (AWG)* | | | | | |
| | | 4 | 6 | 8 | 10 | 12 | 14 |
| 5 | 600 | | | 350 (106) | 225 (68) | 137 (42) | 100 (30) |
| 7 | 840 | | 400 (122) | 250 (76) | 150 (46) | 100 (30) | 62 (19) |
| 10 | 1200 | 400 (122) | 275 (84) | 175 (53) | 112 (34) | 62 (19) | 50 (15) |
| 15 | 1800 | 300 (91) | 175 (53) | 112 (34) | 75 (23) | 37 (11) | 30 (9) |
| 20 | 2400 | 225 (68) | 137 (42) | 87 (26) | 50 (15) | 30 (9) | |
| 25 | 3000 | 175 (53) | 112 (34) | 62 (19) | 37 (11) | | |
| 30 | 3600 | 150 (46) | 87 (26) | 50 (15) | 37 (11) | | |
| 35 | 4200 | 125 (38) | 75 (23) | 50 (15) | | | |
| 40 | 4800 | 112 (34) | 62 (19) | 37 (11) | | | |
| 45 | 5400 | 100 (30) | 62 (19) | | | | |
| 50 | 6000 | 87 (26) | 50 (15) | | | | |

*Conductor size is based on maximum 2% voltage drop

| Cord Lengths for 240 Volt Loads | | | | | | | |
|---|--------------|---|-----------|-----------|-----------|----------|----------|
|  | | | | | | | |
| ⚠ If unit does not have GFCI receptacles, use GFCI-protected extension cord. | | | | | | | |
| Current (Amperes) | Load (Watts) | Maximum Allowable Cord Length in ft (m) for Conductor Size (AWG)* | | | | | |
| | | 4 | 6 | 8 | 10 | 12 | 14 |
| 5 | 1200 | | | 700 (213) | 450 (137) | 225 (68) | 200 (61) |
| 7 | 1680 | | 800 (244) | 500 (152) | 300 (91) | 200 (61) | 125 (38) |
| 10 | 2400 | 800 (244) | 550 (168) | 350 (107) | 225 (69) | 125 (38) | 100 (31) |
| 15 | 3600 | 600 (183) | 350 (107) | 225 (69) | 150 (46) | 75 (23) | 60 (18) |
| 20 | 4800 | 450 (137) | 275 (84) | 175 (53) | 100 (31) | 60 (18) | |
| 25 | 6000 | 350 (107) | 225 (69) | 125 (38) | 75 (23) | | |
| 30 | 7000 | 300 (91) | 175 (53) | 100 (31) | 75 (23) | | |
| 35 | 8400 | 250 (76) | 150 (46) | 100 (31) | | | |
| 40 | 9600 | 225 (69) | 125 (38) | 75 (23) | | | |
| 45 | 10,800 | 200 (61) | 125 (38) | | | | |
| 50 | 12,000 | 175 (53) | 100 (31) | | | | |

*Conductor size is based on maximum 2% voltage drop

SECTION 12 – PARTS LIST

☞ Hardware is common and not available unless listed.





Figure 12-1. Main Assembly



| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|-----------------------------------|-------------|-----------|---|----------|
| Figure 12-1. Main Assembly | | | | |
| 1 | | 189 824 | PANEL, gen LH | 1 |
| 2 | | | Deleted | |
| 3 | | +189 828 | PANEL, engine side | 1 |
| 4 | Z1 | 214 972 | REACTOR, ac | 1 |
| 5 | | 206 352 | BRACE, front to center upright | 2 |
| 6 | 1T | 038 621 | BLOCK, term 30A 4 pole frict term str | 1 |
| | | 038 620 | LINK, jumper term blk 30A | 2 |
| 7 | | 081 499 | BRACKET, mtg strip terminal | 1 |
| 8 | SR4, SR5 | 215 909 | RECTIFIER | 2 |
| 9 | CB4 | 045 061 | CIRCUIT BREAKER, auto reset 24vdc 7 amp | 1 |
| 10 | T1 | 201 613 | TRANSFORMER w/bracket | 1 |
| 11 | | 173 352 | EXTRUSION, rubber clamp/bulb (order by ft) | 3ft |
| 12 | | 189 708 | FIREWALL, top | 1 |
| 13 | | 191 307 | COVER, plate | 1 |
| 14 | | 191 829 | HOSE, air cleaner | 1 |
| 15 | | 189 763 | BRACKET, mtg air cleaner | 1 |
| 16 | | 189 764 | AIR CLEANER, intake | 1 |
| | | *192 938 | FILTER, air element primary | 1 |
| | | *♦192 939 | FILTER, air element safety | 1 |
| 17 | | 189 464 | SEAL, weather lift eye | 1 |
| | | 173 909 | HOSE, sae .312 id x .560 od x 24.000 (order by ft) | 2 |
| 18 | | 201 658 | UPRIGHT, center assembly | 1 |
| 19 | | +201 934 | COVER, top | 1 |
| 20 | | 189 052 | GROMMET, plastic neck filler fuel | 1 |
| 21 | | 190 198 | CAP, tank screw-on 3.500 in w/vent | 1 |
| 22 | | 192 041 | LABEL, use diesel fuel only | 1 |
| 23 | | 222 513 | LABEL, warning falling equipment can cause serious | 1 |
| 24 | | 224 265 | LABEL, warning hot exhaust parts do not touch | 1 |
| 25 | | 105 734 | PIPE, muffler extension elbow 1.875 OD | 1 |
| 25 | | 201 592 | PIPE, exhaust (export models) | 1 |
| 26 | | 201 851 | COVER, radiator access | 1 |
| 27 | | 191 354 | SUPPORT, cover | 1 |
| 28 | Figure 12-4 | | GENERATOR | 1 |
| 29 | | 225 120 | LABEL, warning moving parts can cause injury | 6 |
| 30 | | 191 577 | GUARD, starter | 1 |
| 31 | | 197 370 | BRACKET, mtg engine LH | 1 |
| 32 | | 190 951 | EDGE TRIM, styel tl750-b2 x 1/16 black w/clips 1.625 | 1 |
| 33 | | 197 639 | BAFFLE, air | 1 |
| 34 | | 200 731 | MANIFOLD, exhaust muffler (Included w/Engine – export models) | 1 |
| | | 010 875 | CLAMP, muffler 2.000 dia u pld | 1 |
| 35 | | 237 004 | ENGINE, Deutz dsl elec D2011I03i (includes manifold/muffler) | 1 |
| | | *067 265 | FILTER, oil (engine) | 1 |
| | | *192 744 | FILTER, fuel spin-on | 1 |
| | | *066 217 | FILTER, fuel secondary | 1 |
| | | *195 745 | SWITCH, oil pressure | 1 |
| | | *195 746 | SENDER, coolant | 1 |
| | | 179 561 | EXTRUSION, rubber clamp/bulb 2.250lg (order by ft) | 1 |
| | | 179 562 | EXTRUSION, rubber clamp/bulb 3.000lg (order by ft) | 1 |
| 36 | | *216 959 | BELT, blower | 1 |
| 37 | | | Deleted | |
| 38 | | 201 714 | BOX, air intake | 1 |
| 39 | | 201 748 | UPRIGHT, rear | 1 |
| 40 | | 108 081 | TERMINAL PROTECTOR, battery post mtg | 2 |
| 41 | | 190 206 | CABLE, bat neg 42 in lg No. 2 awg w/clamp and .375rng | 1 |

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|---|------------|----------|--|----------|
| Figure 12-1. Main Assembly (Continued) | | | | |
| 42 | | 190 207 | CABLE, bat pos 45 in lg No. 1 awg w/clamp and .406rng | 1 |
| 43 | | 203 430 | BRACKET, battery holddown | 1 |
| 44 | | 190 897 | BATTERY, stor 12V 650crk 110rsv gp 24 | 1 |
| 45 | | 201 006 | BOLT, j stl .312-18 x 8.500 pld | 2 |
| 46 | | 168 385 | LABEL, warning battery explosion can blind | 1 |
| 47 | | | Deleted | |
| 48 | | +201 183 | COVER, battery access | 1 |
| 49 | | +215 252 | GUARD, belt | 1 |
| 50 | | 206 297 | BASE, fuel filter w/fittings | 1 |
| 51 | | 145 282 | FITTING, hose brs barbed elbow M 5/16tbg x 1/4NPT | 2 |
| 52 | | 196 465 | HOSE, SAE .312 ID X .560 OD X 23.000 | 1 |
| | | 200 032 | HOSE, SAE .312 ID X .560 OD X 38.000 | 1 |
| 53 | | *192 744 | FILTER, fuel spin-on | 1 |
| 54 | | +201 715 | BOX, air intake | 1 |
| 55 | | 199 849 | SCREW, 625-11 x 4.00hexhd pln gr 5 pld | 4 |
| 56 | | 071 731 | WASHER, flat .656 ID x 2.250 OD x .187T stl pld | 4 |
| 57 | | 197 366 | BRACKET, mtg engine RH | 1 |
| 58 | | 071 890 | RETAINER, mount eng/gen | 4 |
| 59 | | 071 730 | TUBING, stl .875 OD x 12ga wall x 2.500 | 4 |
| 60 | | 083 476 | MOUNT, eng/gen nprn .875 ID x 2.500 OD x 2.000 | 4 |
| 61 | | 197 373 | BRACKET, support base RH | 1 |
| 62 | | 135 205 | NUT, 625-11 .94hex .76H stl pld elastic stop nut | 4 |
| 63 | | 190 992 | KEEPER, latch engine access door | 1 |
| 64 | | 190 076 | CHANNEL, stiffener engine access | 1 |
| 65 | | 199 592 | LATCH, paddle series 20 (black) | 1 |
| 66 | | 237 352 | LABEL, maintenance big blue deutz series ce | 1 |
| 67 | | +200 989 | DOOR, engine access | 1 |
| 68 | | 189 975 | HINGE, door access 180deg | 2 |
| 69 | | 208 141 | STOP, door | 2 |
| 70 | | 189 826 | PANEL, rocker | 1 |
| 71 | | 189 827 | PANEL, gen RH | 1 |
| 72 | | 191 626 | BUMPER, door engine access | 2 |
| | | 199 507 | HOSE, oil drain assy 20 in (consisting of) | 1 |
| 73 | | 165 271 | VALVE, oil drain 3/8-18NPTF | 1 |
| 74 | | 176 529 | FITTING, hose brs barbed fem 1/2tbg x 3/8NPT | 1 |
| 75 | | 113 854 | HOSE, SAE .500 ID x .780 OD xc oil (order by ft) | 2ft |
| 76 | | 176 528 | FITTING, hose brs barbed elbow fem 1/2 tbg x 1/2 NPT | 1 |
| 77 | | 173 336 | FITTING, adapter oil drain | 1 |
| 78 | | | WASHER, oil drain (available through engine manufacturer) | 1 |
| 79 | | 218 087 | TANK, fuel (consisting of) | 1 |
| 80 | | 124 253 | BUSHING, tank fuel | 4 |
| | | 084 173 | CLAMP, hose .460 - .545clp dia slftng | 2 |
| 81 | | 189 912 | FITTING, stl barbed elbow w/.047 in orf zinc pld | 1 |
| 82 | | 189 909 | FITTING, stand pipe hose .250 x 9.260 lg 90deg zinc | 1 |
| 83 | | 189 913 | FITTING, stl barbed elbow zinc pld | 1 |
| 84 | | 190 142 | SENDER, fuel gauge 9.7500 deep tank | 1 |
| 85 | | 189 910 | FITTING, stand pipe hose .3125 x 9.260 lg 90deg zinc | 1 |
| 86 | | 189 908 | VALVE, drain fuel 180deg | 1 |
| 87 | | 181 572 | BUSHING, tank fuel | 1 |
| 88 | | 191 446 | EXTRUSION, rubber w/adhesive 1.000 x 1.000 D (order by ft) | 6ft |
| 89 | | 196 220 | BRACKET, hold down fuel tank rear | 1 |
| 90 | | 192 362 | BRACKET, mtg nyl 1/2 conduit | 1 |
| 91 | | 191 897 | BRACKET, mtg unit | 4 |

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|----------|------------|----------|-------------|----------|
|----------|------------|----------|-------------|----------|


Figure 12-1. Main Assembly (Continued)

| | | | | |
|--------------|--------------|---------|--|-----|
| .. 92 | +200 | 999 | .. BASE | 1 |
| .. 93 | | 224 266 | .. LABEL, warning do not weld on base | 2 |
| .. 94 | R2 | 189 699 | .. RESISTOR, WW tap 375W 10 ohm w/mtg bkt | 1 |
| .. 95 | R3 | 189 699 | .. RESISTOR, WW tap 375W 10 ohm w/mtg bkt | 1 |
| .. 96 | | 191 446 | .. EXTRUSION, rubber w/adhesive 1.000 x 1.000 D (order by ft) | 6ft |
| .. 97 | | 218 086 | .. BRACKET, hold down fuel tank | 1 |
| .. 98 | Figure 12-2 | | .. CONTROL BOX ASSEMBLY | 1 |
| .. 99 | | 189 731 | .. FIREWALL, lower | 1 |
| .. 100 | | 173 352 | .. EXTRUSION, rubber clamp/bulb (order by ft) | 3ft |
| .. 101 | | 201 697 | .. PAN, reactor and rectifier | 1 |
| | | 203 260 | .. LABEL, caution do not use ether | 1 |
| .. 102 | Figure 12-5 | | .. MAIN RECTIFIER ASSEMBLY | 1 |
| .. 103 | | 191 448 | .. TOP, cover front upright | 1 |
| .. 104 | +201 | 750 | .. UPRIGHT, front | 1 |
| .. 105 | | 233 953 | .. LABEL, warning general precautionary CSA | 1 |
| .. 106 | Figure 12-3, | | .. PANEL, front w/components | 1 |
| .. 107 | | 212 944 | .. LABEL, cc stick overlap weld ranges | 1 |
| .. 108 | | 233 088 | .. LABEL, danger using a generator indoors can kill you in minutes (unit) .. | 1 |
| | | 237 278 | .. LABEL, hour/fuel meter usage | 1 |
| | | 190 058 | .. NUT, .250-20 u-nut multi-thread | 19 |
| | | 049 525 | .. NUT, 312-18 u-nut multi-thread | 32 |
| | | 224 688 | .. KIT, label (includes safety and informational labels) | 1 |

+ When ordering a component originally displaying a precautionary label, the label should also be ordered.

* Recommended Spare Parts.

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.



804 175-D

Figure 12-2. Control Box Assembly

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|----------|------------|----------|-------------|----------|
|----------|------------|----------|-------------|----------|

Figure 12-2. Control Box Assembly (Figure 12-1 Item 98)


| | | | | | |
|-----|----|--------------|----------|--|---|
| ... | 1 | F1, F2 | *085 874 | FUSE, mintr cer slo-blo 10A 250V | 2 |
| ... | 2 | | 046 432 | HOLDER, fuse mintr .250 x 1.250 | 2 |
| ... | 3 | CR7 | 188 636 | RELAY, OCV control | 1 |
| ... | 4 | | 201 077 | CONTROL BOX, lh | 1 |
| ... | 5 | C12 | 191 944 | CAPACITOR, polyp met film 10. uf 250 vac 10% | 1 |
| ... | 6 | R6 | 141 424 | RESISTOR, ww fxd 30 w 25 ohm faston te | 1 |
| ... | 7 | | 201 078 | CONTROL BOX, rh | 1 |
| ... | 8 | CR1 | 214 876 | RELAY, encl 6vds spst 35a/14vdc 5 pin | 1 |
| ... | 9 | D8/C8, D12 | 189 701 | DIODE/CAPACITOR BOARD | 1 |
| ... | 10 | CB10 | 190 374 | CIRCUIT BREAKER, auto reset 12VDC 40A | 1 |
| ... | 11 | CR5 | 223 710 | RELAY, encl 12vdc dpst-no 25a 6pin flange | 1 |
| ... | 12 | | 201 079 | COVER, control box | 1 |
| ... | 13 | SR1, SR2 | 035 704 | RECTIFIER, integ 40A 800V | 2 |
| ... | 14 | C9 | 087 110 | CAPACITOR, elctlt 240uf 200VDC | 1 |
| ... | 15 | | 177 136 | CLAMP, capacitor 1.375dia | 1 |
| ... | 16 | D1/C1 | 189 701 | DIODE/CAPACITOR BOARD | 1 |
| ... | 17 | CB11, 12, 13 | 139 266 | SUPPLEMENTARY PROTECTOR, man reset 1p 15a 250vac | 3 |
| ... | 18 | CR9 | 090 104 | RELAY, encl 12vdc spst 30a/15vdc 5pin flange mtg | 1 |
| ... | | | 235 251 | HARNESS, fuel shutdown solenoid (consisting of) | 1 |
| ... | 19 | R7 | 235 250 | RESISTOR, hsc 30 w 3 ohm | 1 |
| ... | | | 148 850 | SOCKET, relay 5 pin | 1 |

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|--|------------|----------|---|----------|
| Figure 12-2. Control Box Assembly (Continued) | | | | |
| | | 236606 | HARNESS, control box, weld control (consisting of) | 1 |
| | SR1, SR2 | 035704 | Rectifier, Integ Bridge 40. Amp 800v | 2 |
| | D1/C1 | 189701 | Diode/Capacitor Board, | 1 |
| | RC4 | 047483 | Conn, Rect Univ 084 15p/S 3row Rcpt Cable/Panel Lkg | 1 |
| CB11, CB12, CB13 | | 139266 | Supplementary Protector, Man Reset 1p 15a 250vac | 3 |
| | CR7 | 188636 | Relay, Ocv Control | 1 |
| | | 148850 | Socket, Relay 5 Pin | 1 |
| | S6 | 011622 | Switch, Tgl 3pdt 15a 125vac On–none–on Spd Term | 1 |
| | S5 | 011609 | Switch, Tgl Spdt 15a 125vac On–none–on Spd Term Chr | 1 |
| | | 211292 | Conn, Pack 4p 1row Female | 1 |
| | | 211293 | Conn, Pack Terminal Position Assurance(Lock) | 1 |
| | | 164617 | Clip, Wiring Straight | 3 |
| | S2 | 021467 | Switch, Tgl Spst 3a 250v Off–none–(On) Spd Term | 1 |
| | | 150316 | Conn, Rect Univ 039 6p/S 3row Plug Cable Lkg | 5 |
| | RC3 | 158466 | Conn, Rect Univ 084 12p/S 3row Rcpt Cable/Panel Lkg | 1 |
| | RC1 | 135133 | Conn, Rect Univ 084 9p/S 3row Rcpt Cable/Panel Lkg | 1 |
| | | 092670 | Conn, Rect Univ 084 3p/S 1row Plug Cable Lkg | 1 |
| | | 214932 | Conn, Rect Univ 039 8p/S 2row Plug Cable Lkg Seal | 1 |
| | | 214933 | Seal, Wire Univ 039 | 6 |
| | | 215013 | HARNESS, unit weld control (consisting of) | 1 |
| | PLG3 | 158465 | CONN, rect univ 084 12p/s 3row plug cable lkg | 1 |
| | | 187654 | SEAL, wire univ 12p/s 3row | 1 |
| | PLG6 | 114063 | CONN, rect univ 084 4p/s 1row plug cable lkg | 1 |
| | | 192309 | CLIP, snap in .630 bundle .250 hole .248 thk | 2 |
| | | 215659 | HARNESS, engine control (consisting of) | 1 |
| | | 148850 | SOCKET, relay 5 pin | 2 |
| | PLG4 | 114062 | CONNECTOR, rect univ 084 15P/S 3 row plug cable lkg | 1 |
| | | 173916 | HOUSING, contact 10-pole | 1 |

*Recommended Spare Parts.

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

☞ Hardware is common and not available unless listed.



804 171-B


Figure 12-3. Panel, Front w/Components

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|--|------------|------------|---|----------|
| Figure 12-3. Panel, Front w/Components (Figure 12-1 Item 106) | | | | |
| ... | 1 | 019 602 | .. KNOB, pointer | 1 |
| ... | 2 | | .. PLATE SCREENED, ident contrl rating (order by model & serial number) | 1 |
| ... | 3 | 236 608 | .. PANEL, engine/weld control | 1 |
| ... | 4 | S3 208 278 | .. SWITCH, range/changeover | 1 |

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|---|------------|----------|--|----------|
| Figure 12-3. Panel, Front w/Components (Continued) | | | | |
| | | 192 558 | HARNESSES, range (consisting of) | 1 |
| | RC6 | 148 439 | HOUSING, rect univ 084 4p/s 1 row rcpt | 1 |
| 5 | R1 | 188 635 | RHEOSTAT, WW 300W 34 ohm | 1 |
| 6 | | 202 209 | SPACER, nylon | 3 |
| 7 | S6 | 011 622 | SWITCH, tgl DPDT 15A 125VAC (included in control box harness, see Figure 12-2) | 1 |
| 8 | S5 | 011 609 | SWITCH, tgl SPDT 15A 125VAC on-none-on spd term chr (included in control box harness, see Figure 12-2) | 1 |
| 9 | RC13 | 032 897 | RECEPTACLE, twlk grd 2P3W 15A 125V | 1 |
| 10 | S1 | 212 436 | SWITCH, ignition 4posn w/handle | 1 |
| | | 201 553 | CLIP, circuit breaker retaining | 1 |
| 11 | CB2, CB3 | 093 996 | SUPPLEMENTARY PRO, man reset 1p 20a 250vac frict | 2 |
| 12 | GFCI1 | 246 865 | RCPT, str dx grd 2p3w 20a 125v *5-20r gfi | 1 |
| 13 | | 190 861 | LABEL, warning electric shock and moving parts | 1 |
| 14 | | +215 347 | PANEL, gen pwr | 1 |
| 15 | | 083 030 | STUD, brs .250-20 x 1.750 w/hex collar | 1 |
| 16 | | 601 836 | NUT, 250-20 .50hex .19h brs | 3 |
| 17 | | 201 125 | PANEL, mtg terminal pwr output | 1 |
| 18 | | 241 433 | TERMINAL, pwr output black | 1 |
| | | 180 735 | WASHER, output stud | 2 |
| 19 | | 181 169 | SPACER, output stud | 2 |
| 20 | | 186 621 | BOOT, generic output stud | 2 |
| 21 | | 241 432 | TERMINAL, pwr output red | 1 |
| 22 | RC1 | 176 355 | RECEPTACLE, str 2P3W 16A 220V flange mtg | 1 |
| 23 | | 209 056 | COVER, receptacle w/gasket | 1 |
| 24 | | 206 795 | BOOT, circuit breaker clear hex nut | 2 |
| 25 | | 201 045 | COVER, receptacle twistlock | 1 |
| 26 | FUEL/HM | 232 113 | GAUGE, fuel elec/hour meter | 1 |
| 27 | | 217 084 | GAUGE, Coolant Temp 0- 300 Deg F | 1 |
| | | 195 746 | SENDER, coolant temp & 130c switch | 1 |
| 28 | | 217 083 | GAUGE, Pressure Oil 0-100 Psi | 1 |
| | | 195 745 | SWITCH, pressure oil 1.5 bar nc cont | 1 |
| 29 | | 164 874 | VOLT METER, W/Leads | 1 |
| 30 | | 164 873 | AMMETER, W/Leads | 1 |
| 31 | | 021 385 | BOOT, toggle switch lever | 2 |
| 32 | | 189 161 | HANDLE, switch range | 1 |
| 33 | | 010 647 | PIN, spring CS .156 x 1.250 | 1 |
| | | 024 103 | BLANK, snap-in nyl .750 mtg hole black | 1 |

+ When ordering a component originally displaying a precautionary label, the label should also be ordered.

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.



802 552-B

Figure 12-4. Generator

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|----------|------------|----------|-------------|----------|
|----------|------------|----------|-------------|----------|

Figure 12-4. Generator (Figure 12-1 Item 28)

| | | | | |
|-----|----|----------|--|----|
| ... | 1 | 132 053 | .. SCREW, .375-16x1.50 hex hd-pln gr5 pld | 6 |
| ... | 2 | 183 387 | .. WASHER, conical spring .406 ID x .875 OD pltd | 6 |
| ... | 3 | 195 911 | .. ENDBELL, gen (consisting of) | 1 |
| ... | 4 | 143 220 | .. O-RING, 2.859 ID x .139CS | 1 |
| ... | 5 | 201 099 | .. STATOR, exciter/gen pwr | 1 |
| ... | 6 | +215 011 | .. STATOR, weld assembly complete | 1 |
| ... | 7 | 225 120 | .. LABEL, warning moving parts can cause injury | 2 |
| ... | 8 | 190 197 | .. GUARD, generator wire mesh | 1 |
| ... | 9 | 172 674 | .. SPRING, ext .240 OD x .041 wire x 3.500pld | 2 |
| ... | 10 | 039 207 | .. BAFFLE, air | 1 |
| ... | 11 | .. ROTOR | .. ROTOR, Generator Segmented Assy (Includes) | 1 |
| ... | 12 | 210 824 | .. ROTOR, Generator (Includes) | 1 |
| ... | 13 | 024 617 | .. RING, Rtnng Ext 1.375 Shaft X .050 Thk | 1 |
| ... | 14 | 053 390 | .. BEARING, Ball Rdl Sgl Row 1.370 X 2.830 X .6 | 1 |
| ... | | | .. HUB, Drive (Not Sold Separately) | 1 |
| ... | | 210 447 | .. FAN, Rotor Assy Generator (Segmented) (includes) | 1 |
| ... | 15 | 210 332 | .. PLATE, Flex Hubmount | 1 |
| ... | 16 | 206 242 | .. FAN, Rotor Segmented Assy Gen | 4 |
| ... | 17 | 049 026 | .. SCREW, M10-1.5x 25 Hex Hd-pln 8.8 Pln | 10 |
| ... | 18 | 083 883 | .. WASHER, Lock .402idx0.709odx.087t Stl Split10mm | 10 |
| ... | 19 | 080 389 | .. SCREW, 312-18x1.00 Hexwhd.66d Stl Pld Slffmg Tap-rw | 8 |
| ... | 20 | 195 748 | .. FLYWHEEL, Engine | 1 |
| ... | 21 | 193 256 | .. ADAPTER, Engine | 1 |
| ... | 22 | 083 883 | .. WASHER, Lock .402idx0.709odx.087t Stl Split10mm | 4 |

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|---|------------|----------|--|----------|
| Figure 12-4. Generator (Continued) | | | | |
| ... 23 | | 049 026 | .. SCREW, M10-1.5x 25 Hex Hd-pln 8.8 Pln | 4 |
| ... 24 | | 191 579 | .. COVER, starter hole Perkins/Continental | 1 |
| | | 195 560 | .. GUARD, starter hole deutz 912 | 1 |
| ... 25 | | 083 883 | .. WASHER, Lock .402idx0.709odx.087t Stl Split10mm | 6 |
| ... 26 | | 172 555 | .. SCREW, M10-1.5 x 50hexhd pln 8.8pld | 6 |
| ... 27 | | 602 159 | .. SCREW, .312-18x .75 hexwhd.66d stl pld slffmg tap-rw | 6 |
| ... 28 | | 601 961 | .. SCREW, .312-18 x 2.25hexhd pln gr 5pld | 4 |
| ... 29 | | 602 211 | .. WASHER, lock .318 ID x 0.586 | 6 |
| ... 30 | | 139 341 | .. WASHER, exciter | 4 |
| ... 31 | | *190 823 | .. BRUSH, contact | 3 |
| ... 32 | | 208 469 | .. CLIP, spring | 3 |
| ... 33 | | 189 142 | .. BRUSHHOLDER ASSEMBLY, gen | 1 |
| ... 34 | | 602 242 | .. WASHER, flat .375IDx0.875odx.083t stl pld | 2 |
| ... 35 | | 602 211 | .. WASHER, Lock .318idx0.586odx.078t Stl Pld Split.312 | 2 |
| ... 36 | | 604 534 | .. SCREW, .312-18x1.25 hex hd-pln gr5 pld | 2 |
| | | 190 259 | .. HARNESS, brush (consisting of) | 1 |
| | PLG1 | 168 071 | ... CONNECTOR, (kit) rect univ 084 9P/S 3 row plug cable lkg | 1 |
| | | 187 651 | ... SEAL, wire univ 9P/S 3 row | 1 |


+ When ordering a component originally displaying a precautionary label, the label should also be ordered.

*Recommended Spare Parts.

◆Optional

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

☞ Hardware is common and not available unless listed.



802 279-A

Figure 12-5. Main Rectifier Assembly

| Item No. | Dia. Mkgs. | Part No. | Description | Quantity |
|----------|------------|----------|-------------|----------|
|----------|------------|----------|-------------|----------|

Figure 12-5. Main Rectifier Assembly (Figure 12-1 Item 102)

| | | | | |
|-------|------------|---------|---|---|
| | SR3 | 239 784 | RECTIFIER, environmental high power (consisting of) | 1 |
| ... 1 | | 188 137 | CONNECTION BOARD, rectifier AC | 1 |
| ... 2 | | 188 517 | BUS BAR, connection board | 3 |
| ... 3 | | 188 135 | ENCLOSURE, rectifier | 2 |
| ... 4 | | 134 201 | STAND-OFF, support | 3 |
| ... 5 | PC3 | 215 755 | CIRCUIT CARD ASSEMBLY, protection | 1 |
| ... 6 | | 188 136 | INSULATOR, heat sink | 8 |
| ... 7 | | 188 493 | HEAT SINK, rectifier al | 2 |
| ... 8 | D3, D5, D7 | 245 097 | DIODE, rect 300 a 500v do-9 (straight) modified | 3 |
| ... 9 | D2, D4, D6 | 245 096 | DIODE, rect 300 a 500v do-9 (reversed) modified | 3 |

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

Warranty

Effective January 1, 2010
(Equipment with a serial number preface of MA or newer)

This limited warranty supersedes all previous manufacturers warranties and is exclusive with no other guarantees or warranties expressed or implied.

LIMITED WARRANTY – Subject to the terms and conditions below, warrants to its original retail purchaser that new equipment sold after the effective date of this limited warranty is free of defects in material and workmanship at the time it is shipped from factory. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

Within the warranty periods listed below, manufacturer will repair or replace any warranted parts or components that fail due to such defects in material or workmanship. Manufacturer must be notified in writing within thirty (30) days of such defect or failure, at which time manufacturer will provide instructions on the warranty claim procedures to be followed.

Manufacturer shall honor warranty claims on warranted equipment listed below in the event of such a failure within the warranty time periods. All warranty time periods start on the delivery date of the equipment to the original end-user purchaser, and not to exceed one year after the equipment is shipped to the distributor.

1. 5 Years Parts — 3 Years Labor
 - * Original main power rectifiers only to include SCRs, diodes, and discrete rectifier modules
2. 3 Years — Parts and Labor
 - * Engine Driven Welding Generators
(NOTE: Engines are warranted separately by the engine manufacturer.)
 - * Inverter Power Sources (Unless Otherwise Stated)
 - * Plasma Arc Cutting Power Sources
 - * Process Controllers
 - * Semi-Automatic and Automatic Wire Feeders
 - * Smith 30 Series Flowgauge and Flowmeter Regulators (No Labor)
 - * Transformer/Rectifier Power Sources
 - * Water Coolant Systems (Integrated)
3. 2 Years — Parts
 - * Auto-Darkening Helmet Lenses (No Labor)
4. 1 Year — Parts and Labor Unless Specified
 - * Automatic Motion Devices
 - * CoolBelt and CoolBand Blower Unit (No Labor)
 - * External Monitoring Equipment and Sensors
 - * Field Options
(NOTE: Field options are covered for the remaining warranty period of the product they are installed in, or for a minimum of one year — whichever is greater.)
 - * Flowgauge and Flowmeter Regulators (No Labor)
 - * RFCS Foot Controls (Except RFCS-RJ45)
 - * Fume Extractors
 - * HF Units
 - * ICE Plasma Cutting Torches (No Labor)
 - * Induction Heating Power Sources, Coolers, and Electronic Controls/Recorders
 - * Load Banks
 - * Motor Driven Guns (w/exception of Spoolmate Spoolguns)
 - * PAPR Blower Unit (No Labor)
 - * Positioners and Controllers
 - * Racks
 - * Running Gear/Trailers
 - * Spot Welders
 - * Subarc Wire Drive Assemblies
 - * Water Coolant Systems (Non-Integrated)
 - * Weldcraft-Branded TIG Torches (No Labor)
 - * Work Stations/Weld Tables (No Labor)
5. 6 Months — Parts
 - * Batteries
 - * Bernard Guns (No Labor)
 - * Tregaskiss Guns (No Labor)

6. 90 Days — Parts
 - * Accessory (Kits)
 - * Canvas Covers
 - * Induction Heating Coils and Blankets, Cables, and Non-Electronic Controls
 - * M-Guns
 - * MIG Guns and Subarc (SAW) Guns
 - * Remote Controls and RFCS-RJ45
 - * Replacement Parts (No labor)
 - * Roughneck Guns
 - * Spoolmate Spoolguns

Limited Warranty shall not apply to:

1. **Consumable components; such as contact tips, cutting nozzles, contactors, brushes, relays, work station table tops and welding curtains, or parts that fail due to normal wear. (Exception: brushes and relays are covered on all engine-driven products.)**
2. Items furnished by manufacturer, but manufactured by others, such as engines or trade accessories. These items are covered by the manufacturer's warranty, if any.
3. Equipment that has been modified by any party other than manufacturer, or equipment that has been improperly installed, improperly operated or misused based upon industry standards, or equipment which has not had reasonable and necessary maintenance, or equipment which has been used for operation outside of the specifications for the equipment.

MANUFACTURER'S PRODUCTS ARE INTENDED FOR PURCHASE AND USE BY COMMERCIAL/INDUSTRIAL USERS AND PERSONS TRAINED AND EXPERIENCED IN THE USE AND MAINTENANCE OF WELDING EQUIPMENT.

In the event of a warranty claim covered by this warranty, the exclusive remedies shall be, at manufacturer's option: (1) repair; or (2) replacement; or, where authorized in writing by manufacturer in appropriate cases, (3) the reasonable cost of repair or replacement at an authorized service station; or (4) payment of or credit for the purchase price (less reasonable depreciation based upon actual use) upon return of the goods at customer's risk and expense. Manufacturer's option of repair or replacement will be F.O.B., Factory at Appleton, Wisconsin, or F.O.B. at an authorized service facility as determined by manufacturer. Therefore no compensation or reimbursement for transportation costs of any kind will be allowed.

TO THE EXTENT PERMITTED BY LAW, THE REMEDIES PROVIDED HEREIN ARE THE SOLE AND EXCLUSIVE REMEDIES. IN NO EVENT SHALL MANUFACTURER BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING LOSS OF PROFIT), WHETHER BASED ON CONTRACT, TORT OR ANY OTHER LEGAL THEORY.

ANY EXPRESS WARRANTY NOT PROVIDED HEREIN AND ANY IMPLIED WARRANTY, GUARANTY OR REPRESENTATION AS TO PERFORMANCE, AND ANY REMEDY FOR BREACH OF CONTRACT TORT OR ANY OTHER LEGAL THEORY WHICH, BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION, OPERATION OF LAW, CUSTOM OF TRADE OR COURSE OF DEALING, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE, WITH RESPECT TO ANY AND ALL EQUIPMENT FURNISHED BY MANUFACTURER IS EXCLUDED AND DISCLAIMED BY MANUFACTURER.

Some states in the U.S.A. do not allow limitations of how long an implied warranty lasts, or the exclusion of incidental, indirect, special or consequential damages, so the above limitation or exclusion may not apply to you. This warranty provides specific legal rights, and other rights may be available, but may vary from state to state.

In Canada, legislation in some provinces provides for certain additional warranties or remedies other than as stated herein, and to the extent that they may not be waived, the limitations and exclusions set out above may not apply. This Limited Warranty provides specific legal rights, and other rights may be available, but may vary from province to province.



Owner's Record

Please complete and retain with your personal records.

Model Name

Serial/Style Number

Purchase Date

(Date which equipment was delivered to original customer.)


Distributor

Address

City

State

Zip



RED-D-ARC

Welderrentals

1-800-245-3660

www.red-d-arc.com

Contact the Delivering Carrier for:

File a claim for loss or damage during shipment.

For assistance in filing or settling claims, contact your distributor and/or equipment manufacturer's Transportation Department.