

COMMUNICATIONS



CHAPTER 6

In This Chapter...

| | |
|--|-------------|
| Communications: Capabilities | 6-3 |
| Communication Ports..... | 6-3 |
| Communications: Connectivity | 6-11 |
| Communication Ports..... | 6-11 |
| Communications ASCII and Custom Protocol Functionality | 6-17 |
| ASCII Instructions | 6-17 |
| Custom Protocol Instructions | 6-18 |
| Communications: Ethernet | 6-20 |
| TCP and UDP Port Numbers | 6-20 |
| IP Addressing and Subnetting | 6-20 |
| PC Setup | 6-21 |
| CPU Setup..... | 6-22 |
| TCP Connection Behavior with Modbus TCP and Network Instructions | 6-23 |
| Communications Modbus Functionality | 6-24 |
| Master/Client Function Code and Data Type Support | 6-24 |
| Slave/Server Function Code and Data Type Support | 6-26 |
| Assigning Modbus Addresses to Tags | 6-27 |
| Modbus Options | 6-30 |
| Modbus Instructions..... | 6-33 |
| Network Instructions | 6-35 |
| Automatic Poll versus Manual Polling and Interlocking..... | 6-36 |
| Message Queue..... | 6-38 |
| EtherNet/IP for the Productivity Series | 6-39 |
| Terminology Definitions | 6-39 |
| Network Layer Chart | 6-40 |
| EtherNet/IP Data | 6-40 |

| | |
|--|-------------|
| Class 1 and Class 3 Connections | 6-41 |
| Example Setup: Productivity3000® as EtherNet/IP Adapter | 6-41 |
| Troubleshooting Tips: | 6-47 |
| Ethernet IP I/O Message Troubleshooting:..... | 6-49 |
| Ethernet IP Explicit Message Troubleshooting:..... | 6-49 |
| Communications: Remote I/O and GS-Drives | 6-50 |
| Things To Consider for the design of Remote I/O and GS-Drives..... | 6-50 |
| Configuration of Remote Slaves..... | 6-51 |
| Configuration of GS-Drive Connections..... | 6-54 |
| Communications: Port Configuration | 6-58 |
| Ethernet Configuration | 6-58 |
| External Ethernet Port Settings | 6-59 |
| Local Ethernet Port Settings..... | 6-60 |
| Remote Access Configuration | 6-60 |
| Serial Configuration..... | 6-61 |
| RS-232 and RS-485 Port Settings..... | 6-61 |
| Communications: Error Codes | 6-64 |
| P3000 EtherNet/IP Error Codes | 6-65 |




NOTE: The P3-RS module is discontinued as of 6/20. Please use P3-RX as a replacement.

Communications: Capabilities

Communication Ports

The AutomationDirect P3000 CPUs are provided with several Communications Ports. Each of these ports are described in the sections below.

- a. USB IN: The USB IN programming port is a USB Type B style connector located on the upper left side of the CPU. It is used exclusively for connecting to a PC running the Productivity Suite Programming Software. Installing the programming software will install the USB driver as well. See *Communications: Connectivity* section for connection information.




NOTE: The USB IN port is NOT compatible with older 1.0/1.1 full speed USB devices.

- b. Ethernet: The Ethernet port is 10/100 Base-T Ethernet with an RJ-45 style connector. It is used for:
 - Connection to a PC running the Productivity Suite programming software.
 - Modbus TCP Client connections (Modbus requests sent from the CPU).
 - Modbus TCP Server connections (Modbus requests received by the CPU).
 - Outgoing Email.

Modbus TCP Client connections: The CPU can connect to 32 Modbus TCP server devices concurrently by means of communications instructions in the ladder program (MRX, MWX, RX, WX). It is possible to connect to more than 32 Modbus TCP server devices, but not concurrently.

This is accomplished by having communications instructions for more than 32 devices in the ladder program and controlling the enabling and disabling of the instructions so that only 32 devices are enabled at a given time. To connect to non Productivity3000® devices, use the MRX (Modbus Read) and MWX (Modbus Write) instructions. To connect to other P3000 CPU's, use the RX (Network Read) and WX (Network Write) instructions.

Modbus TCP Client (MRX-MWX)




The greatest difference between the RX and the MRX is the RX Tag Name in the target CPU can be referenced directly and does not need a corresponding Modbus address. The way this is accomplished is by mapping local and remote tagnames together within the local CPU's RX instruction. Once the instruction is set up to read a remote project, the "Tags of Remote Project" or "Array Tags of Remote Project" drop down lists will be accessible. Map the Tag of the Remote project to a Tag in the Local project to read this data.

Modbus TCP Server connections: The CPU can serve data back to 32 Modbus TCP Client devices concurrently. If 32 Modbus TCP Client devices are connected to the CPU, then any new TCP connection requests will be denied until one of the existing 32 devices drops its connection. If the Client device connecting to the CPU is not a Productivity3000® device, then a Modbus address must be assigned to the tag that is being requested. This is done in the Tag Database window. If the device connecting to the CPU is another P3000 CPU or C-more panel, no Modbus address is required. See Communications Port Configuration for port configuration, *Communications: Connectivity* section for connection information and *Communications: Ethernet* section for Ethernet set up.


- c. **Remote I/O:** The Remote I/O port is 10/100Base-T Ethernet with an RJ-45 style connector. It is used for connecting to a Remote I/O network consisting of P3-RS or P3-RX Remote Slaves and/or GS-EDRV100 units with GS-drives.

Remote Slaves: The P3-550(E) and P3-550E CPUs can connect with up to 16 P3-RS/RX Remote Slaves. The P3-550(E)/E will auto detect all P3-RS/RX units that are configured with unique station addresses (by means of two rotary switches on the front of the module). The configuration can be managed in the Hardware Configuration in the Productivity Suite Programming Software. See Communications Remote I/O and GS Drives for configuration information and *Communications: Connectivity* section for connection information.

Modbus TCP Client (RX-WX)




Remote I/O Slaves



Remote GS1 (GS-EDRV100)

GS Drive Devices: The P3-550(E) CPU can connect to up to 32 GS-EDRV100 Modules. The P3-550(E) will auto detect all GS-EDRV100 modules that have a unique address (configured by the bank of dipswitches on the module). The configuration can be managed in the Hardware Configuration in the Productivity Suite programming software. See *Communications: Remote I/O and GS Drives* section for configuration information and *Communications: Connectivity* section for connection information.



- d. USB OUT: The USB OUT data port is the upper port of two USB 2.0 Type A connectors on the CPU. The USB OUT port uses a SDCZ4-2048-A10 Pen Drive (may work with other pen drives) for data logging only in the P3-530 or for data logging and project transfers in the P3-550(E).




NOTE: The USB OUT port is NOT compatible with older 1.0/1.1 full speed USB devices.

USB Removable Storage Drive



OR



Project Transfer (P3-550(E) only): For security, this feature is disabled by default when creating a new project. It can be enabled in the Hardware Configuration panel for the P3-550(E). Once enabled, projects may be transferred between a CPU and Removable Storage Device, or between a Removable Storage Device and PC. Files stored on the Removable Storage Device by a P3-550(E) or the Productivity Suite programming software are stored under a default name, so only one project may be handled at a time on a Removable Storage Device. Existing projects on the Removable Storage Device will be overwritten without a prompt.

Data Logging: The Data Logger tool allows setup of periodic or event-based data logging of tag and System Errors to the Removable Storage Drive. Data Logger setup is accessed under the Monitor & Debug Menu. See *Communications: Connectivity* section for more information.

P3-EX Expansion Network

- e. EXP I/O OUT: The Expansion I/O port is the lower port of two USB 2.0 Type A connectors on the CPU. The EXP I/O Out port is only used for connections to local P3-EX modules in a Productivity3000® base with I/O. Expansion I/O is treated as local I/O by the CPU and is completely scan-synchronous. The I/O is automatically detected on power up.




CAUTION: This port is ONLY for Expansion I/O. The signal pins on this port are NOT standard USB. DO NOT USE A USB REPEATER TO EXTEND THE RANGE OF THIS PORT. See Communications Connectivity for more information.

- f. RS-232: The RS-232 port is an RJ-12 connector located on the right side of the CPU. This port can be used for:
- Modbus RTU Master connections.
 - Modbus RTU Slave connections.
 - ASCII Incoming and Outgoing communications.
 - Custom Protocol Incoming and Outgoing communications.


Modbus RTU Master connections: The RS-232 port is intended to be used for point-to-point connections but it is possible to connect up to 128 devices on a network if a RS-232 to RS-485/422 converter is connected to the port (such as a FA-ISOCON). This is accomplished by using the communications instructions in the ladder project (MRX, MWX, RX, WX). If 4-wire RS-485 or RS-422 communications is needed, using this port with an FA-ISOCON is the best method. See *Communications: Connectivity* section for more information.

RS-232 Modbus RTU Master Network Topology




RS-232 Modbus RTU Slave Network Topology

Modbus RTU Slave connections: The RS-232 port is intended to be used for point-to-point connections but it is possible for the RS-232 port to be used on a Modbus RTU network by using a RS-232 to RS-485/422 converter. The port is addressable in the Hardware Configuration in the Productivity Suite programming software. It is important to note that the RS-232 port cannot be a Modbus RTU master and slave concurrently. If the port is set to Modbus RTU and there are no communications instructions (MRX, MWX, RX, WX) in the project, the CPU will automatically respond to Modbus requests from a Modbus master. See *Communications: Connectivity* section for more information.




ASCII Incoming and Outgoing communications: The RS-232 port can be used for sending and receiving non-sequenced String data. This feature is typically used for receiving bar code strings from a scanner or sending statistical data to a terminal or serial printer using the ASCII IN and ASCII OUT instructions. See *Communications: Connectivity* section for more information.

RS-232 ASCII In Communication




RS-232 ASCII Out Communication



RS-232 Custom Protocol In and Out


Custom Protocol Incoming and Outgoing communications: The RS-232 port can be used for sending and receiving non-sequenced byte arrays to various devices. This function is typically used for communicating with devices that don't support the Modbus protocol but have another serial communications protocol. This is accomplished by using the Custom Protocol In and Custom Protocol Out instructions. The RS-232 port is intended to be used for point-to-point connections but it is possible for the RS-232 port to be used on a multi-node network by using a RS-232 to RS-485/422 converter. See *Communications: Connectivity* for more information.



- g. RS-485: The RS-485 port is a 3-pin removable terminal block. The RS-485 port can be used for:
- Modbus RTU Master connections.
 - Modbus RTU Slave connections.
 - ASCII Incoming and Outgoing communications.
 - Custom Protocol Incoming and Outgoing communications.


Modbus RTU Master connections: The RS-485 network port is used for multi-node networks. The CPU can connect to 128 Modbus RTU slave devices on a network. This is accomplished by using the communications instructions in the ladder project (MRX, MWX, RX, WX). See *Communications: Connectivity* section or more information.

RS-485 Modbus RTU Master Network Topology




RS-485 Modbus RTU Slave Network Topology

Modbus RTU Slave connections: The RS-485 network port is used for multi-node networks. The port is addressable in the Hardware Configuration in the Productivity Suite programming software. If the port is set to Modbus RTU and there are no communications instructions (MRX, MWX, RX, WX) in the project, the CPU will automatically respond to Modbus requests from a Modbus master. See Communications Connectivity for more information.




ASCII Incoming and Outgoing communications: The RS-485 port can be used for sending and receiving non-sequenced String data. If long distances are required between the ASCII device and the CPU, the RS-485 port is the better selection because of its increased distance support (1,000 meters). ASCII communications are typically used for receiving bar code strings from a scanner or sending statistical data to a terminal or serial printer using the ASCII IN and ASCII OUT instructions. See *Communications: Connectivity* section for more information.

RS-485 ASCII In Communication




RS-485 ASCII Out Communication



Custom Protocol Incoming and Outgoing communications: The RS-485 port can be used for sending and receiving non-sequenced byte arrays to various devices. This function is typically used for communicating with devices that don't support the Modbus protocol but have another serial communications protocol. If long distances are required between the device and the CPU, the RS-485 port is the better selection because of its increased distance support (1,000 meters). This feature is accomplished by using the Custom Protocol In and Custom Protocol Out instructions. See *Communications: Connectivity* section for more information.

RS-485 Custom Protocol In and Out





Communications: Connectivity

Communication Ports

The AutomationDirect P3000 CPUs are designed with several Communications Ports, seven communications ports on the P3-550, six on P3-550E, and five communications ports on the P3-530. The connectivity for each of these ports is described in the sections below. The Communication Ports available are:

- a. USB IN Port (P3-550 only): Programming port with a USB Type B female connector.




This port requires a USB Type A-B cable (such as the P3-EX-CBL6 cable).




The USB Port is the simplest method of connecting the Productivity Suite programming software to the P3-550 CPU. After the programming software has been installed, connect a USB A to B cable from the PC to the CPU. Once the software has been opened, click on CPU and select the “Choose CPU” option. The dialog shown below will appear.

Highlight the CPU listed in the dialog box and click on “Connect”. No configuration is required.



NOTE: The USB IN port is NOT compatible with older 1.0/1.1 full speed USB devices.

- b. Ethernet Port: Programming and Modbus TCP Client/Server port with 10/100 Base-T Ethernet RJ45 connector.



- **General Information:**


Crossover cables can be used to directly connect two endpoint Ethernet devices such as a PC network interface card and the CPU. Patch (or Straight-through) cables are used to connect an endpoint Ethernet device to an Ethernet switch.

The maximum distance for one cable or segment is 100 meters (328 feet). If the distance required between 2 devices is greater than 100 meters, add an Ethernet switch to extend the distance. An Ethernet switch can be added every 100 meters (or less) almost indefinitely. Each Ethernet switch added will incur some latency (actual amount differs between switches and manufacturers). So if a very long distance is needed between 2 Ethernet devices, it may be better to convert to fiber optics.


The External Ethernet Port can be used as a programming port, a Modbus TCP Client port, a Modbus TCP Server port, or to communicate to other P3000 CPUs. The External Ethernet Port can also be used to send emails using the EMAIL instruction.

- **Create a Connection:**


To communicate with the Productivity Suite programming software, connect a crossover Ethernet cable from the PC to the CPU External Ethernet Port or connect a patch (straight-through) Ethernet cable from the PC to an Ethernet switch and another patch cable from the Ethernet switch to the External Ethernet Port. Once the software has been opened, click on CPU and select the “Choose CPU” option. The dialog shown below will appear.



Highlight the CPU that you wish to connect to and press the “Connect” button. You may see CPUs that are not on the same subnet as your PC within the CPU Connections dialog box, but this does not mean you can connect to them. To connect to the CPU, you must configure either your PC or your CPU to be in the same subnet. You can easily change the Ethernet settings of the CPU by highlighting it and selecting the “Change CPU IP/Name” button (shown below). Or if you prefer, the PC Setup section of this chapter contains information on configuring the Ethernet settings of your PC.



- c. Remote I/O Ethernet Port (P3-550(E) only): P3-RS/RX Remote Slave and/or GS-EDRV100 Drive Ethernet RJ45 connector.



Crossover cables can be used to directly connect endpoint Ethernet devices and the CPU. For example, connecting a P3-RS or P3-RX Remote Slave Module to the P3-550(E) CPU. Patch (or Straight-through) cables are used to connect an endpoint Ethernet device to an Ethernet switch.

The maximum distance for one cable or segment is 100 meters (328 feet). If the distance required between 2 devices is greater than 100 meters, add an Ethernet switch to extend the distance. An Ethernet switch can be added every 100 meters (or less) almost indefinitely. Each Ethernet switch added will incur some latency (actual amount differs between switches and manufacturers). So if a very long distance is needed between 2 Ethernet devices, it may be better to convert to fiber optics.


The Remote I/O Ethernet Port is used to communicate to the Remote I/O Network, consisting of Remote Slave bases (P3-RS/RX modules) and GS Drives with a GS-EDRV100 Ethernet module. It is highly recommended that the network attached to this port be isolated from other networks and it is absolutely necessary that it be isolated from other Remote I/O networks. See Remote I/O and GS Drives topic for details.



NOTE: USB Project Transfers are NOT supported by the P3-530 CPU.

- d. USB OUT Port: USB Port for Data logging or project transfer with USB 2.0 Type A connector.

This Port serves two purposes: Data logging with the P3-530 or data logging and project transfers with the P3-550(E), require a SDCZ4-2048-A10 Removable Storage Device (may work with other pen drives).




Mating face of USB Type A female

| Pin# | Signal |
|------|--------|
| 1 | +5 |
| 2 | -Data |
| 3 | +Data |
| 4 | GND |



NOTE: The USB OUT port is NOT compatible with older 1.0/1.1 full speed USB devices.

Data logging is set up in the Productivity Suite Programming Software Data Logger configuration window. See Data Logger Memory section of the previous chapter for setup instructions.



Project Transfer to and from a USB drive can be accomplished several different ways:

- Transfer project to USB Drive from PC programming software.
- Transfer project from USB Drive to PC programming software.
- Transfer project from USB Drive to P3-550(E) CPU.
- Transfer project from P3-550(E) CPU to USB Drive.



NOTE: You must first select the "Enable project transfer to/from USB drive" checkbox in the P3-550(E) CPU Module Configuration.



NOTE: Before transferring a project to the CPU via USB pen drive, ensure that you are NOT connected with the programming software either by USB or Ethernet. If you attempt the transfer with the software connected via USB or Ethernet, a PACCON Error will appear on the LCD of the P3-550(E).

To transfer a project to or from a USB Drive from the PC programming software, insert the USB Drive into a USB Port on the PC. Go to File and Transfer Project and select To USB Drive or From USB Drive.


To transfer a project to or from a USB Drive on the P3-550(E) CPU, press Menu on the CPU display LCD and scroll down to the M8USB DRV option as seen on right.

Select ">SAVE->PEN" to load the project that is currently on the CPU down to the connected USB Drive.

Select ">LOAD->CPU" to load the project that is currently on the USB Drive to the CPU.



- e. Expansion I/O OUT Port: Expansion I/O Port with USB 2.0 Type A connector.



| Pin# | Signal |
|------|--------|
| 1 | +5 |
| 2 | -Data |
| 3 | +Data |
| 4 | GND |




CAUTION: The Expansion I/O Port is ONLY for connecting to other Productivity3000® I/O bases with a P3-EX module in the CPU slot. This port is not a standard USB A port. Note that in the diagram above, pin 1 is used for the System Reset signal and is not the typical +5VDC VBUS signal on most USB A ports. DO NOT USE EXTENDERS, CONVERTERS OR HUBS OF ANY SORT ON THIS PORT. A P3-EX-CBL6 cable ships with each P3-EX Module. It is not recommended to use any cable other than the one supplied.



After this connection is made, power cycle the system and the CPU will automatically detect the expansion I/O units. They can be used once the Hardware Configuration has been read into the programming software. Up to 4 expansion I/O bases may be added to a CPU.

- f. RS-232 Port: Serial RS-232 multipurpose communications port with RJ12 connector.



| Pin# | Signal |
|------|-------------------|
| 1 | GND Logic Ground |
| 2 | +5V 210mA Maximum |
| 3 | RXD RS-232 Input |
| 4 | TXD RS-232 Output |
| 5 | RTS RS-232 Output |
| 6 | GND Logic Ground |

The RS-232 Port can be connected to Modbus RTU master or slave devices, as well as devices that output non-sequenced ASCII strings or characters. The manner in which these devices are wired to the CPU depends whether the device is considered to be DTE (Data Terminal Equipment) or DCE (Data Communications Equipment).

If two DTE devices are connected together, the RX and TX signals should cross or the RX of one device should go to the TX of the other device and the TX of one device should go to the RX of the other device (as shown below).




The CPU is considered a DTE device. Most Modbus or ASCII devices being connected to the CPU will also be considered a DTE device and will need to swap TX and RX, but you should always consult the documentation of that device to verify. If a communication device, such as a Modem, is placed between the CPU and another Modbus or ASCII device it will most likely require connecting the signals straight across (TX to TX and RX to RX). Again, this can differ from manufacturer to manufacturer so always consult the documentation before wiring the devices together.

The RTS signal on pin 5 of the RS-232 Port will turn on when the TX signal is turned on and the RTS signal will turn off when the TX signal turns off. The amount of time that the RTS signal turns on before the TX signal turns on and the amount of time that the RTS signal waits before turning off after the TX signal turns off is adjustable in the P3-550(E) or P3-530 CPU Module Configuration for the RS-232 Port. The RTS signal is very often required for media converters, such as a RS-232 to RS-422/485 converter (much like the FA-ISOCAN).

The RTS signal is sometimes required for use with Radio modems as well (Key on and off control).

There is also +5VDC @ 210mA on pin 2 available for powering an external device such as the C-more Micro panel.


- g. RS-485 Port: Serial RS-485 multipurpose communications port with removable 3-pin connector.



The RS-485 Port is useful for connecting multiple Modbus and ASCII devices on one network and/or connecting devices to the CPU at distances greater than 50 feet (RS-232 limit). The RS-485 standard supports distances of up to 1000 meters without requiring a repeater. The RS-485 Port on the CPU can support up to 50 devices, depending on each device's load (this assumes a 19K Ohm load for each device). This number can be increased by placing an RS-485 repeater on the network, if necessary.

This port only supports RS-485 2-wire connections. For 4-wire RS-485 or RS-422, a converter, such as an FA-ISOCAN, should be used with the RS-232 Port.

A 120 Ohm resistor is required at each end of the network for termination.



DL06 CPU Port 2

Communications ASCII and Custom Protocol Functionality

Besides Modbus RTU, there are two additional functions supported on the serial ports in the Productivity3000® system.



- The first function is the ability to send and receive text-based data with devices such as bar code readers and serial printers.
- The second function is the ability to communicate serially with other devices that do not support the Modbus protocol and lack a Productivity3000 driver.

ASCII Instructions

The ASCII In/Out instructions use the String data type to send or receive text-based data through the serial port. The String data type is only intended for use with the “printable character set”. This can include numbers, letters or special characters.

With the ASCII In instruction, the CPU can receive a fixed length of characters or a variable length of characters with a termination code (an ‘end of message’ character).

The ASCII Out instruction sends text-based data out of the serial port to various devices for control, printing or display.



Full duplex Mode (P3-550(E)/530)

1. RS232 can be set to FullDuplex mode. Half Duplex is selected by default. This can be changed in the Hardware Configuration window for the CPU serial port.
2. AIN and AOUT instructions may be enabled at the same time.
3. AOUT may be enabled while AIN is already active, and vice versa.
4. The user may control treatment of buffered data before AIN is enabled using the checkbox mentioned above.
5. RTS mode must be either always on or always off. Assert during transmit is not available.

Half duplex Mode [default] (P3-550(E)/530)

The ASCII instruction limitations are that it is not advisable to use the ASCII Out instruction to send a String to a device that will respond (if the response is needed) and to use the ASCII IN (AIN) instruction to try to receive this data.

1. AIN and AOUT cannot be enabled at the same time on the same serial port.
2. When the AOUT completes, the AIN cannot be enabled until the next logic scan.
3. The user may control treatment of buffered data before AIN is enabled using the checkbox mentioned above.

Custom Protocol Instructions


The Custom Protocol is a HEX based protocol used to communicate with devices that do not have the standard Modbus RTU Protocol. There are two instructions used with Custom Protocol communication:

- Custom Protocol Out (CPO)
- Custom Protocol In (CPI)

Custom Protocol Out

The Custom Protocol Out instruction allows the user to send a 'byte formatted' packet of data out of the CPU serial port.

Constant values and/or Tag values can be used as the source for data transmitted. There are several formatting options including Byte Swap and Checksum.



The Checksum option allows the user to select where in the packet the checksum should be inserted, what type of Checksum (CRC-8 bit, CRC-16 bit, CRC-32 bit, XOR-8 bit, XOR-16 bit and XOR 32 bit), which bytes of the data source should be used in the calculation of the checksum, what the byte order should be of the checksum (if greater than 8 bit) and how to preload the checksum calculation.

If the device requires a different Checksum calculation, this can be done outside of the instruction in other ladder code and the resulting Tag values can be inserted where appropriate in the packet.

Termination characters can also be specified when needed.


The Custom Protocol Out instruction is for transmission only. If information needs to be received from field devices, the Custom Protocol In instruction will have to be used. Unlike ASCII, the Custom Protocol will buffer the received data. When the Custom Protocol In instruction is executed, it will retrieve any data held in this buffer. Therefore, the lost responses found with ASCII communication do not occur with Custom Protocol communication.

Custom Protocol In

The Custom Protocol In instruction has similar formatting options to the Custom Protocol Out instruction.

The Custom Protocol In instruction will calculate the Checksum of the data packet received based on the criteria specified in the instruction and this will determine the state of the status bits assigned to the instruction. If the Checksum calculation passes based on the criteria specified in the instruction, the “Success” status bit will become true. If the Checksum calculation fails, the “Checksum Error” status bit will become true.

With the CPI instruction, the packet termination must be specified, either in terms of a termination character(s) or a packet length. If a Checksum is expected in the reply, be sure to include this in the Fixed Length value specified.



Communications: Ethernet

TCP and UDP Port Numbers

When doing TCP/IP and UDP/IP communications, there is a Source Port number and Destination Port number for every message. The Client device must be aware of the Destination Port Number(s) that the Server device is expecting to see and the Server device must listen for this Destination Port number. After the Server device has received the message with the Destination Port Number that it is listening on, it will formulate the return message (if the applications require this) with the Source Port Number from the message sent as its Destination Port Number.

It is important to understand a little about the Port numbering concept because many Ethernet devices, such as routers with firewalls, will block messages with Destination Port numbers that are not configured for that device. Listed below are the default Port Numbers used in the Productivity3000® system. Some of these are configurable, allowing more flexibility when going through routers in many applications.

| Port | Port Number (Decimal Format) | TCP or UDP | Configurable |
|--|------------------------------|------------|--------------|
| Programming Software CPU Discovery | 8888 | UDP | No |
| Programming Software Connection and Project Transfer | 9999 | UDP | No |
| Modbus Client Connections (MRX, MWX, RX and WX instructions) | 502 | TCP | Yes |
| Modbus Server Connections | 502 | TCP | Yes |
| GS-Drive Discovery | 28784 | UDP | No |
| GS-Drive Connection | 502 | TCP | No |
| Remote I/O Discovery | 8887 | UDP | No |
| Remote I/O Connection | 8877 | UDP | No |
| Email Instruction | 25 | TCP | No |
| Ethernet IP | 44818 | TCP | Yes |
| Ethernet IP | 2222 | UDP | No* |

* Adapters may choose to respond using another port number.

IP Addressing and Subnetting


IP Addresses (used in conjunction with the Subnet Mask and Default Gateway address) are used for network routing. This allows for easy and logical separation of networks.

It is outside of the scope of this help file to explain how IP Addresses and Subnet masks are configured for actual usage. There are many books, documents and tools (Subnet calculators) on the internet that provide this information. Each facility and network will incorporate their own rules and guidelines for how their networks are to be configured.

PC Setup

For testing and verification purpose, it is recommended that the PC and the CPU be on an isolated Ethernet switch. Configure the PC's network interface card setting as described below.


1. Go to Start, then Run, type ncpa.cpl in the Open field and click on OK to bring up the Network Connections dialog.




NOTE: Many system settings on your computer require Administrative privileges. Consult with your IT department for necessary privileges and approvals.

NOTE: You should record initial settings prior to making any network configuration changes.

2. Network Connections
 - a. Right click on the Network interface shown in the Network Connections dialog and select Properties. If there is more than one Network Interface on the PC, be sure to choose the one connected to the Ethernet Switch with the CPU on it.
 - b. From the Local Area Connection Properties window, highlight the Internet Protocol(TCP/IP) selection and click on Properties.




3. Internet Protocol (TCP/IP) Properties.
 - a. In the Properties window, select Use the following IP address.
 - b. Enter an IP Address of 192.168.1.1 and Subnet Mask 255.255.255.0 and select OK. Select OK again on the Local Area Connection Properties window.




CPU Setup

Now configure the CPU's network IP setting as shown below.

1. Select CPU from the Productivity3000® software Main Menu and then select Choose CPU from the drop down menu.
2. The CPU Connections window will open as shown below.



- a. Click to highlight the CPU connected to the Ethernet switch.
 - b. Select the “Change CPU IP/Name” button.
3. The Change IP Address/CPU Name window will open as shown below.
 - a. Enter an IP Address of 192.168.1.2 and Subnet Mask 255.255.0.0 for the CPU’s network IP setting and select OK.



The CPU is now configured with the correct IP Address for connectivity with the PC. The IP Address and Subnet Mask settings will very likely differ from what will be used in the actual application. Consult the Network Administrator of the facility where the CPU will be installed to get the appropriate settings for that network.

TCP Connection Behavior with Modbus TCP and Network Instructions

When performing communications over TCP, a Connection must be established before the applications can transfer data. The connection is typically maintained until the application decides that the connection is no longer needed and then the connection will be severed. Frequent connects and disconnects are not efficient for the Client or the Server and can add unnecessary network traffic. But maintaining connections needlessly is also costly to the Client and Server in terms of processing and memory so this should also be avoided.

The CPU allows user control of Client connections through enabling and disabling the rungs containing Modbus and Network instructions. The MRX, MWX, RX and WX instructions have two options for sending messages: Automatic Poll and Manual Poll.

Automatic Poll sends out messages at a specified rate. Enabling the instruction performs a TCP connect with the Server device. Once the connection is established, the instruction messages are sent at the rate entered in the poll rate field. This continues until the instruction is disabled. The TCP connection will automatically be severed five seconds after the instruction is disabled.

Manual Poll sends out a message each time the instruction is enabled. Enabling the instruction performs a TCP connect with the Server device and sends the message one time. The TCP connection will automatically be severed five seconds after receiving the reply from the Server device. If the instruction gets another positive edge enable within the five seconds, the message will be sent and the disconnect of the TCP connection will be delayed by an additional five seconds.

Communications Modbus Functionality

Master/Client Function Code and Data Type Support

The following table lists the Modbus data type, the function code and the CPU source data type that is supported when the CPU is the Client or Master on a Modbus TCP or serial connection.

| Modbus Client/Master Support (Using MRX and MWX Instructions) | | | | |
|---|------------------------|------------------------------------|-----------------------|--|
| Function Code | Function Name | Modbus 984 Addressing (Zero Based) | Modbus 984 Addressing | Productivity3000® Tag Types (Data designation or source) |
| 01 | Read Coil Status | 000000 - 065535 | 000001 - 065536 | Discrete Output (DO) |
| | | | | Boolean (C) |
| | | | | Boolean System (SBRW) |
| 02 | Read Coil Status | 100000 - 165535 | 100001 - 165536 | Discrete Input (DI) |
| | | | | Boolean (C) |
| | | | | Boolean System (SBRW) |
| 03 | Read Holding Registers | 400000 - 465535 | 400001 - 465536 | Integer 8 bit Unsigned (U8) |
| | | | | Integer 16 bit (S16) |
| | | | | Integer 16 bit Unsigned (U16) |
| | | | | Integer 16 bit BCD (B16) |
| | | | | Integer 32 bit (S32) |
| | | | | Integer 32 bit BCD (B32) |
| | | | | Integer 32 bit Float (F32) |
| | | | | Integer 16 bit System (SWRW) |
| 04 | Read Input Registers | 300000 - 365535 | 300001 -365536 | Integer 8 bit Unsigned (U8) |
| | | | | Integer 16 bit (S16) |
| | | | | Integer 16 bit Unsigned (U16) |
| | | | | Integer 16 bit BCD (B16) |
| | | | | Integer 32 bit (S32) |
| | | | | Integer 32 bit BCD (B32) |
| | | | | Integer 32 bit Float (F32) |
| | | | | Integer 16 bit System (SWRW) |
| 05 | Write Single Coil | 000000 - 065535 | 000001 - 065536 | Discrete Input (DI) |
| | | | | Discrete Output (DO) |
| | | | | Boolean (C) |
| | | | | Boolean System (SBRW) |
| | | | | Boolean System Read Only (SBR) |

| Modbus Client/Master Support (Using MRX and MWX Instructions) (continued) | | | | |
|---|--------------------------|------------------------------------|-----------------------|--|
| Function Code | Function Name | Modbus 984 Addressing (Zero Based) | Modbus 984 Addressing | Productivity3000® Tag Types (Data designation or source) |
| 06 | Write Single Register | 400000 - 465535 | 400001 - 465536 | Integer 8 bit Unsigned (U8) |
| | | | | Integer 16 bit (S16) |
| | | | | Integer 16 bit Unsigned (U16) |
| | | | | Integer 16 bit BCD (B16) |
| | | | | Integer 32 bit (S32) |
| | | | | Integer 32 bit BCD (B32) |
| | | | | Integer 32 bit Float (F32) |
| | | | | Integer 16 bit System (SWRW) |
| 15 | Write Multiple Coils | 000000 - 065535 | 000001 - 065536 | Discrete Input (DI) |
| | | | | Discrete Output (DO) |
| | | | | Boolean (C) |
| | | | | Boolean System (SBRW) |
| | | | | Boolean System Read Only (SBR) |
| 16 | Write Multiple Registers | 400000 - 465535 | 400001 - 465536 | Integer 8 bit Unsigned (U8) |
| | | | | Integer 16 bit (S16) |
| | | | | Integer 16 bit Unsigned (U16) |
| | | | | Integer 16 bit BCD (B16) |
| | | | | Integer 32 bit (S32) |
| | | | | Integer 32 bit BCD (B32) |
| | | | | Integer 32 bit Float (F32) |
| | | | | Integer 16 bit System (SWRW) |
| Integer 16 bit System Read Only (SWR) | | | | |

Slave/Server Function Code and Data Type Support

The following table lists the Modbus data type, the function code and the CPU source data type that is supported when the CPU is the Server or Slave on a Modbus TCP or serial connection.

| Modbus Server/Slave Support | | | |
|-----------------------------|------------------------|-----------------------|---|
| Function Code | Function Name | Modbus 984 Addressing | Productivity3000® Tag Types (Data designation or source) |
| 01 | Read Coil Status | 000001 - 065536 | Discrete Output (DO) |
| | | | Boolean (C) |
| | | | Boolean System (SBRW) |
| 02 | Read Coil Status | 100001 - 165536 | Discrete Input (DI) |
| | | | Boolean System Read Only (SBR) |
| 03 | Read Holding Registers | 400001 - 465536 | Integer 8 bit Unsigned (U8) |
| | | | Integer 16 bit (S16) |
| | | | Integer 16 bit Unsigned (U16) |
| | | | Integer 16 bit BCD (B16) |
| | | | Integer 32 bit (S32) |
| | | | Integer 32 bit BCD (B32) |
| | | | Integer 32 bit Float (F32) |
| | | | Integer 16 bit System (SWRW) |
| 04 | Read Input Registers | 300001 -365536 | Analog Input, Integer 32 bit (AIS32) |
| | | | Analog Input, Float 32 bit (AIF32) |
| | | | Integer 16 bit System Read Only (SWR) |
| 05 | Write Single Coil | 000001 - 065536 | Discrete Output (DO) |
| | | | Boolean (C) |
| | | | Boolean System (SBRW) |
| 06 | Write Single Register | 400001 - 465536 | Integer 8 bit Unsigned (U8) |
| | | | Integer 16 bit (S16) |
| | | | Integer 16 bit Unsigned (U16) |
| | | | Integer 16 bit BCD (B16) |
| | | | Integer 32 bit (S32) |
| | | | Integer 32 bit BCD (B32) |
| | | | Integer 32 bit Float (F32) |
| | | | Integer 16 bit System (SWRW) |
| 15 | Write Multiple Coils | 000001 - 065536 | Discrete Output (DO) |
| | | | Boolean (C) |
| | | | Boolean System (SBRW) |

| Modbus Server/Slave Support (continued) | | | |
|---|--------------------------|-----------------------|--|
| Function Code | Function Name | Modbus 984 Addressing | Productivity3000® Tag Types (Data designation or source) |
| 16 | Write Multiple Registers | 400001 - 465536 | Integer 8 bit Unsigned (U8) |
| | | | Integer 16 bit (S16) |
| | | | Integer 16 bit Unsigned (U16) |
| | | | Integer 16 bit BCD (B16) |
| | | | Integer 32 bit (S32) |
| | | | Integer 32 bit BCD (B32) |
| | | | Integer 32 bit Float (F32) |
| | | | Integer 16 bit System (SWRW) |
| | | | Integer 16 bit System Read Only (SBR) |
| String | | | |

Assigning Modbus Addresses to Tags

There are many different data types in the CPU. Because of this, the Modbus addresses need to be mapped to the various tag data types in the CPU.


There are two ways to map Modbus addresses to Tags in the Programming software:

- Modbus mapping in Tag Database window.
- Modbus mapping when creating Tags.

1. Modbus mapping in Tag Database window:

There are only two data sizes in the Modbus protocol: bits and words. In the CPU, there are multiple size types, so it is sometimes necessary to map multiple Modbus addresses to a single Tag entity. There are also array data structures in the CPU. When Modbus addresses are mapped to arrays, they will be mapped as a contiguous block of addresses. This is, in fact, the most efficient method to handle Modbus communications.

In the Tag Database window, there are two columns named “Mod Start” and “Mod End”. To map a Modbus address to a tag in the Tag Database window, simply double-click in the Mod Start field for the Tag.



When you do this, you will see two values appear in the field. The left most value is the Modbus data type. This is fixed based upon the tag data type. The chart below indicates the four different Modbus data types in the 984 addressing scheme.

| Mod Start | Mod End | For |
|-----------|---------|-----|
| 100001 | 100001 | |
| 100003 | 100003 | |
| 100002 | 100002 | |
| 000001 | 000001 | |
| 000002 | 000002 | |
| 000003 | 000003 | |
| 000004 | 000004 | |


| Address Identifier | Modbus 984 Address Type |
|--------------------|---|
| 0xxxxx | Coil (Read/Write bit) |
| 1xxxxx | Input (Read Only bit) |
| 3xxxxx | Input Register (Read Only 16 bit word) |
| 4xxxxx | Holding Register (Read/Write 16 bit word) |

The right most value that you see in the “Mod Start” field is the address offset (range is from 1 – 65535). You can accept the value that is pre-filled for you or the value can be changed. The software automatically pre-fills the address offset with the next available address.


| Name | Type | Mod Start | Mod End |
|------------------|----------------------------|-----------|---------|
| MST-0.1.2.1 | Module Status Bit | 100004 | 100004 |
| MST-0.1.2.2 | Module Status Bit | 100005 | 100005 |
| MST-0.1.2.3 | Module Status Bit | 100006 | 100006 |
| MST-0.1.2.4 | Module Status Bit | 100007 | 100007 |
| MST-0.1.2.5 | Module Status Bit | 100008 | 100008 |
| MST-0.1.2.6 | Module Status Bit | 100009 | 100009 |
| MST-0.1.2.7 | Module Status Bit | 100010 | 100010 |
| MST-0.1.2.8 | Module Status Bit | 100011 | 100011 |
| PAC in Run | Boolean, System, Read Only | 100012 | 100012 |
| Always Off Bit | Boolean, System, Read Only | 100014 | 100014 |
| First Scan Bit | Boolean, System, Read Only | 100013 | 100013 |
| Every Other Scan | Boolean, System, Read Only | 100015 | 100015 |

2. Modbus mapping when creating Tags:

Modbus addresses can be assigned to Tags as they are created in the Tag Database.




Type in the Modbus offset value when entering the Tag Name and Data Type. If the address is already assigned, a warning message will appear.




Modbus Options

The Modbus protocol does not have a specific method outlined for data types outside of bits and 16-bit words. Most systems now have 32-bit data types. In order to transport 32-bit data types across Modbus, they must be placed into two Modbus 16-bit registers. Unfortunately, some devices do not support this and there are sometimes incompatibilities in the order of the 16-bit high word and low word handling between the devices.


In order to help alleviate this situation, there are some options for handling this in the programming software. To find the Modbus Address options, go to File and click on Project Properties and then click on the “Modbus Server Settings” tab.



- a. No exception response for non-existing Modbus address requests: Because the Modbus addresses can be manually assigned to tags, it is possible that gaps can occur in the Modbus address mapping. For example: Tag1 has Modbus address 400001 assigned to it and Tag 2 has Modbus address 400003 assigned to it.



Most Modbus Master/Client devices will attempt to optimize their data requests to a Modbus Slave/Server device by requesting blocks of data instead of individual registers. In the case mentioned previously, most Modbus masters would send one read request starting at 400001 and a size of three instead of sending two read requests starting at 400001 with a size of one and 400003 with a size of one as shown below.



In the example shown above on left, a Modbus Slave/Server device should give an exception response since there is no Modbus Address of 400002 in the device. This method can cause a lot of inefficiencies. By selecting the “No exception response for non-existing Modbus address requests” option, the CPU will not give an exception response to the request. Note that if Modbus address 400002 by itself were requested it would give an exception response.

- b. Word swap option (S-32, AIS-32, AOS-32, F-32, FI-32, FO-32):

Word swap allows the word order of 32-bit tags to be changed when sending the values across Modbus. The default selection is on, which returns the data low word first.

Tag1 (Integer, 32-Bit) = 305,419,896 (hex = 0x12345678)

Tag1 Modbus address = 400001, 400002

Modbus reply for Tag1 (Word Swap ON) = 01 03 04 56 78 12 34

| | |
|----------------------|----------------------|
| Low Word First | High Word Last |
|----------------------|----------------------|

Modbus reply for Tag1 (Word Swap OFF) = 01 03 04 12 34 56 78

| | |
|-----------------------|---------------------|
| High Word First | Low Word Last |
|-----------------------|---------------------|

- c. Map value to a single 16 bit Modbus register:

This option allows for compatibility with devices that do not support 32-bit Modbus functionality. This option can be selected individually for the Analog Input and Output Signed 32 data types and the Internal Signed 32 data types, including the array form of these data types. This function is only useful when the value contained in a 32-bit tag does not exceed a signed 15-bit value (32,765).

Tag1 (Integer, 32-Bit) = 22136 (hex = 0x00005678)

With “Map value to a single 16 bit Modbus register” turned OFF =

Tag1 Modbus address = 400001, 400002

Modbus reply for Tag1 (Word Swap ON) = 01 03 04 **56 78 00 00**

With “Map value to a single 16 bit Modbus register” turned ON =

Tag 1 Modbus address = 400001

Modbus reply for Tag1 = 01 03 02 **56 78**

- d. Map value to two consecutive 16-bit Modbus registers: Allows for 32-bit data types to be mapped to two consecutive 16-bit registers. This option is selected as default.

All of the options in the “Modbus Address” tab of the Project Properties only apply to the Modbus Slave/Server functionality. Similar options are available for the Modbus Master/Client functions as well and are available in the MRX and MWX Modbus instructions.

Modbus Instructions

To read or set data in other Modbus Slave/Server devices, there are two instructions available in the programming software, Modbus Read and Modbus Write.

- The Modbus Read (MRX) instruction is used to read data from other Modbus devices into Tags of the CPU.
- The MRX instruction can be used for Modbus TCP or Modbus RTU. There are several status bits that can be used to determine whether the read message was successful and if it was not, the reason why.

The screenshot shows the 'Modbus Read (MRX)' configuration window. It includes the following settings:

- Port Selection:**
 - Ethernet Port: CPU-ETH-Ext
 - IP Address: []
 - TCP Port Number: 502
 - Slave Node Number: 255 (Default=255)
 - Serial Port: CPU-232
 - Slave Node Number: 1 (Default=1)
- Status and Timing:**
 - In Progress: []
 - Complete: []
 - Success: []
 - Error: []
 - Timeout: []
 - Exception Response String: []
- Automatic Polling:**
 - Automatic Polling: every 100 msec, poll offset: 0 msec
 - Skip execution if buffer is greater than 75 % full
- Data Format:**
 - Word Swap
 - Map 32 bit data to 16 bit
 - Slave Modbus Starting Address: 0 + 000000
 - Modbus Decimal Addressing
 - Zero Based Modbus Addressing
- Modbus Function Code:** 1: Read Coils
- Tag Configuration:**
 - Non-Array: Number of Tags: 15
 - Tag Name Mapping table:

| Tag | Tag |
|-----|-----|
| 1 | |
| 2 | |
| 3 | |
| 4 | |
| 5 | |
 - Array: Array Name: [], Starting Index: 1, End Index: 1
 - String: String Name: [], Number of Characters: 2
 - Byte Swap (Even Number Only)
- Show instruction Comment
- Buttons: Monitor, OK, Cancel, Help

There is an “Automatic Polling” feature in the instruction to make it easier to read a device on a pre-determined poll rate. There is also a “poll offset” field that can be used when simultaneous instructions are enabled with the Automatic Polling feature to help stagger the flow of messages being sent to the network.

- The Modbus Write (MWX) instruction is very similar in layout and configuration to the MRX instruction. It is used to write values to a Modbus device from the tags in the CPU.


The screenshot shows the 'Modbus Write (MWX)' configuration window. It is divided into several sections:

- Port Selection:** Radio buttons for 'Ethernet Port' (selected) and 'Serial Port'. Ethernet Port is set to 'CPU-ETH-Ext' and Serial Port to 'CPU-232'.
- Addressing:** Fields for IP Address, TCP Port Number (502), Slave Node Number (255), and Exception Response String.
- Automatic Polling:** Checkboxes for 'Automatic Polling' (checked) and 'Skip execution if buffer is greater than' (checked). Values include 'every 100 msec' and 'poll offset: 0 msec'.
- Word Swap:** Checkboxes for 'Word Swap' (checked) and 'Map 32 bit data to 16 bit'.
- Slave Modbus Starting Address:** Set to '0 + 000000'.
- Addressing Mode:** Radio buttons for 'Modbus Decimal Addressing' (selected) and 'Zero Based Modbus Addressing'.
- Modbus Function Code:** Set to '0x Write Coil'.
- Non-Array:** Radio button selected. 'Number of Tags' is set to 15. A 'Tag Name Mapping' table is shown with 5 rows and 2 columns.
- Array:** Radio button unselected. Fields for 'Array Name', 'Starting Index' (1), and 'End Index' (1).
- String:** Radio button selected. Fields for 'String Name' and 'Number of Characters' (2).
- Byte Swap:** Checkboxes for 'Byte Swap'.
- Show Instruction Comment:** Checkboxes for 'Show Instruction Comment'.
- Buttons:** 'Monitor', 'OK', 'Cancel', and 'Help'.


- The MWX operates very similarly to the MRX instruction. There are also many status bits to indicate the success or reason of failure when sending a message.
- The Automatic Polling option is also available to the MWX instruction, although greater care should be taken when using this feature in this instruction. This is explained in better detail in the “Message Queue” section.

Network Instructions

The Network Read (RX) and Network Write (WX) instructions are used to communicate to other CPUs. They are very similar in operation to the MRX and MWX instructions but they target Tag Names instead of Modbus addresses in the other CPU. There is also a significant performance gain in using the RX and WX instructions when communicating to other CPUs as opposed to using the MRX and MWX instructions.



The same status bits are available in the RX instruction as in the MRX instruction and operate in the same manner. The greatest difference in the RX versus the MRX is that with the RX, the Tag Name in the target CPU can be referenced directly and does not need a corresponding Modbus address. The way this is accomplished is by mapping local and remote tag names together within the local CPU's RX instruction. Once the instruction is set up to read a remote project, the "Tags of Remote Project" or "Array Tags of Remote Project" drop down lists will be accessible. Map the Tag of the Remote project to a Tag in the Local project to read this data.



The WX instruction operates in the same manner except that the data from the Local tags will be written into the Tags of the remote project. No Modbus mapping is required.



NOTE: The PC programming software project for the Remote CPU must be accessible by the PC running the programming software for the Local project.


Automatic Poll versus Manual Polling and Interlocking

In many cases when performing multiple communications requests to other devices, the message flow must be explicitly controlled in ladder code so that a message is not sent while another one is in operation. This usually requires writing ‘interlocking’ code between the instructions which typically involves the use of timers and shift registers, etc. Sometimes this is necessary because of the application but in other cases where the CPU just wants to read changing values from other devices and the frequency of that update is not critical it would be much more efficient to skip the unnecessary code complexity of interlocking.


The desire to make it easier to communicate to other devices brought about the “Automatic Polling” feature and the “Message Queue” in the CPU. The Automatic Polling feature allows the user to choose the rate at which they desire to send messages without having to use a separate timer and enable logic. The ‘Message Queue’ allows the user to stage the messages from the ladder code to go out to each physical communications port without requiring interlocking logic.

The implementation of how the message queue works is slightly different based on whether the request is a read request or a write request.

Read Request Flowchart



Write Request Flowchart



Write requests will fill the queue much faster than read requests. That’s why it is advisable to carefully choose when doing write requests whether to use the “Automatic Poll” feature or to manually send write requests only when needed (data to write has changed). When designing a system, it is important to know the total time it takes to send a request and get a reply for each target device. The Poll time should be longer than this time. The longer the poll time can be, within tolerance of the application, the better the overall network performance. So for efficiency in programming and for the best possible performance for the system, conservative poll rates should be used when utilizing the “Automatic Poll” feature.

There is also a “Poll offset” field in the communications instructions. This helps prevent the instructions from being queued all at the same time. When the CPU project starts, there is a master timer that begins. The ladder scan will look to see if the instruction is enabled. If it is enabled, it will begin the Automatic Poll timer at the specified poll offset value from the master time clock.

Message Queue

If the application requires more explicit, orderly control of each message sent to the devices, turn off the “Automatic Poll” feature. Using the instruction’s status bits, logically control each message as required.

All of the above explains how messages get into the “queue”. There are several factors involved with how each queue (1 for each physical port) is emptied.

- Serial port queues: The serial port queues empty slower than the Ethernet port queues, not just because of the hardware speed itself but because of the nature of serial communications. Each request sent must wait for a response or a timeout (whichever comes first). Once the reply is received for a request or a timeout has occurred, the next item in the list can be sent. So the response time of the slave devices on the network will largely affect the speed at which the queue fills and empties.
- Ethernet port queues: The Ethernet port queue can empty faster because when sending requests to multiple devices, the CPU does not have to wait on a response from one device before sending a request to another device due to the inherent nature of the Ethernet hardware. However, sending multiple requests to the same Ethernet device does necessitate that the CPU waits for a response from the first request before sending another request to that same device.

Another difference in the Ethernet port queue versus the Serial port queue spawns from the TCP ‘connection’ based behavior of Modbus TCP. If a TCP connection is lost to a device and there are still requests in the queue for that device, those requests will be dropped from the queue. There are three ways this can happen:

1. If a TCP timeout occurs (server device fails to respond within specified timeout value), the TCP connection is lost.
2. If the server device closes the connection, then all of the requests will be dropped.
3. And, finally, if all rungs with communications instructions to a device are disabled for five seconds, the CPU will drop the TCP connection for that device in order to free up valuable resources that could be used elsewhere in the system.

This is another factor that should be considered when designing the system. If it is imperative that no message be lost when communicating to a device, each instruction should be explicitly handled one by one (interlocking logic).

EtherNet/IP for the Productivity Series

Terminology Definitions

A lot of terminology associated with EtherNet/IP is not always clear. Some of these terms are listed below along with their respective definitions.

- **Scanner:** This is the term used to describe the device that initiates the EtherNet/IP sessions. The Scanner is sometimes referred to as the “Originator” as well. In more standard Ethernet terms, the Scanner would often be called the “Client”.
- **Adapter:** This is the device that responds to the EtherNet/IP communications that are initiated by the Scanner. The Adapter is also known as the “Target” as well. Typically, the Adapter is an Ethernet “Server”.
- **Object:** In EtherNet/IP, an Object is a representation of a defined set of Ethernet connections, behaviors, services and data attributes. There are standard objects and there are custom defined objects as well. See Object Modeling example below.
- **Class:** A Class is a set of Objects that are related in some fashion. See Object Modeling example below.
- **Instance:** An Instance is an actual, usable manifestation of an Object. See Object Modeling example below.
- **Attributes:** Attributes are the specific items within an Object Class. The category of Attributes should be the same for all Instances of an Object but the actual Attribute itself might vary. See Object Modeling example below.
- **Connection Point:** A Connection Point value is the “Class Code” reference for a data block. This value is required for access to input and output data in IO Messaging. It is typically defined for each input and output data block by the Adapter device manufacturer.
- **IO Messaging:** IO Messaging (also called “Implicit Messaging”) is a method of reading and writing blocks of data without defining the Connection Point and size for each block transfer. The Connection Point, size and transfer rate (RPI) are defined at the beginning and then the data blocks are transferred at the specified intervals.
- **Explicit Messaging:** This method of reading or writing data requires that each message defines the type of data and size of data needed for each request.

Object Modeling Example:


Class ----- Definition of Automobile

Attributes -- Make, Model, etc...

Object ----- A Ford Mustang

Instance ----Sally’s Ford Mustang

Network Layer Chart



The diagram above illustrates the OSI seven layer model and how EtherNet/IP fits into this model. In general, there are three basic layers for sending and receiving data in the EtherNet/IP protocol:

- EtherNet/IP layer (Register Session, etc...)
- CIP layer (CIP Forward Open, etc...)
- The uppermost layer, which contains several different types of messaging.

The ODVA specification defines many different types of messaging that reside on the CIP layer. Two types of messaging supported in the phase 1 release of the Productivity3000® EtherNet/IP protocol are IO Messaging and Explicit Messaging. IO Messaging is accomplished through a Class 1 Connection and Explicit Messaging can be accomplished through a Class 3 Connection or an Unconnected Message.

Tag Based Messaging (used for reading and writing values to Allen Bradley Control and ComCPUtLogix PLCs) and PCCC (used for reading and writing values to Allen Bradley MicroLogix and SLC PLCs) are planned for subsequent phases of this protocol.

EtherNet/IP Data

When doing IO Messaging, the data that is transported is defined as “Input” data and “Output” data. Don’t confuse this type of data with what most PLCs define as Input data and Output data. In most PLCs, Inputs are typically associated with an Input module that reads point from real word devices. Outputs are typically associated with an Output module that turns off and on real word devices.

In IO Messaging, Input data is data that is sent from the target device back to the Originator or to multiple devices that are listening (multicast messages). Output data is data that is sent from the Target device. This data may or may not be connected to real word devices. That is completely dependent upon the Adapter device. For example: When the Productivity3000 is configured as an EtherNet/IP Adapter device, the Input data and Output data is defined in internal data arrays and does not directly tie to any Input and Output point to the real world. If it is desired to tie these array elements to real word devices, that must be accomplished in code by Copy commands (or other instructions).



NOTE: The Scanner (originator) in the P3000 will only accept messages from an Adapter (target) device that the Scanner has established a connection to.



NOTE: The Adapter (target) in the P3000 will respond back to a Scanner (originator) in the method (Multicast or Unicast) that is sent in the forward open message from the Scanner (originator).

Class 1 and Class 3 Connections

What are they and how are they best used?

- Class 1 Connection is the transport mechanism that IO Messaging uses to send data. The basic concept is that data is sent in one direction: the Originator sends Output data in a Unicast UDP message to the Target and the Target sends Input data in either a Unicast message back to the Originator or Multicast UDP messages to multiple devices. The Input data and Output data messages have no relationship to each other. This method works well for Remote I/O type data and is very efficient due to little overhead and reduced handshaking messages on the wire. Class 3 Connection is one of the mechanisms that Explicit messaging uses. Class 3 messaging uses TCP messages unlike Class 1. Each Class 3 request has a header that defines the type of data requested as well as the size requested. It allows for more flexibility in messaging but does create additional overhead.



NOTE: Explicit messaging can be accomplished with unconnected messages as well for more infrequent requests. Explicit messaging is a slower performing method of communications but it typically allows for more flexibility and control when the situation requires it.

When can the P3000 CPU use Class 1 or Class 3 Connections?



- Class 1 and Class 3 Connections can be accomplished with the Productivity3000® CPU as an Adapter or as a Scanner or both simultaneously.

How many connections can the P3000 support for Ethernet IP?

- 4 - TCP
- 4 - Ethernet IP
- 4 - CIP (Up to 4 CIP connections are allowed per Ethernet IP connection. Therefore, if one device can support 4 CIP connections then you can have up to a total of 16 CIP connections using 4 devices)

Example Setup: Productivity3000 as EtherNet/IP Adapter

The Adapter setup is accomplished through the EtherNet/IP Adapter setup under the Comm Adapter Config section of the Setup menu as seen on right.



When the EtherNet/IP Adapter is selected from the menu the window shown here will open.

Chapter 6: Communications

Fill in the required parameters and once configured these parameters will be used to configure the Scanner side as shown in the examples below. The first example shows how to setup a Class 1 IO Message connection from a 3rd party EtherNet/IP Scanner device (an Allen Bradley PLC).


The screenshot displays the 'Module Properties: LocalENB (ETHERNET-MODULE 1.1)' window. The 'Connection' tab is active, showing 'Type: ETHERNET-MODULE Generic Ethernet Module', 'Vendor: Allen-Bradley', and 'Parent: LocalENB'. The 'Name' is 'P3000_1'. The 'Connection Parameters' section includes 'Input: 101 (16-bit)', 'Output: 102 (16-bit)', and 'Configuration: 1'. Below this, the 'EtherNet/IP Adapter' window is open, showing 'Enable EtherNet/IP Adapter' checked, 'Number of Data Blocks (1 - 4)' set to 1, and 'Device Name' as 'P3KE/IP Adapter'. Under 'Data Block 1', 'Input Parameters' are configured with 'Datatype: Unsigned Int 16 ID Array', 'Data Array: InputDataBlock', 'Message Size (bytes): 100', and 'Number of Elements: 50'. The 'Output Parameters' are also configured with 'Datatype: Unsigned Int 16 ID Array', 'Data Array: OutputDataBlock', 'Message Size (bytes): 100', and 'Number of Elements: 50'. The 'Input Parameters' section shows 'Connection Point (I/O): 101 (0x65)', 'Class (Explicit): 4 (0x4)', 'Instance (Explicit): 101 (0x65)', and 'Attribute (Explicit): 3 (0x3)'. The 'Output Parameters' section shows 'Connection Point (I/O): 102 (0x66)', 'Class (Explicit): 4 (0x4)', 'Instance (Explicit): 102 (0x66)', and 'Attribute (Explicit): 3 (0x3)'. Colored arrows (red, green, blue, orange) connect the 'Input' and 'Output' fields in the 'Connection Parameters' window to the corresponding 'Connection Point (I/O)' fields in the 'Input Parameters' and 'Output Parameters' sections of the 'EtherNet/IP Adapter' window.

The following example shows how a Class 3 Explicit Message might be accomplished from a 3rd party device (Allen Bradley PLC). As you can see the Input Data must be retrieved in one connection or message and the output data in another. Remember that Class 3 messaging is not as efficient in protocol messaging as Class 1 but it does allow for granular control.




NOTE: In this example, size configuration is not shown on the Scanner side. The tag created for the Destination must be large enough to contain the data requested (shown with dashed boxes).

RS Logix5000 MSG instruction for Control/CompactLogix




Example Setup: Productivity3000® as EtherNet/IP Scanner

This example shows how to connect the Productivity3000 Scanner function to an EtherNet/IP adapter device using Class1 IO Messaging. First, create an EtherNet/IP device in the Hardware Configuration as seen below:





Configure the parameters to match the settings of the Adapter device. The image on right shows the setup of the Input data.

The size, in this case, is dynamic to the configuration of the device. For this particular example, we configured the device in a manner that allows it to publish 8 bytes of data for Input. Many devices will have a fixed configuration that should be published in the manufacturer's documentation.



The Output data must also be configured. Its data is also dynamic based upon the configuration. In our example, we configured the device in a manner that caused it to require 8 bytes of Output data.




| Box | Assembly Instance | Size |
|---------------|-----------------------------|---|
| Input | 1 (This value is required.) | The value will vary based on the number of [DL From Net xx] parameters used for your application (see details below). |
| Output | 2 (This value is required.) | The value will vary based on the number of [DL To Net xx] parameters used for your application (see details below). |
| Configuration | 6 (This value is required.) | 0 (This value is required.) |

The image on left shows the setup for the Configuration data. The Configuration data, for most devices, is a fixed size. Some devices will require that the Configuration data Connection Point be included in the Forward Open message (as shown on left) even if the size is 0. Some devices will require that the Configuration data Connection Point not be in the Forward Open and the checkbox option in the image below would need to be de-selected.

| Box | Assembly Instance | Size |
|---------------|-----------------------------|---|
| Input | 1 (This value is required.) | The value will vary based on the number of [DL From Net xx] parameters used for your application (see details below). |
| Output | 2 (This value is required.) | The value will vary based on the number of [DL To Net xx] parameters used for your application (see details below). |
| Configuration | 6 (This value is required.) | 0 (This value is required.) |

Chapter 6: Communications

The following example shows how to connect the Productivity3000® Scanner function to an EtherNet/IP adapter device using Class 3 Explicit Messaging. As with IO Messaging, an EtherNet/IP device must be created in the Hardware Configuration as seen below:



Explicit Messages can be performed in 2 ways: Unconnected or Connected (Class 3). The advantage of using Unconnected messaging is it allows more discrete control of each request. The disadvantage of Unconnected messaging is that Unconnected messages have a lower priority and will take longer to get serviced on some devices. Connected messages get serviced faster since there is a connection established to the device. If Connected messaging is desired, create an Explicit Message tab as shown in the image above. If Unconnected messaging is desired, do not create an Explicit Message tab. Only fill out the information in the upper portion of the EtherNet/IP Client Properties window.

Once the desired parameters have been entered, the device may now be referenced in the Explicit Message Instruction. If Unconnected messaging has been selected, choose the Unconnected MSG option in the Connection drop down box. If Connected messaging has been selected, choose the Explicit Message that was configured in the EtherNet/IP Client Properties window in the Connection drop down box. The rest of the settings should be matched to the specifications documented by the manufacturer. An example for requesting the Identity of a device is shown below. The data array configured for this function must be sufficient in size to hold the returned data from the device for this object. Data can also be written to the device if it supports an object for this purpose. If data is being written, enable the Output selection and specify the data array and size required by that device's object.

Identity Object

The screenshot shows the 'EtherNet/IP Explicit Message (EMSG)' configuration window. The main window has the following settings:

- Device Name: Conveyor1Drive
- Connection: EXP MSG 1
- Service: Generic
- Service ID: 19 (0x13)
- Class ID: 1 (0x1)
- Attribute ID: 2 (0x2)
- Instance ID: 2 (0x2)
- Enable Input:
- Message Size (bytes): 0
- Number Elements: 1

Callout boxes provide additional details:

- Services Table:**

| Service Code | Implemented for: | Service Name |
|--------------|------------------|----------------------|
| Class | Instance | |
| 0x05 | No | Reset |
| 0x0E | Yes | Get_Attribute_Single |
| 0x01 | Yes | Get_Attributes_All |
- Class Code Table:**

| Hexadecimal | Decimal |
|-------------|---------|
| 0x01 | 1 |
- Class Attributes Table:**

| Attribute ID | Access Rule | Name | Data Type | Description |
|--------------|-------------|--------------|-----------|---------------------------|
| 2 | Get | Max Instance | UINT | Total number of instances |
- Instances Table:**

| Instance | Description |
|----------|-----------------------------|
| 0 | Class |
| 1 | Host |
| 2...15 | Peripherals on Ports 1...14 |

Troubleshooting Tips:

- a. Use the diagnostic tags in the Hardware Configuration and Explicit Message Instruction: As explained previously in the Network Layer Chart section, there are multiple layers of messaging involved with EtherNet/IP. If it appears that the Productivity3000 is not communicating with another EtherNet/IP device, there are diagnostic tags available to narrow down which layer of the protocol is preventing successful communications.

1. At the TCP layer, there is a TCP Connected field that will expose the status of the TCP/IP connection when a tag is populated in this field.
 2. There is an Adapter Name field for a String tag and a Vendor ID field for an Integer tag. Both of these fields can help to identify whether the Productivity3000 is connected to the correct device or not.
 3. At the CIP layer, there is a Connection Online field for a Boolean tag.
 4. There are three additional fields to help determine why the CIP session might not be successful: General Status for an Integer tag, Extended Status for an Integer Data Array and Status Description for a String tag.
- b. Use the TCP connected tag:

Step 1 is to check the TCP Connected tag. If the connection has been enabled (by turning on the tag configured in the Enable field or triggering an Explicit Message instruction with an Unconnected MSG specified) and the TCP Connected tag is not true, check the following items:

- Cabling. Ensure that all of the cables are connected and in good shape. In most cases, the Ethernet port that the cable is connected to should indicate a Link Good LED. Ensure that any interim Ethernet switches are powered up and functioning and that the end device is powered up and functional.
- IP address and correct subnet. Check that the IP address entered into the IP Address field is the correct address for the device that you are connecting to. Also check that the EtherNet/IP device's IP address and subnet mask is compatible with the IP address and subnet mask of the Productivity3000. If there are any routers in between the two, ensure that a proper default gateway that matches the router's IP address is configured. If you are unfamiliar with proper IP addressing and subnet configuration, consult with the network administrator for guidance.
- TCP Port number. The default listening TCP port number for EtherNet/IP is 44818. Check that the target device is listening on this specific port number. If it is not, change the value in TCP Port Number field to the appropriate value. If there are interim router devices that are using port forwarding, ensure that the router is properly configured for this setup.



NOTE: Attempting to do IO Messaging across routers (different subnets) is unlikely to be successful. IO Messaging uses multicast messaging in many cases and the Port number is not necessarily fixed when the IO Messaging is established (the Forward Open message has the ability to 'negotiate' the port number used for the IO Messages).

- Adapter Name and Vendor ID. If the network contains many EtherNet/IP devices and these devices may not necessarily be connected to the Productivity3000, it may be a good safeguard to check the Adapter Name and Vendor ID returned and verify that these devices are the correct devices to connect to.
- c. Use the Connection Online and Error tags:
- If the TCP Connected tag is true and the Adapter Name and Vendor ID look correct, the next tags to look at are the Connection Online, the General Status, the Extended Status and the Status Description.

If the Enable tag is true and the Connection Online tag is not true, check the General Status value along with the Extended Status value(s) and the Status Description. If the General Status value and the Extended Status value(s) are part of the defined errors from the ODVA

specification, the Status Description should also return a more descriptive String. Once these errors are known, it may possible to very simply make the adjustment in the settings to correct the issue. If it is not obvious from the description, first check the manufacturer's documentation for corrective action in this particular scenario.

If the manufacturer's documentation doesn't give corrective action, check the EtherNet/IP Error Code List in this chapter for possible solutions.



NOTE: *This may not always solve the problem as each device manufacturer may publish the error for slightly different reasons.*

If the Connection Online tag is true and the data being received is different than what is expected, verify that the correct Connection Point values and/or Class, Instance, Attribute values are configured. There may be multiple areas of available data in that device. Verify that the correct data types are being used for both sides. If the data types are mismatched, this may make the data 'appear' to be incorrect.

Another great tool that can be used is Wireshark. Wireshark is a free network analyzer tool that can be downloaded from www.wireshark.net.



NOTE: *Using this tool implies some knowledge of how networking protocols function. Using Wireshark will also require that you have a true Ethernet hub (not an unmanaged switch) or a managed switch with Port mirroring capability.*

You may also use the following basic steps to check your Ethernet IP Setup.

Ethernet IP I/O Message Troubleshooting:

1. Does the IP Address set up in the Scanner match the Adapter IP Address?
2. Is the enable tag entered into the Scanner turned ON?
3. Does the connection point entered into the I/O Message Data Block match the connection point of the Adapter?
4. Does the number of elements match the Adapter?
5. Does the data type match the Adapter?

Steps 4 & 5 are important because the number of bytes being read from or written to the Adapter have to match the Adapter bytes allocated.

Ethernet IP Explicit Message Troubleshooting:

1. Does the IP Address set up in the Scanner match the Adapter IP Address?
2. Is the enable tag entered into the Scanner turned ON when not using the Unconnected MSG connection type?
3. Make sure the logic for the EtherNet/IP Explicit Message (EMSG) is TRUE so the instruction is enabled.
4. When using Get or Set single attributes in the Service field make sure the Instance ID matches the Instance ID of the Adapter.
5. When using Generic in the Service field make sure the Service ID, Class ID, Attribute ID and Instance ID match the Adapter settings.
6. Does the number of elements match the Adapter?
7. Does the data type match the Adapter?

Steps 6 & 7 are important because the number of bytes being read from or written to the Adapter have to match the Adapter bytes allocated.

ProNET

Productivity Network (ProNET) provides the ability to share data with other P-Series CPU's. This can easily be accomplished using the Productivity Network (PNET) setup in the Hardware Configuration window used to join a data sharing network consisting of other P-Series controllers.


Each member of the data sharing network receives data from all of the other P-Series controllers on that data sharing network. Each node can optionally send data to the other nodes of the data sharing network by electing to “publish” data.

The ProNET configuration uses UDP broadcast packets to publish the blocks of data to the network. One caveat with the use of broadcast packets is that it limits the scope of the shared data network to the local broadcast domain.

ProNET uses the verbs ‘publishing’ and ‘subscribing’ to describe how the controller data is exchanged with other P-Series controllers on the data sharing network.

Publishing is analogous to sending data, and is done only if ProNET is configured to ‘publish’ one or more of its assigned tags. If so configured, the P-Series controller will broadcast a packet that contains the data from the selected tags.

Subscribing is analogous to receiving data, and is accomplished by ‘subscribing to’ a publisher’s global ID of any P-Series CPU on the data sharing network set up to publish its data.



The ProNET configuration works with a 1D array tag(s) that can contain up to 65535 elements, however you are limited to 32 total 32-bit elements, 64 total 16-bit elements, or 128 total 8-bit or Boolean elements of data per publisher array data type. These tags provide the local storage for the data sent and received over the data-sharing network.



NOTE: The message size for each data type is limited to 128 bytes regardless of the defined array size.

| Data Type | Number of Elements |
|----------------|--------------------|
| Boolean | 128 |
| Integer 8-Bit | 128 |
| Integer 16-Bit | 64 |
| Integer 32-Bit | 32 |
| Integer 64-Bit | 32 |

When the input logic to the ProNET configuration is Enabled, it operates at a fixed rate of 10 times per second (100ms). The instruction will publish all of the elements of the array that it is configured to publish, and will process any ProNET nodes that it receives. When the input logic is OFF, (the device is disabled), it DOES NOT publish any of its tags and DOES NOT process any ProNET nodes that it receives.

Custom Protocol over Ethernet Functionality

Besides Modbus RTU, EtherNet/IP, and ProNET the Productivity1000 system has the ability to communicate via Ethernet with other devices using the Custom Protocol over Ethernet (CPoE).

Custom Protocol over Ethernet

The Custom Protocol is a HEX based protocol used to communicate with devices that do not support one of the other protocols on Productivity1000. There are two steps to initiate communications via the Custom Protocol over Ethernet:


First you must set up a device in the hardware configuration under the CPoE tab.

Then you must use the Custom Protocol Ethernet (CPE) instruction to initiate messages.

Hardware Configuration

First you must set up a device to talk to in the CPoE tab of the hardware configuration. This will require you to:

1. Enter a Device Name
2. Enter the IP Address of the device you wish to communicate with.
3. Enter the port number of the device.
4. Enter an Enable tag to enable the device if using TCP.



5. Choose whether you wish to Use the PLC as the master or the slave device via TCP connection
6. Choose whether you wish to use a UDP connection.
7. Enter tags for status of this device for troubleshooting (Example below shows the Structure method used).

Custom Protocol Ethernet Instruction

Next you must use the Custom Protocol Ethernet instruction in ladder.

1. The instruction can be chosen Receive or Send messages to the Custom Device.
2. The user can choose to use:
 - A table with tags that allow the user to send a specific data.
 - An array tag that is numerical can be used to Send/Receive from.
 - A string tag that contains an ASCII string to be sent or string location to receive characters to.


Communications: Remote I/O and GS-Drives

Things To Consider for the design of Remote I/O and GS-Drives

It is important to understand that only one Remote I/O network can be on an unmanaged switch. If two or more Remote I/O networks are mixed into the same physical LAN (local area network), duplicate IP addressing will occur and the system will not function properly. Multiple Remote I/O networks can be used on a managed switch using the VLAN feature to create a virtual separation of the different networks, but multicasting messages are necessary for the network to function properly. Care must be taken when designing a system this way (using a managed switch).

Even if only one Remote I/O network is being used in a facility, it is strongly recommended to keep it on a dedicated network, physically isolated from other networks. As mentioned above, the Productivity3000 Remote I/O network makes use of multi-casting messages and many devices will not function properly in this situation.

The GS Drive configuration does not use multicasting in its setup but there are some initial UDP broadcast messages that occur upon discovery when initiated from the software and at power up. This should be considered if installing the GS Drive network with other devices.




Configuration of Remote Slaves





NOTE: The P3-RS module is discontinued as of 6/20. Please use P3-RX as a replacement.

The Productivity3000® Remote I/O is very easy to configure. Each P3-RS or P3-RX Remote Slave module's address is set by rotary switches on the front of the module. The X1 switch is used to set the least significant digit and the X10 switch is used to set the most significant digit. So if the X10 switch were set to 2 and the X1 switch were set to 4, the Slave Address of that module would be 24. Valid addresses are 01-99. 00 is not valid. Each slave module must have a unique address and up to 16 slave units are allowed on a single system.



The address rotary switches are only read by the P3-RS/RX at power up. Power must be cycled after an address change for it to take effect. Connect a straight through (patch) Ethernet cable from the front of the P3-RS/RX module to an Ethernet switch. Connect a straight through cable from the P3-550(E) Local Ethernet (Remote I/O) port (lower Ethernet port) to the same switch. Open up the Productivity Suite Programming software and connect to the P3-550(E). Once the software is connected, open Hardware Configuration. Select the “Read Configuration” button in the upper left hand corner of this dialog and the P3-550(E) will automatically discover the slave modules connected to the switch and return all found P3-RS/RX modules and their configurations (bases and I/O modules).







There are two fields that can be configured in regards to connectivity to the slave modules (see the Local Ethernet Port Settings section of this chapter for a more detailed explanation of these settings). The above diagram shows the CPU hardware configuration popup where these settings can be found.

1. “Timeout between data query and response”: This is the time allowed (in 10 millisecond units) between when the CPU sends a message to the P3-RS/RX and when a response is required. If the CPU does not receive the response within the time specified, the outcome will depend on how the P3-RS/RX and its I/O modules are configured:



CAUTION: If a timeout occurs and a module within a P3-RS/RX base or expansion base connected to the P3-RS/RX has the “Automatic Module Verification” selection enabled, the CPU will go out of run mode and a critical error will be generated.



- If a timeout occurs but all of the modules within the P3-RS/RX base or expansion bases connected to the P3-RS/RX have the “No Verification and Enable Hot Swap” selection enabled and the P3-RS/RX module has the “Do not Detect if the Remote Base Group is Disconnected” selection enabled (see above), the CPU will remain in Run and a non-critical error will be generated.




CAUTION: If a timeout occurs and the P3-RS/RX module has the “Automatic Remote Base Group Detection” selection enabled, the CPU will go out of run mode and a critical error will be generated.

2. Comm Heartbeat Value: (previous page graphic) This value is used to help the P3-RS/RX determine that the P3-550(E) is no longer communicating to it. If the P3-RS/RX module does not receive a message from the P3-550(E) within the time frame specified in the “Comm Heartbeat Value” field in the P3-550(E) configuration window, the P3-RS/RX module will turn off all of its outputs.


Configuration of GS-Drive Connections

GS Drive connections are set up in a similar manner as the Remote Slaves. Set a unique address for each GS-EDRV100 using its DIP switches. Or set the DIP switches to 0 and select the address using NetEdit (free download at AutomationDirect.com). 01–64 are valid addresses for a GS-EDRV100 in a Productivity3000® system. Since the DIP switch settings can only represent 00–63, setting a GS-EDRV100 to address 64 must be done using NetEdit.




After the GS-EDRV100 modules' addresses have been set, be sure to connect the serial cable that comes with the GS-EDRV100 to the GS-Drive serial port. The GS-EDRV100 will automatically configure the GS-Drive serial port to the correct settings. Once the GS-EDRV100 is properly addressed and connected to the GS-Drive, connect a straight through (patch) Ethernet cable from the Ethernet port of the GS-EDRV100 to an Ethernet switch. Connect a straight through cable from the P3-550(E) Local Ethernet Port (Remote I/O) to the same switch.


Open the Productivity Suite Programming software and go online with the P3-550(E). Select Setup and then Hardware Configuration. Select the “Read Configuration” button in the upper left hand corner of this dialog and the P3-550(E) will automatically discover all of the GS-EDRV100s connected to the switch and display all found GS-Drives.




Once the drives have been discovered, the configuration of each drive can be read and written from the programming software.



To allow the P3-550(E) to automatically write the drive parameters on each CPU project transfer and when the CPU is powered up, a setting must be configured in the P3-550(E) project. Go to Tools and Options and select the “Project Transfer” tab. Select the “Transfer GS drive configuration” as shown below. Drive parameters are ONLY transferred to the GS Drive at project transfer or at boot up of the CPU.



To monitor the status of the connection between the P3-550(E) and the GS-EDRV100 modules, use the status bits of the GS Read and GS Write instructions as shown below. If a Timeout occurs or an error is received, this can be monitored in the ladder code and appropriate action can be taken.



The Communications Heartbeat function is configured differently for the GS Drives than the Remote Slaves. Primarily because, as mentioned previously, there are two possible communication paths that could be lost:

- P3-550(E) to GS-EDRV100.
- GS-EDRV100 to GS drive.


To configure the GS-EDRV100 and GS Drive to detect and react to loss of communications, three parameters should be configured appropriately in the drive.

As shown below, parameter P9.03 determines what the drive will do when it detects loss of communications. Parameter P9.04 enables the transmission loss detection feature. Parameter P9.05 determines the amount of time the drive will wait for a transmission before assuming that the link is lost and react according to how parameter P9.03 is configured.


The GS-EDRV100 reads these configured parameters and if they are configured for detecting communications loss, it will also monitor for loss of communications on the Ethernet side. If communications are lost on the Ethernet side, the GS-EDRV100 will shut down the GS Drive.

| Communications Parameters | | | |
|---------------------------|------------------------------|--|---------|
| GS2 Parameter | Description | Range | Default |
| P9.00 | Communication Address | 01 to 254 | 01 |
| P9.01 | Transmission Speed | 00: 4800 baud 01: 9600 baud 02: 19200 baud 03: 38400 baud | 01 |
| P9.02 | Communication Protocol | 00: Modbus ASCII mode 7 data bits, no parity, 2 stop bits 01: Modbus ASCII mode 7 data bits, even parity, 1 stop bit 02: Modbus ASCII mode 7 data bits, odd parity, 1 stop bit 03: Modbus RTU mode 0 data bits, no parity, 2 stop bits 04: Modbus RTU mode 8 data bits, even parity, 1 stop bit 05: Modbus RTU mode 8 data bits, odd parity, 1 stop bit | 00 |
| P9.03 | Transmission Fault Treatment | 00: Display fault and continue operating 01: Display fault and RAMP to stop 02: Display fault and COAST to stop 03: No fault displayed and continue operating | 00 |
| P9.04 | Time Out Detection | 00: Disable 01: Enable | 00 |
| P9.05 | Time Out Duration | 0.1 to 60.0 seconds | 0.5 |
| ◆ P9.07 | Parameter Lock | 00: All parameters can be set and read 01: All parameters are read only | 00 |

It is very important to note that if the communications loss feature is enabled; either a GS Drive Read or GS Drive Write instruction needs to be configured to communicate to the GS-EDRV100 and GS Drive at a poll rate that will prevent the GS-EDRV100 and GS Drive from detecting a loss of communication.





There is also a parameter (P22.01) that can be monitored to check the health of the serial connection between the GS-EDRV100 and the GS Drive. This parameter can be monitored in the ladder code and appropriate action taken if serial communications loss is detected.




Communications: Port Configuration

The Communications Port Configuration for any module containing comm ports is accessed from the Hardware Configuration window. For example, to access the P3-550(E) communications port configuration, first select



the Local Base Group from the Hardware Configuration window by double left-clicking the Local Base Group or by right-clicking the Local Base Group and selecting Open from the drop down menu as seen above.

Then select the P3-550(E) by double left-clicking the CPU or by right-clicking the CPU and selecting Open from the drop down list as seen above. This will display the P3-550(E) configuration window seen here.



Although the following descriptions will focus on the P3-550(E) communications ports, the settings also apply to any other module containing these ports (P3-530, P3-RS, P3-RX).

Ethernet Configuration

Ethernet Ports: There are two 10/100Base-T Ethernet ports on the P3-550(E) CPU.

- External Ethernet: The upper Ethernet port is referred to as the “External Ethernet Port”. This port can connect to Modbus TCP Client devices, Modbus TCP Server devices and PCs running the Productivity3000 programming software.

The External Ethernet Port is configured with an IP Address, Subnet Mask and Default Gateway, allowing it to function seamlessly on a typical LAN network.

- Local Ethernet: The lower Ethernet (Remote I/O)port is referred to as the “Local Ethernet Port”. This port functions as a Productivity3000 Remote I/O Client and also as a GS-Drive Client. The Local Ethernet Port is not configurable and each CPU Remote I/O network should be located on its own physical or logical network.



NOTE: Two CPU Remote I/O networks cannot co-exist on the same LAN.


External Ethernet Port Settings

- a. Port Name: Allows the entry of a unique Name for the External Ethernet Port. This Name is referenced in the Communications instructions (MRX, MWX, RX, WX) to select the Port to send the request from.
- b. Port Security Option: This Option can be used as a simple Security measure to prevent Modbus TCP write requests from being accepted by the CPU. To allow Reads and Writes, select Read/Write.
- c. TCP/IP Settings: The IP Setting of this Port may be changed in several ways:
 - The Settings may be entered manually in the Choose CPU tool in the Productivity Suite programming software. This allows the user to make changes to the IP to allow connection by the computer running the Productivity Suite programming software. Changes are sent using Multicast Messages.
 - The Settings can be saved as part of the project. This must be Enabled in the P3-550(E) Hardware Configuration Settings by selecting Use the Following (discussed on Item f below). If handled this way, the Settings stored in the project will take effect at Project Transfer and at boot up only. The Settings may be changed after boot up.
- d. Use Current Settings: When selected, Project Transfer or boot up will not make changes to the TCP/IP Settings of the CPU.
- e. Use DHCP: This specifies that the CPU should request its IP Settings from a DHCP Server on the network.



NOTE: If the CPU is set to use DHCP for it's IP Settings it cannot, in all likelihood, be used as a Modbus TCP Server.

- f. Use The Following: If this Option is selected, the CPU will set itself to the specified project Settings upon Project Transfer or at boot up.
- g. IP Address: This field is where the IP Address is specified in Four Octets.
For Example: 192.168.1.5
- h. Subnet Mask: This field is where the Subnet Mask is specified in Four Octets (i.e., 255.255.255.0). The Subnet Mask is used in conjunction with the IP Address to configure a Logical Network.
- i. Default Gateway: This field is where the Default Gateway Address is specified in Four Octets (i.e., 192.168.1.1). This is typically the IP Address of the router on the network. If a target IP Address is specified in an outgoing message from the CPU that is not in the Local Subnet, the Default Gateway Address is where this message will be sent.
- j. Timeout Between Data Query and Response: The Time period specified in this field is the Time between the queries sent from the CPU (via a Communication instruction, such as a MRX, MWX, RX or WX) and the Time a response from that device is received. If the Response takes longer to receive (or is not received) than the specified Time period, a Timeout Error will occur for the given instruction. Each instruction has a Timeout Status bit that can be assigned to it. See the diagram shown here.




- k. Modbus TCP Port: This is the listening TCP Port Number for Modbus TCP connections. If necessary, this value can be adjusted for advanced router access. In most situations, this Number should be left at 502.
- l. Comm Heartbeat Value: This feature allows the ladder logic in the CPU to know if a device has stopped communicating to the CPU. If a value is placed in this field, the CPU will start a timer between each communication packet coming in to the CPU. If a communication packet fails to be received by the CPU within the specified time period, the System Bit Ethernet Heartbeat Timeout Bit will become true.

Local Ethernet Port Settings


- m. Timeout Between Data Query and Response: The Time period specified in this field is the Time between the queries sent from the CPU (for Remote I/O Nodes and GS Drive Nodes) and the Time a Response from that device is Received. If the Response takes longer to receive (or is not received) than the specified Time period, a Timeout Error will occur for the given device and an Error will be generated in the Error Log. For P3-RS/RX Timeouts, the Error will be critical or non-critical, dependent on the Hot-Swap settings for that unit, its I/O Modules and P3-EX Bases. See Modbus Server diagram shown on previous page.
- n. Comm Heartbeat Value: This value specifies how long the Remote I/O Slaves should wait for a communication packet from the CPU. If a communication packet is not received from the CPU within the specified time period, all outputs on the Remote Slave will be turned OFF.

Remote Access Configuration



- a.. Web Server Function: Allows the ability to make a non secure web connection to the P3-550(E) in order to access the USB pen drive and view read-only system tags. When enabled, a port number selection is required.
 - Port: (Default 80) Allows user to set a port number ranging from 1-65535.
- b. Session Timeout: Allows the user to set a specific time limit (1-20 mins.) on inactivity that will close the Web Server connection. If there is no activity between the PC and the Web Server for the specified time limit, the connection will close.
- c. Mobile Function: Enables Remote Access which allows the CPU Data Remote Monitor App to monitor the selected tags.
- d. Password Option: Allows the user to set a password for access to the Web Server.
 - Enter an account name and password of up to a combination of 16 numbers and characters (can include special characters).

Serial Configuration




When the Serial Ports Tab is selected, the Serial Ports settings are displayed as shown below.

There are two Serial Ports on the P3-550(E) CPU. There is an RS-232 Port with an RJ-12 connector and a 2-wire RS-485 Port with a removable three point terminal block. Both Ports are capable of Modbus RTU Client (device that initiates communications requests) and Server (device that responds to communications requests) communications. They are also capable of ASCII outgoing strings and incoming strings.


RS-232 and RS-485 Port Settings

- Port Name: Allows the entry of a unique Name for the RS-232 and RS-485 Ports. This name is referenced inside of the Communications instructions (MRX, MWX, RX, WX) and ASCII instructions (AIN, AOUT, CPO, CPI) to select the Port to send or receive the request.
- Port Security: This Option can be used as a simple Security measure to prevent Modbus TCP write requests from being accepted by the CPU. To allow Reads and Writes, select Read/Write.
- Protocol: This field determines whether the Port is used for Modbus RTU communications, sending or receiving ASCII Strings or performing the Custom Protocol function.
- Baud Rate: Choose the Baud Rate that your device and the CPU should communicate in this field. The appropriate choice will vary greatly with device, application and environment. The important point is that all devices communicating on the network need to be set to the same Baud Rate. The available Baud Rates are 1200, 2400, 9600, 19200, 33600, 38400, 57600 and 115200 bps.


- e. Node Address: This field is used only when the CPU is a Modbus RTU Server device. This field is used to uniquely identify the CPU on the network. This setting is also sometimes referred to as a Station Address. This field can be set from 1 to 247.
- f. Parity: The Parity Bit is used as a simple, low-level form of Error Detection. All devices on the network need to be at the same Parity setting. The appropriate choice will vary with devices. Valid selections are None, Even and Odd.
- g. Data Bits: This field determines whether the communications packet uses Seven Data Bits or Eight Data Bits. Eight Data Bits is the only valid selection for Modbus RTU. Either Seven or Eight Data Bits can be selected when using ASCII communications. Set this field to match the device that is connected to the CPU.
- h. Stop Bits: This field determines whether the communications packet uses One or Two Stop Bits. Set this field to match the device that is connected to the CPU.
- i. Duplex Mode: In ASCII/Custom Protocol mode Half Duplex or Full Duplex can be chosen.
 - Half Duplex: When selected, the serial port can either transmit or receive, but not both at the same time.
 - Full Duplex: When selected, allows the serial port to transmit and receive simultaneously. (Only available in ASCII/Custom Protocol).
- j. RTS Mode: Set the RTS mode to control the Request to Send signal out of the Serial Port.
- k. RTS Off Delay Time (RS-232 Only): This Time period is the amount of Time between the end of the data transmission to when the RTS signal is turned off. The diagram illustrates this.




- l. RTS On Delay Time (RS-232 Only): This Time period is the amount of Time between when the RTS Signal is turned ON and the data transmission begins. The diagram illustrates this. This setting may be needed when using media converters (RS-232 to RS-485 converters) and/or radio modems. A delay may be needed after the assertion of the RTS Signal and when the data transmission begins for processing time in the device.





- m. Timeout Between Query and Response: The Time period specified in this field is the Time between the queries sent from the CPU (via a Communication instruction, such as an MRX, MWX, RX, or WX) and the Time a Response from that device is Received. If the Response takes longer to receive (or is not received) than the specified Time period, a Timeout Error will occur for the given instruction. Each instruction has a Timeout Status bit that can be assigned to it.



- n. Modbus Character Timeout: The Modbus Character Delay Time is specified as the Time between two bytes (or characters) within a given Modbus Message. The Modbus RTU specification states that this time must be no more than 1.5 Character Times (real time based on Baud Rate). Sometimes delays do occur between bytes when using radio modems, media converters, etc. This setting allows some tolerance in these situations for the incoming Modbus Messages in the CPU. The CPU will wait for the amount of time specified in this field before discarding the incomplete packet. If the CPU does not receive the remainder of the Message within the specified Time Frame, it will discard the first portion of the Message and wait for a new Message.



- o. Response/Request Delay (RS-485 Only): This setting is used when the CPU is a Modbus RTU Server or Client on the RS-485 Port.
- The total Response Time can be up to the Total CPU Scan Time + the Value specified in this field. When using 2-wire RS-485 communications, sometimes Echoes can occur since both devices use the same differential signal pair to send and receive.
- If acting as a Server (on left below), upon receiving a Modbus Request, the CPU will wait for the time period specified in this field before sending a Response. This can be used with slow clients that need extra time to change from sending to receiving.
 - If acting as a Client (on right below), after receiving a Modbus Response, the CPU will wait for the time period specified in this field before sending another Request. This can be used to delay request messages in order to give extra time for slow server devices.




- p. Comm Heartbeat Value: This feature allows the ladder logic in the CPU to know if a device has stopped communicating to the CPU. If a value is placed in this field, the CPU will start a timer between each communication packet coming in to the CPU. If a communication packet fails to be received by the CPU within the specified Time period, the System Bit RS-232 Heartbeat Timeout Bit or RS-485 Heartbeat Timeout Bit will become true.

Communications: Error Codes



NOTE: The only time you will see Communications Error Codes is when the CPU is the Master of a Communications Network.

To simplify the process of identifying a possible Error, the Productivity3000® CPU will automatically report to a specific memory location an Error Code that helps identify the existing issue. The Error Codes are reported in the Exception Response String Tag specified in the instruction as shown below.



The Exception Response String field is available on the following instructions:

- GS Drives Read
- GS Drives Write
- Modbus Read
- Modbus Write
- Network Read
- Network Write
- Dataworx Request

The Table shown below provides a list of Productivity3000 Communication Error Codes that may be reported by the Productivity CPU.

| Productivity3000 Communication Error Codes | | |
|--|--|---|
| Error Code | Description | Suggested Fix |
| 01 | Function Code not supported | Check instruction or connected device and correct Function code or address range selected. |
| 02 | Address out of range. This error is typically generated when a Modbus address has been requested that does not exist in the CPU. | Check instruction or connected device and correct Function code or address range selected. |
| 03 | Illegal Data Value. This error is typically generated when the Modbus request sent to the CPU is formed incorrectly. | Check the Modbus request against the Modbus protocol specification (www.modbus.org) to verify that it was formed correctly. |
| 04 | Device Failure | Check connected device |
| 06 | Slave Device is Busy. This error is typically due to excess communications to the EDRV. | Slow down the poll rate in the GS instruction. |

P3000 EtherNet/IP Error Codes



--- CPU server currently supported errors














--- CPU server (will not generate error)

Note: Other adapters may generate this error










| P3000 EtherNet/IP Error Codes | | | | |
|-------------------------------|-----------------------|---|--|-----------------|
| General Status Error | Extended Status Error | Name | Description | P3000 Supported |
| 0x01 | 0x0100 | Connection In Use/ Duplicate Forward Open | A connection is already established from the target device sending a Forward Open request or the target device has sent multiple forward open request. This could be caused by poor network traffic. Check the cabling, switches and connections. | |
| 0x01 | 0x0103 | Transport Class/ Trigger Combination not supported | The Transport class and trigger combination is not supported. The Productivity3000 CPU only supports Class 1 and Class 3 transports and triggers: Change of State and Cyclic. | |
| 0x01 | 0x0106 | Owner Conflict | An existing exclusive owner has already configured a connection to this Connection Point. Check to see if other Scanner devices are connected to this adapter or verify that Multicast is supported by adapter device if Multicast is selected for Forward Open. This could be caused by poor network traffic. Check the cabling, switches and connections. | |
| 0x01 | 0x0107 | Target Connection Not Found | This occurs if a device sends a Forward Close on a connection and the device can't find this connection. This could occur if one of these devices has powered down or if the connection timed out on a bad connection. This could be caused by poor network traffic. Check the cabling, switches and connections. | |
| 0x01 | 0x0108 | Invalid Network Connection Parameter | This error occurs when one of the parameters specified in the Forward Open message is not supported such as Connection Point, Connection type, Connection priority, redundant owner or exclusive owner. The Productivity3000 CPU does not return this error and will instead use errors 0x0120, 0x0121, 0x0122, 0x0123, 0x0124, 0x0125 or 0x0132 instead. | |
| 0x01 | 0x0109 | Invalid Connection Size | This error occurs when the target device doesn't support the requested connection size. Check the documentation of the manufacturer's device to verify the correct Connection size required by the device. Note that most devices specify this value in terms of bytes. The Productivity3000 CPU does not return this error and will instead use errors 0x0126, 0x0127 and 0x0128. | |
| 0x01 | 0x0110 | Target for Connection Not Configured | This error occurs when a message is received with a connection number that does not exist in the target device. This could occur if the target device has powered down or if the connection timed out. This could be caused by poor network traffic. Check the cabling, switches and connections. | |
| 0x01 | 0x0111 | RPI Not Supported | This error occurs if the Originator is specifying an RPI that is not supported. The Productivity3000 CPU will accept a minimum value of 10ms on a CIP Forward Open request. However, the CPU will produce at the specified rate up to the scan time of the installed project. The CPU cannot product any faster than the scan time of the running project. | |

Chapter 6: Communications

| P3000 EtherNet/IP Error Codes | | | | |
|-------------------------------|-----------------------|--|--|---|
| General Status Error | Extended Status Error | Name | Description | P3000 Supported |
| 0x01 | 0x0112 | RPI Value not acceptable | <p>This error can be returned if the Originator is specifying an RPI value that is not acceptable. There may be six additional values following the extended error code with the acceptable values. An array can be defined for this field in order to view the extended error code attributes. If the Target device supports extended status, the format of the values will be as shown below:</p> <ul style="list-style-type: none"> • Unsigned Integer 16, Value = 0x0112, Explanation: Extended Status code • Unsigned Integer 8, Value = variable, Explanation: Acceptable Originator to Target RPI type, values: 0 = The RPI specified in the forward open was acceptable (O -> T value is ignored), 1 = unspecified (use a different RPI), 2 = minimum acceptable RPI (too fast), 3 = maximum acceptable RPI (too slow), 4 = required RPI to corrected mismatch (data is already being consumed at a different RPI), 5 to 255 = reserved. • Unsigned Integer 32, Value = variable, Explanation: Value of O -> T RPI that is within the acceptable range for the application. • Unsigned Integer 32, Value = variable, Explanation: Value of T -> O RPI that is within the acceptable range for the application. |  |
| 0x01 | 0x0113 | Out of Connections | The Productivity3000 EtherNet/IP Adapter connection limit of 4 when doing Class 3 connections has been reached. An existing connection must be dropped in order for a new one to be generated. |  |
| 0x01 | 0x0114 | Vendor ID or Product Code Mismatch | The compatibility bit was set in the Forward Open message but the Vendor ID or Product Code did not match. |  |
| 0x01 | 0x0115 | Device Type Mismatch | The compatibility bit was set in the Forward Open message but the Device Type did not match. |  |
| 0x01 | 0x0116 | Revision Mismatch | The compatibility bit was set in the Forward Open message but the major and minor revision numbers were not a valid revision. |  |
| 0x01 | 0x0117 | Invalid Produced or Consumed Application Path | This error is returned from the Target device when the Connection Point parameters specified for the O -> T (Output) or T -> O (Input) connection is incorrect or not supported. The Productivity3000 CPU does not return this error and uses the following error codes instead: 0x012A, 0x012B or 0x012F. |  |
| 0x01 | 0x0118 | Invalid or Inconsistent Configuration Application Path | This error is returned from the Target device when the Connection Point parameter specified for the Configuration data is incorrect or not supported. The Productivity3000 CPU does not return this error and uses the following error codes instead: 0x0129 or 0x012F. |  |
| 0x01 | 0x0119 | Non-listen Only Connection Not Opened | This error code is returned when an Originator device attempts to establish a listen only connection and there is no non-listen only connection established. The Productivity3000 CPU does not support listen only connections as Scanner or Adapter. |  |

| P3000 EtherNet/IP Error Codes | | | | |
|-------------------------------|-----------------------|--|---|---|
| General Status Error | Extended Status Error | Name | Description | P3000 Supported |
| 0x01 | 0x011A | Target Object Out of Connections | The maximum number of connections supported by this instance of the object has been exceeded. |  |
| 0x01 | 0x011B | RPI is smaller than the Production Inhibit Time | The Target to Originator RPI is smaller than the Target to Originator Production Inhibit Time. Consult the manufacturer's documentation as to the minimum rate that data can be produced and adjust the RPI to greater than this value. |  |
| 0x01 | 0x011C | Transport Class Not Supported | The Transport Class requested in the Forward Open is not supported. Only Class 1 and Class 3 classes are supported in the Productivity3000 CPU. |  |
| 0x01 | 0x011D | Production Trigger Not Supported | The Production Trigger requested in the Forward Open is not supported. In Class 1, only Cyclic and Change of state are supported in the Productivity3000 CPU. In Class 3, Application object is supported. |  |
| 0x01 | 0x011E | Direction Not Supported | The Direction requested in the Forward Open is not supported. |  |
| 0x01 | 0x011F | Invalid Originator to Target Network Connection Fixed/ Variable Flag | The Originator to Target fixed/variable flag specified in the Forward Open is not supported. Only Fixed is supported in the Productivity3000 CPU. |  |
| 0x01 | 0x0120 | Invalid Target to Originator Network Connection Fixed/ Variable Flag | The Target to Originator fixed/variable flag specified in the Forward Open is not supported. Only Fixed is supported in the Productivity3000 CPU. |  |
| 0x01 | 0x0121 | Invalid Originator to Target Network Connection Priority | The Originator to Target Network Connection Priority specified in the Forward Open is not supported. Low, High, Scheduled and Urgent are supported in the Productivity3000 CPU. |  |
| 0x01 | 0x0122 | Invalid Target to Originator Network Connection Priority | The Target to Originator Network Connection Priority specified in the Forward Open is not supported. Low, High, Scheduled and Urgent are supported in the Productivity3000 CPU. |  |
| 0x01 | 0x0123 | Invalid Originator to Target Network Connection Type | The Originator to Target Network Connection Type specified in the Forward Open is not supported. Only Unicast is supported for O -> T (Output) data in the Productivity3000 CPU. |  |
| 0x01 | 0x0124 | Invalid Target to Originator Network Connection Type | The Target to Originator Network Connection Type specified in the Forward Open is not supported. Multicast and Unicast is supported in the Productivity3000 CPU. Some devices may not support one or the other so if this error is encountered try the other method. |  |
| 0x01 | 0x0125 | Invalid Originator to Target Network Connection Redundant_Owner | The Originator to Target Network Connection Redundant_Owner flag specified in the Forward Open is not supported. Only Exclusive owner connections are supported in the Productivity3000 CPU. |  |
| 0x01 | 0x0126 | Invalid Configuration Size | This error is returned when the Configuration data sent in the Forward Open does not match the size specified or is not supported by the Adapter. The Target device may return an additional Unsigned Integer 16 value that specifies the maximum size allowed for this data. An array can be defined for this field in order to view the extended error code attributes. |  |

Chapter 6: Communications

| P3000 EtherNet/IP Error Codes | | | | |
|-------------------------------|-----------------------|---|---|---|
| General Status Error | Extended Status Error | Name | Description | P3000 Supported |
| 0x01 | 0x0127 | Invalid Originator to Target Size | This error is returned when the Originator to Target (Output data) size specified in the Forward Open does not match what is in the Target. Consult the documentation of the Adapter device to verify the required size. Note that if the Run/Idle header is requested, it will add 4 additional bytes and must be accounted for in the Forward Open calculation. The Productivity3000 CPU always requires the Run/Idle header so if the option doesn't exist in the Scanner device, you must add an additional 4 bytes to the O -> T (Output) setup. Some devices may publish the size that they are looking for as an additional attribute (Unsigned Integer 16 value) of the Extended Error Code. An array can be defined for this field in order to view the extended error code attributes. NOTE: This error may also be generated when a Connection Point value that is invalid for IO Messaging (but valid for other cases such as Explicit Messaging) is specified, such as 0. Please verify if the Connection Point value is valid for IO Messaging in the target device. |  |
| 0x01 | 0x0128 | Invalid Target to Originator Size | This error is returned when the Target to Originator (Input data) size specified in the Forward Open does not match what is in Target. Consult the documentation of the Adapter device to verify the required size. Note that if the Run/Idle header is requested, it will add 4 additional bytes and must be accounted for in the Forward Open calculation. The Productivity3000 CPU does not support a Run/Idle header for the T -> O (Input) data. Some devices may publish the size that they are looking for as an additional attribute (Unsigned Integer 16 value) of the Extended Error Code. An array can be defined for this field in order to view the extended error code attributes. NOTE: This error may also be generated when a Connection Point value that is invalid for IO Messaging (but valid for other cases such as Explicit Messaging) is specified, such as 0. Please verify if the Connection Point value is valid for IO Messaging in the target device. |  |
| 0x01 | 0x0129 | Invalid Configuration Application Path | This error will be returned by the Productivity3000 CPU if a Configuration Connection with a size other than 0 is sent to the CPU. The Configuration Connection size must always be zero if it this path is present in the Forward Open message coming from the Scanner device. |  |
| 0x01 | 0x012A | Invalid Consuming Application Path | This error will be returned by the Productivity3000 CPU if the Consuming (O -> T) Application Path is not present in the Forward Open message coming from the Scanner device or if the specified Connection Point is incorrect. |  |
| 0x01 | 0x012B | Invalid Producing Application Path | This error will be returned by the Productivity3000 CPU if the Producing (T -> O) Application Path is not present in the Forward Open message coming from the Scanner device or if the specified Connection Point is incorrect. |  |
| 0x01 | 0x012C | Config. Symbol Does not Exist | The Originator attempted to connect to a configuration tag name that is not supported in the Target. |  |
| 0x01 | 0x012D | Consuming Symbol Does not Exist | The Originator attempted to connect to a consuming tag name that is not supported in the Target. |  |
| 0x01 | 0x012E | Producing Symbol Does not Exist | The Originator attempted to connect to a producing tag name that is not supported in the Target. |  |
| 0x01 | 0x012F | Inconsistent Application Path Combination | The combination of Configuration, Consuming and Producing application paths specified are inconsistent. |  |

| P3000 EtherNet/IP Error Codes | | | | |
|-------------------------------|-----------------------|--|---|-----------------|
| General Status Error | Extended Status Error | Name | Description | P3000 Supported |
| 0x01 | 0x0130 | Inconsistent Consume data format | Information in the data segment not consistent with the format of the data in the consumed data. | ✗ |
| 0x01 | 0x0131 | Inconsistent Product data format | Information in the data segment not consistent with the format of the data in the produced data. | ✗ |
| 0x01 | 0x0132 | Null Forward Open function not supported | The target device does not support the function requested in the NULL Forward Open request. The request could be such items as "Ping device", "Configure device application", etc. | ✗ |
| 0x01 | 0x0133 | Connection Timeout Multiplier not acceptable | The Connection Multiplier specified in the Forward Open request not acceptable by the Target device (once multiplied in conjunction with the specified timeout value). Consult the manufacturer device's documentation on what the acceptable timeout and multiplier are for this device. | ✗ |
| 0x01 | 0x0203 | Connection Timed Out | This error will be returned by the Productivity3000 CPU if a message is sent to the CPU on a connection that has already timed out. Connections time out if no message is sent to the CPU in the time period specified by the RPI rate X Connection multiplier specified in the Forward Open message. | ✗ |
| 0x01 | 0x0204 | Unconnected Request Timed Out | This time out occurs when the device sends an Unconnected Request and no response is received within the specified time out period. In the Productivity3000 CPU, this value may be found in the hardware configuration under the Ethernet port settings for the P3-550(E) or P3-530. | ✓ |
| 0x01 | 0x0205 | Parameter Error in Unconnected Request Service | This error occurs when Connection Tick Time/ Connection time-out combination is specified in the Forward Open or Forward Close message this is not supported by the device. | ✗ |
| 0x01 | 0x0206 | Message Too Large for Unconnected_Send Service | Occurs when Unconnected_Send message is too large to be sent to the network. | ✗ |
| 0x01 | 0x0207 | Unconnected Acknowledge without Reply | This error occurs if an Acknowledge was received but no data response occurred. Verify that the message that was sent is supported by the Target device using the device manufacturer's documentation. | ✗ |
| 0x01 | 0x0301 | No Buffer Memory Available | This error occurs if the Connection memory buffer in the target device is full. Correct this by reducing the frequency of the messages being sent to the device and/or reducing the number of connections to the device. Consult the manufacturer's documentation for other means of correcting this. | ✗ |
| 0x01 | 0x0302 | Network Bandwidth not Available for Data | This error occurs if the Producer device cannot support the specified RPI rate when the connection has been configured with schedule priority. Reduce the RPI rate or consult the manufacturer's documentation for other means to correct this. | ✗ |
| 0x01 | 0x0303 | No Consumed Connection ID Filter Available | This error occurs if a Consumer device doesn't have an available consumed_connection_id filter. | ✗ |
| 0x01 | 0x0304 | Not Configured to Send Scheduled Priority Data | This error occurs if a device has been configured for a scheduled priority message and it cannot send the data at the scheduled time slot. | ✗ |

Chapter 6: Communications

| P3000 EtherNet/IP Error Codes | | | | |
|-------------------------------|-----------------------|--|--|-----------------|
| General Status Error | Extended Status Error | Name | Description | P3000 Supported |
| 0x01 | 0x0305 | Schedule Signature Mismatch | This error occurs if the schedule priority information does not match between the Target and the Originator. | ✗ |
| 0x01 | 0x0306 | Schedule Signature Validation not Possible | This error occurs when the schedule priority information sent to the device is not validated. | ✗ |
| 0x01 | 0x0311 | Port Not Available | This error occurs when a port number specified in a port segment is not available. Consult the documentation of the device to verify the correct port number. | ✗ |
| 0x01 | 0x0312 | Link Address Not Valid | The Link address specified in the port segment is not correct. Consult the documentation of the device to verify the correct port number. | ✗ |
| 0x01 | 0x0315 | Invalid Segment in Connection Path | This error occurs when the target device cannot understand the segment type or segment value in the Connection Path. Consult the documentation of the device to verify the correct segment type and value. If a Connection Point greater than 255 is specified this error could occur. | ✓ |
| 0x01 | 0x0316 | Forward Close Service Connection Path Mismatch | This error occurs when the Connection path in the Forward Close message does not match the Connection Path configured in the connection. Contact Tech Support if this error persists. | ✗ |
| 0x01 | 0x0317 | Scheduling Not Specified | This error can occur if the Schedule network segment or value is invalid. | ✗ |
| 0x01 | 0x0318 | Link Address to Self Invalid | If the Link address points back to the originator device, this error will occur. | ✗ |
| 0x01 | 0x0319 | Secondary Resource Unavailable | This occurs in a redundant system when the secondary connection request is unable to duplicate the primary connection request. | ✗ |
| 0x01 | 0x031A | Rack Connection Already established | The connection to a module is refused because part or all of the data requested is already part of an existing rack connection. | ✗ |
| 0x01 | 0x031B | Module Connection Already established | The connection to a rack is refused because part or all of the data requested is already part of an existing module connection. | ✗ |
| 0x01 | 0x031C | Miscellaneous | This error is returned when there is no other applicable code for the error condition. Consult the manufacturer's documentation or contact Tech support if this error persist. | ✗ |
| 0x01 | 0x031D | Redundant Connection Mismatch | This error occurs when these parameters don't match when establishing a redundant owner connection: O -> T RPI, O -> T Connection Parameters, T -> O RPI, T -> O Connection Parameters and Transport Type and Trigger. | ✗ |
| 0x01 | 0x031E | No more User Configurable Link Resources Available in the Producing Module | This error is returned from the Target device when no more available Consumer connections available for a Producer. | ✗ |

| P3000 EtherNet/IP Error Codes | | | | |
|-------------------------------|-----------------------|---|---|-----------------|
| General Status Error | Extended Status Error | Name | Description | P3000 Supported |
| 0x01 | 0x031F | No User Configurable Link Consumer Resources Configured in the Producing Module | This error is returned from the Target device when no Consumer connections have been configured for a Producer connection. | ✗ |
| 0x01 | 0x0800 | Network Link Offline | The Link path is invalid or not available. | ✗ |
| 0x01 | 0x0810 | No Target Application Data Available | This error is returned from the Target device when the application has no valid data to produce. | ✗ |
| 0x01 | 0x0811 | No Originator Application Data Available | This error is returned from the Originator device when the application has no valid data to produce. | ✗ |
| 0x01 | 0x0812 | Node Address has changed since the Network was scheduled | This specifies that the router has changed node addresses since the value configured in the original connection. | ✗ |
| 0x01 | 0x0813 | Not Configured for Off-subnet Multicast | The producer has been requested to support a Multicast connection for a consumer on a different subnet and does not support this functionality. | ✗ |
| 0x01 | 0x0814 | Invalid Produce/ Consume Data format | Information in the data segment not consistent with the format of the data in the consumed or produced data. Errors 0x0130 and 0x0131 are typically used for this situation in most devices now. | ✗ |
| 0x02 | N/A | Resource Unavailable for Unconnected Send | The Target device does not have the resources to process the Unconnected Send request. | ✗ |
| 0x04 | N/A | Path Segment Error in Unconnected Send | The Class, Instance or Attribute value specified in the Unconnected Explicit Message request is incorrect or not supported in the Target device. Check the manufacturer's documentation for the correct codes to use. | ✗ |
| 0x09 | Index to error | Error in Data Segment | This error code is returned when an error is encountered in the Data segment portion of a Forward Open message. The Extended Status value is the offset in the Data segment where the error was encountered. | ✗ |
| 0x0C | Optional | Object State Error | This error is returned from the Target device when the current state of the Object requested does not allow it to be returned. The current state can be specified in the Optional Extended Error status field. | ✗ |
| 0x10 | Optional | Device State Error | This error is returned from the Target device when the current state of the Device requested does not allow it to be returned. The current state can be specified in the Optional Extended Error status field. | ✗ |
| 0x13 | N/A | Not Enough Data | Not enough data was supplied in the service request specified. | ✗ |
| 0x15 | N/A | Too Much Data | Too much data was supplied in the service request specified. | ✗ |