

SONY®

DATA PROJECTOR

PROTOCOL MANUAL
(SUPPORTED COMMAND LIST)
1st Edition (Revised 2)

Table of Contents

Related Manuals	1 (E)
------------------------------	--------------

1. Overview	2 (E)
--------------------------	--------------

2. Correspondence of ADCP Command in Each Projector Model

2-1. System Command	3 (E)
2-1-1. Command Type: sys_sel	3 (E)
2-1-2. Command Type: sys_stat	5 (E)
2-1-3. Command Type: sys_var	8 (E)
2-2. Menu Command	9 (E)
2-2-1. Command Type: menu_sel/menu_val/ menu_exec	9 (E)
2-3. Remote Controller Key Command	22 (E)
2-3-1. Command Type: key	22 (E)
2-4. Advanced Adjustment Command	25 (E)
2-4-1. Command Type: warp	25 (E)
2-4-2. Command Type: area_bk_level	26 (E)
2-4-3. Command Type: panel_align_zone	28 (E)
2-4-4. Command Type: user_gamma	30 (E)
2-4-5. Command Type: color_gamut	31 (E)
2-4-6. Command Type: pattern_sel/pattern_pos	32 (E)

3. PJ Control API Correspondence Table for Each Model

3-1. API Service	34 (E)
3-2. API List	36 (E)

4. Network Communication	45 (E)
---------------------------------------	---------------

5. Model List	46 (E)
----------------------------	---------------

The information contained in this manual does not guarantee compatibility or operability of the Sony projector models listed in this manual with all other equipment and systems.

Sony is not responsible for product malfunctions resulting from failure to follow the instructions and information contained herein.

For details on the projector models listed herein, please refer to the Sony user manuals and operating instructions.

The information and specifications contained herein are subject to change without notice.

Related Manuals

The following manual is provided for this unit in addition to this “Protocol Manual (SUPPORTED COMMAND LIST) ”.

- **“Protocol Manual” (COMMON)**
This manual describes the basic configuration and operation to write the various commands to be used in the serial communication (RS-232C) and network communication for the projector.

1. Overview

This manual is a protocol and command correspondence list in each projector model.
For details of each protocol, refer to REMOTE CONTROL PROTOCOL MANUAL (COMMON) on separate sheet.

Protocol for each model

(○: supported (initial setting: ON), ●: supported (initial setting: OFF), –: not supported)

Protocol	VPL-*** series (*** means model name)													Remarks
	FHZ120/FHZ90/ F1200Z/F900Z	FHZ70/FHZ60/FHZ50/ FWZ60/ F640HZ/F630HZ/ F540HZ/F530HZ/F430HZ/ F630WZ/F530WZ	FH60/FW60/ F530H/F630H/ F630W/F530W	FHZ700/ F700HZ	FH30/ F400H/ F500H	C300	E200	E300	E400/ E500	S200	S600	P10/P500	U300	
SDAP	○	○	○	●	●	●	●	●	●	●	●	●	●	
ADCP	○	○	○	○	○	○	○	○	○	○	○	○	○	Initial setting of authentication during connection is also ON. For the individual command correspondence, refer to ADCP in Section 2.
PJLink	○	○	○	●	●	○	○	○	○	○	○	○	○	Menu setting item to set whether or not to always perform the communication with the projector control device in the environment where network is connected.
DDDP (AMX Dynamic Device Discovery Protocol)	○	○	○	●	●	●	●	●	●	●	●	●	●	Function is always ON during serial connection.
SDDP (Control4 Simple Device Discovery Protocol)	–	–	–	–	–	–	–	–	–	–	–	–	–	
CIP (Crestron Internet Protocol)	○	○	○	○	○	○	○	○	○	○	○	○	○	
SNMP (Simple Network Management Protocol)	○	○	○	○	○	–	–	–	–	–	–	–	–	
PJ Control API	–	○ * FHZ70/F640HZ/ F540HZ series only	–	–	–	–	–	–	–	–	–	–	–	

Other items for each model

(○: supported/–: not supported)

Item	VPL-*** series (*** means model name)													Remarks
	FHZ120/FHZ90/ F1200Z/F900Z	FHZ70/FHZ60/FHZ50/ FWZ60/ F640HZ/F630HZ/ F540HZ/F530HZ/F430HZ/ F630WZ/F530WZ	FH60/FW60/ F530H/F630H/ F630W/F530W	FHZ700/ F700HZ	FH30/ F400H/ F500H	C300	E200	E300	E400/ E500	S200	S600	P10/P500	U300	
Ethernet terminal provided	○	○	○	○	○	○	○	○	○	○	○	○	○	
Standby mode menu setting item	○	○	○	○	○	○	○	○	○	○	○	○	○	Power consumption setting during the standby state If set to “Low”, the network function cannot be used during the standby state. When performing the power ON/OFF and so on in the network connection, set this item to “standard”.
Network management menu setting item	–	–												

2. Correspondence of ADCP Command in Each Projector Model

2-1. System Command

A system command can acquire the projector power operation and the power, error, or warning status. The type of a command is classified as follows:

- sys_sel command type: Sets the selected value for turning on and off the power.
- sys_stat command type: Acquires the status.
- sys_var command type: Sets the network address.

2-1-1. Command Type: sys_sel

By optional designation, the command of a sys_sel command type can set values and acquire values, settable choices, and command information.

Command name	command
Value to be set	txt_param1
Settable choice	txt_param1, txt_param2

In the case described above, commands conform to the formats below, respectively.

Setting of value

Transmitting example: command "txt_param1" 

Returning example: ok 

Sets the selected value using a command. The selected value is enclosed with double quotation marks (" ").

Inquiry of value:

Transmitting example: command ? 

Returning example: "txt_param1" 

Acquires the selected value of the set parameter.

The selected value that has been set is returned with the value being enclosed in double quotation marks (" ").

Inquiry of value range:

Transmitting example: command ? --range 

Returning example: ["txt_param1", "txt_param2"] 

Acquires a list of parameter-selected values that can be set.

Inquiry of command information:

Transmitting example: command ? --info 

Returning example: { "type": "sys_sel", "version": "1.0", "range": ["txt_param1", "txt_param2"] } 

Acquires the command information.

A command type, command version, and a list of selected values that can be set using a command are returned as command information.

1. Command list

Function	Command	Parameter/ response	Remarks	VPL-*** series (*** means model name)												
				FHZ120/FHZ90/ F1200Z/F900Z	FHZ70/FHZ60/FHZ50/ FWZ60/ F640HZ/F630HZ/ F540HZ/F530HZ/F430HZ/ F630WZ/F530WZ	FH60/FW60/ F530H/F630H/ F630W/F530W	FHZ700/ F700HZ	FH30/ F400H/ F500H	C300	E200	E300	E400/ E500	S200	S600	P10/P500	U300
Power on/off operation	power*1	"on"	Power on operation	○	○	○	○	○	○	○	○	○	○	○	○	○
		"off"	Power off operation	○	○	○	○	○	○	○	○	○	○	○	○	○
IPv4 network setting	ipv4_network_setting*2	"start"	Setting start	○	○	○	○	○	○	○	○	○	○	○	○	○
		"apply"	Setting reflection	○	○	○	○	○	○	○	○	○	○	○	○	○
IPv4 address setting method Setting/acquisition	ipv4_set_method	"auto"	Auto	○	○	○	○	○	○	○	○	○	○	○	○	○
	ipv4_set_method ?	"manual"	Manual*3	○	○	○	○	○	○	○	○	○	○	○	○	○

*1: A value cannot be acquired. Use the power_status ? command of a sys_stat command type when acquiring the power state.

2. Command example

```
power "on" ↵
ok ↵
```

*2: During network setting, set an address after sending “start”. Then, send “apply” and reflect the setting.

Example

```
ipv4_network_setting "start" ↵
ipv4_set_method "auto" ↵
ipv4_dns_set_method "auto" ↵
ipv4_network_setting "apply" ↵
```

*3: Set each address using the network setting command of a sys_var command category when selecting “manual”. Then, send “apply” and reflect the setting.

Example

```
ipv4_network_setting "start" ↵
ipv4_set_method "manual" ↵
ipv4_ip_address "XXX.XXX.XXX.XXX" ↵
ipv4_sub_net_mask "XXX.XXX.XXX.XXX" ↵
ipv4_default_gateway "XXX.XXX.XXX.XXX" ↵
ipv4_dns_server1 "XXX.XXX.XXX.XXX" ↵
ipv4_dns_server2 "XXX.XXX.XXX.XXX" ↵
ipv4_network_setting "apply" ↵
```


2. Command example

```
power_status ?  
"standby"
```

2-1-3. Command Type: sys_var

You can set and obtain the items of special value representation with the command of the “sys_var” command type.

Command name: In the case of "command", the following format is used.

Setting of value:

```
Transmitting example: command "192.168.0.1"  
Returning example: ok
```

Inquiry of value:

```
Transmitting example: command ?  
Returning example: "192.168.0.1"
```

Inquiry of settable value range:

```
Transmitting example: command ? --range  
Returning example: { "min": "0.0.0.0", "max": "255.255.255.255" }
```

1. System numeric command

2. Command example

```
ipv4_ip_address ?  
"192.168.0.1"
```

2-2. Menu Command

2-2-1. Command Type: menu_sel/menu_val/menu_exec

By optional designation, the command of a menu_sel/menu_val/menu_exec command type can set and acquire menu values, and acquire command information.
Command name: In the case of “cmd”, the following format is used.

Command Type		Set		Reset	Query
		Direct	Relative		Value
menu_sel	Transmitting example	cmd "item" 		cmd --reset 	cmd ? 
	Returning example	ok 		ok 	"item" 
menu_num	Transmitting example	cmd 10 	cmd --rel -1 	cmd --reset 	cmd ? 
	Returning example	ok 	ok 	ok 	10 
menu_exec	Transmitting example	cmd 		—	—
	Returning example	ok 			

Command Type		Query	
		Range	Command info
menu_sel	Transmitting example	cmd --range 	cmd --info 
	Returning example	"item" 	{"type": "menu_sel", "version": "1.0", "range": ["item", "item2"]} 
menu_num	Transmitting example	cmd --range 	cmd --info 
	Returning example	{"min": 0, "max": 10} 	{"type": "menu_num", "version": "1.0", "range": {"min": 0, "max": 10}} 
menu_exec	Transmitting example	—	cmd --info 
	Returning example		{"type": "menu_exec", "version": "1.0"} 

