


Operating Instructions

Proline Prowirl D 200

HART

Vortex flowmeter



- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these instructions.

Table of contents

| | | | | |
|----------|---|-----------|--|--|
| 1 | Document information | 6 | | |
| 1.1 | Document function | 6 | | |
| 1.2 | Symbols used | 6 | | |
| 1.2.1 | Safety symbols | 6 | | |
| 1.2.2 | Electrical symbols | 6 | | |
| 1.2.3 | Tool symbols | 6 | | |
| 1.2.4 | Symbols for certain types of information | 7 | | |
| 1.2.5 | Symbols in graphics | 7 | | |
| 1.3 | Documentation | 7 | | |
| 1.3.1 | Standard documentation | 8 | | |
| 1.3.2 | Supplementary device-dependent documentation | 8 | | |
| 1.4 | Registered trademarks | 8 | | |
| 2 | Basic safety instructions | 9 | | |
| 2.1 | Requirements for the personnel | 9 | | |
| 2.2 | Designated use | 9 | | |
| 2.3 | Workplace safety | 10 | | |
| 2.4 | Operational safety | 10 | | |
| 2.5 | Product safety | 10 | | |
| 2.6 | IT security | 10 | | |
| 3 | Product description | 11 | | |
| 3.1 | Product design | 11 | | |
| 4 | Incoming acceptance and product identification | 12 | | |
| 4.1 | Incoming acceptance | 12 | | |
| 4.2 | Product identification | 12 | | |
| 4.2.1 | Transmitter nameplate | 13 | | |
| 4.2.2 | Sensor nameplate | 14 | | |
| 4.2.3 | Symbols on measuring device | 16 | | |
| 5 | Storage and transport | 17 | | |
| 5.1 | Storage conditions | 17 | | |
| 5.2 | Transporting the product | 17 | | |
| 5.2.1 | Measuring devices without lifting lugs | 17 | | |
| 5.2.2 | Measuring devices with lifting lugs | 18 | | |
| 5.2.3 | Transporting with a fork lift | 18 | | |
| 5.3 | Packaging disposal | 18 | | |
| 6 | Installation | 19 | | |
| 6.1 | Installation conditions | 19 | | |
| 6.1.1 | Mounting position | 19 | | |
| 6.1.2 | Requirements from environment and process | 23 | | |
| 6.1.3 | Special mounting instructions | 24 | | |
| 6.2 | Mounting the measuring device | 25 | | |
| 6.2.1 | Required tools | 25 | | |
| 6.2.2 | Preparing the measuring device | 25 | | |
| 6.2.3 | Mounting the sensor | 25 | | |
| 6.2.4 | Mounting the transmitter of the remote version | 26 | | |
| 6.2.5 | Turning the transmitter housing | 27 | | |
| 6.2.6 | Turning the display module | 28 | | |
| 6.3 | Post-installation check | 28 | | |
| 7 | Electrical connection | 30 | | |
| 7.1 | Connection conditions | 30 | | |
| 7.1.1 | Required tools | 30 | | |
| 7.1.2 | Connecting cable requirements | 30 | | |
| 7.1.3 | Terminal assignment | 32 | | |
| 7.1.4 | Requirements for the supply unit | 33 | | |
| 7.1.5 | Preparing the measuring device | 35 | | |
| 7.2 | Connecting the measuring device | 35 | | |
| 7.2.1 | Connecting the remote version | 35 | | |
| 7.2.2 | Connecting the transmitter | 39 | | |
| 7.2.3 | Ensuring potential equalization | 41 | | |
| 7.3 | Special connection instructions | 41 | | |
| 7.3.1 | Connection examples | 41 | | |
| 7.4 | Ensuring the degree of protection | 43 | | |
| 7.5 | Post-connection check | 44 | | |
| 8 | Operation options | 45 | | |
| 8.1 | Overview of operating options | 45 | | |
| 8.2 | Structure and function of the operating menu | 46 | | |
| 8.2.1 | Structure of the operating menu | 46 | | |
| 8.2.2 | Operating philosophy | 47 | | |
| 8.3 | Access to the operating menu via the local display | 48 | | |
| 8.3.1 | Operational display | 48 | | |
| 8.3.2 | Navigation view | 49 | | |
| 8.3.3 | Editing view | 51 | | |
| 8.3.4 | Operating elements | 53 | | |
| 8.3.5 | Opening the context menu | 53 | | |
| 8.3.6 | Navigating and selecting from list | 55 | | |
| 8.3.7 | Calling the parameter directly | 55 | | |
| 8.3.8 | Calling up help text | 56 | | |
| 8.3.9 | Changing the parameters | 57 | | |
| 8.3.10 | User roles and related access authorization | 58 | | |
| 8.3.11 | Disabling write protection via access code | 58 | | |
| 8.3.12 | Enabling and disabling the keypad lock | 58 | | |
| 8.4 | Access to the operating menu via the operating tool | 59 | | |
| 8.4.1 | Connecting the operating tool | 60 | | |
| 8.4.2 | Field Xpert SFX350, SFX370 | 60 | | |
| 8.4.3 | FieldCare | 60 | | |
| 8.4.4 | AMS Device Manager | 62 | | |
| 8.4.5 | SIMATIC PDM | 62 | | |

| | | | | | |
|-----------|--|------------|-----------|---|------------|
| 8.4.6 | Field Communicator 475 | 62 | 11.7 | Showing data logging | 134 |
| 9 | System integration | 63 | 12 | Diagnostics and troubleshooting .. | 137 |
| 9.1 | Overview of device description files | 63 | 12.1 | General troubleshooting | 137 |
| 9.1.1 | Current version data for the device ... | 63 | 12.2 | Diagnostic information on local display | 139 |
| 9.1.2 | Operating tools | 63 | 12.2.1 | Diagnostic message | 139 |
| 9.2 | Measured variables via HART protocol | 63 | 12.2.2 | Calling up remedial measures | 141 |
| 9.3 | Other settings | 65 | 12.3 | Diagnostic information in FieldCare | 141 |
| 9.3.1 | Burst mode functionality in accordance with HART 7 Specification | 65 | 12.3.1 | Diagnostic options | 141 |
| 10 | Commissioning | 68 | 12.3.2 | Calling up remedy information | 142 |
| 10.1 | Function check | 68 | 12.4 | Adapting the diagnostic information | 143 |
| 10.2 | Switching on the measuring device | 68 | 12.4.1 | Adapting the diagnostic behavior ... | 143 |
| 10.3 | Setting the operating language | 68 | 12.4.2 | Adapting the status signal | 143 |
| 10.4 | Configuring the measuring device | 69 | 12.5 | Overview of diagnostic information | 144 |
| 10.4.1 | Defining the tag name | 69 | 12.6 | Pending diagnostic events | 147 |
| 10.4.2 | Selecting and setting the medium ... | 71 | 12.7 | Diagnostic list | 148 |
| 10.4.3 | Configuring the current input | 73 | 12.8 | Event logbook | 149 |
| 10.4.4 | Configuring the current output | 76 | 12.8.1 | Event history | 149 |
| 10.4.5 | Configuring the pulse/frequency/ switch output | 79 | 12.8.2 | Filtering the event logbook | 149 |
| 10.4.6 | Configuring the local display | 90 | 12.8.3 | Overview of information events | 149 |
| 10.4.7 | Configuring the output conditioning | 92 | 12.9 | Resetting the measuring device | 150 |
| 10.4.8 | Configuring the low flow cut off | 93 | 12.9.1 | Function scope of the "Device reset" parameter | 151 |
| 10.5 | Advanced settings | 95 | 12.10 | Device information | 151 |
| 10.5.1 | Setting the system units | 96 | 12.11 | Firmware history | 154 |
| 10.5.2 | Setting the medium properties | 99 | 13 | Maintenance | 155 |
| 10.5.3 | Performing external compensation . | 113 | 13.1 | Maintenance tasks | 155 |
| 10.5.4 | Carrying out a sensor adjustment ... | 115 | 13.1.1 | Exterior cleaning | 155 |
| 10.5.5 | Configuring the totalizer | 116 | 13.1.2 | Interior cleaning | 155 |
| 10.5.6 | Carrying out additional display configurations | 118 | 13.1.3 | Replacing seals | 155 |
| 10.6 | Configuration management | 120 | 13.2 | Measuring and test equipment | 155 |
| 10.6.1 | Function scope of the "Configuration management" parameter | 121 | 13.3 | Endress+Hauser services | 155 |
| 10.7 | Simulation | 122 | 14 | Repair | 156 |
| 10.8 | Protecting settings from unauthorized access | 124 | 14.1 | General notes | 156 |
| 10.8.1 | Write protection via access code ... | 124 | 14.2 | Spare parts | 156 |
| 10.8.2 | Write protection via write protection switch | 125 | 14.3 | Endress+Hauser services | 157 |
| 11 | Operation | 128 | 14.4 | Return | 157 |
| 11.1 | Reading the device locking status | 128 | 14.5 | Disposal | 157 |
| 11.2 | Adjusting the operating language | 128 | 14.5.1 | Removing the measuring device ... | 157 |
| 11.3 | Configuring the display | 128 | 14.5.2 | Disposing of the measuring device .. | 158 |
| 11.4 | Reading measured values | 128 | 15 | Accessories | 159 |
| 11.4.1 | Process variables | 128 | 15.1 | Device-specific accessories | 159 |
| 11.4.2 | Totalizer | 131 | 15.1.1 | For the transmitter | 159 |
| 11.4.3 | Input values | 131 | 15.1.2 | For the sensor | 160 |
| 11.4.4 | Output values | 132 | 15.2 | Communication-specific accessories | 160 |
| 11.5 | Adapting the measuring device to the process conditions | 133 | 15.3 | Service-specific accessories | 161 |
| 11.6 | Performing a totalizer reset | 133 | 15.4 | System components | 161 |
| | | | 16 | Technical data | 163 |
| | | | 16.1 | Application | 163 |
| | | | 16.2 | Function and system design | 163 |
| | | | 16.3 | Input | 163 |
| | | | 16.4 | Output | 169 |

| | | |
|--------------|---------------------------------------|------------|
| 16.5 | Power supply | 172 |
| 16.6 | Performance characteristics | 174 |
| 16.7 | Installation | 177 |
| 16.8 | Environment | 177 |
| 16.9 | Process | 178 |
| 16.10 | Mechanical construction | 178 |
| 16.11 | Operability | 184 |
| 16.12 | Certificates and approvals | 186 |
| 16.13 | Application packages | 187 |
| 16.14 | Accessories | 188 |
| 16.15 | Supplementary documentation | 188 |
| Index | | 190 |





1 Document information

1.1 Document function







These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Symbols used




1.2.1 Safety symbols

| Symbol | Meaning |
|---|--|
|  | DANGER! This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury. |
|  | WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury. |
|  | CAUTION! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury. |
|  | NOTE! This symbol contains information on procedures and other facts which do not result in personal injury. |












1.2.2 Electrical symbols

| Symbol | Meaning | Symbol | Meaning |
|---|--|--|--|
|  | Direct current |  | Alternating current |
|  | Direct current and alternating current |  | Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system. |
|  | Protective ground connection A terminal which must be connected to ground prior to establishing any other connections. |  | Equipotential connection A connection that has to be connected to the plant grounding system: This may be a potential equalization line or a star grounding system depending on national or company codes of practice. |





1.2.3 Tool symbols

| Symbol | Meaning |
|---|------------------------|
|  | Flat blade screwdriver |
|  | Allen key |
|  | Open-ended wrench |


1.2.4 Symbols for certain types of information

| Symbol | Meaning |
|--|--|
|  | Permitted Procedures, processes or actions that are permitted. |
|  | Preferred Procedures, processes or actions that are preferred. |
|  | Forbidden Procedures, processes or actions that are forbidden. |
|  | Tip Indicates additional information. |
|  | Reference to documentation |
|  | Reference to page |
|  | Reference to graphic |
|  | Series of steps |
|  | Result of a step |
|  | Help in the event of a problem |
|  | Visual inspection |

1.2.5 Symbols in graphics

| Symbol | Meaning | Symbol | Meaning |
|---|----------------|---|--------------------------------|
| 1, 2, 3,... | Item numbers |  | Series of steps |
| A, B, C, ... | Views | A-A, B-B, C-C, ... | Sections |
|  | Hazardous area |  | Safe area (non-hazardous area) |
|  | Flow direction | | |

1.3 Documentation

 For an overview of the scope of the associated Technical Documentation, refer to the following:

- The *W@M Device Viewer* : Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

 For a detailed list of the individual documents along with the documentation code

1.3.1 Standard documentation

| Document type | Purpose and content of the document |
|------------------------------|--|
| Technical Information | Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device. |
| Brief Operating Instructions | Guide that takes you quickly to the 1st measured value The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning. |

1.3.2 Supplementary device-dependent documentation

Additional documents are supplied depending on the device version ordered: Always comply strictly with the instructions in the supplementary documentation. The supplementary documentation is an integral part of the device documentation.

1.4 Registered trademarks

HART®

Registered trademark of the HART Communication Foundation, Austin, USA

KALREZ®, VITON®

Registered trademarks of DuPont Performance Elastomers L.L.C., Wilmington, DE USA

GYLON®

Registered trademark of Garlock Sealing Technologies, Palmyra, NY, USA

Applicator®, FieldCare®, DeviceCare®, Field Xpert™, HistoROM®, Heartbeat Technology™

Registered or registration-pending trademarks of the Endress+Hauser Group

2 Basic safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ▶ Trained, qualified specialists must have a relevant qualification for this specific function and task
- ▶ Are authorized by the plant owner/operator
- ▶ Are familiar with federal/national regulations
- ▶ Before beginning work, the specialist staff must have read and understood the instructions in the Operating Instructions and supplementary documentation as well as in the certificates (depending on the application)
- ▶ Following instructions and basic conditions

The operating personnel must fulfill the following requirements:

- ▶ Being instructed and authorized according to the requirements of the task by the facility's owner-operator
- ▶ Following the instructions in these Operating Instructions


2.2 Designated use

Application and media

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring devices for use in hazardous areas, in hygienic applications or in applications where there is an increased risk due to process pressure, are labeled accordingly on the nameplate.

To ensure that the measuring device remains in proper condition for the operation time:

- ▶ Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- ▶ Check the nameplate to verify if the device ordered can be put to its intended use in the approval-related area (e.g. explosion protection, pressure vessel safety).
- ▶ Use the measuring device only for media against which the process-wetted materials are adequately resistant.
- ▶ If the measuring device is not operated at atmospheric temperature, compliance with the relevant basic conditions specified in the associated device documentation is absolutely essential: "Documentation" section →  7.
- ▶ Protect the measuring device permanently against corrosion from environmental influences.

Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

WARNING

Danger of breakage of the sensor due to corrosive or abrasive fluids or from environmental conditions!

- ▶ Verify the compatibility of the process fluid with the sensor material.
- ▶ Ensure the resistance of all fluid-wetted materials in the process.
- ▶ Keep within the specified pressure and temperature range.

Verification for borderline cases:

- ▶ For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any

warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

Residual risks

Possible burn hazard due to fluid temperatures!

- ▶ For elevated fluid temperature, ensure protection against contact to prevent burns.

2.3 Workplace safety

For work on and with the device:

- ▶ Wear the required personal protective equipment according to federal/national regulations.

For welding work on the piping:

- ▶ Do not ground the welding unit via the measuring device.

If working on and with the device with wet hands:

- ▶ It is recommended to wear gloves on account of the higher risk of electric shock.

2.4 Operational safety

Risk of injury.

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

- ▶ If, despite this, modifications are required, consult with Endress+Hauser.

Repair

To ensure continued operational safety and reliability,

- ▶ Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to repair of an electrical device.
- ▶ Use original spare parts and accessories from Endress+Hauser only.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EC directives listed in the device-specific EC Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

2.6 IT security

We only provide a warranty if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the device settings.

IT security measures in line with operators' security standards and designed to provide additional protection for the device and device data transfer must be implemented by the operators themselves.


3 Product description

The device consists of a transmitter and a sensor.

Two device versions are available:

- Compact version – transmitter and sensor form a mechanical unit.
- Remote version - transmitter and sensor are mounted in separate locations.

3.1 Product design





















A0020649


1 Important components of a measuring device

- 1 Electronics compartment cover
- 2 Display module
- 3 Main electronics module
- 4 Cable glands
- 5 Transmitter housing (incl. HistoROM)
- 6 I/O electronics module
- 7 Terminals (pluggable spring terminals)
- 8 Connection compartment cover
- 9 Sensor

4 Incoming acceptance and product identification

4.1 Incoming acceptance

| | | | | | |
|---|---|--|---|---|--|
|  |  |  |  |  | <p>Are the order codes on the delivery note (1) and the product sticker (2) identical?</p> |
|  | | | | | |
|  |  |  |  |  | <p>Are the goods undamaged?</p> |
|  |  |  |  | | <p>Do the nameplate data match the ordering information on the delivery note?</p> |
|  |  |  | | | <p>Is the CD-ROM with the Technical Documentation (depends on device version) and documents present?</p> |



-  If one of the conditions is not satisfied, contact your Endress+Hauser Sales Center.
- Depending on the device version, the CD-ROM might not be part of the delivery! The Technical Documentation is available via the Internet or via the *Endress+Hauser Operations App*, see the "Product identification" section → 13.

4.2 Product identification


The following options are available for identification of the measuring device:


- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in *W@M Device Viewer* (www.endress.com/deviceviewer): All information about the measuring device is displayed.
- Enter the serial number from the nameplates into the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the nameplate with the *Endress+Hauser Operations App*: all the information for the measuring device is displayed.

For an overview of the scope of the associated Technical Documentation, refer to the following:

- The chapters "Additional standard documentation on the device" →  8 and "Supplementary device-dependent documentation" →  8
- The *W@M Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

4.2.1 Transmitter nameplate




 2 Example of a transmitter nameplate

- 1 Manufacturing location
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Electrical connection data, e.g. available inputs and outputs, supply voltage
- 7 Type of cable glands
- 8 Permitted ambient temperature (T_a)
- 9 Firmware version (FW) and device revision (Dev.Rev.) from the factory
- 10 CE mark, C-Tick
- 11 Additional information on version: certificates, approvals
- 12 Permitted temperature range for cable
- 13 Manufacturing date: year-month
- 14 Degree of protection
- 15 Approval information for explosion protection
- 16 Document number of safety-related supplementary documentation
- 17 2-D matrix code

4.2.2 Sensor nameplate

Order code for "Housing" option B "GT18 two-chamber, 316L" and option K "GT18 two-chamber, remote, 316L"




A0020760

3 Example of a sensor nameplate

- 1 Name of the sensor
- 2 Nominal diameter of the sensor
- 3 Flange nominal diameter/nominal pressure
- 4 Serial number (Ser. no.)
- 5 Measuring tube material
- 6 Measuring tube material
- 7 Maximal permitted volume flow (gas/steam)
- 8 Test pressure of the sensor
- 9 Seal material
- 10 Document number of safety-related supplementary documentation → 188
- 11 Ambient temperature range
- 12 CE mark
- 13 Medium temperature range
- 14 Degree of protection

Order code for "Housing" option C "GT20 two-chamber, aluminum coated"




A0020758

4 Example of a sensor nameplate

- 1 Nominal diameter of the sensor
- 2 Flange nominal diameter/nominal pressure
- 3 Measuring tube material
- 4 Measuring tube material
- 5 Serial number (Ser. no.)
- 6 Maximal permitted volume flow (gas/steam)
- 7 Test pressure of the sensor
- 8 Degree of protection
- 9 Approval information for explosion protection and Pressure Equipment Directive
- 10 CE mark
- 11 Seal material
- 12 Medium temperature range
- 13 Ambient temperature range

Order code for "Housing" option J "GT20 two-chamber, remote, aluminum coated"



A0020759

5 Example of a sensor nameplate

- 1 Name of the sensor
- 2 Nominal diameter of the sensor
- 3 Flange nominal diameter/nominal pressure
- 4 Order code
- 5 Serial number (Ser. no.)
- 6 Extended order code (Ext. ord. cd.)
- 7 Maximal permitted volume flow (gas/steam)
- 8 Degree of protection
- 9 Approval information for explosion protection and Pressure Equipment Directive
- 10 Ambient temperature range
- 11 Document number of safety-related supplementary documentation → 188
- 12 Test pressure of the sensor
- 13 Measuring tube material
- 14 Measuring tube material
- 15 Seal material
- 16 Medium temperature range

i Order code

The measuring device is reordered using the order code.

Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approval-related specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE +).

4.2.3 Symbols on measuring device

| Symbol | Meaning |
|--------|--|
| | WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury. |
| | Reference to documentation Refers to the corresponding device documentation. |
| | Protective ground connection A terminal which must be connected to ground prior to establishing any other connections. |

5 Storage and transport

5.1 Storage conditions

Observe the following notes for storage:


- Store in the original packaging to ensure protection from shock.
- Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- Protect from direct sunlight to avoid unacceptably high surface temperatures.
- Store in a dry and dust-free place.
- Do not store outdoors.

Storage temperature:

- All components apart from the display modules: -50 to $+80$ °C (-58 to $+176$ °F)
- Display modules: -40 to $+80$ °C (-40 to $+176$ °F)

5.2 Transporting the product

Transport the measuring device to the measuring point in the original packaging.



A0015604

- i** Do not remove protective covers or caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.


5.2.1 Measuring devices without lifting lugs

⚠ WARNING

Center of gravity of the measuring device is higher than the suspension points of the webbing slings.

Risk of injury if the measuring device slips.

- ▶ Secure the measuring device against slipping or turning.
- ▶ Observe the weight specified on the packaging (stick-on label).



A0015606

5.2.2 Measuring devices with lifting lugs

⚠ CAUTION

Special transportation instructions for devices with lifting lugs

- ▶ Only use the lifting lugs fitted on the device or flanges to transport the device.
- ▶ The device must always be secured at two lifting lugs at least.

5.2.3 Transporting with a fork lift

If transporting in wood crates, the floor structure enables the crates to be lifted lengthwise or at both sides using a forklift.

5.3 Packaging disposal

All packaging materials are environmentally friendly and 100% recyclable:


- Measuring device secondary packaging: polymer stretch film that conforms to EC Directive 2002/95/EC (RoHS).
- Packaging:
 - Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.
 - or
 - Carton in accordance with European Packaging Directive 94/62EC; recyclability is confirmed by the affixed RESY symbol.
- Seaworthy packaging (optional): Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.
- Carrying and mounting hardware:
 - Disposable plastic pallet
 - Plastic straps
 - Plastic adhesive strips
- Dunnage: Paper cushion

6 Installation

6.1 Installation conditions

6.1.1 Mounting position

Mounting location



A0015543


Orientation

The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

Vortex meters require a fully developed flow profile as a prerequisite for correct volume flow measurement. Therefore, please note the following:

| Orientation | | Compact version | Remote version |
|-------------|--|---------------------|----------------|
| A | Vertical orientation | ✓✓ ¹⁾ | ✓✓ |
| B | Horizontal orientation, transmitter head up | ✓✓ ^{2) 3)} | ✓✓ |
| C | Horizontal orientation, transmitter head down | ✓✓ ^{4) 5)} | ✓✓ |
| D | Horizontal orientation, transmitter head at side | ✓✓ ⁴⁾ | ✓✓ |

- 1) In the case of liquids, there should be upward flow in vertical pipes to avoid partial pipe filling (Fig. A). Disruption in flow measurement! In the case of vertical orientation and downward flowing liquid, the pipe always needs to be completely filled to ensure correct liquid flow measurement.
- 2) Danger of electronics overheating! If the fluid temperature is $\geq 200\text{ °C}$ (392 °F) orientation B is not permitted for the wafer version (Prowirl D) with nominal diameters DN 100 (4") and DN 150 (6").
- 3) In the case of hot media (e.g. steam or fluid temperature (TM) $\geq 200\text{ °C}$ (392 °F): orientation C or D
- 4) In the case of very cold media (e.g. liquid nitrogen): orientation B or D
- 5) For "wet steam detection/measurement" option: orientation C

Minimum spacing and cable length

A0019211

- A* Minimum spacing in all directions
L Required cable length

The following dimensions must be observed to guarantee problem-free access to the device for service purposes:


- $A = 100 \text{ mm}$ (3.94 in)
- $L = L + 150 \text{ mm}$ (5.91 in)

Rotating the electronics housing and the display

The electronics housing can be rotated continuously by 360° on the housing support. The display unit can be rotated in 45° stages. This means you can read the display comfortably from all directions.

Inlet and outlet runs

To attain the specified level of accuracy of the measuring device, the inlet and outlet runs mentioned below must be maintained at the very minimum.



A0019189

6 Minimum inlet and outlet runs with various flow obstructions

h Difference in expansion

1 Reduction by one nominal diameter size

2 Single elbow (90° elbow)

3 Double elbow (2 × 90° elbows, opposite)

4 Double elbow 3D (2 × 90° elbows, opposite, not on one plane)

5 T-piece

6 Expansion

7 Control valve

8 Two measuring devices in a row where $DN \leq 25$ (1"): directly flange on flange


9 Two measuring devices in a row where $DN \geq 40$ (1½"): for spacing, see graphic

i ■ If there are several flow disturbances present, the longest specified inlet run must be maintained.

■ If the required inlet runs cannot be observed, it is possible to install a specially designed flow conditioner → 24.

Flow conditioner

If the required inlet runs cannot be observed, it is possible to install a specially designed flow conditioner which can be ordered from Endress+Hauser. The flow conditioner is fitted between two pipe flanges and centered by the mounting bolts. Generally this reduces the inlet run needed to $10 \times DN$ with full accuracy.



1 Flow conditioner

The pressure loss for flow conditioners is calculated as follows: $\Delta p \text{ [mbar]} = 0.0085 \cdot \rho \text{ [kg/m}^3\text{]} \cdot v^2 \text{ [m/s]}$

Example for steam

$p = 10 \text{ bar abs.}$

$t = 240 \text{ }^\circ\text{C} \rightarrow \rho = 4.39 \text{ kg/m}^3$

$v = 40 \text{ m/s}$

$\Delta p = 0.0085 \cdot 4.39 \cdot 40^2 = 59.7 \text{ mbar}$

Example for H₂O condensate (80 °C)

$\rho = 965 \text{ kg/m}^3$

$v = 2.5 \text{ m/s}$

$\Delta p = 0.0085 \cdot 965 \cdot 2.5^2 = 51.3 \text{ mbar}$

ρ : density of the process medium


v : average flow velocity

abs. = absolute

 For the dimensions of the flow conditioner, see the "Technical Information" document, "Mechanical construction" section

Outlet runs when installing external devices


If installing an external device, observe the specified distance.



PT Pressure transmitter

TT Temperature transmitter

Installation dimensions

 For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

6.1.2 Requirements from environment and process

Ambient temperature range

Compact version

| | | |
|-------------------------|--------------------------|--|
| Measuring device | Non-Ex: | -40 to +80 °C (-40 to +176 °F) ¹⁾ |
| | Ex i: | -40 to +70 °C (-40 to +158 °F) ¹⁾ |
| | EEx d/XP version: | -40 to +60 °C (-40 to +140 °F) ¹⁾ |
| | ATEX II1/2G Ex d, Ex ia: | -40 to +60 °C (-40 to +140 °F) ¹⁾ |
| Local display | | -20 to +70 °C (-4 to +158 °F) ¹⁾ |

1) Additionally available as order code for "Test, certificate", option JN "Transmitter ambient temperature -50 °C (-58 °F)".

Remote version

| | | |
|----------------------|--------------------------|--|
| Transmitter | Non-Ex: | -40 to +80 °C (-40 to +176 °F) ¹⁾ |
| | Ex i: | -40 to +80 °C (-40 to +176 °F) ¹⁾ |
| | Ex d: | -40 to +60 °C (-40 to +140 °F) ¹⁾ |
| | ATEX II1/2G Ex d, Ex ia: | -40 to +60 °C (-40 to +140 °F) ¹⁾ |
| Sensor | Non-Ex: | -40 to +85 °C (-40 to +185 °F) ¹⁾ |
| | Ex i: | -40 to +85 °C (-40 to +185 °F) ¹⁾ |
| | Ex d: | -40 to +85 °C (-40 to +185 °F) ¹⁾ |
| | ATEX II1/2G Ex d, Ex ia: | -40 to +85 °C (-40 to +185 °F) ¹⁾ |
| Local display | | -20 to +70 °C (-4 to +158 °F) ¹⁾ |

1) Additionally available as order code for "Test, certificate", option JN "Transmitter ambient temperature -50 °C (-58 °F)".

- ▶ If operating outdoors:
Avoid direct sunlight, particularly in warm climatic regions.


Thermal insulation

For optimum temperature measurement and mass calculation, heat transfer at the sensor must be avoided for some fluids. This can be ensured by installing thermal insulation. A wide range of materials can be used for the required insulation.

This applies for:

- Compact version
- Remote sensor version

The maximum insulation height permitted is illustrated in the diagram:



1 Maximum insulation height


A0019212

- ▶ When insulating, ensure that a sufficiently large area of the housing support remains exposed.

The uncovered part serves as a radiator and protects the electronics from overheating and excessive cooling.

NOTICE

Electronics overheating on account of thermal insulation!

- ▶ Observe the maximum permitted insulation height of the transmitter neck so that the transmitter head and/or the connection housing of the remote version is completely free.
- ▶ Observe information on the permissible temperature ranges .
- ▶ Note that a certain orientation might be required, depending on the fluid temperature →  19.

Vibrations

The correct operation of the measuring system is not affected by plant vibrations up to 1 g, 10 to 500 Hz. Therefore no special measures are needed to secure the sensors.



6.1.3 Special mounting instructions


Installation for delta heat measurements

Order code for "Sensor version", option 3 "Mass flow (integrated temperature measurement)"


The second temperature measurement is taken using a separate temperature sensor. The measuring device reads in this value via a communication interface.

- In the case of saturated steam delta heat measurements, the Prowirl 200 must be installed on the steam side.
- In the case of water delta heat measurements, the Prowirl 200 can be installed on the cold or warm side.

 In the case of saturated steam delta heat measurements, the value **0 bar abs.** must be set in the **Fixed process pressure** parameter (→  72) in order for the measuring device to calculate on the saturated steam curve. The current input can then be used to read in the temperature.





A0019209

 7 Layout for delta heat measurement of saturated steam and water

- 1 Prowirl
- 2 Temperature sensor
- 3 Heat exchanger
- Q Heat flow

Weather protection cover

Observe the following minimum head clearance: 222 mm (8.74 in)

 For information on the weather protection cover, see →  159

6.2 Mounting the measuring device**6.2.1 Required tools****For transmitter**

- For turning the transmitter housing: Open-ended wrench 8 mm
- For opening the securing clamps: Allen key 3 mm

For sensor

For flanges and other process connections: Corresponding mounting tools


6.2.2 Preparing the measuring device

1. Remove all remaining transport packaging.
2. Remove any protective covers or protective caps present from the sensor.
3. Remove stick-on label on the electronics compartment cover.

6.2.3 Mounting the sensor** WARNING****Danger due to improper process sealing!**

- ▶ Ensure that the inside diameters of the gaskets are greater than or equal to that of the process connections and piping.
- ▶ Ensure that the gaskets are clean and undamaged.
- ▶ Install the gaskets correctly.

1. Ensure that the direction of the arrow on the sensor matches the flow direction of the medium.
2. To ensure compliance with device specifications, install the measuring device between the pipe flanges in a way that it is centered in the measurement section.
3. Install the measuring device or turn the transmitter housing so that the cable entries do not point upwards.




A0013964

Mounting kit*Mounting kit for disc (wafer version)*


The centering rings supplied are used to mount and center the wafer-style devices.

A mounting kit comprises:

- Tie rods
- Seals
- Nuts
- Washers



A0019875

 8 *Mounting kit for wafer version*

- 1 Nut, washer, tie rod
 2 Seal
 3 Centering ring (is supplied with the measuring device)

 A mounting kit can be ordered separately (see the "Accessories" section →  160).

6.2.4 Mounting the transmitter of the remote version

CAUTION

Ambient temperature too high!

Danger of electronics overheating and housing deformation.

- ▶ Do not exceed the permitted maximum ambient temperature .
- ▶ If operating outdoors: Avoid direct sunlight and exposure to weathering, particularly in warm climatic regions.

CAUTION


Excessive force can damage the housing!

- ▶ Avoid excessive mechanical stress.

The transmitter of the remote version can be mounted in the following ways:

- Wall mounting
- Pipe mounting

Wall mounting




A0019864

9 Engineering unit mm (in)

1. Drill the holes.
2. Insert wall plugs into the drilled holes.
3. Screw in the securing screws slightly at first.
4. Fit the transmitter housing over the securing screws and mount in place.
5. Tighten the securing screws.

Post mounting




A0019862

10 Engineering unit mm (in)

1 Post retainer kit for post mounting

6.2.5 Turning the transmitter housing

To provide easier access to the connection compartment or display module, the transmitter housing can be turned.




A0013713

1. Release the fixing screw.
2. Turn the housing to the desired position.
3. Firmly tighten the securing screw.

6.2.6 Turning the display module

The display module can be turned to optimize display readability and operability.



A0013905

1. Loosen the securing clamp of the electronics compartment cover using an Allen key.
2. Unscrew cover of the electronics compartment from the transmitter housing.
3. Optional: pull out the display module with a gentle rotational movement.
4. Rotate the display module into the desired position: Max. $8 \times 45^\circ$ in each direction.
5. Without display module pulled out:
Allow display module to engage at desired position.
6. With display module pulled out:
Feed the cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment until it engages.
7. Reverse the removal procedure to reassemble the transmitter.

6.3 Post-installation check

| | |
|--|--------------------------|
| Is the device undamaged (visual inspection)? | <input type="checkbox"/> |
|--|--------------------------|

| | |
|---|--------------------------|
| <p>Does the measuring device conform to the measuring point specifications?</p> <p>For example:</p> <ul style="list-style-type: none"> ▪ Process temperature ▪ Process pressure (refer to the section on "Pressure-temperature ratings" in the "Technical Information" document) ▪ Ambient temperature ▪ Measuring range → 167 | <input type="checkbox"/> |
| <p>Has the correct orientation for the sensor been selected → 19?</p> <ul style="list-style-type: none"> ▪ According to sensor type ▪ According to medium temperature ▪ According to medium properties (outgassing, with entrained solids) | <input type="checkbox"/> |
| <p>Does the arrow on the sensor nameplate match the direction of flow of the fluid through the piping → 19?</p> | <input type="checkbox"/> |
| <p>Are the measuring point identification and labeling correct (visual inspection)?</p> | <input type="checkbox"/> |
| <p>Is the device adequately protected from precipitation and direct sunlight?</p> | <input type="checkbox"/> |
| <p>Are the securing screw and securing clamp tightened securely?</p> | <input type="checkbox"/> |

7 Electrical connection

i The measuring device does not have an internal circuit breaker. For this reason, assign the measuring device a switch or power-circuit breaker so that the power supply line can be easily disconnected from the mains.

7.1 Connection conditions

7.1.1 Required tools

- For cable entries: Use corresponding tools
- For securing clamp: Allen key 3 mm
- Wire stripper
- When using stranded cables: crimping tool for ferrule
- For removing cables from terminal: flat blade screwdriver ≤ 3 mm (0.12 in)

7.1.2 Connecting cable requirements

The connecting cables provided by the customer must fulfill the following requirements.

Electrical safety

In accordance with applicable federal/national regulations.

Permitted temperature range

- -40 °C (-40 °F) to $+80$ °C ($+176$ °F)
- Minimum requirement: cable temperature range \geq ambient temperature $+20$ K

Signal cable

Current output

- For 4-20 mA: standard installation cable is sufficient.
- For 4-20 mA HART: Shielded cable recommended. Observe grounding concept of the plant.

Pulse/frequency/switch output

Standard installation cable is sufficient.

Current input

Standard installation cable is sufficient.

Connecting cable for remote version

Connecting cable (standard)

| | |
|-----------------------|--|
| Standard cable | $2 \times 2 \times 0.34$ mm ² (22 AWG) PVC cable with common shield (2 pairs, pair-stranded) |
| Flame resistance | According to DIN EN 60332-1-2 |
| Oil-resistance | According to DIN EN 60811-2-1 |
| Shielding | Galvanized copper-braid, opt. density approx. 85% |
| Cable length | 5 m (16 ft), 10 m (32 ft), 20 m (65 ft), 30 m (98 ft) |
| Operating temperature | When mounted in a fixed position: -50 to $+105$ °C (-58 to $+221$ °F); when cable can move freely: -25 to $+105$ °C (-13 to $+221$ °F) |

Connecting cable (reinforced)

| | |
|--|--|
| Cable, reinforced | 2 × 2 × 0.34 mm ² (22 AWG) PVC cable with common shield (2 pairs, pair-stranded) and additional steel-wire braided sheath |
| Flame resistance | According to DIN EN 60332-1-2 |
| Oil-resistance | According to DIN EN 60811-2-1 |
| Shielding | Galvanized copper-braid, opt. density approx. 85% |
| Strain relief and reinforcement | Steel-wire braid, galvanized |
| Cable length | 5 m (16 ft), 10 m (32 ft), 20 m (65 ft), 30 m (98 ft) |
| Operating temperature | When mounted in a fixed position: -50 to +105 °C (-58 to +221 °F); when cable can move freely: -25 to +105 °C (-13 to +221 °F) |

Cable diameter

- Cable glands supplied:
M20 × 1.5 with cable ϕ 6 to 12 mm (0.24 to 0.47 in)
- Plug-in spring terminals for device version without integrated overvoltage protection:
wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)
- Screw terminals for device version with integrated overvoltage protection: wire cross-sections 0.2 to 2.5 mm² (24 to 14 AWG)

7.1.3 Terminal assignment

Transmitter

4-20 mA HART connection version with additional inputs and outputs

| | |
|--|--|
| | |
| <p><i>Maximum number of terminals Terminals 1 to 6: Without integrated overvoltage protection</i></p> | <p><i>Maximum number of terminals for order code for "Accessory mounted", option NA "Overvoltage protection"</i></p> <ul style="list-style-type: none"> ■ <i>Terminals 1 to 4: With integrated overvoltage protection</i> ■ <i>Terminals 5 to 6: Without integrated overvoltage protection</i> |
| <p>1 Output 1 (passive): supply voltage and signal transmission 2 Output 2 (passive): supply voltage and signal transmission 3 Input (passive): supply voltage and signal transmission 4 Ground terminal for cable shield</p> | |

| Order code for "Output" | Terminal numbers | | | | | |
|---------------------------|------------------------|-------|---|-------|---------------------------------|-------|
| | Output 1 | | Output 2 | | Input | |
| | 1 (+) | 2 (-) | 3 (+) | 4 (-) | 5 (+) | 6 (-) |
| Option A | 4-20 mA HART (passive) | | - | | - | |
| Option B ¹⁾ | 4-20 mA HART (passive) | | Pulse/frequency/switch output (passive) | | - | |
| Option C ¹⁾ | 4-20 mA HART (passive) | | 4-20 mA analog (passive) | | - | |
| Option D ^{1) 2)} | 4-20 mA HART (passive) | | Pulse/frequency/switch output (passive) | | 4-20 mA current input (passive) | |

- 1) Output 1 must always be used; output 2 is optional.
- 2) The integrated overvoltage protection is not used with option D: Terminals 5 and 6 (current input) are not protected against overvoltage.

Remote version

In the case of the remote version, the sensor and transmitter are mounted separately from one another and connected by a connecting cable. The sensor is connected via the

connection housing while the transmitter is connected via the connection compartment of the wall holder unit.

i The way the transmitter wall holder is connected depends on the measuring device approval and the version of the connecting cable used.


Connection is only possible via terminals:

- For approvals Ex n, Ex tb and cCSAus Div. 1
- If a reinforced connecting cable is used

The connection is via an M12 connector:

- For all other approvals
- If the standard connecting cable is used

Connection to the connection housing of the sensor is always via the terminals (tightening torque for terminals: 1.2 to 1.7 Nm).



11 Terminals for connection compartment in the transmitter wall holder and the sensor connection housing

- 1 Terminals for connecting cable
 2 Grounding via the cable strain relief

| Terminal number | Assignment | Cable color Connecting cable |
|-----------------|----------------|---------------------------------|
| 1 | Supply voltage | Brown |
| 2 | Grounding | White |
| 3 | RS485 (+) | Yellow |
| 4 | RS485 (-) | Green |

7.1.4 Requirements for the supply unit

Supply voltage

Transmitter

An external power supply is required for each output.

The following supply voltage values apply for the outputs available:

Supply voltage for a compact version without a local display ¹⁾

| Order code for "Output" | Minimum terminal voltage ²⁾ | Maximum terminal voltage |
|---|--|--------------------------|
| Option A: 4-20 mA HART | ≥ DC 12 V | DC 35 V |
| Option B: 4-20 mA HART, pulse/ frequency/switch output | ≥ DC 12 V | DC 35 V |

| Order code for "Output" | Minimum terminal voltage ²⁾ | Maximum terminal voltage |
|--|--|--------------------------|
| Option C: 4-20 mA HART + 4-20 mA analog | ≥ DC 12 V | DC 30 V |
| Option D: 4-20 mA HART, pulse/frequency/switch output, 4-20 mA current input ³⁾ | ≥ DC 12 V | DC 35 V |

- 1) In event of external supply voltage of the power supply unit with load
- 2) The minimum terminal voltage increases if local operation is used: see the following table
- 3) Voltage drop 2.2 to 3 V for 3.59 to 22 mA

Increase in minimum terminal voltage

| Local operation | Increase in minimum terminal voltage |
|---|--------------------------------------|
| Order code for "Display; Operation", option C: Local operation SD02 | + DC 1 V |
| Order code for "Display; Operation", option E: Local operation SD03 with lighting (backlighting not used) | + DC 1 V |
| Order code for "Display; Operation", option E: Local operation SD03 with lighting (backlighting used) | + DC 3 V |


Load

Load for current output: 0 to 500 Ω, depending on the external supply voltage of the power supply unit

Calculation of the maximum load

Depending on the supply voltage of the power supply unit (U_S), the maximum load (R_B) including line resistance must be observed to ensure adequate terminal voltage at the device. In doing so, observe the minimum terminal voltage

- $R_B \leq (U_S - U_{\text{term. min}}) : 0.022 \text{ A}$
- $R_B \leq 500 \text{ } \Omega$



12 Load for a compact version without local operation

- 1 Operating range
- 1.1 For order code for "Output", option A "4-20 mA HART"/option B "4-20 mA HART, pulse/frequency/switch output" with Ex i and option C "4-20 mA HART + 4-20 mA analog"
- 1.2 For order code for "Output", option A "4-20 mA HART"/option B "4-20 mA HART, pulse/frequency/switch output" with non-Ex and Ex d

Sample calculation

Supply voltage of the supply unit:

– $U_S = 19 \text{ V}$

– $U_{\text{term. min}} = 12 \text{ V}$ (measuring device) + 1 V (local operation without lighting) = 13 V

Maximum load: $R_B \leq (19 \text{ V} - 13 \text{ V}): 0.022 \text{ A} = 273 \Omega$

 The minimum terminal voltage ($U_{\text{term. min}}$) increases if local operation is used (Verweisziel existiert nicht, aber @y.link.required=true).

7.1.5 Preparing the measuring device

1. Remove dummy plug if present.

2. **NOTICE**

Insufficient sealing of the housing!

Operational reliability of the measuring device could be compromised.

- ▶ Use suitable cable glands corresponding to the degree of protection.

If measuring device is delivered without cable glands:

Provide suitable cable gland for corresponding connecting cable .

3. If measuring device is delivered with cable glands:

Observe cable specification .

7.2 Connecting the measuring device**NOTICE****Limitation of electrical safety due to incorrect connection!**

- ▶ Have electrical connection work carried out by correspondingly trained specialists only.
- ▶ Observe applicable federal/national installation codes and regulations.
- ▶ Comply with local workplace safety regulations.
- ▶ For use in potentially explosive atmospheres, observe the information in the device-specific Ex documentation.

7.2.1 Connecting the remote version**⚠ WARNING****Risk of damaging the electronic components!**

- ▶ Ground the remote version and in doing so connect the sensor and transmitter to the same potential equalization.
- ▶ Only connect the sensor to a transmitter with the same serial number.

The following procedure (in the action sequence given) is recommended for the remote version:

1. Mount the transmitter and sensor.

2. Connect the connecting cable.

3. Connect the transmitter.

i The way the transmitter wall holder is connected depends on the measuring device approval and the version of the connecting cable used.

Connection is only possible via terminals:


- For approvals Ex n, Ex tb and cCSAus Div. 1
- If a reinforced connecting cable is used

The connection is via an M12 connector:


- For all other approvals
- If the standard connecting cable is used

Connection to the connection housing of the sensor is always via the terminals (tightening torque for terminals: 1.2 to 1.7 Nm).

Connecting the sensor connection housing



A0020410



A0020411

1. Loosen the securing clamp.
2. Unscrew the housing cover.
3. Guide the connecting cable through the cable entry and into the connection housing (if using a connecting cable without an M12 device plug, use the shorter stripped end of the connecting cable).

4. NOTICE**Terminals tightened with an incorrect tightening torque.**

Incorrect connection or damaged terminal.


- ▶ Tighten the terminals with a tightening torque in the 1.2 to 1.7 Nm range.

Wire the connecting cable:

- ↳ Terminal 1 = brown cable
- Terminal 2 = white cable
- Terminal 3 = yellow cable
- Terminal 4 = green cable

5. Connect the cable shield via the cable strain relief.**6.** Reverse the removal procedure to reassemble the transmitter.**Connection to the wall holder of the transmitter**


Connecting the transmitter via plug






A0020412


- ▶ Connect the plug.

Connecting the transmitter via terminals



A0020404






A0020409

1. Loosen the securing clamp of the transmitter housing.
2. Loosen the securing clamp of the electronics compartment cover.
3. Unscrew the electronics compartment cover.
4. Pull out the display module with a gentle rotational movement. To make it easier to access the lock switch, attach the display module to the edge of the electronics compartment.
5. Loosen the locking screw of the transmitter housing.
6. Turn the transmitter housing to the right until the mark and lift it up. The connection board of the wall housing is connected to the electronics board of the transmitter via a signal cable. Pay attention to the signal cable when lifting the transmitter housing!
7. Disconnect the signal cable from the connection board of the wall housing by pressing in the locking clip on the connector.
8. Remove the transmitter housing.
9. Guide the connecting cable through the cable entry and into the connection housing (if using a connecting cable without an M12 device plug, use the shorter stripped end of the connecting cable).
10. Wire the connecting cable:
 - ↳ Terminal 1 = brown cable
 - Terminal 2 = white cable
 - Terminal 3 = yellow cable
 - Terminal 4 = green cable
11. Connect the cable shield via the cable strain relief.
12. Reverse the removal procedure to reassemble the transmitter.

7.2.2 Connecting the transmitter

Connection via terminals



A0013836


1. Loosen the securing clamp of the connection compartment cover.
2. Unscrew the connection compartment cover.
3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
5. Connect the cable in accordance with the terminal assignment . For HART communication: when connecting the cable shielding to the ground terminal, observe the grounding concept of the facility.
6. Firmly tighten the cable glands.
7. **⚠ WARNING**

Housing degree of protection may be voided due to insufficient sealing of the housing.

- ▶ Screw in the screw without using any lubricant. The threads on the cover are coated with a dry lubricant.

Reverse the removal procedure to reassemble the transmitter.

Removing a cable



A0013835

- ▶ To remove a cable from the terminal, use a flat-blade screwdriver to push the slot between the two terminal holes while simultaneously pulling the cable end out of the terminal.

7.2.3 Ensuring potential equalization

Requirements

Please consider the following to ensure correct measurement:

- Same electrical potential for the fluid and sensor
- Remote version: same electrical potential for the sensor and transmitter
- Company-internal grounding concepts
- Pipe material and grounding




For devices intended for use in hazardous locations, please observe the guidelines in the Ex documentation (XA).

7.3 Special connection instructions

7.3.1 Connection examples

Current output 4-20 mA HART




A0015511

13 Connection example for 4-20 mA HART current output (passive)

- 1 Automation system with current input (e.g. PLC)
- 2 Active barrier for power supply with integrated resistor for HART communication ($\geq 250 \Omega$) (e.g. RN221N)
Connection for HART operating devices → 185
Observe the maximum load → 34
- 3 Cable shield, observe cable specifications
- 4 Analog display unit: observe maximum load → 34
- 5 Transmitter

Pulse/frequency output




A0016801

14 Connection example for pulse/frequency output (passive)

- 1 Automation system with pulse/frequency input (e.g. PLC)
- 2 Power supply
- 3 Transmitter: observe input values → 170

Switch output




A0016802

15 Connection example for switch output (passive)

- 1 Automation system with switch input (e.g. PLC)
- 2 Power supply
- 3 Transmitter: observe input values

Current input




A0020741

16 Connection example for 4-20 mA current input

- 1 Control system (e.g. PLC)
- 2 Power supply
- 3 External measuring device (for reading in pressure or temperature, for instance)
- 4 Transmitter: Observe input values → 168

HART input



A0016029

17 Connection example for HART input with a common negative


- 1 Automation system with HART output (e.g. PLC)
- 2 Resistor for HART communication ($\geq 250 \Omega$): observe maximum load → 34
- 3 Active barrier for power supply (e.g. RN221N)
- 4 Cable shield, observe cable specifications
- 5 Analog display unit: observe maximum load → 34
- 6 Pressure transmitter (e.g. Cerabar M, Cerabar S): see requirements
- 7 Transmitter

7.4 Ensuring the degree of protection

The measuring device fulfills all the requirements for the IP66/67 degree of protection, Type 4X enclosure.

To guarantee IP66/67 degree of protection, Type 4X enclosure, carry out the following steps after the electrical connection:


1. Check that the housing seals are clean and fitted correctly. Dry, clean or replace the seals if necessary.
2. Tighten all housing screws and screw covers.
3. Firmly tighten the cable glands.
4. To ensure that moisture does not enter the cable entry, route the cable so that it loops down before the cable entry ("water trap").



A0013960


5. Insert dummy plugs into unused cable entries.

7.5 Post-connection check

| | |
|--|--------------------------|
| Are cables or the device undamaged (visual inspection)? | <input type="checkbox"/> |
| Do the cables comply with the requirements ? | <input type="checkbox"/> |
| Do the cables have adequate strain relief? | <input type="checkbox"/> |
| Are all the cable glands installed, firmly tightened and leak-tight? Cable run with "water trap" →  43 ? | <input type="checkbox"/> |
| Depending on the device version: are all the device plugs firmly tightened ? | <input type="checkbox"/> |
| Does the supply voltage match the specifications on the transmitter nameplate ? | <input type="checkbox"/> |
| Is the terminal assignment correct ? | <input type="checkbox"/> |
| If supply voltage is present, do values appear on the display module? | <input type="checkbox"/> |
| Are all housing covers installed and firmly tightened? | <input type="checkbox"/> |
| Is the securing clamp tightened correctly? | <input type="checkbox"/> |

8 Operation options

8.1 Overview of operating options





A0015607


- 1 Local operation via display module
- 2 Computer with operating tool (e.g. FieldCare, AMS Device Manager, SIMATIC PDM)
- 3 Field Xpert SFX350 or SFX370
- 4 Field Communicator 475
- 5 Automation system (e.g. PLC)

8.2 Structure and function of the operating menu

8.2.1 Structure of the operating menu

 For an overview of the operating menu with menus and parameters



 18 Schematic structure of the operating menu

A0018237-EN


8.2.2 Operating philosophy

The individual parts of the operating menu are assigned to certain user roles (operator, maintenance etc.). Each user role contains typical tasks within the device lifecycle.

| Menu/parameter | | User role and tasks | Content/meaning |
|----------------|-------------------|--|--|
| Language | task-oriented | Role "Operator", "Maintenance" Tasks during operation: <ul style="list-style-type: none"> ▪ Configuring the operational display ▪ Reading measured values | Defining the operating language |
| Operation | | | <ul style="list-style-type: none"> ▪ Configuring the operational display (e.g. display format, display contrast) ▪ Resetting and controlling totalizers |
| Setup | | "Maintenance" role Commissioning: <ul style="list-style-type: none"> ▪ Configuration of the measurement ▪ Configuration of the inputs and outputs | Wizards for fast commissioning: <ul style="list-style-type: none"> ▪ Configure the outputs ▪ Configuring the operational display ▪ Define the output conditioning ▪ Set the low flow cut off Advanced setup <ul style="list-style-type: none"> ▪ For more customized configuration of the measurement (adaptation to special measuring conditions) ▪ Configuration of totalizers ▪ Administration (define access code, reset measuring device) |
| Diagnostics | | "Maintenance" role Fault elimination: <ul style="list-style-type: none"> ▪ Diagnostics and elimination of process and device errors ▪ Measured value simulation | Contains all parameters for error detection and analyzing process and device errors: <ul style="list-style-type: none"> ▪ Diagnostic list Contains up to 5 currently pending diagnostic messages. ▪ Event logbook Contains up to 20 or 100 (order option "Extended HistoROM") event messages that have occurred. ▪ Device information Contains information for identifying the device. ▪ Measured values Contains all current measured values. ▪ Data logging (Order option "Extended HistoROM") Storage and visualization of up to 1000 measured values ▪ Heartbeat The functionality of the device is checked on demand and the verification results are documented. ▪ Simulation Is used to simulate measured values or output values. |
| Expert | function-oriented | Tasks that require detailed knowledge of the function of the device: <ul style="list-style-type: none"> ▪ Commissioning measurements under difficult conditions ▪ Optimal adaptation of the measurement to difficult conditions ▪ Detailed configuration of the communication interface ▪ Error diagnostics in difficult cases | Contains all the parameters of the device and makes it possible to access these parameters directly using an access code. The structure of this menu is based on the function blocks of the device: <ul style="list-style-type: none"> ▪ System Contains all higher-order device parameters which do not concern the measurement or the communication interface. ▪ Sensor Configuration of the measurement. ▪ Input Configuration of the input. ▪ Output Configuration of the outputs. ▪ Communication Configuration of the digital communication interface. ▪ Application Configuration of the functions that go beyond the actual measurement (e.g. totalizer). ▪ Diagnostics Error detection and analysis of process and device errors and for device simulation and Heartbeat Technology. |

8.3 Access to the operating menu via the local display

8.3.1 Operational display




Status area

The following symbols appear in the status area of the operational display at the top right:

- Status signals → 139
 - **F**: Failure
 - **C**: Function check
 - **S**: Out of specification
 - **M**: Maintenance required
- Diagnostic behavior → 140
 - : Alarm
 - : Warning
- : Locking (the device is locked via the hardware)
- : Communication (communication via remote operation is active)

Display area

In the display area, each measured value is prefaced by certain symbol types for further description:



Measured variables

| Symbol | Meaning |
|--------|-------------|
| | Volume flow |

| | |
|--|---|
| | Totalizer The measurement channel number indicates which of the three totalizers is displayed. |
| | Output The measurement channel number indicates which of the two current outputs is displayed. |

Measurement channel numbers

| Symbol | Meaning |
|--------|----------------------------|
| | Measurement channel 1 to 4 |

The measurement channel number is displayed only if more than one channel is present for the same measured variable type (e.g. totalizer 1-3).

Diagnostic behavior

The diagnostic behavior pertains to a diagnostic event that is relevant to the displayed measured variable. For information on the symbols → 140

The number and display format of the measured values can be configured via the **"Format display" parameter** → 90. "Operation" menu → Display → Format display

8.3.2 Navigation view

| In the submenu | In the wizard |
|---|---------------|
| | |
| <p>1 Navigation view 2 Navigation path to current position 3 Status area 4 Display area for navigation 5 Operating elements → 53</p> | |

Navigation path

The navigation path - displayed at the top left in the navigation view - consists of the following elements:




| | | | |
|----------|--|--|---------|
| | Omission symbol for operating menu levels in between | Name of current <ul style="list-style-type: none"> ▪ Submenu ▪ Wizard ▪ Parameter | |
| | ↓ | ↓ | |
| Examples | | / .. / | Display |
| | | / .. / | Display |

 For more information about the menu icons, refer to the "Display area" section
 →  50

Status area





The following appears in the status area of the navigation view in the top right corner:

- Of the submenu
 - The direct access code for the parameter you are navigating to (e.g. 0022-1)
 - If a diagnostic event is present, the diagnostic behavior and status signal
- In the wizard
 - If a diagnostic event is present, the diagnostic behavior and status signal





-  ▪ For information on the diagnostic behavior and status signal →  139
- For information on the function and entry of the direct access code →  55

Display area


Menus

| Symbol | Meaning |
|---|--|
|  | Operation Appears: <ul style="list-style-type: none"> ▪ In the menu next to the "Operation" selection ▪ At the left in the navigation path in the "Operation" menu |
|  | Setup Appears: <ul style="list-style-type: none"> ▪ In the menu next to the "Setup" selection ▪ At the left in the navigation path in the "Setup" menu |
|  | Diagnostics Appears: <ul style="list-style-type: none"> ▪ In the menu next to the "Diagnostics" selection ▪ At the left in the navigation path in the "Diagnostics" menu |
|  | Expert Appears: <ul style="list-style-type: none"> ▪ In the menu next to the "Expert" selection ▪ At the left in the navigation path in the "Expert" menu |




Submenus, wizards, parameters

| Symbol | Meaning |
|---|--|
|  | Submenu |
|  | Wizard |
|  | Parameters within a wizard  No display symbol exists for parameters in submenus. |



Locking

| Symbol | Meaning |
|---|---|
|  | Parameter locked When displayed in front of a parameter name, indicates that the parameter is locked. <ul style="list-style-type: none"> ▪ By a user-specific access code ▪ By the hardware write protection switch |

Wizard operation

| Symbol | Meaning |
|---|--|
|  | Switches to the previous parameter. |
|  | Confirms the parameter value and switches to the next parameter. |
|  | Opens the editing view of the parameter. |









8.3.3 Editing view

| Numeric editor | Text editor |
|--|---|
|  |  |
| <p>1 Editing view 2 Display area of the entered values 3 Input mask 4 Operating elements → 53</p> | |












Input mask


The following input symbols are available in the input mask of the numeric and text editor:





Numeric editor

| Symbol | Meaning |
|---|--|
|  ...  | Selection of numbers from 0 to 9. |
|  | Inserts decimal separator at the input position. |
|  | Inserts minus sign at the input position. |
|  | Confirms selection. |
|  | Moves the input position one position to the left. |
|  | Exits the input without applying the changes. |
|  | Clears all entered characters. |








Text editor

| Symbol | Meaning |
|---|---|
|  | Toggle <ul style="list-style-type: none"> ▪ Between upper-case and lower-case letters ▪ For entering numbers ▪ For entering special characters |
|  ...  | Selection of letters from A to Z. |
|  ...  | Selection of letters from a to z. |
|  ...  | Selection of special characters. |
|  | Confirms selection. |
|  | Switches to the selection of the correction tools. |
|  | Exits the input without applying the changes. |
|  | Clears all entered characters. |

Correction symbols under 

| Symbol | Meaning |
|---|--|
|  | Clears all entered characters. |
|  | Moves the input position one position to the right. |
|  | Moves the input position one position to the left. |
|  | Deletes one character immediately to the left of the input position. |

8.3.4 Operating elements

| Key | Meaning |
|---|--|
|  | <p>Minus key</p> <p><i>In a menu, submenu</i> Moves the selection bar upwards in a choose list.</p> <p><i>With a Wizard</i> Confirms the parameter value and goes to the previous parameter.</p> <p><i>With a text and numeric editor</i> In the input mask, moves the selection bar to the left (backwards).</p> |
|  | <p>Plus key</p> <p><i>In a menu, submenu</i> Moves the selection bar downwards in a choose list.</p> <p><i>With a Wizard</i> Confirms the parameter value and goes to the next parameter.</p> <p><i>With a text and numeric editor</i> Moves the selection bar to the right (forwards) in an input screen.</p> |
|  | <p>Enter key</p> <p><i>For operational display</i></p> <ul style="list-style-type: none"> ▪ Pressing the key briefly opens the operating menu. ▪ Pressing the key for 2 s opens the context menu. <p><i>In a menu, submenu</i></p> <ul style="list-style-type: none"> ▪ Pressing the key briefly: <ul style="list-style-type: none"> - Opens the selected menu, submenu or parameter. - Starts the wizard. - If help text is open, closes the help text of the parameter. ▪ Pressing the key for 2 s for parameter: <ul style="list-style-type: none"> - If present, opens the help text for the function of the parameter. <p><i>With a Wizard</i> Opens the editing view of the parameter.</p> <p><i>With a text and numeric editor</i></p> <ul style="list-style-type: none"> ▪ Pressing the key briefly: <ul style="list-style-type: none"> - Opens the selected group. - Carries out the selected action. ▪ Pressing the key for 2 s confirms the edited parameter value. |
|  | <p>Escape key combination (press keys simultaneously)</p> <p><i>In a menu, submenu</i></p> <ul style="list-style-type: none"> ▪ Pressing the key briefly: <ul style="list-style-type: none"> - Exits the current menu level and takes you to the next higher level. - If help text is open, closes the help text of the parameter. ▪ Pressing the key for 2 s returns you to the operational display ("home position"). <p><i>With a Wizard</i> Exits the wizard and takes you to the next higher level.</p> <p><i>With a text and numeric editor</i> Closes the text or numeric editor without applying changes.</p> |
|  | <p>Minus/Enter key combination (press the keys simultaneously)</p> <p>Reduces the contrast (brighter setting).</p> |
|  | <p>Plus/Enter key combination (press and hold down the keys simultaneously)</p> <p>Increases the contrast (darker setting).</p> |
|  | <p>Minus/Plus/Enter key combination (press the keys simultaneously)</p> <p><i>For operational display</i> Enables or disables the keypad lock (only SD02 display module).</p> |

8.3.5 Opening the context menu


Using the context menu, the user can call up the following menus quickly and directly from the operational display:

- Setup
- Conf. backup disp.
- Simulation

Calling up and closing the context menu

The user is in the operational display.

1. Press \square for 2 s.
 - ↳ The context menu opens.



A0016326-EN

2. Press \square + \oplus simultaneously.
 - ↳ The context menu is closed and the operational display appears.

Calling up the menu via the context menu


1. Open the context menu.
2. Press \oplus to navigate to the desired menu.
3. Press \square to confirm the selection.
 - ↳ The selected menu opens.

8.3.6 Navigating and selecting from list

Different operating elements are used to navigate through the operating menu. The navigation path is displayed on the left in the header. Icons are displayed in front of the individual menus. These icons are also shown in the header during navigation.

i For an explanation of the navigation view with symbols and operating elements → 49

Example: Setting the number of displayed measured values to "2 values"



A0014010-EN


8.3.7 Calling the parameter directly

A parameter number is assigned to every parameter to be able to access a parameter directly via the onsite display. Entering this access code in the **Direct access** parameter calls up the desired parameter directly.

Navigation path

"Expert" menu → Direct access

The direct access code consists of a 4-digit number and the channel number, which identifies the channel of a process variable: e.g. 0914-1. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



A0017223

1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered.
Example: Input of "914" instead of "0914"
- If no channel number is entered, channel 1 is jumped to automatically.
Example: Input of "0914" → Parameter **Totalizer 1**
- If a different channel is jumped to: Enter the direct access code with the corresponding channel number.
Example: Input of "0914-2" → Parameter **Totalizer 2**



For the direct access codes of the individual parameters


8.3.8 Calling up help text

For some parameters, help texts exist, which the user can call up from the navigation view. These briefly describe the function of the parameter and thus support fast and reliable commissioning.

Calling up and closing the help text

The user is in the navigation view and the selection bar is on a parameter.

1. Press for 2 s.
 - ↳ The help text for the selected parameter opens.



A0014002-EN


19 Example: Help text for parameter "Enter access code"

2. Press + simultaneously.
 - ↳ The help text is closed.

8.3.9 Changing the parameters

i For a description of the editing display - consisting of text editor and numeric editor - with symbols → 51, for a description of the operating elements → 53

Example: Changing the tag name in the "Tag description" parameter from 001-FT-101 to 001-FT-102



A0014020-EN

8.3.10 User roles and related access authorization


The two user roles "Operator" and "Maintenance" have different write access to the parameters if the customer defines a user-specific access code. This protects the device configuration via the local display from unauthorized access .

Access authorization to parameters


| User role | Read access | | Write access | |
|-------------|--|------------------|--|------------------|
| | Without access code (from the factory) | With access code | Without access code (from the factory) | With access code |
| Operator | ✓ | ✓ | ✓ | -- 1) |
| Maintenance | ✓ | ✓ | ✓ | ✓ |

- 1) Despite the defined access code, certain parameters can always be modified and thus are excepted from the write protection, as they do not affect the measurement. Refer to the "Write protection via access code" section



If an incorrect access code is entered, the user obtains the access rights of the "Operator" role.

 The user role with which the user is currently logged on is indicated by the **Access status display** parameter. Navigation path: Operation → Access status display

8.3.11 Disabling write protection via access code

If the -symbol appears on the local display in front of a parameter, the parameter is write-protected by a user-specific access code and its value cannot be changed at the moment using the local display .


The locking of the write access via local operation can be disabled by entering the customer-defined access code via the respective access option.

1. After you press , the input prompt for the access code appears.
2. Enter the access code.
 - ↳ The -symbol in front of the parameters disappears; all previously write-protected parameters are now re-enabled.

8.3.12 Enabling and disabling the keypad lock




The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.


Local operation with mechanical push buttons (display module SD02)

 Display module SD02: order characteristic "Display; Operation", option C




The keypad lock is switched on and off in the same way:

Switching on the keypad lock


- ▶ The device is in the measured value display. Press the  +  +  keys simultaneously.
 - ↳ The message **Keylock on** appears on the display: The keypad lock is switched on.

 If the user attempts to access the operating menu while the keypad lock is active, the message **Keylock on** appears.

Switching off the keypad lock

- ▶ The keypad lock is switched on.
Press the  +  +  keys simultaneously.
 - ↳ The message **Keylock off** appears on the display: The keypad lock is switched off.

Local operation with touch control (display module SD03)


 Display module SD03: Order characteristic "Display; Operation", option **E**

The keypad lock is switched on and off via the context menu.

Switching on the keypad lock


The keypad lock is switched on automatically:

- Each time the device is restarted.
- If the device has not been operated for longer than one minute in the measured value display.

1. The device is in the measured value display.
Press the  key for longer than 2 seconds.
 - ↳ A context menu appears.
2. In the context menu, select the **Keylock on** option.
 - ↳ The keypad lock is switched on.

 If the user attempts to access the operating menu while the keypad lock is active, the message **Keylock on** appears.

Switching off the keypad lock


1. The keypad lock is switched on.
Press the  key for longer than 2 seconds.
 - ↳ A context menu appears.
2. In the context menu, select the **Keylock off** option.
 - ↳ The keypad lock is switched off.

8.4 Access to the operating menu via the operating tool

The structure of the operating menu in the operating tools is the same as for operation via the local display.

8.4.1 Connecting the operating tool

Via service interface (CDI)



- 1 Service interface (CDI = Endress+Hauser Common Data Interface) of the measuring device
 2 Commubox FXA291
 3 Computer with "FieldCare" operating tool with COM DTM "CDI Communication FXA291"

A0020545

8.4.2 Field Xpert SFX350, SFX370

Function scope

Field Xpert SFX350 and Field Xpert SFX370 are mobile computers for commissioning and maintenance. They enable efficient device configuration and diagnostics for HART and FOUNDATION fieldbus devices in the **non-Ex area** (SFX350, SFX370) and the **Ex area** (SFX370).



For details, see Operating Instructions BA01202S

Source for device description files

See data → 63

8.4.3 FieldCare

Function scope

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access is via:

- HART protocol
- Service interface CDI → 60

Typical functions:

- Configuring parameters of transmitters
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook



For additional information about FieldCare, see Operating Instructions BA00027S and BA00059S

Source for device description files


See information → 63

Establishing a connection



For additional information, see Operating Instructions BA00027S and BA00059S

User interface



A0021051-EN


- 1 Header
- 2 Picture of device
- 3 Device name
- 4 Tag name
- 5 Status area with status signal
- 6 Display area for current measured values
- 7 Edit toolbar with additional functions such as save/restore, event list and create documentation
- 8 Navigation area with operating menu structure
- 9 Working area
- 10 Range of action
- 11 Status area

8.4.4 AMS Device Manager

Function scope

Program from Emerson Process Management for operating and configuring measuring devices via HART protocol.

Source for device description files


See data →  63

8.4.5 SIMATIC PDM

Function scope

SIMATIC PDM is a standardized, manufacturer-independent program from Siemens for the operation, configuration, maintenance and diagnosis of intelligent field devices via HART protocol.

Source for device description files


See data →  63

8.4.6 Field Communicator 475

Function scope

Industrial handheld terminal from Emerson Process Management for remote configuration and measured value display via HART protocol.

Source for device description files

See data →  63

9 System integration

9.1 Overview of device description files

9.1.1 Current version data for the device

| | | |
|----------------------------------|----------|---|
| Firmware version | 01.02.00 | <ul style="list-style-type: none"> ▪ On the title page of the Operating instructions ▪ On transmitter nameplate ▪ Firmware version parameter "Diagnostics" menu → Device information → Firmware version |
| Release date of firmware version | 10.2014 | --- |
| Manufacturer ID | 0x11 | Manufacturer ID parameter "Diagnostics" menu → Device information → Manufacturer ID |
| Device type ID | 0x38 | Device type parameter "Diagnostics" menu → Device information → Device type |
| HART protocol revision | 7 | --- |
| Device revision | 3 | <ul style="list-style-type: none"> ▪ On transmitter nameplate ▪ Device revision parameter "Diagnostics" menu → Device information → Device revision |

 For an overview of the different firmware versions for the device →  154

9.1.2 Operating tools

The suitable device description file for the individual operating tools is listed in the table below, along with information on where the file can be acquired.

| Operating tool via HART protocol | Sources for obtaining device descriptions |
|--|---|
| <ul style="list-style-type: none"> ▪ Field Xpert SFX350 ▪ Field Xpert SFX370 | Use update function of handheld terminal |
| FieldCare | <ul style="list-style-type: none"> ▪ www.endress.com → Download Area ▪ CD-ROM (contact Endress+Hauser) ▪ DVD (contact Endress+Hauser) |
| AMS Device Manager (Emerson Process Management) | www.endress.com → Download Area |
| SIMATIC PDM (Siemens) | www.endress.com → Download Area |
| Field Communicator 475 (Emerson Process Management) | Use update function of handheld terminal |

9.2 Measured variables via HART protocol

The following measured variables (HART device variables) are assigned to the dynamic variables at the factory:

| Dynamic variables | Measured variables (HART device variables) |
|---------------------------------|---|
| Primary dynamic variable (PV) | Volume flow |
| Secondary dynamic variable (SV) | Temperature |

| Dynamic variables | Measured variables (HART device variables) |
|----------------------------------|---|
| Tertiary dynamic variable (TV) | Totalizer 1 |
| Quaternary dynamic variable (QV) | Totalizer 2 |

The assignment of the measured variables to the dynamic variables can be modified and assigned as desired via local operation and the operating tool using the following parameters:

- Expert → Communication → HART output → Output → Assign PV
- Expert → Communication → HART output → Output → Assign SV
- Expert → Communication → HART output → Output → Assign TV
- Expert → Communication → HART output → Output → Assign QV


The following measured variables can be assigned to the dynamic variables:

Measured variables for PV (primary dynamic variable)

- Volume flow
- Corrected volume flow
- Mass flow
- Flow velocity
- Temperature
- Calculated saturated steam pressure
- Steam quality
- Total mass flow
- Energy flow
- Heat flow difference

Measured variables for SV, TV, QV (secondary, tertiary and quaternary dynamic variable)

- Volume flow
- Corrected volume flow
- Mass flow
- Flow velocity
- Temperature
- Calculated saturated steam pressure
- Steam quality
- Total mass flow
- Energy flow
- Heat flow difference
- Condensate mass flow
- Reynolds number
- Totalizer 1 to 3
- HART input
- Density
- Pressure
- Specific volume
- Degree of overheating

 The range of options increases if the measuring device has one or more application packages.

Device variables

The device variables are permanently assigned. A maximum of 8 device variables can be transmitted:

- 0 = volume flow
- 1 = corrected volume flow
- 2 = Mass flow
- 3 = flow velocity
- 4 = temperature

- 5 = calculated saturated steam pressure
- 6 = steam quality
- 7 = total mass flow
- 8 = energy flow
- 9 = heat flow difference
- 10 = condensate mass flow
- 11 = Reynolds number
- 12 = totalizer 1
- 13 = totalizer 2
- 14 = totalizer 3

9.3 Other settings

9.3.1 Burst mode functionality in accordance with HART 7 Specification

Navigation

"Expert" menu → Communication → HART output → Burst configuration → Burst configuration 1 to 3

The screenshot shows a hierarchical menu structure for burst configuration. At the top is a grey button labeled '► Burst configuration'. Below it is another grey button labeled '► Burst configuration 1 to 3'. Underneath this, there is a vertical list of ten white rectangular buttons with black text, each representing a different configuration parameter:

- Burst mode 1 to 3
- Burst command 1 to 3
- Burst variable 0
- Burst variable 1
- Burst variable 2
- Burst variable 3
- Burst variable 4
- Burst variable 5
- Burst variable 6
- Burst variable 7
- Burst trigger mode
- Burst trigger level

| |
|--------------------|
| Min. update period |
| Max. update period |

Parameter overview with brief description

| Parameter | Description | Selection / User entry | Factory setting |
|----------------------|--|---|-----------------|
| Burst mode 1 to 3 | Activate the HART burst mode for burst message X. | <ul style="list-style-type: none"> ■ Off ■ On | Off |
| Burst command 1 to 3 | Select the HART command that is sent to the HART master. | <ul style="list-style-type: none"> ■ Command 1 ■ Command 2 ■ Command 3 ■ Command 9 ■ Command 33 ■ Command 48 | Command 2 |
| Burst variable 0 | | <ul style="list-style-type: none"> ■ Volume flow ■ Corrected volume flow ■ Mass flow ■ Flow velocity ■ Temperature ■ Calculated saturated steam pressure * ■ Steam quality * ■ Total mass flow * ■ Energy flow * ■ Heat flow difference * ■ Condensate mass flow * ■ Reynolds number * ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ HART input ■ Density * ■ Pressure * ■ Specific volume * ■ Degrees of superheat * ■ Percent Of Range ■ Measured current ■ Primary variable (PV) ■ Secondary variable (SV) ■ Tertiary variable (TV) ■ Quaternary variable (QV) ■ Not used | Volume flow |
| Burst variable 1 | | See the Burst variable 0 parameter. | Not used |
| Burst variable 2 | | See the Burst variable 0 parameter. | Not used |
| Burst variable 3 | | See the Burst variable 0 parameter. | Not used |
| Burst variable 4 | | See the Burst variable 0 parameter. | Not used |
| Burst variable 5 | | See the Burst variable 0 parameter. | Not used |
| Burst variable 6 | | See the Burst variable 0 parameter. | Not used |
| Burst variable 7 | | See the Burst variable 0 parameter. | Not used |

| Parameter | Description | Selection / User entry | Factory setting |
|---------------------|--|--|-----------------|
| Burst trigger mode | Select the event that triggers burst message X. | <ul style="list-style-type: none"> ■ Continuous ■ Window ■ Rising ■ Falling ■ On change | Continuous |
| Burst trigger level | Enter the burst trigger value. Together with the option selected in the Burst trigger mode parameter the burst trigger value determines the time of burst message X. | Positive floating-point number | – |
| Min. update period | | Positive integer | 1 000 ms |
| Max. update period | | Positive integer | 2 000 ms |

* Visibility depends on order options or device settings

10 Commissioning

10.1 Function check

Before commissioning the measuring device:

- ▶ Make sure that the post-installation and post-connection checks have been performed.
 - "Post-installation check" checklist → 28
 - "Post-connection check" checklist → 44


10.2 Switching on the measuring device

- ▶ After a successful function check, switch on the measuring device.
 - ↳ After a successful startup, the local display switches automatically from the startup display to the operational display.

If nothing appears on the local display or a diagnostic message is displayed, refer to the section on "Diagnostics and troubleshooting" → 137.

10.3 Setting the operating language

Factory setting: English or ordered local language




20 Taking the example of the local display

A0013996

10.4 Configuring the measuring device

- The **Setup** menu with its guided wizards contains all the parameters needed for standard operation.
- Navigation to the **Setup** menu



A0014007-EN


21 Taking the example of the local display

Overview of the wizards in the "Setup" menu

| 🔧 Setup | |
|---------------------------------|--------|
| Device tag | → 📖 70 |
| ▶ Medium selection | → 📖 71 |
| ▶ Current input | → 📖 73 |
| ▶ Current output 1 to 2 | → 📖 76 |
| ▶ Pulse/frequency/switch output | → 📖 79 |
| ▶ Display | → 📖 90 |
| ▶ Output conditioning | → 📖 92 |
| ▶ Low flow cut off | → 📖 93 |
| ▶ Advanced setup | → 📖 95 |

10.4.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.



A0013375

22 Header of the operational display with tag name

1 Device tag

-  The number of characters displayed depends on the characters used.
- Enter the tag name in the "FieldCare" operating tool →  61

Navigation

"Setup" menu → Device tag

Parameter overview with brief description

| Parameter | Description | User entry | Factory setting |
|------------|---|---|-----------------|
| Device tag | Enter the name for the measuring point. | Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /). | Prowirl |


10.4.2 Selecting and setting the medium

The **Medium selection** wizard guides you systematically through all the parameters that have to be configured for selecting and setting the medium.

Navigation

"Setup" menu → Medium selection

Structure of the wizard





A0020776-EN

23 "Medium selection" wizard in the "Setup" menu

Parameter overview with brief description


| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------------|--|---------------------------|--|-------------------|
| Select medium | - | Select medium type. | <ul style="list-style-type: none"> ■ Gas ■ Liquid ■ Steam | Steam |
| Select gas type | The following conditions are met: <ul style="list-style-type: none"> ■ Order code <ul style="list-style-type: none"> - "Sensor version", option "Mass flow" - "Application package", option "Air + Industrial gases" or option "Natural gas" ■ The Gas option is selected in the Select medium parameter. | Select measured gas type. | <ul style="list-style-type: none"> ■ Single gas ■ Gas mixture ■ Air ■ Natural gas ■ User-specific gas | User-specific gas |


| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|------------------------|--|--|--|-----------------|
| Select liquid type | The following conditions are met: <ul style="list-style-type: none"> Order code for "Sensor version", option "Mass flow" The Liquid option is selected in the Select medium parameter. | Select measured liquid type. | <ul style="list-style-type: none"> Water LPG ((liquefied petroleum gas)) User-specific liquid | Water |
| Select steam type | The following conditions are met: <ul style="list-style-type: none"> Order code for "Sensor version", option "Mass flow (integrated temperature measurement)" In the Select medium parameter, the Steam option is selected. | Select measured steam type. | <ul style="list-style-type: none"> Wet steam Superheated steam Saturated steam | Saturated steam |
| Fixed process pressure | The following conditions are met: <ul style="list-style-type: none"> Order code for "Sensor version", option "Mass flow (integrated temperature measurement)" In the External value parameter (→ 74), the Pressure option is not selected. | Enter fixed value for process pressure. <i>Dependency</i> The unit is taken from the Pressure unit parameter  For detailed information on the calculation of the measured variables with steam: → 165  For detailed information on setting the parameter in steam applications, see the Special Documentation for the Wet Steam Detection and Wet Steam Measurement → 189 application package. | 0 to 250 bar abs. | 0 bar abs. |
| Enthalpy calculation | The following conditions are met: <ul style="list-style-type: none"> Order code <ul style="list-style-type: none"> "Sensor version", option "Mass flow (integrated temperature measurement)" "Application package", option "Natural gas" In the Select medium parameter, the Gas option is selected and in the Select gas type parameter, the Natural gas option is selected. | Select the norm the enthalpy calculation is based on. | <ul style="list-style-type: none"> AGA5 ISO 6976 | AGA5 |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|---------------------|--|--|--|-----------------|
| Density calculation | The following conditions are met: <ul style="list-style-type: none"> In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. | Select the norm the density calculation is based on. | <ul style="list-style-type: none"> AGA Nx19 ISO 12213- 2 ISO 12213- 3 | AGA Nx19 |
| Enthalpy type | The following conditions are met: <ul style="list-style-type: none"> In the Select gas type parameter, the User-specific gas option is selected. Or <ul style="list-style-type: none"> In the Select liquid type parameter, the User-specific liquid option is selected. | Define which kind of enthalpy is used. | <ul style="list-style-type: none"> Heat Calorific value | Heat |

10.4.3 Configuring the current input

The **"Current input"** submenu guides you systematically through all the parameters that have to be set for configuring the current input.

 The **Fixed process pressure** parameter is set to the value **0 bar abs.** (ex works). In this case, the measuring device ignores the pressure read in via the current input. For the measuring device to use the external (read-in) pressure, a value > 0 bar abs. must be entered in the **Fixed process pressure** parameter.

For a detailed description of how to calculate the mass flow and energy flow:
 →  164

Navigation





"Setup" menu → Current input

Structure of the submenu

▶ Current input

| |
|---------------|
| Failure mode |
| Failure value |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|----------------------|--|---|--|---|
| External value | For the following order code: "Sensor version", option "Mass flow" | <p>Assign variable from external device to process variable.</p> <p> For detailed information on the calculation of the measured variables with steam: →  165</p> <p> For detailed information on setting the parameter in steam applications, see the Special Documentation for the Wet Steam Detection and Wet Steam Measurement →  189 application package.</p> | <ul style="list-style-type: none"> ▪ Off ▪ Pressure ▪ Relative pressure ▪ Density ▪ Temperature ▪ 2nd temperature delta heat | Off |
| Pressure unit | For the following order code: "Sensor version", option "Mass flow" | <p>Select process pressure unit.</p> <p><i>Effect</i></p> <p>The unit is taken from the:</p> <ul style="list-style-type: none"> ▪ Calculated saturated steam pressure ▪ Atmospheric pressure ▪ Maximum value ▪ Fixed process pressure ▪ Pressure ▪ Reference pressure | Unit choose list | Country-specific: <ul style="list-style-type: none"> ▪ bar ▪ psi |
| Atmospheric pressure | – | Enter atmospheric pressure value to be used for pressure correction. | 0 to 250 bar | 1.01325 bar |
| Temperature unit | – | <p>Select temperature unit.</p> <p><i>Effect</i></p> <p>The selected unit applies for:</p> <ul style="list-style-type: none"> ▪ Temperature ▪ Maximum value ▪ Minimum value ▪ Average value ▪ Maximum value ▪ Minimum value ▪ Maximum value ▪ Minimum value ▪ 2nd temperature delta heat ▪ Fixed temperature ▪ Reference combustion temperature ▪ Reference temperature ▪ Saturation temperature | Unit choose list | Country-specific: <ul style="list-style-type: none"> ▪ °C ▪ °F |
| Density unit | – | <p>Select density unit.</p> <p><i>Effect</i></p> <p>The selected unit applies for:</p> <ul style="list-style-type: none"> ▪ Output ▪ Simulation process variable | Unit choose list | Country-specific: <ul style="list-style-type: none"> ▪ kg/m³ ▪ lb/ft³ |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|---------------|--|---|--|---|
| Current span | – | Select current range for process value output and upper/lower level for alarm signal. | <ul style="list-style-type: none"> ■ 4...20 mA ■ 4...20 mA NAMUR ■ 4...20 mA US | Country-specific: <ul style="list-style-type: none"> ■ 4...20 mA NAMUR ■ 4...20 mA US |
| 4 mA value | – | Enter 4 mA value. | Signed floating-point number | 0 |
| 20 mA value | – | Enter 20 mA value. | Signed floating-point number | Depends on country and nominal diameter |
| Failure mode | – | Define input behavior in alarm condition. | <ul style="list-style-type: none"> ■ Alarm ■ Last valid value ■ Defined value | Alarm |
| Failure value | In the Failure mode parameter, the Defined value option is selected. | Enter value to be used by the device if input value from external device is missing. | Signed floating-point number | 0 |


10.4.4 Configuring the current output

The "Current output 1 to 2" wizard guides you systematically through all the parameters that have to be set for configuring the specific current output.

Navigation

"Setup" menu → Current output 1 to 2

Structure of the wizard







A0020788-EN

24 "Current output 1 to 2" wizard in the "Setup" menu

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|----------------------------|--|--|--|---|
| Assign current output | – | Select process variable for current output. | <ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Corrected volume flow ■ Mass flow ■ Flow velocity ■ Temperature ■ Calculated saturated steam pressure[*] ■ Steam quality[*] ■ Total mass flow[*] ■ Energy flow[*] ■ Heat flow difference[*] | Volume flow |
| Mass flow unit | – | Select mass flow unit. <i>Effect</i> The selected unit applies for: <ul style="list-style-type: none"> ■ Output ■ Low flow cut off ■ Simulation process variable | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ kg/h ■ lb/min |
| Volume flow unit | – | Select volume flow unit. <i>Effect</i> The selected unit applies for: <ul style="list-style-type: none"> ■ Output ■ Low flow cut off ■ Simulation process variable | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ m³/h ■ ft³/min |
| Corrected volume flow unit | – | Select corrected volume flow unit. <i>Effect</i> The selected unit applies for: Corrected volume flow | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ Nm³/h ■ Sft³/h |
| Temperature unit | – | Select temperature unit. <i>Effect</i> The selected unit applies for: <ul style="list-style-type: none"> ■ Temperature ■ Maximum value ■ Minimum value ■ Average value ■ Maximum value ■ Minimum value ■ Maximum value ■ Minimum value ■ 2nd temperature delta heat ■ Fixed temperature ■ Reference combustion temperature ■ Reference temperature ■ Saturation temperature | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ °C ■ °F |
| Energy flow unit | For the following order code: "Sensor version", option "Mass flow" | Select energy flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> ■ Outputs ■ Low flow cut off | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ kW ■ Btu/h |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------------|---|---|---|--|
| Pressure unit | For the following order code: "Sensor version", option "Mass flow" | Select process pressure unit. <i>Effect</i> The unit is taken from the: <ul style="list-style-type: none"> ▪ Calculated saturated steam pressure ▪ Atmospheric pressure ▪ Maximum value ▪ Fixed process pressure ▪ Pressure ▪ Reference pressure | Unit choose list | Country-specific: <ul style="list-style-type: none"> ▪ bar ▪ psi |
| Velocity unit | – | Select velocity unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> ▪ Flow velocity ▪ Maximum value | Unit choose list | Country-specific: <ul style="list-style-type: none"> ▪ m/s ▪ ft/s |
| Current span | – | Select current range for process value output and upper/lower level for alarm signal. | <ul style="list-style-type: none"> ▪ 4...20 mA NAMUR ▪ 4...20 mA US ▪ 4...20 mA ▪ Fixed current | Country-specific: <ul style="list-style-type: none"> ▪ 4...20 mA NAMUR ▪ 4...20 mA US |
| 4 mA value | In the Current span parameter (→  78), one of the following options is selected: <ul style="list-style-type: none"> ▪ 4...20 mA NAMUR ▪ 4...20 mA US ▪ 4...20 mA | Enter 4 mA value. | Signed floating-point number | Country-specific: <ul style="list-style-type: none"> ▪ 0 m³/h ▪ 0 ft³/min |
| 20 mA value | In the Current span parameter (→  78), one of the following options is selected: <ul style="list-style-type: none"> ▪ 4...20 mA NAMUR ▪ 4...20 mA US ▪ 4...20 mA | Enter 20 mA value. | Signed floating-point number | Depends on country and nominal diameter |
| Failure mode | In the Assign current output parameter (→  77), one of the following options is selected: <ul style="list-style-type: none"> ▪ Volume flow ▪ Corrected volume flow ▪ Mass flow ▪ Flow velocity ▪ Temperature ▪ Calculated saturated steam pressure ▪ Steam quality * ▪ Total mass flow * ▪ Energy flow * ▪ Heat flow difference * In the Current span parameter (→  78), one of the following options is selected: <ul style="list-style-type: none"> ▪ 4...20 mA NAMUR ▪ 4...20 mA US ▪ 4...20 mA | Define output behavior in alarm condition. | <ul style="list-style-type: none"> ▪ Min. ▪ Max. ▪ Last valid value ▪ Actual value ▪ Defined value | Max. |
| Failure current | The Defined value option is selected in the Failure mode parameter. | Enter current output value in alarm condition. | 3.59 to 22.5 mA | 22.5 mA |

* Visibility depends on order options or device settings

10.4.5 Configuring the pulse/frequency/switch output


The **Pulse/frequency/switch output** wizard guides you systematically through all the parameters that can be set for configuring the selected output type.

Configuring the pulse output

Navigation

"Setup" menu → Pulse/frequency/switch output

Structure of the wizard for the pulse output



A0020792-EN

25 "Pulse/frequency/switch output" wizard in the "Setup" menu: "Operating mode" parameter "Pulse" option

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------------------|--|---|--|---|
| Operating mode | – | Define the output as a pulse, frequency or switch output. | <ul style="list-style-type: none"> ■ Pulse ■ Frequency ■ Switch | Pulse |
| Assign pulse output | The Pulse option is selected in the Operating mode parameter. | Select process variable for pulse output. | <ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Corrected volume flow ■ Mass flow ■ Total mass flow * ■ Energy flow * ■ Heat flow difference * | Volume flow |
| Mass unit | – | Select mass unit. | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ kg ■ lb |
| Volume unit | – | Select volume unit. | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ m³ ■ ft³ |
| Corrected volume unit | – | Select corrected volume unit. | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ Nm³ ■ Sft³ |
| Energy unit | For the following order code: "Sensor version", option "Mass flow" | Select energy unit. | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ kWh ■ Btu |
| Value per pulse | The Pulse option is selected in the Operating mode parameter, and one of the following options is selected in the Assign pulse output parameter (→ 80): <ul style="list-style-type: none"> ■ Volume flow ■ Corrected volume flow ■ Mass flow ■ Total mass flow * ■ Energy flow * ■ Heat flow difference * | Enter measured value at which a pulse is output. | Positive floating-point number | Depends on country and nominal diameter |
| Pulse width | In the Operating mode parameter, the Pulse option is selected and one of the following options is selected in the Assign pulse output parameter (→ 80): <ul style="list-style-type: none"> ■ Volume flow ■ Corrected volume flow ■ Mass flow ■ Total mass flow * ■ Energy flow * ■ Heat flow difference * | Define time width of the output pulse. | 5 to 2 000 ms | 100 ms |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|----------------------|--|--|---|-----------------|
| Failure mode | In the Operating mode parameter, the Pulse option is selected and one of the following options is selected in the Assign pulse output parameter (→ 80): <ul style="list-style-type: none"> ■ Volume flow ■ Corrected volume flow ■ Mass flow ■ Total mass flow * ■ Energy flow * ■ Heat flow difference * | Define output behavior in alarm condition. | <ul style="list-style-type: none"> ■ Actual value ■ No pulses | No pulses |
| Invert output signal | – | Invert the output signal. | <ul style="list-style-type: none"> ■ No ■ Yes | No |


* Visibility depends on order options or device settings

Configuring the frequency output

Navigation

"Setup" menu → Pulse/frequency/switch output


Structure of the wizard for the frequency output





A0020789-EN

26 "Pulse/frequency/switch output" wizard in the "Setup" menu: "Operating mode" parameter "Frequency" option

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|----------------------------|--|--|--|---|
| Operating mode | – | Define the output as a pulse, frequency or switch output. | <ul style="list-style-type: none"> ■ Pulse ■ Frequency ■ Switch | Pulse |
| Assign frequency output | The Frequency option is selected in the Operating mode parameter (→  80). | Select process variable for frequency output. | <ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Corrected volume flow ■ Mass flow ■ Flow velocity ■ Temperature ■ Calculated saturated steam pressure[*] ■ Steam quality[*] ■ Total mass flow[*] ■ Energy flow[*] ■ Heat flow difference[*] | Off |
| Mass flow unit | – | Select mass flow unit. <i>Effect</i> The selected unit applies for: <ul style="list-style-type: none"> ■ Output ■ Low flow cut off ■ Simulation process variable | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ kg/h ■ lb/min |
| Volume flow unit | – | Select volume flow unit. <i>Effect</i> The selected unit applies for: <ul style="list-style-type: none"> ■ Output ■ Low flow cut off ■ Simulation process variable | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ m³/h ■ ft³/min |
| Corrected volume flow unit | – | Select corrected volume flow unit. <i>Effect</i> The selected unit applies for: Corrected volume flow | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ Nm³/h ■ Sft³/h |
| Energy flow unit | For the following order code: "Sensor version", option "Mass flow" | Select energy flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> ■ Outputs ■ Low flow cut off | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ kW ■ Btu/h |
| Pressure unit | For the following order code: "Sensor version", option "Mass flow" | Select process pressure unit. <i>Effect</i> The unit is taken from the: <ul style="list-style-type: none"> ■ Calculated saturated steam pressure ■ Atmospheric pressure ■ Maximum value ■ Fixed process pressure ■ Pressure ■ Reference pressure | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ bar ■ psi |
| Velocity unit | – | Select velocity unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> ■ Flow velocity ■ Maximum value | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ m/s ■ ft/s |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-------------------------|---|---|------------------------|---|
| Temperature unit | – | Select temperature unit. <i>Effect</i> The selected unit applies for: <ul style="list-style-type: none"> ■ Temperature ■ Maximum value ■ Minimum value ■ Average value ■ Maximum value ■ Minimum value ■ Maximum value ■ Minimum value ■ 2nd temperature delta heat ■ Fixed temperature ■ Reference combustion temperature ■ Reference temperature ■ Saturation temperature | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ °C ■ °F |
| Minimum frequency value | The Frequency option is selected in the Operating mode parameter, and one of the following options is selected in the Assign frequency output parameter (→  83): <ul style="list-style-type: none"> ■ Volume flow ■ Corrected volume flow ■ Mass flow ■ Flow velocity ■ Temperature ■ Calculated saturated steam pressure * ■ Steam quality * ■ Total mass flow * ■ Energy flow * ■ Heat flow difference * | Enter minimum frequency. | 0 to 1 000 Hz | 0 Hz |
| Maximum frequency value | The Frequency option is selected in the Operating mode parameter, and one of the following options is selected in the Assign frequency output parameter (→  83): <ul style="list-style-type: none"> ■ Volume flow ■ Corrected volume flow ■ Mass flow ■ Flow velocity ■ Temperature ■ Calculated saturated steam pressure * ■ Steam quality * ■ Total mass flow * ■ Energy flow * ■ Heat flow difference * | Enter maximum frequency. | 0 to 1 000 Hz | 1 000 Hz |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|--------------------------------------|---|---|---|---|
| Measuring value at minimum frequency | The Frequency option is selected in the Operating mode parameter, and one of the following options is selected in the Assign frequency output parameter (→ 83): <ul style="list-style-type: none"> ▪ Volume flow ▪ Corrected volume flow ▪ Mass flow ▪ Flow velocity ▪ Temperature ▪ Calculated saturated steam pressure * ▪ Steam quality * ▪ Total mass flow * ▪ Energy flow * ▪ Heat flow difference * | Enter measured value for minimum frequency. | Signed floating-point number | Depends on country and nominal diameter |
| Measuring value at maximum frequency | The Frequency option is selected in the Operating mode parameter, and one of the following options is selected in the Assign frequency output parameter (→ 83): <ul style="list-style-type: none"> ▪ Volume flow ▪ Corrected volume flow ▪ Mass flow ▪ Flow velocity ▪ Temperature ▪ Calculated saturated steam pressure * ▪ Steam quality * ▪ Total mass flow * ▪ Energy flow * ▪ Heat flow difference * | Enter measured value for maximum frequency. | Signed floating-point number | Depends on country and nominal diameter |
| Failure mode | The Frequency option is selected in the Operating mode parameter (→ 80), and one of the following options is selected in the Assign frequency output parameter (→ 83): <ul style="list-style-type: none"> ▪ Volume flow ▪ Corrected volume flow ▪ Mass flow ▪ Flow velocity ▪ Temperature ▪ Calculated saturated steam pressure * ▪ Steam quality * ▪ Total mass flow * ▪ Energy flow * ▪ Heat flow difference * | Define output behavior in alarm condition. | <ul style="list-style-type: none"> ▪ Actual value ▪ Defined value ▪ 0 Hz | 0 Hz |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|----------------------|---|--|---|-----------------|
| Failure frequency | The Frequency option is selected in the Operating mode parameter (→ 80), and one of the following options is selected in the Assign frequency output parameter (→ 83): <ul style="list-style-type: none"> ▪ Volume flow ▪ Corrected volume flow ▪ Mass flow ▪ Flow velocity ▪ Temperature ▪ Calculated saturated steam pressure * ▪ Steam quality * ▪ Total mass flow * ▪ Energy flow * ▪ Heat flow difference * | Enter frequency output value in alarm condition. | 0.0 to 1 250.0 Hz | 0.0 Hz |
| Invert output signal | – | Invert the output signal. | <ul style="list-style-type: none"> ▪ No ▪ Yes | No |


* Visibility depends on order options or device settings

Configuring the switch output

Navigation


"Setup" menu → Pulse/frequency/switch output

Structure of the wizard for the switch output



A0017439-EN

27 "Pulse/frequency/switch output" wizard in the "Setup" menu: "Operating mode" parameter "Switch" option (part 1)



A0020794-EN

28 "Pulse/frequency/switch output" wizard in the "Setup" menu: "Operating mode" parameter "Switch" option (part 2)

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|------------------------|--|---|---|-----------------|
| Operating mode | - | Define the output as a pulse, frequency or switch output. | <ul style="list-style-type: none"> ■ Pulse ■ Frequency ■ Switch | Pulse |
| Switch output function | The Switch option is selected in the Operating mode parameter. | Select function for switch output. | <ul style="list-style-type: none"> ■ Off ■ On ■ Diagnostic behavior ■ Limit ■ Status | Off |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------------------------|--|---|---|---|
| Assign diagnostic behavior | <ul style="list-style-type: none"> The Switch option is selected in the Operating mode parameter. The Diagnostic behavior option is selected in the Switch output function parameter. | Select diagnostic behavior for switch output. | <ul style="list-style-type: none"> Alarm Alarm or warning Warning | Alarm |
| Assign limit | <ul style="list-style-type: none"> The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. | Select process variable for limit function. | <ul style="list-style-type: none"> Volume flow Corrected volume flow Mass flow Flow velocity Temperature Calculated saturated steam pressure * Steam quality * Total mass flow * Energy flow * Heat flow difference * Reynolds number * Totalizer 1 Totalizer 2 Totalizer 3 | Volume flow |
| Assign flow direction check | <ul style="list-style-type: none"> The Switch option is selected in the Operating mode parameter. The Flow direction check option is selected in the Switch output function parameter. | Select process variable for flow direction monitoring. | <ul style="list-style-type: none"> Off Volume flow Mass flow Corrected volume flow | Volume flow |
| Assign status | <ul style="list-style-type: none"> The Switch option is selected in the Operating mode parameter. The Status option is selected in the Switch output function parameter. | Select device status for switch output. | Low flow cut off | Low flow cut off |
| Mass flow unit | – | Select mass flow unit. <i>Effect</i> The selected unit applies for: <ul style="list-style-type: none"> Output Low flow cut off Simulation process variable | Unit choose list | Country-specific: <ul style="list-style-type: none"> kg/h lb/min |
| Volume flow unit | – | Select volume flow unit. <i>Effect</i> The selected unit applies for: <ul style="list-style-type: none"> Output Low flow cut off Simulation process variable | Unit choose list | Country-specific: <ul style="list-style-type: none"> m³/h ft³/min |
| Corrected volume flow unit | – | Select corrected volume flow unit. <i>Effect</i> The selected unit applies for: Corrected volume flow | Unit choose list | Country-specific: <ul style="list-style-type: none"> Nm³/h Sft³/h |
| Energy flow unit | For the following order code: "Sensor version", option "Mass flow" | Select energy flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> Outputs Low flow cut off | Unit choose list | Country-specific: <ul style="list-style-type: none"> kW Btu/h |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|------------------|--|--|------------------------------|---|
| Pressure unit | For the following order code: "Sensor version", option "Mass flow" | Select process pressure unit. <i>Effect</i> The unit is taken from the: <ul style="list-style-type: none"> ■ Calculated saturated steam pressure ■ Atmospheric pressure ■ Maximum value ■ Fixed process pressure ■ Pressure ■ Reference pressure | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ bar ■ psi |
| Velocity unit | – | Select velocity unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> ■ Flow velocity ■ Maximum value | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ m/s ■ ft/s |
| Unit totalizer | One of the following options is selected in the Assign process variable parameter (→ 117) of the Totalizer 1 to 3 submenu: <ul style="list-style-type: none"> ■ Volume flow ■ Corrected volume flow ■ Mass flow ■ Total mass flow * ■ Condensate mass flow * ■ Energy flow * ■ Heat flow difference * | Select process variable totalizer unit. | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ m³ ■ ft³ |
| Temperature unit | – | Select temperature unit. <i>Effect</i> The selected unit applies for: <ul style="list-style-type: none"> ■ Temperature ■ Maximum value ■ Minimum value ■ Average value ■ Maximum value ■ Minimum value ■ Maximum value ■ Minimum value ■ 2nd temperature delta heat ■ Fixed temperature ■ Reference combustion temperature ■ Reference temperature ■ Saturation temperature | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ °C ■ °F |
| Switch-on value | <ul style="list-style-type: none"> ■ The Switch option is selected in the Operating mode parameter. ■ The Limit option is selected in the Switch output function parameter. | Enter measured value for the switch-on point. | Signed floating-point number | Country-specific: <ul style="list-style-type: none"> ■ 0 m³/h ■ 0 ft³/h |
| Switch-off value | <ul style="list-style-type: none"> ■ The Switch option is selected in the Operating mode parameter. ■ The Limit option is selected in the Switch output function parameter. | Enter measured value for the switch-off point. | Signed floating-point number | Country-specific: <ul style="list-style-type: none"> ■ 0 m³/h ■ 0 ft³/h |
| Switch-on delay | <ul style="list-style-type: none"> ■ The Switch option is selected in the Operating mode parameter. ■ The Limit option is selected in the Switch output function parameter. | Define delay for the switch-on of status output. | 0.0 to 100.0 s | 0.0 s |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|----------------------|---|---|---|-----------------|
| Switch-off delay | <ul style="list-style-type: none"> ▪ The Switch option is selected in the Operating mode parameter. ▪ The Limit option is selected in the Switch output function parameter. | Define delay for the switch-off of status output. | 0.0 to 100.0 s | 0.0 s |
| Failure mode | – | Define output behavior in alarm condition. | <ul style="list-style-type: none"> ▪ Actual status ▪ Open ▪ Closed | Open |
| Invert output signal | – | Invert the output signal. | <ul style="list-style-type: none"> ▪ No ▪ Yes | No |

* Visibility depends on order options or device settings


10.4.6 Configuring the local display

The **Display** wizard guides you systematically through all the parameters that can be configured for configuring the local display.

Navigation

"Setup" menu → Display

Structure of the wizard



29 "Display" wizard in the "Setup" menu

A0013797-EN

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------------------|--|---|---|---|
| Format display | A local display is provided. | Select how measured values are shown on the display. | <ul style="list-style-type: none"> ▪ 1 value, max. size ▪ 1 bargraph + 1 value ▪ 2 values ▪ 1 value large + 2 values ▪ 4 values | 1 value, max. size |
| Value 1 display | A local display is provided. | Select the measured value that is shown on the local display. | <ul style="list-style-type: none"> ▪ Volume flow ▪ Corrected volume flow ▪ Mass flow ▪ Flow velocity ▪ Temperature ▪ Calculated saturated steam pressure[*] ▪ Steam quality[*] ▪ Total mass flow[*] ▪ Condensate mass flow[*] ▪ Energy flow[*] ▪ Heat flow difference[*] ▪ Reynolds number[*] ▪ Density[*] ▪ Pressure[*] ▪ Specific volume[*] ▪ Degrees of superheat[*] ▪ Totalizer 1 ▪ Totalizer 2 ▪ Totalizer 3 ▪ Current output 1 ▪ Current output 2[*] | Volume flow |
| 0% bargraph value 1 | A local display is provided. | Enter 0% value for bar graph display. | Signed floating-point number | Country-specific: <ul style="list-style-type: none"> ▪ 0 m³/h ▪ 0 ft³/h |
| 100% bargraph value 1 | A local display is provided. | Enter 100% value for bar graph display. | Signed floating-point number | Depends on country and nominal diameter |
| Value 2 display | A local display is provided. | Select the measured value that is shown on the local display. | Picklist, see Value 1 display parameter | None |
| Value 3 display | A local display is provided. | Select the measured value that is shown on the local display. | Picklist, see Value 1 display parameter | None |
| 0% bargraph value 3 | A selection has been made in the Value 3 display parameter. | Enter 0% value for bar graph display. | Signed floating-point number | Country-specific: <ul style="list-style-type: none"> ▪ 0 m³/h ▪ 0 ft³/h |
| 100% bargraph value 3 | An option has been selected in the Value 3 display parameter. | Enter 100% value for bar graph display. | Signed floating-point number | 0 |
| Value 4 display | A local display is provided. | Select the measured value that is shown on the local display. | Picklist, see Value 1 display parameter | None |

* Visibility depends on order options or device settings


10.4.7 Configuring the output conditioning

The **Output conditioning** wizard guides you systematically through all the parameters that have to be set for configuring the output conditioning.

Navigation

"Setup" menu → Output conditioning

Structure of the "Output conditioning" wizard



A0020796-EN

30 "Output conditioning" wizard in the "Setup" menu

Parameter overview with brief description

| Parameter | Prerequisite | Description | User entry | Factory setting |
|------------------|---|--|----------------|-----------------|
| Display damping | – | Set display reaction time to fluctuations in the measured value. | 0.0 to 999.9 s | 5.0 s |
| Damping output 1 | – | Set the reaction time of the output signal of the current output to fluctuations in the measured value. | 0 to 999.9 s | 1 s |
| Damping output 2 | The measuring device has a second current output. | Set the reaction time of the output signal of the second current output to fluctuations in the measured value. | 0 to 999.9 s | 1 s |
| Damping output 2 | The measuring device has a pulse/frequency/switch output. | Set the reaction time of the output signal of the frequency output to fluctuations in the measured value. | 0 to 999.9 s | 1 s |


10.4.8 Configuring the low flow cut off

The **Low flow cut off** wizard guides you systematically through all the parameters that have to be set for configuring the low flow cut off.

Navigation

"Setup" menu → Low flow cut off

Structure of the wizard



A0020775-EN

31 "Low flow cut off" wizard in the "Setup" menu

Parameter overview with brief description


| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|---------------------------|---|---|---|-----------------|
| Assign process variable | - | Select process variable for low flow cut off. | <ul style="list-style-type: none"> ▪ Off ▪ Volume flow ▪ Corrected volume flow ▪ Mass flow ▪ Reynolds number * | Off |
| On value low flow cutoff | One of the following options is selected in the Assign process variable parameter (→ 94): <ul style="list-style-type: none"> ▪ Volume flow ▪ Corrected volume flow ▪ Mass flow ▪ Reynolds number * | Enter on value for low flow cut off. | Positive floating-point number | 0 |
| Off value low flow cutoff | One of the following options is selected in the Assign process variable parameter (→ 94): <ul style="list-style-type: none"> ▪ Volume flow ▪ Corrected volume flow ▪ Mass flow ▪ Reynolds number * | Enter off value for low flow cut off. | 0 to 100.0 % | 50 % |

* Visibility depends on order options or device settings

10.5 Advanced settings

The **Advanced setup** submenu together with its submenus contains parameters for specific settings.

Navigation to the "Advanced setup" submenu




A0014009-EN

32 Taking the example of the local display

i The number of submenus can vary depending on the device version. Some submenus are not dealt with in the Operating Instructions. These submenus and the parameters they contain are explained in the Special Documentation for the device.

Navigation

"Setup" menu → Advanced setup



| | |
|--------------------------------|-------|
| ▶ Sensor adjustment | → 115 |
| ▶ Totalizer 1 to 3 | → 116 |
| ▶ SIL confirmation | |
| ▶ Deactivate SIL | |
| ▶ Display | → 118 |
| ▶ Heartbeat setup | |
| ▶ Configuration backup display | → 120 |
| ▶ Administration | → 150 |

10.5.1 Setting the system units

In the **System units** submenu the units of all the measured values can be set.

Navigation

"Setup" menu → Advanced setup → System units

| |
|----------------------------|
| ▶ System units |
| Volume flow unit |
| Volume unit |
| Mass flow unit |
| Mass unit |
| Corrected volume flow unit |
| Corrected volume unit |
| Pressure unit |
| Temperature unit |
| Energy flow unit |
| Energy unit |
| Calorific value unit |
| Calorific value unit |

| |
|------------------------|
| Velocity unit |
| Density unit |
| Dynamic viscosity unit |
| Length unit |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection | Factory setting |
|----------------------------|--|--|------------------|---|
| Volume flow unit | – | Select volume flow unit. <i>Effect</i> The selected unit applies for: <ul style="list-style-type: none"> Output Low flow cut off Simulation process variable | Unit choose list | Country-specific: <ul style="list-style-type: none"> m³/h ft³/min |
| Volume unit | – | Select volume unit. | Unit choose list | Country-specific: <ul style="list-style-type: none"> m³ ft³ |
| Mass flow unit | – | Select mass flow unit. <i>Effect</i> The selected unit applies for: <ul style="list-style-type: none"> Output Low flow cut off Simulation process variable | Unit choose list | Country-specific: <ul style="list-style-type: none"> kg/h lb/min |
| Mass unit | – | Select mass unit. | Unit choose list | Country-specific: <ul style="list-style-type: none"> kg lb |
| Corrected volume flow unit | – | Select corrected volume flow unit. <i>Effect</i> The selected unit applies for: Corrected volume flow | Unit choose list | Country-specific: <ul style="list-style-type: none"> Nm³/h Sft³/h |
| Corrected volume unit | – | Select corrected volume unit. | Unit choose list | Country-specific: <ul style="list-style-type: none"> Nm³ Sft³ |
| Pressure unit | For the following order code: "Sensor version", option "Mass flow" | Select process pressure unit. <i>Effect</i> The unit is taken from the: <ul style="list-style-type: none"> Calculated saturated steam pressure Atmospheric pressure Maximum value Fixed process pressure Pressure Reference pressure | Unit choose list | Country-specific: <ul style="list-style-type: none"> bar psi |

| Parameter | Prerequisite | Description | Selection | Factory setting |
|-----------------------------|--|---|------------------|---|
| Temperature unit | – | Select temperature unit. <i>Effect</i> The selected unit applies for: <ul style="list-style-type: none"> ■ Temperature ■ Maximum value ■ Minimum value ■ Average value ■ Maximum value ■ Minimum value ■ Maximum value ■ Minimum value ■ 2nd temperature delta heat ■ Fixed temperature ■ Reference combustion temperature ■ Reference temperature ■ Saturation temperature | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ °C ■ °F |
| Energy flow unit | For the following order code: "Sensor version", option "Mass flow" | Select energy flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> ■ Outputs ■ Low flow cut off | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ kW ■ Btu/h |
| Energy unit | For the following order code: "Sensor version", option "Mass flow" | Select energy unit. | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ kWh ■ Btu |
| Calorific value unit | The following conditions are met: <ul style="list-style-type: none"> ■ Order code for "Sensor version", option "Mass flow" ■ The Gross calorific value volume option or the Net calorific value volume option is selected in the Calorific value type parameter. | Select calorific value unit. <i>Result</i> The selected unit applies for: Reference gross calorific value | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ kJ/Nm³ ■ Btu/Sft³ |
| Calorific value unit (Mass) | The following conditions are met: <ul style="list-style-type: none"> ■ Order code for "Sensor version", option "Mass flow" ■ The Gross calorific value mass option or the Net calorific value mass option is selected in the Calorific value type parameter. | Select calorific value unit. | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ kJ/kg ■ Btu/lb |
| Velocity unit | – | Select velocity unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> ■ Flow velocity ■ Maximum value | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ m/s ■ ft/s |
| Density unit | – | Select density unit. <i>Effect</i> The selected unit applies for: <ul style="list-style-type: none"> ■ Output ■ Simulation process variable | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ kg/m³ ■ lb/ft³ |
| Specific volume unit | For the following order code: "Sensor version", option "Mass flow" | Select the unit for the specific volume. <i>Result</i> The selected unit applies for: Specific volume | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ m³/kg ■ ft³/lb |

| Parameter | Prerequisite | Description | Selection | Factory setting |
|------------------------|--------------|---|------------------|---|
| Dynamic viscosity unit | – | Select dynamic viscosity unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> ▪ Dynamic viscosity parameter (gases) ▪ Dynamic viscosity parameter (liquids) | Unit choose list | Pa s |
| Length unit | – | Select length unit for nominal diameter. <i>Effect</i> The selected unit applies for: <ul style="list-style-type: none"> ▪ Inlet run ▪ Mating pipe diameter | Unit choose list | Country-specific: <ul style="list-style-type: none"> ▪ mm ▪ in |

10.5.2 Setting the medium properties

In the **Medium properties** submenu the reference values for the measuring application can be set.

Navigation

"Setup" menu → Advanced setup → Medium properties

▶ Medium properties

| |
|-------------------|
| Dynamic viscosity |
| Dynamic viscosity |
| ► Gas composition |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|----------------------------------|--|--|--|----------------------------|
| Enthalpy type | The following conditions are met: <ul style="list-style-type: none"> In the Select gas type parameter, the User-specific gas option is selected. Or In the Select liquid type parameter, the User-specific liquid option is selected. | Define which kind of enthalpy is used. | <ul style="list-style-type: none"> Heat Calorific value | Heat |
| Calorific value type | The Calorific value type parameter is visible. | Select calculation based on gross calorific value or net calorific value. | <ul style="list-style-type: none"> Gross calorific value volume Net calorific value volume Gross calorific value mass Net calorific value mass | Gross calorific value mass |
| Reference combustion temperature | The Reference combustion temperature parameter is visible. | Enter reference combustion temperature to calculate the natural gas energy value. <i>Dependency</i> The unit is taken from the Temperature unit parameter | -200 to 450 °C | 20 °C |
| Reference density | The following conditions are met: <ul style="list-style-type: none"> In the Select gas type parameter, the User-specific gas option is selected. Or In the Select liquid type parameter, the Water option or User-specific liquid option is selected. | Enter fixed value for reference density. <i>Dependency</i> The unit is taken from the Density unit parameter | 0.01 to 15 000 kg/m ³ | 1 000 kg/m ³ |
| Reference gross calorific value | The following conditions are met: <ul style="list-style-type: none"> In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-3 option is selected. | Enter reference gross calorific value of the natural gas. <i>Dependency</i> The unit is taken from the Calorific value unit parameter | Positive floating-point number | 50 000 kJ/Nm ³ |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|------------------------------|--|--|--------------------------|-----------------|
| Reference pressure | The following conditions are met: <ul style="list-style-type: none"> Order code for "Sensor version", option "Mass flow (integrated temperature measurement)" The Gas option is selected in the Select medium parameter. | Enter reference pressure for the calculation of the reference density. <i>Dependency</i> The unit is taken from the Pressure unit parameter | 0 to 250 bar | 1.01325 bar |
| Reference temperature | The following conditions are met: <ul style="list-style-type: none"> The Gas option is selected in the Select medium parameter. Or The Liquid option is selected in the Select medium parameter. | Enter reference temperature for calculating the reference density. <i>Dependency</i> The unit is taken from the Temperature unit parameter | -200 to 450 °C | 20 °C |
| Reference Z-factor | In the Select gas type parameter, the User-specific gas option is selected. | Enter real gas constant Z for gas under reference conditions. | 0.1 to 2 | 1 |
| Linear expansion coefficient | The following conditions are met: <ul style="list-style-type: none"> The Liquid option is selected in the Select medium parameter. The User-specific liquid option is selected in the Select liquid type parameter. | Enter linear, medium-specific expansion coefficient for calculating the reference density. | 1.0^{-6} to 2.0^{-3} | 2.06^{-4} |
| Relative density | The following conditions are met: <ul style="list-style-type: none"> In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-3 option is selected. | Enter a relative density of the natural gas. | 0.55 to 0.9 | 0.664 |
| Specific heat capacity | The following conditions are met: <ul style="list-style-type: none"> Selected medium: <ul style="list-style-type: none"> In the Select gas type parameter, the User-specific gas option is selected. Or In the Select liquid type parameter, the User-specific liquid option is selected. In the Enthalpy type parameter, the Heat option is selected. | Enter the specific heat capacity of the medium. <i>Dependency</i> The unit is taken from the Specific heat capacity unit parameter | 0 to 50 kJ/(kgK) | 4.187 kJ/(kgK) |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------------------------|--|--|--------------------------------|-----------------|
| Calorific value | The following conditions are met: <ul style="list-style-type: none"> Selected medium: <ul style="list-style-type: none"> In the Select gas type parameter, the User-specific gas option is selected. Or In the Select liquid type parameter, the User-specific liquid option is selected. In the Enthalpy type parameter, the Calorific value option is selected. In the Calorific value type parameter, the Gross calorific value volume option or Gross calorific value mass option is selected. | Enter gross calorific value to calculate the energy flow. | Positive floating-point number | 50 000 kJ/kg |
| Z-factor | In the Select gas type parameter, the User-specific gas option is selected. | Enter real gas constant Z for gas under operation conditions. | 0.1 to 2.0 | 1 |
| Dynamic viscosity (Gases) | The following conditions are met: <ul style="list-style-type: none"> Order code for "Sensor version", option "Volume flow" The Gas option or the Steam option is selected in the Select medium parameter. Or The User-specific gas option is selected in the Select gas type parameter. | Enter fixed value for dynamic viscosity for a gas/steam. <i>Dependency</i> The unit is taken from the Dynamic viscosity unit parameter. | Positive floating-point number | 0.015 cP |
| Dynamic viscosity (Liquids) | The following conditions are met: <ul style="list-style-type: none"> Order code for "Sensor version", option "Volume flow" The Liquid option is selected in the Select medium parameter. Or The User-specific liquid option is selected in the Select liquid type parameter. | Enter fixed value for dynamic viscosity for a liquid. <i>Dependency</i> The unit is taken from the Dynamic viscosity unit parameter. | Positive floating-point number | 1 cP |

Configuring the gas composition

In the **Gas composition** submenu the gas composition for the measuring application can be set.

Navigation

"Setup" menu → Advanced setup → Medium properties → Gas composition

► Gas composition

Gas type

Gas mixture

Mol% Ar

Mol% C2H3Cl

Mol% C2H4

Mol% C2H6

Mol% C3H8

Mol% CH4

Mol% Cl2

Mol% CO

Mol% CO2

Mol% H2

Mol% H2O

Mol% H2S

Mol% HCl

Mol% He

Mol% i-C4H10

Mol% i-C5H12

Mol% Kr

Mol% N2

Mol% n-C10H22

Mol% n-C4H10

| |
|---------------------------------------|
| Mol% n-C ₅ H ₁₂ |
| Mol% n-C ₆ H ₁₄ |
| Mol% n-C ₇ H ₁₆ |
| Mol% n-C ₈ H ₁₈ |
| Mol% n-C ₉ H ₂₀ |
| Mol% Ne |
| Mol% NH ₃ |
| Mol% O ₂ |
| Mol% SO ₂ |
| Mol% Xe |
| Mol% other gas |
| Relative humidity |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-------------|---|------------------------------|---|-----------------|
| Gas type | The following conditions are met: <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Single gas option is selected. | Select measured gas type. | <ul style="list-style-type: none"> ▪ Hydrogen H2 ▪ Helium He ▪ Neon Ne ▪ Argon Ar ▪ Krypton Kr ▪ Xenon Xe ▪ Nitrogen N2 ▪ Oxygen O2 ▪ Chlorine Cl2 ▪ Ammonia NH3 ▪ Carbon monoxide CO ▪ Carbon dioxide CO2 ▪ Sulfur dioxide SO2 ▪ Hydrogen sulfide H2S ▪ Hydrogen chloride HCl ▪ Methane CH4 ▪ Ethane C2H6 ▪ Propane C3H8 ▪ Butane C4H10 ▪ Ethylene C2H4 ▪ Vinyl Chloride C2H3Cl | Methane CH4 |
| Gas mixture | The following conditions are met: <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Gas mixture option is selected. | Select measured gas mixture. | <ul style="list-style-type: none"> ▪ Hydrogen H2 ▪ Helium He ▪ Neon Ne ▪ Argon Ar ▪ Krypton Kr ▪ Xenon Xe ▪ Nitrogen N2 ▪ Oxygen O2 ▪ Chlorine Cl2 ▪ Ammonia NH3 ▪ Carbon monoxide CO ▪ Carbon dioxide CO2 ▪ Sulfur dioxide SO2 ▪ Hydrogen sulfide H2S ▪ Hydrogen chloride HCl ▪ Methane CH4 ▪ Ethane C2H6 ▪ Propane C3H8 ▪ Butane C4H10 ▪ Ethylene C2H4 ▪ Vinyl Chloride C2H3Cl ▪ Others | Methane CH4 |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-------------|---|--|------------------------|-----------------|
| Mol% Ar | <p>The following conditions are met:</p> <p>In the Select medium parameter, the Gas option is selected.</p> <ul style="list-style-type: none"> - In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Argon Ar option is selected. <p>Or</p> <ul style="list-style-type: none"> - In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213-2 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% C2H3Cl | <p>The following conditions are met:</p> <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Gas mixture option is selected. ▪ In the Gas mixture parameter, the Vinyl Chloride C2H3Cl option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% C2H4 | <p>The following conditions are met:</p> <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Gas mixture option is selected. ▪ In the Gas mixture parameter, the Ethylene C2H4 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% C2H6 | <p>The following conditions are met:</p> <p>In the Select medium parameter, the Gas option is selected.</p> <ul style="list-style-type: none"> - In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Ethane C2H6 option is selected. <p>Or</p> <ul style="list-style-type: none"> - In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213-2 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------|--|--|------------------------|-----------------|
| Mol% C3H8 | <p>The following conditions are met: In the Select medium parameter, the Gas option is selected.</p> <ul style="list-style-type: none"> - In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Propane C3H8 option is selected. <p>Or</p> <ul style="list-style-type: none"> - In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213-2 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% CH4 | <p>The following conditions are met: In the Select medium parameter, the Gas option is selected.</p> <ul style="list-style-type: none"> - In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Methane CH4 option is selected. <p>Or</p> <ul style="list-style-type: none"> - In the Select gas type parameter, the Natural gas option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 100 % |
| Mol% Cl2 | <p>The following conditions are met:</p> <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Gas mixture option is selected. ▪ In the Gas mixture parameter, the Chlorine Cl2 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% CO | <p>The following conditions are met: In the Select medium parameter, the Gas option is selected.</p> <ul style="list-style-type: none"> - In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Carbon monoxide CO option is selected. <p>Or</p> <ul style="list-style-type: none"> - In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213-2 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------|--|--|------------------------|-----------------|
| Mol% CO2 | <p>The following conditions are met: In the Select medium parameter, the Gas option is selected.</p> <ul style="list-style-type: none"> - In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Carbon dioxide CO2 option is selected. <p>Or</p> <ul style="list-style-type: none"> - In the Select gas type parameter, the Natural gas option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% H2 | <p>The following conditions are met: In the Select medium parameter, the Gas option is selected.</p> <ul style="list-style-type: none"> - In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Hydrogen H2 option is selected. <p>Or</p> <ul style="list-style-type: none"> - In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the AGA Nx19 option is not selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% H2O | <p>The following conditions are met:</p> <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Natural gas option is selected. ▪ In the Density calculation parameter, the ISO 12213-2 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% H2S | <p>The following conditions are met: In the Select medium parameter, the Gas option is selected.</p> <ul style="list-style-type: none"> - In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Hydrogen sulfide H2S option is selected. <p>Or</p> <ul style="list-style-type: none"> - In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213-2 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|---------------------------------------|--|--|------------------------|-----------------|
| Mol% HCl | The following conditions are met: <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Gas mixture option is selected. ▪ In the Gas mixture parameter, the Hydrogen chloride HCl option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% He | The following conditions are met: In the Select medium parameter, the Gas option is selected. – In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Helium He option is selected. Or – In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213-2 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% i-C ₄ H ₁₀ | The following conditions are met: <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Natural gas option is selected. ▪ In the Density calculation parameter, the ISO 12213-2 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% i-C ₅ H ₁₂ | The following conditions are met: <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Natural gas option is selected. ▪ In the Density calculation parameter, the ISO 12213-2 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% Kr | The following conditions are met: <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Gas mixture option is selected. ▪ In the Gas mixture parameter, the Krypton Kr option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|---------------|--|--|------------------------|-----------------|
| Mol% N2 | <p>The following conditions are met:</p> <p>In the Select medium parameter, the Gas option is selected.</p> <ul style="list-style-type: none"> - In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Nitrogen N2 option is selected. <p>Or</p> <ul style="list-style-type: none"> - In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the AGA Nx19 option or the ISO 12213- 2 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% n-C10H22 | <p>The following conditions are met:</p> <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Natural gas option is selected. ▪ In the Density calculation parameter, the ISO 12213- 2 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% n-C4H10 | <p>The following conditions are met:</p> <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. <ul style="list-style-type: none"> - In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Butane C4H10 option is selected. <p>Or</p> <ul style="list-style-type: none"> - In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213- 2 option is selected. <ul style="list-style-type: none"> ▪ Or In the Select medium parameter, the Liquid option is selected and in the Select liquid type parameter, the LPG option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |


| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|--------------|--|--|------------------------|-----------------|
| Mol% n-C5H12 | The following conditions are met: <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Natural gas option is selected. ▪ In the Density calculation parameter, the ISO 12213-2 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% n-C6H14 | The following conditions are met: <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Natural gas option is selected. ▪ In the Density calculation parameter, the ISO 12213-2 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% n-C7H16 | The following conditions are met: <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Natural gas option is selected. ▪ In the Density calculation parameter, the ISO 12213-2 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% n-C8H18 | The following conditions are met: <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Natural gas option is selected. ▪ In the Density calculation parameter, the ISO 12213-2 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% n-C9H20 | The following conditions are met: <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Natural gas option is selected. ▪ In the Density calculation parameter, the ISO 12213-2 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |


| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------|--|--|------------------------|-----------------|
| Mol% Ne | The following conditions are met: <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Gas mixture option is selected. ▪ In the Gas mixture parameter, the Neon Ne option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% NH3 | The following conditions are met: <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Gas mixture option is selected. ▪ In the Gas mixture parameter, the Ammonia NH3 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% O2 | The following conditions are met: In the Select medium parameter, the Gas option is selected. – In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Oxygen O2 option is selected. Or – In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213-2 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% SO2 | The following conditions are met: <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Gas mixture option is selected. ▪ In the Gas mixture parameter, the Sulfur dioxide SO2 option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Mol% Xe | The following conditions are met: <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Gas mixture option is selected. ▪ In the Gas mixture parameter, the Xenon Xe option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-------------------|---|--|------------------------|-----------------|
| Mol% other gas | The following conditions are met: <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Gas mixture option is selected. ▪ In the Gas mixture parameter, the Others option is selected. | Enter amount of substance for the gas mixture. | 0 to 100 % | 0 % |
| Relative humidity | The following conditions are met: <ul style="list-style-type: none"> ▪ In the Select medium parameter, the Gas option is selected. ▪ In the Select gas type parameter, the Air option is selected. | Enter humidity content of air in %. | 0 to 100 % | 0 % |

10.5.3 Performing external compensation

The **External compensation** submenu contains parameters which can be used to enter external or fixed values. These values are used for internal calculations.

 The **Fixed process pressure** parameter is set to the value **0 bar abs.** (ex works). In this case, the measuring device ignores the pressure read in via the current input. For the measuring device to use the external (read-in) pressure, a value > 0 bar abs. must be entered in the **Fixed process pressure** parameter.





For a detailed description of how to calculate the mass flow and energy flow:
 →  164






Navigation

"Setup" menu → Advanced setup → External compensation

▶ External compensation

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|----------------------------|--|--|--|-------------------------|
| External value | For the following order code: "Sensor version", option "Mass flow" | Assign variable from external device to process variable.  For detailed information on the calculation of the measured variables with steam: →  165  For detailed information on setting the parameter in steam applications, see the Special Documentation for the Wet Steam Detection and Wet Steam Measurement →  189 application package. | <ul style="list-style-type: none"> ▪ Off ▪ Pressure ▪ Relative pressure ▪ Density ▪ Temperature ▪ 2nd temperature delta heat | Off |
| Atmospheric pressure | In the External value parameter, the Relative pressure option is selected. | Enter atmospheric pressure value to be used for pressure correction. <i>Dependency</i> The unit is taken from the Pressure unit parameter | 0 to 250 bar | 1.01325 bar |
| Delta heat calculation | The Delta heat calculation parameter is visible. | Calculates the transferred heat of a heat exchanger (= delta heat). | <ul style="list-style-type: none"> ▪ Off ▪ Device on cold side ▪ Device on warm side | Device on warm side |
| Fixed density | For the following order code: "Sensor version", option "Volume flow" | Enter fixed value for medium density. <i>Dependency</i> The unit is taken from the Density unit parameter. | 0.01 to 15 000 kg/m ³ | 1 000 kg/m ³ |
| Fixed temperature | – | Enter a fixed value for process temperature. <i>Dependency</i> The unit is taken from the Temperature unit parameter | –200 to 450 °C | 20 °C |
| 2nd temperature delta heat | The 2nd temperature delta heat parameter is visible. | Enter 2nd temperature value to calculate the delta heat. <i>Dependency</i> The unit is taken from the Temperature unit parameter | –200 to 450 °C | 20 °C |


| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|------------------------|---|---|---|-----------------|
| Fixed process pressure | <p>The following conditions are met:</p> <ul style="list-style-type: none"> Order code for "Sensor version", option "Mass flow (integrated temperature measurement)" In the External value parameter (→ 74), the Pressure option is not selected. | <p>Enter fixed value for process pressure.</p> <p><i>Dependency</i> The unit is taken from the Pressure unit parameter</p> <p> For detailed information on the calculation of the measured variables with steam: → 165</p> <p> For detailed information on setting the parameter in steam applications, see the Special Documentation for the Wet Steam Detection and Wet Steam Measurement → 189 application package.</p> | 0 to 250 bar abs. | 0 bar abs. |
| Steam quality | <p>The following conditions are met:</p> <ul style="list-style-type: none"> Order code for "Application package": <ul style="list-style-type: none"> Option ES "Wet steam detection" Option EU "Wet steam measurement" In the Select medium parameter, the Steam option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Select compensation mode for steam quality.</p> <p> For detailed information on setting the parameter in steam applications, see the Special Documentation for the Wet Steam Detection and Wet Steam Measurement → 189 application package.</p> | <ul style="list-style-type: none"> Fixed value Calculated value | Fixed value |
| Steam quality value | <p>The following conditions are met:</p> <ul style="list-style-type: none"> In the Select medium parameter, the Steam option is selected. In the Steam quality parameter, the Fixed value option is selected. | <p>Enter fixed value for steam quality.</p> <p> For detailed information on setting the parameter in steam applications, see the Special Documentation for the Wet Steam Detection and Wet Steam Measurement → 189 application package.</p> | 0 to 100 % | 100 % |

10.5.4 Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

Navigation

"Setup" menu → Advanced setup → Sensor adjustment



| |
|--|
| <input style="width: 80%; border: 1px solid black;" type="text" value="Inlet run"/> |
| <input style="width: 80%; border: 1px solid black;" type="text" value="Mating pipe diameter"/> |
| <input style="width: 80%; border: 1px solid black;" type="text" value="Installation factor"/> |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|----------------------|---|---|---|--|
| Inlet configuration | The inlet run correction feature: <ul style="list-style-type: none"> ■ Is a standard feature and can only be used in Prowirl F 200. ■ Can be used for the following pressure ratings and nominal diameters: DN 15 to 150 (1 to 6") <ul style="list-style-type: none"> - EN (DIN) - ASME B16.5, Sch. 40/80 | Select inlet configuration. | <ul style="list-style-type: none"> ■ Off ■ Single elbow ■ Double elbow ■ Double elbow 3D ■ Reduction | Off |
| Inlet run | The inlet run correction feature: <ul style="list-style-type: none"> ■ Is a standard feature and can only be used in Prowirl F 200. ■ Can be used for the following pressure ratings and nominal diameters: DN 15 to 150 (1 to 6") <ul style="list-style-type: none"> - EN (DIN) - ASME B16.5, Sch. 40/80 | Define length of the straight inlet run. <i>Dependency</i> The unit is taken from the Length unit parameter | 0 to 20 m | 0 m |
| Mating pipe diameter | - | Enter diameter of mating pipe to enable diameter mismatch correction. Detailed information on diameter mismatch correction: → 175 <i>Dependency</i> The unit is taken from the Length unit parameter. | 0 to 1 m (0 to 3 ft) Input value = 0: Diameter mismatch correction is disabled. | Country-specific: <ul style="list-style-type: none"> ■ 0 m ■ 0 ft |
| Installation factor | - | Enter factor to adjust for installation conditions. | Positive floating-point number | 1.0 |

10.5.5 Configuring the totalizer

In the "Totalizer 1 to 3" submenu the individual totalizer can be configured.



Navigation

"Setup" menu → Advanced setup → Totalizer 1 to 3

| |
|--|
| <div style="background-color: #cccccc; padding: 5px; margin-bottom: 10px;">▶ Totalizer 1 to 3</div> <div style="border: 1px solid black; padding: 5px; margin-left: 40px; width: 60%;">Assign process variable</div> |
|--|

| |
|----------------|
| Unit totalizer |
| Failure mode |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection | Factory setting |
|--------------------------|--|---|--|---|
| Assign process variable | – | Select process variable for totalizer. | <ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Corrected volume flow ■ Mass flow ■ Total mass flow * ■ Condensate mass flow * ■ Energy flow * ■ Heat flow difference * | Volume flow |
| Unit totalizer | One of the following options is selected in the Assign process variable parameter (→  117) of the Totalizer 1 to 3 submenu: <ul style="list-style-type: none"> ■ Volume flow ■ Corrected volume flow ■ Mass flow ■ Total mass flow * ■ Condensate mass flow * ■ Energy flow * ■ Heat flow difference * | Select process variable totalizer unit. | Unit choose list | Country-specific: <ul style="list-style-type: none"> ■ m³ ■ ft³ |
| Totalizer operation mode | – | Select totalizer calculation mode. | <ul style="list-style-type: none"> ■ Net flow total ■ Forward flow total ■ Reverse flow total | Net flow total |
| Failure mode | One of the following options is selected in the Assign process variable parameter (→  117) of the Totalizer 1 to 3 submenu: <ul style="list-style-type: none"> ■ Volume flow ■ Corrected volume flow ■ Mass flow ■ Total mass flow * ■ Condensate mass flow * ■ Energy flow * ■ Heat flow difference * | Define totalizer behavior in alarm condition. | <ul style="list-style-type: none"> ■ Stop ■ Actual value ■ Last valid value | Stop |

* Visibility depends on order options or device settings

10.5.6 Carrying out additional display configurations

In the **Display** submenu you can set all the parameters associated with the configuration of the local display.

Navigation


"Setup" menu → Advanced setup → Display

► Display

- Format display
- Value 1 display
- 0% bargraph value 1
- 100% bargraph value 1
- Decimal places 1
- Value 2 display
- Decimal places 2
- Value 3 display
- 0% bargraph value 3
- 100% bargraph value 3
- Decimal places 3
- Value 4 display
- Decimal places 4
- Language
- Display interval
- Display damping
- Header
- Header text
- Separator
- Backlight

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------------------|--|---|---|---|
| Format display | A local display is provided. | Select how measured values are shown on the display. | <ul style="list-style-type: none"> ■ 1 value, max. size ■ 1 bargraph + 1 value ■ 2 values ■ 1 value large + 2 values ■ 4 values | 1 value, max. size |
| Value 1 display | A local display is provided. | Select the measured value that is shown on the local display. | <ul style="list-style-type: none"> ■ Volume flow ■ Corrected volume flow ■ Mass flow ■ Flow velocity ■ Temperature ■ Calculated saturated steam pressure * ■ Steam quality * ■ Total mass flow * ■ Condensate mass flow * ■ Energy flow * ■ Heat flow difference * ■ Reynolds number * ■ Density * ■ Pressure * ■ Specific volume * ■ Degrees of superheat * ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Current output 1 ■ Current output 2 * | Volume flow |
| 0% bargraph value 1 | A local display is provided. | Enter 0% value for bar graph display. | Signed floating-point number | Country-specific: <ul style="list-style-type: none"> ■ 0 m³/h ■ 0 ft³/h |
| 100% bargraph value 1 | A local display is provided. | Enter 100% value for bar graph display. | Signed floating-point number | Depends on country and nominal diameter |
| Decimal places 1 | A measured value is specified in the Value 1 display parameter. | Select the number of decimal places for the display value. | <ul style="list-style-type: none"> ■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx | x.xx |
| Value 2 display | A local display is provided. | Select the measured value that is shown on the local display. | Picklist, see Value 1 display parameter | None |
| Decimal places 2 | A measured value is specified in the Value 2 display parameter. | Select the number of decimal places for the display value. | <ul style="list-style-type: none"> ■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx | x.xx |
| Value 3 display | A local display is provided. | Select the measured value that is shown on the local display. | Picklist, see Value 1 display parameter | None |
| 0% bargraph value 3 | A selection has been made in the Value 3 display parameter. | Enter 0% value for bar graph display. | Signed floating-point number | Country-specific: <ul style="list-style-type: none"> ■ 0 m³/h ■ 0 ft³/h |
| 100% bargraph value 3 | An option has been selected in the Value 3 display parameter. | Enter 100% value for bar graph display. | Signed floating-point number | 0 |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|------------------|---|---|--|--|
| Decimal places 3 | A measured value is specified in the Value 3 display parameter. | Select the number of decimal places for the display value. | <ul style="list-style-type: none"> ▪ x ▪ x.x ▪ x.xx ▪ x.xxx ▪ x.xxxx | x.xx |
| Value 4 display | A local display is provided. | Select the measured value that is shown on the local display. | Picklist, see Value 1 display parameter | None |
| Decimal places 4 | A measured value is specified in the Value 4 display parameter. | Select the number of decimal places for the display value. | <ul style="list-style-type: none"> ▪ x ▪ x.x ▪ x.xx ▪ x.xxx ▪ x.xxxx | x.xx |
| Language | A local display is provided. | Set display language. | <ul style="list-style-type: none"> ▪ English ▪ Deutsch * ▪ Français * ▪ Español * ▪ Italiano * ▪ Nederlands * ▪ Portuguesa * ▪ Polski * ▪ русский язык (Russian) * ▪ Svenska * ▪ Türkçe * ▪ 中文 (Chinese) * ▪ 日本語 (Japanese) * ▪ 한국어 (Korean) * ▪ Bahasa Indonesia * ▪ tiếng Việt (Vietnamese) * ▪ čeština (Czech) * | English (alternatively, the ordered language is preset in the device) |
| Display interval | A local display is provided. | Set time measured values are shown on display if display alternates between values. | 1 to 10 s | 5 s |
| Display damping | A local display is provided. | Set display reaction time to fluctuations in the measured value. | 0.0 to 999.9 s | 5.0 s |
| Header | A local display is provided. | Select header contents on local display. | <ul style="list-style-type: none"> ▪ Device tag ▪ Free text | Device tag |
| Header text | The Free text option is selected in the Header parameter. | Enter display header text. | Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /) | ----- |
| Separator | A local display is provided. | Select decimal separator for displaying numerical values. | <ul style="list-style-type: none"> ▪ . (point) ▪ , (comma) | . (point) |
| Backlight | - | Switch the local display backlight on and off.  Only for device version with local display SD03 (touch control) | <ul style="list-style-type: none"> ▪ Disable ▪ Enable | Disable |

* Visibility depends on order options or device settings


10.6 Configuration management

After commissioning, you can save the current device configuration, copy it to another measuring point or restore the previous device configuration.

You can do so using the **Configuration management** parameter and the related options found in the **Configuration backup display** submenu.

Navigation

"Setup" menu → Advanced setup → Configuration backup display



Parameter overview with brief description

| Parameter | Prerequisite | Description | User interface / Selection | Factory setting |
|--------------------------|------------------------------|--|--|-----------------|
| Operating time | – | Indicates how long the device has been in operation. | Days (d), hours (h), minutes (m) and seconds (s) | – |
| Last backup | A local display is provided. | Indicates when the last data backup was saved to the display module. | Days (d), hours (h), minutes (m) and seconds (s) | – |
| Configuration management | A local display is provided. | Select action for managing the device data in the display module. | <ul style="list-style-type: none"> ▪ Cancel ▪ Execute backup ▪ Restore ▪ Duplicate ▪ Compare ▪ Clear backup data | Cancel |
| Comparison result | A local display is provided. | Comparison between present device data and display backup. | <ul style="list-style-type: none"> ▪ Settings identical ▪ Settings not identical ▪ No backup available ▪ Backup settings corrupt ▪ Check not done ▪ Dataset incompatible | Check not done |


10.6.1 Function scope of the "Configuration management" parameter

| Options | Description |
|----------------|--|
| Execute backup | The current device configuration is backed up from the integrated HistoROM to the device's display module. The backup copy includes the transmitter data of the device. |
| Restore | The last backup copy of the device configuration is restored from the display module to the device's integrated HistoROM. The backup copy includes the transmitter data of the device. |
| Duplicate | The transmitter configuration from another device is duplicated to the device using the display module. |

| Options | Description |
|-------------------|--|
| Compare | The device configuration saved in the display module is compared with the current device configuration of the integrated HistoROM. |
| Clear backup data | The backup copy of the device configuration is deleted from the display module of the device. |

Integrated HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

 While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.

10.7 Simulation

The **Simulation** submenu enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).

Navigation

"Diagnostics" menu → Simulation

▶ Simulation

Assign simulation process variable

Value process variable

Simulation current input 1

Value current input 1

Simulation current output 1 to 2

Value current output 1 to 2

Frequency simulation

Frequency value


Pulse simulation

Pulse value

Switch output simulation





Switch status

Simulation device alarm



Parameter overview with brief description


| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|------------------------------------|---|---|---|-----------------|
| Assign simulation process variable | – | Select a process variable for the simulation process that is activated. | <ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Corrected volume flow ■ Mass flow ■ Flow velocity ■ Temperature ■ Calculated saturated steam pressure * ■ Steam quality * ■ Total mass flow * ■ Condensate mass flow * ■ Energy flow ■ Heat flow difference * ■ Reynolds number | Off |
| Value process variable | One of the following options is selected in the Assign simulation process variable parameter (→ 123): <ul style="list-style-type: none"> ■ Volume flow ■ Corrected volume flow ■ Mass flow ■ Flow velocity ■ Temperature * ■ Calculated saturated steam pressure * ■ Steam quality * ■ Total mass flow * ■ Condensate mass flow * ■ Energy flow * ■ Heat flow difference * ■ Reynolds number * | Enter the simulation value for the selected process variable. | Depends on the process variable selected | 0 |
| Simulation current input 1 | – | Switch simulation of the current input on and off. | <ul style="list-style-type: none"> ■ Off ■ On | Off |
| Value current input 1 | In the Simulation current input parameter the On option is selected. | Enter the current value for simulation. | 3.59 to 22.5 mA | 3.59 mA |
| Simulation current output 1 to 2 | – | Switch the simulation of the current output on and off. | <ul style="list-style-type: none"> ■ Off ■ On | Off |
| Value current output 1 to 2 | In the Simulation current output 1 to 2 parameter, the On option is selected. | Enter the current value for simulation. | 3.59 to 22.5 mA | 3.59 mA |
| Frequency simulation | The Frequency option is selected in the Operating mode parameter. | Switch the simulation of the frequency output on and off. | <ul style="list-style-type: none"> ■ Off ■ On | Off |
| Frequency value | The On option is selected in the Frequency simulation parameter. | Enter the frequency value for the simulation. | 0.0 to 1250.0 Hz | 0.0 Hz |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------------------------|--|---|---|-----------------|
| Pulse simulation | The Pulse option is selected in the Operating mode parameter. | Set and switch off the pulse output simulation.  For Fixed value option: Pulse width parameter (→  80) defines the pulse width of the pulses output. | <ul style="list-style-type: none"> ▪ Off ▪ Fixed value ▪ Down-counting value | Off |
| Pulse value | In the Pulse simulation parameter (→  124), the Down-counting value option is selected. | Enter the number of pulses for simulation. | 0 to 65 535 | 0 |
| Switch output simulation | The Switch option is selected in the Operating mode parameter. | Switch the simulation of the switch output on and off. | <ul style="list-style-type: none"> ▪ Off ▪ On | Off |
| Switch status | The On option is selected in the Switch output simulation parameter (→  124). | Select the status of the status output for the simulation. | <ul style="list-style-type: none"> ▪ Open ▪ Closed | Open |
| Simulation device alarm | – | Switch the device alarm on and off. | <ul style="list-style-type: none"> ▪ Off ▪ On | Off |
| Diagnostic event category | – | Select a diagnostic event category. | <ul style="list-style-type: none"> ▪ Sensor ▪ Electronics ▪ Configuration ▪ Process | Process |
| Simulation diagnostic event | – | Select a diagnostic event for the simulation process that is activated. | <ul style="list-style-type: none"> ▪ Off ▪ Diagnostic event picklist (depends on the category selected) | Off |

* Visibility depends on order options or device settings

10.8 Protecting settings from unauthorized access

The following options exist for protecting the configuration of the measuring device from unintentional modification after commissioning:

- Write protection via access code
- Write protection via write protection switch
- Write protection via keypad lock →  58

10.8.1 Write protection via access code


With the customer-specific access code, the parameters for the measuring device configuration are write-protected and their values can no longer be changed via local operation.

Navigation




"Setup" menu → Advanced setup → Administration → Define access code

▶ Define access code

Defining the access code via local display


1. Navigate to the **Enter access code** parameter.
2. Define a max. 4-digit numeric code as an access code.
3. Enter the access code again to confirm the code.
 - ↳ The -symbol appears in front of all write-protected parameters.

The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. The device locks the write-protected parameters automatically after 60 s if the user skips back to the operational display mode from the navigation and editing view.

-  If write access is activated via access code, it can be also be deactivated only via the access code →  58.
- The user role with which the user is currently logged on via the local display →  58 is indicated by the **Access status display** parameter. Navigation path: "Operation" menu → Access status display

Parameters which can always be modified via the local display

Certain parameters that do not affect the measurement are excepted from write protection via the local display. Despite the defined access code, these parameters can always be modified even if the other parameters are locked.




10.8.2 Write protection via write protection switch

Unlike write protection via a user-specific access code, this allows write access to the entire operating menu - other than the **"Contrast display" parameter** - to be locked.


The parameter values are now read only and cannot be edited any more (exception **"Contrast display" parameter**):

- Via local display
- Via service interface (CDI)
- Via HART protocol





A0025794

1. Loosen the securing clamp.
2. Unscrew the electronics compartment cover.
3. Pull out the display module with a gentle rotational movement. To make it easier to access the write protection switch, attach the display module to the edge of the electronics compartment.
 - ↳ Display module is attached to the edge of the electronics compartment.




A0013909

4. Setting the write protection switch (WP) on the main electronics module to the **ON** position enables hardware write protection. Setting the write protection switch (WP) on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.
 - ↳ If hardware write protection is enabled, the **Locking status** parameter displays the **Hardware locked** option . In addition, on the local display the -symbol appears in front of the parameters in the header of the operational display and in the navigation view.



A0015870

If hardware write protection is disabled, no option is displayed in the **Locking status** parameter . On the local display, the -symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

5. Feed the cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment in the desired direction until it engages.
6. Reverse the removal procedure to reassemble the transmitter.

11 Operation


11.1 Reading the device locking status

Device active write protection: **Locking status** parameter


Navigation



"Operation" menu → Locking status

Function scope of the "Locking status" parameter



| Options | Description |
|--------------------|---|
| None | The access status displayed in " Access status display " parameter applies →  58. Only appears on local display. |
| Hardware locked | The DIP switch for hardware locking is activated on the main electronics module. This prevents write access to the parameters . |
| Temporarily locked | Write access to the parameters is temporarily lock due to device-internal processing (e.g. data upload/download, reset). Once the internal processing has been completed, the parameters can be changed once again. |

11.2 Adjusting the operating language

Information →  68

 For information on the operating languages supported by the measuring device →  186

11.3 Configuring the display

- Basic settings for the local display →  90
- Advanced settings for the local display →  118

11.4 Reading measured values


With the **Measured values** submenu, it is possible to read all the measured values.

11.4.1 Process variables

The **Process variables** submenu contains all the parameters needed to display the current measured values for every process variable.

Navigation

"Diagnostics" menu → Measured values → Process variables



| |
|-------------------------------------|
| Flow velocity |
| Temperature |
| Calculated saturated steam pressure |
| Steam quality |
| Total mass flow |
| Condensate mass flow |
| Energy flow |
| Heat flow difference |
| Reynolds number |
| Density |
| Specific volume |
| Pressure |
| Compressibility factor |
| Degrees of superheat |

Parameter overview with brief description

| Parameter | Prerequisite | Description | User interface |
|-----------------------|--------------|--|------------------------------|
| Volume flow | – | Displays the volume flow currently measured. <i>Dependency</i> The unit is taken from the Volume flow unit parameter | Signed floating-point number |
| Corrected volume flow | – | Displays the corrected volume flow currently calculated. <i>Dependency</i> The unit is taken from: Corrected volume flow unit parameter | Signed floating-point number |
| Mass flow | – | Displays the mass flow currently calculated. <i>Dependency</i> The unit is taken from the Mass flow unit parameter | Signed floating-point number |
| Flow velocity | – | Displays the flow velocity currently calculated. <i>Dependency</i> The unit is taken from the Velocity unit parameter | Signed floating-point number |

| Parameter | Prerequisite | Description | User interface |
|-------------------------------------|--|--|--------------------------------|
| Temperature | – | Displays the temperature currently measured. <i>Dependency</i> The unit is taken from the Temperature unit parameter | Signed floating-point number |
| Calculated saturated steam pressure | The following conditions are met: <ul style="list-style-type: none"> Order code for "Sensor version", option "Mass flow" The Steam option is selected in the Select medium parameter. | Displays the saturated steam pressure currently calculated. <i>Dependency</i> The unit is taken from the Pressure unit parameter | Signed floating-point number |
| Steam quality | The following conditions are met: <ul style="list-style-type: none"> Order code for "Sensor version", option "Mass flow" The Steam option is selected in the Select medium parameter. | Displays the current steam quality. Depends on the compensation mode of the steam quality (Steam quality parameter (7605)). | Signed floating-point number |
| Total mass flow | The following conditions are met: <ul style="list-style-type: none"> Order code for "Application package", option EU "Wet steam measurement" The Steam option is selected in the Select medium parameter. | Displays the total mass flow currently calculated (steam and condensate). <i>Dependency</i> The unit is taken from the Mass flow unit parameter | Signed floating-point number |
| Condensate mass flow | The following conditions are met: <ul style="list-style-type: none"> Order code for "Application package", option EU "Wet steam measurement" The Steam option is selected in the Select medium parameter. | Displays the condensate mass flow currently calculated. <i>Dependency</i> The unit is taken from the Mass flow unit parameter | Signed floating-point number |
| Energy flow | For the following order code: "Sensor version", option "Mass flow" | Displays the energy flow currently calculated. <i>Dependency</i> The unit is taken from the Energy flow unit parameter | Signed floating-point number |
| Heat flow difference | The following conditions are met: <ul style="list-style-type: none"> Order code for "Sensor version", option "Mass flow" In the Select gas type parameter, one of the following options is selected: <ul style="list-style-type: none"> Single gas Gas mixture Natural gas User-specific gas | Displays the heat flow difference currently calculated. <i>Dependency</i> The unit is taken from the Energy flow unit parameter | Signed floating-point number |
| Reynolds number | For the following order code: "Sensor version", option "Mass flow" | Displays the Reynolds number currently calculated. | Signed floating-point number |
| Density | For the following order code: "Sensor version", option "Mass flow" | Displays the density currently measured. <i>Dependency</i> The unit is taken from the Density unit parameter | Positive floating-point number |
| Specific volume | For the following order code: "Sensor version", option "Mass flow" | Displays the current value for the specific volume. <i>Dependency</i> The unit is taken from the Specific volume unit parameter | Positive floating-point number |
| Pressure | For the following order code: <ul style="list-style-type: none"> "Sensor version", option "Mass flow" In the External value parameter, the Pressure option is selected. | Displays the current process pressure. <i>Dependency</i> The unit is taken from the Pressure unit parameter | 0 to 250 bar |


| Parameter | Prerequisite | Description | User interface |
|------------------------|--|---|----------------|
| Compressibility factor | The following conditions are met: Order code for "Sensor version", option "Mass flow" In the Select medium parameter, the Gas option or Steam option is selected. | Displays the compressibility factor currently calculated. | 0 to 2 |
| Degrees of superheat | In the Select medium parameter, the Steam option is selected. | Displays the degree of superheating currently calculated. | 0 to 500 K |

11.4.2 Totalizer

The **Totalizer** submenu contains all the parameters needed to display the current measured values for every totalizer.

Navigation

"Diagnostics" menu → Measured values → Totalizer



Parameter overview with brief description

| Parameter | Prerequisite | Description | User interface |
|---------------------------|---|---|------------------------------|
| Totalizer value 1 to 3 | One of the following options is selected in the Assign process variable parameter (→ ⓘ 117) of the Totalizer 1 to 3 submenu: <ul style="list-style-type: none"> ▪ Volume flow ▪ Corrected volume flow ▪ Mass flow ▪ Total mass flow * ▪ Condensate mass flow * ▪ Energy flow * ▪ Heat flow difference * | Displays the current totalizer counter value. | Signed floating-point number |
| Totalizer overflow 1 to 3 | One of the following options is selected in the Assign process variable parameter (→ ⓘ 117) of the Totalizer 1 to 3 submenu: <ul style="list-style-type: none"> ▪ Volume flow ▪ Corrected volume flow ▪ Mass flow ▪ Total mass flow * ▪ Condensate mass flow * ▪ Energy flow * ▪ Heat flow difference * | Displays the current totalizer overflow. | Integer with sign |

* Visibility depends on order options or device settings

11.4.3 Input values


The **Input values** submenu guides you systematically to the individual input values.

The submenu only appears if the device was ordered with a current input → ⓘ 32.

Navigation

"Diagnostics" menu → Measured values → Input values

Structure of the submenu



Parameter overview with brief description


| Parameter | Description | User interface |
|--------------------|--|------------------------------|
| Measured current 1 | Displays the current value of the current input. | 3.59 to 22.5 mA |
| Measured values 1 | Displays the current input value. <i>Dependency</i> The display depends on the option selected in the External value parameter. | Signed floating-point number |

11.4.4 Output values

The **Output values** submenu contains all the parameters needed to display the current measured values for every output.

Navigation

"Diagnostics" menu → Measured values → Output values



Parameter overview with brief description

| Parameter | Prerequisite | Description | User interface |
|--------------------|--|--|--|
| Output current 1 | – | Displays the current value currently calculated for the current output. | 3.59 to 22.5 mA |
| Measured current 1 | – | Displays the current value currently measured for the current output. | 0 to 30 mA |
| Terminal voltage 1 | – | Displays the current terminal voltage that is applied at the current output. | 0.0 to 50.0 V |
| Output current 2 | – | Displays the current value currently calculated for the current output. | 3.59 to 22.5 mA |
| Pulse output | The Pulse option is selected in the Operating mode parameter. | Displays the pulse frequency currently output. | Positive floating-point number |
| Output frequency | In the Operating mode parameter, the Frequency option is selected. | Displays the value currently measured for the frequency output. | 0 to 1250 Hz |
| Switch status | In the Operating mode parameter, the Switch option is selected. | Displays the current switch output status. | <ul style="list-style-type: none"> ▪ Open ▪ Closed |

11.5 Adapting the measuring device to the process conditions

The following are available for this purpose:

- Basic settings using the **Setup** menu →  69
- Advanced settings using the **Advanced setup** submenu →  95

11.6 Performing a totalizer reset

The totalizers are reset in the **Operation** submenu:

- Control Totalizer
- Reset all totalizers

Function scope of the "Control Totalizer" parameter


| Options | Description |
|-------------------|---|
| Totalize | The totalizer is started. |
| Reset + hold | The totaling process is stopped and the totalizer is reset to 0. |
| Preset + hold | The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter. |
| Reset + totalize | The totalizer is reset to 0 and the totaling process is restarted. |
| Preset + totalize | The totalizer is set to the defined start value from the Preset value parameter and the totaling process is restarted. |
| Hold | Totalizing is stopped. |

Function scope of the "Reset all totalizers" parameter

| Options | Description |
|------------------|--|
| Reset + totalize | Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized. |

Navigation

"Operation" menu → Totalizer handling



Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|--------------------------|--|--|--|---|
| Control Totalizer 1 to 3 | One of the following options is selected in the Assign process variable parameter (→ ☰ 117) of the Totalizer 1 to 3 submenu: <ul style="list-style-type: none"> ▪ Volume flow ▪ Corrected volume flow ▪ Mass flow ▪ Total mass flow * ▪ Condensate mass flow * ▪ Energy flow * ▪ Heat flow difference * | Control totalizer value. | <ul style="list-style-type: none"> ▪ Totalize ▪ Reset + hold ▪ Preset + hold ▪ Reset + totalize ▪ Preset + totalize | Totalize |
| Preset value 1 to 3 | One of the following options is selected in the Assign process variable parameter (→ ☰ 117) of the Totalizer 1 to 3 submenu: <ul style="list-style-type: none"> ▪ Volume flow ▪ Corrected volume flow ▪ Mass flow ▪ Total mass flow * ▪ Condensate mass flow * ▪ Energy flow * ▪ Heat flow difference * | Specify start value for totalizer. <i>Dependency</i> The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→ ☰ 89). | Signed floating-point number | Country-specific: <ul style="list-style-type: none"> ▪ 0 m³ ▪ 0 ft³ |
| Reset all totalizers | – | Reset all totalizers to 0 and start. | <ul style="list-style-type: none"> ▪ Cancel ▪ Reset + totalize | Cancel |

* Visibility depends on order options or device settings


11.7 Showing data logging

The **Extended HistoROM** application package must be enabled in the device (order option) for the **Data logging** submenu to appear. This contains all the parameters for the measured value history.

The measured value history is also available via the FieldCare plant asset management tool → ☰ 60.

Function scope

- A total of 1000 measured values can be stored
- 4 logging channels
- Adjustable logging interval for data logging
- Display of the measured value trend for each logging channel in the form of a chart



A0016222

33 Chart of a measured value trend

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

i If the length of the logging interval or the assignment of the process variables to the channels is changed, the content of the data logging is deleted.

Navigation

"Diagnostics" menu → Data logging

"Data logging" submenu

▶ Data logging

Assign channel 1

Assign channel 2

Assign channel 3

Assign channel 4

Logging interval

Clear logging data




▶ Display channel 1

▶ Display channel 2

▶ Display channel 3

▶ Display channel 4

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------------------|---|--|---|-----------------|
| Assign channel 1 to 4 | <p>The Extended HistoROM application package is available.</p> <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | Assign process variable to logging channel. | <ul style="list-style-type: none"> ▪ Off ▪ Volume flow ▪ Corrected volume flow ▪ Mass flow ▪ Flow velocity ▪ Temperature ▪ Calculated saturated steam pressure ▪ Steam quality ▪ Total mass flow ▪ Condensate mass flow ▪ Energy flow ▪ Heat flow difference ▪ Reynolds number ▪ Current output 1 ▪ Current output 2 * ▪ Density ▪ Pressure ▪ Specific volume ▪ Degrees of superheat ▪ Vortex frequency ▪ Electronic temperature | Off |
| Logging interval | <p>The Extended HistoROM application package is available.</p> <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | Define the logging interval for data logging. This value defines the time interval between the individual data points in the memory. | 1.0 to 3 600.0 s | 10.0 s |
| Clear logging data | <p>The Extended HistoROM application package is available.</p> <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | Clear the entire logging data. | <ul style="list-style-type: none"> ▪ Cancel ▪ Clear data | Cancel |

* Visibility depends on order options or device settings

12 Diagnostics and troubleshooting

12.1 General troubleshooting






For local display

| Problem | Possible causes | Remedy |
|---|--|--|
| Local display dark and no output signals | Supply voltage does not match the value indicated on the nameplate. | Apply the correct supply voltage . |
| Local display dark and no output signals | The polarity of the supply voltage is wrong. | Correct the polarity. |
| Local display dark and no output signals | No contact between connecting cables and terminals. | Check the connection of the cables and correct if necessary. |
| Local display dark and no output signals | Terminals are not plugged into the I/O electronics module correctly. | Check terminals. |
| Local display dark and no output signals | I/O electronics module is defective. | Order spare part → 156. |
| Local display is dark, but signal output is within the valid range | Display is set too bright or too dark. | <ul style="list-style-type: none"> ▪ Set the display brighter by simultaneously pressing $\square + \square$. ▪ Set the display darker by simultaneously pressing $\square + \square$. |
| Local display is dark, but signal output is within the valid range | The cable of the display module is not plugged in correctly. | Insert the plug correctly into the main electronics module and display module. |
| Local display is dark, but signal output is within the valid range | Display module is defective. | Order spare part → 156. |
| Backlighting of local display is red | Diagnostic event with "Alarm" diagnostic behavior has occurred. | Take remedial measures → 144 |
| Text on local display appears in a foreign language and cannot be understood. | Incorrect operating language is configured. | <ol style="list-style-type: none"> 1. Press $\square + \square$ for 2 s ("home position"). 2. Press \square. 3. Set the desired language in the Language parameter. |
| Message on local display: "Communication Error" "Check Electronics" | Communication between the display module and the electronics is interrupted. | <ul style="list-style-type: none"> ▪ Check the cable and the connector between the main electronics module and display module. ▪ Order spare part → 156. |

For output signals

| Problem | Possible causes | Remedy |
|---|--|---|
| Signal output outside the valid range | Main electronics module is defective. | Order spare part → 156. |
| Signal output outside the valid current range (< 3.6 mA or > 22 mA) | I/O electronics module is defective. | Order spare part → 156. |
| Device shows correct value on local display, but signal output is incorrect, though in the valid range. | Configuration error | Check and correct the parameter configuration. |
| Device measures incorrectly. | Configuration error or device is operated outside the application. | <ol style="list-style-type: none"> 1. Check and correct parameter configuration. 2. Observe limit values specified in the "Technical Data". |


For access

| Problem | Possible causes | Remedy |
|-------------------------------------|---|--|
| No write access to parameters | Hardware write protection enabled | Set the write protection switch on the main electronics module to the OFF position . |
| No write access to parameters | Current user role has limited access authorization | 1. Check user role →  58. 2. Enter correct customer-specific access code →  58. |
| No connection via HART protocol | Communication resistor missing or incorrectly installed. | Install the communication resistor (250 Ω) correctly. Observe the maximum load →  34. |
| No connection via HART protocol | Commubox <ul style="list-style-type: none"> ▪ Connected incorrectly ▪ Configured incorrectly ▪ Drivers not installed correctly ▪ USB interface on computer configured incorrectly | Observe the documentation for the Commubox.  FXA195 HART: Document "Technical Information" TI00404F |
| No connection via service interface | Incorrect configuration of USB interface on PC or driver not installed correctly. | Observe the documentation for the Commubox.  FXA291: Document "Technical Information" TI00405C |

12.2 Diagnostic information on local display

12.2.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the operational display.



If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.

- i** Other diagnostic events that have occurred can be called up in the **Diagnostics** menu:
 - Via parameters → 147
 - Via submenus → 148



Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

- i** The status signals are categorized according to VDI/VDE 2650 and NAMUR Recommendation NE 107: F = Failure, C = Function Check, S = Out of Specification, M = Maintenance Required


| Symbol | Meaning |
|-------------------------------------|--|
| F <small>A0013956</small> | Failure A device error has occurred. The measured value is no longer valid. |
| C <small>A0013959</small> | Function check The device is in service mode (e.g. during a simulation). |
| S <small>A0013958</small> | Out of specification The device is operated: <ul style="list-style-type: none"> ▪ Outside its technical specification limits (e.g. outside the process temperature range) ▪ Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value) |
| M <small>A0013957</small> | Maintenance required Maintenance is required. The measured value remains valid. |

Diagnostic behavior



| Symbol | Meaning |
|--|--|
|  <small>A0013961</small> | Alarm <ul style="list-style-type: none"> Measurement is interrupted. Signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. For local display with touch control: the background lighting changes to red. |
|  <small>A0013962</small> | Warning Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated. |

Diagnostic information


The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



Operating elements

| Key | Meaning |
|--|---|
|  <small>A0013970</small> | Plus key <i>In a menu, submenu</i> Opens the message about remedy information. |
|  <small>A0013952</small> | Enter key <i>In a menu, submenu</i> Opens the operating menu. |

12.2.2 Calling up remedial measures



34 Message for remedial measures

- 1 Diagnostic information
- 2 Short text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operation time of occurrence
- 6 Remedial measures

The user is in the diagnostic message.

1. Press **+** (**+** symbol).
 - ↳ The **Diagnostic list** submenu opens.
2. Select the desired diagnostic event with **+** or **-** and press **↵**.
 - ↳ The message for the remedial measures for the selected diagnostic event opens.
3. Press **-** + **+** simultaneously.
 - ↳ The message for the remedial measures closes.


The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in the **Diagnostic list** submenu or the **Previous diagnostics** parameter.

1. Press **↵**.
 - ↳ The message for the remedial measures for the selected diagnostic event opens.
2. Press **-** + **+** simultaneously.
 - ↳ The message for the remedial measures closes.

12.3 Diagnostic information in FieldCare

12.3.1 Diagnostic options

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.



A0021799-EN


- 1 Status area with status signal → 139
- 2 Diagnostic information → 140
- 3 Remedy information with Service ID

i Furthermore, diagnostic events that have occurred can be viewed in the **Diagnostics** menu:

- Via parameter → 147
- Via submenu → 148

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



12.3.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page
Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu
Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.


1. Call up the desired parameter.
2. On the right in the working area, mouse over the parameter.
 - ↳ A tool tip with remedy information for the diagnostic event appears.

12.4 Adapting the diagnostic information

12.4.1 Adapting the diagnostic behavior

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for certain diagnostic information in the **Diagnostic behavior** submenu.

"Expert" menu → System → Diagnostic handling → Diagnostic behavior



35 Taking the example of the local display

You can assign the following options to the diagnostic number as the diagnostic behavior:

| Options | Description |
|--------------------|---|
| Alarm | Measurement is interrupted. Signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. For local display with touch control: the background lighting changes to red. |
| Warning | Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated. |
| Logbook entry only | The device continues to measure. The diagnostic message is entered in the Event logbook (events list) submenu only and is not displayed in alternation with the measured value display. |
| Off | The diagnostic event is ignored, and no diagnostic message is generated or entered. |

12.4.2 Adapting the status signal

Each item of diagnostic information is assigned a specific status signal at the factory. The user can change this assignment for certain diagnostic information in the **Diagnostic event category** submenu .

"Expert" menu → Communication → Diagnostic event category


Available status signals



Configuration as per HART 7 Specification (Condensed Status), in accordance with NAMUR NE107.

| Symbol | Meaning |
|-------------------------------------|---|
| F <small>A0013956</small> | Failure A device error has occurred. The measured value is no longer valid. |
| C <small>A0013959</small> | Function check The device is in service mode (e.g. during a simulation). |

| Symbol | Meaning |
|-------------------------------------|--|
| S <small>A0013958</small> | Out of specification The device is operated: <ul style="list-style-type: none"> ▪ Outside its technical specification limits (e.g. outside the process temperature range) ▪ Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value) |
| M <small>A0013957</small> | Maintenance required Maintenance is required. The measured value remains valid. |
| N <small>A0023076</small> | Has no effect on the condensed status. |

12.5 Overview of diagnostic information

 The amount of diagnostic information and the number of measured variables affected increase if the measuring device has one or more application packages.

 In the case of some items of diagnostic information, the status signal and the diagnostic behavior can be changed. Change the diagnostic information →  143


| Diagnostic number | Short text | Remedy instructions | Status signal [from the factory] | Diagnostic behavior [from the factory] |
|---------------------------------|------------------------------|---|----------------------------------|--|
| Diagnostic of sensor | | | | |
| 004 | Sensor defective | 1. Check plug connections 2. Change pre-amplifier 3. Change DSC sensor | F | Alarm |
| 022 | Temperature sensor defective | 1. Check plug connections 2. Change pre-amplifier 3. Change DSC sensor | F | Alarm ¹⁾ |
| 046 | Sensor limit exceeded | 1. Check plug connections 2. Change pre-amplifier 3. Change DSC sensor | S | Warning |
| 062 | Sensor connection defective | 1. Check plug connections 2. Change pre-amplifier 3. Change DSC sensor | F | Alarm |
| 082 | Data storage | 1. Change main electronic module 2. Change sensor | F | Alarm |
| 083 | Memory content | 1. Restart device 2. Restore S-Dat data 3. Change sensor | F | Alarm |
| 114 | Sensor leaky | Change DSC sensor | F | Alarm |
| 122 | Temperature sensor defective | 1. Check plug connections 2. Change pre-amplifier 3. Change DSC sensor | M | Warning ¹⁾ |
| Diagnostic of electronic | | | | |
| 242 | Software incompatible | 1. Check software 2. Flash or change main electronics module | F | Alarm |
| 252 | Modules incompatible | 1. Check electronic modules 2. Change I/O or main electronic module | F | Alarm |
| 261 | Electronic modules | 1. Restart device 2. Check electronic modules 3. Change I/O Modul or main electronics | F | Alarm |

| Diagnostic number | Short text | Remedy instructions | Status signal [from the factory] | Diagnostic behavior [from the factory] |
|------------------------------------|------------------------------|---|----------------------------------|--|
| 262 | Module connection | 1. Check module connections 2. Change electronic modules | F | Alarm |
| 270 | Main electronic failure | Change main electronic module | F | Alarm |
| 271 | Main electronic failure | 1. Restart device 2. Change main electronic module | F | Alarm |
| 272 | Main electronic failure | 1. Restart device 2. Contact service | F | Alarm |
| 273 | Main electronic failure | 1. Emergency operation via display 2. Change main electronics | F | Alarm |
| 275 | I/O module failure | Change I/O module | F | Alarm |
| 276 | I/O module failure | 1. Restart device 2. Change I/O module | F | Alarm |
| 277 | Electronics defective | 1. Change pre-amplifier 2. Change main electronic module | F | Alarm |
| 282 | Data storage | 1. Restart device 2. Contact service | F | Alarm |
| 283 | Memory content | 1. Transfer data or reset device 2. Contact service | F | Alarm |
| 302 | Device verification active | Device verification active, please wait. | C | Warning |
| 311 | Electronic failure | 1. Transfer data or reset device 2. Contact service | F | Alarm |
| 311 | Electronic failure | Maintenance required! 1. Do not perform reset 2. Contact service | M | Warning |
| 350 | Pre-amplifier defective | Change pre-amplifier | F | Alarm ¹⁾ |
| 351 | Pre-amplifier defective | Change pre-amplifier | F | Alarm |
| 370 | Pre-amplifier defective | 1. Check plug connections 2. Check cabel connection of remote version 3. Change pre-amplifier or main electronic module | F | Alarm |
| 371 | Temperature sensor defective | 1. Check plug connections 2. Change pre-amplifier 3. Change DSC sensor | M | Warning ¹⁾ |
| Diagnostic of configuration | | | | |
| 410 | Data transfer | 1. Check connection 2. Retry data transfer | F | Alarm |
| 412 | Processing Download | Download active, please wait | C | Warning |
| 431 | Trim 1 to 2 | Carry out trim | C | Warning |
| 437 | Configuration incompatible | 1. Restart device 2. Contact service | F | Alarm |
| 438 | Dataset | 1. Check data set file 2. Check device configuration 3. Up- and download new configuration | M | Warning |
| 441 | Current output 1 to 2 | 1. Check process 2. Check current output settings | S | Warning ¹⁾ |
| 442 | Frequency output | 1. Check process 2. Check frequency output settings | S | Warning ¹⁾ |

| Diagnostic number | Short text | Remedy instructions | Status signal [from the factory] | Diagnostic behavior [from the factory] |
|------------------------------|---------------------------------------|--|----------------------------------|--|
| 443 | Pulse output | 1. Check process 2. Check pulse output settings | S | Warning ¹⁾ |
| 444 | Current input 1 | 1. Check process 2. Check current input settings | S | Warning ¹⁾ |
| 453 | Flow override | Deactivate flow override | C | Warning |
| 484 | Simulation failure mode | Deactivate simulation | C | Alarm |
| 485 | Simulation measured variable | Deactivate simulation | C | Warning |
| 486 | Simulation current input 1 | Deactivate simulation | C | Warning |
| 491 | Simulation current output 1 to 2 | Deactivate simulation | C | Warning |
| 492 | Simulation frequency output | Deactivate simulation frequency output | C | Warning |
| 493 | Simulation pulse output | Deactivate simulation pulse output | C | Warning |
| 494 | Switch output simulation | Deactivate simulation switch output | C | Warning |
| 495 | Simulation diagnostic event | Deactivate simulation | C | Warning |
| 538 | Flow computer configuration incorrect | Check input value (pressure, temperature) | S | Warning |
| 539 | Flow computer configuration incorrect | 1. Check input value (pressure, temperature) 2. Check allowed values of the medium properties | S | Alarm |
| 540 | Flow computer configuration incorrect | Check entered reference value using the document Operating Instructions | S | Warning |
| 570 | Inverted delta heat | Check configuration of mounting location (parameter Installation direction) | F | Alarm |
| Diagnostic of process | | | | |
| 801 | Supply voltage too low | Increase supply voltage | S | Warning |
| 803 | Current loop | 1. Check wiring 2. Change I/O module | F | Alarm |
| 828 | Ambient temperature too low | Increase ambient temperature of pre-amplifier | S | Warning ¹⁾ |
| 829 | Ambient temperature too high | Reduce ambient temperature of pre-amplifier | S | Warning ¹⁾ |
| 832 | Electronic temperature too high | Reduce ambient temperature | S | Warning ¹⁾ |
| 833 | Electronic temperature too low | Increase ambient temperature | S | Warning ¹⁾ |
| 834 | Process temperature too high | Reduce process temperature | S | Warning ¹⁾ |
| 835 | Process temperature too low | Increase process temperature | S | Warning ¹⁾ |
| 841 | Flow velocity too high | Reduce flow velocity | S | Warning ¹⁾ |
| 842 | Process limit | Low flow cut off active! 1. Check low flow cut off configuration | S | Warning |






| Diagnostic number | Short text | Remedy instructions | Status signal [from the factory] | Diagnostic behavior [from the factory] |
|-------------------|-------------------------------------|---|----------------------------------|--|
| 844 | Sensor range exceeded | Reduce flow velocity | S | Warning ¹⁾ |
| 870 | Measuring inaccuracy increased | 1. Check process 2. Increase flow volume | S | Warning ¹⁾ |
| 871 | Near steam saturation limit | Check process conditions | S | Warning ¹⁾ |
| 872 | Wet steam detected | 1. Check process 2. Check plant | S | Warning ¹⁾ |
| 873 | Water detected | Check process (water in piping) | S | Warning ¹⁾ |
| 874 | X% spec invalid | 1. Check pressure, temperature 2. Check flow velocity 3. Check for flow fluctuation | S | Warning ¹⁾ |
| 882 | Input signal | 1. Check input configuration 2. Check external device or process conditions | F | Alarm |
| 945 | Sensor range exceeded | Check immediately process conditions (pressure-temperature rating) | S | Warning ¹⁾ |
| 946 | Vibration detected | Check installation | S | Warning |
| 947 | Vibration exceeded | Check installation | S | Alarm ¹⁾ |
| 972 | Degrees of superheat limit exceeded | 1. Controll process conditions 2. Install pressure transmitter or enter correct fixed pressure value | S | Warning ¹⁾ |

1) Diagnostic behavior can be changed.

-  Operating conditions for displaying the following diagnostics information:
- Diagnostics information 871: The process temperature is less than 2K from the saturated steam line.
 - Diagnostics information 872: The measured steam quality has dropped below the configured limit value for the steam quality (limit value: "Expert" menu → System → Diagnostic handling → Diagnostic limits → Steam quality limit).
 - Diagnostics information 873: The process temperature is ≤ 0 °C.
 - Diagnostics information 874: Wet steam detection/measurement is outside the specified limits for the following process parameters: pressure, temperature, velocity.
 - Diagnostics information 972: The degree of superheat has exceeded the configured limit value (limit value: "Expert" menu → System → Diagnostic handling → Diagnostic limits → Degrees of superheat limit).


12.6 Pending diagnostic events

The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.

-  To call up the measures to rectify a diagnostic event:
- Via local display →  141
 - Via "FieldCare" operating tool →  142
-  Other pending diagnostic events can be displayed in the **Diagnostic list** submenu →  148

Navigation

"Diagnostics" menu

Structure of the submenu**Parameter overview with brief description**


| Parameter | Prerequisite | Description | User interface |
|-----------------------------|--|--|--|
| Actual diagnostics | A diagnostic event has occurred. | Shows the current occurred diagnostic event along with its diagnostic information. If two or more messages occur simultaneously, the message with the highest priority is shown on the display. | Symbol for diagnostic behavior, diagnostic code and short message. |
| Previous diagnostics | Two diagnostic events have already occurred. | Shows the diagnostic event that occurred prior to the current diagnostic event along with its diagnostic information. | Symbol for diagnostic behavior, diagnostic code and short message. |
| Operating time from restart | - | Shows the time the device has been in operation since the last device restart. | Days (d), hours (h), minutes (m) and seconds (s) |
| Operating time | - | Indicates how long the device has been in operation. | Days (d), hours (h), minutes (m) and seconds (s) |

12.7 Diagnostic list

In the **Diagnostic list** submenu, up to 5 currently pending diagnostic events can be displayed along with the related diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

Navigation path

Diagnostics menu → Diagnostic list submenu



A0014006-EN

36 Taking the example of the local display

To call up the measures to rectify a diagnostic event:

- Via local display → 141
- Via "FieldCare" operating tool → 142


12.8 Event logbook

12.8.1 Event history

A chronological overview of the event messages that have occurred is provided in the **Events list** submenu.

Navigation path

"Diagnostics" menu → Event logbook → Events list



37 Taking the example of the local display

A maximum of 20 event messages can be displayed in chronological order. If the advanced HistoROM function is enabled in the device (order option), up to 100 entries can be displayed.

The event history includes entries for:

- Diagnostic events → 144
- Information events → 149

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
 - ⌚: Event has occurred
 - ⌚: Event has ended
- Information event
 - ⌚: Event has occurred

i To call up the measures to rectify a diagnostic event:

- Via local display → 141
- Via "FieldCare" operating tool → 142

i For filtering the displayed event messages → 149

12.8.2 Filtering the event logbook

Using the **Filter options** parameter, you can define which category of event messages is displayed in the **Events list** submenu.

Navigation path

"Diagnostics" menu → Event logbook → Filter options

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

12.8.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

| Info number | Info name |
|-------------|--------------------------------------|
| I1000 | ----- (Device ok) |
| I1079 | Sensor changed |
| I1089 | Power on |
| I1090 | Configuration reset |
| I1091 | Configuration changed |
| I1092 | Trend data deleted |
| I1110 | Write protection switch changed |
| I1137 | Electronic changed |
| I1151 | History reset |
| I1154 | Reset terminal voltage min/max |
| I1155 | Reset electronic temperature |
| I1156 | Memory error trend |
| I1157 | Memory error event list |
| I1185 | Display backup done |
| I1186 | Restore via display done |
| I1187 | Settings downloaded with display |
| I1188 | Display data cleared |
| I1189 | Backup compared |
| I1227 | Sensor emergency mode activated |
| I1228 | Sensor emergency mode failed |
| I1256 | Display: access status changed |
| I1264 | Safety sequence aborted |
| I1335 | Firmware changed |
| I1397 | Fieldbus: access status changed |
| I1398 | CDI: access status changed |
| I1444 | Device verification passed |
| I1445 | Device verification failed |
| I1459 | Failed: I/O module verification |
| I1461 | Failed: Sensor verification |
| I1512 | Download started |
| I1513 | Download finished |
| I1514 | Upload started |
| I1515 | Upload finished |
| I1552 | Failed: Main electronic verification |
| I1553 | Failed: Pre-amplifier verification |

12.9 Resetting the measuring device

Using the **Device reset** parameter it is possible to reset the entire device configuration or some of the configuration to a defined state.

Navigation

"Setup" menu → Advanced setup → Administration → Device reset

The screenshot shows a menu structure starting with 'Administration'. Under 'Administration', there is an option for 'Define access code'. Below this, there are two input fields: 'Define access code' and 'Confirm access code'. At the bottom of the menu, there is a 'Device reset' option.

Parameter overview with brief description

| Parameter | Description | Selection | Factory setting |
|--------------|---|---|-----------------|
| Device reset | Reset the device configuration - either entirely or in part - to a defined state. | <ul style="list-style-type: none"> ▪ Cancel ▪ To factory defaults ▪ To delivery settings ▪ Restart device | Cancel |

12.9.1 Function scope of the "Device reset" parameter

| Options | Description |
|----------------------|---|
| Cancel | No action is executed and the user exits the parameter. |
| To delivery settings | Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting. |
| Restart device | The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged. |
| History reset | Every parameter is reset to the factory setting. |

12.10 Device information

The **Device information** submenu contains all the parameters that display different information for identifying the device.





Navigation


"Diagnostics" menu → Device information

The screenshot shows a menu structure starting with 'Device information'. Under 'Device information', there are three options: 'Device tag', 'Serial number', and 'Firmware version'.

| |
|-----------------------|
| Device name |
| Order code |
| Extended order code 1 |
| Extended order code 2 |
| Extended order code 3 |
| ENP version |
| Device revision |
| Device ID |
| Device type |
| Manufacturer ID |


Parameter overview with brief description


| Parameter | Description | User interface | Factory setting |
|-----------------------|--|---|-----------------|
| Device tag | Display the name for the measuring point. | Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /) | Prowirl |
| Serial number | Shows the serial number of the measuring device. | A maximum of 11-digit character string comprising letters and numbers. | – |
| Firmware version | Shows the device firmware version installed. | Character string in the format xx.yy | 01.02 |
| Device name | Shows the name of the transmitter.  The name can be found on the nameplate of the transmitter. | Prowirl | – |
| Order code | Shows the device order code.  The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field. | Character string composed of letters, numbers and certain punctuation marks (e.g. /). | – |
| Extended order code 1 | Shows the 1st part of the extended order code.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field. | Character string | – |
| Extended order code 2 | Shows the 2nd part of the extended order code.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field. | Character string | – |


| Parameter | Description | User interface | Factory setting |
|-----------------------|--|----------------------------|-----------------|
| Extended order code 3 | Shows the 3rd part of the extended order code.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field. | Character string | – |
| ENP version | Shows the version of the electronic nameplate (ENP). | Character string | 2.02.00 |
| Device revision | Shows the device revision with which the device is registered with the HART Communication Foundation. | 2-digit hexadecimal number | 0x03 |
| Device ID | Enter device ID of external device. | 6-digit hexadecimal number | – |
| Device type | Displays the device type with which the measuring device is registered with the HART Communication Foundation. | 0 to 255 | 0x38 |
| Manufacturer ID | Displays the manufacturer ID with which the measuring device is registered with the HART Communication Foundation. | 0 to 255 | 0x11 |

12.11 Firmware history

| Release date | Firmware version | Order code for "Firmware version" | Firmware changes | Documentation type | Documentation |
|--------------|------------------|-----------------------------------|---|------------------------|----------------------|
| 10.2014 | 01.02.00 | Option 74 | <ul style="list-style-type: none"> ▪ No need to restart device after parameter download ▪ Additional process variables: <ul style="list-style-type: none"> – Pressure – Degree of overheating – Specific volume ▪ Process variables interconnectable with local display, the data logger (trend) and as HART device variable ▪ Verification progress is displayed (0-100%) ▪ New Wet Steam Measurement application package ▪ Operation in steam simplified ▪ More robust signal processing in event of low flow rates in wet steam | Operating Instructions | BA01153D/06/EN/03.14 |
| 02.2014 | 01.01.00 | Option 75 | In accordance with HART 7 Specification | Operating Instructions | BA01153D/06/EN/02.14 |
| 09.2013 | 01.00.00 | Option 76 | Original firmware | Operating Instructions | BA01153D/06/EN/01.13 |

 Flashing the firmware to the current version or to the previous version is possible via the service interface (CDI) .

 For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.

 The manufacturer's information is available:

- In the Downloads area of the Endress+Hauser web site: www.endress.com → Downloads
- Specify the following details:
 - Text search: Manufacturer's information
 - Media type: Documentation – Technical Documentation

13 Maintenance

13.1 Maintenance tasks

No special maintenance work is required.

13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

13.1.2 Interior cleaning

NOTICE

The use of unsuitable equipment or cleaning liquids can damage the transducer.

- ▶ Do not use pigs to clean the pipe.

13.1.3 Replacing seals

Replacing sensor seals

NOTICE

Under normal circumstances, wetted seals must not be replaced.

Replacement is necessary only in special circumstances, for example if aggressive or corrosive fluids are incompatible with the seal material.

- ▶ The time span between the individual replacement procedures depends on the fluid properties.
- ▶ Only Endress+Hauser sensor seals may be used: replacement seals

Replacing housing seals

The housing seals must be clean and undamaged when inserted into their grooves. Dry, clean or replace the seals if necessary.

NOTICE


When the measuring device is used in a dusty atmosphere:

- ▶ only use the associated Endress+Hauser housing seals.

13.2 Measuring and test equipment


Endress+Hauser offers a wide variety of measuring and test equipment, such as W@M or device tests.

 Your Endress+Hauser Sales Center can provide detailed information on the services.

 For a list of some of the measuring and test equipment, refer to the "Accessories" chapter of the "Technical Information" document for the device.

13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

 Your Endress+Hauser Sales Center can provide detailed information on the services.

14 Repair

14.1 General notes

Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by correspondingly trained customers.
- Certified devices can be converted into other certified devices by Endress+Hauser Service or at the factory only.

Notes for repair and conversion

For repair and modification of a measuring device, observe the following notes:


- Use only original Endress+Hauser spare parts.
- Carry out the repair according to the Installation Instructions.
- Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- Document every repair and each conversion and enter them into the *W@M* life cycle management database.

14.2 Spare parts

Some interchangeable measuring device components are listed on an overview sign in the connection compartment cover.

The spare part overview sign contains the following information:

- A list of the most important spare parts for the measuring device, including their ordering information.
- The URL for the *W@M Device Viewer* (www.endress.com/deviceviewer):
All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.



38 Example for "Spare part overview sign" in connection compartment cover

- 1 Measuring device name
- 2 Measuring device serial number

- i** Measuring device serial number:
- Is located on the device nameplate and the spare part overview sign.
 - Can be read out via the **Serial number** parameter in the **Device information** submenu .

14.3 Endress+Hauser services

Endress+Hauser offers a wide range of services.

- i** Your Endress+Hauser Sales Center can provide detailed information on the services.

14.4 Return

The measuring device must be returned if it is need of repair or a factory calibration, or if the wrong measuring device has been delivered or ordered. Legal specifications require Endress+Hauser, as an ISO-certified company, to follow certain procedures when handling products that are in contact with the medium.

To ensure safe, swift and professional device returns, please refer to the procedure and conditions for returning devices provided on the Endress+Hauser website at <http://www.endress.com/support/return-material>

14.5 Disposal

14.5.1 Removing the measuring device

1. Switch off the device.
2. **⚠ WARNING**

Danger to persons from process conditions.

- ▶ Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive fluids.

Carry out the mounting and connection steps from the chapters "Mounting the measuring device" and "Connecting the measuring device" in the logically reverse sequence. Observe the safety instructions.

14.5.2 Disposing of the measuring device

⚠ WARNING

Danger to personnel and environment from fluids that are hazardous to health.

- ▶ Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:





- Observe valid federal/national regulations.
- Ensure proper separation and reuse of the device components.




15 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress+Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.


15.1 Device-specific accessories

15.1.1 For the transmitter






| Accessories | Description |
|---|---|
| Prowirl 200 transmitter | <p>Transmitter for replacement or storage. Use the order code to define the following specifications:</p> <ul style="list-style-type: none"> ▪ Approvals ▪ Output ▪ Display / operation ▪ Housing ▪ Software <p> For details, see Installation Instructions EA01056D</p> |
| Remote display FHX50 | <p>FHX50 housing for accommodating a display module →  185.</p> <ul style="list-style-type: none"> ▪ FHX50 housing suitable for: <ul style="list-style-type: none"> – SD02 display module (push buttons) – SD03 display module (touch control) ▪ Housing material: <ul style="list-style-type: none"> – Plastic PBT – Stainless steel CF-3M (316L, 1.4404) ▪ Length of connecting cable: up to max. 60 m (196 ft) (cable lengths available for order: 5 m (16 ft), 10 m (32 ft), 20 m (65 ft), 30 m (98 ft)) <p>The measuring device can be ordered with the FHX50 housing and a display module. The following options must be selected in the separate order codes:</p> <ul style="list-style-type: none"> ▪ Order code for measuring device, feature 030: <ul style="list-style-type: none"> Option L or M "Prepared for FHX50 display" ▪ Order code for FHX50 housing, feature 050 (device version): <ul style="list-style-type: none"> Option A "Prepared for FHX50 display" ▪ Order code for FHX50 housing, depends on the desired display module in feature 020 (display, operation): <ul style="list-style-type: none"> – Option C: for an SD02 display module (push buttons) – Option E: for an SD03 display module (touch control) <p>The FHX50 housing can also be ordered as a retrofit kit. The measuring device display module is used in the FHX50 housing. The following options must be selected in the order code for the FHX50 housing:</p> <ul style="list-style-type: none"> ▪ Feature 050 (measuring device version): option B "Not prepared for FHX50 display" ▪ Feature 020 (display, operation): option A "None, existing displayed used" <p> For details, see Special Documentation SD01007F</p> <p>(Order number: FHX50)</p> |
| Overvoltage protection for 2-wire devices | <p>Ideally, the overvoltage protection module should be ordered directly with the device. See product structure, characteristic 610 "Accessory mounted", option NA "Overvoltage protection". Separate order necessary only if retrofitting.</p> <ul style="list-style-type: none"> ▪ OVP10: For 1-channel devices (characteristic 020, option A): ▪ OVP20: For 2-channel devices (characteristic 020, options B, C, E or G) <p> For details, see Special Documentation SD01090F.</p> |




| | |
|-------------------------------------|--|
| Weather protection cover | <p>Is used to protect the measuring device from the effects of the weather: e.g. rainwater, excess heating from direct sunlight or extreme cold in winter.</p> <p> For details, see Special Documentation SD00333F</p> |
| Connecting cable for remote version | <ul style="list-style-type: none"> ■ Connecting cable available in various lengths: <ul style="list-style-type: none"> - 5 m (16 ft) - 10 m (32 ft) - 20 m (65 ft) - 30 m (98 ft) ■ Reinforced cables available on request. <p> Standard length: 5 m (16 ft) Is always supplied if no other cable length has been ordered.</p> |
| Post mounting kit | <p>Post mounting kit for transmitter.</p> <p> The post mounting kit can only be ordered together with a transmitter.</p> <p>(Order number: DK8WM-B)</p> |

15.1.2 For the sensor



| Accessories | Description |
|------------------|---|
| Mounting kit | <p>Mounting set for disc (wafer version) comprising:</p> <ul style="list-style-type: none"> ■ Tie rods ■ Seals ■ Nuts ■ Washers <p> For details, see Installation Instructions EA00075D</p> <p>(Order numbers: see EA00075D)</p> |
| Flow conditioner | <p>Is used to shorten the necessary inlet run.</p> <p>(Order number: DK7ST)</p> |

15.2 Communication-specific accessories


| Accessories | Description |
|-----------------------------|---|
| Commubox FXA195 HART | <p>For intrinsically safe HART communication with FieldCare via the USB interface.</p> <p> For details, see "Technical Information" TI00404F</p> |
| Commubox FXA291 | <p>Connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) and the USB port of a computer or laptop.</p> <p> For details, see the "Technical Information" document TI405C/07</p> |
| HART Loop Converter HMX50 | <p>Is used to evaluate and convert dynamic HART process variables to analog current signals or limit values.</p> <p> For details, see "Technical Information" TI00429F and Operating Instructions BA00371F</p> |
| Wireless HART adapter SWA70 | <p>Is used for the wireless connection of field devices.</p> <p>The WirelessHART adapter can be easily integrated into field devices and existing infrastructures, offers data protection and transmission safety and can be operated in parallel with other wireless networks with minimum cabling complexity.</p> <p> For details, see Operating Instructions BA00061S</p> |
| Fieldgate FXA320 | <p>Gateway for the remote monitoring of connected 4-20 mA measuring devices via a Web browser.</p> <p> For details, see "Technical Information" TI00025S and Operating Instructions BA00053S</p> |





| | |
|--------------------|--|
| Fieldgate FXA520 | Gateway for the remote diagnostics and remote configuration of connected HART measuring devices via a Web browser.  For details, see "Technical Information" TI00025S and Operating Instructions BA00051S |
| Field Xpert SFX350 | Field Xpert SFX350 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the non-Ex area .  For details, see Operating Instructions BA01202S |
| Field Xpert SFX370 | Field Xpert SFX370 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the non-Ex area and the Ex area .  For details, see Operating Instructions BA01202S |

15.3 Service-specific accessories

| Accessories | Description |
|-------------|--|
| Applicator | Software for selecting and sizing Endress+Hauser measuring devices: <ul style="list-style-type: none"> Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, accuracy or process connections. Graphic illustration of the calculation results Administration, documentation and access to all project-related data and parameters throughout the entire life cycle of a project. Applicator is available: <ul style="list-style-type: none"> Via the Internet: https://wapps.endress.com/applicator On CD-ROM for local PC installation. |
| W@M | Life cycle management for your plant W@M supports you with a wide range of software applications over the entire process: from planning and procurement, to the installation, commissioning and operation of the measuring devices. All the relevant device information, such as the device status, spare parts and device-specific documentation, is available for every device over the entire life cycle. The application already contains the data of your Endress+Hauser device. Endress+Hauser also takes care of maintaining and updating the data records. W@M is available: <ul style="list-style-type: none"> Via the Internet: www.endress.com/lifecyclemanagement On CD-ROM for local PC installation. |
| FieldCare | FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.  For details, see Operating Instructions BA00027S and BA00059S |
| DeviceCare | Tool for connecting and configuring Endress+Hauser field devices.  For details, see Innovation brochure IN01047S |

15.4 System components

| Accessories | Description |
|--------------------------------------|--|
| Memograph M graphic display recorder | The Memograph M graphic display recorder provides information on all relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.  For details, see "Technical Information" TI00133R and Operating Instructions BA00247R |

| | |
|-----------|---|
| RN221N | <p>Active barrier with power supply for safe separation of 4-20 mA standard signal circuits. Offers bidirectional HART transmission.</p> <p> For details, see "Technical Information" TI00073R and Operating Instructions BA00202R</p> |
| RNS221 | <p>Supply unit for powering two 2-wire measuring devices solely in the non-Ex area. Bidirectional communication is possible via the HART communication jacks.</p> <p> For details, see "Technical Information" TI00081R and Brief Operating Instructions KA00110R</p> |
| Cerabar M | <p>The pressure transmitter for measuring the absolute and gauge pressure of gases, steam and liquids. It can be used to read in the operating pressure value.</p> <p> For details, see "Technical Information" TI00426P, TI00436P and Operating Instructions BA00200P, BA00382P</p> |
| Cerabar S | <p>The pressure transmitter for measuring the absolute and gauge pressure of gases, steam and liquids. It can be used to read in the operating pressure value.</p> <p> For details, see "Technical Information" TI00383P and Operating Instructions BA00271P</p> |

16 Technical data


16.1 Application

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are adequately resistant.

16.2 Function and system design

| | |
|---------------------|--|
| Measuring principle | Vortex meters work on the principle of the <i>Karman vortex street</i> . |
|---------------------|--|

| | |
|------------------|---|
| Measuring system | <p>The device consists of a transmitter and a sensor.</p> <p>Two device versions are available:</p> <ul style="list-style-type: none"> ■ Compact version – transmitter and sensor form a mechanical unit. ■ Remote version - transmitter and sensor are mounted in separate locations. <p>For information on the structure of the device →  11</p> |
|------------------|---|

16.3 Input

| | |
|-------------------|--|
| Measured variable | <p>Direct measured variables</p> <p>Order code for "Sensor version":</p> <ul style="list-style-type: none"> ■ Option 1 "Volume flow, basis" and ■ Option 2 "Volume flow, high-temperature/low temperature": Volume flow <p>Order code for "Sensor version":</p> <p>Option 3 "Mass flow (integrated temperature measurement)":</p> <ul style="list-style-type: none"> – Volume flow – Temperature <p>Calculated measured variables</p> <p>Order code for "Sensor version":</p> <ul style="list-style-type: none"> ■ Option 1 "Volume flow, basis" and ■ Option 2 "Volume flow, high-temperature/low temperature": <ul style="list-style-type: none"> – In the case of constant process conditions: Mass flow ¹⁾ or Corrected volume flow – The totalized values for Volume flow, Mass flow ¹⁾, or Corrected volume flow <p>Order code for "Sensor version":</p> <p>Option 3 "Mass flow (integrated temperature measurement)":</p> <ul style="list-style-type: none"> – Corrected volume flow – Mass flow – Calculated saturated steam pressure – Energy flow |
|-------------------|--|

1) A fixed density must be entered for calculating the mass flow (Setup menu → Advanced setup submenu → External compensation submenu → Fixed density parameter).

- Heat flow difference
- Specific volume
- Degrees of superheat

Calculation of the measured variables

The meter electronics system of the Prowirl 200 unit with the order code "Sensor version", option 3 "Mass flow (integrated temperature measurement)" has a flow computer. This computer can calculate the following secondary measured variables directly from the primary measured variables recorded using the pressure value (entered or external) and/or temperature value (measured or entered).

Mass flow and corrected volume flow

| Medium | Fluid | Standards | Explanation | |
|---------------------|---------------|---------------------|---|--|
| Steam ¹⁾ | - | IAPWS-IF97/ ASME | If integrated temperature measurement is provided and the process pressure is fixed, or if the pressure is read in via the current input/HART | |
| Gas | Single gas | NEL40 | If the process pressure is fixed, or if the pressure is read in via the current input/HART | |
| | Gas mixture | NEL40 | | |
| | Air | NEL40 | | |
| | Natural gas | | ISO 12213-2 | Contains AGA8-DC92 If the process pressure is fixed, or if the pressure is read in via the current input/HART |
| | | | AGA NX-19 | If the process pressure is fixed, or if the pressure is read in via the current input/HART |
| | | ISO 12213-3 | Contains SGERG-88, AGA8 Gross Method 1 If the process pressure is fixed, or if the pressure is read in via the current input/HART | |
| | Other gases | Linear equation | Ideal gases If the process pressure is fixed, or if the pressure is read in via the current input/HART | |
| Liquids | Water | IAPWS-IF97/ ASME | | |
| | Liquefied gas | Tables | Propane and butane mixture | |
| | Other liquid | Linear equation | Ideal liquids | |

1) The Prowirl 200 is able to calculate the volume flow, and other measured variables derived from the volume flow, across all steam types with full compensation using the pressure and temperature. For information on setting the device behavior, see the "Perform external compensation" section → 113

Mass flow calculation

Volume flow × operating density

- Operating density for saturated steam, water and other liquids: depends on the temperature
- Operating density for superheated steam and all other gases: depends on the temperature and process pressure


Corrected volume flow calculation

(Volume flow × operating density)/reference density

- Operating density for water and other liquids: depends on the temperature
- Operating density for all other gases: depends on the temperature and process pressure


Energy flow

| Medium | Fluid | Standards | Explanation | Heat/energy option |
|---------------------|---------------|-----------------|---|--|
| Steam ¹⁾ | – | IAPWS-IF97/ASME | If the process pressure is fixed, or if the pressure is read in via the current input/HART | Heat Gross calorific value ²⁾ in relation to mass Net calorific value ³⁾ in relation to mass Gross calorific value ²⁾ in relation to corrected volume Net calorific value ³⁾ in relation to corrected volume |
| Gas | Single gas | ISO 6976 | Contains GPA 2172 If the process pressure is fixed, or if the pressure is read in via the current input/HART | |
| | Gas mixture | ISO 6976 | Contains GPA 2172 If the process pressure is fixed, or if the pressure is read in via the current input/HART | |
| | Air | NEL40 | If the process pressure is fixed, or if the pressure is read in via the current input/HART | |
| | Natural gas | ISO 6976 | Contains GPA 2172 If the process pressure is fixed, or if the pressure is read in via the current input/HART | |
| AGA 5 | | | | |
| Liquids | Water | IAPWS-IF97/ASME | | |
| | Liquefied gas | ISO 6976 | Contains GPA 2172 | |
| | Other liquid | Linear equation | | |




- 1) The Prowirl 200 is able to calculate the volume flow, and other measured variables derived from the volume flow, across all steam types with full compensation using the pressure and temperature. For information on setting the device behavior, see the "Perform external compensation" section →  113
- 2) Gross calorific value: combustion energy + condensation energy of the flue gas (gross calorific value > net calorific value)
- 3) Net calorific value: only combustion energy

*Mass flow and energy flow calculation***NOTICE**

The process pressure (p) in the process pipe is required to calculate the process variables and the limit values of the measuring range.

- ▶ In the case of the HART device, the process pressure can be read in from an external transmitter (e.g. Cerabar-M) via the 4 to 20mA current input or via HART or entered as a fixed value in the **External compensation** submenu (→  113).

Steam is calculated based on the following factors:

- The measuring device calculates the density with full compensation using the pressure and temperature measured variables.
- Assuming superheated steam conditions the measuring device calculates until the saturation point is reached. The diagnostic behavior of the diagnostic message **△S871 Near steam saturation limit** is set to **Off** by default (ex works) →  144. This diagnostic behavior can optionally be redefined as an alarm or a warning →  143. Then the diagnostic message **△S871 Near steam saturation limit** is triggered at 2 K above saturation.
- The smaller of the following two pressure values is always used to calculate the density:
 - The measured pressure which is either entered as the Fixed process pressure (→  72) ≠ 0 bar abs. or read in via the current input/HART
 - The saturated steam pressure which is determined from the saturated steam line (IAPWS-IF97/ASME)
- If the fixed process pressure = 0 bar abs. the measuring device only calculates on the saturated steam curve using temperature compensation.

 For detailed information on performing external compensation: →  113

Calculated value

The unit calculates the mass flow, heat flow, energy flow, density and specific enthalpy from the measured volume flow and the measured temperature and/or the pressure based on international standard IAPWS-IF97/ASME.

Formulae for calculation:

- Mass flow: $m = q \cdot \rho (T, p)$
- Heat quantity: $E = q \cdot \rho (T, p) \cdot h_D (T, p)$

m = Mass flow

E = Heat quantity

q = Volume flow (measured)

h_D = Specific enthalpy

T = Process temperature (measured)

p = Process pressure

ρ = Density ²⁾

Pre-programmed gases

The following gases are pre-programmed in the flow computer:

| | | | |
|------------------------|---|-------------------------------|---------------------------------|
| Hydrogen ¹⁾ | Helium 4 | Neon | Argon |
| Krypton | Xenon | Nitrogen | Oxygen |
| Chlorine | Ammonia | Carbon monoxide ¹⁾ | Carbon dioxide |
| Sulfur dioxide | Hydrogen sulfide ¹⁾ | Hydrogen chloride | Methane ¹⁾ |
| Ethane ¹⁾ | Propane ¹⁾ | Butane ¹⁾ | Ethylene (ethene) ¹⁾ |
| Vinyl chloride | Mixtures of up to 8 components of these gases ¹⁾ | | |

1) The energy flow is calculated as per ISO 6976 (contains GPA 2172) or AGA5 - in relation to the net calorific value or gross calorific value .


2) From steam data as per IAPWS-IF97 (ASME), for the measured temperature and the specified pressure

Energy flow calculation

Volume flow \times operating density \times specific enthalpy

- Operating density for saturated steam and water: depends on the temperature
- Operating density for superheated steam, natural gas ISO 6976 (contains GPA 2172), natural gas AGA5: depends on the temperature and pressure

Heat flow difference

- Between saturated steam upstream from a heat exchanger and condensate downstream from the heat exchanger (second temperature read in via current input/HART) in accordance with IAPWS-IF97/ASME \rightarrow  24.
- Between warm and cold water (second temperature read in via current input/HART) in accordance with IAPWS-IF97/ASME.


Vapor pressure and steam temperature

The measuring device can perform the following in saturated steam measurements between the feed line and return line of any heating liquid (second temperature read in via current input/HART and C_p value entered):

- Calculate the saturation pressure of the steam from the measured temperature and output the value in accordance with IAPWS-IF97/ASME.
- Calculate the saturation temperature of the steam from the specified pressure and output the value in accordance with IAPWS-IF97/ASME.



Measuring range

The measuring range depends on the fluid and nominal diameter.

Flow velocity

A0027507

- E DN diameter
- v_E Velocity in process pipe
- v Bluff body approaching flow velocity (Re is based on this)
- v_2 Maximum velocity (applies only to oxygen) $v_2 = v_{max}$
- v_3 Velocity when leaving the measuring device
- D_i Internal diameter $D_i = D_3$
- D_3 Internal diameter $D_3 = D_i$
- d Width of bluff body
- f Vortex shedding frequency

 The Applicator can be used for calculation purposes. \rightarrow  161

| Maximum volume flow | Strouhal number | Reynolds number |
|--|--|---|
| $Q_{\max(G)} = v_{\max} \cdot \frac{\pi}{4} D_i^2$ <small>A0027504</small> | $Sr = \frac{f \cdot d}{v}$ <small>A0027505</small> | $Re = \frac{\rho \cdot v \cdot D_i}{\mu}$ <small>A0027506</small> |

Lower range value

Depends on the density of the medium and the Reynolds number ($Re_{\min} = 5\,000$, $Re_{\text{linear}} = 20\,000$). The Reynolds number is dimensionless and indicates the ratio of the inertia force of a fluid to its viscous force. It is used to characterize the flow. The Reynolds number is calculated as follows:

| | |
|---|---|
| $Re = \frac{4 \cdot Q \text{ [m}^3\text{/s]} \cdot \rho \text{ [kg/m}^3\text{]}}{\pi \cdot di \text{ [m]} \cdot \mu \text{ [Pa}\cdot\text{s]}}$ | $Re = \frac{4 \cdot Q \text{ [ft}^3\text{/s]} \cdot \rho \text{ [lb/ft}^3\text{]}}{\pi \cdot di \text{ [ft]} \cdot \mu \text{ [0.001 cP]}}$ |
|---|---|

A0003794

Re = Reynolds number; Q = flow; di = internal diameter; μ = dynamic viscosity, ρ = density

| |
|---|
| $DN\ 15\dots150 \rightarrow v_{\min.} = \frac{6}{\sqrt{\rho \text{ [kg/m}^3\text{]}}} \text{ [m/s]}$ |
| $DN\ 1/2\dots6" \rightarrow v_{\min.} = \frac{4.92}{\sqrt{\rho \text{ [lb/ft}^3\text{]}}} \text{ [ft/s]}$ |

A0020557

Upper range value



Liquids:

The upper range value must be calculated as follows:
 $v_{\max} = 9 \text{ m/s (30 ft/s)}$ and $v_{\max} = 350/\sqrt{\rho} \text{ m/s (130/\sqrt{\rho} ft/s)}$

► Use the lower value.

Gas/steam:

| Nominal diameter | v_{\max} |
|---|--|
| Standard device: DN 15 (1/2") | 46 m/s (151 ft/s) and $350/\sqrt{\rho} \text{ m/s (130/\sqrt{\rho} ft/s)}$ (Use the lower value.) |
| Standard device: DN 25 (1"), DN 40 (1 1/2") | 75 m/s (246 ft/s) and $350/\sqrt{\rho} \text{ m/s (130/\sqrt{\rho} ft/s)}$ (Use the lower value.) |
| Standard device: DN 50 to 150 (2 to 8") | 120 m/s (394 ft/s) and $350/\sqrt{\rho} \text{ m/s (130/\sqrt{\rho} ft/s)}$ (Use the lower value.) Calibrated range: up to 75 m/s (246 ft/s) |

 For information on the Applicator →  161

Operable flow range Up to 45: 1 (ratio between lower and upper range value)

Input signal

Current input

| | |
|---------------|-------------------|
| Current input | 4-20 mA (passive) |
| Resolution | 1 μA |

| | |
|---------------------------------|--|
| Voltage drop | Typically: 2.2 to 3 V for 3.6 to 22 mA |
| Maximum voltage | ≤35 V |
| Possible input variables | <ul style="list-style-type: none"> ■ Pressure ■ Temperature ■ Density |

External measured values

To increase the accuracy of certain measured variables or to calculate the corrected volume flow, the automation system can continuously write different measured values to the measuring device:

- Operating pressure to increase accuracy (Endress+Hauser recommends the use of a pressure measuring device for absolute pressure, e.g. Cerabar M or Cerabar S)
- Medium temperature to increase accuracy (e.g. iTEMP)
- Reference density for calculating the corrected volume flow



- Various pressure transmitters can be ordered from Endress+Hauser: see "Accessories" section → [161](#)

- Please comply with the special mounting instructions when using pressure transmitters → [24](#)

It is recommended to read in external measured values to calculate the following measured variables:

- Energy flow
- Mass flow
- Corrected volume flow

Current input

The measured values are written from the automation system to the measuring device via the current input → [168](#).

HART protocol

The measured values are written from the automation system to the measuring device via the HART protocol. The pressure transmitter must support the following protocol-specific functions:

- HART protocol
- Burst mode

16.4 Output

Output signal

Current output

| | |
|--------------------------------------|--|
| Current output 1 | 4-20 mA HART (passive) |
| Current output 2 | 4-20 mA (passive) |
| Resolution | < 1 µA |
| Damping | Adjustable: 0.0 to 999.9 s |
| Assignable measured variables | <ul style="list-style-type: none"> ■ Volume flow ■ Corrected volume flow ■ Mass flow ■ Flow velocity ■ Temperature ■ Calculated saturated steam pressure ■ Total mass flow ■ Energy flow ■ Heat flow difference |

Pulse/frequency/switch output

| | |
|--------------------------------------|--|
| Function | Can be set to pulse, frequency or switch output |
| Version | Passive, open collector |
| Maximum input values | <ul style="list-style-type: none"> ▪ DC 35 V ▪ 50 mA |
| Voltage drop | <ul style="list-style-type: none"> ▪ For ≤ 2 mA: 2 V ▪ For 10 mA: 8 V |
| Residual current | ≤ 0.05 mA |
| Pulse output | |
| Pulse width | Adjustable: 5 to 2 000 ms |
| Maximum pulse rate | 100 Impulse/s |
| Pulse value | Adjustable |
| Assignable measured variables | <ul style="list-style-type: none"> ▪ Total volume flow ▪ Total corrected volume flow ▪ Total mass flow ▪ Total energy flow ▪ Total heat flow difference |
| Frequency output | |
| Output frequency | Adjustable: 0 to 1 000 Hz |
| Damping | Adjustable: 0 to 999 s |
| Pulse/pause ratio | 1:1 |
| Assignable measured variables | <ul style="list-style-type: none"> ▪ Volume flow ▪ Corrected volume flow ▪ Mass flow ▪ Flow velocity ▪ Temperature ▪ Calculated saturated steam pressure ▪ Steam quality ▪ Total mass flow ▪ Energy flow ▪ Heat flow difference |
| Switch output | |
| Switching behavior | Binary, conductive or non-conductive |
| Switching delay | Adjustable: 0 to 100 s |
| Number of switching cycles | Unlimited |
| Assignable functions | <ul style="list-style-type: none"> ▪ Off ▪ On ▪ Diagnostic behavior ▪ Limit value <ul style="list-style-type: none"> - Volume flow - Corrected volume flow - Mass flow - Flow velocity - Temperature - Calculated saturated steam pressure - Steam quality - Total mass flow - Energy flow - Heat flow difference - Reynolds number - Totalizer 1-3 ▪ Status ▪ Status of low flow cut off |

Signal on alarm

Depending on the interface, failure information is displayed as follows:

Current output

HART

| | |
|--------------------|--|
| Device diagnostics | Device condition can be read out via HART Command 48 |
|--------------------|--|

Pulse/frequency/switch output

| Pulse output | |
|------------------|---|
| Failure mode | No pulses |
| Frequency output | |
| Failure mode | Choose from: <ul style="list-style-type: none"> ▪ Actual value ▪ 0 Hz ▪ Defined value: 0 to 1 250 Hz |
| Switch output | |
| Failure mode | Choose from: <ul style="list-style-type: none"> ▪ Current status ▪ Open ▪ Closed |

Local display

| | |
|--------------------|---|
| Plain text display | With information on cause and remedial measures |
| Backlight | Additionally for device version with SD03 local display: red lighting indicates a device error. |

 Status signal as per NAMUR recommendation NE 107

Operating tool

- Via digital communication:
 - HART protocol
- Via service interface

| | |
|--------------------|---|
| Plain text display | With information on cause and remedial measures |
|--------------------|---|

Load →  34

Low flow cut off The switch points for low flow cut off are user-selectable.

Galvanic isolation All outputs are galvanically isolated from one another.

Protocol-specific data

HART

- For information on the device description files
- For information on the dynamic variables and measured variables (HART device variables)

16.5 Power supply

Terminal assignment →  32

Supply voltage

Transmitter

An external power supply is required for each output.

The following supply voltage values apply for the outputs available:

Supply voltage for a compact version without a local display ¹⁾

| Order code for "Output" | Minimum terminal voltage ²⁾ | Maximum terminal voltage |
|--|--|--------------------------|
| Option A: 4-20 mA HART | ≥ DC 12 V | DC 35 V |
| Option B: 4-20 mA HART, pulse/frequency/switch output | ≥ DC 12 V | DC 35 V |
| Option C: 4-20 mA HART + 4-20 mA analog | ≥ DC 12 V | DC 30 V |
| Option D: 4-20 mA HART, pulse/frequency/switch output, 4-20 mA current input ³⁾ | ≥ DC 12 V | DC 35 V |

- 1) In event of external supply voltage of the power supply unit with load
- 2) The minimum terminal voltage increases if local operation is used: see the following table
- 3) Voltage drop 2.2 to 3 V for 3.59 to 22 mA




Increase in minimum terminal voltage

| Local operation | Increase in minimum terminal voltage |
|---|--------------------------------------|
| Order code for "Display; Operation", option C: Local operation SD02 | + DC 1 V |
| Order code for "Display; Operation", option E: Local operation SD03 with lighting (backlighting not used) | + DC 1 V |
| Order code for "Display; Operation", option E: Local operation SD03 with lighting (backlighting used) | + DC 3 V |

Power consumption

Transmitter

| Order code for "Output" | Maximum power consumption |
|--|---|
| Option A: 4-20 mA HART | 770 mW |
| Option B: 4-20 mA HART, pulse/frequency/switch output | <ul style="list-style-type: none"> ▪ Operation with output 1: 770 mW ▪ Operation with output 1 and 2: 2 770 mW |
| Option C: 4-20 mA HART + 4-20 mA analog | <ul style="list-style-type: none"> ▪ Operation with output 1: 660 mW ▪ Operation with output 1 and 2: 1 320 mW |
| Option D: 4-20 mA HART, pulse/frequency/switch output, 4-20 mA current input | <ul style="list-style-type: none"> ▪ Operation with output 1: 770 mW ▪ Operation with output 1 and 2: 2 770 mW ▪ Operation with output 1 and input: 840 mW ▪ Operation with output 1, 2 and input: 2 840 mW |

| | | | | | | | | | | | | | | | |
|---|---|----------------------------|--|-------------------------------|----------------------|-----------------------------|--------------|---------------------------|---------|-----------------------------|----------|---|-------|--------------------------|--------------------------------|
| Current consumption | <p>Current output</p> <p>For every 4-20 mA or 4-20 mA HART current output: 3.6 to 22.5 mA</p> <p> If the option Defined value is selected in the Failure mode parameter : 3.59 to 22.5 mA</p> <p>Current input</p> <p>3.59 to 22.5 mA</p> <p> Internal current limiting: max. 26 mA</p> | | | | | | | | | | | | | | |
| Power supply failure | <ul style="list-style-type: none"> ■ Totalizers stop at the last value measured. ■ Configuration is retained in the device memory (HistoROM). ■ Error messages (incl. total operated hours) are stored. | | | | | | | | | | | | | | |
| Electrical connection | →  35 | | | | | | | | | | | | | | |
| Terminals | <ul style="list-style-type: none"> ■ For device version without integrated overvoltage protection: plug-in spring terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG) ■ For device version with integrated overvoltage protection: screw terminals for wire cross-sections 0.2 to 2.5 mm² (24 to 14 AWG) | | | | | | | | | | | | | | |
| Cable entries | <ul style="list-style-type: none"> ■ Cable gland: M20 × 1.5 with cable ϕ6 to 12 mm (0.24 to 0.47 in) ■ Thread for cable entry: <ul style="list-style-type: none"> – NPT ½" – G ½" | | | | | | | | | | | | | | |
| Cable specification | →  30 | | | | | | | | | | | | | | |
| Overvoltage protection | <p>The device can be ordered with integrated overvoltage protection for diverse approvals: <i>Order code for "Accessory mounted", option NA "Overvoltage protection"</i></p> <table border="1" data-bbox="496 1429 1533 1758"> <tr> <td>Input voltage range</td> <td>Values correspond to supply voltage specifications ¹⁾</td> </tr> <tr> <td>Resistance per channel</td> <td>2 · 0.5 Ω max</td> </tr> <tr> <td>DC sparkover voltage</td> <td>400 to 700 V</td> </tr> <tr> <td>Trip surge voltage</td> <td>< 800 V</td> </tr> <tr> <td>Capacitance at 1 MHz</td> <td>< 1.5 pF</td> </tr> <tr> <td>Nominal discharge current (8/20 μs)</td> <td>10 kA</td> </tr> <tr> <td>Temperature range</td> <td>–40 to +85 °C (–40 to +185 °F)</td> </tr> </table> <p>1) The voltage is reduced by the amount of the internal resistance $I_{min} \cdot R_i$</p> <p> Depending on the temperature class, restrictions apply to the ambient temperature for device versions with overvoltage protection .</p> <p> For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.</p> | Input voltage range | Values correspond to supply voltage specifications ¹⁾ | Resistance per channel | 2 · 0.5 Ω max | DC sparkover voltage | 400 to 700 V | Trip surge voltage | < 800 V | Capacitance at 1 MHz | < 1.5 pF | Nominal discharge current (8/20 μs) | 10 kA | Temperature range | –40 to +85 °C (–40 to +185 °F) |
| Input voltage range | Values correspond to supply voltage specifications ¹⁾ | | | | | | | | | | | | | | |
| Resistance per channel | 2 · 0.5 Ω max | | | | | | | | | | | | | | |
| DC sparkover voltage | 400 to 700 V | | | | | | | | | | | | | | |
| Trip surge voltage | < 800 V | | | | | | | | | | | | | | |
| Capacitance at 1 MHz | < 1.5 pF | | | | | | | | | | | | | | |
| Nominal discharge current (8/20 μs) | 10 kA | | | | | | | | | | | | | | |
| Temperature range | –40 to +85 °C (–40 to +185 °F) | | | | | | | | | | | | | | |

16.6 Performance characteristics

Reference operating conditions

- Error limits following ISO/DIN 11631
- +20 to +30 °C (+68 to +86 °F)
- 2 to 4 bar (29 to 58 psi)
- Calibration system traceable to national standards
- Calibration with the process connection corresponding to the particular standard

 To obtain measured errors, use the *Applicator* sizing tool →  161 →  188


Maximum measured error

Base accuracy

o.r. = of reading, Re = Reynolds number

Volume flow

The measured error for the volume flow is as follows depending on the Reynolds number and the compressibility of the medium under measurement:



A0019703

| Deviation of volume flow value (absolute) from the reading | | | |
|--|--------------------------|----------------|----------------------------|
| Medium type | | Incompressible | Compressible ¹⁾ |
| Re range | Measured value deviation | Standard | Standard |
| R1 to R2 | A2 | < 10 % | < 10 % |
| R2 to Re _{max} | A1 | < 0.75 % | < 1.0 % |

1) Accuracy specifications valid up to 75 m/s (246 ft/s)

| Reynolds numbers | Incompressible | Compressible |
|------------------|----------------|--------------|
| | Standard | Standard |
| R1 | 5000 | |
| R2 | 20000 | |

Temperature

- Saturated steam and liquids at room temperature if $T > 100\text{ °C}$ (212 °F) applies: $< 1\text{ °C}$ (1.8 °F)
- Gas: $< 1\%$ o.r. [K]
- Volume flow: $> 70\text{ m/s}$ (230 ft/s): 2% o.r.

Rise time 50 % (stirred under water, following IEC 60751): 8 s

Mass flow (saturated steam)

- Flow velocities 20 to 50 m/s (66 to 164 ft/s), $T > 150\text{ °C}$ (302 °F) or (423 K)
 - Re $> 20\,000$: $< 1.7\%$ o.r.
 - Re between 5 000 to 20 000: $< 10\%$ o.r.
- Flow velocities 10 to 70 m/s (33 to 210 ft/s), $T > 140\text{ °C}$ (284 °F) or (413 K)
 - Re $> 20\,000$: $< 2\%$ o.r.
 - Re between 5 000 to 20 000: $< 10\%$ o.r.
- Flow velocities $< 10\text{ m/s}$ (33 ft/s): Re > 5000 : 5%



The use of a Cerabar S is required for the measured errors listed in the following section. The measured error used to calculate the error in the measured pressure is 0.15%.

Mass flow of superheated steam and gas (single gas, gas mixture, air: NEL40; natural gas: ISO 12213-2 contains AGA8-DC92, AGA NX-19, ISO 12213-3 contains SGERG-88 and AGA8 Gross Method 1)

- Re $> 20\,000$ and process pressure $< 40\text{ bar abs.}$ (580 psi abs.): 1.7 % o.r.
- Re between 5 000 to 20 000 and process pressure $< 40\text{ bar abs.}$ (580 psi abs.): 10 % o.r.
- Re $> 20\,000$ and process pressure $< 120\text{ bar abs.}$ (1 740 psi abs.): 2.6 % o.r.
- Re between 5 000 to 20 000 and process pressure $< 120\text{ bar abs.}$ (1 740 psi abs.): 10 % o.r.

abs. = absolute

Mass flow (water)

- Re 20 000: $< 0.85\%$ o.r.
- Re between 5 000 to 20 000: $< 10\%$ o.r.

Mass flow (user-defined liquids)

To specify the system accuracy, Endress+Hauser requires information about the type of liquid and its operating temperature or information in table form about the dependency between the liquid density and the temperature.

Example

- Acetone is to be measured at fluid temperatures from $+70$ to $+90\text{ °C}$ ($+158$ to $+194\text{ °F}$).
- For this purpose, the **Reference temperature** parameter (7703) (here 80 °C (176 °F)), **Reference density** parameter (7700) (here 720.00 kg/m^3) and **Linear expansion coefficient** parameter (7621) (here $18.0298 \times 10^{-4}\text{ 1/°C}$) must be entered in the transmitter.
- The overall system uncertainty, which is less than 0.9 % for the example above, is comprised of the following measurement uncertainties: uncertainty of volume flow measurement, uncertainty of temperature measurement, uncertainty of the density-temperature correlation used (incl. the resulting uncertainty of density).

Mass flow (other media)

Depends on the selected fluid and the pressure value, which is specified in the parameters. Individual error analysis must be performed.

Diameter mismatch correction

Prowirl 200 can correct shifts in the calibration factor which are caused, for example, by diameter mismatch between the device flange (e.g. ASME B16.5/Sch. 80, DN 50 (2")) and the mating pipe (e.g. ASME B16.5/Sch. 40, DN 50 (2")). Only apply diameter mismatch correction within the following limit values (listed below) for which test measurements have also been performed.

Disc (wafer flange):

- DN 15 (½"): ±15 % of the internal diameter
- DN 25 (1"): ±12 % of the internal diameter
- DN 40 (1½"): ±9 % of the internal diameter
- DN ≥ 50 (2"): ±8 % of the internal diameter

If the standard internal diameter of the ordered process connection differs from the internal diameter of the mating pipe, an additional measuring uncertainty of approx. 2 % o.r. must be expected.

Example

Influence of the diameter mismatch without using the correction function:

- Mating pipe DN 100 (4"), schedule 80
- Device flange DN 100 (4"), schedule 40
- This installation position results in a diameter mismatch of 5 mm (0.2 in). If the correction function is not used, an additional measuring uncertainty of approx. 2 % o.r. must be expected.

Accuracy of outputs

The outputs have the following base accuracy specifications.

Current output

| | |
|----------|--------|
| Accuracy | ±10 µA |
|----------|--------|

Pulse/frequency output

o.r. = of reading

| | |
|----------|--------------------|
| Accuracy | Max. ±100 ppm o.r. |
|----------|--------------------|

Repeatability o.r. = of reading
±0.2 % o.r.

Response time If all the configurable functions for filter times (flow damping, display damping, current output time constant, frequency output time constant, status output time constant) are set to 0, in the event of vortex frequencies of 10 Hz and higher a response time of max(T_v , 100 ms) can be expected.

In the event of measuring frequencies < 10 Hz, the response time is > 100 ms and can be up to 10 s. T_v is the average vortex period duration of the flowing fluid.

Influence of ambient temperature

Current output

o.r. = of reading

Additional error, based on span of 16 mA:


| | |
|--|-------------|
| Temperature coefficient at zero point (4 mA) | 0.02 %/10 K |
| Temperature coefficient with span (20 mA) | 0.05 %/10 K |

Pulse/frequency output

o.r. = of reading

| | |
|--------------------------------|-------------------------|
| Temperature coefficient | Max. ± 100 ppm o.r. |
|--------------------------------|-------------------------|

16.7 Installation

"Mounting requirements" →  19

16.8 Environment

Ambient temperature range

Temperature tables



Observe the interdependencies between the permitted ambient and fluid temperatures when operating the device in hazardous areas.



For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.

Storage temperature

All components apart from the display modules:
-50 to +80 °C (-58 to +176 °F)

Remote display and operating module DKX001

-50 to +80 °C (-58 to +176 °F)

Climate class

DIN EN 60068-2-38 (test Z/AD)

Degree of protection

Transmitter

- As standard: IP66/67, type 4X enclosure
- When housing is open: IP20, type 1 enclosure
- Display module: IP20, type 1 enclosure

Sensor

IP66/67, type 4X enclosure

Vibration resistance

- For compact/remote version made of coated aluminum and remote version made of stainless steel:
Acceleration up to 2 g (if gain set to factory setting), 10 to 500 Hz, following IEC 60068-2-6
- For the compact version made of stainless steel:
Acceleration up to 1 g (if gain set to factory setting), 10 to 500 Hz, following IEC 60068-2-6

Electromagnetic compatibility (EMC)

As per IEC/EN 61326 and NAMUR Recommendation 21 (NE 21)



For details, refer to the Declaration of Conformity.

16.9 Process

Medium temperature range **DSC sensor**³⁾

Order code for "Sensor version":

- Option 1 "Volume flow, basis":
-40 to +260 °C (-40 to +500 °F), stainless steel
- Option 2 "Volume flow, high-temperature/low-temperature":
-200 to +400 °C (-328 to +752 °F), stainless steel
- Option 3 "Mass flow (integrated temperature measurement)":
-200 to +400 °C (-328 to +752 °F), stainless steel

Order code for "Sensor option":

Option CD "Harsh environment"⁴⁾, DSC sensor components Alloy C22":
-200 to +400 °C (-328 to +752 °F), DSC sensor Alloy C22

Seals

- -200 to +400 °C (-328 to +752 °F) for graphite (standard)
- -15 to +175 °C (+5 to +347 °F) for Viton
- -20 to +275 °C (-4 to +527 °F) for Kalrez
- -200 to +260 °C (-328 to +500 °F) for Gylon

Pressure-temperature ratings



An overview of the pressure-temperature ratings for the process connections is provided in the "Technical Information" document

Secondary containment pressure rating

The following overpressure resistance values apply to the sensor shaft in the event of a membrane rupture:

| Sensor version | Overpressure, sensor shaft in [bar a] |
|--|---------------------------------------|
| Volume flow, basis | 200 |
| Volume flow, high-temperature/low-temperature | 200 |
| Mass flow (integrated temperature measurement) | 200 |

Pressure loss

For a precise calculation, use the Applicator → 161.

16.10 Mechanical construction

Design, dimensions



For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

Weight

Compact version

Weight data:

- Including the transmitter:
 - Order code for "Housing", option C: 1.8 kg (4.0 lb)
 - Order code for "Housing", option B: 4.5 kg (9.9 lb)
- Excluding packaging material

3) Capacitance sensor

4) Aggressive atmosphere (salts or chloride in the air)

Weight in SI units

| DN [mm] | Weight [kg] | |
|------------|--|--|
| | Order code for "Housing", option C Aluminum, AlSi10Mg, coated ¹⁾ | Order code for "Housing", option B Stainless steel, 1.4404 (316L) ¹⁾ |
| 15 | 3.1 | 5.8 |
| 25 | 3.3 | 6.0 |
| 40 | 3.9 | 6.6 |
| 50 | 4.2 | 6.9 |
| 80 | 5.6 | 8.3 |
| 100 | 6.6 | 9.3 |
| 150 | 9.1 | 11.8 |

1) For high-temperature/low-temperature version: values + 0.2 kg

Weight in US units

| DN [in] | Weight [lbs] | |
|------------|--|--|
| | Order code for "Housing", option C Aluminum, AlSi10Mg, coated ¹⁾ | Order code for "Housing", option B Stainless steel, 1.4404 (316L) ¹⁾ |
| ½ | 6.9 | 12.9 |
| 1 | 7.4 | 13.3 |
| 1½ | 8.7 | 14.6 |
| 2 | 9.4 | 15.3 |
| 3 | 12.4 | 18.4 |
| 4 | 14.6 | 20.6 |
| 6 | 20.2 | 26.1 |

1) For high-temperature/low-temperature version: values +0.4 lbs

Transmitter remote version*Wall-mount housing*

Depends on the material of the wall-mount housing:

- Aluminum, AlSi10Mg, coated: 2.4 kg (5.2 lb)
- Stainless steel, 1.4404 (316L): 6.0 kg (13.2 lb)

Sensor remote version

Weight data:

- Including the connection housing:
 - Aluminum, AlSi10Mg, coated: 0.8 kg (1.8 lb)
 - Stainless cast steel, 1.4408 (CF3M): 2.0 kg (4.4 lb)
- Excluding the connecting cable
- Excluding packaging material

Weight in SI units

| DN [mm] | Weight [kg] | |
|------------|--|---|
| | Connection housing Aluminum, AlSi10Mg, coated ¹⁾ | Connection housing Stainless cast steel, 1.4408 (CF3M) ¹⁾ |
| 15 | 2.1 | 3.3 |
| 25 | 2.3 | 3.5 |
| 40 | 2.9 | 4.1 |
| 50 | 3.2 | 4.4 |
| 80 | 4.6 | 5.8 |
| 100 | 5.6 | 6.8 |
| 150 | 8.1 | 9.3 |

1) For high-temperature/low-temperature version: values + 0.2 kg

Weight in US units

| DN [in] | Weight [lbs] | |
|------------|--|---|
| | Connection housing Aluminum, AlSi10Mg, coated ¹⁾ | Connection housing Stainless cast steel, 1.4408 (CF3M) ¹⁾ |
| ½ | 4.5 | 7.3 |
| 1 | 5.0 | 7.8 |
| 1½ | 6.3 | 9.1 |
| 2 | 7.0 | 9.7 |
| 3 | 10.0 | 12.8 |
| 4 | 12.3 | 15.0 |
| 6 | 17.3 | 20.5 |

1) For high-temperature/low-temperature version: values +0.4 lbs

Accessories

Flow conditioner

Weight in SI units

| DN ¹⁾ [mm] | Pressure rating | Weight [kg] |
|--------------------------|----------------------|----------------|
| 15 | PN 10 to 40 | 0.04 |
| 25 | PN 10 to 40 | 0.1 |
| 40 | PN 10 to 40 | 0.3 |
| 50 | PN 10 to 40 | 0.5 |
| 80 | PN 10 to 40 | 1.4 |
| 100 | PN 10 to 40 | 2.4 |
| 150 | PN 10/16 PN 25/40 | 6.3 7.8 |

1) EN (DIN)

| DN ¹⁾ [mm] | Pressure rating | Weight [kg] |
|--------------------------|------------------------|----------------|
| 15 | Class 150 Class 300 | 0.03 0.04 |
| 25 | Class 150 Class 300 | 0.1 |
| 40 | Class 150 Class 300 | 0.3 |
| 50 | Class 150 Class 300 | 0.5 |
| 80 | Class 150 Class 300 | 1.2 1.4 |
| 100 | Class 150 Class 300 | 2.7 |
| 150 | Class 150 Class 300 | 6.3 7.8 |

1) ASME

| DN ¹⁾ [mm] | Pressure rating | Weight [kg] |
|--------------------------|-----------------|----------------|
| 15 | 20K | 0.06 |
| 25 | 20K | 0.1 |
| 40 | 20K | 0.3 |
| 50 | 10K 20K | 0.5 |
| 80 | 10K 20K | 1.1 |
| 100 | 10K 20K | 1.80 |
| 150 | 10K 20K | 4.5 5.5 |

1) JIS

Weight in US units

| DN ¹⁾ [in] | Pressure rating | Weight [lbs] |
|--------------------------|------------------------|-----------------|
| ½ | Class 150 Class 300 | 0.07 0.09 |
| 1 | Class 150 Class 300 | 0.3 |
| 1½ | Class 150 Class 300 | 0.7 |
| 2 | Class 150 Class 300 | 1.1 |
| 3 | Class 150 Class 300 | 2.6 3.1 |

| DN ¹⁾ [in] | Pressure rating | Weight [lbs] |
|--------------------------|------------------------|-----------------|
| 4 | Class 150 Class 300 | 6.0 |
| 6 | Class 150 Class 300 | 14.0 16.0 |

1) ASME

Materials

Transmitter housing


Compact version

- Order code for "Housing", option **B** "Compact, stainless":
Stainless steel CF-3M (316L, 1.4404)
- Order code for "Housing", option **C** "Compact, aluminum coated":
Aluminum, AlSi10Mg, coated
- Window material: glass

Remote version

- Order code for "Housing", option **J** "Remote, aluminum coated":
Aluminum, AlSi10Mg, coated
- Order code for "Housing", option **K** "Remote, stainless":
For maximum corrosion resistance: stainless steel 1.4404 (316L)
- Window material: glass

Cable entries/cable glands



39 Possible cable entries/cable glands

- 1 Cable entry in transmitter housing, wall-mount housing or connection housing with internal thread M20 x 1.5
- 2 Cable gland M20 x 1.5
- 3 Adapter for cable entry with internal thread G ½" or NPT ½"

Order code for "Housing", option **B** "Compact, stainless", option **K** "Remote, stainless"

| Cable entry/cable gland | Type of protection | Material |
|---|--|--------------------------------|
| Cable gland M20 x 1.5 | <ul style="list-style-type: none"> ■ Non-Ex ■ Ex ia ■ Ex ic ■ Ex nA ■ Ex tb | Stainless steel ,1.4404 |
| Adapter for cable entry with internal thread G ½" | For non-Ex and Ex (except for CSA Ex d/XP) | Stainless steel, 1.4404 (316L) |
| Adapter for cable entry with internal thread NPT ½" | For non-Ex and Ex | |

Order code for "Housing": option C "Compact, aluminum coated", option J "Remote, aluminum coated"

| Cable entry/cable gland | Type of protection | Material |
|---|--|---------------------|
| Cable gland M20 × 1.5 | <ul style="list-style-type: none"> ■ Non-Ex ■ Ex ia ■ Ex ic | Plastic |
| | Adapter for cable entry with internal thread G ½" | Nickel-plated brass |
| Adapter for cable entry with internal thread NPT ½" | For non-Ex and Ex (except for CSA Ex d/XP) | Nickel-plated brass |
| Thread NPT ½" via adapter | For non-Ex and Ex | |

Connecting cable for remote version

- Standard cable: PVC cable with copper shield
- Reinforced cable: PVC cable with copper shield and additional steel wire braided jacket

Sensor connection housing

- Coated aluminum AlSi10Mg
- Stainless cast steel, 1.4408 (CF3M), in compliance with NACE MR0175-2003 and MR0103-2003

Measuring tubes

Pressure ratings up to PN 40, Class 150/300, and JIS 10K/20K:

Stainless cast steel, 1.4408 (CF3M), in compliance with AD2000 (for AD2000 the temperature range is limited to -10 to +400 °C (+14 to +752 °F)) and in compliance with NACE MR0175-2003 and MR0103-2003

DSC sensor

Pressure ratings up to PN 40, Class 150/300, and JIS 10K/20K:

Parts in contact with medium (marked as "wet" on the DSC sensor flange):
Stainless steel, 1.4435 (316, 316L), in compliance with NACE MR0175-2003 and MR0103-2003

Parts not in contact with medium:

- Stainless steel 1.4301 (304)
- Order code for "Sensor option", option CD "Harsh environment⁵⁾, DSC sensor sensor components Alloy C22":
Alloy C22 sensor: UNS N06022 similar to Alloy C22/2.4602, in compliance with NACE MR0175-2003 and MR0103-2003

Seals

- Graphite (standard)
Sigraflex Hochdruck™ with smooth sheet metal insert made of stainless steel, 316/316L (BAM-certified for oxygen applications, "high quality in terms of TA Luft" (German Clean Air Act))
- FPM (Viton)
- Kalrez 6375
- Gylon 3504 (BAM-certified for oxygen applications, "high quality in terms of TA Luft" (German Clean Air Act))

5) Aggressive atmosphere (salts or chloride in the air)

Housing support

Stainless steel, 1.4408 (CF3M)

Accessories

Weather protection cover

Stainless steel 1.4404 (316L)



Flow conditioner

Stainless steel, multiple certifications, 1.4404 (316, 316L), in compliance with NACE MR0175-2003 and MR0103-2003

16.11 Operability

Local operation







Via display module

| Order code for "Display; Operation", option C "SD02" | Order code for "Display; Operation", option E "SD03" |
|---|---|
|  <p style="text-align: right; font-size: small;">A0015544</p> |  <p style="text-align: right; font-size: small;">A0015546</p> |
| <p>1 <i>Operation with pushbuttons</i></p> | <p>1 <i>Operation with touch control</i></p> |

Display elements

- 4-line display
- With order code for "Display; operation", option **E**:
White background lighting; switches to red in event of device errors
- Format for displaying measured variables and status variables can be individually configured
- Permitted ambient temperature for the display: -20 to +60 °C (-4 to +140 °F)
The readability of the display may be impaired at temperatures outside the temperature range.


Operating elements

- With order code for "Display; operation", option **C**:
Local operation with 3 push buttons: , , 
- With order code for "Display; operation", option **E**:
External operation via touch control; 3 optical keys: , , 
- Operating elements also accessible in various hazardous areas

Additional functionality

- Data backup function
The device configuration can be saved in the display module.
- Data comparison function
The device configuration saved in the display module can be compared to the current device configuration.
- Data transfer function
The transmitter configuration can be transmitted to another device using the display module.

Via remote display and operating module FHX50



A0013137


40 Operating options via FHX50

- 1 Housing of remote display and operating module FHX50
- 2 SD02 display and operating module, push buttons: cover must be opened for operation
- 3 SD03 display and operating module, optical buttons: operation possible through cover glass

Remote operation

Via HART protocol

This communication interface is available in device versions with a HART output.




A0013764

41 Options for remote operation via HART protocol

- 1 Control system (e.g. PLC)
- 2 Transmitter power supply unit, e.g. RN221N (with communication resistor)
- 3 Connection for Commubox FXA195 and Field Communicator 475
- 4 Field Communicator 475
- 5 Computer with operating tool (e.g. FieldCare, AMS Device Manager, SIMATIC PDM)
- 6 Commubox FXA195 (USB)
- 7 Field Xpert SFX350 or SFX370
- 8 VIATOR Bluetooth modem with connecting cable
- 9 Transmitter

Service interface

Via service interface (CDI)



- 1 Service interface (CDI = Endress+Hauser Common Data Interface) of the measuring device
 2 Commubox FXA291
 3 Computer with "FieldCare" operating tool with COM DTM "CDI Communication FXA291"

Languages

Can be operated in the following languages:

- Via local display:
 English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Swedish, Turkish, Chinese, Japanese, Korean, Bahasa (Indonesian), Vietnamese, Czech
- Via "FieldCare" operating tool:
 English, German, French, Spanish, Italian, Chinese, Japanese

16.12 Certificates and approvals

CE mark

The measuring system is in conformity with the statutory requirements of the applicable EC Directives. These are listed in the corresponding EC Declaration of Conformity along with the standards applied.

Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

C-Tick symbol

The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".



Ex approval

The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.

Functional safety

The measuring device can be used for flow monitoring systems (min., max., range) up to SIL 2 (single-channel architecture) and SIL 3 (multichannel architecture with homogeneous redundancy) and is independently evaluated and certified by the TÜV in accordance with IEC 61508.

The following types of monitoring in safety equipment are possible:
 Volume flow

 Functional Safety Manual with information on the SIL device →  188

| | |
|--------------------------------|--|
| Pressure Equipment Directive | <ul style="list-style-type: none"> ■ With the PED/G1/x (x = category) marking on the sensor nameplate, Endress+Hauser confirms compliance with the "Essential Safety Requirements" specified in Annex I of the Pressure Equipment Directive 97/23/EC. ■ Devices not bearing this marking (PED) are designed and manufactured according to good engineering practice. They meet the requirements of Art.3 Section 3 of the Pressure Equipment Directive 97/23/EC. The range of application is indicated in tables 6 to 9 in Annex II of the Pressure Equipment Directive. |
| Experience | The Prowirl 200 measuring system is the official successor to Prowirl 72 and Prowirl 73. |
| Other standards and guidelines | <ul style="list-style-type: none"> ■ EN 60529 Degrees of protection provided by enclosures (IP code) ■ DIN ISO 13359 Measurement of conductive liquid flow in closed conduits - Flanged-type electromagnetic flowmeters - Overall length ■ EN 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use - general requirements ■ IEC/EN 61326 Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements). ■ NAMUR NE 21 Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment ■ NAMUR NE 32 Data retention in the event of a power failure in field and control instruments with microprocessors ■ NAMUR NE 43 Standardization of the signal level for the breakdown information of digital transmitters with analog output signal. ■ NAMUR NE 53 Software of field devices and signal-processing devices with digital electronics ■ NAMUR NE 105 Specifications for integrating fieldbus devices in engineering tools for field devices ■ NAMUR NE 107 Self-monitoring and diagnosis of field devices ■ NAMUR NE 131 Requirements for field devices for standard applications ■ ASME BPVC Section VIII, Division 1 Rules for Construction of Pressure Vessels |

16.13 Application packages

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.



The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.




Detailed information on the application packages:

- Special Documentation for the device → 189
- Special Documentation for the device

16.14 Accessories

 Overview of accessories available for order →  159

16.15 Supplementary documentation

 For an overview of the scope of the associated Technical Documentation, refer to the following:

- The *W@M Device Viewer* : Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

Standard documentation

Brief Operating Instructions

| Measuring device | Documentation code |
|------------------|--------------------|
| Prowirl D 200 | KA01135D |

Technical Information

| Measuring device | Documentation code |
|------------------|--------------------|
| Prowirl D 200 | TI01083D |

Description of device parameters

| Measuring device | Documentation code |
|------------------|--------------------|
| Prowirl 200 | GP01019D |

Supplementary device-dependent documentation



Safety Instructions

| Contents | Documentation code |
|-------------------------|--------------------|
| ATEX/IECEX Ex d, Ex tb | XA01148D |
| ATEX/IECEX Ex ia, Ex tb | XA01151D |
| ATEX/IECEX Ex ic, Ex nA | XA01152D |
| cCSA _{US} XP | XA01153D |
| cCSA _{US} IS | XA01154D |
| NEPSI Ex d | XA01238D |
| NEPSI Ex i | XA01239D |
| NEPSI Ex ic, Ex nA | XA01240D |
| INMETRO Ex d | XA01250D |
| INMETRO Ex i | XA01042D |
| INMETRO Ex nA | XA01043D |

Special Documentation

| Contents | Documentation code |
|--|--------------------|
| Information on the Pressure Equipment Directive | SD01163D |
| Functional Safety Manual | SD01162D |
| Heartbeat Technology | SD01204D |
| Natural gas | SD01194D |
| Air + Industrial Gases (Single Gas + Gas Mixtures) | SD01195D |

Installation Instructions

| Contents | Documentation code |
|---|---|
| Installation Instructions for spare part sets |  Overview of accessories available for order →  159 |

Index

A

- Access authorization to parameters
 - Read access 58
 - Write access 58
- Access code 58
 - Incorrect input 58
- Adapting the diagnostic behavior 143
- Adapting the status signal 143
- Ambient temperature
 - Influence 176
- Ambient temperature range 23
- AMS Device Manager 62
 - Function 62
- Application 9, 163
- Applicator 167
- Approvals 186

B

- Burst mode 65

C

- C-Tick symbol 186
- Cable entries
 - Technical data 173
- Cable entry
 - Degree of protection 43
- CE mark 10, 186
- Certificates 186
- Check
 - Installation 28
- Checklist
 - Post-connection check 44
 - Post-installation check 28
- Cleaning
 - Exterior cleaning 155
 - Interior cleaning 155
 - Replacing housing seals 155
 - Replacing seals 155
 - Replacing sensor seals 155
- Climate class 177
- Commissioning 68
 - Advanced settings 95
 - Configuring the measuring device 69
- Communication-specific data 63
- Connecting cable 30
- Connecting the measuring device 35
- Connection
 - see Electrical connection
- Connection preparations 35
- Connection tools 30
- Context menu
 - Closing 53
 - Explanation 53
 - Opening 53
- Current consumption 173

D

- Declaration of Conformity 10
- Define access code 125
- Degree of protection 43, 177
- Designated use 9
- Device components 11
- Device description files 63
- Device documentation
 - Supplementary documentation 8
- Device locking, status 128
- Device name
 - Sensor 14
 - Transmitter 13
- Device repair 156
- Device revision 63
- Device type ID 63
- Diagnostic behavior
 - Explanation 140
 - Symbols 140
- Diagnostic information
 - Design, description 140, 142
 - FieldCare 141
 - Local display 139
 - Overview 144
 - Remedy information 144
- Diagnostic list 148
- Diagnostic message 139
- Diagnostics
 - Symbols 139
- DIP switches
 - see Write protection switch
- Direct access 55
- Direct access code 50
- Disabling write protection 124
- Display
 - see Local display
- Display area
 - For operational display 48
 - In the navigation view 50
- Display values
 - For locking status 128
- Disposal 157
- Document
 - Function 6
 - Symbols used 6
- Document function 6

E

- Electrical connection
 - Commubox FXA195 (USB) 185
 - Commubox FXA291 60, 186
 - Degree of protection 43
 - Field Communicator 475 185
 - Field Xpert SFX350/SFX370 185
 - Measuring device 30

Operating tool (e.g. FieldCare, AMS Device Manager, SIMATIC PDM) 185

Operating tools

- Via HART protocol 185
- Via service interface (CDI) 60, 186

Transmitter power supply unit 185

VIATOR Bluetooth modem 185

Electromagnetic compatibility 177

Enabling write protection 124

Endress+Hauser services

- Maintenance 155
- Repair 157

Environment

- Ambient temperature range 23
- Storage temperature 177
- Vibration resistance 177

Error messages

- see Diagnostic messages

Event history 149

Events list 149

Ex approval 186

Experience 187

Extended order code

- Sensor 14
- Transmitter 13

Exterior cleaning 155

F

Field Communicator

- Function 62

Field Communicator 475 62

Field of application

- Residual risks 10

Field Xpert

- Function 60

Field Xpert SFX350 60

FieldCare 60

- Device description file 63
- Establishing a connection 61
- Function 60
- User interface 61

Filtering the event logbook 149

Firmware

- Release date 63
- Version 63

Firmware history 154

Flow direction 19

Function check 68

Function scope

- AMS Device Manager 62
- Field Communicator 62
- Field Communicator 475 62
- Field Xpert 60
- SIMATIC PDM 62

Functional safety (SIL) 186

Functions

- see Parameter

G

Galvanic isolation 171

H

Hardware write protection 125

HART protocol

- Device variables 63
- Measured variables 63

Help text

- Calling up 56
- Close 56
- Explanation 56

HistoROM 120

I

I/O electronics module 11, 39

Identifying the measuring device 12

Incoming acceptance 12

Influence

- Ambient temperature 176

Information on the document 6

Inlet runs 20

Input 163

Input mask 51

Inspection

- Received goods 12

Inspection check

- Connection 44

Installation 19

Installation conditions

- Inlet and outlet runs 20
- Mounting kit 25
- Mounting location 19
- Orientation 19
- Thermal insulation 23
- Vibrations 24

Installation dimensions 22

Interior cleaning 155

K

Keypad lock

- Disabling 58
- Enabling 58

L

Languages, operation options 186

Line recorder 134

Load 34

Local display 184

- Editing view 51
- Navigation view 49
- see Diagnostic message
- see In alarm condition
- see Operational display

Low flow cut off 171

M

Main electronics module 11

Maintenance tasks 155

Managing the device configuration 120
 Manufacturer ID 63
 Manufacturing date 13, 14
 Materials 182
 Maximum measured error 174
 Measured variables
 Calculated 163
 Measured 163
 see Process variables
 Measuring and test equipment 155
 Measuring device
 Configuration 69
 Conversion 156
 Disposal 158
 Mounting the sensor 25
 Preparing for electrical connection 35
 Preparing for mounting 25
 Removing 157
 Repair 156
 Structure 11
 Switch-on 68
 Measuring principle 163
 Measuring range 167
 Measuring system 163
 Media 9
 Medium temperature range 178
 Menu
 Diagnostics 147
 Operation 128
 Setup 69
 Menus
 For measuring device configuration 69
 For specific settings 95
 Mounting dimensions
 see Installation dimensions
 Mounting kit 25
 Mounting location 19
 Mounting preparations 25
 Mounting requirements
 Installation dimensions 22
 Mounting tools 25

N
 Nameplate
 Sensor 14
 Transmitter 13
 Navigation path (navigation view) 49
 Navigation view
 In the submenu 49
 In the wizard 49
 Nominal pressure
 Secondary containment 178
 Numeric editor 51

O

Operable flow range 168
 Operating elements 53, 140
 Operating keys
 see Operating elements

Operating menu
 Menu, submenus 46
 Structure 46
 Submenus and user roles 47
 Operating options 45
 Operating philosophy 47
 Operation 128
 Operation options 45
 Operational display 48
 Operational safety 10
 Order code 12, 13, 14
 Orientation (vertical, horizontal) 19
 Outlet runs 20
 Output 169
 Output signal 169

P

Packaging disposal 18
 Parameter
 Changing 57
 Enter a value 57
 Parameter settings
 Administration (Submenu) 150
 Burst configuration 1 to 3 (Submenu) 65
 Configuration backup display (Submenu) 120
 Current input (Wizard) 73
 Current output 1 to 2 (Wizard) 76
 Data logging (Submenu) 134
 Device information (Submenu) 151
 Diagnostics (Menu) 147
 Display (Submenu) 118
 Display (Wizard) 90
 External compensation (Submenu) 113
 Gas composition (Submenu) 102
 Input values (Submenu) 131
 Low flow cut off (Wizard) 93
 Medium properties (Submenu) 99
 Medium selection (Wizard) 71
 Output conditioning (Wizard) 92
 Output values (Submenu) 132
 Process variables (Submenu) 128
 Pulse/frequency/switch output (Wizard) 79, 82, 86
 Sensor adjustment (Submenu) 115
 Setup (Menu) 69
 Simulation (Submenu) 122
 System units (Submenu) 96
 Totalizer (Submenu) 131
 Totalizer 1 to 3 (Submenu) 116
 Totalizer handling (Submenu) 133
 Performance characteristics 174
 Post-connection check (checklist) 44
 Post-installation check 68
 Post-installation check (checklist) 28
 Potential equalization 41
 Power consumption 172
 Power supply failure 173
 Pressure Equipment Directive 187
 Pressure loss 178
 Pressure-temperature ratings 178

- Process
 - Pressure loss 178
- Process conditions
 - Medium temperature 178
- Product safety 10
- Protecting parameter settings 124
- R**
- Read access 58
- Reading measured values 128
- Recalibration 155
- Reference operating conditions 174
- Registered trademarks 8
- Remedial measures
 - Calling up 141
 - Closing 141
- Remote operation 185
- Remote version
 - Connecting the connecting cable 35
- Repair 156
 - Notes 156
- Repair of a device 156
- Repeatability 176
- Replacement
 - Device components 156
- Replacing seals 155
- Requirements for personnel 9
- Response time 176
- Return 157
- S**
- Safety 9
- Sensor
 - Mounting 25
- Serial number 13, 14
- Setting the operating language 68
- Settings
 - Adapting the measuring device to the process conditions 133
 - Advanced display configurations 118
 - Current input 73
 - Current output 76
 - Device reset 150
 - Device tag 69
 - External compensation 113
 - Gas composition 102
 - Local display 90
 - Low flow cut off 93
 - Managing the device configuration 120
 - Medium 71
 - Medium properties 99
 - Operating language 68
 - Output conditioning 92
 - Pulse output 79
 - Pulse/frequency/switch output 79, 82
 - Resetting the totalizer 133
 - Sensor adjustment 115
 - Simulation 122
 - Switch output 86
 - System units 96
 - Totalizer 116
 - Totalizer reset 133
- Showing data logging 134
- Signal on alarm 170
- SIL (functional safety) 186
- SIMATIC PDM 62
 - Function 62
- Spare part 156
- Spare parts 156
- Special connection instructions 41
- Standards and guidelines 187
- Status area
 - For operational display 48
 - In the navigation view 50
- Status signals 139
- Storage conditions 17
- Storage temperature 17
- Storage temperature range 177
- Structure
 - Measuring device 11
 - Operating menu 46
- Submenu
 - Administration 150
 - Advanced setup 95
 - Burst configuration 1 to 3 65
 - Configuration backup display 120
 - Data logging 134
 - Device information 151
 - Display 118
 - Events list 149
 - External compensation 113
 - Gas composition 102
 - Input values 131
 - Medium properties 99
 - Output values 132
 - Overview 47
 - Process variables 128
 - Sensor adjustment 115
 - Simulation 122
 - System units 96
 - Totalizer 131
 - Totalizer 1 to 3 116
 - Totalizer handling 133
- Supplementary documentation 188
- Supply unit
 - Requirements 33
- Supply voltage 33, 172
- Symbols
 - For communication 48
 - For correction 51
 - For diagnostic behavior 48
 - For locking 48
 - For measured variable 48
 - For measurement channel number 48
 - For menus 50
 - For parameters 50
 - For status signal 48
 - For submenu 50

- For wizard 50
- In the status area of the local display 48
- In the text and numeric editor 51
- System design
 - Measuring system 163
 - see Measuring device design
- System integration 63
- T**
- Technical data, overview 163
- Temperature range
 - Ambient temperature range for display 184
 - Storage temperature 17
- Terminal assignment 32, 39
- terminal voltage 34
- Terminals 173
- Text editor 51
- Thermal insulation 23
- Tool tip
 - see Help text
- Tools
 - Electrical connection 30
 - Installation 25
 - Transport 17
- Transmitter
 - Connecting the signal cables 39
 - Turning the display module 28
 - Turning the housing 27
- Transporting the measuring device 17
- Troubleshooting
 - General 137
- Turning the display module 28
- Turning the electronics housing
 - see Turning the transmitter housing
- Turning the transmitter housing 27
- U**
- Use of the measuring device
 - Borderline cases 9
 - Incorrect use 9
 - see Designated use
- User interface
 - Current diagnostic event 147
 - Previous diagnostic event 147
- User roles 47
- V**
- Version data for the device 63
- Vibration resistance 177
- Vibrations 24
- W**
- W@M 155, 156
- W@M Device Viewer 12, 156
- Weight
 - Compact version
 - SI units 179
 - US units 179
 - Flow conditioner 180
- Sensor remote version
 - SI units 180
 - US units 180
- Transport (notes) 17
- Wizard
 - Current input 73
 - Current output 1 to 2 76
 - Define access code 124
 - Display 90
 - Low flow cut off 93
 - Medium selection 71
 - Output conditioning 92
 - Pulse/frequency/switch output 79, 82, 86
- Workplace safety 10
- Write access 58
- Write protection
 - Via access code 124
 - Via write protection switch 125
- Write protection switch 125

www.addresses.endress.com
