


Installer Instructions

DC Blue **ADVANCED** **ROLL-UP**



Domestic Roll-Up Door Operator

Designed, manufactured and supported by ET NICE (Pty) Ltd



www.etnice.co.za

| Introduction. | |
|--------------------------------------------|--------------------------------------------------------------------------------------------------|
| Page 3 | Be Safe! Instructions, warnings and obligations. |
| Page 4 | Technical specifications. |
| Page 5 | Component identification and descriptions. |
| Hardware installation - Mechanical. | |
| Page 6 | Fitting the motorhead and control box. |
| Hardware installation - Electrical. | |
| Page 11 | Control card wiring and layout. |
| Page 19 | Fitting the optional batteries. |
| Control card programming and setup. | |
| Page 12 | How to use the two on-board buttons. |
| Page 12 | Buzzer indications. (Confirmations and trouble shooting) |
| Page 12 | On-board LED indications. (Confirmations) |
| Page 13 | Programming menu, quick reference guide. |
| Page 14 | How to enter programming mode. |
| Page 14 | Option B1 - Runtime setup. Learning the door travel and natural door load profile. |
| Page 15 | Option B2 - Force. Adjusting the safety overload force sensitivity. |
| Page 15 | Option B3 - Beams. Enabling the safety beams input. |
| Page 15 | Option B4 - Auto-close. Enabling and selecting an auto-close time. |
| Page 16 | Option B5 - Positive close - Enabling a positive close force level. |
| Page 16 | Option A1 - Receiver - Learning a transmitter user code into the Button Trigger channel. |
| Page 16 | Option A2 - Receiver - Learning a transmitter user code into the courtesy Light Trigger channel. |
| Page 17 | Option A3 - Receiver - Learning a transmitter user code into the Auxiliary Relay channel. |
| Page 17 | Option A4 - Receiver - Learning a transmitter user code into the Holiday Lock-out channel. |
| Page 17 | Option A5 - Receiver - Erasing a single user code from the receiver memory. |
| Page 18 | Option A6 - Receiver - Master erasing the receiver memory. (Deleting all user codes) |
| Warranty and further information. | |
| Page 20 | Warranty. |

For any assistance with this product that is not covered in this manual please contact us on: 0860 109 238 (RSA) or via our online support facility at www.etnice.co.za.

Be Safe!

WARNING!! These are the general safety obligations for the installers and users of ET NICE (Pty) Ltd automation equipment. A copy of this document also appears in the user instructions. Those instructions must be issued to the responsible end user during the handover and instruction meeting.

1. Only suitably qualified persons, may install, repair or service the product. Unless expressly indicated in the user instructions, no user serviceable components can be found inside any ET NICE (Pty) Ltd automation product.
2. It is important for personal safety to study and follow all the instructions carefully. Incorrect installation or misuse may cause serious personal harm.
3. Keep the instructions in a safe place for future reference.
4. This product was designed and manufactured, strictly for the use indicated in the accompanying documentation. Any other use not expressly indicated in the documentation, may damage the product and/or be a source of danger. ET NICE (Pty) Ltd cannot accept responsibility for improper use or incorrect installation of this product.
5. ET NICE (Pty) Ltd cannot accept responsibility if the principles of good workmanship are disregarded by the installer.
6. ET NICE (Pty) Ltd cannot accept responsibility regarding safety and correct operation of the automation, if other manufacturers' equipment is added to this product.
7. Do not make any modifications or alterations to this product. Do not substitute any component of this product with any other component not expressly designed into this product.
8. Anything other than expressly provided for in the accompanying instructions is not permitted.

Prior to installation:

1. All unnecessary ropes, chains and fasteners must be removed and all unnecessary latches or locks must be disabled from locking.
2. The gate or door must be balanced correctly where it, neither opens nor closes from any position under its own load. When operated by hand the gate or door should be free of hindrance and easily moved (In the case of a garage door if the balancing springs need to be adjusted the adjustment should only be carried out by a qualified and experienced person).
3. The construction of the gate or door must be sound and automatable. It is the responsibility of the installer to ensure that the mechanical components of the gate or door system are sufficient to withstand the necessary forces in cases of overload.
4. It is the responsibility of the installer to ensure the gate or door is sufficiently trapped within its range of travel by means of mechanical ends of travel stoppers.
5. Ensure all fixed mounting points, such as the wall above the door in a garage door system or the posts in a swing gate system, are sound and strong enough to allow proper fixing of the operator.
6. It is the responsibility of the installer to ensure the installed position selected for this product, falls within the limitations of the products ingress protection rating.
7. Ensure the area of installation is not subject to explosive hazards. There should be no volatile gasses or fumes as these can present a serious safety hazard.
8. All ET NICE (Pty) Ltd garage door operators are supplied with a sealed 15A safety plug on lead for use in an electrical code of practice approved plug point. Do not extend, modify or replace the plug lead unless duly qualified as an electrician. Before installing the unit, ensure the mains supply is switched off.
9. ET NICE (Pty) Ltd gate operators are supplied with a terminal connection for the electrical supply beneath the screwed down cover of the operator. In the case of a model requiring 220Vac supply at the operator, an all pole negatively biased switch, with a contact opening of greater than 3mm must be installed within 1.5m of the operator. This switch must be clear of all workings of the system and must be in a position secure from public access. This switch and its connections must be inspected and passed by a certified electrician prior to using it.
10. It is the responsibility of the installer to ascertain that the designated persons (including children) intended to use the system, do not suffer reduced physical sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the system by a person responsible for their safety.
11. The drive may not be installed on a door incorporating a wicket door, unless the drive is disabled by the release of the wicket door. (Wicket door :- A pedestrian door within the main gate or door)

During installation:

1. Ensure the working area is clear of obstructions and obstacles.
2. Install the safety warning sticker within clear view of where the gate or door will be operated from. Typically this would be adjacent to any fixed trigger switches or on the gate or door itself.
3. The emergency manual release must be installed where it is no higher than 1.8m from the floor level. This would apply to the cord in a garage installation or the lockable lever in a gate installation.
4. Any additional fixed door control switches such as wall consoles or keypads, if installed, must be at a height of at least 1.5m, within clear sight of the gate or door and away from any moving components of the system.


Continued overleaf.....

1. It is highly recommended that a set of safety infra-red beams be used in conjunction with this product. The safety beams must be installed in such a way that the product is prevented from running when anything is in the path of the door or gate.
2. Over and above the recommendation to use safety infra-red beams with this product it is mandatory to install and use a safety beam set when using the automatic closing feature. It is recommended that a warning light be fitted to any automation system.
3. The gate or door warning labels must be installed in a prominent place and/or adjacent to any fixed controls that trigger the system. These must be in clear line of sight of the gate or door opening.
4. The emergency manual release instruction label must be installed on or adjacent to the emergency manual release mechanism.


After installation - It is the responsibility of the installer to ensure the users:

1. Is proficient in the use of the manual emergency release mechanism.
2. Is issued with the documentation accompanying this product.
3. Understands that the gate or door may not be operated out of clear sight.
4. Ensures that children are kept clear of the gate or door area at all times, and that children do not play with the remote transmitters or any fixed trigger switches linked to the system.
5. Is instructed not to attempt to repair or adjust the automation system and to be aware of the danger of continuing to use the automation system in an unsafe condition before a service provider attends to it.
6. Is proficient in testing the unit's safety obstruction sensing system.
7. Is aware of what to check for with regards to wear and tear that may need to be attended to from time to time by the service provider.
8. Is aware that a fatigued battery may not be disposed of in the general refuse and must be handed in at a battery merchant for safe disposal. Before removing the battery from the system the household mains must be disconnected. In the case of the motor unit being removed and scrapped, the battery must be removed first.

Technical specifications.


| | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------|
| Rated door size. | 8m ² |
| Maximum travel. | 137 drum revolutions. |
| Primary power supply to control box. | 220 – 240Vac @ 50Hz – 60Hz |
| Peak power consumption at control box. | 230W |
| Electrical class. | Class 1  |
| Motor voltage. | 24Vdc |
| Ancillary devices power supply output. | 24Vdc @ 200mA |
| Built in battery charger. | 200mA intelligent charger, with low battery cutout. |
| Motor current. | Current limited to 6.5A. |
| Rated Load. | 40N |
| Anti-crushing safety sensing. | Yes – Electronic profiling. |
| Duty cycle maximum. | 25% with 220Vac present. |
| Number of operations on battery reserve. <i>(Battery health and charge level at time of power failure dependent. Calculated on a 2.1m door travel with a movement resistance of 40N or less)</i> | 25 using the standard 1.3Ah batteries within 24hrs. |
| Operating speed. <i>(Door load and power supply dependent)</i> | Up to 8m/min. (Calculated on a door with a drum diameter of 200mm) |
| Built-in courtesy light. | LED cluster. |
| Courtesy light brightness. | 400 lumens. |
| Courtesy light power. | 1W |
| Receiver format. | ET BLU MIX © backward compatible with ET BLUE. (Rolling code) |
| Receiver frequency. | 433.92MHz |
| Receiver channels. | 4CH (Button trigger, Courtesy light, Auxiliary relay, Holiday lock-out) |
| Receiver memory capacity. | 31 users. |
| All users can be allowed control of all channels. | Yes |
| Auto-close mode. | Simple auto-close. |
| Auxiliary relay modes. | Courtesy light, electric lock, receiver relay, alarm. (Via ET E-Coms relay modules) |
| Alarm monitoring. | Safety beam tampering and door forced open alarm. |
| Programming interface. | Up and down buttons, LEDs and buzzer. |
| Ingress protection. | IP20 |
| Operating temperature range. | -20 to 50° C (14F to 122F) |
| Physical dimensions. | See next page. |
| <i>Technical specifications subject to change without prior notice.</i> | |

Component identification and descriptions.




| Diagram number | Description | Diagram number | Description |
|----------------|---------------------------------------|----------------|----------------------------------------------------|
| 1 | Encoder. | 10 | Emergency release cord bobbin. |
| 2 | Geared electric motor. | 11 | Battery cradle. |
| 3 | Torsion bar mounting bracket. | 12 | Torroidal transformer. |
| 4 | Motor-head chasis. | 13 | Control card. |
| 5 | Emergency release lever. | 14 | Household mains supply connector with inline fuse. |
| 6 | Drum wheel engagement fork. | 15 | Factory fitted household mains plug. |
| 7 | Drum wheel. | 16 | Product model decal. |
| 8 | Motor and encoder wiring cable. | 17 | Control box cover with intergrated light diffuser. |
| 9 | Emergency release instructions label. | 18 | Control box cover mounting screw. |

Motor Head




Control Box with batteries installed




Fitting the motorhead.

1




Open door fully.

2




Remove open stops.

3




Carefully feed the curtain out of the guide tracks and allow the door to roll up fully. Using a rope or strap, tie the door up.

4




Carefully allow the door tension to unroll. Count the number of turns as you do this.

5




Install support stands under the door.

6




Remove the U-bolt clamps on both wall brackets.

7




Lower door onto the floor.

8





Put motorhead into manual mode.

9



Slide motorhead over the torsion pole.


10



ET NICE Drum wheel adaptor plate.


Confirm the door's drum wheel spoke is all the way against the surface of the motor head drum wheel. Use an ET Nice drum wheel adapter plate if the fork and spoke do not fit properly.

11




Lift door with inserted motor up onto the wall brackets. Use the axle stands to brace the door.

12




Check spacing and level. Move wall bracket if necessary.

13




Line up the leading edge of the curtain with the top of the guide tracks.

14




Fasten the U Bolt clamps.

15




Roll the door 1 to 2 times towards the wall. Not more than two turns. This should be the same as the turns removed in step 4.

16




While holding the door firmly, remove the rope or strap.

17




Carefully feed the leading edge of the curtain into the tops of the guide tracks.

18




Replace the open stoppers.

19




Move the door through the full length of door travel to test for snagging or coning

20




Test the door remains stationary when closed.

21




Test the door remains stationary when left at 25% open.

22




Test the door remains stationary when left at 50% open.

23




Test the door remains stationary when left at 75% open.

24




Test the door remains stationary when left fully open.

25




Pin curtain to the drumwheels, with pop rivets or "Tek" screws, in the closed position to prevent the door being forced open.

26




For additional support or for installations where the motorhead does not rest on top of the wall bracket, install a "Tek" screw through the motor pipe and into the torsion pipe.

27




Remove the control box front cover.

28



Mount the control box on the wall within reach of the motorhead lead. There is a 1:1 scale mounting hole template included in the kit.

29




Left hand fit -
Red - M+
Yellow - M-

Right hand fit -
Red - M-
Yellow - M+

Wire the motor wires to the control card.


30





Green - 0V
Brown - 5V
White - ENC

Wire encoder wires to control card.







Control card wiring.




Using the buttons when in standby mode: (Installer actions)







| | |
|----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|
| Trigger to run | Stop the door |
|  |  |
| Press release either button | Press release either button |

Using the buttons when in programming mode: (Installer actions)

| | | | | | |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
| Increase by 1 | Decrease by 1 | Runtime | Runtime | Select option | Save value |
|  |  |  |  |  |  |
| 1 x Up | 1 x Down | Hold Up to open | Hold Down to close | 1 x Both | 1 x Both |

| |
|-----------------------------------------------------------------------------------|
| Exit programming |
|  |
| Hold both for 3sec |

Buzzer indications: (Controller responses)

| | | | | | |
|------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| Enter Programming | Exit Programming | Scrolling | Save/select | Error | AC Fail in standby |
|  |  |  |  |  |  |
| 2 x Long | 1 x Long | 1 x Rapid per press | 2 x Rapid | 10 x | 1 x every 15sec. |





LED indications: (Controller responses)


There are three LED statuses. Namely:

Static off.

Static on.

Blinking - LED blinks followed by a pause repeatedly to confirm a program option or option value.

| | | | |
|------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| Standby | Programming | Receiver setup | Operation setup |
|  |  |  |  |
| Both static off | Both static on | Red A blinking | Green B blinking |

| |
|-------------------------------------------------------------------------------------|
| Option value confirmation when in B options |
|  |
| LED A confirms option value LED B confirms which option is selected |

Programming menu, quick reference guide.

| START HERE → | Programming option | | Action to take | | Confirmation | | | Data range |
|------------------------------------------------------|----------------------|---------------------|-----------------------------|----------------------------------|----------------------------------|-----------------------------------------------------------------------------------------|-----------|------------|
| | Up button | Down button | Buzzer | LED A | LED B | | | |
| RX SETUP A6 A5 A4 A3 A2 A1 | Master erase | Not used | Single blip with each press | 6 flashes; pause; 6 flashes..... | LED B | All codes in memory cleared | | |
| | Single button erase | Not used | Single blip with each press | 5 flashes; pause; 5 flashes..... | Off | Only code being transmitted cleared | | |
| | HOL channel learn | Not used | Single blip with each press | 4 flashes; pause; 4 flashes..... | Off | 30 user memory. Each user can be allowed usage of any combination of the 4 channels. | | |
| | RLY channel learn | Not used | Single blip with each press | 3 flashes; pause; 3 flashes..... | Off | | | |
| | LT channel learn | Not used | Single blip with each press | 2 flashes; pause; 2 flashes..... | Off | | | |
| | BT channel learn | Not used | Single blip with each press | 1 flash; pause; 1 flash..... | Off | | | |
| | Programming menu | Press + Hold | Press + Hold | Double beep after 3 seconds | Static on | | Static on | |
| Operation Setup B1 B2 B3 B4 B5 | Runtime setup | Press + release x 1 | Single blip with each press | Flashes saved data value | 1 flash; pause; 1 flash..... | Open, closed positions & load profile | | |
| | Force level setup | Not used | Single blip with each press | Flashes saved data value | 2 flashes; pause; 2 flashes..... | 1 (Most sensitive) - 9 (Least sensitive) | | |
| | Beam input setup | Not used | Single blip with each press | Flashes saved data value | 3 flashes; pause; 3 flashes..... | Enable/disable | | |
| | Auto-close setup | Not used | Single blip with each press | Flashes saved data value | 4 flashes; pause; 4 flashes..... | 0 (Off) - 255 seconds. | | |
| | Positive close setup | Not used | Single blip with each press | Flashes saved data value | 5 flashes; pause; 5 flashes..... | 0 (Off) - 5 (Hardest) | | |

How to enter programming mode:

| | | | | | | |
|-------------------------------|------------------|-----------------------|------------------|------------------------|-----------------------------------|----------------------------------------------------------------------------------------------|
| 1 Confirm | 2 Action | 3 Action | 4 Confirm | 5 Action | 6 Confirm | You have entered the programming options menu. Scroll up or down to required program option. |
| Red - A Green - B | | | | | Red - A Green - B | |
| Standby. Both off. | Hold both | Wait 3 seconds | 2 x Beeps | Release buttons | Program mode. Both on. | |

How to exit programming mode:












(Programming will also exit automatically 30 seconds after the last button press)

| | | | | | | |
|--------------------------------|------------------|-----------------------|------------------|------------------------|-------------------------------|-------------------------------------------------------------------------------------------------------------|
| 1 Confirm | 2 Action | 3 Action | 4 Confirm | 5 Action | 6 Confirm | You have exited the programming options menu. If runtime was previously set, the door can be used normally. |
| Red - A Green - B | | | | | Red - A Green - B | |
| Anywhere in programming | Hold both | Wait 3 seconds | 1 x Beep | Release buttons | Standby. Both off. | |












OPTION B1 - (Runtime) Learning the door travel and natural door load profile.

| | | | | | |
|-------------------------------------|--------------------------------------|-------------------------------------|------------------------------------|------------------------------------|--------------------------------------------------------------------------------|
| 1 Confirm | 2 Action | 3 Confirm | 4 Action | 5 Confirm | 6 Confirm |
| Red - A Green - B | | Red - A Green - B | | | Red - A Green - B |
| Program mode. Both on. | 1 x Down | 1 Blink | Press and release to select | 2 x Rapid beeps | Static on |
| 7 Action | 8 Confirm | 9 Action | 10 Confirm | 11 Action | 12 Action |
| | | | | | |
| Press and hold | Door opens | Release at open position | Door stops | Adjust if required | 1 x Both to save position |
| 13 Confirm | 14 Confirm | 15 Action | 16 Confirm | 17 Action | 18 Confirm |
| | Red - A Green - B | | | | |
| 2 x Rapid beeps | Static on | Press and hold | Door closes | Release at closed position | Door stops |
| 19 Action | 20 Action | 21 Confirm | 22 Confirm | 23 Confirm | 24 Confirm |
| | | | | | |
| Adjust if required | 1 x Both to save position | 2 x Rapid beeps | 1 x Long beep | Door opens and buzzer beeps | Door surges onto open stops |
| 26 Confirm | 27 Confirm | 29 Confirm | 30 Confirm | 31 Confirm | Runtime is complete. Scroll to another programming option or exit programming. |
| | | | | Red - A Green - B | |
| Door closes and buzzer beeps | Door surges into closed stops | Door reverses to saved close | 2 x Rapid beeps | Program mode. Both on. | |












OPTION B2 - (Force) Adjusting the safety overload force sensitivity. 1 Gentle to 9 Hard (Default = 3)

| | | | | | |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>1 Confirm</p>  <p>Red - A Green - B</p> <p>Program mode. Both on.</p> | <p>2 Action</p>  <p>2 x Down</p> | <p>3 Confirm</p>  <p>Red - A Green - B</p> <p>2 x Blinks</p> | <p>4 Action</p>  <p>1 x Both to select option</p> | <p>5 Confirm</p>  <p>2 x Rapid beeps</p> | <p>6 Confirm</p>  <p>Red - A Green - B</p> <p>LED A Current level LED B 2 x Blinks</p> |
| <p>7 Action</p>  <p>Adjust if required</p> | <p>8 Confirm</p>  <p>Red - A Green - B</p> <p>LED A New level LED B 2 x Blinks</p> | <p>9 Action</p>  <p>1 x Both to save</p> | <p>10 Confirm</p>  <p>2 x Rapid beeps</p> | <p>11 Confirm</p>  <p>Red - A Green - B</p> <p>Program mode. Both on.</p> | <p>The new force level is set. Scroll to another programming option or exit programming.</p> |












OPTION B3 - (Beams) ENABLING the safety beam input. (Default = Disabled)

| | | | | | |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>1 Confirm</p>  <p>Red - A Green - B</p> <p>Program mode. Both on.</p> | <p>2 Action</p>  <p>3 x Down</p> | <p>3 Confirm</p>  <p>Red - A Green - B</p> <p>3 x Blinks</p> | <p>4 Action</p>  <p>Press and release</p> | <p>5 Confirm</p>  <p>2 x Rapid beeps</p> | <p>6 Confirm</p>  <p>Red - A Green - B</p> <p>LED A On/off status LED B 3 x Blinks</p> |
| <p>7 Action</p>  <p>Adjust if required</p> | <p>8 Confirm</p>  <p>Red - A Green - B</p> <p>LED A New status LED B 3 x Blinks</p> | <p>9 Action</p>  <p>1 x Both to save</p> | <p>10 Confirm</p>  <p>2 x Rapid beeps</p> | <p>11 Confirm</p>  <p>Red - A Green - B</p> <p>Static on</p> | <p>The safety beam input is now enabled. Scroll to another programming option or exit programming.</p> |










OPTION B4 - (Autoclose) ENABLING an auto-close time. NB! Auto-close is not available without beams enabled.

| | | | | | |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>1 Confirm</p>  <p>Red - A Green - B</p> <p>Program mode. Both on.</p> | <p>2 Action</p>  <p>4 x Down</p> | <p>3 Confirm</p>  <p>Red - A Green - B</p> <p>4 x Blinks</p> | <p>4 Action</p>  <p>1 x Both to select</p> | <p>5 Confirm</p>  <p>2 x Rapid beeps</p> | <p>6 Confirm</p>  <p>Red - A Green - B</p> <p>LED A On/off status LED B 4 x Blinks</p> |
| <p>7 Action</p>  <p>Adjust if required</p> | <p>8 Confirm</p>  <p>Red - A Green - B</p> <p>LED A New status LED B 4 x Blinks</p> | <p>9 Action</p>  <p>1 x Both to save</p> | <p>10 Confirm</p>  <p>2 x Rapid beeps</p> | <p>11 Confirm</p>  <p>Red - A Green - B</p> <p>Static on</p> | <p>The auto-close time is now enabled. Scroll to another programming option or exit programming.</p> |










OPTION B5 - (Positive close) ENABLING a positive close level. (1 Gentle to 5 Hard)

| | | | | | |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>1 Confirm</p>  <p>Red - A Green - B</p> <p>Program mode. Both on.</p> | <p>2 Action</p>  <p>A B</p> <p>5 x Down</p> | <p>3 Confirm</p>  <p>Red - A Green - B</p> <p>5 x Blinks</p> | <p>4 Action</p>  <p>A B</p> <p>1 x Both to select</p> | <p>5 Confirm</p>  <p>2 x Rapid beeps</p> | <p>6 Confirm</p>  <p>Red - A Green - B</p> <p>LED A Current level LED B 5 x Blinks</p> |
| <p>7 Action</p>  <p>A Or B</p> <p>Adjust if required</p> | <p>8 Confirm</p>  <p>Red - A Green - B</p> <p>LED A New level LED B 5 x Blinks</p> | <p>9 Action</p>  <p>A B</p> <p>1 x Both to save</p> | <p>10 Confirm</p>  <p>2 x Rapid beeps</p> | <p>11 Confirm</p>  <p>Red - A Green - B</p> <p>Static on</p> | <p>The Positive close mode is now enabled. Scroll to another programming option or exit programming.</p> |










Option A1 - Receiver: Learning a transmitter user code into the Button Trigger channel.

| | | | | | |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| <p>1 Confirm</p>  <p>Red - A Green - B</p> <p>Program mode. Both on.</p> | <p>2 Action</p>  <p>A B</p> <p>1 X Up</p> | <p>3 Confirm</p>  <p>Red - A Green - B</p> <p>1 x Blink</p> | <p>4 Action</p>  <p>Press and hold desired channel</p> | <p>5 Action</p>  <p>A B</p> <p>1 X Both to save</p> | <p>6 Confirm</p>  <p>2 x rapid beeps</p> |
| <p>7 Confirm</p>  <p>1 = Pass. 3 = Fail</p> <p>Beeps</p> | <p>8 Action</p>  <p>Release button</p> | <p>9 Confirm</p>  <p>Red - A Green - B</p> <p>1 x Blink</p> | <p>Repeat from 4 for additional transmitters, scroll to another programming option or exit programming.</p> | | |










Option A2 - Receiver: Learning a transmitter user code into the Light Trigger channel.

| | | | | | |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|
| <p>1 Confirm</p>  <p>Red - A Green - B</p> <p>Program mode. Both on.</p> | <p>2 Action</p>  <p>A B</p> <p>2 X Up</p> | <p>3 Confirm</p>  <p>Red - A Green - B</p> <p>2 x Blinks</p> | <p>4 Action</p>  <p>Press and hold desired channel</p> | <p>5 Action</p>  <p>A B</p> <p>1 X Both to save</p> | <p>6 Confirm</p>  <p>2 x rapid beeps</p> |
| <p>7 Confirm</p>  <p>1 = Pass. 3 = Fail</p> <p>Beeps</p> | <p>8 Action</p>  <p>Release button</p> | <p>9 Confirm</p>  <p>Red - A Green - B</p> <p>2 x Blinks</p> | <p>Repeat from 4 for additional transmitters, scroll to another programming option or exit programming.</p> | | |










Option A3 - Receiver: Learning a transmitter user code into the Auxiliary Relay channel. (Requires E-coms relay)

| | | | | | |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| <p>1 Confirm</p>  <p>Red - A Green - B</p> <p>Program mode. Both on.</p> | <p>2 Action</p>  <p>3 X Up</p> | <p>3 Confirm</p>  <p>Red - A Green - B</p> <p>3 x Blinks</p> | <p>4 Action</p>  <p>Press and hold desired channel</p> | <p>5 Action</p>  <p>1 X Both to save</p> | <p>6 Confirm</p>  <p>2 x rapid beeps</p> |
| <p>7 Confirm</p>  <p>1 = Pass. 3 = Fail</p> <p>Beeps</p> | <p>8 Action</p>  <p>Release button</p> | <p>9 Confirm</p>  <p>Red - A Green - B</p> <p>3 x Blinks</p> | <p>Repeat from 4 for additional transmitters, scroll to another programming option or exit programming.</p> | | |













Option A4 - Receiver: Learning a transmitter user code into the Holiday Lock-out channel.

| | | | | | |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| <p>1 Confirm</p>  <p>Red - A Green - B</p> <p>Program mode. Both on.</p> | <p>2 Action</p>  <p>4 X Up</p> | <p>3 Confirm</p>  <p>Red - A Green - B</p> <p>4 x Blinks</p> | <p>4 Action</p>  <p>Press and hold desired channel</p> | <p>5 Action</p>  <p>1 X Both to save</p> | <p>6 Confirm</p>  <p>2 x rapid beeps</p> |
| <p>7 Confirm</p>  <p>1 = Pass. 3 = Fail</p> <p>Beeps</p> | <p>8 Action</p>  <p>Release button</p> | <p>9 Confirm</p>  <p>Red - A Green - B</p> <p>4 x Blinks</p> | <p>Repeat from 4 for additional transmitters, scroll to another programming option or exit programming.</p> | | |

Option A5 - Receiver: Erasing a single user code. The transmitter must be present.

| | | | | | |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|
| <p>1 Confirm</p>  <p>Red - A Green - B</p> <p>Program mode. Both on.</p> | <p>2 Action</p>  <p>5 X Up</p> | <p>3 Confirm</p>  <p>Red - A Green - B</p> <p>5 x Blinks</p> | <p>4 Action</p>  <p>Press and hold desired channel</p> | <p>5 Action</p>  <p>1 X Both to save</p> | <p>6 Confirm</p>  <p>2 x rapid beeps</p> |
| <p>7 Confirm</p>  <p>1 = Pass. 3 = Fail</p> <p>Beeps</p> | <p>8 Action</p>  <p>Release button</p> | <p>9 Confirm</p>  <p>Red - A Green - B</p> <p>5 x Blinks</p> | <p>Repeat from 4 for additional transmitters, scroll to another programming option or exit programming.</p> | | |


Option A6 - Receiver: Master erasing the receiver memory. This does not effect any of the B option values.

| | | | | | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>1 Confirm</p>  <p>Red - A Green - B</p> <p>Program mode. Both on.</p> | <p>2 Action</p>  <p>A</p> <p>B</p> <p>6 x Up</p> | <p>3 Confirm</p>  <p>Red - A Green - B</p> <p>6 x Blinks</p> | <p>4 Action</p>  <p>A B</p> <p>1 X Both to save</p> | <p>5 Confirm</p>  <p>2 x rapid beeps</p> | <p>6 Action</p>  <p>A B</p> <p>Hold both</p> |
| <p>7 Confirm</p>  <p>On/off beeping. Erase can be aborted by releasing buttons.</p> | <p>8 Confirm</p>  <p>Beeping stops as erase occurs</p> | <p>9 Confirm</p>  <p>1 x long beep as erase finishes</p> | <p>10 Action</p>  <p>A B</p> <p>Release buttons</p> | <p>11 Confirm</p>  <p>2 x rapid beeps</p> | <p>10 Confirm</p>  <p>Red - A Green - B</p> <p>Program mode. Both on.</p> |

**Receiver master
erase is complete.
Scroll to another
programming
option or exit
programming.**


Fitting the Batteries.

1




Remove the two longer battery leads from the kit.

2




Feed the leads through the hole in the battery cradle and connect them to the battery terminals on the card.

3




Remove the cable tie from the kit.

4




Feed the cable tie through the hole in the battery cradle, then beneath the cradle and out the hole at the back again.

5



Place the batteries in the cradle and fasten them in place using the cable tie.

6



Connect the battery leads in the method shown here.

WARRANTY:

1. All goods manufactured by ET NICE (Pty) Ltd carry a 12 month factory warranty from date of original invoice.
2. All goods are warranted to be free of faulty components and manufacturing defects.
3. Faulty goods will be repaired or replaced at the sole discretion of ET NICE (Pty) Ltd free of charge. Within the warranty period.
4. This warranty is subject to the goods being returned to the premises of ET NICE (Pty) Ltd.
5. The carriage of goods is for the customer's account.
6. This warranty is only valid if the correct installation and application of goods, as laid out in the applicable documentation accompanying said goods, is adhered to.
7. All warranty claims must be accompanied by the original invoice.
8. All claims made by the end user must be directed to their respective service provider/installer.

The following conditions will disqualify this product from the warranty as laid out above. These conditions are non- negotiable.

1. Any unauthorized non-manufacturer modifications to the product or components thereof.
2. Any modification to the installation methods described in the installation instructions.
3. Any application or use of the product other than the intended use and application described in the product documentation.

The following items are not included in the warranty or they carry a special warranty condition of their own.

1. The battery (Limited 6 month warranty)
2. The motor brushes.
3. Damage resultant of wind and other climatic influences such as lightning strikes.
4. Damage due to high voltage surges on the household mains or short circuiting of the gates to the electric fencing.
5. Damage due to infestation i.e. Ants nesting...
6. Water damage. It is the responsibility of the installer to ensure the product is installed in a location that is protected from water ingress. The ingress protection rating is specified in the accompanying documentation. Housings that require that cable entries are made by the installer do not carry an ex-factory ingress protection rating as it is the responsibility of the installer to seal the cable entry points after installation of the cabling.

For further product documentation, such as the sales brochure, visit our webpage by scanning the QR code here:

