

Performance Series IP Network Video Recorder

HEN04101(X)	HEN08101(X)	HEN16101(X)
HEN04111(X)	HEN08121(X)	HEN16131(X)
HEN04121(X)	HEN08141(X)	HEN16161(X)
	HEN08161(X)	




User Guide

User Guide

Revisions

Issue	Date	Revisions
A	06/2014	New document based on 800-18160V1.
V1 Rev A	12/2014	Added new models [HEN0401(X); HDN04111(X); HEN04121(X); HEN08101(X); HEN16101(X)] to front page, and updated the Specifications section for the addition of the 4-channel NVRs.
V1 Rev A	01/2015	Updated some of the Specifications.

Cautions and Warnings

	<p style="text-align: center;">CAUTION</p> <p style="text-align: center;">RISK OF ELECTRIC SHOCK DO NOT OPEN</p>		<p>THIS SYMBOL INDICATES THAT DANGEROUS VOLTAGE CONSTITUTING A RISK OF ELECTRIC SHOCK IS PRESENT WITHIN THE UNIT.</p>
<p>CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.</p>			 <p>THIS SYMBOL INDICATES THAT IMPORTANT OPERATING AND MAINTENANCE INSTRUCTIONS ACCOMPANY THIS UNIT.</p>

Installation and servicing should be performed only by qualified and experienced technicians to conform to all local codes and to maintain your warranty.

WARNING Use only with the supplied power converters. The Ethernet connection is not intended to be connected to an exposed (outside plant) network.

CAUTION There is a risk of explosion if the battery is replaced by an incorrect type. Dispose of used batteries in accordance to local laws.

CAUTION Installation and servicing should be performed only by qualified and experienced technicians to conform to all local codes and to maintain your warranty.

Regulatory Statements

FCC Compliance Statement

Information to the User: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This Class B digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la Classe B est conforme à la norme NMB-003 du Canada.

Manufacturer's Declaration of Conformance

North America

The equipment supplied with this guide conforms to UL 60950-1 and CSA C22.2 No. 60950-1.

Europe

The manufacturer declares that the equipment supplied is compliant with the essential protection requirements of the EMC directive 2004/108/EC and the Low Voltage Directive (LVD) 2006/95/EC, conforming to the requirements of standards EN 55022 for emissions, EN 50130-4 for immunity, and EN 60950 for electrical equipment safety.

Waste Electrical and Electronic Equipment (WEEE)



Correct Disposal of this Product (applicable in the European Union and other European countries with separate collection systems).

This product should be disposed of, at the end of its useful life, as per applicable local laws, regulations, and procedures.

Safety Instructions

BEFORE OPERATING OR INSTALLING THE UNIT, READ AND FOLLOW ALL INSTRUCTIONS. AFTER INSTALLATION, retain the safety and operating instructions for future reference

1. **HEED WARNINGS** - Adhere to all warnings on the unit and in the operating instructions.
2. **INSTALLATION**
 - Install in accordance with the manufacturer's instructions.
 - Installation and servicing should be performed only by qualified and experienced technicians to conform to all local codes and to maintain your warranty.
 - Do not install the unit in an extremely hot or humid location, or in a place subject to dust or mechanical vibration. The unit is not designed to be waterproof. Exposure to rain or water may damage the unit.
 - Any wall or ceiling mounting of the product should follow the manufacturer's instructions and use a mounting kit approved or recommended by the manufacturer.
3. **POWER SOURCES** - This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supplied to your facility, consult your product dealer or local power company.
4. **HEAT** - Situate away from items that produce heat or are heat sources such as radiators, heat registers, stoves, or other products (including amplifiers).
5. **WATER AND MOISTURE** - Do not use this unit near water or in an unprotected outdoor installation, or any area classified as a wet location.
6. **MOUNTING SYSTEM** - Use only with a mounting system recommended by the manufacturer, or sold with the product.
7. **ATTACHMENTS** - Do not use attachments not recommended by the product manufacturer as they may result in the risk of fire, electric shock, or injury to persons.
8. **ACCESSORIES** - Only use accessories specified by the manufacturer.
9. **CLEANING** - Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
10. **SERVICING** - Do not attempt to service this unit yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
11. **REPLACEMENT PARTS** - When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

Warranty and Service

Subject to the terms and conditions listed on the Product warranty, during the warranty period Honeywell will repair or replace, at its sole option, free of charge, any defective products returned prepaid.

In the event you have a problem with any Honeywell product, please call Customer Service at 1.800.323.4576 for assistance or to request a **Return Merchandise Authorization (RMA)** number.

Be sure to have the model number, serial number, and the nature of the problem available for the technical service representative.

Prior authorization must be obtained for all returns, exchanges, or credits. **Items shipped to Honeywell without a clearly identified Return Merchandise Authorization (RMA) number may be refused.**

Contents

About This Document	21
Overview of Contents	21
Related Documents	22
Typographical Conventions	22
1 Introduction	25
Overview of the Performance Series NVR	25
Features of the Performance Series Network Video Recorder	26
Network Video Recorder Components	27
USB 2.0 Mouse Components and Functions	31
Single-click the Left Mouse Button	31
Double-click the Left Mouse Button	31
Single-click the Right Mouse Button	32
Click the Mouse Wheel	32
Other Mouse Functions	32
2 Installation	33
Alarm Connection	33
Alarm Configuration	33
Bi-Directional Communication Connection	34
Audio Output Device to a PC	34
Connect:	34
Configuring to Hear Audio From the NVR	34
PC to an Audio Input Device	34
Connect:	34
Configuring to Hear Audio from the PC	35
Hard Disk Drive Installation	35
Hard Disk Drive Recommendations	35
Installing a HDD	35
Network Connection	38
3 NVR Configurations	39
Logging In to Your NVR	39
Logging In and Setting Up with the Startup Wizard	40
Opening the Main Menu	44
Live View	45
Preview Control	45
Preview Control Interface	46
Playback Control	47
Right-Click Menu	47
Main Menu	48
Search and Playback	48
Information	53
HDD Information	54
Viewing the HDD Recording Time Information	54
BPS	55

Log	56
Version	58
Online Users	58
Remote Device Information Tab	59
Network Information	60
Settings	62
Configuring the General Settings.	63
Configuring the Encoding Settings.	66
Configuring the Schedule	69
Configuring RS232	71
Configuring the Network	73
Configuring Alarms	93
Configuring Detection Settings	98
Configuring Display Settings	109
Configuring Default Settings	111
Connecting to and Configuring the Remote Devices/Cameras.	111
Configuring the Built-in Switch Setup	112
Configuring the Remote Device/Camera	113
Advanced Configurations	115
Configuring HDD Management.	116
Configuring Abnormality Settings	119
Configuring Alarm Output	121
Configuring Manual Recording Settings	121
Configuring Account Settings	122
Configuring Automatic Maintenance Settings	126
Configuring Backup	127
Shutting Down the NVR.	127
4 Honeywell Configuration Tool	129
Starting the Honeywell Configuration Tool.	129
Installing the Honeywell Configuration Tool.	129
Opening the Honeywell Configuration Tool, Searching for Devices, and Opening a Web Client	131
Upgrading a Single Device (IP Camera or NVR)	132
Upgrading the IP Devices (Batch Upgrade).	135
Modifying the IP Address	138
5 Web Operation	141
Preparing to Use the Device Web Client	141
PC Requirements	141
Before You Log In	142
Logging In	142
LAN Mode	145
Section 1: Function Buttons	145
Section 2: Monitor Channels	146
Section 3: Start Talk Button	146
Section 4: Instant Record Button	147
Section 5: Local Play Button	147
Section 6: PTZ Control Panel	147
Section 7: Image and Alarm Configuration Panels	147
Section 8: Viewer Configuration Controls	148
Real-Time Monitoring	148
Configuring Image/Alarm Out Settings	149
Configuring Image Settings	149
Configuring Alarm Output	150
Playing Back Recorded Video	150
Downloading Video	152
Loading More	153
Enabling and Disabling Alarms	154
Configuring Settings	155

Configuring Remote Settings	156
Remotely Adding a Device/Camera	156
Remotely Configuring Video and Audio	158
Configuring the Channel Name	161
Configuring Network Settings	161
Configuring TCP/IP Settings	161
Configuring the Network Connection	163
Configuring Wifi	163
Configuring CDMA/GPRS for 3G	164
Configuring the Mobile Setup for 3G	165
Configuring PPPoE	166
Configuring DDNS	167
Configuring the IP Filter	169
Configuring Email Settings	169
Configuring UPnP	171
Configuring SNMP	172
Configuring Multicast	173
Configuring Auto Registration Settings	174
Configuring Events	174
Configuring Detection Settings	175
Configuring for Motion Detection	175
Configuring for Video Loss Detection	179
Configuring for Camera Masking	180
Configuring Alarms	181
Configuring Local Alarms	181
Configuring Net Alarms	184
Configuring External Alarms	184
Configuring for No Signal	185
Configuring for Abnormalities	186
Configuring Storage	187
Configuring Schedules for Storage	187
Configuring Local Storage for Schedules	189
Configuring the HDD Group Settings	189
Configuring Recording Settings	190
Configuring the Channel for Schedules	190
Configuring Settings	192
Configuring General Settings	192
General Settings	193
Date & Time Settings	193
Holiday Settings	194
Configuring Account Settings	195
Configuring User Settings	195
Configuring Group Settings	197
Configuring Display Settings	199
Enabling and Disabling Alarm Out Settings	200
Returning to Default Settings	201
Configuring Backup Settings	201
Configuring Automatic Maintenance Settings	202
Configuring Preview Control Settings	202
Configuring System Information	203
Viewing the Version	203
Configuring the Log	203
Viewing the Online Users	204
Logging Out	205
Appendix A Troubleshooting	207
Problem: The NVR does not boot up properly	207
Problem: The NVR cannot detect the hard disk	208

Problem: The real-time video color is distorted 208

Problem: Motion detection does not work 208

Problem: You can not log into the NVR or web client 209

Problem: The remote control does not work. 209

Problem: You have forgotten the local menu operation password or network password 210

Problem: There is no video; the screen is black 210

Problem: When viewing multiple channels in the client end, the video is not smooth 210

Appendix B Daily Maintenance 211

Appendix C Specifications 213

Appendix D Compatible IP Cameras 217

NOTE: Connecting to Group 1 IP Cameras 220

NOTE: Connecting to Group 2 IP Cameras 221

NOTE: Connecting to Group 3 IP Cameras 223

Appendix E Compatible SATA HDD 225

Appendix F Compatible USB 2.0 Devices 227

Appendix G Compatible Monitors. 229

Index. 231

Table 1-1	Performance Series Network Video Recorder Features	26
Table 1-2	NVR Front Panel Components	27
Table 1-3	NVR Back Panel Components	29
Table 1-4	Single-click Left Mouse Button Functions	31
Table 1-5	Double-click Left Mouse Button Functions.	31
Table 1-6	Single-click Right Mouse Button Functions	32
Table 1-7	Mouse Wheel Functions	32
Table 3-1	Channel Recording and Alarm Status Icons	40
Table 3-2	Default Accounts	41
Table 3-3	Preview Controls	46
Table 3-4	Search GUI	49
Table 3-5	Playback Controls	52
Table 3-6	HDD Drive Status Symbols	54
Table 3-7	HDD Recording Time Information	55
Table 3-8	General Settings	64
Table 3-9	Encode Configurations	67
Table 3-10	Schedule Configurations	70
Table 3-11	RS232 Configurations	72
Table 3-12	Network Configurations.	73
Table 3-13	IP Filter Configurations	77
Table 3-14	NTP Configurations.	78
Table 3-15	Time Zones	78
Table 3-16	Multicast Configurations Special IP Addresses	79
Table 3-17	DDNS Configurations	81
Table 3-18	UPnP Configurations	83
Table 3-19	WIFI Setting Functions/Control	85
Table 3-20	Email Configurations	87
Table 3-21	FTP Configurations	90
Table 3-22	Alarm Configurations	94
Table 3-23	Motion Detection Configurations	99
Table 3-24	Video Loss Detection Configurations.	103
Table 3-25	Camera Masking Detection Configurations	106
Table 3-26	Display Configurations	110
Table 3-27	Remote Device Configurations	113
Table 3-28	HDD MANAGE Configurations	117
Table 3-29	Abnormality Configurations.	120
Table 3-30	Manual Recording Configurations	122
Table 3-31	SHUTDOWN Selections	128
Table 5-1	PC Requirements	141
Table 5-2	Viewer Configuration Controls	148
Table 5-3	Live View Video Window Controls	149
Table 5-4	Live View Video Window Controls	149
Table 5-5	Image Settings	150
Table 5-6	Alarm Configurations	155
Table 5-7	Remote - Add Device Configurations.	156

Table 5-8	Video&Audio Configuration Interface	158
Table 5-9	Snapshot Configurations	159
Table 5-10	Video Overlay Configurations	160
Table 5-11	TCP/IP Configurations	162
Table 5-12	Network Connection Configurations	163
Table 5-13	CDMA/GPRS Configurations	165
Table 5-14	DDNS Configuration Options	167
Table 5-15	DDNS Configurations	168
Table 5-16	Email Configurations	170
Table 5-17	SNMP Configurations	173
Table 5-18	Motion Detection Configurations	176
Table 5-19	Local Alarm Configurations	182
Table 5-20	Configuring for Abnormalities	186
Table 5-21	Schedule Configurations	189
Table 5-22	Recording Configurations for Storage	190
Table 5-23	General Settings Configurations	193
Table 5-24	Date & Time Configurations	193
Table 5-25	GUI Configurations	200
Table 5-26	Configuration Backup/Import&Export Interface	202
Table 5-27	Log Configurations	204
Table A-1	PC Requirements	210
Table C-1	Specifications	213
Table D-1	Compatible IP Cameras	217
Table D-2	Connecting Group 1IP Cameras	220
Table D-3	Connecting to Group 2 IP Cameras	221
Table D-4	Connecting to Group 3 IP Cameras	223
Table E-1	Compatible SATA HDD	225
Table F-1	Compatible USB 2.0 Devices	227
Table G-1	Compatible Monitors	229

Figures

Figure 1-1	NVR Front Panel	27
Figure 1-2	NVR Back Panel	29
Figure 2-3	Enabling Bi-Directional Communication.	34
Figure 2-4	Configuring to Hear from the NVR.	34
Figure 2-5	Configuring to Hear from the PC	35
Figure 2-6	Removing the NVR Cover	36
Figure 2-7	Loosening the Four Screws in the HDD Housing	36
Figure 2-8	Placing the HDD	36
Figure 2-9	Securing the HDD to the NVR Housing	37
Figure 2-10	Connecting the HDD and the Power Cable	37
Figure 2-11	Replacing the NVR Cover	37
Figure 2-12	Securing the NVR Cover.	37
Figure 2-13	Network Connections	38
Figure 3-1	Multiple-channel Display Mode	40
Figure 3-2	Startup Wizard	40
Figure 3-3	System Login Window	41
Figure 3-4	Electronic Keyboard	41
Figure 3-5	General Window	42
Figure 3-6	Network Configuration Window	43
Figure 3-7	Remote Device Configuration Window	43
Figure 3-8	Schedule Configuration Window	44
Figure 3-9	Configuration Wizard Message	44
Figure 3-10	Right-click Menu	45
Figure 3-11	Main Menu	45
Figure 3-12	Preview Control Interface	46
Figure 3-13	Right-cut Menu.	47
Figure 3-14	Main Menu	48
Figure 3-15	Search Interface	48
Figure 3-16	Card Number Search Interface	52
Figure 3-17	Information Tab	53
Figure 3-18	HDD Information Tab	54
Figure 3-19	HDD Recording Time Information Interface	55
Figure 3-20	BPS Interface	56
Figure 3-21	Log Tab	57
Figure 3-22	Detailed Information About a Log File	57

Figure 3-23	Version Tab	58
Figure 3-24	Online Users Tab	59
Figure 3-25	Channel/Device Status	59
Figure 3-26	Connection Log	60
Figure 3-27	Network Test Tab	61
Figure 3-28	Network Load Interface	62
Figure 3-29	Setting Interface	63
Figure 3-30	General Settings Interface	64
Figure 3-31	Encode Interface.	67
Figure 3-32	Schedule Interface.	70
Figure 3-33	Copy Interface	71
Figure 3-34	Network Interface	73
Figure 3-35	Network Setting Configuration Interface	75
Figure 3-36	IP Filter Configuration Interface	76
Figure 3-37	NTP Configuration Interface	78
Figure 3-38	Multicast Configuration Interface	79
Figure 3-39	PPPoE Configuration Interface	80
Figure 3-40	DDNS Configuration Interface	81
Figure 3-41	UPNP Configuration Interface	83
Figure 3-42	Port Info Configuration Interface.	84
Figure 3-43	WIFI Connection Status	84
Figure 3-44	WIFI Setting Interface	85
Figure 3-45	Viewing WIFI Settings	87
Figure 3-46	Email Configurations Interface.	87
Figure 3-47	Configuring FTP	88
Figure 3-48	Testing the FTP Setup	89
Figure 3-49	Network Setting Configuration Interface	89
Figure 3-50	FTP Configuration Interface	90
Figure 3-51	Message Indication FTP Connection Failure	91
Figure 3-52	SNMP Configuration Interface	92
Figure 3-53	Auto Register Configuration Interface	93
Figure 3-54	Alarms Configuration Interface	94
Figure 3-55	Detect Configuration Interface.	99
Figure 3-56	Video Loss Configuration Interface	103
Figure 3-57	Camera Masking Configuration Interface	106
Figure 3-58	Display Configuration Interface	109
Figure 3-59	NVR Real Panel - PoE Ports	112
Figure 3-60	Switch Settings Configuration Interface	112
Figure 3-61	Remote Device Configuration Interface	113
Figure 3-62	Manual Add Configuration Interface.	114
Figure 3-63	Short-cut to Remote Device Configuration Interface	114
Figure 3-64	Remote Device Configuration Interface	115
Figure 3-65	Advanced Configuration Interface.	115
Figure 3-66	HDD MANAGE Configuration Interface	116
Figure 3-67	HDD Setting Configuration Interface	118

Figure 3-68	Channel Settings Configuration Interface	119
Figure 3-69	Abnormality Configuration Interface	120
Figure 3-70	ALARM OUTPUT Configuration Interface	121
Figure 3-71	RECORD Configuration Interface	121
Figure 3-72	ACCOUNT Configuration Interface	123
Figure 3-73	Add Group Configuration Interface	124
Figure 3-74	Add User Configuration Interface	125
Figure 3-75	Modifying Password Configuration Interface	126
Figure 3-76	AUTO MAINTAIN Configuration Interface	126
Figure 3-77	BACKUP Configuration Interface	127
Figure 3-78	SHUTDOWN Dialog Box.	128
Figure 4-1	Honeywell Config Tool Wizard	130
Figure 4-2	User License Agreement Page	130
Figure 4-3	Installation is Complete Page	131
Figure 4-4	Configtool Interface	132
Figure 4-5	ConfigTool Login.	132
Figure 4-6	Device Upgrade Login Interface.	133
Figure 4-7	Config Upgrade Interface	133
Figure 4-8	Device Offline Message	134
Figure 4-9	Upgrade Interface	134
Figure 4-10	ConfigTool Login.	135
Figure 4-11	Upgrade Interface	136
Figure 4-12	Open Interface	136
Figure 4-13	Upgrade Interface	137
Figure 4-14	Batch Upgrade Progress Message	137
Figure 4-15	Batch Upgrade Successful Message	138
Figure 4-16	ConfigTool Login.	138
Figure 4-17	Selecting Net in the ConfigTool	139
Figure 5-1	IE Window	143
Figure 5-2	Configuring the ActiveX Controls	144
Figure 5-3	Login Interface	144
Figure 5-4	LAN Mode Main Window	145
Figure 5-5	LAN Main Window Function Buttons	145
Figure 5-6	Monitor Channels Section	146
Figure 5-7	Start Talk Button	146
Figure 5-8	Instant Record Button	147
Figure 5-9	Local Play - Select a File Interface.	147
Figure 5-10	Live View Video Window.	148
Figure 5-11	Image Settings.	150
Figure 5-12	Alarm Out Configuration Interface.	150
Figure 5-13	Playback Interface	151
Figure 5-14	List of Recorded Video Clips	151
Figure 5-15	Playing Back Video	152
Figure 5-16	Downloading Recorded Video.	153
Figure 5-17	Download by File/Download by Time Interfaces	153

Figure 5-18	Alarm Configuration Interface	154
Figure 5-19	Remotely Adding a Device Configuration Window	156
Figure 5-20	Manual Add Configuration Window	157
Figure 5-21	Video&Audio Configuration Interface	158
Figure 5-22	Snapshot Configuration Interface	159
Figure 5-23	Video Overlay Configuration Interface.	160
Figure 5-24	Path Configuration Interface	161
Figure 5-25	Channel Name Configuration Interface	161
Figure 5-26	TCP/IP Configuration Interface	162
Figure 5-27	Connection Configuration Interface	163
Figure 5-28	Wifi Configuration Interface	164
Figure 5-29	CDMA/GPRS Configuration Interface	165
Figure 5-30	Mobile Setup Configuration Interface	166
Figure 5-31	PPPoE Configuration Interface	166
Figure 5-32	DDNS Configuration Interface	168
Figure 5-33	IP Filter Configuration Interface	169
Figure 5-34	Email Configuration Interface.	170
Figure 5-35	UPnP Configuration Interface	172
Figure 5-36	SNMP Configuration Interface	173
Figure 5-37	Multicast Configuration Interface	174
Figure 5-38	Auto Register Configuration Interface	174
Figure 5-39	Detect Configuration Interface	175
Figure 5-40	Video Loss Configuration Interface	180
Figure 5-41	Camera Masking Configuration Interface	181
Figure 5-42	Local Alarm Configuration Interface	182
Figure 5-43	Net Alarm Configuration Interface	184
Figure 5-44	IPC External Alarm Configuration Interface	185
Figure 5-45	No Signal Configuration Interface	185
Figure 5-46	Configuring for Abnormalities	186
Figure 5-47	Schedule Configuration Interface	188
Figure 5-48	Set Configuration Interface	188
Figure 5-49	Local Storage Configuration Interface for Schedules	189
Figure 5-50	HDD Setting Configuration Interface	189
Figure 5-51	Record Configuration Interface for Storage Settings	190
Figure 5-52	Channel Configuration Interface.	191
Figure 5-53	Extra Stream Configuration Interface	191
Figure 5-54	Image Storage Configuration Interface	191
Figure 5-55	General Settings	192
Figure 5-56	Date & Time Configuration Interface	193
Figure 5-57	Holiday Settings Configuration Interface	194
Figure 5-58	Account Settings Configuration Interface	195
Figure 5-59	Add User Configuration Interface	196
Figure 5-60	Modify User Configuration Interface.	197
Figure 5-61	Group Configuration Interface	198
Figure 5-62	Add Group Configuration Interface	198

Figure 5-63	Modify Group Configuration Interface	199
Figure 5-64	GUI Configuration Interface	200
Figure 5-65	Alarm Out Configuration Interface.	201
Figure 5-66	Default Settings Interface	201
Figure 5-67	Import&Export Interface	202
Figure 5-68	Auto Maintain Configuration Interface	202
Figure 5-69	Preview Control Configuration Interface.	203
Figure 5-70	Version Configuration Interface	203
Figure 5-71	Log Configuration Interface	204
Figure 5-72	Online User Configuration Interface.	205
Figure 5-73	Login Interface	205

About This Document

This document introduces the Honeywell Performance Series Network Video Recorder. It explains how to install and operate the Performance Series Network Video Recorder.

This document is intended for installers and users.

Overview of Contents

This document contains the following chapters and appendixes:

- [Chapter 1, Introduction](#), introduces the Performance Series Network Video Recorder, including descriptions of their features and illustrations showing the NVRs' dimensions.
- [Chapter 2, Installation](#), describes how to install and connect the NVR, including alarm and bi-directional audio connections.
- [Chapter 3, NVR Configurations](#), describes how to configure your NVR, including how to log into your NVR, and how to configure your NVR's settings.
- [Chapter 4, Honeywell Configuration Tool](#), describes how to install and use the Quick Configuration tool for configuring your NVR.
- [Chapter 5, Web Operation](#), describes how to connect to your NVR over the internet, the user interface, and how to remotely configure and operate your NVR.
- [Appendix A, Troubleshooting](#), describes possible problems and their solutions.
- [Appendix B, Daily Maintenance](#), describes how to care for your NVR.
- [Appendix C, Specifications](#), provides the NVR's specifications.
- [Appendix E, Compatible SATA HDD](#), lists the manufacturers and models of compatible SATA HDD.
- [Appendix F, Compatible USB 2.0 Devices](#), lists the manufacturers and models of USB 2.0 storage devices.
- [Appendix G, Compatible Monitors](#), lists the manufacturers and models of compatible monitors.
- The [Index](#), provides a searchable list for easy access to the document.

Related Documents

This document is a necessary prerequisite for understanding the Performance Series Network Video Recorder. For more information, please refer to the following documents:

Document title	Part number	Description
<i>Embedded NVR Quick Installation Guide</i>	800-16860	Visually describes how to connect and start up an Performance Series NVR.
<i>Embedded NVR Quick Networking Guide</i>	800-16861	Visually describes how to configure network connections, including the mobile application.
<i>H2D2PR1(X) 1080p True Day/Night IR Ball IP Camera Quick Installation Guide</i>	800-17073	Describes the physical setup of a H2D2PR1(X) ball camera.
<i>HBD2PR1(X) 1080p True Day/Night IR Bullet IP Camera Quick Installation Guide</i>	800-17077	Describes the physical setup of a HBD2PR1(X) ball camera.
<i>Performance Series IP Cameras User Guide</i>	800-18161	Describes the Performance Series IP Cameras, how to install them, how to configure them, and how to operate them.

Typographical Conventions

This document uses the following typographical conventions:

Font	What it represents	Example
Helvetica	Keys on the keyboard	Press Ctrl+C
Lucida	Values of editable fields that are mentioned in the body text of the document for reference purposes, but do not need to be entered as part of a procedure	The Time from field can be set to Hours:Minute:Seconds.
	Text strings displayed on the screen Syntax	The message Unauthorized displays. (object) entered
Swiss721 BT Bold	Words or characters that you must type. The word “enter” is used if you must type text and then press the Enter or Return key.	Enter the password .
	Menu titles and other items you select	Double-click Open from the File menu.
	Buttons you click to perform actions	Click Exit to close the program.

Font	What it represents	Example
<i>Italic</i>	Placeholders: words that vary depending on the situation	Enter your <i>user name</i> .
	Cross-reference to external source	Refer to the <i>Embedded NVR Quick Installation Guide</i> .
	Cross-reference within document	See <i>Chapter 2, Configuration</i> .

1

Introduction

This chapter covers:

- An overview of the Performance Series Network Video Recorder and its features.
- An overview of the USB mouse.

Overview of the Performance Series NVR

The Performance Series Network Video Recorder is a high-performance network video recorder. It supports:

- Local preview
- Multiple-window display
- Local recorded file storage
- Remote control and mouse shortcut menu operation
- Remote management
- Control

The Performance Series Network Video Recorder also features multiple storage options:

- Central storage
- Front-end storage
- Client-end storage

Because of the flexibility of its design, the Performance Series Network Video Recorder can be used in a variety of applications, such as public security, water conservancy, transportation, and education.

Features of the Performance Series Network Video Recorder

Table 1-1 Performance Series Network Video Recorder Features


Category	Features
User Management	<ul style="list-style-type: none"> • Different user rights for each group; each user belongs to a specific group. • User rights cannot exceed Group rights.
Storage	<ul style="list-style-type: none"> • Supports central server backup that follows your configuration and setup in Alarm or Schedule settings. • Supports recording through the Internet. The recorded files are stored on the client's PC. • Supports network storage, such as FTP.
Alarm	<ul style="list-style-type: none"> • Responds to external alarms almost instantly (within 200 milliseconds), based on your pre-defined relay setup. You can also configure a visual and/or noise prompt (if supported by a pre-recorded noise) upon alarm detection. • Supports central alarm server setup, so that alarm information can automatically and remotely notify users. The alarm input can be derived from various connected peripheral devices.
Network Monitor	<ul style="list-style-type: none"> • The NVR supports the transmission of audio/video data that is compressed by an IP camera, which is then decoded for display. The delay time is less than 500 ms (sufficient network bandwidth support is required). • Supports a maximum of 10 connections. • Compatible to broadcast audio/video with the following transmission protocols: HTTP, TCP, UDP, MULTICAST, RTP/RTCP. • Transmits some alarm data or alarm information through SMTP. • Supports Internet access through the WAN.
Window Split	<ul style="list-style-type: none"> • Video compression plus a digital process allows the NVR to split the monitor screen to show four video channels at the same time.
Recording	<ul style="list-style-type: none"> • Supports a schedule for recording. The recorded files can be saved in the HDD, on the client's PC, or on a network storage server. You can search and view the recorded video that is stored locally or through the Internet connection.
Backup	<ul style="list-style-type: none"> • Supports backing up video, through the network, to a USB 2.0 device. The recorded files can be saved on the network storage server, on a peripheral USB 2.0 device, or to a burner, for example.

Table 1-1 Performance Series Network Video Recorder Features

Category	Features
Network Management	<ul style="list-style-type: none"> • Supports NVR configuration and management through the Ethernet. • Supports device management through the Internet.
Peripheral Equipment Management	<ul style="list-style-type: none"> • Supports peripheral equipment management such as protocol setup and port connection. • Supports transparent data transmission such as RS232 (RS-422) and RS485 (RS-485).
Auxiliary	<ul style="list-style-type: none"> • Supports switching between NTSC and PAL. • Supports viewing real-time system resources information and running statistics display. • Supports log file. • Supports local GUI output and shortcut menu operation with a computer mouse. • Supports IR control using shortcut menu operation with a computer mouse. • Supports IP camera remote video preview and control.

Network Video Recorder Components

For NVR specifications, please see [Appendix G](#) on [page 229](#).

Figure 1-1 NVR Front Panel**Table 1-2NVR Front Panel Components**




Component Name	Icon	Function
Power Button		Power button. Press this button for three seconds to boot up or shut down the NVR.
IR Receiver		Receives the signal from the remote control.
Shift	SHIFT	<ul style="list-style-type: none"> • When the cursor is in a textbox, click this button to switch between numbers and letters (lower case/upper case). • Enable/disable a tour.

Table 1-2NVR Front Panel Components

Component Name	Icon	Function
Assistant	Fn	<ul style="list-style-type: none"> • Single window monitor mode: Click this button to display the Assistant function; to start PTZ control (not supported); and to configure the image color. • Backspace function: When entering letters or numbers, press and hold for 1.5 seconds to delete the last-entered character. • Motion detection: Use in conjunction with the direction keys. • Text mode: When entering characters, click to switch between numbers and letters (uppercase/lowercase). • HDD management: Click to switch the HDD recording information and other information. (Menu prompt.) • Other special functions.
Play Previous	◀	In playback mode, play the previous video.
Play Next	▶	In playback mode, play the next video.
Slow Play	▶	Click to adjust the playback speed. Various slow playback speeds are available.
Fast Play	▶▶	Click to adjust the playback speed. Various fast playback speeds are available.
Reverse/Pause	◀	<ul style="list-style-type: none"> • Normal playback: Click to reverse playback. • Reverse playback: Click to pause playback.
Play/Pause	▶	<ul style="list-style-type: none"> • Reverse playback or pause mode: Click to return to normal playback mode. • Normal playback: Click to pause playback. • Pause mode: Click to resume playback. • Real-time monitor mode: Click to enter the Search interface.
ESC	ESC	<ul style="list-style-type: none"> • Go to the previous menu or cancel the current operation. • Playback: Click to go back to the real-time monitor mode.
Up/Down	▲ ▼	<ul style="list-style-type: none"> • Activate the current control, modify setup, and then move up and/or down. • Increase or decrease the current number. • Assistant function such as the PTZ menu (not supported).
Left/Right	◀ ▶	<ul style="list-style-type: none"> • Shift the currently active control, then move left or right. • Playback mode: Click to control the playback bar.

Table 1-2NVR Front Panel Components

Component Name	Icon	Function
Enter	ENTER	<ul style="list-style-type: none"> Confirm the current operation. Go to the Default button. Go to the Menu.
USB 2.0 Port		Connect to a USB 2.0 storage device, USB 2.0 mouse or CD/DVD burner.
HDD Abnormal Indication Light	HDD	Lights RED to indicate an HDD error or when the HDD capacity is below the specified threshold.
Network Abnormal Indication Light	Net	Lights RED to indicate that a network error has occurred or that there is no network connection.

Note The 8-/16-channel NVR is shown in this User Guide.

Figure 1-2 NVR Back Panel




Table 1-3NVR Back Panel Components






Icon/Marker	Port/Component Name	Connection	Function
	USB 2.0 Port		Connect a USB 2.0 mouse.
	Network Port		10 M / 100 M / 1000 Mbps self-adaptive Ethernet port. Connect to a network cable.
RS232 (RS-422)	232 Debug COM		For general COM debugging, to configure the IP address or to transfer transparent COM data.
HDMI	High Definition Media Interface		High definition audio and video signal output port. It transmits uncompressed high-definition video and multiple-channel data to the display device's HDMI port.
VGA	VGA Video Output Port	VGA	VGA video output port. Outputs the analog video signal. It can connect to the monitor for viewing analog video.


Table 1-3NVR Back Panel Components

Icon/Marker	Port/Component Name	Connection	Function
1-4	Alarm Input Port	I/O Port	<ul style="list-style-type: none"> Receives the signals from the external alarm sources. Two types: NO (normally open), NC (normally closed). When your alarm input device is using external power, please make sure the device and the NVR have the same ground.
	Alarm Input Port Ground End		Alarm input ground end.
NO1 to NO3 C1 to C3	3-channel Alarm Output Port		<ul style="list-style-type: none"> Three groups of alarm output ports. (Group 1: port NO1 ~ C1; Group 2: port NO2 ~ C2; Group 3: port NO3 ~ C3). Output alarm signal to the alarm device. Please make sure there is power to the external alarm device. NO: Normally open alarm output port. C: Alarm output public end.
	Power Input Port		Input 12 V DC.
Power Button			Power On/Off button.
PoE Ports			The built-in switch supports PoE function. It also supports up to 48 V / 50 W.
	Power Input Port		Switch power port. Input 48 V DC.
VIDEO OUT	Video Output Port		CVBS output.
MIC IN	Audio Input Port		Bi-directional communication input port. It receives the analog audio signal output from devices such as a microphone pickup.
MIC OUT	Audio Output Port		<p>Audio output port. It outputs the analog audio signal to devices such as an alarm.</p> <ul style="list-style-type: none"> Bi-directional communication output. Audio output on a 1-window video monitor. Audio output on a 1-window video playback.

USB 2.0 Mouse Components and Functions


Single-click the Left Mouse Button

Table 1-4 Single-click Left Mouse Button Functions

View menu content when you have selected a menu item.	
Modify a checkbox or motion detection status.	
Pop up a dropdown list.	
Input box: Select an input method for an input box. Left-click the corresponding button on the panel to enter a number or letter (uppercase/lowercase). In this mode, ← is the backspace button, and _ is the space button.	
English input mode: ← is the "delete previous character" button, and _ is the backspace space button.	
Number input mode: ← is the "delete previous number" button, and _ is the clear button.	

Double-click the Left Mouse Button

Table 1-5 Double-click Left Mouse Button Functions


Start a special control operation such as double-clicking an item in the file list to play the video.	
Multiple window view mode: Double click the left mouse button on one channel to view it in full window mode. Double click the window again to go back to the previous multiple window view again.	

Single-click the Right Mouse Button

Table 1-6 Single-click Right Mouse Button Functions

When in real time monitoring mode, single-clicking the right mouse button opens the popup shortcut menu.

Click to exit the currently open menu without saving any changes.



Click the Mouse Wheel

Table 1-7 Mouse Wheel Functions

Number input mode: Increase or decrease the number's value.

Enable/disable a check box.

Page up or down.



Other Mouse Functions

- Move the mouse to select the current control or move control.
- Define a motion detection zone.
- Define a privacy mask zone.

2

Installation

This chapter includes:

- An overview of connections for alarms and bi-directional communication.
- Instructions for HDD installation.
- Network connections.

Alarm Connection

1. Connect the alarm input device to the alarm input port.
2. Connect the alarm output device to the alarm output port. The NO and NC alarm output device can connect to the NO/C/NC port.
 - For the NO alarm device, please connect to the NO/C ports.
 - For the NC alarm device, please connect to the NC/C ports.

Note The NO/C ports are for NO alarm devices only.

Alarm Configuration

1. Open the web client, login, and go to the **Alarm** setup interface to set the alarm input and output ([Configuring Alarms on page 93](#)). The alarm setting **01** corresponds to the device's first channel I/O port (and so on).
2. Set the NO/NC type according to the high/low level the alarm input device generates when an alarm occurred. See [Figure 3-54 on page 94](#).
3. Set the alarm output on the web client. See [Configuring Alarm Output on page 121](#). The alarm output setting **01** corresponds to the first group of the alarm output port.

Bi-Directional Communication Connection

Audio Output Device to a PC

Connect:

1. Connect a speaker or pickup to the first audio input port on the NVR's rear panel.
2. Connect the earphone or the sound box to the audio output port on your PC.
3. Open the web client and log in.
4. Enable the desired channel in the web client's live view monitor.


Figure 2-3 Enabling Bi-Directional Communication



Configuring to Hear Audio From the NVR

At the NVR end, speak through the microphone or the pickup. Then you can get the audio from the speaker or earphone from the PC end.

Figure 2-4 Configuring to Hear from the NVR



PC to an Audio Input Device


Connect:

1. Connect the microphone or the pickup to the audio output port in the PC
2. Connect the earphone or the sound box to the audio output port on your PC.
3. Open web client and log in.
4. Enable the desired channel in the web client's live view monitor.
5. See [Figure 2-3](#) for enabling bi-directional communication.

Configuring to Hear Audio from the PC

At the PC end, speak through the microphone or the pickup. Then you can get the audio from the speaker or earphone from the NVR.

Figure 2-5 Configuring to Hear from the PC



Hard Disk Drive Installation

CAUTION Disconnect power if your NVR is connected to a power source.

Note The images in this section are for reference only. Your hard disk drive might be different from the one shown.

Hard Disk Drive Recommendations

- See [Compatible SATA HDD on page 225](#) for a list of recommended Hard Disk Drive (HDD) brands and models.
- Please use a HDD of 7200 rpm or higher.
- Do not use a PC HDD.

Installing a HDD

1. Loosen the screws on the upper cover and side panel of the NVR.

Figure 2-6 Removing the NVR Cover



2. Loosen four screws in the HDD.

Figure 2-7 Loosening the Four Screws in the HDD Housing



3. Align the HDD with the four holes in the bottom of the NVR housing.

Figure 2-8 Placing the HDD



4. Turn the NVR upside down, and then turn the screws to firmly attach the HDD to the NVR housing.

Figure 2-9 Securing the HDD to the NVR Housing



5. Connect the HDD cable and power cable.

Figure 2-10 Connecting the HDD and the Power Cable



6. Replace the NVR cover.

Figure 2-11 Replacing the NVR Cover



7. Secure the NVR cover in place by turning the screws in the rear and side panels.


Figure 2-12 Securing the NVR Cover



Network Connection

Follow this diagram to connect your NVR to the network.

Figure 2-13 Network Connections



3

NVR Configurations

This chapter includes:

- Logging into the NVR.
- An overview of the NVR GUI, including live viewing, searching, and playing back.
- Instructions on configuring the NVR.

Logging In to Your NVR

Before you can open the GUI for your NVR, you must do the following:

1. Connect your NVR to a monitor.
2. Connect the mouse and power cable to the NVR.
3. Click the power button on the NVR's rear panel to turn on the NVR.

The NVR will boot up and you will see the GUI, which is in multiple-channel display mode, and the default mode.

Figure 3-1 Multiple-channel Display Mode



Use the mouse to navigate and enter.

Each channel displays its channel recording and alarm status information.

Table 3-1 Channel Recording and Alarm Status Icons

Icon	Status	Icon	Status
	Recording status		Video loss
	Motion detection		Camera lock

Logging In and Setting Up with the Startup Wizard


The **Startup Wizard** appears after the NVR has powered up.

Figure 3-2 Startup Wizard



1. Click **Next Step** to open the **System Login** window.

Figure 3-3 System Login Window



2. Click to select the **Password** field. An electronic keyboard appears.

Figure 3-4 Electronic Keyboard



3. Enter a password by using the mouse to select characters on the GUI keyboard.
Click to **123** switch between numbers, letters (uppercase/lowercase), and punctuation/symbols.

The NVR has four default accounts.

Table 3-2 Default Accounts

Username	Password	Profile
admin	1234	Administrator; local; network
888888	888888	Administrator, local only
666666	666666	Lower authority user who can only monitor live and video, play back, backup video
default	default	Hidden user

4. Click **Enter** on the electronic keyboard, and then **OK** on the login window.
The **General** window appears.

Figure 3-5 General Window

The screenshot shows the Honeywell NVR General Window configuration interface. The window is titled "GENERAL" and contains the following settings:

- System Time:** 2014 - 07 - 04 | 14 : 15 : 37 (with a Save button)
- Basic Settings:**
 - Date Format: YYYY MM DD (dropdown)
 - Date Separator: - (dropdown)
 - Time Format: 24-HOUR (dropdown)
 - DST: (checkbox) with a Set button
- Device Settings:**
 - Language: ENGLISH (dropdown)
 - Video Standard: NTSC (dropdown)
 - Device No.: 8 (text input)
 - Device ID: NVR (text input)
 - HDD Full: Overwrite (dropdown)
 - Pack Duration: 60 min. (text input)
 - Realtime Play: 5 min. (text input)
- Other Settings:**
 - Holiday: (checkbox) with a Setup button
 - Navigation: (checkbox)
 - Mouse Property: MouseSet (dropdown)
 - Auto Logout: 10 min. (text input)
 - IPC Time Sync: 1 Hours (text input)


At the bottom of the window, there are four buttons: Default, Pre Step, Next Step (highlighted in orange), and Cancel.

5. Enter the **System Time**, select the **Language** and **Video Standard**, and then click **Next Step**.

The **Network** configuration window appears.


Note The NVR reboots after you configure the language.

Figure 3-6 Network Configuration Window



6. Configure the network settings as either fixed (enter an **IP Address**, **Subnet Mask**, and **Gateway**) or DHCP (click to select **DHCP**).
7. Click **Next Step**. The **Remote Device** configuration window appears.

Figure 3-7 Remote Device Configuration Window




8. Click to select the cameras you want to add, and the NVR automatically adds the IP cameras that are connected to the PoE ports. These added cameras appear in the **Added Device** table in [Figure 3-7](#).
9. Click **Next Step**, and the **Schedule** configuration window appears.

Figure 3-8 Schedule Configuration Window



10. Configure the schedule rules for recording. Select the **Channel**, **Period** (day and time), and **Type** (**Regular**, **Motion Detection**, **Alarm**, and **Motion&Alarm**) for scheduled recording.
11. Click **Finished** to finish the setup wizard. A message appears.

Figure 3-9 Configuration Wizard Message



12. Click **OK** to close the **Startup Wizard**.

Opening the Main Menu

1. Right-click anywhere on the GUI, and a menu appears.

Figure 3-10 Right-click Menu

2. Click to select **Main Menu**, and the **Main Menu** appears.

Figure 3-11 Main Menu

Live View

Preview Control

With the preview control, you can do the following:

Preview Playback

- While in the preview desktop, the NVR can play back the previous 5 to 60 minutes of recorded video from the current channel. Go to the **Main Menu > Setting > General** to configure the real-time playback settings. See [Configuring the General Settings on page 63](#).
- Supports drag-and-play function. You can use your mouse to select any playback start time.
- Supports playback, pause, and exit functions.
- Will support slow playback (both forward and reverse) in the future.

Digital Zoom

Real-time Backup

Preview Control Interface

Move the mouse to the top center of the current channel's video, and the preview control interface appears.

Figure 3-12 Preview Control Interface



If your mouse hovers in this position for more than 6 seconds without any further action, the control bar automatically disappears.

Table 3-3 Preview Controls












Icon	Name	Function
	Real-time playback	<p>Click to play back the previous 5 to 60 minutes of recorded video from the current channel.</p> <p>Go to the Main Menu > Setting > General to configure the real-time playback settings. See Configuring the General Settings on page 63.</p> <p>You might see a popup window if there is no video recorded for the current channel.</p>
	Digital zoom	<p>Click to digitally zoom on a specific area of live video for the current channel. You can also use digital zoom on multiple channels or in multiple-channel view.</p> <p>This icon  indicates the area of video that is enlarged; this icon  indicates the "free" area.</p>
	Real-time backup	<p>Use to back up video from the current channel to a USB 2.0 device. The NVR can not back up video from multiple channels at the same time.</p> <p>This icon  indicates the currently selected backup channel. This icon  indicates a free channel. This icon  indicates a free channel when the backup procedure has begun.</p>

Table 3-3 Preview Controls

Icon	Name	Function
	Manual snapshot	Click to manually take a snapshot of the current live video.
	Remote device add shortcut	Click to open the remote device connection interface.
	Bi-directional talk	Click to begin bi-directional communication with the front-end device (camera).

Playback Control

The **Playback Control** supports play, pause, exit, and drag time line functions.


While playing back video, you can not see the channel title and recording status for the current channel. The channel title and recording status reappear after you leave the playback mode.

While playing back video, you can not change channels or change the current display mode or configuration.

Note The Tour function has higher priority than Preview Playback. The NVR automatically exits Preview Playback and its interface when a Tour is started. You can not control Preview Playback until the Tour has ended.

Right-Click Menu

After you have logged in to the NVR, right-click the mouse and the right-cut menu appears.

Figure 3-13 Right-cut Menu

Main Menu

After you have logged in to the NVR, the NVR's main menu appears.

Figure 3-14 Main Menu



Search and Playback


Click  to open the **Search** interface.

Figure 3-15 Search Interface




Table 3-4 Search GUI

Number	Name	Function
1	Display Window	View the found video or snapshot. Supports 1/4/8-window playback.
2	Search Type	Search for recorded video or a saved snapshot. Select to play from the read-write HDD, from a peripheral device, or from a redundancy HDD. Before you can play video from a peripheral device, please remember to connect to that device. You can view all of the recorded files on the root directory of that peripheral device. Click Browse to find and select the file you want to play. Note The redundancy HDD does not support snapshot backup. It supports picture playback. You can select to play from the redundancy HDD if there are snapshots saved to the redundancy HDD.
3	Calendar	If the date is highlighted in orange, that means that there is a picture or file recorded for that date. While in any playback mode, click on the date you want to see. You will see the recorded file that corresponds with that date on the time bar.
4	Playback Mode and Channel Selection Pane	Playback mode: <ul style="list-style-type: none"> • 1/4/8/9 channels for 8-channel NVRs • 1/4/8/9/16 channels for 16-channel NVRs In the single-window playback mode, you can select one channel from the 8 or 16 (depending on your model) available. In the multiple-channel playback modes, you can select whatever four channels you require. The time bar changes when you modify the playback mode or the channel option.

Table 3-4 Search GUI







Number	Name	Function
5	File List Switch Button	<p>Double-click to view the snapshot/recorded file for the currently selected day.</p> <p>The file displays the recorded file for the first channel.</p> <p>The system can display up to 128 files at a time. Use the ▲/▼ or the mouse to select the file. Select a file, then double-click the mouse or click ENTER to begin playback.</p> <p>Use the following interface for entering a time period to search for recorded video or a snapshot.</p>  <p>File types: R=regular recording; A=external alarm recording; M=motion detection recording.</p> <p>Lock file: Click the file you want to lock, then click  to lock the file.</p> <p>Search locked file: Click  to view the locked file.</p> <p>Return: Click  to return to the calendar and channel setup interface.</p> <p>Note The system can lock up to 16 files. The size of the locked file must be less than 25% of the HDD total space. The first 16 G of each partition cannot be locked.</p> <p>The system can lock only one file at a time, and cannot lock the extra streaming file. You cannot lock a file that is currently writing or overwriting.</p>
6	Card Number Search	
7	Playback Control Panel	See Table 3-5 on page 52 for more about the Playback Control interface.
8	Time Bar	<p>Displays the recording type and its period in the current search criteria.</p> <p>In the 4-channel playback mode, there are four corresponding time bars. In the single-channel playback mode, there is only one time bar.</p> <p>Use the mouse to click and select a color zone in the time bar for playback. The NVR starts playing that recorded video.</p> <p>The time bar begins at 00:00 when you are setting the configuration. The time bar displays the time period for the video that is playing, plus a range of time before and after.</p> <p>Green=regular recorded file; Red=external alarm recorded file; Yellow=motion detection recorded file.</p>

Table 3-4 Search GUI

Number	Name	Function
9	Time Bar Unit	<p>Select from: 24H, 12H, 1H, and 30M. The smaller the unit, the more magnified the time bar. The time bar allows you to select a more accurate time for playback.</p> <p>The time bar begins at 00:00 when you are setting the configuration. The time bar displays the time period for the video that is playing, plus a range of time before and after.</p>
10	Backup	<ol style="list-style-type: none"> 1. From the File list, select the file(s) that you want to back up. The system allows you to select up to four channels. 2. Click the Backup button. The Backup menu appears. 3. Click Start to begin backing up the file(s). <p>Check the file again to cancel the current selection.</p> <p>The NVR can display up to 32 files from one channel.</p>
11	Clip	<p>The Clip button is used to edit files.</p> <ol style="list-style-type: none"> 1. While playing the file you want to edit, click Clip when you want to edit that file. A slide bar appears that corresponds to the channel for the recorded video. 2. Adjust the time slide bar or enter a specific time for the recorded file end time. 3. Click Clip again, and then save the current file as a new file.
12	Record Type	While in any playback mode, the time bar changes if you modify the Search type.
OTHER FUNCTIONS		
14	Other Channel Synchronization Switch to Play When Playing Back	When playing a video file, click a channel number button to switch to video from another channel that was recorded at that time.
15	Digital Zoom	<ol style="list-style-type: none"> 1. When in full-screen playback, left-click your mouse on the screen. 2. Drag your mouse across the screen to select a region, then left-click the mouse to open Digital Zoom. <p>Right-click your mouse to exit Digital Zoom.</p>
16	Manually Switch Channel When Playing Back	<p>When in full-screen playback, you can switch to another channel either by using the drop-down list or by scrolling your mouse.</p> <p>This function is not available if there is no recorded file or if the NVR is conducting a Smart Search.</p>

Figure 3-16 Card Number Search Interface**Table 3-5 Playback Controls**


Button	Name	Function
	Play/Pause	<p>There are three ways to begin playback:</p> <ul style="list-style-type: none"> Click , the play button. Double-click a time on the time bar. Double-click a file in the file list. <p>In Slow Play mode, click to switch between Play and Pause.</p>
	Stop	
	Reverse Play	<p>In Normal Play mode, click to begin playback in reverse.</p> <p>Click it again to pause the current playback.</p> <p>In reverse Playback mode, click to return to Normal Playback.</p>
		<p>In Playback mode, click to play the next or previous section or file. You can click continuously when you are watching files from the same channel.</p> <p>In Normal Play mode, when you pause the currently playing file, click to begin Frame-by-frame Playback.</p> <p>In frame-by-frame playback, click to return to Normal Playback.</p>
	Slow Play	<p>In Playback Mode, click to start Slow Playback. Click again to adjust the slow playback speed.</p>
	Fast Forward	<p>In Playback mode, click to start Fast Forward Playback. Click again to adjust the fast forward playback speed.</p>
Note The actual playback speed is affected by the software version.		
	Volume	Adjust the volume of the playback video.
	Snapshot Button	<p>Click in the full-screen mode, and the NVR takes one snapshot per second.</p> <p>You can configure the save path for snapshots. If you want to save to a peripheral device:</p> <ol style="list-style-type: none"> 1. Insert a USB memory stick into the NVR. 2. Playback the desired video in full-screen mode (double-click the playback video to enter full-screen mode). 3. Click in the full-screen mode to create the snapshot and save it to the USB storage device.

Information

You can view the following information on the Information tab:

- HDD INFO (hard disk information)
- BPS (data stream statistics)
- Log
- Version
- Online Users
- Remote Device
- Network

Figure 3-17 Information Tab



HDD Information

Figure 3-18 HDD Information Tab



This page shows the hard disk type, the total space, the free/available space, and the status of the HDD. You can have up to two HDDs.

Table 3-6 HDD Drive Status Symbols

Symbol	Meaning
o	The currently selected HDD is normal.
-	There is no HDD.
?	The disk is damaged.

Note If the disk is damaged, you will see ? in the Status column. Remove the broken disk before adding a new one.

Viewing the HDD Recording Time Information

Click **View recording time** in the **HDD INFO** interface. The HDD recording time interface for the selected HDD appears.

Figure 3-19 HDD Recording Time Information Interface




Table 3-7 HDD Recording Time Information

Parameter	Function
SATA	You can connect up to two HDDs, which are shown here. When the connected HDD is working properly, you see o . When there is no HDD, you see - .
SN	View the size of the HDD drive that is connected to your NVR. When the second HDD is the currently working HDD, you see * .
Type	The type of the connected HDD.
Total Space	The total capacity of the connected HDD.
Free Space	The total free capacity of the connected HDD.
Status	Indicates if the HDD is working correctly or not.
Bad Track	Indicates that there is a bad track.
Page Up	Click to view the previous page.
Page Down	Click to view the next page.
View Recording Time	Click to view the HDD recording information, such as the file start time and file end time.
View HDD Type and Capacity	Click to view the HDD properties such as status, type, total space, free space, and S.M.A.R.T.

BPS



Click **BPS** in the **INFO** tab to open the **BPS** interface.

Figure 3-20 BPS Interface



The screenshot shows the Honeywell BPS interface. At the top, the Honeywell logo is visible. Below it, the 'BPS' tab is selected. The main area contains a table with the following data:

Channel	Kb/S	MB/H	Wave
1	3903	2049	100%
2	0	0	100%
3	0	0	100%
4	0	0	100%
5	0	0	100%
6	0	0	100%
7	0	0	100%
8	0	0	100%
9	0	0	100%
10	0	0	100%
11	0	0	100%
12	0	0	100%
13	0	0	100%
14	0	0	100%
15	0	0	100%
16	0	0	100%

View the current video data stream (in KB/s) and the stored hard disk storage (MB/h).


Log



Click **LOG** in the **INFO** tab to open the **LOG** interface.

The **LOG** tab displays system log information.

Figure 3-21 Log Tab



Log types: Select from **All**, **System operation**, **Configuration operation**, **Data management**, **Alarm event**, **Recording operation**, and **Log clear**.

Start/End Time: Select the Start and End time for the log search, then click **Search**.

Backup: Select the folder you want to save, then click **Backup** to save the log file. When the file has been saved, the folder is named **Log_time** on the save path. Double-click the folder to see the file.

Details: Click the **Details** button or double-click the log item to view detailed information about that file.

Figure 3-22 Detailed Information About a Log File




Use the rolling bar at the bottom to scroll through information about the file. Use **Previous/Next** to view other log information. For alarm events such as video loss, you can click the **Playback** button at the bottom right corner to play the alarm event-recorded video.

Version



Click **VERSION** in the **INFO** tab to open the **VERSION** interface.

Figure 3-23 Version Tab



On the **Version** tab, you can see the following information about your NVR:

- The channel
- Alarm in
- Alarm out
- System version
- Build date
- Web client software build number
- Serial number

Online Users



Click **ONLINE USERS** in the **INFO** tab to open the **ONLINE USERS** interface.


On the **Online Users** interface, you can see the users who are connected to the local NVR.

Figure 3-24 Online Users Tab



On this tab, you can disconnect or block a user, if you have Administrator rights.


Remote Device Information Tab

Click **REMOTE DEVICE**  in the **INFO** tab to open the **REMOTE DEVICE** interface.

On this tab, you can view the channel status of the remote device, the connection log, etc.


Channel Status: View the IP camera (IPC) status for the corresponding channel, such as motion detection, video loss, camera masking, and alarms.

Figure 3-25 Channel/Device Status



Connection Log: Search the IP camera log information for the corresponding channel. This includes the IP cameras that are online and offline.

Figure 3-26 Connection Log



The screenshot shows a web interface for viewing connection logs. At the top, there is a search filter with a dropdown menu set to 'All', a 'Start Time' field set to '2014 - 03 - 04 | 00 : 00 : 00', and an 'End Time' field set to '2014 - 03 - 05 | 00 : 00 : 00'. A 'Search' button is located to the right of the end time field. Below the search fields is a table with the following data:

9	channel	Time	IP Address	Connection
1	3	2014-03-04 06:26:28	10.1.1.67	User logged in
2	3	2014-03-04 06:29:10	10.1.1.67	User logged out
3	3	2014-03-04 06:29:14	10.1.1.67	User logged in
4	3	2014-03-04 06:51:38	10.1.1.67	User logged in
5	3	2014-03-04 06:55:30	10.1.1.67	User logged out
6	3	2014-03-04 06:55:57	10.1.1.67	User logged in
7	3	2014-03-04 07:29:14	10.1.1.67	User logged out
8	3	2014-03-04 07:29:17	10.1.1.67	User logged in
9	3	2014-03-04 07:31:43	10.1.1.67	User logged in

Network Information

Click **NETWORK**  in the **INFO** tab to open the **NETWORK** interface.

In the **Network Test** tab, you can test your network connection, and see the average delay and packet loss rate. In the **Network Load** tab, you can see the network information for all connected network adapters, including connection status, send rate, and receive rate.

Network Test Tab

Figure 3-27 Network Test Tab

Enter the IP address

Name	IP	Sniffer Packet Size	Sniffer Packet
LAN1	192.168.1.108	0KB	
LAN2	10.1.1.1	0KB	

Network Test

1. Enter an IP address in the Destination Ad field.
2. Click **Test**.

The test results will show if the network connection is good, as well as the average delay and packet loss rate.

Network Sniffer Packet Backup

1. Insert a USB 2.0 device into the USB port on the front panel of your NVR. See [Figure 1-1](#) on [page 27](#).
2. Click **Refresh**, then find your USB 2.0 device in the **Device Name** field. See [Figure 3-27](#). You might need to use the drop-down menu to find your device.
3. Click **Browse** to select the save path.
4. Click the **Begin Sniffer** button in the column on the right to start the **Sniffer**.

All connected adapter names appear in the found network adapters table. Adapter names can include Ethernet, PPPoE, WIFI, and 3G.

To stop the Sniffer, click the gray **Stop** button.

Note You can not Sniff several network adapters at the same time.

While the Sniffer is working in the background, you can perform other network operations, such as logging into the Web and monitoring. Click to stop the Sniffer and return to the Sniffer interface. The NVR/system will save the packets to the specified path. The file name is **Network adapter name+time**.

Opening the Packets Use software such as Wireshark to open the packets on the PC so that a professional engineer can solve the problem.

Network Load

Click the **NET LOAD** on the **Network Information** configuration interface.

View and follow the statistics for the device's network adapter.

Click to select a network adapter in the found network adapters table.

Figure 3-28 Network Load Interface



The flow statistics such as send rate and receive rate appear in the top panel.

Settings

In the **Main Menu**, highlight the **Setting** icon, and double-click your mouse. The **Setting** interface appears.

Figure 3-29 Setting Interface

Note You need to have the proper rights to configure the Settings.

Configuring the General Settings


Click the **GENERAL** icon  to open the General Settings interface.

Figure 3-30 General Settings Interface

Table 3-8 General Settings

Setting	Description
System time	Configure the system time.
Date format	Select from three formats: YYYY-MM-DD , MM-DD-YYYY , or DD-MM-YYYY .
Date separation format	Select from three formats: dot (.), hyphen (-), or slash (/).
Daylight Saving Time (DST)	Configure the DST time and date.

1. Enable DST, then click **Set**. The DST interface appears.

2. Configure the **Start** time and **End** time by either configuring the Week setup, as shown above. Or by configuring the date setup, as shown below.

3. Click **OK** to save the new settings.

Table 3-8 General Settings

Setting	Description
Time format	Select from either 24-hour mode or 12-hour mode.
Language	Your NVR supports 12 languages: Arabic, Czechoslovakian, Dutch, English, French, German, Italian, Polish, Portuguese, Russian, Spanish, and Turkish.
HDD full setting	Configure what happens when the HDD is full. Select from Stop Recording and Rewrite . Stop Recording: If the currently working HDD is overwritten or is full while the next HDD is not empty, then the system stops recording. Rewrite: If the currently working HDD is full and the next HDD is not empty, then the system overwrites the files saved on the HDD.
Pack duration	Configure how long the NVR records. Select from 60 to 120 minutes. The default is 60 minutes.
Device No.	Used when you are using one remote control to control several NVRs. Assign a device number for each NVR.
Video standard	Select from NTSC or PAL .
Realtime play	Configure the playback time for Preview. Select from 5 to 60 minutes.
Device ID	Enter a device name.
Holiday setting	Click Setup on the General setting interface to open the Holiday Setting interface.




Go to the **Holidays Period** interface to set the holiday recording setup. See [Holiday Settings on page 194](#).

Note When you enable Holiday settings and a schedule at the same time, the Holiday settings has priority. This means that if a selected day is a holiday, then the NVR follows the holiday setting and ignores the schedule setting. But if the selected day is not a holiday, then the NVR follows the schedule setting. See [Holiday Settings on page 194](#).

Note There is no year setup on the Holiday setting. This might be confusing for holidays that do not fall on the same date each year. For example, if you set a holiday for October 30, 2014, October 30th will be considered a holiday for every year after.

Table 3-8 General Settings

Setting	Description
Mouse properties	<p>Click MouseSet to open the mouse setup interface.</p>  <p>You can configure the mouse double-click speed. Click Default to restore the mouse settings to the default setup.</p>
Startup wizard	If you check to enable the Startup wizard, then the next time the NVR restarts, it will open to the Startup wizard. If you do not check to enable the Startup wizard, the NVR opens to the login interface.
Auto logout	Configure how long the user can be inactive before the NVR automatically logs out the inactive user. Select from 0 to 60 minutes.
Navigation bar	Check to enable the navigation bar, and it appears on the GUI.
IPC Time Sync	Configure an interval for synchronizing the NVR's time with the IP camera time.

Configuring the Encoding Settings


Click the **Encode** icon  in the **Setting** interface to open the **Encode** interface.

Figure 3-31 Encode Interface

The screenshot shows the Honeywell ENCODE interface with the following settings:

- Channel: 1
- Type: Regular (Mainstream) and Extra Stream 1
- Compression: H.264
- Resolution: 1920x1080(1080i) and 352x240(CIF)
- Frame Rate(FPS): 30
- Bit Rate Type: CBR
- Bit Rate(Kb/S): 4096 (Mainstream) and 1024 (Extra Stream 1)
- Audio/Video:

Buttons: Overlay, SNAPSHOT, Copy, OK, Cancel

Table 3-9 Encode Configurations

Setting	Description
Channel	Select a channel.
Type	Select an encoding type from the drop-down list. Select from: Regular , Motion Detect , and Alarm . You can select the various encoding parameters for the different recording types.
Compression	The NVR supports H.264 , MPEG4 , and MJPEG .
Resolution	The mainstream resolution type is IP camera's encoding configuration. Select from 1080p , 720p , D1 , SXGA , 1280x960 .
Frame Rate	Select from 1 f/s to 25 f/s in NTSC mode; 1 f/s to 30 f/s in PAL mode.
Bit Rate Type	Select from CBR and VBR . If you select VBR , then you can configure the video quality.
Bit Rate	Select from 4096 , 6144 , 8192 , or customize the Bit Rate setting. If you choose Customize , you must enter a bit rate value.
Audio/video	Enable or disable the audio/video.

Table 3-9 Encode Configurations

Setting	Description
---------	-------------

Overlay Click **Overlay** to open the **Overlay** interface.





Cover area (privacy mask): Configure the privacy mask to block certain areas of the video. Drag the mouse to select the area. When in 1-channel mode, the NVR supports up to 4 privacy mask zones.

Preview/monitor: The privacy masks have two types: **Preview** and **Monitor**. If you select **Preview** for a privacy mask zone, then when the NVR is in Preview status, the privacy mask zone can not be viewed by users. If you select **Monitor** for a privacy mask zone, then when the NVR is in Monitor status, the privacy mask zone can not be viewed by users.

Time display: Select whether the NVR displays the time during playback. Click **Set**, and then drag the time display to the desired position on the video.

Channel display: Select whether the NVR displays the channel during playback. Click **Set**, and then drag the channel display to the desired position on the video.

Table 3-9 Encode Configurations

Setting	Description
Snapshot	<p>Click SNAPSHOT in the General settings interface to open the SNAPSHOT interface.</p>  <p>Media: Choose from Timing or Trigger. If you choose Timing, then the snapshot is taken according to a scheduled time. If you choose Trigger, then the snapshot is taken in response to an internal and/or external alarm trigger.</p> <p>Image Size: Choose an image size.</p> <p>Image Quality: Choose from 1 to 6. The higher the number, the higher the quality of the snapshot.</p> <p>Snapshot Frequency: Choose from 1 to 7 SPP (seconds per picture).</p>
Copy	<p>After you have finished configuring the current channel, you can click Copy to copy the current setup to other channels.</p>  <p>The currently selected channel is in gray. Click to select channels to which you want to copy the setup, or click to select All. Click OK twice (once in the Copy interface, once in the Encode interface) to save the settings and complete the setup.</p>

Configuring the Schedule

Click the **Schedule** icon  in the **Setting** interface to open the **Schedule** interface.

Figure 3-32 Schedule Interface



Table 3-10 Schedule Configurations

Parameter	Function
Channel	Select a channel number. Select All for all channels.
Week day	Select a day of the week, or All .
Pre-record	The NVR has a buffer that allows it to "record" video that happens before an event occurs. Select from 1 to 30 seconds, depending on the bit stream.
Redundancy	You can configure the NVR to backup recorded files onto two different HDDs. Click to enable. Note Before you can enable this function, you must configure at least one HDD as redundant. Go to Main Menu > Advanced > HDD Management . Note This function is not available if there is only one HDD.
Snapshot	Click to enable the Snapshot function, which takes a snapshot when an alarm occurs.
Record type	Select from: Regular , Motion Detection (MD) , Alarm , MD&Alarm .
Holiday	Click to enable the holiday settings you configured in the General interface. See Configuring the General Settings on page 63 .

Click the corresponding box to enable each function. Click **OK** to save the settings and return to the previous menu.

Note If you have configured the NVR to record when motion detection and alarms occur (**MD&Ala**), then the NVR will not record if it detects only motion detection or an alarm.


Quick Setup

The **Copy** button allows you to copy one channel's setup to other channels.

1. Click **Copy** after configuring a channel.

The **Copy** interface appears.

Figure 3-33 Copy Interface



The currently selected channel is highlighted in gray.

2. Click to select the channel or channels to which you want to copy the settings. Click **All** to select all channels.
3. Click **OK** in the **Copy** interface, then click **OK** again in the **Encode/Schedule** interface to complete the copy function.

Note If you select **All**, then the recording setup for all channels is the same, and then the Copy button disappears.

Configuring RS232

Click the **RS232** icon  in the **Setting** interface to open the **RS232** configuration interface.

RS232 Configuration Interface




Table 3-11 RS232 Configurations

Parameter	Function
Function	<p>Select from six devices.</p> <p>Console: Use the COM or mini-end software to upgrade or debug the program.</p> <p>Control Keyboard: Use the special keyboard to control the NVR.</p> <p>Transparent COM (adapter): Connect to the PC to directly transfer data.</p> <p>Protocol COM: Used for card overlay.</p> <p>Network Keyboard: Use the special keyboard to control the NVR.</p> <p>PTZ Matrix: Use to connect to the peripheral matrix control.</p> <p>The default setting is: Console.</p>
Baudrate	<p>Select an appropriate baud rate.</p> <p>The default setting is 115200.</p>
Data Bits	<p>Select an appropriate data bit. Select from 5 to 8.</p> <p>The default setting is 8.</p>
Stop Bits	<p>Select from: 1, 1.5, or 2.</p> <p>The default setting is 1.</p>
Parity	<p>Select from: None, Odd, Even, Space Mark.</p> <p>The default is N one.</p>

Click **Save** to save the new configuration. The NVR will return to the previous menu.

Configuring the Network


Click the **Network** icon  in the **Setting** interface to open the Network configuration interface.

Figure 3-34 Network Interface



Table 3-12 Network Configurations

Parameter	Function
IP Version	Select either IPv4 or IPv6 . Both formats are supported.
MAC Address	Each NVR gets a unique MAC address. You can use the MAC address to connect to the NVR in the LAN. The MAC address is not configurable; it is read-only.
IP Address	Use the Up/Down arrows (▲/▼) to select an IP address, or use the keyboard to enter an IP address. Then configure the corresponding subnet mask for the default gateway.
Subnet Prefix	Select from 0 to 128 . Used to mark a specified network MAC address.
Default Gateway	Enter the default gateway.
	Note The system needs to check the validity of all IPv6 addresses. The IP address and the default gateway must be in the same IP section. The specified length of the subnet prefix must have the same string.

Table 3-12 Network Configurations

Parameter	Function
DHCP	<p>Used to automatically search for the IP address. When the DHCP function is enabled, you can not modify the IP address, Subnet mask, or Gateway. If you have not enabled DHCP, the IP address, Subnet mask, and Gateway are all 0 by default.</p> <p>To view the current the IP information, you must turn off DHCP.</p> <p>You can not modify the IP address, Subnet mask, or Gateway if you are using PPPoE.</p>
TCP Port	Default is 37777 . This value is configurable.
UDP Port	Default is 37778 . This value is configurable.
HTTP Port	Default is 80 .
RTSP Port	Default is 554 .
Note	If you change and any of the above port settings, you must reboot your NVR to activate those saved settings. Please ensure that the these port settings do not conflict.
Max Connection	The NVR can support up to 20 users. 0 means that this NVR can not connect to any PC or other device.
MTU	<p>Configure the MTU value for the network adapter. Select from 1280 to 7200 bytes. The default is 1500 bytes.</p> <p>Note MTU modification can affect the current network service. Click OK to confirm a reboot, or click Cancel to cancel the modifications.</p> <p>Note Before configuring the MTU for the NVR, check the gateway's MTU. The NVR's MTU should be the same or lower than the MTU's gateway. This helps to reduce the number of packets and increases network transmission efficiency.</p>
MTU Values (reference only)	<p>1500: The Ethernet information packet maximum value. This is also the default value, especially where there is no PPPoE or VPN. This is also the default setup for some routers, switches, or the network adapter.</p> <p>1492: The recommended value for PPPoE.</p> <p>1468: The recommended value for DHCP.</p> <p>Please ensure that the MTU port does not conflict with other ports.</p>
Preferred DNS Server	Enter the preferred DNS server IP address.
Alternate DNS Server	Enter an alternate DNS server IP address.
Transfer Mode	Select a priority, either Fluency or Video Quality .
LAN Download	If you enable this function, the NVR can process the downloaded data first. Select a download speed, either 1.5x or 2.0x the normal speed.


Note For IPv6 IP addresses, the Default Gateway, Preferred DNS, and Alternate DNS should be a 128-digit number. Do not leave these fields blank.

You must click **Save** after configuring the Network. The system returns to the previous menu.

Configuring Network Settings

Click **NETWORK SETTING**  on the Network configuration interface. The **Network Setting** configuration interface opens.

Figure 3-35 Network Setting Configuration Interface



Click to enable a network setting configuration.

Double-click to a configuration window for each network setting configuration.

Configuring the IP Filter

Figure 3-36 IP Filter Configuration Interface

IP Start	IP End	Edit	Delete

You can add safe ID addresses which the NVR can safely access. You can add up to 64 IP addresses.

Note The NVR needs to check the validity of all IPv6 addresses.

If you enable **Trusted Sites**, then only the IP addresses that are listed can access the NVR. If you enabled **Blocked Sites**, then the listed IP addresses can not access the NVR.

Table 3-13 IP Filter Configurations

Parameter	Function
Enable	Click to enable either Trusted Sites or Blocked Sites . The Trusted Sites/Blocked Sites drop-down menu is available only if those functions have been enabled here.
Type	Select either Trusted Sites or Blocked Sites . When you select either Trusted Sites or Blocked Sites , the IP address list for that selection appears in the table.
IP Start address/IP End address	<ol style="list-style-type: none"> 1. Select a list Type. 2. Enter start and end IP addresses. 3. Click in the field, and enter the IP address. <ul style="list-style-type: none"> • Newly added IP addresses are enabled by default. Click to disable and remove the IP address from the list. • The NVR supports up to 64 IP addresses. • The NVR supports both IPv4 and IPv6 address formats. If you are using an IPv6 address, the NVR can optimize that address. For example, aa:0000: 00: 00aa: 00aa: 00aa: 00aa as aa:: aa: aa: aa: aa: aa: aa. • The NVR automatically removes spaces if there are spaces before or after the newly added IP address. • If you add an IP address, the NVR checks the start address only. If you add an IP address section, and the end address is greater than the start address, then the NVR check both the start and the end address. • The NVR checks if the newly added IP address exists. The NVR will not accept the new IP address if it does not exist.
Delete	Click to remove the selected item.
Edit	Click to edit the start address and/or the end address. After editing the IP address, the NVR can again check for the new IP address' validity, and implement IPv6 optimization.

Configuring the NTP Setup

Before you can use NTP, you must first install an SNTP server (such as Absolute Time Server) in your PC. In Windows XP OS, you can use **command net start 232 time** to boot up an NTP service.

Figure 3-37 NTP Configuration Interface
Table 3-14 NTP Configurations

Parameter	Function
Host IP	Enter your PC's IP address.
Port	This NVR supports TCP transmission only. The default port value is 123 .
Update Period	The minimum value is 1. The maximum value is 65535 . (Units=minute)
Time Zone	Select the time zone here.
Manual Update	This allows you to manually synchronize the time with the server.

Table 3-15 Time Zones


City/Region Name	Time Zone
London	GMT + 0
Berlin	GMT + 1
Cairo	GMT + 2
Moscow	GMT + 3
New Delhi	GMT + 5
Bangkok	GMT + 7
Beijing (Hong Kong)	GMT + 8
Tokyo	GMT + 9
Sydney	GMT + 10
Hawaii	GMT - 10
Alaska	GMT - 9
Pacific Time (PT)	GMT - 8
American Mountain Time (MT)	GMT - 7
American Central Time (CT)	GMT - 6
American Eastern Time (ET)	GMT - 5

Table 3-15 Time Zones

City/Region Name	Time Zone
Atlantic Time	GMT - 4
Brazil	GMT - 3
Middle Atlantic Time	GMT - 2

Configuring the Multicast Settings

You can configure a multiple cast (Multicast) group.

Figure 3-38 Multicast Configuration Interface**Table 3-16 Multicast Configurations Special IP Addresses**

Parameter	Description
IP multiple cast group address	Enter a value between 224.0.0.0 to 239.255.255.255.
Reserved local multiple cast group address	Enter a value between 224.0.0.0 to 224.0.0.255. TTL = 1 when sending out a telegraph. For example: 224.0.0.1 All systems in the sub-net. 224.0.0.2 All routers in the sub-net. 224.0.0.4 DVMRP router. 224.0.0.5 OSPF router 224.0.0.13 PIMv2 router.
Administrative scoped addresses	Enter a value between 239.0.0.0 to 239.255.255.255. <ul style="list-style-type: none"> • Like the single broadcast address of RVC1918 • Cannot be used in Internet transmission • Use for multiple cast broadcast in limited space

You can use any IP address except for the IP addresses mentioned in [Table 3-16](#).


For example, you can use the following:

- Multiple cast IP: 235.8.8.36
- Multiple cast port: 3666

After you have logged onto the web client, the web client can automatically get the multiple cast address, and add it to the multiple cast groups. You can enable the real-time monitor function to view the view.

Configuring the PPPoE Settings

Figure 3-39 PPPoE Configuration Interface



The screenshot shows a configuration window titled "PPPOE". It features three input fields: "User Name", "Password", and "IP Address". The "IP Address" field is composed of two rows of four boxes each, each containing a "0". At the bottom of the window, there are three buttons: "Default", "OK", and "Cancel".

1. Enter the **PPPoE name** and **password** that you received from your Internet Service Provider (ISP).
2. Click **OK**.
3. Reboot your NVR to activate the new settings.

After you reboot, the NVR will automatically connect to the internet. The IP address that appears is the dynamic IP address for the NVR.

Note You can access the NVR through this dynamic IP address. Just enter it in the address field of a browser.

Configuring the DDNS Settings

Figure 3-40 DDNS Configuration Interface

Before you begin configuring DDNS:

- Ensure that your PC has a fixed IP address.
- Ensure that your PC is running the DDNS software.

In other words, ensure that your PC is a DNS (domain name server).

Configuring DDNS

Table 3-17 DDNS Configurations

Parameter	Description
DDNS Type	You can select the DDNS protocol from the drop-down list, and then enable the DDNS function. Select the Honeywell DDNS server (which is free) to enable the DDNS function.
Server IP	This is the DDNS server IP address. Under Honeywell DDNS , the default server address is www.hennvr-ddns.com .
Mode	Select Auto or Manual . The default is Auto . If you select Manual , then you must enter a domain name.
Domain Name	Auto and self-defined domain names are both MAC address.hennvr-ddns.com . You can define the prefix.
Username	The user name you enter to log in the server (Optional).

Note The NNDS type can include: Honeywell DDNS, CN99 DDNS, NO-IP DDNS, Quick DDNS, and DynDNS DDNS. All of these types of DDNS can be valid at the same time. Select which one you need.

Note Do not register frequently. You need to wait at least 60 seconds between registration requests. Too many registration requests might leave your server vulnerable to attacks.

Configuring the UPnP Settings

The UPnP protocol establishes a mapping relationship between the LAN and the WAN. Double-click **UPNP** in [Figure 3-35, Network Setting Configuration Interface](#), to open the **UPNP** configuration interface.

Figure 3-41 UPnP Configuration Interface



Table 3-18 UPnP Configurations

Parameter	Function
UPnP On/Off	Turn On or Off the UPnP function.
Status	Displays Unknown when the UPnP is offline. Displays Success when the UPnP is working.
Router LAN IP	The router IP in the LAN.
WAN IP	The router IP in the WAN.
Port Mapping list (PAT Table)	This is the one-to-one relationship with the router's port mapping setting.
Enable Switch	A check mark ✓ in the box <input type="checkbox"/> indicates that port mapping is enabled for this port.
List	<p>Service Name: Defined by the user.</p> <p>Protocol: The protocol type.</p> <p>Internal port: The port that has been mapped in the router.</p> <p>External port: The port that has been mapped locally.</p>
Default	Click to restore the UPnP default port settings, which is the HTTP, TCP, and UDP for the NVR.
Add to the List	Click to add the mapping relationship.
Delete	Click to remove a mapping item.

Double-click the UPnP item in the list to configure it. A configuration window appears.

Figure 3-42 Port Info Configuration Interface

Service Name	TCP
Protocol	TCP
Int.Port	37777
Ext.Port	37777

Configuring the WIFI Settings

The **Network Settings** interface shows the WIFI connection status. The interface shows the current connection status and the IP address, if there is a connection.

Figure 3-43 WIFI Connection Status

Setting	Value
<input checked="" type="checkbox"/> IP FILTER	Trusted Sites : 0
<input checked="" type="checkbox"/> NTP	time.windows.com : 60
<input checked="" type="checkbox"/> MULTICAST	239.255.42.42
<input checked="" type="checkbox"/> PPPOE	
<input checked="" type="checkbox"/> DDNS	Honeywell DDNS :
<input checked="" type="checkbox"/> UPNP	Port Forwarding
<input type="checkbox"/> 3G Setting	
<input checked="" type="checkbox"/> WIFI Setting	No connection
<input checked="" type="checkbox"/> EMAIL	MailServer : 25
<input type="checkbox"/> FTP	Record FTP : 0.0.0.0
<input type="checkbox"/> Alarm Center	Private : 10.1.0.2
<input type="checkbox"/> SNMP	
<input type="checkbox"/> Auto Register	0.0.0.0 : 8000
<input type="checkbox"/> Switch Settings	10.1.1.1

Double-click **WIFI Setting** to open the **WIFI Setting** interface.

Figure 3-44 WIFI Setting Interface



Table 3-19 WIFI Setting Functions/Control

Button/Control	Description
Auto Connect WIFI	Check to enable Auto Connect WIFI . The NVR automatically connects to the previous hotspot.
Refresh	Click to refresh the list of found hotspots. When the list is refreshed, the system automatically adds any previously configured information such as a password.

Table 3-19 WIFI Setting Functions/Control

Button/Control	Description
Disconnect	Click to disconnect from the hotspot.
Connection	Click to connect to the hotspot. The NVR needs to turn off the current connection and then connect to a new hotspot, if you have selected a new one. The WIFI Connection interface appears. WIFI Connection interface, no connection.



WIFI Connection interface, showing a connection.



Connection Status	Shows the connection status. After successfully connecting, the WIFI icon appears in the top right corner of the preview interface. When the hotspot Verification Type is WEP, the NVR displays AUTO , because the device can not detect its encryption type. The NVR does not support verification of types WPA and WPA2. The display might become abnormal for the verification type and the encryption type.
--------------------------	---

When the NVR has successfully connected to the WIFI, the hotspot name, IP address, subnet mask, default gateway are all visible.

Figure 3-45 Viewing WIFI Settings



Configuring the Email Settings

Figure 3-46 Email Configurations Interface



Table 3-20 Email Configurations

Parameter	Description
SMTP server	Enter the email SMTP server IP.
Port	Enter the corresponding port.
User Name	Enter the user name for logging in to the sender's email box.
Password	Enter the login password here.
Sender	Enter the sender's email address.
Title	Enter an email subject. You can use up to 32 letters or numbers.

Table 3-20 Email Configurations

Parameter	Description
Receiver	Enter the receiver's email address. You can enter up to 3 email addresses.
SSL enable	The NVR supports an SSL encryption box.
Event Interval	The interval for sending ranges from 0 to 3600 seconds. 0 means that there is no interval.
Health email enable	Click to enable the email health check. The NVR sends a test email to check the network connection.
Interval	After enabling Health Enable, you can configure how frequently the NVR sends out emails to test the network connection. Click Test to send a test email. A popup message appears to indicate the state of the network connection.



Configuring the FTP Settings

You need to download or buy an FTP service tool (such as Ser-U FTP SERVER, used as an example below) to have FTP service.

Installing the FTP service tool

1. Go to **Start > Program > Serv-U FTP SERVER > Serv-U Administrator**.

Figure 3-47 Configuring FTP

2. Configure the password and the FTP folder.

Note You need to grant the FTP upload user the right to write to the FTP server.

3. Use your PC or the FTP login tool to test the setup.

For example, you can log in user ZHY to FTP://10.10.7.7, and then test to see if you can modify or delete folders.

Figure 3-48 Testing the FTP Setup



Uploading Multiple NVRs onto an FTP Server

The system FTP server also supports uploading to multiple NVRs on one FTP server. You can create multiple folders under this FTP.

1. Double-click **FTP** in the **Network Setting** configuration window.

Figure 3-49 Network Setting Configuration Interface



The FTP configuration interface appears.

Figure 3-50 FTP Configuration Interface

The screenshot shows the FTP Configuration Interface with the following fields and values:

- Server IP: 0 . 0 . 0 . 0
- Port: 21
- User Name: [Empty]
- Password: [Empty]
- Anonymous:
- Remote Directory: [Empty]
- File Length: 0 M
- Snapshot: 2 sec.
- Channel: 1
- Weekday: Wed
- Alarm, Motion, Regular: [Empty]
- Time Period 1: 00 :00 -24 :00
- Time Period 2: 00 :00 -24 :00

Buttons at the bottom: Default, OK, Cancel, Test.

2. Click to enable the **FTP** function.
3. Enter an FTP server address, port, and remote directory.

Table 3-21 FTP Configurations

Parameter	Description
User Name	The same user name that you used for logging in to the FTP.
Password	The same password that you used for logging in to the FTP.
File Length	This is the upload file length. When the setup is larger than the actual file length, then the system will upload the whole file. When the setup is smaller than the actual file length, the system uploads only the set length, and then ignores whatever exceeds that length. When the interval value is 0 , then the system uploads all corresponding files.

Note When the remote directory is null, the system automatically creates folders according to the IP, time, and channel.

4. Select a **Channel** and **Weekday**, then configure up to two **Time Periods**.
5. Click **Test** to test the network connection.
A popup message appears to indicate the state of the network connection.

Figure 3-51 Message Indication FTP Connection Failure

Alarm Center

Not functional at this time.

Configuring SNMP

Simple Network Management Protocol (SNMP) provides the basic network management frame for the network management system. SNMP is widely used in many environments, in many network devices, software, and systems.

Note Use the corresponding software tool (MIB Builder and MG-SOFT MIB Browser, plus two MIB files: BASE-SNMP-MIB, and NVR-SNMP-MIB) to connect to the NVR.

The corresponding device configuration information appears after you have successfully connected.

1. Double-click SNMP in the **Network Setting** configuration window. The SNMP configuration interface appears.

Figure 3-52 SNMP Configuration Interface



The screenshot shows the SNMP Configuration Interface. At the top, there is a red 'Honeywell' logo and a yellow 'SNMP' tab. Below the tab, the configuration options are as follows:

- SNMP Enable:
- V1:
- V2:
- SNMP Port:
- Read-Community:
- Write-Community:
- Trap Address:
- Trap Port:

At the bottom of the window, there are three buttons: 'Default', 'Save', and 'Cancel'.


2. Click to enable **SNMP**.
3. Enter in the **Trap Address** field the IP address for the PC that is running the software.
You can use the default settings for the other items.
4. Compile the two MIB files. See the note on [page 91](#).
5. Run the **MG-SOFT MIB Browser** to load the files through the software MIB Builder.
6. Enter the IP for the device you want to manage in the MG-SOFT MIB Browser. Make a note for your future reference.
7. Open the tree list in the **MG-SOFT MIB Browser** where you can get the device configuration. You can see the following information for the device: the number of video channels, the number of audio channels, the version number, for example.

Configuring Auto Register Settings

The **Auto Register** function allows the device to automatically register to the proxy that you have specified. This means that you can use the client-end to access the NVR through the proxy. The proxy has a switch function. The device supports server either IPv4 or domain server addresses.

Follow these steps to set the proxy server address, the port, and the sub-device name at the device end.

1. Double-click **Auto Register** in the **Network Setting** configuration window. The **Auto Register** configuration interface appears.

Figure 3-53 Auto Register Configuration Interface

Note Do not enter a TCP port number for the network default port.

2. Click to **Enable** automatic registration to the proxy server.
3. Open the proxy server software that was developed from the SDK, then enter the global setup.
Ensure that the auto connection port here is the same as the port you set in [step 2](#).
4. Add the device. Do not enter the default port number such as the TCP port in the mapping port number. The device ID should be the same as the ID you entered in [Figure 3-53](#).
5. Click **Save** to complete the setup.
6. Boot up the proxy server. If you see that the network status is **Y**, then you correctly registered your device. You will be able to see the proxy server when the device is online.

Note The server IP address can also be the domain. However, you need to register the domain name before you can run the proxy device server.

Configuring Alarms


Click the **Alarms** icon  in the **Setting** interface to open the **Alarms** configuration interface.

Figure 3-54 Alarms Configuration Interface




Table 3-22 Alarm Configurations

Parameter	Description
Event Type	Select from four types: Local input alarm: The alarm signal system detects from the alarm input port. Network input alarm: An alarm signal from the network. IPC external alarm: The on/off alarm signal from the camera, which activates the local NVR to receive the IP camera's alarm if there is an alarm occurring at the camera. IPC offline alarm: When enabled, the system generates an alarm when the front end IP camera disconnects from the local NVR. The alarm can activate recording or taking a snapshot, for example. The alarm can last until the camera and the NVR connection resumes.
Alarm In	Select a channel.
Enable	Click to enable the this alarm configuration.
Device Type	Select either Normally Open or Normal Closed .

Table 3-22 Alarm Configurations

Parameter	Description
-----------	-------------

Period Configure when the local alarm period is active.
 1. Click **Set**. The **Set** configuration interface appears.



2. Select a a day of the week, or **Work Day** or **Free Day**.

Note If you select **Work Day** or **Free Day**, a **Set** button appears so you can configure which days are **Work Days** and which days are **Free Days**. Click **Set**, select the Work Days and the Free Days, then click **Save**.



3. Enter a time range for the alarm, then click the check box to select that time range.

Note Newer configurations override previous configurations. For example, if you configure Work Days with an alarm period from 8:30 to 17:30, and then Configure a Monday alarm period for 7:10 to 18:00, the Monday alarm period overrides the Work Day alarm period. So on Mondays, the alarm period will be 7:10 to 18:00.

Table 3-22 Alarm Configurations

Parameter	Description
Anti-dither	<p>Select an anti-dither time, from 5s to 600s. The anti-dither time starts when a second alarm is detected, and it determines what happens when a second alarm is detected. It determines if a second alarm will trigger another alarm action such as showing a screen alert, sending an email, starting a buzzer, flashing a light, taking a snapshot, or recording video. During the anti-dither time, if the system detects another alarm, the system will not be activated.</p> <p>If you set the Anti-dither time for 10 seconds, then each activated alarm action will last for 10 seconds. But if the alarm is triggered again 5 seconds after the anti-dither time began, then alarm actions such as triggering a buzzer, a snapshot, and recording will reset and last another 10 seconds from that second alarm trigger time. There will not be another screen prompt or alarm upload, nor will another email be sent. After the 10 seconds is over, if the system detects another alarm after the anti-dither time is over, it will generate another alarm.</p> <p>The stay time here does not include the latch time.</p>
Alarm Out	Select the device output port, from 1 to 3 . Select the corresponding port(s) so the system can activate the corresponding alarm devices when an alarm occurs.
Latch	When the anti-dither time has ended, the channel alarm you have selected will last this period. Select from 1s to 300s . Latch does not work with other alarm activation operations. Latch is still valid even if you directly disable the alarm event function. The system can delay the alarm output for a specified time after an alarm ends. The value ranges from 1s to 300s .
Show Message	Click to enable a pop-up message on your local host PC screen to let you know an alarm has occurred.
Alarm Upload	<p>Click to enable the system to upload the alarm signal to the network (including an alarm center and the web client). The system uploads only the alarm channel status.</p> <p>Go to the Web operation, and then go to the Alarm interface to set the alarm event and alarm operation. See Enabling and Disabling Alarm Out Settings on page 200 and Configuring Alarms on page 181.</p>
Send Email	The system can send an email when an alarm is detected. When you have enabled the Snapshot function, the system can also send an image attached to the email. Go to Main Menu > Setting > Network > Email to configure the email settings. See Configuring the Email Settings on page 87 .
Record Channel	Select a recording channel. See How to Record on page 97 for more about recording.
PTZ Activation	Not supported.
Delay	The system can delay recording for a specified amount of time after an alarm has ended. Select from 10s to 300s .

Table 3-22 Alarm Configurations

Parameter	Description
Tour	Click to enable a tour to be triggered by an alarm. The system supports 1/8-window tour. Go to Configuring Display Settings on page 109 for tour interval setup. Note Tours setup here have higher priority than tours setup in the Display interface. If there is no alarm, the system implements the tour setup in the Display interface.
Snapshot	Click to enable the Snapshot function. A snapshot will be taken when an alarm occurs.
Buzzer	Click to enable the Buzzer function. The buzzer beeps when an alarm occurs.

Note You must click **Save** after configuring the settings to save them.

How to Record

1. In the **Record** interface, set the alarm record mode to **Schedule**.
Go to **Main Menu > Advanced > Record**.

Note If you select **Manual** recording, that mode has the highest priority. So the system will record all the time instead of because of an alarm trigger.

2. Set the recording type, corresponding channel, week, and date.
 - Go to **Main Menu > Setting > Schedule**.
 - For the recording type, select from **Regular**, **MD**, **Alarm**, **MD&Alarm**.

Note You can not select **MD&Alarm** and **MD** (or **Alarm**) at the same time.

3. Set the alarm record and encoder parameters.
 - Go to **Main Menu > Setting > Encode**.
4. Set the alarm input as the local alarm, and then select the recording channel. The NVR will record this channel when an alarm is detected.

Note The system begins the alarm-triggered recording instead of motion detection-triggered recording if the local alarm and the motion detection event occur at the same time.

Configuring Detection Settings


In the **Detect** configuration interface, you can configure the event detection settings. There are three types of detection:

- Motion Detection
- Video Loss Detection
- Camera Masking Detection

Note You can not configure a detection region or sensitivity for **Video Loss**. You can not configure a detection region for **Camera Masking**.

Note The **Motion Detection** icon appears only if the currently viewed channel has an enabled motion detection alarm.

Note When selecting the event detection region, you can drag the mouse to configure the motion detection region without clicking the **FN** button on the NVR's front panel. Click **OK** to save the currently selected region. Right-click the mouse to exit the current interface.

Click the **Detect** icon  in the **Setting** interface to open the **Detect** configuration interface.

Configuring Motion Detection Settings

Select **Motion Detection** from the **Event Type** drop-down list.

Figure 3-55 Detect Configuration Interface

The screenshot shows a configuration window with the following fields and options:

- Event Type:** Motion Detect (dropdown)
- Channel:** 1 (dropdown)
- Enable:**
- Region:** Select (button)
- Sensitivity:** 5 (dropdown)
- Period:** Set (button)
- Alarm Out:** (dropdown: 2, 3)
- Latch:** 10 (input field) sec.
- Show Message:**
- Alarm Upload:**
- Send Email:**
- Record Channel:** (dropdown: 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16)
- PTZ Activation:** (button: Select)
- Delay:** 10 (input field) sec.
- Tour:** (dropdown: 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16)
- Snapshot:** (dropdown: 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16)
- Buzzer:**

Buttons at the bottom: Copy, Save, Cancel.

Table 3-23 Motion Detection Configurations

Configuration	Description
Event Type	Select the event detection type. Select from Motion Detection , Video Loss , or Camera Masking .
Channel	Select a channel.
Enable	Click to enable event detection.

Table 3-23 Motion Detection Configurations


Configuration	Description
Region	<p>Configure the event detection region.</p> <ol style="list-style-type: none"> Click Select. The area selection window opens.  <p>There are 396 (PAL) or 330 (NTSC) small zones.</p> <p>Green: Indicates the current cursor position.</p> <p>Grey: Indicates the event detection zone.</p> <p>Black: Indicates a disarmed zone.</p> <ol style="list-style-type: none"> Select the event detection area by either clicking and dragging the mouse or using the direction arrows on the NVR's front panel. <p>Note Use the FN button on the NVR's front panel to switch the cursor between selecting and deselecting.</p> <ol style="list-style-type: none"> Click ENTER on the NVR's front panel to save the configuration, or click ESC to exit the area selection interface without saving the configuration.
Sensitivity	Select from 6 levels. Level 6 is the highest sensitivity.

Table 3-23 Motion Detection Configurations

Configuration	Description
Period	<p>Configure when the event detection area is active.</p> <ol style="list-style-type: none"> Click Set. The Set configuration interface appears. <div data-bbox="782 411 1421 898" data-label="Image"> </div> Select a day of the week, or Work Day or Free Day. <div data-bbox="766 976 1427 1094" data-label="Text"> <p>Note If you select Work Day or Free Day, a Set button appears so you can configure which days are Work Days and which days are Free Days. Click Set, select the Work Days and the Free Days, then click OK.</p> </div> <div data-bbox="782 1100 1421 1310" data-label="Image"> </div> Configure a time range for when the event detection area is active, then click the check box to select that time range. <div data-bbox="766 1409 1427 1703" data-label="Text"> <p>Note You can configure up to 6 time periods within one day.</p> <p>Note Newer configurations override previous configurations. For example, if you configure Work Days with an event detection area active period from 8:30 to 17:30, and then Configure a Monday alarm period for 7:10 to 18:00, the Monday event detection area active period overrides the Work Day event detection area active period. So on Mondays, the event detection area active period will be 7:10 to 18:00.</p> </div> Click OK.
Alarm Out	<p>Select the device output port, from 1 to 3. Select the corresponding port(s) so the system can activate the corresponding alarm devices when an alarm occurs.</p>

Table 3-23 Motion Detection Configurations

Configuration	Description
Latch	When a motion detection event is complete, the system automatically delays, for a specified time, the NVR from detecting new motion detection events.
Show message	Configure the system to automatically pop up a message in the local view screen when an alarm occurs.
Alarm upload	Click to enable the system to upload the alarm signal to the network (including an alarm center and the web client). The system uploads only the alarm channel status. Go to the Web operation, and then go to the Alarm interface to set the alarm event and alarm operation. See Enabling and Disabling Alarm Out Settings on page 200 and Configuring Alarms on page 181 .
Send email	The system can send an email when an alarm is detected. When you have enabled the Snapshot function, the system can also send an image attached to the email. Go to Main Menu > Setting > Network > Email to configure the email settings. See Configuring the Email Settings on page 87 .
Record channel	Select a recording channel. See How to Record on page 97 for more about recording.
PTZ activation	Not supported.
Record delay	The system can delay recording for a specified amount of time after an alarm has ended. Select from 10s to 300s .
Tour	Click to enable a tour to be triggered by an alarm. The system supports 1/8-window tour. Go to Configuring Display Settings on page 109 for tour interval setup. Note Tours setup here have higher priority than tours setup in the Display interface. If there is no alarm, the system implements the tour setup in the Display interface.
Snapshot	Click to enable the Snapshot function. A snapshot will be taken when an event occurs.

Note You must click **Save** after configuring the settings to save them.

Note In the **Detection** interface, the copy-and-paste function is only valid for the same type of event detection. You can not copy a channel setup in video loss mode to camera masking mode.

Configuring Video Loss Settings

The **Video Loss** function allows you to be informed when video loss has occurred.

TIP! You can enable an alarm output channel, and then enable the **Show Message** function.

Select **Video Loss** from the **Event Type** drop-down list.

Figure 3-56 Video Loss Configuration Interface




Table 3-24 Video Loss Detection Configurations

Configuration	Description
Event Type	Select the event detection type. Select from Motion Detection , Video Loss , or Camera Masking .
Channel	Select a channel.
Enable	Click to enable event detection.

Table 3-24 Video Loss Detection Configurations

Configuration	Description
Period	<p>Configure when the event detection area is active.</p> <ol style="list-style-type: none"> Click Set. The Set configuration interface appears. <div data-bbox="782 411 1421 898" data-label="Image"> </div> Select a day of the week, or Work Day or Free Day. <div data-bbox="766 978 1425 1094" data-label="Text"> <p>Note If you select Work Day or Free Day, a Set button appears so you can configure which days are Work Days and which days are Free Days. Click Set, select the Work Days and the Free Days, then click OK.</p> </div> <div data-bbox="782 1098 1412 1310" data-label="Image"> </div> Configure a time range for when the event detection area is active, then click the check box to select that time range. <div data-bbox="766 1411 1425 1644" data-label="Text"> <p>Note Newer configurations override previous configurations. For example, if you configure Work Days with an event detection area active period from 8:30 to 17:30, and then Configure a Monday alarm period for 7:10 to 18:00, the Monday event detection area active period overrides the Work Day event detection area active period. So on Mondays, the event detection area active period will be 7:10 to 18:00.</p> </div>
Alarm Out	Select the device output port, from 1 to 3 . Select the corresponding port(s) so the system can activate the corresponding alarm devices when an alarm occurs.
Latch	When a video loss event is complete, the system automatically delays, for a specified time, the NVR from detecting new video loss detection events.

Table 3-24 Video Loss Detection Configurations

Configuration	Description
Show message	Configure the system to automatically pop up a message in the local view screen when an alarm occurs.
Alarm upload	<p>Click to enable the system to upload the alarm signal to the network (including an alarm center and the web client). The system uploads only the alarm channel status.</p> <p>Go to the Web operation, and then go to the Alarm interface to set the alarm event and alarm operation. See Enabling and Disabling Alarm Out Settings on page 200 and Configuring Alarms on page 181.</p>
Send email	The system can send an email when an alarm is detected. When you have enabled the Snapshot function, the system can also send an image attached to the email. Go to Main Menu > Setting > Network > Email to configure the email settings. See Configuring the Email Settings on page 87 .
Record channel	Select a recording channel. See How to Record on page 97 for more about recording.
PTZ activation	Not supported.
Record delay	The system can delay recording for a specified amount of time after an alarm has ended. Select from 10s to 300s .
Tour	<p>Click to enable a tour to be triggered by an alarm. The system supports 1/8-window tour. Go to Configuring Display Settings on page 109 for tour interval setup.</p> <p>Note Tours setup here have higher priority than tours setup in the Display interface. If there is no alarm, the system implements the tour setup in the Display interface.</p>
Snapshot	Click to enable the Snapshot function. A snapshot will be taken when an event occurs.

Note You must click **Save** after configuring the settings to save them.

Note In the **Detection** interface, the copy-and-paste function is only valid for the same type of event detection. You can not copy a channel setup in video loss mode to camera masking mode.

TIP! You can enable a preset, tour, or pattern activation for when video loss occurs.

Configuring Camera Masking Settings

If something masks or blocks part of the camera lens, or if the output video turns to one color due to a change in the environment's lighting, the system can alert you to guarantee video continuity.

Select **Camera Masking** from the **Event Type** drop-down list.

Figure 3-57 Camera Masking Configuration Interface

Table 3-25 Camera Masking Detection Configurations

Configuration	Description
Event Type	Select the event detection type. Select from Motion Detection , Video Loss , or Camera Masking .
Channel	Select a channel.
Enable	Click to enable event detection.

Table 3-25 Camera Masking Detection Configurations

Configuration	Description
Period	<p>Configure when the event detection area is active.</p> <ol style="list-style-type: none"> Click Set. The Set configuration interface appears. <div data-bbox="786 409 1421 898" data-label="Image"> </div> Select a day of the week, or Work Day or Free Day. <div data-bbox="768 976 1421 1094" data-label="Text"> <p>Note If you select Work Day or Free Day, a Set button appears so you can configure which days are Work Days and which days are Free Days. Click Set, select the Work Days and the Free Days, then click OK.</p> </div> <div data-bbox="786 1100 1421 1310" data-label="Image"> </div> Configure a time range for when the event detection area is active, then click the check box to select that time range. <div data-bbox="768 1411 1421 1644" data-label="Text"> <p>Note Newer configurations override previous configurations. For example, if you configure Work Days with an event detection area active period from 8:30 to 17:30, and then Configure a Monday alarm period for 7:10 to 18:00, the Monday event detection area active period overrides the Work Day event detection area active period. So on Mondays, the event detection area active period will be 7:10 to 18:00.</p> </div>
Alarm Out	Select the device output port, from 1 to 3 . Select the corresponding port(s) so the system can activate the corresponding alarm devices when an alarm occurs.
Latch	When a motion detection event is complete, the system automatically delays, for a specified time, the NVR from detecting new video loss detection events.

Table 3-25 Camera Masking Detection Configurations

Configuration	Description
Show message	Configure the system to automatically pop up a message in the local view screen when an alarm occurs.
Alarm upload	<p>Click to enable the system to upload the alarm signal to the network (including an alarm center and the web client). The system uploads only the alarm channel status.</p> <p>Go to the Web operation, and then go to the Alarm interface to set the alarm event and alarm operation. See Enabling and Disabling Alarm Out Settings on page 200 and Configuring Alarms on page 181.</p>
Send email	The system can send an email when an alarm is detected. When you have enabled the Snapshot function, the system can also send an image attached to the email. Go to Main Menu > Setting > Network > Email to configure the email settings. See Configuring the Email Settings on page 87 .
Record channel	Select a recording channel. See How to Record on page 97 for more about recording.
PTZ activation	Not supported.
Record delay	The system can delay recording for a specified amount of time after an alarm has ended. Select from 10s to 300s .
Tour	<p>Click to enable a tour to be triggered by an alarm. The system supports 1/8-window tour. Go to Configuring Display Settings on page 109 for tour interval setup.</p> <p>Note Tours setup here have higher priority than tours setup in the Display interface. If there is no alarm, the system implements the tour setup in the Display interface.</p>
Snapshot	Click to enable the Snapshot function. A snapshot will be taken when an event occurs.

Note You must click **Save** after configuring the settings to save them.

Note In the **Detection** interface, the copy-and-paste function is only valid for the same type of event detection. You can not copy a channel setup in video loss mode to camera masking mode.

Configuring Display Settings


Click the **DISPLAY** icon  in the **Setting** interface to open the **Display** configuration interface.

Figure 3-58 Display Configuration Interface





Table 3-26 Display Configurations

Configuration	Description
Transparency	Adjust the transparency of the GUI overlay. Select from 128 to 255 .
Channel Name	<p>Customize the channel name. You can enter up to 31 characters. Changes here apply only to the NVR local end.</p> <ol style="list-style-type: none"> Click Modify. The Channel Name configuration interface opens.  <ol style="list-style-type: none"> Enter camera names in the editable fields. Click Save. <p>Note Modifications here apply only to the local end only. You need to open the web client to refresh the channel name.</p>
Time Display	Turn time display On or Off for playback.
Channel Display	Turn channel display On or Off for playback.
Resolution	Select from four options: 1920x1080 , 1280x1024 , 1280x720 , and 1024x768 (default).
Image Enhance	Click to enable.

Note We recommend that you change resolution to the maximum resolution that your monitor can support.

Note You must click **Save** after configuring the settings to save them.

Configuring Default Settings

Click the **DEFAULT** icon  in the **Setting** interface to open the **Default** configuration interface.

In the **Default** interface, you can click to select what parameters are returned to their default settings. Choose from:

- General
- Schedule
- RS232
- Network
- Alarm
- Detect
- Pan/Tilt/Zoom
- Display
- Channel Name
- Remote Device

Note You must click **OK** to save the new settings.

Note The system menu color, language, time display mode, video format, IP address, and user account will not keep any custom settings if you default the NVR.

Connecting to and Configuring the Remote Devices/Cameras

Note Do NOT connect the switch to the PoE port. If you do, then the connection might fail.

Depending on your model, your NVR can support up to 16 channels, with a transmission rate of 8Mbps. It supports 100/120 @ 1080p. The delay time for each channel is below 500 ms.


Your NVR supports IP cameras from many popular manufacturers such as Honeywell, Sony, Hitachi, Dynacolor, Axis, Samsung, Arecont, Dahua, and Onvif. For a full list of compatible cameras, see [Appendix D, Compatible IP Cameras](#).

Just enter the camera's URL address, user name, and password to log in to the camera.

Note Connecting to these cameras can be slightly different for each manufacturer and model.

Connect the cameras to the PoE ports on the NVR's rear panel.

Figure 3-59 NVR Real Panel - PoE Ports



The NVR automatically searches for and connects to the network cameras.

Note The four-channel NVR back panel is shown here as an example. The back panel of the eight-channel and 16-channel NVRs will be slightly different.

Configuring the Built-in Switch Setup

1. Open the **Switch Settings** configuration interface.

On the **Main Menu** interface, click **Setting** > **Network** > **Network Setting**, then double-click **Switch Setting**.

Figure 3-60 Switch Settings Configuration Interface



2. Enter values for the **IP Address**, **Subnet Mask**, and **Gateway**.
3. Click **OK** to save these settings.

Configuring the Remote Device/Camera

Click the **REMOTE DEVICE** icon  in the **Main Menu** to open the **Remote Device** configuration interface.

Figure 3-61 Remote Device Configuration Interface




Table 3-27 Remote Device Configurations

Configuration	Description
IP Search	Click to search for an IP address.
Add	Click to connect to the selected, found IP device (camera), and add it to the Added device list. Note You can batch add more than one device.
Show Filter	Displays the specified devices from the added device.
Delete	Select a device in the Added device list, and then click Delete to remove it.
Manual Add	Click to manually add a camera. The port number is 37777 . The default user name is admin , and the default password is 1234 .

Adding a Remote Device/Camera

Click **Manual Add** in the **Remote Device** configuration interface. The **Manual Add** configuration interface appears.

Figure 3-62 Manual Add Configuration Interface


The image shows a configuration dialog box with a dark blue background. It contains several input fields and dropdown menus. At the bottom, there are 'OK' and 'Cancel' buttons.

Channel	16	v
Manufacturer	Private	v
IP Address	192.168.0.0	
User	admin	TCP Port 37777
Password	••••	
Decoder Buffer	280	msec
Remote Channel	1	

Shortcut Menu

If there is no IP camera connected, the GUI shows [Figure 3-63](#).

Figure 3-63 Short-cut to Remote Device Configuration Interface

Click the + in the center of the **Preview** interface for the channel which is not connected to an IP camera.

The **Remote Device** configuration interface appears.

Figure 3-64 Remote Device Configuration Interface



Advanced Configurations

Click the **ADVANCED** icon  in the **Main Menu** to open the **ADVANCED** configuration interface.

The **ADVANCED** configuration interface appears.

Figure 3-65 Advanced Configuration Interface



Configuring HDD Management


In the **HDD MANAGE** configuration window, you manage the Hard Disk Drive and view its current HDD type, status, capacity, and record time.

Figure 3-66 HDD MANAGE Configuration Interface



When the HDD is working properly, you see an **O**. When an HDD error has occurred, you see an **X**.

Table 3-28 HDD MANAGE Configurations

Configuration	Description
Alarm Set	<p>Click Alarm Set. The Alarm Set configuration interface appears. This interface looks just like the Abnormality configuration interface. See Configuring for Abnormalities on page 186.</p> 
HDD Setting	<p>Select the HDD mode from the dropdown list. Select from Read-only or you can erase all the data on the HDD.</p> <p>Note The system needs to reboot to activate the new configurations.</p>

Note For setting up HDD group operation:

- Each channel’s records can be stored in the specified HDD Group.
- Each HDD Group can correspond to several hard disks. But a HDD can belong to only one group. Each channel can correspond to only one hard disk. But one HDD Group can store records from several channels.
- HDD Groups are available for read-write HDDs and self-defined disks. Other types of hard disks can not be set as a HDD Group.

Note The current software version can set only the HDD Group operation of the read-write HDDs. It is not for the redundancy HDD.

Configuring HDD Group Settings

1. Click **HDD Setting** on the **HDD MANAGE** configuration interface.

The **HDD Setting** configuration interface appears.

Figure 3-67 HDD Setting Configuration Interface



The **HDD No.** column shows the maximum number of HDD you can install.

If the serial number is highlighted, then you can connect to that HDD.

If the serial number is not highlighted, then you can not connect to that HDD.

2. Select a HDD group name from the **HDD Group** drop-down list.

The **HDD Group** column shows the **HDD Group** number of the current hard disk.

3. Click **OK** to save these new settings.

Note A HDD can belong to only one group. But one group can contain many HDDs. The **HDD No.** corresponds to the HDD port. The **HDD Group No.** can change if you change the HDD.

Note When you change the **HDD Group** settings, the system will save the recorded video and snapshots, then reboot.

Configuring HDD Channels

1. Click **HDD Channel** on the **HDD MANAGE** configuration interface. The **Channel Settings** configuration interface appears.

Figure 3-68 Channel Settings Configuration Interface



2. Configure the HDDs for the main stream, the extra stream, and for snapshots as well. The main and extra stream configurations for one channel can be saved to different groups.

Channel: Displays the actual channel number for the current NVR.

HDD Group: The SN of the **HDD Group** management. See [Configuring HDD Group Settings on page 117](#).

Note Ensure that you have set the **HDD Group** for each channel. If you fail to set the **HDD Group** for a channel, then you will not be able to save the current setup.

Note When you change the **HDD Group** settings, the system will save the recorded video and snapshots, then reboot.

TIPS! There is an easy way to test whether or not the recordings from the corresponding channel are saved in the specified HDD. Remove the HDD and then check to see if the channel can record. The channel should not record, and you should not be able to search the previous recordings.

Configuring Abnormality Settings

Click **ABNORMALITY** in the **ADVANCED** configuration interface. The **ABNORMALITY** configuration interface appears.

Figure 3-69 Abnormality Configuration Interface




Table 3-29 Abnormality Configurations

Configuration	Description
Event Type	Select from No Disk , Disk Error , Disk No Space , Net Disconnection , IP Conflict , or MAC Conflict .
Enable	Click to enable the Abnormality function.
Alarm Out	Select an alarm activation output port.
Latch	When an event is complete, the system automatically delays, for a specified time, the NVR from detecting new events.
Show Message	Click to enable a popup message to alert you when an alarm occurs.
Alarm Upload	Click to enable the system to upload the alarm signal to the network (including an alarm center and the web client). The system uploads only the alarm channel status. Go to the Web operation, and then go to the Alarm interface to set the alarm event and alarm operation. See Enabling and Disabling Alarm Out Settings on page 200 and Configuring Alarms on page 181 .
Send Email	The system can send an email when an alarm is detected. When you have enabled the Snapshot function, the system can also send an image attached to the email. Go to Main Menu > Setting > Network > Email to configure the email settings. See Configuring the Email Settings on page 87 .
Buzzer	Click to enable the Buzzer function. When an alarm occurs, the buzzer beeps.

Configuring Alarm Output

1. Click **ALARM OUTPUT** in the **ADVANCED** configuration interface. The **ALARM OUTPUT** configuration interface appears.

Figure 3-70 ALARM OUTPUT Configuration Interface



2. Click to make your selections, and then click **OK** to save the changes.

Configuring Manual Recording Settings

Note You must have proper rights to configure the **Recording** settings. Also, ensure that the HDD has been properly installed.

1. Click **RECORD** in the **ADVANCED** configuration interface.
OR
Right-click the mouse to open the shortcut menu, then click **Record**.
The **RECORD** configuration interface appears.

Figure 3-71 RECORD Configuration Interface



2. Select a recording status for each channel, and then click **OK** to save the changes.

Note Select **All** to select the same setting for all channels.

Table 3-30 Manual Recording Configurations

Configuration	Description
Manual	<p>The highest priority. Selecting Manual means that the channels begin ordinary recording.</p> <p>If you select All for Manual recording, the schedules for the individual channels will not work, and the system records manually.</p> <p>The front panel light indicates that the system is manually recording.</p>
Schedule	<p>Recording follows the schedule you have configured. See Configuring the Schedule on page 69.</p> <p>If you select All for Schedule recording, all channels will record following the schedules you have previously set for each channel.</p> <p>The front panel light indicates that the system is recording according to the schedule.</p>
Stop	<p>All channels stop recording.</p> <p>If you select All for Stop recording, all channels will not record.</p>
<input type="radio"/>	Indicates that the channel is not activated for this recording status.
<input checked="" type="radio"/>	Indicates that the channel is activated for this recording status.

Configuring Account Settings

In the **ACCOUNT** configuration interface, you can do the following:

- Add a new user
- Modify a user
- Add a group
- Modify a group
- Modify a password

Click **ACCOUNT** in the **ADVANCED** configuration interface. The **ACCOUNT** configuration interface appears.

Figure 3-72 ACCOUNT Configuration Interface



Account Naming Conventions The maximum length for the account name and user name is 6 bytes. There cannot be a space at the beginning or the end of the name string. But there can be a space in the middle. You can use letters, numbers, underline, subtraction/hyphen, and a period in the name.

Account Management The system account adopts a two-level management: group and user. There is no limit to the number of groups or users.

Group or User Management For group or user management, there are two levels: admin and user.

User and Group Naming Conventions The maximum length for a user or group name is 8 bytes. There are four default users: **admin**, **888888**, and **666666**, plus a hidden user **default**. All default users except **666666** have administrator rights.

Hidden Default User The hidden user, **default**, is for internal system use only, and can not be deleted. When logging in without a user name, the system automatically uses the hidden user. You can configure some rights for the hidden user, such as the right to monitor video, so that you can view video channels without logging in.

User Limitations Users can belong to only one group. User rights can not exceed the rights of the group to which it belongs.

Reusable Function Click to enable the **Reuseable** function, which allows multiple users to use the same account for logging in.

Adding or Modifying a Group

The procedures for adding a group and modifying a group are similar. The **Add Group** configuration interface is shown in this example.

1. Click **Add Group** or **Modify Group** in the **ACCOUNT** configuration interface. The **Add Group** or **Modify Group** configuration interface opens.

Figure 3-73 Add Group Configuration Interface



2. Enter a group **Name**. Entering **Memo** information is optional.
3. Click to enable privileges in the list. There are 60 from which to choose.
4. Click **Save** to save the new settings.

Adding or Modifying a User

The procedures for adding a user and modifying a user are similar. The **Add User** configuration interface is shown in this example.

1. Click **Add User** or **Modify User** in the **ACCOUNT** configuration interface. The **Add User** or **Modify User** configuration interface opens.

Figure 3-74 Add User Configuration Interface

Authority	Control Panel	Shutdown the Device	Monitor	Monitor_CH01	Monitor_CH02	Monitor_CH03	Monitor_CH04	Replay	Replay_CH01	Replay_CH02
39	1	2	3	4	5	6	7	8	9	10
	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

2. Enter a **User** name, a **Password** (twice), and **Memo** information, if required.
3. Click **Reuseable** to enable the **Reuseable** function. See [Reusable Function on page 123](#).
4. Click to enable privileges for this user.

TIP! We recommend that general user account rights are less than administrator account user rights.

5. Click **Save** to save the new settings.

Modifying a Password

1. Click **Modify Password** in the **ACCOUNT** configuration interface. The **Modify Password** configuration interface opens.

Figure 3-75 Modifying Password Configuration Interface

2. Select the user account from the drop-down menu.
3. Enter the old password, then enter the new password twice.
4. Click **Save** to save the new settings.

Configuring Automatic Maintenance Settings

The **AUTO MAINTAIN** function allows you to automatically reboot the time and automatically delete old file setups. You can set the system to delete the files for the specified days.

1. Click **AUTO MAINTAIN** in the **ADVANCED** configuration interface. The **AUTO MAINTAIN** configuration interface appears.

Figure 3-76 AUTO MAINTAIN Configuration Interface

2. Select from the drop-down lists a day and time for automatically rebooting the system. Select from **Never**, **Every day**, **Every Sunday**, **Every Monday**, **Every Tuesday**, **Every Wednesday**, **Every Thursday**, **Every Friday**, or **Every Saturday**.

3. Select from the drop-down lists when the system automatically deletes the old files. Select either **Never** or **Customized**. If you select **Customized**, then you can enter how many days until the system next automatically deletes the old files.
4. Click **OK** to save the new settings.

Configuring Backup

With the **CONFIG BACKUP** function, you can copy the current system configuration to other devices. It also supports importing, creating new folders and, deleting folders.

1. Click **BACKUP** in the **ADVANCED** configuration interface. The **CONFIG BACKUP** configuration interface appears.

Figure 3-77 BACKUP Configuration Interface



2. Click to select a device, and then click **Export** or **Import**.

Shutting Down the NVR

1. Click **SHUTDOWN** in the **ADVANCED** configuration interface. The **SHUTDOWN** dialog box appears.

Figure 3-78 SHUTDOWN Dialog Box



2. Select from the drop-down menu.

Table 3-31 SHUTDOWN Selections

Selection	Description
Logout	Log out of the NVR. The next time you log in, you will need to enter a password.
Shutdown	The NVR shuts down and turns off the power.
Restart system	Reboots the system.
Switch user	Use another user account for logging in.

Note If you shut down the device, a process bar appears for your reference. The system waits for 3 seconds and then shuts down. You can not cancel the shut down sequence after it has begun.

Note You might need to enter your password to shut down the NVR.

4

Honeywell Configuration Tool

This chapter includes:

- Installing the Honeywell Configuration Tool.
- Opening the Honeywell Configuration Tool, and then using it to search for online IP devices.

Note The Honeywell Configuration Tool applies only to IP addresses that are in the same segment.

Starting the Honeywell Configuration Tool

You must install the Honeywell Configuration Tool before you can use it to discover IP devices.

Installing the Honeywell Configuration Tool


1. Insert the Software CD that came with your NVR into your PC. Navigate to and double-click **Honeywell Config Tool** to install the configuration tool software.
The **Honeywell Config Tool** installation wizard opens.

Figure 4-1 Honeywell Config Tool Wizard




2. Click **Next** to begin the installation. The **User License Agreement** page appears.

Figure 4-2 User License Agreement Page



3. Click to select **I agree**, and then click **Install** to install the software. The **Installation is Complete** page appears has been successful.

Figure 4-3 Installation is Complete Page

4. Click **Enjoy Now** to open and use the **Config Tool**.

Opening the Honeywell Configuration Tool, Searching for Devices, and Opening a Web Client

In the **Config Tool**, you will find the IP addresses for the IP devices (NVRs and IP cameras).


1. Click to  open the **Config Tool**.

Figure 4-4 Configtool Interface



The screenshot shows the Honeywell Configtool interface. At the top, there is a search bar and several buttons: Refresh, Login, Setting, and Upgrade. Below these is a search field with the text "Find number of devices: 9" and a dropdown menu set to "IPv4". The main part of the interface is a table with the following columns: SN, Type, Model, IP, Port, Gateway, MAC, and Config. The table contains 9 rows of device information.

SN	Type	Model	IP	Port	Gateway	MAC	Config
1	HEN161*1	HEN161*1	192.168.1.108	37777	192.168.1.1	90:02:a9:b8:5b:fa	⚙️ e
2	IPC	H2D2PR1V	192.168.1.205	37777	192.168.1.1	90:02:a9:3d:fc:7b	⚙️ e
3	IPC	HBD2PR1	192.168.1.201	37777	192.168.1.1	90:02:a9:2b:82:21	⚙️ e
4	IPC	HBD2PR1	192.168.1.65	37777	192.168.1.1	90:02:a9:2b:82:22	⚙️ e
5	IPC	HBD2PR1	192.168.1.129	37777	192.168.1.1	90:02:a9:38:cd:87	⚙️ e
6	IPC	H2D2PR1	192.168.1.203	37777	192.168.1.1	90:02:a9:21:ad:62	⚙️ e
7	IPC	H2D2PR1	192.168.1.131	37777	192.168.1.1	90:02:a9:21:ad:60	⚙️ e
8	HEN041*1	HEN041*1	192.168.1.11	37777	192.168.1.1	90:02:a9:8d:0b:d8	⚙️ e
9	HBD2PR1	HBD2PR1	192.168.1.67	37777	192.168.1.1	90:02:a9:2b:82:23	⚙️ e

2. Click  in the **Config** column for a device to open a **Web Client** for that device.

Upgrading a Single Device (IP Camera or NVR)

Note For the following, examples of upgrading an IP camera are shown. The procedures for upgrading an NVR are similar.

1. Open the **ConfigTool** software.

Figure 4-5 ConfigTool Login



The screenshot shows the Honeywell Configtool Login interface. The "Login" button is highlighted with a red box. Below it, a table lists devices, with the first row highlighted in blue. The "Login" button is also highlighted with a red box.

SN	Type	Model	IP	Port	Gateway	MAC	Config
1	IPC	IPC-HDW4200S-...	192.168.1.108	37777	192.168.1.1	90:02:a9:38:80:39	⚙️ e

2. Select from the list the device you want to upgrade.
3. Click **Login** to log in to the device.


Note If you do not select a device before clicking **Login**, you will get a **Connection Error** message.

Figure 4-6 Device Upgrade Login Interface




- 4. Click **OK**. The **Config Upgrade** interface appears.

Figure 4-7 Config Upgrade Interface




- 5. Click **OpenFile** to select the upgrade file, and then click **Upgrade** to begin the upgrade. When the upgrade is complete, and the device is rebooting a **Device is offline: [device IP address]** message appears.

Figure 4-8 Device Offline Message



6. Click **OK** to close the **Device Offline** warning message, and to return to the **Upgrade** interface.

Figure 4-9 Upgrade Interface



7. Log into the device again.

Note If you do not select a device before clicking **Login**, you will get a **Connection Error**.

Upgrading the IP Devices (Batch Upgrade)


Note For the following, examples of upgrading an IP camera are shown. The procedures for upgrading an NVR are similar.

1. Open the **ConfigTool** software if it is not already open.


Figure 4-10 ConfigTool Login



2. Click **Upgrade** to begin the batch upgrading process.
The **Upgrade** interface appears.


Figure 4-11 Upgrade Interface

3. Click **Open** to find and select the upgrade file.
The **Open** interface appears.

Figure 4-12 Open Interface

4. Select the upgrade firmware, and then click **Open** or double-click the file to open it.
The **Open** interface closes and you return to the **Upgrade** interface.


Figure 4-13 Upgrade Interface



- 5. Click to select the devices you want to upgrade. Their row turns blue when selected.
- 6. Click **Upgrade** to begin the batch upgrade.


A message appears in the **Upgrade State** fields for each selected IP camera to show the batch upgrade progress.

Figure 4-14 Batch Upgrade Progress Message



A message appears to show that the batch upgrade procedure is successful.

Figure 4-15 Batch Upgrade Successful Message



Modifying the IP Address


1. Open the **ConfigTool** software if it is not already open.

Figure 4-16 ConfigTool Login



- 2. Select from the list the device you want to modify.
- 3. Click **Login** to log in to the device.

Figure 4-17 Selecting Net in the ConfigTool



- 4. Click **Net** to open the Net tab.
- 5. Enter the new **IP Address**, and the corresponding **Subnet Mask** and **Gateway**.
- 6. Click **Save** to save these new settings.

5

Web Operation

This chapter includes:

- A description of the NVR web client.
- Descriptions about setting up and operating the NVR web client.

Preparing to Use the Device Web Client

PC Requirements

Table 5-1 PC Requirements

Component	Minimum Requirement
Processor	Quad core
System memory (RAM)	2G pr higher
Non-integrated video card	256M or higher

Before You Log In

Ensure that the following conditions are met:

- Ensure that the network connection is good.
- Ensure that the NVR and PC network setup is correct. See the network setup: **Main Menu > Setting > Network**.
- Ping to ensure that the network connection is good. Ping ***** **** (where ***** **** is the NVR's IP address). The return TTL should be less than 225.
- Open an IE browser and then enter the NVR's IP address.
- The system can automatically download the latest ActiveX web control. The new version can overwrite the previous one.
- If you want to un-install the web control, then run **uninstall webrec2.0.bat**. Or, you can go to **C:\Program Files\webrec** to remove the single folder.


Note Before you uninstall the web control, close all web pages. If you do not, then the uninstallation procedure might result in an error.

- The current NVR supports various browsers such as Apple Safari, Mozilla Firefox, and Google Chrome. The NVR supports only 1-channel monitoring on an Apple PC.

Logging In


1. Open a Web browser window.

Note These instructions were created using IE. You can use Internet Explorer (IE), Safari, Chrome, or FireFox.

Figure 5-1 IE Window


2. Enter the NVR IP address in the address field.
For example, if your NVR's IP address is **192.168.1.108**, then enter **http://192.168.1.108** in the address field.
A message pops up asking if you want to install **webrec.cab** control.
3. Click **Yes** to install **webrec.cab** control.
4. Configure the ActiveX control settings if you can not download the ActiveX files.

Figure 5-2 Configuring the ActiveX Controls



When installation is successful, the login interface appears.

Figure 5-3 Login Interface




5. Enter your username (default: **admin**) and password (default: **1234**).

Note For security, we recommend that you modify your password on your first log in.

LAN Mode

The LAN main window, which is divided into 9 main sections.

Figure 5-4 LAN Mode Main Window



Section 1: Function Buttons

Figure 5-5 LAN Main Window Function Buttons




There are six function tabs:

- **Preview:** You are currently in the Preview mode, where you can see all these tabs.
- **Playback:** See [Playing Back Recorded Video on page 150](#)
- **Alarm:** See [Enabling and Disabling Alarms on page 154](#)
- **Set:** See [Configuring Settings on page 155](#)
- **Information:** See [Configuring System Information on page 203](#)
- **Logout:** See [Logging Out on page 205](#)

Section 2: Monitor Channels


Figure 5-6 Monitor Channels Section



The Monitor Channels section displays monitor channels that are successfully connected to the NVR. Left-click to select a channel for viewing.

Section 3: Start Talk Button

Figure 5-7 Start Talk Button



Click to enable communication. Click ▼ in the control panel on the right to select the bi-directional communication mode. There are four options for the communication mode: **DEFAULT**, **G711a**, **G711u**, and **PCM**.

After you enable bi-directional communication, the system will not encode the audio data from that one channel. See [Bi-Directional Communication Connection on page 34](#) for the audio connections.

Section 4: Instant Record Button

Figure 5-8 Instant Record Button



Click **Instant Record**, and the button turns blue. The NVR begins manual recording. Click **Instant Record** again to restore the NVR to the previous recording mode.

Section 5: Local Play Button

The NVR can play back saved files (in the .dav format) in the PC.

1. Click **Local Play**, and an interface appears for selecting the playback file.

Figure 5-9 Local Play - Select a File Interface



2. Select a file, then click **Open**. A media player opens and plays the selected video.

Section 6: PTZ Control Panel







Not supported at this time.

Section 7: Image and Alarm Configuration Panels

See [Configuring Image/Alarm Out Settings on page 149](#) for more information.

Section 8: Viewer Configuration Controls

Table 5-2 Viewer Configuration Controls

Button	Name	Description
	Video Quality	Click to select the video quality. Select either High quality or Low quality.
	Fluency	Click to configure the fluency. Select from Fluency Level 1 , Fluency Level 2 , Fluency Level 3 , Middle level , Latency Level 1 , Latency Level 2 , and Latency Level 3 .
	Full Screen	Click to switch the viewer to show video full screen. Click Esc (on your PC) to quit full screen.
	Vertical Synchronization	Click to configure vertical synchronization.
	Single-channel Window	Click to switch to single channel viewing.
	Multi-channel Window	Click to switch to multi-channel viewing.

Real-Time Monitoring

Left-click a channel name in Section 2, the **Monitors Channel** section, to select that channel for viewing.

The video window shows statistics about the video.

Figure 5-10 Live View Video Window



Table 5-3 Live View Video Window Controls**Table 5-4 Live View Video Window Controls**

Control	Description
Display Device Information	Shows the following information about the video: <ul style="list-style-type: none"> • IP address • Channel number • Bit rate • Decoding mode: Select either M for Main stream or S for sub stream.
Digital Zoom	Click this button and then left drag the mouse in the zone to zoom in. Right-click the mouse to return to the original viewing status.
Local Record	When you click the Local Record button, the system/NVR begins recording. The recorded file is saved to the default system folder: \RecordDownload .
Snapshot	Click to take a snapshot of the currently viewed video. All images are saved to the default system folder: \picture download .
Audio	Turn audio On or Off . Note This control has nothing to do with the system audio setup.
Close Window	Close video in the current window.






Configuring Image/Alarm Out Settings

Select a monitor channel for video, and then click the Image button in section 9 of [Figure 5-4](#).

Configuring Image Settings

In the **Image** settings, you can adjust the brightness, contrast, hue, and saturation.

Figure 5-11 Image Settings**Table 5-5 Image Settings**

Setting	Description
	Adjusts the monitor's video brightness.
	Adjusts the monitor's video contrast.
	Adjusts the monitor's video hue.
	Adjusts the monitor's video saturation.
	Restores the system to its defaults value.

Note All of these configurations apply only to the Web viewer.

Configuring Alarm Output

1. Click to open the **Alarm Out** configuration interface.

Figure 5-12 Alarm Out Configuration Interface

2. Disable/enable the alarm signal for the corresponding port.

Playing Back Recorded Video


1. Click the **Playback** tab at the top of the **Main** window.
The **Playback** interface appears.

Figure 5-13 Playback Interface




2. Select a recording type, recording date, window display mode, and channel name to select video for playback.
3. Click **File List**, and the system displays a list of recorded video clips that match the search criteria from [step 2](#).

Figure 5-14 List of Recorded Video Clips



4. Select a file for playback, then click **Play** (▶). You can play back in full screen mode. Use the playback control bar to control playback.

Figure 5-15 Playing Back Video



Note For one-channel playback, the system can not play back and download at the same time.

Downloading Video

After generating a list of recorded video clips by clicking **File List** (see [Playing Back Recorded Video on page 150](#)), select the files you want to download, then click Download (▼).

Figure 5-16 Downloading Recorded Video




The **Download** button becomes the **Stop** button, and it indicates the downloading progress (in a percentage).

Go to your default **Saved Path** file to view the downloaded files. See [Configuring the Save Path on page 160](#).

Loading More

Click **More** in [Figure 5-16](#), and the **Download by File/Download by Time** interfaces appear.

Figure 5-17 Download by File/Download by Time Interfaces



In this window, you can search for recordings or snapshots. Select the channel, recording type, and the recording time.

Enabling and Disabling Alarms

Click the **Alarm** tab at the top of the **Main** window. The **Alarm** configuration interface appears.

Note For information about configuring alarms, see [Configuring Alarms on page 181](#).

Figure 5-18 Alarm Configuration Interface




Table 5-6 Alarm Configurations

Configuration Type	Configuration	Description
Alarm Type	Motion Detection	Click to enable Motion Detection . The system will then trigger an alarm when motion is detected under the specified circumstances.
	Video Masking	Click to enable Video Masking . The system triggers an alarm when camera masking occurs.
	Video Loss	Click to enable Video Loss . The system then an alarm when video loss occurs.
	External Alarm	Click to enable the camera's External Alarm , the On/Off signal from the network camera. It activates the NVR to locally activate.
	Disk Error	Click to enable the Disk Error alarm. The system triggers an alarm when a disk error occurs.
	Disk Full	Click to enable the Disk Full alarm. The system triggers an alarm when the disk is full.
	No Signal	Click to enable the No Signal alarm. The system triggers an alarm when the network camera and the NVR are disconnected.
Prompt	Prompt	Click to enable the Prompt . Then the system automatically pops up an alarm icon on the Alarm button on the Main interface when there is an alarm.
Alarm Sound	Alarm Sound	Click to enable the Alarm Sound . Then the system triggers an alarm sound when an alarm occurs. You can choose the sound.
	Sound Path	Select the sound file.

Configuring Settings

Click the **Set** tab at the top of the **Main** window. The **Set** configuration interface appears.

In the Set configuration interface, you can configure the following:

- Remote settings
- Audio and video encoding settings
- The save path
- Snapshot settings
- Video overlay settings
- Network settings, including wifi and 3G
- Email settings
- UPnP settings
- Automatic registration settings

Configuring Remote Settings

Remotely Adding a Device/Camera

1. Click the arrow beside **REMOTE** to expand the **REMOTE** selection tree.
2. Click **Add Device** to open the **Add Device** configuration interface.

Figure 5-19 Remotely Adding a Device Configuration Window




Table 5-7 Remote - Add Device Configurations

Configuration	Description
Device Search	Click Device Search , and you can view the device information for all found devices. You can see the camera's IP address, port, device name, manufacturer, and type.
Add	Select a device in the list, and then click Add to automatically connect to the camera and add it to the Added device list. Or you can double-click a camera in the list to add it to the Added device list.

Table 5-7 Remote - Add Device Configurations






Configuration	Description
Modify	Click  or any camera in the Added device list to open a configuration window to change the corresponding channel setup.
Delete	Click  to delete the remote connection for the corresponding channel.
Connection Status	 indicates that the connection was successful.  indicates that the connection was not successful.
Delete	Select a camera in the Added device list, and then click Delete . The system disconnects from the camera and removes it from the Added device list.
Manual Add	<ol style="list-style-type: none"> 1. Click Manual Add, and the Manual Add configuration interface appears. See Figure 5-20. 2. Select a channel from the drop-down list. Only disconnected channels are shown. <p>Note The NVR supports cameras from Honeywell, Panasonic, Sony, Dynacolor, Samsung, AXIS, Arecont, Dahua, and cameras with ONVIF-standard protocol.</p> <p>Note If you do not enter an IP address, the system uses the default IP address 192.168.0.0, and the system does not connect to this IP address.</p> <p>Note You can not add two devices at the same time. If you click OK, the system connects only to the camera for the currently selected channel.</p>

Figure 5-20 Manual Add Configuration Window


Remotely Configuring Video and Audio

Configuring Encoding for Video and Audio

Click **Video&Audio** in the **REMOTE** configuration interface to open the **Video&Audio** configuration interface.

Figure 5-21 Video&Audio Configuration Interface




Table 5-8 Video&Audio Configuration Interface


Configuration	Description
Channel	Select a channel from the drop-down list.
Code Stream Type	<ul style="list-style-type: none"> Select from Regular, Motion, and Alarm. You can select a different encoder frame rates for different recorded events. The system supports the active control frame function (ACF). It allows you to record in different frame rates. For example, you can use a high frame rate to record important events and a lower frame rate to record schedule events. The system allows you to set different frame rates for recording motion detection and recording alarms.
Video Enable	Check to enable the extra video stream. This is enabled by default.
Compression	The main bit stream supports H.264. The secondary stream supports H.264 or MJPG.
Resolution	This value refers to the capability of the network camera.
Frame Rate	PAL: 1–25 fps; NTSC: 1–30 fps
Bit Rate Type	Select either CBR or VBR .

Table 5-8 Video&Audio Configuration Interface

Configuration	Description
Bit Rate	<p>Main stream: Select a bit rate to change the video quality. The larger the bit rate, the better the quality. Please see the Referenced Bit Rate below.</p> <p>Extra stream: When in CBR mode, the bit rate here is the maximum value. When there is movement in the scene, the system needs to reduce the frame rate or video quality to maintain the bit rate. This is not available in VBR mode.</p>
Reference Bit Rate	The recommended bit rate value based on your settings for the resolution and the frame rate.

Configuring Snapshot Settings

Click the **Snapshot** tab on the **Video&Audio** configuration interface to open the **Snapshot** configuration interface.

Figure 5-22 Snapshot Configuration Interface**Table 5-9 Snapshot Configurations**

Configuration	Description
Channel	Select a channel from the drop-down list.
Mode	<p>There are two modes: Timing (schedule) and Trigger.</p> <p>Timing: The snapshot function is valid during the specified time period.</p> <p>Trigger: The snapshot function is only available as a result of an alarm, such as motion detection, tampering, or local activation.</p>
Image Size	This matches the resolution of the main stream.
Quality	Select from six levels of image quality.
Snapshot Frequency	Set the snapshot frequency, from 1 snapshot per second (SPL) to 7 SPL .

Configuring Video Overlay

Click **Overlay** in the **Video&Audio** configuration interface to open the **Video Overlay** configuration interface.

Figure 5-23 Video Overlay Configuration Interface**Table 5-10 Video Overlay Configurations**

Configuration	Description
Channel	Select a channel from the drop-down list.
Cover-Area	Click to enable the Monitor . Click Set to configure a privacy mask for the Preview or Monitor . The system supports up to four privacy mask zones.
Channel Display	Enable this function to overlay channel information on the video window. Use the mouse to drag the channel title to the desired position. View the channel title on the live web client video or the playback video.
Time Display	Enable this function to overlay time information on the video window. Use the mouse to drag the time display to the desired position. View the time display on the live web client video or the playback video.

Configuring the Save Path

Click **Path** in the **Video&Audio** configuration interface to open the **Path** configuration interface.

Figure 5-24 Path Configuration Interface




Click **Browse** to configure a new save path for snapshots or recorded video. The default locations are **C:\PictureDownload** and **C:\RecordDownload**.

Click **Save** to save any changes.

Configuring the Channel Name

Click **Channel Name** in the **Video&Audio** configuration interface to open the **Channel Name** configuration interface.

Figure 5-25 Channel Name Configuration Interface



Click **Browse** to select the upgrade file. Or use the filter to select several network cameras for upgrading at the same time.

Configuring Network Settings

Click the **Network** arrow to expand the **Network** selection tree.

Configuring TCP/IP Settings

Click **TCP/IP** in the **Network** configuration interface to open the **TCP/IP** configuration interface.

Figure 5-26 TCP/IP Configuration Interface

Table 5-11 TCP/IP Configurations

Configuration	Description
Mode	<p>There are two modes: Static and DHCP.</p> <ul style="list-style-type: none"> The IP address, submask, and gateway is inactive and not configurable when you select the DHCP mode to automatically search for the IP address. If you select Static mode, then you need to manually configure the IP address, submask, and gateway. If you select DHCP mode, then you can only view the IP address, submask, and gateway. You can not configure these values. If you switch from the DHCP mode to the static mode, then you need to reset the IP parameters. The IP address, submask, gateway, and DHCP are read-only values when the PPPoE dial is OK.
MAC Address	Displays the MAC address. This field is not configurable.
IP Version	<p>Select the IP version, either IPv4 or IPv6.</p> <p>You can use either version to access the camera's IP address.</p>
IP Address	<ol style="list-style-type: none"> Use your PC's keyboard to enter the IP address. Set the Subnet mask and Default gateway.
Preferred DNS	Enter the DNS IP address.
Alternate DNS	Enter an alternate DNS IP address.
Note	For the IPv6 version IP address, the Preferred DNS and Alternate DNS shall be no more the 128 digits. They also can not be left blank.
LAN Download	Enable this function so that the system can process the downloaded data first. The download speed is 1.5X or 2.0X of the normal speed.

Configuring the Network Connection

Click **Connection** in the **Network** configuration interface to open the **Connection** configuration interface.

Figure 5-27 Connection Configuration Interface

The screenshot shows the 'Connection' configuration interface. It features a table of configuration items with input fields and ranges. At the bottom, there are three buttons: 'Save', 'Refresh', and 'Default'.

Configuration	Value	Range
Max Connection	20	(0~20)
TCP Port	37777	(1025~65535)
UDP Port	37778	(1025~65535)
HTTP Port	80	(1~65535)
HTTPS Port	443	(128~65535)
RTSP Port	554	(128~65535)
RTSP Format	rtsp://<Username>:<Password>@<IP Address>:<Port>/cam/realmonitor?channel=1&subtype=0 channel: Channel, 1-4; subtype: Code-Stream Type, Main Stream 0, Extra Stream 1.	

Table 5-12 Network Connection Configurations

Configuration	Description
Max Connection	The maximum Web connection for the same NVR. The value ranges from 1 to 120. The default is 120.
TCP Port	The default is 37777. You can enter the actual port number, if necessary.
UDP Port	The default is 37778. You can enter the actual port number, if necessary.
HTTP Port	The default is 80. You can enter the actual port number, if necessary.
HTTPS Port	The default is 443. You can enter the actual port number, if necessary.
RTSP Port	The default is 554.

Configuring Wifi

Note This section applies only to devices with Wifi capability, such as tablet computers, smartphones, and laptop computers.

1. Click **Wifi** in the **Network** configuration interface to open the **Wifi** configuration interface.

Figure 5-28 Wifi Configuration Interface

2. Click to enable **Wifi**.
3. Click **Search SSID** to generate a list of all the wireless network information.
4. Double-click the name of a wireless device to connect to it.

Note Click **Refresh** to update the list of wireless network information.

Configuring CDMA/GPRS for 3G

1. Click **3G** in the **Network** configuration interface to open the **3G** configuration interface.
2. Click the **CDMA/GPRS** tab to open the **CDMA/GPRS** configuration interface.

Figure 5-29 CDMA/GPRS Configuration Interface
Table 5-13 CDMA/GPRS Configurations

Configuration	Description
WLAN Type	Select a 3G network type to distinguish this 3G module from different ISPs. Choose from WCDMA , CDMA1x , for example.
APN & Dial No.	APN and the Dial No. are important PPPoE parameters. The APN (Access Point Name) and the Dial No. are automatically received by the NVR after connecting to a 3G module.
AUTH	Authorization. Choose from PAP , CHAP , or NO_AUTH .
Pulse Interval	Configure a time for ending the 3G connection after you close the extra stream monitor. For example, if you select 60 here, the NVR ends the 3G connection 60 seconds after you close the extra stream monitor.
Note	If the Pulse Interval is 0 , then the system does not end the 3G connection after you close the extra stream monitor.
Note	The Pulse Interval here is for the extra stream only. This field is inactive if you are using a main stream monitor.

Configuring the Mobile Setup for 3G

Click the **Mobile Setup** tab in the **Network Configuration** interface to open the **Mobile Setup** configuration interface.

Figure 5-30 Mobile Setup Configuration Interface

Activate/deactivate 3G connected phones or mobile phones, or the phone you configured to get alarm messages.

Configuring PPPoE

1. Click **PPPoE** in the **Network** configuration interface to open the **PPPoE** configuration interface.

Figure 5-31 PPPoE Configuration Interface

2. Enter the **PPPoE User name** and **Password**, which you receive from your Internet Service Provider (ISP).
3. Enable the **PPPoE** function.
4. Click **Save** to save the changes.
5. **Reboot** the device to activate these changes.

After rebooting, the device should connect to the Internet through the PPPoE connection. The IP address is found in the WAN from the IP address column.

Note You need to use the previous IP address in the LAN to log into the device. Go to the IP address field, which is found in the device's current device information. You can access the NVR through this new address.

Configuring DDNS

Use DDNS to connect the various servers so that you can access the system through the server.

1. Go to the corresponding service website to apply for a domain name.
2. Access the system through that domain name.

Note This works even if your IP address has changed.

3. Select **DDNS** from the drop-down list.

Table 5-14 DDNS Configuration Options

Configuration	Description
DDNS Type	Select the DDNS protocol from the drop-down list, then enable the DDNS function.
Server IP	The DDNS server IP address.
Domain Mode	The DDNS server port.
Domain Name	Your self-defined domain name.
Email Address	Server email address.

Honeywell DDNS

The Honeywell DDNS function works with a special DDNS server and special Professional Surveillance Software (PSS).

Click **DDNS** in the **Network** configuration interface to open the **PPPoE** configuration interface.

Figure 5-32 DDNS Configuration Interface

Operation Before you can use Honeywell DDNS, you need to enable this service and configure the proper server address, port value, and domain name.

Table 5-15 DDNS Configurations

Parameter	Description
DDNS Type	You can select the DDNS protocol from the drop-down list, and then enable the DDNS function. Select the Honeywell DDNS server (which is free) to enable the DDNS function.
Server IP	This is the DDNS server IP address. Under Honeywell DDNS , the default server address is www.hennvr-ddns.com .
Domain Mode	Select Default Domain or Custom Domain Name . The default is Default Domain . If you select Custom Domain Name , then you must enter a domain name.
Domain Name	The default domain name is MAC address.hennvr-ddns.com . You can define the prefix.
Username	The user name you enter to log in the server (Optional).


Note Do not register frequently. You need to wait at least 60 seconds between registration requests. Too many registration requests might leave your server vulnerable to attacks.

Note The system DDNS server might take back a domain name that is idle for one year. If you configure your email address in the DDNS configuration, you will get a notification email before the domain name is taken back.

Configuring the IP Filter

1. Click **IP Filter** in the **Network** configuration interface to open the **IP Filter** configuration interface.

Figure 5-33 IP Filter Configuration Interface



2. Click to enable **Trusted Sites**, and only the listed IP addresses can access the current NVR.
OR
Click to enable **Blocked Sites**, and the listed IP addresses can not access the current NVR.

Configuring Email Settings

Click **Email** in the **Network** configuration interface to open the **Email** configuration interface.

Figure 5-34 Email Configuration Interface.
Table 5-16 Email Configurations

Parameter	Description
Enable	Click to enable the email function.
SMTP server	Enter the email SMTP server IP.
Port	Enter the corresponding port.
Anonymous	Only available if the server supports the anonymity function. This function allows you to automatically log in anonymously, so you do not need to enter your user name, password, or sender's information.
User Name	Enter the user name for logging in to the sender's email box.
Password	Enter the login password here.
Sender	Enter the sender's email address.
Encrypt Type	Select from NONE , TLS , or SSL .
Title	Enter an email subject. You can use up to 32 letters or numbers.
Attachment	Click to enable so that a snapshot can be attached to the email.
Receiver	Enter the receiver's email address. You can enter up to 3 email boxes.

Table 5-16 Email Configurations

Parameter	Description
Interval	<p>The interval for sending ranges from 0 to 3600 seconds. 0 means that there is no interval.</p> <p>Note The system will not send an email immediately when the alarm occurs. When an alarm, motion detection, or video abnormality triggers an email, the system sends out the email according to the interval that is specified here. This function is very useful when there are too many emails activated by events, which might result in an overload for the email server.</p>
Health email enable	<p>Click to enable the email health check. The NVR sends a test email to check the network connection.</p> <p>After enabling Health Enable, you can configure how frequently the NVR sends out emails to test the network connection.</p>
Test	<p>Click Test to send a test email. A popup message appears to indicate the state of the network connection.</p>

Configuring UPnP

UPnP allows you to establish the mapping relationship between the LAN and the public network. Here you can also add, modify, or remove a UPnP item.

Preparing for UPnP

1. In the Windows OS, click **Start > Control Panel > Add or remove programs**.
2. Click **Add/Remove Windows Components**, and then select **Network Services** from the **Windows Component Wizard**.
3. Click **Details**, then check **Internet Gateway Device Discovery and Control client and UPnP User Interface**. Then click **OK** to begin the installation.
4. Enable **UPnP** from the internet. If your UPnP is enabled in the Windows OS, then the NVR can automatically detect it through the **My Network Places**.
5. Click **UPnP** in the **Network** configuration interface to open the **UPnP** configuration interface.

Configuring UPnP

Figure 5-35 UPnP Configuration Interface

The screenshot displays the UPnP configuration interface. At the top, there are radio buttons for 'Enable' (selected) and 'Disable'. Below this, the 'Status' is set to 'Disable'. There are input fields for 'LAN IP' and 'WAN IP', both showing '0 . 0 . 0 . 0'. A 'Port Mapping List' table is shown with columns for 'No.', 'Service Name', 'Protocol', 'Internal Port', 'External Port', 'Modify', and 'Delete'. The table contains seven entries, each with a checked checkbox in the 'No.' column. Below the table are buttons for 'Add', 'Save', 'Refresh', and 'Default'.

No.	✓	Service Name	Protocol	Internal Port	External Port	Modify	Delete
1	✓	HTTP	TCP	80	80		
2	✓	TCP	TCP	37777	37777		
3	✓	UDP	UDP	37778	37778		
4	✓	RTSP	UDP	554	554		
5	✓	RTSP	TCP	554	554		
6	✓	SNMP	UDP	161	161		
7	✓	HTTPS	TCP	443	443		

Configuring SNMP

SNMP allows the communication between the network management work station software and the proxy of the managed device. It is reserved for a third party developer.

Click **SNMP** in the **Network** configuration interface to open the **SNMP** configuration interface.

Figure 5-36 SNMP Configuration Interface

The screenshot shows the SNMP configuration interface with the following settings:

- Enable:**
- SNMP Port:** 161 (range 0-65535)
- Read Community:** public
- Write Community:** private
- Trap Address:** 192.168.0.1
- Trap Port:** 162 (range 0-65535)
- SNMP Version:** V1 V2

Buttons at the bottom: Save, Refresh, Default.

Table 5-17 SNMP Configurations

Configuration	Description
SNMP Port	The listening port of the proxy program of the NVR. It is a UDP port, not a TCP port. This value ranges from 1 to 65535 . The default is 161 .
Read Community	This is a string, and it is a command between the managing processes and the proxy process. Read Community defines the authentication, the access control, and the management relationship between one proxy and one managers' group. Ensure that the device and the proxy are the same. The Read Community reads all the objects the SNMP supports in the specified name. The default is Public .
Write Community	This is a string, and it is a command between the managing processes and the proxy process. It defines the authentication, the access control, and the management relationship between one proxy and one manager's group. Ensure that the device and the proxy are the same. The Write Community reads, writes, and/or accesses all of the objects the SNMP supports in the specified name. The default is Write .
Trap Address	The Trap information destination address from the device's proxy program.
Trap Port	The Trap information destination port from the device's proxy program. The Trap port allows the gateway device and the client-end PC in the LAN to exchange information.
SNMP Version	If you check V1 , the system processes only the V1 information. If you check V2 , the system processes only the V2 information.

Configuring Multicast

Multicast is a transmission mode for data packets. When there are multiple hosts to receive the same data packets, multiple cast is the best option for reducing the bandwidth and the CPU load. The source host can send out just one data for transit. This function also depends on the relationship of the group member and the router group.

Click **Multicast** in the **Network** configuration interface to open the **Multicast** configuration interface.

Figure 5-37 Multicast Configuration Interface

Configuring Auto Registration Settings

Auto Register allows the device to automatically register to the proxy you have specified. This allows you to use the client-end to access the NVR through the proxy. The proxy acts as a switch. In network service, the device supports IPv4 server addresses or domains.

Click **Auto Register** in the **Network** configuration interface to open the **Auto Register** configuration interface.

Figure 5-38 Auto Register Configuration Interface

Configuring Events

Click the **Event** arrow to expand the **Event** selection tree.

Configuring Detection Settings

Configuring for Motion Detection

You can configure the system to generate a motion detection alarm when the minimum amount of motion (as defined by you) is detected in the video.

Click **Detect** in the **Event** configuration interface to open the **Detect** configuration interface.

Figure 5-39 Detect Configuration Interface

The screenshot displays the Honeywell web interface for configuring motion detection. The top navigation bar includes 'Preview', 'Playback', 'Alarm', 'Set', 'Info', and 'Logout'. The left sidebar shows a tree view with 'Event' expanded and 'DETECT' selected. The main content area is titled 'Motion Detect' and includes the following settings:

- Enable:** A checkbox that is currently unchecked, with a dropdown menu set to '1'.
- Period:** A 'Set' button.
- Sensitivity:** A dropdown menu set to '3'.
- Region:** A 'Set' button.
- Record Channel:** A checked checkbox with a 'Set' button.
- Delay:** An input field with '10' and the label 'Second (10-300)'.
- Alarm Out:** A checkbox that is unchecked, with a dropdown menu set to '2' and '3'.
- Latch:** An input field with '10' and the label 'Second(1-300)'.
- PTZ Activation:** A 'Set' button.
- Tour:** A 'Set' button.
- Snapshot:** A 'Set' button.
- Show Message:** A checkbox that is unchecked, with sub-options for 'Send Email' and 'Buzzer'.

At the bottom of the configuration area, there are four buttons: 'Copy', 'Save', 'Refresh', and 'Default'.

Table 5-18 Motion Detection Configurations

Configuration	Description
Enable	Click to enable motion detection. Select a channel from the drop-down list.
Period	<p>Define a period during which motion detection is active.</p> <ol style="list-style-type: none"> Click Set. The Set configuration interface appears. <div data-bbox="812 537 1321 1291" data-label="Image"> </div> Select a day of the week from the drop-down menu. Select from a day of the week, Work Day, or Free Day. <p>Note If you select Work Day or Free Day, a Set button appears so you can configure which days are Work Days and which days are Free Days. Click Set, select the Work Days and the Free Days, then click OK.</p> <p>Note You can configure up to 6 periods within one day.</p> Configure a time range for when the event detection area is active, then click the check box to select that time range. Click Save.
Sensitivity	Select from six levels of sensitivity. The higher the number, the higher the sensitivity.

Table 5-18 Motion Detection Configurations

Configuration	Description
Region	<ol style="list-style-type: none"> Select a motion detection type. Click Set. The Motion Detection Set configuration interface appears. <div data-bbox="812 436 1258 846" data-label="Image"> </div> Select the event detection area by left-clicking and dragging the mouse. <p>There are 396 (PAL) or 330 (NTSC) small zones.</p> <p>Green: Indicates the current cursor position.</p> <p>Grey: Indicates the event detection zone.</p> <p>Black: Indicates a disarmed zone.</p> <p>Note Use the FN button on the NVR's front panel to switch the cursor between selecting and deselecting.</p> <p>Note When the alarm is armed, you can use the directional buttons on the NVR to move the green motion detection rectangle.</p> Click Save to save the configurations. Click Esc to exit the setup without saving the changes.
Record Channel	<p>The system automatically starts recording selected channels when a motion detection alarm occurs.</p> <p>Note You need to set the motion detection recording period. Go to Storage > Schedule to configure the current channel for scheduled recording. See Configuring Local Storage for Schedules on page 189.</p>
Delay	<p>The system can delay recording for a specified amount of time after an alarm has ended. Select from 10s to 300s.</p>
Alarm Out	<p>Select the device output port, from 1 to 3. Select the corresponding port(s) so the system can activate the corresponding alarm devices when an alarm occurs.</p>
Latch	<p>The system can delay the alarm output for a specified time after an alarm ends. The value ranges from 1s to 300s.</p>

Table 5-18 Motion Detection Configurations




Configuration	Description
PTZ Activation (not supported)	<p>When PTZ activation is configured, the system can activate PTZ operation when an alarm is detected.</p> <ol style="list-style-type: none"> Click Set to open the PTZ Activation configuration interface.  <ol style="list-style-type: none"> Select a preset, tour, or pattern from the drop-down menu. Click Save.
Tour	<p>Click to enable a tour to be triggered by an alarm. The system supports 1/8-window tour. See Configuring Display Settings on page 199 for tour interval setup. On the Display Settings tab, when there are two tours enabled by default, you can configure the system so an alarm triggers the system to enable the alarm tours you configured here. If there is no alarm, then the system uses the tour setup that was configured in the Display interface.</p> <ol style="list-style-type: none"> Click Setup to select a tour channel. The system begins a 1-window or multiple-window tour display showing the channels you've set to record when an alarm occurs.  <ol style="list-style-type: none"> Click to select a channel, or All, then click Save.

Table 5-18 Motion Detection Configurations

Configuration	Description
Snapshot	<p>Click to enable the Snapshot function. A snapshot will be taken when an alarm occurs.</p> <ol style="list-style-type: none"> Click Set to open the Snapshot Configuration interface.  <ol style="list-style-type: none"> Click to select a channel, or All, then click Save.
Show Message	Click to enable a pop-up message on your local host PC screen to let you know an alarm has occurred.
Send Email	The system can send an email when an alarm is detected. When you have enabled the Snapshot function, the system can also send an image attached to the email. Go to Main Menu > Setting > Network > Email to configure the email settings. See Configuring Email Settings on page 169 .
Buzzer	Click to enable the Buzzer function. When an alarm occurs, the buzzer beeps.

Configuring for Video Loss Detection

You can configure the system to generate a video loss alarm when the minimum amount of video loss (as defined by you) is detected in the video.

Note Video loss does not support anti-dither, sensitivity, or region setup.

Click **Video Loss** in the **Event** configuration interface to open the **Video Loss** configuration interface.

Figure 5-40 Video Loss Configuration Interface

The configuration for **Video Loss Detection** is very similar to the configuration for **Motion Detection**. Please see [Configuring for Motion Detection on page 175](#) for more information.

Configuring for Camera Masking

You can configure the system to generate a camera masking alarm when the minimum amount of masking (as defined by you) is detected in the video.

Click **Camera Masking** in the **Event** configuration interface to open the **Camera Masking** configuration interface.

Figure 5-41 Camera Masking Configuration Interface

The configuration for **Camera Masking Detection** is very similar to the configuration for **Motion Detection**. Please see [Configuring for Motion Detection on page 175](#) for more information.

Configuring Alarms

Before configuring alarms, ensure that you have properly connected alarm devices such as a buzzer. You can configure local and network alarms.

Click **Alarm** in the **Event** configuration interface to open the **Alarm** configuration interface.



Configuring Local Alarms

Click **Local Alarm** in the **Alarm** configuration interface to open the **Local Alarm** configuration interface.

Figure 5-42 Local Alarm Configuration Interface
Table 5-19 Local Alarm Configurations

Configuration	Description
Enable	Click to enable local alarms. Select a channel from the drop-down list.
Period	<p>Define a period during which local alarms are active.</p> <ol style="list-style-type: none"> Click Set. The Set configuration interface appears. Select a time period. <p>Note You can configure up to 6 periods within one day.</p> <ol style="list-style-type: none"> Select a date. If you do not select a date, the current setup will apply to today only. <p>Note You can select All Week if you want these settings to apply to the whole week.</p> <ol style="list-style-type: none"> Click OK, then click Save.
Type	Select from NO or NC .
Record Channel	<p>When an alarm occurs, the system automatically records motion detection channels.</p> <p>Note You need to set the motion detection recording period. Go to Storage > Schedule to configure the current channel for scheduled recording. See Configuring Local Storage for Schedules on page 189.</p>
Delay	The system can delay recording for a specified amount of time after an alarm has ended. Select from 10s to 300s .

Table 5-19 Local Alarm Configurations

Configuration	Description
Alarm Out	Select the device output port, from 1 to 3 . Select the corresponding port(s) so the system can activate the corresponding alarm devices when an alarm occurs.
Latch	The system can delay the alarm output for a specified time after an alarm ends. The value ranges from 1s to 300s .
PTZ Activation (not supported)	5.
Tour	<p>Click to enable a tour to be triggered by an alarm. The system supports 1/8-window tour. See Configuring Display Settings on page 199 for tour interval setup. On the Display Settings tab, when there are two tours enabled by default, you can configure the system so an alarm triggers the system to enable the alarm tours you configured here. If there is no alarm, then the system uses the tour setup that was configured in the Display interface.</p> <ol style="list-style-type: none"> Click Setup to select a tour channel. The system begins a 1-window or multiple-window tour display showing the channels you've set to record when an alarm occurs.  <ol style="list-style-type: none"> Click to select a channel, or All, then click Save.
Snapshot	<p>Click to enable the Snapshot function. A snapshot will be taken when an alarm occurs.</p> <ol style="list-style-type: none"> Click Set to open the Snapshot Configuration interface.  <ol style="list-style-type: none"> Click to select a channel, or All, then click Save.
Show Message	Click to enable a pop-up message on your local host PC screen to let you know an alarm has occurred.
Send Email	The system can send an email when an alarm is detected. When you have enabled the Snapshot function, the system can also send an image attached to the email. Go to Main Menu > Setting > Network > Email to configure the email settings. See Configuring Email Settings on page 169 .
Buzzer	Click to enable the Buzzer function. When an alarm occurs, the buzzer beeps.

Configuring Net Alarms

Configure **Network Alarms** so that the NVR can detect alarm signals from the network. The system does not support anti-dither and sensor type setup.

Click **Net Alarm** in the **Alarm** configuration interface to open the **Net Alarm** configuration interface.

Figure 5-43 Net Alarm Configuration Interface

The screenshot shows the 'Net Alarm' configuration interface. It features four tabs: 'Local Alarm', 'Net Alarm' (which is active), 'IPC External Alarm', and 'No Signal'. The 'Net Alarm' tab contains several configuration options:

- Enable:** A checked checkbox.
- Period:** A dropdown menu set to '1'.
- Record Channel:** A 'Set' button.
- Delay:** A text input field with '10' and the label 'Second (10-300)'.
- Alarm Out:** A checked checkbox and three buttons labeled '2' and '3'.
- Latch:** A text input field with '10' and the label 'Second(1-300)'.
- PTZ Activation:** A 'Set' button.
- Tour:** A 'Set' button.
- Snapshot:** A 'Set' button.
- Show Message:** Two unchecked checkboxes labeled 'Send Email' and 'Buzzer'.

At the bottom of the interface are four buttons: 'Copy', 'Save', 'Refresh', and 'Default'.

The configuration for **Net Alarms** is very similar to the configuration for **Local Alarms**. Please see [Configuring Local Alarms on page 181](#) for more information.

Configuring External Alarms

Configure the **External Alarms** so that the NVR can detect alarm signals from the IP cameras. The system does not support anti-dither and sensor type setup.

Click **IPC External Alarm** in the **Alarm** configuration interface to open the **IPC External Alarm** configuration interface.

Figure 5-44 IPC External Alarm Configuration Interface

The configuration for **IPC External Alarms** is very similar to the configuration for **Local Alarms**. Please see [Configuring Local Alarms on page 181](#) for more information.

Configuring for No Signal

The system can generate an alarm if the network camera goes offline.

Click **No Signal** in the **Alarm** configuration interface to open the **No Signal** configuration interface.

Figure 5-45 No Signal Configuration Interface

The configuration for **No Signal Alarms** is very similar to the configuration for **Local Alarms**. Please see [Configuring Local Alarms on page 181](#) for more information.

Configuring for Abnormalities

Click **Abnormality** in the **Event** configuration interface to open the **Abnormality** configuration interface.

There are six types of abnormalities:

- No Disk
- Disk Error
- No Space
- Net Disconnection
- IP Conflict
- MAC Conflict

You can configure how the system responds to each kind of abnormality. The configuration is similar for each type.

Figure 5-46 Configuring for Abnormalities

Note The **No Disk** configuration interface is shown here as an example. The other configuration interfaces, and the configuration done on the interfaces, are similar.

Table 5-20 Configuring for Abnormalities

Configuration	Description
Event Type	Select from No Disk , Disk Error , Disk No Space , Net Disconnection , IP Conflict , and MAC Conflict . Less Than: (For No Space configuration only) Configure the minimum percentage of free space on the disk. An alarm lets you know when the disk capacity is low. You need to click to enable this function.
Enable	Click to enable this function.
Alarm Out	Select the device output port, from 1 to 3 . Select the corresponding port(s) so the system can activate the corresponding alarm devices when an alarm occurs.
Latch	The system can delay the alarm output for a specified time after an alarm ends. The value ranges from 1s to 300s .

Table 5-20 Configuring for Abnormalities

Configuration	Description
Show Message	Click to enable a pop-up message on your local host PC screen to let you know an alarm has occurred.
Alarm Upload	The system can upload the alarm signal to the center (including the alarm center).
Send Email	The system can send an email when an alarm is detected. When you have enabled the Snapshot function, the system can also send an image attached to the email. Go to Main Menu > Setting > Network > Email to configure the email settings. See Configuring Email Settings on page 169 .
Buzzer	Click to enable the Buzzer function. When an alarm occurs, the buzzer beeps.

Configuring Storage

Click the **Storage** arrow to expand the **Storage** selection tree.


Configuring Schedules for Storage

You can add or remove schedules for recording.

There are four recording modes: **General** (auto), **Motion Detect**, **Alarm**, and **MD&Alarm**.

1. Click **Schedule** in the **Storage** selection tree to open the **Schedule** configuration interface.


Figure 5-47 Schedule Configuration Interface



The schedules are color-coded by type:

- **Green:** General recording/snapshot.
 - **Yellow:** Motion detection recording/snapshot.
 - **Red:** Alarm recording/snapshot.
 - **Blue:** MD&Alarm recording/snapshot.
2. Click **Set**. The **Set** configuration interface opens.

Figure 5-48 Set Configuration Interface



- Configure the schedule, then click **Save**.

Table 5-21 Schedule Configurations


Configuration	Description
Channel	Select a channel from the drop-down list.
Regular	Check to enable the Regular schedule mode.
Motion	Check to enable the Motion Detection schedule mode.
Alarm	Check to enable the Alarm mode.
MD&Alarm	Check to enable the MD&Alarm mode.

- Click **Save** to save the settings, and then click **Save** to save the **Schedule** configuration.

Configuring Local Storage for Schedules

Click **Local Storage** in the **Schedule** configuration interface to open the **Local Storage** configuration interface.

Figure 5-49 Local Storage Configuration Interface for Schedules




You can see the HDD information, and you can select the read-only / write-only redundancy (if there is more than one HDD), and formatting.

Configuring the HDD Group Settings

Click **HDD Setting** in the **Schedule** configuration interface to open the **HDD Setting** configuration interface.

Figure 5-50 HDD Setting Configuration Interface



Select the HDD group in which you want to save the recording.

Configuring Recording Settings

Click **Record** in the **Schedule** configuration interface to open the **Record** configuration interface.

Figure 5-51 Record Configuration Interface for Storage Settings

Section	Option	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Main Stream	Auto	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
	Manual	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	Off	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Extra Stream	Auto	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	Manual	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	Off	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>
Snapshot	Enable	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	Disable	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>

Table 5-22 Recording Configurations for Storage

Configuration	Description
Channel	View the channel number. The number displayed here is the maximum number of channels for your NVR.
Status	Select a status: Auto , Manual , or Off .
Auto	The system enables the automatic recording function, which you have set in the Recording Schedule setup (such as general, motion detection, and alarm settings). See Configuring the General Settings on page 63 , Configuring Detection Settings on page 175 , and Configuring Alarms on page 181 .
Manual	This is the highest priority setting. Enable the corresponding channel to record, no matter the period that was configured in the Recording setup.
Off	Stop the corresponding channel from recording, no matter the period that was configured in the Recording setup.

Configuring the Channel for Schedules

Click **Channel** in the **Schedule** configuration interface to open the **Channel** configuration interface.

Figure 5-52 Channel Configuration Interface

Configuring the Main Stream Channel

Select an **HDD Group** from the drop-down menu, then click **Save**. See [Figure 5-52](#).

Configuring the Extra Stream Channel

You can select the corresponding HDD group for the sub stream.

1. Click the **Extra Stream** tab to open the **Extra Stream** configuration interface.

Figure 5-53 Extra Stream Configuration Interface

2. Select an **HDD Group** from the drop-down menu, then click **Save**.

Configuring the Image Storage Channel

You can select the corresponding HDD group for saving snapshots.

1. Click the **Image Storage** tab to open the **Image Storage** configuration interface.

Figure 5-54 Image Storage Configuration Interface

2. Select an **HDD Group** from the drop-down menu, then click **Save**.

Configuring Settings

In the **Settings** configuration interface, you can configure:

- **General** settings such as the device's name, number, language, video standard, date and time settings, and holidays. See [Configuring General Settings on page 192](#).
- **Account** settings for different users, including privileges, passwords, and groups. See [Configuring Account Settings on page 195](#).
- **Display** settings such as the GUI settings, monitor settings, tour settings, and zero-channel encoding. See [Configuring Display Settings on page 199](#).
- **Alarm Out** settings such as the alarm output mode (auto/manual/stop). See [Enabling and Disabling Alarm Out Settings on page 200](#).
- **Default** settings for the network, events, storage, the system configuration, and cameras. See [Returning to Default Settings on page 201](#).
- **Configuration Backup** settings for importing and exporting the configuration files. See [Configuring Backup Settings on page 201](#).
- **Automatic Maintenance** settings such as automatic rebooting and automatically deleting files. See [Configuring Automatic Maintenance Settings on page 202](#).
- **Pan/Tilt/Zoom** settings such as PTZ encoding, channel, type, and bit rates. See [Configuring Preview Control Settings on page 202](#). (not supported)
- **Preview Control** settings such as single channel view or multiple channel view. See [Configuring Preview Control Settings on page 202](#).

Configuring General Settings

Click the **General** arrow to expand the **General** selection tree.

Figure 5-55 General Settings

The screenshot displays the Honeywell NVR configuration interface. At the top, there is a navigation bar with buttons for 'Preview', 'Playback', 'Alarm', 'Set', 'Info', and 'Logout'. Below this, a sidebar menu on the left lists various settings categories: REMOTE, NETWORK, Event, STORAGE, SETTING (expanded), GENERAL (selected), ACCOUNT, DISPLAY, Alarm Out, DEFAULT, CONFIG BACKUP, AUTO MAINTAIN, PAN/TILT/ZOOM, and Preview Control. The main content area is titled 'GENERAL' and contains the following settings:

Setting	Value
Device Name	NVR
Device No.	8
Language	ENGLISH
Video Standard	PAL
HDD Full	OverWrite
Pack Duration	60 Minute

At the bottom of the settings area, there are three buttons: 'Save', 'Refresh', and 'Default'.

General Settings

Table 5-23 General Settings Configurations

Configuration	Description
Device Name	Enter a device name.
Device No.	Enter a channel number.
Language	Select a GUI language from the drop-down list. Note You need to reboot the device/NVR to activate this change.
Video Standard	Select the video standard, either NTSC or PAL .
HDD Full	Select what happens when the NVR's storage is full. Select either Stop Recording or OverWrite . Stop Recording: If the HDD is full, the NVR stops recording. OverWrite: If the currently working HDD is full and the next HDD is also full, the NVR overwrites the previous files.
Pack Duration	Select the recording duration. Select from 1 to 120 minutes. The default is 60 minutes.

Date & Time Settings

Click the **Date & Time** tab in the **General** settings configuration interface to open the **Date & Time** configuration interface.

Figure 5-56 Date & Time Configuration Interface

Table 5-24 Date & Time Configurations


Configuration	Description
Date Format	Select the date format from the drop-down list.
Time Format	Select from either 24 hour or 12 hour .
Date Separator	Select from a period (.), a hyphen (-), or a slash (/).
System Time	Set the NVR's time. You have to Save to activate this setting.
Sync PC	Click to synchronize your NVR's time with your PC's time.

Table 5-24 Date & Time Configurations

Configuration	Description
Time Zone	Select a Time Zone for the NVR.
DST	Click to enable Daylight Saving Time (DST). Click to select a type, either Date or Week . Then configure a date and time when DST begins and ends.
NTP	Click to enable the NTP server.
NTP Server	Enter the NTP time server address.
Port	Enter the NTP time server port.
Upgrade Period	Configure the synchronization period between the NVR and the NTP time server.

Holiday Settings

1. Click the **Holiday Settings** tab in the **General** settings configuration interface to open the **Holiday Settings** configuration interface.

Figure 5-57 Holiday Settings Configuration Interface

2. Click on a date to add a holiday, then click **Save**.


Configuring Account Settings

Some Basic User and Group Rules

- You can use up to 6 characters for user names and group names. You can not use a space at the beginning or end of a name. You can use characters, numbers, and an underline (_).
- You can add up to 64 users and 20 groups (these are also the default settings). The default setting includes two group levels: **user** and **admin**. Configure the Group privileges, and then assign users to their groups according to the privileges those users require.
- User management involves assigning privileges to groups, and users to groups. User names can not be the same as group names; user names and group names must be unique. Users can belong to only one group.

Click **Account** in the **General** settings configuration interface to open the **Account** settings configuration interface.

Figure 5-58 Account Settings Configuration Interface



The screenshot shows the 'Account' settings configuration interface. It features a table with columns for SN, Username, Group Name, Memo, Modify, and Delete. There are four rows of data representing different user accounts. Below the table is an 'Add User' button.

SN	Username	Group Name	Memo	Modify	Delete
1	888888	admin	admin(888)'s account		
2	666666	user	666666 user's account		
3	admin	admin	admin's account		
4	default	user	default account		

Configuring User Settings

There are four default users:

- admin
- 888888
- 666666
- a hidden user

All except default user 666666 have administrator rights. User 666666 has only monitor rights.

The hidden default user is for internal use only, and can not be deleted. If users log in without selecting a login user, the hidden default user is automatically used. You can configure some rights for the default hidden user, such as monitor rights so that the user can view channels without logging in.

Note User rights can not exceed group rights.

TIP! General users should have fewer rights than administrators.

Adding a User

1. Click **Add User**. The **Add User** configuration interface opens.

Figure 5-59 Add User Configuration Interface

The screenshot shows the 'Add User' configuration window. The 'Group' dropdown is set to 'admin'. The 'Authority' section has three tabs: 'System', 'Playback', and 'Real-time Monitor'. The 'System' tab is active, displaying a list of permissions with checkboxes, all of which are checked. The permissions listed are:

System	Playback	Real-time Monitor
<input checked="" type="checkbox"/> All		
<input checked="" type="checkbox"/> Control Panel	<input checked="" type="checkbox"/> Shutdown	<input checked="" type="checkbox"/> Record Control
<input checked="" type="checkbox"/> HDD Manager	<input checked="" type="checkbox"/> PTZ Control	<input checked="" type="checkbox"/> Account
<input checked="" type="checkbox"/> Alarm I/O Config	<input checked="" type="checkbox"/> Query Log Info	<input checked="" type="checkbox"/> Clear Log
<input checked="" type="checkbox"/> Control Device	<input checked="" type="checkbox"/> Auto Maintain	<input checked="" type="checkbox"/> General Setup
<input checked="" type="checkbox"/> Schedule	<input checked="" type="checkbox"/> Network Setup	<input checked="" type="checkbox"/> Alarm Setup
<input checked="" type="checkbox"/> PTZ Setup	<input checked="" type="checkbox"/> Display	<input checked="" type="checkbox"/> Default
<input checked="" type="checkbox"/> Config Backup	<input checked="" type="checkbox"/> Color Setting	<input checked="" type="checkbox"/> Remote Device
		<input checked="" type="checkbox"/> File Backup
		<input checked="" type="checkbox"/> System Info View
		<input checked="" type="checkbox"/> System Update
		<input checked="" type="checkbox"/> Encode Setup
		<input checked="" type="checkbox"/> Video Detection
		<input checked="" type="checkbox"/> Data Format

2. Enter a **Username** and a **Password**. Re-enter the Password to confirm it.
3. Select a **Group**.
4. Select **System**, **Playback**, and **Real-Time Monitor** privileges.
5. Click **Save** to save these new settings.

Modifying a User


1. Click  under **Modify** to open the **Modify User** configuration interface.

Figure 5-60 Modify User Configuration Interface

Modify User

Username: 888888

Username: 888888

Reuseable:

Group: admin

Memo: admin(888)'s account

Modify Password

Authority

System | Playback | Real-time Monitor

- All
- Control Panel
- HDD Manager
- Alarm I/O Config
- Control Device
- Schedule
- PTZ Setup
- Config Backup
- Shutdown
- PTZ Control
- Query Log Info
- Auto Maintain
- Network Setup
- Display
- Color Setting
- Record Control
- Account
- Clear Log
- General Setup
- Alarm Setup
- Default
- Remote Device
- File Backup
- System Info View
- System Update
- Encode Setup
- Video Detection
- Data Format

Save Cancel

2. Change the settings, then click **Save**.

Modifying a Password

1. Click **Modify Password** in the **Modify User** configuration interface.
2. Enter the old **Password**, then enter the new **Password** twice.
3. Click **OK** to save the new password.

Note Passwords can have up to 6 characters, numbers only. Users with admin rights can modify the password of other users.

Configuring Group Settings

Click the **Group** tab in the **Account** configuration interface to open the **Group** configuration interface.


Figure 5-61 Group Configuration Interface



Adding a Group

1. Click **Add Group** in the **Group Account** configuration interface.

Figure 5-62 Add Group Configuration Interface



2. Enter a **Group** name.
3. Select **System**, **Playback**, and **Real-time Monitor** privileges.
4. Click **Save** to save these new settings.

Modifying a Group

1. Click under **Modify** to open the **Modify Group** configuration interface.

Figure 5-63 Modify Group Configuration Interface


The screenshot shows the 'Modify Group' configuration window. The 'Group Name' is set to 'admin' and the 'Memo' is 'administrator group'. The 'System' tab is selected, displaying a grid of checked checkboxes for various system functions. The 'Save' and 'Cancel' buttons are visible at the bottom.

System	Playback	Real-time Monitor
<input checked="" type="checkbox"/> All		
<input checked="" type="checkbox"/> Control Panel	<input checked="" type="checkbox"/> Shutdown	<input checked="" type="checkbox"/> Record Control
<input checked="" type="checkbox"/> HDD Manager	<input checked="" type="checkbox"/> PTZ Control	<input checked="" type="checkbox"/> Account
<input checked="" type="checkbox"/> Alarm I/O Config	<input checked="" type="checkbox"/> Query Log Info	<input checked="" type="checkbox"/> Clear Log
<input checked="" type="checkbox"/> Control Device	<input checked="" type="checkbox"/> Auto Maintain	<input checked="" type="checkbox"/> General Setup
<input checked="" type="checkbox"/> Schedule	<input checked="" type="checkbox"/> Network Setup	<input checked="" type="checkbox"/> Alarm Setup
<input checked="" type="checkbox"/> PTZ Setup	<input checked="" type="checkbox"/> Display	<input checked="" type="checkbox"/> Default
<input checked="" type="checkbox"/> Remote Device	<input checked="" type="checkbox"/> Config Backup	<input checked="" type="checkbox"/> Color Setting
		<input checked="" type="checkbox"/> File Backup
		<input checked="" type="checkbox"/> System Info View
		<input checked="" type="checkbox"/> System Update
		<input checked="" type="checkbox"/> Encode Setup
		<input checked="" type="checkbox"/> Video Detection
		<input checked="" type="checkbox"/> Data Format

2. Modify the **Group** privileges, then click **Save** to save the changes.

Configuring Display Settings

Click **Display** in the **General** settings configuration interface to open the **GUI** settings configuration interface.

Figure 5-64 GUI Configuration Interface**Table 5-25 GUI Configurations**

Configuration	Description
Resolution	Select from four options: 1920x1080 , 1280x1024 (default), 1280x720 , and 1024x768 . Note You need to reboot the NVR to activate changes to the resolution.
Transparency	Configure the transparency of the GUI display. Select from 128 to 255 .
Time Display/Channel Display	Click to enable these functions, which display the time and channel on the video monitor.
Image Enhance	Check to enable Image Enhance , to optimize the preview video.

Enabling and Disabling Alarm Out Settings


Click **Alarm Out** in the **General** settings configuration interface to open the **Alarm Out** settings configuration interface.

Figure 5-65 Alarm Out Configuration Interface

Click to enable alarm types for each or all of the alarm outputs.

Returning to Default Settings

Click **Default** in the **General** settings configuration interface to open the **Default** settings interface.

Figure 5-66 Default Settings Interface

Click to enable the **Default** settings, then click **Default**.

Configuring Backup Settings


Click **Config Backup** in the **General** settings configuration interface to open the **Import&Export** settings interface.

Figure 5-67 Import&Export Interface**Table 5-26 Configuration Backup/Import&Export Interface**

Configuration	Description
Browse	Click to select a file for importing.
Config Import	Click to import the local setup files to the NVR.
Config Export	Click to export the corresponding web client setup to your PC.

Configuring Automatic Maintenance Settings

1. Click **Auto Maintain** in the **General** settings configuration interface to open the **Auto Maintain** settings configuration interface.

Figure 5-68 Auto Maintain Configuration Interface

2. Select when the NVR automatically reboots, both day and time.
3. Select when the NVR automatically deletes old files.
4. Click **Save** to save the new settings.

Note Click **Manual Reboot** to manually reboot the NVR.

Configuring Preview Control Settings

Click **Preview Control** in the **General** settings configuration interface to open the **Preview Control** settings configuration interface.

Figure 5-69 Preview Control Configuration Interface

If you select **View 1**, you have to select a Preview Channel.

If you select **View 4**, you have to select all channels for previewing.

Configuring System Information

Click the **Info** tab on the **Main Menu** to open the **Info** configuration interface.

Viewing the Version

1. Click the arrow next to **System** to expand the **System** menu tree.
2. Click **Version** to open the **Version** configuration interface.

Figure 5-70 Version Configuration Interface

Here you can view the recording channel, the alarm input/output information, the software version, and the release date. None of these values can be changed; they are viewable only.

Configuring the Log

Click **Log** in the **System** menu to open the **Log** configuration interface.

Figure 5-71 Log Configuration Interface




Table 5-27 Log Configurations

Configuration	Description
Begin Time	Set a start time for the log.
End Time	Set an end time for the log.
Type	Select from System Operation, Configuration Operation, Data Operation, Event Operation, Record Operation, User Management, Log Clear , and All .
Search	Click Search to find a log or logs that fit the search requirements (Begin time, End time, and Type). You can click Stop to terminate the current search.
Detailed Information	Select one item to see its detailed information.
Clear	Click to clear the found log files. Note You can not clear by log file.
Backup	Click to backup the currently selected files to the selected PC.

Viewing the Online Users

Click **Online User** in the System menu to open the **Online User** interface.

Figure 5-72 Online User Configuration Interface

The screenshot shows a web interface titled "Online User". It contains a table with the following columns: No., Username, Group Name, IP Address, and User Login Time. There is one row of data.


No.	Username	Group Name	IP Address	User Login Time
1	admin	admin	192.168.1.110	2014-03-07 08:59:06

Below the table is a "Refresh" button.

You can view what users are currently online.

Logging Out

Click the **Logout** tab in the **Main Menu**. The NVR returns to the Login interface.

Figure 5-73 Login Interface

The screenshot shows the Honeywell login interface. It features the Honeywell logo at the top. Below the logo are two input fields: "Username:" with the value "admin" and "Password:". Below the password field are two radio buttons: "LAN" (selected) and "WAN". At the bottom are two buttons: "Login" and "Cancel".



Troubleshooting

Prior to calling Honeywell technical support, refer to the following topics for possible solutions to problems with your NVR. To contact the Honeywell Video Systems technical support team, call 1-800-323-4576 (North America only) or send an e-mail to <https://www.honeywellsystems.com/ss/techsupp/index.html>. See the back cover for international contact information.

Any equipment returned to Honeywell Video Systems for warranty or service repair must have a Return Merchandise Authorization (RMA) number. The RMA number must be clearly marked on all return packages and internal paperwork.

Problem: The NVR does not boot up properly

Possible Solutions:

- Ensure that the input power is correct.
- Ensure that the power connection is connected.
- Check the upgraded software. It might be incorrect and require another upgrade.
- Check the HDD and HDD ribbon. They might be damaged and require replacement.
- Upgrade to the latest software version for Seagate DB35.1 / DB35.2 / SV35, or Maxtor 17-g to resolve compatibility problem.

Problem: The NVR cannot detect the hard disk

Possible solutions:

- Check the HDD cable connection.
- Check the HDD and HDD ribbon. They might be damaged and require replacement.
- Replace the Main board SATA port.

Problem: The real-time video color is distorted

Possible solutions:

- Check the NTSC and PAL setup when using the BNC output. If this setup is incorrect, the real-time video appears black and white.
- Check the compatibility of the resistance between the NVR and the monitor.
- Check the video transmission. The clip might be too long or there is a lot of file degradation.
- Check the NVR's color and/or brightness settings.

Problem: Motion detection does not work

Possible solutions:

- Check that the period setup is correct. See [Configuring the Schedule on page 69](#).
- Check the motion detection zone setup.
- Check that the motion sensitivity level is not too low.

Problem: You can not log into the NVR or web client

Possible solutions:

- Upgrade to Windows 2000 SP4 from Windows 98 or Windows ME if you are using them on your system. Or you can install a client-end software of a lower version.

Note The NVR is not compatible with Windows VISTA.

- Check the ActiveX settings. ActiveX might have been disabled. See [Figure 5-2](#) on [page 144](#).
- The display card driver might be inadequate (lower than dx8.1). Upgrade the display card driver.
- Check the network connection. There might be a network connection error.
- Check the network setup. There might be a network setup error.
- Check that you have entered the correct username and password.
- Your client-end computer might not be compatible with the NVR's software.

Problem: The remote control does not work

Possible solutions:

- Check and correct the remote control's address.
- Move closer to the NVR. The transmission distance might be too far. Change your position. The angle might be too small.
- Check the remote control's battery.

Problem: You have forgotten the local menu operation password or network password

Possible solution:

Contact your local service engineer or sales engineer for help.

Problem: There is no video; the screen is black

Possible solutions:

- Check and correct the IP camera's IP address.
- Check and correct the IP camera's port number.
- Check and correct the IP camera's account user name and password.
- Check the physical connections.

Problem: When viewing multiple channels in the client end, the video is not smooth

Possible solutions:

- Check the network bandwidth, as it needs to be at least 100M or higher for monitoring multiple channels. Increase the bandwidth or reduce the number of channels for viewing.
- Ensure that your PC meets the minimum requirements:

Table A-1 PC Requirements

Component	Minimum Requirement
Processor	Quad core
System memory (RAM)	2G pr higher
Non-integrated video card	256M or higher



Daily Maintenance

- Please use a brush to clean the board, socket connector and the chassis regularly.
- Carefully ground the NVR to protect from audio/video disturbances. Keep the NVR away from static voltage or induced voltage.
- Please unplug the power cable when you remove the audio/video signal cable, RS232, or RS485 cable.
- Always properly shut down the device. Please press the power button in the front panel for at least three seconds to shut down the device. If you don't, you might experience an HDD malfunction.
- Please make sure the device is away from the direct sunlight or other sources of heat. Ensure that the NVR is properly ventilated.
- Please check and maintain the device regularly.



Specifications

Table C-1 Specifications

System	
Main Processor	Dual-core embedded processor
Operating System	Embedded LINUX
Video	
IP Camera Inputs	4-channel NVRs: 4 8-channel NVRs: 8 16-channel NVRs: 16
Two-way Talking	1 channel input; 1 channel output; BNC
Display	
Interface	1 HDMI, 1 VGA
Resolution	1920 x 1080; 1280 x 1024; 1280 x 720; 1024 x 768
Display Split	4-channel NVRs: 1/4 8-channel NVRs: 1/4/8/9 16-channel NVRs: 1/4/8/9/16
OSD	Camera title; Time; Video loss; Camera lock; Motion detection; Recording
Recording	
Compression	H.264 / MJPEG
Resolution	1080p (1920 x 1080); 720p (1280 x 720); D1 (704 x 576 / 704 x 480); SXGA (800 x 600); 1.3 MP (1280 x 1024)
Recording Rate	4-channel NVRs: 100/120 fps @ 1080p (100 fps @ 1080p for PAL; 120 fps @ 1080p for NTSC) 8-channel NVRs: 200/240 fps @ 1080p (200 fps @ 1080p for PAL; 240 fps @ 1080p for NTSC) 16-channel NVRs: 400/480 fps @ 1080p (400 fps @ 1080p for PAL; 480 fps @ 1080p for NTSC)
Bit Rate	4-channel NVRs: 256 to 8192 kbps 8-channel and 16-channel NVRs: 1 to 8192 kbps

Table C-1 Specifications

Recording Mode	Manual; Schedule (Regular[Continuous]; Motion Detection; Alarm; Motion Detection+Alarm); Stop
Recording Interval	1 to 120 minutes (default: 60 minutes); Pre-recording: 1 to 30 seconds
Video Detection and Alarms	
Trigger Events	Recording; Tour; Alarm; Email; FTP; Buzzer; Screen Tips
Video Detection	Motion Detection; Motion Detection Zones (396: 22 x 18); Video Loss and Camera Blank
Alarm Input	16 channels
Relay Output	3 channels
Playback and Backup	
Sync Playback	4-channel NVRs: 1/4 8-channel NVRs: 1/4/9 16-channel NVRs: 1/4/9/16
Search Mode	Time/Date; Alarm; Motion Detection; Exact Search (accurate to a second)
Playback Function	Play; Pause; Stop; Rewind; Fast play; Slow Play; Full Screen; Backup Selection
Backup Mode Compatibility	USB Device; Network
Network	
Ethernet	1 RJ-45 port (10/100/1000Mbps)
PoE	4-channel NVRs: 4 ports (IEEE802.3af) 8-channel and 16-channel NVRs: 8 ports (IEEE802.3af)
Network Function	HTTP, TCP/IP, IPv4/IPv6, UPnP, RTSP, UDP, SMTP, NTP, DHCP, DNS, IP Filter, PPPoE, DDNS, FTP, Alarm Server, IP Search
Maximum number of users	20 users
Smart Phone compatibility	IOS; Android
Storage	
Internal Storage	2 SATA ports: up to 8 TB; RAID (redundancy)
Auxiliary Interface	
USB	2 ports (1 on rear panel); USB 2.0
RS232	1 port, for PC communication and keyboard
RS485	1 port, for PTZ control (not supported)
Electrical	
Power Supply (NVR)	12 V DC; 5 A

Table C-1 Specifications

Power Supply (PoE)	4-channel NVRs: 48 V DC; 1.04 A 8-channel and 16-channel NVRs: 48 V DC; 2.5 A
Power Consumption (NVR)	20 W (without HDD)
Power Consumption (PoE)	Maximum 15 W each
Environmental	
Operating Temperature	14° F to 131°F (-10°C to 55°C)
Storage Temperature	-4° F to 158°F (-20°C to 70°C)
Humidity	10% to 90%
Physical	
Dimensions	14.8 x 11.2 x 2.0 inches (375 x 285 x 50 mm)
Weight (without HDD)	5.07 pounds (2.3 kg)



Compatible IP Cameras

Table D-1 Compatible IP Cameras

Part Number	Description	Connection Notes
HBD2PR1	IP IR TDN Indoor/Outdoor 1080p IR Bullet Camera, 3.6 mm F1.6 fixed lens, H.264, NTSC	
HBD2PR1X	IP IR TDN Indoor/Outdoor 1080p IR Bullet Camera, 3.6 mm F1.6 fixed lens, H.264, PAL	
H2D2PR1	IP IR TDN Indoor/Outdoor 1080p IR Ball Camera, 3.6 mm F1.6 fixed lens, H.264, NTSC	
H2D2PR1X	IP IR TDN Indoor/Outdoor 1080p IR Ball Camera, 3.6 mm F1.6 fixed lens, H.264, PAL	
HCD2F	IP TDN 1/2.7" Progressive Scan, CMOS, 1080p, 24 VAC or PoE IEEE 802.3af, H.264, NTSC, ONVIF	See NOTE: Connecting to Group 1 IP Cameras on page 220. See NOTE: Connecting to Group 2 IP Cameras on page 221.
HCD2FX	IP TDN 1/2.7" Progressive Scan, CMOS, 1080p, 24 VAC or PoE IEEE 802.3af, H.264, PAL, ONVIF	See NOTE: Connecting to Group 1 IP Cameras on page 220. See NOTE: Connecting to Group 2 IP Cameras on page 221.
H4D2F1	IP TDN Rugged Fixed Dome, 1/2.7" Progressive Scan, CMOS, 1080p, 3-9 mm MFZ, 24 VAC or PoE IEEE 802.3af, H.264, NTSC, ONVIF	See NOTE: Connecting to Group 1 IP Cameras on page 220. See NOTE: Connecting to Group 2 IP Cameras on page 221.
H4D2F1X	IP TDN Rugged Fixed Dome, 1/2.7" Progressive Scan, CMOS, 1080p, 3-9 mm MFZ, 24 VAC or PoE IEEE 802.3af, H.264, PAL, ONVIF	See NOTE: Connecting to Group 1 IP Cameras on page 220. See NOTE: Connecting to Group 2 IP Cameras on page 221.
H3D2F1	IP TDN 1/2.7" Progressive Scan, CMOS, 1080p Resolution Camera, 3-9 mm MFZ, 24 VAC or PoE IEEE 802.3 af, H.264, NTSC, ONVIF	See NOTE: Connecting to Group 1 IP Cameras on page 220. See NOTE: Connecting to Group 2 IP Cameras on page 221.

Part Number	Description	Connection Notes
H3D2F1X	IP TDN 1/2.7" Progressive Scan, CMOS, 1080p Resolution Camera, 3-9 mm MFZ, 24 VAC or PoE IEEE 802.3af, H.264, PAL, ONVIF	See <i>NOTE: Connecting to Group 1 IP Cameras on page 220.</i> See <i>NOTE: Connecting to Group 2 IP Cameras on page 221.</i>
HBD2FR1	IP IR DN Rugged, Indoor/Outdoor, Bullet Camera, 1/2.7" Progressive Scan CMOS, 1080p Resolution, 3–9 mm MFZ, 48 LEDs, PoE IEEE 802.3af Class 3, H.264, NTSC	See <i>NOTE: Connecting to Group 2 IP Cameras on page 221.</i>
HBD2FR1X	IP IR DN Rugged, Indoor/Outdoor, Bullet Camera, 1/2.7" Progressive Scan CMOS, 1080p Resolution, 3–9 mm MFZ, 48 LEDs, PoE IEEE 802.3af Class 3, H.264, PAL	See <i>NOTE: Connecting to Group 2 IP Cameras on page 221.</i>
HBD2FR2	IP IR DN Rugged, Indoor/Outdoor, Bullet Camera, 1/2.7" Progressive Scan CMOS, 1080p Resolution, 10–23 mm MFZ, 48 LEDs, PoE IEEE 802.3af Class 3, H.264, NTSC	See <i>NOTE: Connecting to Group 2 IP Cameras on page 221.</i>
HBD2FR2X	IP IR DN Rugged, Indoor/Outdoor, Bullet Camera, 1/2.7" Progressive Scan CMOS, 1080p Resolution, 10–23 mm MFZ, 48 LEDs, PoE IEEE 802.3af Class 3, H.264, PAL	See <i>NOTE: Connecting to Group 2 IP Cameras on page 221.</i>
HCD1F	IP TDN 1/4" Progressive Scan, CMOS, 720p, 24 VAC or PoE IEEE 802.3af Class 1, H.264, NTSC, ONVIF	See <i>NOTE: Connecting to Group 2 IP Cameras on page 221.</i>
HCD1FX	IP TDN 1/4" Progressive Scan, CMOS, 720p, 24 VAC or PoE IEEE 802.3af Class 1, H.264, PAL, ONVIF	See <i>NOTE: Connecting to Group 2 IP Cameras on page 221.</i>
H4D1F1	IP TDN Rugged Fixed Dome, 1/4" Progressive Scan, CMOS, 720p, 3.3-12 mm VFAI, 24 VAC or PoE IEEE 802.3af Class 1, H.264, NTSC, ONVIF	See <i>NOTE: Connecting to Group 2 IP Cameras on page 221.</i>
H4D1F1X	IP TDN Rugged Fixed Dome, 1/4" Progressive Scan, CMOS, 720p, 3.3-12 mm VFAI, 24 VAC or PoE IEEE 802.3af Class 1, H.264, PAL, ONVIF	See <i>NOTE: Connecting to Group 2 IP Cameras on page 221.</i>
H3D1F1	IP TDN 1/4" Progressive Scan, CMOS, 720p, 3.3-12 mm VFAI, 24 VAC or PoE IEEE 802.3af Class 1, H.264, NTSC, ONVIF	See <i>NOTE: Connecting to Group 2 IP Cameras on page 221.</i>
H3D1F1X	IP TDN 1/4" Progressive Scan, CMOS, 720p, 3.3-12 mm VFAI, 24 VAC or PoE IEEE 802.3af Class 1, H.264, PAL, ONVIF	See <i>NOTE: Connecting to Group 2 IP Cameras on page 221.</i>
HCW1F	IP TDN 1/3" Progressive Scan, CMOS, Wide Dynamic 720p Resolution Camera, 24 V AC or PoE IEEE 802.3af, H.264, NTSC, ONVIF	See <i>NOTE: Connecting to Group 2 IP Cameras on page 221.</i>
HCW1FX	IP TDN 1/3" Progressive Scan, CMOS, Wide Dynamic 720p Resolution Camera, 24 V AC or PoE IEEE 802.3af, H.264, PAL, ONVIF	See <i>NOTE: Connecting to Group 2 IP Cameras on page 221.</i>
H4W1F1	IP TDN Rugged Fixed Dome, 1/3" Progressive Scan, CMOS, Wide Dynamic, 720p, 3.3-12 mm VFAI, 24 V AC or PoE IEEE 802.3af, H.264, NTSC, ONVIF	See <i>NOTE: Connecting to Group 2 IP Cameras on page 221.</i>
H4W1F1X	IP TDN Rugged Fixed Dome, 1/3" Progressive Scan, CMOS, Wide Dynamic, 720p, 3.3-12 mm VFAI, 24 V AC or PoE IEEE 802.3af, H.264, PAL, ONVIF	See <i>NOTE: Connecting to Group 2 IP Cameras on page 221.</i>
H3W1F1	IP TDN 1/3" Progressive Scan, CMOS, Wide Dynamic 720p, 3.3-12 mm VFAI, 24 V AC or PoE IEEE 802.3af, H.264, NTSC, ONVIF	See <i>NOTE: Connecting to Group 2 IP Cameras on page 221.</i>

Part Number	Description	Connection Notes
H3W1F1X	IP TDN 1/3" Progressive Scan, CMOS, Wide Dynamic 720p, 3.3-12 mm VFAI, 24 V AC or PoE IEEE 802.3af, H.264, PAL, ONVIF	See NOTE: Connecting to Group 2 IP Cameras on page 221.
H3S1P1	IP TDN IP TDN 1/4" Progressive Scan, CMOS, 720p, 3.3 – 12 mm VFAI, 24 V AC or PoE IEEE 802.3af, H.264, NTSC, ONVIF	See NOTE: Connecting to Group 2 IP Cameras on page 221.
H3S1P1X	IP TDN Fixed Dome, 1/4" Progressive Scan, CMOS, 720p, 3.3 – 12 mm VFAI, 24 V AC or PoE IEEE 802.3af, H.264, PAL, ONVIF	See NOTE: Connecting to Group 2 IP Cameras on page 221.
H4S1P1	IP TDN Rugged Fixed Dome, 1/4" Progressive Scan, CMOS, 720p, 3.3-12 mm VFAI, 24 VAC or PoE IEEE 802.3af Class 1, H.264, NTSC, ONVIF	See NOTE: Connecting to Group 2 IP Cameras on page 221.
H4S1P1X	IP TDN Rugged Fixed Dome, 1/4" Progressive Scan, CMOS, 720p, 3.3-12 mm VFAI, 24 VAC or PoE IEEE 802.3af Class 1, H.264, PAL, ONVIF	See NOTE: Connecting to Group 2 IP Cameras on page 221.
H2S1P6	IP TDN Indoor Micro Dome, 1/2.7" Progressive Scan, CMOS, 720p H264, NTSC, ONVIF	See NOTE: Connecting to Group 3 IP Cameras on page 223.
H2S1P6X	IP TDN Indoor Micro Dome, 1/2.7" Progressive Scan, CMOS, 720p H264, NTSC, PAL	See NOTE: Connecting to Group 3 IP Cameras on page 223.
H2S2P6	IP TDN Indoor Micro Dome, 1/2.7" Progressive Scan, CMOS, 1080p H264, NTSC, ONVIF	See NOTE: Connecting to Group 3 IP Cameras on page 223.
H2S2P6X	IP TDN Indoor Micro Dome, 1/2.7" Progressive Scan, CMOS, 1080p H264, NTSC, PAL	See NOTE: Connecting to Group 3 IP Cameras on page 223.
H3D2S2	IP TDN Indoor Minidome, 1/2.7" Progressive Scan, CMOS, 1080p H264, NTSC, ONVIF	See NOTE: Connecting to Group 3 IP Cameras on page 223.
H3D2S2X	IP TDN Indoor Minidome, 1/2.7" Progressive Scan, CMOS, 1080p H264, NTSC, PAL	See NOTE: Connecting to Group 3 IP Cameras on page 223.
H3D2SR2	IP IR TDN Indoor Minidome, 1/2.7" Progressive Scan, CMOS, 1080p H264, NTSC, ONVIF	See NOTE: Connecting to Group 3 IP Cameras on page 223.
H3D2SR2X	IP IR TDN Indoor Minidome, 1/2.7" Progressive Scan, CMOS, 1080p H264, NTSC, PAL	See NOTE: Connecting to Group 3 IP Cameras on page 223.
H4D2S2	IP TDN Rugged Outdoor Minidome, 1/2.7" Progressive Scan, CMOS, 1080p H264, NTSC, ONVIF	See NOTE: Connecting to Group 3 IP Cameras on page 223.
H4D2S2X	IP TDN Rugged Outdoor Minidome, 1/2.7" Progressive Scan, CMOS, 1080p H264, NTSC, PAL	See NOTE: Connecting to Group 3 IP Cameras on page 223.
HCW2S2	IP WDR TDN, Indoor Box Camera, 1/2.8" Progressive Scan, CMOS, 1080p Resolution, 12 V DC/24 V AC/PoE IEEE 802.3af Class 0, H.264, NTSC	See NOTE: Connecting to Group 3 IP Cameras on page 223.
HCW2S2X	IP WDR TDN, Indoor Box Camera, 1/2.8" Progressive Scan, CMOS, 1080p Resolution, 12 V DC/24 V AC/PoE IEEE 802.3af Class 0, H.264, PAL	See NOTE: Connecting to Group 3 IP Cameras on page 223.

NOTE: Connecting to Group 1 IP Cameras

To connect the cameras in this group, please do the following:

1. Connect the camera to the separate PoE switch.
2. Adjust the field of view through the analog output.
3. Connect the camera to the NVR.

Table D-2 Connecting Group 1IP Cameras

Part Number	Description
HCD2F	IP TDN 1/2.7" Progressive Scan, CMOS, 1080p, 24 VAC or PoE IEEE 802.3af, H.264, NTSC, ONVIF
HCD2FX	IP TDN 1/2.7" Progressive Scan, CMOS, 1080p, 24 VAC or PoE IEEE 802.3af, H.264, PAL, ONVIF
H4D2F1	IP TDN Rugged Fixed Dome, 1/2.7" Progressive Scan, CMOS, 1080p, 3-9 mm MFZ, 24 VAC or PoE IEEE 802.3af, H.264, NTSC, ONVIF
H4D2F1X	IP TDN Rugged Fixed Dome, 1/2.7" Progressive Scan, CMOS, 1080p, 3-9 mm MFZ, 24 VAC or PoE IEEE 802.3af, H.264, PAL, ONVIF
H3D2F1	IP TDN 1/2.7" Progressive Scan, CMOS, 1080p Resolution Camera, 3-9 mm MFZ, 24 VAC or PoE IEEE 802.3 af, H.264, NTSC, ONVIF
H3D2F1X	IP TDN 1/2.7" Progressive Scan, CMOS, 1080p Resolution Camera, 3-9 mm MFZ, 24 VAC or PoE IEEE 802.3 af, H.264, PAL, ONVIF
HBD2FR1	IP IR DN Rugged, Indoor/Outdoor, Bullet Camera, 1/2.7" Progressive Scan CMOS, 1080p Resolution, 3–9 mm MFZ, 48 LEDs, PoE IEEE 802.3af Class 3, H.264, NTSC
HBD2FR1X	IP IR DN Rugged, Indoor/Outdoor, Bullet Camera, 1/2.7" Progressive Scan CMOS, 1080p Resolution, 3–9 mm MFZ, 48 LEDs, PoE IEEE 802.3af Class 3, H.264, PAL
HBD2FR2	IP IR DN Rugged, Indoor/Outdoor, Bullet Camera, 1/2.7" Progressive Scan CMOS, 1080p Resolution, 10–23 mm MFZ, 48 LEDs, PoE IEEE 802.3af Class 3, H.264, NTSC
HBD2FR2X	IP IR DN Rugged, Indoor/Outdoor, Bullet Camera, 1/2.7" Progressive Scan CMOS, 1080p Resolution, 10–23 mm MFZ, 48 LEDs, PoE IEEE 802.3af Class 3, H.264, PAL

NOTE: Connecting to Group 2 IP Cameras

To connect the cameras in this group, please do the following:

1. Check the camera's firmware version in [Table D-3](#) before you add the camera to NVR.
If the firmware version for your camera matches what is listed in [Table D-3](#), then continue to [step 2](#).
2. Log in the camera and select **H.264+H.264** for the encoding setting.
3. Then add the camera to your NVR.

Table D-3 Connecting to Group 2 IP Cameras

Part Number	Description	Firmware Version
HCD2F	IP TDN 1/2.7" Progressive Scan, CMOS, 1080p, 24 VAC or PoE IEEE 802.3af, H.264, NTSC, ONVIF	v40.0.6, v42.0.3
HCD2FX	IP TDN 1/2.7" Progressive Scan, CMOS, 1080p, 24 VAC or PoE IEEE 802.3af, H.264, PAL, ONVIF	v40.0.6, v42.0.3
H4D2F1	IP TDN Rugged Fixed Dome, 1/2.7" Progressive Scan, CMOS, 1080p, 3-9 mm MFZ, 24 VAC or PoE IEEE 802.3af, H.264, NTSC, ONVIF	v40.0.6, v42.0.3
H4D2F1X	IP TDN Rugged Fixed Dome, 1/2.7" Progressive Scan, CMOS, 1080p, 3-9 mm MFZ, 24 VAC or PoE IEEE 802.3af, H.264, PAL, ONVIF	v40.0.6, v42.0.3
H3D2F1	IP TDN 1/2.7" Progressive Scan, CMOS, 1080p Resolution Camera, 3-9 mm MFZ, 24 VAC or PoE IEEE 802.3 af, H.264, NTSC, ONVIF	v40.0.6, v42.0.3
H3D2F1X	IP TDN 1/2.7" Progressive Scan, CMOS, 1080p Resolution Camera, 3-9 mm MFZ, 24 VAC or PoE IEEE 802.3 af, H.264, PAL, ONVIF	v40.0.6, v42.0.3
HBD2FR1	IP IR DN Rugged, Indoor/Outdoor, Bullet Camera, 1/2.7" Progressive Scan CMOS, 1080p Resolution, 3–9 mm MFZ, 48 LEDs, PoE IEEE 802.3af Class 3, H.264, NTSC	v41.1.0, v41.2.0, v42.0.3
HBD2FR1X	IP IR DN Rugged, Indoor/Outdoor, Bullet Camera, 1/2.7" Progressive Scan CMOS, 1080p Resolution, 3–9 mm MFZ, 48 LEDs, PoE IEEE 802.3af Class 3, H.264, PAL	v41.1.0, v41.2.0, v42.0.3
HBD2FR2	IP IR DN Rugged, Indoor/Outdoor, Bullet Camera, 1/2.7" Progressive Scan CMOS, 1080p Resolution, 10–23 mm MFZ, 48 LEDs, PoE IEEE 802.3af Class 3, H.264, NTSC	v41.2.0, v42.0.3
HBD2FR2X	IP IR DN Rugged, Indoor/Outdoor, Bullet Camera, 1/2.7" Progressive Scan CMOS, 1080p Resolution, 10–23 mm MFZ, 48 LEDs, PoE IEEE 802.3af Class 3, H.264, PAL	v41.2.0, v42.0.3
HCD1F	IP TDN 1/4" Progressive Scan, CMOS, 720p, 24 VAC or PoE IEEE 802.3af Class 1, H.264, NTSC, ONVIF	v40.0.6, v42.0.3

Part Number	Description	Firmware Version
HCD1FX	IP TDN 1/4" Progressive Scan, CMOS, 720p, 24 VAC or PoE IEEE 802.3af Class 1, H.264, PAL, ONVIF	v40.0.6, v42.0.3
H4D1F1	IP TDN Rugged Fixed Dome, 1/4" Progressive Scan, CMOS, 720p, 3.3-12 mm VFAI, 24 VAC or PoE IEEE 802.3af Class 1, H.264, NTSC, ONVIF	v40.0.6, v42.0.3
H4D1FX	IP TDN Rugged Fixed Dome, 1/4" Progressive Scan, CMOS, 720p, 3.3-12 mm VFAI, 24 VAC or PoE IEEE 802.3af Class 1, H.264, PAL, ONVIF	v40.0.6, v42.0.3
H3D1F1	IP TDN 1/4" Progressive Scan, CMOS, 720p, 3.3-12 mm VFAI, 24 VAC or PoE IEEE 802.3 af Class 1, H.264, NTSC, ONVIF	v40.0.6, v42.0.3
H3D1FX	IP TDN 1/4" Progressive Scan, CMOS, 720p, 3.3-12 mm VFAI, 24 VAC or PoE IEEE 802.3 af Class 1, H.264, PAL, ONVIF	v40.0.6, v42.0.3
HCW1F	IP TDN 1/3" Progressive Scan, CMOS, Wide Dynamic 720p Resolution Camera, 24 V AC or PoE IEEE 802.3af, H.264, NTSC, ONVIF	v40.0.6, v42.0.3
HCW1FX	IP TDN 1/3" Progressive Scan, CMOS, Wide Dynamic 720p Resolution Camera, 24 V AC or PoE IEEE 802.3af, H.264, PAL, ONVIF	v40.0.6, v42.0.3
H4W1F1	IP TDN Rugged Fixed Dome, 1/3" Progressive Scan, CMOS, Wide Dynamic, 720p, 3.3-12 mm VFAI, 24 V AC or PoE IEEE 802.3af, H.264, NTSC, ONVIF	v40.0.6, v42.0.3
H4W1FX	IP TDN Rugged Fixed Dome, 1/3" Progressive Scan, CMOS, Wide Dynamic, 720p, 3.3-12 mm VFAI, 24 V AC or PoE IEEE 802.3af, H.264, PAL, ONVIF	v40.0.6, v42.0.3
H3W1F1	IP TDN 1/3" Progressive Scan, CMOS, Wide Dynamic 720p, 3.3-12 mm VFAI, 24 V AC or PoE IEEE 802.3af, H.264, NTSC, ONVIF	v40.0.6, v42.0.3
H3W1FX	IP TDN 1/3" Progressive Scan, CMOS, Wide Dynamic 720p, 3.3-12 mm VFAI, 24 V AC or PoE IEEE 802.3af, H.264, PAL, ONVIF	v40.0.6, v42.0.3
H3S1P1	IP TDN IP TDN 1/4" Progressive Scan, CMOS, 720p, 3.3 – 12 mm VFAI, 24 V AC or PoE IEEE 802.3af, H.264, NTSC, ONVIF	v40.0.6, v42.0.3
H3S1P1X	IP TDN Fixed Dome, 1/4" Progressive Scan, CMOS, 720p, 3.3 – 12 mm VFAI, 24 V AC or PoE IEEE 802.3af, H.264, PAL, ONVIF	v40.0.6, v42.0.3
H4S1P1	IP TDN Rugged Fixed Dome, 1/4" Progressive Scan, CMOS, 720p, 3.3-12 mm VFAI, 24 VAC or PoE IEEE 802.3af Class 1, H.264, NTSC, ONVIF	v40.0.6, v42.0.3
H4S1P1X	IP TDN Rugged Fixed Dome, 1/4" Progressive Scan, CMOS, 720p, 3.3-12 mm VFAI, 24 VAC or PoE IEEE 802.3af Class 1, H.264, PAL, ONVIF	v40.0.6, v42.0.3

NOTE: Connecting to Group 3 IP Cameras

To connect the cameras in this group, we suggest that you either:

- Set the IP address as **Static** if the firmware version for your camera matches what is listed in [Table D-4](#).
- OR
- Upgrade to the latest firmware.

Table D-4 Connecting to Group 3 IP Cameras

Part Number	Description	Firmware Version
H2S1P6	IP TDN Indoor Micro Dome, 1/2.7" Progressive Scan, CMOS, 720p H264, NTSC, ONVIF	HS20140521NSA
H2S1P6X	IP TDN Indoor Micro Dome, 1/2.7" Progressive Scan, CMOS, 720p H264, NTSC, PAL	HS20140521NSA
H2S2P6	IP TDN Indoor Micro Dome, 1/2.7" Progressive Scan, CMOS, 1080p H264, NTSC, ONVIF	HS20140521NSA
H2S2P6X	IP TDN Indoor Micro Dome, 1/2.7" Progressive Scan, CMOS, 1080p H264, NTSC, PAL	HS20140521NSA
H3D2S2	IP TDN Indoor Minidome, 1/2.7" Progressive Scan, CMOS, 1080p H264, NTSC, ONVIF	HS20140521NSA
H3D2S2X	IP TDN Indoor Minidome, 1/2.7" Progressive Scan, CMOS, 1080p H264, NTSC, PAL	HS20140521NSA
H3D2SR2	IP IR TDN Indoor Minidome, 1/2.7" Progressive Scan, CMOS, 1080p H264, NTSC, ONVIF	HS20140521NSA
H3D2SR2X	IP IR TDN Indoor Minidome, 1/2.7" Progressive Scan, CMOS, 1080p H264, NTSC, PAL	HS20140521NSA
H4D2S2	IP TDN Rugged Outdoor Minidome, 1/2.7" Progressive Scan, CMOS, 1080p H264, NTSC, ONVIF	HS20140521NSA
H4D2S2X	IP TDN Rugged Outdoor Minidome, 1/2.7" Progressive Scan, CMOS, 1080p H264, NTSC, PAL	HS20140521NSA
HCW2S2	IP WDR TDN, Indoor Box Camera, 1/2.8" Progressive Scan, CMOS, 1080p Resolution, 12 V DC/24 V AC/PoE IEEE 802.3af Class 0, H.264, NTSC	HS20140627NSX
HCW2S2X	IP WDR TDN, Indoor Box Camera, 1/2.8" Progressive Scan, CMOS, 1080p Resolution, 12 V DC/24 V AC/PoE IEEE 802.3af Class 0, H.264, PAL	HS20140627NSX



Compatible SATA HDD

Table E-1 Compatible SATA HDD

Manufacturer	Series	Model	Capacity	Level
Seagate	Seagate SV35.5	ST1000VX000	1T	Supervision
Seagate	Seagate SV35.5	ST2000VX000	2T	Supervision
Seagate	Seagate SV35.5	ST3000VX000	3T	Supervision
Seagate	Seagate Constellation ES	ST1000NM0033	1T	Enterprise
Seagate	Seagate Constellation ES	ST2000NM0033	2T	Enterprise
Seagate	Seagate Constellation ES	ST3000NM0033	3T	Enterprise
Western Digital	WD Purple	WD10PURX	1T	Supervision
Western Digital	WD Purple	WD20PURX	2T	Supervision
Western Digital	WD Purple	WD30PURX	3T	Supervision
Western Digital	WD Purple	WD40PURX	4T	Supervision

Note The interface for all of the compatible HDDs is **SATA**.



Compatible USB 2.0 Devices

Table F-1 Compatible USB 2.0 Devices

Manufacturer	Model	Capacity
Sandisk	Cruzer Micro	512M
Sandisk	Cruzer Micro	1G
Sandisk	Cruzer Micro	2G
Sandisk	Cruzer Freedom	256M
Sandisk	Cruzer Freedom	512M
Sandisk	Cruzer Freedom	1G
Sandisk	Cruzer Freedom	2G
Kingston	Data Traveler II	1G
Kingston	Data Traveler II	2G
Kingston	Data Traveler	1G
Kingston	Data Traveler	2G
Maxell	USB 2.0 Flash Stick	128M
Maxell	USB 2.0 Flash Stick	256M
Maxell	USB 2.0 Flash Stick	512M
Maxell	USB 2.0 Flash Stick	1G
Maxell	USB 2.0 Flash Stick	2G
Kingax	Super Stick	128M
Kingax	Super Stick	256M
Kingax	Super Stick	512M
Kingax	Super Stick	1G
Kingax	Super Stick	2G
Netac	U210	128M
Netac	U210	256M

Table F-1 Compatible USB 2.0 Devices

Manufacturer	Model	Capacity
Netac	U210	512M
Netac	U210	1G
Netac	U210	2G
Teclast	Ti Cool	128M
Teclast	Ti Cool	256M
Teclast	Ti Cool	512M
Teclast	Ti Cool	1G
Teclast	Ti Cool	2G



Compatible Monitors

Table G-1 Compatible Monitors

Manufacturer	Model	Screen Size
BenQ (LCD)	ET-0007-TA	19-inch (wide screen)
Dell (LCD)	E178FPc	17-inch
BenQ (LCD)	Q7T4	17-inch
BenQ (LCD)	Q7T3	17-inch
Lenovo (LCD)	LXB-L17C	17-inch
Samsung (LCD)	225bw	22-inch (wide screen)
Lenovo (CRT)	LXB-FD17069HB	17-inch
Lenovo (CRT)	LXB-HF769A	17-inch
Lenovo (CRT)	LX-GJ556D	17-inch
Samsung (LCD)	2494HS	24-inch
Samsung (LCD)	P2350	23-inch
Samsung (LCD)	P2250	22-inch
Samsung (LCD)	P2370G	23-inch
Samsung (LCD)	2043	20-inch
Samsung (LCD)	2243EW	22-inch
LG (LCD)	W1942SP	19-inch
LG (LCD)	W2243S	22-inch
LG (LCD)	W2343T	23-inch
BenQ (LCD)	G900HD	18.5-inch
BenQ (LCD)	G2220HD	22-inch
Philips (LCD)	230E	23-inch

Table G-1 Compatible Monitors

Manufacturer	Model	Screen Size
Philips (LCD)	220CW9	23-inch
Philips (LCD)	220BW9	24-inch
Philips (LCD)	220EW9	25-inch

Index

Numerics

- 1080p [67](#)
- 12 V DC port [30](#)
- 1280x960 [67](#)
- 232 debug COM [29](#)
- 3G configurations [164](#), [165](#)
 - WLAN type [165](#)
- 40 V DC port [30](#)
- 666666
 - default password [41](#)
- 720p [67](#)
- 888888
 - default password [41](#)

A

- abnormality
 - event type [120](#)
 - settings [119](#)
- accounts [122](#)
 - management [123](#)
 - naming conventions [123](#)
 - settings [195](#)
- ActiveX [142](#)
 - configuring [143](#)
- adding
 - devices remotely [156](#)
 - devices, remotely and manually [157](#)
 - groups [123](#), [198](#)
 - users [124](#), [196](#)
- address
 - configuring email receiver [88](#)
 - IP multicast [79](#)
 - reserved multicast group [79](#)
- addresses
 - administrative scoped [79](#)
- adjusting
 - monitor brightness [150](#)
 - monitor contrast [150](#)
 - monitor saturation [150](#)
- admin default password [41](#)
- alarm in, number of [58](#)
- alarm out
 - motion detection [177](#)
 - number of [58](#)
- alarm output configuration [150](#)
- alarms [181](#)
 - abnormalities [186](#)
 - abnormality alarm upload [187](#)
 - alarm in channel [94](#)
 - alarm out [96](#)
 - alarm upload [96](#)
 - alarm upload error settings [120](#)
 - anti-dither settings [96](#)
 - buzzer settings [97](#)
 - camera masking [180](#)
 - camera masking alarm upload [108](#)
 - camera masking settings [107](#)
 - configuring [33](#), [93](#)
 - configuring IPC offline alarms [94](#)
 - configuring latch [96](#)
 - configuring messages [96](#)
 - configuring period [95](#)
 - configuring recording channel [96](#)
 - configuring sound file [155](#)
 - configuring tour [97](#)
 - configuring type [94](#)
 - connecting [33](#)
 - delay [96](#)
 - disabling [154](#)
 - disabling alarm out settings [200](#)
 - disk error [155](#)
 - disk full [155](#)
 - emails [96](#)
 - enable sound [155](#)
 - enabling [154](#)
 - enabling alarm out settings [200](#)
 - error alarm upload [187](#)
 - error setting [120](#)
 - errors [186](#)
 - event type [94](#)
 - external alarms [155](#), [184](#)
 - input port ground [30](#)
 - input ports [30](#)
 - IPC external alarms [94](#)
 - local [181](#)
 - local alarm buzzer [183](#)
 - local alarm delay [182](#)

- local alarm email [183](#)
- local alarm latch [183](#)
- local alarm message [183](#)
- local alarm out [183](#)
- local alarm period [182](#)
- local alarm PTZ activation [183](#)
- local alarm recording channel [182](#)
- local alarm snapshot [183](#)
- local alarm tour [183](#)
- local input alarm [94](#)
- motion detection [155](#)
- motion detection settings [102](#)
- net alarms [184](#)
- network alarms [184](#)
- network input alarm [94](#)
- no signal [155](#)
- output ports [30](#)
- output settings [121](#)
- PTZ activation [96](#)
- snapshot settings [97](#)
- type [94](#), [182](#)
- video loss [155](#), [179](#)
- video loss alarm out settings [104](#)
- video loss upload [105](#)
- video masking [155](#)
- alternate DNS server [74](#)
- APN [165](#)
- attachments, email [170](#)
- audio
 - from the NVR [34](#)
 - from the PC [34](#)
 - remote encoding [158](#)
- audio connections
 - audio output device to a PC [34](#)
 - PC to an audio input device [34](#)
- audio from the NVR [34](#)
- audio input port [30](#)
- audio On/Off, live video [149](#)
- audio output port [30](#)
- audio/video
 - enable/disable [67](#)
- authorization [165](#)
- auto logout [66](#)
- auto maintenance [126](#)
- auto registration [174](#)
- automatic maintenance [202](#)

B

- back panel components [29](#)
- back up
 - files [51](#)
- backup [204](#)
 - file name [57](#)
 - logs [57](#)
 - settings [127](#), [201](#)
- batch upgrading cameras [135](#)
- baud rate

- default RS232 setting [72](#)
- begin time, log [204](#)
- bi-directional communication [146](#)
 - connections [34](#)
- bit rate [67](#)
 - live video [149](#)
 - remotely configuring [159](#)
- bit rate type [67](#)
 - remotely configuring [158](#)
- block a user [59](#)
- blocked sites [77](#), [169](#)
- BPS [55](#)
- brightness [150](#)
- browse
 - import/export files [202](#)
- browsers [142](#)
- build date of NVR [58](#)
- built-in switch
 - configuration [112](#)
 - gateway [112](#)
 - subnet mask [112](#)
- button
 - file list switch [50](#)
 - instant record [147](#)
 - PTZ control [47](#)
 - search for recorded video [47](#)
 - start talking [146](#)
 - video color settings [47](#)
- buzzer [120](#)
 - abnormality [187](#)
 - error [187](#)
 - local alarm [183](#)
 - motion detection [179](#)

C

- calendar
 - searching recorded video [49](#)
- camera lock status icon [40](#)
- camera masking [98](#), [99](#), [180](#)
 - alarm out settings [107](#)
 - alarm upload [108](#)
 - channel [106](#)
 - email [108](#)
 - latch settings [107](#)
 - message [108](#)
 - period [107](#)
 - PTZ activation [108](#)
 - recording channel [108](#)
 - recording delay [108](#)
 - settings [106](#)
 - snapshot settings [108](#)
 - tour [108](#)
- cameras
 - remotely adding [156](#)
- cameras supported [157](#)
- capacity
 - HDD [55](#)

- card number search [50](#)
- cautions [5](#)
- CDMA1X [165](#)
- CDMS for 3G
 - configurations [164](#)
- channel
 - remotely configuring [158](#)
 - selection [49](#)
 - video loss [105](#)
- channel display [110, 200](#)
 - configuration [160](#)
 - overlay [68](#)
- channel name
 - configuration [161](#)
- channel number, live video [149](#)
- channel settings
 - motion detection [102](#)
- channel status [59](#)
- channels
 - video loss [103](#)
- choose language [65](#)
- clear log [204](#)
- clip button
 - editing files [51](#)
- code stream type
 - remotely configuring [158](#)
- color code
 - external alarm recorded file, red [50](#)
 - motion detection
 - yellow recorded file [50](#)
 - recorded file, green [50](#)
- compliance
 - FCC [5](#)
- components, NVR [27](#)
- compression
 - remotely configuring [158](#)
- config tool, opening [131](#)
- configuration
 - controls [148](#)
 - exporting files [202](#)
 - importing files [202](#)
 - operation [204](#)
- configurations
 - batch upgrade [135](#)
 - modifying an IP address [138](#)
 - upgrading a camera [132](#)
 - upgrading multiple cameras [135](#)
- configuring
 - 3G [164](#)
 - abnormality alarm out [186](#)
 - abnormality alarm upload [187](#)
 - abnormality buzzer [187](#)
 - abnormality email [187](#)
 - abnormality event type [120](#)
 - abnormality latch [186](#)
 - abnormality message [187](#)
 - abnormality settings [119](#)
 - accounts [122](#)
 - administrative scoped addresses [79](#)
 - alarm buzzer [97](#)
 - alarm delay [96](#)
 - alarm emails [96](#)
 - alarm event type [94](#)
 - alarm in channel [94](#)
 - alarm messages [96](#)
 - alarm out [96](#)
 - alarm output [121, 150](#)
 - alarm period [95](#)
 - alarm PTZ activation [96](#)
 - alarm schedule [189](#)
 - alarm sound file [155](#)
 - alarm tour [97](#)
 - alarm type [94](#)
 - alarm upload [96](#)
 - alarms [33, 93, 181](#)
 - alarms recording channel [96](#)
 - anonymous email [170](#)
 - anti-dither for alarms [96](#)
 - APN [165](#)
 - AUTH [165](#)
 - auto logout [66](#)
 - auto registration [174](#)
 - automatic maintenance settings [126](#)
 - automatic recording [190](#)
 - backup [127](#)
 - bit rate [67](#)
 - bit rate type [67](#)
 - built-in switch [112](#)
 - built-in switch gateway [112](#)
 - built-in switch IP address [112](#)
 - built-in switch subnet mask [112](#)
 - buzzer [179](#)
 - camera [113](#)
 - camera masking [180](#)
 - camera masking alarm out settings [107](#)
 - camera masking alarm upload [108](#)
 - camera masking channel [106](#)
 - camera masking email [108](#)
 - camera masking latch setting [107](#)
 - camera masking message [108](#)
 - camera masking period [107](#)
 - camera masking PTZ activation [108](#)
 - camera masking recording channel [108](#)
 - camera masking recording delay [108](#)
 - camera masking settings [106](#)
 - camera masking snapshots [108](#)
 - camera masking tour [108](#)
 - CDMA AUTH [165](#)
 - CDMS for 3G [164](#)
 - channel display [110](#)
 - channel display overlay [68](#)
 - channel names [110](#)
 - date settings [193](#)
 - DDNS [81, 167](#)
 - DDNS domain name [81](#)
 - DDNS mode [81](#)

DDNS server IP [167](#)
DDNS type [167](#), [168](#)
DDNS username [81](#)
default settings [111](#)
detection settings [98](#), [175](#)
Dial No. [165](#)
display image enhance [110](#)
display resolution [110](#)
display settings [109](#)
email attachment [170](#)
email encryption [170](#)
email event interval events [88](#)
email interval [171](#)
email password [87](#), [170](#)
email port [87](#), [170](#)
email receiver [170](#)
email receiver's address [88](#)
email sender [87](#), [170](#)
email server SMTP [87](#)
email settings [87](#), [169](#)
email SMTP [170](#)
email SMTP server [87](#)
email SSL encryption [88](#)
email title [87](#), [170](#)
email user name [87](#), [170](#)
emails [179](#)
encode channel [67](#)
encode settings [66](#)
encoder compression [67](#)
encoding bit rate [67](#)
encoding bit rate type [67](#)
encoding frame rate [67](#)
encoding type [67](#)
error alarm out [120](#), [186](#)
error alarm upload [187](#)
error alarm upload settings [120](#)
error buzzer [187](#)
error buzzer settings [120](#)
error email [187](#)
error email settings [120](#)
error latch [186](#)
error latch setting [120](#)
error message [120](#), [187](#)
event detection region [100](#)
event detection sensitivity [100](#)
event type [99](#)
external alarms [184](#)
frame rate [67](#)
frequency of snapshots [69](#)
FTP file length [90](#)
FTP password [90](#)
FTP settings [88](#)
FTP upload user rights [88](#)
FTP user name [90](#)
HDD channels [118](#)
HDD group settings [117](#), [189](#)
holiday settings [65](#), [194](#)
HTTP port [74](#), [163](#)
HTTPS port [163](#)
image quality for snapshots [69](#)
image settings [149](#)
image size for snapshots [69](#)
IP end address [77](#)
IP filter [169](#)
IP multicast group address [79](#)
IP start address [77](#)
IPC external alarm [94](#)
IPC offline alarm [94](#)
latch [96](#), [177](#)
local alarm buzzer [183](#)
local alarm delay [182](#)
local alarm emails [183](#)
local alarm latch [183](#)
local alarm message [183](#)
local alarm period [182](#)
local alarm PTZ activation [183](#)
local alarm recording channel [182](#)
local alarm snapshot [183](#)
local alarm tour [183](#)
local alarm type [182](#)
local alarms [181](#)
local alarms alarm out [183](#)
local input alarm [94](#)
local storage for schedules [189](#)
maintenance settings [126](#)
manual recording settings [121](#)
maximum network connection [163](#)
MD&Alarm schedule [189](#)
messages [179](#)
mobile setup for 3G [165](#)
monitor hue [150](#)
monitor privacy mask [68](#)
motion detection alarm out [101](#), [177](#)
motion detection alarm upload [102](#)
motion detection buzzer [179](#)
motion detection channel settings [102](#)
motion detection email settings [102](#)
motion detection emails [179](#)
motion detection latch [102](#), [177](#)
motion detection message [102](#), [179](#)
motion detection period [101](#), [176](#)
motion detection PTZ activation [102](#), [178](#)
motion detection recording channel [177](#)
motion detection recording delay [102](#)
motion detection region [177](#)
motion detection relay [177](#)
motion detection schedule [189](#)
motion detection sensitivity [176](#)
motion detection settings [98](#)
motion detection snapshot [179](#)
motion detection snapshot settings [102](#)
motion detection tour [178](#)
motion detection tours [102](#)
mouse properties [66](#)
MTU for network adaptor [74](#)
multicast [173](#)

multicast settings [79](#)
 net alarms [184](#)
 network adaptor MTU [74](#)
 network alarms [184](#)
 network alternate DNS server [74](#)
 network connection [163](#)
 network default gateway [73](#)
 network DHCP [74](#)
 network input alarm [94](#)
 network IP address [73](#)
 network IP version [73](#)
 network LAN download [74](#)
 network preferred DNS server [74](#)
 network settings [73](#), [75](#), [161](#)
 network subnet prefix [73](#)
 network TCP port [163](#)
 network transfer mode [74](#)
 NTP setup [77](#)
 NTP update period [78](#)
 overlay [68](#)
 PPPoE [80](#), [166](#)
 preview playback [65](#)
 preview privacy mask [68](#)
 privacy mask [68](#)
 PTZ activation [178](#)
 pulse interval [165](#)
 recording channel [190](#)
 recording settings [190](#)
 recording status [190](#)
 remote device [113](#)
 remote settings [156](#)
 reserved local multicast group address [79](#)
 RS232 [71](#)
 RS232 baud rate [72](#)
 RS232 console control [72](#)
 RS232 data bits [72](#)
 RS232 function [72](#)
 RS232 keyboard control [72](#)
 RS232 network keyboard [72](#)
 RS232 parity [72](#)
 RS232 protocol COM [72](#)
 RS232 PTZ matrix [72](#)
 RS232 stop bits [72](#)
 RS232 transparent COM [72](#)
 RTSP port [74](#), [163](#)
 schedule channel [70](#)
 schedule channels [190](#)
 schedule day [70](#)
 schedule extra stream channel [191](#)
 schedule holidays [70](#)
 schedule image storage channel [191](#)
 schedule main stream channel [191](#)
 schedule recording type [70](#)
 schedule redundancy [70](#)
 schedule snapshot [70](#)
 schedules [69](#)
 schedule pre-record time [70](#)
 snapshot [97](#), [179](#)
 snapshot frequency [69](#)
 snapshot image quality [69](#)
 snapshot image size [69](#)
 snapshot settings [69](#)
 snapshot timing [69](#)
 snapshot trigger [69](#)
 SNMP [91](#), [172](#)
 SNMP port [173](#)
 SNMP read community [173](#)
 SNMP trap address [92](#), [173](#)
 SNMP trap port [173](#)
 SNMP version [173](#)
 SNMP write community [173](#)
 storage [187](#)
 storage channel [189](#)
 storage schedules [187](#)
 stream resolution [67](#)
 TCP port [74](#)
 TCP/IP address remotely [162](#)
 TCP/IP alternate DNS remotely [162](#)
 TCP/IP LAN download remotely [162](#)
 TCP/IP MAC address remotely [162](#)
 TCP/IP mode remotely [162](#)
 TCP/IP preferred DNS remotely [162](#)
 TCP/IP settings [161](#)
 TCP/IP version remotely [162](#)
 time display [110](#)
 time display overlay [68](#)
 time settings [193](#)
 time sync [66](#)
 time synchronization [78](#)
 time zones [78](#)
 tours [178](#)
 transparency [110](#)
 UDP port [74](#), [163](#)
 UPnP [171](#)
 UPnP router LAN IP [83](#)
 UPnP settings [82](#)
 video compression [67](#)
 video loss alarm out settings [104](#)
 video loss alarm upload [105](#)
 video loss channel [103](#), [105](#)
 video loss detection [179](#)
 video loss emails [105](#)
 video loss latch settings [104](#)
 video loss message [105](#)
 video loss period [104](#)
 video loss PTZ activation [105](#)
 video loss recording delay [105](#)
 video loss settings [103](#)
 video loss snapshot settings [105](#)
 video loss tour [105](#)
 video quality [148](#)
 WAN IP [83](#)
 WIFI [163](#)
 WIFI autoconnect [85](#)
 WIFI settings [84](#)
 configuring email event interval [88](#)

- configuring GPRS for 3G [164](#)
- configuring IPC time sync [66](#)
- connecting
 - alarms [33](#)
 - WIFI [86](#)
- connection
 - log [60](#)
 - status [157](#)
 - WIFI status [86](#)
- connection status, WIFI [86](#)
- connections
 - audio output device to a PC [34](#)
 - bi-directional communication [34](#)
 - network [38](#)
 - PC to an audio input device [34](#)
 - system [38](#)
- contrast [150](#)
- copying setup [69](#)

D

- D1 [67](#)
- data bits
 - configuring RS232 [72](#)
- data operation [204](#)
- date
 - format [193](#)
 - format settings [64](#)
 - separator [193](#)
 - settings [64](#), [193](#)
- daylight saving time [64](#), [194](#)
- DDNS
 - configurations [81](#), [167](#)
 - default server address [81](#), [168](#)
 - domain mode [167](#), [168](#)
 - domain name [81](#), [167](#), [168](#)
 - email address [167](#)
 - Honeywell [167](#)
 - mode [81](#)
 - mode default [81](#)
 - server IP [81](#), [167](#), [168](#)
 - type [167](#)
 - types [81](#), [168](#)
 - username [168](#)
- Declaration of Conformance [6](#)
- decoding mode, live video [149](#)
- default
 - DDNS mode [81](#)
 - DDNS server address [81](#), [168](#)
 - DDNS server IP address [81](#)
 - display resolution [110](#)
 - domain name [168](#)
 - gateway [73](#)
 - Honeywell DDNS server address [81](#), [168](#)
 - HTTP port [74](#), [163](#)
 - HTTPS port [163](#)
 - maximum network connections [163](#)
 - MTU network adaptor [74](#)

- NTP port [78](#)
- password [113](#)
- PTZ matrix [72](#)
- resolution [200](#)
- restore UPnP defaults [83](#)
- RS232 baud rate [72](#)
- RS232 data bit [72](#)
- RS232 parity [72](#)
- RS232 stop bits [72](#)
- RTSP port [74](#), [163](#)
- saved path [153](#)
- settings [150](#), [201](#)
- snapshot save path [161](#)
- SNMP port [173](#)
- SNMP read community [173](#)
- SNMP write community [173](#)
- TCP port [74](#), [163](#)
- UDP port [74](#), [163](#)
- user name [113](#)
- users [195](#)
- video save path [161](#)
- default password
 - 666666 [41](#)
 - 888888 [41](#)
 - admin [41](#)
 - hidden user [41](#)
- default settings
 - configuring [111](#)
- deleting
 - devices remotely [157](#)
 - old files [126](#)
- details
 - information, log [204](#)
 - log [57](#)
- detection settings [98](#), [175](#)
- device
 - ID [65](#)
 - name [193](#)
 - number [65](#), [193](#)
- device control
 - device number [65](#)
- device search [156](#)
- devices
 - remotely adding [156](#)
 - remotely deleting [157](#)
 - remotely manually adding [157](#)
 - remotely modifying [157](#)
- DHCP [74](#)
- Dial No. [165](#)
- digital zoom [46](#), [51](#)
 - live video [149](#)
- disabling
 - alarm out settings [200](#)
 - alarms [154](#)
 - audio video [67](#)
- disconnect
 - users [59](#)
 - WIFI [86](#)

- disconnection [186](#)
 - net [186](#)
- disk
 - error [120](#), [186](#)
 - no space error [120](#), [186](#)
- display
 - default resolution [110](#)
 - image enhance [110](#)
 - resolution [110](#)
 - settings [109](#), [199](#)
- displaying
 - channel [200](#)
 - device information [149](#)
 - time [200](#)
- DNS [74](#)
- DNS server [74](#)
- domain mode [167](#)
 - DDNS [168](#)
- domain name [81](#)
 - DDNS [167](#), [168](#)
 - default [168](#)
- downloading video [152](#)
- DST [64](#), [194](#)

E

- editing files [51](#)
- email
 - anonymous [170](#)
 - attachments [170](#)
 - configuring event interval [88](#)
 - configuring health email [88](#)
 - configuring password [87](#)
 - configuring port [87](#)
 - configuring receiver's address [88](#)
 - configuring sender [87](#)
 - configuring server SMTP [87](#)
 - configuring SMTP [87](#)
 - configuring SSL encryption [88](#)
 - configuring title [87](#)
 - configuring user name [87](#)
 - enabling health email [171](#)
 - encryption [170](#)
 - error settings [120](#)
 - interval settings [171](#)
 - motion detection settings [102](#)
 - password [170](#)
 - port settings [170](#)
 - receiver [170](#)
 - sender [170](#)
 - settings [169](#)
 - SMTP settings [170](#)
 - snapshots [170](#)
 - test [171](#)
 - title [170](#)
 - user name [170](#)
- email address
 - DDNS [167](#)
- email settings, configuring [87](#)
- emails
 - abnormality [187](#)
 - camera masking [108](#)
 - error [187](#)
 - local alarm [183](#)
 - motion detection [179](#)
 - video loss [105](#)
- enabling
 - alarm disk error [155](#)
 - alarm disk full [155](#)
 - alarm out settings [200](#)
 - alarm sound [155](#)
 - alarm video masking [155](#)
 - alarms [154](#)
 - alarms video loss [155](#)
 - audio/video [67](#)
 - external alarms [155](#)
 - health email [88](#), [171](#)
 - motion detection [155](#)
 - no signal alarm [155](#)
 - prompt [155](#)
- encoder compression [67](#)
- encoding
 - audio remotely [158](#)
 - channel [67](#)
 - settings [66](#)
 - type [67](#)
 - video remotely [158](#)
- encryption [170](#)
 - configuring email SSL [88](#)
- end time, log [204](#)
- enhance image display [110](#)
- error
 - disk [186](#)
 - disk error [120](#)
 - internet disconnection [186](#)
 - IP conflict [120](#), [186](#)
 - MAC conflict [120](#), [186](#)
 - message settings [120](#)
 - net disconnection [120](#), [186](#)
 - no disk [120](#), [186](#)
 - no disk space [120](#)
 - no space [186](#)
 - settings [120](#)
 - types [120](#)
- errors
 - alarm upload settings [120](#)
 - buzzer settings [120](#)
 - email settings [120](#)
- EULA [130](#)
- event detection
 - configuring region [100](#)
 - sensitivity [100](#)
- event operation [204](#)
- event type [99](#)
 - no disk [186](#)
- exporting

- configuration files [202](#)
- external alarm
 - color code [50](#)
 - recorded file color [50](#)

F

- FCC compliance [5](#)
- file
 - backup [51](#)
 - list [50](#), [152](#)
 - video format [147](#)
- file name
 - backup file [57](#)
- files, deleting [126](#)
- finding, device name [193](#)
- fluency [74](#), [148](#)
- formatting
 - date [193](#)
 - date separator [193](#)
 - daylight saving time [64](#)
 - time [193](#)
- four-channel window [148](#)
- frame rate [67](#)
 - remotely configuring [158](#)
- free day [95](#)
- front panel components [27](#)
- FTP
 - file length [90](#)
 - password [90](#)
 - port [90](#)
 - remote directory [90](#)
 - server address [90](#)
 - settings [88](#)
 - upload user rights [88](#)
 - user name [90](#)
- full screen [148](#)
- function buttons for LAN [145](#)

G

- gateway
 - built-in switch [112](#)
- GPRS for 3G
 - configurations [164](#)
- green recorded file [50](#)
- group
 - management [123](#)
 - naming conventions [123](#)
 - rules [195](#)
 - settings [197](#)
- groups
 - adding [123](#), [198](#)
 - modifying [123](#), [198](#)
- GUI
 - channel display [110](#)
 - channel names [110](#)
 - language [193](#)

- time display [110](#)
- transparency [110](#), [200](#)

H

- H.264 [67](#)
- HDD [35](#)
 - abnormal indicator [29](#)
 - bad track warning [55](#)
 - configuring channels [118](#)
 - drive info [55](#)
 - drive status symbols [54](#)
 - free space [55](#)
 - full [193](#)
 - group settings [117](#), [189](#)
 - information [54](#)
 - installation [35](#)
 - management [116](#)
 - overwrite [193](#)
 - rewrite [65](#)
 - status [55](#)
 - stop recording [65](#), [193](#)
 - test recording settings [119](#)
 - total space [55](#)
 - type [55](#)
 - view recording time [55](#)
 - view type and capacity [55](#)
- HDMI port [29](#)
- hidden default user [123](#), [195](#)
- hidden user default password [41](#)
- holiday
 - period [65](#)
 - settings [65](#), [194](#)
- Honeywell config tool [129](#)
- Honeywell DDNS [81](#), [82](#), [167](#), [168](#)
- host IP [78](#)
- HTTP port [74](#)
 - configuration [163](#)
 - default [74](#), [163](#)
- HTTPS port
 - configuration [163](#)
 - default [163](#)
- hue [150](#)

I

- icons [40](#)
 - camera lock [40](#)
 - motion detection [40](#)
 - video loss [40](#)
- ID [65](#)
- image
 - enhance [200](#)
 - settings [149](#)
- image storage channel [191](#)
- importing
 - configuration files [202](#)
- information

- HDD [54](#)
- installing
 - HDD [35](#)
- instant record button [147](#)
- internet [186](#)
 - disconnection [186](#)
 - disconnection error [120](#)
- interval, email [171](#)
- IP
 - conflict error [120](#), [186](#)
 - end address [77](#)
 - start address [77](#)
 - version [73](#)
- IP address [73](#), [78](#)
 - built-in switch [112](#)
 - DDNS [81](#)
 - default DDNS server [81](#)
 - live video [149](#)
 - search [113](#)
 - UPnP router LAN [83](#)
 - WAN [83](#)
- IP address, modifying [138](#)
- IP configuration
 - blocked sites [169](#)
 - trusted sites [169](#)
- IP filter
 - configuration [169](#)
- IP multicast group address [79](#)
- IPv6 [75](#)
- ISP [166](#)

L

- LAN
 - download [74](#)
- LAN mode [145](#)
 - function buttons [145](#)
- language [65](#), [193](#)
- latch
 - abnormality [186](#)
 - error [186](#)
 - error setting [120](#)
 - settings [102](#), [177](#)
 - video loss settings [104](#)
- led
 - HDD abnormal indicator [29](#)
 - network abnormal indicator [29](#)
- license agreement [130](#)
- live video
 - audio On/Off [149](#)
 - bit rate [149](#)
 - channel number [149](#)
 - decoding mode [149](#)
 - digital zoom [149](#)
 - IP address [149](#)
 - local recording [149](#)
 - recording system folder [149](#)
 - snapshot [149](#)

- snapshot system folder [149](#)
- local alarm activation [183](#)
- local recording, live video [149](#)
- log [56](#), [203](#)
 - backup [57](#), [204](#)
 - begin time [204](#)
 - clear [204](#)
 - configuration operation [204](#)
 - data operation [204](#)
 - detailed information [204](#)
 - details [57](#)
 - end time [204](#)
 - event operation [204](#)
 - record operation [204](#)
 - search [204](#)
 - start/end times [57](#)
 - system operation [204](#)
 - type [204](#)
 - types [57](#)
 - user management [204](#)
- logging in
 - NVR [39](#)
- logging out [128](#), [205](#)

M

- MAC address [73](#)
 - conflict error [120](#), [186](#)
- maintenance settings [126](#)
- managing
 - HDD [116](#)
- manual snapshot [47](#)
- manual time synchronization [78](#)
- manually adding a device [113](#)
- maximum network connections
 - default [163](#)
- maximum user connection [74](#)
- MD&alarm [188](#)
- messages [96](#)
 - abnormality [187](#)
 - error [187](#)
 - error settings [120](#)
 - local alarm [183](#)
 - motion detection [179](#)
 - video loss settings [105](#)
- MG-SOFT MIB browser [92](#)
- MIC in port [30](#)
- MIC out port [30](#)
- MJPEG [67](#)
- mobile setup [165](#)
- modifying
 - devices remotely [157](#)
 - groups [123](#), [198](#)
 - passwords [197](#)
 - users [124](#), [196](#)
- monitor
 - brightness [150](#)
 - channels [146](#)

- contrast [150](#)
- hue [150](#)
- saturation [150](#)
- monitoring, real-time [148](#)
- motion detection [99](#)
 - alarm color code [50](#)
 - alarm out [177](#)
 - alarm out configurations [101](#)
 - alarm upload settings [102](#)
 - buzzer [179](#)
 - channel settings [102](#)
 - configuring latch settings [102](#)
 - email settings [102](#)
 - emails [179](#)
 - enabling [155](#)
 - latch settings [177](#)
 - message settings [102](#)
 - messages [179](#)
 - period [101](#), [176](#)
 - PTZ activation [178](#)
 - PTZ activation settings [102](#)
 - recorded file color [50](#)
 - recording channel [177](#)
 - recording delay [102](#)
 - region [177](#)
 - relay settings [177](#)
 - sensitivity [176](#)
 - settings [98](#)
 - snapshot [179](#)
 - snapshot settings [102](#)
 - status icon [40](#)
 - tour settings [102](#)
 - tours [178](#)
- mouse properties [66](#)
- mouseset [66](#)
- MPEG4 [67](#)
- MTU [74](#)
- MTU adaptor default [74](#)
- multicast [173](#)
 - group address [79](#)
 - settings [79](#)
- multiple cast [79](#)

N

- name
 - backup file [57](#)
- naming conventions
 - account [123](#)
 - group [123](#)
 - user [123](#)
- navigation bar [66](#)
- net disconnection [186](#)
 - IP conflict [186](#)
- network
 - alternate DNS server [74](#)
 - default gateway [73](#)
 - DHCP [74](#)

- fluency [74](#)
- HTTP port [74](#)
- IP address [73](#)
- IP version [73](#)
- keyboard [72](#)
- LAN download [74](#)
- load [62](#)
- MAC address [73](#)
- ports [29](#)
- preferred DNS server [74](#)
- RTSP port [74](#)
- settings [73](#), [161](#)
- sniffer [61](#)
- subnet prefix [73](#)
- TCP port [74](#)
- test [61](#)
- transfer mode [74](#)
- UDP port [74](#)
- video quality [74](#)
- network abnormal indicator [29](#)
- network alarms [184](#)
- network connection
 - configurations [163](#)
 - configuring maximum connections [163](#)
- no disk error [120](#), [186](#)
- no signal [185](#)
- no space error [186](#)
- normally closed [94](#)
- normally open [94](#)
- NTP [194](#)
 - port [194](#)
 - port default [78](#)
 - server [194](#)
 - setup [77](#)
 - updated period [78](#)
 - upgrade period [194](#)
- NTSC [65](#), [193](#)
- NVR [58](#)
 - alarm in, number of [58](#)
 - back panel [29](#)
 - build date [58](#)
 - channel [58](#)
 - components [27](#)
 - restart [128](#)
 - serial number [58](#)
 - shutdown [127](#)
 - status icons [40](#)
 - system version [58](#)
 - time [193](#)
 - version [58](#)

O

- online users [58](#), [204](#)
- opening the config tool [131](#)
- opening Web client [132](#)
- overlay
 - channel display [68](#)

configuration [68](#)
time display [68](#)

P

pack duration [65](#), [193](#)
packets
 backup [61](#)
 opening [62](#)
PAL [65](#), [193](#)
part mapping list [83](#)
passwords
 configuring email [87](#)
 default [113](#)
 email [170](#)
 FTP [90](#)
 modifying [197](#)
 PPPoE [80](#), [166](#)
PAT table [83](#)
PC
 requirements [141](#)
 time [193](#)
period
 video loss settings [104](#)
playback
 button [147](#)
 channel selection [49](#)
 file list [151](#)
 interface [151](#)
 mode [49](#)
playing recorded video [147](#), [150](#)
PoE
 ports [30](#)
popup menu [32](#)
ports
 alarm input [30](#)
 alarm input port ground [30](#)
 alarm output ports [30](#)
 audio input port [30](#)
 audio output port [30](#)
 configuring email ports [87](#)
 email settings [170](#)
 FTP [90](#)
 HDMI [29](#)
 network [29](#)
 NTP [194](#)
 PoE [30](#)
 power input [30](#)
 power input port [30](#)
 RS232 [29](#)
 SNMP [173](#)
 SNMP trap address [173](#)
 SNMP trap port [173](#)
 USB 2.0 [29](#)
 VGA [29](#)
 video output [30](#)
power button [27](#)
power input port [30](#)

PPPoE

configurations [80](#), [166](#)
name [80](#)
password [80](#), [166](#)
username [166](#)

PPS [167](#)

preferred DNS server [74](#)
preparing for UPnP [171](#)
pre-record time configuration [70](#)
preview

 control settings [202](#)
 controls [46](#)
 playback [65](#)

privacy mask

 configuring [68](#)
 monitor mode [68](#)
 preview mode [68](#)
 video overlay [160](#)

processor [141](#)

professional surveillance software [167](#)

prompt enabling [155](#)

PTZ [105](#), [183](#)

 activating motion detection [178](#)
 alarm activation [96](#)
 camera masking activation [108](#)
 control a PTZ camera [47](#)
 matrix [72](#)
 matrix default setting [72](#)
 motion detection activation settings [102](#)

pulse interval configurations [165](#)

R

RAM [141](#)

rate

 video data stream [55](#)

read community [173](#)

real-time

 backup [46](#)
 monitoring [148](#)
 playback control [46](#)

receive rate [62](#)

record operation [204](#)

recorded video

 calendar search [49](#)
 search type [49](#)
 searching for [47](#)

recording

 automatic [190](#)
 camera masking channel [108](#)
 camera masking delay [108](#)
 channel [190](#)
 duration [193](#)
 how to record [97](#)
 manual [122](#)
 motion detection delay [102](#)
 pack duration [65](#)
 rewrite HDD [65](#)

- scheduled [122](#)
- settings [190](#)
- settings, manual [121](#)
- status [40](#), [190](#)
- status icon [40](#)
- stop when HDD full [65](#)
- turning off [190](#)
- type [50](#)
- type colors [50](#)
- video loss delay [105](#)
- video standard [65](#)
- recording channel
 - motion detection [177](#)
- red recorded file [50](#)
- reference bit rate
 - remotely configuring [159](#)
- region, configuring for event detection [100](#)
- region, motion detection [177](#)
- regularly recorded file color [50](#)
- regulatory [5](#)
- related documents [22](#)
- relay
 - motion detection [177](#)
- remote
 - device search [156](#)
- remote control
 - device number [65](#)
- remote device information tab [59](#)
- remote settings [156](#)
- requirement [35](#)
- requirements
 - HDD [35](#)
 - non-integrated video card [141](#)
 - processor [141](#)
 - system memory [141](#)
- reserved local multicast group address [79](#)
- resolution [67](#), [200](#)
 - default [200](#)
 - display [110](#)
 - remotely configuring [158](#)
- restarting the NVR [128](#)
- restore to default settings [150](#)
- reusable function [123](#)
- right-click menu [47](#)
- router
 - LAN IP [83](#)
 - port mapping [83](#)
- RS232
 - baud rate [72](#)
 - configuration [71](#)
 - configuring the function [72](#)
 - console control [72](#)
 - data bit default [72](#)
 - data bits [72](#)
 - default baud rate [72](#)
 - default data bit [72](#)
 - default parity [72](#)
 - default stop bits [72](#)

- keyboard control [72](#)
- network keyboard [72](#)
- parity configuration [72](#)
- parity default [72](#)
- port [29](#)
- protocol COM [72](#)
- PTZ matrix [72](#)
- stop bit defaults [72](#)
- stop bits configuration [72](#)
- transparent COM [72](#)
- RTSP port [74](#)
 - configurations [163](#)
 - default [74](#)

S

- safety instructions [7](#)
- SATA drive [55](#)
- saturation [150](#)
- save path
 - configuration [160](#)
 - default [153](#)
- schedules [69](#)
 - alarm [189](#)
 - channels [190](#)
 - configuring holidays [70](#)
 - extra stream channel [191](#)
 - image storage channel [191](#)
 - local storage [189](#)
 - main stream channel [191](#)
 - MD&Alarm [189](#)
 - motion detection [189](#)
 - recording type [70](#)
 - redundancy [70](#)
 - selecting a day [70](#)
 - snapshot settings [70](#)
 - storage [187](#)
- SDK [93](#)
- search
 - by card number [50](#)
 - IP address [113](#)
 - log [204](#)
 - type [49](#)
- send rate [62](#)
- sender
 - configuring email [87](#)
- sensitivity
 - event detection [100](#)
- serial number [58](#)
- server IP [167](#)
 - DDNS [168](#)
- service [7](#)
- settings [47](#), [64](#), [65](#), [171](#)
 - HDD group [117](#)
 - NVR date [64](#)
 - NVR date format [64](#)
 - NVR time [64](#)
 - NVR time format [65](#)

- shortcut menu [114](#)
- shutting down [127](#), [128](#)
- simple network management protocol [91](#)
- single-channel window [148](#)
- SMTP [170](#)
 - configuring email [87](#)
 - email server [87](#)
- snapshot [47](#), [52](#)
 - camera masking settings [108](#)
 - configuring channel [159](#)
 - configuring frequency [69](#)
 - configuring image size remotely [159](#)
 - configuring mode remotely [159](#)
 - configuring quality remotely [159](#)
 - default save path [161](#)
 - image quality [69](#)
 - image size [69](#), [159](#)
 - live video [149](#)
 - local alarm [183](#)
 - motion detection settings [102](#), [179](#)
 - remotely configuring [159](#)
 - remotely configuring frequency [159](#)
 - save path [160](#)
 - settings [69](#)
 - timing [69](#)
 - trigger [69](#)
 - video loss settings [105](#)
- SNMP [91](#)
 - configurations [91](#), [172](#)
 - default port [173](#)
 - default read community setting [173](#)
 - port settings [173](#)
 - read community [173](#)
 - trap address [92](#), [173](#)
 - trap port [173](#)
 - version [173](#)
 - write community [173](#)
 - write community default [173](#)
- SNTP server [77](#)
- software CD [129](#)
- start talking button [146](#)
- startup wizard [66](#)
- status icons [40](#)
- storage [187](#)
 - blue [188](#)
 - channel [189](#)
 - green [188](#)
 - local storage for schedules [189](#)
 - red [188](#)
 - schedules [187](#)
 - yellow [188](#)
- stream resolution [67](#)
- subnet mask
 - built-in switch [112](#)
- subnet prefix [73](#)
- supported cameras [157](#)
- switch user [128](#)
- SXGA [67](#)

- symbols
 - HDD drive status [54](#)
- sync
 - IPC time sync [66](#)
- system
 - connections [38](#)
 - date [64](#)
 - date format [64](#)
 - information [203](#)
 - operation [204](#)
 - time [64](#), [193](#)
 - time format [65](#)
 - version [203](#)
 - version of NVR [58](#)

T

- taking a manual snapshot [47](#)
- taking snapshots [52](#)
- TCP
 - port default [74](#), [163](#)
 - port number [93](#)
- TCP port [74](#)
 - configuration [163](#)
- TCP/IP
 - address remote configurations [162](#)
 - alternate DNS remote configurations [162](#)
 - LAN download remote configurations [162](#)
 - MAC address remote configurations [162](#)
 - preferred DNS remote configurations [162](#)
 - version remote configurations [162](#)
- TCP/IP mode
 - remote configurations [162](#)
- TCP/IP settings
 - remote configurations [161](#)
- test
 - email [171](#)
 - HDD recording location [119](#)
- time
 - NVR [193](#)
 - zone [194](#)
- time bar [50](#)
 - unit [51](#)
- time display [110](#), [160](#), [200](#)
 - overlay [68](#)
- time format [193](#)
 - settings [65](#)
- time reboot [126](#)
- time settings [64](#), [193](#)
- time sync [193](#)
- time zones [78](#)
- timing for snapshots [69](#)
- tour function priority [47](#)
- tours
 - camera masking settings [108](#)
 - motion detection [178](#)
 - motion detection settings [102](#)
 - video loss settings [105](#)

transparency [110](#), [200](#)
 trap address [92](#)
 triggers for snapshots [69](#)
 trusted sites [77](#), [169](#)
 type
 HDD [55](#)

U

UDP port [74](#)
 configuration [163](#)
 default [74](#), [163](#)
 ULA [130](#)
 uninstall Web control [142](#)
 update period, NTP [78](#)
 upgrade period [194](#)
 UPnP [83](#), [171](#)
 preparations [171](#)
 restore defaults [83](#)
 settings [82](#)
 USB 2.0 port [29](#)
 user limitations [123](#)
 user management [123](#), [204](#)
 user name [90](#)
 configuring email [87](#)
 default [113](#)
 email [170](#)
 user naming conventions [123](#)
 user rules [195](#)
 user settings [195](#)
 username
 6666666 [41](#)
 8888888 [41](#)
 admin [41](#)
 DDNS [81](#), [168](#)
 hidden default
 hidden default user [41](#)
 PPPoE [166](#)
 users
 adding [124](#), [196](#)
 maximum connection [74](#)
 modifying [124](#), [196](#)

V

version [58](#)
 system [203](#)
 vertical synchronization [148](#)
 VGA port [29](#)
 video
 card [141](#)
 color [47](#)
 color settings [47](#)
 compression [67](#)
 data stream rate [55](#)
 default save path [161](#)
 file format [147](#)
 output port [30](#)

 playback [147](#), [150](#)
 quality [74](#), [148](#)
 remote encoding [158](#)
 save path [160](#)
 standard [65](#), [193](#)
 video loss [98](#), [99](#)
 activation [105](#)
 alarm out settings [104](#)
 alarm upload [105](#)
 channel [105](#)
 channel setting [103](#)
 configuring emails [105](#)
 detection [179](#)
 latch settings [104](#)
 message settings [105](#)
 period settings [104](#)
 PTZ activation [105](#)
 recording delay [105](#)
 settings [103](#)
 snapshot settings [105](#)
 tour settings [105](#)
 video loss status icon [40](#)
 video overlay
 channel configuration [160](#)
 channel display configuration [160](#)
 configuration [160](#)
 configuring remotely [159](#)
 privacy mask [160](#)
 time display configuration [160](#)
 video, downloading [152](#)
 view recording time [55](#)
 viewer configuration controls [148](#)
 viewing
 network MAC address [73](#)
 volume button [52](#)

W

WAN
 IP address [83](#)
 warnings [5](#)
 bad HDD track [55](#)
 warranty [7](#)
 WCDMA [165](#)
 Web client, opening [132](#)
 WEEE [6](#)
 WEP [86](#)
 WIFI [84](#)
 autoconnect [85](#)
 configurations [163](#)
 connect [86](#)
 connection status [86](#)
 disconnect [86](#)
 verification type [86](#)
 wizard, startup [66](#)
 WLAN type [165](#)
 work day [95](#)
 WPA [86](#)

WPA2 [86](#)
write community [173](#)

X
X [117](#)

Y
yellow recorded file [50](#)

Z
zoom [51](#)

Honeywell Security Products Americas (Head Office)

2700 Blankenbaker Pkwy, Suite 150
Louisville, KY 40299, USA
www.honeywell.com/security
☎ +1 800 323 4576

Honeywell Security Northern Europe

Ampèrestraat 41
1446 TR Purmerend, The Netherlands
www.honeywell.com/security/nl
☎ +31 (0) 299 410 200

Honeywell Security Europe/South Africa

Aston Fields Road, Whitehouse Industrial Estate
Runcorn, WA7 3DL, United Kingdom
www.honeywell.com/security/uk
☎ +44 (0) 1928 754 028

Honeywell Security Deutschland

Johannes-Mauthe-Straße 14
72458 Albstadt, Germany
www.honeywell.com/security/de
☎ +49 (0) 7431 801-0

**Honeywell Security Products Americas
Caribbean/Latin America**

9315 NW 112th Ave.
Miami, FL 33178, USA
www.honeywell.com/security/clar
☎ +1 305 805 8188

Honeywell Security France

Immeuble Lavoisier
Parc de Haute Technologie
3-7 rue Georges Besse
92160 Antony, France
www.honeywell.com/security/fr
☎ +33 (0) 1 40 96 20 50

Honeywell Security Asia Pacific

35F Tower A, City Center, 100 Zun Yi Road
Shanghai 200051, China
www.asia.security.honeywell.com
☎ +86 21 2219 6888

Honeywell Security Italia SpA

Via della Resistenza 53/59
20090 Buccinasco
Milan, Italy
www.honeywell.com/security/it
☎ +39 (0) 2 4888 051

Honeywell Security Middle East/N. Africa

Emaar Business Park, Sheikh Zayed Road
Building No. 2, Office No. 301
Post Office Box 232362
Dubai, United Arab Emirates
www.honeywell.com/security/me
☎ +971 (0) 4 450 5800

Honeywell Security España

Avenida de Italia, nº 7, 2ª planta
C.T. Coslada
28821 Coslada, Madrid, Spain
www.honeywell.com/security/es
☎ +34 902 667 800

Honeywell

www.honeywell.com/security
+1 800 323 4576 (North America only)
<https://www.honeywellsystems.com/ss/techsupp/index.html>

Document 800-19340V2 – Rev A – 01/2015

© 2015 Honeywell International Inc. All rights reserved. No part of this publication may be reproduced by any means without written permission from Honeywell. The information in this publication is believed to be accurate in all respects. However, Honeywell cannot assume responsibility for any consequences resulting from the use thereof. The information contained herein is subject to change without notice. Revisions or new editions to this publication may be issued to incorporate such changes.