

# VortexMaster FSV400, SwirlMaster FSS400

## Vortex and Swirl flowmeter



Device firmware version:

- 02.02.xx (HART)
- 01.00.xx (Modbus)
- 01.00.xx (PROFIBUS)
- 01.00.xx (FOUNDATION Fieldbus)

**Measurement made easy**

—  
VortexMaster  
FSV430 / FSV450

SwirlMaster  
FSS430 / FSS450

### Introduction

The robust VortexMaster FSV4x0 vortex flowmeter by ABB is a high-performance and reliable tool, which is especially suited for the measurement of liquids, gas, and steam.

The SwirlMaster FSS4x0 swirl flowmeters combine the measuring dynamics of turbine flowmeters with the robustness and reliability of Vortex flowmeters and require only very short inlet and outlet sections.

Equipped with digital signal processing (DSP) and advanced filtering techniques, these innovative flowmeters allow for excellent flow signal detection and provide measurement immunity from the effects of hydraulic noise and pipe vibration.

### Additional Information

Additional documentation on VortexMaster FSV400, SwirlMaster FSS400 is available for download free of charge at [www.abb.com/flow](http://www.abb.com/flow).

Alternatively simply scan this code:



FSV430

FSV450

FSS430

FSS450

## Table of contents

<b>1</b>	<b>Safety</b> .....	<b>4</b>
	General information and instructions.....	4
	Warnings.....	4
	Intended use.....	4
	Improper use.....	5
	Warranty provisions.....	5
	Notes on data safety.....	5
	Manufacturer's address.....	5
<b>2</b>	<b>Use in potentially explosive atmospheres</b> .....	<b>6</b>
	Obligations of the operator.....	6
	Ex marking.....	6
	ATEX, IECEx, NEPSI.....	6
	FM / CSA.....	6
	Overview of explosion protection approvals.....	7
	Assembly and operating instructions.....	8
	Devices with aluminum housing.....	8
	Protection against electrostatic discharges.....	8
	Opening and closing the housing.....	8
	Temperature resistance for the connecting cable.....	8
	Cable glands.....	9
	Signal cable installation in accordance with cFMus.....	9
	Electrical connections.....	10
	Type of protection 'non-sparking' (Ex n / NA) and	
	'intrinsic safety' (Ex ic), Zone 2, 22.....	11
	Ex marking.....	11
	Electrical Data.....	12
	Temperature Data.....	14
	Zone 0, 1, 20, 21 - type of protection 'intrinsically safe' ..	15
	Ex marking.....	15
	Electric and temperature data.....	16
	Limit value tables.....	18
	Type of protection 'flameproof (enclosure)' – Zone 1, 21/22	
	Ex marking.....	22
	Electric and temperature data.....	22
	Repair.....	24
<b>3</b>	<b>Design and function</b> .....	<b>25</b>
	Overview.....	25
	VortexMaster FSV430 / FSV450.....	25
	SwirlMaster FSS430 / FSS450.....	26
	Transmitter.....	27
	Model variants.....	28
	Measurement principle.....	28
<b>4</b>	<b>Product identification</b> .....	<b>30</b>
	Name plate.....	30
<b>5</b>	<b>Transport and storage</b> .....	<b>31</b>
	Inspection.....	31
	Transport.....	31
	Storing the device.....	31
	Ambient conditions.....	31
	Returning devices.....	31
<b>6</b>	<b>Installation</b> .....	<b>32</b>
	Safety instructions.....	32
	Installation conditions.....	32
	General.....	32
	Inlet and outlet sections.....	33
	Avoiding cavitation.....	34
	Installation at high measuring medium temperatures	
	.....	34
	Installation for external pressure and temperature	
	measurement.....	34
	Installation of setting equipment.....	35
	Sensor insulation.....	35
	Ambient conditions.....	36
	Ambient temperature.....	36
	Relative humidity.....	36
	Measuring medium temperature range.....	36
	Pressure Equipment Directive.....	36
	CRN approval.....	36
	Material load.....	37
	FSV430, FSV450.....	37
	FSS430, FSS450.....	38
	Installing the sensor.....	39
	Installation of the flowmeter.....	39
	Centering the wafer type design.....	40
	Adjusting the transmitter position.....	40
	Opening and closing the housing.....	41
<b>7</b>	<b>Electrical connections</b> .....	<b>42</b>
	Safety instructions.....	42
	Signal cables.....	43
	Recommended cables.....	43
	Installing the connection cables.....	43
	Cable glands.....	44
	Devices with an M20 × 1.5 thread.....	44
	Devices with a ½ in NPT thread.....	44
	Grounding.....	44
	Devices with HART® communication.....	45
	Current output / HART output.....	45
	Analog input 4 to 20 mA.....	47
	HART® communication with remote transmitter.....	47
	HART® communication connection example.....	48
	Devices with Modbus® communication.....	49
	Modbus communication.....	49
	Cable specification.....	50
	Devices with PROFIBUS PA® or FOUNDATION-Fieldbus®	
	communication.....	51
	Cable specification.....	51
	Connection to remote mount design.....	52
	Producing a signal cable.....	52
	Connecting the signal cable.....	53

<b>8 Commissioning</b> .....	<b>54</b>	<b>10 Diagnosis / error messages</b> .....	<b>131</b>
Safety instructions.....	54	General Notes .....	131
General .....	54	Sensor .....	131
Digital output.....	54	Application conditions.....	131
Checks prior to commissioning .....	55	Transmitter .....	131
Power Supply Power-Up.....	55	Calling up the error description .....	132
Checks after switching on the power supply .....	55	Possible error messages .....	133
Checking and configuring the basic settings .....	55	Response of the outputs to error messages .....	137
Parameterization via the menu function Easy Setup .....	56	Malfunctions without error messages .....	139
Devices with HART® and Modbus® communication. ....	60	<b>11 Maintenance</b> .....	<b>141</b>
Hardware Settings .....	60	Safety instructions .....	141
Operating modes .....	65	Cleaning.....	141
Energy measurement for liquids, gases and steam ...	73	Sensor .....	141
Natural gas calculation in accordance with AGA8 /		<b>12 Repair</b> .....	<b>142</b>
SGERG88 .....	78	Replacing the transmitter, downloading system data.	142
Eliminating HART® communication faults.....	83	Returning devices .....	142
Devices with PROFIBUS PA® or FOUNDATION-Fieldbus®		<b>13 Dismounting and disposal</b> .....	<b>143</b>
communication.....	84	Dismounting .....	143
Hardware Settings .....	84	Disposal .....	143
PROFIBUS PA® .....	85	<b>14 Specification</b> .....	<b>143</b>
FOUNDATION Fieldbus® .....	86	<b>15 Additional documents</b> .....	<b>143</b>
<b>9 Operation</b> .....	<b>88</b>	<b>16 Appendix</b> .....	<b>144</b>
Safety instructions.....	88	Return form.....	144
Parameterization of the device .....	88	Measuring range table .....	145
Menu navigation .....	88	FSV430, FSV450 .....	145
Menu levels .....	89	FSS430, FSS450 .....	146
Process display .....	90		
Switching to the information level (operator menu).....	90		
Switching to the configuration level (parameterization)	91		
Selecting and changing parameters.....	92		
Entry from table.....	92		
Error messages on the LCD display .....	93		
Parameter overview .....	94		
Parameter descriptions .....	104		
Menu: Easy Setup .....	104		
Menu: Device Info .....	108		
Menu: Device Setup.....	110		
Menu: Display .....	114		
Menu: Input/Output .....	115		
Menu: Process Alarm .....	118		
Menu: Communication for devices with HART®			
communication.....	119		
Menu: Communication for devices with Modbus®			
communication.....	120		
Menu: Communication for devices with PROFIBUS PA®			
communication.....	121		
Menu: Communication for devices with			
FOUNDATION Fieldbus® communication .....	123		
Menu: Diagnostics.....	125		
Menu: Totalizer .....	127		
Counter overflow.....	128		
Software history.....	129		
Zero point balance under operating conditions .....	130		
Automatic zero point balancing .....	130		
Manual zero point balancing .....	130		

# 1 Safety

## General information and instructions

These instructions are an important part of the product and must be retained for future reference.

Installation, commissioning, and maintenance of the product may only be performed by trained specialist personnel who have been authorized by the plant operator accordingly. The specialist personnel must have read and understood the manual and must comply with its instructions.

For additional information or if specific problems occur that are not discussed in these instructions, contact the manufacturer.

The content of these instructions is neither part of nor an amendment to any previous or existing agreement, promise or legal relationship.

Modifications and repairs to the product may only be performed if expressly permitted by these instructions.

Information and symbols on the product must be observed.

These may not be removed and must be fully legible at all times.

The operating company must strictly observe the applicable national regulations relating to the installation, function testing, repair and maintenance of electrical products.

## Warnings

The warnings in these instructions are structured as follows:

### DANGER

The signal word '**DANGER**' indicates an imminent danger. Failure to observe this information will result in death or severe injury.

### WARNING

The signal word '**WARNING**' indicates an imminent danger. Failure to observe this information may result in death or severe injury.

### CAUTION

The signal word '**CAUTION**' indicates an imminent danger. Failure to observe this information may result in minor or moderate injury.

### NOTICE

The signal word '**NOTICE**' indicates possible material damage.

### Note

'**Note**' indicates useful or important information about the product.

## Intended use

This device is intended for the following uses:

- For conveying liquid and gaseous media (including unstable liquids and gases)
- For measuring volume flow in the operating condition.
- For measuring standard volume flow (indirectly via volume flow rate, pressure and temperature).
- For measuring mass flow (indirectly via volume flow, pressure / temperature and density)
- For measuring the energy flow (indirectly via volume flow, pressure / temperature and density)
- For measuring the temperature of the medium

The device has been designed for use exclusively within the technical limit values indicated on the identification plate and in the data sheets.

When using measuring media, the following points must be observed:

- Measuring media may only be used if, based on the state of the art or the operating experience of the user, it can be assured that the chemical and physical properties necessary for operational security of the materials of the wetted parts of the temperature sensor will not be adversely affected during the operating time.
- Media containing chloride in particular can cause corrosion damage to stainless steels which, although not visible externally, can damage wetted parts beyond repair and lead to the measuring medium escaping. It is the operator's responsibility to check the suitability of these materials for the respective application.
- Measuring media with unknown properties or abrasive measuring media may only be used if the operator is able to perform regular and suitable tests to ensure the safe condition of the device

## Improper use

The following are considered to be instances of especially improper use of the device:

- Operation as a flexible compensating adapter in piping, for example for compensating pipe offsets, pipe vibrations, pipe expansions, etc.
- For use as a climbing aid, for example for mounting purposes.
- For use as a bracket for external loads, for example as a support for piping, etc.
- Material application, for example by painting over the housing, name plate or welding/soldering on parts.
- Material removal, for example by spot drilling the housing.

## Warranty provisions

Using the device in a manner that does not fall within the scope of its intended use, disregarding this manual, using underqualified personnel, or making unauthorized alterations releases the manufacturer from liability for any resulting damage. This renders the manufacturer's warranty null and void.

## Notes on data safety

This product is designed to be connected to and to communicate information and data via a network interface. It is operator's sole responsibility to provide and continuously ensure a secure connection between the product and your network or any other network (as the case may be). Operator shall establish and maintain any appropriate measures (such as but not limited to the installation of firewalls, application of authentication measures, encryption of data, installation of anti-virus programs, etc.) to protect the product, the network, its system and the interface against any kind of security breaches, unauthorized access, interference, intrusion, leakage and / or theft of data or information. ABB Automation Products GmbH and its affiliates are not liable for damages and / or losses related to such security breaches, any unauthorized access, interference, intrusion, leakage and / or theft of data or information.

## Manufacturer's address

### **ABB Automation Products GmbH Measurement & Analytics**

Schillerstr. 72  
32425 Minden  
Germany  
Tel: +49 571 830-0  
Fax: +49 571 830-1806

### **ABB Inc. Measurement & Analytics**

125 E. County Line Road  
Warminster, PA 18974  
USA  
Tel: +1 215 674 6000  
Fax: +1 215 674 7183

### **ABB Engineering (Shanghai) Ltd. Measurement & Analytics**

No. 4528, Kangxin Highway, Pudong New District  
Shanghai, 201319,  
P.R. China  
Tel: +86(0) 21 6105 6666  
Fax: +86(0) 21 6105 6677  
Email: china.instrumentation@cn.abb.com

### **Customer service center**

Tel: +49 180 5 222 580  
Email: automation.service@de.abb.com

## 2 Use in potentially explosive atmospheres

### Obligations of the operator

#### Ex marking

If the device manufacturer has not specified the type of protection on the name plate, the operator must specify the type of protection used on the name plate, by permanent means, during installation of the device.

#### ATEX, IECEx, NEPSI

The installation, commissioning, maintenance and repair of devices in potentially explosive atmospheres must only be carried out by appropriately trained personnel. Works may be carried out only by persons, whose training has included instructions on different types of protection and installation techniques, concerned rules and regulations as well as general principles of zoning.

The person must possess the appropriate competences for the type of work to be conducted.

The safety instructions for electrical apparatus in potentially explosive areas must be in accordance with Directive 2014/34/EU (ATEX) and IEC 60079-14 (Installation of electrical equipment in potentially explosive areas).

Comply with the applicable regulations for the protection of employees to ensure safe operation.

#### FM / CSA

The installation, commissioning, maintenance and repair of devices in areas with explosion hazard must only be carried out by appropriately trained personnel.

The operator must strictly observe the applicable national regulations with regard to installation, function tests, repairs, and maintenance of electrical devices. (e. g. NEC, CEC).

## Overview of explosion protection approvals

The following tables provide an overview of the approvals available for explosion protection. Refer to the appropriate chapter for information on Ex marking as well as electric and temperature data!

### Type of protection 'non-sparking' (Ex n / NA) and 'intrinsic safety' (Ex ic\*), Zone 2, 22

Approval	Order code	Ex relevant specifications
ATEX (Europe)	B1	Refer to <b>Type of protection 'non-sparking' (Ex n / NA) and 'intrinsic safety' (Ex ic), Zone 2, 22</b> on page 11.
IECEX	N1	
NEPSI (China)	S2	
FM (USA and Canada)	F3	

\* Only for devices with PROFIBUS PA® or FOUNDATION-Fieldbus® communication

### Type of protection 'intrinsic safety' (Ex ia / IS), Zone 0, 1, 20, 21

Approval	Order code	Ex relevant specifications
ATEX (Europe)	A4	Refer to <b>Zone 0, 1, 20, 21 - type of protection 'intrinsically safe'</b> on page 15.
IECEX	N2	
NEPSI (China)	S6	
FM (USA and Canada)	F4	

### Type of protection 'flameproof enclosure' (Ex db ia / XP-IS), Zone 1, 21

Approval	Order code	Ex relevant specifications
ATEX (Europe)	A9	Refer to <b>Type of protection 'flameproof (enclosure)' - Zone 1, 21</b> on page 22.
IECEX	N3	
NEPSI (China)	S1	
FM (USA and Canada)	F1	

### Combined approvals

In the case of combined approvals, the user decides on the type of protection during installation.

Type of protection	Order code	Ex relevant specifications
ATEX Ex n + Ex ia	B8 = B1 + A4	For combined approvals, the Ex relevant specification of the respective individual approvals apply.
ATEX Ex n + Ex ia + Ex db ia	B9 = B1 + A4 + A9	
IEC Ex Ex n + Ex ia	N8 = N1 + N2	
IEC Ex Ex n + Ex ia + Ex db ia	N9 = N1 + N2 + N3	
NEPSI Ex n + Ex ia	S8 = S2 + S6	
NEPSI Ex n + Ex ia + Ex db ia	S9 = S2 + S1 + S6	
cFMus NA + IS	F8 = F3 + F4	
cFMus NA + IS + XP-IS	F9 = F3 + F4 + F1	

## ... 2 Use in potentially explosive atmospheres

### Assembly and operating instructions

#### Devices with aluminum housing

##### **DANGER**

###### **Risk of explosion!**

Risk of explosion due to formation of sparks. Devices with housing components made of aluminum can form an ignition source, as sparks occur due to mechanical friction or impact.

- When working on the devices, only use tools that are approved for working with aluminum in potentially explosive atmospheres.
- Avoid mechanical friction and impacts on aluminum components.

#### Protection against electrostatic discharges

##### **DANGER**

###### **Risk of explosion!**

The painted surface of the device can store electrostatic charges.

As a result, the housing can form an ignition source due to electrostatic discharges in the following conditions:

- The device is operated in environments with a relative humidity of  $\leq 30\%$ .
- The painted surface of the device is thereby relatively free from impurities such as dirt, dust or oil.
- Instructions on avoiding ignition in potentially explosive environments due to electrostatic discharges in accordance with PD CLC/TR 60079-32-1 and IEC TS 60079-32-1 must be complied with!

#### Instructions on cleaning

The painted surface of the device must be cleaned only using a moist cloth.

#### Opening and closing the housing

##### **DANGER**

###### **Danger of explosion if the device is operated with the transmitter housing or terminal box open!**

Before opening the transmitter housing or the terminal box, note the following points:

- Check that a valid fire permit is available.
- Make sure that there is no explosion hazard.
- Before opening the device, switch off the power supply and wait for  $t > 2$  minutes.

##### **WARNING**

###### **Risk of injury due to live parts!**

When the housing is open, contact protection is not provided and EMC protection is limited.

- Before opening the housing, switch off the power supply.

See also **Opening and closing the housing** on page 41.

Only original spare parts must be used to seal the housing.

#### Note

Spare parts can be ordered from ABB Service.

[www.abb.com/contacts](http://www.abb.com/contacts)

#### Temperature resistance for the connecting cable

The temperature at the cable entries of the device is dependent on the measuring medium temperature  $T_{\text{medium}}$  and the ambient temperature  $T_{\text{amb}}$ .

- For electrical connection of the device, cables suited for temperatures up to  $110\text{ °C}$  ( $230\text{ °F}$ ) can be used without restriction.
- For cables suited only for temperatures up to  $80\text{ °C}$  ( $176\text{ °F}$ ), the connection of both circuits must be checked in the event of a fault. Otherwise, the restricted temperature ranges listed in the following table shall apply.

$T_{\text{amb}}$	$T_{\text{medium}}$ maximum	Maximum cable temperature
-40 to $50\text{ °C}$ (-40 to $122\text{ °F}$ )	$272\text{ °C}$ ( $522\text{ °F}$ )	$80\text{ °C}$ ( $176\text{ °F}$ )
-40 to $40\text{ °C}$ (-40 to $104\text{ °F}$ )	$400\text{ °C}$ ( $752\text{ °F}$ )	
-40 to $67\text{ °C}$ (-40 to $153\text{ °F}$ )	$180\text{ °C}$ ( $356\text{ °F}$ )	



## Cable glands

### Note

Devices with a ½ in-NPT thread are generally supplied without cable glands.

The devices are supplied with cable glands certified according to ATEX or IECEx.

The cable glands supplied are approved for use in Zone 1.

Please observe the following points:

- The use of standard cable glands and closures is prohibited.
- The black plugs in the cable glands are intended to provide protection during transport. Any unused cable entries must be sealed securely before commissioning.
- The outside diameter of the connection cable must measure between 6 mm (0.24 in) and 12 mm (0.47 in) to guarantee the required tightness.

## Use of the devices in Zone 0 / 20

If the devices are used in Zone 0 / 20, the cable glands supplied must be replaced with cable glands approved for use in Zone 0.

## Flame-resistant pipe fittings

The electrical connection for the flowmeter is made via the cable gland on the device. Alternatively, the flowmeter can be connected using an approved flame-resistant pipe fitting located directly on the device.

To do this, the existing cable gland must be removed.

When selecting suited flame-resistant pipe fittings, please note the following:

- The requirements set out in EN 50018 section 13.1 and 13.2 must be observed.
- The installation requirements set out in EN 60079-14 must be complied with when selecting pipe fittings.
- The outside diameter of the unshielded connection cable must be between 8.0 mm (0.31 in) and 11.7 mm (0.46 in).

### Note

The flame-resistant pipe fitting must be assembled in accordance with the manufacturer's assembly instructions supplied with the pipe fitting.

## Signal cable installation in accordance with cFMus




Figure 1: Signal cable installation with FM/CSA


The signal cable must be installed in accordance with the FM16US0227X certificate of conformity and the National Electrical Code, 2017 edition (NFPA70), Article 501.10 (a)(1)(a) wiring methods for Class I, Division 1 in appropriately approved metal pipe systems (Conduits).

They can be stiff metal pipes with threaded screw connections or metal pipes with threads.

## ... 2 Use in potentially explosive atmospheres

### ... Assembly and operating instructions

#### Electrical connections



- ① VortexMaster FSV400, SwirlMaster FSS400
- ② Supply isolator
- ③ Switching amplifier
- ④ Bridge

Figure 2: Electrical connection (example)


Output configuration	Bridge
Optoelectronic coupler output	1-2
NAMUR output	3-4

Terminal	Function
PWR/COMM + /	Power supply / current output / HART® output
PWR/COMM -	
DIGITAL OUTPUT+ /	Digital output as optoelectronic coupler or NAMUR
DIGITAL OUTPUT-	output

In the factory setting, the output is configured as an optoelectronic coupler output.

If the digital output is configured as a NAMUR output, a suitable NAMUR switching amplifier must be connected.

#### PROFIBUS PA® / FOUNDATION Fieldbus® FISCO-Concept



- ① Bus termination
- ② Power supply (Supply isolator)
- ③ Power supply
- ④ Data
- ⑤ Handheld Terminal
- ⑥ FISCO- Field Devices
- ⑦ Trunk line
- ⑧ Spur line

Figure 3: FISCO Control drawing (example)

The intrinsic safety fieldbus concept (FISCO for short) is an intrinsically safe fieldbus system for potentially explosive atmospheres.

Exclusive use of FISCO-approved intrinsically safe devices allows for simplified hookup in potentially explosive atmospheres without the need for costly intrinsic safety installation checks.

The following prerequisites must be met to this effect:

- The electric data of the supply isolator must be less / equal to the maximum permissible data of the field device, even in case of failure. (Intrinsic safety installation check)
- The unprotected residual capacity ( $C_i$ ) and residual inductance ( $L_i$ ) of each component connected to the fieldbus must not up-scale 5 nF / 10µH. The bus termination is excluded from this.
- Each intrinsically safe fieldbus segment must have only one power supply (supply isolator). All other components must be designed passively, while the maximum permissible leakage current per component is 50 µA.
- Devices with power supplies separated from the fieldbus must have electrical isolation between the power supply and the fieldbus.

## Type of protection ‘non-sparking’ (Ex n / NA) and ‘intrinsic safety’ (Ex ic), Zone 2, 22

### Ex marking

#### ATEX / IECEx

---

##### ATEX – order code ‘Explosion protection: B1, B8, B9’

---

Type Examination Test Certificate FM13ATEX0056X

For electrical parameters, see certificate FM13ATEX0056X

##### Order code ‘Output signal: H1, H5, M4’ – HART®, Modbus®

---

II 3G Ex nA IIC T4 to T6 Gc

II 3 D Ex tc IIIC T85 °C DC

##### Order code ‘Output signal: P1, F1’ – PROFIBUS®, FOUNDATION Fieldbus®

---

II 3G Ex ic IIC T4...T6 Gc

II 3G Ex nA IIC T4 to T6 Gc

II 3 D Ex tc IIIC T85 °C DC

FISCO Field Instrument, FF-816

---



---

##### IECEx – Order code ‘Explosion protection: N1, N8, N9’

---

Certificate of conformity IECEX FME 13.0004X

For electrical parameters, see certification IECEX FME 13.0004X

##### Order code ‘Output signal: H1, H5, M4’ – HART®, Modbus®

---

Ex nA IIC T4 to T6 Gc

Ex tc IIIC T85 °C DC

##### Order code ‘Output signal: P1, F1’ – PROFIBUS®, FOUNDATION Fieldbus®

---

Ex ic IIC T4...T6 Gc

Ex nA IIC T4 to T6 Gc

Ex tc IIIC T85 °C Dc

FISCO Field Instrument,FF-816

---

#### FM approval for USA and Canada

---

##### FM approval for USA and Canada–

##### order code ‘Explosion protection: F3, F8, F9’

---

Housing: TYPE 4X

##### Order code ‘Output signal: H1, H5, M4’ – HART®, Modbus®

---

CL I, ZONE 2 AEx/Ex nA IIC T6, T5, T4

CL I/DIV 2/GP ABCD

NI CL 1/DIV 2/GP ABCD,

DIP CL II, III/DIV 2/GP EFG

##### Order code ‘Output signal: P1, F1’ – PROFIBUS®, FOUNDATION Fieldbus®

---

CL I, ZONE 2 AEx/Ex ic IIC T6, T5, T4

CL I, ZONE 2 AEx/Ex nA IIC T6, T5, T4

NI CL 1/DIV 2/GP ABCD,

DIP CL II,III/DIV 2/GP EFG

FISCO Field Instrument, FF-816

---

#### NEPSI (China)

---

##### NEPSI – order code ‘Explosion protection: S2, S8, S9’

---

For electrical parameters, see certificate GYJ14.1088X

##### Order code ‘Output signal: H1, H5, M4’ – HART®, Modbus®

---

Ex nA IIC T4 to T6 Gc

DIP A22 Ta 85 °C

##### Order code ‘Output signal: P1, F1’ – PROFIBUS®, FOUNDATION Fieldbus®

---

Ex ic IIC T4 to T6 Gc

Ex nA IIC T4 to T6 Gc

DIP A22 Ta 85 °C

FISCO Field Instrument, FF-816

---

## ... 2 Use in potentially explosive atmospheres

### ... Type of protection ‘non-sparking’ (Ex n / NA) and ‘intrinsic safety’ (Ex ic), Zone 2, 22


#### Electrical Data

The symbols used in this chapter have the following meaning.

ID code	Description
$U_S$	Supply voltage of the device ( $U_{Supply}$ )
$U_M$	Maximum permissible voltage ( $U_{Maximum}$ )
$R_B$	Load resistor

#### Power supply

- Type of protection ‘Ex nA’:  $U_S = 12$  to  $42$  V DC
- Type of protection ‘Ex ic’ (Fisco):  $U_S = 9$  to  $17.5$  V DC



The voltage  $U_S = 12$  V is based on a load of  $0 \Omega$ .

$R_B$  Maximum permissible load in the power supply circuit, e.g. indicator, recorder or power resistor.

Figure 4: Power supply in Zone 2, explosion protection, non-sparking

Power supply / current output / HART®, Modbus®	
HART terminals	PWR/COMM + / PWR/COMM -
Modbus terminals	A (+), B (-) / PWR +, PWR -
$U_S$	HART: 45 V, Modbus: 30 V
Zone 2:	Ex nA IIC T4 bis T6 Gc $T_{amb} = -40$ to $xx$ °C*
Zone 22:	Ex tc IIIC T85 °C Dc $T_{amb} = -40$ to $75$ °C
FM (USA and Canada):	CL I, ZONE 2 AEx/Ex nA IIC T6, T5, T4 CL I/DIV 2/GP ABCD TYPE 4XNI CL 1/DIV 2/GP ABCD, DIP CL II, III/DIV 2/GP EFG
Housing:	TYPE 4X

\* The temperature  $xx$  °C depends on the temperature class  $T_{class}$

Power supply / PROFIBUS PA®, FOUNDATION Fieldbus®	
Fieldbus terminals	BUS CONNECTION + / BUS CONNECTION -
$U_M$	45 V DC
Zone 2:	Ex nA IIC T4 to T6 Gc Ex ic IIC T4 to T6 Gc $T_{amb} = -40$ to $xx$ °C* FISCO Field Instrument, FF-816
Zone 22:	Ex tc IIIC T85 °C Dc $T_{amb} = -40$ to $75$ °C FISCO Field Instrument, FF-816
FM (USA and Canada):	CL I, ZONE 2 AEx/Ex nA IIC T6, T5, T4 CL I, ZONE 2 AEx/Ex ic IIC T6, T5, T4 CL I/DIV 2/GP ABCD TYPE 4X NI CL 1/DIV 2/GP ABCD, DIP CL II,III/DIV 2/GP EFG FISCO Field Instrument, FF-816
Housing:	TYPE 4X

\* The temperature  $xx$  °C depends on the temperature class  $T_{class}$

### Digital output

For devices with HART®, Modbus®, PROFIBUS® and FOUNDATION Fieldbus® communication.

The digital output is designed as an optoelectronic coupler or NAMUR contact (in accordance with DIN 19234).

- When the NAMUR contact is closed, the internal resistance is approx. 1000 Ω.
- When the contact is open, the internal resistance is > 10 kΩ.

The digital output can be changed over to 'optoelectronic coupler' if required.

- NAMUR with switching amplifier
- Digital output Ex nA:  $U_B = 16$  to 30 V,  $I_B = 2$  to 30 mA

---

#### Digital output

Terminals	DIGITAL OUTPUT 1+ / DIGITAL OUTPUT 4-
$U_M$	45 V
Zone 2: Ex nA IIC T4 to T6 Gc	
Zone 22: Ex tc IIIC T85 °C Dc	
$T_{amb} = -40$ to 75 °C*	
CL I, ZONE 2 AEx/Ex nA IIC T6, T5, T4	
CL I/DIV 2/GP ABCD TYPE 4X	
NI CL 1/DIV 2/GP ABCD, DIP CL II,III/DIV 2/GP EFG	

\* See temperature ranges in **Temperature Data** on page 14.

### Analog input

---

#### Analog input

Terminals	ANALOG INPUT + / ANALOG INPUT -
$U_M$	45 V
Zone 2: Ex nA IIC T4 to T6 Gc	
Zone 22: Ex tc IIIC T85 °C Dc	
$T_{amb} = -40$ to 75 °C	
CL I, ZONE 2 AEx/Ex nA IIC T6, T5, T4	
CL I/DIV 2/GP ABCD TYPE 4X	
NI CL 1/DIV 2/GP ABCD, DIP CL II,III/DIV 2/GP EFG	

### Special conditions

- If the type of protection of the device has **not** been marked on the name plate by the manufacturer, during installation of the device, the operator must identify the type of protection used on the name plate in a **permanent** manner!
- The painted surface become electrostatically charged. If the painted surface is relatively free of contamination such as dirt, dust or oil and the relative air humidity is > 30%, it can become a source of ignition.
- Instructions on avoiding ignition in potentially explosive environments due to electrostatic discharges in accordance with PD CLC/TR 60079-32-1 and IEC TS 60079-32-1 must be observed!
- It must be guaranteed that the overvoltage is limited to 140 % of the maximum operating voltage of 45 V.

### Overvoltage protection

For the devices, the client must provide an external overvoltage protection.

It must be guaranteed that the overvoltage is limited to 140 % (HART: 63 V DC, Modbus: 42 V DC) of the maximum operating voltage  $U_S$ .

## ... 2 Use in potentially explosive atmospheres

### ... Type of protection 'non-sparking' (Ex n / NA) and 'intrinsic safety' (Ex ic), Zone 2, 22

#### Temperature Data

##### Operating temperature ranges

The permissible maximum ambient temperature and measuring medium temperature are dependent on each other and on the temperature class.

- The ambient temperature range  $T_{amb}$  is  $-40$  to  $85$  °C ( $-40$  to  $185$  °F).
- The measuring medium temperature range  $T_{medium}$  is  $-200$  to  $400$  °C ( $-328$  to  $752$  °F).

#### Devices without LCD indicator and with HART® / Modbus® communication

Temperature class	$T_{amb}$ max.	$T_{medium}$ max.
T4	$\leq 85$ °C	90 °C
	$\leq 82$ °C	180 °C
	$\leq 81$ °C	280 °C
	$\leq 79$ °C	400 °C
T5	$\leq 56$ °C	90 °C
	$\leq 53$ °C	180 °C
	$\leq 52$ °C	280 °C
T6	$\leq 50$ °C	400 °C
	$\leq 44$ °C	90 °C
	$\leq 41$ °C	180 °C
	$\leq 40$ °C	280 °C
	$\leq 38$ °C	400 °C

#### Devices with LCD indicator, order code L1 and with HART® / Modbus® communication

Temperature class	$T_{amb}$ max.	$T_{medium}$ max.
T4	$\leq 85$ °C	90 °C
	$\leq 82$ °C	180 °C
	$\leq 81$ °C	280 °C
	$\leq 79$ °C	400 °C
T5, T6	$\leq 40$ °C	90 °C
	$\leq 37$ °C	180 °C
	$\leq 36$ °C	280 °C
	$\leq 34$ °C	400 °C

#### Devices with LCD indicator, order code L2 and with HART® / Modbus® communication

Temperature class	$T_{amb}$ max.	$T_{medium}$ max.
T4	$\leq 60$ °C	90 °C
	$\leq 57$ °C	180 °C
	$\leq 56$ °C	280 °C
	$\leq 54$ °C	400 °C
T5	$\leq 56$ °C	90 °C
	$\leq 53$ °C	180 °C
	$\leq 52$ °C	280 °C
T6	$\leq 50$ °C	400 °C
	$\leq 44$ °C	90 °C
	$\leq 41$ °C	180 °C
	$\leq 40$ °C	280 °C
	$\leq 38$ °C	400 °C

#### Devices with PROFIBUS®- / FOUNDATION Fieldbus® communication

Temperature class	$T_{amb}$ max.	$T_{medium}$ max.
T4	$\leq 85$ °C	90 °C
	$\leq 82$ °C	180 °C
	$\leq 81$ °C	280 °C
	$\leq 79$ °C	400 °C
T5, T6	$\leq 40$ °C	90 °C
	$\leq 37$ °C	180 °C
	$\leq 36$ °C	280 °C
	$\leq 34$ °C	400 °C

## Zone 0, 1, 20, 21 - type of protection 'intrinsically safe'

Only for devices with HART®, PROFIBUS PA® or FOUNDATION Fieldbus® communication (order code 'output signal H1, H5, P1 or F1')!

### Ex marking

ATEX / IECEx

---

#### ATEX – order code 'Explosion protection: A4, B8, B9'

Type examination certificate: FM13ATEX0055X

II 1 G Ex ia IIC T4 to T6 Ga

II 1 D Ex ia IIIC T85 °C

FISCO Field Instrument, FF-816

(for devices with PROFIBUS PA and FOUNDATION Fieldbus)

---

#### IECEx – Order code 'Explosion protection: N2, N8, N9'

Certificate of conformity IECEx FME 13.0004X

Ex ia IIC T4 to T6 Ga

Ex ia IIIC T85 °C

FISCO Field Instrument, FF-816

(for devices with PROFIBUS PA and FOUNDATION Fieldbus)

For electrical parameters, see certificate IECEx FME 13.0004X

### FM approval for USA and Canada

---

#### FM approval for USA and Canada –

##### order code 'Explosion protection: F4, F8, F9'

IS Control Drawing: 3KXF065215U0109

IS/S. Intrinsic(Entity) CL I,

Zone 0 AEx/Ex ia IIC T6, T5, T4

CI I/Div 1/ABCD IS-CL II, III/DIV 1/EFG TYPE 4X

FISCO Field Instrument, FF-816

(for devices with PROFIBUS PA and FOUNDATION Fieldbus)

### NEPSI (China)

---

#### NEPSI – order code 'Explosion protection: S6, S8, S9'

Ex ia IIC T4 to T6 Ga

Ex iaD 20 T85 °C

FISCO Field Instrument, FF-816

(for devices with PROFIBUS PA and FOUNDATION Fieldbus)

For electrical parameters, see certificate GYJ14.1088X

## ... 2 Use in potentially explosive atmospheres


### ... Zone 0, 1, 20, 21 - type of protection 'intrinsically safe'

#### Electric and temperature data

The symbols used in this chapter have the following meaning.

ID code	Description
$U_S$	Supply voltage of the device ( $U_{SUPPLY}$ )
$U_M$	Maximum permissible voltage ( $U_{Maximum}$ )
$R_B$	Load resistor
$I_{max}$	Maximum permissible current ( $I_{Maximum}$ )
$P_i$	Maximum permissible power of the connected device
$C_i$	Maximum permissible inner capacity of the connected device
$L_i$	Maximum permissible inner inductance of the connected device

#### Power supply



The voltage  $U_S = 12\text{ V}$  is based on a load of  $0\ \Omega$ .

$R_B$  Maximum permissible load in the power supply circuit, e.g. indicator, recorder or power resistor.

Figure 5: Power supply in Zone 0, 1, 20, 21 – Ex protection 'intrinsically safe'

Power supply / current output / HART® output	
Terminals	PWR/COMM + / PWR/COMM -
Zone 0:	Ex ia IIC T4 to T6 Ga $T_{amb} = -40\text{ to }85\text{ }^\circ\text{C}^*$
$U_M$	30 V
$I_{max}$	See <b>Limit value tables</b> on page 18
$P_i$	
$C_i$	13 nF for indicator option L1 17 nF for all other options
$L_i$	10 $\mu\text{H}$
Zone 20:	Ex ia IIIC T85 $^\circ\text{C}$ $T_{amb} = -40\text{ to }85\text{ }^\circ\text{C}^*$
FM (USA and Canada):	IS/S. Intrinsic (Entity) CL I, Zone 0 AEx/Ex ia IIC T6, T5, T4 CI I/Div 1 /ABCD IS-CL II, III/DIV 1 /EFG TYPE 4X IS Control Drawing: 3KXF065215U0109

\* See temperature ranges in **Limit value tables** on page 18.

Power supply and PROFIBUS PA® / FOUNDATION Fieldbus® output	
Terminals	BUS CONNECTION+ / BUS CONNECTION-
Zone 0:	Ex ia IIC T4 to T6 Ga FISCO Field Instrument, FF-816 $T_{amb} = -40\text{ to }85\text{ }^\circ\text{C}^*$
Zone 20:	Ex ia IIIC T85 $^\circ\text{C}$
FM (USA and Canada):	IS/S. Intrinsic (Entity) CL I, Zone 0 AEx/Ex ia IIC T6, T5, T4 CI I/Div 1 /ABCD IS-CL II, III/DIV 1 /EFG TYPE 4X FISCO Field Instrument, FF-816 IS Control Drawing: 3KXF065215U0109
$U_M$	24 V for FF-816, 17.5V for FISCO
$I_{max}$	See <b>Limit value tables</b> on page 18
$P_i$	1.2 W for FF-816, 5.32 W for FISCO
$C_i$	5 nF
$L_i$	10 $\mu\text{H}$

\* See temperature ranges in **Limit value tables** on page 18.



### Digital output

The digital output is designed as an optoelectronic coupler or NAMUR contact (in accordance with DIN 19234).

- When the NAMUR contact is closed, the internal resistance is approx. 1000  $\Omega$ .
- When the NAMUR contact is open, the internal resistance is > 10 k $\Omega$ .

The digital output can be changed over to 'optoelectronic coupler' if required.

- NAMUR with switching amplifier
- Digital output: Ex ia:  $U_i = 30$  V DC

#### Digital output

Terminals	DIGITAL OUTPUT 1+ / DIGITAL OUTPUT 4-
Zone 0:	Ex ia IIC T4 to T6 Ga
$U_{max}$	30 V
$I_{max}$	30 mA
$C_i$	7 nF
$L_i$	0 mH
Zone 20:	Ex ia IIIC T85 °C $T_{amb} = -40$ to 85 °C*
FM (USA and Canada):	IS/S. Intrinsic (Entity) CL I, Zone 0 AEx/Ex ia IIC T6, T5, T4 CI I/Div 1 /ABCD IS-CL II, III/DIV 1 /EFG TYPE 4X IS Control Drawing: 3KXF065215U0109

#### Analog input

Terminals	ANALOG INPUT + / ANALOG INPUT -
Zone 0:	Ex ia IIC T4 to T6 Ga
$U_{max}$	See <b>Limit value tables</b> on page 18
$I_{max}$	
$C_i$	7 nF
$L_i$	0 mH
Zone 20:	Ex ia IIIC T85 °C $T_{amb} = -40$ to 85 °C*
FM (USA and Canada):	IS/S. Intrinsic (Entity) CL I, Zone 0 AEx/Ex ia IIC T6, T5, T4 CI I/Div 1 /ABCD IS-CL II, III/DIV 1 /EFG TYPE 4X IS Control Drawing: 3KXF065215U0109

\* See temperature ranges in **Limit value tables** on page 18.

### Special conditions

- If the type of protection of the device has **not** been marked on the name plate by the manufacturer, during installation of the device, the operator must identify the type of protection used on the name plate in a **permanent** manner!
- The painted surface become electrostatically charged. If the painted surface is relatively free of contamination such as dirt, dust or oil and the relative air humidity is > 30%, it can become a source of ignition.
- Instructions on avoiding ignition in potentially explosive environments due to electrostatic discharges in accordance with PD CLC/TR 60079-32-1 and IEC TS 60079-32-1 must be observed!
- In devices with the order option '**Housing material / cable connection – A1 or B1**', the transmitter housing is made of aluminum and can form a source of ignition through the creation of sparks due to mechanical friction or impact.
  - When working on the devices, only use tools that are approved for working with aluminum in potentially explosive atmospheres.
  - Avoid mechanical friction and impacts on aluminum components.

### Devices with extended EMC-protection

For devices with the order code '**Optional equipment for devices – G4**', power circuits must be connected to the device through electrically isolated safety barriers.

### Devices with PROFIBUS PA® or FOUNDATION Fieldbus® output

- For devices in remote mount design, the fieldbus must be connected to the device through electrically isolated safety barriers.
- The power supply, digital output and the analog input must be considered as separate intrinsically safe circuits. If the power supply, digital output and analog input are routed in a common multi core cable, the laying and installation of the cable must comply with regulations for separate intrinsically safe circuits.

## ... 2 Use in potentially explosive atmospheres

### ... Zone 0, 1, 20, 21 - type of protection 'intrinsically safe'

#### Limit value tables

##### Operating temperature ranges

- The ambient temperature range  $T_{amb}$  of the devices is -40 to 85 °C
- The measuring medium temperature range  $T_{medium}$  is -200 to 400 °C

##### Devices without LCD indicator

Devices with 'Output signal – H1, H5 and M4' ordering code

Temperature class	$T_{amb}$ max.	$U_M$	$I_{max}$	$P_i$ max	$T_{medium}$ max.
<b>Power supply, current / HART® output, analog input</b>					
T4*	≤ 85 °C	30 V	100 mA	0.75 W	90 °C
	≤ 82 °C				180 °C
	≤ 81 °C				280 °C
	≤ 79 °C				400 °C
T4*	≤ 70 °C	30 V	160 mA	1.0 W	90 °C
	≤ 67 °C				180 °C
	≤ 66 °C				280 °C
	≤ 64 °C				400 °C
T5	≤ 56 °C	30 V	100 mA	1.4 W	90 °C
	≤ 53 °C				180 °C
	≤ 52 °C				280 °C
	≤ 50 °C				400 °C
T6	≤ 44 °C	30 V	50 mA	0.4 W	90 °C
	≤ 41 °C				180 °C
	≤ 40 °C				280 °C
	≤ 38 °C				400 °C
<b>Digital output</b>					
T4	≤ 85 °C	30 V	30 mA	1.0 W	90 °C
	≤ 82 °C				180 °C
	≤ 81 °C				280 °C
	≤ 79 °C				400 °C
T5	≤ 56 °C	30 V	30 mA	1.0 W	90 °C
	≤ 53 °C				180 °C
	≤ 52 °C				280 °C
	≤ 50 °C				400 °C
T6	≤ 44 °C	30 V	30 mA	1.0 W	90 °C
	≤ 41 °C				180 °C
	≤ 40 °C				280 °C
	≤ 38 °C				400 °C

\* Depending on the electric data of the connected supply isolator.

## Devices with LCD indicator, order code L1

Devices with 'Output signal – H1, H5 and M4' ordering code

Temperature class	T <sub>amb</sub> max.	U <sub>M</sub>	I <sub>max</sub>	P <sub>i</sub> max	T <sub>medium</sub> max.
<b>Power supply, current / HART® output, analog input</b>					
T4*	≤ 85 °C	30 V	100 mA	0.75 W	90 °C
	≤ 82 °C				180 °C
	≤ 81 °C				280 °C
	≤ 79 °C				400 °C
T4*	≤ 70 °C	30 V	160 mA	1.0 W	90 °C
	≤ 67 °C				180 °C
	≤ 66 °C				280 °C
	≤ 64 °C				400 °C
T5	≤ 40 °C	30 V	100 mA	1.4 W	90 °C
	≤ 37 °C				180 °C
	≤ 36 °C				280 °C
	≤ 34 °C				400 °C
T6	≤ 40 °C	30 V	50 mA	0.4 W	90 °C
	≤ 37 °C				180 °C
	≤ 36 °C				280 °C
	≤ 34 °C				400 °C
<b>Digital output</b>					
T4	≤ 85 °C	30 V	30 mA	1.0 W	90 °C
	≤ 82 °C				180 °C
	≤ 81 °C				280 °C
	≤ 79 °C				400 °C
T5	≤ 40 °C	30 V	30 mA	1.0 W	90 °C
	≤ 37 °C				180 °C
	≤ 36 °C				280 °C
	≤ 34 °C				400 °C
T6	≤ 40 °C	30 V	30 mA	1.0 W	90 °C
	≤ 37 °C				180 °C
	≤ 36 °C				280 °C
	≤ 34 °C				400 °C

\* Depending on the electric data of the connected supply isolator.

## ... 2 Use in potentially explosive atmospheres

### ... Zone 0, 1, 20, 21 - type of protection 'intrinsically safe'

Devices with LCD indicator, order code L2 (operation through the front glass)

Devices with 'Output signal – H1, H5 and M4' ordering code

Temperature class	T <sub>amb</sub> max.	U <sub>Mx</sub>	I <sub>max</sub>	P <sub>i</sub> max	T <sub>medium</sub> max.
<b>Power supply, current / HART® output, analog input</b>					
T4*	≤ 60 °C	30 V	100 mA	0.75 W	90 °C
	≤ 57 °C				180 °C
	≤ 56 °C				280 °C
	≤ 54 °C				400 °C
T4*	≤ 60 °C	30 V	160 mA	1.0 W	90 °C
	≤ 57 °C				180 °C
	≤ 56 °C				280 °C
	≤ 54 °C				400 °C
T5	≤ 56 °C	30 V	100 mA	1.4 W	90 °C
	≤ 53 °C				180 °C
	≤ 52 °C				280 °C
	≤ 50 °C				400 °C
T6	≤ 44 °C	30 V	50 mA	0.4 W	90 °C
	≤ 41 °C				180 °C
	≤ 40 °C				280 °C
	≤ 38 °C				400 °C
<b>Digital output</b>					
T4	≤ 60 °C	30 V	30 mA	1.0 W	90 °C
	≤ 57 °C				180 °C
	≤ 56 °C				280 °C
	≤ 54 °C				400 °C
T5	≤ 56 °C	30 V	30 mA	1.0 W	90 °C
	≤ 53 °C				180 °C
	≤ 52 °C				280 °C
	≤ 50 °C				400 °C
T6	≤ 44 °C	30 V	30 mA	1.0 W	90 °C
	≤ 41 °C				180 °C
	≤ 40 °C				280 °C
	≤ 38 °C				400 °C

\* Depending on the electric data of the connected supply isolator.

Devices with 'Output signal – P1 and F1' ordering code

Temperature class	T <sub>amb</sub> max.	U <sub>M</sub>	I <sub>max</sub>	P <sub>i</sub> max	T <sub>medium</sub> max.
<b>Power supply</b>					
T4	≤ 85 °C				90 °C
	≤ 82 °C				180 °C
	≤ 81 °C				280 °C
	≤ 79 °C				400 °C
T5, T6	≤ 40 °C				90 °C
	≤ 37 °C				180 °C
	≤ 36 °C				280 °C
	≤ 34 °C				400 °C
<b>Digital output</b>					
T4	≤ 85 °C	30 V	30 mA	1.0 W	90 °C
	≤ 82 °C				180 °C
	≤ 81 °C				280 °C
	≤ 79 °C				400 °C
T5, T6	≤ 40 °C	30 V	30 mA	1.0 W	90 °C
	≤ 37 °C				180 °C
	≤ 36 °C				280 °C
	≤ 34 °C				400 °C
<b>Analog input</b>					
T4*	≤ 85 °C	30 V	100 mA	0.75 W	90 °C
	≤ 82 °C				180 °C
	≤ 81 °C				280 °C
	≤ 79 °C				400 °C
T4*	≤ 70 °C	30 V	160 mA	1.0 W	90 °C
	≤ 67 °C				180 °C
	≤ 66 °C				280 °C
	≤ 64 °C				400 °C
T5	≤ 40 °C	30 V	100 mA	1.4 W	90 °C
	≤ 37 °C				180 °C
	≤ 36 °C				280 °C
	≤ 34 °C				400 °C
T6	≤ 40 °C	30 V	50 mA	0.4 W	90 °C
	≤ 37 °C				180 °C
	≤ 36 °C				280 °C
	≤ 34 °C				400 °C

\* Depending on the electric data of the connected supply isolator.

## ... 2 Use in potentially explosive atmospheres

### Type of protection 'flameproof (enclosure)' – Zone 1, 21

#### Ex marking

ATEX / IECEx

#### ATEX

Order code	A9, B9
Type Examination Test Certificate	FM13ATEX0057X
II 2 G Ex db ia IIC T6 Gb/Ga – II 2 D Ex tb IIIC T85 °C Db (-40 °C < Ta < +75 °C) supply voltage 42 V DC, Um: 45 V	

#### IECEx

Order code	N3, N9
Certificate of conformity	IECEx FME 13.0004X
Ex db ia IIC T6 Gb/Ga-Ex tb IIIC T85 °C Db (-40 °C < Ta < +75 °C) supply voltage 42 V DC, Um = 45 V	

#### FM approval for USA and Canada

#### FM approval for USA and Canada

Order code	F1, F9
XP-IS (US) CL I/DIV I/GP BCD, DIP CL II, III/DIV I/GP EFG XP-IS (Canada) CL I/DIV I/GP BCD, DIP CL II, III/DIV I/GP EFG CL I, ZONE 1, AEx/Ex d ia IIC T6 -40 °C < Ta < +75 °C TYPE 4X Tamb = 75 °C 'Dual seal device'	

#### NEPSI (China)

#### NEPSI

Order code	S1, S9
Ex d ia IIC T6 Gb / Ga DIP A21 Ta 85 °C For electrical parameters, see certificate GYJ14.1088X	

#### Electric and temperature data

The symbols used in this chapter have the following meaning.

ID code	Description
U <sub>S</sub>	Supply voltage of the device (U <sub>Supply</sub> )
U <sub>M</sub>	Maximum permissible voltage (U <sub>Maximum</sub> )
R <sub>B</sub>	Load resistor

#### Power supply


Ex d ia Gb/Ga:

U<sub>S</sub> = 12 to 42 V DC

#### Note

- The power supply and the digital output must be either only intrinsically safe or only non-intrinsically safe. A combination is not permitted.

Intrinsically safe circuits must have potential equalization in place along the entire length of the cable of the circuit.



The voltage  $U_s = 12\text{ V}$  is based on a load of  $0\ \Omega$ .

$R_B$  Maximum permissible load in the power supply circuit, e.g. indicator, recorder or power resistor.

Figure 6: Power supply in Zone 1, explosion protection

Power supply / current output / HART® output, Modbus®	
HART terminals	PWR/COMM + / PWR/COMM -
Modbus terminals	A (+), B (-) / PWR +, PWR -
$U_M$	HART: 45 V, Modbus: 30 V
$T_{amb}$	-40 to 75 °C
Ex marking	
Zone 1:	Ex db ia IIC T6 Gb/Ga
Zone 21:	Ex tb IIIC T85 °C Db
FM	XP-IS (US) CL I/DIV I/GP BCD,
(USA and Canada):	DIP CL II, III/DIV I/ GP EFG
	XP-IS (Kanada) CL I/DIV I/GP BCD,
	DIP CL II, III/ DIV I/GP EFG
	CL I, ZONE 1, AEx/Ex d ia IIC T6 -40 °C < Ta < +75 °C
	TYPE 4X Tamb = 75 °C „Dual seal device“

### Digital output

The digital output is designed as an optoelectronic coupler or NAMUR contact (in accordance with DIN 19234).

- When the NAMUR contact is closed, the internal resistance is approx. 1000  $\Omega$ .
- When the NAMUR contact is open, the internal resistance is  $> 10\text{ k}\Omega$ .

The digital output can be changed over to 'optoelectronic coupler' if required.

- NAMUR with switching amplifier
- Digital output: Ex d ia:  $U_M = 45\text{ V}$

Digital output	
Terminals	DIGITAL OUTPUT 1+ / DIGITAL OUTPUT 4-
$U_M$	45 V
$T_{amb}$	-40 to 75 °C
Ex marking	
Zone 1:	Ex db ia IIC T6 Gb/Ga
Zone 21:	Ex tb IIIC T85 °C Db
FM	XP-IS (US) CL I/DIV I/GP BCD,
(USA and Canada):	DIP CL II, III/DIV I/ GP EFG
	XP-IS (Kanada) CL I/DIV I/GP BCD,
	DIP CL II, III/ DIV I/GP EFG
	CL I, ZONE 1, AEx/Ex d ia IIC T6 -40 °C < Ta < +75 °C
	TYPE 4X Tamb = 75 °C „Dual seal device“

### Analog input

Analog input	
Terminals	ANALOG INPUT + / ANALOG INPUT -
$U_M$	45 V
$T_{amb}$	-40 to 75 °C
Ex marking	
Zone 1:	Ex db ia IIC T6 Gb/Ga
Zone 21:	Ex tb IIIC T85 °C Db
FM	XP-IS (US) CL I/DIV I/GP BCD,
(USA and Canada):	DIP CL II, III/DIV I/ GP EFG
	XP-IS (Kanada) CL I/DIV I/GP BCD,
	DIP CL II, III/ DIV I/GP EFG
	CL I, ZONE 1, AEx/Ex d ia IIC T6 -40 °C < Ta < +75 °C
	TYPE 4X Tamb = 75 °C „Dual seal device“

## ... 2 Use in potentially explosive atmospheres

### ... Type of protection 'flameproof (enclosure)' – Zone 1, 21

#### Special conditions

- If the type of protection of the device has **not** been marked on the name plate by the manufacturer, during installation of the device, the operator must identify the type of protection used on the name plate in a **permanent** manner!
- The painted surface become electrostatically charged. If the painted surface is relatively free of contamination such as dirt, dust or oil and the relative air humidity is > 30%, it can become a source of ignition.
- Instructions on avoiding ignition in potentially explosive environments due to electrostatic discharges in accordance with PD CLC/TR 60079-32-1 and IEC TS 60079-32-1 must be observed!
- In devices with the order option 'Housing material / cable connection – A1 or B1', the transmitter housing is made of aluminum and can form a source of ignition through the creation of sparks due to mechanical friction or impact.
  - When working on the devices, only use tools that are approved for working with aluminum in potentially explosive atmospheres.
  - Avoid mechanical friction and impacts on aluminum components.

#### Repair

Devices of explosion protection class of 'flameproof enclosure / Flameproof enclosure' are equipped with flameproof open joints in the housing.

Contact ABB before commencing repair work.



## 3 Design and function

### Overview

#### VortexMaster FSV430 / FSV450



- ① Integral mount design in flange design  
 ② Integral mount design in wafer type design  
 ③ Remote mount design with transmitter  
 ④ Remote mount design with dual sensor

Figure 7: VortexMaster FSV430 / FSV450

Sensor		
Model number	FSV430	FSV450
Design	Integral mount design, remote mount design	
IP degree of protection in accordance with EN 60529	IP 66, IP 67, NEMA 4X	
Measuring accuracy for liquids*	≤ ±0.65 % under reference conditions	
Measuring accuracy for gases and vapors*	≤ ±0.9 % under reference conditions	
Repeatability*	DN 15 (½ in): ≤ ±0.3 %, DN 15 (½ in) to DN 150 (6 in): ≤ ±0.2 %, from DN 200 (8 in): ≤ ±0.25 %	
Permissible viscosity for liquids	DN 15 (½ in): ≤ 4 mPa s, DN 25 (1 in): ≤ 5 mPa s, from DN 40 (1½ in): ≤ 7.5 mPa s	
Measuring span (typical)	1:20	
Process connections	<ul style="list-style-type: none"> <li>Flange: DN 15 to 300 (½ in to 12 in)</li> <li>Wafer type: DN 25 to 150 (1 in to 6 in)</li> </ul>	
Inlet / outlet sections (typical)	Inlet section: 15 × DN, outlet section 5 × DN, see also <b>Inlet and outlet sections</b> on page 33.	
Temperature measurement	Resistance thermometer Pt100 class A optional, installed in Piezo sensor, can be retrofitted	Resistance thermometer Pt100 class A standard, fixed installation in Piezo sensor
Permissible measuring medium temperature	Standard: -55 to 280 °C (-67 to 536 °F), Optional: -55 to 350 °C (-67 to 662 °F)	Standard: -55 to 280 °C (-67 to 536 °F), Optional: -55 to 350 °C (-67 to 662 °F)
<b>Wetted material</b>		
• Sensor	Stainless steel, optional Hastelloy® C	
• Gasket	PTFE, optional Kalrez® or graphite	
• Sensor housing	Stainless steel, optional Hastelloy® C, carbon steel	
<b>Sensor design</b>	Piezo sensor with two pairs of sensors for flow measurement and vibration compensation	
<b>Approvals for explosion protection</b>	ATEX / IECEx, cFMus, NEPSI	

\* Indication of accuracy in % of the measured value (% of meas.val.)

## ... 3 Design and function

### ... Overview

#### SwirlMaster FSS430 / FSS450



① Integral mount design

② Remote mount design with transmitter

③ Remote mount design with dual sensor

Figure 8: SwirlMaster FSS430 / FSS450

Sensor		
Model number	FSS430	FSS450
Design	Integral mount design, remote mount design	
IP degree of protection in accordance with EN 60529	IP 66 / 67, NEMA 4X	
Measuring accuracy for liquids*	≤ ±0.5 % under reference conditions	
Measuring accuracy for gases and vapors*	≤ ±0.5 % under reference conditions	
Repeatability*	DN 15 ≤ ±0.3 %, from DN 20 ≤ ±0.2 %	
Permissible viscosity for liquids	DN 15 to 32: ≤ 5 mPa s, DN 40 to 50: ≤ 10 mPa s, from DN 80: ≤ 30 mPa s	
Measuring span (typical)	1:25	
Process connections	Flange DN 15 to 400 (0.5 in to 16 in)	Flange DN 15 to 400 (0.5 in to 16 in)
Inlet / outlet sections (typical)	Inlet section: 3 × DN, outlet section 1 × DN, see also <b>Inlet and outlet sections</b> on page 33.	
Temperature measurement	Resistance thermometer Pt100 class A optional, installed in Piezo sensor, can be retrofitted	Resistance thermometer Pt100 class A standard, fixed installation in Piezo sensor
Permissible measuring medium temperature	Standard: -55 to 280 °C (-67 to 536 °F), Optional: -55 to 350 °C(-67 to 662 °F)	Standard: -55 to 280 °C (-67 to 536 °F), Optional: -55 to 350 °C(-67 to 662 °F)
<b>Wetted material</b>		
• Sensor	Stainless steel, optional Hastelloy® C	
• Inlet / outlet guide bodies	Stainless steel, optional Hastelloy® C	
• Gasket	PTFE, optional Kalrez® or graphite	
• Sensor housing	Stainless steel, optional Hastelloy® C	
Sensor design	Piezo sensor with two pairs of sensors for flow measurement and vibration compensation	
Approvals for explosion protection	ATEX / IECEx, cFMus, NEPSI	

\* Indication of accuracy in % of the measured value (% of meas.val.)

## Transmitter

Model number	FSS430 / FSV430	FSS450 / FSV450
<b>Display</b>	Optional LCD indicator with four operating buttons for operation through front glass (option)	Standard LCD indicator with four operating buttons for operation through front glass
<b>Operating modes</b>		
• Liquids	Operating volume, standard volume, mass	Operating volume, standard volume, mass, energy
• Gases	Operating volume, standard volume, mass	Operating volume, standard volume, mass, energy
• Biogas	–	Operating volume, standard volume
• Steam	Operating volume, mass	Operating volume, mass, energy
<b>Digital output</b> (Not for devices with FOUNDATION Fieldbus® communication)	Optional, can be configured as pulse output, frequency output or alarm output via software	Standard, can be configured as pulse output, frequency output or alarm output via software
<b>Inputs for external sensors</b> (Only for devices with HART® communication)	<ul style="list-style-type: none"> <li>HART® input for external pressure or temperature transmitter communicating in HART burst mode</li> </ul>	<ul style="list-style-type: none"> <li>Analog input 4 to 20 mA for external pressure- / temperature transmitter or gas analyzer</li> <li>HART® input for external pressure- / temperature transmitter or gas analyzer communicating in HART burst mode</li> </ul>
<b>Current output, communication</b>	4 to 20 mA, HART® (HART 7), Modbus RTU®, PROFIBUS PA®, FOUNDATION Fieldbus®	4 to 20 mA, HART® (HART 7), PROFIBUS PA®, FOUNDATION Fieldbus®
<b>Power supply x</b>	12 to 42 V DC, for devices in explosion-proof design, refer to <b>Use in potentially explosive atmospheres</b> on page 6.	
<b>SensorMemory</b>	Saves sensor & process parameters for easy start-up after transmitter exchange	
<b>Housing material</b>	Aluminum (copper content < 0.3 %), epoxy resin coated; optional: stainless steel CF3M, complies with AISI 316L Tower: CF8, complies with AISI 304	
<b>IP degree of protection in accordance with EN 60529</b> IP 66, IP 67, NEMA 4X		

### ... 3 Design and function

#### Model variants

##### SwirlMaster FSS430 / VortexMaster FSV430

Vortex flowmeter / swirl flowmeter for steam, liquid and gas, with optional graphical display, optional binary output, and optional integrated temperature measurement.

##### SwirlMaster FSS450 / VortexMaster FSV450

Vortex flowmeter / swirl flowmeter for steam, liquid and gas, with integrated binary output, temperature compensation, and flow measurement calculation functionality.

The device offers the option of directly connecting remote temperature transmitters, pressure transmitters, or gas analyzers.

#### Measurement principle

##### SwirlMaster FSS430 / FSS450





Figure 9: Measuring principle

The inlet guide body converts the axial flow of the incoming measuring medium into rotational movement. In the center of this rotation a vortex core is formed which is forced into a secondary spiral-shaped rotation by the return flow.

The frequency of this secondary rotation is proportional to the flow and, if the internal geometry of the meter measuring device exhibits an optimum design, will be linear over a wide measuring range.

This frequency is measured by a Piezo sensor. The frequency signal from the flowmeter sensor, which is proportional to the flow, undergoes downstream processing in the transmitter.




① Linear flow area

Figure 10: How the Strouhal number is dependent upon the Reynolds number

Due to the dimensions of the inlet guide body and the inner geometry, the Strouhal number ( $St$ ) is constant over a very wide range of the Reynolds number ( $Re$ ).

**VortexMaster FSV430 / FSV450**

The operating principle of the Vortex flowmeter is based on the Karman street. As the measuring medium flows over and under the bluff body, vortices are shed alternately above and below. The shedding of these vortices due to the flow forms a vortex trail (Karman vortex street).



- ① Bluff body
- ② Piezo Sensor

**Figure 11: Measuring principle**

Here, the frequency  $f$  of vortex shedding is proportional to the medium velocity  $v$  and inversely proportional to the width of the bluff body  $d$ .

---


$$f = St \times \frac{v}{d}$$


---

$St$ , known as the Strouhal number, is a dimensionless number, which has a decisive impact on the quality of vortex flow measurement.

If the bluff body is dimensioned appropriately, the Strouhal number ( $St$ ) remains constant across a very wide range of the Reynolds number ( $Re$ ).


---


$$Re = \frac{v \times D}{\nu}$$


---

$\nu$  Kinematic viscosity  
 $D$  Nominal diameter of meter tube

---



- ① Linear flow area

**Figure 12: How the Strouhal number is dependent upon the Reynolds number**


Consequently, the vortex shedding frequency to be evaluated is dependent solely upon the flow velocity and not at all upon measuring medium density and viscosity.

The local pressure variations induced by vortex shedding are detected by a piezo sensor and converted into electrical pulses corresponding to the vortex frequency.

The frequency signal from the flowmeter sensor, which is proportional to the flow, undergoes downstream processing in the transmitter.

## 4 Product identification

### Name plate



- (A) Name plate
- (B) Additional plate with Ex marking
- (C) Plate with measuring point tagging (Tag number)
- (D) Tag plate with customer data made from stainless steel (optional)
- (1) Product name
- (2) Firmware version
- (3) Maximum flow rate at nominal diameter
- (4) Nominal diameter
- (5) Pressure equipment classification (SEP or fluid group)
- (6) Current output
- (7) Maximum ambient temperature
- (8) Symbol: read instruction before use
- (9) Country of manufacture
- (10) Date of manufacture
- (11) Maximum measuring medium temperature
- (12) IP rating
- (13) Pressure rating
- (14) Power supply
- (15) Manufacturer address
- (16) Model number
- (17) Serial number
- (18) Manufacturer logo

Figure 13: Types and tag plates (example)

#### Note

The device can optionally be delivered with a tag plate (D) made from stainless steel and fastened with wire. Customer specific text that has been specified in the purchase order is laser printed on the tag plate.

For this, 4 lines of 32 characters each are provided.

## 5 Transport and storage

### Inspection

Check the devices immediately after unpacking for possible damage that may have occurred from improper transport. Details of any damage that has occurred in transit must be recorded on the transport documents. All claims for damages must be submitted to the shipper without delay and before installation.

### Transport

#### **⚠ DANGER**

##### **Life-threatening danger due to suspended loads.**

In the case of suspended loads, a danger of the load falling exists.

- Standing under suspended loads is prohibited.

#### **⚠ WARNING**

##### **Risk of injury due to device slipping.**

The device's center of gravity may be higher than the harness suspension points.

- Make sure that the device does not slip or turn during transport.
- Support the device laterally during transport.




Figure 14: Transport instructions

#### **Flange devices ≤ DN 300**

- Use carrying straps to transport flange designs smaller than DN 350.
- Wrap the carrying straps around both process connections when lifting the device. Chains should not be used, since these may damage the housing.

#### **Flange devices > DN 300**

- Using a forklift to transport flange device can dent the housing.
- Flange devices must not be lifted by the center of the housing when using a forklift for transport.
- Flange devices must not be lifted by the terminal box or by the center of the housing.
- Only the transport lugs fitted to the device can be used to lift the device and insert it into the piping.

### Storing the device

Bear the following points in mind when storing devices:

- Store the device in its original packaging in a dry and dust-free location.
- Observe the permitted ambient conditions for transport and storage.
- Avoid storing the device in direct sunlight.
- In principle, the devices may be stored for an unlimited period. However, the warranty conditions stipulated in the order confirmation of the supplier apply.

#### **Ambient conditions**

The ambient conditions for the transport and storage of the device correspond to the ambient conditions for operation of the device.

Refer to **Ambient conditions** on page 31.

### Returning devices

For the return of devices, follow the instructions in **Repair** on page 142.

## 6 Installation

### Safety instructions

#### DANGER

##### **Danger of explosion if the device is operated with the transmitter housing or terminal box open!**

Before opening the transmitter housing or the terminal box, note the following points:

- Check that a valid fire permit is available.
- Make sure that there is no explosion hazard.
- Before opening the device, switch off the power supply and wait for  $t > 2$  minutes.

#### WARNING

##### **Risk of injury due to process conditions.**

The process conditions, for example high pressures and temperatures, toxic and aggressive measuring media, can give rise to hazards when working on the device.

- Before working on the device, make sure that the process conditions do not pose any hazards.
- If necessary, wear suited personal protective equipment when working on the device.
- Depressurize and empty the device / piping, allow to cool and purge if necessary.

### Installation conditions

#### General

A Vortex or Swirl flowmeter can be installed at any point in the pipeline system. However, the following installation conditions must be considered:

- Compliance with the ambient conditions
- Compliance with the recommended inlet and outlet sections
- The flow direction must correspond to that indicated by the arrow on the sensor
- Compliance with the required minimum interval for removing the transmitter and replacing the sensor
- Avoidance of mechanical vibrations of the piping (by fitting supports if necessary)
- The inside diameter of the sensor and the piping must be identical
- Avoidance of pressure oscillations in long piping systems at zero flow by fitting gates at intervals
- Attenuation of alternating (pulsating) flow during piston pump or compressor conveying by using appropriate damping devices. The residual pulse must not exceed 10 %. The frequency of the conveying equipment must not be within the range of the measuring frequency of the flowmeter.
- Valves / gates should normally be arranged in the flow direction downstream of the flowmeter (typically:  $3 \times DN$ ). If the medium is conveyed through piston / plunger pumps or compressors (pressures for fluids  $> 10$  bar / 145 psi), it may be subject to hydraulic vibration in the pipeline when the valve is closed. If this does occur, the valve absolutely has to be installed in the flow direction upstream of the flowmeter. Suitable damping devices (e.g. air vessels) might need to be fitted.
- When fluids are measured, the sensor must always be filled with measuring medium and must not run dry.
- When fluids are measured and during damping, there must be no evidence of cavitation.
- The relationship between the measuring medium and the ambient temperature must be taken into consideration (see data sheet).
- At high measuring medium temperatures  $> 150$  °C ( $> 302$  °F), the sensor must be installed so that the transmitter or terminal box is pointing to the side or downward.



**Inlet and outlet sections**

**SwirlMaster FSS430, FSS450**

On account of its operating principle, the swirl flowmeter functions virtually without inlet and outlet sections. The figures below show the recommended inlet and outlet sections for various installations.




Figure 15: Straight pipe sections

Installation	Inlet section	Outlet section
(A) Straight pipe section	min. $3 \times DN$	min. $1 \times DN$
(B) Valve upstream of the meter tube	min. $5 \times DN$	min. $1 \times DN$
(C) Pipe reduction	min. $3 \times DN$	min. $1 \times DN$
(D) Pipe extension	min. $3 \times DN$	min. $3 \times DN$

Additional inlet and outlet sections are not required downstream of reductions with flange transition pieces in accordance with DIN 28545 ( $\alpha/2 = 8^\circ$ ).




Figure 16: Pipe sections with pipe elbows

Installation	Inlet section	Outlet section
Single pipe elbow upstream or downstream of the meter tube	min. $3 \times DN$	min. $1 \times DN$

If the elbow radius of single or double pipe elbows positioned upstream or downstream of the device is greater than  $1.8 \times DN$ , inlet and outlet sections are not required.

**VortexMaster FSV430, FSV450**

In order to maximize operational reliability, the flow profile at the inflow end must not be distorted if at all possible. The figures below show the recommended inlet and outlet sections for various installations.




Figure 17: Straight pipe sections

Installation	Inlet section	Outlet section
(A) Straight pipe section	min. $15 \times DN$	min. $5 \times DN$
(B) Valve upstream of the meter tube	min. $50 \times DN$	min. $5 \times DN$
(C) Pipe reduction	min. $15 \times DN$	min. $5 \times DN$
(D) Pipe extension	min. $18 \times DN$	min. $5 \times DN$

## ... 6 Installation

### ... Installation conditions




Figure 18: Pipe sections with pipe elbows

Installation	Inlet section	Outlet section
(A) Single pipe elbow	min. 20 × DN	min. 5 × DN
(B) S-shaped pipe elbow	min. 25 × DN	min. 5 × DN
(C) Three-dimensional pipe elbow	min. 40 × DN	min. 5 × DN

#### Avoiding cavitation

To avoid cavitation, a static overpressure is required downstream of the flowmeter (downstream pressure). This can be estimated using the following formula:

$$p_1 \geq 1,3 \times p_2 + 2,6 \times \Delta p'$$

$p_1$	Static gauge pressure downstream of the device (mbar)
$p_2$	Steam pressure of fluid at operating temperature (mbar)
$\Delta p'$	Pressure drop, measuring medium (mbar)

### Installation at high measuring medium temperatures





Figure 19: Installation at high measuring medium temperatures

At high measuring medium temperatures > 150 °C (> 302 °F), the sensor must be installed so that the transmitter is pointing to the side or downward.

### Installation for external pressure and temperature measurement



① Pressure measuring point      ② Temperature measuring point

Figure 20: Arrangement of the temperature and pressure measuring points

As an option, the flowmeter can be fitted with a Pt100 for direct temperature measurement. This temperature measurement enables, for example, the monitoring of the measuring medium temperature or the direct measurement of saturated steam in mass flow units.

If pressure and temperature are to be compensated externally (e.g. using the flow computer unit), the measuring points must be installed as illustrated.

### Installation of setting equipment




Figure 21: Installation of setting devices


Control and setting devices should be arranged in the forward flow direction **downstream** from the flowmeter at a distance of at least  $5 \times DN$ .

If the measuring medium is conveyed through piston pumps / plunger pumps or compressors (pressures for fluids  $> 10$  bar [ $> 145$  psi]), it may be subject to hydraulic vibration in the piping when the valve is closed.

If this case, it is essential that the valve be installed in the forward flow direction **upstream** from the flowmeter. Suitable dampers (for example, air vessels in the case of pumping using a compressor) might need to be used.

The **SwirlMaster FSS400** is particularly well suited for such arrangements.

### Sensor insulation



① Insulation

Figure 22: Insulation of the meter tube

The piping can be insulated up to a thickness of 100 mm (4 in).

### Use of heat tracing

Trace heating may be used under the following conditions:

- If it is installed directly on or around the piping
- If, in the case of existing pipeline insulation, it is installed inside the insulation (the maximum thickness of 100 mm [4 in] must not be exceeded).
- If the maximum temperature the heat tracing is able to produce is less than or equal to the maximum medium temperature.

### Note

Installation requirements in accordance with EN 60079-14 must be observed.

Please note that the use of trace heaters will not impair EMC protection or generate additional vibrations.

## ... 6 Installation

### Ambient conditions

#### Ambient temperature

In accordance with IEC 60068-2-78

Explosion protection	Ambient temperature range $T_{amb}$	
	Standard	Advanced mode
No explosion protection	-20 to 85 °C (-4 to 185 °F)	-40 to 85 °C (-40 to 185 °F)
Ex ia, Ex nA	-20 °C < $T_a$ < xx °C* (-4°F < $T_a$ < xx °F)*	-40 °C < $T_a$ < xx °C* (-40 °F < $T_a$ < xx °F)*
Ex d ia, XP-IS	-20 to 75 °C (-4 to 167 °F)	-40 to 75 °C (-40 to 167 °F)
IS, NI	-20 °C < $T_a$ < xx °C* (-4°F < $T_a$ < xx °F)*	-40 °C < $T_a$ < xx °C* (-40 °F < $T_a$ < xx °F)*


\* The temperature xx °C (xx °F) depends on the temperature class  $T_{class}$

#### Relative humidity

Design	Relative humidity
Standard	Maximum 85 %, annual average ≤ 65 %

#### Measuring medium temperature range

Design	$T_{medium}$
Standard	-55 to 280 °C (-67 to 536 °F)
High-temperature version (option)	-55 to 350 °C (-67 to 662 °F)



- ① Temperature range standard version
- ② Temperature range high-temperature version (option)

Figure 23: Measuring medium temperature  $T_{medium}$  dependent on the ambient temperature  $T_{amb}$ .

### Pressure Equipment Directive

Conformity assessment in accordance with Category III, fluid group 1, gas.

Note the corrosion resistance of the meter tube materials in relation to the measuring medium.

### CRN approval

Certain device versions and connection options have CRN approval under number 'CRN 0F1209.xx'.

Please contact ABB for more information.

## Material load


### FSV430, FSV450

#### Note

For devices in high temperature version with sensor seals made of graphite, the maximum pressures deviating from the diagrams shall apply.

For more information, please contact the ABB Service.


#### Flange devices



G11799-01


① Range for high-temperature version

Figure 24: DIN flange process connection



① Range for high-temperature version

Figure 25: Process connection of ASME-flange (stainless steel)



① Range for high-temperature version

Figure 26: Process connection of ASME-flange (carbon steel)

#### Aseptic flange

In accordance with DIN 11864-2


Nominal diameter	PS	TS [°C]
DN 25 to DN 40	25 bar (362.6 psi)	140 °C (284 °F)
DN 50, DN 80	16 bar (232.1 psi)	140 °C (284 °F)

\* When selecting suited gasket materials

## ... 6 Installation


### ... Material load

#### Wafer type devices



① Range for high-temperature version

Figure 27: DIN wafer type process connection



① Range for high-temperature version

Figure 28: ASME wafer type process connection

#### FSS430, FSS450




Figure 29: DIN flange process connection




Figure 30: ASME flange process connection

## Installing the sensor

Observe the following points during installation:

- For devices with a remote mount design, make sure that the sensor and transmitter are assigned correctly.
- The flow direction must correspond to the marking, if present
- The maximum torque must be observed for all flanged connections.
- The devices must be installed without mechanical tension (torsion, bending)
- Wafer type devices with plane parallel counterflanges should be installed with suited gaskets only.
- Use gaskets made from a material that is compatible with the measuring medium and measuring medium temperature.
- The piping may not exert any inadmissible forces or torques on the device.
- Do not remove the sealing plugs in the cable glands until you are ready to install the electric lines.
- Make sure the gaskets for the housing cover are seated correctly. Carefully seal the cover. Tighten the cover fittings
- Do not expose the transmitter to direct sunlight and provide for appropriate sun protection where necessary
- When selecting the installation location, make sure that moisture cannot penetrate into the terminal box or the transmitter housing

### Installation of the flowmeter

The device can be installed at any location in a pipeline under consideration of the installation conditions.

1. Position the meter tube coplanar and centered between the piping.
2. Install gaskets between the sealing surfaces.

#### Note

- To achieve the best results, make sure that the gaskets and meter tube fit concentrically.
  - To guarantee that the flow profile is not distorted, the gaskets must not protrude into the piping.
3. Use the appropriate screws for the holes.
  4. Slightly grease the threaded nuts.
  5. Tighten the nuts in a crosswise manner as shown in the figure. First tighten the nuts to approx. 50 % of the maximum torque, then to approx. 80 %, and finally a third time to the maximum torque.

#### Note

Torques for screws depend on temperature, pressure, screw and gasket materials. The relevant applicable regulations must be taken into consideration.




Figure 31: Tightening sequence for the flange screws

## ... 6 Installation

### ... Installing the sensor

#### Centering the wafer type design




Figure 32: Centering the wafer type design with the ring or segment

Wafer type devices (FV400 only) are centered via the outside diameter of the flowmeter sensor body with the corresponding bolts.

Depending on the nominal pressure rating, sleeves for the bolts, a centering ring up to DN 80 (3 in) or centering segments can be ordered as additional accessories.

### Adjusting the transmitter position

#### Rotating the transmitter housing

#### **⚠ DANGER**

##### Explosion hazard


When the screws for the transmitter housing are loosened, the explosion protection is suspended.

- Tighten all the screws of the transmitter housing prior to commissioning.

#### **NOTE**

##### Damage to components!

- The transmitter housing must not be lifted without pulling out the cable, otherwise the cable can tear off
- The transmitter housing must not be rotated more than 360 degrees.



1 Locking screw

Figure 33: Rotating the transmitter housing

1. Loosen the stop screw on the transmitter housing using a 4 mm Allen key.
2. Rotate the transmitter housing in the direction required.
3. Tighten the locking screw.




### Rotating the LCD indicator

#### **WARNING**

##### **Risk of injury due to live parts!**

When the housing is open, contact protection is not provided and EMC protection is limited.

- Before opening the housing, switch off the power supply.



① LCD indicator

② Plug-in connector

Figure 34: Rotating the LCD indicator

The LCD indicator can be rotated in 90° increments to make it easier to read and operate.

1. Unscrew the front housing cover.
2. Pull out the LCD indicator and place it in the desired position.
3. Tighten the screws on the front of the housing cover hand-tight.

#### **NOTE**

##### **Potential adverse effect on the IP rating!**

If the O-ring gasket is seated incorrectly or is damaged, this may have an adverse effect on the IP rating.

- Check that the O-ring gasket is properly seated when closing the housing cover.

## Opening and closing the housing

#### **DANGER**

##### **Danger of explosion if the device is operated with the transmitter housing or terminal box open!**

Before opening the transmitter housing or the terminal box, note the following points:

- Check that a valid fire permit is available.
- Make sure that there is no explosion hazard.
- Before opening the device, switch off the power supply and wait for  $t > 2$  minutes.

#### **WARNING**

##### **Risk of injury due to live parts.**

Improper work on the electrical connections can result in electric shock.

- Connect the device only with the power supply switched off.
- Observe the applicable standards and regulations for the electrical connection.

#### **NOTE**

##### **Potential adverse effect on the IP rating**

- Check the O-ring gasket for damage and replace it if necessary before closing the housing cover.
- Check that the O-ring gasket is properly seated when closing the housing cover.




Figure 35: Cover lock (example)

To open the housing, release the cover lock by screwing in the Allen screw ①.

After closing the housing, lock the housing cover by unscrewing the Allen screw ①.

## ... 6 Installation

### ... Opening and closing the housing

#### Note

After several weeks, increased force will be required to unscrew the housing cover.

This is not caused by the threads, but instead is due to the type of gasket.

#### Note

For LCD indicators with TTG (Through-The-Glass) operation via capacitive buttons, the device must be switched to zero potential briefly after closing the transmitter housing cover.

Thus, the button sensitivity is calibrated and an optimum button function is ensured.

## 7 Electrical connections

### Safety instructions

#### **WARNING**

##### **Risk of injury due to live parts.**

Improper work on the electrical connections can result in electric shock.

- Connect the device only with the power supply switched off.
- Observe the applicable standards and regulations for the electrical connection.

#### Note

When using the device in potentially explosive atmospheres, note the additional connection data in **Use in potentially explosive atmospheres** on page 6!

The electrical connection may only be established by authorized specialist personnel and in accordance with the connection diagrams.

The electrical connection information in this manual must be observed; otherwise, the IP rating may be adversely affected. Ground the measurement system according to requirements.

## Signal cables

For devices with a remote mount design, the transmitter and sensor are connected using a signal cable.

The signal cable used must meet at least the following technical specification.

Cable specification	
Impedance	70 to 120 Ω
Withstand voltage	500 V
Outer diameter	6 to 12 mm (0.24 to 0.47 in)
Cable design	3×2×0.75 mm <sup>2</sup> , twisted pair
Conductor cross-section	0.75 mm <sup>2</sup>
Shield	Copper braid with approximately 85 % coverage
Temperature range	Application-dependent, for use in potentially explosive atmospheres, observe the information in <b>Temperature resistance for the connecting cable</b> on page 8!
Maximum signal cable length	30 m (98 ft)

### Recommended cables

It is recommended to use an ABB signal cable for standard applications.

The ABB signal cable fulfills the above-mentioned cable specification and can be utilized unrestrictedly up to an ambient temperature of  $T_{amb.} = 80\text{ °C}$  (176 °F).


ABB signal cable	Ordering number
5 m (16 ft), standard scope of delivery	3KXF065068U0200
10 m (33 ft)	3KXF065068U0300
20 m (65 ft)	3KXF065068U0400
30 m (98 ft)	3KXF065068U0500

## Installing the connection cables

Ensure that a drip loop (water trap) is used when installing the connecting cables for the sensor.

When mounting the sensor vertically, position the cable entries at the bottom.

If necessary, rotate the transmitter housing accordingly.



① Drip loop

Figure 36: Laying the connection cable

## ... 7 Electrical connections

### Cable glands

The electrical connection is made using cable entries with a ½ in NPT or M20 × 1.5 thread.

#### Devices with an M20 × 1.5 thread

Devices with an M20 × 1.5 thread are supplied with factory-installed cable glands and sealing plugs.

#### Devices with a ½ in NPT thread

The supplied transport sealing plugs do not have IP rating 4X / IP 67 and are not approved for use in potentially explosive atmospheres.

The transport sealing plugs must be replaced with suitable cable glands or sealing plugs during device installation.

When selecting the cable glands or sealing plugs, make sure they have the required IP rating and explosion protection!

To guarantee IP rating 4X / IP67, the cable glands / sealing plugs must be screwed in using a suited sealing compound.


### Grounding

#### NOTICE

##### Impact on measurement

The measurement may be impacted by external electric disruptions (EMC disruptions).

- Ground the device as shown to avoid impact on the measurement by external electric disruptions (EMC disruptions)



- ① Integral mount design and sensor in remote design
- ② Transmitter with remote mount design
- ③ Ground terminal

Figure 37: Ground terminals

For the earthing (PE) of the transmitter or the connection of a protective earth, a connection is available both on the exterior of the housing and in the connection space. Both connections must be galvanically connected to one another.

To avoid potential differences, a 3-point grounding as shown in Figure 37 is recommended.

These connection points can be used if grounding or the connection of a protective conductor is prescribed by national regulations for the selected type of supply or the type of protection used.

1. Loosen the screw terminal on the transmitter housing or on the housing of the VortexMaster / SwirlMaster.
2. Insert the forked cable lug for functional grounding between the two metal tabs and into the loosened terminal.
3. Tighten the screw terminal.

## Devices with HART® communication

### Note

The HART® protocol is an unsecured protocol, as such the intended application should be assessed to ensure that these protocols are suitable before implementation.

### Current output / HART output




Figure 38: Terminals FSx430 (without binary output)

Terminal	Function / comment
PWR/COMM +	Power supply, current
PWR/COMM -	output- / HART output
EXT. METER	Not assigned

### Current output / HART output, digital output and analog input




Figure 39: Terminals FSx450 or FSx430 with binary output

Terminal	Function / comment
PWR/COMM +	Power supply, current output / HART output
PWR/COMM -	
EXT. METER +	Current output 4 to 20 mA for external display
DIGITAL OUTPUT 1+	Digital output, positive pole
DIGITAL OUTPUT 2	Bridge after terminal 1+, NAMUR output deactivated
DIGITAL OUTPUT 3	Bridge after terminal 4-, NAMUR output activated
DIGITAL OUTPUT 4-	Digital output, negative pole
ANALOG INPUT +	Analog input 4 to 20 mA for remote transmitter, e.g.
ANALOG INPUT -	for temperature, pressure, etc.

### Power supply

#### Devices with HART® communication

Terminals	PWR/COMM + / PWR/COMM -
Supply voltage	12 to 42 V DC
Residual ripple	Maximum 5 % or $U_{SS} = \pm 1.5$ V
Power consumption	< 1 W
$U_{SS}$	Peak-to-peak value of voltage

## ... 7 Electrical connections

### ... Devices with HART® communication

#### Current output / HART output

Only for devices with HART communication.




Figure 40: Load diagram of current output; load depending on supply voltage

#### Devices with HART® communication

Terminals PWR/COMM + / PWR/COMM -

Minimal Load  $R_B$  250  $\Omega$

The load  $R_B$  is calculated as a function of the available supply voltage  $U_S$  and the selected signal current  $I_B$  as follows:


$$R_B = U_S / I_B$$

$R_B$  Load resistance

$U_S$  Supply voltage

$I_B$  Signalstrom

#### Low flow cut-off



① Low flow

Figure 41: Behavior of the current output

The current output behaves as shown in the figure.


Above the low flow, the current curve proceeds as a straight line in accordance with the flow rate.

- Flow rate = 0, current output = 4 mA
- Flow rate =  $Q_{max}$ , current output = 20 mA

If the low flow cut-off is activated, flow rates below the low flow are set to 0 and the current output set to 4 mA.

### Analog input 4 to 20 mA

Only for devices with HART® communication.



- ① Terminal points in separate cable junction box
- ② VortexMaster FSV400, SwirlMaster FSS400
- ③ Power supply VortexMaster FSV400, SwirlMaster FSS400
- ④ Remote transmitter
- ⑤ Power supply for the remote transmitter

Figure 42: Connection of transmitters to analog input (example)

### Analog input 4 to 20 mA

Terminals	ANALOG INPUT+ / ANALOG INPUT-
Operating voltage	16 to 30 V DC
Input current	3.8 to 20.5 mA
Equivalent resistance	90 Ω

A remote transmitter with current output from 4 to 20 mA can be connected to the analog input:


- Pressure transmitter e.g. ABB model 261 / 266
- Temperature transmitter
- Gas analyzer for the net methane content of biogas
- Density meter or mass meter for a density signal

The analog input can be configured using the relevant software:

- Input for the pressure measurement for pressure compensation for the flow measurement of gases and vapor.
- Input for the return temperature measurement for energy measurement.
- Input for the net methane content of biogas.
- Input for density measurement for the calculation of the mass flow.

### HART® communication with remote transmitter

Only for devices with HART® communication.



- ① Control cabinet
- ② Power supply
- ③ Power supply for the remote transmitter
- ④ Load resistance
- ⑤ External pressure transmitter
- ⑥ FSx430 connection with output option H1
- ⑦ FSx450 or FSx430 connection with output option H5

Figure 43: Connection of transmitters with HART communication (example)

G11773-01

## ... 7 Electrical connections

### ... Devices with HART® communication

A remote pressure transmitter with HART communication can be connected through the current output / HART output (4 to 20 mA). Here, the remote transmitter must be operated in HART Burst mode, e.g. the ABB pressure transmitter model 266 or model 261 with the 'P6 – HART Burst Mode' ordering option. The VortexMaster F5V400, SwirlMaster F5S400 transmitter supports HART communication up to the HART7 protocol.

**Note**

The VortexMaster / SwirlMaster cannot communicate with a control system or configuration tool via HART while the pressure transmitter is communicating in BURST mode, because the BURST signal has priority over cyclical HART communication.

#### HART® communication connection example




Figure 44: HART communication (example)

For connecting the signal voltage / supply voltage, twisted cables with a conductor cross-section of 18 to 22 AWG / 0.8 to 0.35 mm<sup>2</sup> and a maximum length of 1500 m (4921 ft) must be used. For longer leads a greater cable cross section is required.

For shielded cables the cable shielding must only be placed on one side (not on both sides).

For the earthing on the transmitter, the inner terminal with the corresponding marking can also be used.

The output signal (4 to 20 mA) and the power supply are conducted via the same conductor pair.

The transmitter works with a supply voltage between 12 and 42 V DC. For devices with the type of protection 'Ex ia, intrinsic safety' (FM, CSA, and SAA approval), the supply voltage must not exceed 30 V DC. In some countries the maximum supply voltage is limited to lower values. The permissible supply voltage is specified on the name plate on the top of the transmitter.

**Note**

Any configuration changes are saved in sensor memory only if no HART communication is taking place. To securely save any changes, make sure that HART communication has ended before the device is disconnected from power.

The possible lead length depends on the total capacity and the total resistance and can be estimated based on the following formula.

$$L = \frac{65 \times 106}{R \times C} - \frac{C_i + 10000}{C}$$

L Lead length is meters  
 R Total resistance in Ω  
 C Lead capacity  
 C<sub>i</sub> Maximum internal capacity in pF of the HART field devices in the circuit

Avoid installing the cable together with other power leads (with inductive load, etc.), as well as the vicinity to large electrical installations.

The HART Handheld terminal can be connected to any connection point in the circuit if a resistance of at least 250 Ω is present in the circuit. If there is resistance of less than 250 Ω, an additional resistor must be provided to enable communication. The handheld terminal is connected between the resistor and transmitter, not between the resistor and the power supply.



## Devices with Modbus® communication

### Note

The Modbus® protocol is an unsecured protocol, as such the intended application should be assessed to ensure that these protocols are suitable before implementation.




Figure 45: Terminals

Terminal	Function / comment
PWR +	Power supply
PWR -	
A (+)	Modbus interface RS485
B (-)	
DIGITAL OUTPUT 1+	Digital output, positive pole
DIGITAL OUTPUT 2	Bridge after terminal 1+, NAMUR output deactivated
DIGITAL OUTPUT 3	Bridge after terminal 4-, NAMUR output activated
DIGITAL OUTPUT 4-	Digital output, negative pole

### Power supply

#### Devices with Modbus® communication

Terminals	PWR + / PWR -
Supply voltage	9 to 30 V DC
Residual ripple	Maximum 5 % or $U_{SS} = \pm 1.5 V$
Power consumption	< 1 W
$U_{SS}$	Peak-to-peak value of voltage

### Modbus communication

Using the Modbus protocol allows devices made by different manufacturers to exchange information via the same communication bus, without the need for any special interface devices to be used.

Up to 32 devices can be connected on one Modbus line. The Modbus network can be expanded using repeaters.




Figure 46: Modbus network (example)

#### Modbus interface

Configuration	Via the Modbus interface in connection with Asset Vision Basic (DAT200) and a corresponding Device Type Manager (DTM)
Transmission	Modbus RTU - RS485 serial connection
Baud rate	1200, 2400, 4800, 9600 bps Factory setting: 9600 bps
Parity	None, even, odd Factory setting: none
Typical response time	< 100 milliseconds
Response Delay Time	0 to 200 milliseconds Factory setting: 50 milliseconds
Device address	1 to 247 Factory setting: 247
Register address offset	One base, Zero base Factory setting: One base

## ... 7 Electrical connections

### ... Devices with Modbus® communication

#### Cable specification

The maximum permissible length depends on the baud rate, the cable (diameter, capacity and surge impedance), the number of loads in the device chain, and the network configuration (2-core or 4-core).

- At a baud rate of 9600 and with a conductor cross-section of at least  $0.14 \text{ mm}^2$  (AWG 26), the maximum length is 1000 m (3280 ft).
- If a four-core cable is used in a two-wire system, the maximum length must be divided in half.
- The spur lines must be short (maximum of 20 m (66 ft)).
- When using a distributor with 'n' connections, the maximum length of each branch is calculated as follows: 40 m (131 ft) divided by 'n'.

The maximum cable length depends on the type of cable used.

The following standard values apply:

- Up to 6 m (20 ft):  
cable with standard shielding or twisted-pair cable.
- Up to 300 m (984 ft):  
double twisted-pair cable with overall foil shielding and integrated earth cable.
- Up to 1200 m (3937 ft):  
double twisted-pair cable with individual foil shielding and integrated earth cables. Example: Belden 9729 or equivalent cable.

A category 5 cable can be used for Modbus RS485 up to a maximum length of 600 m (1968 ft). For the symmetrical pairs in RS485 systems, a surge impedance of more than  $100 \Omega$  is preferred, especially at a baud rate of 19200 and above.

## Devices with PROFIBUS PA® or FOUNDATION-Fieldbus® communication.

### Note

The PROFIBUS PA® / FOUNDATION Fieldbus® protocols are unsecured protocols, as such the intended application should be assessed to ensure that these protocols are suitable before implementation.

### Cable specification

The Fieldbus cable to connect the devices with each other must fulfill the following specifications.

### Loop resistance R

15 to 150 Ω/km

### Inductance L

0.4 to 1 μH/km

### Capacitance C

80 to 200 nF/km



### Cable length

Spur line: maximum 30 m  
Trunk line: maximum 1 km

### Bus termination

Passive at both ends of the main bus line  
(RC element R = 90 to 100 Ω, C = 0 to 2.2 μF).

### Power supply



Version with increased EMC protection in accordance with NE21

(Order code 'Additional device equipment – G4')

Figure 47: Terminals

Terminal	Function / comment
BUS CONNECTION	Power supply and PROFIBUS PA® /
BUS CONNECTION	FOUNDATION Fieldbus® interface
DIGITAL OUTPUT 1+*	Digital output, positive pole
DIGITAL OUTPUT 2*	Bridge after terminal 1+, NAMUR output deactivated
DIGITAL OUTPUT 3*	Bridge after terminal 4-, NAMUR output activated
DIGITAL OUTPUT 4-*	Digital output, negative pole

\* Not active in devices with FOUNDATION Fieldbus® communication.

### Devices with PROFIBUS PA® or FOUNDATION Fieldbus® communication.

Terminals	BUS CONNECTION
Supply voltage	9 to 32 V DC
Input Current	~ 10 to 20 mA

## ... 7 Electrical connections

### Connection to remote mount design

#### NOTE

##### Impairment of the device function

Impairment of the device function due to incorrect allocation of sensor and transmitter.

Correct allocation can be identified via the serial number on the name plate.

- Make sure that the sensor and transmitter are correctly allocated.

The signal cable connects the measuring sensor to the transmitter. The cable is fixed to the transmitter, however, it can be separated as needed.

When laying the signal cable, observe the following points:

- Install the signal cable in the shortest path between the measuring sensor and the transmitter. Shorten the signal cable accordingly as needed.
- The maximum permissible signal cable length is 30 m (99 ft).
- Avoid installing the signal cable in the vicinity of electric equipment or switching elements that can create stray fields, switching pulses and magnetic induction. If this is not possible, run the signal cable through a metal pipe and connect this to operational ground.
- Carry out all terminal connections carefully.
- Lay the wires in the terminal box in such a way that they are not affected by vibrations.

#### Producing a signal cable

The signal cable is available in four standard lengths: 5 m (16.4 ft), 10 m (32.8 ft), 20 m (65.6 ft) and 30 m (98.4 ft).

The cable ends are already prepared for installation.




Figure 48: Signal cable, dimensions in mm (in)

The signal cable can also be cut to any length. Then the cable ends must be prepared as shown in Figure 48.

- Twist the shield, shorten and insulate with heat-shrink tube ③. Crimp a matching forked cable lug ② and insulate the crimping with a heat-shrink tube ①.
- Attach wire-end ferrules ( $0.75 \text{ mm}^2$ ) to the wires on the sensor side.
- Twist the wires on the transmitter side and solder.

## Connecting the signal cable

### **⚠ DANGER**

#### **Danger of explosion if the device is operated with the transmitter housing or terminal box open!**

Before opening the transmitter housing or the terminal box, note the following points:

- A valid fire permit must be present.
- Make sure that there is no explosion hazard.
- Switch off the power supply and wait for  $t > 2$  minutes before opening.

1. Use the signal cable connected to the transmitter to make the electrical connection between the measuring sensor and the transmitter.
2. Unscrew the cover of the terminal boxes on the transmitter and the measuring sensor.
3. Produce the signal cable in accordance with the specification (see **Figure 48**).
4. Insert the cable through the cable gland into the terminal box.
5. Tighten the cable gland.
6. Connect the wires to the corresponding terminals (see **Figure 49**).
7. Connect the shield of the signal cable to the forked cable lug to the ground terminal.
8. Screw on the cover of the terminal compartment on the transmitter and the measuring sensor and tighten by hand. Make sure the gaskets for the cover are seated properly.





Figure 49: Electrical connection

Terminal	Color / function
VDD	Yellow
/M/R	White
GND	Green
HS	Pink
DX	Grey
RX	Brown
	Ground terminal (functional ground / shield)

### Note

The shielding of the signal cable also serves as a functional ground and must be connected to the sensor and to the transmitter on both sides.

## 8 Commissioning

### Safety instructions

#### **⚠ DANGER**

**Danger of explosion if the device is operated with the transmitter housing or terminal box open!**

Before opening the transmitter housing or the terminal box, note the following points:

- Check that a valid fire permit is available.
- Make sure that there is no explosion hazard.
- Before opening the device, switch off the power supply and wait for  $t > 2$  minutes.

#### **⚠ CAUTION**

**Risk of burns due to hot measuring media**

The device surface temperature may exceed 70 °C (158 °F), depending on the measuring medium temperature!

- Before starting work on the device, make sure that it has cooled sufficiently.

### General

The commissioning of the device depends on the communication version (HART®, Modbus® / PROFIBUS®, Foundation Fieldbus®).

Commissioning is divided into a general part and fieldbus-dependent information.

#### General commissioning

The following chapters address general commissioning:

- Checks prior to commissioning on page 55
- Power Supply Power-Up on page 55
- Checking and configuring the basic settings on page 55

Commissioning of devices with HART® and Modbus® communication see Devices with HART® and Modbus® communication. on page 60.

Commissioning of devices with PROFIBUS®- and FOUNDATION Fieldbus® communication see Devices with PROFIBUS PA® or FOUNDATION-Fieldbus® communication. on page 84.

### Digital output

Not active in devices with FOUNDATION Fieldbus® communication!




Figure 50: Range of the external supply voltage and current

#### Digital output

Operating voltage	16 to 30 V DC
Output current	maximum 20 mA
External resistance $R_B$	$1.5 \text{ k}\Omega \leq R_B \leq 80 \text{ k}\Omega$
Output 'closed'	$0 \text{ V} \leq U_{low} \leq 2 \text{ V}$ $2 \text{ mA} \leq I_{low} \leq 20 \text{ mA}$
Output 'open'	$16 \text{ V} \leq U_{high} \leq 30 \text{ V}$ $0 \text{ mA} \leq I_{high} \leq 0.2 \text{ mA}$
Pulse output	$f_{max}: 10 \text{ kHz}$ Pulse width: 0.05 to 2000 ms
Frequency output	$f_{max}: 10.5 \text{ kHz}$
Output functions (configurable)	Frequency output Pulse output Binary output (in / out, e.g. alarm signal)

It is possible to use software to configure the optional digital output as an alarm, frequency or pulse output.  
 It is possible to use a bridge to configure the digital output as an optoelectronic coupler output or a NAMUR output.




Figure 51: Hardware configuration of the digital output

Output configuration	Bridge
Optoelectronic coupler output	1–2
NAMUR output	3–4

In the factory setting, the output is configured as an optoelectronic coupler output.

**Note**

The type of protection of the outputs remains unchanged, regardless of the output configuration.  
 The devices connected to the digital output must conform to the current regulations for explosion protection.

**Checks prior to commissioning**

The following points must be checked before commissioning:

- The power supply must be switched off.
- The power supply used must match the information on the name plate.
- Correct wiring in accordance with **Electrical connections** on page 42.
- Correct grounding in accordance with **Grounding** on page 44.
- The ambient conditions must meet the requirements set out in the specification.
- The transmitter must be installed at a location largely free of vibrations.
- The housing cover and cover lock must be sealed before powering-up the power supply.
- For devices with a remote mount design, make sure that the sensor and transmitter are assigned correctly.

**Power Supply Power-Up**

1. Switch on the device power supply.  
 After switching on the power supply, the system data in the SensorMemory is compared with the values stored internally in the transmitter.
  - If the system data is not identical, it is matched automatically.
- The flowmeter is now ready for operation.
- The LCD display shows the process display.

**Checks after switching on the power supply**

The following must be checked after commissioning the device:

- Parameter configuration must correspond to the operating conditions.
- The system zero point is stable.  
 If this is not the case, a zero point balance must be carried out (see **Zero point balance under operating conditions** on page 130).


**Checking and configuring the basic settings**

The device can be factory parameterized to customer specifications upon request. If no customer information is available, the device is delivered with factory settings.

Parameter	Factory setting
Active Mode	Liquid Volume
Output Value	Flow rate
DO Function	No function
Q <sub>max</sub>	Actual value set to Q <sub>max</sub> DN. Depending on the nominal diameter of the flowmeter.
Unit Q	m <sup>3</sup> /h
Analog In Value	No function
HART In Value	No function
Low Flow Cutoff	4 %
low at Alarm	Low Alarm Value
Low Alarm Value	3.55 mA
High Alarm Value	22 mA

## ... 8 Commissioning


### Parameterization via the menu function Easy Setup


Settings for the most common parameters are summarized in the 'Easy Setup' menu. This menu provides the fastest way to configure the device. The next respective parameter is called out by  (Next).


**Note**




The LCD display is provided with capacitive control buttons. These enable you to control the device through the closed housing cover.


**Open the Menu Easy Setup**




1. Switch to the configuration level using .




2. Use  /  'Standard' to make the selection.
3. Confirm the selection with .






4. Use  to confirm the password. A password is not available as factory default; you can continue without entering a password.


**Note**





For security reasons it is recommended, to set a password.



5. Use  /  'Easy Setup' to make the selection.
6. Confirm the selection with .



**Selection of the menu language**







1. Use  to call up the edit mode.
2. Use  /  to select the desired language.
3. Confirm the selection with .

**Select the operating mode\* / measuring medium\*\***

For more information on the operating mode\*, refer to **Operating modes** on page 65.



1. Use  to call up the edit mode.
2. Use  /  to select the desired operating mode\* / measuring medium\*\*.
3. Confirm the selection with .

\* Only for devices with HART® and Modbus® communication.  
 \*\* Only for devices with PROFIBUS® or FOUNDATION Fieldbus® communication.




### Configuration of the current output

Only for devices with HART® communication!




1. Use to call up the edit mode.
2. Use / to select the desired process value for the current output.
3. Confirm the selection with .




### Configuration of the digital output




1. Use to call up the edit mode.
2. Use / to select the desired operating mode for the digital output.
  - Logic on DO: Operation as a switch output.
  - Pulse on DO: In pulse mode, pulses are emitted per unit.
  - Freq on DO: In frequency mode, a frequency proportional to the flow is emitted.
3. Confirm the selection with .



4. Use to call up the edit mode.
5. With the help of / / , set the pulses per unit (Pulse on DO) or the upper frequency (Freq on DO).
6. Confirm the selection with .




7. Use to call up the edit mode.
8. With the help of / / , set the pulse width (Pulse on DO) or the lower frequency (Freq on DO).
9. Confirm the selection with .



10. Use to call up the edit mode.
11. Select the switching behavior for the binary output using / .
12. Confirm the selection with .

### Selection of the units

In the following menus, the units for the following process values are selected: volume, mass, standard volume, power, density, temperature, pressure, volume flowmeter, mass flowmeter, standard volume flowmeter and energy meter.




1. Use to call up the edit mode.
2. Use / to select the desired unit for the respective process value.
3. Confirm the selection with .

## ... 8 Commissioning

### ... Parameterization via the menu function Easy Setup

Configuration of the analog / HART input  
 Only for devices with HART® communication!




1. Use to call up the edit mode.
2. Use / to select the desired function for the analog / HART input.

HART In Value	Analog In Value	Function
Ext. T	Ext. T	External temperature transmitter downstream for energy measurement
Pressure	Pressure	External pressure transmitter
Gas Content	Gas Content	External gas analyzer
Density	Density	External density transmitter
Int.T	Int.T	External temperature transmitter upstream for energy measurement
-	Ext. Cutoff	External output zero return

3. Confirm the selection with .

In the following menus, the measurement range limits for the external transmitters are fixed at the analog input.



4. Use to call up the edit mode.
5. Use / to set the measuring range limits for the respective process value.
6. Confirm the selection with .

Configuration of the parameters dependent on the operating mode


Only for devices with HART® communication!

The parameters shown in this position in the menu depend on the selected operating mode and are not presented in detail here. Refer to **Operating modes** on page 65 and **Parameter descriptions** on page 104 for detailed information!

#### Select the end value for the current output

Only for devices with HART® communication!

Setting of the flow rate or energy quantity at which the current output is to output 20 mA (100 %). The value entered must be at least 15 % of Q max DN.




1. Use to call up the edit mode.
2. Use / to set the desired end value for the current output.
3. Confirm the selection with .

#### Adjusting the damping value

Adjustment of the damping for the respective process value. [the value relates to 1 T (Tau)].

The damping relates to a step change in the flow rate or energy quantity or temperature.

The damping affects the instantaneous value in the process display and at the current output.




1. Use to call up the edit mode.
2. Use / to set the desired damping for the respective process value.
3. Confirm the selection with .


**Configuration of the alarm signaling via the current output**

Only for devices with HART® communication!



**Configuration of the low flow cut-off**




1. Use to call up the edit mode.
2. Adjust the desired state in case of faults using / .
3. Confirm the selection with .



1. Use to call up the edit mode.
2. Use / / to set the desired value for the low flow cut-off.
3. Confirm the selection with .



4. Use to call up the edit mode.
5. Use / / to set the alarm current.
6. Confirm the selection with .



Once all parameter have been set, the main menu appears again. The most important parameters are now set.


4. Use to switch to the process display.

**Zero point adjustment of the flowmeter**

**Note**

Prior to starting the zero point adjustment, make sure that:

- There is no flow through the sensor (close all valves, shut-off devices etc.)
- The sensor must be completely filled with the medium to be measured.



- Use to start automatic adjustment of the zero point for the system.

## ... 8 Commissioning

### Devices with HART® and Modbus® communication.

#### Hardware Settings

##### Current output 4 to 20 mA / HART®

In the factory setting, the flow signal is emitted via the current output of 4 to 20 mA. Alternatively, the temperature signal can be assigned to the current output.

##### Analog input 4 to 20 mA

Only for FSx450mit HART® communication !

External devices can be connected to the passive analog input (4 to 20 mA).

The function of the analog input can be selected via the software ('Input/Output' menu).

The analog input can be configured via the 'Easy Setup' menu or the setup menu of the device. Before starting the configuration, select the type of the connected signal and then select the values for 4 mA and 20 mA that correspond to the relevant output values of the connected device.

#### HART® Input

Only for devices with HART® communication!

The HART input can be configured via the 'Easy Setup' menu or the setup menu of the device.

The device recognizes the value and the corresponding unit via the HART input.


The remote transmitter must be operated in HART burst mode.

If, for example, the pressure unit is set to psi in the setup menu of the device but the pressure unit of the connected pressure transmitter is set to kPa, the VortexMaster / SwirlMaster takes the pressure unit from the pressure transmitter.

#### Note

The use of the ABB Pressure transmitter model 266 or model 261 with ordering option 'P6 – HART Burst Mode' is recommended.

DIP switch on the HART® communication board



① Interface for LCD indicators and ② DIP switch service port

Figure 52: HART communication board / 4 to 20 mA

DIP switch	Function
SW 1.1	Write protection switch On: Write protection active Off: Write protection deactivated
SW 1.2	Replacement mode (transfer system data) On: Replacement mode active Off: Replacement mode deactivated
SW 1.3	System data transfer direction On: Transmitter -> sensor Off: Sensor -> transmitter
SW 1.4	Selection whether the alarm function is configured via software or DIP switch. On: Selection of alarm current via SW 1.5 Off: Selection of alarm current via the 'Input/Output / Iout at Alarm' menu.
SW 1.5	Selection of alarm current On: Low alarm (3.5 to 3.6 mA) Off: High alarm (21.0 to 22.6 mA)
SW 1.6	Format SensorMemory Service function! - Risk of data loss in the device.

The communication board is located behind the front housing cover. The LCD indicator may have to be removed to provide access to the DIP switches.

The DIP switches are used to configure specific hardware functions. The power supply to the transmitter must be briefly interrupted in order for the modified setting to take effect. The interface for the LCD indicator is also used as the service port for device configuration.

**Write-protect switch**

When write protection is activated, device parameterization cannot be changed via HART or the LCD indicator. Activating and sealing the write protection switch protects the device against tampering

**Note**

The product has an ABB Service Account, which can be deactivated with this write protection switch.

**Downloading system data, replacing the transmitter**

When replacing transmitter components (communication board), system data must be downloaded from the SensorMemory.


Download of system data and the system data transfer direction is activated using DIP switches SW 1.2 and SW 1.3.

Refer to **Replacing the transmitter, downloading system data** on page 142.

**Status of the current output**

DIP switches SW 1.4 and SW 1.5 can be used to configure the status of the current output in the event of an alarm / error. If the current in the event of an alarm is selected via DIP switch SW 1.5, the setting can no longer be changed using HART or the LCD indicator.

**DIP switch on the Modbus communication board**



G11969

① Interface for LCD indicators and ② DIP switch service port

Figure 53: Modbus communication board

DIP switch	Function
SW 1.1	Replacement mode (transfer system data) On: Replacement mode active Off: Replacement mode deactivated
SW 1.2	System data transfer direction On: Transmitter -> sensor Off: Sensor -> transmitter
SW 1.3	No function
SW 1.4	Format SensorMemory Service function! – Risk of data loss in the device.
SW 1.5	Write protection switch On: Write protection active Off: Write protection deactivated
SW 1.6	No function

## ... 8 Commissioning

### ... Devices with HART® and Modbus® communication.

The communication board is located behind the front housing cover. The LCD indicator may have to be removed to provide access to the DIP switches.

The DIP switches are used to configure specific hardware functions. The power supply to the transmitter must be briefly interrupted in order for the modified setting to take effect. The interface for the LCD indicator is also used as the service port for device configuration.

#### **Write-protect switch**

If write protection is active, the device parameterization cannot be changed. Activating and sealing the write protection switch protects the device against tampering

#### **Note**

The product has an ABB Service Account, which can be deactivated with this write protection switch.

#### **Downloading system data, replacing the transmitter**

When replacing transmitter components (communication board), system data must be downloaded from the SensorMemory.

Loading system data and the system data transfer direction is activated using DIP switches SW 1.1 and SW 1.2.

Refer to **Replacing the transmitter, downloading system data** on page 142.

**Factory settings of HART® Variables PV, SV, TV and QV depending on the operating mode**

The following table shows the factory default assignment of process variables to the HART variables (PV, SV, TV or Qv) depending on operating mode.

Operating mode	HART variables			
	PV	SV	TV	QV
Liquid Volume	Operating volumes	Temperature	Totalizer volumes	–
Liquid Std/Norm Vol.	Standard volume	Temperature	Standard volume counter	Operating volumes
Liquid Mass	Mass	Temperature	Totalizer mass	Operating volumes
Liquid Energy	Energy	Temperature	Energy counter	Operating volumes
Gas Act. Volume	Operating volumes	Temperature	Totalizer volumes	–
Gas Std/Norm Vol.	Standard volume	Temperature	Standard volume counter	Operating volumes
Gas Mass	Mass	Temperature	Totalizer mass	Operating volumes
Gas Power	Energy	Temperature	Energy counter	Operating volumes
Bio Act. Volume	Partial operating volumes	Temperature	Partial volume counter	Operating volumes
Bio Std/Norm Vol.	Standard partial volumes	Temperature	Standard partial volume counter	Standard volume counter
Steam Act. Volume	Operating volumes	Temperature	Totalizer volumes	–
Steam/Water Mass	Mass	Temperature	Totalizer mass	Operating volumes
Steam/Water Energy	Energy	Temperature	Energy counter	Mass

## ... 8 Commissioning

### ... Devices with HART® and Modbus® communication.

Possible selection of HART® Variables depending on the respective operating mode

The following table shows the possible process variables which can be assigned to the HART variables (PV, SV, TV or Qv) depending on the operating mode. The process variables can be assigned to the HART variables via the Device Type Manager or the EDD / FDI package in the Field Information Manager (FIM tool).

Operating mode	PV	Additional dynamic HART variables which can be selected							
Liquid Volume	Operating volumes	Temperature	Totalizer volumes	-	-	-	-	-	-
Liquid Std/Norm Vol.	Standard volume	Temperature	Standard volume counter	Operating volumes	Totalizer volumes	-	-	-	-
Liquid Mass	Mass	Temperature	Totalizer mass	Operating volumes	Totalizer volumes	-	-	-	-
Liquid Energy	Energy	Temperature	Energy counter	Operating volumes	Totalizer volumes	Mass	Totalizer mass	-	-
Gas Act. Volume	Operating volumes	Temperature	Totalizer volumes	-	-	-	-	-	-
Gas Std/Norm Vol.	Standard volume	Temperature	Standard volume counter	Operating volumes	Totalizer volumes	-	-	-	-
Gas Mass	Mass	Temperature	Totalizer mass	Operating volumes	Totalizer volumes	-	-	-	-
Gas Power	Energy	Temperature	Energy counter	Operating volumes	Totalizer volumes	Standard volumes	Standard volume counter	-	-
Bio Act. Volume	Partial operating volumes	Temperature	Partial volume counter	Operating volumes	Totalizer volumes	-	-	-	-
Bio Std/Norm Vol.	Standard partial volumes	Temperature	Standard partial volume counter	Operating volumes	Totalizer volumes	Standard volumes	Standard volume counter	Partial operating volumes	Partial volume counter
Steam Act. Volume	Operating volumes	Temperature	Totalizer volumes	-	-	-	-	-	-
Steam/Water Mass	Mass	Temperature	Totalizer mass	Operating volumes	Totalizer volumes	-	-	-	-
Steam/Water Energy	Energy	Temperature	Energy counter	Operating volumes	Totalizer volumes	Mass	Totalizer mass	-	-



## Operating modes

The parameters for the different operating modes are described in the following table.

Operating mode / (order code)	Designation	Additional parameters required	Parameter setting
Liquid Volume / NL1	Operating volume flow (for liquid measuring medium)	–	–
Liquid Volume (temperature compensated) / NL2	Standard volume flow (for liquid measuring medium)	Measuring medium temperature <sup>1</sup>	With internal temperature sensor. No information required, the measured value from the temperature sensor is used.  Default setting for the temperature value: Device Setup / Plant/Customized / Compensation Setting -> Preset Int.Temp
		Reference temperature in the normal condition	Device Setup / Plant/Customized / Compensation Setting -> Ref. Temperature
		Volume expansion coefficient	Device Setup / Plant/Customized / Compensation Setting -> Volume Exp.Coef.
Liquid Mass (no adjustment) / NL3	Liquid mass flow, based on direct determination of the operating density via analog input, HART input or default setting. (for liquid measuring medium)	Operating density <sup>2,3</sup>	Via analog input: Input/Output / Field Input / Analog In Value -> Density  Via HART input: Input/Output / Field Input / HART In Value -> Density  Default setting for the density: Device Setup / Plant/Customized / Compensation Setting -> Preset Density

1 The highest priority of the device is to record the operating temperature.

2 The highest priority of the device is to record the density via the analog input, as long as the analog input is activated as a density input. If the analog input is not available as a density input, the system attempts to record the density via the HART input. If both the analog input and the HART input are deactivated as a density input, the system uses the default density value.

3 The connection via the analog input or HART input is described in **Electrical connections** on page 42.

## ... 8 Commissioning

### ... Devices with HART® and Modbus® communication.

Operating mode / (order code)	Designation	Additional parameters required	Parameter setting
Liquid Mass (density adjustment) / NL3	Mass flow rate, based on the density under reference conditions and density expansion coefficient in the normal condition. (for liquid measuring medium)	Measuring medium temperature <sup>1</sup>	With internal temperature sensor. No information required, the measured value from the temperature sensor is used.
		Reference temperature in the normal condition	Default setting for the temperature value: Device Setup / Plant/Customized / Compensation Setting -> Preset Int.Temp
		Density expansion coefficient	Device Setup / Plant/Customized / Compensation Setting -> Ref. Temperature
		Density under reference conditions in the normal condition	Device Setup / Plant/Customized / Compensation Setting -> Density Exp.Coef.
Liquid Mass (volume adjustment) / NL3	Liquid mass flow, based on density under reference conditions and volume expansion coefficient in the normal condition (for liquid measuring medium)	Measuring medium temperature <sup>1</sup>	With internal temperature sensor. No information required, the measured value from the temperature sensor is used.
		Reference temperature in the normal condition	Default setting for the temperature value: Device Setup / Plant/Customized / Compensation Setting -> Preset Int.Temp
		Volume expansion coefficient	Device Setup / Plant/Customized / Compensation Setting -> Ref. Temperature
		Density under reference conditions in the normal condition	Device Setup / Plant/Customized / Compensation Setting -> Volume Exp.Coef.
		Density under reference conditions in the normal condition	Device Setup / Plant/Customized / Compensation Setting -> Ref. Density

<sup>1</sup> The highest priority of the device is to record the operating temperature.

Operating mode / (order code)	Designation	Additional parameters required	Parameter setting
Liquid Energy / NL4 <sup>4</sup>	Energy measurement, such as brine or condensate. (for liquid measuring medium)	Heat capacity  Upstream measuring medium temperature <sup>1</sup>	Device Setup / Plant/Customized / Compensation Setting -> Specific Heat Capacity  With internal temperature sensor. No information required, the measured value from the temperature sensor is used.  Default setting for the temperature value: Device Setup / Plant/Customized / Compensation Setting -> Preset Int.Temp
		Reverse measuring medium temperature <sup>3, 5</sup>	Via analog input: Input/Output / Field Input / Analog In Value -> Temperature  Via HART input: Input/Output / Field Input / HART In Value -> Temperature  Default setting for the temperature: Device Setup / Plant/Customized / Compensation Setting -> Preset Ext.Temp
Gas Act. Volume / NG1	Operating volume flow (for gaseous measuring media)	-	-

- 1 The highest priority of the device is to record the operating temperature.
- 3 The connection via the analog input or HART input is described in **Electrical connections** on page 42.
- 4 In order to implement the 'Liquid Energy' mode, required parameters from one of the NL3 modes must be available as a precondition. Refer to **Energy measurement for liquid measuring medium (except water)** on page 73.
- 5 The highest priority of the device is to record the temperature via the analog input, as long as the analog input is activated as a temperature input. If the analog input is not available as a temperature input, the system attempts to record the temperature via the HART input. If both the analog input and the HART input are deactivated as a temperature input, the system uses the default density value.

## ... 8 Commissioning

### ... Devices with HART® and Modbus® communication.

Operating mode / (order code)	Designation	Additional parameters required	Parameter setting
Gas Std/Norm Vol. / NG2	Standard volume flow (for gaseous measuring media)	Operating pressure <sup>3,5</sup>	Via analog input: Input/Output / Field Input / Analog In Value -> Pressure
			Via HART input: Input/Output / Field Input / HART In Value -> Pressure
			Default setting for the pressure value: Device Setup / Plant/Customized / Compensation Setting -> Preset Pressure(abs)
		Operating temperature <sup>3,5</sup>	With internal temperature sensor. No information required, the measured value from the temperature sensor is used.
			Via analog input: Input/Output / Field Input / Analog In Value -> Temperature
			Via HART input: Input/Output / Field Input / HART In Value -> Temperature
			Default setting for the temperature value: Device Setup / Plant/Customized / Compensation Setting -> Preset Int.Temp
		Compression factor in the standard condition (AGA / SGERG only)	Adjustment via DTM/EDD <sup>7</sup>
		Compression factor in the operating condition	Adjustment via DTM/EDD <sup>7</sup>

<sup>3</sup> The connection via the analog input or HART input is described in **Electrical connections** on page 42.

<sup>5</sup> The highest priority of the device is to record the temperature via the analog input, as long as the analog input is activated as a temperature input. If the analog input is not available as a temperature input, the system attempts to record the temperature via the HART input. If both the analog input and the HART input are deactivated as a temperature input, the system uses the default density value.

<sup>7</sup> If for the menu item Device Setup / Plant/Customized -> Gas Std. Mode the selection is set to 'Gas linear.', the compression factor is reset to 1.0. Refer to **Energy measurement for liquids, gases and steam** on page 73.

Operating mode / (order code)	Designation	Additional parameters required	Parameter setting
Gas Mass (Density under reference conditions) / NG3	Mass flow rate, calculated with the density under reference conditions, pressure and temperature (for gaseous measuring media)	Reference pressure and reference temperature in the normal condition  Density under reference conditions	Device Setup / Plant/Customized / Gas Ref. Conditions Via analog input: (For selection, see operating mode Gas Std/Norm Vol. / NG2) Via HART input: (For selection, see operating mode Gas Std/Norm Vol. / NG2)
Gas Mass (actual density) / NG3	Mass flow rate, calculated using the current density in the operating condition. (gaseous measuring media)	Operating density <sup>2, 3</sup>	Via analog input: Input/Output / Field Input / Analog In Value -> Density Via HART input: Input/Output / Field Input / HART In Value -> Density Default setting for the density: Device Setup / Plant/Customized / Compensation Setting -> Preset Density
Gas Power / NG4	Energy measurement (gaseous measuring media)	Energy density	Device Setup / Plant/Customized / Compensation Setting -> Gas Energy Density
Bio Act. Volume / NG5	Partial operating volume flow rate of biogas	Biogas proportion <sup>8</sup>	Via analog input: Input/Output / Field Input / Analog In Value -> Gas Content
Bio Std/Norm Vol. <sup>9</sup> / NG6	Partial standard volume flow of biogas		Via HART input: Input/Output / Field Input / HART In Value -> Gas Content Default setting for the density: Device Setup / Plant/Customized / Compensation Setting -> Preset Density

- 2 The highest priority of the device is to record the density via the analog input, as long as the analog input is activated as a density input. If the analog input is not available as a density input, the system attempts to record the density via the HART input. If both the analog input and the HART input are deactivated as a density input, the system uses the default density value.
- 3 The connection via the analog input or HART input is described in **Electrical connections** on page 42.
- 8 The biogas proportion can be determined via the analog input, HART input or default setting. The highest priority of the device is to record the biogas proportion via the analog input, as long as the analog input is activated as a biogas proportion input. If the analog input is not available as a biogas proportion input, the system attempts to record the biogas proportion via the HART input. If both the analog input and the HART input are deactivated as a biogas proportion input, the system uses the default biogas proportion value.
- 9 In order to implement the 'Bio Std/Norm Vol.' mode, the required parameters from one of the NG2 modes must be available as a precondition.

## ... 8 Commissioning

### ... Devices with HART® and Modbus® communication.

Operating mode / order code	Designation	Additional parameters required	Parameter setting
Steam Act. Volume / NS1	Actual volume flow rate of steam	n/a	–
Steam/Water Mass (internal density determination) <sup>10</sup> / NS2	Mass flow rate of steam / hot water. The calculation is done in accordance with IAPWS-IF97.	Steam type  Operating pressure <sup>3,6</sup>  Operating temperature <sup>3,5</sup>	Selection of steam type via: Device Setup / Plant/Customized / Compensation Setting / Water/Steam Type  Via analog input: Input/Output / Field Input / Analog In Value -> Pressure  Via HART input: Input/Output / Field Input / HART In Value -> Pressure  Default setting for the pressure value: Device Setup / Plant/Customized / Compensation Setting -> Preset Pressure(abs)  With internal temperature sensor. No information required, the measured value from the temperature sensor is used.  Default setting for the temperature value: Device Setup / Plant/Customized / Compensation Setting -> Preset Int.Temp

3 The connection via the analog input or HART input is described in **Electrical connections** on page 42.

5 The highest priority of the device is to record the temperature via the analog input, as long as the analog input is activated as a temperature input. If the analog input is not available as a temperature input, the system attempts to record the temperature via the HART input. If both the analog input and the HART input are deactivated as a temperature input, the system uses the default density value.

6 The highest priority of the device is to record the pressure via the analog input, as long as the analog input is activated as a pressure input. If the analog input is not available as a pressure input, the system attempts to record the pressure via the HART input. If both the analog input and the HART input are deactivated as a pressure input, the system uses the default pressure value.

10 In order to implement the 'Steam/Water Mass' mode with internal density determination, the selection 'Calculated from...' must be set in the Device Setup / Plant/Customized / Compensation Setting -> Density Selection menu.

Operating mode / order code	Designation	Additional parameters required	Parameter setting
Steam/Water Mass (external density determination) / NS2 <sup>11</sup>	Mass flow rate of steam / hot water	Steam type	Selection of steam type via: Device Setup / Plant/Customized / Compensation Setting / Water/Steam Type
		Operating density <sup>2,3</sup>	Via analog input: Input/Output / Field Input / Analog In Value -> Density  Via HART input: Input/Output / Field Input / HART In Value -> Density  Default setting for the density: Device Setup / Plant/Customized / Compensation Setting -> Preset Density
Steam/Water Energy / NS3 <sup>12</sup>	Energy flow of steam / hot water. The calculation is done in accordance with IAPWS-IF97. <sup>13</sup>	Steam type	Selection of steam type via: Device Setup / Plant/Customized / Compensation Setting / Water/Steam Type
		Energy calculation	Selection of the type of energy calculation via: Device Setup / Plant/Customized / Compensation Setting Energy calc. method
		Upstream measuring medium temperature <sup>14</sup>	With internal temperature sensor. No information required, the measured value from the temperature sensor is used.  Default setting for the temperature value: Device Setup / Plant/Customized / Compensation Setting -> Preset Int.Temp

- 2 The highest priority of the device is to record the density via the analog input, as long as the analog input is activated as a density input. If the analog input is not available as a density input, the system attempts to record the density via the HART input. If both the analog input and the HART input are deactivated as a density input, the system uses the default density value.
- 3 The connection via the analog input or HART input is described in **Electrical connections** on page 42.
- 11 In order to implement the 'Steam/Water Mass' mode with external density determination, in the Device Setup / Plant/Customized / Compensation Setting -> Density Selection menu, the selection 'Ext. Density' must be made.
- 12 For a detailed description of steam calculation, refer to **Energy measurement for steam / hot water in accordance with IAPWS-IF97** on page 73ff.
- 13 Two different properties of steam are supported: saturated steam and overheated steam. The end user can change this in the Device Setup / Plant/Customized / Compensation Setting -> Water/Steam Type menu item.
- 14 Required only for net energy calculation of the actually consumed energy

## ... 8 Commissioning

### ... Devices with HART® and Modbus® communication.

Operating mode / order code	Designation	Additional parameters required	Parameter setting
Steam/Water Energy / NS3 <sup>12</sup> (continued)	Energy flow of steam / hot water. Reverse measuring medium temperature <sup>14</sup> The calculation is done in accordance with IAPWS-IF97. <sup>13</sup>		Via analog input: Input/Output / Field Input / Analog In Value -> Temperature <hr/> Via HART input: Input/Output / Field Input / HART In Value -> Temperature <hr/> Default setting for the temperature: Device Setup / Plant/Customized / Compensation Setting -> Preset Ext.Temp
		Operating pressure <sup>3, 6</sup>	Via analog input: Input/Output / Field Input / Analog In Value -> Pressure <hr/> Via HART input: Input/Output / Field Input / HART In Value -> Pressure <hr/> Default setting for the pressure value: Device Setup / Plant/Customized / Compensation Setting -> Preset Pressure(abs)
		Operating temperature <sup>3, 5</sup>	With internal temperature sensor. No information required, the measured value from the temperature sensor is used. <hr/> Default setting for the temperature value: Device Setup / Plant/Customized / Compensation Setting -> Preset Int.Temp

3 The connection via the analog input or HART input is described in **Electrical connections** on page 42.

5 The highest priority of the device is to record the temperature via the analog input, as long as the analog input is activated as a temperature input. If the analog input is not available as a temperature input, the system attempts to record the temperature via the HART input. If both the analog input and the HART input are deactivated as a temperature input, the system uses the default density value.

6 The highest priority of the device is to record the pressure via the analog input, as long as the analog input is activated as a pressure input. If the analog input is not available as a pressure input, the system attempts to record the pressure via the HART input. If both the analog input and the HART input are deactivated as a pressure input, the system uses the default pressure value.

12 For a detailed description of steam calculation, refer to **Energy measurement for steam / hot water in accordance with IAPWS-IF97** on page 73ff.

13 Two different properties of steam are supported: saturated steam and overheated steam. The end user can change this in the Device Setup / Plant/Customized / Compensation Setting -> Water/Steam Type menu item.

14 Required only for net energy calculation of the actually consumed energy



**Energy measurement for liquids, gases and steam**

**Note**

Pulse output for energy measurement:

- The pulse output generally relates to the selected flow unit.
- If the flow unit is selected as energy unit 'watt (W), kilowatt (KW), or megawatt (MW)', the pulses relate to J (W), KJ (KW), or MJ (MW). 1 watt then corresponds to 1 J/s.

**Energy measurement for liquid measuring medium (except water)**

**Order code N2**

The VortexMaster FSV450 and the SwirlMaster FSS450 with order code N2 have an extended function for measuring the energy flow for fluids, which is built into the transmitter. Based on the values for actual volume flow, density, heat capacity of the medium (energy unit / mass flow unit), temperature of the feed flow (built-in Pt100 resistance thermometer) and temperature of the return flow, the transmitter calculates the actual volume flow and the energy flow.





Figure 54: Measuring the energy of liquids

**Energy measurement for steam / hot water in accordance with IAPWS-IF97**

**Order code N1**

The VortexMaster FSV450 and the SwirlMaster FSS450 with option N1 have an extended function for measuring the flow of steam, which is built into the transmitter.



- ① Feed flow
- ② VortexMaster / SwirlMaster with built-in temperature sensor
- ③ Pressure transmitter, via HART or analog input
- ④ Temperature transmitter, via HART or analog input
- ⑤ Condensate return

Figure 55: Energy measurement

Based on the values of pressure (external diaphragm seal, connected via HART or analog input, or a preset pressure value) and temperature (built-in Pt100 resistance thermometer), the transmitter calculates the density and the energy content of the measuring medium.

The measured volume flow rate is converted into the mass flow rate and energy flow rate.

The type of energy calculation can be selected:

- **Gross energy:** The amount of energy that flows through the device is recorded. Any energy re-flow in form of condensate is not considered.
- **Net energy:** The amount of energy that flows through the device is recorded. Any energy re-flow in form of condensate is deducted again from the amount of energy. For this, an additional external temperature transmitter must be connected.

## ... 8 Commissioning

### ... Devices with HART® and Modbus® communication.

For energy measurement, the medium types 'Saturated Steam', 'Overheated Steam' or 'Hot Water' can be selected.

The calculation is done according to IAPWS-IF97.

#### Calculation of the net energy for steam

$$Q_p = Q_m \times (H_{steam} - H_{water})$$

#### Calculation of the net energy for hot water / condensate

$$Q_p = Q_m \times (H_{water\_in} - H_{water\_out})$$

#### Formula elements used

$Q_p$	Net energy
$Q_m$	Mass flow
$H_{steam}$	Steam enthalpy
$H_{water}$	Water enthalpy
$H_{water\_in}$	Water enthalpy (feed flow)
$H_{water\_out}$	Water enthalpy (return flow)

Prerequisites for the energy measurement:

- When measuring the energy of steam, the steam must condense completely.
- The process must form a closed system, energy losses due to leaks are not recorded.

#### Steam mass calculation

The following options are available for the steam mass calculation:

- Density calculated from the temperature (saturated steam only)
- Density calculated from the pressure (saturated steam only)
- Density calculated from pressure and temperature
- Constant density

If a pressure transmitter is connected, the steam state is checked automatically. A distinction is made between wet steam, saturated steam, and superheated steam. The correct density is always calculated regardless of the selected media type.

If a pressure transmitter is not connected and steam type 'Overheated Steam' is selected, a constant pressure must be entered for the state to be detected and, if applicable, the density to be calculated.

A value must always be stored for the steam density value (constant) in the transmitter in order to define the measuring range limits for  $Q_{max, DN}$  in mass flow units.

An approximation is sufficient here, the density diagrams provide an indication for determining the steam density.

#### Density diagrams

The following diagrams show an extract from the density table for saturated steam at different temperatures / pressures.




Figure 56: Saturated steam pressure by temperature





Figure 57: Saturated steam density by pressure



- (A) Hot steam zone
- (B) Saturated steam zone
- (1) 1.0 kg/m<sup>3</sup> (0.06 lb/ft<sup>3</sup>)
- (2) 1.5 kg/m<sup>3</sup> (0.09 lb/ft<sup>3</sup>)
- (3) 2 kg/m<sup>3</sup> (0.12 lb/ft<sup>3</sup>)
- (4) 2.5 kg/m<sup>3</sup> (0.16 lb/ft<sup>3</sup>)
- (5) 3 kg/m<sup>3</sup> (0.19 lb/ft<sup>3</sup>)
- (6) 4 kg/m<sup>3</sup> (0.25 lb/ft<sup>3</sup>)
- (7) 5 kg/m<sup>3</sup> (0.31 lb/ft<sup>3</sup>)
- (8) 6 kg/m<sup>3</sup> (0.37 lb/ft<sup>3</sup>)
- (9) 8 kg/m<sup>3</sup> (0.50 lb/ft<sup>3</sup>)
- (10) Saturated steam limit

Figure 58: Steam density for hot steam

The parallel lines (1) to (9) are lines of the same density.

**Application example (broken line in diagram)**

Superheated steam with 225°C, 9 bar abs (437 °F, 130 psia). It yields a steam density of approx. 4.1 kg/m<sup>3</sup> (0.26 lb/ft<sup>3</sup>).

## ... 8 Commissioning

### ... Devices with HART® and Modbus® communication.

#### Calculation of the density

The density calculation method is selected using the 'Density Selection' parameter.

Media type	Calculation method	Description
Saturated Steam	Calc. From T	The steam density is calculated in accordance with the saturated steam curve using the measured temperature value from the internal temperature sensor. If using an FSS430 / FSV430 without optional internal temperature sensor, a constant (parameter 'Preset Int.Temp') must be entered for the temperature. Alternatively, an external temperature transmitter can also be connected with HART communication.
	Calc. From P	The steam density is calculated according to IAPWS-IF97 with a measured pressure value. The measured pressure value can either be supplied via the analog input, the HART input, or as a constant (parameter 'Preset Pressure(abs)').
	Calc. From P&T	The steam density is calculated in accordance with IAPWS-IF97 using the measured temperature value from the internal temperature sensor and a measured pressure value. The measured pressure value can either be supplied via the analog input, the HART input, or as a constant (parameter 'Preset Pressure(abs)'). If using an FSS430 / FSV430 without optional internal temperature sensor, a constant (parameter 'Preset Int.Temp') must be entered for the temperature. Alternatively, an external temperature transmitter can also be connected with HART communication. <ul style="list-style-type: none"> <li>• If the steam is not saturated steam, the device issues a warning 'Wrong Steam Type'. The density and energy content of the steam is then calculated as overheated steam using the current values.</li> <li>• If the steam temperature is too low (wet steam), the device issues a warning 'Wrong Steam Type'. The density (and energy if necessary) is then calculated in accordance with the saturated steam curve based on the measured value of the internal or external temperature sensor.</li> </ul> If the 'Wrong Steam Type' warning is set, a status message with the steam status is additionally generated, while the time of the active status message is incremented and can be assessed.
	Ext. Density	The steam mass is calculated using the density value that is supplied either via the analog input, the HART input, or as a constant (parameter 'Preset Density'). Detection of wet steam / overheated steam is not possible with this calculation method.

Media type	Calculation method	Description
Overheated Steam	Calc. From P&T	<p>The steam density is calculated in accordance with IAPWS-IF97 using the measured temperature value from the internal temperature sensor and a measured pressure value.</p> <p>The measured pressure value can either be supplied via the analog input, the HART input, or as a constant (parameter 'Preset Pressure(abs)').</p> <p>If using an FSS430 / FSV430 without optional internal temperature sensor, a constant (parameter 'Preset Int.Temp') must be entered for the temperature. Alternatively, an external temperature transmitter can also be connected with HART communication.</p> <ul style="list-style-type: none"> <li>If the steam temperature is too low (wet steam), the device issues a warning 'Wrong Steam Type'. The density (and energy if necessary) is then calculated in accordance with the saturated steam curve based on the measured value of the internal or external temperature sensor.</li> </ul> <p>If the 'Wrong Steam Type' warning is set, a status message with the steam status is additionally generated, while the time of the active status message is incremented and can be assessed.</p>
	Ext. Density	<p>The steam mass is calculated using the density value that is supplied either via the analog input, the HART input, or as a constant (parameter 'Preset Density').</p> <p>Detection of wet steam / overheated steam is not possible with this calculation method.</p>
Hot Water	Calc. From T	<p>The density is calculated in accordance with IAPWS-IF97 using the measured temperature value from the internal temperature sensor.</p> <p>If using an FSS430 / FSV430 without optional internal temperature sensor, a constant (parameter 'Preset Int.Temp') must be entered for the temperature. Alternatively, an external temperature transmitter can also be connected with HART communication.</p>
	Ext. Density	<p>The hot water mass is calculated from the density.</p> <p>The density can either be supplied via the analog input, the HART input, or as a constant (parameter 'Preset Density').</p>

#### Note

Regardless of the media type and the calculation method, a density value must be entered in the 'Device Setup / Plant/Customized / Compensation Setting / Preset Density' menu to determine the max. measuring range limits.

- The entered density will not be used for compensation purposes.
- The entered density should be calculated in accordance with the typical (maximum) operating conditions.

## ... 8 Commissioning

### ... Devices with HART® and Modbus® communication.

#### Natural gas calculation in accordance with AGA8 / SGERG88

The VortexMaster and SwirlMaster both have a natural gas calculation function in accordance with AGA8 (ISO12212-2) / SGERG88 (ISO12212-3).

In order to calculate the compressibility factor in relation to the temperature and pressure limits, the composition of the natural gas must be entered in the transmitter.

The parameters are entered using Asset Vision Basic in combination with the DTM500 package or, alternatively, using a hand held terminal.

To ensure accurate calculation of the gas density and compressibility factor, it is recommended that the integrated temperature sensor be used and an external pressure transmitter connected.

#### Configuration using Asset Vision Basic

1. Select the required calculation function (AGA8 / SGERG88) from the DTM menu.




Figure 59: DTM Menu

2. Enter limits for the measuring medium pressure [0 to 120 bar (0 to 1740 psi)] and the measuring medium temperature [-10 to 64.85 °C (14 to 148.7 °F)].




Figure 60: Measuring medium pressure / Measuring medium temperature

#### Note

The entered pressure and temperature limits are used for the matrix calculation of the compressibility factor. To ensure accurate calculation of the compressibility factor, the value should correspond as closely as possible to real process conditions.

- Entry of the natural gas composition in accordance with the gas analysis. The percentages entered must add up to 100%. The input masks for AGA8 / SGERG88 are different. See the following figures.

Gas Data for Test according AGA 8 with Mole fractions [%]

Methane	<input type="text" value="81.00000"/>	%	n-Butane	<input type="text" value="0.00000"/>	%
Nitrogen	<input type="text" value="4.50000"/>	%	Isopentane	<input type="text" value="0.00000"/>	%
Carbon Dioxide	<input type="text" value="9.00000"/>	%	n-Pentane	<input type="text" value="0.00000"/>	%
Ethane	<input type="text" value="4.60000"/>	%	n-Hexane	<input type="text" value="0.00000"/>	%
Propane	<input type="text" value="0.75000"/>	%	n-Heptane	<input type="text" value="0.00000"/>	%
Water	<input type="text" value="0.00000"/>	%	n-Octane	<input type="text" value="0.00000"/>	%
Hydrogen Sulfide	<input type="text" value="0.15000"/>	%	n-Nonane	<input type="text" value="0.00000"/>	%
Carbon Monoxide	<input type="text" value="0.00000"/>	%	n-Decane	<input type="text" value="0.00000"/>	%
Hydrogen	<input type="text" value="0.00000"/>	%	Helium	<input type="text" value="0.00000"/>	%
Oxygen	<input type="text" value="0.00000"/>	%	Argon	<input type="text" value="0.00000"/>	%
Isobutane	<input type="text" value="0.00000"/>	%			

Figure 61: AGA8 in accordance with ISO12212-2

Gas Data for Test according GERG 88 with Mole fractions [%]

Calorific Value	<input type="text" value="36.64000"/>	%
Carbon Dioxide	<input type="text" value="9.00000"/>	%
Hydrogen	<input type="text" value="0.00000"/>	%
Reference Condition	<input type="text" value="Cal. Val. 0 deg.C; Dens. 0 deg.C, 1.01325 bar"/>	
Standard Density	<input type="text" value="0.83000"/>	kg/m3

Figure 62: SGERG88 in accordance with ISO12212-3

- After entering the natural gas composition, start the compressibility factor calculation.

## ... 8 Commissioning

### ... Devices with HART® and Modbus® communication.

- Click the "Apply" button to apply the calculated compressibility factors to the transmitter.



G11822

Figure 63: Display of the calculated compressibility factors



**Configuration with the Field Information Manager (FIM-Tool)**

Alternatively, the configuration and entry of values for the natural gas calculation can be done using the FIM Tool with an appropriate Device Package.

Both are provided by ABB on the website of the device.

The following example illustrates the procedure:

- Make sure the FSx450 Device Package has been loaded onto the FIM-Tool.
1. Select operating mode 'Gas Standard Volume' or 'Gas Mass'. The operating mode is selected using the 'Operating Mode / Process Mode' menu item.




Figure 64: Selection of the operating mode

2. Call up the 'Device Setup' menu.




Figure 65: Calling up the menu

3. Selection / change of the desired calculation method in the 'Compensation Settings' menu under 'Gas Std Mode'.




Figure 66: Selection of the desired calculation method

4. The selection is sent to the device by the 'Send' function.



Figure 67: Send selection to the device

5. A range for the pressure and temperature process parameters is defined through the 'Basic Parameters'. The operating data should be within this range, which is why should be chosen as generously as possible to accommodate the expected minimum and maximum pressures and temperatures. A matrix with corresponding compressibility factors is generated for these framework conditions.



Figure 68: Basic Parameter

6. The selection is sent to the device by the 'Send' function.

# ... 8 Commissioning

## ... Devices with HART® and Modbus® communication.

7. Starting the calculation function.



Figure 69: Starting the calculation function

The selected calculation mode and previously selected framework conditions can be viewed in the 'Configurations' tab.




Figure 70: Calculation mode and framework conditions

8. Switch to the 'Compressibility Factor' tab. Any existing values in the device are read out or a standard gas composition is loaded as the default value. Due to the large amount of data, this can take a moment.





Figure 71: Presentation of existing values

9. Entering the gas composition data. New compression values can be calculated by pressing the 'Calculate' button.



G12211

Figure 72: Compression value calculation

10. The new compression factors are sent to the device by pressing the 'Send to Device' button.




Figure 73: Sending the compression factors to the device

After all the steps are successfully completed, all values in this window become white again. The device now calculates the gas density according to the selected method.

## Eliminating HART® communication faults

**COM9 # Konfiguration**

Communication interface: HART modem

Serial Interface: COM9 (MACTek VIATOR USB HART Modem)

HART protocol: Master: Primary Master

Preamble: 5

Number of communication retries: 10

Address scan: Start address: 0, End address: 0

Communication timeout: 5 seconds

Multimaster and Burst mode support

Figure 74: Adjusting the communication parameters

If any disruptions in communication with the DTM should appear, we recommend adjusting the communication parameters to stabilize the HART® communication.


Parameter	Recommended settings
Number of communication retries (number of communication attempts)	Maximum possible amount
Communication timeout (time out period)	Maximum possible time

## ... 8 Commissioning

### Devices with PROFIBUS PA® or FOUNDATION-Fieldbus® communication.

#### Hardware Settings

DIP switch on the PROFIBUS PA®- / FOUNDATION Fieldbus® communication board



① Interface for LCD indicators and service port      ② DIP switch

Figure 75: PA/FF communication board

DIP switch	Function
DIP 1	Write protection switch On: Write protection active Off: Write protection deactivated
DIP 2	Replacement mode (transfer system data) On: Replacement mode active Off: Replacement mode deactivated
DIP 3	System data transfer direction On: Transmitter -> sensor Off: Sensor -> transmitter
DIP 4	Simulation mode (only with FOUNDATION Fieldbus) On: Simulation mode active Off: Simulation mode deactivated
DIP 5	No function
DIP 6	Format SensorMemory Service function! – Risk of data loss in the device.

The communication board is located behind the front housing cover. The LCD indicator may have to be removed to provide access to the DIP switches.

The DIP switches are used to configure specific hardware functions. The power supply to the transmitter must be briefly interrupted in order for the modified setting to take effect.

The interface for the LCD indicator is also used as the service port for device configuration.

#### Write-protect switch

When write protection is activated, device parameterization cannot be changed via the Fieldbus or the LCD indicator. Activating and sealing the write protection switch protects the device against tampering

#### Note

The product has an ABB Service Account, which can be deactivated with this write protection switch.

#### Downloading system data, replacing the transmitter

When replacing transmitter components (communication board), system data must be downloaded from the SensorMemory.

Loading system data and the system data transfer direction is activated using the DIP 2 and DIP 3 DIP switches.

Refer to **Replacing the transmitter, downloading system data** on page 142.

#### Simulation mode (only with FOUNDATION Fieldbus)

You can release the simulation of AI function blocks with the DIP 4 DIP switch.

**PROFIBUS PA®**

**Note**

The PROFIBUS PA® protocol is an unsecured protocol, as such the intended application should be assessed to ensure that these protocols are suitable before implementation.

**PROFIBUS PA® Interface**

Terminals	BUS CONNECTION
Configuration	Via the PROFIBUS PA interface or the local LCD indicator
Transmission	In accordance with IEC 61158-2
Baud rate	9.6 kbps, 19.2 kbps, 45.45 kbps, 93.75 kbps, 187.5 kbps, 500 kbps, 1.5 Mbps The baud rate is automatically detected and does not need to be configured manually
Device profile	PA Profile 3.02
Bus address	Address range 0 to 126 Factory setting: 126

A device driver in the form of a EDD (Electronic Device Description) DTM (Device Type Manager) as well as a GSD file is required for commissioning.

You can download EDD, DTM and GSD from [www.abb.de/flow](http://www.abb.de/flow).

The files required for operation can also be downloaded from [www.profibus.com](http://www.profibus.com).

ABB provides three different GSD files which can be integrated in the system.

ID number	GSD file name	Blocks
0x9700	—	1×AI
0x9740	—	1×AI, 1×TOT
0x3433	ABB_3433.gsd	4×AI, 3×AO, 1×DI, 3×TOT

Users decide at system integration whether to install the full range of functions or only part. Switching is made using the 'IdentNr Selector' parameter.

**Structure and design of the function blocks**

Block structure	Supported PROFIBUS ID numbers		
	0x3433	0x9740	0x9700
Physical Block	Slot 0	Slot 0	Slot 0
Analog Input Block (AI)	Slot 1	Slot 1	Slot 1
	Slot 2	—	—
	Slot 3	—	—
	Slot 4	—	—
Analog output block (AO)	Slot 5	—	—
	Slot 6	—	—
	Slot 7	—	—
Discrete Input Block (DI)	Slot 8	—	—
Totalizer Block (TOT)	Slot 9	Slot 9	—
	Slot 10	—	—
	Slot 11	—	—
Transducer Block-HMI	Slot 12	Slot 12	Slot 12
Transducer Block-PCB	Slot 13	Slot 13	Slot 13
Transducer Block-Standard	Slot 14	Slot 14	Slot 14




Figure 76: Design of the function blocks

**Note**

For additional information on the PROFIBUS PA® interface, refer to the separate COM/FSV/FSS/430/450/PB interface description!

## ... 8 Commissioning

### ... Devices with PROFIBUS PA® or FOUNDATION-Fieldbus® communication.

#### FOUNDATION Fieldbus®

**Note**

The FOUNDATION Fieldbus® protocol is an unsecured protocol, as such the intended application should be assessed to ensure that these protocols are suitable before implementation.

**FOUNDATION Fieldbus® Interface**

Terminals	BUS CONNECTION
Configuration	Via the FOUNDATION Fieldbus interface or the local LCD indicator
Transmission	FOUNDATION Fieldbus H1 in accordance with IEC 61158-2
Baud rate	9.6 kbps, 19.2 kbps, 45.45 kbps, 93.75 kbps, 187.5 kbps, 500 kbps, 1.5 Mbps The baud rate is automatically detected and does not need to be configured manually
Interoperability test campaign no.	ITK 6.3.0
Manufacturer ID	0x000320
Device ID	0x12C
Bus address	Address range 0 to 126 Factory setting: 126

A device driver in the form of an EDD (Electronic Device Description) / CFF file (Common File Format) is required for commissioning purposes.

You can download the EDD and CFF at [www.abb.de/flow](http://www.abb.de/flow).

The files required for operation can also be downloaded from [www.fieldbus.org](http://www.fieldbus.org).

#### Structure and design of the function blocks

Ordinal	Block
0	RESOURCE_2_FD
1	TB0: HMI
2	TB1: PCB
3	TB2: Standard
4	TB3: Advanced
5	AI1
6	AI2
7	AI3
8	AI4
9	AO1
10	AO2
11	AO3
12	DI
13	IT
14	EPID




Figure 77: Design of the function blocks

**FOUNDATION Fieldbus® Channel Assignment (Channel)**

<b>AI Channel</b>	<b>Process value</b>
1	Volume flow
2	Partial volume flow
3	Standard volume flow
4	Partial standard volume flow
5	Mass flow
6	Energy
7	Temperature
8	Volume flow counter
9	Partial volume flow counter
10	Standard volume flow counter
11	Partial standard volume flow counter
12	Mass flow counter
13	Energy counter
<b>AO Channel</b>	<b>Process value</b>
14	Temperature
15	Second temperature
16	Gauge pressure
17	Absolute pressure
18	Density
19	Gas content
<b>DI Channel</b>	
20	Switch output
21	Low flow cutoff

**Note**

For additional information on the FOUNDATION Fieldbus® interface, refer to the separate COM/FSV/FSS/430/450/FF interface description!

## 9 Operation

### Safety instructions

#### **CAUTION**

##### **Risk of burns due to hot measuring media**

The device surface temperature may exceed 70 °C (158 °F), depending on the measuring medium temperature!

- Before starting work on the device, make sure that it has cooled sufficiently.

If there is a chance that safe operation is no longer possible, take the device out of operation and secure it against unintended startup.


### Parameterization of the device

The LCD indicator has capacitive operating buttons. These enable you to control the device through the closed housing cover.

#### **Note**

The transmitter automatically calibrates the capacitive buttons on a regular basis. If the cover is opened during operation, the sensitivity of the buttons is firstly increased to enable operating errors to occur. The button sensitivity will return to normal during the next automatic calibration.

### Menu navigation



- ① Operating buttons for menu navigation
- ② Indication of menu designation
- ③ Indication of menu number
- ④ Marking to indicate relative position within the menu
- ⑤ Indication of the current function assigned to the operating buttons and

Figure 78: LCD indicator (example)

You can use the or operating buttons to browse through the menu or select a number or character within a parameter value.

Different functions can be assigned to the and operating buttons. The function that is currently assigned (⑤) is shown on the LCD display.

### Operating button functions


	Meaning
Exit	Exit menu
Back	Go back one submenu
Cancel	Cancel parameter entry
Next	Select the next position for entering numerical and alphanumeric values

	Meaning
Select	Select submenu / parameter
Edit	Edit parameter
OK	Save parameter entered



## Menu levels



### Process display

The process display shows the current process values.  
There are two menu levels under the process display.

### Information level (Operator Menu)

The information level contains the parameters and information that are relevant for the operator.  
The device configuration cannot be changed on this level.

### Configuration level (Configuration)

The configuration level contains all the parameters required for device commissioning and configuration. The device configuration can be changed on this level. For detailed information on the parameters, refer to **Parameter descriptions** on page 104.

### Note

With the hardware write protection activated (see **DIP switch on the HART® communication board** on page 60, **DIP switch on the Modbus communication board** on page 61 or **DIP switch on the PROFIBUS PA®- / FOUNDATION Fieldbus® communication board** on page 84), the device configuration can no longer be changed using the LCD indicator or the Fieldbus interface. By activating the hardware write protection and sealing the respective DIP switches, the device can be protected against unauthorized changes to the device configuration.

## ... 9 Operation

### Process display




Figure 79: Process display (example)

The process display appears on the LCD display when the device is powered on. It shows information about the device and current process values.


The way in which the current process values are shown can be adjusted on the configuration level.

The symbols at the bottom of the process display are used to indicate the functions of the operating buttons and , in addition to other information.


Symbol	Description
/	Call up information level. When Autoscroll mode is activated, the  icon appears here and the operator pages are automatically displayed one after the other.
	Call up configuration level.
	The device is protected against changes in the parametrization.

### Switching to the information level (operator menu)

On the information level, the operator menu can be used to display diagnostic information and choose which operator pages to display.



1. Open the using Operator Menu.




2. Select the desired submenu using / .
3. Confirm the selection with .


Menu	Description
... / Operator Menu	
Diagnostics	Selection of sub-menu 'Diagnostics'; see also <b>Error messages on the LCD display</b> on page 93.
Operator Page 1 to n	Selection of operator page to be displayed.
Autoscroll	When 'Autoscroll' is activated, automatic switching of the operator pages is initiated on the process screen.
Signal view	Selection of submenu 'Signal view' (only for service purposes).




## Switching to the configuration level (parameterization)

The device parameters can be displayed and changed on the configuration level.



1. Switch to the configuration level with .



2. Select the desired level of access using  / .
3. Confirm the selection with .


### Note

There are three levels of access. A password can be defined for level 'Standard'.


There is no factory default password. For security reasons it is recommended, to set a password.


Access Level	Description
Read Only	All parameters are locked. Parameters are read only and cannot be modified.
Standard	All the parameters can be altered.
Service	Only Customer Service has access to the Service menu.

Once you have logged on to the corresponding access level, you can edit or reset the password.




Reset (status 'no password defined') by selecting  as a password.

The newly assigned password is not valid until you log out from the 'Standard'.



4. Enter the corresponding password (see **Selecting and changing parameters** on page 92). No password is preset in the factory settings. Users can switch to the configuration level without entering a password. The selected access level remains active for 3 minutes. Within this time period you can toggle between the process display and the configuration level without re-entering the password.
5. Use  to confirm the password.

The LCD display now indicates the first menu item on the configuration level.


6. Select a menu using  / .
7. Confirm the selection with .

## ... 9 Operation


### Selecting and changing parameters

#### Entry from table

When an entry is made from a table, a value is selected from a list of parameter values.



1. Select the parameters you want to set in the menu.
2. Use to call up the list of available parameter values. The parameter value that is currently set is highlighted.




3. Select the desired value using / .
4. Confirm the selection with .


This concludes the procedure for selecting a parameter value.

#### Numerical entry

When a numerical entry is made, a value is set by entering the individual decimal positions.




1. Select the parameters you want to set in the menu.
2. Use to call up the parameter for editing. The decimal place that is currently selected is highlighted.




3. Use to select the decimal place to change.
  4. Use / to set the desired value.
  5. Use to select the next decimal place.
  6. If necessary select and set additional decimal places in accordance with steps 3 to 4.
  7. Use to confirm your setting.
- This concludes the procedure for changing a parameter value.

#### Alphanumeric entry

When an alphanumeric entry is made, a value is set by entering the individual decimal positions.



1. Select the parameters you want to set in the menu.
2. Use to call up the parameter for editing. The decimal place that is currently selected is highlighted.




3. Use to select the decimal place to change.
  4. Use / to set the desired value.
  5. Use to select the next decimal place.
  6. If necessary select and set additional decimal places in accordance with steps 3 to 4.
  7. Use to confirm your setting.
- This concludes the procedure for changing a parameter value.





## Error messages on the LCD display

In the event of an error, a message consisting of a symbol and text (e.g. Electronics) appears at the bottom of the process screen.

The text displayed provides information about the area in which the error has occurred.



The error messages are divided into four groups in accordance with the NAMUR classification scheme. The group assignment can only be changed using a DTM or EDD:

Symbol	Description
	Error / failure
	Function check
	Outside of the specification
	Maintenance required

The error messages are also divided into the following areas:

Range	Description
Fonctionnement	Error / alarm due to the current operating conditions.
Sensor	Error / alarm of the flowmeter sensor.
Electronics	Error / alarm of the electronics.
Configuration	Error / alarm due to device configuration.

### Note

For a detailed description of errors and troubleshooting instructions, please see **Diagnosis / error messages** on page 131.

## ... 9 Operation

### Parameter overview

**Note**  
 This overview of parameters shows all the menus and parameters available on the device. Depending on the version and configuration of the device, not all of the menus and parameters may be visible in it.

The various operating modes have different menu displays. In this overview, menus are marked with numbers that appear only in certain operating modes.

**Operating modes\***

1	Liquid Mass	6	Bio Std/Norm Vol.	11	Gas Power
2	Liquid Volume	7	Liquid Std/Norm Vol.	12	Steam Act. Volume
3	Gas Mass	8	Bio Act. Volume	13	Steam/Water Energy
4	Steam/Water Mass	9	Liquid Energy		
5	Gas Std/Norm Vol.	10	Gas Act. Volume		

**Easy Setup**

Language

Active Mode\* / Medium Type\*\*

Current Out

DO Function

Pulses Per Unit

Pulse Width

Lower Frequency

Upper Frequency

Logic on DO

Unit Qv

Unit Qm <sup>1,3,4</sup>

Unit Qnv

Unit Qpower

Unit Density <sup>1,3,4</sup>

Unit Temperature

Unit Pressure <sup>3,4,5,6</sup>

Unit Volume

Unit Mass

Unit Std/Norm Vol.

Unit Energy

HART In Value

Analog In Value

T Ext. Upper Range <sup>1,4,5,6,7</sup>

T Ext. Lower Range <sup>1,3,4,5,6,7</sup>

Pressure Upper Range

Pressure Lower Range

P(abs) Upper Range

P(abs) Lower Range


Continued on next page

\* Only for devices with HART® or Modbus® communication.  
 \*\* Only for devices with PROFIBUS® or FOUNDATION Fieldbus® communication.


Continued  
Density Upper Range  
Density Lower Range  
Gas% Upper Range  
Gas% Lower Range  
Ext.Cutoff Trigger  
Liquid Mass Corr.  
Volume Exp.Coeff. 1,7  
Density Exp.Coeff. 1,7  
Specific Heat Capacity  
Gas Density Selec.  
Gas Ref. Conditions 3,5,6  
Gas Std. Mode  
Gas Energy Density  
Water/Steam Type 4  
Density Selection  
Energy calc. method  
Ref. Density 1,3  
Preset Density 1,3,4  
Ref. Temperature 1,3,6,7  
Preset Int.Temp 1,3,4,5,7  
Preset Ext.Temp  
Preset Pressure(abs) </v> 3,4,5,6  
Preset Gas Content  
Qvmax  
QnMax 3,5,6,7  
QvpMax 6,8  
QnpMax 6  
QmMax 3,4  
QpowerMax  
Damping Qv  
Damping Qn 1,3,5,6,7  
Damping Qvp 6,8  
Damping Qnp 6  
Damping Qm 3,4  
Damping Qpower  
Temp->I=0%  
Damping Temperature  
Iout at Alarm  
Low Alarm Value  
High Alarm Value  
Auto Zero  
Low Flow Cutoff

# ... 9 Operation

## ... Parameter overview









# ... 9 Operation

## ... Parameter overview




\* Only for devices with HART® or Modbus® communication.

\*\* Only for devices with PROFIBUS® or FOUNDATION Fieldbus® communication.




# ... 9 Operation

## ... Parameter overview




**Note**


The menu Communication depends on the device design.



# ... 9 Operation

## ... Parameter overview





## ... 9 Operation

### Parameter descriptions

#### Note

This overview of parameters shows all the menus and parameters available on the device. Depending on the version and configuration of the device, not all of the menus and parameters may be visible in it.

#### Menu: Easy Setup

Menu / parameter	Description
<b>Easy Setup</b>	
Language	Selection of menu language.
Active Mode	Selection of operating mode (only for devices with HART® or Modbus® communication). See <b>Operating modes</b> on page 65 for further information.
Medium Type	Selection of the measuring medium type (only for devices with PROFIBUS® or FOUNDATION Fieldbus® communication). <ul style="list-style-type: none"> <li>Liquid: Liquid measuring media</li> <li>Gas: Gaseous measuring media</li> <li>Steam: Steam as a measuring medium</li> </ul>
Output Value	Selection of the process variable issued at the current output. <ul style="list-style-type: none"> <li>Q: Flow</li> <li>T: Temperature</li> </ul>
DO Function	Selection of the function for the digital output (not for devices with FOUNDATION Fieldbus® communication). <ul style="list-style-type: none"> <li>None: Digital output deactivated.</li> <li>Logic on DO: Digital output as a binary output (e.g. as an alarm output).</li> <li>Pulse on DO: Digital output DO1 as a pulse output. In pulse mode, pulses are output per unit (e.g. 1 pulse per m3)</li> <li>Freq on DO: Digital output DO1 as a frequency output. In frequency mode, a frequency is issued that is proportional to the flow rate. The maximum frequency can be configured in accordance with the upper range value.</li> </ul>
Pulses Per Unit	Setting of the pulses per unit of the selected operating mode and pulse width for the 'Pulse on DO' function of the digital output.
Pulse Width	Available only if the digital output has been configured as a pulse output.
Lower Frequency	Setting of the frequency range for the 'Freq on DO' function of the digital output.
Upper Frequency	Available only if the digital output has been configured as a frequency output.
Logic on DO	Select switching properties for the binary output. <ul style="list-style-type: none"> <li>Normally Closed: Binary output to open a normally closed contact.</li> <li>Normally Open: Binary output to close a normally open contact.</li> </ul>
Unit Qv	Selection of unit for volume flow. m3/s, m3/min, m3/h, m3/Tag, ft3/s, ft3/min, ft3/h, ft3/Tag, l/s, l/min, l/h, l/Tag, kl/s, kl/min, kl/h, kl/Tag, us gal/s, us gal/min, us gal/h, us gal/Tag, imperial gal/s, imperial gal/min, imperial gal/h, imperial gal/day, barrel/s, barrels/min, barrel/h, barrels/day Factory setting: l/min
Unit Qm	Selection of unit for mass flow. g/s, g/min, g/h, kg/s, kg/min, kg/h, kg/day, lbs/s, lbs/min, lbs/h, lbs/d, uton/min, uton/h, uton/day, kl/s, kl/min, kl/h, kl/day
Unit Qnv	Selection of unit for the standard volume flow. m3/s, m3/min, m3/h, m3/Tag, ft3/s, ft3/min, ft3/h, ft3/Tag, l/s, l/min, l/h, l/Tag, kl/s, kl/min, kl/h, kl/Tag, us gal/s, us gal/min, us gal/h, us gal/Tag, imperial gal/s, imperial gal/min, imperial gal/h, imperial gal/day, barrel/s, barrel/min, barrel/h, barrel/day, kft3/s, kft3/min, kft3/h, kft3/day, hl/s, hl/min, hl/h, hl/day, kl/s, kl/min, kl/h, kl/day Factory setting: l/min
Unit Qpower	Selection of unit for energy measurement. W, MW, KW, KJ/s, KJ/min, KJ/h, KJ/day, MJ/h




Menu / parameter	Description
<b>Easy Setup</b>	
Unit Density	Selection of unit for density. kg/m <sup>3</sup> , g/cm <sup>3</sup> , kg/l, g/ml, g/l, lb/in <sup>3</sup> , lb/ft <sup>3</sup>
Unit Temperature	Selection of unit for temperature. kelvin, celsius, fahrenheit
Unit Pressure	Selection of unit for pressure measurement. Pa, MPa, KPa, HPa, bar, mbar, mm H <sub>2</sub> O, psi, kg/cm <sup>3</sup>
Unit Volume	Selection of unit for the volume totalizer. m <sup>3</sup> , ft <sup>3</sup> , l, milli l, hecto l, imp gallon, us gallon, us barrels beer
Unit Mass	Selection of unit for the mass counter. g, kg, t, us ton, uk ton, pounds, unze
Unit Std/Norm Vol.	Selection of unit for the standard volume totalizer. m <sup>3</sup> , ft <sup>3</sup> , l, milli l, hecto l, imp gallon, us gallon, us barrels beer
Unit Energy	Selection of unit for the energy counter. J, KJ, MJ, KWH
HART In Value	Selection of the process variables measured via the HART input (only for devices with HART® communication). <ul style="list-style-type: none"> <li>• None: No remote transmitter at the input.</li> <li>• Temperature: Remote temperature transmitter at the input (transmitter in the reverse flow of a heating or cooling cycle for net energy calculation or transmitter in the device outlet (see <b>Installation for external pressure and temperature measurement</b> on page 34) for temperature compensation, if no internal temperature measurement is possible / desired).</li> <li>• Pressure: Remote pressure transmitter at the input.</li> <li>• Pressure(abs): Remote absolute pressure transmitter at the input.</li> <li>• Gas Content: Remote gas analyzer at the input.</li> <li>• Density: Remote transmitter at the input.</li> <li>• Int.T: External temperature transmitter, e.g. for using a remote temperature transmitter instead of the internal temperature sensor to increase the accuracy or reduce the response time.</li> </ul> Refer to <b>HART® Input</b> on page 60.
Analog In Value	Selection of the process variables measured via the analog input (only for devices with HART® communication). For description, see parameter "HART In Value". Refer to <b>Analog input 4 to 20 mA</b> on page 60.
T Ext. Upper Range	Setting of the measuring range limits for the external transmitter at the analog input.
T Ext. Lower Range	The upper value applies for a current of 20 mA at the analog input, the lower value for a current of 4 mA.
Pressure Upper Range	The availability of this parameter depends on the process variable selected for the analog input.
Pressure Lower Range	
P(abs) Upper Range	
P(abs) Lower Range	
Density Upper Range	
Density Lower Range	
Gas% Upper Range	
Gas% Lower Range	

## ... 9 Operation

### ... Parameter descriptions

Menu / parameter	Description
<b>Easy Setup</b>	
Ext.Cutoff Trigger	<p>Selection of the switching point for externally switching off the output via the analog input.</p> <p>If the switching point is exceeded, the flow measurement is set to zero.</p> <p>Possible switching points: &gt; 4 mA, &gt; 8 mA, &gt; 12 mA</p>
Liquid Mass Corr.	<p>Selection of the correction method for liquid mass measurement in operating mode 'Liquid Mass'.</p> <ul style="list-style-type: none"> <li>None: Liquid mass flow, based on direct determination of the operating density via analog input, HART input, or a constant preset value.</li> <li>Density Corr.: Liquid mass flow, based on density under reference conditions and density expansion coefficient.</li> <li>Volume Corr.: Liquid mass flow, based on density under reference conditions and volume expansion coefficient.</li> </ul> <p>See <b>Operating modes</b> on page 65 for further information.</p>
Gas Density Selec.	<p>Selection of the density source for gas mass measurement in operating mode 'Gas Mass'.</p> <ul style="list-style-type: none"> <li>Ref. Density: Gas mass flow, calculated using pressure, temperature, and density under reference conditions.</li> <li>Act. Density: Gas mass flow, calculated using the current density in the operating condition.</li> </ul> <p>See <b>Operating modes</b> on page 65 for further information.</p>
Gas Ref. Conditions	<p>Selection of the reference pressure and reference temperature for determination of the standard condition.</p> <p>Possible selection: 14.7 psi, 60°F / 14.7 psi, 70°F / 1.013 bar, 0°C / 1.013 bar, 20°C</p>
Gas Std. Mode	<p>Selection of method for gas density calculation.</p> <ul style="list-style-type: none"> <li>Ideal Gas: Gas density calculation in accordance with the general gas law. The gases are regarded as "ideal gas".</li> <li>AGA8: Natural gas calculation in accordance with AGA8 (ISO12212-2).</li> <li>GERG88: Natural gas calculation in accordance with GERG88 (ISO12212-3).</li> </ul> <p>Refer to <b>Natural gas calculation in accordance with AGA8 / SGERG88</b> on page 78.</p>
Gas Energy Density	<p>Setting of the calorific value for gas in operating mode 'Gas Power'.</p> <p>See <b>Operating modes</b> on page 65 for further information.</p>
Water/Steam Type	<p>Selection of the medium type in the operating mode 'Steam/Water Mass'.</p> <ul style="list-style-type: none"> <li>Saturated Steam: Saturated steam.</li> <li>Overheated Steam: Overheated steam.</li> <li>Hot Water: Hot water.</li> </ul> <p>See <b>Operating modes</b> on page 65 and <b>Energy measurement for steam / hot water in accordance with IAPWS-IF97</b> on page 73 for additional information.</p>
Density Selection	<p>Selection of the steam density source in operating mode 'Steam/Water Mass'.</p> <ul style="list-style-type: none"> <li>Ext. Density: Remote density transmitter at HART or analog input.</li> <li>Calc. From P&amp;T: Calculation of the density for saturated steam and overheated steam using a remote pressure transmitter and the integrated temperature sensor.</li> <li>Calc. From T: Calculation of the density for saturated steam using the integrated temperature sensor.</li> <li>Calc. From P: Calculation of the density from the pressure only</li> </ul>
Energy calc. method	<p>Selection of the type of energy calculation in the operating mode Steam/Water Energy.</p> <ul style="list-style-type: none"> <li>Gross energy: The amount of energy that flows through the device is recorded. Any energy re-flow in form of condensate is not considered.</li> <li>Net energy: The amount of energy that flows through the device is recorded. Any energy re-flow in form of condensate is deducted again from the amount of energy.</li> </ul> <p>See <b>Operating modes</b> on page 65 and <b>Energy measurement for steam / hot water in accordance with IAPWS-IF97</b> on page 73 for additional information.</p>

Menu / parameter	Description
<b>Easy Setup</b>	
Ref. Density	Setting of the standard density of the measuring medium.
Preset Density	Setting of the density (operating density) of the measuring medium as a constant.
Ref. Temperature	Setting of the reference temperature.
Preset Int.Temp	Setting of the measuring medium temperature as a constant. The value entered must correspond as closely as possible to the temperature of the measuring medium in the meter tube.
Preset Ext.Temp	Adjustment of the return flow temperature as constant for the calculation of net energy consumption.
Preset Pressure(abs)	Setting of the measuring medium pressure as a constant.
Preset Gas Content	Setting of the methane content as a constant.
Qvmax	Setting of the flow rate or energy quantity at which the current output is to output 20 mA (100 %).
QnMax	The value entered must be at least 15 % of $Q_{\dots\max\text{DN}}$ .
QvpMax	
QnpMax	
QmMax	
QpowerMax	
Damping Qv	Setting of the damping (the value relates to 1 T [Tau]).
Damping Qn	The value relates to a step change in the flow rate or energy quantity.
Damping Qvp	The value affects the instantaneous value in the process display and at the current output.
Damping Qnp	Default setting: 1 second
Damping Qm	
Damping Qpower	
Temp->I=0%	Setting of the temperature at which the current output is to output 20 mA or 4 mA. Only available if parameter 'Output Value' has been set to 'Temperature'.
Temp->I=100%	
Damping Temperature	Setting of the damping (the value relates to 1 T [Tau]). The value relates to a step change in the temperature. The value affects the instantaneous value in the process display and at the current output.
Out at Alarm	Selection of status of the current output in error condition. The output 'min.' or 'max.' current is set in the subsequent menu.
Low Alarm Value	Sets the current for min. alarm.
High Alarm Value	Sets the current for max. alarm.
Auto Zero	Starts the automatic zero point balancing using  .
	<b>Note</b>
	Prior to starting the zero point adjustment, make sure that: <ul style="list-style-type: none"> <li>• There is no flow through the sensor (close all valves, shut-off devices etc.)</li> <li>• The sensor must be filled completely with measuring medium for measurement.</li> <li>• The adjustment process takes approximately 45 seconds.</li> <li>• If automatic zero point balancing does not yield the desired results, see chapter <b>Zero point balance under operating conditions</b> on page 130.</li> </ul>
Low Flow Cutoff	Sets the switching threshold for the low flow cut-off. The set value relates to the $Q_{\dots\max\text{DN}}$ value in the selected operating mode. If the flow rate is below the switching threshold, there is no flow measurement. The setting of 0 % deactivates the low flow cut-off.

## ... 9 Operation


### ... Parameter descriptions

#### Menu: Device Info



##### Note

This menu is only used to display the device parameters. The parameters are displayed independently of the configured access level, but cannot be changed.

Menu / parameter	Description
<b>Device Info</b>	
Sensor	Selection of submenu 'Sensor' using  .
Transmitter	Selection of submenu 'Transmitter' using  .

<b>Device Info / Sensor</b>	
Sensor Type	Displays the sensor type. <ul style="list-style-type: none"> <li>Swirl: Swirl flowmeters FSS430, FSS450</li> <li>Vortex: Vortex flowmeters FSV430, FSV450</li> </ul>
Meter(V) Size, Meter(S) Size	Displays the sensor nominal diameter.
QvMaxDN	Display of the maximum configurable upper range value for the respective operating mode. For information purposes only; the value cannot be changed – it is calculated from $Q_{...Max}DN$ for the respective medium and the set parameters such as density, pressure, or temperature.
QvpMaxDN	
QmMaxDN	
QnMaxDN	
QnpMaxDN	
QpowerMaxDN	
Sensor ID	Displays the ID number of the sensor.
SAP/ERP No.	Displays the order number of the sensor.
Sensor Run Hours	Displays the operating hours of the sensor.
<b>Calibration</b>	Selection of submenu 'Calibration' using  .

<b>Device Info / Sensor / Calibration</b>	
Cal. Date	Date of sensor calibration.
Cal. Cert. No.	Identification (no.) of the relevant calibration certificate.
Cal. Location	Location of sensor calibration.

<b>Device Info / Transmitter</b>	
Transmitter Type	Displays the transmitter type.
Transmitter ID	Displays the transmitter ID number.
SAP/ERP No.	Displays the order number of the transmitter.
<b>Transmitter Version</b>	Selection of submenu 'Transmitter Version' using  .
Transmitter Run Hours	Displays the operating hours of the transmitter.
<b>Calibration</b>	Selection of submenu 'Calibration' using  .
Manufacturer	Name of manufacturer.
Street	Address of manufacturer (street).
City	Address of manufacturer (city).
Phone	Telephone number of manufacturer.

Menu / parameter	Description
<b>Device Info / Transmitter / Transmitter Version</b>	
Transmitter FW Ver.	Displays the transmitter software version.
Transmitter HW Ver.	Displays the transmitter hardware version.
Frontend FW Version	Displays the sensor software version.
Frontend HW Version	Displays the sensor hardware version.
Bootloader Version	Displays the boot loader version.

**Note**






The firmware version specified on the name plate is a combination of the transmitter software version and the sensor software version.



Menu / parameter	Description
<b>Device Info / Transmitter / Calibration</b>	
Cal. Date	Date of transmitter calibration.
Cal. Cert. No.	Identification (no.) of the relevant calibration certificate.
Cal. Location	Location of transmitter calibration.

## ... 9 Operation

### ... Parameter descriptions

#### Menu: Device Setup

Menu / parameter	Description
<b>Device Setup</b>	
Access Control	Selection of submenu 'Access Control' using  .
Sensor	Selection of submenu 'Sensor' using  .
Transmitter	Selection of submenu 'Transmitter' using  .
Plant/Customized	Selection of submenu 'Plant/Customized' using  .
<b>Device Setup / Access Control</b>	
Standard Password	Entry / change of the password for the 'Standard' access level.
Read Only Switch	Display of switch position of the write protection switch (hardware write protection). See <b>DIP switch on the HART® communication board</b> on page 60 or <b>DIP switch on the Modbus communication board</b> on page 61.
<b>Device Setup / Sensor</b>	
QvMaxDN	Display of the maximum configurable upper range value for the respective operating mode. For information purposes only;
QvpMaxDN	the value cannot be changed – it is calculated from $Q_{...Max}DN$ for the respective medium and the set parameters such as
QmMaxDN	density, pressure, or temperature.
QnMaxDN	
QnpMaxDN	
QpowerMaxDN	
Qvmax	Setting of the flow rate or energy quantity at which the current output is to output 20 mA (100 %).
QvpMax	The value entered must be at least 15 % of $Q_{...max}DN$ .
QmMax	
QnMax	
QnpMax	
QpowerMax	
Sensor Location Tag	Enter the TAG number of the flowmeter sensor (shown in the upper left of the process display). Alphanumeric, maximum 20 characters.
Sensor TAG	Enter the TAG number for the measuring sensor. Alphanumeric, maximum 20 characters.
<b>Device Setup / Transmitter</b>	
Units	Selection of submenu '„Units“' using  .
Damping Qv	Setting of the damping (the value relates to 1 T [Tau]).
Damping Qnp	The value relates to a step change in the flow rate, energy quantity, or temperature.
Damping Qm	The value affects the instantaneous value in the process display and at the current output.
Damping Qn	Default setting: 1 second
Damping Qnp	
Damping Qpower	
Damping Temperature	
Low Flow Cutoff	Sets the switching threshold for the low flow cut-off. The set value relates to the $Q_{...max}DN$ value in the selected operating mode. If the flow rate is below the switching threshold, there is no flow measurement. The setting of 0 % deactivates the low flow cut-off.


Menu / parameter	Description
<b>Device Setup / Transmitter / Units</b>	
Unit Qv	Selection of unit for volume flow. m3/s, m3/min, m3/h, m3/Tag, ft3/s, ft3/min, ft3/h, ft3/Tag, l/s, l/min, l/h, l/Tag, kl/s, kl/min, kl/h, kl/Tag, us gal/s, us gal/min, us gal/h, us gal/Tag, imperial gal/s, imperial gal/min, imperial gal/h, imperial gal/day, barrel/s, barrels/min, barrel/h, barrels/day Factory setting: l/min
Unit Qm	Selection of unit for mass flow. g/s, g/min, g/h, kg/s, kg/min, kg/h, kg/day
Unit Qnv	Selection of unit for the standard volume flow. m3/s, m3/min, m3/h, m3/Tag, ft3/s, ft3/min, ft3/h, ft3/Tag, l/s, l/min, l/h, l/Tag, kl/s, kl/min, kl/h, kl/Tag, us gal/s, us gal/min, us gal/h, us gal/Tag, imperial gal/s, imperial gal/min, imperial gal/h, imperial gal/day, barrel/s, barrels/min, barrel/h, barrels/day Factory setting: l/min
Unit Qpower	Selection of unit for energy measurement. W, MW, KW, KJ/s, KJ/min, KJ/h, KJ/day, MJ/h
Unit Density	Selection of unit for density. kg/m3, g/cm3, kg/l, g/ml, g/l, lb/in, lb/ft3
Unit Temperature	Selection of unit for temperature. kelvin, celsius, fahrenheit
Unit Pressure	Selection of unit for pressure measurement. Pa, MPa, KPa, HPa, bar, mbar, psi, kg/cm3
Unit Volume	Selection of unit for the volume totalizer. m3, ft3, l, milli l, hecto l, imp gallon, us gallon, us barrels beer
Unit Mass	Selection of unit for the mass counter. g, kg, t, pounds, unze
Unit Std/Norm Vol.	Selection of unit for the standard volume totalizer. m3, ft3, l, milli l, hecto l, imp gallon, us gallon, us barrels beer
Unit Energy	Selection of unit for the energy counter. J, KJ, MJ, KWH
<b>Device Setup / Plant/Customized</b>	
Active Mode	Selection of operating mode (only for devices with HART® or Modbus® communication). See <b>Operating modes</b> on page 65 for further information.
Medium Type	Selection of the measuring medium (only for devices with PROFIBUS® or FOUNDATION Fieldbus® communication). <ul style="list-style-type: none"> <li>• Liquid: Liquid measuring media</li> <li>• Gas: Gaseous measuring media</li> <li>• Steam: Steam as a measuring medium</li> </ul>
Compensation Setting	Selection of submenu '„Compensation Setting“' using  .
Field optimization	Selection of submenu '„Field optimization' using  .

## ... 9 Operation

### ... Parameter descriptions

Menu / parameter	Description
<b>Device Setup / Plant/Customized / Compensation Setting</b>	
Liquid Mass Corr.	<p>Selection of the correction method for liquid mass measurement in operating mode 'Liquid Mass'.</p> <ul style="list-style-type: none"> <li>None: Liquid mass flow, based on direct determination of the operating density via analog input, HART input, or a constant preset value.</li> <li>Density Corr.: Liquid mass flow, based on density under reference conditions and density expansion coefficient.</li> <li>Volume Corr.: Liquid mass flow, based on density under reference conditions and volume expansion coefficient.</li> </ul> <p>See <b>Operating modes</b> on page 65 for further information.</p>
Volume Exp.Coef.	<p>Setting of the volume expansion coefficient.</p> <p>See <b>Operating modes</b> on page 65 for further information.</p>
Density Exp.Coef.	<p>Setting of the density expansion coefficient.</p> <p>See <b>Operating modes</b> on page 65 for further information.</p>
Specific Heat Capacity	<p>Setting of the calorific value for the measuring medium in operating mode 'Gas Power'.</p> <p>See <b>Operating modes</b> on page 65 for further information.</p>
Gas Density Selec.	<p>Selection of the density source for gas mass measurement in operating mode 'Gas Mass'.</p> <ul style="list-style-type: none"> <li>Ref. Density: Gas mass flow, calculated using pressure, temperature, and density under reference conditions.</li> <li>Act. Density: Gas mass flow, calculated using the current density in the operating condition.</li> </ul> <p>See <b>Operating modes</b> on page 65 for further information.</p>
Gas Ref. Conditions	<p>Selection of the reference pressure and reference temperature for determination of the standard condition.</p> <p>Possible selection: 14.7 psi, 60°F / 14.7 psi, 70°F / 1.013 bar, 0°C / 1.013 bar, 20°C</p>
Gas Std. Mode	<p>Selection of method for gas density calculation.</p> <ul style="list-style-type: none"> <li>Ideal Gas: Gas density calculation in accordance with the general gas law. The gases are regarded as "ideal gas".</li> <li>AGA8: Natural gas calculation in accordance with AGA8 (ISO12212-2).</li> <li>GERG88: Natural gas calculation in accordance with GERG88 (ISO12212-3).</li> </ul> <p>Refer to <b>Natural gas calculation in accordance with AGA8 / SGERG88</b> on page 78.</p>
Gas Energy Density	<p>Setting of the calorific value for gas in operating mode 'Gas Power'.</p> <p>See <b>Operating modes</b> on page 65 for further information.</p>
Water/Steam Type	<p>Selection of the medium type in the operating mode 'Steam/Water Mass'.</p> <ul style="list-style-type: none"> <li>Saturated Steam: Saturated steam.</li> <li>Overheated Steam: Overheated steam.</li> <li>Hot Water: Hot water.</li> </ul> <p>See <b>Operating modes</b> on page 65 and <b>Energy measurement for steam / hot water in accordance with IAPWS-IF97</b> on page 73 for additional information.</p>
Density Selection	<p>Selection of the steam density source in operating mode 'Steam/Water Mass'.</p> <ul style="list-style-type: none"> <li>Ext. Density: Remote density transmitter at HART or analog input.</li> <li>Calc. From P&amp;T: Calculation of the density for saturated steam and overheated steam using a remote pressure transmitter and the integrated temperature sensor.</li> <li>Calc. From T: Calculation of the density for saturated steam using the integrated temperature sensor.</li> <li>Calc. From P: Calculation of the density from the pressure only</li> </ul>
Energy calc. method	<p>Selection of the type of energy calculation in the operating mode Steam/Water Energy.</p> <ul style="list-style-type: none"> <li>Gross energy: The amount of energy that flows through the device is recorded. Any energy re-flow in form of condensate is not considered.</li> <li>Net energy: The amount of energy that flows through the device is recorded. Any energy re-flow in form of condensate is deducted again from the amount of energy.</li> </ul> <p>See <b>Operating modes</b> on page 65 and <b>Energy measurement for steam / hot water in accordance with IAPWS-IF97</b> on page 73 for additional information.</p>










Menu / parameter	Description
<b>Device Setup / Plant/Customized / Field optimization</b>	
Ref. Density	Setting of the standard density of the measuring medium.
Preset Density	Setting of the density (operating density) of the measuring medium as a constant.
Ref. Temperature	Setting of the reference temperature.
Preset Int.Temp	Setting of the measuring medium temperature as a constant. The value entered must correspond as closely as possible to the temperature of the measuring medium in the meter tube.
Preset Ext.Temp	Adjustment of the return flow temperature as constant for the calculation of net energy consumption.
Preset Pressure(abs)	Setting of the measuring medium pressure as a constant.
Preset Gas Content	Setting of the methane content as a constant.
Dynamic Viscosity	Setting of the dynamic viscosity of the measuring medium.
Temperature Offset	<p>Setting of the offset correction for the internal temperature measurement.</p> <p>Any deviation between the internal temperature measurement and an external temperature measurement can be corrected here. When doing this, the correction value must be offset against the existing balancing value.</p> <p>The correction can significantly improve accuracy; e.g. for a saturated steam measurement that does not take pressure into account.</p> <p>The temperature sensor is factory-calibrated at 22 to 28 °C. At operating temperatures significantly outside of this range, errors of up to <math>\pm 2</math> K can occur, which can be corrected under operating conditions.</p>
Auto Zero	<p>Starts the automatic zero point balancing using .</p> <p><b>NOTICE</b></p> <p>Prior to starting the zero point adjustment, make sure that:</p> <ul style="list-style-type: none"> <li>• There is no flow through the sensor (close all valves, shut-off devices etc.)</li> <li>• The sensor must be filled completely with measuring medium for measurement.</li> <li>• The adjustment process takes approximately 45 seconds.</li> <li>• If automatic zero point balancing does not yield the desired results, see chapter <b>Zero point balance under operating conditions</b> on page 130.</li> </ul>
Auto Zero status	<p>Display of whether automatic zero point balancing has been performed.</p> <p>If the zero point is not stable (flow indicator for zero flow), automatic balancing must be performed.</p>
Low Flow Thld.	<p>Setting of manual zero point balancing. The higher the value entered, the <b>lower</b> the sensitivity of the sensor.</p> <p>Setting range: 7 to 2000.</p> <p>See <b>Zero point balance under operating conditions</b> on page 130.</p>




## ... 9 Operation

### ... Parameter descriptions

#### Menu: Display

Menu / parameter	Description
<b>Display</b>	
Language	Selection of menu language.
Contrast	Contrast setting for the LCD display.
<b>Operator Pages</b>	Selection of submenu 'Operator Pages' using  . Up to four user-specific operator pages (layouts) can be configured for the process display. If multiple operator pages have been configured, these can be scrolled through manually on the information level. In the factory setting only Operator Page 1 is enabled.
Autoscroll	If Multiplex operation is enabled, you can also activate the 'Autoscroll' function on the information level of the operator menu. In this function, operator pages are automatically displayed in succession on the process screen, changing every 10 seconds. Manual scrolling through pre-configured operator pages as described above is no longer necessary. When Auto scroll mode is enabled, the icon  is displayed in the lower left corner of the screen.
Flowrate Format	Selection of number of decimal places (maximum 12) used to display the corresponding process variables.
Totalizer Format	
Date/Time Format	Set the display format for the date and time.
Display Test	Start the test of the LCD display with  .
<b>Display / Operator Pages</b>	
Operator Page 1	Selection of submenu 'Operator Page 1' using  .
Operator Page 2	Selection of submenu 'Operator Page 2' using  .
Operator Page 3	Selection of submenu 'Operator Page 3' using  .
Operator Page 4	Selection of submenu 'Operator Page 4' using  .
<b>Display / Operator Pages / Operator Page 1 ... n</b>	
Display Mode	Configure each operator page. The following versions can be selected: Off, Graph Format, 1x4, 1x6, 1x6 bar, 1x6, 1x6 bar, 1x9, 1x9 bar, 2x9, 2x9 bar, 3x9, 4x9. Selecting 'Off' deactivates the corresponding operator page.
1st Line	Selection of process variable displayed in the respective row.
2nd Line	
3rd Line	
Bargraph	Selection of process variable displayed as a bar graph.

**Menu: Input/Output**




Menu / parameter	Description
<b>Input/Output</b>	
<b>Current Out</b>	Selection of submenu 'Current Out' using  .
<b>DO Function</b>	Selection of submenu 'DO Function' using  .
<b>Field Input</b>	Selection of submenu 'Field Input' using  .

**Input/Output / Current Out**

<b>Output Value</b>	Selection of the process variable issued at the current output. <ul style="list-style-type: none"> <li>• Q: Flow</li> <li>• T: Temperature</li> </ul>
<b>Qv-&gt;I=100%</b>	Setting of the flow rate at which the current output is to output 20 mA (100 %).
<b>Qvp-&gt;I=100%</b>	The value range depends on the nominal diameter of the sensor and the operating mode selected.
<b>Qn-&gt;I=100%</b>	Parameters will be displayed only if 'Q: Flow' has been selected for parameter 'Output Value'.
<b>Qnp-&gt;I=100%</b>	
<b>Qm-&gt;I=100%</b>	
<b>Qpower-&gt;I=100%</b>	
<b>Temp-&gt;I=100%</b>	Setting of the temperature limits at which the current output is to output 4 mA or 20 mA.
<b>Temp-&gt;I=0%</b>	Parameters will be displayed only if 'T: Temperature' has been selected for parameter 'Output Value'.
<b>Out at Alarm</b>	Selection of status of the current output in error condition. The output 'high' or 'low' current is set in the subsequent menu.
<b>Low Alarm Value</b>	Sets the current for Low Alarm.
<b>High Alarm Value</b>	Sets the current for High Alarm.
<b>Out at Flow&gt;103%</b>	Select the status of the current output when the upper range value is up-scaled. <ul style="list-style-type: none"> <li>• Off: Error is not output through the current output.</li> <li>• High Alarm: The current output assumes the value for 'High Alarm'. The current output is 'frozen' at 20.5 mA and returns to the regular range once it falls below the upper range value.</li> <li>• Low Alarm: The current output assumes the value for 'Low Alarm'.</li> </ul>

**Input/Output / DO Function**

Not for devices with FOUNDATION Fieldbus® communication!

<b>Function</b>	Selection of the function for the digital output. <ul style="list-style-type: none"> <li>• None: Digital output deactivated.</li> <li>• Logic on DO: Digital output as a binary output (e.g. as an alarm output).</li> <li>• Pulse on DO: Digital output DO1 as a pulse output. In pulse mode, pulses are output per unit (e.g. 1 pulse per m3)</li> <li>• Freq on DO: Digital output DO1 as a frequency output. In frequency mode, a frequency is issued that is proportional to the flow rate. The maximum frequency can be configured in accordance with the upper range value.</li> </ul>
<b>Setup Pulse Out</b>	Selection of submenu 'Setup Pulse Out' using  .
<b>Setup Freq Out</b>	Selection of submenu 'Setup Freq Out' using  .
<b>Alarm Config</b>	Selection of submenu 'Alarm Config' using  .
<b>Logic on DO</b>	Select switching properties for the binary output. <ul style="list-style-type: none"> <li>• Normally Closed: Binary output to open a normally closed contact.</li> <li>• Normally Open: Binary output to close a normally open contact.</li> </ul>

## ... 9 Operation

### ... Parameter descriptions




Menu / parameter	Description
<b>Input/Output / DO Function / Setup Pulse Out</b>	
Pulses Per Unit	Setting of the pulses per unit of the selected operating mode and pulse width for the 'Pulse on DO' function of the digital output.
Pulse Width	<p>The pulse value relates to the set flow unit, not the totalizer unit.</p> <p>For the kW energy unit (1 kW = 1 kJ/s), the pulse output automatically refers to kJ, meaning that a pulse value of 1 would lead to 1 pulse per second at an energy flow of 1 kW. The maximum frequency of the pulse output is 10 kHz. The device automatically calculates the max. pulse width using <math>Q_{max}</math> and the pulse value. The pulse length and pulse pause are considered to be equal, with a safety factor of 1.1.</p> <p>Available only if the digital output has been configured as a pulse output.</p>
<b>Input/Output / DO Function / Setup Freq Out</b>	
Lower Frequency	Setting of the frequency range for the 'Freq on DO' function of the digital output Available only if the digital output has been configured as a frequency output.
Upper Frequency	
<b>Input/Output / DO Function / Alarm Config</b>	
General Alarm	Each alarm can be activated separately. This allows for individual configuration when the digital output signals an alarm.
Min Flowrate Alarm	
Max Flowrate Alarm	
Min Sensor T Alarm	
Max Sensor T Alarm	
Flow Cutoff Alarm	
<b>Input/Output / Field Input</b>	
Analog In Value	<p>Selection of the process variable measured via the analog input.</p> <ul style="list-style-type: none"> <li>• None: No remote transmitter at the input.</li> <li>• Temperature: Remote temperature transmitter at the input (transmitter in the reverse flow of a heating or cooling cycle for net energy calculation or transmitter in the device outlet (see <b>Installation for external pressure and temperature measurement</b> on page 34) for temperature compensation, if no internal temperature measurement is possible / desired).</li> <li>• Pressure: Remote pressure transmitter at the input.</li> <li>• Pressure(abs): Remote absolute pressure transmitter at the input.</li> <li>• Gas Content: Remote gas analyzer at the input.</li> <li>• Density: Remote transmitter at the input.</li> <li>• Int.T: External temperature transmitter, e.g. for using a remote temperature transmitter instead of the internal temperature sensor to increase the accuracy or reduce the response time.</li> </ul> <p>Refer to <b>Analog input 4 to 20 mA</b> on page 47.</p>

Menu / parameter	Description
<b>Input/Output / Field Input (continued)</b>	
T Ext. Upper Range	Setting of the measuring range limits for the external transmitter at the analog input.
T Ext. Lower Range	The upper value applies for a current of 20 mA at the analog input, the lower value for a current of 4 mA.
T Int. Upper Range	The availability of this parameter depends on the process variable selected for the analog input.
T Int. Lower Range	
Pressure Upper Range	
Pressure Lower Range	
P(abs) Upper Range	
P(abs) Lower Range	
Density Upper Range	
Density Lower Range	
Gas% Upper Range	
Gas% Lower Range	
Ext.Cutoff Trigger	Selection of the switching point for externally switching off the output via the analog input. If the switching point is exceeded, the flow measurement is set to zero. Possible switching points: > 4 mA, > 8 mA, > 12 mA
HART In Value	Selection of the process variable measured via the HART input. For description, see parameter 'Analog In Value'. Refer to <b>HART® communication with remote transmitter</b> on page 47.


## ... 9 Operation

### ... Parameter descriptions

#### Menu: Process Alarm

Menu / parameter	Description
<b>Process Alarm</b>	
Diagnostic History	Display of the alarm history.
Clear History	Reset of the alarm history.
<b>Group Masking</b>	Selection of submenu ' <b>Group Masking</b> ' using  .
<b>Individual Masking</b>	Selection of submenu ' <b>Individual Masking</b> ' using  .
<b>Alarm Limits</b>	Selection of submenu ' <b>Alarm Limits</b> ' using  .
<b>Process Alarm / Group Masking</b>	
Maintenance Required	Alarm messages are divided into groups.
Function Check	If masking is activated for a group (On), no alarm is issued.
Out Of Specification	For more detailed information, see <b>Diagnosis / error messages</b> on page 131.
<b>Process Alarm / Individual Masking</b>	
Min Flowrate Alarm	Individual alarm messages can also be masked. These are not included in the masking for the group. If masking is activated
Max Flowrate Alarm	for an alarm (On), no alarm occurs.
Flow > 103%	For more detailed information, see <b>Diagnosis / error messages</b> on page 131.
Flow Cutoff Alarm	There are no alarms masked by default.
Int. T Sensor Fault	
Medium Temp OffSpec.	
Housing Temp OffSpec.	
<b>Process Alarm / Alarm Limits</b>	
Min Qv Alarm	Sets the minimum / maximum limit value for volume measurement. If the volume flow exceeds or falls below the limit
Max Qv Alarm	values, an alarm is triggered.
Min Qm Alarm	Sets the minimum / maximum limit value for mass measurement. If the mass flow up-scales or down-scales the limit values,
Max Qm Alarm	an alarm is triggered.
Min Temp.Alarm	Sets the minimum / maximum limit value for temperature measurement. If the measuring medium temperature exceeds or
Max Temp.Alarm	falls below the limit values, an alarm is triggered.
Min P(abs) Alarm	Sets the minimum / maximum limit value for pressure measurement. If the pressure exceeds or falls below the limit values,
Max P(abs) Alarm	an alarm is triggered.
Min Re Alarm	Setting of the minimum / maximum limit values for the Reynolds number (Re). If the Reynolds number (Re) exceeds or falls
	below the limit values, an alarm is triggered.
No HART Input Alarm	Setting of the delay time in seconds for error message 'No HART Burst In' if the external HART input has been activated.
	Value range: 5 to 10800 seconds (3 hours)



**Menu: Communication for devices with HART® communication**

Menu / parameter	Description
<b>Communication</b>	
HART	Selection of submenu 'HART' using  .
<b>Communication / HART</b>	
Device Address	Selection of HART device address. <b>Note</b> The HART protocol has provisions for creating a bus with up to 15 devices (1 to 15)). If an address greater than 0 is set, the device operates in multidrop mode. The current output is then fixed at 4 mA. Apart from that, the current output is only used for HART communication.
Tag	Entry of a HART TAG number as unique identifier for the device. Alphanumeric, a maximum of 8 characters, upper case only, no special characters.
Descriptor	Entry of a HART descriptor. Alphanumeric, a maximum of 16 characters, upper case only, no special characters.
Message	Display of the alphanumeric TAG number.
Manuf. ID	Display of the HART manufacturer ID. ABB = 26
Device ID	Display of the HART device ID.
Last Command	Display of the most recently sent HART command.

## ... 9 Operation






### ... Parameter descriptions

#### Menu: Communication for devices with Modbus® communication

Menu / parameter	Description
<b>Communication</b>	
<b>Service Port</b>	Selection of submenu 'Service Port' using  .
<b>MODBUS</b>	Selection of submenu 'MODBUS' using  .
<b>Communication / Service Port</b>	
Baud Rate	Selection of the transmission speed (baud rate) for the service port. Factory setting: 9600 bd.
<b>Communication / MODBUS</b>	
Address	Setting of the Modbus device address. Setting range: 1 to 247. Factory setting: 247
Baud Rate	Selection of the transmission speed (bit rate) for the Modbus communication. <ul style="list-style-type: none"> <li>• 1200 bps</li> <li>• 2400 bps</li> <li>• 4800 bps</li> <li>• 9600 bps</li> </ul> Factory setting: 9600 bps
Parity	Selection of the parity for the Modbus communication. <ul style="list-style-type: none"> <li>• NULL</li> <li>• Even</li> <li>• Odd</li> </ul> Factory setting: NULL
RespDelayTime	Setting of the pause time in milliseconds after receiving a Modbus command. The device sends a response no earlier than expiration of the set pause time. Setting range: 0 to 200 ms Factory setting: 50 ms
Address Offset	Selection of the address offset for the Modbus address (PLC Base 0 or PLC Base 1). In the Modbus protocol, there are two options for register addressing. Depending on the manufacturer, the start address of the register is defined as '0' (e.g. 40000) or '1' (e.g. 40001). <ul style="list-style-type: none"> <li>• Zero Base: Modbus addresses PLC Base 0</li> <li>• One Base: Modbus addresses PLC Base 1</li> </ul> Factory setting: One Base



**Menu: Communication for devices with PROFIBUS PA® communication**

Menu / parameter	Description
<b>Communication</b>	
...PROFIBUS	Selection of submenu ' <b>PROFIBUS</b> ' using  .
<b>Communication / PROFIBUS</b>	
Tag	Entry of a unique PROFIBUS TAG number as an identifier for the device. Alphanumeric, a maximum of 8 characters, upper case only, no special characters.
Device Adresse	Setting the PROFIBUS PA device address (1 to 126).
IdentNr Selector	Selecting the PROFIBUS PA identification number
<b>AI1 Block</b>	Selection of submenu ' <b>AI1 Block, AI2 Block, AI3 Block</b> ' using  .
<b>AI2 Block</b>	
<b>AI3 Block</b>	
<b>TOT1 Block</b>	Selection of submenu ' <b>TOT1 Block, TOT2 Block, TOT3 Block</b> ' using  .
<b>TOT2 Block</b>	
<b>TOT3 Block</b>	
<b>DI Block</b>	Selection of submenu ' <b>DI Block</b> ' using  .
<b>AO1 Block</b>	Selection of submenu ' <b>AO1 Block, AO2 Block, AO3 Block</b> ' using  .
<b>AO2 Block</b>	
<b>AO3 Block</b>	
Service Port Config	Selection of the transmission speed (baud rate) for the service port. Factory setting: 9600 bd.
<b>Communication / PROFIBUS / AI1 Block</b>	
<b>Communication / PROFIBUS / AI2 Block</b>	
<b>Communication / PROFIBUS / AI3 Block</b>	
Tag	Entry of a name for the respective AI input block. Alphanumeric, a maximum of 8 characters, upper case only, no special characters.
Channel	Display of the process variables assigned to the respective AI input blocks.*
PV Time	Damping of the output signal
<b>Communication / PROFIBUS / TOT1 Block</b>	
<b>Communication / PROFIBUS / TOT2 Block</b>	
<b>Communication / PROFIBUS / TOT3 Block</b>	
Tag	Entry of a name for the respective TOT output block. Alphanumeric, a maximum of 8 characters, upper case only, no special characters.
Channel	Display of the process variables assigned to the respective TOT output blocks.*

\* The process variables are assigned to the blocks via the control system during commissioning.

## ... 9 Operation

### ... Parameter descriptions

Menu / parameter	Description
<b>Communication / PROFIBUS / DI Block</b>	
Tag	Entry of a name for the respective DI input block. Alphanumeric, a maximum of 8 characters, upper case only, no special characters.
Channel	Display of the DI input block function.* <ul style="list-style-type: none"> <li>• Output deactivation: remote output deactivation through the DI input block, sets the flow measurement to 0.</li> <li>• Low flow: Remote low flow volume deactivation through the DI input block</li> </ul>

#### Communication / PROFIBUS / AO1 Block





#### Communication / PROFIBUS / AO2 Block

#### Communication / PROFIBUS / AO3 Block

Tag	Entry of a name for the respective AO output block. Alphanumeric, a maximum of 8 characters, upper case only, no special characters.
Channel	Display of the process variables assigned to the respective AO output blocks.* <ul style="list-style-type: none"> <li>• Temperature: Output of the temperature of the internal temperature sensor.</li> <li>• Temperature 2: Output of the temperature of the remote temperature sensor.</li> <li>• Pressure: Output of the measured value of the remote pressure transmitter</li> <li>• Pressure(abs): Output of the measured value of the remote pressure transmitter (absolute pressure)</li> <li>• Density: Output of the density.</li> <li>• Gas Content: Output of the gas proportion</li> </ul>

\* The process variables and functions are assigned to the blocks via the control system during commissioning.

**Menu: Communication for devices with FOUNDATION Fieldbus® communication**

Menu / parameter	Description
<b>Communication</b>	
<b>Fieldbus FF</b>	Selection of the 'Fieldbus FF' submenu using  .
<b>Communication / Fieldbus FF</b>	
Tag	Entry of a unique FOUNDATION Fieldbus TAG number as an identifier for the device. Alphanumeric, a maximum of 8 characters, upper case only, no special characters.
Device Adresse	Setting the FOUNDATION Fieldbus device address (1 to 126).
Device Boot Type	Selection of the FOUNDATION Fieldbus operating mode. <ul style="list-style-type: none"> <li>• Basic: Operation of the device as a 'basic device'.</li> <li>• Link Master: Operation of the device as a 'Link Master'.</li> </ul>
DD Revision	Selection of the FOUNDATION Fieldbus DD Revision.
<b>AI1 Block</b>	Selection of submenu ' <b>AI1 Block, AI2 Block, AI3 Block</b> ' using  .
<b>AI2 Block</b>	
<b>AI3 Block</b>	
<b>DI Block</b>	Selection of submenu ' <b>DI Block</b> ' using  .
<b>AO1 Block</b>	Selection of submenu ' <b>AO1 Block, AO2 Block, AO3 Block</b> ' using  .
<b>AO2 Block</b>	
<b>AO3 Block</b>	
Service Port Config	Selection of the transmission speed (baud rate) for the service port. Factory setting: 9600 bd.

**Communication / Fieldbus FF / AI1 Block****Communication / Fieldbus FF / AI2 Block****Communication / Fieldbus FF / AI3 Block**

Tag	Entry of a name for the respective AI input block. Alphanumeric, a maximum of 8 characters, upper case only, no special characters.
Channel	Display of the process variables assigned to the respective AI input blocks.*
PV Time	Damping of the output signal

\* The process variables are assigned to the blocks via the control system during commissioning.

## ... 9 Operation

### ... Parameter descriptions

Menu / parameter	Description
<b>Communication / Fieldbus FF / DI Block</b>	
Tag	Entry of a name for the respective DI input block. Alphanumeric, a maximum of 8 characters, upper case only, no special characters.
Channel	Display of the DI input block function.* <ul style="list-style-type: none"> <li>• Output deactivation: remote output deactivation through the DI input block, sets the flow measurement to 0.</li> <li>• Low flow: Remote low flow volume deactivation through the DI input block</li> </ul>

#### Communication / Fieldbus FF / AO1 Block






#### Communication / Fieldbus FF / AO2 Block

#### Communication / Fieldbus FF / AO3 Block


Tag	Entry of a name for the respective AO output block. Alphanumeric, a maximum of 8 characters, upper case only, no special characters.
Channel	Display of the process variables assigned to the respective AO output blocks.* <ul style="list-style-type: none"> <li>• Temperature: Output of the temperature of the internal temperature sensor.</li> <li>• Temperature 2: Output of the temperature of the remote temperature sensor.</li> <li>• Pressure: Output of the measured value of the remote pressure transmitter</li> <li>• Pressure(abs): Output of the measured value of the remote pressure transmitter (absolute pressure)</li> <li>• Density: Output of the density.</li> <li>• Gas Content: Output of the gas proportion</li> </ul>

\* The process variables and functions are assigned to the blocks via the control system during commissioning.

**Menu: Diagnostics**

Menu / parameter	Description
<b>Diagnostics</b>	
<b>Diagnosis Control</b>	Selection of submenu ' <b>Diagnosis Control</b> ' using  .
<b>Diagnosis Values</b>	Selection of submenu ' <b>Diagnosis Values</b> ' using  .
<b>Simulation Mode</b>	Selection of submenu ' <b>Simulation Mode</b> ' using  .
<b>Output Readings</b>	Selection of submenu ' <b>Output Readings</b> ' using  .
<b>Alarm Simulation</b>	Selection of submenu ' <b>Alarm Simulation</b> ' using  .

**Diagnostics / Diagnosis Control**

Sensor Self Check	Start of sensor self-test using  . The device runs a self-test of the Piezo sensor and PT100 temperature sensor for wire breaks or short-circuits. Any errors detected will immediately trigger a corresponding error message. Refer to <b>Possible error messages</b> on page 133.
Maintenance Cycle	Sets the service interval. After the maintenance interval has expired, the corresponding error message 'Maintenance Warning' is set. The setting '0' deactivates the maintenance interval.

**Diagnostics / Diagnosis Values**

Reynolds Number	Display of the current Reynolds number (Re).
Ext. Temperature	Display of the current measuring medium temperature.
Housing Temperature	Display of the current housing temperature in °C.
AI Value	Display of the current measured value at the analog input.

**Diagnostics / Simulation Mode**



Off	Manual simulation of measured values. After selecting the value to be simulated, a corresponding parameter is displayed in the menu 'Diagnostics / Simulation Mode'. The simulation value can be set here.
Volume Flow Unit	The output values correspond to the simulated flowrate entered.
Volume Flow	Information 'Configuration' appears in the lower line of the display.
Volume Flow[%]	Only one measured value / output can be selected for simulation.
Mass Flow Unit	After power-up / restart of the device, the simulation is switched off.
Mass Flow	
Mass Flow[%]	
Temperature Unit	
Medium Temperature	
Housing Temperature	
Current Out	
Freq on DO	
Logic on DO	
Pulse on DO	
AI Value	
Sensor Freq	

## ... 9 Operation

### ... Parameter descriptions

Menu / parameter	Description
<b>Diagnostics / Output Readings</b>	
Current Out	Display the current values and statuses of the listed inputs and outputs.
DO Pulse	
DO Frequency	
DO State	
<b>Diagnostics / Alarm Simulation</b>	
Manual simulation of alarms / error messages.	
The simulated alarm is selected by setting the parameter to the corresponding error.	
Refer to <b>Diagnosis / error messages</b> on page 131.	
The following error messages can be simulated:	
Off, sim. current output, sim. switch output, Sig. Sensor Fault, Int. T Sensor Fault, Vbr.Sensor Fault, AI Out of Range, Max Flowrate Alarm, Max Int. Temp Alarm, AI Cut Off, Max Pressure Alarm, Min Flowrate Alarm, Min Int. Temp Alarm, Current Output Saturated, Min Pressure Alarm, Bad SNR , Sensor NV Error, Sensor Not Calibrated, Sync. Signal Error, Sensor Comm Error, Transmitter NV Error, AI Comm Error, Pulse Output Cutoff, Re. Out of Range, Wrong Steam Type, Maintenance Warning, Voltage Warning, Min Housing T Alarm, Flowrate Cutoff, Flowrate > 103%, Data Simulation, Alarm Simulation, Fixed Current Output, Current Output Fault , CO Readback High, CO Readback Low, NV Replace Warning, Sensor RAM Fault, Totalizer Stop, Totalizer Reset, No HART Burst In.	

**Menu: Totalizer**

Menu / parameter	Description
<b>Totalizer</b>	
<b>Start</b>	Selection of submenu <b>'Start'</b> using  .
<b>Stop</b>	Selection of submenu <b>'Stop'</b> using  .
<b>Reset</b>	Selection of submenu <b>'Reset'</b> using  .
<b>Preset</b>	Selection of submenu <b>'Preset'</b> using  .

**Totalizer / Start**

All Totalizers	Starts all counters.
Act.Volume Totalizer	Starts the selected counters.
Std.Volume Totalizer	
Mass Totalizer	
Energy Totalizer	
Net Act.Vol.Totalizer	
Net Std.Vol.Totalizer	



**Totalizer / Stop**

All Totalizers	Stops all counters.
Act.Volume Totalizer	Stops the selected counters.
Std.Volume Totalizer	
Mass Totalizer	
Energy Totalizer	
Net Act.Vol.Totalizer	
Net Std.Vol.Totalizer	

**Totalizer / Reset**

All Totalizers	Resets all counters.
Act.Volume Totalizer	Resets the selected counters.
Std.Volume Totalizer	
Mass Totalizer	
Energy Totalizer	
Net Act.Vol.Totalizer	
Net Std.Vol.Totalizer	

**Totalizer / Preset**

<b>Enter Preset Value</b>	Selection of submenu <b>'Enter Preset Value'</b> using  .
<b>Set To Preset Value</b>	Selection of submenu <b>'Set To Preset Value'</b> using  .

## ... 9 Operation

### ... Parameter descriptions

Menu / parameter	Description
<b>Totalizer / Preset / Enter Preset Value</b>	
Act.Volume Totalizer	Input from meter readings (e.g. when replacing the transmitter).
Std.Volume Totalizer	
Mass Totalizer	
Energy Totalizer	
Net Act.Vol.Totalizer	
Net Std.Vol.Totalizer	

<b>Totalizer / Preset / Set To Preset Value</b>	
Act.Volume Totalizer	Sets the counters to the values entered under 'Totalizer / Preset / Enter Preset Value'.
Std.Volume Totalizer	
Mass Totalizer	
Energy Totalizer	
Net Act.Vol.Totalizer	
Net Std.Vol.Totalizer	

#### Counter overflow

All counters count up to 10 million (in the selected totalizer unit). After a value of 10 million is reached, the corresponding overflow counter is incremented by one and the totalizer value is reset to zero to continue counting the flow.

To indicate in the process display that an overflow has occurred, a corresponding warning is displayed on the LCD indicator.

Threshold for counter overflow = 10,000,000 Kg (m<sup>3</sup> or KJ)

Counter reading = Current counter reading + (number of counter overflows × 10,000,000)



## Software history

In accordance with NAMUR recommendation NE53, ABB offers a transparent and traceable software history.

### Standard and HART® Version

Firmware version (name plate)	Transmitter firmware version	Sensor firmware version	Date	Type of change	Associated operating instruction
01.00.00	01.03.00	01.04.00	06.2014	New release	OI/FSS/FSV430/450 Rev. B
02.00.00	01.04.00	01.04.02	11.2015	Supplement to the hot water calculation, SIL introduction	OI/FSS/FSV430/450 Rev. D
02.00.01	01.04.00	01.04.03	03.2018	Improvement of signal stability	OI/FSS/FSV430/450 Rev. D
02.01.00	01.05.00	01.04.03	05.2018	Update of steam calculation	OI/FSS/FSV430/450 Rev. E
02.01.01	01.05.00	01.04.04	09.2018	Improvement of filter settings	OI/FFS/FSV430/450 Rev.E
02.02.00	02.00.00	01.04.04	11.2019	Improvement of the stability of the analog input	OI/FFS/FSV430/450 Rev.F

### Modbus® Version

Firmware version (name plate)	Transmitter firmware version	Sensor firmware version	Date	Type of change	Associated operating instruction
01.00.00	01.00.00	01.04.00	10.2015	New release	OI/FSS/FSV430/450 Rev. C
01.00.01	01.00.00	01.04.03	03.2018	Improvement of signal stability	OI/FSS/FSV430/450 Rev. D
01.00.02	01.00.02	01.04.04	11.2019	Bug fixing, improvement of filter settings	OI/FFS/FSV430/450 Rev.F

### PROFIBUS PA® Version

Firmware version (name plate)	Transmitter firmware version	Sensor firmware version	Date	Type of change	Associated operating instruction
01.00.06	01.00.06	01.04.03	07.2018	New release	OI/FSS/FSV430/450 Rev. E
01.00.08	01.00.08	01.04.04	04.2020	Bug fixing, improvement of filter settings	OI/FFS/FSV430/450 Rev.F

### FOUNDATION Fieldbus® Version

Firmware version (name plate)	Transmitter firmware version	Sensor firmware version	Date	Type of change	Associated operating instruction
01.00.06	01.00.06	01.04.03	07.2018	New release	OI/FSS/FSV430/450 Rev. E
01.00.08	01.00.08	01.04.04	04.2020	Bug fixing, improvement of filter settings	OI/FFS/FSV430/450 Rev.F

## ... 9 Operation

### Zero point balance under operating conditions

#### Automatic zero point balancing

With automatic zero point balancing, the transmitter determines the noise threshold of the sensor signal automatically. As long as the sensor signal remains above the determined noise threshold, this is recognized as a valid flow signal.

Automatic zero point balancing should be rerun in the event of the following changes:

- Change in external installation conditions, such as more or fewer vibrations, pulsations, or electromagnetic field interspersions.
- Replacement of the communication board in the transmitter.
- Replacement of the sensor or sensor electronics.

For zero point balancing, the conditions in the meter tube have to correspond to the operating conditions for zero flow.

Automatic zero point balancing is started in the 'Device Setup / Plant/Customized / Field optimization / Auto Zero' menu.

#### Note

If the results of automatic zero point balancing are not acceptable, manual zero point balancing can be performed.

#### Manual zero point balancing

For manual zero point balancing, the noise threshold of the sensor signal must be determined manually. The same requirements apply for manual zero point balancing as for automatic zero point balancing.

1. Read out the signal amplitude of the source of interference in the 'Service / Sensor / Sig. Amplitude' menu. Note down the maximum value of the signal amplitude.
2. Multiply the calculated maximum value by a safety factor of between 1.2 and 2.0. Experience has shown that a value of 1.7 yields very good results.
3. Enter the calculated value in the 'Device Setup / Field optimization / Low Flow Thld.' menu.
4. Check the zero point setting in the process display / at the current output.
5. Check whether the lowest desired lower range value can be achieved with the new zero point setting.

#### Note

Zero point settings > 200 indicate an elevated potential for interference (vibrations, pulsations or EMC interference). The installation location and installation of the device should therefore be checked and appropriate measures taken, if necessary, to eliminate interference.

## 10 Diagnosis / error messages

### General Notes

The following checks should be performed whenever a malfunction occurs. This will help to isolate and remedy the cause of the malfunction.

#### Sensor

Check the following:

- Has the device been installed in accordance with the installation conditions?
- Have the nominal diameter and measuring range been selected in accordance with the application?
- Does the flow direction correspond to the direction indicated on the device?
- Have the electrical connections been completed correctly?
- Run the device self-test in the 'Diagnostics / Diagnosis Control / Sensor Self Check' menu. Take note of any error messages.

#### Application conditions

Check the following:

- Do the density and viscosity of the measuring medium correspond to the requirements of the selected nominal diameter of the device?
- Is the measuring medium a multiphase medium?
- Gas inclusions in liquid measuring media and condensate in gaseous measuring media can cause significant measuring errors. Multiphase media should therefore be avoided.

#### Zero point balancing

Complete zero point balancing in accordance with **Zero point balance under operating conditions** on page 130.

#### Pipe vibrations

Please observe the following points:

- Take appropriate measures to dampen pipe vibrations at the sensor inlet and outlet.
- Take suitable measures to dampen vibrations in the kHz range, which are transferred by brackets, for example.

#### Transmitter

Check the following:

- Check the supply voltage at the transmitter terminals. Check the length of the power supply cable, see **Current output / HART output** on page 46.
- Make sure the transmitter unit is seated correctly. Check the transmitter plug connectors for damage.
- Check the following parameters in the order specified.
  - Sensor Type: Swirl or Vortex (in accordance with the name plate).
  - Meter(V) Size: Nominal diameter of the device (in accordance with the name plate).
  - Active Mode / Medium Type: Corresponds to the application.
- Make sure the electrical connections of the device are correct.
- The sensor, transmitter and power supply for the device should be connected to the same potential, if possible.
- The signal cable for the remote mount design must not be exposed to strong magnetic fields.


## ... 10Diagnosis / error messages

### Calling up the error description


Additional details about the error that has occurred can be called up on the information level.



1. Use to switch to the information level (Operator Menu).



2. Use / to select the submenu 'Diagnostics'.
3. Confirm the selection with .



The error message is shown on the display according to priority.

The first line shows the area in which the error has occurred.

The second line shows the unique error number. It is made up of the priority (Fxxx) and the error position (.xxx)

The next lines show a brief description of the error and information on how to remedy it.

You absolutely need to scroll the display further to read the error message in more detail.

#### Note

For a detailed description of the error messages and information on troubleshooting, see the following pages.

## Possible error messages

The error messages are divided into four groups in accordance with the NAMUR classification scheme. Depending on the model variant, not all error messages are always available.

### Errors

Error no. / Range		Text on the LCD display	Cause	Remedy
HART / Modbus	PA / FF			
F217.041 / Electronics*	—	CO Readback High	Incorrectly calibrated current output or faulty electronics.	Contact ABB Service.
F216.042 / Electronics*	—	CO Readback Low	Incorrectly calibrated current output or faulty electronics.	Contact ABB Service.
F215.020 / Electronics	F215.001 / Electronics	Sensor Comm Error	Communication errors between sensor and transmitter.	Check electrical connections between sensor and transmitter.
F214.019 / Electronics	F214.002 / Sensor	Sync. Signal Error	Error in SensorMemory.	Switch transmitter off and back on again. If the error remains, contact ABB Service.
F213.000 / Sensor	F213.003 / Sensor	Sig. Sensor Fault	Errors in sensor self-test. Signal errors from Piezo sensor.	Contact ABB Service.
F212.001 / Sensor*	F212.004 / Sensor	Int. T Sensor Fault	Errors in internal temperature sensor.	Contact ABB Service.
F211.002 / Sensor	F211.005 / Sensor	Vbr.Sensor Fault	Errors in sensor self-test. Signal errors from Piezo sensor.	Contact ABB Service.
F210.016 / Electronics	F210.006 / Electronics	Bad SNR	Signal-to-noise ratio for the sensor signal is outside of the set limit values.	Increase the flow rate. Check the setting in the 'Process Alarm / Alarm Limits' menu and adjust if necessary.
F209.017 / Electronics	F209.007 / Electronics	Sensor NV Error	Faulty transmitter electronics.	Replace transmitter electronics or contact ABB Service.
F208.044 / Electronics	F207.008 / Electronics	Sensor RAM Fault	Faulty transmitter electronics.	Replace transmitter electronics or contact ABB Service.
F207.023 / Electronics	—	Transmitter NV Error	Faulty communication board.	Replace the communication board or contact ABB Service.
F203.040 / Electronics*	—	Current Output Fault	Current output errors.	Contact ABB Service.

\* Not for devices with Modbus communication

## ... 10Diagnosis / error messages

### ... Possible error messages

#### Function check

Error no. / Range		Text on the LCD display	Cause	Remedy
HART / Modbus	PA / FF			
C202.024 / Electronics*	—	AI Comm Error	Errors in signal at analog input.	Check the electrical connection at the analog input.
—	C160.000 / Operation**	Not Remove FF Check	One of the blocks is out of service.	Contact ABB Service.
C155.045 / Configuration	S155.023 / Operation**	Totalizer Stop	Counter stopped.	Start counter in menu 'Totalizer / Start'.
C154.039 / Configuration*	—	Fixed Current Output	The current output is simulated and is currently set to a specific value. The error message is displayed if the HART address is not 0 (HART multidrop mode, current output is set permanently to 4 mA).	In the 'Diagnostics / Simulation Mode' menu, deactivate simulation mode. Alternatively, set the HART address to 0 in the 'Communication' menu.
—	C153.009 / Operation	No AO Input	Error in AO block.	Check DCS signal.
C153.047 / Configuration*	—	No HART Burst In	Errors in signal at HART input.	Check HART communication with remote transmitter. If necessary, deactivate monitoring of the external HART signal in the 'Process Alarm / Alarm Limits / No HART Input Alarm' menu. Refer to <b>HART® communication with remote transmitter</b> on page 47.
C152.038 / Configuration	C152.010 / Operation	Alarm Simulation	An alarm is being simulated. Alarm simulation is switched on.	Switch off alarm simulation in the 'Diagnostics / Alarm Simulation' menu.
C151.037 / Configuration	C151.011 / Operation	Data Simulation	A process variable is being simulated. Simulation mode is activated.	In the 'Diagnostics / Simulation Mode' menu, deactivate simulation mode. If necessary, deactivate the simulation via the HART communication.

\* Not for devices with Modbus® communication

\*\* Not for devices with PROFIBUS PA® communication

## Operation outside of specifications (out of spec)

Error no. / Range		Text on the LCD display	Cause	Remedy
HART / Modbus	PA / FF			
S116.030 / Operation	S116.022 / Operation	Wrong Steam Type	Incorrect steam type configured.	Check the steam type setting in the 'Device Setup / Plant/Customized / Water/Steam Type' menu.
S115.036 / Operation	—	Flowrate > 103%	The flow rate exceeds the configured upper range value by more than 3 %.	Increase the upper range value in the 'Device Setup / Sensor' menu.
S114.004 / Operation	S114.012 / Operation	Max Flowrate Alarm	The present flow rate is greater than the max. alarm configured.	Reduce the flow rate or increase the value for the max. alarm.
S113.010 / Operation	S113.013 / Operation	Min Flowrate Alarm	The present flow rate is lower than the min. alarm configured.	Increase the flow rate or reduce the value for the min. alarm.
S112.005 / Operation	S112.014 / Operation	Max Int. Temp Alarm	The measuring medium temperature is greater than the max. alarm configured.	Check the measuring medium temperature or increase the value for the max. alarm.
S111.011 / Operation	S111.015 / Operation	Min Int. Temp Alarm	The measuring medium temperature is lower than the min. alarm configured.	Check the measuring medium temperature or reduce the value for the min. alarm.
S110.035 / Operation	S110.016 / Operation	Low Flow Cutoff	The instantaneous flow rate is lower than the set leak flow volume.	Increase flow rate or value for the low flow cut-off in the menu 'Device Setup / Transmitter / Low Flow Cutoff'.
S109.026 / Operation	S109.017 / Operation	Re. Out of Range	The Reynolds number (Re) is lower than the set minimum alarm. Measuring accuracy is reduced if the Reynolds number (Re) falls below a specific value. Refer to <b>Measuring range table</b> on page 145.	Check the device set-up. Increase the flow rate. If necessary, reduce the value for the min. alarm.
S108.012 / Operation*	—	Current Output Saturated	The current output has fallen below or exceeded the measuring range limits. The process value output via the current output is outside of the set limits (3.8 to 20.5 mA).	Check the device set-up. Check the measuring range limit setting for the current output in the 'Input/Output / Current Out' menu and adjust if necessary.
S107.006 / Operation*	—	AI Cut Off	External switching off of output via analog input is active.	Check analog input value. Check the switching point setting for the external output switch-off in the 'Input/Output / Field Input / Ext.Cutoff Trigger' menu and adjust if necessary.

\* Not for devices with Modbus® communication

\*\* Not for devices with PROFIBUS PA® communication

## ... 10Diagnosis / error messages

### ... Possible error messages

Error no. / Range		Text on the LCD display	Cause	Remedy
HART / Modbus	PA / FF			
S106.003 / Operation*	—	AI Out of Range	The signal at the analog input is outside the permissible limits of 3.8 to 20.5 mA.	Check analog input value.
S105.034 / Operation	—	Min Housing T Alarm	The ambient temperature of the transmitter is outside permissible limits.	Ensure that the ambient temperature of the transmitter is within permissible limits.
S104.033 / Operation*	—	Flowrate Cutoff		Check the device installation in accordance with <b>Installation conditions</b> on page 32.
S103.025 / Operation	S103.018 / Operation	Pulse Output Cutoff	Incorrect configuration of pulse output. The maximum pulse rate has been exceeded.	Check the pulse rate in the 'Input/Output / DO Function / Setup Pulse Out' menu and adjust if necessary.
S102.007 / Operation*	—	Max Pressure Alarm	The measuring medium pressure is greater than the max. alarm configured.	Check the measuring medium pressure or increase the value for the max. alarm.
S101.013 / Operation*	—	Min Pressure Alarm	The measuring medium pressure is lower than the min. alarm configured.	Check the measuring medium pressure or reduce the value for the min. alarm.

### Maintenance

Error no. / Range		Text on the LCD display	Cause	Remedy
HART / Modbus	PA / FF			
M054.043 / Operation	M54.019 / Operation	NV Replace Warning	The communication board or frontend board has been replaced without downloading the system data. The system data was not downloaded correctly.	Download the system data, see <b>Replacing the transmitter, downloading system data</b> on page 142.
M053.032 / Operation	—	Voltage Warning	The supply voltage to the transmitter is outside permissible limits.	Check the supply voltage at the transmitter terminals. Check the length of the power supply cable, see <b>Current output / HART output</b> on page 46. Check the external power supply and replace if necessary.
M052.031 / Operation	M53.020 / Operation	Maintenance Warning	Maintenance interval reached.	Adjust the maintenance interval or contact ABB Service to have the device recalibrated.
M051.018 / Operation	M52.021 / Operation	Sensor Not Calibrated	The sensor has not been calibrated or the calibration status has not been set to 'Calibrated'.	Contact ABB Service to have the device recalibrated.

\* Not for devices with Modbus® communication

\*\* Not for devices with PROFIBUS PA® communication



## Response of the outputs to error messages

Error no. / Range	Error text	Current output	Digital output	Error maskable?	
F217.041 / Electronics	—	CO Readback High	High Alarm	Collective alarm	No
F216.042 / Electronics	—	CO Readback Low	Low Alarm	Collective alarm	No
F215.020 / Electronics	F215.001 / Electronics	Sensor Comm Error	High Alarm or Low Alarm, depending on parameter 'lout at Alarm'.	Collective alarm	No
F214.019 / Electronics	F214.002 /	Sensor Sync. Signal Error		Collective alarm	No
F213.000 /	Sensor F213.003 /	Sensor Sig. Sensor Fault		Collective alarm	No
F212.001 / Sensor*	F212.004 /	Sensor Int. T Sensor Fault		Collective alarm	Menu 'Individual Masking'.
F211.002 /	Sensor F211.005 /	Sensor Vbr.Sensor Fault		Collective alarm	No
F210.016 / Electronics	F210.006 / Electronics	Bad SNR		Collective alarm	No
F209.017 / Electronics	F209.007 / Electronics	Sensor NV Error		Collective alarm	No
F208.044 / Electronics	F207.008 / Electronics	Sensor RAM Fault		Collective alarm	No
F207.023 / Electronics	—	Transmitter NV Error		Collective alarm	No
F203.040 / Electronics*	—	Current Output Fault		Collective alarm	No
C202.024 / Electronics*	—	AI Comm Error		Collective alarm	No
—	C160.000 / Operation**	Not Remove FF Check	—	No change	No
C155.045 / Configuration	S155.023 / Operation	Totalizer Stop	Current value - no change.	No change	Menu 'Group Masking'.
C154.039 / Configuration*	—	Fixed Current Output	Fixed value set by simulation.	No change	Menu 'Group Masking'.
—	C153.009 / Operation	No AO Input	—	No change	Menu 'Individual Masking'.
C153.047 / Configuration	—	No HART Burst In	Current value - no change.	No change	Menu 'Group Masking'.
C152.038 / Configuration	C152.010 / Operation	Alarm Simulation	*	**	Menu 'Group Masking'.
C151.037 / Configuration	C151.011 / Operation	Data Simulation	Current or simulated value. Parameter "Simulation Mode / Current Out".	Current or simulated value. Parameter "Simulation Mode / Logic on DO".	Menu 'Group Masking'.

\* If the Int. T Sensor Fault alarms or Flowrate > 103% are simulated, the current output assumes the value for High Alarm or Low Alarm, depending on the 'lout at Alarm' parameter. The currently measured value is output for all other alarms.

\*\* If the Int. T Sensor Fault, Flowrate > 103%, Max Flowrate Alarm, Min Flowrate Alarm alarms or Low Flow Cutoff are simulated, the digital output assumes the status, depending on the 'Alarm Config' parameter. The status remains unchanged for all other alarms.

## ... 10Diagnosis / error messages

### ... Possible error messages

Error no. / Range	Error text	Current output	Digital output	Error maskable?	
S116.030 / Operation	S116.022 / Operation	Wrong Steam Type	Current value - no change.	No change	Menu 'Group Masking'.
S115.036 / Operation	—	Flowrate > 103%	High Alarm or Low Alarm, depending on parameter 'Iout at Alarm'.	Collective alarm	Menu 'Individual Masking'.
S114.004 / Operation	S114.012 / Operation	Max Flowrate Alarm	Current value - no change.	Depending on parameter 'Max Flowrate Alarm'.	Menu 'Individual Masking'.
S113.010 / Operation	S113.013 / Operation	Min Flowrate Alarm	Current value - no change.	Depending on parameter 'Min Flowrate Alarm'.	Menu 'Individual Masking'.
S112.005 / Operation	S112.014 / Operation	Max Int. Temp Alarm	Current value - no change.	Depending on parameter 'Max Sensor T Alarm'.	Menu 'Individual Masking'.
S111.011 / Operation	S111.015 / Operation	Min Int. Temp Alarm	Current value - no change.	Depending on parameter 'Min Sensor T Alarm'.	Menu 'Individual Masking'.
S110.035 / Operation	S110.016 / Operation	Low Flow Cutoff	4 mA	Depending on parameter 'Flow Cutoff Alarm'.	Menu 'Individual Masking'.
S109.026 / Operation	S109.017 / Operation	Re. Out of Range	Current value - no change.	No change	Menu 'Group Masking'.
S108.012 / Operation	—	Current Output Saturated	Configured maximum current.	No change	Menu 'Group Masking'.
S107.006 / Operation	—	AI Cut Off	4 mA	No change	Menu 'Group Masking'.
S106.003 / Operation	—	AI Out of Range	Current value - no change.	No change	Menu 'Group Masking'.
S105.034 / Operation	—	Flowrate Cutoff	Current value - no change.	No change	Menu 'Individual Masking'.
S104.033 / Operation	—	Min Housing T Alarm	Current value - no change.	No change	Menu 'Individual Masking'.
S103.025 / Operation	S103.018 / Operation	Pulse Output Cutoff	Current value - no change.	No change	Menu 'Group Masking'.
S102.007 / Operation	—	Max Pressure Alarm	Current value - no change.	No change	Menu 'Group Masking'.
S101.013 / Operation	—	Min Pressure Alarm	Current value - no change.	No change	Menu 'Group Masking'.
M054.043 / Operation	M54.019 / Operation	NV Replace Warning	Current value - no change.	No change	Menu 'Group Masking'.
M053.032 / Operation	—	Voltage Warning	Current value - no change.	No change	Menu 'Group Masking'.
M052.031 / Operation	M53.020 / Operation	Maintenance Warning	Current value - no change.	No change	Menu 'Group Masking'.
M051.018 / Operation	M52.021 / Operation	Sensor Not Calibrated	Current value - no change.	No change	Menu 'Group Masking'.

## Malfunctions without error messages

Failure	Corrective action	
No flow measurement when there is a flow through the piping	General	See the general information in <b>General Notes</b> on page 131.
		Check whether the flow rate is within the selected measuring range limits of the device.
	Sensor	Check the measuring tube for damage, foreign matter, and deposits that could impair the flow profile. Clean the meter tube if necessary.
		Check the guide body, bluff body, and Piezo sensor in the meter tube for damage.
		Overheating of the Piezo sensor as a result of the permissible measuring medium temperature having been exceeded can damage the Piezo sensor and impair the measurement.
	Application	Check whether there is sufficient back pressure downstream of the device to prevent cavitation.
		Refer to <b>Avoiding cavitation</b> on page 34.
		For test purposes, increase the measuring medium pressure.
		For test purposes, increase / reduce the flow rate.
	Transmitter	Determine the sensor frequency in the 'Diagnostics / Sensor Freq' menu. The frequency must correspond with the requirements set out in the measuring range tables. Refer to <b>Measuring range table</b> on page 145.
		If the sensor frequency seems plausible, check the configuration of the transmitter and the electrical connection.
		Check the function of the outputs in the 'Diagnostics / Simulation Mode' menu.
	Check the configuration of the outputs in the 'Input/Output' menu.	
Incorrect flow measurement when there is a flow through the piping	General	See the general information in <b>Sensor</b> on page 131.
		Check whether the flow rate is within the selected measuring range limits of the device.
	Sensor	Check the meter tube gaskets.
		Even very small leaks can cause a hissing noise and impair the measurement. In the event of low flow rates in relation to the nominal diameter, this results in excessively high flow rates being measured. Hardly any errors occur with higher flow rates.
		If necessary, tighten the flange screws or replace the gaskets.
		Check the measuring tube for damage, foreign matter, and deposits that could impair the flow profile. Clean the meter tube if necessary.
	Application	For test purposes, check the response of the device to changes in the flow.
	Installation	Check whether the inside diameters of the sensor and piping are different from one another.
		Check the inlet and outlet sections and the distances from setting equipment and pipe bends. Refer to <b>Installation conditions</b> on page 32.
		Check the distances from internal piping components such as pressure and temperature measuring points.
		Refer to <b>Installation for external pressure and temperature measurement</b> on page 34.
		Check whether valves are installed in the piping upstream of the sensor. Valves can disrupt the flow profile of the measuring medium and therefore impair the measurement.
	Valves can cause a hissing noise and impair the measurement.	
	Refer to <b>Installation of setting equipment</b> on page 35.	

## ... 10Diagnosis / error messages

### ... Malfunctions without error messages

Error / Malfunction	Corrective action	
Incorrect flow measurement when there is a flow through the piping	Outgassing of measuring media and cavitation	<p>Check whether there is sufficient back pressure downstream of the device to prevent cavitation.</p> <p>Refer to <b>Avoiding cavitation</b> on page 34.</p> <p>For test purposes, increase the measuring medium pressure.</p> <p>Pressure variations in measuring media at high pressures and temperatures can result in outgassing. A typical example is a pressure variation from a high to a low pressure through a valve.</p>
	Pulsating measuring media	<p>Pumps can cause hydraulic oscillations of the measuring medium in the piping. The frequency of this oscillations can be within the range of measuring frequency and thus have an effect on the measuring accuracy.</p> <p>Take appropriate measures to suppress hydraulic oscillations in the measuring medium.</p> <p>When selecting the nominal diameter and device type of piston pumps, ensure that the pump frequency is below the minimum measuring frequency of the sensor.</p>
	Transmitter	<p>Determine the sensor frequency in the 'Diagnostics / Sensor Freq' menu. The frequency must correspond with the requirements set out in the measuring range tables. Refer to <b>Measuring range table</b> on page 145.</p> <p>If the sensor frequency seems plausible, check the configuration of the transmitter and the electrical connection.</p> <p>Check the function of the outputs in the 'Diagnostics / Simulation Mode' menu.</p> <p>Check the configuration of the outputs in the 'Input/Output' menu.</p>
The flowmeter measures a flow rate even though there is no flow through the piping.	General	See instructions in <b>Zero point balance under operating conditions</b> on page 130 and <b>Sensor</b> on page 131.
	Sensor	<p>Check the meter tube gaskets.</p> <p>Even very small leaks can cause a hissing noise and impair the measurement. In the event of low flow rates in relation to the nominal diameter, this results in excessively high flow rates being measured. Hardly any errors occur with higher flow rates.</p> <p>If necessary, tighten the flange screws or replace the gaskets.</p>
	Application	For test purposes, check the response of the device to changes in the flow.
	Installation	<p>Check the seal integrity of closed valves.</p> <p>Valves can cause a hissing noise and impair the measurement.</p>
	Pulsating measuring media	<p>Pumps can cause hydraulic oscillations of the measuring medium in the piping. The frequency of this oscillations can be within the range of measuring frequency and thus have an effect on the measuring accuracy.</p> <p>Take appropriate measures to suppress hydraulic oscillations in the measuring medium.</p> <p>In long lengths of piping, temperature changes and pressure fluctuations can cause movement in the measuring medium, which is then interpreted as flow.</p>
	Transmitter	<p>Determine the sensor frequency in the 'Diagnostics / Sensor Freq' menu. The frequency must correspond with the requirements set out in the measuring range tables. Refer to <b>Measuring range table</b> on page 145.</p> <p>If the sensor frequency seems plausible, check the configuration of the transmitter and the electrical connection.</p> <p>Check the function of the outputs in the 'Diagnostics / Simulation Mode' menu.</p> <p>Check the configuration of the outputs in the 'Input/Output' menu.</p>

# 11 Maintenance

## Safety instructions

### WARNING

#### Risk of injury due to live parts!

When the housing is open, contact protection is not provided and EMC protection is limited.

- Before opening the housing, switch off the power supply.

### CAUTION

#### Risk of burns due to hot measuring media

The device surface temperature may exceed 70 °C (158 °F), depending on the measuring medium temperature!

- Before starting work on the device, make sure that it has cooled sufficiently.

### NOTICE

#### Damage to components!

The electronic components of the printed circuit board can be damaged by static electricity (observe ESD guidelines).

- Make sure that the static electricity in your body is discharged before touching electronic components.

Corrective maintenance work may only be performed by trained personnel.

- Before removing the device, depressurize it along with any adjacent lines or vessels.
- Check whether hazardous materials have been used as measuring medium before opening the device. Residual amounts of hazardous material may still be present in the device and could escape when it is opened.

Within the scope of operator responsibility, check the following as part of a regular inspection:

- pressure-carrying walls / pressure equipment liner
- the measurement-related function
- the leak tightness
- the wear (corrosion)

## Cleaning

When cleaning the exterior of meters, make sure that the cleaning agent used does not corrode the housing surface and the seals.

To avoid static charge, a damp cloth must be used for cleaning.

## Sensor

Essentially no maintenance is required for the sensor.

The following items should be checked annually:

- Ambient conditions (air circulation, humidity).
- Tightness of the process connections,
- Cable entries and cover screws,
- Operational reliability of the power supply, lightning protection, and station ground.

## 12 Repair

Repair and maintenance activities may only be performed by authorized customer service personnel.

When replacing or repairing individual components, use original spare parts.

### Replacing the transmitter, downloading system data

The sensor is equipped with storage capacity — known as the SensorMemory — in which the sensor calibration data and transmitter settings are saved.

In case of a replacement of components, these system data must be loaded into the new component.

Loading of system data is controlled by the DIP switches on the communication board.

See **DIP switch on the HART® communication board** on page 60, **DIP switch on the Modbus communication board** on page 61 and **DIP switch on the PROFIBUS PA®- / FOUNDATION Fieldbus® communication board** on page 84.

#### Note

Depending on the model version (HART® / Modbus® / PROFIBUS®, FOUNDATION Fieldbus®), the positions and designations of the DIP switches may differ.

#### After you replace the complete transmitter or the communication board:

The system data must be transferred from the **sensor** to the **transmitter**.

1. Switch off the power supply.
2. Set DIP switch SW 1.2 (HART) / SW 1.1 (Modbus) / DIP 2 (PROFIBUS, FOUNDATION Fieldbus) to 'ON'.
3. Switch on the power supply.
4. Wait at least 60 seconds and then switch off the power supply.
5. Set DIP switch SW 1.2 (HART) / SW 1.1 (Modbus) / DIP 2 (PROFIBUS, FOUNDATION Fieldbus) to 'OFF'.
6. Switch on the power supply.

The system data has now been transferred from the sensor to the transmitter.

#### After you replace the sensor or the sensor board:

The system data must be transferred from the **transmitter** to the **sensor**.

1. Switch off the power supply.
2. Set DIP switch SW 1.2 (HART) / SW 1.1 (Modbus) / DIP 2 (PROFIBUS, FOUNDATION Fieldbus) to 'ON'.
3. Set DIP switch SW 1.3 (HART) / SW 1.2 (Modbus) / DIP 3 (PROFIBUS, FOUNDATION Fieldbus) to 'ON'.
4. Switch on the power supply.
5. Wait at least 60 seconds and then switch off the power supply.
6. Set DIP switch SW 1.2 (HART) / SW 1.1 (Modbus) / DIP 2 (PROFIBUS, FOUNDATION Fieldbus) to 'OFF'.
7. Set DIP switch SW 1.3 (HART) / SW 1.2 (Modbus) / DIP 3 (PROFIBUS, FOUNDATION Fieldbus) to 'OFF'.
8. Switch on the power supply.

The system data has now been transferred from the transmitter to the sensor.

#### Note

Check the device parameterization before restarting the process!

### Returning devices

Use the original packaging or a secure transport container of an appropriate type if you need to return the device for repair or recalibration purposes.

Fill out the return form (see **Return form** on page 144) and include this with the device.

In accordance with the EU Directive governing hazardous materials, the owner of hazardous waste is responsible for its disposal or must observe the following regulations for shipping purposes:

All devices delivered to ABB must be free from any hazardous materials (acids, alkalis, solvents, etc.).

Address for returns:

Please contact Customer Center Service according to page 5 for nearest service location.

## 13 Dismounting and disposal

### Dismounting

#### **WARNING**

##### **Risk of injury due to process conditions.**

The process conditions, for example high pressures and temperatures, toxic and aggressive measuring media, can give rise to hazards when dismantling the device.

- If necessary, wear suited personal protective equipment during disassembly.
- Before disassembly, make sure that the process conditions do not pose any safety risks.
- Depressurize and empty the device / piping, allow to cool and purge if necessary.

Bear the following points in mind when dismantling the device:

- Switch off the power supply.
- Disconnect electrical connections.
- Allow the device / piping to cool and depressurize and empty. Collect any escaping medium and dispose of it in accordance with environmental guidelines.
- Use suited tools to disassemble the device, taking the weight of the device into consideration.
- If the device is to be used at another location, the device should preferably be packaged in its original packing so that it cannot be damaged.
- Observe the notices in **Returning devices** on page 31.

### Disposal

#### Note



Products that are marked with the adjacent symbol may **not** be disposed of as unsorted municipal waste (domestic waste).

They should be disposed of through separate collection of electric and electronic devices.

This product and its packaging are manufactured from materials that can be recycled by specialist recycling companies.

Bear the following points in mind when disposing of them:

- As of 8/15/2018, this product will be under the open scope of the WEEE Directive 2012/19/EU and relevant national laws (for example, ElektroG - Electrical Equipment Act - in Germany).
- The product must be supplied to a specialist recycling company. Do not use municipal waste collection points. These may be used for privately used products only in accordance with WEEE Directive 2012/19/EU.
- If there is no possibility to dispose of the old equipment properly, our Service can take care of its pick-up and disposal for a fee.

## 14 Specification

#### Note

The device data sheet is available in the ABB download area at [www.abb.com/flow](http://www.abb.com/flow).

## 15 Additional documents

#### Note

All documentation, declarations of conformity, and certificates are available in ABB's download area.

[www.abb.com/flow](http://www.abb.com/flow)

## 16 Appendix

### Return form

#### Statement on the contamination of devices and components

Repair and/or maintenance work will only be performed on devices and components if a statement form has been completed and submitted.

Otherwise, the device/component returned may be rejected. This statement form may only be completed and signed by authorized specialist personnel employed by the operator.

#### Customer details:

Company: \_\_\_\_\_

Address: \_\_\_\_\_

Contact person: \_\_\_\_\_

Telephone: \_\_\_\_\_

Fax: \_\_\_\_\_

Email: \_\_\_\_\_

#### Device details:

Type: \_\_\_\_\_

Serial no.: \_\_\_\_\_

Reason for the return/description of the defect: \_\_\_\_\_

#### Was this device used in conjunction with substances which pose a threat or risk to health?

Yes       No

If yes, which type of contamination (please place an X next to the applicable items):

biological

corrosive / irritating

combustible (highly / extremely combustible)

toxic

explosive

other toxic substances

radioactive

Which substances have come into contact with the device?

1. \_\_\_\_\_

2. \_\_\_\_\_

3. \_\_\_\_\_

We hereby state that the devices/components shipped have been cleaned and are free from any dangerous or poisonous substances.

\_\_\_\_\_  
Town/city, date

\_\_\_\_\_  
Signature and company stamp



## Measuring range table

### FSV430, FSV450

#### Flow measurement for liquids

Nominal diameter	Minimum Reynolds number		$Q_{\max} DN^3$		Frequency for $Q_{\max}^4$
	Re1 <sup>1</sup>	Re2 <sup>2</sup>	[m <sup>3</sup> /h]	[Usgpm]	[Hz, ±5 %]
DN 15 (½ in)	11300	20000	7	31	430
DN 25 (1 in)	13100	20000	18	79	247
DN 40 (1½ in)	15300	20000	48	211	193
DN 50 (2 in)	15100	20000	75	330	155
DN 80 (3 in)	44000	44000	170	749	101
DN 100 (4 in)	36400	36400	270	1189	73
DN 150 (6 in)	58000	58000	630	2774	51
DN 200 (8 in)	128000	128000	1100	4844	40
DN 250 (10 in)	100000	100000	1800	7926	33
DN 300 (12 in)	160000	160000	2600	11449	28

#### Flow measurement of gases and steam

Nominal diameter Flange		Minimum Reynolds number		$Q_{\max} DN^3$		Frequency for $Q_{\max}^4$
		Re1 <sup>1</sup>	Re2 <sup>2</sup>	[m <sup>3</sup> /h]	[ft <sup>3</sup> /min]	[Hz, ±5 %]
DN 15 (½ in)	DIN	4950	10000	42	25	2640
	ASME			36	21,4	3000
DN 25 (1 in)	DIN	6600	10000	150	88	2040
	ASME			130	76	2960
DN 40 (1 ½ in)	DIN	6750	10000	390	230	1580
	ASME			390	230	2240
DN 50 (2 in)	DIN	9950	20000	630	371	1310
	ASME			630	371	1720
DN 80 (3 in)	DIN	13000	20000	1380	812	820
	ASME			1380	812	1120
DN 100 (4 in)	DIN	16800	20000	2400	1413	640
	ASME			2400	1413	850
DN 150 (6 in)	DIN	26500	27000	5400	3178	430
	ASME			5400	3178	540
DN 200 (8 in)	DIN	27600	28000	9600	5650	350
	ASME			9600	5650	420
DN 250 (10 in)	DIN	41000	41000	16300	9594	290
	ASME			16300	9594	320
DN 300 (12 in)	DIN	48000	48000	23500	13832	260
	ASME			23500	13832	270

1 Minimum Reynolds number from which the function takes effect. For accurate dimensioning of the flowmeter, please use the ABB Product Selection Assistant (PSA) for flow rate at [www.abb.com/flow-selector](http://www.abb.com/flow-selector).

2 Minimum Reynolds number from which the specified accuracy is achieved. Below this value, the measuring error is 0.5 % of  $Q_{\max}$ .

3 Medium velocity approx. 90 m/s (295 ft/s). For devices with nominal diameter DN 15 (½ in), the maximum medium velocity is 60 m/s (180 ft/s).

4 For information only, precise values can be found in the test log delivered with the device.

## ... 16 Appendix

### ... Measuring range table

#### FSS430, FSS450

##### Flow measurement for liquids

Nominal diameter	Minimum Reynolds number		$Q_{max} DN^3$		Frequency for $Q_{max}^4$
	Re1 <sup>1</sup>	Re2 <sup>2</sup>	[m <sup>3</sup> /h]	[Usgpm]	[Hz, ±5 %]
DN 15 (½ in)	2100	5000	2.5	11	297
DN 20 (¾ in)	3130	5000	4	18	194
DN 25 (1 in)	5000	7500	8	35	183
DN 32 (1¼ in)	6900	7500	16	70	150
DN 40 (1½ in)	8400	10000	20	88	116
DN 50 (2 in)	6000	10000	30	132	100
DN 80 (3 in)	9000	10000	120	528	89
DN 100 (4 in)	17500	18000	180	793	80
DN 150 (6 in)	28500	28500	400	1760	51
DN 200 (8 in)	30300	30300	700	3082	37
DN 300 (12 in)	114000	114000	1600	7045	24
DN 400 (16 in)	163000	163000	2,500	11000	19

##### Flow measurement of gases and steam

Nominal diameter	Minimum Reynolds number		$Q_{max} DN^3$		Frequency for $Q_{max}^4$
	Re1 <sup>1</sup>	Re2 <sup>2</sup>	[m <sup>3</sup> /h]	[ft <sup>3</sup> /min]	[Hz, ±5 %]
DN 15 (½ in)	2360	5000	20	12	2380
DN 20 (¾ in)	3510	5000	44	26	2140
DN 25 (1 in)	4150	5000	90	53	2060
DN 32 (1¼ in)	3650	5000	230	135	2150
DN 40 (1½ in)	6000	7500	300	177	1740
DN 50 (2 in)	7650	10000	440	259	1450
DN 80 (3 in)	16950	17000	1160	683	860
DN 100 (4 in)	11100	12000	1725	1015	766
DN 150 (6 in)	23300	24000	3800	2237	510
DN 200 (8 in)	18400	20000	5800	3414	340
DN 300 (12 in)	31600	32000	13600	8005	225
DN 400 (16 in)	33500	34000	21500	12655	180

- 1 Minimum Reynolds number from which the function takes effect. For accurate dimensioning of the flowmeter, please use the ABB Product Selection Assistant (PSA) for flow rate at [www.abb.com/flow-selector](http://www.abb.com/flow-selector).
- 2 Minimum Reynolds number from which the specified accuracy is achieved. Below this value, the measuring error is 0.5 % of  $Q_{max}$ .
- 3 Medium velocity approx. 90 m/s (295 ft/s). For devices with nominal diameter DN 15 (½ in), the maximum medium velocity is 60 m/s (180 ft/s).
- 4 For information only, precise values can be found in the test log delivered with the device.

## Trademarks

HART is a registered trademark of FieldComm Group, Austin, Texas, USA

Modbus is a registered trademark of Schneider Automation Inc.

PROFIBUS and PROFIBUS PA are registered trademarks of PROFIBUS & PROFINET International (PI)

FOUNDATION Fieldbus is a registered trademark of FieldComm Group, Austin, Texas, USA.

Kalrez and Kalrez Spectrum are registered trademarks of DuPont Performance Elastomers.

Hastelloy C is a trademark of Haynes International

---

## **ABB Measurement & Analytics**

For your local ABB contact, visit:  
**[www.abb.com/contacts](http://www.abb.com/contacts)**

For more product information, visit:  
**[www.abb.com/flow](http://www.abb.com/flow)**

---

We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail. ABB does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents – in whole or in parts – is forbidden without prior written consent of ABB.